

SECTION **ACS**

AUTO CRUISE CONTROL SYSTEM

CONTENTS

		A
		B
		C
		D
		E
ASCD		F
AUTOMATIC SPEED CONTROL DEVICE (ASCD)....		G
Description	3	
ICC		H
PRECAUTIONS	4	I
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	4	
Precautions for ICC System Service	4	
PREPARATION	5	J
Special Service Tools	5	
DESCRIPTION	6	ACS
Outline	6	L
VEHICLE-TO-VEHICLE DISTANCE CONTROL MODE	6	
CONVENTIONAL (FIXED SPEED) CRUISE CONTROL MODE	6	
BRAKE ASSIST (WITH PREVIEW FUNCTION)....	6	M
Functional Diagram	7	
Components Description	9	
CAN Communication	9	
CAN COMMUNICATION UNIT	9	
Switch Operation	10	
ICC System Display	10	
ACTION TEST	11	
ICC System Running Test	11	
VEHICLE-TO-VEHICLE DISTANCE CONTROL MODE	11	
CONVENTIONAL (FIXED SPEED) CRUISE CONTROL MODE	12	
LASER BEAM AIMING ADJUSTMENT	14	
Outline	14	
Preparation	14	
Outline of Adjustment Procedure	14	
Setting the ICC Target Board	14	
ADJUSTING HEIGHT OF THE TARGET	14	
ADJUSTING THE RIGHT-LEFT POSITION OF THE TARGET	15	
SETTING THE TARGET	15	
Aiming Adjustment	17	
CHECK AFTER THE ADJUSTMENT	18	
ELECTRICAL UNITS LOCATION	19	
Component Parts and Harness Connector Location..	19	
WIRING DIAGRAM	20	
Schematic	20	
Wiring Diagram — ICC —	21	
TERMINALS AND REFERENCE VALUE	28	
Terminals and Reference Value for ICC Unit	28	
Terminals and Reference Value for ICC Sensor	29	
TROUBLE DIAGNOSIS — GENERAL DESCRIPTION	30	
Work Flow	30	
CONSULT-II Function (ICC)	31	
DESCRIPTION	31	
CONSULT-II BASIC OPERATION	31	
WORK SUPPORT	32	
SELF-DIAGNOSTIC RESULTS	32	
DATA MONITOR	33	
ACTIVE TEST	35	
Self-Diagnostic Function	37	
WITH CONSULT-II	37	
WITHOUT CONSULT-II	37	
SELF-DIAGNOSIS BY ICC SYSTEM DISPLAY WILL NOT RUN	39	
TROUBLE DIAGNOSIS FOR SELF-DIAGNOSTIC ITEMS	42	
Diagnostic Trouble Code (DTC) Chart	42	
DTC 11 CONTROL UNIT	44	
DTC 20 CAN COMM CIRCUIT	44	
DTC 31 POWER SUPPLY CIR, DTC 34 POWER SUPPLY CIR 2	44	
DTC 41 VHCL SPEED SE CIRC	45	
DTC 43 ABS/TCS/VDC CIRC	46	
DTC 45 BRAKE SW/STOP L SW	46	
DTC 46 OPERATION SW CIRC	48	
DTC 61 PRESS SEN CIRCUIT	50	
DTC 62 BOOSTER SOL/V CIRCUIT	51	
DTC 63 RELEASE SW CIRCUIT	52	

DTC 65 PRESSURE CONTROL	54	the A/T Selector Lever Is in Other Than “D” and “M” Position	70
DTC 74 LASER BEAM OFF CNTR	55	Symptom 5: Chime Does Not Sound	70
DTC 90 STOP LAMP RLY FIX	55	Symptom 6: Driving Force Is Hunting	71
DTC 92 ECM CIRCUIT	61	Symptom 7: ICC System Frequently Cannot Detect the Vehicle Ahead/ Detection Zone Is Short	71
DTC 96 NP RANGE	62	Symptom 8: The System Does Not Detect the Vehi- cle Ahead at All	72
DTC 97 AT CIRCUIT	64	ELECTRICAL COMPONENT INSPECTION	73
DTC 98 GEAR POSITION	64	ICC Steering Switch	73
DTC 102 RADAR STAIN	65	Booster Solenoid	73
DTC 103 LASER SENSOR FAIL	65	Release Switch	73
DTC 104 LASER AIMING INCMP	66	ICC Brake Switch and Stop Lamp Switch	74
DTC 107 LASER COMM FAIL	66	ICC Brake Hold Relay	74
DTC 109 LASER HIGH TEMP	66	REMOVAL AND INSTALLATION	75
TROUBLE DIAGNOSIS FOR SYMPTOMS	67	ICC Unit	75
Symptom Chart	67	REMOVAL	75
Symptom 1: MAIN Switch Does Not Turn ON* ¹ , MAIN Switch Does Not Turn OFF* ²	68	INSTALLATION	75
Symptom 2: ICC System Cannot Be Set (MAIN Switch Turns ON/OFF)	68	ICC Sensor	75
Symptom 3: ICC System Cannot Be Operated by CANCEL Switch, RESUME/ACCELERATE Switch or DISTANCE Switch	69	REMOVAL	75
Symptom 4: ICC System Is Not Cancelled When the A/T Selector Lever Is in Other Than “D” and “M” Position		INSTALLATION	76
		ICC Steering Switch	76

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

[ASCD]

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

PFP:18930

Description

NKS003EF

Regarding the information for ASCD system, refer to [EC-36, "AUTOMATIC SPEED CONTROL DEVICE \(ASCD\)"](#) (VQ35DE), [EC-696, "AUTOMATIC SPEED CONTROL DEVICE \(ASCD\)"](#) (VK45DE).

A

B

C

D

E

F

G

H

I

J

ACS

L

M

PRECAUTIONS

PFP:00001

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

NKS003EG

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precautions for ICC System Service

NKS003EH

- Never look straight into the laser beam discharger when adjusting laser beam aiming.
- Turn the MAIN switch OFF in conditions similar to driving, such as free rollers or a chassis dynamometer.
- Do not use the ICC sensor removing from vehicle, disassemble, or remodel the sensor.
- Erase DTC when replacing parts of ICC system, then check the operation of ICC system after adjusting laser beam aiming if necessary.

PREPARATION

[ICC]

PREPARATION

PFP:00002

Special Service Tools

NKS003EI

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
KV99110100 (J-45718) ICC target board	Uses for laser beam aiming adjustment



PKIA0358J

A
B
C
D
E
F
G
H
I
J
L
M

ACS

DESCRIPTION**Outline**

NKS003EJ

The Intelligent Cruise Control (ICC) system automatically maintains a selected distance from the vehicle ahead according to that vehicle's speed, or at the set speed, if the road ahead is clear. The ICC function has two cruise control modes and brake assist (with preview function).

VEHICLE-TO-VEHICLE DISTANCE CONTROL MODE

With vehicle-to-vehicle distance control mode, the driver can maintain the same speed as other vehicles without the constant need to adjust the set speed as the driver would with a normal cruise control system. The system is intended to enhance the operation of the vehicle when following the vehicle traveling in the same lane and direction.

If the distance sensor detects a slower moving vehicle ahead, the system will reduce speed so that the vehicle ahead can be followed at the selected distance.

The system automatically controls the throttle and applies the brakes (up to 25% of vehicle braking power) if necessary.

The detection range of the sensor is approximately 120 m (390 ft) ahead.

Refer to Owner's Manual for Intelligent Cruise Control System operating instructions.

CONVENTIONAL (FIXED SPEED) CRUISE CONTROL MODE

Conventional (fixed speed) cruise control mode is cruising at preset speeds.

Refer to Owner's Manual for Intelligent Cruise Control System operating instructions.

BRAKE ASSIST (WITH PREVIEW FUNCTION)


When the force applied to brake pedal exceeds a certain level, the Brake Assist is activated and generates a greater braking force than that of a conventional brake booster even with light pedal force.

When the Preview Function identifies the need to apply the sudden brake by sensing the vehicle ahead in the same lane and the distance and relative speed from it, it applies the brake pre-pressure before driver depress the brake pedal and improves brake response by reducing its free play.

Refer to Owner's Manual for BRAKE ASSIST (WITH PREVIEW FUNCTION) operating instructions.

Functional Diagram

NKS0031D



Items of input/output signal to be checked with CONSULT-II

Input	Data monitored Item [unit]	CAN	Description
ECM	THRTL OPENING [%]	×	Indicates throttle angle read by ICC unit through CAN communication (ECM transmits throttle angle through CAN communication).
	ENGINE RPM [rpm]	×	Indicates engine speed read by ICC unit through CAN communication (ECM transmits engine speed through CAN communication).
	MAIN SW [ON/OFF]	×	Indicates [ON/OFF] status as judged from steering switch signal (ECM transmits steering switch signal through CAN communication).
	SET/COAST SW [ON/OFF]	×	Indicates [ON/OFF] status as judged from steering switch signal (ECM transmits steering switch signal through CAN communication).
	CANCEL SW [ON/OFF]	×	Indicates [ON/OFF] status as judged from steering switch signal (ECM transmits steering switch signal through CAN communication).
	RESUME/ACC SW [ON/OFF]	×	Indicates [ON/OFF] status as judged from steering switch signal (ECM transmits steering switch signal through CAN communication).
	IDLE SW [ON/OFF]	×	Indicates [ON/OFF] status of idle switch read by ICC unit through CAN communication (ECM transmits ON/OFF status through CAN communication).
TCM	VHCL SPD AT [km/h] or [mph]	×	Indicates vehicle speed calculated from AT vehicle speed sensor by ICC unit through CAN communication (TCM transmits AT vehicle speed sensor signal through CAN communication).
	GEAR [1, 2, 3, 4, 5]	×	Indicates AT gear position read by ICC unit through CAN communication (TCM transmits gear position through CAN communication).
	D RANGE SW [ON/OFF]	×	Indicates [ON/OFF] status of "D" position read by ICC unit through CAN communication (TCM transmits ON/OFF condition of "D" position through CAN communication).
	NP RANGE SW [ON/OFF]	×	Indicates PNP switch signal read by ICC unit through CAN communication (TCM transmits PNP switch signal through CAN communication).

DESCRIPTION

[ICC]

Input	Data monitored Item [unit]	CAN	Description
ABS actuator and electric unit (control unit)	VHCL SPEED SE [km/h] or [mph]	×	Indicates vehicle speed calculated from wheel sensor by ICC unit through CAN communication (ABS actuator and electric unit (control unit) transmits wheel speed sensor signal through CAN communication).
BCM	WIPER SW [OFF/LOW/HIGH]	×	Indicates wiper [OFF/LOW/HIGH] status (BCM transmits front wiper request signal through CAN communication).
Brake pressure sensor	PRESS SENS [bar]		Indicates brake fluid pressure value calculated from signal voltage of pressure sensor.
Release switch	RELEASE SW NO [ON/OFF]		Indicates [ON/OFF] status as judged from release switch signal. ON when brake is depressed. OFF when brake is not depressed.
	RELEASE SW NC [ON/OFF]		Indicates [ON/OFF] status as judged from release switch signal. ON when brake is not depressed. OFF when brake is depressed.
ICC brake switch	BRAKE SW [ON/OFF]		Indicates [ON/OFF] status as judged from ICC brake switch signal.
Stop lamp switch	STOP LAMP SW [ON/OFF]		Indicates [ON/OFF] status as judged from stop lamp switch signal.

Output	Data monitored Item [unit]	CAN	Description
ICC warning chime	BUZZER O/P [ON/OFF]	×	Indicates [ON/OFF] status of ICC warning chime output.
ICC brake hold relay	STP LMP DRIVE [ON/OFF]		Indicates [ON/OFF] status of brake hold relay drive output.

Output	CONSULT-II ICC [ACTIVE TEST] Item	CAN	Description
Combination meter	ICC BUZZER 1	×	Able to start ICC warning chime with a driving signal from ICC unit.
	METER LAMP	×	Able to turn ICC system display ON with a driving signal from ICC unit.
ICC brake hold relay	STOP LAMP		Able to start ICC brake hold relay with a driving signal from ICC unit.
Booster solenoid	BOOSTER SOL/V 3		Able to start booster solenoid with a driving signal from ICC unit.

Components Description

NKS003EL

Component	Vehicle-to-vehicle distance control mode	Conventional (fixed speed) cruise control mode	Brake assist (with pre-view function)	Description
ICC unit	×	×	×	Operates electric throttle control actuator and brake booster based on that sensor signals and CAN communication data, then controls vehicle distance.
ICC sensor	×		×	Irradiates laser beam, and receives reflected laser beam to measure distance from preceding vehicle.
ECM	×	×	×	Transmits throttle position signal and ICC steering switch signal to ICC unit through CAN communication.
ABS actuator and electric unit (control unit)	×	×	×	Transmits wheel speed sensor signal to ICC unit through CAN communication.
Brake pressure sensor	×		×	Detects fluid pressure in master cylinder.
Brake booster	×		×	Adjusts brake fluid pressure, based on command from ICC unit.
BCM	×			Transmit front wiper request signal to ICC unit through CAN communication.
TCM	×	×		Transmits gear position signal and output shaft revolution signal to ICC unit through CAN communication.
Unified meter and A/C amp.	×	×	×	Receives ICC system display signal, ICC warning lamp signal and buzzer output signal from ICC unit through CAN communication.
ICC brake switch, stop lamp switch	×	×	×	Transmit operating signal to ICC unit when touching brake pedal. ICC unit cancels cruise system at driver's brake operation.
ICC brake hold relay	×			Receives stop lamp driving signal from ICC unit, and turns stop lamp ON.
Parking brake switch	×	×		The cruise system is cancelled when applied.

CAN Communication

NKS003EM

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electric control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN COMMUNICATION UNIT


Refer to [LAN-32, "CAN Communication Unit"](#) .

A
B
C
D
E
F
G
H
I
J
L
M

ACS

Switch Operation


The system is operated by MAIN switch and four control switches, all mounted on the steering wheel.



SKIB8558E

No.	Switch name	Description
1	RESUME/ACCELERATE switch	Resumes set speed or increases speed incrementally.
2	SET/COAST switch	Sets desired cruise speed, reduces speed incrementally.
3	CANCEL switch	Deactivates system without erasing set speed.
4	MAIN switch	Master switch to activate the system
5	DISTANCE switch	Changes the following distance from: Long, Middle, Short.

ICC System Display



SKIA6177E

No.	Display items	Description
1	Set vehicle speed indicator	Indicates the set vehicle speed. ● For CANADA models: km/h ● For US models: MPH
2	Vehicle ahead detection indicator	Indicates whether it detects a vehicle ahead.
3	Set distance indicator	Display the selected distance between vehicles set with the DISTANCE switch.
4	Own vehicle indicator	Indicates the base vehicle.
5	MAIN switch indicator lamp (Green)	Indicates that the MAIN switch is ON.
6	Intelligent cruise control system warning lamp (Orange)	The light comes on if there is a malfunction in the ICC system.
7	SET switch indicator lamp	Indicates that the conventional cruise control mode is controlled.

ACTION TEST

PFP:00000

**ICC System Running Test
VEHICLE-TO-VEHICLE DISTANCE CONTROL MODE**

NKS003EP

Set Checking

1. Press the MAIN switch for less than 1.5 seconds.
2. Drive the vehicle between 40 km/h (25 MPH) and 144 km/h (90 MPH).
3. Push the SET/COAST switch.
4. Confirm that the desired speed is set as hand is released from the SET/COAST switch.

NOTE:

- When there is no vehicle ahead, drive at the set speed steadily.
- When there is a vehicle ahead, control to maintain distance from the vehicle ahead, watching its speed.
- The set vehicle speed is displayed on the ICC system indicator in the combination meter.

Check For Increase Of Cruising Speed

1. Set vehicle-to-vehicle distance control mode at desired speed.
2. Check if the set speed increases by 1 km/h (1 MPH) as RESUME/ACCELERATE switch is pushed.

NOTE:

The maximum set speed of the vehicle-to-vehicle distance control mode is 144 km/h (90 MPH).

Check For Decrease Of Cruising Speed

1. Set vehicle-to-vehicle distance control mode at desired speed.
2. Check if the set speed decreases by 1 km/h (1 MPH) as SET/COAST switch is pushed.

NOTE:

- Vehicle-to-vehicle distance control mode is automatically turned off when the driving speed lowers to 32 km/h (20 MPH) due to the deceleration of the vehicle ahead.
- The minimum set speed of the vehicle-to-vehicle distance control mode is 40 km/h (25 MPH).

Check For Cancellation Of Vehicle-To-Vehicle Distance Control Mode (Normal Driving Condition) In The Following Cases:


- When the brake pedal is depressed after the system is turned ON.
- When the selector lever is shifted to the "N" (Neutral) position.
- When the MAIN switch is turned OFF.
- When CANCEL switch is operated.

Check For Restoring Speed That Is Set By Vehicle-To-Vehicle Distance Control Mode Before Cancellation

1. Cancel the system by depressing the foot brake. Then, check that the speed before cancellation is restored when pressing RESUME/ACCELERATE switch with 40 km/h (25 MPH) or above.
2. Cancel the system by shifting the selector lever to "N" position. Then, check if the speed set before the cancellation is restored when RESUME/ACCELERATE switch is pushed up.
3. Check if the speed previously set is restored when RESUME/ACCELERATE switch is operated with driving 40 km/h (25 MPH), after canceling vehicle-to-vehicle distance control mode by operating the CANCEL switch.

Check For MAIN Switch

1. Start engine. Then, check if the following operations are performed correctly.
2. Vehicle-to-vehicle distance control mode is displayed in combination meter illuminates when MAIN switch is pressed "ON" for less than 1.5 seconds and ready for operation. The illumination goes off when MAIN switch is turned to OFF.
3. "CRUISE" illumination and ICC system display go off when the ignition switch is turned to OFF while MAIN switch is ON ("CRUISE" illumination is ON and vehicle-to-vehicle distance control mode is ready for operation).



Check For RESUME/ACCELERATE, SET/COAST, CANCEL Switches




1. Check if RESUME/ACCELERATE, SET/COAST, CANCEL switches are operated smoothly.
2. Check if buttons come up as hand is released from the buttons.

Check For Distance Switch

1. Start engine.
2. Press the MAIN switch for less than 1.5 seconds.
3. Press the DISTANCE switch.
4. Check if the set distance indicator changes display in order of: (Long)→(Middle)→(Short).

NOTE:

The set distance indicator shows (Long) immediately after the engine starts.

Distance	Display	Approximate distance at 100 km/h (60 MPH) [m (ft)]
Long		60 (195)
Middle		40 (130)
Short		30 (90)

SKIB8746E

CONVENTIONAL (FIXED SPEED) CRUISE CONTROL MODE

Set Checking

1. Press the MAIN switch for more than 1.5 seconds.
2. Drive the vehicle between 40 km/h (25 MPH) and 144 km/h (90 MPH).
3. Push down the SET/COAST switch.
4. Confirm that the desired speed is set as hand is released from the SET/COAST switch.

NOTE:

ICC system display in the combination meter shows nothing.

Check For Increase Of Cruising Speed

1. Set the conventional (fixed speed) cruise control mode at desired speed.
2. Check if the set speed increases by 1.6 km/h (1 MPH) as RESUME/ACCELERATE switch is pushed up.

NOTE:

- If the RESUME/ACCELERATE switch is kept pushing up during cruise control driving, the vehicle speed increases until the switch is released.
- The maximum set speed is 144 km/h (90 MPH).

Check For Decrease Of Cruising Speed

1. Set the conventional (fixed speed) cruise control mode at desired speed.
2. Check if the set speed decreases by 1.6 km/h (1 MPH) as SET/COAST switch is pushed down.

NOTE:

- Conventional (fixed speed) cruise control mode is automatically turned off when the driving speed lowers to 32 km/h (20 MPH).
- The minimum set speed is 40 km/h (25 MPH).

Check For Cancellation Of Conventional (Fixed Speed) Cruise Control Mode (Normal Driving Condition) In The Following Cases:


Refer to [ACS-11, "Check For Cancellation Of Vehicle-To-Vehicle Distance Control Mode \(Normal Driving Condition\) In The Following Cases:"](#) .

Check For Restoring Speed That Is Set By Conventional (Fixed Speed) Cruise Control Mode Before ICC Cancellation

Refer to [ACS-11, "Check For Restoring Speed That Is Set By Vehicle-To-Vehicle Distance Control Mode Before Cancellation"](#) .

Check For MAIN Switch

1. Start engine. Then, check if the following operations are performed correctly.
2. "CRUISE" lamp illuminates and ICC system indicator goes off when MAIN switch is pressed "ON" for more than 1.5 seconds, and then ready for operation. The illumination goes off when MAIN switch is turned to OFF.
3. "CRUISE" illumination go off when the ignition switch is turned to OFF while MAIN switch is ON.



Check For RESUME/ACCELERATE, SET/COAST, CANCEL Switches

1. Check if RESUME/ACCELERATE, SET/COAST, CANCEL switches are operated smoothly.
2. Check if buttons come up as hand is released from the buttons.

LASER BEAM AIMING ADJUSTMENT

Outline

NKS003EO

Adjust the laser beam aiming every time the ICC sensor is removed or installed.


CAUTION:

- Adjust laser beam aiming at a horizontal place as far as 12 m (39 ft) forward the vehicle can be seen.
- Adjust laser beam aiming 5 seconds after starting engine.
- Never view ICC sensor integrated unit body window directly during laser beam aiming adjustment.
- Follow the CONSULT-II when adjusting the laser beam aiming (laser beam aiming adjustment cannot be operated without CONSULT-II).
- Never ride on vehicle during laser beam aiming adjustment.
- Idle and turn headlamps OFF during laser beam aiming adjustment.

Preparation

NKS003ER

- Adjust the tire pressure to the specified value.
- See that there is no load in the vehicle.
- Coolant, engine oil filled up to correct level and full fuel tank.
- Shift the gear into "P" position and release the parking brake.
- Clean the ICC sensor with a soft cloth.



Outline of Adjustment Procedure

NKS003ES

1. Set up the ICC target board [KV99110100 (J-45718)].
2. Adjust the sensor following the procedure on CONSULT-II. (Turn manually the screw for up-down position adjustment. ICC sensor automatically adjust the right-left position.)

Setting the ICC Target Board

NKS003ET


Accurate ICC target board setting is required for the laser beam aiming adjustment.

CAUTION:

ICC system does not function normally if laser beam aiming is not accurate.

ADJUSTING HEIGHT OF THE TARGET


1. Attach a triangle scale at the center.



LASER BEAM AIMING ADJUSTMENT

[ICC]


2. Adjust the height of the target board stand so that the point of the triangle aims the center of the ICC sensor.



A
B
C
D


ADJUSTING THE RIGHT-LEFT POSITION OF THE TARGET

1. Attach a scale [at least 350 mm (14 in) or longer] or stick as shown in the figure.



E
F
G

2. Suspend a thread with weight on the tip of the thread to 310 mm (12.2 in) left side of the target board from the center of the target board on top.




H
I
J

ACS

SETTING THE TARGET

1. Suspend a thread with weight on tip to splice the center of the front and rear bumpers. Then, mark the center point on the ground as each weight points.
2. Link the front and rear bumpers center points marked on the ground, and mark a point 5 m (16.4 ft) ahead of the sensor, on the extended line of the previous link line of the bumper center points. Then, adjust the position of the target board so that the weight come on the top of the marked point [5 m (16.4 ft) ahead of the sensor] and face to the vehicle.
3. Adjust the position of the target board so that the extended line that links the center of the rear window glass (the center of the rear window defogger pattern) and the center of the windshield (the setting part of the room mirror) align with the weight suspended from the board.
4. Remove the thread suspended to the left side of board and suspend a thread with weight on tip on the center of the target board. Then mark the point of weight on the ground.



L
M



LASER BEAM AIMING ADJUSTMENT

[ICC]


5. Pivot the edge of the target board 20° to either side.

NOTE:

Approx. 50 mm (1.97 in) shift rates the 20° movement.



6. Do not place anything in the space shown in the figure (view from top).



NOTE:

In case the space shown in the figure is not available, make space by covering the side of the target board with a 400 mm (15.75 in)-size frosted black board or black cloth.

Aiming Adjustment


CAUTION:

Complete all necessary work for laser beam adjustment until the adjustment completes as shown in the procedure. If the procedure does not complete, the ICC system is inoperable.

NOTE:

CONSULT-II basic operation: Refer to [GI-38, "CONSULT-II Start Procedure"](#) .

1. Touch "WORK SUPPORT".
2. Touch "LASER BEAM ADJUST".



3. Touch "START".



CAUTION:

If the adjustment screen does not appear on the CONSULT-II screen in 10 seconds. After touching "LASER BEAM ADJUST" screen, the following causes may be considered:

- Target is not set accurately.
 - There is not enough space beside the target.
 - Deformation of vehicle or the surrounding equipment unit, bracket, or the surrounding equipment is causing inappropriate installation of sensor and aiming may be set out of the adjustable range.
 - The area is not suitable for the adjustment work.
 - ICC sensor is not clean.
4. After the CONSULT-II displays "ADJUST THE VERTICAL OF LASER BEAM AIMING" turn the up-down direction adjusting screw until "U/D CORRECT" value is set in the range of ± 4 .


CAUTION:

Turn the screw slowly. The value change on display is slower than actual movement of the ICC sensor. Wait for 2 seconds every time the screw is turned half a rotation.



NOTE:

Turning the screw to the right lowers the aiming and to the left lifts the aiming.



A
B
C
D
E
F
G
H
I
J

ACS

L
M

LASER BEAM AIMING ADJUSTMENT

[ICC]

5. When "U/D CORRECT" value indicates ± 4 , confirm that the margin of value remains within ± 4 at least for 2 seconds with no equipment or hand touching the ICC sensor. When "COMPLETED THE VERTICAL AIMING OF LASER BEAM" appears on screen, touch "END".

CAUTION:

Be sure that the margin of "U/D CORRECT" is within ± 4 with ICC sensor unit is untouched.

LASER BEAM ADJUST	
COMPLETED THE VERTICAL AIMING OF LASER BEAM.	
WHEN TOUCHED "END", THEN PERFORM THE ADJUSTMENT OF HORIZONTAL AIMING OF LASER BEAM.	
MONITOR	
U/D CORRECT	-2
ADJ DIRECTION	OK
END	INTERRUPTED

SKIA1223E

6. Confirm that "ADJUSTING AUTOMATIC HORIZONTAL LASER BEAM AIMING" is on screen and wait for a while (maximum: 10 seconds).

LASER BEAM ADJUST	
ADJUSTING AUTOMATIC HORIZONTAL LASER BEAM AIMING.	
MONITOR	
	INTERRUPTED

SKIA1224E

7. Confirm that "NORMALLY COMPLETED" is displayed on CONSULT-II and close the aiming adjustment procedure by touching "END".

CAUTION:

Complete all the procedures once "LASER BEAM ADJUST" mode is entered in CONSULT-II. When the procedure is discontinued, the ICC system is inoperable.

LASER BEAM ADJUST	
NORMALLY COMPLETED	
MONITOR	
END	

SKIA1225E

CHECK AFTER THE ADJUSTMENT

Test the ICC system operation by running test. Refer to [ACS-11, "ICC System Running Test"](#).

ELECTRICAL UNITS LOCATION

[ICC]










ELECTRICAL UNITS LOCATION

PPF:25230

Component Parts and Harness Connector Location

NKS003EV

A
B
C
D
E
F
G
H
I
J
ACS
L
M



SKIB8561E

WIRING DIAGRAM


[ICC]

WIRING DIAGRAM

PF0:0000

Schematic

NKS003EW



* : This relay is built into the IPDM E/R (Intelligent power distribution module engine room).

TKWM4441E

WIRING DIAGRAM




[ICC]

Wiring Diagram — ICC —

NKS003EX

ACS-ICC-01

▬ : DATA LINE



REFER TO THE FOLLOWING.

- (E211) -SUPER MULTIPLE JUNCTION (SMJ)
- (M1), (E201) -FUSE BLOCK-JUNCTION BOX (J/B)



A
B
C
D
E
F
G
H
I
J
L
M

ACS

WIRING DIAGRAM

[ICC]

ACS-ICC-02



REFER TO THE FOLLOWING.


- (E21) -SUPER MULTIPLE JUNCTION (SMJ)
- (E201) -FUSE BLOCK-JUNCTION BOX (J/B)
- (M90) -ELECTRICAL UNITS

TKWM4443E

WIRING DIAGRAM



[ICC]

ACS-ICC-03




A
B
C
D
E
F
G
H
I
J
K
L
M

ACS



REFER TO THE FOLLOWING.
 (F102) -SUPER MULTIPLE JUNCTION (SMJ)
 (M90) -ELECTRICAL UNITS





*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

TKWM4444E


WIRING DIAGRAM

[ICC]


ACS-ICC-04



(M5)
W



(M89)
GY



(E57)
GY



(E207)
W


REFER TO THE FOLLOWING.
(E21) -SUPER MULTIPLE
JUNCTION (SMJ)

TKWM4445E





WIRING DIAGRAM

[ICC]

ACS-ICC-05



A
B
C
D
E
F
G
H
I
J
ACS
L
M



REFER TO THE FOLLOWING.
 (E211) -SUPER MULTIPLE JUNCTION (SMJ)




TKWM4446E

WIRING DIAGRAM

[ICC]

ACS-ICC-06

— : DATA LINE



REFER TO THE FOLLOWING.


- (M1) - FUSE BLOCK-JUNCTION BOX (J/B)
- (M3) - ELECTRICAL UNITS

TKWM4447E

WIRING DIAGRAM


[ICC]

ACS-ICC-07



A
B
C
D
E
F
G
H
I
J
K
L
M

ACS



REFER TO THE FOLLOWING.
E56 - ELECTRICAL UNITS

TKWM4448E

TERMINALS AND REFERENCE VALUE


[ICC]

TERMINALS AND REFERENCE VALUE

PFP:00000

Terminals and Reference Value for ICC Unit

NKS003EY

Terminals (Wire color)		Item	Condition		Voltage (V)	
+	-		Ignition switch	Operation		
1 (R/W) 2 (R/W)	Ground	Battery power supply	OFF	—	Battery voltage	
5 (P)		CAN-L	—	—	—	
6 (GY/L)		Release switch power supply	ON	—	Approx. 10	
7 (GY/R)		NEUT-SW	ON	Selector lever in "N" or "P" positions	Approx. 12	
				Selector lever in other positions	Approx. 0	
8 (G)	24 (R)	Brake pressure sensor power supply	ON	—	Approx. 5	
10 (B/R)	Ground	Brake booster solenoid (+) side	ON	—	Approx. 12	
12 (L/W)		Brake booster solenoid (-) side	ON	Solenoid operating		
				Solenoid not operating	Approx. 12	
14 (L)		CAN-H	—	—	—	
15 (LG/B)	Brake release switch (normal closed)	ON	Depress the brake pedal	Approx. 0		
			Release the brake pedal	Approx. 10		
17 (BR)	24 (R)	Brake pressure sensor signal	ON	Release the brake pedal	Approx. 0.5	
			Depress the brake pedal	Approx. 0.5 - 3 (Note) Voltage becomes higher depending on effectiveness of depressing brakes.		
19 (B) 20 (B) 46 (B)	Ground	ON	—	Approx. 0		
22 (G/Y)	Brake release switch (normally open)	ON	Depress the brake pedal	Approx. 10		
			Release the brake pedal	Approx. 0		
29 (SB)	Ground	ICC brake switch (normal closed)	ON	Selector lever: Not in "N" or "P" position	Depress the brake pedal	Approx. 0
				Release the brake pedal	Approx. 12	
30 (Y)	DDL-TX	—	—	—		
33 (W) 42 (W)	Ignition switch ON or START	ON	—	Battery voltage		
38 (P/B)	Stop lamp switch (normally open)	ON	Depress the brake pedal	Approx. 12		
			Release the brake pedal	Approx. 0		
39 (G/OR)	DDL-RX	—	—	—		

TERMINALS AND REFERENCE VALUE

[ICC]

Terminals (Wire color)		Item	Condition		Voltage (V)
+	-		Ignition switch	Operation	
40 (PU/W)	Ground	Parking brake signal	ON	Depress the parking brake	Approx. 0
				Release the parking brake	Approx. 12
47 (W/R)		Stop lamp drive output signal	ON	Brake operating with ICC system	Approx. 12
				Brake not operating with ICC system	Approx. 0

A
B
C
D

Terminals and Reference Value for ICC Sensor

NKS003EZ

Terminals (Wire color)		Item	Condition		Voltage (V)
+	-		Ignition switch	Operation	
1 (Y)	Ground	ICC sensor power	ON	—	Battery voltage
3 (L)		CAN-H	—	—	—
4 (B)		Ground	—	—	Approx. 0
6 (R)		CAN-L	—	—	—

E
F
G

H

I

J

ACS

L


M

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

PFP:00004

Work Flow

NKS003F0



SKIA1227E

- Reference 1... Refer to [ACS-37, "Self-Diagnostic Function"](#) .
- Reference 2... Refer to [ACS-42, "Diagnostic Trouble Code \(DTC\) Chart"](#) .
- Reference 3... Refer to [ACS-67, "Symptom Chart"](#) .
- Reference 4... Refer to [GI-39, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#) / [ACS-39, "SELF-DIAGNOSIS BY ICC SYSTEM DISPLAY WILL NOT RUN"](#) .

CONSULT-II Function (ICC) DESCRIPTION

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.

Test mode	Function	Reference page
WORK SUPPORT	<ul style="list-style-type: none"> ● Monitors aiming direction to facilitate laser beam aiming operation. ● Indicates causes of automatic cancellation of the ICC system. 	ACS-32
SELF-DIAGNOSTIC RESULTS	Displays malfunctioning system memorized in ICC unit.	ACS-32
DATA MONITOR	Displays real-time input/output data of ICC unit.	ACS-33
CAN DIAG SUPPORT MNTR	The results of transmit/receive diagnosis of CAN communication can be read.	LAN-16
ACTIVE TEST	Enables operation check of electrical loads by sending driving signal to them.	ACS-35
ECU PART NUMBER	Displays part number of ICC unit.	—

CONSULT-II BASIC OPERATION

Refer to [GI-38, "CONSULT-II Start Procedure"](#) .

A
B
C
D
E
F
G
H
I
J
L
M

WORK SUPPORT

Work Item


Operation	Function
CAUSE OF AUTO-CANCEL	Indicates causes of automatic cancellation of the ICC system.
LASER BEAM ADJUST	Outputs laser beam, calculates dislocation of the beam, and indicates adjustment direction.

Cause of Auto-Cancel

1. Touch "WORK SUPPORT" on the "SELECT DIAG MODE" screen. Refer to [GI-38, "CONSULT-II Start Procedure"](#).
2. Touch "CAUSE OF AUTO-CANCEL" on the "SELECT WORK ITEM" screen.
3. Cause of automatic cancellation screen will be shown.

CAUTION:

Last five cancel (system cancel) causes are displayed.



Display Item List

Cause of cancellation	Description
OPERATING WIPER	Windshield wipers were operated at HI or LO speed operation.
OPERATING ABS	ABS function was operated.
OPERATING TCS	TCS function was operated.
OPERATING VDC	VDC function was operated.
OPE SW VOLT CIRC	Outside the standard control switch input voltage was detected.
ECM CIRCUIT	ECM did not permit ICC operation.
LASER SUN BEAM	Intense light such as sunlight entered ICC sensor light sensing part.
LASER TEMP	Temperature around ICC sensor became low.
OP SW DOUBLE TOUCH	ICC steering switches were pressed at the same time.
WHL SPD ELEC NOISE	Wheel speed sensor signal caught electromagnetic noise.
VDC/TCS OFF SW	VDC OFF switch was pressed.
WHEEL SPD UNMATCH	Wheel speed became different from AT vehicle speed.
TIRE SLIP	Wheel slipped.
PKB SW ON	Parking brake is applied.
IGN LOW VOLT	Power supply voltage became low.
SNOW MODE SW	Snow mode switch was pressed.
NO RECORD	—

Laser Beam Adjust

For details, refer to [ACS-14, "LASER BEAM AIMING ADJUSTMENT"](#).


SELF-DIAGNOSTIC RESULTS

For details, refer to [ACS-42, "Diagnostic Trouble Code \(DTC\) Chart"](#).

DATA MONITOR

Operation Procedure

1. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen. Refer to [GI-38, "CONSULT-II Start Procedure"](#).
2. Touch any of "ECU INPUT SIGNALS", "MAIN SIGNALS" and "SELECTION FROM MENU" on selection screen.
3. Touch "START".
4. Display the data monitor.
5. If necessary, touch "COPY" in turn, and print data.



Monitored Item

×: Applicable

Monitored Item [unit]	ECU INPUT SIGNALS	MAIN SIGNALS	SELEC- TION FROM MENU	Description
VHCL SPEED SE [km/h] or [mph]	×	×	×	Indicates vehicle speed calculated from ICC unit through CAN communication [ABS actuator and electric unit (control unit) transmits wheel speed sensor signal through CAN communication].
SET VHCL SPD [km/h] or [mph]		×	×	Indicates set vehicle speed memorized in ICC unit.
THRTL OPENING [%]	×	×	×	Indicates throttle angle read from ICC unit through CAN communication (ECM transmits throttle angle through CAN communication).
ENGINE RPM [rpm]	×		×	Indicates engine speed read from ICC unit through CAN communication (ECM transmits engine speed through CAN communication).
DISTANCE ADJ [SHOR/MID/LONG]	×	×	×	Indicates set distance memorized in ICC unit.
WIPER SW [OFF/LOW/HIGH]	×		×	Indicates wiper [OFF/LOW/HIGH] status (BCM transmits front wiper request signal through CAN communication).
MAIN SW [ON/OFF]	×	×	×	Indicates [ON/OFF] status as judged from ICC steering switch signal (ECM transmits ICC steering switch signal through CAN communication).
SET/COAST SW [ON/OFF]	×	×	×	Indicates [ON/OFF] status as judged from ICC steering switch signal (ECM transmits ICC steering switch signal through CAN communication).
CANCEL SW [ON/OFF]	×	×	×	Indicates [ON/OFF] status as judged from ICC steering switch signal (ECM transmits ICC steering switch signal through CAN communication).
RESUME/ACC SW [ON/OFF]	×	×	×	Indicates [ON/OFF] status as judged from ICC steering switch signal (ECM transmits ICC steering switch signal through CAN communication).
CRUISE OPE [ON/OFF]		×	×	Indicates whether controlling or not (ON means "controlling").
BRAKE SW [ON/OFF]	×	×	×	Indicates [ON/OFF] status as judged from ICC brake switch signal.
STOP LAMP SW [ON/OFF]	×	×	×	Indicates [ON/OFF] status as judged from stop lamp switch signal.
RELEASE SW NO [ON/OFF]	×		×	Indicates [ON/OFF] status as judged from release switch signal. ON when brake is depressed. OFF when brake is not depressed.

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION


[ICC]

Monitored Item [unit]	ECU INPUT SIGNALS	MAIN SIGNALS	SELEC- TION FROM MENU	Description
RELEASE SW NC [ON/OFF]	×		×	Indicates [ON/OFF] status as judged from release switch signal. ON when brake is not depressed. OFF when brake is depressed.
IDLE SW [ON/OFF]	×		×	Indicates [ON/OFF] status of idle switch read from ICC unit through CAN communication (ECM transmits ON/OFF status through CAN communication).
GEAR [1, 2, 3, 4, 5]	×		×	Indicates AT gear position read from ICC unit through CAN com- munication (TCM transmits gear position through CAN commu- nication).
BUZZER O/P [ON/OFF]			×	Indicates [ON/OFF] status of ICC warning chime output.
ICC WARNING			×	NOTE: This item is displayed, but cannot monitor.
VHCL SPD AT [km/h] or [mph]			×	Indicates vehicle speed calculated from AT vehicle speed sen- sor read from ICC unit through CAN communication (TCM transmits AT vehicle speed sensor signal through CAN commu- nication).
PRESS SENS [bar]	×	×	×	Indicates brake fluid pressure value calculated from signal volt- age of pressure sensor.
PRESS SENS 2	×		×	NOTE: This item is displayed, but cannot monitor.
D RANGE SW [ON/OFF]	×		×	Indicates [ON/OFF] status of "D" position read from ICC unit through CAN communication (TCM transmits ON/OFF condition of "D" position through CAN communication).
A/T OD OFF [ON/OFF]			×	Indicates [ON/OFF] status of OD cancel output under control.
NP RANGE SW [ON/OFF]	×		×	Indicates PNP switch signal read from ICC unit through CAN communication (TCM transmits PNP switch signal through CAN communication).
DISTANCE			×	NOTE: This item is displayed, but cannot monitor.
RELATIVE SPD			×	NOTE: This item is displayed, but cannot monitor.
STP LMP DRIVE [ON/OFF]		×	×	Indicates [ON/OFF] status of brake hold relay drive output.
TURN SIGNAL	×		×	NOTE: This item is displayed, but cannot monitor.

ACTIVE TEST

CAUTION:


- Never perform the active test while driving.
 - Active test cannot be started while ICC system warning indicator illuminates.
1. Touch “ACTIVE TEST” on “SELECT DIAG MODE” screen. Refer to [GI-38, "CONSULT-II Start Procedure"](#)
 2. Touch any of “ICC BUZZER 1”, “METER LAMP”, “STOP LAMP” and “BOOSTER SOL/V 3” on selection screen.
 3. Touch necessary item and “START”.
 4. Active test screen will be shown.



ICC BUZZER 1

- Touch “ON” and “OFF” to check that ICC warning chime operates as in the following chart.


BUZZER O/P	ON	OFF
Buzzer sound	Beep	Not activated



METER LAMP

- Start engine.
- Touch “ON” and “OFF” to check that ICC system display operates as in the following chart.


METER LAMP	ON	OFF
ICC system display	Full illumination	OFF



STOP LAMP

- Touch “ON” and “OFF” to check that stop lamp operates as in the following chart.

STP LMP DRIVE	ON	OFF
Stop lamp	Lamp ON	Lamp OFF




A
B
C
D
E
F
G
H
I
J
ACS
L
M

BOOSTER SOL/V 3

- Start engine.
- Touch any of “MODE 1”, “MODE 2”, “MODE 3” to check that following operation condition is caused by operating monitor and brake pedal.
- “START” is displayed 10 seconds after operation start. (Active test is completed.)

ACTIVE TEST	
BOOSTER SOL/V 3	OFF
MONITOR	
PRESS SENS	0bar
PRESS SENS 2	0bar
MODE 2	MODE 3
TEST START	

SKIA1233E



Self-Diagnostic Function WITH CONSULT-II

1. Go to operation check after asking the customer for symptom information. Refer to [ACS-11, "ACTION TEST"](#) .
2. Stop vehicle, turn ignition switch OFF, then connect CONSULT-II and CONSULT-II CONVERTER to data link connector.
3. With engine started, touch "START (NISSAN BASED VHCL)", "ICC", "SELF-DIAG RESULTS" on CONSULT-II screen in this order.

CAUTION:

If "ICC" cannot be shown after several attempts, the ICC unit may have had malfunction. Repair or replace it. Refer to [GI-39, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#) .

4. Self-diagnostic result appears on screen. If "NO DTC ..." is shown, check ICC warning lamp. If any malfunction is indicated, GO TO step 5.
5. According to [ACS-42, "Diagnostic Trouble Code \(DTC\) Chart"](#) , perform appropriate check, and repair or replace malfunctioning part as necessary.
6. Turn ignition switch OFF.
7. Start the engine and touch "START (NISSAN BASED VHCL)", "ICC", "SELF-DIAG RESULTS", and "ERASE" on CONSULT-II display in turn to erase the memory.

CAUTION:

If the memory does not erase, go to 5.


8. Perform ICC system running test (drive vehicle with ICC system ON), and make sure that ICC warning lamp does not illuminate.

WITHOUT CONSULT-II

1. Go to operation check after asking the customer for symptom information. Refer to [ACS-11, "ACTION TEST"](#) .
2. Stop the vehicle to start the self-diagnosis.
3. Turn ignition switch OFF.
4. From 5 seconds through 15 seconds after turning ignition switch ON, press RESUME/ACCELERATE switch 5 times, and SET/COAST switch 5 times.

CAUTION:


- Never start engine.
- Never turn the MAIN switch ON.
- When operation above is not completed from 5 seconds through 15 seconds, start again from above go to 3.
- If self-diagnosis mode cannot be started after several attempts, the ICC unit may have had malfunction. Repair or replace it. Refer to [ACS-39, "SELF-DIAGNOSIS BY ICC SYSTEM DISPLAY WILL NOT RUN"](#) .



A
B
C
D
E
F
G
H
I
J
L
M

ACS

5. When self-diagnosis mode is started, DTC are shown on set vehicle speed indicator.



CAUTION:

- DTC will disappear after 5 minutes.
- When more than one malfunction is detected, a maximum of 3 code numbers can be stored; the latest malfunction will be displayed first.

6. Check [ACS-42, "Diagnostic Trouble Code \(DTC\) Chart"](#) , and repair or replace if necessary.
7. After repair, erase DTC stored in the ICC unit.
8. DTC 55 will be shown.
9. Turn ignition switch OFF to exit the diagnosis.
10. Perform ICC system running test (drive vehicle with ICC system ON), and make sure that ICC warning lamp (Orange) does not illuminate.

Self-Diagnostic Erasing Method

1. Stop the vehicle and turn the ignition switch OFF.
2. Turn ignition switch ON and start self-diagnosis.
3. During self-diagnosis mode, press CANCEL switch 5 times, and DISTANCE switch 5 times in this order.

CAUTION:

- Press them within 10 seconds after pressing CANCEL switch at first.
- When operation is not completed within 10 seconds, start again from step 2 above.


4. DTC 55 will be shown.

CAUTION:

DTC of an existing malfunction will not be erased.

5. Turn ignition switch OFF to exit the diagnosis.
6. Perform ICC system running test (drive vehicle with ICC system ON), and make sure that ICC system warning lamp (Orange) does not illuminate.

SELF-DIAGNOSIS BY ICC SYSTEM DISPLAY WILL NOT RUN



Possible Irregular Condition

Open or short lines	Symptoms	Malfunction causes
ICC unit power supply malfunction	No voltage supply from ignition switch	Fuse blown
		Harness open
	Ground cable not connected	Harness open
		Harness shorted
ICC steering switch malfunction	No signal transmitted	Harness open
		Harness shorted
		Spiral cable open
		Spiral cable shorted
		Switch or ECM malfunction
CAN communication system malfunction	Signal not transmitted	Harness open
		Harness shorted
		CAN communication outside the standard.
Combination meter system malfunction	Indication not possible	Indicator display malfunction
		ICC system display segments disappear.
ICC unit malfunction		ICC unit internal malfunction.

1. CHECK FUSES

Check that any of the fuses is blown.

Unit	Power source	Fuse No.
ICC unit	Ignition switch (ON)	12
	Battery	35

OK or NG

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.

2. CHECK ICC SYSTEM DISPLAY

1. Turn ignition switch ON.
2. Check if all displays illuminate.

Do all displays illuminate?


YES >> GO TO 3.

NO >> GO TO 6.

3. CHECK HARNESS BETWEEN ECM AND ICC STEERING SWITCH

1. Turn ignition switch OFF.
2. Disconnect ECM connector, and check terminals for bend and looseness.
3. Check continuity between ECM harness connector terminals.

ECM connector	Terminal		Condition	Resistance (Approx.)
M90	82	99	When MAIN switch pressed	0 Ω
			When MAIN switch released	5.5 kΩ




4. Check continuity between ECM harness connector and ground.

ECM connector	Terminal	Ground	Continuity
M90	82		
	99		

OK or NG

- OK >> GO TO 5.
 NG >> GO TO 4.



4. CHECK ICC STEERING SWITCH

Check ICC steering switch. Refer to [ACS-73, "ICC Steering Switch"](#).

OK or NG

- OK >> 1. Repair or replace harness between ECM and ICC steering switch.
 2. Perform self-diagnosis mode for ICC system.
- NG >> 1. Replace ICC steering switch.
 2. Perform self-diagnosis mode for ICC system.

5. CHECK SELF-DIAGNOSIS

1. Connect ECM connector.
2. Turn ignition switch ON.
3. Perform self-diagnosis mode for ICC system.

OK or NG

- OK >> INSPECTION END
 NG >> GO TO 6.

6. CHECK CONNECTOR FOR ICC UNIT

1. Turn ignition switch OFF.
2. Disconnect ICC unit connector, and check terminals for bend and looseness.
3. Connect ICC unit connector.
4. Turn ignition switch ON.
5. Check if all displays illuminate.

Do all displays illuminate?

- YES >> Perform self-diagnosis again.
 NO >> GO TO 7.


7. CHECK POWER SUPPLY CIRCUIT FOR ICC UNIT

Check voltage between ICC unit harness connector terminals.

ICC unit connector	Terminal		Voltage (Approx.)
	(+)	(-)	
M89	33	Ground	Battery voltage
	42		

OK or NG

- OK >> GO TO 8.
- NG >> Repair ICC unit power supply harness.




8. CHECK GROUND CIRCUIT FOR ICC UNIT

1. Turn ignition switch OFF.
2. Disconnect ICC unit connector.
3. Check continuity between ICC unit harness connector and ground.

ICC unit connector	Terminal	Ground	Continuity
M88	19		Ground
	20		
M89	46	Ground	Yes

OK or NG

- OK >> GO TO 9.
- NG >> Repair ICC unit ground harness.



9. CHECK DISPLAYS

1. Connect ICC unit connector.
2. Turn ignition switch ON.
3. Check if all displays illuminate.

Do all displays illuminate?

- YES >> Perform self-diagnosis again.
- NO >> GO TO 10.

10. CHECK CAN COMMUNICATION

Perform self-diagnosis with CONSULT-II, and check CAN communication system for malfunction.

OK or NG

- OK >> Replace combination meter.
- NG >> CAN communication inspection. Refer to [ACS-44, "DTC 20 CAN COMM CIRCUIT"](#).

A
B
C
D
E
F
G
H
I
J
L
M

ACS

TROUBLE DIAGNOSIS FOR SELF-DIAGNOSTIC ITEMS

[ICC]

TROUBLE DIAGNOSIS FOR SELF-DIAGNOSTIC ITEMS

PFP:00000

Diagnostic Trouble Code (DTC) Chart

NKS003F3

x: Applicable

DTC No.	CONSULT-II screen terms	ICC system warning lamp	Fail-safe			Malfunctions detected where...	Reference page
			Vehicle-to-vehicle distance control mode	Conventional (fixed speed) cruise control mode	Brake assist (with preview function)		
11	CONTROL UNIT	x	x	x	x	● ICC unit internal malfunction	ACS-44
20	CAN COMM CIRCUIT	x	x	x	x	● ICC unit detected CAN communication malfunction.	ACS-44
31	POWER SUPPLY CIR	x	x	x	x	● ICC unit power supply voltage is excessively low (less than 8 V).	ACS-44
34	POWER SUPPLY CIR2	x	x	x	x	● ICC unit power supply voltage is excessively high (more than 19 V).	ACS-44
41	VHCL SPEED SE CIRC	x	x	x	x	<ul style="list-style-type: none"> ● Wheel sensor malfunction. ● ABS actuator and electric unit (control unit) malfunction ● AT vehicle speed sensor malfunction ● TCM malfunction 	ACS-45
43	ABS/TCS/VDC CIRC	x	x	x	x	● VDC/TCS/ABS system malfunction	ACS-46
45	BRAKE SW/STOP L SW	x	x	x	x	<ul style="list-style-type: none"> ● Brake and stop lamp switch harness is open or shorted. ● Brake and stop lamp switch is ON or stuck to OFF. ● Brake and stop lamp switch is stuck to ON. 	ACS-46
46	OPERATION SW CIRC	x	x	x		<ul style="list-style-type: none"> ● ICC steering switch harness or spiral cable is open or shorted. ● ICC steering switch malfunction 	ACS-48
61	PRESS SEN CIRCUIT	x	x		x	<ul style="list-style-type: none"> ● Brake pressure sensor harness is open or shorted. ● Brake pressure sensor malfunction ● Brake pressure sensor input circuit malfunction 	ACS-50
62	BOOSTER SOL/V CIRCUIT	x	x		x	<ul style="list-style-type: none"> ● Solenoid harness is open or shorted. ● Solenoid is open. ● Solenoid drive circuit malfunction 	ACS-51
63	RELEASE SW CIRCUIT	x	x	x	x	<ul style="list-style-type: none"> ● Release switch harness is open or shorted. ● Release switch malfunction ● Release switch input circuit malfunction 	ACS-52
65	PRESSURE CONTROL	x	x		x	● Booster malfunction	ACS-54
74	LASER BEAM OFF CNTR	x	x		x	● Laser beam of ICC sensor is off the aiming point.	ACS-55

TROUBLE DIAGNOSIS FOR SELF-DIAGNOSTIC ITEMS

[ICC]

DTC No.	CONSULT-II screen terms	ICC system warning lamp	Fail-safe			Malfunctions detected where...	Reference page
			Vehicle-to-vehicle distance control mode	Conventional (fixed speed) cruise control mode	Brake assist (with preview function)		
90	STOP LAMP RLY FIX	×	×		×	<ul style="list-style-type: none"> ● Normally open terminal of stop lamp relay is stuck. 	ACS-55
92	ECM CIRCUIT	×	×	×	×	<ul style="list-style-type: none"> ● ECM malfunction ● Accelerator pedal position sensor malfunction ● ICC unit malfunction 	ACS-61
96	NP RANGE	×	×	×		<ul style="list-style-type: none"> ● Park/neutral position switch harness is open or shorted. ● Park/neutral position switch malfunction. ● TCM malfunction 	ACS-62
97	AT CIRCUIT	×	×	×		<ul style="list-style-type: none"> ● TCM malfunction 	ACS-64
98	GEAR POSITION	×	×	×		<ul style="list-style-type: none"> ● TCM malfunction ● AT turbine revolution sensor malfunction ● AT vehicle speed sensor malfunction 	ACS-64
102	RADAR STAIN	×	×		×	<ul style="list-style-type: none"> ● ICC sensor body window has contamination. 	ACS-65
103	LASER SENSOR FAIL	×	×		×	<ul style="list-style-type: none"> ● ICC sensor internal malfunction 	ACS-65
104	LASER AIMING INCOMP	×	×		×	<ul style="list-style-type: none"> ● Laser beam aiming of ICC sensor is not adjusted. 	ACS-66
107	LASER COMM FAIL	×	×		×	<ul style="list-style-type: none"> ● CAN data received by ICC sensor is strange (from ICC unit, combination meter or ECM). 	ACS-66
109	LASER HIGH TEMP	×	×		×	<ul style="list-style-type: none"> ● Temperature around ICC sensor is excessively high. 	ACS-66

A
B
C
D
E
F
G
H
I
J
ACS
L
M

DTC 11 CONTROL UNIT

NKS003F4

1. CHECK ICC UNIT SELF-DIAGNOSIS

1. Perform self-diagnosis.
2. Check if any item other than "DTC 11 CONTROL UNIT" is indicated on self-diagnosis display.

Is any indicated?

- YES >> 1. Repair or replace applicable item.
 2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.
- NO >> 1. Replace ICC unit.
 2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

DTC 20 CAN COMM CIRCUIT

NKS003F5

1. CHECK CAN COMMUNICATION

With CONSULT-II

1. Perform self-diagnosis.
2. Print self-diagnostic result.

>> After printing self-diagnostic result, go to "CAN system". Refer to [LAN-3, "Precautions When Using CONSULT-II"](#) .

DTC 31 POWER SUPPLY CIR, DTC 34 POWER SUPPLY CIR 2

NKS003F6

1. CHECK CONNECTOR ICC UNIT

1. Turn ignition switch OFF.
2. Disconnect ICC unit connector, and connect it securely again.
3. Erase DTC and perform ICC running test. Then perform self-diagnosis of ICC system again.

Is malfunction indicated?

- YES >> GO TO 2.
- NO >> Poor connector connection
1. Check connector. (Check connector housing for disconnected, loose, bent, and collapsed terminals. If any malfunction is detected, repair applicable part.)
 2. Erase DTC and perform ICC running test. Then perform self-diagnosis of ICC system again.


2. CHECK POWER SUPPLY CIRCUIT FOR ICC UNIT

1. Turn ignition switch ON.
2. Check voltage between ICC unit harness connector and ground.

ICC unit connector	Terminal		Voltage (Approx.)
	(+)	(-)	
M89	33	Ground	Battery voltage
	42		

OK or NG


- OK >> GO TO 3.
- NG >> 1. Repair ICC unit power supply harness.
 2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.



3. CHECK GROUND CIRCUIT FOR ICC UNIT

1. Turn ignition switch OFF.
2. Disconnect ICC unit connector.
3. Check continuity between ICC unit harness connector and ground.

ICC unit connector	Terminal	Ground	Continuity
M88	19		Ground
	20		
M89	46		



OK or NG

- OK** >> 1. Replace ICC unit.
 2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.
- NG** >> 1. Repair ICC unit ground harness.
 2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

DTC 41 VHCL SPEED SE CIRC

NKS003F7

1. CHECK ICC UNIT SELF-DIAGNOSIS

1. Perform self-diagnosis.
2. Check if "DTC 43 ABS/TCS/VDC CIRC" or "DTC 20 CAN COMM CIRCUIT" other than "DTC 41 VHCL SPEED SE CIRC" is indicated in self-diagnosis item in the display.

Is any indicated?

- YES** >> 1. Repair or replace applicable item.
 2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.
- NO** >> GO TO 2.

2. CHECK AT VEHICLE SPEED SENSOR

ACS

Ⓜ With CONSULT-II

With "DATA MONITOR", check "VHCL SPD AT" operates normally. Refer to [ACS-33, "DATA MONITOR"](#) .

OK or NG

- OK** >> 1. Replace ICC unit.
 2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.
- NG** >> 1. Perform "A/T" self-diagnosis.
 2. After repairing or replacing applicable item, erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

DTC 43 ABS/TCS/VDC CIRC

NKS003F8

1. CHECK ICC UNIT SELF-DIAGNOSIS**With CONSULT-II**

1. Perform self-diagnosis.
2. Check if "DTC 20 CAN COMM CIRCUIT" other than "DTC 43 ABS/TCS/VDC CIRC" is indicated in self-diagnosis item in the display.

Is it indicated?

- YES >> 1. Repair or replace applicable item.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.
- NO >> GO TO 2.

2. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS**With CONSULT-II**

1. Perform self-diagnosis of ABS actuator and electric unit (control unit). Refer to [BRC-11, "TROUBLE DIAGNOSIS"](#).
2. Check if malfunction is indicated.

Is malfunction indicated?

- YES >> 1. Repair or replace applicable item.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.
- NO >> 1. Replace ICC unit.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

DTC 45 BRAKE SW/STOP L SW

NKS003F9

1. CHECK CONNECTOR FOR ICC UNIT

1. Turn ignition switch OFF.
2. Disconnect ICC unit connector, and connect it securely again.
3. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

Is malfunction indicated?

- YES >> GO TO 2.
- NO >> Poor connector connection
1. Check connector. (Check connector housing for disconnected, loose, bent, and collapsed terminals. If any malfunction is detected, repair applicable part.)
 2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

2. CHECK STOP LAMP SWITCH AND ICC BRAKE SWITCH**With CONSULT-II**

With "DATA MONITOR", check if "STOP LAMP SW" and "BRAKE SW" are operated normally. Refer to [ACS-33, "DATA MONITOR"](#).

OK or NG

- OK >> 1. Replace ICC unit.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.
- NG >> ● BRAKE SW: GO TO 3.
● STOP LAMP SW: GO TO 5.

3. CHECK BRAKE SWITCH INSTALLATION AND ADJUSTMENT

Check brake switch for proper installation, and adjust the switch if necessary. Refer to [BR-6, "BRAKE PEDAL"](#)

OK or NG

- OK >> GO TO 4.
- NG >> After adjustment, erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

4. CHECK ICC BRAKE SWITCH

Check ICC brake switch. Refer to [ACS-74, "ICC Brake Switch and Stop Lamp Switch"](#) .

OK or NG

- OK >> 1. Replace ICC unit.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.
- NG >> 1. Replace ICC brake switch.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

5. CHECK STOP LAMP ILLUMINATION

Check stop lamp illumination.

OK or NG

- OK >> GO TO 6.
- NG >> 1. Check stop lamp circuit.
2. After repairing, erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

6. CHECK ICC BRAKE HOLD RELAY

1. Turn ignition switch OFF.
2. Remove ICC brake hold relay.
3. Check ICC brake hold relay. Refer to [ACS-74, "ICC Brake Hold Relay"](#)

OK or NG

- OK >> GO TO 7.
- NG >> 1. Replace brake hold relay.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

A
B
C
D
E
F
G
H
I
J
L
M


ACS

7. CHECK ICC BRAKE HOLD RELAY CIRCUIT

1. Disconnect ICC unit connector and stop lamp switch connector.
2. Check continuity between ICC unit harness connector and ICC brake hold relay harness connector.

ICC unit connector	Terminal	ICC brake hold relay connector	Terminal	Continuity
M89	38	E14	7	Yes

ICC unit connector	Terminal	Ground	Continuity
M89	38		No




OK or NG

- OK >> GO TO 8.
- NG >> 1. Repair harness between ICC unit and ICC brake hold relay.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

8. CHECK STOP LAMP SWITCH CIRCUIT

Check continuity between ICC unit harness connector and stop lamp switch harness connector.

ICC unit connector	Terminal	Stop lamp switch connector	Terminal	Continuity
M89	38	E210	2	Yes



OK or NG

- OK >> 1. Replace ICC unit.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.
- NG >> 1. Repair harness between ICC unit and stop lamp switch.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

DTC 46 OPERATION SW CIRC

NKS003FA

1. CHECK CONNECTOR FOR ECM

1. Turn ignition switch OFF.
2. Disconnect ECM connector, and connect it securely again.
3. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

Is malfunction indicated?

- YES >> GO TO 2.
- NO >> Poor connector connection
 1. Check connector. (Check connector housing for disconnected, loose, bent, and collapsed terminals. If any malfunction is detected, repair applicable part.)
 2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

2. CHECK ICC STEERING SWITCH

Check ICC steering switch. Refer to [ACS-73, "ICC Steering Switch"](#).

OK or NG

OK >> GO TO 3.


NG >> 1. Replace ICC steering switch.

2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

3. CHECK ICC STEERING SWITCH SIGNAL CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect ECM connector and spiral cable connector.
3. Check continuity between spiral cable harness connector and ECM harness connector.

Spiral cable connector	Terminal	ECM connector	Terminal	Continuity
M15	33	M90	82	Yes
	34		99	



4. Check continuity between spiral cable harness connector and ground.

Spiral cable connector	Terminal	Ground	Continuity
M15	33	Ground	No
	34		



OK or NG

OK >> GO TO 4.

NG >> 1. Repair harness between ECM and spiral cable.

2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

4. CHECK SPIRAL CABLE

Check continuity between spiral cable connector terminals.

Spiral cable connector	Terminal	Spiral cable connector	Terminal	Continuity
M15	33	M203	14	Yes
	34		15	


OK or NG

OK >> 1. Perform ECM self-diagnosis.

2. After repairing or replacing applicable item, erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

NG >> 1. Replace spiral cable.

2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.



DTC 61 PRESS SEN CIRCUIT

1. CHECK CONNECTOR BRAKE PRESSURE SENSOR AND ICC UNIT

1. Turn ignition switch OFF.
2. Disconnect brake pressure sensor connector and ICC unit connector, and connect them securely again.
3. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

Is malfunction indicated?

YES >> GO TO 2.


NO >> Poor connector connection

1. Check connector. (Check connector housing for disconnected, loose, bent, and collapsed terminals. If any malfunction is detected, repair applicable part.)
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

2. CHECK HARNESS BETWEEN BRAKE PRESSURE SENSOR AND ICC UNIT


1. Turn ignition switch OFF.
2. Disconnect ICC unit connector and brake pressure sensor connector.
3. Check continuity between brake pressure sensor harness connector and ICC unit harness connector.

Brake pressure sensor connector	Terminal	ICC unit connector	Terminal	Continuity
E142	1	M88	24	Yes
	2		17	
	3		8	



4. Check continuity between ICC unit harness connector and ground.

ICC unit connector	Terminal	Ground	Continuity
M88	8	Ground	No
	17		
	24		



OK or NG

OK >> GO TO 3.

NG >> 1. Repair harness between brake pressure sensor and ICC unit.

2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.


3. CHECK POWER SUPPLY CIRCUIT FOR BRAKE PRESSURE SENSOR

1. Connect ICC unit connector.
2. Turn ignition switch ON.
3. Check voltage between ICC unit harness connector terminals.

ICC unit connector	Terminal		Voltage (Approx.)
	(+)	(-)	
M88	8	24	5 V

OK or NG

- OK** >> 1. Replace brake pressure sensor. Refer to [BR-13](#), "[BRAKE MASTER CYLINDER](#)".
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.
- NG** >> 1. Replace ICC unit.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.



DTC 62 BOOSTER SOL/V CIRCUIT

NKS003FC

1. CHECK SOLENOID/RELEASE SWITCH AND ICC UNIT CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect brake booster connector and ICC unit connector, and connect them securely again.
3. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

Is malfunction indicated?

- YES** >> GO TO 2.
- NO** >> Poor connector connection
1. Check connector. (Check connector housing for disconnected, loose, bent, and collapsed terminals. If any malfunction is detected, repair applicable part.)
 2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.


A
B
C
D
E
F
G
H
I
J
L
M

ACS

2. CHECK HARNESS BETWEEN SOLENOID/RELEASE SWITCH AND ICC UNIT


1. Turn ignition switch OFF.
2. Disconnect ICC unit connector and brake booster connector.
3. Check continuity between ICC unit harness connector (A) and brake booster harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M88	10	E54	4	Yes
	12		6	



4. Check continuity between ICC unit harness connector and ground.

ICC unit connector	Terminal	Ground	Continuity
M88	10		
	12		



OK or NG

- OK >> GO TO 3.
 NG >> 1. Repair harness between brake booster and ICC unit.
 2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

3. CHECK BOOSTER SOLENOID

Check booster solenoid. Refer to [ACS-73, "Booster Solenoid"](#) .

OK or NG

- OK >> 1. Replace ICC unit.
 2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.
- NG >> Booster solenoid malfunction
 1. Replace brake booster.
 2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

DTC 63 RELEASE SW CIRCUIT

NKS003FD

1. CHECK SOLENOID/RELEASE SWITCH AND ICC UNIT CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect brake booster connector and ICC unit connector, and connect them securely again.
3. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.


Is malfunction indicated?

- YES >> GO TO 2.
 NO >> Poor connector connection
 1. Check connector. (Check connector housing for disconnected, loose, bent, and collapsed terminals. If any malfunction is detected, repair applicable part.)
 2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

2. CHECK HARNESS SOLENOID/RELEASE SWITCH AND ICC UNIT


1. Turn ignition switch OFF.
2. Disconnect ICC unit connector and brake booster connector.
3. Check continuity between ICC unit harness connector (A) and brake booster harness connector (B).

A		B		Continuity
ICC unit connector	Terminal	Brake booster connector	Terminal	
M88	6	E54	1	Yes
	15		3	
	22		2	



4. Check continuity between ICC unit harness connector and ground.

ICC unit connector	Terminal	Ground	Continuity
M88	6		No
	15		
	22		



OK or NG

OK >> GO TO 3.


NG >> 1. Repair harness between brake booster and ICC unit.

2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

3. CHECK RELEASE SWITCH POWER SUPPLY CIRCUIT

1. Connect ICC unit connector.
2. Turn ignition switch ON.
3. Check voltage between ICC unit harness connector and ground.

ICC unit connector	Terminal		Voltage (Approx.)
	(+)	(-)	
M88	6	Ground	10 V



OK or NG

OK >> GO TO 4.

NG >> 1. Replace ICC unit.

2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

4. CHECK RELEASE SWITCH

1. Turn ignition switch OFF.
2. Check release switch. Refer to [ACS-73, "Release Switch"](#) .

OK or NG

- OK >> 1. Replace ICC unit.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.
- NG >> Release switch malfunction
1. Replace brake booster.
 2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

DTC 65 PRESSURE CONTROL

NKS003FE

1. OPERATION CHECK

Check foot brake pedal operates normally.

OK or NG

- OK >> GO TO 2.
- NG >> 1. Check brake circuit.
2. After repairing, erase DTC and perform active test (BOOSTER SOL/V3) with CONSULT-II.
Then perform self-diagnosis of ICC system again.

2. CHECK BOOSTER SOLENOID

Check booster solenoid. Refer to [ACS-73, "Booster Solenoid"](#) .


OK or NG

- OK >> GO TO 3.
- NG >> Booster solenoid malfunction
1. Replace brake booster.
 2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

3. CHECK HARNESS BETWEEN ICC UNIT AND BRAKE BOOSTER


1. Turn ignition switch OFF.
2. Disconnect ICC unit connector and brake booster connector.
3. Check continuity between ICC unit harness connector (A) and brake booster harness connector (B).

A		B		Continuity
ICC unit connector	Terminal	Brake booster connector	Terminal	
M88	10	E54	4	Yes
	12		6	



4. Check continuity between ICC unit harness connector and ground.

ICC unit connector	Terminal	Ground	Continuity
M88	10		
	12		



OK or NG

- OK** >> 1. Replace ICC unit.
 2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.
- NG** >> 1. Repair harness between brake booster and ICC unit.
 2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

DTC 74 LASER BEAM OFF CNTR

NKS003FF

1. DIAGNOSTIC CHECK

1. Adjust laser beam aiming. Then erase DTC, and perform ICC system running test.
2. Perform self-diagnosis of ICC system.
3. Check if "DTC 74 LASER BEAM OFF CNTR" is indicated.

Is it indicated?

- YES** >> 1. Replace ICC sensor, and adjust laser beam aiming.
 2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.
- NO** >> INSPECTION END

DTC 90 STOP LAMP RLY FIX

NKS003FG

1. CHECK CONNECTOR ICC UNIT

1. Turn ignition switch OFF.
2. Disconnect ICC unit connector, and connect it securely again.
3. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

Is malfunction indicated?

- YES** >> GO TO 2.
- NO** >> Poor connector connection
1. Check connector (Check connector housing for disconnected, loose, bent, and collapsed terminals. If any malfunction is detected, repair applicable part).
 2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

2. CHECK STOP LAMP SWITCH AND ICC BRAKE SWITCH

 **With CONSULT-II**

With "DATA MONITOR", check that "STOP LAMP SW" and "BRAKE SW" operate normally. Refer to [ACS-33, "DATA MONITOR"](#) .

OK or NG

- OK >> GO TO 12.
- NG >> ● BRAKE SW: GO TO 3.
● STOP LAMP SW: GO TO 9.

3. CHECK BRAKE SWITCH INSTALLATION AND ADJUSTMENT

Check brake switch for proper installation, and adjust the switch if necessary. Refer to [BR-6, "BRAKE PEDAL"](#) .

OK or NG

- OK >> GO TO 4.
- NG >> After adjustment, erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

4. CHECK ICC BRAKE SWITCH AND STOP LAMP SWITCH

Check ICC brake switch and stop lamp switch. Refer to [ACS-74, "ICC Brake Switch and Stop Lamp Switch"](#) .

OK or NG

- OK >> GO TO 5.
- NG >> 1. Replace ICC brake switch.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

5. CHECK ICC BRAKE HOLD RELAY

1. Turn ignition switch OFF.
2. Disconnect ICC brake hold relay.
3. Check ICC brake hold relay. Refer to [ACS-74, "ICC Brake Hold Relay"](#) .

OK or NG

- OK >> GO TO 6.
- NG >> 1. Replace ICC brake hold relay.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.


6. CHECK HARNESS BETWEEN ICC BRAKE HOLD RELAY AND ICC BRAKE SWITCH

1. Disconnect ICC brake switch connector and ICC unit connector.
2. Check continuity between ICC brake hold relay harness connector and ICC brake switch harness connector.

ICC brake hold relay connector	Terminal	ICC brake switch connector	Terminal	Continuity
E14	3	E209	2	Yes

3. Check continuity between ICC brake hold relay harness connector and ground.

ICC brake hold relay connector	Terminal	Ground	Continuity
E14	3		No



OK or NG

OK >> GO TO 7.

NG >> 1. Repair harness between ICC brake hold relay and ICC brake switch.

2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.


7. CHECK HARNESS BETWEEN ICC UNIT AND ICC BRAKE HOLD RELAY

1. Disconnect ECM connector.
2. Check continuity between ICC unit harness connector and ICC brake hold relay harness connector.

ICC unit connector	Terminal	ICC brake hold relay connector	Terminal	Continuity
M89	29	E14	4	Yes

3. Check continuity between ICC unit harness connector and ground.

ICC unit connector	Terminal	Ground	Continuity
M89	29		No



OK or NG

OK >> GO TO 8.

NG >> 1. Repair harness between ICC unit and ICC brake hold relay.

2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.


8. CHECK ICC BRAKE SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between ICC brake switch harness connector and ground.

ICC brake switch connector	Terminal		Voltage (Approx.)
	(+)	(-)	
E209	1	Ground	Battery voltage

OK or NG

- OK >> 1. Replace ICC unit.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.
- NG >> 1. Repair or replace harness or fuse.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.



9. CHECK STOP LAMP ILLUMINATION

1. Turn ignition switch OFF.
2. Disconnect ICC brake hold relay.
3. Check stop lamp circuit.

OK or NG

- OK >> GO TO 10.
- NG >> After repairing, erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

10. CHECK ICC BRAKE HOLD RELAY CIRCUIT

1. Connect ICC brake hold relay connector.
2. Disconnect stop lamp switch connector.
3. When brake pedal is not depressed, make sure that stop lamp does not illuminate.

OK or NG

- OK >> 1. Replace ICC unit.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.
- NG >> GO TO 11.

11. CHECK ICC BRAKE HOLD RELAY

1. Disconnect ICC brake hold relay.
2. Check ICC brake hold relay. Refer to [ACS-74, "ICC Brake Hold Relay"](#).

OK or NG

- OK >> 1. Replace ICC unit.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.
- NG >> 1. Replace ICC brake hold relay.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.


12. CHECK HARNESS BETWEEN ICC UNIT AND ICC BRAKE HOLD RELAY

1. Turn ignition switch OFF.
2. Disconnect ICC unit connector and ICC brake hold relay.
3. Check continuity between ICC unit harness connector and ICC brake hold relay harness connector.

ICC unit connector	Terminal	ICC brake hold relay connector	Terminal	Continuity
M89	47	E14	1	Yes

4. Check continuity between ICC unit harness connector and ground.

ICC unit connector	Terminal	Ground	Continuity
M89	47		No




OK or NG

- OK >> GO TO 13.
 NG >> 1. Repair harness between ICC unit and ICC brake hold relay.
 2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

13. CHECK ICC BRAKE HOLD RELAY GROUND CIRCUIT

Check continuity between ICC brake hold relay harness connector and ground.

ICC brake hold relay connector	Terminal	Ground	Continuity
E14	2		Yes



OK or NG

- OK >> GO TO 14.
 NG >> 1. Repair harness between ICC brake hold relay and ground.
 2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

14. CHECK ICC BRAKE HOLD RELAY

Check ICC brake hold relay. Refer to [ACS-74, "ICC Brake Hold Relay"](#).

OK or NG


- OK >> GO TO 15.
 NG >> 1. Replace ICC brake hold relay.
 2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

15. CHECK ICC UNIT STANDARD VOLTAGE

With CONSULT-II

1. Connect ICC unit connector and stop lamp switch connector.
2. Perform "ACTIVE TEST" ("STOP LAMP": "STP LMP DRIVE ON") with CONSULT-II, check voltage between ICC unit harness connector and ground.

ICC unit connector	Terminal		Condition	Voltage (Approx.)
	(+)	(-)		
M89	47	Ground	During "ACTIVE TEST"	12 V



OK or NG

OK >> GO TO 16.


NG >> 1. Replace ICC unit.

2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

16. CHECK ICC BRAKE HOLD RELAY POWER SUPPLY CIRCUIT

Check voltage between ICC brake hold relay harness connector and ground.

ICC brake hold relay connector	Terminal		Voltage (Approx.)
	(+)	(-)	
E14	6	Ground	Battery voltage



OK or NG

OK >> GO TO 17.

NG >> 1. Repair or replace harness or fuse.

2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.


17. CHECK HARNESS BETWEEN ICC UNIT AND ICC BRAKE HOLD RELAY

1. Turn ignition switch OFF.
2. Disconnect ICC unit.
3. Check continuity between ICC unit harness connector and ICC brake hold relay harness connector.

ICC unit connector	Terminal	ICC brake hold relay connector	Terminal	Continuity
M89	38	E14	7	Yes

4. Check continuity between ICC unit harness connector and ground.

ICC unit connector	Terminal	Ground	Continuity
M89	38		No



OK or NG

OK >> GO TO 18.

NG >> 1. Repair harness between ICC unit and ICC brake hold relay.

2. Erase DTC and perform ICC system running test. Then, perform self-diagnosis of ICC system again.

18. CHECK ICC BRAKE HOLD RELAY

With CONSULT-II

1. Connect ICC unit connector and ICC brake hold relay.
2. Disconnect stop lamp switch connector.
3. Perform "ACTIVE TEST" ("STOP LAMP") with CONSULT-II, and make sure that stop lamp is illuminated.

OK or NG


- OK >> GO TO 19.
- NG >> 1. Replace ICC brake hold relay.
 2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

19. CHECK ICC UNIT STANDARD VOLTAGE

With CONSULT-II

1. Connect stop lamp switch connector.
2. Perform "ACTIVE TEST" ("STOP LAMP": "STP LMP DRIVE ON") with CONSULT-II, check voltage between ICC unit harness connector and ground.

ICC unit connector	Terminal		Condition	Voltage (Approx.)
	(+)	(-)		
M89	29	Ground	During "ACTIVE TEST"	0 V



OK or NG

- OK >> 1. Replace ICC unit.
 2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.
- NG >> 1. Replace stop lamp switch.
 2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

DTC 92 ECM CIRCUIT

NKS003FH

ACS

1. CHECK ICC UNIT SELF-DIAGNOSIS

With CONSULT-II

1. Perform self-diagnosis with CONSULT-II.
2. Check if "DTC 20 CAN COMM CIRCUIT" other than "DTC 92 ECM CIRCUIT" is indicated in self-diagnosis item in the display.

Is it indicated?

- YES >> 1. Repair or replace applicable item.
 2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.
- NO >> GO TO 2.

2. CHECK ECM SELF-DIAGNOSIS

With CONSULT-II

1. Perform ECM self-diagnosis with CONSULT-II.
2. Check if malfunction is indicated.

Is malfunction indicated?

- YES >> 1. Repair or replace applicable item.
 2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.
- NO >> 1. Replace ICC unit.
 2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

DTC 96 NP RANGE

NKS003FI

1. CHECK CONNECTOR ICC UNIT

1. Turn ignition switch OFF.
2. Disconnect ICC unit connector, and connect them securely again.
3. Erase DTC and then perform ICC system running test. Then perform self-diagnosis of ICC system again.

Is malfunction indicated?

- YES >> GO TO 2.
- NO >> Poor connector connection
1. Check connector. (Check connector housing for disconnected, loose, bent, and collapsed terminals. If any malfunction is detected, repair applicable part.)
 2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

2. CHECK NP RANGE SWITCH SIGNAL

With CONSULT-II

With "DATA MONITOR", check that "NP RANGE SW" operates normally. Refer to [ACS-33, "DATA MONITOR"](#)

OK or NG

- OK >> GO TO 5.
 NG >> GO TO 3.


3. CHECK HARNESS BETWEEN ICC UNIT AND TCM

1. Turn ignition switch OFF.
2. Disconnect ICC unit connector and A/T assembly connector.
3. Check continuity between ICC unit harness connector and A/T assembly harness connector.

ICC unit connector	Terminal	A/T assembly connector	Terminal	Continuity
M88	7	F44	9	Yes

4. Check continuity between ICC unit harness connector and ground.

ICC unit connector	Terminal	Ground	Continuity
M88	7		No



OK or NG

- OK >> GO TO 4.
- NG >> 1. Repair harness between ICC unit and A/T assembly.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

4. CHECK TCM START SIGNAL CIRCUIT

Check TCM start signal. Refer to [AT-107, "DTC P0615 START SIGNAL CIRCUIT"](#).

OK or NG

- OK >> 1. Replace ICC unit.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.
- NG >> 1. Repair or replace damaged parts.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

5. CHECK SHIFT POSITION SIGNAL

Ⓟ With CONSULT-II

With TCM diagnosis, check that shift operates normally. Refer to [AT-112, "DTC P0705 PARK/NEUTRAL POSITION SWITCH"](#).

OK or NG

- OK >> 1. Replace ICC unit.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.
- NG >> 1. Perform TCM self-diagnosis.
2. After repairing or replacing applicable item, erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

A
B
C
D
E
F
G
H
I
J
L
M

ACS

DTC 97 AT CIRCUIT

NKS003FJ

1. CHECK AT CIRCUIT**④ With CONSULT-II**

With TCM diagnosis, check that shift operates normally. Refer to [AT-112, "DTC P0705 PARK/NEUTRAL POSITION SWITCH"](#).

OK or NG

- OK >> 1. Replace ICC unit.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.
- NG >> 1. Perform TCM self-diagnosis.
2. After repairing or replacing applicable item, erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

DTC 98 GEAR POSITION

NKS003FK

1. CHECK ICC UNIT SELF-DIAGNOSIS**④ With CONSULT-II**

1. Perform self-diagnosis.
2. Check if "DTC 43 ABS/TCS/VDC CIRC" or "DTC 41 VHCL SPEED SE CIRC" other than "DTC 98 GEAR POSITION" is indicated in self-diagnosis item in the display.

Is any indicated?

- YES >> 1. Repair or replace applicable item.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.
- NO >> GO TO 2.

2. CHECK VEHICLE SPEED SIGNAL**④ With CONSULT-II**

With "DATA MONITOR", check that "VHCL SPEED SE" is normal.

OK or NG

- OK >> GO TO 3.
- NG >> 1. Replace ICC unit.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

3. CHECK SHIFT GEAR POSITION

Check that gear positions are correct in A/T.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.

4. CHECK TCM GEAR POSITION SIGNAL**④ With CONSULT-II**

With TCM "DATA MONITOR" with CONSULT-II, check that gear positions are correct.

OK or NG

- OK >> 1. Replace ICC unit.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.
- NG >> 1. Perform TCM self-diagnosis.
2. After repairing or replacing applicable item, erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

5. CHECK TCM TURBINE ROTATION

With CONSULT-II

With TCM diagnosis, check that turbine rpm is normal. Refer to [AT-116, "DTC P0717 TURBINE REVOLUTION SENSOR"](#) .

OK or NG

- OK >> 1. Replace ICC unit.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.
- NG >> 1. Perform TCM self-diagnosis.
2. After repairing or replacing applicable item, erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

DTC 102 RADAR STAIN

NKS003FL

1. VISUAL INSPECTION 1

Check that there is no contamination and foreign material on ICC sensor body window.

OK or NG

- OK >> GO TO 2.
- NG >> 1. If any, remove them.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

2. VISUAL INSPECTION 2

Check ICC sensor body window for cracks.

OK or NG

- OK >> GO TO 3.
- NG >> 1. Replace ICC sensor, and adjust laser beam aiming.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

3. ASKING COMPLAINTS

1. Ask if there is any trace of contamination or foreign material on ICC sensor.
2. Ask if vehicle was driven in snow or ICC sensor was frosted.
3. Ask if ICC sensor was fogged temporarily. (Front window glass may have also tended to be fogged.)

Is there any symptom?

- YES >> Explain difference in displays between contamination detection result and current indication to customer, and tell them "This is not malfunction".
- NO >> 1. Replace ICC sensor, and adjust laser beam aiming.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

DTC 103 LASER SENSOR FAIL

NKS003FM

1. CHECK ICC UNIT SELF-DIAGNOSIS

1. Perform self-diagnosis.
2. Check if "DTC 11 CONTROL UNIT" or "DTC 20 CAN COMM CIRCUIT" item other than "DTC 103 LASER SENSOR FAIL" is indicated in self-diagnosis item in the display.

Is any indicated?

- YES >> Go to applicable item inspection. Refer to [ACS-44, "DTC 11 CONTROL UNIT"](#) , and [ACS-44, "DTC 20 CAN COMM CIRCUIT"](#) .
- NO >> 1. Replace ICC sensor, and adjust laser beam aiming.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

DTC 104 LASER AIMING INCOMP

NKS003FN

1. CHECK DIAGNOSIS

1. Adjust laser beam aiming. Erase DTC and perform ICC system running test.
2. After that, perform self-diagnosis of ICC system.
3. Check if “DTC 104 LASER AIMING INCOMP” is indicated.

Is it indicated?

- YES >> 1. Replace ICC sensor, and adjust laser beam aiming.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.
- NO >> INSPECTION END

DTC 107 LASER COMM FAIL

NKS003FO

1. CHECK ICC UNIT SELF-DIAGNOSIS

1. Perform self-diagnosis.
2. Check if “DTC 11 CONTROL UNIT” or “DTC 20 CAN COMM CIRCUIT” item other than “DTC 107 LASER COMM FAIL” is indicated in the self-diagnosis item in the display.

Is any indicated?

- YES >> Go to applicable item inspection. Refer to [ACS-44, "DTC 11 CONTROL UNIT"](#) , and [ACS-44, "DTC 20 CAN COMM CIRCUIT"](#) .
- NO >> 1. Replace ICC sensor, and adjust laser beam aiming.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

DTC 109 LASER HIGH TEMP

NKS003FP

1. CHECK SYMPTOM

Check if cooling system malfunctions.

Does it malfunction?

- YES >> 1. Repair cooling system.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.
- NO >> 1. Replace ICC sensor, and adjust laser beam aiming.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

TROUBLE DIAGNOSIS FOR SYMPTOMS

[ICC]

TROUBLE DIAGNOSIS FOR SYMPTOMS

PFP:00007

Symptom Chart

NKS003FQ

	Symptoms	Reference page
Operation	MAIN switch does not switch ON.	Symptom 1 ACS-68
	MAIN switch does not switch OFF.	Symptom 1 ACS-68
	Cruise does not function for setting (powering functions).	Symptom 2 ACS-68
	CANCEL switch does not function.	Symptom 3 ACS-69
	Resume does not function.	Symptom 3 ACS-69
	Set speed does not increase.	Symptom 3 ACS-69
	Set distance to the vehicle ahead cannot be changed.	Symptom 3 ACS-69
	ICC is not cancelled when the A/T selector lever is in other than "D" and "M" position.	Symptom 4 ACS-70
Display/Chime	ICC system display does not appear.	Check combination meter. Refer to DI-16 , "Trouble Diagnosis" .
	Chime does not function.	Symptom 5 ACS-70
Control	Driving force is hunting.	Symptom 6 ACS-71
Function to detect the vehicle ahead	System frequently cannot detect the vehicle ahead.	Symptom 7 ACS-71
	Distance to detect the vehicle ahead is short.	Symptom 7 ACS-71
	System misidentifies a vehicle even though there is no vehicle ahead.	<ul style="list-style-type: none"> ● Refer to ACS-14, "LASER BEAM AIMING ADJUSTMENT" . ● Refer to ACS-11, "ICC System Running Test" .
	System misidentifies a vehicle in the next lane.	<ul style="list-style-type: none"> ● Refer to ACS-14, "LASER BEAM AIMING ADJUSTMENT" . ● Refer to ACS-11, "ICC System Running Test" .
	System does not detect a vehicle at all.	Symptom 8 ACS-72

A
B
C
D
E
F
G
H
I
J
L
M

ACS

Symptom 1: MAIN Switch Does Not Turn ON^{*1} , MAIN Switch Does Not Turn OFF^{*2}

NKS003FR

NOTE:

- *1: The ICC system display in the combination meter does not illuminate.
- *2: The ICC system display in the combination meter remains powered.

1. CHECK MAIN SWITCH

Ⓟ With CONSULT-II

With "DATA MONITOR", check that MAIN switch operates normally.

OK or NG

- OK >> GO TO 2.
NG >> GO TO 3.

2. CHECK CONNECTOR ICC UNIT

1. Turn ignition switch OFF.
2. Disconnect ICC unit connector.
3. Check connector housing for disconnected, loose, bent, and collapsed terminals.

OK or NG

- OK >> GO TO 3.
NG >> Poor connector connection
1. Repair ICC unit connector.
 2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

3. CHECK ICC UNIT SELF-DIAGNOSIS

Ⓟ With CONSULT-II

1. Perform self-diagnosis with CONSULT-II.
2. Check if "DTC 20 CAN COMM CIRCUIT" is indicated.

Is it indicated?

- YES >> Refer to [ACS-44, "DTC 20 CAN COMM CIRCUIT"](#) .
NO >> Refer to [ACS-48, "DTC 46 OPERATION SW CIRC"](#) .

Symptom 2: ICC System Cannot Be Set (MAIN Switch Turns ON/OFF)

NKS003FS

The ICC cannot be set in the following cases.

- When the vehicle speed is not in range of approx. 40 km/h (25 MPH) to 144 km/h (90 MPH).
- When the A/T selector lever is in gears other than "D" and "M" position.
- While the brake is in operation.

1. CHECK CAUSE OF AUTOMATIC CANCELLATION

Ⓟ With CONSULT-II

With "CAUSE OF AUTO-CANCEL" in "WORK SUPPORT", check if any cause of cancellation exists.

OK or NG

- OK >> Cancel with appropriate cause, and go to specified diagnosis.
- "OPE SW VOLT CIRC": Refer to [ACS-48, "DTC 46 OPERATION SW CIRC"](#) .
 - "VHCL SPD UNMATCH": Refer to [ACS-45, "DTC 41 VHCL SPEED SE CIRC"](#) .
 - "IGN LOW VOLT": Refer to [ACS-44, "DTC 31 POWER SUPPLY CIR, DTC 34 POWER SUPPLY CIR 2"](#) .
- NG >> GO TO 2.

2. CHECK ICC UNIT SELF-DIAGNOSIS

④ With CONSULT-II

Perform CONSULT-II self-diagnosis to check for malfunctioning items.

OK or NG

OK >> GO TO 3.

NG >> 1. Repair or replace applicable item.

2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

3. CHECK SWITCHES AND VEHICLE SPEED SIGNAL

④ With CONSULT-II

With "DATA MONITOR", check that switches and vehicle speed signal operate normally. Refer to [ACS-33, "DATA MONITOR"](#).

- VHCL SPEED SE
- D RANGE SW
- BRAKE SW
- SET/COAST SW

OK or NG

OK >> 1. Replace ICC unit.

2. Erase DTC and Perform ICC system running test. Then perform self-diagnosis of ICC system again.

NG >> ● VHCL SPEED SE. Refer to [ACS-45, "DTC 41 VHCL SPEED SE CIRC"](#).

● D RANGE SW. Refer to [ACS-70, "Symptom 4: ICC System Is Not Cancelled When the A/T Selector Lever Is in Other Than "D" and "M" Position"](#).

● BRAKE SW. Refer to [ACS-46, "DTC 45 BRAKE SW/STOP L SW"](#).

● SET/COAST SW. Refer to [ACS-48, "DTC 46 OPERATION SW CIRC"](#).

Symptom 3: ICC System Cannot Be Operated by CANCEL Switch, RESUME/ACCELERATE Switch or DISTANCE Switch

NKS003FT

RESUME does not function in the following cases.

- When MAIN switch is turned off once.
- When the vehicle speed is less than 40 km/h (25 MPH).

1. CHECK SWITCHES

④ With CONSULT-II

With "DATA MONITOR", check that switches operate normally.

"RESUME/ACC SW", "CANCEL SW", "DISTANCE ADJ". Refer to [ACS-33, "DATA MONITOR"](#).

OK or NG

OK >> 1. Replace ICC unit.

2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

NG >> GO TO 2.

2. CHECK ICC UNIT SELF-DIAGNOSIS

④ With CONSULT-II

1. Perform self-diagnosis with CONSULT-II.

2. Check if "DTC 20 CAN COMM CIRCUIT" is indicated.

Is it indicated?

YES >> Refer to [ACS-44, "DTC 20 CAN COMM CIRCUIT"](#).

NO >> Refer to [ACS-48, "DTC 46 OPERATION SW CIRC"](#).

Symptom 4: ICC System Is Not Cancelled When the A/T Selector Lever Is in Other Than "D" and "M" Position

NKS003FU

1. CHECK D RANGE SWITCH

Ⓟ With CONSULT-II

With "DATA MONITOR", check that "D RANGE SW" operates normally. Refer to [ACS-33, "DATA MONITOR"](#).
OK or NG

- OK >> 1. Replace ICC unit.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.
- NG >> GO TO 2.

2. CHECK ICC UNIT SELF-DIAGNOSIS

Ⓟ With CONSULT-II

1. Perform self-diagnosis with CONSULT-II.
2. Check if "DTC 20 CAN COMM CIRCUIT" is indicated.

Is it indicated?

- YES >> Refer to [ACS-44, "DTC 20 CAN COMM CIRCUIT"](#).
NO >> GO TO 3.

3. CHECK D RANGE SWITCH

Ⓟ With CONSULT-II

With TCM "DATA MONITOR", check that "D" position switch operates normally.

OK or NG

- OK >> 1. Replace ICC unit.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.
- NG >> 1. Repair or replace applicable item.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

Symptom 5: Chime Does Not Sound

NKS003FV

The chime may not sound occasionally in the following cases even if the distance from the vehicle ahead is short:

- When the speed difference from that of the vehicle ahead is small (both vehicles driving at similar speed).
- When the vehicle ahead drives at faster speed (the actual distance is increasing).
- When depressing the accelerator.
- Chime does not sound when the vehicle is not driving.
- Chime does not sound when the system does not detect any vehicle ahead. (Diagnose the conditions under which the system is detecting the vehicle ahead and when the system is malfunctioning. If there is any malfunction in detecting the vehicle ahead, check the system following the [ACS-71, "Symptom 7: ICC System Frequently Cannot Detect the Vehicle Ahead/ Detection Zone Is Short"](#) .

1. CHECK ICC WARNING CHIME

Ⓟ With CONSULT-II

With "ACTIVE TEST", check that ICC warning chime operates normally.

OK or NG

- OK >> Determine preceding vehicle detection status when malfunction occurred. If chime should have sounded: after replacing ICC unit. Perform ICC system running test, and then perform self-diagnosis of ICC system again.
- NG >> GO TO 2.

2. CHECK CAN COMMUNICATION

With CONSULT-II

1. Perform self-diagnosis with CONSULT-II.
2. Check if "DTC 20 CAN COMM CIRCUIT" is indicated.

Is it indicated?

- YES >> Refer to [ACS-44, "DTC 20 CAN COMM CIRCUIT"](#) .
- NO >> GO TO 3.

3. CHECK UNIFIED METER AND A/C AMP.

Perform self-diagnosis of unified meter and A/C amp. Refer to [DI-31, "CONSULT-II Function \(METER A/C AMP\)"](#) .

OK or NG

- OK >> 1. Replace combination meter.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.
- NG >> 1. Repair or replace applicable item.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

Symptom 6: Driving Force Is Hunting

NKS003FW

1. CHECK ECM SELF-DIAGNOSIS

Perform self-diagnosis of ECM.

OK or NG

- OK >> Refer to [ACS-71, "Symptom 7: ICC System Frequently Cannot Detect the Vehicle Ahead/ Detection Zone Is Short"](#) .
- NG >> 1. Repair or replace applicable parts.
2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

Symptom 7: ICC System Frequently Cannot Detect the Vehicle Ahead/ Detection Zone Is Short

NKS003FX

ACS

The detection function may become unstable in the following cases.

- When the reflector of the vehicle ahead is deficient/ not clean enough to reflect the radar.
- When driving a road with extremely sharp corners.
- When the radar cannot detect the reflector of the vehicle ahead as the vehicle ahead is passing a hill or passing the peak.

1. VISUAL CHECK

Check ICC sensor body window for contamination and foreign materials.

OK or NG

- OK >> If any contamination or foreign materials are found, remove them. Then perform ICC system running test.
- NG >> GO TO 2.

2. CHECK FUNCTION

After adjusting ICC sensor beam aiming, perform ICC system running test. Check that preceding vehicle detection performance has been improved.

OK or NG

OK >> INSPECTION END

NG >> 1. Replace ICC sensor, and perform laser beam aiming adjustment.

2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

Symptom 8: The System Does Not Detect the Vehicle Ahead at All

NKS003FY

1. VISUAL CHECK 1

With ignition switch turned ON (engine not started), check that all indicator lamps in ICC system display are continuously lit. (Check for a missing segment in preceding vehicle detection display.)

OK or NG

OK >> GO TO 2.

NG >> Check for combination meter. Refer to [DI-16, "Trouble Diagnosis"](#) .

2. VISUAL CHECK 2

Check ICC sensor body window for contamination and foreign materials.

OK or NG

OK >> If any contamination or foreign materials are found, remove them. Perform ICC system running test.

NG >> GO TO 3.

3. VISUAL CHECK 3

Check ICC sensor body window for cracks and scratches.

OK or NG

OK >> GO TO 4.

NG >> 1. Replace ICC sensor, and perform laser beam aiming adjustment.

2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

4. ADJUST ICC SENSOR

After adjusting ICC sensor beam aiming, perform ICC system running test. Check that preceding vehicle detection performance has been improved.

OK or NG

OK >> INSPECTION END

NG >> 1. Replace ICC sensor, and perform laser beam aiming adjustment.

2. Erase DTC and perform ICC system running test. Then perform self-diagnosis of ICC system again.

ELECTRICAL COMPONENT INSPECTION


PFP:00000

ICC Steering Switch

NKS003FZ

1. Disconnect ICC steering switch.
2. Check resistance between ICC steering switch connector terminals by pressing each switch.

Terminals		Switch	Condition	Resistance [kΩ]
14	15	MAIN	Pressed	Approx. 0
			Released	Approx. 5.5
		CANCEL	Pressed	Approx. 0.3
			Released	Approx. 5.5
		DISTANCE	Pressed	Approx. 0.7
			Released	Approx. 5.5
		SET/COAST	Pressed	Approx. 1.4
			Released	Approx. 5.5
		RESUME/ACCELERATE	Pressed	Approx. 2.6
			Released	Approx. 5.5




Booster Solenoid

NKS003G1

Disconnect booster solenoid/release switch connector, and measure resistance between terminals 4 and 6.

Terminals		Resistance [Ω]
4	6	Approx. 1.4



Release Switch


NKS003G2

Disconnect booster solenoid/release switch connector and check resistance between the terminals.

Condition	1 - 3	1 - 2	2 - 3
Release the brake pedal.	Continuity should exist.	Continuity should not exist.	Continuity should not exist.
Depress the brake pedal.	Continuity should not exist. (Note)	Continuity should exist. (Note)	Continuity should not exist.

NOTE:

If pedal is depressed insufficiently, resistance value may remain unchanged.




A
B
C
D
E
F
G
H
I
J
ACS
L
M

ICC Brake Switch and Stop Lamp Switch

NKS003G0

Condition	Continuity	
	ICC brake switch	Stop lamp switch
When brake pedal is depressed	No	Yes
When brake pedal is released	Yes	No

Check each switch after adjusting brake pedal, refer to BR-6, "BRAKE PEDAL" .




ICC Brake Hold Relay

NKS003IE

Disconnect ICC brake hold relay, and check continuity between terminals.

Terminals		Condition	Continuity
3	4	Applying battery voltage to between terminals 1 and 2.	No
6	7		Yes
3	4	No battery voltage	Yes
6	7		No




REMOVAL AND INSTALLATION

PFP:00000

ICC Unit

NKS003G3



REMOVAL


1. Remove the instrument passenger lower panel. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#).
2. Remove the ECM.
3. Disconnect ICC unit connector.
4. Remove a mounting bolt and a nut from ICC unit.

INSTALLATION

Installation is the reverse order of removal.

ICC Sensor

NKS003G4



REMOVAL

1. Remove the front bumper. Refer to [EI-14, "FRONT BUMPER"](#).
2. Disconnect ICC sensor connector.
3. Remove mounting bolts from ICC sensor.

A
B
C
D
E
F
G
H
I
J
L
M

ACS

INSTALLATION

Installation is the reverse order of removal.

CAUTION:

Adjust the laser beam aiming every time the ICC sensor is removed or installed.

ICC Steering Switch

NKS003G5

Refer to [PS-12, "Removal and Installation"](#) .