

SECTION DEF

DEFOGGER

CONTENTS

| | | | |
|--|----|--|----|
| BASIC INSPECTION | 3 | Component Function Check | 13 |
| DIAGNOSIS AND REPAIR WORK FLOW | 3 | Diagnosis Procedure | 13 |
| Work Flow | 3 | DOOR MIRROR DEFOGGER | 15 |
| SYSTEM DESCRIPTION | 4 | Description | 15 |
| REAR WINDOW DEFOGGER SYSTEM | 4 | Component Function Check | 15 |
| System Diagram | 4 | Diagnosis Procedure | 15 |
| System Description | 4 | DRIVER SIDE DOOR MIRROR DEFOGGER ... | 16 |
| Component Parts Location | 5 | Description | 16 |
| Component Description | 5 | Component Function Check | 16 |
| DIAGNOSIS SYSTEM (BCM) | 6 | Diagnosis Procedure | 16 |
| COMMON ITEM | 6 | PASSENGER SIDE DOOR MIRROR DEFOGGER | 18 |
| COMMON ITEM : CONSULT Function (BCM - | | Description | 18 |
| COMMON ITEM) | 6 | Component Function Check | 18 |
| REAR WINDOW DEFOGGER | 7 | Diagnosis Procedure | 18 |
| REAR WINDOW DEFOGGER : CONSULT Func- | | REAR WINDOW DEFOGGER SYSTEM | 20 |
| tion (BCM - REAR DEFOGGER) | 7 | Wiring Diagram - DEFOGGER SYSTEM - | 20 |
| DTC/CIRCUIT DIAGNOSIS | 9 | ECU DIAGNOSIS INFORMATION | 21 |
| POWER SUPPLY AND GROUND CIRCUIT | 9 | BCM (BODY CONTROL MODULE) | 21 |
| BCM | 9 | Reference Value | 21 |
| BCM : Diagnosis Procedure | 9 | Wiring Diagram - BCM - | 43 |
| REAR WINDOW DEFOGGER SWITCH | 10 | Fail-safe | 47 |
| Description | 10 | DTC Inspection Priority Chart | 48 |
| Component Function Check | 10 | DTC Index | 49 |
| Diagnosis Procedure | 10 | SYMPTOM DIAGNOSIS | 51 |
| REAR WINDOW DEFOGGER RELAY | 11 | REAR WINDOW DEFOGGER AND DOOR | |
| Description | 11 | MIRROR DEFOGGERS DO NOT OPERATE ... | 51 |
| Component Function Check | 11 | Diagnosis Procedure | 51 |
| Diagnosis Procedure | 11 | REAR WINDOW DEFOGGER DOES NOT | |
| Component Inspection | 12 | OPERATE BUT BOTH DOOR MIRROR DE- | |
| REAR WINDOW DEFOGGER | 13 | FOGGERS OPERATE | 52 |
| Description | 13 | Diagnosis Procedure | 52 |

| | |
|---|-----------|
| DOOR MIRROR DEFOGGER DOES NOT OPERATE | 53 |
| BOTH SIDES | 53 |
| BOTH SIDES : Diagnosis Procedure | 53 |
| DRIVER SIDE | 53 |
| DRIVER SIDE : Diagnosis Procedure | 53 |
| PASSENGER SIDE | 53 |
| PASSENGER SIDE : Diagnosis Procedure | 53 |
| ON IS NOT DISPLAYED WHEN PRESSING REAR WINDOW DEFOGGER SWITCH BUT IT IS OPERATED | 54 |
| Diagnosis Procedure | 54 |

| | |
|--|-----------|
| REAR WINDOW DEFOGGER INDICATOR DOES NOT ILLUMINATE | 55 |
| Diagnosis Procedure | 55 |
| PRECAUTION | 56 |
| PRECAUTIONS | 56 |
| Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" | 56 |
| REMOVAL AND INSTALLATION | 57 |
| FILAMENT | 57 |
| Inspection and Repair | 57 |

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000007512125

DETAILED FLOW

1.OBTAIN INFORMATION ABOUT SYMPTOM

Interview the customer to obtain as much malfunction information (conditions and environment when the malfunction occurred) as possible when the customer brings the vehicle in.

>> GO TO 2.

2.CHECK DTC

Perform self diagnosis using CONSULT.

Is any DTC detected?

YES >> Refer to [BCS-74. "DTC Index"](#).

NO >> GO TO 3.

3.REPRODUCE THE MALFUNCTION INFORMATION

Check the malfunction on the vehicle that the customer describes.

Inspect the relation of the symptoms and the condition when the symptoms occur.

>> GO TO 4.

4.IDENTIFY THE MALFUNCTIONING SYSTEM WITH "SYMPTOM DIAGNOSIS"

Use "Symptom diagnosis" from the symptom inspection result in step 3. Then identify where to start performing the diagnosis based on possible causes and symptoms.

>> GO TO 5.

5.IDENTIFY MALFUNCTIONING PARTS WITH "COMPONENT DIAGNOSIS"

Perform the diagnosis with "Component diagnosis" of the applicable system.

>> GO TO 6.

6.REPAIR OR REPLACE THE MALFUNCTIONING PARTS

Repair or replace the specified malfunctioning parts.

>> GO TO 7.

7.FINAL CHECK

Check that malfunctions are not reproduced when obtaining the malfunction information from the customer, referring to the symptom inspection result in step 3.

Are all malfunctions corrected?

YES >> INSPECTION END

NO >> GO TO 4.

A

B

C

D

E

F

G

H

I

J

K

DEF

M

N

O

P

REAR WINDOW DEFOGGER SYSTEM


< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

REAR WINDOW DEFOGGER SYSTEM

System Diagram

INFOID:000000007512126



System Description

INFOID:000000007512127

Operation Description

- Turn rear window defogger switch ON when the ignition switch turns ON. Then multifunction switch (rear window defogger switch) transmits rear window defogger switch signal to AV control unit via AV communication. AV control unit transmits rear window defogger switch signal to BCM via CAN communication.
- BCM turns rear window defogger relay ON and transmits rear window defogger control signal to IPDM E/R via CAN communication when rear window defogger switch signal is received.
- Rear window defogger and door mirror defogger (with mirror defogger) are supplied with power and operate when rear window defogger relay turns ON.
- IPDM E/R transmits rear window defogger control signal to AV control unit via CAN communication.
- AV control unit transmits rear defogger indicator signal to multifunction switch (rear window defogger switch) via AV communication, then rear window defogger indicator is illuminated.

Timer function

- BCM turns rear window defogger relay ON for approximately 15 minutes when rear window defogger switch turns ON. It makes rear window defogger and door mirror defogger (with mirror defogger) operate.
- Timer is canceled after pressing rear window defogger switch again during timer operation. Then BCM turns rear window defogger relay OFF. The same reaction also occurs during timer operation, if the ignition switch is turned OFF.

INPUT/OUTPUT SIGNAL CHART


| Switch | Input signal to BCM | BCM function | Actuator |
|-----------------------------|------------------------|---|--|
| Rear window defogger switch | Defogger switch signal | Rear window defogger and Door mirror defogger control | Rear window defogger Door mirror defogger |
| Push button ignition switch | Ignition signal | | |

REAR WINDOW DEFOGGER SYSTEM

< SYSTEM DESCRIPTION >

Component Parts Location

INFOID:000000007512128



1. Rear window defogger relay

2. BCM

3. IPDM E/R
4. Rear window defogger switch (built-in multifunction switch)

5. Rear window defogger connector

6. Rear window defogger connector
7. AV control unit
- A. Dash side lower (driver side)

B. Dash side lower (passenger side)

C. Engine room dash panel (RH)
- D. Behind back door finisher

E. Behind cluster lid C

Component Description

INFOID:000000007512129

| Item | Function |
|--|--|
| BCM | <ul style="list-style-type: none">Operates the rear window defogger relay with the operation of rear window defogger switch.Performs the timer control of rear window defogger. |
| Rear window defogger relay | <ul style="list-style-type: none">Operates the rear window defogger and the door mirror defogger with the control signal from BCM. |
| IPDM E/R | <ul style="list-style-type: none">Transmits rear window defogger control signal to AV control unit via CAN communication. |
| Multifunction switch (Rear window defogger switch) | <ul style="list-style-type: none">The rear window defogger switch is installed.Turns the indicator lamp ON when detecting the operation of rear window defogger. |
| AV control unit | <ul style="list-style-type: none">Displays the rear window defogger ON to the display when detecting the operation of rear window defogger. |
| Rear window defogger | <ul style="list-style-type: none">Heats the heating wire with the power supply from the rear window defogger relay to prevent the rear window from fogging up. |
| Door mirror defogger | <ul style="list-style-type: none">Heats the heating wire with the power supply from the rear window defogger relay to prevent the door mirror from fogging up. |

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000007799404

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

| Diagnosis mode | Function Description |
|--------------------------|---|
| Work Support | Changes the setting for each system function. |
| Self Diagnostic Result | Displays the diagnosis results judged by BCM. |
| CAN Diag Support Monitor | Monitors the reception status of CAN communication viewed from BCM. |
| Data Monitor | The BCM input/output signals are displayed. |
| Active Test | The signals used to activate each device are forcibly supplied from BCM. |
| Ecu Identification | The BCM part number is displayed. |
| Configuration | <ul style="list-style-type: none"> Read and save the vehicle specification. Write the vehicle specification when replacing BCM. |

SYSTEM APPLICATION

BCM can perform the following functions for each system.

NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

×: Applicable item

| System | Sub system selection item | Diagnosis mode | | |
|---|---------------------------|----------------|--------------|-------------|
| | | Work Support | Data Monitor | Active Test |
| Door lock | DOOR LOCK | × | × | × |
| Rear window defogger | REAR DEFOGGER | | × | × |
| Warning chime | BUZZER | | × | × |
| Interior room lamp timer | INT LAMP | × | × | × |
| Exterior lamp | HEAD LAMP | × | × | × |
| Wiper and washer | WIPER | × | × | × |
| Turn signal and hazard warning lamps | FLASHER | × | × | × |
| — | AIR CONDITONER* | | | |
| <ul style="list-style-type: none"> Intelligent Key system Engine start system | INTELLIGENT KEY | × | × | × |
| Combination switch | COMB SW | | × | |
| Body control system | BCM | × | | |
| IVIS - NATS | IMMU | | × | × |
| Interior room lamp battery saver | BATTERY SAVER | × | × | × |
| Back door open | TRUNK | | × | × |
| Vehicle security system | THEFT ALM | × | × | × |
| RAP system | RETAINED PWR | | × | |
| Signal buffer system | SIGNAL BUFFER | | × | × |

NOTE:

*: This item is displayed, but is not used.

FREEZE FRAME DATA (FFD)

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays on CONSULT.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

| CONSULT screen item | Indication/Unit | Description | | |
|---------------------|-----------------|--|--|-----|
| Vehicle Speed | km/h | Vehicle speed of the moment a particular DTC is detected | | A |
| Odo/Trip Meter | km | Total mileage (Odometer value) of the moment a particular DTC is detected | | |
| Vehicle Condition | SLEEP>LOCK | Power position status of the moment a particular DTC is detected* | While turning BCM status from low power consumption mode to normal mode (Power supply position is "LOCK"*) | B |
| | SLEEP>OFF | | While turning BCM status from low power consumption mode to normal mode (Power supply position is "OFF".) | C |
| | LOCK>ACC | | While turning power supply position from "LOCK"* to "ACC" | |
| | ACC>ON | | While turning power supply position from "ACC" to "IGN" | D |
| | RUN>ACC | | While turning power supply position from "RUN" to "ACC" (Vehicle is stopping and selector lever is except P position.) | |
| | CRANK>RUN | | While turning power supply position from "CRANKING" to "RUN" (From cranking up the engine to run it) | E |
| | RUN>URGENT | | While turning power supply position from "RUN" to "ACC" (Emergency stop operation) | F |
| | ACC>OFF | | While turning power supply position from "ACC" to "OFF" | |
| | OFF>LOCK | | While turning power supply position from "OFF" to "LOCK"* | G |
| | OFF>ACC | | While turning power supply position from "OFF" to "ACC" | |
| | ON>CRANK | | While turning power supply position from "IGN" to "CRANKING" | |
| | OFF>SLEEP | | While turning BCM status from normal mode (Power supply position is "OFF".) to low power consumption mode | H |
| | LOCK>SLEEP | | While turning BCM status from normal mode (Power supply position is "LOCK"*) to low power consumption mode | I |
| | LOCK | | Power supply position is "LOCK"* | |
| | OFF | | Power supply position is "OFF" (Ignition switch OFF) | J |
| | ACC | | Power supply position is "ACC" (Ignition switch ACC) | |
| | ON | | Power supply position is "IGN" (Ignition switch ON with engine stopped) | K |
| | ENGINE RUN | | Power supply position is "RUN" (Ignition switch ON with engine running) | |
| | CRANKING | | Power supply position is "CRANKING" (At engine cranking) | DEF |
| IGN Counter | 0 - 39 | The number of times that ignition switch is turned ON after DTC is detected <ul style="list-style-type: none"> • The number is 0 when a malfunction is detected now. • The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. • The number is fixed to 39 until the self-diagnosis results are erased if it is over 39. | | M |

NOTE:

*: Power supply position shifts to "LOCK" from "OFF", when ignition switch is in the OFF position, selector lever is in the P position, and any of the following conditions are met.

- Closing door
- Opening door
- Door is locked using door request switch
- Door is locked using Intelligent Key

The power supply position shifts to "ACC" when the push-button ignition switch (push switch) is pushed at "LOCK".

REAR WINDOW DEFOGGER

REAR WINDOW DEFOGGER : CONSULT Function (BCM - REAR DEFOGGER)

INFOID:0000000007512131

Data monitor

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

| Monitor Item | Description |
|--------------|---|
| REAR DEF SW | This is displayed even when it is not equipped. |
| PUSH SW | Indicates [ON/OFF] condition of push switch. |

ACTIVE TEST

| Test Item | Description |
|---------------|---|
| REAR DEFOGGER | Rear window defogger operates when "ON" on CONSULT screen is touched. |

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT

BCM

BCM : Diagnosis Procedure

INFOID:000000007512132

1.CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

| Terminal No. | Signal name | Fuse and fusible link No. |
|--------------|----------------------|---------------------------|
| 1 | Battery power supply | L(40A) |
| 11 | | 10 (10A) |

Is the fuse blown?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit if a fuse or fusible link is blown.

NO >> GO TO 2.

2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connectors.
3. Check voltage between BCM harness connector and ground.

| (+) | | (-) | Voltage (V) (Approx.) |
|-----------|----------|--------|--------------------------|
| BCM | | | |
| Connector | Terminal | | |
| M118 | 1 | Ground | Battery voltage |
| M119 | 11 | | |

Is the measurement value normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3.CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

| BCM | | Ground | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal | | |
| M119 | 13 | | Existed |

Does continuity exist?

YES >> INSPECTION END

NO >> Repair or replace harness.

REAR WINDOW DEFOGGER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

REAR WINDOW DEFOGGER SWITCH

Description

INFOID:000000007512133

- The rear window defogger is operated by turning the rear window defogger switch ON.
- The indicator lamp in the rear window defogger illuminates when the rear window defogger is operating.

Component Function Check

INFOID:000000007512134

1.CHECK REAR WINDOW DEFOGGER SWITCH FUNCTION

Check that the indicator lamp of rear window defogger illuminates when rear window defogger switch ON.

Is the inspection result normal?

- YES >> Rear window defogger switch function is OK.
NO >> Refer to [DEF-10. "Diagnosis Procedure"](#)

Diagnosis Procedure

INFOID:000000007512135

1.CHECK PRESET SWITCH

Does preset switch operate normally?

- Without navigation system. Refer to [AV-17. "On Board Diagnosis Function"](#).
- With navigation system. Refer to [AV-151. "On Board Diagnosis Function"](#).

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Replace preset switch. Refer to [AV-126. "Removal and Installation"](#) (without navigation system) or [AV-301. "Removal and Installation"](#) (with navigation system).

REAR WINDOW DEFOGGER RELAY

< DTC/CIRCUIT DIAGNOSIS >

REAR WINDOW DEFOGGER RELAY

Description

INFOID:000000007512136

Power is supplied to the rear window defogger using BCM control.

Component Function Check

INFOID:000000007512137

1.CHECK REAR WINDOW DEFOGGER RELAY POWER SUPPLY CIRCUIT

1. Perform Active Test ("REAR DEFOGGER") using CONSULT.
2. Touch "ON".
3. Check that the rear window heating wire is getting warmer.

Is the inspection result normal?

- YES >> Rear window defogger relay power supply circuit is OK.
NO >> Refer to [DEF-11. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000007512138

1.CHECK FUSE

1. Turn ignition switch OFF.
2. Check 10A fuse [No.3, located in fuse block (J/B)].

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.

2.CHECK REAR WINDOW DEFOGGER RELAY CIRCUIT 1

1. Turn ignition switch ON.
2. Check voltage between BCM harness connector and ground.

| (+) | | (-) | Condition | Voltage (V) (Approx.) |
|-----------|----------|--------|----------------------------------|--------------------------|
| BCM | | | | |
| Connector | Terminal | | | |
| M123 | 151 | Ground | Rear window defogger switch: ON | 0 |
| | | | Rear window defogger switch: OFF | Battery voltage |

Is the inspection result normal?

- YES >> Rear window defogger power supply circuit is OK.
NO >> GO TO 3.

3.CHECK REAR WINDOW DEFOGGER RELAY CIRCUIT 2

1. Turn ignition switch OFF.
2. Disconnect BCM connector and fuse block (J/B).
3. Check continuity between BCM harness connector and fuse block (J/B) harness connector.

| BCM | | Fuse block (J/B) | | Continuity |
|-----------|----------|------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M123 | 151 | M2 | 4B | Existed |

4. Check continuity between BCM harness connector and ground.

| BCM | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| M123 | 151 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace harness.

REAR WINDOW DEFOGGER RELAY

< DTC/CIRCUIT DIAGNOSIS >

4.CHECK REAR WINDOW DEFOGGER RELAY

1. Disconnect rear window defogger relay,
2. Check rear window defogger relay.
Refer to [DEF-12. "Component Inspection"](#)

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace rear window defogger relay.

5.CHECK FUSE BLOCK (J/B)

1. Install the rear window defogger relay.
2. Turn ignition switch ON.
3. Check voltage between fuse block (J/B) connector (fuse block side) and ground.

| (+) | | (-) | Voltage (V) (Approx.) |
|------------------|----------|--------|--------------------------|
| Fuse block (J/B) | | | |
| Connector | Terminal | | |
| M2 | 4B | Ground | Battery voltage |

Is the inspection result normal?

YES >> GO TO 6.

NO >> Replace fuse block (J/B).

6.CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [GI-45. "Intermittent Incident"](#)

>> INSPECTION END.

Component Inspection

INFOID:000000007512139

1.CHECK REAR WINDOW DEFOGGER RELAY


1. Turn ignition switch OFF.
2. Disconnect rear window defogger relay.
3. Check rear window defogger relay.

| Rear window defogger relay | | Condition | Continuity |
|----------------------------|---|---|-------------|
| Terminal | | | |
| 3 | 5 | 12 V direct current supply between terminals 1 and 2. | Existed |
| | | No current supply | Not existed |

Is the inspection result normal?

YES >> INSPECTION END.

NO >> Replace rear window defogger relay.



REAR WINDOW DEFOGGER

< DTC/CIRCUIT DIAGNOSIS >

REAR WINDOW DEFOGGER

Description

INFOID:000000007512140

Heats the heating wire with the power supply from the rear window defogger relay to prevent the rear window from fogging up.

Component Function Check

INFOID:000000007512141

1.CHECK REAR WINDOW DEFOGGER

1. Perform Active Test ("REAR DEFOGGER") using CONSULT.
2. Touch "ON".
3. Check that the rear window heating wire is getting warmer.

Is the inspection result normal?

- YES >> Rear window defogger is OK.
NO >> Refer to [DEF-13, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000007512142

1.CHECK FUSE

1. Turn ignition switch OFF.
2. Check the following items.
 - 20A fuse [No.14, located in fuse block (J/B)]
 - 20A fuse [No.15, located in fuse block (J/B)]

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.

2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between rear window defogger harness connector and ground.

| (+)Rear window defogger | | (-) | Condition | Voltage (V) (Approx.) |
|-------------------------|----------|--------|----------------------------------|--------------------------|
| Connector | Terminal | | | |
| D108 | 1 | Ground | Rear window defogger switch: ON | Battery voltage |
| | | | Rear window defogger switch: OFF | 0 |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 4.

3.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear window defogger connector.
3. Check continuity between rear window defogger harness connector and ground.

| Rear window defogger | | Ground | Continuity |
|----------------------|----------|--------|------------|
| Connector | Terminal | | |
| D120 | 2 | | Existed |

Is the inspection result normal?

- YES >> GO TO 7.
NO >> Repair or replace harness.

4.CHECK REAR WINDOW DEFOGGER POWER SUPPLY CIRCUIT

REAR WINDOW DEFOGGER

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect fuse block (J/B) connector and rear window defogger connector.
3. Check continuity between fuse block (J/B) harness connector and rear window defogger harness connector.

| Fuse block (J/B) | | Rear window defogger | | Continuity |
|------------------|----------|----------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B6 | 10G | D108 | 1 | Existed |
| | 11G | | | |

4. Check continuity between fuse block (J/B) harness connector and ground.

| Fuse block (J/B) | | Ground | Continuity |
|------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B6 | 10G | | Not existed |
| | 11G | | |

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness.

5.CHECK FUSE BLOCK (J/B)

1. Turn ignition switch ON.
2. Check voltage between fuse block (J/B) (fuse block side) and ground.

| (+) Fuse block (J/B) | | (-) | Condition | Voltage (V) (Approx.) |
|----------------------|----------|--------|----------------------------------|--------------------------|
| Connector | Terminal | | | |
| B6 | 10G | Ground | Rear window defogger switch: ON | Battery voltage |
| | | | Rear window defogger switch: OFF | 0 |
| | 11G | | Rear window defogger switch: ON | Battery voltage |
| | | | Rear window defogger switch: OFF | 0 |

Is the inspection result normal?

YES >> GO TO 8.

NO >> GO TO 6.

6.CHECK REAR WINDOW DEFOGGER RELAY

Check rear window defogger relay. Refer to [DEF-12, "Component Inspection"](#)

Is the inspection result normal?

YES >> GO TO 8.

NO >> Replace rear window defogger relay.

7.CHECK FILAMENT

Check the filament for damage or blown.

Refer to [DEF-57, "Inspection and Repair"](#)

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair filament.

8.CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [GI-45, "Intermittent Incident"](#)

>> INSPECTION END

DOOR MIRROR DEFOGGER

< DTC/CIRCUIT DIAGNOSIS >

DOOR MIRROR DEFOGGER

Description

INFOID:000000007512144

Power is supplied to the door mirror defogger using BCM control.

Component Function Check

INFOID:000000007512145

1.CHECK DOOR MIRROR DEFOGGER

1. Perform Active Test ("REAR DEFOGGER") using CONSULT.
2. Touch "ON".
3. Check that both side door mirror glasses are getting warmer.

Is the inspection result normal?

- YES >> Door mirror defogger is OK.
NO >> Refer to [DEF-15. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000007512146

1.CHECK FUSE

1. Turn ignition switch OFF.
2. Check 10A fuse [No.13, located in fuse block (J/B)].

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.

2.CHECK FUSE BLOCK (J/B)

1. Disconnect fuse block (J/B) connector.
2. Turn ignition switch ON.
3. Check voltage between fuse block (J/B) connector (fuse block side) and ground.

| (+) | | (-) | Condition | Voltage (V) (Approx.) |
|------------------|----------|--------|----------------------------------|--------------------------|
| Fuse block (J/B) | | | | |
| Connector | Terminal | | | |
| M3 | 9C | Ground | Rear window defogger switch: ON | Battery voltage |
| | | | Rear window defogger switch: OFF | 0 |
| | 10C | | Rear window defogger switch: ON | Battery voltage |
| | | | Rear window defogger switch: OFF | 0 |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Replace fuse block (J/B).

3.CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [GI-45. "Intermittent Incident"](#).

>> INSPECTION END

DRIVER SIDE DOOR MIRROR DEFOGGER

< DTC/CIRCUIT DIAGNOSIS >

DRIVER SIDE DOOR MIRROR DEFOGGER

Description

INFOID:000000007512147

Heats the heating wire with the power supply from the rear window defogger relay to prevent the door mirror from fogging up.

Component Function Check

INFOID:000000007512148

1.CHECK DRIVER SIDE DOOR MIRROR DEFOGGER

1. Perform Active Test ("REAR DEFOGGER") using CONSULT.
2. Touch "ON".
3. Check that the driver side door mirror glass is getting warmer.

Is the inspection result normal?

- YES >> Driver side door mirror defogger is OK.
NO >> Refer to [DEF-16, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000007512149

1.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect door mirror (driver side) connector.
3. Turn ignition switch ON.
4. Check voltage between door mirror (driver side) harness connector and ground.

| (+)Door mirror (driver side) | | (-) | Condition | Voltage (V) (Approx.) |
|------------------------------|----------|--------|----------------------------------|--------------------------|
| Connector | Terminal | | | |
| D3 | 7 | Ground | Rear window defogger switch: ON | Battery voltage |
| | | | Rear window defogger switch: OFF | 0 |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> GO TO 2.

2.CHECK DRIVER SIDE DOOR MIRROR DEFOGGER CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect fuse block (J/B) connector.
3. Check continuity between fuse block (J/B) harness connector and door mirror (driver side) harness connector.

| Fuse block (J/B) | | Door mirror (driver side) | | Continuity |
|------------------|----------|---------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M3 | 10C | D3 | 7 | Existed |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace harness between fuse block (J/B) and door mirror (driver side).

3.CHECK FUSE BLOCK (J/B) OUTPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between fuse block (J/B) harness connector and ground.

DRIVER SIDE DOOR MIRROR DEFOGGER

< DTC/CIRCUIT DIAGNOSIS >

| (+)Fuse block (J/B) | | (-) | Condition | Voltage (V) (Approx.) |
|---------------------|----------|--------|----------------------------------|--------------------------|
| Connector | Terminal | | | |
| M3 | 10C | Ground | Rear window defogger switch: ON | Battery voltage |
| | | | Rear window defogger switch: OFF | 0 |

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace fuse block (J/B).

4.CHECK GROUND CIRCUIT

- Turn ignition switch OFF.
- Check continuity between door mirror (driver side) harness connector and ground.

| Door mirror (driver side) | | Ground | Continuity |
|---------------------------|----------|--------|------------|
| Connector | Terminal | | |
| D3 | 19 | | Existed |

Is the inspection result normal?

YES >> Replace door mirror glass (driver side). Refer to [MIR-48, "GLASS MIRROR : Removal and Installation"](#).

NO >> Repair or replace harness between door mirror (driver side) and ground.

5.CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [GI-45, "Intermittent Incident"](#)

>> INSPECTION END

A
B
C
D
E
F
G
H
I
J
K
DEF
M
N
O
P

DEF

PASSENGER SIDE DOOR MIRROR DEFOGGER

< DTC/CIRCUIT DIAGNOSIS >

PASSENGER SIDE DOOR MIRROR DEFOGGER

Description

INFOID:000000007512150

Heats the heating wire with the power supply from the rear window defogger relay to prevent the door mirror from fogging up.

Component Function Check

INFOID:000000007512151

1.CHECK PASSENGER SIDE DOOR MIRROR DEFOGGER

1. Perform Active Test ("REAR DEFOGGER") using CONSULT.
2. Touch "ON".
3. Check that the passenger side door mirror glass is getting warmer.

Is the inspection result normal?

- YES >> Passenger side door mirror defogger is OK.
NO >> Refer to [DEF-18, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000007512152

1.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect door mirror (passenger side) connector.
3. Turn ignition switch ON.
4. Check voltage between door mirror (passenger side) harness connector and ground.

| (+)Door mirror (Passenger side) | | (-) | Condition | Voltage (V) (Approx.) |
|---------------------------------|----------|--------|----------------------------------|--------------------------|
| Connector | Terminal | | | |
| D33 | 7 | Ground | Rear window defogger switch: ON | Battery voltage |
| | | | Rear window defogger switch: OFF | 0 |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> GO TO 2.

2.CHECK PASSENGER SIDE DOOR MIRROR DEFOGGER CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect fuse block (J/B) connector.
3. Check continuity between fuse block (J/B) harness connector and door mirror (passenger side) harness connector.

| Fuse block (J/B) | | Door mirror (passenger side) | | Continuity |
|------------------|----------|------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M3 | 9C | D33 | 7 | Existed |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace harness between fuse block (J/B) and door mirror (passenger side).

3.CHECK FUSE BLOCK (J/B) OUTPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between fuse block (J/B) harness connector and ground.

PASSENGER SIDE DOOR MIRROR DEFOGGER

< DTC/CIRCUIT DIAGNOSIS >

| (+)Fuse block (J/B) | | (-) | Condition | Voltage (V) (Approx.) |
|---------------------|----------|--------|----------------------------------|--------------------------|
| Connector | Terminal | | | |
| M3 | 9C | Ground | Rear window defogger switch: ON | Battery voltage |
| | | | Rear window defogger switch: OFF | 0 |

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace fuse block (J/B).

4.CHECK GROUND CIRCUIT

- Turn ignition switch OFF.
- Check continuity between door mirror (passenger side) harness connector and ground.

| Door mirror (passenger side) | | Ground | Continuity |
|------------------------------|----------|--------|------------|
| Connector | Terminal | | |
| D33 | 19 | | Existed |

Is the inspection result normal?

YES >> Replace door mirror glass (passenger side). Refer to [MIR-48, "GLASS MIRROR : Removal and Installation"](#).

NO >> Repair or replace harness between door mirror (passenger side) and ground.

5.CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [GI-45, "Intermittent Incident"](#)

>> INSPECTION END

A
B
C
D
E
F
G
H
I
J
K
DEF
M
N
O
P

DEF


REAR WINDOW DEFOGGER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

REAR WINDOW DEFOGGER SYSTEM

Wiring Diagram - DEFOGGER SYSTEM -

INFOID:000000007512153



2011/07/22

JRLWC1080GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION

BCM (BODY CONTROL MODULE)

Reference Value

INFOID:000000007799407

VALUES ON THE DIAGNOSIS TOOL

CONSULT MONITOR ITEM

| Monitor Item | Condition | Value/Status |
|----------------|---|----------------------------|
| FR WIPER HI | Other than front wiper switch HI | Off |
| | Front wiper switch HI | On |
| FR WIPER LOW | Other than front wiper switch LO | Off |
| | Front wiper switch LO | On |
| FR WASHER SW | Front washer switch OFF | Off |
| | Front washer switch ON | On |
| FR WIPER INT | Other than front wiper switch INT/AUTO | Off |
| | Front wiper switch INT/AUTO | On |
| FR WIPER STOP | Front wiper is not in STOP position | Off |
| | Front wiper is in STOP position | On |
| INT VOLUME | Wiper volume dial is in a dial position 1 - 7 | Wiper volume dial position |
| RR WIPER ON | Other than rear wiper switch ON | Off |
| | Rear wiper switch ON | On |
| RR WIPER INT | Other than rear wiper switch INT | Off |
| | Rear wiper switch INT | On |
| RR WASHER SW | Rear washer switch OFF | Off |
| | Rear washer switch ON | On |
| RR WIPER STOP | Rear wiper is in STOP position | Off |
| | Rear wiper is not in STOP position | On |
| TURN SIGNAL R | Other than turn signal switch RH | Off |
| | Turn signal switch RH | On |
| TURN SIGNAL L | Other than turn signal switch LH | Off |
| | Turn signal switch LH | On |
| TAIL LAMP SW | Other than lighting switch 1ST and 2ND | Off |
| | Lighting switch 1ST or 2ND | On |
| HI BEAM SW | Other than lighting switch HI | Off |
| | Lighting switch HI | On |
| HEAD LAMP SW 1 | Other than lighting switch 2ND | Off |
| | Lighting switch 2ND | On |
| HEAD LAMP SW 2 | Other than lighting switch 2ND | Off |
| | Lighting switch 2ND | On |
| PASSING SW | Other than lighting switch PASS | Off |
| | Lighting switch PASS | On |
| AUTO LIGHT SW | Other than lighting switch AUTO | Off |
| | Lighting switch AUTO | On |
| FR FOG SW | Front fog lamp switch OFF | Off |
| | Front fog lamp switch ON | On |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Monitor Item | Condition | Value/Status |
|---------------|--|--------------|
| RR FOG SW | NOTE: The item is indicated, but not monitored. | Off |
| DOOR SW-DR | Driver door closed | Off |
| | Driver door opened | On |
| DOOR SW-AS | Passenger door closed | Off |
| | Passenger door opened | On |
| DOOR SW-RR | Rear RH door closed | Off |
| | Rear RH door opened | On |
| DOOR SW-RL | Rear LH door closed | Off |
| | Rear LH door opened | On |
| DOOR SW-BK | Back door closed | Off |
| | Back door opened | On |
| CDL LOCK SW | Other than power door lock switch LOCK | Off |
| | Power door lock switch LOCK | On |
| CDL UNLOCK SW | Other than power door lock switch UNLOCK | Off |
| | Power door lock switch UNLOCK | On |
| KEY CYL LK-SW | Other than driver door key cylinder LOCK position | Off |
| | Driver door key cylinder LOCK position | On |
| KEY CYL UN-SW | Other than driver door key cylinder UNLOCK position | Off |
| | Driver door key cylinder UNLOCK position | On |
| KEY CYL SW-TR | NOTE: The item is indicated, but not monitored. | Off |
| HAZARD SW | Hazard switch is OFF | Off |
| | Hazard switch is ON | On |
| REAR DEF SW | NOTE: The item is indicated, but not monitored. | Off |
| TR CANCEL SW | NOTE: The item is indicated, but not monitored. | Off |
| TR/BD OPEN SW | Back door opener switch OFF | Off |
| | While the back door opener switch is turned ON | On |
| TRNK/HAT MNTR | NOTE: The item is indicated, but not monitored. | Off |
| REVERSE SW | NOTE: The item is indicated, but not monitored. | Off |
| RKE-LOCK | LOCK button of the Intelligent Key is not pressed | Off |
| | LOCK button of the Intelligent Key is pressed | On |
| RKE-UNLOCK | UNLOCK button of the Intelligent Key is not pressed | Off |
| | UNLOCK button of the Intelligent Key is pressed | On |
| RKE-TR/BD | NOTE: The item is indicated, but not monitored. | Off |
| RKE-PANIC | PANIC button of the Intelligent Key is not pressed | Off |
| | PANIC button of the Intelligent Key is pressed | On |
| RKE-P/W OPEN | UNLOCK button of the Intelligent Key is not pressed | Off |
| | UNLOCK button of the Intelligent Key is pressed and held | On |
| RKE-MODE CHG | LOCK/UNLOCK button of the Intelligent Key is not pressed and held simultaneously | Off |
| | LOCK/UNLOCK button of the Intelligent Key is pressed and held simultaneously | On |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Monitor Item | Condition | Value/Status | |
|----------------|--|--------------|-----|
| OPTICAL SENSOR | Bright outside of the vehicle | Close to 5 V | A |
| | Dark outside of the vehicle | Close to 0 V | |
| REQ SW -DR | Driver door request switch is not pressed | Off | B |
| | Driver door request switch is pressed | On | |
| REQ SW -AS | Passenger door request switch is not pressed | Off | C |
| | Passenger door request switch is pressed | On | |
| REQ SW -RR | NOTE: The item is indicated, but not monitored. | Off | D |
| REQ SW -RL | NOTE: The item is indicated, but not monitored. | Off | |
| REQ SW -BD/TR | Back door request switch is not pressed | Off | E |
| | Back door request switch is pressed | On | |
| PUSH SW | Push-button ignition switch (push switch) is not pressed | Off | F |
| | Push-button ignition switch (push switch) is pressed | On | |
| IGN RLY2 -F/B | NOTE: The item is indicated, but not monitored. | Off | |
| ACC RLY -F/B | NOTE: The item is indicated, but not monitored. | Off | G |
| CLUCH SW | NOTE: The item is indicated, but not monitored. | Off | H |
| BRAKE SW 1 | The brake pedal is depressed when No. 7 fuse is blown | Off | |
| | The brake pedal is not depressed when No. 7 fuse is blown, or No. 7 fuse is normal | On | I |
| BRAKE SW 2 | The brake pedal is not depressed | Off | |
| | The brake pedal is depressed | On | J |
| DETE/CANCL SW | Selector lever in P position | Off | |
| | Selector lever in any position other than P | On | K |
| SFT PN/N SW | Selector lever in any position other than P and N | Off | |
| | Selector lever in P or N position | On | |
| S/L -LOCK | NOTE: The item is indicated but not monitored. | Off | DEF |
| S/L -UNLOCK | NOTE: The item is indicated but not monitored. | Off | |
| S/L RELAY-F/B | NOTE: The item is indicated but not monitored. | Off | M |
| UNLK SEN -DR | Driver door is unlocked | Off | |
| | Driver door is locked | On | N |
| PUSH SW -IPDM | Push-button ignition switch (push-switch) is not pressed | Off | O |
| | Push-button ignition switch (push-switch) is pressed | On | |
| IGN RLY1 -F/B | Ignition switch in OFF or ACC position | Off | |
| | Ignition switch in ON position | On | P |
| DETE SW -IPDM | Selector lever in any position other than P | Off | |
| | Selector lever in P position | On | |
| SFT PN -IPDM | Selector lever in any position other than P and N | Off | |
| | Selector lever in P or N position | On | |
| SFT P -MET | Selector lever in any position other than P | Off | |
| | Selector lever in P position | On | |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Monitor Item | Condition | Value/Status |
|----------------|--|--|
| SFT N -MET | Selector lever in any position other than N | Off |
| | Selector lever in N position | On |
| ENGINE STATE | Engine stopped | Stop |
| | While the engine stalls | Stall |
| | At engine cranking | Crank |
| | Engine running | Run |
| S/L LOCK-IPDM | NOTE: The item is indicated but not monitored. | Off |
| S/L UNLK-IPDM | NOTE: The item is indicated but not monitored. | Off |
| S/L RELAY-REQ | NOTE: The item is indicated but not monitored. | Off |
| VEH SPEED 1 | While driving | Equivalent to speedometer reading |
| VEH SPEED 2 | While driving | Equivalent to speedometer reading |
| DOOR STAT-DR | Driver door is locked | LOCK |
| | Wait with selective UNLOCK operation (5 seconds) | READY |
| | Driver door is unlocked | UNLOCK |
| DOOR STAT-AS | Passenger door is locked | LOCK |
| | Wait with selective UNLOCK operation (5 seconds) | READY |
| | Passenger door is unlocked | UNLOCK |
| ID OK FLAG | Driver side door is open after ignition switch is turned OFF (Selector lever is in the P position) | Reset |
| | Ignition switch ON | Set |
| PRMT ENG STRT | The engine start is prohibited | Reset |
| | The engine start is permitted | Set |
| PRMT RKE STRT | NOTE: The item is indicated, but not monitored. | Reset |
| KEY SW -SLOT | The Intelligent Key is not inserted into key slot | Off |
| | The Intelligent Key is inserted into key slot | On |
| RKE OPE COUN1 | During the operation of the Intelligent Key | Operation frequency of the Intelligent Key |
| RKE OPE COUN2 | NOTE: The item is indicated, but not monitored. | — |
| CONFIRM ID ALL | The key ID that the key slot receives is not recognized by any key ID registered to BCM. | Yet |
| | The key ID that the key slot receives accords with any key ID registered to BCM. | Done |
| CONFIRM ID4 | The key ID that the key slot receives is not recognized by the fourth key ID registered to BCM. | Yet |
| | The key ID that the key slot receives is recognized by the fourth key ID registered to BCM. | Done |
| CONFIRM ID3 | The key ID that the key slot receives is not recognized by the third key ID registered to BCM. | Yet |
| | The key ID that the key slot receives is recognized by the third key ID registered to BCM. | Done |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Monitor Item | Condition | Value/Status |
|--------------|---|--------------|
| CONFIRM ID2 | The key ID that the key slot receives is not recognized by the second key ID registered to BCM. | Yet |
| | The key ID that the key slot receives is recognized by the second key ID registered to BCM. | Done |
| CONFIRM ID1 | The key ID that the key slot receives is not recognized by the first key ID registered to BCM. | Yet |
| | The key ID that the key slot receives is recognized by the first key ID registered to BCM. | Done |
| TP 4 | The ID of fourth Intelligent Key is not registered to BCM | Yet |
| | The ID of fourth Intelligent Key is registered to BCM | Done |
| TP 3 | The ID of third Intelligent Key is not registered to BCM | Yet |
| | The ID of third Intelligent Key is registered to BCM | Done |
| TP 2 | The ID of second Intelligent Key is not registered to BCM | Yet |
| | The ID of second Intelligent Key is registered to BCM | Done |
| TP 1 | The ID of first Intelligent Key is not registered to BCM | Yet |
| | The ID of first Intelligent Key is registered to BCM | Done |


A
B
C
D
E
F
G
H
I
J
K
DEF
M
N
O
P

DEF

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >

TERMINAL LAYOUT



BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|--|------------------|---|--|---|
| + | - | Signal name | Input/ Output | | | |
| 1 (W) | Ground | Battery power supply | Input | Ignition switch OFF | | Battery voltage |
| 2 (Y) | Ground | P/W power supply (BAT) | Output | Ignition switch OFF | | 12 V |
| 3 (BG) | Ground | P/W power supply (IGN) | Output | Ignition switch ON | | 12 V |
| 4 (P) | Ground | Interior room lamp power supply | Output | Interior room lamp battery saver is activated. (Cuts the interior room lamp power supply) | | 0 V |
| | | | | Interior room lamp battery saver is not activated. (Outputs the interior room lamp power supply) | | 12 V |
| 5 (V) | Ground | Passenger door UN- LOCK | Output | Passenger door | UNLOCK (Actuator is activated) | 12 V |
| | | | | | Other than UNLOCK (Actuator is not activated) | 0 V |
| 7 (Y) | Ground | Step lamp control | Output | Step lamp | ON | 0 V |
| | | | | | OFF | 12 V |
| 8 (V) | Ground | All doors, fuel lid LOCK | Output | All doors, fuel lid | LOCK (Actuator is activated) | 12 V |
| | | | | | Other than LOCK (Actuator is not activated) | 0 V |
| 9 (G) | Ground | Driver door, fuel lid UNLOCK | Output | Driver door, fuel lid | UNLOCK (Actuator is activated) | 12 V |
| | | | | | Other than UNLOCK (Actuator is not activated) | 0 V |
| 10 (BR) | Ground | Rear RH door and rear LH door UN- LOCK | Output | Rear RH door and rear LH door | UNLOCK (Actuator is activated) | 12 V |
| | | | | | Other than UNLOCK (Actuator is not activated) | 0 V |
| 11 (R) | Ground | Battery power supply | Input | Ignition switch OFF | | Battery voltage |
| 13 (B) | Ground | Ground | — | Ignition switch ON | | 0 V |
| 15 (Y) | Ground | ACC indicator lamp | Output | Ignition switch | OFF (LOCK indicator is not illuminated) | Battery voltage |
| | | | | | ACC or ON | 0 V |
| 17 (W) | Ground | Turn signal RH (Front) | Output | Ignition switch ON | Turn signal switch OFF | 0 V |
| | | | | | Turn signal switch RH |  |

A

B

C

D

E

F

G

H

I

J

K

DEF

M






N

O

P







BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|-------------------------------|------------------|---|--|---|
| + | - | Signal name | Input/ Output | | | |
| 18 (BG) | Ground | Turn signal LH (Front) | Output | Ignition switch ON | Turn signal switch OFF | 0 V |
| | | | | | Turn signal switch LH |  PKID0926E 6.5 V |
| 19 (SB) | Ground | Interior room lamp control | Output | Other than under condition | | 5.0 V |
| | | | | <ul style="list-style-type: none"> Interior room lamp timer is activated. (Door is unlocked. etc...) Welcome light function is activated. | | 0 V |
| 20 (V) | Ground | Turn signal RH (Rear) | Output | Ignition switch ON | Turn signal switch OFF | 0 V |
| | | | | | Turn signal switch RH |  PKID0926E 6.5 V |
| 25 (G) | Ground | Turn signal LH (Rear) | Output | Ignition switch ON | Turn signal switch OFF | 0 V |
| | | | | | Turn signal switch LH |  PKID0926E 6.5 V |
| 26 (P) | Ground | Rear wiper | Output | Rear wiper | OFF (Stopped) | 0 V |
| | | | | | ON (Operated) | 12 V |
| 34 (SB) | Ground | Luggage room anten- na (-) | Output | Ignition switch OFF | When Intelligent Key is in the passenger compart- ment |  JMKIA0062GB |
| | | | | | When Intelligent Key is not in the passenger com- partment |  JMKIA0063GB |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|-----------------------------------|------------------|---|---|--|
| + | - | Signal name | Input/ Output | | | |
| 35 (V) | Ground | Luggage room antenna (+) | Output | Ignition switch OFF | When Intelligent Key is in the passenger compartment |  JMKIA0062GB |
| | | | | | When Intelligent Key is not in the passenger compartment |  JMKIA0063GB |
| 38 (B) | Ground | Back door antenna (-) | Output | When the back door opener request switch is operated with ignition switch OFF | When Intelligent Key is in the antenna detection area |  JMKIA0062GB |
| | | | | | When Intelligent Key is not in the antenna detection area |  JMKIA0063GB |
| 39 (W) | Ground | Back door antenna (+) | Output | When the back door opener request switch is operated with ignition switch OFF | When Intelligent Key is in the antenna detection area |  JMKIA0062GB |
| | | | | | When Intelligent Key is not in the antenna detection area |  JMKIA0063GB |
| 47 (Y) | Ground | Ignition relay (IPDM E/R) control | Output | Ignition switch | OFF or ACC | 12 V |
| | | | | | ON | 0 V |

A

B

C

D

E

F

G

H

I

J

K

DEF

M





N

O

P






BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|--|------------------|--|--|--|
| + | - | Signal name | Input/ Output | | | |
| 52 (LG) | Ground | Starter relay control | Output | Ignition switch ON | When selector lever is in P or N position | 12 V |
| | | | | | When selector lever is not in P or N position | 0 V |
| 60 (SB) | Ground | Push-button ignition switch (Push switch) | Input | Push-button ig- nition switch (Push switch) | Pressed | 0 V |
| | | | | | Not pressed | 12 V |
| 61 (W) | Ground | Back door opener re- quest switch | Input | Back door re- quest switch | ON (Pressed) | 0 V |
| | | | | | OFF (Not pressed) |  1.0 V |
| 64 (L) | Ground | Intelligent Key warn- ing buzzer (Engine room) | Output | Intelligent Key warning buzzer (Engine room) | Sounding | 0 V |
| | | | | | Not sounding | 12 V |
| 65 (BG) | Ground | Rear wiper stop posi- tion | Input | Rear wiper | In stop position |  1.0 V |
| | | | | | Not in stop position | 0 V |
| 66 (LG) | Ground | Back door switch | Input | Back door switch | OFF (Door close) | 12 V |
| | | | | | ON (Door open) | 0 V |
| 67 (P) | Ground | Back door opener switch | Input | Back door open- er switch | Pressed | 0 V |
| | | | | | Not pressed |  8.5 - 9.0 V |
| 68 (BR) | Ground | Rear RH door switch | Input | Rear RH door switch | OFF (Door close) |  8.5 - 9.0 V |
| | | | | | ON (Door open) | 0 V |

BCM (BODY CONTROL MODULE)







< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|----------------------------|------------------|---|---|--|
| + | - | Signal name | Input/ Output | | | |
| 69 (R) | Ground | Rear LH door switch | Input | Rear LH door switch | OFF (Door close) |  8.5 - 9.0 V |
| | | | | | ON (Door open) | 0 V |
| 74 (SB) | Ground | Passenger door antenna (-) | Output | When the passenger door request switch is operated with ignition switch OFF | When Intelligent Key is in the antenna detection area |  JMKIA0062GB |
| | | | | | When Intelligent Key is not in the antenna detection area |  JMKIA0063GB |
| 75 (BR) | Ground | Passenger door antenna (+) | Output | When the passenger door request switch is operated with ignition switch OFF | When Intelligent Key is in the antenna detection area |  JMKIA0062GB |
| | | | | | When Intelligent Key is not in the antenna detection area |  JMKIA0063GB |

A
B
C
D
E
F
G
H
I
J
K
DEF
M
N
O
P





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|--|------------------|--|---|--|
| + | - | Signal name | Input/ Output | | | |
| 76 (V) | Ground | Driver door antenna (-) | Output | When the driver door request switch is operat- ed with ignition switch OFF | When Intelligent Key is in the antenna detection area |  JMKIA0062GB |
| | | | | | When Intelligent Key is not in the antenna detec- tion area |  JMKIA0063GB |
| 77 (LG) | Ground | Driver door antenna (+) | Output | When the driver door request switch is operat- ed with ignition switch OFF | When Intelligent Key is in the antenna detection area |  JMKIA0062GB |
| | | | | | When Intelligent Key is not in the antenna detec- tion area |  JMKIA0063GB |
| 78 (Y) | Ground | Room antenna (-) (Instrument panel) | Output | Ignition switch OFF | When Intelligent Key is in the passenger compart- ment |  JMKIA0062GB |
| | | | | | When Intelligent Key is not in the passenger com- partment |  JMKIA0063GB |

BCM (BODY CONTROL MODULE)





< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|---|------------------|------------------------|---|--|
| + | - | Signal name | Input/ Output | | | |
| 79 (BR) | Ground | Room antenna (+) (Instrument panel) | Output | Ignition switch OFF | When Intelligent Key is in the passenger compart- ment |  JMKIA0062GB |
| | | | | | When Intelligent Key is not in the passenger compart- ment |  JMKIA0063GB |
| 80 (GR) | Ground | NATS antenna amp. | Input/ Output | During waiting | Ignition switch is pressed while inserting the Intelli- gent Key into the key slot. | Just after pressing ignition switch. Pointer of tester should move. |
| 81 (W) | Ground | NATS antenna amp. | Input/ Output | During waiting | Ignition switch is pressed while inserting the Intelli- gent Key into the key slot. | Just after pressing ignition switch. Pointer of tester should move. |
| 82 (P) | Ground | Ignition relay [Fuse block (J/B)] control | Output | Ignition switch | OFF or ACC | 0 V |
| | | | | | ON | 12 V |
| 83 (GR) | Ground | Remote keyless entry receiver communica- tion | Input/ Output | | During waiting |  JMKIA0064GB |
| | | | | | When operating either button on the Intelli- gent Key |  JMKIA0065GB |

A
B
C
D
E
F
G
H
I
J
K
DEF
M
N
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|-------------------------------|------------------|--|--|
| + | - | Signal name | Input/ Output | | |
| 87 (BR) | Ground | Combination switch INPUT 5 | Input | Combination switch |  <p>1.4 V</p> |
| | | | | Front fog lamp switch ON (Wiper volume dial 4) |  <p>1.3 V</p> |
| | | | | Rear wiper switch ON (Wiper volume dial 4) |  <p>1.3 V</p> |
| | | | | Any of the conditions below with all switches OFF <ul style="list-style-type: none"> • Wiper volume dial 1 • Wiper volume dial 2 • Wiper volume dial 6 • Wiper volume dial 7 |  <p>1.3 V</p> |

BCM (BODY CONTROL MODULE)




< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|-------------------------------|------------------|-----------------------|--|
| + | - | Signal name | Input/ Output | | |
| 88 (V) | Ground | Combination switch INPUT 3 | Input | Combination switch | All switches OFF (Wiper volume dial 4) 1.4 V |
| | | | | | Lighting switch HI (Wiper volume dial 4) 1.3 V |
| | | | | | Lighting switch 2ND (Wiper volume dial 4) 1.3 V |
| | | | | | Rear washer switch ON (Wiper volume dial 4) 1.3 V |
| | | | | | Any of the conditions below with all switches OFF <ul style="list-style-type: none"> • Wiper volume dial 1 • Wiper volume dial 2 • Wiper volume dial 3 1.3 V |
| 90 (P) | Ground | CAN-L | Input/ Output | — | — |
| 91 (L) | Ground | CAN-H | Input/ Output | — | — |

A
B
C
D
E
F
G
H
I
J
K
DEF
M
N
O
P






BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|--|------------------|-------------------------------|---|--|
| + | - | Signal name | Input/ Output | | | |
| 92 (LG) | Ground | Key slot illumination | Output | Key slot illumination | OFF | 12 V |
| | | | | | Blinking |  <p>JPMIA0015GB</p> |
| | | | | | ON | 0 V |
| 93 (V) | Ground | ON indicator lamp | Output | Ignition switch | OFF (LOCK indicator is not illuminated) | Battery voltage |
| | | | | | ON or ACC | 0 V |
| 95 (BG) | Ground | ACC relay control | Output | Ignition switch | OFF | 0 V |
| | | | | | ACC or ON | 12 V |
| 96 (GR) | Ground | A/T shift selector (Detention switch) power supply | Output | — | — | 12 V |
| 99 (R) | Ground | Selector lever P position switch | Input | Selector lever | P position | 0 V |
| | | | | | Any position other than P | 12 V |
| 100 (G) | Ground | Passenger door request switch | Input | Passenger door request switch | ON (Pressed) | 0 V |
| | | | | | OFF (Not pressed) |  <p>JPMIA0016GB</p> |
| 101 (SB) | Ground | Driver door request switch | Input | Driver door request switch | ON (Pressed) | 0 V |
| | | | | | OFF (Not pressed) |  <p>JPMIA0016GB</p> |
| 102 (BG) | Ground | Blower fan motor relay control | Output | Ignition switch | OFF or ACC | 0 V |
| | | | | | ON | 12 V |
| 103 (BR) | Ground | Remote keyless entry receiver power supply | Output | Ignition switch OFF | | 12 V |

BCM (BODY CONTROL MODULE)






< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|-------------------------------|------------------|---|--|
| + | - | Signal name | Input/ Output | | |
| 107 (LG) | Ground | Combination switch INPUT 1 | Input | Combination switch (Wiper volume dial 4) | All switches OFF  1.4 V |
| | | | | | Turn signal switch LH  1.3 V |
| | | | | | Turn signal switch RH  1.3 V |
| | | | | | Front wiper switch LO  1.3 V |
| | | | | | Front washer switch ON  1.3 V |

A
B
C
D
E
F
G
H
I
J
K
DEF
M
N
O
P







BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|-------------------------------|------------------|-----------------------|---|
| + | - | Signal name | Input/ Output | | |
| 108 (R) | Ground | Combination switch INPUT 4 | Input | Combination switch | <p>All switches OFF (Wiper volume dial 4)</p>  <p>1.4 V</p> |
| | | | | | <p>Lighting switch AUTO (Wiper volume dial 4)</p>  <p>1.3 V</p> |
| | | | | | <p>Lighting switch 1ST (Wiper volume dial 4)</p>  <p>1.3 V</p> |
| | | | | | <p>Rear wiper switch INT (Wiper volume dial 4)</p>  <p>1.3 V</p> |
| | | | | | <p>Any of the conditions be- low with all switches OFF</p> <ul style="list-style-type: none"> • Wiper volume dial 1 • Wiper volume dial 5 • Wiper volume dial 6  <p>1.3 V</p> |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|-------------------------------|------------------|---|--|
| + | - | Signal name | Input/ Output | | |
| 109 (Y) | Ground | Combination switch INPUT 2 | Input | Combination switch (Wiper volume dial 4) | All switches OFF  1.4 V |
| | | | | | Lighting switch PASS  1.3 V |
| | | | | | Lighting switch 2ND  1.3 V |
| | | | | | Front wiper switch INT/ AUTO  1.3 V |
| | | | | | Front wiper switch HI  1.3 V |
| | | | | | ON 0 V |
| 110 (G) | Ground | Hazard switch | Input | Hazard switch | OFF  1.1 V |

A

B

C

D

E

F

G

H

I

J

K

DEF

M




N

O

P





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) | |
|------------------------------|--------|---|------------------|--|--|--|--|
| + | − | Signal name | Input/ Output | | | | |
| 112 (GR) | Ground | Rain sensor serial link | Input/ Output | Ignition switch ON | |  8.7 V | |
| 113 (P) | Ground | Optical sensor | Input | Ignition switch ON | When bright outside of the vehicle | Close to 5 V | |
| | | | | | When dark outside of the vehicle | Close to 0 V | |
| 116 (BR) | Ground | Stop lamp switch 1 | Input | — | | Battery voltage | |
| 118 (P) | Ground | Stop lamp switch 2 (Without ICC) | Input | Stop lamp switch | OFF (Brake pedal is not depressed) | 0 V | |
| | | | | | ON (Brake pedal is depressed) | Battery voltage | |
| | | Stop lamp switch 2 (With ICC) | | Stop lamp switch OFF (Brake pedal is not depressed) and ICC brake hold relay OFF | | 0 V | |
| | | | | Stop lamp switch ON (Brake pedal is depressed) or ICC brake hold relay ON | | Battery voltage | |
| 119 (SB) | Ground | Front door lock assembly driver side (Unlock sensor) | Input | Driver door | LOCK status (Unlock sensor switch OFF) |  8.5 - 9.0 V | |
| | | | | | UNLOCK status (Unlock switch sensor ON) | 0 V | |
| 121 (BR) | Ground | Key slot switch | Input | When the Intelligent Key is inserted into key slot | | 12 V | |
| | | | | When the Intelligent Key is not inserted into key slot | | 0 V | |
| 123 (W) | Ground | IGN feedback | Input | Ignition switch | OFF or ACC | 0 V | |
| | | | | | ON | Battery voltage | |
| 124 (LG) | Ground | Passenger door switch | Input | Passenger door switch | OFF (Door close) |  8.5 - 9.0 V | |
| | | | | | ON (Door open) | 0 V | |





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|--------------------------------------|------------------|---|--|--|
| + | - | Signal name | Input/ Output | | | |
| 132 (BG) | Ground | Power window switch communication | Input/ Output | Ignition switch ON | |  JPMIA0013GB 10.2 V |
| | | | | Ignition switch OFF or ACC | | 12 V |
| 134 (GR) | Ground | LOCK indicator lamp | Output | LOCK indicator lamp | OFF | Battery voltage |
| | | | | | ON | 0 V |
| 137 (B) | Ground | Receiver and sensor ground | Input | Ignition switch ON | | 0 V |
| 138 (Y) | Ground | Sensor power supply | Output | Ignition switch | OFF | 0 V |
| | | | | | ACC or ON | 5.0 V |
| 140 (R) | Ground | Selector lever P/N position | Input | Selector lever | P or N position | 12 V |
| | | | | | Except P and N positions | 0 V |
| 141 (G) | Ground | Security indicator lamp | Output | Security indica- tor lamp | ON | 0 V |
| | | | | | Blinking |  JPMIA0014GB 11.3 V |
| | | | | | OFF | 12 V |
| 142 (BG) | Ground | Combination switch OUTPUT 5 | Output | Combination switch (Wiper volume dial 4) | All switches OFF | 0 V |
| | | | | | Lighting switch 1ST |  JPMIA0031GB 10.7 V |
| | | | | | Lighting switch HI | |
| | | | | | Lighting switch 2ND | |
| | | | | | Turn signal switch RH | |
| 143 (P) | Ground | Combination switch OUTPUT 1 | Output | Combination switch | All switches OFF (Wiper volume dial 4) | 0 V |
| | | | | | Front wiper switch HI (Wiper volume dial 4) |  JPMIA0032GB 10.7 V |
| | | | | | Rear wiper switch INT (Wiper volume dial 4) | |
| | | | | | Any of the conditions be- low with all switches OFF | |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|---|------------------|---|---|--|
| + | - | Signal name | Input/ Output | | | |
| 144 (G) | Ground | Combination switch OUTPUT 2 | Output | Combination switch | All switches OFF (Wiper volume dial 4) | 0 V |
| | | | | | Front washer switch ON (Wiper volume dial 4) |  |
| | | | | | Rear wiper switch ON (Wiper volume dial 4) | |
| | | | | | Rear washer switch ON (Wiper volume dial 4) | |
| | | | | | Any of the conditions below with all switches OFF <ul style="list-style-type: none"> • Wiper volume dial 1 • Wiper volume dial 5 • Wiper volume dial 6 | |
| 145 (L) | Ground | Combination switch OUTPUT 3 | Output | Combination switch (Wiper volume dial 4) | All switches OFF | 0 V |
| | | | | | Front wiper switch INT/ AUTO |  |
| | | | | | Front wiper switch LO | |
| | | | | | Lighting switch AUTO | |
| 146 (SB) | Ground | Combination switch OUTPUT 4 | Output | Combination switch (Wiper volume dial 4) | All switches OFF | 0 V |
| | | | | | Front fog lamp switch ON |  |
| | | | | | Lighting switch 2ND | |
| | | | | | Lighting switch PASS | |
| | | | | | Turn signal switch LH | |
| 150 (GR) | Ground | Driver door switch | Input | Driver door switch | OFF (Door close) |  8.5 - 9.0 V |
| | | | | | ON (Door open) | 0 V |
| 151 (G) | Ground | Rear window defog- ger relay control | Output | Rear window de- fogger | Active | 0 V |
| | | | | | Not activated | Battery voltage |


BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Wiring Diagram - BCM -

INFOID:000000007799408

For connector terminal arrangements, harness layouts, and alphabets in a  (option abbreviation; if not described in wiring diagram), refer to [GI-13, "Connector Information"](#).




2011/07/22

JRMWC4836GB

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >



JRMWC4837GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >




JRMWC4838GB

A
B
C
D
E
F
G
H
I
J
K
DEF
M
N
O
P

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >

IC : With ICC
OI : Without ICC



BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >



Fail-safe

FAIL-SAFE CONTROL BY DTC

BCM performs fail-safe control when any DTC are detected.

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Display contents of CONSULT | Fail-safe | Cancellation |
|-----------------------------|---|--|
| B2190: NATS ANTENNA AMP | Inhibit engine cranking | Erase DTC |
| B2191: DIFFERENCE OF KEY | Inhibit engine cranking | Erase DTC |
| B2192: ID DISCORD BCM-ECM | Inhibit engine cranking | Erase DTC |
| B2193: CHAIN OF BCM-ECM | Inhibit engine cranking | Erase DTC |
| B2195: ANTI SCANNING | Inhibit engine cranking | Ignition switch ON → OFF |
| B2560: STARTER CONT RELAY | Inhibit engine cranking | 500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> Starter control relay signal Starter relay status signal |
| B2608: STARTER RELAY | Inhibit engine cranking | 500 ms after the following signal communication status becomes consistent <ul style="list-style-type: none"> Starter relay control signal Starter relay status signal (CAN) |
| B260A: IGNITION RELAY | Inhibit engine cranking | 500 ms after the following conditions are fulfilled <ul style="list-style-type: none"> IGN relay (IPDM E/R) control signal: OFF (Battery voltage) Ignition ON signal (CAN to IPDM E/R): OFF (Request signal) Ignition ON signal (CAN from IPDM E/R): OFF (Condition signal) |
| B260F: ENG STATE SIG LOST | Maintains the power supply position attained at the time of DTC detection | When any of the following conditions are fulfilled <ul style="list-style-type: none"> Power position changes to ACC Receives engine status signal (CAN) |
| B2617: STARTER RELAY CIRC | Inhibit engine cranking | 1 second after the starter relay control inside BCM becomes normal |
| B2618: BCM | Inhibit engine cranking | 1 second after the ignition relay (IPDM E/R) control inside BCM becomes normal |
| B261E: VEHICLE TYPE | Inhibit engine cranking | BCM initialization |

FAIL-SAFE CONTROL BY RAIN SENSOR MALFUNCTION

- BCM judges the rain sensor serial link error by the rain sensor serial link condition and detects the rain sensor malfunction by rain sensor malfunction signal.
- When BCM detects the rain sensor serial link error or the rain sensor malfunction while front wiper AUTO operation, BCM operates a fail-safe control.

NOTE:

If rain sensor malfunction is detected when ignition switch is turned OFF ⇒ ON and front wiper switch is INT position, BCM operates a fail-safe control.

REAR WIPER MOTOR PROTECTION

BCM detects the rear wiper stopping position according to the rear wiper stop position signal.

When the rear wiper stop position signal does not change for more than 5 seconds while driving the rear wiper, BCM stops power supply to protect the rear wiper motor.

Condition of cancellation

- More than 1 minute is passed after the rear wiper stops.
- Turn rear wiper switch OFF.
- Operate the rear wiper switch or rear washer switch.

DTC Inspection Priority Chart

INFOID:000000007799410

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

| Priority | DTC |
|----------|---|
| 1 | B2562: LOW VOLTAGE |
| 2 | <ul style="list-style-type: none"> U1000: CAN COMM U1010: CONTROL UNIT(CAN) |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Priority | DTC |
|----------|--|
| 3 | <ul style="list-style-type: none"> B2190: NATS ANTENNA AMP B2191: DIFFERENCE OF KEY B2192: ID DISCORD BCM-ECM B2193: CHAIN OF BCM-ECM B2195: ANTI SCANNING |
| 4 | <ul style="list-style-type: none"> B2553: IGNITION RELAY B2555: STOP LAMP B2556: PUSH-BTN IGN SW B2557: VEHICLE SPEED B2560: STARTER CONT RELAY B2601: SHIFT POSITION B2602: SHIFT POSITION B2603: SHIFT POSI STATUS B2604: PNP/CLUTCH SW B2605: PNP/CLUTCH SW B2608: STARTER RELAY B260A: IGNITION RELAY B260F: ENG STATE SIG LOST B2614: BCM B2615: BCM B2616: BCM B2617: BCM B2618: BCM B261A: PUSH-BTN IGN SW B261E: VEHICLE TYPE B26EA: KEY REGISTRATION U0415: VEHICLE SPEED SIG |
| 5 | <ul style="list-style-type: none"> B2621: INSIDE ANTENNA B2623: INSIDE ANTENNA |
| 6 | B26E7: TPMS CAN COMM |

DTC Index

INFOID:000000007799411

NOTE:

The details of time display are as follows.

- CRNT: A malfunction is detected now.
- PAST: A malfunction was detected in the past.

IGN counter is displayed on Freeze Frame Data. For details of Freeze Frame Data, refer to [BCS-18, "COMMON ITEM : CONSULT Function \(BCM - COMMON ITEM\)"](#).

| CONSULT display | Fail-safe | Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition | Intelligent Key warn- ing lamp ON | Reference |
|--|-----------|--|--------------------------------------|------------------------|
| No DTC is detected. Further testing may be required. | — | — | — | — |
| U1000: CAN COMM | — | — | — | BCS-36 |
| U1010: CONTROL UNIT(CAN) | — | — | — | BCS-37 |
| U0415: VEHICLE SPEED SIG | — | — | — | BCS-38 |
| B2190: NATS ANTENNA AMP | × | — | — | SEC-47 |
| B2191: DIFFERENCE OF KEY | × | — | — | SEC-50 |
| B2192: ID DISCORD BCM-ECM | × | — | — | SEC-51 |
| B2193: CHAIN OF BCM-ECM | × | — | — | SEC-53 |
| B2195: ANTI SCANNING | × | — | — | SEC-54 |
| B2553: IGNITION RELAY | — | × | — | PCS-49 |
| B2555: STOP LAMP | — | × | — | SEC-55 |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| CONSULT display | Fail-safe | Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition | Intelligent Key warn- ing lamp ON | Reference |
|---------------------------|-----------|--|--------------------------------------|-------------------------|
| B2556: PUSH-BTN IGN SW | — | × | × | SEC-57 |
| B2557: VEHICLE SPEED | × | × | × | SEC-59 |
| B2560: STARTER CONT RELAY | × | × | × | SEC-60 |
| B2562: LOW VOLTAGE | — | × | — | BCS-39 |
| B2601: SHIFT POSITION | × | × | × | SEC-61 |
| B2602: SHIFT POSITION | × | × | × | SEC-64 |
| B2603: SHIFT POSI STATUS | × | × | × | SEC-66 |
| B2604: PNP/CLUTCH SW | × | × | × | SEC-69 |
| B2605: PNP/CLUTCH SW | × | × | × | SEC-71 |
| B2608: STARTER RELAY | × | × | × | SEC-73 |
| B260A: IGNITION RELAY | × | × | × | PCS-51 |
| B260F: ENG STATE SIG LOST | × | × | × | SEC-75 |
| B2614: BCM | — | × | × | PCS-53 |
| B2615: BCM | — | × | × | PCS-55 |
| B2616: BCM | — | × | × | PCS-57 |
| B2617: BCM | × | × | × | SEC-77 |
| B2618: BCM | × | × | × | PCS-59 |
| B261A: PUSH-BTN IGN SW | — | × | × | SEC-79 |
| B261E: VEHICLE TYPE | × | × | × (Turn ON for 15 seconds) | SEC-82 |
| B2621: INSIDE ANTENNA | — | × | — | DLK-100 |
| B2623: INSIDE ANTENNA | — | × | — | DLK-102 |
| B26E7: TPMS CAN COMM | — | — | — | BCS-40 |
| B26EA: KEY REGISTRATION | — | × | × (Turn ON for 15 seconds) | SEC-76 |

REAR WINDOW DEFOGGER AND DOOR MIRROR DEFOGGER DO NOT OPERATE

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

REAR WINDOW DEFOGGER AND DOOR MIRROR DEFOGGER DO NOT OPERATE

Diagnosis Procedure

INFOID:0000000007512159

1.CHECK BCM POWER SUPPLY AND GROUND CIRCUIT

Check BCM power supply and ground circuit.
Refer to [DEF-9, "BCM : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK REAR WINDOW DEFOGGER SWITCH

Check rear window defogger switch.
Refer to [DEF-10, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CHECK REAR WINDOW DEFOGGER RELAY

Check rear window defogger relay.
Refer to [DEF-11, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4.CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

NO >> GO TO 1.

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

DEF

REAR WINDOW DEFOGGER DOES NOT OPERATE BUT BOTH DOOR MIRROR DEFOGGERS OPERATE

< SYMPTOM DIAGNOSIS >

REAR WINDOW DEFOGGER DOES NOT OPERATE BUT BOTH DOOR MIRROR DEFOGGERS OPERATE

Diagnosis Procedure

INFOID:000000007512160

1.CHECK REAR WINDOW DEFOGGER

Check rear window defogger.

Refer to [DEF-13, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CONFIRM THE OPERATION

Confirm the operation again

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

NO >> GO TO 1.

DOOR MIRROR DEFOGGER DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

DOOR MIRROR DEFOGGER DOES NOT OPERATE BOTH SIDES

BOTH SIDES : Diagnosis Procedure

INFOID:000000007512161

1.CHECK DOOR MIRROR DEFOGGER

Check door mirror defogger.

Refer to [DEF-15, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

NO >> GO TO 1.

DRIVER SIDE

DRIVER SIDE : Diagnosis Procedure

INFOID:000000007512162

1.CHECK DRIVER SIDE DOOR MIRROR DEFOGGER

Check driver side door mirror defogger.

Refer to [DEF-16, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

NO >> GO TO 1.

PASSENGER SIDE

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000007512163

1.CHECK PASSENGER SIDE DOOR MIRROR DEFOGGER.

Check passenger side door mirror defogger.

Refer to [DEF-18, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

NO >> GO TO 1.

A

B

C

D

E

F

G

H

I

J

K

DEF

M

N

O

P

ON IS NOT DISPLAYED WHEN PRESSING REAR WINDOW DEFOGGER SWITCH BUT IT IS OPERATED

< SYMPTOM DIAGNOSIS >

ON IS NOT DISPLAYED WHEN PRESSING REAR WINDOW DEFOGGER SWITCH BUT IT IS OPERATED

Diagnosis Procedure

INFOID:000000007512164

1.CHECK AV CONTROL UNIT FUNCTION

Check that the AV control unit is operating normally.

- Without navigation system. Refer to [AV-56, "Work Flow"](#).
- With navigation system. Refer to [AV-196, "Work Flow \(Multi AV\)"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

NO >> GO TO 1.

REAR WINDOW DEFOGGER INDICATOR DOES NOT ILLUMINATE

< SYMPTOM DIAGNOSIS >

REAR WINDOW DEFOGGER INDICATOR DOES NOT ILLUMINATE

Diagnosis Procedure

INFOID:000000007512165

1.CHECK PRESET SWITCH

Check rear window defogger operation.

- YES >> Replace preset switch. Refer to [AV-126. "Removal and Installation"](#) (without navigation system) or [AV-301. "Removal and Installation"](#) (with navigation system).
- NO >> Check rear window defogger system. Refer to [DEF-3. "Work Flow"](#).

A
B
C
D
E
F
G
H
I
J
K
DEF
M
N
O
P

DEF

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000007512166

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

FILAMENT

< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION


FILAMENT

Inspection and Repair


INFOID:000000007512167

INSPECTION


1. When measuring voltage, wrap tin foil around the top of the negative probe. Then press the foil against the wire with finger.



2. Attach probe circuit tester (in Volt range) to middle portion of each filament.



3. If a filament is burned out, circuit tester registers 0 or battery voltage.
4. To locate burned out point, move probe to left and right along filament. Test needle will swing abruptly when probe passes the point.



REPAIR

REPAIR EQUIPMENT

- Conductive silver composition (Dupont No. 4817 or equivalent)


FILAMENT

< REMOVAL AND INSTALLATION >


- Ruler 30 cm (11.8 in) long
- Drawing pen
- Heat gun
- Alcohol
- Cloth

REPAIRING PROCEDURE

1. Wipe broken heat wire and its surrounding area clean with a stop cloth dampened in alcohol.
2. Shake silver composition container before use.
Apply a small amount of conductive silver composition to tip of drawing pen.
3. Place ruler on glass along broken line. Deposit conductive silver composition on break with drawing pen. Slightly overlap existing heat wire on both sides [preferably 5 mm (0.20 in)] of the break.



4. After repair is completed, check repaired wire for continuity. This check must be conducted 10 minutes after silver composition is deposited.
Do not touch repairing area while test is being conducted.



5. Apply a constant stream of hot air directly to the repaired area for approximately 20 minutes with a heat gun. The minimum distance of 3 cm (1.2 in) must be kept between repaired area and hot air outlet.
If a heat gun is not available, let the repaired area dry for 24 hours.

