

# SECTION **SEC**

## SECURITY CONTROL SYSTEM

### CONTENTS

<b>BASIC INSPECTION</b>	3	<b>IMMU</b>	14
		IMMU : CONSULT-III Function (BCM - IMMU)	14
<b>DIAGNOSIS AND REPAIR WORKFLOW</b>	3	<b>THEFT ALM</b>	15
Work Flow	3	THEFT ALM : CONSULT-III Function (BCM - THEFT ALM)	15
<b>PRE-INSPECTION FOR DIAGNOSTIC</b>	6	<b>COMPONENT DIAGNOSIS</b>	16
Basic Inspection	6	<b>U1000 CAN COMM CIRCUIT</b>	16
<b>INSPECTION AND ADJUSTMENT</b>	7	Description	16
<b>ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT</b>	7	DTC Logic	16
ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement	7	Diagnosis Procedure	16
<b>ECM RE-COMMUNICATING FUNCTION</b>	7	<b>U1010 CONTROL UNIT (CAN)</b>	17
ECM RE-COMMUNICATING FUNCTION : De- scription	7	Description	17
ECM RE-COMMUNICATING FUNCTION : Spe- cial Repair Requirement	7	DTC Logic	17
		Diagnosis Procedure	17
		Special Repair Requirement	17
<b>FUNCTION DIAGNOSIS</b>	8	<b>B2190, P1614 NATS ANTENNA AMP.</b>	18
<b>NVIS (NISSAN VEHICLE IMMOBILIZER SYS- TEM-NATS)</b>	8	Description	18
System Diagram	8	DTC Logic	18
System Description	8	Diagnosis Procedure	18
Component Parts Location	9	<b>B2191, P1615 DIFFERENCE OF KEY</b>	21
Component Description	10	Description	21
<b>VEHICLE SECURITY SYSTEM</b>	11	DTC Logic	21
System Diagram	11	Diagnosis Procedure	21
System Description	11	<b>B2192, P1611 ID DISCORD, IMMU-ECM</b>	22
Component Parts Location - King Cab	12	Description	22
Component Parts Location - Crew Cab	13	DTC Logic	22
Component Description	13	Diagnosis Procedure	22
<b>DIAGNOSIS SYSTEM (BCM)</b>	14	<b>B2193, P1612 CHAIN OF ECM-IMMU</b>	24
<b>COMMON ITEM</b>	14	Description	24
COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM)	14	DTC Logic	24
		Diagnosis Procedure	24
<b>P1610 LOCK MODE</b>	25	<b>P1610 LOCK MODE</b>	25
		Description	25
		DTC Logic	25

Diagnosis Procedure .....	25
<b>POWER SUPPLY AND GROUND CIRCUIT ....</b>	<b>26</b>
Diagnosis Procedure .....	26
<b>KEY CYLINDER SWITCH .....</b>	<b>28</b>
<b>DRIVER SIDE .....</b>	<b>28</b>
DRIVER SIDE : Description .....	28
DRIVER SIDE : Component Function Check .....	28
DRIVER SIDE : Diagnosis Procedure .....	28
<b>HORN FUNCTION .....</b>	<b>31</b>
Symptom Table .....	31
<b>VEHICLE SECURITY INDICATOR .....</b>	<b>32</b>
Description .....	32
Component Function Check .....	32
Diagnosis Procedure .....	32
<b>ECU DIAGNOSIS .....</b>	<b>34</b>
<b>BCM (BODY CONTROL MODULE) .....</b>	<b>34</b>
Reference Value .....	34
Terminal Layout .....	37
Physical Values .....	37
Wiring Diagram - VEHICLE SECURITY SYSTEM (King Cab) - .....	43
Wiring Diagram - VEHICLE SECURITY SYSTEM (Crew Cab) - .....	52
Wiring Diagram - NVIS - .....	60
Fail Safe .....	63
DTC Inspection Priority Chart .....	64
DTC Index .....	64
<b>IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) .....</b>	<b>66</b>
Reference Value .....	66
Terminal Layout .....	67
Physical Values .....	68
Wiring Diagram .....	72
Fail Safe .....	76
DTC Index .....	78
<b>SYMPTOM DIAGNOSIS .....</b>	<b>79</b>
<b>VEHICLE SECURITY SYSTEM SYMPTOMS ...</b>	<b>79</b>
Symptom Table .....	79
<b>NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS SYMPTOMS .....</b>	<b>80</b>
Symptom Table .....	80
<b>PRECAUTION .....</b>	<b>81</b>
<b>PRECAUTIONS .....</b>	<b>81</b>
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	81
<b>ON-VEHICLE REPAIR .....</b>	<b>82</b>
<b>NATS ANTENNA AMP. ....</b>	<b>82</b>
Removal and Installation .....	82
<b>REMOTE KEYLESS ENTRY RECEIVER .....</b>	<b>83</b>
Removal and Installation .....	83

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

#### Work Flow

INFOID:000000005272573

#### OVERALL SEQUENCE



#### DETAILED FLOW

A

B

C

D

E

F

G

H

I

J

SEC

L

M

N

O

P

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

## 1. GET INFORMATION FOR SYMPTOM

Get the detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred).

>> GO TO 2

## 2. CHECK DTC

1. Check DTC for BCM.
2. Perform the following procedure if DTC is displayed.
  - Erase DTC.
  - Study the relationship between the cause detected by DTC and the symptom described by the customer.
3. Check related service bulletins for information.

Is any symptom described and any DTC detected?

Symptom is described, DTC is displayed>>GO TO 3

Symptom is described, DTC is not displayed>>GO TO 4

Symptom is not described, DTC is displayed>>GO TO 5

## 3. CONFIRM THE SYMPTOM

Confirm the symptom described by the customer.

Connect CONSULT-III to the vehicle in "DATA MONITOR" mode and check real-time diagnosis results.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5

## 4. CONFIRM THE SYMPTOM

Confirm the symptom described by the customer.

Connect CONSULT-III to the vehicle in "DATA MONITOR" mode and check real-time diagnosis results.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6

## 5. PERFORM DTC CONFIRMATION PROCEDURE

Perform DTC Confirmation Procedure for the displayed DTC, and then check that DTC is detected again.

If two or more DTCs are detected, refer to [SEC-64, "DTC Inspection Priority Chart"](#) (BCM) and determine trouble diagnosis order.

Is DTC detected?

YES >> GO TO 8

NO >> Refer to [GI-46, "Intermittent Incident"](#).

## 6. PERFORM BASIC INSPECTION

Perform Basic Inspection. Refer to [SEC-6, "Basic Inspection"](#).

>> GO TO 7

## 7. DETECT MALFUNCTIONING SYSTEM BY SYMPTOM TABLE

Detect malfunctioning system according to Symptom Table based on the confirmed symptom in step 4.

>> GO TO 8

## 8. DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

Inspect according to Diagnostic Procedure of the system.

**NOTE:**

The Diagnostic Procedure is described based on open circuit inspection. A short circuit inspection is also required for the circuit check in the Diagnostic Procedure.

>> GO TO 9

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

## 9.REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnostic Procedure again after repair and replacement.
3. Check DTC. If DTC is displayed, erase it.

>> GO TO 10

## 10.FINAL CHECK

When DTC was detected in step 9, perform DTC Confirmation Procedure or Component Function Check again, and then check that the malfunctions have been fully repaired.

When symptom was described by the customer, refer to the confirmed symptom in step 3 or 4, and check that the symptom is not detected.

Does the symptom reappear?

YES (DTC is detected)>>GO TO 8

YES (Symptom remains)>>GO TO 6

NO      >> Inspection End.

A

B

C

D

E

F

G

H

I

J

SEC

L

M

N

O

P

# PRE-INSPECTION FOR DIAGNOSTIC

< BASIC INSPECTION >

## PRE-INSPECTION FOR DIAGNOSTIC

### Basic Inspection

INFOID:0000000005272636

#### 1. INSPECTION START

Turn ignition switch OFF.

**NOTE:**

Before starting operation check, open front windows.

>> GO TO 2

#### 2. CHECK SECURITY INDICATOR LAMP

1. Lock doors using keyfob or mechanical key.
2. Check that security indicator lamp illuminates for 30 seconds.

Does the security indicator lamp illuminate?

YES >> GO TO 3

NO >> Perform diagnosis and repair. Refer to [SEC-11, "System Description"](#).

#### 3. CHECK ALARM FUNCTION

1. After 30 seconds, security indicator lamp will start to blink.
2. Open any door before unlocking with keyfob or mechanical key, or open back door or glass hatch without keyfob.

Does the alarm function properly?

YES >> GO TO 4

NO >> Check the following.

- The vehicle security system does not phase in alarm mode. Refer to [SEC-79, "Symptom Table"](#).
- Alarm (horn and headlamps) does not operate. Refer to [SEC-79, "Symptom Table"](#).

#### 4. CHECK ALARM CANCEL OPERATION

Unlock any door using keyfob or mechanical key.

Does the alarm (horn and headlamps) stop?

YES >> Inspection End.

NO >> Check door lock function. Refer to [DLK-12, "DOOR LOCK AND UNLOCK SWITCH : System Description"](#).

# INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

## INSPECTION AND ADJUSTMENT

### ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement

INFOID:000000005272574

Refer to the CONSULT-III Operation Manual-NATS.

#### ECM RE-COMMUNICATING FUNCTION

##### ECM RE-COMMUNICATING FUNCTION : Description

INFOID:000000005272575

Performing following procedure can automatically perform re-communication of ECM and BCM, but only when the ECM has been replaced with a new one (\*1).

\*1: New one means an ECM which has never been energized on-board.

(In this step, initialization procedure by CONSULT-III is not necessary)

###### NOTE:

- When registering new Key IDs or replacing the ECM that is not brand new, refer to CONSULT-III Operation Manual.
- If multiple keys are attached to the key holder, separate them before work.
- Distinguish keys with unregistered key ID from those with registered ID.

##### ECM RE-COMMUNICATING FUNCTION : Special Repair Requirement

INFOID:000000005272576

###### 1 .PERFORM ECM RE-COMMUNICATING FUNCTION

1. Install ECM.
2. Using a registered key (\*2), turn ignition switch to "ON".  
\*2: To perform this step, use the key that has been used before performing ECM replacement.
3. Maintain ignition switch in "ON" position for at least 5 seconds.
4. Turn ignition switch to "OFF".
5. Start engine.

###### Can engine be started?

YES >> Procedure is completed.

NO >> Initialize control unit. Refer to CONSULT-III Operation Manual.

SEC

L

M

N

O

P

# NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)


< FUNCTION DIAGNOSIS >

## FUNCTION DIAGNOSIS

### NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

#### System Diagram

INFOID:0000000005272577



PIIA1121E

#### System Description

INFOID:0000000005272578

#### INPUT/OUTPUT SIGNAL CHART

##### BCM

Switch/Input signal	Input signal to BCM	BCM function	Actuator/Output signal
NATS antenna amp.	Key ID	NATS	• Security indicator lamp • Starter request
ECM	Engine status signal		

#### SYSTEM DESCRIPTION

NATS (Nissan Anti-Theft System) has the following immobilizer functions:

- Engine immobilizer shows high anti-theft performance to prevent engine from starting by other than the owner.
- Only a key with key ID registered in BCM and ECM can start engine, and shows high anti-theft performance to prevent key from being copied or stolen.
- Security indicator always flashes with mechanical key removed condition (key switch: OFF) and ignition knob released condition on LOCK position (ignition knob switch: OFF).
- Therefore, NATS warns outsiders that the vehicle is equipped with the anti-theft system. Refer to [SEC-11, "System Description"](#).
- If system detects malfunction, security indicator illuminates when ignition switch is turned to ON position.
- If the owner requires, ignition key ID or mechanical key ID can be registered for up to 5 keys.
- During trouble diagnosis or when the following parts have been replaced, and if ignition key is added, registration<sup>\*1</sup> is required.

\*1: All keys kept by the owner of the vehicle should be registered with mechanical key.

- ECM
  - BCM
  - Ignition key
  - Remote keyless entry receiver
- NATS trouble diagnosis, system initialization and additional registration of other mechanical key IDs must be carried out using CONSULT-III.

When NATS initialization has been completed, the ID of the inserted mechanical key or mechanical key IDs can be carried out.

# NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

## < FUNCTION DIAGNOSIS >

- Possible symptom of NATS malfunction is "Engine cannot start". Identify the possible causes according to "Work Flow", Refer to [SEC-3, "Work Flow"](#).
- If ECM other than Genuine NISSAN is installed, the engine cannot be started. For ECM replacement procedure, refer to [SEC-7, "ECM RE-COMMUNICATING FUNCTION : Description"](#).

## PRECAUTIONS FOR KEY REGISTRATION

- The key registration is a procedure that erases the current NATS ID once, and then re-registers a new ID. Therefore the registered key is necessary for this procedure. Before starting the registration operation collect all registered Keys from the customer.
- The NATS ID registration is the procedure that registers the ID stored into the transponder (integrated in mechanical key) to BCM.  
The key ID registration is the procedure that registers the ID to the BCM.
- When performing the key system registration only, the engine cannot be started by inserting the key into the key cylinder. When performing the NATS registration only, the engine cannot be started by using the ignition key.

## SECURITY INDICATOR

- Always flashes with ignition key in the OFF position.

## MAINTENANCE INFORMATION


### CAUTION:

**It is necessary to perform NATS ID registration when replacing any of the following part.  
If it's not (or fail to do so), the electrical system may not operate properly.**

- BCM
- ECM
- IPDM E/R
- Ignition key
- NATS antenna amp.
- Combination meter

## Component Parts Location

INFOID:000000005272579



# NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

## < FUNCTION DIAGNOSIS >

1. NATS antenna amp. M21  
(view with cluster lid A removed)
2. BCM M18, M20  
(view with lower instrument panel LH removed)
3. ECM E16
4. IPDM E/R E121
5. Combination meter M24

## Component Description

INFOID:0000000005272580

Item	Function
BCM	Verifies the received signal from the ignition key ID, then informs ECM whether to allow engine start.
Remote keyless entry receiver	Receives lock/unlock signal from the keyfob, and then transmits to the BCM.
A/T shift selector (detention key switch)	Detects whether the shift lever is in park.
NATS antenna amp.	Detects the ignition key presence in the ignition key cylinder.
Security indicator	Indicates the status of the security system.
IPDM E/R	Powers-up the horn and the headlamps in case of a security breach.


# VEHICLE SECURITY SYSTEM

< FUNCTION DIAGNOSIS >

## VEHICLE SECURITY SYSTEM

### System Diagram

INFOID:0000000005272581



### System Description


INFOID:0000000005272582

#### DESCRIPTION

The security system provides an audible and visual alarm when an unauthorized access to the vehicle is detected while the system is in armed phase.

The security system consist of the BCM managing the audible alarm (horn) and the visual alarm (headlamps).

#### OPERATION FLOW



#### Disarmed Phase

When the vehicle is being driven or when doors are open, the theft warning system is set in the disarmed phase on the assumption that the owner is inside or near the vehicle.

#### Pre-Armed Phase And Armed Phase

The vehicle security system turns into the pre-armed phase when ignition switch is in OFF position, all doors are closed and locked (using keyfob, doorlock/unlock switch, driver key cylinder or auto relock function). The system automatically shifts into the armed phase.

#### Condition of Activating The System

When the following condition is performed in armed phase, the system sounds the horns and flashes the headlamps for approximately 50 seconds.

- Any door is opened.

# VEHICLE SECURITY SYSTEM

## < FUNCTION DIAGNOSIS >


### Condition of Deactivating The System

When one of the following operations is performed, the armed phase is canceled.

- Unlock the doors with keyfob.
- Use the mechanical key to unlock the driver door using the door key cylinder.

## Component Parts Location - King Cab

INFOID:000000005272583




- |   |   |  |
|---|---|--|
| 1. IPDM E/R E122, E123, E124                        | 2. BCM M18, M19, M20<br>(view with lower instrument panel LH removed) | 3. Horn E3<br>(behind front combination lamp LH)         |
| 4. Main power window and door lock/unlock switch D7 | 5. Power window and door lock/unlock switch RH D105                   | 6. Front door lock assembly LH (key cylinder switch) D14 |
| 7. Rear door switch upper<br>LH D211<br>RH D312     | 8. Front door switch<br>LH D213<br>RH D314                            | 9. Rear door switch lower<br>LH D212<br>RH D313          |
| 10. Combination meter M24                           |   |  |

# VEHICLE SECURITY SYSTEM

< FUNCTION DIAGNOSIS >

Component Parts Location - Crew Cab

INFOID:0000000005272584



ALKIA13882Z

1. IPDM E/R E122, E123, E124
2. BCM M18, M19, M20  
(view with lower instrument panel LH removed)
3. Horn E3  
(behind front combination lamp LH)
4. Front door lock assembly LH (key cylinder switch) D14
5. Main power window and door lock/unlock switch D7  
Power window and door lock/unlock switch RH D105
6. Front door switch LH B8  
RH B108
7. Rear door switch LH B18  
RH B116
8. Combination meter M24

**SEC**

## Component Description

INFOID:0000000005272585

Item	Function
BCM	Verifies the received signal from ignition key, then informs ECM whether to allow engine start.
Door switch	Provides the BCM with the status of each monitored door.
Security indicator	Indicates the status of the security system.
IPDM E/R	Controls the horn and headlamps operation.
Horn	Sounds when the vehicle security system is triggered.

P

# DIAGNOSIS SYSTEM (BCM)

< FUNCTION DIAGNOSIS >

## DIAGNOSIS SYSTEM (BCM)

### COMMON ITEM

#### COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM)

INFOID:000000005549834

##### APPLICATION ITEM

CONSULT-III performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
WORK SUPPORT	Changes the setting for each system function.
SELF-DIAG RESULTS	Displays the diagnosis results judged by BCM. Refer to <a href="#">SEC-64, "DTC Index"</a> .
CAN DIAG SUPPORT MNTR	Monitors the reception status of CAN communication viewed from BCM.
DATA MONITOR	The BCM input/output signals are displayed.
ACTIVE TEST	The signals used to activate each device are forcibly supplied from BCM.
ECU IDENTIFICATION	The BCM part number is displayed.
CONFIGURATION	<ul style="list-style-type: none"><li>• Enables to read and save the vehicle specification.</li><li>• Enables to write the vehicle specification when replacing BCM.</li></ul>

##### SYSTEM APPLICATION

BCM can perform the following functions for each system.

##### NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

System	Sub system selection item	Diagnosis mode		
		WORK SUPPORT	DATA MONITOR	ACTIVE TEST
BCM	BCM	×		
Door lock	DOOR LOCK	×	×	×
Rear window defogger	REAR DEFOGGER		×	×
Warning chime	BUZZER		×	×
Interior room lamp timer	INT LAMP	×	×	×
Remote keyless entry system	MULTI REMOTE ENT	×	×	×
Exterior lamp	HEAD LAMP	×	×	×
Wiper and washer	WIPER	×	×	×
Turn signal and hazard warning lamps	FLASHER		×	×
Air conditioner	AIR CONDITIONER		×	
Combination switch	COMB SW		×	
Immobilizer	IMMU		×	×
Interior room lamp battery saver	BATTERY SAVER	×	×	×
Vehicle security system	THEFT ALM	×	×	×
RAP (retained accessory power)	RETAINED PWR	×	×	×
Signal buffer system	SIGNAL BUFFER		×	×
TPMS (tire pressure monitoring system)	AIR PRESSURE MONITOR	×	×	×
Panic alarm system	PANIC ALARM			×

##### IMMU

#### IMMU : CONSULT-III Function (BCM - IMMU)

INFOID:000000005549835

##### DATA MONITOR

# DIAGNOSIS SYSTEM (BCM)

## < FUNCTION DIAGNOSIS >

Monitor Item [Unit]	Description
IGN ON SW [ON/OFF]	Indicates condition of ignition switch in ON position.

## ACTIVE TEST

Test Item	Description
THEFT IND	This test is able to check security indicator operation [ON/OFF].

## THEFT ALM

### THEFT ALM : CONSULT-III Function (BCM - THEFT ALM)

INFOID:0000000005549836

## WORK SUPPORT

Test Item	Description
SECURITY ALARM SET	This mode is able to confirm and change security alarm ON-OFF setting.
THEFT ALM TRG	The switch which triggered vehicle security alarm is recorded. This mode is able to confirm and erase the record of vehicle security alarm. The trigger data can be erased by touching "CLEAR" on CONSULT-III screen.

## DATA MONITOR

Monitor Item [Unit]	Description
IGN ON SW [ON/OFF]	Indicates ignition switch (ON) status judged from IGN signal (ignition power supply)
ACC ON SW [ON/OFF]	Indicates ignition switch (ACC) status judged from ACC signal (accessory power supply)
KEYLESS LOCK [ON/OFF]	Indicates lock signal status received from remote keyless entry receiver (integrated in the BCM)
KEYLESS UNLOCK [ON/OFF]	Indicates unlock signal status received from remote keyless entry receiver (integrated in the BCM)
DOOR SW-DR [ON/OFF]	Indicates switch status input from front door switch LH
DOOR SW-AS [ON/OFF]	Indicates switch status input from front door switch RH
DOOR SW-RR [ON/OFF]	Indicates switch status input from rear door switch RH
DOOR SW-RL [ON/OFF]	Indicates switch status input from rear door switch LH
KEY CYL LK-SW [ON/OFF]	Indicates lock switch status from door key cylinder switch
KEY CYL UN-SW [ON/OFF]	Indicates unlock switch status from door key cylinder switch
CDL LOCK SW [ON/OFF]	Indicates lock switch status from door lock and unlock switch
CDL UNLOCK SW [ON/OFF]	Indicates unlock switch status from door lock and unlock switch

## ACTIVE TEST

Test Item	Description
THEFT IND	This test is able to check security indicator lamp operation. The lamp will be turned on when "ON" on CONSULT-III screen is touched.
VEHICLE SECURITY HORN	This test is able to check vehicle security horn operation. The horns will be activated for 0.5 seconds after "ON" on CONSULT-III screen is touched.
HEADLAMP(HI)	This test is able to check vehicle security lamp operation. The headlamps will be activated for 0.5 seconds after "ON" on CONSULT-III screen is touched.

< COMPONENT DIAGNOSIS >

## COMPONENT DIAGNOSIS

### U1000 CAN COMM CIRCUIT

#### Description

INFOID:000000005272589

CAN (Controller Area Network) is a serial communication line for real time applications. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicle is equipped with many electronic control unit, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Signal Chart, refer to [LAN-48, "CAN Communication Signal Chart"](#).

#### DTC Logic

INFOID:000000005272590

#### DTCT DETECTION LOGIC

DTC	CONSULT-III display description	DTC Detection Condition	Possible cause
U1000	CAN COMM CIRCUIT	When BCM cannot communicate CAN communication signal continuously for 2 seconds or more.	In CAN communication system, any item (or items) of the following listed below is malfunctioning. <ul style="list-style-type: none"><li>• Receiving (TCM)</li><li>• Receiving (IPDM E/R)</li><li>• Receiving (ECM)</li><li>• Receiving (METER/M&amp;A)</li></ul>

#### Diagnosis Procedure

INFOID:000000005272591

##### 1. PERFORM SELF DIAGNOSTIC

1. Turn ignition switch ON and wait for 2 seconds or more.
2. Check "Self Diagnostic Result".

Is "CAN COMM CIRCUIT" displayed?

YES >> Refer to [LAN-5, "CAN Communication Control Circuit"](#).

NO >> Refer to [GI-46, "Intermittent Incident"](#).

# U1010 CONTROL UNIT (CAN)

< COMPONENT DIAGNOSIS >

## U1010 CONTROL UNIT (CAN)

### Description

INFOID:0000000005272592

CAN (Controller Area Network) is a serial communication line for real time applications. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicle is equipped with many electronic control unit, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Signal Chart, refer to [LAN-48, "CAN Communication Signal Chart"](#).

### DTC Logic

INFOID:0000000005272593

### DTC DETECTION LOGIC

DTC	CONSULT-III display de-scription	DTC Detection Condition	Possible cause
U1010	CONTROL UNIT (CAN)	When detecting error during the initial diagnosis of CAN controller of BCM.	BCM

### Diagnosis Procedure

INFOID:0000000005272594

#### 1 .REPLACE BCM

When DTC [U1010] is detected, replace BCM.

>> Replace BCM. Refer to [BCS-54, "Removal and Installation"](#).

### Special Repair Requirement

INFOID:0000000005272595

#### 1 .REQUIRED WORK WHEN REPLACING BCM

Initialize BCM. Refer to CONSULT-III Operation Manual.

>> Inspection End.

SEC

L

M

N

O

P

# B2190, P1614 NATS ANTENNA AMP.

< COMPONENT DIAGNOSIS >

## B2190, P1614 NATS ANTENNA AMP.

### Description

INFOID:0000000005272596

Performs ID verification through BCM and NATS antenna amplifier when ignition key is inserted and ignition switch turned ON.

Prohibits the start of engine when an unregistered ID of ignition key is used.

### DTC Logic

INFOID:0000000005272597

### DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2190			
P1614	NATS ANTENNA AMP	<ul style="list-style-type: none"><li>Inactive communication between NATS antenna amp. and BCM.</li><li>Ignition key is malfunctioning.</li></ul>	<ul style="list-style-type: none"><li>Harness or connectors (The NATS antenna amp. circuit is open or shorted)</li><li>Ignition key</li><li>NATS antenna amp.</li><li>BCM</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

- Insert ignition key into the key cylinder.
- Turn ignition switch ON.
- Check "Self diagnostic result" with CONSULT-III.

Is DTC detected?

- YES >> Refer to [SEC-18, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000005272598

Regarding Wiring Diagram information, refer to [SEC-60, "Wiring Diagram - NVIS -"](#).

#### 1. CHECK NATS ANTENNA AMP. INSTALLATION

Check NATS antenna amp. installation. Refer to [SEC-82, "Removal and Installation"](#).

Is the inspection result normal?

- YES >> GO TO 2  
NO >> Reinstall NATS antenna amp. correctly.

#### 2. CHECK NVIS (NATS) IGNITION KEY ID CHIP

Start engine with another registered NATS ignition key.

Does the engine start?

- YES >>
  - Ignition key ID chip is malfunctioning.
  - Replace the ignition key.
  - Perform initialization with CONSULT-III.  
For initialization, refer to "CONSULT-III Operation Manual".

NO >> GO TO 3

#### 3. CHECK POWER SUPPLY FOR NATS ANTENNA AMP.

# B2190, P1614 NATS ANTENNA AMP.

## < COMPONENT DIAGNOSIS >

1. Turn ignition switch ON.
2. Check voltage between NATS antenna amp. connector M21 terminal 1 and ground.


**1 - Ground**

**: Battery voltage**

Is the inspection result normal?

YES >> GO TO 4

NO >> Repair or replace fuse or harness.



## 4.CHECK NATS ANTENNA AMP. GROUND LINE CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect NATS antenna amp. connector.
3. Check continuity between NATS antenna amp. connector M21 terminal 3 and ground.

**3 - Ground**

**: Continuity should exist.**

Is the inspection result normal?


YES >> GO TO 5

NO >> • Repair or replace harness.

**NOTE:**


If harness is OK, replace BCM [BCS-54, "Removal and Installation"](#). Perform initialization with CONSULT-III.

For initialization, refer to "CONSULT-III Operation Manual".



## 5.CHECK NATS ANTENNA AMP. SIGNAL LINE- 1

1. Connect NATS antenna amp. connector.
2. Turn ignition switch ON.
3. Check voltage between NATS antenna amp. connector M21 terminal 2 and ground with analog tester.



Terminals		Position of ignition key cylinder	Voltage (V) (Approx.)
( + )	( - )		
2	Ground	Before inserting ignition key	Battery voltage
		After inserting ignition key	Pointer of tester should move for approx. 30 seconds, then return to battery voltage
		Just after turning ignition switch ON	Pointer of tester should move for approx. 1 second, then return to battery voltage

Is the inspection result normal?

YES >> GO TO 6

NO >> • Repair or replace harness.

**NOTE:**


If harness is OK, replace BCM [BCS-54, "Removal and Installation"](#). Perform initialization with CONSULT-III. For initialization, refer to "CONSULT-III Operation Manual".

# B2190, P1614 NATS ANTENNA AMP.

< COMPONENT DIAGNOSIS >

## 6.CHECK NATS ANTENNA AMP. SIGNAL LINE- 2

Check voltage between NATS antenna amp. connector M21 terminal 4 and ground with analog tester.



Terminals		Position of ignition key cylinder	Voltage (V) (Approx.)
( + )	( - )		
4	Ground	Before inserting ignition key	Battery voltage
		After inserting ignition key	Pointer of tester should move for approx. 30 seconds, then return to battery voltage
		Just after turning ignition switch ON	Pointer of tester should move for approx. 1 second, then return to battery voltage

Is the inspection result normal?

YES >> NATS antenna amp. is malfunctioning.

NO >> • Repair or replace harness.

**NOTE:**

If harness is OK, replace BCM, refer to [BCS-54, "Removal and Installation"](#). Perform initialization with CONSULT-III. For initialization, refer to "CONSULT-III Operation Manual".

# B2191, P1615 DIFFERENCE OF KEY

< COMPONENT DIAGNOSIS >

## B2191, P1615 DIFFERENCE OF KEY

### Description

INFOID:0000000005272599

Performs ID verification through BCM when ignition knob switch is pressed.

Prohibits the release of steering lock or start of engine when an unregistered ID of mechanical key is used.

### DTC Logic

INFOID:0000000005272600

### DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2191	DIFFERENCE OF KEY	The ID verification results between BCM and mechanical key are NG. The registration is necessary.	Mechanical key
P1615			

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Insert mechanical key into the key cylinder.
2. Check "Self diagnostic result" with CONSULT-III.

##### Is DTC detected?

- YES    >> Refer to [SEC-21, "Diagnosis Procedure"](#).  
NO    >> Inspection End.

### Diagnosis Procedure

INFOID:0000000005272601

#### 1. PERFORM INITIALIZATION

Perform initialization with CONSULT-III. Re-register all mechanical keys.

For initialization and registration of mechanical key. Refer to "CONSULT-III Operation Manual".

##### Can the system be initialized and can the engine be started with re-registered mechanical key?

- YES    >> Mechanical key was unregistered.  
NO    >> BCM is malfunctioning.
  - Replace BCM. Refer to [BCS-54, "Removal and Installation"](#).
  - Perform initialization again

A

B

C

D

E

F

G

H

I

J

SEC

L

M

N

O

P

## B2192, P1611 ID DISCORD, IMMU-ECM

< COMPONENT DIAGNOSIS >

### B2192, P1611 ID DISCORD, IMMU-ECM

#### Description

INFOID:0000000005272602

BCM performs the ID verification with ECM that allows the engine to start. BCM starts the communication with ECM if ignition switch is turned ON and starts the engine if the ID is OK. ECM prevents the engine from starting if the ID is not registered.

#### DTC Logic

INFOID:0000000005272603

#### DTC DETECTION LOGIC

##### NOTE:

- If DTC B2192 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [SEC-16, "DTC Logic"](#).
- If DTC B2192 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [SEC-17, "DTC Logic"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2192	ID DISCORD BCM-ECM	The ID verification results between BCM and ECM are NG. The registration is necessary.	<ul style="list-style-type: none"><li>• BCM</li><li>• ECM</li></ul>
P1611			

#### DTC CONFIRMATION PROCEDURE

##### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check "Self diagnostic result" with CONSULT-III.

##### Is DTC detected?

- YES    >> Refer to [SEC-22, "Diagnosis Procedure"](#).  
NO      >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000005272604

##### 1. PERFORM INITIALIZATION

Perform initialization with CONSULT-III. Re-register all mechanical keys.

For initialization and registration of mechanical key. Refer to "CONSULT-III Operation Manual".

##### Can the system be initialized and can the engine be started with re-registered mechanical key?

- YES    >> ID was unregistered.  
NO      >> GO TO 2

##### 2. PEPLACE BCM

1. Replace BCM. Refer to [BCS-54, "Removal and Installation"](#).
2. Perform initialization with CONSULT-III. Re-register all mechanical keys.  
For initialization and registration of mechanical key. Refer to "CONSULT-III Operation Manual".

##### Can the system be initialized and can the engine be started with re-registered mechanical key?

- YES    >> BCM is malfunctioning.  
NO      >> GO TO 3

##### 3. PEPLACE ECM

1. Replace ECM. Refer to Removal and Installation.
2. Perform initialization with CONSULT-III. Re-register all mechanical keys.  
For initialization and registration of mechanical key. Refer to "CONSULT-III Operation Manual".

##### Can the system be initialized and can the engine be started with re-registered mechanical key?

- YES    >> ECM is malfunctioning.  
NO      >> GO TO 4

##### 4. CHECK INTERMITENT INCIDENT

Refer to [GI-46, "Intermittent Incident"](#).

## B2192, P1611 ID DISCORD, IMMU-ECM

< COMPONENT DIAGNOSIS >

---

>> Inspection End.

A

B

C

D

E

F

G

H

I

J

SEC

L

M

N

O

P

# B2193, P1612 CHAIN OF ECM-IMMU

< COMPONENT DIAGNOSIS >

## B2193, P1612 CHAIN OF ECM-IMMU

### Description

INFOID:0000000005272605

BCM performs the ID verification with ECM that allows the engine to start. BCM starts the communication with ECM if ignition switch is turned ON and starts the engine if the ID is OK. ECM prevents the engine from starting if the ID is not registered.

### DTC Logic

INFOID:0000000005272606

#### DTC DETECTION LOGIC

##### NOTE:

- If DTC B2193 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [SEC-16, "DTC Logic"](#).
- If DTC B2193 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [SEC-17, "DTC Logic"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2193			
P1612	CHAIN OF BCM-ECM	Inactive communication between ECM and BCM	<ul style="list-style-type: none"><li>• Harness or connectors (The CAN communication line is open or short)</li><li>• BCM</li><li>• ECM</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check "Self diagnostic result" with CONSULT-III.

##### Is DTC detected?

- YES    >> Refer to [SEC-24, "Diagnosis Procedure"](#).  
NO      >> Inspection End.

### Diagnosis Procedure

INFOID:0000000005272607

#### 1. REPLACE BCM

1. Replace BCM. Refer to [BCS-54, "Removal and Installation"](#).
2. Perform initialization with CONSULT-III.  
For initialization, refer to "CONSULT-III Operation Manual".

##### Does the engine start?

- YES    >> BCM was malfunctioning.  
NO      >> ECM is malfunctioning.
  - Replace ECM.
  - Perform ECM re-communicating function.

# P1610 LOCK MODE

< COMPONENT DIAGNOSIS >

## P1610 LOCK MODE

### Description

INFOID:0000000005272608

When the starting operation is carried more than five times consecutively under the following conditions, NATS will shift to the mode which prevents the engine from being started.

- Unregistered mechanical key is used.
- BCM or ECM's malfunctioning.

### DTC Logic

INFOID:0000000005272609

#### DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1610	LOCK MODE	When the starting operation is carried out five or more times consecutively under the following conditions. <ul style="list-style-type: none"><li>• Unregistered mechanical key</li><li>• BCM or ECM's malfunctioning.</li></ul>	—

#### DTC CONFIRMATION PROCEDURE

##### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check "Self diagnostic result" with CONSULT-III.

###### Is DTC detected?

YES    >> Refer to [SEC-25, "Diagnosis Procedure"](#).

NO    >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000005272610

##### 1. CHECK ENGINE START FUNCTION

1. Perform the check for DTC except DTC P1610.
2. Use CONSULT-III to erase DTC after fixing.
3. Check that engine can start with registered mechanical key.

###### Does the engine start?

YES    >> Inspection End.

NO    >> GO TO 2

##### 2. CHECK INTERMITTENT INCIDENT

Refer to [GI-46, "Intermittent Incident"](#).

>> Inspection End.

SEC

L

M

N

O

P

# POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

## POWER SUPPLY AND GROUND CIRCUIT

### Diagnosis Procedure

INFOID:000000005549837

Regarding Wiring Diagram information, refer to [BCS-46, "Wiring Diagram"](#).

#### 1. CHECK FUSES AND FUSIBLE LINK

Check that the following fuses and fusible link are not blown.

Terminal No.	Signal name	Fuses and fusible link No.
57	Battery power supply	18 (10A)
70		G (50A)
11	Ignition ACC or ON	4 (10A)
38	Ignition ON or START	1 (10A)

Is the fuse blown?


YES >> Replace the blown fuse or fusible link after repairing the affected circuit.

NO >> GO TO 2

#### 2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM.
3. Check voltage between BCM harness connector and ground.

Connector	Terminals		Power source	Condition	Voltage (V) (Approx.)
	(+)	(-)			
M18	11	Ground	ACC power supply	Ignition switch ACC or ON	Battery voltage
	38	Ground	Ignition power supply	Ignition switch ON or START	Battery voltage
M20	57	Ground	Battery power supply	Ignition switch OFF	Battery voltage
	70	Ground	Battery power supply	Ignition switch OFF	Battery voltage



Is the measurement value normal?

YES >> GO TO 3

NO >> Repair or replace harness.

#### 3. CHECK GROUND CIRCUIT

## POWER SUPPLY AND GROUND CIRCUIT


## < COMPONENT DIAGNOSIS >

Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M20	67		Yes

## Does continuity exist?

YES >> Inspection End.  
NO >> Repair or replace harness.



LIIA0915E

A  
B  
C  
D

G H I J

SEC

L

M

N

8

P

# KEY CYLINDER SWITCH

< COMPONENT DIAGNOSIS >

## KEY CYLINDER SWITCH DRIVER SIDE

### DRIVER SIDE : Description

INFOID:000000005272612

The main power window and door lock/unlock switch detects condition of the door key cylinder switch and transmits to BCM as the LOCK or UNLOCK signal.

### DRIVER SIDE : Component Function Check

INFOID:000000005272613

#### 1. CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL

Check "KEY CYL LK-SW" AND "KEY CYL UN-SW" in DATA MONITOR mode for "POWER DOOR LOCK SYSTEM" with CONSULT-III.

Monitor item	Condition	
KEY CYL LK-SW	Lock	: ON
	Neutral / Unlock	: OFF
KEY CYL UN-SW	Unlock	: ON
	Neutral / Lock	: OFF

Is the inspection result normal?

YES >> Key cylinder switch is OK.

NO >> Refer to [SEC-28, "DRIVER SIDE : Diagnosis Procedure".](#)

### DRIVER SIDE : Diagnosis Procedure

INFOID:000000005272614

Regarding Wiring Diagram information, refer to [SEC-43, "Wiring Diagram - VEHICLE SECURITY SYSTEM \(King Cab\) -"](#) or [SEC-52, "Wiring Diagram - VEHICLE SECURITY SYSTEM \(Crew Cab\) -"](#).

#### 1. CHECK DOOR KEY CYLINDER SWITCH LH

With CONSULT-III

Check front door lock assembly LH (key cylinder switch) ("KEY CYL LK-SW") and ("KEY CYL UN-SW") in DATA MONITOR mode in CONSULT-III. Refer to [DLK-20, "DOOR LOCK : CONSULT-III Function \(BCM - DOOR LOCK\)".](#)

- When key inserted in front key cylinder is turned to LOCK:

**KEY CYL LK-SW : ON**


- When key inserted in front key cylinder is turned to UNLOCK:

**KEY CYL UN-SW : ON**

Without CONSULT-III

1. Turn ignition switch OFF.
2. Check voltage between BCM connector M18 terminals 7, 8 and ground.

Connector	Terminals		Condition	Voltage (V) (Approx.)
	(+)	(-)		



# KEY CYLINDER SWITCH

## < COMPONENT DIAGNOSIS >

M18	7	Ground	Neutral/Lock	5
			Unlock	0
	8	Ground	Neutral/Unlock	5
			Lock	0

Is the inspection result normal?

- YES >> Front door lock assembly LH (key cylinder switch) signal is OK.  
NO >> GO TO 2.


## 2.CHECK FRONT DOOR LOCK ASSEMBLY LH (KEY CYLINDER SWITCH)

1. Turn ignition switch OFF.
2. Disconnect front door lock assembly LH (key cylinder switch).
3. Check continuity between front door lock assembly LH (key cylinder switch) connector D14 terminals 3, 4 and 5.

Terminals	Condition	Continuity
4 – 5	Key is turned to LOCK.	Yes
	Key is in N position or turned to UNLOCK	No
3 – 4	Key is turned to UNLOCK.	Yes
	Key is in N position or turned to LOCK	No

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Replace front door lock assembly LH (key cylinder switch). Refer to [DLK-135, "Removal and Installation"](#).



## 3.CHECK FRONT DOOR LOCK ASSEMBLY LH HARNESS

1. Disconnect BCM.
2. Check continuity between BCM connector M18 terminals 7, 8 and front door lock assembly LH connector D14 terminals 3, 5.


**7 - 3 : Continuity should exist.**

**8 - 5 : Continuity should exist.**

3. Check continuity between BCM connector M18 terminals 7, 8 and ground.

**7 - Ground : Continuity should not exist.**

**8 - Ground : Continuity should not exist.**



Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Repair or replace harness.


## 4.CHECK FRONT DOOR LOCK ASSEMBLY LH GROUND

Check continuity between front door lock assembly LH connector D14 terminal 4 and ground.

**4 - Ground : Continuity should exist.**

Is the inspection result normal?

- YES >> GO TO 5.  
NO >> Repair or replace harness.



# KEY CYLINDER SWITCH

< COMPONENT DIAGNOSIS >

## 5. CHECK BCM OUTPUT VOLTAGE

1. Connect BCM.
2. Check voltage between BCM connector M18 terminals 7, 8 and ground.


**7 - Ground** : Approx. 5V

**8 - Ground** : Approx. 5V

Is the inspection result normal?

YES >> Check condition of the harness and connector.

NO >> Replace BCM. Refer to [BCS-54, "Removal and Installation".](#)



# HORN FUNCTION

< COMPONENT DIAGNOSIS >

## HORN FUNCTION

### Symptom Table

INFOID:0000000005272615

#### HAZARD AND HORN REMINDER FUNCTION MALFUNCTION

##### NOTE:

- Before performing the diagnosis in the following table, check "Work flow". Refer to [SEC-3, "Work Flow"](#).
- If the following symptoms" are detected, check systems shown in the "Diagnosis/service procedure" column in this order.

##### Conditions of Vehicle (Operating Conditions)

- "ANSWER BACK FUNCTION" is ON when setting on CONSULT-III.
- Ignition switch is in OFF position.
- All doors are closed.

Symptom	Diagnosis/service procedure	Reference page
Hazard reminder does not operate by keyfob. (Horn reminder operate.)	1. Check "HAZARD ANSWER BACK" setting in "WORK SUPPORT".	<a href="#">DLK-21</a>
	2. Check hazard function.	<a href="#">EXL-72</a>
	3. Check keyfob battery inspection.	<a href="#">DLK-51</a>
Horn reminder does not operate by keyfob. (Hazard reminder operate.)	1. Check "HORN WITH KEYLESS LOCK" setting in "WORK SUPPORT".	<a href="#">DLK-21</a>
	2. Check horn function.	<a href="#">HRN-3</a>
	3. Check Intermittent Incident.	<a href="#">GI-46</a>

A

B

C

D

E

F

G

H

I

J

SEC

L

M

N

O

P

# VEHICLE SECURITY INDICATOR

< COMPONENT DIAGNOSIS >

## VEHICLE SECURITY INDICATOR

### Description

INFOID:0000000005272616

- Vehicle security indicator is built in combination meter.
- NATS (Nissan Anti-Theft System) and vehicle security system conditions are indicated by blink or illumination of vehicle security indicator.

### Component Function Check

INFOID:0000000005272617

#### 1.CHECK FUNCTION

- Perform "THEFT IND" in the "Active Test" mode with CONSULT-III.
- Check vehicle security indicator operation.

Test item		Description	
THEFT IND	ON	Vehicle security indicator	ON
	OFF		OFF

Is the inspection result normal?

- YES >> Inspection End.  
NO >> Refer to [SEC-32, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000005272618

Regarding Wiring Diagram information, refer to [SEC-43, "Wiring Diagram - VEHICLE SECURITY SYSTEM \(King Cab\) -"](#) or [SEC-52, "Wiring Diagram - VEHICLE SECURITY SYSTEM \(Crew Cab\) -"](#).

#### 1.SECURITY INDICATOR LAMP ACTIVE TEST


With CONSULT-III

Check "THEFT IND" in "ACTIVE TEST" mode with CONSULT-III.

Without CONSULT-III

- Disconnect BCM.
- Check voltage between BCM harness connector M18 terminal 23 and ground.

Connector	Terminals		Condition	Voltage (V) (Approx.)
	(+)	(-)		
M18	23	Ground	ON	0
			OFF	Battery voltage



Is the inspection result normal?

- YES >> Security indicator lamp is OK.  
NO >> GO TO 2

#### 2.SECURITY INDICATOR LAMP CHECK

Check security indicator lamp condition.

Is the inspection result normal?

- YES >> GO TO 3  
NO >> Replace security indicator lamp.

#### 3.CHECK HARNESS CONTINUITY

- Turn ignition switch OFF.
- Disconnect BCM and security indicator lamp connector.

# VEHICLE SECURITY INDICATOR

## < COMPONENT DIAGNOSIS >

3. Check continuity between BCM connector M18 (A) terminal 23 and combination meter connector M24 (B) terminal 39.

**23 - 39**

: Continuity should exist.

4. Check continuity between BCM connector M18 (A) terminal 23 and ground.

**23 - Ground**


: Continuity should not exist.

Is the inspection result normal?

YES >> Check the following:

- 10A fuse [No. 19, located in fuse block (J/B)]
- Harness for open or short between security indicator lamp and fuse

NO >> Repair or replace harness.



## BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

# ECU DIAGNOSIS

## BCM (BODY CONTROL MODULE)

### Reference Value

INFOID:0000000005549838

### VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Condition	Value/Status
IGN ON SW	Ignition switch OFF or ACC	OFF
	Ignition switch ON	ON
KEY ON SW	Mechanical key is removed from key cylinder	OFF
	Mechanical key is inserted to key cylinder	ON
CDL LOCK SW	Door lock/unlock switch does not operate	OFF
	Press door lock/unlock switch to the lock side	ON
CDL UNLOCK SW	Door lock/unlock switch does not operate	OFF
	Press door lock/unlock switch to the unlock side	ON
DOOR SW-DR	Driver's door closed	OFF
	Driver's door opened	ON
DOOR SW-AS	Passenger door closed	OFF
	Passenger door opened	ON
DOOR SW-RR	Rear RH door closed	OFF
	Rear RH door opened	ON
DOOR SW-RL	Rear LH door closed	OFF
	Rear LH door opened	ON
KEY CYL LK-SW	Other than driver door key cylinder LOCK position	OFF
	Driver door key cylinder LOCK position	ON
KEY CYL UN-SW	Other than driver door key cylinder UNLOCK position	OFF
	Driver door key cylinder UNLOCK position	ON
KEYLESS LOCK	"LOCK" button of key fob is not pressed	OFF
	"LOCK" button of key fob is pressed	ON
KEYLESS UNLOCK	"UNLOCK" button of key fob is not pressed	OFF
	"UNLOCK" button of key fob is pressed	ON
ACC ON SW	Ignition switch OFF	OFF
	Ignition switch ACC or ON	ON
REAR DEF SW	Rear window defogger switch OFF	OFF
	Rear window defogger switch ON	ON
LIGHT SW 1ST	Lighting switch OFF	OFF
	Lighting switch 1ST	ON
BUCKLE SW	The seat belt (driver side) is unfastened. [Seat belt switch (driver side) OFF]	OFF
	The seat belt (driver side) is fastened. [Seat belt switch (driver side) ON]	ON
KEYLESS PANIC	PANIC button of key fob is not pressed	OFF
	PANIC button of key fob is pressed	ON

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

Monitor Item	Condition	Value/Status	
RKE LCK-UNLCK	LOCK/UNLOCK button of key fob is not pressed and held simultaneously	OFF	A
	LOCK/UNLOCK button of key fob is pressed and held simultaneously	ON	B
RKE KEEP UNLK	UNLOCK button of key fob is not pressed	OFF	C
	UNLOCK button of key fob is pressed and held	ON	
HI BEAM SW	Lighting switch OFF	OFF	D
	Lighting switch HI	ON	
HEAD LAMP SW 1	Lighting switch OFF	OFF	E
	Lighting switch 2ND	ON	
HEAD LAMP SW 2	Lighting switch OFF	OFF	F
	Lighting switch 2ND	ON	
AUTO LIGHT SW	Lighting switch OFF	OFF	G
	Lighting switch AUTO	ON	
PASSING SW	Other than lighting switch PASS	OFF	H
	Lighting switch PASS	ON	
FR FOG SW	Front fog lamp switch OFF	OFF	J
	Front fog lamp switch ON	ON	
TURN SIGNAL R	Turn signal switch OFF	OFF	L
	Turn signal switch RH	ON	
TURN SIGNAL L	Turn signal switch OFF	OFF	M
	Turn signal switch LH	ON	
CARGO LAMP SW	Cargo lamp switch OFF	OFF	N
	Cargo lamp switch ON	ON	
OPTICAL SENSOR	Bright outside vehicle	5V	O
	Dark outside vehicle	0V	
IGN SW CAN	Ignition switch OFF or ACC	OFF	P
	Ignition switch ON	ON	
FR WIPER HI	Front wiper switch OFF	OFF	
	Front wiper switch HI	ON	
FR WIPER LOW	Front wiper switch OFF	OFF	
	Front wiper switch LO	ON	
FR WIPER INT	Front wiper switch OFF	OFF	
	Front wiper switch INT	ON	
FR WASHER SW	Front washer switch OFF	OFF	
	Front washer switch ON	ON	
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	1 - 7	
FR WIPER STOP	Any position other than front wiper stop position	OFF	
	Front wiper stop position	ON	
VEHICLE SPEED	While driving	Equivalent to speedometer reading	
HAZARD SW	Hazard switch OFF	OFF	
	Hazard switch ON	ON	
BRAKE SW	Brake pedal is not depressed	OFF	
	Brake pedal is depressed	ON	

## BCM (BODY CONTROL MODULE)

### < ECU DIAGNOSIS >


Monitor Item	Condition	Value/Status
FAN ON SIG	Blower fan motor switch OFF	OFF
	Blower fan motor switch ON (other than OFF)	ON
AIR COND SW	Compressor ON is not requested from auto amp. (A/C indicator OFF, blower fan motor switch OFF or etc.)	OFF
	Compressor ON is requested from auto amp. (A/C indicator ON and blower fan motor switch ON).	ON
OIL PRESS SW	• Ignition switch OFF or ACC • Engine running	OFF
	Ignition switch ON	ON
AIR PRESS FL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front LH tire
AIR PRESS FR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front RH tire
AIR PRESS RR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear RH tire
AIR PRESS RL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear LH tire
ID REGST FL1	ID of front LH tire transmitter is registered	DONE
	ID of front LH tire transmitter is not registered	YET
ID REGST FR1	ID of front RH tire transmitter is registered	DONE
	ID of front RH tire transmitter is not registered	YET
ID REGST RR1	ID of rear RH tire transmitter is registered	DONE
	ID of rear RH tire transmitter is not registered	YET
ID REGST RL1	ID of rear LH tire transmitter is registered	DONE
	ID of rear LH tire transmitter is not registered	YET
WARNING LAMP	Tire pressure indicator OFF	OFF
	Tire pressure indicator ON	ON
BUZZER	Tire pressure warning alarm is not sounding	OFF
	Tire pressure warning alarm is sounding	ON

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Terminal Layout

INFOID:000000005549839



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
**SEC**  
L  
M  
N  
O  
P





Physical Values

LIIIA2443E

INFOID:000000005549840




# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

Terminal	Wire color	Item	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
1	BR	Ignition keyhole illumination	Output	OFF	Door is locked (SW OFF)	Battery voltage
					Door is unlocked (SW ON)	0V
2	P	Combination switch input 5	Input	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5291E
3	SB	Combination switch input 4	Input	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5292E
4	V	Combination switch input 3	Input	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5291E
5	L	Combination switch input 2	Input	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5292E
6	R	Combination switch input 1				
7	GR	Front door lock assembly LH (key cylinder switch) unlock	Input	OFF	ON (open, 2nd turn)	Momentary 1.5V
8	SB	Front door lock assembly LH (key cylinder switch) lock	Input		OFF (closed)	0V
9	Y	Rear window defogger switch	Input	ON	On (open)	Momentary 1.5V
					OFF (closed)	0V
11	G/B	Ignition switch (ACC or ON)	Input	ACC or ON	Rear window defogger switch ON	0V
					Rear window defogger switch OFF	5V
12	LG	Front door switch RH (All)	Input	OFF	ON (open)	0V
12		Rear door switch upper RH (King Cab)			OFF (closed)	Battery voltage
		Rear door switch lower RH (King Cab)				

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Terminal	Wire color	Item	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
13	L	Rear door switch RH (Crew Cab)	Input	OFF	ON (open)	0V
					OFF (closed)	Battery voltage
15	W	Tire pressure warning check connector	Input	OFF	—	5V
18	BR	Remote keyless entry receiver (Ground)	Output	OFF	—	0V
19	V	Remote keyless entry receiver (power supply)	Output	OFF	Ignition switch OFF	 LTIA1893E
20	G	Remote keyless entry receiver signal (Signal)	Input	OFF	Stand-by (keyfob buttons released)	 LTIA1894E
					When remote keyless entry receiver receives signal from keyfob (keyfob buttons pressed)	 LTIA1895E
21	GR	NATS antenna amp.	Input	OFF → ON	Ignition switch (OFF → ON)	Just after turning ignition switch ON: Pointer of tester should move.
23	G	Security indicator lamp	Output	OFF	Goes OFF → illuminates (Every 2.4 seconds)	Battery voltage → 0V
25	BR	NATS antenna amp.	Input	OFF → ON	Ignition switch (OFF → ON)	Just after turning ignition switch ON: Pointer of tester should move.
27	W	Compressor ON signal	Input	ON	A/C switch OFF	5V
					A/C switch ON	0V
28	R	Front blower monitor	Input	ON	Front blower motor OFF	Battery voltage
					Front blower motor ON	0V
29	G	Hazard switch	Input	OFF	ON	0V
					OFF	5V
31	GR	Cargo lamp switch	Input	OFF	ON	0V
					OFF	Battery voltage

A

B

C

D

E

F

G

H

I

J

**SEC**

L

M


N

O

P





# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

Terminal	Wire color	Item	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
32	O	Combination switch output 5	Output	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5291E
33	GR	Combination switch output 4	Output	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5292E
34	G	Combination switch output 3	Output	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5291E
35	BR	Combination switch output 2	Output	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5292E
36	LG	Combination switch output 1				
37	B	Key switch	Input	OFF	Key inserted	Battery voltage
					Key removed	0V
38	W/R	Ignition switch (ON)	Input	ON	—	Battery voltage
39	L	CAN-H	—	—	—	—
40	P	CAN-L	—	—	—	—
45	V	Lock switch	Input	OFF	ON (lock)	0V
					OFF	Battery voltage
46	LG	Unlock switch	Input	OFF	ON (unlock)	0V
					OFF	Battery voltage
47	GR	Front door switch LH (All)	Input	OFF	ON (open)	0V
		Rear door switch upper LH (King Cab)			Battery voltage	
		Rear door switch lower LH (King Cab)				
48	P	Rear door switch LH (Crew Cab)	Input	OFF	ON (open)	0V
					OFF (closed)	Battery voltage
50	P	Cargo lamp	Output	OFF	Any door open (ON)	0V
					All doors closed (OFF)	Battery voltage

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Terminal	Wire color	Item	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
51	O	Trailer turn signal (right)	Output	ON	Turn right ON	 SKIA3009J
52	LG	Trailer turn signal (left)	Output	ON	Turn left ON	 SKIA3009J
56	R/Y	Battery saver output	Output	OFF	30 minutes after ignition switch is turned OFF	0V
				ON	—	Battery voltage
57	R/Y	Battery power supply	Input	—	—	Battery voltage
58	W	Optical sensor	Input	ON	When optical sensor is illuminated	3.1V or more
					When optical sensor is not illuminated	0.6V or less
59	GR	Front door lock assembly LH (unlock)	Output	OFF	OFF (neutral)	0V
					ON (unlock)	Battery voltage
60	LG	Turn signal (left)	Output	ON	Turn left ON	 SKIA3009J
61	G	Turn signal (right)	Output	ON	Turn right ON	 SKIA3009J
63	BR	Interior room/map lamp	Output	OFF	Any door switch	ON (open)
					OFF (closed)	0V Battery voltage
65	V	All door lock actuators (lock)	Output	OFF	OFF (neutral)	0V
					ON (lock)	Battery voltage
66	L	Front door lock actuator RH, rear door lock actuators LH/RH (unlock)	Output	OFF	OFF (neutral)	0V
					ON (unlock)	Battery voltage
67	B	Ground	Input	ON	—	0V

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
  
SEC  
L  
M  
N  
O  
P

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

Terminal	Wire color	Item	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
68 <sup>1</sup>	O	Power window power supply (RAP)	Output	—	Ignition switch ON	Battery voltage
					Within 45 seconds after ignition switch OFF	Battery voltage
					More than 45 seconds after ignition switch OFF	0V
					When front door LH or RH is open or power window timer operates	0V
68 <sup>2</sup>	SB	Power window power supply (RAP)	Output	—	Ignition switch ON	Battery voltage
					Within 45 seconds after ignition switch OFF	Battery voltage
					More than 45 seconds after ignition switch OFF	0V
					When front door LH or RH is open or power window timer operates	0V
69	P	Power window power supply (BAT)	Output	OFF	—	Battery voltage
70	W	Battery power supply	Input	OFF	—	Battery voltage

1: King cab (with power door lock system)


2: Crew cab (with power door lock system)

## **BCM (BODY CONTROL MODULE)**

## < ECU DIAGNOSIS >

## Wiring Diagram - VEHICLE SECURITY SYSTEM (King Cab) -


INFOID:000000005272622



ABKWA0638GB

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >



ABKWA0639GB

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

## VEHICLE SECURITY SYSTEM CONNECTORS - KING CAB

Connector No.	M3	
Connector Name	FUSE BLOCK (J/B)	
Connector Color	WHITE	
		
Terminal No.	Color of Wire	Signal Name
4N	R/Y	-

Connector No.	M4	
Connector Name	FUSE BLOCK (J/B)	
Connector Color	WHITE	
		
Terminal No.	Color of Wire	Signal Name
4P	GR	-
8P	RY	-

Connector No.	M6	
Connector Name	WIRE TO WIRE	
Connector Color	WHITE	
		
Terminal No.	Color of Wire	Signal Name
6	W	-

Connector No.	M16	
Connector Name	WIRE TO WIRE	
Connector Color	WHITE	
		
Terminal No.	Color of Wire	Signal Name
8	LG	-


  

Connector No.	M9	
Connector Name	WIRE TO WIRE	
Connector Color	WHITE	
		
Terminal No.	Color of Wire	Signal Name
8	LG	-

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >


Connector No.	M18	Terminal No.	Color of Wire	Signal Name
Connector Name	BCM (BODY CONTROL MODULE)			KEY CYLINDER UNLOCK SW
Connector Color	WHITE	7	GR	



Connector No.	M19	Terminal No.	Color of Wire	Signal Name
Connector Name	BCM (BODY CONTROL MODULE)			KEY CYLINDER LOCK SW
Connector Color	WHITE	8	SB	




Connector No.	M40	Terminal No.	Color of Wire	Signal Name
Connector Name	WIRE TO WIRE			CDL LOCK SW
Connector Color	WHITE	45	V	




Terminal No.	Color of Wire	Signal Name
61J	GR	-

Connector No.	M20	Terminal No.	Color of Wire	Signal Name
Connector Name	BCM (BODY CONTROL MODULE)			COMBINATION METER
Connector Color	BLACK	39	L	CAN-H



Connector No.	M24	Terminal No.	Color of Wire	Signal Name
Connector Name	COMBINATION METER			BATTERY
Connector Color	WHITE	39	R/Y	




Terminal No.	Color of Wire	Signal Name
57	R/Y	BAT(FUSE)
67	B	GND (POWER)
70	W	BAT (F/L)

ABKIA0532GB


# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Connector No.	M74
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	M75
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
12	B	-

Terminal No.	Color of Wire	Signal Name
12	B	-
1	P	-

Terminal No.	Color of Wire	Signal Name
10	P	-
11	L	-




Terminal No.	Color of Wire	Signal Name
10	P	-
11	L	-

Terminal No.	Color of Wire	Signal Name
12	B	-
1	P	-



Terminal No.	Color of Wire	Signal Name
10	P	-
11	L	-

Connector No.	E6
Connector Name	HORN
Connector Color	BLACK



SEC








J — I G F M Z O P

A B C D M T

ABKIA1857GB

# BCM (BODY CONTROL MODULE)

**< ECU DIAGNOSIS >**


<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>E122</td></tr> <tr><td>Connector Name</td><td>IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)</td></tr> <tr><td>Connector Color</td><td>WHITE</td></tr> </table>  	Connector No.	E122	Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	Connector Color	WHITE	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>E123</td></tr> <tr><td>Connector Name</td><td>IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)</td></tr> <tr><td>Connector Color</td><td>BROWN</td></tr> </table>  	Connector No.	E123	Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	Connector Color	BROWN	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>38</td><td>B</td><td>GND (SIGNAL)</td></tr> <tr><td>39</td><td>L</td><td>CAN-H</td></tr> <tr><td>40</td><td>P</td><td>CAN-L</td></tr> <tr><td>45</td><td>LG</td><td>ANTI THEFT HORN</td></tr> </table>	Terminal No.	Color of Wire	Signal Name	38	B	GND (SIGNAL)	39	L	CAN-H	40	P	CAN-L	45	LG	ANTI THEFT HORN	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>52</td><td>P</td><td>H/LAMP LO LH</td></tr> <tr><td>54</td><td>R</td><td>H/LAMP LO RH</td></tr> <tr><td>55</td><td>G</td><td>H/LAMP HI LH</td></tr> <tr><td>56</td><td>L</td><td>H/LAMP HI RH</td></tr> </table>	Terminal No.	Color of Wire	Signal Name	52	P	H/LAMP LO LH	54	R	H/LAMP LO RH	55	G	H/LAMP HI LH	56	L	H/LAMP HI RH	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>59</td><td>B</td><td>GND (POWER)</td></tr> </table>  	Terminal No.	Color of Wire	Signal Name	59	B	GND (POWER)															
Connector No.	E122																																																																		
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)																																																																		
Connector Color	WHITE																																																																		
Connector No.	E123																																																																		
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)																																																																		
Connector Color	BROWN																																																																		
Terminal No.	Color of Wire	Signal Name																																																																	
38	B	GND (SIGNAL)																																																																	
39	L	CAN-H																																																																	
40	P	CAN-L																																																																	
45	LG	ANTI THEFT HORN																																																																	
Terminal No.	Color of Wire	Signal Name																																																																	
52	P	H/LAMP LO LH																																																																	
54	R	H/LAMP LO RH																																																																	
55	G	H/LAMP HI LH																																																																	
56	L	H/LAMP HI RH																																																																	
Terminal No.	Color of Wire	Signal Name																																																																	
59	B	GND (POWER)																																																																	
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>B16</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Color</td><td>WHITE</td></tr> </table>  	Connector No.	B16	Connector Name	WIRE TO WIRE	Connector Color	WHITE	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>B69</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Color</td><td>WHITE</td></tr> </table>  	Connector No.	B69	Connector Name	WIRE TO WIRE	Connector Color	WHITE	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>1J</td><td>2J</td><td>3J</td><td>4J</td><td>5J</td><td></td></tr> <tr><td>6J</td><td>7J</td><td>8J</td><td>9J</td><td>10J</td><td></td></tr> </table>	Terminal No.	Color of Wire	Signal Name	1J	2J	3J	4J	5J		6J	7J	8J	9J	10J		<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>1J</td><td>12J</td><td>13J</td><td>14J</td><td>15J</td><td>16J</td><td>17J</td><td>18J</td><td>19J</td><td>20J</td><td>21J</td><td></td></tr> <tr><td>22J</td><td>23J</td><td>24J</td><td>25J</td><td>26J</td><td>27J</td><td>28J</td><td>29J</td><td>30J</td><td></td><td></td><td></td></tr> </table>	Terminal No.	Color of Wire	Signal Name	1J	12J	13J	14J	15J	16J	17J	18J	19J	20J	21J		22J	23J	24J	25J	26J	27J	28J	29J	30J				<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>7</td><td>B</td><td>-</td></tr> <tr><td>8</td><td>GR</td><td>-</td></tr> </table>	Terminal No.	Color of Wire	Signal Name	7	B	-	8	GR	-
Connector No.	B16																																																																		
Connector Name	WIRE TO WIRE																																																																		
Connector Color	WHITE																																																																		
Connector No.	B69																																																																		
Connector Name	WIRE TO WIRE																																																																		
Connector Color	WHITE																																																																		
Terminal No.	Color of Wire	Signal Name																																																																	
1J	2J	3J	4J	5J																																																															
6J	7J	8J	9J	10J																																																															
Terminal No.	Color of Wire	Signal Name																																																																	
1J	12J	13J	14J	15J	16J	17J	18J	19J	20J	21J																																																									
22J	23J	24J	25J	26J	27J	28J	29J	30J																																																											
Terminal No.	Color of Wire	Signal Name																																																																	
7	B	-																																																																	
8	GR	-																																																																	
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>B107</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Color</td><td>WHITE</td></tr> </table>  	Connector No.	B107	Connector Name	WIRE TO WIRE	Connector Color	WHITE	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>B107</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Color</td><td>WHITE</td></tr> </table>  	Connector No.	B107	Connector Name	WIRE TO WIRE	Connector Color	WHITE	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>3J</td><td>32J</td><td>33J</td><td>34J</td><td>35J</td><td>36J</td><td>37J</td><td>38J</td><td>39J</td><td>40J</td><td>41J</td><td></td></tr> <tr><td>42J</td><td>43J</td><td>44J</td><td>45J</td><td>46J</td><td>47J</td><td>48J</td><td>49J</td><td>50J</td><td></td><td></td><td></td></tr> </table>	Terminal No.	Color of Wire	Signal Name	3J	32J	33J	34J	35J	36J	37J	38J	39J	40J	41J		42J	43J	44J	45J	46J	47J	48J	49J	50J				<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>7J</td><td>72J</td><td>73J</td><td>74J</td><td>75J</td><td></td></tr> <tr><td>76J</td><td>77J</td><td>78J</td><td>79J</td><td>80J</td><td></td></tr> </table>	Terminal No.	Color of Wire	Signal Name	7J	72J	73J	74J	75J		76J	77J	78J	79J	80J		<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>61J</td><td>GR</td><td>-</td></tr> </table>	Terminal No.	Color of Wire	Signal Name	61J	GR	-			
Connector No.	B107																																																																		
Connector Name	WIRE TO WIRE																																																																		
Connector Color	WHITE																																																																		
Connector No.	B107																																																																		
Connector Name	WIRE TO WIRE																																																																		
Connector Color	WHITE																																																																		
Terminal No.	Color of Wire	Signal Name																																																																	
3J	32J	33J	34J	35J	36J	37J	38J	39J	40J	41J																																																									
42J	43J	44J	45J	46J	47J	48J	49J	50J																																																											
Terminal No.	Color of Wire	Signal Name																																																																	
7J	72J	73J	74J	75J																																																															
76J	77J	78J	79J	80J																																																															
Terminal No.	Color of Wire	Signal Name																																																																	
61J	GR	-																																																																	

ABKIA1858GB


# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Connector No.	B162
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	D1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
8	LG	—

Terminal No.	Color of Wire	Signal Name
9	R/W	—
10	SB	—
11	W	—
12	LG	—


Terminal No.	Color of Wire	Signal Name
9	B	—



Connector No.	D7
Connector Name	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	R/W	—
4	B	—
5	SB	—



Terminal No.	Color of Wire	Signal Name
12	B	—



Terminal No.	Color of Wire	Signal Name
3	R/W	—
4	B	—
5	SB	—

SEC

J — I G F M Z O P

A B C D M T

ABKIA1859GB


# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >


Connector No.	D102
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	D105
Connector Name	POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH
Connector Color	WHITE




Connector No.	D211
Connector Name	REAR DOOR SWITCH UPPER LH
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	LG	-
2	W	-
3	B	-

Terminal No.	Color of Wire	Signal Name
4	W	-
5	LG	-


Terminal No.	Color of Wire	Signal Name
1	LG	-
2	B	-




Connector No.	D213
Connector Name	FRONT DOOR SWITCH LH (KING CAB)
Connector Color	WHITE



Connector No.	D212
Connector Name	REAR DOOR SWITCH LOWER LH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
2	LG	-
3	B	-



Terminal No.	Color of Wire	Signal Name
7	B	-
8	LG	-

Terminal No.	Color of Wire	Signal Name
2	LG	-
3	B	-


Terminal No.	Color of Wire	Signal Name
1	LG	-
2	B	-

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
SEC

Connector No.	D302
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	B	-
8	LG	-

Connector No.	D312
Connector Name	REAR DOOR SWITCH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	L	-
2	B	-

Terminal No.	Color of Wire	Signal Name
1	L	-
2	B	-




### **BCM (BODY CONTROL MODULE)**

## < ECU DIAGNOSIS >

Wiring Diagram - VEHICLE SECURITY SYSTEM (Crew Cab) -


INFOID:000000005272623



ABKWA0640GB

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >



ABKWA0641GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P


SEC

# BCM (BODY CONTROL MODULE)


**< ECU DIAGNOSIS >**


---

## VEHICLE SECURITY SYSTEM CONNECTORS - CREW CAB


M3		
Connector No.	M3	
Connector Name	FUSE BLOCK (J/B)	
Connector Color	WHITE	
		
Terminal No.	Color of Wire	Signal Name
4N	R/Y	-

M4		
Connector No.	M4	
Connector Name	FUSE BLOCK (J/B)	
Connector Color	WHITE	
		
Terminal No.	Color of Wire	Signal Name
4P	G/B	-
8P	R/Y	-

M6		
Connector No.	M6	
Connector Name	WIRE TO WIRE	
Connector Color	WHITE	
		
Terminal No.	Color of Wire	Signal Name
6	W	-

M16		
Connector No.	M16	
Connector Name	WIRE TO WIRE	
Connector Color	WHITE	
		
Terminal No.	Color of Wire	Signal Name
7	L	-
8	LG	-

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

A

B

C

D

E

F

SEC

G

H

I

J

Connector No.	M18
Connector Name	BCM(BODY CONTROL MODULE)
Connector Color	WHITE





Terminal No.	Color of Wire	Signal Name
7	GR	KEY CYLINDER UNLOCK SW
8	SB	KEY CYLINDER LOCK SW
11	G/B	ACC SW
12	LG	DOOR SW (AS)
13	L	DOOR SW (RR)
23	G	SECURITY INDICATOR OUTPUT
39	L	CAN-H
40	P	CAN-L
47	GR	DOOR SW (DR)
48	P	DOOR SW (RL)

Connector No.	M19
Connector Name	BCM(BODY CONTROL MODULE)
Connector Color	WHITE





Terminal No.	Color of Wire	Signal Name
41	LG	44
42	GR	45
43	GR	46
44	GR	47
50	LG	48
51	GR	49
52	GR	50
53	GR	51
54	GR	52
55	GR	53


Connector No.	M20
Connector Name	BCM(BODY CONTROL MODULE)
Connector Color	BLACK





Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE





Terminal No.	Color of Wire	Signal Name
45	V	CDL LOCK SW
46	LG	CDL UNLOCK SW
47	GR	DOOR SW (DR)
48	P	DOOR SW (RL)


Terminal No.	Color of Wire	Signal Name
20	GR	58
19	LG	59
18	GR	60
17	LG	61
16	GR	62
15	LG	63
14	GR	64
13	LG	
12	GR	
11	LG	
10	GR	
9	LG	
8	GR	
7	LG	
6	GR	
5	LG	
4	GR	
3	LG	
2	GR	
1	LG	

ABKIA0527GB


# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M74
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
12	B	-
1	-	-



Connector No.	M91
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	LG	-
5	P	-



Terminal No.	Color of Wire	Signal Name
12	B	-
1	-	-



Terminal No.	Color of Wire	Signal Name
6	W	-
1	-	-





Terminal No.	Color of Wire	Signal Name
1	B	-
2	G	-





# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >



Connector No.	E126
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	E122
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN



Connector No.	E122
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
10	P	—	38	B	GND (SIGNAL)
11	L	—	39	L	CAN-H
			40	P	CAN-L
			45	LG	ANTI THEFT HORN

Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
10	P	—	38	B	GND (SIGNAL)
11	L	—	39	L	CAN-H
			40	P	CAN-L
			45	LG	ANTI THEFT HORN

Connector No.	E124
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK



Connector No.	B18
Connector Name	REAR DOOR SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	P	—

Terminal No.	Color of Wire	Signal Name
2	P	—

Connector No.	B8
Connector Name	FRONT DOOR SWITCH LH (CREW CAB)
Connector Color	WHITE



Connector No.	E124
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK



SEC

—

M

Z

O

P

R

A

B

T

G

—

J

L

—

M

Z

O

P

R


A

B

# BCM (BODY CONTROL MODULE)


**< ECU DIAGNOSIS >**

Connector No.	B108
Connector Name	FRONT DOOR SWITCH RH (CREW CAB)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	LG	-

Terminal No.	Color of Wire	Signal Name
2	L	-




Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	LG	-

Terminal No.	Color of Wire	Signal Name
2	L	-



Connector No.	B162
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
60J	P	-
61J	GR	-

Terminal No.	Color of Wire	Signal Name
60J	P	-
61J	GR	-



Terminal No.	Color of Wire	Signal Name
9	B	-




Terminal No.	Color of Wire	Signal Name
1	2	3
2	3	4
3	4	5
4	5	6
5	6	7
6	7	8
7	8	9
8	9	10
9	10	11
10	11	12
11	12	13
12	13	14
13	14	15
14	15	16

# BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS >

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
SEC

Connector No.	D14
Connector Name	FRONT DOOR LOCK ASSEMBLY LH
Connector Color	GRAY




Connector No.	D7
Connector Name	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	R/W	—
4	B	—
5	SB	—


Terminal No.	Color of Wire	Signal Name
10	LG	—
11	W	—
14	B	—

Terminal No.	Color of Wire	Signal Name
12	B	—



Terminal No.	Color of Wire	Signal Name
1	BR	—
2	O	—
3	G	—

Terminal No.	Color of Wire	Signal Name
105	—	POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH
110	—	—
111	—	—



Terminal No.	Color of Wire	Signal Name
4	W	—
5	LG	—



Terminal No.	Color of Wire	Signal Name
1	LG	—
2	W	—
3	B	—


ABKIA1864GB

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Wiring Diagram - NVIS -

INFOID:0000000005272624




ABKWA0642GB

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >


## NVIS CONNECTORS

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4N	R/Y	—

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
8P	R/Y	—
15P	W/R	—

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6	W	—

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
21	GR	IMMOBILIZER ANTENNA SIGNAL (CLOCK)
23	G	SECURITY INDICATOR OUTPUT
25	BR	IMMOBILIZER ANTENNA SIGNAL (RX,TX)
38	W/R	IGN SW
39	L	CAN-H
40	P	CAN-L

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
57	R/Y	BAT (FUSE)
67	B	GND (POWER)
70	W	BAT (FL)

SEC

P

M

Z

O

L

C

F

G

I

J

A

B

D

E

M

N

T

U

V

W

X

Y

Z


# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >


Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R/B	VB (12V)
2	GR	CLOCK
3	B	GND
4	BR	RX,TX




Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6G	R/B	-

Connector No.	E121
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
30	R/B	ECM BAT

Terminal No.	Color of Wire	Signal Name
6	W	-

ABKIA1866GB

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >



ABKIA1867GB

INFOID:0000000005549841

## Fail Safe

### Fail-safe index

BCM performs fail-safe control when any DTC listed below is detected.

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

Display contents of CONSULT	Fail-safe	Cancellation
U1000: CAN COMM CIRCUIT	Inhibit engine cranking	When the BCM re-establishes communication with the other modules.

## DTC Inspection Priority Chart

INFOID:0000000005549842

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	DTC
1	<ul style="list-style-type: none"> <li>• U1000: CAN COMM CIRCUIT</li> </ul>
2	<ul style="list-style-type: none"> <li>• B2190: NATS ANTENNA AMP</li> <li>• B2191: DIFFERENCE OF KEY</li> <li>• B2192: ID DISCORD BCM-ECM</li> <li>• B2193: CHAIN OF BCM-ECM</li> </ul>
3	<ul style="list-style-type: none"> <li>• C1729: VHCL SPEED SIG ERR</li> <li>• C1735: IGNITION SIGNAL</li> </ul>
4	<ul style="list-style-type: none"> <li>• C1704: LOW PRESSURE FL</li> <li>• C1705: LOW PRESSURE FR</li> <li>• C1706: LOW PRESSURE RR</li> <li>• C1707: LOW PRESSURE RL</li> <li>• C1708: [NO DATA] FL</li> <li>• C1709: [NO DATA] FR</li> <li>• C1710: [NO DATA] RR</li> <li>• C1711: [NO DATA] RL</li> <li>• C1712: [CHECKSUM ERR] FL</li> <li>• C1713: [CHECKSUM ERR] FR</li> <li>• C1714: [CHECKSUM ERR] RR</li> <li>• C1715: [CHECKSUM ERR] RL</li> <li>• C1716: [PRESSDATA ERR] FL</li> <li>• C1717: [PRESSDATA ERR] FR</li> <li>• C1718: [PRESSDATA ERR] RR</li> <li>• C1719: [PRESSDATA ERR] RL</li> <li>• C1720: [CODE ERR] FL</li> <li>• C1721: [CODE ERR] FR</li> <li>• C1722: [CODE ERR] RR</li> <li>• C1723: [CODE ERR] RL</li> <li>• C1724: [BATT VOLT LOW] FL</li> <li>• C1725: [BATT VOLT LOW] FR</li> <li>• C1726: [BATT VOLT LOW] RR</li> <li>• C1727: [BATT VOLT LOW] RL</li> </ul>

## DTC Index

INFOID:0000000005549843

### NOTE:

- Details of time display
- CRNT: Displays when there is a malfunction now or after returning to the normal condition until turning ignition switch OFF → ON again.
  - 1 - 39: Displayed if any previous malfunction is present when current condition is normal. It increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. The counter remains at 39 even if the number of cycles exceeds it. It is counted from 1 again when turning ignition switch OFF → ON after returning to the normal condition if the malfunction is detected again.

CONSULT display	Fail-safe	Tire pressure monitor warning lamp ON	Reference page
No DTC is detected. further testing may be required.	—	—	—
U1000: CAN COMM CIRCUIT	—	—	<a href="#">BCS-28</a>

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

CONSULT display	Fail-safe	Tire pressure monitor warning lamp ON	Reference page
B2190: NATS ANTENNA AMP	—	—	<a href="#">SEC-18</a>
B2191: DIFFERENCE OF KEY	—	—	<a href="#">SEC-21</a>
B2192: ID DISCORD BCM-ECM	—	—	<a href="#">SEC-22</a>
B2193: CHAIN OF BCM-ECM	—	—	<a href="#">SEC-24</a>
C1708: [NO DATA] FL	—	—	<a href="#">WT-14</a>
C1709: [NO DATA] FR	—	—	<a href="#">WT-14</a>
C1710: [NO DATA] RR	—	—	<a href="#">WT-14</a>
C1711: [NO DATA] RL	—	—	<a href="#">WT-14</a>
C1712: [CHECKSUM ERR] FL	—	—	<a href="#">WT-16</a>
C1713: [CHECKSUM ERR] FR	—	—	<a href="#">WT-16</a>
C1714: [CHECKSUM ERR] RR	—	—	<a href="#">WT-16</a>
C1715: [CHECKSUM ERR] RL	—	—	<a href="#">WT-16</a>
C1716: [PRESSDATA ERR] FL	—	—	<a href="#">WT-18</a>
C1717: [PRESSDATA ERR] FR	—	—	<a href="#">WT-18</a>
C1718: [PRESSDATA ERR] RR	—	—	<a href="#">WT-18</a>
C1719: [PRESSDATA ERR] RL	—	—	<a href="#">WT-18</a>
C1720: [CODE ERR] FL	—	—	<a href="#">WT-16</a>
C1721: [CODE ERR] FR	—	—	<a href="#">WT-16</a>
C1722: [CODE ERR] RR	—	—	<a href="#">WT-16</a>
C1723: [CODE ERR] RL	—	—	<a href="#">WT-16</a>
C1724: [BATT VOLT LOW] FL	—	—	<a href="#">WT-16</a>
C1725: [BATT VOLT LOW] FR	—	—	<a href="#">WT-16</a>
C1726: [BATT VOLT LOW] RR	—	—	<a href="#">WT-16</a>
C1727: [BATT VOLT LOW] RL	—	—	<a href="#">WT-16</a>
C1729: VHCL SPEED SIG ERR	—	—	<a href="#">WT-19</a>
C1735: IGNITION SIGNAL	—	—	—

A

B

C

D

E

F

G

H

I

J

SEC

L

M

N

O

P

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

## IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

### Reference Value

INFOID:000000005549844

### VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Condition		Value/Status				
MOTOR FAN REQ	Engine idle speed	Changes depending on engine coolant temperature, air conditioner operation status, vehicle speed, etc.	0 - 100 %				
A/C COMP REQ	A/C switch OFF		OFF				
	A/C switch ON		ON				
TAIL&CLR REQ	Lighting switch OFF		OFF				
	Lighting switch 1ST, 2ND, HI or AUTO (Light is illuminated)		ON				
HL LO REQ	Lighting switch OFF		OFF				
	Lighting switch 2ND HI or AUTO (Light is illuminated)		ON				
HL HI REQ	Lighting switch OFF		OFF				
	Lighting switch HI		ON				
FR FOG REQ	Lighting switch 2ND	Front fog lamp switch OFF	OFF				
		Front fog lamp switch ON	ON				
FR WIP REQ	Ignition switch ON	Front wiper switch OFF	STOP				
		Front wiper switch INT	1LOW				
		Front wiper switch LO	LOW				
		Front wiper switch HI	HI				
WIP AUTO STOP	Ignition switch ON	Front wiper stop position	STOP P				
		Any position other than front wiper stop position	ACT P				
WIP PROT	Ignition switch ON	Front wiper operates normally	OFF				
		Front wiper stops at fail-safe operation	BLOCK				
ST RLY REQ	Ignition switch OFF or ACC		OFF				
	Ignition switch START		ON				
IGN RLY	Ignition switch OFF or ACC		OFF				
	Ignition switch ON		ON				
RR DEF REQ	Rear defogger switch OFF		OFF				
	Rear defogger switch ON		ON				
OIL P SW	Ignition switch OFF, ACC or engine running		OPEN				
	Ignition switch ON		CLOSE				
DTRL REQ	Daytime light system requested OFF with CONSULT-III.		OFF				
	Daytime light system requested ON with CONSULT-III.		ON				
THFT HRN REQ	Not operated		OFF				
	<ul style="list-style-type: none"> <li>• Panic alarm is activated</li> <li>• Horn is activated with VEHICLE SECURITY (THEFT WARNING) SYSTEM</li> </ul>		ON				
	<table border="1"> <tr> <td>Not operated</td> <td>OFF</td> </tr> <tr> <td>Door locking with keyfob (horn chirp mode)</td> <td>ON</td> </tr> </table>		Not operated	OFF	Door locking with keyfob (horn chirp mode)	ON	
Not operated	OFF						
Door locking with keyfob (horn chirp mode)	ON						
HORN CHIRP	<table border="1"> <tr> <td>Not operated</td> <td>OFF</td> </tr> <tr> <td>Door locking with keyfob (horn chirp mode)</td> <td>ON</td> </tr> </table>		Not operated	OFF	Door locking with keyfob (horn chirp mode)	ON	
Not operated	OFF						
Door locking with keyfob (horn chirp mode)	ON						


# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

## Terminal Layout

INFOID:0000000005549845

### TERMINAL LAYOUT —TYPE A




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
**SEC**  
L  
M  
N  
O  
P

WKIA5883E

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

TERMINAL LAYOUT —TYPE B



AAMIA0364GB

INFOID:0000000005549846

Physical Values

PHYSICAL VALUES

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS >

Terminal	Wire color	Signal name	Signal input/output	Measuring condition		Reference value (Approx.)
				Ignition switch	Operation or condition	
1	W	Battery power supply	Input	OFF	—	Battery voltage
2	R	Battery power supply	Input	OFF	—	Battery voltage
3	G	ECM relay	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
4	P	ECM relay	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
6	V	Throttle control motor relay	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
7	BR	ECM relay control	Input	—	Ignition switch ON or START	0V
					Ignition switch OFF or ACC	Battery voltage
8	W/R	Fuse 54	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
10	R/B	Fuse 45	Output	ON	Daytime light system active	0V
					Daytime light system inactive	Battery voltage
11	Y	A/C compressor	Output	ON or START	A/C switch ON or defrost A/C switch	Battery voltage
					A/C switch OFF or defrost A/C switch	0V
12	W/G	Ignition switch supplied power	Input	—	OFF or ACC	0V
					ON or START	Battery voltage
13	R	Fuel pump relay	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
14	W/G	Fuse 49	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
15	W/R	Fuse 50 (ABS)	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
16	W/G	Fuse 51	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
17	W/G	Fuse 55	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
19	W	Starter motor	Output	START	—	Battery voltage
20	BR	Cooling fan motor (low)	Output	ON or START	—	Battery voltage
21	GR	Ignition switch supplied power	Input	—	OFF or ACC	0V
					START	Battery voltage
22	G	Battery power supply	Output	OFF	—	Battery voltage
23	LG	Door mirror defogger output signal	Output	—	When rear defogger switch is ON	Battery voltage
					When raker defogger switch is OFF	0V

A

B

C

D

E

F

G

H

I

J

SEC

L

M




N

O

P

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS >

Terminal	Wire color	Signal name	Signal input/output	Measuring condition		Reference value (Approx.)
				Ignition switch	Operation or condition	
24	P	Cooling fan motor (high)	Output	—	Conditions correct for cooling fan operation	Battery voltage
					Conditions not correct for cooling fan operation	0V
27	W	Fuse 38	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
28	R	LH front parking and front side marker lamp	Output	OFF	Lighting switch 1st position	OFF 0V
					ON	Battery voltage
29	G	Trailer tow relay	Output	ON	Lighting switch 1st position	OFF 0V
					ON	Battery voltage
30	R/B	Fuse 53	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
32	GR	Wiper low speed signal	Output	ON or START	Wiper switch	OFF Battery voltage
					LO or INT	0V
35	L	Wiper high speed signal	Output	ON or START	Wiper switch	OFF, LO, INT Battery voltage
					HI	0V
37	Y	Power generation command signal	Output	—	Ignition switch ON	(V)  6.3 V JPMIA0001GB
					40% is set on "Active test," "ALTERNATOR DUTY" of "ENGINE"	(V)  3.8 V JPMIA0002GB
					40% is set on "Active test," "ALTERNATOR DUTY" of "ENGINE"	(V)  1.4 V JPMIA0003GB
38	B	Ground	Input	—	—	0V
39	L	CAN-H	—	ON	—	—
40	P	CAN-L	—	ON	—	—
42	GR	Oil pressure switch	Input	—	Engine running	Battery voltage
					Engine stopped	0V

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

Terminal	Wire color	Signal name	Signal input/output	Measuring condition		Reference value (Approx.)
				Ignition switch	Operation or condition	
43	G	Wiper auto stop signal	Input	ON or START	Wiper switch OFF, LO, INT	Battery voltage
44	R	Daytime light relay control (Canada only)	Input	ON	Daytime light system active	0V
					Daytime light system inactive	Battery voltage
45	LG	Horn relay control	Input	ON	When door locks are operated using keyfob (OFF → ON)*	Battery voltage → 0V
46	V	Fuel pump relay control	Input	—	Ignition switch ON or START	0V
					Ignition switch OFF or ACC	Battery voltage
47	O	Throttle control motor relay control	Input	—	Ignition switch ON or START	0V
					Ignition switch OFF or ACC	Battery voltage
48	R	Starter relay (inhibit switch)	Input	ON or START	Selector lever in "P" or "N"	0V
					Selector lever any other position	Battery voltage
49	GR	Front RH parking and front side marker lamp	Output	OFF	Lighting switch 1st position	0V
						Battery voltage
50	W	Front fog lamp (LH)	Output	ON or START	Lighting switch must be in the 2nd position (LOW beam is ON) and the front fog lamp switch	0V
						Battery voltage
51	V	Front fog lamp (RH)	Output	ON or START	Lighting switch must be in the 2nd position (LOW beam is ON) and the front fog lamp switch	0V
						Battery voltage
52	P	LH low beam head-lamp	Output	—	Lighting switch in 2nd position	Battery voltage
54	R	RH low beam head-lamp	Output	—	Lighting switch in 2nd position	Battery voltage
55	G	LH high beam head-lamp	Output	—	Lighting switch in 2nd position and placed in HIGH or PASS position	Battery voltage
56	L	RH high beam head-lamp	Output	—	Lighting switch in 2nd position and placed in HIGH or PASS position	Battery voltage
57	GR	Parking, license, and tail lamp	Output	ON	Lighting switch 1st position	0V
						Battery voltage
59	B	Ground	Input	—	—	0V
60	GR	Rear window defogger relay	Output	ON or START	Rear defogger switch ON	Battery voltage
					Rear defogger switch OFF	0V
61	R/B	Fuse 32	Output	OFF	—	Battery voltage


\*: When horn reminder is ON

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

## Wiring Diagram


INFOID:000000005549847



ABMWA0542GB

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >



ABMWA0543GB

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

## IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) CONNECTORS


Connector No.	E30	Connector No.	E118
Connector Name	FUSIBLE LINK BOX (BATTERY)	Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	-	Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
3	R	-

Terminal No.	Color of Wire	Signal Name
1	W	F/L USM
2	R	F/L MAIN

Connector No.	E120
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Connector No.	E120
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	BR	ECM RLY CONT
8	W/R	O2 SENSOR
9	-	-
10	R/B	DTRL RLY SUPPLY
11	Y	A/C COMPRESSOR
12	W/G	IGN SW (G)
13	R	FUEL PUMP
14	W/G	A/T ECU IGN SUPPLY
15	W/R	ABS IGN SUPPLY
16	W/G	REVERSE LAMP
17	W/G	INJECTOR
18	-	-
21	GR	IGN SW (ST)
22	G	F/L MOTOR FAN
23	LG	HEATED MIRROR
24	P	MOTOR FAN 2

Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	G	IGN COIL
4	P	ECM
5	-	-
6	V	ETC

ABMIA1428GB


# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

Connector No.	E123
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN




Connector No.	E122
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
37	Y	ALT-C CONT	49	GR	CLEARANCE FRONT RH
38	B	GND (SIGNAL)	50	W	FR FOG LAMP LH
39	L	CAN-H	51	V	FR FOG LAMP RH
40	P	CAN-L	52	P	H/LAMP LO LH
41	-	-	53	-	-
42	GR	OIL PRESSURE SW	54	R	H/LAMP LO RH
43	G	AUTO STOP SW	55	G	H/LAMP HI LH
44	R	DTR/LRY CONT	56	L	H/LAMP HI RH
45	LG	ANT THEFT HORN			
46	V	FUEL PUMP RLY			
47	O	ETC RLY CONT			
48	R	INHIBIT SW			

Connector No.	E121
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
25	-	-	28	R	CLEARANCE FRONT LH
26	-	-	29	G	TRAILER RLY CONT
27	W	T TOW REV LAMP	30	R/B	ECM BAT
28	R	CLEARANCE FRONT LH	31	-	-
29	G	TRAILER RLY CONT	32	GR	FR WIPER LO
30	R/B	ECM BAT	33	-	-
31	-	-	34	-	-
32	GR	FR WIPER LO	35	L	FR WIPER HI
33	-	-	36	-	-



# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

---

Connector No.	E129
Connector Name	FUSIBLE LINK BOX (BATTERY)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W	-
2	R	-

Connector No.	E124
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
57	GR	TAIL LAMP
58	-	-
59	B	GND (POWER)
60	GR	RR DEF
61	R/B	TRAIL RLY SUPPLY
62	-	-

ABMIA1430GB

INFOID:0000000005549848

## Fail Safe

### CAN COMMUNICATION CONTROL

When CAN communication with ECM and BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If No CAN Communication Is Available With ECM

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS >

Control part	Fail-safe in operation
Cooling fan	<ul style="list-style-type: none"> <li>• Turns ON the cooling fan relay when the ignition switch is turned ON</li> <li>• Turns OFF the cooling fan relay when the ignition switch is turned OFF</li> </ul>

If No CAN Communication Is Available With BCM

Control part	Fail-safe in operation
Headlamp	<ul style="list-style-type: none"> <li>• Turns ON the headlamp low relay when the ignition switch is turned ON</li> <li>• Turns OFF the headlamp low relay when the ignition switch is turned OFF</li> <li>• Headlamp (LH/RH) high relays OFF</li> </ul>
• Parking lamps • License plate lamps • Tail lamps	<ul style="list-style-type: none"> <li>• Turns ON the tail lamp relay when the ignition switch is turned ON</li> <li>• Turns OFF the tail lamp relay when the ignition switch is turned OFF</li> </ul>
Front wiper	<ul style="list-style-type: none"> <li>• The status just before activation of fail-safe control is maintained until the ignition switch is turned OFF while the front wiper is operating at LO or HI speed.</li> <li>• The wiper is operated at LO speed until the ignition switch is turned OFF if the fail-safe control is activated while the front wiper is set in the INT mode and the front wiper motor is operating.</li> </ul>
Rear window defogger	Rear window defogger relay OFF
A/C compressor (if equipped)	A/C relay OFF
Front fog lamps (if equipped)	Front fog lamp relay OFF

## IGNITION RELAY MALFUNCTION DETECTION FUNCTION

- IPDM E/R monitors the voltage at the contact circuit and excitation coil circuit of the ignition relay inside it.
- IPDM E/R judges the ignition relay error if the voltage differs between the contact circuit and the excitation coil circuit.
- If the ignition relay cannot turn OFF due to contact seizure, it activates the tail lamp relay for 10 minutes to alert the user to the ignition relay malfunction when the ignition switch is turned OFF.

Ignition switch	Ignition relay	Tail lamp relay
ON	ON	—
OFF	OFF	—

### NOTE:

The tail lamp turns OFF when the ignition switch is turned ON.

SEC

## FRONT WIPER CONTROL

IPDM E/R detects front wiper stop position by a front wiper auto stop signal.

When a front wiper auto stop signal is in the conditions listed below, IPDM E/R stops power supply to wiper after repeating a front wiper 10 second activation and 20 second stop five times.

Ignition switch	Front wiper switch	Auto stop signal
ON	OFF	Front wiper stop position signal cannot be input 10 seconds.
	ON	The signal does not change for 10 seconds.

### NOTE:

This operation status can be confirmed on the IPDM E/R “DATA MONITOR” that displays “Block” for the item “WIP PROT” while the wiper is stopped.

## STARTER MOTOR PROTECTION FUNCTION

IPDM E/R turns OFF the starter control relay to protect the starter motor when the starter control relay remains active for 90 seconds.

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

<ECU DIAGNOSIS>

## DTC Index

INFOID:000000005549849

CONSULT-III display	Fail-safe	TIME <sup>NOTE</sup>	Refer to
No DTC is detected. further testing may be required.	—	—	—
U1000: CAN COMM CIRCUIT	×	CRNT	1 – 39

### NOTE:

The details of TIME display are as follows.

- CRNT: The malfunctions that are detected now
- 1 - 39: The number is indicated when it is normal at present and a malfunction was detected in the past. It increases like 0 → 1 → 2 … 38 → 39 after returning to the normal condition whenever IGN OFF → ON. It is fixed to 39 until the self-diagnosis results are erased if it is over 39. It returns to 0 when a malfunction is detected again in the process.

# VEHICLE SECURITY SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

## SYMPTOM DIAGNOSIS

### VEHICLE SECURITY SYSTEM SYMPTOMS

#### Symptom Table

INFOID:000000005272634

Procedure		Diagnostic procedure	Refer to page
Symptom			
1 Vehicle security system cannot be set by ....	All items	Check door switch (king cab)	<a href="#">DLK-27</a>
		Check door switch (crew cab)	<a href="#">DLK-29</a>
		Replace BCM	<a href="#">BCS-54</a>
	Door lock/unlock switch	Check door lock/unlock switch (king cab)	<a href="#">DLK-32</a>
		Check door lock/unlock switch (crew cab)	<a href="#">DLK-34</a>
	Key cylinder switch	Check key cylinder switch (driver)	<a href="#">SEC-28</a>
	—	Check Intermittent Incident	<a href="#">GI-46</a>
	Security indicator does not turn ON.		<a href="#">SEC-32</a>
			<a href="#">GI-46</a>
2 * Vehicle security system does not sound alarm when ....	Any door is opened.	Check door switch (king cab)	<a href="#">DLK-27</a>
		Check door switch (crew cab)	<a href="#">DLK-34</a>
		—	<a href="#">GI-46</a>
3 Vehicle security alarm does not activate.	Horn alarm	Check horn operation	<a href="#">SEC-31</a>
		Check Intermittent Incident	<a href="#">GI-46</a>
	Headlamp alarm	Check headlamp function	<a href="#">DLK-57</a>
		Check Intermittent Incident	<a href="#">GI-46</a>
4. Vehicle security system cannot be canceled by ....	Key cylinder switch	Check key cylinder switch (driver)	<a href="#">SEC-28</a>
		Check Intermittent Incident	<a href="#">GI-46</a>
	Keyfob	Check RKE function	<a href="#">DLK-49</a>
		Replace BCM	<a href="#">BCS-54</a>

\*: Check the system is in the armed phase.

A

B

C

D

E

F

G

H

I

J

SEC

L

M

N

O

P

# NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS SYMPTOMS

< SYMPTOM DIAGNOSIS >

## NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS SYMPTOMS

### Symptom Table

INFOID:0000000005272635

#### NOTE:

- Before performing the diagnosis in the following table, check “[SEC-3. "Work Flow"](#)”.
- Check that vehicle is under the condition shown in “Conditions of vehicle” before starting diagnosis, and check each symptom.
- If the following symptoms are detected, check systems shown in the “Diagnosis/service procedure” column in this order.

#### CONDITIONS OF VEHICLE (OPERATING CONDITIONS)

- Mechanical key is not inserted into key cylinder.
- Ignition knob switch is not depressed.

Symptom	Diagnosis/service procedure	Reference page
Security indicator does not turn ON or flash.	1. Check vehicle security indicator	<a href="#">SEC-32</a>
	2. Check Intermittent Incident	<a href="#">GI-46</a>

## PRECAUTIONS

< PRECAUTION >

# PRECAUTION

## PRECAUTIONS

### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000005519010

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

A

B

C

D

E

F

G

H

I

J

SEC

L

M

N

O

P

< ON-VEHICLE REPAIR >

## ON-VEHICLE REPAIR

### NATS ANTENNA AMP.

#### Removal and Installation


INFOID:000000005272638

##### NOTE:

- If NATS antenna amp. is not installed correctly, NVIS (NATS) system will not operate properly and "SELF-DIAG RESULTS" on CONSULT-III screen will show "LOCK MODE" or "CHAIN OF IMMU-KEY".
- Initialization is not necessary when only the NATS antenna amp. is replaced with a new one.

#### REMOVAL

1. Disconnect the battery negative terminal. Refer to [PG-84, "Removal and Installation"](#).
2. Remove the lower instrument panel LH. Refer to [IP-10, "Exploded View"](#).
3. Remove the bolt (A), disconnect the electrical connector (1) and remove the NATS antenna amp (2).



AWKIA1481ZZ

#### INSTALLATION

Installation is in the reverse order of removal.

# REMOTE KEYLESS ENTRY RECEIVER

< ON-VEHICLE REPAIR >


## REMOTE KEYLESS ENTRY RECEIVER

### Removal and Installation

INFOID:0000000005272639

#### REMOVAL

1. Remove the front pillar upper finisher (RH). Refer to [INT-17, "Component"](#).
2. Remove the side ventilator grille (RH). Refer to [IP-10, "Exploded View"](#).
3. Remove the upper glove box. Refer to [IP-10, "Exploded View"](#).
4. Remove cluster lid D. Refer to [IP-10, "Exploded View"](#).
5. Remove the bolt (A), disconnect the harness connector (1) and remove the remote keyless entry receiver (2).



#### INSTALLATION

Installation is in the reverse order of removal.

- Perform TPMS ID registration. Refer to [WT-6, "ID Registration Procedure"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J

SEC

L  
M  
N  
O  
P