

SECTION **INL**

INTERIOR LIGHTING SYSTEM

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

CONTENTS

WITH POWER DOOR LOCKS BASIC INSPECTION 3 DIAGNOSIS AND REPAIR WORKFLOW 3 Work Flow 3 SYSTEM DESCRIPTION 6 INTERIOR ROOM LAMP CONTROL SYSTEM 6 System Diagram 6 System Description 6 Component Parts Location 7 Component Description 8 ILLUMINATION CONTROL SYSTEM 9 System Diagram 9 System Description 9 Component Parts Location 10 Component Description 10 DIAGNOSIS SYSTEM (BCM) 11 COMMON ITEM 11 COMMON ITEM : CONSULT Function (BCM - COMMON ITEM) 11 INT LAMP 11 INT LAMP : CONSULT Function (BCM - INT LAMP) 12 BATTERY SAVER 12 BATTERY SAVER : CONSULT Function (BCM - BATTERY SAVER) 12 DTC/CIRCUIT DIAGNOSIS 14 POWER SUPPLY AND GROUND CIRCUIT 14 BCM 14 BCM : Diagnosis Procedure 14	BATTERY SAVER OUTPUT/POWER SUPPLY CIRCUIT 16 Description 16 Component Function Check 16 Diagnosis Procedure 16 INTERIOR ROOM LAMP CONTROL CIRCUIT 18 Description 18 Component Function Check 18 Diagnosis Procedure 18 CARGO LAMP CONTROL CIRCUIT 20 Description 20 Diagnosis Procedure 20 Component Inspection 22 IGNITION KEYHOLE ILLUMINATION CONTROL CIRCUIT 24 Description 24 Component Function Check 24 Diagnosis Procedure 24 ECU DIAGNOSIS INFORMATION 26 BCM (BODY CONTROL MODULE) 26 Reference Value 26 Terminal Layout 29 Physical Values 29 Fail Safe 34 DTC Inspection Priority Chart 34 DTC Index 35 WIRING DIAGRAM 37 INTERIOR ROOM LAMP 37 Wiring Diagram - With Power Door Lock System 37 ILLUMINATION 50 Wiring Diagram 50 SYMPTOM DIAGNOSIS 60
---	---

INL

INTERIOR LIGHTING SYSTEM SYMPTOMS	60	INTERIOR ROOM LAMP	78
Symptom Table	60	Diagnosis Procedure	78
PRECAUTION	61	Component Inspection (Door Switch)	79
PRECAUTIONS	61	CARGO LAMP CONTROL CIRCUIT	80
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER"	61	Description	80
Precaution for Work	61	Diagnosis Procedure	80
PREPARATION	62	Component Inspection	82
PREPARATION	62	ECU DIAGNOSIS INFORMATION	84
Special Service Tool	62	BCM (BODY CONTROL MODULE)	84
REMOVAL AND INSTALLATION	63	Reference Value	84
INTERIOR ROOM LAMP	63	Terminal Layout	87
Removal and Installation	63	Physical Values	87
ILLUMINATION	66	Fail Safe	92
Removal and Installation	66	DTC Inspection Priority Chart	92
SERVICE DATA AND SPECIFICATIONS (SDS)	67	DTC Index	93
BULB SPECIFICATIONS	67	WIRING DIAGRAM	95
Bulb Specifications	67	INTERIOR ROOM LAMP	95
WITHOUT POWER DOOR LOCKS		Wiring Diagram - Without Power Door Lock Sys- tem	95
BASIC INSPECTION	68	ILLUMINATION	104
DIAGNOSIS AND REPAIR WORKFLOW	68	Wiring Diagram	104
Work Flow	68	SYMPTOM DIAGNOSIS	114
SYSTEM DESCRIPTION	71	INTERIOR LIGHTING SYSTEM SYMPTOMS	114
INTERIOR ROOM LAMP	71	Symptom Table	114
System Diagram	71	PRECAUTION	115
System Description	71	PRECAUTIONS	115
Component Parts Location	72	Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER"	115
Component Description	72	Precaution for Work	115
ILLUMINATION CONTROL SYSTEM	74	PREPARATION	116
System Diagram	74	PREPARATION	116
System Description	74	Special Service Tool	116
Component Parts Location	75	REMOVAL AND INSTALLATION	117
Component Description	75	INTERIOR ROOM LAMP	117
DIAGNOSIS SYSTEM (BCM)	76	Removal and Installation	117
COMMON ITEM	76	ILLUMINATION	120
COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)	76	Removal and Installation	120
INT LAMP	76	SERVICE DATA AND SPECIFICATIONS (SDS)	121
INT LAMP : CONSULT Function (BCM - INT LAMP)	77	BULB SPECIFICATIONS	121
DTC/CIRCUIT DIAGNOSIS	78	Bulb Specifications	121

< BASIC INSPECTION >


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000010711420

OVERALL SEQUENCE



A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

AWLIA1837GB

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[WITH POWER DOOR LOCKS]

DETAILED FLOW

1. INTERVIEW FOR MALFUNCTION

Find out what the customer's concerns are.

>> GO TO 2.

2. SYMPTOM CHECK

Verify the symptom from the customer's information.

>> GO TO 3.

3. BASIC INSPECTION

Check the operation of each part. Check that any concerns occur other than those mentioned in the customer interview.

>> GO TO 4.

4. SELF-DIAGNOSIS WITH CONSULT

Perform the self-diagnosis with CONSULT. Check that any DTC is detected.

Is any DTC detected?

YES >> GO TO 5.

NO >> GO TO 6.

5. TROUBLE DIAGNOSIS BY DTC

Perform the trouble diagnosis for the detected DTC. Specify the malfunctioning part.

>> GO TO 9.

6. FAIL-SAFE ACTIVATION CHECK

Determine if the customer's concern is related to fail-safe activation.

Does the fail-safe activate?

YES >> GO TO 7.

NO >> GO TO 8.

7. SYSTEM DIAGNOSIS

Perform the system diagnosis for the system in which the fail-safe activates. Specify the malfunctioning part.

>> GO TO 9.

8. SYMPTOM DIAGNOSIS

Perform the symptom diagnosis. Specify the malfunctioning part.

>> GO TO 9.

9. MALFUNCTION PART REPAIR

Repair or replace the malfunctioning part.

>> GO TO 10.

10. REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT)

Perform the self-diagnosis with CONSULT. Verify that no DTCs are detected. Erase all DTCs detected prior to the repair. Verify that DTC is not detected again.

Is any DTC detected?

YES >> GO TO 5.

DIAGNOSIS AND REPAIR WORKFLOW

[WITH POWER DOOR LOCKS]

< BASIC INSPECTION >

NO >> GO TO 11.

11. REPAIR CHECK (OPERATION CHECK)

Check the operation of each part.

Does it operate normally?

YES >> Inspection End.

NO >> GO TO 3.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

INTERIOR ROOM LAMP CONTROL SYSTEM

< SYSTEM DESCRIPTION >


[WITH POWER DOOR LOCKS]

SYSTEM DESCRIPTION

INTERIOR ROOM LAMP CONTROL SYSTEM

System Diagram

INFOID:0000000010711421



ALLIA1588GB

System Description

INFOID:0000000010711422

OUTLINE

- Front room/map lamp and room lamp 2nd row are controlled by the interior room lamp timer control function of the BCM.
- Cargo lamp is controlled by the cargo lamp control function of the BCM.

The timer control functions of the BCM activate based on inputs from the remote keyless entry receiver, the key cylinder lock/unlock switch, the door switches, the key switch and the power window and door lock/unlock switches.

ROOM LAMP TIMER OPERATION

When the interior room lamp switch is in the DOOR position, the BCM begins timer control (maximum 30 seconds) for interior room lamp ON/OFF when all of the following conditions are met:

- When the front door LH is unlocked [with main power window and door lock/unlock switch, or front door lock assembly LH (key cylinder switch)].
- When a door opens → closes.

Timer control is cancelled under the following conditions:

- When the front door LH is locked [with main power window and door lock/unlock switch, or front door lock assembly LH (key cylinder switch)].
- A door is opened (door switch turns ON).
- The ignition switch is placed the ON position.

Interior lamp operational settings can be changed with the CONSULT.

INTERIOR LAMP BATTERY SAVER CONTROL

INTERIOR ROOM LAMP CONTROL SYSTEM

< SYSTEM DESCRIPTION >

[WITH POWER DOOR LOCKS]

If an interior lamp is left ON and does not turn OFF even when the doors are closed, the BCM turns off power to the interior lamps automatically to save the battery 10 minutes after the ignition switch is turned OFF. The BCM controls power and ground to all interior lamps.


After the battery saver system turns the lamps OFF, the lamps will illuminate again when the following conditions are met:

- a signal is received from a main power window and door lock/unlock switch, or when the front door lock assembly LH (key cylinder switch) is locked or unlocked
- a door is opened or closed

The interior lamp battery saver control time period can be changed with the CONSULT.

Component Parts Location

INFOID:0000000010711423



1. BCM M18, M19, M20 (view with lower instrument panel LH removed)
2. Key switch M27
3. Cargo lamp switch M71
4. Front door switch LH B8 (crew cab)
Front door switch RH B108 (crew cab)
5. Rear door switch LH B18 (crew cab)
Rear door switch RH B116 (crew cab)
6. Front door switch LH D213 (king cab)
Front door switch RH D314 (king cab)

INTERIOR ROOM LAMP CONTROL SYSTEM

< SYSTEM DESCRIPTION >

[WITH POWER DOOR LOCKS]

- | | | |
|--|--|--|
| 7. Rear door switch upper LH D211 (king cab) | 8. Rear door switch lower LH D212 (king cab) | 9. Cargo lamp B161 |
| Rear door switch upper RH D312 (king cab) | Rear door switch lower RH D313 (king cab) | |
| 10. Room lamp 2nd row R10 | 11. Front room/map lamp assembly R9 | 12. Vanity lamp LH B80 (if equipped)
Vanity lamp RH B81 (if equipped) |
| 13. Ignition keyhole illumination M150 (if equipped) | | |

Component Description

INFOID:000000010711424

Part name	Description
BCM	Provides power and ground and controls timer functions for the interior room lamps and cargo lamp.
Key switch	Provides key in ignition status to the BCM.
Door switches	Provides door OPEN/CLOSED status to the BCM.
Cargo lamp switch	Provides cargo lamp ON/OFF request to the BCM.
Main power window and door lock/unlock switch	Provides door lock/unlock position switch status to the BCM.
Power window and door lock/unlock switch RH	
Front door lock assembly LH (key cylinder switch)	Provides door lock/unlock status to the BCM.

ILLUMINATION CONTROL SYSTEM


< SYSTEM DESCRIPTION >

[WITH POWER DOOR LOCKS]

ILLUMINATION CONTROL SYSTEM

System Diagram

INFOID:0000000010711425



System Description

INFOID:0000000010711426

The illumination lamps operation is dependent upon the position of the combination switch (lighting and turn signal switch). When the combination switch (lighting and turn signal switch) is placed in the 1ST or 2ND position (or if the auto light system is activated) the BCM (body control module) receives input requesting the parking lamps to illuminate. This input is communicated to the IPDM E/R (intelligent power distribution module engine room) via the CAN communication lines. The CPU (central processing unit) of the IPDM E/R controls the tail lamp relay coil. When energized, this relay directs power to the parking and illumination lamps, which then illuminate.

BATTERY SAVER CONTROL

When the combination switch (lighting and turn signal switch) is in the 1ST or 2ND position and the ignition switch is turned from ON or ACC to OFF, the battery saver control feature is activated. Under this condition, the illumination lamps remain illuminated for 10 minutes unless the combination switch (lighting and turn signal switch) position is changed. If the combination switch (lighting and turn signal switch) position is changed, then the illumination lamps are turned off after a 30 second delay. When the combination switch (lighting and turn signal switch) is turned from OFF to 1ST or 2ND position (or if auto light system is activated) after illumination lamps have been turned off by the battery saver control, the illumination lamps illuminate again.

INL

M

N

O

P


ILLUMINATION CONTROL SYSTEM

< SYSTEM DESCRIPTION >

[WITH POWER DOOR LOCKS]

Component Parts Location

INFOID:000000010711427



WKIA5029E

1. IPDM E/R E122, E124
2. Combination switch (lighting and turn signal switch) M28
3. Combination meter M24
4. Illumination control switch (built into combination meter)
5. BCM M18, M20 (view with lower instrument panel LH removed)

Component Description

INFOID:000000010711428

Part name	Description
BCM	The BCM monitors the lighting switch position with the combination switch reading function. The BCM requests, via CAN communication, that the IPDM E/R activate the tail lamp relay.
IPDM E/R	The IPDM E/R activates the tail lamp relay based on inputs received from the BCM via the CAN communication network.
Combination meter (illumination control switch)	The illumination control switch is a part of the combination meter. The combination meter controls illumination intensity by varying ground to the illumination lamps based on the illumination control switch position.
Combination switch (lighting and turn signal switch)	The combination switch (lighting and turn signal switch) provides input to the BCM about the lighting switch position.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[WITH POWER DOOR LOCKS]

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000011341375

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Direct Diagnostic Mode	Description
ECU Identification	The BCM part number is displayed.
Self Diagnostic Result	The BCM self diagnostic results are displayed.
Data Monitor	The BCM input/output data is displayed in real time.
Active Test	The BCM activates outputs to test components.
Work support	The settings for BCM functions can be changed.
Configuration	<ul style="list-style-type: none"> • The vehicle specification can be read and saved. • The vehicle specification can be written when replacing BCM.
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

SYSTEM APPLICATION

BCM can perform the following functions.

System	Sub System	Direct Diagnostic Mode						
		ECU Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
Door lock	DOOR LOCK			×	×	×		
Rear window defogger	REAR DEFOGGER			×	×			
Warning chime	BUZZER			×	×			
Interior room lamp timer	INT LAMP			×	×	×		
Remote keyless entry system	MULTI REMOTE ENT			×	×	×		
Exterior lamp	HEAD LAMP			×	×	×		
Wiper and washer	WIPER			×	×	×		
Turn signal and hazard warning lamps	FLASHER			×	×			
Air conditioner	AIR CONDITIONER			×				
Combination switch	COMB SW			×				
BCM	BCM	×	×			×	×	×
Immobilizer	IMMU		×	×	×			
Interior room lamp battery saver	BATTERY SAVER			×	×	×		
Vehicle security system	THEFT ALM			×	×	×		
RAP system	RETAINED PWR			×	×	×		
Signal buffer system	SIGNAL BUFFER			×	×			
TPMS	AIR PRESSURE MONITOR		×	×	×	×		
Panic alarm system	PANIC ALARM				×			

INT LAMP

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[WITH POWER DOOR LOCKS]

INT LAMP : CONSULT Function (BCM - INT LAMP)

INFOID:000000011341376

DATA MONITOR

Monitor Item [Unit]	Description
IGN ON SW [On/Off]	Indicates condition of ignition switch ON position.
KEY ON SW [On/Off]	Indicates condition of key switch.
DOOR SW-DR [On/Off]	Indicates condition of front door switch LH.
DOOR SW-AS [On/Off]	Indicates condition of front door switch RH.
DOOR SW-RR [On/Off]	Indicates condition of rear door switch RH.
DOOR SW-RL [On/Off]	Indicates condition of rear door switch LH.
KEY CYL LK-SW [On/Off]	Indicates condition of lock signal from door key cylinder switch.
KEY CYL UN-SW [On/Off]	Indicates condition of unlock signal from door key cylinder switch.
CDL LOCK SW [On/Off]	Indicates condition of lock signal from door lock and unlock switch.
CDL UNLOCK SW [On/Off]	Indicates condition of unlock signal from door lock and unlock switch.
KEYLESS LOCK [On/Off]	Indicates condition of lock signal from keyfob.
KEYLESS UNLOCK [On/Off]	Indicates condition of unlock signal from keyfob.

ACTIVE TEST

Test Item	Description
IGN ILLUM	This test is able to check ignition keyhole illumination operation [Off/On].
INT LAMP	This test is able to check interior room lamp operation [Off/On].

WORK SUPPORT

Support Item	Setting	Description
SET I/L D-UNLCK INTCON	Off	Interior room lamp timer function OFF.
	On*	Interior room lamp timer function ON.
ROOM LAMP ON TIME SET	MODE7 0 sec.	Sets the interior room lamp gradual brightening time.
	MODE6 5 sec.	
	MODE5 4 sec.	
	MODE4 3 sec.	
	MODE3 2 sec.	
	MODE2* 1 sec.	
	MODE1 0.5 sec.	
ROOM LAMP OFF TIME SET	MODE7 0 sec.	Sets the interior room lamp gradual dimming time.
	MODE6 5 sec.	
	MODE5 4 sec.	
	MODE4 3 sec.	
	MODE3 2 sec.	
	MODE2* 1 sec.	
	MODE1 0.5 sec.	

* : Initial setting

BATTERY SAVER

BATTERY SAVER : CONSULT Function (BCM - BATTERY SAVER)

INFOID:000000011341377

DATA MONITOR

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[WITH POWER DOOR LOCKS]

Monitor Item [Unit]	Description
IGN ON SW [On/Off]	Indicates condition of ignition switch ON position.
KEY ON SW [On/Off]	Indicates condition of key switch.
DOOR SW-DR [On/Off]	Indicates condition of front door switch LH.
DOOR SW-AS [On/Off]	Indicates condition of front door switch RH.
DOOR SW-RR [On/Off]	Indicates condition of rear door switch RH.
DOOR SW-RL [On/Off]	Indicates condition of rear door switch LH.
KEY CYL LK SW [On/Off]	Indicates condition of lock signal from door key cylinder switch.
KEY CYL UN SW [On/Off]	Indicates condition of unlock signal from door key cylinder switch.
CDL LOCK SW [On/Off]	Indicates condition of lock signal from door lock and unlock switch.
CDL UNLOCK SW [On/Off]	Indicates condition of unlock signal from door lock and unlock switch.
KEYLESS LOCK [On/Off]	Indicates condition of lock signal from keyfob.
KEYLESS UNLOCK [On/Off]	Indicates condition of unlock signal from keyfob.

ACTIVE TEST

Test item	Description
BATTERY SAVER	This test is able to check battery saver operation [Off/On].

WORK SUPPORT

Support Item	Setting		Description
ROOM LAMP TIMER SET	MODE2	60 min	Sets the interior room lamp battery saver timer operating time.
	MODE1*	10 min	

*: Initial setting

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

DTC/CIRCUIT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT BCM

BCM : Diagnosis Procedure

INFOID:0000000011341378

Regarding Wiring Diagram information, refer to [BCS-45, "Wiring Diagram"](#).

1. CHECK FUSES AND FUSIBLE LINK

Check that the following fuses and fusible link are not blown.

Terminal No.	Signal name	Fuses and fusible link No.
57	Battery power supply	21 (10A)
70		G (50A)
11	Ignition ACC or ON	4 (10A)
38	Ignition ON or START	1 (10A)


Is the fuse blown?

- YES >> Replace the blown fuse or fusible link after repairing the affected circuit.
NO >> GO TO 2

2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM.
3. Check voltage between BCM harness connector and ground.

Connector	Terminals		Power source	Condition	Voltage (V) (Ap-prox.)
	(+)	(-)			
M18	11	Ground	ACC power supply	Ignition switch ACC or ON	Battery voltage
	38	Ground	Ignition power supply	Ignition switch ON or START	Battery voltage
M20	57	Ground	Battery power supply	Ignition switch OFF	Battery voltage
	70	Ground	Battery power supply	Ignition switch OFF	Battery voltage



Is the measurement value normal?

- YES >> GO TO 3
NO >> Repair or replace harness.

3. CHECK GROUND CIRCUIT

POWER SUPPLY AND GROUND CIRCUIT

[WITH POWER DOOR LOCKS]


< DTC/CIRCUIT DIAGNOSIS >

Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M20	67		Yes

Does continuity exist?

- YES >> Inspection End.
NO >> Repair or replace harness.



A
B
C
D
E
F
G
H
I
J
K
L
INL
M
N
O
P

BATTERY SAVER OUTPUT/POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[WITH POWER DOOR LOCKS]

BATTERY SAVER OUTPUT/POWER SUPPLY CIRCUIT

Description

INFOID:0000000010711433

Provides the battery saver output/power supply. Also cuts the power supply when the interior room lamp battery saver is activating.

Component Function Check

INFOID:0000000010711434

1. CHECK BATTERY SAVER OUTPUT/POWER SUPPLY FUNCTION

(B) WITH CONSULT

1. Turn ignition switch ON.
2. Turn each interior room lamp ON.
 - Front room/map lamp assembly
 - Vanity lamps
 - Room lamp 2nd row
3. Select "BATTERY SAVER" of BCM (BATTERY SAVER) active test item.
4. While operating the test item, check that each interior room lamp turns ON/OFF.

OFF : Interior room lamp OFF

ON : Interior room lamp ON

Is the inspection result normal?

YES >> Battery saver output/power supply circuit is normal.

NO >> Refer to [INL-16, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000010711435


Regarding Wiring Diagram information, refer to [INL-37, "Wiring Diagram - With Power Door Lock System"](#).

1. CHECK BATTERY SAVER OUTPUT/POWER SUPPLY OUTPUT

(B) WITH CONSULT

1. Turn ignition switch ON.
2. Select "BATTERY SAVER" of BCM (BATTERY SAVER) active test item.
3. While operating the test item, check voltage between BCM connector M20 terminal 56 and ground.

Connector	Terminal	(-)	Test item	Voltage
			BATTERY SAVER	
M20	56	Ground	OFF	0V
			ON	Battery voltage



Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace BCM after making sure the battery saver output/power supply circuit is not shorted to voltage. Refer to [BCS-51, "Removal and Installation"](#).

2. CHECK BATTERY SAVER OUTPUT/POWER SUPPLY OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the following connectors:
 - BCM M20
 - Ignition keyhole illumination
 - Front room/map lamp assembly
 - Vanity lamp LH
 - Vanity lamp RH

BATTERY SAVER OUTPUT/POWER SUPPLY CIRCUIT

[WITH POWER DOOR LOCKS]

< DTC/CIRCUIT DIAGNOSIS >

- Room lamp 2nd row

3. Check continuity between BCM connector M20 terminal 56 and each interior room lamp connector.

BCM		Each interior room lamp		Continuity
Connector	Terminal	Connector	Terminal	
M20	56	Ignition keyhole illumination	M150	1
		Front room/map lamp assembly	R9	1
		Vanity lamp LH	B80	1
		Vanity lamp RH	B81	1
		Room lamp 2nd row	R10	2

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the harness or connectors.

3.CHECK BATTERY SAVER OUTPUT/POWER SUPPLY SHORT CIRCUIT


Check continuity between BCM connector M20 terminal 56 and ground.

Connector	Terminal	-	Continuity
M20	56	Ground	No

Is the inspection result normal?

YES >> Replace the interior room lamp. Refer to [INL-63, "Removal and Installation".](#)

NO >> Repair the harness or connectors.



ALLIA0409GB

INTERIOR ROOM LAMP CONTROL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[WITH POWER DOOR LOCKS]

INTERIOR ROOM LAMP CONTROL CIRCUIT

Description

INFOID:0000000010711436

Controls the following interior room lamps (ground side) by PWM signal:

- Front room/map lamp assembly
- Room lamp 2nd row

NOTE:

PWM signal control period is approximately 250 Hz (in the gradual brightening/dimming).

Component Function Check

INFOID:0000000010711437

CAUTION:

Before performing the diagnosis, check that the following is normal:

- Battery saver output/power supply
- Front room/map lamp bulbs (if equipped)
- Room lamp 2nd row bulb

1.CHECK INTERIOR ROOM LAMP CONTROL FUNCTION

(B) WITH CONSULT

1. Switch the front room/map lamp assembly and room lamp 2nd row switches to DOOR.
2. Turn ignition switch ON.
3. Select "INT LAMP" of BCM (INT LAMP) active test item.
4. While operating the test item, check that each interior room lamp turns ON/OFF (gradual brightening/dimming).

ON : Interior room lamp gradual brightening

OFF : Interior room lamp gradual dimming

Is the inspection result normal?

YES >> Interior room lamp control circuit is normal.

NO >> Refer to [INL-18, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000010711438

Regarding Wiring Diagram information, refer to [INL-37, "Wiring Diagram - With Power Door Lock System"](#).

1.CHECK INTERIOR ROOM LAMP CONTROL OUTPUT

(B) WITH CONSULT

1. Turn ignition switch ON.
2. Select "INT LAMP" of BCM (INT LAMP) active test item.
3. While operating the test item, check voltage between BCM connector M20 terminal 63 and ground.

(+) Connector		(-) Terminal	INT LAMP	Voltage	
Connector	Terminal				
M20	63		ON	0V	
			OFF	Battery voltage	


Is the inspection result normal?

YES >> Interior room lamp control circuit is operating normally.

Fixed ON>> GO TO 3.

Fixed OFF>> GO TO 2.

2.CHECK INTERIOR ROOM LAMP CONTROL OPEN CIRCUIT



INTERIOR ROOM LAMP CONTROL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[WITH POWER DOOR LOCKS]


1. Turn ignition switch OFF.
2. Disconnect BCM connector M20, room lamp 2nd row connector and front room/map lamp connector.
3. Check continuity between BCM connector M20 (A) terminal 63 and interior room lamp connectors.

Terminal		Terminal			Continuity
Connector	Terminal	Component	Connector	Terminal	
M20 (A)	63	Room lamp 2nd row	R10 (B)	1	Yes
		Front room/map lamp	R9 (C)	2	

Is the inspection result normal?

YES >> Check interior room lamp for an open. If OK, replace the BCM. Refer to [BCS-51, "Removal and Installation"](#). If NG, replace the interior room lamp. Refer to [INL-63, "Removal and Installation"](#).

NO >> Repair the harness or connectors.



3.CHECK INTERIOR ROOM LAMP CONTROL SHORT CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect BCM connector M20, room lamp 2nd row connector and front room/map lamp connector.
3. Check continuity between BCM connector M20 terminal 63 and ground.

Connector	Terminal	—	Continuity
M20	63	Ground	No

Is the inspection result normal?

YES >> Check interior room lamp for a short circuit. If OK, replace the BCM. Refer to [BCS-51, "Removal and Installation"](#). If NG, replace the interior room lamp. Refer to [INL-63, "Removal and Installation"](#).

NO >> Repair the harness or connectors.



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

INL

CARGO LAMP CONTROL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[WITH POWER DOOR LOCKS]

CARGO LAMP CONTROL CIRCUIT

Description

INFOID:0000000010711439

Controls the cargo lamp relay coil (ground side) to turn the cargo lamp ON and OFF.

Diagnosis Procedure

INFOID:0000000010711440

Regarding Wiring Diagram information, refer to [INL-37, "Wiring Diagram - With Power Door Lock System"](#).

CAUTION:

Before performing the diagnosis, check that the following is normal:

- Fuse
- Cargo lamp bulb

1. CHECK CARGO LAMP OPERATION

Check the cargo lamp operation from the cargo lamp switch, the door switches, and a keyfob (if equipped).

Is the cargo lamp operative from all of the above switches and the keyfob?

YES >> At this time, the cargo lamp operates normally.

NO >>

- Inoperative from all the above switches and the keyfob, GO TO 6.
 - Inoperative from cargo lamp switch only, GO TO 2.
 - Inoperative from door switches only, refer to [DLK-27, "KING CAB : Description"](#) (king cab), [DLK-29, "CREW CAB : Description"](#) (crew cab).
 - Inoperative from keyfob only, refer to [DLK-51, "Description"](#).
 - Fixed ON, GO TO 2.

2. CHECK CARGO LAMP SWITCH

Check the cargo lamp switch. Refer to [INL-22, "Component Inspection"](#).

Is the inspection result normal?

YES >>

- For inoperative from cargo lamp switch only, GO TO 3.
- For fixed ON, GO TO 5.

NO >> Replace the cargo lamp switch.

3. CHECK CARGO LAMP SWITCH CIRCUIT OPEN

1. Disconnect BCM connector M18 and cargo lamp switch connector.
2. Check continuity between BCM connector M18 terminal 31 and cargo lamp switch connector M71 terminal 1.

BCM		Cargo lamp switch		Continuity
Connector	Terminal	Connector	Terminal	
M18	31	M71	1	Yes

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair harness or connectors.

4. CHECK CARGO LAMP SWITCH GROUND CIRCUIT

1. Check continuity between cargo lamp switch connector M71 terminal 3 and ground.

Connector	Terminal	-	Continuity
M71	3	Ground	Yes

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-51, "Removal and Installation"](#).

NO >> Repair harness or connectors.

CARGO LAMP CONTROL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[WITH POWER DOOR LOCKS]

5.CHECK CARGO LAMP SWITCH CIRCUIT SHORT

1. Disconnect BCM connector M18 and cargo lamp switch connector.
2. Check continuity between BCM connector M18 terminal 31 and ground.

Connector	Terminal	-	Continuity
M18	31	Ground	No

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair harness or connectors.

6.CHECK CARGO LAMP RELAY

Check the cargo lamp relay. Refer to [INL-22, "Component Inspection"](#).

Is the inspection result normal?

YES >> • For fixed OFF, GO TO 7.
• For fixed ON, GO TO 13.

NO >> Replace the cargo lamp relay.

7.CHECK CARGO LAMP RELAY CONTROL


While operating the cargo lamp switch, check voltage between BCM connector M19 terminal 50 and ground.

Connector	Terminal	-	Cargo lamp switch	Voltage
M19	50	Ground	ON	0V
			OFF	Battery voltage

Is the inspection result normal?

YES >> GO TO 8.

NO >> GO TO 11.



8.CHECK CARGO LAMP VOLTAGE

1. Disconnect the cargo lamp connector.
2. While operating the cargo lamp switch, check voltage between cargo lamp connector B161 terminal 3 and ground.

Connector	Terminal	-	Cargo lamp switch	Voltage
B161	3	Ground	ON	Battery voltage

Is the inspection result normal?

YES >> GO TO 9.

NO >> GO TO 10.

9.CHECK CARGO LAMP GROUND CIRCUIT

1. While operating the cargo lamp switch, check voltage between cargo lamp connector B161 terminal 3 and terminal 2.

Connector	Terminal (+)	Terminal (-)	Cargo lamp switch	Voltage
B161	3	2	ON	Battery voltage

Is the inspection result normal?

YES >> Replace cargo lamp.

NO >> Repair harness or connectors.

10.CHECK CARGO LAMP RELAY VOLTAGE PART 1

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
INL

CARGO LAMP CONTROL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[WITH POWER DOOR LOCKS]


Check voltage between cargo lamp relay connector M165 terminal 5 and ground.

Cargo lamp relay		Ground	Voltage
Connector	Terminal		Battery voltage
M165	5		

Is the inspection result normal?

YES >> Repair harness or connectors between cargo lamp relay and cargo lamp.

NO >> Repair harness or connector between splice and cargo lamp relay.



11. CHECK CARGO LAMP RELAY VOLTAGE PART 2


Check voltage between cargo lamp relay connector M165 terminal 2 and ground.

Cargo lamp relay		Ground	Voltage
Connector	Terminal		Battery voltage
M165	2		

Is the inspection result normal?

YES >> GO TO 12.

NO >> Repair harness or connectors.



12. CHECK CARGO LAMP RELAY CONTROL CIRCUIT OPEN

1. Disconnect BCM connector M19 and cargo lamp relay.
2. Check continuity between BCM connector M19 terminal 50 and cargo lamp relay connector M165 terminal 1.

BCM		Cargo lamp relay		Continuity
Connector	Terminal	Connector	Terminal	
M19	50	M165	1	Yes

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-51, "Removal and Installation"](#).

NO >> Repair harness or connectors.

13. CHECK CARGO LAMP RELAY CONTROL CIRCUIT SHORT

1. Disconnect BCM connector M19 and cargo lamp relay.
2. Check continuity between BCM connector M19 terminal 50 and ground.

Connector	Terminal	-	Continuity
M19	50	Ground	No

Is the inspection result normal?

YES >> Replace BCM after making sure the cargo lamp power supply circuit is not shorted to voltage. Refer to [BCS-51, "Removal and Installation"](#).

NO >> Repair harness or connectors.

Component Inspection

INFOID:0000000010711441

CARGO LAMP SWITCH

1. CHECK CARGO LAMP SWITCH

CARGO LAMP CONTROL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >


[WITH POWER DOOR LOCKS]

1. Turn ignition switch OFF.
2. Disconnect cargo lamp switch connector.
3. Check continuity between cargo lamp switch terminals 1 and 3.

Cargo lamp switch	Condition	Continuity
Terminal		
1 – 3	ON	Yes
	OFF	No

Is the inspection result normal?

- YES >> Inspection End.
 NO >> Replace cargo lamp switch.



AWLIA0804Z2

CARGO LAMP RELAY


1. CHECK CARGO LAMP RELAY

1. Turn ignition switch OFF.
2. Disconnect cargo lamp relay.
3. Supply power to terminal 2 and ground to terminal 1 of the cargo lamp relay.
4. Check continuity between cargo lamp relay terminals 3 and 5.

Terminal	Condition	Continuity
3 5	Power and ground supplied to terminals 1 and 2	Yes
	No power and ground supplied	No

Is the inspection result normal?

- YES >> Inspection End.
 NO >> Replace cargo lamp relay.



SEF497Y

IGNITION KEYHOLE ILLUMINATION CONTROL CIRCUIT

Description

Controls the ignition keyhole illumination (ground side) to turn the ignition keyhole illumination ON and OFF.

Component Function Check

CAUTION:

Before performing the diagnosis, check that the following is normal:

- Battery saver output/power supply circuit
- Ignition keyhole illumination bulb

1. CHECK IGNITION KEYHOLE ILLUMINATION OPERATION

(B) WITH CONSULT

1. Turn the ignition switch ON.
2. Select "IGN ILLUM" of BCM (INT LAMP) active test item.
3. While operating the test item, check that the ignition keyhole illumination turns ON/OFF

ON : Ignition keyhole illumination ON

OFF : Ignition keyhole illumination OFF

Is the inspection result normal?

YES >> Ignition keyhole illumination circuit is normal.

NO >> Refer to [INL-24, "Diagnosis Procedure"](#).

Diagnosis Procedure

Regarding Wiring Diagram information, refer to [INL-37, "Wiring Diagram - With Power Door Lock System"](#).

1. CHECK IGNITION KEYHOLE OUTPUT

(B) WITH CONSULT

1. Turn ignition switch ON.
2. Select "IGN ILLUM" of BCM (INT LAMP) active test item.
3. While operating the test item, check voltage between BCM connector M18 terminal 1 and ground.

Connector	Terminal	-	IGN ILLUM	Voltage
M18	1	Ground	ON	0V
			OFF	Battery voltage


Is the inspection result normal?

YES >> Ignition keyhole illumination control circuit is operating normally.

Fixed ON>> GO TO 3.

Fixed OFF>> GO TO 2.

2. CHECK IGNITION KEYHOLE ILLUMINATION OPEN CIRCUIT



IGNITION KEYHOLE ILLUMINATION CONTROL CIRCUIT


[WITH POWER DOOR LOCKS]

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect BCM connector M18 and ignition keyhole illumination connector.
3. Check continuity between BCM connector M18 (A) terminal 1 and ignition keyhole illumination connector M150 (B) terminal 2.

BCM		Ignition keyhole illumination		Continuity
Connector	Terminal	Connector	Terminal	
M18 (A)	1	M150 (B)	2	Yes

Is the inspection result normal?



YES >> Check the ignition keyhole illumination for an open. If OK, replace the BCM. Refer to [BCS-51, "Removal and Installation"](#). If NG, replace ignition keyhole illumination.


NO >> Repair harness or connectors.

3. CHECK IGNITION KEYHOLE ILLUMINATION SHORT CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector M18 and ignition keyhole illumination connector.
3. Check continuity between BCM connector M18 terminal 1 and ground.

Connector	Terminal	-	Continuity
M18	1	Ground	No

Is the inspection result normal?



YES >> Check the ignition keyhole illumination for a short circuit. If OK, replace the BCM. Refer to [BCS-51, "Removal and Installation"](#). If NG, replace ignition keyhole illumination.

NO >> Repair harness or connectors.

ECU DIAGNOSIS INFORMATION

BCM (BODY CONTROL MODULE)

Reference Value

INFOID:000000011349829

NOTE:

The Signal Tech II Tool [– (J-50190)] can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs
- Test remote keyless entry keyfob relative signal strength

VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Condition	Value/Status
ACC ON SW	Ignition switch OFF or ON	Off
	Ignition switch ACC	On
AIR COND SW	A/C switch OFF	Off
	A/C switch ON	On
AIR PRESS FL	Front left tire air pressure value	kPa, kg/cm ² , psi
AIR PRESS FR	Front right tire air pressure value	kPa, kg/cm ² , psi
AIR PRESS RL	Rear left tire air pressure value	kPa, kg/cm ² , psi
AIR PRESS RR	Rear right tire air pressure value	kPa, kg/cm ² , psi
AUTO LIGHT SW	Lighting switch OFF	Off
	Lighting switch AUTO	On
BRAKE SW	Brake pedal released	Off
	Brake pedal applied	On
BUCKLE SW	Seat belt buckle unfastened	Off
	Seat belt buckle fastened	On
BUZZER	Buzzer in combination meter OFF	Off
	Buzzer in combination meter ON	On
CARGO LAMP SW	Cargo lamp switch OFF	Off
	Cargo lamp switch ON	On
CDL LOCK SW	Door lock/unlock switch does not operate	Off
	Press door lock/unlock switch to the LOCK side	On
CDL UNLOCK SW	Door lock/unlock switch does not operate	Off
	Press door lock/unlock switch to the UNLOCK side	On
DOOR SW-AS	Front door RH closed	Off
	Front door RH opened	On
DOOR SW-DR	Front door LH closed	Off
	Front door LH opened	On
DOOR SW-RL	Rear door LH closed	Off
	Rear door LH opened	On
DOOR SW-RR	Rear door RH closed	Off
	Rear door RH opened	On

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH POWER DOOR LOCKS]

Monitor Item	Condition	Value/Status
FAN ON SIG	Blower motor fan switch OFF	Off
	Blower motor fan switch ON	On
FR FOG SW	Front fog lamp switch OFF	Off
	Front fog lamp switch ON	On
FR WASHER SW	Front washer switch OFF	Off
	Front washer switch ON	On
FR WIPER LOW	Front wiper switch OFF	Off
	Front wiper switch LO	On
FR WIPER HI	Front wiper switch OFF	Off
	Front wiper switch HI	On
FR WIPER INT	Front wiper switch OFF	Off
	Front wiper switch INT	On
FR WIPER STOP	Any position other than front wiper stop position	Off
	Front wiper stop position	On
HAZARD SW	When hazard switch is not pressed	Off
	When hazard switch is pressed	On
HEAD LAMP SW 1	Headlamp switch OFF	Off
	Headlamp switch 1st	On
HEAD LAMP SW 2	Headlamp switch OFF	Off
	Headlamp switch 1st	On
HI BEAM SW	High beam switch OFF	Off
	High beam switch HI	On
ID REGST FL1	ID registration of front left tire incomplete	YET
	ID registration of front left tire complete	DONE
ID REGST FR1	ID registration of front right tire incomplete	YET
	ID registration of front right tire complete	DONE
ID REGST RL1	ID registration of rear left tire incomplete	YET
	ID registration of rear left tire complete	DONE
ID REGST RR1	ID registration of rear right tire incomplete	YET
	ID registration of rear right tire complete	DONE
IGN ON SW	Ignition switch OFF or ACC	Off
	Ignition switch ON	On
IGN SW CAN	Ignition switch OFF or ACC	Off
	Ignition switch ON	On
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	1 - 7
KEY CYL LK-SW	Door key cylinder LOCK position	Off
	Door key cylinder other than LOCK position	On
KEY CYL UN-SW	Door key cylinder UNLOCK position	Off
	Door key cylinder other than UNLOCK position	On
KEY ON SW	Mechanical key is removed from key cylinder	Off
	Mechanical key is inserted to key cylinder	On
KEYLESS LOCK	LOCK button of key fob is not pressed	Off
	LOCK button of key fob is pressed	On

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH POWER DOOR LOCKS]

Monitor Item	Condition	Value/Status
KEYLESS PANIC	PANIC button of key fob is not pressed	Off
	PANIC button of key fob is pressed	On
KEYLESS UNLOCK	UNLOCK button of key fob is not pressed	Off
	UNLOCK button of key fob is pressed	On
LIGHT SW 1ST	Lighting switch OFF	Off
	Lighting switch 1st	On
OIL PRESS SW	<ul style="list-style-type: none"> • Ignition switch OFF or ACC • Engine running 	Off
	Ignition switch ON	On
OPTICAL SENSOR	Bright outside of the vehicle	Close to 5V
	Dark outside of the vehicle	Close to 0V
PASSING SW	Other than lighting switch PASS	Off
	Lighting switch PASS	On
REAR DEF SW	Rear window defogger switch OFF	Off
	Rear window defogger switch ON	On
TURN SIGNAL L	Turn signal switch OFF	Off
	Turn signal switch LH	On
TURN SIGNAL R	Turn signal switch OFF	Off
	Turn signal switch RH	On
VEHICLE SPEED	While driving	Equivalent to speedometer reading
WARNING LAMP	Low tire pressure warning lamp in combination meter OFF	Off
	Low tire pressure warning lamp in combination meter ON	On

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH POWER DOOR LOCKS]

Terminal Layout

INFOID:000000011349830

A

B

C

D

E

F

G

H

I

J

K


INL

M

N

O

P



Physical Values





AWMIA1598ZZ

INFOID:000000011349831

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >




[WITH POWER DOOR LOCKS]

Terminal	Wire color	Item	Signal input/output	Measuring condition		Reference value or waveform (Approx.)	
				Ignition switch	Operation or condition		
1	BR	Ignition keyhole illumination	Output	OFF	Door is locked (SW OFF)	Battery voltage	
					Door is unlocked (SW ON)	0V	
2	P	Combination switch input 5	Input	ON	Lighting, turn, wiper OFF Wiper dial position 4		
							
3	SB	Combination switch input 4	Input	ON	Lighting, turn, wiper OFF Wiper dial position 4		
							
4	V	Combination switch input 3	Input	ON	Lighting, turn, wiper OFF Wiper dial position 4		
							
5	L	Combination switch input 2	Input	ON	Lighting, turn, wiper OFF Wiper dial position 4		
6	R	Combination switch input 1					
7	GR	Front door lock assembly LH (key cylinder switch) unlock	Input	OFF	ON (open, 2nd turn)	Momentary 1.5V	
8	SB	Front door lock assembly LH (key cylinder switch) lock			OFF (closed)	0V	
9	LG	Brake sw	Input	OFF	On (open)	Momentary 1.5V	
					OFF (closed)	0V	
11	G/B	Ignition switch (ACC or ON)	Input	ACC or ON	OFF (brake pedal is not depressed)	0V	
					ON (brake pedal is depressed)	Battery voltage	
12	LG	Front door switch RH (All)	Input	OFF	ON (open)	0V	
12		Rear door switch upper RH (King Cab)			OFF (closed)		
		Rear door switch lower RH (King Cab)					

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH POWER DOOR LOCKS]

Terminal	Wire color	Item	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
13	L	Rear door switch RH (Crew Cab)	Input	OFF	ON (open)	0V
					OFF (closed)	Battery voltage
15	W	Tire pressure warning check connector	Input	OFF	—	5V
18	BR	Remote keyless entry receiver and optical sensor (Ground)	Output	OFF	—	0V
19	V	Remote keyless entry receiver (power supply)	Output	OFF	Ignition switch OFF	 LIIA1893E
20	G	Remote keyless entry receiver signal (Signal)	Input	OFF	Stand-by (keyfob buttons released)	 LIIA1894E
					When remote keyless entry receiver receives signal from keyfob (keyfob buttons pressed)	 LIIA1895E
21	GR	NATS antenna amp.	Input	OFF → ON	Ignition switch (OFF → ON)	Just after turning ignition switch ON: Pointer of tester should move.
23	G	Security indicator lamp	Output	OFF	Goes OFF → illuminates (Every 2.4 seconds)	Battery voltage → 0V
25	BR	NATS antenna amp.	Input	OFF → ON	Ignition switch (OFF → ON)	Just after turning ignition switch ON: Pointer of tester should move.
27	W	Compressor ON signal	Input	ON	A/C switch OFF	5V
					A/C switch ON	0V
28	R	Front blower monitor	Input	ON	Front blower motor OFF	Battery voltage
					Front blower motor ON	0V
29	G	Hazard switch	Input	OFF	ON	0V
					OFF	5V
31	GR	Cargo lamp switch	Input	OFF	ON	0V
					OFF	Battery voltage

A
B
C
D
E
F
G
H
I
J
K





INL

M
N
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >





[WITH POWER DOOR LOCKS]

Terminal	Wire color	Item	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
32	BG	Combination switch output 5	Output	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5291E
33	GR	Combination switch output 4	Output	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5292E
34	G	Combination switch output 3	Output	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5291E
35	BR	Combination switch output 2	Output	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5292E
36	LG	Combination switch output 1				
37	B	Key switch	Input	OFF	Key inserted	Battery voltage
					Key removed	0V
38	W/R	Ignition switch (ON)	Input	ON	—	Battery voltage
39	L	CAN high	—	—	—	—
40	P	CAN low	—	—	—	—
41	Y	Rear window defogger switch	Input	ON	Rear window defogger switch ON	0V
					Rear window defogger switch OFF	5V
45	V	Lock switch	Input	OFF	ON (lock)	0V
					OFF	Battery voltage
46	LG	Unlock switch	Input	OFF	ON (unlock)	0V
					OFF	Battery voltage
47	GR	Front door switch LH (All)	Input	OFF	ON (open)	0V
		Rear door switch upper LH (King Cab)			OFF (closed)	Battery voltage
		Rear door switch lower LH (King Cab)				

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH POWER DOOR LOCKS]

Terminal	Wire color	Item	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
48	P	Rear door switch LH (Crew Cab)	Input	OFF	ON (open)	0V
					OFF (closed)	Battery voltage
50	P	Cargo lamp	Output	OFF	Any door open (ON)	0V
					All doors closed (OFF)	Battery voltage
51	BG	Trailer turn signal (right)	Output	ON	Turn right ON	
					 SKIA3009J	
52	LG	Trailer turn signal (left)	Output	ON	Turn left ON	
					 SKIA3009J	
56	R/Y	Battery saver output	Output	OFF	10 minutes after ignition switch is turned OFF	0V
				ON	—	Battery voltage
57	R/Y	Battery power supply	Input	—	—	Battery voltage
58	W	Optical sensor	Input	ON	When optical sensor is illuminated	3.1V or more
					When optical sensor is not illuminated	0.6V or less
59	GR	Front door lock assembly LH (unlock)	Output	OFF	OFF (neutral)	0V
					ON (unlock)	Battery voltage
60	LG	Turn signal (left)	Output	ON	Turn left ON	
					 SKIA3009J	
61	G	Turn signal (right)	Output	ON	Turn right ON	
					 SKIA3009J	
63	BR	Interior room/map lamp	Output	OFF	Any door switch	ON (open)
					OFF (closed)	Battery voltage
65	V	All door lock actuators (lock)	Output	OFF	OFF (neutral)	0V
					ON (lock)	Battery voltage

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH POWER DOOR LOCKS]

Terminal	Wire color	Item	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
66	L	Front door lock actuator RH, rear door lock actuators LH/RH (unlock)	Output	OFF	OFF (neutral)	0V
					ON (unlock)	Battery voltage
67	B	Ground	Input	ON	—	0V
68 ¹	O	Power window power supply (RAP)	Output	—	Ignition switch ON	Battery voltage
					Within 45 seconds after ignition switch OFF	Battery voltage
					More than 45 seconds after ignition switch OFF	0V
					When front door LH or RH is open or power window timer operates	0V
68 ²	SB	Power window power supply (RAP)	Output	—	Ignition switch ON	Battery voltage
					Within 45 seconds after ignition switch OFF	Battery voltage
					More than 45 seconds after ignition switch OFF	0V
					When front door LH or RH is open or power window timer operates	0V
69	P	Power window power supply (BAT)	Output	OFF	—	Battery voltage
70	W	Battery power supply	Input	OFF	—	Battery voltage

1: King cab

2: Crew cab

Fail Safe

INFOID:0000000011349832

Fail-safe index

BCM performs fail-safe control when any DTC listed below is detected.

Display contents of CONSULT	Fail-safe	Cancellation
U1000: CAN COMM CIRCUIT	Inhibit engine cranking	When the BCM re-establishes communication with the other modules.

DTC Inspection Priority Chart

INFOID:0000000011349833

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	DTC
1	• U1000: CAN COMM CIRCUIT
2	• B2190: NATS ANTENNA AMP • B2191: DIFFERENCE OF KEY • B2192: ID DISCORD BCM-ECM • B2193: CHAIN OF BCM-ECM

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH POWER DOOR LOCKS]

Priority	DTC	
3	<ul style="list-style-type: none"> • C1729: VHCL SPEED SIG ERR • C1735: IGNITION SIGNAL 	A
4	<ul style="list-style-type: none"> • C1704: LOW PRESSURE FL • C1705: LOW PRESSURE FR • C1706: LOW PRESSURE RR • C1707: LOW PRESSURE RL • C1708: [NO DATA] FL • C1709: [NO DATA] FR • C1710: [NO DATA] RR • C1711: [NO DATA] RL • C1712: [CHECKSUM ERR] FL • C1713: [CHECKSUM ERR] FR • C1714: [CHECKSUM ERR] RR • C1715: [CHECKSUM ERR] RL • C1716: [PRESSDATA ERR] FL • C1717: [PRESSDATA ERR] FR • C1718: [PRESSDATA ERR] RR • C1719: [PRESSDATA ERR] RL • C1720: [CODE ERR] FL • C1721: [CODE ERR] FR • C1722: [CODE ERR] RR • C1723: [CODE ERR] RL • C1724: [BATT VOLT LOW] FL • C1725: [BATT VOLT LOW] FR • C1726: [BATT VOLT LOW] RR • C1727: [BATT VOLT LOW] RL 	B C D E F G H

DTC Index

INFOID:000000011349834

NOTE:

Details of time display

- CRNT: Displays when there is a malfunction now or after returning to the normal condition until turning ignition switch OFF → ON again.
- 1 - 39: Displayed if any previous malfunction is present when current condition is normal. It increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. The counter remains at 39 even if the number of cycles exceeds it. It is counted from 1 again when turning ignition switch OFF → ON after returning to the normal condition if the malfunction is detected again.

CONSULT display	Fail-safe	Low tire pressure warning lamp ON	Reference page
No DTC is detected. further testing may be required.	—	—	—
U1000: CAN COMM CIRCUIT	—	—	BCS-27
B2190: NATS ANTENNA AMP	—	—	SEC-18
B2191: DIFFERENCE OF KEY	—	—	SEC-21
B2192: ID DISCORD BCM-ECM	—	—	SEC-22
B2193: CHAIN OF BCM-ECM	—	—	SEC-24
C1708: [NO DATA] FL	—	X	WT-15
C1709: [NO DATA] FR	—	X	WT-15
C1710: [NO DATA] RR	—	X	WT-15
C1711: [NO DATA] RL	—	X	WT-15
C1712: [CHECKSUM ERR] FL	—	X	WT-17
C1713: [CHECKSUM ERR] FR	—	X	WT-17
C1714: [CHECKSUM ERR] RR	—	X	WT-17
C1715: [CHECKSUM ERR] RL	—	X	WT-17

INL

M

N

O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITH POWER DOOR LOCKS]

CONSULT display	Fail-safe	Low tire pressure warning lamp ON	Reference page
C1716: [PRESSDATA ERR] FL	—	X	WT-19
C1717: [PRESSDATA ERR] FR	—	X	WT-19
C1718: [PRESSDATA ERR] RR	—	X	WT-19
C1719: [PRESSDATA ERR] RL	—	X	WT-19
C1720: [CODE ERR] FL	—	X	WT-17
C1721: [CODE ERR] FR	—	X	WT-17
C1722: [CODE ERR] RR	—	X	WT-17
C1723: [CODE ERR] RL	—	X	WT-17
C1724: [BATT VOLT LOW] FL	—	X	WT-17
C1725: [BATT VOLT LOW] FR	—	X	WT-17
C1726: [BATT VOLT LOW] RR	—	X	WT-17
C1727: [BATT VOLT LOW] RL	—	X	WT-17
C1729: VHCL SPEED SIG ERR	—	X	WT-21
C1735: IGNITION SIGNAL	—	X	WT-22

INTERIOR ROOM LAMP

< WIRING DIAGRAM >


[WITH POWER DOOR LOCKS]

WIRING DIAGRAM

INTERIOR ROOM LAMP

Wiring Diagram - With Power Door Lock System


INFOID:0000000010711451



INTERIOR ROOM LAMP

< WIRING DIAGRAM >

[WITH POWER DOOR LOCKS]




ABILWA2809GP

INTERIOR ROOM LAMP

< WIRING DIAGRAM >

[WITH POWER DOOR LOCKS]



ABLWA2388GB

INTERIOR ROOM LAMP


< WIRING DIAGRAM >

[WITH POWER DOOR LOCKS]

INTERIOR ROOM LAMP CONNECTORS - WITH POWER DOOR LOCK SYSTEM


Connector No.	M1	Connector No.	M3
Connector Name	WIRE TO WIRE	Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE	Connector Color	WHITE

Connector No.	M4	Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE		



Terminal No.	Color of Wire	Signal Name
9	R/Y	-
20	B	-
21	BR	-

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4N	R/Y	—

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
15P	W/R	-

Connector No.	M9
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	SB	-
2	LG	-
3	V	-
7	GR	-

Connector No.	M8
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
9	B	—

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	W	—


ABLIA6832GP

INTERIOR ROOM LAMP

< WIRING DIAGRAM >

[WITH POWER DOOR LOCKS]

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
18	BR	KEYLESS & AUTO LIGHT SENSOR GND
19	V	KEYLESS TUNER POWER SUPPLY OUTPUT
20	G	KEYLESS TUNER SIGNAL
31	GR	CARGO LAMP SW
37	B	KEY SW
38	W/R	IGN SW
39	L	CAN-H
40	P	CAN-L

Terminal No.	Color of Wire	Signal Name
1	BR	KEY RING OUTPUT
7	GR	KEY CYLINDER UNLOCK SW
8	SB	KEY CYLINDER LOCK SW
12	LG	DOOR SW (AS)
13	L	DOOR SW (RR)



Connector No.	M27
Connector Name	KEY SWITCH
Connector Color	WHITE



Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	B	-
2	Y	-

ABLIA6833GB

INTERIOR ROOM LAMP

< WIRING DIAGRAM >

[WITH POWER DOOR LOCKS]



ABLIA6834GB

INTERIOR ROOM LAMP

< WIRING DIAGRAM >

[WITH POWER DOOR LOCKS]

Connector No.	M150
Connector Name	IGNITION KEYHOLE ILLUMINATION
Connector Color	WHITE



Connector No.	M120
Connector Name	REMOTE KEYLESS ENTRY RECEIVER
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	BR	R/Y
2	G	BR
4	V	-

Terminal No.	Color of Wire	Signal Name
1	R/Y	-
2	BR	-

Terminal No.	Color of Wire	Signal Name
1	P	-
2	R/Y	-
3	G	-
5	R/Y	-


Terminal No.	Color of Wire	Signal Name
35G	Y	-



Connector No.	E10
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	W	-



ABLIA5636GB


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z
INL

INTERIOR ROOM LAMP

< WIRING DIAGRAM >

[WITH POWER DOOR LOCKS]

Connector No.	B18
Connector Name	REAR DOOR SWITCH LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	P	—

Connector No.	B80
Connector Name	VANITY LAMP LH
Connector Color	WHITE



Connector No.	B16
Connector Name	WIRE TO WIRE
Connector Color	WHITE






Terminal No.	Color of Wire	Signal Name
7	B	—

Terminal No.	Color of Wire	Signal Name
40J	P	-
...



Connector No.	B8
Connector Name	FRONT DOOR SWITCH LH (CREW CAB)



ABLTIA5637GP

INTERIOR ROOM LAMP

< WIRING DIAGRAM >

[WITH POWER DOOR LOCKS]

Connector No.	B107
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	B	-
8	LG	-

Connector No.	B81
Connector Name	VANITY LAMP RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R/Y	-
2	B	-

Terminal No.	Color of Wire	Signal Name
2	LG	-

Connector No.	B149
Connector Name	WIRE TO WIRE
Connector Color	WHITE



5M	4M	3M	2M	1M
10M	9M	8M	7M	6M
21M	20M	19M	18M	17M
30M	29M	28M	27M	26M
41M	40M	39M	38M	37M
50M	49M	48M	47M	46M
61M	60M	59M	58M	57M
70M	69M	68M	67M	66M
81M	80M	79M	78M	77M
90M	89M	88M	87M	86M
95M	94M	93M	92M	91M
100M	99M	98M	97M	96M

Terminal No.	Color of Wire	Signal Name
2	L	-

Connector No.	B116
Connector Name	REAR DOOR SWITCH RH
Connector Color	WHITE



Connector No.	B108
Connector Name	FRONT DOOR SWITCH RH (CREW CAB)
Connector Color	WHITE



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
INL


ABLIA5638GB

INTERIOR ROOM LAMP


< WIRING DIAGRAM >

[WITH POWER DOOR LOCKS]

Connector No.	R1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	B161
Connector Name	HIGH-MOUNTED STOP LAMP ASSEMBLY
Connector Color	WHITE




Connector No.	R10
Connector Name	ROOM LAMP 2ND ROW
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
9	R/Y	-
20	B	-
21	BR	-

Terminal No.	Color of Wire	Signal Name
2	B	-
3	G	-
21	BR	-

Terminal No.	Color of Wire	Signal Name
1	R/Y	-
2	Y	-
3	B	-



Terminal No.	Color of Wire	Signal Name
9	B	-
10	SB	-
11	W	-
12	LG	-
13	R/W	-



Terminal No.	Color of Wire	Signal Name
1	R/Y	-
2	Y	-
3	B	-
4	SB	-
5	W	-
6	LG	-
7	R/W	-


ABLIA6835GB

INTERIOR ROOM LAMP

< WIRING DIAGRAM >


[WITH POWER DOOR LOCKS]

Connector No.	D14
Connector Name	FRONT DOOR LOCK ASSEMBLY LH
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
3	RW	-
4	B	-
5	SB	-


Terminal No.	Color of Wire	Signal Name
10	LG	-
11	W	-
14	B	-




Connector No.	D7
Connector Name	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH
Connector Color	WHITE




10	B	-
----	---	---



3	RW	-
4	B	-
5	SB	-



1	LG	-
2	W	-
3	SB	-



2	LG	-(WITH KING CAB)
2	P	-(WITH CREW CAB)
3	P	-(WITH KING CAB)
3	W	-(WITH CREW CAB)

P

M

Z

O

K

INL

G

F

E

D

C

B


A

INTERIOR ROOM LAMP


< WIRING DIAGRAM >

[WITH POWER DOOR LOCKS]

Connector No.	D152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	D151
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
10	B	-

Terminal No.	Color of Wire	Signal Name
10	B	-
2	P	- (WITH CREW CAB)
2	P	- (WITH KING CAB)
3	P	- (WITH KING CAB)
3	W	- (WITH CREW CAB)

Terminal No.	Color of Wire	Signal Name
10	B	-

Terminal No.	Color of Wire	Signal Name
10	B	-
2	P	- (WITH CREW CAB)
2	P	- (WITH KING CAB)
3	P	- (WITH KING CAB)
3	W	- (WITH CREW CAB)




Terminal No.	Color of Wire	Signal Name
10	B	-

Terminal No.	Color of Wire	Signal Name
10	B	-
2	P	- (WITH CREW CAB)
2	P	- (WITH KING CAB)
3	P	- (WITH KING CAB)
3	W	- (WITH CREW CAB)



Terminal No.	Color of Wire	Signal Name
10	B	-

Terminal No.	Color of Wire	Signal Name
10	B	-
2	P	- (WITH CREW CAB)
2	P	- (WITH KING CAB)
3	P	- (WITH KING CAB)
3	W	- (WITH CREW CAB)



Terminal No.	Color of Wire	Signal Name
10	B	-

Terminal No.	Color of Wire	Signal Name
10	B	-
2	P	- (WITH CREW CAB)
2	P	- (WITH KING CAB)
3	P	- (WITH KING CAB)
3	W	- (WITH CREW CAB)

ABLIA6837GB

INTERIOR ROOM LAMP


< WIRING DIAGRAM >

[WITH POWER DOOR LOCKS]

Connector No.	D302
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	D216
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	B	-
8	LG	-

Terminal No.	Color of Wire	Signal Name
7	B	-
8	LG	-

Connector No.	D313
Connector Name	REAR DOOR SWITCH LOWER RH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	L	-
2	LG	-

Terminal No.	Color of Wire	Signal Name
1	L	-
2	LG	-



Terminal No.	Color of Wire	Signal Name
1	2	-
2	3	-

Terminal No.	Color of Wire	Signal Name
1	2	-
2	3	-

A

B

C

D

E

F

G

H

I

K

INL

M

N

O

P

ABLIA5642GB

ILLUMINATION


< WIRING DIAGRAM >

[WITH POWER DOOR LOCKS]

ILLUMINATION

Wiring Diagram

INFOID:0000000010711452




ABLWA2390GB

ILLUMINATION

[WITH POWER DOOR LOCKS]

< WIRING DIAGRAM >

- : WITH 4-WHEEL DRIVE
- : WITH AUTO A/C
- : WITH CLUTCH INTERLOCK CANCEL SWITCH
- : WITH ELECTRONIC LOCKING REAR DIFFERENTIAL
- : WITHOUT NAVI
- : WITH POWER OUTSIDE MIRRORS
- : WITH AUDIO AMPLIFIER
- : WITHOUT AUDIO AMPLIFIER
- : MANUAL WITH TYPE 1
- : MANUAL WITH TYPE 2
- : WITH NAVI
- : WITH BASE AUDIO SYSTEM FOR MEXICO
- : WITH DISPLAY AUDIO SYSTEM




ABLWA2808GB

A
B
C
D
E
F
G
H
I
J
K
L
INL
M
N
O
P

ILLUMINATION

< WIRING DIAGRAM >

[WITH POWER DOOR LOCKS]



* : THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PG SECTION.

ABLWA2820GB

ILLUMINATION CONNECTORS

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8P	R/Y	-
15P	W/R	-

Terminal No.	Color of Wire	Signal Name
6	W	-

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	P	INPUT 5
3	SB	INPUT 4
4	V	INPUT 3
5	L	INPUT 2
6	R	INPUT 1
32	BG	OUTPUT 5
33	GR	OUTPUT 4
34	G	OUTPUT 3
35	BR	OUTPUT 2
36	LG	OUTPUT 1
38	W/R	IGN SW
39	L	CANH
40	P	CANL

ABLIA6825GB

A

B

C

D

E

F

G

H

I

K

L

M

O

P


R

ILLUMINATION


< WIRING DIAGRAM >

[WITH POWER DOOR LOCKS]


Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE



Connector No.	M30
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1	LG	-
2	BR	-
3	G	-
4	GR	-
5	BG	-
6	R	-
7	L	-
8	P	-
9	SB	-
10	V	-




Terminal No.	Color of Wire	Signal Name
42G	R	-

Connector No.	M44
Connector Name	AUDIO UNIT (WITH DISPLAY AUDIO SYSTEM)
Connector Color	WHITE




Connector No.	M49
Connector Name	FRONT AIR CONTROL (MANUAL WITH TYPE 2)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
42G	R	-

Connector No.	M43
Connector Name	AUDIO UNIT (BASE AUDIO SYSTEM - EXCEPT FOR MEXICO)
Connector Color	WHITE



Connector No.	M44
Connector Name	AUDIO UNIT (WITH DISPLAY AUDIO SYSTEM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
8	GR	ILL (-)
9	R	ILL (+)

ILLUMINATION

< WIRING DIAGRAM >

[WITH POWER DOOR LOCKS]

Connector No.	M52
Connector Name	FRONT AIR CONTROL (WITH AUTO A/C)
Connector Color	BLACK



13	12	11	10	9	8	7	6	5	4	3	2	1
26	25	24	23	22	21	20	19	18	17	16	15	14



Connector No.	M50
Connector Name	FRONT AIR CONTROL (MANUAL WITH TYPE 1)
Connector Color	BLACK


13	12	11	10	9	8	7	6	5	4	3	2	1
26	25	24	23	22	21	20	19	18	17	16	15	14



Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
8	G	ILLUM+	3	R	-
9	BR	ILLUM-	4	BR	-

Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
8	G	ILLUM+	3	R	-
9	BR	ILLUM-	4	BR	-


Connector No.	M55
Connector Name	HAZARD SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
3	R	-	10	P	-
4	BR	-	11	L	-

Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
3	2	-	7	6	-
4	1	-	14	5	-
5	3	-	13	12	-
6	4	-	11	10	-
7	5	-	9	8	-

Connector No.	M76
Connector Name	ELECTRIC BRAKE (PRE-WIRING)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
1	B	-	2	—	-
4	R	-	4	—	-

Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
2	P	-	10	P	-
4	V	-	11	L	-

A B C D E F G H I J K L M N O P


INL INZ INO

ILLUMINATION

< WIRING DIAGRAM >

[WITH POWER DOOR LOCKS]


Connector No.	M94
Connector Name	SONAR SYSTEM OFF
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
3	R	LIGHT SW
4	BR	—


Terminal No.	Color of Wire	Signal Name
20	W	—
21	R	—

Connector No.	M96
Connector Name	AV CONTROL UNIT (WITH NAVI WITH AMPLIFIER)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
23	P	MR OUTPUT
44	GR	ILL CONT

Terminal No.	Color of Wire	Signal Name
23	P	MR OUTPUT
44	GR	ILL CONT




Connector No.	M107
Connector Name	AV CONTROL UNIT (WITH NAVI WITHOUT AMPLIFIER)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
9	R	LIGHT SW
20	W	—



Terminal No.	Color of Wire	Signal Name
23	P	MR OUTPUT
44	GR	ILL CONT




ILLUMINATION


< WIRING DIAGRAM >

[WITH POWER DOOR LOCKS]

Connector No.	M149
Connector Name	DIFFERENTIAL LOCK MODE SWITCH
Connector Color	GRAY



Connector No.	M141
Connector Name	4WD SHIFT SWITCH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
4	R	-
5	BR	-


Terminal No.	Color of Wire	Signal Name
7	R	-
8	BR	-

Terminal No.	Color of Wire	Signal Name
3	R	-
4	BR	-

Terminal No.	Color of Wire	Signal Name
1	2	3
2	4	5
3	6	7
4	8	9
5	10	11
6	12	13
7	14	15
8	16	-

Terminal No.	Color of Wire	Signal Name
15	BR	-
16	R	-

Connector No.	M155
Connector Name	HILL DESCENT CONTROL SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	R	-
6	BR	-

Terminal No.	Color of Wire	Signal Name
3	R	-
5	BR	-

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
INL
Z
M
O
P


ABLIA6829GB

ILLUMINATION

< WIRING DIAGRAM >


[WITH POWER DOOR LOCKS]

Connector No.	M161
Connector Name	FRONT HEATED SEAT SWITCH LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5	R	-
6	BR	-

Connector No.	M160
Connector Name	FRONT HEATED SEAT SWITCH RH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
5	SB	-
6	BG	-

Connector No.	M167
Connector Name	JOINT CONNECTOR-M02
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
5	R	-
6	BR	-



Terminal No.	Color of Wire	Signal Name
5	R	-
6	BR	-



Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-
4	P	-
10	L	-
11	L	-
13	L	-



ILLUMINATION

< WIRING DIAGRAM >

[WITH POWER DOOR LOCKS]


Connector No.	E124
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
38	B	GND (SIGNAL)	57	GR	TAIL LAMP
39	L	CAN-H	59	B	GND (POWER)
40	P	CAN-L			




Connector No.	E122
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
10	P	-
11	L	-

Terminal No.	Color of Wire	Signal Name
10	P	-
11	L	-

Connector No.	E26
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



ABLIA6831GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

INL

SYMPTOM DIAGNOSIS

INTERIOR LIGHTING SYSTEM SYMPTOMS

Symptom Table

INFOID:000000010711453

CAUTION:

Perform the self-diagnosis with CONSULT before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom	Possible cause	Inspection item
All of the following lamps do not turn ON • Front room/map lamp assembly • Room lamp 2nd row • Vanity mirror lamps • Ignition keyhole illumination	<ul style="list-style-type: none"> • Harness between BCM and each interior room lamp • Harness between BCM and each door switch • BCM 	Battery saver output/power supply circuit Refer to INL-16 .
Some or all of the following interior room lamps do not turn ON/OFF • Front room/map lamp assembly • Room lamp 2nd row	<ul style="list-style-type: none"> • Harness between BCM and each interior room lamp • BCM 	Interior room lamp control circuit Refer to INL-18 .
Cargo lamp does not turn ON/OFF	<ul style="list-style-type: none"> • Harness between fuse block (J/B) and cargo lamp relay • Harness between cargo lamp relay and cargo lamp • Harness between BCM and cargo lamp relay • BCM 	Cargo lamp control circuit Refer to INL-20 .
Ignition keyhole illumination does not turn ON/OFF	<ul style="list-style-type: none"> • Harness between BCM and ignition keyhole illumination • BCM 	Ignition keyhole illumination circuit Refer to INL-24
Interior room lamp timer does not activate. (It turns ON/ OFF when the door opens/closes.)	—	Check the interior room lamp setting. Refer to INL-12, "INT LAMP : CONSULT Function (BCM - INT LAMP)" .
Interior room lamp battery saver does not activate.	—	Check the interior room lamp battery saver setting. Refer to BCS-23, "BATTERY SAVER : CONSULT Function (BCM - BATTERY SAVER)" .

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000010711454

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

Precaution for Work

INFOID:0000000010711455

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
 - Water soluble dirt:
 - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
 - Then rub with a soft, dry cloth.
 - Oily dirt:
 - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
 - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
 - Then rub with a soft, dry cloth.
 - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
 - For genuine leather seats, use a genuine leather seat cleaner.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

PREPARATION

< PREPARATION >

[WITH POWER DOOR LOCKS]

PREPARATION


PREPARATION

Special Service Tool

INFOID:000000010711456

The actual shape of the tools may differ from those illustrated here.

Tool number (TechMate No.) Tool name	Description
— (J-46534) Trim Tool Set	Removing trim components



AWJIA0483ZZ

REMOVAL AND INSTALLATION

INTERIOR ROOM LAMP


Removal and Installation

INFOID:0000000010711457

FRONT ROOM/MAP LAMP ASSEMBLY

Removal

- Using a suitable tool, release the metal clips and drop the front room/map lamp assembly away from the headlining.
←: Front
[]: Metal clip
- Disconnect the harness connectors from the front room/map lamp assembly and remove.




Installation

Installation is in the reverse order of removal.

Bulb or Lens Replacement

- Using a suitable tool (A), remove the front room/map lamp RH and/or LH lenses (1) as necessary.
←: Front
[]: Pawl
- Release one side of the bulb (2) from the tab using a suitable tool, then pull straight downward to remove.

**Front room/
map lamp as-
sembly bulb** : 12V - 8W



- Install the new bulb into the socket tabs.
- Install the front room/map lamp lens(es).

VANITY LAMP


Removal

INTERIOR ROOM LAMP

< REMOVAL AND INSTALLATION >

[WITH POWER DOOR LOCKS]

The vanity lamp is replaced as part of the sun visor assembly. Refer to [INT-25, "Removal and Installation"](#).



Installation

Installation is in the reverse order of removal.


Bulb Replacement

The vanity mirror lamp bulb is replaced as part of the sun visor assembly. Refer to [INT-25, "Removal and Installation"](#).

ROOM LAMP 2ND ROW

Removal

1. Using a suitable tool (A), release the pawls and remove the room lamp lens (1).
①: Pawl
2. Remove room lamp screws (2).
3. Disconnect the harness connector from the room lamp and remove.




Installation

Installation is in the reverse order of removal.

Bulb or Lens Replacement

1. Using a suitable tool, release the room lamp lens.
2. Release the room lamp bulb retainers (1), then pull bulb (2) straight out to remove.
3. Install the bulb (2) securely into the room lamp bulb retainers (1).

Room lamp bulb : 12V - 8W



INTERIOR ROOM LAMP

< REMOVAL AND INSTALLATION >

[WITH POWER DOOR LOCKS]

4. Install the room lamp lens.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O


P

ILLUMINATION**Removal and Installation**

INFOID:0000000010711458

ILLUMINATION CONTROL SWITCH**Removal**


The illumination control switch is replaced as a part of the combination meter. Refer to [MWI-91, "Removal and Installation"](#).

**Installation**

Installation is in the reverse order of removal.

SHIFT SELECTOR FINISHER LAMP**Removal**

1. Remove shift selector finisher from center console. Refer to [IP-25, "Removal and Installation"](#).
2. Rotate shift selector finisher lamp socket (2) with bulb (3) counterclockwise, then pull away from finisher (1).


**Installation**

Installation is in the reverse order of removal.

Bulb Replacement

1. Remove shift selector finisher from center console. Refer to [IP-25, "Removal and Installation"](#).
2. Remove shift selector finisher lamp socket (1), then pull bulb (2) straight out away from socket.
3. Install the bulb (2) into the shift selector finisher socket (1).

AT finisher lamp bulb : 12V - 3W



4. Install shift selector finisher in center console. Refer to [IP-25, "Removal and Installation"](#).

BULB SPECIFICATIONS

< SERVICE DATA AND SPECIFICATIONS (SDS)

[WITH POWER DOOR LOCKS]

SERVICE DATA AND SPECIFICATIONS (SDS)

BULB SPECIFICATIONS

Bulb Specifications

INFOID:000000010711459

Item	Wattage (W)*
Front room/map lamp	8
Vanity lamp	—
Room lamp 2nd row	8
Shift selector finisher lamp	3

*: Always check with the Parts Department for the latest parts information.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[WITHOUT POWER DOOR LOCKS]


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000010711460

OVERALL SEQUENCE



AWLIA1837GB

DIAGNOSIS AND REPAIR WORKFLOW

[WITHOUT POWER DOOR LOCKS]

< BASIC INSPECTION >

DETAILED FLOW

1. INTERVIEW FOR MALFUNCTION

Find out what the customer's concerns are.

>> GO TO 2.

2. SYMPTOM CHECK

Verify the symptom from the customer's information.

>> GO TO 3.

3. BASIC INSPECTION

Check the operation of each part. Check that any concerns occur other than those mentioned in the customer interview.

>> GO TO 4.

4. SELF-DIAGNOSIS WITH CONSULT

Perform the self-diagnosis with CONSULT. Check that any DTC is detected.

Is any DTC detected?

YES >> GO TO 5.

NO >> GO TO 6.

5. TROUBLE DIAGNOSIS BY DTC

Perform the trouble diagnosis for the detected DTC. Specify the malfunctioning part.

>> GO TO 9.

6. FAIL-SAFE ACTIVATION CHECK

Determine if the customer's concern is related to fail-safe activation.

Does the fail-safe activate?

YES >> GO TO 7.

NO >> GO TO 8.

7. SYSTEM DIAGNOSIS

Perform the system diagnosis for the system in which the fail-safe activates. Specify the malfunctioning part.

INL

>> GO TO 9.

8. SYMPTOM DIAGNOSIS

Perform the symptom diagnosis. Specify the malfunctioning part.

M

N

>> GO TO 9.

9. MALFUNCTION PART REPAIR

Repair or replace the malfunctioning part.

O

P

>> GO TO 10.

10. REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT)

Perform the self-diagnosis with CONSULT. Verify that no DTCs are detected. Erase all DTCs detected prior to the repair. Verify that DTC is not detected again.

Is any DTC detected?

YES >> GO TO 5.

DIAGNOSIS AND REPAIR WORKFLOW

[WITHOUT POWER DOOR LOCKS]

< BASIC INSPECTION >

NO >> GO TO 11.

11. REPAIR CHECK (OPERATION CHECK)

Check the operation of each part.

Does it operate normally?

YES >> Inspection End.


NO >> GO TO 3.

SYSTEM DESCRIPTION

INTERIOR ROOM LAMP

System Diagram

INFOID:0000000010711461



ALLIA1589GB

System Description

INFOID:0000000010711462

OUTLINE

- Room lamp 2nd row and front room/map lamp are powered by fuse block (J/B) fuse number 21 (10A). When the lamp is set to the DOOR position, ground is provided through the door switches.
- Cargo lamp is controlled by the cargo lamp control function of the BCM.

A
B
C
D
E
F
G
H
I
J
K
L
INL
M
N
O
P


INTERIOR ROOM LAMP

< SYSTEM DESCRIPTION >

[WITHOUT POWER DOOR LOCKS]

Component Parts Location

INFOID:000000010711463



1. BCM M18, M19, M20 (view with lower instrument panel LH removed)
2. Key switch M27
3. Cargo lamp switch M71
4. Front door switch LH B8 (crew cab)
Front door switch RH B108 (crew cab)
5. Rear door switch LH B18 (crew cab)
Rear door switch RH B116 (crew cab)
6. Front door switch LH D213 (king cab)
Front door switch RH D314 (king cab)
7. Cargo lamp B161
8. Room lamp 2nd row R10
9. Front room/map lamp assembly R9 (if equipped)

Component Description

INFOID:000000010711464

Part name	Description
BCM	Provides ground for the cargo lamp relay.
Key switch	Provides key in ignition status to the BCM.

INTERIOR ROOM LAMP

< SYSTEM DESCRIPTION >

[WITHOUT POWER DOOR LOCKS]

Door switches	Provides door OPEN/CLOSED status to the BCM. Provides ground for the room lamp 2nd row.	A
Cargo lamp switch	Provides cargo lamp ON/OFF request to the BCM.	B
		C
		D
		E
		F
		G
		H
		I
		J
		K
		INL
		M
		N
		O
		P

ILLUMINATION CONTROL SYSTEM


< SYSTEM DESCRIPTION >

[WITHOUT POWER DOOR LOCKS]

ILLUMINATION CONTROL SYSTEM

System Diagram

INFOID:0000000010711465



ALLIA1505GB

System Description

INFOID:0000000010711466

The illumination lamps operation is dependent upon the position of the combination switch (lighting and turn signal switch). When the combination switch (lighting and turn signal switch) is placed in the 1ST or 2ND position (or if the auto light system is activated) the BCM (body control module) receives input requesting the parking lamps to illuminate. This input is communicated to the IPDM E/R (intelligent power distribution module engine room) via the CAN communication lines. The CPU (central processing unit) of the IPDM E/R controls the tail lamp relay coil. When energized, this relay directs power to the parking and illumination lamps, which then illuminate.

BATTERY SAVER CONTROL

When the combination switch (lighting and turn signal switch) is in the 1ST or 2ND position and the ignition switch is turned from ON or ACC to OFF, the battery saver control feature is activated. Under this condition, the illumination lamps remain illuminated for 10 minutes unless the combination switch (lighting and turn signal switch) position is changed. If the combination switch (lighting and turn signal switch) position is changed, then the illumination lamps are turned off after a 30 second delay. When the combination switch (lighting and turn signal switch) is turned from OFF to 1ST or 2ND position (or if auto light system is activated) after illumination lamps have been turned off by the battery saver control, the illumination lamps illuminate again.


ILLUMINATION CONTROL SYSTEM

< SYSTEM DESCRIPTION >

[WITHOUT POWER DOOR LOCKS]

Component Parts Location

INFOID:000000010711467



WKIA5029E

1. IPDM E/R E122, E124
2. Combination switch (lighting and turn signal switch) M28
3. Combination meter M24
4. Illumination control switch (built into combination meter)
5. BCM M18, M20 (view with lower instrument panel LH removed)

Component Description

INFOID:000000010711468

INL

Part name	Description
BCM	The BCM monitors the lighting switch position with the combination switch reading function. The BCM requests, via CAN communication, that the IPDM E/R activate the tail lamp relay.
IPDM E/R	The IPDM E/R activates the tail lamp relay based on inputs received from the BCM via the CAN communication network.
Combination meter (illumination control switch)	The illumination control switch is a part of the combination meter. The combination meter controls illumination intensity by varying ground to the illumination lamps based on the illumination control switch position.
Combination switch (lighting and turn signal switch)	The combination switch (lighting and turn signal switch) provides input to the BCM about the lighting switch position.

M

N

O

P

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[WITHOUT POWER DOOR LOCKS]

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000011343362

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Direct Diagnostic Mode	Description
ECU Identification	The BCM part number is displayed.
Self Diagnostic Result	The BCM self diagnostic results are displayed.
Data Monitor	The BCM input/output data is displayed in real time.
Active Test	The BCM activates outputs to test components.
Work support	The settings for BCM functions can be changed.
Configuration	<ul style="list-style-type: none">• The vehicle specification can be read and saved.• The vehicle specification can be written when replacing BCM.
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

SYSTEM APPLICATION

BCM can perform the following functions.

System	Sub System	Direct Diagnostic Mode						
		ECU Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
Door lock	DOOR LOCK			×	×	×		
Rear window defogger	REAR DEFOGGER			×	×			
Warning chime	BUZZER			×	×			
Interior room lamp timer	INT LAMP			×	×	×		
Remote keyless entry system	MULTI REMOTE ENT			×	×	×		
Exterior lamp	HEAD LAMP			×	×	×		
Wiper and washer	WIPER			×	×	×		
Turn signal and hazard warning lamps	FLASHER			×	×			
Air conditioner	AIR CONDITIONER			×				
Combination switch	COMB SW			×				
BCM	BCM	×	×			×	×	×
Immobilizer	IMMU		×	×	×			
Interior room lamp battery saver	BATTERY SAVER			×	×	×		
Vehicle security system	THEFT ALM			×	×	×		
RAP system	RETAINED PWR			×	×	×		
Signal buffer system	SIGNAL BUFFER			×	×			
TPMS	AIR PRESSURE MONITOR		×	×	×	×		
Panic alarm system	PANIC ALARM				×			

INT LAMP

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[WITHOUT POWER DOOR LOCKS]

INT LAMP : CONSULT Function (BCM - INT LAMP)

INFOID:000000011343364

DATA MONITOR

Monitor Item [Unit]	Description
IGN ON SW [On/Off]	Indicates condition of ignition switch ON position.
KEY ON SW [On/Off]	Indicates condition of key switch.
DOOR SW-DR [On/Off]	Indicates condition of front door switch LH.
DOOR SW-AS [On/Off]	Indicates condition of front door switch RH.
DOOR SW-RR [On/Off]	Indicates condition of rear door switch RH.
DOOR SW-RL [On/Off]	Indicates condition of rear door switch LH.
KEY CYL LK-SW [On/Off]	Indicates condition of lock signal from door key cylinder switch.
KEY CYL UN-SW [On/Off]	Indicates condition of unlock signal from door key cylinder switch.
CDL LOCK SW [On/Off]	Indicates condition of lock signal from door lock and unlock switch.
CDL UNLOCK SW [On/Off]	Indicates condition of unlock signal from door lock and unlock switch.
KEYLESS LOCK [On/Off]	Indicates condition of lock signal from keyfob.
KEYLESS UNLOCK [On/Off]	Indicates condition of unlock signal from keyfob.

ACTIVE TEST

Test Item	Description
IGN ILLUM	This test is able to check ignition keyhole illumination operation [Off/On].
INT LAMP	This test is able to check interior room lamp operation [Off/On].

WORK SUPPORT

Support Item	Setting	Description
SET I/L D-UNLCK INTCON	Off	Interior room lamp timer function OFF.
	On*	Interior room lamp timer function ON.
ROOM LAMP ON TIME SET	MODE7 0 sec.	Sets the interior room lamp gradual brightening time.
	MODE6 5 sec.	
	MODE5 4 sec.	
	MODE4 3 sec.	
	MODE3 2 sec.	
	MODE2* 1 sec.	
	MODE1 0.5 sec.	
ROOM LAMP OFF TIME SET	MODE7 0 sec.	Sets the interior room lamp gradual dimming time.
	MODE6 5 sec.	
	MODE5 4 sec.	
	MODE4 3 sec.	
	MODE3 2 sec.	
	MODE2* 1 sec.	
	MODE1 0.5 sec.	

* : Initial setting

DTC/CIRCUIT DIAGNOSIS**INTERIOR ROOM LAMP****Diagnosis Procedure**

INFOID:000000010711471

Regarding Wiring Diagram information, refer to [INL-95, "Wiring Diagram - Without Power Door Lock System"](#).

CAUTION:

Before performing the diagnosis, check that the following is normal:

- **Fuse**
- **Interior room lamp bulbs**

1.CHECK INTERIOR ROOM LAMP POWER SUPPLY

Check voltage between interior room lamp connectors and ground.

Component	(+)		(-)	Voltage
	Connector	Terminal		
Room lamp 2nd row	R10	2	Ground	Battery voltage
Front room/map lamp	R9	1		

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the harness or connectors.

2.CHECK INTERIOR ROOM LAMP GROUND

1. Turn ignition switch OFF.
2. Disconnect BCM connectors M18, M19, room lamp 2nd row connector R10 and front room/map lamp connector R9.
3. Check continuity between interior room lamp connectors and ground while opening/closing the door.

Component	(+)		(-)	Door states	Continuity
	Connector	Terminal			
Room lamp 2nd row	R10	1	Ground	Open	Yes
Front room/map lamp		2		Closed	No
	R9	1	Ground	Open	Yes
				Closed	No

Is the inspection result normal?

YES >> Replace the interior room lamp. Refer to [INL-63, "Removal and Installation"](#).

NO >> GO TO 3.

3.CHECK DOOR SWITCHES

Check the door switches. Refer to [INL-79, "Component Inspection \(Door Switch\)"](#).

Is the inspection result normal?

YES >> • Crew cab models, repair the harness or connectors between the interior room lamp and the door switches.
• King cab models, GO TO 4.

NO >> Replace the door switch.

4.CHECK DOOR SWITCH GROUND (KING CAB)

INTERIOR ROOM LAMP

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT POWER DOOR LOCKS]


Check continuity between door switch connectors and ground.

Component	(+)		(-)	Continuity
	Connector	Terminal		
Front door switch LH	D213	3	Ground	Yes
Front door switch RH	D314	3		

Is the inspection result normal?

YES >> Repair the harness or connectors between the interior room lamp and the door switches.

NO >> Repair the harness or connectors between the door switch and ground.



Component Inspection (Door Switch)

INFOID:000000010711472

CREW CAB

1. CHECK DOOR SWITCHES


1. Disconnect door switch.
2. Check continuity between door switch terminal 1 and ground.

	Terminal	Condition	Continuity
Door switch	1 – Ground	Open	Yes
		Closed	No

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace door switch.



KING CAB

1. CHECK DOOR SWITCHES


1. Disconnect door switch.
2. Check continuity between door switch terminals 1 and 3.

Item	Terminal	Condition	Continuity
Door switches	1 – 3	Open	Yes
		Closed	No

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace door switch.



CARGO LAMP CONTROL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT POWER DOOR LOCKS]

CARGO LAMP CONTROL CIRCUIT

Description

INFOID:0000000010711473

Controls the cargo lamp relay coil (ground side) to turn the cargo lamp ON and OFF.

Diagnosis Procedure

INFOID:0000000010711474

Regarding Wiring Diagram information, refer to [INL-95, "Wiring Diagram - Without Power Door Lock System"](#).

CAUTION:

Before performing the diagnosis, check that the following is normal:

- Fuse
- Cargo lamp bulb

1. CHECK CARGO LAMP OPERATION

Check the cargo lamp operation from the cargo lamp switch, the door switches, and a keyfob (if equipped).

Is the cargo lamp operative from all of the above switches and the keyfob?

YES >> At this time, the cargo lamp operates normally.

NO >> • Inoperative from all the above switches and the keyfob, GO TO 6.

- Inoperative from cargo lamp switch only, GO TO 2.
- Inoperative from door switches only, refer to [DLK-27, "KING CAB : Description"](#) (king cab), [DLK-29, "CREW CAB : Description"](#) (crew cab).
- Inoperative from keyfob only, refer to [DLK-51, "Description"](#).
- Fixed ON, GO TO 2.

2. CHECK CARGO LAMP SWITCH

Check the cargo lamp switch. Refer to [INL-82, "Component Inspection"](#).

Is the inspection result normal?

YES >> • For inoperative from cargo lamp switch only, GO TO 3.
• For fixed ON, GO TO 5.

NO >> Replace the cargo lamp switch.

3. CHECK CARGO LAMP SWITCH CIRCUIT OPEN

1. Disconnect BCM connector M18 and cargo lamp switch connector.
2. Check continuity between BCM connector M18 terminal 31 and cargo lamp switch connector M71 terminal 1.

BCM		Cargo lamp switch		Continuity
Connector	Terminal	Connector	Terminal	
M18	31	M71	1	Yes

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair harness or connectors.

4. CHECK CARGO LAMP SWITCH GROUND CIRCUIT

1. Check continuity between cargo lamp switch connector M71 terminal 3 and ground.

Connector	Terminal	-	Continuity
M71	3	Ground	Yes

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-51, "Removal and Installation"](#).

NO >> Repair harness or connectors.

CARGO LAMP CONTROL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT POWER DOOR LOCKS]

5.CHECK CARGO LAMP SWITCH CIRCUIT SHORT

1. Disconnect BCM connector M18 and cargo lamp switch connector.
2. Check continuity between BCM connector M18 terminal 31 and ground.

Connector	Terminal	-	Continuity
M18	31	Ground	No

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair harness or connectors.

6.CHECK CARGO LAMP RELAY

Check the cargo lamp relay. Refer to [INL-82, "Component Inspection"](#).

Is the inspection result normal?

YES >> • For fixed OFF, GO TO 7.
• For fixed ON, GO TO 13.

NO >> Replace the cargo lamp relay.

7.CHECK CARGO LAMP RELAY CONTROL


While operating the cargo lamp switch, check voltage between BCM connector M19 terminal 50 and ground.

Connector	Terminal	-	Cargo lamp switch	Voltage
M19	50	Ground	ON	0V
			OFF	Battery voltage

Is the inspection result normal?

YES >> GO TO 8.

NO >> GO TO 11.



8.CHECK CARGO LAMP VOLTAGE

1. Disconnect the cargo lamp connector.
2. While operating the cargo lamp switch, check voltage between cargo lamp connector B161 terminal 3 and ground.

Connector	Terminal	-	Cargo lamp switch	Voltage
B161	3	Ground	ON	Battery voltage

Is the inspection result normal?

YES >> GO TO 9.

NO >> GO TO 10.

9.CHECK CARGO LAMP GROUND CIRCUIT

1. While operating the cargo lamp switch, check voltage between cargo lamp connector B161 terminal 3 and terminal 2.

Connector	Terminal (+)	Terminal (-)	Cargo lamp switch	Voltage
B161	3	2	ON	Battery voltage

Is the inspection result normal?

YES >> Replace cargo lamp.

NO >> Repair harness or connectors.

10.CHECK CARGO LAMP RELAY VOLTAGE PART 1

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

CARGO LAMP CONTROL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT POWER DOOR LOCKS]


Check voltage between cargo lamp relay connector M165 terminal 5 and ground.

Cargo lamp relay		Ground	Voltage
Connector	Terminal		Battery voltage
M165	5		

Is the inspection result normal?

YES >> Repair harness or connectors between cargo lamp relay and cargo lamp.

NO >> Repair harness or connector between splice and cargo lamp relay.



11. CHECK CARGO LAMP RELAY VOLTAGE PART 2


Check voltage between cargo lamp relay connector M165 terminal 2 and ground.

Cargo lamp relay		Ground	Voltage
Connector	Terminal		Battery voltage
M165	2		

Is the inspection result normal?

YES >> GO TO 12.

NO >> Repair harness or connectors.



12. CHECK CARGO LAMP RELAY CONTROL CIRCUIT OPEN

1. Disconnect BCM connector M19 and cargo lamp relay.
2. Check continuity between BCM connector M19 terminal 50 and cargo lamp relay connector M165 terminal 1.

BCM		Cargo lamp relay		Continuity
Connector	Terminal	Connector	Terminal	
M19	50	M165	1	Yes

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-51, "Removal and Installation"](#).

NO >> Repair harness or connectors.

13. CHECK CARGO LAMP RELAY CONTROL CIRCUIT SHORT

1. Disconnect BCM connector M19 and cargo lamp relay.
2. Check continuity between BCM connector M19 terminal 50 and ground.

Connector	Terminal	-	Continuity
M19	50	Ground	No

Is the inspection result normal?

YES >> Replace BCM after making sure the cargo lamp power supply circuit is not shorted to voltage. Refer to [BCS-51, "Removal and Installation"](#).

NO >> Repair harness or connectors.

Component Inspection

INFOID:0000000010711475

CARGO LAMP SWITCH

1. CHECK CARGO LAMP SWITCH

CARGO LAMP CONTROL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >


[WITHOUT POWER DOOR LOCKS]

1. Turn ignition switch OFF.
2. Disconnect cargo lamp switch connector.
3. Check continuity between cargo lamp switch terminals 1 and 3.

Cargo lamp switch	Condition	Continuity
Terminal		
1 – 3	ON	Yes
	OFF	No

Is the inspection result normal?

- YES >> Inspection End.
 NO >> Replace cargo lamp switch.



CARGO LAMP RELAY


1. CHECK CARGO LAMP RELAY

1. Turn ignition switch OFF.
2. Disconnect cargo lamp relay.
3. Supply power to terminal 2 and ground to terminal 1 of the cargo lamp relay.
4. Check continuity between cargo lamp relay terminals 3 and 5.

Terminal	Condition	Continuity
3 5	Power and ground supplied to terminals 1 and 2	Yes
	No power and ground supplied	No

Is the inspection result normal?

- YES >> Inspection End.
 NO >> Replace cargo lamp relay.



ECU DIAGNOSIS INFORMATION

BCM (BODY CONTROL MODULE)

Reference Value

INFOID:000000011343370

NOTE:

The Signal Tech II Tool [– (J-50190)] can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs
- Test remote keyless entry keyfob relative signal strength

VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Condition	Value/Status
ACC ON SW	Ignition switch OFF or ON	Off
	Ignition switch ACC	On
AIR COND SW	A/C switch OFF	Off
	A/C switch ON	On
AIR PRESS FL	Front left tire air pressure value	kPa, kg/cm ² , psi
AIR PRESS FR	Front right tire air pressure value	kPa, kg/cm ² , psi
AIR PRESS RL	Rear left tire air pressure value	kPa, kg/cm ² , psi
AIR PRESS RR	Rear right tire air pressure value	kPa, kg/cm ² , psi
AUTO LIGHT SW	Lighting switch OFF	Off
	Lighting switch AUTO	On
BRAKE SW	Brake pedal released	Off
	Brake pedal applied	On
BUCKLE SW	Seat belt buckle unfastened	Off
	Seat belt buckle fastened	On
BUZZER	Buzzer in combination meter OFF	Off
	Buzzer in combination meter ON	On
CARGO LAMP SW	Cargo lamp switch OFF	Off
	Cargo lamp switch ON	On
CDL LOCK SW	Door lock/unlock switch does not operate	Off
	Press door lock/unlock switch to the LOCK side	On
CDL UNLOCK SW	Door lock/unlock switch does not operate	Off
	Press door lock/unlock switch to the UNLOCK side	On
DOOR SW-AS	Front door RH closed	Off
	Front door RH opened	On
DOOR SW-DR	Front door LH closed	Off
	Front door LH opened	On
DOOR SW-RL	Rear door LH closed	Off
	Rear door LH opened	On
DOOR SW-RR	Rear door RH closed	Off
	Rear door RH opened	On

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITHOUT POWER DOOR LOCKS]

Monitor Item	Condition	Value/Status
FAN ON SIG	Blower motor fan switch OFF	Off
	Blower motor fan switch ON	On
FR FOG SW	Front fog lamp switch OFF	Off
	Front fog lamp switch ON	On
FR WASHER SW	Front washer switch OFF	Off
	Front washer switch ON	On
FR WIPER LOW	Front wiper switch OFF	Off
	Front wiper switch LO	On
FR WIPER HI	Front wiper switch OFF	Off
	Front wiper switch HI	On
FR WIPER INT	Front wiper switch OFF	Off
	Front wiper switch INT	On
FR WIPER STOP	Any position other than front wiper stop position	Off
	Front wiper stop position	On
HAZARD SW	When hazard switch is not pressed	Off
	When hazard switch is pressed	On
HEAD LAMP SW 1	Headlamp switch OFF	Off
	Headlamp switch 1st	On
HEAD LAMP SW 2	Headlamp switch OFF	Off
	Headlamp switch 1st	On
HI BEAM SW	High beam switch OFF	Off
	High beam switch HI	On
ID REGST FL1	ID registration of front left tire incomplete	YET
	ID registration of front left tire complete	DONE
ID REGST FR1	ID registration of front right tire incomplete	YET
	ID registration of front right tire complete	DONE
ID REGST RL1	ID registration of rear left tire incomplete	YET
	ID registration of rear left tire complete	DONE
ID REGST RR1	ID registration of rear right tire incomplete	YET
	ID registration of rear right tire complete	DONE
IGN ON SW	Ignition switch OFF or ACC	Off
	Ignition switch ON	On
IGN SW CAN	Ignition switch OFF or ACC	Off
	Ignition switch ON	On
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	1 - 7
KEY CYL LK-SW	Door key cylinder LOCK position	Off
	Door key cylinder other than LOCK position	On
KEY CYL UN-SW	Door key cylinder UNLOCK position	Off
	Door key cylinder other than UNLOCK position	On
KEY ON SW	Mechanical key is removed from key cylinder	Off
	Mechanical key is inserted to key cylinder	On
KEYLESS LOCK	LOCK button of key fob is not pressed	Off
	LOCK button of key fob is pressed	On

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITHOUT POWER DOOR LOCKS]

Monitor Item	Condition	Value/Status
KEYLESS PANIC	PANIC button of key fob is not pressed	Off
	PANIC button of key fob is pressed	On
KEYLESS UNLOCK	UNLOCK button of key fob is not pressed	Off
	UNLOCK button of key fob is pressed	On
LIGHT SW 1ST	Lighting switch OFF	Off
	Lighting switch 1st	On
OIL PRESS SW	<ul style="list-style-type: none"> • Ignition switch OFF or ACC • Engine running 	Off
	Ignition switch ON	On
OPTICAL SENSOR	Bright outside of the vehicle	Close to 5V
	Dark outside of the vehicle	Close to 0V
PASSING SW	Other than lighting switch PASS	Off
	Lighting switch PASS	On
REAR DEF SW	Rear window defogger switch OFF	Off
	Rear window defogger switch ON	On
TURN SIGNAL L	Turn signal switch OFF	Off
	Turn signal switch LH	On
TURN SIGNAL R	Turn signal switch OFF	Off
	Turn signal switch RH	On
VEHICLE SPEED	While driving	Equivalent to speedometer reading
WARNING LAMP	Low tire pressure warning lamp in combination meter OFF	Off
	Low tire pressure warning lamp in combination meter ON	On

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITHOUT POWER DOOR LOCKS]

Terminal Layout

INFOID:000000011343371

A

B

C

D

E

F

G

H

I

J

K


INL

M

N

O

P



Physical Values





AWMIA1598ZZ

INFOID:000000011343372

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >




[WITHOUT POWER DOOR LOCKS]

Terminal	Wire color	Item	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
1	BR	Ignition keyhole illumination	Output	OFF	Door is locked (SW OFF)	Battery voltage
					Door is unlocked (SW ON)	0V
2	P	Combination switch input 5	Input	ON	Lighting, turn, wiper OFF Wiper dial position 4	
					 <small>(V)</small> <small>5ms</small>	
3	SB	Combination switch input 4	Input	ON	Lighting, turn, wiper OFF Wiper dial position 4	
					 <small>(V)</small> <small>5ms</small>	
4	V	Combination switch input 3	Input	ON	Lighting, turn, wiper OFF Wiper dial position 4	
					 <small>(V)</small> <small>5ms</small>	
5	L	Combination switch input 2	Input	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <small>(V)</small> <small>5ms</small>
6	R	Combination switch input 1			Lighting, turn, wiper OFF Wiper dial position 4	
7	GR	Front door lock assembly LH (key cylinder switch) unlock	Input	OFF	ON (open, 2nd turn)	Momentary 1.5V
					OFF (closed)	0V
8	SB	Front door lock assembly LH (key cylinder switch) lock	Input	OFF	On (open)	Momentary 1.5V
					OFF (closed)	0V
9	LG	Brake sw	Input	OFF	OFF (brake pedal is not depressed)	0V
					ON (brake pedal is depressed)	Battery voltage
11	G/B	Ignition switch (ACC or ON)	Input	ACC or ON	Ignition switch ACC or ON	Battery voltage
12	LG	Front door switch RH (All)	Input	OFF	ON (open)	0V
		Rear door switch upper RH (King Cab)			OFF (closed)	
		Rear door switch lower RH (King Cab)			Battery voltage	

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITHOUT POWER DOOR LOCKS]

Terminal	Wire color	Item	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
13	L	Rear door switch RH (Crew Cab)	Input	OFF	ON (open)	0V
					OFF (closed)	Battery voltage
15	W	Tire pressure warning check connector	Input	OFF	—	5V
18	BR	Remote keyless entry receiver and optical sensor (Ground)	Output	OFF	—	0V
19	V	Remote keyless entry receiver (power supply)	Output	OFF	Ignition switch OFF	 <small>LIIA1893E</small>
20	G	Remote keyless entry receiver signal (Signal)	Input	OFF	Stand-by (keyfob buttons released)	 <small>LIIA1894E</small>
					When remote keyless entry receiver receives signal from keyfob (keyfob buttons pressed)	 <small>LIIA1895E</small>
21	GR	NATS antenna amp.	Input	OFF → ON	Ignition switch (OFF → ON)	Just after turning ignition switch ON: Pointer of tester should move.
23	G	Security indicator lamp	Output	OFF	Goes OFF → illuminates (Every 2.4 seconds)	Battery voltage → 0V
25	BR	NATS antenna amp.	Input	OFF → ON	Ignition switch (OFF → ON)	Just after turning ignition switch ON: Pointer of tester should move.
27	W	Compressor ON signal	Input	ON	A/C switch OFF	5V
					A/C switch ON	0V
28	R	Front blower monitor	Input	ON	Front blower motor OFF	Battery voltage
					Front blower motor ON	0V
29	G	Hazard switch	Input	OFF	ON	0V
					OFF	5V
31	GR	Cargo lamp switch	Input	OFF	ON	0V
					OFF	Battery voltage

A

B

C

D

E

F

G

H

I

J

K

INL

M

N





O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >





[WITHOUT POWER DOOR LOCKS]

Terminal	Wire color	Item	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
32	BG	Combination switch output 5	Output	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5291E
33	GR	Combination switch output 4	Output	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5292E
34	G	Combination switch output 3	Output	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5291E
35	BR	Combination switch output 2	Output	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5292E
36	LG	Combination switch output 1				
37	B	Key switch	Input	OFF	Key inserted	Battery voltage
					Key removed	0V
38	W/R	Ignition switch (ON)	Input	ON	—	Battery voltage
39	L	CAN high	—	—	—	—
40	P	CAN low	—	—	—	—
41	Y	Rear window defogger switch	Input	ON	Rear window defogger switch ON	0V
					Rear window defogger switch OFF	5V
45	V	Lock switch	Input	OFF	ON (lock)	0V
					OFF	Battery voltage
46	LG	Unlock switch	Input	OFF	ON (unlock)	0V
					OFF	Battery voltage
47	GR	Front door switch LH (All)	Input	OFF	ON (open)	0V
		Rear door switch upper LH (King Cab)			OFF (closed)	Battery voltage
		Rear door switch lower LH (King Cab)				

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITHOUT POWER DOOR LOCKS]

Terminal	Wire color	Item	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
48	P	Rear door switch LH (Crew Cab)	Input	OFF	ON (open)	0V
					OFF (closed)	Battery voltage
50	P	Cargo lamp	Output	OFF	Any door open (ON)	0V
					All doors closed (OFF)	Battery voltage
51	BG	Trailer turn signal (right)	Output	ON	Turn right ON	
					 SKIA3009J	
52	LG	Trailer turn signal (left)	Output	ON	Turn left ON	
					 SKIA3009J	
56	R/Y	Battery saver output	Output	OFF	10 minutes after ignition switch is turned OFF	0V
				ON	—	Battery voltage
57	R/Y	Battery power supply	Input	—	—	Battery voltage
58	W	Optical sensor	Input	ON	When optical sensor is illuminated	3.1V or more
					When optical sensor is not illuminated	0.6V or less
59	GR	Front door lock assembly LH (unlock)	Output	OFF	OFF (neutral)	0V
					ON (unlock)	Battery voltage
60	LG	Turn signal (left)	Output	ON	Turn left ON	
					 SKIA3009J	
61	G	Turn signal (right)	Output	ON	Turn right ON	
					 SKIA3009J	
63	BR	Interior room/map lamp	Output	OFF	Any door switch	ON (open)
					OFF (closed)	Battery voltage
65	V	All door lock actuators (lock)	Output	OFF	OFF (neutral)	0V
					ON (lock)	Battery voltage

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITHOUT POWER DOOR LOCKS]

Terminal	Wire color	Item	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
66	L	Front door lock actuator RH, rear door lock actuators LH/RH (unlock)	Output	OFF	OFF (neutral)	0V
					ON (unlock)	Battery voltage
67	B	Ground	Input	ON	—	0V
68 ¹	O	Power window power supply (RAP)	Output	—	Ignition switch ON	Battery voltage
					Within 45 seconds after ignition switch OFF	Battery voltage
					More than 45 seconds after ignition switch OFF	0V
					When front door LH or RH is open or power window timer operates	0V
68 ²	SB	Power window power supply (RAP)	Output	—	Ignition switch ON	Battery voltage
					Within 45 seconds after ignition switch OFF	Battery voltage
					More than 45 seconds after ignition switch OFF	0V
					When front door LH or RH is open or power window timer operates	0V
69	P	Power window power supply (BAT)	Output	OFF	—	Battery voltage
70	W	Battery power supply	Input	OFF	—	Battery voltage

1: King cab

2: Crew cab

Fail Safe

INFOID:0000000011343373

Fail-safe index

BCM performs fail-safe control when any DTC listed below is detected.

Display contents of CONSULT		Fail-safe	Cancellation
U1000: CAN COMM CIRCUIT	Inhibit engine cranking	When the BCM re-establishes communication with the other modules.	

DTC Inspection Priority Chart

INFOID:0000000011343374

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	DTC
1	• U1000: CAN COMM CIRCUIT
2	• B2190: NATS ANTENNA AMP • B2191: DIFFERENCE OF KEY • B2192: ID DISCORD BCM-ECM • B2193: CHAIN OF BCM-ECM

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITHOUT POWER DOOR LOCKS]

Priority	DTC	
3	<ul style="list-style-type: none"> • C1729: VHCL SPEED SIG ERR • C1735: IGNITION SIGNAL 	A
4	<ul style="list-style-type: none"> • C1704: LOW PRESSURE FL • C1705: LOW PRESSURE FR • C1706: LOW PRESSURE RR • C1707: LOW PRESSURE RL • C1708: [NO DATA] FL • C1709: [NO DATA] FR • C1710: [NO DATA] RR • C1711: [NO DATA] RL • C1712: [CHECKSUM ERR] FL • C1713: [CHECKSUM ERR] FR • C1714: [CHECKSUM ERR] RR • C1715: [CHECKSUM ERR] RL • C1716: [PRESSDATA ERR] FL • C1717: [PRESSDATA ERR] FR • C1718: [PRESSDATA ERR] RR • C1719: [PRESSDATA ERR] RL • C1720: [CODE ERR] FL • C1721: [CODE ERR] FR • C1722: [CODE ERR] RR • C1723: [CODE ERR] RL • C1724: [BATT VOLT LOW] FL • C1725: [BATT VOLT LOW] FR • C1726: [BATT VOLT LOW] RR • C1727: [BATT VOLT LOW] RL 	B C D E F G H

DTC Index

INFOID:000000011343375

NOTE:

Details of time display

- CRNT: Displays when there is a malfunction now or after returning to the normal condition until turning ignition switch OFF → ON again.
- 1 - 39: Displayed if any previous malfunction is present when current condition is normal. It increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. The counter remains at 39 even if the number of cycles exceeds it. It is counted from 1 again when turning ignition switch OFF → ON after returning to the normal condition if the malfunction is detected again.

CONSULT display	Fail-safe	Low tire pressure warning lamp ON	Reference page
No DTC is detected. further testing may be required.	—	—	—
U1000: CAN COMM CIRCUIT	—	—	BCS-27
B2190: NATS ANTENNA AMP	—	—	SEC-18
B2191: DIFFERENCE OF KEY	—	—	SEC-21
B2192: ID DISCORD BCM-ECM	—	—	SEC-22
B2193: CHAIN OF BCM-ECM	—	—	SEC-24
C1708: [NO DATA] FL	—	X	WT-15
C1709: [NO DATA] FR	—	X	WT-15
C1710: [NO DATA] RR	—	X	WT-15
C1711: [NO DATA] RL	—	X	WT-15
C1712: [CHECKSUM ERR] FL	—	X	WT-17
C1713: [CHECKSUM ERR] FR	—	X	WT-17
C1714: [CHECKSUM ERR] RR	—	X	WT-17
C1715: [CHECKSUM ERR] RL	—	X	WT-17

INL

M

N

O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[WITHOUT POWER DOOR LOCKS]

CONSULT display	Fail-safe	Low tire pressure warning lamp ON	Reference page
C1716: [PRESSDATA ERR] FL	—	X	WT-19
C1717: [PRESSDATA ERR] FR	—	X	WT-19
C1718: [PRESSDATA ERR] RR	—	X	WT-19
C1719: [PRESSDATA ERR] RL	—	X	WT-19
C1720: [CODE ERR] FL	—	X	WT-17
C1721: [CODE ERR] FR	—	X	WT-17
C1722: [CODE ERR] RR	—	X	WT-17
C1723: [CODE ERR] RL	—	X	WT-17
C1724: [BATT VOLT LOW] FL	—	X	WT-17
C1725: [BATT VOLT LOW] FR	—	X	WT-17
C1726: [BATT VOLT LOW] RR	—	X	WT-17
C1727: [BATT VOLT LOW] RL	—	X	WT-17
C1729: VHCL SPEED SIG ERR	—	X	WT-21
C1735: IGNITION SIGNAL	—	X	WT-22

INTERIOR ROOM LAMP

< WIRING DIAGRAM >


[WITHOUT POWER DOOR LOCKS]

WIRING DIAGRAM

INTERIOR ROOM LAMP

Wiring Diagram - Without Power Door Lock System

INFOID:0000000010711482




INTERIOR ROOM LAMP

< WIRING DIAGRAM >

[WITHOUT POWER DOOR LOCKS]

: CREW CAB
 : WITH FRONT MAP LAMPS
 : KING CAB



ABLWA2386GB


INTERIOR ROOM LAMP


< WIRING DIAGRAM >

[WITHOUT POWER DOOR LOCKS]

INTERIOR ROOM LAMP CONNECTORS - WITHOUT POWER DOOR LOCK SYSTEM

Connector No.	M1	Connector No.	M3
Connector Name	WIRE TO WIRE	Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE	Connector Color	WHITE







Terminal No.	Color of Wire	Signal Name
9	R/Y	—
20	B	—
21	BR	—

Terminal No.	Color of Wire	Signal Name
4N	R/Y	—

Connector No.	M6	Connector No.	M18
Connector Name	WIRE TO WIRE	Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE	Connector Color	WHITE





Terminal No.	Color of Wire	Signal Name
12	LG	DOOR SW (AS)
13	L	DOOR SW (RR)
31	GR	CARGO LAMP SW
37	B	KEY SW
38	W/R	IGN SW
39	L	CAN-H
40	P	CAN-L

Terminal No.	Color of Wire	Signal Name
47	GR	DOOR SW (DR)
48	P	DOOR SW (RL)
50	P	CARGO LAMP OUTPUT

ABLIA5627GB


A B C D E F G H I J K L M N O P Q R S T U V Z INL

INTERIOR ROOM LAMP

< WIRING DIAGRAM >

[WITHOUT POWER DOOR LOCKS]


Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
57	R/Y	BAT (FUSE)
67	B	GND (POWER)
70	W	BAT (F/L)



Terminal No.	Color of Wire	Signal Name
1	B	-
2	Y	-




ABLIA6838GB

INTERIOR ROOM LAMP

< WIRING DIAGRAM >

[WITHOUT POWER DOOR LOCKS]

Terminal No.	Color of Wire	Signal Name
34J	L	-
35J	R	-
40J	P	-
41J	GR	-



Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M71
Connector Name	CARGO LAMP SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	GR	-
3	B	-



Terminal No.	Color of Wire	Signal Name
1	GR	-
3	B	-

Connector No.	E10
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Connector No.	M139
Connector Name	DIODE-6
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
6	W	-

Connector No.	M165
Connector Name	CARGO LAMP RELAY
Connector Color	BLUE

Terminal No.	Color of Wire	Signal Name
1	P	-
2	R/Y	-
3	G	-
5	R/Y	-

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
INL


ABLIA6839GB

INTERIOR ROOM LAMP

< WIRING DIAGRAM >

[WITHOUT POWER DOOR LOCKS]

Connector No.	B8
Connector Name	FRONT DOOR SWITCH LH (CREW CAB)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
35G	Y	-

Signal Name


Color of Wire

Terminal No.	Color of Wire	Signal Name
35G	Y	-


Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	B18
Connector Name	REAR DOOR SWITCH LH
Connector Color	WHITE



Connector No.	B16
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R	-
2	P	-

Terminal No.	Color of Wire	Signal Name
6	L	-
7	B	-
8	GR	-

ABLIA5630GB

INTERIOR ROOM LAMP


< WIRING DIAGRAM >

[WITHOUT POWER DOOR LOCKS]

Connector No.	B107
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	R	-
7	B	-
8	LG	-



Connector No.	B116
Connector Name	REAR DOOR SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R	-
2	I	-



Connector No.	B108
Connector Name	FRONT DOOR SWITCH RH (CREW CAB)
Connector Color	WHITE















Terminal No.	Color of Wire	Signal Name
1	R	-
2	G	-

ABLIA5631GE

INTERIOR ROOM LAMP

< WIRING DIAGRAM >

[WITHOUT POWER DOOR LOCKS]

<table border="1"> <tr> <td>Connector No.</td> <td>B149</td> </tr> <tr> <td>Connector Name</td> <td>WIRE TO WIRE</td> </tr> <tr> <td>Connector Color</td> <td>WHITE</td> </tr> </table> 	Connector No.	B149	Connector Name	WIRE TO WIRE	Connector Color	WHITE	<table border="1"> <tr> <td>Terminal No.</td> <td>Color of Wire</td> <td>Signal Name</td> </tr> <tr> <td>44M</td> <td>R</td> <td>-</td> </tr> <tr> <td>45M</td> <td>G</td> <td>-</td> </tr> <tr> <td>49M</td> <td>LG</td> <td>-</td> </tr> <tr> <td>50M</td> <td>L</td> <td>-</td> </tr> </table> 	Terminal No.	Color of Wire	Signal Name	44M	R	-	45M	G	-	49M	LG	-	50M	L	-	<table border="1"> <tr> <td>Connector No.</td> <td>B161</td> </tr> <tr> <td>Connector Name</td> <td>HIGH-MOUNTED STOP LAMP ASSEMBLY</td> </tr> <tr> <td>Connector Color</td> <td>WHITE</td> </tr> </table> 	Connector No.	B161	Connector Name	HIGH-MOUNTED STOP LAMP ASSEMBLY	Connector Color	WHITE			
Connector No.	B149																															
Connector Name	WIRE TO WIRE																															
Connector Color	WHITE																															
Terminal No.	Color of Wire	Signal Name																														
44M	R	-																														
45M	G	-																														
49M	LG	-																														
50M	L	-																														
Connector No.	B161																															
Connector Name	HIGH-MOUNTED STOP LAMP ASSEMBLY																															
Connector Color	WHITE																															
<table border="1"> <tr> <td>Connector No.</td> <td>R1</td> </tr> <tr> <td>Connector Name</td> <td>WIRE TO WIRE</td> </tr> <tr> <td>Connector Color</td> <td>WHITE</td> </tr> </table> 	Connector No.	R1	Connector Name	WIRE TO WIRE	Connector Color	WHITE	<table border="1"> <tr> <td>Terminal No.</td> <td>Color of Wire</td> <td>Signal Name</td> </tr> <tr> <td>2</td> <td>B</td> <td>-</td> </tr> <tr> <td>3</td> <td>G</td> <td>-</td> </tr> </table> 	Terminal No.	Color of Wire	Signal Name	2	B	-	3	G	-	<table border="1"> <tr> <td>Connector No.</td> <td>R10</td> </tr> <tr> <td>Connector Name</td> <td>ROOM LAMP 2ND ROW</td> </tr> <tr> <td>Connector Color</td> <td>WHITE</td> </tr> </table> 	Connector No.	R10	Connector Name	ROOM LAMP 2ND ROW	Connector Color	WHITE									
Connector No.	R1																															
Connector Name	WIRE TO WIRE																															
Connector Color	WHITE																															
Terminal No.	Color of Wire	Signal Name																														
2	B	-																														
3	G	-																														
Connector No.	R10																															
Connector Name	ROOM LAMP 2ND ROW																															
Connector Color	WHITE																															
<table border="1"> <tr> <td>Connector No.</td> <td>R9</td> </tr> <tr> <td>Connector Name</td> <td>FRONT ROOM/MAP LAMP ASSEMBLY</td> </tr> <tr> <td>Connector Color</td> <td>WHITE</td> </tr> </table> 	Connector No.	R9	Connector Name	FRONT ROOM/MAP LAMP ASSEMBLY	Connector Color	WHITE	<table border="1"> <tr> <td>Terminal No.</td> <td>Color of Wire</td> <td>Signal Name</td> </tr> <tr> <td>1</td> <td>BR</td> <td>-</td> </tr> <tr> <td>2</td> <td>R/Y</td> <td>-</td> </tr> </table> 	Terminal No.	Color of Wire	Signal Name	1	BR	-	2	R/Y	-	<table border="1"> <tr> <td>Connector No.</td> <td>R1</td> </tr> <tr> <td>Connector Name</td> <td>WIRE TO WIRE</td> </tr> <tr> <td>Connector Color</td> <td>WHITE</td> </tr> </table> 	Connector No.	R1	Connector Name	WIRE TO WIRE	Connector Color	WHITE									
Connector No.	R9																															
Connector Name	FRONT ROOM/MAP LAMP ASSEMBLY																															
Connector Color	WHITE																															
Terminal No.	Color of Wire	Signal Name																														
1	BR	-																														
2	R/Y	-																														
Connector No.	R1																															
Connector Name	WIRE TO WIRE																															
Connector Color	WHITE																															
<table border="1"> <tr> <td>Terminal No.</td> <td>Color of Wire</td> <td>Signal Name</td> </tr> <tr> <td>9</td> <td>R/Y</td> <td>-</td> </tr> <tr> <td>20</td> <td>B</td> <td>-</td> </tr> <tr> <td>21</td> <td>BR</td> <td>-</td> </tr> </table> 	Terminal No.	Color of Wire	Signal Name	9	R/Y	-	20	B	-	21	BR	-	<table border="1"> <tr> <td>Terminal No.</td> <td>Color of Wire</td> <td>Signal Name</td> </tr> <tr> <td>1</td> <td>R/Y</td> <td>-</td> </tr> <tr> <td>2</td> <td>Y</td> <td>-</td> </tr> <tr> <td>3</td> <td>B</td> <td>-</td> </tr> </table> 	Terminal No.	Color of Wire	Signal Name	1	R/Y	-	2	Y	-	3	B	-	<table border="1"> <tr> <td>Connector No.</td> <td>R1</td> </tr> <tr> <td>Connector Name</td> <td>WIRE TO WIRE</td> </tr> <tr> <td>Connector Color</td> <td>WHITE</td> </tr> </table> 	Connector No.	R1	Connector Name	WIRE TO WIRE	Connector Color	WHITE
Terminal No.	Color of Wire	Signal Name																														
9	R/Y	-																														
20	B	-																														
21	BR	-																														
Terminal No.	Color of Wire	Signal Name																														
1	R/Y	-																														
2	Y	-																														
3	B	-																														
Connector No.	R1																															
Connector Name	WIRE TO WIRE																															
Connector Color	WHITE																															


ABLIA5632GB

INTERIOR ROOM LAMP

< WIRING DIAGRAM >


[WITHOUT POWER DOOR LOCKS]

Connector No.	D216
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
6	R	-	6	R	-
7	B	-	7	B	-
8	LG	-	8	LG	-

Connector No.	D213
Connector Name	FRONT DOOR SWITCH LH (KING CAB)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
1	R	-	6	R	-
2	LG	-	7	B	-
3	B	-	8	LG	-

Connector No.	D314
Connector Name	FRONT DOOR SWITCH RH (KING CAB)
Connector Color	WHITE



Connector No.	D302
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
1	R	-	1	R	-
2	LG	-	2	LG	-
3	B	-	3	B	-

ABLIA6840GB

A

B

C

D

E

F

G

H

I

K

L

M

N

O

P

INL

ILLUMINATION


< WIRING DIAGRAM >

[WITHOUT POWER DOOR LOCKS]

ILLUMINATION

Wiring Diagram

INFOID:0000000010711483




ABLWA2390GB

ILLUMINATION

[WITHOUT POWER DOOR LOCKS]

< WIRING DIAGRAM >

- : WITH 4-WHEEL DRIVE
- : WITH AUTO A/C
- : WITH CLUTCH INTERLOCK CANCEL SWITCH
- : WITH ELECTRONIC LOCKING REAR DIFFERENTIAL
- : WITHOUT NAVI
- : WITH POWER OUTSIDE MIRRORS
- : WITH AUDIO AMPLIFIER
- : WITHOUT AUDIO AMPLIFIER
- : MANUAL WITH TYPE 1
- : MANUAL WITH TYPE 2
- : WITH NAVI
- : WITH BASE AUDIO SYSTEM FOR MEXICO
- : WITH BASE AUDIO SYSTEM EXCEPT FOR MEXICO
- : WITH DISPLAY AUDIO SYSTEM




ABLWA2808GB

ILLUMINATION

< WIRING DIAGRAM >

[WITHOUT POWER DOOR LOCKS]



* : THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PG SECTION.

ABLWA2820GB


ILLUMINATION

< WIRING DIAGRAM >

[WITHOUT POWER DOOR LOCKS]


ILLUMINATION CONNECTORS

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8P	R/Y	-
15P	W/R	-


Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	P	INPUT 5
3	SB	INPUT 4
4	V	INPUT 3
5	L	INPUT 2
6	R	INPUT 1
32	BG	OUTPUT 5
33	GR	OUTPUT 4
34	G	OUTPUT 3
35	BR	OUTPUT 2
36	LG	OUTPUT 1
38	W/R	IGN SW
39	L	CANH
40	P	CANL

ABLIA6825GB


Connector No.	M12
Connector Name	AUDIO UNIT (BASE AUDIO SYSTEM - FOR MEXICO)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8	GR	ILL CONT
9	R	LIGHT SW




Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8	GR	ILL CONT
9	R	LIGHT SW

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
20	R/Y	BATTERY
21	GR	CAN-L

Terminal No.	Color of Wire	Signal Name
3	R/Y	BATTERY
11	P	CAN-L
12	L	CAN-H
13	GR	GROUND
22	BR	ILLUMINATION CONTROL
23	B	POWER GND


A B C D E F G H I J K L M N O P Z INL

ILLUMINATION

< WIRING DIAGRAM >

[WITHOUT POWER DOOR LOCKS]

Connector No.	M30
Connector Name	COMBINATION SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	LG	-
2	BR	-
3	G	-
4	GR	-
5	BG	-
6	R	-
7	L	-
8	P	-
9	SB	-
10	V	-



Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
33	V	-
34	LG	-



Terminal No.	Color of Wire	Signal Name
42G	R	-

Terminal No.	Color of Wire	Signal Name
42G	R	-

Terminal No.	Color of Wire	Signal Name
42G	R	-

Terminal No.	Color of Wire	Signal Name
42G	R	-

Terminal No.	Color of Wire	Signal Name
9G	BR	-

Terminal No.	Color of Wire	Signal Name
9G	BR	-

Terminal No.	Color of Wire	Signal Name
9	BR	-


Terminal No.	Color of Wire	Signal Name
9	BR	-

ILLUMINATION

< WIRING DIAGRAM >

[WITHOUT POWER DOOR LOCKS]

Connector No.	M52
Connector Name	FRONT AIR CONTROL (WITH AUTO A/C)
Connector Color	BLACK



13	12	11	10	9	8	7	6	5	4	3	2	1
26	25	24	23	22	21	20	19	18	17	16	15	14



Connector No.	M50
Connector Name	FRONT AIR CONTROL (MANUAL WITH TYPE 1)
Connector Color	BLACK


13	12	11	10	9	8	7	6	5	4	3	2	1
26	25	24	23	22	21	20	19	18	17	16	15	14



Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
8	G	ILLUM+	3	R	-
9	BR	ILLUM-	4	BR	-

Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
8	G	ILLUM+	3	R	-
9	BR	ILLUM-	4	BR	-


Connector No.	M55
Connector Name	HAZARD SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
10	P	-
11	L	-

Terminal No.	Color of Wire	Signal Name
10	P	-
11	L	-

Connector No.	M76
Connector Name	ELECTRIC BRAKE (PRE-WIRING)
Connector Color	WHITE



Connector No.	M71
Connector Name	CARGO LAMP SWITCH
Connector Color	WHITE



A B C D E F G H I J K L M N O P INL


ABLIA6827GB

ILLUMINATION

< WIRING DIAGRAM >

[WITHOUT POWER DOOR LOCKS]

Connector No.	M94
Connector Name	SONAR SYSTEM OFF
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
3	R	—
4	BR	—

Connector No.	M102
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
20	W	—
21	R	—

Connector No.	M97
Connector Name	AV CONTROL UNIT (WITH NAVI WITH AMPLIFIER)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
23	P	MR OUTPUT
44	GR	ILL CONT

Connector No.	M108
Connector Name	AV CONTROL UNIT (WITH NAVI WITHOUT AMPLIFIER)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
23	P	MR OUTPUT
44	GR	ILL CONT

ILLUMINATION


< WIRING DIAGRAM >

[WITHOUT POWER DOOR LOCKS]

Connector No.	M149
Connector Name	DIFFERENTIAL LOCK MODE SWITCH
Connector Color	GRAY




Connector No.	M141
Connector Name	4WD SHIFT SWITCH
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
4	R	-
5	BR	-

Terminal No.	Color of Wire	Signal Name
7	R	-
8	BR	-


Terminal No.	Color of Wire	Signal Name
3	R	-
4	BR	-




Connector No.	M156
Connector Name	A/T SHIFT SELECTOR
Connector Color	WHITE



Connector No.	M155
Connector Name	HILL DESCENT CONTROL SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	R	-
5	BR	-



Terminal No.	Color of Wire	Signal Name
15	BR	-
16	R	-

ABLIA6829GB

A

B

C

D

E

F

G

H

I

K

INL

M

Z

O


P

ILLUMINATION

< WIRING DIAGRAM >


[WITHOUT POWER DOOR LOCKS]

Connector No.	M161
Connector Name	FRONT HEATED SEAT SWITCH LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5	R	-
6	BR	-

Connector No.	M160
Connector Name	FRONT HEATED SEAT SWITCH RH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
5	SB	-
6	BG	-

Connector No.	M167
Connector Name	JOINT CONNECTOR-M02
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
5	R	-
6	BR	-



Terminal No.	Color of Wire	Signal Name
5	R	-
6	BR	-



Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-
4	P	-
10	L	-
11	L	-
13	L	-



Terminal No.	Color of Wire	Signal Name
5	R	-
6	BR	-

Terminal No.	Color of Wire	Signal Name
5	R	-
6	BR	-

ABLIA6830GB

ILLUMINATION

< WIRING DIAGRAM >

[WITHOUT POWER DOOR LOCKS]


Connector No.	E124
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
38	B	GND (SIGNAL)	57	GR	TAIL LAMP
39	L	CAN-H	59	B	GND (POWER)
40	P	CAN-L			




Connector No.	E122
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
10	P	-
11	L	-

Connector No.	E26
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
10G	9G	-
10G	8G	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



ABLIA6831GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
INL

SYMPTOM DIAGNOSIS

INTERIOR LIGHTING SYSTEM SYMPTOMS

Symptom Table

INFOID:000000010711484

CAUTION:

Perform the self-diagnosis with CONSULT before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom	Possible cause	Inspection item
interior room lamps do not turn ON/OFF • Room lamp 2nd row • Front room/map lamp assembly	<ul style="list-style-type: none"> • Harness between fuse block (J/B) and each interior room lamp • Harness between each interior room lamp and door switches • Door switches 	Interior room lamp Refer to INL-78 .
Cargo lamp does not turn ON/OFF	<ul style="list-style-type: none"> • Harness between fuse block (J/B) and cargo lamp relay • Harness between cargo lamp relay and cargo lamp • Harness between BCM and cargo lamp relay • BCM 	Cargo lamp control circuit Refer to INL-80 .

PRECAUTION**PRECAUTIONS****Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"**

INFOID:0000000010711485

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS**WARNING:**

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

Precaution for Work

INFOID:0000000010711486

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
 - Water soluble dirt:
 - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
 - Then rub with a soft, dry cloth.
 - Oily dirt:
 - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
 - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
 - Then rub with a soft, dry cloth.
 - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
 - For genuine leather seats, use a genuine leather seat cleaner.

A

B

C

D

E

F

G

H

I

J

INL

K

M

N

O

P

PREPARATION

< PREPARATION >

[WITHOUT POWER DOOR LOCKS]

PREPARATION


PREPARATION

Special Service Tool

INFOID:000000010711487

The actual shape of the tools may differ from those illustrated here.

Tool number (TechMate No.) Tool name	Description
— (J-46534) Trim Tool Set	Removing trim components



AWJIA0483ZZ

REMOVAL AND INSTALLATION

INTERIOR ROOM LAMP


Removal and Installation

INFOID:0000000010711488

FRONT ROOM/MAP LAMP ASSEMBLY (IF EQUIPPED)

Removal

- Using a suitable tool, release the metal clips and drop the front room/map lamp assembly away from the headlining.
←: Front
[]: Metal clip
- Disconnect the harness connectors from the front room/map lamp assembly and remove.




Installation

Installation is in the reverse order of removal.

Bulb or Lens Replacement

- Using a suitable tool (A), remove the front room/map lamp RH and/or LH lenses (1) as necessary.
←: Front
(): Pawl
- Release one side of the bulb (2) from the tab using a suitable tool, then pull straight downward to remove.

**Front room/
map lamp as-
sembly bulb** : 12V - 8W



- Install the new bulb into the socket tabs.
- Install the front room/map lamp lens(es).

VANITY LAMP


Removal

INTERIOR ROOM LAMP

< REMOVAL AND INSTALLATION >

[WITHOUT POWER DOOR LOCKS]

The vanity lamp is replaced as part of the sun visor assembly. Refer to [INT-25, "Removal and Installation"](#).



Installation

Installation is in the reverse order of removal.


Bulb Replacement

The vanity mirror lamp bulb is replaced as part of the sun visor assembly. Refer to [INT-25, "Removal and Installation"](#).

ROOM LAMP 2ND ROW

Removal

1. Using a suitable tool (A), release the pawls and remove the room lamp lens (1).
①: Pawl
2. Remove room lamp screws (2).
3. Disconnect the harness connector from the room lamp and remove.




Installation

Installation is in the reverse order of removal.

Bulb or Lens Replacement

1. Using a suitable tool, release the room lamp lens.
2. Release the room lamp bulb retainers (1), then pull bulb (2) straight out to remove.
3. Install the bulb (2) securely into the room lamp bulb retainers (1).

Room lamp bulb : 12V - 8W



INTERIOR ROOM LAMP

< REMOVAL AND INSTALLATION >

[WITHOUT POWER DOOR LOCKS]

4. Install the room lamp lens.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O


P

ILLUMINATION**Removal and Installation**

INFOID:0000000010711489

ILLUMINATION CONTROL SWITCH**Removal**


The illumination control switch is replaced as a part of the combination meter. Refer to [MWI-91, "Removal and Installation"](#).

**Installation**

Installation is in the reverse order of removal.

SHIFT SELECTOR FINISHER LAMP**Removal**

1. Remove shift selector finisher from center console. Refer to [IP-25, "Removal and Installation"](#).
2. Rotate shift selector finisher lamp socket (2) with bulb (3) counterclockwise, then pull away from finisher (1).


**Installation**

Installation is in the reverse order of removal.

Bulb Replacement

1. Remove shift selector finisher from center console. Refer to [IP-25, "Removal and Installation"](#).
2. Remove shift selector finisher lamp socket (1), then pull bulb (2) straight out away from socket.
3. Install the bulb (2) into the shift selector finisher socket (1).

AT finisher lamp bulb : 12V - 3W



4. Install shift selector finisher in center console. Refer to [IP-25, "Removal and Installation"](#).

BULB SPECIFICATIONS

< SERVICE DATA AND SPECIFICATIONS (SDS)

[WITHOUT POWER DOOR LOCKS]

SERVICE DATA AND SPECIFICATIONS (SDS)

BULB SPECIFICATIONS

Bulb Specifications

INFOID:000000010711490

Item	Wattage (W)*
Front room/map lamp (if equipped)	8
Vanity lamp	—
Room lamp 2nd row	8
Shift selector finisher lamp	3

*: Always check with the Parts Department for the latest parts information.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P