

ENGINE LUBRICATION & COOLING SYSTEMS

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

SECTION LC






CONTENTS

PREPARATION/PRECAUTION	2	Inspection	11
Special Service Tools	2	Thermostat	11
Liquid Gasket Application Procedure	3	Removal	11
ENGINE LUBRICATION SYSTEM	4	Inspection	11
Lubrication Circuit	4	Installation	12
Oil Pressure Check	4	Radiator	12
Oil Pump	5	Removal And Installation	12
Removal And Installation	5	Cooling Fan (Crankshaft driven)	13
Disassembly And Assembly	5	Removal And Installation	13
Inspection	6	Inspection	14
Regulator Valve Inspection	6	Refilling Engine Coolant	14
Oil Filter	6	Inspection	14
Oil Filter Bracket	7	Overheating Cause Analysis	15
ENGINE COOLING SYSTEM	8	SERVICE DATA AND SPECIFICATIONS (SDS)	16
Cooling Circuit	8	Engine Lubrication System	16
System Check	8	Oil pressure	16
Checking Cooling System Hoses	8	Regulator valve	16
Checking Cooling System For Leaks	8	Oil pump	16
Checking Radiator	8	Engine Cooling System	16
Checking Radiator Cap	9	Thermostat	16
Water Pump	10	Radiator	16
Removal And Installation	10		



PREPARATION/PRECAUTION

Special Service Tools

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description	
ST25051001 (J25695-1) Oil pressure gauge	 <p>PF1/4x19/in</p> <p>NT558</p>	<p>Measuring oil pressure</p> <p>Maximum measuring range: 2,452 kPa (25 kg/cm², 356 psi)</p>
ST25052000 (J25695-2) Hose	 <p>PS1/4x19/in</p> <p>PS1/8x28/in</p> <p>NT559</p>	<p>Adapting oil pressure gauge to cylinder block</p>
KV10115801 (J38956) Oil filter wrench	 <p>14 faces, Inner span: 64.3 mm (2.531 in) (Face to opposite face)</p> <p>NT362</p>	<p>Removing oil filter</p>
EG17650301 (J33984-A) Radiator cap tester adapter	 <p>a</p> <p>b</p> <p>c</p> <p>NT564</p>	<p>Adapting radiator cap tester to radiator filler neck</p> <p>a: 28 (1.10) dia. b: 31.4 (1.236) dia. c: 41.3 (1.626) dia. Unit: mm (in)</p>
WS39930000 (—) Tube presser	 <p>NT052</p>	<p>Pressing the tube of liquid gasket</p>

PREPARATION/PRECAUTION



Liquid Gasket Application Procedure

- Use a scraper to remove all traces of old liquid gasket from mating surface and grooves. Also, completely clean any oil from these areas.
- Apply a continuous bead of liquid gasket to mating surfaces. (Use Genuine RTV silicone sealant part No. 999 MP-A7007 or equivalent.)
 - Be sure liquid gasket is 3.5 to 4.5 mm (0.138 to 0.177 in) dia. (for oil pan).
 - Be sure liquid gasket is 2.0 to 3.0 mm (0.079 to 0.118 in) dia. (in areas except oil pan).
- Apply liquid gasket around the inner side of bolt holes (unless otherwise specified).
- Assembly should be done within 5 minutes after coating.
- Wait at least 30 minutes before refilling engine oil and engine coolant.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT



HA

EL

IDX

ENGINE LUBRICATION SYSTEM

Lubrication Circuit



Oil Pressure Check

WARNING:

- Be careful not to burn yourself, as the engine and oil may be hot.
- Oil pressure check should be done in "Neutral position" (M/T) or "Parking position" (A/T).


1. Check oil level.
2. Remove oil pressure switch.

3. Install pressure gauge.
4. Start engine and warm it up to normal operating temperature.
5. Check oil pressure with engine running under no-load.

Engine speed rpm	Approximate discharge pressure kPa (kg/cm ² , psi)
Idle speed	More than 59 (0.6, 9)
2,000	412 - 451 (4.2 - 4.6, 60 - 65)

If difference is extreme, check oil passage and oil pump for oil leaks.

6. Install oil pressure switch with sealant.




ENGINE LUBRICATION SYSTEM

Oil Pump

REMOVAL AND INSTALLATION

1. Drain engine oil.
2. Drain engine coolant from drain plug on radiator.
3. Remove air duct (from mass air flow sensor to throttle body).
4. Remove cooling fan.
5. Remove radiator hoses (upper and lower) and fan shroud. Refer to "Radiator".
6. Remove drive belts. Refer to MA section ("Checking Drive Belts").
7. Remove crankshaft pulley and front upper and lower belt covers. Refer to EM section ("TIMING BELT").
8. Remove oil pan. Refer to EM section ("OIL PAN").
9. Remove oil strainer.
10. Remove oil pump assembly.

DISASSEMBLY AND ASSEMBLY



- Always replace with new oil seal and gasket.
- When installing oil pump, apply engine oil to inner and outer gears.
- Be sure that O-ring is properly installed.

ENGINE LUBRICATION SYSTEM





Oil Pump (Cont'd) INSPECTION

Using a feeler gauge, straightedge and micrometers, check the following clearances:

Unit: mm (in)

Body to outer gear radial clearance ①	0.114 - 0.200 (0.0045 - 0.0079)
Inner gear to outer gear tip clearance ②	Below 0.18 (0.0071)
Body to inner gear axial clearance ③	0.05 - 0.09 (0.0020 - 0.0035)
Body to outer gear axial clearance ④	0.050 - 0.110 (0.0020 - 0.0043)
Inner gear to brazed portion of housing clearance ⑤	0.045 - 0.091 (0.0018 - 0.0036)

- If the tip clearance (②) exceeds the limit, replace gear set.
- If body to gear clearances (①, ③, ④, ⑤) exceed the limit, replace oil pump body assembly.



REGULATOR VALVE INSPECTION


1. Visually inspect components for wear and damage.
2. Check oil pressure regulator valve sliding surface and valve spring.
3. Coat regulator valve with engine oil. Check that it falls smoothly into the valve hole by its own weight.

If damaged, replace regulator valve set or oil pump assembly.


OIL FILTER

The oil filter is a small, full-flow cartridge type and is provided with a relief valve.

- The new and previous oil filter designs differ from each other and are not interchangeable.
- Use Tool KV10115801 (J38956) for removing oil filter.



ENGINE LUBRICATION SYSTEM



Oil Pump (Cont'd)

OIL FILTER BRACKET

1. Remove oil filter.
2. Disconnect oil pressure switch and connector.
3. Remove oil filter bracket.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

ENGINE COOLING SYSTEM

Cooling Circuit




System Check

WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could occur from high pressure coolant escaping from the radiator.

Wrap a thick cloth around the cap. Slowly turn it a quarter turn to allow built-up pressure to escape. Carefully remove the cap by turning it all the way.



CHECKING COOLING SYSTEM HOSES

Check hoses for improper attachment, leaks, cracks, damage, loose connections, chafing and deterioration.

CHECKING COOLING SYSTEM FOR LEAKS

To check for leakage, apply pressure to the cooling system with a tester.

Testing pressure: 157 kPa (1.6 kg/cm², 23 psi)

CAUTION:

Higher pressure than specified may cause radiator damage.

CHECKING RADIATOR

Check radiator for mud or clogging. If necessary, clean radiator as follows.


- Be careful not to bend or damage the radiator fins.
 - When radiator is cleaned without removal, remove all surrounding parts such as cooling fan, radiator shroud and horns.
 - Tape the harness connectors to prevent water from entering.
1. Apply water by hose to the back side of the radiator core vertically downward.
 2. Apply water again to all radiator core surfaces once per minute.

ENGINE COOLING SYSTEM

System Check (Cont'd)

3. Stop washing when stains no longer flow out from the radiator. GI
4. Blow air into the back side of radiator core vertically downward.
 - Use compressed air lower than 5 kg/cm^2 and keep distance more than 30 cm (11.8 in). MA
5. Blow air again into all the radiator core surfaces once per minute until no water sprays out. EM

LC



CHECKING RADIATOR CAP

To check radiator cap, apply pressure to cap with a tester.

Radiator cap relief pressure:

Standard

78 - 98 kPa (0.8 - 1.0 kg/cm², 11 - 14 psi)

Limit

59 - 98 kPa (0.6 - 1.0 kg/cm², 9 - 14 psi)

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX

ENGINE COOLING SYSTEM

Water Pump (Cont'd)

2. Remove radiator hoses (upper and lower) and fan shroud. GI
3. Remove drive belts. Refer to MA section ("Checking Drive Belts"). MA
4. Remove water pump pulley. EM
5. Remove crankshaft pulley and front (upper and lower) belt cover. Refer to EM section ("TIMING BELT"). EM
6. Remove water pump. LC




INSPECTION

1. Check for badly rusted or corroded body assembly and vanes. EC
2. Check for rough operation due to excessive end play. FE

Thermostat

REMOVAL

1. Drain engine coolant from drain plugs on radiator. TF
2. Remove radiator hoses (upper and lower) and fan shroud. PD
3. Remove drive belts. FA
4. Remove pulley bracket. RA
5. Remove water inlet and thermostat assembly. BR



INSPECTION

1. Check valve seating condition at ordinary temperatures. It should seat tightly. ST




ENGINE COOLING SYSTEM

Thermostat (Cont'd)

2. Check valve opening temperature and valve lift.

Valve opening temperature	°C (°F)	82 (180)
Valve lift	mm/°C (in/°F)	More than 10/95 (0.39/203)

3. Check if valve is closed at 5°C (9°F) below valve opening temperature.



INSTALLATION

1. Install thermostat with jiggle valve or air bleeder at upper side.

2. When installing water inlet, apply liquid gasket as shown.

- Use Genuine RTV silicone sealant part No. 999 MP-A7007 or equivalent.
- After installation, run engine for a few minutes and check for leaks.
- Be careful not to spill coolant over engine compartment. Use a rag to absorb coolant.



Radiator

REMOVAL AND INSTALLATION

1. Remove under cover.
2. Drain coolant from radiator drain plug.
3. Remove air duct. (From mass air flow sensor to throttle body)
4. Disconnect radiator upper and lower hoses.
5. Remove A/T oil cooler hoses. (A/T model only)
6. Remove radiator lower shroud.
7. Disconnect reservoir tank hose.
8. Remove radiator.
9. After repairing or replacing radiator, install any part removed in reverse order of removal.

ENGINE COOLING SYSTEM

Radiator (Cont'd)



Cooling Fan (Crankshaft driven)

REMOVAL AND INSTALLATION

- Do not release the drive belt tension by removing the fan/water pump pulley.
- Fan coupling cannot be disassembled and should be replaced as a unit. If front mark **F** is present, install fan so that side marked **F** faces the front.
- Install the drive belt only after the fan and fan coupling to water pump flange bolts/nuts have been properly torqued.
- Proper alignment of these components is essential. Improper alignment will cause them to wobble and may eventually cause the fan to separate from the water pump, causing extensive damage.


GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

ENGINE COOLING SYSTEM

Cooling Fan (Crankshaft driven) (Cont'd)

INSPECTION

Check fan coupling for rough operation, silicon oil leakage or bent bimetal.



Refilling Engine Coolant



For details on refilling engine coolant, refer to MA section ("REFILLING ENGINE COOLANT", "Changing Engine Coolant").

INSPECTION

1. Apply pressure with Tool.
Specified pressure value:
157 kPa (1.6 kg/cm², 23 psi)

WARNING:

To prevent the risk of the hose coming undone while under pressure, securely fasten it down with a hose clamp. Attach a hose to the oil cooler as well. (A/T model only)



2. Check for leakage.

ENGINE COOLING SYSTEM

Overheating Cause Analysis

	Symptom	Check items					
Cooling system parts malfunction	Poor heat transfer	Water pump malfunction	—	—	GI		
		Thermostat stuck closed	—	—	MA		
		Water control valve stuck closed	—	—	EM		
		Damaged fins	Dust contamination or paper clogging	—	—	LC	
			Mechanical damage	—	—	EC	
	Clogged radiator cooling tube	Excess foreign material (rust, dirt, sand, etc.)	—	—	FE		
	Reduced air flow	High resistance to fan rotation	—	—	CL		
		Damaged fan blades	—	—	MT		
	Damaged radiator shroud	—	—	—	AT		
	Improper coolant mixture ratio	—	—	—	TF		
	Poor coolant quality	—	—	—	PD		
	Insufficient coolant	Coolant leaks	Cooling hose	Loose clamp	—	FA	
				Cracked hose	—	—	RA
			Water pump	Poor sealing	—	—	BR
			Radiator cap	Loose	—	—	ST
Poor sealing				—	—	RS	
Radiator			O-ring for damage, deterioration or improper fitting	—	—	BT	
			Cracked radiator tank	—	—	HA	
	Cracked radiator core	—	—	EL			
Reservoir tank	Cracked reservoir tank	—	—	IDX			
Overflowing reservoir tank	Exhaust gas leaks into cooling system	Cylinder head deterioration	—	—	BT		
		Cylinder head gasket deterioration	—	—	HA		
Except cooling system parts malfunction	—	Overload on engine	Abusive driving	High engine rpm under no load	—	—	RA
				Driving in low gear for extended time	—	—	BR
				Driving at extremely high speed	—	—	ST
			Powertrain system malfunction	—	—	RS	
			Installed improper size wheels and tires	—	—	BT	
	Dragging brakes	—	—	HA			
	Improper ignition timing.	—	—	—	EL		
Blocked or restricted air flow	Blocked bumper	—	—	—	EL		
	Blocked radiator grille	Installed car brassiere	—	—	BT		
		Mud contamination or paper clogging	—	—	HA		
	Blocked radiator	—	—	—	EL		
	Blocked condenser	—	—	—	EL		
Installed large fog lamp	—	—	—	EL			

SERVICE DATA AND SPECIFICATIONS (SDS)

Engine Lubrication System

Oil pressure

Engine speed rpm	Approximate discharge pressure kPa (kg/cm ² , psi)
Idle speed 2,000	More than 59 (0.6, 9) 412 - 451 (4.2 - 4.6, 60 - 65)

Regulator valve

Unit: mm (in)	
Regulator valve to oil pump cover clearance	0.040 - 0.097 (0.0016 - 0.0038)

Oil pump

Unit: mm (in)	
Body to outer gear radial clearance	0.114 - 0.200 (0.0045 - 0.0079)
Inner gear to outer gear tip clear- ance	Below 0.18 (0.0071)
Body to inner gear axial clearance	0.05 - 0.09 (0.0020 - 0.0035)
Body to outer gear axial clearance	0.050 - 0.110 (0.0020 - 0.0043)
Inner gear to brazed portion of housing clearance	0.045 - 0.091 (0.0018 - 0.0036)

Engine Cooling System

Thermostat

Valve opening temperature	°C (°F)	82 (180)
Valve lift	mm/°C (in/°F)	More than 10/95 (0.39/203)

Radiator

Unit: kPa (kg/cm ² , psi)		
Cap relief pressure	Standard	78 - 98 (0.8 - 1.0, 11 - 14)
	Limit	59 - 98 (0.6 - 1.0, 9 - 14)
Leakage test pressure		157 (1.6, 23)