

SECTION CL

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX

CONTENTS

<p>PRECAUTIONS AND PREPARATION.....2</p> <p style="padding-left: 20px;">Precautions.....2</p> <p style="padding-left: 20px;">Special Service Tools2</p> <p style="padding-left: 20px;">Commercial Service Tools2</p> <p>NOISE, VIBRATION AND HARSHNESS (NVH)</p> <p>TROUBLESHOOTING3</p> <p style="padding-left: 20px;">NVH Troubleshooting Chart.....3</p> <p>CLUTCH SYSTEM.....4</p> <p style="padding-left: 20px;">Clutch Pedal5</p> <p>INSPECTION AND ADJUSTMENT6</p> <p style="padding-left: 20px;">Adjusting Clutch Pedal6</p> <p style="padding-left: 20px;">Air Bleeding Procedure.....7</p>	<p>HYDRAULIC CLUTCH CONTROL8</p> <p style="padding-left: 20px;">Clutch Master Cylinder (With clutch damper)8</p> <p style="padding-left: 20px;">Operating Cylinder.....9</p> <p>CLUTCH RELEASE MECHANISM10</p> <p>CLUTCH DISC AND CLUTCH COVER13</p> <p style="padding-left: 20px;">Clutch Disc.....13</p> <p style="padding-left: 20px;">Clutch Cover and Flywheel14</p> <p>SERVICE DATA AND SPECIFICATIONS (SDS)15</p> <p style="padding-left: 20px;">General Specifications.....15</p> <p style="padding-left: 20px;">Clutch Control System15</p> <p style="padding-left: 20px;">Inspection and Adjustment15</p>
-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

PRECAUTIONS AND PREPARATION



Precautions



- Recommended fluid is brake fluid DOT 3.
- Never reuse drained brake fluid.
- Be careful not to splash brake fluid on painted areas.
- When removing and installing clutch piping, use a suitable tool.
- Use new brake fluid to clean or wash all parts of master cylinder, operating cylinder and clutch damper.
- Never use mineral oils such as gasoline or kerosene. They will ruin the rubber parts of the hydraulic system.

WARNING:




After cleaning the clutch disc, wipe it with a dust collector. Do not use compressed air.

Special Service Tools

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
ST20630000 (J26366) Clutch aligning bar	 <p>Installing clutch cover and clutch disc</p> <p>a: 15.9 mm (0.626 in) dia. b: 22.8 mm (0.898 in) dia. c: 55 mm (2.17 in)</p>
ST20050240 (—) Diaphragm spring adjusting wrench	 <p>Adjusting unevenness of clutch cover diaphragm spring</p> <p>a: 150 mm (5.91 in) b: 25 mm (0.98 in)</p>

Commercial Service Tools

Tool name	Description
① Flare nut crowfoot ② Torque wrench	 <p>Removing and installing clutch piping</p> <p>a: 10 mm (0.39 in)</p>
Bearing puller	 <p>Removing release bearing</p>
Bearing drift	 <p>Installing release bearing</p> <p>a: 52 mm (2.05 in) dia. b: 45 mm (1.77 in) dia.</p>

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

NVH Troubleshooting Chart


Use the chart below to help you find the cause of the symptom. The numbers indicate the order of the inspection. If necessary, repair or replace these parts.

Symptom		SUSPECTED PARTS (Possible cause)																		
		CLUTCH PEDAL (Free play out of adjustment)	CLUTCH LINE (Air in line)	MASTER CYLINDER PISTON CUP (Damaged)	OPERATING CYLINDER PISTON CUP (Damaged)	ENGINE MOUNTING (Loose)	RELEASE BEARING (Worn, dirty or damaged)	CLUTCH DISC (Out of true)	CLUTCH DISC (Runout is excessive)	CLUTCH DISC (Lining broken)	CLUTCH DISC (Dirty or burned)	CLUTCH DISC (Oily)	CLUTCH DISC (Worn out)	CLUTCH DISC (Hardened)	CLUTCH DISC (Lack of spline grease)	DIAPHRAGM SPRING (Damaged)	DIAPHRAGM SPRING (Out of tip alignment)	CLUTCH COVER (Distortion)	FLYWHEEL (Distortion)	
Symptom	Clutch grabs/chatters					1														
	Clutch pedal spongy		1	2	2															
	Clutch noisy						1													
	Clutch slips	1										2	2							
	Clutch does not disengage	1	2	3	4				5	5	5	5	5		5	6	6	7		
Reference page		CL-6	CL-7	CL-8	CL-9	Refer to EM section	CL-10	CL-13	CL-13	CL-13	CL-13	CL-13	CL-13	CL-13	CL-13	CL-14	CL-14	CL-14	CL-14	

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

CLUTCH SYSTEM

SEC. 300 • 305 • 306 • 465



Ⓛ : N·m (kg-m, in-lb)

Ⓡ : N·m (kg-m, ft-lb)

Ⓡ : Apply genuine anaerobic liquid gasket, Three Bond TB 1212, Loctite Part No. 51813 or equivalent.


Ⓛ : Apply lithium-based grease including molybdenum disulphide.

Ⓡ : Apply rubber lubricant.

CLUTCH SYSTEM

Clutch Pedal


SEC. 465



: N·m (kg·m, ft·lb)

ACL093

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX




Adjusting Clutch Pedal

1. Adjust pedal height with pedal stopper bolt or ASDC clutch switch.

Pedal height "H":

221 - 231 mm (8.70 - 9.09 in)



2. Adjust pedal free play by turning master cylinder push rod. Then tighten lock nut.

Pedal free play "A":

9 - 16 mm (0.35 - 0.63 in)


Pedal free play, measured at pedal pad includes the following:

- Free play due to clevis pin and clevis pin hole, push rod and master cylinder.

3. Make sure that clevis pin can rotate smoothly. If not, readjust pedal free play with master cylinder push rod.

INSPECTION AND ADJUSTMENT


Adjusting Clutch Pedal (Cont'd)



4. Adjust clearance "C" shown in the figure while fully depressing clutch pedal.

Clearance "C":

0.1 - 1.0 mm (0.004 - 0.039 in)



Air Bleeding Procedure

Bleed air according to the following procedure.

Bleed air from operating cylinder.

1. Fill the master cylinder reservoir tank with new brake fluid.
2. Connect a transparent vinyl hose to the air bleeder.
3. Slowly depress the clutch pedal to its full stroke length and release it completely. Repeat this operation several times at 2 to 3 second intervals.
4. Open the air bleeder with the clutch pedal fully depressed.
5. Close the air bleeder.
6. Release the clutch pedal and wait at least 5 seconds.
7. Repeat steps 3 through 6 above until air bubbles no longer appear in the brake fluid.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

HYDRAULIC CLUTCH CONTROL

Clutch Master Cylinder (With clutch damper)



DISASSEMBLY AND ASSEMBLY

- Use a screwdriver to remove stopper ring while pushing push rod into cylinder.
- When installing stopper ring, tap in lightly while pushing push rod into cylinder.

INSPECTION


Check the following items, and replace as necessary.

- Rubbing surface of cylinder and piston, for uneven wear, rust and damage
- Piston with piston cup, for wear and damage
- Return spring, for wear and damage
- Dust cover, for cracks, deformation and damage
- Reservoir, for deformation and damage

HYDRAULIC CLUTCH CONTROL

Operating Cylinder

SEC. 306



ACL090


INSPECTION

Check the following items, and replace as necessary.

- Rubbing surface of cylinder and piston, for uneven wear, rust and damage
- Piston with piston cup, for wear and damage
- Piston spring, for wear and damage
- Dust cover, for cracks, deformation and damage

CLUTCH RELEASE MECHANISM



SEC. 321




ACL091

REMOVAL AND INSTALLATION

- Remove release bearing.
- Install release bearing with suitable drift.



CLUTCH RELEASE MECHANISM



- Install retainer spring and holder spring.


INSPECTION

Check the following items, and replace as necessary.

- Release bearing, to see that it rolls freely and is free from noise, cracks, pitting and wear
- Release sleeve and withdrawal lever rubbing surface, for wear, rust and damage


LUBRICATION

- Apply recommended grease to contact surface and rubbing surface.
- Too much lubricant might damage clutch disc facing.



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

CLUTCH RELEASE MECHANISM




WATERPROOF — for 4WD model

- Apply recommended sealant to contact surface of transmission case dust cover and withdrawal lever, then install dust cover clip.

Recommended sealant: Nissan genuine part KP115-00100, Three Bond TB1212, Loctite Part No. 51813 or equivalent.



CLUTCH DISC AND CLUTCH COVER

SEC. 300



- Do not clean clutch disc surface with solvent.
 - When installing, be careful that grease from main drive shaft does not adhere to clutch disc.
- : Apply lithium-based grease including molybdenum disulphide.
 : N·m (kg·m, ft·lb)

ACL092



Clutch Disc

INSPECTION

Check the following items, and replace as necessary.

- Clutch disc, for burns, discoloration and oil or grease leakage
- Clutch disc, for wear of facing

Wear limit of facing surface to rivet head:
0.3 mm (0.012 in)

- Clutch disc, for backlash of spline and runout of facing
Maximum backlash of spline (at outer edge of disc):
1.0 mm (0.039 in)
Runout limit:
1.0 mm (0.039 in)
Distance of runout check point (from hub center):
115 mm (4.53 in)


GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

CLUTCH DISC AND CLUTCH COVER

Clutch Disc (Cont'd)

INSTALLATION


- Apply recommended grease to contact surface of splines.
- Too much lubricant may damage clutch disc facing.



Clutch Cover and Flywheel

INSPECTION AND ADJUSTMENT

- Check clutch cover, installed on vehicle, for uneven diaphragm spring toe height.
Uneven limit:
0.7 mm (0.028 in)
- If out of limit, adjust the height using Tool.




FLYWHEEL INSPECTION

CAUTION:

Do not allow any magnetic materials to contact the ring gear teeth.

- Inspect contact surface of flywheel for slight burns or discoloration. Clean flywheel using emery paper.
- Check flywheel runout.
Maximum allowable runout:
Refer to EM section ("Inspection", "CYLINDER BLOCK").



INSTALLATION

- Insert Tool into clutch disc hub while installing clutch cover and disc.
- Be careful not to allow grease to contaminate clutch facing.
- Tighten bolts in numerical order, in two steps.
First step:
☑: 10 - 20 N·m (1.0 - 2.0 kg-m, 7 - 14 ft-lb)
Final step:
☑: 22 - 29 N·m (2.2 - 3.0 kg-m, 16 - 22 ft-lb)

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

CLUTCH CONTROL SYSTEM

Type of clutch control	Hydraulic
------------------------	-----------

CLUTCH MASTER CYLINDER (with clutch damper)

Unit: mm (in)

Inner diameter	15.87 (5/8)
----------------	-------------

CLUTCH OPERATING CYLINDER

Unit: mm (in)

Inner diameter	17.46 (11/16)
----------------	---------------

CLUTCH DISC

Unit: mm (in)

Model	240
Engine	KA24DE
Facing size (Outer dia. x inner dia. x thickness)	240 x 150 x 3.5 (9.45 x 5.91 x 0.138)
Thickness of disc assembly With load	7.75 - 8.25 (0.3051 - 0.3248) with 4904 N (500 kg, 1103 lb)

CLUTCH COVER

Model	240		
Engine	KA24DE		
Set-load	N (kg, lb)	2WD	4904 (500, 1103)
		4WD	4658 (475, 1047)

Inspection and Adjustment

CLUTCH PEDAL

Unit: mm (in)

Pedal height "H"	221 - 231 (8.70 - 9.09)
Pedal free play "A" (at pedal pad)	9 - 16 (0.35 - 0.63)
Clearance "C" between pedal stopper bracket and clutch pedal position switch (with clutch pedal fully depressed)	0.1 - 1.0 (0.004 - 0.039)

*: Measured from surface of dash lower panel to pedal pad.

CLUTCH DISC

Unit: mm (in)

Model	240
Wear limit of facing surface to rivet head	0.3 (0.012)
Runout limit of facing Distance of runout check point (from hub center)	1.0 (0.039) 115 (4.53)
Maximum backlash of spline (at outer edge of disc)	1.0 (0.039)

CLUTCH COVER

Unit: mm (in)

Model	240
Diaphragm spring height	37.5 - 39.5 (1.476 - 1.555)
Uneven limit of diaphragm spring toe height	0.7 (0.028)

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX