

ENGINE LUBRICATION & COOLING SYSTEMS

SECTION LC

GI
MA
EM
LC
EC
FE

CONTENTS

KA24DE

ENGINE LUBRICATION SYSTEM	3
Precautions	3
SUPPLEMENTAL RESTRAINT SYSTEM (SRS)	
"AIR BAG" AND "SEAT BELT PRE-TENSIONER"	3
LIQUID GASKET APPLICATION PROCEDURE.....	3
Preparation	4
SPECIAL SERVICE TOOLS	4
Lubrication Circuit.....	5
Oil Pressure Check.....	6
Oil Pump	6
REMOVAL AND INSTALLATION.....	6
REGULATOR VALVE INSPECTION	7
OIL FILTER	7
OIL PUMP INSPECTION	7
Service Data and Specifications (SDS).....	8
OIL PRESSURE CHECK	8
REGULATOR VALVE	8
OIL PUMP	8
ENGINE COOLING SYSTEM	9
Precautions	9
SUPPLEMENTAL RESTRAINT SYSTEM (SRS)	
"AIR BAG" AND "SEAT BELT PRE-TENSIONER"	9
LIQUID GASKET APPLICATION PROCEDURE.....	9
Preparation	10
SPECIAL SERVICE TOOLS	10
Cooling Circuit	10
System Check.....	11
CHECKING COOLING SYSTEM HOSES.....	11
CHECKING RADIATOR.....	11
CHECKING COOLING SYSTEM FOR LEAKS	11
CHECKING RADIATOR CAP	12
Water Pump	12
REMOVAL.....	12
INSPECTION.....	12
INSTALLATION.....	13
Thermostat.....	13
REMOVAL.....	13
INSPECTION.....	13
INSTALLATION.....	13

Radiator	14
REMOVAL AND INSTALLATION.....	14
COMPONENTS	15
INSPECTION.....	15
Cooling Fan (Crankshaft driven)	16
REMOVAL AND INSTALLATION.....	16
INSPECTION.....	16
Refilling Engine Coolant	16
Overheating Cause Analysis	17
Service Data and Specifications (SDS).....	18
THERMOSTAT	18
RADIATOR.....	18

VG33E

AX

ENGINE LUBRICATION SYSTEM	19
Precautions	19
SUPPLEMENTAL RESTRAINT SYSTEM (SRS)	
"AIR BAG" AND "SEAT BELT PRE-TENSIONER"	19
LIQUID GASKET APPLICATION PROCEDURE.....	19
Preparation	20
SPECIAL SERVICE TOOLS	20
Lubrication Circuit.....	20
Oil Pressure Check.....	21
Oil Pump	21
REMOVAL AND INSTALLATION.....	21
DISASSEMBLY AND ASSEMBLY.....	22
INSPECTION.....	23
REGULATOR VALVE INSPECTION	23
OIL FILTER	23
OIL FILTER BRACKET	24
Service Data and Specifications (SDS).....	25
OIL PRESSURE CHECK	25
REGULATOR VALVE	25
OIL PUMP	25
ENGINE COOLING SYSTEM	26
Precautions	26
SUPPLEMENTAL RESTRAINT SYSTEM (SRS)	
"AIR BAG" AND "SEAT BELT PRE-TENSIONER"	26
LIQUID GASKET APPLICATION PROCEDURE.....	26
Preparation	27

EL

IDX

CONTENTS (Cont'd)

SPECIAL SERVICE TOOLS	27	Radiator	32
Cooling Circuit	27	REMOVAL AND INSTALLATION.....	32
System Check.....	27	COMPONENTS	32
CHECKING COOLING SYSTEM HOSES.....	28	INSPECTION.....	33
CHECKING RADIATOR CAP	28	Cooling Fan (Crankshaft driven)	33
CHECKING RADIATOR.....	28	REMOVAL AND INSTALLATION.....	33
CHECKING COOLING SYSTEM FOR LEAKS.....	28	INSPECTION.....	33
Water Pump	29	Refilling Engine Coolant	35
REMOVAL.....	29	Overheating Cause Analysis	35
INSPECTION.....	30	Service Data and Specifications (SDS).....	36
INSTALLATION.....	30	THERMOSTAT	36
Thermostat.....	30	RADIATOR.....	36
REMOVAL.....	30		
INSPECTION.....	31		
INSTALLATION.....	31		

Precautions

SUPPLEMENTAL RESTRAINT SYSTEM (SRS) "AIR BAG" AND "SEAT BELT PRE-TENSIONER"



The Supplemental Restraint System "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a seat belt, help to reduce the risk or severity of injury to the driver and front passenger in a frontal collision. The Supplemental Restraint System consists of air bag modules (located in the center of the steering wheel and in the instrument panel on the passenger side), seat belt pre-tensioners, a diagnosis sensor unit, a crash zone sensor (4WD models), warning lamp, wiring harness, and spiral cable.

The vehicle (except Crew Cab) is equipped with a passenger air bag deactivation switch. Because no rear seat exists where a rear-facing child restraint can be placed, the switch is designed to turn off the passenger air bag so that a rear-facing child restraint can be used in the front passenger seat. The switch is located in the center of the instrument panel, near the ashtray. When the switch is turned to the ON position, the passenger air bag is enabled and could inflate in a frontal collision. When the switch is turned to the OFF position, the passenger air bag is disabled and will not inflate in a frontal collision. A passenger air bag OFF indicator on the instrument panel lights up when the passenger air bag is switched OFF. The driver air bag always remains enabled and is not affected by the passenger air bag deactivation switch.

Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance should be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, **RS-21**.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. Spiral cable and wiring harnesses (except "SEAT BELT PRE-TENSIONER") are covered with yellow insulation either just before the harness connectors or on the complete harness, for easy identification.
- The vehicle (except Crew Cab) is equipped with a passenger air bag deactivation switch which can be operated by the customer. When the passenger air bag is switched OFF, the passenger air bag is disabled and will not inflate in a frontal collision. When the passenger air bag is switched ON, the passenger air bag is enabled and could inflate in a frontal collision. After SRS maintenance or repair, make sure the passenger air bag deactivation switch is in the same position (ON or OFF) as when the vehicle arrived for service.



LIQUID GASKET APPLICATION PROCEDURE

1. Use a scraper to remove all traces of old liquid gasket from mating surfaces and grooves. Also, completely clean any oil from these areas.
2. Apply a continuous bead of liquid gasket to mating surfaces. (Use Genuine RTV Silicone Sealant Part No. 999 MP-A7007 or equivalent.)
 - For oil pan, be sure liquid gasket diameter is 3.5 to 4.5 mm (0.138 to 0.177 in).
 - For areas except oil pan, be sure liquid gasket diameter is 2.0 to 3.0 mm (0.079 to 0.118 in).
3. Apply liquid gasket around the inner side of bolt holes (unless otherwise specified).
4. Assembly should be done within 5 minutes after coating.
5. Wait at least 30 minutes before refilling engine oil and engine coolant.




Preparation

Preparation

SPECIAL SERVICE TOOLS

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

=NELC0142

Tool number (Kent-Moore No.) Tool name	Description	
(J34301-C) Oil pressure gauge set 1: (J34301-1) Oil pressure gauge 2: (J34301-2) Hoses 3: (J34298) Adapter 4: (J34282-1) Adapter 5: (790-301-1230-A) 60° adapter 6: (J34301-15) Square socket	 <p>AAT896</p>	<p>Measuring oil pressure Maximum measuring range: 1,379 kPa (14 kg/cm², 200 psi)</p>
WS39930000 (—) Tube presser	 <p>NT052</p>	Pressing the tube of liquid gasket
KV10115801 (J38956) Oil filter wrench	 <p>NT362</p>	Removing oil filter



ENGINE LUBRICATION SYSTEM

KA24DE

Lubrication Circuit

Lubrication Circuit

NELC0143




ALC116

- | | | |
|---------------------------|---------------------------|----------------------------------|
| 1. Connecting rod | 6. Oil pump | 10. Idler sprocket |
| 2. Connecting rod bearing | 7. Oil pan | 11. Upper timing chain tensioner |
| 3. Main bearing | 8. Piston oil jet | 12. Exhaust camshaft |
| 4. Oil filter | 9. Timing chain tensioner | 13. Intake camshaft |
| 5. Oil strainer | | |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL

Oil Pressure Check

NELC0144



Oil Pressure Check

WARNING:

- Be careful not to burn yourself, as the engine and oil may be hot.
- For M/T models, put gearshift lever in Neutral "N" position. For A/T models, put selector lever in Park "P" position.
- 1. Check oil level.
- 2. Remove oil pressure switch.
- 3. Install pressure gauge.
- 4. Start engine and warm it up to normal operating temperature.
- 5. Check oil pressure with engine running under no-load.

Engine speed	Approximate discharge pressure
Idle speed	More than 78 kPa (0.8 kg/cm ² , 11 psi)
3,000 rpm	412 - 481 kPa (4.2 - 4.9 kg/cm ² , 60 - 70 psi)


- If difference is extreme, check oil passage and oil pump for oil leaks.
- 6. Install oil pressure switch with sealant.

: 12.25 – 17.25 N·m (1.3 – 1.7 kg-m, 9 – 12 ft-lb)


Oil Pump

REMOVAL AND INSTALLATION


NELC0145



SLC945-A




- Always replace with new oil seal and gasket.
- When removing oil pump, turn crankshaft so that No. 1 piston is at TDC on its compression stroke.
- When installing oil pump, apply engine oil to gears, then align punchmark on drive spindle and oil hole on oil pump.



REGULATOR VALVE INSPECTION

- NELC0146
- Visually inspect components for wear and damage.
 - Check oil pressure regulator valve sliding surface and valve spring.
 - Clean regulator valve with engine oil. Check that it falls smoothly into the valve hole by its own weight.
 - Replace regulator valve set or oil pump assembly, if damaged.**




OIL FILTER

NELC0147

The oil filter is a small, full-flow cartridge type and is provided with a relief valve.

- The new and previous oil filter designs differ from each other and are not interchangeable.
- Use Tool KV10115801 (J38956) for removing oil filter.



OIL PUMP INSPECTION

NELC0148


Using a feeler gauge, check the following clearances.

Standard clearance:

Unit: mm (in)

Rotor tip clearance 1	Less than 0.12 (0.0047)
Outer rotor to body clearance 2	0.15 - 0.21 (0.0059 - 0.0083)
Side clearance (with gasket) 3	0.04 - 0.100 (0.0016 - 0.0039)

- If the tip clearance (1) exceeds the limit, replace gear set.
- If body to gear clearances (2, 3) exceed the limit, replace oil pump assembly.



ENGINE LUBRICATION SYSTEM

KA24DE

Service Data and Specifications (SDS)

Service Data and Specifications (SDS)

OIL PRESSURE CHECK

NELC0149

Engine speed	Approximate discharge pressure
Idle speed	More than 78 kPa (0.8 kg/cm ² , 11 psi)
3,000 rpm	412 - 481 kPa (4.2 - 4.9 kg/cm ² , 60 - 70 psi)

REGULATOR VALVE

NELC0150
Unit: mm (in)

Regulator valve to oil pump cover clearance	0.040 - 0.097 (0.0016 - 0.0038)
---	---------------------------------

OIL PUMP

NELC0151
Unit: mm (in)

Rotor tip clearance	Less than 0.12 (0.0047)
Outer rotor to body clearance	0.15 - 0.21 (0.0059 - 0.0083)
Side clearance (with gasket)	0.04 - 0.100 (0.0016 - 0.0039)

Precautions



SUPPLEMENTAL RESTRAINT SYSTEM (SRS) "AIR BAG" AND "SEAT BELT PRE-TENSIONER"

The Supplemental Restraint System "AIR BAG" and "SEAT BELT PRE-TENSIONER" (Crew Cab only), used along with a seat belt, help to reduce the risk or severity of injury to the driver and front passenger in a frontal collision. The Supplemental Restraint System consists of air bag modules (located in the center of the steering wheel and in the instrument panel on the passenger side), seat belt pre-tensioners (Crew Cab only), a diagnosis sensor unit, a crash zone sensor (4WD models), warning lamp, wiring harness, and spiral cable. The vehicle (except Crew Cab) is equipped with a passenger air bag deactivation switch. Because no rear seat exists where a rear-facing child restraint can be placed, the switch is designed to turn off the passenger air bag so that a rear-facing child restraint can be used in the front passenger seat. The switch is located in the center of the instrument panel, near the ashtray. When the switch is turned to the ON position, the passenger air bag is enabled and could inflate in a frontal collision. When the switch is turned to the OFF position, the passenger air bag is disabled and will not inflate in a frontal collision. A passenger air bag OFF indicator on the instrument panel lights up when the passenger air bag is switched OFF. The driver air bag always remains enabled and is not affected by the passenger air bag deactivation switch.

Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance should be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, **RS-21**.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. Spiral cable and wiring harnesses (except "SEAT BELT PRE-TENSIONER") are covered with yellow insulation either just before the harness connectors or on the complete harness, for easy identification.
- The vehicle (except Crew Cab) is equipped with a passenger air bag deactivation switch which can be operated by the customer. When the passenger air bag is switched OFF, the passenger air bag is disabled and will not inflate in a frontal collision. When the passenger air bag is switched ON, the passenger air bag is enabled and could inflate in a frontal collision. After SRS maintenance or repair, make sure the passenger air bag deactivation switch is in the same position (ON or OFF) as when the vehicle arrived for service.



LIQUID GASKET APPLICATION PROCEDURE

1. Use a scraper to remove all traces of old liquid gasket from mating surfaces and grooves. Also, completely clean any oil from these areas.
2. Apply a continuous bead of liquid gasket to mating surfaces. (Use Genuine RTV Silicone Sealant Part No. 999 MP-A7007 or equivalent.)
 - For oil pan, be sure liquid gasket diameter is 3.5 to 4.5 mm (0.138 to 0.177 in).
 - For areas except oil pan, be sure liquid gasket diameter is 2.0 to 3.0 mm (0.079 to 0.118 in).
3. Apply liquid gasket around the inner side of bolt holes (unless otherwise specified).
4. Assembly should be done within 5 minutes after coating.
5. Wait at least 30 minutes before refilling engine oil and engine coolant.



Preparation

Preparation

SPECIAL SERVICE TOOLS

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.


=NELC0154

Tool number (Kent-Moore No.) Tool name	Description
EG17650301 (J33984-A) Radiator cap tester adapter	 <p>Adapting radiator cap tester to radiator filler neck a: 28 (1.10) dia. b: 31.4 (1.236) dia. c: 41.3 (1.626) dia. Unit: mm (in)</p> <p>NT564</p>
WS39930000 (—) Tube presser	 <p>Pressing the tube of liquid gasket</p> <p>NT052</p>

Cooling Circuit

NELC0155

- ← Thermostat: Open
→ Thermostat: Closed



ALC117

System Check**WARNING:**

Never remove the radiator cap when the engine is hot. Serious burns could occur from high pressure coolant escaping from the radiator.

Wrap a thick cloth around the radiator cap. Slowly turn it a quarter turn to allow built-up pressure to escape. Carefully remove the radiator cap by turning it all the way.

CHECKING COOLING SYSTEM HOSES


Check hoses for the following:

- Improper attachment
- Leaks
- Cracks
- Damage
- Chafing
- Deterioration

CHECKING RADIATOR

Check radiator for mud or clogging. If necessary, clean radiator as follows.

- Be careful not to bend or damage the radiator fins.
- When radiator is cleaned without removal, remove all surrounding parts such as cooling fan, radiator shroud and horns.
- Tape the harness connectors to prevent water from entering.
- 1. Apply water by hose to the back side of the radiator core vertically downward.
- 2. Apply water again to all radiator core surfaces once per minute.
- 3. Stop washing when stains no longer flow out from the radiator.
- 4. Blow air into the back side of radiator core vertically downward.
- Use compressed air lower than 490 kPa (5 kg/cm², 71 psi) and keep distance more than 30 cm (11.8 in).
- 5. Blow air again into all the radiator core surfaces once per minute until no water sprays out.

**CHECKING COOLING SYSTEM FOR LEAKS**

To check for leakage, apply pressure to the cooling system with a radiator cap tester.

Testing pressure:

157 kPa (1.6 kg/cm², 23 psi)

CAUTION:

Higher pressure than specified may cause radiator damage.

NELC0156S03

BT


HA

SC

EL

IDX

System Check (Cont'd)

**CHECKING RADIATOR CAP**

To check radiator cap, apply pressure to radiator cap with a radiator cap tester.


Radiator cap relief pressure:**Standard**

78 - 98 kPa (0.8 - 1.0 kg/cm², 11 - 14 psi)


Limit

59 - 98 kPa (0.6 - 1.0 kg/cm², 9 - 14 psi)

NELC0156S04




Pull the negative pressure valve to open it.
Check that it closes completely when released.

**Water Pump****REMOVAL**

NELC0157


CAUTION:

- When removing water pump assembly, be careful not to get coolant on drive belts.
 - Water pump cannot be disassembled and should be replaced as a unit.
 - After installing water pump, connect hose and clamp securely. Check for leaks using radiator cap tester.
1. Drain coolant from engine.
Refer to **MA-18**, ("Changing Engine Coolant", "ENGINE MAINTENANCE").
 2. Remove fan coupling with fan.
 3. Remove power steering pump drive belt, generator drive belt and A/C compressor drive belt.
 4. Remove water pump.


**INSPECTION**

NELC0158

- Check body assembly for rust or corrosion.
- Check for rough operation due to excessive end play.

**INSTALLATION**

- NELC0159
1. Use a scraper to remove liquid gasket from water pump.
 - Also remove traces of liquid gasket from mating surface of cylinder block.




2. Apply a continuous bead of liquid gasket to mating surface of water pump.

- Use Genuine RTV Silicone Sealant Part No. 999 MP-A7007 or equivalent.


When filling radiator with coolant, refer to **MA-18**, ("Changing Engine Coolant", "ENGINE MAINTENANCE").

When installing drive belts, refer to **MA-17**, ("Checking Drive Belts").

**Thermostat****REMOVAL**

- NELC0160
- Be careful not to spill coolant over engine compartment. Use a rag to absorb coolant.


1. Drain coolant from engine. Refer to **MA-18**, ("Changing Engine Coolant", "ENGINE MAINTENANCE").
2. Remove air cleaner and air duct assembly.
3. Remove water hose from water inlet housing.
4. Remove water inlet housing, then take out thermostat.

**INSPECTION**

- NELC0161
1. Check valve seating condition at normal room temperature. It should seat tightly.
 2. Check valve opening temperature and valve lift.


Valve opening temperature	76.5°C (170°F)
Valve lift	More than 8 mm/90°C (0.31 in/194°F)

3. Check if valve closes at 5°C (9°F) below valve opening temperature.

**INSTALLATION**

- NELC0162
1. Use a scraper to remove old liquid gasket from water inlet.
 - Also remove traces of liquid gasket from mating surface of front cover.
 2. Apply a continuous bead of liquid gasket to mating surface of water inlet.
 - Use Genuine RTV Silicone Sealant Part No. 999 MP-A7007 or equivalent.

Thermostat (Cont'd)



3. Install thermostat with jiggle valve or air bleeder at upper side.
4. Install water inlet housing.
5. Install water hose to water inlet housing.
6. Install air cleaner and air duct assembly.
7. Refill engine coolant. Refer to **MA-18**, ("Changing Engine Coolant", "ENGINE MAINTENANCE").
- **After installation, run engine for a few minutes and check for leaks.**

Radiator

REMOVAL AND INSTALLATION

NELC0163

1. Remove under cover.
2. Drain coolant from radiator. Refer to **MA-18**, ("Changing Engine Coolant", "ENGINE MAINTENANCE").
3. Disconnect upper and lower radiator hoses.
4. Remove air cleaner and air duct assembly.
5. Remove lower radiator shroud.
6. Remove radiator shroud.
7. Remove A/T oil cooler hoses (A/T models only).
8. Disconnect coolant reservoir hose.
9. Remove radiator.
10. After replacing radiator, install all parts in reverse order of removal.
11. Refill engine coolant. Refer to **MA-18**, ("Changing Engine Coolant", "ENGINE MAINTENANCE").
- **After installation, run engine for a few minutes, and check for leaks.**

COMPONENTS

NELC0164

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF

PD

AX

SU

BR

ST

RS

BT


HA

SC

EL

IDX


SEC. 214



: N·m (kg·m, in·lb)

ALC118

NELC0165



INSPECTION


1. Apply pressure with Tool.

Specified pressure value:

157 kPa (1.6 kg/cm², 23 psi)


WARNING:

To prevent the risk of the hose coming undone while under pressure, securely fasten it down with a hose clamp. Attach a hose to the oil cooler as well. (A/T model only)




2. Check for leakage.

Cooling Fan (Crankshaft driven)

**Cooling Fan (Crankshaft driven)****REMOVAL AND INSTALLATION**


NELC0166

- Do not release the drive belt tension by removing the fan/water pump pulley.
- Fan coupling cannot be disassembled and should be replaced as a unit. If front mark **F** is present, install fan so that side marked **F** faces the front.
- Install the drive belt only after the fan and fan coupling to water pump flange bolts/nuts have been properly torqued.
- Proper alignment of these components is essential. Improper alignment will cause them to wobble and may eventually cause the fan to separate from the water pump, causing extensive damage.

**INSPECTION**

Check fan coupling for rough operation, silicon oil leakage and bent bimetal.

NELC0167



After assembly, verify the fan does not wobble or flap while the engine is running.

WARNING:

- When the engine is running, keep hands and clothing away from moving parts such as drive belts and fan.

Refilling Engine Coolant

NELC0168

For details on refilling engine coolant, refer to **MA-18**, ("Changing Engine Coolant", "ENGINE MAINTENANCE").

ENGINE COOLING SYSTEM

KA24DE

Overheating Cause Analysis

Overheating Cause Analysis

=NELC0169

	Symptom	Check items			
Cooling system parts malfunction	Poor heat transfer	Water pump malfunction	Worn or loose drive belt	GI	
		Thermostat stuck closed	—		
		Damaged fins	Dust contamination or paper clogging		
			Mechanical damage		
	Reduced air flow	Clogged radiator cooling tube	Excess foreign material (rust, dirt, sand, etc.)	LC	
		Fan coupling does not operate	—		
		High resistance to fan rotation	—		
	Insufficient coolant	Damaged fan blades	—	FE	
		Damaged radiator shroud	—		
		Improper coolant mixture ratio	—		
	Poor coolant quality	Poor coolant quality	—	MT	
		Coolant leaks	Cooling hose		
			Loose clamp		
			Cracked hose		
			Water pump	TF	
		Radiator cap	Poor sealing		
			Loose	PD	
			Poor sealing		
		Radiator	O-ring for damage, deterioration or improper fitting	AX	
			Cracked radiator tank		
			Cracked radiator core		
		Reservoir tank	Cracked reservoir tank	SU	
			Cylinder head deterioration		
	Overflowing reservoir tank	Exhaust gas leaks into cooling system	Cylinder head gasket deterioration	BR	
			—		

ENGINE COOLING SYSTEM

KA24DE

Overheating Cause Analysis (Cont'd)

Symptom		Check items	
Except cooling system parts malfunction	Overload on engine	Abusive driving	High engine rpm under no-load Driving in low gear for extended time Driving at extremely high speed
		Powertrain system malfunction	—
		Installed improper size wheels and tires	—
		Dragging brakes	—
		Improper ignition timing	—
	Blocked or restricted air flow	Blocked bumper	—
		Blocked radiator grille	Installed car brassiere Mud contamination or paper clogging
		Blocked radiator	—
		Blocked condenser	—
		Installed large fog lamp	—

Service Data and Specifications (SDS)

THERMOSTAT

NELC0170

Valve opening temperature	76.5°C (170°F)
Valve lift	More than 8 mm/90°C (0.31 in/194°F)

RADIATOR

NELC0171
Unit: kPa (kg/cm², psi)

Cap relief pressure	Standard	78 - 98 (0.8 - 1.0, 11 - 14)
	Limit	59 - 98 (0.6 - 1.0, 9 - 14)
Leakage test pressure		157 (1.6, 23)

Precautions

SUPPLEMENTAL RESTRAINT SYSTEM (SRS) "AIR BAG" AND "SEAT BELT PRE-TENSIONER"


The Supplemental Restraint System "AIR BAG" and "SEAT BELT PRE-TENSIONER" (crew cab model only), used along with a seat belt, help to reduce the risk or severity of injury to the driver and front passenger in a frontal collision. The Supplemental Restraint System consists of air bag modules (located in the center of the steering wheel and in the instrument panel on the passenger side), seat belt pre-tensioners (crew cab model only), a diagnosis sensor unit, a crash zone sensor (4WD models), warning lamp, wiring harness, and spiral cable.

The vehicle (except crew cab model) is equipped with a passenger air bag deactivation switch. Because no rear seat exists where a rear-facing child restraint can be placed, the switch is designed to turn off the passenger air bag so that a rear-facing child restraint can be used in the front passenger seat. The switch is located in the center of the instrument panel, near the ashtray. When the switch is turned to the ON position, the passenger air bag is enabled and could inflate in a frontal collision. When the switch is turned to the OFF position, the passenger air bag is disabled and will not inflate in a frontal collision. A passenger air bag OFF indicator on the instrument panel lights up when the passenger air bag is switched OFF. The driver air bag always remains enabled and is not affected by the passenger air bag deactivation switch.

Information necessary to service the system safely is included in the **RS section** of this Service Manual.


WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance should be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, **RS-21**.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. Spiral cable and wiring harnesses (except "SEAT BELT PRE-TENSIONER") are covered with yellow insulation either just before the harness connectors or on the complete harness, for easy identification.
- The vehicle (except crew cab model) is equipped with a passenger air bag deactivation switch which can be operated by the customer. When the passenger air bag is switched OFF, the passenger air bag is disabled and will not inflate in a frontal collision. When the passenger air bag is switched ON, the passenger air bag is enabled and could inflate in a frontal collision. After SRS maintenance or repair, make sure the passenger air bag deactivation switch is in the same position (ON or OFF) as when the vehicle arrived for service.



LIQUID GASKET APPLICATION PROCEDURE

1. Use a scraper to remove all traces of old liquid gasket from mating surface and grooves. Also, completely clean any oil from these areas.
2. Apply a continuous bead of liquid gasket to mating surfaces. (Use Genuine RTV silicone sealant Part No. 999MP-A7007 or equivalent.)
 - Be sure liquid gasket is 3.5 to 4.5 mm (0.138 to 0.177 in) dia. (for oil pan).
 - Be sure liquid gasket is 2.0 to 3.0 mm (0.079 to 0.118 in) dia. (in areas except oil pan).
3. Apply liquid gasket around the inner side of bolt holes (unless otherwise specified).
4. Assembly should be done within 5 minutes after coating.
5. Wait at least 30 minutes before refilling engine oil and engine coolant.



ENGINE LUBRICATION SYSTEM

VG33E





Preparation

Preparation

SPECIAL SERVICE TOOLS


The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

=NELC0002

Tool number (Kent-Moore No.) Tool name	Description	
ST25051001 (J25695-1) Oil pressure gauge	 NT558	Measuring oil pressure Maximum measuring range: 2,452 kPa (25 kg/cm ² , 356 psi)
ST25052000 (J25695-2) Hose	 NT559	Adapting oil pressure gauge to cylinder block
KV10115801 (J38956) Oil filter wrench	 NT362	Removing oil filter
WS39930000 (—) Tube presser	 NT052	Pressing the tube of liquid gasket


Lubrication Circuit

NELC0003




SLC082B

NELC0004

**Oil Pressure Check****WARNING:**

- Be careful not to burn yourself, as the engine and oil may be hot.
 - Oil pressure check should be done in “Neutral position” (M/T) or “Parking position” (A/T).
1. Check oil level.
 2. Remove oil pressure switch.
 3. Install pressure gauge.
 4. Start engine and warm it up to normal operating temperature.
 5. Check oil pressure with engine running under no-load.



Engine speed rpm	Approximate discharge pressure kPa (kg/cm ² , psi)
Idle speed	More than 59 (0.6, 9)
2,000	412 - 451 (4.2 - 4.6, 60 - 65)

If difference is extreme, check oil passage and oil pump for oil leaks.

6. Install oil pressure switch with sealant.

: 12.25 – 17.15 N·m (1.3 – 1.7 kg-m, 9 – 12 ft-lb)

Oil Pump**REMOVAL AND INSTALLATION**

NELC0005

1. Drain engine oil.
2. Drain engine coolant from drain plug on radiator.
3. Remove air duct (from mass air flow sensor to throttle body).
4. Remove cooling fan.
5. Remove radiator hoses (upper and lower) and fan shroud. Refer to “Radiator”.
6. Remove drive belts. Refer to **MA-26**.
7. Remove crankshaft pulley and front upper and lower belt covers. Refer to **EM-77**.
8. Remove oil pan. Refer to **EM-74**.
9. Remove oil strainer.
10. Remove oil pump assembly.


ENGINE LUBRICATION SYSTEM

VG33E


Oil Pump (Cont'd)

DISASSEMBLY AND ASSEMBLY

NELC0006







- Always replace with new oil seal and gasket.
- When installing oil pump, apply engine oil to inner and outer gears.
- Be sure that O-ring is properly installed.



INSPECTION

NELC0007
Using a feeler gauge, straightedge and micrometers, check the following clearances:

Unit: mm (in)



REGULATOR VALVE INSPECTION

NELC0008

1. Visually inspect components for wear and damage.
2. Check oil pressure regulator valve sliding surface and valve spring.
3. Coat regulator valve with engine oil. Check that it falls smoothly into the valve hole by its own weight.

If damaged, replace regulator valve set or oil pump assembly.


OIL FILTER

NELC0009

The oil filter is a small, full-flow cartridge type and is provided with a relief valve.

- The new and previous oil filter designs differ from each other and are not interchangeable.
- Use Tool KV10115801 (J38956) for removing oil filter.

Oil Pump (Cont'd)

**OIL FILTER BRACKET**

NELC0010

1. Remove oil filter.
2. Disconnect oil pressure switch and connector.
3. Remove oil filter bracket.

ENGINE LUBRICATION SYSTEM

VG33E

Service Data and Specifications (SDS)

Service Data and Specifications (SDS)

OIL PRESSURE CHECK

=NELC0011

GI

Engine speed rpm	Approximate discharge pressure kPa (kg/cm ² , psi)
Idle speed	More than 59 (0.6, 9)
2,000	412 - 451 (4.2 - 4.6, 60 - 65)

MA

EM

REGULATOR VALVE

NELC0012

Unit: mm (in)

LC

Regulator valve to oil pump cover clearance	0.040 - 0.097 (0.0016 - 0.0038)
---	---------------------------------

OIL PUMP

NELC0013

Unit: mm (in)

EC

Body to outer gear radial clearance	0.114 - 0.200 (0.0045 - 0.0079)
Inner gear to outer gear tip clearance	Below 0.18 (0.0071)
Body to inner gear axial clearance	0.05 - 0.09 (0.0020 - 0.0035)
Body to outer gear axial clearance	0.050 - 0.110 (0.0020 - 0.0043)
Inner gear to brazed portion of housing clearance	0.045 - 0.091 (0.0018 - 0.0036)

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

Precautions

Precautions

SUPPLEMENTAL RESTRAINT SYSTEM (SRS) "AIR BAG" AND "SEAT BELT PRE-TENSIONER"

NELC0139


The Supplemental Restraint System "AIR BAG" and "SEAT BELT PRE-TENSIONER" (crew cab model only), used along with a seat belt, help to reduce the risk or severity of injury to the driver and front passenger in a frontal collision. The Supplemental Restraint System consists of air bag modules (located in the center of the steering wheel and in the instrument panel on the passenger side), seat belt pre-tensioners (crew cab model only), a diagnosis sensor unit, a crash zone sensor (4WD models), warning lamp, wiring harness, and spiral cable.

The vehicle (except crew cab model) is equipped with a passenger air bag deactivation switch. Because no rear seat exists where a rear-facing child restraint can be placed, the switch is designed to turn off the passenger air bag so that a rear-facing child restraint can be used in the front passenger seat. The switch is located in the center of the instrument panel, near the ashtray. When the switch is turned to the ON position, the passenger air bag is enabled and could inflate in a frontal collision. When the switch is turned to the OFF position, the passenger air bag is disabled and will not inflate in a frontal collision. A passenger air bag OFF indicator on the instrument panel lights up when the passenger air bag is switched OFF. The driver air bag always remains enabled and is not affected by the passenger air bag deactivation switch.

Information necessary to service the system safely is included in the **RS section** of this Service Manual.


WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance should be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the RS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. Spiral cable and wiring harnesses (except "SEAT BELT PRE-TENSIONER") are covered with yellow insulation either just before the harness connectors or on the complete harness, for easy identification.
- The vehicle (except crew cab model) is equipped with a passenger air bag deactivation switch which can be operated by the customer. When the passenger air bag is switched OFF, the passenger air bag is disabled and will not inflate in a frontal collision. When the passenger air bag is switched ON, the passenger air bag is enabled and could inflate in a frontal collision. After SRS maintenance or repair, make sure the passenger air bag deactivation switch is in the same position (ON or OFF) as when the vehicle arrived for service.

**LIQUID GASKET APPLICATION PROCEDURE**

NELC0014

1. Use a scraper to remove all traces of old liquid gasket from mating surface and grooves. Also, completely clean any oil from these areas.
2. Apply a continuous bead of liquid gasket to mating surfaces. (Use Genuine RTV silicone sealant Part No. 999MP-A7007 or equivalent.)
 - Be sure liquid gasket is 3.5 to 4.5 mm (0.138 to 0.177 in) dia. (for oil pan).
 - Be sure liquid gasket is 2.0 to 3.0 mm (0.079 to 0.118 in) dia. (in areas except oil pan).
3. Apply liquid gasket around the inner side of bolt holes (unless otherwise specified).
4. Assembly should be done within 5 minutes after coating.
5. Wait at least 30 minutes before refilling engine oil and engine coolant.





Preparation

SPECIAL SERVICE TOOLS


The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

=NELC0015

Tool number (Kent-Moore No.) Tool name	Description
EG17650301 (J33984-A) Radiator cap tester adapter	 <p>Adapting radiator cap tester to radiator filler neck a: 28 (1.10) dia. b: 31.4 (1.236) dia. c: 41.3 (1.626) dia. Unit: mm (in)</p> <p>NT564</p>
WS39930000 (—) Tube presser	 <p>Pressing the tube of liquid gasket</p> <p>NT052</p>

Cooling Circuit

=NELC0016



System Check


=NELC0017

WARNING:


Never remove the radiator cap when the engine is hot. Serious burns could occur from high pressure coolant escaping from the radiator.

Wrap a thick cloth around the cap. Slowly turn it a quarter turn to allow built-up pressure to escape. Carefully remove the cap by turning it all the way.

System Check (Cont'd)

**CHECKING COOLING SYSTEM HOSES**

NELC0017S01
Check hoses for improper attachment, leaks, cracks, damage, loose connections, chafing and deterioration.

**CHECKING RADIATOR CAP**


To check radiator cap, apply pressure to cap with a tester. NELC0017S02

Radiator cap relief pressure:**Standard**

78 - 98 kPa (0.8 - 1.0 kg/cm², 11 - 14 psi)

Limit

59 - 98 kPa (0.6 - 1.0 kg/cm², 9 - 14 psi)



Pull the negative pressure valve to open it.

Check that it closes completely when released.

CHECKING RADIATOR

NELC0017S04
Check radiator for mud or clogging. If necessary, clean radiator as follows.

- Be careful not to bend or damage the radiator fins.
 - When radiator is cleaned without removal, remove all surrounding parts such as cooling fan, radiator shroud and horns.
 - Tape the harness connectors to prevent water from entering.
- 1) Apply water by hose to the back side of the radiator core vertically downward.
 - 2) Apply water again to all radiator core surfaces once per minute.
 - 3) Stop washing when stains no longer flow out from the radiator.
 - 4) Blow air into the back side of radiator core vertically downward.
 - Use compressed air lower than 490 kPa (5 kg/cm², 71 psi) and keep distance more than 30 cm (11.8 in).
 - 5) Blow air again into all the radiator core surfaces once per minute until no water sprays out.

CHECKING COOLING SYSTEM FOR LEAKS

NELC0017S03
To check for leakage, apply pressure to the cooling system with a tester.


Testing pressure: 157 kPa (1.6 kg/cm², 23 psi)

CAUTION:

Higher pressure than specified may cause radiator damage.

Water Pump REMOVAL



NELC0018



N·m (kg·m, ft·lb)

CAUTION:


- When removing water pump assembly, be careful not to get coolant on timing belt.
- Water pump cannot be disassembled and should be replaced as a unit.
- After installing water pump, connect hose and clamp securely, then check for leaks using radiator cap tester.
- To avoid deforming timing cover, make sure there is adequate clearance between it and the hose clamp.




1. Drain coolant from drain plugs on both sides of cylinder block and radiator. Refer to **MA-27**.

Water Pump (Cont'd)


2. Remove radiator hoses (upper and lower) and fan shroud. Refer to "Radiator", LC-32.
3. Remove drive belts. Refer to **MA-26**.
4. Remove water pump pulley.
5. Remove crankshaft pulley and front (upper and lower) belt cover. Refer to **EM-77**.
6. Remove water pump.

**INSPECTION**

- NELC0019
1. Check for badly rusted or corroded body assembly and vanes.
 2. Check for rough operation due to excessive end play.

**INSTALLATION**

- NELC0132
1. Use a scraper to remove liquid gasket from water pump.
 - **Also remove traces of liquid gasket from mating surface of cylinder block.**



2. Apply a continuous bead of liquid gasket to mating surface of water pump.
- **Use Genuine RTV Silicone Sealant Part No. 999 MP-A7007 or equivalent.**

When filling radiator with coolant, refer to "Changing Engine Coolant", MA-27.

When installing drive belts, refer to MA-26.

Thermostat**REMOVAL**

- NELC0020
1. Drain engine coolant from drain plugs on radiator.
 2. Remove radiator hoses (upper and lower) and fan shroud.
 3. Remove drive belts.
 4. Remove pulley bracket.
 5. Remove water inlet and thermostat assembly.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA



SC

EL

IDX

INSPECTION


- NELC0021
1. Check valve seating condition at ordinary temperatures. It should seat tightly.




2. Check valve opening temperature and valve lift.

Valve opening temperature °C (°F)	82 (180)
Valve lift mm/°C (in/°F)	More than 10/95 (0.39/203)

3. Then check if valve is closed at 5°C (9°F) below valve opening temperature.

**INSTALLATION**

- NELC0022
1. Install thermostat with jiggle valve or air bleeder at upper side.



2. When installing water inlet apply liquid gasket as shown.

- After installation, run engine for a few minutes, and check for leaks.
- Be careful not to spill coolant over engine compartment. Use a rag to absorb coolant.

Radiator


Radiator**REMOVAL AND INSTALLATION**

NELC0023

1. Remove under cover.
2. Drain coolant from radiator drain plug.
3. Remove air duct. (From mass air flow sensor to throttle body)
4. Disconnect radiator upper and lower hoses.
5. Remove A/T oil cooler hoses. (A/T model only)
6. Remove radiator lower shroud.
7. Disconnect reservoir tank hose.
8. Remove radiator.
9. After repairing or replacing radiator, install any part removed in reverse order of removal.

COMPONENTS

NELC0024

SEC. 214


: N·m (kg·m, in·lb)

: N·m (kg·m, ft·lb)


ALC111

NELC0028

GI


**INSPECTION**

1. Apply pressure with Tool.

Specified pressure value:157 kPa (1.6 kg/cm², 23 psi)**WARNING:**


To prevent the risk of the hose coming undone while under pressure, securely fasten it down with a hose clamp.

Attach a hose to the oil cooler as well. (A/T model only)

**Cooling Fan (Crankshaft driven)****REMOVAL AND INSTALLATION**

NELC0029

- Do not release the drive belt tension by removing the fan/water pump pulley.
- Fan coupling cannot be disassembled and should be replaced as a unit. If front mark **F** is present, install fan so that side marked **F** faces the front.
- Install the drive belt only after the fan and fan coupling to water pump flange bolts/nuts have been properly torqued.
- Proper alignment of these components is essential. Improper alignment will cause them to wobble and may eventually cause the fan to separate from the water pump causing extensive damage.

**INSPECTION**


NELC0030

Check fan coupling for rough operation, wobbling, oil leakage or bent bimetal.

ENGINE COOLING SYSTEM

VG33E

Cooling Fan (Crankshaft driven) (Cont'd)



SLC151B

After assembly, verify the fan does not wobble or flap while the engine is running.

WARNING:

- When the engine is running, keep hands and clothing away from moving parts such as drive belts and fan.

Refilling Engine Coolant

For details on refilling engine coolant, refer to "REFILLING ENGINE COOLANT", **MA-27**.

GI

MA

EM

LC

Overheating Cause Analysis

NELC0032

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

	Symptom	Check items	
Cooling system parts malfunction	Poor heat transfer	Water pump malfunction	—
		Thermostat stuck closed	—
		Damaged fins	Dust contamination or paper clogging Mechanical damage
		Clogged radiator cooling tube	Excess foreign material (rust, dirt, sand, etc.)
	Reduced air flow	Cooling fan does not operate	—
		High resistance to fan rotation	—
		Damaged fan blades	—
	Damaged radiator shroud	—	—
	Improper coolant mixture ratio	—	—
	Poor coolant quality	—	—
Insufficient coolant	Coolant leaks	Cooling hose	Loose clamp Cracked hose
			Water pump Poor sealing
		Radiator cap	Loose Poor sealing
			O-ring for damage, deterioration or improper fitting Cracked radiator tank
		Radiator	Cracked radiator core
			Reservoir tank Cracked reservoir tank
	Overflowing reservoir tank	Exhaust gas leaks into cooling system	Cylinder head deterioration
			Cylinder head gasket deterioration

ENGINE COOLING SYSTEM

VG33E

Overheating Cause Analysis (Cont'd)

Symptom		Check items	
Except cooling system parts malfunction	Overload on engine	Abusive driving	High engine rpm under no-load Driving in low gear for extended time Driving at extremely high speed
		Powertrain system malfunction	—
		Installed improper size wheels and tires	—
		Dragging brakes	—
		Improper ignition timing.	—
	Blocked or restricted air flow	Blocked bumper	—
		Blocked radiator grille	Installed car brassiere Mud contamination or paper clogging
		Blocked radiator	—
		Blocked condenser	—
		Installed large fog lamp	—

Service Data and Specifications (SDS)

THERMOSTAT

NELC0033

Valve opening temperature °C (°F)	82 (180)
Valve lift mm°C (in°F)	More than 10/95 (0.39/203)

RADIATOR

NELC0034
Unit: kPa (kg/cm², psi)

Cap relief pressure	Standard	78 - 98 (0.8 - 1.0, 11 - 14)
	Limit	59 - 98 (0.6 - 1.0, 9 - 14)
Leakage test pressure		157 (1.6, 23)