

SECTION **PG**

POWER SUPPLY, GROUND & CIRCUIT ELEMENTS

CONTENTS

| | | | | |
|--------------------------------------------------------------------------------------------------|----|-----------------------------------------------------------------------------------------------|----|----|
| PRECAUTION | 3 | Terminal Arrangement | 77 | A |
| PRECAUTIONS | 3 | FUSE AND RELAY BOX | 78 | B |
| Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" | 3 | Terminal Arrangement | 78 | C |
| Precaution for Power Generation Variable Voltage Control System | 3 | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) | 79 | D |
| PREPARATION | 4 | IPDM E/R Terminal Arrangement | 79 | E |
| PREPARATION | 4 | BASIC INSPECTION | 80 | F |
| Special Service Tool | 4 | BATTERY | 80 | G |
| Commercial Service Tool | 4 | How to Handle Battery | 80 | H |
| SYSTEM DESCRIPTION | 5 | Work Flow | 80 | I |
| ELECTRICAL UNITS LOCATION | 5 | INSPECTION AND ADJUSTMENT | 83 | J |
| Electrical Units Location | 5 | ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL | 83 | K |
| COMPONENT PARTS | 8 | ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement | 83 | L |
| Circuit Breaker (Built Into BCM) | 8 | FUSE INSPECTION | 84 | PG |
| Circuit Breaker (External to BCM) | 8 | How To Check | 84 | |
| Harness Connector | 8 | FUSIBLE LINK INSPECTION | 88 | |
| Standardized Relay | 11 | Fusible Link | 88 | |
| WIRING DIAGRAM | 14 | REMOVAL AND INSTALLATION | 89 | N |
| POWER SUPPLY ROUTING CIRCUIT | 14 | BATTERY | 89 | O |
| Wiring Diagram—Battery Power Supply | 14 | Removal and Installation | 89 | |
| Wiring Diagram—Accessory Power Supply | 23 | BATTERY TERMINAL WITH FUSIBLE LINK ... | 90 | P |
| Wiring Diagram—Ignition Power Supply | 26 | Exploded View | 90 | |
| GROUND | 32 | Removal and Installation | 90 | |
| Ground Distribution | 32 | SERVICE DATA AND SPECIFICATIONS (SDS) | 91 | |
| HARNESS | 44 | SERVICE DATA AND SPECIFICATIONS (SDS) | 91 | |
| Harness Layout | 44 | | | |
| FUSE BLOCK - JUNCTION BOX (J/B) | 76 | | | |
| Terminal Arrangement | 76 | | | |
| FUSE, FUSIBLE LINK AND RELAY BOX | 77 | | | |

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000012563562

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

Precaution for Power Generation Variable Voltage Control System

INFOID:000000012563563

CAUTION:

For this model, the battery current sensor that is installed to the negative battery cable measures the charging/discharging current of the battery and performs various engine controls. If an electrical component is connected directly to the negative battery terminal, the current flowing through that component will not be measured by the battery current sensor. This condition may cause a malfunction of the engine control system and battery discharge may occur. Do not connect an electrical component or ground wire directly to the battery terminal.

A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

PREPARATION

< PREPARATION >



PREPARATION

PREPARATION

Special Service Tool


INFOID:0000000012563564

The actual shape of the tools may differ from those illustrated here.

| Tool number (TechMate No.) Tool name | Description |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>— (—) Model GR8-1200 NI Multitasking battery and electrical diagnostic station</p>  <p style="text-align: right;">AWIIA1239ZZ</p> | <p>Tests batteries, starting and charging systems and charges batteries. For operating instructions, refer to diagnostic station instruction manual.</p> |
| <p>— (—) Model EXP-800 NI Battery and electrical diagnostic analyzer</p>  <p style="text-align: right;">JSMIA0806ZZ</p> | <p>Tests batteries and charging systems. For operating instructions, refer to diagnostic analyzer instruction manual.</p> |

Commercial Service Tool

INFOID:0000000012563565

| Tool name | Description |
|---------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------|
| <p>Power tool</p>  <p style="text-align: right;">PIIB1407E</p> | <p>Loosening nuts, screws and bolts</p> |

ELECTRICAL UNITS LOCATION

< SYSTEM DESCRIPTION >



SYSTEM DESCRIPTION

ELECTRICAL UNITS LOCATION

Electrical Units Location

INFOID:0000000012563566

ENGINE COMPARTMENT




A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P


ELECTRICAL UNITS LOCATION

< SYSTEM DESCRIPTION >

PASSENGER COMPARTMENT










A Instrument panel side RH



ABMIA6558GB

ELECTRICAL UNITS LOCATION

< SYSTEM DESCRIPTION >



A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

ABMIA6559GB

COMPONENT PARTS

< SYSTEM DESCRIPTION >

COMPONENT PARTS


Circuit Breaker (Built Into BCM)

INFOID:000000012563567

For example, when current is 30A, the circuit is broken within 8 to 20 seconds.

This circuit breaker is used for the following systems:

- Power windows
- Power moonroof




Circuit Breaker (External to BCM)

INFOID:000000012563568

The PTC thermistor generates heat in response to current flow. The temperature (and resistance) of the thermistor element varies with current flow. Excessive current flow will cause the element's temperature to rise. When the temperature reaches a specified level, the electrical resistance will rise sharply to control the circuit current. Reduced current flow will cause the element to cool. Resistance falls accordingly and normal circuit current flow is allowed to resume.

This circuit breaker is used for the following systems:

- Power seats
- Power moonroof



SEL109W

Harness Connector

INFOID:000000012563569

HARNESS CONNECTOR (TAB-LOCKING TYPE)

- The tab-locking type connectors help prevent accidental looseness or disconnection.
- The tab-locking type connectors are disconnected by pushing or lifting the locking tab(s). Refer to the figure below.

Refer to the next page for description of the slide-locking type connector.


CAUTION:

Do not pull the harness or wires when disconnecting the connector.

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[Example]



SEL769DA

HARNESS CONNECTOR (SLIDE-LOCKING TYPE)

- A new style slide-locking type connector is used on certain systems and components, especially those related to OBD.
- The slide-locking type connectors help prevent incomplete locking and accidental looseness or disconnection.
- The slide-locking type connectors are disconnected by pushing or pulling the slider. Refer to the figure below.

CAUTION:


- **Do not pull the harness or wires when disconnecting the connector.**
- **Be careful not to damage the connector support bracket when disconnecting the connector.**

A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[Example]



HARNESS CONNECTOR (LEVER LOCKING TYPE)


- Lever locking type harness connectors are used on certain control units and control modules such as ECM, ABS actuator and electric unit (control unit), etc.
- Lever locking type harness connectors are also used on super multiple junction (SMJ) connectors.
- Always confirm the lever is fully locked in place by moving the lever as far as it will go to ensure full connection.

CAUTION:

COMPONENT PARTS

< SYSTEM DESCRIPTION >

- Always confirm the lever is fully released (loosened) before attempting to disconnect or connect these connectors to avoid damage to the connector housing or terminals.




- | | | |
|--------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------|---------------------------------------------------------------------------|
| <p>1. Control unit with single lever</p> <p>A. Fasten</p> <p>B. Loosen</p> <p>C. Lever</p> | <p>2. Control unit with dual lever</p> <p>A. Levers</p> <p>B. Fasten</p> <p>C. Loosen</p> | <p>3. SMJ connector</p> <p>A. Lever</p> <p>B. Fasten</p> <p>C. Loosen</p> |
|--------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------|---------------------------------------------------------------------------|

HARNESS CONNECTOR (DIRECT-CONNECT SRS COMPONENT TYPE)

- SRS direct-connect type harness connectors are used on certain SRS components such as air bag modules and seat belt pre-tensioners.
- Always pull up to release black locking tab prior to removing connector from SRS components.
- Always push down to lock black locking tab after installing connector to SRS components. When locked, the black locking tab is level with the connector housing.

CAUTION:

- Do not pull the harness or wires when removing connectors from SRS components.




Standardized Relay

NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS

COMPONENT PARTS

< SYSTEM DESCRIPTION >


Relays can mainly be divided into three types: normal open, normal closed and mixed type relays.



SEL881H

TYPE OF STANDARDIZED RELAYS
















- 1M 1 Make
- 1T 1 Transfer
- 2M 2 Make
- 1M·1B 1 Make 1 Break



SEL882H

COMPONENT PARTS

< SYSTEM DESCRIPTION >

| Type | Outer view | Circuit | Connector Symbol and connection | Case color |
|-------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|------------|
| 1T |  |  |  | BLACK |
| 2M |  |  |  | BROWN |
| 1M-1B |  |  |  | GRAY |
| 1M |  |  |  | BLACK |
| |  |  |  | BLUE |

The arrangement of terminal numbers on the actual relays may differ from those shown above.

WKIA0253E

A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

POWER SUPPLY ROUTING CIRCUIT


< WIRING DIAGRAM >

WIRING DIAGRAM

POWER SUPPLY ROUTING CIRCUIT

Wiring Diagram—Battery Power Supply

INFOID:00000001256371




ABMWA3481GB

POWER SUPPLY ROUTING CIRCUIT

< WIRING DIAGRAM >

△ : WITH AT




ABMWA3482GB

A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

POWER SUPPLY ROUTING CIRCUIT

< WIRING DIAGRAM >


QR : WITH QR25DE
 ZV : WITH VQ40DE



ABMWA3483GB

POWER SUPPLY ROUTING CIRCUIT

< WIRING DIAGRAM >



A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

PG


ABMWA2866GB

POWER SUPPLY ROUTING CIRCUIT

< WIRING DIAGRAM >

BATTERY POWER SUPPLY CONNECTORS

| | |
|-----------------|------------------|
| Connector No. | M3 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1N | R/B | - |
| 4N | R/Y | - |

| | |
|-----------------|------------------|
| Connector No. | M4 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1P | R/B | - |
| 8P | R/Y | - |
| 16P | R/B | - |

| | |
|-----------------|--------------|
| Connector No. | M6 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2 | W/G | - |

| | |
|-----------------|--------------|
| Connector No. | M31 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 81G | V | - |

| | |
|-----------------|-------------------|
| Connector No. | M82 |
| Connector Name | CIRCUIT BREAKER-2 |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | G | - |
| 2 | P | - |

| | |
|-----------------|-----------------------|
| Connector No. | M152 |
| Connector Name | TRANSFER CONTROL UNIT |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 25 | W/G | IGN SW |

ABMIA5558GB

POWER SUPPLY ROUTING CIRCUIT

< WIRING DIAGRAM >

| | |
|-----------------|-----------------------|
| Connector No. | M153 |
| Connector Name | TRANSFER CONTROL UNIT |
| Connector Color | WHITE |



| | | | | | |
|--------------|----|---------------|---|-------------|------|
| Terminal No. | 40 | Color of Wire | V | Signal Name | SSOF |
|--------------|----|---------------|---|-------------|------|

| | |
|-----------------|--------------|
| Connector No. | E10 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| | | | | | |
|--------------|---|---------------|-----|-------------|---|
| Terminal No. | 2 | Color of Wire | W/G | Signal Name | - |
|--------------|---|---------------|-----|-------------|---|

| | |
|-----------------|----------------------------|
| Connector No. | E30 |
| Connector Name | FUSIBLE LINK BOX (BATTERY) |
| Connector Color | - |



| | | | | | |
|--------------|---|---------------|---|-------------|---|
| Terminal No. | 3 | Color of Wire | R | Signal Name | - |
|--------------|---|---------------|---|-------------|---|

| | |
|-----------------|--------------------------------------------------------------|
| Connector No. | E118 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | BLACK |




| | | | | | |
|--------------|---|---------------|---|-------------|----------|
| Terminal No. | 1 | Color of Wire | W | Signal Name | F/L USM |
| Terminal No. | 2 | Color of Wire | R | Signal Name | F/L MAIN |

| | |
|-----------------|--------------------------------------------------------------|
| Connector No. | E119 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | WHITE |



| | | | | | |
|--------------|----|---------------|-----|-------------|-------------------------|
| Terminal No. | 3 | Color of Wire | G | Signal Name | IGN COIL |
| Terminal No. | 4 | Color of Wire | P | Signal Name | ECM (FOR MEXICO) |
| Terminal No. | 4 | Color of Wire | R | Signal Name | ECM (EXCEPT FOR MEXICO) |
| Terminal No. | 6 | Color of Wire | V | Signal Name | ETC |
| Terminal No. | 7 | Color of Wire | BR | Signal Name | ECM RLY CONT |
| Terminal No. | 10 | Color of Wire | R/B | Signal Name | DTRL RLY SUPPLY |

| | |
|-----------------|--------------------------------------------------------------|
| Connector No. | E121 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | BROWN |



| | | | | | |
|--------------|----|---------------|-----|-------------|--------------------|
| Terminal No. | 28 | Color of Wire | R | Signal Name | CLEARANCE FRONT LH |
| Terminal No. | 29 | Color of Wire | G | Signal Name | TRAILER RLY CONT |
| Terminal No. | 30 | Color of Wire | R/B | Signal Name | ECM BAT |

POWER SUPPLY ROUTING CIRCUIT


< WIRING DIAGRAM >

| | |
|-----------------|--------------------------------------------------------------|
| Connector No. | E124 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | BLACK |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--------------------|
| 57 | GR | TAIL LAMP |
| 59 | B | GND (POWER) |
| 61 | R/B | TRAILER RLY SUPPLY |

| | |
|-----------------|--------------------------------------------------------------|
| Connector No. | E123 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | BROWN |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--------------------|
| 49 | GR | CLEARANCE FRONT RH |
| 50 | W | FR FOG LAMP LH |
| 51 | V | FR FOG LAMP RH |
| 52 | P | H/LAMP LO LH |
| 54 | R | H/LAMP LO RH |
| 55 | G | H/LAMP HI LH |
| 56 | L | H/LAMP HI RH |

| | |
|-----------------|--------------------------------------------------------------|
| Connector No. | E122 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|----------------------------------|
| 38 | B | GND (SIGNAL) |
| 47 | W | ETC RLY CONT (FOR MEXICO) |
| 47 | BG | ETC RLY CONT (EXCEPT FOR MEXICO) |

| | |
|-----------------|----------------------------|
| Connector No. | E129 |
| Connector Name | FUSIBLE LINK BOX (BATTERY) |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | W | - |
| 2 | R | - |

| | |
|-----------------|----------------------------|
| Connector No. | E128 |
| Connector Name | FUSIBLE LINK BOX (BATTERY) |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 4 | W | - |
| 7 | W | - |

ABMIA6665GB

POWER SUPPLY ROUTING CIRCUIT

< WIRING DIAGRAM >

| | |
|-----------------|---------------------------|
| Connector No. | E157 |
| Connector Name | TRANSFER SHUT OFF RELAY 2 |
| Connector Color | BLUE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | G | - |
| 2 | V | - |
| 3 | B | - |
| 5 | W | - |

| | |
|-----------------|---------------------------|
| Connector No. | E156 |
| Connector Name | TRANSFER SHUT OFF RELAY 1 |
| Connector Color | BLUE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | W/G | - |
| 2 | B | - |
| 3 | B | - |
| 5 | W | - |

| | |
|-----------------|--------------|
| Connector No. | E152 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 81G | V | - |

| | |
|-----------------|----------------------------|
| Connector No. | E202 |
| Connector Name | FUSIBLE LINK BOX (BATTERY) |
| Connector Color | - |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 5 | B/R | - |

| | |
|-----------------|------------------|
| Connector No. | E160 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 8Q | R/B | - |

| | |
|-----------------|------------------|
| Connector No. | E158 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1S | W | - |

ABMIA5560GB

A B C D E F G H I J K L N O P

PG

POWER SUPPLY ROUTING CIRCUIT

< WIRING DIAGRAM >

| | |
|-----------------|---------------|
| Connector No. | E210 |
| Connector Name | STARTER MOTOR |
| Connector Color | - |



| | | | | | |
|--------------|---|---------------|-----|-------------|---|
| Terminal No. | 2 | Color of Wire | B/R | Signal Name | - |
|--------------|---|---------------|-----|-------------|---|

| | |
|-----------------|-----------|
| Connector No. | E206 |
| Connector Name | GENERATOR |
| Connector Color | - |



| | | | | | |
|--------------|---|---------------|-----|-------------|---|
| Terminal No. | 1 | Color of Wire | B/R | Signal Name | - |
|--------------|---|---------------|-----|-------------|---|

| | |
|-----------------|----------------------------|
| Connector No. | E204 |
| Connector Name | FUSIBLE LINK BOX (BATTERY) |
| Connector Color | - |



| | | | | | |
|--------------|---|---------------|-----|-------------|---|
| Terminal No. | 6 | Color of Wire | B/R | Signal Name | - |
|--------------|---|---------------|-----|-------------|---|

ABMIA4370GB


POWER SUPPLY ROUTING CIRCUIT

< WIRING DIAGRAM >

Wiring Diagram—Accessory Power Supply

INFOID:000000012563572

ACCESSORY POWER SUPPLY




A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

PG

ABMWA2827GB


ACCESSORY POWER SUPPLY CONNECTORS

| | |
|-----------------|------------------|
| Connector No. | M3 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Color | WHITE |



| | | | | | |
|--------------|----|---------------|---|-------------|---|
| Terminal No. | 7N | Color of Wire | B | Signal Name | - |
|--------------|----|---------------|---|-------------|---|

| | |
|-----------------|------------------|
| Connector No. | M4 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Color | WHITE |



| | | | | | |
|--------------|-----|---------------|-----|-------------|---|
| Terminal No. | 4P | Color of Wire | G/B | Signal Name | - |
| Terminal No. | 10P | Color of Wire | G/Y | Signal Name | - |
| Terminal No. | 12P | Color of Wire | G/Y | Signal Name | - |

| | |
|-----------------|--------------|
| Connector No. | M6 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| | | | | | |
|--------------|---|---------------|-----|-------------|---|
| Terminal No. | 1 | Color of Wire | G/Y | Signal Name | - |
| Terminal No. | 4 | Color of Wire | G | Signal Name | - |

| | |
|-----------------|-----------------|
| Connector No. | M26 |
| Connector Name | IGNITION SWITCH |
| Connector Color | WHITE |



| | | | | | |
|--------------|-----|---------------|-----|-------------|---|
| Terminal No. | B | Color of Wire | G | Signal Name | - |
| Terminal No. | ACC | Color of Wire | G/Y | Signal Name | - |

| | |
|-----------------|--------------|
| Connector No. | E10 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| | | | | | |
|--------------|---|---------------|-----|-------------|---|
| Terminal No. | 1 | Color of Wire | G/Y | Signal Name | - |
| Terminal No. | 4 | Color of Wire | G | Signal Name | - |

| | |
|-----------------|----------------------------|
| Connector No. | E128 |
| Connector Name | FUSIBLE LINK BOX (BATTERY) |
| Connector Color | GRAY |




| | | | | | |
|--------------|---|---------------|---|-------------|---|
| Terminal No. | 4 | Color of Wire | W | Signal Name | - |
|--------------|---|---------------|---|-------------|---|

ABMIA0380GB

POWER SUPPLY ROUTING CIRCUIT

< WIRING DIAGRAM >

| | |
|-----------------|------------------|
| Connector No. | E160 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 6Q | G/Y | - |

| | |
|-----------------|------------------|
| Connector No. | E158 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1S | W | - |

| | |
|-----------------|-----------------------------------------|
| Connector No. | J-2 |
| Connector Name | FUSE BLOCK (J/B) (ACCESSORY RELAY-1) |
| Connector Color | - |



ABMIA4371GB


A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

POWER SUPPLY ROUTING CIRCUIT

< WIRING DIAGRAM >

Wiring Diagram—Ignition Power Supply

INFOID:000000012563573




ABMWA3480GB

POWER SUPPLY ROUTING CIRCUIT

< WIRING DIAGRAM >


QR : WITH QR25DE
ZV : WITH VQ40DE



A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

POWER SUPPLY ROUTING CIRCUIT

< WIRING DIAGRAM >




ABMWA2864GB

POWER SUPPLY ROUTING CIRCUIT

< WIRING DIAGRAM >

IGNITION POWER SUPPLY CONNECTORS

| | |
|-----------------|------------------|
| Connector No. | M3 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 5N | W/G | - |

| | |
|-----------------|------------------|
| Connector No. | M4 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2P | W/G | - |
| 5P | W/G | - |
| 6P | W/R | - |
| 9P | W/G | - |
| 13P | W/G | - |
| 15P | W/R | - |

| | |
|-----------------|--------------|
| Connector No. | M6 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2 | W/G | - |
| 3 | GR | - |
| 4 | G | - |
| 5 | R | - |

| | |
|-----------------|-----------------|
| Connector No. | M26 |
| Connector Name | IGNITION SWITCH |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| B | G | - |
| ST | GR | - |
| IG1 | W/G | - |
| IG2 | R | - |

| | |
|-----------------|--------------|
| Connector No. | E10 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2 | W/G | - |
| 3 | GR | - |
| 4 | G | - |
| 5 | R | - |

| | |
|-----------------|--------------------------------------------------------------|
| Connector No. | E118 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | W | F/L USM |
| 2 | R | F/L MAIN |

ABMIA4424GB

A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

POWER SUPPLY ROUTING CIRCUIT

< WIRING DIAGRAM >

| | |
|-----------------|--------------------------------------------------------------|
| Connector No. | E120 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | WHITE |

| | | |
|----|----|----|
| 21 | 20 | 19 |
| 24 | 23 | 22 |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---------------|
| 19 | W | STARTER MTR |
| 20 | BR | MOTOR FAN 1 |
| 21 | GR | IGN SW (ST) |
| 22 | G | F/L MOTOR FAN |
| 23 | LG | HEATED MIRROR |
| 24 | P | MOTOR FAN 2 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|----------------|
| 15 | W/R | ABS IGN SUPPLY |
| 16 | W/G | REVERSE LAMP |
| 17 | W/G | INJECTOR |

| | |
|-----------------|--------------------------------------------------------------|
| Connector No. | E119 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | WHITE |

| | | | | | | |
|----|----|----|----|----|----|----|
| 9 | 8 | 7 | 6 | 5 | 4 | 3 |
| 18 | 17 | 16 | 15 | 14 | 13 | 12 |
| 11 | 10 | 9 | 8 | 7 | 6 | 5 |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--------------------|
| 8 | W/R | O2 SENSOR |
| 11 | Y | A/C COMPRESSOR |
| 12 | W/G | IGN SW (IG) |
| 13 | R | FUEL PUMP |
| 14 | W/G | A/T ECU IGN SUPPLY |

| | |
|-----------------|--------------------------------------------------------------|
| Connector No. | E124 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | BLACK |

| | | |
|----|----|----|
| 59 | 58 | 57 |
| 62 | 61 | 60 |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 59 | B | GND (POWER) |
| 60 | GR | RR DEF |

| | |
|-----------------|--------------------------------------------------------------|
| Connector No. | E122 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | WHITE |

| | | | | | |
|----|----|----|----|----|----|
| 42 | 41 | 40 | 39 | 38 | 37 |
| 48 | 47 | 46 | 45 | 44 | 43 |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--------------------|
| 38 | B | GND (SIGNAL) |
| 39 | L | CAN-H |
| 40 | P | CAN-L |
| 43 | G | AUTO STOP SW |
| 46 | V | FUEL PUMP RLY CONT |
| 48 | R | RANGE SW |

| | |
|-----------------|--------------------------------------------------------------|
| Connector No. | E121 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | BROWN |

| | | | | |
|----|----|----|----|----|
| 29 | 28 | 27 | 26 | 25 |
| 36 | 35 | 34 | 33 | 32 |
| 31 | 30 | 29 | 28 | 27 |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|----------------|
| 27 | W/G | T TOW REV LAMP |
| 32 | GR | FR WIPER LO |
| 35 | L | FR WIPER HI |


ABMIA6666GB

POWER SUPPLY ROUTING CIRCUIT

< WIRING DIAGRAM >

A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

| | |
|-----------------|------------------|
| Connector No. | E160 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1Q | W/G | - |
| 2Q | R | - |
| 5Q | W/R | - |

| | |
|-----------------|------------------|
| Connector No. | E159 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1R | W/G | - |
| 2R | W/G | - |

ABMIA1464GB

GROUND



< WIRING DIAGRAM >

GROUND

Ground Distribution

INFOID:000000012563574



MAIN HARNESS



ABMIA6563GB

GROUND

< WIRING DIAGRAM >



| CONNECTOR NUMBER | CONNECT TO |
|------------------|----------------------------------------------------------|
| (M13) | Front passenger air bag OFF indicator |
| (M24) | Combination meter (Terminal No. 13) |
| (M34) | In-vehicle sensor |
| (M35) | Air bag diagnosis sensor unit (Terminal No. 2) |
| (M47) | Steering angle sensor |
| (M49) | Front air control (Terminal No. 20) (manual with type 2) |
| (M51) | Front blower switch |
| (M55) | Hazard switch |
| (M56) | Front air control (Terminal No. 35) (with auto A/C) |
| (M59) | Front air control (Terminal No. 35) (manual with type 1) |
| (M71) | Cargo lamp switch |
| (M121) | Variable blower control (front) |
| (M152) | Transfer control unit (Terminal No. 6) |
| (M152) | Transfer control unit (Terminal No. 18) |
| (M153) | Transfer control unit (Terminal No. 32) |
| (M154) | VDC OFF switch |
| (M155) | Hill descent control switch |
| (M156) | A/T shift selector (Terminal No. 2) |
| (M156) | A/T shift selector (Terminal No. 8) |
| (M156) | A/T shift selector (Terminal No. 10) |
| (M159) | Door mirror remote control switch |
| (M160) | Front heated seat switch RH |
| (M161) | Front heated seat switch LH |
| (M163) | Clutch interlock cancel switch |

A
B
C
D
E
F
G
H
I
J
K
L



PG

N
O
P

ABMIA5552GB

GROUND

< WIRING DIAGRAM >





ABMIA4384GB

GROUND

< WIRING DIAGRAM >

ENGINE ROOM HARNESS




A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

PG


AAMIA2131GB

GROUND

< WIRING DIAGRAM >




⊃ZV⊃ : WITH VQ40DE




ABMIA6564GB

GROUND

< WIRING DIAGRAM >



⬡ZV⬢ : WITH VQ40DE




ABMIA6571GB

A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

GROUND





< WIRING DIAGRAM >



ABMIA6572GB

GROUND

< WIRING DIAGRAM >





ABMIA6565GB

A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

GROUND

< WIRING DIAGRAM >

ENGINE CONTROL HARNESS (VQ40DE MODELS)





ABMIA6573GB

GROUND

< WIRING DIAGRAM >

ENGINE CONTROL HARNESS (QR25DE MODELS)



A
B
C
D
E
F
G
H
I
J
K
L
N
O
P



PG

ABMIA6574GB

GROUND

< WIRING DIAGRAM >

BODY HARNESS





ABMIA6575GB

GROUND

< WIRING DIAGRAM >

BODY NO. 2 HARNESS



ABMIA6566GB

A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

HARNESS

< WIRING DIAGRAM >

HARNESS

Harness Layout

INFOID:000000012786565


HOW TO READ HARNESS LAYOUT

The following Harness Layouts use a map style grid to help locate connectors on the drawings:

- Main Harness and Console Sub-harness
- Engine Room Harness (RH View), Generator Sub-harness and Trailer Tow Harness
- Engine Room Harness (Passenger Compartment)
- Engine Room Harness (LH View)
- Engine Control Harness (QR25DE Models) and Injector Sub-harness
- Engine Control Harness (VQ40DE Models), Injector Sub-harness, Ignition Coil Sub-harness and Knock Sensor Sub-harness
- Chassis Harness, Differential Lock Sub-harness, Trailer Sub-harness and Tail Lamp Sub-harness, Rear sonar sub-harness, Rear view camera sub-harness
- Body Harness (King Cab Models) and Front Seat LH Harness
- Body Harness (Crew Cab Models) and Front Seat LH Harness
- Body No. 2 Harness (King Cab Models) and Front Seat RH Harness
- Body No. 2 Harness (Crew Cab Models) and Front Seat RH Harness
- Room Lamp Harness

To use the grid reference


1. Find the desired connector number on the connector list.
2. Find the grid reference.
3. On the drawing, find the crossing of the grid reference letter column and number row.
4. Find the connector number in the crossing zone.
5. Follow the line to the connector.



HARNESS

< WIRING DIAGRAM >

OUTLINE (KING CAB MODELS)




A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

HARNESS

< WIRING DIAGRAM >


OUTLINE (CREW CAB MODELS)



HARNESS

< WIRING DIAGRAM >

MAIN HARNESS



AAMIA0572ZZ

| | | | | | | | |
|----|----|------|-----------------------|----|-----|------|--------------------------------------------------------|
| A3 | M1 | W/24 | : To R1 | F2 | M75 | W/10 | : To D153 |
| F1 | M2 | G/20 | : Joint connector-M03 | B3 | M76 | W/6 | : Electric brake (pre-wiring) |
| F1 | M3 | W/8 | : Fuse block (J/B) | D1 | M77 | Y/4 | : Front passenger air bag module (service replacement) |
| F2 | M4 | W/16 | : Fuse block (J/B) | E1 | M79 | — | : Body ground |
| A5 | M6 | W/6 | : To E10 | A3 | M82 | W/2 | : Circuit breaker-2 |

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

PG

HARNESS

< WIRING DIAGRAM >

| | | | | | | | |
|----|-----|-------|------------------------------------------------------|----|------|------|-------------------------------------------------|
| A4 | M8 | BR/12 | : To D2 | A4 | M91 | W/16 | : To E26 |
| A4 | M9 | W/12 | : To D1 | A3 | M92 | W/4 | : Sonar buzzer |
| A4 | M10 | Y/4 | : To E29 | A3 | M93 | W/16 | : Sonar control unit |
| D2 | M12 | W/20 | : Audio unit (base audio system - for Mexico) | C3 | M94 | GR/8 | : Sonar system off switch |
| C3 | M13 | BR/3 | : Front passenger air bag OFF indicator | D2 | M96 | W/20 | : AV control unit (with NAVI with amplifier) |
| C1 | M14 | B/4 | : Optical sensor and sunload sensor | C2 | M97 | W/24 | : AV control unit (with NAVI with amplifier) |
| E3 | M17 | W/16 | : To B163 | D2 | M98 | B/6 | : AV control unit (with NAVI with amplifier) |
| B2 | M18 | W/40 | : BCM (body control module) | E2 | M105 | Y/2 | : Front passenger air bag module |
| B3 | M19 | W/15 | : BCM (body control module) | E2 | M106 | O/2 | : Front passenger air bag module |
| B3 | M20 | B/15 | : BCM (body control module) | C2 | M107 | W/20 | : AV control unit (with NAVI without amplifier) |
| C4 | M21 | W/4 | : NATS antenna amp. | C2 | M108 | W/24 | : AV control unit (with NAVI without amplifier) |
| C3 | M22 | W/16 | : Data link connector | A2 | M109 | BR/2 | : Front tweeter LH |
| F2 | M23 | Y/4 | : To D154 | C2 | M110 | B/6 | : AV control unit (with NAVI without amplifier) |
| B2 | M24 | W/40 | : Combination meter | E1 | M111 | BR/2 | : Front tweeter RH |
| A4 | M25 | Y/4 | : To D5 | E2 | M120 | W/4 | : Remote keyless entry receiver |
| B3 | M26 | W/6 | : Ignition switch | E2 | M121 | W/4 | : Variable blower control (front) |
| B3 | M27 | W/2 | : Key switch | E2 | M122 | W/4 | : Front blower motor resistor |
| C3 | M28 | W/16 | : Combination switch | C4 | M123 | W/2 | : Tire pressure warning check connector |
| C4 | M29 | Y/6 | : Combination switch (spiral cable) | E2 | M131 | B/6 | : Air mix door motor (passenger) |
| C4 | M30 | GR/8 | : Combination switch (spiral cable) | B2 | M139 | B/2 | : Diode-6 |
| F2 | M31 | SMJ | : To E152 | D4 | M141 | GR/8 | : 4WD shift switch |
| E2 | M34 | W/4 | : In-vehicle sensor | C3 | M142 | B/6 | : Mode door motor |
| E5 | M35 | Y/28 | : Air bag diagnosis sensor unit | E2 | M146 | GR/2 | : Intake sensor |
| F3 | M36 | SMJ | : To B149 | D2 | M147 | B/6 | : Air mix door motor |
| A4 | M40 | SMJ | : To B69 | E2 | M148 | B/6 | : Air mix door motor (driver) |
| D2 | M42 | W/8 | : Audio unit (with display audio system) | E4 | M149 | W/6 | : Differential lock mode switch |
| D2 | M43 | W/20 | : Audio unit (base audio system - except for Mexico) | C3 | M150 | W/2 | : Ignition keyhole illumination |
| C2 | M44 | W/20 | : Audio unit (with display audio system) | B4 | M152 | W/26 | : Transfer control unit |
| D2 | M45 | W/32 | : Audio unit (with display audio system) | B4 | M153 | W/24 | : Transfer control unit |
| B4 | M47 | W/8 | : Steering angle sensor | D4 | M154 | GR/6 | : VDC off switch |
| D3 | M49 | B/26 | : Front air control (manual with type 2) | D4 | M155 | W/8 | : Hill descent control switch |
| D3 | M50 | B/26 | : Front air control (manual with type 1) | D4 | M156 | W/10 | : A/T shift selector |
| C3 | M51 | W/8 | : Front blower switch | B4 | M159 | W/16 | : Door mirror remote control switch |
| D2 | M52 | B/26 | : Front air control (with auto A/C) | E3 | M160 | BR/6 | : Front heated seat switch RH |
| D3 | M53 | B/3 | : Lower front power socket | D4 | M161 | W/6 | : Front heated seat switch LH |
| E3 | M54 | GR/3 | : Upper front power socket | B3 | M163 | W/8 | : Clutch interlock cancel switch |
| C3 | M55 | W/4 | : Hazard switch | A3 | M165 | L/4 | : Cargo lamp relay |
| B3 | M56 | W/18 | : Front air control (with auto A/C) | B3 | M166 | L/20 | : Joint connector-M01 |
| B3 | M57 | — | : Body ground | B3 | M167 | L/20 | : Joint connector-M02 |
| E2 | M58 | B/6 | : Intake door motor | B4 | M168 | L/4 | : Accessory relay-2 |
| E3 | M59 | B/18 | : Front air control (manual with type 1) | E4 | M169 | B/6 | : To M205 |

HARNESS

< WIRING DIAGRAM >

| | | | | | | | | | |
|----|-----|------|------------------------------------------------------|---------------------|------|-----|------------------------|---|--|
| D2 | M60 | W/16 | : Audio unit (base audio system - except for Mexico) | C4 | M170 | B/2 | : Resistor | A | |
| D2 | M61 | — | : Body ground | Console sub-harness | | | | | |
| E2 | M62 | B/2 | : Front blower motor | E5 | M204 | W/6 | : To M63 | B | |
| D4 | M63 | W/6 | : To M204 | E4 | M205 | B/6 | : To M169 | B | |
| D2 | M64 | B/6 | : Audio unit (with display audio system) | F5 | M207 | B/3 | : Console power socket | | |
| B4 | M70 | W/26 | : Differential lock control unit | D3 | M214 | B/6 | : USB interface | C | |
| B4 | M71 | W/6 | : Cargo lamp switch | D3 | M215 | W/4 | : Aux in jack | | |
| F2 | M74 | W/12 | : To D151 | | | | | D | |

A
B
C
D

E

F

G

H

I

J

K

L

PG

N


O

P

HARNESS

< WIRING DIAGRAM >

ENGINE ROOM HARNESS (RH VIEW)



Refer to "ENGINE ROOM HARNESS (LH VIEW)" for continuation of engine room harness.

| | | | | | | | |
|----|----|------|--------------------------------|----|------|------|----------------------------------------------------------------|
| E3 | E2 | W/16 | : To F32 | E3 | E123 | BR/8 | : IPDM E/R (intelligent power distribution module engine room) |
| D1 | E5 | W/24 | : To F14 | C2 | E124 | B/6 | : IPDM E/R (intelligent power distribution module engine room) |
| C2 | E8 | B/40 | : ECM (with VQ40DE for Mexico) | D5 | E128 | GR/2 | : Fusible link box (battery) |

HARNESSES


< WIRING DIAGRAM >

| | | | | | | | | |
|----|------|-------|----------------------------------------------------------------|-----------------------|------|------|-------------------------------------|----|
| C2 | E12 | L/4 | : Stop lamp relay | D4 | E129 | B/2 | : Fusible link box (battery) | A |
| B3 | E15 | — | : Body ground | E4 | E150 | — | : Battery ground | A |
| D2 | E16 | B/32 | : ECM (with QR25DE) | C4 | E151 | — | : Negative battery cable | B |
| E3 | E19 | W/16 | : To F33 | C4 | E156 | L/4 | : Transfer shut off relay 1 | B |
| C3 | E24 | — | : Body ground | E3 | E157 | L/4 | : Transfer shut off relay 2 | C |
| C3 | E30 | — | : Fusible link box (battery) | D4 | E161 | B/3 | : Battery current sensor | C |
| E4 | E40 | GR/9 | : To E201 | C2 | E164 | L/4 | : Trailer turn relay LH | C |
| F3 | E41 | SMJ | : To C1 | E3 | E165 | L/4 | : Trailer turn relay RH | D |
| D2 | E45 | BR/6 | : Back-up lamp relay (with A/T) | D2 | E166 | BR/6 | : Clutch interlock cancel relay 2 | D |
| C3 | E46 | B/5 | : Transfer shift high relay | E4 | E168 | W/12 | : To E225 | E |
| F4 | E47 | B/5 | : Transfer shift low relay | C2 | E171 | B/5 | : Clutch interlock cancel relay 1 | E |
| D5 | E48 | B/3 | : Refrigerant pressure sensor | Generator sub-harness | | | | E |
| F4 | E54 | BR/6 | : Front blower motor relay | E3 | E201 | GR/9 | : To E40 | F |
| C2 | E55 | GR/32 | : ECM (with VQ40DE except for Mexico) | C3 | E202 | — | : Fusible link box (battery) | F |
| B5 | E102 | B/2 | : Front fog lamp RH | B4 | E203 | — | : Body ground | G |
| D2 | E103 | B/5 | : Daytime light relay 1 | C3 | E204 | — | : Fusible link box (battery) | G |
| D1 | E104 | L/4 | : Daytime light relay 2 | E5 | E205 | B/3 | : Generator | H |
| E1 | E105 | B/2 | : Front washer motor | E4 | E206 | — | : Generator | H |
| E2 | E106 | BR/2 | : Washer fluid level switch | F5 | E207 | GR/1 | : Starter motor (with VQ40DE) | I |
| C5 | E107 | B/3 | : Front combination lamp RH | E5 | E208 | GR/1 | : Oil pressure switch (with VQ40DE) | I |
| B3 | E108 | GR/2 | : Front combination lamp RH | E5 | E209 | — | : Generator | J |
| C4 | E111 | GR/3 | : Front combination lamp RH | E4 | E210 | — | : Starter motor | J |
| C4 | E113 | GR/4 | : Cooling fan motor (with VQ40DE) | F4 | E211 | GR/1 | : Starter motor (with QR25DE) | K |
| D4 | E117 | GR/2 | : Front wheel sensor RH | F5 | E212 | GR/2 | : Engine oil temperature sensor | K |
| F3 | E118 | B/2 | : IPDM E/R (intelligent power distribution module engine room) | Trailer tow harness | | | | L |
| E1 | E119 | W/16 | : IPDM E/R (intelligent power distribution module engine room) | D4 | E225 | W/12 | : To E168 | L |
| E1 | E120 | W/6 | : IPDM E/R (intelligent power distribution module engine room) | C3 | E226 | L/4 | : Back-up lamp relay (with M/T) | L |
| E3 | E121 | BR/12 | : IPDM E/R (intelligent power distribution module engine room) | C3 | E227 | L/4 | : Trailer tow relay 1 | L |
| E1 | E122 | W/12 | : IPDM E/R (intelligent power distribution module engine room) | B3 | E228 | BR/6 | : Trailer tow relay 2 | PG |

HARNESS

< WIRING DIAGRAM >

ENGINE ROOM HARNESS (PASSENGER COMPARTMENT)



Refer to "ENGINE ROOM HARNESS (LH VIEW)" for continuation of engine room harness.

ABMIA0398GB

| | | | | | | | |
|----|-----|------|-------------------------------------------|----|------|-----|--------------------------------|
| C4 | E10 | W/6 | : To M6 | C3 | E43 | L/2 | : Clutch pedal position switch |
| D3 | E20 | B/6 | : Accelerator pedal position (APP) sensor | F4 | E152 | SMJ | : To M31 |
| C4 | E26 | W/16 | : To M91 | G2 | E158 | B/1 | : Fuse block (J/B) |
| C4 | E29 | Y/4 | : To M10 | G3 | E159 | B/2 | : Fuse block (J/B) |

HARNESS

< WIRING DIAGRAM >


| | | | | | | | |
|----|-----|------|------------------------------------------|----|------|-----|--------------------------------------------------------------------|
| G3 | E36 | W/2 | : To B102 | G3 | E160 | W/8 | : Fuse block (J/B) |
| C3 | E37 | BR/2 | : Brake pedal position switch (with M/T) | C3 | E163 | L/2 | : Clutch interlock switch (with clutch interlock cancel system) |
| C3 | E38 | B/2 | : Stop lamp switch (with M/T) | C4 | E167 | B/2 | : Diode-3 |
| D3 | E39 | W/4 | : Stop lamp switch (with A/T) | C3 | E169 | L/2 | : Clutch interlock switch (without clutch interlock cancel system) |
| C3 | E42 | BR/2 | : Brake pedal position switch (with A/T) | | | | |

A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

HARNESS

< WIRING DIAGRAM >

ENGINE ROOM HARNESS (LH VIEW)



Refer to "ENGINE ROOM HARNESS (RH VIEW)" for continuation of engine room harness.

ABMIA4392GB

| | | | | | | | |
|----|----|-----|---------------------------------------------------------|----|-----|------|-----------------------------|
| E5 | E4 | Y/2 | : Crash zone sensor | D2 | E21 | GR/2 | : Brake fluid level switch |
| F3 | E6 | B/2 | : Horn | C1 | E23 | GR/5 | : Front wiper motor |
| E4 | E7 | B/3 | : Front combination lamp LH (with daytime light system) | E3 | E27 | GR/3 | : Front combination lamp LH |
| F2 | E9 | — | : Body ground | E5 | E28 | B/2 | : Ambient sensor |

HARNESS

< WIRING DIAGRAM >

| | | | | | | | | |
|----|-----|------|------------------------------------------------------------|----|------|------|-------------------------------------------------|---|
| E3 | E11 | B/3 | : Front combination lamp LH (without daytime light system) | C3 | E34 | W/8 | : To B40 | A |
| D5 | E13 | B/2 | : Ambient sensor 2 | F4 | E101 | B/2 | : Front fog lamp LH | B |
| E2 | E14 | — | : Body ground | E2 | E126 | — | : Body ground | B |
| F2 | E17 | GR/2 | : Front combination lamp LH | D2 | E127 | B/47 | : ABS actuator and electric unit (control unit) | C |
| D3 | E18 | GR/2 | : Front wheel sensor LH | | | | | C |

A

B

C

D

E

F

G

H

I

J

K

L

PG

N


O

P

HARNESS

< WIRING DIAGRAM >

ENGINE CONTROL HARNESS (QR25DE MODELS)



ABMIA4376GB

| | | | | | | | |
|----|----|------|-----------------------------------------------|----|-----|-------|--------------------------------------|
| F4 | F3 | B/1 | : A/C compressor | B4 | F33 | W/16 | : To E19 |
| E3 | F4 | GR/1 | : Oil pressure switch | D5 | F45 | B/6 | : To F210 |
| E3 | F5 | GR/3 | : Ignition coil No. 1 (with power transistor) | C5 | F46 | B/3 | : Power steering pressure sensor |
| E3 | F6 | GR/3 | : Ignition coil No. 2 (with power transistor) | F3 | F50 | W/6 | : Electric throttle control actuator |
| E3 | F7 | GR/3 | : Ignition coil No. 3 (with power transistor) | A4 | F52 | GR/32 | : ECM (with QR25DE) |

HARNES

< WIRING DIAGRAM >

| | | | | | | | | |
|----|-----|------|-------------------------------------------------------------------|----------------------|------|-------|----------------------------------------------|---|
| E2 | F8 | GR/3 | : Ignition coil No. 4 (with power transistor) | E5 | F53 | B/6 | : Mass air flow sensor | A |
| C2 | F9 | G/10 | : A/T assembly | B4 | F56 | BR/48 | : ECM (with QR25DE) | B |
| E4 | F10 | — | : Engine ground | E5 | F61 | GR/2 | : Intake valve timing control solenoid valve | B |
| E3 | F11 | B/3 | : Crankshaft position sensor (POS) | F3 | F65 | BR/4 | : Air fuel ratio (A/F) sensor 1 | C |
| D2 | F13 | G/4 | : Heated oxygen sensor 2 | C1 | F66 | B/2 | : Park/neutral position (PNP) switch | C |
| B4 | F14 | W/24 | : To E5 | B1 | F69 | W/2 | : Back-up lamp switch | D |
| E3 | F15 | GR/2 | : EVAP canister purge volume control solenoid valve (with QR25DE) | Injector sub-harness | | | | D |
| E4 | F16 | — | : Engine ground | D4 | F202 | GR/2 | : Fuel injector No. 1 | D |
| E3 | F18 | B/2 | : Knock sensor | D3 | F203 | GR/2 | : Fuel injector No. 2 | E |
| D3 | F21 | W/2 | : Condenser-1 | D3 | F204 | GR/2 | : Fuel injector No. 3 | E |
| D2 | F23 | B/3 | : Camshaft position sensor (PHASE) | D3 | F205 | GR/2 | : Fuel injector No. 4 | F |
| D2 | F24 | GR/2 | : Engine coolant temperature sensor | D4 | F210 | B/6 | : To F45 | F |
| B4 | F32 | W/16 | : To E2 | | | | | F |

PG

N


O

P

HARNESS

< WIRING DIAGRAM >

ENGINE CONTROL HARNESS (VQ40DE MODELS)



| | | | | | | | |
|----|-----|------|--------------------------------------------------------------------------|----|-----|-------|---------------------------------------|
| E4 | F2 | GR/4 | : Air fuel ratio (A/F) sensor 1 (bank 2) (with VQ40DE except for Mexico) | F2 | F55 | B/2 | : ATP switch |
| C5 | F3 | B/1 | : A/C compressor | B2 | F57 | BR/48 | : ECM (with VQ40DE except for Mexico) |
| E2 | F9 | G/10 | : A/T assembly | G1 | F58 | B/8 | : Transfer control device |
| D4 | F10 | — | : Engine ground | G2 | F59 | GR/2 | : Wait detection switch |

HARNESSES


< WIRING DIAGRAM >

| | | | | | | | | |
|----|-----|------|-------------------------------------------------------------------|---------------------------|------|------|--------------------------------------------------------------------------|----|
| C2 | F11 | B/3 | : Crankshaft position sensor (POS) | F2 | F60 | GR/2 | : 4LO switch | A |
| F3 | F12 | B/4 | : Heated oxygen sensor 2 (bank 2) (with VQ40DE except for Mexico) | D2 | F66 | B/2 | : Park/neutral position (PNP) switch | B |
| B2 | F14 | W/24 | : To E5 | C2 | F67 | L/4 | : To F250 | C |
| D5 | F16 | — | : Engine ground | C2 | F68 | GR/4 | : Air fuel ratio (A/F) sensor 1 (bank 1) (with VQ40DE for Mexico) | D |
| C5 | F17 | GR/2 | : EVAP canister purge volume control solenoid valve (with VQ40DE) | E2 | F69 | W/2 | : Back-up lamp switch | E |
| C4 | F19 | B/2 | : VIAS control solenoid valve | C2 | F70 | G/3 | : Camshaft position sensor (PHASE) (bank 1) | F |
| D4 | F20 | GR/2 | : Fuel injector No. 4 | D2 | F71 | GR/4 | : Air fuel ratio (A/F) sensor 1 (bank 1) (with VQ40DE except for Mexico) | G |
| D3 | F21 | W/2 | : Condenser-1 | B2 | F73 | B/48 | : ECM (with VQ40DE except for Mexico) | H |
| D4 | F22 | GR/2 | : Fuel injector No. 6 | F3 | F74 | G/4 | : Heated oxygen sensor 2 (bank 2) (with VQ40DE for Mexico) | I |
| D2 | F24 | GR/2 | : Engine coolant temperature sensor | F2 | F75 | L/4 | : Heated oxygen sensor 2 (bank 1) (with VQ40DE for Mexico) | J |
| E3 | F25 | B/3 | : Camshaft position sensor (PHASE) (bank 2) | E4 | F76 | GR/4 | : Air fuel ratio (A/F) sensor 1 (bank 2) (with VQ40DE for Mexico) | K |
| C3 | F26 | G/8 | : To F225 | Injector sub-harness | | | | L |
| E2 | F27 | B/4 | : Heated oxygen sensor 2 (bank 1) (with VQ40DE except for Mexico) | D2 | F201 | G/4 | : To F44 | M |
| C4 | F28 | GR/2 | : Fuel injector No. 2 | C4 | F206 | GR/2 | : Fuel injector No. 1 | N |
| D5 | F29 | GR/3 | : Ignition coil No. 2 (with power transistor) | C3 | F207 | GR/2 | : Fuel injector No. 3 | O |
| D4 | F30 | GR/3 | : Ignition coil No. 4 (with power transistor) | C3 | F208 | GR/2 | : Fuel injector No. 5 | P |
| E4 | F31 | GR/3 | : Ignition coil No. 6 (with power transistor) | Ignition coil sub-harness | | | | Q |
| B2 | F32 | W/16 | : To E2 | B3 | F225 | G/8 | : To F26 | R |
| B2 | F33 | W/16 | : To E19 | B3 | F226 | GR/3 | : Ignition coil No. 1 (with power transistor) | S |
| D5 | F41 | B/2 | : Intake manifold runner control valve motor | B3 | F227 | GR/3 | : Ignition coil No. 3 (with power transistor) | T |
| D5 | F42 | B/3 | : Intake manifold runner control valve position sensor | C3 | F228 | GR/3 | : Ignition coil No. 5 (with power transistor) | U |
| D2 | F44 | G/4 | : To F201 | B4 | F229 | GR/2 | : Intake valve timing control solenoid valve (bank 1) | V |
| B4 | F46 | B/3 | : Power steering pressure sensor | Knock sensor sub-harness | | | | W |
| B4 | F50 | W/6 | : Electric throttle control actuator | D4 | F250 | L/4 | : To F67 | X |
| D5 | F51 | GR/2 | : Intake valve timing control solenoid valve (bank 2) | C5 | F251 | GR/2 | : Knock sensor (bank 1) | Y |
| C5 | F53 | B/6 | : Mass air flow sensor | D4 | F252 | GR/2 | : Knock sensor (bank 2) | Z |
| A2 | F54 | B/81 | : ECM (WITH VQ40DE except for Mexico) | | | | | AA |

HARNESS

< WIRING DIAGRAM >

CHASSIS HARNESS



ABMIA4378GB

| | | | | | | | |
|----|-----|------|----------------------------------------|----|------|------|---------------------------------------|
| G2 | C1 | SMJ | : To E41 | A3 | C201 | BR/3 | : Rear combination lamp LH |
| D2 | C5 | GR/5 | : Fuel level sensor unit and fuel pump | C5 | C202 | BR/3 | : Rear combination lamp RH |
| C3 | C6 | B/2 | : EVAP canister vent control valve | A4 | C203 | GR/2 | : License plate lamp LH |
| C3 | C7 | GR/3 | : EVAP control system pressure sensor | B5 | C204 | GR/2 | : License plate lamp RH |
| D4 | C10 | GR/2 | : Rear wheel sensor RH | A4 | C205 | GR/2 | : Rear combination lamp LH (with A/T) |

HARNESS

< WIRING DIAGRAM >


| | | | | | | | | |
|-------------------------------|------|-------|-------------------------------------|------------------------------|------|-------|---------------------------------------|---|
| C3 | C11 | BR/2 | : Rear wheel sensor LH | C5 | C206 | GR/2 | : Rear combination lamp RH (with A/T) | A |
| C3 | C14 | GR/4 | : To C115 | A3 | C207 | GR/2 | : Rear combination lamp LH | B |
| B4 | C15 | GR/8 | : To C200 | C5 | C208 | GR/2 | : Rear combination lamp RH | C |
| A3 | C16 | B/6 | : To C226 | C5 | C209 | GR/2 | : Rear combination lamp RH (with M/T) | D |
| B5 | C17 | GR/10 | : To C212 | A4 | C210 | GR/2 | : Rear combination lamp LH (with M/T) | E |
| B4 | C51 | GR/6 | : To C125 | A3 | C211 | B/6 | : To C225 | F |
| A4 | C52 | B/2 | : To C150 | B5 | C212 | GR/10 | : To C17 | G |
| Differential lock sub-harness | | | | C5 | C213 | B/6 | : To C250 | H |
| C3 | C115 | GR/4 | : To C14 | Rear sonar sub-harness | | | | I |
| D3 | C116 | GR/2 | : Differential lock position switch | A3 | C225 | B/6 | : To C211 | J |
| D4 | C117 | B/2 | : Differential lock solenoid | A3 | C226 | B/6 | : To C16 | K |
| Trailer sub-harness | | | | A3 | C227 | B/3 | : Rear sonar sensor LH outer | L |
| A4 | C125 | GR/8 | : To C51 | A3 | C228 | B/3 | : Rear sonar sensor LH inner | M |
| B5 | C126 | B/7 | : Trailer | A4 | C229 | B/3 | : Rear sonar sensor RH inner | N |
| B5 | C129 | B/7 | : Trailer receptacle | A4 | C230 | B/3 | : Rear sonar sensor RH outer | O |
| A4 | C150 | B/2 | : To C52 | Rear view camera sub-harness | | | | P |
| Tail lamp sub-harness | | | | B5 | C250 | B/6 | : To C213 | |
| A4 | C200 | GR/8 | : To C15 | C5 | C251 | GR/6 | : Rear view camera | |

PG

HARNESS

< WIRING DIAGRAM >

BODY HARNESS (KING CAB MODELS)



| | | | | | | | |
|----|-----|------|--------------------------------------|----|-----|-----|----------------------------------|
| C5 | B7 | — | : Body ground | C4 | B78 | Y/2 | : To B157 |
| C3 | B9 | Y/22 | : Air bag diagnosis sensor unit | C2 | B80 | W/2 | : Vanity lamp LH |
| C4 | B10 | Y/2 | : Front LH side air bag module | B1 | B81 | W/2 | : Vanity lamp RH |
| C4 | B12 | W/4 | : Seat belt buckle switch LH | C1 | B82 | Y/2 | : RH side curtain air bag module |
| D5 | B15 | Y/2 | : LH side air bag (satellite) sensor | C4 | B84 | B/1 | : Parking brake switch |

HARNESS

< WIRING DIAGRAM >

| | | | | | | | |
|----|-----|------|----------------------------------|-----------------------|------|------|-------------------------|
| F3 | B16 | W/8 | : To D216 | C5 | B85 | W/3 | : Front seat heater LH |
| F3 | B19 | — | : Body ground | Front seat LH harness | | | |
| C5 | B37 | W/16 | : To B200 | D5 | B200 | W/16 | : To B37 |
| D2 | B38 | Y/2 | : LH side curtain air bag module | C4 | B204 | GR/2 | : Sliding motor LH |
| B5 | B40 | W/8 | : To E34 | D4 | B205 | W/2 | : Reclining motor LH |
| B4 | B69 | SMJ | : To M40 | C4 | B206 | GR/2 | : Lifting motor (front) |
| D3 | B73 | B/4 | : Yaw rate/side/decel G sensor | D4 | B207 | GR/2 | : Lifting motor (rear) |
| F3 | B76 | W/2 | : Rear door speaker LH | D5 | B208 | W/10 | : Power seat switch LH |

A
B
C
D
E
F
G
H
I
J
K
L


PG

N
O
P

HARNESS

< WIRING DIAGRAM >

BODY HARNESS (CREW CAB MODELS)



ABMIA5565ZZ

| | | | | | | | |
|----|-----|------|---------------------------------|----|-----|-------|----------------------------------|
| E4 | B6 | W/12 | : To D201 | C2 | B80 | W/2 | : Vanity lamp LH |
| C5 | B7 | — | : Body ground | B1 | B81 | W/2 | : Vanity lamp RH |
| E4 | B8 | W/3 | : Front door switch LH | A1 | B82 | Y/2 | : RH side curtain air bag module |
| C3 | B9 | Y/22 | : Air bag diagnosis sensor unit | C2 | B83 | GR/10 | : Sunroof motor assembly |
| C4 | B10 | Y/2 | : Front LH side air bag module | C4 | B84 | B/1 | : Parking brake switch |

HARNESS

< WIRING DIAGRAM >

| | | | | | | | |
|----|-----|------|--------------------------------------|-----------------------|------|------|----------------------------------------------|
| C4 | B12 | W/4 | : Seat belt buckle switch LH | D5 | B85 | W/3 | : Front seat heater LH (without power seats) |
| E4 | B14 | Y/2 | : Front LH seat belt pre-tensioner | Front seat LH harness | | | |
| D5 | B15 | Y/2 | : LH side air bag (satellite) sensor | C5 | B200 | W/16 | : To B37 |
| G3 | B18 | W/3 | : Rear door switch LH | C4 | B204 | GR/2 | : Sliding motor LH |
| F3 | B19 | — | : Body ground | D4 | B205 | W/2 | : Reclining motor LH |
| C5 | B37 | W/16 | : To B200 | C4 | B206 | GR/2 | : Lifting motor (front) |
| D2 | B38 | Y/2 | : LH side curtain air bag module | D4 | B207 | GR/2 | : Lifting motor (rear) |
| B5 | B40 | W/8 | : To E34 | C5 | B208 | W/10 | : Power seat switch LH |
| B5 | B69 | SMJ | : To M40 | C5 | B209 | W/3 | : Front seat heater LH (with power seats) |
| F4 | B72 | GR/4 | : Subwoofer | F3 | B210 | B/1 | : Rear window defogger |
| C4 | B73 | B/4 | : Yaw rate/side/decel G sensor | F4 | B211 | — | : Body ground |
| B4 | B78 | Y/2 | : To B157 | | | | |

A
B
C
D
E
F
G
H
I
J
K
L


PG

N
O
P

HARNESS

< WIRING DIAGRAM >

BODY NO. 2 HARNESS (KING CAB MODELS)




| | | | | | | | |
|----|------|------|--------------------------------------|----|------|------|-----------------------------------|
| F4 | B102 | W/2 | : To E36 | F5 | B149 | SMJ | : To M36 |
| B3 | B107 | W/8 | : To D302 | E3 | B157 | Y/2 | : To B78 |
| D4 | B110 | W/4 | : Seat belt buckle switch RH | B3 | B160 | W/2 | : Rear door speaker RH |
| D3 | B113 | Y/22 | : Air bag diagnosis sensor unit | B1 | B161 | W/3 | : High-mounted stop lamp assembly |
| C5 | B114 | Y/2 | : RH side air bag (satellite) sensor | F5 | B163 | W/16 | : To M17 |

HARNESS

< WIRING DIAGRAM >

| | | | | | | | |
|----|------|------|--------------------------------|-----------------------|------|------|-----------------------------------------------|
| E4 | B117 | — | : Body ground | D4 | B166 | W/3 | : Front seat heater RH |
| D4 | B126 | Y/2 | : Front RH side air bag module | Front seat RH harness | | | |
| B3 | B132 | — | : Body ground | E4 | B351 | W8 | : To B136 |
| E4 | B136 | W/8 | : To B351 | D4 | B352 | B/18 | : Occupant classification system control unit |
| D5 | B141 | W/32 | : Bluetooth® control unit | C4 | B353 | B/3 | : Occupant classification system sensor |
| D5 | B143 | W/8 | : Bluetooth® control unit | | | | |

BODY NO. 2 HARNESS (CREW CAB MODELS)



ABMIA5567ZZ

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

PG

HARNES


< WIRING DIAGRAM >

| | | | | | | | |
|----|------|------|--------------------------------------|-----------------------|------|------|-----------------------------------------------|
| F5 | B102 | W/2 | : To E36 | D4 | B158 | W/8 | : Audio amplifier |
| C4 | B106 | W/12 | : To D301 | E4 | B159 | W/24 | : Audio amplifier |
| C4 | B108 | W/3 | : Front door switch RH | B1 | B161 | W/3 | : High-mounted stop lamp assembly |
| D4 | B110 | W/4 | : Seat belt buckle switch RH | F5 | B163 | W/16 | : To M17 |
| E4 | B113 | Y/22 | : Air bag diagnosis sensor unit | A2 | B165 | B/1 | : Rear window defogger |
| D5 | B114 | Y/2 | : RH side air bag (satellite) sensor | E5 | B166 | W/3 | : Front seat heater RH (without power seats) |
| B3 | B116 | W/3 | : Rear door switch RH | Front seat RH harness | | | |
| E5 | B117 | — | : Body ground | D4 | B302 | W/2 | : Reclining motor RH |
| E4 | B126 | Y/2 | : Front RH side air bag module | E5 | B303 | W/16 | : To B154 |
| C4 | B127 | Y/2 | : Front RH seat belt pretensioner | D4 | B307 | W/3 | : Front seat heater RH (with power seats) |
| B3 | B132 | — | : Body ground | D4 | B308 | W/6 | : Power seat switch RH |
| E4 | B136 | W/8 | : To B351 | D4 | B309 | GR/2 | : Sliding motor RH |
| C5 | B137 | B/3 | : Belt tension sensor | D4 | B310 | W/8 | : To B349 |
| D5 | B141 | W/32 | : Bluetooth® control unit | D4 | B349 | W/8 | : To B310 |
| D5 | B143 | W/8 | : Bluetooth® control unit | E4 | B351 | W/8 | : To B136 |
| F5 | B149 | SMJ | : To M36 | E4 | B352 | B/18 | : Occupant classification system control unit |
| E5 | B154 | W/16 | : To B303 | D4 | B353 | B/3 | : Occupant classification system sensor |
| F4 | B157 | Y/2 | : To B78 | | | | |

HARNESS

< WIRING DIAGRAM >

ROOM LAMP HARNESS



A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P


| | | | | | | | |
|----|----|------|-----------------------------------------------------------------------------|----|------|-----|--------------------------------------------------|
| C5 | R1 | W/24 | : To M1 | B3 | R9† | W/3 | : Front room/map lamp assembly (with sunroof) |
| B3 | R4 | W/3 | : Sunroof switch | B2 | R9†† | W/3 | : Front room/map lamp assembly (without sunroof) |
| B3 | R6 | W/7 | : Auto anti-dazzling inside mirror (without homelink universal transceiver) | D1 | R10† | W/2 | : Room lamp 2nd row (king cab) |

HARNESS

< WIRING DIAGRAM >

| | | | | | | | |
|----|----|------|--------------------------------------------------------------------------|----|-------|-----|--------------------------------|
| B3 | R7 | B/10 | : Auto anti-dazzling inside mirror (with homelink universal transceiver) | E1 | R10†† | W/2 | : Room lamp 2nd row (crew cab) |
| C3 | R8 | W/4 | : Microphone | | | | |

FRONT DOOR LH HARNESS




ABMIA6569ZZ

| | | | | | |
|----|-------|------------------------------------------|-----|------|-------------------------------------------------|
| D1 | W/12 | : To M9 | D7 | W/16 | : Main power window and door lock/unlock switch |
| D2 | BR/12 | : To M8 | D9 | BR/2 | : Front power window motor LH |
| D4 | B/10 | : Door mirror LH (with heated mirror) | D10 | Y/2 | : Front door satellite sensor LH |
| D5 | Y/4 | : To M25 | D12 | W/2 | : Front door speaker LH |
| D6 | B/3 | : Door mirror LH (without heated mirror) | D14 | GR/6 | : Front door lock assembly LH |

HARNESS

< WIRING DIAGRAM >

FRONT DOOR RH HARNESS




ABMIA6570ZZ

| | | | | | |
|------|------|-----------------------------------------------|---------------------------|------|-------------------------------|
| D101 | W/10 | : To D152 | D114 | GR/2 | : Front door lock actuator RH |
| D102 | W/12 | : To D150 | Front door RH sub-harness | | |
| D103 | Y/4 | : To D155 | D150 | W/12 | : To D102 |
| D104 | BR/2 | : Front power window motor RH | D151 | W/12 | : To M74 |
| D105 | W/12 | : Power window and door lock/unlock switch RH | D152 | W/10 | : To D101 |
| D106 | B/3 | : Door mirror RH (without heated mirror) | D153 | W/10 | : To M75 |
| D107 | B/10 | : Door mirror RH (with heated mirror) | D154 | Y/4 | : To M23 |
| D109 | Y/2 | : Front door satellite sensor RH | D155 | Y/4 | : To D103 |
| D112 | W/2 | : Front door speaker RH | | | |

HARNESS

< WIRING DIAGRAM >

REAR DOOR LH HARNESS (KING CAB MODELS)




ABMIA0453GB

| | | | | | |
|------|-----|------------------------------------|------|-----|------------------------|
| D210 | Y/2 | : Front LH seat belt pre-tensioner | D213 | W/3 | : Front door switch LH |
| D211 | B/2 | : Rear door switch upper LH | D216 | W/8 | : To B16 |
| D212 | B/2 | : Rear door switch lower LH | | | |

HARNESS

< WIRING DIAGRAM >

REAR DOOR RH HARNESS (KING CAB MODELS)



ABMIA0409GB


| | | | | | |
|------|-----|------------------------------------|------|-----|-----------------------------|
| D302 | W/8 | : To B107 | D312 | B/2 | : Rear door switch upper RH |
| D310 | Y/2 | : Front RH seat belt pre-tensioner | D313 | B/2 | : Rear door switch lower RH |
| D311 | B/3 | : Belt tension sensor | D314 | W/3 | : Front door switch RH |

A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

HARNESS

< WIRING DIAGRAM >

REAR DOOR LH HARNESS (CREW CAB MODELS)




ABMIA2588GB

| | | | | | |
|------|------|-------------------------------|------|------|------------------------------|
| D201 | W/12 | : To B6 | D205 | GR/2 | : Rear door lock actuator LH |
| D203 | W/8 | : Rear power window switch LH | D207 | W/2 | : Rear door speaker LH |
| D204 | B/2 | : Rear power window motor LH | D208 | BR/2 | : Rear tweeter LH |

HARNESSES

< WIRING DIAGRAM >

REAR DOOR RH HARNESSES (CREW CAB MODELS)



ABMIA2589GB

| | | | | | |
|------|------|-------------------------------|------|------|------------------------------|
| D301 | W/12 | : To B106 | D305 | GR/2 | : Rear door lock actuator RH |
| D303 | W/8 | : Rear power window switch RH | D307 | W/2 | : Rear door speaker RH |
| D304 | B/2 | : Rear power window motor RH | D308 | BR/2 | : Rear door tweeter RH |

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

PG


FUSE BLOCK - JUNCTION BOX (J/B)

< WIRING DIAGRAM >

FUSE BLOCK - JUNCTION BOX (J/B)

Terminal Arrangement

INFOID:000000012563576



ABMIA6560GB

FUSE, FUSIBLE LINK AND RELAY BOX


< WIRING DIAGRAM >

FUSE, FUSIBLE LINK AND RELAY BOX


Terminal Arrangement

INFOID:000000012563577

FUSE AND FUSIBLE LINK BOX



FUSIBLE LINK BOX (BATTERY)



ABMIA1482GB

A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P


FUSE AND RELAY BOX

< WIRING DIAGRAM >

FUSE AND RELAY BOX

Terminal Arrangement

INFOID:000000012563578



ABMIA6561GB


IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< WIRING DIAGRAM >

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

IPDM E/R Terminal Arrangement

INFOID:000000012563579



NOTE:

Numbers preceded by an "F" represent the fuse numbers imprinted on the IPDM E/R. The other numbers represent the fuse numbers as they appear in the wiring diagrams.

ABMIA6562GB

BATTERY

< BASIC INSPECTION >

BASIC INSPECTION

BATTERY

How to Handle Battery

INFOID:000000012563580


CAUTION:

- If it becomes necessary to start the engine with a booster battery and jumper cables, use a 12-volt booster battery.
- After connecting battery cables, ensure that they are tightly clamped to battery terminals for good contact.
- Never add distilled water through the hole used to check specific gravity.


METHODS OF PREVENTING OVER-DISCHARGE

The following precautions must be taken to prevent over-discharging a battery.

- The battery surface (particularly its top) should always be kept clean and dry.
- The terminal connections should be clean and tight.
- At every routine maintenance, check the electrolyte level.
This also applies to batteries designated as "low maintenance" and "maintenance-free".



- When the vehicle is not going to be used over a long period of time, disconnect the battery cable from the negative terminal. (If the vehicle has an extended storage switch, turn it off.)



Work Flow

INFOID:000000012563581

BATTERY DIAGNOSIS WITH EXP-800 NI OR GR8-1200 NI

To diagnose and confirm the condition of the battery, use the following special service tools:

- EXP-800 NI Battery and electrical diagnostic analyzer
- GR8-1200 NI Multitasking battery and electrical diagnostic station

NOTE:

Refer to the applicable Instruction Manual for proper battery diagnosis procedures.

BATTERY DIAGNOSIS WITHOUT EXP-800 NI OR GR8-1200 NI

Checking Electrolyte Level


WARNING:

Never allow battery fluid to come in contact with skin, eyes, fabrics, or painted surfaces. After touching a battery, never touch or rub your eyes until you have thoroughly washed your hands. If acid contacts eyes, skin or clothing, immediately flush with water for 15 minutes and seek medical attention. Failure to do this may cause personal injury or damage to clothing or the painted surfaces.

BATTERY


< BASIC INSPECTION >

- Remove the cell plug using a suitable tool.
- Add distilled water up to the MAX level.



SULFATION

- **A battery will be completely discharged if it is left unattended for a long time and the specific gravity will become less than 1.100. This may result in sulfation on the cell plates.**
- **To determine if a battery has been “sulfated”, note its voltage and current when charging it. As shown in the figure, less current and higher voltage are observed in the initial stage of charging sulfated batteries.**
- **A sulfated battery may sometimes be brought back into service by means of a long, slow charge, 12 hours or more, followed by a battery capacity test.**




Specific Gravity Check

NOTE:

Check the charge condition of the battery.

Periodically check the specific gravity of the electrolyte. Keep a close check on charge condition to prevent over-discharge.

1. Read hydrometer and thermometer indications at eye level.
2. Use the chart below to correct your hydrometer reading according to electrolyte temperature.



Hydrometer Temperature Correction

| Battery electrolyte temperature [°C (°F)] | Add to specific gravity reading |
|-------------------------------------------|---------------------------------|
| 71 (160) | 0.032 |
| 66 (150) | 0.028 |
| 60 (140) | 0.024 |
| 54 (130) | 0.020 |
| 49 (120) | 0.016 |
| 43 (110) | 0.012 |
| 38 (100) | 0.008 |
| 32 (90) | 0.004 |
| 27 (80) | 0 |
| 21 (70) | -0.004 |
| 16 (60) | -0.008 |
| 10 (50) | -0.012 |

A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

BATTERY

< BASIC INSPECTION >

| Battery electrolyte temperature [°C (°F)] | Add to specific gravity reading |
|-------------------------------------------|---------------------------------|
| 4 (40) | -0.016 |
| -1 (30) | -0.020 |
| -7 (20) | -0.024 |
| -12 (10) | -0.028 |
| -18 (0) | -0.032 |

| Corrected specific gravity | Approximate charge condition |
|----------------------------|------------------------------|
| 1.260 - 1.280 | Fully charged |
| 1.230 - 1.250 | 3/4 charged |
| 1.200 - 1.220 | 1/2 charged |
| 1.170 - 1.190 | 1/4 charged |
| 1.140 - 1.160 | Almost discharged |
| 1.110 - 1.130 | Completely discharged |

Charging The Battery

CAUTION:

- **Never “quick charge” a fully discharged battery.**
- **Keep the battery away from open flame while it is being charged.**
- **When connecting the charger, connect the leads first, then turn on the charger. Never turn on the charger first, as this may cause a spark.**
- **If battery electrolyte temperature rises above 55 °C (131 °F), stop charging. Always charge battery at a temperature below 55 °C (131 °F).**

Charging Rates (Standard Charge)

| Approximate charge condition | Charge current (A) | Charge time (h) |
|------------------------------|--------------------|-----------------|
| Fully charged | 7 | 2 |
| 3/4 charged | | 2.5 |
| 1/2 charged | | 5 |
| 1/4 charged | | 7.5 |
| Almost discharged | | 9 |
| Completely discharged | | 10 |

Charging Rates (Quick Charge)

| Approximate charge condition | Charge current (A) | Charge time (h) |
|------------------------------|--------------------|-----------------|
| Fully charged | — | — |
| 3/4 charged | 16 | 0.5 |
| 1/2 charged | 33 | |
| 1/4 charged | | |
| Almost discharged | — | — |
| Completely discharged | — | |

NOTE:

The ammeter reading on your battery charger will automatically decrease as the battery charges. This indicates that the voltage of the battery is increasing normally as the state of charge improves. The charging amps indicated above refer to initial charge rate.

- If, after charging, the specific gravity of any two cells varies more than 0.050, the battery should be replaced.

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

INSPECTION AND ADJUSTMENT

ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL

ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement

INFOID:0000000012563582

Required Procedure After Battery Disconnection

| System | Item | Reference |
|-----------------------------------|-------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------|
| Engine Control System | Idle Air Volume Learning | EC-126 (QR25DE) EC-604 (VQ40DE FOR USA AND CANADA) EC-1098 (VQ40DE FOR MEXICO) |
| Roof | Sunroof Memory Reset/Initialization | RF-5 |
| Audio, Visual & Navigation System | Audio (Radio Preset) | Refer to Owner's Manual. |
| | Navigation System | Refer to Owner's Manual. |

A
B
C
D
E
F
G
H
I
J
K
L

PG

N
O
P

FUSE INSPECTION


< BASIC INSPECTION >

FUSE INSPECTION

How To Check

INFOID:000000012563583

- If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.
- Use fuse of specified rating. Never use fuse of more than specified rating.
- Do not partially install fuse; always insert it into fuse holder properly.
- Remove fuse for "ELECTRICAL PARTS (BAT)" if vehicle is not used for a long period of time.




EXTENDED STORAGE SWITCH (IF EQUIPPED)

NOTE:

- When extended storage switch is pulled out, a message may be shown in the meter or display. To turn message/display off, push extended storage switch in.
- The following information is related to extended storage switch (shipping mode). For information related to BCM transit mode, refer to [BCS-8, "System Description"](#).

The following switch may be mounted on the fuse block (Junction Box) for transportation and storage.



① Extended storage switch

(A) Type A

(B) Type B

(C) Type C

Remove the extended storage switch if it interferes when checking fuses.


How/When to turn Extended Storage Switch ON/OFF

CAUTION:


FUSE INSPECTION

< BASIC INSPECTION >


- Turn the ignition switch OFF when operating the extended storage switch.
- Under normal conditions, keep the extended storage switch in ON state. Never operate the extended storage switch except when necessary.
- Type A



- To turn the extended storage switch OFF, pull out in ① direction as shown in the figure.
- To turn the extended storage switch ON, press in ② direction as shown in the figure.
- Type B



- To turn the extended storage switch OFF, pinch tabs ① of the switch and pull out in ② direction as shown in the figure.
- To turn the extended storage switch ON, press in ③ direction as shown in the figure.
- Type C



- To turn the extended storage switch OFF, pull out in ① direction as shown in the figure.
- To turn the extended storage switch ON, press in ② direction as shown in the figure.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

PG


FUSE INSPECTION

< BASIC INSPECTION >

How To Remove Extended Storage Switch

Type A

1. Turn the ignition switch OFF.
2. Turn the extended storage switch OFF.
3. Pinch tabs (A) and tilt to disengage the extended storage switch.
Pinch tabs (B) to remove the extended storage switch.



CAUTION:


For bus bar type extended storage switch, never replace bus bar with a fuse, or fuse may continually open.

NOTE:

- Extended storage switch and fuse (or bus bar) are removed together. Remove fuse (or bus bar) from extended storage switch, if necessary.
- Install removed fuse (or bus bar) to fuse block.
- Extended storage switch is for transportation and storage. Reinstallation of switch is not required after removal, but fuse (or bus bar) must be reinstalled/pushed back in to activate all electrical systems and turn message off (which may be shown in meter/display).

Type B

1. Turn the ignition switch OFF.
2. Turn the extended storage switch OFF.
3. Pinch tabs (A) and firmly pull out the extended storage switch in (B) direction.



CAUTION:

For bus bar type extended storage switch, never replace bus bar with a fuse, or fuse may continually open.

NOTE:

- Extended storage switch and fuse (or bus bar) may be removed together. Remove fuse (or bus bar) from extended storage switch, if necessary.
- Install removed fuse (or bus bar) to fuse block.
- Extended storage switch is for transportation and storage. Reinstallation of switch is not required after removal, but fuse (or bus bar) must be reinstalled/pushed back in to activate all electrical systems and turn message off (which may be shown in meter/display).


Type C

1. Turn the ignition switch OFF.
2. Turn the extended storage switch OFF.

FUSE INSPECTION

< BASIC INSPECTION >

3. Pinch tabs (A) and firmly pull out the extended storage switch in (B) direction.



CAUTION:

For bus bar type extended storage switch, never replace bus bar with a fuse, or fuse may continually open.

NOTE:

- Extended storage switch and fuse (or bus bar) are removed together. Remove fuse (or bus bar) from extended storage switch, if necessary.
- Install removed fuse (or bus bar) to fuse block.
- Extended storage switch is for transportation and storage. Reinstallation of switch is not required after removal, but fuse (or bus bar) must be reinstalled/pushed back in to activate all electrical systems and turn message off (which may be shown in meter/display).

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

PG

FUSIBLE LINK INSPECTION

< BASIC INSPECTION >

FUSIBLE LINK INSPECTION

Fusible Link

INFOID:000000012563584


A melted fusible link can be detected either by visual inspection or by feeling with finger tip. If its condition is questionable, use circuit tester or test lamp.

1 : Fusible link

←: Vehicle front

CAUTION:

- If fusible link should melt, it is possible that critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check and eliminate cause of malfunction.
- Never wrap outside of fusible link with vinyl tape. Important: Never let fusible link touch any other wiring harness, vinyl or rubber parts.



AAMIA0515GB

BATTERY

< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION


BATTERY

Removal and Installation

INFOID:0000000012563585

REMOVAL

1. Disconnect both negative and positive battery terminals.
CAUTION:
 - **Before servicing, turn the ignition switch off and wait at least three minutes.**
 - **Disconnect negative battery terminal first.**
2. Remove battery clamp nuts and battery clamp.
3. Remove battery cover.
4. Remove battery.



INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

Connect positive battery terminal first.

Battery clamp nuts : 3.92 N·m (0.40 kg-m, 35 in-lb)

Battery terminal nut : 3.4 N·m (0.35 kg-m, 30 in-lb)

Reset electronic systems as necessary. Refer to [PG-83. "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement"](#).

A
B
C
D
E
F
G
H
I
J
K
L

PG


BATTERY TERMINAL WITH FUSIBLE LINK

< REMOVAL AND INSTALLATION >

BATTERY TERMINAL WITH FUSIBLE LINK

Exploded View

INFOID:000000012563586



- | | | |
|-------------------------------|----------------------|------------|
| 1. Fusible link box (battery) | 2. Positive Terminal | 3. Battery |
| 4. Harness connectors | 5. Positive cable | 6. Cover |
- ⇐ Front

Removal and Installation

INFOID:000000012563587

REMOVAL

1. Disconnect negative terminal from the battery and reposition.
CAUTION:
To prevent damage to the parts, disconnect the negative terminal from the battery negative post first.
2. Disconnect positive terminal from the battery.
3. Disconnect positive cable from fusible link box (battery).
4. Disconnect harness connectors and separate positive terminal from fusible link box (battery).

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

Replace the fusible link box (battery) if it has been dropped or sustained and impact.

To install the fusible link box (battery), carefully read the following instructions:

- **To prevent damage to the parts, connect the positive terminal to the battery positive post first.**
- **After connecting the positive terminal, to securely supply battery voltage, ensure that the positive and negative terminals are tightly clamped to battery posts for good contact.**
- **To securely supply battery voltage, check the positive and negative terminals for poor connection caused by corrosion.**

Reset electronic systems as necessary. Refer to [PG-83. "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement"](#).

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

Battery

INFOID:0000000012563588

| | |
|-----------------------------------------------------------------|-------|
| Type* | GR35 |
| Capacity (20 HR) minimum V-AH | 12-60 |
| Cold cranking current A [For reference value at -18°C (0°F)] | 550 |

*: Always check with the Parts Department for the latest parts information.

A

B

C

D

E

F

G

H

I

J

K

L

PG

N

O

P