

# ELECTRICAL SYSTEM

## SECTION **EL**

**When you read wiring diagrams:**

- Read GI section, "HOW TO READ WIRING DIAGRAMS".

**When you perform trouble diagnoses, read GI section, "HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES" and "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT".**

## CONTENTS

<b>PRECAUTION</b> .....	3	<b>HEADLAMP — Daytime Light System —</b> .....	34
Supplemental Restraint System "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	3	System Description .....	34
<b>HARNES CONNECTOR</b> .....	4	Operation.....	35
Description .....	4	Schematic.....	35
<b>STANDARDIZED RELAY</b> .....	5	Wiring Diagram — DTRL — .....	36
Description .....	5	<b>HEADLAMP</b> .....	39
<b>POWER SUPPLY ROUTING</b> .....	8	Trouble Diagnoses (For USA) .....	39
Schematic.....	8	Trouble Diagnoses (For Canada).....	40
Wiring Diagram — POWER — .....	10	Bulb Replacement.....	41
Fuse.....	15	Aiming Adjustment.....	42
Fusible Link.....	15	<b>EXTERIOR LAMP</b> .....	44
<b>BATTERY</b> .....	16	Clearance, License, Tail and Stop Lamps/Wiring Diagram — TAIL/L — .....	44
How to Handle Battery.....	16	Clearance, License, Tail and Stop Lamps/ Schematic.....	47
Service Data and Specifications (SDS).....	19	Back-up Lamp/Wiring Diagram — BACK/L — .....	48
<b>STARTING SYSTEM</b> .....	20	Front Fog Lamp/System Description .....	49
System Description .....	20	Front Fog Lamp/Wiring Diagram — F/FOG — .....	50
Wiring Diagram — START — .....	22	Turn Signal and Hazard Warning Lamps/System Description.....	51
Construction .....	24	Turn Signal and Hazard Warning Lamps/ Wiring Diagram — TURN — .....	53
Removal and Installation.....	25	Turn Signal and Hazard Warning Lamps/ Schematic.....	56
Pinion/Clutch Check.....	25	Turn Signal and Hazard Warning Lamps/Trouble Diagnoses.....	57
Service Data and Specifications (SDS).....	25	Combination Flasher Unit Check .....	57
<b>CHARGING SYSTEM</b> .....	26	Bulb Specifications .....	58
System Description.....	26	<b>INTERIOR LAMP</b> .....	59
Construction .....	26	Illumination/System Description .....	59
Wiring Diagram — CHARGE — .....	27	Illumination/Wiring Diagram — ILL — .....	60
Trouble Diagnoses.....	28	Illumination/Schematic.....	63
Service Data and Specifications (SDS).....	29	Interior, Spot and Trunk Room Lamps/System Description .....	64
<b>COMBINATION SWITCH</b> .....	30		
Combination Switch/Check.....	30		
Replacement .....	31		
<b>HEADLAMP — Without Daytime Light System —</b> .....	32		
System Description.....	32		
Wiring Diagram — H/LAMP — .....	33		

# CONTENTS (Cont'd.)

<p>Interior, Spot and Trunk Room Lamps/Wiring Diagram — INT/L — .....66</p> <p><b>METER AND GAUGES</b> .....67</p> <p>System Description .....67</p> <p>Combination Meter .....68</p> <p>Speedometer, Tachometer, Temp., Oil and Fuel Gauges/Wiring Diagram — METER — .....69</p> <p>Inspection/Fuel Gauge, Water Temperature Gauge and Oil Pressure Gauge .....71</p> <p>Fuel Tank Gauge Unit Check .....72</p> <p>Fuel Warning Lamp Sensor Check .....72</p> <p>Thermal Transmitter Check .....72</p> <p>Oil Pressure Switch Check .....73</p> <p>Vehicle Speed Sensor Signal Check .....73</p> <p><b>WARNING LAMPS AND CHIME</b> .....74</p> <p>Warning Lamps/Schematic .....74</p> <p>Warning Lamps/Wiring Diagram — WARN — .....75</p> <p>Warning Chime/System Description .....77</p> <p>Warning Chime/Wiring Diagram — CHIME — .....78</p> <p>Diode Check .....79</p> <p>Warning Chime Check .....79</p> <p><b>TIME CONTROL SYSTEM</b> .....80</p> <p>System Description .....80</p> <p>Wiring Diagram — TIME — .....81</p> <p>Trouble Diagnoses .....86</p> <p><b>WIPER AND WASHER</b> .....97</p> <p>Front Wiper and Washer/System Description .....97</p> <p>Front Wiper and Washer/Wiring Diagram — WIPER — .....99</p> <p>Installation .....100</p> <p>Washer Nozzle Adjustment .....101</p> <p>Check Valve .....101</p> <p>Washer Tube Layout .....101</p> <p><b>HORN, CIGARETTE LIGHTER AND CLOCK</b> .....102</p> <p>Wiring Diagram — HORN — .....102</p> <p><b>REAR WINDOW DEFOGGER</b> .....103</p> <p>System Description .....103</p> <p>Wiring Diagram — DEF — .....104</p> <p>Filament Check .....105</p> <p>Filament Repair .....106</p> <p><b>AUDIO AND POWER ANTENNA</b> .....107</p>	<p>Audio/System Description .....107</p> <p>Audio/Wiring Diagram — AUDIO — .....108</p> <p>Power Antenna/System Description .....110</p> <p>Power Antenna/Wiring Diagram — P/ANT — .....111</p> <p>Trouble Diagnoses .....112</p> <p>Location of Antenna .....113</p> <p>Antenna Rod Replacement .....114</p> <p>Window Antenna Repair .....115</p> <p><b>AUTOMATIC SPEED CONTROL DEVICE (ASCD)</b> .....116</p> <p>System Description .....116</p> <p>Component Parts and Harness Connector Location .....118</p> <p>Wiring Diagram — ASCD — .....119</p> <p>Trouble Diagnoses .....124</p> <p><b>THEFT WARNING SYSTEM</b> .....138</p> <p>System Description .....138</p> <p>Component Parts and Harness Connector Location .....141</p> <p>Wiring Diagram — THEFT — .....142</p> <p>Trouble Diagnoses .....149</p> <p><b>LOCATION OF ELECTRICAL UNITS</b> .....167</p> <p>Engine Compartment .....167</p> <p>Passenger Compartment .....168</p> <p>Luggage Compartment .....169</p> <p><b>HARNES LAYOUT</b> .....171</p> <p>Outline .....171</p> <p>Engine Room Harness .....172</p> <p>Room Lamp Harness .....175</p> <p>Main Harness .....176</p> <p>Main Harness, Tail Harness and Tail Harness No.2 .....179</p> <p>Engine Control Harness and Alternator Harness .....180</p> <p>Engine Harness .....181</p> <p>Door Harness (LH side) .....182</p> <p>Door Harness (RH side) .....183</p> <p><b>SUPER MULTIPLE JUNCTION (SMJ)</b> ..... Foldout page</p> <p>Terminal Arrangement ..... Foldout page</p> <p><b>JOINT CONNECTOR</b> ..... Foldout page</p> <p>Terminal Arrangement ..... Foldout page</p>
--	--

## WIRING DIAGRAM REFERENCE CHART

ECCS (Ignition system) .....	FOLDOUT PAGE
AUTOMATIC TRANSAXLE CONTROL SYSTEM, SHIFT LOCK SYSTEM .....	AT SECTION
ANTI-LOCK BRAKING SYSTEM .....	BR SECTION
FUEL FILLER LID OPENER, TRUNK LID OPENER, POWER WINDOW AND POWER DOOR LOCK, SUPPLEMENTAL RESTRAINT SYSTEM, MULTI-REMOTE CONTROL SYSTEM, POWER SEAT, SUN ROOF, DOOR MIRROR .....	BF SECTION
HEATER AND AIR CONDITIONER .....	HA SECTION

## PRECAUTION

### Supplemental Restraint System “AIR BAG” and “SEAT BELT PRE-TENSIONER”

The Supplemental Restraint System “Air Bag” and “Seat Belt Pre-tensioner” help to reduce the risk or severity of injury to the driver and front passenger in a frontal collision. The Supplemental Restraint System consists of air bags (located in the center of the steering wheel and on the instrument panel on the passenger side), seat belt pre-tensioners, sensors, a diagnosis unit, warning lamp, wiring harness and spiral cable. Information necessary to service the system safely is included in the **BF** section of this Service Manual.

#### WARNING:

- To avoid rendering the SRS inoperative, which could lead to personal injury or death in the event of a severe frontal collision, all maintenance must be performed by an authorized INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- All SRS air bag electrical wiring harnesses and connectors are covered with yellow outer insulation. Do not use electrical test equipment on any circuit related to the SRS SYSTEM.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

IDX

# HARNESS CONNECTOR

## Description


### HARNESS CONNECTOR

- All harness connectors have been modified to prevent accidental looseness or disconnection.
- The connector can be disconnected by pushing or lifting the locking section.

#### CAUTION:

Do not pull the harness when disconnecting the connector.

[Example]




# STANDARDIZED RELAY

## Description

### NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS


Relays can mainly be divided into three types: normal open, normal closed and mixed type relays.



SEL881H

### TYPE OF STANDARDIZED RELAYS
















- 1M ..... 1 Make      2M ..... 2 Make
- 1T ..... 1 Transfer      1M-1B ..... 1 Make 1 Break



SEL882H




# STANDARDIZED RELAY

## Description (Cont'd)

Type	Outer view	Circuit	Connector symbol and connection	Case color
1T				BLACK
1M				BLUE or GREEN
2M				BROWN
1M-1B				GRAY
1M				BLUE

# STANDARDIZED RELAY

## Description (Cont'd)

Type	Outer view	Circuit	Connector symbol and connection	Case color
1T				BLACK

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA


EL

EL

IDX

# POWER SUPPLY ROUTING


## Schematic





# POWER SUPPLY ROUTING

## Schematic (Cont'd)





GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
**EL**  
IDX

MEL173D

# POWER SUPPLY ROUTING

## Wiring Diagram — POWER —


EL-POWER-01



# POWER SUPPLY ROUTING

## Wiring Diagram — POWER — (Cont'd)

EL-POWER-02



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF



HA

EL

IDX

Refer to last page (Foldout page).



(M5), (E102)



# POWER SUPPLY ROUTING

## Wiring Diagram — POWER — (Cont'd)

EL-POWER-03




Refer to last page (Foldout page).

M5, E102

# POWER SUPPLY ROUTING

## Wiring Diagram — POWER — (Cont'd)


EL-POWER-04



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA

EL



IDX




# POWER SUPPLY ROUTING

## Wiring Diagram — POWER — (Cont'd)

EL-POWER-05




# POWER SUPPLY ROUTING



## Fuse

- If fuse is blown, be sure to eliminate cause of problem before installing new fuse.
- Use fuse of specified rating. Never use fuse of more than specified rating.
- Do not partially install fuse; always insert it into fuse holder properly.
- Remove fuse for clock if vehicle is not used for a long period of time.

GI  
MA  
EM



## Fusible Link

A melted fusible link can be detected by visual inspection. If its condition is questionable, use circuit tester or test lamp.

### CAUTION:

- If fusible link should melt, it is possible that critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check and eliminate cause of problem.
- Never wrap outside of fusible link with vinyl tape. Important: Never let fusible link touch any other wiring harness, vinyl or rubber parts.

LC  
EC  
FE  
CL

MT

AT

FA

RA

BR

ST

BF

HA




EL

IDX

# BATTERY

## CAUTION:

- If it becomes necessary to start the engine with a booster battery and jumper cables, use a 12-volt booster battery.
- After connecting battery cables, ensure that they are tightly clamped to battery terminals for good contact.
- Never add distilled water through the hole used to check specific gravity.



## How to Handle Battery

### METHODS OF PREVENTING OVER-DISCHARGE

The following precautions must be taken to prevent over-discharging a battery.

- The battery surface (particularly its top) should always be kept clean and dry.
  - The terminal connections should be clean and tight.
  - At every routine maintenance, check the electrolyte level.
- 
- When the vehicle is not going to be used over a long period of time, disconnect the negative battery terminal. (If the vehicle has an extended storage switch, turn it off.)

- Check the charge condition of the battery. Periodically check the specific gravity of the electrolyte. Keep a close check on charge condition to prevent over-discharge.



# BATTERY

## How to Handle Battery (Cont'd)

### CHECKING ELECTROLYTE LEVEL

#### WARNING:

Do not allow battery fluid to come in contact with skin, eyes, fabrics, or painted surfaces. After touching a battery, do not touch or rub your eyes until you have thoroughly washed your hands. If the acid contacts the eyes, skin or clothing, immediately flush with water for 15 minutes and seek medical attention.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR


ST

BF


HA

EL

IDX



- Remove the cell plug using a suitable tool.
- Add distilled water up to the MAX level.




### SULPHATION

A battery will be completely discharged if it is left unattended for a long time and the specific gravity becomes less than 1.100. This may result in sulphation on the cell plates.

To find if a discharged battery has been sulphated, pay attention to its voltage and current when charging it.

As shown in the figure at left, if the battery has been "sulphated", less current and higher voltage may be observed in the initial stage of charging.



### SPECIFIC GRAVITY CHECK

Read hydrometer and thermometer indications at eye level.

## BATTERY

### How to Handle Battery (Cont'd)

- Use the chart below to correct your hydrometer reading according to electrolyte temperature.

#### Hydrometer temperature correction

Battery electrolyte temperature °C (°F)	Add to specific gravity reading
71 (160)	0.032
66 (150)	0.028
60 (140)	0.024
54 (129)	0.020
49 (120)	0.016
43 (110)	0.012
38 (100)	0.008
32 (90)	0.004
27 (80)	0
21 (70)	-0.004
16 (60)	-0.008
10 (50)	-0.012
4 (39)	-0.016
-1 (30)	-0.020
-7 (20)	-0.024
-12 (10)	-0.028
-18 (0)	-0.032

Corrected specific gravity	Approximate charge condition
1.260 - 1.280	Fully charged
1.230 - 1.250	3/4 charged
1.200 - 1.220	1/2 charged
1.170 - 1.190	1/4 charged
1.140 - 1.160	Almost discharged
1.110 - 1.130	Completely discharged

### CHARGING THE BATTERY

#### CAUTION:

- Do not "quick charge" a fully discharged battery.
- Keep the battery away from open flame while it is being charged.
- When connecting the charger, connect the leads first, then turn on the charger. Do not turn on the charger first, as this may cause a spark.
- If battery electrolyte temperature rises above 60°C (140°F), stop charging. Always charge battery at a temperature below 60°C (140°F).

#### Charging rates:

Amps	Time
50	1 hour
25	2 hours
10	5 hours
5	10 hours

# BATTERY

## How to Handle Battery (Cont'd)

Do not charge at more than 50 ampere rate.

**NOTE:** The ammeter reading on your battery charger will automatically decrease as the battery charges. This indicates that the voltage of the battery is increasing normally as the state of charge improves. The charging amps indicated above refer to initial charge rate.

- If, after charging, the specific gravity of any two cells varies more than 0.050, the battery should be replaced.

## Service Data and Specifications (SDS)

Type		80D26L
Capacity	V-AH	12-65
Cold cranking current (For reference)	A	582

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

IDX

# STARTING SYSTEM

## System Description

### A/T models

Power is supplied at all times

- to ignition switch terminal ①
- through 30A fusible link (letter **d** , located in the fuse and fusible link box).

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse (No. **7** , located in the fuse block)
- to theft warning relay-2 terminal ① and ③.

With the ignition switch in the START position, power is supplied

- from ignition switch terminal ④
- to inhibitor relay terminal ⑦.

If the theft warning system is triggered, terminal ② of the theft warning relay-2 is grounded and power to the inhibitor switch is interrupted.

When theft warning system is not operating, power is supplied

- through theft warning relay-2 terminal ④
- to inhibitor relay terminal ①.

When the selector lever in the P or N position, ground is supplied to inhibitor relay terminal ② through the inhibitor switch and body grounds **(E10)** and **(E33)**.

The inhibitor relay is energized and power is supplied

- from terminal ⑥ of the inhibitor relay
- to terminal ① of the starter motor windings.

The starter motor plunger closes and provides a closed circuit between the battery and the starter motor. The starter motor is grounded to the engine block. With power and ground supplied, cranking occurs and the engine starts.

### M/T models for USA

Power is supplied at all times

- to ignition switch terminal ①
- through 30A fusible link (letter **d** , located in the fuse and fusible link box).

With the ignition switch in the START position, power is supplied

- through terminal ④ of the ignition switch
- to clutch interlock relay terminal ⑤.

With the ignition switch in the START position, power is supplied

- through 10A fuse (No. **16** , located in the fuse block)
- to theft warning relay-2 terminal ③.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse (No. **7** , located in the fuse block)
- to theft warning relay-2 terminal ①.

If the theft warning system is triggered, terminal ② of the theft warning relay-2 is grounded and power to the clutch interlock relay is interrupted.

When theft warning system is not operating, power is supplied

- through theft warning relay-2 terminal ④
- to clutch interlock relay terminal ①.

Ground is supplied to clutch interlock relay terminal ②, when the clutch pedal is depressed, through the clutch interlock switch and body grounds **(M1)** and **(M60)**.

The clutch interlock relay is energized and power is supplied

- from terminal ③ of the clutch interlock relay
- to terminal ① of the starter motor windings.

The starter motor plunger closes and provides a closed circuit between the battery and the starter motor. The starter motor is grounded to the engine block. With power and ground supplied, cranking occurs and the engine starts.

# STARTING SYSTEM

## System Description (Cont'd)

### M/T models for Canada

Power is supplied at all times

- to ignition switch terminal ①
- through 30A fusible link (letter **d**, located in the fuse and fusible link box).

With the ignition switch in the START position, power is supplied

- through terminal ④ of the ignition switch
- to theft warning relay-2 terminal ③.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse (No. **7**, located into fuse block)
- to theft warning relay-2 terminal ①.

If the theft warning system is triggered, terminal ② of the theft warning relay-2 is grounded and power to the starter is interrupted.

When theft warning system is not operating, power is supplied

- through theft warning relay-2 terminal ④
- to terminal ① of the starter motor.

The starter motor plunger closes and provides a closed circuit between the battery and the starter motor. The starter motor is grounded to the engine block. With power and ground supplied, cranking occurs and the engine starts.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL


IDX

# STARTING SYSTEM

## Wiring Diagram — START —


M/T models

EL-START-01



Refer to last page (Foldout page).

(M5), (E102)




# STARTING SYSTEM

## Wiring Diagram — START — (Cont'd)

A/T models


EL-START-02



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA

Refer to last page (Foldout page).

M5, E102




EL

IDX

# STARTING SYSTEM

## Construction


S114-701C



SEL556QA

- |                   |                            |                         |
|-------------------|----------------------------|-------------------------|
| ① Gear case       | ⑧ Adjusting plate          | ⑮ Internal gear         |
| ② Bearing cover   | ⑨ Magnetic switch assembly | ⑯ Center bracket        |
| ③ Ball bearing    | ⑩ E-ring                   | ⑰ Yoke assembly         |
| ④ Pinion assembly | ⑪ Thrust washer            | ⑱ Armature              |
| ⑤ Shift lever     | ⑫ Center bracket           | ⑲ Brush holder assembly |
| ⑥ Dust cover      | ⑬ Pinion shaft             | ⑳ Rear cover            |
| ⑦ Torsion spring  | ⑭ Planetary gear           | ㉑ Dust cover            |

M1T72985A




SEL663Q

- |                   |                            |                |
|-------------------|----------------------------|----------------|
| ① Sleeve bearing  | ⑧ Plate                    | ⑮ Armature     |
| ② Gear case       | ⑨ Packing                  | ⑯ Bush (+)     |
| ③ Stopper clip    | ⑩ Planetary gear           | ⑰ Brush spring |
| ④ Pinion stopper  | ⑪ Adjusting plate          | ⑱ Brush holder |
| ⑤ Pinion assembly | ⑫ Magnetic switch assembly | ⑲ Bearing      |
| ⑥ Internal gear   | ⑬ Packing                  | ⑳ Rear cover   |
| ⑦ Shift lever     | ⑭ Yoke                     |                |



# STARTING SYSTEM



## Removal and Installation

### REMOVAL

1. Remove battery negative cable from battery.
2. Remove intake air duct.
3. Remove starter motor mounting bolts.
4. Remove battery cable from starter motor.
5. Disconnect harness connector from starter motor harness.
6. Remove starter motor from under vehicle.

### INSTALLATION

Installation procedure is basically the reverse order of removal.

### Pinion/Clutch Check

1. Inspect pinion teeth.
  - Replace pinion if teeth are worn or damaged. (Also check condition of ring gear teeth.)
2. Inspect reduction gear teeth.
  - Replace reduction gear if teeth are worn or damaged. (Also check condition of armature shaft gear teeth.)
3. Check to see if pinion locks in one direction and rotates smoothly in the opposite direction.
  - If it locks or rotates in both directions, or unusual resistance is evident, replace.

## Service Data and Specifications (SDS)

### STARTER

Type	S114-701C		M1T72985A	
	HITACHI		MITSUBISHI	
		Reduction gear		
System voltage	V	12		
No-load				
Terminal voltage	V	11.0		
Current	A	Less than 90	50 - 75	
Revolution	rpm	More than 2,950	3,000 - 4,000	
Minimum diameter of commutator	mm (in)	32.0 (1.260)	28.8 (1.134)	
Minimum length of brush	mm (in)	11.0 (0.433)	12.0 (0.472)	
Brush spring tension	N (kg, lb)	17.6 - 21.6 (1.80 - 2.20, 3.96 - 4.86)	13.7 - 25.5 (1.4 - 2.6, 3.1 - 5.7)	
Movement "ℓ" in height of pinion assembly	mm (in)	---		
Clearance of bearing metal and armature shaft	mm (in)	0.03 - 0.3 (0.0012 - 0.0118)	Less than 0.2 (0.008)	
Clearance "ℓ" between pinion front edge and pinion stopper	mm (in)	0.05 - 1.5 (0.0020 - 0.0591)	0.5 - 2.0 (0.020 - 0.079)	

# CHARGING SYSTEM

## System Description

The alternator provides DC voltage to operate the vehicle's electrical system and to keep the battery charged. The voltage output is controlled by the IC regulator.

Power is supplied at all times to alternator terminal **(S)** through:

- 30A fusible link (letter **(d)**, located in the fuse and fusible link box).

Voltage output through alternator terminal **(B)**, to charge the battery and operate the vehicle's electrical system, is controlled by the amount of voltage detected by the IC regulator at terminal **(S)**. The charging circuit is protected by the 75A fusible link.

Terminal **(E)** of the alternator supplies ground through body ground **(AB)**.


With the ignition switch in the ON or START position, power is supplied

- through 10A fuse (No. **(21)**, located in the fuse block)
- to combination meter terminal **(17)** for the charge warning lamp.

Ground is supplied to terminal **(34)** of the combination meter through terminal **(L)** of the alternator. With power and ground supplied, the charge warning lamp will illuminate. When the alternator is providing sufficient voltage with the engine running, the ground is opened and the charge warning lamp will go off.

If the charge warning lamp illuminates with the engine running, a malfunction is indicated.


## Construction



# CHARGING SYSTEM

## Wiring Diagram — CHARGE —


EL-CHARGE-01



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA

EL  
IDX

Refer to last page (Foldout page).  
(M5) . (E102)




# CHARGING SYSTEM

## Trouble Diagnoses

Before conducting an alternator test, make sure that the battery is fully charged. A 30-volt voltmeter and suitable test probes are necessary for the test. The alternator can be checked easily by referring to the Inspection Table.

**Before starting trouble diagnoses, inspect the fusible link.**


### WITH IC REGULATOR



- 1) Use fully charged battery.
- 2) Light : Charge warning light  
ACG : Alternator parts except IC regulator  
IC-RG : IC regulator  
OK : IC-alternator is in good condition.
- 3) When reaching "Damaged ACG", remove alternator from vehicle and disassembly, inspect and correct or replace faulty parts.
- 4) \*Method of grounding F terminal (HITACHI make only)

#### Gasoline engine model

Contact tip of wire with brush and attach wire to alternator body.



SEL030Z

- 5) Terminals "S", "L", "B" and "E" are marked on rear cover of alternator.

# CHARGING SYSTEM

## Service Data and Specifications (SDS)

### ALTERNATOR

Type		A2T82491	
		mitsubishi	GI
Nominal rating	V-A	12-80	
Ground polarity		Negative	MA
Minimum revolution under no-load (When 13.5 volts is applied)	rpm	Less than 1,300	
Hot output current	A/rpm	More than 22/1,300 More than 65/2,500	EM
Regulated output voltage	V	14.1 - 14.7	LC
Minimum length of brush	mm (in)	5 (0.20)	
Brush spring pressure	N (g, oz)	4.609 - 5.786 (470 - 590, 16.58 - 20.81)	EC
Slip ring minimum outer diameter	mm (in)	More than 22.1 (0.870)	
Field coil resistance [at 20°C (68°F)]	Ω	2.4 - 2.9	FE

CL

MT

AT

FA

RA

BR

ST

BF



HA

EL

IDX

# COMBINATION SWITCH

## Combination Switch/Check





**LIGHTING SWITCH**

	OFF			1ST			2ND		
	A	B	C	A	B	C	A	B	C
5			○			○	○	○	○
6			○			○	○	○	○
7									○
8			○			○	○	○	○
9			○			○	○	○	○
10									○
11				○	○	○	○	○	○
12				○	○	○	○	○	○

**WIPER SWITCH**


	OFF	INT	LO	HI	WASH
13	○	○			
14	○	○	○		
15		○	○		
16				○	
17		○	○		○
18					○



**TURN SIGNAL SWITCH**


	R	N	L
1	○		○
2	○		○
3			○

# COMBINATION SWITCH



## Replacement

- Each switch can be replaced without removing combination switch base.



- To remove combination switch base, remove base attaching screw and turn after pushing on it.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

**EL**

IDX

## System Description

The headlamps are controlled by the lighting switch which is built into the combination switch. Power is supplied at all times

- to lighting switch terminal ⑤
- through 15A fuse (No. 27), located in the fuse and fusible link box), and
- to lighting switch terminal ⑧
- through 15A fuse (No. 28), located in the fuse and fusible link box).

### Low beam operation

When the lighting switch is turned to the 2ND and LOW ("B") position, power is supplied

- from lighting switch terminal ⑩
- to terminal ② of the LH headlamp, and
- from lighting switch terminal ⑦
- to terminal ② of the RH headlamp.

Terminal ③ of each headlamp supplies ground through body grounds E10 and E33.

With power and ground supplied, the headlamp(s) will illuminate.

### High beam operation/flash-to-pass operation

When the lighting switch is placed in the 2ND and HIGH ("A") position or PASS ("C") position, power is supplied

- from lighting switch terminal ⑥
- to terminal ① of the RH headlamp, and
- from lighting switch terminal ⑨
- to terminal ① of the LH headlamp, and
- to combination meter terminal ⑤ for the high beam indicator.

Ground is supplied to terminal ④ of the combination meter through body grounds M1 and M80.

Terminal ③ of each headlamp supplies ground through body grounds E10 and E33.

With power and ground supplied, the high beams and the HI BEAM indicator illuminate.


### Theft warning system

The theft warning system will flash the high beams if the system is triggered. Refer to "THEFT WARNING SYSTEM" (EL-138).



# HEADLAMP — Without Daytime Light System —

## Wiring Diagram — H/LAMP —



EL-H/LAMP-01


Refer to 'EL-POWER'.

LIGHTING SWITCH (E108)

COMBINATION METER (HIGH BEAM INDICATOR) (M27)

Refer to last page (Foldout page).

(M5) , (E102)



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

## System Description

The headlamp system for Canada vehicles contains a daytime light control unit that activates the high beam headlamps at approximately half illumination whenever the engine is running. If the parking brake is applied before the engine is started, the daytime lights will not be illuminated. The daytime lights will illuminate once the parking brake is released. Thereafter, the daytime lights will continue to operate when the parking brake is applied.

Power is supplied at all times

- through 15A fuse (No. 27), located in the fuse and fusible link box)
- to daytime light control unit terminal ③ and
- to lighting switch terminal ⑤.

Power is also supplied at all times

- through 15A fuse (No. 28), located in the fuse and fusible link box)
- to daytime light control unit terminal ④,
- to lighting switch terminal ⑧.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse (No. 26), located in the fuse block)
- to daytime light control unit terminal ⑤.

Ground is supplied to daytime light control unit terminal ⑩ through body grounds M1 and M60.

## HEADLAMP OPERATION

### Low beam operation

When the lighting switch is moved to the 2ND and LOW ("B") position, power is supplied

- from lighting switch terminal ⑦
- to RH headlamp terminal ③ and
- to daytime light control unit terminal ②.

Ground is supplied to RH headlamp terminal ② through body grounds E10 and E33.

Also, when the lighting switch is moved to the 2ND and LOW ("B") position, power is supplied

- from lighting switch terminal ⑩
- to LH headlamp terminal ③.

Ground is supplied

- to LH headlamp terminal ②
- from daytime light control unit terminal ⑧
- through daytime light control unit terminal ⑩
- through body grounds M1 and M60.

With power and ground supplied, the low beam headlamps illuminate.

### High beam operation/flash-to-pass operation

When the lighting switch is moved to the 2ND and HIGH ("A") position or PASS ("C") position, power is supplied

- from lighting switch terminal ⑥
- to RH headlamp terminal ①.

When the lighting switch is moved to the 2ND and HIGH ("A") position or PASS ("C") position, power is supplied

- from lighting switch terminal ⑨
- to combination meter terminal ⑤ for the high beam indicator and
- to daytime light control unit terminal ⑥
- through daytime light control unit terminal ⑦
- to LH headlamp terminal ①.

Ground is supplied in the same manner as low beam operation.

Ground is supplied to terminal ④ of the combination meter through body ground M1 and M60.

With power and ground supplied, the high beam headlamps and high beam indicator illuminate.

## DAYTIME LIGHT OPERATION

With the engine running and the lighting switch in the OFF position, power is supplied

- to daytime light control module terminal ④,
- through daytime light control module terminal ⑦
- to LH headlamp terminal ①,
- through LH headlamp terminal ②

# HEADLAMP — Daytime Light System —

## System Description (Cont'd)

- to daytime light control module terminal ⑧ and
- through daytime light control module terminal ⑨
- to RH headlamp terminal ①.

Ground is supplied to RH headlamp terminal ② through body grounds (E10) and (E33).  
 Because the high beam headlamps are now wired in series, they operate at half illumination.

### Operation

After starting the engine with the lighting switch in the "OFF" or "1ST" position, the headlamp high beam automatically turns on. Lighting switch operations other than the above are the same as conventional light systems.


Engine		With engine stopped									With engine running								
		OFF			1ST			2ND			OFF			1ST			2ND		
		A	B	C	A	B	C	A	B	C	A	B	C	A	B	C	A	B	C
Headlamp	High beam	X	X	O	X	X	O	O	X	O	△	△	O	△	△	O	O	X	O
	Low beam	X	X	X	X	X	X	X	O	X	X	X	X	X	X	X	X	O	X
Clearance and tail lamp		X	X	X	O	O	O	O	O	O	X	X	X	O	O	O	O	O	O
License and instrument illumination lamp		X	X	X	O	O	O	O	O	O	X	X	X	O	O	O	O	O	O

O : Lamp "ON"

X : Lamp "OFF"


△ : Lamp dims.

### Schematic




Wiring Diagram — DTRL —

EL-DTRL-01




Refer to "EL-POWER".

Refer to last page (Foldout page).  
 (M5), (E102)




# HEADLAMP — Daytime Light System — Wiring Diagram — DTRL — (Cont'd)

EL-DTRL-02



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF




Refer to last page (Foldout page).  
(M5), (E102)

HA  
**EL**  
IDX



# HEADLAMP — Daytime Light System — Wiring Diagram — DTRL — (Cont'd)

EL-DTRL-03



Preceding page

Refer to last page (Foldout page).  
M5, E102



# HEADLAMP

## Trouble Diagnoses (For USA)

Symptom	Possible cause	Repair order
LH headlamps do not operate.	<ol style="list-style-type: none"> <li>1. Bulb</li> <li>2. Grounds (E10) and (E15)</li> <li>3. 15A fuse</li> <li>4. Lighting switch</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb.</li> <li>2. Check grounds (E10) and (E15).</li> <li>3. Check 15A fuse (No. 28), located in fusible link and fuse box). Verify battery positive voltage is present at terminal ⑥ of lighting switch.</li> <li>4. Check lighting switch.</li> </ol>
RH headlamps do not operate.	<ol style="list-style-type: none"> <li>1. Bulb</li> <li>2. Grounds (E10) and (E15)</li> <li>3. 15A fuse</li> <li>4. Lighting switch</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb.</li> <li>2. Check grounds (E10) and (E15).</li> <li>3. Check 15A fuse (No. 27), located in fusible link and fuse box). Verify battery positive voltage is present at terminal ⑤ of lighting switch.</li> <li>4. Check lighting switch.</li> </ol>
LH high beam does not operate, but LH low beam operates.	<ol style="list-style-type: none"> <li>1. Bulb</li> <li>2. Open in LH high beam circuit</li> <li>3. Lighting switch</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb.</li> <li>2. Check R/B wire between lighting switch and LH headlamp for an open circuit.</li> <li>3. Check lighting switch.</li> </ol>
LH low beam does not operate, but LH high beam operates.	<ol style="list-style-type: none"> <li>1. Bulb</li> <li>2. Open in LH low beam circuit</li> <li>3. Lighting switch</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb.</li> <li>2. Check R/Y wire between lighting switch and LH headlamp for an open circuit.</li> <li>3. Check lighting switch.</li> </ol>
RH high beam does not operate, but RH low beam operates.	<ol style="list-style-type: none"> <li>1. Bulb.</li> <li>2. Open in RH high beam circuit</li> <li>3. Lighting switch.</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb.</li> <li>2. Check R/G wire between lighting switch and RH headlamp for an open circuit.</li> <li>3. Check lighting switch.</li> </ol>
RH low beam does not operate, but RH high beam operates.	<ol style="list-style-type: none"> <li>1. Bulb</li> <li>2. Open in RH low beam circuit</li> <li>3. Lighting switch</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb.</li> <li>2. Check R/L wire between lighting switch and RH headlamp for an open circuit.</li> <li>3. Check lighting switch.</li> </ol>
High beam indicator does not work.	<ol style="list-style-type: none"> <li>1. Bulb</li> <li>2. Grounds (M1) and (M60)</li> <li>3. Open in high beam circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb in combination meter.</li> <li>2. Check grounds (M1) and (M60).</li> <li>3. Check R/B wire between joint connector-5 and combination meter for an open circuit.</li> </ol>

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL
















IDX

# HEADLAMP

## Trouble Diagnoses (For Canada)

### DAYTIME LIGHT CONTROL UNIT INSPECTION TABLE






(Data are reference values.)


Terminal No.	Item	Condition		Judgement standard
1	Start/parking brake signal		When turning ignition switch to "ST".	Battery positive voltage
		 	When turning ignition switch to "ON" from "ST" with parking brake set.	Battery positive voltage
		 	When releasing parking brake with engine running. <b>CAUTION: Block wheels and ensure selector lever is in N or P position.</b>	1V or less
			When turning ignition switch to "OFF".	1V or less
2	Lighting switch (Lo beam)		When turning lighting switch to "HEAD" (2nd position).	Battery positive voltage
3	Power source		When turning ignition switch to "ON".	Battery positive voltage
			When turning ignition switch to "OFF".	Battery positive voltage
4	Power source		When turning ignition switch to "ON".	Battery positive voltage
			When turning ignition switch to "OFF".	Battery positive voltage
5	Power source		When turning ignition switch to "ON".	Battery positive voltage
			When turning ignition switch to "ST".	Battery positive voltage
			When turning ignition switch to "OFF".	1V or less
6	Lighting switch (Hi beam)		When turning lighting switch to "HI BEAM".	Battery positive voltage
			When turning lighting switch to "FLASH TO PASS".	Battery positive voltage
7	LH hi beam		When turning lighting switch to "HI BEAM".	Battery positive voltage
		 	When releasing parking brake with engine running and turning lighting switch to "OFF" (day-time light operation). <b>CAUTION: Block wheels and ensure selector lever is in N or P position.</b>	Battery positive voltage



# HEADLAMP

## Trouble Diagnoses (For Canada) (Cont'd)

Terminal No.	Item	Condition	Judgement standard	
8	LH headlamp control (ground)		When lighting switch is turned to "HEAD".	1V or less
			When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation). <b>CAUTION: Block wheels and ensure selector lever is in N or P position.</b>	Approx. half battery voltage
9	RH hi beam		When turning lighting switch to "HI BEAM".	Battery positive voltage
			When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation). <b>CAUTION: Block wheels and ensure selector lever is in N or P position.</b>	Approx. half battery voltage
10	Ground	—	—	
11	Alternator		When turning ignition switch to "ON".	1V or less
			When engine is running.	Battery positive voltage
			When turning ignition switch to "OFF".	1V or less
12	—	—	—	



### Bulb Replacement

The headlamp is a semi-sealed beam type which uses a replaceable halogen bulb. The bulb can be replaced from the engine compartment side without removing the headlamp body.

- **Grasp only the plastic base when handling the bulb. Never touch the glass envelope.**

1. Disconnect the battery cable.
2. Turn the bulb retaining ring counterclockwise until it is free from the headlamp reflector, and then remove it.
3. Disconnect the harness connector from the back side of the bulb.
4. Remove the headlamp bulb carefully. Do not shake or rotate the bulb when removing it.
5. Install in the reverse order of removal.

#### CAUTION:

- **Do not leave headlamp reflector without bulb for a long period of time. Dust, moisture, smoke, etc. entering headlamp body may affect the performance of the headlamp. Remove headlamp bulb from the headlamp reflector just before a replacement bulb is installed.**

# HEADLAMP


## Aiming Adjustment

When performing headlamp aiming adjustment, use an aiming machine, aiming wall screen or headlamp tester. Aimers should be in good repair, calibrated and operated in accordance with respective operation manuals.

If any aimer is not available, aiming adjustment can be done as follows:

**For details, refer to the regulations in your own country.**



- a. **Keep all tires inflated to correct pressures.**
- b. **Place vehicle and tester on one and same flat surface.**
- c. **See that there is no-load in vehicle (coolant, engine oil filled up to correct level and full fuel tank) other than the driver (or equivalent weight placed in driver's position).**



### AIMER ADJUSTMENT MARK

When using a mechanical aimer, adjust adapter legs to the data marked on the headlamps.

Example:




### LOW BEAM

1. Turn headlamp low beam on.
  2. Use adjusting screws to perform aiming adjustment.
- **First tighten the adjusting screw all the way and then make adjustment by loosening the screw.**

# HEADLAMP

## Aiming Adjustment (Cont'd)



- Upper edge and left edge of high intensity zone should be within the range shown at left. Adjust headlamps accordingly.
  - Dotted lines in illustration show center of headlamp.
- "H": Horizontal center line of headlamps  
 "W<sub>L</sub>": Distance between each headlamp center


GI  
 MA  
 EM  
 LC  
 EC  
 FE  
 CL  
 MT  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
**EL**  
 IDX



# EXTERIOR LAMP

## Clearance, License, Tail and Stop Lamps/Wiring Diagram — TAIL/L — (Cont'd)

EL-TAIL/L-02





GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

# EXTERIOR LAMP


## Clearance, License, Tail and Stop Lamps/Wiring Diagram — TAIL/L — (Cont'd)

EL-TAIL/L-03



# EXTERIOR LAMP

## Clearance, License, Tail and Stop Lamps/ Schematic




MEL178D

# EXTERIOR LAMP



## Back-up Lamp/Wiring Diagram — BACK/L —

EL-BACK/L-01



Refer to last page (Foldout page).

M5, E102





# EXTERIOR LAMP

## Front Fog Lamp/System Description

Power is supplied at all times to fog lamp relay terminal ③ through:

- 15A fuse (No. 13 , located in the fuse block).

With the lighting switch in the 2ND and LOW ("B") position, power is supplied

- through 15A fuse (No. 27 , located in the fuse and fusible link box)
- to lighting switch terminal ⑤ and
- through terminal ⑦ of the lighting switch
- to fog lamp switch terminal ①.

### Fog lamp operation

The lighting switch must be in the 2ND and LOW ("B") position for fog lamp operation.

With the fog lamp switch in the ON position:

- ground is supplied to fog lamp relay terminal ② through the fog lamp switch and body grounds M1 and M60.

The fog lamp relay is energized and power is supplied

- from fog lamp relay terminal ⑤
- to terminal ① of each fog lamp.

Ground is supplied to terminal ② of each fog lamp through body grounds E10 and E33.

With power and ground supplied, the fog lamps illuminate.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA


EL

IDX

# EXTERIOR LAMP

## Front Fog Lamp/Wiring Diagram — F/FOG —

EL-F/FOG-01



Refer to "EL-POWER".

Refer to last page (Foldout page).

M5, E102



## EXTERIOR LAMP

### Turn Signal and Hazard Warning Lamps/System Description

#### TURN SIGNAL OPERATION

With the hazard switch in the OFF position and the ignition switch in the ON or START position, power is supplied GI

- through 10A fuse (No. 22 , located in the fuse block)
- to hazard switch terminal ② MA
- through terminal ① of the hazard switch
- to combination flasher unit terminal ① EM
- through terminal ③ of the combination flasher unit
- to turn signal switch terminal ①.

Ground is supplied to combination flasher unit terminal ② through body grounds (M1) and (M60). LC

#### LH turn

When the turn signal switch is moved to the LH position, power is supplied from turn signal switch terminal ③ to EC

- front turn signal lamp LH terminal ① FE
- rear combination lamp LH terminal ③
- combination meter terminal ⑥, and

Ground is supplied to the front turn signal lamp LH terminal ② through body grounds (E10) and (E33). CL

Ground is supplied to the rear combination lamp LH terminal ④ through body grounds (M101) and (M165).

Ground is supplied to combination meter terminal ⑯ through body grounds (M1) and (M60).

With power and ground supplied, the flasher unit controls the flashing of the LH turn signal lamps. MT

#### RH turn

When the turn signal switch is moved to the RH position, power is supplied from turn signal switch terminal ② to AT

- front turn signal lamp RH terminal ① FA
- rear combination lamp RH terminal ③
- combination meter terminal ⑫, and

Ground is supplied to the front turn signal lamp RH terminal ② through body grounds (E10) and (E33). RA

Ground is supplied to the rear combination lamp RH terminal ④ through body ground (M101) and (M165).

Ground is supplied to combination meter terminal ⑯ through body grounds (M1) and (M60).

With power and ground supplied, the flasher unit controls the flashing of the RH turn signal lamps. BR

#### HAZARD LAMP OPERATION

Power is supplied at all times to hazard switch terminal ③ through: ST

- 10A fuse (No. 17 , located in the fuse block).

With the hazard switch in the ON position, power is supplied BF

- through terminal ① of the hazard switch
- to combination flasher unit terminal ①
- through terminal ③ of the combination flasher unit HA
- to hazard switch terminal ④.

Ground is supplied to combination flasher unit terminal ② through body grounds (M1) and (M60).

Power is supplied through terminal ⑤ of the hazard switch to EL

- front turn signal lamp LH terminal ①
- rear combination lamp LH terminal ③
- combination meter terminal ⑥. IDX

Power is supplied through terminal ⑥ of the hazard switch to

- front turn signal lamp RH terminal ①
- rear combination lamp RH terminal ③
- combination meter terminal ⑫, and

Ground is supplied to terminal ② of the front turn signal lamps through body grounds (E10) and (E33).

Ground is supplied to terminal ④ of the rear combination lamps through body grounds (M101) and (M165).

Ground is supplied to combination meter terminal ⑳ through body grounds (M1) and (M60).

With power and ground supplied, the flasher unit controls the flashing of the hazard warning lamps.

## EXTERIOR LAMP

### Turn Signal and Hazard Warning Lamps/System Description (Cont'd)

#### WITH MULTI-REMOTE CONTROL SYSTEM

Power is supplied at all times

- through 10A fuse (No. 17) located in the fuse block)
- to multi-remote control relay terminal ①, ⑥ and ③.

Ground is supplied to multi-remote control relay terminal ②, when the multi-remote control system is triggered through the multi-remote control unit.

(Refer to "MULTI-REMOTE CONTROL SYSTEM" in BF section.)

The multi-remote control relay is energized.

Power is supplied through terminal ⑦ of the multi-remote control relay

- to front turn signal lamp RH terminal ①,
- to rear combination lamp RH terminal ③ and
- to combination meter terminal ⑫

Power is supplied through terminal ⑤ of the multi-remote control relay



- to front turn signal lamp LH terminal ①,
- to rear combination lamp LH terminal ③ and
- to combination meter terminal ⑥.

With power and ground supplied, the multi-remote control unit controls the flashing of the hazard warning lamps.

# EXTERIOR LAMP

## Turn Signal and Hazard Warning Lamps/ Wiring Diagram — TURN —

EL-TURN-01



GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA



EL

IDX

# EXTERIOR LAMP

## Turn Signal and Hazard Warning Lamps/ Wiring Diagram — TURN — (Cont'd)

EL-TURN-02




(KL) : Models with multi-remote control system



# EXTERIOR LAMP

## Turn Signal and Hazard Warning Lamps/ Wiring Diagram — TURN — (Cont'd)

EL-TURN-03




GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA

EL  
IDX


Refer to last page (Foldout page).

(M5), (E102)



# EXTERIOR LAMP

## Turn Signal and Hazard Warning Lamps/ Schematic




MEL130D



# EXTERIOR LAMP

## Turn Signal and Hazard Warning Lamps/Trouble Diagnoses

Symptom	Possible cause	Repair order
Turn signal and hazard warning lamps do not operate.	<ol style="list-style-type: none"> <li>1. Hazard switch</li> <li>2. Combination flasher unit</li> <li>3. Open in combination flasher unit circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check hazard switch.</li> <li>2. Refer to combination flasher unit check.</li> <li>3. Check wiring to combination flasher unit for open circuit.</li> </ol>
Turn signal lamps do not operate but hazard warning lamps operate.	<ol style="list-style-type: none"> <li>1. 10A fuse</li> <li>2. Hazard switch</li> <li>3. Turn signal switch</li> <li>4. Open in turn signal switch circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check 10A fuse (No. 22, located in fuse block). Turn ignition switch ON and verify battery positive voltage is present at terminal ② of hazard switch.</li> <li>2. Check hazard switch.</li> <li>3. Check turn signal switch.</li> <li>4. Check LG/B wire between combination flasher unit and turn signal switch for open circuit.</li> </ol>
Hazard warning lamps do not operate but turn signal lamps operate.	<ol style="list-style-type: none"> <li>1. 10A fuse</li> <li>2. Hazard switch</li> <li>3. Open in hazard switch circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check 10A fuse (No. 17, located in fuse block). Verify battery positive voltage is present at terminal ③ of hazard switch.</li> <li>2. Check hazard switch.</li> <li>3. Check LG/B wire between combination flasher unit and hazard switch for open circuit.</li> </ol>
Front turn signal lamp LH or RH does not operate.	<ol style="list-style-type: none"> <li>1. Bulb</li> <li>2. Grounds (E10) and (E33)</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb.</li> <li>2. Check grounds (E10) and (E33).</li> </ol>
Rear turn signal lamp LH or RH does not operate.	<ol style="list-style-type: none"> <li>1. Bulb</li> <li>2. Grounds (M101) and (M165)</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb.</li> <li>2. Check grounds (M101) and (M165).</li> </ol>
LH and RH turn indicators do not operate.	<ol style="list-style-type: none"> <li>1. Ground</li> </ol>	<ol style="list-style-type: none"> <li>1. Check grounds (M1) and (M60).</li> </ol>
LH or RH turn indicator does not operate.	<ol style="list-style-type: none"> <li>1. Bulb</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb in combination meter.</li> </ol>



### Combination Flasher Unit Check

- Before checking, ensure that bulbs meet specifications.
- Connect a battery and test lamp to the combination flasher unit, as shown. Combination flasher unit is properly functioning if it blinks when power is supplied to the circuit.

# EXTERIOR LAMP

## Bulb Specifications

	Wattage (12 volt)
Headlamp (Semi-sealed beam)	
High/Low	65/45
Front turn signal lamp	27
Front clearance lamp	3.8
Front side marker lamp	3.8
Front fog lamp	55
Rear combination lamp	
Turn signal	27
Stop/Tail	27/8
Back-up	27
Rear side marker lamp	3.8
License plate lamp	5
High-mounted stop lamp	12
Interior lamp	10
Spot lamp	10
Trunk room lamp	3.4

# INTERIOR LAMP

## Illumination/System Description

Power is supplied at all times

- through 15A fuse (No. 23), located in the fuse block)
- to lighting switch terminal ①.

The lighting switch must be in the 1ST or 2ND position for illumination.

The illumination control switch is a thumbwheel that controls the amount of current to the illumination system. As the amount of current increases, the illumination becomes brighter.

The ashtray illumination and the glove box lamp are not controlled by the illumination control switch. The intensity of these lamps does not change.

The following chart shows the power and ground connector terminals for the components included in the illumination system.

Component	Connector No.	Power terminal	Ground terminal
Radio	M38	⑧	⑦
Door lock and unlock switch	M130	⑥	⑦
Key illumination	E105	①	②
Push control unit	M40	⑮	⑯
Front fog lamp switch	M37	③	④
A/T indicator	M115	③	④
Hazard switch	M36	⑦	⑧
Power window main switch LH	M110	⑥	⑦
Power window main switch RH	M129	⑦	⑧
Front power window sub-switch LH	D4	⑤	⑥
Front power window sub-switch RH	D30	⑥	⑦
Cigarette lighter	M43	③	④
Ashtray	M44	①	②
Combination meter	M27	23	20
Clock	M27	22	20
ASCD main switch	M25	⑤	⑥
Rear window defogger switch	M34	⑤	⑥
Glove box lamp	M51	①	②
Illumination control switch	M23	①	②

With the exception of the glove box lamp and the ashtray illumination, the ground for all of the components are controlled through terminals ② and ③ of the illumination control switch and body grounds M1 and M60.


The glove box lamp terminal ② and ashtray illumination terminal ② are grounded directly through body grounds M1 and M60.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
DX


# INTERIOR LAMP

## Illumination/Wiring Diagram — ILL —

EL-ILL-01




Refer to last page (Foldout page).  
 (M5), (E102)




# INTERIOR LAMP

## Illumination/Wiring Diagram — ILL — (Cont'd)

EL-ILL-02



GI  
 MA  
 EM  
 LC  
 EC  
 FE  
 CL  
 WT  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA





EL

IDX

# INTERIOR LAMP


## Illumination/Wiring Diagram — ILL — (Cont'd)

EL-ILL-03



# INTERIOR LAMP

## Illumination/Schematic



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

## INTERIOR LAMP

### Interior, Spot and Trunk Room Lamps/System Description

Power is supplied at all times

- through 10A fuse (No. 25) located in the fuse block)
- to interior lamp terminal ①,
- to spot lamp terminal ①,
- to trunk room lamp terminal ①,
- to vanity mirror illumination LH terminal ① and
- to vanity mirror illumination RH terminal ①.

### INTERIOR LAMP

#### Switch operation

With interior lamp switch is ON, ground is supplied to turn interior lamp on.

When a door switch is set to OPEN with interior lamp switch in DOOR, ground is supplied

- to interior lamp terminal ②
- through diode terminal ①
- to diode terminal ②
- through front door switch LH terminal ②,
- through front door switch RH terminal ②,
- through rear door switch LH terminal ① or
- through rear door switch RH terminal ①.

#### Interior lamp timer operation by time control system

With front door switch LH set to CLOSED, ground is supplied

- to time control unit terminal 18
- through front door switch LH terminal ①
- to front door switch LH terminal ③
- through body grounds (M101) and (M165).

With interior lamp switch in DOOR and front door switch LH set to CLOSED, time control unit receives position signals. Ground is then supplied

- to interior lamp terminal ②
- through time control unit terminal 20.

Time control unit is grounded at terminal 20 to control interior lamp operation.

#### Interior lamp control by multi-remote control system

Multi-remote control system receives a signal to turn interior lamp on with interior lamp switch set to DOOR. Ground is then supplied

- to interior lamp terminal ②
- through multi-remote control unit terminal 17.

Multi-remote control unit is grounded at terminal 17 to turn interior lamp on.

### SPOT LAMP AND VANITY MIRROR LAMP

With a switch ON, power is supplied

- to spot lamp,
- to vanity mirror lamp LH and
- to vanity mirror lamp RH.

Ground is supplied

- to spot lamp terminal ②,
- to vanity mirror lamp LH terminal ② and
- to vanity mirror lamp RH terminal ②
- through body grounds (M1) and (M60).

With power and ground supplied, the lamp turns on.



## INTERIOR LAMP

### Interior, Spot and Trunk Room Lamps/System Description (Cont'd)

#### TRUNK ROOM LAMP

When trunk room lamp switch is in OPEN position, ground is supplied

- to trunk room lamp terminal ②
- through trunk room lamp switch terminal ①
- to trunk room lamp switch terminal ②
- through body grounds (M101) and (M166).

With power and ground supplied, trunk room lamp turns on.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA


**EL**

IDX

# INTERIOR LAMP

## Interior, Spot and Trunk Room Lamps/Wiring Diagram — INT/L —

EL-INT/L-01



Refer to last page (Foldout page).

(M5, E102)



## System Description

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse (No. 21 , located in the fuse block)
- to combination meter terminal 17 .

Ground is supplied

- to combination meter terminal 12 and
- terminal 19
- through body grounds (M1) and (M60).

The water temperature gauge indicates the engine coolant temperature. The reading on the gauge is based on the resistance of the thermal transmitter.

As the temperature of the coolant increases, the resistance of the thermal transmitter decreases. A variable ground is supplied to terminal 24 of the combination meter for the water temperature gauge. The needle on the gauge moves from "C" to "H".

The tachometer indicates engine speed in revolutions per minute (rpm).

The tachometer is regulated by a signal

- from terminal 3 of the ECM (ECCS control module)
- to combination meter terminal 21 for the tachometer.

The fuel gauge indicates the approximate fuel level in the fuel tank.

The fuel gauge is regulated by a variable ground signal supplied

- to combination meter terminal 18 for the fuel gauge
- from terminal 1 of the fuel tank gauge unit
- through terminal 3 of the fuel tank gauge unit and
- through body grounds (M101) and (M185).

The vehicle speed sensor provides a voltage signal to the combination meter for the speedometer.

The voltage is supplied

- to combination meter terminals 14 and 16 for the speedometer
- from terminals 1 and 2 of the vehicle speed sensor.

The speedometer converts the voltage into the vehicle speed displayed.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF




HA

EL

IDX

# METER AND GAUGES


## Combination Meter



MEL194D

Speedometer, Tachometer, Temp., Oil and Fuel Gauges/Wiring Diagram — METER —

EL-METER-01




GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA

Refer to last page (Foldout page).



M5, E102  
F29

EL



# METER AND GAUGES

## Speedometer, Tachometer, Temp., Oil and Fuel Gauges/Wiring Diagram — METER — (Cont'd)







Refer to last page (Foldout page).


(M5) (E102)

# METER AND GAUGES

## Inspection/Fuel Gauge, Water Temperature Gauge and Oil Pressure Gauge




GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX



## Fuel Tank Gauge Unit Check


- For removal, refer to FE section. Check the resistance between terminals (G) and (E).

Ohmmeter		Float position mm (in)		Resistance value ( $\Omega$ )
(+)	(-)			
G	E	*3	Full	49 (1.93)
		*2	1/2	106 (4.17)
		*1	Empty	161 (6.34)



## Fuel Warning Lamp Sensor Check

- It will take a short time for the bulb to light.




## Thermal Transmitter Check

Check the resistance between the terminals of thermal transmitter and body ground.

Water temperature	Resistance
65°C (149°F)	Approx. 60 - 75 $\Omega$
91°C (196°F)	Approx. 21 - 24 $\Omega$






## Oil Pressure Switch Check

Check the continuity between the terminals of oil pressure switch and body ground.

	Oil pressure kPa (kg/cm <sup>2</sup> , psi)	Continuity
Engine start	More than 10 - 20 (0.1 - 0.2, 1 - 3)	NO
Engine stop	Less than 10 - 20 (0.1 - 0.2, 1 - 3)	YES




## Vehicle Speed Sensor Signal Check

1. Remove vehicle speed sensor from transaxle.
2. Turn vehicle speed sensor pinion quickly and measure voltage across **a** and **b**.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX



# WARNING LAMPS AND CHIME

## Warning Lamps/Schematic



Warning Lamps/Wiring Diagram — WARN —

EL-WARN-01



Refer to last page (Foldout page).

- (M5) (E102)
- (M63)
- (F29)

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA



EL

IDX

# WARNING LAMPS AND CHIME

## Warning Lamps/Wiring Diagram — WARN — (Cont'd)

EL-WARN-02



Refer to last page (Foldout page).

M5, E102

A101

## Warning Chime/System Description

The warning chime is a part of the combination meter and is controlled by the Time Control System.

Power is supplied at all times

- through 10A fuse (No. 25), located in the fuse block)
- to time control unit terminal 9, and
- key switch terminal 1.

GI

Power is supplied at all times

- through 10A fuse (No. 19), located in the fuse block)
- to lighting switch terminal 1, and
- combination meter terminal 26.

MA

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse (No. 26) located in the fuse block)
- to time control unit terminal 5.

EM

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse (No. 21) located in the fuse block)
- to seat belt relay terminal 1.

LC

Ground is supplied to time control unit terminal 15 through body grounds M1 and M60.

EC

When a signal, or combination of signals, is received by the time control unit, ground is supplied

- through time control unit terminal 19 and
- through seat belt relay terminal 3
- to combination meter terminal 13.

FE

With power and ground supplied, the warning chime will sound.

CL

### Ignition key warning chime

With the key in the ignition switch in the OFF position, and the driver's door open, the warning chime will sound. A battery positive voltage is supplied

MT

- from key switch terminal 2
- to time control unit terminal 10.

AT

Ground is supplied

- from front door switch LH terminal 1
- to time control unit terminal 18.

FA

Front door switch LH terminal 3 is grounded through body grounds M101 and M165.

RA

### Light warning chime

With the ignition switch in the OFF position, the driver's door open, and the lighting switch in the 1ST or 2ND position, the warning chime will sound. A battery positive voltage is supplied

BR

- from lighting switch terminal 12
- to time control unit terminal 6 and
- from key switch terminal 2
- to time control unit terminal 10

ST

Ground is supplied

- from front door switch LH terminal 1
- to time control unit terminal 18.

BF

HA

### Seat belt warning chime

This warning chime sounds for approximately 7 seconds

- when ignition switch is turned from OFF to ON and seat belt is unfastened (seat belt switch ON).

EL

The warning chime sounds until seat belt buckle switch is turned OFF (seat belt tongue is inserted into buckle).

IDX

Ground is supplied to seat belt relay terminal 2 when the seat belt is unfastened through the seat belt buckle switch and body grounds M101 and M165.


The seat belt relay is energized and ground is supplied

- through time control unit terminal 16
- to seat belt relay terminal 4

# WARNING LAMPS AND CHIME

## Warning Chime/Wiring Diagram — CHIME —

EL-CHIME-01




Refer to 'EL-POWER'.


TIME CONTROL UNIT (M17)  
(Refer to 'EL-TIME'.)

Refer to last page (Foldout page).

(M5, E102)  
(E29)



# WARNING LAMPS AND CHIME




## Diode Check

- Check continuity using an ohmmeter.
- Diode is functioning properly if test results are as shown in the figure at left.

**NOTE:** Specification may vary depending on the type of tester. Before performing this inspection, be sure to refer to the instruction manual for the tester to be used.

- Diodes for warning lamps are built into the combination meter printed circuit.

Refer to "Combination Meter" (EL-68).



## Warning Chime Check

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

IDX

## System Description

Power is supplied at all times

- to time control unit terminal ⑨
- through 10A fuse (No. 25), located in the fuse block).

With the ignition switch in the ACC or ON position, power is supplied

- to time control unit terminal ②
- through 10A fuse (No. 10), located in the fuse block).

With the ignition switch in the ON or START position, power is supplied

- to time control unit terminal ⑤
- through 10A fuse (No. 26), located in the fuse block).

Terminal ⑮ of the time control unit is grounded through body grounds (M1) and (M60).

The time control system controls operation of the

- rear window and door mirror defogger,
- warning chime
- front wiper and washer and
- interior lamp.

### Rear Window and Door Mirror Defogger

The time control unit will operate the rear window and door mirror defogger for 15 minutes as long as the rear window defogger switch is in the ON position. For detailed description, refer to "REAR WINDOW DEFOGGER" (EL-103).

### Warning Chime

The time control system will operate the warning chime located on the combination meter under the following conditions:

- key in ignition, ignition switch in OFF position, and driver's door open.
- ignition switch in the OFF position, driver's door open, and lighting switch in the 1ST or 2ND position.
- ignition switch turned from the OFF position to the ON position, and the seat belt unfastened.

For detailed description, refer to "WARNING LAMPS AND CHIME" (EL-74).

### Front Wiper and Washer

The time control system controls operation of the intermittent feature for the front wiper. It also controls wiper motor for the washer operation.

For detailed description, refer to "FRONT WIPER AND WASHER" (EL-97).

### Interior lamp

Time control unit starts to dim interior lamp and turns it off within approximately 10 seconds when

- interior lamp switch is set to DOOR and front door switch LH to CLOSED.

## FUNCTION

- Time control unit has the following functions.



Item	Details of control
Intermittent wiper control	Regulates intermittent time from approximately 1 to 20 seconds depending on the intermittent wiper volume setting.
Washer and wiper combination control	Wiper is operated in conjunction with washer switch.
Light warning chime timer	When driver's door is opened with light switch ON and ignition switch OFF, warning chime sounds.
Ignition key warning chime timer	When driver's door is opened with ignition switch OFF, warning chime sounds.
Seat belt warning chime timer	Sounds warning chime if ignition switch is turned "ON" when seat belt switch is "ON" (seat belt is unfastened). Warning chime sounds for about 7 seconds.
Rear defogger timer	Rear defogger operates for about 15 minutes when defogger switch is ON.
Interior lamp timer	Fades out interior lamp when driver's side door is opened and closed.



# TIME CONTROL SYSTEM

## Wiring Diagram — TIME —

EL-TIME-01




EL  
IDX


# TIME CONTROL SYSTEM

## Wiring Diagram — TIME — (Cont'd)

EL-TIME-02



Refer to last page (Foldout page).  
 (M5), (E102)











# TIME CONTROL SYSTEM

## Wiring Diagram — TIME — (Cont'd)

EL-TIME-05



Refer to last page (Foldout page).

(M5, E102)

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

IDX

# TIME CONTROL SYSTEM

## Trouble Diagnoses

### SYMPTOM CHART

PROCEDURE		Preliminary Check			Main Power Supply and Ground Circuit Check	Diagnostic Procedure							
		EL-87	EL-87	EL-87		EL-88	EL-90	EL-91	EL-91	EL-92	EL-93	EL-94	EL-95
REFERENCE PAGE		EL-87	EL-87	EL-87	EL-88	EL-90	EL-91	EL-91	EL-92	EL-93	EL-94	EL-95	EL-96
SYMPTOM		Procedure 1	Procedure 2	Procedure 3	Main power supply and Ground circuit	Diagnostic Procedure 1	Diagnostic Procedure 2	Diagnostic Procedure 3	Diagnostic Procedure 4	Diagnostic Procedure 5	Diagnostic Procedure 6	Diagnostic Procedure 7	Diagnostic Procedure 8
Wiper & washer	Intermittent wiper does not operate.				○	○							
	Intermittent time of wiper cannot be adjusted.						○						
	Wiper and washer activate individually but not in combination.							○					
Warning	Light warning chime does not activate.	○			○				○				
	Ignition key warning chime does not activate.		○		○					○			
	Seat belt warning chime does not activate.			○	○						○		
Rear defogger	Rear defogger does not activate, or go off after activating.				○							○	
Illumination	Interior lamp does not fade out after driver's door is closed.				○								○


# TIME CONTROL SYSTEM

## Trouble Diagnoses (Cont'd)

### PRELIMINARY CHECK


#### Preliminary check 1

- Light warning chime does not activate.




#### Preliminary check 2

- Ignition key warning chime does not activate.



#### Preliminary check 3

- Seat belt warning chime does not activate.



EL


IDX

# TIME CONTROL SYSTEM


## Trouble Diagnoses (Cont'd)

### MAIN POWER SUPPLY AND GROUND CIRCUIT CHECK

#### Main power supply



Terminals	Battery voltage existence condition		
	Ignition switch position		
	OFF	ACC	ON
⑨ - ⑮	Yes	Yes	Yes
⑤ - ⑮	No	No	Yes
② - ⑮	No	Yes	Yes



#### Ground circuit


Terminals	Continuity
⑮ - Ground	Yes



# TIME CONTROL SYSTEM

## Trouble Diagnoses (Cont'd)

### CIRCUIT DIAGRAM FOR QUICK PINPOINT CHECK





GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

# TIME CONTROL SYSTEM

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 1

**SYMPTOM: Intermittent wiper does not operate.**




**A**

**WIPER RELAY OUTPUT SIGNAL CHECK**

- 1) Turn ignition switch to "ACC".
- 2) Turn wiper switch to "INT" or "OFF".
- 3) Measure voltage between control unit harness terminals ① and ⑮.

Condition of wiper switch	Voltage [V]
OFF	Approx. 12
INT	Pointer swings from 0 to 12 every 3 to 23 seconds.





**B**

**INTERMITTENT SWITCH INPUT SIGNAL CHECK**

Measure voltage between control unit harness terminals ⑫ and ⑮.

Condition of wiper switch	Voltage [V]
OFF	Approx. 12
INT	0




# TIME CONTROL SYSTEM

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 2

**SYMPTOM: Intermittent time of wiper cannot be adjusted.**



**A**

**INTERMITTENT WIPER VOLUME INPUT SIGNAL CHECK**  
 Measure resistance between control unit harness terminals ⑭ and ⑮ while turning intermittent wiper volume.

Position of wiper knob	Resistance [ $\Omega$ ]
S	0
L	Approx. 1 k

OK → Replace control unit.

NG

Check intermittent wiper volume.  
 Check harness continuity between TCU and wiper switch.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR


ST

BF

HA

EL

IDX



### DIAGNOSTIC PROCEDURE 3

**SYMPTOM: Wiper and washer activate individually but not in combination.**


**A**

**WASHER SWITCH INPUT SIGNAL CHECK**  
 1) Turn ignition switch to "ACC".  
 2) Measure voltage between control unit harness terminals ⑬ and ⑮.

Condition of washer switch	Voltage [V]
OFF	Approx. 12
ON	0

NG → Check harness continuity between TCU and washer switch.

OK



**B**

**WIPER RELAY OUTPUT SIGNAL CHECK**  
 Measure voltage between control unit harness terminals ① and ⑮ after operating washer switch.  
**0V for approx. 3 seconds after washer has operated.**

NG → Replace control unit.

OK

Replace wiper relay.





# TIME CONTROL SYSTEM

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 4

**SYMPTOM: Light warning chime does not activate.**

- Perform "PRELIMINARY CHECK — Procedure 1" before referring to the following flow chart.







# TIME CONTROL SYSTEM

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 5

**SYMPTOM: Ignition key warning chime does not activate.**

- Perform "PRELIMINARY CHECK — Procedure 2" before referring to the following flow chart.



GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

IDX




# TIME CONTROL SYSTEM

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 6

**SYMPTOM: Seat belt warning chime does not activate.**

- Perform "PRELIMINARY CHECK — Procedure 3" before referring to the following flow chart.





# TIME CONTROL SYSTEM

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 7

**SYMPTOM: Rear defogger does not activate, or does not go off after activating.**



**A**

**REAR WINDOW DEFOGGER OUTPUT SIGNAL CHECK**  
Measure voltage between control unit harness terminals ④ and ⑮.

OK → Check rear window defogger relay. Check rear window defogger circuit.

Condition of defogger switch	Voltage [V]
OFF	Approx. 12
ON	0

NG

**B**

**REAR WINDOW DEFOGGER SWITCH INPUT SIGNAL CHECK**  
1) Disconnect TCU harness connector.  
2) Check continuity between control unit harness terminals ③ and ⑮.

NG → Check rear window defogger switch. Check harness continuity between TCU and rear window defogger switch.

Condition of defogger switch	Continuity
OFF	No
ON	Yes

OK

Replace control unit.


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

# TIME CONTROL SYSTEM

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 8

**SYMPTOM:** Interior lamp does not fade out after driver's door is closed.




**A**

**DOOR SWITCH INPUT SIGNAL CHECK**  
Measure voltage between control unit harness terminals ⑱ and ⑮.

Condition of driver's door	Voltage [V]
Closed	Approx. 12
Open	0

NG → Check door switch.  
Check harness continuity between TCU and door switch.



OK

**B**

**INTERIOR LAMP SIGNAL CHECK**  
Measure voltage between control unit harness terminals ⑳ and ⑮.

Condition of driver's door	Voltage [V]
Closed	0 → Approx. 12
Open	0

OK → Check interior lamp and harness between TCU and interior lamp.

NG → Replace TCU.



## Front Wiper and Washer/System Description

### WIPER OPERATION

The wiper switch is controlled by a lever built into the combination switch.

There are three wiper switch positions:

- LO speed
- HI speed
- INT (Intermittent)

With the ignition switch in the ACC or ON position, power is supplied

- through 20A fuse (No. 6), located in the fuse block
- to wiper motor terminal 4 and
- to wiper relay terminal 1.

### Low and high speed wiper operation

Ground is supplied to wiper switch terminal 17 through body grounds E10 and E33.

When the wiper switch is placed in the LO position, ground is supplied

- through terminal 14 of the wiper switch
- to wiper motor terminal 2.

With power and ground supplied, the wiper motor operates at low speed.

When the wiper switch is placed in the HI position, ground is supplied

- through terminal 16 of the wiper switch
- to wiper motor terminal 3.

With power and ground supplied, the wiper motor operates at high speed.

### Auto stop operation

When the wiper switch is placed in the OFF position, the wiper motor will continue to operate until the wiper arms reach the base of the windshield.

When wiper arms are not located at base of windshield with wiper switch OFF, ground is provided

- from terminal 14 of the wiper switch
- to wiper motor terminal 2, in order to continue wiper motor operation at low speed.

Ground is also supplied

- through terminal 13 of the wiper switch
- to wiper relay terminal 3
- through terminal 4 of the wiper relay
- to wiper motor terminal 5
- through terminal 6 of the wiper motor, and
- through body grounds M1 and M80.

When wiper arms reach base of windshield, wiper motor terminals 5 and 4 are connected instead of terminals 5 and 6. Wiper motor will then stop wiper arms at the PARK position.

### Intermittent operation

The wiper motor operates the wiper arms one time at low speed at a set interval of approximately 1 to 20 seconds. This feature is controlled by the time control unit.

When the wiper switch is placed in the INT position, ground is supplied

- to time control unit terminal 12
- from wiper switch terminal 15
- through body grounds E10 and E33.

The desired interval time is input

- to time control unit terminal 14
- from wiper switch terminal 19.

Based on these two inputs, an intermittent ground is supplied

- to wiper relay terminal 2
- from time control unit terminal 1.

With power and ground supplied, the wiper relay is activated.

When activated, an intermittent ground is supplied

- to wiper motor terminal 2
- through the wiper switch terminal 14
- to wiper switch terminal 13

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

IDX

## WIPER AND WASHER

### Front Wiper and Washer/System Description (Cont'd)

- through wiper relay terminal ③
- to wiper relay terminal ⑤
- through body grounds E10 and E33.

Wiper motor operates at desired low speeds with time control unit terminal ① grounded.

#### WASHER OPERATION

With the ignition switch in the ACC or ON position, power is supplied

- through 20A fuse (No. ⑥ , located in the fuse block)
- to washer motor terminal ①.

When the lever is pulled to the WASH position, ground is supplied

- to washer motor terminal ②, and
- to time control unit terminal ⑬
- from terminal ⑩ of the wiper switch
- through terminal ⑰ of the wiper switch, and
- through body grounds E10 and E33.


With power and ground supplied, the washer motor operates.

Wiper motor will then operate at low speed for approximately 3 seconds to clean windshield. This feature is controlled by the time control unit in the same manner as the intermittent operation.

# WIPER AND WASHER

## Front Wiper and Washer/Wiring Diagram — WIPER —

EL-WIPER-01




GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA

Refer to last page (Foldout page).  
M5, E102

EL

IDX



# WIPER AND WASHER

## Installation


1. Turn on wiper switch to operate wiper motor and then turn it "OFF" (Auto Stop).
  2. Lift the blade up and then set it down onto glass surface. Set the blade center to clearance "C" or "D" immediately before tightening nut.
  3. Eject washer fluid. Turn on wiper switch to operate wiper motor and then turn it "OFF".
  4. Ensure that wiper blades stop within clearance "C" or "D".
- Tighten windshield wiper arm nuts to specified torque.

### Front wiper:

17 - 23 N·m (1.7 - 2.3 kg-m, 12 - 17 ft-lb)

## Front wiper and washer


### Washer nozzle adjustment



All the diameters of these circles are less than 80 (3.15).

*1:	405 (15.94)
*2:	220 (8.66)
*3:	385 (15.16)
*4:	170 (6.69)
*5:	115 (4.53)
*6:	180 (7.09)
*7:	225 (8.86)
*8:	420 (16.54)


Unit: mm (in)



MEL417A

# WIPER AND WASHER

## Installation (Cont'd)



- Before reinstalling wiper arm, clean up the pivot area as illustrated. This will reduce possibility of wiper arm looseness.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR


ST

BF

HA

EL


IDX



## Washer Nozzle Adjustment

- Adjust washer nozzle with adjusting tool (Tool number: J36126) as shown in the figure at left.


Before attempting to turn the nozzle, gently tap the end of the tool to free the nozzle. This will prevent "rounding out" the small female square in the center of the nozzle.



## Check Valve

- A check valve is provided in the washer fluid line. Be careful not to connect check valve to washer tube in the wrong direction.


## Washer Tube Layout



# HORN, CIGARETTE LIGHTER AND CLOCK

## Wiring Diagram — HORN —


EL-HORN-01



Refer to 'EL-POWER'.

Refer to last page (Foldout page).

M5, E102, E60



# REAR WINDOW DEFOGGER

## System Description

The rear window defogger system is controlled by the time control unit. The rear window defogger operates only for approximately 15 minutes.

Power is supplied at all times

- to rear window defogger relay terminal ③
- through 20A fuse (No. ① , located in the fuse block) and
- to rear window defogger relay terminal ⑥
- through 20A fuse (No. ② , located in the fuse block).

With the ignition switch in the ON or START position, power is supplied

- to the rear window defogger relay terminal ① .

Ground is supplied to terminal ② of the rear window defogger switch through body grounds (M1) and (M60).

When the rear window defogger switch is activated, ground is supplied

- through terminal ① of the rear window defogger switch
- to time control unit terminal ③ .

Terminal ④ of the time control unit then supplies ground to the rear window defogger relay terminal ② .

With power and ground supplied, the rear window defogger relay is energized.

Power is supplied

- through terminals ⑤ and ⑦ of the rear window defogger relay
- to condenser terminal ①
- through terminal ② of the condenser
- to the rear window defogger.

The rear window defogger has an independent ground.

With power and ground supplied, the rear window defogger filaments heat and defog the rear window.

When the system is activated, the rear window defogger indicator on the rear window defogger switch illuminates.

Power is supplied

- to terminal ③ of the combination meter
- from terminal ⑤ and ⑦ of the rear window defogger relay.

Terminal ②⑦ of the combination meter is grounded through body grounds (M1) and (M60).

### With door mirror defogger models

Door mirror defogger is connected parallel to rear window defogger.

With rear window defogger switch ON, time control unit activates rear window defogger relay. Ground is supplied

- to door mirror defogger relay terminal ②
- through time control unit terminal ④ .

Then door mirror defogger relay is energized power is supplied to door mirror defogger. Refer to "Door Mirror" in BF section.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA



EL

IDX

# REAR WINDOW DEFOGGER





## Wiring Diagram — DEF —

EL-DEF-01





# REAR WINDOW DEFOGGER



## Filament Check

1. Attach probe circuit tester (in volt range) to middle portion of each filament.

- When measuring voltage, wrap tin foil around the top of the negative probe. Then press the foil against the wire with your finger.

2. If a filament is burned out, circuit tester registers 0 or 12 volts.

3. To locate a burned out point, move probe to left and right along filament. Tester needle will swing abruptly when probe passes the point.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

IDX

# REAR WINDOW DEFOGGER

## Filament Repair

### REPAIR EQUIPMENT

1. Conductive silver composition (Dupont No. 4817 or equivalent)
2. Ruler 30 cm (11.8 in) long
3. Drawing pen
4. Heat gun
5. Alcohol
6. Cloth

### REPAIRING PROCEDURE

1. Wipe broken heat wire and its surrounding area clean with a cloth dampened in alcohol.
2. Apply a small amount of conductive silver composition to tip of drawing pen.




**Shake silver composition container before use.**

3. Place ruler on glass along broken line. Deposit conductive silver composition on break with drawing pen. Slightly overlap existing heat wire on both sides [preferably 5 mm (0.20 in)] of the break.

4. After repair has been completed, check repaired wire for continuity. This check should be conducted 10 minutes after silver composition is deposited.

**Do not touch repaired area while test is being conducted.**

5. Apply a constant stream of hot air directly to the repaired area for approximately 20 minutes with a heat gun. A minimum distance of 3 cm (1.2 in) should be kept between repaired area and hot air outlet. If a heat gun is not available, let the repaired area dry for 24 hours.



# AUDIO AND POWER ANTENNA

## Audio/System Description

Refer to Owner's Manual for audio system operating instructions.

Power is supplied at all times

- through 10A fuse (No. 25 , located in the fuse block)
- to radio terminal 6
- through 15A fuse (No. 14 , located in the fuse block)
- to front amp. terminal 10 and
- to rear amp. terminal 10 .

GI

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse (No. 9 , located in the fuse block)
- to radio terminal 10 .

MA

EM

Ground is supplied through the case of the radio.

LC

When the radio POWER button is pressed, audio signals are supplied

- through radio terminals 1 , 2 , 3 , 4 , 12 , 13 , 14 , 15 and 16
- to terminals 1 , 2 , 3 , 4 and 12 of the rear amp. and terminals 1 , 2 , 3 , 4 and 12 of the front amp.
- to tweeters and the front and rear speakers through terminals 5 , 6 , 7 , 8 , 13 , 14 , 15 and 16 of the front amp. and terminals 5 , 6 , 7 and 8 of the rear amp.

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF




HA

**EL**

IDX



Audio/Wiring Diagram — AUDIO —

EL-AUDIO-01



# AUDIO AND POWER ANTENNA

## Audio/Wiring Diagram — AUDIO — (Cont'd)



GI  
 MA  
 EM  
 LC  
 EC  
 FE  
 CL  
 MT  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
**EL**  
 IDX

## Power Antenna/System Description

Power is supplied at all times

- through 10A fuse (No. 25 , located in the fuse block)
- to power antenna terminal ①.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse (No. 9 , located in the fuse block)
- to radio terminal 10 .

Ground is supplied to the power antenna timer terminal ⑤ through body ground M101 and M165.

When the radio is turned ON, battery positive voltage is supplied

- through radio terminal ⑤
- to power antenna terminal ②.

Power is supplied

- to power antenna motor terminal ⑥
- through power antenna timer terminal ⑥ .

Ground is supplied

- to power antenna motor terminal ⑦
- through power antenna timer terminal ⑦ .

The antenna raises and is held in the extended position.

When the radio is turned to the OFF position, battery positive voltage is interrupted

- from radio terminal ⑤
- to power antenna terminal ②.

Power is supplied

- to power antenna motor terminal ⑦
- through power antenna timer terminal ⑦ .

Ground is supplied


- to power antenna motor terminal ⑥
- through power antenna timer terminal ⑥ .

The antenna retracts.

# AUDIO AND POWER ANTENNA

## Power Antenna/Wiring Diagram — P/ANT —

EL-P/ANT-01



GI  
 MA  
 EM  
 LC  
 EC  
 FE  
 CL  
 MT  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
 EL  
 IDX



# AUDIO AND POWER ANTENNA

## Trouble Diagnoses

Symptom	Possible causes	Repair order
Radio inoperative (no digital display and no sound from speakers).	<ol style="list-style-type: none"> <li>10A fuse</li> <li>Poor radio case ground</li> <li>Radio</li> </ol>	<ol style="list-style-type: none"> <li>Check 10A fuse (No. <b>9</b>), located in fuse block). Turn ignition switch ON and verify battery positive voltage is present at terminal <b>10</b> of radio.</li> <li>Check radio case ground.</li> <li>Remove radio for repair.</li> </ol>
Radio controls are operational, but no sound is heard from any speaker.	<ol style="list-style-type: none"> <li>15A fuse</li> <li>Radio output</li> <li>Radio</li> </ol>	<ol style="list-style-type: none"> <li>Check 15A fuse (No. <b>14</b>), located in fuse block). Verify that battery positive voltage is present at terminal <b>10</b> of front and rear speaker amps.</li> <li>Check radio output voltages.</li> <li>Remove radio for repair.</li> </ol>
Radio presets are lost when ignition switch is turned OFF.	<ol style="list-style-type: none"> <li>10A fuse</li> <li>Radio</li> </ol>	<ol style="list-style-type: none"> <li>Check 10A fuse (No. <b>25</b>), located in fuse block) and verify battery positive voltage is present at terminal <b>6</b> of radio.</li> <li>Remove radio for repair.</li> </ol>
Rear speakers are inoperative.	<ol style="list-style-type: none"> <li>Rear speaker amp. 15A fuse</li> <li>Poor rear amp. case ground</li> <li>Rear speaker amp.</li> <li>Rear speaker amp. circuit</li> <li>Radio</li> </ol>	<ol style="list-style-type: none"> <li>Check 15A fuse on amp.</li> <li>Check rear amp. case ground.</li> <li>Check rear speaker amp. voltages.</li> <li>Check wires for open or short between radio, rear speaker amp. and rear speakers.</li> <li>Remove radio for repair.</li> </ol>
Front speakers are inoperative.	<ol style="list-style-type: none"> <li>Front speaker amp. 10A fuse</li> <li>Poor front amp. case ground</li> <li>Front speaker amp.</li> <li>Front speaker amp. circuit</li> <li>Radio</li> </ol>	<ol style="list-style-type: none"> <li>Check 10A fuse on amp.</li> <li>Check front amp. case ground.</li> <li>Check front speaker amp. voltages.</li> <li>Check wires for open or short between radio, front speaker amp. and front speakers.</li> <li>Remove radio for repair.</li> </ol>
Individual speaker is noisy or inoperative.	<ol style="list-style-type: none"> <li>Speaker</li> <li>Radio/amp. output</li> <li>Speaker circuit</li> <li>Radio</li> </ol>	<ol style="list-style-type: none"> <li>Check speaker.</li> <li>Check radio/amp. output voltages.</li> <li>Check wires for open or short between radio/amp. and speaker.</li> <li>Remove radio for repair.</li> </ol>
AM stations are weak or noisy (FM stations OK).	<ol style="list-style-type: none"> <li>Antenna</li> <li>Poor radio ground</li> <li>Radio</li> </ol>	<ol style="list-style-type: none"> <li>Check antenna.</li> <li>Check radio ground.</li> <li>Remove radio for repair.</li> </ol>
FM stations are weak or noisy (AM stations OK).	<ol style="list-style-type: none"> <li>Window antenna</li> <li>Radio</li> </ol>	<ol style="list-style-type: none"> <li>Check window antenna.</li> <li>Remove radio for repair.</li> </ol>
Radio generates noise in AM and FM modes with engine running.	<ol style="list-style-type: none"> <li>Poor radio ground</li> <li>Loose or missing ground bonding straps</li> <li>Ignition condenser or rear window defogger noise suppressor condenser</li> <li>Alternator</li> <li>Ignition coil or secondary wiring</li> <li>Radio</li> </ol>	<ol style="list-style-type: none"> <li>Check radio ground.</li> <li>Check ground bonding straps.</li> <li>Replace ignition condenser or rear window defogger noise suppressor condenser.</li> <li>Check alternator.</li> <li>Check ignition coil and secondary wiring.</li> <li>Remove radio for repair.</li> </ol>
Radio generates noise in AM and FM modes with accessories on (switch pops and motor noise).	<ol style="list-style-type: none"> <li>Poor radio ground</li> <li>Antenna</li> <li>Accessory ground</li> <li>Faulty accessory</li> </ol>	<ol style="list-style-type: none"> <li>Check radio ground.</li> <li>Check antenna.</li> <li>Check accessory ground.</li> <li>Replace accessory.</li> </ol>
Power antenna does not operate.	<ol style="list-style-type: none"> <li>10A fuse</li> <li>10A fuse</li> <li>Radio signal</li> <li>Grounds <b>M101</b> and <b>M165</b></li> <li>Power antenna motor</li> <li>Open in power antenna motor circuit</li> </ol>	<ol style="list-style-type: none"> <li>Check 10A fuse (No. <b>25</b>), located in fuse block). Verify that battery positive voltage is present at terminal <b>1</b> of power antenna timer.</li> <li>Check 10A fuse (No. <b>9</b>), located in fuse block). Turn ignition switch ON and verify that battery positive voltage is present at terminal <b>10</b> of radio.</li> <li>Turn ignition switch and radio ON. Verify that battery positive voltage is present at terminal <b>2</b> of power antenna timer.</li> <li>Check grounds <b>M101</b> and <b>M165</b>.</li> <li>Check power antenna motor.</li> <li>Check L/R and L/B wires between power antenna timer and power antenna motor.</li> </ol>



# AUDIO AND POWER ANTENNA

## Trouble Diagnoses (Cont'd)

### SPEAKER INSPECTION

1. Disconnect speaker harness connector.
2. Measure the resistance between speaker terminals ① and ②.
  - The resistance should be 2-4  $\Omega$ .
3. Using jumper wires, momentarily connect a 9V battery between speaker terminals ① and ②.
  - A momentary hum or pop should be heard.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

IDX

### ANTENNA INSPECTION


1. Using a jumper wire, clip an auxiliary ground between antenna and body.
  - If reception improves, check antenna ground (at body surface).
  - If reception does not improve, check main feeder cable for short circuit or open circuit.

### RADIO AND AMP INSPECTION

All voltage inspections are made with:


- Ignition switch ON or ACC
- Radio ON
- Radio and amps. connected (If radio or amp. is removed for inspection, supply a ground to the case using a jumper wire.)

### Location of Antenna



MEL419A



# AUDIO AND POWER ANTENNA



## Antenna Rod Replacement

### REMOVAL

1. Remove antenna nut and antenna base.
2. Withdraw antenna rod while raising it by operating antenna motor.



### INSTALLATION

1. Lower antenna rod by operating antenna motor.
2. Insert gear section of antenna rope into place with it facing toward antenna motor.
3. As soon as antenna rope is wound on antenna motor, stop antenna motor. Insert antenna rod lower end into antenna motor pipe.
4. Retract antenna rod completely by operating antenna motor.
5. Install antenna nut and base.

## Window Antenna Repair

### ELEMENT CHECK

1. Attach probe circuit tester (in ohm range) to antenna terminal on each side.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR


ST

BF


HA

**EL**


IDX



2. If an element is broken, no continuity will exist.



3. To locate broken point, move probe to left and right along element. Tester needle will swing abruptly when probe passes the point.



### ELEMENT REPAIR

Refer to REAR WINDOW DEFOGGER "Filament Repair" (EL-106).

## System Description

Refer to Owner's Manual for ASCD operating instructions.

When the ignition switch is in the ON or START position, power is supplied

- through 10A fuse (No. 26), located in the fuse block)
- to ASCD main switch terminal ① and
- to ASCD hold relay terminal ⑤.

When ASCD main switch is in the ON position, power is supplied

- from terminal ② of the ASCD main switch
- to ASCD control unit terminal ④ and
- from terminal ③ of the ASCD main switch
- to ASCD hold relay terminal ②.

Ground is supplied

- to ASCD hold relay terminal ①
- through body grounds E10 and E33.

With power and ground supplied, the ASCD hold relay is activated, and power is supplied

- from terminal ③ of the ASCD hold relay
- to ASCD control unit terminal ④ and
- to ASCD clutch switch terminal ① (M/T models) or
- to inhibitor relay terminal ④ (A/T models).

Power remains supplied to ASCD control unit terminal ④ when the ASCD main switch is released to the N (neutral) position.

Ground is supplied

- to ASCD control unit terminal ③
- through body grounds M1 and M60.

## Inputs

At this point, the system is ready to activate or deactivate, based on inputs from the following:

- speedometer in the combination meter
- stop lamp switch
- ASCD steering switch
- inhibitor relay (A/T models)
- ASCD clutch switch (M/T models)
- ASCD cancel switch.

A vehicle speed input is supplied

- to ASCD control unit terminal ⑦
- from terminal 15 of the combination meter.

Power is supplied at all times

- to stop lamp switch terminal ①
- through 20A fuse (No. 24), located in the fuse block).

When the brake pedal is depressed, power is supplied

- from terminal ② of the stop lamp switch
- to ASCD control unit terminal ⑪.

Power is supplied at all times

- through 10A fuse (No. 18), located in the fusible link and fuse box)
- to horn relay terminal ②
- through terminal ① of the horn relay
- to ASCD steering switch terminal ①.

When the SET/COAST switch is depressed, power is supplied

- from terminal ② of the ASCD steering switch
- to ASCD control unit terminal ②.

When the RESUME/ACCEL switch is depressed, power is supplied

- from terminal ③ of the ASCD steering switch
- to ASCD control unit terminal ①.

When the CANCEL switch is depressed, power is supplied

- to ASCD control unit terminals ① and ②.

When the system is activated, power is supplied

- to ASCD control unit terminal ⑤.

Power is interrupted when

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## System Description (Cont'd)

- the shift lever is placed in P or N (A/T models)
- the clutch pedal is depressed (M/T models) or
- the brake pedal is depressed.

### Outputs

The ASCD actuator controls the throttle drum via the ASCD wire based on inputs from the ASCD control unit. The ASCD actuator consists of a vacuum motor, an air valve, and a release valve.

Power is supplied

- from terminal ⑧ of the ASCD control unit
- to ASCD actuator terminal ①.

Ground is supplied to the vacuum motor

- from terminal ⑨ of the ASCD control unit
- to ASCD actuator terminal ④.

Ground is supplied to the air valve

- from terminal ⑩ of the ASCD control unit
- to ASCD actuator terminal ②.

Ground is supplied to the release valve

- from terminal ⑭ of the ASCD control unit
- to ASCD actuator terminal ③.

When the system is activated, power is supplied

- from terminal ⑬ of the ASCD control unit
- to combination meter terminal ⑦ and
- to A/T control unit terminal ⑳ (A/T models).

Ground is supplied

- to combination meter terminal ⑲
- through body grounds ①① and ①②.

With power and ground supplied, the CRUISE indicator lamp illuminates.

When the RESUME/ACCEL switch is depressed on A/T models, a signal is sent

- from terminal ⑫ of the ASCD control unit
- to A/T control unit terminal ⑳.

When this occurs, the A/T control unit cancels overdrive.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF







HA

EL

IDX

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)



## Component Parts and Harness Connector Location



# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Wiring Diagram — ASCD —

EL-ASCD-01




Refer to last page (Foldout page).

(M5) (E102)

GI  
 MA  
 EM  
 LC  
 EC  
 FE  
 CL  
 MT  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
 EL  
 IDX


# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Wiring Diagram — ASCD — (Cont'd)



Refer to last page (Foldout page).

- (M5), (E102)
- (E59)
- (E61)






# AUTOMATIC SPEED CONTROL DEVICE (ASCD)



## Wiring Diagram — ASCD — (Cont'd)

EL-ASCD-03



GI  
 MA  
 EM  
 LC  
 EC  
 FE  
 CL  
 MT  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF

Refer to last page (Foldout page).  
 (M5), (E102)





HA  
 EL  
 IDX

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Wiring Diagram — ASCD — (Cont'd)

EL-ASCD-04





Refer to last page (Foldout page).  
 (M5), (E102)  
 (M74)

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Wiring Diagram — ASCD — (Cont'd)

EL-ASCD-05



(M16)  
B



(E35)  
GY

Refer to last page (Foldout page).

(M5) , (E102)

GI  
 MA  
 EM  
 LC  
 EC  
 FE  
 CL  
 MT  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
 EL  
 IDX

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Trouble Diagnoses


### SYMPTOM CHART

PROCEDURE	Diagnostic Procedure								Electrical Components Inspection							
	EL-126	EL-128	EL-128	EL-129	EL-130	EL-131	EL-132	EL-133	EL-134	EL-135	EL-135	EL-136	EL-136	EL-136	EL-136	
REFERENCE PAGE																
SYMPTOM	Diagnostic Procedure 1	Diagnostic Procedure 2	Diagnostic Procedure 3	Diagnostic Procedure 4	Diagnostic Procedure 5	Diagnostic Procedure 6	Diagnostic Procedure 7	Diagnostic Procedure 8	ASCD wire adjustment	ASCD actuator/ASCD pump	ASCD main switch	ASCD steering switch	ASCD cancel switch and stop lamp switch	ASCD clutch switch (For M/T models)	Inhibitor switch (For A/T models)	Vehicle speed sensor
ASCD control unit cannot be set properly.	<input type="radio"/>									<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Engine hunts.		<input type="radio"/>							<input type="radio"/>	<input type="radio"/>						
Large difference between set speed and actual vehicle speed.			<input type="radio"/>						<input type="radio"/>	<input type="radio"/>						
Deceleration is greatest immediately after ASCD has been set.				<input type="radio"/>					<input type="radio"/>	<input type="radio"/>						
ACCEL switch will not operate.	<input type="radio"/>				<input type="radio"/>							<input type="radio"/>				
RESUME switch will not operate.	<input type="radio"/>					<input type="radio"/>						<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		
Set speed cannot be cancelled.							<input type="radio"/>		<input type="radio"/>	<input type="radio"/>			<input type="radio"/>	<input type="radio"/>		
"CRUISE" indicator lamp blinks.								<input type="radio"/>		<input type="radio"/>		<input type="radio"/>	<input type="radio"/>			

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Trouble Diagnoses (Cont'd)

### CIRCUIT DIAGRAM FOR QUICK PINPOINT CHECK







GI  
 MA  
 EM  
 LC  
 EC  
 FE  
 CL  
 MT  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
**EL**  
 IDX

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 1

**SYMPTOM: ASCD control cannot be set.**



Turn ASCD main switch "OFF" and "ON" to make sure indicator illuminates.

**A** CHECK POWER SUPPLY FOR ASCD MAIN SWITCH.  
1. Disconnect main switch harness connector.  
2. Do approx. 12 volts exist between main switch harness terminal ① and body ground?

No → Check fuse and harness.  
Yes →

CHECK ASCD MAIN SWITCH.  
Refer to "Electrical Components Inspection" (EL-135).  
CHECK ASCD HOLD RELAY.

**B** CHECK POWER SUPPLY CIRCUIT FOR ASCD CONTROL UNIT.  
1. Turn ASCD main switch "ON".  
2. Check voltage between control unit harness terminals ④ and ③.  
**Battery voltage should exist.**

NG → Check continuity between control unit harness terminal ④ and ASCD hold relay.

**C** CHECK CUT-OFF CIRCUIT FOR ASCD CONTROL UNIT.  
Check voltage between control unit harness terminals ⑤ and ③.  
**Battery voltage should exist.**

NG → CHECK ASCD CANCEL SWITCH, ASCD CLUTCH SWITCH (M/T models) AND INHIBITOR SWITCH (A/T models).  
Refer to "Electrical Components Inspection" (EL-136).  
CHECK INHIBITOR RELAY (A/T models) AND THEFT WARNING RELAY.

**D** CHECK SET/COAST SWITCH CIRCUIT FOR ASCD CONTROL UNIT.  
1. Push and hold SET/COAST button on ASCD steering switch.  
2. Check voltage between control unit harness terminals ② and ③.  
**Battery voltage should exist.**



NG → Does horn work?  
No → Check fuse and horn relay.  
Yes →

CHECK ASCD STEERING SWITCH.  
Refer to "Electrical Components Inspection" (EL-136).

OK →  
Ⓐ (Next page)

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Trouble Diagnoses (Cont'd)



**E**

**CHECK VEHICLE SPEED SENSOR CIRCUIT.**

1. Apply wheel chocks and jack up front of vehicle.
2. Connect voltmeter between control unit harness terminals ⑦ and ③.
3. Slowly turn front wheel.
4. Check deflection of voltmeter pointer.

NG → **CHECK VEHICLE SPEED SENSOR.**  
Refer to "Electrical Components Inspection".

OK →

**CHECK ASCD ACTUATOR/ASCD PUMP.**  
Refer to "Electrical Components Inspection" (EL-135).

NG → **Replace ASCD actuator/ASC pump.**

OK →

**F**

**CHECK ASCD ACTUATOR/ASCD PUMP CIRCUIT.**

1. Check voltage between control unit harness terminals ⑧ and ③.  
**Voltage is 0V.**
2. Disconnect ASCD control unit connector.
3. Measure resistance between control unit harness terminals ⑧ and ⑨, ⑩, ⑭.

NG → **Repair short or open circuit in ASCD actuator/ASC pump harness.**

Terminals	Resistance [Ω]
⑧ - ⑨	Approx. 8 - 45
⑧ - ⑩	Approx. 65
⑧ - ⑭	Approx. 65

OK → **Replace ASCD control unit.**


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Trouble Diagnoses (Cont'd)


### DIAGNOSTIC PROCEDURE 2

**SYMPTOM: Engine hunts.**



### DIAGNOSTIC PROCEDURE 3

**SYMPTOM: Large difference between set vehicle speed and actual speed.**






# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 4

**SYMPTOM:** Deceleration is greatest immediately after ASCD has been set.



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA

EL





IDX

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 5

**SYMPTOM: ACCEL switch will not operate.**









# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 6

**SYMPTOM: RESUME switch will not operate.**




GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 7

**SYMPTOM: Set speed cannot be cancelled.**



**A**


CHECK ASCD CANCEL, CLUTCH, INHIBITOR SWITCH CIRCUIT.

1. Turn ASCD main switch "ON".
2. Check voltage between control unit harness terminals ⑤ and ③.

NG → CHECK ASCD CANCEL, CLUTCH, and INHIBITOR SWITCH.  
Refer to "Electrical Components Inspection" (EL-136).

Conditions			Voltage [V]
M/T	ASCD cancel switch	De-pressed	0
		Released	Approx. 12
	ASCD clutch switch	De-pressed	0
		Released	Approx. 12
A/T	A/T shift lever position is at any position except N or P.		Approx. 12
	A/T shift lever position is at N or P.		0

OK



**B**

CHECK STOP LAMP SWITCH CIRCUIT.  
Check voltage between control unit harness terminals ⑪ and ③.

NG → CHECK STOP LAMP SWITCH.  
Refer to "Electrical Components Inspection" (EL-136).

Condition		Voltage [V]
Stop lamp switch	Depressed	Approx. 12
	Released	0

OK

Check ASCD wire moves smoothly.

NG → Replace ASCD wire.

OK

CHECK ASCD ACTUATOR/ASCD PUMP.  
Refer to "Electrical Components Inspection" (EL-135).

NG → Replace ASCD actuator/ASCD pump.

OK



Replace ASCD control unit.

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 8

SYMPTOM: "CRUISE" indicator lamp blinks.




Terminals	Resistance [Ω]	
⑧	⑨	Approx. 8 - 45
	⑩	Approx. 65
	⑭	Approx. 65

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

## AUTOMATIC SPEED CONTROL DEVICE (ASCD)

### Trouble Diagnoses (Cont'd)

#### ASCD WIRE ADJUSTMENT



#### CAUTION:

- Be careful not to twist ASCD wire when removing it.
- Do not tense ASCD wire excessively during adjustment.

Adjust the tension of ASCD wire in the following manner.

- (1) Loosen lock nut and adjusting nut.
- (2) Make sure that accelerator wire is properly adjusted. (Refer to FE section, "ACCELERATOR CONTROL SYSTEM".)
- (3) Tighten adjusting nut until throttle drum just starts to move.
- (4) Loosen adjusting nut again 1/2 to 1 turn.
- (5) Tighten lock nut.







# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Trouble Diagnoses (Cont'd)

### ELECTRICAL COMPONENTS INSPECTION

#### ASCD actuator/ASCD pump

1. Disconnect ASCD actuator/ASCD pump connector.
2. Check ASCD actuator/ASCD pump operations as shown.



#### ASCD main switch

Check continuity between terminals by pushing switch to each position.

Switch position	Terminals					
	1	2	3	4	5	6
ON	○	○	○	⊕		
N		○	○	⊕		ILL.
OFF						⊕


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)


## Trouble Diagnoses (Cont'd)

### ASCD steering switch

Check continuity between terminals by pushing each button.




Button	Terminal		
	1	2	3
SET/COAST	○—○		
RESUME/ACCEL	○—○		○—○
CANCEL	○—○	▶—○	
	○—○	▶—○	○—○



### ASCD cancel switch and stop lamp switch


Condition	Continuity	
	ASCD cancel switch	Stop lamp switch
When brake pedal is depressed	No	Yes
When brake pedal is released	Yes	No

Check each switch after adjusting brake pedal — refer to BR section.




### Clutch switch (For M/T models)

Condition	Continuity
When clutch pedal is depressed	No
When clutch pedal is released	Yes



### Inhibitor switch (For A/T models)

Condition	Continuity
When shift lever position is "N" or "P"	Yes
When shift lever position is any position except "N" or "P"	No



### Vehicle speed sensor

1. Remove vehicle speed sensor from transaxle.
2. Turn vehicle speed sensor pinion quickly and measure voltage across (a) and (b).





## System Description

Refer to Owner's Manual for theft warning system operating instructions.

Power is supplied at all times

- through 30A fusible link (letter **d**), located in the fusible link and fuse box)
- to ignition switch terminal **1**.

With the ignition switch in the START position, power is supplied

- from terminal **4** of the ignition switch
- to clutch interlock relay terminal **2** (M/T models for U.S.A.) or 
- to theft warning relay-2 terminal **3** (M/T models for Canada) or 
- to inhibitor relay terminal **7** (A/T models).

With the ignition switch in the START position, power is supplied

- through 10A fuse (No. **16**), located in the fuse block)
- to theft warning relay-2 terminal **3** (M/T models for U.S.A.).

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse (No. **7**), located in the fuse block)
- to theft warning relay-2 terminal **1** and
- to theft warning relay-2 terminal **3** (A/T models).

Power is supplied at all times

- through 10A fuse (No. **25**), located in the fuse block)
- to theft warning control unit terminal **1** and
- to security indicator lamp terminal **1**.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse (No. **10**), located in the fuse block)
- to theft warning control unit terminal **3**.

Ground is supplied

- to theft warning control unit terminal **16**
- through body grounds **(M1)** and **(M60)**.

### THEFT WARNING SYSTEM ACTIVATION (Without key or remote controller used to lock front doors)

The operation of the theft warning system is controlled by the doors, hood and trunk lid.

To activate the theft warning system, the key must be removed from the ignition switch and the theft warning control unit must receive signals indicating the doors, hood and trunk are closed and the doors are locked.

When a door is open, theft warning control unit terminal **5** receives a ground signal from each door switch.

When a door is unlocked, theft warning control unit terminal **9** receives a ground signal

- from terminal **2** of the door lock actuator (door unlock sensor)
- through body grounds **(M1)** and **(M60)** for the front doors and
- through body grounds **(M101)** and **(M165)** for the rear doors.

When the hood is open, theft warning control unit terminal **15** receives a ground signal

- from terminal **1** of the hood switch
- through body grounds **(E10)** and **(E33)**.

When the trunk lid is open, theft warning control unit terminal **14** receives a ground signal

- from terminal **1** of the trunk room lamp switch
- through body grounds **(M101)** and **(M165)**.

If none of the described conditions exist, the theft warning system will activate automatically.

### THEFT WARNING SYSTEM ACTIVATION (With key used to lock doors)

If the rear doors are locked and the key is used to lock either front door, theft warning control unit terminal **7** receives a ground signal

- from terminal **1** of the front door key cylinder switch LH or terminal **2** of the front door key cylinder switch RH
- through body grounds **(M1)** and **(M60)**.

If this signal is received by the theft warning control unit, the theft warning system will activate automatically.

# THEFT WARNING SYSTEM

## System Description (Cont'd)

### THEFT WARNING SYSTEM ACTIVATION (With remote controller used to lock doors)

The remote controller used to lock all doors, theft warning control unit terminal ⑦ receives a ground signal

- from terminal ⑩ of the multi-remote control unit.

If this signal is received by the theft warning control unit, the theft warning system will activate automatically.

Once the theft warning system has been activated, theft warning control unit terminal ② supplies ground to terminal ⑨ of the security indicator lamp.

The security indicator lamp will illuminate for approximately 30 seconds and then go out.

### THEFT WARNING SYSTEM OPERATION

The theft warning system is triggered by

- opening a door or the trunk lid without using the key
- opening the hood
- tampering with the key cylinder in the door or trunk lid.

Once the theft warning system has been activated, if the theft warning control unit receives a ground signal at terminal ⑤, terminal ⑭ or terminal ⑮ (as described under THEFT WARNING SYSTEM ACTIVATION), the theft warning system will be triggered. Also, when one of the following signals is received at the theft warning control unit, the system will be triggered. The headlamps flash and the horn sounds intermittently, and the starting system is interrupted.

When a door key cylinder switch has been tampered with, theft warning control unit terminal ⑥ receives a ground signal

- from terminal ③ of the front door key cylinder switch LH or RH
- through body grounds (M1) and (M6).

When the trunk lid key cylinder switch has been tampered with, theft warning control unit terminal ⑥ receives a ground signal

- from terminal ② of the trunk lid key cylinder switch
- through body grounds (M10) and (M16).

If the theft warning system is triggered, ground is supplied

- from terminal ④ of the theft warning control unit
- to theft warning relay-2 terminal ②.

With power and ground supplied, power to the clutch interlock relay (M/T models for U.S.A.) or inhibitor relay (A/T models) or starter motor (M/T models for Canada) is interrupted. The starter motor will not crank and the engine will not start.

Power is supplied at all times

- through 15A fuse (No. 18), located in fusible link and fuse box
- to theft warning horn relay terminals ① and ③,
- to theft warning relay-1 terminal ① and
- to horn relay terminal ②.

Power is supplied at all times

- through 15A fuse (No. 27), located in fusible link and fuse box
- to theft warning relay-1 terminal ⑥.

Power is supplied at all times

- through 15A fuse (No. 28), located in the fusible link and fuse box
- to theft warning relay-1 terminal ③.

When the theft warning system is triggered, ground is supplied intermittently

- from terminal ⑫ of the theft warning control unit
- to theft warning horn relay terminal ② and
- to theft warning relay-1 terminal ②, and
- from theft warning horn relay terminal ⑥
- to horn relay terminal ①. ←

The headlamps flash and the horn sounds intermittently.

The alarm automatically turns off after 2 or 3 minutes but will reactivate if the vehicle is tampered with again.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

IDX

# THEFT WARNING SYSTEM

## System Description (Cont'd)

### THEFT WARNING SYSTEM DEACTIVATION

To deactivate the theft warning system, a door or the trunk lid must be unlocked with the key or remote controller.

When the key is used to unlock a door, theft warning control unit terminal ⑩ receives a ground signal from terminal ② of the front door key cylinder switch LH or terminal ① of the front door key cylinder switch RH.

When the key is used to unlock the trunk lid, theft warning control unit terminal ⑩ receives a ground signal from terminal ① of the trunk lid key cylinder switch.


When the remote controller is used to unlock the doors or trunk lid, theft warning control unit terminal ① receives a ground signal from terminal ⑩ of the multi-remote control unit.

When the theft warning control unit receives either one of these signals, the theft warning system is deactivated.

### PANIC ALARM OPERATION

Multi-remote control system may operate the theft warning system (horn and headlamps) as required.

When the multi-remote control system is triggered, ground is supplied intermittently 


- from multi-remote control unit terminal ⑩
- to theft warning horn relay terminal ② and
- to theft warning relay-1 terminal ②, and
- from theft warning horn relay terminal ⑥
- to horn relay terminal ①. 

The headlamps flash and the horn sounds intermittently.

Alarm automatically turns off after 30 seconds or when multi-remote controller receives a certain signal.

# THEFT WARNING SYSTEM

## Component Parts and Harness Connector Location





GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

# THEFT WARNING SYSTEM

## Wiring Diagram — THEFT —

EL-THEFT-01





# THEFT WARNING SYSTEM

## Wiring Diagram — THEFT — (Cont'd)


EL-THEFT-02

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA




# THEFT WARNING SYSTEM

## Wiring Diagram — THEFT — (Cont'd)



Refer to last page (Foldout page).




(M5) (E102)



# THEFT WARNING SYSTEM

## Wiring Diagram — THEFT — (Cont'd)

EL-THEFT-04







# THEFT WARNING SYSTEM

## Wiring Diagram — THEFT — (Cont'd)


EL-THEFT-05



# THEFT WARNING SYSTEM



## Wiring Diagram — THEFT — (Cont'd)

EL-THEFT-06



Refer to last page (Foldout page).

◻M5, ◻E102









# THEFT WARNING SYSTEM

## Trouble Diagnoses (Cont'd)



# THEFT WARNING SYSTEM

## Trouble Diagnoses (Cont'd)



GI

MA

EM

LC

EC

FE

CL

MT

AT

EA

RA

BR

ST

BF

HA


EL

IDX

# THEFT WARNING SYSTEM




## Trouble Diagnoses

### CIRCUIT DIAGRAM FOR QUICK PINPOINT CHECK



# THEFT WARNING SYSTEM

## Trouble Diagnoses (Cont'd)



- (A) : A/T models
- (U) : For U. S. A.
- (N) : For Canada
- (EN) : Except for (NM)
- (UM) : M/T models for U. S. A.
- (NM) : M/T models for Canada
- (KL) : Models with multi-remote control system
- (NK) : Models without multi-remote control system




# THEFT WARNING SYSTEM

## Trouble Diagnoses (Cont'd)

### POWER SUPPLY AND GROUND CIRCUIT CHECK


#### Ground circuit check

Terminals	Continuity
⑯ - Ground	Yes




#### Main power supply circuit check

Terminals	Ignition switch position		
	OFF	ACC	ON
① - ⑯	Battery voltage	Battery voltage	Battery voltage



#### Power supply circuit check for system cancel

Terminals	Ignition switch position		
	OFF	ACC	ON
③ - ⑯	0V	Battery voltage	Battery voltage






# THEFT WARNING SYSTEM

## Trouble Diagnoses (Cont'd)




### DIAGNOSTIC PROCEDURE 1

- SYMPTOM:**
- Indicator lamp does not blink.
  - Indicator lamp remains blinking.

#### Diagnostic procedure 1-(1)



Condition	Continuity
All doors are closed	No
At least one door is open	Yes





GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX






# THEFT WARNING SYSTEM

## Trouble Diagnoses (Cont'd)

### Diagnostic procedure 1-(2)






OK → Go to Diagnostic Procedure 4 (EL-161).



# THEFT WARNING SYSTEM

## Trouble Diagnoses (Cont'd)

### Diagnostic procedure 1-(3)





GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX





# THEFT WARNING SYSTEM

## Trouble Diagnoses (Cont'd)

### Diagnostic procedure 1-(4)



Condition	Continuity
Tamper switch is Normal	No
Tamper switch is Removed	Yes






# THEFT WARNING SYSTEM

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 2

**SYMPTOM: Indicator lamp does not come on.**








GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

# THEFT WARNING SYSTEM

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 3

**SYMPTOM: Indicator lamp does not come on.**











# THEFT WARNING SYSTEM

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 6

**SYMPTOM: Alarm does not operate.**





# THEFT WARNING SYSTEM

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 7

**SYMPTOM:** Alarm does not stop even if stop signal is given.



**A**

**DOOR UNLOCK SWITCH INPUT SIGNAL CHECK (UNLOCK SIGNAL)**  
Check continuity between control unit harness terminals ⑪ and ⑫.

Key position	Continuity
Neutral/Unlock	No
Between neutral and unlock	Yes

OK → Replace control unit.

NG →

**DOOR UNLOCK SWITCH CHECK**  
Refer to "Electrical Components Inspection" (EL-166).

NG → Replace key cylinder switch.

OK →

**B**

**DOOR UNLOCK SWITCH CIRCUIT CHECK**

- Check harness continuity between control unit harness terminal ⑪ and door unlock switch terminal.
- Check harness continuity between door unlock switch terminal and body ground.

Continuity should exist.

NG → Repair harness or connectors.

OK →

**CHECK THE CONNECTIONS AT EACH CONNECTOR.**




GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

# THEFT WARNING SYSTEM

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 8

**SYMPTOM:** Alarm does not stop even if stop signal is given.




# THEFT WARNING SYSTEM

## Trouble Diagnoses (Cont'd)

### ELECTRICAL COMPONENTS INSPECTION

#### Door switches


Check continuity between terminal and switch body.



GI  
MA  
EM  
LC  
EC  
FE  
CL

#### Hood switch


Check continuity between terminals when hood switch is pushed and released.



MT  
AT  
FA  
RA

Terminal	Pushed	Released
a		○
b		○

#### Trunk room lamp switch



BR  
ST  
BF  
HA

Terminal	Trunk lid	
	Closed	Open
a		○
b		○

**EL**

IDX

# THEFT WARNING SYSTEM

## Trouble Diagnoses (Cont'd)


### Key cylinder tamper switch, door lock switch and door unlock switch

#### ● Door

	TAMPER SWITCH		DOOR LOCK SWITCH		DOOR UNLOCK SWITCH		
	Key cylinder is installed	Key cylinder is removed	Full stroke	Between full stroke and neutral	Neutral	Between full stroke and neutral	Full stroke
1				○			
2				○			
3		○		○			
4		○		○		○	


#### ● Trunk lid

	TAMPER SWITCH		Trunk lid unlock switch		
	Key cylinder is installed	Key cylinder is removed	Full stroke	Between full stroke and neutral	Neutral
1				○	
2		○		○	
3		○		○	





#### Door unlock sensor

	LOCK	UNLOCK
1		○
2		○




# LOCATION OF ELECTRICAL UNITS


## Engine Compartment



**Fuse and fusible link box**



**Relay box-2**



GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

**EL**

IDX


# LOCATION OF ELECTRICAL UNITS

## Passenger Compartment



# LOCATION OF ELECTRICAL UNITS

## Luggage Compartment



GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA


**EL**

IDX



# HARNESSES LAYOUT

## Outline



GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

**EL**

IDX

# HARNESS LAYOUT

## Engine Room Harness




# HARNESS LAYOUT

## Engine Room Harness (Cont'd)

B2	: Hood switch	E1	: Body ground (For anti-lock brake system)
C2	: Front wheel sensor RH (For anti-lock braking system)	E2	: Front wheel sensor LH (For anti-lock brake system)
C2	: Theft warning horn	E3	: Battery
C2	: Body ground (For anti-lock braking system)	E3*	: To E215
E1	: Cooling fan relay-3 (A/T models)	E4	: To E216
B2	: To A1	E3	: To E219
E7	: To A2	D3*	: To E220
A2	: Front washer motor	E3*	: Dropping resistor (A/T models)
A2	: Washer fluid level switch	C3	: Dual-pressure switch (For Canada)
B2*	: Body ground	E1	: Cooling fan relay-1
A3	: Front side marker lamp RH	E1	: ASCD hold relay
A3	: Front fog lamp RH	E1	: Fog lamp relay
A2	: Front turn signal lamp RH	E1	: Air conditioner relay
A3	: Clearance lamp RH	E1	: Daytime light cancel relay
A3	: Headlamp RH	E1	: Door mirror defogger relay
B4	: Compressor	E1	: Theft warning relay-1
C3	: Actuator (For anti-lock brake system)	F1	: Horn relay
C3	: Horn (High)	E1	: Inhibitor relay (A/T models) Clutch inter lock relay (M/T models)
B4	: Cooling fan motor-1	E1	: Fuel pump relay
C4	: Cooling fan motor-2	E1	: Theft warning relay-2
D4	: Headlamp LH	E1*	: ECOS relay
D4	: Clearance lamp LH	F1	: Front wiper relay
C5	: Triple-pressure switch (For U.S.A.)	E59	: Joint connector-2
E1	: Cooling fan relay-2	*E60	: Joint connector-3
D4	: Front turn signal lamp LH	E61	: Joint connector-4
E29	: Joint connector-1		
E4	: Fuse and fusible link box		
D5	: Front fog lamp LH		
E5	: Front side marker lamp LH		
F4*	: Body ground		
E2	: Brake fluid level switch		
F3	: ASCD actuator		

\*3: Joint connector box




\*: Be sure to connect and securely lock connectors after the repairs.  
Failure to do so may cause the on-board diagnostic system to light up the MIL as an open circuit detection. (Refer to EC section.)

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX


# HARNESS LAYOUT

## Engine Room Harness




\*: Be sure to connect and securely lock connectors after the repairs. Failure to do so may cause the on-board diagnostic system to light up the MIL as an open circuit detection. (Refer to EC section.)

- \* E101 : Diode
- \* E102 : Diode (A/T models)
- E103 : Diode
- \* E104 : Horn relay
- E105 : Fuse block
- E107 : Key switch
- E110 : Daytime light system
- E111 : Daytime light system
- \* E112 : Diode
- \* E113 : Diode
- E114 : Diode



# HARNES LAYOUT


## Room Lamp Harness



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

# HARNESS LAYOUT

## Main Harness



\*: Be sure to connect and securely lock connectors after the repairs.  
 Failure to do so may cause the on-board diagnostic system to light up the MIL as an open circuit detection. (Refer to EC section.)

# HARNES LAYOUT

## Main Harness (Cont'd)


- A4 : Body ground
- A4 : To **(M1)**
- A4 : To **(D1)**
- A4 : To **(D2)**
- A4 : To **(E10)**
- A4 : To **(E102)** (SMJ)
- A4 : Diode
- A3 : Circuit breaker
- B3 : Seat belt rela
- B4 : Power windo
- B4 : Shift lock con
- B2 : To **(R1)**
- B2 : To **(R2)**
- C4 : Data link connector for CONSULT
- C4 : Fuse block
- B3 : ASCD control unit
- C4 : Time control unit
- C3 : Rear window defogger relay
- C3 : Clutch interlock switch (For U.S.A. M/T models)
- C3 : ASCD clutch switch (M/T models)
- C3 : Stop lamp switch
- C3 : ASCD cancel switch
- B3 : Illumination control switch
- C2 : Door mirror remote control switch
- B3 : ASCD main switch
- C3 : Theft warning indicator lamp
- C3 : Combination meter
- D3 : Theft warning control unit
- D2 : Combination flasher unit
- D4 : Mode door motor
- D2 : Rear window defogger switch
- E2 : Hazard switch
- E2 : Fog lamp switch
- D3 : Radio
- E3 : Fan switch
- E4 : Push control unit
- D4 : Not used
- E4 : Cigarette lighter
- E4 : Ashtray illumination
- F3 : Daytime light control unit (For Canada)
- E2 : Thermo control amplifier
- F3 : Trunk lid opener cancel switch

- F2 : Glove box lamp
- F2 : Intake door motor
- F1 : To **(M7)**
- E2 : Front wiper motor
- G2 : To **(B2)**
- G2 : To **(B22)**
- F2 : Blower motor
- F2 : Resistor
- G2 : Body ground
- G3 : Body ground (For anti-lock brake system)
- G3 : ABS control unit
- B5 : Blower relay
- G1 : To **(M34)**
- G1 : Tweeter RH
- F3 : Door lock timer
- F3 : Diode


- B4 : A/T control unit
- B4 : To **(E13)**
- B4 : Diode
- D3 : Vent mode switch
- D3 : Diode
- E4 : Full cold switch
- D2 : To **(A104)**
- E2 : To **(A103)**
- D3 : To **(F28)**
- E3 : Maximum cold door motor
- G3 : Multi-remote control relay-2
- F4 : To **(F30)**
- F4 : To **(F31)**
- A4 : Diode

(Models with multi-remote control system)


**(M7)** : Diode




**(M6)** : Diode (For Canada)




**(M78)** : Diode (Models with multi-remote control system)



**(M78)** : Diode



**(M90)** : Diode (Models with multi-remote control system)





GI  
 MA  
 EM  
 LC  
 EC  
 FE  
 CL  
 MT  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
 EL  
 IDX

# HARNES LAYOUT

## Main Harness (Cont'd)

- (M109) : Body ground
- (M110) : To (D41)
- (M111) : Front door switch LH
- (M112) : Seat belt buckle switch
- (M113) : Parking brake switch
- (M114) : Power window main switch LH and door lock and unlock switch
- (M115) : Rear wheel sensor LH (For anti-lock braking system)
- (M116) : Rear wheel sensor RH (For anti-lock braking system)
- (M117) : Fuel tank gauge unit
- (M118) : Fuel pump
- (M119) : Shift lock solenoid, detention switch, A/T indicator illumination and overdrive control switch (A/T models)
- (M120) : Front door switch RH
- (M121) : To (D51)
- (M122) : Rear door switch LH

- (M123) : Pre-tensioner RH
- (M124) : Front power seat RH
- (M125) : A/T mode switch
- (M126) : Front power seat LH
- (M127) : Pre-tensioner LH
- (M128) : Rear heated oxygen sensor
- (M129) : Power window main switch RH




\*: Be sure to connect and securely lock connectors after the repairs. Failure to do so may cause the on-board diagnostic system to light up the MIL as an open circuit detection. (Refer to EC section.)



# HARNESS LAYOUT


## Main Harness, Tail Harness and Tail Harness No.2



Tail harness No. 2

T9 : To T8  
T10 : To M161



## Engine Control Harness and Alternator Harness




# HARNES LAYOUT

## Engine Harness

- E203** : Thermal transmitter
- E208** : Oil pressure switch
- E209** : Starter motor
- E210** : Neutral position switch (M/T models)
- E211** : Back-up lamp switch (M/T models)
- E213** : Inhibitor switch (A/T models)
- E214** : To **F14**
- E215** : To **E39**
- E216** : To **E40**
- E219** : Battery
- E220** : To **E41**
- E222** : Vehicle speed sensor
- E223** : EGRC-solenoid valve



- Sub-harness**
- F100** : To **E38**
  - F101** : Injector No. 1
  - F102** : Injector No. 2
  - F103** : Injector No. 3
  - F104** : Injector No. 4
  - F105** : Knock sensor




\*: Be sure to connect and securely lock connectors after the repairs. Failure to do so may cause the on-board diagnostic system to light up the MIL as an open circuit detection. (Refer to EC section.)

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX


# HARNESS LAYOUT

## FRONT

### Door Harness (LH side)




## REAR



# HARNESS LAYOUT


FRONT

## Door Harness (RH side)



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT

REAR



FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX