

LT  
**SECTION**  
**LIGHTING SYSTEM**

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

**CONTENTS**

<b>PRECAUTIONS</b> .....	<b>Headlamp Does Not Illuminate (One Side)</b> .....
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	Headlamps Do Not Turn OFF .....
Precautions for Battery Service .....	General Information for Xenon Headlamp Trouble
General Precautions for Service Operations .....	Diagnosis .....
<b>HEADLAMP - XENON TYPE -</b> .....	Caution: .....
Component Parts and Harness Connector Location...	Xenon Headlamp Trouble Diagnosis .....
System Description .....	Aiming Adjustment .....
OUTLINE .....	PREPARATION BEFORE ADJUSTING .....
HEADLAMP OPERATION .....	LOW BEAM AND HIGH BEAM .....
COMBINATION SWITCH READING FUNCTION...	ADJUSTMENT USING AN ADJUSTMENT
EXTERIOR LAMP BATTERY SAVER CONTROL...	SCREEN (LIGHT/DARK BORDERLINE) .....
AUTO LIGHT OPERATION .....	Bulb Replacement .....
VEHICLE SECURITY SYSTEM .....	HEADLAMP LOW/HIGH BEAM .....
XENON HEADLAMP .....	FRONT FOG LAMP .....
CAN Communication System Description .....	PARKING LAMP .....
CAN Communication Unit .....	FRONT TURN SIGNAL LAMP .....
Schematic .....	Removal and Installation .....
Wiring Diagram — H/LAMP — .....	REMOVAL .....
Terminals and Reference Values for BCM .....	INSTALLATION .....
Terminals and Reference Values for IPDM E/R ....	Disassembly .....
How to Proceed With Trouble Diagnosis .....	Assembly .....
Preliminary Check .....	Servicing to Replace Headlamps When Damaged..
CHECK POWER SUPPLY AND GROUND CIRCUIT .....	REMOVAL AND INSTALLATION .....
CONSULT-II Functions (BCM) .....	<b>DAYTIME LIGHT SYSTEM</b> .....
CONSULT-II BASIC OPERATION .....	Component Parts and Harness Connector Location..
WORK SUPPORT .....	System Description .....
DATA MONITOR .....	OUTLINE .....
ACTIVE TEST .....	DAYTIME LIGHT OPERATION .....
CONSULT-II Functions (IPDM E/R) .....	COMBINATION SWITCH READING FUNCTION..
CONSULT-II BASIC OPERATION .....	EXTERIOR LAMP BATTERY SAVER CONTROL..
DATA MONITOR .....	AUTO LIGHT OPERATION .....
ACTIVE TEST .....	CAN Communication System Description .....
Headlamp Does Not Change To High Beam (Both Sides) .....	CAN Communication Unit .....
Headlamp Does Not Change To High Beam (One Side) .....	Schematic .....
Headlamp Does Not Illuminate (Both Sides) .....	Wiring Diagram — DTRL — .....
	Terminals and Reference Values for BCM .....
	Terminals and Reference Values for IPDM E/R ....
	How to Proceed With Trouble Diagnosis .....
	Preliminary Check .....
	CHECK POWER SUPPLY AND GROUND CIR-

CUIT .....	46	TURN SIGNAL OPERATION .....	77
CHECK PARKING BRAKE SWITCH CIRCUIT ...	47	HAZARD LAMP OPERATION .....	78
CONSULT-II Functions (BCM) .....	48	REMOTE KEYLESS ENTRY SYSTEM OPERA-	
CONSULT-II Functions (IPDM E/R) .....	48	TION .....	79
Daytime Light Control Does Not Operate Properly..	48	COMBINATION SWITCH READING FUNCTION..	79
Aiming Adjustment .....	50	CAN Communication System Description .....	79
Bulb Replacement .....	50	CAN Communication Unit .....	79
Removal and Installation .....	50	Schematic .....	80
<b>AUTO LIGHT SYSTEM .....</b>	<b>51</b>	Wiring Diagram — TURN — .....	81
Component Parts and Harness Connector Location..	51	Terminals and Reference Values for BCM .....	84
System Description .....	51	How to Proceed With Trouble Diagnosis .....	85
OUTLINE .....	51	Preliminary Check .....	85
COMBINATION SWITCH READING FUNCTION..	52	CHECK POWER SUPPLY AND GROUND CIR-	
DELAY TIMER FUNCTION .....	52	CUIT .....	85
CAN Communication System Description .....	52	CONSULT-II Functions (BCM) .....	86
CAN Communication Unit .....	52	CONSULT-II BASIC OPERATION .....	86
Major Components and Functions .....	52	DATA MONITOR .....	86
Schematic .....	53	ACTIVE TEST .....	87
Wiring Diagram — AUTO/L — .....	54	Turn Signal Lamp Does Not Operate .....	87
Terminals and Reference Values for BCM .....	57	Hazard Warning Lamp Does Not Operate But Turn	
Terminals and Reference Values for IPDM E/R ....	58	Signal Lamp Operates .....	89
How to Proceed With Trouble Diagnosis .....	58	Bulb Replacement .....	90
Preliminary Check .....	59	FRONT TURN SIGNAL LAMP .....	90
SETTING CHANGE FUNCTIONS .....	59	REAR TURN SIGNAL LAMP .....	90
CHECK POWER SUPPLY AND GROUND CIR-		Removal and Installation .....	90
CUIT .....	59	FRONT TURN SIGNAL LAMP .....	90
CONSULT-II Functions (BCM) .....	60	REAR TURN SIGNAL LAMP .....	90
CONSULT-II Functions (IPDM E/R) .....	60	<b>LIGHTING AND TURN SIGNAL SWITCH .....</b>	<b>91</b>
Symptom Chart .....	60	Removal and Installation .....	91
Lighting Switch Inspection .....	60	REMOVAL .....	91
Optical sensor System Inspection .....	61	INSTALLATION .....	91
Removal and Installation of Optical Sensor .....	63	<b>HAZARD SWITCH .....</b>	<b>92</b>
REMOVAL .....	63	Removal and Installation (M/T) .....	92
INSTALLATION .....	63	REMOVAL .....	92
<b>FRONT FOG LAMP .....</b>	<b>64</b>	INSTALLATION .....	92
Component Parts and Harness Connector Location..	64	Removal and Installation (A/T) .....	92
System Description .....	64	REMOVAL .....	92
OUTLINE .....	64	INSTALLATION .....	92
FRONT FOG LAMP OPERATION .....	65	<b>COMBINATION SWITCH .....</b>	<b>93</b>
COMBINATION SWITCH READING FUNCTION..	65	Wiring Diagram — COMBSW — .....	93
EXTERIOR LAMP BATTERY SAVER CONTROL..	65	Combination Switch Reading Function .....	94
CAN Communication System Description .....	65	Terminals and Reference Values for BCM .....	94
CAN Communication Unit .....	65	CONSULT-II Function (BCM) .....	99
Wiring Diagram — F/FOG — .....	66	CONSULT-II BASIC OPERATION .....	99
Terminals and Reference Values for BCM .....	68	DATA MONITOR .....	99
Terminals and Reference Values for IPDM E/R ....	70	Combination Switch Inspection .....	100
How to Proceed With Trouble Diagnosis .....	70	Removal and Installation .....	102
Preliminary Check .....	70	<b>STOP LAMP .....</b>	<b>103</b>
CHECK POWER SUPPLY AND GROUND CIR-		Wiring Diagram — STOP/L — .....	103
CUIT .....	70	Bulb Replacement of High-Mounted Stop Lamp ..	105
CONSULT-II Functions (BCM) .....	71	WITH REAR SPOILER .....	105
CONSULT-II Functions (IPDM E/R) .....	71	WITHOUT REAR SPOILER .....	105
Front Fog lamps Do Not Illuminate (Both Sides) ...	72	Bulb Replacement of Rear Combination Lamp (Stop	
Front Fog Lamp Does Not Illuminate (One Side) ...	74	Lamp) .....	105
Aiming Adjustment .....	75	Removal and Installation of High-Mounted Stop	
Bulb Replacement .....	76	Lamp .....	105
<b>TURN SIGNAL AND HAZARD WARNING LAMPS..</b>	<b>77</b>	REMOVAL (WITH REAR SPOILER) .....	105
Component Parts and Harness Connector Location..	77	INSTALLATION .....	105
System Description .....	77	REMOVAL (WITHOUT REAR SPOILER) .....	105

INSTALLATION .....	105	ROOM LAMP TIMER OPERATION .....	130
Removal and Installation of Rear Combination Lamp (Stop Lamp) .....	105	INTERIOR ROOM LAMP BATTERY SAVER CONTROL .....	131
<b>BACK-UP LAMP .....</b>	<b>106</b>	Schematic .....	132
Wiring Diagram — BACK/L — .....	106	Wiring Diagram — ROOM/L — .....	134
A/T MODELS .....	106	Terminals and Reference Values for BCM .....	140
M/T MODELS .....	107	How to Proceed With Trouble Diagnosis .....	141
Bulb Replacement .....	108	Preliminary Check .....	141
Removal and Installation .....	108	CHECK POWER SUPPLY AND GROUND CIRCUIT .....	141
<b>PARKING, LICENSE PLATE AND TAIL LAMPS ..</b>	<b>109</b>	CONSULT-II Functions (BCM) .....	142
Component Parts and Harness Connector Location	109	CONSULT-II BASIC OPERATION .....	142
System Description .....	109	WORK SUPPORT (INT LAMP) .....	142
OPERATION BY LIGHTING SWITCH .....	110	DATA MONITOR (INT LAMP) .....	142
COMBINATION SWITCH READING FUNCTION	110	ACTIVE TEST (INT LAMP) .....	143
EXTERIOR LAMP BATTERY SAVER CONTROL	110	WORK SUPPORT (BATTERY SAVER) .....	143
CAN Communication System Description .....	110	DATA MONITOR (BATTERY SAVER) .....	144
CAN Communication Unit .....	110	ACTIVE TEST (BATTERY SAVER) .....	145
Schematic .....	111	Map Lamp Control Does Not Operate .....	145
Wiring Diagram — TAIL/L — .....	112	Ignition Key Hole Illumination Control Does Not Operate .....	146
Terminals and Reference Values for BCM .....	116	All Step Lamps Does Not Operate .....	148
Terminals and Reference Values for IPDM E/R ..	116	All Interior Room Lamps Does Not Operate .....	149
How to Proceed With Trouble Diagnosis .....	117	Bulb Replacement .....	149
Preliminary Check .....	117	VANITY MIRROR LAMP .....	149
CHECK POWER SUPPLY AND GROUND CIRCUIT .....	117	MAP LAMP .....	149
CONSULT-II Functions (BCM) .....	118	STEP LAMP .....	150
CONSULT-II Functions (IPDM E/R) .....	118	TRUNK ROOM LAMP .....	150
Parking, License Plate, Side Marker and Tail Lamps Do Not Illuminate .....	119	IGNITION KEY HOLE ILLUMINATION .....	150
Parking, License Plate, Side Marker and Tail Lamps Do Not Turn OFF (After Approx. 10 Minutes) .....	124	Removal and Installation .....	151
Bulb Replacement .....	124	MAP LAMP .....	151
FRONT SIDE MARKER LAMP .....	124	STEP LAMP .....	151
LICENSE PLATE LAMP .....	124	TRUNK ROOM LAMP .....	151
PARKING LAMP .....	124	<b>ILLUMINATION .....</b>	<b>152</b>
TAIL LAMP .....	124	System Description .....	152
Removal and Installation .....	125	ILLUMINATION OPERATION BY LIGHTING SWITCH .....	152
FRONT SIDE MARKER LAMP .....	125	EXTERIOR LAMP BATTERY SAVER CONTROL	154
LICENSE PLATE LAMP .....	125	CAN Communication System Description .....	154
PARKING LAMP .....	125	CAN Communication Unit .....	154
TAIL LAMP .....	125	Schematic .....	155
<b>REAR COMBINATION LAMP .....</b>	<b>126</b>	Wiring Diagram — ILL — .....	156
Bulb Replacement .....	126	Bulb Replacement .....	165
Removal and Installation .....	126	GLOVE BOX LAMP .....	165
REMOVAL .....	126	UPPER GLOVE BOX LAMP .....	165
INSTALLATION .....	126	ASHTRAY ILLUMINATION .....	165
<b>INTERIOR ROOM LAMP .....</b>	<b>127</b>	CIGARETTE LIGHTER ILLUMINATION .....	165
Component Parts and Harness Connector Location	127	<b>BULB SPECIFICATIONS .....</b>	<b>166</b>
System Description .....	128	Headlamp .....	166
POWER SUPPLY AND GROUND .....	128	Exterior Lamp .....	166
SWITCH OPERATION .....	129	Interior Lamp/Illumination .....	166

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# PRECAUTIONS

## PRECAUTIONS

PFP:00011

### Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

NKS000FA

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

#### WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

### Precautions for Battery Service



NKS000FB

Before disconnecting the battery, lower both the driver and passenger windows. This will prevent any interference between the window edge and the vehicle when the door is opened/closed. During normal operation, the window slightly raises and lowers automatically to prevent any window to vehicle interference. The automatic window function will not work with the battery disconnected.

### General Precautions for Service Operations

NKS000FC

- Never work with wet hands.
- Xenon headlamp includes high voltage generating part. Be sure to disconnect battery negative cable (negative terminal) or power fuse before removing, installing, or touching the xenon headlamp (including lamp bulb).
- Turn the lighting switch OFF before disconnecting and connecting the connector.
- When turning the xenon headlamp on and while it is illuminated, never touch the harness, bulb, and socket of the headlamp.
- When checking the headlamp on/off operation, check it on vehicle and with the power connected to the vehicle-side connector.
- Do not touch the headlamp bulb glass surface with bare hands or allow oil or grease to get on it. Do not touch the headlamp bulb just after the headlamp is turned off, because it is very hot.
- Install the xenon headlamp bulb socket correctly. If it is installed improperly, high-voltage leak or corona discharge may occur that can melt the bulb, connector, and housing. Do not illuminate the xenon headlamp bulb out of the headlamp housing. Doing so can cause fire and harm your eyes.
- When the bulb has burned out, wrap it in a thick vinyl bag and discard. Do not break the bulb.
- Leaving the bulb removed from the headlamp housing for a long period of time can deteriorate the performance of the lens and reflector (dirt, clouding). Always prepare a new bulb and have it on hand when replacing the bulb.
- When adjusting the headlamp aiming, turn the aiming adjustment screw only in the tightening direction. (If it is necessary to loosen the screw, first fully loosen the screw, and then turn it in the tightening direction.)
- Do not use organic solvent (paint thinner or gasoline) to clean lamps and to remove old sealant.




# HEADLAMP - XENON TYPE -

## HEADLAMP - XENON TYPE -

PPF:26010

### Component Parts and Harness Connector Location

NKS002ND



## System Description

NKS002NE

The control of headlamp system operation is dependent upon the position of the lighting switch. When the lighting switch is placed in the 2ND position, BCM (body control module) receives input signal requesting the headlamps (and tail lamps) illuminate. This input signal is communicated to IPDM E/R (intelligent power distribution module engine room) through CAN communication lines. The CPU (central processing unit) located in the IPDM E/R controls headlamp high relay and headlamp low relay. These relays, when energized, direct power to the respective headlamps, which then illuminate.

If voltage is applied to a high beam solenoid, the bulb shade will move, even a xenon headlamp bulb comes out, and a high beam and a low beam are changed.

## OUTLINE

Power is supplied at all times

- to ignition relay, located in IPDM E/R
- to headlamp high relay, located in IPDM E/R, and
- to headlamp low relay, located in IPDM E/R, from battery direct,
- through 10A fuse (No. 71, located in IPDM E/R)
- to CPU located in IPDM E/R,
- through 15A fuse (No. 78, located in IPDM E/R)
- to CPU located in IPDM E/R,
- through 50A fusible link (letter F, located in fuse, fusible link and relay box)
- to BCM terminal 55,
- through 10A fuse [No. 18, located in fuse block (J/B)]

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

## HEADLAMP - XENON TYPE -

---

- to BCM terminal 42,
- through 10A fuse [No. 19, located in fuse block (J/B)]
- to combination meter terminal 21.

With the ignition switch in the ON or START position, power is supplied

- to ignition relay, located in IPDM E/R, from battery direct,
- through 10A fuse [No. 1, located in fuse block (J/B)]
- to BCM terminal 38,
- through 10A fuse [No. 14, located in fuse block (J/B)]
- to combination meter terminals 22 and 23.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 6, located in fuse block (J/B)]
- to BCM terminal 11.

Ground is supplied

- to BCM terminal 52
- through grounds M30 and M66,
- to IPDM E/R terminals 38 and 60
- through grounds E17 and E43,
- to combination meter terminals 1, 24 and 25
- through grounds M30 and M66.

### HEADLAMP OPERATION

#### Low Beam Operation

With the lighting switch in 2ND position, the BCM receives input signal requesting headlamps to illuminate. This input signal is communicated to IPDM E/R across CAN communication lines. The CPU located in the IPDM E/R controls headlamp low relay coil, which when energized, directs power

- through 15A fuse (No. 76, located in IPDM E/R)
- through IPDM E/R terminal 20
- to front combination lamp RH terminal 3,
- through 15A fuse (No. 86, located in IPDM E/R)
- through IPDM E/R terminal 30
- to front combination lamp LH terminal 3.

Ground is supplied

- to front combination lamp RH and LH terminals 4
- through grounds E17 and E43.

With power and ground supplied, low beam headlamps illuminate.

#### High Beam Operation/Flash-to-Pass Operation

With the lighting switch in 2ND position and placed in HIGH BEAM or PASSING position, the BCM receives input signal requesting the headlamp high beams to illuminate. This input signal is communicated to IPDM E/R through the CAN communication lines. The CPU located in the IPDM E/R controls headlamp high relay and headlamp low relay, which when energized, directs power

- through 15A fuse (No. 76, located in IPDM E/R)
- through IPDM E/R terminal 20
- to front combination lamp RH terminal 3,
- through 15A fuse (No. 86, located in IPDM E/R)
- through IPDM E/R terminal 30
- to front combination lamp LH terminal 3,
- through 10A fuse (No. 72, located in IPDM E/R)
- through IPDM E/R terminal 27
- to front combination lamp RH terminal 2,
- through 10A fuse (No. 74, located in IPDM E/R)

# HEADLAMP - XENON TYPE -

- through IPDM E/R terminal 28
- to front combination lamp LH terminal 2.

Ground is supplied

- to front combination lamp RH and LH terminals 8
- through grounds E17 and E43.

With power and ground supplied, the high beam headlamps illuminate.

If voltage is applied to a high beam solenoid, the bulb shade will move, even a xenon headlamp bulb comes out, and a high beam and a low beam are changed.

The high beam indicator illuminates when combination meter receives input signal requesting high beam indicator to illuminate. This is communicated to BCM through the CAN communication lines.

## COMBINATION SWITCH READING FUNCTION

Refer to [BCS-3, "COMBINATION SWITCH READING FUNCTION"](#) .

## EXTERIOR LAMP BATTERY SAVER CONTROL

When the lighting switch is in the 2ND position and the ignition switch is turned from ON or ACC to OFF, the battery saver control function is activated.

Under this condition, the headlamps remain illuminated for 5 minutes, and then the headlamps are turned off. Exterior lamp battery saver control mode can be changed by the function setting of CONSULT-II.

## AUTO LIGHT OPERATION

Refer to [LT-51, "System Description"](#) .

## VEHICLE SECURITY SYSTEM

The vehicle security system will flash the high beams if the system is triggered. Refer to [BL-188, "VEHICLE SECURITY \(THEFT WARNING\) SYSTEM"](#) .

## XENON HEADLAMP

Xenon type lamps are used for to the low beam headlamps. Xenon bulbs do not use a filament. Instead, they produce light when a high voltage current is passed between two tungsten electrodes through a mixture of xenon (an inert gas) and certain other metal halides. In addition to strong lighting power, electronic control of the power supply gives the headlamps stable quality and tone color.

Followings are some advantages of the xenon type headlamp.

- The light produced by the headlamps is white color similar to sunlight that is easy to the eyes.
- Light output is nearly double that of halogen headlamps, affording increased area of illumination.
- Counter-reflected luminance increases and the contrast enhances on the wet road in the rain. That makes visibility go up more than the increase of the light volume.
- Power consumption is approximately 25 percent less than halogen headlamps, reducing battery load.

## CAN Communication System Description

NKS002NF

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

## CAN Communication Unit


NKS002NG

Refer to [LAN-47, "CAN System Specification Chart"](#) .

# HEADLAMP - XENON TYPE -

## Schematic

NKS002NH



\* : This relay is built into the IPDM E/R (Intelligent power distribution module engine room).

TKWM3445E





# HEADLAMP - XENON TYPE -

## Wiring Diagram — H/LAMP —

NKS002NI

### LT-H/LAMP-01




REFER TO THE FOLLOWING.

- (E108) -SUPER MULTIPLE JUNCTION (SMJ)
- (M4) -FUSE BLOCK-JUNCTION BOX (J/B)
- (M1), (M2) -ELECTRICAL UNITS

TKWM2185E

# HEADLAMP - XENON TYPE -

LT-H/LAMP-02



16	15	14	13	12	11	10	9
8	7	6	5	4	3	2	1

(M8)  
W

20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22	21

(M19)  
W

REFER TO THE FOLLOWING.



- (M4) - FUSE BLOCK-JUNCTION BOX (J/B)
- (M1) - ELECTRICAL UNITS

TKWM2186E

# HEADLAMP - XENON TYPE -

LT-H/LAMP-03

▬ : DATA LINE





REFER TO THE FOLLOWING.

(B1) -SUPER MULTIPLE JUNCTION (SMJ)

TKWM3446E

# HEADLAMP - XENON TYPE -

LT-H/LAMP-04



TKWM4010E

# HEADLAMP - XENON TYPE -

## Terminals and Reference Values for BCM

NKS002NJ

**CAUTION:**





- Check combination switch system terminal waveform under the loaded condition with lighting switch, turn signal switch and wiper switch OFF not to be fluctuated by overloaded.
- Turn wiper dial position to 4 except when checking waveform or voltage of wiper dial position. Wiper dial position can be confirmed on CONSULT-II. Refer to [LT-17, "DATA MONITOR"](#) .

Terminal No.	Wire color	Signal name	Measuring condition		Reference value	
			Ignition switch	Operation or condition		
2	G/R	Combination switch input 5	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	OFF	Approx. 0 V
					Lighting switch HIGH beam (Operates only HIGH beam switch)	<p>Approx. 1.0 V</p>
					Lighting switch 2ND	<p>Approx. 2.0 V</p>
3	G	Combination switch input 4	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	OFF	Approx. 0 V
					Any of the conditions below <ul style="list-style-type: none"> <li>● Lighting switch 2ND</li> <li>● Lighting switch PASSING (Operates only PASSING switch)</li> </ul>	<p>Approx. 1.0 V</p>
11	LG	Ignition switch (ACC)	ACC	—	Battery voltage	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LT

## HEADLAMP - XENON TYPE -

Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
34	PU	Combination switch output 3	ON	Lighting, turn, wiper switch	OFF (Wiper intermittent dial position 4)  <p style="text-align: right; font-size: small;">PKIB4960J</p> Approx. 7.2 V
					Any of the conditions below <ul style="list-style-type: none"> <li>● Lighting switch 2ND</li> <li>● Lighting switch HI beam (Operates only HI beam switch)</li> </ul>  <p style="text-align: right; font-size: small;">PKIB4958J</p> Approx. 1.2 V
35	Y/R	Combination switch output 2	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	OFF  <p style="text-align: right; font-size: small;">PKIB4960J</p> Approx. 7.2 V
					Any of the conditions below <ul style="list-style-type: none"> <li>● Lighting switch 2ND</li> <li>● Lighting switch PASSING (Operates only PASSING switch)</li> </ul>  <p style="text-align: right; font-size: small;">PKIB4958J</p> Approx. 1.2 V
38	W/L	Ignition switch (ON)	ON	—	Battery voltage
39	L	CAN - H	—	—	—
40	P	CAN - L	—	—	—
42	GY	Battery power supply	OFF	—	Battery voltage
52	B	Ground	ON	—	Approx. 0 V
55	R	Battery power supply	OFF	—	Battery voltage

# HEADLAMP - XENON TYPE -

## Terminals and Reference Values for IPDM E/R

NKS002NK

Terminal No.	Wire color	Signal name	Measuring condition		Reference value	
			Ignition switch	Operation or condition		
20	R	Headlamp HIGH&LOW (RH)	ON	Lighting switch 2ND position	OFF	Approx. 0 V
					ON	Battery voltage
27	BR	Headlamp high (RH)	ON	Lighting switch HIGH BEAM or PASSING position	OFF	Approx. 0 V
					ON	Battery voltage
28	R/Y	Headlamp high (LH)	ON	Lighting switch HIGH BEAM or PASSING position	OFF	Approx. 0 V
					ON	Battery voltage
30	R/B	Headlamp HIGH&LOW (LH)	ON	Lighting switch 2ND position	OFF	Approx. 0 V
					ON	Battery voltage
38	B/R	Ground	ON	—	Approx. 0 V	
48	L	CAN – H	—	—	—	
49	P	CAN – L	—	—	—	
60	B/R	Ground	ON	—	Approx. 0 V	

### How to Proceed With Trouble Diagnosis

NKS002NL

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-5, "System Description"](#) .
3. Perform the preliminary check. Refer to [LT-15, "Preliminary Check"](#) .
4. Check symptom and repair or replace the malfunctioning parts.
5. Does headlamp operate normally? If YES, GO TO 6. If NO, GO TO 4.
6. INSPECTION END

### Preliminary Check

NKS002NM

#### CHECK POWER SUPPLY AND GROUND CIRCUIT

#### 1. CHECK FUSES AND FUSIBLE LINK

Check for blown fuses and fusible link.

Unit	Power source	Fuse and fusible link No.
BCM	Battery	F
		18
	Ignition switch ON or START position	1
	Ignition switch ACC or ON position	6
IPDM E/R	Battery	72
		74
		76
		86

Refer to [LT-9, "Wiring Diagram — H/LAMP —"](#) .

#### OK or NG

OK >> GO TO 2.

NG >> If fuse or fusible link is blown, be sure to eliminate cause of malfunction before installing new fuse or fusible link. Refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#) .

# HEADLAMP - XENON TYPE -

## 2. CHECK POWER SUPPLY CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check voltage between BCM harness connector and ground.

(+)		(-)	Ignition switch position		
BCM connector	Terminal		OFF	ACC	ON
M1	11	Ground	Approx. 0 V	Battery voltage	Battery voltage
	38		Approx. 0 V	Approx. 0 V	Battery voltage
M2	42		Battery voltage	Battery voltage	Battery voltage
	55		Battery voltage	Battery voltage	Battery voltage

OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.



## 3. CHECK GROUND CIRCUIT


Check continuity between BCM harness connector and ground.

BCM connector	Terminal	Ground	Continuity
M2	52		Yes

OK or NG

OK >> INSPECTION END

NG >> Repair harness or connector.



## CONSULT-II Functions (BCM)

CONSULT-II can display each diagnostic item using the diagnostic test mode shown following.

BCM diagnosis part	Diagnosis mode	Description
HEADLAMP	WORK SUPPORT	Changes the setting for each function.
	DATA MONITOR	Displays BCM input data in real time.
	ACTIVE TEST	Operation of electrical loads can be checked by sending drive signal to them.
BCM	SELF-DIAG RESULTS	BCM performs self-diagnosis of CAN communication.
	CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.

## CONSULT-II BASIC OPERATION

Refer to [GI-37, "CONSULT-II Start Procedure"](#) .

### WORK SUPPORT

#### Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "WORK SUPPORT" on "SELECT DIAG MODE" screen.
3. Touch "BATTERY SAVER SET" on "SELECT WORK ITEM" screen.



## HEADLAMP - XENON TYPE -

4. Touch "START".
5. Touch "CHANGE SET".
6. The setting will be changed and "CUSTOMIZING COMPLETED" will be displayed.
7. Touch "END".

### Display Item List

Item	Description
BATTERY SAVER SET	Exterior lamp battery saver control mode can be changed in this mode. Selects exterior lamp battery saver control mode between two ON/OFF. Factory setting is ON.
CUSTOM A/LIGHT SETTING	Auto light sensitivity can be changed in this mode. Sensitivity can be adjusted in 4 modes. Factory setting is MODE 1. <ul style="list-style-type: none"> <li>● MODE 1 (Normal)/MODE 2 (sensitive)/MODE 3 (Desensitized)/MODE 4 (Insensitive)</li> </ul>
ILL DELAY SET	Auto light delay off timer period can be changed in this mode. Selects auto light delay off timer period among eight modes. Factory setting is MODE 1. <ul style="list-style-type: none"> <li>● MODE 1 (45 sec.)/MODE 2 (OFF)/MODE 3 (30 sec.)/MODE 4 (60 sec.)/MODE 5 (90 sec.)/MODE 6 (120 sec.)/MODE 7 (150 sec.)/MODE 8 (180 sec.)</li> </ul>

### DATA MONITOR

#### Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
3. Touch either "ALL SIGNALS" or "SELECTION FROM MENU" on "SELECT MONITOR ITEM" screen.

ALL SIGNALS	Monitors all the signals.
SELECTION FROM MENU	Selects items and monitor them.

4. When "SELECTION FROM MENU" is selected, touch individual items to be monitored. When "ALL SIGNALS" is selected, all the items will be monitored.
5. Touch "START".
6. Touch "RECORD" while monitoring, then the status of the monitored item can be recorded. To stop recording, touch "STOP".

### Display Item List

Monitor item	Contents
IGN ON SW "ON/OFF"	Displays status (ignition switch IGN position: ON/other: OFF) of ignition switch judged from the ignition switch signal.
ACC ON SW "ON/OFF"	Displays status (ignition switch ACC or IGN position: ON/other: OFF) of ignition switch judged from the ignition switch signal.
HI BEAM SW "ON/OFF"	Displays status (lighting switch high beam position: ON/other: OFF) of high beam switch judged from the lighting switch signal.
HEAD LAMP SW 1 "ON/OFF"	Displays status (lighting switch 2ND position: ON/other: OFF) of headlamp 1 switch judged from the lighting switch signal.
HEAD LAMP SW 2 "ON/OFF"	Displays status (lighting switch 2ND position: ON/other: OFF) of headlamp 2 switch judged from the lighting switch signal.
LIGHT SW 1ST "ON/OFF"	Displays status (lighting switch 1ST or 2ND position: ON/other: OFF) of lighting switch 1ST position switch judged from the lighting switch signal.
AUTO LIGHT SW <sup>NOTE 1</sup> "ON/OFF"	Displays status (lighting switch AUTO position: ON/other: OFF) of auto light switch position judged from the lighting switch signal.
PASSING SW "ON/OFF"	Displays status (lighting switch passing position: ON/other: OFF) of passing switch judged from the lighting switch signal.
FR FOG SW "ON/OFF"	Displays status (lighting switch front fog lamp ON position: ON/others: OFF) of front fog lamp switch judged from the lighting switch signal.
RR FOG SW <sup>NOTE 2</sup> "ON/OFF"	—
DOOR SW - DR "ON/OFF"	Displays status (door is open: ON/door is closed: OFF) of driver side door switch judged from the driver side door switch signal.

## HEADLAMP - XENON TYPE -

Monitor item	Contents
DOOR SW - AS "ON/OFF"	Displays status (door is open: ON/door is closed: OFF) of passenger side door switch judged from the passenger side door switch signal.
DOOR SW - RR <sup>NOTE 2</sup> "OFF"	—
DOOR SW - RL <sup>NOTE 2</sup> "OFF"	—
BACK DOOR SW <sup>NOTE 2</sup> "OFF"	—
TURN SIGNAL R "ON/OFF"	Displays status (turn signal switch right position: ON/other: OFF) of turn RH switch judged from the turn signal switch signal.
TURN SIGNAL L "ON/OFF"	Displays status (turn signal switch left position: ON/other: OFF) of turn LH switch judged from the turn signal switch signal.
ENGINE RUN <sup>NOTE 3</sup> "ON/OFF"	Displays status (Engine running: ON/Other: OFF) as judged from engine status signal.
PKB SW <sup>NOTE 3</sup> "ON/OFF"	Displays status (Parking brake switch: ON/Other: OFF) of parking brake switch judged from parking brake switch signal.
CARGO LAMP SW <sup>NOTE 2</sup> "OFF"	—
OPTICAL SENSOR <sup>NOTE 1</sup> "0 - 5 V"	Displays status "outside brightness (close to 5 V when light/close to 0 V when dark)" of optical sensor judged from the optical sensor signal.

**NOTE:**

1. Vehicles without auto light system display this item, but cannot be monitored.
2. This item is displayed, but cannot be monitored.
3. Vehicles without daytime light system does not display this item.

### ACTIVE TEST

#### Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
3. Touch item to be tested and check operation of the selected item.
4. During the operation check, touching "OFF" deactivates the operation.

#### Display Item List

Test item	Description
TAIL LAMP	Allows tail lamp relay to operate by switching ON-OFF.
HEAD LAMP	Allows headlamp high relay and headlamp low relay to operate by switching ON-OFF.
FR FOG LAMP	Allows front fog lamp relay to operate by switching ON-OFF.
DTRL <sup>NOTE1</sup>	Allows daytime light lamp operate by switching ON-OFF.
CORNERING LAMP <sup>NOTE 2</sup>	—

**NOTE:**

1. Vehicles without daytime light lamp system does not display this item.
2. This item is displayed, but can not be tested.

### CONSULT-II Functions (IPDM E/R)

NKS002NO

CONSULT-II can display each diagnostic item using the diagnostic test mode shown following.

Diagnosis Mode	Description
SELF-DIAGNOSTIC RESULTS	Refer to <a href="#">PG-18, "SELF-DIAG RESULTS"</a> .
DATA MONITOR	The input/output data of IPDM E/R is displayed in real time.
CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.
ACTIVE TEST	IPDM E/R sends a drive signal to electronic components to check their operation.

### CONSULT-II BASIC OPERATION

Refer to [GI-37, "CONSULT-II Start Procedure"](#) .

# HEADLAMP - XENON TYPE -

## DATA MONITOR

### Operation Procedure

1. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
2. Touch "ALL SIGNALS", "MAIN SIGNALS" or "SELECTION FROM MENU" on "SELECT MONITOR ITEM" screen.

ALL SIGNALS	Monitors all items.
MAIN SIGNALS	Monitor the predetermined item.
SELECTION FROM MENU	Selects items and monitors them.

3. When "SELECTION FROM MENU" is selected, touch individual items to be monitored. In "ALL SIGNALS", all items are monitored. In "MAIN SIGNALS", predetermined items are monitored.
4. Touch "START".
5. Touch "RECORD" while monitoring to record the status of the item being monitored. To stop recording, touch "STOP".

### All Signals, Main Signals, Selection From Menu

Item name	CONSULT-II screen display	Display or unit	Monitor item selection			Description
			ALL SIGNALS	MAIN SIGNALS	SELECTION FROM MENU	
Position lights request	TAIL&CLR REQ	ON/OFF	×	×	×	Signal status input from BCM
Headlamp low beam request	HL LO REQ	ON/OFF	×	×	×	Signal status input from BCM
Headlamp high beam request	HL HI REQ	ON/OFF	×	×	×	Signal status input from BCM
Front fog lights request	FR FOG REQ	ON/OFF	×	×	×	Signal status input from BCM

#### NOTE:

Perform monitoring of IPDM E/R data with ignition switch ON. When ignition switch is at ACC, display may not be correct.

## ACTIVE TEST

### Operation Procedure

1. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Touch item to be tested, and check operation.
3. Touch "START".
4. Touch "STOP" while testing to stop the operation.

Test item	CONSULT-II screen display	Description
Headlamp relay (HI, LO) output	LAMPS	Allows headlamp relay (HI, LO) to operate by switching operation (OFF, HI ON, LO ON) at your option.
Front fog lamp relay output		Allows front fog lamp relay to operate by switching operation ON-OFF at your option.
Tail lamp relay output	TAIL LAMP	Allows tail lamp relay to operate by switching operation ON-OFF at your option.

# HEADLAMP - XENON TYPE -

## Headlamp Does Not Change To High Beam (Both Sides)

NKS002NP

### 1. CHECK COMBINATION SWITCH INPUT SIGNAL

④ With CONSULT-II

Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "HI BEAM SW" turns ON-OFF linked with operation of lighting switch.

**When lighting switch is HIGH BEAM position : HI BEAM SW ON**

⊗ Without CONSULT-II

Refer to [LT-100, "Combination Switch Inspection"](#).

OK or NG

OK >> GO TO 2.

NG >> Check combination switch (lighting switch). Refer to [LT-100, "Combination Switch Inspection"](#).

DATA MONITOR			
MONITOR			
HI BEAM SW	ON		
		RECORD	
MODE	BACK	LIGHT	COPY

PKIA7585E

### 2. HEADLAMP ACTIVE TEST

④ With CONSULT-II

1. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "LAMPS" on "SELECT TEST ITEM" screen.
3. Touch "HI" screen.
4. Make sure headlamp high beam operates.

**Headlamp high beam should operate.  
(Headlamp high beam repeats ON-OFF every 1 second.)**

⊗ Without CONSULT-II

1. Start auto active test. Refer to [PG-21, "Auto Active Test"](#).
2. Make sure headlamp high beam operates.

**Headlamp high beam should operate.**

OK or NG

OK >> GO TO 3.

NG >> GO TO 4.

ACTIVE TEST			
LAMPS		OFF	
		HI	
LO		FOG	
MODE	BACK	LIGHT	COPY

SKIA5774E

### 3. CHECK IPDM E/R

1. Select "IPDM E/R" on CONSULT-II, and select "DATA MONITOR" on "SELECT DIAG MODE" screen.
2. Make sure "HL LO REQ" and "HL HI REQ" turns ON when lighting switch is in HIGH BEAM position.

**When lighting switch is HIGH BEAM position : HL LO REQ ON  
: HL HI REQ ON**

OK or NG

OK >> Replace IPDM E/R. Refer to [PG-27, "Removal and Installation of IPDM E/R"](#).

NG >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#).

DATA MONITOR			
MONITOR			
HL LO REQ	ON		
HL HI REQ	ON		
		Page Down	
		RECORD	
MODE	BACK	LIGHT	COPY


SKIA5775E

# HEADLAMP - XENON TYPE -

## 4. CHECK HEADLAMP INPUT SIGNAL

With CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH and LH connectors.
3. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
4. Select "LAMPS" on "SELECT TEST ITEM" screen.
5. Touch "HI" screen.
6. When headlamp high relay is operating, check voltage between front combination lamp harness connector and ground (headlamp high beam repeats ON-OFF every 1 second).



(+)		Terminal	(-)	Voltage
Front combination lamp connector				
RH	E24	2	Ground	Battery voltage
LH	E41	2		

Without CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH and LH connectors.
3. Start auto active test. Refer to [PG-21, "Auto Active Test"](#).
4. When headlamp high relay is operating, check voltage between front combination lamp harness connector and ground.

(+)		Terminal	(-)	Voltage
Front combination lamp connector				
RH	E24	2	Ground	Battery voltage
LH	E41	2		

OK or NG

- OK >> GO TO 6.  
 NG >> GO TO 5.


## 5. CHECK HEADLAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector E7 terminal 27 and front combination lamp RH harness connector E24 terminal 2.

**27 – 2 : Continuity should exist.**

4. Check continuity between IPDM E/R harness connector E7 terminal 28 and front combination lamp LH harness connector E41 terminal 2.

**28 – 2 : Continuity should exist.**



OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-27, "Removal and Installation of IPDM E/R"](#).  
 NG >> Repair harness or connector.

# HEADLAMP - XENON TYPE -

## 6. CHECK HEADLAMP GROUND

1. Check continuity between front combination lamp RH harness connector E24 terminal 4 and ground.

**4 – Ground : Continuity should exist.**


2. Check continuity between front combination lamp LH harness connector E41 terminal 4 and ground.

**4 – Ground : Continuity should exist.**

OK or NG

OK >> Replace front combination lamp. Refer to [LT-32, "Removal and Installation"](#).

NG >> Repair harness or connector.




## Headlamp Does Not Change To High Beam (One Side)

NKS002N0

### 1. CHECK HEADLAMP INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH or LH connectors.
3. Turn ignition switch ON.
4. Lighting switch is turned HIGH BEAM position.
5. Check voltage between front combination lamp harness connector and ground.



		(+)	(-)	Voltage
Front combination lamp connector		Terminal		
RH	E24	2	Ground	Battery voltage
LH	E41	2		

OK or NG

OK >> GO TO 3.

NG >> GO TO 2.


### 2. CHECK HEADLAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector E7 terminal 27 and front combination lamp RH harness connector E24 terminal 2.

**27 – 2 : Continuity should exist.**

4. Check continuity between IPDM E/R harness connector E7 terminal 28 and front combination lamp LH harness connector E41 terminal 2.

**28 – 2 : Continuity should exist.**



OK or NG

OK >> Replace IPDM E/R. Refer to [PG-27, "Removal and Installation of IPDM E/R"](#).

NG >> Repair harness or connector.

# HEADLAMP - XENON TYPE -

## 3. CHECK HEADLAMP GROUND

1. Check continuity between front combination lamp RH harness connector E24 terminal 4 and ground.

**4 – Ground : Continuity should exist.**


2. Check continuity between front combination lamp LH harness connector E41 terminal 4 and ground.

**4 – Ground : Continuity should exist.**

OK or NG

OK >> Replace front combination lamp. Refer to [LT-32, "Removal and Installation"](#).

NG >> Repair harness or connector.



## Headlamp Does Not Illuminate (Both Sides)

NKS002NS

### 1. CHECK COMBINATION SWITCH INPUT SIGNAL

☑ With CONSULT-II

Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "HEAD LAMP SW 1" and "HEAD LAMP SW 2" turns ON-OFF linked with operation of lighting switch.

**When lighting switch is 2ND position : HEAD LAMP SW 1 ON  
: HEAD LAMP SW 2 ON**

☒ Without CONSULT-II

Refer to [LT-100, "Combination Switch Inspection"](#).

OK or NG

OK >> GO TO 2.

NG >> Check combination switch (lighting switch). Refer to [LT-100, "Combination Switch Inspection"](#).

DATA MONITOR			
MONITOR			
HEAD LAMP SW1	ON		
HEAD LAMP SW2	ON		
		RECORD	
MODE	BACK	LIGHT	COPY

PKIA7586E

## 2. HEADLAMP ACTIVE TEST

☑ With CONSULT-II

1. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "LAMPS" on "SELECT TEST ITEM" screen.
3. Touch "LO" screen.
4. Make sure headlamp low beam operates.

**Headlamp low beam should operate.**

☒ Without CONSULT-II

1. Start auto active test. Refer to [PG-21, "Auto Active Test"](#).
2. Make sure headlamp low beam operates.

**Headlamp low beam should operate.**

OK or NG

OK >> GO TO 3.

NG >> GO TO 4.

ACTIVE TEST			
LAMPS	OFF		
		HI	
LO	FOG		
		RECORD	
MODE	BACK	LIGHT	COPY

SKIA5774E

# HEADLAMP - XENON TYPE -

## 3. CHECK IPDM E/R

1. Select "IPDM E/R" on CONSULT-II, and select "DATA MONITOR" on "SELECT DIAG MODE" screen.
2. Make sure "HL LO REQ" turns ON when lighting switch is in 2ND position.

**When lighting switch is 2ND : HL LO REQ ON position**

DATA MONITOR			
MONITOR			
HL LO REQ	ON		
			Page Down
			RECORD
MODE	BACK	LIGHT	COPY

SKIA5780E


### OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-27, "Removal and Installation of IPDM E/R"](#) .
- NG >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#) .

## 4. CHECK HEADLAMP INPUT SIGNAL

### ☑ With CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH and LH connectors.
3. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
4. Select "LAMPS" on "SELECT TEST ITEM" screen.
5. Touch "LO" screen.
6. When headlamp low relay is operating, check voltage between front combination lamp harness connector and ground.



(+)		Terminal	(-)	Voltage
Front combination lamp connector				
RH	E24	3	Ground	Battery voltage
LH	E41	3		

### ☒ Without CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH and LH connectors.
3. Start auto active test. Refer to [PG-21, "Auto Active Test"](#) .
4. When headlamp low relay is operating, check voltage between front combination lamp harness connector and ground.

(+)		Terminal	(-)	Voltage
Front combination lamp connector				
RH	E24	3	Ground	Battery voltage
LH	E41	3		

### OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.



# HEADLAMP - XENON TYPE -


## 5. CHECK HEADLAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector E7 terminal 20 and front combination lamp RH harness connector E24 terminal 3.

**20 – 3 : Continuity should exist.**

4. Check continuity between IPDM E/R harness connector E7 terminal 30 and front combination lamp LH harness connector E41 terminal 3.

**30 – 3 : Continuity should exist.**



OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-27, "Removal and Installation of IPDM E/R"](#).
- NG >> Repair harness or connector.


## 6. CHECK HEADLAMP GROUND

1. Turn ignition switch OFF.
2. Check continuity between front combination lamp RH harness connector E24 terminal 4 and ground.

**4 – Ground : Continuity should exist.**

3. Check continuity between front combination lamp LH harness connector E41 terminal 4 and ground.

**4 – Ground : Continuity should exist.**



OK or NG

- OK >> Check headlamp harness and connectors, ballasts (HID control unit), and xenon bulbs. Refer to [LT-28, "Xenon Headlamp Trouble Diagnosis"](#).
- NG >> Repair harness or connector.

## Headlamp Does Not Illuminate (One Side)

NKS002NT

### 1. CHECK BULB

Check ballast (HID control unit) and xenon bulb of lamp which does not illuminate. Refer to [LT-28, "Xenon Headlamp Trouble Diagnosis"](#).

OK or NG


- OK >> GO TO 2.
- NG >> Replace malfunctioning part.

# HEADLAMP - XENON TYPE -

## 2. CHECK HEADLAMP INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH or LH connectors.
3. Turn ignition switch ON.
4. Lighting switch is turned 2ND position.
5. Check voltage between front combination lamp harness connector and ground.

Front combination lamp connector		(+)	(-)	Voltage
RH	E24	3	Ground	Battery voltage
LH	E41	3		



OK or NG

- OK >> GO TO 4.  
 NG >> GO TO 3.


## 3. CHECK HEADLAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector E7 terminal 20 and front combination lamp RH harness connector E24 terminal 3.

**20 – 3 : Continuity should exist.**

4. Check continuity between IPDM E/R harness connector E7 terminal 30 and front combination lamp LH harness connector E41 terminal 3.

**30 – 3 : Continuity should exist.**



OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-27, "Removal and Installation of IPDM E/R"](#) .  
 NG >> Repair harness or connector.

## 4. CHECK HEADLAMP GROUND

1. Check continuity between front combination lamp RH harness connector E24 terminal 4 and ground.


**4 – Ground : Continuity should exist.**

2. Check continuity between front combination lamp LH harness connector E41 terminal 4 and ground.

**4 – Ground : Continuity should exist.**

OK or NG

- OK >> Check headlamp harness and connector.  
 NG >> Repair harness or connector.



# HEADLAMP - XENON TYPE -

NKS002NW

## Headlamps Do Not Turn OFF

### 1. CHECK HEADLAMP TURN OFF

Make sure that lighting switch is OFF. And make sure headlamp turns off when ignition switch is turned OFF.

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.

### 2. CHECK COMBINATION SWITCH INPUT SIGNAL

Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "HEAD LAMP SW 1" and "HEAD LAMP SW 2" turns ON-OFF linked with operation of lighting switch.

**When lighting switch is OFF : HEAD LAMP SW 1 OFF position : HEAD LAMP SW 2 OFF**

OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-27, "Removal and Installation of IPDM E/R"](#).
- NG >> Check combination switch (lighting switch). Refer to [LT-100, "Combination Switch Inspection"](#).

DATA MONITOR			
MONITOR			
HEAD LAMP SW1	OFF		
HEAD LAMP SW2	OFF		
		Page Down	
		RECORD	
MODE	BACK	LIGHT	COPY

PKIA7588E

### 3. CHECKING CAN COMMUNICATIONS BETWEEN BCM AND IPDM E/R

Select "BCM" on CONSULT-II, and perform self-diagnosis for "BCM".

Display of self-diagnosis results

- NO DTC>> Replace IPDM E/R. Refer to [PG-27, "Removal and Installation of IPDM E/R"](#).
- CAN COMM CIRCUIT>> Refer to [BCS-15, "CAN Communication Inspection Using CONSULT-II \(Self-Diagnosis\)"](#).

SELF-DIAG RESULTS			
DTC RESULTS		TIME	
CAN COMM CIRCUIT [U1000]			
ERASE		PRINT	
MODE	BACK	LIGHT	COPY

PKIA7627E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# HEADLAMP - XENON TYPE -

## General Information for Xenon Headlamp Trouble Diagnosis

NKS002NX

In most cases, malfunction of xenon headlamp - "does not illuminate", "flickers" or "dark" - is caused by a malfunctioning xenon bulb. A malfunctioning HID control unit or lamp housing, however, may be a cause. Be sure to perform trouble diagnosis following the steps described below.

### Caution:

NKS002NY

- Installation or removal of connector must be done with lighting switch OFF.
- Disconnect the battery cable from the negative terminal or remove power fuse.

#### **CAUTION:**

**After the battery cables are disconnected, never open/close the driver and/or front passenger door with the window in the full up position. The automatic window adjusting function will not work and the side roof panel may be damaged.**

- When the lamp is illuminated (when lighting switch is ON), never touch harness, HID control unit, inside of lamp, or lamp metal parts.
- To check illumination, temporarily install lamp in vehicle. Be sure to connect power at vehicle side connector.
- If error can be traced directly to electrical system, first check for items such as blown fuses and fusible links, broken wires or loose connectors, dislocated terminals, and improper connections.
- Never work with wet hands.
- Using a tester for HID control unit circuit trouble diagnosis is prohibited.
- Disassembling HID control unit or harnesses (bulb socket harness, ECM harness) is prohibited.
- Immediately after illumination, light intensity and color will fluctuate, but there is nothing wrong.
- When bulb has come to end of its life, brightness will drop significantly, it will flash repeatedly, or light color will turn reddish.

## Xenon Headlamp Trouble Diagnosis

NKS002NZ

### 1. CHECK 1: XENON HEADLAMP LIGHTING

Install normal xenon bulb to corresponding xenon bulb headlamp, and check if lamp lights up.

#### OK or NG

- OK >> Replace xenon bulb.
- NG >> GO TO 2.

### 2. CHECK 2: XENON HEADLAMP LIGHTING

Install normal HID control unit to corresponding xenon headlamp, and check if lamp lights up.

#### OK or NG

- OK >> Replace HID control unit.
- NG >> GO TO 3.

### 3. CHECK 3: XENON HEADLAMP LIGHTING

Install normal xenon lamp housing assembly to corresponding xenon headlamp, and check if lamp lights up.


#### OK or NG

- OK >> Replace xenon headlamp housing assembly. [Malfunction in starter (boosting circuit) in xenon headlamp housing]
- NG >> INSPECTION END

# HEADLAMP - XENON TYPE -

## Aiming Adjustment

NKS00200



### PREPARATION BEFORE ADJUSTING

**For Details, Refer to the Regulations in Your Own Country.**

Before performing aiming adjustment, check the following.

1. Keep all tires inflated to correct pressures.
2. Place vehicle on level ground.
3. Set that there is no-load in vehicle other than the driver (or equivalent weight placed in driver's position). Coolant, engine oil filled up to correct level and full fuel tank.


### LOW BEAM AND HIGH BEAM

1. Turn headlamp low beam ON.
2. Use adjusting screws to perform aiming adjustment.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# HEADLAMP - XENON TYPE -

## ADJUSTMENT USING AN ADJUSTMENT SCREEN (LIGHT/DARK BORDERLINE)



If the vehicle front body has been repaired and/or the headlamp assembly has been replaced, check aiming. Use the aiming chart shown in the figure.

- Basic illumination area for adjustment should be within the range shown on the aiming chart. Adjust headlamp accordingly.

## Bulb Replacement HEADLAMP LOW/HIGH BEAM


NKS00201

1. Turn lighting switch OFF.
2. Open the driver and front passenger window, and then disconnect the battery cable from the negative terminal or remove power fuse.

### CAUTION:

After the battery cables are disconnected, never open/close the driver and/or front passenger door with the window in the full up position. The automatic window adjusting function will not work and the side roof panel may be damaged.

3. Remove headlamp. Refer to [LT-32, "Removal and Installation"](#).
4. Turn plastic cap counterclockwise and unlock it.
5. Turn bulb socket counterclockwise and unlock it.
6. Unlock retaining spring and remove bulb from headlamp.
7. Installation is the reverse order of removal.



# HEADLAMP - XENON TYPE -

## FRONT FOG LAMP

1. Turn lighting switch OFF. A
2. Open the driver and front passenger window, and then disconnect the battery cable from the negative terminal or remove power fuse. B

### CAUTION:

**After the battery cables are disconnected, never open/close the driver and/or front passenger door with the window in the full up position. The automatic window adjusting function will not work and the side roof panel may be damaged.** C

3. Remove fender protector (front). Refer to [EI-20, "FENDER PROTECTOR"](#) . D
4. Turn plastic cap counterclockwise and unlock it.
5. Disconnect bulb terminal.
6. Unlock retaining spring and remove bulb from headlamp.
7. Installation is the reverse order of removal. E

## PARKING LAMP

1. Turn lighting switch OFF. F
2. Open the driver and front passenger window, and then disconnect the battery cable from the negative terminal or remove power fuse. G

### CAUTION:

**After the battery cables are disconnected, never open/close the driver and/or front passenger door with the window in the full up position. The automatic window adjusting function will not work and the side roof panel may be damaged.** H

3. Remove fender protector (front). Refer to [EI-20, "FENDER PROTECTOR"](#) . I
4. Push the claw of bulb socket and remove it.
5. Remove bulb from its socket.
6. Installation is the reverse order of removal. J

## FRONT TURN SIGNAL LAMP

1. Turn lighting switch OFF. LT
2. Open the driver and front passenger window, and then disconnect the battery cable from the negative terminal or remove power fuse. L

### CAUTION:

**After the battery cables are disconnected, never open/close the driver and/or front passenger door with the window in the full up position. The automatic window adjusting function will not work and the side roof panel may be damaged.** M

3. Remove fender protector (front). Refer to [EI-20, "FENDER PROTECTOR"](#) . L
4. Turn bulb socket counterclockwise and unlock it.
5. Remove bulb from its socket.
6. Installation is the reverse order of removal. M

Headlamp low/high beam (Xenon)	: 12 V - 35 W (D2S)
Front fog lamp	: 12 V - 55 W (H1)
Parking lamp	: 12 V - 5 W
Front turn signal lamp	: 12 V - 21 W (amber bulb)

### CAUTION:

**After installing bulb, be sure to install plastic cap and bulb socket securely to insure watertightness.**

# HEADLAMP - XENON TYPE -

NKS00202

## Removal and Installation

### REMOVAL

1. Open the driver and front passenger window, and then disconnect the battery cable from the negative terminal or remove power fuse.



**CAUTION:**

After battery cables are disconnected, never open/close the driver and/or front passenger door with the window in the full up position. The automatic window adjusting function will not work and the side roof panel may be damaged.

2. Remove front grille. Refer to [EI-18, "FRONT GRILLE"](#).
3. Remove front undercover and fender protector. Refer to [EI-20, "FENDER PROTECTOR"](#).
4. Remove mounting clip on top of front bumper and screws on side of front bumper. Refer to [EI-14, "FRONT BUMPER"](#).
5. Pull side of front bumper toward the vehicle front and disengage it from clips on the body.
6. Remove headlamp mounting bolts.
7. Pull headlamp toward the vehicle front, disconnect connector, and remove headlamp.

**CAUTION:**

When removing headlamps, put a shop cloth or something similar between headlamps and bumper to protect bumper.



### INSTALLATION

Installation is the reverse order of removal.


**Headlamp mounting bolt**  : 5.9 N-m (0.60 kg-m, 52 in-lb)



# HEADLAMP - XENON TYPE -

## Disassembly

NKS00203



PKIC5942E

- |                                      |  |                                 |
|--------------------------------------|--|---------------------------------|
| 1. High beam solenoid connector      | 2. Xenon bulb (high/low)               | 3. Seal packing                 |
| 4. Plastic cap (high/low)            | 5. Xenon bulb socket                   | 6. Halogen bulb (front fog)     |
| 7. Halogen bulb power supply harness | 8. Halogen bulb ground harness         | 9. Seal packing                 |
| 10. Plastic cap (front fog)          | 11. Parking lamp bulb                  | 12. Parking lamp bulb socket    |
| 13. Headlamp assembly connector      | 14. Front turn signal lamp bulb socket | 15. Front turn signal lamp bulb |
| 16. HID C/U connector                | 17. Screw                              | 18. HID C/U                     |
| 19. Seal packing                     | 20. HID connector                      | 21. Screw                       |
| 22. Headlamp housing assembly        |  |                                 |

1. Turn the plastic cap (high/low) counterclockwise and remove it.
2. Disconnect the high beam solenoid connector.
3. Turn the xenon bulb socket counterclockwise and remove it.
4. Unlock the retaining spring and remove the xenon bulb (high/low).
5. Disconnect the HID C/U connector.
6. Remove the mounting screws from the HID C/U.
7. Disconnect the HID connector and remove a screw from the HID C/U.
8. Turn the plastic cap (front fog) counterclockwise and remove it.
9. Disconnect the halogen bulb power supply harness and halogen bulb ground harness from the halogen bulb (front fog).
10. Unlock the retaining spring and remove the halogen bulb (front fog).
11. Push the claw of the parking lamp bulb socket and remove it.
12. Remove the parking lamp bulb from its socket.
13. Turn the front turn signal lamp bulb socket counterclockwise and remove it.
14. Remove the front turn signal lamp bulb from its socket.
15. Remove the headlamp assembly connector.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# HEADLAMP - XENON TYPE -

## Assembly

NKS00204

Assembly is the reverse order of disassembly.

**HID control unit**  : 3.2 N·m (0.33 kg·m, 28 in·lb)


### CAUTION:

- When HID control unit is removed, reinstall it securely and avoid any looseness.
- After installing bulb, be sure to install plastic cap and bulb socket securely to insure watertightness.

## Servicing to Replace Headlamps When Damaged


NKS00205

If only installation part as shown in the figure is damaged, and headlamp housing itself is not damaged, repair can be completed easily by installing correction brackets.



## REMOVAL AND INSTALLATION

1. Remove headlamps. Refer to [LT-32, "Removal and Installation"](#).
2. Cut damaged section of installation part, and then shape with sandpaper.
3. Attach Inner side bracket to headlamp housing boss with 2 screws.




# DAYTIME LIGHT SYSTEM

## DAYTIME LIGHT SYSTEM

PFP:284B2

### Component Parts and Harness Connector Location

NKS0027G



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

PKIC5973E

### System Description

NKS0027H

Daytime light system turns ON daytime light lamps (front fog lamps) while driving. Daytime light lamps are not turned ON if engine is activated with parking brake ON. Release parking brake to turn on daytime light lamps. The lamps turn OFF when lighting switch is in the 2ND position or AUTO position (headlamp is ON) and when lighting switch is in the PASSING position. (Daytime light lamps are not turned off only by parking brake itself.) A parking brake signal and engine run or stop signal are sent to BCM (body control module) by CAN communication line, and control daytime light system.

### OUTLINE

Power is supplied at all times

- to ignition relay located in IPDM E/R (intelligent power distribution module engine room), from battery direct,

# DAYTIME LIGHT SYSTEM

---

- through 15A fuse (No. 88, located in IPDM E/R)
- to front fog lamp relay located in IPDM E/R,
- through 10A fuse (No. 71, located in IPDM E/R)
- to CPU (central processing unit) located in IPDM E/R,
- through 15A fuse (No. 78, located in IPDM E/R)
- to CPU located in IPDM E/R,
- through 50A fusible link (letter F, located in fuse and fusible link block)
- to BCM terminal 55,
- through 10A fuse [No. 18, located in fuse block (J/B)]
- to BCM terminal 42,
- through 10A fuse [No. 19, located in fuse block (J/B)]
- to combination meter terminal 21.

When the ignition switch is in ON or START position, power is supplied

- to ignition relay located in IPDM E/R, from battery direct,
- through 10A fuse [No. 1, located in fuse block (J/B)]
- to BCM terminal 38,
- through 10A fuse [No. 14, located in fuse block (J/B)]
- to combination meter terminals 22 and 23.

When the ignition switch is in ACC or ON position, power is supplied

- through 10A fuse [No. 6, located in fuse block (J/B)]
- to BCM terminal 11.

Ground is supplied

- to BCM terminal 52 and
- to combination meter terminals 1, 24 and 25
- through grounds M30 and M66,
- to IPDM E/R terminals 38 and 60
- through grounds E17 and E43.

## DAYTIME LIGHT OPERATION

With the engine running, the lighting switch in the OFF or 1ST position and parking brake released, the CPU located in the IPDM E/R grounds the coil side of the front fog lamp relay. The front fog lamp relay then directs power

- through IPDM E/R terminal 37
- to front combination lamp LH terminal 1,
- through IPDM E/R terminal 36
- to front combination lamp RH terminal 1.

Ground is supplied

- to front fog lamp RH and LH terminals 8
- through grounds E17 and E43.

With power and grounds supplied, the front fog lamps illuminate.

## COMBINATION SWITCH READING FUNCTION

Refer to [BCS-3, "COMBINATION SWITCH READING FUNCTION"](#) .

## EXTERIOR LAMP BATTERY SAVER CONTROL

With the combination switch (lighting switch) is in the 2ND position and the ignition switch is turned from ON or ACC to OFF, the battery saver control function is activated.

Under this condition, the front fog lamps remain illuminated for 5 minutes, and then the front fog lamps are turned off.

Exterior lamp battery saver control made can be changed by the function setting of CONSULT-II.

## AUTO LIGHT OPERATION

For auto light operation, refer to [LT-51, "System Description"](#) .

# DAYTIME LIGHT SYSTEM

## CAN Communication System Description

NKS0027I

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

## CAN Communication Unit

NKS0027J

Refer to [LAN-47, "CAN System Specification Chart"](#) .

A

B

C

D

E

F

G

H

I

J

LT


L

M

# DAYTIME LIGHT SYSTEM

## Schematic

NKS0027K



\* : This relay is built into the IPDME/R (Intelligent power distribution module engine room).

TKWM3447E


# DAYTIME LIGHT SYSTEM

## Wiring Diagram — DTRL —

NKS0027L

LT-DTRL-01

▬ : DATA LINE






7	8	9	10	13	12
6	5	4	3	2	1

(M29) W

# DAYTIME LIGHT SYSTEM

LT-DTRL-02



REFER TO THE FOLLOWING.  
 (B1) -SUPER MULTIPLE JUNCTION (SMJ)


TKWM4012E




# DAYTIME LIGHT SYSTEM

LT-DTRL-03

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M



(A) : WITH A/T  
(M) : WITH M/T





REFER TO THE FOLLOWING.  
(E108), (F102), (B1) -SUPER MULTIPLE JUNCTION (SMJ)  
(M4) -FUSE BLOCK-JUNCTION BOX (J/B)

TKWM3451E


# DAYTIME LIGHT SYSTEM

LT-DTRL-04

▬ : DATA LINE



(M8)  
W



(M19)  
W

TKWM3452E

# DAYTIME LIGHT SYSTEM

## Terminals and Reference Values for BCM

NKS0027M

**CAUTION:**







- Check combination switch system terminal waveform under the loaded condition with lighting switch, turn signal switch and wiper switch OFF not to be fluctuated by overloaded.
- Turn wiper dial position to 4 except when checking waveform or voltage of wiper dial position. Wiper dial position can be confirmed on CONSULT-II. Refer to [LT-17, "DATA MONITOR"](#).

Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
2	G/R	Combination switch input 5	ON	OFF	Approx. 0 V
				Lighting switch 2ND	<p style="text-align: right; font-size: small;">PKIB4953J</p>
3	G	Combination switch input 4	ON	OFF	Approx. 0 V
				Front fog lamp switch (Operate only front fog lamp switch)	<p style="text-align: right; font-size: small;">PKIB4955J</p>
				Any of the conditions below	<ul style="list-style-type: none"> <li>● Lighting switch 2ND</li> <li>● Lighting switch PASSING (Operates only PASSING switch)</li> </ul> <p style="text-align: right; font-size: small;">PKIB4959J</p>
4	W/L	Combination switch input 3	ON	OFF	Approx. 0 V
				Any of the conditions below	<ul style="list-style-type: none"> <li>● Lighting switch AUTO</li> </ul> <p style="text-align: right; font-size: small;">PKIB4959J</p>
11	LG	Ignition switch (ACC)	ACC	—	Battery voltage



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LT

# DAYTIME LIGHT SYSTEM

Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
32	GY	Combination switch output 5	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	OFF  Approx. 7.2 V
					Front fog lamp switch (Operates only front fog lamp switch)  Approx. 1.0 V
33	L	Combination switch output 4	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	OFF  Approx. 7.2 V
					Lighting switch AUTO  Approx. 1.2 V
34	PU	Combination switch output 3	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	OFF  Approx. 7.2 V
					Lighting switch 2ND  Approx. 1.2 V

# DAYTIME LIGHT SYSTEM

Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
35	Y/R	Combination switch output 2	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	OFF  PKIB4960J Approx. 7.2 V
					Any of the conditions below <ul style="list-style-type: none"> <li>● Lighting switch 2ND</li> <li>● Lighting switch PASSING (Operates only PASSING switch)</li> </ul>  PKIB4958J Approx. 1.2 V
38	W/L	Ignition switch (ON)	ON	—	Battery voltage
39	L	CAN - H	—	—	—
40	P	CAN - L	—	—	—
42	GY	Battery power supply	OFF	—	Battery voltage
52	B	Ground	ON	—	Approx. 0 V
55	W/R	Battery power supply	OFF	—	Battery voltage

## Terminals and Reference Values for IPDM E/R

NKS0027N

Terminal No.	Wire color	Signal name	Measuring condition		Reference value	
			Ignition switch	Operation or condition		
36	W/G	Front fog lamp (RH)	ON	Lighting switch must be in the 2ND position or AUTO position (LOW beam is ON) and the front fog lamp switch must be ON.	OFF	Approx. 0 V
					ON	Battery voltage
37	SB	Front fog lamp (LH)	ON	Lighting switch must be in the 2ND position or AUTO position (LOW beam is ON) and the front fog lamp switch must be ON.	OFF	Approx. 0 V
					ON	Battery voltage
38	B/R	Ground	ON	—	Approx. 0 V	
48	L	CAN - H	—	—	—	
49	P	CAN - L	—	—	—	
60	B/R	Ground	ON	—	Approx. 0 V	

## How to Proceed With Trouble Diagnosis

NKS0027O

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-35, "System Description"](#) .
3. Perform the Preliminary Check. Refer to [LT-46, "Preliminary Check"](#) .
4. Check symptom and repair or replace the cause of malfunction.
5. Does the front fog lamp operate normally? If YES, GO TO 6. If NO, GO TO 4.
6. INSPECTION END

# DAYTIME LIGHT SYSTEM

NKS0027P

## Preliminary Check CHECK POWER SUPPLY AND GROUND CIRCUIT

### 1. CHECK FUSES AND FUSIBLE LINK

Check for blown fuses and fusible link.

Unit	Power source	Fuse and fusible link No.
BCM	Battery	F
		18
	Ignition switch ON or START position	1
	Ignition switch ACC or ON position	6
IPDM E/R	Battery	88

Refer to [LT-39, "Wiring Diagram — DTRL —"](#).

OK or NG

OK >> GO TO 2.

NG >> If fuse or fusible link is blown, be sure to eliminate cause of malfunction before installing new fuse or fusible link. Refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#).

### 2. CHECK POWER SUPPLY CIRCUIT


- Turn ignition switch OFF.
- Disconnect BCM connector.
- Check voltage between BCM harness connector and ground.

(+)		(-)	Ignition switch position		
BCM connector	Terminal		OFF	ACC	ON
M1	11	Ground	Approx. 0 V	Battery voltage	Battery voltage
	38		Approx. 0 V	Approx. 0 V	Battery voltage
M2	42		Battery voltage	Battery voltage	Battery voltage
	55		Battery voltage	Battery voltage	Battery voltage

OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.



### 3. CHECK GROUND CIRCUIT


Check continuity between BCM harness connector and ground.

BCM connector	Terminal	Ground	Continuity
M2	52		Yes

OK or NG

OK >> INSPECTION END

NG >> Repair harness or connector.



# DAYTIME LIGHT SYSTEM

## CHECK PARKING BRAKE SWITCH CIRCUIT

### 1. CHECK BRAKE INDICATOR

1. Turn ignition switch ON.
2. When parking brake is made ON/OFF, it checks whether the brake indicator lamp of combination meter lights up/puts out the light.

OK or NG

- OK >> INSPECTION END  
 NG >> GO TO 2.

### 2. CHECK PARKING BRAKE SWITCH SIGNAL

1. Turn ignition switch ON.
2. Check voltage between parking brake switch harness connector and ground, when parking brake is released.

(+)		(-)	Condition	Voltage
Parking brake switch connector	Terminal			
E110 *1 , B37 *2	1	Ground	Not released	Approx. 0 V
			Released	Battery voltage

\*1: with A/T, \*2: with M/T

OK or NG

- OK >> GO TO 3  
 NG >> Replace parking brake switch.

### 3. CHECK PARKING BRAKE SWITCH CIRCUIT



1. Turn ignition switch OFF.
2. Disconnect parking brake switch connector and combination meter connector.
3. Check continuity between combination meter harness connector (A) M20 terminal 43 and parking brake switch harness connector (B) E110 \*1 , B37 \*2 terminal 1.

**43 - 1 : Continuity should exist.**

\*1: with A/T, \*2: with M/T

OK or NG

- OK >> INSPECTION END  
 NG >> Repair harness or connector.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# DAYTIME LIGHT SYSTEM

## CONSULT-II Functions (BCM)

NKS0027Q

Refer to [LT-16, "CONSULT-II Functions \(BCM\)"](#) .

## CONSULT-II Functions (IPDM E/R)

NKS0027R

Refer to [LT-18, "CONSULT-II Functions \(IPDM E/R\)"](#) .

## Daytime Light Control Does Not Operate Properly

NKS0027S

### 1. FRONT FOG LAMP ACTIVE TEST

Ⓜ With CONSULT-II

1. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "LAMPS" on "SELECT TEST ITEM" screen.
3. Touch "FOG" screen.
4. Make sure front fog lamp operates.

**Front fog lamp should operate.**

ⓧ Without CONSULT-II

1. Start auto active test. Refer to [PG-21, "Auto Active Test"](#) .
2. Make sure front fog lamp operates.

**Front fog lamp should operate.**

OK or NG

- OK >> GO TO 5.  
NG >> GO TO 2.

ACTIVE TEST			
LAMPS		OFF	
		HI	
LO		FOG	
MODE	BACK	LIGHT	COPY

SKIA5774E




# DAYTIME LIGHT SYSTEM

## 2. CHECK FRONT FOG LAMP INPUT SIGNAL

With CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH and LH connectors.
3. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
4. Select "LAMPS" on "SELECT TEST ITEM" screen.
5. Touch "FOG" screen.
6. When front fog lamp is operating, check voltage between front combination lamp RH and LH harness connectors and ground.



Front combination lamp connector		(+)	(-)	Voltage
		Terminal		
RH	E24	1	Ground	Battery voltage
LH	E41	1		

Without CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH and LH connectors.
3. Start auto active test. Refer to [PG-21, "Auto Active Test"](#).
4. When front fog lamp is operating, check voltage between front combination lamp RH and LH harness connectors and ground.

Front combination lamp connector		(+)	(-)	Voltage
		Terminal		
RH	E24	1	Ground	Battery voltage
LH	E41	1		

OK or NG

- OK >> GO TO 4.  
 NG >> GO TO 3.


## 3. CHECK FRONT FOG LAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector E8 terminal 36 and front combination lamp RH harness connector E24 terminal 1.

**36 – 1 : Continuity should exist.**

4. Check continuity between IPDM E/R harness connector E8 terminal 37 and front combination lamp LH harness connector E41 terminal 1.

**37 – 1 : Continuity should exist.**



OK or NG

- OK >> Replace IPDM E/R.  
 NG >> Repair harness or connector.

# DAYTIME LIGHT SYSTEM

## 4. CHECK FRONT FOG LAMP GROUND

1. Check continuity between front combination lamp RH harness connector E24 terminal 8 and ground.


**8 – Ground : Continuity should exist.**

2. Check continuity between front combination lamp LH harness connector E41 terminal 8 and ground.

**8 – Ground : Continuity should exist.**

OK or NG

- OK >> Check front fog lamp bulbs.
- NG >> Repair harness or connector.



## 5. CHECK SELF-DIAGNOSIS

Select "BCM" on CONSULT-II, and self-diagnosis for "BCM".

Displayed results of self-diagnosis

No malfunction detected>> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#).

CAN communications or CAN system>> Check BCM CAN communication system. Refer to [BCS-15, "CAN Communication Inspection Using CONSULT-II \(Self-Diagnosis\)"](#).

SELF-DIAG RESULTS			
DTC RESULTS		TIME	
CAN COMM CIRCUIT [U1000]			
ERASE		PRINT	
MODE	BACK	LIGHT	COPY

PKIA7627E

### Aiming Adjustment

Refer to [LT-29, "Aiming Adjustment"](#).

### Bulb Replacement

Refer to [LT-30, "Bulb Replacement"](#).

### Removal and Installation

Refer to [LT-32, "Removal and Installation"](#).

NKS0053U

NKS0053V

NKS0053W


# AUTO LIGHT SYSTEM

## AUTO LIGHT SYSTEM

PPF:28491

### Component Parts and Harness Connector Location

NKS000GY



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

## System Description

NKS000GZ

Automatically turns ON/OFF the parking lamps and the headlamps in accordance with ambient light. Timing for when lamps turn ON/OFF can be selected using four modes.

### OUTLINE

The auto light control system has an optical sensor inside it that detects outside brightness. When the lighting switch is in AUTO position, it automatically turns ON/OFF the parking lamps and the headlamps in accordance with ambient light. Sensitivity can be adjusted in four steps. For the details of the setting, Refer to [LT-59, "SETTING CHANGE FUNCTIONS"](#).

Optical sensor, power is supplied

- from BCM (body control module) terminal 17
- to optical sensor terminal 1.

Optical sensor, ground is supplied

- to optical sensor terminal 3
- through BCM terminal 18.

When ignition switch is turn to ON position, and

# AUTO LIGHT SYSTEM

When outside brightness is darker than prescribed level, input is supplied

- from optical sensor terminal 2
- to BCM terminal 14.

The headlamps will then illuminate. For a description of headlamp operation, Refer to [LT-51, "System Description"](#).

## COMBINATION SWITCH READING FUNCTION

Refer to [BCS-3, "COMBINATION SWITCH READING FUNCTION"](#).

## DELAY TIMER FUNCTION

Delay timer function carries out a function that BCM activates the timer and controls lights out of headlamps by door switch signal and lightning switch signal when turning the ignition switch OFF while it is ON and headlamps are ON by the auto light function.

Timer types are a 5 minute timer and a 45 second timer

- When opening any door (door switch is ON), the 5 minute timer starts and then headlamps go out five minutes later
- When all the doors are closed (from door switch ON to OFF), the 45 second timer starts and then headlamps go out 45 seconds later. If any door is opened (door switch ON) while the 45 second timer is in operation, the 5 minute timer starts again
- The timer stops when turning on the ignition switch or turning off the auto light switch under the above conditions.

Delay timer control mode can be changed by the function setting of CONSULT-II.

## CAN Communication System Description

NKS000H0

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

## CAN Communication Unit

NKS000H1

Refer to [LAN-47, "CAN System Specification Chart"](#).

## Major Components and Functions


NKS000H2

Components	Functions
BCM	● Turns on/off circuits of tail light and headlamp according to signals from optical sensor, lighting switch (AUTO), driver door switch, passenger door switch and ignition switch (ON, OFF).
Optical sensor	● Converts outside brightness (lux) to voltage, and sends it to BCM. (Detects brightness of 800 to 2,500 lux)

# AUTO LIGHT SYSTEM

## Schematic

NKS000H3



\* : This relay is built into the IPDM E/R (intelligent power distribution module engine room).

TKWM2194E




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# AUTO LIGHT SYSTEM

## Wiring Diagram — AUTO/L —

NKS000H4

LT-AUTO/L-01





REFER TO THE FOLLOWING.

- (E108) -SUPER MULTIPLE JUNCTION (SMJ)
- (M4) -FUSE BLOCK-JUNCTION BOX (J/B)
- (M1), (M2) -ELECTRICAL UNITS


TKWM2195E

# AUTO LIGHT SYSTEM

LT-AUTO/L-02



(M8)  
W



(M19)  
W



(B17), (B410)  
W W



REFER TO THE FOLLOWING.  
 (B1), (B401) -SUPER MULTIPLE JUNCTION (SMJ)  
 (M1), (B4) -ELECTRICAL UNITS

TKWM3453E

# AUTO LIGHT SYSTEM

LT-AUTO/L-03

▬ : DATA LINE



REFER TO THE FOLLOWING.

(B1) -SUPER MULTIPLE JUNCTION (SMJ)

TKWM3454E



# AUTO LIGHT SYSTEM

## Terminals and Reference Values for BCM

NKS000H5

**CAUTION:**

- Check combination switch system terminal waveform under the loaded condition with lighting switch, turn signal switch and wiper switch OFF not to be fluctuated by overloaded.
- Turn wiper dial position to 4 except when checking waveform or voltage of wiper dial position. Wiper dial position can be confirmed on CONSULT-II. Refer to [LT-17, "DATA MONITOR"](#).

Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
4	W/L	Combination switch input 3	ON	—	Approx. 0 V
				Lighting switch AUTO	<p>Approx. 1.0 V</p>
11	LG	Ignition switch (ACC)	ACC	—	Battery voltage
12	P	Front door switch passenger side signal	OFF	Front door switch passenger side ON (open)	Approx. 0 V
				Front door switch passenger side OFF (closed)	Battery voltage
14	Y/PU	Optical sensor signal	ON	When optical sensor is illuminated	3.1 V or more <sup>Note</sup>
				When optical sensor is not illuminated	0.6 V or less
17	P	Optical sensor power supply	ON	—	Approx. 5 V
18	B	Sensor ground	ON	—	Approx. 0 V
33	L	Combination switch output 4	ON	—	<p>Approx. 7.2 V</p>
				Lighting switch AUTO	<p>Approx. 1.2 V</p>
38	W/L	Ignition switch (ON)	ON	—	Battery voltage
39	L	CAN - H	—	—	—
40	P	CAN - L	—	—	—
42	GY	Battery power supply	OFF	—	Battery voltage
52	B	Ground	ON	—	Approx. 0 V
55	W/R	Battery power supply	OFF	—	Battery voltage
62	Y	Front door switch driver side signal	OFF	Front door switch driver side ON (open)	Approx. 0 V
				Front door switch driver side OFF (closed)	Battery voltage

# AUTO LIGHT SYSTEM

**NOTE:**

Optical sensor must be securely subjected to work lamp light. If the optical sensor is insufficiently illuminated, the measured value may not satisfy standard.

## Terminals and Reference Values for IPDM E/R

NKS000H6

Terminal No.	Wire color	Signal name	Measuring condition			Reference value
			Ignition switch	Operation or condition		
20	R	Headlamp HIGH & LOW (RH)	ON	Lighting switch 2ND position	OFF	Approx. 0 V
					ON	Battery voltage
22	R/L	Parking, license plate, side marker and tail lamps	ON	Lighting switch 1ST position	OFF	Approx. 0 V
					ON	Battery voltage
27	BR	Headlamp high beam solenoid (RH)	ON	Lighting switch HIGH BEAM or PASSING position	OFF	Approx. 0 V
					ON	Battery voltage
28	R/Y	Headlamp high beam solenoid (LH)	ON	Lighting switch HIGH BEAM or PASSING position	OFF	Approx. 0 V
					ON	Battery voltage
30	R/B	Headlamp HIGH & LOW (LH)	ON	Lighting switch 2ND position	OFF	Approx. 0 V
					ON	Battery voltage
38	B/R	Ground	ON	—	—	Approx. 0 V
48	L	CAN - H	—	—	—	—
49	P	CAN - L	—	—	—	—
60	B/R	Ground	ON	—	—	Approx. 0 V

## How to Proceed With Trouble Diagnosis

NKS000H7

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-51, "System Description"](#) .
3. Perform the preliminary check. Refer to [LT-59, "Preliminary Check"](#) .
4. Check symptom and repair or replace the cause of malfunction. Refer to [LT-60, "Symptom Chart"](#) .
5. Does the auto light system operate normally? If YES, GO TO 6. If NO, GO TO 4.
6. INSPECTION END

# AUTO LIGHT SYSTEM

NKS000HB

## Preliminary Check SETTING CHANGE FUNCTIONS

Sensitivity of auto light system can be adjusted using CONSULT-II. Refer to [LT-16, "WORK SUPPORT"](#).

### CHECK POWER SUPPLY AND GROUND CIRCUIT

#### 1. CHECK FUSES AND FUSIBLE LINK

Check for blown fuses and fusible link.

Unit	Power source	Fuse and fusible link No.
BCM	Battery	F
		18
	Ignition switch ON or START position	1
	Ignition switch ACC or ON position	6
IPDM E/R	Battery	71
		72
		74
		76
		76
		86

Refer to [LT-54, "Wiring Diagram — AUTO/L —"](#).

#### OK or NG

OK >> GO TO 2.

NG >> If fuse or fusible link is blown, be sure to eliminate cause of malfunction before installing new fuse or fusible link. Refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#).

#### 2. CHECK POWER SUPPLY CIRCUIT


- Turn ignition switch OFF.
- Disconnect BCM connector.
- Check voltage between BCM harness connector and ground.

BCM connector	Terminal	(-)	Ignition switch position		
			OFF	ACC	ON
M1	11	Ground	Approx. 0 V	Battery voltage	Battery voltage
	38		Approx. 0 V	Approx. 0 V	Battery voltage
M2	42		Battery voltage	Battery voltage	Battery voltage
	55		Battery voltage	Battery voltage	Battery voltage

#### OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.



# AUTO LIGHT SYSTEM


## 3. CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

BCM connector	Terminal	Ground	Continuity
M2	52		Yes

OK or NG

- OK >> INSPECTION END
- NG >> Repair harness or connector.



NKS000H9

## CONSULT-II Functions (BCM)

Refer to [LT-16, "CONSULT-II Functions \(BCM\)"](#).

## CONSULT-II Functions (IPDM E/R)

Refer to [LT-18, "CONSULT-II Functions \(IPDM E/R\)"](#).

NKS000HA

## Symptom Chart

NKS000HB

Phenomenon	Malfunction system and reference
<ul style="list-style-type: none"> <li>● Parking, license plate, side marker and tail lamps and headlamps will not illuminate when outside of the vehicle becomes dark. (Lighting switch 1ST position and 2ND position operate normally.)</li> <li>● Parking, license plate, side marker and tail lamps and headlamp will not go out when outside of the vehicle becomes light. (Lighting switch 1ST position and 2ND position operate normally.)</li> <li>● Headlamps go out when outside of the vehicle becomes light, but parking lamps stay on.</li> </ul>	<ul style="list-style-type: none"> <li>● Refer to <a href="#">LT-16, "WORK SUPPORT"</a>.</li> <li>● Refer to <a href="#">LT-60, "Lighting Switch Inspection"</a>.</li> <li>● Refer to <a href="#">LT-61, "Optical sensor System Inspection"</a>.</li> </ul> <p>If above systems are normal, replace BCM.</p>
Auto light adjustment system will not operate. (Lighting switch AUTO, 1ST position and 2ND position operate normally.)	<ul style="list-style-type: none"> <li>● Refer to <a href="#">LT-61, "Optical sensor System Inspection"</a>.</li> </ul> <p>If above system is normal, replace BCM.</p>
Shut off delay feature will not operate.	<ul style="list-style-type: none"> <li>● CAN communication line inspection between BCM and combination meter. Refer to <a href="#">BCS-15, "CAN Communication Inspection Using CONSULT-II (Self-Diagnosis)"</a>.</li> <li>● Refer to <a href="#">BL-68, "Check Door Switch"</a>.</li> </ul> <p>If above system is normal, replace BCM.</p>

## Lighting Switch Inspection

NKS000HC

### 1. CHECK LIGHTING SWITCH INPUT SIGNAL

With CONSULT-II

Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "AUTO LIGHT SW" turns ON-OFF linked with operation of lighting switch.


**When lighting switch is AUTO : AUTO LIGHT SW ON position**

Without CONSULT-II

Refer to [LT-100, "Combination Switch Inspection"](#).

OK or NG

- OK >> INSPECTION END
- NG >> Check combination switch (lighting switch). Refer to [LT-100, "Combination Switch Inspection"](#).



PKIA7595E

# AUTO LIGHT SYSTEM

## Optical sensor System Inspection

NKS000HD

### 1. CHECK OPTICAL SENSOR INPUT SIGNAL

④ With CONSULT-II

Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "OPTICAL SENSOR", and check difference in voltage when the optical sensor is illuminated and not illuminated.

**Illuminated**

**OPTICAL SENSOR : 3.1 V or more**

**Not illuminated**

**OPTICAL SENSOR : 0.6 V or less**

**CAUTION:**

**Optical sensor must be securely subjected to work lamp light. If optical sensor is insufficiently illuminated, the measured value may not satisfy the standard.**

DATA MONITOR			
MONITOR			
OPTICAL SENSOR	0.75V		
RECORD			
MODE	BACK	LIGHT	COPY

PKIA7596E

⊗ Without CONSULT-II

1. Turn ignition switch ON.
2. Check voltage between BCM harness connector M1 terminal 14 and ground.

**Illuminated**


**OPTICAL SENSOR : 3.1 V or more**

**Not illuminated**

**OPTICAL SENSOR : 0.6 V or less**

**CAUTION:**

**Optical sensor must be securely subjected to work lamp light. If optical sensor is insufficiently illuminated, the measured value may not satisfy the standard.**



OK or NG

- OK >> INSPECTION END  
NG >> GO TO 2.


### 2. CHECK OPTICAL SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector and optical sensor connector.
3. Check continuity (open circuit) between BCM harness connector M1 terminal 17 and optical sensor harness connector M63 terminal 1.

**17 - 1 : Continuity should exist.**

4. Check continuity (short circuit) between BCM harness connector M1 terminal 17 and ground.

**17 - Ground : Continuity should not exist.**



OK or NG

- OK >> GO TO 3.  
NG >> Repair harness or connector.

# AUTO LIGHT SYSTEM

## 3. CHECK OPTICAL SENSOR SIGNAL CIRCUIT

1. Check continuity (open circuit) between BCM harness connector M1 terminal 14 and optical sensor harness connector M63 terminal 2.

**14 – 2 : Continuity should exist.**


2. Check continuity (short circuit) between BCM harness connector M1 terminal 14 and ground.

**14 – Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 4.

NG >> Repair harness or connector.



## 4. CHECK OPTICAL SENSOR GROUND CIRCUIT

1. Check continuity (open circuit) between BCM harness connector M1 terminal 18 and optical sensor harness connector M63 terminal 3.

**18 – 3 : Continuity should exist.**


2. Check continuity (short circuit) between BCM harness connector M1 terminal 18 and ground.

**18 – Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 5.

NG >> Repair harness or connector.



## 5. CHECK OPTICAL SENSOR VOLTAGE


1. Connect BCM connector.
2. Turn ignition switch ON.
3. Check voltage between BCM harness connector M1 terminal 17 and ground.

**17 – Ground : Approx. 5 V**

OK or NG

OK >> Replace optical sensor. Refer to [LT-63, "Removal and Installation of Optical Sensor"](#).

NG >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#).




# AUTO LIGHT SYSTEM

## Removal and Installation of Optical Sensor

NKS000HE

### REMOVAL

1. Insert a screwdriver or similar tool and remove front defroster grill (LH). Refer to [IP-15, "\(Aa\) Defroster Grille \(RH/LH\)"](#) .
2. Disconnect optical sensor connector.
3. Remove optical sensor.



### INSTALLATION

Installation is the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M


# FRONT FOG LAMP

## FRONT FOG LAMP

PFP:26150

### Component Parts and Harness Connector Location

NKS00206



PKIC0494E

## System Description

NKS00207

The control of the front fog lamps is dependent upon the position of the lighting switch. The lighting switch must be in the 2ND position or AUTO position (headlamp is ON) for front fog lamp operation. When the lighting switch is placed in front fog lamp switch ON position the BCM (body control module) receives input signal requesting the front fog lamps to illuminate. When the headlamps are illuminated, this input signal is communicated to the IPDM E/R (intelligent power distribution module engine room) through the CAN communication lines. The CPU (central processing unit) located in the IPDM E/R controls the front fog lamp relay. When activated, this relay directs power to the front fog lamps.

## OUTLINE

Power is supplied at all times

- to ignition relay, located in IPDM E/R, from battery direct,
- through 15A fuse (No. 88, located in IPDM E/R)
- to front fog lamp relay, located in IPDM E/R,
- through 15A fuse (No. 78, located in IPDM E/R)
- to CPU located in IPDM E/R,
- through 10A fuse (No. 71, located in IPDM E/R)
- to CPU located in IPDM E/R,
- through 50A fusible link (letter F, located in fuse, fusible link and relay box)
- to BCM terminal 55,
- through 10A fuse [No. 18, located in fuse block (J/B)]



# FRONT FOG LAMP

- to BCM terminal 42.

With the ignition switch in the ON or START position, power is supplied

- to ignition relay, located in IPDM E/R, from battery direct,
- through ignition relay, located in IPDM E/R
- to CPU located in IPDM E/R,
- through 10A fuse [No. 1, located in fuse block (J/B)]
- to BCM terminal 38.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 6, located in fuse block (J/B)]
- to BCM terminal 11.

Ground is supplied

- to BCM terminal 52
- through grounds M30 and M66,
- to IPDM E/R terminals 38 and 60
- through grounds E17 and E43.

## FRONT FOG LAMP OPERATION

The front fog lamp switch is built in lighting switch. The lighting switch must be in 2ND position or AUTO position (headlamp is ON) and front fog lamp switch must be ON position for front fog lamp operation.

With the front fog lamp switch in the ON position, the CPU located in the IPDM E/R grounds coil side of the front fog lamp relay. Front fog lamp relay then directs power

- through IPDM E/R terminal 37
- to front combination lamp LH terminal 1,
- through IPDM E/R terminal 36
- to front combination lamp RH terminal 1.

Ground is supplied

- to front combination lamp RH and LH terminals 8
- through grounds E17 and E43.

With power and grounds supplied, front fog lamps illuminate.

## COMBINATION SWITCH READING FUNCTION

Refer to [BCS-3, "COMBINATION SWITCH READING FUNCTION"](#) .

## EXTERIOR LAMP BATTERY SAVER CONTROL

When lighting switch is in the 2ND position and ignition switch is turned from ON or ACC to OFF, the battery saver control feature is activated.

Under this condition, front fog lamps (and headlamps) remain illuminated for 5 minutes, then front fog lamps (and headlamps) are turned off.

Exterior lamp battery saver control mode can be changed by the function setting of CONSULT-II.

## CAN Communication System Description

NKS00208

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

## CAN Communication Unit

NKS00209

Refer to [LAN-47, "CAN System Specification Chart"](#) .




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# FRONT FOG LAMP

## Wiring Diagram — F/FOG —

NKS0020B

LT-F/FOG-01



REFER TO THE FOLLOWING.



(E108), (B1) -SUPER MULTIPLE JUNCTION (SMJ)

(M4) -FUSE BLOCK-JUNCTION BOX (J/B)

(M1), (M2) -ELECTRICAL UNITS

TKWM3455E

# FRONT FOG LAMP



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# FRONT FOG LAMP

## Terminals and Reference Values for BCM

NKS0020C

**CAUTION:**

- Check combination switch system terminal waveform under the loaded condition with lighting switch, turn signal switch and wiper switch OFF not to be fluctuated by overloaded.
- Turn wiper dial position to 4 except when checking waveform or voltage of wiper dial position. Wiper dial position can be confirmed on CONSULT-II. Refer to [LT-17, "DATA MONITOR"](#) .

Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
2	G/R	Combination switch input 5	ON	OFF	Approx. 0 V
				Lighting switch 2ND	<p style="text-align: right; font-size: small;">PKIB4953J</p>
3	G	Combination switch input 4	ON	OFF	Approx. 0 V
				Any of the conditions below	<p style="text-align: right; font-size: small;">PKIB4955J</p>
11	LG	Ignition switch (ACC)	ACC	—	Battery voltage
32	GY	Combination switch output 5	ON	OFF	<p style="text-align: right; font-size: small;">PKIB4960J</p>
				Front fog lamp switch (Operates only front fog lamp switch)	<p style="text-align: right; font-size: small;">PKIB4956J</p>

# FRONT FOG LAMP

Terminal No.	Wire color	Signal name	Measuring condition		Reference value	
			Ignition switch	Operation or condition		
34	PU	Combination switch output 3	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	OFF	<p style="text-align: right;">PKIB4960J</p> <p style="text-align: center;">Approx. 7.2 V</p>
					Lighting switch 2ND	<p style="text-align: right;">PKIB4958J</p> <p style="text-align: center;">Approx. 1.2 V</p>
35	Y/R	Combination switch output 2	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	OFF	<p style="text-align: right;">PKIB4960J</p> <p style="text-align: center;">Approx. 7.2 V</p>
					Lighting switch 2ND	<p style="text-align: right;">PKIB4958J</p> <p style="text-align: center;">Approx. 1.2 V</p>
38	W/L	Ignition switch (ON)	ON	—	Battery voltage	
39	L	CAN – H	—	—	—	
40	P	CAN – L	—	—	—	
42	GY	Battery power supply	OFF	—	Battery voltage	
52	B	Ground	ON	—	Approx. 0 V	
55	R	Battery power supply	OFF	—	Battery voltage	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LT

# FRONT FOG LAMP

## Terminals and Reference Values for IPDM E/R

NKS0020D

Terminal No.	Wire color	Signal name	Measuring condition		Reference value	
			Ignition switch	Operation or condition		
36	W/G	Front fog lamp (RH)	ON	Lighting switch must be in the 2ND position or AUTO position (headlamp is ON) and the front fog lamp switch must be ON	OFF	Approx. 0 V
					ON	Battery voltage
37	SB	Front fog lamp (LH)			OFF	Approx. 0 V
					ON	Battery voltage
38	B/R	Ground	ON	—	Approx. 0 V	
48	L	CAN – H	—	—	—	
49	P	CAN – L	—	—	—	
60	B/R	Ground	ON	—	Approx. 0 V	

## How to Proceed With Trouble Diagnosis

NKS0020E

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-64, "System Description"](#) .
3. Perform the Preliminary Check. Refer to [LT-70, "Preliminary Check"](#) .
4. Check symptom and repair or replace the malfunctioning parts.
5. Does the front fog lamp operate normally? If YES, GO TO 6. If NO, GO TO 4.
6. INSPECTION END

## Preliminary Check

NKS0020F

### CHECK POWER SUPPLY AND GROUND CIRCUIT

#### 1. CHECK FUSES AND FUSIBLE LINK

Check for blown fuses and fusible link.

Unit	Power source	Fuse and fusible link No.
BCM	Battery	F
		18
	Ignition switch ON or START position	1
	Ignition switch ACC or ON position	6
IPDM E/R	Battery	88

Refer to [LT-66, "Wiring Diagram — F/FOG —"](#) .

OK or NG

OK >> GO TO 2.

NG >> If fuse or fusible link is blown, be sure to eliminate cause of malfunction before installing new fuse or fusible link. Refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#) .

# FRONT FOG LAMP


## 2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check voltage between BCM harness connector and ground.

(+)		(-)	Ignition switch position		
BCM connector	Terminal		OFF	ACC	ON
M1	11	Ground	Approx. 0 V	Battery voltage	Battery voltage
	38		Approx. 0 V	Approx. 0 V	Battery voltage
M2	42		Battery voltage	Battery voltage	Battery voltage
	55		Battery voltage	Battery voltage	Battery voltage

OK or NG

- OK >> GO TO 3.  
 NG >> Repair harness or connector.




## 3. CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

BCM connector	Terminal	Ground	Continuity
M2	52		Yes

OK or NG

- OK >> INSPECTION END  
 NG >> Repair harness or connector.



## CONSULT-II Functions (BCM)

Refer to [LT-16. "CONSULT-II Functions \(BCM\)"](#) .

## CONSULT-II Functions (IPDM E/R)

Refer to [LT-18. "CONSULT-II Functions \(IPDM E/R\)"](#) .

NKS0020G

NKS0020H

# FRONT FOG LAMP

NKS00201

## Front Fog lamps Do Not Illuminate (Both Sides)

### 1. CHECK COMBINATION SWITCH INPUT SIGNAL

④ With CONSULT-II

Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "FR FOG SW" turns ON-OFF linked with operation of front fog lamp switch.

**When front fog lamp switch : FR FOG SW ON is ON position**

⊗ Without CONSULT-II

Refer to [LT-100, "Combination Switch Inspection"](#).

OK or NG

OK >> GO TO 2.

NG >> Check combination switch (lighting switch). Refer to [LT-100, "Combination Switch Inspection"](#).

DATA MONITOR			
MONITOR			
FR FOG SW	ON		
		RECORD	
MODE	BACK	LIGHT	COPY

PKIA7598E

### 2. FOG LAMP ACTIVE TEST

④ With CONSULT-II

1. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "LAMPS" on "SELECT TEST ITEM" screen.
3. Touch "FOG" screen.
4. Make sure front fog lamp operates.

**Front fog lamp should operate.**

⊗ Without CONSULT-II

1. Start auto active test. Refer to [PG-21, "Auto Active Test"](#).
2. Make sure front fog lamp operates.

**Front fog lamp should operate.**

OK or NG

OK >> GO TO 3.

NG >> GO TO 4.

ACTIVE TEST			
LAMPS		FOG	
OFF	HI		
LO			
		RECORD	
MODE	BACK	LIGHT	COPY

PKIA7748E

### 3. CHECK IPDM E/R

1. Select "IPDM E/R" on CONSULT-II, and select "DATA MONITOR" on "SELECT DIAG MODE" screen.
2. Make sure "FR FOG REQ" turns ON when front fog lamp switch is in ON position.

**When front fog lamp switch : FR FOG REQ ON is ON position**

OK or NG

OK >> Replace IPDM E/R. Refer to [PG-27, "Removal and Installation of IPDM E/R"](#).

NG >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#).

DATA MONITOR			
MONITOR			
FR FOG REQ	ON		
		Page Down	
		RECORD	
MODE	BACK	LIGHT	COPY

SKIA5898E




# FRONT FOG LAMP

## 4. CHECK FOG LAMP INPUT SIGNAL

With CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH and LH connectors.
3. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
4. Select "LAMPS" on "SELECT TEST ITEM" screen.
5. Touch "FOG" screen.
6. When front fog lamp relay is operating, check voltage between front combination lamp harness connector and ground.



(+)		Terminal	(-)	Voltage
Front combination lamp connector				
RH	E24	1	Ground	Battery voltage
LH	E41	1		

Without CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH and LH connectors.
3. Start auto active test. Refer to [PG-21, "Auto Active Test"](#).
4. When front fog lamp relay is operating, check voltage between front combination lamp harness connector and ground.

(+)		Terminal	(-)	Voltage
Front combination lamp connector				
RH	E24	1	Ground	Battery voltage
LH	E41	1		

OK or NG

- OK >> GO TO 6.  
 NG >> GO TO 5.


## 5. CHECK FOG LAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector E8 terminal 36 and front combination lamp RH harness connector E24 terminal 1.

**36 – 1 : Continuity should exist.**

4. Check continuity between IPDM E/R harness connector E8 terminal 37 and front combination lamp LH harness connector E41 terminal 1.

**37 – 1 : Continuity should exist.**



OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-27, "Removal and Installation of IPDM E/R"](#).  
 NG >> Repair harness or connector.

# FRONT FOG LAMP

## 6. CHECK FOG LAMP GROUND

1. Check continuity between front combination lamp RH harness connector E24 terminal 8 and ground.


**8 – Ground** : **Continuity should exist.**

2. Check continuity between front combination lamp LH harness connector E41 terminal 8 and ground.

**8 – Ground** : **Continuity should exist.**

OK or NG

- OK >> Check front fog lamp bulbs.  
NG >> Repair harness or connector.



## Front Fog Lamp Does Not Illuminate (One Side)

NKS0020J

### 1. CHECK BULB

Check bulb of lamp with does not illuminate which does not illuminate.

OK or NG

- OK >> GO TO 2.  
NG >> Replace front fog lamp bulb.

### 2. CHECK FOG LAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and front combination lamp RH or LH connector.
3. Check continuity between IPDM E/R harness connector E8 terminal 36 and front combination lamp RH harness connector E24 terminal 1.


**36 – 1** : **Continuity should exist.**

4. Check continuity between IPDM E/R harness connector E8 terminal 37 and front combination lamp LH harness connector E41 terminal 1.

**37 – 1** : **Continuity should exist.**

OK or NG

- OK >> GO TO 3.  
NG >> Repair harness or connector.



### 3. CHECK FOG LAMP GROUND

1. Check continuity between front combination lamp RH harness connector E24 terminal 8 and ground.


**8 – Ground** : **Continuity should exist.**

2. Check continuity between front combination lamp LH harness connector E41 terminal 8 and ground.

**8 – Ground** : **Continuity should exist.**

OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-27, "Removal and Installation of IPDM E/R"](#).  
NG >> Repair harness or connector.




# FRONT FOG LAMP

NKS0020K

## Aiming Adjustment


The front fog lamp is a semi-sealed beam type which uses a replaceable halogen bulb. Before performing aiming adjustment, make sure of the following.

- Keep all tires inflated to correct pressure.
- Place vehicle on level ground.
- See that vehicle is unloaded (except for full levels of coolant, engine oil and fuel, and spare tire, jack, and tools). Have the driver or equivalent weight placed in driver seat.



Adjust aiming in the vertical direction by turning the adjusting screw.


1. Set the distance between the screen and the center of the front fog lamp lens as shown at left.
2. Turn front fog lamps ON.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

## FRONT FOG LAMP

- Adjust front fog lamps using adjusting screw so that the top edge of the high intensity zone is in the hatched area as shown in the figure.
  - When performing this adjustment, cover the headlamps and the opposite front fog lamp, if necessary.



### Bulb Replacement

Refer to [LT-30, "Bulb Replacement"](#).

NKS0020L


# TURN SIGNAL AND HAZARD WARNING LAMPS

## TURN SIGNAL AND HAZARD WARNING LAMPS

PPF:26120

### Component Parts and Harness Connector Location

NKS0020M



PKIC0415E

### System Description

#### TURN SIGNAL OPERATION

NKS0020N

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 1, located in fuse block (J/B)]
- to BCM (body control module) terminal 38,
- through 10A fuse [No. 14, located in fuse block (J/B)]
- to combination meter terminals 22 and 23.

Ground is supplied

- to BCM terminal 52
- through grounds M30 and M66,
- to combination meter terminals 1, 24 and 25
- through grounds M30 and M66.

#### LH Turn Signal Lamp

When turn signal switch is moved to left position, BCM receives input signal requesting left turn signals to flash. BCM then supplies power

- through BCM terminal 45
- to front combination lamp LH terminal 6 and
- to rear combination lamp LH terminal 5.

Ground is supplied

- to front combination lamp LH terminal 8

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# TURN SIGNAL AND HAZARD WARNING LAMPS

---

- through grounds E17 and E43,
- to rear combination lamp LH terminal 4
- through ground B103.

The BCM also supplies input to combination meter terminals 4 and 5 through CAN communication lines. This input is processed by unified meter control unit in combination meter, which in turn supplies ground to the left turn signal indicator lamp.

With power and input supplied, BCM controls flashing of LH turn signal lamps.

## RH Turn Signal Lamp

When turn signal switch is moved to right position, BCM receives input signal requesting right turn signals to flash. BCM then supplies power

- through BCM terminal 46
- to front combination lamp RH terminal 6 and
- to rear combination lamp RH terminal 5.

Ground is supplied

- to front combination lamp RH terminal 8
- through grounds E17 and E43,
- to rear combination lamp RH terminal 4
- through ground B103.

The BCM also supplies input to combination meter terminals 4 and 5 through CAN communication lines. This input is processed by unified meter control unit in combination meter, which in turn supplies ground to the right turn signal indicator lamp.

With power and input supplied, BCM controls flashing of RH turn signal lamps.

## HAZARD LAMP OPERATION

Power is supplied at all times

- through 50A fusible link (letter F, located in fuse, fusible link and relay box)
- to BCM terminal 55,
- through 10A fuse [No. 18, located in fuse block (J/B)]
- to BCM terminal 42,
- through 10A fuse [No. 19, located in fuse block (J/B)]
- to combination meter terminal 21.

Ground is supplied

- to hazard switch terminal 1
- to combination meter terminals 1, 24 and 25, and
- to BCM terminal 52
- through grounds M30 and M66,

When hazard switch is depressed, ground is supplied

- to BCM terminal 29
- through hazard switch terminal 2.

BCM then supplies power

- through BCM terminal 45
- to front combination lamp LH terminal 6 and
- to rear combination lamp LH terminal 5,
- through BCM terminal 46
- to front combination lamp RH terminal 6 and
- to rear combination lamp RH terminal 5.

Ground is supplied

- to front combination lamp RH and LH terminals 8
- through grounds E17 and E43,
- to rear combination lamp RH and LH terminals 4
- through ground B103.

# TURN SIGNAL AND HAZARD WARNING LAMPS

The BCM also supplies input to combination meter terminals 4 and 5 through CAN communication lines. This input is processed by unified meter control unit in combination meter, which in turn supplies ground to the left and right turn signal indicator lamps.

With power and input supplied, BCM controls flashing of hazard warning lamps.

## REMOTE KEYLESS ENTRY SYSTEM OPERATION

Power is supplied at all times

- through 50A fusible link (letter F, located in fuse, fusible link and relay box)
- to BCM terminal 55,
- through 10A fuse [No. 19, located in fuse block (J/B)]
- to combination meter terminal 21.

Ground is supplied

- to BCM terminal 52 and
- to combination meter terminals 1, 24 and 25
- through grounds M30 and M66.

When the remote keyless entry system is triggered by input from key fob, BCM supplies power

- through BCM terminal 45
- to front combination lamp LH terminal 6 and
- to rear combination lamp LH terminal 5,
- through BCM terminal 46
- to front combination lamp RH terminal 6 and
- to rear combination lamp RH terminal 5.

Ground is supplied

- to front combination lamp RH and LH terminals 8
- through grounds E17 and E43,
- to rear combination lamp RH and LH terminals 4
- through ground B103.

The BCM also supplies input to combination meter terminals 4 and 5 through CAN communication lines. This input is processed by unified meter control unit in combination meter, which in turn supplies ground to the left and right turn signal indicator lamps.

With power and ground supplied, BCM controls flashing of hazard warning lamps when key fob is used to activate remote keyless entry system.

## COMBINATION SWITCH READING FUNCTION

Refer to [BCS-3, "COMBINATION SWITCH READING FUNCTION"](#) .

## CAN Communication System Description

NKS00200

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

## CAN Communication Unit


NKS0020P

Refer to [LAN-47, "CAN System Specification Chart"](#) .

# TURN SIGNAL AND HAZARD WARNING LAMPS

## Schematic

NKS0020Q





TKWM4099E



# TURN SIGNAL AND HAZARD WARNING LAMPS

NKS0020R

## Wiring Diagram — TURN —



REFER TO THE FOLLOWING.

(E108) -SUPER MULTIPLE JUNCTION (SMJ)

(M4) -FUSE BLOCK-JUNCTION BOX (J/B)



(M1), (M2) -ELECTRICAL UNITS

\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

TKWM2919E

# TURN SIGNAL AND HAZARD WARNING LAMPS

LT-TURN-02



REFER TO THE FOLLOWING.

(B1) -SUPER MULTIPLE JUNCTION (SMJ)




(M2) -ELECTRICAL UNITS

TKWM4921E

# TURN SIGNAL AND HAZARD WARNING LAMPS

LT-TURN-03

— : DATA LINE



REFER TO THE FOLLOWING.

(M4) - FUSE BLOCK-JUNCTION BOX (J/B)

(M1) - ELECTRICAL UNITS

TKWM2205E





# TURN SIGNAL AND HAZARD WARNING LAMPS

NKS0020S

## Terminals and Reference Values for BCM

**CAUTION:**

- Check combination switch system terminal waveform under the loaded condition with lighting switch, turn signal switch and wiper switch OFF not to be fluctuated by overloaded.
- Turn wiper dial position to 4 except when checking waveform or voltage of wiper dial position. Wiper dial position can be confirmed on CONSULT-II. Refer to [LT-86, "DATA MONITOR"](#).

Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
2	G/R	Combination switch input 5	ON	OFF	Approx. 0 V
				Lighting, turn, wiper switch (Wiper intermittent dial position 4) Turn signal switch to right	 <p style="text-align: right; font-size: small;">PKIB4959J</p>
3	G	Combination switch input 4	ON	OFF	Approx. 0 V
				Lighting, turn, wiper switch (Wiper intermittent dial position 4) Turn signal switch to left	 <p style="text-align: right; font-size: small;">PKIB4959J</p>
11	LG	Ignition switch (ACC)	ACC	—	Battery voltage
29	GR	Hazard switch signal	OFF	Hazard switch ON	Approx. 0 V
				Hazard switch OFF	Battery voltage
36	Y	Combination switch output 1	ON	OFF	 <p style="text-align: right; font-size: small;">PKIB4960J</p>
				Any of the conditions below ● Turn signal switch to right ● Turn signal switch to left	 <p style="text-align: right; font-size: small;">PKIB4958J</p>
38	W/L	Ignition switch (ON)	ON	—	Battery voltage
39	L	CAN - H	—	—	—
40	P	CAN - L	—	—	—
42	GY	Battery power supply	OFF	—	Battery voltage

# TURN SIGNAL AND HAZARD WARNING LAMPS

Terminal No.	Wire color	Signal name	Measuring condition			Reference value
			Ignition switch	Operation or condition		
45	G/W	Turn signal (left)	ON	Combination switch	Turn left ON	
46	PU/W	Turn signal (right)	ON	Combination switch	Turn right ON	
52	B	Ground	ON	—		Approx. 0 V
55	R	Battery power supply	OFF	—		Battery voltage

## How to Proceed With Trouble Diagnosis

NKS0020T

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-77, "System Description"](#).
3. Perform the preliminary check. Refer to [LT-85, "Preliminary Check"](#).
4. Check symptom and repair or replace the malfunctioning parts.
5. Do turn signal and hazard warning lamps operate normally? If YES, GO TO 6. If NO, GO TO 4.
6. INSPECTION END

## Preliminary Check

NKS0020U

### CHECK POWER SUPPLY AND GROUND CIRCUIT

#### 1. CHECK FUSES AND FUSIBLE LINK

Check for blown fuses and fusible link.

Unit	Power source	Fuse and fusible link No.
BCM	Battery	F
		18
	Ignition switch ON or START position	1
	Ignition switch ACC or ON position	6
Combination meter	Battery	19
	Ignition switch ON or START position	14

Refer to [LT-81, "Wiring Diagram — TURN —"](#).

#### OK or NG

OK >> GO TO 2.

NG >> If fuse is or fusible link blown, be sure to eliminate cause of malfunction before installing new fuse or fusible link. Refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#).

# TURN SIGNAL AND HAZARD WARNING LAMPS


## 2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check voltage between BCM harness connector and ground.

(+)		(-)	Ignition switch position		
BCM connector	Terminal		OFF	ACC	ON
M1	11	Ground	Approx. 0 V	Battery voltage	Battery voltage
	38		Approx. 0 V	Approx. 0 V	Battery voltage
M2	42		Battery voltage	Battery voltage	Battery voltage
	55		Battery voltage	Battery voltage	Battery voltage

OK or NG

- OK >> GO TO 3.  
 NG >> Repair harness or connector.




## 3. CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

BCM connector	Terminal	Ground	Continuity
M2	52		Yes

OK or NG

- OK >> INSPECTION END  
 NG >> Repair harness or connector.



## CONSULT-II Functions (BCM)

CONSULT-II can display each diagnostic item using the diagnostic test mode shown following.

BCM diagnosis part	Diagnosis mode	Description
FLASHER	DATA MONITOR	Displays BCM input data in real time.
	ACTIVE TEST	Operation of electrical loads can be checked by sending driving signal to them.

## CONSULT-II BASIC OPERATION

Refer to [GI-37, "CONSULT-II Start Procedure"](#) .

### DATA MONITOR

#### Operation Procedure

1. Touch "FLASHER" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
3. Touch either "ALL SIGNALS" or "SELECTION FROM MENU" on "SELECT MONITOR ITEM" screen.

ALL SIGNALS	Monitors all the signals.
SELECTION FROM MENU	Selects items and monitor them.

# TURN SIGNAL AND HAZARD WARNING LAMPS

4. When "SELECTION FROM MENU" is selected, touch items to be monitored. When "ALL SIGNALS" is selected, all items will be monitored.
5. Touch "START".
6. Touch "RECORD" while monitoring, then the status of monitored item can be recorded. To stop recording, touch "STOP".

## Display Item List

Monitor item	Contents
IGN ON SW "ON/OFF"	Displays status (ignition switch IGN position: ON/other: OFF) of ignition switch judged from the ignition switch signal.
HAZARD SW "ON/OFF"	Displays status (hazard switch ON position: ON/other: OFF) of hazard switch judged from the hazard switch signal.
TURN SIGNAL R "ON/OFF"	Displays status (turn signal switch right position: ON/other: OFF) of turn RH switch judged from the turn signal switch signal.
TURN SIGNAL L "ON/OFF"	Displays status (turn signal switch left position: ON/other: OFF) of turn LH switch judged from the turn signal switch signal.
BRAKE SW "ON/OFF"	Displays status (brake lamp switch ON position: ON/other: OFF) of brake lamp switch judged from the brake lamp switch signal.

## ACTIVE TEST

### Operation Procedure

1. Touch "FLASHER" on "SELECT TEST ITEM" screen.
2. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
3. Touch item to be tested and check operation of the selected item.
4. During the operation check, touching "OFF" deactivates the operation.

## Display Item List

Test item	Description
FLASHER	Turn signal lamp (right or left) can be operated by any ON-OFF operations.

## Turn Signal Lamp Does Not Operate

NKS0020W

### 1. CHECK BULB

Check each turn signal lamp bulb if the proper bulb is used and if it is not blown.

#### OK or NG

- OK >> GO TO 2.
- NG >> Replace turn signal lamp bulb.

### 2. CHECK COMBINATION SWITCH INPUT SIGNAL

#### ☑ With CONSULT-II

Select "BCM" on CONSULT-II. With "FLASHER" data monitor, make sure "TURN SIGNAL R" and "TURN SIGNAL L" turns ON-OFF linked with operation of turn signal switch.

**When turn signal switch is : TURN SIGNAL R ON  
RH position**

**When turn signal switch is : TURN SIGNAL L ON  
LH position**

#### ☒ Without CONSULT-II

Refer to [LT-100, "Combination Switch Inspection"](#).

#### OK or NG

- OK >> GO TO 3.
- NG >> Check combination switch (lighting switch). Refer to [LT-100, "Combination Switch Inspection"](#).

DATA MONITOR			
MONITOR			
TURN SIGNAL R	ON		
TURN SIGNAL L	ON		
RECORD			
MODE	BACK	LIGHT	COPY

PKIA7600E

# TURN SIGNAL AND HAZARD WARNING LAMPS

## 3. ACTIVE TEST

☑ With CONSULT-II

1. Select "BCM" on CONSULT-II. Select "FLASHER" active test. Refer to [LT-87, "ACTIVE TEST"](#) .
2. Touch "RH" or "LH" screen.
3. Make sure turn signal lamp RH and LH operates.

**Turn signal lamp should operate.**


☒ Without CONSULT-II

GO TO 4.

OK or NG

OK >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#) .

NG >> GO TO 4.



## 4. CHECK SHORT CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect BCM connector and all turn signal lamp connectors.
3. Check continuity (short circuit) between BCM harness connector and ground.

BCM connector		Terminal	Ground	Continuity
RH	M2	46		No
LH		45		

OK or NG

OK >> Replace BCM if turn signal lamps does not work after setting the connector again. Refer to [BCS-16, "Removal and Installation of BCM"](#) .

NG >> Repair harness or connector.





# TURN SIGNAL AND HAZARD WARNING LAMPS

## Hazard Warning Lamp Does Not Operate But Turn Signal Lamp Operates


NKS0020X

### 1. CHECK HAZARD SWITCH INPUT SIGNAL

① With CONSULT-II

Select "BCM" on CONSULT-II. With "FLASHER" data monitor, make sure "HAZARD SW" turns ON-OFF linked with operation of hazard switch.

**When hazard switch is ON : HAZARD SW ON position**




② Without CONSULT-II

Check voltage between BCM harness connector and ground.

(+)		(-)	Condition	Voltage
BCM connector	Terminal			
M1	29	Ground	Hazard switch is ON	Approx. 0 V
			Hazard switch is OFF	Battery voltage

OK or NG

- OK >> Replace BCM. Refer to [BCS-16. "Removal and Installation of BCM"](#).
- NG >> GO TO 2.



### 2. CHECK HAZARD SWITCH CIRCUIT


- Turn ignition switch OFF.
- Disconnect BCM connector and hazard switch connector.
- Check continuity BCM harness connector M1 terminal 29 and hazard switch harness connector M282\*1, M46\*2 terminal 2.

**29 – 2 : Continuity should exist.**

\*1: with A/T, \*2: with M/T

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness or connector.



### 3. CHECK HAZARD SWITCH GROUND


Check continuity hazard switch harness connector M282\*1, M46\*2 terminal 1 and ground.

**1 – Ground : Continuity should exist.**

\*1: with A/T, \*2: with M/T

OK or NG

- OK >> GO TO 4.
- NG >> Repair harness or connector.



# TURN SIGNAL AND HAZARD WARNING LAMPS


## 4. CHECK HAZARD SWITCH

1. Disconnect hazard switch connector.
2. Check continuity hazard switch terminals.

Hazard switch		Condition	Continuity
Terminal			
1	2	Hazard switch is ON	Yes
		Hazard switch is OFF	No

### OK or NG

- OK >> Replace BCM if turn signal lamps does not work after setting the connector again. Refer to [BCS-16, "Removal and Installation of BCM"](#) .
- NG >> Replace hazard switch.



### Bulb Replacement FRONT TURN SIGNAL LAMP

NKS002OZ

Refer to [LT-30, "Bulb Replacement"](#) .

### REAR TURN SIGNAL LAMP

Refer to [LT-126, "Bulb Replacement"](#) .

### Removal and Installation FRONT TURN SIGNAL LAMP

NKS002P0

Refer to [LT-32, "Removal and Installation"](#) .

### REAR TURN SIGNAL LAMP

Refer to [LT-126, "Removal and Installation"](#) .

# LIGHTING AND TURN SIGNAL SWITCH

## LIGHTING AND TURN SIGNAL SWITCH


PPF:25540

### Removal and Installation

NKS000D

#### REMOVAL

1. Remove steering column cover. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#).
2. Remove mounting bolts of cluster lid A and combination meter. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#).
3. While pressing pawls in direction as shown in the figure, pull lighting and turn signal switch toward driver door and disconnect from the base.
4. Disconnect lighting and turn signal switch connector.



#### INSTALLATION

Installation is the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# HAZARD SWITCH

## HAZARD SWITCH


PFP:25290

### Removal and Installation (M/T)

NKS0001E

#### REMOVAL

1. Remove console boot (M/T). Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#) .
2. Disconnect hazard switch connector.
3. Remove screws.
4. Remove hazard switch.



#### INSTALLATION


Installation is the reverse order of removal.

### Removal and Installation (A/T)

NKS0001F

#### REMOVAL

1. Remove console finisher (A/T). Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#) .
2. Disconnect hazard switch connector.
3. Remove screws.
4. Remove hazard switch.



#### INSTALLATION

Installation is the reverse order of removal.

# COMBINATION SWITCH




PFP:25567

## COMBINATION SWITCH

### Wiring Diagram — COMBSW —

NKS002P1

## LT-COMBSW-01



REFER TO THE FOLLOWING.

- E108 -SUPER MULTIPLE JUNCTION (SMJ)
- M4 -FUSE BLOCK-JUNCTION BOX (J/B)
- M1, M2 -ELECTRICAL UNITS

TKWM2183E

# COMBINATION SWITCH

## Combination Switch Reading Function

NKS002P2

For details, refer to [BCS-3, "COMBINATION SWITCH READING FUNCTION"](#).

## Terminals and Reference Values for BCM

NKS002Q1

### CAUTION:

- Check combination switch system terminal waveform under the loaded condition with lighting switch, turn signal and wiper switch OFF not to be fluctuated by overloaded.
- Turn wiper dial position to 4 except when checking waveform or voltage of wiper dial position. Wiper dial position can be confirmed on CONSULT-II. Refer to [LT-99, "DATA MONITOR"](#).





Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
2	G/R	Combination switch input 5	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	<p>OFF</p> <p>Approx. 0 V</p>
				<p>Any of the conditions below</p> <ul style="list-style-type: none"> <li>● Lighting switch 1ST</li> <li>● Lighting switch HIGH beam (Operates only HIGH beam switch)</li> <li>● Turn signal switch to right</li> </ul>	<p>PKIB4959J</p> <p>Approx. 1.0 V</p>
				Lighting switch 2ND	<p>PKIB4953J</p> <p>Approx. 2.0 V</p>
3	G	Combination switch input 4	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	<p>OFF</p> <p>Approx. 0 V</p>
				Front fog lamp switch (Operates only front fog lamp switch)	<p>PKIB4955J</p> <p>Approx. 0.8 V</p>
				<p>Any of the conditions below</p> <ul style="list-style-type: none"> <li>● Lighting switch 2ND</li> <li>● Lighting switch PASSING (Operates only PASSING switch)</li> <li>● Turn signal switch to left</li> </ul>	<p>PKIB4959J</p> <p>Approx. 1.0 V</p>

# COMBINATION SWITCH

Terminal No.	Wire color	Signal name	Measuring condition		Reference value	
			Ignition switch	Operation or condition		
4	W/L	Combination switch input 3	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	OFF	Approx. 0 V
					Any of the conditions below <ul style="list-style-type: none"> <li>● Lighting switch AUTO</li> <li>● Front wiper switch MIST</li> <li>● Front wiper switch INT</li> <li>● Front wiper switch LO</li> </ul>	<p style="text-align: right; font-size: small;">PKIB4959J</p>
5	W/G	Combination switch input 2	ON	Lighting, turn, wiper switch	OFF	Approx. 0 V
					Any of the conditions below <ul style="list-style-type: none"> <li>● Front washer switch (Wiper intermittent dial position 4)</li> <li>● Wiper intermittent dial position 1</li> <li>● Wiper intermittent dial position 5</li> <li>● Wiper intermittent dial position 6</li> </ul>	<p style="text-align: right; font-size: small;">PKIB4959J</p>
6	W/R	Combination switch input 1	ON	Lighting, turn, wiper switch	OFF	Approx. 0 V
					Any of the conditions below <ul style="list-style-type: none"> <li>● Front wiper switch HI (Wiper intermittent dial position 4)</li> <li>● Wiper intermittent dial position 3</li> </ul>	<p style="text-align: right; font-size: small;">PKIB4959J</p>
					Any of the conditions below <ul style="list-style-type: none"> <li>● Wiper intermittent dial position 1</li> <li>● Wiper intermittent dial position 2</li> </ul>	<p style="text-align: right; font-size: small;">PKIB4952J</p>
					Any of the conditions below <ul style="list-style-type: none"> <li>● Wiper intermittent dial position 6</li> <li>● Wiper intermittent dial position 7</li> </ul>	<p style="text-align: right; font-size: small;">PKIB4955J</p>
11	LG	Ignition switch (ACC)	ACC	—	Battery voltage	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# COMBINATION SWITCH

Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
32	GY	Combination switch output 5	ON	Lighting, turn, wiper switch	OFF (Wiper intermittent dial position 4)  Approx. 7.2 V
					Any of the conditions below <ul style="list-style-type: none"> <li>● Front fog lamp switch (Operates only front fog lamp switch)</li> <li>● Wiper intermittent dial position 1</li> <li>● Wiper intermittent dial position 2</li> <li>● Wiper intermittent dial position 6</li> <li>● Wiper intermittent dial position 7</li> </ul>  Approx. 1.0 V
33	L	Combination switch output 4	ON	Lighting, turn, wiper switch	OFF (Wiper intermittent dial position 4)  Approx. 7.2 V
					Any of the conditions below <ul style="list-style-type: none"> <li>● Lighting switch AUTO (Wiper dial position 4)</li> <li>● Lighting switch 1ST (The same result with lighting switch 2ND) (Wiper intermittent dial position 4)</li> <li>● Rear wiper switch INT</li> <li>● Wiper intermittent dial position 1</li> <li>● Wiper intermittent dial position 5</li> <li>● Wiper intermittent dial position 6</li> </ul>  Approx. 1.2 V



# COMBINATION SWITCH

Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
34	PU	Combination switch output 3	ON	Lighting, turn, wiper switch	OFF 
					Any of the conditions below <ul style="list-style-type: none"> <li>● Lighting switch 2ND</li> <li>● Lighting switch HI beam (Operates only HI beam switch)</li> <li>● Wiper intermittent dial position 1</li> <li>● Wiper intermittent dial position 2</li> <li>● Wiper intermittent dial position 3</li> </ul>
35	Y/R	Combination switch output 2	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	OFF 
					Any of the conditions below <ul style="list-style-type: none"> <li>● Lighting switch 2ND</li> <li>● Lighting switch PASSING (Operates only PASSING switch)</li> <li>● Front wiper switch INT</li> <li>● Front wiper switch HI</li> </ul>
36	Y	Combination switch output 1	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	OFF 
					Any of the conditions below <ul style="list-style-type: none"> <li>● Turn signal switch to right</li> <li>● Turn signal switch to left</li> <li>● Front wiper switch MIST</li> <li>● Front wiper switch LO</li> <li>● Front washer switch</li> </ul>
38	W/L	Ignition switch (ON)	ON	—	Battery voltage

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

## COMBINATION SWITCH

Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
39	L	CAN – H	—	—	—
40	P	CAN – L	—	—	—
42	GY	Battery power supply	OFF	—	Battery voltage
52	B	Ground	ON	—	Approx. 0 V
55	W/R	Battery power supply	OFF	—	Battery voltage

# COMBINATION SWITCH

## CONSULT-II Function (BCM)

NKS002P3

CONSULT-II can display each diagnostic item using the diagnostic test mode shown following.

BCM diagnosis part	Diagnosis mode	Description
COMB SW	DATA MONITOR	Displays BCM input data in real time.

## CONSULT-II BASIC OPERATION

Refer to [GI-37, "CONSULT-II Start Procedure"](#) .

### DATA MONITOR

#### Operation Procedure

1. Touch "COMB SW" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
3. Touch either "ALL SIGNALS" or "SELECTION FROM MENU" on "SELECT MONITOR ITEM" screen.

ALL SIGNALS	Monitors all the signals.
SELECTION FROM MENU	Selects item and monitor them.

4. When "SELECTION FROM MENU" is selected, touch items to be monitored. When "ALL SIGNALS" is selected, all signals will be monitored.
5. Touch "START".
6. Touch "RECORD" while monitoring, then the status of monitored item can be recorded. To stop recording, touch "STOP".

#### Display Item List

Monitor item name	Contents
TURN SIGNAL R "ON/OFF"	Displays status (turn signal switch right position: ON/other: OFF) of turn RH switch judged from the turn signal switch signal.
TURN SIGNAL L "ON/OFF"	Displays status (turn signal switch left position: ON/other: OFF) of turn LH switch judged from the turn signal switch signal.
HI BEAM SW "ON/OFF"	Displays status (lighting switch high beam position: ON/other: OFF) of high beam switch judged from the lighting switch signal.
HEAD LAMP SW 1 "ON/OFF"	Displays status (lighting switch 2ND position: ON/other: OFF) of headlamp 1 switch judged from the lighting switch signal.
HEAD LAMP SW 2 "ON/OFF"	Displays status (lighting switch 2ND position: ON/other: OFF) of headlamp 2 switch judged from the lighting switch signal.
LIGHT SW 1ST "ON/OFF"	Displays status (lighting switch 1ST or 2ND position: ON/other: OFF) of lighting switch 1ST position switch judged from the lighting switch signal.
PASSING SW "ON/OFF"	Displays status (lighting switch passing position: ON/other: OFF) of passing switch judged from the lighting switch signal.
AUTO LIGHT SW "ON/OFF"	Displays status (lighting switch AUTO position: ON/other: OFF) of auto light switch position judged from the lighting switch signal.
FR FOG SW "ON/OFF"	Displays status (lighting switch front fog lamp ON position: ON/others: OFF) of front fog lamp switch judged from the lighting switch signal.
RR FOG SW <sup>NOTE</sup> "ON/OFF"	—
FR WIPER HI "ON/OFF"	Displays status (front wiper switch high position: ON/other: OFF) of front wiper high switch judged from the wiper switch signal.
FR WIPER LOW "ON/OFF"	Displays status (front wiper switch low position: ON/other: OFF) of front wiper low switch judged from the wiper switch signal.
FR WIPER INT "ON/OFF"	Displays status (front wiper switch intermittent position: ON/other: OFF) of front wiper intermittent switch judged from the wiper switch signal.
FR WASHER SW "ON/OFF"	Displays status (front washer switch ON position: ON/other: OFF) of front washer switch judged from the wiper switch signal.
INT VOLUME "1 - 7"	Displays status (wiper intermittent dial position setting 1-7) of intermittent volume switch judged from the wiper switch signal.

# COMBINATION SWITCH

Monitor item name	Contents
RR WIPER ON <sup>NOTE</sup> "OFF"	—
RR WIPER INT <sup>NOTE</sup> "OFF"	—
RR WASHER SW <sup>NOTE</sup> "OFF"	—

**NOTE:**

This item is displayed, but cannot be monitored.

## Combination Switch Inspection

NKS002P4

### 1. SYSTEM CHECK

Referring to table below, check which system malfunctioning switch belongs to.

System 1	System 2	System 3	System 4	System 5
—	FR WASHER	FR WIPER LO	TURN LH	TURN RH
FR WIPER HI	—	FR WIPER INT	PASSING	HEAD LAMP1
INT VOLUME 1	RR WASHER	—	HEAD LAMP2	HI BEAM
RR WIPER INT	INT VOLUME 3	AUTO LIGHT	—	LIGHT SW 1ST
INT VOLUME 2	RR WIPER ON	—	FR FOG	—

>> Check the system to which malfunctioning switch belongs, and GO TO 2.

### 2. SYSTEM CHECK

 With CONSULT-II

**CAUTION:**

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

1. Connect CONSULT-II, and select "COMB SW" on "SELECT TEST ITEM" screen.
2. Select "DATA MONITOR".
3. Select "START", and confirm that other switches in malfunctioning system operate normally.  
Example: When the auto light switch is malfunctioning, confirm that "FRONT WIPER LOW" and "FRONT WIPER INT" in system 3, to which the auto light switch belongs, turn ON-OFF normally.

DATA MONITOR	
MONITOR	
TURN SIGNAL R	OFF
TURN SIGNAL L	OFF
HIBEAM SW	OFF
HEAD LAMP SW1	OFF
HEAD LAMP SW2	OFF
LIGHT SW 1ST	OFF
PASSING SW	OFF
AUTO LIGHT SW	OFF
FR FOG SW	OFF
	Page Down
	RECORD
MODE	BACK LIGHT COPY

PKIA7602E

 Without CONSULT-II

Operating combination switch, and confirm that other switches in malfunctioning system operate normally.  
Example: When the auto light switch is malfunctioning, confirm that FRONT WIPER LOW and FRONT WIPER INT in system 3, to which the auto light switch belongs, operate normally.

Check results


- Other switches in malfunctioning system operate normally.>>Replace lighting switch or wiper switch.
- Other switches in malfunctioning system do not operate normally.>>GO TO 3.

# COMBINATION SWITCH

## 3. CHECK HARNESS


1. Turn ignition switch OFF.
2. Disconnect BCM connector and combination switch connector.
3. Check for continuity between BCM harness connector of the suspect system and the corresponding combination switch harness connector.

Suspect system	BCM		Combination switch		Continuity	
	Connector	Terminal	Connector	Terminal		
1	M1	Input 1	6	M29	6	Yes
		Output 1	36		1	
2		Input 2	5		7	
		Output 2	35		2	
3		Input 3	4		10	
		Output 3	34		3	
4		Input 4	3		9	
		Output 4	33		4	
5		Input 5	2		8	
		Output 5	32		5	



4. Check for continuity between BCM harness connector in suspect malfunctioning system and ground.

Suspect system	BCM connector	Terminal		Continuity	
1	M1	Input 1	6	Ground	No
		Output 1	36		
2		Input 2	5		
		Output 2	35		
3		Input 3	4		
		Output 3	34		
4		Input 4	3		
		Output 4	33		
5		Input 5	2		
		Output 5	32		



OK or NG


OK >> GO TO 4.

NG >> Check harness between BCM and combination switch for open or short circuit.

# COMBINATION SWITCH

## 4. CHECK BCM OUTPUT TERMINAL

1. Turn lighting switch and wiper switch OFF position.
2. Set wiper dial position 4.
3. Connect BCM connector and combination switch connector.
4. Turn ignition switch ON.
5. Check BCM output terminal voltage waveform of suspect malfunctioning system.



Suspect system	(+)		(-)	Reference value
	Combination switch connector	Terminal		
1	M29	1	Ground	<p>PKIB4960J</p>
2		2		
3		3		
4		4		
5		5		

OK or NG

OK >> Open circuit in combination switch, GO TO 5.

NG >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#) .

## 5. CHECK COMBINATION SWITCH

Referring to table below, perform combination switch inspection.

Procedure												
1	2		3		4		5		6		7	
Replace lighting switch	Confirm check results	OK	INSPECTION END		Confirm check results	OK	INSPECTION END		Confirm check results	OK	INSPECTION END	
		NG	Replace wiper switch			NG	Replace switch base			NG	Confirm symptom again	

>> INSPECTION END

## Removal and Installation

NKS002P5

For details, refer to [LT-91, "LIGHTING AND TURN SIGNAL SWITCH"](#) .

# STOP LAMP



## STOP LAMP

PFP:26550

### Wiring Diagram — STOP/L —

NKS000IL

## LT-STOP/L-01



REFER TO THE FOLLOWING.

⊠E108⊠, ⊠B1⊠, ⊠B401⊠ -SUPER MULTIPLE JUNCTION (SMJ)

⊠E101⊠ -FUSE BLOCK-JUNCTION BOX (J/B)

TKWM2206E

# STOP LAMP

LT-STOP/L-02


⬡HP⬢ : WITH HIGH-MOUNTED STOP LAMP ON THE REAR PARCEL SHELF

⬡A⬢ : WITH A/T


⬡M⬢ : WITH M/T

\*1 W : ⬡A⬢

R/L : ⬡M⬢



B116  
BR



B125  
W

B127  
W

TKWM4922E



# STOP LAMP

## Bulb Replacement of High-Mounted Stop Lamp WITH REAR SPOILER

NKS000IM

1. Remove high-mounted stop lamp. Refer to [LT-105, "REMOVAL \(WITH REAR SPOILER\)"](#) .
2. Replace together with high-mounted stop lamp.

**High-mounted stop lamp : LED**

3. Installation is the reverse order of removal.

## WITHOUT REAR SPOILER

1. Remove high-mounted stop lamp. Refer to [LT-105, "REMOVAL \(WITHOUT REAR SPOILER\)"](#) .
2. Replace together with high-mounted stop lamp.

**High-mounted stop lamp : LED**

3. Installation is the reverse order of removal.

## Bulb Replacement of Rear Combination Lamp (Stop Lamp)


NKS000IN

Refer to [LT-126, "Bulb Replacement"](#) .

## Removal and Installation of High-Mounted Stop Lamp REMOVAL (WITH REAR SPOILER)

NKS000IO

1. Remove rear spoiler. Refer to [EI-27, "REAR SPOILER"](#) .
2. Remove screws and remove high-mounted stop lamp from rear spoiler.
3. Disconnect high-mounted stop lamp connector.




## INSTALLATION

Installation is the reverse order of removal.

## REMOVAL (WITHOUT REAR SPOILER)

1. Remove rear parcel shelf finisher. Refer to [EI-33, "REAR PARCEL SHELF FINISHER"](#) .
2. Remove screws and remove high-mounted stop lamp from rear parcel shelf finisher.
3. Disconnect high-mounted stop lamp connector.



## INSTALLATION

Installation is the reverse order of removal.

## Removal and Installation of Rear Combination Lamp (Stop Lamp)

NKS000IP

Refer to [LT-126, "Removal and Installation"](#) .

# BACK-UP LAMP









PFP:26550

NKS000IS

## BACK-UP LAMP

### Wiring Diagram — BACK/L — A/T MODELS

LT-BACK/L-01




\*: THIS CONNECTOR IS NOT SHOWN IN "HARNES LAYOUT", PG SECTION.




# BACK-UP LAMP

M/T MODELS


LT-BACK/L-02



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M



REFER TO THE FOLLOWING.  
F102, B1 -SUPER MULTIPLE JUNCTION (SMJ)



# BACK-UP LAMP

---

## **Bulb Replacement**

*NKS000IT*

Refer to [LT-126, "Bulb Replacement"](#) .

## **Removal and Installation**

*NKS000IU*

Refer to [LT-126, "Removal and Installation"](#) .


# PARKING, LICENSE PLATE AND TAIL LAMPS

## PARKING, LICENSE PLATE AND TAIL LAMPS

PPF:26550

### Component Parts and Harness Connector Location

NKS002P6



## System Description

NKS002P7

The control of the parking, license plate, side marker and tail lamp operation is dependent upon the position of lighting switch. When the lighting switch is placed in the 1ST position, 2ND position or AUTO position (head-lamp is ON), the BCM (body control module) receives input signal requesting the parking, license plate, side marker and tail lamps to illuminate. This input signal is communicated to the IPDM E/R (intelligent power distribution module engine room) through the CAN communication lines. The CPU (central processing unit) located in the IPDM E/R controls the tail lamp relay. This relay, when energized, directs power to parking, license plate, side marker and tail lamps, which then illuminate.

Power is supplied at all times

- through 10A fuse (No. 71, located in IPDM E/R)
- to CPU located in IPDM E/R, and
- to tail lamp relay, located in IPDM E/R,
- through 15A fuse (No. 78, located in IPDM E/R)
- to CPU located in IPDM E/R,
- through 50A fusible link (letter F, located in fuse, fusible link and relay box)
- to BCM terminal 55,
- through 10A fuse [No. 18, located in fuse block (J/B)]
- to BCM terminal 42.

With the ignition switch in the ON or START position, power is supplied

- to CPU located in IPDM E/R, from battery direct,
- through 10A fuse [No. 1, located in fuse block (J/B)]

A  
B  
C  
D  
E  
F  
G  
H  
I  
J

LT

L  
M

# PARKING, LICENSE PLATE AND TAIL LAMPS

---

- to BCM terminal 38.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 6, located in fuse block (J/B)]
- to BCM terminal 11.

Ground is supplied

- to BCM terminal 52
- through grounds M30 and M66,
- to IPDM E/R terminals 38 and 60
- through grounds E17 and E43.

## OPERATION BY LIGHTING SWITCH

With the lighting switch in the 1ST position, 2ND position or AUTO position (headlamp is ON), the BCM receives input signal requesting parking, license plate, side marker and tail lamps to illuminate. This input signal is communicated to the IPDM E/R through CAN communication lines. The CPU located in the IPDM E/R controls tail lamp relay, which when energized, directs power

- through IPDM E/R terminal 22
- to front side marker lamp RH and LH terminals 1
- to front combination lamp RH and LH terminals 7
- to rear combination lamp RH and LH terminals 3, and
- to license plate lamp RH and LH terminals 1.

Ground is supplied

- to front side marker lamp RH and LH terminals 2, and
- to front combination lamp RH and LH terminals 8
- through grounds E17 and E43,
- to rear combination lamp RH and LH terminals 4
- through ground B103,
- to license plate lamp RH and LH terminals 2
- through grounds B5 and B29.

With power and ground supplied, parking, license plate, side marker and tail lamps illuminate.

## COMBINATION SWITCH READING FUNCTION

Refer to [BCS-3, "COMBINATION SWITCH READING FUNCTION"](#) .

## EXTERIOR LAMP BATTERY SAVER CONTROL

When the lighting switch is in the 1ST or 2ND position and ignition switch is turned from ON or ACC to OFF, battery saver control feature is activated.

Under this condition, parking, license plate, side marker and tail lamps remain illuminated for 5 minutes, then the parking, license plate, side marker and tail lamps are turned off.

Exterior lamp battery saver control mode can be changed by the function setting of CONSULT-II.

## CAN Communication System Description

NKS002P8

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

## CAN Communication Unit


NKS002P9

Refer to [LAN-47, "CAN System Specification Chart"](#) .

# PARKING, LICENSE PLATE AND TAIL LAMPS

## Schematic

NKS002PA



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M




TKWM5160E

# PARKING, LICENSE PLATE AND TAIL LAMPS

NKS002/PB

## Wiring Diagram — TAIL/L —

### LT-TAIL/L-01



REFER TO THE FOLLOWING.

- (E108), (B1) -SUPER MULTIPLE JUNCTION (SMJ)
- (M4) -FUSE BLOCK-JUNCTION BOX (J/B)
- (M1), (M2) -ELECTRICAL UNITS



TKWM3459E



# PARKING, LICENSE PLATE AND TAIL LAMPS

LT-TAIL/L-02

▬ : DATA LINE



A

B

C

D

E

F

G

H

I

J

LT



L

M

TKWM3460E

# PARKING, LICENSE PLATE AND TAIL LAMPS


LT-TAIL/L-03



TKWM4011E

# PARKING, LICENSE PLATE AND TAIL LAMPS

LT-TAIL/L-04



TKWM4924E




# PARKING, LICENSE PLATE AND TAIL LAMPS

## Terminals and Reference Values for BCM

NKS002PC

### CAUTION:

- Check combination switch system terminal waveform under the loaded condition with lighting switch, turn signal switch and wiper switch OFF not to be fluctuated by overloaded.
- Turn wiper dial position to 4 except when checking waveform or voltage of wiper dial position. Wiper dial position can be confirmed on CONSULT-II. Refer to [LT-17, "DATA MONITOR"](#).

Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
2	G/R	Combination switch input 5	ON	OFF	Approx. 0 V
				Lighting switch 1ST (Wiper intermittent dial position 4)	 <p>Approx. 1.0 V</p>
11	LG	Ignition switch (ACC)	ACC	—	Battery voltage
33	L	Combination switch output 4	ON	OFF	 <p>Approx. 7.2 V</p>
				Lighting switch 1ST (The same result with lighting switch 2ND)	 <p>Approx. 1.2 V</p>
38	W/L	Ignition switch (ON)	ON	—	Battery voltage
39	L	CAN – H	—	—	—
40	P	CAN – L	—	—	—
42	GY	Battery power supply	OFF	—	Battery voltage
52	B	Ground	ON	—	Approx. 0 V
55	R	Battery power supply	OFF	—	Battery voltage

## Terminals and Reference Values for IPDM E/R

NKS002PD

Terminal No.	Wire color	Signal name	Measuring condition		Reference value	
			Ignition switch	Operation or condition		
22	R/L	Parking, license plate, side marker and tail lamps	ON	Lighting switch 1ST position	OFF	Approx. 0 V
				ON	Battery voltage	
38	B/R	Ground	ON	—	Approx. 0 V	
48	L	CAN – H	—	—	—	

# PARKING, LICENSE PLATE AND TAIL LAMPS

Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
49	P	CAN – L	—	—	—
60	B/R	Ground	ON	—	Approx. 0 V

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

## How to Proceed With Trouble Diagnosis

NKS002PE

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-109, "System Description"](#) .
3. Perform the preliminary check. Refer to [LT-117, "Preliminary Check"](#) .
4. Check symptom and repair or replace the malfunctioning parts.
5. Do the parking, license plate and tail lamps operate normally? If YES, GO TO 6. If NO, GO TO 4.
6. INSPECTION END

## Preliminary Check

NKS002PF

### CHECK POWER SUPPLY AND GROUND CIRCUIT

#### 1. CHECK FUSES AND FUSIBLE LINK

Check for blown fuses and fusible link.

Unit	Power source	Fuse and fusible link No.
BCM	Battery	F
		18
	Ignition switch ON or START position	1
	Ignition switch ACC or ON position	6
IPDM E/R	Battery	71

Refer to [LT-112, "Wiring Diagram — TAIL/L —"](#) .

OK or NG

OK >> GO TO 2.

NG >> If fuse or fusible link is blown, be sure to eliminate cause of malfunction before installing new fuse or fusible link. Refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#) .

LT

# PARKING, LICENSE PLATE AND TAIL LAMPS

## 2. CHECK POWER SUPPLY CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check voltage between BCM harness connector and ground.

(+)		(-)	Ignition switch position		
BCM connector	Terminal		OFF	ACC	ON
M1	11	Ground	Approx. 0 V	Battery voltage	Battery voltage
	38		Approx. 0 V	Approx. 0 V	Battery voltage
M2	42		Battery voltage	Battery voltage	Battery voltage
	55		Battery voltage	Battery voltage	Battery voltage

OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.



## 3. CHECK GROUND CIRCUIT


Check continuity between BCM harness connector and ground.

BCM connector	Terminal	Ground	Continuity
M2	52		Yes

OK or NG

OK >> INSPECTION END

NG >> Repair harness or connector.



### CONSULT-II Functions (BCM)

Refer to [LT-16, "CONSULT-II Functions \(BCM\)"](#).

### CONSULT-II Functions (IPDM E/R)

Refer to [LT-18, "CONSULT-II Functions \(IPDM E/R\)"](#).

NKS002PG

NKS002PH

# PARKING, LICENSE PLATE AND TAIL LAMPS

## Parking, License Plate, Side Marker and Tail Lamps Do Not Illuminate

NKS002PI

### 1. CHECK COMBINATION SWITCH INPUT SIGNAL

④ With CONSULT-II

Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "LIGHT SW 1ST" turns ON-OFF linked with operation of lighting switch.

**When lighting switch is 1ST : LIGHT SW 1ST ON position**

⊗ Without CONSULT-II

Refer to [LT-100, "Combination Switch Inspection"](#).

OK or NG

OK >> GO TO 2.

NG >> Check combination switch (lighting switch). Refer to [LT-100, "Combination Switch Inspection"](#).

DATA MONITOR			
MONITOR			
LIGHT SW 1ST	ON		
		RECORD	
MODE	BACK	LIGHT	COPY

PKIA7607E

### 2. ACTIVE TEST

④ With CONSULT-II

1. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "TAIL LAMP" on "SELECT TEST ITEM" screen.
3. Touch "ON" screen.
4. Make sure parking, license plate, side marker and tail lamps operates.

**Parking, license plate, side marker and tail lamps should operate.**

⊗ Without CONSULT-II

1. Start auto active test. Refer to [PG-21, "Auto Active Test"](#).
2. Make sure parking, license plate, side marker and tail lamps operates.

**Parking, license plate, side marker and tail lamps should operate.**

OK or NG

OK >> GO TO 3.

NG >> GO TO 4.

### 3. CHECK IPDM E/R

1. Select "IPDM E/R" on CONSULT-II, and select "DATA MONITOR" on "SELECT DIAG MODE" screen.
2. Make sure "TAIL&CLR REQ" turns ON when lighting switch is in 1ST position.

**When lighting switch is 1ST : TAIL&CLR REQ ON position**

OK or NG

OK >> Replace IPDM E/R. Refer to [PG-27, "Removal and Installation of IPDM E/R"](#).

NG >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#).

ACTIVE TEST			
TAIL LAMP	ON		
		OFF	
		RECORD	
MODE	BACK	LIGHT	COPY

PKIA7753E

DATA MONITOR			
MONITOR			
TAIL&CLR REQ	ON		
		RECORD	
MODE	BACK	LIGHT	COPY

SKIA5958E

# PARKING, LICENSE PLATE AND TAIL LAMPS

## 4. CHECK INPUT SIGNAL


☑ With CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front side marker lamp RH and LH, front combination lamp RH and LH, license plate lamp RH and LH, and rear combination lamp RH and LH connectors.
3. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
4. Select "TAIL LAMP" on "SELECT TEST ITEM" screen.
5. Touch "ON" screen.
6. When tail lamp relay is operating, check voltage between front side marker lamp, front combination lamp, license plate lamp and rear combination lamp harness connector and ground.


☒ Without CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front side marker lamp RH and LH, front combination lamp RH and LH, license plate lamp RH and LH, and rear combination lamp RH and LH connectors.
3. Start auto active test. Refer to [PG-21, "Auto Active Test"](#).
4. When tail lamp relay is operating, check voltage between front side marker lamp, front combination lamp, license plate lamp, rear combination lamp harness connector and ground.


(+)		Terminal	(-)	Voltage
Front side marker lamp connector				
RH	E28			
LH	E40			



(+)		Terminal	(-)	Voltage
Front side marker lamp connector (Parking)				
RH	E24			
LH	E41			



(+)		Terminal	(-)	Voltage
License plate lamp connector				
RH	B153			
LH	B152			






# PARKING, LICENSE PLATE AND TAIL LAMPS

(+)		Terminal	(-)	Voltage
Rear combination lamp connector (Tail and side marker)				
RH	B127	3	Ground	Battery voltage
LH	B125			

**OK or NG**

- OK    >> GO TO 6.
- NG    >> GO TO 5.




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# PARKING, LICENSE PLATE AND TAIL LAMPS


## 5. CHECK PARKING, LICENSE PLATE AND TAIL LAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and front side marker lamp, front combination lamp, license plate lamp and rear combination lamp harness connector.


IPDM E/R		Front side marker lamp		Continuity	
Connector	Terminal	Connector	Terminal		
E7	22	RH	E28	1	Yes
		LH	E40		




IPDM E/R		Front combination lamp (Parking)		Continuity	
Connector	Terminal	Connector	Terminal		
E7	22	RH	E24	7	Yes
		LH	E41		



IPDM E/R		License plate lamp		Continuity	
Connector	Terminal	Connector	Terminal		
E7	22	RH	B153	1	Yes
		LH	B152		



IPDM E/R		Rear combination lamp (Tail and side marker)		Continuity	
Connector	Terminal	Connector	Terminal		
E7	22	RH	B127	3	Yes
		LH	B125		



OK or NG

OK >> Replace IPDM E/R. Refer to [PG-27, "Removal and Installation of IPDM E/R"](#).


NG >> Repair harness or connector.

# PARKING, LICENSE PLATE AND TAIL LAMPS


## 6. CHECK GROUND

Check continuity between front side marker lamp, front combination lamp, license plate lamp and rear combination lamp harness connector and ground.


Front side marker lamp connector		Terminal	Ground	Continuity
RH	E28	2		Yes
LH	E40			




Front combination lamp connector (Parking)		Terminal	Ground	Continuity
RH	E24	8		Yes
LH	E41			



License plate lamp connector		Terminal	Ground	Continuity
RH	B153	2		Yes
LH	B152			



Rear combination lamp connector (Tail and side marker)		Terminal	Ground	Continuity
RH	B127	4		Yes
LH	B125			



### OK or NG

- OK >> Check bulb and replace rear combination lamp.
- NG >> Repair harness or connector.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# PARKING, LICENSE PLATE AND TAIL LAMPS

## Parking, License Plate, Side Marker and Tail Lamps Do Not Turn OFF (After Approx. 10 Minutes)

NKS002PJ

- This symptom indicates the malfunction of ignition relay in IPDM E/R. Refer to [PG-17, "Function of Detecting Ignition Relay Malfunction"](#) .
- Select "BCM" on CONSULT-II. Select "HEADLAMP" on "SELECT TEST ITEM" screen and select "DATA MONITOR" on "SELECT DIAG MODE" screen. If "LIGHT SW 1ST" is OFF when lighting switch is OFF, replace IPDM E/R.

## Bulb Replacement


### FRONT SIDE MARKER LAMP

NKS002PK

1. Remove front side marker lamp. Refer to [LT-125, "FRONT SIDE MARKER LAMP"](#) .
2. Turn bulb socket counterclockwise and unlock it.
3. Remove bulb from it's socket.

**Front side marker lamp : 12 V - 3.8 W**

4. Installation is the reverse order of removal.




### LICENSE PLATE LAMP

1. Remove license plate lamp. Refer to [LT-125, "LICENSE PLATE LAMP"](#) .
2. Turn bulb socket counter click wise and unlock it.
3. Remove bulb from it's socket.

**License plate lamp : 12 V - 5 W**

4. Installation is the reverse order of removal.



### PARKING LAMP

For bulb replacement, refer to [LT-30, "Bulb Replacement"](#) .

### TAIL LAMP

For bulb replacement, refer to [LT-126, "Bulb Replacement"](#) .


# PARKING, LICENSE PLATE AND TAIL LAMPS

## Removal and Installation FRONT SIDE MARKER LAMP

NKS002PL

### Removal

1. Insert a slotted screwdriver or similar tool into fender protector gap to push front side marker lamp metal clip in direction 1 (see figure) while pulling in direction 2. Remove front side marker lamp from vehicle.
2. Disconnect front side marker lamp connector.




### Installation

Installation is the reverse order of removal.

## LICENSE PLATE LAMP

### Removal

1. While pressing pawl on reverse side, push license plate towards you to remove.
2. Disconnect license plate lamp connector.



### Installation

Installation is the reverse order of removal.

## PARKING LAMP

For parking lamp removal and installation procedures, refer to [LT-32, "Removal and Installation"](#) .

## TAIL LAMP

For tail lamp removal and installation procedures, refer to [LT-126, "Removal and Installation"](#) .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# REAR COMBINATION LAMP

## REAR COMBINATION LAMP

PFP:26554

### Bulb Replacement

NKS000JB


1. Remove rear combination lamp. Refer to [LT-126, "Removal and Installation"](#).
2. Turn bulb socket counterclockwise and unlock it.
3. Remove bulb.

**Stop/tail lamp** : LED (Replace together with rear combination lamp assembly.)

**Rear turn signal lamp** : 12 V - 21 W

**Back-up lamp** : 12 V - 18 W

**Rear side marker lamp** : 12 V - 3.8 W




4. Installation is the reverse order of removal.

### Removal and Installation

#### REMOVAL

NKS000JC

1. Open trunk lid and remove trunk rear finisher (end). Refer to [EI-38, "TRUNK ROOM TRIM & TRUNK LID FINISHER"](#).
2. Disconnect rear combination lamp connector.
3. Remove rear combination lamp installation nuts.
4. Pull the rear combination lamp toward rear of the vehicle and remove from the vehicle.
5. Remove seal packing from the vehicle.



#### INSTALLATION

Installation is the reverse order of removal.

- Install a new seal packing to the rear combination lamp.

#### CAUTION:

**Seal packing cannot be reused.**

**Rear combination lamp mounting nut**  : 3.2 N·m (0.33 kg·m, 28 in·lb)

# INTERIOR ROOM LAMP












PPF:26410

NKS002PM

## INTERIOR ROOM LAMP

### Component Parts and Harness Connector Location

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

<p><b>View with dash side LH removed</b> Fuse block (J/B)</p>  <p>BCM (Body Control Module) M1, M2, B4</p>	 <p>Data link connector M8</p>	<p>Without Intelligent Key system <b>View with steering column cover removed</b></p>  <p>Key switch M307</p>
<p>With Intelligent Key system <b>View with steering column cover removed</b></p>  <p>Key switch and ignition knob switch M310</p>	 <p>Driver side door switch B17</p>	 <p>Passenger side door switch B410</p>
<p>Trunk lid lock assembly B419 (Trunk room lamp switch)</p> 	 <p>Power window main switch (Door lock and unlock switch) D7</p>	 <p>Power window sub-switch (Door lock and unlock switch) D43</p>
 <p>Driver side door lock assembly (Door key cylinder switch) D15</p>	<p><b>View with battery removed</b></p>  <p>Fuse, fusible link and relay box</p>	

PKID0822E

# INTERIOR ROOM LAMP

NKS002PN

## System Description

When map lamp switch is in DOOR position, map lamp ON/OFF is controlled by timer according to signals from switches including key switch, front door switch driver side, unlock signal from key fob, door lock and unlock switch, key cylinder lock and unlock switch, ignition switch.

When map lamp turns ON, there is a gradual brightening over 1 second. When map lamp turns OFF, there is a gradual dimming over 1 second.

Map lamp timer is controlled by BCM (body control module).

Map lamp timer control settings can be changed with CONSULT-II.

Ignition keyhole illumination turns ON at time when driver door is opened (door switch ON) or removed key fob from key cylinder. Illumination turns OFF when driver door is closed (door switch OFF).

Step lamp turns ON at time when driver door, passenger door is opened (door switch ON). Lamp turns OFF when driver, passenger doors are closed (all door switches OFF).

## POWER SUPPLY AND GROUND

Power is supplied at all times (without Intelligent Key system)

- through 10A fuse [No. 21, located in fuse block (J/B)]
- to key switch terminal 2,
- through 10A fuse [No. 18, located in fuse block (J/B)]
- to BCM terminal 42,
- through 50A fusible link (letter F, located in fuse, fusible link and relay box)
- to BCM terminal 55.

Power is supplied at all times (with Intelligent Key system)

- through 15A fuse (No.33, located in fuse, fusible link and relay box)
- to key switch and ignition knob switch terminals 1 and 3,
- through 10A fuse [No.18, located infuse block (J/B)]
- to BCM terminal 42,
- through 50A fusible link (letter F, located in fuse, fusible link and relay box)
- to BCM terminal 55.

When key plate inserted to key switch, power is supplied (without Intelligent Key system)

- through key switch terminal 1
- to BCM terminal 37.

When inserted key plate to key switch, power is supplied (with Intelligent Key system)

- through key switch and ignition knob switch terminal 4
- to BCM terminal 37.

When moved ignition knob switch, power is supplied (with Intelligent Key system)

- through key switch and ignition knob switch terminal 2
- to intelligent key unit terminal 27.

With ignition switch in ON or START position, power is supplied

- through 10A fuse [No. 1, located in fuse block (J/B)]
- to BCM terminal 38.

Ground is supplied

- to BCM terminal 52
- through grounds terminals M30 and M66.

When driver side door is opened, ground is supplied

- to BCM terminal 62
- through front door switch driver side terminal 1
- through case ground of driver side door switch.

When passenger side door is opened, ground is supplied

- to BCM terminal 12
- through front door switch passenger side terminal 1
- through case ground of passenger side door switch.



# INTERIOR ROOM LAMP

When driver side door is unlocked by door lock and unlock switch, BCM receives a ground signal

- to BCM terminal 22
- from power window main switch (door lock and unlock switch) terminal 12 and power window sub switch (door lock and unlock switch) terminal 16
- to power window main switch (door lock and unlock switch) terminal 15 and power window sub switch (door lock and unlock switch) terminal 11
- through grounds terminals M30 and M66.

When driver side door is unlocked by driver side door lock assembly (door key cylinder switch), BCM receives a ground signal

- to BCM terminal 22
- through power window main switch (door lock and unlock switch) terminal 12
- to power window main switch (door lock and unlock switch) terminal 7
- through driver side door lock assembly (door key cylinder switch) terminal 6
- to driver side door lock assembly (door key cylinder switch) terminal 5
- through grounds M30 and M66.

When a signal, or combination of signals is received by BCM, ground is supplied

- to map lamp terminal 2
- through BCM terminal 48.

With power and ground supplied, the interior lamp illuminates.

## SWITCH OPERATION

When driver door switch is ON (door is opened), ground is supplied

- to ignition keyhole illumination terminal 2
- through BCM terminal 1.

And power is supplied

- through BCM terminal 41
- to ignition keyhole illumination terminal 1.

When any door switch is ON (door is opened), ground is supplied

- to step lamp (driver side and passenger side) terminal 2
- through BCM terminal 47.

And power is supplied

- through BCM terminal 41
- to step lamp (driver side and passenger side) terminal 1.

When map lamp switch is ON, ground is supplied

- to map lamp terminal 1
- through grounds M30 and M66.

And power is supplied

- through BCM terminal 41
- to map lamp terminal 3.

When vanity mirror lamp (driver side and passenger side) is ON, ground is supplied

- to vanity mirror lamp (driver side and passenger side) terminal 2
- through grounds M30 and M66.

And power is supplied

- through BCM terminal 41
- to vanity mirror lamp (driver side and passenger side) terminal 1.

When trunk room lamp switch is OPEN, ground is supplied

- to BCM terminal 57
- through trunk room lamp switch terminals 3 and 1
- through grounds B402 and B413.

When trunk room lamp is ON, ground is supplied

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# INTERIOR ROOM LAMP

---

- to trunk room lamp terminal 2
- through BCM terminal 64.

And power is supplied

- through BCM terminal 41
- to trunk room lamp terminal 1.

## ROOM LAMP TIMER OPERATION

### Without Intelligent Key System

When map lamp switch is in DOOR position, and when all conditions below are met, BCM performs timer control (maximum 30 seconds) for map lamp ON/OFF.

In addition, when spot turns ON or OFF there is gradual brightening or dimming over 1 second.

Power is supplied

- through 10A fuse [No. 21, located in the fuse block (J/B)]
- to key switch terminal 2.

Key is removed from ignition key cylinder (key switch OFF), power will not be supplied to BCM terminal 37.

Ground is supplied

- to power window main switch (door lock and unlock switch) terminal 14
- through BCM terminal 22.

At the time that driver door is opened, BCM detects that driver door is unlocked. It determines that map lamp timer operation condition is met, and turns the map lamp ON for 30 seconds.

Key is in ignition key cylinder (key switch ON),

Power is supplied

- to BCM terminal 37
- through key switch terminal 1.

When key is removed from key switch (key switch OFF), power supply to BCM terminal 37 is terminated. BCM detects that key has been removed, determines that map lamp timer conditions are met, and turns the map lamp ON for 30 seconds.

When driver door opens → closes, and the key is not inserted in the key switch (key switch OFF), BCM terminal 62 changes between 0 V (door open) → 12 V (door closed). The BCM determines that conditions for map lamp operation is met, and turns the map lamp ON for 30 seconds.

Timer control is canceled under the following conditions.

- Driver door is locked [when locked power window main switch (door lock and unlock switch) or door key cylinder switch]
- Driver door is opened (driver door switch turns ON)
- Ignition switch ON.

### With Intelligent Key System

When the map lamp switch is in DOOR position, and when all conditions below are met, BCM performs timer control (maximum 30 second) for map lamp ON/OFF.

In addition, when spot turns ON or OFF there is gradual brightening or dimming over 1 second.

Power is supplied

- through 15A fuse [No. 33, located in fuse and fuse block (J/B)]
- to key switch and ignition knob switch terminals 1 and 3.

Key is removed from ignition key cylinder (key switch OFF), power will not be supplied to BCM terminal 37.

And not turned ignition knob switch, power will not be supplied to Intelligent Key unit.

Ground is supplied

- to power window main switch (door lock and unlock switch) terminal 14
- through BCM terminal 22.

At the time that driver door are opened, BCM detects that driver door is unlocked. It determines that map lamp timer operation conditions is met, and turns map lamp ON for 30 seconds.

Key is in ignition key cylinder (key switch ON), or turned ignition knob switch,

Power is supplied

- through key switch and ignition knob switch terminal 4
- to BCM terminal 37,
- through key switch and ignition knob switch terminal 2

## INTERIOR ROOM LAMP

- to intelligent key unit terminal 27.

When the key is removed from key switch (key switch OFF), power supply to BCM terminal 37 is terminated. And turned ignition knob switch, power supply to Intelligent Key unit is terminated. BCM detects that key has been removed, determines that map lamp timer conditions is met, and turns map lamp ON for 30 seconds.

When driver door opens → closes, and key is not inserted in key switch (or not turned ignition knob switch), BCM terminal 62 changes between 0 V (door open) → 12 V (door closed). BCM determines that conditions for map lamp operation is met, and turns map lamp ON for 30 seconds.

Timer control is canceled under the following conditions.

- Driver door is locked [when locked keyfob, power window main switch (door lock and unlock switch) or door key cylinder switch].
- Driver door is opened (driver door switch turns ON).
- Ignition switch ON.

### INTERIOR ROOM LAMP BATTERY SAVER CONTROL

If interior room lamp is left "ON", it will not be turned out even when door is closed.

BCM turns off interior room lamp automatically to save battery 30 minutes after ignition switch is turned off.

BCM controls interior room lamps listed below:

- Ignition key hole illumination
- Trunk room lamp
- Step lamp
- Map lamp
- Vanity mirror lamp

After lamps turn OFF by the battery saver system, the lamps illuminate again when

- signal from power window main switch (door lock and unlock switch) or key cylinder is locked or unlocked,
- door is opened or closed,
- key is removed from ignition key cylinder or inserted in ignition key cylinder, or turned key switch.


Interior lamp battery saver control period can be changed by the function setting of CONSULT-II.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# INTERIOR ROOM LAMP


## Schematic

NKS002PO



TKWM3461E

# INTERIOR ROOM LAMP





TKWM4925E

# INTERIOR ROOM LAMP

## Wiring Diagram — ROOM/L —

NKS002PP

LT-ROOM/L-01



REFER TO THE FOLLOWING.



- E108 -SUPER MULTIPLE JUNCTION (SMJ)
- M4, M5 -FUSE BLOCK-JUNCTION BOX (J/B)
- M1, M2 -ELECTRICAL UNITS

TKWM3463E

# INTERIOR ROOM LAMP

## LT-ROOM/L-02

- ◊IK◊ : WITH INTELLIGENT KEY    \*1 3 : ◊IK◊  
 ◊OK◊ : WITHOUT INTELLIGENT KEY    2 : ◊OK◊  
 \*2 9 : ◊IK◊  
 6 : ◊OK◊





REFER TO THE FOLLOWING.  
 (D1), (D31) -SUPER MULTIPLE JUNCTION (SMJ)  
 (M1), (M2) -ELECTRICAL UNITS

TKWM3464E

# INTERIOR ROOM LAMP

## LT-ROOM/L-03

PRECEDING PAGE





REFER TO THE FOLLOWING.  
**(M2)** -ELECTRICAL UNITS

TKWM4926E



# INTERIOR ROOM LAMP

LT-ROOM/L-04





REFER TO THE FOLLOWING.  
 (B1) -SUPER MULTIPLE JUNCTION (SMJ)  
 (M1), (M75), (B4)  
 -ELECTRICAL UNITS

TKWM3466E

# INTERIOR ROOM LAMP

LT-ROOM/L-05



REFER TO THE FOLLOWING.  
 (B1), (B401) -SUPER MULTIPLE JUNCTION (SMJ)  
 (M1), (B4) -ELECTRICAL UNITS

TKWM4927E



# INTERIOR ROOM LAMP

## Terminals and Reference Values for BCM

NKS002PQ

### CAUTION:

- Check combination switch system terminal waveform under the loaded condition with lighting switch, turn signal switch and wiper switch OFF not to be fluctuated by overloaded.
- Turn wiper dial position to 4 except when checking waveform or voltage of wiper dial position. Wiper dial position can be confirmed on CONSULT-II. Refer to [LT-17, "DATA MONITOR"](#).

Terminal No.	Wire color	Signal name	Measuring condition			Reference value
			Ignition switch	Operation or condition		
1	PU	Ignition keyhole illumination signal	OFF	Door is locked. (SW OFF)		Battery voltage
				Door is unlocked. (SW ON)		Approx. 0 V
12	P	Passenger side door switch signal	OFF	Passenger side door switch	ON (open)	Approx. 0 V
					OFF (closed)	Battery voltage
22	Y	Power window switch serial link	—	—		
37	B/P	Key-in detection switch signal	OFF	Vehicle key is removed.		Approx. 0 V
				Vehicle key is inserted.		Battery voltage
38	W/L	Ignition power supply	ON	—		Battery voltage
39	L	CAN – H	—	—		—
40	P	CAN – L	—	—		—
41	R/B	Battery saver output signal	OFF	30 minutes after ignition switch is turned to OFF		Approx. 0 V
			ON	—		Battery voltage
42	GY	Battery power supply	OFF	—		Battery voltage
47	Y/PU	Step lamp signal	OFF	Any door is open (ON)		Approx. 0 V
				All doors are closed (OFF)		Battery voltage
48	PU/R	Map lamp output signal	OFF	Map lamp switch: DOOR position	Any door switch ON (open)	Approx. 0 V
					Any door switch OFF (closed)	Battery voltage
52	B	Ground	ON	—		Approx. 0 V
55	W/R	Battery power supply	OFF	—		Battery voltage
57	R	Trunk room lamp switch signal	OFF	Trunk room lamp switch	ON (open)	Approx. 0 V
					OFF (closed)	Battery voltage
62	Y	Driver side door switch signal	OFF	Driver side door switch	ON (open)	Approx. 0 V
					OFF (closed)	Battery voltage
64	R/W	Trunk room lamp signal	OFF	Trunk room lamp	ON (open)	Approx. 0 V
					OFF (closed)	Battery voltage

# INTERIOR ROOM LAMP

## How to Proceed With Trouble Diagnosis

NKS002PR

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-128, "System Description"](#) .
3. Perform the preliminary check. Refer to [LT-141, "Preliminary Check"](#) .
4. Check symptom and repair or replace the malfunctioning parts.
5. Does the interior room lamp operate normally? If YES, GO TO 6. If NO, GO TO 4.
6. INSPECTION END

## Preliminary Check

NKS002PS

### CHECK POWER SUPPLY AND GROUND CIRCUIT

#### 1. CHECK FUSES AND FUSIBLE LINK

Check for blown fuses and fusible link.

Unit	Power source	Fuse and fusible link No.
BCM	Battery	F
		18
		21
	Ignition switch ON or START position	1

Refer to [LT-134, "Wiring Diagram — ROOM/L —"](#) .

#### OK or NG

OK >> GO TO 2.

NG >> If fuse or fusible link is blown, be sure to eliminate cause of malfunction before installing new fuse or fusible link. Refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#) .

#### 2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check voltage between BCM harness connector and ground.

(+)		(-)	Ignition switch position	
BCM connector	Terminal		OFF	ON
M1	38	Ground	Approx. 0 V	Battery voltage
M2	42		Battery voltage	Battery voltage
	55		Battery voltage	Battery voltage

#### OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.

#### 3. CHECK GROUND CIRCUIT



Check continuity between BCM harness connector and ground.

BCM connector	Terminal	Ground	Continuity
M2	52		Yes

#### OK or NG

OK >> INSPECTION END

NG >> Repair harness or connector.



# INTERIOR ROOM LAMP

## CONSULT-II Functions (BCM)

NKS002PT

CONSULT-II can display each diagnostic item using the diagnostic test mode shown following.

BCM diagnosis part	Diagnosis mode	Description
INT LAMP	WORK SUPPORT	Changes the setting for each function.
	DATA MONITOR	Displays BCM input data in real time.
	ACTIVE TEST	Operation of electrical loads can be checked by sending driving signal to them.
BATTERY SAVER	WORK SUPPORT	Changes the setting for each function.
	DATA MONITOR	Displays BCM input data in real time.
	ACTIVE TEST	Operation of electrical loads can be checked by sending driving signal to them.

## CONSULT-II BASIC OPERATION

Refer to [GI-37, "CONSULT-II Start Procedure"](#).

### WORK SUPPORT (INT LAMP)

#### Operation Procedure

1. Touch "INT LAMP" on "SELECT TEST ITEM" screen.
2. Touch "WORK SUPPORT" on "SELECT DIAG MODE" screen.
3. Touch "SET I/L D- UNLCK INTCON" on "SELECT WORK ITEM" screen.
4. Touch "START".
5. Touch "CHANGE SETT".
6. The setting will be changed and "CUSTOMIZING COMPLETED" will be displayed.
7. Touch "END".

#### Display Item List

Item	Description	CONSULT-II
SET I/L D-UNLCK INTCON	The 30 seconds glowing function interior room lamps and ignition keyhole illumination can be selected when driver door is released (unlocked).	ON/OFF
ROOM LAMP ON TIME SET	The time in order to escalate illumination can be adjusted when interior room lamps and ignition keyhole illumination is turned on.	MODE 1 - 7
ROOM LAMP OFF TIME SET	The time in order to diminish illumination can be adjusted when interior room lamps and ignition keyhole illumination is turned off.	MODE 1 - 7

Reference between "MODE" and "TIME" for "TURN ON/OFF"

MODE	1	2	3	4	5	6	7
Time (sec.)	0.5	1	2	3	4	5	0

### DATA MONITOR (INT LAMP)

#### Operation Procedure

1. Touch "INT LAMP" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
3. Touch either "ALL SIGNALS" or "SELECTION FROM MENU" on "SELECT MONITOR ITEM" screen.

ALL SIGNALS	Monitors all the signals.
SELECTION FROM MENU	Selects items and monitor them.

4. When "SELECTION FROM MENU" is selected, touch items to be monitored. When "ALL SIGNALS" is selected, all items will be monitored.
5. Touch "START".
6. Touch "RECORD" while monitoring, then the status of monitored item can be recorded. To stop recording, touch "STOP".

# INTERIOR ROOM LAMP

## Display Item List

Monitor item	Contents
IGN ON SW "ON/OFF"	Displays status (ignition switch IGN position: ON/other: OFF) of ignition switch judged from the ignition switch signal.
KEY ON SW "ON/OFF"	Displays status (key inserted: ON/key removed: OFF) of key switch judged from the key switch signal.
DOOR SW - DR "ON/OFF"	Displays status (door is open: ON/door is closed: OFF) of driver side door switch judged from the driver side door switch signal.
DOOR SW - AS "ON/OFF"	Displays status (door is open: ON/door is closed: OFF) of passenger side door switch judged from the passenger side door switch signal.
DOOR SW - RR <sup>NOTE</sup> "OFF"	—
DOOR SW - RL <sup>NOTE</sup> "OFF"	—
BACK DOOR SW <sup>NOTE</sup> "OFF"	—
KEY CYL LK - SW "ON/OFF"	Displays status (door is locked: ON/other: OFF) of key cylinder lock switch from the door key cylinder switch (driver door) signal.
KEY CYL UN - SW "ON/OFF"	Displays status (door is unlocked: ON/other: OFF) of key cylinder unlock switch from the door key cylinder switch (driver door) signal.
CDL LOCK SW "ON/OFF"	Displays status (door is locked: ON/other: OFF) of lock switch from the door lock and unlock switch signal.
CDL UNLOCK SW "ON/OFF"	Displays status (door is unlocked: ON/other: OFF) of unlock switch from the door lock and unlock switch signal.
I- KEY LOCK "ON/OFF"	Displays status (door is locked: ON/other: OFF) of intelligent key system lock signal from the intelligent key unit signal.
I- KEY UNLOCK "ON/OFF"	Displays status (door is locked: ON/other: OFF) of intelligent key system unlock signal from the intelligent key unit signal.
KEYLESS LOCK "ON/OFF"	Displays status (door is locked: ON/other: OFF) of remote keyless entry system lock signal from the remote key less entry receiver signal.
KEYLESS UNLOCK "ON/OFF"	Displays status (door is unlocked: ON/other: OFF) of remote keyless entry system unlock signal from the remote key less entry receiver signal.

**NOTE:**

This item is displayed, but cannot be monitored.

## ACTIVE TEST (INT LAMP)

### Operation Procedure

1. Touch "INT LAMP" on "SELECT TEST ITEM" screen.
2. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
3. Touch item to be tested and check operation of the selected item.
4. During the operation check, touching "OFF" deactivates the operation.

## Display Item List

Test item	Description
INT LAMP	Interior room lamp can be operated by ON-OFF operations.
IGN ILLUM	Ignition key hole illumination can be operated by ON-OFF operation.
STEP LAMP TEST	All step lamp can be operated by ON-OFF operation.
LUGGAGE LAMP TEST	Trunk room lamp can be operated by ON-OFF operations.

## WORK SUPPORT (BATTERY SAVER)

### Operation Procedure

1. Touch "BATTERY SAVER" on "SELECT TEST ITEM" screen.
2. Touch "WORK SUPPORT" on "SELECT DIAG MODE" screen.
3. Touch "ROOM LAMP BAT SAV SET" on "SELECT WORK ITEM" screen.
4. Touch "START".

# INTERIOR ROOM LAMP

5. Touch "CHANGE SETT".
6. The setting will be changed and "CUSTOMIZING COMPLETED " will be displayed.
7. Touch "END".

## Display Item List

Item	Description	CONSULT-II
ROOM LAMP TIME SET	Interior room lamp battery saver timer setting can be changed.	MODE 1: 30min MODE 2: 60min

## DATA MONITOR (BATTERY SAVER)

### Operation Procedure

1. Touch "BATTERY SAVER" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
3. Touch either "ALL SIGNALS" or "SELECTION FROM MENU" on "SELECT MONITOR ITEM" screen.

ALL SIGNALS	Monitors all the signals.
SELECTION FROM MENU	Selects items and monitor them.

4. When "SELECTION FROM MENU" is selected, touch items to be monitored. When "ALL SIGNALS" is selected, all items will be monitored.
5. Touch "START".
6. Touch "RECORD" while monitoring, then the status of monitored item can be recorded. To stop recording, touch "STOP".

## Display Item List

Monitor item	Contents
IGN ON SW "ON/OFF"	Displays status (ignition switch IGN position: ON/other: OFF) of ignition switch judged from the ignition switch signal.
KEY ON SW "ON/OFF"	Displays status (key inserted: ON/key removed: OFF) of key switch judged from the key switch signal.
DOOR SW - DR "ON/OFF"	Displays status (door is open: ON/door is closed: OFF) of driver side door switch judged from the driver side door switch signal.
DOOR SW - AS "ON/OFF"	Displays status (door is open: ON/door is closed: OFF) of passenger side door switch judged from the passenger side door switch signal.
DOOR SW - RR <sup>NOTE</sup> "OFF"	—
DOOR SW - RL <sup>NOTE</sup> "OFF"	—
BACK DOOR SW <sup>NOTE</sup> "OFF"	—
KEY CYL LK - SW "ON/OFF"	Displays status (door is locked: ON/other: OFF) of key cylinder lock switch from the door key cylinder switch (driver door) signal.
KEY CYL UN - SW "ON/OFF"	Displays status (door is unlocked: ON/other: OFF) of key cylinder unlock switch from the door key cylinder switch (driver door) signal.
CDL LOCK SW "ON/OFF"	Displays status (door is locked: ON/other: OFF) of lock switch from the door lock and unlock switch signal.
CDL UNLOCK SW "ON/OFF"	Displays status (door is unlocked: ON/other: OFF) of unlock switch from the door lock and unlock switch signal.
I- KEY LOCK "ON/OFF"	Displays status (door is locked: ON/other: OFF) of intelligent key system lock signal from the intelligent key unit signal.
I- KEY UNLOCK "ON/OFF"	Displays status (door is locked: ON/other: OFF) of intelligent key system unlock signal from the intelligent key unit signal.
KEYLESS LOCK "ON/OFF"	Displays status (door is locked: ON/other: OFF) of remote keyless entry system lock signal from the remote key less entry receiver signal.
KEYLESS UNLOCK "ON/OFF"	Displays status (door is unlocked: ON/other: OFF) of remote keyless entry system unlock signal from the remote key less entry receiver signal.



# INTERIOR ROOM LAMP

**NOTE:**

This item is displayed, but cannot be monitored.

**ACTIVE TEST (BATTERY SAVER)**

**Operation Procedure**

1. Touch "BATTERY SAVER" on "SELECT TEST ITEM" screen.
2. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
3. Touch item to be tested and check operation of the selected item.
4. During the operation check, touching "OFF" deactivates the operation.

**Display Item List**

Test item	Description
BATTERY SAVER	Interior room lamp can be operated by ON-OFF operations.

**Map Lamp Control Does Not Operate**

NKS002PU

**1. CHECK EACH SWITCH**

Select "BCM" on CONSULT-II. With "INT LAMP" data monitor make sure switches listed in display item list turn ON-OFF linked with switch operation. Refer to [LT-143, "Display Item List"](#) for switches and their functions.

OK or NG

- OK >> GO TO 2.
- NG >> Inspect malfunctioning switch system.

DATA MONITOR	
MONITOR	
IGN ON SW	ON
KEY ON SW	ON
DOOR SW-DR	ON
DOOR SW-AS	ON
DOOR SW-RR	OFF
DOOR SW-RL	OFF
BACK DOOR SW	OFF
KEY CYL LK-SW	OFF
KEY CYL UN-SW	OFF
Page Down	
RECORD	
MODE	BACK
LIGHT	COPY

PKIB3532E

**2. ACTIVE TEST**

1. Select "BCM" on CONSULT-II. Select "INT LAMP" active test.
2. When map lamp switch is in DOOR position, use active test to make sure map lamp operates.

**Map lamp should operate.**

OK or NG

- OK >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#).
- NG >> GO TO 3.

ACTIVE TEST	
INT LAMP	ON
OFF	
MODE	BACK
LIGHT	COPY

PKIA6881E


**3. CHECK MAP LAMP INPUT**

1. Turn ignition switch OFF.
2. Check voltage between map lamp harness connector R52 terminal 2 and ground.

**2 – Ground : Battery voltage**

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 4.



# INTERIOR ROOM LAMP


## 4. CHECK MAP LAMP

1. Disconnect map lamp connectors.
2. Check continuity map lamp terminals.

Terminal		Condition	Continuity
Map lamp			
2	3	Map lamp switch is DOOR	Yes
		Map lamp switch is OFF	No

OK or NG

- OK >> GO TO 5.  
 NG >> Replace map lamp.




## 5. CHECK MAP LAMP CIRCUIT

1. Disconnect BCM connector and map lamp connector.
2. Check continuity between BCM harness connector M2 terminal 41 and map lamp harness connector R52 terminal 3.

**41 – 3 : Continuity should exist.**

OK or NG

- OK >> Replace BCM if map lamp does not work after setting the connector again. Refer to [BCS-16, "Removal and Installation of BCM"](#) .  
 NG >> Repair harness or connector.




## 6. CHECK MAP LAMP CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector M2 terminal 48 and map lamp harness connector R52 terminal 2.

**48 – 2 : Continuity should exist.**

OK or NG

- OK >> Replace BCM if map lamp does not work after setting the connector again. Refer to [BCS-16, "Removal and Installation of BCM"](#) .  
 NG >> Repair harness or connector.



## Ignition Key Hole Illumination Control Does Not Operate

NKS002PV

### 1. CHECK EACH SWITCH

Select "BCM" on CONSULT-II. With "INT LAMP" data monitor, make sure switches listed in display item list turn ON-OFF linked with switch operation. Refer to [LT-143, "Display Item List"](#) for switches and their functions.

OK or NG

- OK >> GO TO 2.  
 NG >> Inspect malfunctioning switch system.

DATA MONITOR			
MONITOR			
IGN ON SW		ON	
KEY ON SW		ON	
DOOR SW-DR		ON	
DOOR SW-AS		ON	
DOOR SW-RR		OFF	
DOOR SW-RL		OFF	
BACK DOOR SW		OFF	
KEY CYL LK-SW		OFF	
KEY CYL UN-SW		OFF	
		Page Down	
		RECORD	
MODE	BACK	LIGHT	COPY

PKIB3532E

# INTERIOR ROOM LAMP


## 2. ACTIVE TEST

1. Select "BCM" on CONSULT-II. Select "INT LAMP".
2. Select "IGN ILLUM" active test to make sure lamp operates.

**Ignition key hole illumination should operate.**

OK or NG

- OK >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#).
- NG >> GO TO 3.




## 3. CHECK IGNITION KEY HOLE ILLUMINATION INPUT

1. Turn ignition switch OFF.
2. Open the driver side door.
3. Check voltage between ignition key hole illumination harness connector M309 terminal 1 and ground.

**1 – Ground : Battery voltage**

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 6.




## 4. CHECK IGNITION KEY HOLE ILLUMINATION BULB

1. Disconnect ignition key hole illumination connector.
2. Check continuity between ignition key hole illumination terminals 1 and 2.

**1 – 2 : Continuity should exist.**

OK or NG

- OK >> GO TO 5.
- NG >> Replace ignition key hole illumination. Refer to [LT-150, "IGNITION KEY HOLE ILLUMINATION"](#).




## 5. CHECK IGNITION KEY HOLE ILLUMINATION CIRCUIT

1. Disconnect BCM connector and key hole illumination connector.
2. Check continuity between BCM harness connector M1 terminal 1 and key hole illumination harness connector M309 terminal 2.

**1 – 2 : Continuity should exist.**

OK or NG

- OK >> Replace BCM if ignition key hole illumination does not work after setting the connector again. Refer to [BCS-16, "Removal and Installation of BCM"](#).
- NG >> Repair harness or connector.



# INTERIOR ROOM LAMP

## 6. CHECK IGNITION KEY HOLE ILLUMINATION CIRCUIT


1. Disconnect BCM connector and key hole illumination connector.
2. Check continuity between BCM harness connector M2 terminal 41 and key hole illumination harness connector M309 terminal 1.

**41 – 1 : Continuity should exist.**

OK or NG

OK >> Replace BCM if ignition key hole illumination does not work after setting the connector again. Refer to [BCS-16, "Removal and Installation of BCM"](#).

NG >> Repair harness or connector.



## All Step Lamps Does Not Operate

### 1. CHECK EACH DOOR SWITCH

Select "BCM" on CONSULT-II. With "INT LAMP" data monitor to make sure switches listed below turn ON-OFF linked with switch operation.

Switch name	CONSULT screen
Driver side door switch	DOOR SW - DR
Passenger side door switch	DOOR SW - AS

OK or NG

OK >> GO TO 2.

NG >> Inspect malfunctioning switch system.

DATA MONITOR	
MONITOR	
IGN ON SW	ON
KEY ON SW	ON
DOOR SW-DR	ON
DOOR SW-AS	ON
DOOR SW-RR	OFF
DOOR SW-RL	OFF
BACK DOOR SW	OFF
KEY CYL LK-SW	OFF
KEY CYL UN-SW	OFF
Page Down	
RECORD	
MODE	BACK LIGHT COPY

### 2. CHECK STEP LAMP INPUT


1. Turn ignition switch OFF.
2. Check voltage between step lamp (driver side) harness connector D10 terminal 1 and ground.

**1 – Ground : Battery voltage**

OK or NG

OK >> GO TO 3.

NG >> GO TO 4.



### 3. CHECK STEP LAMP CIRCUIT


1. Disconnect BCM connector and front door driver side step lamp connector.
2. Check continuity between BCM harness connector M2 terminal 47 and step lamp (driver side) harness connector D10 terminal 2.

**47 – 2 : Continuity should exist.**

OK or NG

OK >> Replace BCM if step lamps does not work after setting the connector again. Refer to [BCS-16, "Removal and Installation of BCM"](#).

NG >> Repair harness or connector.



# INTERIOR ROOM LAMP


## 4. CHECK STEP LAMP CIRCUIT

1. Disconnect BCM connector and step lamp connector.
2. Check continuity between BCM harness connector M2 terminal 41 and step lamp (driver side) harness connector D10 terminal 1.

**41 – 1 : Continuity should exist.**

### OK or NG

- OK >> Replace BCM if step lamps does not work after setting the connector again. Refer to [BCS-16, "Removal and Installation of BCM"](#) .
- NG >> Repair harness or connector.



NKS002PX

## All Interior Room Lamps Does Not Operate


### 1. CHECK POWER SUPPLY CIRCUIT

1. All interior room lamps switch are OFF.
2. Turn ignition switch ON.
3. Check voltage between BCM harness connector M2 terminal 41 and ground.

**41 – Ground : Battery voltage**

### OK or NG

- OK >> Repair harness or connector. In a case of making a short circuit, be sure to disconnect battery negative cable after repairing harness, and then reconnect.
- NG >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#) .




NKS002PY

## Bulb Replacement VANITY MIRROR LAMP

1. Insert a thin screwdriver in the lens end and remove lens.
2. Remove bulb together with substrate.

**Vanity mirror lamp : 12 V - 1.32 W**

3. Installation is the reverse order of removal.




## MAP LAMP

1. Insert a small screwdriver into the lens hinge gap and remove lens.
2. Remove bulb.

**Map lamp : 12 V - 8 W**

3. Installation is the reverse order of removal.




# INTERIOR ROOM LAMP

## STEP LAMP

1. Remove step lamp. Refer to [LT-151, "STEP LAMP"](#) .
2. Remove bulb.

**Step lamp : 12 V - 5 W**

3. Installation is the reverse order of removal.




## TRUNK ROOM LAMP

1. Unfold pawl A and remove lens.
2. Remove trunk room lamp while pressing pawl B in the direction of the arrow.
3. Disconnect trunk room lamp connector.

**Trunk room lamp : 12 V - 3.4 W**

4. Installation is the reverse order of removal.




## IGNITION KEY HOLE ILLUMINATION

### Without Intelligent Key System

1. Remove cluster lid A and steering lock escutcheon. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#) .
2. Pull out ring, turn bulb socket to left to release lock and remove it.

**Ignition key hole illumination : 12 V - 1.4 W**


3. Installation is the reverse order of removal.



### With Intelligent Key System

1. Remove instrument lower driver panel. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#) .
2. Turn bulb socket to left to release lock and remove it.

**Ignition key hole illumination : 12 V - 1.4 W**



# INTERIOR ROOM LAMP


## Removal and Installation

### MAP LAMP

NKS002PZ

#### Removal

1. Insert a clip driver or a suitable tool and disengage the pawl fittings of the map lamp.
2. Disconnect connector and remove map lamp.




#### Installation

Installation is the reverse order of removal.

### STEP LAMP

#### Removal

1. Remove clips which are lower part of front door finisher and lift finisher up.
2. Disconnect step lamp connector.
3. Press pawl on reverse side and remove the step lamp.




#### Installation

Installation is the reverse order of removal.

### TRUNK ROOM LAMP

#### Removal

1. Unfold pawl A and remove lens.
2. Remove trunk room lamp while pressing pawl B in the direction of the arrow.
3. Disconnect trunk room lamp connector.
4. Installation is the reverse order of removal.



#### Installation

Installation is the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J

LT

L  
M

## ILLUMINATION

### System Description

NKS000JZ

The control of the illumination lamps operation is dependent upon the position of the lighting switch (combination switch). When the lighting switch is placed in the 1ST position, 2ND position or AUTO position (headlamp is ON), BCM (body control module) receives input signal requesting the illumination lamps to illuminate. This input signal is communicated to IPDM E/R (intelligent power distribution module engine room) through CAN communication lines. CPU (central processing unit) located in the IPDM E/R controls the tail lamp relay. This relay, when energized, directs power to the illumination lamps, which then illuminate.

Power is supplied at all times

- to ignition relay located in IPDM E/R, from battery direct,
- through 10A fuse (No. 71, located in IPDM E/R)
- to CPU located in IPDM E/R and
- to tail lamp relay, located in IPDM E/R,
- through 15A fuse (No. 78, located in IPDM E/R)
- to CPU located in IPDM E/R,
- through 50A fusible link (letter F, located in fuse, fusible link and relay box)
- to BCM terminal 55,
- through 10A fuse [No.18, located in fuse block (J/B)]
- to BCM terminal 42.

With the ignition switch in the ON or START position, power is supplied

- to ignition relay located in IPDM E/R, from battery direct,
- through 10A fuse [No.1, located in fuse block (J/B)]
- to BCM terminal 38,
- through 10A fuse [No.14, located in fuse block (J/B)]
- to combination meter terminals 22 and 23,
- through 10A fuse [No.12, located in fuse block (J/B)]
- to NAVI control unit terminal 63 (with navigation system) and
- to display and A/C auto amp. terminal 2.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No.6, located in fuse block (J/B)]
- to BCM terminal 11
- to combination meter terminal 18
- to NAVI control unit terminal 5 (with navigation system)
- to display unit terminal 19 (with navigation system) and
- to NAVI switch terminal 1 (with navigation system).

Ground is supplied

- to BCM terminal 52
- to combination meter terminals 1, 24 and 25
- to NAVI control unit terminals 1 and 21 (with navigation system)
- to display unit terminals 22 and 24 (with navigation system)
- to NAVI switch terminal 7 (with navigation system) and
- to display and A/C auto amp. terminal 5
- through grounds M30 and M66,
- to IPDM E/R terminals 38 and 60
- through grounds E17 and E47.

### ILLUMINATION OPERATION BY LIGHTING SWITCH

With the lighting switch in the 1ST position, 2ND position or AUTO position (headlamp is ON), BCM receives input signal requesting the illumination lamps to illuminate. This input signal is communicated to IPDM E/R through CAN communication lines. CPU located in the IPDM E/R controls the tail lamp relay, which, when energized, directs power



# ILLUMINATION

- through IPDM E/R terminal 22
- to combination meter terminal 10
- to NAVI control unit terminal 61 (with navigation system)
- to NAVI switch terminal 2 (with navigation system)
- to display and A/C auto amp. terminal 1
- to A/C and audio controller terminal 9
- to microphone terminal 2 (with telephone system)
- to VDC off switch (illumination) terminal 3
- to A/T illumination terminal 1 (with A/T)
- to hazard switch (illumination) terminal 3
- to ashtray illumination and cigarette lighter socket illumination terminal 5 (with A/T)
- to ashtray illumination and cigarette lighter socket illumination terminal 2 (with M/T)
- to heated seat switch (driver side) (illumination) terminal 5
- to heated seat switch (passenger side) (illumination) terminal 5
- to combination switch (spiral cable) terminal 26
- to trunk lid opener switch (illumination) terminal 3
- to illumination control switch terminal 1
- to upper glove box lamp terminal 1 (without navigation system) and
- to glove box lamp terminal 1,
- through combination switch (spiral cable) terminal 18
- to ASCD steering switch illumination and
- to steering wheel audio control switch illumination.

Ground is supplied

- to steering wheel audio control switch illumination and
- to ASCD steering switch illumination
- through combination switch (spiral cable) terminal 21,
- to combination meter terminal 9
- to NAVI switch terminal 3 (with navigation system)
- to display and A/C auto amp. terminal 21
- to A/C and audio controller terminal 10
- to VDC off switch (illumination) terminal 4
- to A/T illumination terminal 2 (with A/T)
- to hazard switch (illumination) terminal 4
- to heated seat switch (driver side) (illumination) terminal 6
- to heated seat switch (passenger side) (illumination) terminal 6
- to combination switch (spiral cable) terminal 27 and
- to trunk lid opener switch (illumination) terminal 4
- through illumination control switch terminal 2,
- to ashtray illumination and cigarette lighter socket illumination terminal 4 (with A/T)
- to ashtray illumination and cigarette lighter socket illumination terminal 3 (with M/T)
- to illumination control switch terminal 3
- to upper glove box lamp terminal 2 (without navigation system) and
- to glove box lamp terminal 2
- through grounds M30 and M66,
- to microphone
- through case ground of microphone.

With power and ground supplied, illumination lamps illuminate.

A

B

C

D

E

F

G

H

I

J

LT

L

M

# ILLUMINATION

---

## EXTERIOR LAMP BATTERY SAVER CONTROL

When the lighting switch is in the 1ST or 2ND position, and ignition switch is turned from ON or ACC to OFF, the battery saver control function is activated.

Under this condition, illumination lamps remain illuminated for 5 minutes, then illumination lamps are turned off.

When lighting switch is turned from OFF to 1ST position 2ND position (or if auto light system is activated) after illumination lamps are turned off by battery saver control, and illumination lamps illuminate again.

Exterior lamp battery saver control mode can be changed by the function setting of CONSULT-II.

## CAN Communication System Description

NKS000K0

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

## CAN Communication Unit


NKS000K1

Refer to [LAN-47, "CAN System Specification Chart"](#) .

# ILLUMINATION

## Schematic

NKS000K2



(A) : With A/T  
(WN) : With navigation system  
(ON) : Without navigation system  
(HF) : With telephone system  
\* : This relay is built into the IPDM E/R (Intelligent power distribution module engine room).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M






TKWM4928E

# ILLUMINATION

## Wiring Diagram — ILL —

NKS000K3

LT-ILL-01





REFER TO THE FOLLOWING.

- (E108) -SUPER MULTIPLE JUNCTION (SMJ)
- (M4) -FUSE BLOCK-JUNCTION BOX (J/B)
- (M1), (M2) -ELECTRICAL UNITS

TKWM2219E

# ILLUMINATION

LT-ILL-02





REFER TO THE FOLLOWING.  
 (E108), (B1) -SUPER MULTIPLE JUNCTION (SMJ)

TKWM3470E

# ILLUMINATION

LT-ILL-03




REFER TO THE FOLLOWING.  
 M4 - FUSE BLOCK-JUNCTION BOX (J/B)

TKWM4929E

# ILLUMINATION

LT-ILL-04




24	22	20	18	16	14	10	8	6	4	2		
23	21	19	17	15	13	12	11	9	7	5	3	1

(M35) W

3	2	1		
8	7	6	5	4

(M37) W











REFER TO THE FOLLOWING.  
M4 - FUSE BLOCK-JUNCTION BOX (J/B)

TKWM3472E

# ILLUMINATION

LT-ILL-05

⬡HF⬡ : WITH TELEPHONE SYSTEM



TKWM4930E



# ILLUMINATION


## LT-ILL-06

(A) : WITH A/T

(M) : WITH M/T

\*1 B: (A)

R/Y: (M)



\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.



TKWM3474E

# ILLUMINATION

LT-ILL-07

(A) : WITH A/T

(M) : WITH M/T





TKWM3475E

# ILLUMINATION

LT-ILL-08

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M




\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

TKWM4931E

# ILLUMINATION

LT-ILL-09

ON : WITHOUT NAVIGATION SYSTEM




TKWM3477E

# ILLUMINATION

## Bulb Replacement GLOVE BOX LAMP


NKS0026I

1. Remove instrument lower passenger panel. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#).
2. Turn bulb socket counterclockwise and remove it.  
**Glove box lamp : 12 V - 1.4 W**
3. Installation is the reverse order of removal.




## UPPER GLOVE BOX LAMP

1. Remove instrument lower passenger panel. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#).
2. Turn bulb socket counterclockwise and remove it.  
**Upper glove box lamp : 12 V - 3.4 W**
3. Installation is the reverse order of removal.




## ASHTRAY ILLUMINATION

1. Remove console finisher. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#).
2. Turn bulb socket to counterclockwise and remove it.  
**Ashtray illumination : 12 V - 1.4 W**
3. Installation is the reverse order of removal.



## CIGARETTE LIGHTER ILLUMINATION

1. Remove console finisher. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#).
2. Open hooks and remove bulb socket.  
**Cigarette lighter illumination : 12 V - 0.8 W**  
**CAUTION:**  
**When replacing bulb, replace assembly together with illumination ring.**
3. Installation is the reverse order of removal.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# BULB SPECIFICATIONS

## BULB SPECIFICATIONS

PFP:26297

### Headlamp

NKS000K5

Item	Wattage (W)
Low / High	35 (D2R)
FOG	55 (H1)

### Exterior Lamp

NKS000K6

Item	Wattage (W)	
Front combination lamp	Turn signal	21 (amber)
	Parking lamp	5
Rear combination lamp	Stop/Tail lamp	LED
	Turn signal lamp	21
	Back-up lamp	18
	Rear side marker lamp	3.8
Front side marker lamp	3.8	
License plate lamp	5	
High-mounted stop lamp	LED	

### Interior Lamp/Illumination

NKS000K7

Item	Wattage (W)
Glove box lamp	1.4
Upper glove box lamp	3.4
Ignition key hole illumination lamp	1.4
Ashtray illumination lamp	1.4
Cigarette lighter illumination lamp	0.8
Map lamp	8
Step lamp	5
Trunk room lamp	3.4
Vanity mirror lamp	1.32