

# SECTION **SBC**

## SEAT BELT CONTROL SYSTEM

A  
B  
C  
D  
E  
F  
G  
SBC  
I  
J  
K  
L  
M  
N  
O  
P

### CONTENTS

<b>BASIC INSPECTION</b> .....	3	Description .....	16
<b>DIAGNOSIS AND REPAIR WORKFLOW</b> .....	3	DTC Logic .....	16
Work Flow .....	3	Diagnosis Procedure .....	16
<b>SYSTEM DESCRIPTION</b> .....	6	Component Inspection .....	17
<b>SEAT BELT TENSION REDUCER SYSTEM</b> .....	6	<b>B2454 MOTOR PWR SUP CIRC</b> .....	18
System Diagram .....	6	Description .....	18
System Description .....	6	DTC Logic .....	18
Component Parts Location .....	7	Diagnosis Procedure .....	18
Component Description .....	7	<b>B2455 PSB C/U INT CIRCUIT</b> .....	19
<b>PRE-CRASH SEAT BELT SYSTEM</b> .....	8	Description .....	19
System Diagram .....	8	DTC Logic .....	19
System Description .....	8	<b>BRAKE PEDAL STROKE SENSOR SHIELD</b>	
Component Parts Location .....	10	<b>WIRE CIRCUIT CHECK</b> .....	20
Component Description .....	10	Description .....	20
<b>ON BOARD DIAGNOSTIC (OBD) SYSTEM</b> .....	11	Component Function Check .....	20
Diagnosis Description .....	11	<b>SEAT BELT BUCKLE SWITCH (DRIVER</b>	
CONSULT-III Function .....	11	<b>SIDE) CIRCUIT CHECK</b> .....	21
<b>DTC/CIRCUIT DIAGNOSIS</b> .....	13	Description .....	21
<b>U1000 CAN COMM CIRCUIT</b> .....	13	Component Function Check .....	21
Description .....	13	Component Inspection (Driver seat belt buckle	
DTC Logic .....	13	switch) .....	21
<b>B2451 SB MOTOR RH CIRC</b> .....	14	Component Inspection (Driver seat belt buckle	
Description .....	14	switch ground circuit) .....	22
DTC Logic .....	14	<b>SEAT BELT BUCKLE SWITCH (PASSEN-</b>	
Diagnosis Procedure .....	14	<b>GER SIDE) CIRCUIT CHECK</b> .....	23
Component Inspection .....	14	Description .....	23
<b>B2452 SB MOTOR LH CIRC</b> .....	15	Component Function Check .....	23
Description .....	15	Component Inspection (Passenger seat belt buck-	
DTC Logic .....	15	le switch) .....	23
Diagnosis Procedure .....	15	Component Inspection (Passenger seat belt side	
Component Inspection .....	15	buckle switch ground circuit) .....	24
<b>B2453 BR STROK SEN CIRC</b> .....	16	<b>IGNITION POWER SUPPLY CIRCUIT</b>	
		<b>CHECK</b> .....	25
		Description .....	25
		Component Function Check .....	25

<b>PRE-CRASH SEAT BELT CONTROL UNIT</b>		<b>PRECAUTION .....</b>	<b>35</b>
<b>GROUND CIRCUIT CHECK .....</b>	<b>26</b>	<b>PRECAUTIONS .....</b>	<b>35</b>
Description .....	26	Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	35
Component Function Check .....	26	Precaution for Seat Belt Service .....	35
<b>ECU DIAGNOSIS INFORMATION .....</b>	<b>27</b>	<b>PERIODIC MAINTENANCE .....</b>	<b>37</b>
<b>PRE-CRASH SEAT BELT CONTROL UNIT ....</b>	<b>27</b>	<b>BRAKE PEDAL STROKE SENSOR .....</b>	<b>37</b>
Reference Value .....	27	Exploded View .....	37
Fail Safe .....	28	Removal and Installation .....	37
DTC Index .....	28	<b>PRE-CRASH SEAT BELT CONTROL UNIT ....</b>	<b>38</b>
Wiring Diagram - SEAT BELT CONTROL SYSTEM - .....	29	Exploded View .....	38
<b>SYMPTOM DIAGNOSIS .....</b>	<b>34</b>	Removal and Installation .....	38
<b>PRE-CRASH SEAT BELT SYSTEM .....</b>	<b>34</b>		
Description .....	34		
Symptom Table .....	34		

# DIAGNOSIS AND REPAIR WORKFLOW


< BASIC INSPECTION >

## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000002912384



#### 1.GET INFORMATION FOR SYSTEM

Interview the customer to obtain the malfunction information (conditions and environment when the malfunction occurred) as much as possible when the customer brings the vehicles in.

>> GO TO 2.

#### 2.STUDY AND UNDERSTAND THE SYSTEM DESCRIPTION

Understand the operation condition or non-operation condition of pre-crash seat belt. Refer to [SBC-8. "System Description"](#).

>> GO TO 3.

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

---

## 3. CHECK DTC

---

Perform "Self-diagnosis procedure" of appropriate DTC to check if DTC is detected again.  
At this time, always connect CONSULT-III to the vehicle, and then check the diagnosis results in real time on "DATA MONITOR (AUTO RECORD)".

There is no priority for each DTC. Record them based on the following rules.

Current malfunction: Record all DTCs detected.

Past malfunction: Record up to 5 DTCs. When the 6th DTC is detected, it is overwritten to the last recorded DTC.

Is DTC detected?

YES >> GO TO 4.

NO >> Follow the diagnosis simulation test to check. Refer to [GI-39, "Intermittent Incident"](#).

---

## 4. PERFORM PRELIMINARY CHECK

---

Perform Pre-Diagnosis Inspection. Refer to [SBC-34, "Description"](#).

>> GO TO 5.

## 5. DETECT MALFUNCTIONING SYSTEM BY SYMPTOM TABLE

---

Identify the malfunctioning system with "Diagnosis Chart by Symptom". Refer to [SBC-34, "Symptom Table"](#).

With CONSULT-III >> GO TO 6.

Without CONSULT-III >> GO TO 7 (Parts system).

Without CONSULT-III >> GO TO 8 (Power supply, ground system).

## 6. PERFORM DTC CONFIRMATION PROCEDURE

---

Perform the inspection with "DTC CONFIRMATION PROCEDURE" of the applicable system.

>> GO TO 7.

## 7. DETECT MALFUNCTIONING PART BY DIAGNOSIS PROCEDURE

---

Identify the malfunctioning part with "Diagnosis Procedure".

Are malfunctioning parts detected?

YES >> GO TO 10.

NO >> GO TO 9.

---

## 8. PERFORM COMPONENT FUNCTION CHECK

---

Identify the malfunctioning part with "Component Parts Function Inspection".

Are malfunctioning parts detected?

YES >> GO TO 10.

NO >> GO TO 9.

---

## 9. PERFORM COMPONENT INSPECTION

---

Perform the inspection with "Component Parts Inspection".

>> GO TO 10.

## 10. REPAIR OR REPLACE THE MALFUNCTIONING PART

---

Repair or replace the specified malfunctioning parts.

After repairing or replacing, reconnect parts or connector disconnected in "Diagnosis Procedure", and then erase DTC if necessary. Refer to [SBC-11, "Diagnosis Description"](#).

>> GO TO 11.

## 11. FINAL CHECK

---

Perform "CONSULT-III function" again to check that the repair is performed correctly.

## DIAGNOSIS AND REPAIR WORKFLOW

### < BASIC INSPECTION >

---

Check that malfunctions are not reproduced when obtaining the malfunction information from the customer, referring to the symptom inspection result in step 4.

#### Are all malfunctions corrected?

YES >> • Before delivering the vehicle to the customer, check that that DTC is erased.

• **INSPECTION END.**

NO >> DTC is reproduced: GO TO 6.

A

B

C

D

E

F

G

SBC

I

J

K

L

M

N

O

P

# SEAT BELT TENSION REDUCER SYSTEM


< SYSTEM DESCRIPTION >

## SYSTEM DESCRIPTION

### SEAT BELT TENSION REDUCER SYSTEM

#### System Diagram

INFOID:000000002912385



JMHIA0428GB

#### System Description

INFOID:000000002912386

- The seat belt tension reducer is adopted as the standard for front seat of all models.
- During seat belt tension reducer operation, the tension reducer reduces the retracting force of the spring in the seat belt to decrease the feeling of pressure.

#### OPERATION DESCRIPTION


- When turning the ignition switch to ON, the power is supplied to the front seat tension reducer terminal 1.
- When fastening the seat belt (turning the seat belt buckle switch to ON) with ignition switch ON, the power is grounded from front seat tension reducer terminal 2 to front seat belt buckle switch terminal 3, and seat belt buckle switch terminal 2 via seat belt buckle switch. Then, the tension reducer is turned to ON to hold the belt.
- When releasing the seat belt (turning the seat belt buckle switch to OFF), the circuit is not grounded. The tension reducer is turned to OFF, and then the belt is not held.

# SEAT BELT TENSION REDUCER SYSTEM

< SYSTEM DESCRIPTION >

## Component Parts Location

INFOID:000000002912387



1. Seat belt buckle  
 A. Back of center pillar lower garnish    B. Tension reducer connector    C. Seat belt buckle switch connector

## Component Description

INFOID:000000002912388

Component	Function
Seat belt buckle switch	Perform the control of tension reducer according to the seat belt buckle switch ON/OFF in the seat belt buckle.
Tension reducer	When the seat belt buckle switch is turned ON, the tension reducer in the tension reducer seat belt is turned ON. It reduces the retracting force for seat belt.

SBC

I  
J  
K  
L  
M  
N  
O  
P


# PRE-CRASH SEAT BELT SYSTEM

< SYSTEM DESCRIPTION >

## PRE-CRASH SEAT BELT SYSTEM

### System Diagram

INFOID:000000002912389



JMHIA0430GB

### System Description

INFOID:000000002912390

- Pre-crash seat belt has been adopted to RH/LH seat belts.
- When the pre-crash seat belt control unit judges the emergency braking operation, the motor built into the pre-crash seat belt retract the shoulder belt to protect the passenger in case of collision, also give a sense of security.

### FUNCTION DESCRIPTION

#### Operation Condition

- Pre-crash seat belt operates under the following conditions.

Condition	<ul style="list-style-type: none"> <li>• During emergency brake operation</li> <li>• When operation prohibition condition is not satisfied</li> </ul>
-----------	---

#### Operation Prohibition Condition

- Pre-crash seat belt does not operate under the following conditions.

Condition	<ul style="list-style-type: none"> <li>• When seat belt is not fastened (Only the seat belt that is not fastened does not operate)</li> <li>• When the vehicle speed is 15 km/h or less</li> <li>• When pre-crash seat belt continuously operates 3 times or more *1</li> <li>• At fail-safe condition *2</li> </ul>
-----------	--


\*1: When pre-crash seat belt does not operate after it continuously operates 3 times or more, operation can be performed again by stopping operation for approximately 7 minutes.

\*2: Refer to [SBC-28. "Fail Safe"](#) for details of fail-safe mode.



# PRE-CRASH SEAT BELT SYSTEM

< SYSTEM DESCRIPTION >



Refer to [SBC-8. "System Diagram"](#) for details of operation condition.


A  
B  
C  
D  
E  
F  
G  
SBC  
I  
J  
K  
L  
M  
N  
O  
P

# PRE-CRASH SEAT BELT SYSTEM

< SYSTEM DESCRIPTION >

## Component Parts Location

INFOID:000000002912391



JMHIA0432ZZ

- |  |  |  |
|--|--|--|
| 1. Battery                             | 2. 30A (F/L-G)                             | 3. Pre-crash seat belt control unit    |
| 4. Brake pedal stroke sensor           | 5. Brake pedal                             | 6. Accelerator pedal                   |
| 7. Seat belt pre-tensioner             | 8. Seat belt buckle                        | 9. Seat belt buckle switch             |
| A. Back side of glove box              | B. Back of driver instrument panel (lower) | C. Brake pedal stroke sensor connector |
| D. Back of center pillar lower garnish | E. Seat belt pre-tensioner connector       |  |

## Component Description

INFOID:000000002912392

Component	Function
Pre-crash seat belt control unit	It controls pre-crash seat belt motor according to input signal.
Pre-crash seat belt motor (Seat belt motor [RH/LH])	It is built into seat belt retractor, and it pulls, returns, and maintains according to the motor rotation.
Brake pedal stroke sensor	<ul style="list-style-type: none"> <li>It changes voltage according to brake pedal depressed amount and sends the signal to pre-crash seat belt control unit.</li> <li>There are 2 signals (brake pedal stroke sensor 1 and 2) sent from the brake pedal stroke sensor. Pre-crash seat belt control unit will judge the stroke amount and the speed of the brake pedal according to the voltage of the signal sent by each side.</li> </ul>
Seat belt buckle switch	It is arranged in the seat belt buckle and judges whether the seat belt is fastened or not fastened.
CAN system: Unified meter and A/C amp	It transmits the vehicle status to pre-crash seat belt control unit using the CAN communication system.

# ON BOARD DIAGNOSTIC (OBD) SYSTEM

< SYSTEM DESCRIPTION >

## ON BOARD DIAGNOSTIC (OBD) SYSTEM

### Diagnosis Description

INFOID:000000002912393

#### HOW TO DIAGNOSE

- Diagnosis for pre-crash seat belt system can be performed using CONSULT-III electronic diagnostic tester.
- Diagnosis allows technicians to detect and analyze circuits that return errors.
- Diagnostic modes of CONSULT-III are.

	Self-diagnosis mode	Inspection
SELF-DIAGNOSIS RESULTS	×	×
DATA MONITOR	×	×

#### DIAGNOSIS PROCEDURE

Follow the diagnosis procedure to check. Refer to [SBC-3. "Work Flow"](#).

#### DIAGNOSIS ITEM

- Communication
- LH/RH seat belt motor
- Brake pedal sensor
- Motor power supply
- Pre-crash seat belt control unit

#### ERASING SELF-DIAGNOSIS RESULTS

- SELF-DIAGNOSIS RESULTS  
Current "SELF-DIAG RESULTS" are displayed. (If all suspect circuits have been repaired, "NO DTC" is displayed.)
- SELF-DIAG RESULTS [MEMORY]  
Resume trouble diagnosis item selection screen, confirm "SELF-DIAG RESULTS", and then touch ERASE MEMORY.

#### CONSULT-III Function

INFOID:000000002912394

"SELF-DIAG RESULTS", "DATA MONITOR", "CAN DIAG SUPPORT MNTR", "C/U PART NO" of pre-crash seat belt system can be checked by combining communications between CONSULT-III (data reception and command transmission).

Part to be diagnosed	Inspection Item, Diagnosis Mode	Description	Refer to
Pre-crash seat belt	SELF-DIAGNOSIS RESULTS	<ul style="list-style-type: none"><li>• Displays names of freeze frame data and basic inspection stored in ECM.</li><li>• Displays data recorded when a malfunction is detected.</li><li>• Can print out the display.</li><li>• Erases DTCs recorded in memory.</li></ul>	<a href="#">SBC-11</a>
	DATA MONITOR	<ul style="list-style-type: none"><li>• Displays input data for pre-crash seat belt control unit in real time.</li></ul>	<a href="#">SBC-11</a>
	CAN DIAG SUPPORT MNTR	<ul style="list-style-type: none"><li>• Monitors communication status of CAN communication.</li></ul>	<a href="#">LAN-16</a>
	ECU PART NUMBER	<ul style="list-style-type: none"><li>• Displays pre-crash seat belt control unit part number.</li></ul>	—

#### SELF-DIAGNOSIS RESULTS

Check self-diagnosis results.

#### CAUTION:

**When malfunctions are detected in several systems, including the CAN communication [U1000], troubleshoot the CAN communication [U1000].**

# ON BOARD DIAGNOSTIC (OBD) SYSTEM

## < SYSTEM DESCRIPTION >

Diagnostic item	Malfunction judgement criteria	Refer to
CAN COMM CIRC [U1000]	CAN communication is malfunctioning.	<a href="#">SBC-13</a>
Seat belt motor system RH [B2451]	Circuit of seat belt motor (RH) is open or shorted.	<a href="#">SBC-14</a>
Seat belt motor system LH [B2452]	Circuit of seat belt motor (LH) is open or shorted.	<a href="#">SBC-15</a>
B-pedal sensor system [B2453]	Circuit of brake pedal stroke sensor is open or shorted.	<a href="#">SBC-16</a>
Motor power supply circuit system [B2454]	Circuit of motor power supply is open or shorted. <b>CAUTION:</b> <b>Malfunction is judged when 30A (F/L-G) fusible link blows out even if motor power supply circuit is not malfunctioning.</b>	<a href="#">SBC-18</a>

### NOTE:

Timing display judges the status of self-diagnosis results judged from each input signal.

- When malfunction is found in the past and it is normal now, "MEMORY" is displayed.
- When malfunction is found at present or found immediately after the self-diagnosis, "CURRENT" is displayed.
- When malfunction is not found in the past and it is normal now, nothing is displayed.

### CAUTION:

**Some malfunctions are displayed at low battery voltage (when keeping 7 to 8 V for 2 seconds) even if the system is not malfunctioning. Erase DTC memory and do not replace any parts after making sure that the system is normal especially if the malfunctions are displayed after replacing battery.**

### DATA MONITOR

- Check DATA MONITOR

Monitor item	[Operation or unit]	Display item
B-pedal sensor SIG1	[V]	Brake pedal stroke sensor 1 signal voltage is displayed.
B-pedal sensor SIG2	[V]	Brake pedal stroke sensor 2 signal voltage is displayed.
BUCKLE SW RH	[ON/OFF]	ON/OFF status of RH seat belt switch signal is displayed.
BUCKLE SW LH	[ON/OFF]	ON/OFF status of LH seat belt switch signal is displayed.
Vehicle speed sensor	[km/h]	Vehicle speed signal is displayed.

# U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## DTC/CIRCUIT DIAGNOSIS

### U1000 CAN COMM CIRCUIT

#### Description

INFOID:000000002912396

- CAN (Controller Area Network) is a serial communication line for real time applications. It is an on board multiplex communication line with high data communication speed and excellent error detection ability. A modern vehicle is equipped with many ECMs, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, two control units are connected with two communication lines (CAN H-line, CAN L-line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.
- It transmits the vehicle status to pre-crash seat belt control unit using the CAN communication system.
- It consists of CAN system (unified meter and A/C amp).
- Refer to [LAN-28. "CAN System Specification Chart"](#) in LAN section for CAN communication unit (2WD).
- Refer to [LAN-28. "CAN System Specification Chart"](#) in LAN section for CAN communication unit (4WD).

#### DTC Logic

INFOID:000000002912397

#### DTC DETECTION LOGIC

DTC No.	Self-diagnosis item	DTC Detection Condition	Possible causes
U1000	CAN communication circuit	Pre-crash seat belt control unit cannot transmit and receive CAN communication system for 2 seconds or more.	CAN message reception malfunction

SBC

#### DTC CONFIRMATION PROCEDURE

##### 1. SELF-DIAGNOSIS WITH PRE-CRASH SEAT BELT CONTROL UNIT

Check "SELF-DIAG RESULT" of CONSULT-III.

##### Is any DTC detected?

- YES >> Refer to [LAN-28. "CAN System Specification Chart"](#) in LAN section for CAN communication or CAN system.
- NO >> CAN communication system is normal.

# B2451 SB MOTOR RH CIRC

< DTC/CIRCUIT DIAGNOSIS >

## B2451 SB MOTOR RH CIRC

### Description

INFOID:000000002912398

- It pulls, returns, and maintains according to the motor rotation.
- It is built into the seat belt retractor.
- It is installed to back of RH center pillar garnish.

### DTC Logic

INFOID:000000002912399

### DTC DETECTION LOGIC

DTC No.	Self-diagnosis item	DTC Detection Condition	Possible causes
B2451	Seat belt motor system RH	Circuit of seat belt motor (RH) is open or shorted	<ul style="list-style-type: none"><li>• Open circuit, short circuit to battery, and short circuit to ground in seat belt motor (RH) harness</li><li>• ECU internal malfunction</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK RH PRE-CRASH SEAT BELT MOTOR CIRCUIT

Check "SELF-DIAG RESULT" of CONSULT-III.

Is any DTC detected?

- YES >> Refer to [SBC-14, "Diagnosis Procedure"](#).  
NO >> RH pre-crash seat belt motor system is normal.

### Diagnosis Procedure

INFOID:000000002912400

#### 1. CHECK RH PRE-CRASH SEAT BELT MOTOR HARNESS

1. Turn the ignition switch OFF.
2. Disconnect pre-crash seat belt control unit and RH pre-crash seat belt motor connector.
3. Does continuity between pre-crash seat belt control unit harness connector terminals 1, 3 and RH pre-crash seat belt motor harness connector terminals 1, 2 exist?

**1 - 1 Existed**

**2 - 3 Existed**

4. Does continuity between pre-crash seat belt control unit harness connector terminals 1, 3 and ground exist?

**1 - Ground Not existed**

**3 - Ground Not existed**

Is the inspection result normal?

- YES >> Refer to [SBC-14, "Component Inspection"](#).  
NO >> Repair or replace harness between pre-crash seat belt control unit and RH pre-crash seat belt motor.

### Component Inspection

INFOID:000000002912401

#### 1. CHECK RH PRE-CRASH SEAT BELT MOTOR

Does continuity between RH pre-crash seat belt motor terminals 1 and 2 exist?

**1 - 2 Existed**

Is the inspection result normal?

- YES >> Replace pre-crash seat belt control unit.  
NO >> Replace RH pre-crash seat belt motor.

# B2452 SB MOTOR LH CIRC

< DTC/CIRCUIT DIAGNOSIS >

## B2452 SB MOTOR LH CIRC

### Description

INFOID:000000002912402

- It pulls, returns, and maintains according to the motor rotation.
- It is built into the seat belt retractor.
- It is installed to the back of LH center pillar garnish.

### DTC Logic

INFOID:000000002912403

### DTC DETECTION LOGIC

DTC No.	Self-diagnosis item	DTC Detection Condition	Possible causes
B2452	Seat belt motor system LH	Circuit of seat belt motor (LH) is open or shorted	<ul style="list-style-type: none"><li>• Open circuit, short circuit to battery, and short circuit to ground in seat belt motor (LH) harness</li><li>• ECU internal malfunction</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK LH PRE-CRASH SEAT BELT MOTOR CIRCUIT

Check "SELF-DIAG RESULT" of CONSULT-III.

Is any DTC detected?

- YES >> Refer to [SBC-15, "Diagnosis Procedure"](#).  
NO >> LH pre-crash seat belt motor system is normal.

### Diagnosis Procedure

INFOID:000000002912404

#### 1. CHECK LH PRE-CRASH SEAT BELT MOTOR HARNESS

1. Turn the ignition switch OFF.
2. Disconnect pre-crash seat belt control unit and LH pre-crash seat belt motor connector.
3. Does continuity between pre-crash seat belt control unit harness connector terminals 4, 6 and LH pre-crash seat belt motor harness connector terminals 1, 2 exist?

**1 - 6** **Existed**

**2 - 4** **Existed**

4. Does continuity between pre-crash seat belt control unit harness connector terminals 4, 6 and ground exist?

**4 - Ground** **Not existed**

**6 - Ground** **Not existed**

Is the inspection result normal?

- YES >> Refer to [SBC-15, "Component Inspection"](#).  
NO >> Repair or replace harness between pre-crash seat belt control unit and LH pre-crash seat belt motor.

### Component Inspection

INFOID:000000002912405

#### 1. CHECK LH PRE-CRASH SEAT BELT MOTOR

Does continuity between LH pre-crash seat belt motor terminals 1 and 2 exist?

**1 - 2** **Existed**

Is the inspection result normal?

- YES >> Replace pre-crash seat belt control unit.  
NO >> Replace LH pre-crash seat belt motor.

A  
B  
C  
D  
E  
F  
G  
I  
J  
K  
L  
M  
N  
O  
P

**SBC**

# B2453 BR STROK SEN CIRC

< DTC/CIRCUIT DIAGNOSIS >

## B2453 BR STROK SEN CIRC

### Description

INFOID:000000002912406

- It changes voltage according to brake pedal depressed amount and sends the signal to pre-crash seat belt control unit.
- There are 2 signals (brake pedal stroke sensor 1 and 2) sent from the brake pedal stroke sensor. Pre-crash seat belt control unit will judge the stroke amount and the speed of the brake pedal according to the voltage of the signal sent by each side.
- It is installed to back of driver instrument panel (lower).

### DTC Logic

INFOID:000000002912407

### DTC DETECTION LOGIC

DTC No.	Self-diagnosis item	DTC Detection Condition	Possible causes
B2453	B-pedal sensor system	Circuit of brake pedal stroke sensor output is open or shorted	<ul style="list-style-type: none"><li>• Open circuit, short circuit to battery, and short circuit to ground in brake pedal stroke sensor harness</li><li>• ECU internal malfunction</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK LH PRE-CRASH SEAT BELT MOTOR CIRCUIT

Check "SELF-DIAG RESULT" of CONSULT-III.

Is any DTC detected?

- YES >> Refer to Check 2 of [SBC-16. "Diagnosis Procedure"](#).  
NO >> Refer to Check 1 of [SBC-16. "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000002912408

#### 1. CHECK PRE-CRASH SEAT BELT CONTROL UNIT INPUT SIGNAL

Select "B-pedal sensor SIG1" and "B-pedal sensor SIG2", and then check that the voltage changes are synchronized with brake pedal operation.

##### **B-pedal sensor SIG1**

**Brake released → depressed    Approx. 1V → 4V**

##### **B-pedal sensor SIG2**

**Brake released → depressed    Approx. 4V → 1V**

Is the inspection result normal?

- YES >> Brake pedal stroke sensor system is normal.  
NO >> GO TO 2.

#### 2. CHECK BRAKE PEDAL STROKE SENSOR HARNESS

1. Turn the ignition switch OFF.
2. Disconnect pre-crash seat belt control unit and brake pedal stroke sensor connector.
3. Does continuity between pre-crash seat belt control unit harness connector terminals 16, 18, 20, 21 and brake pedal stroke sensor harness connector terminals 1, 2, 3, 4 exist?

**16 - 1                            Existed**

**18 - 2                            Existed**

**20 - 3                            Existed**

**21 - 4                            Existed**

4. Does continuity between pre-crash seat belt control unit harness connector terminals 16, 18, 20, 21 and ground exist?



# B2453 BR STROK SEN CIRC

## < DTC/CIRCUIT DIAGNOSIS >

16 - Ground	Not existed
18 - Ground	Not existed
20 - Ground	Not existed
21 - Ground	Not existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness between pre-crash seat belt control unit and brake pedal stroke sensor.

### 3.CHECK BRAKE PEDAL STROKE SENSOR POWER SUPPLY

1. Connect pre-crash seat belt control unit connector.
2. Turn the ignition switch ON.
3. Check that voltage between pre-crash seat belt control unit harness connector terminal 18 and ground is normal.

18 - Ground                      Approx. 5V

Is the inspection result normal?

YES >> Refer to [SBC-17, "Component Inspection"](#).

NO >> Replace pre-crash seat belt control unit.

## Component Inspection

INFOID:000000002912409

### 1.CHECK BRAKE PEDAL STROKE SENSOR

Check that continuity between brake pedal stroke sensor terminal 2 and terminals 1 and 3 is normal when performing the brake operation.

Terminal	Measuring condition	Resistance (KΩ)
2	1 Brake released → depressed	Approx. 1.0 → 0.2
	3 Brake released → depressed	Approx. 0.2 → 1.0

Is the inspection result normal?

YES >> Brake pedal stroke sensor system is normal.

NO >> Replace brake pedal stroke sensor.

A  
B  
C  
D  
E  
F  
G  
I  
J  
K  
L  
M  
N  
O  
P

SBC

# B2454 MOTOR PWR SUP CIRC

< DTC/CIRCUIT DIAGNOSIS >

## B2454 MOTOR PWR SUP CIRC

### Description

INFOID:000000002912410

- When the control unit judges the emergency braking operation, it retracts the shoulder belt with the electric motor and reduces the looseness of the belt.
- When the ignition switch is turned ON, the current is flowing to the seat belt motor. It stops when the ignition switch is turned OFF.
- It is installed to back of center pillar garnish.

### DTC Logic

INFOID:000000002912411

### DTC DETECTION LOGIC

DTC No.	Self-diagnosis item	DTC Detection Condition	Possible causes
B2454	Motor power supply circuit system	Motor power supply circuit is open or shorted <b>CAUTION:</b> <b>Malfunction is judged when 30A (F/L-G) fusible link blows out even if motor power supply circuit is not malfunctioning.</b>	<ul style="list-style-type: none"><li>• Open circuit and short circuit to ground in drive circuit power supply harness</li><li>• ECU internal malfunction</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK MOTOR POWER SUPPLY CIRCUIT

Check "SELF-DIAG RESULT" of CONSULT-III.

Is any DTC detected?

- YES >> Refer to [SBC-18, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000002912412

#### 1. CHECK MOTOR POWER SUPPLY CIRCUIT

1. Disconnect the pre-crash seat belt control unit connector.
2. Check that voltage between pre-crash seat belt control unit harness connector terminal 2 and ground is 12V.

**2 - Ground**

**Approx. 12V**

Is the inspection result normal?

- YES >> Inspection End.  
NO >> Repair or replace pre-crash seat belt control unit power supply circuit harness.

# B2455 PSB C/U INT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## B2455 PSB C/U INT CIRCUIT

### Description

INFOID:000000002912413

- It controls pre-crash seat belt motor according to input signal.
- It consists of pre-crash seat belt control unit.
- It is installed on the back of the glove box.

### DTC Logic

INFOID:000000002912414

### DTC DETECTION LOGIC

DTC No.	Self-diagnosis item	DTC Detection Condition	Possible causes
B2455	C/U internal circuit system	Pre-crash seat belt control unit internal circuit malfunction	ECU internal malfunction

### DTC CONFIRMATION PROCEDURE

#### 1. SELF-DIAGNOSIS WITH PRE-CRASH SEAT BELT CONTROL UNIT

Check "SELF-DIAG RESULT" of CONSULT-III.

#### Is any DTC detected?

- YES >> Replace pre-crash seat belt control unit.  
NO >> Pre-crash seat belt control unit is normal.

A  
B  
C  
D  
E  
F  
G  
I  
J  
K  
L  
M  
N  
O  
P

SBC

# BRAKE PEDAL STROKE SENSOR SHIELD WIRE CIRCUIT CHECK

< DTC/CIRCUIT DIAGNOSIS >

## BRAKE PEDAL STROKE SENSOR SHIELD WIRE CIRCUIT CHECK

### Description

INFOID:000000002912415

- It changes voltage according to brake pedal depressed amount and sends the signal to pre-crash seat belt control unit.
- There are two signals (brake pedal stroke sensor 1 and 2) sent from the brake pedal stroke sensor. Pre-crash seat belt control unit will judge the stroke amount and the speed of the brake pedal according to the voltage of the signal sent by each side.
- It is installed to back of driver instrument panel (lower).

### Component Function Check

INFOID:000000002912416

#### 1. CHECK PRE-CRASH SEAT BELT CONTROL UNIT INPUT SIGNAL

With CONSULT-III

When checking "B-pedal sensor SIG1" and "2" on DATA MONITOR screen, check that the voltage does not change if brake pedal is not operated.

**NOTE:**

Diagnosis should be performed with engine running, audio and air conditioner operating.

**B-pedal sensor SIG1**

**Brake released** There is no change in the voltage value,  
and it is almost constant

**B-pedal sensor SIG2**

**Brake released** There is no change in the voltage value,  
and it is almost constant

Without CONSULT-III

1. Start the engine.
2. Check that voltage between pre-crash seat belt harness connector and ground without brake pedal operation is normal.

Terminal		Measuring condition	Voltage
(+)	(-)		
16	Ground	Brake released When engine is started and audio and air conditioner are operating	There is no change in the voltage value, and it is almost constant.
20			

Is the inspection result normal?

- YES >> Brake pedal stroke sensor shield ground system is normal.  
NO >> Check shield wire for damage. Repair or replace if necessary.

# SEAT BELT BUCKLE SWITCH (DRIVER SIDE) CIRCUIT CHECK

< DTC/CIRCUIT DIAGNOSIS >

## SEAT BELT BUCKLE SWITCH (DRIVER SIDE) CIRCUIT CHECK

### Description

INFOID:000000002912417

- Perform the control of tension reducer according to the seat belt buckle switch ON/OFF.
- If the seat belt is not fastened when the ignition switch is turned ON, it detects whether the seat belt is fastened or not so as to turn on the seat belt warning lamp of combination meter.
- The seat belt buckle switch is installed in the seat belt buckle.

### Component Function Check

INFOID:000000002912418

#### 1. CHECK PRE-CRASH SEAT BELT CONTROL UNIT INPUT SIGNAL

With CONSULT-III

When checking "BUCKLE SW LH" on DATA MONITOR screen, check that ON/OFF display changes synchronized with the insertion operation to the seat belt buckle.

##### BUCKLE SW LH

When LH seat belt is not fastened OFF

When LH seat belt is fastened ON

Without CONSULT-III

1. Turn the ignition switch ON.
2. Check that voltage between LH seat belt buckle switch harness connector terminal 1 and ground is normal.

Terminal		Measuring condition	Voltage (V)
(+)	(-)		
1	Ground	When seat belt is not fastened	Approx. 0
		When seat belt is fastened	Approx. 12

Is the inspection result normal?

- YES >> LH seat belt buckle switch system is normal.  
NO >> GO TO 2.

#### 2. CHECK LH SEAT BELT BUCKLE SWITCH HARNESS

1. Turn the ignition switch OFF.
2. Disconnect pre-crash seat belt control unit connector and LH seat belt buckle switch connector.
3. Does continuity between pre-crash seat belt control unit harness connector terminal 10 and LH seat belt buckle switch harness connector terminal 1 exist?

10 - 1 Existed

4. Does continuity between pre-crash seat belt control unit harness connector terminal 10 and ground exist?

10 - Ground Not existed

Is the inspection result normal?

- YES >> Refer to [SBC-21, "Component Inspection \(Driver seat belt buckle switch\)"](#).  
NO >> Repair or replace harness between pre-crash seat belt control unit and LH seat belt buckle switch.

### Component Inspection (Driver seat belt buckle switch)

INFOID:000000002912419

#### 1. CHECK LH SEAT BELT BUCKLE SWITCH

Check that continuity between LH seat belt buckle switch terminals 1 and 2 is normal when performing the insertion operation to the seat belt buckle.

# SEAT BELT BUCKLE SWITCH (DRIVER SIDE) CIRCUIT CHECK

< DTC/CIRCUIT DIAGNOSIS >

---

Terminal		Measuring condition	Continuity
1	2	When seat belt is not fastened	Existed
		When seat belt is fastened	Not existed

Is the inspection result normal?

- YES >> Refer to [SBC-22, "Component Inspection \(Driver seat belt buckle switch ground circuit\)".](#)  
NO >> Replace LH seat belt buckle.

## Component Inspection (Driver seat belt buckle switch ground circuit)

INFOID:000000002912420

### 1. CHECK LH SEAT BELT BUCKLE SWITCH GROUND CIRCUIT HARNESS

---

Does continuity between LH seat belt buckle switch harness connector terminal 2 and ground exist?

**2 - Ground**                      **Existed**

Is the inspection result normal?

- YES >> LH seat belt buckle switch system is normal.  
NO >> Repair or replace harness between LH seat belt buckle switch and ground.

# SEAT BELT BUCKLE SWITCH (PASSENGER SIDE) CIRCUIT CHECK

< DTC/CIRCUIT DIAGNOSIS >

## SEAT BELT BUCKLE SWITCH (PASSENGER SIDE) CIRCUIT CHECK

### Description

INFOID:000000002912421

- Perform the control of tension reducer according to the seat belt buckle switch ON/OFF.
- If the seat belt is not fastened when the ignition switch is turned ON, it detects whether the seat belt is fastened or not so as to turn on the seat belt warning lamp of combination meter.
- The seat belt buckle switch is installed in the seat belt buckle.

### Component Function Check

INFOID:000000002912422

#### 1. CHECK PRE-CRASH SEAT BELT CONTROL UNIT INPUT SIGNAL

With CONSULT-III

When checking "BUCKLE SW RH" on DATA MONITOR screen, check that ON/OFF display changes are synchronized with the insertion operation to the seat belt buckle.

##### BUCKLE SW RH

When RH seat belt is not fastened OFF

When RH seat belt is fastened ON

Without CONSULT-III

1. Turn the ignition switch ON.
2. Check that voltage between RH seat belt buckle switch harness connector terminal 1 and ground is normal.

Terminal		Measuring condition	Voltage (V)
(+)	(-)		
1	Ground	When seat belt is not fastened	Approx. 0
		When seat belt is fastened	Approx. 5

Is the inspection result normal?

- YES >> RH seat belt buckle switch system is normal.  
NO >> GO TO 2.

#### 2. CHECK RH SEAT BELT BUCKLE SWITCH HARNESS

1. Turn the ignition switch OFF.
2. Disconnect pre-crash seat belt control unit connector and RH seat belt buckle switch connector.
3. Does continuity between pre-crash seat belt control unit harness connector terminal 8 and RH seat belt buckle switch harness connector terminal 1 exist?

8 - 1 Existed

4. Does continuity between pre-crash seat belt control unit harness connector terminal 8 and ground exist?

8 - Ground Not existed

Is the inspection result normal?

- YES >> Refer to [SBC-23, "Component Inspection \(Passenger seat belt buckle switch\)"](#).  
NO >> Repair or replace harness between pre-crash seat belt control unit and RH seat belt buckle switch.

### Component Inspection (Passenger seat belt buckle switch)

INFOID:000000002912423

#### 1. CHECK RH SEAT BELT BUCKLE SWITCH

Check that continuity between RH seat belt buckle switch terminals 1 and 2 is normal when performing the insertion operation to the seat belt buckle.

# SEAT BELT BUCKLE SWITCH (PASSENGER SIDE) CIRCUIT CHECK

< DTC/CIRCUIT DIAGNOSIS >

---

Terminal		Measuring condition	Continuity
1	2	When seat belt is not fastened	Existed
		When seat belt is fastened	Not existed

Is the inspection result normal?

- YES >> Refer to [SBC-24. "Component Inspection \(Passenger seat belt side buckle switch ground circuit\)".](#)  
NO >> Replace RH seat belt buckle.

Component Inspection (Passenger seat belt side buckle switch ground circuit)

INFOID:000000002912424

## 1. CHECK RH SEAT BELT BUCKLE SWITCH GROUND CIRCUIT HARNESS

---

Does continuity between RH seat belt buckle switch harness connector terminal 2 and ground exist?

**2 - Ground**                      **Existed**

Is the inspection result normal?

- YES >> RH seat belt buckle switch system is normal.  
NO >> Repair or replace harness between RH seat belt buckle switch and ground.



# IGNITION POWER SUPPLY CIRCUIT CHECK

< DTC/CIRCUIT DIAGNOSIS >

## IGNITION POWER SUPPLY CIRCUIT CHECK

### Description

INFOID:000000002912425

- It is the power supply system when turning the ignition switch to IGN ON/OFF.
- The ignition switch is installed to the right side of the steering column.

### Component Function Check

INFOID:000000002912426

#### 1. CHECK FUSES

1. Turn the ignition switch OFF.
2. Check that the fuses are not blown.

**CAUTION:**

Refer to [GI-42, "Circuit Inspection"](#) for fuse number.

Is the inspection result normal?

YES >> GO TO 2.

NO >> If a fuse is blown, determine the possible cause, repair the affected circuit, and replace the blown fuse.

#### 2. CHECK IGNITION POWER SUPPLY CIRCUIT

1. Disconnect the pre-crash seat belt control unit connector.
2. Turn the ignition switch ON.
3. Check that voltage between pre-crash seat belt control unit harness connector terminal 13 and ground is normal.

**13 - Ground**

**Approx. 12V**

Is the inspection result normal?

YES >> Ignition power supply system is normal.

NO >> Repair or replace pre-crash seat belt control unit ignition power supply circuit harness.

A  
B  
C  
D  
E  
F  
G  
I  
J  
K  
L  
M  
N  
O  
P

SBC

# PRE-CRASH SEAT BELT CONTROL UNIT GROUND CIRCUIT CHECK

< DTC/CIRCUIT DIAGNOSIS >

## PRE-CRASH SEAT BELT CONTROL UNIT GROUND CIRCUIT CHECK

### Description

INFOID:000000002912427

- The pre-crash seat belt control unit controls the pre-crash seat belt motor according to the input signal.
- When the control unit judges the emergency braking operation and the intelligent brake assistance operating status, it gives the sense of security by the motor built into the pre-crash seat belt motor retracting the shoulder belt and suppressing the crew's posture change. Or, it eases the damage of the collision.
- It is installed on the back of the glove box.

### Component Function Check

INFOID:000000002912428

#### 1. CHECK PRE-CRASH SEAT BELT CONTROL UNIT GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the pre-crash seat belt control unit connector.
3. Check that continuity between pre-crash seat belt control unit harness connector terminals 5, 26 and ground is normal.

**5 - Ground**

**Existed**

**26 - Ground**

**Existed**

Is the inspection result normal?

YES >> Ground system is normal.

NO >> Repair or replace harness between pre-crash seat belt control unit and ground.

# PRE-CRASH SEAT BELT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

## ECU DIAGNOSIS INFORMATION

### PRE-CRASH SEAT BELT CONTROL UNIT


Reference Value

INFOID:000000002912430

VALUES ON THE DIAGNOSIS TOOL  
CONSULT-III MONITOR ITEM

Monitor item	Condition	Value/Status (Approx)
B PEDAL SENS SIG1 B PEDAL SENS SIG2	Brake released Brake released	(1V) (4V)
B PEDAL SENS SIG1 B PEDAL SENS SIG2	Brake released → depressed Brake released → depressed	(1V→4V) (4V→1V)
RH BUCKLE SW	RH seat belt is not fastened RH seat belt is fastened	OFF ON
LH BUCKLE SW	LH seat belt is not fastened LH seat belt is fastened	OFF ON

### TERMINAL LAYOUT



### PHYSICAL VALUES

Terminal No.		Wire color	Description		Condition	Value (*1) (Approx)
+	-		Signal name	Input/Output		
1	GND	G/R	RH seat belt motor release signal	Output	—	—
2	GND	W	Drive circuit power supply (+BAT)	Input	Seat belt motor non-operational	BAT
3	GND	G/Y	RH seat belt motor forward (retract) signal	Output	—	—
4	GND	GR/W	LH seat belt motor forward (retract) signal	Output	—	—
5	GND	W	Drive circuit ground	—	Always	GND
6	GND	LY	LH seat belt motor release signal	Output	—	—
7	GND	G	Indicator (seat belt warning lamp)	Output	LH seat belt is not fastened	GND
					LH seat belt is fastened	BAT
					LH seat belt is fastened or malfunction of system	BAT←→GND (0.5sec)
8	GND	LG	RH seat belt buckle switch signal	Input	RH seat belt is fastened	BAT
					RH seat belt is not fastened	GND
10	GND	SB	LH seat belt buckle switch signal	Input	LH seat belt is fastened	OPEN
					LH seat belt is not fastened	GND

# PRE-CRASH SEAT BELT CONTROL UNIT

## < ECU DIAGNOSIS INFORMATION >

Terminal No.		Wire color	Description		Condition	Value (*1) (Approx)
+	-		Signal name	Input/ Output		
13	GND	W	Control circuit power supply (IGN)	Input	IGN ON	BAT
					IGN OFF	GND
16	GND	W	Brake pedal stroke sensor signal1	Input	IGN ON	(1→4V) *2
					IGN OFF	0V
18	GND	R	Brake pedal stroke sensor power circuit	Output	IGN ON	5V
					IGN OFF	0V
20	GND	G	Brake pedal stroke sensor signal2	Input	IGN ON	(4→1V) *2
					IGN OFF	0V
21	GND	B	Brake pedal stroke sensor ground circuit	—	Always	GND
22	GND	P	CAN communication signal (CAN L-line)	Input/ Output	—	—
24	GND	L	CAN communication signal (CAN H-line)	Input/ Output	—	—
25	GND	SHIELD	Shield ground	—	Always	GND
26	GND	B	Control circuit ground	—	Always	GND

\*1: Perform the measurement while connecting the control unit and the harness.

\*2: The value may be changed according to the brake pedal depressed amount.

## Fail Safe

INFOID:000000002912431

When a malfunction occurs in the following system, the pre-crash seat belt function is controlled according to the malfunctioning parts.

Display contents of CONSULT-III	Fail-safe	Cancellation
B2451: SB MOTOR RH CIRC	Deactivate the RH pre-crash seat belt function	Erase DTC
B2452: SB MOTOR LH CIRC	Deactivate the LH pre-crash seat belt function	Erase DTC
B2453: BR STROK SEN CIRC	Deactivate the interlock function during emergency brake operation	Erase DTC
B2454: MOTOR PWR SUP CIRC	Deactivate the pre-crash seat belt function	Erase DTC

## DTC Index

INFOID:000000002912432

## DISPLAY ITEM LIST (PRE-CRASH SEAT BELT)


DTC	Trouble diagnosis name (CONSULT-III display)	DTC detection condition	Reference
—	—	No malfunction is detected	—
U1000	CAN COMM CIRCUIT	Pre-crash seat belt control unit cannot transmit and receive CAN communication signal for 2 seconds or more	<a href="#">SBC-13</a>
B2451	SB MOTOR RH CIRC	RH seat belt motor circuit is shorted or open	<a href="#">SBC-14</a>
B2452	SB MOTOR LH CIRC	LH seat belt motor circuit is shorted or open	<a href="#">SBC-15</a>
B2453	BR STROK SEN CIRC	Brake pedal stroke sensor circuit is shorted or open	<a href="#">SBC-16</a>
B2454	MOTOR PWR SUP CIRC	Motor power supply circuit is shorted or open <b>CAUTION:</b> <b>Malfunction is judged when 30A (F/L-G) fusible link blows out even if motor power supply circuit is not malfunctioning.</b>	<a href="#">SBC-18</a>
B2455	PSB C/U INT CIRCUIT	Internal breakdown in pre-crash seat belt control unit	<a href="#">SBC-19</a>

# PRE-CRASH SEAT BELT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

## Wiring Diagram - SEAT BELT CONTROL SYSTEM -

INFOID:000000002912433



2007/06/15

JCHWA0107GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


SBC

# PRE-CRASH SEAT BELT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


## PRE-CRASH SEAT BELT SYSTEM

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH80FY-GS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
23	L	-
24	P	-
25	L	-
26	P	-
27	SB	-
91	G/R	-
96	G/Y	-
97	SHIELD	-

Connector No.	B13
Connector Name	SEAT BELT BUCKLE SWITCH (DRIVER SIDE)
Connector Type	A03FW




Terminal No.	Color of Wire	Signal Name [Specification]
1	SB	-
2	B	-

Connector No.	B28
Connector Name	PRE-CRASH SEAT BELT MOTOR LH
Connector Type	TB02FW-ZV




Terminal No.	Color of Wire	Signal Name [Specification]
1	G/Y	-
2	G/R	-

Connector No.	B201
Connector Name	WIRE TO WIRE
Connector Type	TH80FY-GS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
4	SHIELD	-
5	G/R	-
7	LG	-
10	G/Y	-

Connector No.	B213
Connector Name	SEAT BELT BUCKLE SWITCH (PASSENGER SIDE)
Connector Type	A03FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	-
2	B	-

Connector No.	B228
Connector Name	PRE-CRASH SEAT BELT MOTOR RH
Connector Type	TB02FW-ZV




Terminal No.	Color of Wire	Signal Name [Specification]
1	G/R	-
2	G/Y	-

Connector No.	E67
Connector Name	ICC SENSOR INTEGRATED UNIT
Connector Type	RS08FB-PR



Terminal No.	Color of Wire	Signal Name [Specification]
3	L	CAN-H
6	P	CAN-L

Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	TH80FY-GS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	W	-
3	G	-
4	B	-
5	W	-
6	P	-
7	L	-
9	SHIELD	-
10	SHIELD	-

JCHWA0108GB

# PRE-CRASH SEAT BELT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

## PRE-CRASH SEAT BELT SYSTEM

Connector No.	E116
Connector Name	BRAKE PEDAL STROKE SENSOR
Connector Type	HIS4FB




Terminal No.	Color of Wire	Signal Name [Specification]
1	W	S1
2	R	VCC
3	G	SZ
4	B	GND

Connector No.	F51
Connector Name	A/T ASSEMBLY
Connector Type	RK10FG-EGY




Terminal No.	Color of Wire	Signal Name [Specification]
3	L	-
6	P	-

Connector No.	F103
Connector Name	WIRE TO WIRE
Connector Type	TK38FW-NS10



Terminal No.	Color of Wire	Signal Name [Specification]
43	P	-
44	L	-

Connector No.	F151
Connector Name	TCM (TRANSMISSION CONTROL MODULE)
Connector Type	SPI08EGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	CAN-H
2	L/Y	CAN-L

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS10FW-M2



Terminal No.	Color of Wire	Signal Name [Specification]
2A	G	-

Connector No.	M2
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS10FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
6B	Y	-

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS12FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
8C	W	-
12C	R	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	W	-
3	G	-
4	B	-
5	W	-
6	P	-
7	L	-
8	SHIELD	-
10	SHIELD	-

A  
B  
C  
D  
E  
F  
G  
SBC  
I  
J  
K  
L  
M  
N  
O  
P


JCHWA0109GB

# PRE-CRASH SEAT BELT CONTROL UNIT

## < ECU DIAGNOSIS INFORMATION >


### PRE-CRASH SEAT BELT SYSTEM

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	TH60MW-GS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
23	L	-
24	P	-
25	L	-
26	P	-
27	L	-
91	GR/W	-
96	L/Y	-
97	SHIELD	-

Connector No.	M24
Connector Name	DATA LINK CONNECTOR
Connector Type	BD18FW



Terminal No.	Color of Wire	Signal Name [Specification]
6	L	-
14	P	-

Connector No.	M53
Connector Name	COMBINATION METER
Connector Type	SAB40FW




Terminal No.	Color of Wire	Signal Name [Specification]
2	LG	COMM (METER->AMP.)
3	GR	COMM (AMP->METER)
21	R	IGN
24	BR	COMM (LGD->AMP.)
25	Y	COMM (AMP->LCD)
29	L	SEAT BELT BUCKLE SW (DRIVER SIDE)
30	G	SEAT BELT

Connector No.	M66
Connector Name	UNIFIED METER AND A/C AMP.
Connector Type	TH40FW-NH




Terminal No.	Color of Wire	Signal Name [Specification]
7	GR	COMM (AMP->METER)
14	BR	COMM (LGD->AMP.)
27	LG	COMM (METER->AMP.)
34	Y	COMM (AMP->LCD)

Connector No.	M67
Connector Name	UNIFIED METER AND A/C AMP.
Connector Type	TH52FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
53	W	IGN
54	Y	BAT
55	B	GND
56	L	CAN-H
71	GR	GND
72	P	CAN-L

Connector No.	M110
Connector Name	PRE-CRASH SEAT BELT CONTROL UNIT
Connector Type	TH20FW-TB6



Terminal No.	Color of Wire	Signal Name [Specification]
1	G/R	MOTEOUR (RH) (RELEASE)
2	W	-IB
3	G/Y	MOTOR (RH) (FASTEN)
4	GR/W	MOTEOUR (LH) (FASTEN)
5	W	GND (DRIVE)
6	L/Y	MOTEOUR (LH) (RELEASE)
7	G	INDICATOR
8	LG	BUCKLE SW RH
10	SB	BUCKLE SW LH
13	W	IGN
16	W	SENS OUTPUT I

18	R	SENS POWER
20	G	SENS OUTPUT 2
21	B	SENS GND
22	P	CAN-L
24	L	CAN-H
25	SHIELD	SHIELD GND
26	B	GND (CONT)

Connector No.	M116
Connector Name	WIRE TO WIRE
Connector Type	TK38MW-HS10




Terminal No.	Color of Wire	Signal Name [Specification]
43	P	-
44	L	-



# PRE-CRASH SEAT BELT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

A  
B  
C  
D  
E  
F  
G  
SBC  
I  
J  
K  
L  
M  
N  
O  
P



JCHWA0111GB

# PRE-CRASH SEAT BELT SYSTEM

< SYMPTOM DIAGNOSIS >

## SYMPTOM DIAGNOSIS

### PRE-CRASH SEAT BELT SYSTEM

#### Description

INFOID:000000002912434

#### WARNING:

- The following tests should be performed in a safe, open place that is free of traffic and obstacles.
  - The tests should be performed on a dry, paved road. Do not attempt to perform the tests on a wet or unpaved road, open road, or highway. (This may cause an accident or personal injury.)
  - Driver and passenger should assume seat belt will not operate and prepare themselves accordingly.
1. Tighten driver and passenger seat belts.
  2. Drive at approximately 25 km/h.
  3. Notify passenger of a sudden stop. Driver and passenger prepare themselves for the possibility of system not operating. Then, driver fully depresses the brake pedal to stop suddenly.
  4. Check that the shoulder of the seat belt is pulled while braking.

#### Symptom Table

INFOID:000000002912435

Symptom	Suspect Item	Refer to
Pre-crash seat belt system does not operate. (Neither RH nor LH operate.)	IGNITION POWER SUPPLY CIRCUIT	<a href="#">SBC-25</a>
	B2454 MOTOR POWER SUPPLY CIRCUIT	<a href="#">SBC-18</a>
	PRE-CRASH SEAT BELT CONTROL UNIT GROUND CIRCUIT	<a href="#">SBC-26</a>
	U1000 CAN COMM CIRCUIT	<a href="#">SBC-13</a>
	When the above is normal, check connector housing for damage, looseness and poor connection. Replace PRE-CRASH SEAT BELT CONTROL UNIT if it is normal.	<a href="#">SBC-38</a>
RH pre-crash seat belt system does not operate.	SEAT BELT BUCKLE SWITCH (PASSENGER SIDE) CIRCUIT	<a href="#">SBC-23</a>
	B2451 SB MOTOR RH CIRC	<a href="#">SBC-14</a>
	When the above is normal, check connector housing for damage, looseness and poor connection. Replace PRE-CRASH SEAT BELT CONTROL UNIT if it is normal.	<a href="#">SBC-38</a>
LH pre-crash seat belt system does not operate.	SEAT BELT BUCKLE SWITCH (DRIVER SIDE) CIRCUIT	<a href="#">SBC-21</a>
	B2452 SB MOTOR LH CIRC	<a href="#">SBC-15</a>
	When the above is normal, check connector housing for damage, looseness and poor connection. Replace PRE-CRASH SEAT BELT CONTROL UNIT if it is normal.	<a href="#">SBC-38</a>
Pre-crash seat belt system does not operate during emergency brake operation.	U1000 CAN COMM CIRCUIT	<a href="#">SBC-13</a>
	B2453 BR STROK SEN CIRC	<a href="#">SBC-16</a>
	BRAKE PEDAL STROKE SENSOR SHIELD WIRE CIRCUIT	<a href="#">SBC-20</a>
	When the above is normal, check connector housing for damage, looseness and poor connection. Replace PRE-CRASH SEAT BELT CONTROL UNIT if it is normal.	<a href="#">SBC-38</a>

# PRECAUTIONS

< PRECAUTION >

## PRECAUTION

### PRECAUTIONS

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000002912444

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIR BAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

#### Precaution for Seat Belt Service

INFOID:000000002912437

#### **CAUTION:**

- Before removing the seat belt pre-tensioner assembly, turn the ignition switch off, disconnect the both battery cables and wait at least 3 minutes.
- Do not use electrical test equipment for seat belt pre-tensioner connector.
- After replacing or reinstalling seat belt pre-tensioner assembly, or reconnecting front seat belt pre-tensioner connector, check the system function. Refer to [SBC-11, "Diagnosis Description"](#).
- Do not use disassemble buckle or seat belt assembly.
- Replace anchor bolts if they are deformed or worn out.
- Never oil tongue and buckle.
- If any component of seat belt assembly is questionable, do not repair. Replace the whole seat belt assembly.
- If webbing is cut, frayed, or damaged, replace seat belt assembly.
- When replacing seat belt assembly, use a genuine NISSAN seat belt assembly.

#### AFTER A COLLISION

#### **WARNING:**

Inspect all seat belt assemblies including retractors and attaching hardware after any collision. NISSAN recommends that all seat belt assemblies in use during a collision be replaced unless the collision was minor and the belts show no damage and continue to operate properly. Failure to do so could result in serious personal injury in an accident. Seat belt assemblies not in use during a collision should also be replaced if either damage or improper operation is noted. Seat belt pre-tensioner should be replaced even if the seat belts are not in use during a frontal collision in which the air bags are deployed.

Replace any seat belt assembly (including anchor bolts) if:

## PRECAUTIONS

### < PRECAUTION >

---

- The seat belt was in use at the time of a collision (except for minor collisions and the belts, retractors and buckles show no damage and continue to operate properly).
- The seat belt was damaged in an accident. (i.e. torn webbing, bent retractor or guide).
- The seat belt attaching point was damaged in an accident. Inspect the seat belt attaching area for damage or distortion and repair as necessary before installing a new seat belt assembly.
- Anchor bolts are deformed or worn out.
- The seat belt pre-tensioner should be replaced even if the seat belts are not in use during the collision in which the air bags are deployed.

# BRAKE PEDAL STROKE SENSOR


< PERIODIC MAINTENANCE >

## PERIODIC MAINTENANCE

### BRAKE PEDAL STROKE SENSOR

Exploded View

INFOID:000000002912439



1. Brake pedal stroke sensor

A. Brake pedal stroke sensor connector

### Removal and Installation

INFOID:000000002912440

#### REMOVAL

1. Remove the driver instrument panel (lower). Refer to [IP-12, "Removal and Installation"](#).
2. Disconnect the brake pedal stroke sensor connector (A).
3. Remove the screws.
4. Remove the brake pedal stroke sensor (1).

#### INSTALLATION

Install in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
I  
J  
K  
L  
M  
N  
O  
P

SBC


# PRE-CRASH SEAT BELT CONTROL UNIT

< PERIODIC MAINTENANCE >

## PRE-CRASH SEAT BELT CONTROL UNIT

Exploded View

INFOID:000000002912441



- 1. Pre-crash seat belt control unit
- A. Pre-crash seat belt control unit connector

### Removal and Installation

INFOID:000000002912442

#### REMOVAL

1. Remove the glove box. Refer to [IP-12. "Removal and Installation"](#).
2. Disconnect the pre-crash seat belt control unit connector (A).
3. Remove the screws.
4. Remove the pre-crash seat belt control unit (1).

#### INSTALLATION

Install in the reverse order of removal.