

SECTION **EX**  
EXHAUST SYSTEM

A  
EX

CONTENTS

<b>PRECAUTION</b> .....	2	<b>PERIODIC MAINTENANCE</b> .....	4	F
<b>PRECAUTIONS</b> .....	2	<b>EXHAUST SYSTEM</b> .....	4	
Removal and Installation .....	2	Inspection .....	4	G
<b>PREPARATION</b> .....	3	<b>REMOVAL AND INSTALLATION</b> .....	5	
<b>PREPARATION</b> .....	3	<b>EXHAUST SYSTEM</b> .....	5	H
Special Service Tool .....	3	Exploded View .....	5	
Commercial Service Tool .....	3	Removal and Installation .....	6	
		Inspection .....	6	I

D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

## PRECAUTIONS

< PRECAUTION >

---

### PRECAUTION

#### PRECAUTIONS

##### Removal and Installation

INFOID:000000008154686

**CAUTION:**

- Be sure to use genuine exhaust system parts or equivalents which are specially designed for heat resistance, corrosion resistance, and shape.
- Perform the operation with the exhaust system fully cooled down because the system will be hot just after engine stops.
- Be careful not to cut your hand on the heat insulator edge.

# PREPARATION

< PREPARATION >

## PREPARATION

### PREPARATION


#### Special Service Tool

INFOID:000000008154687

A

EX

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
KV10114400 (J-38365) Heated oxygen sensor wrench  	Loosening or tightening heated oxygen sensor 2 <b>For 22 mm (0.87 in) (a) width hexagon nut</b>




C

D

E

#### Commercial Service Tool

INFOID:000000008154688

(Kent-Moore No.) Tool name	Description
Heated oxygen sensor thread cleaner  	Reconditioning the exhaust system threads before installing a new heated oxygen sensor (Use with anti-seize lubricant shown below.) <b>A: For zirconia heated oxygen sensor [18 mm (0.71 in) dia.]</b> <b>B: For titania heated oxygen sensor [12 mm (0.47 in) dia.]</b> <b>C: Mating surface shave cylinder</b> <b>D: Flutes</b>
( — ) Anti-seize lubricant (Permatex 133AR or equivalent meeting MIL specification MIL-A-907)  	Lubricating heated oxygen sensor thread cleaner when reconditioning exhaust system threads
( — ) Power tool  	Loosening bolts and nuts

F

G

H

I

J

K

L

M

N

O

P

# EXHAUST SYSTEM

< PERIODIC MAINTENANCE >

## PERIODIC MAINTENANCE


### EXHAUST SYSTEM

#### Inspection

INFOID:000000008154689

Check exhaust pipes, muffler and mounting for improper attachment, leakage, cracks, damage or deterioration.

- If anything is found, repair or replace damaged parts.



# EXHAUST SYSTEM

< REMOVAL AND INSTALLATION >

## REMOVAL AND INSTALLATION


### EXHAUST SYSTEM

Exploded View

INFOID:000000008154690

A

EX



- |                        |                                     |                                     |
|------------------------|-------------------------------------|-------------------------------------|
| 1. Mounting bracket    | 2. Mounting rubber                  | 3. Main muffler                     |
| 4. Dynamic damper      | 5. Mounting rubber                  | 6. Gasket                           |
| 7. Mounting rubber     | 8. Mounting bracket                 | 9. Center muffler                   |
| 10. Gasket             | 11. Three way catalyst (bank 1)     | 12. Heated oxygen sensor 2 (bank 1) |
| 13. Collar             | 14. Grommet                         | 15. Exhaust mounting bracket        |
| 16. Grommet            | 17. Heated oxygen sensor 2 (bank 2) | 18. Three way catalyst (bank 2)     |
| 19. Gasket             | 20. Dynamic damper                  | 21. Insulator                       |
| 22. Exhaust front tube | 23. Gasket                          |                                     |

Refer to [GI-4, "Components"](#) for symbols in the figure.

C

D

E

F

G

H

I

J

K

L

M

N

O

P

# EXHAUST SYSTEM

## < REMOVAL AND INSTALLATION >

### Removal and Installation

INFOID:000000008154691

#### REMOVAL

- Disconnect each joint and mounting using power tool.
- Remove heated oxygen sensor 2 as follows:
  - Using heated oxygen sensor wrench [SST: KV10114400 (J-38365)] (C), removal heated oxygen sensor 2.


A : Bank 1

B : Bank 2

↔ : Vehicle front

#### CAUTION:

Be careful not to damage heated oxygen sensor 2.



#### INSTALLATION

Note the following, and install in the reverse order of removal.

- Check for deformation of the grommets (14 and 16 of Components).
- Insert the collar (13 of Components) vertically.
- Temporarily tighten nuts and bolts when installing exhaust pipe assembly. Tighten them to the specified torque when connecting the vehicle rear to the vehicle front.

#### CAUTION:

- Always replace exhaust tube gaskets with new ones when reassembling.
- Discard any heated oxygen sensor 2 which has been dropped onto a hard surface such as a concrete floor. Use a new one.
- Before installing a new heated oxygen sensor 2, clean exhaust system threads using the heated oxygen sensor thread cleaner [commercial service tool: J-43897-18 or J-43897-12], and apply the anti-seize lubricant (commercial service tool).
- Never over torque heated oxygen sensor 2. Doing so may cause damage to heated oxygen sensor 2, resulting in the "MIL" coming on.
- Prevent rust preventives from adhering to the sensor body.
- If heat insulator is badly deformed, repair or replace it. If deposits such as mud pile up on the heat insulator, remove them.
- When installing heat insulator avoid large gaps or interference between heat insulator and each exhaust pipe.
- Remove deposits from the sealing surface of each connection. Connect them securely to avoid gases leakage.
- Temporarily tighten mounting nuts on the exhaust manifold side and mounting bolts on the vehicle side. Check each part for unusual interference, and then tighten them to the specified torque.
- When installing each mounting rubber, avoid twisting or unusual extension in up/down and right/left directions.

#### Inspection

INFOID:000000008154692

#### INSPECTION AFTER INSTALLATION

- Check clearance between tail tube and rear bumper is even.
- With engine running, check exhaust tube joints for gas leakage and unusual noises.
- Check to ensure that mounting brackets and mounting rubbers are installed properly and free from undue stress. Improper installation could result in excessive noise and vibration.