

SECTION **ADP**

AUTOMATIC DRIVE POSITIONER

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

CONTENTS

<p>BASIC INSPECTION 6</p> <p>DIAGNOSIS AND REPAIR WORKFLOW 6</p> <p style="padding-left: 20px;">Work Flow6</p> <p>INSPECTION AND ADJUSTMENT 9</p> <p>ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL9</p> <p style="padding-left: 20px;">ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Description9</p> <p style="padding-left: 20px;">ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement9</p> <p>ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT9</p> <p style="padding-left: 20px;">ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description9</p> <p style="padding-left: 20px;">ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement9</p> <p>SYSTEM INITIALIZATION 10</p> <p style="padding-left: 20px;">SYSTEM INITIALIZATION : Description 10</p> <p style="padding-left: 20px;">SYSTEM INITIALIZATION : Special Repair Requirement 10</p> <p>MEMORY STORING 10</p> <p style="padding-left: 20px;">MEMORY STORING : Description 10</p> <p style="padding-left: 20px;">MEMORY STORING : Special Repair Requirement 10</p> <p>SYSTEM SETTING 11</p> <p style="padding-left: 20px;">SYSTEM SETTING : Description 11</p> <p style="padding-left: 20px;">SYSTEM SETTING : Special Repair Requirement 11</p> <p>SYSTEM DESCRIPTION 13</p> <p>AUTOMATIC DRIVE POSITIONER SYSTEM..... 13</p> <p>AUTOMATIC DRIVE POSITIONER SYSTEM 13</p>	<p>AUTOMATIC DRIVE POSITIONER SYSTEM :</p> <p style="padding-left: 20px;">System Diagram13</p> <p>AUTOMATIC DRIVE POSITIONER SYSTEM :</p> <p style="padding-left: 20px;">System Description14</p> <p>AUTOMATIC DRIVE POSITIONER SYSTEM :</p> <p style="padding-left: 20px;">Component Parts Location15</p> <p>AUTOMATIC DRIVE POSITIONER SYSTEM :</p> <p style="padding-left: 20px;">Component Description17</p> <p>MANUAL FUNCTION19</p> <p style="padding-left: 20px;">MANUAL FUNCTION : System Diagram19</p> <p style="padding-left: 20px;">MANUAL FUNCTION : System Description19</p> <p style="padding-left: 20px;">MANUAL FUNCTION : Component Parts Location21</p> <p style="padding-left: 20px;">MANUAL FUNCTION : Component Description23</p> <p>SEAT SYNCHRONIZATION FUNCTION24</p> <p style="padding-left: 20px;">SEAT SYNCHRONIZATION FUNCTION : System Diagram24</p> <p style="padding-left: 20px;">SEAT SYNCHRONIZATION FUNCTION : System Description24</p> <p style="padding-left: 20px;">SEAT SYNCHRONIZATION FUNCTION : Component Parts Location26</p> <p style="padding-left: 20px;">SEAT SYNCHRONIZATION FUNCTION : Component Description28</p> <p>MEMORY FUNCTION29</p> <p style="padding-left: 20px;">MEMORY FUNCTION : System Diagram29</p> <p style="padding-left: 20px;">MEMORY FUNCTION : System Description29</p> <p style="padding-left: 20px;">MEMORY FUNCTION : Component Parts Location31</p> <p style="padding-left: 20px;">MEMORY FUNCTION : Component Description.....33</p> <p>INTELLIGENT KEY INTERLOCK FUNCTION34</p> <p style="padding-left: 20px;">INTELLIGENT KEY INTERLOCK FUNCTION : System Diagram34</p> <p style="padding-left: 20px;">INTELLIGENT KEY INTERLOCK FUNCTION : System Description34</p> <p style="padding-left: 20px;">INTELLIGENT KEY INTERLOCK FUNCTION : Component Parts Location36</p> <p style="padding-left: 20px;">INTELLIGENT KEY INTERLOCK FUNCTION : Component Description38</p>
---	--

ADP

POWER WALK-IN FUNCTION	38	DRIVER SEAT CONTROL UNIT	64
POWER WALK-IN FUNCTION : System Diagram..	39	DRIVER SEAT CONTROL UNIT :	
POWER WALK-IN FUNCTION : System Description	39	Diagnosis Procedure	64
POWER WALK-IN FUNCTION : Component Parts Location	41	DRIVER SEAT CONTROL UNIT : Special Repair Requirement	65
POWER WALK-IN FUNCTION : Component Description	43		
DIAGNOSIS SYSTEM (DRIVER SEAT C/U)	45	AUTOMATIC DRIVE POSITIONER CONTROL UNIT	65
Diagnosis Description	45	AUTOMATIC DRIVE POSITIONER CONTROL UNIT : Diagnosis Procedure	65
CONSULT-III Function	45	AUTOMATIC DRIVE POSITIONER CONTROL UNIT : Special Repair Requirement	66
DTC/CIRCUIT DIAGNOSIS	48	SLIDING SWITCH	67
U1000 CAN COMM CIRCUIT	48	Description	67
Description	48	Component Function Check	67
DTC Logic	48	Diagnosis Procedure	67
Diagnosis Procedure	48	Component Inspection	68
Special Repair Requirement	48	RECLINING SWITCH	69
B2112 SLIDING MOTOR	49	Description	69
Description	49	Component Function Check	69
DTC Logic	49	Diagnosis Procedure	69
Diagnosis Procedure	49	Component Inspection	70
B2113 RECLINING MOTOR	51	LIFTING SWITCH (FRONT)	71
Description	51	Description	71
DTC Logic	51	Component Function Check	71
Diagnosis Procedure	51	Diagnosis Procedure	71
B2118 TILT SENSOR	53	Component Inspection	72
Description	53	LIFTING SWITCH (REAR)	73
DTC Logic	53	Description	73
Diagnosis Procedure	53	Component Function Check	73
B2119 TELESCOPIC SENSOR	56	Diagnosis Procedure	73
Description	56	Component Inspection	74
DTC Logic	56	FORWARD SWITCH	75
Diagnosis Procedure	56	Description	75
B2126 DETENT SW	59	Component Function Check	75
Description	59	Diagnosis Procedure	75
DTC Logic	59	Component Inspection	76
Diagnosis Procedure	59	SEAT BELT BUCKLE SWITCH	77
B2127 PARKING BRAKE SWITCH	61	Description	77
Description	61	Component Function Check	77
DTC Logic	61	Diagnosis Procedure	77
Diagnosis Procedure	61	Component Inspection	78
Component Inspection	62	SLIDING LIMIT SWITCH	79
B2128 UART COMMUNICATION LINE	63	Description	79
Description	63	Component Function Check	79
DTC Logic	63	Diagnosis Procedure	79
Diagnosis Procedure	63	Component Inspection	80
POWER SUPPLY AND GROUND CIRCUIT	64	POWER WALK-IN SWITCH	81
BCM	64	Description	81
BCM : Diagnosis Procedure	64	Component Function Check	81
		Diagnosis Procedure	81
		Component Inspection	82

TILT SWITCH	83	Component Function Check	104	
Description	83	Diagnosis Procedure	104	A
Component Function Check	83			
Diagnosis Procedure	83	LIFTING SENSOR (FRONT)	107	
Component Inspection	84	Description	107	B
		Component Function Check	107	
TELESCOPIC SWITCH	85	Diagnosis Procedure	107	
Description	85			
Component Function Check	85	LIFTING SENSOR (REAR)	110	C
Diagnosis Procedure	85	Description	110	
Component Inspection	86	Component Function Check	110	
		Diagnosis Procedure	110	D
SEAT MEMORY SWITCH	87			
Description	87	TILT SENSOR	113	
Component Function Check	87	Description	113	E
Diagnosis Procedure	87	Component Function Check	113	
Component Inspection	88	Diagnosis Procedure	113	
DOOR MIRROR REMOTE CONTROL SWITCH	90	TELESCOPIC SENSOR	116	F
		Description	116	
MIRROR SWITCH	90	Component Function Check	116	
MIRROR SWITCH : Description	90	Diagnosis Procedure	116	G
MIRROR SWITCH : Component Function Check...	90			
MIRROR SWITCH : Diagnosis Procedure	90	MIRROR SENSOR	119	
MIRROR SWITCH : Component Inspection	91			
		DRIVER SIDE	119	H
CHANGEOVER SWITCH	92	DRIVER SIDE : Description	119	
CHANGEOVER SWITCH : Description	92	DRIVER SIDE : Component Function Check	119	
CHANGEOVER SWITCH : Component Function Check	92	DRIVER SIDE : Diagnosis Procedure	119	I
CHANGEOVER SWITCH : Diagnosis Procedure...	92			
CHANGEOVER SWITCH : Component Inspection	93	PASSENGER SIDE	121	
		PASSENGER SIDE : Description	121	
POWER SEAT SWITCH GROUND CIRCUIT	95	PASSENGER SIDE :		
Diagnosis Procedure	95	Component Function Check	121	ADP
		PASSENGER SIDE : Diagnosis Procedure	121	
TILT & TELESCOPIC SWITCH GROUND CIRCUIT	96			
Diagnosis Procedure	96	SLIDING MOTOR	124	K
		Description	124	
DETENTION SWITCH	97	Component Function Check	124	
Description	97	Diagnosis Procedure	124	L
Component Function Check	97	Component Inspection	125	
Diagnosis Procedure	97			
Component Inspection	98	RECLINING MOTOR	126	M
		Description	126	
PARKING BRAKE SWITCH	99	Component Function Check	126	
Description	99	Diagnosis Procedure	126	
Component Function Check	99	Component Inspection	127	N
Diagnosis Procedure	99			
Component Inspection	100	LIFTING MOTOR (FRONT)	128	
		Description	128	O
SLIDING SENSOR	101	Component Function Check	128	
Description	101	Diagnosis Procedure	128	
Component Function Check	101	Component Inspection	129	P
Diagnosis Procedure	101			
		LIFTING MOTOR (REAR)	130	
RECLINING SENSOR	104	Description	130	
Description	104	Component Function Check	130	
		Diagnosis Procedure	130	
		Component Inspection	131	
		TILT MOTOR	132	
		Description	132	

Component Function Check	132	STEERING POSITION FUNCTION DOES NOT OPERATE : Description	212
Diagnosis Procedure	132	STEERING POSITION FUNCTION DOES NOT OPERATE : Diagnosis Procedure	213
Component Inspection	133		
TELESCOPIC MOTOR	134	SEAT SLIDING	213
Description	134	SEAT SLIDING : Description	213
Component Function Check	134	SEAT SLIDING : Diagnosis Procedure	213
Diagnosis Procedure	134		
Component Inspection	135	SEAT RECLINING	213
DOOR MIRROR MOTOR	136	SEAT RECLINING : Description	213
Description	136	SEAT RECLINING : Diagnosis Procedure	214
Component Function Check	136		
Diagnosis Procedure	136	SEAT LIFTING (FRONT)	214
Component Inspection	137	SEAT LIFTING (FRONT) : Description	214
		SEAT LIFTING (FRONT) : Diagnosis Procedure ..	214
SEAT MEMORY INDICATOR	139	SEAT LIFTING (REAR)	215
Description	139	SEAT LIFTING (REAR) : Description	215
Component Function Check	139	SEAT LIFTING (REAR) : Diagnosis Procedure ..	215
Diagnosis Procedure	139		
DOOR MIRROR SYSTEM	141	STEERING TILT	215
Wiring Diagram - DOOR MIRROR (WITH AUTO-MATIC DRIVE POSITIONER) -	141	STEERING TILT : Description	215
		STEERING TILT : Diagnosis Procedure	215
ECU DIAGNOSIS INFORMATION	146	STEERING TELESCOPIC	216
DRIVER SEAT CONTROL UNIT (WITH AUTOMATIC DRIVE POSITIONER)	146	STEERING TELESCOPIC : Description	216
Reference Value	146	STEERING TELESCOPIC : Diagnosis Procedure ..	216
Wiring Diagram - AUTOMATIC DRIVE POSITIONER CONTROL SYSTEM -	152		
Fail Safe	161	DOOR MIRROR	216
DTC Index	162	DOOR MIRROR : Description	217
		DOOR MIRROR : Diagnosis Procedure	217
AUTOMATIC DRIVE POSITIONER CONTROL UNIT	163	MEMORY FUNCTION DOES NOT OPERATE. 218	
Reference Value	163	ALL COMPONENT	218
Wiring Diagram - AUTOMATIC DRIVE POSITIONER CONTROL SYSTEM -	167	ALL COMPONENT : Description	218
		ALL COMPONENT : Diagnosis Procedure	218
BCM (BODY CONTROL MODULE)	177	SEAT SLIDING	218
Reference Value	177	SEAT SLIDING : Description	218
Wiring Diagram - BCM -	200	SEAT SLIDING : Diagnosis Procedure	218
Fail-safe	205		
DTC Inspection Priority Chart	207	SEAT RECLINING	219
DTC Index	209	SEAT RECLINING : Description	219
		SEAT RECLINING : Diagnosis Procedure	219
SYMPTOM DIAGNOSIS	212	SEAT LIFTING (FRONT)	219
MANUAL FUNCTION DOES NOT OPERATE 212		SEAT LIFTING (FRONT) : Description	219
ALL COMPONENT	212	SEAT LIFTING (FRONT) : Diagnosis Procedure ..	219
ALL COMPONENT : Description	212	SEAT LIFTING (REAR)	220
ALL COMPONENT : Diagnosis Procedure	212	SEAT LIFTING (REAR) : Description	220
		SEAT LIFTING (REAR) : Diagnosis Procedure ..	220
POWER SEAT	212	STEERING TELESCOPIC	220
POWER SEAT : Description	212	STEERING TELESCOPIC : Description	220
POWER SEAT : Diagnosis Procedure	212	STEERING TELESCOPIC : Diagnosis Procedure ..	220
STEERING POSITION FUNCTION DOES NOT OPERATE	212	STEERING TILT	221
		STEERING TILT : Description	221
		STEERING TILT : Diagnosis Procedure	221
		DOOR MIRROR	221

DOOR MIRROR : Description	221	Service	228	
DOOR MIRROR : Diagnosis Procedure	221	Work	228	A
MEMORY INDICATE DOES NOT ILLUMI- NATE	222	REMOVAL AND INSTALLATION	230	
Diagnosis Procedure	222	DRIVER SEAT CONTROL UNIT	230	B
SEAT SYNCHRONIZATION FUNCTION DOES NOT OPERATE	223	Exploded View	230	
Diagnosis Procedure	223	Removal and Installation	230	C
POWER WALK-IN FUNCTION DOES NOT OPERATE	224	AUTOMATIC DRIVE POSITIONER CON- TROL UNIT	231	
Diagnosis Procedure	224	Exploded View	231	D
INTELLIGENT KEY INTERLOCK FUNCTION DOES NOT OPERATE	226	Removal and Installation	231	
Diagnosis Procedure	226	SEAT MEMORY SWITCH	232	E
NORMAL OPERATING CONDITION	227	Exploded View	232	
Description	227	Removal and Installation	232	F
PRECAUTION	228	POWER SEAT SWITCH	233	
PRECAUTIONS	228	Exploded View	233	G
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER"	228	Removal and Installation	233	
Precaution for Battery Service	228	SIDE SUPPORT SWITCH	234	H
		Exploded View	234	
		Removal and Installation	234	I
		TILT&TELESCOPIC SWITCH	235	
		Exploded View	235	
		Removal and Installation	235	

ADP

K
L
M
N
O
P

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000004535127

OVERALL SEQUENCE



JMJIA2428GB

DETAILED FLOW

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

1.GET INFORMATION FOR SYMPTOM

Get the detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred).

>> GO TO 2.

2.CHECK DTC WITH AUTOMATIC DRIVE POSITIONER SYSTEM

Check "Self Diagnostic Result" with CONSULT-III. Refer to [ADP-162, "DTC Index"](#)

Is any symptom described and any DTC is displayed?

Symptom is described, DTC is displayed.>>GO TO 3.

Symptom is not described, DTC is displayed.>>GO TO 6.

Symptom is described, DTC is not displayed.>>GO TO 4.

3.CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

>> GO TO 6.

4.CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

>> GO TO 5.

5.CHECK NORMAL OPERATING CONDITION

Check normal operating condition. Refer to [ADP-227, "Description"](#).

Is the incident normal operation?

YES >> INSPECTION END

NO >> GO TO 7.

6.PERFORM DTC CONFIRMATION PROCEDURE

Perform the confirmation procedure for the detected DTC.

Is the DTC displayed?

YES >> GO TO 8.

NO >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

7.DETECT MALFUNCTIONING SYSTEM BY SYMPTOM DIAGNOSIS

Detect malfunctioning system according to SYMPTOM DIAGNOSIS based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

>> GO TO 8.

8.PERFORM COMPONENT FUNCTION CHECK

Perform the component function check for the isolated malfunctioning point.

>> GO TO 9.

9.DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

Isolate the malfunctioning point by performing the diagnosis procedure relevant to the symptom during the component diagnosis.

>> GO TO 10.

10.REPARE OR REPLACE

Repair or replace the malfunctioning part.

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

>> GO TO 11.

11.FINAL CHECK

Perform the DTC confirmation procedure (if DTC is detected) or component function check (if no DTC is detected) again, and then check that the malfunction can be repaired securely.

Are all malfunctions corrected?

YES >> INSPECTION END

Symptom is detected.>> GO TO 5.

DTC is detected.>> GO TO 6.

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

INSPECTION AND ADJUSTMENT

ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL

ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Description

INFOID:000000004535128

Each function is reset to the following condition when the battery terminal is disconnected.

Function	Condition	Procedure
Memory (Seat, steering, mirror)	Erased	Perform memory storing
Intelligent Key interlock	Erased	Perform memory storing
Seat synchronization	OFF	—

NOTE:

When disconnecting the battery terminal or replacing the driver seat control unit, DTC, registered items of memory storing, and details of system setting detected in the past are erased. Perform operation after checking the contents.

ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement

INFOID:000000004535129

1.SYSTEM INITIALIZATION

Perform system initialization. Refer to [ADP-10, "SYSTEM INITIALIZATION : Description"](#).

>> GO TO 2.

2.SYSTEM SETTING

Perform system setting. Refer to [ADP-11, "SYSTEM SETTING : Description"](#).

>> GO TO 3.

3.MEMORY STORING

Perform memory storing. Refer to [ADP-10, "MEMORY STORING : Description"](#).

>> END

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description

INFOID:000000004535130

Each function is reset to the following condition when the driver seat control unit is replaced.

Function	Condition	Procedure
Memory (Seat, steering, mirror)	Erased	Perform memory storing
Intelligent Key interlock	Erased	Perform memory storing
Seat synchronization	OFF	—

NOTE:

When disconnecting the battery terminal or replacing the driver seat control unit, DTC, registered items of memory storing, and details of system setting detected in the past are erased. Perform operation after checking the contents.

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement

INFOID:000000004535131

1.SYSTEM INITIALIZATION

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

Perform system initialization. Refer to [ADP-10, "SYSTEM INITIALIZATION : Description"](#).

>> GO TO 2.

2.SYSTEM SETTING

Perform system setting. Refer to [ADP-11, "SYSTEM SETTING : Description"](#).

>> GO TO 3.

3.MEMORY STORING

Perform memory storing. Refer to [ADP-10, "MEMORY STORING : Description"](#).

>> END

SYSTEM INITIALIZATION

SYSTEM INITIALIZATION : Description

INFOID:000000004535132

When disconnecting battery negative terminal or replacing control unit, always perform the system initialization. Otherwise, the backward operation for power walk-in function does not activate normally.

SYSTEM INITIALIZATION : Special Repair Requirement

INFOID:000000004535133

INITIALIZATION PROCEDURE

1. STEP-1

Slide the seat to the front edge.

NOTE:

- STEP-1 is the initialization procedure for power walk-in function.
- If the seat sliding position is already at the front edge, slide the seat rearward once, and then slide it to the front edge again.

>> END

MEMORY STORING

MEMORY STORING : Description

INFOID:000000004636979

Always perform the memory storage when the battery terminal is disconnected or the driver seat control unit is replaced. The memory function and Intelligent Key interlock function will not operate normally if no memory storage is performed.

MEMORY STORING : Special Repair Requirement

INFOID:000000004636980

Memory Storage Procedure

Two positions for the driver seat, steering column and outside mirror can be stored for memory operation by following procedure.

1.STEP 1

Shift AT selector lever to P position (AT model) or applied parking brake (MT model).

>> GO TO 2.

2.STEP 2

Turn ignition switch ON.

>> GO TO 3.

3.STEP 3

Adjust driver seat, steering column and outside mirror position manually.

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

>> GO TO 4.

4.STEP 4

1. Push set switch.

NOTE:

- Memory indicator for which driver seat position is already retained in memory is illuminated for 5 seconds.
- Memory indicator for which driver seat position is not retained in memory is illuminated for 0.5 second.

2. Push the memory switch (1 or 2) for at least 1 second within 5 seconds after pushing the set switch.

NOTE:

If memory is stored in the same memory switch, the previous memory will be deleted.

Do you need linking of Intelligent Key?

YES >> GO TO 6.

NO >> GO TO 5.

5.STEP 5

Confirm the operation of each part with memory operation.

>> END

6.STEP 6

Turn ignition switch OFF (LOCK).

>> GO TO 7.

7.STEP 7

- Press and release set switch. Memory switch indicator is illuminated for 5 seconds. During memory switch indicator is illuminated, press Intelligent Key unlock button while pressing memory switch 1 or 2.

NOTE:

Memory switch indicator lamp blinks for 5 seconds when registration is complete.

>> GO TO 8.

8.STEP 8

Confirm the operation of each part with memory operation and Intelligent Key interlock operation.

>> END

SYSTEM SETTING

SYSTEM SETTING : Description

INFOID:000000004535136

The setting of the automatic driving positioner system can be changed using the set switch.

SYSTEM SETTING : Special Repair Requirement

INFOID:000000004535137

SETTING PROCEDURE

1.STEP-1

Set the vehicle to the following condition.

- Ignition position: ACC
- A/T selector lever: P position (A/T models)
- Parking brake: Applied only (M/T models)

>> GO TO 2.

2.STEP-2

Press set switch and hold for more than 10 seconds, then confirm blinking of the memory switch indicator.

A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O

P

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

- Seat synchronization are ON : Memory switch indicator blink two times.
- Seat synchronization are OFF : Memory switch indicator blink once.

NOTE:

- After memory setting registration, by pushing set switch for approximately 10 seconds, memory switch indicator lamp turns 4 seconds. turns OFF, blinks 1 or 2 times, and then the switching operation is complete. Push and hold set switch during the switching operation.

>> END.

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >


SYSTEM DESCRIPTION

AUTOMATIC DRIVE POSITIONER SYSTEM

AUTOMATIC DRIVE POSITIONER SYSTEM

AUTOMATIC DRIVE POSITIONER SYSTEM : System Diagram

INFOID:000000004535060



JMJIA2436GB

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

AUTOMATIC DRIVE POSITIONER SYSTEM : System Description

INFOID:000000004535061

OUTLINE

The system automatically moves the driver seat, steering column and door mirror position by the driver seat control unit and the automatic drive positioner control unit. The driver seat control unit corresponds with the automatic drive positioner control unit by UART communication.

Function	Description
Manual function	The driving position (seat, steering column and door mirror position) can be adjusted by using the power seat switch, tilt & telescopic switch or door mirror remote control switch.
Seat synchronization function	The positions of the steering column and door mirror are adjusted to the proper position automatically while linking with manual operation [seat sliding, seat lifting (rear) or seat reclining].
Memory function	The seat, steering column and outside mirror move to the stored driving position by pressing seat memory switch (1 or 2).
Power walk-in function	The seat is made to advance when the seat back of driver seat is folded down and press the walk-in switch. The seat is made to retreat to former position when the seat back of driver seat is folded up and press the walk-in switch.
Intelligent Key interlock function	Perform memory operation, exiting operation and entry operation by Intelligent Key unlock operation or driver side door request switch unlock operation.


NOTE:

The lumbar support system and the side support system are controlled independently with no link to the automatic drive positioner system.

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >


AUTOMATIC DRIVE POSITIONER SYSTEM : Component Parts Location INFOID:000000004535062



- | | | |
|--|--|--|
| 1. BCM M118, M119, M122, M123 | 2. Automatic drive positioner control unit M51, M52 | 3. Driver seat control unit B503, B504 |
| 4. Unified meter and A/C amp. M67 | 5. A/T assembly F51 | 6. Tilt & telescopic switch M31 |
| 7. Key slot M22 | 8. Tilt sensor M48 | 9. Telescopic sensor M48 |
| 10. Seat memory switch D5 | 11. Door mirror remote control switch D17 | |
| A. Dash side lower (passenger side) | B. View with instrument driver lower panel removed (Remove 4WAS front control unit with 4WAS models) | C. Backside of seat cushion (driver side) |
| D. Behind cluster lid C | E. A/T assembly (TCM is built in A/T assembly) | F. View with instrument driver lower panel removed |
| G. View with steering column cover lower and upper removed | | |

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >




JMJIA2416ZZ

- | | | |
|---|--|-------------------------------|
| 12. Driver side door switch B16 | 13. A/T shift selector (detention switch) M137 | 14. Parking brake switch B14 |
| 15. Door mirror (driver side) D3 | 16. Telescopic motor M49 | 17. Tilt motor M49 |
| 18. Forward switch B512 | 19. Sliding limit switch B514 | 20. Power walk-in switch B513 |
| 21. Seat belt buckle switch (driver side) B13 | | |

- | | | |
|--|--|--|
| H. View with center console assembly is removed. | I. View with center console assembly is removed. | J. View with instrument driver lower panel is removed. |
| K. View with seat back pad is removed. | L. View with seat cushion pad is removed. | |

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >



- | | | |
|-------------------------------|---|--|
| 22. Reclining motor B523 | 23. Reclining switch
(Power seat switch)
B510 | 24. Sliding, lifting switch
(Power seat switch)
B510 |
| 25. Sliding sensor B526 | 26. Lifting motor (front) B527 | 27. Sliding motor
B525 |
| 28. Lifting motor (rear) B529 | | |
- M. View with seat cushion pad and seat-
back pad are removed.
- N. Backside of seat cushion

AUTOMATIC DRIVE POSITIONER SYSTEM : Component Description

INFOID:000000004535063

CONTROL UNITS

Item	Function
Driver seat control unit	<ul style="list-style-type: none"> Main units of automatic drive positioner system. It is connected to the CAN. It communicates with the automatic drive positioner control unit via UART communication.
Automatic drive positioner control unit	<ul style="list-style-type: none"> It communicates with the driver seat control unit via UART communication. Perform various controls with the instructions of driver seat control unit. Perform the controls of the tilt & telescopic, door mirror and the seat memory switch.
BCM	Transmit the following status to the driver seat control unit via CAN communication. <ul style="list-style-type: none"> Driver door: OPEN/CLOSE Ignition switch position: ACC/ON Door lock: UNLOCK (with Intelligent Key or driver side door request switch operation) Key ID Key switch: Insert/Pull out Intelligent Key Starter: CRANKING/OTHER
Unified meter and A/C amp.	Transmit the vehicle speed signal to the driver seat control unit via CAN communication.
TCM	Transmit the shift position signal (P range) to the driver seat control unit via CAN communication.

INPUT PARTS

Switches

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

Item	Function
Key slot	The key switch is installed to detect the key inserted/removed status.
Driver side door switch	Detect front door (driver side) open/close status.
A/T shift selector (detention switch)	Detect the P range position of A/T selector lever. (A/T models)
Parking break switch	Detect the parking brake status. (M/T models)
Set switch	The registration and system setting can be performed with its operation.
Memory switch 1/2	The registration and operation can be performed with its operation.
Power seat switch	The following switch is installed. <ul style="list-style-type: none"> • Reclining switch • Lifting switch (front) • Lifting switch (rear) • Sliding switch The specific parts can be operated with the operation of each switch.
Power walk-in switch	Perform the power walk-in operation by operating the power walk-in switch.
Sliding limit switch	Detect the front end position of seat sliding during the power walk-in function forward operation.
Seat belt buckle switch	Detect the seat belt fastening/releasing condition.
Forward switch	Detect the folded up/folded down condition of seatback that is the operation condition of power walk-in function.
Tilt & telescopic switch	The following switch is installed. <ul style="list-style-type: none"> • Tilt switch • Telescopic switch The specific parts can be operated with the operation of each switch.
Door mirror remote control switch	The following switch is installed. <ul style="list-style-type: none"> • Mirror switch • Changeover switch The specific parts can be operated with the operation of each switch.

Sensors

Item	Function
Door mirror sensor (driver side/passenger side)	Detect the upward/downward and leftward/rightward position of outside mirror face.
Tilt & telescopic sensor	Detect the upward/downward and forward/backward position of steering column.
Lifting sensor (front)	Detect the upward/downward position of seat lifting (front).
Lifting sensor (rear)	Detect the upward/downward position of seat lifting (rear).
Reclining sensor	Detect the tilt of seatback.
Sliding sensor	Detect the forward/backward position of seat.

OUTPUT PARTS

Item	Function
Door mirror motor (driver side/passenger side)	Move the outside mirror face upward/downward and leftward/rightward.
Tilt & telescopic motor	Move the steering column upward/downward and frontward/rearward.
Lifting motor (front)	Move the seat lifting (front) upward/downward.
Lifting motor (rear)	Move the seat lifting (rear) upward/downward.
Reclining motor	Tilt and raise up the seatback.
Sliding motor	Slide the seat forward/backward.
Memory indicator	Illuminates or blinks according to the registration/operation status.

SLEEP MODE

- The seat control unit adopts the sleep mode to reduce the electric power consumption.

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >


- The sleep mode is activated when all of the following condition are fulfilled.
 - Ignition switch turn OFF (steering LOCK position)
 - No load is applied to the seat control
 - The seat control unit 45seconds timer in not activated
 - Set switch and memory switch (1 and 2) turn OFF

WAKE-UP MODE

- The sleep mode is cancelled when any status change is detected for the followings.
 - CAN communication
 - Power seat switch
 - Set switch and memory switch (1 and 2)
 - Power walk-in switch
 - Door mirror switch
 - Steering column switch

MANUAL FUNCTION

MANUAL FUNCTION : System Diagram



MANUAL FUNCTION : System Description

INFOID:000000004535065

OUTLINE

The driving position (seat, steering column and door mirror position) can be adjusted manually with power seat switch, tilt & telescopic switch and door mirror remote control switch.

OPERATION PROCEDURE

- Turn ignition switch ON.
- Operate power seat switch, tilt & telescopic switch or door mirror remote control switch.
- The driver seat, steering column or door mirror operates according to the operation of each switch.

DETAIL FLOW

Seat

A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O

P

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

Order	Input	Output	Control unit condition
1	Power seat switch (sliding, lifting, reclining)	—	The power seat switch signal is inputted to the driver seat control unit when the power seat switch is operated.
2	—	Motors (sliding, lifting, reclining)	The driver seat control unit outputs signals to each motor according to the power seat switch input signal.

Tilt & Telescopic

Order	Input	Output	Control unit condition
1	Tilt & telescopic switch	—	The tilt & telescopic switch signals are inputted to the automatic drive positioner control unit when the tilt & telescopic switch are operated.
2	—	Motors (Tilt, telescopic)	The automatic drive positioner control unit actuates each motor according to the operation of the tilt & telescopic switch.
3	Sensors (Tilt, telescopic)	—	The automatic drive positioner control unit recognizes any operation limit of each actuator via each sensor and will not operate the actuator anymore at that time.*

*: Tilt does not operate upward when tilt sensor value is less than 1.1 V, tilt does not operate downward when the sensor value is more than 3.9 V. Telescopic does not operate backward when telescopic sensor value is less than 0.5 V, telescopic does not operate forward when the sensor value is more than 4.5 V.

Door Mirror

Order	Input	Output	Control unit condition
1	Door mirror remote control switch	—	The door mirror remote control switch signal is inputted to the automatic drive positioner control unit when the door mirror remote control switch is operated.
2	—	Motors (Door mirror motor)	The automatic drive positioner control unit actuates each motor according to the signal from the door mirror remote control switch.
3	Sensors (Mirror)	—	The automatic drive positioner control unit monitors the input of mirror sensor. It stops the operation if the input reaches the operation limit.

NOTE:


The door mirrors can be operated manually when ignition switch is in either ACC or ON position. The ignition switch signal (ACC/ON) is transmitted from BCM to the driver seat control unit via CAN communication and from the driver seat control unit to the automatic drive positioner control unit via UART communication.

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

MANUAL FUNCTION : Component Parts Location

INFOID:000000004556335




A
B
C
D
E
F
G
H
I
ADP
K
L
M
N
O
P

- | | | |
|--|--|--|
| 1. BCM M118, M119, M122, M123 | 2. Automatic drive positioner control unit M51, M52 | 3. Driver seat control unit B503, B504 |
| 4. Unified meter and A/C amp. M67 | 5. A/T assembly F51 | 6. Tilt & telescopic switch M31 |
| 7. Key slot M22 | 8. Tilt sensor M48 | 9. Telescopic sensor M48 |
| 10. Seat memory switch D5 | 11. Door mirror remote control switch D17 | |
| A. Dash side lower (passenger side) | B. View with instrument driver lower panel removed (Remove 4WAS front control unit with 4WAS models) | C. Backside of seat cushion (driver side) |
| D. Behind cluster lid C | E. A/T assembly (TCM is built in A/T assembly) | F. View with instrument driver lower panel removed |
| G. View with steering column cover lower and upper removed | | |

JMJIA2415ZZ

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >




JMJIA2416ZZ

- | | | |
|---|--|-------------------------------|
| 12. Driver side door switch B16 | 13. A/T shift selector (detention switch) M137 | 14. Parking brake switch B14 |
| 15. Door mirror (driver side) D3 | 16. Telescopic motor M49 | 17. Tilt motor M49 |
| 18. Forward switch B512 | 19. Sliding limit switch B514 | 20. Power walk-in switch B513 |
| 21. Seat belt buckle switch (driver side) B13 | | |

- | | | |
|--|--|--|
| H. View with center console assembly is removed. | I. View with center console assembly is removed. | J. View with instrument driver lower panel is removed. |
| K. View with seat back pad is removed. | L. View with seat cushion pad is removed. | |

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >



22. Reclining motor B523

23. Reclining switch
(Power seat switch)
B510

24. Sliding, lifting switch
(Power seat switch)
B510

25. Sliding sensor B526

26. Lifting motor (front) B527

27. Sliding motor
B525

28. Lifting motor (rear) B529

M. View with seat cushion pad and seat-
back pad are removed. N. Backside of seat cushion

MANUAL FUNCTION : Component Description

INFOID:000000004535067

CONTROL UNITS

Item	Function
Driver seat control unit	<ul style="list-style-type: none"> Operates the specific seat motor with the signal from the power seat switch. Transmits the ignition switch signal (ACC/ON) via UART communication to the automatic drive positioner control unit.
Automatic drive positioner control unit	Operates the specific motor with the signal from tilt & telescopic switch or door mirror remote control switch.
BCM	Recognizes the following status and transmits it to the driver seat control unit via CAN communication. <ul style="list-style-type: none"> Ignition position: ACC/ON

INPUT PARTS

Switches

Item	Function
Power seat switch	The following switch is installed. <ul style="list-style-type: none"> Reclining switch Lifting switch (front) Lifting switch (rear) Sliding switch The specific parts can be operated with the operation of each switch.
Tilt & telescopic switch	The following switch is installed. <ul style="list-style-type: none"> Tilt switch Telescopic switch The specific parts can be operated with the operation of each switch.

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

Item	Function
Forward switch	Detect folded down or folded up of the seat back.
Door mirror remote control switch	The following switch is installed. <ul style="list-style-type: none"> • Mirror switch • Changeover switch The specific parts can be operated with the operation of each switch.

Sensors

Item	Function
Tilt & telescopic sensor	Detect the upward/downward & forward/backward position of steering column.
Door mirror sensor (driver side / passenger side)	Detect the upward/downward and leftward/rightward position of outside mirror face.


OUTPUT PARTS

Item	Function
Door mirror motor (driver side/passenger side)	Move the outside mirror face upward/downward and leftward/rightward.
Tilt & telescopic motor	Move the steering column upward/downward and forward/backward.
Lifting motor (front)	Move the seat lifter (front) upward/downward.
Lifting motor (rear)	Move the seat lifter (rear) upward/downward.
Reclining motor	Tilt and raise up the seatback.
Sliding motor	Slide the seat forward/backward.

SEAT SYNCHRONIZATION FUNCTION

SEAT SYNCHRONIZATION FUNCTION : System Diagram

INFOID:000000004535068



SEAT SYNCHRONIZATION FUNCTION : System Description

INFOID:000000004535069

OUTLINE

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

The steering column position and door mirror position is adjusted to the position automatically according to the direction and distance of seat movement when performing the manual operation of sliding, reclining or lifting (rear). This function saves adjusting the mirror and steering column when adjusting the seat.

NOTE:

This function is set to OFF before delivery. (initial setting)

For the system setting procedure. Refer to [ADP-11. "SYSTEM SETTING : Description"](#).

OPERATION PROCEDURE

1. Turn ignition switch ON.
2. Adjust seat position [sliding, reclining, lifting (rear)].
3. The steering and outside mirror is adjusted automatically.

NOTE:

- The seat synchronization function will not operate if seat adjusting value is more than limit value.

Item	Limit value
Seat sliding	76 mm
Seat reclining	9.1 degrees
Seat lifter (rear)	20 mm

- The seat synchronization function will not operate if the steering column or door mirror moves to the operating end while this function is operating. Perform memory function or drive the vehicle at vehicle speed of 7 km/h or more once to activate this function again.
- If the seat position is uncomfortable after the adjustment, seat position can be adjusted easily by memory operation.

OPERATION CONDITION

Satisfy all of the following items. The seat synchronization function is not performed if these items are not satisfied.

Item	Request status
System setting	ON
Ignition position	ON
Seat back	Folded up
A/T selector lever (A/T models)	P position
Parking break (M/T models)	Applied
Switch inputs <ul style="list-style-type: none"> • Power seat switch • Tilt & telescopic switch • Door mirror remote control switch • Set switch • Memory switch 	OFF (Not operated)

DETAIL FLOW

When performing the sliding, reclining or lifting (rear) operation in manual function, the driver seat control unit performs the seat synchronization function as follows.


Order	Input	Output	Control unit condition
1	Sensors [Sliding, reclining, lifting (rear)]	—	The driver seat control unit judges the direction and distance of seat movement according to the signal input from each seat sensor during manual operation.
2	—	Motors (Tilt, telescopic, outside mirror)	Driver seat control unit requests the operation to position according to the direction and distance of seat movement to the automatic drive positioner control unit via UART communication. The automatic drive positioner control unit operates each motor.
	Sensors (Tilt, telescopic, outside mirror)	—	Driver seat control unit stops the operation of each motor when the value of each sensor that is input to automatic drive positioner control unit via UART communication reaches the target address.

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

SEAT SYNCHRONIZATION FUNCTION : Component Parts Location

INFOID:000000004556336




JMJIA2415ZZ

- | | | |
|--|--|--|
| 1. BCM M118, M119, M122, M123 | 2. Automatic drive positioner control unit M51, M52 | 3. Driver seat control unit B503, B504 |
| 4. Unified meter and A/C amp. M67 | 5. A/T assembly F51 | 6. Tilt & telescopic switch M31 |
| 7. Key slot M22 | 8. Tilt sensor M48 | 9. Telescopic sensor M48 |
| 10. Seat memory switch D5 | 11. Door mirror remote control switch D17 | |
| A. Dash side lower (passenger side) | B. View with instrument driver lower panel removed (Remove 4WAS front control unit with 4WAS models) | C. Backside of seat cushion (driver side) |
| D. Behind cluster lid C | E. A/T assembly (TCM is built in A/T assembly) | F. View with instrument driver lower panel removed |
| G. View with steering column cover lower and upper removed | | |

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >



12. Driver side door switch B16

13. A/T shift selector (detention switch) M137

14. Parking brake switch B14

15. Door mirror (driver side) D3

16. Telescopic motor M49

17. Tilt motor M49

18. Forward switch B512

19. Sliding limit switch B514

20. Power walk-in switch B513

21. Seat belt buckle switch (driver side) B13

H. View with center console assembly is removed.

I. View with center console assembly is removed.

J. View with instrument driver lower panel is removed.

K. View with seat back pad is removed.


L. View with seat cushion pad is removed.

JMJIA2416ZZ

A
B
C
D
E
F
G
H
I
ADP
K
L
M
N
O
P

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >



- | | | |
|-------------------------------|---|--|
| 22. Reclining motor B523 | 23. Reclining switch
(Power seat switch)
B510 | 24. Sliding, lifting switch
(Power seat switch)
B510 |
| 25. Sliding sensor B526 | 26. Lifting motor (front) B527 | 27. Sliding motor
B525 |
| 28. Lifting motor (rear) B529 | | |
- M. View with seat cushion pad and seat-back pad are removed. N. Backside of seat cushion

SEAT SYNCHRONIZATION FUNCTION : Component Description

INFOID:000000004535071

CONTROL UNITS

Item	Function
Driver seat control unit	Operates the specific seat motor with the signal from the power seat switch.
Automatic drive positioner control unit	Operates the steering motor and door mirror with the signal from the driver seat control unit.

INPUT PARTS

Switches

Item	Function
Power seat switch	The following switch is installed. <ul style="list-style-type: none"> • Reclining switch • Lifting switch (front) • Lifting switch (rear) • Sliding switch The specific parts can be operated with the operation of each switch.
Forward switch	Detect folded down or folded up of the seat back.

Sensors

Item	Function
Door mirror sensor (driver side/passenger side)	Detect the upward/downward and leftward/rightward position of outside mirror face.
Tilt & telescopic sensor	Detect the upward/downward and forward/backward position of steering column.
Lifting sensor (rear)	Detect the upward/downward position of seat lifter (rear).

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

Item	Function
Reclining sensor	Detect the tilt of seatback.
Sliding sensor	Detect the forward/rearward position of seat.


OUTPUT PARTS

Item	Function
Door mirror motor (driver side/passenger side)	Move the outside mirror face upward/downward and leftward/rightward.
Tilt & telescopic motor	Move the steering column upward/downward and forward/backward.
Lifting motor (rear)	Move the seat lifter (rear) upward/downward.
Reclining motor	Tilt and raise up the seatback.
Sliding motor	Slide the seat forward/backward.

MEMORY FUNCTION

MEMORY FUNCTION : System Diagram

INFOID:000000004535072



MEMORY FUNCTION : System Description

INFOID:000000004535073

OUTLINE

The driver seat control unit can store the optimum driving positions (seat, steering column and door mirror position) for 2 people. If the front seat position is changed, one-touch (pressing desired memory switch for more than 0.5 second) operation allows changing to the other driving position.

NOTE:

Further information for the memory storing procedure. Refer to [ADP-10. "MEMORY STORING : Description"](#).

OPERATION PROCEDURE

1. Turn ignition switch ON
2. Press desired memory switch for more than 0.5 second.
3. Driver seat, steering and door mirror will move to the memorized position.

OPERATION CONDITION

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

Satisfy all of the following items. The memory function is not performed if these items are not satisfied.

Item	Request status
Ignition position	ON
Seat back	Folded up
A/T selector lever (A/T models)	P position
Parking break (M/T models)	Applied
Switch inputs <ul style="list-style-type: none"> • Power seat switch • Tilt & telescopic switch • Door mirror control switch • Set switch • Memory switch 	OFF (Not operated)

DETAIL FLOW


Order	Input	Output	Control unit condition
1	Memory switch	—	The memory switch signal is inputted to the automatic drive positioner control unit when memory switch 1 or 2 is operated. Memory switch signal is output to driver seat control unit via UART communication.
2	—	Motors (Seat, steering, door mirror)	Driver seat control unit operates each motor of seat when it recognizes the memory switch pressed for 0.5 second or more and requests each motor operation to automatic drive positioner control unit via UART communication. The automatic drive positioner control unit operates each motor.
		Memory switch Indica- tor	Driver seat control unit requests the flashing of memory indicator to automatic drive positioner control unit via UART communication while either of the motors is operating. The automatic drive positioner control unit illuminates the memory indicator.
3	Sensors (Seat, steering, door mirror)	—	Driver seat control unit judges the operating seat position with each seat sensor input. The positions of the steering column and outside mirror are monitored with each sensor signal that is input from auto drive positioner control unit via UART communication. Driver seat control unit stops the operation of each motor when each part reaches the recorded address.
4	—	Memory switch Indica- tor	Driver seat control unit requests the illumination of memory indicator to auto drive positioner control unit via UART communication after all motors stop. The auto driving positioner control unit illuminates the memory indicator for 5 seconds.

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

MEMORY FUNCTION : Component Parts Location

INFOID:000000004556337



- | | | |
|--|--|--|
| 1. BCM M118, M119, M122, M123 | 2. Automatic drive positioner control unit M51, M52 | 3. Driver seat control unit B503, B504 |
| 4. Unified meter and A/C amp. M67 | 5. A/T assembly F51 | 6. Tilt & telescopic switch M31 |
| 7. Key slot M22 | 8. Tilt sensor M48 | 9. Telescopic sensor M48 |
| 10. Seat memory switch D5 | 11. Door mirror remote control switch D17 | |
| A. Dash side lower (passenger side) | B. View with instrument driver lower panel removed (Remove 4WAS front control unit with 4WAS models) | C. Backside of seat cushion (driver side) |
| D. Behind cluster lid C | E. A/T assembly (TCM is built in A/T assembly) | F. View with instrument driver lower panel removed |
| G. View with steering column cover lower and upper removed | | |


A
B
C
D
E
F
G
H
I
M
K
L
N
O
P

ADP

JMJIA2415ZZ

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >




JMJIA2416ZZ

- | | | |
|---|--|-------------------------------|
| 12. Driver side door switch B16 | 13. A/T shift selector (detention switch) M137 | 14. Parking brake switch B14 |
| 15. Door mirror (driver side) D3 | 16. Telescopic motor M49 | 17. Tilt motor M49 |
| 18. Forward switch B512 | 19. Sliding limit switch B514 | 20. Power walk-in switch B513 |
| 21. Seat belt buckle switch (driver side) B13 | | |

- | | | |
|--|--|--|
| H. View with center console assembly is removed. | I. View with center console assembly is removed. | J. View with instrument driver lower panel is removed. |
| K. View with seat back pad is removed. | L. View with seat cushion pad is removed. | |

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >



- | | | |
|-------------------------------|---|--|
| 22. Reclining motor B523 | 23. Reclining switch
(Power seat switch)
B510 | 24. Sliding, lifting switch
(Power seat switch)
B510 |
| 25. Sliding sensor B526 | 26. Lifting motor (front) B527 | 27. Sliding motor
B525 |
| 28. Lifting motor (rear) B529 | | |
- M. View with seat cushion pad and seat-
back pad are removed.
- N. Backside of seat cushion

MEMORY FUNCTION : Component Description

INFOID:000000004535075

CONTROL UNITS

Item	Function
Driver seat control unit	<ul style="list-style-type: none"> The address of each part is recorded. Operates each motor of seat to the registered position. Requests the operations of steering column and door mirror to automatic drive positioner control unit
Automatic drive positioner control unit	Operates the steering column and door mirror with the signal from the driver seat control.

INPUT PARTS

Switches

Item	Function
Memory switch 1/2	The registration and memory function can be performed with its operation.
Forward switch	Detect folded down or folded up of the seat back.

Sensors

Item	Function
Door mirror sensor (driver side/passenger side)	Detect the upward/downward and leftward/rightward position of outside mirror face.
Tilt & telescopic sensor	Detect the upward/downward and forward/backward position of steering column.
Lifting sensor (front)	Detect the upward/downward position of seat lifting (front).
Lifting sensor (rear)	Detect the upward/downward position of seat lifting (rear).

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

Item	Function
Reclining sensor	Detect the tilt of seatback.
Sliding sensor	Detect the forward/backward position of seat.


OUTPUT PARTS

Item	Function
Door mirror motor (driver side/passenger side)	Move the outside mirror face upward/downward and leftward/rightward.
Tilt & telescopic motor	Move the steering column upward/downward and forward/backward.
Lifting motor (front)	Move the seat lifter (front) upward/downward.
Lifting motor (rear)	Move the seat lifter (rear) upward/downward.
Reclining motor	Tilt and raise up the seatback.
Sliding motor	Slide the seat forward/backward.
Memory indicator	Illuminates or blinks according to the registration/operation status.

INTELLIGENT KEY INTERLOCK FUNCTION

INTELLIGENT KEY INTERLOCK FUNCTION : System Diagram

INFOID:000000004535076



INTELLIGENT KEY INTERLOCK FUNCTION : System Description

INFOID:000000004535077

OUTLINE

When unlocking doors by using Intelligent Key or driver side door request switch, the system performs memory operation.

OPERATION PROCEDURE

1. Unlock doors by using Intelligent Key or driver side door request switch.
2. The system performs memory operation, and then performs exit assist operation.

NOTE:

If the seat position is in memorized position before unlocking doors, memory operation does not perform.

NOTE:

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

Further information for Intelligent Key interlock function. Refer to [ADP-10, "MEMORY STORING : Description"](#).

OPERATION CONDITION

Satisfy all of the following items. The Intelligent Key interlock function is performed if these items are satisfied.

Item	Request status
Key switch	OFF (Key is removed.)
Ignition position	LOCK
Seat back	Folded up
A/T selector lever (A/T models)	P position
Parking break (M/T models)	Applied
Switch inputs <ul style="list-style-type: none"> • Power seat switch • Tilt & telescopic switch • Door mirror control switch • Set switch • Memory switch 	OFF (Not operated)

DETAIL FLOW

Order	Input	Output	Control unit condition
1	<ul style="list-style-type: none"> • Door unlock signal (CAN) • Key ID signal (CAN) 	—	Driver seat control unit receives the door unlock signal and the key ID signal from BCM when unlocking the door with Intelligent Key or driver side door request switch.
2	—	—	Driver seat control unit performs the memory function.


A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

INTELLIGENT KEY INTERLOCK FUNCTION : Component Parts Location INFOID:000000004556338




JMJIA2415ZZ

- | | | |
|--|--|--|
| 1. BCM M118, M119, M122, M123 | 2. Automatic drive positioner control unit M51, M52 | 3. Driver seat control unit B503, B504 |
| 4. Unified meter and A/C amp. M67 | 5. A/T assembly F51 | 6. Tilt & telescopic switch M31 |
| 7. Key slot M22 | 8. Tilt sensor M48 | 9. Telescopic sensor M48 |
| 10. Seat memory switch D5 | 11. Door mirror remote control switch D17 | |
| A. Dash side lower (passenger side) | B. View with instrument driver lower panel removed (Remove 4WAS front control unit with 4WAS models) | C. Backside of seat cushion (driver side) |
| D. Behind cluster lid C | E. A/T assembly (TCM is built in A/T assembly) | F. View with instrument driver lower panel removed |
| G. View with steering column cover lower and upper removed | | |

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >



12. Driver side door switch B16

15. Door mirror (driver side)
D3

18. Forward switch B512

21. Seat belt buckle switch (driver side)
B13

H. View with center console assembly
is removed.

K. View with seat back pad is removed.

13. A/T shift selector (detention switch)
M137

16. Telescopic motor M49

19. Sliding limit switch B514

I. View with center console assembly
is removed.

L. View with seat cushion pad is re-
moved.

14. Parking brake switch B14

17. Tilt motor M49

20. Power walk-in switch B513


J. View with instrument driver lower
panel is removed.

JMJIA2416ZZ

A
B
C
D
E
F
G
H
I
ADP
K
L
M
N
O
P

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >



- | | | |
|-------------------------------|---|--|
| 22. Reclining motor B523 | 23. Reclining switch
(Power seat switch)
B510 | 24. Sliding, lifting switch
(Power seat switch)
B510 |
| 25. Sliding sensor B526 | 26. Lifting motor (front) B527 | 27. Sliding motor
B525 |
| 28. Lifting motor (rear) B529 | | |

M. View with seat cushion pad and seat back pad are removed. N. Backside of seat cushion

INTELLIGENT KEY INTERLOCK FUNCTION : Component Description

INFOID:000000004535079

CONTROL UNITS

Item	Function
Driver seat control unit	It performs memory function after receiving the door unlock signal from BCM.
Automatic drive positioner control unit	Operates the steering column and door mirror with the instructions from the driver seat control unit.
BCM	Recognizes the following status and transmits it to the driver seat control unit via CAN communication. <ul style="list-style-type: none"> • Door lock: UNLOCK (with Intelligent Key or driver side door request switch)


POWER WALK-IN FUNCTION

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

POWER WALK-IN FUNCTION : System Diagram

INFOID:000000004535080



POWER WALK-IN FUNCTION : System Description

INFOID:000000004535081

OUTLINE

Slide the driver seat automatically with the power walk-in switch operation so as to easily facilitate the entry to the rear seat.

Forward Operation

Slide (forward) the driver seat to the front end position (sliding limit switch: ON) by operating the power walk-in switch when the seatback is folded down.

The forward operation is stopped by folding the seatback (forward switch: OFF) during the forward operation.

Backward Operation

The seat back is folded up after performing the forward operation of power walk-in function. Slide (backward) it to the position before performing the forward operation by operating the power walk-in switch.

If the manual operation, memory operation, and Intelligent Key interlock operation are performed after performing the forward operation, do not perform the backward operation.

OPERATION PROCEDURE

Forward Operation

1. Open driver door.
2. Pull the walk-in lever on the upper part of seatback, and then the seatback is folded down.
3. Press the power walk-in switch.
4. Slide the seat to the front end position.

Backward Operation

1. Open driver door.
2. Fold up the seatback after performing the forward operation.
3. Press the power walk-in switch.
4. Slide the seat to the previous position before the forward operation was performed.

OPERATION CONDITION

Perform the power walk-in function when the following conditions are satisfied.

A
B
C
D
E
F
G
H

I

ADP

K

L

M

N

O

P

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

Forward Operation

Item	Request status
Driver side door	Open
Driver side seat belt	Not fastened
Power seat switch (sliding)	Not operated
Vehicle speed	0 km/h
Seat position (sliding)	Other than front end
Seat back	Folded down

Backward Operation

Item	Request status
Initialize	Done
Driver side seat belt	Not fastened
Switch inputs <ul style="list-style-type: none"> • Power seat switch (sliding) • Set switch • Memory switch 	Not operated
Vehicle speed	0 km/h
Seat position (sliding)	The seat sliding position will not move after performing the forward operation.
Seat back	Folded up

DETAIL FLOW

Forward Operation

Order	Inputs	Outputs	Control unit condition
1	Forward switch	—	Driver seat control unit detects that the seatback is folded down by the signal from the forward switch.
2	Power walk-in switch	—	The operation signal is inputted to the driver seat control unit when the power walk-in switch is operated.
3	—	Sliding motor (forward)	Driver seat control unit operates the seat sliding motor forward when it detects that the power walk-in switch is operated.
4	Sliding limit switch	—	Driver seat control unit stops the seat sliding motor when it detects that the seat sliding reaches the front end position by the sliding limit switch.

Backward Operation


Order	Inputs	Outputs	Control unit condition
1	Forward switch	—	Driver seat control unit detects that the seatback is folded up by the signal from the forward switch.
2	Power walk-in switch	—	The operation signal is inputted to the driver seat control unit when the power walk-in switch is operated.
3	—	Sliding motor (backward)	Driver seat control unit operates the sliding motor backward when it detects that the power walk-in switch is operated.
4	Sliding sensor	—	Driver seat control unit stops the seat sliding motor when the seat sliding position reaches the position before performing the forward operation by the signal from sliding sensor.

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

POWER WALK-IN FUNCTION : Component Parts Location


INFOID:000000004556339



- | | | |
|--|--|--|
| 1. BCM M118, M119, M122, M123 | 2. Automatic drive positioner control unit M51, M52 | 3. Driver seat control unit B503, B504 |
| 4. Unified meter and A/C amp. M67 | 5. A/T assembly F51 | 6. Tilt & telescopic switch M31 |
| 7. Key slot M22 | 8. Tilt sensor M48 | 9. Telescopic sensor M48 |
| 10. Seat memory switch D5 | 11. Door mirror remote control switch D17 | |
| A. Dash side lower (passenger side) | B. View with instrument driver lower panel removed (Remove 4WAS front control unit with 4WAS models) | C. Backside of seat cushion (driver side) |
| D. Behind cluster lid C | E. A/T assembly (TCM is built in A/T assembly) | F. View with instrument driver lower panel removed |
| G. View with steering column cover lower and upper removed | | |

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >




JMJIA2416ZZ

- | | | |
|---|--|-------------------------------|
| 12. Driver side door switch B16 | 13. A/T shift selector (detention switch) M137 | 14. Parking brake switch B14 |
| 15. Door mirror (driver side) D3 | 16. Telescopic motor M49 | 17. Tilt motor M49 |
| 18. Forward switch B512 | 19. Sliding limit switch B514 | 20. Power walk-in switch B513 |
| 21. Seat belt buckle switch (driver side) B13 | | |

- | | | |
|--|--|--|
| H. View with center console assembly is removed. | I. View with center console assembly is removed. | J. View with instrument driver lower panel is removed. |
| K. View with seat back pad is removed. | L. View with seat cushion pad is removed. | |

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >



- | | | |
|-------------------------------|---|--|
| 22. Reclining motor B523 | 23. Reclining switch
(Power seat switch)
B510 | 24. Sliding, lifting switch
(Power seat switch)
B510 |
| 25. Sliding sensor B526 | 26. Lifting motor (front) B527 | 27. Sliding motor
B525 |
| 28. Lifting motor (rear) B529 | | |
- M. View with seat cushion pad and seat-back pad are removed. N. Backside of seat cushion

POWER WALK-IN FUNCTION : Component Description

INFOID:000000004535083

CONTROL UNITS

Item	Function
Driver seat control unit	<ul style="list-style-type: none"> Main units of automatic drive positioner system It is connected to the CAN. It communicates with the automatic drive positioner control unit via UART communication.
BCM	Transmit the following status to the driver seat control unit via CAN communication. <ul style="list-style-type: none"> Driver door: OPEN/CLOSE Starter: CRANKING/OTHER
Unified meter and A/C amp.	Transmit the vehicle speed signal to the driver seat control unit via CAN communication.

INPUT PARTS

Switches

Item	Function
Front door switch (driver side)	Detect front door (driver side) open/close status.
Power walk-in switch	Perform the power walk-in operation by operating the power walk-in switch.
Sliding limit switch	Detect the front end position of seat sliding during the power walk-in function forward operation.
Seat belt buckle switch	Detect the seat belt fastening/releasing condition.
Forward switch	Detect the folded up/folded down condition of seatback that is the operation condition of power walk-in function.

Sensors

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

Item	Function
Sliding sensor	Detect the forward/backward position of seat.

OUTPUT PARTS

Item	Function
Sliding motor	Slide the seat forward/backward.

DIAGNOSIS SYSTEM (DRIVER SEAT C/U)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (DRIVER SEAT C/U)

Diagnosis Description

INFOID:000000004535084

The automatic drive positioner system can be checked and diagnosed for component operation using CONSULT-III.

DIAGNOSTIC MODE

Diagnostic mode	Description
SELF-DIAG RESULTS	Performs self-diagnosis for the auto drive positioner system and displays the results.
DATA MONITOR	Displays input signals transmitted from various switches and sensors to driver seat control unit in real time.
CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.
ACTIVE TEST	Drives each output device.
ECU PART NUMBER	Displays part numbers of driver seat control unit.

CONSULT-III Function

INFOID:000000004535085

SELF DIAGNOSTIC RESULTS

Refer to [ADP-162, "DTC Index"](#).

DATA MONITOR

Monitor Item	Unit	Main Signals	Selection From Menu	Contents
SET SW	"ON/OFF"	×	×	ON/OFF status judged from the setting switch signal.
MEMORY SW 1	"ON/OFF"	×	×	ON/OFF status judged from the seat memory switch 1 signal.
MEMORY SW 2	"ON/OFF"	×	×	ON/OFF status judged from the seat memory switch 2 signal.
SLIDE SW-FR*3	"ON/OFF"	×	×	ON/OFF status judged from the sliding switch (forward) signal.
SLIDE SW-RR*3	"ON/OFF"	×	×	ON/OFF status judged from the sliding switch (backward) signal.
RECLN SW-FR*3	"ON/OFF"	×	×	ON/OFF status judged from the reclining switch (forward) signal.
RECLN SW-RR*3	"ON/OFF"	×	×	ON/OFF status judged from the reclining switch (backward) signal.
LIFT FR SW-UP*3	"ON/OFF"	×	×	ON/OFF status judged from the lifting switch front (upward) signal.
LIFT FR SW-DN*3	"ON/OFF"	×	×	ON/OFF status judged from the lifting switch front (downward) signal.
LIFT RR SW-UP*3	"ON/OFF"	×	×	ON/OFF status judged from the lifting switch rear (upward) signal.
LIFT RR SW-DN*3	"ON/OFF"	×	×	ON/OFF status judged from the lifting switch rear (downward) signal.
MIR CON SW-UP	"ON/OFF"	×	×	ON/OFF status judged from the mirror switch (upward) signal.
MIR CON SW-DN	"ON/OFF"	×	×	ON/OFF status judged from the mirror switch (downward) signal.
MIR CON SW-RH	"ON/OFF"	×	×	ON/OFF status judged from the door mirror remote control switch (passenger side) signal.
MIR CON SW-LH	"ON/OFF"	×	×	ON/OFF status judged from the door mirror remote control switch (driver side) signal.
MIR CHNG SW-R	"ON/OFF"	×	×	ON/OFF status judged from the door mirror remote control switch (switching to right) signal.
MIR CHNG SW-L	"ON/OFF"	×	×	ON/OFF status judged from the door mirror remote control switch (switching to left) signal.

DIAGNOSIS SYSTEM (DRIVER SEAT C/U)

< SYSTEM DESCRIPTION >

Monitor Item	Unit	Main Signals	Selection From Menu	Contents
TILT SW-UP	"ON/OFF"	×	×	ON/OFF status judged from the tilt switch (upward) signal.
TILT SW-DOWN	"ON/OFF"	×	×	ON/OFF status judged from the tilt switch (downward) signal.
TELESCO SW-FR	"ON/OFF"	×	×	ON/OFF status judged from the telescoping switch (forward) signal.
TELESCO SW-RR	"ON/OFF"	×	×	ON/OFF status judged from the telescoping switch (backward) signal.
FORWARD SW*3	"ON/OFF"	×	×	ON/OFF status judged from the forward switch signal.
WALK-IN SW*3	"ON/OFF"	×	×	ON/OFF status judged from the power walk-in switch signal.
FWD LIMIT SW*3	"ON/OFF"	×	×	ON/OFF status judged from the sliding limit switch signal.
SEAT BELT SW*3	"ON/OFF"	×	×	ON/OFF status judged from the seat belt buckle switch signal.
DETENT SW*1	"ON/OFF"	×	×	The selector lever position "OFF (P position) / ON (other than the P position)" judged from the detention switch signal.
PARK BRAKE SW*2	"ON/OFF"	×	×	The parking brake condition "ON (applied) / OFF (release)" judged from the parking brake switch signal.
STARTER SW	"ON/OFF"	×	×	Ignition key switch ON (START, ON) /OFF (ACC, OFF) status judged from the ignition switch signal.
SLIDE PULSE*3	–	–	×	Value (32768) when battery connections are standard. If it moves backward, the value increases. If it moves forward, the value decreases.
RECLN PULS*4	–	–	×	Value (32768) when battery connections are standard. If it moves backward, the value increases. If it moves forward, the value decreases.
LIFT FR PULSE*4	–	–	×	Value (32768) when battery connections are standard. If it moves DOWN, the value increases. If it moves UP, the value decreases.
LIFT RR PULSE*4	–	–	×	Value (32768) when battery connections are standard. If it moves DOWN, the value increases. If it moves UP, the value decreases.
MIR/SEN RH U–D	"V"	–	×	Voltage input from door mirror sensor (passenger side) upward/downward is displayed.
MIR/SEN RH R–L	"V"	–	×	Voltage input from door mirror sensor (passenger side) leftward/rightward is displayed.
MIR/SEN LH U–D	"V"	–	×	Voltage input from door mirror sensor (driver side) upward/downward is displayed.
MIR/SEN LH R–L	"V"	–	×	Voltage input from door mirror sensor (driver side) leftward/rightward is displayed.
TILT SEN	"V"	–	×	Voltage input from tilt sensor upward/downward is displayed.
TELESCO SEN	"V"	–	×	Voltage input from telescopic sensor forward/backward is displayed.

*1: M/T models display all item except this item.

*2: A/T models display all item except this item.

*3: Only this item is displayed for driver seat without automatic drive positioner system.

*4: It is displayed but is not operated for models with driver seat without automatic driver positioner system.

ACTIVE TEST

CAUTION:

When driving vehicle, never perform active test.

Test item	Description
SEAT SLIDE	Activates/deactivates the sliding motor.
SEAT RECLINING	Activates/deactivates the reclining motor.

DIAGNOSIS SYSTEM (DRIVER SEAT C/U)

< SYSTEM DESCRIPTION >

Test item	Description
SEAT LIFTER FR	Activates/deactivates the lifting motor (front).
SEAT LIFTER RR	Activates/deactivates the lifting motor (rear).
TILT MOTOR*	Activates/deactivates the tilt motor.
TELESCO MOTOR*	Activates/deactivates the telescopic motor.
MIRROR MOTOR RH*	Activates/deactivates the mirror motor (passenger side).
MIRROR MOTOR LH*	Activates/deactivates the mirror motor (driver side).
MEMORY SW INDCTR*	Turns ON/OFF the memory indicator.

*: Does not display without automatic driver position system.

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

U1000 CAN COMM CIRCUIT

Description

INFOID:000000004534910

CAN (Controller Area Network) is a serial communication line for real time applications. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicle is equipped with many electronic control unit, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H-line, CAN L-line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

DTC Logic

INFOID:000000004534911

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
U1000	CAN COMM CIRCUIT	<ul style="list-style-type: none">• Driver seat control unit cannot communicate to other control units.• Driver seat control unit cannot communicate for more than the specified time.	Harness or connectors (CAN communication line is open or shorted)

DTC CONFIRMATION PROCEDURE

1.STEP 1

1. Turn ignition switch ON and wait for 3 seconds or more.
2. Check "Self diagnostic result" using CONSULT-III.

Is the DTC detected?

- YES >> Perform diagnosis procedure. Refer to [ADP-48, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000004534912

Refer to [LAN-18, "Trouble Diagnosis Flow Chart"](#).

Special Repair Requirement

INFOID:000000004534913

Refer to [ADP-10, "SYSTEM INITIALIZATION : Description"](#).

B2112 SLIDING MOTOR

< DTC/CIRCUIT DIAGNOSIS >

B2112 SLIDING MOTOR

Description

INFOID:000000004534914

- The seat sliding motor is installed to the seat cushion frame.
- The seat sliding motor is installed with the driver seat control unit.
- Slides the seat forward/ rearward by changing the rotation direction of sliding motor.

DTC Logic

INFOID:000000004534915

DTC DETECTION LOGIC

NOTE:

First perform diagnosis for B2126 if B2126 is detected.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2112	SEAT SLIDE	The driver seat control unit detects the output of sliding motor output terminal for 0.1 second or more even if the sliding switch is not input.	<ul style="list-style-type: none">• Driver seat control unit• Slide motor harness is power shorted

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check "Self diagnostic result" using CONSULT-III.

Is the DTC detected?

- YES >> Perform diagnosis procedure. Refer to [ADP-49, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000004534916

1. CHECK SLIDING MOTOR CIRCUIT (POWER SHORT)

ADP

1. Turn ignition switch OFF.
2. Disconnect sliding motor and driver seat control unit connector.
3. Check voltage between sliding motor harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Sliding motor			
Connector	Terminals	Ground	0
B525	35		
	42		

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace harness.

2. CHECK DRIVER SEAT CONTROL UNIT OUTPUT SIGNAL

1. Connect driver seat control unit connector.
2. Check voltage between driver seat control unit harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Driver seat control unit			
Connector	Terminals	Ground	0
B525	35		
	42		

Is the inspection result normal?

B2112 SLIDING MOTOR

< DTC/CIRCUIT DIAGNOSIS >

YES >> GO TO 3.

NO >> Replace driver seat control unit. Refer to [ADP-230, "Removal and Installation"](#)

3.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

B2113 RECLINING MOTOR

< DTC/CIRCUIT DIAGNOSIS >

B2113 RECLINING MOTOR

Description

INFOID:000000004534917

- The seat reclining motor is installed to the seatback frame.
- The seat reclining motor is activated with the driver seat control unit.
- Tilts the seatback frontward/rearward by changing the rotation direction of reclining motor.

DTC Logic

INFOID:000000004534918

DTC DETECTION LOGIC

NOTE:

First perform diagnosis for B2126 if B2126 is detected.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2113	SEAT RECLINING	The driver seat control unit detects the output of reclining motor output terminal for 0.1 second or more even if the reclining switch is not input.	<ul style="list-style-type: none">• Driver seat control unit• Reclining motor harness is power shorted

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check "Self diagnostic result" using CONSULT-III.

Is the DTC detected?

- YES >> Perform diagnosis procedure. Refer to [ADP-51, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000004534919

1. CHECK RECLINING MOTOR CIRCUIT (POWER SHORT)

1. Turn ignition switch OFF.
2. Disconnect reclining motor and driver seat control unit connector.
3. Check voltage between reclining motor harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Reclining motor			
Connector	Terminals	Ground	0
B523	15		
	71		

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace harness.

2. CHECK DRIVER SEAT CONTROL UNIT OUTPUT SIGNAL

1. Connect driver seat control unit connector.
2. Check voltage between driver seat control unit harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Driver seat control unit			
Connector	Terminals	Ground	0
B523	15		
	71		

Is the inspection result normal?

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

B2113 RECLINING MOTOR

< DTC/CIRCUIT DIAGNOSIS >

YES >> GO TO 3.

NO >> Replace driver seat control unit. Refer to [ADP-230, "Removal and Installation"](#).

3.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

B2118 TILT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

B2118 TILT SENSOR

Description

INFOID:000000004534920

- The tilt sensor is installed to the steering column assembly.
- The resistance of tilt sensor is changed according to the up/down position of steering column.
- The terminal voltage of automatic drive positioner control unit will be changed according to a change of tilt sensor resistance. Automatic drive positioner control unit calculates the tilt position from the voltage.

DTC Logic

INFOID:000000004534921

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2118	TILT SENSOR	The input voltage of tilt sensor is less than 0.1V or more than 4.9V.	<ul style="list-style-type: none"> • Harness and connectors (Tilt sensor circuit is opened/shorted, tilt sensor power supply circuit is opened/shorted.) • Tilt sensor

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check "Self diagnostic result" using CONSULT-III.

Is the DTC detected?

- YES >> Perform diagnosis procedure. Refer to [ADP-53. "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000004534922

1.CHECK TILT SENSOR SIGNAL

1. Turn ignition switch ON.
2. Select "TILT SEN" in the "Data monitor" mode using CONSULT-III.
3. Check tilt sensor signal under the following condition.

Monitor item	Condition	Value
TILT SEN	Tilt position	Change between 1.1 V (close to top) 3.9 V (close to bottom)

Is the value normal?

- YES >> GO TO 6.
 NO >> GO TO 2.

2.CHECK TILT SENSOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit and tilt & telescopic sensor connector.
3. Check continuity between automatic drive positioner control unit harness connector and tilt & telescopic sensor harness connector.

Automatic drive positioner control unit		Tilt & telescopic sensor		Continuity
Connector	Terminal	Connector	Terminal	
M51	7	M48	3	Existed

4. Check continuity between automatic drive positioner control unit harness connector and ground.

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

B2118 TILT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M51	7		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK TILT SENSOR POWER SUPPLY

1. Connect automatic drive positioner control unit connector.
2. Turn ignition switch ON.
3. Check voltage between tilt & telescopic sensor harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Tilt & telescopic sensor			
Connector	Terminal		
M48	1	Ground	5

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

4. CHECK TILT SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and tilt & telescopic sensor harness connector.

Automatic drive positioner control unit		Tilt & telescopic sensor		Continuity
Connector	Terminal	Connector	Terminal	
M52	33	M48	1	Existed

4. Check continuity between automatic drive positioner control unit harness connector and ground.

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M52	33		

Is the inspection result normal?

YES >> Replace automatic drive positioner control unit. Refer to [ADP-231, "Removal and Installation"](#).

NO >> Repair or replace harness.

5. CHECK TILT SENSOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and tilt & telescopic sensor harness connector.

Automatic drive positioner control unit		Tilt & telescopic sensor		Continuity
Connector	Terminal	Connector	Terminal	
M52	41	M48	4	Existed

Is the inspection result normal?

YES >> Replace tilt & telescopic sensor.

NO >> Repair or replace harness.

6. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

B2118 TILT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

>> INSPECTION END

A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O

P

B2119 TELESCOPIC SENSOR

< DTC/CIRCUIT DIAGNOSIS >

B2119 TELESCOPIC SENSOR

Description

INFOID:000000004534923

- The telescopic sensor is installed to the steering column assembly.
- The resistance of telescopic sensor is changed according to the forward/backward position of steering column.
- The terminal voltage of automatic drive positioner control unit will be changed according to a change of telescopic sensor resistance. Automatic drive positioner control unit calculates the telescopic position from the voltage.

DTC Logic

INFOID:000000004534924

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2119	TELESCOPIC SENSOR	The input voltage of telescopic sensor is less than 0.1V or more than 4.9V.	<ul style="list-style-type: none">• Harness and connectors (Telescopic sensor circuit is opened/shorted, telescopic sensor power supply circuit is opened/shorted.)• Telescopic sensor

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check "Self diagnostic result" using CONSULT-III.

Is the DTC is detected?

- YES >> Perform diagnosis procedure. Refer to [ADP-56. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000004534925

1. CHECK TELESCOPIC SENSOR SIGNAL

1. Turn ignition switch ON.
2. Select "TELESCO SEN" in the "Data monitor" mode using CONSULT-III.
3. Check the tilt sensor signal under the following condition.

Monitor item	Condition	Value
TELESCO SEN	Telescopic position	Change between 0.5 V (close to top) 4.5 V (close to bottom)

Is the valve normal?

- YES >> GO TO 6.
NO >> GO TO 2.

2. CHECK TELESCOPIC SENSOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit and tilt & telescopic sensor connector.
3. Check continuity between automatic drive positioner control unit harness connector and tilt & telescopic sensor harness connector.

Automatic drive positioner control unit		Tilt & telescopic sensor		Continuity
Connector	Terminal	Connector	Terminal	
M51	23	M48	2	Existed

4. Check continuity between automatic drive positioner control unit harness connector and ground.

B2119 TELESCOPIC SENSOR

< DTC/CIRCUIT DIAGNOSIS >

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M51	23		Not existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3.CHECK TELESCOPIC SENSOR POWER SUPPLY

1. Connect automatic drive positioner control unit connector.
2. Turn ignition switch ON.
3. Check voltage between tilt & telescopic sensor harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Tilt & telescopic sensor			
Connector	Terminal		
M48	1	Ground	5

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

4.CHECK TELESCOPIC SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and tilt & telescopic sensor harness connector.

Automatic drive positioner control unit		Tilt & telescopic sensor		Continuity
Connector	Terminal	Connector	Terminal	
M52	33	M48	1	Existed

4. Check continuity between automatic drive positioner control unit harness connector and ground.

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M52	33		Not existed

Is the inspection result normal?

YES >> Replace automatic drive positioner control unit. Refer to [ADP-231, "Removal and Installation"](#).

NO >> Repair or replace harness.

5.CHECK TELESCOPIC SENSOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and tilt & telescopic sensor harness connector.

Automatic drive positioner control unit		Tilt & telescopic sensor		Continuity
Connector	Terminal	Connector	Terminal	
M52	41	M48	4	Existed

Is the inspection result normal?

YES >> Replace tilt & telescopic sensor.

NO >> Repair or replace harness.

6.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

B2119 TELESCOPIC SENSOR

< DTC/CIRCUIT DIAGNOSIS >

>> INSPECTION END

B2126 DETENT SW

< DTC/CIRCUIT DIAGNOSIS >

B2126 DETENT SW

Description

INFOID:000000004534926

- Detention switch is installed on A/T shift selector. It is turned OFF when the A/T selector lever is in P position.
- The driver seat control unit judges that the A/T selector lever is in P position if continuity does not exist in this circuit.

DTC Logic

INFOID:000000004534927

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2126	DETENT SW	Selector lever is in P position and the vehicle speed of 7±4 km/h is detected.	<ul style="list-style-type: none"> • Harness and connectors (Detention switch circuit is opened/shorted.) • Detention switch • Unified meter and A/C amp. (CAN communication)

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Drive the vehicle at 7±4 km/h or more.
2. Check "Self diagnostic result" using CONSULT-III.

Is the DTC detected?

- YES >> Perform diagnosis procedure. Refer to [ADP-59, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000004534928

ADP

1. CHECK DTC WITH "BCM"

Check "Self diagnostic result" for BCM using CONSULT-III.

Is the either DTC B2601, B2602, B2603, B2604 or B2605 detected?

- YES >> Check the DTC. Refer to [BCS-76, "DTC Index"](#).
 NO >> GO TO 2.

2. CHECK DTC WITH "METER/M&A"

Check "Self diagnostic result" for METER/M&A using CONSULT-III.

Is the DTC detected?

- YES >> Check the DTC. Refer to [MWI-81, "DTC Index"](#).
 NO >> GO TO 3.

3. CHECK DETENTION SWITCH SIGNAL

1. Turn ignition switch ON.
2. Select "DETENT SW" in the "Data Monitor" mode using CONSULT-III.
3. Check detention switch signal under the following condition.

Monitor item	Condition		Status
DETENT SW	selector lever	P position	OFF
		Other than above	ON

Is the status normal?

- YES >> GO TO 5.
 NO >> GO TO 4.

4. CHECK DETENTION SWITCH CIRCUIT

B2126 DETENT SW

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit and A/T shift selector connector.
3. Check continuity between driver seat control unit harness connector and A/T shift selector harness connector.

Driver seat control unit		A/T shift selector		Continuity
Connector	Terminal	Connector	Terminal	
B503	21	M137	11	Existed

4. Check continuity between driver seat control unit harness connector and ground.

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B503	21		Not existed

Is the inspection result normal?

- YES >> Replace driver seat control unit. Refer to [ADP-230, "Removal and Installation"](#).
NO >> Repair or replace harness.

5. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

B2127 PARKING BRAKE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

B2127 PARKING BRAKE SWITCH

Description

INFOID:000000004534929

- Parking brake switch is installed on parking brake lever. It is turned ON when the parking brake is applied.
- The driver seat control unit judges that the parking brake is engaged if continuity exists in this circuit.

DTC Logic

INFOID:000000004534930

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2127	PARKING BRAKE	Parking brake is engaged and the vehicle speed of 7 km/h (4MPH) or more is detected.	<ul style="list-style-type: none">• Harness and connectors (Parking brake switch circuit is opened/shorted.)• Parking brake switch• Combination meter (CAN communication)• Driver seat control unit

DTC CONFIRMATION PROCEDURE

1. STEP 1

1. Drive the vehicle at 7 km/h (4 MPH) or more.
2. Check "Self Diagnostic Result" using CONSULT-III.

Is the DTC detected?

- YES >> Perform diagnosis procedure. Refer to [ADP-61, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000004534931

1. CHECK PARKING BRAKE SWITCH SIGNAL

ADP

1. Turn ignition switch ON.
2. Select "PARK BRAKE SW" in the "Data Monitor" mode using CONSULT-III.
3. Check parking brake switch signal under the following condition.

Monitor item	Condition		Status
PARK BRAKE SW	Parking brake	Applied	ON
		Release	OFF

Is the status normal?

- YES >> GO TO 5.
NO >> GO TO 2.

2. CHECK PARKING BRAKE SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect parking brake switch harness connector.
3. Turn ignition switch ON.
4. Check voltage between parking brake switch harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Connector	Terminal		
B14	1	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 4.
NO >> GO TO 3.

B2127 PARKING BRAKE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

3.CHECK PARKING BRAKE SWITCH HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector and parking brake switch connector.
3. Check continuity between driver seat control unit harness connector and parking brake switch harness connector.

Driver seat control unit		Parking brake switch		Continuity
Connector	Terminal	Connector	Terminal	
B503	8	B14	1	Existed

4. Check continuity between driver seat control unit harness connector and ground.

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B503	8		Not existed

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-230, "Removal and Installation"](#).

NO >> Repair or replace harness.

4.CHECK PARKING BRAKE SWITCH

Refer to [ADP-62, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Adjust or replace parking brake switch.

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000004534932

1.CHECK PARKING BRAKE SWITCH

1. Turn ignition switch OFF.
2. Disconnect parking brake switch connector.
3. Check continuity between parking brake switch terminal and ground part of parking brake switch.

Terminal		Condition	Continuity
Parking brake switch			
1	Ground part of parking brake switch	Parking brake	Applied Existed
			Other than above Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Adjust or replace parking brake switch.

B2128 UART COMMUNICATION LINE

< DTC/CIRCUIT DIAGNOSIS >

B2128 UART COMMUNICATION LINE

Description

INFOID:000000004534933

Driver seat control unit performs UART communication with the automatic drive positioner control unit using 2 communication lines, TX and RX line. Driver seat control unit receives the operation signals of tilt & telescopic switch, door mirror remote control switch, set switch and memory switch and the position signals of tilt & telescopic sensor and door mirror sensor from the automatic drive positioner control unit and transmits the operation request signal.

DTC Logic

INFOID:000000004534934

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2128	UART COMM	The communication between driver seat control unit and auto drive positioner control unit is interrupted for a period of time.	<ul style="list-style-type: none"> • UART communication line (UART communication line is open or shorted) • Driver seat control unit • Automatic drive positioner control unit

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Operate tilt & telescopic switch for more than 2 seconds.
3. Check "Self diagnostic result" using CONSULT-III.

Is the DTC detected?

- YES >> Perform diagnosis procedure. Refer to [ADP-63, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000004534935

ADP

1. CHECK UART COMMUNICATION LINE CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit and automatic drive positioner control unit connector.
3. Check continuity between driver seat control unit harness connector and automatic drive positioner control unit harness connector.

Driver seat control unit		Automatic drive positioner control unit		Continuity
Connector	Terminal	Connector	Terminal	
B503	1	M51	10	Existed
	17		26	

4. Check continuity between driver seat control unit harness connector and ground.

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B503	1		Not existed
	17		

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
 NO >> Repair or replace harness.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

POWER SUPPLY AND GROUND CIRCUIT

BCM

BCM : Diagnosis Procedure

INFOID:000000004534936

1. CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

Signal name	Fuse and fusible link No.
Battery power supply	K (40A)
	10 (10A)

Is the fuse fusing?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit if a fuse or fusible link is blown.

NO >> GO TO 2.

2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connectors.
3. Check voltage between BCM harness connector and ground.

(+)		(-)	Voltage (Approx.)
BCM			
Connector	Terminal	Ground	Battery voltage
M118	1		
M119	11		

Is the measurement value normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3. CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M119	13		Existed

Does continuity exist?

YES >> INSPECTION END

NO >> Repair harness or connector.

DRIVER SEAT CONTROL UNIT

DRIVER SEAT CONTROL UNIT : Diagnosis Procedure

INFOID:000000004534937

NOTE:

Do not disconnect the battery negative terminal and the driver seat control unit connector until DTC is confirmed using CONSULT-III.

1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Check voltage between driver seat control unit harness connector and ground.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

(+)		(-)	Voltage (V) (Approx.)
Driver seat control unit			
Connector	Terminal	Ground	Battery voltage
B504	33		
	40		

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check the following.

- Repair or replace harness between driver seat control unit and fuse block (J/B).
- Circuit breaker.

2.CHECK GROUND CIRCUIT

Check continuity between the driver seat control unit harness connector and ground.

Driver seat control unit		Ground	Continuity
Connector	Terminal		Existed
B503	32		
B504	48		

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace harness.

DRIVER SEAT CONTROL UNIT : Special Repair Requirement

INFOID:000000004534938

1.PERFORM ADDITIONAL SERVICE

Perform additional service when removing battery negative terminal.

>> Refer to [ADP-64. "DRIVER SEAT CONTROL UNIT : Diagnosis Procedure"](#).

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

AUTOMATIC DRIVE POSITIONER CONTROL UNIT : Diagnosis Procedure

INFOID:000000004534939

NOTE:

Do not disconnect the battery negative terminal and the driver seat control unit connector until DTC is confirmed using CONSULT-III.

1.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Check voltage between automatic drive positioner control unit harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Automatic drive positioner control unit			
Connector	Terminal	Ground	Battery voltage
M52	34		
	39		

Is the inspection result normal?

YES >> GO TO 2.

NO - 1 >> Repair or replace harness between automatic drive positioner control unit and fuse block (J/B).

NO - 2 >> Check circuit breaker.

2.CHECK GROUND CIRCUIT

Check continuity between the automatic drive positioner control unit harness connector and ground.

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M52	40		Existed
	48		

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace harness.

AUTOMATIC DRIVE POSITIONER CONTROL UNIT : Special Repair Requirement

INFOID:000000004534940

1.PERFORM ADDITIONAL SERVICE

Perform additional service when removing battery negative terminal.

>> Refer to [ADP-9, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Description"](#).

SLIDING SWITCH

< DTC/CIRCUIT DIAGNOSIS >

SLIDING SWITCH

Description

INFOID:000000004534941

Sliding switch is equipped to the power seat switch on the seat cushion side surface. The operation signal is input to the driver seat control unit when the sliding switch is operated.

Component Function Check

INFOID:000000004534942

1.CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "SLIDE SW-FR", "SLIDE SW-RR" in the "Data monitor" mode using CONSULT-III.
3. Check sliding switch signal under the following conditions.

Monitor item	Condition		Status
SLIDE SW-FR	Sliding switch (forward)	Operate	ON
		Release	OFF
SLIDE SW-RR	Sliding switch (backward)	Operate	ON
		Release	OFF

Is the indication normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-67. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004534943

1.CHECK SLIDING SWITCH SIGNAL

1. Turn ignition switch OFF.
2. Disconnect power seat switch connector.
3. Turn ignition switch ON.
4. Check voltage between power seat switch harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Power seat switch			
Connector	Terminal	Ground	Battery voltage
B510	11		
	26		

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2.CHECK SLIDING SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between driver seat control unit harness connector and power seat switch harness connector.

Driver seat control unit		Power seat switch		Continuity
Connector	Terminal	Connector	Terminal	
B503	11	B510	11	Existed
	26		26	

4. Check continuity between driver seat control unit harness connector and ground.

SLIDING SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B503	11		
	26		

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-230, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK SLIDING SWITCH

Refer to [ADP-68, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace power seat switch. Refer to [ADP-233, "Removal and Installation"](#).

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000004534944

1.CHECK SLIDING SWITCH

1. Turn ignition switch OFF.
2. Disconnect power seat switch connector.
3. Check continuity between power seat switch terminals.

Power seat switch		Condition		Continuity
Terminal				
32	11	Sliding switch (backward)	Operate	Existed
			Release	Not existed
	26	Sliding switch (forward)	Operate	Existed
			Release	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace power seat switch. Refer to [ADP-233, "Removal and Installation"](#).

RECLINING SWITCH

< DTC/CIRCUIT DIAGNOSIS >

RECLINING SWITCH

Description

INFOID:000000004534945

Reclining switch is equipped to the power seat switch on the seat cushion side surface. The operation signal is input to the driver seat control unit when the reclining switch is operated.

Component Function Check

INFOID:000000004534946

1. CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "RECLN SW-FR", "RECLN SW-RR" in the "Data monitor" mode using CONSULT-III.
3. Check reclining switch signal under the following conditions.

Monitor item	Condition	Status	
RECLINE SW-FR	Reclining switch (forward)	Operate	ON
		Release	OFF
RECLINE SW-RR	Reclining switch (backward)	Operate	ON
		Release	OFF

Is the indication normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-69. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004534947

1. CHECK RECLINING SWITCH SIGNAL

1. Turn ignition switch OFF.
2. Disconnect power seat switch connector.
3. Turn ignition switch ON.
4. Check voltage between power seat switch harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Power seat switch			
Connector	Terminal	Ground	Battery voltage
B510	12		
	27		

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK RECLINING SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between driver seat control unit harness connector and power seat switch harness connector.

Driver seat control unit		Power seat switch		Continuity
Connector	Terminal	Connector	Terminal	
B503	12	B510	12	Existed
	27		27	

4. Check continuity between driver seat control unit harness connector and ground.

RECLINING SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B503	12		
	27		

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-230, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK RECLINING SWITCH

Refer to [ADP-70, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace power seat switch. Refer to [ADP-233, "Removal and Installation"](#).

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000004534948

1.CHECK RECLINING SWITCH

1. Turn ignition switch OFF.
2. Disconnect power seat switch connector.
3. Check continuity between power seat switch terminals.

Power seat switch		Condition	Continuity	
Terminal				
32	12	Reclining switch (backward)	Operate	Existed
			Release	Not existed
	27	Reclining switch (forward)	Operate	Existed
			Release	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace power seat switch. Refer to [ADP-233, "Removal and Installation"](#).

LIFTING SWITCH (FRONT)

< DTC/CIRCUIT DIAGNOSIS >

LIFTING SWITCH (FRONT)

Description

INFOID:000000004534949

Lifting switch (front) is equipped to the power seat switch on the seat cushion side surface. The operation signal is input to the driver seat control unit when the lifting switch (front) is operated.

Component Function Check

INFOID:000000004534950

1.CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "LIFT FR SW-UP", "LIFT FR SW-DN" in the "Data monitor" mode using CONSULT-III.
3. Check lifting switch (front) signal under the following conditions.

Monitor item	Condition		Status
LIFT FR SW-UP	Lifting switch front (up)	Operate	ON
		Release	OFF
LIFT FR SW-DN	Lifting switch front (down)	Operate	ON
		Release	OFF

Is the indication normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-71. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004534951

1.CHECK LIFTING SWITCH SIGNAL

1. Turn ignition switch OFF.
2. Disconnect power seat switch connector.
3. Turn ignition switch ON.
4. Check voltage between power seat switch harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Power seat switch			
Connector	Terminal	Ground	Battery voltage
B510	13		
	28		

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2.CHECK LIFTING SWITCH (FRONT) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between driver seat control unit harness connector and power seat switch harness connector.

Driver seat control unit		Power seat switch		Continuity
Connector	Terminal	Connector	Terminal	
B503	13	B510	13	Existed
	28		28	

4. Check continuity between driver seat control unit harness connector and ground.

LIFTING SWITCH (FRONT)

< DTC/CIRCUIT DIAGNOSIS >

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B503	13		
	28		

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-230, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK LIFTING SWITCH (FRONT)

Refer to [ADP-72, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace power seat switch. Refer to [ADP-233, "Removal and Installation"](#).

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000004534952

1.CHECK LIFTING SWITCH (FRONT)

1. Turn ignition switch OFF.
2. Disconnect power seat switch connector.
3. Check continuity between power seat switch terminals.

Power seat switch		Condition	Continuity	
Terminal				
32	13	Lifting switch front (down)	Operate	Existed
			Release	Not existed
	28	Lifting switch front (up)	Operate	Existed
			Release	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace power seat switch. Refer to [ADP-233, "Removal and Installation"](#).

LIFTING SWITCH (REAR)

< DTC/CIRCUIT DIAGNOSIS >

LIFTING SWITCH (REAR)

Description

INFOID:000000004534953

Lifting switch (rear) is equipped to the power seat switch on the seat cushion side surface. The operation signal is input to the driver seat control unit when the lifting switch (rear) is operated.

Component Function Check

INFOID:000000004534954

1. CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "LIFT RR SW-UP", "LIFT RR SW-DN" in the "Data monitor" mode using CONSULT-III.
3. Check lifting switch (rear) signal under the following conditions.

Monitor item	Condition		Status
LIFT RR SW-UP	Lifting switch rear (up)	Operate	ON
		Release	OFF
LIFT RR SW-DN	Lifting switch rear (down)	Operate	ON
		Release	OFF

Is the indication normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-73. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004534955

1. CHECK LIFTING SWITCH (REAR) SIGNAL

1. Turn ignition switch OFF.
2. Disconnect power seat switch connector.
3. Turn ignition switch ON.
4. Check voltage between power seat switch harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Power seat switch			
Connector	Terminal	Ground	Battery voltage
B510	14		
	29		

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK LIFTING SWITCH (REAR) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between driver seat control unit harness connector and power seat switch harness connector.

Driver seat control unit		Power seat switch		Continuity
Connector	Terminal	Connector	Terminal	
B503	14	B510	14	Existed
	29		29	

4. Check continuity between driver seat control unit harness connector and ground.

LIFTING SWITCH (REAR)

< DTC/CIRCUIT DIAGNOSIS >

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B503	14		
	29		

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-230, "Removal and Installation"](#).

NO >> Repair or replace harness.

3. CHECK LIFTING SWITCH (REAR)

Refer to [ADP-74, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace power seat switch. Refer to [ADP-233, "Removal and Installation"](#).

4. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000004534956

1. CHECK LIFTING SWITCH (REAR)

1. Turn ignition switch OFF.
2. Disconnect power seat switch connector.
3. Check continuity between power seat switch terminals.

Power seat switch		Condition		Continuity
Terminal				
32	14	Lifting switch rear (down)	Operate	Existed
			Release	Not existed
	29	Lifting switch rear (up)	Operate	Existed
			Release	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace power seat switch. Refer to [ADP-233, "Removal and Installation"](#).

FORWARD SWITCH

< DTC/CIRCUIT DIAGNOSIS >

FORWARD SWITCH

Description

INFOID:000000004534957

Forward switch is installed on the seat back frame. Forward switch detects condition of seat back.

Component Function Check

INFOID:000000004534958

1. CHECK FUNCTION

1. Select "FORWARD SW" in the "Data Monitor" mode using CONSULT-III.
2. Check the forward switch signal under the following condition.

Test item	Condition		Status
FORWARD SW	Driver side seat back	Folded up	ON
		Folded down	OFF

Is the indication normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-75, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004534959

1. CHECK FORWARD SWITCH SIGNAL

1. Turn ignition switch OFF.
2. Disconnect forward switch harness connector.
3. Check voltage between forward switch harness connector and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)
Connector	Terminal			
B512	41	Ground	Seat back is folded up and power walk-in switch pressed	5

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK FORWARD SWITCH CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check continuity between driver seat control unit harness connector and forward switch harness connector.

Driver seat control unit		Forward switch		Continuity
Connector	Terminal	Connector	Terminal	
B504	41	B512	41	Existed

3. Check continuity between driver seat control unit harness connector and ground.

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B504	41		Not existed

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-230, "Removal and Installation"](#)

NO >> Repair or replace harness.

3. FORWARD SWITCH GROUND CIRCUIT

Check continuity between forward switch harness connector and ground.

FORWARD SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Forward switch		Ground	Continuity
Connector	Terminal		
B512	32		Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK FORWARD SWITCH

Refer to [ADP-76, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace forward switch (Built in seat back frame). Refer to [SE-179, "Exploded View"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000004534960

1.CHECK FORWARD SWITCH

1. Turn ignition switch OFF.
2. Disconnect forward switch connector.
3. Check continuity between forward switch terminals.

Forward switch		Condition	Continuity		
Connector	Terminal				
B512	41	32	Driver side seat back	Folded up	Not existed
			Folded down	Existed	

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace forward switch (Built in seat back frame). Refer to [SE-179, "Exploded View"](#).

SEAT BELT BUCKLE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

SEAT BELT BUCKLE SWITCH

Description

INFOID:000000004534961

Seat belt buckle switch is installed in seat belt buckle. Seat belt buckle switch detects condition of seat belt.

Component Function Check

INFOID:000000004534962

1.CHECK FUNCTION

1. Select "SEAT BELT SW" in the "Data Monitor" mode using CONSULT-III.
2. Check the seat belt buckle switch signal under the following condition.

Test item	Condition		Status
SEAT BELT SW	Driver side seat belt	Fastened	ON
		Released	OFF

Is the indication normal?

YES >> INSPECTION END

NO >> Refer to [ADP-77, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004534963

1.CHECK SEAT BELT BUCKLE SWITCH SIGNAL

1. Turn ignition switch OFF.
2. Disconnect seat belt buckle switch harness connector.
3. Check voltage between seat belt buckle switch harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Seat belt buckle switch			
Connector	Terminal		
B13	1	Ground	5

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2.CHECK SEAT BELT BUCKLE SWITCH CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check continuity between driver seat control unit harness connector and seat belt buckle switch harness connector.

Driver seat control unit		Seat belt buckle switch		Continuity
Connector	Terminal	Connector	Terminal	
B503	5	B13	1	Existed

3. Check continuity between driver seat control unit harness connector and ground.

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B503	5		Not existed

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-230, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK SEAT BELT BUCKLE SWITCH GROUND CIRCUIT

Check continuity between seat belt buckle switch harness connector and ground.

SEAT BELT BUCKLE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Seat belt buckle switch		Ground	Continuity
Connector	Terminal		Existed
B13	2		

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK SEAT BELT BUCKLE SWITCH

Refer to [ADP-78, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace seat belt buckle switch (Built in seat belt buckle). Refer to [SE-179, "Exploded View"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000004534964

1.CHECK SEAT BELT BUCKLE SWITCH

1. Turn ignition switch OFF.
2. Disconnect seat belt buckle switch connector.
3. Check continuity between seat belt buckle switch terminals.

Seat belt buckle switch		Condition		Continuity	
Connector	Terminal				
B13	1	2	Driver side seat belt	Fastened	Not existed
				Released	Existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace seat belt buckle switch (Built in seat belt buckle). Refer to [SE-179, "Exploded View"](#).

SLIDING LIMIT SWITCH

< DTC/CIRCUIT DIAGNOSIS >

SLIDING LIMIT SWITCH

Description

INFOID:000000004534965

Sliding limit switch is installed on seat cushion frame. Sliding limit switch detects condition of seat sliding.

Component Function Check

INFOID:000000004534966

1.CHECK FUNCTION

1. Select "FWD LIMIT SW" in the "Data Monitor" mode using CONSULT-III.
2. Check the sliding limit switch signal under the following condition.

Test item	Condition		Status
FWD LIMIT SW	Seat sliding	Front edge	ON
		Other than above	OFF

Is the indication normal?

- YES >> INSPECTION END
 NO >> Go to [ADP-79, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004534967

1.CHECK SLIDING LIMIT SWITCH SIGNAL

1. Turn ignition switch OFF.
2. Disconnect sliding limit switch harness connector.
3. Check voltage between sliding limit switch harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Sliding limit switch			
Connector	Terminal	Ground	5
B514	4		

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 2.

2.CHECK SLIDING LIMIT SWITCH CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check continuity between driver seat control unit harness connector and sliding limit switch harness connector.

Driver seat control unit		Sliding limit switch		Continuity
Connector	Terminal	Connector	Terminal	
B503	4	B514	4	Existed

3. Check continuity between driver seat control unit harness connector and ground.

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B503	4		Not existed

Is the inspection result normal?

- YES >> Replace driver seat control unit. Refer to [ADP-230, "Removal and Installation"](#)
 NO >> Repair or replace harness.

3.CHECK SLIDING LIMIT SWITCH GROUND CIRCUIT

Check continuity between sliding limit switch harness connector and ground.

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

SLIDING LIMIT SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Sliding limit switch		Ground	Continuity
Connector	Terminal		Existed
B514	32		

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace harness.

4.CHECK SLIDING LIMIT SWITCH

Refer to [ADP-80, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Replace forward switch (Built in seat back frame). Refer to [SE-179, "Exploded View"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000004534968

1.CHECK SLIDING LIMIT SWITCH

1. Turn ignition switch OFF.
2. Disconnect sliding limit switch connector.
3. Check continuity between sliding limit switch terminals.

Sliding limit switch			Condition	Continuity	
Connector	Terminal			Existed	
B514	4	32	Seat sliding	Front edge	Existed
				Other than above	Not existed

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Replace forward switch (Built in seat back frame). Refer to [SE-179, "Exploded View"](#).

POWER WALK-IN SWITCH

< DTC/CIRCUIT DIAGNOSIS >

POWER WALK-IN SWITCH

Description

INFOID:000000004534969

Power walk-in switch is installed on seat back. The operation signal is input to driver seat control unit when power walk-in switch is operated.

Component Function Check

INFOID:000000004534970

1. CHECK FUNCTION

1. Select "WALK-IN SW" in the "Data Monitor" mode using CONSULT-III.
2. Check the power walk-in switch signal under the following condition.

Test item	Condition		Status
WALK-IN SW	Power walk-in switch	Pressed	ON
		Released	OFF

Is the indication normal?

- YES >> INSPECTION END
NO >> Refer to [ADP-81, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004534971

1. CHECK POWER WALK-IN SWITCH SIGNAL

1. Turn ignition switch OFF.
2. Disconnect power walk-in switch harness connector.
3. Check voltage between power walk-in switch harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Power walk-in switch			
Connector	Terminal	Ground	5
B513	30		

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK POWER WALK-IN SWITCH CIRCUIT

1. Disconnect driver seat control unit connector and power walk-in switch connector.
2. Check continuity between driver seat control unit harness connector and power walk-in switch harness connector.

Driver seat control unit		Power walk-in switch		Continuity
Connector	Terminal	Connector	Terminal	
B503	30	B513	30	Existed

3. Check continuity between driver seat control unit harness connector and ground.

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B503	30		Not existed

Is the inspection result normal?

- YES >> Replace driver seat control unit. Refer to [ADP-230, "Removal and Installation"](#).
NO >> Repair or replace harness.

3. CHECK POWER WALK-IN SWITCH GROUND CIRCUIT

Check continuity between power walk-in switch harness connector and ground.

POWER WALK-IN SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Power walk-in switch		Ground	Continuity
Connector	Terminal		Existed
B513	32		

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK POWER WALK-IN SWITCH

Refer to [ADP-82, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace power walk-in switch (Built in walk-in lever). Refer to [SE-179, "Exploded View"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000004534972

1.CHECK POWER WALK-IN SWITCH

1. Turn ignition switch OFF.
2. Disconnect power walk-in switch connector.
3. Check continuity between power walk-in switch terminals.

Power walk-in switch			Condition	Continuity
Connector	Terminal			Existed
B513	30	32	Power walk-in switch Pressed	Existed
			Released	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace power walk-in switch (Built in walk-in lever). Refer to [SE-179, "Exploded View"](#).

TILT SWITCH

< DTC/CIRCUIT DIAGNOSIS >

TILT SWITCH

Description

INFOID:000000004534973

Tilt switch is equipped to the steering column. The operation signal is input to the automatic drive positioner control unit when the tilt switch is operated.

Component Function Check

INFOID:000000004534974

1.CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "TILT SW-UP", "TILT SW-DN" in the "Data monitor" mode using CONSULT-III.
3. Check tilt switch signal under the following conditions.

Monitor item	Condition		Status
TILT SW-UP	Tilt switch (up)	Operate	ON
		Release	OFF
TILT SW-DN	Tilt switch (down)	Operate	ON
		Release	OFF

Is the indication normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-83. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004534975

1.CHECK TILT SWITCH SIGNAL

1. Turn ignition switch OFF.
2. Disconnect tilt & telescopic switch connector.
3. Turn ignition switch ON.
4. Check voltage between tilt & telescopic switch harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Tilt & telescopic switch			
Connector	Terminal	Ground	Battery voltage
M31	4		
	5		

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2.CHECK TILT SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and tilt & telescopic switch harness connector.

Automatic drive positioner control unit		Tilt & telescopic switch		Continuity
Connector	Terminal	Connector	Terminal	
M51	1	M31	4	Existed
	17		5	

4. Check continuity between automatic drive positioner control unit harness connector and ground.

TILT SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M51	1		
	17		

Is the inspection result normal?

YES >> Replace automatic drive positioner control unit. Refer to [ADP-231, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK TILT SWITCH

Refer to [ADP-84, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace tilt & telescopic switch. Refer to [ADP-235, "Removal and Installation"](#).

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000004534976

1.CHECK TILT SWITCH

1. Turn ignition switch OFF.
2. Disconnect tilt & telescopic switch connector.
3. Check continuity between tilt & telescopic switch terminals.

Tilt & telescopic switch		Condition		Continuity
Terminal				
1	4	Tilt switch (up)	Operate	Existed
			Release	Not existed
	5	Tilt switch (down)	Operate	Existed
			Release	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace tilt & telescopic switch. Refer to [ADP-235, "Removal and Installation"](#).

TELESCOPIC SWITCH

< DTC/CIRCUIT DIAGNOSIS >

TELESCOPIC SWITCH

Description

INFOID:000000004534977

Telescopic switch is equipped to the steering column. The operation signal is input to the automatic drive positioner control unit when the telescopic switch is operated.

Component Function Check

INFOID:000000004534978

1. CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "TELESCO SW-FR", "TELESCO SW-RR" in the "Data monitor" mode using CONSULT-III.
3. Check telescopic switch signal under the following conditions.

Monitor item	Condition	Status	
TELESCO SW-FR	Telescopic switch (forward)	Operate	ON
		Release	OFF
TELESCO SW-RR	Telescopic switch (backward)	Operate	ON
		Release	OFF

Is the indication normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-85. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004534979

1. CHECK TELESCOPIC SWITCH SIGNAL

1. Turn ignition switch OFF.
2. Disconnect tilt & telescopic switch connector.
3. Turn ignition switch ON.
4. Check voltage between tilt & telescopic switch harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Tilt & telescopic switch			
Connector	Terminal	Ground	Battery voltage
M31	2		
	3		

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK TELESCOPIC SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and tilt & telescopic switch harness connector.

Automatic drive positioner control unit		Tilt & telescopic switch		Continuity
Connector	Terminal	Connector	Terminal	
M51	11	M31	2	Existed
	27		3	

4. Check continuity between automatic drive positioner control unit harness connector and ground.

TELESCOPIC SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M51	11		
	27		

Is the inspection result normal?

YES >> Replace automatic drive positioner control unit. Refer to [ADP-231, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK TELESCOPIC SWITCH

Refer to [ADP-86, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace tilt & telescopic switch. Refer to [ADP-235, "Removal and Installation"](#).

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000004534980

1.CHECK TELESCOPIC SWITCH

1. Turn ignition switch OFF.
2. Disconnect tilt & telescopic switch connector.
3. Check continuity between tilt & telescopic switch terminals.

Tilt & telescopic switch		Condition		Continuity
Terminal				
1	2	Telescopic switch (forward)	Operate	Existed
			Release	Not existed
	3	Telescopic switch (backward)	Operate	Existed
			Release	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace tilt & telescopic switch. Refer to [ADP-235, "Removal and Installation"](#).

SEAT MEMORY SWITCH

< DTC/CIRCUIT DIAGNOSIS >

SEAT MEMORY SWITCH

Description

INFOID:000000004534981

Memory switch is equipped on the seat set switch and seat memory switch installed to the driver side door trim. The operation signal is input to the automatic drive positioner control unit when the set switch or memory switch is operated.

Component Function Check

INFOID:000000004534982

1.CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "MEMORY SW 1", "MEMORY SW 2" "SET SW" in the "Data monitor" mode using CONSULT-III.
3. Check seat memory switch signal under the following conditions.

Monitor item	Condition	Status	
SET SW	SET SW	Push	ON
		Release	OFF
MEMORY SW 1	Memory switch 1	Push	ON
		Release	OFF
MEMORY SW 2	Memory switch 2	Push	ON
		Release	OFF

Is the indication normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-87, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004534983

1.CHECK SEAT MEMORY SWITCH SIGNAL

1. Turn ignition switch OFF.
2. Disconnect seat memory switch connector.
3. Turn ignition switch ON.
4. Check voltage between seat memory switch harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Seat memory switch			
Connector	Terminal	Ground	5
D5	3		
	1		
	2		

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2.CHECK MEMORY SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and seat memory switch harness connector.

SEAT MEMORY SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Automatic drive positioner control unit		Seat memory switch		Continuity
Connector	Terminal	Connector	Terminal	
M51	24	D5	3	Existed
	9		1	
	25		2	

4. Check continuity between automatic drive positioner control unit harness connector and ground.

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M51	24		Not existed
	9		
	25		

Is the inspection result normal?

YES >> Replace automatic drive positioner control unit. Refer to [ADP-231, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK MEMORY SWITCH GROUND CIRCUIT

- Turn ignition switch OFF.
- Check continuity between seat memory switch harness connector and ground.

Seat memory switch		Ground	Continuity
Connector	Terminal		
D5	4		Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK SEAT MEMORY SWITCH

Refer to [ADP-88, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace seat memory switch. Refer to [ADP-232, "Removal and Installation"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000004534984

1.CHECK SEAT MEMORY SWITCH

- Turn ignition switch OFF.
- Disconnect seat memory switch connector.
- Check continuity between seat memory switch terminals.

SEAT MEMORY SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Seat memory switch		Condition		Continuity
Terminal				
4	3	Set switch	Push	Existed
			Release	Not existed
	1	Memory switch 1	Push	Existed
			Release	Not existed
	2	Memory switch 2	Push	Existed
			Release	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace seat memory switch. Refer to [ADP-232, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

DOOR MIRROR REMOTE CONTROL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

DOOR MIRROR REMOTE CONTROL SWITCH MIRROR SWITCH

MIRROR SWITCH : Description

INFOID:000000004534985

It operates angle of the door mirror face.

It transmits mirror face adjust operation to AUTOMATIC DRIVE POSITIONER CONTROL UNIT.

MIRROR SWITCH : Component Function Check

INFOID:000000004534986

1. CHECK MIRROR SWITCH FUNCTION

Check the operation on "MIR CON SW-UP/DN" and "MIR CON SW-RH/LH" in the "DATA MONITOR" mode using CONSULT-III.

Monitor item	Condition	
MIR CON SW-UP/DN	When operating the mirror switch up or down side.	: ON
	Other than above.	: OFF
MIR CON SW-RH/LH	When operating the mirror switch right or left side.	: ON
	Other than above.	: OFF

Is the inspection result normal?

YES >> Mirror switch function is OK.

NO >> Refer to [ADP-90, "MIRROR SWITCH : Diagnosis Procedure"](#).

MIRROR SWITCH : Diagnosis Procedure

INFOID:000000004534987

1. CHECK MIRROR SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect door mirror remote control switch connector.
3. Turn ignition switch ON.
4. Check voltage between door mirror remote control switch harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Door mirror remote control switch			
Connector	Terminal	Ground	5
D17	4		
	12		
	13		
	15		

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK MIRROR SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and door mirror remote control switch harness connector.

DOOR MIRROR REMOTE CONTROL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Automatic drive positioner control unit		Door mirror remote control switch		Continuity
Connector	Terminal	Connector	Terminal	
M51	3	D17	15	Existed
	4		13	
	19		12	
	20		4	

4. Check continuity between automatic drive positioner control unit harness connector and ground.

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M51	3	Ground	Not existed
	4		
	19		
	20		

Is the inspection result normal?

YES >> Replace automatic drive positioner control unit. Refer to [ADP-231, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK DOOR MIRROR REMOTE CONTROL SWITCH GROUND CIRCUIT

- Turn ignition switch OFF.
- Check continuity between door mirror remote control switch harness connector and ground.

Door mirror remote control switch		Ground	Continuity
Connector	Terminal		
D17	7	Ground	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK MIRROR SWITCH

Check door mirror remote control switch (mirror switch).
Refer to [ADP-91, "MIRROR SWITCH : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace door mirror remote control switch (mirror switch). Refer to [MIR-21, "Removal and Installation"](#).

5.CHECK INTERMITTENT INCIDENT

Check intermittent incident.
Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

MIRROR SWITCH : Component Inspection

INFOID:000000004534988

1.CHECK MIRROR SWITCH

- Turn ignition switch OFF.
- Disconnect door mirror remote control switch connector.
- Check continuity between door mirror remote control switch terminals.

DOOR MIRROR REMOTE CONTROL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Door mirror remote control switch		Condition	Continuity
Connector	Terminal		
D17	4	RIGHT	Existed
		Other than above	Not existed
	13	LEFT	Existed
		Other than above	Not existed
	15	UP	Existed
		Other than above	Not existed
	12	DOWN	Existed
		Other than above	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace door mirror remote control switch. Refer to [MIR-21. "Removal and Installation"](#).

CHANGEOVER SWITCH

CHANGEOVER SWITCH : Description

INFOID:000000004534989

Changeover switch is integrated into door mirror remote control switch.

Changeover switch has three positions (L, N and R).

It changes operating door mirror motor by transmitting control signal to automatic drive positioner control unit.

CHANGEOVER SWITCH : Component Function Check

INFOID:000000004534990

1. CHECK CHANGEOVER SWITCH FUNCTION

Check the operation on "MIR CHNG SW-R" or "MIR CHNG SW-L" in the "DATA MONITOR" mode using CONSULT-III.

Monitor item	Condition
MIR CHNG SW-R/L	When operating the changeover toward the right or left side. : ON
	Other than above. : OFF

Is the inspection result normal?

YES >> Changeover switch function is OK.

NO >> Refer to [ADP-92. "CHANGEOVER SWITCH : Diagnosis Procedure"](#).

CHANGEOVER SWITCH : Diagnosis Procedure

INFOID:000000004534991

1. CHECK CHANGEOVER SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect door mirror remote control switch connector.
3. Turn ignition switch ON.
4. Check voltage between door mirror remote control switch harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Door mirror remote control switch			
Connector	Terminal		
D17	10	Ground	5
	11		

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK CHANGEOVER SWITCH CIRCUIT

DOOR MIRROR REMOTE CONTROL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and door mirror remote control switch harness connector.

Automatic drive positioner control unit		Door mirror remote control switch		Continuity
Connector	Terminal	Connector	Terminal	
M51	2	D17	11	Existed
	18		10	

4. Check continuity between automatic drive positioner control unit harness connector and ground.

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M51	2		Not existed
	18		

Is the inspection result normal?

- YES >> Replace automatic drive positioner control unit. Refer to [ADP-231, "Removal and Installation"](#).
 NO >> Repair or replace harness.

3.CHECK DOOR MIRROR REMOTE CONTROL SWITCH GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between door mirror remote control switch harness connector and ground.

Door mirror remote control switch		Ground	Continuity
Connector	Terminal		
D17	7		Existed

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair or replace harness.

4.CHECK CHANGEOVER SWITCH

Check door mirror remote control switch (changeover switch).
 Refer to [ADP-93, "CHANGEOVER SWITCH : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> Replace door mirror remote control switch (changeover switch). Refer to [MIR-21, "Removal and Installation"](#).

5.CHECK INTERMITTENT INCIDENT

Check intermittent incident.
 Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

CHANGEOVER SWITCH : Component Inspection

INFOID:000000004534992

1.CHECK CHANGEOVER SWITCH

1. Turn ignition switch OFF.
2. Disconnect door mirror remote control switch connector.
3. Check continuity between door mirror remote control switch terminals.

DOOR MIRROR REMOTE CONTROL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Door mirror remote control switch		Terminal	Condition	Continuity
Connector				
D17	10	7	LEFT	Existed
			Other than above	Not existed
	11		RIGHT	Existed
			Other than above	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace door mirror remote control switch. Refer to [MIR-21. "Removal and Installation"](#).

POWER SEAT SWITCH GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

POWER SEAT SWITCH GROUND CIRCUIT

Diagnosis Procedure

INFOID:000000004534993

1. CHECK POWER SEAT SWITCH GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect power seat switch connector.
3. Check continuity between power seat switch connector and ground.

Power seat switch		Ground	Continuity
Connector	Terminal		Existed
B510	32		

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace harness.

2. CHECK POWER SEAT SWITCH INTERNAL CIRCUIT

Check reclining switch.
Refer to [ADP-70, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Replace power seat switch. Refer to [ADP-233, "Removal and Installation"](#).

3. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

TILT & TELESCOPIC SWITCH GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

TILT & TELESCOPIC SWITCH GROUND CIRCUIT

Diagnosis Procedure

INFOID:000000004534994

1. CHECK POWER TILT & TELESCOPIC SWITCH GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect power tilt & telescopic switch connector.
3. Check continuity between power seat switch connector and ground.

Tilt & telescopic switch		Ground	Continuity
Connector	Terminal		Existed
M31	1		

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace harness.

2. CHECK POWER TILT & TELESCOPIC SWITCH INTERNAL CIRCUIT

Check tilt switch.
Refer to [ADP-84, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Replace tilt & telescopic switch. Refer to [ADP-235, "Removal and Installation"](#).

3. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

DETENTION SWITCH

< DTC/CIRCUIT DIAGNOSIS >

DETENTION SWITCH

Description

INFOID:000000004534995

Detention switch is installed on A/T shift selector. It is turned OFF when the Selector lever is in P position. The driver seat control unit judges that the Selector lever is in P position if continuity does not exist in this circuit.

Component Function Check

INFOID:000000004534996

1. CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "DETENT SW" signal in the "Data monitor" mode using CONSULT-III.
3. Check detention switch signal under the following conditions.

Monitor item	Condition		Status
DETENT SW	Selector lever	P position	OFF
		Other than above	ON

Is the indication normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-97, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004534997

1. CHECK DTC WITH "BCM"

Check "Self Diagnostic Result" for BCM using CONSULT-III.

Is the either DTC B2601, B2602, B2603, B2604 or B2605 detected?

YES >> Check the DTC. Refer to [ADP-209, "DTC Index"](#).

NO >> GO TO 2.

2. CHECK DETENTION SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect A/T shift selector harness connector.
3. Turn ignition switch ON.
4. Check voltage between A/T shift selector harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
A/T shift selector			
Connector	Terminal	Ground	Battery voltage
M137	11		

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 3.

3. CHECK DETENTION SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit.
3. Check continuity between driver seat control unit harness connector and A/T shift selector harness connector.

Driver seat control unit		A/T shift selector		Continuity
Connector	Terminal	Connector	Terminal	
B503	21	M137	11	Existed

4. Check continuity between driver seat control unit harness connector and ground.

DETENTION SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B503	21		Not existed

Is the inspection result normal?

- YES >> Replace driver seat control unit. Refer to [ADP-230, "Removal and Installation"](#).
 NO >> Repair or replace harness.

4.CHECK DETENTION SWITCH

Refer to [ADP-98, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> Replace A/T shift selector. Refer to [TM-277, "2WD : Removal and Installation"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000004534998

1.CHECK DETENTION SWITCH

1. Turn ignition switch OFF.
2. Disconnect A/T shift selector connector.
3. Check A/T shift selector terminals.

A/T shift selector			Condition		Continuity
Connector	Terminal				
M137	10	11	Selector lever	P position	Existed
				Other than above	Not existed

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> Replace A/T shift selector. Refer to [TM-277, "2WD : Removal and Installation"](#).

PARKING BRAKE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

PARKING BRAKE SWITCH

Description

INFOID:000000004534999

Parking brake switch is installed on parking brake lever. It is turned ON when the parking brake is applied. The driver seat control unit judges that the parking brake is engaged if continuity exists in this circuit.

Component Function Check

INFOID:000000004535000

1.CHECK PARKING BRAKE SWITCH INPUT SIGNAL

1. Select "PARK BRAKE SW" in the "Data Monitor" mode using CONSULT-III.
2. Check parking brake switch signal under the following conditions.

Monitor item	Condition		Status
PARK BRAKE SW	Parking brake	Applied	ON
		Release	OFF

Is the indication normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-99. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004535001

1.CHECK PARKING BRAKE SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect A/T shift selector harness connector.
3. Turn ignition switch ON.
4. Check voltage between parking brake switch harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Parking brake switch			
Connector	Terminal		
B14	1	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2.CHECK PARKING BRAKE SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between driver seat control unit harness connector and parking brake switch harness connector.

Driver seat control unit		Parking brake switch		Continuity
Connector	Terminal	Connector	Terminal	
B503	8	B14	1	Existed

4. Check continuity between driver seat control unit harness connector and ground.

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B503	8		Not existed

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-230. "Removal and Installation"](#).

NO >> Repair or replace harness.

PARKING BRAKE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

3.CHECK PARKING BRAKE SWITCH

Refer to [ADP-100. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Adjust or replace parking brake switch.

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-41. "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000004535002

1.CHECK PARKING BRAKE SWITCH

1. Turn ignition switch OFF.
2. Disconnect parking brake switch connector.
3. Check continuity between parking brake switch terminal and ground part of parking brake switch.

Parking brake		Condition		Continuity
Terminal				
1	Ground part of parking brake switch	Parking brake	Applied	Existed
			Release	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO-1 >> Adjust or replace parking brake switch (pedal type). Refer to [PB-6. "PEDAL TYPE : Exploded View"](#).

NO-2 >> Adjust or replace parking brake switch (lever type). Refer to [PB-7. "LEVER TYPE : Exploded View"](#).

SLIDING SENSOR

< DTC/CIRCUIT DIAGNOSIS >

SLIDING SENSOR

Description

INFOID:000000004535003

- The sliding sensor is installed to the seat slide cushion frame.
- The pulse signal is input to the driver seat control unit when sliding is performed.
- The driver seat control unit counts the pulse and calculates the sliding amount of the seat.

Component Function Check

INFOID:000000004535004

1. CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "SLIDE PULSE" in the "Data monitor" mode using CONSULT-III.
3. Check sliding sensor signal under the following conditions.

Monitor item	Condition		Valve
SLIDE PULSE	Seat sliding	Operate (forward)	Change (increase)*1
		Operate (backward)	Change (decrease)*1
		Release	No change*1

*1: The value at the seat position attained when the battery is connected is considered to be 32768.

Is the indication normal?

- YES >> INSPECTION END
 NO >> Perform diagnosis procedure. Refer to [ADP-101, "Diagnosis Procedure"](#).


Diagnosis Procedure

INFOID:000000004535005

1. CHECK SLIDING SENSOR SIGNAL

1. Turn ignition switch ON.
2. Check voltage signal between driver seat control unit harness connector and ground with oscilloscope.

ADP

(+) Driver seat control unit		(-)	Condition	Voltage (V) (Approx.)
Connector	Terminal			
B503	24	Ground	Seat sliding	
			Operate	
			Other than above	0 or 5

Is the inspection result normal?

- YES >> Replace driver seat control unit. Refer to [ADP-230, "Removal and Installation"](#).
 NO >> GO TO 2.

2. CHECK SLIDING SENSOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit and sliding sensor connector.
3. Check continuity between driver seat control unit harness connector and sliding sensor harness connector.

SLIDING SENSOR

< DTC/CIRCUIT DIAGNOSIS >

Driver seat control unit		Sliding sensor		Continuity
Connector	Terminal	Connector	Terminal	
B503	24	B526	24	Existed

4. Check continuity between driver seat control unit harness connector and ground.

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B503	24		Not existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK SLIDING SENSOR POWER SUPPLY

1. Connect driver seat control unit connector.
2. Turn ignition switch ON.
3. Check voltage between sliding sensor harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Sliding sensor			
Connector	Terminal		
B526	16	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

4. CHECK SLIDING SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between driver seat control unit harness connector and sliding sensor harness connector.

Driver seat control unit		Sliding sensor		Continuity
Connector	Terminal	Connector	Terminal	
B503	16	B526	16	Existed

4. Check continuity between driver seat control unit harness connector and ground.

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B503	16		Not existed

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-230, "Removal and Installation"](#).

NO >> Repair or replace harness.

5. CHECK SLIDING SENSOR GROUND CIRCUIT 1

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between driver seat control unit harness connector and sliding sensor harness connector.

Driver seat control unit		Sliding sensor		Continuity
Connector	Terminal	Connector	Terminal	
B503	31	B526	31	Existed

SLIDING SENSOR

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace harness.

6.CHECK SLIDING SENSOR GROUND CIRCUIT 2

1. Connect driver seat control unit connector.
2. Check continuity between driver seat control unit harness connector and ground.

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B503	31		Existed

Is the inspection result normal?

YES >> Replace sliding sensor (Built in seat slide cushion frame). Refer to [ST-21, "WITH ELECTRIC MOTOR : Exploded View"](#).

NO >> Replace driver seat control unit. Refer to [ADP-230, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

RECLINING SENSOR

< DTC/CIRCUIT DIAGNOSIS >

RECLINING SENSOR

Description

INFOID:000000004535006

- The reclining motor is installed to the seatback frame.
- The pulse signal is input to the driver seat control unit when the reclining is operated.
- The driver seat control unit counts the pulse and calculates the reclining amount of the seat.

Component Function Check

INFOID:000000004535007

1. CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "RECLN PULSE" in the "Data monitor" mode using CONSULT-III.
3. Check reclining sensor signal under the following conditions.

Monitor item	Condition		Value
RECLN PULSE	Seat reclining	Operate (forward)	Change (increase)*1
		Operate (backward)	Change (decrease)*1
		Release	No change*1

*1: The value at the seat position attained when the battery is connected is considered to be 32768.

Is the indication normal?

YES >> INSPECTION END


NO >> Perform diagnosis procedure. Refer to [ADP-104, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004535008

1. CHECK RECLINING SENSOR SIGNAL

1. Turn ignition switch ON.
2. Check voltage signal between driver seat control unit harness connector and ground with oscilloscope.

(+) Driver seat control unit		(-)	Condition	Voltage (V) (Approx.)
Connector	Terminal			
B503	9	Ground	Seat reclining	 <p>10mSec/div 2V/div JMJA0119ZZ</p>
			Other than above	0 or 5

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-230, "Removal and Installation"](#).

NO >> GO TO 2.

2. CHECK RECLINING SENSOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit and reclining motor connector.
3. Check continuity between driver seat control unit harness connector and reclining motor harness connector.

RECLINING SENSOR

< DTC/CIRCUIT DIAGNOSIS >

Driver seat control unit		Reclining motor		Continuity
Connector	Terminal	Connector	Terminal	
B503	9	B523	9	Existed

4. Check continuity between driver seat control unit harness connector and ground.

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B503	9		Not existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK RECLINING SENSOR POWER SUPPLY

1. Connect driver seat control unit connector.
2. Turn ignition switch ON.
3. Check voltage between reclining motor harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Reclining motor			
Connector	Terminal		
B523	16	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

4. CHECK RECLINING SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between driver seat control unit harness connector and reclining motor harness connector.

Driver seat control unit		Reclining motor		Continuity
Connector	Terminal	Connector	Terminal	
B503	16	B523	16	Existed

4. Check continuity between driver seat control unit harness connector and ground.

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B503	16		Not existed

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-230, "Removal and Installation"](#).

NO >> Repair or replace harness.

5. CHECK RECLINING SENSOR GROUND CIRCUIT 1

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between driver seat control unit harness connector and reclining motor harness connector.

Driver seat control unit		Reclining motor		Continuity
Connector	Terminal	Connector	Terminal	
B503	31	B523	31	Existed

RECLINING SENSOR

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace harness.

6. CHECK RECLINING SENSOR GROUND CIRCUIT 2

1. Connect driver seat control unit connector.
2. Check continuity between reclining sensor harness connector and ground.

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B503	31		Existed

Is the inspection result normal?

YES >> Replace reclining motor. Refer to [SE-179, "Exploded View"](#).

NO >> Replace driver seat control unit. Refer to [ADP-230, "Removal and Installation"](#).

LIFTING SENSOR (FRONT)

< DTC/CIRCUIT DIAGNOSIS >

LIFTING SENSOR (FRONT)

Description

INFOID:000000004535009

- The lifting sensor (front) is installed to the seat slide cushion frame.
- The pulse signal is input to the driver seat control unit when the lifting (front) is operated.
- The driver seat control unit counts the pulse and calculates the lifting (front) amount of the seat.

Component Function Check

INFOID:000000004535010

1. CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "LIFT FR PULSE" in the "Data monitor" mode using CONSULT-III.
3. Check the lifting sensor (front) signal under the following conditions.

Monitor item	Condition		Value
LIFT FR PULSE	Seat lifting (front)	Operate (Up)	Change (increase) ^{*1}
		Operate (Down)	Change (decrease) ^{*1}
		Release	No change ^{*1}

^{*1}:The value at the seat position attained when the battery is connected is considered to be 32768.

Is the indication normal?

YES >> INSPECTION END


NO >> Perform diagnosis procedure. Refer to [ADP-107. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004535011

1. CHECK LIFTING SENSOR (FRONT) SIGNAL

1. Turn ignition switch ON.
2. Check the voltage signal driver seat control unit harness connector and ground with an oscilloscope.

(+)		(-)	Condition	Voltage (V) (Approx.)
Driver seat control unit				
Connector	Terminal			
B503	25	Ground	Seat Lifting (front)	 10mSec/div 2V/div JMJA0119ZZ
			Operate	
			Other than above	0 or 5

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-230. "Removal and Installation"](#).

NO >> GO TO 2.

2. CHECK LIFTING SENSOR (FRONT) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit and lifting motor (front) connector.
3. Check continuity between driver seat control unit harness connector and lifting motor (front) harness connector.

LIFTING SENSOR (FRONT)

< DTC/CIRCUIT DIAGNOSIS >

Driver seat control unit		Lifting motor (front)		Continuity
Connector	Terminal	Connector	Terminal	
B503	25	B527	25	Existed

4. Check continuity between driver seat control unit harness connector and ground.

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B503	25		Not existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK LIFTING SENSOR (FRONT) POWER SUPPLY

1. Connect driver seat control unit connector.
2. Turn ignition switch ON.
3. Check voltage between lifting motor (front) harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Lifting motor (front)			
Connector	Terminal		
B527	16	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

4. CHECK LIFTING SENSOR (FRONT) POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between driver seat control unit harness connector and lifting motor (front) harness connector.

Driver seat control unit		Lifting motor (front)		Continuity
Connector	Terminal	Connector	Terminal	
B503	16	B527	16	Existed

4. Check continuity between driver seat control unit harness connector and ground.

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B503	16		Not existed

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-230, "Removal and Installation"](#).

NO >> Repair or replace harness.

5. CHECK LIFTING SENSOR (FRONT) GROUND CIRCUIT 1

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between driver seat control unit harness connector and lifting motor (front) harness connector.

Driver seat control unit		Lifting motor (front)		Continuity
Connector	Terminal	Connector	Terminal	
B503	31	B527	31	Existed

LIFTING SENSOR (FRONT)

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace harness.

6. CHECK LIFTING SENSOR (FRONT) GROUND CIRCUIT 2

1. Connect driver seat control unit connector.
2. Check continuity between lifting motor (front) harness connector and ground.

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B503	31		Existed

Is the inspection result normal?

YES >> Replace lifting motor (front). Refer to [SE-179, "Exploded View"](#).

NO >> Replace driver seat control unit. Refer to [ADP-230, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

LIFTING SENSOR (REAR)

< DTC/CIRCUIT DIAGNOSIS >

LIFTING SENSOR (REAR)

Description

INFOID:000000004535012

- The lifting sensor (rear) is installed to the seat slide cushion frame.
- The pulse signal is input to the driver seat control unit when the lifting (rear) is operated.
- The driver seat control unit counts the pulse and calculates the lifting (rear) amount of the seat.

Component Function Check

INFOID:000000004535013

1. CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "LIFT RR PULSE" in the "Data monitor" mode using CONSULT-III.
3. Check lifting sensor (rear) signal under the following conditions.

Monitor item	Condition		Value
LIFT RR PULSE	Seat lifting (rear)	Operate (Up)	Change (increase) ^{*1}
		Operate (Down)	Change (decrease) ^{*1}
		Release	No change ^{*1}

*1: The value at the seat position attained when the battery is connected is considered to be 32768.

Is the indication normal?

YES >> INSPECTION END


NO >> Perform diagnosis procedure. Refer to [ADP-110. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004535014

1. CHECK LIFTING SENSOR (REAR) SIGNAL

1. Turn ignition switch ON.
2. Check voltage signal between driver seat control unit harness connector and ground with oscilloscope.

(+) Driver seat control unit		(-)	Condition	Voltage (V) (Approx.)
Connector	Terminal			
B503	10	Ground	Seat Lifting (rear)	 10mSec/div 2V/div JMJA0119ZZ
			Operate	
			Other than above	0 or 5

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-230. "Removal and Installation"](#).

NO >> GO TO 2.

2. CHECK LIFTING SENSOR (REAR) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit and lifting motor (rear) connector.
3. Check the continuity between driver seat control unit harness connector and lifting motor (rear) harness connector.

LIFTING SENSOR (REAR)

< DTC/CIRCUIT DIAGNOSIS >

Driver seat control unit		Lifting motor (rear)		Continuity
Connector	Terminal	Connector	Terminal	
B503	10	B529	10	Existed

4. Check the continuity between driver seat control unit harness connector and ground.

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B503	10		Not Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3.CHECK LIFTING SENSOR (REAR) POWER SUPPLY

1. Connect driver seat control unit connector.
2. Turn ignition switch ON.
3. Check the voltage between lifting motor (rear) harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Lifting motor (rear)			
Connector	Terminal		
B529	16	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

4.CHECK LIFTING SENSOR (REAR) POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check the continuity between driver seat control unit harness connector and lifting motor (rear) harness connector.

Driver seat control unit		Lifting motor (rear)		Continuity
Connector	Terminal	Connector	Terminal	
B503	16	B529	16	Existed

4. Check the continuity between driver seat control unit harness connector and ground.

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B503	16		Not existed

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-230, "Removal and Installation"](#).

NO >> Repair or replace harness.

5.CHECK LIFTING SENSOR (REAR) GROUND CIRCUIT 1

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check the continuity between driver seat control unit harness connector and lifting motor (rear) harness connector.

Driver seat control unit		Lifting motor (rear)		Continuity
Connector	Terminal	Connector	Terminal	
B503	31	B529	31	Existed

LIFTING SENSOR (REAR)

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace harness.

6. CHECK LIFTING SENSOR (REAR) GROUND CIRCUIT 2

1. Connect driver seat control unit connector.
2. Check continuity between lifting motor (rear) harness connector and ground.

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B503	31		Existed

Is the inspection result normal?

YES >> Replace lifting motor (rear). Refer to [SE-179, "Exploded View"](#).

NO >> Replace driver seat control unit. Refer to [ADP-230, "Removal and Installation"](#).

TILT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

TILT SENSOR

Description

INFOID:000000004535015

- The tilt sensor is installed to the steering column assembly.
- The resistance of tilt sensor changes according to the up/down position of steering column.
- The terminal voltage of automatic drive positioner control unit changes according to a change of tilt sensor resistance. Automatic drive positioner control unit calculates the tilt position from the voltage.

Component Function Check

INFOID:000000004535016

1. CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "TILT SEN" in the "Data monitor" mode using CONSULT-III.
3. Check the tilt sensor signal under the following condition.

Monitor item	Condition	Value
TILT SEN	Tilt position	Change between 1.1 V (Close to top) 3.9 V (Close to bottom)

Is the indication normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-113, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004535017

1. CHECK TILT SENSOR SIGNAL

1. Turn ignition switch ON.
2. Check voltage automatic drive positioner control unit harness connector and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)
Automatic drive positioner control unit Connector	Terminal			
M51	7	Ground	Tilt position	Change between 1.1 V (Close to top) 3.9 V (Close to bottom)

Is the inspection result normal?

YES >> Replace automatic drive positioner control unit. Refer to [ADP-231, "Removal and Installation"](#).

NO >> GO TO 2.

2. CHECK TILT SENSOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit and tilt & telescopic sensor connector.
3. Check continuity between automatic drive positioner control unit harness connector and tilt & telescopic sensor harness connector.

Automatic drive positioner control unit		Tilt & telescopic sensor		Continuity
Connector	Terminal	Connector	Terminal	
M51	7	M48	3	Existed

4. Check continuity between automatic drive positioner control unit harness connector and ground.

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M51	7		Not existed

Is the inspection result normal?

TILT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

- YES >> GO TO 3.
 NO >> Repair or replace harness.

3. CHECK TILT SENSOR POWER SUPPLY

1. Connect automatic drive positioner control unit connector.
2. Turn ignition switch ON.
3. Check voltage between tilt & telescopic sensor harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Tilt & telescopic sensor			
Connector	Terminal		
M48	1	Ground	5

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> GO TO 4.

4. CHECK TILT SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and tilt & telescopic sensor harness connector.

Automatic drive positioner control unit		Tilt & telescopic sensor		Continuity
Connector	Terminal	Connector	Terminal	
M52	33	M48	1	Existed

4. Check continuity between automatic drive positioner control unit harness connector and ground.

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M52	33		Not existed

Is the inspection result normal?

- YES >> Replace automatic drive positioner control unit. Refer to [ADP-231. "Removal and Installation"](#).
 NO >> Repair or replace harness.

5. CHECK TILT SENSOR GROUND CIRCUIT 1

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and tilt & telescopic sensor harness connector.

Automatic drive positioner control unit		Tilt & telescopic sensor		Continuity
Connector	Terminal	Connector	Terminal	
M52	41	M48	4	Existed

Is the inspection result normal?

- YES >> GO TO 6.
 NO >> Repair or replace harness.

6. CHECK TILT SENSOR GROUND CIRCUIT 2

1. Connect automatic drive positioner control unit connector.
2. Check continuity between automatic drive positioner control unit harness connector and ground.

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M52	41		Existed

TILT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES >> Replace tilt & telescopic sensor (Built in steering column assembly). Refer to [ST-18, "WITHOUT ELECTRIC MOTOR : Exploded View"](#).
- NO >> Replace automatic drive positioner control unit. Refer to [ADP-231, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

TELESCOPIC SENSOR

< DTC/CIRCUIT DIAGNOSIS >

TELESCOPIC SENSOR

Description

INFOID:000000004535018

- The telescopic sensor is installed to the steering column assembly.
- The resistance of telescopic sensor changes according to the forward/backward position of steering column.
- The terminal voltage of automatic drive positioner control unit changes according to a change of telescopic sensor resistance. Automatic drive positioner control unit calculates the telescopic position from the voltage.

Component Function Check

INFOID:000000004535019

1. CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "TELESCO SEN" in the "Data monitor" mode using CONSULT-III.
3. Check the tilt sensor signal under the following conditions.

Monitor item	Condition	Value
TELESCO SEN	Telescopic position	Change between 0.5 [V] (close to top) 4.5 [V] (close to bottom)

Is the indication normal?

YES >> INSPECTION END.

NO >> Perform diagnosis procedure. Refer to [ADP-116, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004535020

1. CHECK TELESCOPIC SENSOR SIGNAL

1. Turn ignition switch ON.
2. Check voltage automatic drive positioner control unit harness connector and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)
Automatic drive positioner control unit	Connector			
Terminal	Terminal	Ground	Telescopic position	Change between 0.5 [V] (close to top) 4.5 [V] (close to bottom)
M51	23	Ground	Telescopic position	Change between 0.5 [V] (close to top) 4.5 [V] (close to bottom)

Is the inspection result normal?

YES >> Replace automatic drive positioner control unit. Refer to [ADP-231, "Removal and Installation"](#).

NO >> GO TO 2.

2. CHECK TELESCOPIC SENSOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit and tilt & telescopic sensor connector.
3. Check continuity between automatic drive positioner control unit harness connector and tilt & telescopic sensor harness connector.

Automatic drive positioner control unit		Tilt & telescopic sensor		Continuity
Connector	Terminal	Connector	Terminal	
M51	23	M48	2	Existed

4. Check continuity between automatic drive positioner control unit harness connector and ground.

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M51	23		Not existed

Is the inspection result normal?

TELESCOPIC SENSOR

< DTC/CIRCUIT DIAGNOSIS >

- YES >> GO TO 3.
 NO >> Repair or replace harness.

3.CHECK TELESCOPIC SENSOR POWER SUPPLY

1. Connect automatic drive positioner control unit connector.
2. Turn ignition switch ON.
3. Check voltage between tilt & telescopic sensor harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Tilt & telescopic sensor			
Connector	Terminal		
M48	1	Ground	5

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> GO TO 4.

4.CHECK TELESCOPIC SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and tilt & telescopic sensor harness connector.

Automatic drive positioner control unit		Tilt & telescopic sensor		Continuity
Connector	Terminal	Connector	Terminal	
M52	33	M48	1	Existed

4. Check continuity between automatic drive positioner control unit harness connector and ground.

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M52	33		Not existed

Is the inspection result normal?

- YES >> Replace automatic drive positioner control unit. Refer to [ADP-231, "Removal and Installation"](#).
 NO >> Repair or replace harness.

5.CHECK TELESCOPIC SENSOR GROUND CIRCUIT 1

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and tilt & telescopic sensor harness connector.

Automatic drive positioner control unit		Tilt & telescopic sensor		Continuity
Connector	Terminal	Connector	Terminal	
M52	41	M48	4	Existed

Is the inspection result normal?

- YES >> GO TO 6.
 NO >> Repair or replace harness.

6.CHECK TELESCOPIC SENSOR GROUND CIRCUIT 2

1. Connect automatic drive positioner control unit connector.
2. Check continuity between automatic drive control unit harness connector and ground.

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M52	41		Existed

TELESCOPIC SENSOR

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES >> Replace tilt & telescopic sensor (Built in steering column assembly). Refer to [ST-18, "WITHOUT ELECTRIC MOTOR : Exploded View"](#).
- NO >> Replace automatic drive positioner control unit. Refer to [ADP-231, "Removal and Installation"](#).

MIRROR SENSOR

< DTC/CIRCUIT DIAGNOSIS >

MIRROR SENSOR

DRIVER SIDE

DRIVER SIDE : Description

INFOID:000000004535021

- The mirror sensor (driver side) is installed to the door mirror (driver side).
- The resistance of 2 sensors (horizontal and vertical) is changed when the door mirror (driver side) is operated.
- Automatic drive positioner control unit calculates the door mirror position according to the change of the voltage of 2 sensor input terminals.

DRIVER SIDE : Component Function Check

INFOID:000000004535022

1.CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "MIR/SEN LH U-D", "MIR/SEN LH R-L" in the "Data monitor" using CONSULT-III.
3. Check mirror sensor (driver side) signal under the following condition.

Monitor item	Condition	Value
MIR/SEN LH U-D	Door mirror (driver side)	Change between 3.4 [V] (close to peak) 0.6 [V] (close to valley)
MIR/SEN LH R-L		Change between 0.6 [V] (close to left edge) 3.4 [V] (close to right edge)

Is the indication normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-119. "DRIVER SIDE : Diagnosis Procedure"](#).

DRIVER SIDE : Diagnosis Procedure

INFOID:000000004535023

1.CHECK DOOR MIRROR SENSOR (DRIVER SIDE) SIGNAL

1. Turn ignition switch ON.
2. Check voltage automatic drive positioner control unit harness connector and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)
Automatic drive positioner control unit				
Connector	Terminal			
M51	6	Ground	Door mirror (Driver side) position	Change between 3.4 [V] (close to peak) 0.6 [V] (close to valley)
	22			Change between 3.4 [V] (close to left edge) 0.6 [V] (close to right edge)

Is the inspection result normal?

YES >> Replace automatic drive positioner control unit. Refer to [ADP-231. "Removal and Installation"](#).

NO >> GO TO 2.

2.CHECK DOOR MIRROR (DRIVER SIDE) SENSOR CIRCUIT

1. Turn ignition OFF.
2. Disconnect automatic drive positioner control unit connector and door mirror (drive side) connector.
3. Check continuity between automatic drive positioner control unit harness connector and door mirror (driver side) harness connector.

MIRROR SENSOR

< DTC/CIRCUIT DIAGNOSIS >

Automatic drive positioner control unit		Door mirror (driver side)		Continuity
Connector	Terminal	Connector	Terminal	
M51	6	D3	9	Existed
	22		10	

4. Check continuity between automatic drive positioner control unit harness connector and ground.

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M51	6		Not existed
	22		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK DOOR MIRROR (DRIVER SIDE) SENSOR POWER SUPPLY

1. Connect automatic drive positioner control unit connector.
2. Turn ignition switch ON.
3. Check voltage between door mirror (driver side) harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Door mirror (driver side)			
Connector	Terminal		
D3	11	Ground	5

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

4. CHECK DOOR MIRROR (DRIVER SIDE) SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and door mirror (driver side) harness connector.

Automatic drive positioner control unit		Door mirror (driver side)		Continuity
Connector	Terminal	Connector	Terminal	
M52	33	D3	11	Existed

4. Check continuity between automatic drive positioner control unit harness connector and ground.

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M52	33		Not existed

Is the inspection result normal?

YES >> Replace automatic drive positioner control unit. Refer to [ADP-231. "Removal and Installation"](#).

NO >> Repair or replace harness.

5. CHECK DOOR MIRROR (DRIVER SIDE) SENSOR GROUND 1

1. Turn ignition switch OFF.
2. Disconnect automatic drive control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and door mirror (driver side) harness connector.

MIRROR SENSOR

< DTC/CIRCUIT DIAGNOSIS >

Automatic drive positioner control unit		Door mirror (driver side)		Continuity
Connector	Terminal	Connector	Terminal	
M52	41	D3	12	Existed

Is the inspection result normal?

- YES >> GO TO 6.
 NO >> Repair or replace harness.

6.CHECK DOOR MIRROR (DRIVER SIDE) SENSOR GROUND 2

1. Connect automatic drive positioner control unit connector.
2. Check continuity between automatic drive positioner control unit harness connector and ground.

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M52	41		Existed

Is the inspection result normal?

- YES >> Replace automatic drive positioner control unit. Refer to [ADP-231, "Removal and Installation"](#).
 NO >> Replace door mirror sensor (Built in passenger side door mirror). Refer to [MIR-18, "DOOR MIRROR ASSEMBLY : Removal and Installation"](#).

PASSENGER SIDE

PASSENGER SIDE : Description

INFOID:000000004535024

- The mirror sensor (passenger side) is installed to the door mirror (passenger side).
- The resistance of 2 sensors (horizontal and vertical) is changed when the door mirror (passenger side) is operated.
- Automatic drive positioner control unit calculates the door mirror position according to the change of the voltage of 2 sensor input terminals.

PASSENGER SIDE : Component Function Check

INFOID:000000004535025

ADP

1.CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "MIR/SEN RH U-D", "MIR/SEN RH R-L" in the "Data monitor" using CONSULT-III.
3. Check the mirror sensor (passenger side) signal under the following conditions.

Monitor item	Condition	Value
MIR/SEN RH U-D	Door mirror (passenger side)	Change between 3.4 [V] (close to peak) 0.6 [V] (close to valley)
MIR/SEN RH R-L		Change between 3.4 [V] (close to left edge) 0.6 [V] (close to right edge)

Is the indication normal?

- YES >> INSPECTION END
 NO >> Perform diagnosis procedure. Refer to [ADP-121, "PASSENGER SIDE : Diagnosis Procedure"](#).

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000004535026

1.CHECK DOOR MIRROR SENSOR (PASSENGER SIDE) SIGNAL

1. Turn ignition switch ON.
2. Check voltage automatic drive positioner control unit harness connector and ground.

MIRROR SENSOR

< DTC/CIRCUIT DIAGNOSIS >

(+)		(-)	Condition	Voltage (V) (Approx.)
Automatic drive positioner control unit				
Connector	Terminal			
M51	5	Ground	Door mirror (Passenger side) position	Change between 3.4 [V] (close to peak) 0.6 [V] (close to valley)
	21			Change between 3.4 [V] (close to left edge) 0.6 [V] (close to right edge)

Is the inspection result normal?

- YES >> Replace automatic drive positioner control unit. Refer to [ADP-231. "Removal and Installation"](#).
 NO >> GO TO 2.

2. CHECK DOOR MIRROR (PASSENGER SIDE) SENSOR CIRCUIT

- Turn ignition switch OFF.
- Disconnect automatic drive positioner control unit connector and door mirror (passenger side) connector.
- Check continuity between automatic drive positioner control unit harness connector and door mirror (passenger side) harness connector.

Automatic drive positioner control unit		Door mirror (passenger side)		Continuity
Connector	Terminal	Connector	Terminal	
M51	5	D33	9	Existed
	21		10	

- Check continuity between automatic drive positioner control unit harness connector and ground.

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M51	5		Not existed
	21		

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair or replace harness.

3. CHECK DOOR MIRROR SENSOR (PASSENGER SIDE) POWER SUPPLY

- Connect automatic drive positioner control unit connector.
- Turn ignition switch ON.
- Check voltage between door mirror (passenger side) harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Door mirror (passenger side)			
Connector	Terminal		
D33	11	Ground	5

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> GO TO 4.

4. CHECK DOOR MIRROR (PASSENGER SIDE) SENSOR POWER SUPPLY CIRCUIT

- Turn ignition switch OFF.
- Disconnect automatic drive positioner control unit connector.
- Check continuity between automatic drive positioner control unit harness connector and door mirror (passenger side) harness connector.

MIRROR SENSOR

< DTC/CIRCUIT DIAGNOSIS >

Automatic drive positioner control unit		Door mirror (passenger side)		Continuity
Connector	Terminal	Connector	Terminal	
M52	33	D33	11	Existed

4. Check continuity between automatic drive positioner control unit harness connector and ground.

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M52	33		Not existed

Is the inspection result normal?

- YES >> Replace automatic driver positioner control unit. Refer to [ADP-231, "Removal and Installation"](#).
 NO >> Repair or replace harness.

5.CHECK DOOR MIRROR (PASSENGER SIDE) SENSOR GROUND 1

- Turn ignition switch OFF.
- Disconnect automatic drive positioner control unit connector.
- Check continuity between automatic drive positioner control unit harness connector and door mirror (passenger side) connector.

Automatic drive positioner control unit		Door mirror (passenger side)		Continuity
Connector	Terminal	Connector	Terminal	
M52	41	D33	12	Existed

Is the inspection result normal?

- YES >> GO TO 6.
 NO >> Repair or replace harness.

6.CHECK DOOR MIRROR (PASSENGER SIDE) SENSOR GROUND 2

- Connect automatic drive positioner control unit connector.
- Check continuity between automatic drive positioner control unit harness connector and ground.

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M52	41		Existed

Is the inspection result normal?

- YES >> Replace automatic drive positioner control unit. Refer to [ADP-231, "Removal and Installation"](#).
 NO >> Replace door mirror sensor (Built in passenger side door mirror). Refer to [MIR-18, "DOOR MIRROR ASSEMBLY : Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

SLIDING MOTOR

< DTC/CIRCUIT DIAGNOSIS >

SLIDING MOTOR

Description

INFOID:000000004535027

- The seat sliding motor is installed to the seat cushion frame.
- The seat sliding motor is activated with the driver seat control unit.
- The seat is slid forward/rearward by changing the rotation direction of sliding motor.

Component Function Check

INFOID:000000004535028

1.CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "SEAT SLIDE" in "Active test" mode using CONSULT-III.
3. Check the sliding motor operation.

Test item		Description	
SEAT SLIDE	OFF	Seat sliding	Stop
	FR		Forward
	RR		Backward

Is the operation of relevant parts normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-124, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004535029

1.CHECK SLIDING MOTOR POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect sliding motor connector.
3. Turn the ignition switch ON.
4. Perform "Active test" ("SEAT SLIDE") using CONSULT-III
5. Check voltage between sliding motor harness connector and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)	
Sliding motor					
Connector	Terminal				
B525	35	Ground	SEAT SLIDE	OFF	0
				FR (forward)	Battery voltage
				RR (backward)	0
	42			OFF	0
				FR (forward)	0
				RR (backward)	Battery voltage

Is the inspection result normal?

YES >> Replace sliding motor. (Built in seat slide cushion frame.) Refer to [SE-179, "Exploded View"](#).

NO >> GO TO 2.

2.CHECK SLIDING MOTOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between driver seat control unit harness connector and sliding motor harness connector.

SLIDING MOTOR

< DTC/CIRCUIT DIAGNOSIS >

Driver seat control unit		Sliding motor		Continuity
Connector	Terminal	Connector	Terminal	
B504	35	B525	35	Existed
	42		42	

4. Check continuity between driver seat control unit harness connector and ground.

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B504	35		Not existed
	42		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3.CHECK SLIDING MOTOR

Refer to [ADP-125. "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-230. "Removal and Installation"](#).

NO >> Replace sliding motor. (Built in seat slide cushion frame.) Refer to [SE-179. "Exploded View"](#).

Component Inspection

INFOID:000000004535030

1.CHECK SLIDING MOTOR-1

Visually check the sliding motor for foreign object, and check that the sliding motor is not broken.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace seat cushion frame (sliding motor).

2.CHECK SLIDING MOTOR-2

1. Turn ignition switch OFF.
2. Disconnect sliding motor connector.
3. Supply sliding motor terminals with battery voltage and check operation.

Terminal		Operation
(+)	(-)	
35	42	Forward
42	35	Backward

Is the inspection result normal?

YES >> Sliding motor is OK.

NO >> Replace sliding motor. (Built in seat slide cushion frame.) Refer to [SE-179. "Exploded View"](#).

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

RECLINING MOTOR

< DTC/CIRCUIT DIAGNOSIS >

RECLINING MOTOR

Description

INFOID:000000004535031

- The seat reclining motor is installed to the seat back frame.
- The seat reclining motor is activated with the driver seat control unit.
- The seatback is reclined frontward/rearward by changing the rotation direction of reclining motor.

Component Function Check

INFOID:000000004535032

1.CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "SEAT RECLINING" in "Active test" mode using CONSULT-III.
3. Check the reclining motor operation.

Test item		Description	
SEAT RECLINING	OFF	Seat reclining	Stop
	FR		Forward
	RR		Backward

Is the operation of relevant parts normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-126, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004535033

1.CHECK RECLINING MOTOR POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect reclining motor connector.
3. Turn the ignition switch ON.
4. Perform "Active test" ("SEAT RECLINING") using CONSULT-III
5. Check voltage between reclining motor harness connector and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)	
Reclining motor					
Connector	Terminal				
B523	36	Ground	SEAT RECLINING	OFF	0
			FR (forward)	Battery voltage	
			RR (backward)	0	
	44		SEAT RECLINING	OFF	0
			FR (forward)	0	
			RR (backward)	Battery voltage	

Is the inspection result normal?

YES >> Replace reclining motor. (Built in seat back frame.) Refer to [SE-179, "Exploded View"](#).

NO >> GO TO 2.

2.CHECK RECLINING MOTOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between driver seat control unit harness connector and reclining motor harness connector.

RECLINING MOTOR

< DTC/CIRCUIT DIAGNOSIS >

Driver seat control unit		Reclining motor		Continuity
Connector	Terminal	Connector	Terminal	
B504	36	B523	36	Existed
	44		44	

4. Check continuity between driver seat control unit harness connector and ground.

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B504	36		Not existed
	44		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3.CHECK RECLINING MOTOR

Refer to [ADP-127. "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-230. "Removal and Installation"](#).

NO >> Replace reclining motor. (Built in seat slide cushion frame.) Refer to [SE-179. "Exploded View"](#).

Component Inspection

INFOID:000000004535034

1.CHECK RECLINING MOTOR-1

Visually check the reclining motor for foreign object, and check that the reclining motor is not broken.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace seatback frame (reclining motor).

2.CHECK RECLINING MOTOR-2

1. Turn ignition switch OFF.
2. Disconnect reclining motor connector.
3. Supply reclining motor terminals with battery voltage and check operation.

Terminal		Operation
(+)	(-)	
36	44	Forward
44	36	Backward

Is the inspection result normal?

YES >> Reclining motor is OK.

NO >> Replace reclining motor. (Built in seat slide cushion frame.) Refer to [SE-179. "Exploded View"](#).

LIFTING MOTOR (FRONT)

< DTC/CIRCUIT DIAGNOSIS >

LIFTING MOTOR (FRONT)

Description

INFOID:000000004535035

- The lifting motor (front) is installed to the seat slide cushion frame.
- The lifting motor (front) is activated with the driver seat control unit.
- The lifter (front) is moved upward/downward by changing the rotation direction of lifting motor (front).

Component Function Check

INFOID:000000004535036

1. CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "SEAT LIFTER FR" in "Active test" mode using CONSULT-III.
3. Check the lifting motor (front) operation.

Test item		Description	
SEAT LIFTER FR	OFF	Seat lifting (front)	Stop
	UP		Upward
	DWN		Downward

Is the operation of relevant parts normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-128, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004535037

1. CHECK LIFTING MOTOR (FRONT) POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect lifting motor (front) connector.
3. Turn the ignition switch ON.
4. Perform "Active test" ("SEAT LIFTER FR") using CONSULT-III.
5. Check voltage between lifting motor (front) harness connector and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)	
Lifting motor (front)					
Connector	Terminal				
B527	37	Ground	SEAT LIFTER FR	OFF	0
				UP	0
				DWN (down)	Battery voltage
	45			OFF	0
				UP	Battery voltage
				DWN (down)	0

Is the inspection result normal?

YES >> Replace lifting motor (front). (Built in seat slide cushion frame.) Refer to [SE-179, "Exploded View"](#).

NO >> GO TO 2.

2. CHECK LIFTING MOTOR (FRONT) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between driver seat control unit harness connector and lifting motor (front) harness connector.

LIFTING MOTOR (FRONT)

< DTC/CIRCUIT DIAGNOSIS >

Driver seat control unit		Lifting motor (front)		Continuity
Connector	Terminal	Connector	Terminal	
B504	37	B527	37	Existed
	45		45	

4. Check continuity between driver seat control unit harness connector and ground.

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B504	37		Not existed
	45		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3.CHECK LIFTING MOTOR (FRONT)

Refer to [ADP-129. "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-230. "Removal and Installation"](#).

NO >> Replace lifting motor (front). (Built in seat slide cushion frame.) Refer to [SE-179. "Exploded View"](#).

Component Inspection

INFOID:000000004535038

1.CHECK LIFTING MOTOR-1

Visually the lifting motor (front) for foreign object, and check that the lifting motor (front) is not broken.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace seat cushion frame (lifting motor).

2.CHECK LIFTING MOTOR-2

1. Turn ignition switch OFF.
2. Disconnect lifting motor connector.
3. Supply lifting motor terminals with battery voltage and check operation.

Item	Terminal		Operation
	(+)	(-)	
Lifting motor (front)	45	37	Up
	37	45	Down

Is the inspection result normal?

YES >> Lifting motor (front) is OK.

NO >> Replace lifting motor (front). (Built in seat slide cushion frame.) Refer to [SE-179. "Exploded View"](#).

LIFTING MOTOR (REAR)

< DTC/CIRCUIT DIAGNOSIS >

LIFTING MOTOR (REAR)

Description

INFOID:000000004535039

- The lifting motor (rear) is installed to the seat slide cushion frame.
- The lifting motor (rear) is activated with the driver seat control unit.
- The seat lifter (rear) is moved upward/downward by changing the rotation direction of lifting motor (rear).

Component Function Check

INFOID:000000004535040

1. CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "SEAT LIFTER RR" in "Active test" mode using CONSULT-III.
3. Check the lifting motor (rear) operation.

Test item		Description	
SEAT LIFTER RR	OFF	Seat lifting (rear)	Stop
	UP		Upward
	DWN		Downward

Is the operation of relevant parts normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-130, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004535041

1. CHECK LIFTING MOTOR (REAR) POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect lifting motor (rear) connector.
3. Turn the ignition switch ON.
4. Perform "Active test" ("SEAT LIFTER RR") using CONSULT-III
5. Check voltage between lifting motor (rear) harness connector and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)	
Lifting motor (rear)					
Connector	Terminal				
B529	38	Ground	SEAT LIFTER RR	OFF	0
				UP	Battery voltage
	DWN (DOWN)			0	
	OFF			0	
	UP			0	
	DWN (DOWN)			Battery voltage	
39					

Is the inspection result normal?

YES >> Replace lifting motor (rear). (Built in seat slide cushion frame.) Refer to [SE-179, "Exploded View"](#).

NO >> GO TO 2.

2. CHECK LIFTING MOTOR (REAR) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector and lifting motor (rear) connector.
3. Check continuity between driver seat control unit harness connector and lifting motor (rear) harness connector.

LIFTING MOTOR (REAR)

< DTC/CIRCUIT DIAGNOSIS >

Driver seat control unit		Lifting motor (rear)		Continuity
Connector	Terminal	Connector	Terminal	
B504	38	B529	38	Existed
	39		39	

4. Check continuity between driver seat control unit harness connector and ground.

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B504	38		Not existed
	39		

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace harness.

3.CHECK LIFTING MOTOR (REAR)

Refer to [ADP-131, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace driver seat control unit. Refer to [ADP-230, "Removal and Installation"](#).
NO >> Replace lifting motor (rear). (Built in seat slide cushion frame.) Refer to [SE-179, "Exploded View"](#).

Component Inspection

INFOID:000000004535042

1.CHECK LIFTING MOTOR-1

Visually the lifting motor (rear) for foreign object, and check that the lifting motor (rear) is not broken.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace seat cushion frame (lifting motor).

2.CHECK LIFTING MOTOR-2

1. Turn ignition switch OFF.
2. Disconnect lifting motor connector.
3. Supply lifting motor terminals with battery voltage and check operation.

Item	Terminal		Operation
	(+)	(-)	
Lifting motor (rear)	38	39	Up
	39	38	Down

Is the inspection result normal?

- YES >> Lifting motor (rear) is OK.
NO >> Replace lifting motor (rear). (Built in seat slide cushion frame.) Refer to [SE-179, "Exploded View"](#).

TILT MOTOR

< DTC/CIRCUIT DIAGNOSIS >

TILT MOTOR

Description

INFOID:000000004535043

- The tilt motor is installed to the steering column assembly.
- The tilt motor is activated with the automatic drive positioner control unit.
- The steering column is tilted upward/downward by changing the rotation direction of tilt motor.

Component Function Check

INFOID:000000004535044

1.CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "TILT MOTOR" in "Active test" mode using CONSULT-III.
3. Check the tilt motor operation.

Test item		Description	
TILT MOTOR	OFF	Steering tilt	Stop
	UP		Upward
	DWN		Downward

Is the operation of relevant parts normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-132, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004535045

1.CHECK TILT MOTOR POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect tilt & telescopic motor connector.
3. Turn ignition switch ON.
4. Perform "Active test" ("TILT MOTOR") using CONSULT-III.
5. Check voltage between tilt & telescopic motor harness connector and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)	
Connector	Terminal				
M49	3	Ground	TILT MOTOR	OFF	0
			UP	0	
			DWN (down)	Battery voltage	
	4		OFF	0	
			UP	Battery voltage	
			DWN (down)	0	

Is the inspection result normal?

YES >> Replace tilt motor. (Built in steering column assembly.) Refer to [ST-21, "WITH ELECTRIC MOTOR : Exploded View"](#).

NO >> GO TO 2.

2.CHECK TILT MOTOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and tilt & telescopic motor harness connector.

TILT MOTOR

< DTC/CIRCUIT DIAGNOSIS >

Automatic drive positioner control unit		Tilt & telescopic motor		Continuity
Connector	Terminal	Connector	Terminal	
M52	35	M49	4	Existed
	42		3	

4. Check continuity between automatic drive positioner control unit harness connector and ground.

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M52	35		Not existed
	42		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3.CHECK TILT MOTOR

Refer to [ADP-133, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace automatic drive positioner control unit. Refer to [ADP-231, "Removal and Installation"](#).

NO >> Replace tilt motor. (Built in steering column assembly.) Refer to [ST-21, "WITH ELECTRIC MOTOR : Exploded View"](#).

Component Inspection

INFOID:000000004535046

1.CHECK SLIDING MOTOR

1. Turn ignition switch OFF.
2. Disconnect tilt motor connector.
3. Supply tilt motor terminals with battery voltage and check operation.

Terminal		Operation
(+)	(-)	
4	3	Up
3	4	Down

Is the inspection result normal?

YES >> Tilt motor is OK.

NO >> Replace tilt motor. (Built in steering column assembly.) Refer to [ST-21, "WITH ELECTRIC MOTOR : Exploded View"](#).

ADP

TELESCOPIC MOTOR

< DTC/CIRCUIT DIAGNOSIS >

TELESCOPIC MOTOR

Description

INFOID:000000004535047

- The telescopic motor is installed to the steering column assembly.
- The telescopic motor is activated with the automatic drive positioner control unit.
- Compresses the steering column by changing the rotation direction of telescopic motor.

Component Function Check

INFOID:000000004535048

1. CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "TELESCO MOTOR" in "Active test" mode using CONSULT-III.
3. Check the telescopic motor operation.

Test item		Description	
TELESCO MOTOR	OFF	Steering telescopic	Stop
	FR		Forward
	RR		Backward

Is the operation of relevant parts normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-134, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004535049

1. CHECK TELESCOPIC MOTOR POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect tilt & telescopic motor connector.
3. Turn ignition switch ON.
4. Perform "Active test" ("TELESCO MOTOR") using CONSULT-III
5. Check voltage between tilt & telescopic motor harness connector and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)	
Connector	Terminal				
M49	1	Ground	TELESCOPIC MO- TOR	OFF	0
			FR (forward)	0	
			RR (backward)	Battery voltage	
	2		OFF	0	
			FR (forward)	Battery voltage	
			RR (backward)	0	

Is the inspection result normal?

YES >> Replace telescopic motor. (Built in steering column assembly.) Refer to [ST-21, "WITH ELECTRIC MOTOR : Exploded View"](#).

NO >> GO TO 2.

2. CHECK TELESCOPIC MOTOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and tilt & telescopic motor harness connector.

TELESCOPIC MOTOR

< DTC/CIRCUIT DIAGNOSIS >

Automatic drive positioner control unit		Tilt & telescopic motor		Continuity
Connector	Terminal	Connector	Terminal	
M52	36	M49	2	Existed
	44		1	

4. Check continuity between automatic drive positioner control unit harness connector and ground.

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M52	36		Not existed
	44		

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair or replace harness.

3.CHECK SLIDING MOTOR

Refer to [ADP-135. "Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace automatic drive positioner control unit. Refer to [ADP-231. "Removal and Installation"](#).
 NO >> Replace telescopic motor. (Built in steering column assembly.) Refer to [ST-21. "WITH ELECTRIC MOTOR : Exploded View"](#).

Component Inspection

INFOID:000000004535050

1.CHECK SLIDING MOTOR-2

- Turn ignition switch OFF.
- Disconnect telescopic motor connector.
- Supply telescopic motor terminals with battery voltage and check operation.

Terminal		Operation
(+)	(-)	
2	1	Forward
1	2	Backward

Is the inspection result normal?

- YES >> Telescopic motor is OK.
 NO >> Replace telescopic motor. (Built in steering column assembly.) Refer to [ST-21. "WITH ELECTRIC MOTOR : Exploded View"](#).

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

DOOR MIRROR MOTOR

< DTC/CIRCUIT DIAGNOSIS >

DOOR MIRROR MOTOR

Description

INFOID:000000004535051

It makes mirror face operate from side to side and up and down with the electric power that automatic drive positioner control unit supplies.

Component Function Check

INFOID:000000004535052

1. CHECK DOOR MIRROR MOTOR FUNCTION

1. Turn ignition switch ON.
2. Select "DOOR MIRROR MOTOR LH" and "DOOR MIRROR MOTOR RH" in "Active test" mode using CONSULT-III.
3. Check the door mirror motor operation.

Test item		Description	
DOOR MIRROR MOTOR LH	OFF	Door mirror face	Stop
	L		Outward
	R		Inward
	UP		Upward
	DWN		Downward

Test item		Description	
DOOR MIRROR MOTOR RH	OFF	Door mirror face	Stop
	L		Inward
	R		Outward
	UP		Upward
	DWN		Downward

Is the operation of relevant parts normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-136, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004535053

1. CHECK DOOR MIRROR MOTOR INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect door mirror connector.
3. Turn ignition switch ON.
4. Check voltage between door mirror connector and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)	
Door mirror					
Connector	Terminal				
D3 (Driver side) D33 (Passenger side)	5	Ground	Door mirror remote control switch	UP	Battery voltage
				Other than above	0
	6			LEFT	Battery voltage
				Other than above	0
	7			DOWN / RIGHT	Battery voltage
				Other than above	0

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

DOOR MIRROR MOTOR

< DTC/CIRCUIT DIAGNOSIS >

2.CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit connector and door mirror connector.

[Door mirror driver side]

Automatic drive positioner control unit		Door mirror (driver side)		Continuity
Connector	Terminal	Connector	Terminal	
M51	16	D3	7	Existed
	31		5	
	32		6	

[Door mirror passenger side]

Automatic drive positioner control unit		Door mirror (passenger side)		Continuity
Connector	Terminal	Connector	Terminal	
M51	14	D33	5	Existed
	15		6	
	30		7	

4. Check continuity between automatic drive positioner control unit connector and ground.

[Door mirror driver side]

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M51	16	Ground	Not existed
	31		
	32		

[Door mirror passenger side]

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M51	14	Ground	Not existed
	15		
	30		

Is the inspection result normal?

- YES >> Replace automatic drive positioner control unit. Refer to [ADP-231, "Removal and Installation"](#).
NO >> Repair or replace harness.

3.CHECK DOOR MIRROR MOTOR

Check door mirror motor.

Refer to [ADP-137, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Replace door mirror. Refer to [MIR-18, "DOOR MIRROR ASSEMBLY : Removal and Installation"](#).

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000004535054

1.CHECK DOOR MIRROR MOTOR-I

Check that door mirror motor does not trap foreign objects and does not have any damage.

Refer to [MIR-17, "DOOR MIRROR ASSEMBLY : Exploded View"](#).

DOOR MIRROR MOTOR

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace door mirror. Refer to [MIR-18, "DOOR MIRROR ASSEMBLY : Removal and Installation"](#).

2. CHECK DOOR MIRROR MOTOR-II

1. Turn ignition switch OFF.
2. Disconnect door mirror connector.
3. Apply 12V to each power supply terminal of door mirror motor.

Door mirror			Operational direction
Connector	Terminal		
	(+)	(-)	
D3 (Driver side) D33 (Passenger side)	7	6	RIGHT
	6	7	LEFT
	5	7	UP
	7	5	DOWN

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace door mirror. Refer to [MIR-18, "DOOR MIRROR ASSEMBLY : Removal and Installation"](#).

SEAT MEMORY INDICATOR

< DTC/CIRCUIT DIAGNOSIS >

SEAT MEMORY INDICATOR

Description

INFOID:000000004535055

- Memory indicator is equipped on the seat memory switch installed to the driver side door trim. The operation signal is inputted to the automatic drive positioner control unit when the memory switch is operated.
- The status of automatic drive positioner system can be checked according to the illuminating/flashing status.

Component Function Check

INFOID:000000004535056

1. CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "MEMORY SW INDCTR" in "Active test" mode using CONSULT-III.
3. Check the memory indicator operation.

Test item		Description	
MEMORY SW INDCTR	OFF	Memory switch indicator	OFF
	ON-1		Indicator 1: ON
	ON-2		Indicator 2: ON

Is the operation of relevant parts normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-139, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004535057

1. CHECK MEMORY INDICATOR POWER SUPPLY

Check voltage between seat memory switch harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Seat memory switch			
Connector	Terminal	Ground	Battery voltage
D5	5		

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check the following.

- 10A fuse [No.10 located in fuse block (J/B)].
- Harness for open or short between memory indicator and fuse.

2. CHECK MEMORY INDICATOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit and seat memory switch connector.
3. Check continuity between automatic drive positioner control unit harness connector and seat memory switch harness connector.

Automatic drive positioner control unit		Seat memory switch		Continuity
Connector	Terminal	Connector	Terminal	
M51	12	D5	6	Existed
	13		7	

4. Check continuity between automatic drive positioner control unit harness connector and ground.

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M51	12		Not existed
	13		

SEAT MEMORY INDICATOR

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES >> Replace seat memory switch. Refer to [ADP-232, "Removal and Installation"](#).
- NO >> Repair or replace harness.

DOOR MIRROR SYSTEM


< DTC/CIRCUIT DIAGNOSIS >

DOOR MIRROR SYSTEM

Wiring Diagram - DOOR MIRROR (WITH AUTOMATIC DRIVE POSITIONER) -

INFOID:000000004684734

DOOR MIRROR (WITH AUTOMATIC DRIVE POSITIONER)



2008/08/22

JCLWM2661GE


A
B
C
D
E
F
G
H
I
ADP
K
L
M
N
O
P

DOOR MIRROR SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

DOOR MIRROR (WITH AUTOMATIC DRIVE POSITIONER)

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



40	17	1	13	19
60	67	33	21	48
32	66	5	48	21
33	67	33	21	48



Connector No.	B11
Connector Name	WIRE TO WIRE
Connector Type	NS16FW-CS



19	3	1	17	40
5	66	32	48	21
33	67	33	21	48



Connector No.	B502
Connector Name	WIRE TO WIRE
Connector Type	NS16MW-LC



1	3	4	5	8	9	10	11	12	13	14	15
17	19	121	124	25	26	27	28	29	30	31	32



Connector No.	B503
Connector Name	DRIVER SEAT CONTROL UNIT
Connector Type	TH82FW




Terminal No.	Color of Wire	Signal Name [Specification]
16	BR	-
17	LG	-
18	G	-
20	P	-
21	P	-
39	SB	-

Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
3	L	-
17	LG	-
19	P	-
32	B	-
33	SB	-
40	BR	-
48	B	-

Terminal No.	Color of Wire	Signal Name [Specification]
1	L/W	-
3	R/Y	-
17	Y/R	-
19	V	-
32	B/W	-
33	R	-
40	R/W	-
48	B	-


Terminal No.	Color of Wire	Signal Name [Specification]
1	L/W	RX
3	R/Y	GAN-H
17	Y/R	TX
19	V	GAN-L
32	B/W	GND (SIGNAL)

Connector No.	B504
Connector Name	DRIVER SEAT CONTROL UNIT
Connector Type	NS16FW-CS



33	35	36	37	38	39
40	41	42	44	45	48

Connector No.	D1
Connector Name	WIRE TO WIRE
Connector Type	TH40FW-CS15



Terminal No.	Color of Wire	Signal Name [Specification]
33	R	BAT (C/B)
40	R/W	BAT (FUSE)
48	B	GND (POWER)

Connector No.	D3
Connector Name	DOOR MIRROR (DRIVER SIDE)
Connector Type	TH12MW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
5	BR	-
6	GR	- [With automatic drive positioner]
7	G	- [With automatic drive positioner]

Connector No.	D17
Connector Name	DOOR MIRROR REMOTE CONTROL SWITCH (WITH AUTOMATIC DRIVE POSITIONER)
Connector Type	TK16FBFR



1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16	17	18	19	20	21

Terminal No.	Color of Wire	Signal Name [Specification]
4	BR	-
7	B	-
10	GR	-
11	LG	-
12	G	-
13	W	-
15	Y	-

JCLWMM2663GE

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

DOOR MIRROR SYSTEM

< DTC/CIRCUIT DIAGNOSIS >


DOOR MIRROR (WITH AUTOMATIC DRIVE POSITIONER)

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS30FW-M2



Terminal No.	7A	Color of Wire	R	Signal Name [Specification]	
--------------	----	---------------	---	-----------------------------	--

Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4




Terminal No.	91	Color of Wire	G	Signal Name [Specification]	
--------------	----	---------------	---	-----------------------------	--

Connector No.	D33
Connector Name	DOOR MIRROR (PASSENGER SIDE)
Connector Type	TH12MF-NH




Terminal No.	5	Color of Wire	O	Signal Name [Specification]	
6	GR				
7	G				

Connector No.	D31
Connector Name	WIRE TO WIRE
Connector Type	TH40FW-CS15




Terminal No.	38	Color of Wire	O	Signal Name [Specification]	
39	GR				
40	G				

Connector No.	M24
Connector Name	DATA LINK CONNECTOR
Connector Type	BD10FW-P




Terminal No.	6	Color of Wire	L	Signal Name [Specification]	
14	P				

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4




Terminal No.	16	Color of Wire	BR	Signal Name [Specification]	
17	P				
18	V				
20	L				
21	P				
99	P				

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4



Terminal No.	91	Color of Wire	W	Signal Name [Specification]	
--------------	----	---------------	---	-----------------------------	--

Connector No.	M5
Connector Name	WIRE TO WIRE
Connector Type	TH40MW-CS15



Terminal No.	13	Color of Wire	B	Signal Name [Specification]	
27	P				
28	LG				
29	SB				
30	G				
31	V				
32	BR				
38	G				
39	L				
40	Y				


JCLW2664GE

DOOR MIRROR SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

DOOR MIRROR (WITH AUTOMATIC DRIVE POSITIONER)

Connector No.	M51
Connector Name	AUTOMATIC DRIVE POSITIONER CONTROL UNIT
Connector Type	TH22FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
2	LG	MIRROR SELECT SW (RH)
3	G	MIRROR SW (UPWARD)
4	V	MIRROR SW (LEFTWARD)
10	V	TX (UART)
14	W	MIRROR MOTOR (RH VERTICAL)
15	O	MIRROR MOTOR (RH HORIZONTAL)
16	Y	MIRROR MOTOR (LF COMMON)
18	P	MIRROR SELECT SW (LH)
19	SB	MIRROR SW (DOWNWARD)
20	BR	MIRROR SW (RIGHTWARD)
26	P	RX (UART)

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	MG3FB-LC




Terminal No.	Color of Wire	Signal Name [Specification]
1	W	BAT (F/L)

30	SB	MIRROR MOTOR (RH COMMON)
31	G	MIRROR MOTOR (LH VERTICAL)
32	L	MIRROR MOTOR (LH HORIZONTAL)



Terminal No.	Color of Wire	Signal Name [Specification]
34	V	BAT (FUSE)
39	W	BAT (G/B)
40	B	GND(SIGNAL)
48	B	GND(POWER)

Connector No.	M122
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH




Terminal No.	Color of Wire	Signal Name [Specification]
90	P	CAN-L
91	L	CAN-H

Connector No.	M62
Connector Name	CIRCUIT BREAKER
Connector Type	MG2FW-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	
2	P	

Connector No.	M124
Connector Name	WIRE TO WIRE
Connector Type	TH40MW-CS15



Terminal No.	Color of Wire	Signal Name [Specification]
38	W	
39	O	
40	SB	

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

DRIVER SEAT CONTROL UNIT (WITH AUTOMATIC DRIVE POSITIONER)

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION

DRIVER SEAT CONTROL UNIT (WITH AUTOMATIC DRIVE POSITIONER)

Reference Value

INFOID:000000004555928

VALUES ON THE DIAGNOSIS TOOL

CONSULT-III MONITOR ITEM

Monitor Item	Condition	Value/Status	
SET SW	Set switch	Push	ON
		Release	OFF
MEMORY SW1	Memory switch 1	Push	ON
		Release	OFF
MEMORY SW2	Memory switch 2	Push	ON
		Release	OFF
SLIDE SW-FR	Sliding switch (front)	Operate	ON
		Release	OFF
SLIDE SW-RR	Sliding switch (rear)	Operate	ON
		Release	OFF
RECLN SW-FR	Reclining switch (front)	Operate	ON
		Release	OFF
RECLN SW-RR	Reclining switch (rear)	Operate	ON
		Release	OFF
LIFT FR SW-UP	Lifting switch front (up)	Operate	ON
		Release	OFF
LIFT FR SW-DN	Lifting switch front (down)	Operate	ON
		Release	OFF
LIFT RR SW-UP	Lifting switch rear (up)	Operate	ON
		Release	OFF
LIFT RR SW-DN	Lifting switch rear (down)	Operate	ON
		Release	OFF
MIR CON SW-UP	Mirror switch	Up	ON
		Other than above	OFF
MIR CON SW-DN	Mirror switch	Down	ON
		Other than above	OFF
MIR CON SW-RH	Mirror switch	Right	ON
		Other than above	OFF
MIR CON SW-LH	Mirror switch	Left	ON
		Other than above	OFF
MIR CHNG SW-R	Changeover switch	Right	ON
		Other than above	OFF
MIR CHNG SW-L	Changeover switch	Left	ON
		Other than above	OFF
TILT SW-UP	Tilt switch	Up	ON
		Other than above	OFF
TILT SW-DOWN	Tilt switch	Down	ON
		Other than above	OFF

DRIVER SEAT CONTROL UNIT (WITH AUTOMATIC DRIVE POSITIONER)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition		Value/Status
TELESCO SW-FR	Telescopic switch	Forward	ON
		Other than above	OFF
TELESCO SW-RR	Tilt switch	Backward	ON
		Other than above	OFF
FORWARD SW	Seat back	Folded down	ON
		Other than above	OFF
WALK-IN SW	Power walk-in switch	Pressed	ON
		Other than above	OFF
FWD LIMIT SW	Seat sliding	Front edge	ON
		Other than above	OFF
SEAT BELT SW	Seat belt	Fastened	ON
		Other than above	OFF
DETENT SW*1	A/T selector lever	P position	OFF
		Other than above	ON
PARK BRAKE SW*2	Parking brake	Applied	ON
		Release	OFF
STARTER SW	Ignition position	Cranking	ON
		Other than above	OFF
SLIDE PULSE	Seat sliding	Forward	The numeral value decreases *3
		Backward	The numeral value increases *3
		Other than above	No change to numeral value*3
RECLN PULSE	Seat reclining	Forward	The numeral value decreases *3
		Backward	The numeral value increases *3
		Other than above	No change to numeral value*3
LIFT FR PULSE	Seat lifter (front)	Up	The numeral value decreases *3
		Down	The numeral value increases *3
		Other than above	No change to numeral value*3
LIFT RR PULSE	Seat lifter (rear)	Up	The numeral value decreases *3
		Down	The numeral value increases *3
		Other than above	No change to numeral value*3
MIR/SEN RH U-D	Door mirror (passenger side)	Change between 3.4 (close to peak) 0.6 (close to valley)	
MIR/SEN RH R-L	Door mirror (passenger side)	Change between 3.4 (close to left edge) 0.6 (close to right edge)	
MIR/SEN LH U-D	Door mirror (driver side)	Change between 3.4 (close to peak) 0.6 (close to valley)	
MIR/SEN LH R-L	Door mirror (driver side)	Change between 0.6 (close to left edge) 3.4 (close to right edge)	
TILT SEN	Tilt position	Change between 1.2 (close to top) 3.4 (close to bottom)	
TELESCO SEN	Telescopic position	Change between 3.4 (close to top) 0.8 (close to bottom)	

*1: A/T model

*2: M/T model

*3: The value at the position attained when the battery is connected is regarded as 32768.


A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

DRIVER SEAT CONTROL UNIT (WITH AUTOMATIC DRIVE POSITIONER)

< ECU DIAGNOSIS INFORMATION >

TERMINAL LAYOUT







PHYSICAL VALUES

Terminal No.		Description		Condition	Voltage (V) (Approx)	
+	-	Signal name	Input/ Output			
1 L/W	Ground	UART communication (RX)	Input	Ignition switch ON	<p style="text-align: right;">JMJA0118ZZ</p>	
3 R/Y	—	CAN-H	—	—	—	
4 O/B	Ground	Sliding limit switch signal	Input	Seat sliding front edge	0	
				Seat switch & power walk-in switch is pressed	5	
5 L	Ground	Seat belt buckle switch signal (driver side)	Input	Seat belt fastened & seat switch pressed	5	
				Other than above	0	
8 L/Y	Ground	Parking brake switch signal	Input	Parking brake	Applied	0
					Release	Battery voltage
9 W/G	Ground	Reclining sensor signal	Input	Seat reclining	Operate	<p style="text-align: right;">JMJA0119ZZ</p>
					Stop	0 or 5
10 P/B	Ground	Lifting sensor (rear) signal	Input	Seat lifting (rear)	Operate	<p style="text-align: right;">JMJA0119ZZ</p>
					Stop	0 or 5

DRIVER SEAT CONTROL UNIT (WITH AUTOMATIC DRIVE POSITIONER)

< ECU DIAGNOSIS INFORMATION >

Terminal No.		Description		Condition		Voltage (V) (Approx)
+	-	Signal name	Input/ Output			
11 (BR)	Ground	Sliding switch backward signal	Input	Sliding switch	Operate (backward)	0
					Release	Battery voltage
12 (SB)	Ground	Reclining switch backward signal	Input	Reclining switch	Operate (backward)	0
					Release	Battery voltage
13 (LG/R)	Ground	Lifting switch (front) downward signal	Input	Lifting switch (front)	Operate (downward)	0
					Release	Battery voltage
14 (GB)	Ground	Lifting switch (rear) downward signal	Input	Lifting switch (rear)	Operate (downward)	0
					Release	Battery voltage
16 (O)	Ground	Sensor power supply	Output	—		Battery voltage
17 (Y/R)	Ground	UART communication (TX)	Output	Ignition switch ON		
19 (V)	—	CAN-L	—	—	—	
21 (L/Y)	Ground	Detention switch switch	Input	A/T selector lever	P position	0
					Except P position	
24 (R)	Ground	Sliding sensor signal	Input	Seat sliding	Operate	
					Stop	0 or 5
25 (Y/B)	Ground	Lifting sensor (front) signal	Input	Seat lifting (front)	Operate	
					Stop	0 or 5

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

DRIVER SEAT CONTROL UNIT (WITH AUTOMATIC DRIVE POSITIONER)

< ECU DIAGNOSIS INFORMATION >

Terminal No.		Description		Condition		Voltage (V) (Approx)
+	-	Signal name	Input/ Output			
26 (Y)	Ground	Sliding switch forward signal	Input	Sliding switch	Operate (forward)	0
					Release	Battery voltage
27 (R/G)	Ground	Reclining switch forward signal	Input	Reclining switch	Operate (forward)	0
					Release	Battery voltage
28 (W/B)	Ground	Lifting switch (front) upward signal	Input	Seat lifting switch (front)	Operate (upward)	0
					Release	Battery voltage
29 (P/L)	Ground	Lifting switch (rear) upward signal	Input	Seat lifting switch (rear)	Operate (upward)	0
					Release	Battery voltage
30 (P)	Ground	Power walk-in switch signal	Input	Power walk-in switch	Pressed	0
					Other than above	Battery voltage
31 (GR)	Ground	Sensor ground	—	—	—	0
32 (B/W)	Ground	Ground (signal)	—	—	—	0
33 (R)	Ground	Power source (C/B)	Input	—	—	Battery voltage
35 (W/R)	Ground	Sliding motor forward output	Output	Seat sliding	Operate (forward)	Battery voltage
					Release	0
36 (G/Y)	Ground	Reclining motor forward output signal	Output	Seat reclining	Operate (forward)	Battery voltage
					Release	0
37 (G/W)	Ground	Lifting motor (front) downward output	Output	Seat lifting (front)	Operate (downward)	Battery voltage
					Stop	0
38 (L/Y)	Ground	Lifting motor (rear) upward output	Output	Seat lifting (rear)	Operate (upward)	Battery voltage
					Stop	0
39 (R/B)	Ground	Lifting motor (rear) downward output	Output	Seat lifting (rear)	Operate (downward)	Battery voltage
					Stop	0
40 (R/W)	Ground	Power source (Fuse)	Input	—	—	Battery voltage
41 (Y/G)	Ground	Forward switch signal	Input	Seat back is floded down and power walk-in switch pressed		0
				Seat back is fold up and seat rclining is operation		battery voltage
				Seat back is fold up and power walk-in switch is pressed		5
42 (W)	Ground	Sliding motor backward output	Output	Seat sliding	Operate (backward)	Battery voltage
					Stop	0

DRIVER SEAT CONTROL UNIT (WITH AUTOMATIC DRIVE POSITIONER)

< ECU DIAGNOSIS INFORMATION >

Terminal No.		Description		Condition	Voltage (V) (Approx)
+	-	Signal name	Input/ Output		
44 (P)	Ground	Reclining motor backward output	Output	Seat reclining	Battery voltage
				Operate (backward)	0
45 (L/R)	Ground	Lifting motor (front) upward output	Output	Seat lifting (front)	Battery voltage
				Operate (upward)	0
48 (B)	Ground	Ground (power)	—	—	0

A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O


P

DRIVER SEAT CONTROL UNIT (WITH AUTOMATIC DRIVE POSITIONER)

< ECU DIAGNOSIS INFORMATION >

Wiring Diagram - AUTOMATIC DRIVE POSITIONER CONTROL SYSTEM -

INFOID:000000004250399




2008/08/22

JCJWM0667GE

DRIVER SEAT CONTROL UNIT (WITH AUTOMATIC DRIVE POSITIONER)


< ECU DIAGNOSIS INFORMATION >



A
B
C
D
E
F
G
H
I
ADP
K
L
M
N
O
P

DRIVER SEAT CONTROL UNIT (WITH AUTOMATIC DRIVE POSITIONER)

< ECU DIAGNOSIS INFORMATION >




DRIVER SEAT CONTROL UNIT (WITH AUTOMATIC DRIVE POSITIONER)

< ECU DIAGNOSIS INFORMATION >


AUTOMATIC DRIVE POSITIONER

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	THBDFW-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
15	Y	-
16	BR	-
17	LG	-
18	G	-
20	L	-
21	P	-
71	V	-
95	V	-
98	SB	-

Connector No.	B16
Connector Name	DRIVER SIDE DOOR SWITCH
Connector Type	A03FW




Terminal No.	Color of Wire	Signal Name [Specification]
2	V	-

Connector No.	B11
Connector Name	WIRE TO WIRE
Connector Type	NSI (P/W)-CS




Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
3	L	-
5	BR	-
17	LG	-
19	P	-
21	Y	-
32	B	-
33	SB	-
40	BR	-
48	B	-

Connector No.	B502
Connector Name	WIRE TO WIRE
Connector Type	NSI (BMW)-LC




Terminal No.	Color of Wire	Signal Name [Specification]
1	L/W	-
3	R/Y	-
5	L	-
17	Y/R	-
19	V	-
21	L/Y	-
32	B/W	-
33	R	-
40	R/W	-
48	B	-

Connector No.	B13
Connector Name	SEAT BELT BUCKLE SWITCH (DRIVER SIDE)
Connector Type	A03FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	B	-

Connector No.	B503
Connector Name	DRIVER SEAT CONTROL UNIT
Connector Type	THB2FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	L/W	RX
3	R/Y	CAN-H
4	O/B	SLIDING LIMIT SW
5	L	BUCKLE SW
8	L/Y	P RANGE SW
9	W/G	PULSE (RECLINING)
10	P/B	PULSE (RR LIFTING)
11	BR	SLIDING SW (BACKWARD)
12	SB	RECLINING SW (BACKWARD)
13	LG/R	FRONT LIFTING SW (DOWNWARD)
14	G/B	REAR LIFTING SW (DOWNWARD)

Connector No.	B14
Connector Name	PARKING BRAKE SWITCH (WITH M/T)
Connector Type	P01FB-A



Terminal No.	Color of Wire	Signal Name [Specification]
1	V	-

Terminal No.	Color of Wire	Signal Name [Specification]
16	O	VCC
17	Y/R	TX
19	V	CAN-L
21	L/Y	P RANGE SW
24	R	PULSE (SLIDING)
25	Y/B	PULSE (FR LIFTING)
26	Y	SLIDING SW (FORWARD)
27	R/G	RECLINING SW (FORWARD)
28	W/B	FRONT LIFTING SW (UPWARD)
29	P/L	REAR LIFTING SW (UPWARD)
30	P	POWER WALK-IN SW
31	GR	SENSOR GND
32	B/W	GND (SIGNAL)

A
B
C
D
E
F
G
H
I
ADP
K
L
M
N
O
P

DRIVER SEAT CONTROL UNIT (WITH AUTOMATIC DRIVE POSITIONER)

< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER

Connector No.	B504
Connector Name	DRIVER SEAT CONTROL UNIT
Connector Type	NS16FW-CS



33	35	36	37	38	39
40	41	42	44	45	48

Terminal No.	Color of Wire	Signal Name [Specification]
33	R	BAT (C/B)
35	W/R	SLIDING MOTOR (FORWARD)
36	G/Y	RECLINING MOTOR (FORWARD)
37	G/W	FRONT LIFTING MOTOR (DOWNWARD)
38	L/Y	REAR LIFTING MOTOR (UPWARD)
39	R/B	REAR LIFTING MOTOR (BACKWARD)
40	R/W	BAT (FUSE)
41	Y/G	FORWARD SW
42	W	SLIDING MOTOR (BACKWARD)
44	P	RECLINING MOTOR (BACKWARD)
45	L/R	FRONT LIFTING MOTOR (UPWARD)

Connector No.	B513
Connector Name	POWER WALK-IN SWITCH (DRIVER SIDE)
Connector Type	TK02FB



32	30
----	----

Terminal No.	Color of Wire	Signal Name [Specification]
30	P	
32	B/W	

48	B	GND (POWER)
----	---	-------------

Connector No.	B510
Connector Name	POWER SEAT SWITCH (DRIVER SIDE) (WITH AUTOMATIC DRIVE POSITIONER)
Connector Type	NS10FW-CS



32	12	27	11	26	13	28
----	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name [Specification]
11	BR	
12	SB	
13	LG/R	
14	G/B	
26	Y	
27	R/G	
28	W/B	
29	P/L	
32	B/W	

Connector No.	B523
Connector Name	RECLINING MOTOR (DRIVER SIDE) (WITH AUTOMATIC DRIVE POSITIONER)
Connector Type	NS08FW-CS



44	16	31	9
36			

Terminal No.	Color of Wire	Signal Name [Specification]
9	W/G	
16	O	
31	GR	
36	G/Y	
44	P	

Connector No.	B512
Connector Name	FORWARD SWITCH (DRIVER SIDE)
Connector Type	SS2FW



41	32
----	----

Terminal No.	Color of Wire	Signal Name [Specification]
32	B/W	
41	Y/G	

Connector No.	B525
Connector Name	SLIDING MOTOR (DRIVER SIDE)
Connector Type	BC086-0239



42	35
----	----

Terminal No.	Color of Wire	Signal Name [Specification]
35	W/R	
42	W	

JCJWM0671GE

DRIVER SEAT CONTROL UNIT (WITH AUTOMATIC DRIVE POSITIONER)

< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER

Connector No.	B526
Connector Name	SLIDING SENSOR (DRIVER SIDE)
Connector Type	B068 0241



Terminal No.	Color of Wire	Signal Name [Specification]
16	O	-
24	R	-
31	GR	-

Connector No.	B327
Connector Name	LIFTING MOTOR (FRONT) (DRIVER SIDE) (WITH AUTOMATIC DRIVE POSITIONER)
Connector Type	NS3GFW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
16	O	-
25	Y/B	-
31	GR	-
37	G/W	-
45	L/R	-

Connector No.	B529
Connector Name	LIFTING MOTOR (REAR) (DRIVER SIDE) (WITH AUTOMATIC DRIVE POSITIONER)
Connector Type	NS3GFER-CS



Terminal No.	Color of Wire	Signal Name [Specification]
10	P/B	-
16	O	-
31	GR	-
38	L/Y	-
39	R/B	-

Connector No.	D1
Connector Name	WIRE TO WIRE
Connector Type	TH40FW-CS15



Terminal No.	Color of Wire	Signal Name [Specification]
13	B	-
21	R	-
22	P	-
23	O	-
24	BR	-
25	SB	-
26	GR	-
27	GR	-
28	LG	-
29	G	-
30	Y	-

Terminal No.	Color of Wire	Signal Name [Specification]
31	W	-
32	BR	-
38	BR	-
39	GR	-
40	G	-
43	BR	-
44	V	-
45	P	-
46	W	-

Connector No.	D3
Connector Name	DOOR MIRROR (DRIVER SIDE)
Connector Type	TH12MW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
5	BR	-
6	GR	- [With automatic drive positioner]
7	G	- [With automatic drive positioner]
9	P	-
10	BR	-
11	W	-
12	V	-

Connector No.	D5
Connector Name	SEAT MEMORY SWITCH
Connector Type	A08FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	SB	-
2	BR	-
3	GR	-
4	B	-
5	R	-
6	O	-
7	P	-


A
B
C
D
E
F
G
H
I
ADP
K
L
M
N
O
P

DRIVER SEAT CONTROL UNIT (WITH AUTOMATIC DRIVE POSITIONER)

< ECU DIAGNOSIS INFORMATION >


AUTOMATIC DRIVE POSITIONER

Connector No.	D17
Connector Name	DOOR MIRROR REMOTE CONTROL SWITCH (WITH AUTOMATIC DRIVE POSITIONER)
Connector Type	TK16E8R



Terminal No.	Color of Wire	Signal Name [Specification]
4	BR	-
7	B	-
10	GR	-
11	LG	-
12	G	-
13	W	-
15	Y	-

Connector No.	D31
Connector Name	WIRE TO WIRE
Connector Type	TH40FW-CS15




Terminal No.	Color of Wire	Signal Name [Specification]
38	O	-
39	GR	-
40	G	-
43	BR	-
44	V	-
45	P	-
46	W	-

Connector No.	D33
Connector Name	DOOR MIRROR (PASSENGER SIDE)
Connector Type	TH12MW-NH




Terminal No.	Color of Wire	Signal Name [Specification]
5	O	-
6	GR	-
7	G	-
9	P	-
10	BR	-
11	W	-
12	V	-

Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS19-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
91	G	-


Connector No.	F51
Connector Name	A/T ASSEMBLY
Connector Type	RK10FG-DGY




Connector No.	F103
Connector Name	WIRE TO WIRE
Connector Type	TK38FW-NS10



Connector No.	F157
Connector Name	TCM (TRANSMISSION CONTROL MODULE)
Connector Type	SP10FG



Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS30FW-M2



Terminal No.	Color of Wire	Signal Name [Specification]
3	L	-
8	P	-

Terminal No.	Color of Wire	Signal Name [Specification]
43	P	-
44	L	-

Terminal No.	Color of Wire	Signal Name [Specification]
3	R	CAN-H
8	BR	CAN-L

Terminal No.	Color of Wire	Signal Name [Specification]
4A	P	-
7A	R	-


JCJWM0673GE

DRIVER SEAT CONTROL UNIT (WITH AUTOMATIC DRIVE POSITIONER)

< ECU DIAGNOSIS INFORMATION >


AUTOMATIC DRIVE POSITIONER

Connector No.	M5
Connector Name	WIRE TO WIRE
Connector Type	TH80MP-CS15



Terminal No.	Color of Wire	Signal Name [Specification]
13	B	-
21	W	-
22	P	-
23	O	-
24	LG	-
25	L	-
26	R	-
27	P	-
28	LG	-
29	SB	-
30	G	-


Connector No.	M22
Connector Name	KEY SLOT
Connector Type	TH12FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	BAT
7	B	GND
11	SB	KEY SWITCH SIGNAL


31	V	-
32	BR	-
36	G	-
38	L	-
40	Y	-
43	SB	-
44	Y	-
45	GR	-
46	W	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	TH80MP-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
91	W	-

Connector No.	M31
Connector Name	TILT & TELESCOPIC SWITCH
Connector Type	TK08FGY




Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	GR	-
3	G	-
4	Y	-
5	BR	-

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	TH80MP-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
15	R	- [W6A A/T]
15	Y	- [W6A M/T]
16	BR	-
17	P	-
18	V	-
20	L	-
21	P	-
71	R	-
95	O	-
99	P	-

Connector No.	M48
Connector Name	TILT & TELESCOPIC SENSOR
Connector Type	TK04FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	P	-
3	O	-
4	Y	-

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

DRIVER SEAT CONTROL UNIT (WITH AUTOMATIC DRIVE POSITIONER)

< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER

Connector No.	M49
Connector Name	TILT & TELESCOPIC MOTOR
Connector Type	NS34FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	GR	-
3	O	-
4	L	-

Connector No.	M62
Connector Name	CIRCUIT BREAKER
Connector Type	M02FW-LC




Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	P	-

Connector No.	M51
Connector Name	AUTOMATIC DRIVE POSITIONER CONTROL UNIT
Connector Type	TH32FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	TILT SW (UPWARD)
2	LG	MIRROR SELECT SW (RH)
3	G	MIRROR SW (UPWARD)
4	V	MIRROR SW (LEFTWARD)
5	R	MIRROR SENSOR (RH VERTICAL)
6	GR	MIRROR SENSOR (LH VERTICAL)
7	O	TILT SENSOR
9	L	ADDRESS1
10	V	TX (UART)
11	GR	TELESCOPIC SW (FRONTWARD)
12	O	IND1


Connector No.	M67
Connector Name	UNIFIED METER AND A/C AMP.
Connector Type	TH32FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
56	L	CAN-H
72	P	CAN-L


Terminal No.	Color of Wire	Signal Name [Specification]
13	P	IND2
14	W	MIRROR MOTOR (RH VERTICAL)
15	O	MIRROR MOTOR (RH HORIZONTAL)
16	V	MIRROR MOTOR (LH COMMON)
17	BR	TILT SW (DOWNWARD)
18	P	MIRROR SELECT SW (LH)
19	SB	MIRROR SW (DOWNWARD)
20	BR	MIRROR SW (RIGHTWARD)
21	L	MIRROR SENSOR (RH HORIZONTAL)
22	SB	MIRROR SENSOR (LH HORIZONTAL)
23	P	TELESCOPIC SENSOR
24	R	SET SW
25	LG	ADDRESS2
26	P	RX (UART)
27	G	TELESCOPIC SW (BACKWARD)
30	SB	MIRROR MOTOR (RH COMMON)
31	G	MIRROR MOTOR (LH VERTICAL)
32	L	MIRROR MOTOR (LH HORIZONTAL)

Connector No.	M116
Connector Name	WIRE TO WIRE
Connector Type	TK38MW-NS10



Terminal No.	Color of Wire	Signal Name [Specification]
43	P	-
44	L	-

Connector No.	M62
Connector Name	AUTOMATIC DRIVE POSITIONER CONTROL UNIT
Connector Type	NS316FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
33	W	POWER SUPPLY (SENSOR)
34	V	BAT (FUSE)
35	L	TILT MOTOR (UPWARD)
36	GR	TELESCOPIC MOTOR (FORWARD)
39	W	BAT (C/B)
40	B	GND(SIGNAL)
41	Y	GND(SENSOR)
42	O	TILT MOTOR (DOWNWARD)
44	G	TELESCOPIC MOTOR (BACKWARD)
48	B	GND(POWER)

Connector No.	M118
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	M03FB-LC




Terminal No.	Color of Wire	Signal Name [Specification]
1	W	BAT (F/L)

DRIVER SEAT CONTROL UNIT (WITH AUTOMATIC DRIVE POSITIONER)

< ECU DIAGNOSIS INFORMATION >


AUTOMATIC DRIVE POSITIONER

Connector No.	M119
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH16FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
11	R	BAT (FUSE)
13	B	GND

Connector No.	M137
Connector Name	A/T SHIFT SELECTOR
Connector Type	TH12FW-NH




Terminal No.	Color of Wire	Signal Name [Specification]
10	GR	-
11	R	-

Connector No.	M122
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH4GFB-NH




Terminal No.	Color of Wire	Signal Name [Specification]
90	P	CAN-L
91	L	CAN-H
96	GR	A/T SHIFT SELECTOR POWER SUPPLY
99	R	SHIFT P. [A/T models]

Connector No.	M123
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH4GFB-NH



Terminal No.	Color of Wire	Signal Name [Specification]
121	SB	KEY SLOT SW
150	R	DRIVER DOOR SW

Connector No.	M124
Connector Name	WIRE TO WIRE
Connector Type	TH40MP-CS15



Terminal No.	Color of Wire	Signal Name [Specification]
38	W	-
39	O	-
40	SB	-
43	L	-
44	Y	-
45	R	-
46	W	-

A
B
C
D
E
F
G
H
I
ADP
K
L
M
N
O
P

Fail Safe

The fail-safe mode may be activated if the following symptoms are observed.

JCJWM0676GE

INFOID:000000004250400

DRIVER SEAT CONTROL UNIT (WITH AUTOMATIC DRIVE POSITIONER)

< ECU DIAGNOSIS INFORMATION >

Operating in fail-safe mode	Malfunction Item	Related DTC	Diagnosis
Only manual functions operate normally.	CAN communication*1	U1000	With ADP: ADP-48
			Without ADP: ADP-48
	Tilt sensor*1	B2118	With ADP: ADP-53
			Without ADP: ADP-53
	Telescopic sensor	B2119	ADP-56
	Detent switch	B2126	ADP-59
Parking brake switch	B2127	ADP-61	
Only manual functions, except door mirror, operate normally.	UART communication	B2128	ADP-63
Only manual functions, except seat sliding, operate normally.	Seat sliding output	B2112	ADP-49
Only manual functions, except seat reclining, operate normally.	Seat reclining output	B2113	ADP-51

*1: Driver seat without automatic driver positioner system display only "U1000 CAN COMM CIRCUIT" and "B2112 SEAT SLIDE".

DTC Index

INFOID:000000004250401

CONSULT-III display	Timing*1		Item	Reference page
	Current malfunction	Previous malfunction		
CAN COMM CIRCUIT*2 [U1000]	0	1-39	CAN communication	With ADP: ADP-48
				Without ADP: ADP-48
SEAT SLIDE*2 [B2112]	0	1-39	Seat slide motor output	With ADP: ADP-49
				Without ADP: ADP-49
SEAT RECLINING [B2113]	0	1-39	Seat reclining motor output	ADP-51
TILT SENSOR [B2118]	0	1-39	Tilt sensor input	ADP-53
TELESCO SENSOR [B2119]	0	1-39	Telescopic sensor input	ADP-56
DETENT SW*2 [B2126]	0	1-39	Detention switch condition	ADP-59
PARKING BRAKE [B2127]	0	1-39	Parking brake switch condition	ADP-61
UART COMM [B2128]	0	1-39	UART communication	ADP-63

*1:

- 0: Current malfunction is present
- 1-39: Displayed if any previous malfunction is present when current condition is normal. The numeral value increases by one at each IGN ON to OFF cycle from 1 to 39. The counter remains at 39 even if the number of cycles exceeds it. However, the counter is reset to 1 if any malfunction is detected again, the normal operation is resumed and the ignition switch is turned from OFF to ON.

*2: Driver seat without automatic driver positioner system display only "U1000 CAN COMM CIRCUIT" and "B2112 SEAT SLIDE".

AUTOMATIC DRIVE POSITIONER CONTROL UNIT


< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

Reference Value

INFOID:000000004555929

TERMINAL LAYOUT



PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition		Voltage (V) (Approx.)
+	-	Signal name	Input/ Output			
1 (Y)	Ground	Tilt switch upward signal	Input	Tilt switch	Operate (upward)	0
					Other than above	5
2 (LG)	Ground	Changeover switch RH signal	Input	Changeover switch position	RH	0
					Neutral or LH	5
3 (G)	Ground	Mirror switch upward signal	Input	Mirror switch	Operated (upward)	0
					Other than above	5
4 (V)	Ground	Mirror switch leftward signal	Input	Mirror switch	Operated (leftward)	0
					Other than above	5
5 (R)	Ground	Door mirror sensor (RH) upward/downward signal	Input	Mirror face (door mirror RH)	Change between 3.4 (close to peak) 0.6 (close to valley)	
6 (GR)	Ground	Door mirror sensor (LH) upward/downward signal	Input	Mirror face (door mirror LH)	Change between 3.4 (close to peak) 0.6 (close to valley)	
7 (O)	Ground	Tilt sensor signal	Input	Tilt position	Change between 1.2 (close to top) 3.8 (close to bottom)	
9 (L)	Ground	Memory switch 1 signal	Input	Memory switch 1	Press	0
					Other than above	5
10 (V)	Ground	UART communication (TX)	Output	Ignition switch ON		

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Voltage (V) (Approx.)
+	-	Signal name	Input/ Output			
11 (GR)	Ground	Telescopic switch forward signal	Input	Telescopic switch	Operate (forward)	0
					Other than above	5
12 (O)	Ground	Memory indicator 1 signal	Output	Memory indicator 1	Illuminate	1
					Other than above	Battery voltage
13 (P)	Ground	Memory indicator 2 signal	Output	Memory indicator 2	Illuminate	1
					Other than above	Battery voltage
14 (W)	Ground	Door mirror motor (RH) upward output	Output	Door mirror RH	Operate (upward)	Battery voltage
					Other than above	0
15 (O)	Ground	Door mirror motor (RH) leftward output	Output	Door mirror RH	Operate (leftward)	Battery voltage
					Other than above	0
16 (Y)	Ground	Door mirror motor (LH) downward output	Output	Door mirror (LH)	Operate (downward)	Battery voltage
					Other than above	0
		Door mirror motor (LH) rightward output			Operate (rightward)	Battery voltage
					Other than above	0
17 (BR)	Ground	Tilt switch downward signal	Input	Tilt switch	Operate (downward)	0
					Other than above	5
18 (P)	Ground	Changeover switch LH signal	Input	Changeover switch position	LH	0
					Neutral or RH	5
19 (SB)	Ground	Mirror switch downward signal	Input	Mirror switch	Operate (downward)	0
					Other than above	5
20 (BR)	Ground	Mirror switch rightward signal	Input	Mirror switch	Operate (rightward)	0
					Other than above	5
21 (L)	Ground	Door mirror sensor (RH) leftward/rightward signal	Input	Door mirror RH position		Change between 3.4 (close to left edge) 0.6 (close to right edge)
22 (SB)	Ground	Door mirror sensor (LH) leftward/rightward signal	Input	Door mirror LH position		Change between 0.6 (close to left edge) 3.4 (close to right edge)
23 (P)	Ground	Telescopic sensor signal	Input	Telescopic position		Change between 0.8 (close to top) 4.4 (close to bottom)

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Voltage (V) (Approx.)	
+	-	Signal name	Input/ Output			
24 (R)	Ground	Set switch signal	Input	Set switch	Press	0
					Other than above	5
25 (LG)	Ground	Memory switch 2 signal	Input	Memory switch 2	Press	0
					Other than above	5
26 (P)	Ground	UART communication (RX)	Input	Ignition switch ON		
27 (G)	Ground	Telescopic switch backward signal	Input	Telescopic switch	Operate (backward)	0
					Other than above	5
30 (SB)	Ground	Door mirror motor (RH) downward output	Output	Door mirror (RH)	Operate (downward)	Battery voltage
					Other than above	0
		Door mirror motor (RH) rightward output			Operate (rightward)	Battery voltage
					Other than above	0
31 (G)	Ground	Door mirror motor (LH) upward output	Output	Door mirror (LH)	Operate (upward)	Battery voltage
					Other than above	0
32 (L)	Ground	Door mirror motor (LH) leftward output	Output	Door mirror (LH)	Operate (leftward)	Battery voltage
					Other than above	0
33 (W)	Ground	Sensor power supply	Input	—	5	
34 (V)	Ground	Power source (Fuse)	Input	—	Battery voltage	
35 (L)	Ground	Tilt motor upward output	Output	Steering tilt	Operate (upward)	Battery voltage
					Other than above	0
36 (GR)	Ground	Telescopic motor forward output signal	Output	Steering telescopic	Operate (forward)	Battery voltage
					Other than above	0
39 (W)	Ground	Power source (C/B)	Input	—	Battery voltage	
40 (B)	Ground	Ground	—	—	0	

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP


AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Voltage (V) (Approx.)	
+	-	Signal name	Input/ Output			
41 (Y)	Ground	Sensor ground	—	—	0	
42 (O)	Ground	Tilt motor downward out- put	Output	Steering tilt	Operate (down- ward)	Battery voltage
					Other than above	0
44 (G)	Ground	Telescopic motor back- ward output	Output	Steering telescop- ic	Operate (backward)	Battery voltage
						Other than above
48 (B)	Ground	Ground	—	—	0	


AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >



AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >



A
B
C
D
E
F
G
H
I
K
L
M
N
O
P


ADP

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


AUTOMATIC DRIVE POSITIONER

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
15	Y	-
16	BR	-
17	LG	-
18	G	-
20	L	-
21	P	-
21	V	-
35	V	-
35	SB	-
99	SB	-

Connector No.	B11
Connector Name	WIRE TO WIRE
Connector Type	NS1(FW)-CS




Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
3	L	-
5	BR	-
17	LG	-
19	P	-
21	Y	-
32	B	-
33	SB	-
40	BR	-
48	B	-

Connector No.	B16
Connector Name	DRIVER SIDE DOOR SWITCH
Connector Type	A03FW



Terminal No.	Color of Wire	Signal Name [Specification]
2	V	-

Connector No.	B13
Connector Name	SEAT BELT BUCKLE SWITCH (DRIVER SIDE)
Connector Type	A03FW




Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	B	-

Connector No.	B14
Connector Name	PARKING BRAKE SWITCH (WITH M/T)
Connector Type	P01FB-A




Terminal No.	Color of Wire	Signal Name [Specification]
1	V	-

Connector No.	B503
Connector Name	DRIVER SEAT CONTROL UNIT
Connector Type	TH32FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	L/W	RX
3	R/Y	GAN-H
4	O/B	SLIDING LIMIT SW
5	L	BUCKLE SW
8	L/Y	P RANGE SW
9	W/G	PULSE (RECLINING)
10	P/B	PULSE (RR LIFTING)
11	BR	SLIDING SW (BACKWARD)
12	SB	RECLINING SW (BACKWARD)
13	LG/R	FRONT LIFTING SW (DOWNWARD)
14	G/B	REAR LIFTING SW (DOWNWARD)

Connector No.	B502
Connector Name	WIRE TO WIRE
Connector Type	NS16MW-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	L/W	-
3	R/Y	-
5	L	-
17	Y/R	-
19	V	-
21	L/Y	-
32	B/W	-
33	R	-
40	R/W	-
48	B	-

Terminal No.	Color of Wire	Signal Name [Specification]
16	O	VGC
17	Y/R	TX
19	V	GAN-L
21	L/Y	P RANGE SW
24	R	PULSE (SLIDING)
25	Y/B	PULSE (FR LIFTING)
26	Y	SLIDING SW (FORWARD)
27	R/G	RECLINING SW (FORWARD)
28	W/B	FRONT LIFTING SW (UPWARD)
29	P/L	REAR LIFTING SW (UPWARD)
30	P	POWER MULT-TR SW
31	GR	SENSOR GND
32	B/W	GND (SIGNAL)

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER

Connector No.	B504
Connector Name	DRIVER SEAT CONTROL UNIT
Connector Type	NS16FW-CS

33	35	36	37	38	39
40	41	42	44	45	48



Terminal No.	Color of Wire	Signal Name [Specification]
33	R	BAT (C/B)
35	W/R	SLIDING MOTOR (FORWARD)
36	G/Y	RECLINING MOTOR (FORWARD)
37	G/W	FRONT LIFTING MOTOR (FORWARD)
38	L/Y	REAR LIFTING MOTOR (UPWARD)
38	R/B	REAR LIFTING MOTOR (BACKWARD)
40	R/W	BAT (PUSE)
41	Y/G	FORWARD SW
42	W	SLIDING MOTOR (BACKWARD)
44	P	RECLINING MOTOR (BACKWARD)
45	L/R	FRONT LIFTING MOTOR (UPWARD)



32	30
----	----

Connector No.	B513
Connector Name	POWER WALK-IN SWITCH (DRIVER SIDE)
Connector Type	TK02FBR

48	B	GND (POWER)
----	---	-------------



32	4
----	---

Connector No.	B514
Connector Name	SLIDING LIMIT SWITCH (DRIVER SIDE)
Connector Type	TK02MBR-P

Connector No.	B510
Connector Name	POWER SEAT SWITCH (DRIVER SIDE) (WITH AUTOMATIC DRIVE POSITIONER)
Connector Type	NS10FW-CS

32	14	29
12	27	11
26	13	28



Terminal No.	Color of Wire	Signal Name [Specification]
11	BR	-
12	SB	-
13	LG/R	-
14	G/B	-
26	Y	-
27	R/G	-
28	W/B	-
29	P/L	-
32	B/W	-



44	36
16	31
19	

Connector No.	B523
Connector Name	RECLINING MOTOR (DRIVER SIDE) (WITH AUTOMATIC DRIVE POSITIONER)
Connector Type	NS08FW-CS

Connector No.	B512
Connector Name	FORWARD SWITCH (DRIVER SIDE)
Connector Type	SS2FW



41	32
----	----

Terminal No.	Color of Wire	Signal Name [Specification]
32	B/W	-
41	Y/G	-

Connector No.	B525
Connector Name	SLIDING MOTOR (DRIVER SIDE)
Connector Type	6038-0239



42	35
----	----

Terminal No.	Color of Wire	Signal Name [Specification]
9	W/G	-
16	O	-
31	GR	-
38	G/Y	-
44	P	-

Terminal No.	Color of Wire	Signal Name [Specification]
4	O/B	-
32	B/W	-

Terminal No.	Color of Wire	Signal Name [Specification]
30	P	-
32	B/W	-

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER

Connector No.	B526
Connector Name	SLIDING SENSOR (DRIVER SIDE)
Connector Type	B088 0241



Terminal No.	Color of Wire	Signal Name [Specification]
16	O	-
24	R	-
31	GR	-

Connector No.	B327
Connector Name	LIFTING MOTOR (FRONT) (DRIVER SIDE) (WITH AUTOMATIC DRIVE POSITIONER)
Connector Type	NS06FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
16	O	-
25	Y/B	-
31	GR	-
37	G/W	-
45	L/R	-

Connector No.	B529
Connector Name	LIFTING MOTOR (REAR) (DRIVER SIDE) (WITH AUTOMATIC DRIVE POSITIONER)
Connector Type	NS06FER-CS



Terminal No.	Color of Wire	Signal Name [Specification]
10	P/B	-
16	O	-
31	GR	-
38	L/Y	-
39	R/B	-

Connector No.	D1
Connector Name	WIRE TO WIRE
Connector Type	TH40FW-CS15



Terminal No.	Color of Wire	Signal Name [Specification]
31	W	-
32	BR	-
38	BR	-
39	GR	-
40	G	-
43	BR	-
44	V	-
45	P	-
46	W	-

Connector No.	D3
Connector Name	DOOR MIRROR (DRIVER SIDE)
Connector Type	TH12MW-NH



Connector No.	D5
Connector Name	SEAT MEMORY SWITCH
Connector Type	A08FW



Terminal No.	Color of Wire	Signal Name [Specification]
13	B	-
21	R	-
22	P	-
23	O	-
24	BR	-
25	SB	-
26	GR	-
27	GR	-
28	LG	-
29	G	-
30	Y	-

Terminal No.	Color of Wire	Signal Name [Specification]
5	BR	-
6	GR	- [With automatic drive positioner]
7	G	- [With automatic drive positioner]
9	P	-
10	BR	-
11	W	-
12	V	-


Terminal No.	Color of Wire	Signal Name [Specification]
1	SB	-
2	BR	-
3	GR	-
4	B	-
5	R	-
6	O	-
7	P	-

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


AUTOMATIC DRIVE POSITIONER

Connector No.	D17
Connector Name	DOOR MIRROR REMOTE CONTROL SWITCH (WITH AUTOMATIC DRIVE POSITIONER)
Connector Type	TK10FBR




Terminal No.	Color of Wire	Signal Name [Specification]
4	BR	-
7	B	-
10	GR	-
11	LG	-
12	G	-
13	W	-
15	Y	-

Connector No.	F51
Connector Name	A/T ASSEMBLY
Connector Type	RK10FG-DGY




Terminal No.	Color of Wire	Signal Name [Specification]
3	L	-
8	P	-

Connector No.	D31
Connector Name	WIRE TO WIRE
Connector Type	TH40FY-CS15



Terminal No.	Color of Wire	Signal Name [Specification]
38	O	-
39	GR	-
40	G	-
43	BR	-
44	V	-
45	P	-
46	W	-

Connector No.	F103
Connector Name	WIRE TO WIRE
Connector Type	TK30FW-NS10




Terminal No.	Color of Wire	Signal Name [Specification]
43	P	-
44	L	-

Connector No.	D33
Connector Name	DOOR MIRROR (PASSENGER SIDE)
Connector Type	TH12MW-NH




Terminal No.	Color of Wire	Signal Name [Specification]
5	O	-
6	GR	-
7	G	-
9	P	-
10	BR	-
11	W	-
12	V	-

Connector No.	F157
Connector Name	TCM (TRANSMISSION CONTROL MODULE)
Connector Type	SP10FG




Terminal No.	Color of Wire	Signal Name [Specification]
3	R	CAN-H
8	BR	CAN-L

Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	TH60FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
91	G	-

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS30FW-M2



Terminal No.	Color of Wire	Signal Name [Specification]
4A	P	-
7A	R	-

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P


ADP

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


AUTOMATIC DRIVE POSITIONER

Connector No.	M5
Connector Name	WIRE TO WIRE
Connector Type	TH40MW-CS15



Terminal No.	Color of Wire	Signal Name [Specification]
13	B	-
21	W	-
22	P	-
23	O	-
24	LG	-
25	L	-
26	R	-
27	P	-
28	LG	-
28	SB	-
30	G	-


Connector No.	M22
Connector Name	KEY SLOT
Connector Type	TH12FV-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	BAT
7	B	GND
11	SB	KEY SWITCH SIGNAL


31	V	-
32	BR	-
38	G	-
39	-	-
40	Y	-
43	SB	-
44	Y	-
45	GR	-
46	W	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	TH20MW-CS18-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
91	W	-

Connector No.	M24
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FV-P




Terminal No.	Color of Wire	Signal Name [Specification]
6	L	-
14	P	-

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
15	R	- [WBA A/T]
15	Y	- [WBA M/T]
16	BR	-
17	P	-
18	V	-
20	L	-
21	P	-
71	R	-
95	O	-
99	P	-

Connector No.	M48
Connector Name	TILT & TELESCOPIC SENSOR
Connector Type	TKQ4FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	P	-
3	O	-
4	Y	-

Connector No.	M31
Connector Name	TILT & TELESCOPIC SWITCH
Connector Type	TKQ8FGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	GR	-
3	G	-
4	Y	-
5	BR	-

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER

Connector No.	M49
Connector Name	TILT & TELESCOPIC MOTOR
Connector Type	NS4FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	TILT MOTOR (UPWARD)
2	GR	TILT MOTOR (DOWNWARD)
3	O	TILT MOTOR (FORWARD)
4	L	TILT MOTOR (BACKWARD)

Connector No.	M51
Connector Name	AUTOMATIC DRIVE POSITIONER CONTROL UNIT
Connector Type	TH32FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	TILT SW (UPWARD)
2	LG	TILT SW (DOWNWARD)
3	G	MIRROR SW (UPWARD)
4	V	MIRROR SW (DOWNWARD)
5	R	MIRROR SW (LEFTWARD)
6	GR	MIRROR SW (RIGHTWARD)
7	O	MIRROR SELECT SW (RH)
8	L	MIRROR SELECT SW (LH)
9	L	MIRROR MOTOR (RH VERTICAL)
10	V	MIRROR MOTOR (RH HORIZONTAL)
11	GR	MIRROR MOTOR (LH VERTICAL)
12	O	MIRROR MOTOR (LH HORIZONTAL)
		SET SW
		ADDRESS2
		RX (UART)
		TELESCOPIC SW (BACKWARD)
		TELESCOPIC SW (FORWARD)
		MIRROR MOTOR (LH HORIZONTAL)

Connector No.	M62
Connector Name	CIRCUIT BREAKER
Connector Type	MD2FW-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	CIRCUIT BREAKER
2	P	CIRCUIT BREAKER


Terminal No.	Color of Wire	Signal Name [Specification]
13	P	MIRROR MOTOR (RH VERTICAL)
14	W	MIRROR MOTOR (RH HORIZONTAL)
15	O	MIRROR MOTOR (LH VERTICAL)
16	Y	MIRROR MOTOR (LH HORIZONTAL)
17	BR	TILT SW (DOWNWARD)
18	P	MIRROR SELECT SW (RH)
19	SB	MIRROR SELECT SW (LH)
20	BR	MIRROR SW (DOWNWARD)
21	L	MIRROR SW (UPWARD)
22	SB	MIRROR SW (LEFTWARD)
23	P	MIRROR SW (RIGHTWARD)
24	R	SET SW
25	LG	ADDRESS2
26	P	RX (UART)
27	G	TELESCOPIC SW (BACKWARD)
30	SB	MIRROR MOTOR (RH VERTICAL)
31	G	MIRROR MOTOR (RH HORIZONTAL)
32	L	MIRROR MOTOR (LH VERTICAL)
		MIRROR MOTOR (LH HORIZONTAL)

Connector No.	M116
Connector Name	WIRE TO WIRE
Connector Type	TK3BMW-NS10



Terminal No.	Color of Wire	Signal Name [Specification]
43	P	WIRE TO WIRE
44	L	WIRE TO WIRE

Connector No.	M62
Connector Name	AUTOMATIC DRIVE POSITIONER CONTROL UNIT
Connector Type	NS3BFW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
33	W	POWER SUPPLY (SENSOR)
34	V	BATT FUSE
35	L	TILT MOTOR (UPWARD)
36	GR	TELESCOPIC MOTOR (FORWARD)
39	W	BATT (G/B)
40	B	BATT (G/B)
41	Y	GND (SENSOR)
42	O	GND (SENSOR)
44	G	TILT MOTOR (DOWNWARD)
48	B	TELESCOPIC MOTOR (BACKWARD)
		GND (POWER)

Connector No.	M118
Connector Name	ECM (BODY CONTROL MODULE)
Connector Type	MD3FB-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	ECM (BODY CONTROL MODULE)
		BAT (F/L)

A
B
C
D
E
F
G
H
I
ADP
K
L
M
N
O
P

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


AUTOMATIC DRIVE POSITIONER

Connector No.	M119
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	HS16FV-CS



Terminal No.	Color of Wire	Signal Name [Specification]
11	R	BAT (FUSE)
13	B	GND

Connector No.	M137
Connector Name	A/T SHIFT SELECTOR
Connector Type	TH12FV-NH



Terminal No.	Color of Wire	Signal Name [Specification]
10	GR	-
11	R	-

Connector No.	M122
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH4GF-B-NH




Terminal No.	Color of Wire	Signal Name [Specification]
90	P	CAN-L
91	L	CAN-H
96	GR	A/T SHIFT SELECTOR POWER SUPPLY
99	R	SHIFT P. [A/T models]

Connector No.	M123
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH4DF-G-NH



Terminal No.	Color of Wire	Signal Name [Specification]
121	SB	KEY SLOT SW
150	R	DRIVER DOOR SW

Connector No.	M124
Connector Name	WIRE TO WIRE
Connector Type	TH4DMF-CS15



Terminal No.	Color of Wire	Signal Name [Specification]
38	W	-
39	O	-
40	SB	-
43	L	-
44	Y	-
45	R	-
46	W	-

JCJWM0676GE

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)

Reference Value

INFOID:000000004685555

VALUES ON THE DIAGNOSIS TOOL

CONSULT-III MONITOR ITEM

Monitor Item	Condition	Value/Status
FR WIPER HI	Other than front wiper switch HI	Off
	Front wiper switch HI	On
FR WIPER LOW	Other than front wiper switch LO	Off
	Front wiper switch LO	On
FR WASHER SW	Front washer switch OFF	Off
	Front washer switch ON	On
FR WIPER INT	Other than front wiper switch INT	Off
	Front wiper switch INT	On
FR WIPER STOP	Front wiper is not in STOP position	Off
	Front wiper is in STOP position	On
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	Wiper intermittent dial position
TURN SIGNAL R	Other than turn signal switch RH	Off
	Turn signal switch RH	On
TURN SIGNAL L	Other than turn signal switch LH	Off
	Turn signal switch LH	On
TAIL LAMP SW	Other than lighting switch 1ST and 2ND	Off
	Lighting switch 1ST or 2ND	On
HI BEAM SW	Other than lighting switch HI	Off
	Lighting switch HI	On
HEAD LAMP SW 1	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
HEAD LAMP SW 2	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
PASSING SW	Other than lighting switch PASS	Off
	Lighting switch PASS	On
AUTO LIGHT SW	Other than lighting switch AUTO	Off
	Lighting switch AUTO	On
FR FOG SW	Front fog lamp switch OFF	Off
	Front fog lamp switch ON	On
RR FOG SW	NOTE: The item is indicated, but not monitored.	Off
DOOR SW-DR	Driver door closed	Off
	Driver door opened	On
DOOR SW-AS	Passenger door closed	Off
	Passenger door opened	On
DOOR SW-RR	NOTE: The item is indicated, but not monitored.	Off
DOOR SW-RL	NOTE: The item is indicated, but not monitored.	Off

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
DOOR SW-BK	NOTE: The item is indicated, but not monitored.	Off
CDL LOCK SW	Other than power door lock switch LOCK	Off
	Power door lock switch LOCK	On
CDL UNLOCK SW	Other than power door lock switch UNLOCK	Off
	Power door lock switch UNLOCK	On
KEY CYL LK-SW	Other than driver door key cylinder LOCK position	Off
	Driver door key cylinder LOCK position	On
KEY CYL UN-SW	Other than driver door key cylinder UNLOCK position	Off
	Driver door key cylinder UNLOCK position	On
KEY CYL SW-TR	NOTE: The item is indicated, but not monitored.	Off
HAZARD SW	Hazard switch is OFF	Off
	Hazard switch is ON	On
REAR DEF SW	NOTE: The item is indicated, but not monitored.	Off
H/L WASH SW	NOTE: The item is indicated, but not monitored.	Off
TR CANCEL SW	Trunk lid opener cancel switch OFF	Off
	Trunk lid opener cancel switch ON	On
TR/BD OPEN SW	Trunk lid opener switch OFF	Off
	While the trunk lid opener switch is turned ON	On
TRNK/HAT MNTR	Trunk lid closed	Off
	Trunk lid opened	On
RKE-LOCK	LOCK button of the Intelligent Key is not pressed	Off
	LOCK button of the Intelligent Key is pressed	On
RKE-UNLOCK	UNLOCK button of the Intelligent Key is not pressed	Off
	UNLOCK button of the Intelligent Key is pressed	On
RKE-TR/BD	TRUNK OPEN button of the Intelligent Key is not pressed	Off
	TRUNK OPEN button of the Intelligent Key is pressed	On
RKE-PANIC	PANIC button of the Intelligent Key is not pressed	Off
	PANIC button of the Intelligent Key is pressed	On
RKE-P/W OPEN	UNLOCK button of the Intelligent Key is not pressed	Off
	UNLOCK button of the Intelligent Key is pressed and held	On
RKE-MODE CHG	LOCK/UNLOCK button of the Intelligent Key is not pressed and held simultaneously	Off
	LOCK/UNLOCK button of the Intelligent Key is pressed and held simultaneously	On
OPTICAL SENSOR	Bright outside of the vehicle	Close to 5 V
	Dark outside of the vehicle	Close to 0 V
REQ SW -DR	Driver door request switch is not pressed	Off
	Driver door request switch is pressed	On
REQ SW -AS	Passenger door request switch is not pressed	Off
	Passenger door request switch is pressed	On
REQ SW -RR	NOTE: The item is indicated, but not monitored.	Off
REQ SW -RL	NOTE: The item is indicated, but not monitored.	Off

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status	
REQ SW -BD/TR	Trunk lid opener request switch is not pressed	Off	A
	Trunk lid opener request switch is pressed	On	
PUSH SW	Push-button ignition switch (push switch) is not pressed	Off	B
	Push-button ignition switch (push switch) is pressed	On	
IGN RLY2 -F/B	Ignition switch in OFF or ACC position	Off	C
	Ignition switch in ON position	On	
ACC RLY -F/B	NOTE: The item is indicated, but not monitored.	Off	D
CLUCH SW	The clutch pedal is not depressed	Off	D
	The clutch pedal is depressed	On	
BRAKE SW 1	The brake pedal is depressed when No. 7 fuse is blown	Off	E
	The brake pedal is not depressed when No. 7 fuse is blown, or No. 7 fuse is normal	On	
BRAKE SW 2	The brake pedal is not depressed	Off	F
	The brake pedal is depressed	On	
DETE/CANCL SW	<ul style="list-style-type: none"> • Selector lever in P position (Except M/T models) • The clutch pedal is depressed (M/T models) 	Off	G
	<ul style="list-style-type: none"> • Selector lever in any position other than P (Except M/T models) • The clutch pedal is not depressed (M/T models) 	On	
SFT PN/N SW	Selector lever in any position other than P and N	Off	H
	Selector lever in P or N position	On	
S/L -LOCK	Steering is unlocked	Off	I
	Steering is locked	On	
S/L -UNLOCK	Steering is locked	Off	
	Steering is unlocked	On	ADP
S/L RELAY-F/B	Ignition switch in OFF or ACC position	Off	
	Ignition switch in ON position	On	
UNLK SEN -DR	Driver door is unlocked	Off	K
	Driver door is locked	On	
PUSH SW -IPDM	Push-button ignition switch (push-switch) is not pressed	Off	L
	Push-button ignition switch (push-switch) is pressed	On	
IGN RLY1 -F/B	Ignition switch in OFF or ACC position	Off	M
	Ignition switch in ON position	On	
DETE SW -IPDM	Selector lever in any position other than P	Off	
	Selector lever in P position	On	N
SFT PN -IPDM	<ul style="list-style-type: none"> • Selector lever in any position other than P and N (Except M/T models) • The clutch pedal is not depressed (M/T models) 	Off	
	<ul style="list-style-type: none"> • Selector lever in P or N position • The clutch pedal is depressed 	On	O
SFT P -MET	Selector lever in any position other than P	Off	
	Selector lever in P position	On	P
SFT N -MET	Selector lever in any position other than N	Off	
	Selector lever in N position	On	

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
ENGINE STATE	Engine stopped	Stop
	While the engine stalls	Stall
	At engine cranking	Crank
	Engine running	Run
S/L LOCK-IPDM	Steering is unlocked	Off
	Steering is locked	On
S/L UNLK-IPDM	Steering is locked	Off
	Steering is unlocked	On
S/L RELAY-REQ	Steering lock system is not the LOCK condition and the changing condition from LOCK to UNLOCK	Off
	Steering lock system are not the LOCK condition or the changing condition from LOCK to UNLOCK	On
VEH SPEED 1	While driving	Equivalent to speedometer reading
VEH SPEED 2	While driving	Equivalent to speedometer reading
DOOR STAT-DR	Driver door is locked	LOCK
	Wait with selective UNLOCK operation (60 seconds)	READY
	Driver door is unlocked	UNLOCK
DOOR STAT-AS	Passenger door is locked	LOCK
	Wait with selective UNLOCK operation (60 seconds)	READY
	Passenger door is unlocked	UNLOCK
ID OK FLAG	Steering is locked	Reset
	Steering is unlocked	Set
PRMT ENG STRT	The engine start is prohibited	Reset
	The engine start is permitted	Set
PRMT RKE STRT	NOTE: The item is indicated, but not monitored.	Reset
KEY SW -SLOT	The Intelligent Key is not inserted into key slot	Off
	The Intelligent Key is inserted into key slot	On
RKE OPE COUN1	During the operation of the Intelligent Key	Operation frequency of the Intelligent Key
RKE OPE COUN2	NOTE: The item is indicated, but not monitored.	—
CONFIRM ID ALL	The key ID that the key slot receives is not recognized by any key ID registered to BCM.	Yet
	The key ID that the key slot receives is recognized by any key ID registered to BCM.	Done
CONFIRM ID4	The key ID that the key slot receives is not recognized by the fourth key ID registered to BCM.	Yet
	The key ID that the key slot receives is recognized by the fourth key ID registered to BCM.	Done
CONFIRM ID3	The key ID that the key slot receives is not recognized by the third key ID registered to BCM.	Yet
	The key ID that the key slot receives is recognized by the third key ID registered to BCM.	Done

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status	
CONFIRM ID2	The key ID that the key slot receives is not recognized by the second key ID registered to BCM.	Yet	A
	The key ID that the key slot receives is recognized by the second key ID registered to BCM.	Done	B
CONFIRM ID1	The key ID that the key slot receives is not recognized by the first key ID registered to BCM.	Yet	C
	The key ID that the key slot receives is recognized by the first key ID registered to BCM.	Done	
TP 4	The ID of fourth Intelligent Key is not registered to BCM	Yet	D
	The ID of fourth Intelligent Key is registered to BCM	Done	
TP 3	The ID of third Intelligent Key is not registered to BCM	Yet	E
	The ID of third Intelligent Key is registered to BCM	Done	
TP 2	The ID of second Intelligent Key is not registered to BCM	Yet	F
	The ID of second Intelligent Key is registered to BCM	Done	
TP 1	The ID of first Intelligent Key is not registered to BCM	Yet	
	The ID of first Intelligent Key is registered to BCM	Done	
AIR PRESS FL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front LH tire	G
AIR PRESS FR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front RH tire	H
AIR PRESS RR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear RH tire	I
AIR PRESS RL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear LH tire	
ID REGST FL1	ID of front LH tire transmitter is registered	Done	
	ID of front LH tire transmitter is not registered	Yet	ADP
ID REGST FR1	ID of front RH tire transmitter is registered	Done	
	ID of front RH tire transmitter is not registered	Yet	
ID REGST RR1	ID of rear RH tire transmitter is registered	Done	K
	ID of rear RH tire transmitter is not registered	Yet	
ID REGST RL1	ID of rear LH tire transmitter is registered	Done	L
	ID of rear LH tire transmitter is not registered	Yet	
WARNING LAMP	Tire pressure indicator OFF	Off	
	Tire pressure indicator ON	On	M
BUZZER	Tire pressure warning alarm is not sounding	Off	
	Tire pressure warning alarm is sounding	On	N

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

TERMINAL LAYOUT



PHYSICAL VALUES

BCM (BODY CONTROL MODULE)





< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
		Signal name	Input/ Output			
+	-					
1 (W)	Ground	Battery power supply	Input	Ignition switch OFF		Battery voltage
2 (Y)	Ground	P/W power supply (BAT)	Output	Ignition switch OFF		12 V
3 (O)	Ground	P/W power supply (RAP)	Output	Ignition switch ON		12 V
4 (LG)	Ground	Interior room lamp power supply	Output	Interior room lamp battery saver is activated. (Cuts the interior room lamp power supply)		0 V
				Interior room lamp battery saver is not activated. (Outputs the interior room lamp power supply)		12 V
5 (P)	Ground	Passenger door UN- LOCK	Output	Passenger door	UNLOCK (Actuator is activated)	12 V
					Other than UNLOCK (Ac- tuator is not activated)	0 V
7 (SB)	Ground	Step lamp	Output	Step lamp	ON	0 V
					OFF	12 V
8 (V)	Ground	All doors, fuel lid LOCK	Output	All doors, fuel lid	LOCK (Actuator is activated)	12 V
					Other than LOCK (Actuator is not activated)	0 V
9 (G)	Ground	Driver door, fuel lid UNLOCK	Output	Driver door, fuel lid	UNLOCK (Actuator is activated)	12 V
					Other than UNLOCK (Actuator is not activated)	0 V
11 (R)	Ground	Battery power supply	Input	Ignition switch OFF		Battery voltage
13 (B)	Ground	Ground	—	Ignition switch ON		0 V
14 (W)	Ground	Push-button ignition switch illumination ground	Output	Tail lamp	OFF	0 V
					ON	<p style="text-align: center;">NOTE: When the illumination brighten- ing/dimming level is in the neutral position.</p>  <p style="text-align: right; font-size: small;">JSNIA0010GB</p>
15 (O)	Ground	ACC indicator lamp	Output	Ignition switch	OFF (LOCK indicator is not illuminated)	Battery voltage
					ACC	0 V

A
B
C
D
E
F
G
H
I
ADP
K
L
M
N
O
P







BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
17 (W)	Ground	Turn signal RH (Front)	Output	Ignition switch ON	Turn signal switch OFF 0 V
				Turn signal switch RH	 6.5 V
18 (O)	Ground	Turn signal LH (Front)	Output	Ignition switch ON	Turn signal switch OFF 0 V
				Turn signal switch LH	 6.5 V
19 (V)	Ground	Room lamp timer control	Output	Interior room lamp	OFF 12 V
				ON	0 V
20 (V)	Ground	Turn signal RH (Rear)	Output	Ignition switch ON	Turn signal switch OFF 0 V
				Turn signal switch RH	 6.5 V
23 (L)	Ground	Trunk lid open	Output	Trunk lid	OPEN (Trunk lid opener actuator is activated) 12 V
				Other than OPEN (Trunk lid opener actuator is not activated)	0 V
25 (Y)	Ground	Turn signal LH (Rear)	Output	Ignition switch ON	Turn signal switch OFF 0 V
				Turn signal switch LH	 6.5 V
30 (P)	Ground	Trunk room lamp	Output	Trunk room lamp	ON 0 V
				OFF	12 V

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
		Signal name	Input/ Output		
+	-				
34 (SB)	Ground	Trunk room antenna (-)	Output	Ignition switch OFF	 <p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				Ignition switch OFF	 <p style="text-align: right; font-size: small;">JMKIA0063GB</p>
35 (V)	Ground	Trunk room antenna (+)	Output	Ignition switch OFF	 <p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				Ignition switch OFF	 <p style="text-align: right; font-size: small;">JMKIA0063GB</p>
38 (B)	Ground	Rear bumper antenna (-)	Output	When the trunk lid opener request switch is operated with ignition switch OFF	 <p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				Ignition switch OFF	 <p style="text-align: right; font-size: small;">JMKIA0063GB</p>

A
B
C
D
E
F
G
H
I
ADP
K
L
M
N
O
P






BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)				
+	-	Signal name	Input/ Output						
39 (W)	Ground	Rear bumper antenna (+)	Output	When Intelligent Key is in the antenna detection area	<p style="text-align: right; font-size: small;">JMKIA0062GB</p>				
				When the trunk lid opener request switch is operated with ignition switch OFF	<p style="text-align: right; font-size: small;">JMKIA0063GB</p>				
47 (Y)	Ground	Ignition relay (IPDM E/R) control	Output	Ignition switch	<table border="0" style="width: 100%;"> <tr> <td style="width: 50%;">OFF or ACC</td> <td style="text-align: right;">12 V</td> </tr> <tr> <td>ON</td> <td style="text-align: right;">0 V</td> </tr> </table>	OFF or ACC	12 V	ON	0 V
				OFF or ACC	12 V				
ON	0 V								
50 (R)	Ground	Trunk room lamp switch	Input	Trunk room lamp switch	<table border="0" style="width: 100%;"> <tr> <td style="width: 50%;">OFF (Trunk lid is closed)</td> <td> <p style="text-align: right; font-size: small;">JPMIA0011GB</p> </td> </tr> <tr> <td>ON (Trunk lid is opened)</td> <td style="text-align: right;">0 V</td> </tr> </table>	OFF (Trunk lid is closed)	<p style="text-align: right; font-size: small;">JPMIA0011GB</p>	ON (Trunk lid is opened)	0 V
				OFF (Trunk lid is closed)	<p style="text-align: right; font-size: small;">JPMIA0011GB</p>				
ON (Trunk lid is opened)	0 V								
52 (SB)	Ground	Starter relay control	Output	Ignition switch ON (A/T models)	When selector lever is in P or N position	12 V			
				Ignition switch ON (M/T models)	When selector lever is not in P or N position	0 V			
			Input	Ignition switch ON (A/T models)	When the clutch pedal is depressed	Battery voltage			
				Ignition switch ON (M/T models)	When the clutch pedal is not depressed	0 V			
61 (SB)	Ground	Trunk lid opener request switch	Input	Trunk lid opener request switch	<table border="0" style="width: 100%;"> <tr> <td style="width: 50%;">ON (Pressed)</td> <td style="text-align: right;">0 V</td> </tr> <tr> <td>OFF (Not pressed)</td> <td> <p style="text-align: right; font-size: small;">JPMIA0016GB</p> </td> </tr> </table>	ON (Pressed)	0 V	OFF (Not pressed)	<p style="text-align: right; font-size: small;">JPMIA0016GB</p>
				ON (Pressed)	0 V				
OFF (Not pressed)	<p style="text-align: right; font-size: small;">JPMIA0016GB</p>								
64 (L)	Ground	Intelligent Key warning buzzer (Engine room)	Output	Intelligent Key warning buzzer (Engine room)	<table border="0" style="width: 100%;"> <tr> <td style="width: 50%;">Sounding</td> <td style="text-align: right;">0 V</td> </tr> <tr> <td>Not sounding</td> <td style="text-align: right;">12 V</td> </tr> </table>	Sounding	0 V	Not sounding	12 V
				Sounding	0 V				
Not sounding	12 V								

BCM (BODY CONTROL MODULE)




< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
		Signal name	Input/ Output			
+	-					
67 (GR)	Ground	Trunk lid opener switch	Input	Trunk lid open- er switch	Pressed	0 V
					Not pressed	 <p style="text-align: right; font-size: small;">JPMIA0011GB</p>
72 (R)	Ground	Room antenna 2 (-) (Center console)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compart- ment	 <p style="text-align: right; font-size: small;">JMKIA0062GB</p>
					When Intelligent Key is not in the passenger compart- ment	 <p style="text-align: right; font-size: small;">JMKIA0063GB</p>
73 (G)	Ground	Room antenna 2 (+) (Center console)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compart- ment	 <p style="text-align: right; font-size: small;">JMKIA0062GB</p>
					When Intelligent Key is not in the passenger compart- ment	 <p style="text-align: right; font-size: small;">JMKIA0063GB</p>

A
B
C
D
E
F
G
H
I
ADP
K
L
M
N
O
P







BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
		Signal name	Input/ Output		
+	-				
74 (SB)	Ground	Passenger door antenna (-)	Output	When Intelligent Key is in the antenna detection area	 <p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				When the passenger door request switch is operated with ignition switch OFF	When Intelligent Key is not in the antenna detection area
75 (BR)	Ground	Passenger door antenna (+)	Output	When Intelligent Key is in the antenna detection area	 <p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				When the passenger door request switch is operated with ignition switch OFF	When Intelligent Key is not in the antenna detection area
76 (V)	Ground	Driver door antenna (-)	Output	When Intelligent Key is in the antenna detection area	 <p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				When the driver door request switch is operated with ignition switch OFF	When Intelligent Key is not in the antenna detection area

BCM (BODY CONTROL MODULE)






< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
		Signal name	Input/ Output		
+	-				
77 (LG)	Ground	Driver door antenna (+)	Output	When the driver door request switch is operated with ignition switch OFF	When Intelligent Key is in the antenna detection area  <small>JMKIA0062GB</small>
				When Intelligent Key is not in the antenna detection area  <small>JMKIA0063GB</small>	
78 (Y)	Ground	Room antenna 1 (-) (Instrument panel)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compartment  <small>JMKIA0062GB</small>
				When Intelligent Key is not in the passenger compartment  <small>JMKIA0063GB</small>	
79 (BR)	Ground	Room antenna 1 (+) (Instrument panel)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compartment  <small>JMKIA0062GB</small>
				When Intelligent Key is not in the passenger compartment  <small>JMKIA0063GB</small>	

A
B
C
D
E
F
G
H
I
ADP
K
L
M
N
O
P






BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
80 (GR)	Ground	NATS antenna amp (Built in key slot)	Input/ Output	During waiting	Ignition switch is pressed while inserting the Intelli- gent Key into the key slot.	Just after pressing ignition switch. Pointer of tester should move.
81 (W)	Ground	NATS antenna amp (Built in key slot)	Input/ Output	During waiting	Ignition switch is pressed while inserting the Intelli- gent Key into the key slot.	Just after pressing ignition switch. Pointer of tester should move.
82 (R)	Ground	Ignition relay [Fuse block (J/B)] control	Output	Ignition switch	OFF or ACC ON	0 V 12 V
83 (Y)	Ground	Remote keyless entry receiver communica- tion	Input/ Output	During waiting		 <p style="text-align: right; font-size: small;">JMKIA0064GB</p>
				When operating either button on the Intelli- gent Key		 <p style="text-align: right; font-size: small;">JMKIA0065GB</p>
87 (Y)	Ground	Combination switch INPUT 5	Input	Combination switch	All switches OFF (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0041GB</p> <p style="text-align: center;">1.4 V</p>
				Combination switch	Front fog lamp switch ON (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0037GB</p> <p style="text-align: center;">1.3 V</p>
					Any of the conditions be- low with all switches OFF • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 6 • Wiper intermittent dial 7	 <p style="text-align: right; font-size: small;">JPMIA0040GB</p> <p style="text-align: center;">1.3 V</p>

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
88 (O)	Ground	Combination switch INPUT 3	Input	Combination switch	All switches OFF (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0041GB</p> <p style="text-align: center;">1.4 V</p>
					Lighting switch HI (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0036GB</p> <p style="text-align: center;">1.3 V</p>
					Lighting switch 2ND (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0037GB</p> <p style="text-align: center;">1.3 V</p>
					Any of the conditions below with all switches OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 3 	 <p style="text-align: right; font-size: small;">JPMIA0040GB</p> <p style="text-align: center;">1.3 V</p>
89 (BR)	Ground	Push-button ignition switch (Push switch)	Input	Push-button ignition switch (push switch)	Pressed	0 V
				Not pressed	Battery voltage	
90 (P)	Ground	CAN-L	Input/ Output	—	—	
91 (L)	Ground	CAN-H	Input/ Output	—	—	
92 (LG)	Ground	Key slot illumination	Output	Key slot illumina- tion	OFF	0 V
					Blinking	 <p style="text-align: right; font-size: small;">JPMIA0015GB</p> <p style="text-align: center;">6.5 V</p>
					ON	12 V

A

B

C

D

E

F

G

H

I

ADP

K

L

M



N

O

P






BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
		Signal name	Input/ Output			
+	-					
93 (Y)	Ground	ON indicator lamp	Output	Ignition switch	OFF (LOCK indicator is not illuminated)	Battery voltage
					ON	0 V
95 (O)	Ground	ACC relay control	Output	Ignition switch	OFF	0 V
					ACC or ON	12 V
96 (GR)	Ground	A/T shift selector (Detention switch) power supply	Output	—		12 V
97 (L)	Ground	Steering lock condition No. 1	Input	Steering lock	LOCK status	0 V
					UNLOCK status	12 V
98 (P)	Ground	Steering lock condition No. 2	Input	Steering lock	LOCK status	12 V
					UNLOCK status	0 V
99 (R)	Ground	Selector lever P position switch	Input	Selector lever	P position	0 V
					Any position other than P	12 V
		ASCD clutch switch (M/T models without ICC)		ASCD clutch switch	OFF (Clutch pedal is depressed)	0 V
					ON (Clutch pedal is not depressed)	12 V
		ICC clutch switch (M/T models with ICC)		ICC clutch switch	OFF (Clutch pedal is depressed)	0 V
					ON (Clutch pedal is not depressed)	12 V
100 (Y)	Ground	Passenger door request switch	Input	Passenger door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	 1.0 V
101 (P)	Ground	Driver door request switch	Input	Driver door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	 1.0 V
102 (O)	Ground	Blower fan motor relay control	Output	Ignition switch	OFF or ACC	0 V
					ON	12 V
103 (LG)	Ground	Remote keyless entry receiver power supply	Output	Ignition switch OFF		12 V
106 (W)	Ground	Steering lock unit power supply	Output	Ignition switch	OFF or ACC	12 V
					ON	0 V

BCM (BODY CONTROL MODULE)





< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
		Signal name	Input/ Output			
+	-					
107 (LG)	Ground	Combination switch INPUT 1	Input	Combination switch (Wiper intermit- tent dial 4)	All switches OFF	 <p style="text-align: right; margin-right: 50px;">JPMIA0041GB</p> <p style="text-align: center;">1.4 V</p>
					Turn signal switch LH	 <p style="text-align: right; margin-right: 50px;">JPMIA0037GB</p> <p style="text-align: center;">1.3 V</p>
					Turn signal switch RH	 <p style="text-align: right; margin-right: 50px;">JPMIA0036GB</p> <p style="text-align: center;">1.3 V</p>
					Front wiper switch LO	 <p style="text-align: right; margin-right: 50px;">JPMIA0038GB</p> <p style="text-align: center;">1.3 V</p>
					Front washer switch ON	 <p style="text-align: right; margin-right: 50px;">JPMIA0039GB</p> <p style="text-align: center;">1.3 V</p>

A
B
C
D
E
F
G
H
I
ADP
K
L
M
N
O
P







BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
		Signal name	Input/ Output			
+	-					
108 (R)	Ground	Combination switch INPUT 4	Input	Combination switch	All switches OFF (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0041GB</p> <p style="text-align: center;">1.4 V</p>
					Lighting switch AUTO (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0038GB</p> <p style="text-align: center;">1.3 V</p>
					Lighting switch 1ST (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0036GB</p> <p style="text-align: center;">1.3 V</p>
					Any of the conditions below with all switches OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6 	 <p style="text-align: right; font-size: small;">JPMIA0039GB</p> <p style="text-align: center;">1.3 V</p>

BCM (BODY CONTROL MODULE)



< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
109 (W)	Ground	Combination switch INPUT 2	Input	Combination switch (Wiper intermit- tent dial 4)	All switches OFF	 <p style="text-align: right;">JPMIA0041GB</p> <p style="text-align: center;">1.4 V</p>
					Lighting switch PASS	 <p style="text-align: right;">JPMIA0037GB</p> <p style="text-align: center;">1.3 V</p>
					Lighting switch 2ND	 <p style="text-align: right;">JPMIA0036GB</p> <p style="text-align: center;">1.3 V</p>
					Front wiper switch INT	 <p style="text-align: right;">JPMIA0038GB</p> <p style="text-align: center;">1.3 V</p>
					Front wiper switch HI	 <p style="text-align: right;">JPMIA0040GB</p> <p style="text-align: center;">1.3 V</p>
					ON	0 V
110 (G)	Ground	Hazard switch	Input	Hazard switch	ON	
				Hazard switch	OFF	 <p style="text-align: right;">JPMIA0012GB</p> <p style="text-align: center;">1.1 V</p>

A
B
C
D
E
F
G
H
I
ADP
K
L
M
N
O
P





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
		Signal name	Input/ Output			
+	-					
111 (Y)	Ground	Steering lock unit communication	Input/ Output	Steering lock	LOCK status	12 V
					LOCK or UNLOCK	 <p style="text-align: right; font-size: small;">JMKIA0066GB</p>
					For 15 seconds after UN- LOCK	12 V
					15 seconds or later after UNLOCK	0 V
113 (O)	Ground	Optical sensor	Input	Ignition switch ON	When bright outside of the vehicle	Close to 5 V
					When dark outside of the vehicle	Close to 0 V
114 (R)	Ground	Clutch interlock switch	Input	Clutch interlock switch	OFF (Clutch pedal is not depressed)	0 V
					ON (Clutch pedal is de- pressed)	Battery voltage
116 (SB)	Ground	Stop lamp switch 1	Input	—	Battery voltage	
118 (BR)	Ground	Stop lamp switch 2 (Without ICC)	Input	Stop lamp switch	OFF (Brake pedal is not depressed)	0 V
					ON (Brake pedal is de- pressed)	Battery voltage
		Stop lamp switch 2 (With ICC)		Stop lamp switch OFF (Brake pedal is not depressed) and ICC brake hold relay OFF	0 V	
				Stop lamp switch ON (Brake pedal is de- pressed) or ICC brake hold relay ON	Battery voltage	
119 (SB)	Ground	Driver side door lock assembly (Unlock sensor)	Input	Driver door	LOCK status (Unlock sensor switch OFF)	 <p style="text-align: right; font-size: small;">JPMIA0012GB</p>
					UNLOCK status (Unlock switch sensor ON)	1.1 V
121 (SB)	Ground	Key slot switch	Input	When the Intelligent Key is inserted into key slot	12 V	
				When the Intelligent Key is not inserted into key slot	0 V	
123 (W)	Ground	IGN feedback	Input	Ignition switch	OFF or ACC	0 V
					ON	Battery voltage

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >






Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
124 (LG)	Ground	Passenger door switch	Input	Passenger door switch	OFF (Door close)	 <p style="text-align: right; font-size: small;">JPMIA0011GB</p> <p style="text-align: center;">11.8 V</p>
					ON (Door open)	0 V
129 (O)	Ground	Trunk lid opener cancel switch	Input	Trunk lid opener cancel switch	CANCEL	 <p style="text-align: right; font-size: small;">JPMIA0012GB</p> <p style="text-align: center;">1.1 V</p>
					ON	0 V
132 (V)	Ground	Power window switch communication	Input/ Output	Ignition switch ON	 <p style="text-align: right; font-size: small;">JPMIA0013GB</p> <p style="text-align: center;">10.2 V</p>	
				Ignition switch OFF or ACC	12 V	
133 (L)	Ground	Push-button ignition switch illumination	Output	Push-button ignition switch illumination	ON (Tail lamps OFF)	9.5 V
					ON (Tail lamps ON)	<p style="text-align: center;">NOTE: The pulse width of this wave is varied by the illumination brightening/dimming level.</p>  <p style="text-align: right; font-size: small;">JPMIA0159GB</p>
					OFF	0 V
134 (LG)	Ground	LOCK indicator lamp	Output	LOCK indicator lamp	OFF	Battery voltage
					ON	0 V
137 (O)	Ground	Receiver and sensor ground	Input	Ignition switch ON	0 V	
138 (V)	Ground	Receiver and sensor power supply	Output	Ignition switch	OFF	0 V
					ACC or ON	5.0 V

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
139 (L)	Ground	Tire pressure receiver communication	Input/ Output	Ignition switch ON	 <p style="text-align: right;">OCC3881D</p>
				When receiving the signal from the transmitter	 <p style="text-align: right;">OCC3880D</p>
140 (GR)	Ground	Selector lever P/N position (A/T models)	Input	Selector lever	P or N position 12 V
				Except P and N positions 0 V	
141 (R)	Ground	Security indicator	Output	Security indicator	ON 0 V
				Blinking	 <p style="text-align: right;">JPMIA0014GB</p>
				OFF 12 V	
142 (BR)	Ground	Combination switch OUTPUT 5	Output	Combination switch (Wiper intermittent dial 4)	All switches OFF 0 V
				Lighting switch 1ST	 <p style="text-align: right;">JPMIA0031GB</p>
				Lighting switch HI	
				Lighting switch 2ND	
Turn signal switch RH	10.7 V				
143 (V)	Ground	Combination switch OUTPUT 1	Output	Combination switch	All switches OFF (Wiper intermittent dial 4) 0 V
				Front wiper switch HI (Wiper intermittent dial 4)	 <p style="text-align: right;">JPMIA0032GB</p>
				Any of the conditions below with all switches OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 3 • Wiper intermittent dial 6 • Wiper intermittent dial 7 	

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
144 (G)	Ground	Combination switch OUTPUT 2	Output	Combination switch	All switches OFF (Wiper intermittent dial 4)	0 V
					Front washer switch ON (Wiper intermittent dial 4)	
Any of the conditions below with all switches OFF					10.7 V	
<ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6 						
145 (L)	Ground	Combination switch OUTPUT 3	Output	Combination switch (Wiper intermit- tent dial 4)	All switches OFF	0 V
					Front wiper switch INT	
					Front wiper switch LO	
					Lighting switch AUTO	
					10.7 V	
146 (SB)	Ground	Combination switch OUTPUT 4	Output	Combination switch (Wiper intermit- tent dial 4)	All switches OFF	0 V
					Front fog lamp switch ON	
					Lighting switch 2ND	
					Lighting switch PASS	
					Turn signal switch LH	
					10.7 V	
149 (W)	Ground	Tire pressure warning check switch	Input	—	12 V	
150 (R)	Ground	Driver door switch	Input	Driver door switch	OFF (Door close)	
					ON (Door open)	
151 (G)	Ground	Rear window defog- ger relay control	Output	Rear window defogger	Active	0 V
				Not activated	Battery voltage	

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P


ADP

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Wiring Diagram - BCM -

INFOID:000000004685556




2008/08/22

JCMWM3046G

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

◁ : With A/T
 ▷ : With M/T



*: This connector is not shown in "Harness Layout".


JCMWM3047G1

A
 B
 C
 D
 E
 F
 G
 H
 I
 ADP
 K
 L
 M
 N
 O
 P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


- : With A/T
- : With M/T
- : With sunroof
- : With ICC
- : Without ICC



JCMWM3048G

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >



JCMWM3049G1


A
B
C
D
E
F
G
H
I
ADP
K
L
M
N
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


BCM (BODY CONTROL MODULE)

Connector No.	M33
Connector Name	COMBINATION SWITCH
Connector Type	TH16FW-NH




Terminal No.	Color of Wire	Signal Name [Specification]
2	SB	OUTPUT 4
5	L	OUTPUT 3
7	O	INPUT 3
8	BR	OUTPUT 5
9	W	INPUT 2
10	R	INPUT 4
11	LG	INPUT 1
12	V	OUTPUT 1
13	Y	INPUT 5
14	G	OUTPUT 2

Connector No.	M120
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS12FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
20	V	TURN SIGNAL RH (REAR)
23	L	TRUNK LID OPEN OUTPUT
25	Y	TURN SIGNAL LH (REAR)
30	P	TRUNK ROOM LAMP

Connector No.	M118
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	M03FB-LC




Terminal No.	Color of Wire	Signal Name [Specification]
1	W	BAT (F/L)
2	Y	POWER WINDOW POWER SUPPLY(BAT)
3	O	POWER WINDOW POWER SUPPLY(TRAFF)

Connector No.	M121
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FGY-NH




Terminal No.	Color of Wire	Signal Name [Specification]
34	SB	TRUNK ROOM ANT-
35	V	TRUNK ROOM ANT+
38	B	REAR BUMPER ANT-
39	W	REAR BUMPER ANT+
47	Y	IGN RELAY (IPDM E/R) CONT
50	R	TRUNK ROOM LAMP SW
52	SB	STARTER RELAY CONT
61	SB	TRUNK LID OPENER REQUEST SW
64	L	L-KEY WARN BUZZER (ENG ROOM)
67	GR	TRUNK LID OPENER SW

Connector No.	M119
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS18FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
4	LG	INTERIOR ROOM LAMP POWER SUPPLY
5	P	PASSENGER DOOR UNLOCK OUTPUT
7	SB	STEP LAMP OUTPUT
8	V	ALL DOOR FUEL LID LOCK OUTPUT
9	G	DRIVER DOOR FUEL LID UNLOCK OUTPUT
11	R	BAT (F/USE)
13	B	GND
14	W	PUSH-BUTTON IGNITION SW (LL GND ACC IN)
15	O	ACC IN
17	W	TURN SIGNAL RH (FRONT)
18	O	TURN SIGNAL LH (FRONT)

Connector No.	M122
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH



Terminal No.	Color of Wire	Signal Name [Specification]
72	R	ROOM ANT2-
73	G	ROOM ANT2+
74	SB	PASSENGER DOOR ANT-
75	BR	PASSENGER DOOR ANT+
76	V	DRIVER DOOR ANT-
77	LG	DRIVER DOOR ANT+
78	Y	ROOM ANT1-
79	BR	ROOM ANT1+
80	GR	IMMOBI ANTENNA CONTROL
81	W	IMMOBI ANTENNA SIGNAL
82	R	IGN RELAY (E/B) CONT

19	V	ROOM LAMP TIMER CONTROL
----	---	-------------------------

83	Y	KEYLESS ENTRY RECEIVER COMM
87	Y	COMBI SW INPUT 5
88	O	COMBI SW INPUT 3
89	BR	PUSH SW
90	P	CAN-L
91	L	CAN-H
92	LG	KEY SLOT ILL ON IND
93	Y	KEY SLOT ILL ON IND
95	O	ACC RELAY CONT
96	GR	A/T SHIFT SELECTOR POWER SUPPLY
97	L	S/L CONDITION 1
98	P	S/L CONDITION 2
99	R	ASD CLUTCH SW (M/T models without ICC)
99	R	ICC CLUTCH SW (M/T models with ICC)
100	R	SHIFT P (A/T models)
100	Y	PASSENGER DOOR REQUEST SW
101	P	DRIVER DOOR REQUEST SW
102	O	BLOWER FAN MOTOR RELAY CONT
103	LG	KEYLESS ENTRY RECEIVER POWER SUPPLY
106	W	S/L UNIT POWER SUPPLY
107	LG	COMBI SW INPUT 1
108	R	COMBI SW INPUT 4
109	W	COMBI SW INPUT 2
110	G	HAZARD SW
111	Y	S/L UNIT COMM

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

BCM (BODY CONTROL MODULE)

Connector No.	M123
Connector Name	BCM BODY CONTROL MODULE
Connector Type	TH40FG-1M1



Terminal No.	Color of Wire	Signal Name [Specification]
113	O	OPTICAL SENSOR
114	R	CLUTCH INTERLOCK SW
116	SB	STOP LAMP SW 1
118	BR	STOP LAMP SW 2
119	SB	DR DOOR UNLOCK SENSOR
121	SB	KEY SLOT SW
123	W	IGN P/B
124	LG	PASSENGER DOOR SW
129	O	TRUNK LID OPENER CANCEL SW
132	V	POWER WINDOW SW COMM
133	L	PUSH-BUTTON IGNITION SW ILL POWER

134	LG	LOCK IND
137	O	RECEIVER SENSOR GND
138	V	RECEIVER SENSOR POWER SUPPLY
139	L	TIRE PRESSURE RECEIVER COMM
140	GR	SHIFT N/P
141	R	SECURITY INDICATOR
142	BR	COMBI SW OUTPUT 5
143	V	COMBI SW OUTPUT 1
144	G	COMBI SW OUTPUT 2
145	L	COMBI SW OUTPUT 3
146	SB	COMBI SW OUTPUT 4
148	W	TIRE PRESSURE WARN CHECK SW
149	W	DRIVER DOOR SW
150	R	REAR WINDOW DEFROGGER RELAY CONT
151	G	

Fail-safe

FAIL-SAFE CONTROL BY DTC

BCM performs fail-safe control when any DTC are detected.

JCMWM3051G1

INFOID:000000004685557

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Display contents of CONSULT	Fail-safe	Cancellation
B2013: ID DISCORD BCM-S/L	Inhibit engine cranking	Erase DTC
B2014: CHAIN OF S/L-BCM	Inhibit engine cranking	Erase DTC
B2190: NATS ANTENNA AMP	Inhibit engine cranking	Erase DTC
B2191: DIFFERENCE OF KEY	Inhibit engine cranking	Erase DTC
B2192: ID DISCORD BCM-ECM	Inhibit engine cranking	Erase DTC
B2193: CHAIN OF BCM-ECM	Inhibit engine cranking	Erase DTC
B2195: ANTI SCANNING	Inhibit engine cranking	Ignition switch ON → OFF
B2557: VEHICLE SPEED	Inhibit steering lock	When normal vehicle speed signals are received from ABS actuator and electric unit (control unit) for 500 ms
B2560: STARTER CONT RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> • Starter control relay signal • Starter relay status signal
B2601: SHIFT POSITION	Inhibit steering lock	500 ms after the following signal reception status becomes consistent <ul style="list-style-type: none"> • Selector lever P position switch signal • P range signal (CAN)
B2602: SHIFT POSITION	Inhibit steering lock	5 seconds after the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Ignition switch is in the ON position • Selector lever P position switch signal: Except P position (battery voltage) • Vehicle speed: 4 km/h (2.5 MPH) or more
B2603: SHIFT POSI STATUS	Inhibit steering lock	500 ms after the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Ignition switch is in the ON position • Selector lever P position switch signal: Except P position (battery voltage) • Selector lever P/N position signal: Except P and N positions (0 V)
B2604: PNP SW	Inhibit steering lock	500 ms after any of the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Status 1 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Selector lever P/N position signal: P and N position (battery voltage) - P range signal or N range signal (CAN): ON • Status 2 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Selector lever P/N position signal: Except P and N positions (0 V) - P range signal and N range signal (CAN): OFF
B2605: PNP SW	Inhibit steering lock	500 ms after any of the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Status 1 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Selector lever P/N position signal: Except P and N positions (0 V) - Interlock/PNP switch signal (CAN): OFF • Status 2 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Selector lever P/N position signal: P or N position (battery voltage) - PNP switch signal (CAN): ON
B2606: S/L RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> • Steering lock relay signal (Request signal) • Steering lock relay signal (Condition signal)

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Display contents of CONSULT	Fail-safe	Cancellation
B2607: S/L RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status has becomes consistent <ul style="list-style-type: none"> • Steering lock relay signal (Request signal) • Steering lock relay signal (Condition signal)
B2608: STARTER RELAY	Inhibit engine cranking	500 ms after the following signal communication status becomes consistent <ul style="list-style-type: none"> • Starter motor relay control signal • Starter relay status signal (CAN)
B2609: S/L STATUS	<ul style="list-style-type: none"> • Inhibit engine cranking • Inhibit steering lock 	When the following steering lock conditions agree <ul style="list-style-type: none"> • BCM steering lock control status • Steering lock condition No. 1 signal status • Steering lock condition No. 2 signal status
B260A: IGNITION RELAY	Inhibit engine cranking	500 ms after the following conditions are fulfilled <ul style="list-style-type: none"> • IGN relay (IPDM E/R) control signal: OFF (Battery voltage) • Ignition ON signal (CAN to IPDM E/R): OFF (Request signal) • Ignition ON signal (CAN from IPDM E/R): OFF (Condition signal)
B260F: ENG STATE SIG LOST	Maintains the power supply position attained at the time of DTC detection	When any of the following conditions are fulfilled <ul style="list-style-type: none"> • Power position changes to ACC • Receives engine status signal (CAN)
B2612: S/L STATUS	<ul style="list-style-type: none"> • Inhibit engine cranking • Inhibit steering lock 	When any of the following conditions are fulfilled <ul style="list-style-type: none"> • Steering lock unit status signal (CAN) is received normally • The BCM steering lock control status matches the steering lock status recognized by the steering lock unit status signal (CAN from IPDM E/R)
B2617: STARTER RELAY CIRC	Inhibit engine cranking	1 second after the starter motor relay control inside BCM becomes normal
B2618: BCM	Inhibit engine cranking	1 second after the ignition relay (IPDM E/R) control inside BCM becomes normal
B2619: BCM	Inhibit engine cranking	1 second after the steering lock unit power supply output control inside BCM becomes normal
B261E: VEHICLE TYPE	Inhibit engine cranking	BCM initialization
B26E8: CLUTCH SW	Inhibit engine cranking	When any of the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Status 1 <ul style="list-style-type: none"> - Clutch switch signal (CAN from ECM): ON - Clutch interlock switch signal: OFF (0 V) • Status 2 <ul style="list-style-type: none"> - Clutch switch signal (CAN from ECM): OFF - Clutch interlock switch signal: ON (Battery voltage)
B26E9: S/L STATUS	<ul style="list-style-type: none"> • Inhibit engine cranking • Inhibit steering lock 	When BCM transmits the LOCK request signal to steering lock unit, and receives LOCK response signal from steering lock unit, the following conditions are fulfilled <ul style="list-style-type: none"> • Steering condition No. 1 signal: LOCK (0 V) • Steering condition No. 2 signal: LOCK (Battery voltage)

HIGH FLASHER OPERATION

BCM detects the turn signal lamp circuit status by the current value.
 BCM increases the turn signal lamp blinking speed if the bulb or harness open is detected with the turn signal lamp operating.

NOTE:

The blinking speed is normal while activating the hazard warning lamp.

DTC Inspection Priority Chart

INFOID:000000004685558

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Priority	DTC
1	B2562: LOW VOLTAGE
2	<ul style="list-style-type: none"> • U1000: CAN COMM • U1010: CONTROL UNIT(CAN)
3	<ul style="list-style-type: none"> • B2190: NATS ANTENNA AMP • B2191: DIFFERENCE OF KEY • B2192: ID DISCORD BCM-ECM • B2193: CHAIN OF BCM-ECM • B2195: ANTI SCANNING
4	<ul style="list-style-type: none"> • B2013: ID DISCORD BCM-S/L • B2014: CHAIN OF S/L-BCM • B2553: IGNITION RELAY • B2555: STOP LAMP • B2556: PUSH-BTN IGN SW • B2557: VEHICLE SPEED • B2560: STARTER CONT RELAY • B2601: SHIFT POSITION • B2602: SHIFT POSITION • B2603: SHIFT POSI STATUS • B2604: PNP SW • B2605: PNP SW • B2606: S/L RELAY • B2607: S/L RELAY • B2608: STARTER RELAY • B2609: S/L STATUS • B260A: IGNITION RELAY • B260B: STEERING LOCK UNIT • B260C: STEERING LOCK UNIT • B260D: STEERING LOCK UNIT • B260F: ENG STATE SIG LOST • B2612: S/L STATUS • B2614: ACC RELAY CIRC • B2615: BLOWER RELAY CIRC • B2616: IGN RELAY CIRC • B2617: STARTER RELAY CIRC • B2618: BCM • B2619: BCM • B261A: PUSH-BTN IGN SW • B261E: VEHICLE TYPE • B26E8: CLUTCH SW • B26E9: S/L STATUS • B26EA: KEY REGISTRATION • C1729: VHCL SPEED SIG ERR • U0415: VEHICLE SPEED SIG

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Priority	DTC	
5	<ul style="list-style-type: none"> • C1704: LOW PRESSURE FL • C1705: LOW PRESSURE FR • C1706: LOW PRESSURE RR • C1707: LOW PRESSURE RL • C1708: [NO DATA] FL • C1709: [NO DATA] FR • C1710: [NO DATA] RR • C1711: [NO DATA] RL • C1712: [CHECKSUM ERR] FL • C1713: [CHECKSUM ERR] FR • C1714: [CHECKSUM ERR] RR • C1715: [CHECKSUM ERR] RL • C1716: [PRESSDATA ERR] FL • C1717: [PRESSDATA ERR] FR • C1718: [PRESSDATA ERR] RR • C1719: [PRESSDATA ERR] RL • C1720: [CODE ERR] FL • C1721: [CODE ERR] FR • C1722: [CODE ERR] RR • C1723: [CODE ERR] RL • C1724: [BATT VOLT LOW] FL • C1725: [BATT VOLT LOW] FR • C1726: [BATT VOLT LOW] RR • C1727: [BATT VOLT LOW] RL • C1734: CONTROL UNIT 	A B C D E F G
6	<ul style="list-style-type: none"> • B2621: INSIDE ANTENNA • B2622: INSIDE ANTENNA • B2623: INSIDE ANTENNA 	H

DTC Index

INFOID:000000004685559

NOTE:

The details of time display are as follows.

- CRNT: A malfunction is detected now.
- PAST: A malfunction was detected in the past.

IGN counter is displayed on Freeze Frame Data. For details of Freeze Frame Data, refer to [BCS-14. "COMMON ITEM : CONSULT-III Function \(BCM - COMMON ITEM\)"](#).

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle condition	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Refer- ence page
No DTC is detected. further testing may be required.	—	—	—	—	—
U1000: CAN COMM	—	—	—	—	BCS-35
U1010: CONTROL UNIT(CAN)	—	—	—	—	BCS-36
U0415: VEHICLE SPEED SIG	—	—	—	—	BCS-37
B2013: ID DISCORD BCM-S/L	×	×	—	—	SEC-55
B2014: CHAIN OF S/L-BCM	×	×	—	—	SEC-56
B2190: NATS ANTENNA AMP	×	—	—	—	SEC-47
B2191: DIFFERENCE OF KEY	×	—	—	—	SEC-50
B2192: ID DISCORD BCM-ECM	×	—	—	—	SEC-51
B2193: CHAIN OF BCM-ECM	×	—	—	—	SEC-53
B2195: ANTI SCANNING	×	—	—	—	SEC-54
B2553: IGNITION RELAY	—	×	—	—	PCS-48
B2555: STOP LAMP	—	×	—	—	SEC-59

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle condition	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Refer- ence page
B2556: PUSH-BTN IGN SW	—	×	×	—	SEC-61
B2557: VEHICLE SPEED	×	×	×	—	SEC-63
B2560: STARTER CONT RELAY	×	×	×	—	SEC-64
B2562: LOW VOLTAGE	—	×	—	—	BCS-38
B2601: SHIFT POSITION	×	×	×	—	SEC-65
B2602: SHIFT POSITION	×	×	×	—	SEC-68
B2603: SHIFT POSI STATUS	×	×	×	—	SEC-70
B2604: PNP SW	×	×	×	—	SEC-73
B2605: PNP SW	×	×	×	—	SEC-75
B2606: S/L RELAY	×	×	×	—	SEC-77
B2607: S/L RELAY	×	×	×	—	SEC-78
B2608: STARTER RELAY	×	×	×	—	SEC-80
B2609: S/L STATUS	×	×	×	—	SEC-82
B260A: IGNITION RELAY	×	×	×	—	PCS-50
B260B: STEERING LOCK UNIT	—	×	×	—	SEC-86
B260C: STEERING LOCK UNIT	—	×	×	—	SEC-87
B260D: STEERING LOCK UNIT	—	×	×	—	SEC-88
B260F: ENG STATE SIG LOST	×	×	×	—	SEC-89
B2612: S/L STATUS	×	×	×	—	SEC-94
B2614: ACC RELAY CIRC	—	×	×	—	PCS-52
B2615: BLOWER RELAY CIRC	—	×	×	—	PCS-54
B2616: IGN RELAY CIRC	—	×	×	—	PCS-56
B2617: STARTER RELAY CIRC	×	×	×	—	SEC-98
B2618: BCM	×	×	×	—	PCS-58
B2619: BCM	×	×	×	—	SEC-100
B261A: PUSH-BTN IGN SW	—	×	×	—	PCS-59
B261E: VEHICLE TYPE	×	×	× (Turn ON for 15 seconds)	—	SEC-101
B2621: INSIDE ANTENNA	—	×	—	—	DLK-55
B2622: INSIDE ANTENNA	—	×	—	—	DLK-57
B2623: INSIDE ANTENNA	—	×	—	—	DLK-59
B26E8: CLUTCH SW	×	×	×	—	SEC-90
B26E9: S/L STATUS	×	×	× (Turn ON for 15 seconds)	—	SEC-92
B26EA: KEY REGISTRATION	—	×	× (Turn ON for 15 seconds)	—	SEC-93
C1704: LOW PRESSURE FL	—	—	—	×	WT-17
C1705: LOW PRESSURE FR	—	—	—	×	
C1706: LOW PRESSURE RR	—	—	—	×	
C1707: LOW PRESSURE RL	—	—	—	×	

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle condition	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Refer- ence page	
C1708: [NO DATA] FL	—	—	—	×	WT-19	A
C1709: [NO DATA] FR	—	—	—	×		B
C1710: [NO DATA] RR	—	—	—	×		C
C1711: [NO DATA] RL	—	—	—	×	WT-21	D
C1712: [CHECKSUM ERR] FL	—	—	—	×		
C1713: [CHECKSUM ERR] FR	—	—	—	×		
C1714: [CHECKSUM ERR] RR	—	—	—	×		
C1715: [CHECKSUM ERR] RL	—	—	—	×	WT-24	E
C1716: [PRESSDATA ERR] FL	—	—	—	×		
C1717: [PRESSDATA ERR] FR	—	—	—	×		
C1718: [PRESSDATA ERR] RR	—	—	—	×	WT-26	F
C1719: [PRESSDATA ERR] RL	—	—	—	×		
C1720: [CODE ERR] FL	—	—	—	×	WT-29	G
C1721: [CODE ERR] FR	—	—	—	×		
C1722: [CODE ERR] RR	—	—	—	×		
C1723: [CODE ERR] RL	—	—	—	×		
C1724: [BATT VOLT LOW] FL	—	—	—	×	WT-32	H
C1725: [BATT VOLT LOW] FR	—	—	—	×		
C1726: [BATT VOLT LOW] RR	—	—	—	×		
C1727: [BATT VOLT LOW] RL	—	—	—	×		
C1729: VHCL SPEED SIG ERR	—	—	—	×	WT-33	I
C1734: CONTROL UNIT	—	—	—	×		

ADP

K
L
M
N
O
P

MANUAL FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

MANUAL FUNCTION DOES NOT OPERATE

ALL COMPONENT

ALL COMPONENT : Description

INFOID:000000004535086

All functions do not operate when manually operated.(power seat, tilt & telescopic, and door mirror.

ALL COMPONENT : Diagnosis Procedure

INFOID:000000004535087

1.CHECK DRIVER SEAT CONTROL UNIT POWER SUPPLY AND GROUND CIRCUIT

Check driver seat control unit power supply and ground circuit.

Refer to [ADP-64. "DRIVER SEAT CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK AUTOMATIC DRIVE POSITIONER CONTROL UNIT POWER SUPPLY AND GROUND CIRCUIT

Check automatic drive positioner control unit power supply and ground circuit.

Refer to [ADP-65. "AUTOMATIC DRIVE POSITIONER CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-41. "Intermittent Incident"](#).

NO >> GO TO 1.

POWER SEAT

POWER SEAT : Description

INFOID:000000004535088

Power seat does not operate when manually operated.

POWER SEAT : Diagnosis Procedure

INFOID:000000004535089

1.CHECK POWER SEAT SWITCH GROUND CIRCUIT

Check power seat switch ground circuit.

Refer to [ADP-95. "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness or connector.

2.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-41. "Intermittent Incident"](#).

NO >> GO TO 1.

STEERING POSITION FUNCTION DOES NOT OPERATE

STEERING POSITION FUNCTION DOES NOT OPERATE : Description

INFOID:000000004535090

Tilt & telescopic do not operate when manually operated.

MANUAL FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

STEERING POSITION FUNCTION DOES NOT OPERATE : Diagnosis Procedure

INFOID:000000004535091

1.CHECK TILT & TELESCOPIC SWITCH GROUND CIRCUIT

Check tilt & telescopic switch ground circuit.

Refer to [ADP-96, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness or connector.

2.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> GO TO 1.

SEAT SLIDING

SEAT SLIDING : Description

INFOID:000000004535092

Seat sliding alone does not operate when manually operated.

SEAT SLIDING : Diagnosis Procedure

INFOID:000000004535093

1.CHECK SLIDING MECHANISM

Check for the following.

- Mechanism deformation or pinched foreign materials.
- Interference with other parts because of poor installation.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK SLIDING SWITCH

Check sliding switch.

Refer to [ADP-67, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CHECK SLIDING MOTOR

Check sliding motor.

Refer to [ADP-124, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4.CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> GO TO 1.

SEAT RECLINING

SEAT RECLINING : Description

INFOID:000000004535094

Seat reclining only does not operate when manually operated.

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

MANUAL FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

SEAT RECLINING : Diagnosis Procedure

INFOID:000000004535095

1.CHECK RECLINING MECHANISM

Check for the following.

- Mechanism deformation or pinched foreign materials.
- Interference with other parts because of poor installation.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK RECLINING SWITCH

Check reclining switch.

Refer to [ADP-104. "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CHECK RECLINING MOTOR

Check reclining motor.

Refer to [ADP-126. "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4.CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-41. "Intermittent Incident"](#).

NO >> GO TO 1.

SEAT LIFTING (FRONT)

SEAT LIFTING (FRONT) : Description

INFOID:000000004535096

Seat lifting (front) only does not operate when manually operated.

SEAT LIFTING (FRONT) : Diagnosis Procedure

INFOID:000000004535097

1.CHECK LIFTING (FRONT) MECHANISM

Check for the following.

- Mechanism deformation or pinched foreign materials.
- Interference with other parts because of poor installation.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK LIFTING SWITCH (FRONT)

Check lifting switch (front).

Refer to [ADP-71. "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CHECK LIFTING MOTOR (FRONT)

Check lifting motor (front).

Refer to [ADP-128. "Component Function Check"](#).

Is the inspection result normal?

MANUAL FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

- YES >> GO TO 4.
NO >> Repair or replace the malfunctioning parts.

4.CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

- YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
NO >> GO TO 1.

SEAT LIFTING (REAR)

SEAT LIFTING (REAR) : Description

INFOID:000000004535098

Seat lifting (rear) only does not operate when manually operated.

SEAT LIFTING (REAR) : Diagnosis Procedure

INFOID:000000004535099

1.CHECK LIFTING (REAR) MECHANISM

Check for the following.

- Mechanism deformation or pinched foreign materials.
- Interference with other parts because of poor installation.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace the malfunctioning parts.

2.CHECK LIFTING SWITCH (REAR)

Check lifting switch (rear).

Refer to [ADP-73, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace the malfunctioning parts.

3.CHECK LIFTING MOTOR (REAR)

Check lifting motor (rear).

Refer to [ADP-130, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace the malfunctioning parts.

4.CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

- YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
NO >> GO TO 1.

STEERING TILT

STEERING TILT : Description

INFOID:000000004535100

Steering tilt only does not operate when manually operated.

STEERING TILT : Diagnosis Procedure

INFOID:000000004535101

1.CHECK STEERING TILT MECHANISM

Check for the following.

- Mechanism deformation or pinched foreign materials.
- Interference with other parts because of poor installation.

Is the inspection result normal?

- YES >> GO TO 2.

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

MANUAL FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

NO >> Repair or replace the malfunctioning parts.

2.CHECK TILT SWITCH

Check tilt switch.

Refer to [ADP-83, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CHECK TILT MOTOR

Check tilt motor.

Refer to [ADP-132, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4.CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> GO TO 1.

STEERING TELESCOPIC

STEERING TELESCOPIC : Description

INFOID:000000004535102

Steering telescopic only does not operate when manually operated.

STEERING TELESCOPIC : Diagnosis Procedure

INFOID:000000004535103

1.CHECK STEERING TELESCOPIC MECHANISM

Check for the following.

- Mechanism deformation or pinched foreign materials.
- Interference with other parts because of poor installation.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK TELESCOPIC SWITCH

Check telescopic switch.

Refer to [ADP-85, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CHECK TELESCOPIC MOTOR

Check telescopic motor.

Refer to [ADP-134, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4.CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> GO TO 1.

DOOR MIRROR

MANUAL FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

DOOR MIRROR : Description

INFOID:000000004535104

Door mirror does not operate when manually operated.

DOOR MIRROR : Diagnosis Procedure

INFOID:000000004535105

1.CHECK DOOR MIRROR MECHANISM

Check for the following.

- Mechanism deformation or pinched foreign materials.
- Interference with other parts because of poor installation.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK MIRROR SWITCH

Check mirror switch.

Refer to [ADP-90. "MIRROR SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CHECK MIRROR MOTOR

Check mirror motor.

Refer to [ADP-136. "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4.CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-41. "Intermittent Incident"](#).

NO >> GO TO 1.

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

MEMORY FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

MEMORY FUNCTION DOES NOT OPERATE

ALL COMPONENT

ALL COMPONENT : Description

INFOID:000000004535106

All functions do not operate when memory operated. (power seat, tilt & telescopic, and door mirror)

ALL COMPONENT : Diagnosis Procedure

INFOID:000000004535107

1.CHECK MANUAL OPERATION

Check manual operation.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refer to [ADP-212, "ALL COMPONENT : Diagnosis Procedure"](#)

2.PERFORM MEMORY STORING PROCEDURE

Perform memory storing procedure.

Refer to [ADP-10, "MEMORY STORING : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> Memory function is normal.

NO >> GO TO 3.

3.CHECK SEAT MEMORY SWITCH

Check seat memory switch.

Refer to [ADP-87, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace seat memory switch.

4.CHECK DETENTION SWITCH

Check detention switch.

Refer to [ADP-97, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> GO TO 1.

SEAT SLIDING

SEAT SLIDING : Description

INFOID:000000004535108

Seat sliding only does not operate when memory operated.

SEAT SLIDING : Diagnosis Procedure

INFOID:000000004535109

1.CHECK MANUAL OPERATION

Check manual operation.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refer to [ADP-213, "SEAT SLIDING : Diagnosis Procedure"](#)

2.CHECK SLIDING SENSOR

Check sliding sensor.

MEMORY FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

Refer to [ADP-101, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

- YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
- NO >> GO TO 1.

SEAT RECLINING

SEAT RECLINING : Description

INFOID:000000004535110

Seat reclining only does not operate when memory operated.

SEAT RECLINING : Diagnosis Procedure

INFOID:000000004535111

1.CHECK MANUAL OPERATION

Check manual operation.

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Refer to [ADP-214, "SEAT RECLINING : Diagnosis Procedure"](#)

2.CHECK RECLINING SENSOR

Check reclining sensor.

Refer to [ADP-104, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

- YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
- NO >> GO TO 1.

SEAT LIFTING (FRONT)

SEAT LIFTING (FRONT) : Description

INFOID:000000004535112

Seat lifting (front) only does not operate when memory operated.

SEAT LIFTING (FRONT) : Diagnosis Procedure

INFOID:000000004535113

1.CHECK MANUAL OPERATION

Check manual operation.

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Refer to [ADP-214, "SEAT LIFTING \(FRONT\) : Diagnosis Procedure"](#)

2.CHECK LIFTING SENSOR (FRONT)

Check lifting sensor (front).

Refer to [ADP-107, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace the malfunctioning parts.

A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O

P

MEMORY FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

3.CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> GO TO 1.

SEAT LIFTING (REAR)

SEAT LIFTING (REAR) : Description

INFOID:000000004535114

Seat lifting (rear) only does not operate when memory operated.

SEAT LIFTING (REAR) : Diagnosis Procedure

INFOID:000000004535115

1.CHECK MANUAL OPERATION

Check manual operation.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refer to [ADP-215, "SEAT LIFTING \(REAR\) : Diagnosis Procedure"](#)

2.CHECK LIFTING SENSOR (REAR)

Check lifting sensor (rear).

Refer to [ADP-110, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> GO TO 1.

STEERING TELESCOPIC

STEERING TELESCOPIC : Description

INFOID:000000004535116

Steering telescopic only does not operate when memory operated.

STEERING TELESCOPIC : Diagnosis Procedure

INFOID:000000004535117

1.CHECK MANUAL OPERATION

Check manual operation.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refer to [ADP-216, "STEERING TELESCOPIC : Diagnosis Procedure"](#)

2.CHECK TELESCOPIC SENSOR

Check steering telescopic sensor.

Refer to [ADP-116, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

MEMORY FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

NO >> GO TO 1.

STEERING TILT

STEERING TILT : Description

INFOID:000000004535118

Steering tilt only does not operate when memory operated.

STEERING TILT : Diagnosis Procedure

INFOID:000000004535119

1.CHECK MANUAL OPERATION

Check manual operation.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refer to [ADP-215, "STEERING TILT : Diagnosis Procedure"](#)

2.CHECK TILT SENSOR

Check steering tilt sensor.

Refer to [ADP-113, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> GO TO 1.

DOOR MIRROR

DOOR MIRROR : Description

INFOID:000000004535120

Door mirror does not operate when memory operated.

DOOR MIRROR : Diagnosis Procedure

INFOID:000000004535121

1.CHECK MANUAL OPERATION

Check manual operation.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refer to [ADP-217, "DOOR MIRROR : Diagnosis Procedure"](#)

2.CHECK MIRROR SENSOR

Check mirror sensor.

• Refer to [ADP-119, "DRIVER SIDE : Component Function Check"](#). (Driver side)

• Refer to [ADP-121, "PASSENGER SIDE : Component Function Check"](#). (Passenger side)

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> GO TO 1.

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

MEMORY INDICATE DOES NOT ILLUMINATE

< SYMPTOM DIAGNOSIS >

MEMORY INDICATE DOES NOT ILLUMINATE

Diagnosis Procedure

INFOID:000000004535122

1. CHECK MEMORY INDICATOR

Check memory indicator.

Refer to [ADP-139, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> GO TO 1.

SEAT SYNCHRONIZATION FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

SEAT SYNCHRONIZATION FUNCTION DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000004535123

1.CHECK SYSTEM SETTING

Check system setting.

Refer to [ADP-11, "SYSTEM SETTING : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> Synchronization function is normal.

NO >> GO TO 2.

2.CHECK ALL FUNCTIONS MAMUAL OPERATION

Check all functions manual operation.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Refer to [ADP-212, "ALL COMPONENT : Diagnosis Procedure"](#).

3.CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> GO TO 1.

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

POWER WALK-IN FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

POWER WALK-IN FUNCTION DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000004535124

1. CHECK POWER WALK-IN FUNCTION

Check power walk-in function.

Refer to [ADP-39, "POWER WALK-IN FUNCTION : System Description"](#).

Is the inspection result normal?

- YES >> Power walk-in function is OK.
- NO >> GO TO 2.

2. PERFORM INITIALIZATION PROCEDURE

1. Perform initialization procedure.

Refer to [ADP-10, "SYSTEM INITIALIZATION : Special Repair Requirement"](#).

2. Check power walk-in function.

Refer to [ADP-39, "POWER WALK-IN FUNCTION : System Description"](#).

Is the inspection result normal?

- YES >> Power walk-in function is normal.
- NO >> GO TO 3.

3. CHECK POWER WALK-IN SWITCH

Check power walk-in switch.

Refer to [ADP-81, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair or replace the malfunctioning parts.

4. CHECK SEAT BELT BUCKLE SWITCH

Check seat belt buckle switch.

Refer to [ADP-77, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Repair or replace the malfunctioning parts.

5. CHECK FORWARD SWITCH

Check forward switch.

Refer to [ADP-75, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 6.
- NO >> Repair or replace the malfunctioning parts.

6. CHECK SLIDING LIMIT SWITCH

Check sliding limit switch.

Refer to [ADP-79, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 7.
- NO >> Repair or replace the malfunctioning parts.

7. CHECK DRIVER SIDE DOOR SWITCH

Check driver side door switch.

Refer to [DLK-62, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 8.
- NO >> Repair or replace the malfunctioning parts.

8. CONFIRM THE OPERATION

Check the operation again.

POWER WALK-IN FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

Refer to [ADP-39. "POWER WALK-IN FUNCTION : System Description"](#).

Is the result normal?

- YES >> Check intermittent incident. Refer to [GI-41. "Intermittent Incident"](#).
- NO >> GO TO 1.

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

INTELLIGENT KEY INTERLOCK FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

INTELLIGENT KEY INTERLOCK FUNCTION DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000004535125

1. CHECK DOOR LOCK FUNCTION

Check door lock function.

Refer to [DLK-7, "Work Flow"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. PERFORM MEMORY STORING PROCEDURE

1. Perform memory storing procedure.

Refer to [ADP-10, "MEMORY STORING : Special Repair Requirement"](#).

2. Check Intelligent Key interlock function.

Refer to [ADP-34, "INTELLIGENT KEY INTERLOCK FUNCTION : System Description"](#).

Is the inspection result normal?

YES >> Intelligent Key inter lock function is normal.

NO >> GO TO 1.

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

NORMAL OPERATING CONDITION

Description

INFOID:000000004535126

The following symptoms are normal operations, and they do not indicate a malfunction.

Symptom	Cause	Action to take	Reference page
Seat synchronization function does not operate.	The synchronization function will not operate if the steering (tilt, telescopic) or the door mirror moves to the operating end while the seat synchronization function is operating.	Perform the memory function or drive the vehicle at more than 7km/h (4 MPH).	ADP-24
	Seat adjustment value has exceed any of the values below. <ul style="list-style-type: none"> • Seat sliding: 76 mm • Seat reclining: 9.1 degrees • Seat lifting (rear): 20 mm 	—	—
Side support or lumbar support does not perform memory operation.	The side support and the lumbar support are controlled independently with no link to the automatic drive positioner system.	—	Side support: SE-23
			Lumbar support: SE-26
Memory function, power walk-in function, seat synchronization function, or Intelligent Key interlock function does not operate.	The operating conditions are not fulfilled.	Fulfill the operation conditions.	Memory function: ADP-29
			Power walk-in function: ADP-39
			Seat synchronization function: ADP-24
			Intelligent Key interlock function: ADP-34

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000004250425

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIR BAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precaution for Battery Service

INFOID:000000004535059

Before disconnecting the battery, lower both the driver and passenger windows. This will prevent any interference between the window edge and the vehicle when the door is opened/closed. During normal operation, the window slightly raises and lowers automatically to prevent any window to vehicle interference. The automatic window function will not work with the battery disconnected.

Service

INFOID:000000004250426

- When removing or installing various parts, place a cloth or padding onto the vehicle body to prevent scratches.
- Handle trim, molding, instruments, grille, etc. carefully during removing or installing. Be careful not to oil or damage them.
- Apply sealing compound where necessary when installing parts.
- When applying sealing compound, be careful that the sealing compound does not protrude from parts.
- When replacing any metal parts (for example body outer panel, members, etc.), be sure to take rust prevention measures.

Work

INFOID:000000004250427

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and keep them.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with new one.

PRECAUTIONS

< PRECAUTION >

- Be sure to tighten bolts and nuts securely to the specified torque.
- After re-installation is completed, be sure to check that each part works normally.
- Follow the steps below to clean components.
- Water soluble foul: Dip a soft cloth into lukewarm water, and wring the water out of the cloth to wipe the fouled area.
Then rub with a soft and dry cloth.
- Oily foul: Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%), and wipe the fouled area.
Then dip a cloth into fresh water, and wring the water out of the cloth to wipe the detergent off. Then rub with a soft and dry cloth.
- Do not use organic solvent such as thinner, benzene, alcohol, and gasoline.
- For genuine leather seats, use a genuine leather seat cleaner.

A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O

P

DRIVER SEAT CONTROL UNIT

< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION

DRIVER SEAT CONTROL UNIT

Exploded View

INFOID:000000004250428

Refer to [SE-179, "Exploded View"](#).

Removal and Installation


INFOID:000000004250429

REMOVAL

CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

1. Remove driver seat (1). Refer to [SE-182, "Removal and Installation"](#).
2. Remove mounting bolts (A).
3. Remove driver seat control unit (2).



INSTALLATION

Install in reverse order of removal.

CAUTION:

Be sure to clump the harness to the right place.

NOTE:

After installing driver seat, perform additional service when replacing control unit. Refer to [ADP-9, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< REMOVAL AND INSTALLATION >

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

Exploded View

INFOID:000000004250430

Refer to [IP-11. "Exploded View"](#).

Removal and Installation


INFOID:000000004250431

REMOVAL

CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

1. Remove instrument driver lower panel. Refer to [IP-12. "Removal and Installation"](#).
2. Remove screws (A).
3. Remove automatic drive positioner control unit (1).



INSTALLATION

Install in reverse order of removal.

CAUTION:

Be sure to clump the harness to the right place.

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

SEAT MEMORY SWITCH

< REMOVAL AND INSTALLATION >

SEAT MEMORY SWITCH

Exploded View

INFOID:000000004250432

Refer to [INT-11, "Exploded View"](#)

Removal and Installation


INFOID:000000004250433

REMOVAL

CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

1. Remove front door finisher (1). Refer to [INT-11, "Removal and Installation"](#).
2. Press pawls and remove seat memory switch (2) from front door finisher (1).



INSTALLATION

Install in reverse order of removal.

CAUTION:

Be sure to clump the harness to the right place.

POWER SEAT SWITCH

< REMOVAL AND INSTALLATION >

POWER SEAT SWITCH

Exploded View

INFOID:000000004250434

Refer to [SE-179, "Exploded View"](#).

Removal and Installation


INFOID:000000004250435

REMOVAL

CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

1. Remove seat cushion outer finisher (1). Refer to [SE-182, "Removal and Installation"](#).
2. Remove screws (A).
3. Remove power seat switch (2) from seat cushion outer finisher (1).



INSTALLATION

Install in reverse order of removal.

CAUTION:

Be sure to clump the harness to the right place.

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

SIDE SUPPORT SWITCH

< REMOVAL AND INSTALLATION >

SIDE SUPPORT SWITCH

Exploded View

INFOID:000000004250436

Refer to [SE-179. "Exploded View"](#)

Removal and Installation


INFOID:000000004250437

REMOVAL

CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

1. Remove seat cushion outer finisher (1). Refer to [SE-182. "Removal and Installation"](#)
2. Remove screws (A).
3. Remove side support switch (2) from seat cushion outer finisher.



INSTALLATION

Install in reverse order of removal.

CAUTION:

Be sure to clump the harness to the right place.

TILT&TELESCOPIC SWITCH

< REMOVAL AND INSTALLATION >

TILT&TELESCOPIC SWITCH

Exploded View

INFOID:000000004250438

Refer to [JP-11, "Exploded View"](#).

Removal and Installation


INFOID:000000004250439

REMOVAL

CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

1. Remove steering column mask (1). Refer to [JP-12, "Removal and Installation"](#).
2. Press pawls and remove tilt & telescopic switch (2) from steering column mask (1).



INSTALLATION

Install in reverse order of removal.

CAUTION:

Be sure to clump the harness to the right place.

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP