

SECTION **ADP**

AUTOMATIC DRIVE POSITIONER

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

CONTENTS

| | |
|--|--|
| <p>BASIC INSPECTION 6</p> <p>DIAGNOSIS AND REPAIR WORK FLOW 6</p> <p style="padding-left: 20px;">Work Flow6</p> <p>INSPECTION AND ADJUSTMENT 9</p> <p>ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL9</p> <p style="padding-left: 20px;">ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Description9</p> <p style="padding-left: 20px;">ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement9</p> <p>ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT9</p> <p style="padding-left: 20px;">ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description9</p> <p style="padding-left: 20px;">ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement9</p> <p>SYSTEM INITIALIZATION 10</p> <p style="padding-left: 20px;">SYSTEM INITIALIZATION : Description 10</p> <p style="padding-left: 20px;">SYSTEM INITIALIZATION : Special Repair Requirement 10</p> <p>MEMORY STORING 10</p> <p style="padding-left: 20px;">MEMORY STORING : Description 10</p> <p style="padding-left: 20px;">MEMORY STORING : Special Repair Requirement 10</p> <p>SYSTEM SETTING 11</p> <p style="padding-left: 20px;">SYSTEM SETTING : Description 11</p> <p style="padding-left: 20px;">SYSTEM SETTING : Special Repair Requirement 11</p> <p>SYSTEM DESCRIPTION 13</p> <p>AUTOMATIC DRIVE POSITIONER SYSTEM..... 13</p> <p>AUTOMATIC DRIVE POSITIONER SYSTEM 13</p> | <p>AUTOMATIC DRIVE POSITIONER SYSTEM :</p> <p style="padding-left: 20px;">System Diagram13</p> <p>AUTOMATIC DRIVE POSITIONER SYSTEM :</p> <p style="padding-left: 20px;">System Description14</p> <p>AUTOMATIC DRIVE POSITIONER SYSTEM :</p> <p style="padding-left: 20px;">Component Parts Location15</p> <p>AUTOMATIC DRIVE POSITIONER SYSTEM :</p> <p style="padding-left: 20px;">Component Description17</p> <p>MANUAL FUNCTION19</p> <p style="padding-left: 20px;">MANUAL FUNCTION : System Diagram19</p> <p style="padding-left: 20px;">MANUAL FUNCTION : System Description19</p> <p style="padding-left: 20px;">MANUAL FUNCTION : Component Parts Location21</p> <p style="padding-left: 20px;">MANUAL FUNCTION : Component Description23</p> <p>SEAT SYNCHRONIZATION FUNCTION24</p> <p style="padding-left: 20px;">SEAT SYNCHRONIZATION FUNCTION : System Diagram24</p> <p style="padding-left: 20px;">SEAT SYNCHRONIZATION FUNCTION : System Description24</p> <p style="padding-left: 20px;">SEAT SYNCHRONIZATION FUNCTION : Component Parts Location26</p> <p style="padding-left: 20px;">SEAT SYNCHRONIZATION FUNCTION : Component Description28</p> <p>MEMORY FUNCTION29</p> <p style="padding-left: 20px;">MEMORY FUNCTION : System Diagram29</p> <p style="padding-left: 20px;">MEMORY FUNCTION : System Description29</p> <p style="padding-left: 20px;">MEMORY FUNCTION : Component Parts Location31</p> <p style="padding-left: 20px;">MEMORY FUNCTION : Component Description.....33</p> <p>INTELLIGENT KEY INTERLOCK FUNCTION34</p> <p style="padding-left: 20px;">INTELLIGENT KEY INTERLOCK FUNCTION : System Diagram34</p> <p style="padding-left: 20px;">INTELLIGENT KEY INTERLOCK FUNCTION : System Description34</p> <p style="padding-left: 20px;">INTELLIGENT KEY INTERLOCK FUNCTION : Component Parts Location36</p> <p style="padding-left: 20px;">INTELLIGENT KEY INTERLOCK FUNCTION : Component Description38</p> |
|--|--|

ADP

| | | | |
|---|-----------|--|-----------|
| POWER WALK-IN FUNCTION | 38 | DRIVER SEAT CONTROL UNIT : | |
| POWER WALK-IN FUNCTION : System Diagram.. | 39 | Diagnosis Procedure | 64 |
| POWER WALK-IN FUNCTION : System Description | 39 | DRIVER SEAT CONTROL UNIT : Special Repair Requirement | 65 |
| POWER WALK-IN FUNCTION : Component Parts Location | 41 | AUTOMATIC DRIVE POSITIONER CONTROL UNIT | 65 |
| POWER WALK-IN FUNCTION : Component Description | 43 | AUTOMATIC DRIVE POSITIONER CONTROL UNIT : Diagnosis Procedure | 65 |
| DIAGNOSIS SYSTEM (DRIVER SEAT C/U) | 45 | AUTOMATIC DRIVE POSITIONER CONTROL UNIT : Special Repair Requirement | 66 |
| CONSULT Function | 45 | SLIDING SWITCH | 67 |
| DTC/CIRCUIT DIAGNOSIS | 48 | Description | 67 |
| U1000 CAN COMM CIRCUIT | 48 | Component Function Check | 67 |
| Description | 48 | Diagnosis Procedure | 67 |
| DTC Logic | 48 | Component Inspection | 68 |
| Diagnosis Procedure | 48 | RECLINING SWITCH | 69 |
| Special Repair Requirement | 48 | Description | 69 |
| B2112 SLIDING MOTOR | 49 | Component Function Check | 69 |
| Description | 49 | Diagnosis Procedure | 69 |
| DTC Logic | 49 | Component Inspection | 70 |
| Diagnosis Procedure | 49 | LIFTING SWITCH (FRONT) | 71 |
| B2113 RECLINING MOTOR | 51 | Description | 71 |
| Description | 51 | Component Function Check | 71 |
| DTC Logic | 51 | Diagnosis Procedure | 71 |
| Diagnosis Procedure | 51 | Component Inspection | 72 |
| B2118 TILT SENSOR | 53 | LIFTING SWITCH (REAR) | 73 |
| Description | 53 | Description | 73 |
| DTC Logic | 53 | Component Function Check | 73 |
| Diagnosis Procedure | 53 | Diagnosis Procedure | 73 |
| B2119 TELESCOPIC SENSOR | 56 | Component Inspection | 74 |
| Description | 56 | FORWARD SWITCH | 75 |
| DTC Logic | 56 | Description | 75 |
| Diagnosis Procedure | 56 | Component Function Check | 75 |
| B2126 DETENT SW | 59 | Diagnosis Procedure | 75 |
| Description | 59 | Component Inspection | 76 |
| DTC Logic | 59 | SEAT BELT BUCKLE SWITCH | 77 |
| Diagnosis Procedure | 59 | Description | 77 |
| B2127 PARKING BRAKE SWITCH | 61 | Component Function Check | 77 |
| Description | 61 | Diagnosis Procedure | 77 |
| DTC Logic | 61 | Component Inspection | 78 |
| Diagnosis Procedure | 61 | SLIDING LIMIT SWITCH | 79 |
| Component Inspection | 62 | Description | 79 |
| B2128 UART COMMUNICATION LINE | 63 | Component Function Check | 79 |
| Description | 63 | Diagnosis Procedure | 79 |
| DTC Logic | 63 | Component Inspection | 80 |
| Diagnosis Procedure | 63 | POWER WALK-IN SWITCH | 81 |
| POWER SUPPLY AND GROUND CIRCUIT | 64 | Description | 81 |
| BCM | 64 | Component Function Check | 81 |
| BCM : Diagnosis Procedure | 64 | Diagnosis Procedure | 81 |
| DRIVER SEAT CONTROL UNIT | 64 | Component Inspection | 82 |
| | | TILT SWITCH | 83 |

| | | | |
|--|------------|--|------------|
| Description | 83 | Diagnosis Procedure | 104 |
| Component Function Check | 83 | LIFTING SENSOR (FRONT) | 107 |
| Diagnosis Procedure | 83 | Description | 107 |
| Component Inspection | 84 | Component Function Check | 107 |
| TELESCOPIC SWITCH | 85 | Diagnosis Procedure | 107 |
| Description | 85 | LIFTING SENSOR (REAR) | 110 |
| Component Function Check | 85 | Description | 110 |
| Diagnosis Procedure | 85 | Component Function Check | 110 |
| Component Inspection | 86 | Diagnosis Procedure | 110 |
| SEAT MEMORY SWITCH | 87 | TILT SENSOR | 113 |
| Description | 87 | Description | 113 |
| Component Function Check | 87 | Component Function Check | 113 |
| Diagnosis Procedure | 87 | Diagnosis Procedure | 113 |
| Component Inspection | 88 | TELESCOPIC SENSOR | 116 |
| DOOR MIRROR REMOTE CONTROL SWITCH | 90 | Description | 116 |
| MIRROR SWITCH | 90 | Component Function Check | 116 |
| MIRROR SWITCH : Description | 90 | Diagnosis Procedure | 116 |
| MIRROR SWITCH : Component Function Check | 90 | MIRROR SENSOR | 119 |
| MIRROR SWITCH : Diagnosis Procedure | 90 | DRIVER SIDE | 119 |
| MIRROR SWITCH : Component Inspection | 91 | DRIVER SIDE : Description | 119 |
| CHANGEOVER SWITCH | 92 | DRIVER SIDE : Component Function Check | 119 |
| CHANGEOVER SWITCH : Description | 92 | DRIVER SIDE : Diagnosis Procedure | 119 |
| CHANGEOVER SWITCH : Component Function Check | 92 | PASSENGER SIDE | 121 |
| CHANGEOVER SWITCH : Diagnosis Procedure | 92 | PASSENGER SIDE : Description | 121 |
| CHANGEOVER SWITCH : Component Inspection | 93 | PASSENGER SIDE : | |
| POWER SEAT SWITCH GROUND CIRCUIT | 95 | Component Function Check | 121 |
| Diagnosis Procedure | 95 | PASSENGER SIDE : Diagnosis Procedure | 121 |
| TILT & TELESCOPIC SWITCH GROUND CIRCUIT | 96 | SLIDING MOTOR | 124 |
| Diagnosis Procedure | 96 | Description | 124 |
| DETENTION SWITCH | 97 | Component Function Check | 124 |
| Description | 97 | Diagnosis Procedure | 124 |
| Component Function Check | 97 | Component Inspection | 125 |
| Diagnosis Procedure | 97 | RECLINING MOTOR | 126 |
| Component Inspection | 98 | Description | 126 |
| PARKING BRAKE SWITCH | 99 | Component Function Check | 126 |
| Description | 99 | Diagnosis Procedure | 126 |
| Component Function Check | 99 | Component Inspection | 127 |
| Diagnosis Procedure | 99 | LIFTING MOTOR (FRONT) | 128 |
| Component Inspection | 100 | Description | 128 |
| SLIDING SENSOR | 101 | Component Function Check | 128 |
| Description | 101 | Diagnosis Procedure | 128 |
| Component Function Check | 101 | Component Inspection | 129 |
| Diagnosis Procedure | 101 | LIFTING MOTOR (REAR) | 130 |
| RECLINING SENSOR | 104 | Description | 130 |
| Description | 104 | Component Function Check | 130 |
| Component Function Check | 104 | Diagnosis Procedure | 130 |
| DIAGNOSIS PROCEDURE | 104 | Component Inspection | 131 |
| Diagnosis Procedure | 104 | TILT MOTOR | 132 |
| ADP | | Description | 132 |
| | | Component Function Check | 132 |

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

| | | | |
|--|------------|--|------------|
| Diagnosis Procedure | 132 | SEAT SLIDING | 190 |
| Component Inspection | 133 | SEAT SLIDING : Description | 190 |
| TELESCOPIC MOTOR | 134 | SEAT SLIDING : Diagnosis Procedure | 190 |
| Description | 134 | SEAT RECLINING | 190 |
| Component Function Check | 134 | SEAT RECLINING : Description | 190 |
| Diagnosis Procedure | 134 | SEAT RECLINING : Diagnosis Procedure | 191 |
| Component Inspection | 135 | SEAT LIFTING (FRONT) | 191 |
| DOOR MIRROR MOTOR | 136 | SEAT LIFTING (FRONT) : Description | 191 |
| Description | 136 | SEAT LIFTING (FRONT) : Diagnosis Procedure | 191 |
| Component Function Check | 136 | SEAT LIFTING (REAR) | 192 |
| Diagnosis Procedure | 136 | SEAT LIFTING (REAR) : Description | 192 |
| Component Inspection | 137 | SEAT LIFTING (REAR) : Diagnosis Procedure | 192 |
| SEAT MEMORY INDICATOR | 139 | STEERING TILT | 192 |
| Description | 139 | STEERING TILT : Description | 192 |
| Component Function Check | 139 | STEERING TILT : Diagnosis Procedure | 192 |
| Diagnosis Procedure | 139 | STEERING TELESCOPIC | 193 |
| ECU DIAGNOSIS INFORMATION | 141 | STEERING TELESCOPIC : Description | 193 |
| BCM (BODY CONTROL MODULE) | 141 | STEERING TELESCOPIC : Diagnosis Procedure | 193 |
| Reference Value | 141 | DOOR MIRROR | 193 |
| Wiring Diagram - BCM - | 164 | DOOR MIRROR : Description | 194 |
| Fail-safe | 167 | DOOR MIRROR : Diagnosis Procedure | 194 |
| DTC Inspection Priority Chart | 168 | MEMORY FUNCTION DOES NOT OPERATE. | 195 |
| DTC Index | 169 | ALL COMPONENT | 195 |
| DRIVER SEAT CONTROL UNIT (WITH AU- | | ALL COMPONENT : Description | 195 |
| TOMATIC DRIVE POSITIONER) | 172 | ALL COMPONENT : Diagnosis Procedure | 195 |
| Reference Value | 172 | SEAT SLIDING | 195 |
| Wiring Diagram - AUTOMATIC DRIVE POSI- | | SEAT SLIDING : Description | 195 |
| TIONER CONTROL SYSTEM - | 178 | SEAT SLIDING : Diagnosis Procedure | 195 |
| Fail Safe | 180 | SEAT RECLINING | 196 |
| DTC Index | 181 | SEAT RECLINING : Description | 196 |
| AUTOMATIC DRIVE POSITIONER CON- | | SEAT RECLINING : Diagnosis Procedure | 196 |
| TROL UNIT | 182 | SEAT LIFTING (FRONT) | 196 |
| Reference Value | 182 | SEAT LIFTING (FRONT) : Description | 196 |
| Wiring Diagram - AUTOMATIC DRIVE POSI- | | SEAT LIFTING (FRONT) : Diagnosis Procedure | 196 |
| TIONER CONTROL SYSTEM - | 186 | SEAT LIFTING (REAR) | 197 |
| SYMPTOM DIAGNOSIS | 189 | SEAT LIFTING (REAR) : Description | 197 |
| MANUAL FUNCTION DOES NOT OPERATE | 189 | SEAT LIFTING (REAR) : Diagnosis Procedure | 197 |
| ALL COMPONENT | 189 | STEERING TELESCOPIC | 197 |
| ALL COMPONENT : Description | 189 | STEERING TELESCOPIC : Description | 197 |
| ALL COMPONENT : Diagnosis Procedure | 189 | STEERING TELESCOPIC : Diagnosis Procedure | 197 |
| POWER SEAT | 189 | STEERING TILT | 198 |
| POWER SEAT : Description | 189 | STEERING TILT : Description | 198 |
| POWER SEAT : Diagnosis Procedure | 189 | STEERING TILT : Diagnosis Procedure | 198 |
| STEERING POSITION FUNCTION DOES NOT | | DOOR MIRROR | 198 |
| OPERATE | 189 | DOOR MIRROR : Description | 198 |
| STEERING POSITION FUNCTION DOES NOT | | DOOR MIRROR : Diagnosis Procedure | 198 |
| OPERATE : Description | 189 | MEMORY INDICATE DOES NOT ILLUMI- | 199 |
| STEERING POSITION FUNCTION DOES NOT | | NATE | |
| OPERATE : Diagnosis Procedure | 190 | | |

| | | | | |
|--|------------|--|------------|---|
| Diagnosis Procedure | 199 | REMOVAL AND INSTALLATION | 207 | |
| SEAT SYNCHRONIZATION FUNCTION DOES NOT OPERATE | 200 | DRIVER SEAT CONTROL UNIT | 207 | A |
| Diagnosis Procedure | 200 | Exploded View | 207 | |
| POWER WALK-IN FUNCTION DOES NOT OPERATE | 201 | Removal and Installation | 207 | B |
| Diagnosis Procedure | 201 | AUTOMATIC DRIVE POSITIONER CONTROL UNIT | 208 | |
| INTELLIGENT KEY INTERLOCK FUNCTION DOES NOT OPERATE | 203 | Exploded View | 208 | C |
| Diagnosis Procedure | 203 | Removal and Installation | 208 | |
| NORMAL OPERATING CONDITION | 204 | SEAT MEMORY SWITCH | 209 | D |
| Description | 204 | Exploded View | 209 | |
| PRECAUTION | 205 | Removal and Installation | 209 | E |
| PRECAUTIONS | 205 | POWER SEAT SWITCH | 210 | |
| Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" | 205 | Exploded View | 210 | F |
| Precaution for Battery Service | 205 | Removal and Installation | 210 | |
| Service | 205 | SIDE SUPPORT SWITCH | 211 | G |
| Work | 205 | Exploded View | 211 | |
| | | Removal and Installation | 211 | H |
| | | TILT&TELESCOPIC SWITCH | 212 | |
| | | Exploded View | 212 | I |
| | | Removal and Installation | 212 | |

ADP

K
L
M
N
O
P

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000008163541

OVERALL SEQUENCE



JMJIA2428GB

DETAILED FLOW

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

1.GET INFORMATION FOR SYMPTOM

Get the detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred).

>> GO TO 2.

2.CHECK DTC WITH AUTOMATIC DRIVE POSITIONER SYSTEM

Check "Self Diagnostic Result" with CONSULT. Refer to [ADP-181, "DTC Index"](#)

Is any symptom described and any DTC is displayed?

Symptom is described, DTC is displayed.>>GO TO 3.

Symptom is not described, DTC is displayed.>>GO TO 6.

Symptom is described, DTC is not displayed.>>GO TO 4.

3.CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

>> GO TO 6.

4.CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

>> GO TO 5.

5.CHECK NORMAL OPERATING CONDITION

Check normal operating condition. Refer to [ADP-204, "Description"](#).

Is the incident normal operation?

YES >> INSPECTION END

NO >> GO TO 7.

6.PERFORM DTC CONFIRMATION PROCEDURE

Perform the confirmation procedure for the detected DTC.

Is the DTC displayed?

YES >> GO TO 8.

NO >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

7.DETECT MALFUNCTIONING SYSTEM BY SYMPTOM DIAGNOSIS

Detect malfunctioning system according to SYMPTOM DIAGNOSIS based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

>> GO TO 8.

8.PERFORM COMPONENT FUNCTION CHECK

Perform the component function check for the isolated malfunctioning point.

>> GO TO 9.

9.DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

Isolate the malfunctioning point by performing the diagnosis procedure relevant to the symptom during the component diagnosis.

>> GO TO 10.

10.REPARE OR REPLACE

Repair or replace the malfunctioning part.

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

>> GO TO 11.

11.FINAL CHECK

Perform the DTC confirmation procedure (if DTC is detected) or component function check (if no DTC is detected) again, and then check that the malfunction can be repaired securely.

Are all malfunctions corrected?

YES >> INSPECTION END

Symptom is detected.>> GO TO 5.

DTC is detected.>> GO TO 6.

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

INSPECTION AND ADJUSTMENT

ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL

ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Description

INFOID:000000008163542

Each function is reset to the following condition when the battery terminal is disconnected.

| Function | Condition | Procedure |
|---------------------------------|-----------|------------------------|
| Memory (Seat, steering, mirror) | Erased | Perform memory storing |
| Intelligent Key interlock | Erased | Perform memory storing |
| Seat synchronization | OFF | — |

NOTE:

When disconnecting the battery terminal or replacing the driver seat control unit, DTC, registered items of memory storing, and details of system setting detected in the past are erased. Perform operation after checking the contents.

ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement

INFOID:000000008163543

1.SYSTEM INITIALIZATION

Perform system initialization. Refer to [ADP-10, "SYSTEM INITIALIZATION : Description"](#).

>> GO TO 2.

2.SYSTEM SETTING

Perform system setting. Refer to [ADP-11, "SYSTEM SETTING : Description"](#).

>> GO TO 3.

3.MEMORY STORING

Perform memory storing. Refer to [ADP-10, "MEMORY STORING : Description"](#).

>> END

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description

INFOID:000000008163544

Each function is reset to the following condition when the driver seat control unit is replaced.

| Function | Condition | Procedure |
|---------------------------------|-----------|------------------------|
| Memory (Seat, steering, mirror) | Erased | Perform memory storing |
| Intelligent Key interlock | Erased | Perform memory storing |
| Seat synchronization | OFF | — |

NOTE:

When disconnecting the battery terminal or replacing the driver seat control unit, DTC, registered items of memory storing, and details of system setting detected in the past are erased. Perform operation after checking the contents.

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement

INFOID:000000008163545

1.SYSTEM INITIALIZATION

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

Perform system initialization. Refer to [ADP-10, "SYSTEM INITIALIZATION : Description"](#).

>> GO TO 2.

2.SYSTEM SETTING

Perform system setting. Refer to [ADP-11, "SYSTEM SETTING : Description"](#).

>> GO TO 3.

3.MEMORY STORING

Perform memory storing. Refer to [ADP-10, "MEMORY STORING : Description"](#).

>> END

SYSTEM INITIALIZATION

SYSTEM INITIALIZATION : Description

INFOID:000000008163546

When disconnecting battery negative terminal or replacing control unit, always perform the system initialization. Otherwise, the backward operation for power walk-in function does not activate normally.

SYSTEM INITIALIZATION : Special Repair Requirement

INFOID:000000008163547

INITIALIZATION PROCEDURE

1. STEP-1

Slide the seat to the front edge.

NOTE:

- STEP-1 is the initialization procedure for power walk-in function.
- If the seat sliding position is already at the front edge, slide the seat rearward once, and then slide it to the front edge again.

>> END

MEMORY STORING

MEMORY STORING : Description

INFOID:000000008163548

Always perform the memory storage when the battery terminal is disconnected or the driver seat control unit is replaced. The memory function and Intelligent Key interlock function will not operate normally if no memory storage is performed.

MEMORY STORING : Special Repair Requirement

INFOID:000000008163549

Memory Storage Procedure

Two positions for the driver seat, steering column and outside mirror can be stored for memory operation by following procedure.

1.STEP 1

Shift AT selector lever to P position (AT model) or applied parking brake (MT model).

>> GO TO 2.

2.STEP 2

Turn ignition switch ON.

>> GO TO 3.

3.STEP 3

Adjust driver seat, steering column and outside mirror position manually.

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

>> GO TO 4.

4.STEP 4

1. Push set switch.

NOTE:

- Memory indicator for which driver seat position is already retained in memory is illuminated for 5 seconds.
- Memory indicator for which driver seat position is not retained in memory is illuminated for 0.5 second.

2. Push the memory switch (1 or 2) for at least 1 second within 5 seconds after pushing the set switch.

NOTE:

If memory is stored in the same memory switch, the previous memory will be deleted.

Do you need linking of Intelligent Key?

YES >> GO TO 6.

NO >> GO TO 5.

5.STEP 5

Confirm the operation of each part with memory operation.

>> END

6.STEP 6

Turn ignition switch OFF (LOCK).

>> GO TO 7.

7.STEP 7

- Press and release set switch. Memory switch indicator is illuminated for 5 seconds. During memory switch indicator is illuminated, press Intelligent Key unlock button while pressing memory switch 1 or 2.

NOTE:

Memory switch indicator lamp blinks for 5 seconds when registration is complete.

>> GO TO 8.

8.STEP 8

Confirm the operation of each part with memory operation and Intelligent Key interlock operation.

>> END

SYSTEM SETTING

SYSTEM SETTING : Description

INFOID:000000008163550

The setting of the automatic driving positioner system can be changed using the set switch.

SYSTEM SETTING : Special Repair Requirement

INFOID:000000008163551

SETTING PROCEDURE

1.STEP-1

Set the vehicle to the following condition.

- Ignition position: ACC
- A/T selector lever: P position (A/T models)
- Parking brake: Applied only (M/T models)

>> GO TO 2.

2.STEP-2

Press set switch and hold for more than 10 seconds, then confirm blinking of the memory switch indicator.

A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O

P

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

- Seat synchronization are ON : Memory switch indicator blink two times.
- Seat synchronization are OFF : Memory switch indicator blink once.

NOTE:

- After memory setting registration, by pushing set switch for approximately 10 seconds, memory switch indicator lamp turns 4 seconds. turns OFF, blinks 1 or 2 times, and then the switching operation is complete. Push and hold set switch during the switching operation.

>> END.

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >


SYSTEM DESCRIPTION

AUTOMATIC DRIVE POSITIONER SYSTEM

AUTOMATIC DRIVE POSITIONER SYSTEM

AUTOMATIC DRIVE POSITIONER SYSTEM : System Diagram

INFOID:000000008163552



A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O

P

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

AUTOMATIC DRIVE POSITIONER SYSTEM : System Description

INFOID:000000008163553

OUTLINE

The system automatically moves the driver seat, steering column and door mirror position by the driver seat control unit and the automatic drive positioner control unit. The driver seat control unit corresponds with the automatic drive positioner control unit by UART communication.

| Function | Description |
|------------------------------------|--|
| Manual function | The driving position (seat, steering column and door mirror position) can be adjusted by using the power seat switch, tilt & telescopic switch or door mirror remote control switch. |
| Seat synchronization function | The positions of the steering column and door mirror are adjusted to the proper position automatically while linking with manual operation [seat sliding, seat lifting (rear) or seat reclining]. |
| Memory function | The seat, steering column and outside mirror move to the stored driving position by pressing seat memory switch (1 or 2). |
| Power walk-in function | The seat is made to advance when the seat back of driver seat is folded down and press the walk-in switch. The seat is made to retreat to former position when the seat back of driver seat is folded up and press the walk-in switch. |
| Intelligent Key interlock function | Perform memory operation, exiting operation and entry operation by Intelligent Key unlock operation or driver side door request switch unlock operation. |


NOTE:

The lumbar support system and the side support system are controlled independently with no link to the automatic drive positioner system.

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

AUTOMATIC DRIVE POSITIONER SYSTEM : Component Parts Location INFOID:000000008163554




- | | | |
|--|--|--|
| 1. BCM M118, M119, M122, M123 | 2. Automatic drive positioner control unit M51, M52 | 3. Driver seat control unit B503, B504 |
| 4. Unified meter and A/C amp. M67 | 5. A/T assembly F51 | 6. Tilt & telescopic switch M31 |
| 7. Key slot M22 | 8. Tilt sensor M48 | 9. Telescopic sensor M48 |
| 10. Seat memory switch D5 | 11. Door mirror remote control switch D17 | |
| A. Dash side lower (passenger side) | B. View with instrument driver lower panel removed (Remove 4WAS front control unit with 4WAS models) | C. Backside of seat cushion (driver side) |
| D. Behind cluster lid C | E. A/T assembly (TCM is built in A/T assembly) | F. View with instrument driver lower panel removed |
| G. View with steering column cover lower and upper removed | | |

JMJIA2415ZZ

A
B
C
D
E
F
G
H
I
ADP
K
L
M
N
O
P

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >




JMJIA2416ZZ

- | | | |
|---|--|-------------------------------|
| 12. Driver side door switch B16 | 13. A/T shift selector (detention switch) M137 | 14. Parking brake switch B14 |
| 15. Door mirror (driver side) D3 | 16. Telescopic motor M49 | 17. Tilt motor M49 |
| 18. Forward switch B512 | 19. Sliding limit switch B514 | 20. Power walk-in switch B513 |
| 21. Seat belt buckle switch (driver side) B13 | | |

- | | | |
|--|--|--|
| H. View with center console assembly is removed. | I. View with center console assembly is removed. | J. View with instrument driver lower panel is removed. |
| K. View with seat back pad is removed. | L. View with seat cushion pad is removed. | |

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >



- | | | |
|-------------------------------|---|--|
| 22. Reclining motor B523 | 23. Reclining switch (Power seat switch) B510 | 24. Sliding, lifting switch (Power seat switch) B510 |
| 25. Sliding sensor B526 | 26. Lifting motor (front) B527 | 27. Sliding motor B525 |
| 28. Lifting motor (rear) B529 | | |
- M. View with seat cushion pad and seat-
back pad are removed.
- N. Backside of seat cushion

AUTOMATIC DRIVE POSITIONER SYSTEM : Component Description

INFOID:000000008163555

CONTROL UNITS

| Item | Function |
|---|---|
| Driver seat control unit | <ul style="list-style-type: none"> Main units of automatic drive positioner system. It is connected to the CAN. It communicates with the automatic drive positioner control unit via UART communication. |
| Automatic drive positioner control unit | <ul style="list-style-type: none"> It communicates with the driver seat control unit via UART communication. Perform various controls with the instructions of driver seat control unit. Perform the controls of the tilt & telescopic, door mirror and the seat memory switch. |
| BCM | Transmit the following status to the driver seat control unit via CAN communication. <ul style="list-style-type: none"> Driver door: OPEN/CLOSE Ignition switch position: ACC/ON Door lock: UNLOCK (with Intelligent Key or driver side door request switch operation) Key ID Key switch: Insert/Pull out Intelligent Key Starter: CRANKING/OTHER |
| Unified meter and A/C amp. | Transmit the vehicle speed signal to the driver seat control unit via CAN communication. |
| TCM | Transmit the shift position signal (P range) to the driver seat control unit via CAN communication. |

INPUT PARTS

Switches

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

| Item | Function |
|---------------------------------------|---|
| Key slot | The key switch is installed to detect the key inserted/removed status. |
| Driver side door switch | Detect front door (driver side) open/close status. |
| A/T shift selector (detention switch) | Detect the P range position of A/T selector lever. (A/T models) |
| Parking break switch | Detect the parking brake status. (M/T models) |
| Set switch | The registration and system setting can be performed with its operation. |
| Memory switch 1/2 | The registration and operation can be performed with its operation. |
| Power seat switch | The following switch is installed. <ul style="list-style-type: none"> • Reclining switch • Lifting switch (front) • Lifting switch (rear) • Sliding switch The specific parts can be operated with the operation of each switch. |
| Power walk-in switch | Perform the power walk-in operation by operating the power walk-in switch. |
| Sliding limit switch | Detect the front end position of seat sliding during the power walk-in function forward operation. |
| Seat belt buckle switch | Detect the seat belt fastening/releasing condition. |
| Forward switch | Detect the folded up/folded down condition of seatback that is the operation condition of power walk-in function. |
| Tilt & telescopic switch | The following switch is installed. <ul style="list-style-type: none"> • Tilt switch • Telescopic switch The specific parts can be operated with the operation of each switch. |
| Door mirror remote control switch | The following switch is installed. <ul style="list-style-type: none"> • Mirror switch • Changeover switch The specific parts can be operated with the operation of each switch. |

Sensors

| Item | Function |
|---|--|
| Door mirror sensor (driver side/passenger side) | Detect the upward/downward and leftward/rightward position of outside mirror face. |
| Tilt & telescopic sensor | Detect the upward/downward and forward/backward position of steering column. |
| Lifting sensor (front) | Detect the upward/downward position of seat lifting (front). |
| Lifting sensor (rear) | Detect the upward/downward position of seat lifting (rear). |
| Reclining sensor | Detect the tilt of seatback. |
| Sliding sensor | Detect the forward/backward position of seat. |

OUTPUT PARTS

| Item | Function |
|--|---|
| Door mirror motor (driver side/passenger side) | Move the outside mirror face upward/downward and leftward/rightward. |
| Tilt & telescopic motor | Move the steering column upward/downward and frontward/rearward. |
| Lifting motor (front) | Move the seat lifting (front) upward/downward. |
| Lifting motor (rear) | Move the seat lifting (rear) upward/downward. |
| Reclining motor | Tilt and raise up the seatback. |
| Sliding motor | Slide the seat forward/backward. |
| Memory indicator | Illuminates or blinks according to the registration/operation status. |

SLEEP MODE

- The seat control unit adopts the sleep mode to reduce the electric power consumption.

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >


- The sleep mode is activated when all of the following condition are fulfilled.
 - Ignition switch turn OFF (steering LOCK position)
 - No load is applied to the seat control
 - The seat control unit 45seconds timer in not activated
 - Set switch and memory switch (1 and 2) turn OFF

WAKE-UP MODE

- The sleep mode is cancelled when any status change is detected for the followings.
 - CAN communication
 - Power seat switch
 - Set switch and memory switch (1 and 2)
 - Power walk-in switch
 - Door mirror switch
 - Steering column switch

MANUAL FUNCTION

MANUAL FUNCTION : System Diagram



MANUAL FUNCTION : System Description

INFOID:000000008163557

OUTLINE

The driving position (seat, steering column and door mirror position) can be adjusted manually with power seat switch, tilt & telescopic switch and door mirror remote control switch.

OPERATION PROCEDURE

- Turn ignition switch ON.
- Operate power seat switch, tilt & telescopic switch or door mirror remote control switch.
- The driver seat, steering column or door mirror operates according to the operation of each switch.

DETAIL FLOW

Seat

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

| Order | Input | Output | Control unit condition |
|-------|---|--------------------------------------|--|
| 1 | Power seat switch (sliding, lifting, reclining) | — | The power seat switch signal is inputted to the driver seat control unit when the power seat switch is operated. |
| 2 | — | Motors (sliding, lifting, reclining) | The driver seat control unit outputs signals to each motor according to the power seat switch input signal. |

Tilt & Telescopic

| Order | Input | Output | Control unit condition |
|-------|----------------------------|---------------------------|--|
| 1 | Tilt & telescopic switch | — | The tilt & telescopic switch signals are inputted to the automatic drive positioner control unit when the tilt & telescopic switch are operated. |
| 2 | — | Motors (Tilt, telescopic) | The automatic drive positioner control unit actuates each motor according to the operation of the tilt & telescopic switch. |
| 3 | Sensors (Tilt, telescopic) | — | The automatic drive positioner control unit recognizes any operation limit of each actuator via each sensor and will not operate the actuator anymore at that time.* |

*: Tilt does not operate upward when tilt sensor value is less than 1.1 V, tilt does not operate downward when the sensor value is more than 3.9 V. Telescopic does not operate backward when telescopic sensor value is less than 0.5 V, telescopic does not operate forward when the sensor value is more than 4.5 V.

Door Mirror

| Order | Input | Output | Control unit condition |
|-------|-----------------------------------|----------------------------|---|
| 1 | Door mirror remote control switch | — | The door mirror remote control switch signal is inputted to the automatic drive positioner control unit when the door mirror remote control switch is operated. |
| 2 | — | Motors (Door mirror motor) | The automatic drive positioner control unit actuates each motor according to the signal from the door mirror remote control switch. |
| 3 | Sensors (Mirror) | — | The automatic drive positioner control unit monitors the input of mirror sensor. It stops the operation if the input reaches the operation limit. |

NOTE:


The door mirrors can be operated manually when ignition switch is in either ACC or ON position. The ignition switch signal (ACC/ON) is transmitted from BCM to the driver seat control unit via CAN communication and from the driver seat control unit to the automatic drive positioner control unit via UART communication.

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

MANUAL FUNCTION : Component Parts Location


INFOID:000000008163558



- | | | |
|--|--|--|
| 1. BCM M118, M119, M122, M123 | 2. Automatic drive positioner control unit M51, M52 | 3. Driver seat control unit B503, B504 |
| 4. Unified meter and A/C amp. M67 | 5. A/T assembly F51 | 6. Tilt & telescopic switch M31 |
| 7. Key slot M22 | 8. Tilt sensor M48 | 9. Telescopic sensor M48 |
| 10. Seat memory switch D5 | 11. Door mirror remote control switch D17 | |
| A. Dash side lower (passenger side) | B. View with instrument driver lower panel removed (Remove 4WAS front control unit with 4WAS models) | C. Backside of seat cushion (driver side) |
| D. Behind cluster lid C | E. A/T assembly (TCM is built in A/T assembly) | F. View with instrument driver lower panel removed |
| G. View with steering column cover lower and upper removed | | |

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >




JMJIA2416ZZ

- | | | |
|---|--|-------------------------------|
| 12. Driver side door switch B16 | 13. A/T shift selector (detention switch) M137 | 14. Parking brake switch B14 |
| 15. Door mirror (driver side) D3 | 16. Telescopic motor M49 | 17. Tilt motor M49 |
| 18. Forward switch B512 | 19. Sliding limit switch B514 | 20. Power walk-in switch B513 |
| 21. Seat belt buckle switch (driver side) B13 | | |

- | | | |
|--|--|--|
| H. View with center console assembly is removed. | I. View with center console assembly is removed. | J. View with instrument driver lower panel is removed. |
| K. View with seat back pad is removed. | L. View with seat cushion pad is removed. | |

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >



- | | | |
|-------------------------------|---|--|
| 22. Reclining motor B523 | 23. Reclining switch (Power seat switch) B510 | 24. Sliding, lifting switch (Power seat switch) B510 |
| 25. Sliding sensor B526 | 26. Lifting motor (front) B527 | 27. Sliding motor B525 |
| 28. Lifting motor (rear) B529 | | |
- M. View with seat cushion pad and seat-back pad are removed. N. Backside of seat cushion

MANUAL FUNCTION : Component Description

INFOID:000000008163559

CONTROL UNITS

| Item | Function |
|---|--|
| Driver seat control unit | <ul style="list-style-type: none"> Operates the specific seat motor with the signal from the power seat switch. Transmits the ignition switch signal (ACC/ON) via UART communication to the automatic drive positioner control unit. |
| Automatic drive positioner control unit | Operates the specific motor with the signal from tilt & telescopic switch or door mirror remote control switch. |
| BCM | Recognizes the following status and transmits it to the driver seat control unit via CAN communication. <ul style="list-style-type: none"> Ignition position: ACC/ON |

INPUT PARTS

Switches

| Item | Function |
|--------------------------|--|
| Power seat switch | The following switch is installed. <ul style="list-style-type: none"> Reclining switch Lifting switch (front) Lifting switch (rear) Sliding switch The specific parts can be operated with the operation of each switch. |
| Tilt & telescopic switch | The following switch is installed. <ul style="list-style-type: none"> Tilt switch Telescopic switch The specific parts can be operated with the operation of each switch. |

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

| Item | Function |
|-----------------------------------|--|
| Forward switch | Detect folded down or folded up of the seat back. |
| Door mirror remote control switch | The following switch is installed. <ul style="list-style-type: none"> • Mirror switch • Changeover switch The specific parts can be operated with the operation of each switch. |

Sensors

| Item | Function |
|--|--|
| Tilt & telescopic sensor | Detect the upward/downward & forward/backward position of steering column. |
| Door mirror sensor (driver side / passenger side) | Detect the upward/downward and leftward/rightward position of outside mirror face. |


OUTPUT PARTS

| Item | Function |
|---|--|
| Door mirror motor (driver side/passenger side) | Move the outside mirror face upward/downward and leftward/rightward. |
| Tilt & telescopic motor | Move the steering column upward/downward and forward/backward. |
| Lifting motor (front) | Move the seat lifter (front) upward/downward. |
| Lifting motor (rear) | Move the seat lifter (rear) upward/downward. |
| Reclining motor | Tilt and raise up the seatback. |
| Sliding motor | Slide the seat forward/backward. |

SEAT SYNCHRONIZATION FUNCTION

SEAT SYNCHRONIZATION FUNCTION : System Diagram

INFOID:000000008163560



SEAT SYNCHRONIZATION FUNCTION : System Description

INFOID:000000008163561

OUTLINE

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

The steering column position and door mirror position is adjusted to the position automatically according to the direction and distance of seat movement when performing the manual operation of sliding, reclining or lifting (rear). This function saves adjusting the mirror and steering column when adjusting the seat.

NOTE:

This function is set to OFF before delivery. (initial setting)

For the system setting procedure. Refer to [ADP-11. "SYSTEM SETTING : Description"](#).

OPERATION PROCEDURE

1. Turn ignition switch ON.
2. Adjust seat position [sliding, reclining, lifting (rear)].
3. The steering and outside mirror is adjusted automatically.

NOTE:

- The seat synchronization function will not operate if seat adjusting value is more than limit value.

| Item | Limit value |
|--------------------|-------------|
| Seat sliding | 76 mm |
| Seat reclining | 9.1 degrees |
| Seat lifter (rear) | 20 mm |

- The seat synchronization function will not operate if the steering column or door mirror moves to the operating end while this function is operating. Perform memory function or drive the vehicle at vehicle speed of 7 km/h or more once to activate this function again.
- If the seat position is uncomfortable after the adjustment, seat position can be adjusted easily by memory operation.

OPERATION CONDITION

Satisfy all of the following items. The seat synchronization function is not performed if these items are not satisfied.

| Item | Request status |
|---|-----------------------|
| System setting | ON |
| Ignition position | ON |
| Seat back | Folded up |
| A/T selector lever (A/T models) | P position |
| Parking break (M/T models) | Applied |
| Switch inputs <ul style="list-style-type: none"> • Power seat switch • Tilt & telescopic switch • Door mirror remote control switch • Set switch • Memory switch | OFF (Not operated) |

DETAIL FLOW

When performing the sliding, reclining or lifting (rear) operation in manual function, the driver seat control unit performs the seat synchronization function as follows.


| Order | Input | Output | Control unit condition |
|-------|---|--|--|
| 1 | Sensors [Sliding, reclining, lifting (rear)] | — | The driver seat control unit judges the direction and distance of seat movement according to the signal input from each seat sensor during manual operation. |
| 2 | — | Motors (Tilt, telescopic, outside mirror) | Driver seat control unit requests the operation to position according to the direction and distance of seat movement to the automatic drive positioner control unit via UART communication. The automatic drive positioner control unit operates each motor. |
| | Sensors (Tilt, telescopic, outside mirror) | — | Driver seat control unit stops the operation of each motor when the value of each sensor that is input to automatic drive positioner control unit via UART communication reaches the target address. |

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

SEAT SYNCHRONIZATION FUNCTION : Component Parts Location

INFOID:000000008163562




JMJIA2415ZZ

- | | | |
|--|--|--|
| 1. BCM M118, M119, M122, M123 | 2. Automatic drive positioner control unit M51, M52 | 3. Driver seat control unit B503, B504 |
| 4. Unified meter and A/C amp. M67 | 5. A/T assembly F51 | 6. Tilt & telescopic switch M31 |
| 7. Key slot M22 | 8. Tilt sensor M48 | 9. Telescopic sensor M48 |
| 10. Seat memory switch D5 | 11. Door mirror remote control switch D17 | |
| A. Dash side lower (passenger side) | B. View with instrument driver lower panel removed (Remove 4WAS front control unit with 4WAS models) | C. Backside of seat cushion (driver side) |
| D. Behind cluster lid C | E. A/T assembly (TCM is built in A/T assembly) | F. View with instrument driver lower panel removed |
| G. View with steering column cover lower and upper removed | | |

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >




- | | | |
|--|--|--|
| 12. Driver side door switch B16 | 13. A/T shift selector (detention switch) M137 | 14. Parking brake switch B14 |
| 15. Door mirror (driver side) D3 | 16. Telescopic motor M49 | 17. Tilt motor M49 |
| 18. Forward switch B512 | 19. Sliding limit switch B514 | 20. Power walk-in switch B513 |
| 21. Seat belt buckle switch (driver side) B13 | | |
| H. View with center console assembly is removed. | I. View with center console assembly is removed. | J. View with instrument driver lower panel is removed. |
| K. View with seat back pad is removed. | L. View with seat cushion pad is removed. | |

JMJIA2416ZZ

A
B
C
D
E
F
G
H
I
ADP
K
L
M
N
O
P

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >



- | | | |
|-------------------------------|---|--|
| 22. Reclining motor B523 | 23. Reclining switch (Power seat switch) B510 | 24. Sliding, lifting switch (Power seat switch) B510 |
| 25. Sliding sensor B526 | 26. Lifting motor (front) B527 | 27. Sliding motor B525 |
| 28. Lifting motor (rear) B529 | | |
- M. View with seat cushion pad and seat-back pad are removed. N. Backside of seat cushion

SEAT SYNCHRONIZATION FUNCTION : Component Description

INFOID:000000008163563

CONTROL UNITS

| Item | Function |
|---|--|
| Driver seat control unit | Operates the specific seat motor with the signal from the power seat switch. |
| Automatic drive positioner control unit | Operates the steering motor and door mirror with the signal from the driver seat control unit. |

INPUT PARTS

Switches

| Item | Function |
|-------------------|--|
| Power seat switch | The following switch is installed. <ul style="list-style-type: none"> • Reclining switch • Lifting switch (front) • Lifting switch (rear) • Sliding switch The specific parts can be operated with the operation of each switch. |
| Forward switch | Detect folded down or folded up of the seat back. |

Sensors

| Item | Function |
|--|--|
| Door mirror sensor (driver side/passenger side) | Detect the upward/downward and leftward/rightward position of outside mirror face. |
| Tilt & telescopic sensor | Detect the upward/downward and forward/backward position of steering column. |
| Lifting sensor (rear) | Detect the upward/downward position of seat lifter (rear). |

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

| Item | Function |
|------------------|---|
| Reclining sensor | Detect the tilt of seatback. |
| Sliding sensor | Detect the forward/rearward position of seat. |


OUTPUT PARTS

| Item | Function |
|---|--|
| Door mirror motor (driver side/passenger side) | Move the outside mirror face upward/downward and leftward/rightward. |
| Tilt & telescopic motor | Move the steering column upward/downward and forward/backward. |
| Lifting motor (rear) | Move the seat lifter (rear) upward/downward. |
| Reclining motor | Tilt and raise up the seatback. |
| Sliding motor | Slide the seat forward/backward. |

MEMORY FUNCTION

MEMORY FUNCTION : System Diagram

INFOID:000000008163564



MEMORY FUNCTION : System Description

INFOID:000000008163565

OUTLINE

The driver seat control unit can store the optimum driving positions (seat, steering column and door mirror position) for 2 people. If the front seat position is changed, one-touch (pressing desired memory switch for more than 0.5 second) operation allows changing to the other driving position.

NOTE:

Further information for the memory storing procedure. Refer to [ADP-10. "MEMORY STORING : Description"](#).

OPERATION PROCEDURE

1. Turn ignition switch ON
2. Press desired memory switch for more than 0.5 second.
3. Driver seat, steering and door mirror will move to the memorized position.

OPERATION CONDITION

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

Satisfy all of the following items. The memory function is not performed if these items are not satisfied.

| Item | Request status |
|--|-----------------------|
| Ignition position | ON |
| Seat back | Folded up |
| A/T selector lever (A/T models) | P position |
| Parking break (M/T models) | Applied |
| Switch inputs <ul style="list-style-type: none"> • Power seat switch • Tilt & telescopic switch • Door mirror control switch • Set switch • Memory switch | OFF (Not operated) |

DETAIL FLOW


| Order | Input | Output | Control unit condition |
|-------|---|--|--|
| 1 | Memory switch | — | The memory switch signal is inputted to the automatic drive positioner control unit when memory switch 1 or 2 is operated. Memory switch signal is output to driver seat control unit via UART communication. |
| 2 | — | Motors (Seat, steering, door mirror) | Driver seat control unit operates each motor of seat when it recognizes the memory switch pressed for 0.5 second or more and requests each motor operation to automatic drive positioner control unit via UART communication. The automatic drive positioner control unit operates each motor. |
| | | Memory switch Indica- tor | Driver seat control unit requests the flashing of memory indicator to automatic drive positioner control unit via UART communication while either of the motors is operating. The automatic drive positioner control unit illuminates the memory indicator. |
| 3 | Sensors (Seat, steering, door mirror) | — | Driver seat control unit judges the operating seat position with each seat sensor input. The positions of the steering column and outside mirror are monitored with each sensor signal that is input from auto drive positioner control unit via UART communication. Driver seat control unit stops the operation of each motor when each part reaches the recorded address. |
| 4 | — | Memory switch Indica- tor | Driver seat control unit requests the illumination of memory indicator to auto drive positioner control unit via UART communication after all motors stop. The auto driving positioner control unit illuminates the memory indicator for 5 seconds. |

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

MEMORY FUNCTION : Component Parts Location

INFOID:000000008163566




- | | | |
|--|--|--|
| 1. BCM M118, M119, M122, M123 | 2. Automatic drive positioner control unit M51, M52 | 3. Driver seat control unit B503, B504 |
| 4. Unified meter and A/C amp. M67 | 5. A/T assembly F51 | 6. Tilt & telescopic switch M31 |
| 7. Key slot M22 | 8. Tilt sensor M48 | 9. Telescopic sensor M48 |
| 10. Seat memory switch D5 | 11. Door mirror remote control switch D17 | |
| A. Dash side lower (passenger side) | B. View with instrument driver lower panel removed (Remove 4WAS front control unit with 4WAS models) | C. Backside of seat cushion (driver side) |
| D. Behind cluster lid C | E. A/T assembly (TCM is built in A/T assembly) | F. View with instrument driver lower panel removed |
| G. View with steering column cover lower and upper removed | | |

A
B
C
D
E
F
G
H
I
ADP
K
L
M
N
O
P

JMJIA2415ZZ

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >




JMJIA2416ZZ

- | | | |
|--|--|--|
| 12. Driver side door switch B16 | 13. A/T shift selector (detention switch) M137 | 14. Parking brake switch B14 |
| 15. Door mirror (driver side) D3 | 16. Telescopic motor M49 | 17. Tilt motor M49 |
| 18. Forward switch B512 | 19. Sliding limit switch B514 | 20. Power walk-in switch B513 |
| 21. Seat belt buckle switch (driver side) B13 | | |
| H. View with center console assembly is removed. | I. View with center console assembly is removed. | J. View with instrument driver lower panel is removed. |
| K. View with seat back pad is removed. | L. View with seat cushion pad is removed. | |

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >



- | | | |
|-------------------------------|---|--|
| 22. Reclining motor B523 | 23. Reclining switch (Power seat switch) B510 | 24. Sliding, lifting switch (Power seat switch) B510 |
| 25. Sliding sensor B526 | 26. Lifting motor (front) B527 | 27. Sliding motor B525 |
| 28. Lifting motor (rear) B529 | | |
- M. View with seat cushion pad and seat-
back pad are removed.
- N. Backside of seat cushion

MEMORY FUNCTION : Component Description

INFOID:000000008163567

CONTROL UNITS

| Item | Function |
|---|---|
| Driver seat control unit | <ul style="list-style-type: none"> The address of each part is recorded. Operates each motor of seat to the registered position. Requests the operations of steering column and door mirror to automatic drive positioner control unit |
| Automatic drive positioner control unit | Operates the steering column and door mirror with the signal from the driver seat control. |

INPUT PARTS

Switches

| Item | Function |
|-------------------|---|
| Memory switch 1/2 | The registration and memory function can be performed with its operation. |
| Forward switch | Detect folded down or folded up of the seat back. |

Sensors

| Item | Function |
|--|--|
| Door mirror sensor (driver side/passenger side) | Detect the upward/downward and leftward/rightward position of outside mirror face. |
| Tilt & telescopic sensor | Detect the upward/downward and forward/backward position of steering column. |
| Lifting sensor (front) | Detect the upward/downward position of seat lifting (front). |
| Lifting sensor (rear) | Detect the upward/downward position of seat lifting (rear). |

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

| Item | Function |
|------------------|---|
| Reclining sensor | Detect the tilt of seatback. |
| Sliding sensor | Detect the forward/backward position of seat. |


OUTPUT PARTS

| Item | Function |
|--|---|
| Door mirror motor (driver side/passenger side) | Move the outside mirror face upward/downward and leftward/rightward. |
| Tilt & telescopic motor | Move the steering column upward/downward and forward/backward. |
| Lifting motor (front) | Move the seat lifter (front) upward/downward. |
| Lifting motor (rear) | Move the seat lifter (rear) upward/downward. |
| Reclining motor | Tilt and raise up the seatback. |
| Sliding motor | Slide the seat forward/backward. |
| Memory indicator | Illuminates or blinks according to the registration/operation status. |

INTELLIGENT KEY INTERLOCK FUNCTION

INTELLIGENT KEY INTERLOCK FUNCTION : System Diagram

INFOID:000000008163568



INTELLIGENT KEY INTERLOCK FUNCTION : System Description

INFOID:000000008163569

OUTLINE

When unlocking doors by using Intelligent Key or driver side door request switch, the system performs memory operation.

OPERATION PROCEDURE

1. Unlock doors by using Intelligent Key or driver side door request switch.
2. The system performs memory operation, and then performs exit assist operation.

NOTE:

If the seat position is in memorized position before unlocking doors, memory operation does not perform.

NOTE:

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

Further information for Intelligent Key interlock function. Refer to [ADP-10, "MEMORY STORING : Description"](#).

OPERATION CONDITION

Satisfy all of the following items. The Intelligent Key interlock function is performed if these items are satisfied.

| Item | Request status |
|--|-----------------------|
| Key switch | OFF (Key is removed.) |
| Ignition position | LOCK |
| Seat back | Folded up |
| A/T selector lever (A/T models) | P position |
| Parking break (M/T models) | Applied |
| Switch inputs <ul style="list-style-type: none"> • Power seat switch • Tilt & telescopic switch • Door mirror control switch • Set switch • Memory switch | OFF (Not operated) |

DETAIL FLOW

| Order | Input | Output | Control unit condition |
|-------|---|--------|--|
| 1 | <ul style="list-style-type: none"> • Door unlock signal (CAN) • Key ID signal (CAN) | — | Driver seat control unit receives the door unlock signal and the key ID signal from BCM when unlocking the door with Intelligent Key or driver side door request switch. |
| 2 | — | — | Driver seat control unit performs the memory function. |


A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

INTELLIGENT KEY INTERLOCK FUNCTION : Component Parts Location INFOID:000000008163570




JMJIA2415ZZ

- | | | |
|--|--|--|
| 1. BCM M118, M119, M122, M123 | 2. Automatic drive positioner control unit M51, M52 | 3. Driver seat control unit B503, B504 |
| 4. Unified meter and A/C amp. M67 | 5. A/T assembly F51 | 6. Tilt & telescopic switch M31 |
| 7. Key slot M22 | 8. Tilt sensor M48 | 9. Telescopic sensor M48 |
| 10. Seat memory switch D5 | 11. Door mirror remote control switch D17 | |
| A. Dash side lower (passenger side) | B. View with instrument driver lower panel removed (Remove 4WAS front control unit with 4WAS models) | C. Backside of seat cushion (driver side) |
| D. Behind cluster lid C | E. A/T assembly (TCM is built in A/T assembly) | F. View with instrument driver lower panel removed |
| G. View with steering column cover lower and upper removed | | |

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >



12. Driver side door switch B16

13. A/T shift selector (detention switch) M137

14. Parking brake switch B14

15. Door mirror (driver side) D3

16. Telescopic motor M49

17. Tilt motor M49

18. Forward switch B512

19. Sliding limit switch B514

20. Power walk-in switch B513

21. Seat belt buckle switch (driver side) B13

H. View with center console assembly is removed.

I. View with center console assembly is removed.

J. View with instrument driver lower panel is removed.

K. View with seat back pad is removed.


L. View with seat cushion pad is removed.

JMJIA2416ZZ

A
B
C
D
E
F
G
H
I
ADP
K
L
M
N
O
P

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >



- | | | |
|-------------------------------|---|--|
| 22. Reclining motor B523 | 23. Reclining switch (Power seat switch) B510 | 24. Sliding, lifting switch (Power seat switch) B510 |
| 25. Sliding sensor B526 | 26. Lifting motor (front) B527 | 27. Sliding motor B525 |
| 28. Lifting motor (rear) B529 | | |
- M. View with seat cushion pad and seat-
back pad are removed.
- N. Backside of seat cushion

INTELLIGENT KEY INTERLOCK FUNCTION : Component Description

INFOID:000000008163571

CONTROL UNITS

| Item | Function |
|---|---|
| Driver seat control unit | It performs memory function after receiving the door unlock signal from BCM. |
| Automatic drive positioner control unit | Operates the steering column and door mirror with the instructions from the driver seat control unit. |
| BCM | Recognizes the following status and transmits it to the driver seat control unit via CAN communication. <ul style="list-style-type: none"> • Door lock: UNLOCK (with Intelligent Key or driver side door request switch) |


POWER WALK-IN FUNCTION

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

POWER WALK-IN FUNCTION : System Diagram

INFOID:000000008163572



POWER WALK-IN FUNCTION : System Description

INFOID:000000008163573

OUTLINE

Slide the driver seat automatically with the power walk-in switch operation so as to easily facilitate the entry to the rear seat.

Forward Operation

Slide (forward) the driver seat to the front end position (sliding limit switch: ON) by operating the power walk-in switch when the seatback is folded down.

The forward operation is stopped by folding the seatback (forward switch: OFF) during the forward operation.

Backward Operation

The seat back is folded up after performing the forward operation of power walk-in function. Slide (backward) it to the position before performing the forward operation by operating the power walk-in switch.

If the manual operation, memory operation, and Intelligent Key interlock operation are performed after performing the forward operation, do not perform the backward operation.

OPERATION PROCEDURE

Forward Operation

1. Open driver door.
2. Pull the walk-in lever on the upper part of seatback, and then the seatback is folded down.
3. Press the power walk-in switch.
4. Slide the seat to the front end position.

Backward Operation

1. Open driver door.
2. Fold up the seatback after performing the forward operation.
3. Press the power walk-in switch.
4. Slide the seat to the previous position before the forward operation was performed.

OPERATION CONDITION

Perform the power walk-in function when the following conditions are satisfied.

A
B
C
D
E
F
G
H

ADP

K
L
M
N
O
P

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

Forward Operation

| Item | Request status |
|-----------------------------|----------------------|
| Driver side door | Open |
| Driver side seat belt | Not fastened |
| Power seat switch (sliding) | Not operated |
| Vehicle speed | 0 km/h |
| Seat position (sliding) | Other than front end |
| Seat back | Folded down |

Backward Operation

| Item | Request status |
|--|---|
| Initialize | Done |
| Driver side seat belt | Not fastened |
| Switch inputs <ul style="list-style-type: none"> • Power seat switch (sliding) • Set switch • Memory switch | Not operated |
| Vehicle speed | 0 km/h |
| Seat position (sliding) | The seat sliding position will not move after performing the forward operation. |
| Seat back | Folded up |

DETAIL FLOW

Forward Operation

| Order | Inputs | Outputs | Control unit condition |
|-------|----------------------|-------------------------|---|
| 1 | Forward switch | — | Driver seat control unit detects that the seatback is folded down by the signal from the forward switch. |
| 2 | Power walk-in switch | — | The operation signal is inputted to the driver seat control unit when the power walk-in switch is operated. |
| 3 | — | Sliding motor (forward) | Driver seat control unit operates the seat sliding motor forward when it detects that the power walk-in switch is operated. |
| 4 | Sliding limit switch | — | Driver seat control unit stops the seat sliding motor when it detects that the seat sliding reaches the front end position by the sliding limit switch. |

Backward Operation


| Order | Inputs | Outputs | Control unit condition |
|-------|----------------------|--------------------------|--|
| 1 | Forward switch | — | Driver seat control unit detects that the seatback is folded up by the signal from the forward switch. |
| 2 | Power walk-in switch | — | The operation signal is inputted to the driver seat control unit when the power walk-in switch is operated. |
| 3 | — | Sliding motor (backward) | Driver seat control unit operates the sliding motor backward when it detects that the power walk-in switch is operated. |
| 4 | Sliding sensor | — | Driver seat control unit stops the seat sliding motor when the seat sliding position reaches the position before performing the forward operation by the signal from sliding sensor. |

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

POWER WALK-IN FUNCTION : Component Parts Location


INFOID:000000008163574



- | | | |
|--|--|--|
| 1. BCM M118, M119, M122, M123 | 2. Automatic drive positioner control unit M51, M52 | 3. Driver seat control unit B503, B504 |
| 4. Unified meter and A/C amp. M67 | 5. A/T assembly F51 | 6. Tilt & telescopic switch M31 |
| 7. Key slot M22 | 8. Tilt sensor M48 | 9. Telescopic sensor M48 |
| 10. Seat memory switch D5 | 11. Door mirror remote control switch D17 | |
| A. Dash side lower (passenger side) | B. View with instrument driver lower panel removed (Remove 4WAS front control unit with 4WAS models) | C. Backside of seat cushion (driver side) |
| D. Behind cluster lid C | E. A/T assembly (TCM is built in A/T assembly) | F. View with instrument driver lower panel removed |
| G. View with steering column cover lower and upper removed | | |

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >




JMJIA2416ZZ

- | | | |
|---|--|-------------------------------|
| 12. Driver side door switch B16 | 13. A/T shift selector (detention switch) M137 | 14. Parking brake switch B14 |
| 15. Door mirror (driver side) D3 | 16. Telescopic motor M49 | 17. Tilt motor M49 |
| 18. Forward switch B512 | 19. Sliding limit switch B514 | 20. Power walk-in switch B513 |
| 21. Seat belt buckle switch (driver side) B13 | | |

- | | | |
|--|--|--|
| H. View with center console assembly is removed. | I. View with center console assembly is removed. | J. View with instrument driver lower panel is removed. |
| K. View with seat back pad is removed. | L. View with seat cushion pad is removed. | |

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >



- | | | |
|-------------------------------|---|--|
| 22. Reclining motor B523 | 23. Reclining switch (Power seat switch) B510 | 24. Sliding, lifting switch (Power seat switch) B510 |
| 25. Sliding sensor B526 | 26. Lifting motor (front) B527 | 27. Sliding motor B525 |
| 28. Lifting motor (rear) B529 | | |
- M. View with seat cushion pad and seat-back pad are removed. N. Backside of seat cushion

POWER WALK-IN FUNCTION : Component Description

INFOID:000000008163575

CONTROL UNITS

| Item | Function |
|----------------------------|--|
| Driver seat control unit | <ul style="list-style-type: none"> Main units of automatic drive positioner system It is connected to the CAN. It communicates with the automatic drive positioner control unit via UART communication. |
| BCM | Transmit the following status to the driver seat control unit via CAN communication. <ul style="list-style-type: none"> Driver door: OPEN/CLOSE Starter: CRANKING/OTHER |
| Unified meter and A/C amp. | Transmit the vehicle speed signal to the driver seat control unit via CAN communication. |

INPUT PARTS

Switches

| Item | Function |
|---------------------------------|---|
| Front door switch (driver side) | Detect front door (driver side) open/close status. |
| Power walk-in switch | Perform the power walk-in operation by operating the power walk-in switch. |
| Sliding limit switch | Detect the front end position of seat sliding during the power walk-in function forward operation. |
| Seat belt buckle switch | Detect the seat belt fastening/releasing condition. |
| Forward switch | Detect the folded up/folded down condition of seatback that is the operation condition of power walk-in function. |

Sensors

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

| Item | Function |
|----------------|---|
| Sliding sensor | Detect the forward/backward position of seat. |

OUTPUT PARTS

| Item | Function |
|---------------|----------------------------------|
| Sliding motor | Slide the seat forward/backward. |

DIAGNOSIS SYSTEM (DRIVER SEAT C/U)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (DRIVER SEAT C/U)

CONSULT Function

INFOID:000000008163576

The automatic drive positioner system can be checked and diagnosed for component operation using CONSULT.

DIAGNOSTIC MODE

| Diagnostic mode | Description |
|-----------------------|--|
| SELF-DIAG RESULTS | Performs self-diagnosis for the auto drive positioner system and displays the results. |
| DATA MONITOR | Displays input signals transmitted from various switches and sensors to driver seat control unit in real time. |
| CAN DIAG SUPPORT MNTR | The result of transmit/receive diagnosis of CAN communication can be read. |
| ACTIVE TEST | Drives each output device. |
| ECU PART NUMBER | Displays part numbers of driver seat control unit. |

SELF DIAGNOSTIC RESULTS

Refer to [ADP-181, "DTC Index"](#).

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

| Monitor Item | Unit | Main Signals | Selection From Menu | Contents |
|-----------------|----------|--------------|---------------------|--|
| SET SW | "ON/OFF" | × | × | ON/OFF status judged from the setting switch signal. |
| MEMORY SW 1 | "ON/OFF" | × | × | ON/OFF status judged from the seat memory switch 1 signal. |
| MEMORY SW 2 | "ON/OFF" | × | × | ON/OFF status judged from the seat memory switch 2 signal. |
| SLIDE SW-FR*3 | "ON/OFF" | × | × | ON/OFF status judged from the sliding switch (forward) signal. |
| SLIDE SW-RR*3 | "ON/OFF" | × | × | ON/OFF status judged from the sliding switch (backward) signal. |
| RECLN SW-FR*3 | "ON/OFF" | × | × | ON/OFF status judged from the reclining switch (forward) signal. |
| RECLN SW-RR*3 | "ON/OFF" | × | × | ON/OFF status judged from the reclining switch (backward) signal. |
| LIFT FR SW-UP*3 | "ON/OFF" | × | × | ON/OFF status judged from the lifting switch front (upward) signal. |
| LIFT FR SW-DN*3 | "ON/OFF" | × | × | ON/OFF status judged from the lifting switch front (downward) signal. |
| LIFT RR SW-UP*3 | "ON/OFF" | × | × | ON/OFF status judged from the lifting switch rear (upward) signal. |
| LIFT RR SW-DN*3 | "ON/OFF" | × | × | ON/OFF status judged from the lifting switch rear (downward) signal. |
| MIR CON SW-UP | "ON/OFF" | × | × | ON/OFF status judged from the mirror switch (upward) signal. |
| MIR CON SW-DN | "ON/OFF" | × | × | ON/OFF status judged from the mirror switch (downward) signal. |
| MIR CON SW-RH | "ON/OFF" | × | × | ON/OFF status judged from the door mirror remote control switch (passenger side) signal. |
| MIR CON SW-LH | "ON/OFF" | × | × | ON/OFF status judged from the door mirror remote control switch (driver side) signal. |
| MIR CHNG SW-R | "ON/OFF" | × | × | ON/OFF status judged from the door mirror remote control switch (switching to right) signal. |
| MIR CHNG SW-L | "ON/OFF" | × | × | ON/OFF status judged from the door mirror remote control switch (switching to left) signal. |

DIAGNOSIS SYSTEM (DRIVER SEAT C/U)

< SYSTEM DESCRIPTION >

| Monitor Item | Unit | Main Signals | Selection From Menu | Contents |
|-----------------|----------|--------------|---------------------|---|
| TILT SW-UP | "ON/OFF" | × | × | ON/OFF status judged from the tilt switch (upward) signal. |
| TILT SW-DOWN | "ON/OFF" | × | × | ON/OFF status judged from the tilt switch (downward) signal. |
| TELESCO SW-FR | "ON/OFF" | × | × | ON/OFF status judged from the telescoping switch (forward) signal. |
| TELESCO SW-RR | "ON/OFF" | × | × | ON/OFF status judged from the telescoping switch (backward) signal. |
| FORWARD SW*3 | "ON/OFF" | × | × | ON/OFF status judged from the forward switch signal. |
| WALK-IN SW*3 | "ON/OFF" | × | × | ON/OFF status judged from the power walk-in switch signal. |
| FWD LIMIT SW*3 | "ON/OFF" | × | × | ON/OFF status judged from the sliding limit switch signal. |
| SEAT BELT SW*3 | "ON/OFF" | × | × | ON/OFF status judged from the seat belt buckle switch signal. |
| DETENT SW*1 | "ON/OFF" | × | × | The selector lever position "OFF (P position) / ON (other than the P position)" judged from the detention switch signal. |
| PARK BRAKE SW*2 | "ON/OFF" | × | × | The parking brake condition "ON (applied) / OFF (release)" judged from the parking brake switch signal. |
| STARTER SW | "ON/OFF" | × | × | Ignition key switch ON (START, ON) /OFF (ACC, OFF) status judged from the ignition switch signal. |
| SLIDE PULSE*3 | – | – | × | Value (32768) when battery connections are standard. If it moves backward, the value increases. If it moves forward, the value decreases. |
| RECLN PULS*4 | – | – | × | Value (32768) when battery connections are standard. If it moves backward, the value increases. If it moves forward, the value decreases. |
| LIFT FR PULSE*4 | – | – | × | Value (32768) when battery connections are standard. If it moves DOWN, the value increases. If it moves UP, the value decreases. |
| LIFT RR PULSE*4 | – | – | × | Value (32768) when battery connections are standard. If it moves DOWN, the value increases. If it moves UP, the value decreases. |
| MIR/SEN RH U–D | "V" | – | × | Voltage input from door mirror sensor (passenger side) upward/downward is displayed. |
| MIR/SEN RH R–L | "V" | – | × | Voltage input from door mirror sensor (passenger side) leftward/rightward is displayed. |
| MIR/SEN LH U–D | "V" | – | × | Voltage input from door mirror sensor (driver side) upward/downward is displayed. |
| MIR/SEN LH R–L | "V" | – | × | Voltage input from door mirror sensor (driver side) leftward/rightward is displayed. |
| TILT SEN | "V" | – | × | Voltage input from tilt sensor upward/downward is displayed. |
| TELESCO SEN | "V" | – | × | Voltage input from telescopic sensor forward/backward is displayed. |

*1: M/T models display all item except this item.

*2: A/T models display all item except this item.

*3: Only this item is displayed for driver seat without automatic drive positioner system.

*4: It is displayed but is not operated for models with driver seat without automatic driver positioner system.

ACTIVE TEST

CAUTION:

When driving vehicle, never perform active test.

| Test item | Description |
|----------------|--|
| SEAT SLIDE | Activates/deactivates the sliding motor. |
| SEAT RECLINING | Activates/deactivates the reclining motor. |

DIAGNOSIS SYSTEM (DRIVER SEAT C/U)

< SYSTEM DESCRIPTION >

| Test item | Description |
|-------------------|--|
| SEAT LIFTER FR | Activates/deactivates the lifting motor (front). |
| SEAT LIFTER RR | Activates/deactivates the lifting motor (rear). |
| TILT MOTOR* | Activates/deactivates the tilt motor. |
| TELESCO MOTOR* | Activates/deactivates the telescopic motor. |
| MIRROR MOTOR RH* | Activates/deactivates the mirror motor (passenger side). |
| MIRROR MOTOR LH* | Activates/deactivates the mirror motor (driver side). |
| MEMORY SW INDCTR* | Turns ON/OFF the memory indicator. |

*: Does not display without automatic driver position system.

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

U1000 CAN COMM CIRCUIT

Description

INFOID:000000008163577

CAN (Controller Area Network) is a serial communication line for real time applications. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicle is equipped with many electronic control unit, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H-line, CAN L-line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

DTC Logic

INFOID:000000008163578

DTC DETECTION LOGIC

| DTC No. | Trouble diagnosis name | DTC detecting condition | Possible cause |
|---------|------------------------|---|---|
| U1000 | CAN COMM CIRCUIT | <ul style="list-style-type: none">Driver seat control unit cannot communicate to other control units.Driver seat control unit cannot communicate for more than the specified time. | Harness or connectors (CAN communication line is open or shorted) |

DTC CONFIRMATION PROCEDURE

1.STEP 1

1. Turn ignition switch ON and wait for 3 seconds or more.
2. Check "Self diagnostic result" using CONSULT.

Is the DTC detected?

- YES >> Perform diagnosis procedure. Refer to [ADP-48, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008163579

Refer to [LAN-16, "Trouble Diagnosis Flow Chart"](#).

Special Repair Requirement

INFOID:000000008163580

Refer to [ADP-10, "SYSTEM INITIALIZATION : Description"](#).

B2112 SLIDING MOTOR

< DTC/CIRCUIT DIAGNOSIS >

B2112 SLIDING MOTOR

Description

INFOID:000000008163581

- The seat sliding motor is installed to the seat cushion frame.
- The seat sliding motor is installed with the driver seat control unit.
- Slides the seat forward/ rearward by changing the rotation direction of sliding motor.

DTC Logic

INFOID:000000008163582

DTC DETECTION LOGIC

NOTE:

First perform diagnosis for B2126 if B2126 is detected.

| DTC No. | Trouble diagnosis name | DTC detecting condition | Possible cause |
|---------|------------------------|--|---|
| B2112 | SEAT SLIDE | The driver seat control unit detects the output of sliding motor output terminal for 0.1 second or more even if the sliding switch is not input. | <ul style="list-style-type: none">• Driver seat control unit• Slide motor harness is power shorted |

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check "Self diagnostic result" using CONSULT.

Is the DTC detected?

- YES >> Perform diagnosis procedure. Refer to [ADP-49, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008163583

1. CHECK SLIDING MOTOR CIRCUIT (POWER SHORT)

ADP

1. Turn ignition switch OFF.
2. Disconnect sliding motor and driver seat control unit connector.
3. Check voltage between sliding motor harness connector and ground.

| (+) | | (-) | Voltage (V) (Approx.) |
|---------------|-----------|--------|--------------------------|
| Sliding motor | | | |
| Connector | Terminals | Ground | 0 |
| B525 | 35 | | |
| | 42 | | |

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace harness.

2. CHECK DRIVER SEAT CONTROL UNIT OUTPUT SIGNAL

1. Connect driver seat control unit connector.
2. Check voltage between driver seat control unit harness connector and ground.

| (+) | | (-) | Voltage (V) (Approx.) |
|--------------------------|-----------|--------|--------------------------|
| Driver seat control unit | | | |
| Connector | Terminals | Ground | 0 |
| B525 | 35 | | |
| | 42 | | |

Is the inspection result normal?

B2112 SLIDING MOTOR

< DTC/CIRCUIT DIAGNOSIS >

YES >> GO TO 3.

NO >> Replace driver seat control unit. Refer to [ADP-207, "Removal and Installation"](#)

3.CHECK INTERMITTENT INCIDENT

Refer to [GI-43, "Intermittent Incident"](#).

>> INSPECTION END

B2113 RECLINING MOTOR

< DTC/CIRCUIT DIAGNOSIS >

B2113 RECLINING MOTOR

Description

INFOID:000000008163584

- The seat reclining motor is installed to the seatback frame.
- The seat reclining motor is activated with the driver seat control unit.
- Tilts the seatback frontward/rearward by changing the rotation direction of reclining motor.

DTC Logic

INFOID:000000008163585

DTC DETECTION LOGIC

NOTE:

First perform diagnosis for B2126 if B2126 is detected.

| DTC No. | Trouble diagnosis name | DTC detecting condition | Possible cause |
|---------|------------------------|--|--|
| B2113 | SEAT RECLINING | The driver seat control unit detects the output of reclining motor output terminal for 0.1 second or more even if the reclining switch is not input. | <ul style="list-style-type: none"> • Driver seat control unit • Reclining motor harness is power shorted |

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check "Self diagnostic result" using CONSULT.

Is the DTC detected?

- YES >> Perform diagnosis procedure. Refer to [ADP-51, "Diagnosis Procedure"](#).
- NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008163586

1. CHECK RECLINING MOTOR CIRCUIT (POWER SHORT)

1. Turn ignition switch OFF.
2. Disconnect reclining motor and driver seat control unit connector.
3. Check voltage between reclining motor harness connector and ground.

| (+) | | (-) | Voltage (V) (Approx.) |
|-----------------|-----------|--------|--------------------------|
| Reclining motor | | | |
| Connector | Terminals | Ground | 0 |
| B523 | 15 | | |
| | 71 | | |

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair or replace harness.

2. CHECK DRIVER SEAT CONTROL UNIT OUTPUT SIGNAL

1. Connect driver seat control unit connector.
2. Check voltage between driver seat control unit harness connector and ground.

| (+) | | (-) | Voltage (V) (Approx.) |
|--------------------------|-----------|--------|--------------------------|
| Driver seat control unit | | | |
| Connector | Terminals | Ground | 0 |
| B523 | 15 | | |
| | 71 | | |

Is the inspection result normal?

B2113 RECLINING MOTOR

< DTC/CIRCUIT DIAGNOSIS >

YES >> GO TO 3.

NO >> Replace driver seat control unit. Refer to [ADP-207, "Removal and Installation"](#).

3.CHECK INTERMITTENT INCIDENT

Refer to [GI-43, "Intermittent Incident"](#).

>> INSPECTION END

B2118 TILT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

B2118 TILT SENSOR

Description

INFOID:000000008163587

- The tilt sensor is installed to the steering column assembly.
- The resistance of tilt sensor is changed according to the up/down position of steering column.
- The terminal voltage of automatic drive positioner control unit will be changed according to a change of tilt sensor resistance. Automatic drive positioner control unit calculates the tilt position from the voltage.

DTC Logic

INFOID:000000008163588

DTC DETECTION LOGIC

| DTC No. | Trouble diagnosis name | DTC detecting condition | Possible cause |
|---------|------------------------|---|--|
| B2118 | TILT SENSOR | The input voltage of tilt sensor is less than 0.1V or more than 4.9V. | <ul style="list-style-type: none"> • Harness and connectors (Tilt sensor circuit is opened/shorted, tilt sensor power supply circuit is opened/shorted.) • Tilt sensor |

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check "Self diagnostic result" using CONSULT.

Is the DTC detected?

- YES >> Perform diagnosis procedure. Refer to [ADP-53. "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008163589

1.CHECK TILT SENSOR SIGNAL

1. Turn ignition switch ON.
2. Select "TILT SEN" in the "Data monitor" mode using CONSULT.
3. Check tilt sensor signal under the following condition.

| Monitor item | Condition | Value |
|--------------|---------------|---|
| TILT SEN | Tilt position | Change between 1.1 V (close to top) 3.9 V (close to bottom) |

Is the value normal?

- YES >> GO TO 6.
 NO >> GO TO 2.

2.CHECK TILT SENSOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit and tilt & telescopic sensor connector.
3. Check continuity between automatic drive positioner control unit harness connector and tilt & telescopic sensor harness connector.

| Automatic drive positioner control unit | | Tilt & telescopic sensor | | Continuity |
|---|----------|--------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M51 | 7 | M48 | 3 | Existed |

4. Check continuity between automatic drive positioner control unit harness connector and ground.

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

B2118 TILT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

| Automatic drive positioner control unit | | Ground | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| M51 | 7 | | |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair or replace harness.

3. CHECK TILT SENSOR POWER SUPPLY

1. Connect automatic drive positioner control unit connector.
2. Turn ignition switch ON.
3. Check voltage between tilt & telescopic sensor harness connector and ground.

| (+) | | (-) | Voltage (V) (Approx.) |
|--------------------------|----------|--------|--------------------------|
| Tilt & telescopic sensor | | | |
| Connector | Terminal | | |
| M48 | 1 | Ground | 5 |

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> GO TO 4.

4. CHECK TILT SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and tilt & telescopic sensor harness connector.

| Automatic drive positioner control unit | | Tilt & telescopic sensor | | Continuity |
|---|----------|--------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M52 | 33 | M48 | 1 | Existed |

4. Check continuity between automatic drive positioner control unit harness connector and ground.

| Automatic drive positioner control unit | | Ground | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| M52 | 33 | | |

Is the inspection result normal?

- YES >> Replace automatic drive positioner control unit. Refer to [ADP-208, "Removal and Installation"](#).
 NO >> Repair or replace harness.

5. CHECK TILT SENSOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and tilt & telescopic sensor harness connector.

| Automatic drive positioner control unit | | Tilt & telescopic sensor | | Continuity |
|---|----------|--------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M52 | 41 | M48 | 4 | Existed |

Is the inspection result normal?

- YES >> Replace tilt & telescopic sensor.
 NO >> Repair or replace harness.

6. CHECK INTERMITTENT INCIDENT

Refer to [GI-43, "Intermittent Incident"](#).

B2118 TILT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

>> INSPECTION END

A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O

P

B2119 TELESCOPIC SENSOR

< DTC/CIRCUIT DIAGNOSIS >

B2119 TELESCOPIC SENSOR

Description

INFOID:000000008163590

- The telescopic sensor is installed to the steering column assembly.
- The resistance of telescopic sensor is changed according to the forward/backward position of steering column.
- The terminal voltage of automatic drive positioner control unit will be changed according to a change of telescopic sensor resistance. Automatic drive positioner control unit calculates the telescopic position from the voltage.

DTC Logic

INFOID:000000008163591

DTC DETECTION LOGIC

| DTC No. | Trouble diagnosis name | DTC detecting condition | Possible cause |
|---------|------------------------|---|---|
| B2119 | TELESCOPIC SENSOR | The input voltage of telescopic sensor is less than 0.1V or more than 4.9V. | <ul style="list-style-type: none">• Harness and connectors (Telescopic sensor circuit is opened/shorted, telescopic sensor power supply circuit is opened/shorted.)• Telescopic sensor |

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check "Self diagnostic result" using CONSULT.

Is the DTC is detected?

- YES >> Perform diagnosis procedure. Refer to [ADP-56. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008163592

1. CHECK TELESCOPIC SENSOR SIGNAL

1. Turn ignition switch ON.
2. Select "TELESCO SEN" in the "Data monitor" mode using CONSULT.
3. Check the tilt sensor signal under the following condition.

| Monitor item | Condition | Value |
|--------------|---------------------|---|
| TELESCO SEN | Telescopic position | Change between 0.5 V (close to top) 4.5 V (close to bottom) |

Is the valve normal?

- YES >> GO TO 6.
NO >> GO TO 2.

2. CHECK TELESCOPIC SENSOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit and tilt & telescopic sensor connector.
3. Check continuity between automatic drive positioner control unit harness connector and tilt & telescopic sensor harness connector.

| Automatic drive positioner control unit | | Tilt & telescopic sensor | | Continuity |
|---|----------|--------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M51 | 23 | M48 | 2 | Existed |

4. Check continuity between automatic drive positioner control unit harness connector and ground.

B2119 TELESCOPIC SENSOR

< DTC/CIRCUIT DIAGNOSIS >

| | | | |
|---|----------|--------|-------------|
| Automatic drive positioner control unit | | Ground | Continuity |
| Connector | Terminal | | Not existed |
| M51 | 23 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3.CHECK TELESCOPIC SENSOR POWER SUPPLY

1. Connect automatic drive positioner control unit connector.
2. Turn ignition switch ON.
3. Check voltage between tilt & telescopic sensor harness connector and ground.

| | | | |
|--------------------------|----------|--------|--------------------------|
| (+) | | (-) | Voltage (V) (Approx.) |
| Tilt & telescopic sensor | | | |
| Connector | Terminal | | |
| M48 | 1 | Ground | 5 |

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

4.CHECK TELESCOPIC SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and tilt & telescopic sensor harness connector.

| | | | | |
|---|----------|--------------------------|----------|------------|
| Automatic drive positioner control unit | | Tilt & telescopic sensor | | Continuity |
| Connector | Terminal | Connector | Terminal | |
| M52 | 33 | M48 | 1 | Existed |

4. Check continuity between automatic drive positioner control unit harness connector and ground.

| | | | |
|---|----------|--------|-------------|
| Automatic drive positioner control unit | | Ground | Continuity |
| Connector | Terminal | | Not existed |
| M52 | 33 | | |

Is the inspection result normal?

YES >> Replace automatic drive positioner control unit. Refer to [ADP-208, "Removal and Installation"](#).

NO >> Repair or replace harness.

5.CHECK TELESCOPIC SENSOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and tilt & telescopic sensor harness connector.

| | | | | |
|---|----------|--------------------------|----------|------------|
| Automatic drive positioner control unit | | Tilt & telescopic sensor | | Continuity |
| Connector | Terminal | Connector | Terminal | |
| M52 | 41 | M48 | 4 | Existed |

Is the inspection result normal?

YES >> Replace tilt & telescopic sensor.

NO >> Repair or replace harness.

6.CHECK INTERMITTENT INCIDENT

Refer to [GI-43, "Intermittent Incident"](#).

B2119 TELESCOPIC SENSOR

< DTC/CIRCUIT DIAGNOSIS >

>> INSPECTION END

B2126 DETENT SW

< DTC/CIRCUIT DIAGNOSIS >

B2126 DETENT SW

Description

INFOID:000000008163593

- Detention switch is installed on A/T shift selector. It is turned OFF when the A/T selector lever is in P position.
- The driver seat control unit judges that the A/T selector lever is in P position if continuity does not exist in this circuit.

DTC Logic

INFOID:000000008163594

DTC DETECTION LOGIC

| DTC No. | Trouble diagnosis name | DTC detecting condition | Possible cause |
|---------|------------------------|--|--|
| B2126 | DETENT SW | Selector lever is in P position and the vehicle speed of 7±4 km/h is detected. | <ul style="list-style-type: none"> • Harness and connectors (Detention switch circuit is opened/shorted.) • Detention switch • Unified meter and A/C amp. (CAN communication) |

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Drive the vehicle at 7±4 km/h or more.
2. Check "Self diagnostic result" using CONSULT.

Is the DTC detected?

- YES >> Perform diagnosis procedure. Refer to [ADP-59, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008163595

ADP

1. CHECK DTC WITH "BCM"

Check "Self diagnostic result" for BCM using CONSULT.

Is the either DTC B2601, B2602, B2603, B2604 or B2605 detected?

- YES >> Check the DTC. Refer to [BCS-73, "DTC Index"](#).
 NO >> GO TO 2.

2. CHECK DTC WITH "METER/M&A"

Check "Self diagnostic result" for METER/M&A using CONSULT.

Is the DTC detected?

- YES >> Check the DTC. Refer to [MWI-85, "DTC Index"](#).
 NO >> GO TO 3.

3. CHECK DETENTION SWITCH SIGNAL

1. Turn ignition switch ON.
2. Select "DETENT SW" in the "Data Monitor" mode using CONSULT.
3. Check detention switch signal under the following condition.

| Monitor item | Condition | | Status |
|--------------|----------------|------------------|--------|
| DETENT SW | selector lever | P position | OFF |
| | | Other than above | ON |

Is the status normal?

- YES >> GO TO 5.
 NO >> GO TO 4.

4. CHECK DETENTION SWITCH CIRCUIT

B2126 DETENT SW

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit and A/T shift selector connector.
3. Check continuity between driver seat control unit harness connector and A/T shift selector harness connector.

| Driver seat control unit | | A/T shift selector | | Continuity |
|--------------------------|----------|--------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B503 | 21 | M137 | 11 | Existed |

4. Check continuity between driver seat control unit harness connector and ground.

| Driver seat control unit | | Ground | Continuity |
|--------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B503 | 21 | | Not existed |

Is the inspection result normal?

- YES >> Replace driver seat control unit. Refer to [ADP-207, "Removal and Installation"](#).
NO >> Repair or replace harness.

5. CHECK INTERMITTENT INCIDENT

Refer to [GI-43, "Intermittent Incident"](#).

>> INSPECTION END

B2127 PARKING BRAKE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

B2127 PARKING BRAKE SWITCH

Description

INFOID:000000008163596

- Parking brake switch is installed on parking brake lever. It is turned ON when the parking brake is applied.
- The driver seat control unit judges that the parking brake is engaged if continuity exists in this circuit.

DTC Logic

INFOID:000000008163597

DTC DETECTION LOGIC

| DTC No. | Trouble diagnosis name | DTC detecting condition | Possible cause |
|---------|------------------------|--|--|
| B2127 | PARKING BRAKE | Parking brake is engaged and the vehicle speed of 7 km/h (4MPH) or more is detected. | <ul style="list-style-type: none">• Harness and connectors (Parking brake switch circuit is opened/shorted.)• Parking brake switch• Combination meter (CAN communication)• Driver seat control unit |

DTC CONFIRMATION PROCEDURE

1. STEP 1

1. Drive the vehicle at 7 km/h (4 MPH) or more.
2. Check "Self Diagnostic Result" using CONSULT.

Is the DTC detected?

- YES >> Perform diagnosis procedure. Refer to [ADP-61, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008163598

1. CHECK PARKING BRAKE SWITCH SIGNAL

ADP

1. Turn ignition switch ON.
2. Select "PARK BRAKE SW" in the "Data Monitor" mode using CONSULT.
3. Check parking brake switch signal under the following condition.

| Monitor item | Condition | | Status |
|---------------|---------------|---------|--------|
| PARK BRAKE SW | Parking brake | Applied | ON |
| | | Release | OFF |

Is the status normal?

- YES >> GO TO 5.
NO >> GO TO 2.

2. CHECK PARKING BRAKE SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect parking brake switch harness connector.
3. Turn ignition switch ON.
4. Check voltage between parking brake switch harness connector and ground.

| (+) | | (-) | Voltage (V) (Approx.) |
|-----------|----------|--------|--------------------------|
| Connector | Terminal | | |
| B14 | 1 | Ground | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> GO TO 3.

B2127 PARKING BRAKE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

3.CHECK PARKING BRAKE SWITCH HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector and parking brake switch connector.
3. Check continuity between driver seat control unit harness connector and parking brake switch harness connector.

| Driver seat control unit | | Parking brake switch | | Continuity |
|--------------------------|----------|----------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B503 | 8 | B14 | 1 | Existed |

4. Check continuity between driver seat control unit harness connector and ground.

| Driver seat control unit | | Ground | Continuity |
|--------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B503 | 8 | | Not existed |

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-207. "Removal and Installation"](#).

NO >> Repair or replace harness.

4.CHECK PARKING BRAKE SWITCH

Refer to [ADP-62. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Adjust or replace parking brake switch.

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-43. "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000008163599

1.CHECK PARKING BRAKE SWITCH

1. Turn ignition switch OFF.
2. Disconnect parking brake switch connector.
3. Check continuity between parking brake switch terminal and ground part of parking brake switch.

| Terminal | | Condition | Continuity |
|----------------------|-------------------------------------|---------------|---------------------------------|
| Parking brake switch | | | |
| 1 | Ground part of parking brake switch | Parking brake | Applied Existed |
| | | | Other than above Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Adjust or replace parking brake switch.

B2128 UART COMMUNICATION LINE

< DTC/CIRCUIT DIAGNOSIS >

B2128 UART COMMUNICATION LINE

Description

INFOID:000000008163600

Driver seat control unit performs UART communication with the automatic drive positioner control unit using 2 communication lines, TX and RX line. Driver seat control unit receives the operation signals of tilt & telescopic switch, door mirror remote control switch, set switch and memory switch and the position signals of tilt & telescopic sensor and door mirror sensor from the automatic drive positioner control unit and transmits the operation request signal.

DTC Logic

INFOID:000000008163601

DTC DETECTION LOGIC

| DTC No. | Trouble diagnosis name | DTC detecting condition | Possible cause |
|---------|------------------------|--|---|
| B2128 | UART COMM | The communication between driver seat control unit and auto drive positioner control unit is interrupted for a period of time. | <ul style="list-style-type: none"> • UART communication line (UART communication line is open or shorted) • Driver seat control unit • Automatic drive positioner control unit |

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Operate tilt & telescopic switch for more than 2 seconds.
3. Check "Self diagnostic result" using CONSULT.

Is the DTC detected?

- YES >> Perform diagnosis procedure. Refer to [ADP-63, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008163602

ADP

1. CHECK UART COMMUNICATION LINE CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit and automatic drive positioner control unit connector.
3. Check continuity between driver seat control unit harness connector and automatic drive positioner control unit harness connector.

| Driver seat control unit | | Automatic drive positioner control unit | | Continuity |
|--------------------------|----------|---|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B503 | 1 | M51 | 10 | Existed |
| | 17 | | 26 | |

4. Check continuity between driver seat control unit harness connector and ground.

| Driver seat control unit | | Ground | Continuity |
|--------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B503 | 1 | | Not existed |
| | 17 | | |

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).
 NO >> Repair or replace harness.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

POWER SUPPLY AND GROUND CIRCUIT

BCM

BCM : Diagnosis Procedure

INFOID:000000008163603

1. CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

| Signal name | Fuse and fusible link No. |
|----------------------|---------------------------|
| Battery power supply | K (40A) |
| | 10 (10A) |

Is the fuse fusing?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit if a fuse or fusible link is blown.

NO >> GO TO 2.

2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connectors.
3. Check voltage between BCM harness connector and ground.

| (+) | | (-) | Voltage (Approx.) |
|-----------|----------|--------|-------------------|
| BCM | | | |
| Connector | Terminal | Ground | Battery voltage |
| M118 | 1 | | |
| M119 | 11 | | |

Is the measurement value normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3. CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

| BCM | | Ground | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal | | |
| M119 | 13 | | Existed |

Does continuity exist?

YES >> INSPECTION END

NO >> Repair harness or connector.

DRIVER SEAT CONTROL UNIT

DRIVER SEAT CONTROL UNIT : Diagnosis Procedure

INFOID:000000008163604

NOTE:

Do not disconnect the battery negative terminal and the driver seat control unit connector until DTC is confirmed using CONSULT.

1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Check voltage between driver seat control unit harness connector and ground.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

| (+) | | (-) | Voltage (V) (Approx.) |
|--------------------------|----------|--------|--------------------------|
| Driver seat control unit | | | |
| Connector | Terminal | Ground | Battery voltage |
| B504 | 33 | | |
| | 40 | | |

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check the following.

- Repair or replace harness between driver seat control unit and fuse block (J/B).
- Circuit breaker.

2.CHECK GROUND CIRCUIT

Check continuity between the driver seat control unit harness connector and ground.

| Driver seat control unit | | Ground | Continuity |
|--------------------------|----------|--------|------------|
| Connector | Terminal | | Existed |
| B503 | 32 | | |
| B504 | 48 | | |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace harness.

DRIVER SEAT CONTROL UNIT : Special Repair Requirement

INFOID:000000008163605

1.PERFORM ADDITIONAL SERVICE

Perform additional service when removing battery negative terminal.

>> Refer to [ADP-64. "DRIVER SEAT CONTROL UNIT : Diagnosis Procedure"](#).

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

AUTOMATIC DRIVE POSITIONER CONTROL UNIT : Diagnosis Procedure

INFOID:000000008163605

NOTE:

Do not disconnect the battery negative terminal and the driver seat control unit connector until DTC is confirmed using CONSULT.

1.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Check voltage between automatic drive positioner control unit harness connector and ground.

| (+) | | (-) | Voltage (V) (Approx.) |
|---|----------|--------|--------------------------|
| Automatic drive positioner control unit | | | |
| Connector | Terminal | Ground | Battery voltage |
| M52 | 34 | | |
| | 39 | | |

Is the inspection result normal?

YES >> GO TO 2.

NO - 1 >> Repair or replace harness between automatic drive positioner control unit and fuse block (J/B).

NO - 2 >> Check circuit breaker.

2.CHECK GROUND CIRCUIT

Check continuity between the automatic drive positioner control unit harness connector and ground.

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

| Automatic drive positioner control unit | | Ground | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| M52 | 40 | | Existed |
| | 48 | | |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace harness.

AUTOMATIC DRIVE POSITIONER CONTROL UNIT : Special Repair Requirement

INFOID:000000008163607

1.PERFORM ADDITIONAL SERVICE

Perform additional service when removing battery negative terminal.

>> Refer to [ADP-9, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Description"](#).

SLIDING SWITCH

< DTC/CIRCUIT DIAGNOSIS >

SLIDING SWITCH

Description

INFOID:000000008163608

Sliding switch is equipped to the power seat switch on the seat cushion side surface. The operation signal is input to the driver seat control unit when the sliding switch is operated.

Component Function Check

INFOID:000000008163609

1. CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "SLIDE SW-FR", "SLIDE SW-RR" in the "Data monitor" mode using CONSULT.
3. Check sliding switch signal under the following conditions.

| Monitor item | Condition | | Status |
|--------------|---------------------------|---------|--------|
| SLIDE SW-FR | Sliding switch (forward) | Operate | ON |
| | | Release | OFF |
| SLIDE SW-RR | Sliding switch (backward) | Operate | ON |
| | | Release | OFF |

Is the indication normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-67. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008163610

1. CHECK SLIDING SWITCH SIGNAL

1. Turn ignition switch OFF.
2. Disconnect power seat switch connector.
3. Turn ignition switch ON.
4. Check voltage between power seat switch harness connector and ground.

| (+) | | (-) | Voltage (V) (Approx.) |
|-------------------|----------|--------|--------------------------|
| Power seat switch | | | |
| Connector | Terminal | Ground | Battery voltage |
| B510 | 11 | | |
| | 26 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK SLIDING SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between driver seat control unit harness connector and power seat switch harness connector.

| Driver seat control unit | | Power seat switch | | Continuity |
|--------------------------|----------|-------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B503 | 11 | B510 | 11 | Existed |
| | 26 | | 26 | |

4. Check continuity between driver seat control unit harness connector and ground.

SLIDING SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Driver seat control unit | | Ground | Continuity |
|--------------------------|----------|--------|------------|
| Connector | Terminal | | |
| B503 | 11 | | |
| | 26 | | |

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-207, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK SLIDING SWITCH

Refer to [ADP-68, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace power seat switch. Refer to [ADP-210, "Removal and Installation"](#).

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-43, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000008163611

1.CHECK SLIDING SWITCH

1. Turn ignition switch OFF.
2. Disconnect power seat switch connector.
3. Check continuity between power seat switch terminals.

| Power seat switch | | Condition | Continuity | |
|-------------------|----|---------------------------|------------|-------------|
| Terminal | | | | |
| 32 | 11 | Sliding switch (backward) | Operate | Existed |
| | | | Release | Not existed |
| | 26 | Sliding switch (forward) | Operate | Existed |
| | | | Release | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace power seat switch. Refer to [ADP-210, "Removal and Installation"](#).

RECLINING SWITCH

< DTC/CIRCUIT DIAGNOSIS >

RECLINING SWITCH

Description

INFOID:000000008163612

Reclining switch is equipped to the power seat switch on the seat cushion side surface. The operation signal is input to the driver seat control unit when the reclining switch is operated.

Component Function Check

INFOID:000000008163613

1. CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "RECLN SW-FR", "RECLN SW-RR" in the "Data monitor" mode using CONSULT.
3. Check reclining switch signal under the following conditions.

| Monitor item | Condition | Status | |
|---------------|-----------------------------|---------|-----|
| RECLINE SW-FR | Reclining switch (forward) | Operate | ON |
| | | Release | OFF |
| RECLINE SW-RR | Reclining switch (backward) | Operate | ON |
| | | Release | OFF |

Is the indication normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-69. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008163614

1. CHECK RECLINING SWITCH SIGNAL

1. Turn ignition switch OFF.
2. Disconnect power seat switch connector.
3. Turn ignition switch ON.
4. Check voltage between power seat switch harness connector and ground.

| (+) | | (-) | Voltage (V) (Approx.) |
|-------------------|----------|--------|--------------------------|
| Power seat switch | | | |
| Connector | Terminal | Ground | Battery voltage |
| B510 | 12 | | |
| | 27 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK RECLINING SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between driver seat control unit harness connector and power seat switch harness connector.

| Driver seat control unit | | Power seat switch | | Continuity |
|--------------------------|----------|-------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B503 | 12 | B510 | 12 | Existed |
| | 27 | | 27 | |

4. Check continuity between driver seat control unit harness connector and ground.

RECLINING SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Driver seat control unit | | Ground | Continuity |
|--------------------------|----------|--------|------------|
| Connector | Terminal | | |
| B503 | 12 | | |
| | 27 | | |

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-207, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK RECLINING SWITCH

Refer to [ADP-70, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace power seat switch. Refer to [ADP-210, "Removal and Installation"](#).

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-43, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000008163615

1.CHECK RECLINING SWITCH

1. Turn ignition switch OFF.
2. Disconnect power seat switch connector.
3. Check continuity between power seat switch terminals.

| Power seat switch | | Condition | Continuity | |
|-------------------|----|-----------------------------|------------|-------------|
| Terminal | | | | |
| 32 | 12 | Reclining switch (backward) | Operate | Existed |
| | | | Release | Not existed |
| | 27 | Reclining switch (forward) | Operate | Existed |
| | | | Release | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace power seat switch. Refer to [ADP-210, "Removal and Installation"](#).

LIFTING SWITCH (FRONT)

< DTC/CIRCUIT DIAGNOSIS >

LIFTING SWITCH (FRONT)

Description

INFOID:000000008163616

Lifting switch (front) is equipped to the power seat switch on the seat cushion side surface. The operation signal is input to the driver seat control unit when the lifting switch (front) is operated.

Component Function Check

INFOID:000000008163617

1.CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "LIFT FR SW-UP", "LIFT FR SW-DN" in the "Data monitor" mode using CONSULT.
3. Check lifting switch (front) signal under the following conditions.

| Monitor item | Condition | | Status |
|---------------|-----------------------------|---------|--------|
| LIFT FR SW-UP | Lifting switch front (up) | Operate | ON |
| | | Release | OFF |
| LIFT FR SW-DN | Lifting switch front (down) | Operate | ON |
| | | Release | OFF |

Is the indication normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-71. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008163618

1.CHECK LIFTING SWITCH SIGNAL

1. Turn ignition switch OFF.
2. Disconnect power seat switch connector.
3. Turn ignition switch ON.
4. Check voltage between power seat switch harness connector and ground.

| (+) | | (-) | Voltage (V) (Approx.) |
|-------------------|----------|--------|--------------------------|
| Power seat switch | | | |
| Connector | Terminal | Ground | Battery voltage |
| B510 | 13 | | |
| | 28 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2.CHECK LIFTING SWITCH (FRONT) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between driver seat control unit harness connector and power seat switch harness connector.

| Driver seat control unit | | Power seat switch | | Continuity |
|--------------------------|----------|-------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B503 | 13 | B510 | 13 | Existed |
| | 28 | | 28 | |

4. Check continuity between driver seat control unit harness connector and ground.

LIFTING SWITCH (FRONT)

< DTC/CIRCUIT DIAGNOSIS >

| Driver seat control unit | | Ground | Continuity |
|--------------------------|----------|--------|------------|
| Connector | Terminal | | |
| B503 | 13 | | |
| | 28 | | |

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-207, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK LIFTING SWITCH (FRONT)

Refer to [ADP-72, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace power seat switch. Refer to [ADP-210, "Removal and Installation"](#).

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-43, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000008163619

1.CHECK LIFTING SWITCH (FRONT)

1. Turn ignition switch OFF.
2. Disconnect power seat switch connector.
3. Check continuity between power seat switch terminals.

| Power seat switch | | Condition | Continuity | |
|-------------------|----|-----------------------------|------------|-------------|
| Terminal | | | | |
| 32 | 13 | Lifting switch front (down) | Operate | Existed |
| | | | Release | Not existed |
| | 28 | Lifting switch front (up) | Operate | Existed |
| | | | Release | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace power seat switch. Refer to [ADP-210, "Removal and Installation"](#).

LIFTING SWITCH (REAR)

< DTC/CIRCUIT DIAGNOSIS >

LIFTING SWITCH (REAR)

Description

INFOID:000000008163620

Lifting switch (rear) is equipped to the power seat switch on the seat cushion side surface. The operation signal is input to the driver seat control unit when the lifting switch (rear) is operated.

Component Function Check

INFOID:000000008163621

1. CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "LIFT RR SW-UP", "LIFT RR SW-DN" in the "Data monitor" mode using CONSULT.
3. Check lifting switch (rear) signal under the following conditions.

| Monitor item | Condition | | Status |
|---------------|----------------------------|---------|--------|
| LIFT RR SW-UP | Lifting switch rear (up) | Operate | ON |
| | | Release | OFF |
| LIFT RR SW-DN | Lifting switch rear (down) | Operate | ON |
| | | Release | OFF |

Is the indication normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-73. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008163622

1. CHECK LIFTING SWITCH (REAR) SIGNAL

1. Turn ignition switch OFF.
2. Disconnect power seat switch connector.
3. Turn ignition switch ON.
4. Check voltage between power seat switch harness connector and ground.

| (+) | | (-) | Voltage (V) (Approx.) |
|-------------------|----------|--------|--------------------------|
| Power seat switch | | | |
| Connector | Terminal | Ground | Battery voltage |
| B510 | 14 | | |
| | 29 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK LIFTING SWITCH (REAR) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between driver seat control unit harness connector and power seat switch harness connector.

| Driver seat control unit | | Power sear switch | | Continuity |
|--------------------------|----------|-------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B503 | 14 | B510 | 14 | Existed |
| | 29 | | 29 | |

4. Check continuity between driver seat control unit harness connector and ground.

LIFTING SWITCH (REAR)

< DTC/CIRCUIT DIAGNOSIS >

| Driver seat control unit | | Ground | Continuity |
|--------------------------|----------|--------|------------|
| Connector | Terminal | | |
| B503 | 14 | | |
| | 29 | | |

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-207, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK LIFTING SWITCH (REAR)

Refer to [ADP-74, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace power seat switch. Refer to [ADP-210, "Removal and Installation"](#).

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-43, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000008163623

1.CHECK LIFTING SWITCH (REAR)

1. Turn ignition switch OFF.
2. Disconnect power seat switch connector.
3. Check continuity between power seat switch terminals.

| Power seat switch | | Condition | | Continuity |
|-------------------|----|----------------------------|---------|-------------|
| Terminal | | | | |
| 32 | 14 | Lifting switch rear (down) | Operate | Existed |
| | | | Release | Not existed |
| | 29 | Lifting switch rear (up) | Operate | Existed |
| | | | Release | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace power seat switch. Refer to [ADP-210, "Removal and Installation"](#).

FORWARD SWITCH

< DTC/CIRCUIT DIAGNOSIS >

FORWARD SWITCH

Description

INFOID:000000008163624

Forward switch is installed on the seat back frame. Forward switch detects condition of seat back.

Component Function Check

INFOID:000000008163625

1.CHECK FUNCTION

1. Select "FORWARD SW" in the "Data Monitor" mode using CONSULT.
2. Check the forward switch signal under the following condition.

| Test item | Condition | | Status |
|------------|-----------------------|-------------|--------|
| FORWARD SW | Driver side seat back | Folded up | ON |
| | | Folded down | OFF |

Is the indication normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-75, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008163626

1.CHECK FORWARD SWITCH SIGNAL

1. Turn ignition switch OFF.
2. Disconnect forward switch harness connector.
3. Check voltage between forward switch harness connector and ground.

| (+) | | (-) | Condition | Voltage (V) (Approx.) |
|-----------|----------|--------|---|--------------------------|
| Connector | Terminal | | | |
| B512 | 41 | Ground | Seat back is folded up and power walk-in switch pressed | 5 |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2.CHECK FORWARD SWITCH CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check continuity between driver seat control unit harness connector and forward switch harness connector.

| Driver seat control unit | | Forward switch | | Continuity |
|--------------------------|----------|----------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B504 | 41 | B512 | 41 | Existed |

3. Check continuity between driver seat control unit harness connector and ground.

| Driver seat control unit | | Ground | Continuity |
|--------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B504 | 41 | | Not existed |

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-207, "Removal and Installation"](#)

NO >> Repair or replace harness.

3.FORWARD SWITCH GROUND CIRCUIT

Check continuity between forward switch harness connector and ground.

FORWARD SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Forward switch | | Ground | Continuity |
|----------------|----------|--------|------------|
| Connector | Terminal | | Existed |
| B512 | 32 | | |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK FORWARD SWITCH

Refer to [ADP-76. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace forward switch (Built in seat back frame). Refer to [SE-163. "Exploded View"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-43. "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000008163627

1.CHECK FORWARD SWITCH

1. Turn ignition switch OFF.
2. Disconnect forward switch connector.
3. Check continuity between forward switch terminals.

| Forward switch | | Condition | Continuity | | |
|----------------|----------|-----------|-----------------------|-----------|-------------|
| Connector | Terminal | | Existed | | |
| B512 | 41 | 32 | Driver side seat back | Folded up | Not existed |
| | | | Folded down | Existed | |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace forward switch (Built in seat back frame). Refer to [SE-163. "Exploded View"](#).

SEAT BELT BUCKLE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

SEAT BELT BUCKLE SWITCH

Description

INFOID:000000008163628

Seat belt buckle switch is installed in seat belt buckle. Seat belt buckle switch detects condition of seat belt.

Component Function Check

INFOID:000000008163629

1.CHECK FUNCTION

1. Select "SEAT BELT SW" in the "Data Monitor" mode using CONSULT.
2. Check the seat belt buckle switch signal under the following condition.

| Test item | Condition | | Status |
|--------------|-----------------------|----------|--------|
| SEAT BELT SW | Driver side seat belt | Fastened | ON |
| | | Released | OFF |

Is the indication normal?

YES >> INSPECTION END

NO >> Refer to [ADP-77, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008163630

1.CHECK SEAT BELT BUCKLE SWITCH SIGNAL

1. Turn ignition switch OFF.
2. Disconnect seat belt buckle switch harness connector.
3. Check voltage between seat belt buckle switch harness connector and ground.

| (+) | | (-) | Voltage (V) (Approx.) |
|-------------------------|----------|--------|--------------------------|
| Seat belt buckle switch | | | |
| Connector | Terminal | | |
| B13 | 1 | Ground | 5 |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2.CHECK SEAT BELT BUCKLE SWITCH CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check continuity between driver seat control unit harness connector and seat belt buckle switch harness connector.

| Driver seat control unit | | Seat belt buckle switch | | Continuity |
|--------------------------|----------|-------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B503 | 5 | B13 | 1 | Existed |

3. Check continuity between driver seat control unit harness connector and ground.

| Driver seat control unit | | Ground | Continuity |
|--------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B503 | 5 | | Not existed |

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-207, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK SEAT BELT BUCKLE SWITCH GROUND CIRCUIT

Check continuity between seat belt buckle switch harness connector and ground.

SEAT BELT BUCKLE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Seat belt buckle switch | | Ground | Continuity |
|-------------------------|----------|--------|------------|
| Connector | Terminal | | |
| B13 | 2 | | Existed |

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair or replace harness.

4.CHECK SEAT BELT BUCKLE SWITCH

Refer to [ADP-78, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> Replace seat belt buckle switch (Built in seat belt buckle). Refer to [SE-163, "Exploded View"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-43, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000008163631

1.CHECK SEAT BELT BUCKLE SWITCH

1. Turn ignition switch OFF.
2. Disconnect seat belt buckle switch connector.
3. Check continuity between seat belt buckle switch terminals.

| Seat belt buckle switch | | Condition | Continuity | |
|-------------------------|----------|-----------------------|------------|-------------|
| Connector | Terminal | | | |
| B13 | 1 | Driver side seat belt | Fastened | Not existed |
| | | | Released | Existed |

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> Replace seat belt buckle switch (Built in seat belt buckle). Refer to [SE-163, "Exploded View"](#).

SLIDING LIMIT SWITCH

< DTC/CIRCUIT DIAGNOSIS >

SLIDING LIMIT SWITCH

Description

INFOID:000000008163632

Sliding limit switch is installed on seat cushion frame. Sliding limit switch detects condition of seat sliding.

Component Function Check

INFOID:000000008163633

1.CHECK FUNCTION

1. Select "FWD LIMIT SW" in the "Data Monitor" mode using CONSULT.
2. Check the sliding limit switch signal under the following condition.

| Test item | Condition | | Status |
|--------------|--------------|------------------|--------|
| FWD LIMIT SW | Seat sliding | Front edge | ON |
| | | Other than above | OFF |

Is the indication normal?

- YES >> INSPECTION END
 NO >> Go to [ADP-79, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008163634

1.CHECK SLIDING LIMIT SWITCH SIGNAL

1. Turn ignition switch OFF.
2. Disconnect sliding limit switch harness connector.
3. Check voltage between sliding limit switch harness connector and ground.

| (+) | | (-) | Voltage (V) (Approx.) |
|----------------------|----------|--------|--------------------------|
| Sliding limit switch | | | |
| Connector | Terminal | Ground | 5 |
| B514 | 4 | | |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 2.

2.CHECK SLIDING LIMIT SWITCH CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check continuity between driver seat control unit harness connector and sliding limit switch harness connector.

| Driver seat control unit | | Sliding limit switch | | Continuity |
|--------------------------|----------|----------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B503 | 4 | B514 | 4 | Existed |

3. Check continuity between driver seat control unit harness connector and ground.

| Driver seat control unit | | Ground | Continuity |
|--------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B503 | 4 | | Not existed |

Is the inspection result normal?

- YES >> Replace driver seat control unit. Refer to [ADP-207, "Removal and Installation"](#)
 NO >> Repair or replace harness.

3.CHECK SLIDING LIMIT SWITCH GROUND CIRCUIT

Check continuity between sliding limit switch harness connector and ground.

SLIDING LIMIT SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Sliding limit switch | | Ground | Continuity |
|----------------------|----------|--------|------------|
| Connector | Terminal | | Existed |
| B514 | 32 | | |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK SLIDING LIMIT SWITCH

Refer to [ADP-80. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace forward switch (Built in seat back frame). Refer to [SE-163. "Exploded View"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-43. "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000008163635

1.CHECK SLIDING LIMIT SWITCH

1. Turn ignition switch OFF.
2. Disconnect sliding limit switch connector.
3. Check continuity between sliding limit switch terminals.

| Sliding limit switch | | | Condition | Continuity | |
|----------------------|----------|----|--------------|------------------|-------------|
| Connector | Terminal | | | Existed | |
| B514 | 4 | 32 | Seat sliding | Front edge | Existed |
| | | | | Other than above | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace forward switch (Built in seat back frame). Refer to [SE-163. "Exploded View"](#).

POWER WALK-IN SWITCH

< DTC/CIRCUIT DIAGNOSIS >

POWER WALK-IN SWITCH

Description

INFOID:000000008163636

Power walk-in switch is installed on seat back. The operation signal is input to driver seat control unit when power walk-in switch is operated.

Component Function Check

INFOID:000000008163637

1.CHECK FUNCTION

1. Select "WALK-IN SW" in the "Data Monitor" mode using CONSULT.
2. Check the power walk-in switch signal under the following condition.

| Test item | Condition | | Status |
|------------|----------------------|----------|--------|
| WALK-IN SW | Power walk-in switch | Pressed | ON |
| | | Released | OFF |

Is the indication normal?

- YES >> INSPECTION END
NO >> Refer to [ADP-81, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008163638

1.CHECK POWER WALK-IN SWITCH SIGNAL

1. Turn ignition switch OFF.
2. Disconnect power walk-in switch harness connector.
3. Check voltage between power walk-in switch harness connector and ground.

| (+) | | (-) | Voltage (V) (Approx.) |
|----------------------|----------|--------|--------------------------|
| Power walk-in switch | | | |
| Connector | Terminal | Ground | 5 |
| B513 | 30 | | |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2.CHECK POWER WALK-IN SWITCH CIRCUIT

1. Disconnect driver seat control unit connector and power walk-in switch connector.
2. Check continuity between driver seat control unit harness connector and power walk-in switch harness connector.

| Driver seat control unit | | Power walk-in switch | | Continuity |
|--------------------------|----------|----------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B503 | 30 | B513 | 30 | Existed |

3. Check continuity between driver seat control unit harness connector and ground.

| Driver seat control unit | | Ground | Continuity |
|--------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B503 | 30 | | Not existed |

Is the inspection result normal?

- YES >> Replace driver seat control unit. Refer to [ADP-207, "Removal and Installation"](#).
NO >> Repair or replace harness.

3.CHECK POWER WALK-IN SWITCH GROUND CIRCUIT

Check continuity between power walk-in switch harness connector and ground.

POWER WALK-IN SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Power walk-in switch | | Ground | Continuity |
|----------------------|----------|--------|------------|
| Connector | Terminal | | |
| B513 | 32 | | Existed |

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair or replace harness.

4.CHECK POWER WALK-IN SWITCH

Refer to [ADP-82. "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> Replace power walk-in switch (Built in walk-in lever). Refer to [SE-163. "Exploded View"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-43. "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000008163639

1.CHECK POWER WALK-IN SWITCH

1. Turn ignition switch OFF.
2. Disconnect power walk-in switch connector.
3. Check continuity between power walk-in switch terminals.

| Power walk-in switch | | Condition | Continuity |
|----------------------|----------|----------------------|-------------------------|
| Connector | Terminal | | |
| B513 | 30 | Power walk-in switch | 32 Pressed Existed |
| | | | 32 Released Not existed |

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> Replace power walk-in switch (Built in walk-in lever). Refer to [SE-163. "Exploded View"](#).

TILT SWITCH

< DTC/CIRCUIT DIAGNOSIS >

TILT SWITCH

Description

INFOID:000000008163640

Tilt switch is equipped to the steering column. The operation signal is input to the automatic drive positioner control unit when the tilt switch is operated.

Component Function Check

INFOID:000000008163641

1.CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "TILT SW-UP", "TILT SW-DN" in the "Data monitor" mode using CONSULT.
3. Check tilt switch signal under the following conditions.

| Monitor item | Condition | | Status |
|--------------|--------------------|---------|--------|
| TILT SW-UP | Tilt switch (up) | Operate | ON |
| | | Release | OFF |
| TILT SW-DN | Tilt switch (down) | Operate | ON |
| | | Release | OFF |

Is the indication normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-83. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008163642

1.CHECK TILT SWITCH SIGNAL

1. Turn ignition switch OFF.
2. Disconnect tilt & telescopic switch connector.
3. Turn ignition switch ON.
4. Check voltage between tilt & telescopic switch harness connector and ground.

| (+) | | (-) | Voltage (V) (Approx.) |
|--------------------------|----------|--------|--------------------------|
| Tilt & telescopic switch | | | |
| Connector | Terminal | | |
| M31 | 4 | Ground | Battery voltage |
| | 5 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2.CHECK TILT SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and tilt & telescopic switch harness connector.

| Automatic drive positioner control unit | | Tilt & telescopic switch | | Continuity |
|---|----------|--------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M51 | 1 | M31 | 4 | Existed |
| | 17 | | 5 | |

4. Check continuity between automatic drive positioner control unit harness connector and ground.

TILT SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Automatic drive positioner control unit | | Ground | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| M51 | 1 | | |
| | 17 | | |

Is the inspection result normal?

YES >> Replace automatic drive positioner control unit. Refer to [ADP-208, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK TILT SWITCH

Refer to [ADP-84, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace tilt & telescopic switch. Refer to [ADP-212, "Removal and Installation"](#).

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-43, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000008163643

1.CHECK TILT SWITCH

1. Turn ignition switch OFF.
2. Disconnect tilt & telescopic switch connector.
3. Check continuity between tilt & telescopic switch terminals.

| Tilt & telescopic switch | | Condition | | Continuity |
|--------------------------|---|--------------------|---------|-------------|
| Terminal | | | | |
| 1 | 4 | Tilt switch (up) | Operate | Existed |
| | | | Release | Not existed |
| | 5 | Tilt switch (down) | Operate | Existed |
| | | | Release | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace tilt & telescopic switch. Refer to [ADP-212, "Removal and Installation"](#).

TELESCOPIC SWITCH

< DTC/CIRCUIT DIAGNOSIS >

TELESCOPIC SWITCH

Description

INFOID:000000008163644

Telescopic switch is equipped to the steering column. The operation signal is input to the automatic drive positioner control unit when the telescopic switch is operated.

Component Function Check

INFOID:000000008163645

1. CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "TELESCO SW-FR", "TELESCO SW-RR" in the "Data monitor" mode using CONSULT.
3. Check telescopic switch signal under the following conditions.

| Monitor item | Condition | Status | |
|---------------|------------------------------|---------|-----|
| TELESCO SW-FR | Telescopic switch (forward) | Operate | ON |
| | | Release | OFF |
| TELESCO SW-RR | Telescopic switch (backward) | Operate | ON |
| | | Release | OFF |

Is the indication normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-85. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008163646

1. CHECK TELESCOPIC SWITCH SIGNAL

1. Turn ignition switch OFF.
2. Disconnect tilt & telescopic switch connector.
3. Turn ignition switch ON.
4. Check voltage between tilt & telescopic switch harness connector and ground.

| (+) | | (-) | Voltage (V) (Approx.) |
|--------------------------|----------|--------|--------------------------|
| Tilt & telescopic switch | | | |
| Connector | Terminal | Ground | Battery voltage |
| M31 | 2 | | |
| | 3 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK TELESCOPIC SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and tilt & telescopic switch harness connector.

| Automatic drive positioner control unit | | Tilt & telescopic switch | | Continuity |
|---|----------|--------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M51 | 11 | M31 | 2 | Existed |
| | 27 | | 3 | |

4. Check continuity between automatic drive positioner control unit harness connector and ground.

TELESCOPIC SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Automatic drive positioner control unit | | Ground | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| M51 | 11 | | |
| | 27 | | |

Is the inspection result normal?

YES >> Replace automatic drive positioner control unit. Refer to [ADP-208, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK TELESCOPIC SWITCH

Refer to [ADP-86, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace tilt & telescopic switch. Refer to [ADP-212, "Removal and Installation"](#).

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-43, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000008163647

1.CHECK TELESCOPIC SWITCH

1. Turn ignition switch OFF.
2. Disconnect tilt & telescopic switch connector.
3. Check continuity between tilt & telescopic switch terminals.

| Tilt & telescopic switch | | Condition | | Continuity |
|--------------------------|---|------------------------------|---------|-------------|
| Terminal | | | | |
| 1 | 2 | Telescopic switch (forward) | Operate | Existed |
| | | | Release | Not existed |
| | 3 | Telescopic switch (backward) | Operate | Existed |
| | | | Release | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace tilt & telescopic switch. Refer to [ADP-212, "Removal and Installation"](#).

SEAT MEMORY SWITCH

< DTC/CIRCUIT DIAGNOSIS >

SEAT MEMORY SWITCH

Description

INFOID:000000008163648

Memory switch is equipped on the seat set switch and seat memory switch installed to the driver side door trim. The operation signal is input to the automatic drive positioner control unit when the set switch or memory switch is operated.

Component Function Check

INFOID:000000008163649

1. CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "MEMORY SW 1", "MEMORY SW 2" "SET SW" in the "Data monitor" mode using CONSULT.
3. Check seat memory switch signal under the following conditions.

| Monitor item | Condition | Status | |
|--------------|-----------------|---------|-----|
| SET SW | SET SW | Push | ON |
| | | Release | OFF |
| MEMORY SW 1 | Memory switch 1 | Push | ON |
| | | Release | OFF |
| MEMORY SW 2 | Memory switch 2 | Push | ON |
| | | Release | OFF |

Is the indication normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-87, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008163650

1. CHECK SEAT MEMORY SWITCH SIGNAL

1. Turn ignition switch OFF.
2. Disconnect seat memory switch connector.
3. Turn ignition switch ON.
4. Check voltage between seat memory switch harness connector and ground.

| (+) | | (-) | Voltage (V) (Approx.) |
|--------------------|----------|--------|--------------------------|
| Seat memory switch | | | |
| Connector | Terminal | Ground | 5 |
| D5 | 3 | | |
| | 1 | | |
| | 2 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK MEMORY SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and seat memory switch harness connector.

SEAT MEMORY SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Automatic drive positioner control unit | | Seat memory switch | | Continuity |
|---|----------|--------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M51 | 24 | D5 | 3 | Existed |
| | 9 | | 1 | |
| | 25 | | 2 | |

4. Check continuity between automatic drive positioner control unit harness connector and ground.

| Automatic drive positioner control unit | | Ground | Continuity |
|---|----------|--------|-------------|
| Connector | Terminal | | |
| M51 | 24 | Ground | Not existed |
| | 9 | | |
| | 25 | | |

Is the inspection result normal?

YES >> Replace automatic drive positioner control unit. Refer to [ADP-208, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK MEMORY SWITCH GROUND CIRCUIT

- Turn ignition switch OFF.
- Check continuity between seat memory switch harness connector and ground.

| Seat memory switch | | Ground | Continuity |
|--------------------|----------|--------|------------|
| Connector | Terminal | | |
| D5 | 4 | Ground | Existed |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK SEAT MEMORY SWITCH

Refer to [ADP-88, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace seat memory switch. Refer to [ADP-209, "Removal and Installation"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-43, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000008163651

1.CHECK SEAT MEMORY SWITCH

- Turn ignition switch OFF.
- Disconnect seat memory switch connector.
- Check continuity between seat memory switch terminals.

SEAT MEMORY SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Seat memory switch | | Condition | | Continuity |
|--------------------|---|-----------------|---------|-------------|
| Terminal | | | | |
| 4 | 3 | Set switch | Push | Existed |
| | | | Release | Not existed |
| | 1 | Memory switch 1 | Push | Existed |
| | | | Release | Not existed |
| | 2 | Memory switch 2 | Push | Existed |
| | | | Release | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace seat memory switch. Refer to [ADP-209, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

DOOR MIRROR REMOTE CONTROL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

DOOR MIRROR REMOTE CONTROL SWITCH MIRROR SWITCH

MIRROR SWITCH : Description

INFOID:000000008163652

It operates angle of the door mirror face.

It transmits mirror face adjust operation to AUTOMATIC DRIVE POSITIONER CONTROL UNIT.

MIRROR SWITCH : Component Function Check

INFOID:000000008163653

1. CHECK MIRROR SWITCH FUNCTION

Check the operation on "MIR CON SW-UP/DN" and "MIR CON SW-RH/LH" in the "DATA MONITOR" mode using CONSULT.

| Monitor item | Condition | |
|------------------|--|-------|
| MIR CON SW-UP/DN | When operating the mirror switch up or down side. | : ON |
| | Other than above. | : OFF |
| MIR CON SW-RH/LH | When operating the mirror switch right or left side. | : ON |
| | Other than above. | : OFF |

Is the inspection result normal?

YES >> Mirror switch function is OK.

NO >> Refer to [ADP-90, "MIRROR SWITCH : Diagnosis Procedure"](#).

MIRROR SWITCH : Diagnosis Procedure

INFOID:000000008163654

1. CHECK MIRROR SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect door mirror remote control switch connector.
3. Turn ignition switch ON.
4. Check voltage between door mirror remote control switch harness connector and ground.

| (+) | | (-) | Voltage (V) (Approx.) |
|-----------------------------------|----------|--------|--------------------------|
| Door mirror remote control switch | | | |
| Connector | Terminal | Ground | 5 |
| D17 | 4 | | |
| | 12 | | |
| | 13 | | |
| | 15 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK MIRROR SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and door mirror remote control switch harness connector.

DOOR MIRROR REMOTE CONTROL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Automatic drive positioner control unit | | Door mirror remote control switch | | Continuity |
|---|----------|-----------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M51 | 3 | D17 | 15 | Existed |
| | 4 | | 13 | |
| | 19 | | 12 | |
| | 20 | | 4 | |

4. Check continuity between automatic drive positioner control unit harness connector and ground.

| Automatic drive positioner control unit | | Ground | Continuity |
|---|----------|--------|-------------|
| Connector | Terminal | | |
| M51 | 3 | Ground | Not existed |
| | 4 | | |
| | 19 | | |
| | 20 | | |

Is the inspection result normal?

YES >> Replace automatic drive positioner control unit. Refer to [ADP-208, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK DOOR MIRROR REMOTE CONTROL SWITCH GROUND CIRCUIT

- Turn ignition switch OFF.
- Check continuity between door mirror remote control switch harness connector and ground.

| Door mirror remote control switch | | Ground | Continuity |
|-----------------------------------|----------|--------|------------|
| Connector | Terminal | | |
| D17 | 7 | Ground | Existed |
| | | | |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK MIRROR SWITCH

Check door mirror remote control switch (mirror switch).
Refer to [ADP-91, "MIRROR SWITCH : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace door mirror remote control switch (mirror switch). Refer to [MIR-39, "Removal and Installation"](#).

5.CHECK INTERMITTENT INCIDENT

Check intermittent incident.
Refer to [GI-43, "Intermittent Incident"](#).

>> INSPECTION END

MIRROR SWITCH : Component Inspection

INFOID:000000008163655

1.CHECK MIRROR SWITCH

- Turn ignition switch OFF.
- Disconnect door mirror remote control switch connector.
- Check continuity between door mirror remote control switch terminals.

DOOR MIRROR REMOTE CONTROL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Door mirror remote control switch | | Condition | Continuity |
|-----------------------------------|----------|------------------|-------------|
| Connector | Terminal | | |
| D17 | 4 | RIGHT | Existed |
| | | Other than above | Not existed |
| | 13 | LEFT | Existed |
| | | Other than above | Not existed |
| | 15 | UP | Existed |
| | | Other than above | Not existed |
| | 12 | DOWN | Existed |
| | | Other than above | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace door mirror remote control switch. Refer to [MIR-39. "Removal and Installation"](#).

CHANGEOVER SWITCH

CHANGEOVER SWITCH : Description

INFOID:000000008163656

Changeover switch is integrated into door mirror remote control switch.

Changeover switch has three positions (L, N and R).

It changes operating door mirror motor by transmitting control signal to automatic drive positioner control unit.

CHANGEOVER SWITCH : Component Function Check

INFOID:000000008163657

1. CHECK CHANGEOVER SWITCH FUNCTION

Check the operation on "MIR CHNG SW-R" or "MIR CHNG SW-L" in the "DATA MONITOR" mode using CONSULT.

| Monitor item | Condition |
|-----------------|---|
| MIR CHNG SW-R/L | When operating the changeover toward the right or left side. : ON |
| | Other than above. : OFF |

Is the inspection result normal?

YES >> Changeover switch function is OK.

NO >> Refer to [ADP-92. "CHANGEOVER SWITCH : Diagnosis Procedure"](#).

CHANGEOVER SWITCH : Diagnosis Procedure

INFOID:000000008163658

1. CHECK CHANGEOVER SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect door mirror remote control switch connector.
3. Turn ignition switch ON.
4. Check voltage between door mirror remote control switch harness connector and ground.

| (+) | | (-) | Voltage (V) (Approx.) |
|-----------------------------------|----------|--------|--------------------------|
| Door mirror remote control switch | | | |
| Connector | Terminal | | |
| D17 | 10 | Ground | 5 |
| | 11 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK CHANGEOVER SWITCH CIRCUIT

DOOR MIRROR REMOTE CONTROL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and door mirror remote control switch harness connector.

| Automatic drive positioner control unit | | Door mirror remote control switch | | Continuity |
|---|----------|-----------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M51 | 2 | D17 | 11 | Existed |
| | 18 | | 10 | |

4. Check continuity between automatic drive positioner control unit harness connector and ground.

| Automatic drive positioner control unit | | Ground | Continuity |
|---|----------|--------|-------------|
| Connector | Terminal | | |
| M51 | 2 | | Not existed |
| | 18 | | |

Is the inspection result normal?

- YES >> Replace automatic drive positioner control unit. Refer to [ADP-208, "Removal and Installation"](#).
 NO >> Repair or replace harness.

3.CHECK DOOR MIRROR REMOTE CONTROL SWITCH GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between door mirror remote control switch harness connector and ground.

| Door mirror remote control switch | | Ground | Continuity |
|-----------------------------------|----------|--------|------------|
| Connector | Terminal | | |
| D17 | 7 | | Existed |

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair or replace harness.

4.CHECK CHANGEOVER SWITCH

Check door mirror remote control switch (changeover switch).
 Refer to [ADP-93, "CHANGEOVER SWITCH : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> Replace door mirror remote control switch (changeover switch). Refer to [MIR-39, "Removal and Installation"](#).

5.CHECK INTERMITTENT INCIDENT

Check intermittent incident.
 Refer to [GI-43, "Intermittent Incident"](#).

>> INSPECTION END

CHANGEOVER SWITCH : Component Inspection

INFOID:000000008163659

1.CHECK CHANGEOVER SWITCH

1. Turn ignition switch OFF.
2. Disconnect door mirror remote control switch connector.
3. Check continuity between door mirror remote control switch terminals.

DOOR MIRROR REMOTE CONTROL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Door mirror remote control switch | | Terminal | Condition | Continuity |
|-----------------------------------|----|----------|------------------|-------------|
| Connector | | | | |
| D17 | 10 | 7 | LEFT | Existed |
| | | | Other than above | Not existed |
| | 11 | | RIGHT | Existed |
| | | | Other than above | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace door mirror remote control switch. Refer to [MIR-39. "Removal and Installation"](#).

POWER SEAT SWITCH GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

POWER SEAT SWITCH GROUND CIRCUIT

Diagnosis Procedure

INFOID:000000008163660

1. CHECK POWER SEAT SWITCH GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect power seat switch connector.
3. Check continuity between power seat switch connector and ground.

| Power seat switch | | Ground | Continuity |
|-------------------|----------|--------|------------|
| Connector | Terminal | | Existed |
| B510 | 32 | | |

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace harness.

2. CHECK POWER SEAT SWITCH INTERNAL CIRCUIT

Check reclining switch.
Refer to [ADP-70, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Replace power seat switch. Refer to [ADP-210, "Removal and Installation"](#).

3. CHECK INTERMITTENT INCIDENT

Refer to [GI-43, "Intermittent Incident"](#).

>> INSPECTION END

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

TILT & TELESCOPIC SWITCH GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

TILT & TELESCOPIC SWITCH GROUND CIRCUIT

Diagnosis Procedure

INFOID:000000008163661

1. CHECK POWER TILT & TELESCOPIC SWITCH GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect power tilt & telescopic switch connector.
3. Check continuity between power seat switch connector and ground.

| Tilt & telescopic switch | | Ground | Continuity |
|--------------------------|----------|--------|------------|
| Connector | Terminal | | Existed |
| M31 | 1 | | |

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace harness.

2. CHECK POWER TILT & TELESCOPIC SWITCH INTERNAL CIRCUIT

Check tilt switch.
Refer to [ADP-84, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Replace tilt & telescopic switch. Refer to [ADP-212, "Removal and Installation"](#).

3. CHECK INTERMITTENT INCIDENT

Refer to [GI-43, "Intermittent Incident"](#).

>> INSPECTION END

DETENTION SWITCH

< DTC/CIRCUIT DIAGNOSIS >

DETENTION SWITCH

Description

INFOID:000000008163662

Detention switch is installed on A/T shift selector. It is turned OFF when the Selector lever is in P position. The driver seat control unit judges that the Selector lever is in P position if continuity does not exist in this circuit.

Component Function Check

INFOID:000000008163663

1. CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "DETENT SW" signal in the "Data monitor" mode using CONSULT.
3. Check detention switch signal under the following conditions.

| Monitor item | Condition | | Status |
|--------------|----------------|------------------|--------|
| DETENT SW | Selector lever | P position | OFF |
| | | Other than above | ON |

Is the indication normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-97, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008163664

1. CHECK DTC WITH "BCM"

Check "Self Diagnostic Result" for BCM using CONSULT.

Is the either DTC B2601, B2602, B2603, B2604 or B2605 detected?

YES >> Check the DTC. Refer to [BCS-73, "DTC Index"](#).

NO >> GO TO 2.

2. CHECK DETENTION SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect A/T shift selector harness connector.
3. Turn ignition switch ON.
4. Check voltage between A/T shift selector harness connector and ground.

| (+) | | (-) | Voltage (V) (Approx.) |
|--------------------|----------|--------|--------------------------|
| A/T shift selector | | | |
| Connector | Terminal | Ground | Battery voltage |
| M137 | 11 | | |

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 3.

3. CHECK DETENTION SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit.
3. Check continuity between driver seat control unit harness connector and A/T shift selector harness connector.

| Driver seat control unit | | A/T shift selector | | Continuity |
|--------------------------|----------|--------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B503 | 21 | M137 | 11 | Existed |

4. Check continuity between driver seat control unit harness connector and ground.

DETENTION SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Driver seat control unit | | Ground | Continuity |
|--------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B503 | 21 | | Not existed |

Is the inspection result normal?

- YES >> Replace driver seat control unit. Refer to [ADP-207, "Removal and Installation"](#).
 NO >> Repair or replace harness.

4.CHECK DETENTION SWITCH

Refer to [ADP-98, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> Replace A/T shift selector. Refer to [TM-270, "2WD : Removal and Installation"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-43, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000008163665

1.CHECK DETENTION SWITCH

1. Turn ignition switch OFF.
2. Disconnect A/T shift selector connector.
3. Check A/T shift selector terminals.

| A/T shift selector | | | Condition | | Continuity |
|--------------------|----------|----|----------------|------------------|-------------|
| Connector | Terminal | | | | |
| M137 | 10 | 11 | Selector lever | P position | Existed |
| | | | | Other than above | Not existed |

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> Replace A/T shift selector. Refer to [TM-270, "2WD : Removal and Installation"](#).

PARKING BRAKE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

PARKING BRAKE SWITCH

Description

INFOID:000000008163666

Parking brake switch is installed on parking brake lever. It is turned ON when the parking brake is applied. The driver seat control unit judges that the parking brake is engaged if continuity exists in this circuit.

Component Function Check

INFOID:000000008163667

1.CHECK PARKING BRAKE SWITCH INPUT SIGNAL

1. Select "PARK BRAKE SW" in the "Data Monitor" mode using CONSULT.
2. Check parking brake switch signal under the following conditions.

| Monitor item | Condition | | Status |
|---------------|---------------|---------|--------|
| PARK BRAKE SW | Parking brake | Applied | ON |
| | | Release | OFF |

Is the indication normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-99. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008163668

1.CHECK PARKING BRAKE SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect A/T shift selector harness connector.
3. Turn ignition switch ON.
4. Check voltage between parking brake switch harness connector and ground.

| (+) | | (-) | Voltage (V) (Approx.) |
|----------------------|----------|--------|--------------------------|
| Parking brake switch | | | |
| Connector | Terminal | Ground | Battery voltage |
| B14 | 1 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2.CHECK PARKING BRAKE SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between driver seat control unit harness connector and parking brake switch harness connector.

| Driver seat control unit | | Parking brake switch | | Continuity |
|--------------------------|----------|----------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B503 | 8 | B14 | 1 | Existed |

4. Check continuity between driver seat control unit harness connector and ground.

| Driver seat control unit | | Ground | Continuity |
|--------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B503 | 8 | | Not existed |

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-207. "Removal and Installation"](#).

NO >> Repair or replace harness.

PARKING BRAKE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

3.CHECK PARKING BRAKE SWITCH

Refer to [ADP-100. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Adjust or replace parking brake switch.

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-43. "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000008163669

1.CHECK PARKING BRAKE SWITCH

1. Turn ignition switch OFF.
2. Disconnect parking brake switch connector.
3. Check continuity between parking brake switch terminal and ground part of parking brake switch.

| Parking brake | | Condition | | Continuity |
|---------------|-------------------------------------|---------------|---------|-------------|
| Terminal | | | | |
| 1 | Ground part of parking brake switch | Parking brake | Applied | Existed |
| | | | Release | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO-1 >> Adjust or replace parking brake switch (pedal type). Refer to [PB-6. "PEDAL TYPE : Exploded View"](#).

NO-2 >> Adjust or replace parking brake switch (lever type). Refer to [PB-7. "LEVER TYPE : Exploded View"](#).

SLIDING SENSOR

< DTC/CIRCUIT DIAGNOSIS >

SLIDING SENSOR

Description

INFOID:000000008163670

- The sliding sensor is installed to the seat slide cushion frame.
- The pulse signal is input to the driver seat control unit when sliding is performed.
- The driver seat control unit counts the pulse and calculates the sliding amount of the seat.

Component Function Check

INFOID:000000008163671

1. CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "SLIDE PULSE" in the "Data monitor" mode using CONSULT.
3. Check sliding sensor signal under the following conditions.

| Monitor item | Condition | | Valve |
|--------------|--------------|--------------------|---------------------------------|
| SLIDE PULSE | Seat sliding | Operate (forward) | Change (increase) ^{*1} |
| | | Operate (backward) | Change (decrease) ^{*1} |
| | | Release | No change ^{*1} |

*1: The value at the seat position attained when the battery is connected is considered to be 32768.

Is the indication normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-101, "Diagnosis Procedure"](#).


Diagnosis Procedure

INFOID:000000008163672

1. CHECK SLIDING SENSOR SIGNAL

1. Turn ignition switch ON.
2. Check voltage signal between driver seat control unit harness connector and ground with oscilloscope.

ADP

| (+) Driver seat control unit | | (-) | Condition | Voltage (V) (Approx.) |
|------------------------------|----------|--------|------------------|---|
| Connector | Terminal | | | |
| B503 | 24 | Ground | Seat sliding |  10mSec/div 2V/div JMJA0119ZZ |
| | | | Other than above | |

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-207, "Removal and Installation"](#).

NO >> GO TO 2.

2. CHECK SLIDING SENSOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit and sliding sensor connector.
3. Check continuity between driver seat control unit harness connector and sliding sensor harness connector.

SLIDING SENSOR

< DTC/CIRCUIT DIAGNOSIS >

| Driver seat control unit | | Sliding sensor | | Continuity |
|--------------------------|----------|----------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B503 | 24 | B526 | 24 | Existed |

4. Check continuity between driver seat control unit harness connector and ground.

| Driver seat control unit | | Ground | Continuity |
|--------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B503 | 24 | | Not existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK SLIDING SENSOR POWER SUPPLY

1. Connect driver seat control unit connector.
2. Turn ignition switch ON.
3. Check voltage between sliding sensor harness connector and ground.

| (+) | | (-) | Voltage (V) (Approx.) |
|----------------|----------|--------|--------------------------|
| Sliding sensor | | | |
| Connector | Terminal | | |
| B526 | 16 | Ground | Battery voltage |

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

4. CHECK SLIDING SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between driver seat control unit harness connector and sliding sensor harness connector.

| Driver seat control unit | | Sliding sensor | | Continuity |
|--------------------------|----------|----------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B503 | 16 | B526 | 16 | Existed |

4. Check continuity between driver seat control unit harness connector and ground.

| Driver seat control unit | | Ground | Continuity |
|--------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B503 | 16 | | Not existed |

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-207, "Removal and Installation"](#).

NO >> Repair or replace harness.

5. CHECK SLIDING SENSOR GROUND CIRCUIT 1

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between driver seat control unit harness connector and sliding sensor harness connector.

| Driver seat control unit | | Sliding sensor | | Continuity |
|--------------------------|----------|----------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B503 | 31 | B526 | 31 | Existed |

SLIDING SENSOR

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace harness.

6.CHECK SLIDING SENSOR GROUND CIRCUIT 2

1. Connect driver seat control unit connector.
2. Check continuity between driver seat control unit harness connector and ground.

| Driver seat control unit | | Ground | Continuity |
|--------------------------|----------|--------|------------|
| Connector | Terminal | | |
| B503 | 31 | | Existed |

Is the inspection result normal?

YES >> Replace sliding sensor (Built in seat slide cushion frame). Refer to [ST-21, "WITH ELECTRIC MOTOR : Exploded View"](#).

NO >> Replace driver seat control unit. Refer to [ADP-207, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

RECLINING SENSOR

< DTC/CIRCUIT DIAGNOSIS >

RECLINING SENSOR

Description

INFOID:000000008163673

- The reclining motor is installed to the seatback frame.
- The pulse signal is input to the driver seat control unit when the reclining is operated.
- The driver seat control unit counts the pulse and calculates the reclining amount of the seat.

Component Function Check

INFOID:000000008163674

1. CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "RECLN PULSE" in the "Data monitor" mode using CONSULT.
3. Check reclining sensor signal under the following conditions.

| Monitor item | Condition | | Value |
|--------------|----------------|--------------------|---------------------|
| RECLN PULSE | Seat reclining | Operate (forward) | Change (increase)*1 |
| | | Operate (backward) | Change (decrease)*1 |
| | | Release | No change*1 |

*1: The value at the seat position attained when the battery is connected is considered to be 32768.

Is the indication normal?

YES >> INSPECTION END


NO >> Perform diagnosis procedure. Refer to [ADP-104, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008163675

1. CHECK RECLINING SENSOR SIGNAL

1. Turn ignition switch ON.
2. Check voltage signal between driver seat control unit harness connector and ground with oscilloscope.

| (+) Driver seat control unit | | (-) | Condition | Voltage (V) (Approx.) |
|------------------------------|----------|--------|------------------|---|
| Connector | Terminal | | | |
| B503 | 9 | Ground | Seat reclining |  10mSec/div 2V/div JMJA0119ZZ |
| | | | Other than above | |

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-207, "Removal and Installation"](#).

NO >> GO TO 2.

2. CHECK RECLINING SENSOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit and reclining motor connector.
3. Check continuity between driver seat control unit harness connector and reclining motor harness connector.

RECLINING SENSOR

< DTC/CIRCUIT DIAGNOSIS >

| Driver seat control unit | | Reclining motor | | Continuity |
|--------------------------|----------|-----------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B503 | 9 | B523 | 9 | Existed |

4. Check continuity between driver seat control unit harness connector and ground.

| Driver seat control unit | | Ground | Continuity |
|--------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B503 | 9 | | Not existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK RECLINING SENSOR POWER SUPPLY

1. Connect driver seat control unit connector.
2. Turn ignition switch ON.
3. Check voltage between reclining motor harness connector and ground.

| (+) | | (-) | Voltage (V) (Approx.) |
|-----------------|----------|--------|--------------------------|
| Reclining motor | | | |
| Connector | Terminal | | |
| B523 | 16 | Ground | Battery voltage |

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

4. CHECK RECLINING SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between driver seat control unit harness connector and reclining motor harness connector.

| Driver seat control unit | | Reclining motor | | Continuity |
|--------------------------|----------|-----------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B503 | 16 | B523 | 16 | Existed |

4. Check continuity between driver seat control unit harness connector and ground.

| Driver seat control unit | | Ground | Continuity |
|--------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B503 | 16 | | Not existed |

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-207, "Removal and Installation"](#).

NO >> Repair or replace harness.

5. CHECK RECLINING SENSOR GROUND CIRCUIT 1

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between driver seat control unit harness connector and reclining motor harness connector.

| Driver seat control unit | | Reclining motor | | Continuity |
|--------------------------|----------|-----------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B503 | 31 | B523 | 31 | Existed |

RECLINING SENSOR

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace harness.

6. CHECK RECLINING SENSOR GROUND CIRCUIT 2

1. Connect driver seat control unit connector.
2. Check continuity between reclining sensor harness connector and ground.

| Driver seat control unit | | Ground | Continuity |
|--------------------------|----------|--------|------------|
| Connector | Terminal | | |
| B503 | 31 | | Existed |

Is the inspection result normal?

YES >> Replace reclining motor. Refer to [SE-163, "Exploded View"](#).

NO >> Replace driver seat control unit. Refer to [ADP-207, "Removal and Installation"](#).

LIFTING SENSOR (FRONT)

< DTC/CIRCUIT DIAGNOSIS >

LIFTING SENSOR (FRONT)

Description

INFOID:000000008163676

- The lifting sensor (front) is installed to the seat slide cushion frame.
- The pulse signal is input to the driver seat control unit when the lifting (front) is operated.
- The driver seat control unit counts the pulse and calculates the lifting (front) amount of the seat.

Component Function Check

INFOID:000000008163677

1. CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "LIFT FR PULSE" in the "Data monitor" mode using CONSULT.
3. Check the lifting sensor (front) signal under the following conditions.

| Monitor item | Condition | | Value |
|---------------|----------------------|----------------|---------------------------------|
| LIFT FR PULSE | Seat lifting (front) | Operate (Up) | Change (increase) ^{*1} |
| | | Operate (Down) | Change (decrease) ^{*1} |
| | | Release | No change ^{*1} |

^{*1}:The value at the seat position attained when the battery is connected is considered to be 32768.

Is the indication normal?

YES >> INSPECTION END


NO >> Perform diagnosis procedure. Refer to [ADP-107. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008163678

1. CHECK LIFTING SENSOR (FRONT) SIGNAL

1. Turn ignition switch ON.
2. Check the voltage signal driver seat control unit harness connector and ground with an oscilloscope.

| (+) | | (-) | Condition | Voltage (V) (Approx.) |
|---------------------------------------|----------|--------|-------------------------|---|
| Driver seat control unit Connector | Terminal | | | |
| B503 | 25 | Ground | Seat Lifting (front) |  10mSec/div 2V/div JMJA0119ZZ |
| | | | Operate | |

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-207. "Removal and Installation"](#).

NO >> GO TO 2.

2. CHECK LIFTING SENSOR (FRONT) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit and lifting motor (front) connector.
3. Check continuity between driver seat control unit harness connector and lifting motor (front) harness connector.

LIFTING SENSOR (FRONT)

< DTC/CIRCUIT DIAGNOSIS >

| Driver seat control unit | | Lifting motor (front) | | Continuity |
|--------------------------|----------|-----------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B503 | 25 | B527 | 25 | Existed |

4. Check continuity between driver seat control unit harness connector and ground.

| Driver seat control unit | | Ground | Continuity |
|--------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B503 | 25 | | Not existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3.CHECK LIFTING SENSOR (FRONT) POWER SUPPLY

1. Connect driver seat control unit connector.
2. Turn ignition switch ON.
3. Check voltage between lifting motor (front) harness connector and ground.

| (+) | | (-) | Voltage (V) (Approx.) |
|-----------------------|----------|--------|--------------------------|
| Lifting motor (front) | | | |
| Connector | Terminal | | |
| B527 | 16 | Ground | Battery voltage |

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

4.CHECK LIFTING SENSOR (FRONT) POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between driver seat control unit harness connector and lifting motor (front) harness connector.

| Driver seat control unit | | Lifting motor (front) | | Continuity |
|--------------------------|----------|-----------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B503 | 16 | B527 | 16 | Existed |

4. Check continuity between driver seat control unit harness connector and ground.

| Driver seat control unit | | Ground | Continuity |
|--------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B503 | 16 | | Not existed |

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-207, "Removal and Installation"](#).

NO >> Repair or replace harness.

5.CHECK LIFTING SENSOR (FRONT) GROUND CIRCUIT 1

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between driver seat control unit harness connector and lifting motor (front) harness connector.

| Driver seat control unit | | Lifting motor (front) | | Continuity |
|--------------------------|----------|-----------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B503 | 31 | B527 | 31 | Existed |

LIFTING SENSOR (FRONT)

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace harness.

6. CHECK LIFTING SENSOR (FRONT) GROUND CIRCUIT 2

1. Connect driver seat control unit connector.
2. Check continuity between lifting motor (front) harness connector and ground.

| Driver seat control unit | | Ground | Continuity |
|--------------------------|----------|--------|------------|
| Connector | Terminal | | |
| B503 | 31 | | Existed |

Is the inspection result normal?

YES >> Replace lifting motor (front). Refer to [SE-163. "Exploded View"](#).

NO >> Replace driver seat control unit. Refer to [ADP-207. "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

LIFTING SENSOR (REAR)

< DTC/CIRCUIT DIAGNOSIS >

LIFTING SENSOR (REAR)

Description

INFOID:000000008163679

- The lifting sensor (rear) is installed to the seat slide cushion frame.
- The pulse signal is input to the driver seat control unit when the lifting (rear) is operated.
- The driver seat control unit counts the pulse and calculates the lifting (rear) amount of the seat.

Component Function Check

INFOID:000000008163680

1. CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "LIFT RR PULSE" in the "Data monitor" mode using CONSULT.
3. Check lifting sensor (rear) signal under the following conditions.

| Monitor item | Condition | | Value |
|---------------|---------------------|----------------|---------------------------------|
| LIFT RR PULSE | Seat lifting (rear) | Operate (Up) | Change (increase) ^{*1} |
| | | Operate (Down) | Change (decrease) ^{*1} |
| | | Release | No change ^{*1} |

*1: The value at the seat position attained when the battery is connected is considered to be 32768.

Is the indication normal?

YES >> INSPECTION END


NO >> Perform diagnosis procedure. Refer to [ADP-110. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008163681

1. CHECK LIFTING SENSOR (REAR) SIGNAL

1. Turn ignition switch ON.
2. Check voltage signal between driver seat control unit harness connector and ground with oscilloscope.

| (+) Driver seat control unit | | (-) | Condition | Voltage (V) (Approx.) |
|------------------------------|----------|--------|---------------------|---|
| Connector | Terminal | | | |
| B503 | 10 | Ground | Seat Lifting (rear) |  <p>10mSec/div 2V/div JMJA0119ZZ</p> |
| | | | Other than above | |

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-207. "Removal and Installation"](#).

NO >> GO TO 2.

2. CHECK LIFTING SENSOR (REAR) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit and lifting motor (rear) connector.
3. Check the continuity between driver seat control unit harness connector and lifting motor (rear) harness connector.

LIFTING SENSOR (REAR)

< DTC/CIRCUIT DIAGNOSIS >

| Driver seat control unit | | Lifting motor (rear) | | Continuity |
|--------------------------|----------|----------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B503 | 10 | B529 | 10 | Existed |

4. Check the continuity between driver seat control unit harness connector and ground.

| Driver seat control unit | | Ground | Continuity |
|--------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B503 | 10 | | Not Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3.CHECK LIFTING SENSOR (REAR) POWER SUPPLY

1. Connect driver seat control unit connector.
2. Turn ignition switch ON.
3. Check the voltage between lifting motor (rear) harness connector and ground.

| (+) | | (-) | Voltage (V) (Approx.) |
|----------------------|----------|--------|--------------------------|
| Lifting motor (rear) | | | |
| Connector | Terminal | | |
| B529 | 16 | Ground | Battery voltage |

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

4.CHECK LIFTING SENSOR (REAR) POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check the continuity between driver seat control unit harness connector and lifting motor (rear) harness connector.

| Driver seat control unit | | Lifting motor (rear) | | Continuity |
|--------------------------|----------|----------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B503 | 16 | B529 | 16 | Existed |

4. Check the continuity between driver seat control unit harness connector and ground.

| Driver seat control unit | | Ground | Continuity |
|--------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B503 | 16 | | Not existed |

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-207, "Removal and Installation"](#).

NO >> Repair or replace harness.

5.CHECK LIFTING SENSOR (REAR) GROUND CIRCUIT 1

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check the continuity between driver seat control unit harness connector and lifting motor (rear) harness connector.

| Driver seat control unit | | Lifting motor (rear) | | Continuity |
|--------------------------|----------|----------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B503 | 31 | B529 | 31 | Existed |

LIFTING SENSOR (REAR)

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace harness.

6. CHECK LIFTING SENSOR (REAR) GROUND CIRCUIT 2

1. Connect driver seat control unit connector.
2. Check continuity between lifting motor (rear) harness connector and ground.

| Driver seat control unit | | Ground | Continuity |
|--------------------------|----------|--------|------------|
| Connector | Terminal | | |
| B503 | 31 | | Existed |

Is the inspection result normal?

YES >> Replace lifting motor (rear). Refer to [SE-163, "Exploded View"](#).

NO >> Replace driver seat control unit. Refer to [ADP-207, "Removal and Installation"](#).

TILT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

TILT SENSOR

Description

INFOID:000000008163682

- The tilt sensor is installed to the steering column assembly.
- The resistance of tilt sensor changes according to the up/down position of steering column.
- The terminal voltage of automatic drive positioner control unit changes according to a change of tilt sensor resistance. Automatic drive positioner control unit calculates the tilt position from the voltage.

Component Function Check

INFOID:000000008163683

1. CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "TILT SEN" in the "Data monitor" mode using CONSULT.
3. Check the tilt sensor signal under the following condition.

| Monitor item | Condition | Value |
|--------------|---------------|---|
| TILT SEN | Tilt position | Change between 1.1 V (Close to top) 3.9 V (Close to bottom) |

Is the indication normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-113, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008163684

1. CHECK TILT SENSOR SIGNAL

1. Turn ignition switch ON.
2. Check voltage automatic drive positioner control unit harness connector and ground.

| (+) | | (-) | Condition | Voltage (V) (Approx.) |
|--|----------|--------|---------------|---|
| Automatic drive positioner control unit Connector | Terminal | | | |
| M51 | 7 | Ground | Tilt position | Change between 1.1 V (Close to top) 3.9 V (Close to bottom) |

Is the inspection result normal?

YES >> Replace automatic drive positioner control unit. Refer to [ADP-208, "Removal and Installation"](#).

NO >> GO TO 2.

2. CHECK TILT SENSOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit and tilt & telescopic sensor connector.
3. Check continuity between automatic drive positioner control unit harness connector and tilt & telescopic sensor harness connector.

| Automatic drive positioner control unit | | Tilt & telescopic sensor | | Continuity |
|---|----------|--------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M51 | 7 | M48 | 3 | Existed |

4. Check continuity between automatic drive positioner control unit harness connector and ground.

| Automatic drive positioner control unit | | Ground | Continuity |
|---|----------|--------|-------------|
| Connector | Terminal | | |
| M51 | 7 | | Not existed |

Is the inspection result normal?

TILT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

- YES >> GO TO 3.
 NO >> Repair or replace harness.

3.CHECK TILT SENSOR POWER SUPPLY

1. Connect automatic drive positioner control unit connector.
2. Turn ignition switch ON.
3. Check voltage between tilt & telescopic sensor harness connector and ground.

| (+) | | (-) | Voltage (V) (Approx.) |
|--------------------------|----------|--------|--------------------------|
| Tilt & telescopic sensor | | | |
| Connector | Terminal | | |
| M48 | 1 | Ground | 5 |

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> GO TO 4.

4.CHECK TILT SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and tilt & telescopic sensor harness connector.

| Automatic drive positioner control unit | | Tilt & telescopic sensor | | Continuity |
|---|----------|--------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M52 | 33 | M48 | 1 | Existed |

4. Check continuity between automatic drive positioner control unit harness connector and ground.

| Automatic drive positioner control unit | | Ground | Continuity |
|---|----------|--------|-------------|
| Connector | Terminal | | |
| M52 | 33 | | Not existed |

Is the inspection result normal?

- YES >> Replace automatic drive positioner control unit. Refer to [ADP-208. "Removal and Installation"](#).
 NO >> Repair or replace harness.

5.CHECK TILT SENSOR GROUND CIRCUIT 1

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and tilt & telescopic sensor harness connector.

| Automatic drive positioner control unit | | Tilt & telescopic sensor | | Continuity |
|---|----------|--------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M52 | 41 | M48 | 4 | Existed |

Is the inspection result normal?

- YES >> GO TO 6.
 NO >> Repair or replace harness.

6.CHECK TILT SENSOR GROUND CIRCUIT 2

1. Connect automatic drive positioner control unit connector.
2. Check continuity between automatic drive positioner control unit harness connector and ground.

| Automatic drive positioner control unit | | Ground | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| M52 | 41 | | Existed |

TILT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES >> Replace tilt & telescopic sensor (Built in steering column assembly). Refer to [ST-18, "WITHOUT ELECTRIC MOTOR : Exploded View"](#).
- NO >> Replace automatic drive positioner control unit. Refer to [ADP-208, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

TELESCOPIC SENSOR

< DTC/CIRCUIT DIAGNOSIS >

TELESCOPIC SENSOR

Description

INFOID:000000008163685

- The telescopic sensor is installed to the steering column assembly.
- The resistance of telescopic sensor changes according to the forward/backward position of steering column.
- The terminal voltage of automatic drive positioner control unit changes according to a change of telescopic sensor resistance. Automatic drive positioner control unit calculates the telescopic position from the voltage.

Component Function Check

INFOID:000000008163686

1. CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "TELESCO SEN" in the "Data monitor" mode using CONSULT.
3. Check the tilt sensor signal under the following conditions.

| Monitor item | Condition | Value |
|--------------|---------------------|---|
| TELESCO SEN | Telescopic position | Change between 0.5 [V] (close to top) 4.5 [V] (close to bottom) |

Is the indication normal?

YES >> INSPECTION END.

NO >> Perform diagnosis procedure. Refer to [ADP-116, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008163687

1. CHECK TELESCOPIC SENSOR SIGNAL

1. Turn ignition switch ON.
2. Check voltage automatic drive positioner control unit harness connector and ground.

| (+) | | (-) | Condition | Voltage (V) (Approx.) |
|---|-----------|--------|---------------------|---|
| Automatic drive positioner control unit | Connector | | | |
| | Terminal | | | |
| M51 | 23 | Ground | Telescopic position | Change between 0.5 [V] (close to top) 4.5 [V] (close to bottom) |

Is the inspection result normal?

YES >> Replace automatic drive positioner control unit. Refer to [ADP-208, "Removal and Installation"](#).

NO >> GO TO 2.

2. CHECK TELESCOPIC SENSOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit and tilt & telescopic sensor connector.
3. Check continuity between automatic drive positioner control unit harness connector and tilt & telescopic sensor harness connector.

| Automatic drive positioner control unit | | Tilt & telescopic sensor | | Continuity |
|---|----------|--------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M51 | 23 | M48 | 2 | Existed |

4. Check continuity between automatic drive positioner control unit harness connector and ground.

| Automatic drive positioner control unit | | Ground | Continuity |
|---|----------|--------|-------------|
| Connector | Terminal | | |
| M51 | 23 | | Not existed |

Is the inspection result normal?

TELESCOPIC SENSOR

< DTC/CIRCUIT DIAGNOSIS >

- YES >> GO TO 3.
 NO >> Repair or replace harness.

3.CHECK TELESCOPIC SENSOR POWER SUPPLY

1. Connect automatic drive positioner control unit connector.
2. Turn ignition switch ON.
3. Check voltage between tilt & telescopic sensor harness connector and ground.

| (+) | | (-) | Voltage (V) (Approx.) |
|--------------------------|----------|--------|--------------------------|
| Tilt & telescopic sensor | | | |
| Connector | Terminal | | |
| M48 | 1 | Ground | 5 |

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> GO TO 4.

4.CHECK TELESCOPIC SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and tilt & telescopic sensor harness connector.

| Automatic drive positioner control unit | | Tilt & telescopic sensor | | Continuity |
|---|----------|--------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M52 | 33 | M48 | 1 | Existed |

4. Check continuity between automatic drive positioner control unit harness connector and ground.

| Automatic drive positioner control unit | | Ground | Continuity |
|---|----------|--------|-------------|
| Connector | Terminal | | |
| M52 | 33 | | Not existed |

Is the inspection result normal?

- YES >> Replace automatic drive positioner control unit. Refer to [ADP-208. "Removal and Installation"](#).
 NO >> Repair or replace harness.

5.CHECK TELESCOPIC SENSOR GROUND CIRCUIT 1

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and tilt & telescopic sensor harness connector.

| Automatic drive positioner control unit | | Tilt & telescopic sensor | | Continuity |
|---|----------|--------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M52 | 41 | M48 | 4 | Existed |

Is the inspection result normal?

- YES >> GO TO 6.
 NO >> Repair or replace harness.

6.CHECK TELESCOPIC SENSOR GROUND CIRCUIT 2

1. Connect automatic drive positioner control unit connector.
2. Check continuity between automatic drive control unit harness connector and ground.

| Automatic drive positioner control unit | | Ground | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| M52 | 41 | | Existed |

TELESCOPIC SENSOR

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES >> Replace tilt & telescopic sensor (Built in steering column assembly). Refer to [ST-18, "WITHOUT ELECTRIC MOTOR : Exploded View"](#).
- NO >> Replace automatic drive positioner control unit. Refer to [ADP-208, "Removal and Installation"](#).

MIRROR SENSOR

< DTC/CIRCUIT DIAGNOSIS >

MIRROR SENSOR

DRIVER SIDE

DRIVER SIDE : Description

INFOID:000000008163688

- The mirror sensor (driver side) is installed to the door mirror (driver side).
- The resistance of 2 sensors (horizontal and vertical) is changed when the door mirror (driver side) is operated.
- Automatic drive positioner control unit calculates the door mirror position according to the change of the voltage of 2 sensor input terminals.

DRIVER SIDE : Component Function Check

INFOID:000000008163689

1.CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "MIR/SEN LH U-D", "MIR/SEN LH R-L" in the "Data monitor" using CONSULT.
3. Check mirror sensor (driver side) signal under the following condition.

| Monitor item | Condition | Value |
|----------------|---------------------------|---|
| MIR/SEN LH U-D | Door mirror (driver side) | Change between 3.4 [V] (close to peak) 0.6 [V] (close to valley) |
| MIR/SEN LH R-L | | Change between 0.6 [V] (close to left edge) 3.4 [V] (close to right edge) |

Is the indication normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-119. "DRIVER SIDE : Diagnosis Procedure"](#).

DRIVER SIDE : Diagnosis Procedure

INFOID:000000008163690

1.CHECK DOOR MIRROR SENSOR (DRIVER SIDE) SIGNAL

1. Turn ignition switch ON.
2. Check voltage automatic drive positioner control unit harness connector and ground.

| (+) | | (-) | Condition | Voltage (V) (Approx.) |
|---|----------|--------|------------------------------------|---|
| Automatic drive positioner control unit | | | | |
| Connector | Terminal | | | |
| M51 | 6 | Ground | Door mirror (Driver side) position | Change between 3.4 [V] (close to peak) 0.6 [V] (close to valley) |
| | 22 | | | Change between 3.4 [V] (close to left edge) 0.6 [V] (close to right edge) |

Is the inspection result normal?

YES >> Replace automatic drive positioner control unit. Refer to [ADP-208. "Removal and Installation"](#).

NO >> GO TO 2.

2.CHECK DOOR MIRROR (DRIVER SIDE) SENSOR CIRCUIT

1. Turn ignition OFF.
2. Disconnect automatic drive positioner control unit connector and door mirror (drive side) connector.
3. Check continuity between automatic drive positioner control unit harness connector and door mirror (driver side) harness connector.

MIRROR SENSOR

< DTC/CIRCUIT DIAGNOSIS >

| Automatic drive positioner control unit | | Door mirror (driver side) | | Continuity |
|---|----------|---------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M51 | 6 | D3 | 9 | Existed |
| | 22 | | 10 | |

4. Check continuity between automatic drive positioner control unit harness connector and ground.

| Automatic drive positioner control unit | | Ground | Continuity |
|---|----------|--------|-------------|
| Connector | Terminal | | |
| M51 | 6 | | Not existed |
| | 22 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK DOOR MIRROR (DRIVER SIDE) SENSOR POWER SUPPLY

1. Connect automatic drive positioner control unit connector.
2. Turn ignition switch ON.
3. Check voltage between door mirror (driver side) harness connector and ground.

| (+) | | (-) | Voltage (V) (Approx.) |
|---------------------------|----------|--------|--------------------------|
| Door mirror (driver side) | | | |
| Connector | Terminal | | |
| D3 | 11 | Ground | 5 |

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

4. CHECK DOOR MIRROR (DRIVER SIDE) SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and door mirror (driver side) harness connector.

| Automatic drive positioner control unit | | Door mirror (driver side) | | Continuity |
|---|----------|---------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M52 | 33 | D3 | 11 | Existed |

4. Check continuity between automatic drive positioner control unit harness connector and ground.

| Automatic drive positioner control unit | | Ground | Continuity |
|---|----------|--------|-------------|
| Connector | Terminal | | |
| M52 | 33 | | Not existed |

Is the inspection result normal?

YES >> Replace automatic drive positioner control unit. Refer to [ADP-208. "Removal and Installation"](#).

NO >> Repair or replace harness.

5. CHECK DOOR MIRROR (DRIVER SIDE) SENSOR GROUND 1

1. Turn ignition switch OFF.
2. Disconnect automatic drive control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and door mirror (driver side) harness connector.

MIRROR SENSOR

< DTC/CIRCUIT DIAGNOSIS >

| Automatic drive positioner control unit | | Door mirror (driver side) | | Continuity |
|---|----------|---------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M52 | 41 | D3 | 12 | Existed |

Is the inspection result normal?

- YES >> GO TO 6.
 NO >> Repair or replace harness.

6. CHECK DOOR MIRROR (DRIVER SIDE) SENSOR GROUND 2

1. Connect automatic drive positioner control unit connector.
2. Check continuity between automatic drive positioner control unit harness connector and ground.

| Automatic drive positioner control unit | | Ground | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| M52 | 41 | | Existed |

Is the inspection result normal?

- YES >> Replace automatic drive positioner control unit. Refer to [ADP-208. "Removal and Installation"](#).
 NO >> Replace door mirror sensor (Built in passenger side door mirror). Refer to [MIR-36. "DOOR MIRROR ASSEMBLY : Removal and Installation"](#).

PASSENGER SIDE

PASSENGER SIDE : Description

INFOID:000000008163691

- The mirror sensor (passenger side) is installed to the door mirror (passenger side).
- The resistance of 2 sensors (horizontal and vertical) is changed when the door mirror (passenger side) is operated.
- Automatic drive positioner control unit calculates the door mirror position according to the change of the voltage of 2 sensor input terminals.

PASSENGER SIDE : Component Function Check

INFOID:000000008163692

ADP

1. CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "MIR/SEN RH U-D", "MIR/SEN RH R-L" in the "Data monitor" using CONSULT.
3. Check the mirror sensor (passenger side) signal under the following conditions.

| Monitor item | Condition | Value |
|----------------|------------------------------|---|
| MIR/SEN RH U-D | Door mirror (passenger side) | Change between 3.4 [V] (close to peak) 0.6 [V] (close to valley) |
| MIR/SEN RH R-L | | Change between 3.4 [V] (close to left edge) 0.6 [V] (close to right edge) |

Is the indication normal?

- YES >> INSPECTION END
 NO >> Perform diagnosis procedure. Refer to [ADP-121. "PASSENGER SIDE : Diagnosis Procedure"](#).

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000008163693

1. CHECK DOOR MIRROR SENSOR (PASSENGER SIDE) SIGNAL

1. Turn ignition switch ON.
2. Check voltage automatic drive positioner control unit harness connector and ground.

MIRROR SENSOR

< DTC/CIRCUIT DIAGNOSIS >

| (+) | | (-) | Condition | Voltage (V) (Approx.) |
|---|----------|--------|---------------------------------------|---|
| Automatic drive positioner control unit | | | | |
| Connector | Terminal | | | |
| M51 | 5 | Ground | Door mirror (Passenger side) position | Change between 3.4 [V] (close to peak) 0.6 [V] (close to valley) |
| | 21 | | | Change between 3.4 [V] (close to left edge) 0.6 [V] (close to right edge) |

Is the inspection result normal?

- YES >> Replace automatic drive positioner control unit. Refer to [ADP-208. "Removal and Installation"](#).
 NO >> GO TO 2.

2. CHECK DOOR MIRROR (PASSENGER SIDE) SENSOR CIRCUIT

- Turn ignition switch OFF.
- Disconnect automatic drive positioner control unit connector and door mirror (passenger side) connector.
- Check continuity between automatic drive positioner control unit harness connector and door mirror (passenger side) harness connector.

| Automatic drive positioner control unit | | Door mirror (passenger side) | | Continuity |
|---|----------|------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M51 | 5 | D33 | 9 | Existed |
| | 21 | | 10 | |

- Check continuity between automatic drive positioner control unit harness connector and ground.

| Automatic drive positioner control unit | | Ground | Continuity |
|---|----------|--------|-------------|
| Connector | Terminal | | |
| M51 | 5 | | Not existed |
| | 21 | | |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair or replace harness.

3. CHECK DOOR MIRROR SENSOR (PASSENGER SIDE) POWER SUPPLY

- Connect automatic drive positioner control unit connector.
- Turn ignition switch ON.
- Check voltage between door mirror (passenger side) harness connector and ground.

| (+) | | (-) | Voltage (V) (Approx.) |
|------------------------------|----------|--------|--------------------------|
| Door mirror (passenger side) | | | |
| Connector | Terminal | | |
| D33 | 11 | Ground | 5 |

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> GO TO 4.

4. CHECK DOOR MIRROR (PASSENGER SIDE) SENSOR POWER SUPPLY CIRCUIT

- Turn ignition switch OFF.
- Disconnect automatic drive positioner control unit connector.
- Check continuity between automatic drive positioner control unit harness connector and door mirror (passenger side) harness connector.

MIRROR SENSOR

< DTC/CIRCUIT DIAGNOSIS >

| Automatic drive positioner control unit | | Door mirror (passenger side) | | Continuity |
|---|----------|------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M52 | 33 | D33 | 11 | Existed |

4. Check continuity between automatic drive positioner control unit harness connector and ground.

| Automatic drive positioner control unit | | Ground | Continuity |
|---|----------|--------|-------------|
| Connector | Terminal | | |
| M52 | 33 | | Not existed |

Is the inspection result normal?

- YES >> Replace automatic driver positioner control unit. Refer to [ADP-208, "Removal and Installation"](#).
 NO >> Repair or replace harness.

5. CHECK DOOR MIRROR (PASSENGER SIDE) SENSOR GROUND 1

- Turn ignition switch OFF.
- Disconnect automatic drive positioner control unit connector.
- Check continuity between automatic drive positioner control unit harness connector and door mirror (passenger side) connector.

| Automatic drive positioner control unit | | Door mirror (passenger side) | | Continuity |
|---|----------|------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M52 | 41 | D33 | 12 | Existed |

Is the inspection result normal?

- YES >> GO TO 6.
 NO >> Repair or replace harness.

6. CHECK DOOR MIRROR (PASSENGER SIDE) SENSOR GROUND 2

- Connect automatic drive positioner control unit connector.
- Check continuity between automatic drive positioner control unit harness connector and ground.

| Automatic drive positioner control unit | | Ground | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| M52 | 41 | | Existed |

Is the inspection result normal?

- YES >> Replace automatic drive positioner control unit. Refer to [ADP-208, "Removal and Installation"](#).
 NO >> Replace door mirror sensor (Built in passenger side door mirror). Refer to [MIR-36, "DOOR MIRROR ASSEMBLY : Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

SLIDING MOTOR

< DTC/CIRCUIT DIAGNOSIS >

SLIDING MOTOR

Description

INFOID:000000008163694

- The seat sliding motor is installed to the seat cushion frame.
- The seat sliding motor is activated with the driver seat control unit.
- The seat is slid frontward/rearward by changing the rotation direction of sliding motor.

Component Function Check

INFOID:000000008163695

1. CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "SEAT SLIDE" in "Active test" mode using CONSULT.
3. Check the sliding motor operation.

| Test item | | Description | |
|------------|-----|--------------|----------|
| SEAT SLIDE | OFF | Seat sliding | Stop |
| | FR | | Forward |
| | RR | | Backward |

Is the operation of relevant parts normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-124, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008163696

1. CHECK SLIDING MOTOR POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect sliding motor connector.
3. Turn the ignition switch ON.
4. Perform "Active test" ("SEAT SLIDE") using CONSULT-III
5. Check voltage between sliding motor harness connector and ground.

| (+) | | (-) | Condition | Voltage (V) (Approx.) | |
|---------------|----------|--------|------------|--------------------------|-----------------|
| Sliding motor | | | | | |
| Connector | Terminal | | | | |
| B525 | 35 | Ground | SEAT SLIDE | OFF | 0 |
| | | | | FR (forward) | Battery voltage |
| | | | | RR (backward) | 0 |
| | 42 | | | OFF | 0 |
| | | | | FR (forward) | 0 |
| | | | | RR (backward) | Battery voltage |

Is the inspection result normal?

YES >> Replace sliding motor. (Built in seat slide cushion frame.) Refer to [SE-163, "Exploded View"](#).

NO >> GO TO 2.

2. CHECK SLIDING MOTOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between driver seat control unit harness connector and sliding motor harness connector.

SLIDING MOTOR

< DTC/CIRCUIT DIAGNOSIS >

| Driver seat control unit | | Sliding motor | | Continuity |
|--------------------------|----------|---------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B504 | 35 | B525 | 35 | Existed |
| | 42 | | 42 | |

4. Check continuity between driver seat control unit harness connector and ground.

| Driver seat control unit | | Ground | Continuity |
|--------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B504 | 35 | | Not existed |
| | 42 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3.CHECK SLIDING MOTOR

Refer to [ADP-125. "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-207. "Removal and Installation"](#).

NO >> Replace sliding motor. (Built in seat slide cushion frame.) Refer to [SE-163. "Exploded View"](#).

Component Inspection

INFOID:000000008163697

1.CHECK SLIDING MOTOR-1

Visually check the sliding motor for foreign object, and check that the sliding motor is not broken.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace seat cushion frame (sliding motor).

2.CHECK SLIDING MOTOR-2

1. Turn ignition switch OFF.
2. Disconnect sliding motor connector.
3. Supply sliding motor terminals with battery voltage and check operation.

| Terminal | | Operation |
|----------|-----|-----------|
| (+) | (-) | |
| 35 | 42 | Forward |
| 42 | 35 | Backward |

Is the inspection result normal?

YES >> Sliding motor is OK.

NO >> Replace sliding motor. (Built in seat slide cushion frame.) Refer to [SE-163. "Exploded View"](#).

RECLINING MOTOR

< DTC/CIRCUIT DIAGNOSIS >

RECLINING MOTOR

Description

INFOID:000000008163698

- The seat reclining motor is installed to the seat back frame.
- The seat reclining motor is activated with the driver seat control unit.
- The seatback is reclined frontward/rearward by changing the rotation direction of reclining motor.

Component Function Check

INFOID:000000008163699

1. CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "SEAT RECLINING" in "Active test" mode using CONSULT.
3. Check the reclining motor operation.

| Test item | | Description | |
|----------------|-----|----------------|----------|
| SEAT RECLINING | OFF | Seat reclining | Stop |
| | FR | | Forward |
| | RR | | Backward |

Is the operation of relevant parts normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-126, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008163700

1. CHECK RECLINING MOTOR POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect reclining motor connector.
3. Turn the ignition switch ON.
4. Perform "Active test" ("SEAT RECLINING") using CONSULT
5. Check voltage between reclining motor harness connector and ground.

| (+) | | (-) | Condition | Voltage (V) (Approx.) | |
|-----------------|----------|--------|----------------|--------------------------|-----------------|
| Reclining motor | | | | | |
| Connector | Terminal | | | | |
| B523 | 36 | Ground | SEAT RECLINING | OFF | 0 |
| | | | | FR (forward) | Battery voltage |
| | | | | RR (backward) | 0 |
| | 44 | | | OFF | 0 |
| | | | | FR (forward) | 0 |
| | | | | RR (backward) | Battery voltage |

Is the inspection result normal?

YES >> Replace reclining motor. (Built in seat back frame.) Refer to [SE-163, "Exploded View"](#).

NO >> GO TO 2.

2. CHECK RECLINING MOTOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between driver seat control unit harness connector and reclining motor harness connector.

RECLINING MOTOR

< DTC/CIRCUIT DIAGNOSIS >

| Driver seat control unit | | Reclining motor | | Continuity |
|--------------------------|----------|-----------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B504 | 36 | B523 | 36 | Existed |
| | 44 | | 44 | |

4. Check continuity between driver seat control unit harness connector and ground.

| Driver seat control unit | | Ground | Continuity |
|--------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B504 | 36 | | Not existed |
| | 44 | | |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace harness.

3.CHECK RECLINING MOTOR

Refer to [ADP-127. "Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace driver seat control unit. Refer to [ADP-207. "Removal and Installation"](#).
NO >> Replace reclining motor. (Built in seat slide cushion frame.) Refer to [SE-163. "Exploded View"](#).

Component Inspection

INFOID:000000008163701

1.CHECK RECLINING MOTOR-1

Visually check the reclining motor for foreign object, and check that the reclining motor is not broken.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace seatback frame (reclining motor).

2.CHECK RECLINING MOTOR-2

1. Turn ignition switch OFF.
2. Disconnect reclining motor connector.
3. Supply reclining motor terminals with battery voltage and check operation.

| Terminal | | Operation |
|----------|-----|-----------|
| (+) | (-) | |
| 36 | 44 | Forward |
| 44 | 36 | Backward |

Is the inspection result normal?

- YES >> Reclining motor is OK.
NO >> Replace reclining motor. (Built in seat slide cushion frame.) Refer to [SE-163. "Exploded View"](#).

LIFTING MOTOR (FRONT)

< DTC/CIRCUIT DIAGNOSIS >

LIFTING MOTOR (FRONT)

Description

INFOID:000000008163702

- The lifting motor (front) is installed to the seat slide cushion frame.
- The lifting motor (front) is activated with the driver seat control unit.
- The lifter (front) is moved upward/downward by changing the rotation direction of lifting motor (front).

Component Function Check

INFOID:000000008163703

1. CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "SEAT LIFTER FR" in "Active test" mode using CONSULT.
3. Check the lifting motor (front) operation.

| Test item | | Description | |
|----------------|-----|----------------------|----------|
| SEAT LIFTER FR | OFF | Seat lifting (front) | Stop |
| | UP | | Upward |
| | DWN | | Downward |

Is the operation of relevant parts normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-128, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008163704

1. CHECK LIFTING MOTOR (FRONT) POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect lifting motor (front) connector.
3. Turn the ignition switch ON.
4. Perform "Active test" ("SEAT LIFTER FR") using CONSULT.
5. Check voltage between lifting motor (front) harness connector and ground.

| (+) | | (-) | Condition | Voltage (V) (Approx.) | |
|-----------------------|----------|--------|----------------|--------------------------|-----------------|
| Lifting motor (front) | | | | | |
| Connector | Terminal | | | | |
| B527 | 37 | Ground | SEAT LIFTER FR | OFF | 0 |
| | | | | UP | 0 |
| | | | | DWN (down) | Battery voltage |
| | 45 | | | OFF | 0 |
| | | | | UP | Battery voltage |
| | | | | DWN (down) | 0 |

Is the inspection result normal?

YES >> Replace lifting motor (front). (Built in seat slide cushion frame.) Refer to [SE-163, "Exploded View"](#).

NO >> GO TO 2.

2. CHECK LIFTING MOTOR (FRONT) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between driver seat control unit harness connector and lifting motor (front) harness connector.

LIFTING MOTOR (FRONT)

< DTC/CIRCUIT DIAGNOSIS >

| Driver seat control unit | | Lifting motor (front) | | Continuity |
|--------------------------|----------|-----------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B504 | 37 | B527 | 37 | Existed |
| | 45 | | 45 | |

4. Check continuity between driver seat control unit harness connector and ground.

| Driver seat control unit | | Ground | Continuity |
|--------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B504 | 37 | | Not existed |
| | 45 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3.CHECK LIFTING MOTOR (FRONT)

Refer to [ADP-129. "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-207. "Removal and Installation"](#).

NO >> Replace lifting motor (front). (Built in seat slide cushion frame.) Refer to [SE-163. "Exploded View"](#).

Component Inspection

INFOID:000000008163705

1.CHECK LIFTING MOTOR-1

Visually the lifting motor (front) for foreign object, and check that the lifting motor (front) is not broken.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace seat cushion frame (lifting motor).

2.CHECK LIFTING MOTOR-2

1. Turn ignition switch OFF.
2. Disconnect lifting motor connector.
3. Supply lifting motor terminals with battery voltage and check operation.

| Item | Terminal | | Operation |
|-----------------------|----------|-----|-----------|
| | (+) | (-) | |
| Lifting motor (front) | 45 | 37 | Up |
| | 37 | 45 | Down |

Is the inspection result normal?

YES >> Lifting motor (front) is OK.

NO >> Replace lifting motor (front). (Built in seat slide cushion frame.) Refer to [SE-163. "Exploded View"](#).

LIFTING MOTOR (REAR)

< DTC/CIRCUIT DIAGNOSIS >

LIFTING MOTOR (REAR)

Description

INFOID:000000008163706

- The lifting motor (rear) is installed to the seat slide cushion frame.
- The lifting motor (rear) is activated with the driver seat control unit.
- The seat lifter (rear) is moved upward/downward by changing the rotation direction of lifting motor (rear).

Component Function Check

INFOID:000000008163707

1. CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "SEAT LIFTER RR" in "Active test" mode using CONSULT.
3. Check the lifting motor (rear) operation.

| Test item | | Description | |
|----------------|-----|---------------------|----------|
| SEAT LIFTER RR | OFF | Seat lifting (rear) | Stop |
| | UP | | Upward |
| | DWN | | Downward |

Is the operation of relevant parts normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-130, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008163708

1. CHECK LIFTING MOTOR (REAR) POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect lifting motor (rear) connector.
3. Turn the ignition switch ON.
4. Perform "Active test" ("SEAT LIFTER RR") using CONSULT
5. Check voltage between lifting motor (rear) harness connector and ground.

| (+) | | (-) | Condition | Voltage (V) (Approx.) | |
|----------------------|------------|--------|----------------|--------------------------|-----------------|
| Lifting motor (rear) | | | | | |
| Connector | Terminal | | | | |
| B529 | 38 | Ground | SEAT LIFTER RR | OFF | 0 |
| | | | | UP | Battery voltage |
| | DWN (DOWN) | | | 0 | |
| | OFF | | | 0 | |
| | UP | | | 0 | |
| | 39 | | | DWN (DOWN) | Battery voltage |

Is the inspection result normal?

YES >> Replace lifting motor (rear). (Built in seat slide cushion frame.) Refer to [SE-163, "Exploded View"](#).

NO >> GO TO 2.

2. CHECK LIFTING MOTOR (REAR) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector and lifting motor (rear) connector.
3. Check continuity between driver seat control unit harness connector and lifting motor (rear) harness connector.

LIFTING MOTOR (REAR)

< DTC/CIRCUIT DIAGNOSIS >

| Driver seat control unit | | Lifting motor (rear) | | Continuity |
|--------------------------|----------|----------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B504 | 38 | B529 | 38 | Existed |
| | 39 | | 39 | |

4. Check continuity between driver seat control unit harness connector and ground.

| Driver seat control unit | | Ground | Continuity |
|--------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B504 | 38 | | Not existed |
| | 39 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3.CHECK LIFTING MOTOR (REAR)

Refer to [ADP-131. "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-207. "Removal and Installation"](#).

NO >> Replace lifting motor (rear). (Built in seat slide cushion frame.) Refer to [SE-163. "Exploded View"](#).

Component Inspection

INFOID:000000008163709

1.CHECK LIFTING MOTOR-1

Visually the lifting motor (rear) for foreign object, and check that the lifting motor (rear) is not broken.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace seat cushion frame (lifting motor).

2.CHECK LIFTING MOTOR-2

1. Turn ignition switch OFF.
2. Disconnect lifting motor connector.
3. Supply lifting motor terminals with battery voltage and check operation.

| Item | Terminal | | Operation |
|----------------------|----------|-----|-----------|
| | (+) | (-) | |
| Lifting motor (rear) | 38 | 39 | Up |
| | 39 | 38 | Down |

Is the inspection result normal?

YES >> Lifting motor (rear) is OK.

NO >> Replace lifting motor (rear). (Built in seat slide cushion frame.) Refer to [SE-163. "Exploded View"](#).

TILT MOTOR

< DTC/CIRCUIT DIAGNOSIS >

TILT MOTOR

Description

INFOID:000000008163710

- The tilt motor is installed to the steering column assembly.
- The tilt motor is activated with the automatic drive positioner control unit.
- The steering column is tilted upward/downward by changing the rotation direction of tilt motor.

Component Function Check

INFOID:000000008163711

1.CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "TILT MOTOR" in "Active test" mode using CONSULT.
3. Check the tilt motor operation.

| Test item | | Description | |
|------------|-----|---------------|----------|
| TILT MOTOR | OFF | Steering tilt | Stop |
| | UP | | Upward |
| | DWN | | Downward |

Is the operation of relevant parts normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-132, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008163712

1.CHECK TILT MOTOR POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect tilt & telescopic motor connector.
3. Turn ignition switch ON.
4. Perform "Active test" ("TILT MOTOR") using CONSULT.
5. Check voltage between tilt & telescopic motor harness connector and ground.

| (+) | | (-) | Condition | Voltage (V) (Approx.) | |
|-----------|----------|--------|------------|--------------------------|---|
| Connector | Terminal | | | | |
| M49 | 3 | Ground | TILT MOTOR | OFF | 0 |
| | | | UP | 0 | |
| | | | DWN (down) | Battery voltage | |
| | 4 | | TILT MOTOR | OFF | 0 |
| | | | UP | Battery voltage | |
| | | | DWN (down) | 0 | |

Is the inspection result normal?

YES >> Replace tilt motor. (Built in steering column assembly.) Refer to [ST-21, "WITH ELECTRIC MOTOR : Exploded View"](#).

NO >> GO TO 2.

2.CHECK TILT MOTOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and tilt & telescopic motor harness connector.

TILT MOTOR

< DTC/CIRCUIT DIAGNOSIS >

| Automatic drive positioner control unit | | Tilt & telescopic motor | | Continuity |
|---|----------|-------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M52 | 35 | M49 | 4 | Existed |
| | 42 | | 3 | |

4. Check continuity between automatic drive positioner control unit harness connector and ground.

| Automatic drive positioner control unit | | Ground | Continuity |
|---|----------|--------|-------------|
| Connector | Terminal | | |
| M52 | 35 | | Not existed |
| | 42 | | |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair or replace harness.

3.CHECK TILT MOTOR

Refer to [ADP-133, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace automatic drive positioner control unit. Refer to [ADP-208, "Removal and Installation"](#).
 NO >> Replace tilt motor. (Built in steering column assembly.) Refer to [ST-21, "WITH ELECTRIC MOTOR : Exploded View"](#).

Component Inspection

INFOID:000000008163713

1.CHECK SLIDING MOTOR

- Turn ignition switch OFF.
- Disconnect tilt motor connector.
- Supply tilt motor terminals with battery voltage and check operation.

| Terminal | | Operation |
|----------|-----|-----------|
| (+) | (-) | |
| 4 | 3 | Up |
| 3 | 4 | Down |

Is the inspection result normal?

- YES >> Tilt motor is OK.
 NO >> Replace tilt motor. (Built in steering column assembly.) Refer to [ST-21, "WITH ELECTRIC MOTOR : Exploded View"](#).

ADP

TELESCOPIC MOTOR

< DTC/CIRCUIT DIAGNOSIS >

TELESCOPIC MOTOR

Description

INFOID:000000008163714

- The telescopic motor is installed to the steering column assembly.
- The telescopic motor is activated with the automatic drive positioner control unit.
- Compresses the steering column by changing the rotation direction of telescopic motor.

Component Function Check

INFOID:000000008163715

1. CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "TELESCO MOTOR" in "Active test" mode using CONSULT.
3. Check the telescopic motor operation.

| Test item | | Description | |
|---------------|-----|---------------------|----------|
| TELESCO MOTOR | OFF | Steering telescopic | Stop |
| | FR | | Forward |
| | RR | | Backward |

Is the operation of relevant parts normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-134, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008163716

1. CHECK TELESCOPIC MOTOR POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect tilt & telescopic motor connector.
3. Turn ignition switch ON.
4. Perform "Active test" ("TELESCO MOTOR") using CONSULT
5. Check voltage between tilt & telescopic motor harness connector and ground.

| (+) | | (-) | Condition | Voltage (V) (Approx.) | |
|-----------|----------|--------|------------------|--------------------------|---|
| Connector | Terminal | | | | |
| M49 | 1 | Ground | TELESCOPIC MOTOR | OFF | 0 |
| | | | FR (forward) | 0 | |
| | | | RR (backward) | Battery voltage | |
| | 2 | | OFF | 0 | |
| | | | FR (forward) | Battery voltage | |
| | | | RR (backward) | 0 | |

Is the inspection result normal?

YES >> Replace telescopic motor. (Built in steering column assembly.) Refer to [ST-21, "WITH ELECTRIC MOTOR : Exploded View"](#).

NO >> GO TO 2.

2. CHECK TELESCOPIC MOTOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and tilt & telescopic motor harness connector.

TELESCOPIC MOTOR

< DTC/CIRCUIT DIAGNOSIS >

| Automatic drive positioner control unit | | Tilt & telescopic motor | | Continuity |
|---|----------|-------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M52 | 36 | M49 | 2 | Existed |
| | 44 | | 1 | |

4. Check continuity between automatic drive positioner control unit harness connector and ground.

| Automatic drive positioner control unit | | Ground | Continuity |
|---|----------|--------|-------------|
| Connector | Terminal | | |
| M52 | 36 | | Not existed |
| | 44 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK SLIDING MOTOR

Refer to [ADP-135, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace automatic drive positioner control unit. Refer to [ADP-208, "Removal and Installation"](#).

NO >> Replace telescopic motor. (Built in steering column assembly.) Refer to [ST-21, "WITH ELECTRIC MOTOR : Exploded View"](#).

Component Inspection

INFOID:000000008163717

1. CHECK SLIDING MOTOR-2

- Turn ignition switch OFF.
- Disconnect telescopic motor connector.
- Supply telescopic motor terminals with battery voltage and check operation.

| Terminal | | Operation |
|----------|-----|-----------|
| (+) | (-) | |
| 2 | 1 | Forward |
| 1 | 2 | Backward |

Is the inspection result normal?

YES >> Telescopic motor is OK.

NO >> Replace telescopic motor. (Built in steering column assembly.) Refer to [ST-21, "WITH ELECTRIC MOTOR : Exploded View"](#).

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

DOOR MIRROR MOTOR

< DTC/CIRCUIT DIAGNOSIS >

DOOR MIRROR MOTOR

Description

INFOID:000000008163718

It makes mirror face operate from side to side and up and down with the electric power that automatic drive positioner control unit supplies.

Component Function Check

INFOID:000000008163719

1. CHECK DOOR MIRROR MOTOR FUNCTION

1. Turn ignition switch ON.
2. Select "DOOR MIRROR MOTOR LH" and "DOOR MIRROR MOTOR RH" in "Active test" mode using CONSULT.
3. Check the door mirror motor operation.

| Test item | | Description | |
|----------------------|-----|------------------|----------|
| DOOR MIRROR MOTOR LH | OFF | Door mirror face | Stop |
| | L | | Outward |
| | R | | Inward |
| | UP | | Upward |
| | DWN | | Downward |

| Test item | | Description | |
|----------------------|-----|------------------|----------|
| DOOR MIRROR MOTOR RH | OFF | Door mirror face | Stop |
| | L | | Inward |
| | R | | Outward |
| | UP | | Upward |
| | DWN | | Downward |

Is the operation of relevant parts normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-136. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008163720

1. CHECK DOOR MIRROR MOTOR INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect door mirror connector.
3. Turn ignition switch ON.
4. Check voltage between door mirror connector and ground.

| (+) | | (-) | Condition | Voltage (V) (Approx.) | |
|--|----------|--------|-----------------------------------|--------------------------|-----------------|
| Door mirror | | | | | |
| Connector | Terminal | | | | |
| D3 (Driver side) D33 (Passenger side) | 5 | Ground | Door mirror remote control switch | UP | Battery voltage |
| | | | | Other than above | 0 |
| | 6 | | | LEFT | Battery voltage |
| | | | | Other than above | 0 |
| | 7 | | | DOWN / RIGHT | Battery voltage |
| | | | | Other than above | 0 |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

DOOR MIRROR MOTOR

< DTC/CIRCUIT DIAGNOSIS >

2.CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit connector and door mirror connector.

[Door mirror driver side]

| Automatic drive positioner control unit | | Door mirror (driver side) | | Continuity |
|---|----------|---------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M51 | 16 | D3 | 7 | Existed |
| | 31 | | 5 | |
| | 32 | | 6 | |

[Door mirror passenger side]

| Automatic drive positioner control unit | | Door mirror (passenger side) | | Continuity |
|---|----------|------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M51 | 14 | D33 | 5 | Existed |
| | 15 | | 6 | |
| | 30 | | 7 | |

4. Check continuity between automatic drive positioner control unit connector and ground.

[Door mirror driver side]

| Automatic drive positioner control unit | | Ground | Continuity |
|---|----------|--------|-------------|
| Connector | Terminal | | |
| M51 | 16 | Ground | Not existed |
| | 31 | | |
| | 32 | | |

[Door mirror passenger side]

| Automatic drive positioner control unit | | Ground | Continuity |
|---|----------|--------|-------------|
| Connector | Terminal | | |
| M51 | 14 | Ground | Not existed |
| | 15 | | |
| | 30 | | |

Is the inspection result normal?

- YES >> Replace automatic drive positioner control unit. Refer to [ADP-208, "Removal and Installation"](#).
NO >> Repair or replace harness.

3.CHECK DOOR MIRROR MOTOR

Check door mirror motor.

Refer to [ADP-137, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Replace door mirror. Refer to [MIR-36, "DOOR MIRROR ASSEMBLY : Removal and Installation"](#).

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-43, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000008163721

1.CHECK DOOR MIRROR MOTOR-I

Check that door mirror motor does not trap foreign objects and does not have any damage.

Refer to [MIR-35, "DOOR MIRROR ASSEMBLY : Exploded View"](#).

DOOR MIRROR MOTOR

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace door mirror. Refer to [MIR-36, "DOOR MIRROR ASSEMBLY : Removal and Installation"](#).

2. CHECK DOOR MIRROR MOTOR-II

1. Turn ignition switch OFF.
2. Disconnect door mirror connector.
3. Apply 12V to each power supply terminal of door mirror motor.

| Door mirror | | | Operational direction |
|--|----------|-----|-----------------------|
| Connector | Terminal | | |
| | (+) | (-) | |
| D3 (Driver side) D33 (Passenger side) | 7 | 6 | RIGHT |
| | 6 | 7 | LEFT |
| | 5 | 7 | UP |
| | 7 | 5 | DOWN |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace door mirror. Refer to [MIR-36, "DOOR MIRROR ASSEMBLY : Removal and Installation"](#).

SEAT MEMORY INDICATOR

< DTC/CIRCUIT DIAGNOSIS >

SEAT MEMORY INDICATOR

Description

INFOID:000000008163722

- Memory indicator is equipped on the seat memory switch installed to the driver side door trim. The operation signal is inputted to the automatic drive positioner control unit when the memory switch is operated.
- The status of automatic drive positioner system can be checked according to the illuminating/flashing status.

Component Function Check

INFOID:000000008163723

1.CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "MEMORY SW INDCTR" in "Active test" mode using CONSULT.
3. Check the memory indicator operation.

| Test item | | Description | |
|------------------|------|-------------------------|-----------------|
| MEMORY SW INDCTR | OFF | Memory switch indicator | OFF |
| | ON-1 | | Indicator 1: ON |
| | ON-2 | | Indicator 2: ON |

Is the operation of relevant parts normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-139, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008163724

1.CHECK MEMORY INDICATOR POWER SUPPLY

Check voltage between seat memory switch harness connector and ground.

| (+) | | (-) | Voltage (V) (Approx.) |
|--------------------|----------|--------|--------------------------|
| Seat memory switch | | | |
| Connector | Terminal | Ground | Battery voltage |
| D5 | 5 | | |

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check the following.

- 10A fuse [No.10 located in fuse block (J/B)].
- Harness for open or short between memory indicator and fuse.

2.CHECK MEMORY INDICATOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit and seat memory switch connector.
3. Check continuity between automatic drive positioner control unit harness connector and seat memory switch harness connector.

| Automatic drive positioner control unit | | Seat memory switch | | Continuity |
|---|----------|--------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M51 | 12 | D5 | 6 | Existed |
| | 13 | | 7 | |

4. Check continuity between automatic drive positioner control unit harness connector and ground.

| Automatic drive positioner control unit | | Ground | Continuity |
|---|----------|--------|-------------|
| Connector | Terminal | | |
| M51 | 12 | | Not existed |
| | 13 | | |

SEAT MEMORY INDICATOR

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES >> Replace seat memory switch. Refer to [ADP-209, "Removal and Installation"](#).
- NO >> Repair or replace harness.

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION

BCM (BODY CONTROL MODULE)

Reference Value

INFOID:000000008788109

VALUES ON THE DIAGNOSIS TOOL

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

CONSULT MONITOR ITEM

| Monitor Item | Condition | Value/Status |
|----------------|---|----------------------------|
| FR WIPER HI | Other than front wiper switch HI | Off |
| | Front wiper switch HI | On |
| FR WIPER LOW | Other than front wiper switch LO | Off |
| | Front wiper switch LO | On |
| FR WASHER SW | Front washer switch OFF | Off |
| | Front washer switch ON | On |
| FR WIPER INT | Other than front wiper switch INT/AUTO | Off |
| | Front wiper switch INT/AUTO | On |
| FR WIPER STOP | Front wiper is not in STOP position | Off |
| | Front wiper is in STOP position | On |
| INT VOLUME | Wiper volume dial is in a dial position 1 - 7 | Wiper volume dial position |
| TURN SIGNAL R | Other than turn signal switch RH | Off |
| | Turn signal switch RH | On |
| TURN SIGNAL L | Other than turn signal switch LH | Off |
| | Turn signal switch LH | On |
| TAIL LAMP SW | Other than lighting switch 1ST and 2ND | Off |
| | Lighting switch 1ST or 2ND | On |
| HI BEAM SW | Other than lighting switch HI | Off |
| | Lighting switch HI | On |
| HEAD LAMP SW 1 | Other than lighting switch 2ND | Off |
| | Lighting switch 2ND | On |
| HEAD LAMP SW 2 | Other than lighting switch 2ND | Off |
| | Lighting switch 2ND | On |
| PASSING SW | Other than lighting switch PASS | Off |
| | Lighting switch PASS | On |
| AUTO LIGHT SW | Other than lighting switch AUTO | Off |
| | Lighting switch AUTO | On |
| FR FOG SW | Front fog lamp switch OFF | Off |
| | Front fog lamp switch ON | On |
| RR FOG SW | NOTE: The item is indicated, but not monitored. | Off |
| DOOR SW-DR | Driver door closed | Off |
| | Driver door opened | On |
| DOOR SW-AS | Passenger door closed | Off |
| | Passenger door opened | On |

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Monitor Item | Condition | Value/Status |
|----------------|--|--------------|
| DOOR SW-RR | NOTE: The item is indicated, but not monitored. | Off |
| DOOR SW-RL | NOTE: The item is indicated, but not monitored. | Off |
| DOOR SW-BK | NOTE: The item is indicated, but not monitored. | Off |
| CDL LOCK SW | Other than power door lock switch LOCK | Off |
| | Power door lock switch LOCK | On |
| CDL UNLOCK SW | Other than power door lock switch UNLOCK | Off |
| | Power door lock switch UNLOCK | On |
| KEY CYL LK-SW | Other than driver door key cylinder LOCK position | Off |
| | Driver door key cylinder LOCK position | On |
| KEY CYL UN-SW | Other than driver door key cylinder UNLOCK position | Off |
| | Driver door key cylinder UNLOCK position | On |
| KEY CYL SW-TR | NOTE: The item is indicated, but not monitored. | Off |
| HAZARD SW | Hazard switch is OFF | Off |
| | Hazard switch is ON | On |
| REAR DEF SW | NOTE: The item is indicated, but not monitored. | Off |
| TR CANCEL SW | Trunk lid opener cancel switch OFF | Off |
| | Trunk lid opener cancel switch ON | On |
| TR/BD OPEN SW | Trunk lid opener switch OFF | Off |
| | While the trunk lid opener switch is turned ON | On |
| TRNK/HAT MNTR | Trunk lid closed | Off |
| | Trunk lid opened | On |
| REVERSE SW | NOTE: The item is indicated, but not monitored. | Off |
| RKE-LOCK | LOCK button of the Intelligent Key is not pressed | Off |
| | LOCK button of the Intelligent Key is pressed | On |
| RKE-UNLOCK | UNLOCK button of the Intelligent Key is not pressed | Off |
| | UNLOCK button of the Intelligent Key is pressed | On |
| RKE-TR/BD | TRUNK OPEN button of the Intelligent Key is not pressed | Off |
| | TRUNK OPEN button of the Intelligent Key is pressed | On |
| RKE-PANIC | PANIC button of the Intelligent Key is not pressed | Off |
| | PANIC button of the Intelligent Key is pressed | On |
| RKE-P/W OPEN | UNLOCK button of the Intelligent Key is not pressed | Off |
| | UNLOCK button of the Intelligent Key is pressed and held | On |
| RKE-MODE CHG | LOCK/UNLOCK button of the Intelligent Key is not pressed and held simultaneously | Off |
| | LOCK/UNLOCK button of the Intelligent Key is pressed and held simultaneously | On |
| OPTICAL SENSOR | Bright outside of the vehicle | Close to 5 V |
| | Dark outside of the vehicle | Close to 0 V |
| REQ SW -DR | Driver door request switch is not pressed | Off |
| | Driver door request switch is pressed | On |
| REQ SW -AS | Passenger door request switch is not pressed | Off |
| | Passenger door request switch is pressed | On |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Monitor Item | Condition | Value/Status | |
|---------------|---|--------------|-----|
| REQ SW -RR | NOTE: The item is indicated, but not monitored. | Off | A |
| REQ SW -RL | NOTE: The item is indicated, but not monitored. | Off | B |
| REQ SW -BD/TR | Trunk lid opener request switch is not pressed | Off | C |
| | Trunk lid opener request switch is pressed | On | |
| PUSH SW | Push-button ignition switch (push switch) is not pressed | Off | D |
| | Push-button ignition switch (push switch) is pressed | On | |
| IGN RLY2 -F/B | NOTE: The item is indicated, but not monitored. | Off | D |
| ACC RLY -F/B | NOTE: The item is indicated, but not monitored. | Off | E |
| CLUCH SW | The clutch pedal is not depressed | Off | E |
| | The clutch pedal is depressed | On | |
| BRAKE SW 1 | The brake pedal is depressed when No. 7 fuse is blown | Off | F |
| | The brake pedal is not depressed when No. 7 fuse is blown, or No. 7 fuse is normal | On | |
| BRAKE SW 2 | The brake pedal is not depressed | Off | G |
| | The brake pedal is depressed | On | |
| DETE/CANCL SW | <ul style="list-style-type: none"> • Selector lever in P position (Except M/T models) • The clutch pedal is depressed (M/T models) | Off | H |
| | <ul style="list-style-type: none"> • Selector lever in any position other than P (Except M/T models) • The clutch pedal is not depressed (M/T models) | On | |
| SFT PN/N SW | Selector lever in any position other than P and N | Off | I |
| | Selector lever in P or N position | On | |
| S/L -LOCK | NOTE: The item is indicated, but not monitored. | Off | ADP |
| S/L -UNLOCK | NOTE: The item is indicated, but not monitored. | Off | K |
| S/L RELAY-F/B | NOTE: The item is indicated, but not monitored. | Off | |
| UNLK SEN -DR | Driver door is unlocked | Off | L |
| | Driver door is locked | On | |
| PUSH SW -IPDM | Push-button ignition switch (push-switch) is not pressed | Off | M |
| | Push-button ignition switch (push-switch) is pressed | On | |
| IGN RLY1 -F/B | Ignition switch in OFF or ACC position | Off | N |
| | Ignition switch in ON position | On | |
| DETE SW -IPDM | Selector lever in any position other than P | Off | O |
| | Selector lever in P position | On | |
| SFT PN -IPDM | <ul style="list-style-type: none"> • Selector lever in any position other than P and N (Except M/T models) • The clutch pedal is not depressed (M/T models) | Off | P |
| | <ul style="list-style-type: none"> • Selector lever in P or N position • The clutch pedal is depressed | On | |
| SFT P -MET | Selector lever in any position other than P | Off | |
| | Selector lever in P position | On | |
| SFT N -MET | Selector lever in any position other than N | Off | |
| | Selector lever in N position | On | |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Monitor Item | Condition | Value/Status |
|----------------|--|--|
| ENGINE STATE | Engine stopped | Stop |
| | While the engine stalls | Stall |
| | At engine cranking | Crank |
| | Engine running | Run |
| S/L LOCK-IPDM | NOTE: The item is indicated, but not monitored. | Off |
| S/L UNLK-IPDM | NOTE: The item is indicated, but not monitored. | Off |
| S/L RELAY-REQ | NOTE: The item is indicated, but not monitored. | Off |
| VEH SPEED 1 | While driving | Equivalent to speedometer reading |
| VEH SPEED 2 | While driving | Equivalent to speedometer reading |
| DOOR STAT-DR | Driver door is locked | LOCK |
| | Wait with selective UNLOCK operation (60 seconds) | READY |
| | Driver door is unlocked | UNLOCK |
| DOOR STAT-AS | Passenger door is locked | LOCK |
| | Wait with selective UNLOCK operation (60 seconds) | READY |
| | Passenger door is unlocked | UNLOCK |
| ID OK FLAG | Driver side door is open after ignition switch is turned OFF (Selector lever is in the P position except for M/T models) | Reset |
| | Ignition switch is ON | Set |
| PRMT ENG STRT | The engine start is prohibited | Reset |
| | The engine start is permitted | Set |
| PRMT RKE STRT | NOTE: The item is indicated, but not monitored. | Reset |
| KEY SW -SLOT | The Intelligent Key is not inserted into key slot | Off |
| | The Intelligent Key is inserted into key slot | On |
| RKE OPE COUN1 | During the operation of the Intelligent Key | Operation frequency of the Intelligent Key |
| RKE OPE COUN2 | NOTE: The item is indicated, but not monitored. | — |
| CONFIRM ID ALL | The key ID that the key slot receives is not recognized by any key ID registered to BCM. | Yet |
| | The key ID that the key slot receives is recognized by any key ID registered to BCM. | Done |
| CONFIRM ID4 | The key ID that the key slot receives is not recognized by the fourth key ID registered to BCM. | Yet |
| | The key ID that the key slot receives is recognized by the fourth key ID registered to BCM. | Done |
| CONFIRM ID3 | The key ID that the key slot receives is not recognized by the third key ID registered to BCM. | Yet |
| | The key ID that the key slot receives is recognized by the third key ID registered to BCM. | Done |
| CONFIRM ID2 | The key ID that the key slot receives is not recognized by the second key ID registered to BCM. | Yet |
| | The key ID that the key slot receives is recognized by the second key ID registered to BCM. | Done |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


| Monitor Item | Condition | Value/Status |
|--------------|--|-------------------------------|
| CONFIRM ID1 | The key ID that the key slot receives is not recognized by the first key ID registered to BCM. | Yet |
| | The key ID that the key slot receives is recognized by the first key ID registered to BCM. | Done |
| TP 4 | The ID of fourth Intelligent Key is not registered to BCM | Yet |
| | The ID of fourth Intelligent Key is registered to BCM | Done |
| TP 3 | The ID of third Intelligent Key is not registered to BCM | Yet |
| | The ID of third Intelligent Key is registered to BCM | Done |
| TP 2 | The ID of second Intelligent Key is not registered to BCM | Yet |
| | The ID of second Intelligent Key is registered to BCM | Done |
| TP 1 | The ID of first Intelligent Key is not registered to BCM | Yet |
| | The ID of first Intelligent Key is registered to BCM | Done |
| AIR PRESS FL | Ignition switch ON (Only when the signal from the transmitter is received) | Air pressure of front LH tire |
| AIR PRESS FR | Ignition switch ON (Only when the signal from the transmitter is received) | Air pressure of front RH tire |
| AIR PRESS RR | Ignition switch ON (Only when the signal from the transmitter is received) | Air pressure of rear RH tire |
| AIR PRESS RL | Ignition switch ON (Only when the signal from the transmitter is received) | Air pressure of rear LH tire |
| ID REGST FL1 | ID of front LH tire transmitter is registered | Done |
| | ID of front LH tire transmitter is not registered | Yet |
| ID REGST FR1 | ID of front RH tire transmitter is registered | Done |
| | ID of front RH tire transmitter is not registered | Yet |
| ID REGST RR1 | ID of rear RH tire transmitter is registered | Done |
| | ID of rear RH tire transmitter is not registered | Yet |
| ID REGST RL1 | ID of rear LH tire transmitter is registered | Done |
| | ID of rear LH tire transmitter is not registered | Yet |
| WARNING LAMP | Tire pressure indicator OFF | Off |
| | Tire pressure indicator ON | On |
| BUZZER | Tire pressure warning alarm is not sounding | Off |
| | Tire pressure warning alarm is sounding | On |

A
B
C
D
E
F
G
H
I
ADP
K
L
M
N
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

TERMINAL LAYOUT



PHYSICAL VALUES





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|---|------------------|---|--|---|
| | | Signal name | Input/ Output | | | |
| + | - | | | | | |
| 1 (W) | Ground | Battery power supply | Input | Ignition switch OFF | | Battery voltage |
| 2 (Y) | Ground | P/W power supply (BAT) | Output | Ignition switch OFF | | 12 V |
| 3 (BG) | Ground | P/W power supply (RAP) | Output | Ignition switch ON | | 12 V |
| 4 (LG) | Ground | Interior room lamp power supply | Output | Interior room lamp battery saver is activated. (Cuts the interior room lamp power supply) | | 0 V |
| | | | | Interior room lamp battery saver is not activated. (Outputs the interior room lamp power supply) | | 12 V |
| 5 (P) | Ground | Passenger door UN- LOCK | Output | Passenger door | UNLOCK (Actuator is activated) | 12 V |
| | | | | | Other than UNLOCK (Ac- tuator is not activated) | 0 V |
| 7 (SB) | Ground | Step lamp | Output | Step lamp | ON | 0 V |
| | | | | | OFF | 12 V |
| 8 (V) | Ground | All doors, fuel lid LOCK | Output | All doors, fuel lid | LOCK (Actuator is activated) | 12 V |
| | | | | | Other than LOCK (Actuator is not activated) | 0 V |
| 9 (G) | Ground | Driver door, fuel lid UNLOCK | Output | Driver door, fuel lid | UNLOCK (Actuator is activated) | 12 V |
| | | | | | Other than UNLOCK (Actuator is not activated) | 0 V |
| 11 (R) | Ground | Battery power supply | Input | Ignition switch OFF | | Battery voltage |
| 13 (B) | Ground | Ground | — | Ignition switch ON | | 0 V |
| 14 (W) | Ground | Push-button ignition switch illumination ground | Output | Tail lamp | OFF | 0 V |
| | | | | | ON | <p style="text-align: center;">NOTE: When the illumination brighten- ing/dimming level is in the neutral position.</p>  <p style="text-align: right; font-size: small;">JSNIA0010GB</p> |
| 15 (BG) | Ground | ACC indicator lamp | Output | Ignition switch | OFF (LOCK indicator is not illuminated) | Battery voltage |
| | | | | | ACC | 0 V |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|-------------------------------|------------------|--|---|-------|
| | | Signal name | Input/ Output | | | |
| + | - | | | | | |
| 17 (W) | Ground | Turn signal RH (Front) | Output | Ignition switch ON | Turn signal switch OFF | 0 V |
| | | | | Turn signal switch RH |  <small>PKID0926E</small> | 6.5 V |
| 18 (BG) | Ground | Turn signal LH (Front) | Output | Ignition switch ON | Turn signal switch OFF | 0 V |
| | | | | Turn signal switch LH |  <small>PKID0926E</small> | 6.5 V |
| 19 (V) | Ground | Interior room lamp control | Output | Interior room lamp | OFF | 12 V |
| | | | | ON | 0 V | |
| 20 (V) | Ground | Turn signal RH (Rear) | Output | Ignition switch ON | Turn signal switch OFF | 0 V |
| | | | | Turn signal switch RH |  <small>PKID0926E</small> | 6.5 V |
| 23 (LG) | Ground | Trunk lid open | Output | Trunk lid | OPEN (Trunk lid opener actuator is activated) | 12 V |
| | | | | Other than OPEN (Trunk lid opener actuator is not activated) | 0 V | |
| 25 (Y) | Ground | Turn signal LH (Rear) | Output | Ignition switch ON | Turn signal switch OFF | 0 V |
| | | | | Turn signal switch LH |  <small>PKID0926E</small> | 6.5 V |
| 30 (P) | Ground | Trunk room lamp | Output | Trunk room lamp | ON | 0 V |
| | | | | OFF | 12 V | |

BCM (BODY CONTROL MODULE)





< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|------------------------------|------------------|---|---|
| + | - | Signal name | Input/ Output | | |
| 34 (SB) | Ground | Trunk room antenna (-) | Output | Ignition switch OFF | <p style="text-align: right; font-size: small;">JMKIA0062GB</p> |
| | | | | When Intelligent Key is not in the passenger compart- ment | <p style="text-align: right; font-size: small;">JMKIA0063GB</p> |
| 35 (V) | Ground | Trunk room antenna (+) | Output | Ignition switch OFF | <p style="text-align: right; font-size: small;">JMKIA0062GB</p> |
| | | | | When Intelligent Key is not in the passenger compart- ment | <p style="text-align: right; font-size: small;">JMKIA0063GB</p> |
| 38 (B) | Ground | Rear bumper anten- na (-) | Output | When the trunk lid opener re- quest switch is operated with ignition switch OFF | <p style="text-align: right; font-size: small;">JMKIA0062GB</p> |
| | | | | When Intelligent Key is not in the antenna detection area | <p style="text-align: right; font-size: small;">JMKIA0063GB</p> |

A
B
C
D
E
F
G
H
I
ADP
K
L
M
N
O
P






BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|--|------------------|---|---|
| + | - | Signal name | Input/ Output | | |
| 39 (W) | Ground | Rear bumper antenna (+) | Output | When the trunk lid opener request switch is operated with ignition switch OFF |  <p style="text-align: right; font-size: small;">JMkia0062GB</p> |
| | | | | When Intelligent Key is not in the antenna detection area |  <p style="text-align: right; font-size: small;">JMkia0063GB</p> |
| 47 (Y) | Ground | Ignition relay (IPDM E/R) control | Output | Ignition switch | OFF or ACC ON |
| | | | | OFF or ACC ON | 12 V 0 V |
| 50 (BG) | Ground | Trunk room lamp switch | Input | Trunk room lamp switch | OFF (Trunk lid is closed) |
| | | | | OFF (Trunk lid is closed) |  <p style="text-align: right; font-size: small;">JPMIA0011GB</p> |
| | | | | ON (Trunk lid is opened) | 0 V |
| | | | | ON (Trunk lid is opened) | 0 V |
| 52 (R) | Ground | Starter relay control | Output | Ignition switch ON (A/T models) | When selector lever is in P or N position When selector lever is not in P or N position |
| | | | | Ignition switch ON (M/T models) | When the clutch pedal is depressed When the clutch pedal is not depressed |
| | | | | Battery voltage 0 V | |
| | | | | 0 V | |
| 60 (BR) | Ground | Push-button ignition switch (Push switch) | Input | Push-button ignition switch (Push switch) | Pressed Not pressed |
| | | | | Pressed Not pressed | 0 V Battery voltage |
| 61 (SB) | Ground | Trunk lid opener request switch | Input | Trunk lid opener request switch | ON (Pressed) OFF (Not pressed) |
| | | | | ON (Pressed) OFF (Not pressed) | 0 V |
| | | | | OFF (Not pressed) |  <p style="text-align: right; font-size: small;">JPMIA0016GB</p> |
| | | | | OFF (Not pressed) | 1.0 V |
| 64 (G) | Ground | Intelligent Key warning buzzer (Engine room) | Output | Intelligent Key warning buzzer (Engine room) | Sounding Not sounding |
| | | | | Sounding Not sounding | 0 V 12 V |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|--|------------------|------------------------------|--|---|
| | | Signal name | Input/ Output | | | |
| + | - | | | | | |
| 67 (GR) | Ground | Trunk lid opener switch | Input | Trunk lid open- er switch | Pressed | 0 V |
| | | | | | Not pressed |  11.8 V |
| 72 (R) | Ground | Room antenna 2 (-) (Center console) | Output | Ignition switch OFF | When Intelligent Key is in the passenger compart- ment |  11.8 V |
| | | | | | When Intelligent Key is not in the passenger compart- ment |  11.8 V |
| 73 (G) | Ground | Room antenna 2 (+) (Center console) | Output | Ignition switch OFF | When Intelligent Key is in the passenger compart- ment |  11.8 V |
| | | | | | When Intelligent Key is not in the passenger compart- ment |  11.8 V |

A
B
C
D
E
F
G
H
I
ADP
K
L
M
N
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|----------------------------|------------------|---|---|
| + | - | Signal name | Input/ Output | | |
| 74 (SB) | Ground | Passenger door antenna (-) | Output | When Intelligent Key is in the antenna detection area | <p style="text-align: right; font-size: small;">JMKIA0062GB</p> |
| | | | | When the passenger door request switch is operated with ignition switch OFF | <p style="text-align: right; font-size: small;">JMKIA0063GB</p> |
| 75 (BR) | Ground | Passenger door antenna (+) | Output | When Intelligent Key is in the antenna detection area | <p style="text-align: right; font-size: small;">JMKIA0062GB</p> |
| | | | | When the passenger door request switch is operated with ignition switch OFF | <p style="text-align: right; font-size: small;">JMKIA0063GB</p> |
| 76 (V) | Ground | Driver door antenna (-) | Output | When Intelligent Key is in the antenna detection area | <p style="text-align: right; font-size: small;">JMKIA0062GB</p> |
| | | | | When the driver door request switch is operated with ignition switch OFF | <p style="text-align: right; font-size: small;">JMKIA0063GB</p> |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|--|------------------|---|--------------------|
| + | - | Signal name | Input/ Output | | |
| 77 (LG) | Ground | Driver door antenna (+) | Output | When Intelligent Key is in the antenna detection area | <p>JMKIA0062GB</p> |
| | | | | When the driv- er door request switch is oper- ated with igni- tion switch OFF | <p>JMKIA0063GB</p> |
| 78 (Y) | Ground | Room antenna 1 (-) (Instrument panel) | Output | Ignition switch OFF | <p>JMKIA0062GB</p> |
| | | | | When Intelligent Key is not in the passenger compart- ment | <p>JMKIA0063GB</p> |
| 79 (BR) | Ground | Room antenna 1 (+) (Instrument panel) | Output | Ignition switch OFF | <p>JMKIA0062GB</p> |
| | | | | When Intelligent Key is not in the passenger compart- ment | <p>JMKIA0063GB</p> |

A

B

C

D

E

F

G

H

I

ADP

K

L

M






N

O

P






BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|---|------------------|---|--|--|
| + | - | Signal name | Input/ Output | | | |
| 80 (GR) | Ground | NATS antenna amp. | Input/ Output | During waiting | Ignition switch is pressed while inserting the Intelligent Key into the key slot. | Just after pressing ignition switch. Pointer of tester should move. |
| 81 (W) | Ground | NATS antenna amp. | Input/ Output | During waiting | Ignition switch is pressed while inserting the Intelligent Key into the key slot. | Just after pressing ignition switch. Pointer of tester should move. |
| 82 (SB) | Ground | Ignition relay [Fuse block (J/B)] control | Output | Ignition switch | OFF or ACC | 0 V |
| | | | | | ON | 12 V |
| 83 (Y) | Ground | Remote keyless entry receiver communication | Input/ Output | During waiting | |  <p style="text-align: right; font-size: small;">JMKIA0064GB</p> |
| | | | | When operating either button on the Intelligent Key | |  <p style="text-align: right; font-size: small;">JMKIA0065GB</p> |
| 87 (Y) | Ground | Combination switch INPUT 5 | Input | Combination switch | All switches OFF (Wiper volume dial 4) |  <p style="text-align: right; font-size: small;">JPMIA0041GB</p> <p style="text-align: center;">1.4 V</p> |
| | | | | | Front fog lamp switch ON (Wiper volume dial 4) |  <p style="text-align: right; font-size: small;">JPMIA0037GB</p> <p style="text-align: center;">1.3 V</p> |
| | | | | | Any of the conditions below with all switches OFF <ul style="list-style-type: none"> • Wiper volume dial 1 • Wiper volume dial 2 • Wiper volume dial 6 • Wiper volume dial 7 |  <p style="text-align: right; font-size: small;">JPMIA0040GB</p> <p style="text-align: center;">1.3 V</p> |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >



| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|-------------------------------|------------------|----------------------------|---|--|
| + | - | Signal name | Input/ Output | | | |
| 88 (BG) | Ground | Combination switch INPUT 3 | Input | Combination switch | All switches OFF (Wiper volume dial 4) |  <p style="text-align: right; font-size: small;">JPMAI0041GB</p> <p style="text-align: center;">1.4 V</p> |
| | | | | | Lighting switch HI (Wiper volume dial 4) |  <p style="text-align: right; font-size: small;">JPMAI0036GB</p> <p style="text-align: center;">1.3 V</p> |
| | | | | | Lighting switch 2ND (Wiper volume dial 4) |  <p style="text-align: right; font-size: small;">JPMAI0037GB</p> <p style="text-align: center;">1.3 V</p> |
| | | | | | Any of the conditions below with all switches OFF <ul style="list-style-type: none"> Wiper volume dial 1 Wiper volume dial 2 Wiper volume dial 3 |  <p style="text-align: right; font-size: small;">JPMAI0040GB</p> <p style="text-align: center;">1.3 V</p> |
| 90 (P) | Ground | CAN-L | Input/ Output | — | — | |
| 91 (L) | Ground | CAN-H | Input/ Output | — | — | |
| 92 (LG) | Ground | Key slot illumination | Output | Key slot illumin- ation | OFF | 12 V |
| | | | | | Blinking |  <p style="text-align: right; font-size: small;">JPMAI0015GB</p> <p style="text-align: center;">6.5 V</p> |
| 93 (GR) | Ground | ON indicator lamp | Output | Ignition switch | OFF (LOCK indicator is not illuminated) | Battery voltage |
| | | | | | ON | 0 V |

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP






BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|--|------------------|-------------------------------|------------------------------------|--|
| | | Signal name | Input/ Output | | | |
| + | - | | | | | |
| 95 (BG) | Ground | ACC relay control | Output | Ignition switch | OFF | 0 V |
| | | | | | ACC or ON | 12 V |
| 96 (GR) | Ground | A/T shift selector (Detention switch) power supply | Output | — | | 12 V |
| 99 (R)*1 (BR)*2 | Ground | Selector lever P position switch (A/T models) | Input | Selector lever | P position | 0 V |
| | | | | | Any position other than P | 12 V |
| | | ASCD clutch switch (M/T models) | | ASCD clutch switch | OFF (Clutch pedal is depressed) | 0 V |
| | | | | | ON (Clutch pedal is not depressed) | 12 V |
| 100 (Y) | Ground | Passenger door request switch | Input | Passenger door request switch | ON (Pressed) | 0 V |
| | | | | | OFF (Not pressed) |  <p style="text-align: right; font-size: small;">JPMIA0016GB</p> <p style="text-align: center;">1.0 V</p> |
| 101 (P) | Ground | Driver door request switch | Input | Driver door request switch | ON (Pressed) | 0 V |
| | | | | | OFF (Not pressed) |  <p style="text-align: right; font-size: small;">JPMIA0016GB</p> <p style="text-align: center;">1.0 V</p> |
| 102 (BG) | Ground | Blower fan motor relay control | Output | Ignition switch | OFF or ACC | 0 V |
| | | | | | ON | 12 V |
| 103 (P) | Ground | Remote keyless entry receiver power supply | Output | Ignition switch OFF | | 12 V |

BCM (BODY CONTROL MODULE)





< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|-------------------------------|------------------|---|------------------------|--|
| | | Signal name | Input/ Output | | | |
| + | - | | | | | |
| 107 (LG) | Ground | Combination switch INPUT 1 | Input | Combination switch (Wiper volume dial 4) | All switches OFF |  <p style="text-align: right;">JPMAI0041GB</p> <p style="text-align: center;">1.4 V</p> |
| | | | | | Turn signal switch LH |  <p style="text-align: right;">JPMAI0037GB</p> <p style="text-align: center;">1.3 V</p> |
| | | | | | Turn signal switch RH |  <p style="text-align: right;">JPMAI0036GB</p> <p style="text-align: center;">1.3 V</p> |
| | | | | | Front wiper switch LO |  <p style="text-align: right;">JPMAI0038GB</p> <p style="text-align: center;">1.3 V</p> |
| | | | | | Front washer switch ON |  <p style="text-align: right;">JPMAI0039GB</p> <p style="text-align: center;">1.3 V</p> |

A
B
C
D
E
F
G
H
I
ADP
K
L
M
N
O
P







BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|-------------------------------|------------------|-----------------------|---|---|
| | | Signal name | Input/ Output | | | |
| + | - | | | | | |
| 108 (R) | Ground | Combination switch INPUT 4 | Input | Combination switch | All switches OFF (Wiper volume dial 4) |  <p style="text-align: right; margin-right: 20px;">1.4 V</p> |
| | | | | | Lighting switch AUTO (Wiper volume dial 4) |  <p style="text-align: right; margin-right: 20px;">1.3 V</p> |
| | | | | | Lighting switch 1ST (Wiper volume dial 4) |  <p style="text-align: right; margin-right: 20px;">1.3 V</p> |
| | | | | | Any of the conditions below with all switches OFF <ul style="list-style-type: none"> • Wiper volume dial 1 • Wiper volume dial 5 • Wiper volume dial 6 |  <p style="text-align: right; margin-right: 20px;">1.3 V</p> |

BCM (BODY CONTROL MODULE)



< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|-------------------------------|------------------|---|--|--|
| + | - | Signal name | Input/ Output | | | |
| 109 (W) | Ground | Combination switch INPUT 2 | Input | Combination switch (Wiper volume dial 4) | All switches OFF |  <p style="text-align: center;">1.4 V</p> |
| | | | | | Lighting switch PASS |  <p style="text-align: center;">1.3 V</p> |
| | | | | | Lighting switch 2ND |  <p style="text-align: center;">1.3 V</p> |
| | | | | | Front wiper switch INT/ AUTO |  <p style="text-align: center;">1.3 V</p> |
| | | | | | Front wiper switch HI |  <p style="text-align: center;">1.3 V</p> |
| | | | | | ON | 0 V |
| 110 (G) | Ground | Hazard switch | Input | Hazard switch |  <p style="text-align: center;">1.1 V</p> | |
| | | | | OFF | | |

A
B
C
D
E
F
G
H
I
ADP
K
L
M
N
O
P





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|--|------------------|--|--|--|
| + | - | Signal name | Input/ Output | | | |
| 112 (R) | Ground | Rain sensor serial link | Input/ Output | Ignition switch ON | |  8.7 V |
| 113 (BG) | Ground | Optical sensor | Input | Ignition switch ON | When bright outside of the vehicle | Close to 5 V |
| | | | | | When dark outside of the vehicle | Close to 0 V |
| 114 (R) | Ground | Clutch interlock switch | Input | Clutch interlock switch | OFF (Clutch pedal is not depressed) | 0 V |
| | | | | | ON (Clutch pedal is depressed) | Battery voltage |
| 116 (SB) | Ground | Stop lamp switch 1 | Input | — | | Battery voltage |
| 118 (BR) | Ground | Stop lamp switch 2 (Without ICC) | Input | Stop lamp switch | OFF (Brake pedal is not depressed) | 0 V |
| | | | | | ON (Brake pedal is depressed) | Battery voltage |
| | | Stop lamp switch 2 (With ICC) | | Stop lamp switch OFF (Brake pedal is not depressed) and ICC brake hold relay OFF | | 0 V |
| | | | | Stop lamp switch ON (Brake pedal is depressed) or ICC brake hold relay ON | | Battery voltage |
| 119 (SB) | Ground | Driver side door lock assembly (Unlock sensor) | Input | Driver door | LOCK status (Unlock sensor switch OFF) |  1.1 V |
| | | | | | UNLOCK status (Unlock switch sensor ON) | 0 V |
| 121 (SB) | Ground | Key slot switch | Input | When the Intelligent Key is inserted into key slot | | 12 V |
| | | | | When the Intelligent Key is not inserted into key slot | | 0 V |
| 123 (V) | Ground | IGN feedback | Input | Ignition switch | OFF or ACC | 0 V |
| | | | | | ON | Battery voltage |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >






| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|--|------------------|--|---|--|
| + | - | Signal name | Input/ Output | | | |
| 124 (R) | Ground | Passenger door switch | Input | Passenger door switch | OFF (Door close) |  <p style="text-align: right; font-size: small;">JPMA0011GB</p> <p style="text-align: center;">11.8 V</p> |
| | | | | | ON (Door open) | 0 V |
| 129 (BG) | Ground | Trunk lid opener cancel switch | Input | Trunk lid opener cancel switch | CANCEL |  <p style="text-align: right; font-size: small;">JPMA0012GB</p> <p style="text-align: center;">1.1 V</p> |
| | | | | | ON | 0 V |
| 132 (V) | Ground | Power window switch communication | Input/ Output | Ignition switch ON |  <p style="text-align: right; font-size: small;">JPMA0013GB</p> <p style="text-align: center;">10.2 V</p> | |
| | | | | Ignition switch OFF or ACC | 12 V | |
| 133 (L) | Ground | Push-button ignition switch illumination | Output | Push-button ignition switch illumination | ON (Tail lamps OFF) | 9.5 V |
| | | | | | ON (Tail lamps ON) | <p style="text-align: center;">NOTE: The pulse width of this wave is varied by the illumination brightening/dimming level.</p>  <p style="text-align: right; font-size: small;">JPMA0159GB</p> |
| | | | | | OFF | 0 V |
| 134 (LG) | Ground | LOCK indicator lamp | Output | LOCK indicator lamp | OFF | Battery voltage |
| | | | | | ON | 0 V |
| 137 (BG) | Ground | Receiver and sensor ground | Input | Ignition switch ON | | 0 V |
| 138 (V) | Ground | Receiver and sensor power supply | Output | Ignition switch | OFF | 0 V |
| | | | | | ACC or ON | 5.0 V |

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|--------------------------------------|------------------|---|--|
| + | - | Signal name | Input/ Output | | |
| 139 (L) | Ground | Tire pressure receiver communication | Input/ Output | Ignition switch ON | Standby state  OCC3881D |
| | | | | When receiving the signal from the transmitter  OCC3880D | |
| 140*1 (B) | Ground | Selector lever P/N position | Input | Selector lever | P or N position 12 V |
| | | | | Except P and N positions 0 V | |
| 141 (W) | Ground | Security indicator lamp | Output | Security indicator lamp | ON 0 V |
| | | | | Blinking  JPMIA0014GB 11.3 V | |
| 142 (BR) | Ground | Combination switch OUTPUT 5 | Output | Combination switch (Wiper volume dial 4) | All switches OFF 0 V |
| | | | | Turn signal switch RH  JPMIA0031GB 10.7 V | |
| 143 (P) | Ground | Combination switch OUTPUT 1 | Output | Combination switch | All switches OFF (Wiper volume dial 4) 0 V |
| | | | | Front wiper switch HI (Wiper volume dial 4) Any of the conditions below with all switches OFF • Wiper volume dial 1 • Wiper volume dial 2 • Wiper volume dial 3 • Wiper volume dial 6 • Wiper volume dial 7  JPMIA0032GB 10.7 V | |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | | |
|------------------------------|--------|---|------------------|---|---|-----------------|--------|
| | | Signal name | Input/ Output | | | | |
| + | - | | | | | | |
| 144 (G) | Ground | Combination switch OUTPUT 2 | Output | Combination switch | All switches OFF (Wiper volume dial 4) | 0 V | |
| | | | | | Front washer switch ON (Wiper volume dial 4) | | |
| | | | | | Any of the conditions below with all switches OFF | | 10.7 V |
| | | | | | | | |
| 145 (L) | Ground | Combination switch OUTPUT 3 | Output | Combination switch (Wiper volume dial 4) | All switches OFF | 0 V | |
| | | | | | Front wiper switch INT/ AUTO | | |
| | | | | | Front wiper switch LO | | 10.7 V |
| | | | | | Lighting switch AUTO | | |
| 146 (SB) | Ground | Combination switch OUTPUT 4 | Output | Combination switch (Wiper volume dial 4) | All switches OFF | 0 V | |
| | | | | | Front fog lamp switch ON | | |
| | | | | | Lighting switch 2ND | | 10.7 V |
| | | | | | Lighting switch PASS | | |
| | | | | | Turn signal switch LH | | |
| 150 (GR) | Ground | Driver door switch | Input | Driver door switch | OFF (Door close) | | |
| | | | | | 11.8 V | | |
| | | | | | ON (Door open) | 0 V | |
| 151 (G) | Ground | Rear window defog- ger relay control | Output | Rear window defogger | Active | 0 V | |
| | | | | | Not activated | Battery voltage | |


- *1: A/T models
- *2: M/T models

A
B
C
D
E
F
G
H
I
ADP
K
L
M
N
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

M : With M/T




JRMWC4424GB

A
B
C
D
E
F
G
H
I
ADP
K
L
M
N
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >




*: This connector is not shown in "Harness Layout".

JRMWC4425GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >



*: This connector is not shown in "Harness Layout".

A
B
C
D
E
F
G
H
I
ADP
K
L
M
N
O
P

Fail-safe

FAIL-SAFE CONTROL BY DTC

BCM performs fail-safe control when any DTC are detected.

INFOID:000000008788111

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Display contents of CONSULT | Fail-safe | Cancellation |
|-----------------------------|---|---|
| B2190: NATS ANTENNA AMP | Inhibit engine cranking | Erase DTC |
| B2191: DIFFERENCE OF KEY | Inhibit engine cranking | Erase DTC |
| B2192: ID DISCORD BCM-ECM | Inhibit engine cranking | Erase DTC |
| B2193: CHAIN OF BCM-ECM | Inhibit engine cranking | Erase DTC |
| B2195: ANTI-SCANNING | Inhibit engine cranking | Ignition switch ON → OFF |
| B2560: STARTER CONT RELAY | Inhibit engine cranking | 500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> • Starter control relay signal • Starter relay status signal |
| B2608: STARTER RELAY | Inhibit engine cranking | 500 ms after the following signal communication status becomes consistent <ul style="list-style-type: none"> • Starter motor relay control signal • Starter relay status signal (CAN) |
| B260A: IGNITION RELAY | Inhibit engine cranking | 500 ms after the following conditions are fulfilled <ul style="list-style-type: none"> • IGN relay (IPDM E/R) control signal: OFF (12 V) • Ignition ON signal (CAN to IPDM E/R): OFF (Request signal) • Ignition ON signal (CAN from IPDM E/R): OFF (Condition signal) |
| B260F: ENG STATE SIG LOST | Maintains the power supply position attained at the time of DTC detection | When any of the following conditions are fulfilled <ul style="list-style-type: none"> • Power position changes to ACC • Receives engine status signal (CAN) |
| B2617: BCM | Inhibit engine cranking | 1 second after the starter motor relay control inside BCM becomes normal |
| B2618: BCM | Inhibit engine cranking | 1 second after the ignition relay (IPDM E/R) control inside BCM becomes normal |
| B261E: VEHICLE TYPE | Inhibit engine cranking | BCM initialization |
| B26E8: CLUTCH SW | Inhibit engine cranking | When any of the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Status 1 <ul style="list-style-type: none"> - Clutch switch signal (CAN from ECM): ON - Clutch interlock switch signal: OFF (0 V) • Status 2 <ul style="list-style-type: none"> - Clutch switch signal (CAN from ECM): OFF - Clutch interlock switch signal: ON (Battery voltage) |

DTC Inspection Priority Chart

INFOID:000000008788112

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

| Priority | DTC |
|----------|---|
| 1 | B2562: LOW VOLTAGE |
| 2 | <ul style="list-style-type: none"> • U1000: CAN COMM • U1010: CONTROL UNIT(CAN) |
| 3 | <ul style="list-style-type: none"> • B2190: NATS ANTENNA AMP • B2191: DIFFERENCE OF KEY • B2192: ID DISCORD BCM-ECM • B2193: CHAIN OF BCM-ECM • B2195: ANTI-SCANNING |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Priority | DTC | | |
|----------|---|---|--------|
| 4 | <ul style="list-style-type: none"> • B2553: IGNITION RELAY • B2555: STOP LAMP • B2556: PUSH-BTN IGN SW • B2557: VEHICLE SPEED • B2560: STARTER CONT RELAY • B2601: SHIFT POSITION • B2602: SHIFT POSITION • B2603: SHIFT POSI STATUS • B2604: PNP/CLUTCH SW • B2605: PNP/CLUTCH SW • B2608: STARTER RELAY • B260A: IGNITION RELAY • B260F: ENG STATE SIG LOST • B2614: BCM • B2615: BCM • B2616: BCM • B2617: BCM • B2618: BCM • B261A: PUSH-BTN IGN SW • B261E: VEHICLE TYPE • B26E8: CLUTCH SW • B26EA: KEY REGISTRATION • C1729: VHCL SPEED SIG ERR • U0415: VEHICLE SPEED | A B C D E F G | |
| | <ul style="list-style-type: none"> • C1704: LOW PRESSURE FL • C1705: LOW PRESSURE FR • C1706: LOW PRESSURE RR • C1707: LOW PRESSURE RL • C1708: [NO DATA] FL • C1709: [NO DATA] FR • C1710: [NO DATA] RR • C1711: [NO DATA] RL • C1716: [PRESSDATA ERR] FL • C1717: [PRESSDATA ERR] FR • C1718: [PRESSDATA ERR] RR • C1719: [PRESSDATA ERR] RL • C1734: CONTROL UNIT | H I ADP | |
| | 6 | <ul style="list-style-type: none"> • B2621: INSIDE ANTENNA • B2622: INSIDE ANTENNA • B2623: INSIDE ANTENNA | K L |

DTC Index

INFOID:000000008788113

NOTE:

The details of time display are as follows.

- CRNT: A malfunction is detected now.
- PAST: A malfunction was detected in the past.

IGN counter is displayed on Freeze Frame Data. For details of Freeze Frame Data, refer to [BCS-16. "COMMON ITEM : CONSULT Function \(BCM - COMMON ITEM\)"](#).

| CONSULT display | Fail-safe | Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle condition | Intelligent Key warning lamp ON | Tire pressure monitor warning lamp ON | Refer- ence page |
|--|-----------|--|------------------------------------|---|------------------------|
| No DTC is detected. further testing may be required. | — | — | — | — | — |
| U1000: CAN COMM | — | — | — | — | BCS-36 |
| U1010: CONTROL UNIT(CAN) | — | — | — | — | BCS-37 |
| U0415: VEHICLE SPEED | — | — | — | — | BCS-38 |
| B2190: NATS ANTENNA AMP | × | — | — | — | SEC-51 |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| CONSULT display | Fail-safe | Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle condition | Intelligent Key warning lamp ON | Tire pressure monitor warning lamp ON | Refer- ence page |
|---------------------------|-----------|--|------------------------------------|---|------------------------|
| B2191: DIFFERENCE OF KEY | × | — | — | — | SEC-54 |
| B2192: ID DISCORD BCM-ECM | × | — | — | — | SEC-55 |
| B2193: CHAIN OF BCM-ECM | × | — | — | — | SEC-57 |
| B2195: ANTI-SCANNING | × | — | — | — | SEC-58 |
| B2553: IGNITION RELAY | — | × | — | — | PCS-48 |
| B2555: STOP LAMP | — | × | — | — | SEC-59 |
| B2556: PUSH-BTN IGN SW | — | × | × | — | SEC-61 |
| B2557: VEHICLE SPEED | × | × | × | — | SEC-63 |
| B2560: STARTER CONT RELAY | × | × | × | — | SEC-64 |
| B2562: LOW VOLTAGE | — | × | — | — | BCS-39 |
| B2601: SHIFT POSITION | × | × | × | — | SEC-65 |
| B2602: SHIFT POSITION | × | × | × | — | SEC-68 |
| B2603: SHIFT POSI STATUS | × | × | × | — | SEC-70 |
| B2604: PNP/CLUTCH SW | × | × | × | — | SEC-73 |
| B2605: PNP/CLUTCH SW | × | × | × | — | SEC-75 |
| B2608: STARTER RELAY | × | × | × | — | SEC-77 |
| B260A: IGNITION RELAY | × | × | × | — | PCS-50 |
| B260F: ENG STATE SIG LOST | × | × | × | — | SEC-79 |
| B2614: BCM | — | × | × | — | PCS-52 |
| B2615: BCM | — | × | × | — | PCS-54 |
| B2616: BCM | — | × | × | — | PCS-56 |
| B2617: BCM | × | × | × | — | SEC-83 |
| B2618: BCM | × | × | × | — | PCS-58 |
| B261A: PUSH-BTN IGN SW | — | × | × | — | PCS-59 |
| B261E: VEHICLE TYPE | × | × | × (Turn ON for 15 seconds) | — | SEC-85 |
| B2621: INSIDE ANTENNA | — | × | — | — | DLK-55 |
| B2622: INSIDE ANTENNA | — | × | — | — | DLK-57 |
| B2623: INSIDE ANTENNA | — | × | — | — | DLK-59 |
| B26E8: CLUTCH SW | × | × | × | — | SEC-80 |
| B26EA: KEY REGISTRATION | — | × | × (Turn ON for 15 seconds) | — | SEC-82 |
| C1704: LOW PRESSURE FL | — | — | — | × | WT-19 |
| C1705: LOW PRESSURE FR | — | — | — | × | |
| C1706: LOW PRESSURE RR | — | — | — | × | |
| C1707: LOW PRESSURE RL | — | — | — | × | |
| C1708: [NO DATA] FL | — | — | — | × | WT-21 |
| C1709: [NO DATA] FR | — | — | — | × | |
| C1710: [NO DATA] RR | — | — | — | × | |
| C1711: [NO DATA] RL | — | — | — | × | |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| CONSULT display | Fail-safe | Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle condition | Intelligent Key warning lamp ON | Tire pressure monitor warning lamp ON | Refer- ence page |
|---------------------------|-----------|--|------------------------------------|---|-----------------------|
| C1716: [PRESSDATA ERR] FL | — | — | — | × | WT-24 |
| C1717: [PRESSDATA ERR] FR | — | — | — | × | |
| C1718: [PRESSDATA ERR] RR | — | — | — | × | |
| C1719: [PRESSDATA ERR] RL | — | — | — | × | WT-25 |
| C1729: VHCL SPEED SIG ERR | — | — | — | × | |
| C1734: CONTROL UNIT | — | — | — | × | WT-26 |

A
B
C
D

E

F

G

H

I

ADP

K

L

M

N

O

P

DRIVER SEAT CONTROL UNIT (WITH AUTOMATIC DRIVE POSITIONER)

< ECU DIAGNOSIS INFORMATION >

DRIVER SEAT CONTROL UNIT (WITH AUTOMATIC DRIVE POSITIONER)

Reference Value

INFOID:000000008163730

VALUES ON THE DIAGNOSIS TOOL

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

CONSULT MONITOR ITEM

| Monitor Item | Condition | Value/Status | |
|---------------|-----------------------------|------------------|-----|
| SET SW | Set switch | Push | ON |
| | | Release | OFF |
| MEMORY SW1 | Memory switch 1 | Push | ON |
| | | Release | OFF |
| MEMORY SW2 | Memory switch 2 | Push | ON |
| | | Release | OFF |
| SLIDE SW-FR | Sliding switch (front) | Operate | ON |
| | | Release | OFF |
| SLIDE SW-RR | Sliding switch (rear) | Operate | ON |
| | | Release | OFF |
| RECLN SW-FR | Reclining switch (front) | Operate | ON |
| | | Release | OFF |
| RECLN SW-RR | Reclining switch (rear) | Operate | ON |
| | | Release | OFF |
| LIFT FR SW-UP | Lifting switch front (up) | Operate | ON |
| | | Release | OFF |
| LIFT FR SW-DN | Lifting switch front (down) | Operate | ON |
| | | Release | OFF |
| LIFT RR SW-UP | Lifting switch rear (up) | Operate | ON |
| | | Release | OFF |
| LIFT RR SW-DN | Lifting switch rear (down) | Operate | ON |
| | | Release | OFF |
| MIR CON SW-UP | Mirror switch | Up | ON |
| | | Other than above | OFF |
| MIR CON SW-DN | Mirror switch | Down | ON |
| | | Other than above | OFF |
| MIR CON SW-RH | Mirror switch | Right | ON |
| | | Other than above | OFF |
| MIR CON SW-LH | Mirror switch | Left | ON |
| | | Other than above | OFF |
| MIR CHNG SW-R | Changeover switch | Right | ON |
| | | Other than above | OFF |
| MIR CHNG SW-L | Changeover switch | Left | ON |
| | | Other than above | OFF |
| TILT SW-UP | Tilt switch | Up | ON |
| | | Other than above | OFF |

DRIVER SEAT CONTROL UNIT (WITH AUTOMATIC DRIVE POSITIONER)

< ECU DIAGNOSIS INFORMATION >

| Monitor Item | Condition | | Value/Status |
|-----------------------------|------------------------------|--|---|
| TILT SW-DOWN | Tilt switch | Down | ON |
| | | Other than above | OFF |
| TELESCO SW-FR | Telescopic switch | Forward | ON |
| | | Other than above | OFF |
| TELESCO SW-RR | Tilt switch | Backward | ON |
| | | Other than above | OFF |
| FORWARD SW | Seat back | Folded down | ON |
| | | Other than above | OFF |
| WALK-IN SW | Power walk-in switch | Pressed | ON |
| | | Other than above | OFF |
| FWD LIMIT SW | Seat sliding | Front edge | ON |
| | | Other than above | OFF |
| SEAT BELT SW | Seat belt | Fastened | ON |
| | | Other than above | OFF |
| DETENT SW ^{*1} | A/T selector lever | P position | OFF |
| | | Other than above | ON |
| PARK BRAKE SW ^{*2} | Parking brake | Applied | ON |
| | | Release | OFF |
| STARTER SW | Ignition position | Cranking | ON |
| | | Other than above | OFF |
| SLIDE PULSE | Seat sliding | Forward | The numeral value decreases ^{*3} |
| | | Backward | The numeral value increases ^{*3} |
| | | Other than above | No change to numeral value ^{*3} |
| RECLN PULSE | Seat reclining | Forward | The numeral value decreases ^{*3} |
| | | Backward | The numeral value increases ^{*3} |
| | | Other than above | No change to numeral value ^{*3} |
| LIFT FR PULSE | Seat lifter (front) | Up | The numeral value decreases ^{*3} |
| | | Down | The numeral value increases ^{*3} |
| | | Other than above | No change to numeral value ^{*3} |
| LIFT RR PULSE | Seat lifter (rear) | Up | The numeral value decreases ^{*3} |
| | | Down | The numeral value increases ^{*3} |
| | | Other than above | No change to numeral value ^{*3} |
| MIR/SEN RH U-D | Door mirror (passenger side) | Change between 3.4 (close to peak) 0.6 (close to valley) | |
| MIR/SEN RH R-L | Door mirror (passenger side) | Change between 3.4 (close to left edge) 0.6 (close to right edge) | |
| MIR/SEN LH U-D | Door mirror (driver side) | Change between 3.4 (close to peak) 0.6 (close to valley) | |
| MIR/SEN LH R-L | Door mirror (driver side) | Change between 0.6 (close to left edge) 3.4 (close to right edge) | |
| TILT SEN | Tilt position | Change between 1.2 (close to top) 3.4 (close to bottom) | |
| TELESCO SEN | Telescopic position | Change between 3.4 (close to top) 0.8 (close to bottom) | |

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

DRIVER SEAT CONTROL UNIT (WITH AUTOMATIC DRIVE POSITIONER)


< ECU DIAGNOSIS INFORMATION >

*1: A/T model

*2: M/T model

*3: The value at the position attained when the battery is connected is regarded as 32768.

TERMINAL LAYOUT







PHYSICAL VALUES

| Terminal No. (Wire color) | | Description | | Condition | Voltage (V) (Approx) | |
|------------------------------|--------|--|-----------------------|--|-------------------------|-----------------|
| + | - | Signal name | Input/ Out- put | | | |
| 1 (L/W) | Ground | UART communica- tion (RX) | Input | Ignition switch ON | | |
| 3 (R/Y) | — | CAN-H | — | — | — | |
| 4 (O/B) | Ground | Sliding limit switch signal | Input | Seat sliding front edge | 0 | |
| | | | | Seat switch & power walk-in switch is pressed | 5 | |
| 5 (L) | Ground | Seat belt buckle switch signal (driv- er side) | Input | Seat belt fastened & seat switch pressed | 5 | |
| | | | | Other than above | 0 | |
| 8 (L/Y) | Ground | Parking brake switch signal | Input | Parking brake | Applied | 0 |
| | | | | | Release | Battery voltage |
| 9 (W/G) | Ground | Reclining sensor signal | Input | Seat reclining | Operate | |
| | | | | | Stop | 0 or 5 |

DRIVER SEAT CONTROL UNIT (WITH AUTOMATIC DRIVE POSITIONER)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Voltage (V) (Approx) |
|------------------------------|--------|----------------------------------|------------------|------------------------|---|
| + | - | Signal name | Input/ Output | | |
| 10 (P/B) | Ground | Lifting sensor (rear) signal | Input | Seat lifting (rear) | Operate  |
| | | | | Stop | 0 or 5 |
| 11 (BR) | Ground | Sliding switch backward signal | Input | Sliding switch | Operate (backward): 0 Release: Battery voltage |
| | | | | Reclining switch | Operate (backward): 0 Release: Battery voltage |
| 12 (SB) | Ground | Reclining switch backward signal | Input | Lifting switch (front) | Operate (downward): 0 Release: Battery voltage |
| | | | | Lifting switch (rear) | Operate (downward): 0 Release: Battery voltage |
| 16 (O) | Ground | Sensor power supply | Output | — | Battery voltage |
| 17 (Y/R) | Ground | UART communication (TX) | Output | Ignition switch ON |  |
| 19 (V) | — | CAN-L | — | — | — |
| 21 (L/Y) | Ground | Detention switch switch | Input | A/T selector lever | P position: 0 Except P position:  |
| | | | | Seat sliding | Operate:  Stop: 0 or 5 |


A
B
C
D
E
F
G
H
I

ADP

K
L
M
N
O
P

DRIVER SEAT CONTROL UNIT (WITH AUTOMATIC DRIVE POSITIONER)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Voltage (V) (Approx) | |
|------------------------------|--------|--|------------------|--------------------------------|-------------------------|---|
| + | - | Signal name | Input/ Output | | | |
| 25 (Y/B) | Ground | Lifting sensor (front) signal | Input | Seat lifting (front) | Operate |  |
| | | | | Stop | 0 or 5 | |
| 26 (Y) | Ground | Sliding switch for- ward signal | Input | Sliding switch | Operate (forward) | 0 |
| | | | | | Release | Battery voltage |
| 27 (R/G) | Ground | Reclining switch forward signal | Input | Reclining switch | Operate (forward) | 0 |
| | | | | | Release | Battery voltage |
| 28 (W/B) | Ground | Lifting switch (front) upward signal | Input | Seat lifting switch (front) | Operate (upward) | 0 |
| | | | | | Release | Battery voltage |
| 29 (P/L) | Ground | Lifting switch (rear) upward signal | Input | Seat lifting switch (rear) | Operate (upward) | 0 |
| | | | | | Release | Battery voltage |
| 30 (P) | Ground | Power walk-in switch signal | Input | Power walk-in switch | Pressed | 0 |
| | | | | | Other than above | Battery voltage |
| 31 (GR) | Ground | Sensor ground | — | — | 0 | |
| 32 (B/W) | Ground | Ground (signal) | — | — | 0 | |
| 33 (R) | Ground | Power source (C/B) | Input | — | Battery voltage | |
| 35 (W/R) | Ground | Sliding motor for- ward output | Out- put | Seat sliding | Operate (forward) | Battery voltage |
| | | | | | Release | 0 |
| 36 (G/Y) | Ground | Reclining motor for- ward output signal | Out- put | Seat reclining | Operate (forward) | Battery voltage |
| | | | | | Release | 0 |
| 37 (G/W) | Ground | Lifting motor (front) downward output | Out- put | Seat lifting (front) | Operate (downward) | Battery voltage |
| | | | | | Stop | 0 |
| 38 (L/Y) | Ground | Lifting motor (rear) upward output | Out- put | Seat lifting (rear) | Operate (upward) | Battery voltage |
| | | | | | Stop | 0 |
| 39 (R/B) | Ground | Lifting motor (rear) downward output | Out- put | Seat lifting (rear) | Operate (downward) | Battery voltage |
| | | | | | Stop | 0 |
| 40 (R/W) | Ground | Power source (Fuse) | Input | — | Battery voltage | |

DRIVER SEAT CONTROL UNIT (WITH AUTOMATIC DRIVE POSITIONER)

< ECU DIAGNOSIS INFORMATION >


| Terminal No. (Wire color) | | Description | | Condition | Voltage (V) (Approx) |
|------------------------------|--------|--|-----------------------|--|--|
| + | - | Signal name | Input/ Out- put | | |
| 41 (Y/G) | Ground | Forward switch sig- nal | Input | Seat back is folded down and power walk-in switch pressed | 0 |
| | | | | Seat back is fold up and seat reclin- ing is operation | battery voltage |
| | | | | Seat back is fold up and power walk- in switch is pressed | 5 |
| 42 (W) | Ground | Sliding motor back- ward output | Out- put | Seat sliding | Operate (backward) Battery voltage |
| | | | | Stop | 0 |
| 44 (P) | Ground | Reclining motor backward output | Out- put | Seat reclining | Operate (backward) Battery voltage |
| | | | | Stop | 0 |
| 45 (L/R) | Ground | Lifting motor (front) upward output | Out- put | Seat lifting (front) | Operate (upward) Battery voltage |
| | | | | Stop | 0 |
| 48 (B) | Ground | Ground (power) | — | — | 0 |

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

DRIVER SEAT CONTROL UNIT (WITH AUTOMATIC DRIVE POSITIONER)

< ECU DIAGNOSIS INFORMATION >



Fail Safe

INFOID:000000008163732

The fail-safe mode may be activated if the following symptoms are observed.

DRIVER SEAT CONTROL UNIT (WITH AUTOMATIC DRIVE POSITIONER)

< ECU DIAGNOSIS INFORMATION >

| Operating in fail-safe mode | Malfunction Item | Related DTC | Diagnosis |
|---|-----------------------|------------------------|--|
| Only manual functions operate normally. | CAN communication*1 | U1000 | With ADP: ADP-48 |
| | | | Without ADP: ADP-48 |
| | Tilt sensor*1 | B2118 | With ADP: ADP-53 |
| | | | Without ADP: ADP-53 |
| | Telescopic sensor | B2119 | ADP-56 |
| | Detent switch | B2126 | ADP-59 |
| Parking brake switch | B2127 | ADP-61 | |
| Only manual functions, except door mirror, operate normally. | UART communication | B2128 | ADP-63 |
| Only manual functions, except seat sliding, operate normally. | Seat sliding output | B2112 | ADP-49 |
| Only manual functions, except seat reclining, operate normally. | Seat reclining output | B2113 | ADP-51 |

*1: Driver seat without automatic driver positioner system display only "U1000 CAN COMM CIRCUIT" and "B2112 SEAT SLIDE".

DTC Index

INFOID:000000008163733

| CONSULT display | Timing*1 | | Item | Reference page |
|-------------------------------|----------------------|-----------------------|--------------------------------|--|
| | Current mal-function | Previous mal-function | | |
| CAN COMM CIRCUIT*2 [U1000] | 0 | 1-39 | CAN communication | With ADP: ADP-48 |
| | | | | Without ADP: ADP-48 |
| SEAT SLIDE*2 [B2112] | 0 | 1-39 | Seat slide motor output | With ADP: ADP-49 |
| | | | | Without ADP: ADP-49 |
| SEAT RECLINING [B2113] | 0 | 1-39 | Seat reclining motor output | ADP-51 |
| TILT SENSOR [B2118] | 0 | 1-39 | Tilt sensor input | ADP-53 |
| TELESCO SENSOR [B2119] | 0 | 1-39 | Telescopic sensor input | ADP-56 |
| DETENT SW*2 [B2126] | 0 | 1-39 | Detention switch condition | ADP-59 |
| PARKING BRAKE [B2127] | 0 | 1-39 | Parking brake switch condition | ADP-61 |
| UART COMM [B2128] | 0 | 1-39 | UART communication | ADP-63 |

*1:

- 0: Current malfunction is present
- 1-39: Displayed if any previous malfunction is present when current condition is normal. The numeral value increases by one at each IGN ON to OFF cycle from 1 to 39. The counter remains at 39 even if the number of cycles exceeds it. However, the counter is reset to 1 if any malfunction is detected again, the normal operation is resumed and the ignition switch is turned from OFF to ON.

*2: Driver seat without automatic driver positioner system display only "U1000 CAN COMM CIRCUIT" and "B2112 SEAT SLIDE".

AUTOMATIC DRIVE POSITIONER CONTROL UNIT


< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

Reference Value


INFOID:000000008163734

TERMINAL LAYOUT



PHYSICAL VALUES

| Terminal No. (Wire color) | | Description | | Condition | | Voltage (V) (Approx.) |
|------------------------------|--------|--|------------------|------------------------------|---|--------------------------|
| + | - | Signal name | Input/ Output | | | |
| 1 (Y) | Ground | Tilt switch upward signal | Input | Tilt switch | Operate (upward) | 0 |
| | | | | | Other than above | 5 |
| 2 (LG) | Ground | Changeover switch RH signal | Input | Changeover switch position | RH | 0 |
| | | | | | Neutral or LH | 5 |
| 3 (G) | Ground | Mirror switch upward signal | Input | Mirror switch | Operated (upward) | 0 |
| | | | | | Other than above | 5 |
| 4 (Y) | Ground | Mirror switch leftward signal | Input | Mirror switch | Operated (leftward) | 0 |
| | | | | | Other than above | 5 |
| 5 (R) | Ground | Door mirror sensor (RH) upward/downward signal | Input | Mirror face (door mirror RH) | Change between 3.4 (close to peak) 0.6 (close to valley) | |
| 6 (GR) | Ground | Door mirror sensor (LH) upward/downward signal | Input | Mirror face (door mirror LH) | Change between 3.4 (close to peak) 0.6 (close to valley) | |
| 7 (BG) | Ground | Tilt sensor signal | Input | Tilt position | Change between 1.2 (close to top) 3.8 (close to bottom) | |
| 9 (BR) | Ground | Memory switch 1 signal | Input | Memory switch 1 | Press | 0 |
| | | | | | Other than above | 5 |
| 10 (V) | Ground | UART communication (TX) | Output | Ignition switch ON | | |



AUTOMATIC DRIVE POSITIONER CONTROL UNIT


< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | | Voltage (V) (Approx.) | A |
|------------------------------|--------|---|------------------|----------------------------|---------------------|---|---|
| + | - | Signal name | Input/ Output | | | | |
| 11 (GR) | Ground | Telescopic switch forward signal | Input | Telescopic switch | Operate (forward) | 0 | B |
| | | | | | Other than above | 5 | C |
| 12 (BG) | Ground | Memory indicator 1 signal | Output | Memory indicator 1 | Illuminate | 1 | D |
| | | | | | Other than above | Battery voltage | E |
| 13 (P) | Ground | Memory indicator 2 signal | Output | Memory indicator 2 | Illuminate | 1 | F |
| | | | | | Other than above | Battery voltage | G |
| 14 (W) | Ground | Door mirror motor (RH) upward output | Output | Door mirror RH | Operate (upward) | Battery voltage | H |
| | | | | | Other than above | 0 | I |
| 15 (BG) | Ground | Door mirror motor (RH) leftward output | Output | Door mirror RH | Operate (leftward) | Battery voltage | J |
| | | | | | Other than above | 0 | K |
| 16 (Y) | Ground | Door mirror motor (LH) downward output | Output | Door mirror (LH) | Operate (downward) | Battery voltage | L |
| | | | | | Other than above | 0 | M |
| | | Door mirror motor (LH) rightward output | | | Operate (rightward) | Battery voltage | N |
| | | | | | Other than above | 0 | O |
| 17 (BR) | Ground | Tilt switch downward signal | Input | Tilt switch | Operate (downward) | 0 | P |
| | | | | | Other than above | 5 | Q |
| 18 (W) | Ground | Changeover switch LH signal | Input | Changeover switch position | LH | 0 | R |
| | | | | | Neutral or RH | 5 | S |
| 19 (SB) | Ground | Mirror switch downward signal | Input | Mirror switch | Operate (downward) | 0 | T |
| | | | | | Other than above | 5 | U |
| 20 (L) | Ground | Mirror switch rightward signal | Input | Mirror switch | Operate (rightward) | 0 | V |
| | | | | | Other than above | 5 | W |
| 21 (L) | Ground | Door mirror sensor (RH) leftward/rightward signal | Input | Door mirror RH position | | Change between 3.4 (close to left edge) 0.6 (close to right edge) | X |
| 22 (B) | Ground | Door mirror sensor (LH) leftward/rightward signal | Input | Door mirror LH position | | Change between 0.6 (close to left edge) 3.4 (close to right edge) | Y |
| 23 (P) | Ground | Telescopic sensor signal | Input | Telescopic position | | Change between 0.8 (close to top) 4.4 (close to bottom) | Z |

ADP

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | | Voltage (V) (Approx.) |
|------------------------------|--------|--|------------------|---------------------|---|--------------------------|
| + | - | Signal name | Input/ Output | | | |
| 24 (R) | Ground | Set switch signal | Input | Set switch | Press | 0 |
| | | | | | Other than above | 5 |
| 25 (V) | Ground | Memory switch 2 signal | Input | Memory switch 2 | Press | 0 |
| | | | | | Other than above | 5 |
| 26 (P) | Ground | UART communication (RX) | Input | Ignition switch ON |  | |
| 27 (G) | Ground | Telescopic switch back- ward signal | Input | Telescopic switch | Operate (backward) | 0 |
| | | | | | Other than above | 5 |
| 30 (SB) | Ground | Door mirror motor (RH) downward output | Output | Door mirror (RH) | Operate (down- ward) | Battery voltage |
| | | Door mirror motor (RH) rightward output | | | Other than above | 0 |
| | | | | | Operate (rightward) | Battery voltage |
| | | | | | Other than above | 0 |
| 31 (G) | Ground | Door mirror motor (LH) upward output | Output | Door mirror (LH) | Operate (upward) | Battery voltage |
| | | | | | Other than above | 0 |
| 32 (L) | Ground | Door mirror motor (LH) leftward output | Output | Door mirror (LH) | Operate (leftward) | Battery voltage |
| | | | | | Other than above | 0 |
| 33 (W) | Ground | Sensor power supply | Input | — | 5 | |
| 34 (V) | Ground | Power source (Fuse) | Input | — | Battery voltage | |
| 35 (L) | Ground | Tilt motor upward output | Output | Steering tilt | Operate (upward) | Battery voltage |
| | | | | | Other than above | 0 |
| 36 (GR) | Ground | Telescopic motor forward output signal | Output | Steering telescopic | Operate (forward) | Battery voltage |
| | | | | | Other than above | 0 |
| 39 (W) | Ground | Power source (C/B) | Input | — | Battery voltage | |
| 40 (B) | Ground | Ground | — | — | 0 | |

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Voltage (V) (Approx.) | A | |
|------------------------------|--------|---------------------------------------|------------------|--------------------------|----------------------------|-----------------|---|
| + | - | Signal name | Input/ Output | | | B | |
| 41 (Y) | Ground | Sensor ground | — | — | 0 | C | |
| 42 (BG) | Ground | Tilt motor downward out- put | Output | Steering tilt | Operate (down- ward) | Battery voltage | D |
| | | | | | Other than above | 0 | E |
| 44 (G) | Ground | Telescopic motor back- ward output | Output | Steering telescop- ic | Operate (backward) | Battery voltage | F |
| | | | | | Other than above | 0 | G |
| 48 (B) | Ground | Ground | — | — | 0 | H | |


ADP


AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Wiring Diagram - AUTOMATIC DRIVE POSITIONER CONTROL SYSTEM -

INFOID:000000008788114

For connector terminal arrangements, harness layouts, and alphabets in a  (option abbreviation; if not described in wiring diagram), refer to [GI-12, "Connector Information"](#).




2010/10/07

JCJWM1762GB

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >



MANUAL FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

MANUAL FUNCTION DOES NOT OPERATE

ALL COMPONENT

ALL COMPONENT : Description

INFOID:000000008163736

All functions do not operate when manually operated.(power seat, tilt & telescopic, and door mirror.

ALL COMPONENT : Diagnosis Procedure

INFOID:000000008163737

1.CHECK DRIVER SEAT CONTROL UNIT POWER SUPPLY AND GROUND CIRCUIT

Check driver seat control unit power supply and ground circuit.

Refer to [ADP-64. "DRIVER SEAT CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK AUTOMATIC DRIVE POSITIONER CONTROL UNIT POWER SUPPLY AND GROUND CIRCUIT

Check automatic drive positioner control unit power supply and ground circuit.

Refer to [ADP-65. "AUTOMATIC DRIVE POSITIONER CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-43. "Intermittent Incident"](#).

NO >> GO TO 1.

POWER SEAT

POWER SEAT : Description

INFOID:000000008163738

Power seat does not operate when manually operated.

POWER SEAT : Diagnosis Procedure

INFOID:000000008163739

1.CHECK POWER SEAT SWITCH GROUND CIRCUIT

Check power seat switch ground circuit.

Refer to [ADP-95. "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness or connector.

2.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-43. "Intermittent Incident"](#).

NO >> GO TO 1.

STEERING POSITION FUNCTION DOES NOT OPERATE

STEERING POSITION FUNCTION DOES NOT OPERATE : Description

INFOID:000000008163740

Tilt & telescopic do not operate when manually operated.

A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O

P

MANUAL FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

STEERING POSITION FUNCTION DOES NOT OPERATE : Diagnosis Procedure

INFOID:000000008163741

1.CHECK TILT & TELESCOPIC SWITCH GROUND CIRCUIT

Check tilt & telescopic switch ground circuit.

Refer to [ADP-96, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness or connector.

2.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> GO TO 1.

SEAT SLIDING

SEAT SLIDING : Description

INFOID:000000008163742

Seat sliding alone does not operate when manually operated.

SEAT SLIDING : Diagnosis Procedure

INFOID:000000008163743

1.CHECK SLIDING MECHANISM

Check for the following.

- Mechanism deformation or pinched foreign materials.
- Interference with other parts because of poor installation.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK SLIDING SWITCH

Check sliding switch.

Refer to [ADP-67, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CHECK SLIDING MOTOR

Check sliding motor.

Refer to [ADP-124, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4.CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> GO TO 1.

SEAT RECLINING

SEAT RECLINING : Description

INFOID:000000008163744

Seat reclining only does not operate when manually operated.

MANUAL FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

SEAT RECLINING : Diagnosis Procedure

INFOID:000000008163745

1.CHECK RECLINING MECHANISM

Check for the following.

- Mechanism deformation or pinched foreign materials.
- Interference with other parts because of poor installation.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK RECLINING SWITCH

Check reclining switch.

Refer to [ADP-104. "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CHECK RECLINING MOTOR

Check reclining motor.

Refer to [ADP-126. "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4.CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-43. "Intermittent Incident"](#).

NO >> GO TO 1.

SEAT LIFTING (FRONT)

ADP

SEAT LIFTING (FRONT) : Description

INFOID:000000008163746

Seat lifting (front) only does not operate when manually operated.

SEAT LIFTING (FRONT) : Diagnosis Procedure

INFOID:000000008163747

1.CHECK LIFTING (FRONT) MECHANISM

Check for the following.

- Mechanism deformation or pinched foreign materials.
- Interference with other parts because of poor installation.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK LIFTING SWITCH (FRONT)

Check lifting switch (front).

Refer to [ADP-71. "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CHECK LIFTING MOTOR (FRONT)

Check lifting motor (front).

Refer to [ADP-128. "Component Function Check"](#).

Is the inspection result normal?

MANUAL FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

- YES >> GO TO 4.
NO >> Repair or replace the malfunctioning parts.

4.CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

- YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).
NO >> GO TO 1.

SEAT LIFTING (REAR)

SEAT LIFTING (REAR) : Description

INFOID:000000008163748

Seat lifting (rear) only does not operate when manually operated.

SEAT LIFTING (REAR) : Diagnosis Procedure

INFOID:000000008163749

1.CHECK LIFTING (REAR) MECHANISM

Check for the following.

- Mechanism deformation or pinched foreign materials.
- Interference with other parts because of poor installation.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace the malfunctioning parts.

2.CHECK LIFTING SWITCH (REAR)

Check lifting switch (rear).

Refer to [ADP-73, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace the malfunctioning parts.

3.CHECK LIFTING MOTOR (REAR)

Check lifting motor (rear).

Refer to [ADP-130, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace the malfunctioning parts.

4.CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

- YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).
NO >> GO TO 1.

STEERING TILT

STEERING TILT : Description

INFOID:000000008163750

Steering tilt only does not operate when manually operated.

STEERING TILT : Diagnosis Procedure

INFOID:000000008163751

1.CHECK STEERING TILT MECHANISM

Check for the following.

- Mechanism deformation or pinched foreign materials.
- Interference with other parts because of poor installation.

Is the inspection result normal?

- YES >> GO TO 2.

MANUAL FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

NO >> Repair or replace the malfunctioning parts.

2.CHECK TILT SWITCH

Check tilt switch.

Refer to [ADP-83, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CHECK TILT MOTOR

Check tilt motor.

Refer to [ADP-132, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4.CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> GO TO 1.

STEERING TELESCOPIC

STEERING TELESCOPIC : Description

INFOID:000000008163752

Steering telescopic only does not operate when manually operated.

STEERING TELESCOPIC : Diagnosis Procedure

INFOID:000000008163753

1.CHECK STEERING TELESCOPIC MECHANISM

Check for the following.

- Mechanism deformation or pinched foreign materials.
- Interference with other parts because of poor installation.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK TELESCOPIC SWITCH

Check telescopic switch.

Refer to [ADP-85, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CHECK TELESCOPIC MOTOR

Check telescopic motor.

Refer to [ADP-134, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4.CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> GO TO 1.

DOOR MIRROR

A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O

P

MANUAL FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

DOOR MIRROR : Description

INFOID:000000008163754

Door mirror does not operate when manually operated.

DOOR MIRROR : Diagnosis Procedure

INFOID:000000008163755

1.CHECK DOOR MIRROR MECHANISM

Check for the following.

- Mechanism deformation or pinched foreign materials.
- Interference with other parts because of poor installation.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK MIRROR SWITCH

Check mirror switch.

Refer to [ADP-90. "MIRROR SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CHECK MIRROR MOTOR

Check mirror motor.

Refer to [ADP-136. "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4.CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-43. "Intermittent Incident"](#).

NO >> GO TO 1.

MEMORY FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

MEMORY FUNCTION DOES NOT OPERATE

ALL COMPONENT

ALL COMPONENT : Description

INFOID:000000008163756

All functions do not operate when memory operated. (power seat, tilt & telescopic, and door mirror)

ALL COMPONENT : Diagnosis Procedure

INFOID:000000008163757

1.CHECK MANUAL OPERATION

Check manual operation.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refer to [ADP-189, "ALL COMPONENT : Diagnosis Procedure"](#)

2.PERFORM MEMORY STORING PROCEDURE

Perform memory storing procedure.

Refer to [ADP-10, "MEMORY STORING : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> Memory function is normal.

NO >> GO TO 3.

3.CHECK SEAT MEMORY SWITCH

Check seat memory switch.

Refer to [ADP-87, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace seat memory switch.

4.CHECK DETENTION SWITCH

Check detention switch.

Refer to [ADP-97, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> GO TO 1.

SEAT SLIDING

SEAT SLIDING : Description

INFOID:000000008163758

Seat sliding only does not operate when memory operated.

SEAT SLIDING : Diagnosis Procedure

INFOID:000000008163759

1.CHECK MANUAL OPERATION

Check manual operation.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refer to [ADP-190, "SEAT SLIDING : Diagnosis Procedure"](#)

2.CHECK SLIDING SENSOR

Check sliding sensor.

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

MEMORY FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

Refer to [ADP-101, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> GO TO 1.

SEAT RECLINING

SEAT RECLINING : Description

INFOID:000000008163760

Seat reclining only does not operate when memory operated.

SEAT RECLINING : Diagnosis Procedure

INFOID:000000008163761

1.CHECK MANUAL OPERATION

Check manual operation.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refer to [ADP-191, "SEAT RECLINING : Diagnosis Procedure"](#)

2.CHECK RECLINING SENSOR

Check reclining sensor.

Refer to [ADP-104, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> GO TO 1.

SEAT LIFTING (FRONT)

SEAT LIFTING (FRONT) : Description

INFOID:000000008163762

Seat lifting (front) only does not operate when memory operated.

SEAT LIFTING (FRONT) : Diagnosis Procedure

INFOID:000000008163763

1.CHECK MANUAL OPERATION

Check manual operation.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refer to [ADP-191, "SEAT LIFTING \(FRONT\) : Diagnosis Procedure"](#)

2.CHECK LIFTING SENSOR (FRONT)

Check lifting sensor (front).

Refer to [ADP-107, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

MEMORY FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

3.CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> GO TO 1.

SEAT LIFTING (REAR)

SEAT LIFTING (REAR) : Description

INFOID:000000008163764

Seat lifting (rear) only does not operate when memory operated.

SEAT LIFTING (REAR) : Diagnosis Procedure

INFOID:000000008163765

1.CHECK MANUAL OPERATION

Check manual operation.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refer to [ADP-192, "SEAT LIFTING \(REAR\) : Diagnosis Procedure"](#)

2.CHECK LIFTING SENSOR (REAR)

Check lifting sensor (rear).

Refer to [ADP-110, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> GO TO 1.

STEERING TELESCOPIC

STEERING TELESCOPIC : Description

INFOID:000000008163766

Steering telescopic only does not operate when memory operated.

STEERING TELESCOPIC : Diagnosis Procedure

INFOID:000000008163767

1.CHECK MANUAL OPERATION

Check manual operation.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refer to [ADP-193, "STEERING TELESCOPIC : Diagnosis Procedure"](#)

2.CHECK TELESCOPIC SENSOR

Check steering telescopic sensor.

Refer to [ADP-116, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O

P

MEMORY FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

NO >> GO TO 1.

STEERING TILT

STEERING TILT : Description

INFOID:000000008163768

Steering tilt only does not operate when memory operated.

STEERING TILT : Diagnosis Procedure

INFOID:000000008163769

1.CHECK MANUAL OPERATION

Check manual operation.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refer to [ADP-192, "STEERING TILT : Diagnosis Procedure"](#)

2.CHECK TILT SENSOR

Check steering tilt sensor.

Refer to [ADP-113, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> GO TO 1.

DOOR MIRROR

DOOR MIRROR : Description

INFOID:000000008163770

Door mirror does not operate when memory operated.

DOOR MIRROR : Diagnosis Procedure

INFOID:000000008163771

1.CHECK MANUAL OPERATION

Check manual operation.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refer to [ADP-194, "DOOR MIRROR : Diagnosis Procedure"](#)

2.CHECK MIRROR SENSOR

Check mirror sensor.

- Refer to [ADP-119, "DRIVER SIDE : Component Function Check"](#). (Driver side)
- Refer to [ADP-121, "PASSENGER SIDE : Component Function Check"](#). (Passenger side)

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> GO TO 1.

MEMORY INDICATE DOES NOT ILLUMINATE

< SYMPTOM DIAGNOSIS >

MEMORY INDICATE DOES NOT ILLUMINATE

Diagnosis Procedure

INFOID:000000008163772

1.CHECK MEMORY INDICATOR

Check memory indicator.

Refer to [ADP-139, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> GO TO 1.

A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O

P

SEAT SYNCHRONIZATION FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

SEAT SYNCHRONIZATION FUNCTION DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000008163773

1.CHECK SYSTEM SETTING

Check system setting.

Refer to [ADP-11, "SYSTEM SETTING : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> Synchronization function is normal.

NO >> GO TO 2.

2.CHECK ALL FUNCTIONS MAMUAL OPERATION

Check all functions manual operation.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Refer to [ADP-189, "ALL COMPONENT : Diagnosis Procedure"](#).

3.CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> GO TO 1.

POWER WALK-IN FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

POWER WALK-IN FUNCTION DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000008163774

1. CHECK POWER WALK-IN FUNCTION

Check power walk-in function.

Refer to [ADP-39, "POWER WALK-IN FUNCTION : System Description"](#).

Is the inspection result normal?

YES >> Power walk-in function is OK.

NO >> GO TO 2.

2. PERFORM INITIALIZATION PROCEDURE

1. Perform initialization procedure.

Refer to [ADP-10, "SYSTEM INITIALIZATION : Special Repair Requirement"](#).

2. Check power walk-in function.

Refer to [ADP-39, "POWER WALK-IN FUNCTION : System Description"](#).

Is the inspection result normal?

YES >> Power walk-in function is normal.

NO >> GO TO 3.

3. CHECK POWER WALK-IN SWITCH

Check power walk-in switch.

Refer to [ADP-81, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. CHECK SEAT BELT BUCKLE SWITCH

Check seat belt buckle switch.

Refer to [ADP-77, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5. CHECK FORWARD SWITCH

Check forward switch.

Refer to [ADP-75, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the malfunctioning parts.

6. CHECK SLIDING LIMIT SWITCH

Check sliding limit switch.

Refer to [ADP-79, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace the malfunctioning parts.

7. CHECK DRIVER SIDE DOOR SWITCH

Check driver side door switch.

Refer to [DLK-62, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair or replace the malfunctioning parts.

8. CONFIRM THE OPERATION

Check the operation again.

A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O

P

POWER WALK-IN FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

Refer to [ADP-39. "POWER WALK-IN FUNCTION : System Description"](#).

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-43. "Intermittent Incident"](#).

NO >> GO TO 1.

INTELLIGENT KEY INTERLOCK FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

INTELLIGENT KEY INTERLOCK FUNCTION DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000008163775

1. CHECK DOOR LOCK FUNCTION

Check door lock function.

Refer to [DLK-7, "Work Flow"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. PERFORM MEMORY STORING PROCEDURE

1. Perform memory storing procedure.

Refer to [ADP-10, "MEMORY STORING : Special Repair Requirement"](#).

2. Check Intelligent Key interlock function.

Refer to [ADP-34, "INTELLIGENT KEY INTERLOCK FUNCTION : System Description"](#).

Is the inspection result normal?

YES >> Intelligent Key inter lock function is normal.

NO >> GO TO 1.

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

NORMAL OPERATING CONDITION

Description

INFOID:000000008163776

The following symptoms are normal operations, and they do not indicate a malfunction.

| Symptom | Cause | Action to take | Reference page |
|---|--|--|---|
| Seat synchronization function does not operate. | The synchronization function will not operate if the steering (tilt, telescopic) or the door mirror moves to the operating end while the seat synchronization function is operating. | Perform the memory function or drive the vehicle at more than 7km/h (4 MPH). | ADP-24 |
| | Seat adjustment value has exceed any of the values below. <ul style="list-style-type: none"> • Seat sliding: 76 mm • Seat reclining: 9.1 degrees • Seat lifting (rear): 20 mm | — | — |
| Side support or lumbar support does not perform memory operation. | The side support and the lumbar support are controlled independently with no link to the automatic drive positioner system. | — | Side support: SE-23 |
| | | | Lumbar support: SE-26 |
| Memory function, power walk-in function, seat synchronization function, or Intelligent Key interlock function does not operate. | The operating conditions are not fulfilled. | Fulfill the operation conditions. | Memory function: ADP-29 |
| | | | Power walk-in function: ADP-39 |
| | | | Seat synchronization function: ADP-24 |
| | | | Intelligent Key interlock function: ADP-34 |

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000008163777

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precaution for Battery Service

INFOID:000000008163778

Before disconnecting the battery, lower both the driver and passenger windows. This will prevent any interference between the window edge and the vehicle when the door is opened/closed. During normal operation, the window slightly raises and lowers automatically to prevent any window to vehicle interference. The automatic window function will not work with the battery disconnected.

Service

INFOID:000000008163779

- When removing or installing various parts, place a cloth or padding onto the vehicle body to prevent scratches.
- Handle trim, molding, instruments, grille, etc. carefully during removing or installing. Be careful not to oil or damage them.
- Apply sealing compound where necessary when installing parts.
- When applying sealing compound, be careful that the sealing compound does not protrude from parts.
- When replacing any metal parts (for example body outer panel, members, etc.), be sure to take rust prevention measures.

Work

INFOID:000000008163780

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and keep them.

A
B
C
D
E
F
G
H
I
ADP
K
L
M
N
O
P

PRECAUTIONS

< PRECAUTION >

- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After re-installation is completed, be sure to check that each part works normally.
- Follow the steps below to clean components.
- Water soluble foul: Dip a soft cloth into lukewarm water, and wring the water out of the cloth to wipe the fouled area.
Then rub with a soft and dry cloth.
- Oily foul: Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%), and wipe the fouled area.
Then dip a cloth into fresh water, and wring the water out of the cloth to wipe the detergent off. Then rub with a soft and dry cloth.
- Do not use organic solvent such as thinner, benzene, alcohol, and gasoline.
- For genuine leather seats, use a genuine leather seat cleaner.

DRIVER SEAT CONTROL UNIT

< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION

DRIVER SEAT CONTROL UNIT

Exploded View

INFOID:000000008163781

Refer to [SE-163, "Exploded View"](#).

Removal and Installation


INFOID:000000008163782

REMOVAL

CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

1. Remove driver seat (1). Refer to [SE-166, "Removal and Installation"](#).
2. Remove mounting bolts (A).
3. Remove driver seat control unit (2).



INSTALLATION

Install in reverse order of removal.

CAUTION:

Be sure to clump the harness to the right place.

NOTE:

After installing driver seat, perform additional service when replacing control unit. Refer to [ADP-9, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< REMOVAL AND INSTALLATION >

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

Exploded View

INFOID:000000008163783

Refer to [IP-12, "A/T MODELS : Exploded View"](#) (A/T models) or [IP-23, "M/T MODELS : Exploded View"](#) (M/T models).

Removal and Installation


INFOID:000000008163784

REMOVAL

CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

1. Remove instrument driver lower panel. Refer to [IP-13, "A/T MODELS : Removal and Installation"](#) (A/T models) or [IP-24, "M/T MODELS : Removal and Installation"](#) (M/T models).
2. Remove screws (A).
3. Remove automatic drive positioner control unit (1).



JMJIA0198ZZ

INSTALLATION

Install in reverse order of removal.

CAUTION:

Be sure to clump the harness to the right place.

SEAT MEMORY SWITCH

< REMOVAL AND INSTALLATION >

SEAT MEMORY SWITCH

Exploded View

INFOID:000000008163785

Refer to [INT-12. "Exploded View"](#)

Removal and Installation


INFOID:000000008163786

REMOVAL

CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

1. Remove front door finisher (1). Refer to [INT-12. "Removal and Installation"](#).
2. Press pawls and remove seat memory switch (2) from front door finisher (1).



INSTALLATION

Install in reverse order of removal.

CAUTION:

Be sure to clump the harness to the right place.

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

POWER SEAT SWITCH

< REMOVAL AND INSTALLATION >

POWER SEAT SWITCH

Exploded View

INFOID:000000008163787

Refer to [SE-163. "Exploded View"](#).

Removal and Installation


INFOID:000000008163788

REMOVAL

CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

1. Remove seat cushion outer finisher (1). Refer to [SE-166. "Removal and Installation"](#).
2. Remove screws (A).
3. Remove power seat switch (2) from seat cushion outer finisher (1).



INSTALLATION

Install in reverse order of removal.

CAUTION:

Be sure to clump the harness to the right place.

SIDE SUPPORT SWITCH

< REMOVAL AND INSTALLATION >

SIDE SUPPORT SWITCH

Exploded View

INFOID:000000008163789

Refer to [SE-163. "Exploded View"](#)

Removal and Installation


INFOID:000000008163790

REMOVAL

CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

1. Remove seat cushion outer finisher (1). Refer to [SE-166. "Removal and Installation"](#)
2. Remove screws (A).
3. Remove side support switch (2) from seat cushion outer finisher.



INSTALLATION

Install in reverse order of removal.

CAUTION:

Be sure to clump the harness to the right place.

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

ADP

TILT&TELESCOPIC SWITCH

< REMOVAL AND INSTALLATION >

TILT&TELESCOPIC SWITCH

Exploded View

INFOID:000000008163791

Refer to [IP-12, "A/T MODELS : Exploded View"](#) (A/T models) or [IP-23, "M/T MODELS : Exploded View"](#) (M/T models).

Removal and Installation

INFOID:000000008163792


REMOVAL

CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

1. Remove steering column mask (1). Refer to [IP-13, "A/T MODELS : Removal and Installation"](#) (A/T models) or [IP-24, "M/T MODELS : Removal and Installation"](#) (M/T models).
2. Press pawls and remove tilt & telescopic switch (2) from steering column mask (1).

 Pawl



INSTALLATION

Install in reverse order of removal.

CAUTION:

Be sure to clump the harness to the right place.