

SECTION **BRC**

BRAKE CONTROL SYSTEM

A
B
C
D
E

CONTENTS

| | | |
|---|----|--|
| VDC/TCS/ABS | | |
| BASIC INSPECTION | 4 | |
| DIAGNOSIS AND REPAIR WORKFLOW | 4 | |
| Work Flow | 4 | |
| Diagnostic Work Sheet | 7 | |
| INSPECTION AND ADJUSTMENT | 8 | |
| ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT | 8 | |
| ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description | 8 | |
| ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement | 8 | |
| ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION | 8 | |
| ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description | 8 | |
| ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement | 8 | |
| SYSTEM DESCRIPTION | 10 | |
| VDC | 10 | |
| System Diagram | 10 | |
| System Description | 10 | |
| Component Parts Location | 11 | |
| Component Description | 13 | |
| TCS | 14 | |
| System Diagram | 14 | |
| System Description | 14 | |
| Component Parts Location | 15 | |
| Component Description | 17 | |
| ABS | 18 | |
| System Diagram | 18 | |
| System Description | 18 | |
| Component Parts Location | 19 | |
| Component Description | 21 | |
| EBD | 22 | |
| System Diagram | 22 | |
| System Description | 22 | |
| Component Parts Location | 23 | |
| Component Description | 25 | |
| DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)] | 26 | |
| CONSULT-III Function | 26 | |
| DTC/CIRCUIT DIAGNOSIS | 31 | |
| C1101, C1102, C1103, C1104 WHEEL SENSOR-1 | 31 | |
| Description | 31 | |
| DTC Logic | 31 | |
| Diagnosis Procedure | 31 | |
| Component Inspection | 33 | |
| Special Repair Requirement | 33 | |
| C1105, C1106, C1107, C1108 WHEEL SENSOR-2 | 34 | |
| Description | 34 | |
| DTC Logic | 34 | |
| Diagnosis Procedure | 34 | |
| Component Inspection | 36 | |
| Special Repair Requirement | 36 | |
| C1109 POWER AND GROUND SYSTEM | 37 | |
| Description | 37 | |
| DTC Logic | 37 | |
| Diagnosis Procedure | 37 | |
| Special Repair Requirement | 38 | |
| C1110, C1153, C1170 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) | 39 | |
| DTC Logic | 39 | |
| Diagnosis Procedure | 39 | |
| Special Repair Requirement | 39 | |

BRC

G
H
I
J
K
L
M
N
O
P

| | | | |
|---|-----------|--|-----------|
| C1111 ABS MOTOR, MOTOR RELAY SYSTEM | 40 | C1143, C1144 STEERING ANGLE SENSOR... | 59 |
| Description | 40 | Description | 59 |
| DTC Logic | 40 | DTC Logic | 59 |
| Diagnosis Procedure | 40 | Diagnosis Procedure | 59 |
| Component Inspection | 41 | Component Inspection | 60 |
| Special Repair Requirement | 41 | Special Repair Requirement | 60 |
| C1114 ACTUATOR RELAY SYSTEM | 42 | C1145, C1146 YAW RATE/SIDE G SENSOR... | 61 |
| Description | 42 | Description | 61 |
| DTC Logic | 42 | DTC Logic | 61 |
| Diagnosis Procedure | 42 | Diagnosis Procedure | 61 |
| Component Inspection | 43 | Component Inspection | 62 |
| Special Repair Requirement | 43 | Special Repair Requirement | 63 |
| C1115 WHEEL SENSOR | 44 | C1147, C1148, C1149, C1150 USV/HSV LINE.. | 64 |
| Description | 44 | Description | 64 |
| DTC Logic | 44 | DTC Logic | 64 |
| Diagnosis Procedure | 44 | Diagnosis Procedure | 64 |
| Component Inspection | 46 | Component Inspection | 65 |
| Special Repair Requirement | 46 | Special Repair Requirement | 66 |
| C1116 STOP LAMP SWITCH | 47 | C1155 BRAKE FLUID LEVEL SWITCH | 67 |
| Description | 47 | Description | 67 |
| DTC Logic | 47 | DTC Logic | 67 |
| Diagnosis Procedure | 47 | Diagnosis Procedure | 67 |
| Component Inspection | 48 | Component Inspection | 68 |
| Special Repair Requirement | 48 | Special Repair Requirement | 68 |
| C1120, C1122, C1124, C1126 IN ABS SOL | 49 | C1185 ICC UNIT | 69 |
| Description | 49 | Description | 69 |
| DTC Logic | 49 | DTC Logic | 69 |
| Diagnosis Procedure | 49 | Diagnosis Procedure | 69 |
| Component Inspection | 50 | Special Repair Requirement | 69 |
| Special Repair Requirement | 51 | U1000, U1002 CAN COMM CIRCUIT | 70 |
| C1121, C1123, C1125, C1127 OUT ABS SOL.. | 52 | Description | 70 |
| Description | 52 | DTC Logic | 70 |
| DTC Logic | 52 | Diagnosis Procedure | 70 |
| Diagnosis Procedure | 52 | Special Repair Requirement | 70 |
| Component Inspection | 53 | PARKING BRAKE SWITCH | 71 |
| Special Repair Requirement | 54 | Description | 71 |
| C1130, C1131, C1132 ENGINE SIGNAL | 55 | Component Function Check | 71 |
| Description | 55 | Diagnosis Procedure | 71 |
| DTC Logic | 55 | Component Inspection | 72 |
| Diagnosis Procedure | 55 | VDC OFF SWITCH | 73 |
| Special Repair Requirement | 55 | Description | 73 |
| C1138 4WAS SYSTEM | 56 | Component Function Check | 73 |
| Description | 56 | Diagnosis Procedure | 73 |
| DTC Logic | 56 | Component Inspection | 74 |
| Diagnosis Procedure | 56 | ABS WARNING LAMP | 75 |
| Special Repair Requirement | 56 | Description | 75 |
| C1142 PRESS SENSOR | 57 | Component Function Check | 75 |
| Description | 57 | Diagnosis Procedure | 75 |
| DTC Logic | 57 | BRAKE WARNING LAMP | 76 |
| Diagnosis Procedure | 57 | Description | 76 |
| Component Inspection | 58 | Component Function Check | 76 |
| Special Repair Requirement | 58 | Diagnosis Procedure | 76 |

| | | | | |
|---|----|--|-----|-----|
| VDC OFF INDICATOR LAMP | 77 | PREPARATION | 100 | A |
| Description | 77 | PREPARATION | 100 | |
| Component Function Check | 77 | Special Service Tool | 100 | B |
| Diagnosis Procedure | 77 | Commercial Service Tool | 100 | |
| SLIP INDICATOR LAMP | 78 | REMOVAL AND INSTALLATION | 101 | C |
| Description | 78 | WHEEL SENSOR | 101 | |
| Component Function Check | 78 | Exploded View | 101 | D |
| Diagnosis Procedure | 78 | Removal and Installation | 101 | |
| ECU DIAGNOSIS INFORMATION | 79 | SENSOR ROTOR | 102 | E |
| ABS ACTUATOR AND ELECTRIC UNIT | | FRONT SENSOR ROTOR | 102 | |
| (CONTROL UNIT) | 79 | FRONT SENSOR ROTOR : Exploded View | 102 | |
| Reference Value | 79 | FRONT SENSOR ROTOR : Removal and Instal- | 102 | |
| Wiring Diagram - BRAKE CONTROL SYSTEM - | 83 | lation | 102 | |
| Fail-Safe | 87 | REAR SENSOR ROTOR | 102 | BRC |
| DTC No. Index | 88 | REAR SENSOR ROTOR : Exploded View | 102 | |
| SYMPTOM DIAGNOSIS | 90 | REAR SENSOR ROTOR : Removal and Installa- | 102 | G |
| VDC/TCS/ABS | 90 | tion | 102 | |
| Symptom Table | 90 | ABS ACTUATOR AND ELECTRIC UNIT | | H |
| EXCESSIVE ABS FUNCTION OPERATION | | (CONTROL UNIT) | 104 | |
| FREQUENCY | 91 | Exploded View | 104 | |
| Diagnosis Procedure | 91 | Removal and Installation | 104 | |
| UNEXPECTED PEDAL REACTION | 92 | YAW RATE/SIDE G SENSOR | 106 | I |
| Diagnosis Procedure | 92 | Exploded View | 106 | |
| THE BRAKING DISTANCE IS LONG | 93 | Removal and Installation | 106 | J |
| Diagnosis Procedure | 93 | STEERING ANGLE SENSOR | 107 | |
| ABS FUNCTION DOES NOT OPERATE | 94 | Exploded View | 107 | |
| Diagnosis Procedure | 94 | Removal and Installation | 107 | K |
| PEDAL VIBRATION OR ABS OPERATION | | BRAKE ASSIST | | |
| SOUND OCCURS | 95 | SYSTEM DESCRIPTION | 108 | L |
| Diagnosis Procedure | 95 | PREVIEW FUNCTION | 108 | |
| VEHICLE JERKS DURING VDC/TCS/ABS | | System Description | 108 | M |
| CONTROL | 96 | Component Parts Location | 109 | |
| Diagnosis Procedure | 96 | Component Description | 110 | |
| NORMAL OPERATING CONDITION | 97 | DTC/CIRCUIT DIAGNOSIS | 111 | N |
| Description | 97 | PREVIEW FUNCTION | 111 | |
| PRECAUTION | 98 | Diagnosis Procedure | 111 | O |
| PRECAUTIONS | 98 | SYMPTOM DIAGNOSIS | 112 | |
| Precaution for Supplemental Restraint System | | NORMAL OPERATING CONDITION | 112 | P |
| (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- | | Description | 112 | |
| SIONER" | 98 | PRECAUTION | 113 | |
| Precaution for Procedure without Cowl Top Cover... 98 | | PRECAUTIONS | 113 | |
| Precaution for Brake System | 98 | Precautions for Preview Function Service | 113 | |
| Precaution for Brake Control | 99 | | | |

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000004242348

PRECAUTIONS FOR DIAGNOSIS


If steering angle sensor, steering system parts, suspension system parts, 4WAS system parts, ABS actuator and electric unit (control unit) or tires have been replaced, or if wheel alignment has been adjusted, be sure to adjust neutral position of steering angle sensor before driving. Refer to [BRC-8, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

DIAGNOSIS AND REPAIR WORKFLOW

[VDC/TCS/ABS]

< BASIC INSPECTION >

OVERALL SEQUENCE



A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

DETAILED FLOW

1. COLLECT THE INFORMATION FROM THE CUSTOMER

Get the detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred) using the diagnosis worksheet. Refer to [BRC-7, "Diagnostic Work Sheet"](#).

>> GO TO 2.

DIAGNOSIS AND REPAIR WORKFLOW

[VDC/TCS/ABS]

< BASIC INSPECTION >

2. PERFORM THE SELF-DIAGNOSIS

Check the DTC display with the self-diagnosis function.

Is there any DTC displayed?

YES >> GO TO 3.

NO >> GO TO 4.

3. PERFORM THE SYSTEM DIAGNOSIS

Perform the diagnosis applicable to the displayed DTC. Refer to [BRC-88, "DTC No. Index"](#).

>> GO TO 7.

4. CHECK THE SYMPTOM THAT IS NOT CONSIDERED A SYSTEM MALFUNCTION

Check that the symptom is a normal operation that is not considered a system malfunction. Refer to [BRC-97, "Description"](#).

Is the symptom a normal operation?

YES >> INSPECTION END

NO >> GO TO 5.

5. CHECK THE WARNING LAMP AND INDICATOR LAMP FOR ILLUMINATION

Check that the warning lamp and indicator lamp illuminate.

- ABS warning lamp: Refer to [BRC-75, "Description"](#).
- Brake warning lamp: Refer to [BRC-76, "Description"](#).
- VDC OFF indicator lamp: Refer to [BRC-77, "Description"](#).
- SLIP indicator lamp: Refer to [BRC-78, "Description"](#).

Is ON/OFF timing normal?

YES >> GO TO 6.

NO >> GO TO 2.

6. PERFORM THE DIAGNOSIS BY SYMPTOM

Perform the diagnosis applicable to the symptom.

>> GO TO 7.

7. REPAIR OR REPLACE THE MALFUNCTIONING PARTS

Repair or replace the specified malfunctioning parts.

>> GO TO 8.

8. FINAL CHECK

Perform the self-diagnosis again, and check that the malfunction is repaired completely. After checking, erase the self-diagnosis memory.

Is no other DTC present and the repair completed?

YES >> INSPECTION END

NO >> GO TO 3.

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[VDC/TCS/ABS]

Diagnostic Work Sheet

INFOID:000000004242349

| | | | |
|---------------------------|---|---|--|
| Customer name MR/MS | Model & Year | VIN | |
| Engine # | Trans. | Mileage | |
| Incident Date | Manuf. Date | In Service Date | |
| Symptoms | <input type="checkbox"/> Noise and vibration (from engine compartment) <input type="checkbox"/> Noise and vibration (from axle) | <input type="checkbox"/> Warning / Indicator activate | <input type="checkbox"/> Firm pedal operation <input type="checkbox"/> Large stroke pedal operation |
| | <input type="checkbox"/> TCS does not work (Rear wheels slip when accelerating) | <input type="checkbox"/> ABS does not work (Wheels lock when braking) | <input type="checkbox"/> Lack of sense of acceleration |
| Engine conditions | <input type="checkbox"/> When starting <input type="checkbox"/> After starting | | |
| Road conditions | <input type="checkbox"/> Low friction road (<input type="checkbox"/> Snow <input type="checkbox"/> Gravel <input type="checkbox"/> Other) <input type="checkbox"/> Bumps / potholes | | |
| Driving conditions | <input type="checkbox"/> Full-acceleration <input type="checkbox"/> High speed cornering <input type="checkbox"/> Vehicle speed: Greater than 10 km/h (6 MPH) <input type="checkbox"/> Vehicle speed: 10 km/h (6 MPH) or less <input type="checkbox"/> Vehicle is stopped | | |
| Applying brake conditions | <input type="checkbox"/> Suddenly <input type="checkbox"/> Gradually | | |
| Other conditions | <input type="checkbox"/> Operation of electrical equipment <input type="checkbox"/> Shift change <input type="checkbox"/> Other descriptions | | |

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

SFIA3265E

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[VDC/TCS/ABS]

INSPECTION AND ADJUSTMENT

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description

INFOID:000000004242350

After replacing the ABS actuator and electric unit (control unit), perform the neutral position adjustment for the steering angle sensor.

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement

INFOID:000000004242351

1. PERFORM THE NEUTRAL POSITION ADJUSTMENT FOR THE STEERING ANGLE SENSOR

Perform the neutral position adjustment for the steering angle sensor.

>> Refer to [BRC-8, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description

INFOID:000000004242352

In case of doing work that applies to the list below, make sure to adjust neutral position of steering angle sensor before running vehicle.

×: Required –: Not required

| Situation | Adjustment of steering angle sensor neutral position |
|---|--|
| Removing/Installing ABS actuator and electric unit (control unit) | — |
| Replacing ABS actuator and electric unit (control unit) | × |
| Removing/Installing steering angle sensor | × |
| Replacing steering angle sensor | × |
| Removing/Installing 4WAS components | × |
| Replacing 4WAS components | × |
| Removing/Installing steering components | × |
| Replacing steering components | × |
| Removing/Installing suspension components | × |
| Replacing suspension components | × |
| Change tires to new ones | — |
| Tire rotation | — |
| Adjusting wheel alignment | × |

ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement

INFOID:000000004242353

ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

CAUTION:

To adjust neutral position of steering angle sensor, make sure to use CONSULT-III.
(Adjustment cannot be done without CONSULT-III.)

1. ALIGN THE VEHICLE STATUS

Stop vehicle with front wheels in straight-ahead position.

>> GO TO 2.

2. PERFORM THE NEUTRAL POSITION ADJUSTMENT FOR THE STEERING ANGLE SENSOR

INSPECTION AND ADJUSTMENT

[VDC/TCS/ABS]

< BASIC INSPECTION >

1. On the CONSULT-III screen, touch "WORK SUPPORT" and "ST ANG SEN ADJUSTMENT" in order.
2. Touch "START".

CAUTION:

Do not touch steering wheel while adjusting steering angle sensor.

3. After approximately 10 seconds, touch "END".

NOTE:

After approximately 60 seconds, it ends automatically.

4. Turn ignition switch OFF, then turn it ON again.

CAUTION:

Be sure to perform above operation.

>> GO TO 3.

3. CHECK DATA MONITOR

1. Run vehicle with front wheels in straight-ahead position, then stop.
2. Select "DATA MONITOR". Then make sure "STR ANGLE SIG" is within $0 \pm 2.5^\circ$.

Is the steering angle within the specified range?

YES >> GO TO 4.

NO >> Perform the neutral position adjustment for the steering angle sensor again, GO TO 1.

4. ERASE THE SELF-DIAGNOSIS MEMORY

Erase the self-diagnosis memories of the ABS actuator and electric unit (control unit), ECM, 4WAS and ICC.

- ABS actuator and electric unit (control unit): Refer to [BRC-26, "CONSULT-III Function"](#).
- ECM: Refer to [EC-112, "Diagnosis Description"](#).
- 4WAS
 - 4WAS FRONT CONTROL UNIT: Refer to [STC-40, "CONSULT-III Function \[4WAS\(FRONT\)\]"](#).
 - 4WAS MAIN CONTROL UNIT: Refer to [STC-44, "CONSULT-III Function \[4WAS\(MAIN\)/RAS/HICAS\]"](#).
- ICC: Refer to [CCS-37, "Diagnosis Description"](#).

Are the memories erased?

YES >> INSPECTION END


NO >> Check the items indicated by the self-diagnosis.

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

SYSTEM DESCRIPTION

VDC

System Diagram




System Description

INFOID:000000004242355

- Vehicle Dynamics Control system detects driver's steering operation amount and brake pedal travel from steering angle sensor and pressure sensor. Using information from yaw rate/side G sensor and wheel sensor, VDC judges driving condition (conditions of under steer and over steer) to improve vehicle driving stability by controlling brake application to 4 wheels and engine output.
- During VDC operation, it informs driver of system operation by flashing SLIP indicator lamp.
- Electrical system diagnosis by CONSULT-III is available.

For USA



A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

- | | | |
|---------------------------|------------------------|-----------------------|
| 1. Steering angle sensor | 2. ABS warning lamp | 3. Brake warning lamp |
| 4. VDC OFF indicator lamp | 5. SLIP indicator lamp | 6. Front wheel sensor |

JSFIA0024ZZ


VDC

[VDC/TCS/ABS]

< SYSTEM DESCRIPTION >

- 7. ABS actuator and electric unit (control unit)
- 8. VDC OFF switch
- 9. Yaw rate/side G sensor
- 10. Rear wheel sensor
- A. Back of spiral cable assembly
- B. Combination meter
- C. Steering knuckle
- D. Inside brake master cylinder cover
- E. Instrument driver lower panel
- F. Under center console
- G. Rear final drive assembly

For Canada



JSFIA0005ZZ

VDC

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

- | | | | |
|--|----------------------------------|---------------------------|---|
| 1. Steering Angle sensor | 2. ABS warning lamp | 3. Brake warning lamp | A |
| 4. VDC OFF indicator lamp | 5. SLIP indicator lamp | 6. Front wheel sensor | |
| 7. ABS actuator and electric unit (control unit) | 8. VDC OFF switch | 9. Yaw rate/side G sensor | B |
| 10. Rear wheel sensor | | | |
| A. Back of spiral cable assembly | B. Combination meter | C. Steering knuckle | C |
| D. Inside brake master cylinder cover | E. Instrument driver lower panel | F. Under center console | |
| G. Rear final drive assembly | | | |

Component Description

INFOID:000000004242357


| Component parts | | Reference |
|---|--|---------------------------------------|
| ABS actuator and electric unit (control unit) | Pump | BRC-40, "Description" |
| | Motor | |
| | Actuator relay (Main relay) | BRC-42, "Description" |
| | Solenoid valve | BRC-49, "Description" |
| | Pressure sensor | BRC-57, "Description" |
| | VDC switch-over valve (USV1, USV2, HSV1, HSV2) | BRC-64, "Description" |
| Wheel sensor | BRC-31, "Description" | |
| Yaw rate/side G sensor | BRC-61, "Description" | |
| Steering angle sensor | BRC-59, "Description" | |
| VDC OFF switch | BRC-73, "Description" | |
| ABS warning lamp | BRC-75, "Description" | |
| Brake warning lamp | BRC-76, "Description" | |
| VDC OFF indicator lamp | BRC-77, "Description" | |
| SLIP indicator lamp | BRC-78, "Description" | |

BRC

TCS

System Diagram

INFOID:000000004242358



System Description

INFOID:000000004242359

- Traction Control System is a function that electronically controls engine torque, brake fluid pressure and A/T gear position to ensure the optimum slippage ratio at drive wheels by computing wheel speed signals from 4 wheel sensors. When ABS actuator and electric unit (control unit) detects a spin at drive wheels (rear wheels), it compares wheel speed signals from all 4 wheels. At this time, LH and RH rear brake fluid pressure are controlled, while fuel being cut to engine and throttle valve being closed to reduce engine torque by the control unit. Further more, throttle position is continuously controlled to ensure the optimum engine torque at all times.
- During TCS operation, it informs driver of system operation by flashing SLIP indicator lamp.
- Electrical system diagnosis by CONSULT-III is available.

TCS


[VDC/TCS/ABS]

< SYSTEM DESCRIPTION >

Component Parts Location

INFOID:000000004242360

For USA



- | | | |
|---------------------------|------------------------|-----------------------|
| 1. Steering angle sensor | 2. ABS warning lamp | 3. Brake warning lamp |
| 4. VDC OFF indicator lamp | 5. SLIP indicator lamp | 6. Front wheel sensor |

JSFIA0024ZZ

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P


TCS

[VDC/TCS/ABS]

< SYSTEM DESCRIPTION >

- 7. ABS actuator and electric unit (control unit)
- 8. VDC OFF switch
- 9. Yaw rate/side G sensor
- 10. Rear wheel sensor
- A. Back of spiral cable assembly
- B. Combination meter
- C. Steering knuckle
- D. Inside brake master cylinder cover
- E. Instrument driver lower panel
- F. Under center console
- G. Rear final drive assembly

For Canada



JSFIA0005ZZ

TCS

[VDC/TCS/ABS]

< SYSTEM DESCRIPTION >

- | | | | |
|--|----------------------------------|---------------------------|---|
| 1. Steering Angle sensor | 2. ABS warning lamp | 3. Brake warning lamp | A |
| 4. VDC OFF indicator lamp | 5. SLIP indicator lamp | 6. Front wheel sensor | B |
| 7. ABS actuator and electric unit (control unit) | 8. VDC OFF switch | 9. Yaw rate/side G sensor | C |
| 10. Rear wheel sensor | | | D |
| A. Back of spiral cable assembly | B. Combination meter | C. Steering knuckle | E |
| D. Inside brake master cylinder cover | E. Instrument driver lower panel | F. Under center console | F |
| G. Rear final drive assembly | | | G |

Component Description

INFOID:000000004242361


| Component parts | | Reference |
|---|--|---------------------------------------|
| ABS actuator and electric unit (control unit) | Pump | BRC-40, "Description" |
| | Motor | |
| | Actuator relay (Main relay) | BRC-42, "Description" |
| | Solenoid valve | BRC-49, "Description" |
| | Pressure sensor | BRC-57, "Description" |
| | VDC switch-over valve (USV1, USV2, HSV1, HSV2) | BRC-64, "Description" |
| Wheel sensor | BRC-31, "Description" | |
| Yaw rate/side G sensor | BRC-61, "Description" | |
| Steering angle sensor | BRC-59, "Description" | |
| VDC OFF switch | BRC-73, "Description" | |
| ABS warning lamp | BRC-75, "Description" | |
| Brake warning lamp | BRC-76, "Description" | |
| VDC OFF indicator lamp | BRC-77, "Description" | |
| SLIP indicator lamp | BRC-78, "Description" | |

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

ABS

System Diagram

INFOID:000000004242362



System Description

INFOID:000000004242363

- Anti-Lock Braking System is a function that detects wheel revolution while braking, electronically controls braking force, and prevents wheel locking during sudden braking. It improves handling stability and maneuverability for avoiding obstacles.
- Electrical system diagnosis by CONSULT-III is available.

ABS


< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

Component Parts Location

INFOID:000000004242364

For USA



- | | | |
|---------------------------|------------------------|-----------------------|
| 1. Steering angle sensor | 2. ABS warning lamp | 3. Brake warning lamp |
| 4. VDC OFF indicator lamp | 5. SLIP indicator lamp | 6. Front wheel sensor |

JSFIA0024ZZ

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P


ABS

[VDC/TCS/ABS]

< SYSTEM DESCRIPTION >

- 7. ABS actuator and electric unit (control unit)
- 8. VDC OFF switch
- 9. Yaw rate/side G sensor
- 10. Rear wheel sensor
- A. Back of spiral cable assembly
- B. Combination meter
- C. Steering knuckle
- D. Inside brake master cylinder cover
- E. Instrument driver lower panel
- F. Under center console
- G. Rear final drive assembly

For Canada



JSFIA0005ZZ

ABS

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

- | | | | |
|--|----------------------------------|---------------------------|---|
| 1. Steering Angle sensor | 2. ABS warning lamp | 3. Brake warning lamp | |
| 4. VDC OFF indicator lamp | 5. SLIP indicator lamp | 6. Front wheel sensor | A |
| 7. ABS actuator and electric unit (control unit) | 8. VDC OFF switch | 9. Yaw rate/side G sensor | |
| 10. Rear wheel sensor | | | B |
| A. Back of spiral cable assembly | B. Combination meter | C. Steering knuckle | |
| D. Inside brake master cylinder cover | E. Instrument driver lower panel | F. Under center console | C |
| G. Rear final drive assembly | | | |

Component Description

INFOID:000000004242365


| Component parts | Reference | |
|---|---------------------------------------|---------------------------------------|
| ABS actuator and electric unit (control unit) | Pump | BRC-40, "Description" |
| | Motor | |
| | Actuator relay (Main relay) | BRC-42, "Description" |
| | Solenoid valve | BRC-49, "Description" |
| Wheel sensor | BRC-31, "Description" | |
| ABS warning lamp | BRC-75, "Description" | |
| Brake warning lamp | BRC-76, "Description" | |

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

EBD

System Diagram

INFOID:000000004242366




System Description

INFOID:000000004242367

- Electric Brake force Distribution is a following function. ABS actuator and electric unit (control unit) detects subtle slippages between the front and rear wheels during braking. Then is electronically controls the rear braking force (brake fluid pressure) to reducing and reduces rear wheel slippage. Accordingly it improves vehicle stability.
- Electrical system diagnosis by CONSULT-III is available.

For USA



A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

- 1. Steering angle sensor
- 2. ABS warning lamp
- 3. Brake warning lamp
- 4. VDC OFF indicator lamp
- 5. SLIP indicator lamp
- 6. Front wheel sensor

JSFIA0024ZZ


EBD

[VDC/TCS/ABS]

< SYSTEM DESCRIPTION >

- 7. ABS actuator and electric unit (control unit)
- 8. VDC OFF switch
- 9. Yaw rate/side G sensor
- 10. Rear wheel sensor
- A. Back of spiral cable assembly
- B. Combination meter
- C. Steering knuckle
- D. Inside brake master cylinder cover
- E. Instrument driver lower panel
- F. Under center console
- G. Rear final drive assembly

For Canada



< SYSTEM DESCRIPTION >

- | | | |
|--|----------------------------------|---------------------------|
| 1. Steering Angle sensor | 2. ABS warning lamp | 3. Brake warning lamp |
| 4. VDC OFF indicator lamp | 5. SLIP indicator lamp | 6. Front wheel sensor |
| 7. ABS actuator and electric unit (control unit) | 8. VDC OFF switch | 9. Yaw rate/side G sensor |
| 10. Rear wheel sensor | | |
| A. Back of spiral cable assembly | B. Combination meter | C. Steering knuckle |
| D. Inside brake master cylinder cover | E. Instrument driver lower panel | F. Under center console |
| G. Rear final drive assembly | | |

A
B
C
D

Component Description

INFOID:000000004242369

| Component parts | | Reference |
|---|-----------------------------|---------------------------------------|
| ABS actuator and electric unit (control unit) | Pump | BRC-40, "Description" |
| | Motor | |
| | Actuator relay (Main relay) | BRC-42, "Description" |
| | Solenoid valve | BRC-49, "Description" |
| Wheel sensor | | BRC-31, "Description" |
| ABS warning lamp | | BRC-75, "Description" |
| Brake warning lamp | | BRC-76, "Description" |

E

BRC

G

H

I

J

K

L

M

N

O

P

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

CONSULT-III Function

INFOID:000000004242370

FUNCTION

CONSULT-III can display each diagnostic item using the diagnostic test modes shown following.

| Diagnostic test mode | Function |
|-------------------------|--|
| Work support | This mode enables a technician to adjust some devices faster and more accurately by following the indications on CONSULT-III. |
| Self-diagnostic results | Self-diagnostic results can be read and erased quickly. |
| Data monitor | Input/Output data in the ABS actuator and electric unit (control unit) can be read. |
| Active test | Diagnostic test mode is which CONSULT-III drives some actuators apart from the ABS actuator and electric unit (control unit) and also shifts some parameters in a specified range. |
| ECU part number | ABS actuator and electric unit (control unit) part number can be read. |

SELF-DIAG RESULTS MODE

Operation Procedure

Before performing the self-diagnosis, start engine and drive vehicle at 30 km/h (19 MPH) or more for approximately 1 minute.

How to Erase Self-diagnosis Results

After erasing DTC memory, start engine and drive vehicle at 30 km/h (19 MPH) or more for approximately 1 minute as the final inspection, and make sure that the ABS warning lamp, VDC OFF indicator lamp, SLIP indicator lamp and brake warning lamp turn OFF.

CAUTION:

If memory cannot be erased, perform applicable diagnosis.

NOTE:

- When the wheel sensor malfunctions, after inspecting the wheel sensor system, the ABS warning lamp, VDC OFF indicator lamp, SLIP indicator lamp and brake warning lamp will not turn OFF even when the system is normal unless the vehicle is driving at approximately 30 km/h (19 MPH) or more for approximately 1 minute.
- Brake warning lamp will turn ON in case of parking brake operation (when switch is ON) or of brake fluid level switch operation (when brake fluid is insufficient).
- VDC OFF switch should not stay "ON" position.

Display Item List

Refer to [BRC-88, "DTC No. Index"](#).

DATA MONITOR MODE

Display Item List

×: Applicable ▼: Optional item

| Monitor item (Unit) | SELECT MONITOR ITEM | | Remarks |
|---------------------------|---------------------|--------------|--------------------------------|
| | ECU INPUT SIGNALS | MAIN SIGNALS | |
| FR LH SENSOR [km/h (MPH)] | × | × | Wheel speed |
| FR RH SENSOR [km/h (MPH)] | × | × | |
| RR LH SENSOR [km/h (MPH)] | × | × | |
| RR RH SENSOR [km/h (MPH)] | × | × | |
| STOP LAMP SW (On/Off) | × | × | Stop lamp switch signal status |

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

| Monitor item (Unit) | SELECT MONITOR ITEM | | Remarks | | |
|-----------------------------------|---------------------|--------------|--|---------------------------------|---|
| | ECU INPUT SIGNALS | MAIN SIGNALS | | | |
| BATTERY VOLT (V) | × | × | Battery voltage supplied to the ABS actuator and electric unit (control unit) | A | |
| GEAR | × | × | Gear position determined by TCM | B | |
| SLCT LVR POSI | × | × | A/T selector lever position | C | |
| OFF SW (On/Off) | × | × | VDC OFF switch | | |
| YAW RATE SEN (d/s) | × | × | Yaw rate detected by yaw rate/side G sensor | D | |
| 4WD MODE MON | × | × | AWD activated (only AWD models) | | |
| ACCEL POS SIG (%) | × | ▼ | Throttle actuator opening/closing is displayed (Linked with accelerator pedal) | E | |
| SIDE G-SENSOR (m/s ²) | × | ▼ | Transverse G detected by yaw rate/side G sensor | BRC | |
| STR ANGLE SIG (°) | × | ▼ | Steering angle detected by steering angle sensor | | |
| PRESS SENSOR (bar) | × | ▼ | Brake fluid pressure detected by pressure sensor | G | |
| ENGINE RPM [tr/min (rpm)] | × | ▼ | Engine speed | H | |
| FLUID LEV SW (On/Off) | × | ▼ | Brake fluid level switch signal status | | |
| PARK BRAKE SW (On/Off) | × | ▼ | Parking brake switch signal status | I | |
| FR RH IN SOL (On/Off) | ▼ | × | Operation status of each solenoid valve | J | |
| FR RH OUT SOL (On/Off) | ▼ | × | | K | |
| FR LH IN SOL (On/Off) | ▼ | × | | L | |
| FR LH OUT SOL (On/Off) | ▼ | × | | M | |
| RR RH IN SOL (On/Off) | ▼ | × | | N | |
| RR RH OUT SOL (On/Off) | ▼ | × | | | |
| RR LH IN SOL (On/Off) | ▼ | × | | | |
| RR LH OUT SOL (On/Off) | ▼ | × | | | |
| MOTOR RELAY (On/Off) | ▼ | × | | Motor and motor relay operation | O |
| ACTUATOR RLY (On/Off) | ▼ | × | | Actuator relay operation | |
| ABS WARN LAMP (On/Off) | ▼ | × | ABS warning lamp | P | |
| OFF LAMP (On/Off) | ▼ | × | VDC OFF indicator lamp | | |
| SLIP LAMP (On/Off) | ▼ | × | SLIP indicator lamp | | |
| BST OPER SIG | ▼ | ▼ | Not applied but displayed. | | |

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

| Monitor item (Unit) | SELECT MONITOR ITEM | | Remarks |
|--------------------------|---------------------|--------------|---|
| | ECU INPUT SIGNALS | MAIN SIGNALS | |
| EBD SIGNAL (On/Off) | ▼ | ▼ | EBD operation |
| ABS SIGNAL (On/Off) | ▼ | ▼ | ABS operation |
| TCS SIGNAL (On/Off) | ▼ | ▼ | TCS operation |
| VDC SIGNAL (On/Off) | ▼ | ▼ | VDC operation |
| EBD FAIL SIG (On/Off) | ▼ | ▼ | EBD fail-safe signal |
| ABS FAIL SIG (On/Off) | ▼ | ▼ | ABS fail-safe signal |
| TCS FAIL SIG (On/Off) | ▼ | ▼ | TCS fail-safe signal |
| VDC FAIL SIG (On/Off) | ▼ | ▼ | VDC fail-safe signal |
| CRANKING SIG (On/Off) | ▼ | ▼ | Crank operation |
| USV [FR-RL] (On/Off) | ▼ | ▼ | VDC switch-over valve |
| USV [FL-RR] (On/Off) | ▼ | ▼ | |
| HSV [FR-RL] (On/Off) | ▼ | ▼ | |
| HSV [FL-RR] (On/Off) | ▼ | ▼ | |
| V/R OUTPUT (On/Off) | ▼ | ▼ | Solenoid valve relay activated |
| M/R OUTPUT (On/Off) | ▼ | ▼ | Actuator motor and motor relay activated |
| 4WD FAIL REQ (On/Off) | ▼ | ▼ | AWD control unit fail-safe signal (only AWD models) |
| SNOW MODE SW (On/Off) | ▼ | ▼ | SNOW mode switch |
| M-MODE SIG (On/Off) | ▼ | ▼ | Manual mode activated (only A/T models) |

ACTIVE TEST MODE

CAUTION:

- Do not perform active test while driving vehicle.
- Make sure to completely bleed air from brake system.
- The active test cannot be performed with the ABS warning lamp, VDC OFF indicator lamp, SLIP indicator lamp and brake warning lamp are on.
- ABS warning lamp, VDC OFF indicator lamp, SLIP indicator lamp and brake warning lamp are on during active test.
- Erase memory of ICC system after implementing active test.

NOTE:

- When active test is performed while depressing the pedal, the pedal depression amount will change. This is normal. (Only solenoid valve and ABS motor.)
- "TEST IS STOPPED" is displayed 10 seconds after operation start.
- After "TEST IS STOPPED" is displayed, to perform test again.

Test Item

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

ABS SOLENOID VALVE

- Touch “Up”, “Keep” and “Down”. Then use screen monitor to check that solenoid valve operates as shown in the table below.

| Test item | Display item (Note) | Display | | |
|-----------|---------------------|---------|------|------|
| | | Up | Keep | Down |
| FR RH SOL | FR RH IN SOL | Off | On | On |
| | FR RH OUT SOL | Off | Off | On* |
| | USV[FR-RL] | Off | Off | Off |
| | HSV[FR-RL] | Off | Off | Off |
| FR LH SOL | FR LH IN SOL | Off | On | On |
| | FR LH OUT SOL | Off | Off | On* |
| | USV[FL-RR] | Off | Off | Off |
| | HSV[FL-RR] | Off | Off | Off |
| RR RH SOL | RR RH IN SOL | Off | On | On |
| | RR RH OUT SOL | Off | Off | On* |
| | USV[FL-RR] | Off | Off | Off |
| | HSV[FL-RR] | Off | Off | Off |
| RR LH SOL | RR LH IN SOL | Off | On | On |
| | RR LH OUT SOL | Off | Off | On* |
| | USV[FR-RL] | Off | Off | Off |
| | HSV[FR-RL] | Off | Off | Off |

*: On for 1 to 2 seconds after the touch, and then Off.

NOTE:

A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is an operation for checking.

ABS SOLENOID VALVE (ACT)

- Touch “Up”, “ACT UP” and “ACT KEEP”. Then use screen monitor to check that solenoid valve operates as shown in the table below.

| Test item | Display item (Note) | Display | | |
|--------------------------|---------------------|---------|--------|----------|
| | | Up | ACT UP | ACT KEEP |
| FR RH ABS SOLENOID (ACT) | FR RH IN SOL | Off | Off | Off |
| | FR RH OUT SOL | Off | Off | Off |
| | USV[FR-RL] | Off | On | On |
| | HSV[FR-RL] | Off | On* | Off |
| FR LH ABS SOLENOID (ACT) | FR LH IN SOL | Off | Off | Off |
| | FR LH OUT SOL | Off | Off | Off |
| | USV[FL-RR] | Off | On | On |
| | HSV[FL-RR] | Off | On* | Off |
| RR RH ABS SOLENOID (ACT) | RR RH IN SOL | Off | Off | Off |
| | RR RH OUT SOL | Off | Off | Off |
| | USV[FL-RR] | Off | On | On |
| | HSV[FL-RR] | Off | On* | Off |
| RR LH ABS SOLENOID (ACT) | RR LH IN SOL | Off | Off | Off |
| | RR LH OUT SOL | Off | Off | Off |
| | USV[FR-RL] | Off | On | On |
| | HSV[FR-RL] | Off | On* | Off |

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

*: On for 1 to 2 seconds after the touch, and then Off.

NOTE:

A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is an operation for checking.

ABS MOTOR

- Touch "On" and "Off" on screen. Make sure motor relay and actuator relay operates as shown in table below.

| Test item | Display item | Display | |
|-----------|---------------------|---------|-----|
| | | On | Off |
| ABS MOTOR | MOTOR RELAY | On | Off |
| | ACTUATOR RLY (Note) | On | On |

NOTE:

A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is an operation for checking.

C1101, C1102, C1103, C1104 WHEEL SENSOR-1

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

DTC/CIRCUIT DIAGNOSIS

C1101, C1102, C1103, C1104 WHEEL SENSOR-1

Description

INFOID:000000004242371

When the sensor rotor rotates, the magnetic field changes. It converts the magnetic field changes to current signals (rectangular wave) and transmits them to the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000004242372

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|----------------|---|---|
| C1101 | RR RH SENSOR-1 | Circuit of rear RH wheel sensor is open. Or when the sensor power voltage is outside the standard. | <ul style="list-style-type: none">• Harness or connector• Wheel sensor• ABS actuator and electric unit (control unit) |
| C1102 | RR LH SENSOR-1 | Circuit of rear LH wheel sensor is open. Or when the sensor power voltage is outside the standard. | |
| C1103 | FR RH SENSOR-1 | Circuit of front RH wheel sensor is open. Or when the sensor power voltage is outside the standard. | |
| C1104 | FR LH SENSOR-1 | Circuit of front LH wheel sensor is open. Or when the sensor power voltage is outside the standard. | |

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

| Self-diagnosis results |
|------------------------|
| RR RH SENSOR-1 |
| RR LH SENSOR-1 |
| FR RH SENSOR-1 |
| FR LH SENSOR-1 |

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-31, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000004242373

CAUTION:

Do not check between wheel sensor terminals.

INSPECTION PROCEDURE

1. CHECK TIRES

Check air pressure, wear and size.

Are air pressure, wear and size within standard?

- YES >> GO TO 2.
NO >> Adjust air pressure, or replace tire.

2. CHECK SENSOR AND SENSOR ROTOR

- Check sensor rotor for damage.
- Check wheel sensor for damage, disconnection or looseness.

Are the sensor and sensor rotor normal?

- YES >> GO TO 3.
NO >> Repair wheel sensor mount or replace sensor rotor. Then perform the self-diagnosis.

C1101, C1102, C1103, C1104 WHEEL SENSOR-1

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

3. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check terminal to see if it is deformed, disconnected, loose, etc., Repair or replace it if any malfunction condition is found.
5. Reconnect connectors and then perform the self-diagnosis.

Is any item indicated on the self-diagnosis display?

YES >> GO TO 4.

NO >> Poor connection of connector terminal. Repair or replace connector.

4. CHECK WHEEL SENSOR HARNESS

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check continuity between terminals. (Also check continuity when steering wheel is turned right and left and when sensor harness inside the wheel house is moved.)

Measurement terminal for power supply circuit

| ABS actuator and electric unit (control unit) | | Wheel sensor | | Continuity |
|---|----------|----------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E41 | 9 | E27 (Front RH) | 1 | Existed |
| | 26 | E60 (Front LH) | | |
| | 7 | B33 (Rear RH) | | |
| | 6 | B34 (Rear LH) | | |

Measurement terminal for signal circuit

| ABS actuator and electric unit (control unit) | | Wheel sensor | | Continuity |
|---|----------|----------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E41 | 10 | E27 (Front RH) | 2 | Existed |
| | 5 | E60 (Front LH) | | |
| | 29 | B33 (Rear RH) | | |
| | 27 | B34 (Rear LH) | | |

Measurement terminal for ground circuit

| ABS actuator and electric unit (control unit) | | | | Continuity |
|---|----------|-----------|----------|-------------|
| Connector | Terminal | Connector | Terminal | |
| E41 | 9, 10 | E41 | 1, 4 | Not existed |
| | 26, 5 | | | |
| | 7, 29 | | | |
| | 6, 27 | | | |

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace malfunctioning components.

5. CHECK WHEEL SENSOR POWER SUPPLY CIRCUIT

1. Disconnect malfunctioning wheel sensor connector.
2. Turn ignition switch ON.
3. Check voltage between wheel sensor harness connector power supply terminal and ground.

C1101, C1102, C1103, C1104 WHEEL SENSOR-1

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

| Wheel sensor | | — | Voltage |
|----------------|----------|--------|-------------|
| Connector | Terminal | | |
| E27 (Front RH) | 1 | Ground | 8 V or more |
| E60 (Front LH) | | | |
| B33 (Rear RH) | | | |
| B34 (Rear LH) | | | |

Is the inspection result normal?

YES >> Replace applicable wheel sensor.

NO >> Replace ABS actuator and electric unit (control unit).

Component Inspection

INFOID:000000004242374

1. CHECK DATA MONITOR

On "DATA MONITOR", select "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR", and "RR RH SENSOR", and check the vehicle speed.

| Wheel sensor | Vehicle speed (DATA MONITOR) |
|--------------|--|
| FR LH SENSOR | Nearly matches the speedometer display ($\pm 10\%$ or less) |
| FR RH SENSOR | |
| RR LH SENSOR | |
| RR RH SENSOR | |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-31, "Diagnosis Procedure"](#).

Special Repair Requirement

INFOID:000000004242375

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-8, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

>> END

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

C1105, C1106, C1107, C1108 WHEEL SENSOR-2

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1105, C1106, C1107, C1108 WHEEL SENSOR-2

Description

INFOID:000000004242376

When the sensor rotor rotates, the magnetic field changes. It converts the magnetic field changes to current signals (rectangular wave) and transmits them to the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000004242377

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|----------------|--|---|
| C1105 | RR RH SENSOR-2 | When the circuit in the rear RH wheel sensor is short-circuited. Or when the distance between the wheel sensor and sensor rotor is too large and the sensor pulse cannot be recognized by the control unit. | <ul style="list-style-type: none">• Harness or connector• Wheel sensor• ABS actuator and electric unit (control unit) |
| C1106 | RR LH SENSOR-2 | When the circuit in the rear LH wheel sensor is short-circuited. Or when the distance between the wheel sensor and sensor rotor is too large and the sensor pulse cannot be recognized by the control unit. | |
| C1107 | FR RH SENSOR-2 | When the circuit in the front RH wheel sensor is short-circuited. Or when the distance between the wheel sensor and sensor rotor is too large and the sensor pulse cannot be recognized by the control unit. | |
| C1108 | FR LH SENSOR-2 | When the circuit in the front LH wheel sensor is short-circuited. Or when the distance between the wheel sensor and sensor rotor is too large and the sensor pulse cannot be recognized by the control unit. | |

DTC CONFIRMATION PROCEDURE

1.CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

| |
|------------------------|
| Self-diagnosis results |
| RR RH SENSOR-2 |
| RR LH SENSOR-2 |
| FR RH SENSOR-2 |
| FR LH SENSOR-2 |

Is above displayed on the self-diagnosis display?

YES >> Proceed to diagnosis procedure. Refer to [BRC-34. "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000004242378

CAUTION:

Do not check between wheel sensor terminals.

INSPECTION PROCEDURE

1.CHECK TIRES

Check air pressure, wear and size.

Are air pressure, wear and size within standard?

YES >> GO TO 2.

NO >> Adjust air pressure, or replace tire.

2.CHECK SENSOR AND SENSOR ROTOR

- Check sensor rotor for damage.

C1105, C1106, C1107, C1108 WHEEL SENSOR-2

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

- Check wheel sensor for damage, disconnection or looseness.

Are the sensor and sensor rotor normal?

YES >> GO TO 3.

NO >> Repair wheel sensor mount or replace sensor rotor. Then perform the self-diagnosis.

3.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check terminal to see if it is deformed, disconnected, loose, etc., Repair or replace it if any malfunction condition is found.
5. Reconnect connectors and then perform the self-diagnosis.

Is any item indicated on the self-diagnosis display?

YES >> GO TO 4.

NO >> Poor connection of connector terminal. Repair or replace connector.

4.CHECK WHEEL SENSOR HARNESS

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check continuity between terminals. (Also check continuity when steering wheel is turned right and left and when sensor harness inside the wheel house is moved.)

Measurement terminal for power supply circuit

| ABS actuator and electric unit (control unit) | | Wheel sensor | | Continuity |
|---|----------|----------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E41 | 9 | E27 (Front RH) | 1 | Existed |
| | 26 | E60 (Front LH) | | |
| | 7 | B33 (Rear RH) | | |
| | 6 | B34 (Rear LH) | | |

Measurement terminal for signal circuit

| ABS actuator and electric unit (control unit) | | Wheel sensor | | Continuity |
|---|----------|----------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E41 | 10 | E27 (Front RH) | 2 | Existed |
| | 5 | E60 (Front LH) | | |
| | 29 | B33 (Rear RH) | | |
| | 27 | B34 (Rear LH) | | |

Measurement terminal for ground circuit

| ABS actuator and electric unit (control unit) | | | | Continuity |
|---|----------|-----------|----------|-------------|
| Connector | Terminal | Connector | Terminal | |
| E41 | 9, 10 | E41 | 1, 4 | Not existed |
| | 26, 5 | | | |
| | 7, 29 | | | |
| | 6, 27 | | | |

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace malfunctioning components.

5.CHECK WHEEL SENSOR POWER SUPPLY CIRCUIT

1. Disconnect malfunctioning wheel sensor connector.
2. Turn ignition switch ON.

C1105, C1106, C1107, C1108 WHEEL SENSOR-2

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

3. Check voltage between wheel sensor harness connector power supply terminal and ground.

| Wheel sensor | | — | Voltage |
|----------------|----------|--------|-------------|
| Connector | Terminal | | |
| E27 (Front RH) | 1 | Ground | 8 V or more |
| E60 (Front LH) | | | |
| B33 (Rear RH) | | | |
| B34 (Rear LH) | | | |

Is the inspection result normal?

YES >> Replace applicable wheel sensor.

NO >> Replace ABS actuator and electric unit (control unit).

Component Inspection

INFOID:000000004242379

1. CHECK DATA MONITOR

On "DATA MONITOR", select "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR", and "RR RH SENSOR", and check the vehicle speed.

| Wheel sensor | Vehicle speed (DATA MONITOR) |
|--------------|--|
| FR LH SENSOR | Nearly matches the speedometer display ($\pm 10\%$ or less) |
| FR RH SENSOR | |
| RR LH SENSOR | |
| RR RH SENSOR | |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-44. "Diagnosis Procedure"](#).

Special Repair Requirement

INFOID:000000004242380

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-8. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

>> END

C1109 POWER AND GROUND SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1109 POWER AND GROUND SYSTEM

Description

INFOID:000000004242381

Supplies electric power to the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000004242382

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|----------------------------|---|--|
| C1109 | BATTERY VOLTAGE [ABNORMAL] | When the ABS actuator and electric unit (control unit) power supply voltage is lower than normal. | <ul style="list-style-type: none">• Harness or connector• ABS actuator and electric unit (control unit) |

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

| Self-diagnosis results |
|----------------------------|
| BATTERY VOLTAGE [ABNORMAL] |

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-37, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000004242383

INSPECTION PROCEDURE

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connectors and then perform the self-diagnosis.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2.
NO >> Poor connection of connector terminal. Repair or replace connector.

2. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY CIRCUIT AND GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Turn ignition switch ON or OFF and check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.

| ABS actuator and electric unit (control unit) | | — | Condition | Voltage |
|---|----------|--------|----------------------|-----------------|
| Connector | Terminal | | | |
| E41 | 28 | Ground | Ignition switch: ON | Battery voltage |
| | | | Ignition switch: OFF | Approx. 0 V |

4. Turn ignition switch OFF.
5. Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

C1109 POWER AND GROUND SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

| ABS actuator and electric unit (control unit) | | — | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| E41 | 1, 4 | Ground | Existed |

Is the inspection result normal?

YES >> Check battery for terminal looseness, low voltage, etc. If any malfunction is found, repair malfunctioning parts.

NO >> Repair or replace malfunctioning components.

Special Repair Requirement

INFOID:000000004242384

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-8, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

>> END

C1110, C1153, C1170 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

DTC Logic

INFOID:000000004242385

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|--------------------|---|---|
| C1110 | CONTROLLER FAILURE | When there is an internal malfunction in the ABS actuator and electric unit (control unit). | • ABS actuator and electric unit (control unit) |
| C1153 | EMERGENCY BRAKE | When ABS actuator and electric unit (control unit) is malfunctioning. (Pressure increase is too much or too little) | |
| C1170 | VARIANT CODING | In a case where VARIANT CODING is different. | |

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

| |
|------------------------|
| Self-diagnosis results |
| CONTROLLER FAILURE |
| EMERGENCY BRAKE |
| VARIANT CODING |

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-39, "Diagnosis Procedure"](#).
- NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000004242386

INSPECTION PROCEDURE

1. REPLACE ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

CAUTION:

Replace ABS actuator and electric unit (control unit) when self-diagnostic result shows items other than those applicable.

- >> Replace ABS actuator and electric unit (control unit).

Special Repair Requirement

INFOID:000000004242387

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-8, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

- >> END

C1111 ABS MOTOR, MOTOR RELAY SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1111 ABS MOTOR, MOTOR RELAY SYSTEM

Description

INFOID:000000004242388

PUMP

The pump returns the brake fluid stored in the reservoir to the master cylinder by reducing the pressure.

MOTOR

The motor drives the pump according to the signals transmitted by the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000004242389

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|--------------|--|--|
| C1111 | PUMP MOTOR | During the actuator motor operating with ON, when the actuator motor turns OFF, or when the control line for actuator motor relay is open. | <ul style="list-style-type: none">• Harness or connector• ABS actuator and electric unit (control unit) |
| | | During the actuator motor operating with OFF, when the actuator motor turns ON, or when the control line for relay is shorted to ground. | |

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

| Self-diagnosis results |
|------------------------|
| PUMP MOTOR |

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-40, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000004242390

INSPECTION PROCEDURE

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnect, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connectors and then perform the self-diagnosis.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2.
NO >> Poor connection of connector terminal. Repair or replace connector.

2. CHECK ABS MOTOR AND MOTOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check voltage between the ABS actuator and electric unit (control unit) harness connector terminal and ground.

| ABS actuator and electric unit (control unit) | | — | Voltage |
|---|----------|--------|-----------------|
| Connector | Terminal | | |
| E41 | 2 | Ground | Battery voltage |

C1111 ABS MOTOR, MOTOR RELAY SYSTEM

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace malfunctioning components.

3.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

| ABS actuator and electric unit (control unit) | | — | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| E41 | 1, 4 | Ground | Existed |

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit).
NO >> Repair or replace malfunctioning components.

Component Inspection

INFOID:000000004242391

1.CHECK ACTIVE TEST

BRC

1. On "ACTIVE TEST", select "ABS MOTOR".
2. Touch "On" and "Off" on screen. Make sure motor relay and actuator relay operates as shown in table below.

| Test item | Display item | Display | |
|-----------|---------------------|---------|-----|
| | | On | Off |
| ABS MOTOR | MOTOR RELAY | On | Off |
| | ACTUATOR RLY (Note) | On | On |

NOTE:

A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is an operation for checking.

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Go to diagnosis procedure. Refer to [BRC-40, "Diagnosis Procedure"](#).

Special Repair Requirement

INFOID:000000004242392

1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-8, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

>> END

C1114 ACTUATOR RELAY SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1114 ACTUATOR RELAY SYSTEM

Description

INFOID:000000004242393

Activates or deactivates each solenoid valve according to the signals transmitted by the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000004242394

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|--------------|--|---|
| C1114 | MAIN RELAY | During the actuator relay operating with OFF, when the actuator relay turns ON, or when the control line for the relay is shorted to the ground. | <ul style="list-style-type: none"> • Harness or connector • ABS actuator and electric unit (control unit) |
| | | During the actuator relay operating with ON, when the actuator relay turns ON, or when the control line for the relay is open. | |

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

| |
|------------------------|
| Self-diagnosis results |
| MAIN RELAY |

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-42, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000004242395

INSPECTION PROCEDURE

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connectors and then perform the self-diagnosis.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2.
 NO >> Poor connection of connector terminal. Repair or replace connector.

2. CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.

| ABS actuator and electric unit (control unit) | | — | Voltage |
|---|----------|--------|-----------------|
| Connector | Terminal | | |
| E41 | 3 | Ground | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair or replace malfunctioning components.

C1114 ACTUATOR RELAY SYSTEM

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

3.CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY GROUND CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

| ABS actuator and electric unit (control unit) | | — | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| E41 | 1, 4 | Ground | Existed |

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit).
NO >> Repair or replace malfunctioning components.

Component Inspection

INFOID:000000004242396

1.CHECK ACTIVE TEST

1. On "ACTIVE TEST", select "ABS MOTOR".
2. Touch "On" and "Off" on screen. Make sure motor relay and actuator relay operates as shown in table below.

| Test item | Display item | Display | |
|-----------|---------------------|---------|-----|
| | | On | Off |
| ABS MOTOR | MOTOR RELAY | On | Off |
| | ACTUATOR RLY (Note) | On | On |

NOTE:

A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is an operation for checking.

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Go to diagnosis procedure. Refer to [BRC-40, "Diagnosis Procedure"](#).

Special Repair Requirement

INFOID:000000004242397

1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-8, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

>> END

C1115 WHEEL SENSOR

Description

INFOID:000000004242398

When the sensor rotor rotates, the magnetic field changes. It converts the magnetic field changes to current signals (rectangular wave) and transmits them to the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000004242399

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|---------------------------------|---|---|
| C1115 | ABS SENSOR [ABNORMAL SIGNAL] | When wheel sensor input signal is malfunctioning. | <ul style="list-style-type: none"> Harness or connector Wheel sensor ABS actuator and electric unit (control unit) |

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

| |
|------------------------------|
| Self-diagnosis results |
| ABS SENSOR [ABNORMAL SIGNAL] |

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-44, "Diagnosis Procedure"](#).
- NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000004242400

CAUTION:

Do not check between wheel sensor terminals.

INSPECTION PROCEDURE

1. CHECK TIRES

Check air pressure, wear and size.

Are air pressure, wear and size within standard?

- YES >> GO TO 2.
- NO >> Adjust air pressure, or replace tire.

2. CHECK SENSOR AND SENSOR ROTOR

- Check sensor rotor for damage.
- Check wheel sensor for damage, disconnection or looseness.

Are the sensor and sensor rotor normal?

- YES >> GO TO 3.
- NO >> Repair wheel sensor mount or replace sensor rotor. Then perform the self-diagnosis.

3. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check terminal to see if it is deformed, disconnected, loose, etc., Repair or replace it if any malfunction condition is found.
5. Reconnect connectors and then perform the self-diagnosis.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 4.
- NO >> Poor connection of connector terminal. Repair or replace connector.

C1115 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

4. CHECK WHEEL SENSOR HARNESS

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check continuity between terminals. (Also check continuity when steering wheel is turned right and left and when sensor harness inside the wheel house is moved.)

Measurement terminal for power supply circuit

| ABS actuator and electric unit (control unit) | | Wheel sensor | | Continuity |
|---|----------|----------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E41 | 9 | E27 (Front RH) | 1 | Existed |
| | 26 | E60 (Front LH) | | |
| | 7 | B33 (Rear RH) | | |
| | 6 | B34 (Rear LH) | | |

Measurement terminal for signal circuit

| ABS actuator and electric unit (control unit) | | Wheel sensor | | Continuity |
|---|----------|----------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E41 | 10 | E27 (Front RH) | 2 | Existed |
| | 5 | E60 (Front LH) | | |
| | 29 | B33 (Rear RH) | | |
| | 27 | B34 (Rear LH) | | |

Measurement terminal for ground circuit

| ABS actuator and electric unit (control unit) | | | | Continuity |
|---|----------|-----------|----------|-------------|
| Connector | Terminal | Connector | Terminal | |
| E41 | 9, 10 | E41 | 1, 4 | Not existed |
| | 26, 5 | | | |
| | 7, 29 | | | |
| | 6, 27 | | | |

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> Repair or replace malfunctioning components.

5. CHECK WHEEL SENSOR POWER SUPPLY CIRCUIT

1. Disconnect malfunctioning wheel sensor connector.
2. Turn ignition switch ON.
3. Check voltage between wheel sensor harness connector power supply terminal and ground.

| Wheel sensor | | — | Voltage |
|----------------|----------|--------|-------------|
| Connector | Terminal | | |
| E27 (Front RH) | 1 | Ground | 8 V or more |
| E60 (Front LH) | | | |
| B33 (Rear RH) | | | |
| B34 (Rear LH) | | | |

Is the inspection result normal?

- YES >> Replace applicable wheel sensor.
 NO >> Replace ABS actuator and electric unit (control unit).

C1115 WHEEL SENSOR

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

INFOID:000000004242401

Component Inspection

1. CHECK DATA MONITOR

On "DATA MONITOR", select "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR", and "RR RH SENSOR", and check the vehicle speed.

| Wheel sensor | Vehicle speed (DATA MONITOR) |
|--------------|--|
| FR LH SENSOR | Nearly matches the speedometer display ($\pm 10\%$ or less) |
| FR RH SENSOR | |
| RR LH SENSOR | |
| RR RH SENSOR | |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-44, "Diagnosis Procedure"](#).

Special Repair Requirement

INFOID:000000004242402

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-8, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

>> END

C1116 STOP LAMP SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1116 STOP LAMP SWITCH

Description

INFOID:000000004242403

The stop lamp switch transmits the stop lamp switch signal (ON/OFF) to the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000004242404

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|--------------|--|---|
| C1116 | STOP LAMP SW | When stop lamp switch circuit is open. | <ul style="list-style-type: none">• Harness or connector• Stop lamp switch• ABS actuator and electric unit (control unit) |

DTC CONFIRMATION PROCEDURE

1.CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

| |
|------------------------|
| Self-diagnosis results |
| STOP LAMP SWITCH |

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-47, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000004242405

INSPECTION PROCEDURE

1.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect stop lamp switch connector.
4. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
5. Reconnect connectors securely.
6. Start engine.
7. Repeat pumping brake pedal carefully several times, and perform self-diagnosis.

Is DTC "C1116" detected?

- YES >> GO TO 2.
NO >> Poor connection of connector terminal. Repair or replace connector connection.

2.CHECK STOP LAMP SWITCH CLEARANCE

Check stop lamp switch clearance. Refer to [BR-7, "Inspection and Adjustment"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Adjust stop lamp switch clearance. Refer to [BR-7, "Inspection and Adjustment"](#).

3.CHECK STOP LAMP SWITCH

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch connector.
3. Check continuity between stop lamp switch connector terminals.

C1116 STOP LAMP SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

| Stop lamp switch | | Condition | Continuity |
|------------------|---|--|-------------|
| Connector | Terminal | | |
| E110 | 1 – 2 (Without ICC models) 3 – 4 (With ICC models) | Release stop lamp switch (When brake pedal is depressed.) | Existed |
| | | Push stop lamp switch (When brake pedal is released.) | Not existed |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace stop lamp switch.

4.CHECK STOP LAMP SWITCH CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Connect stop lamp switch connector.
3. Check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.

| ABS actuator and electric unit (control unit) | | Condition | Voltage |
|---|----------|--------------------------|-----------------|
| Connector | Terminal | | |
| E41 | 30 | Brake pedal is depressed | Battery voltage |
| | | Brake pedal is released | Approx. 0 V |

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace malfunctioning components.

Component Inspection

INFOID:000000004242406

1.CHECK STOP LAMP SWITCH

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch connector.
3. Check continuity between stop lamp switch connector terminals.

| Stop lamp switch | | Condition | Continuity |
|------------------|---|--|-------------|
| Connector | Terminal | | |
| E110 | 1 – 2 (Without ICC models) 3 – 4 (With ICC models) | Release stop lamp switch (When brake pedal is depressed.) | Existed |
| | | Push stop lamp switch (When brake pedal is released.) | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace stop lamp switch.

Special Repair Requirement

INFOID:000000004242407

1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-8, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

>> END

C1120, C1122, C1124, C1126 IN ABS SOL

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1120, C1122, C1124, C1126 IN ABS SOL

Description

INFOID:000000004242408

The solenoid valve increases, holds or decreases the fluid pressure of each brake caliper according to the signals transmitted by the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000004242409

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|------------------|---|---|
| C1120 | FR LH IN ABS SOL | When the control unit detects a malfunction in the front LH inlet solenoid circuit. | • ABS actuator and electric unit (control unit) |
| C1122 | FR RH IN ABS SOL | When the control unit detects a malfunction in the front RH inlet solenoid circuit. | |
| C1124 | RR LH IN ABS SOL | When the control unit detects a malfunction in the rear LH inlet solenoid circuit. | |
| C1126 | RR RH IN ABS SOL | When the control unit detects a malfunction in the rear RH inlet solenoid circuit. | |

DTC CONFIRMATION PROCEDURE

1.CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

| Self-diagnosis results |
|------------------------|
| FR LH IN ABS SOL |
| FR RH IN ABS SOL |
| RR LH IN ABS SOL |
| RR RH IN ABS SOL |

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-49. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000004242410

INSPECTION PROCEDURE

1.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connectors and then perform the self-diagnosis.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2.
NO >> Poor connection of connector terminal. Repair or replace connector.

2.CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.

C1120, C1122, C1124, C1126 IN ABS SOL

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

| | | | |
|---|----------|--------|-----------------|
| ABS actuator and electric unit (control unit) | | — | Voltage |
| Connector | Terminal | | |
| E41 | 3 | Ground | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair or replace malfunctioning components.

3.CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY GROUND CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

| | | | |
|---|----------|--------|------------|
| ABS actuator and electric unit (control unit) | | — | Continuity |
| Connector | Terminal | | |
| E41 | 1, 4 | Ground | Existed |

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit).
 NO >> Repair or replace malfunctioning components.

Component Inspection

INFOID:000000004242411

1.CHECK ACTIVE TEST

1. Select each test menu item on "ACTIVE TEST".
2. On the display, touch "Up", "Keep" and "Down", and check that the system operates as shown in the table below.

| Test item | Display item (Note) | Display | | |
|-----------|------------------------|---------|------|------|
| | | Up | Keep | Down |
| FR RH SOL | FR RH IN SOL | Off | On | On |
| | FR RH OUT SOL | Off | Off | On* |
| | USV[FR-RL] | Off | Off | Off |
| | HSV[FR-RL] | Off | Off | Off |
| FR LH SOL | FR LH IN SOL | Off | On | On |
| | FR LH OUT SOL | Off | Off | On* |
| | USV[FL-RR] | Off | Off | Off |
| | HSV[FL-RR] | Off | Off | Off |
| RR RH SOL | RR RH IN SOL | Off | On | On |
| | RR RH OUT SOL | Off | Off | On* |
| | USV[FL-RR] | Off | Off | Off |
| | HSV[FL-RR] | Off | Off | Off |
| RR LH SOL | RR LH IN SOL | Off | On | On |
| | RR LH OUT SOL | Off | Off | On* |
| | USV[FR-RL] | Off | Off | Off |
| | HSV[FR-RL] | Off | Off | Off |

*: On for 1 to 2 seconds after the touch, and then Off.

NOTE:

A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is an operation for checking.

Is the inspection result normal?

- YES >> INSPECTION END

C1120, C1122, C1124, C1126 IN ABS SOL

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

NO >> Go to diagnosis procedure. Refer to [BRC-49. "Diagnosis Procedure"](#).

Special Repair Requirement

INFOID:000000004242412

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-8. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

>> END

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

C1121, C1123, C1125, C1127 OUT ABS SOL

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1121, C1123, C1125, C1127 OUT ABS SOL

Description

INFOID:000000004242413

The solenoid valve increases, holds or decreases the fluid pressure of each brake caliper according to the signals transmitted by the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000004242414

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|-------------------|--|---|
| C1121 | FR LH OUT ABS SOL | When the control unit detects a malfunction in the front LH outlet solenoid circuit. | • ABS actuator and electric unit (control unit) |
| C1123 | FR RH OUT ABS SOL | When the control unit detects a malfunction in the front RH outlet solenoid circuit. | |
| C1125 | RR LH OUT ABS SOL | When the control unit detects a malfunction in the rear LH outlet solenoid circuit. | |
| C1127 | RR RH OUT ABS SOL | When the control unit detects a malfunction in the rear RH outlet solenoid circuit. | |

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

| |
|------------------------|
| Self-diagnosis results |
| FR LH OUT ABS SOL |
| FR RH OUT ABS SOL |
| RR LH OUT ABS SOL |
| RR RH OUT ABS SOL |

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-52. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000004242415

INSPECTION PROCEDURE

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connectors and then perform the self-diagnosis.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2.
NO >> Poor connection of connector terminal. Repair or replace connector.

2. CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.

C1121, C1123, C1125, C1127 OUT ABS SOL

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

| ABS actuator and electric unit (control unit) | | — | Voltage |
|---|----------|--------|-----------------|
| Connector | Terminal | | |
| E41 | 3 | Ground | Battery voltage |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning components.

3.CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY GROUND CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

| ABS actuator and electric unit (control unit) | | — | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| E41 | 1, 4 | Ground | Existed |

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace malfunctioning components.

Component Inspection

INFOID:000000004242416

1.CHECK ACTIVE TEST

- Select each test menu item on "ACTIVE TEST".
- On the display, touch "Up", "Keep" and "Down", and check that the system operates as shown in the table below.

| Test item | Display item (Note) | Display | | |
|-----------|---------------------|---------|------|------|
| | | Up | Keep | Down |
| FR RH SOL | FR RH IN SOL | Off | On | On |
| | FR RH OUT SOL | Off | Off | On* |
| | USV[FR-RL] | Off | Off | Off |
| | HSV[FR-RL] | Off | Off | Off |
| FR LH SOL | FR LH IN SOL | Off | On | On |
| | FR LH OUT SOL | Off | Off | On* |
| | USV[FL-RR] | Off | Off | Off |
| | HSV[FL-RR] | Off | Off | Off |
| RR RH SOL | RR RH IN SOL | Off | On | On |
| | RR RH OUT SOL | Off | Off | On* |
| | USV[FL-RR] | Off | Off | Off |
| | HSV[FL-RR] | Off | Off | Off |
| RR LH SOL | RR LH IN SOL | Off | On | On |
| | RR LH OUT SOL | Off | Off | On* |
| | USV[FR-RL] | Off | Off | Off |
| | HSV[FR-RL] | Off | Off | Off |

*: On for 1 to 2 seconds after the touch, and then Off.

NOTE:

A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is an operation for checking.

Is the inspection result normal?

YES >> INSPECTION END

C1121, C1123, C1125, C1127 OUT ABS SOL

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

NO >> Go to diagnosis procedure. Refer to [BRC-52. "Diagnosis Procedure"](#).

Special Repair Requirement

INFOID:000000004242417

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-8. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

>> END

C1130, C1131, C1132 ENGINE SIGNAL

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1130, C1131, C1132 ENGINE SIGNAL

Description

INFOID:000000004242418

ABS actuator and electric unit (control unit) and ECM exchange the engine signal with CAN communication line.

DTC Logic

INFOID:000000004242419

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|-----------------|---|---|
| C1130 | ENGINE SIGNAL 1 | Major engine components are malfunctioning. | <ul style="list-style-type: none">• Harness or connector• ABS actuator and electric unit (control unit)• ECM• CAN communication line |
| C1131 | ENGINE SIGNAL 2 | | |
| C1132 | ENGINE SIGNAL 3 | | |

DTC CONFIRMATION PROCEDURE

1.CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

| Self-diagnosis results |
|------------------------|
| ENGINE SIGNAL 1 |
| ENGINE SIGNAL 2 |
| ENGINE SIGNAL 3 |

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-55, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000004242420

1.CHECK ENGINE SYSTEM

1. Perform ECM self-diagnosis. Repair or replace items indicated, then perform ECM self-diagnosis again.
2. Perform ABS actuator and electric unit (control unit) self-diagnosis.

Is any item indicated on the self-diagnosis display?

- YES >> Repair or replace the affected part.
NO >> INSPECTION END

Special Repair Requirement

INFOID:000000004242421

1.ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-8, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

>> END

C1138 4WAS SYSTEM

Description

INFOID:000000004242422

The ABS actuator and electric unit (control unit) and the 4WAS control unit exchange signals via the CAN communication line.

DTC Logic

INFOID:000000004242423

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|--------------|---|--|
| C1138 | 4WAS CIRCUIT | Abnormal condition in major 4WAS parts. | <ul style="list-style-type: none"> • ABS actuator and electric unit (control unit) • 4WAS system • CAN communication line |

DTC CONFIRMATION PROCEDURE

1.CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

| |
|------------------------|
| Self-diagnosis results |
| 4WAS CIRCUIT |

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-56. "Diagnosis Procedure"](#).
- NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000004242424

INSPECTION PROCEDURE

1.CHECK 4WAS SYSTEM

1. Perform 4WAS front control unit self-diagnosis and 4WAS main control unit self-diagnosis. Repair or replace items indicated, then 4WAS front control unit self-diagnosis and 4WAS main control unit self-diagnosis again.
2. Perform ABS actuator and electric unit (control unit) self-diagnosis.

Is any item indicated on the self-diagnosis display?

- YES >> Repair or replace the affected part.
- NO >> INSPECTION END

Special Repair Requirement

INFOID:000000004242425

1.ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-8. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

>> END

C1142 PRESS SENSOR

Description

INFOID:000000004242426

The pressure sensor converts the brake fluid pressure to an electric signal and transmits it to the ABS actuator and electric unit (control unit). [The pressure sensor is integrated in the ABS actuator and electric unit (control unit).]

DTC Logic

INFOID:000000004242427

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|-------------------|---|---|
| C1142 | PRESS SEN CIRCUIT | Pressure sensor signal line is open or shorted, or pressure sensor is malfunctioning. | <ul style="list-style-type: none"> • Harness or connector • Stop lamp switch • ABS actuator and electric unit (control unit) |

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

| |
|------------------------|
| Self-diagnosis results |
| PRESS SEN CIRCUIT |

Is above displayed on the self-diagnosis display?

YES >> Proceed to diagnosis procedure. Refer to [BRC-57, "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000004242428

INSPECTION PROCEDURE

1. CHECK STOP LAMP SWITCH

Check stop lamp switch system. Refer to [BRC-47, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace malfunctioning component.

2. CHECK BRAKE SYSTEM

1. Check brake fluid leakage: Refer to [BR-10, "Inspection"](#).
2. Check front brake piping: Refer to [BR-24, "FRONT : Inspection"](#).
3. Check rear brake piping: Refer to [BR-27, "REAR : Inspection"](#).
4. Check brake pedal: Refer to [BR-19, "Inspection and Adjustment"](#).
5. Check master cylinder: Refer to [BR-31, "Inspection"](#).
6. Check brake booster: Refer to [BR-33, "Inspection and Adjustment"](#).
7. Check front disc brake: Refer to [BR-45, "BRAKE CALIPER ASSEMBLY \(2 PISTON TYPE\) : Inspection"](#) (2 piston type), [BR-49, "BRAKE CALIPER ASSEMBLY \(4 PISTON TYPE\) : Inspection"](#) (4 piston type).
8. Check rear disc brake: Refer to [BR-59, "BRAKE CALIPER ASSEMBLY \(1 PISTON TYPE\) : Inspection"](#) (1 piston type), [BR-63, "BRAKE CALIPER ASSEMBLY \(2 PISTON TYPE\) : Inspection"](#) (2 piston type).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning component.

3. ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS

Check the self-diagnosis result.

Is above displayed on the self-diagnosis display?

YES >> Replace ABS actuator and electric unit (control unit).

C1142 PRESS SENSOR

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Check ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damaged parts.

Component Inspection

INFOID:000000004242429

1.CHECK DATA MONITOR

On "DATA MONITOR", select "PRESS SENSOR" and check the brake fluid pressure.

| Condition | PRESS SENSOR (DATA MONITOR) |
|---|--------------------------------|
| With ignition switch turned ON and brake pedal released. | Approx. 0 bar |
| With ignition switch turned ON and brake pedal depressed. | - 40 to 300 bar |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-57. "Diagnosis Procedure"](#).

Special Repair Requirement

INFOID:000000004242430

1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-8. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

>> END

C1143, C1144 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1143, C1144 STEERING ANGLE SENSOR

Description

INFOID:000000004242431

The steering angle sensor detects the rotation amount, angular velocity and direction of the steering wheel, and transmits the data to the ABS actuator and electric unit (control unit) via CAN communication.

DTC Logic

INFOID:000000004242432

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|--------------------|--|--|
| C1143 | ST ANG SEN CIRCUIT | Steering angle sensor is malfunctioning. | <ul style="list-style-type: none">• Harness or connector• Steering angle sensor• 4WAS control unit (4WAS models)• ABS actuator and electric unit (control unit) |
| C1144 | ST ANG SEN SIGNAL | Neutral position of steering angle sensor is not finished. | |

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

| |
|------------------------|
| Self-diagnosis results |
| ST ANG SEN CIRCUIT |
| ST ANG SEN SIGNAL |

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-59, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000004242433

INSPECTION PROCEDURE

1. VEHICLE INSPECTION

Check that the vehicle equips 4WAS.

Does the vehicle equips 4WAS?

- YES >> Check 4WAS system. Refer to [STC-33, "System Diagram"](#).
NO >> GO TO 2.

2. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect steering angle sensor connector.
4. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
5. Reconnect connectors and then perform the self-diagnosis.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 3.
NO >> Poor connection of connector terminal. Repair or replace connector.

3. CHECK STEERING ANGLE SENSOR HARNESS

1. Turn ignition switch OFF.
2. Disconnect steering angle sensor connector.
3. Check continuity between steering angle sensor harness connector terminal and ground.

C1143, C1144 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

| Steering angle sensor | | — | Continuity |
|-----------------------|----------|--------|------------|
| Connector | Terminal | | |
| M37 | 7 | Ground | Existed |

4. Turn ignition switch ON.
5. Check voltage between steering angle sensor harness connector terminal and ground.

| Steering angle sensor | | — | Voltage |
|-----------------------|----------|--------|-----------------|
| Connector | Terminal | | |
| M37 | 8 | Ground | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Replace steering angle sensor and adjust neutral position of steering angle sensor.

4.CHECK DATA MONITOR

1. Connect the steering angle sensor connector and ABS actuator and electric unit (control unit) connector.
2. Select "STR ANGLE SIG" in "DATA MONITOR" and check steering angle sensor signal.

| Steering condition | STR ANGLE SIG (DATA MONITOR) |
|--------------------|------------------------------|
| Driving straight | $\pm 2.5^\circ$ |
| Turn 90° to right | Approx. +90° |
| Turn 90° to left | Approx. -90° |

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit).
NO >> Replace steering angle sensor and adjust neutral position of steering angle sensor.

Component Inspection

INFOID:000000004242434

1.CHECK DATA MONITOR

Select "STR ANGLE SIG" in "DATA MONITOR" and check steering angle sensor signal.

| Steering condition | STR ANGLE SIG (DATA MONITOR) |
|--------------------|------------------------------|
| Driving straight | $\pm 2.5^\circ$ |
| Turn 90° to right | Approx. +90° |
| Turn 90° to left | Approx. -90° |

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Go to diagnosis procedure. Refer to [BRC-59, "Diagnosis Procedure"](#).

Special Repair Requirement

INFOID:000000004242435

1.ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the steering angle sensor or the ABS actuator and electric unit (control unit). Refer to [BRC-8, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

>> END

C1145, C1146 YAW RATE/SIDE G SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1145, C1146 YAW RATE/SIDE G SENSOR

Description

INFOID:000000004242436

The yaw rate/side G sensor detects the yaw rate/side G affecting the vehicle, and transmits the data to the ABS actuator and electric unit (control unit) as an analog voltage signal.

DTC Logic

INFOID:000000004242437

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|--------------------|---|---|
| C1145 | YAW RATE SENSOR | Yaw rate sensor is malfunctioning, or the yaw rate sensor signal line is open or shorted. | • Harness or connector • ABS actuator and electric unit (control unit) • Yaw rate/side G sensor |
| C1146 | SIDE G-SEN CIRCUIT | Side G sensor is malfunctioning, or circuit of side G sensor is open or shorted. | |

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

| |
|------------------------|
| Self-diagnosis results |
| YAW RATE SENSOR |
| SIDE G-SEN CIRCUIT |

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-61. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000004242438

CAUTION:

- Sudden turns (such as spin turns, acceleration turns), drifting, etc., when VDC function is off (VDC OFF switch "ON") may cause yaw rate/side G sensor system to indicate a malfunction. However, this is not a malfunction, if normal operation can be resumed after restarting engine. Then erase memory of self-diagnosis.
- If vehicle is on turn-table at entrance to parking garage, or on other moving surface, VDC OFF indicator lamp may illuminate and CONSULT-III self-diagnosis may indicate yaw rate sensor system malfunction. However, in this case there is no malfunction in yaw rate sensor system. Take vehicle off of turn-table or other moving surface, and start engine. Results will return to normal. And after doing spin turns or acceleration turns with VDC function is being off (VDC OFF switch "ON"), too, the results will return to a normal condition by re-starting vehicle.

INSPECTION PROCEDURE

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect yaw rate/side G sensor connector.
4. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
5. Reconnect connectors and then perform the self-diagnosis.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2.
NO >> Poor connection of connector terminal. Repair or replace connector.

2. CHECK YAW RATE/SIDE G SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect yaw rate/side G sensor connector.

C1145, C1146 YAW RATE/SIDE G SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

3. Turn ignition switch ON or OFF and check voltage between yaw rate/side G sensor harness connector terminal and ground.

| Yaw rate/side G sensor | | — | Condition | Voltage |
|------------------------|----------|--------|----------------------|-----------------|
| Connector | Terminal | | | |
| M143 | 4 | Ground | Ignition switch: ON | Battery voltage |
| | | | Ignition switch: OFF | Approx. 0 V |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair or replace malfunctioning components.

3.CHECK YAW RATE/SIDE G SENSOR GROUND CIRCUIT

Check continuity between yaw rate/side G sensor harness connector terminal and ground.

| Yaw rate/side G sensor | | — | Continuity |
|------------------------|----------|--------|------------|
| Connector | Terminal | | |
| M143 | 1 | Ground | Existed |

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair or replace malfunctioning components.

4.CHECK YAW RATE/SIDE G SENSOR HARNESS

1. Disconnect yaw rate/side G sensor connector and ABS actuator and electric unit (control unit) connector.
2. Check continuity between yaw rate/side G sensor harness connector terminals and ABS actuator and electric unit (control unit) harness connector terminals.

| ABS actuator and electric unit (control unit) | | Yaw rate/side G sensor | | Continuity |
|---|----------|------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E41 | 25 | M143 | 2 | Existed |
| | 45 | | 3 | |

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> Repair or replace malfunctioning components.

5.CHECK DATA MONITOR

1. Connect the yaw rate/side G sensor connector and ABS actuator and electric unit (control unit) connector.
2. Select "YAW RATE SEN", "SIDE G-SENSOR" in "DATA MONITOR" and check yaw rate/side G sensor signal.

| Vehicle condition | YAW RATE SEN (DATA MONITOR) | SIDE G-SENSOR (DATA MONITOR) |
|-------------------|-----------------------------|------------------------------|
| Stopped | Approx. 0 d/s | Approx. 0 m/s ² |
| Turning right | Negative value | Negative value |
| Turning left | Positive value | Positive value |

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit).
 NO >> Replace yaw rate/side G sensor.

Component Inspection

INFOID:000000004242439

1.CHECK DATA MONITOR

Select "YAW RATE SEN", "SIDE G-SENSOR" in "DATA MONITOR" and check yaw rate/side G sensor signal.

C1145, C1146 YAW RATE/SIDE G SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

| Vehicle condition | YAW RATE SEN (DATA MONITOR) | SIDE G-SENSOR (DATA MONITOR) |
|-------------------|--------------------------------|---------------------------------|
| Stopped | Approx. 0 d/s | Approx. 0 m/s ² |
| Turning right | Negative value | Negative value |
| Turning left | Positive value | Positive value |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-61. "Diagnosis Procedure"](#).

Special Repair Requirement

INFOID:000000004242440

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-8. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

>> END

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

BRC

C1147, C1148, C1149, C1150 USV/HSV LINE

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1147, C1148, C1149, C1150 USV/HSV LINE

Description

INFOID:000000004242441

USV1, USV2 (CUT VALVE)

The cut valve shuts off the normal brake fluid path from the master cylinder, when VDC/TCS is activated.

HSV1, HSV2 (SUCTION VALVE)

The suction valve supplies the brake fluid from the master cylinder to the pump, when VDC/TCS is activated.

DTC Logic

INFOID:000000004242442

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|-----------------|---|--|
| C1147 | USV LINE[FL-RR] | VDC switch-over solenoid valve (USV1) on the primary side is open circuit or shorted, or the control line is open or shorted to the power supply or the ground. | <ul style="list-style-type: none">• Harness or connector• ABS actuator and electric unit (control unit) |
| C1148 | USV LINE[FR-RL] | VDC switch-over solenoid valve (USV2) on the primary side is open circuit or shorted, or the control line is open or shorted to the power supply or the ground. | |
| C1149 | HSV LINE[FL-RR] | VDC switch-over solenoid valve (HSV1) on the primary side is open circuit or shorted, or the control line is open or shorted to the power supply or the ground. | |
| C1150 | HSV LINE[FR-RL] | VDC switch-over solenoid valve (HSV2) on the primary side is open circuit or shorted, or the control line is open or shorted to the power supply or the ground. | |

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

| |
|------------------------|
| Self-diagnosis results |
| USV LINE[FL-RR] |
| USV LINE[FR-RL] |
| HSV LINE[FL-RR] |
| HSV LINE[FR-RL] |

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-64, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000004242443

INSPECTION PROCEDURE

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connectors and then perform the self-diagnosis.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2.
NO >> Poor connection of connector terminal. Repair or replace connector.

2. CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY POWER SUPPLY CIRCUIT

C1147, C1148, C1149, C1150 USV/HSV LINE

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.

| ABS actuator and electric unit (control unit) | | — | Voltage |
|---|----------|--------|-----------------|
| Connector | Terminal | | |
| E41 | 3 | Ground | Battery voltage |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning components.

3.CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY GROUND CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

| ABS actuator and electric unit (control unit) | | — | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| E41 | 1, 4 | Ground | Existed |

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace malfunctioning components.

Component Inspection

INFOID:000000004242444

1.CHECK ACTIVE TEST

1. Select each test menu item on "ACTIVE TEST".
2. On the display, touch "Up", "ACT UP", and "ACT KEEP", and check that the system operates as shown in the table below.

| Test item | Display item (Note) | Display | | |
|--------------------------|---------------------|---------|--------|----------|
| | | Up | ACT UP | ACT KEEP |
| FR RH ABS SOLENOID (ACT) | FR RH IN SOL | Off | Off | Off |
| | FR RH OUT SOL | Off | Off | Off |
| | USV[FR-RL] | Off | On | On |
| | HSV[FR-RL] | Off | On* | Off |
| FR LH ABS SOLENOID (ACT) | FR LH IN SOL | Off | Off | Off |
| | FR LH OUT SOL | Off | Off | Off |
| | USV[FL-RR] | Off | On | On |
| | HSV[FL-RR] | Off | On* | Off |
| RR RH ABS SOLENOID (ACT) | RR RH IN SOL | Off | Off | Off |
| | RR RH OUT SOL | Off | Off | Off |
| | USV[FL-RR] | Off | On | On |
| | HSV[FL-RR] | Off | On* | Off |
| RR LH ABS SOLENOID (ACT) | RR LH IN SOL | Off | Off | Off |
| | RR LH OUT SOL | Off | Off | Off |
| | USV[FR-RL] | Off | On | On |
| | HSV[FR-RL] | Off | On* | Off |

*: On for 1 to 2 seconds after the touch, and then Off.

NOTE:

C1147, C1148, C1149, C1150 USV/HSV LINE

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is an operation for checking.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-64. "Diagnosis Procedure"](#).

Special Repair Requirement

INFOID:000000004242445

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-8. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

>> END

C1155 BRAKE FLUID LEVEL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1155 BRAKE FLUID LEVEL SWITCH

Description

INFOID:000000004242446

The brake fluid level switch converts the brake fluid level to an electric signal and transmits it to the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000004242447

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|--------------------|---|--|
| C1155 | BR FLUID LEVEL LOW | Brake fluid level is low or communication line between the ABS actuator and electric unit (control unit) and brake fluid level switch is open or shorted. | <ul style="list-style-type: none">• Harness or connector• Brake fluid level switch• Unified meter and A/C amp. |

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

| Self-diagnosis results |
|------------------------|
| BR FLUID LEVEL LOW |

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-67. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000004242448

INSPECTION PROCEDURE

1. CHECK BRAKE FLUID LEVEL

Check the brake fluid level. Refer to [BR-10. "Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Refill the brake fluid. Refer to [BR-10. "Refilling"](#).

2. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect brake fluid level switch connector and unified meter and A/C amp. connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connectors and then perform the self-diagnosis.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 3.
NO >> Poor connection of connector terminal. Repair or replace connector.

3. CHECK BRAKE FLUID LEVEL SWITCH

1. Turn ignition switch OFF.
2. Disconnect brake fluid level switch connector.
3. Check continuity between brake fluid level switch connector terminals.

| Brake fluid level switch | | Condition | Continuity |
|--------------------------|----------|--|-------------|
| Connector | Terminal | | |
| E47 | 1 - 2 | When brake fluid is full in the reservoir tank. | Not existed |
| | | When brake fluid is empty in the reservoir tank. | Existed |

Is the inspection result normal?

C1155 BRAKE FLUID LEVEL SWITCH

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

- YES >> GO TO 4.
NO >> Brake fluid level switch is malfunction. Replace reservoir tank.

4.CHECK BRAKE FLUID LEVEL SWITCH CIRCUIT

1. Disconnect unified meter and A/C amp. connector.
2. Check continuity between brake fluid level switch harness connector terminals, unified meter and A/C amp. harness connector terminal and/or ground.

| Unified meter and A/C amp. | | Brake fluid level switch | | Continuity |
|----------------------------|----------|--------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M67 | 57 | E47 | 1 | Existed |

| Unified meter and A/C amp. | | — | Continuity |
|----------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| M67 | 57 | Ground | Not existed |

| Brake fluid level switch | | — | Continuity |
|--------------------------|----------|--------|------------|
| Connector | Terminal | | |
| E47 | 2 | Ground | Existed |

Is the inspection result normal?

- YES >> Replace unified meter and A/C amp.
NO >> Repair or replace malfunctioning components.

Component Inspection

INFOID:000000004242449

1.CHECK BRAKE FLUID LEVEL SWITCH

1. Turn ignition switch OFF.
2. Disconnect brake fluid level switch connector.
3. Check continuity between brake fluid level switch connector terminals.

| Brake fluid level switch | | Condition | Continuity |
|--------------------------|----------|--|-------------|
| Connector | Terminal | | |
| E47 | 1 – 2 | When brake fluid is full in the reservoir tank. | Not existed |
| | | When brake fluid is empty in the reservoir tank. | Existed |

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Replace reservoir tank.

Special Repair Requirement

INFOID:000000004242450

1.ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-8, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

>> END

C1185 ICC UNIT

Description

INFOID:000000004242451

The ABS actuator and electric unit (control unit) and the ICC sensor integrated unit exchange signals via the CAN communication line.

DTC Logic

INFOID:000000004242452

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|--------------|--|---|
| C1185 | ACC CONT | ICC sensor integrated unit internal malfunction. | <ul style="list-style-type: none"> • Harness or connector • ICC sensor integrated unit • ABS actuator and electric unit (control unit) • CAN communication line |

DTC CONFIRMATION PROCEDURE

1.CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

| |
|------------------------|
| Self-diagnosis results |
| ACC CONT |

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-69, "Diagnosis Procedure"](#).
- NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000004242453

1.CHECK ICC SENSOR INTEGRATED UNIT CIRCUIT

Perform ICC sensor integrated unit self-diagnosis.

Is any item indicated on the self-diagnosis display?

- YES >> Repair or replace malfunction components.
- NO >> GO TO 2.

2.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Perform ABS actuator and electric unit (control unit) self-diagnosis.

Is any item indicated on the self-diagnosis display?

- YES >> Repair or replace malfunction components.
- NO >> INSPECTION END

Special Repair Requirement

INFOID:000000004242454

1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-8, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

>> END

U1000, U1002 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

U1000, U1002 CAN COMM CIRCUIT

Description

INFOID:000000004242455

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

DTC Logic

INFOID:000000004242456

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|------------------|---|--|
| U1000 | CAN COMM CIRCUIT | When ABS actuator and electric unit (control unit) is not transmitting or receiving CAN communication signal for 2 seconds or more. | <ul style="list-style-type: none">CAN communication lineABS actuator and electric unit (control unit) |
| U1002 | SYSTEM COMM | When ABS actuator and electric unit (control unit) is not transmitting or receiving CAN communication signal for 2 seconds or less. | |

Diagnosis Procedure

INFOID:000000004242457

INSPECTION PROCEDURE

1. CHECK CONNECTOR

- Turn ignition switch OFF.
- Disconnect ABS actuator and electric unit (control unit) connector.
- Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
- Reconnect connector and perform self-diagnosis.

Self-diagnosis results

CAN COMM CIRCUIT

SYSTEM COMM

Is above displayed on the self-diagnosis display?

- YES >> Go to [LAN-28, "CAN System Specification Chart"](#).
NO >> INSPECTION END

Special Repair Requirement

INFOID:000000004242458

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-8, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

>> END

PARKING BRAKE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

PARKING BRAKE SWITCH

Description

INFOID:000000004242459

The parking brake switch converts the status of the parking brake lever (M/T models) or the parking brake pedal (A/T models) to an electric signal and transmits it to the ABS actuator and electric unit (control unit).

Component Function Check

INFOID:000000004242460

1.CHECK PARKING BRAKE SWITCH OPERATION

Operate the parking brake lever (M/T models) or the parking brake pedal (A/T models). Then check that the brake warning lamp in the combination meter turns on/off correctly.

| Condition | Brake warning lamp illumination status |
|---|--|
| When the parking brake switch is operation | ON |
| When the parking brake switch is not operation. | OFF |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-71, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004242461

1.CHECK PARKING BRAKE SWITCH

1. Turn ignition switch OFF.
2. Disconnect parking brake switch connector.
3. Check continuity between parking brake switch connector terminal.

| Parking brake switch | | — | Condition | Continuity |
|---------------------------------------|----------|--------|--|-------------|
| Connector | Terminal | | | |
| B14 (M/T models) E107 (A/T models) | 1 | Ground | When the parking brake switch is operated. | Existed |
| | | | When the parking brake switch is not operated. | Not existed |

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace parking brake switch.

2.CHECK COMBINATION METER

Check if the indication and operation of combination meter are normal. Refer to [MWI-36, "Diagnosis Description"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace combination meter.

3.CHECK DATA MONITOR

On "DATA MONITOR", select "PARK BRAKE SW" and perform the parking brake switch inspection.

| Condition | PARK BRAKE SW (DATA MONITOR) |
|----------------------------------|------------------------------|
| Parking brake switch is active | ON |
| Parking brake switch is inactive | OFF |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Check unified meter and A/C amp. Refer to [MWI-38, "CONSULT-III Function \(METER/M&A\)"](#).

PARKING BRAKE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

Component Inspection

INFOID:000000004242462

INSPECTION PROCEDURE

1. CHECK PARKING BRAKE SWITCH

1. Turn ignition switch OFF.
2. Disconnect parking brake switch connector.
3. Check continuity between parking brake switch connector terminal.

| Parking brake switch | | — | Condition | Continuity |
|---------------------------------------|----------|--------|--|-------------|
| Connector | Terminal | | | |
| B14 (M/T models) E107 (A/T models) | 1 | Ground | When the parking brake switch is operated. | Existed |
| | | | When the parking brake switch is not operated. | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace parking brake switch.

VDC OFF SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

VDC OFF SWITCH

Description

INFOID:000000004242463

VDC OFF switch can deactivate (turn OFF) the VDC/TCS function by pressing the VDC OFF switch.

Component Function Check

INFOID:000000004242464

1.CHECK VDC OFF SWITCH OPERATION

Turn ON/OFF the VDC OFF switch and check that the VDC OFF indicator lamp in the combination meter turns ON/OFF correctly.

| Condition | VDC OFF indicator lamp illumination status |
|---------------------|--|
| VDC OFF switch: ON | ON |
| VDC OFF switch: OFF | OFF |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-73. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004242465

1.CHECK VDC OFF SWITCH

1. Turn ignition switch OFF.
2. Disconnect VDC OFF switch connector.
3. Check continuity between VDC OFF switch connector terminals.

| VDC OFF switch | | Condition | Continuity |
|----------------|----------|--------------------------------------|-------------|
| Connector | Terminal | | |
| M19 | 1 – 2 | When VDC OFF switch is hold pressed. | Existed |
| | | When releasing VDC OFF switch. | Not existed |

Is the inspection result normal?

YES >> GO TO 2.

NO >> VDC OFF switch is malfunctioning. Replace VDC OFF switch.

2.CHECK VDC OFF SWITCH HARNESS

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between VDC OFF switch connector terminals and ABS actuator and electric unit (control unit) connector terminal and/or ground.

| ABS actuator and electric unit (control unit) | | VDC OFF switch | | Continuity |
|---|----------|----------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E41 | 31 | M19 | 1 | Existed |

| ABS actuator and electric unit (control unit) | | — | Continuity |
|---|----------|--------|-------------|
| Connector | Terminal | | |
| E41 | 31 | Ground | Not existed |

| VDC OFF switch | | — | Continuity |
|----------------|----------|--------|------------|
| Connector | Terminal | | |
| M19 | 2 | Ground | Existed |

Is the inspection result normal?

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

VDC OFF SWITCH

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

- YES >> GO TO 3.
NO >> If the open or short in harness, repair or replace harness.

3.CHECK COMBINATION METER

Check if the indication and operation of combination meter are normal. Refer to [MWI-36. "Diagnosis Description"](#).

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit).
NO >> Repair or replace combination meter.

Component Inspection

INFOID:000000004242466

INSPECTION PROCEDURE

1.CHECK VDC OFF SWITCH

1. Turn ignition switch OFF.
2. Disconnect VDC OFF switch connector.
3. Check continuity between VDC OFF switch connector terminals.

| VDC OFF switch | | Condition | Continuity |
|----------------|----------|--------------------------------------|-------------|
| Connector | Terminal | | |
| M19 | 1 - 2 | When VDC OFF switch is hold pressed. | Existed |
| | | When releasing VDC OFF switch. | Not existed |

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Replace VDC OFF switch.

ABS WARNING LAMP

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

ABS WARNING LAMP

Description

INFOID:000000004242467

×: ON –: OFF

| Condition | ABS warning lamp |
|---|------------------|
| Ignition switch OFF | – |
| For 1 second after turning ignition switch ON | × |
| 1 second later after turning ignition switch ON | – |
| ABS function is malfunctioning. | × |
| EBD function is malfunctioning. | × |

Component Function Check

INFOID:000000004242468

1.CHECK ABS WARNING LAMP OPERATION

Check that the lamp illuminates for approximately 1 second after the ignition switch is turned ON.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-75. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004242469

1.CHECK SELF-DIAGNOSIS

Perform ABS actuator and electric unit (control unit) self-diagnosis.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check items displayed by self-diagnosis.

2.CHECK COMBINATION METER

Check if the indication and operation of combination meter are normal. Refer to [MWI-36. "Diagnosis Description"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace combination meter.

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

BRAKE WARNING LAMP

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

BRAKE WARNING LAMP

Description

INFOID:000000004242470

×: ON –: OFF

| Condition | Brake warning lamp (Note 1) |
|---|-----------------------------|
| Ignition switch OFF | – |
| For 1 second after turning ignition switch ON | × (Note 2) |
| 1 second later after turning ignition switch ON | × (Note 2) |
| EBD function is malfunctioning. | × |

NOTE:

- 1: Brake warning lamp will turn on in case of parking brake operation (when switch is ON) or of brake fluid level switch operation (when brake fluid is insufficient).
- 2: After starting engine, brake warning lamp is turned off.

Component Function Check

INFOID:000000004242471

1. BRAKE WARNING LAMP OPERATION CHECK 1

Check that the lamp illuminates for approximately 1 second after the ignition switch is turned ON.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Go to diagnosis procedure. Refer to [BRC-76, "Diagnosis Procedure"](#).

2. BRAKE WARNING LAMP OPERATION CHECK 2

Check that the brake warning lamp in the combination meter turns ON/OFF correctly when operating the parking brake lever (M/T models) or the parking brake pedal (A/T models).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Check parking brake switch. Refer to [BRC-71, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004242472

1. CHECK PARKING BRAKE SWITCH

Check that the brake warning lamp in the combination meter turns ON/OFF correctly when operating the parking brake lever (M/T models) or the parking brake pedal (A/T models).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check parking brake switch. Refer to [BRC-71, "Diagnosis Procedure"](#).

2. CHECK SELF-DIAGNOSIS

Perform ABS actuator and electric unit (control unit) self-diagnosis.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check items displayed by self-diagnosis.

3. CHECK COMBINATION METER

Check if the indication and operation of combination meter are normal. Refer to [MWI-36, "Diagnosis Description"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace combination meter.

VDC OFF INDICATOR LAMP

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

VDC OFF INDICATOR LAMP

Description

INFOID:000000004242473

x: ON –: OFF

| Condition | VDC OFF indicator lamp |
|--|------------------------|
| Ignition switch OFF | – |
| For 1 second after turning ignition switch ON | x |
| 1 second later after turning ignition switch ON | – |
| VDC OFF switch turned ON. (VDC function is OFF.) | x |
| VDC/TCS function is malfunctioning. | x |
| ABS function is malfunctioning. | x |
| EBD function is malfunctioning. | x |

Component Function Check

INFOID:000000004242474

1.VDC OFF INDICATOR LAMP OPERATION CHECK 1

Check that the lamp illuminates for approximately 1 second after the ignition switch is turned ON.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Go to diagnosis procedure. Refer to [BRC-77, "Diagnosis Procedure"](#).

2.VDC OFF INDICATOR LAMP OPERATION CHECK 2

Check that the VDC OFF indicator lamp in the combination meter turns ON/OFF correctly when operating the VDC OFF switch.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Check VDC OFF switch. Refer to [BRC-73, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004242475

1.CHECK VDC OFF SWITCH

Check that the VDC OFF indicator lamp in the combination meter turns ON/OFF correctly when operating the VDC OFF switch.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check VDC OFF switch. Refer to [BRC-73, "Diagnosis Procedure"](#).

2.CHECK SELF-DIAGNOSIS

Perform ABS actuator and electric unit (control unit) self-diagnosis.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check items displayed by self-diagnosis.

3.CHECK COMBINATION METER

Check if the indication and operation of combination meter are normal. Refer to [MWI-36, "Diagnosis Description"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace combination meter.

SLIP INDICATOR LAMP

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

SLIP INDICATOR LAMP

Description

INFOID:000000004242476

×: ON –: OFF

| Condition | SLIP indicator lamp |
|---|---------------------|
| Ignition switch OFF | – |
| For 1 second after turning ignition switch ON | × |
| 1 second later after turning ignition switch ON | – |
| VDC/TCS function is malfunctioning. | × |
| ABS function is malfunctioning. | × |
| EBD function is malfunctioning. | × |

Component Function Check

INFOID:000000004242477

1. CHECK SLIP INDICATOR LAMP OPERATION

Check that the lamp illuminates for approximately 1 second after the ignition switch is turned ON.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-78. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004242478

1. CHECK SELF-DIAGNOSIS

Perform ABS actuator and electric unit (control unit) self-diagnosis.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check items displayed by self-diagnosis.

2. CHECK COMBINATION METER

Check if the indication and operation of combination meter are normal. Refer to [MWI-36. "Diagnosis Description"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace combination meter.

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

ECU DIAGNOSIS INFORMATION

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Reference Value

INFOID:000000004242479

VALUES ON THE DIAGNOSIS TOOL

CAUTION:

The display shows the control unit calculation data, so a normal value might be displayed even in the event the output circuit (harness) is open or short-circuited.

CONSULT-III MONITOR ITEM

| Monitor item | Display content | Data monitor | |
|---------------|--|---|--|
| | | Condition | Reference value in normal operation |
| FR LH SENSOR | Wheel speed | Vehicle stopped | 0 [km/h (MPH)] |
| | | Vehicle running (Note 1) | Nearly matches the speed meter display ($\pm 10\%$ or less) |
| FR RH SENSOR | Wheel speed | Vehicle stopped | 0 [km/h (MPH)] |
| | | Vehicle running (Note 1) | Nearly matches the speed meter display ($\pm 10\%$ or less) |
| RR LH SENSOR | Wheel speed | Vehicle stopped | 0 [km/h (MPH)] |
| | | Vehicle running (Note 1) | Nearly matches the speed meter display ($\pm 10\%$ or less) |
| RR RH SENSOR | Wheel speed | Vehicle stopped | 0 [km/h (MPH)] |
| | | Vehicle running (Note 1) | Nearly matches the speed meter display ($\pm 10\%$ or less) |
| STOP LAMP SW | Stop lamp switch signal status | When brake pedal is depressed | On |
| | | When brake pedal is not depressed | Off |
| BATTERY VOLT | Battery voltage supplied to the ABS actuator and electric unit (control unit) | Ignition switch ON | 10 – 16 V |
| GEAR | Gear position determined by TCM | First gear (1GR) | 1 |
| | | Second gear (2GR) | 2 |
| | | Third gear (3GR) | 3 |
| | | Forth gear (4GR) | 4 |
| | | Fifth gear (5GR) | 5 |
| SLCT LVR POSI | A/T selector lever position | P position | P |
| | | R position | R |
| | | N position | N |
| | | D position | D |
| OFF SW | VDC OFF switch ON/OFF | VDC OFF switch ON (When VDC OFF indicator lamp is ON) | On |
| | | VDC OFF switch OFF (When VDC OFF indicator lamp is OFF) | Off |
| YAW RATE SEN | Yaw rate detected by yaw rate/side G sensor | When vehicle stop | Approx. 0 d/s |
| | | When vehicle turning | -75 to 75 d/s |
| ACCEL POS SIG | Throttle actuator opening/closing is displayed (linked with accelerator pedal) | Accelerator pedal not depressed (ignition switch is ON) | 0 % |
| | | Depress accelerator pedal (ignition switch is ON) | 0 - 100 % |

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

| Monitor item | Display content | Data monitor | |
|-----------------------|--|--|--|
| | | Condition | Reference value in normal operation |
| SIDE G-SENSOR | Transverse G detected by side G sensor | Vehicle stopped | Approx. 0 m/s ² |
| | | Vehicle turning right | Negative value (m/s ²) |
| | | Vehicle turning left | Positive value (m/s ²) |
| STR ANGLE SIG | Steering angle detected by steering angle sensor | Straight-ahead | Approx. 0° |
| | | Steering wheel turned | -720 to 720° |
| 4WD MODE MON (Note 2) | AWD activated | Engine running | AUTO |
| PRESS SENSOR | Brake fluid pressure detected by pressure sensor | With ignition switch turned ON and brake pedal released | Approx. 0 bar |
| | | With ignition switch turned ON and brake pedal depressed | -40 to 300 bar |
| ENGINE RPM | With engine running | With engine stopped | 0 rpm |
| | | Engine running | Almost in accordance with tachometer display |
| FLUID LEV SW | Brake fluid level switch signal status | When brake fluid level switch ON | On |
| | | When brake fluid level switch OFF | Off |
| PARK BRAKE SW | Parking brake switch signal status | Parking brake switch is active | On |
| | | Parking brake switch is inactive | Off |
| FR RH IN SOL | Operation status of each solenoid valve | Actuator (solenoid valve) is active ("ACTIVE TEST" with CONSULT-III) | On |
| | | When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON) | Off |
| FR RH OUT SOL | Operation status of each solenoid valve | Actuator (solenoid valve) is active ("ACTIVE TEST" with CONSULT-III) | On |
| | | When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON) | Off |
| FR LH IN SOL | Operation status of each solenoid valve | Actuator (solenoid valve) is active ("ACTIVE TEST" with CONSULT-III) | On |
| | | When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON) | Off |
| FR LH OUT SOL | Operation status of each solenoid valve | Actuator (solenoid valve) is active ("ACTIVE TEST" with CONSULT-III) | On |
| | | When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON) | Off |
| RR RH IN SOL | Operation status of each solenoid valve | Actuator (solenoid valve) is active ("ACTIVE TEST" with CONSULT-III) | On |
| | | When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON) | Off |

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

| Monitor item | Display content | Data monitor | |
|-----------------------|---|--|-------------------------------------|
| | | Condition | Reference value in normal operation |
| RR RH OUT SOL | Operation status of each solenoid valve | Actuator (solenoid valve) is active ("ACTIVE TEST" with CONSULT-III) | On |
| | | When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON) | Off |
| RR LH IN SOL | Operation status of each solenoid valve | Actuator (solenoid valve) is active ("ACTIVE TEST" with CONSULT-III) | On |
| | | When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON) | Off |
| RR LH OUT SOL | Operation status of each solenoid valve | Actuator (solenoid valve) is active ("ACTIVE TEST" with CONSULT-III) | On |
| | | When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON) | Off |
| MOTOR RELAY | Motor and motor relay operation | When the motor relay and motor are operating | On |
| | | When the motor relay and motor are not operating | Off |
| ACTUATOR RLY (Note 3) | Actuator relay operation | When the actuator relay is operating | On |
| | | When the actuator relay is not operating | Off |
| ABS WARN LAMP | ABS warning lamp (Note 4) | When ABS warning lamp is ON | On |
| | | When ABS warning lamp is OFF | Off |
| OFF LAMP | VDC OFF indicator lamp (Note 4) | When VDC OFF indicator lamp is ON | On |
| | | When VDC OFF indicator lamp is OFF | Off |
| SLIP LAMP | SLIP indicator lamp (Note 4) | When SLIP indicator lamp is ON | On |
| | | When SLIP indicator lamp is OFF | Off |
| SNOW MODE SW | SNOW mode switch | When snow mode switch is ON | On |
| | | When snow mode switch is OFF | Off |
| 4WD FAIL REQ (Note 2) | AWD control unit fail-safe signal | When AWD control unit is fail-safe mode | On |
| | | When AWD control unit is normal | Off |
| BST OPER SIG | Not applied but displayed | — | Off |
| M-MODE SIG | Manual mode activated | When the manual mode is active | On |
| | | When the manual mode is inactive | Off |
| EBD SIGNAL | EBD operation | EBD is active | On |
| | | EBD is inactive | Off |
| ABS SIGNAL | ABS operation | ABS is active | On |
| | | ABS is inactive | Off |
| TCS SIGNAL | TCS operation | TCS is active | On |
| | | TCS is inactive | Off |
| VDC SIGNAL | VDC operation | VDC is active | On |
| | | VDC is inactive | Off |
| EBD FAIL SIG | EBD fail-safe signal | In EBD fail-safe | On |
| | | EBD is normal | Off |
| ABS FAIL SIG | ABS fail-safe signal | In ABS fail-safe | On |
| | | ABS is normal | Off |

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

| Monitor item | Display content | Data monitor | |
|-------------------------|--|---|-------------------------------------|
| | | Condition | Reference value in normal operation |
| TCS FAIL SIG | TCS fail-safe signal | In TCS fail-safe | On |
| | | TCS is normal | Off |
| VDC FAIL SIG | VDC fail-safe signal | In VDC fail-safe | On |
| | | VDC is normal | Off |
| CRANKING SIG | Crank operation | Crank is active | On |
| | | Crank is inactive | Off |
| USV [FL-RR] (Note 3) | VDC switch-over valve | When actuator (switch-over valve) is active ("ACTIVE TEST" with CONSULT-III) | On |
| | | When actuator (switch-over valve) is not active and actuator relay is active (ignition switch ON) | Off |
| USV [FR-RL] (Note 3) | VDC switch-over valve | When actuator (switch-over valve) is active ("ACTIVE TEST" with CONSULT-III) | On |
| | | When actuator (switch-over valve) is not active and actuator relay is active (ignition switch ON) | Off |
| HSV [FL-RR] (Note 3) | VDC switch-over valve | When actuator (switch-over valve) is active ("ACTIVE TEST" with CONSULT-III) | On |
| | | When actuator (switch-over valve) is not active and actuator relay is active (ignition switch ON) | Off |
| HSV [FR-RL] (Note 3) | VDC switch-over valve | When actuator (switch-over valve) is active ("ACTIVE TEST" with CONSULT-III) | On |
| | | When actuator (switch-over valve) is not active and actuator relay is active (ignition switch ON) | Off |
| V/R OUTPUT (Note 3) | Solenoid valve relay activated | When the solenoid valve relay is active (When ignition switch OFF) | On |
| | | When the solenoid valve relay is not active (in the fail-safe mode) | Off |
| M/R OUTPUT | Actuator motor and motor relay activated | When the actuator motor and motor relay are active ("ACTIVE TEST" with CONSULT-III) | On |
| | | When the actuator motor and motor relay are inactive | Off |

NOTE:

- 1: Confirm tire pressure is normal.
- 2: Only AWD models.
- 3: A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is an operation for checking.
- 4: On and off timing for warning lamp and indicator lamp.
 - ABS warning lamp: Refer to [BRC-75, "Description"](#).
 - Brake warning lamp: Refer to [BRC-76, "Description"](#).
 - VDC OFF indicator lamp: Refer to [BRC-77, "Description"](#).
 - SLIP indicator lamp: Refer to [BRC-78, "Description"](#).


ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

Wiring Diagram - BRAKE CONTROL SYSTEM -

INFOID:000000004242480



2008/08/07

JCFWA0190GB


ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

BRAKE CONTROL SYSTEM

| | |
|----------------|-----------------|
| Connector No. | B1 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH8DFW-CS16-TM4 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 20 | L | - |
| 21 | P | - |
| 22 | L | - |
| 23 | P | - |
| 98 | V | - |

| | |
|----------------|--------------|
| Connector No. | B4 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS08FW-CS |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 4 | GR | - |
| 5 | O | - |
| 6 | BR | - |
| 7 | LG | - |

| | |
|----------------|------------------|
| Connector No. | B6 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | NS12FER-CS |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 5G | LG | - |

| | |
|----------------|---------------------------------|
| Connector No. | B14 |
| Connector Name | PARKING BRAKE SWITCH (WITH M/T) |
| Connector Type | PR1FB-A |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | V | - |

| | |
|----------------|----------------------|
| Connector No. | B33 |
| Connector Name | REAR WHEEL SENSOR RH |
| Connector Type | AAZ02FB1 |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | BR | - |
| 2 | LG | - |

| | |
|----------------|----------------------|
| Connector No. | B34 |
| Connector Name | REAR WHEEL SENSOR LH |
| Connector Type | AAZ02FB2 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | O | - |
| 2 | GR | - |

| | |
|----------------|---|
| Connector No. | E5 |
| Connector Name | FRONT INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM) |
| Connector Type | TH2DFW-CS12-IM-TV |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 25 | G | - |

| | |
|----------------|-----------------------|
| Connector No. | E27 |
| Connector Name | FRONT WHEEL SENSOR RH |
| Connector Type | AAZ02FB1 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | B | - |
| 2 | W | - |


ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]


BRAKE CONTROL SYSTEM

| | |
|----------------|---|
| Connector No. | E41 |
| Connector Name | ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) |
| Connector Type | 8A42FB-AHZ4-LH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | B | GND |
| 2 | GR | UBMR |
| 3 | O | UEVR |
| 4 | B | GND |
| 5 | Y | DS FL |
| 6 | O | DP RL |
| 7 | BR | DP RR |
| 9 | B | DP FR |
| 10 | W | DS FR |
| 11 | V | DIAG-K |
| 14 | P | CAN-L |

| | |
|----------------|------------------|
| Connector No. | E103 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | MS18FW-CS |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1F | SB | - |
| 2F | W | - |
| 8F | L | - |


| | | |
|----|----|------------|
| 25 | Y | BUS-L |
| 26 | LG | DP FL |
| 27 | GR | DS FL |
| 28 | C | LU* |
| 29 | D | DS BR |
| 30 | SB | BLS |
| 31 | R | VDC OFF-SW |
| 35 | L | CAN-H |
| 45 | B | BUS-H |

| | |
|----------------|--------------------------|
| Connector No. | E47 |
| Connector Name | BRAKE FLUID LEVEL SWITCH |
| Connector Type | YY02FGY |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | R | - |
| 2 | B | - |

| | |
|----------------|--------------|
| Connector No. | E104 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS08MW-CS |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 4 | GR | - |
| 5 | O | - |
| 6 | BR | - |
| 7 | P | - |

| | |
|----------------|-------------------|
| Connector No. | E106 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80FW-CS (P-TM4) |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 6 | P | - |
| 7 | L | - |
| 36 | O | - |
| 44 | G | - |
| 47 | B | - |
| 48 | Y | - |
| 49 | V | - |
| 50 | R | - |
| 80 | R | - |
| 94 | SB | - |

| | |
|----------------|-----------------------|
| Connector No. | E60 |
| Connector Name | FRONT WHEEL SENSOR LH |
| Connector Type | AAZ02FB1 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | LG | - |
| 2 | Y | - |

| | |
|----------------|---------------------------------|
| Connector No. | E107 |
| Connector Name | PARKING BRAKE SWITCH (WITH A-7) |
| Connector Type | TE01FW |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | O | - |

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

BRAKE CONTROL SYSTEM

| | |
|----------------|------------------|
| Connector No. | E110 |
| Connector Name | STOP LAMP SWITCH |
| Connector Type | MS04FW-LC |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | L | - |
| 2 | W | - |
| 3 | L | - |
| 4 | SB | - |

| | |
|----------------|------------------|
| Connector No. | M1 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | NS08FW-M2 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1A | V | - |
| 2A | G | - |
| 5A | L | - |

| | |
|----------------|------------------|
| Connector No. | M3 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | NS12FW-CS |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 12C | R | - |

| | |
|----------------|-----------------|
| Connector No. | M6 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80MW-CS16-TM4 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 6 | P | - |
| 7 | L | - |
| 36 | O | - |
| 44 | G | - |
| 47 | SB | - |
| 48 | Y | - |
| 49 | V | - |
| 50 | LG | - |
| 80 | SB | - |
| 94 | L | - |

| | |
|----------------|-----------------|
| Connector No. | M7 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80MW-CS16-TM4 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 20 | L | - |
| 21 | P | - |
| 22 | L | - |
| 23 | P | - |
| 98 | O | - |

| | |
|----------------|-----------|
| Connector No. | M8 |
| Connector Name | RESISTOR |
| Connector Type | MS2FBR-LC |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | L | - |
| 2 | B | - |

| | |
|----------------|----------------|
| Connector No. | M19 |
| Connector Name | VDC OFF SWITCH |
| Connector Type | TK08FGY |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | LG | - |
| 2 | B | - |

| | |
|----------------|---------------------|
| Connector No. | M24 |
| Connector Name | DATA LINK CONNECTOR |
| Connector Type | BD16FY-P |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 6 | L | - |
| 7 | V | - |
| 14 | P | - |

JCFWA0193GB


ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]


BRAKE CONTROL SYSTEM

| | |
|----------------|-----------------------|
| Connector No. | M37 |
| Connector Name | STEERING ANGLE SENSOR |
| Connector Type | TH88FW-NH |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | L | CAN-H |
| 2 | P | CAN-L |
| 7 | B | GND |
| 8 | G | IGN |

| | |
|----------------|--------------------------|
| Connector No. | M143 |
| Connector Name | YAW RATE / SIDE G SENSOR |
| Connector Type | AAZ04FB |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | B | GND |
| 2 | Y | BUS-L |
| 3 | SB | BUS-H |
| 4 | G | 12V |

| | |
|----------------|-------------------|
| Connector No. | M53 |
| Connector Name | COMBINATION METER |
| Connector Type | SAB00FW |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-------------------------------------|
| 1 | V | BATTERY POWER SUPPLY |
| 2 | LG | COMMUNICATION SIGNAL (METER->METER) |
| 3 | GR | COMMUNICATION SIGNAL (AMP->METER) |
| 5 | B | GROUND |
| 15 | B | IGNITION SIGNAL |
| 21 | R | GROUND |
| 22 | B | GROUND |
| 24 | BR | COMMUNICATION SIGNAL (LCD->AMP) |
| 25 | Y | COMMUNICATION SIGNAL (AMP->LCD) |
| 27 | O | PARKING BRAKE SWITCH SIGNAL |
| 28 | SB | BRAKE FLUID LEVEL SWITCH |

| | |
|----------------|----------------------------|
| Connector No. | M86 |
| Connector Name | UNIFIED METER AND A/C AMP. |
| Connector Type | TH40FW-NH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------------|
| 7 | GR | COMMUNICATION SIGNAL (AMP->METER) |
| 14 | BR | COMMUNICATION SIGNAL (LCD->AMP) |
| 27 | LG | COMMUNICATION SIGNAL (METER->AMP) |
| 30 | V | PARKING BRAKE SWITCH SIGNAL |
| 34 | Y | COMMUNICATION SIGNAL (AMP->LCD) |

| | |
|----------------|----------------------------|
| Connector No. | M87 |
| Connector Name | UNIFIED METER AND A/C AMP. |
| Connector Type | TH32FW-NH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 41 | L | ACC POWER SUPPLY |
| 53 | W | IGNITION POWER SUPPLY |
| 54 | Y | BATTERY POWER SUPPLY |
| 55 | B | GROUND |
| 56 | L | CAN-H |
| 57 | LG | BRAKE FLUID LEVEL SWITCH |
| 71 | GR | GROUND |
| 72 | P | CAN-L |

Fail-Safe

ABS, EBD SYSTEM

In case of electrical malfunctions with the ABS, ABS warning lamp, VDC OFF indicator lamp, SLIP indicator lamp will turn on. In case of electrical malfunctions with the EBD, brake warning lamp, ABS warning lamp, VDC OFF indicator lamp and SLIP indicator lamp will turn on. Simultaneously, the VDC/TCS/ABS become one of the following conditions of the fail-safe function.

JCFWA0194GB

INFOID:000000004242481

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

[VDC/TCS/ABS]

< ECU DIAGNOSIS INFORMATION >

- For malfunction of ABS, only the EBD is activated and the condition of vehicle is the same condition of vehicles without TCS/ABS system.

NOTE:

ABS self-diagnosis sound may be heard. That is a normal condition because a self-diagnosis for "Ignition switch ON" and "The first starting" are being performed.

- For malfunction of EBD, EBD and ABS become inoperative, and the condition of vehicle is the same as the condition of vehicles without TCS/ABS, EBD system.

VDC / TCS

In case of malfunction in the VDC/TCS/ABS system, VDC OFF indicator lamp, SLIP indicator lamp are turned on, and the condition of vehicle is the same as the condition of vehicles without VDC/TCS control.

CAUTION:

If the Fail-Safe function is activated, then perform self-diagnosis for VDC/TCS/ABS control system.

DTC No. Index

INFOID:000000004242482

| DTC | Items (CONSULT screen terms) | Reference |
|-------|------------------------------|---------------------------------------|
| C1101 | RR RH SENSOR-1 | BRC-31, "Description" |
| C1102 | RR LH SENSOR-1 | |
| C1103 | FR RH SENSOR-1 | |
| C1104 | FR LH SENSOR-1 | |
| C1105 | RR RH SENSOR-2 | BRC-34, "Description" |
| C1106 | RR LH SENSOR-2 | |
| C1107 | FR RH SENSOR-2 | |
| C1108 | FR LH SENSOR-2 | |
| C1109 | BATTERY VOLTAGE [ABNORMAL] | BRC-37, "Description" |
| C1110 | CONTROLLER FAILURE | BRC-39, "DTC Logic" |
| C1111 | PUMP MOTOR | BRC-40, "Description" |
| C1114 | MAIN RELAY | BRC-42, "Description" |
| C1115 | ABS SENSOR [ABNORMAL SIGNAL] | BRC-44, "Description" |
| C1116 | STOP LAMP SW | BRC-47, "Description" |
| C1120 | FR LH IN ABS SOL | BRC-49, "Description" |
| C1121 | FR LH OUT ABS SOL | BRC-52, "Description" |
| C1122 | FR RH IN ABS SOL | BRC-49, "Description" |
| C1123 | FR RH OUT ABS SOL | BRC-52, "Description" |
| C1124 | RR LH IN ABS SOL | BRC-49, "Description" |
| C1125 | RR LH OUT ABS SOL | BRC-52, "Description" |
| C1126 | RR RH IN ABS SOL | BRC-49, "Description" |
| C1127 | RR RH OUT ABS SOL | BRC-52, "Description" |
| C1130 | ENGINE SIGNAL 1 | BRC-55, "Description" |
| C1131 | ENGINE SIGNAL 2 | |
| C1132 | ENGINE SIGNAL 3 | |
| C1138 | 4WAS CIRCUIT | BRC-56, "Description" |
| C1142 | PRESS SEN CIRCUIT | BRC-57, "Description" |
| C1143 | ST ANG SEN CIRCUIT | BRC-59, "Description" |
| C1144 | ST ANG SEN SIGNAL | |
| C1145 | YAW RATE SENSOR | BRC-61, "Description" |
| C1146 | SIDE G-SEN CIRCUIT | |

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

| DTC | Items (CONSULT screen terms) | Reference |
|-------|------------------------------|---------------------------------------|
| C1147 | USV LINE [FL-RR] | BRC-64, "Description" |
| C1148 | USV LINE [FR-RL] | |
| C1149 | HSV LINE [FL-RR] | |
| C1150 | HSV LINE [FR-RL] | |
| C1153 | EMERGENCY BRAKE | BRC-39, "DTC Logic" |
| C1155 | BR FLUID LEVEL LOW | BRC-67, "Description" |
| C1170 | VARIANT CORDING | BRC-39, "DTC Logic" |
| C1185 | ACC CONT | BRC-69, "Description" |
| U1000 | CAN COMM CIRCUIT | BRC-70, "Description" |
| U1002 | SYSTEM COMM | |

A
B
C
D
E

G
H
I
J
K
L
M
N
O
P

BRC

SYMPTOM DIAGNOSIS

VDC/TCS/ABS

Symptom Table

INFOID:000000004242483

If ABS warning lamp, VDC OFF indicator lamp and SLIP indicator lamp turn ON, perform self-diagnosis.

| Symptom | Check item | Reference |
|--|--|---|
| Excessive ABS function operation frequency | Brake force distribution | BRC-91. "Diagnosis Procedure" |
| | Looseness of front and rear axle | |
| | Wheel sensor and rotor system | |
| Unexpected pedal reaction | Brake pedal stroke | BRC-92. "Diagnosis Procedure" |
| | Make sure the braking force is sufficient when the ABS is not operating. | |
| The braking distance is long | Check stopping distance when the ABS is not operating. | BRC-93. "Diagnosis Procedure" |
| ABS function does not operate (Note 1) | ABS actuator and electric unit (control unit) | BRC-94. "Diagnosis Procedure" |
| Pedal vibration or ABS operation sound occurs (Note 2) | Brake pedal | BRC-95. "Diagnosis Procedure" |
| | ABS actuator and electric unit (control unit) | |
| Vehicle jerks during VDC/TCS/ABS control | ABS actuator and electric unit (control unit) | BRC-96. "Diagnosis Procedure" |
| | TCM | |
| | ECM | |

NOTE:

- 1: The ABS does not operate when the speed is 10 km/h (6 MPH) or less.
- 2: Under the following conditions, ABS is activated and vibration is felt when brake pedal is lightly depressed (just place a foot on it). However, this is normal.
 - When shifting gears
 - When driving on slippery road
 - During cornering at high speed
 - When passing over bumps or grooves [at approximately 50 mm (1.97 in) or more]
 - When pulling away just after starting engine [at approximately 10 km/h (6 MPH) or higher]

EXCESSIVE ABS FUNCTION OPERATION FREQUENCY

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

EXCESSIVE ABS FUNCTION OPERATION FREQUENCY

Diagnosis Procedure

INFOID:000000004242484

1.CHECK START

Check front and rear brake force distribution using a brake tester. Refer to [BR-64, "General Specifications"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check brake system.

2.CHECK FRONT AND REAR AXLE

Make sure that there is no excessive play in the front and rear axles. Refer to front: [FAX-5, "Inspection"](#) (2WD models), [FAX-14, "Inspection"](#) (AWD models), Rear: [RAX-5, "Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning components.

3.CHECK WHEEL SENSOR AND SENSOR ROTOR

Check the following.

- Wheel sensor installation for damage.
- Sensor rotor installation for damage.
- Wheel sensor connector connection.
- Wheel sensor harness inspection.

Is the inspection result normal?

YES >> GO TO 4.

NO >> • Replace wheel sensor or sensor rotor.
• Repair harness.

4.CHECK ABS WARNING LAMP DISPLAY

Make sure that the ABS warning lamp is turned off after the ignition switch is turned ON or when driving.

Is the ABS warning lamp illuminated?

YES >> Perform self-diagnosis.

NO >> Normal

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

UNEXPECTED PEDAL REACTION

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

UNEXPECTED PEDAL REACTION

Diagnosis Procedure

INFOID:000000004242485

1.CHECK BRAKE PEDAL STROKE

Check brake pedal stroke. Refer to [BR-7, "Inspection and Adjustment"](#).

Is the stroke too large?

- YES >> • Bleed air from brake tube and hose. Refer to [BR-11, "Bleeding Brake System"](#).
• Check brake pedal, brake booster, and master cylinder for mount play, looseness, brake system fluid leakage, etc. Refer to [BR-7, "Inspection and Adjustment"](#) (brake pedal), [BR-12, "Inspection"](#) (master cylinder), [BR-13, "Inspection"](#) (brake booster).

NO >> GO TO 2.

2.CHECK FUNCTION

Disconnect ABS actuator and electric unit (control unit) connector to deactivate ABS. Check if braking force is normal in this condition. Connect connector after inspection.

Is the inspection result normal?

- YES >> Normal
NO >> Check brake system.

THE BRAKING DISTANCE IS LONG

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

THE BRAKING DISTANCE IS LONG

Diagnosis Procedure

INFOID:000000004242486

CAUTION:

The stopping distance on slippery road surfaces might be longer when the ABS is operating than when the ABS is not operating.

1.CHECK FUNCTION

Turn ignition switch OFF and disconnect ABS actuator and electric unit (control unit) connector to deactivate ABS. In this condition, check stopping distance. After inspection, connect connector.

Is the inspection result normal?

YES >> Normal

NO >> Check brake system.

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

ABS FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

ABS FUNCTION DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000004242487

CAUTION:

ABS does not operate when speed is 10 km/h (6 MPH) or lower.

1. CHECK ABS WARNING LAMP DISPLAY

Make sure that the ABS warning lamp turns OFF after ignition switch is turned ON or when driving.

Is the inspection result normal?

YES >> Normal

NO >> Perform self-diagnosis.

PEDAL VIBRATION OR ABS OPERATION SOUND OCCURS

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

PEDAL VIBRATION OR ABS OPERATION SOUND OCCURS

Diagnosis Procedure

INFOID:000000004242488

CAUTION:

Under the following conditions, ABS is activated and vibration is felt when brake pedal is lightly depressed (just place a foot on it). However, this is normal.

- When shifting gears
- When driving on slippery road
- During cornering at high speed
- When passing over bumps or grooves [at approximately 50 mm (1.97 in) or more]
- When pulling away just after starting engine [at approximately 10 km/h (6 MPH) or higher]

1. SYMPTOM CHECK 1

Check that there are pedal vibrations when the engine is started.

Do vibrations occur?

YES >> GO TO 2.

NO >> Inspect the brake pedal.

2. SYMPTOM CHECK 2

Check that there are ABS operation noises when the engine is started.

Do the operation noises occur?

YES >> GO TO 3.

NO >> Perform self-diagnosis.

3. SYMPTOM CHECK 3

Check symptoms when electrical component (headlamps, etc.) switches are operated.

Do symptoms occur?

YES >> Check if there is a radio, antenna, antenna lead wire, or wiring close to the control unit. If there is, move it farther away.

NO >> Normal

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

VEHICLE JERKS DURING VDC/TCS/ABS CONTROL

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

VEHICLE JERKS DURING VDC/TCS/ABS CONTROL

Diagnosis Procedure

INFOID:000000004242489

1.SYMPTOM CHECK

Check if the vehicle jerks during VDC/TCS/ABS control.

Is the inspection result normal?

- YES >> Normal.
- NO >> GO TO 2.

2.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis of ABS actuator and electric unit (control unit).

Are self-diagnosis results indicated?

- YES >> Check corresponding items, make repairs, and perform ABS actuator and electric unit (control unit) self-diagnosis.
- NO >> GO TO 3.

3.CHECK CONNECTOR

- Turn ignition switch OFF and disconnect ABS actuator and electric unit (control unit) connector and check terminal for deformation, disconnection, looseness, etc.
- Securely connect connectors and perform ABS actuator and electric unit (control unit) self-diagnosis.

Are self-diagnosis results indicated?

- YES >> If poor contact, damage, open or short circuit of connector terminal is found, repair or replace.
- NO >> GO TO 4.

4.CHECK ECM AND A/T SELF-DIAGNOSIS RESULTS

Perform ECM and A/T self-diagnosis.

Are self-diagnosis results indicated?

- YES >> Check the corresponding items.
- NO >> Replace ABS actuator and electric unit (control unit).

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

NORMAL OPERATING CONDITION

Description

INFOID:000000004242490

| Symptom | Result |
|--|---|
| Slight vibrations are felt on the brake pedal and the operation noises occur, when VDC, TCS or ABS is activated. | This is a normal condition due to the VDC, TCS or ABS activation. |
| Stopping distance is longer than that of vehicles without ABS when the vehicle drives on rough, gravel, or snow-covered (fresh, deep snow) roads. | |
| The brake pedal moves and generates noises, when TCS or VDC is activated due to rapid acceleration or sharp turn. | |
| The brake pedal vibrates and motor operation noises occur from the engine room, after the engine starts and just after the vehicle starts. | This is a normal, and it is caused by the ABS operation check. |
| Depending on the road conditions, the driver may experience a sluggish feel. | This is normal, because TCS places the highest priority on the optimum traction (stability). |
| TCS may activate momentarily if wheel speed changes when driving over location where friction coefficient varies, when downshifting, or when fully depressing accelerator pedal. | |
| The ABS warning lamp, VDC OFF indicator lamp and SLIP indicator lamp may turn ON when the vehicle is subject to strong shaking or large vibration, such as when the vehicle is rotating on a turntable or located on a ship while the engine is running. | In this case, restart the engine on a normal road. If the normal condition is restored, there is no malfunction. At that time, erase the self-diagnosis memory. |
| VDC may not operate normally or the ABS warning lamp, VDC OFF indicator lamp, and SLIP indicator lamp may illuminate, when running on a special road that is extremely slanted (e.g. bank in a circuit course). | |
| A malfunction may occur in the yaw rate/side G sensor system, when the vehicle turns sharply, such as during a spin turn, axle turn, or drift driving, while the VDC function is off (VDC OFF indicator lamp illuminated). | |
| The vehicle speed will not increase even though the accelerator pedal is depressed, when inspecting the speedometer on a 2-wheel chassis dynamometer. | Normal (Deactivate the VDC/TCS function before performing an inspection on a chassis dynamometer.) |
| VDC OFF indicator lamp and SLIP indicator lamp may simultaneously turn on when low tire pressure warning lamp turns on. | This is not a VDC system error but results from characteristic change of tire. |

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000004685386

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIR BAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS


WARNING:

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precaution for Procedure without Cowl Top Cover

INFOID:000000004685387

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc.



Precaution for Brake System

INFOID:000000004242492

WARNING:

Clean brake pads and shoes with a waste cloth, then wipe with a dust collector.


- Only use DOT 3 brake fluid. Refer to [MA-10, "Fluids and Lubricants"](#).
- Never reuse drained brake fluid.
- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface.
- Never use mineral oils such as gasoline or light oil. They may damage rubber parts and cause improper operation.
- Always loosen the brake tube flare nut with a flare nut wrench.

PRECAUTIONS

[VDC/TCS/ABS]

< PRECAUTION >

- Tighten the brake tube flare nut to the specified torque with a crow-foot (A) and torque wrench (B).
- Always conform the specified tightening torque when installing the brake pipes.
- Brake system is an important safety part. If a brake fluid leak is detected, always disassemble the affected part. If a malfunction is detected, replace part with a new one.
- Turn the ignition switch OFF and disconnect the ABS actuator and electric unit (control unit) connector or the battery negative terminal before performing the work.



Precaution for Brake Control

INFOID:000000004242493

- When starting engine or when starting vehicle just after starting engine, brake pedal may vibrate or motor operating noise may be heard from engine compartment. This is normal condition.
- When an error is indicated by ABS or another warning lamp, collect all necessary information from customer (what symptoms are present under what conditions) and check for estimate causes before starting diagnostic servicing. Besides electrical system inspection, check brake booster operation, brake fluid level, and oil leaks.
- If tire size and type are used in an improper combination, or brake pads are not Genuine NISSAN parts, stopping distance or steering stability may deteriorate.
- ABS might be out of order or malfunctions by putting a radio (wiring inclusive), an antenna and a lead-in wire near the control unit.
- If aftermarket parts (car stereo, CD player, etc.) have been installed, check for incidents such as harness pinches, open circuits, and improper wiring.
- VDC system may not operate normally or a VDC OFF indicator lamp or SLIP indicator lamp may light.
- When replacing the following parts with parts other than genuine parts or making modifications: Suspension related parts (shock absorber, spring, bushing, etc.), tires, wheels (other than specified sizes), brake-related parts (pad, rotor, caliper, etc.), engine-related parts (muffler, ECM, etc.) and body reinforcement-related parts (roll bar, tower bar, etc.).
- When driving with worn or deteriorated suspension, tires and brake-related parts.

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

PREPARATION

< PREPARATION >

[VDC/TCS/ABS]




PREPARATION

PREPARATION

Special Service Tool


INFOID:000000004242494

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

| Tool number (Kent-Moore No.) Tool name | Description |
|---|------------------------------|
| <p>ST30720000 (J-25405) Drift a: 77 mm (3.03 in) dia. b: 55.5 mm (2.185 in) dia.</p>  <p style="text-align: right;">ZZA0701D</p> | |
| <p>ST27863000 (—) Drift a: 74.5 mm (2.933 in) dia. b: 62.5 mm (2.461 in) dia.</p>  <p style="text-align: right;">ZZA0832D</p> | Installing rear sensor rotor |
| <p>KV40104710 (—) a: 76.3 mm (3.004 in) dia. b: 67.9 mm (2.673 in) dia.</p>  <p style="text-align: right;">ZZA0832D</p> | |

Commercial Service Tool

INFOID:000000004242495

| Tool name | Description |
|---|-----------------------|
| <p>1. Flare nut crowfoot a: 10 mm (0.39 in) /12 mm (0.47 in) 2. Torque wrench</p>  <p style="text-align: right;">S-NT360</p> | Installing brake tube |

WHEEL SENSOR

< REMOVAL AND INSTALLATION >


[VDC/TCS/ABS]

REMOVAL AND INSTALLATION

WHEEL SENSOR

Exploded View

INFOID:000000004242496



1. Front LH wheel sensor

2. Rear LH wheel sensor

3. Rear RH wheel sensor

A. Front

B. Rear

↔: Vehicle front

Refer to GI section [GI-4. "Components"](#) for symbol marks in the figure.

NOTE:

The above figure (front side) shows left side. Right side is the mirror image.

Removal and Installation

INFOID:000000004242497

REMOVAL

Pay attention to the following when removing sensor.

CAUTION:

- Do not twist sensor harness as much as possible, when removing it. Pull sensors out without pulling sensor harness.
- Take care to avoid damaging sensor edges or rotor teeth. Remove wheel sensor first before removing front or rear wheel hub. This is to avoid damage to sensor wiring and loss of sensor function.

INSTALLATION

Pay attention to the following when installing wheel sensor. Tighten installation bolts to the specified torques. Refer to [BRC-101. "Exploded View"](#).

- When installing, make sure there is no foreign material such as iron chips on and in the mounting hole of the wheel sensor. Make sure no foreign material has been caught in the sensor rotor. Remove any foreign material and clean the mount.
- When installing wheel sensor, be sure to press rubber grommets in until they lock at locations shown above in the figure. When installed, harness must not be twisted.

SENSOR ROTOR

[VDC/TCS/ABS]

< REMOVAL AND INSTALLATION >

SENSOR ROTOR

FRONT SENSOR ROTOR

FRONT SENSOR ROTOR : Exploded View

INFOID:000000004242498

Refer to [FAX-6, "Exploded View"](#) (2WD models), [FAX-16, "Exploded View"](#) (AWD models).

FRONT SENSOR ROTOR : Removal and Installation

INFOID:000000004242499

REMOVAL

Sensor rotor cannot be disassembled. Remove the sensor rotor together with hub bearing assembly. Refer to [FAX-6, "Exploded View"](#) (2WD models), [FAX-16, "Exploded View"](#) (AWD models).


INSTALLATION

Sensor rotor cannot be disassembled. Remove the sensor rotor together with hub bearing assembly. Refer to [FAX-6, "Exploded View"](#) (2WD models), [FAX-16, "Exploded View"](#) (AWD models).

REAR SENSOR ROTOR

REAR SENSOR ROTOR : Exploded View

INFOID:000000004242500



1. Side flange
2. Rear wheel sensor rotor

Refer to GI section [GI-4, "Components"](#) for symbol marks in the figure.

REAR SENSOR ROTOR : Removal and Installation

INFOID:000000004242501

REMOVAL

- Follow the procedure below to remove rear sensor rotor.
- Remove side flange.
- R200 (2WD) models: refer to [DLN-176, "2WD : Exploded View"](#).
- R200 (AWD) models: refer to [DLN-189, "AWD : Exploded View"](#).
- R200V (M/T) models: refer to [DLN-249, "M/T : Exploded View"](#).
- R200V (A/T) models: refer to [DLN-261, "A/T : Exploded View"](#).
- Using a bearing replacer (suitable tool) and puller (suitable tool), remove sensor rotor from side flange.

INSTALLATION

CAUTION:

Do not reuse sensor rotor.

SENSOR ROTOR

[VDC/TCS/ABS]

< REMOVAL AND INSTALLATION >


- Follow the procedure below to install rear sensor rotor.
- Using a drifts, press rear sensor rotor onto side flange.

A: Drift [SST: ST30720000 (J-25405)]

B: Drift [SST: ST27863000 (—)]

C: Drift [SST: KV40104710 (—)]

- Install side flange.
- R200 (2WD) models: refer to [DLN-176, "2WD : Exploded View"](#).
- R200 (AWD) models: refer to [DLN-189, "AWD : Exploded View"](#).
- R200V (M/T) models: refer to [DLN-249, "M/T : Exploded View"](#).
- R200V (A/T) models: refer to [DLN-261, "A/T : Exploded View"](#).



A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)


< REMOVAL AND INSTALLATION >

[VDC/TCS/ABS]

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Exploded View

INFOID:000000004242502



- | | | |
|--|--|--------------------------------------|
| 1. ABS actuator and electric unit (control unit) | 2. Connector | 3. Bushing |
| 4. Bracket | | |
| A. Left side of dash panel | B. From master cylinder secondary side | C. From master cylinder primary side |
| D. To front LH brake caliper | E. To rear RH brake caliper | F. To Rear LH brake caliper |
| G. To front RH brake caliper | | |

←: Vehicle front

Refer to GI section [GI-4, "Components"](#) for symbol marks in the figure.

Removal and Installation

INFOID:000000004242503

REMOVAL

CAUTION:

- Before servicing, disconnect the battery cable from negative terminal.
- To remove brake tube, use a flare nut wrench to prevent flare nuts and brake tube from being damaged. To install, use flare nut crowfoot and torque wrench.
- Do not apply excessive impact to ABS actuator and electric unit (control unit), such as dropping it.
- Do not remove and install actuator by holding harness.
- After work is completed, bleed air from brake tube. Refer to [BR-11, "Bleeding Brake System"](#).

1. Remove cowl top cover. Refer to [EXT-20, "Exploded View"](#).
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Loosen brake tube flare nuts, then remove brake tubes from ABS actuator and electric unit (control unit).
4. Remove tire (front LH side).
5. Remove fender protector (rear): (front LH side). Refer to [EXT-23, "FENDER PROTECTOR : Exploded View"](#).
6. Remove ABS actuator and electric unit (control unit) bracket mounting nut.

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< REMOVAL AND INSTALLATION >

[VDC/TCS/ABS]

7. Remove ABS actuator and electric unit (control unit) from vehicle.

INSTALLATION

Note the following, and install in the reverse order of removal.

CAUTION:

- Before servicing, disconnect the battery cable from negative terminal.
- To remove brake tube, use a flare nut wrench to prevent flare nuts and brake tube from being damaged. To install, use flare nut crowfoot and torque wrench.
- Do not apply excessive impact to ABS actuator and electric unit (control unit), such as dropping it.
- Do not remove and install actuator by holding harness.
- After work is completed, bleed air from brake tube. Refer to [BR-11, "Bleeding Brake System"](#).
- After installing harness connector in the ABS actuator and electric unit (control unit), make sure connector is securely locked.
- When replacing ABS actuator and electric unit (control unit), make sure to adjust neutral position of steering angle sensor. Refer to [BRC-8, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

YAW RATE/SIDE G SENSOR


< REMOVAL AND INSTALLATION >

[VDC/TCS/ABS]

YAW RATE/SIDE G SENSOR

Exploded View

INFOID:000000004242504



1. Yaw rate/side G sensor

↔: Vehicle front

Refer to GI section [GI-4, "Components"](#) for symbol makes in the figure.

Removal and Installation

INFOID:000000004242505

REMOVAL

CAUTION:

Do not drop or strike yaw rate/side G sensor, or do not use power tool etc., because yaw rate/side G sensor is sensitive to the impact.

1. Remove center console. Refer to [IP-23, "Exploded View"](#).
2. Disconnect yaw rate/side G sensor harness connector.
3. Remove mounting bolts. Remove yaw rate/side G sensor.

INSTALLATION

Note the following, and install in the reverse order of removal.

CAUTION:

Do not drop or strike yaw rate/side G sensor, or do not use power tool etc., because yaw rate/side G sensor is sensitive to the impact.

STEERING ANGLE SENSOR


< REMOVAL AND INSTALLATION >

[VDC/TCS/ABS]

STEERING ANGLE SENSOR

Exploded View

INFOID:000000004242506



1. Steering angle sensor

↔: Vehicle front

Refer to GI section [GI-4. "Components"](#) for symbol marks in the figure.

Removal and Installation

INFOID:000000004242507

REMOVAL

1. Remove spiral cable assembly. Refer to [SR-15. "Exploded View"](#).
2. Remove steering angle sensor from spiral cable assembly.

INSTALLATION

Note the following, and install in the reverse order of removal.

CAUTION:

- After work, make sure to adjust neutral position of steering angle sensor. Refer to [BRC-8. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- Perform 4WAS front actuator adjustment. Refer to [STC-28. "4WAS FRONT ACTUATOR NEUTRAL POSITION ADJUSTMENT : Description"](#).

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

SYSTEM DESCRIPTION

PREVIEW FUNCTION

System Description

INFOID:000000004500859

FUNCTION DESCRIPTION

When the Preview Function identifies the need to apply emergency braking by sensing a vehicle ahead in the same lane and the distance and relative speed from it, it applies the brake pre-pressure before the driver depress the brake pedal and helps improve brake response by reducing pedal free play.

The Preview Function shares component parts and diagnosis with the ICC (Intelligent Cruise Control) system.

CAUTION:

This system is only an aid to assist braking operation and is not a collision warning or avoidance device. It is the driver's responsibility to stay alert, drive safely and be in control of the vehicle at all times.

OPERATION DESCRIPTION

Operation

- The system detects the distance to the vehicle in front with the ICC sensor integrated unit of ICC and judges the necessity of emergency braking.
- The system detects the accelerator pedal release operation of the driver by the accelerator pedal position sensor and estimates the driver's brake operation intention.
- If the system is judged that the emergency braking is necessary or that the driver has the intention to operate the brake it supplies the power supply to the brake booster to apply pre-pressure and adjusts the brake play.

NOTE:

This system will not operate when the vehicle is moving at approximately 32 km/h (20 MPH) or less.

End of Operation

The pre-pressure function ceases when the following conditions are met:

1. When the driver depresses the accelerator pedal or the brake pedal.
2. If the driver does not operate the accelerator pedal or brake pedal within approximately 1 second.

PREVIEW FUNCTION


[BRAKE ASSIST]

< SYSTEM DESCRIPTION >

Component Parts Location

INFOID:000000004510432

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P



- 1. Information display, ICC system warning lamp
- 4. ECM
- 7. ICC brake switch

- 2. Buzzer (ICC warning chime)
- 5. ICC sensor integrated unit
- 8. Stop lamp switch

- 3. ICC steering switch
- 6. ICC brake hold relay
- 9. ICC clutch switch

JSOIA0007GB

PREVIEW FUNCTION

[BRAKE ASSIST]

< SYSTEM DESCRIPTION >

10. ABS actuator and electric unit (control unit)

A. On the combination meter

B. Back of combination meter

C. Steering wheel (RH)

D. Behind the glove box

E. Front bumper (LH)

F. Engine room (LH)

G. Upper side of brake pedal

H. Upper side clutch pedal

Component Description

INFOID:000000004500861

×: Applicable

| Component | Function Description | | | Description |
|---|----------------------|----|----|--|
| | *1 | *2 | *3 | |
| ICC sensor integrated unit | × | × | × | Refer to CCS-43, "Description" . |
| ECM | × | × | × | Refer to CCS-70, "Description" . |
| ABS actuator and electric unit (control unit) | × | × | × | Refer to CCS-50, "Description" . |
| BCM | × | | | Transmits the front wiper request signal to ICC sensor integrated unit via CAN communication. |
| Unified meter and A/C amp. | × | × | × | Receives the meter display signal, buzzer output signal, and ICC warning lamp signal from ICC sensor integrated unit via CAN communication and transmits them to the combination meter via the communication line. |
| Combination meter | × | × | × | Performs the following operations using the signals received from the unified meter and A/C amp. via the communication line. <ul style="list-style-type: none"> Displays the ICC system operation status using the meter display signal. Illuminates the ICC system warning lamp using the ICC warning lamp signal. Operates the buzzer (ICC warning chime) using the buzzer output signal. |
| ICC brake switch | × | × | × | Refer to CCS-52, "Description" . |
| Stop lamp switch | × | × | × | |
| ICC brake hold relay | × | | × | Refer to CCS-64, "Description" . |
| Park/neutral position switch | × | × | | Refer to CCS-103, "Description" . |
| ICC clutch switch | × | × | | Refer to CCS-52, "Description" . |

*1: Vehicle-to-vehicle distance control mode

*2: Conventional (fixed speed) cruise control mode

*3: Brake Assist (With Preview Function)

DTC/CIRCUIT DIAGNOSIS

PREVIEW FUNCTION

Diagnosis Procedure

INFOID:000000004500862

1. PREVIEW FUNCTION DIAGNOSIS

When the preview function is not operating properly, the buzzer sounds and the preview function warning lamp will come on.

NOTE:

The preview function warning lamp shares the ICC system warning lamp.

>> Go to ICC. Refer to [CCS-4, "Work Flow"](#).

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

SYMPTOM DIAGNOSIS


NORMAL OPERATING CONDITION

Description

INFOID:000000004500863

PRECAUTIONS FOR PREVIEW FUNCTION

- This system is only an aid to assist braking operation and is not a collision warning or avoidance device. It is the driver's responsibility to stay alert, drive safely and be in control of the vehicle at all times.
- As there is a performance limit to the Preview Function, never rely solely on this system. This system does not correct careless inattentive or absent-minded driving, or overcome poor visibility in rain, fog, or other bad weather. Reduce vehicle speed by depressing the brake, in order to maintain a safe distance between vehicles.
- The system may not detect a vehicle ahead, depending on road or weather conditions. While the vehicle still travels and the Brake Assist System operates under normal conditions, the Preview Function may operate improperly under the following conditions:
 - When rain, snow or dirt adhere to the system sensor
 - When strong light (for example, at sunrise or sunset) is directly shining on the front of the vehicle
 - Winding or hilly roads may cause the sensor to temporarily not detect a vehicle in the same lane or may detect objects or vehicles in other lanes.
 - Vehicle position in the lane may cause the sensor to temporarily not detect a vehicle in the same lane or may detect objects or vehicles in other lanes.
- The system will not detect:
 - Pedestrians or objects in the roadway
 - Oncoming vehicles in the same lane
 - Motorcycles traveling offset in the travel lane as illustrated
- When the Preview Function operates, the brake pedal may move slightly and may make a small noise. This is not a system malfunction.



PRECAUTION

PRECAUTIONS

Precautions for Preview Function Service

INFOID:000000004500864

CAUTION:

- Never look straight into the laser beam discharger when adjusting laser beam aiming.
- Never use the ICC sensor integrated unit removed from vehicle. Never disassemble or remodel.

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC