

# MWI

## SECTION

### METER, WARNING LAMP & INDICATOR

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

## CONTENTS

<b>BASIC INSPECTION</b> .....	4	<b>ODO/TRIP METER</b> .....	19
<b>DIAGNOSIS AND REPAIR WORKFLOW</b> .....	4	ODO/TRIP METER : System Diagram .....	19
Work flow .....	4	ODO/TRIP METER : System Description .....	19
<b>SYSTEM DESCRIPTION</b> .....	6	ODO/TRIP METER : Component Parts Location .....	20
<b>METER SYSTEM</b> .....	6	ODO/TRIP METER : Component Description .....	20
<b>METER SYSTEM</b> .....	6	<b>SHIFT POSITION INDICATOR</b> .....	21
METER SYSTEM : System Diagram .....	6	SHIFT POSITION INDICATOR : System Diagram .....	21
METER SYSTEM : System Description .....	6	SHIFT POSITION INDICATOR : System Description .....	21
METER SYSTEM : Component Parts Location .....	10	SHIFT POSITION INDICATOR : Component Parts Location .....	22
METER SYSTEM : Component Description .....	10	SHIFT POSITION INDICATOR : Component Description .....	23
<b>SPEEDOMETER</b> .....	11	<b>WARNING LAMPS/INDICATOR LAMPS</b> .....	23
SPEEDOMETER : System Diagram .....	11	WARNING LAMPS/INDICATOR LAMPS : System Diagram .....	23
SPEEDOMETER : System Description .....	11	WARNING LAMPS/INDICATOR LAMPS : System Description .....	23
SPEEDOMETER : Component Parts Location .....	12	WARNING LAMPS/INDICATOR LAMPS : Component Parts Location .....	24
SPEEDOMETER : Component Description .....	12	WARNING LAMPS/INDICATOR LAMPS : Component Description .....	24
<b>TACHOMETER</b> .....	13	<b>METER ILLUMINATION CONTROL</b> .....	25
TACHOMETER : System Diagram .....	13	METER ILLUMINATION CONTROL : System Diagram .....	25
TACHOMETER : System Description .....	13	METER ILLUMINATION CONTROL : System Description .....	25
TACHOMETER : Component Parts Location .....	14	METER ILLUMINATION CONTROL : Component Parts Location .....	26
TACHOMETER : Component Description .....	14	METER ILLUMINATION CONTROL : Component Description .....	26
<b>ENGINE COOLANT TEMPERATURE GAUGE</b> .....	15	<b>INFORMATION DISPLAY</b> .....	27
ENGINE COOLANT TEMPERATURE GAUGE : System Diagram .....	15	INFORMATION DISPLAY : System Diagram .....	27
ENGINE COOLANT TEMPERATURE GAUGE : System Description .....	15	INFORMATION DISPLAY : System Description .....	27
ENGINE COOLANT TEMPERATURE GAUGE : Component Parts Location .....	16	INFORMATION DISPLAY : Component Parts Location .....	30
ENGINE COOLANT TEMPERATURE GAUGE : Component Description .....	16	INFORMATION DISPLAY : Component Description .....	31
<b>FUEL GAUGE</b> .....	17		
FUEL GAUGE : System Diagram .....	17		
FUEL GAUGE : System Description .....	17		
FUEL GAUGE : Component Parts Location .....	18		
FUEL GAUGE : Component Description .....	18		

MWI

<b>COMPASS</b> .....	<b>32</b>	<b>IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)</b> .....	<b>52</b>
Description .....	32	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) : Diagnosis Procedure .....	52
Component Parts Location .....	34		
Special Repair Requirement .....	34		
<b>CLOCK</b> .....	<b>35</b>	<b>FUEL LEVEL SENSOR SIGNAL CIRCUIT</b> .....	<b>54</b>
Component Parts Location .....	35	Description .....	54
<b>DIAGNOSIS SYSTEM (METER)</b> .....	<b>36</b>	Component Function Check .....	54
Diagnosis Description .....	36	Diagnosis Procedure .....	55
<b>DIAGNOSIS SYSTEM (UNIFIED METER AND A/C AMP.)</b> .....	<b>38</b>	Component Inspection .....	56
CONSULT Function (METER/M&A) .....	38	<b>METER CONTROL SWITCH SIGNAL CIRCUIT</b> .....	<b>58</b>
<b>DTC/CIRCUIT DIAGNOSIS</b> .....	<b>42</b>	Description .....	58
<b>U1000 CAN COMM CIRCUIT</b> .....	<b>42</b>	Diagnosis Procedure .....	58
Description .....	42	Component Inspection .....	59
DTC Logic .....	42	<b>OIL PRESSURE SWITCH SIGNAL CIRCUIT</b> ...	<b>60</b>
Diagnosis Procedure .....	42	Description .....	60
<b>U1010 CONTROL UNIT (CAN)</b> .....	<b>43</b>	Component Function Check .....	60
Description .....	43	Diagnosis Procedure .....	60
DTC Logic .....	43	Component Inspection .....	60
Diagnosis Procedure .....	43	<b>PARKING BRAKE SWITCH SIGNAL CIRCUIT</b> .....	<b>62</b>
<b>B2201 COMMUNICATION ERROR 1</b> .....	<b>44</b>	Description .....	62
Description .....	44	Component Function Check .....	62
DTC Logic .....	44	Diagnosis Procedure .....	62
Diagnosis Procedure .....	44	Component Inspection .....	63
<b>B2202 COMMUNICATION ERROR 2</b> .....	<b>46</b>	<b>WASHER LEVEL SWITCH SIGNAL CIRCUIT..</b>	<b>64</b>
Description .....	46	Description .....	64
DTC Logic .....	46	Diagnosis Procedure .....	64
Diagnosis Procedure .....	46	Component Inspection .....	64
<b>B2205 VEHICLE SPEED</b> .....	<b>48</b>	<b>COMPASS</b> .....	<b>65</b>
Description .....	48	Wiring Diagram - COMPASS - .....	65
DTC Logic .....	48	<b>CLOCK</b> .....	<b>67</b>
Diagnosis Procedure .....	48	Wiring Diagram - CLOCK - .....	67
<b>B2267 ENGINE SPEED</b> .....	<b>49</b>	<b>ECU DIAGNOSIS INFORMATION</b> .....	<b>69</b>
Description .....	49	<b>COMBINATION METER</b> .....	<b>69</b>
DTC Logic .....	49	Reference Value .....	69
Diagnosis Procedure .....	49	Wiring Diagram - METER - .....	72
<b>B2268 WATER TEMP</b> .....	<b>50</b>	Fail-safe .....	82
Description .....	50	DTC Index .....	83
DTC Logic .....	50	<b>UNIFIED METER AND A/C AMP.</b> .....	<b>84</b>
Diagnosis Procedure .....	50	Reference Value .....	84
<b>POWER SUPPLY AND GROUND CIRCUIT</b> ....	<b>51</b>	Wiring Diagram - METER - .....	92
<b>COMBINATION METER</b> .....	<b>51</b>	Fail-safe .....	102
COMBINATION METER : Diagnosis Procedure ...	51	DTC Index .....	103
<b>UNIFIED METER AND A/C AMP.</b> .....	<b>51</b>	<b>IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)</b> .....	<b>105</b>
UNIFIED METER AND A/C AMP. : Diagnosis Procedure .....	51	Reference Value .....	105
		Wiring Diagram - IPDM E/R - .....	112
		Fail-safe .....	115

DTC Index .....	117	<b>THE AMBIENT TEMPERATURE DISPLAY IS INCORRECT</b> .....	126	A
<b>SYMPTOM DIAGNOSIS</b> .....	118	Description .....	126	
<b>THE FUEL GAUGE POINTER DOES NOT MOVE</b> .....	118	Diagnosis Procedure .....	126	B
Description .....	118	<b>NORMAL OPERATING CONDITION</b> .....	127	
Diagnosis Procedure .....	118	<b>COMPASS</b> .....	127	C
<b>THE METER CONTROL SWITCH IS INOPERATIVE</b> .....	119	COMPASS : Description .....	127	
Description .....	119	<b>INFORMATION DISPLAY</b> .....	127	D
Diagnosis Procedure .....	119	INFORMATION DISPLAY : Description .....	127	
<b>THE OIL PRESSURE WARNING LAMP DOES NOT TURN ON</b> .....	120	<b>PRECAUTION</b> .....	128	E
Description .....	120	<b>PRECAUTIONS</b> .....	128	
Diagnosis Procedure .....	120	Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	128	F
<b>THE OIL PRESSURE WARNING LAMP DOES NOT TURN OFF</b> .....	121	Precautions for Removing Battery Terminal .....	128	
Description .....	121	<b>PREPARATION</b> .....	129	G
Diagnosis Procedure .....	121	<b>PREPARATION</b> .....	129	
<b>THE PARKING BRAKE RELEASE WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY</b> .....	122	Commercial Service Tools .....	129	H
Description .....	122	<b>REMOVAL AND INSTALLATION</b> .....	130	
Diagnosis Procedure .....	122	<b>COMBINATION METER</b> .....	130	I
<b>THE LOW WASHER FLUID WARNING CONTINUES DISPLAYING, or DOES NOT DISPLAY</b> .....	123	Exploded View .....	130	
Description .....	123	Removal and Installation .....	130	J
Diagnosis Procedure .....	123	Disassembly and Assembly .....	131	
<b>THE DOOR OPEN WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY</b> .....	124	<b>UNIFIED METER AND A/C AMP.</b> .....	132	K
Description .....	124	Exploded View .....	132	
Diagnosis Procedure .....	124	Removal and Installation .....	132	L
<b>THE TRUNK OPEN WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY</b> .....	125	<b>METER CONTROL SWITCH</b> .....	133	
Description .....	125	Exploded View .....	133	M
Diagnosis Procedure .....	125	Removal and Installation .....	133	
		<b>COMPASS</b> .....	134	
		Exploded View .....	134	
		Removal and Installation .....	134	
		<b>CLOCK</b> .....	135	
		Exploded View .....	135	
		Removal and Installation .....	135	

MWI

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

Work flow

INFOID:000000010990544

#### OVERALL SEQUENCE



- Reference 1...[MWI-36, "Diagnosis Description"](#).
- Reference 2...[MWI-103, "DTC Index"](#).
- Reference 3...[MWI-51, "COMBINATION METER : Diagnosis Procedure"](#).

#### DETAILED FLOW

##### 1.OBTAIN INFORMATION ABOUT SYMPTOM

Interview the customer to obtain as much information as possible about the conditions and environment under which the malfunction occurred.

>> GO TO 2.

##### 2.CHECK SYMPTOM

# DIAGNOSIS AND REPAIR WORKFLOW

## < BASIC INSPECTION >

---

- Check the symptom based on the information obtained from the customer.
- Check that any other malfunctions are present.

>> GO TO 3.

## 3.CHECK ON BOARD DIAGNOSIS OPERATION

---

Check that the on board diagnosis function operates. Refer to [MWI-36, "Diagnosis Description"](#).

Does the on board diagnosis function operate normally?

YES >> GO TO 4.

NO >> GO TO 6.

## 4.CHECK CONSULT SELF-DIAGNOSIS RESULTS

---

1. Connect CONSULT and perform self-diagnosis. Refer to [MWI-103, "DTC Index"](#).
2. When DTC is detected, follow the instructions below:
  - Record DTC and Freeze Frame Data.

Are self-diagnosis results normal?

YES >> GO TO 5.

NO >> GO TO 8.

## 5.NARROW DOWN THE MALFUNCTIONING PARTS BY SYMPTOM DIAGNOSIS

---

Perform symptom diagnosis and narrow down the malfunctioning parts.

>> GO TO 7.

## 6.CHECK COMBINATION METER POWER SUPPLY AND GROUND CIRCUITS

---

Inspect combination meter power supply and ground circuits. Refer to [MWI-51, "COMBINATION METER : Diagnosis Procedure"](#).

Is inspection result OK?

YES >> GO TO 7.

NO >> GO TO 8.

## 7.REPLACE COMBINATION METER

---

Replace combination meter.

>> GO TO 9.

## 8.REPAIR OR REPLACE MALFUNCTIONING PARTS

---

Repair or replace the malfunctioning parts.

**NOTE:**

If DTC is displayed, erase DTC after repair or replace malfunctioning parts.

>> GO TO 9.

## 9.FINAL CHECK

---

Check that the combination meter operates normally.

Do they operate normally?

YES >> INSPECTION END

NO >> GO TO 1.

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

# METER SYSTEM

< SYSTEM DESCRIPTION >


## SYSTEM DESCRIPTION

### METER SYSTEM

### METER SYSTEM

### METER SYSTEM : System Diagram

INFOID:000000010990545



### METER SYSTEM : System Description

INFOID:000000010990546

#### COMBINATION METER

- The combination meter retrieves the information required for controlling the operations of the meters, indicator lamps/warning lamps and information display from the communication signals from the unified meter and A/C amp. and the signals from various switches and sensors.
- The combination meter incorporates a trip computer that displays warnings and messages on the information display according to the information received from various units.
- The combination meter incorporates a buzzer function that sounds an audible alarm with the integrated buzzer device. Refer to [WCS-5. "WARNING CHIME SYSTEM : System Description"](#) for further details.
- The combination meter integrates the meter circuit check function and the segment check function that checks the information display operation.

#### UNIFIED METER AND A/C AMP.

- Receives information required by the combination meter from various units via CAN communication line and transmits it to the combination meter with communication line.
- The unified meter and A/C amp. incorporates a power saving control function that reduces the power consumption according to the vehicle status. Refer to [BCS-13. "System Description"](#) for details.
- The unified meter and A/C amp. incorporates a diagnosis function that allows the technician to perform diagnoses with CONSULT.

# METER SYSTEM

## < SYSTEM DESCRIPTION >

Between unified meter and A/C amp. and combination meter.

Unit	Communication line	Input from combination meter	Output to combination meter	
Unified meter and A/C amp.	Communication line (METER <-> AMP.)	<ul style="list-style-type: none"> <li>• Parking brake switch signal</li> <li>• Washer level switch signal</li> <li>• Meter day/night condition signal</li> <li>• Illumination control switch signal</li> <li>• Refuel status signal</li> <li>• Low fuel warning lamp signal</li> <li>• Odo data signal</li> </ul>	<ul style="list-style-type: none"> <li>• Vehicle speed signal</li> <li>• Turn indicator signal</li> <li>• High beam request signal</li> <li>• Front fog light request signal</li> <li>• Engine speed signal</li> <li>• Fuel level sensor signal</li> <li>• Engine coolant temperature signal</li> <li>• A/T CHECK indicator signal</li> <li>• Oil pressure switch signal</li> <li>• Door switch signal</li> <li>• Buzzer output signal</li> <li>• AFS OFF indicator lamp signal</li> <li>• TPMS malfunction warning lamp signal</li> <li>• AWD warning lamp signal</li> <li>• VDC OFF indicator signal</li> <li>• ABS warning lamp signal</li> <li>• Brake warning lamp signal</li> <li>• Malfunction indicator lamp signal</li> <li>• Master warning signal</li> <li>• AWD warning lamp signal</li> <li>• Position light request signal</li> </ul>	A B C D E F
	Communication line (LCD <-> AMP.)	<ul style="list-style-type: none"> <li>• Average fuel consumption reset signal</li> <li>• Travel time reset signal</li> <li>• Possible driving distance reset signal</li> <li>• Average vehicle speed reset signal</li> <li>• Select switch signal</li> <li>• Enter switch signal</li> <li>• Trip A/B reset switch signal</li> <li>• Ambient air temperature display signal</li> </ul>	<ul style="list-style-type: none"> <li>• Shift position signal</li> <li>• Meter display signal</li> <li>• Door switch signal</li> <li>• Trunk switch signal</li> <li>• Fuel level sensor signal</li> <li>• Parking brake switch signal</li> <li>• Washer level switch signal</li> <li>• Charge warning signal</li> <li>• Instantaneous fuel consumption display signal</li> <li>• Ambient air temperature display signal</li> <li>• Average fuel consumption display signal</li> <li>• Average vehicle speed display signal</li> <li>• Possible driving distance display signal</li> <li>• Engine speed signal</li> <li>• Vehicle speed signal</li> <li>• Low tire pressure warning lamp signal</li> <li>• Fuel filler cap warning display signal</li> </ul>	G H I J K

### IPDM E/R

- IPDM E/R reads the ON/OFF signals of the oil pressure switch and transmits the oil pressure switch signal to the unified meter and A/C amp. via BCM with the CAN communication line.
- IPDM E/R is equipped with the diagnosis function. It can perform the operation check of oil pressure warning lamp with the auto active test and the diagnosis with CONSULT.

### METER CONTROL FUNCTION LIST

X: Applicable

System		Description	Signal source	Via unified meter and A/C amp.
Meter/gauge	Speedometer	Receives vehicle speed signal and indicates vehicle speed.	ABS actuator and electric unit (control unit)	X
	Tachometer	Receives engine speed signal and indicates engine speed.	ECM	X
	Fuel gauge	Receives fuel level sensor signal and indicates fuel level.	Fuel level sensor unit	X
	Engine coolant temperature gauge	Receives engine coolant temperature signal and indicates coolant temperature.	ECM	X

# METER SYSTEM

## < SYSTEM DESCRIPTION >


System		Description	Signal source	Via unified meter and A/C amp.
Warning lamp/ indicator lamp	Oil pressure warning lamp	Receives oil pressure warning lamp signal and illuminates warning lamp.	IPDM E/R	X
	Master warning	Illuminates according to warning output on information display.	—	X
Information display	Door open warning	Receives door switch signals and displays warning.	BCM	X
	Trunk open warning	Receives trunk lid opener switch signal and displays warning.	BCM	X
	Parking brake release warning	Receives parking brake switch signal and vehicle speed signal and displays warnings.	Parking brake switch	X
			ABS actuator and electric unit (control unit)	
	Low fuel warning	Receives fuel gauge signal and displays warning if fuel level decreases to 15 ℓ (4 US gal, 3-1/4 Imp gal) or less.	Fuel level sensor unit	X
	Low washer fluid warning	Receives washer level switch signal and displays warning.	Washer level switch	
	Low outside temperature warning	Monitors ambient sensor signal and displays warning if ambient temperature decreases to 3°C (37°F) or less. (If enabled)	Ambient sensor	X
	Low tire pressure warning	Receives low tire pressure warning lamp signal and displays warning.	BCM	X
	Fuel filler cap warning	Receives fuel filler cap warning display signals and displays warning.	ECM	X
	Instantaneous fuel consumption	Calculates instantaneous fuel consumption based on received vehicle speed signals and fuel consumption monitor signal and displays it.	ECM	X
			ABS actuator and electric unit (control unit)	X
	Average fuel consumption	Calculates average fuel consumption in a reset-to-reset interval based on received vehicle speed signals and fuel consumption monitor signal and displays it.	ECM	X
			ABS actuator and electric unit (control unit)	X
	Average vehicle speed	Calculates average vehicle speed in a reset-to-reset interval based on received vehicle speed signals and displays it.	ABS actuator and electric unit (control unit)	X
	Travel time	Displays accumulated key switch ON time from reset to reset.	—	X
Travel distance	Calculates accumulated travel distance in a reset-to-reset interval based on received vehicle speed signals and displays it.	ABS actuator and electric unit (control unit)	X	
Possible driving distance	The unified meter and A/C amp. calculates the possible driving distance according to the vehicle speed signal and the fuel level sensor unit received with CAN communication line, and transmits it to the combination meter by means of communication line.	ABS actuator and electric unit (control unit)	X	
		Fuel level sensor unit	X	
Ambient air temperature	Corrects ambient air temperature value based on received ambient sensor signals and displays it.	Ambient sensor	X	



# METER SYSTEM

< SYSTEM DESCRIPTION >

## ARRANGEMENT OF COMBINATION METER



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


MWI

# METER SYSTEM

< SYSTEM DESCRIPTION >

## METER SYSTEM : Component Parts Location

INFOID:0000000110990547



- |  |                                  |                                  |
|--|----------------------------------|----------------------------------|
| 1. Unified meter and A/C amp.                  | 2. BCM                           | 3. IPDM E/R                      |
| 4. Oil pressure switch                         | 5. Ambient sensor                | 6. Combination meter             |
| 7. Fuel level sensor unit and fuel pump (main) | 8. Fuel level sensor unit (sub)  |                                  |
| A. Behind cluster lid C                        | B. 2WD [oil pan (upper) RH side] | C. AWD (oil filter bracket part) |
| D. Condenser (front)                           | E. Rear seat (lower right)       | F. Rear seat (lower left)        |

## METER SYSTEM : Component Description

INFOID:0000000110990548

Unit	Description
Combination meter	<p>Controls the following with the signals from the unified meter and A/C amp, switches and sensors.</p> <ul style="list-style-type: none"> <li>• Speedometer</li> <li>• Engine coolant temperature gauge</li> <li>• Warning lamps</li> <li>• Information display</li> <li>• Tachometer</li> <li>• Fuel gauge</li> <li>• Indicator lamps</li> <li>• Warning chime</li> </ul>

# METER SYSTEM


## < SYSTEM DESCRIPTION >

Unit	Description
Unified meter and A/C amp.	<ul style="list-style-type: none"> <li>The combination meter receives the necessary information from various units via CAN communication line and transmits them to the unified meter and A/C amp. with the communication line that connects both of them.</li> <li>Transmits the fuel gauge signal from the fuel gauge unit with the communication line that connects the unified meter and A/C amp. and the combination meter.</li> <li>Reads the signals from the A/T shift selector and transmits them to TCM with CAN communication line.</li> </ul>
IPDM E/R	IPDM E/R reads the ON/OFF signals of the oil pressure switch and transmits the oil pressure switch signal to the unified meter and A/C amp. via BCM with CAN communication line.
Fuel level sensor unit	Refer to <a href="#">MWI-54. "Description"</a> .
Oil pressure switch	Refer to <a href="#">MWI-60. "Description"</a> .
ECM	Transmits the following signals to the unified meter and A/C amp. with CAN communication line. <ul style="list-style-type: none"> <li>Engine speed signal</li> <li>Engine coolant temperature signal</li> <li>Fuel consumption monitor signal</li> <li>Fuel filler cap warning display signal</li> </ul>
ABS actuator and electric unit (control unit)	Transmits the vehicle speed signal to the unified meter and A/C amp. with CAN communication line.
BCM	<ul style="list-style-type: none"> <li>Transmits signals provided by various units to the unified meter and A/C amp. with CAN communication line.</li> <li>Transmits the security signal and low tire pressure warning lamp signal to the combination meter.</li> </ul>
A/T shift selector	Transmits the following signals to the unified meter and A/C amp. <ul style="list-style-type: none"> <li>Manual mode signal</li> <li>Non-manual mode signal</li> <li>Manual mode shift up signal</li> <li>Manual mode shift down signal</li> </ul>
TCM	Transmits shift position signal to the unified meter and A/C amp.
Meter control switch	Refer to <a href="#">MWI-58. "Description"</a> .
Washer level switch	Transmits the washer level signal to the combination meter.
Brake fluid level switch	Transmits the brake fluid level switch signal to the combination meter.
Parking brake switch	Refer to <a href="#">MWI-62. "Description"</a> .

## SPEEDOMETER

### SPEEDOMETER : System Diagram

INFOID:000000010990549



### SPEEDOMETER : System Description

INFOID:000000010990550


- The ABS actuator and electric unit (control unit) converts the pulse signal provided by the wheel sensor to a vehicle speed signal and transmits it to the unified meter and A/C amp. with CAN communication line.
- The unified meter and A/C amp. receives the vehicle speed signal from the ABS actuator and electric unit (control unit) with CAN communication line and transmits it to the combination meter by means of communication line.
- The combination meter indicates the vehicle speed according to the vehicle speed signal received from the unified meter and A/C amp. by means of communication line.

# METER SYSTEM

< SYSTEM DESCRIPTION >

## SPEEDOMETER : Component Parts Location

INFOID:0000000110990551



- |  |                                  |                                  |
|--|----------------------------------|----------------------------------|
| 1. Unified meter and A/C amp.                  | 2. BCM                           | 3. IPDM E/R                      |
| 4. Oil pressure switch                         | 5. Ambient sensor                | 6. Combination meter             |
| 7. Fuel level sensor unit and fuel pump (main) | 8. Fuel level sensor unit (sub)  |                                  |
| A. Behind cluster lid C                        | B. 2WD [oil pan (upper) RH side] | C. AWD (oil filter bracket part) |
| D. Condenser (front)                           | E. Rear seat (lower right)       | F. Rear seat (lower left)        |

## SPEEDOMETER : Component Description

INFOID:0000000110990552


Unit	Description
Combination meter	Indicates the vehicle speed according to the vehicle speed signal received from the unified meter and A/C amp. by means of communication line.
Unified meter and A/C amp.	Transmits the vehicle speed signal received from ABS actuator and electric unit (control unit) with CAN communication line to the combination meter by means of communication line.
ABS actuator and electric unit (control unit)	Transmits the vehicle speed signal to the unified meter and A/C amp. with CAN communication line.

# METER SYSTEM

< SYSTEM DESCRIPTION >

## TACHOMETER

### TACHOMETER : System Diagram



### TACHOMETER : System Description

INFOID:000000010990554

- ECM converts the pulse signal provided by the crankshaft position sensor to an engine speed signal and transmits it to the unified meter and A/C amp. with CAN communication line.
- Unified meter and A/C amp. transmits engine speed signal to combination meter with communication line.
- The unified meter and A/C amp. receives the engine speed signal from ECM with CAN communication line and transmits it to the combination meter by means of communication line.
- Combination meter converses engine speed signal to the angle signal, and commands to tachometer.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


MWI

# METER SYSTEM

< SYSTEM DESCRIPTION >

## TACHOMETER : Component Parts Location

INFOID:0000000110990555



- |  |                                  |                                  |
|--|----------------------------------|----------------------------------|
| 1. Unified meter and A/C amp.                  | 2. BCM                           | 3. IPDM E/R                      |
| 4. Oil pressure switch                         | 5. Ambient sensor                | 6. Combination meter             |
| 7. Fuel level sensor unit and fuel pump (main) | 8. Fuel level sensor unit (sub)  |                                  |
| A. Behind cluster lid C                        | B. 2WD [oil pan (upper) RH side] | C. AWD (oil filter bracket part) |
| D. Condenser (front)                           | E. Rear seat (lower right)       | F. Rear seat (lower left)        |

## TACHOMETER : Component Description

INFOID:0000000110990556

Unit	Description
Combination meter	Indicates the engine speed according to the engine speed signal received from the unified meter and A/C amp. by means of communication line.
Unified meter and A/C amp.	Transmits the engine speed signal received from ECM with CAN communication line to the combination meter by means of communication line.
ECM	Transmits the engine speed signal to the unified meter and A/C amp. with CAN communication line.


# METER SYSTEM

< SYSTEM DESCRIPTION >

## ENGINE COOLANT TEMPERATURE GAUGE

### ENGINE COOLANT TEMPERATURE GAUGE : System Diagram

INFOID:000000010990557



### ENGINE COOLANT TEMPERATURE GAUGE : System Description

INFOID:000000010990558

- ECM converts a signal from engine coolant temperature sensor to engine coolant temperature signal, and transmits to unified meter and A/C amp. with CAN communication line.
- Unified meter and A/C amp. transmits engine coolant temperature signal to combination meter with communication line.
- Combination meter converts engine coolant temperature signal to the angle signal, and commands to engine coolant temperature gauge.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P


MWI

# METER SYSTEM

< SYSTEM DESCRIPTION >

## ENGINE COOLANT TEMPERATURE GAUGE : Component Parts Location

INFOID:0000000110990559



- |  |                                  |                                  |
|--|----------------------------------|----------------------------------|
| 1. Unified meter and A/C amp.                  | 2. BCM                           | 3. IPDM E/R                      |
| 4. Oil pressure switch                         | 5. Ambient sensor                | 6. Combination meter             |
| 7. Fuel level sensor unit and fuel pump (main) | 8. Fuel level sensor unit (sub)  |                                  |
| A. Behind cluster lid C                        | B. 2WD [oil pan (upper) RH side] | C. AWD (oil filter bracket part) |
| D. Condenser (front)                           | E. Rear seat (lower right)       | F. Rear seat (lower left)        |

## ENGINE COOLANT TEMPERATURE GAUGE : Component Description

INFOID:0000000110990560

Unit	Description
Combination meter	Indicates the water temperature gauge according to the engine coolant temperature signal received from the unified meter and A/C amp. by means of communication line.




# METER SYSTEM

## < SYSTEM DESCRIPTION >

Unit	Description
Unified meter and A/C amp.	Transmits the engine coolant temperature signal received from ECM with CAN communication line to the combination meter by means of communication line.
ECM	Transmits the engine coolant temperature signal to the unified meter and A/C amp. with CAN communication line.

## FUEL GAUGE

### FUEL GAUGE : System Diagram



### FUEL GAUGE : System Description

INFOID:0000000010990562

#### CONTROL OUTLINE

- The unified meter and A/C amp. reads the fuel level sensor signal from the fuel gauge unit and transmits it to the combination meter with the communication line.
- The combination meter indicates the fuel level on the fuel gauge according to the received fuel level sensor signal.

#### REFUEL CONTROL

The unit judges that the driver is refueling the vehicle and accelerates the fuel gauge needle movement if the fuel level changes by 15 ℓ (4 US gal, 3-3/10 Imp gal) or more.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


MWI

# METER SYSTEM

< SYSTEM DESCRIPTION >

## FUEL GAUGE : Component Parts Location

INFOID:0000000110990563



- |  |                                  |                                  |
|--|----------------------------------|----------------------------------|
| 1. Unified meter and A/C amp.                  | 2. BCM                           | 3. IPDM E/R                      |
| 4. Oil pressure switch                         | 5. Ambient sensor                | 6. Combination meter             |
| 7. Fuel level sensor unit and fuel pump (main) | 8. Fuel level sensor unit (sub)  |                                  |
| A. Behind cluster lid C                        | B. 2WD [oil pan (upper) RH side] | C. AWD (oil filter bracket part) |
| D. Condenser (front)                           | E. Rear seat (lower right)       | F. Rear seat (lower left)        |

## FUEL GAUGE : Component Description

INFOID:0000000110990564


Unit	Description
Combination meter	Indicates the fuel gauge according to the fuel level sensor signal received from the unified meter and A/C amp. by means of communication line.
Unified meter and A/C amp.	Transmits the fuel level sensor signal from the fuel level sensor unit to the combination meter by means of communication line.
Fuel level sensor unit	Refer to <a href="#">MWI-58, "Description"</a> .

# METER SYSTEM

< SYSTEM DESCRIPTION >

## ODO/TRIP METER

### ODO/TRIP METER : System Diagram



### ODO/TRIP METER : System Description

INFOID:000000010990566

- The unified meter and A/C amp. transmits the vehicle speed signal from ABS actuator and electric unit (control unit) to the combination meter.
- The combination meter calculates the vehicle distance according to the vehicle speed signal. The vehicle distance is displayed.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


MWI

# METER SYSTEM

< SYSTEM DESCRIPTION >

## ODO/TRIP METER : Component Parts Location

INFOID:0000000110990567



- |  |                                  |                                  |
|--|----------------------------------|----------------------------------|
| 1. Unified meter and A/C amp.                  | 2. BCM                           | 3. IPDM E/R                      |
| 4. Oil pressure switch                         | 5. Ambient sensor                | 6. Combination meter             |
| 7. Fuel level sensor unit and fuel pump (main) | 8. Fuel level sensor unit (sub)  |                                  |
| A. Behind cluster lid C                        | B. 2WD [oil pan (upper) RH side] | C. AWD (oil filter bracket part) |
| D. Condenser (front)                           | E. Rear seat (lower right)       | F. Rear seat (lower left)        |

## ODO/TRIP METER : Component Description

INFOID:0000000110990568


Unit	Description
Combination meter	The combination meter calculates the vehicle distance according to the vehicle speed signal. The vehicle distance is displayed.
Unified meter and A/C amp.	The unified meter and A/C amp. transmits the vehicle speed signal from ABS actuator and electric unit (control unit) to the combination meter.
ABS actuator and electric unit (control unit)	Transmits the vehicle speed signal to the unified meter and A/C amp. with CAN communication line.

# METER SYSTEM

< SYSTEM DESCRIPTION >

## SHIFT POSITION INDICATOR

### SHIFT POSITION INDICATOR : System Diagram



### SHIFT POSITION INDICATOR : System Description

INFOID:0000000010990570

Shift position is displayed in the information display LCD in the combination meter.

#### MANUAL MODE

- Unified meter and A/C amp. inputs manual mode signal and manual mode shift-up/down signal from A/T shift selector (manual mode switch), and transmits the signals to TCM with CAN communication line.
- TCM processes manual mode signal and manual mode shift-up/down signal, and transmits manual mode indicator signal and shift position signal to unified meter and A/C amp. with CAN communication line.
- Unified meter and A/C amp. transmits manual mode indicator signal and shift position signal to combination meter with the communication line.
- Combination meter indicates A/T gear position and manual mode indicator, when receiving manual mode indicator signal and shift position signal.
- TCM transmits a manual mode shift refusal signal to the unified meter and A/C amp. via CAN communication line when gear shifting cannot be performed in manual mode.
- The unified meter and A/C amp. transmits a manual mode shift refusal signal to the combination meter via communication line.
- The combination meter blinks the shift position indicator and sounds a buzzer when receiving a manual mode shift refusal signal.

#### NON-MANUAL MODE

- Unified meter and A/C amp. inputs non-manual mode signal from A/T shift selector (manual mode switch), and transmits the signals to TCM with CAN communication line.
- TCM transmits shift position signal to unified meter and A/C amp. with CAN communication line.
- Unified meter and A/C amp. transmits shift position signal to combination meter with the communication line.
- Combination meter indicates shift position when receiving shift position signal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P


MWI

# METER SYSTEM

< SYSTEM DESCRIPTION >

## SHIFT POSITION INDICATOR : Component Parts Location

INFOID:000000010990571



- |  |                                  |                                  |
|--|----------------------------------|----------------------------------|
| 1. Unified meter and A/C amp.                  | 2. BCM                           | 3. IPDM E/R                      |
| 4. Oil pressure switch                         | 5. Ambient sensor                | 6. Combination meter             |
| 7. Fuel level sensor unit and fuel pump (main) | 8. Fuel level sensor unit (sub)  |                                  |
| A. Behind cluster lid C                        | B. 2WD [oil pan (upper) RH side] | C. AWD (oil filter bracket part) |
| D. Condenser (front)                           | E. Rear seat (lower right)       | F. Rear seat (lower left)        |

JSNIA0042ZZ

# METER SYSTEM

< SYSTEM DESCRIPTION >

## SHIFT POSITION INDICATOR : Component Description


INFOID:000000010990572

Unit	Description
Combination meter	<ul style="list-style-type: none"> <li>Displays the shift position on the information display with shift position signal and manual mode indicator signal received from unified meter and A/C amp.</li> <li>The combination meter blinks the shift position indicator and sounds a buzzer when received manual mode shift refusal signal from unified meter and A/C amp.</li> </ul>
Unified meter and A/C amp.	<ul style="list-style-type: none"> <li>Transmits the signals from the A/T shift selector to TCM with CAN communication line.</li> <li>Transmits shift position signal, manual mode indicator signal and manual mode shift refusal signal received from TCM with CAN communication line to the combination meter by means of communication line.</li> </ul>
A/T shift selector	Transmits the following signals to the unified meter and A/C amp. <ul style="list-style-type: none"> <li>Manual mode signal</li> <li>Non-manual mode signal</li> <li>Manual mode shift up signal</li> <li>Manual mode shift down signal</li> </ul>
TCM	Transmits shift position signal, manual mode indicator signal and manual mode shift refusal signal to the unified meter and A/C amp.

## WARNING LAMPS/INDICATOR LAMPS

### WARNING LAMPS/INDICATOR LAMPS : System Diagram

INFOID:000000010990573



### WARNING LAMPS/INDICATOR LAMPS : System Description

INFOID:000000010990574

#### OIL PRESSURE WARNING LAMP

- IPDM E/R inputs oil pressure switch signal from oil pressure switch, and transmits the signal to unified meter and A/C amp. through BCM with CAN communication line.
- Unified meter and A/C amp. transmits oil pressure switch signal to combination meter with communication line.
- Let the combination meter turn oil pressure warning lamp ON with received oil pressure switch signal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M


MWI

# METER SYSTEM

< SYSTEM DESCRIPTION >

## WARNING LAMPS/INDICATOR LAMPS : Component Parts Location

INFOID:0000000110990575



- |  |                                  |                                  |
|--|----------------------------------|----------------------------------|
| 1. Unified meter and A/C amp.                  | 2. BCM                           | 3. IPDM E/R                      |
| 4. Oil pressure switch                         | 5. Ambient sensor                | 6. Combination meter             |
| 7. Fuel level sensor unit and fuel pump (main) | 8. Fuel level sensor unit (sub)  |                                  |
| A. Behind cluster lid C                        | B. 2WD [oil pan (upper) RH side] | C. AWD (oil filter bracket part) |
| D. Condenser (front)                           | E. Rear seat (lower right)       | F. Rear seat (lower left)        |

## WARNING LAMPS/INDICATOR LAMPS : Component Description

INFOID:0000000110990576

Unit	Description
Combination meter	Turns the oil pressure warning lamp ON/OFF according to the oil pressure switch signal received from the unified meter and A/C amp. by means of communication line.
Unified meter and A/C amp.	Transmits the oil pressure switch signal received from the IPDM E/R with BCM to the combination meter by means of communication line.
IPDM E/R	IPDM E/R reads the ON/OFF signals from the oil pressure switch and transmits the oil pressure switch signal to the unified meter and A/C amp. via BCM with the CAN communication line.




# METER SYSTEM

## < SYSTEM DESCRIPTION >

Unit	Description
Oil pressure switch	Refer to <a href="#">MWI-60, "Description"</a> .
BCM	Transmits the oil pressure switch signal received from IPDM E/R via CAN communication to the unified meter and A/C amp. via CAN communication line.

## METER ILLUMINATION CONTROL

### METER ILLUMINATION CONTROL : System Diagram



### METER ILLUMINATION CONTROL : System Description


INFOID:000000010990578

#### SYSTEM DESCRIPTION

The combination meter controls the meter illumination by the illumination control switch signal from the meter control switch and the position light request signal transmitted by BCM with unified meter and A/C amp.

#### Daytime Mode

Meter illumination is adjusted to 5 steps by illumination control switch (1) in daytime mode.



#### Nighttime Mode

- Combination meter is transferred to nighttime mode with position light request signal from BCM with CAN communication line.
- Meter illumination is adjusted to 22 steps by illumination control switch in nighttime.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P


MWI

# METER SYSTEM

< SYSTEM DESCRIPTION >

## METER ILLUMINATION CONTROL : Component Parts Location

INFOID:0000000110990579



- |  |                                  |                                  |
|--|----------------------------------|----------------------------------|
| 1. Unified meter and A/C amp.                  | 2. BCM                           | 3. IPDM E/R                      |
| 4. Oil pressure switch                         | 5. Ambient sensor                | 6. Combination meter             |
| 7. Fuel level sensor unit and fuel pump (main) | 8. Fuel level sensor unit (sub)  |                                  |
| A. Behind cluster lid C                        | B. 2WD [oil pan (upper) RH side] | C. AWD (oil filter bracket part) |
| D. Condenser (front)                           | E. Rear seat (lower right)       | F. Rear seat (lower left)        |

## METER ILLUMINATION CONTROL : Component Description

INFOID:0000000110990580

Unit	Description
Combination meter	Controls the meter illumination with the illumination control switch signal from the meter control switch and the position light request signal from unified meter and A/C amp.
Unified meter and A/C amp.	Transmits the position light request signal received from BCM via CAN communication to the combination meter by means of communication.


# METER SYSTEM

## < SYSTEM DESCRIPTION >

Unit	Description
Meter control switch	Transmits the following signals to the combination meter. <ul style="list-style-type: none"> <li>• Illumination control switch signal (+)</li> <li>• Illumination control switch signal (-)</li> </ul>

## INFORMATION DISPLAY

### INFORMATION DISPLAY : System Diagram



### INFORMATION DISPLAY : System Description

INFOID:000000010990582

#### DESCRIPTION

- The combination meter retrieves the information required for controlling the operations of the information display from the communication signals from the unified meter and A/C amp., etc.
- The combination meter incorporates a trip computer that displays the warning / information according to the information received from various units.

#### PARKING BRAKE RELEASE WARNING

The combination meter indicates parking brake release warning judged with the vehicle speed signal received from the unified meter and A/C amp. by means of communication line and the parking brake switch signal from the parking brake switch.

##### Warning Operation Condition

Parking brake release warning is judged if all of the following conditions are fulfilled

- Vehicle speed is 7 km/h (4.3 MPH) or higher
- Parking brake switch ON

#### LOW FUEL WARNING

The combination meter indicates low fuel warning judged with the fuel level sensor signal received from the unified meter and A/C amp.

##### Warning Operation Condition

- Fuel level: Approx. 15 ℓ (4 US gal, 3-1/4 Imp gal) or less

#### LOW WASHER FLUID WARNING

The combination meter indicates low washer fluid warning judged with the signal from the washer level switch.

##### Warning Operation Condition


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

MWI

# METER SYSTEM

## < SYSTEM DESCRIPTION >

- Indicates the warning when it is in washer level switch ON condition for 180 seconds or more. Release the warning when it is in washer level switch OFF condition for 30 seconds or more.



## LOW TIRE PRESSURE WARNING

- The unified meter and A/C amp. receives remaining low tire pressure warning lamp signal from the BCM with CAN communication line.
- The unified meter and A/C amp. transmits remaining low tire pressure warning lamp signal to the combination meter with communication line.
- The combination meter indicates low tire pressure warning when receiving remaining low tire pressure warning lamp signal.
- The combination meter indicates low tire pressure warning judged with the low tire pressure warning lamp signal received from the unified meter and A/C amp.

For details, refer to [WT-8. "System Description"](#).

## FUEL FILLER CAP WARNING

- The unified meter and A/C amp. receives remaining fuel filler cap warning display signal from the ECM with CAN communication line.
- The unified meter and A/C amp. transmits remaining fuel filler cap warning display signal to the combination meter with communication line.
- The combination meter indicates fuel filler cap warning when receiving remaining fuel filler cap warning display signal.
- The combination meter indicates fuel filler cap warning judged with the fuel filler cap warning display signal received from the unified meter and A/C amp.

For details, refer to [EC-103. "System Description"](#).

## DOOR/TRUNK OPEN WARNING

- The combination meter indicates door open warning judged with each door switch signal received from the unified meter and A/C amp. by means of communication line.
- The combination meter indicates trunk open warning judged with the trunk switch signal received from the unified meter and A/C amp. by means of communication line.

## INSTANTANEOUS FUEL CONSUMPTION (MPG)

- The unified meter and A/C amp. receives the fuel consumption monitor signal from ECM and the vehicle speed signal from the ABS actuator and electric unit (control unit) with CAN communication line.
- The unified meter and A/C amp. calculates the instantaneous fuel consumption according to the fuel consumption monitor signal and the vehicle speed signal received with CAN communication line, and transmits it to the combination meter.

## AVERAGE FUEL CONSUMPTION (MPG)

- The unified meter and A/C amp. receives the fuel consumption monitor signal from ECM and the vehicle speed signal from the ABS actuator and electric unit (control unit) with CAN communication line.
- The unified meter and A/C amp. calculates the average fuel consumption according to the fuel consumption monitor signal and the vehicle speed signal received with CAN communication line, and transmits it to the combination meter.
- The average fuel consumption displayed on the information display is uploaded at approximately 30-second intervals.

### NOTE:

“—” is displayed for approximately 30 seconds just after the reset operation and after the ignition switch is OFF → ON. It is displayed simultaneously until the vehicle drives approximately 500 m (0.31 mile).

## AVERAGE VEHICLE SPEED (MPH)

- The unified meter and A/C amp. receives the vehicle speed signal from the ABS actuator and electric unit (control unit) via CAN communication line.

# METER SYSTEM

## < SYSTEM DESCRIPTION >

- Measures the time during the ignition switch ON with the unified meter and A/C amp.
- The unified meter and A/C amp. calculates the average vehicle speed according to the above signals. These signals are transmitted to the combination meter with the communication line.
- The average vehicle speed displayed on the information display is uploaded at approximately 30-second intervals.

### NOTE:

“—” is displayed for 30 seconds just after the reset operation and after the ignition switch is OFF → ON. It is displayed simultaneously until the vehicle drives approximately 500 m (0.31 mile).

### TRAVEL TIME (TIME)

Measures the time during the ignition switch ON with the unified meter and A/C amp, and transmits it to the combination meter by means of communication line.

### TRAVEL DISTANCE (MILES)

- The unified meter and A/C amp. transmits the vehicle speed signal from ABS actuator and electric unit (control unit) to the combination meter.
- The combination meter calculates the vehicle distance according to the vehicle speed signal. The vehicle distance is displayed.

### POSSIBLE DRIVING DISTANCE (RANGE)

The unified meter and A/C amp. calculates possible driving distance according to the vehicle speed signal transmitted through CAN communication and the fuel level sensor signal transmitted from the fuel level sensor. These signals are transmitted to the combination meter with the communication line.

### NOTE:

- “—” is displayed for 30 seconds after the ignition switch is OFF → ON. It is displayed simultaneously until the vehicle drives approximately 500 m (0.31 mile).
- The indicated values may not match each other when filling the fuel with the ignition switch ON. Refer to [MWI-127. "INFORMATION DISPLAY : Description"](#).

### AMBIENT AIR TEMPERATURE

- The unified meter and A/C amp. receives the ambient sensor signal from the ambient sensor.
- The unified meter and A/C amp. calculates the ambient temperature according to the ambient sensor signal, and transmits it to the combination meter.
- The indicated temperature does not increase if the vehicle speed is less than 20 km/h (12 MPH).

### NOTE:

- The ambient sensor input value that is displayed on “Data Monitor” of CONSULT is the value before the correction. It may not match the indicated temperature on the information display.
- Ambient temperature may be indicated higher than an actual temperature, depending on heat in the engine, a road surface temperature, and so on.

## SETTING

### Setting item list

Items		Setting range	Setting unit	Description
ALERT	TIME TO REST	No setting - 6 hours	30 minutes, [60 minutes]*	Time to rest is displayed on the information display if the vehicle reached the set travel distance.
	ICY	ON/OFF	—	Low outside temp is displayed on the information display if the ambient temperature is 3°C (37°F) or less.
MAINTENANCE	ENGINE OIL	No setting - 18,500 miles, (No setting - 30,000 km)	250 miles (500 km), [500 miles (1000 km)]*	The engine oil replacement interval is displayed on the information display if the vehicle reached the set distance.
	OIL FILTER	No setting - 18,500 miles, (No setting - 30,000 km)	250 miles (500 km), [500 miles (1000 km)]*	The oil filter replacement interval is displayed on the information display if the vehicle reached the set distance.
	TIRE	No setting - 18,500 miles, (No setting - 30,000 km)	250 miles (500 km), [500 miles (1000 km)]*	The tire replacement interval is displayed on the information display if the vehicle reached the set distance.
	OTHER	No setting - 18,500 miles, (No setting - 30,000 km)	250 miles (500 km), [500 miles (1000 km)]*	The other replacement interval is displayed on the information display if the vehicle reached the set distance.

# METER SYSTEM


## < SYSTEM DESCRIPTION >

Items		Setting range	Setting unit	Description
DISPLAY	LANGUAGE	ENGLISH/FRANCAIS	—	Changing the language setting can be performed.
	UNIT	US/METRIC	—	Changing the unit setting can be performed.

\*: Press and hold the switch (1 second or more).

## INFORMATION DISPLAY : Component Parts Location

INFOID:000000010990583



- |  |                                  |                                  |
|--|----------------------------------|----------------------------------|
| 1. Unified meter and A/C amp.                  | 2. BCM                           | 3. IPDM E/R                      |
| 4. Oil pressure switch                         | 5. Ambient sensor                | 6. Combination meter             |
| 7. Fuel level sensor unit and fuel pump (main) | 8. Fuel level sensor unit (sub)  |                                  |
| A. Behind cluster lid C                        | B. 2WD [oil pan (upper) RH side] | C. AWD (oil filter bracket part) |
| D. Condenser (front)                           | E. Rear seat (lower right)       | F. Rear seat (lower left)        |

JSNIA0042ZZ

# METER SYSTEM

< SYSTEM DESCRIPTION >

## INFORMATION DISPLAY : Component Description

INFOID:000000010990584

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

Unit	Description
Combination meter	Controls the information display with the signals received from the unified meter and A/C amp. by means of communication and the signals from various switches and sensors.
Unified meter and A/C amp.	Transmits signals received from various units to the combination meter by means of communication.
Fuel level sensor unit	Refer to <a href="#">MWI-54, "Description"</a> .
ECM	Transmits the following signals to the unified meter and A/C amp. via CAN communication. <ul style="list-style-type: none"> <li>• Engine speed signal</li> <li>• Fuel consumption monitor signal</li> <li>• Fuel filler cap warning display signal</li> </ul>
ABS actuator and electric unit (control unit)	Transmits the vehicle speed signal to the unified meter and A/C amp. via CAN communication.
BCM	Transmits signals provided by various units to the unified meter and A/C amp. via CAN communication.
Meter control switch	Transmits the following signals to the combination meter. <ul style="list-style-type: none"> <li>• Enter switch signal</li> <li>• Select switch signal</li> </ul>
Washer level switch	Transmits the washer level signal to the combination meter.
Parking brake switch	Refer to <a href="#">MWI-62, "Description"</a> .
Door switch	Transmits the door switch signals to BCM.
Trunk room lamp switch	Transmits the trunk room lamp switch signal to BCM.
Ambient sensor	Detects the ambient air temperature and transmits the ambient sensor signal to the unified meter and A/C amp.

MWI

# COMPASS

< SYSTEM DESCRIPTION >


## COMPASS

### Description

INFOID:000000010990585

### DESCRIPTION

- This electronic compass is able to display 8 primary directions: N, NE, E, SE, S, SW, W, NW.
- The compass switch (1) is used to operate the compass.



#### Switch Operation

Press	Compass is turned ON/OFF
Press and hold (for 3- 9 sec.)	Compass display (2) turns to zone variation change mode
Press and hold (for more than 9 sec.)	Compass display turns to calibration mode

- All standard compasses determine direction relative to Magnetic North; however, this electronic compass is designed to display direction relative to True North.
- The difference between Magnetic North and True North varies from place to place across the surface of the earth.
- This electronic compass must be “told” approximately where it is on the earth’s surface so that the Magnetic North reading can be properly converted into a True North display.
- To tell the electronic compass where it’s at, the earth is separated into numbered “Zone Variances”. The Zone Variance number in which the compass is to function must be entered into this electronic compass.
- Each zone is magnetically about 4.2° wide. Typically, anything under 22.5° total zone change is not noticed on the electronic compass display. However, over 22.5°, a reading may be off by one or more primary directions.
- On long trips, a vehicle may leave its original zone and enter one or more new zones. Generally, you do not need to reset the compass zone if you travel between 3 or 4 zones, such as business travel or vacation. The typical driver will not notice any difference on the display within 3 or 4 zones. However, if the vehicle is “permanently” moved to a new location, it is recommended that the compass zone be reset.


### ZONE VARIATION SETTING PROCEDURE



# COMPASS

## < SYSTEM DESCRIPTION >

1. Press and hold the compass switch for 3 – 9 seconds.
2. The current zone setting appears on the compass display.
3. Find the current geographical location number in the Zone Variation Chart.
4. Select the new zone number. (Press the compass switch until the new zone number appears on the compass display.)
5. After select the new zone number, the compass display will automatically shows a direction within a few seconds.
6. Perform the following Calibration Procedure for more accurate indications.



## CALIBRATION PROCEDURE

### NOTE:

The compass calibrates itself under normal driving conditions. However, occasional circumstances may cause the compass to operate inaccurately. Example: Driving from rural (wide open) areas to crowded city areas, or if an aftermarket (i.e., non original equipment) antenna with a magnetic base is attached to the vehicle. Calibrate the mirror compass if the display shows only one direction or a limited number of directions.

### NOTE:

- If “magnetic hats” are used in the dealership for vehicle identification, remove the hat from the vehicle before performing the following steps. Do not put the hat back on the vehicle after the procedure is completed.
  - Drive the vehicle to an open level area; away from large metallic objects, structures, and overhead power lines.
  - Turn off “non-essential” electrical accessories (rear window defrost, heater/air conditioning, wipers) and close the doors.
1. Verify the correct compass zone setting for the geographical location.
  2. Press and hold the compass switch for more than 9 seconds.
  3. “C” is displayed on the compass display, when calibration starts.
  4. Drive slowly [less than 8 km/h (5 MPH)] in a circle until the “C / CAL” is replaced with primary headings (N, NE, E, SE, S, SW, W, or NW).

### NOTE:

This will require driving at least 2 complete 360 degree circles; 3 complete circles may be required.

5. The compass calibration procedure is now complete. The compass should operate normally.

### NOTE:

If at any time the compass continually displays the incorrect direction or the reading is erratic or locked, repeat the calibration procedure.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI


# COMPASS

< SYSTEM DESCRIPTION >

## Component Parts Location

INFOID:000000010990586

- 1 : Compass switch
- 2 : Compass display



## Special Repair Requirement

INFOID:000000010990587

### 1.PERFORM ZONE VARIATION SETTING

Perform the zone variation setting. Refer to [MWI-32, "Description"](#).

>> GO TO 2.

### 2.PERFORM CALIBRATION

Perform the calibration. Refer to [MWI-32, "Description"](#).

>> Setting completion

# CLOCK


< SYSTEM DESCRIPTION >

## CLOCK

### Component Parts Location

INFOID:000000010990588

1 : Clock



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI

# DIAGNOSIS SYSTEM (METER)

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (METER)

### Diagnosis Description

INFOID:000000010990589

### SELF-DIAGNOSIS MODE

- Information display LCD segment operation can be checked in self-diagnosis mode.
- Meters/gauges can be checked in self-diagnosis mode.


### OPERATION PROCEDURE

1. Turn ignition switch ON, and switch the trip meter to "trip A" or "trip B".


**NOTE:**

If the diagnosis function is activated with "trip A" displayed, the mileage on "trip A" is reset to "0000.0". (The same way for "trip B".)

2. Turn ignition switch OFF.
3. While pressing the trip A/B reset switch (1), turn ignition switch ON again.
4. Make sure that the trip meter displays "0000.0".
5. Press the trip A/B reset switch at least 3 times. (Within 7 seconds after the ignition switch is turned ON.)



6. The unified meter control unit is turned to self-diagnosis mode.
  - Displays "888888" and "8888.8" in the information display LCD (1) for approximately 5 seconds and then blinks the segment dots of the information display LCD alternately.
  - Water temperature gauge and fuel gauge return to zero, and at the same time.




**NOTE:**

- Check combination meter power supply and ground circuit when self-diagnosis mode of combination meter does not start. Replace combination meter if normal.
- If any of the segments is not displayed, replace combination meter.

# DIAGNOSIS SYSTEM (METER)

## < SYSTEM DESCRIPTION >

7. Each meter activates during pressing trip A/B reset switch.



### NOTE:

- If any of the meter and gages is not activated, replace combination meter.
- The figure is reference.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

MWI

# DIAGNOSIS SYSTEM (UNIFIED METER AND A/C AMP.)

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (UNIFIED METER AND A/C AMP.)

### CONSULT Function (METER/M&A)

INFOID:000000010990590

#### CONSULT APPLICATION ITEMS

CONSULT can perform the following diagnosis modes with CAN communication with the unified meter and A/C amp.

System	Diagnosis mode	Description
METER/M&A	Self Diagnostic Result	Unified meter and A/C amp. checks the conditions and displays memorized error.
	Data Monitor	Displays unified meter and A/C amp. input/output data in real time.
	Ecu Identification	The unified meter and A/C amp. part number is displayed.

#### SELF DIAG RESULT

Refer to [MWI-103, "DTC Index"](#).

#### DATA MONITOR

##### NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

##### Display Item List

X: Applicable

Display item [Unit]	MAIN SIGNALS	Description
SPEED METER [km/h]	X	Value of vehicle speed signal received from ABS actuator and electric unit (control unit) with CAN communication line. <b>NOTE:</b> 655.35 is displayed when the malfunction signal is received.
SPEED OUTPUT [km/h]	X	Vehicle speed signal value transmitted to other units with CAN communication line. <b>NOTE:</b> 655.35 is displayed when the malfunction signal is received.
ODO OUTPUT [km/h or mph]		Odometer signal value transmitted to other units with CAN communication line.
TACHO METER [rpm]	X	Value of the engine speed signal received from ECM with CAN communication line. <b>NOTE:</b> 8191.875 is displayed when the malfunction signal is received.
FUEL METER [lit.]	X	Fuel level indicated on combination meter.
W TEMP METER [°C]	X	Value of engine coolant temperature signal received from ECM with CAN communication line. <b>NOTE:</b> 215 is displayed when the malfunction signal is input.
FUEL CAP W/L [On/Off]		Status of fuel filler cap warning display detected from fuel filler cap warning display signal received from ECM via CAN communication.
ABS W/L [On/Off]		Status of ABS warning lamp judged from ABS warning lamp signal received from ABS actuator and electric unit (control unit) with CAN communication line.
VDC/TCS IND [On/Off]		Status of VDC OFF indicator lamp judged from VDC OFF indicator lamp signal received from ABS actuator and electric unit (control unit) with CAN communication line.
SLIP IND [On/Off]		Status of VDC warning lamp judged from VDC warning lamp signal received from ABS actuator and electric unit (control unit) with CAN communication line.

# DIAGNOSIS SYSTEM (UNIFIED METER AND A/C AMP.)

## < SYSTEM DESCRIPTION >

Display item [Unit]	MAIN SIGNALS	Description
BRAKE W/L [On/Off]		Status of brake warning lamp judged from brake warning lamp signal received from ABS actuator and electric unit (control unit) with CAN communication line. <b>NOTE:</b> Displays "Off" if the brake warning lamp is illuminated when the valve check starts, the parking brake switch is turned ON or the brake fluid level switch is turned ON.
DOOR W/L [On/Off]		Status of door warning judged from door switch signal received from BCM with CAN communication line.
TRUNK/GLAS-H [On/Off]		Status of trunk warning judged from trunk switch signal received from BCM with CAN communication line.
HI-BEAM IND [On/Off]		Status of high beam indicator lamp judged from high beam request signal received from BCM with CAN communication line.
TURN IND [On/Off]		Status of turn indicator lamp judged from turn indicator signal received from BCM with CAN communication line.
FR FOG IND [On/Off]		Status of front fog lamp indicator lamp judged from front fog light request signal received from BCM with CAN communication line.
RR FOG IND [Off]		This item is displayed, but cannot be monitored.
LIGHT IND [On/Off]		Status of tail lamp indicator lamp judged from position light request signal received from BCM with CAN communication line.
OIL W/L [On/Off]		Status of oil pressure warning lamp judged from oil pressure switch signal received from IPDM E/R with CAN communication line.
MIL [On/Off]		Status of malfunction indicator lamp judged from malfunctioning indicator lamp signal received from ECM with CAN communication line.
GLOW IND [On/Off]		This item is displayed, but cannot be monitored.
C-ENG2 W/L [On/Off]		This item is displayed, but cannot be monitored.
CRUISE IND [On/Off]		Status of CRUISE indicator judged from ASCD status signal received from ECM with CAN communication line.
SET IND [On/Off]		Status of set indicator judged from ASCD SET indicator signal received from ECM with CAN communication line.
CRUISE W/L [On/Off]		Status of CRUISE warning lamp judged from ASCD status signal received from ECM with CAN communication line.
BA W/L [Off]		This item is displayed, but cannot be monitored.
ATC/T-AMT W/L [On/Off]		Status of A/T check warning lamp judged from A/T check indicator signal received from TCM with CAN communication line.
4WD W/L [On/Off]		Status of AWD warning lamp judged from AWD warning lamp signal received from AWD control unit with CAN communication line.
4WD LOCK IND [Off]		This item is displayed, but cannot be monitored.
FUEL W/L [On/Off]		Low-fuel warning lamp status judged by the identified fuel level.
WASHER W/L [On/Off]		Status of washer warning lamp judged from washer level switch input to combination meter.
AIR PRES W/L [On/Off]		Status of low tire pressure warning lamp judged from TPMS malfunction warning lamp signal received from BCM with CAN communication line.
KEY G/Y W/L [On/Off]		Status of key warning lamp (G/Y) judged from key warning signal received from BCM with CAN communication line.
AFS OFF IND [On/Off]		Status of AFS OFF indicator lamp judged from AFS OFF indicator lamp signal received from AFS control unit with CAN communication line.
4WAS/RAS W/L [Off]		This item is displayed, but cannot be monitored.

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

## DIAGNOSIS SYSTEM (UNIFIED METER AND A/C AMP.)

### < SYSTEM DESCRIPTION >

Display item [Unit]	MAIN SIGNALS	Description
DDS W/L [On/Off]		This item is displayed, but cannot be monitored.
LANE W/L [On/Off]		This item is displayed, but cannot be monitored.
LDP IND [On/Off]		This item is displayed, but cannot be monitored.
LCD [B&P N, B&P I, ID NG, ROTAT, SFT P, INSRT, BATT, NO KY,OUTKY, LK WN, C&P N,C&P I]		Displays status of Intelligent Key system warning judged from meter display signal received from BCM with CAN communication line.
ACC TARGET [Off]		This item is displayed, but cannot be monitored.
ACC DISTANCE [Off]		This item is displayed, but cannot be monitored.
ACC OWN VHL [Off]		This item is displayed, but cannot be monitored.
ACC SET SPEED [Off]		This item is displayed, but cannot be monitored.
ACC UNIT [Off]		This item is displayed, but cannot be monitored.
O/D OFF SW [On/Off]		This item is displayed, but cannot be monitored.
SHIFT IND [P, R, N, D, M1, M2, M3, M4, M5, M6, M7]		Status of shift position indicator judged from shift position signal and manual mode indicator signal received from TCM with CAN communication line.
AT S MODE SW [On/Off]		Status of snow mode switch.
AT P MODE SW [On/Off]		This item is displayed, but cannot be monitored.
M RANGE SW [On/Off]		Status of manual mode switch.
NM RANGE SW [On/Off]		Status of not manual mode switch.
AT SFT UP SW [On/Off]		Status of manual mode shift up switch.
AT SFT DWN SW [On/Off]		Status of manual mode shift down switch.
ST SFT UP SW [Off]		This item is displayed, but cannot be monitored.
ST SFT DWN SW [Off]		This item is displayed, but cannot be monitored.
COMP FB SIG [On/Off]		A/C compressor activation condition that ECM judges according to the water temperature and the acceleration degree.
4WD LOCK SW [Off]		This item is displayed, but cannot be monitored.
PKB SW [On/Off]		Status of parking brake switch.
BUCKLE SW [On/Off]		Status of seat belt buckle switch.
BRAKE OIL SW [On/Off]		Status of brake fluid level switch.
DISTANCE [km]		Value of possible driving distance calculated by unified meter and A/C amp.



## DIAGNOSIS SYSTEM (UNIFIED METER AND A/C AMP.)

### < SYSTEM DESCRIPTION >

Display item [Unit]	MAIN SIGNALS	Description
OUTSIDE TEMP [°C or °F]		Ambient air temperature value converted from ambient sensor signal received from ambient sensor. <b>NOTE:</b> This may not match with the temperature value indicated on the information display. (Because the information display value is a corrected value from the ambient sensor input value.)
FUEL LOW SIG [On/Off]		Status of fuel level low warning signal to output to AV control unit with CAN communication line.
BUZZER [On/Off]	X	Buzzer status (in the combination meter) is judged with the buzzer output signal received from each unit with CAN communication line and the warning output condition of the combination meter.
ASCD REQ SPD [km/h/Off]		ASCD or speed limiter set vehicle speed value that is judged by the ASCD status signal received from ECM via CAN communication.
ASCD STATUS [Off, ASCD, CRUISE, SL ON, SL SET]		Display status of ASCD and speed limiter status display judged by the ASCD status signal received from ECM via CAN communication.
ASCD SPD BLNK [On/Off]		Blinking status of ASCD or speed limiter set vehicle speed that is judged by the ASCD status signal received from ECM via CAN communication.

**NOTE:**

Some items are not available according to vehicle specification.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI

# U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## DTC/CIRCUIT DIAGNOSIS

### U1000 CAN COMM CIRCUIT

#### Description

INFOID:0000000010990591

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with two communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Signal Chart. Refer to [LAN-12, "How to Use CAN Communication Signal Chart"](#).

#### DTC Logic

INFOID:0000000010990592

#### DTC DETECTION LOGIC

DTC	Display contents of CONSULT	Diagnostic item is detected when ...	Probable malfunction location
U1000	CAN COMM CIRCUIT	When unified meter and A/C amp. is not transmitting or receiving CAN communication signal for 2 seconds or more.	CAN communication system

#### Diagnosis Procedure

INFOID:0000000010990593

#### 1. PERFORM SELF DIAGNOSTIC

1. Turn ignition switch ON and wait for 2 seconds or more.
2. Check "Self Diagnostic Result" of "METER/M&A".

Is "CAN COMM CIRCUIT" displayed?

- YES >> Refer to [LAN-13, "Trouble Diagnosis Flow Chart"](#).  
NO >> Refer to [GI-41, "Intermittent Incident"](#).

# U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

## U1010 CONTROL UNIT (CAN)

### Description

INFOID:000000010990594

Initial diagnosis of unified meter and A/C amp.

### DTC Logic

INFOID:000000010990595

### DTC DETECTION LOGIC

DTC	Display contents of CONSULT	Diagnostic item is detected when ...	Probable malfunction location
U1010	CONTROL UNIT (CAN)	If any malfunction is detected during initial diagnosis of unified meter and A/C amp. CAN controller	Unified meter and A/C amp.

### Diagnosis Procedure

INFOID:000000010990596

#### 1. REPLACE UNIFIED METER AND A/C AMP.

When DTC "U1010" is detected, replace unified meter and A/C amp.

>> INSPECTION END

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI

# B2201 COMMUNICATION ERROR 1

< DTC/CIRCUIT DIAGNOSIS >

## B2201 COMMUNICATION ERROR 1

### Description

INFOID:000000010990597

The communication line (LCD <-> AMP.) is used to communicate signals between the combination meter and the unified meter and A/C amp. in order to control the information display.

### DTC Logic

INFOID:000000010990598

### DTC DETECTION LOGIC

DTC	Display contents of CONSULT	Diagnostic item is detected when ...	Probable malfunction location
B2201	COMM ERROR 1	If a communication error is present in the communication line (LCD <-> AMP.) for 2 seconds or more	Communication line (LCD <-> AMP.) circuit

### Diagnosis Procedure

INFOID:000000010990599

#### 1. CHECK CONNECTOR

Check combination meter, unified meter and A/C amp. and terminals (combination meter side, unified meter and A/C amp. side, and harness side) for looseness or bent.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair terminal or connector.

#### 2. CHECK CONTINUITY COMMUNICATION CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector and unified meter and A/C amp. connector.
3. Check continuity between combination meter harness connector terminal and unified meter and A/C amp. harness connector terminal.

Combination meter		Unified meter and A/C amp.		Continuity
Connector	Terminals	Connector	Terminals	
M53	24	M66	14	Existed
	25		34	

4. Check continuity between combination meter harness connector terminal and ground.

Combination meter		Ground	Continuity
Connector	Terminals		
M53	24		Not existed
	25		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

#### 3. CHECK UNIFIED METER AND A/C AMP. OUTPUT VOLTAGE

1. Connect unified meter and A/C amp. connector.
2. Turn ignition switch ON.
3. Check voltage between unified meter and A/C amp. harness connector terminal and ground.

# B2201 COMMUNICATION ERROR 1

## < DTC/CIRCUIT DIAGNOSIS >

Terminal		(-)	Voltage (Approx.)
(+)			
Unified meter and A/C amp.		Ground	12 V
Connector	Terminal		
M66	14		

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace unified meter and A/C amp.

### 4. CHECK COMBINATION METER OUTPUT VOLTAGE

1. Turn ignition switch OFF.
2. Disconnect unified meter and A/C amp. connector.
3. Connect combination meter connector.
4. Turn ignition switch ON.
5. Check voltage between combination meter harness connector terminal and ground.

Terminal		(-)	Voltage (Approx.)
(+)			
Combination meter		Ground	5 V
Connector	Terminal		
M53	25		

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace combination meter.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI

# B2202 COMMUNICATION ERROR 2

< DTC/CIRCUIT DIAGNOSIS >

## B2202 COMMUNICATION ERROR 2

### Description

INFOID:000000010990600

The communication line (METER <-> AMP.) is used to communicate signals between the combination meter and the unified meter and A/C amp. in order to control the combination meter.

### DTC Logic

INFOID:000000010990601

### DTC DETECTION LOGIC

DTC	Display contents of CONSULT	Diagnostic item is detected when ...	Probable malfunction location
B2202	COMM ERROR 2	If a communication error is present in the communication line (METER <-> AMP.) for 2 seconds or more	Communication line (METER <-> AMP.) circuit

### Diagnosis Procedure

INFOID:000000010990602

#### 1. CHECK CONNECTOR

Check combination meter, unified meter and A/C amp. and terminals (combination meter side, unified meter and A/C amp. side, and harness side) for looseness or bent.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair terminal or connector.

#### 2. CHECK CONTINUITY COMMUNICATION CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector and unified meter and A/C amp. connector.
3. Check continuity between combination meter harness connector terminal and unified meter and A/C amp. harness connector terminal.

Combination meter		Unified meter and A/C amp.		Continuity
Connector	Terminals	Connector	Terminals	
M53	2	M66	27	Existed
	3		7	

4. Check continuity between combination meter harness connector terminal and ground.

Combination meter		Ground	Continuity
Connector	Terminals		
M53	2		Not existed
	3		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

#### 3. CHECK UNIFIED METER AND A/C AMP. OUTPUT VOLTAGE

1. Connect unified meter and A/C amp. connector.
2. Turn ignition switch ON.
3. Check voltage between unified meter and A/C amp. harness connector terminal and ground.

## B2202 COMMUNICATION ERROR 2

### < DTC/CIRCUIT DIAGNOSIS >

Terminal		(-)	Voltage (Approx.)
(+)			
Unified meter and A/C amp.		Ground	5 V
Connector	Terminal		
M66	27		

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace unified meter and A/C amp.

#### 4. CHECK COMBINATION METER OUTPUT VOLTAGE

1. Turn ignition switch OFF.
2. Disconnect unified meter and A/C amp. connector.
3. Connect combination meter connector.
4. Turn ignition switch ON.
5. Check voltage between combination meter harness connector terminal and ground.

Terminal		(-)	Voltage (Approx.)
(+)			
Combination meter		Ground	5 V
Connector	Terminal		
M53	3		

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace combination meter.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI

## B2205 VEHICLE SPEED

< DTC/CIRCUIT DIAGNOSIS >

### B2205 VEHICLE SPEED

#### Description

INFOID:000000010990603

Vehicle speed signal is transmitted from ABS actuator and electric unit (control unit) via CAN communication to unified meter and A/C amp.

#### DTC Logic

INFOID:000000010990604

#### DTC DETECTION LOGIC

DTC	Display contents of CONSULT	Diagnostic item is detected when ...	Probable malfunction location
B2205	VEHICLE SPEED	If the abnormal vehicle speed signal is input from ABS actuator and electric unit (control unit) for 2 seconds or more	<ul style="list-style-type: none"><li>• Wheel sensor</li><li>• ABS actuator and electric unit (control unit)</li></ul>

#### Diagnosis Procedure

INFOID:000000010990605

#### 1. PERFORM SELF-DIAGNOSIS OF ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Perform "Self Diagnostic Result" of ABS actuator and electric unit (control unit), and repair or replace malfunctioning parts.

>> Refer to [BRC-26, "CONSULT Function"](#).



# B2267 ENGINE SPEED

< DTC/CIRCUIT DIAGNOSIS >

## B2267 ENGINE SPEED

### Description

INFOID:000000010990606

The engine speed signal is transmitted from ECM to the unified meter and A/C amp. with CAN communication.

### DTC Logic

INFOID:000000010990607

### DTC DETECTION LOGIC

DTC	Display contents of CONSULT	Diagnostic item is detected when ...	Probable malfunction location
B2267	ENGINE SPEED	If ECM continuously transmits abnormal engine speed signals for 2 seconds or more	<ul style="list-style-type: none"><li>• Crankshaft position sensor (POS)</li><li>• ECM</li></ul>

### Diagnosis Procedure

INFOID:000000010990608

#### 1. PERFORM SELF-DIAGNOSIS OF ECM

Perform "Self Diagnostic Result" of ECM, and repair or replace malfunctioning parts.

>> Refer to [EC-138. "CONSULT Function"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P



# B2268 WATER TEMP

< DTC/CIRCUIT DIAGNOSIS >

## B2268 WATER TEMP

### Description

INFOID:000000010990609

The engine coolant temperature signal is transmitted from ECM to the unified meter and A/C amp. via CAN communication.

### DTC Logic

INFOID:000000010990610

### DTC DETECTION LOGIC

DTC	Display contents of CONSULT	Diagnostic item is detected when ...	Probable malfunction location
B2268	WATER TEMP	If ECM continuously transmits abnormal engine coolant temperature signals for 60 seconds or more	<ul style="list-style-type: none"><li>• Engine coolant temperature sensor</li><li>• ECM</li></ul>

### Diagnosis Procedure

INFOID:000000010990611

#### 1. PERFORM SELF-DIAGNOSIS OF ECM

Perform "Self Diagnosis Result" of ECM, and repair or replace malfunctioning parts.

>> Refer to [EC-138. "CONSULT Function"](#).

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## POWER SUPPLY AND GROUND CIRCUIT COMBINATION METER

### COMBINATION METER : Diagnosis Procedure

INFOID:000000010990612

#### 1.CHECK FUSE

Check for blown fuses.

Power source	Fuse No.
Battery	11
Ignition switch ON or START	4

Is the inspection result normal?

YES >> GO TO 2.

NO >> Be sure to eliminate cause of malfunction before installing new fuse.

#### 2.CHECK POWER SUPPLY CIRCUIT

Check voltage between combination meter harness connector terminal and ground.

Terminals		Ignition switch	Voltage (Approx.)
(+)	(-)		
Combination meter		OFF	Battery voltage
Connector	Terminals		
M53	1	ON	Battery voltage
	21		
		Ground	

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check harness between combination meter and fuse.

#### 3.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector.
3. Check continuity between combination meter harness connector terminal and ground.

Combination meter		Ground	Continuity
Connector	Terminals		
M53	5	Ground	Existed
	15		
	22		

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair harness or connector.

## UNIFIED METER AND A/C AMP.

### UNIFIED METER AND A/C AMP. : Diagnosis Procedure

INFOID:000000010990613

#### 1.CHECK FUSE

Check for blown fuses.

Power source	Fuse No.
Battery	11

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

MWI

# POWER SUPPLY AND GROUND CIRCUIT

## < DTC/CIRCUIT DIAGNOSIS >

Power source	Fuse No.
Ignition switch ACC or ON	19
Ignition switch ON or START	3

### Is the inspection result normal?

YES >> GO TO 2.

NO >> Be sure to eliminate cause of malfunction before installing new fuse.

## 2.CHECK POWER SUPPLY CIRCUIT

Check voltage between unified meter and A/C amp. harness connector terminal and ground.

Terminals		Ignition switch	Voltage (Approx.)
(+)	(-)		
Unified meter and A/C amp.	Ground	OFF	Battery voltage
Connector		ACC	
Terminals		ON	
M67	54		
	41		
	53		

### Is the inspection result normal?

YES >> GO TO 3.

NO >> Check harness between unified meter and A/C amp. and fuse.

## 3.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect unified meter and A/C amp. connector.
3. Check continuity between unified meter and A/C amp. harness connector terminal and ground.

Unified meter and A/C amp.		Ground	Continuity
Connector	Terminals		
M67	55		Existed
	71		

### Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair harness or connector.

## IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

### IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) : Diagnosis Procedure

INFOID:0000000011426131

## 1.CHECK FUSES AND FUSIBLE LINK

Check that the following IPDM E/R fuses or fusible links are not blown.

Signal name	Fuses and fusible link No.
Battery power supply	C
	50
	51

### Is the fuse fusing?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit if a fuse or fusible link is blown.

NO >> GO TO 2.

## 2.CHECK POWER SUPPLY CIRCUIT

# POWER SUPPLY AND GROUND CIRCUIT

## < DTC/CIRCUIT DIAGNOSIS >

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check voltage between IPDM E/R harness connector and the ground.

Terminals		Voltage (Approx.)
(+)	(-)	
IPDM E/R		Battery voltage
Connector	Terminal	
E4	1	
	2	

Is the measurement value normal?

YES >> GO TO 3.

NO >> Repair the harness or connector.

### 3.CHECK GROUND CIRCUIT

Check continuity between IPDM E/R harness connectors and the ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E5	12		Existed
E6	41		

Does continuity exist?

YES >> INSPECTION END

NO >> Repair the harness or connector.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI

# FUEL LEVEL SENSOR SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## FUEL LEVEL SENSOR SIGNAL CIRCUIT

### Description

INFOID:000000010990615

The fuel level sensor unit and fuel pump (main) and the fuel level sensor unit (sub) detect the fuel level in the fuel tank and transmit the fuel gauge signal to the unified meter and A/C amp.

### Component Function Check

INFOID:000000010990616

#### 1. PERFORM SELF-DIAGNOSIS OF UNIFIED METER AND A/C AMP.

Perform "Self Diagnosis" of unified meter and A/C amp. with CONSULT.

##### Is any DTC detected?

YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to [MWI-103. "DTC Index"](#).

NO >> GO TO 2.

#### 2. PERFORM COMPONENT FUNCTION CHECK (1)

1. Turn ignition switch OFF.
2. Disconnect fuel level sensor unit and fuel pump (main) connector and fuel level sensor unit (sub) connector.
3. Connect variable resistor between harness connector terminals located on the vehicle side of the fuel level sensor unit and fuel pump (main) and fuel level sensor unit (sub).

Fuel level sensor unit and fuel pump (main)		Fuel level sensor unit (sub)	
Connector	Terminal	Connector	Terminal
B22	5	B21	1

4. Set variable resistor according to the resistance value shown in the following table and turn ignition switch ON.

Resistance ( $\Omega$ ) (Approx.)	Fuel gauge indication position (Approx.)
Less than 6.0	Full
25.5	3/4
45.5	2/4
66.0	1/4
More than 80.0	0

\*: Reference resistance values used when the combination meter judges the indication position of the fuel gauge.

##### Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 4.

#### 3. PERFORM COMPONENT FUNCTION CHECK (2)

Check the fuel level sensor unit and fuel pump (main) and/or fuel level sensor unit (sub). Refer to [MWI-56. "Component Inspection"](#).

##### Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace fuel level sensor unit and fuel pump (main) and/or fuel level sensor unit (sub). Refer to [FL-6. "Removal and Installation"](#).

#### 4. CHECK DATA MONITOR OF UNIFIED METER AND A/C AMP.

Select "FUEL METER" that is the data monitor item of "METER/M&A". Apply resistance according to the table below and check the monitor value.

# FUEL LEVEL SENSOR SIGNAL CIRCUIT

## < DTC/CIRCUIT DIAGNOSIS >

Except for Mexico

Resistance (Ω) (Approx.)	Reference value of data monitor [L] (Approx.)
Less than 6.0	75
25.5	58
45.5	41
66.0	22
More than 80.0	11

For Mexico

Resistance (Ω) (Approx.)	Reference value of data monitor [L] (Approx.)
Less than 6.0	75
25.5	58
45.5	41
66.0	20
More than 80.0	8

Is the inspection result normal?

YES >> Replace combination meter. Refer to [MWI-130, "Removal and Installation"](#).

NO >> Refer to [MWI-55, "Diagnosis Procedure"](#).

## Diagnosis Procedure

INFOID:0000000010990617

### 1. CHECK FUEL LEVEL SENSOR CIRCUIT

- Turn ignition switch OFF.
- Disconnect unified meter and A/C amp. connector and fuel level sensor unit (sub) connector.
- Check continuity between unified meter and A/C amp. harness connector and fuel level sensor unit (sub) harness connector.

Unified meter and A/C amp.		Fuel level sensor unit (sub)		Continuity
Connector	Terminal	Connector	Terminal	
M67	42	B21	1	Existed

- Check continuity between unified meter and A/C amp. harness connector and ground.

Unified meter and A/C amp.		Ground	Continuity
Connector	Terminal		
M67	42		Not existed

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair harness or connector.

### 2. CHECK FUEL LEVEL SENSOR UNIT (MAIN-SUB) CIRCUIT

- Disconnect fuel level sensor unit and fuel pump (main) connector.
- Check for continuity between the fuel level sensor unit (sub) harness connector and the fuel level sensor unit and fuel pump (main) harness connector.

Fuel level sensor unit (sub)		Fuel level sensor unit and fuel pump (main)		Continuity
Connector	Terminal	Connector	Terminal	
B21	2	B22	2	Existed

- Check for continuity between the fuel level sensor unit (sub) harness connector and the ground.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI

# FUEL LEVEL SENSOR SIGNAL CIRCUIT

## < DTC/CIRCUIT DIAGNOSIS >

Fuel level sensor unit (sub)		Ground	Continuity
Connector	Terminal		Not existed
B21	2		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

### 3. CHECK FUEL LEVEL SENSOR GROUND CIRCUIT

1. Check continuity between fuel level sensor unit and fuel pump (main) harness connector and unified meter and A/C amp. harness connector.

Fuel level sensor unit and fuel pump (main)		Unified meter and A/C amp.		Continuity
Connector	Terminal	Connector	Terminal	
B22	5	M67	58	Existed

2. Check for continuity between the fuel level sensor unit and fuel pump (main) harness connector and the ground.

Fuel level sensor unit and fuel pump (main)		Ground	Continuity
Connector	Terminal		Not existed
B22	5		

Is the inspection result normal?

YES >> Replace unified meter and A/C amp. Refer to [MWI-132, "Removal and Installation"](#).

NO >> Repair harness or connector.

## Component Inspection

INFOID:000000010990618

### 1. CHECK FUEL LEVEL SENSOR UNIT AND FUEL PUMP (MAIN)

1. Remove fuel level sensor unit and fuel pump (main). Refer to [FL-6, "Removal and Installation"](#).
2. Check the resistance between fuel level sensor unit and fuel pump (main).

Fuel level sensor unit and fuel pump (main)		Condition	Resistance (Approx.)
Terminal			
2	5	Full (A)	3 Ω
		Empty (B)	82 Ω

Standard float position

Standard float position [mm (in)]*	
Full (A)	Approx. 202 (7.95)
Empty (B)	Approx. 37 (1.46)

\*: When float rod is contact with stopper.


Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace fuel level sensor unit and fuel pump (main). Refer to [FL-6, "Removal and Installation"](#).

### 2. CHECK FUEL LEVEL SENSOR UNIT (SUB)

1. Remove fuel level sensor unit (sub). Refer to [FL-6, "Removal and Installation"](#).





## FUEL LEVEL SENSOR SIGNAL CIRCUIT

### < DTC/CIRCUIT DIAGNOSIS >

2. Inspect the resistance of fuel level sensor unit (sub).

Fuel level sensor unit (sub)		Condition	Resistance (Approx.)
Terminal			
1	2	Full (A)	3 Ω
		Empty (B)	43 Ω

Standard float position


Standard float position [mm (in)]*	
Full (A)	Approx. 4 (0.16)
Empty (B)	Approx. 174 (6.85)

\*: When float rod is contact with stopper.

Is the inspection result normal?

YES >> INSPECTION END.

NO >> Replace fuel level sensor unit (sub). Refer to [FL-6, "Removal and Installation"](#).



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

MWI

O  
P

# METER CONTROL SWITCH SIGNAL CIRCUIT





< DTC/CIRCUIT DIAGNOSIS >

## METER CONTROL SWITCH SIGNAL CIRCUIT

### Description

INFOID:000000010990619

Transmits the following signals to the combination meter.





-  (Illumination control) switch signal (+)
-  (Illumination control) switch signal (-)
- Trip A/B reset switch signal
-  (select) switch signal
-  (enter) switch is pressed

### Diagnosis Procedure

INFOID:000000010990620

#### 1. CHECK METER CONTROL SWITCH INPUT SIGNAL

1. Turn the ignition switch ON.
2. Measure voltage between the following terminals of the combination meter.

Terminal No.	Condition	Voltage (Approx.)
36 - 16	When  (select) switch is pressed	0 V
	Other than the above	5 V
37 - 16	When  (enter) switch is pressed	0 V
	Other than the above	5 V
38 - 16	When trip A/B reset switch is pressed	0 V
	Other than the above	5 V
39 - 16	When  (illumination control) switch is pressed	0 V
	Other than the above	5 V
40 - 16	When  (illumination control) switch is pressed	0 V
	Other than the above	5 V

Is the inspection result normal?

- YES >> INSPECTION END  
 NO >> GO TO 2.

#### 2. CHECK METER CONTROL SWITCH SIGNAL CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the combination meter and meter control switch connectors.
3. Check continuity between combination meter harness connector terminal and meter control switch harness connector terminal.

Combination meter		Meter control switch		Continuity
Connector	Terminals	Connector	Terminals	
M53	16	M54	7	Existed
	36		2	
	37		1	
	39		10	
	40		9	
	38		5	

4. Check continuity between combination meter harness connector terminal and ground.

# METER CONTROL SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Combination meter		Ground	Continuity
Connector	Terminals		
M53	36	Ground	Not existed
	37		
	39		
	40		
	38		

Is the inspection result normal?

YES >> INSPECTION END





NO >> Repair harness or connector.

## Component Inspection

INFOID:000000010990621

### 1. CHECK METER CONTROL SWITCH UNIT

1. Turn the ignition switch OFF.
2. Disconnect the meter control switch connector.
3. Check continuity of the meter control switch.

Connector	Terminal No.		Operation and status	Continuity
M54	2	7	When  (select) switch is pressed	Existed
			Other than the above	Not existed
	1	7	When  (enter) switch is pressed	Existed
			Other than the above	Not existed
	5	7	When trip A/B reset switch is pressed	Existed
			Other than the above	Not existed
	10	7	When  (illumination control) switch is pressed	Existed
			Other than the above	Not existed
	9	7	When  (illumination control) switch is pressed	Existed
			Other than the above	Not existed

Is the inspection result OK?

YES >> INSPECTION END

NO >> Replace the meter control switch.

MWI

# OIL PRESSURE SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## OIL PRESSURE SWITCH SIGNAL CIRCUIT

### Description

INFOID:000000010990622

Detects the engine oil pressure and transmits the oil pressure switch signal to IPDM E/R.

### Component Function Check

INFOID:000000010990623

#### 1. CHECK UNIFIED METER AND A/C AMP. INPUT SIGNAL

1. Connect the CONSULT.
2. Select the "Data Monitor" for the "METER/M&A" and check the "OIL W/L" monitor value.

"OIL W/L"

Ignition switch ON : On

Engine running : Off

>> INSPECTION END

### Diagnosis Procedure

INFOID:000000010990624

#### 1. CHECK OIL PRESSURE SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and oil pressure switch connector.
3. Check continuity between IPDM E/R harness connector terminal and oil pressure switch harness connector terminal.

IPDM E/R		Oil pressure switch		Continuity
Connector	Terminal	Connector	Terminal	
E7	75	F37	1	Existed

4. Check continuity between IPDM E/R harness connector terminal and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E7	75		Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair harness or connector.


### Component Inspection

INFOID:000000010990625

#### 1. CHECK OIL PRESSURE SWITCH

Check continuity between oil pressure switch and ground.

Condition	Continuity
Engine stopped	Existed
Engine running	Not existed



ELF0044D

Is the inspection result normal?

# OIL PRESSURE SWITCH SIGNAL CIRCUIT

## < DTC/CIRCUIT DIAGNOSIS >

---

YES >> INSPECTION END  
NO >> Replace the oil pressure switch.

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

# PARKING BRAKE SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## PARKING BRAKE SWITCH SIGNAL CIRCUIT

### Description

INFOID:000000010990626

Transmits the parking brake switch signal to the combination meter.

### Component Function Check

INFOID:000000010990627

#### 1. CHECK UNIFIED METER AND A/C AMP. INPUT SIGNAL

1. Connect the CONSULT.
2. Select the "Data Monitor" for the "METER/M&A" and check the "PKB SW" monitor value.

"PKB SW"

Parking brake is applied : On

Parking brake is released : Off


>> INSPECTION END

### Diagnosis Procedure

INFOID:000000010990628

#### 1. CHECK COMBINATION METER INPUT SIGNAL

1. Turn ignition switch ON.
2. Check the voltage and waveform between combination meter harness connector terminal and ground.

Terminal		(-)	Condition	Voltage (Approx.)
(+)				
Connector	Terminal			
M53	27	Ground	Parking brake applied	0 V
			Parking brake released	 <p style="text-align: right; font-size: small;">JSNIA0007GB</p>

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

#### 2. CHECK PARKING BRAKE SWITCH SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector and parking brake switch connector.
3. Check continuity between combination meter harness connector terminal and parking brake switch harness connector terminal.

Combination meter		Parking brake switch		Continuity
Connector	Terminal	Connector	Terminal	
M53	27	E107	1	Existed

4. Check continuity between combination meter harness connector terminal and ground.

# PARKING BRAKE SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Combination meter		Ground	Continuity
Connector	Terminal		
M53	27		Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair harness or connector.

## Component Inspection

INFOID:000000010990630

### 1. CHECK PARKING BRAKE SWITCH

Check parking brake switch. Refer to [BRC-80. "Component Inspection"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace parking brake switch.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI

# WASHER LEVEL SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## WASHER LEVEL SWITCH SIGNAL CIRCUIT

### Description

INFOID:000000010990631

Transmits the washer level switch signal to the combination meter.

### Diagnosis Procedure

INFOID:000000010990632

#### 1. CHECK WASHER LEVEL SWITCH SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector and washer level switch connector.
3. Check continuity between combination meter harness connector terminal and washer level switch harness connector terminal.

Combination meter		Washer level switch		Continuity
Connector	Terminal	Connector	Terminal	
M53	31	E32	1	Existed

4. Check continuity between combination meter harness connector terminal and ground.

Combination meter		Ground	Continuity
Connector	Terminal		
M53	31		Not existed

Is the inspection result normal?

- YES >> INSPECTION END  
NO >> Repair harness or connector.

### Component Inspection

INFOID:000000010990633

#### 1. CHECK WASHER LEVEL SWITCH

1. Turn ignition switch OFF.
2. Disconnect washer level switch connector.
3. Check washer level switch.

Terminal		Washer level switch	Continuity
1	2	ON	Existed
		OFF	Not existed

Is the inspection result normal?

- YES >> INSPECTION END  
NO >> Replace washer level switch. Refer to [WW-96, "Removal and Installation"](#).





# COMPASS



## < DTC/CIRCUIT DIAGNOSIS >

**COMPASS**

Connector No. M1

Connector Name FUSE BLOCK (J/B)

Connector Type NS98FW-M2






Terminal No.	Color Of Wire	Signal Name [Specification]
1A	-	-
2A	-	-
3A	G	-
4A	P	-
5A	L	-
6A	Y	-
7A	R	-
8A	L	-

Connector No. M2

Connector Name FUSE BLOCK (J/B)



Connector Type NS10FW-CS

Connector No. M2

Connector Name WIRE TO WIRE

Connector Type NH10FW-CS10






Terminal No.	Color Of Wire	Signal Name [Specification]
1	SHIELD	-
2	G	-
3	BR	-
4	BR	-
5	Y	-
6	P	-
7	LG	-
8	V	-
9	B	-
10	B	-
11	R	-
12	R	-
13	R	-
14	R	-
15	G	-
16	SHIELD	-
17	B	-

Connector No. R1

Connector Name WIRE TO WIRE

Connector Type NH10FW-CS10

Connector No. M3

Connector Name FUSE BLOCK (J/B)

Connector Type NS98FW-M2




Terminal No.	Color Of Wire	Signal Name [Specification]
1	SHIELD	-
2	G	-
3	BR	-
4	BR	-
5	Y	-
6	P	-
7	LG	-
8	V	-
9	B	-
10	B	-
11	R	-
12	R	-
13	R	-
14	R	-
15	G	-
16	SHIELD	-
17	B	-

Connector No. R3

Connector Name AUTO ANTI-SHAZZLING INSIDE MIRROR

Connector Type TH10PEE-NH




Connector No. M4

Connector Name FUSE BLOCK (J/B)

Connector Type NS98FW-M2




Terminal No.	Color Of Wire	Signal Name [Specification]
1	SHIELD	-
2	G	-
3	BR	-
4	BR	-
5	Y	-
6	P	-
7	LG	-
8	V	-
9	B	-
10	B	-
11	R	-
12	R	-
13	R	-
14	R	-
15	G	-
16	SHIELD	-
17	B	-

Connector No. R4

Connector Name AUTO ANTI-SHAZZLING INSIDE MIRROR

Connector Type TH10PEE-NH




Connector No. M5

Connector Name FUSE BLOCK (J/B)

Connector Type NS98FW-M2




Terminal No.	Color Of Wire	Signal Name [Specification]
1	SHIELD	-
2	G	-
3	BR	-
4	BR	-
5	Y	-
6	P	-
7	LG	-
8	V	-
9	B	-
10	B	-
11	R	-
12	R	-
13	R	-
14	R	-
15	G	-
16	SHIELD	-
17	B	-

Connector No. R5

Connector Name AUTO ANTI-SHAZZLING INSIDE MIRROR

Connector Type TH10PEE-NH




Connector No. M6

Connector Name FUSE BLOCK (J/B)

Connector Type NS98FW-M2




Terminal No.	Color Of Wire	Signal Name [Specification]
1	SHIELD	-
2	G	-
3	BR	-
4	BR	-
5	Y	-
6	P	-
7	LG	-
8	V	-
9	B	-
10	B	-
11	R	-
12	R	-
13	R	-
14	R	-
15	G	-
16	SHIELD	-
17	B	-

Connector No. R6

Connector Name AUTO ANTI-SHAZZLING INSIDE MIRROR

Connector Type TH10PEE-NH




Connector No. M7

Connector Name FUSE BLOCK (J/B)

Connector Type NS98FW-M2




Terminal No.	Color Of Wire	Signal Name [Specification]
1	SHIELD	-
2	G	-
3	BR	-
4	BR	-
5	Y	-
6	P	-
7	LG	-
8	V	-
9	B	-
10	B	-
11	R	-
12	R	-
13	R	-
14	R	-
15	G	-
16	SHIELD	-
17	B	-

Connector No. R7

Connector Name AUTO ANTI-SHAZZLING INSIDE MIRROR

Connector Type TH10PEE-NH




Connector No. M8

Connector Name FUSE BLOCK (J/B)

Connector Type NS98FW-M2




Terminal No.	Color Of Wire	Signal Name [Specification]
1	SHIELD	-
2	G	-
3	BR	-
4	BR	-
5	Y	-
6	P	-
7	LG	-
8	V	-
9	B	-
10	B	-
11	R	-
12	R	-
13	R	-
14	R	-
15	G	-
16	SHIELD	-
17	B	-

Connector No. R8

Connector Name AUTO ANTI-SHAZZLING INSIDE MIRROR

Connector Type TH10PEE-NH




Connector No. M9

Connector Name FUSE BLOCK (J/B)

Connector Type NS98FW-M2




Terminal No.	Color Of Wire	Signal Name [Specification]
1	SHIELD	-
2	G	-
3	BR	-
4	BR	-
5	Y	-
6	P	-
7	LG	-
8	V	-
9	B	-
10	B	-
11	R	-
12	R	-
13	R	-
14	R	-
15	G	-
16	SHIELD	-
17	B	-

Connector No. R9

Connector Name AUTO ANTI-SHAZZLING INSIDE MIRROR

Connector Type TH10PEE-NH




Connector No. M10

Connector Name FUSE BLOCK (J/B)

Connector Type NS98FW-M2




Terminal No.	Color Of Wire	Signal Name [Specification]
1	SHIELD	-
2	G	-
3	BR	-
4	BR	-
5	Y	-
6	P	-
7	LG	-
8	V	-
9	B	-
10	B	-
11	R	-
12	R	-
13	R	-
14	R	-
15	G	-
16	SHIELD	-
17	B	-

Connector No. R10

Connector Name AUTO ANTI-SHAZZLING INSIDE MIRROR

Connector Type TH10PEE-NH




JRNWD7402GB


# CLOCK

< DTC/CIRCUIT DIAGNOSIS >

## CLOCK

Wiring Diagram - CLOCK -

INFOID:000000010990635



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI

CLOCK

2006/09/15


JCNWA0014GB

# CLOCK

< DTC/CIRCUIT DIAGNOSIS >

**CLOCK**



Connector No.	M2
Connector Name	FUSE BLOCK (J/B)
Connector Type	MS10FW-GS

Terminal No.	Color	Wire	Signal Name [Specification]
B	SB	-	-
4B	C	-	-
5B	BG	-	-
6B	Y	-	-
8B	R	-	-
9B	SB	-	-

**CLOCK**

Connector No.	MF4
Connector Name	CLOCK
Connector Type	TH84FW-NH

Terminal No.	Color	Wire	Signal Name [Specification]
1	B	-	ILLUMINATION (-)
2	L	-	ILLUMINATION (+)
3	B	-	GROUND
4	Y	-	BAT

JRNWD7403GB

# COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

## ECU DIAGNOSIS INFORMATION

### COMBINATION METER


Reference Value

INFOID:000000010990636

VALUES ON THE DIAGNOSIS TOOL

Refer to [MWI-84, "Reference Value"](#).

TERMINAL LAYOUT



PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
1 (V)	Ground	Battery power supply	Input	Ignition switch OFF	—	Battery voltage
2 (LG)	Ground	Communication signal (METER→ AMP.)	Output	Ignition switch ON	—	<p style="text-align: right; font-size: x-small;">JSNIA0027GB</p>
3 (GR)	Ground	Communication signal (AMP.→ METER)	Input	Ignition switch ON	—	<p style="text-align: right; font-size: x-small;">JSNIA0027GB</p>
5 (B)	Ground	Ground	—	Ignition switch ON	—	0 V
6 (W)	Ground	Alternator signal	Input	Ignition switch ON	Charge warning lamp ON	0 V
					Charge warning lamp OFF	12 V
7 (LG)	Ground	Air bag signal	Input	Ignition switch ON	Air bag warning lamp ON	4 V
					Air bag warning lamp OFF	0 V
10 (W)	Ground	Security signal	Input	Ignition switch OFF	Security warning lamp ON	0 V
					Security warning lamp OFF	12 V

A

B

C

D

E

F

G

H

I

J

K

L

M





MWI

O

P

# COMBINATION METER

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
15 (B)	Ground	Ground	—	Ignition switch ON	—	0 V
16 (BR)	Ground	Meter control switch ground	—	Ignition switch ON	—	0 V
21 (G)	Ground	Ignition signal	Input	Ignition switch ON	—	12 V
22 (B)	Ground	Ground	—	Ignition switch ON	—	0 V
24 (BR)	Ground	Communication signal (LCD→ AMP.)	Output	Ignition switch ON	—	 <small>JSNIA0028GB</small>
25 (Y)	Ground	Communication signal (AMP.→ LCD)	Input	Ignition switch ON	—	 <small>JSNIA0027GB</small>
26 (R)	Ground	Vehicle speed signal (8-pulse)	Input	Ignition switch ON	Speedometer operated [When vehicle speed is ap- prox. 40 km/h (25 MPH)]	<p><b>NOTE:</b> The maximum voltage varies de- pending on the specification (destination unit).</p>  <small>JSNIA0012GB</small>
27 (P)	Ground	Parking brake switch signal	Input	Ignition switch ON	Parking brake ON	0 V
				Ignition switch ON	Parking brake OFF	 <small>JSNIA0007GB</small>

# COMBINATION METER

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
28 (SB)	Ground	Brake fluid level switch signal	Input	Ignition switch ON	Brake fluid level is normal.	
					The brake fluid level is lower than the low level	0 V
29 (P)	Ground	Seat belt buckle switch signal (driver side)	Input	Ignition switch ON	When driver seat belt is fastened	12 V
					When driver seat belt is unfastened	0 V
30 (G)	Ground	Seat belt buckle switch signal (passenger side)	Input	Ignition switch ON	<ul style="list-style-type: none"> <li>When getting in the passenger seat</li> <li>When passenger seat belt is fastened</li> </ul>	12 V
					<ul style="list-style-type: none"> <li>When getting in the passenger seat</li> <li>When passenger seat belt is unfastened</li> </ul>	0 V
31 (L)	Ground	Washer level switch signal	Input	Ignition switch ON	Washer level switch ON	0 V
					Washer level switch OFF	5 V
33 (R)	Ground	Illumination control signal	Output	Ignition switch ON	Lighting switch ON, then operate the illumination control switch.	<p><b>NOTE:</b> When brightness level is midway</p>
36 (LG)	16 (BR)	Select switch signal	Input	Ignition switch ON	When  is pressed	0 V
					Other than the above	5 V
37 (Y)	16 (BR)	Enter switch signal	Input	Ignition switch ON	When  is pressed	0 V
					Other than the above	5 V
38 (G)	16 (BR)	Trip A/B reset switch signal	Input	Ignition switch ON	When trip A/B reset switch is pressed	0 V
					Other than the above	5 V
39 (P)	16 (BR)	Illumination control switch signal (-)	Input	Ignition switch ON	When  switch is pressed	0 V
					Other than the above	5 V
40 (BG)	16 (BR)	Illumination control switch signal (+)	Input	Ignition switch ON	When  switch is pressed	0 V
					Other than the above	5 V

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P


MWI

# COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

## Wiring Diagram - METER -

INFOID:0000000110990637






# COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

WB : With BOSE system  
OB : Without BOSE system



\* : This connector is not shown in "Harness Layout".

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

MWI




# COMBINATION METER

## < ECU DIAGNOSIS INFORMATION >

### METER

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-C516-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	-
2	BG	-
3	V	-
4	Y	-
5	W	-
6	R	-
7	LG	-
8	BR	-
9	V	-
10	SB	-
11	G	-
12	W	-
13	R	-
14	V	-
15	SHIELD	-
16	SHIELD	-
17	SHIELD	-
18	Y	-
19	SB	-
20	P	-
21	L	-
22	SHIELD	-
23	G	-
24	SB	-
25	BR	-
26	Y	-
27	SB	-
28	BR	-
29	V	-
30	SHIELD	-
31	V	-
32	SB	-
33	SHIELD	-
34	BR	-
35	Y	-
36	Y	-
37	SHIELD	-
38	Y	-
39	SB	-
40	P	-
41	L	-
42	SHIELD	-
43	R	-
44	G	-
45	SHIELD	-
46	SB	-
47	BR	-
48	Y	-
49	SB	-
50	Y	-
51	SB	-
52	BR	-
53	BG	-
54	GR	-
55	P	-

74	L	-
75	S	-
76	Y	-
77	G	-
78	W	-
79	R	-
80	BR	-
81	Y	-
82	SB	-
83	BR	-
84	P	-
85	BG	-

Connector No.	B13
Connector Name	SEAT BELT BUCKLE SWITCH (DRIVER SIDE)
Connector Type	AG8FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	SB	-
2	B	-

Connector No.	B21
Connector Name	FUEL LEVEL SENSOR UNIT (SUB)
Connector Type	EDZFCY-RS



Terminal No.	Color Of Wire	Signal Name [Specification]
2	W	-

Connector No.	B22
Connector Name	FUEL LEVEL SENSOR UNIT AND FUEL PUMP (MAIN)
Connector Type	EDZFCY-RS




Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	-
3	B	-
4	V	-
5	Y	-

Connector No.	E6
Connector Name	POWER FUEL INJECTION POWER DISTRIBUTION MODULE ENGINE
Connector Type	TH80FW-1H



Terminal No.	Color Of Wire	Signal Name [Specification]
39	P	-
40	L	-
41	B/W	-
42	GR	-
43	LG	-
44	LG	-
45	V	-
46	SB	-

Connector No.	E7
Connector Name	POWER FUEL INJECTION POWER DISTRIBUTION MODULE ENGINE
Connector Type	TH80FW-C512-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
48	L	-
49	BG	-
50	W	-
51	W	-
52	W	-
53	W	-
54	P	-
55	SB	-
56	BR	-
57	G	-
58	GR	-
59	BR	-
60	BR	-
61	BR	-
62	BG	-
63	G	-
64	SB	-
65	Y	-
66	R	-
67	R	-
68	W	-
69	W	-

Connector No.	E32
Connector Name	WASHER LEVEL SWITCH
Connector Type	Z02FBR



Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	-
2	B	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

MWI


JRNWD7394GB

# COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

## METER

Connector No.	E40
Connector Name	WIRE TO WIRE
Connector Type	SAAS8MB-RSS-S4Z8



42	LG	-
43	GR	-
44	GR	-
45	SHIELD	-
46	W	-
47	BR	-
48	BR	-
49	G	-
50	B	-
51	SB	-
52	R	-

Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	GROUND
2	GR	UBMR
3	PG	GROUND
4	Y	DS FL
5	Y	DS FL
6	BR	DP RL
7	BR	DP RL
8	W	DP FR
9	B	DP FR
10	W	DS FR
11	V	DIAG-K
14	P	CAN-L
25	V	CAN-L
27	GR	BUS-L
28	V	BUS-L
29	P	DP FL
30	R	DS RL
31	BR	DS RL
32	G	UZ
33	G	UZ
34	GR	YOGA-SW
35	L	YOGA-SW
37	SHIELD	BUS-H
38	L	BUS-H
39	P	-
40	R	-
41	W	-

Connector No.	E47
Connector Name	BRAKE FLUID LEVEL SWITCH
Connector Type	XY02FCY



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	B	-

Connector No.	E76
Connector Name	AMBIENT SENSOR
Connector Type	RS02FE




Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	P	-

Connector No.	E103
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS16FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
3F	SB	-
4F	G	-
6F	BR	-
8F	L	-
9F	P	-

Connector No.	E108
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	-
3	BG	-
5	G	-
6	Y	-
7	V	-
9	R	-
10	R	-
12	R	-
13	L	-
14	L	-
15	P	-
16	W	-
17	SB	-
18	BG	-

JRNWD7395GB

# COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

## METER

Terminal No.	Color Of Wire	Signal Name [Specification]
20	LG	-
21	BR	-
22	Y	-
23	SB	-
24	LG	-
25	V	-
26	R	-
27	B	-
28	R	-
29	R	-
30	LG	-
31	G	-
32	GR	-
33	BR	-
34	LG	-
35	V	-
36	P	-
37	SB	-
38	LG	-
39	CB	-
40	LG	-
41	R	-
42	G	-
43	V	-
44	L	-
45	W	-
46	W	-
47	V	-
48	W	-
49	GR	-
50	LG	-
51	SB	-
52	SHIELD	-
53	L	-
100	P	-

Connector No.	E107
Connector Name	PARKING BRAKE SWITCH
Connector Type	TBD1FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	EG	-

Connector No.	E119
Connector Name	STOP LAMP SWITCH
Connector Type	MAHEW-LC



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	W	-
3	G	-
4	V	-

Connector No.	F36
Connector Name	ALTERNATOR
Connector Type	HSJ3FB




Terminal No.	Color Of Wire	Signal Name [Specification]
2	G	L
3	V	S
4	W	C

Connector No.	F37
Connector Name	OIL PRESSURE SWITCH
Connector Type	E01FGY-RS-4R



Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	-

Connector No.	F39
Connector Name	WIRE TO WIRE
Connector Type	SAA33FB-RSF-S4Z8



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L/Y	-
2	SHIELD	-
3	L/B	-
4	SHIELD	-
5	BR	-
7	G	-
8	W	-
9	W	-
10	G	-
11	R	-
12	P	-
13	L	-
14	LG	-
15	O	-
16	O	-
18	Y	-
19	P	-
20	O	-

Connector No.	F51
Connector Name	A/T ASSEMBLY
Connector Type	RK1DFG-DGY



Terminal No.	Color Of Wire	Signal Name [Specification]
21	BR	-
22	Y	-
23	LG	-
24	LG	-
25	V	-
26	GR	-
27	GR	-
28	BR	-
29	L	-
30	R	-
31	P	-
32	W	-
33	SB	-
34	BR	- [AWD models]
34	O	- [AWD models]
37	SB	- [AWD models]
37	SHIELD	- [AWD models]
38	W	-
39	Y	-
40	Y	-
41	B	-
42	GR	-
43	R	-
45	O	-
46	SHIELD	-
47	W/L	-
48	LG	-
49	O/L	-
50	L/Y	-
51	W	-
52	L/G	-

Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
2	R	-
3	L	-
4	V	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P



# COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

## METER


Terminal No.	Color Of Wire	Signal Name [Specification]
18	P	
20	L	
21	LG	
32	Y	
33	R	
36	R	
37	Y	
38	R	
39	SB	
41	V	
42	LG	
43	P	
44	B	
45	BG	
46	G	
47	L	
48	L	
66	Y	
67	G	
80	SB	
81	B	
82	V	
83	W	
84	L	
85	GR	
89	LG	
91	W	
93	Y	
95	CG	
98	SHIELD	
99	V	
100	SB	

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	TH800MW-CS16-TM4




Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	
2	P	
3	P	
4	Y	
6	L	
8	G	
9	Y	
24	V	
25	LG	
26	BR	
27	BG	
28	LG	
31	V	
32	SHIELD	
33	SHIELD	
34	GR	
35	BR	
36	Y	
37	SHIELD	
38	SB	
39	LG	
40	O	
41	W	
42	SHIELD	
43	R	
44	G	
45	SHIELD	
46	SH	
55	SB	
56	B	
58	V	
59	Y	
71	V	
72	P	
73	SB	
74	V	
81	W	
82	BR	
84	LG	
85	BG	
86	SB	
88	CG	
89	CG	
90	L	
92	L	
93	P	
95	BG	

Connector No.	M4
Connector Name	DATA LINK CONNECTOR
Connector Type	ED18EFP-P



Terminal No.	Color Of Wire	Signal Name [Specification]
3	LG	
4	B	
6	D	
8	V	
11	G	
11	SB	
14	P	
16	R	


Connector No.	M28
Connector Name	AIR BAG DIAGNOSIS SENSOR UNIT
Connector Type	M28EY-EX



Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	
2	B	
3	Y	
4	Y	
5	Y	
6	Y	
7	Y	
8	Y	
9	Y	
18	SB	
18	SB	
19	V	

Terminal No.	Color Of Wire	Signal Name [Specification]
22	SHIELD	
23	LG	
24	R	
25	R	
51	R	
52	G	
53	Y	
54	BR	
59	L	
60	P	

Connector No.	M53
Connector Name	COMBINATION METER
Connector Type	SAB50FV



Terminal No.	Color Of Wire	Signal Name [Specification]
1	V	BATTERY POWER SUPPLY
2	LG	COMMUNICATION SIGNAL (METER-AMP)
3	GR	COMMUNICATION SIGNAL (AMP-METER)
4	R	RESERVE SIGNAL
6	R	A1 TERMINAL SIGNAL
7	LG	AIR BAG SIGNAL
10	W	SECURITY SIGNAL
15	B	GROUND
16	BR	METER CONTROL SWITCH GROUND
18	GR	ILL GND
19	B	ILL GND
20	R	ILL
21	G	IGNITION SIGNAL
22	B	GROUND
24	BR	COMMUNICATION SIGNAL (LCD-AMP)
25	Y	COMMUNICATION SIGNAL (AMP-LCD)
26	R	VEHICLE SPEED SIGNAL (G-PULSE)
27	R	VEHICLE SPEED SIGNAL (G-PULSE)
28	SB	PERIODIC PULSE SIGNAL (CONTROL)
29	SB	PERIODIC PULSE SIGNAL (CONTROL)
30	P	SEAT BELT BUCKLE SW SIGNAL (DRIVER SIDE)
30	G	SEAT BELT BUCKLE SWITCH SIGNAL (PASSENGER SIDE)
31	L	WASHER LEVEL SWITCH SIGNAL
33	R	ILLUMINATION CONTROL SIGNAL
36	LG	SELECT SWITCH SIGNAL

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P




# COMBINATION METER

## < ECU DIAGNOSIS INFORMATION >

### METER

37	Y	ENTER SWITCH SIGNAL
38	G	TRIP & RESET SWITCH SIGNAL
39	P	ILLUMINATION CONTROL SWITCH SIGNAL (-)
40	BG	ILLUMINATION CONTROL SWITCH SIGNAL (+)

Connector No.	M54
Connector Name	METER CONTROL SWITCH
Connector Type	TH142FW-NH



Terminal No.	Color	Wire	Signal Name [Specification]
1	Y		
2	LG		
3	B		
4	R		
5	G		
7	BR		
8	GR		
9	BG		
10	P		

Connector No.	M66
Connector Name	UNIFIED METER AND A/C AMP.
Connector Type	TH407FW-NH



Terminal No.	Color	Wire	Signal Name [Specification]
4	G		STOP LAMP SWITCH SIGNAL
5	L		MANUAL MODE SHIFT UP SIGNAL
7	GR		COMMUNICATION SIGNAL (AMP-METER)
8	L		VEHICLE SPEED SIGNAL (2-PULSE)
9	SB		SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SIDE)


10	W	MANUAL MODE SIGNAL
11	C	NON-MANUAL MODE SIGNAL
14	BR	COMMUNICATION SIGNAL (LCD-AMP)
23	Y	A/T SNOW SWITCH SIGNAL
25	V	MANUAL MODE SHIFT DOWN SIGNAL
27	LG	COMMUNICATION SIGNAL (METER-AMP)
28	R	VEHICLE SPEED SIGNAL (8-PULSE)
30	V	PARKING BRAKE SWITCH SIGNAL
34	Y	COMMUNICATION SIGNAL (AMP-LCD)
38	P	BLOWER MOTOR CONTROL SIGNAL

Connector No.	M67
Connector Name	UNIFIED METER AND A/C AMP.
Connector Type	TH227FW-NH



Terminal No.	Color	Wire	Signal Name [Specification]
41	L		ACC POWER SUPPLY
42	BR		FUEL LEVEL SENSOR SIGNAL
43	BR		INTAKE SENSOR SIGNAL
44	Y		AMBIENT SENSOR SIGNAL
45	V		SUNLOAD SENSOR SIGNAL
46	Y		IGNITION POWER SUPPLY
53	W		BATTERY POWER SUPPLY
54	SB		GROUND
55	B		GROUND
56	L		CAN-H
57	LG		BRAKE FLUID LEVEL SWITCH
58	Y		FUEL LEVEL SENSOR GROUND
59	GR		INTAKE SENSOR GROUND
60	W		IN-VEHICLE SENSOR GROUND
61	B		AMBIENT SENSOR GROUND
62	SB		SUNLOAD SENSOR GROUND
63	PG		ECU SIGNAL
64	PG		A/C SIGNAL
70	R		EACH DOOR MOTOR POWER SUPPLY
71	GR		GROUND
72	P		CAN-L

Connector No.	M107
Connector Name	ECM
Connector Type	RH240V-RZ6-FA-H-Z



Terminal No.	Color	Wire	Signal Name [Specification]
68	R		ACCELERATOR PEDAL POSITION SENSOR 2
69	P		ACCELERATOR PEDAL POSITION SENSOR Z
89	Y		SENSOR POWER SUPPLY
100	W		SENSOR GROUND
101	SB		ASCD STEERING SWITCH
102	LG		EVAP CONTROL SYSTEM PRESSURE SENSOR
103	GR		SENSOR POWER SUPPLY
104	V		SENSOR GROUND
105	L		REFRIGERANT PRESSURE SENSOR
106	W		FUEL TANK TEMPERATURE SENSOR
107	GR		SENSOR POWER SUPPLY
109	Y		SENSOR GROUND
109	G		PNP SWITCH
110	R		ENGINE SPEED OUTPUT SIGNAL
112	V		SENSOR GROUND
113	P		CAN COMMUNICATION LINE
114	L		CAN COMMUNICATION LINE
117	V		DATA LINK CONNECTOR
121	LG		EVAP CANISTER VENT CONTROL VALVE
122	P		STOP LAMP SWITCH
123	B		ECM GROUND
124	B		ECM GROUND
125	R		POWER SUPPLY FOR ECM
126	BR		ASCD BRAKE SWITCH
127	B		ECM GROUND
128	B		ECM GROUND

Connector No.	M116
Connector Name	WIRE TO WIRE
Connector Type	TK38AW-HS10



Terminal No.	Color	Wire	Signal Name [Specification]
1	Y		
2	BG		
3	P		
4	P		
5	B		
9	R		
10	R		
19	BG		
20	Y		
28	B		
29	LG		
31	W		
33	B		
34	B		
35	G		
36	G		
37	R		
38	SB		
43	P		
44	L		
45	Y		
46	SB		




# COMBINATION METER

## < ECU DIAGNOSIS INFORMATION >


### METER

Connector No.	M122
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
72	R	ROOM ANT 2-
73	R	ROOM ANT 2+
74	SB	PASSENGER DOOR ANT-
75	BR	PASSENGER DOOR ANT+
76	BR	DRIVER DOOR ANT-
77	LG	DRIVER DOOR ANT+
78	Y	ROOM ANT 1-
79	BR	ROOM ANT 1+
80	GR	NATS ANT AMP
81	W	NATS ANT AMP
82	SB	IGN RELAY (F/B) CONT
83	Y	KEYLESS ENTRY RECEIVER COMM
87	Y	COMBI SW INPUT 5
88	BG	CAN-L
90	P	COMBI SW INPUT 3
91	P	CAN-L
92	LG	KEY SLOT 1 CONT
93	GR	CON-IND
95	BG	ACC RELAY CONT
96	GR	A/T SHIFT SELECTOR POWER SUPPLY
99	R	SHIFT P
100	Y	PASSENGER DOOR REQUEST SW
101	P	DRIVER DOOR REQUEST SW
102	BG	BLOWER FAN MOTOR RELAY CONT
103	P	KEYLESS ENTRY RECEIVER POWER SUPPLY
107	LG	COMBI SW INPUT 1
108	R	COMBI SW INPUT 4
109	W	COMBI SW INPUT 2
110	G	HAZARD SW

Connector No.	M123
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FC-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
113	BG	OPTICAL SENSOR
114	Y	STOP LAMP SW
115	SB	STOP LAMP SW 2
118	SS	DR DOOR UNLOCK SENSOR
119	SS	KEY SLOT SW
121	V	IGN F/B
123	V	PASSENGER DOOR SW
124	R	TRUNK LID OPERATOR CANCEL SW
129	BG	POWER WINDOW SW COMM
132	V	PUSH-BUTTON IGNITION SW ILL POWER
133	L	LOCK IND
134	LG	RECEIVER / SENSOR GND
137	BG	RECEIVER / SENSOR POWER SUPPLY
138	V	TIRE PRESSURE RECEIVER COMM
139	L	SHIFT IN P
140	B	SECURITY RELAY CONT
141	P	COMBI SW OUTPUT 1
142	BR	COMBI SW OUTPUT 2
143	P	COMBI SW OUTPUT 3
144	G	COMBI SW OUTPUT 4
145	L	COMBI SW OUTPUT 5
146	SS	COMBI SW OUTPUT 6
150	GR	DRIVER DOOR SW
151	G	REAR WINDOW DEFROGGER RELAY CONT

Connector No.	M137
Connector Name	A/T SHIFT SELECTOR
Connector Type	TH12FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	Y	-
3	V	-
4	B	-
5	G	-
6	Y	-
7	Y	-
8	LG	-
9	B	-
10	GR	-
11	R	-

Connector No.	M202
Connector Name	AV CONTROL UNIT
Connector Type	TH24FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
36	BG	SIGNAL VCC
37	LG	SIGNAL GND
38	R	REP
39	R	COMM (GPS CONT)
40	B	RGB (RGB) SIGNAL
41	SHIELD	SHIELD
42	W	RGB SYNC
43	G	RGB (IR) SIGNAL
44	L	RGB (G) SIGNAL
45	P	RGB (B) SIGNAL

46	Y	COMPOSITE IMAGE GND
47	BR	COMPOSITE VIDEO SIGNAL
48	BR	INVERTER GND
49	BR	INVERTER GND
50	G	V.P.
51	P	COMM (CONT-RISP)
52	SHIELD	SHIELD
57	SHIELD	SHIELD
58	SHIELD	SHIELD

Connector No.	M204
Connector Name	AV CONTROL UNIT
Connector Type	TH32FW-NH




Terminal No.	Color Of Wire	Signal Name [Specification]
76	LG	AV COMM (L)
77	SB	AV COMM (H)
78	LG	AV COMM (L)
79	SB	AV COMM (H)
80	L	CON-H
81	L	CON-H
82	BR	SW GND
86	SHIELD	SHIELD
87	L	TEL VOICE SIGNAL (+)
88	P	TEL VOICE SIGNAL (-)
92	R	VEHICLE SPEED (8-PULSE)
93	SB	PARKING BRAKE
94	BG	REVERSE
95	G	IGNITION
96	V	EJECT SIGNAL

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
MWI  
O  
P

# COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

<b>METER</b>	
Connector No.	ME10
Connector Name	AV CONTROL UNIT
Connector Type	TH32FW-4H



Terminal No.	Color	Off	Signal Name [Specification]
63	SB		PARKING BRAKE
64	P		COMPOSITE IMAGE CND.
65	L		COMPOSITE IMAGE SIGNAL
71	SHIELD		MICROPHONE GND
72	G		MICROPHONE VCC
73	P		COMM (CONT-DISP)
74	P		CAN-L
75	LG		AV COMM (L)
76	LG		AV COMM (L)
79	L		ILLUMINATION
80	G		IGNITION
81	BG		REVERSE
82	R		VEHICLE SPEED (3-PULSE)
83	SHIELD		SHIELD
84	R		VEHICLE SIGNAL
87	SHIELD		SHIELD
88	L		COMM (DISP-CONT)
89	L		CAN-H
91	SB		AV COMM (H)
92	SB		AV COMM (H)

JRNWD7401GB

## Fail-safe

INFOID:000000010990638

## FAIL-SAFE

Combination meter performs fail-safe operation when unified meter and A/C amp. communication is malfunction.

Solution for communication error between the unified meter and A/C amp. and combination meter.

# COMBINATION METER

## < ECU DIAGNOSIS INFORMATION >

Function	Specifications	A	
Speedometer	Reset to zero by suspending communication.	B	
Tachometer			
Fuel gauge			
Engine coolant temperature gauge			
Information display	Door open warning	C	
	Parking brake release warning		
	Low tire pressure warning		
	Fuel filler cap warning		
	Instantaneous fuel warning		<ul style="list-style-type: none"> <li>• When reception time of an abnormal signal is 2 seconds or less, the last received datum is used for calculation to indicate the result.</li> <li>• When reception time of an abnormal signal is more than two seconds, the last result calculated during normal condition is indicated.</li> </ul>
	Average fuel consumption		
	Average vehicle speed		
Travel distance			
Illumination control	When suspending communication, change to nighttime mode.	F	
Buzzer	The buzzer turns off by suspending communication.		
Warning lamp/indicator lamp	ABS warning lamp	G	
	Brake warning lamp		
	CRUISE warning lamp		
	Malfunction indicator lamp		
	High beam indicator	<ul style="list-style-type: none"> <li>The lamp turns on by suspending communication.</li> </ul>	H
	Turn signal indicator lamp		I
	Oil pressure warning lamp		J
	A/T CHECK warning lamp		K
	VDC warning lamp		L
	VDC OFF indicator lamp		M
	AWD warning lamp		The lamp turns off by suspending communication.
	Low tire pressure warning lamp		
	Key warning lamp		
	AFS OFF indicator lamp		
	Master warning lamp		
	Tail lamp indicator lamp		
Front fog lamp indicator lamp			

### DTC Index

INFOID:000000010990639

Refer to [MWI-103, "DTC Index"](#).

MWI

O

P

## UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS INFORMATION >

### UNIFIED METER AND A/C AMP.

#### Reference Value

INFOID:000000010990640

#### VALUES ON THE DIAGNOSIS TOOL

##### NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

##### CONSULT MONITOR ITEM

Monitor Item	Condition		Value/Status
SPEED METER [km/h]	Ignition switch ON	While driving	Equivalent to speedometer reading <b>NOTE:</b> 655.35 is displayed when the malfunction signal is received
SPEED OUTPUT [km/h]	Ignition switch ON	While driving	Equivalent to speedometer reading <b>NOTE:</b> 655.35 is displayed when the malfunction signal is received
ODO OUTPUT [km/h] or [mph]	Ignition switch ON	—	Equivalent to odometer reading in combination meter
TACHO METER [rpm]	Ignition switch ON	While driving	Equivalent to tachometer reading <b>NOTE:</b> 8191.875 is displayed when the malfunction signal is received
FUEL METER [lit.]	Ignition switch ON	—	Values according to fuel level
W TEMP METER [°C]	Ignition switch ON	—	Values according to engine coolant temperature <b>NOTE:</b> 215 is displayed when the malfunction signal is input
FUEL CAP W/L	Ignition switch ON	Fuel filler cap warning display ON	On
		Fuel filler cap warning display OFF	Off
ABS W/L	Ignition switch ON	ABS warning lamp ON	On
		ABS warning lamp OFF	Off
VDC/TCS IND	Ignition switch ON	VDC OFF indicator lamp ON	On
		VDC OFF indicator lamp OFF	Off
SLIP IND	Ignition switch ON	VDC warning lamp ON	On
		VDC warning lamp OFF	Off
BRAKE W/L	Ignition switch ON	Brake warning lamp ON	On
		Brake warning lamp OFF	Off
DOOR W/L	Ignition switch ON	Door warning displayed	On
		Door warning not displayed	Off
TRUNK/GLAS-H	Ignition switch ON	Trunk warning displayed	On
		Trunk warning not displayed	Off
HI-BEAM IND	Ignition switch ON	Hi-beam indicator lamp ON	On
		Hi-beam indicator lamp OFF	Off
TURN IND	Ignition switch ON	Turn indicator lamp ON	On
		Turn indicator lamp OFF	Off
FR FOG IND	Ignition switch ON	Front fog lamp indicator lamp ON	On
		Front fog lamp indicator lamp OFF	Off

## UNIFIED METER AND A/C AMP.

### < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition		Value/Status	
RR FOG IND	Ignition switch ON	<b>NOTE:</b> This item is displayed, but cannot be monitored.	Off	A
LIGHT IND	Ignition switch ON	Tail lamp indicator lamp ON	On	B
		Tail lamp indicator lamp OFF	Off	
OIL W/L	Ignition switch ON	Oil pressure warning lamp ON	On	C
		Oil pressure warning lamp OFF	Off	
MIL	Ignition switch ON	Malfunction warning lamp ON	On	D
		Malfunction warning lamp OFF	Off	
GLOW IND	Ignition switch ON	<b>NOTE:</b> This item is displayed, but cannot be monitored.	Off	E
C-ENG2 W/L	Ignition switch ON	<b>NOTE:</b> This item is displayed, but cannot be monitored.	Off	F
CRUISE IND	Ignition switch ON	Cruise indicator displayed	On	F
		Cruise indicator not displayed	Off	
SET IND	Ignition switch ON	Set indicator lamp ON	On	G
		Set indicator lamp OFF	Off	
CRUISE W/L	Ignition switch ON	Cruise warning lamp ON	On	H
		Cruise warning lamp OFF	Off	
BA W/L	Ignition switch ON	<b>NOTE:</b> This item is displayed, but cannot be monitored.	Off	I
ATC/T-AMT W/L	Ignition switch ON	A/T check warning lamp ON	On	J
		A/T check warning lamp OFF	Off	
4WD W/L	Ignition switch ON	AWD warning lamp ON	On	K
		AWD warning lamp OFF	Off	
4WD LOCK IND	Ignition switch ON	<b>NOTE:</b> This item is displayed, but cannot be monitored.	Off	L
FUEL W/L	Ignition switch ON	Low-fuel warning displayed	On	L
		Low-fuel warning not displayed	Off	
WASHER W/L	Ignition switch ON	Washer warning displayed	On	M
		Washer warning not displayed	Off	
AIR PRES W/L	Ignition switch ON	Low tire pressure lamp ON	On	MWI
		Low tire pressure lamp OFF	Off	
KEY G/Y W/L	Ignition switch ON	Key warning lamp ON	On	O
		Key warning lamp OFF	Off	
AFS OFF IND	Ignition switch ON	AFS OFF indicator lamp ON	On	P
		AFS OFF indicator lamp OFF	Off	
4WAS/RAS W/L	Ignition switch ON	<b>NOTE:</b> This item is displayed, but cannot be monitored.	Off	
DDS W/L	Ignition switch ON	<b>NOTE:</b> This item is displayed, but cannot be monitored.	Off	

## UNIFIED METER AND A/C AMP.

### < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition		Value/Status
LANE W/L	Ignition switch ON	<b>NOTE:</b> This item is displayed, but cannot be monitored.	Off
LDP IND	Ignition switch ON	<b>NOTE:</b> This item is displayed, but cannot be monitored.	Off
LCD	Ignition switch ON	Engine start information display	B&P I
	Ignition switch ACC	Engine start information display	B&P N
	Ignition switch LOCK	Key ID warning display	ID NG
	Ignition switch LOCK	Steering lock information display	ROTAT
	Ignition switch LOCK	P position warning display	SFT P
	Ignition switch LOCK	Intelligent Key insert information display	INSRT
	Ignition switch LOCK	Intelligent Key low battery warning display	BATT
	Ignition switch ON	Take away warning display	NO KY
	Ignition switch LOCK	Key warning display	OUTKY
	Ignition switch ON	ACC warning display	LK WN
ACC TARGET	Ignition switch ON	<b>NOTE:</b> This item is displayed, but cannot be monitored.	Off
ACC DISTANCE	Ignition switch ON	<b>NOTE:</b> This item is displayed, but cannot be monitored.	Off
ACC OWN VHL	Ignition switch ON	<b>NOTE:</b> This item is displayed, but cannot be monitored.	Off
ACC SET SPEED	Ignition switch ON	<b>NOTE:</b> This item is displayed, but cannot be monitored.	Off
ACC UNIT	Ignition switch ON	<b>NOTE:</b> This item is displayed, but cannot be monitored.	Off
O/D OFF SW	Ignition switch ON	<b>NOTE:</b> This item is displayed, but cannot be monitored.	Off

# UNIFIED METER AND A/C AMP.

## < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition		Value/Status	
SHIFT IND	Ignition switch ON	Shift position indicator P display	P	A
		Shift position indicator R display	R	
		Shift position indicator N display	N	B
		Shift position indicator D display	D	
		Shift position indicator M1 display	M1	
		Shift position indicator M2 display	M2	C
		Shift position indicator M3 display	M3	
		Shift position indicator M4 display	M4	D
		Shift position indicator M5 display	M5	
		Shift position indicator M6 display	M6	E
AT S MODE SW	Ignition switch ON	Snow mode switch ON	On	
		Snow mode switch OFF	Off	F
AT P MODE SW	Ignition switch ON	<b>NOTE:</b> This item is displayed, but cannot be monitored.	Off	
M RANGE SW	Ignition switch ON	Selector lever manual mode position	On	G
		Other than the above	Off	
NM RANGE SW	Ignition switch ON	Selector lever manual mode position	Off	H
		Other than the above	On	
AT SFT UP SW	Ignition switch ON	Selector lever + position	On	
		Other than the above	Off	I
AT SFT DWN SW	Ignition switch ON	Selector lever – position	On	
		Other than the above	Off	J
ST SFT UP SW	Ignition switch ON	<b>NOTE:</b> This item is displayed, but cannot be monitored.	Off	K
ST SFT DWN SW	Ignition switch ON	<b>NOTE:</b> This item is displayed, but cannot be monitored.	Off	
COMP F/B SIG	Ignition switch ON	A/C compressor activation condition	On	L
		A/C compressor deactivation condition	Off	
4WD LOCK SW	Ignition switch ON	<b>NOTE:</b> This item is displayed, but cannot be monitored.	Off	M
PKB SW	Ignition switch ON	Parking brake switch ON	On	MWI
		Parking brake switch OFF	Off	
BUCKLE SW	Ignition switch ON	Seat belt not fastened	On	
		Seat belt fastened	Off	O
BRAKE OIL SW	Ignition switch ON	Brake fluid level switch ON	On	
		Brake fluid level switch OFF	Off	P
DISTANCE [km]	Ignition switch ON	—	Possible driving distance calculated by unified meter and A/C amp.	
OUTSIDE TEMP [°C] or [°F]	Ignition switch ON	—	Equivalent to ambient temperature <b>NOTE:</b> This may not match the indicated value on the information display.	

# UNIFIED METER AND A/C AMP.


## < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition		Value/Status
FUEL LOW SIG	Ignition switch ON	Low-fuel warning displayed	On
		Low-fuel warning not displayed	Off
BUZZER	Ignition switch ON	Buzzer ON	On
		Buzzer OFF	Off
ASCD REQ SPD	Ignition switch ON	While driving	Same value as ASCD or speed limiter set vehicle speed
ASCD STATUS	Ignition switch ON	ASCD and speed limiter system OFF	Off
		ASCD system ON	ASCD
		ASCD set vehicle speed	CRUISE
		Speed limiter system ON	SL ON
		Speed limiter set vehicle speed	SL SET
ASCD SPD BLNK	Ignition switch ON	Set vehicle speed indicator blinking	On
		Set vehicle speed indicator not blinking	Off

**NOTE:**

Some items are not available according to vehicle specification.

### TERMINAL LAYOUT







### PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
4 (G)	Ground	Stop lamp switch signal	Input	Ignition switch OFF	Brake pedal is depressed	12 V
					Other than the above	0 V
5 (L)	Ground	Manual mode shift up signal	Input	Ignition switch ON	Selector lever UP operation	0 V
					Other than the above	12 V
7 (GR)	Ground	Communication signal (AMP. → METER)	Output	Ignition switch ON	—	



# UNIFIED METER AND A/C AMP.

## < ECU DIAGNOSIS INFORMATION >


Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
8 (L)	Ground	Vehicle speed signal output (2-pulse)	Output	Ignition switch ON	Speedometer operated [When vehicle speed is ap- prox. 40 km/h (25 MPH)]	<b>NOTE:</b> The maximum voltage varies de- pending on the specification (destination unit).   <small>JSNIA0015GB</small>
9 (SB)	Ground	Seat belt buckle switch sig- nal (driver side)	Input	Ignition switch ON	When seat belt is fastened	12 V
					When seat belt is not fas- tened	0 V
10 (W)	Ground	Manual mode signal	Input	Ignition switch ON	Selector lever DS position	0 V
					Other than the above	12 V
11 (G)	Ground	Not manual mode signal	Input	Ignition switch ON	Selector lever DS position	12 V
					Other than the above	0 V
14 (BR)	Ground	Communication signal (LCD → AMP.)	Input	Ignition switch ON	—	 <small>JSNIA0028GB</small>
23 (Y)	Ground	A/T snow switch signal	Input	Ignition switch ON	Snow mode switch ON	12 V
					Snow mode switch OFF	0 V
25 (V)	Ground	Manual mode shift down signal	Input	Ignition switch ON	Selector lever down opera- tion	0 V
					Other than the above	12 V
27 (LG)	Ground	Communication signal (METER → AMP.)	Input	Ignition switch ON	—	 <small>SKIA3361E</small>
28 (R)	Ground	Vehicle speed signal (8-pulse)	Output	Ignition switch ON	Speedometer operated [When vehicle speed is ap- prox. 40 km/h (25 MPH)]	<b>NOTE:</b> The maximum voltage varies de- pending on the specification (destination unit).   <small>JSNIA0012GB</small>


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI


# UNIFIED METER AND A/C AMP.

## < ECU DIAGNOSIS INFORMATION >


Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
30 (V)	Ground	Parking brake switch signal	Input	Ignition switch ON	0 V
				Parking brake OFF	 <p style="text-align: right; font-size: small;">JSNIA0007GB</p>
34 (Y)	Ground	Communication signal (AMP. → LCD)	Output	Ignition switch ON	—
41 (L)	Ground	ACC power supply	Input	Ignition switch ACC	—
42 (BR)	Ground	Fuel level sensor signal	Input	Ignition switch ON	—
45 (V)	Ground	Ambient sensor signal	Input	—	—
53 (W)	Ground	Ignition power supply	Input	Ignition switch ON	—
54 (SB)	Ground	Battery power supply	Input	Ignition switch OFF	—
55 (B)	Ground	Ground	—	Ignition switch ON	—
56 (L)	Ground	CAN-H	—	—	—




JSNIA0007GB



JSNIA0027GB



JSNIA0013GB




JSNIA0014GB

# UNIFIED METER AND A/C AMP.

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
57 (LG)	Ground	Brake fluid level switch signal	Input	Ignition switch ON	Brake fluid level is normal.
				The brake fluid level is lower than the low level	0 V
58 (Y)	Ground	Fuel level sensor ground	—	Ignition switch ON	—
61 (B)	Ground	Ambient sensor ground	—	Ignition switch ON	—
71 (GR)	Ground	Ground	—	Ignition switch ON	—
72 (P)	Ground	CAN-L	—	—	—



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


MWI

# UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS INFORMATION >

## Wiring Diagram - METER -


INFOID:000000011400244



# UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS INFORMATION >

WB : With BOSE system  
OB : Without BOSE system




\* : This connector is not shown in "Harness Layout".

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

MWI

# UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS INFORMATION >



JRNWD7352GB

# UNIFIED METER AND A/C AMP.

## < ECU DIAGNOSIS INFORMATION >


METER		B1		E7		E32	
Connector No.	Wire	Terminal No.	Color Of Wire	Terminal No.	Color Of Wire	Terminal No.	Color Of Wire
WIRE TO WIRE		1	GR	48	L	1	LG
		2	BG	49	BG	2	B
		3	Y	50	W	1	LG
		4	Y	51	W	2	B
		5	Y	52	W		
		6	R	53	W		
		7	W	54	P		
		8	R	55	SB		
		9	LG	56	BR		
		10	LG	57	G		
		11	V	58	GR		
		12	V	59	BR		
		13	V	60	BR		
		14	V	61	BR		
		15	V	62	BR		
		16	V	63	BR		
		17	V	64	BR		
		18	V	65	BR		
		19	V	66	BR		
		20	V	67	BR		
		21	V	68	BR		
		22	V	69	BR		
		23	V	70	BG		
		24	V	71	BG		
		25	SB	72	GR		
		26	G	73	P		
		27	W				
		28	R				
		29	R				
		30	R				
		31	V				
		32	SB				
		33	SHIELD				
		34	SHIELD				
		35	PR				
		36	Y				
		37	SHIELD				
		38	Y				
		39	SB				
		40	P				
		41	L				
		42	SHIELD				
		43	R				
		44	G				
		45	SHIELD				
		46	SB				
		47	BR				
		48	Y				
		49	SB				
		50	Y				
		51	SB				
		52	Y				
		53	SB				
		54	Y				
		55	SB				
		56	Y				
		57	SB				
		58	Y				
		59	SB				
		60	Y				
		61	SB				
		62	Y				
		63	SB				
		64	Y				
		65	SB				
		66	Y				
		67	SB				
		68	Y				
		69	SB				
		70	Y				
		71	SB				
		72	Y				
		73	SB				
		74	L				
		75	S				
		76	Y				
		77	W				
		78	Y				
		79	W				
		80	W				
		81	W				
		82	W				
		83	P				
		84	Y				
		85	G				
		86	W				
		87	R				
		88	BR				
		89	BR				
		90	Y				
		91	SB				
		92	BR				
		93	P				
		94	BG				
		95	BG				
		96	BG				
		97	BG				
		98	BG				
		99	BG				
		100	BG				
		101	BG				
		102	BG				
		103	BG				
		104	BG				
		105	BG				
		106	BG				
		107	BG				
		108	BG				
		109	BG				
		110	BG				
		111	BG				
		112	BG				
		113	BG				
		114	BG				
		115	BG				
		116	BG				
		117	BG				
		118	BG				
		119	BG				
		120	BG				
		121	BG				
		122	BG				
		123	BG				
		124	BG				
		125	BG				
		126	BG				
		127	BG				
		128	BG				
		129	BG				
		130	BG				
		131	BG				
		132	BG				
		133	BG				
		134	BG				
		135	BG				
		136	BG				
		137	BG				
		138	BG				
		139	BG				
		140	BG				
		141	BG				
		142	BG				
		143	BG				
		144	BG				
		145	BG				
		146	BG				
		147	BG				
		148	BG				
		149	BG				
		150	BG				
		151	BG				
		152	BG				
		153	BG				
		154	BG				
		155	BG				
		156	BG				
		157	BG				
		158	BG				
		159	BG				
		160	BG				
		161	BG				
		162	BG				
		163	BG				
		164	BG				
		165	BG				
		166	BG				
		167	BG				
		168	BG				
		169	BG				
		170	BG				
		171	BG				
		172	BG				
		173	BG				
		174	BG				
		175	BG				
		176	BG				
		177	BG				
		178	BG				
		179	BG				
		180	BG				
		181	BG				
		182	BG				
		183	BG				
		184	BG				
		185	BG				
		186	BG				
		187	BG				
		188	BG				
		189	BG				
		190	BG				
		191	BG				
		192	BG				
		193	BG				
		194	BG				
		195	BG				
		196	BG				
		197	BG				
		198	BG				
		199	BG				
		200	BG				
		201	BG				
		202	BG				
		203	BG				
		204	BG				
		205	BG				
		206	BG				
		207	BG				
		208	BG				
		209	BG				
		210	BG				
		211	BG				
		212	BG				
		213	BG				
		214	BG				
		215	BG				
		216	BG				
		217	BG				
		218	BG				
		219	BG				
		220	BG				
		221	BG				
		222	BG				
		223	BG				
		224	BG				
		225	BG				
		226	BG				
		227	BG				
		228	BG				
		229					

# UNIFIED METER AND A/C AMP.

## < ECU DIAGNOSIS INFORMATION >

### METER

Connector No.	E40
Connector Name	WIRE TO WIRE
Connector Type	SA438MB-RSS-S4Z8



42	LG	-	-
43	GR	-	-
44	GR	-	-
45	SHIELD	-	-
46	W	-	-
47	BR	-	-
48	BR	-	-
49	G	-	-
50	B	-	-
51	SB	-	-
52	R	-	-

Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	GROUND
2	GR	UBMR
3	PG	GROUND
4	Y	DS FL
5	Y	DS FL
6	BR	DP RL
7	BR	DP RL
8	W	DP FR
9	B	DP FR
10	W	DS FR
11	V	DIAG-K
12	P	CAN-L
13	L	CAN-L
14	G	BUS-L
15	BG	BUS-L
16	BR	DP FL
17	BR	DS RL
18	BR	DS RL
19	BR	DS RL
20	B	UZ
21	SB	UZ
22	W	DS BR
23	L	DS BR
24	GR	YOGA SW
25	V	CAN-H
26	V	CAN-H
27	GR	BUS-H
28	V	BUS-H
29	P	UZ
30	R	UZ
31	BR	UZ
32	G	UZ
33	G	UZ
34	BG	UZ
35	L	UZ
36	L	UZ
37	SHIELD	UZ
38	L	UZ
39	P	UZ
40	R	UZ
41	W	UZ

Connector No.	E47
Connector Name	BRAKE FLUID LEVEL SWITCH
Connector Type	XY02FCY




Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	B	-

Connector No.	E76
Connector Name	AMBIENT SENSOR
Connector Type	RS02FE




Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	P	-

Connector No.	E103
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS18FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
3F	SB	-
4F	G	-
2F	G	-
1F	BR	-
9F	L	-
8F	P	-

Connector No.	E108
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	-
3	BG	-
5	G	-
6	Y	-
7	V	-
9	R	-
12	R	-
13	L	-
14	L	-
15	P	-
16	W	-
17	SB	-
18	BG	-



# UNIFIED METER AND A/C AMP.

## < ECU DIAGNOSIS INFORMATION >

### METER

Terminal No.	Color Of Wire	Signal Name [Specification]
20	LG	-
21	BR	-
22	Y	-
23	SB	-
24	LG	-
25	Y	-
26	R	-
27	B	-
28	R	-
29	R	-
30	LG	-
31	G	-
32	GR	-
33	BR	-
34	LG	-
35	V	-
36	P	-
37	SB	-
38	LG	-
39	CB	-
40	LG	-
41	R	-
42	G	-
43	V	-
44	L	-
45	W	-
46	W	-
47	V	-
48	W	-
49	GR	-
50	LG	-
51	SB	-
52	SHIELD	-
53	L	-
54	P	-

Connector No.	E107
Connector Name	PARKING BRAKE SWITCH
Connector Type	TBD1FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	EG	-

Connector No.	E119
Connector Name	STOP LAMP SWITCH
Connector Type	M0HEW-LC



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	W	-
3	G	-
4	V	-

Connector No.	F36
Connector Name	ALTERNATOR
Connector Type	H533FB




Terminal No.	Color Of Wire	Signal Name [Specification]
2	G	L
3	V	S
4	W	C

Connector No.	F37
Connector Name	OIL PRESSURE SWITCH
Connector Type	E01FGY-RS-4R



Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	-

Connector No.	F39
Connector Name	WIRE TO WIRE
Connector Type	SAA33FB-RSF-S4Z8



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L/Y	-
2	SHIELD	-
3	L/B	-
4	SHIELD	-
5	BR	-
6	W	-
7	G	-
8	W	-
9	W	-
10	G	-
11	R	-
12	P	-
13	L	-
14	LG	-
15	O	-
16	O	-
17	Y	-
18	LG	-
19	P	-
20	O	-

Connector No.	F51
Connector Name	A/T ASSEMBLY
Connector Type	RK1DFG-DGY



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
2	R	-
3	L	-
4	V	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

MWI



# UNIFIED METER AND A/C AMP.

## < ECU DIAGNOSIS INFORMATION >

### METER


Terminal No.	Color Of Wire	Signal Name [Specification]
18	P	
20	L	
21	LG	
32	Y	
33	R	
36	R	
37	Y	
38	R	
39	SB	
41	V	
42	LG	
43	P	
44	B	
45	BG	
46	G	
47	L	
48	L	
66	Y	
67	G	
80	SB	
81	B	
82	V	
83	W	
84	L	
85	GR	
89	LG	
91	W	
93	Y	
95	CG	
96	SHIELD	
98	V	
99	SB	
100	SB	

Connector No. M7  
 Connector Name WIRE TO WIRE  
 Connector Type TH800MY-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	
2	P	
3	P	
4	Y	
6	L	
8	G	
9	Y	
24	V	
25	LG	
26	BR	
27	BG	
28	LG	
31	V	
32	SHIELD	
33	SHIELD	
34	GR	
35	BR	
36	Y	
37	SHIELD	
38	SB	
39	LG	
40	O	
41	W	
42	SHIELD	
43	R	
44	G	
45	SHIELD	
46	SH	
55	B	
56	V	
59	Y	
71	V	
72	P	
73	SB	
74	V	
81	W	
82	BR	
84	LG	
85	BG	
86	SB	
87	SB	
88	SB	
89	CG	
90	L	
92	L	
93	P	
95	BG	


Connector No. M24  
 Connector Name DATA LINK CONNECTOR  
 Connector Type ED18FV-P



Terminal Color Of Wire  
 3 LG  
 4 B  
 5 D  
 6 D  
 7 V  
 8 G  
 11 SB  
 14 P  
 16 R

Signal Name [Specification]  
 -  
 -  
 -  
 -  
 -  
 -  
 -  
 -  
 -  
 -  
 -  
 -

Connector No. M28  
 Connector Name AIR BAG DIAGNOSIS SENSOR UNIT  
 Connector Type M28FV-EX




Terminal Color Of Wire  
 1 LG  
 2 B  
 3 Y  
 4 Y  
 5 Y  
 6 Y  
 7 Y  
 8 Y  
 9 Y  
 18 SB  
 19 V

Signal Name [Specification]  
 -  
 -  
 -  
 -  
 -  
 -  
 -  
 -  
 -  
 -  
 -  
 -

Terminal Color Of Wire  
 22 SHIELD  
 23 LG  
 24 R  
 25 R  
 51 R  
 52 G  
 53 Y  
 54 BR  
 59 L  
 60 P

Connector No. M53  
 Connector Name COMBINATION METER  
 Connector Type S480FV



Terminal Color Of Wire  
 1 V  
 2 LG  
 3 GR  
 4 R  
 5 R  
 6 R  
 7 LG  
 8 LG  
 10 W  
 15 B  
 16 BR  
 18 GR  
 19 B  
 20 R  
 21 G  
 22 B  
 24 BR  
 25 Y  
 26 R  
 27 R  
 28 SB  
 29 P  
 30 G  
 31 L  
 33 R  
 36 LG

Signal Name [Specification]  
 BATTERY POWER SUPPLY  
 COMMUNICATION SIGNAL (METER-AMP)  
 COMMUNICATION SIGNAL (AMP-METER)  
 COMMUNICATION SIGNAL (METER-AMP)  
 AIR BAG SIGNAL  
 AIR BAG SIGNAL  
 AIR BAG SIGNAL  
 SECURITY SIGNAL  
 GROUND  
 METER CONTROL SWITCH GROUND  
 ILL GND  
 ILL GND  
 ILL  
 IGNITION SIGNAL  
 GROUND  
 COMMUNICATION SIGNAL (LCD-AMP)  
 COMMUNICATION SIGNAL (AMP-LCD)  
 VERGEE SPEED SIGNAL (G-PULSE)  
 PARKING LOCK SIGNAL  
 PARKING LOCK SIGNAL  
 SEAT BELT BUCKLE SW SIGNAL (DRIVER SIDE)  
 SEAT BELT BUCKLE SWITCH SIGNAL (PASSENGER SIDE)  
 WASHER LEVEL SWITCH SIGNAL  
 ILLUMINATION CONTROL SIGNAL  
 ILLUMINATION CONTROL SIGNAL  
 SELECT SWITCH SIGNAL

A B C D E F G H I J K L M MWI O P


# UNIFIED METER AND A/C AMP.

## < ECU DIAGNOSIS INFORMATION >

### METER

37	Y	ENTER SWITCH SIGNAL
38	G	TRIP & RESET SWITCH SIGNAL
39	P	ILLUMINATION CONTROL SWITCH SIGNAL (-)
40	BG	ILLUMINATION CONTROL SWITCH SIGNAL (+)

Connector No.	M54
Connector Name	METER CONTROL SWITCH
Connector Type	TH142FW-NH



Terminal No.	Color	Wire	Signal Name [Specification]
1	Y		
2	LG		
3	B		
4	R		
5	G		
7	BR		
8	GR		
9	BG		
10	P		

Connector No.	M66
Connector Name	UNIFIED METER AND A/C AMP.
Connector Type	TH407FW-NH



Terminal No.	Color	Wire	Signal Name [Specification]
4	G		STOP LAMP SWITCH SIGNAL
5	L		MANUAL MODE SHIFT UP SIGNAL
7	GR		COMMUNICATION SIGNAL (AMP-METER)
8	L		VEHICLE SPEED SIGNAL (2-PULSE)
9	SB		SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SIDE)


10	W	MANUAL MODE SIGNAL
11	C	NON-MANUAL MODE SIGNAL
14	BR	COMMUNICATION SIGNAL (LCD-AMP)
23	Y	A/T SNOW SWITCH SIGNAL
25	V	MANUAL MODE SHIFT DOWN SIGNAL
27	LG	COMMUNICATION SIGNAL (METER-AMP)
28	R	VEHICLE SPEED SIGNAL (8-PULSE)
30	V	PARKING BRAKE SWITCH SIGNAL
34	Y	COMMUNICATION SIGNAL (AMP-LCD)
38	P	BLOWER MOTOR CONTROL SIGNAL

Connector No.	M67
Connector Name	UNIFIED METER AND A/C AMP.
Connector Type	TH227FW-NH



Terminal No.	Color	Wire	Signal Name [Specification]
41	L		ACC POWER SUPPLY
42	BR		FUEL LEVEL SENSOR SIGNAL
43	BR		IN-TAKE SENSOR SIGNAL
44	Y		AMBIENT SENSOR SIGNAL
45	V		SUNLOAD SENSOR SIGNAL
46	Y		IGNITION POWER SUPPLY
53	W		BATTERY POWER SUPPLY
54	SB		GROUND
55	B		GROUND
56	L		CAN-H
57	LG		BRAKE FLUID LEVEL SWITCH
58	Y		FUEL LEVEL SENSOR GROUND
59	GR		INTAKE SENSOR GROUND
60	W		IN-VEHICLE SENSOR GROUND
61	B		AMBIENT SENSOR GROUND
62	SB		SUNLOAD SENSOR GROUND
63	PG		ECU SIGNAL
64	PG		A/C SIGNAL
70	R		EACH DOOR MOTOR POWER SUPPLY
71	GR		GROUND
72	P		CAN-L

Connector No.	M107
Connector Name	ECM
Connector Type	RH240V-42Z-FR-H-LZ



Terminal No.	Color	Wire	Signal Name [Specification]
68	R		ACCELERATOR PEDAL POSITION SENSOR 2
69	P		ACCELERATOR PEDAL POSITION SENSOR 2
69	P		SENSOR POWER SUPPLY
100	W		SENSOR GROUND
101	SB		ASCD STEERING SWITCH
102	LG		EVAP CONTROL SYSTEM PRESSURE SENSOR
103	GR		SENSOR POWER SUPPLY
104	V		SENSOR GROUND
105	L		REFRIGERANT PRESSURE SENSOR
106	W		FUEL TANK TEMPERATURE SENSOR
107	GR		SENSOR POWER SUPPLY
108	Y		SENSOR GROUND
109	G		PNP SWITCH
110	R		ENGINE SPEED OUTPUT SIGNAL
112	V		SENSOR GROUND
113	P		CAN COMMUNICATION LINE
114	L		CAN COMMUNICATION LINE
117	V		DATA LINK CONNECTOR
121	LG		EVAP CANISTER VENT CONTROL VALVE
122	P		STOP LAMP SWITCH
123	B		ECM GROUND
124	B		ECM GROUND
125	R		POWER SUPPLY FOR ECM
126	BR		ASCD BRAKE SWITCH
127	B		ECM GROUND
128	B		ECM GROUND

Connector No.	M116
Connector Name	WIRE TO WIRE
Connector Type	TK38AW-HS10




Terminal No.	Color	Wire	Signal Name [Specification]
1	W		
2	BG		
3	BG		
4	P		
5	B		
9	R		
10	R		
19	BG		
20	Y		
28	B		
29	LG		
31	W		
33	B		
34	B		
35	L		
36	G		
37	R		
38	SB		
43	L		
44	P		
45	Y		
46	SB		

# UNIFIED METER AND A/C AMP.

## < ECU DIAGNOSIS INFORMATION >


### METER

Connector No.	M122
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
72	R	ROOM ANT 2-
73	B	ROOM ANT 2+
74	SB	PASSENGER DOOR ANT-
75	BR	PASSENGER DOOR ANT+
76	V	DRIVER DOOR ANT-
77	LG	DRIVER DOOR ANT+
78	Y	ROOM ANT 1-
79	BR	ROOM ANT 1+
80	GR	NATS ANT AMP
81	W	NATS ANT AMP
82	SB	IGN RELAY (F/B) CONT
83	Y	KEYLESS ENTRY RECEIVER COMM
87	Y	COMBI SW INPUT 5
88	BG	COMBI SW INPUT 3
90	P	CAN-L
91	P	CAN-H
92	LG	KEY SLOT 1 CONT
93	GR	CON IND
95	BG	ACC RELAY CONT
96	GR	A/T SHIFT SELECTOR POWER SUPPLY
99	R	SHIFT P
100	Y	PASSENGER DOOR REQUEST SW
101	P	DRIVER DOOR REQUEST SW
102	BG	BLOWER FAN MOTOR RELAY CONT
103	P	KEYLESS ENTRY RECEIVER POWER SUPPLY
107	LG	COMBI SW INPUT 1
108	R	COMBI SW INPUT 4
109	W	COMBI SW INPUT 2
110	G	HAZARD SW

Connector No.	M123
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FC-NH




Terminal No.	Color Of Wire	Signal Name [Specification]
113	BG	OPTICAL SENSOR
114	SB	STOP LAMP SW
115	SB	STOP LAMP 2
118	SS	DR DOOR UNLOCK SENSOR
119	SS	KEY SLOT SW
121	V	IGN F/B
123	V	PASSENGER DOOR SW
124	R	TRUNK LID OPERATOR CANCEL SW
129	BG	POWER WINDOW SW COMM
132	V	PUSH-BUTTON IGNITION SW ILL POWER
133	L	LOCK IND
134	LG	RECEIVER / SENSOR GND
137	BG	RECEIVER / SENSOR POWER SUPPLY
138	V	TIRE PRESSURE RECEIVER COMM
139	L	SHIFT IN P
140	B	SECURITY SW CONT
141	P	COMBI SW OUTPUT 1
142	BR	COMBI SW OUTPUT 2
143	P	COMBI SW OUTPUT 3
144	G	COMBI SW OUTPUT 4
145	L	COMBI SW OUTPUT 5
146	SS	COMBI SW OUTPUT 6
150	GR	DRIVER DOOR SW
151	G	REAR WINDOW DEFROGGER RELAY CONT

Connector No.	M137
Connector Name	A/T SHIFT SELECTOR
Connector Type	TH12FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	V	-
3	Y	-
4	B	-
5	G	-
7	Y	-
8	LG	-
9	B	-
10	GR	-
11	R	-


Connector No.	M202
Connector Name	AV CONTROL UNIT
Connector Type	TH24FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
36	BG	SIGNAL VCC
37	LG	SIGNAL GND
38	R	AV COMM (L)
39	R	AV COMM (H)
40	B	COMBI SW OUTPUT 1
41	B	RGB (RED) SIGNAL
42	W	SHIELD
43	W	RGB SYNC
44	G	RGB (RED) SIGNAL
45	L	RGB (GREEN) SIGNAL
46	L	RGB (BLUE) SIGNAL
47	P	RGB (BLUE) SIGNAL

46	V	COMPOSITE IMAGE GND
47	BR	COMPOSITE VIDEO SIGNAL
48	BR	INVERTER GND
49	BR	INVERTER GND
50	G	V.P.
51	P	COMMA (CONT-RISP)
52	SHIELD	SHIELD
57	SHIELD	SHIELD
58	SHIELD	SHIELD

Connector No.	M204
Connector Name	AV CONTROL UNIT
Connector Type	TH32FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
76	LG	AV COMM (L)
77	SB	AV COMM (H)
78	LG	AV COMM (L)
79	SB	AV COMM (H)
80	P	AV COMM (L)
81	P	AV COMM (H)
82	BR	SW GND
86	SHIELD	SHIELD
87	L	TEL VOICE SIGNAL (+)
88	P	TEL VOICE SIGNAL (-)
92	R	VEHICLE SPEED (8-PULSE)
93	SB	PARKING BRAKE
94	BG	REVERSE
95	G	IGNITION
96	V	EJECT SIGNAL


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

MWI

# UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS INFORMATION >

<b>METER</b>	
Connector No.	ME10
Connector Name	AV CONTROL UNIT
Connector Type	TH32FW-4H



Terminal No.	Color	Off	Signal Name [Specification]
63	SB		PARKING BRAKE
64	P		COMPOSITE IMAGE CMP.
65	L		COMPOSITE IMAGE SIGNAL
71	SHIELD		MICROPHONE GND
72	G		MICROPHONE VCC
73	P		COMM (CONT-DISP)
74	P		CAN-L
75	LG		AV COMM (L)
76	LG		AV COMM (L)
79	L		ILLUMINATION
80	G		IGNITION
81	BG		REVERSE
82	R		VEHICLE SPEED (3-PULSE)
83	SHIELD		SHIELD
84	P		COMPOSITE IMAGE SIGNAL
87	SHIELD		SHIELD
88	L		COMM (DISP-CONT)
89	L		CAN-H
91	SB		AV COMM (H)
92	SB		AV COMM (H)

JRNWD7401GB

## Fail-safe

INFOID:000000010990642

## FAIL-SAFE

Combination meter performs fail-safe operation when unified meter and A/C amp. communication is malfunction.

Solution for communication error between the unified meter and A/C amp. and combination meter.

# UNIFIED METER AND A/C AMP.

## < ECU DIAGNOSIS INFORMATION >

Function	Specifications	A	
Speedometer	Reset to zero by suspending communication.	B	
Tachometer			
Fuel gauge			
Engine coolant temperature gauge			
Information display	Door open warning	C	
	Parking brake release warning	D	
	Low tire pressure warning	E	
	Fuel filler cap warning	F	
	Instantaneous fuel warning	<ul style="list-style-type: none"> <li>• When reception time of an abnormal signal is 2 seconds or less, the last received datum is used for calculation to indicate the result.</li> <li>• When reception time of an abnormal signal is more than two seconds, the last result calculated during normal condition is indicated.</li> </ul>	
	Average fuel consumption		
	Average vehicle speed		
Travel distance			
Illumination control	When suspending communication, change to nighttime mode.	G	
Buzzer	The buzzer turns off by suspending communication.	H	
Warning lamp/indicator lamp	ABS warning lamp	The lamp turns on by suspending communication.	I
	Brake warning lamp		
	CRUISE warning lamp		
	Malfunction indicator lamp		
	High beam indicator	The lamp turns off by suspending communication.	J
	Turn signal indicator lamp		
	Oil pressure warning lamp		
	A/T CHECK warning lamp		
	VDC warning lamp		
	VDC OFF indicator lamp		
	AWD warning lamp		
	Low tire pressure warning lamp		
	Key warning lamp		
	AFS OFF indicator lamp		
	Master warning lamp		
	Tail lamp indicator lamp		
Front fog lamp indicator lamp	K		

## DTC Index

INFOID:000000010990643

MWI

Display contents of CONSULT	Time	Diagnostic item is detected when ...	Refer to	O
CAN COMM CIRCUIT [U1000]	CRNT, 1 - 39	When unified meter and A/C amp. is not transmitting or receiving CAN communication signal for 2 seconds or more.	<a href="#">MWI-42.</a> <a href="#">"Diagnosis Procedure"</a>	P
CONTROL UNIT (CAN) [U1010]	CRNT, 1 - 39	When detecting error during the initial diagnosis of CAN controller of unified meter and A/C amp.	<a href="#">MWI-43.</a> <a href="#">"Diagnosis Procedure"</a>	
COMM ERROR 1 [B2201]	CRNT, 1 - 39	If a communication error is present in the communication line between unified meter and A/C amp. and combination meter for 2 seconds or more.	<a href="#">MWI-44.</a> <a href="#">"Diagnosis Procedure"</a>	

## UNIFIED METER AND A/C AMP.

### < ECU DIAGNOSIS INFORMATION >

Display contents of CONSULT	Time	Diagnostic item is detected when ...	Refer to
COMM ERROR 2 [B2202]	CRNT, 1 - 39	If a communication error is present in the communication line between unified meter and A/C amp. and combination meter for 2 seconds or more.	<a href="#">MWI-46. "Diagnosis Procedure"</a>
VEHICLE SPEED [B2205]	CRNT, 1 - 39	The abnormal vehicle speed signal is input from ABS actuator and electric unit (control unit) for 2 seconds or more.	<a href="#">MWI-48. "Diagnosis Procedure"</a>
ENGINE SPEED [B2267]	CRNT, 1 - 39	If ECM continuously transmits abnormal engine speed signals for 2 seconds or more.	<a href="#">MWI-49. "Diagnosis Procedure"</a>
WATER TEMP [B2268]	CRNT, 1 - 39	If ECM continuously transmits abnormal engine coolant temperature signals for 60 seconds or more.	<a href="#">MWI-50. "Diagnosis Procedure"</a>



# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

## IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Reference Value

INFOID:000000011426132

VALUES ON THE DIAGNOSIS TOOL

**NOTE:**

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor Item	Condition		Value/Status
RAD FAN REQ	Engine idle speed	Changes depending on engine coolant temperature, air conditioner operation status, vehicle speed, etc.	0 - 100 %
AC COMP REQ	Engine running	A/C switch OFF	Off
		A/C switch ON (Compressor is operating)	On
TAIL&CLR REQ	Lighting switch OFF		Off
	Lighting switch 1ST, 2ND, HI or AUTO (Light is illuminated)		On
HL LO REQ	Lighting switch OFF		Off
	Lighting switch 2ND HI or AUTO (Light is illuminated)		On
HL HI REQ	Lighting switch OFF		Off
	Lighting switch HI		On
FR FOG REQ	Lighting switch 2ND or AUTO (Light is illuminated)	Front fog lamp switch OFF	Off
		Front fog lamp switch ON	On
FR WIP REQ	Ignition switch ON	Front wiper switch OFF	Stop
		Front wiper switch INT	1LOW
		Front wiper switch LO	Low
		Front wiper switch HI	Hi
WIP AUTO STOP	Ignition switch ON	Front wiper stop position	STOP P
		Any position other than front wiper stop position	ACT P
WIP PROT	Ignition switch ON	Front wiper operates normally	Off
		Front wiper stops at fail-safe operation	BLOCK
IGN RLY1 -REQ	Ignition switch OFF or ACC		Off
	Ignition switch ON		On
IGN RLY	Ignition switch OFF or ACC		Off
	Ignition switch ON		On
PUSH SW	Release the push-button ignition switch		Off
	Press the push-button ignition switch		On
INTER/NP SW	Ignition switch ON	Selector lever in any position other than P or N	Off
	Ignition switch ON	Selector lever in P or N position	On
ST RLY CONT	Ignition switch ON		Off
	At engine cranking		On
IHBT RLY -REQ	Ignition switch ON		Off
	At engine cranking		On

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

MWI

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)


## < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status	
ST/INHI RLY	Ignition switch ON	Off	
	At engine cranking	INHI ON → ST ON	
	The status of starter relay or starter control relay cannot be recognized by the battery voltage malfunction, etc. when the starter relay is ON and the starter control relay is OFF	UNKWN	
DETENT SW	Ignition switch ON	<ul style="list-style-type: none"> <li>• Press the selector button with selector lever in P position</li> <li>• Selector lever in any position other than P</li> </ul>	Off
	Release the selector button with selector lever in P position		On
S/L RLY -REQ	<b>NOTE:</b> The item is indicated, but not monitored.	Off	
S/L STATE	<b>NOTE:</b> The item is indicated, but not monitored.	UNLOCK	
DTRL REQ	<b>NOTE:</b> The item is indicated, but not monitored.	Off	
OIL P SW	Ignition switch OFF, ACC or engine running	Open	
	Ignition switch ON	Close	
HOOD SW	Close the hood	Off	
	Open the hood	On	
HL WASHER REQ	<b>NOTE:</b> The item is indicated, but not monitored.	Off	
THFT HRN REQ	Not operation	Off	
	<ul style="list-style-type: none"> <li>• Panic alarm is activated</li> <li>• Horn is activated with VEHICLE SECURITY (THEFT WARNING) SYSTEM</li> </ul>	On	
HORN CHIRP	Not operating	Off	
	Door locking with Intelligent Key (horn chirp mode)	On	
CRNRNG LMP REQ	<b>NOTE:</b> The item is indicated, but not monitored.	Off	

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

## TERMINAL LAYOUT



## PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
1 (W)	Ground	Battery power supply	Input	Ignition switch OFF		Battery voltage
2 (L)	Ground	Battery power supply	Input	Ignition switch OFF		Battery voltage
4 (V)	Ground	Front wiper LO	Output	Ignition switch ON	Front wiper switch OFF	0 V
					Front wiper switch LO	Battery voltage
5 (L)	Ground	Front wiper HI	Output	Ignition switch ON	Front wiper switch OFF	0 V
					Front wiper switch HI	Battery voltage
7 (P)	Ground	Tail, license plate lamps & interior lamps	Output	Ignition switch ON	Lighting switch OFF	0 V
					Lighting switch 1ST	Battery voltage
12 (B/W)	Ground	Ground	—	Ignition switch ON		0 V
13 (Y)	Ground	Fuel pump power supply	Output	Approximately 1 second or more after turning the ignition switch ON		0 V
				<ul style="list-style-type: none"> <li>Approximately 1 second after turning the ignition switch ON</li> <li>Engine running</li> </ul>		Battery voltage
16 (LG)	Ground	Front wiper auto stop	Input	Ignition switch ON	Front wiper stop position	0 V
					Any position other than front wiper stop position	Battery voltage

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
19 (R)	Ground	Ignition relay power supply	Output	Ignition switch OFF	0 V	
				Ignition switch ON	Battery voltage	
25 (G)	Ground	Ignition relay power supply	Output	Ignition switch OFF	0 V	
				Ignition switch ON	Battery voltage	
27 (BG)	Ground	Ignition relay monitor	Input	Ignition switch OFF or ACC	Battery voltage	
				Ignition switch ON	0 V	
28 (L)	Ground	Push-button ignition switch	Input	Press the push-button ignition switch	0 V	
				Release the push-button ignition switch	Battery voltage	
30 (GR)	Ground	Starter relay control	Input	Selector lever in any position other than P or N (Ignition switch ON)	0 V	
				Selector lever P or N (Ignition switch ON)	Battery voltage	
36 (G)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage	
39 (P)	—	CAN-L	Input/ Output	—	—	
40 (L)	—	CAN-H	Input/ Output	—	—	
41 (B/W)	Ground	Ground	—	Ignition switch ON	0 V	
42 (GR)	Ground	Cooling fan relay control	Input	Ignition switch OFF or ACC	0 V	
				Ignition switch ON	0.7 V	
43 (G)	Ground	A/T shift selector (Detention switch)	Input	Ignition switch ON	<ul style="list-style-type: none"> <li>Press the selector button (selector lever P)</li> <li>Selector lever in any position other than P</li> </ul>	Battery voltage
					Release the selector button (selector lever P)	0 V
44 (LG)	Ground	Horn relay control	Input	The horn is deactivated	Battery voltage	
				The horn is activated	0 V	
45 (V)	Ground	Anti theft horn relay control	Input	The horn is deactivated	Battery voltage	
				The horn is activated	0 V	
46 (SB)	Ground	Starter relay control	Input	Selector lever in any position other than P or N (Ignition switch ON)	0 V	
				Selector lever P or N (Ignition switch ON)	Battery voltage	
				Release the clutch pedal	0 V	
				Depress the clutch pedal	Battery voltage	
48 (L)	Ground	A/C relay power supply	Output	Engine running	A/C switch OFF	0 V
					A/C switch ON (A/C compressor is operating)	Battery voltage
49 (BG)	Ground	ECM relay power supply	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)	0 V	
				<ul style="list-style-type: none"> <li>Ignition switch ON</li> <li>Ignition switch OFF (For a few seconds after turning ignition switch OFF)</li> </ul>	Battery voltage	

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)




## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
51 (Y)	Ground	Ignition relay power supply	Output	Ignition switch OFF	0 V	A
				Ignition switch ON	Battery voltage	B
53 (W)	Ground	ECM relay power supply	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)	0 V	C
				<ul style="list-style-type: none"> <li>Ignition switch ON</li> <li>Ignition switch OFF (For a few seconds after turning ignition switch OFF)</li> </ul>	Battery voltage	D
54 (P)	Ground	Throttle control motor relay power supply	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)	0 V	E
				<ul style="list-style-type: none"> <li>Ignition switch ON</li> <li>Ignition switch OFF (For a few seconds after turning ignition switch OFF)</li> </ul>	Battery voltage	F
55 (SB)	Ground	ECM power supply	Output	Ignition switch OFF	Battery voltage	G
56 (BR)	Ground	Ignition relay power supply	Output	Ignition switch OFF	0 V	H
				Ignition switch ON	Battery voltage	
57 (G)	Ground	Ignition relay power supply	Output	Ignition switch OFF	0 V	I
				Ignition switch ON	Battery voltage	
58 (GR)	Ground	Ignition relay power supply	Output	Ignition switch OFF	0 V	J
				Ignition switch ON	Battery voltage	
69 (BR)	Ground	ECM relay control	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)	Battery voltage	K
				<ul style="list-style-type: none"> <li>Ignition switch ON</li> <li>Ignition switch OFF (For a few seconds after turning ignition switch OFF)</li> </ul>	0 - 1.5 V	
70 (BG)	Ground	Throttle control motor relay control	Output	Ignition switch ON → OFF	0 - 1.0 V ↓ Battery voltage ↓ 0 V	L
				Ignition switch ON	0 - 1.0 V	M
74 (G)	Ground	Ignition relay power supply	Output	Ignition switch OFF	0 V	MWI
				Ignition switch ON	Battery voltage	
75 (SB)	Ground	Oil pressure switch	Input	Ignition switch ON	0 V	O
				Engine running	Battery voltage	

P

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
76 (Y)	Ground	Power generation command signal	Output	Ignition switch ON		 <p>6.3 V</p>
				40% is set on "ACTIVE TEST", "ALTERNATOR DUTY" of "ENGINE"		 <p>3.8 V</p>
				80% is set on "ACTIVE TEST", "ALTERNATOR DUTY" of "ENGINE"		 <p>1.4 V</p>
77 (R)	Ground	Fuel pump relay control	Output	<ul style="list-style-type: none"> <li>Approximately 1 second after turning the ignition switch ON</li> <li>Engine running</li> </ul>		0 - 1.0 V
				Approximately 1 second or more after turning the ignition switch ON		Battery voltage
80 (W)	Ground	Starter motor	Output	At engine cranking		Battery voltage
83 (R)	Ground	Headlamp LO (RH)	Output	Ignition switch ON	Lighting switch OFF	0 V
					Lighting switch 2ND	Battery voltage
84 (V)	Ground	Headlamp LO (LH)	Output	Ignition switch ON	Lighting switch OFF	0 V
					Lighting switch 2ND	Battery voltage
86 (W)	Ground	Front fog lamp (RH)	Output	Lighting switch 2ND	Front fog lamp switch OFF	0 V
					Front fog lamp switch ON	Battery voltage
87 (L)	Ground	Front fog lamp (LH)	Output	Lighting switch 2ND	Front fog lamp switch OFF	0 V
					Front fog lamp switch ON	Battery voltage
88 (G)	Ground	Washer pump power supply	Output	Ignition switch ON		Battery voltage
89 (BR)	Ground	Headlamp HI (RH)	Output	Ignition switch ON	Lighting switch OFF	0 V
					<ul style="list-style-type: none"> <li>Lighting switch HI</li> <li>Lighting switch PASS</li> </ul>	Battery voltage
90 (P)	Ground	Headlamp HI (LH)	Output	Ignition switch ON	Lighting switch OFF	0 V
					<ul style="list-style-type: none"> <li>Lighting switch HI</li> <li>Lighting switch PASS</li> </ul>	Battery voltage

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
91 (G)	Ground	Parking lamp (RH)	Output	Ignition switch ON	Lighting switch OFF	0 V
					Lighting switch 1ST	Battery voltage
92 (BG)	Ground	Parking lamp (LH)	Output	Ignition switch ON	Lighting switch OFF	0 V
					Lighting switch 1ST	Battery voltage
97 (V)	Ground	Cooling fan control	Output	Engine idling		0 - 5 V
104 (LG)	Ground	Hood switch	Input	Close the hood		Battery voltage
				Open the hood		0 V

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O


P

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

## Wiring Diagram - IPDM E/R -

INFOID:000000011426133




2014/06/09

JRMWF9364GB



# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >



JRMWF9365GB


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

MWI

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

---



JRMWF9366GB

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

### IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Connector No.	E4
Connector Name	IPDM E/R INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	LGPEB-MC



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	L	-

Connector No.	E5
Connector Name	IPDM E/R INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	TH20FW-CS12-M4-1V



Terminal No.	Color Of Wire	Signal Name [Specification]
4	V	-
5	L	-
6	SB	-
7	P	-
12	B/W	-
13	Y	-
16	LG	-
19	R	-
23	G	-
27	BG	-
28	L	-
30	GR	-
38	G	-

Connector No.	E6
Connector Name	IPDM E/R INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	TH3BFW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
38	P	-
41	P	-
42	B/W	-
43	GR	-
44	G	-
45	V	-
46	SB	-

Connector No.	E7
Connector Name	IPDM E/R INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	TH20FW-CS12-M4



Terminal No.	Color Of Wire	Signal Name [Specification]
48	L	-
49	BG	-
51	Y	-
53	W	-
54	B	-
55	BR	-
57	G	-
58	GR	-
69	BR	-
70	BG	-

74	G	-
75	SB	-
76	W	-
77	R	-
80	W	-

Connector No.	E8
Connector Name	IPDM E/R INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	NSDBFW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
83	R	-
84	V	-
86	W	-
87	L	-
88	G	-
89	BR	-
90	P	-

Connector No.	E9
Connector Name	IPDM E/R INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	TH1BFW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
92	EG	-
97	V	-
104	LG	-
105	L	-

## Fail-safe

### CAN COMMUNICATION CONTROL

When CAN communication with ECM and BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If No CAN Communication Is Available With ECM

JRMWF9518GB

INFOID:0000000011426134

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
MWI  
O  
P

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

Control part	Fail-safe operation
Cooling fan	<ul style="list-style-type: none"> <li>• Outputs the pulse duty signal (PWM signal) 100% when the ignition switch is turned ON</li> <li>• Outputs the pulse duty signal (PWM signal) 0% when the ignition switch is turned OFF</li> </ul>
A/C compressor	A/C relay OFF
Alternator	Outputs the power generation command signal (PWM signal) 0%

### If No CAN Communication Is Available With BCM

Control part	Fail-safe operation
Headlamp	<ul style="list-style-type: none"> <li>• Turns ON the headlamp low relay when the ignition switch is turned ON</li> <li>• Turns OFF the headlamp low relay when the ignition switch is turned OFF</li> <li>• Headlamp high relay OFF</li> </ul>
<ul style="list-style-type: none"> <li>• Parking lamps</li> <li>• Side maker lamp</li> <li>• License plate lamps</li> <li>• Illuminations</li> <li>• Tail lamps</li> </ul>	<ul style="list-style-type: none"> <li>• Turns ON the tail lamp relay when the ignition switch is turned ON</li> <li>• Turns OFF the tail lamp relay when the ignition switch is turned OFF</li> </ul>
Front wiper	<ul style="list-style-type: none"> <li>• The status just before activation of fail-safe control is maintained until the ignition switch is turned OFF while the front wiper is operating at LO or HI speed.</li> <li>• The wiper is operated at LO speed until the ignition switch is turned OFF if the fail-safe control is activated while the front wiper is set in the INT mode and the front wiper motor is operating.</li> </ul>
Horn	Horn relay OFF
Ignition relay	The status just before activation of fail-safe is maintained.
Starter motor	Starter control relay OFF

### IGNITION RELAY MALFUNCTION DETECTION FUNCTION

- IPDM E/R monitors the voltage at the contact circuit and excitation coil circuit of the ignition relay inside it.
- IPDM E/R judges the ignition relay error if the voltage differs between the contact circuit and the excitation coil circuit.
- If the ignition relay cannot turn OFF due to contact seizure, it activates the tail lamp relay for 10 minutes to alert the user to the ignition relay malfunction when the ignition switch is turned OFF.

Voltage judgment		IPDM E/R judgment	Operation
Ignition relay contact side	Ignition relay excitation coil side		
ON	ON	Ignition relay ON normal	—
OFF	OFF	Ignition relay OFF normal	—
ON	OFF	Ignition relay ON stuck	<ul style="list-style-type: none"> <li>• Detects DTC “B2098: IGN RELAY ON CIRC”</li> <li>• Turns ON the tail lamp relay for 10 minutes</li> </ul>
OFF	ON	Ignition relay OFF stuck	Detects DTC “B2099: IGN RELAY OFF CIRC”

### FRONT WIPER CONTROL

IPDM E/R detects front wiper stop position by a front wiper stop position signal.

When a front wiper stop position signal is in the conditions listed below, IPDM E/R stops power supply to wiper after repeating a front wiper 10 seconds activation and 20 seconds stop five times.

Ignition switch	Front wiper switch	Front wiper stop position signal
ON	OFF	The front wiper stop position signal (stop position) cannot be input for 10 seconds.
	ON	The front wiper stop position signal does not change for 10 seconds.

#### NOTE:

This operation status can be confirmed on the IPDM E/R “Data Monitor” that displays “BLOCK” for the item “WIP PROT” while the wiper is stopped.

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

### STARTER MOTOR PROTECTION FUNCTION

IPDM E/R turns OFF the starter control relay to protect the starter motor when the starter control relay remains active for 90 seconds.

### DTC Index

INFOID:000000011426135

#### NOTE:

- The details of time display are as follows.
  - CRNT: A malfunction is detected now.
  - PAST: A malfunction was detected in the past.
- IGN counter is displayed on FFD (Freeze Frame data).
  - The number is 0 when is detected now.
  - The number increases like 1 → 2 ... 38 → 39 after returning to the normal condition whenever IGN OFF → ON.
  - The number is fixed to 39 until the self-diagnosis results are erased if it is over 39.

x: Applicable

CONSULT display	Fail-safe	Refer to
No DTC is detected. further testing may be required.	—	—
U1000: CAN COMM CIRCUIT	×	<a href="#">PCS-14</a>
B2098: IGN RELAY ON CIRC	×	<a href="#">PCS-15</a>
B2099: IGN RELAY OFF CIRC	—	<a href="#">PCS-17</a>
B210B: STR CONT RLY ON CIRC	—	<a href="#">SEC-77</a>
B210C: STR CONT RLY OFF CIRC	—	<a href="#">SEC-78</a>
B210D: STARTER RLY ON CIRC	—	<a href="#">SEC-80</a>
B210E: STARTER RLY OFF CIRC	—	<a href="#">SEC-82</a>
B210F: INTRLCK/PNP SW ON	—	<a href="#">SEC-84</a>
B2110: INTRLCK/PNP SW OFF	—	<a href="#">SEC-86</a>

MWI

# THE FUEL GAUGE POINTER DOES NOT MOVE

< SYMPTOM DIAGNOSIS >

---

## SYMPTOM DIAGNOSIS

### THE FUEL GAUGE POINTER DOES NOT MOVE

#### Description

INFOID:0000000010990648

Fuel gauge needle will not move from a certain position.

#### Diagnosis Procedure

INFOID:0000000010990649

#### 1. CONDUCTING THE COMBINATION METER SELF-DIAGNOSIS MODE

---

Perform the self-diagnosis mode of combination meter, and then check that the fuel gauge operates normally. Refer to [MWI-36, "Diagnosis Description"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace combination meter. Refer to [MWI-130, "Removal and Installation"](#).

#### 2. CHECK FLOAT INTERFERENCE

---

Check that the float arm interferes with or binds to other components in the fuel tank.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning part.

#### 3. CHECK FUEL LEVEL SENSOR SIGNAL CIRCUIT

---

Check the fuel level sensor signal circuit. Refer to [MWI-54, "Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> Repair or replace malfunctioning parts.

# THE METER CONTROL SWITCH IS INOPERATIVE

< SYMPTOM DIAGNOSIS >

## THE METER CONTROL SWITCH IS INOPERATIVE

### Description

INFOID:000000010990650

If any of the following malfunctions is found for the meter control switch operation.

- All switches are inoperative.
- The specified switch cannot be operated.

### Diagnosis Procedure

INFOID:000000010990651

#### 1. CHECK METER CONTROL SWITCH SIGNAL CIRCUIT

Check the meter control switch signal circuit. Refer to [MWI-58, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair harness or connector.

#### 2. CHECK METER CONTROL SWITCH UNIT

Perform a unit check for the meter control switch. Refer to [MWI-59, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace combination meter.

NG >> Replace meter control switch.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI

# THE OIL PRESSURE WARNING LAMP DOES NOT TURN ON

< SYMPTOM DIAGNOSIS >

---

## THE OIL PRESSURE WARNING LAMP DOES NOT TURN ON

### Description

INFOID:000000010990652

The oil pressure warning lamp stays off when the ignition switch is turned ON.

### Diagnosis Procedure

INFOID:000000010990653

#### 1.CHECK OIL PRESSURE WARNING LAMP

---

Perform auto active test. Refer to [MWI-36, "Diagnosis Description"](#).

Is oil pressure warning lamp illuminated?

- YES >> GO TO 2.
- NO >> GO TO 4.

#### 2.CHECK OIL PRESSURE SWITCH SIGNAL CIRCUIT

---

Check the oil pressure switch signal circuit. Refer to [MWI-60, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair harness or connector.

#### 3.CHECK OIL PRESSURE SWITCH UNIT

---

Perform a unit check for the oil pressure switch. Refer to [MWI-60, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace IPDM E/R.
- NO >> Replace oil pressure switch.

#### 4.CHECK UNIFIED METER AND A/C AMP. INPUT SIGNAL

---

Connect CONSULT and perform an input signal check for the unified meter and A/C amp.

Is the inspection result normal?

- YES >> Replace combination meter.
- NO >> Replace BCM. Refer to [BCS-90, "Removal and Installation"](#).



# THE OIL PRESSURE WARNING LAMP DOES NOT TURN OFF

< SYMPTOM DIAGNOSIS >

## THE OIL PRESSURE WARNING LAMP DOES NOT TURN OFF

### Description

INFOID:000000010990654

The oil pressure warning lamp remains illuminated while the engine is running (normal oil pressure).

### Diagnosis Procedure

INFOID:000000010990655

#### 1. CHECK OIL PRESSURE WARNING LAMP

Perform auto active test. Refer to [MWI-36, "Diagnosis Description"](#).

Is oil pressure warning lamp illuminated?

- YES >> GO TO 2.
- NO >> GO TO 5.

#### 2. CHECK IPDM E/R OUTPUT VOLTAGE

1. Disconnect the oil pressure switch connector.
2. Turn ignition switch ON.
3. Check voltage between the oil pressure switch harness connector terminal 1 and ground.

Terminal		Voltage (Approx.)
(+)	(-)	
Oil pressure switch		12 V
Connector	Terminal	
F37	1	
Ground		

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> GO TO 4.

#### 3. CHECK OIL PRESSURE SWITCH UNIT

Perform a unit check for the oil pressure switch. Refer to [MWI-60, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-34, "Removal and Installation"](#).
- NO >> Replace oil pressure switch.

#### 4. CHECK OIL PRESSURE SWITCH SIGNAL CIRCUIT

Check the oil pressure switch signal circuit. Refer to [MWI-60, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Repair harness or connector.

#### 5. CHECK UNIFIED METER AND A/C AMP. INPUT SIGNAL

Connect CONSULT and perform an input signal check for the unified meter and A/C amp. Refer to [MWI-60, "Component Function Check"](#).

Is the inspection result normal?

- YES >> Replace combination meter.
- NO >> Replace BCM. Refer to [BCS-90, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI

# THE PARKING BRAKE RELEASE WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

< SYMPTOM DIAGNOSIS >

## THE PARKING BRAKE RELEASE WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

### Description

INFOID:000000010990656

- The parking brake warning is displayed during vehicle travel even though the parking brake is released.
- The parking brake warning is not displayed even though driving the vehicle with the parking brake applied.

### Diagnosis Procedure

INFOID:000000010990657

#### 1. CHECK PARKING BRAKE WARNING LAMP OPERATION

1. Start engine.
2. Check the operation of the parking brake warning lamp when operating the parking brake.

Condition	Warning lamp status
Parking brake ON	ON
Parking brake OFF	OFF

Is the inspection result normal?

- YES >> Replace combination meter.
- NO >> GO TO 2.

#### 2. CHECK PARKING BRAKE SWITCH SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Check the parking brake switch signal circuit. Refer to [MWI-62, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 3.
- NG >> Repair harness or connector.

#### 3. CHECK PARKING BRAKE SWITCH UNIT

Perform a unit check for the parking brake switch. Refer to [MWI-63, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace combination meter.
- NO >> Replace parking brake switch.

# THE LOW WASHER FLUID WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

< SYMPTOM DIAGNOSIS >

## THE LOW WASHER FLUID WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

### Description

INFOID:000000010990658

- The warning is still displayed even after washer fluid is added.
- The warning is not displayed even though the washer tank is empty.

### Diagnosis Procedure

INFOID:000000010990659

#### 1. CHECK WASHER LEVEL SWITCH SIGNAL CIRCUIT

Check the washer level switch signal circuit. Refer to [MWI-64. "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair harness or connector.

#### 2. CHECK WASHER LEVEL SWITCH UNIT

Perform a unit check for the washer level switch. Refer to [MWI-64. "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace combination meter.

NO >> Replace washer level switch. Refer to [WW-96. "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI

# THE DOOR OPEN WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

< SYMPTOM DIAGNOSIS >

## THE DOOR OPEN WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

### Description

INFOID:000000010990660

- The door ajar warning is displayed even though all of the doors are closed.
- The door ajar warning is not displayed even though a door is ajar.

### Diagnosis Procedure

INFOID:000000010990661

#### 1. CHECK BCM INPUT/OUTPUT SIGNAL

Connect CONSULT and check the BCM input signals. Refer to [DLK-66. "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> GO TO 3.

#### 2. CHECK UNIFIED METER AND A/C AMP. INPUT SIGNAL

Select the "Data Monitor" for the "METER/M&A" and check the "DOOR W/L" monitor value.

"DOOR W/L"

Door open : On

Door closed : Off

Is the inspection result normal?

YES >> Replace combination meter.

NO >> Replace BCM. Refer to [BCS-90. "Removal and Installation"](#).

#### 3. CHECK DOOR SWITCH SIGNAL CIRCUIT

Check the door switch signal circuit. Refer to [DLK-66. "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair harness or connector.

#### 4. CHECK DOOR SWITCH UNIT

Perform a unit check for the door switch. Refer to [DLK-68. "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace combination meter.

NO >> Replace applicable door switch. Refer to [DLK-257. "Removal and Installation"](#).

# THE TRUNK OPEN WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

< SYMPTOM DIAGNOSIS >

## THE TRUNK OPEN WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

### Description

INFOID:000000010990662

- The trunk ajar warning is displayed continuously even though the trunk lid is closed.
- The trunk ajar warning is not displayed even though the trunk lid is open.

### Diagnosis Procedure

INFOID:000000010990663

#### 1. CHECK BCM INPUT/OUTPUT SIGNAL

Connect CONSULT and check the BCM input signals. Refer to [DLK-78. "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> GO TO 3.

#### 2. CHECK UNIFIED METER AND A/C AMP. INPUT SIGNAL

Select the "Data Monitor" for the "METER/M&A" and check the "TRUNK/GLAS-H" monitor value.

"TRUNK/GLAS-H"

Trunk lid open : On  
Trunk lid closed : Off

Is the inspection result normal?

- YES >> Replace combination meter.
- NO >> Replace BCM.

#### 3. CHECK TRUNK ROOM LAMP SWITCH SIGNAL CIRCUIT

Check the trunk lid opener switch signal circuit. Refer to [DLK-78. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair harness or connector.

#### 4. CHECK TRUNK LOOM LAMP SWITCH UNIT

Perform a unit check for the trunk room lamp switch. Refer to [DLK-79. "Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace combination meter.
- NO >> Replace trunk lid lock. Refer to [DLK-254. "TRUNK LID LOCK : Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

MWI

O  
P

# THE AMBIENT TEMPERATURE DISPLAY IS INCORRECT

< SYMPTOM DIAGNOSIS >

---

## THE AMBIENT TEMPERATURE DISPLAY IS INCORRECT

### Description

INFOID:000000010990664

- The displayed ambient air temperature is higher than the actual temperature.
- The displayed ambient air temperature is lower than the actual temperature.

### Diagnosis Procedure

INFOID:000000010990665

#### **NOTE:**

Check that the symptom is not applicable to the normal operating condition before starting diagnosis. Refer to [MWI-127, "INFORMATION DISPLAY : Description"](#).

#### **1.CHECK AMBIENT SENSOR SIGNAL CIRCUIT**

---

Check the ambient sensor signal circuit. Refer to [HAC-59, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair harness or connector.

#### **2.CHECK AMBIENT SENSOR UNIT**

---

Perform a unit check for the ambient sensor. Refer to [HAC-60, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace unified meter and A/C amp.

NO >> Replace ambient sensor. Refer to [HAC-110, "Removal and Installation"](#).

# NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

## NORMAL OPERATING CONDITION COMPASS

### COMPASS : Description

INFOID:000000010990666

#### COMPASS

- The electronic compass is highly protected from changes in most magnetic fields. However, some large changes in magnetic fields can affect it. Some examples are (but not limited to): high tension power lines, large steel buildings, subways, steel bridges, automatic car washes, large piles of scrap metal, etc. While this does not happen very often, it is possible.
- During normal operation, the Compass Mirror will continuously update the compass calibration to adjust for gradual changes in the vehicle's magnetic "remnant" field. If the vehicle is subjected to high magnetic influences, the compass may appear to indicate false headings, become locked, or appear that it is unable to be calibrated. If this occurs, perform the calibration procedure.
- If at any time the compass continually displays the incorrect direction or the reading is erratic or locked, verify the correct zone variance.

#### Symptom Chart

Symptom	Cause	Solution / Reference
The compass display reads "C".	<ul style="list-style-type: none"><li>• Compass is not calibrated.</li><li>• Incorrect zone variance setting.</li><li>• Large change in magnetic field (Steel bridges, subways, concentrations of metal, carwashes, etc.)</li><li>• Compass was calibrated incorrectly or in the presence of a strong magnetic field.</li></ul>	Perform Calibration. Refer to <a href="#">MWI-32, "Description"</a> .
Compass shows the wrong direction.		
Compass does not change direction appears "Locked".		
Compass does not show all the directions, one or more is missing.		
The compass was calibrated but it "loses" calibration.		
On long trips the compass shows the wrong direction.	Perform Zone Variation Setting if correct reading is desired in that location. Refer to <a href="#">MWI-32, "Description"</a> .	

## INFORMATION DISPLAY

### INFORMATION DISPLAY : Description

INFOID:000000010990667

#### AMBIENT AIR TEMPERATURE

The displayed ambient air temperature on the information display may differ from the actual temperature because it is a corrected value calculated from the ambient sensor signal by the unified meter and A/C amp. Refer to [MWI-27, "INFORMATION DISPLAY : System Description"](#) for details on the correction process.

#### POSSIBLE DRIVING DISTANCE

The calculated possible driving distance may differ from the actual distance to empty if the refueling amount is approximately 15 ℓ (4 US gal, 3-3/10 Imp gal) or less. This is because the refuel control (moves the fuel gauge needle quicker than normal judging that the driver is refueling the vehicle) is not performed in such a case.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

MWI

# PRECAUTIONS

< PRECAUTION >

## PRECAUTION

### PRECAUTIONS

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000010990668

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

#### **WARNING:**

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

#### Precautions for Removing Battery Terminal

INFOID:000000011400366

- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.

#### **NOTE:**

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.


#### **NOTE:**

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

#### **NOTE:**

The removal of 12V battery may cause a DTC detection error.





# PREPARATION


< PREPARATION >

## PREPARATION

### PREPARATION

#### Commercial Service Tools

INFOID:0000000010990669

Tool name	Description
Power tool  PBIC0191E	Loosening screws

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

# COMBINATION METER

< REMOVAL AND INSTALLATION >

## REMOVAL AND INSTALLATION

### COMBINATION METER

Exploded View


INFOID:000000010990670

#### REMOVAL

Cluster lid A Assembly

Refer to [IP-12. "Exploded View"](#).


Combination meter



JSNIA0098ZZ

- |                            |                         |                                |
|----------------------------|-------------------------|--------------------------------|
| 1. Cluster lid A           | 2. Meter control switch | 3. Cluster lid A under cover   |
| 4. Bracket (LH)            | 5. Bracket (RH)         | 6. Steering column cover upper |
| 7. Steering column blind   | 8. Blind                | 9. Meter housing               |
| 10. Combination meter stay | 11. Combination meter   | 12. Cluster lid A cover        |

#### DISASSEMBLY



JSNIA0102ZZ

- |                |                               |
|----------------|-------------------------------|
| 1. Front cover | 2. Unified meter control unit |
|----------------|-------------------------------|

#### Removal and Installation


INFOID:000000010990671

#### REMOVAL


# COMBINATION METER

## < REMOVAL AND INSTALLATION >

1. Remove cluster lid A assembly. Refer to [IP-13, "Removal and Installation"](#).
2. Remove screw (A) and remove combination meter stay (1).
3. Remove screws (B) and remove cluster lid A cover (2).



4. Remove screws (A), (B) and remove combination meter (1).
5. Remove meter control switch connector (2) from combination meter (1).



## INSTALLATION

Install in the reverse order of removal.

## Disassembly and Assembly

INFOID:000000010990672

## DISASSEMBLY

Disengage the tabs to separate front cover.

## ASSEMBLY

Assemble in the reverse order of disassembly.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

MWI

O  
P

# UNIFIED METER AND A/C AMP.

< REMOVAL AND INSTALLATION >

## UNIFIED METER AND A/C AMP.


### Exploded View

INFOID:000000010990673

#### REMOVAL

Refer to [IP-12, "Exploded View"](#).

#### DISASSEMBLY



1. Unified meter and A/C amp.
2. Bracket (LH)
3. AV control unit
4. Bracket (RH)

### Removal and Installation

INFOID:000000010990674

#### REMOVAL

1. Remove the display unit. Refer to [AV-108, "Removal and Installation"](#) (BASE AUDIO WITH REAR VIEW CAMERA) or [AV-251, "Removal and Installation"](#) (BOSE AUDIO WITH NAVIGATION).
2. Remove the unified meter and A/C amp and AV control unit as an assembly.
3. Remove the bracket screws and remove the unified meter and A/C amp.

#### INSTALLATION

Install in the reverse order of removal.

#### NOTE:

- Unified meter and A/C amp. screws are different from other screws. Never confuse them when installing.
- Since AV control unit connector and unified meter and A/C amp. connector have the same form, be careful not insert them wrongly.

# METER CONTROL SWITCH

< REMOVAL AND INSTALLATION >

## METER CONTROL SWITCH


### Exploded View

INFOID:000000010990675

#### REMOVAL

Refer to [IP-12, "Exploded View"](#).

#### DISASSEMBLY




- |                          |                         |                                |
|--------------------------|-------------------------|--------------------------------|
| 1. Cluster lid A         | 2. Meter control switch | 3. Cluster lid A under cover   |
| 4. Bracket (LH)          | 5. Bracket (RH)         | 6. Steering column cover upper |
| 7. Steering column blind | 8. Meter housing        |                                |

### Removal and Installation

INFOID:000000010990676

#### REMOVAL

1. Remove combination meter.
2. Remove screws (A) and remove bracket RH (1), LH (2).
3. Remove screws (B) and remove meter control switch.



#### INSTALLATION

Install in the reverse order of removal.

# COMPASS

< REMOVAL AND INSTALLATION >

---

## COMPASS

### Exploded View

INFOID:000000010990677

Refer to [MIR-18. "Exploded View"](#).

### Removal and Installation

INFOID:000000010990678

Refer to [MIR-18. "Removal and Installation"](#).

# CLOCK

< REMOVAL AND INSTALLATION >

## CLOCK


### Exploded View

INFOID:000000010990679

### REMOVAL

Refer to [IP-12. "Exploded View"](#).

### DISASSEMBLY



1. Clock

2. Cluster lid C


3. Preset switch

### Removal and Installation

INFOID:000000010990680

### REMOVAL

1. Remove cluster lid C assembly. Refer to [IP-13. "Removal and Installation"](#).
2. Remove screws (A), (B), (C) and remove clock (2) in conjunction with preset switch (1) from cluster lid C.
3. Disengage the tabs to separate clock.



### INSTALLATION

Install in the reverse order of removal.

#### NOTE:

Never confuse screws when installing.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
MWI  
O  
P