

SECTION **AV**

A
B
C
D
E
F
G
H
I
J
L
M

AUDIO VISUAL, NAVIGATION & TELEPHONE SYSTEM

CONTENTS

| | | | |
|---|----------|--|-----------|
| PRECAUTIONS | 3 | INSTALLATION | 30 |
| Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" | 3 | Removal and Installation for A/C and Audio Controller | 30 |
| Precautions for Battery Service | 3 | REMOVAL | 30 |
| Wiring Diagrams and Trouble Diagnosis | 3 | INSTALLATION | 30 |
| PREPARATION | 4 | Removal and Installation of Door Speaker | 30 |
| Commercial Service Tools | 4 | REMOVAL | 30 |
| AUDIO | 5 | INSTALLATION | 31 |
| System Description | 5 | Removal and Installation of Tweeter Behind Door Mirror | 31 |
| BASE SYSTEM | 5 | REMOVAL | 31 |
| BOSE SYSTEM | 5 | INSTALLATION | 31 |
| SPEED SENSITIVE VOLUME SYSTEM | 6 | Removal and Installation of Rear Side Speaker | 31 |
| Component Parts Location | 7 | REMOVAL | 31 |
| Schematic / Base System | 8 | INSTALLATION | 31 |
| Wiring Diagram – AUDIO – / Base System | 9 | Removal and Installation of Woofer | 31 |
| Schematic / BOSE System | 13 | REMOVAL | 31 |
| Wiring Diagram – AUDIO – / BOSE System | 14 | INSTALLATION | 31 |
| Terminals and Reference Value for Audio Unit for Base System | 19 | Removal and Installation of BOSE Speaker Amp... .. | 32 |
| Terminals and Reference Value for Audio Unit for BOSE System | 20 | REMOVAL | 32 |
| Terminals and Reference Value for BOSE Speaker Amp. | 22 | INSTALLATION | 32 |
| Steering Wheel Audio Control Switch Resistance Check | 23 | AUDIO ANTENNA | 33 |
| Trouble Diagnosis | 23 | System Description | 33 |
| PROBLEM WITH RADIO AND CD | 24 | Wiring Diagram -W/ANT- | 34 |
| FOR RADIO ONLY | 24 | Location of Antenna | 35 |
| FOR CD ONLY | 25 | Window Antenna Repair | 35 |
| Noise Inspection | 25 | ELEMENT CHECK | 35 |
| TYPE OF NOISE AND POSSIBLE CAUSE | 25 | ELEMENT REPAIR | 36 |
| Power Supply Circuit Inspection | 26 | NAVIGATION SYSTEM | 37 |
| Steering Wheel Audio Control Switch Does Not Operate | 27 | System Description | 37 |
| Speed Sensitive Volume System Does Not Work.. | 28 | TRAVEL DISTANCE | 37 |
| Locking CD Auto-Changer Mechanism | 29 | TRAVEL DIRECTION | 37 |
| DAMPER LOCK PROCEDURE | 29 | MAP-MATCHING | 37 |
| Removal and Installation for Audio Unit | 29 | GPS (GLOBAL POSITIONING SYSTEM) | 38 |
| REMOVAL | 29 | COMPONENT DESCRIPTION | 39 |
| | | BIRD VIEW™ | 40 |
| | | MAP DISPLAY | 41 |
| | | FUNCTION OF NAVI SWITCH | 41 |
| | | "VIEW" MODE | 46 |
| | | "HEADING" MODE | 46 |

AV

| | | | |
|---|----|---|-----|
| “NEARBY DISPLAY ICONS” MODE | 47 | RGB Screen Is Rolling | 87 |
| “SAVE CURRENT LOCATION” MODE | 47 | Guide Sound Is Not Heard | 88 |
| “ADJUST CURRENT LOCATION” MODE | 47 | No Fuel Information Is Displayed | 89 |
| “AUTO RE-ROUTE” MODE | 48 | Vehicle Condition Setting Is Not Possible | 89 |
| “AVOID AREA SETTING” MODE | 48 | No Warning Message Is Displayed (Combination Meter Of Warning Lamp Illuminate) | 90 |
| “BUTTON TONE/BEEP RESPONSE” MODE | 48 | The Position Of The Current-Location Mark Is Not Correct | 90 |
| “CLEAR MEMORY” MODE | 48 | Radio Wave From The GPS Satellite Is Not Received | 90 |
| “EDIT ADDRESS BOOK” MODE | 49 | Driving Test | 91 |
| “GPS INFORMATION” MODE | 49 | Example of Symptoms Judged Not Malfunction | 92 |
| “QUICK STOP CUSTOMER SETTING” MODE | 49 | BASIC OPERATION | 92 |
| “SET AVERAGE SPEED” MODE | 49 | VEHICLE MARK | 92 |
| “TRACKING” MODE | 50 | DESTINATION, PASSING POINTS, AND MENU ITEMS CANNOT BE SELECTED/SET | 92 |
| GUIDE VOLUME SETTING | 50 | VOICE GUIDE | 93 |
| TRIP COMPUTER INFORMATION | 50 | ROUTE SEARCHING | 94 |
| FUEL ECONOMY INFORMATION | 50 | EXAMPLES OF CURRENT-LOCATION MARK DISPLACEMENT | 95 |
| MAINTENANCE INFORMATION | 51 | THE CURRENT POSITION MARK SHOWS A POSITION WHICH IS COMPLETELY WRONG | 98 |
| WARNING INDICATIONS | 51 | THE CURRENT POSITION MARK JUMPS | 98 |
| Precautions for NAVI Control Unit Replacement | 52 | THE CURRENT LOCATION MARK IS IN A RIVER OR THE SEA | 99 |
| Component Parts Location | 52 | WHEN DRIVING ON THE SAME ROAD, SOME- TIMES THE CURRENT-LOCATION MARK IS IN THE RIGHT PLACE AND SOMETIMES IT IS THE WRONG PLACE | 99 |
| Schematic | 53 | LOCATION CORRECTION BY MAP MATCHING IS SLOW | 99 |
| Wiring Diagram —NAVI— | 54 | ALTHOUGH THE GPS RECEIVING DISPLAY IS GREEN, THE VEHICLE MARK DOES NOT RETURN TO THE CORRECT LOCATION | 99 |
| Wiring Diagram — COMM— | 59 | THE NAME OF THE CURRENT PLACE IS NOT DISPLAYED | 99 |
| Terminals and Reference Value for NAVI Control Unit | 61 | CONTENTS OF THE DISPLAY DIFFER FOR THE BIRD VIEW™ AND THE (FLAT) MAP SCREEN. | 99 |
| Terminals and Reference Value for Display Unit | 64 | Program Loading | 100 |
| Terminals and Reference Value for NAVI Switch | 66 | Removal and Installation of NAVI Control Unit | 101 |
| Self-Diagnosis Function | 67 | REMOVAL | 101 |
| DESCRIPTION | 67 | INSTALLATION | 101 |
| DIAGNOSIS ITEM | 67 | Removal and Installation of GPS Antenna | 101 |
| Self-Diagnosis Mode | 68 | REMOVAL | 101 |
| OPERATION PROCEDURE | 68 | INSTALLATION | 101 |
| SELF-DIAGNOSIS RESULT | 69 | Removal and Installation of NAVI Switch | 102 |
| CONFIRMATION/ADJUSTMENT Mode | 70 | REMOVAL | 102 |
| OPERATION PROCEDURE | 70 | INSTALLATION | 102 |
| DISPLAY DIAGNOSIS | 71 | Removal and Installation of Display Unit | 102 |
| VEHICLE SIGNALS | 72 | REMOVAL | 102 |
| NAVIGATION | 72 | INSTALLATION | 102 |
| HISTORY OF ERRORS | 73 | | |
| DIAGNOSIS BY HISTORY OF ERRORS | 73 | | |
| Power Supply and Ground Circuit Check for NAVI Control Unit | 76 | | |
| Power Supply and Ground Circuit Check for Display Unit and NAVI Switch | 77 | | |
| Vehicle Speed Signal Check | 78 | | |
| Illumination Signal Check | 79 | | |
| Ignition Signal Check | 79 | | |
| Reverse Signal Check (With A/T) | 80 | | |
| Reverse Signal Check (With M/T) | 80 | | |
| Navigation System Is Not Operated by NAVI Switch | 81 | | |
| Screen Is Not Shown | 82 | | |
| Color of RGB Image Is Not Proper (Bluish) | 84 | | |
| Color of RGB Image Is Not Proper (Reddish) | 85 | | |
| Color of RGB Image Is Not Proper (Yellowish) | 86 | | |

PRECAUTIONS

PRECAUTIONS

PF0:00001

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

AKS004D5

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precautions for Battery Service

AKS00AUS

Before disconnecting the battery, lower both the driver and passenger windows. This will prevent any interference between the window edge and the vehicle when the door is opened/closed. During normal operation, the window slightly raises and lowers automatically to prevent any window to vehicle interference. The automatic window function will not work with the battery disconnected.

Wiring Diagrams and Trouble Diagnosis

AKS003G0

When you read wiring diagrams, refer to the following:

- Refer to [GI-14, "How to Read Wiring Diagrams"](#) .
Refer to [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#) .

When you perform trouble diagnosis, refer to the following:

- Refer to [GI-10, "HOW TO FOLLOW TEST GROUPS IN TROUBLE DIAGNOSES"](#) .
Refer to [GI-26, "How to Perform Efficient Diagnosis for an Electrical Incident"](#) .

A
B
C
D
E
F
G
H
I
J
AV
L
M


PREPARATION

PREPARATION

PFP:00002

Commercial Service Tools

AKS003G1

| Tool name | Description |
|--|--|
| <p data-bbox="140 410 252 436">Power tool</p>  <p data-bbox="837 512 911 532">PBIC0191E</p> | <p data-bbox="997 312 1252 340">Loosening bolts and nuts</p> |

AUDIO

PFP:28111

System Description BASE SYSTEM

AKS003G2

Refer to Owner's Manual for audio system operating instructions.

Power is supplied at all times

- through 15A fuse [No. 37, located in the fuse and fusible link box]
- to audio unit terminal 6.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 6, located in the fuse block (J/B)]
- to audio unit terminal 10.

Ground is supplied through the case of the audio unit.

Audio unit and A/C and audio controller are connected by FPC (Flexible Print Circuit).

A/C and audio controller integrates A/C switches and audio switches.

When A/C and audio controller is pushed to audio switch, it sends audio signal to audio unit. Then audio signals are supplied

- through audio unit terminals 1, 2, 3, and 4
- to terminals 1 and 2 of driver door speaker and passenger door speaker
- to terminals 1 and 2 of tweeter driver side and passenger side
- through audio unit terminals 13, 14, 15, and 16
- to terminals 1 and 2 of rear speaker LH and RH.

When one of steering wheel audio control switches is pushed to volume up, seek up, or mode ON, resistance in steering wheel audio control switch circuit changes depending on which button is pushed. This will change voltage. Power is supplied

- from audio unit terminal 22
- through combination switch (spiral cable) terminals 24 and 20
- to steering wheel audio control switch.

Ground is supplied

- from steering wheel audio control switch
- through combination switch (spiral cable) terminals 17 and 31
- to audio unit terminal 25.

When one of steering wheel audio control switches is pushed to volume down, seek down, or power ON, resistance in steering wheel audio control switch circuit changes depending on which button is pushed. This will change voltage. Power is supplied

- from audio unit terminal 23
- through combination switch (spiral cable) terminals 32 and 16
- to steering wheel audio control switch.

Ground is supplied

- from steering wheel audio control switch
- through combination switch (spiral cable) terminals 17 and 31
- to audio unit terminal 25.

BOSE SYSTEM

Refer to Owner's Manual for audio system operating instructions.

Power is supplied at all times

- through 15A fuse [No. 37, located in the fuse and fusible link box]
- to audio unit terminal 6,
- to BOSE speaker amp. terminal 1.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 6, located in the fuse block (J/B)]
- to audio unit terminal 10.

Ground is supplied through the case of the audio unit.

A
B
C
D
E
F
G
H
I
J
L
M

AV

AUDIO

Ground is also supplied

- to BOSE speaker amp. terminal 17
- through body ground B29 and B5.

Audio unit and A/C and audio controller are connected by FPC (Flexible Print Circuit).

A/C and audio controller integrates A/C switches and audio switches.

When A/C and audio controller is pushed to audio switch, it send audio signal to audio unit.

Then audio signals are supplied

- through audio unit terminals 1, 2, 3, 4, 13, 14, 15, and 16
- to BOSE speaker amp. terminals 23, 24, 25, 26, 27, 28, 29, and 30.

Audio signals are amplified by the BOSE speaker amp.

The amplified audio signals are supplied

- through BOSE speaker amp. terminals 13, 14, 15, and 16
- to terminals 1 and 2 of driver door speaker and passenger door speaker
- to terminals 1 and 2 of tweeter driver side and passenger side
- through BOSE speaker amp. terminals 9, 10, 11, and 12
- to terminals 1 and 2 of rear speaker LH and RH
- through BOSE speaker amp. terminals 2, 3, 18, and 19
- to terminals 1 and 2 of woofer LH and RH.

When one of steering wheel audio control switches is pushed to volume up, seek up, or mode ON, resistance in steering wheel audio control switch circuit changes depending on which button is pushed. This will change voltage. Power is supplied

- from audio unit terminal 22
- through combination switch (spiral cable) terminals 24 and 20
- to steering wheel audio control switch.

Ground is supplied

- from steering wheel audio control switch
- through combination switch (spiral cable) terminals 17 and 31
- to audio unit terminal 25.

When one of steering wheel audio control switches is pushed to volume down, seek down, or power ON, resistance in steering wheel audio control switch circuit changes depending on which button is pushed. This will change voltage. Power is supplied

- from audio unit terminal 23
- through combination switch (spiral cable) terminals 32 and 16
- to steering wheel audio control switch.

Ground is supplied

- from steering wheel audio control switch
- through combination switch (spiral cable) terminals 17 and 31
- to audio unit terminal 25.


SPEED SENSITIVE VOLUME SYSTEM

Volume level of this system gone up and down automatically in proportion to the vehicle speed. And the control level can be selected by the customer. This system is equipped for BOSE system.

AUDIO

Component Parts Location

AKS009BG



A
B
C
D
E
F
G
H
I
J
K
L
M


AV

AUDIO

Schematic / Base System

AKS003G3

(XR) : Except with AT without navigation system and sunroof
 (WN) : With navigation system






TKWM2295E

AUDIO

Wiring Diagram – AUDIO – / Base System

AKS003G4

AV-AUDIO-01



REFER TO THE FOLLOWING.
 (E108) -SUPER MULTIPLE JUNCTION (SMJ)
 (M4) -FUSE BLOCK-JUNCTION BOX (J/B)



*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

A
B
C
D
E
F
G
H
I
J
AV
L
M

AUDIO

AV-AUDIO-02

- WR : WITH A/T WITHOUT NAVIGATION SYSTEM AND SUNROOF
XR : EXCEPT WR
- *1 L : WR *3 BR : WR
 W : XR G : XR
 *2 B/W : WR *4 B/R : WR
 B : XR R : XR




REFER TO THE FOLLOWING.
B1 , D1 , D31
 -SUPER MULTIPLE JUNCTION (SMJ)

TKWM2297E

AUDIO

AV-AUDIO-03



▬ : DATA LINE

(WR) : WITH A/T WITHOUT NAVIGATION SYSTEM AND SUNROOF



(XR) : EXCEPT (WR)

*1 LG : (WR) *3 OR : (WR)

BR : (XR) L : (XR)

*2 B/Y : (WR) *4 B/P : (WR)

Y : (XR) P : (XR)






REFER TO THE FOLLOWING.

(B1), (B401) -SUPER MULTIPLE JUNCTION (SMJ)

A
B
C
D
E
F
G
H
I
J
AV
L
M

AUDIO

AV-AUDIO-04



REFER TO THE FOLLOWING.


(B1) -SUPER MULTIPLE JUNCTION (SMJ)

TKWM2299E

AUDIO

Schematic / BOSE System

AKS00CS4



A
B
C
D
E
F
G
H
I
J
K
L
M

AV





TKWM0834E

AUDIO




Wiring Diagram – AUDIO – / BOSE System

AKS00CS5

AV-AUDIO-05





REFER TO THE FOLLOWING.
 (E108) -SUPER MULTIPLE JUNCTION (SMJ)
 (M4) -FUSE BLOCK-JUNCTION BOX (J/B)



REFER TO THE FOLLOWING.

(B1) -SUPER MULTIPLE JUNCTION (SMJ)






REFER TO THE FOLLOWING.
(B1), (D1), (D31) -SUPER
MULTIPLE JUNCTION (SMJ)

AUDIO

AV-AUDIO-08

A
B
C
D
E
F
G
H
I
J
AV
L
M






REFER TO THE FOLLOWING.
(B1), (B401) -SUPER MULTIPLE JUNCTION (SMJ)

TKWM2303E

AUDIO

AV-AUDIO-09



REFER TO THE FOLLOWING.






(B1) -SUPER MULTIPLE JUNCTION (SMJ)

TKWM2304E

AUDIO

Terminals and Reference Value for Audio Unit for Base System

AKS003G5

| Terminal (Wire color) | | Item | Signal input/ output | Condition | | Reference value | Example of symptom |
|---|---|--------------------------------------|----------------------------|--------------------|--|--|--|
| + | - | | | Ignition switch | Operation | | |
| 2 (L) ^{*1} (W) ^{*2} | 1 (B/W) ^{*1} (B) ^{*2} | Audio sound signal front LH | Output | ON | Receive audio signal |  <p style="text-align: right; font-size: small;">SKIA0177E</p> | No sound from driver door speaker and tweeter driver side. |
| 4 (BR) ^{*1} (G) ^{*2} | 3 (B/R) ^{*1} (R) ^{*2} | Audio sound signal front RH | Output | ON | Receive audio signal |  <p style="text-align: right; font-size: small;">SKIA0177E</p> | No sound from passenger door speaker and tweeter passen- ger side. |
| 5(G/W) ^{*1} (R/W) ^{*2} | Ground | Antenna signal | output | ON | - | Approx. 12V | Receiving status of radio broad- cast becomes bad. |
| 6 (Y) | Ground | Battery power supply | Input | OFF | - | Battery voltage | System does not work properly. |
| 8 (R/L) | Ground | Lighting switch | Input | ON | Lighting switch ON (1st position) | Approx. 12V | Audio unit illum- ination does not function when lighting switch is ON (position 1). |
| | | | | | Lighting switch OFF | Approx. 0V | |
| 9 | - | Shield | - | - | - | - | - |
| 10 (LG) | Ground | ACC power supply | Input | ON | Ignition switch ACC or ON | Battery voltage | System does not work properly. |
| 11 | - | Shield | - | - | - | - | - |
| 14 (LG) ^{*1} (BR) ^{*2} | 13 (B/Y) ^{*1} (Y) ^{*2} | Audio sound signal rear LH | Output | ON | Receive audio signal |  <p style="text-align: right; font-size: small;">SKIA0177E</p> | No sound from rear speaker LH. |
| 16 (OR) ^{*1} (L) ^{*2} | 15 (B/P) ^{*1} (P) ^{*2} | Audio sound signal rear RH | Output | ON | Receive audio signal |  <p style="text-align: right; font-size: small;">SKIA0177E</p> | No sound from rear speaker RH. |
| 18 (W/G) | Ground | Vehicle speed signal (2-pulse) | Input | ON | When vehicle speed is approx. 40km/h (25MPH) |  <p style="text-align: right; font-size: small;">SKIA0168E</p> | Speed sensitive volume system does not work properly. |

A
B
C
D
E
F
G
H
I
J
L
M

AV



AUDIO

| Terminal (Wire color) | | Item | Signal input/ output | Condition | | Reference value | Example of symptom |
|--------------------------|--------|-----------------------------|----------------------------|--------------------|---------------------------|-----------------|--|
| + | - | | | Ignition switch | Operation | | |
| 22 (R) | Ground | Remote control A | Input | ON | Press MODE switch | Approx. 0V | Steering wheel audio controls do not function. |
| | | | | | Press SEEK UP switch | Approx. 1.7V | |
| | | | | | Press VOL UP switch | Approx. 3.3V | |
| | | | | | Except for above | Approx. 5V | |
| 23 (G) | Ground | Remote control B | Input | ON | Press POWER switch | Approx. 0V | Steering wheel audio controls do not function. |
| | | | | | Press SEEK DOWN switch | Approx. 1.7V | |
| | | | | | Press VOL DOWN switch | Approx. 3.3V | |
| | | | | | Except for above | Approx. 5V | |
| 25 (Y) | - | Remote control ground | - | ON | - | - | Steering wheel audio controls do not function. |




- *1: With A/T without navigation system, and sunroof
- *2: Except *1

Terminals and Reference Value for Audio Unit for BOSE System

AKS003G6

| Terminal (Wire color) | | Item | Signal input/ output | Condition | | Reference value | Example of symptom |
|--------------------------|--------|-----------------------------------|----------------------------|--------------------|-----------------------------------|--|--|
| + | - | | | Ignition switch | Operation | | |
| 2 (W) | 1 (B) | Audio sound signal front LH | Output | ON | Receive audio signal |  <p style="text-align: right; font-size: small;">SKIA0177E</p> | No sound from driver door speaker and tweeter driver side. |
| 4 (G) | 3 (R) | Audio sound signal front RH | Output | ON | Receive audio signal |  <p style="text-align: right; font-size: small;">SKIA0177E</p> | No sound from passenger door speaker and tweeter passen- ger side. |
| 5 (G/W) | Ground | Antenna signal | Output | ON | - | Approx. 12V | receiving status of radio broadcast becomes bad. |
| 6 (Y) | Ground | Battery power supply | Input | OFF | - | Battery voltage | System does not work properly. |
| 8 (R/L) | Ground | Lighting switch | Input | ON | Light switch ON (1st position) | Approx. 12V | Audio unit illumi- nation does not function when lighting switch is ON (position 1). |
| | | | | | Lighting switch OFF | Approx. 0V | |

AUDIO

| Terminal (Wire color) | | Item | Signal input/ output | Condition | | Reference value | Example of symptom |
|--------------------------|--------|--------------------------------|----------------------------|--------------------|--|---|---|
| + | - | | | Ignition switch | Operation | | |
| 9 | - | Shield | - | - | - | Approx. 0V | Interference and distortion heard from speakers. |
| 10 (LG) | Ground | ACC power supply | Input | ON | - | Battery voltage | System does not work properly. |
| 11 | - | Shield | - | - | - | Approx. 0V | Interference and distortion heard from speakers. |
| 12 (G/Y) | Ground | Amp. ON signal | Output | ON | - | Approx. 12V | Amp. does not work properly. |
| 14 (BR) | 13 (Y) | Audio sound signal rear LH | Output | ON | Receive audio signal |  SKIA0177E | No sound from rear speaker LH. |
| 16 (L) | 15 (P) | Audio sound signal rear RH | Output | ON | Receive audio signal |  SKIA0177E | No sound from rear speaker RH. |
| 18 (W/G) | Ground | Vehicle speed signal (2-pulse) | Input | ON | When vehicle speed is approx. 40 km/h (25 MPH) |  SKIA0168E | Speed sensitive volume system does not work properly. |
| 22 (R) | Ground | Remote control A | Input | ON | Press MODE switch | Approx. 0V | Steering wheel audio controls do not function. |
| | | | | | Press SEEK UP switch | Approx. 1.7V | |
| | | | | | Press VOL UP switch | Approx. 3.3V | |
| | | | | | Except for above | Approx. 5V | |
| 23 (G) | Ground | Remote control B | Input | ON | Press POWER switch | Approx. 0V | Steering wheel audio controls do not function. |
| | | | | | Press SEEK DOWN switch | Approx. 1.7V | |
| | | | | | Press VOL DOWN switch | Approx. 3.3V | |
| | | | | | Except for above | Approx. 5V | |
| 25 (Y) | - | Remote control ground | - | ON | - | - | Steering wheel audio controls do not function. |







A
B
C
D
E
F
G
H
I
J
AV
L
M

AV





AUDIO

Terminals and Reference Value for BOSE Speaker Amp.

AKS003G7

| Terminal (Wire color) | | Item | Signal input/ output | Condition | | Reference value | Example of symptom |
|--------------------------|----------|---|----------------------------|--------------------|----------------------|---|--|
| + | - | | | Ignition switch | Operation | | |
| 1 (Y/R) | Ground | Battery power supply | Input | OFF | - | Battery voltage | System does not work properly. |
| 9 (G/Y) | 10 (B/Y) | Rear speaker LH | Output | ON | Receive audio signal |  SKIA0177E | No sound from rear speaker LH. |
| 11 (R/L) | 12 (B) | Rear speaker RH | Output | ON | Receive audio signal |  SKIA0177E | No sound from rear speaker RH. |
| 13 (G) | 14 (R) | Driver door speaker and tweeter driver side | Output | ON | Receive audio signal |  SKIA0177E | No sound from driver door speaker and tweeter driver side. |
| 15 (GY) | 16 (Y) | Passenger door speaker and tweeter passenger side | Output | ON | Receive audio signal |  SKIA0177E | No sound from passenger door speaker and tweeter passenger side. |
| 17 (B/R) | Ground | Ground | - | ON | - | - | - |
| 18 (L/Y) | 2 (W/G) | Woofer LH | Output | ON | Receive audio signal |  SKIA0177E | No sound from woofer LH. |
| 19 (L/R) | 3 (L/W) | Woofer RH | Output | ON | Receive audio signal |  SKIA0177E | No sound from woofer RH. |

AUDIO


| Terminal (Wire color) | | Item | Signal input/ output | Condition | | Reference value | Example of symptom |
|--------------------------|----------|---|----------------------------|--------------------|-------------------------|---|--|
| + | - | | | Ignition switch | Operation | | |
| 24 (L) | 23 (P) | Audio sound signal rear RH | Input | ON | Receive audio signal |  SKIA0177E | No sound from rear speaker RH. |
| 26 (LG) | 25 (PU) | Audio sound signal rear LH | Input | ON | Receive audio signal |  SKIA0177E | No sound from rear speaker LH. |
| 28 (OR/L) | 27 (W/L) | Audio sound signal passen- ger door | Input | ON | Receive audio signal |  SKIA0177E | No sound from passenger door speaker and tweeter passen- ger side. |
| 30 (W) | 29 (OR) | Audio sound signal driver door | Input | ON | Receive audio signal |  SKIA0177E | No sound from driver door speaker and tweeter driver side. |
| 31 (SB) | Ground | Control (SWB+) | Input | ON | - | Approx. 12V | System does not work properly. |

A
B
C
D
E
F
G
H
I
J
AV

Steering Wheel Audio Control Switch Resistance Check

AKS003GB

| Terminal (Wire color) | | Signal name | Condition | Resistance (Ω) |
|-----------------------------|------------|----------------------|--------------------------------|----------------------------|
| 16 (L) | 17 (BR) | Power | Depress power switch. | Approx. 0 |
| | | Seek down (previous) | Depress (station) down switch. | Approx. 165 |
| | | Volume (down) | Depress volume down switch. | Approx. 652 |
| 20 (W) | 17 (BR) | Mode | Depress mode switch. | Approx. 0 |
| | | Seek up (next) | Depress (station) up switch. | Approx. 165 |
| | | Volume (up) | Depress volume up switch. | Approx. 652 |



L
M

Trouble Diagnosis

AKS003GA

The majority of the audio troubles are the result of outside causes (bad CD/cassette, electromagnetic interference, etc.). Check the inspection items below to diagnose the malfunction.

AUDIO

PROBLEM WITH RADIO AND CD

| Symptom | Check items | Possible cause |
|-------------|---|---|
| Inoperative | <ul style="list-style-type: none"> ● Check that the ignition switch is in the ACC position. | <ul style="list-style-type: none"> ● Audio unit ● Audio unit power circuit Refer to AV-26, "Power Supply Circuit Inspection" . |
| No sound | <ul style="list-style-type: none"> ● Check that the volume is not turned down. ● Check that the balance and fader control knobs are centered. | <ul style="list-style-type: none"> ● Audio unit ● Audio unit power circuit Refer to AV-26, "Power Supply Circuit Inspection" . ● Speaker ● BOSE speaker amp. (BOSE system) ● Sound signal circuit between speaker and Audio unit (Base system) ● Sound signal circuit between speaker and BOSE speaker amp. (BOSE system) |
| Poor sound | <ul style="list-style-type: none"> ● Check that the bass and treble adjustment knobs are centered. | <ul style="list-style-type: none"> ● Audio unit ● BOSE speaker amp. (BOSE system) ● Speaker |
| Noisy | – | <ul style="list-style-type: none"> ● Audio unit ● BOSE speaker amp. (BOSE system) ● Each electrical equipment |

FOR RADIO ONLY

| Symptom | Check items | Possible cause |
|--|--|--|
| No sound | <ul style="list-style-type: none"> ● Check that the radio is tuned to a station's frequency. | <ul style="list-style-type: none"> ● Audio unit ● Antenna feeder ● Antenna amplifier ● Window antenna |
| Noisy | <ul style="list-style-type: none"> ● Check that the radio is tuned to a station's frequency. ● Check that the signal of the received station is not weak. ● Check that no mirror-type window film nor any metal object (after-market antenna, etc.) is attached on the rear window glass (Note 1). ● Check whether or not the malfunction occurs only in a particular area. (Note 2) | <ul style="list-style-type: none"> ● Audio unit ● Antenna feeder ● Antenna amplifier ● window antenna ● Noise prevention parts ● Each electrical equipment ● Wire harness of each piece of electrical equipment |
| Selected radio stations stored in memory are deleted | – | <ul style="list-style-type: none"> ● Audio unit |

NOTE:

1. The cause is a reduction in the receiving sensitivity of the window antenna.
2. This is noise resulting from variations in field strength, such as fading noise and multi-path noise, or external noise from trains and other sources. It is not a malfunction.
 - Fading noise: This noise occurs because of variations in the field strength in a narrow range due to mountains or buildings blocking the signal.
 - Multi-path noise: This noise results from the waves sent directly from the broadcast station arriving at the antenna at a different time from the waves which reflect off of mountains or buildings.

AUDIO

FOR CD ONLY

| Symptom | Check items | Possible cause |
|---|--|----------------|
| CD cannot be inserted. | Check that a CD is not already inserted. | ● Audio unit |
| CD cannot be ejected. | — | |
| The CD cannot be played. | <ul style="list-style-type: none"> ● Check that the CD is not upside down. ● Check that there is no dirt, damage, or water on the disc. | Audio unit |
| The sound skips, stops suddenly, or is distorted. | <ul style="list-style-type: none"> ● Check that there is no dirt, damage, or water on the disc. ● Check that the trouble is not due to strong vibration. | |

Noise Inspection

AKS003GB

The vehicle itself can be a source of noise if noise prevention parts or electrical equipment is malfunction. Check if noise is caused and/or changed by engine rotation, ignition switch turned to each position, and operation of each piece of electrical equipment, and determine the cause.

NOTE:

The source of the noise can be found easily by listening to the noise while removing the fuses of electrical components, one by one.

TYPE OF NOISE AND POSSIBLE CAUSE

| Occurrence condition | | Possible cause |
|---|---|--|
| Occurs only when engine is ON. | A continuous growling noise occurs. The speed of the noise varies with changes in the engine speed. | ● Problem with the ignition condenser. |
| | A whistling noise occurs while the engine speed is high. A booming noise occurs while the engine is running and the light switch is ON. | ● Problem with the alternator |
| The occurrence of the noise is linked with the operation of the fuel pump. | | ● Problem with the fuel pump condenser |
| Noise only occurs when various electrical components are operating. | A cracking or snapping sound occurs with the operation of various switches. | ● Relay malfunction, radio malfunction |
| | The noise occurs when various motors are operating. | <ul style="list-style-type: none"> ● Problem with the motor case ground ● Problem with the motor |
| The noise occurs constantly, not just under certain conditions. | | <ul style="list-style-type: none"> ● Rear defogger coil malfunction ● Open circuit in printed heater ● Poor ground of antenna amplifier or antenna feeder line ● Mirror type film is attached on the rear window glass ● After-market TV antenna and/or electrical accessories such as radio are attached on the rear window glass. |
| A cracking or snapping sound occurs while the vehicle is being driven, especially when it is vibrating excessively. | | <ul style="list-style-type: none"> ● Problem with the ground wire of body parts. ● Problem with ground due to part installation problem ● Problem with wiring connections or a short circuit |

AUDIO

AKS003GC

Power Supply Circuit Inspection

1. CHECK FUSE

Check that the following fuses of the BOSE speaker amp. and audio unit are not blown.

| Unit | Terminals | | Signal name | Fuse No. |
|-------------------|-----------|-----------------------|---------------------------|----------|
| | (+) | | | |
| | Connector | Terminal (Wire color) | | |
| Audio unit | M40 | 6 (Y) | Battery power | 37 |
| | | 10 (LG) | Ignition switch ACC or ON | 6 |
| BOSE speaker amp. | B123 | 1 (Y/R) | Battery power | 37 |

OK or NG


OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of problem before installing new fuse. Refer to [PG-4](#), "[POWER SUPPLY ROUTING CIRCUIT](#)".

2. POWER SUPPLY CIRCUIT CHECK


1. Check voltage between the audio unit harness connector and ground.

| Unit | Terminal No. | | | OFF | ACC |
|------------|--------------|-----------------------|--------|-----------------|-----------------|
| | (+) | | | | |
| | Connector | Terminal (Wire color) | (-) | | |
| Audio unit | M40 | 6 (Y) | Ground | Battery voltage | Battery voltage |
| | | 10 (LG) | Ground | 0 V | Battery voltage |



2. Check voltage between BOSE speaker amp. harness connector and ground.

| Unit | Terminal No. | | | OFF | ACC |
|-------------------|--------------|-----------------------|--------|-----------------|-----------------|
| | (+) | | | | |
| | Connector | Terminal (Wire color) | (-) | | |
| BOSE speaker amp. | B123 | 1 (Y/R) | Ground | Battery voltage | Battery voltage |



OK or NG

OK >> ● Inspection end. (Base system)

● GO TO 3. (BOSE system)

NG >> Repair harness or connector.

AUDIO


3. GROUND CIRCUIT CHECK

1. Turn ignition switch OFF.
2. Disconnect BOSE speaker amp. connector.
3. Check continuity between BOSE speaker amp. harness connector B123 terminal 17 (B/R) and ground.

Continuity should exist.

OK or NG

- OK >> Inspection end.
 NG >> Repair harness or connector.



Steering Wheel Audio Control Switch Does Not Operate

AKS003GE

1. STEERING WHEEL AUDIO CONTROL SWITCH RESISTANCE CHECK

1. Turn ignition switch OFF.
2. Disconnect steering wheel audio control switch connector.
3. Check resistance steering wheel audio control switch. Refer to [AV-23, "Steering Wheel Audio Control Switch Resistance Check"](#).

Resistance value is OK?


YES or NO

- YES >> GO TO 2.
 NO >> Replace steering wheel audio control switch.

2. STEERING WHEEL AUDIO CONTROL SWITCH CIRCUIT CHECK

1. Disconnect audio unit connector.
2. Check continuity between audio unit harness connector M39 and combination switch (spiral cable) harness connector M23.

| Terminals | | | | Continuity |
|-----------|-----------------------|-----------|-----------------------|------------|
| Connector | Terminal (Wire color) | Connector | Terminal (wire color) | |
| M39 | 22 (R) | M23 | 24 (R) | Yes |
| | 23 (G) | | 32 (G) | |
| | 25 (Y) | | 31 (Y) | |



OK or NG

- OK >> GO TO 3.
 NG >> Repair harness or connector.


3. AUDIO UNIT CHECK

1. Connect audio unit connector.
2. Turn ignition switch ON.
3. Check voltage between audio unit harness connector M39 terminal 22 (R), 23 (G) and ground.

22 (R) - Ground : Approx. 5V
23 (G) - Ground : Approx. 5V

OK or NG

- OK >> Replace combination switch (spiral cable).
 NG >> Replace audio unit.



Speed Sensitive Volume System Does Not Work

1. VEHICLE SPEED OPERATION CHECK

Does speedometer is operated normally?

YES or NO

YES >> GO TO 2.

NO >> Check combination meter trouble diagnosis. Refer to [DI-13, "Vehicle Speed Signal Inspection"](#) in "COMBINATION METERS".


2. HARNESS CHECK

1. Turn ignition switch OFF.
2. Disconnect audio unit connector and combination meter connector.
3. Check continuity between audio unit harness connector M39 terminal 18 (W/G) and combination meter harness connector M19 terminal 14 (W/G).

Continuity should exist.

4. Check continuity between audio unit harness connector M39 terminal 18 (W/G) and ground.

Continuity should not exist.



OK or NG

OK >> GO TO 3.

- NG >> ● Check connector housings for disconnected or loose terminals.
- Repair harness or connector.

3. VEHICLE SPEED SIGNAL CHECK


1. Connect audio unit connector and combination meter connector.
2. Start engine and drive vehicle at more than 40 km/h (25MPH).
3. Check the signal between audio unit harness connector M39 terminal 18 (W/G) and ground with CONSULT-II or oscilloscope.

18 (W/G) – Ground : Refer to [AV-20, "Terminals and Reference Value for Audio Unit for BOSE System"](#) .

OK or NG

OK >> Replace audio unit.

- NG >> Check combination meter system. Refer to [DI-11, "PRE-LIMINARY CHECK"](#) in "COMBINATION METERS".



Locking CD Auto-Changer Mechanism

AKS003ZF

CAUTION:

- Prior to removing a malfunctioning CD auto-changer unit that will be shipped for repair, the changer mechanism **MUST BE LOCKED** to prevent the mechanism from being damaged during shipping.
- If a CD is jammed or unable to be removed from the unit, do **NOT** lock the changer mechanism. If the unit is to be shipped for repair, carefully package the unit to prevent vibration and shock.

DAMPER LOCK PROCEDURE

1. Eject and remove any CDs from the CD auto-changer unit.
2. Turn ignition switch OFF. Wait until CD auto-changer unit display is off and mechanism stops moving (mechanism sound stops).
3. Press any one of the disc selection buttons once. When a display shows on the CD auto-changer unit, press the same disc selection button again within 5 seconds.
 - The changer mechanism will lock itself within 10 seconds.
4. After mechanism stops moving (mechanism sound stops), open the driver and passenger window, and then disconnect negative battery cable.

CAUTION:

After the battery cables are disconnected, do not open/close the driver and/or front passenger door with the window in the full up position. The automatic window adjusting function will not work and the side roof panel may be damaged.

NOTE:


After installing a new or remanufactured CD auto-changer unit, switching the CD auto-changer unit ON will automatically unlock the mechanism. A special unlocking procedure is not required.

Removal and Installation for Audio Unit


AKS003GG

REMOVAL

1. Perform damper lock operation. Refer to [AV-29, "Locking CD Auto-Changer Mechanism"](#).
2. Remove cluster lid C. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#).
3. Unlock FPC (Flexible Print Circuit) connector lock on A/C and audio controller side.
4. Pull off flexible printed circuit from connector.




5. Remove screws (8). Remove audio unit and display unit assembly (with navigation system) from cluster lid C.



AUDIO


6. Separate audio unit from display unit assembly (with navigation system).



7. Remove 8 screws, and then bracket.

CAUTION:

- Be careful not to allow foreign material to enter from CD slot.



INSTALLATION


Installation is the reverse order of removal.

Removal and Installation for A/C and Audio Controller

AKS003GH

REMOVAL

1. Remove audio unit and display unit assembly (with navigation system) from cluster lid C.
2. Remove NAVI switch. Refer to [AV-102, "Removal and Installation of NAVI Switch"](#).
3. Remove screws (5) and remove A/C and audio controller.



INSTALLATION


Installation is the reverse order of removal.

Removal and Installation of Door Speaker

AKS003GJ

REMOVAL

1. Remove door finisher. Refer to [EI-29, "DOOR FINISHER"](#)
2. Remove bolts (3), and remove speaker.



AUDIO

INSTALLATION


Installation is the reverse order of removal.

Removal and Installation of Tweeter Behind Door Mirror

AKS003GL

REMOVAL

1. Remove corner cover inner. Refer to [EI-31, "BODY SIDE TRIM"](#).
2. Remove screws (2), and remove tweeter behind door mirror.



INSTALLATION


Installation is the reverse order of removal.

Removal and Installation of Rear Side Speaker

AKS003ZG

REMOVAL

1. Remove rear side finisher. Refer to [EI-31, "BODY SIDE TRIM"](#).
2. Remove screws (3) and remove speaker.



INSTALLATION


Installation is the reverse order of removal.

Removal and Installation of Woofer

AKS003GM

REMOVAL

1. Remove rear parcel shelf finisher. Refer to [EI-33, "REAR PARCEL SHELF FINISHER"](#).
2. Remove screws (4), and remove woofer.



INSTALLATION

Installation is the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
AV
L
M


AUDIO

Removal and Installation of BOSE Speaker Amp.


AKS003GN

REMOVAL

1. Remove luggage floor carpet and spare tire cover. Refer to [EI-38, "Removal and Installation for Trunk Room Trim"](#).
2. Remove trunk side box. Refer to [EI-38, "Removal and Installation for Trunk Room Trim"](#).
3. Remove nuts (3), and remove BOSE speaker amp. from trunk room floor.



4. Remove bolts (4), and remove bracket.



INSTALLATION

Installation is the reverse order of removal.

AUDIO ANTENNA

AUDIO ANTENNA

PFP:28200

System Description

AKS003G0

With the ignition switch in ACC or ON, power is supplied

- through 10A fuse [No. 6, located in the fuse block (J/B)]
- to audio unit terminal 10.

Ground is supplied through the case of the antenna amp.

When the radio switch is turned ON, antenna signal is supplied

- through audio unit terminal 5
- to the antenna amp. terminal 2.

Then the antenna amp. is activated.

The amplified radio signals are supplied to the audio unit through the antenna amp.

A

B

C

D

E

F

G

H

I

J

AV

L



M

AUDIO ANTENNA

Wiring Diagram -W/ANT-

AKS003GP

AV-W/ANT-01



REFER TO THE FOLLOWING.

(M4) -FUSE BLOCK-JUNCTION BOX (J/B)


*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

TKWM2305E

AUDIO ANTENNA

Location of Antenna

AKS003GQ




PKIB5080E

Window Antenna Repair ELEMENT CHECK


AKS003GR

1. Attach probe circuit tester (ohm setting) to antenna terminal on each side.



SEL250I

- When measuring continuity, wrap tin foil around the top of probe. Then, press the foil against the wire with your finger.




SEL122R


A
B
C
D
E
F
G
H
I
J
AV
L
M

AUDIO ANTENNA

2. If an element is broken, no continuity will exist.



3. To locate a break, move probe along element. Tester needle will swing abruptly when probe passes the broken point.



ELEMENT REPAIR

Refer to [GW-80, "Filament Repair"](#) .

NAVIGATION SYSTEM


PFP:25915

System Description

AKS003GS


The navigation system periodically calculates the vehicle's current position according to the following three signals: Travel distance of the vehicle as determined by the vehicle speed sensor, turning angle of the vehicle as determined by the gyroscope (angular velocity sensor), and the direction of vehicle travel as determined by the GPS antenna (GPS information).

The current position of the vehicle is then identified by comparing the calculated vehicle position with map data read from the map DVD-ROM, which is stored in the DVD-ROM drive (map-matching), and indicated on the screen with a current-location mark.



By comparing the vehicle position detection results found by the GPS and by map-matching, more accurate vehicle position data can be used.

The current vehicle position will be calculated by detecting the distance the vehicle moved from the previous calculation point and its direction.



TRAVEL DISTANCE

Travel distance calculations are based on the vehicle speed sensor input signal. Therefore, the calculation may become incorrect as the tires wear down. To prevent this, an automatic distance fine adjustment function has been adopted.

TRAVEL DIRECTION

Change in the travel direction of the vehicle is calculated by a gyroscope (angular velocity sensor) and a GPS antenna (GPS information). As the gyroscope and GPS antenna have both merit and demerit, input signals from them are prioritized in each situation. However, this order of priority may change in accordance with more detailed travel conditions so that the travel direction is detected more accurately.

| Type | Advantage | Disadvantage |
|-------------------------------------|--|---|
| Gyroscope (angular velocity sensor) | <ul style="list-style-type: none"> Can detect the vehicle's turning angle quite accurately. | <ul style="list-style-type: none"> Direction errors may accumulate when the vehicle is driven for long distances without stopping. |
| GPS antenna (GPS information) | <ul style="list-style-type: none"> Can detect the vehicle's travel direction (North/South/East/West). | <ul style="list-style-type: none"> Correct direction cannot be detected when the vehicle speed is low. |


MAP-MATCHING

Map-matching is a function that repositions the vehicle on the road map when a new location is judged to be the most accurate. This is done by comparing the current vehicle position, calculated by the method described in the position detection principle, with the road map data around the vehicle, read from the map DVD-ROM stored in the DVD-ROM drive.

Therefore, the vehicle position may not be corrected after the vehicle is driven over a certain distance or time in which GPS information is hard to receive. In this case, the current-location mark on the display must be corrected manually.

CAUTION:

The road map data is based on data stored in the map DVD-ROM.




NAVIGATION SYSTEM

- In map-matching, alternative routes to reach the destination will be shown and prioritized, after the road on which the vehicle is currently driven has been judged and the current-location mark has been repositioned.

If there is an error in distance and/or direction, the alternative routes will be shown in different order of priority, and the wrong road can be avoided.


If two roads are running in parallel, they are of the same priority. Therefore, the current-location mark may appear on either of them alternately, depending on maneuvering of the steering wheel and configuration of the road.



- Map-matching does not function correctly when the road on which the vehicle is driving is new and not recorded in the map DVD-ROM, or when the road pattern stored in the map data and the actual road pattern are different due to repair.

When driving on a road not present in the map, the map-matching function may find another road and position the current-location mark on it. Then, when the correct road is detected, the current-location mark may leap to it.

- Effective range for comparing the vehicle position and travel direction calculated by the distance and direction with the road data read from the map DVD-ROM is limited. Therefore, when there is an excessive gap between the current vehicle position and the position on the map, correction by map-matching is not possible.




GPS (GLOBAL POSITIONING SYSTEM)

GPS (Global Positioning System) has been developed and controlled by the US Department of Defense. The system utilizes GPS satellite (NAVSTAR), sending out radio waves while flying on an orbit around the earth at the height of approx. 21,000 km (13,000 miles).

The GPS receiver calculates the vehicle's position in three dimensions (latitude/longitude/altitude) according to the time lag of the radio waves received from four or more GPS satellites (three-dimensional positioning). If radio waves were received only from three GPS satellites, the GPS receiver calculates the vehicle's position in two dimensions (latitude/longitude), utilizing the altitude data calculated previously by using radio waves from four or more GPS satellites (two-dimensional positioning).

Accuracy of the GPS will deteriorate under the following conditions.

- In two-dimensional positioning, the GPS accuracy will deteriorate when the altitude of the vehicle position changes.
- There may be an error of approximately 10m (30ft) in position detected by three-dimensional positioning, which is more accurate than two-dimensional positioning. The accuracy can be even lower depending on the arrangement of the GPS satellites utilized for the positioning.
- Position detection is not possible when the vehicle is in an area where radio waves from the GPS satellite do not reach, such as in a tunnel, parking lot in a building, and under an elevated highway. Radio waves from the GPS satellites may not be received when some object is located over the GPS antenna.
- Position correction by GPS is not available while the vehicle is stopped.




NAVIGATION SYSTEM

COMPONENT DESCRIPTION


NAVI Control Unit

- The gyro (angular speed sensor) and the DVD-ROM drive are built-in units that control the navigation functions.
- Signals are received from the gyro, the vehicle speed sensor, and the GPS antenna. Vehicle location is determined by combining this data with the data contained in the DVD-ROM map. Locational information is shown on LCD (liquid crystal display) screen.



DVD-ROM Drive

Maps, traffic control regulations, and other pertinent information can be easily read from the DVD-ROM disc.



Map DVD-ROM

- The map DVD-ROM has maps, traffic control regulations, and other pertinent information.
- To improve DVD-ROM map matching and route determination functions, the DVD-ROM uses an exclusive Nissan format. Therefore, the use of a DVD-ROM provided by other manufacturers cannot be used.

Gyro (Angular Speed Sensor)

- The oscillator gyro sensor is used to detect changes in vehicle steering angle.
- The gyro is built into the NAVI control unit.

A
B
C
D
E
F
G
H
I
J
L
M


AV

NAVIGATION SYSTEM


BIRD VIEW™

The BIRD VIEW™ provides a detailed and easily seen display of road conditions covering the vehicle's immediate to distant area.

- MAP DISPLAY




- BIRD VIEW™



Description

- Display area: Trapezoidal representation showing approximate distances (W_n , D , and W_d).
- Ten horizontal grid lines indicate display width while six vertical grid lines indicate display depth and direction.
- Drawing line area shows open space, depth, and immediate front area. Each area is to a scale of approximately 5:6:25.
- Pushing the "ZOOM IN" button during operation displays the scale change and the view point height on the left side of the screen.
The height of the view point increases or decreases when "ZOOM" or "WIDE" is selected with the joystick.




NAVIGATION SYSTEM

MAP DISPLAY

Function of each icon is as follows:



1. Azimuth indication
2. Position marker
 - The tip of the arrow shows the current position. The shaft of the arrow indicates the direction in which the vehicle is traveling.
3. GPS reception signal (indicates current reception conditions.)
4. Distance display (shows the distance in a reduced scale.)



FUNCTION OF NAVI SWITCH

Display with Pushed "DEST" Switch

- Easy Mode
- Expert Mode



A
B
C
D
E
F
G
H
I
J
AV
L
M


NAVIGATION SYSTEM

The function of each icon is as follows:


| Icon | MODE | | Description |
|-------------------------|------|--------|---|
| | Easy | Expert | |
| Address Book | | × | Favorite place can be saved to memory. |
| Street Address | × | × | The destination can be searched from the address. |
| Point of Interest (POI) | × | × | The destination of favorite facility can be searched. |
| Previous Dest. | | × | The previous ten destinations stored in memory are displayed. |
| Intersection | | × | The destination can be searched from the intersection. |
| City | | × | The destination can be searched from city name. |
| Map | | × | The destination can be searched from the map. |
| Phone Number | | × | When two or more countries are included in one DVD-ROM, the destination can be searched for under the country name. |
| Home | × | | Sets the home as a destination. |
| Help | × | | Explanation of Navigational functions appear on the Display. |

Display with Pushed "ROUTE" Switch

- Easy Mode



- Expert Mode



NAVIGATION SYSTEM


The function of each icon is as follows:

| Icon | MODE | | Description |
|--------------|------|--------|---|
| | Easy | Expert | |
| Quick Stop | × | × | The selected facility is set as the destination or way point. (Route guidance has been turned OFF or the destination has been reached) |
| Where am I? | × | × | Next, current and previous street names can be displayed. |
| Route Info.* | | × | The following items can be set. <ul style="list-style-type: none"> ● Complete Route ● Turn List ● Route Simulation (Displayed only when the destination area has been set.) |
| Edit Route* | | × | Change the destination or add the transit points of the route set in the route guide. (Displayed only when the automatic reroute function has been turned OFF and the recommended route is not followed.) |
| Help | × | | Explanation of Navigational functions appear on the Display. |

*: When destinations have been entered, route guidance has been turned OFF or destination has been reached, "Route Info." and "Edit Route" are not displayed.

Display with Pushed "SETTING" Switch

The function of each icon is as follows:



| Icon | Description |
|-----------------------|---|
| Clock | Settings of clock can be performed |
| Display | Settings of display can be performed. |
| Language/Unit | Settings of Language or unit can be performed. |
| Navigation | Settings and adjusting of navigation can be performed. |
| Short Menus | Easy Mode and Expert Easy Mode can be switched. |
| Guidance Volume | The volume and/or on/off of voice prompt can be controlled by the joystick. |
| Help (only easy mode) | Explanation of Navigational Functions Appear on the Display. |

NAVIGATION SYSTEM

Display with Pushed "INFO" Switch


NAVI control unit is communicating combination meter.

1. Push "INFO" switch to display vehicle information display.

NOTE:

If a warning signal is received by NAVI at this time, NAVI control unit displays warning message on screen.

2. Select "Trip Computer", "Fuel Economy" or "Maintenance".




| Display items | Display/Setting contents | | Reference page |
|---|----------------------------|--|--|
| Trip Computer | Elapsed Time | Displays driving time with a range of 0000:00:00 to 9999:59:59. | AV-50. "TRIP COMPUTER INFORMATION" |
| | Driving Distance | Displays driving distance with a range of 00000.0 to 99999.9. | |
| | Average speed | Displays average speed with a range of 000.0 to 999.9. | |
| Fuel Economy | Average Fuel Economy (MPG) | Displays fuel economy with ignition switch ON, average fuel economy each 30 minutes. | AV-50. "FUEL ECONOMY INFORMATION" |
| | Distance to Empty (Miles) | Displays possible driving distance with remaining fuel. | |
| | Fuel Economy (MPG) | Displays fuel economy each approx. 100 ms. | |
| | Fuel Economy Record | Displays Average Fuel Consumption History. | |
| Maintenance (with Maintenance information*) | Engine oil | Maintenance intervals of engine oil and setting of oil change cycle. | AV-51. "MAINTENANCE INFORMATION" |
| | Oil Filter | Maintenance intervals of oil filter and setting of filter replacement cycle. | |

*: Maintenance information displays the change cycle of engine oil and oil filter on LCD monitor depending on the driving distance specified by a driver or a technician.

Clock Setting

How To Perform Navigation Setting

1. Start the engine.
2. Push "SETTING" switch.
3. Select "CLOCK".
 - GPS time can be changed to offset time.
 - Daylight Savings Time can be set.
 - Time zone can be set.




NAVIGATION SYSTEM

Display Setting

How To Perform Navigation Setting


1. Start the engine.
2. Push "SETTING" switch.
3. Select "Display".
 - Brightness, contrast, or map background setting can be changed.
 - Display sleep mode ON/OFF can be switched.
 - Display sleep mode timer can be set.



Language Setting

How To Perform Navigation Setting


1. Start the engine.
2. Push "SETTING" switch.
3. Select "Language".
 - Language setting can be switched.
 - Unit setting can be changed.



Navigation Setting

How To Perform Navigation Setting

1. Start the engine.
2. Push "SETTING" switch.
3. Select "Navigation".



A
B
C
D
E
F
G
H
I
J
AV
L
M

NAVIGATION SYSTEM


Application Items

| Icon | Description | Reference page |
|--|--|-----------------------|
| View | Map display mode can be switched. | AV-46 |
| Heading | Heading of the map display can be customized for either north heading or the actual driving direction of the vehicle. | AV-46 |
| Nearby Display Icons | Icons of facilities can be displayed. Facilities to be displayed can be selected from the variety selections. | AV-47 |
| Save Current Location | Current vehicle location can be registered in Address Book. | AV-47 |
| Adjust Current Location | Current location of position marker can be adjusted. Direction of position marker also can be calibrated when heading direction of the vehicle on the display is not matched with the actual direction. | AV-47 |
| Auto Re-route ON/OFF | ON/OFF of Auto Re-route can be switched. | AV-48 |
| Avoid Area Setting | A particular area can be avoided when routing. | AV-48 |
| Button Tone/Beep Response | Button tone can be selected ON/OFF | AV-48 |
| Clear Memory | Address Book, Previous destination or Avoid area can be deleted. | AV-48 |
| Edit Address Book | Address Book can be edited. | AV-49 |
| GPS Information | The GPS data includes longitude, latitude and altitude (distance above sea level) of the present vehicle position, and current date and time for the area in which the vehicle is being driven. Also indicated are the GPS reception conditions and the GPS satellite position. | AV-49 |
| Quick Stop Customer Setting | One facility of your selection can be added to your Quick Stop. | AV-49 |
| Set Average speed for Estimated Journey Time | Average vehicle speed can be set to calibrate estimated journey time for the destination. | AV-49 |
| Tracking On/Off | Tracking to the present vehicle position can be displayed. | AV-50 |

“VIEW” MODE


Select “Bird view” or “Plan view” icon.

- To open the map screen display with Bird View, select “Bird View”.
- To open the map screen display with Plan View, select “Plan View”.



“HEADING” MODE


- To display North up, select “North up”.
- To display the car heading up, select “Heading up”.



NAVIGATION SYSTEM

“NEARBY DISPLAY ICONS” MODE

Select an icon to display on the map screen.




A
B
C
D

“SAVE CURRENT LOCATION” MODE

The current vehicle location can be registered in “Address Book”.

NOTE:


“Address Book” can store 50 items max.



E
F
G
H


“ADJUST CURRENT LOCATION” MODE

1. Select an icon “right” or “left” to calibrate the heading direction. (Arrow marks will rotate corresponding to the calibration key.)



I
J
AV
L

2. Select “Set”. Then the vehicle mark will be matched to the arrow mark.




M

NAVIGATION SYSTEM


“AUTO RE-ROUTE” MODE

- To perform the auto re-route of route, select “On”.
- Not to perform the auto re-route of route, select “Off”.




“AVOID AREA SETTING” MODE

Areas to avoid can be registered.




“BUTTON TONE/BEEP RESPONSE” MODE

- If beep is required, select “On”.
- If no beep is required, select “Off”.



“CLEAR MEMORY” MODE


To delete all the stored places in “Address Book”, “Avoid Area” and “Previous Dest”, select “Yes”.



NAVIGATION SYSTEM

“EDIT ADDRESS BOOK” MODE

Edit the items registered in Address Book.




A
B
C
D

“GPS INFORMATION” MODE

Latitude, longitude, altitude, astronomic state, and satellite location are displayed as GPS information.

NOTE:


Altitude is displayed only in three-dimensional status.



E
F
G
H

“QUICK STOP CUSTOMER SETTING” MODE


Select a category for the “Quick Stop” menu.



I
J
AV
L

“SET AVERAGE SPEED” MODE

- Set the average vehicle speed to calibrate the estimated journey time for the destination.
- Set three items; “Freeway”, “Main Roads”, and “Ordinary Roads”.



M


NAVIGATION SYSTEM

“TRACKING” MODE

- To leave no trail on the map, select “Off”.
- To leave a trail in the map, select “On”.

NOTE:


When a trail display is turned OFF, trail data is erased from the memory.



GUIDE VOLUME SETTING

Description

Following voice guidance setting can be changed.



Activation/Deactivation Setting


The voice prompt can be turned on/off by pushing the “Guidance Volume” button.

Voice Volume Setting

Volume of the voice can be controlled by bending the joystick to left/right.


TRIP COMPUTER INFORMATION

Elapsed time, Driving distance and Average speed are displayed as Trip Computer information.




FUEL ECONOMY INFORMATION

- Average Fuel Economy, Distance to Empty, Fuel Economy are displayed as Fuel Economy information.




NAVIGATION SYSTEM

- Select “Fuel Economy Record”. The average fuel consumption history will be displayed in graph along with the average for the previous Reset – to – Reset period.



MAINTENANCE INFORMATION

Engine Oil and Oil Filter are displayed as Maintenance information.



WARNING INDICATIONS

When combination meter receives warning signal from door switch, combination meter warning lamp is illuminated.

Then combination meter sends warning signal to NAVI control unit to display warning indications on the screen.

| Warning indicators | Warning lamps in instrument panel | Warning detection and cancel conditions | | Cases of malfunction |
|--------------------|-----------------------------------|---|--|----------------------|
| DOOR OPEN | Door | Detection condition | Vehicle is running [approx. 5 km/h (3 MPH) or faster] and door ajar of any of the doors is detected. | Door is open. |
| | | Cancel condition | Vehicle is stopped and all the doors lock. | |

A
B
C
D
E
F
G
H
I
J
L
M

AV

NAVIGATION SYSTEM

AKS003GT

Precautions for NAVI Control Unit Replacement

- When replacing the NAVI control unit, eject the map DVD-ROM before disconnecting the battery.
- The NAVI control unit has the following information stored in its memory. Record the memory contents before replacing the control unit, and input them in the new unit as necessary.

<Image quality>

- **Brightness of light when ON/OFF**
- **Dimming switching**
- **Display color switching**

<Navigation mode>


- **Latest status (map screen/bird view™, reduced scale, rotation angle of map screen, route guide ON/OFF, track ON/OFF, etc.)**
- **Current position**
- **Destination, passing point 1 - 5**
- **Registered places, their names, etc.**

NOTE:

Only removing the battery does not erase the memory.

Component Parts Location

AKS003GU




NAVIGATION SYSTEM

Schematic

AKS003GV

A
B
C
D
E
F
G
H
I
J
AV
L
M






TKWM2306E

NAVIGATION SYSTEM

AKS003GW

Wiring Diagram —NAVI—

AV-NAVI-01



*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

REFER TO THE FOLLOWING.

(E108) -SUPER MULTIPLE JUNCTION (SMJ)



(M4) -FUSE BLOCK-JUNCTION BOX (J/B)

TKWM2307E

NAVIGATION SYSTEM

AV-NAVI-02

— : DATA LINE





REFER TO THE FOLLOWING.
 (M4) - FUSE BLOCK-JUNCTION BOX (J/B)

TKWM2308E

NAVIGATION SYSTEM

AV-NAVI-03


▬ : DATA LINE





TKWM2309E

NAVIGATION SYSTEM

AV-NAVI-04





A
B
C
D
E
F
G
H
I
J
AV
L
M



TKWM2310E

NAVIGATION SYSTEM

AV-NAVI-05



*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

REFER TO THE FOLLOWING.
 (F102), (B1) -SUPER MULTIPLE JUNCTION (SMJ)






TKWM2311E

NAVIGATION SYSTEM

Wiring Diagram — COMM—

AKS00CXH

AV-COMM-01



REFER TO THE FOLLOWING.

(E108) -SUPER MULTIPLE JUNCTION (SMJ)




(M4) -FUSE BLOCK-JUNCTION BOX (J/B)

A
B
C
D
E
F
G
H
I
J
AV
L
M

TKWM2312E

NAVIGATION SYSTEM

AV-COMM-02



REFER TO THE FOLLOWING.
 (M4) - FUSE BLOCK-JUNCTION BOX (J/B)





TKWM2313E

NAVIGATION SYSTEM

AKS003GY

Terminals and Reference Value for NAVI Control Unit





- Measure using circuit tester and oscilloscope.
- Measure with connector connected unless otherwise specified.
- CAUTION:**
Confirm voltage between negative terminal on each unit and body ground is approximately 0V.
- If ignition ON is required in measurement condition, measures with engine running to prevent battery discharge.

| Terminal No. (Wire color) | | Item | Signal input/ output | Condition | | Reference value | Example of symptom |
|------------------------------|---------|----------------------------------|----------------------------|--------------------|---|--|--|
| (+) | (-) | | | Ignition switch | Operation | | |
| 1 (B) | Ground | Ground | - | ON | - | Approx. 0 V | - |
| 2 (Y) | Ground | Battery power supply | Input | OFF | - | Battery voltage | System does not work properly. |
| 3 (Y) | | | | | | | |
| 4 (B) | Ground | Ground | - | ON | - | Approx. 0 V | - |
| 6 (LG) | Ground | ACC power supply | Input | ACC | - | Battery voltage | System does not work properly. |
| 7 (L/W) | 8 (W/B) | Voice guide signal | Output | ON | Push the "VOICE" switch. |  <p style="text-align: right; font-size: small;">SKIA0171J</p> | Only route guide and operation guide are not heard. |
| 9 (B) | Ground | Ground | - | ON | - | Approx. 0V | - |
| 12 (L) | 17 | RGB area (YS) signal | Output | ON | - |  <p style="text-align: right; font-size: small;">SKIA0162E</p> | RGB screen is not shown. |
| 15 (R) | 17 | RGB signal (B: blue) | Output | ON | Select "Color bar" of CONFIRMATION/ ADJUSTMENT func- tion. |  <p style="text-align: right; font-size: small;">SKIA0167E</p> | RGB screen looks yellowish. |
| 16 (P) | 17 | RGB syn- chronizing signal | Output | ON | - |  <p style="text-align: right; font-size: small;">SKIA0164E</p> | RGB screen is rolling. |
| 17 | Ground | Shield Ground | - | ON | - | Approx. 0V | - |





A
B
C
D
E
F
G
H
I
J
L
M

AV

NAVIGATION SYSTEM

| Terminal No. (Wire color) | | Item | Signal input/ output | Condition | | Reference value | Example of symptom |
|------------------------------|--------|---|----------------------------|--------------------|---|---|--|
| (+) | (-) | | | Ignition switch | Operation | | |
| 18 (B) | 17 | RGB signal (R: red) | Output | ON | Select "Color bar" of CONFIRMATION/ ADJUSTMENT func- tion. |  SKIA0166E | RGB screen looks bluish. |
| 20 (G) | Ground | RGB Ground | - | ON | - | Approx. 0V | - |
| 21 (W) | 17 | RGB signal (G: green) | Output | ON | Select "Color bar" of CONFIRMATION/ ADJUSTMENT func- tion. |  SKIA0166E | RGB screen looks reddish. |
| 22 (R/W) | Ground | Llimit switch signal | Input | ON | Display unit is opened. | Approx. 5V | Vehicle informa- tion setting is not possible. |
| | | | | | Except for above | Approx. 0V | |
| 24 (R/B) | 9 (B) | Voice guide ON signal | Output | ON | Push the "Voice" switch. |  SKIB0232E | Only route guide and operation guide are not heard. |
| 25 (R/L) | Ground | Illumina- tion signal | Input | OFF | Lighting switch posi- tion 1st or 2nd | Approx. 12V | Night illumina- tion for switches does not illumina- te. |
| | | | | | Lighting switch posi- tion OFF | Approx. 0V | |
| 26 (Y/G) | Ground | Ignition signal | Input | ON | - | Battery voltage | Vehicle informa- tion setting is not possible. |
| 27 (OR) | Ground | Reverse signal | Input | ON | Select R- position | Approx. 12V | The navigation current-location mark moves strangely when the vehicle is moving back- wards. |
| | | | | | Other position | Approx. 0V | |
| 28 (W/G) | Ground | Vehicle speed signal (2-pulse) | Input | ON | When vehicle speed is approx. 40 km/h (25 MPH) |  SKIA0168E | Navigation cur- rent-location mark does not indicate the cor- rect position. |

NAVIGATION SYSTEM

| Terminal No. (Wire color) | | Item | Signal input/ output | Condition | | Reference value | Example of symptom |
|------------------------------|-----|----------------------------------|----------------------------|--------------------|-----------------------------------|--|--|
| (+) | (-) | | | Ignition switch | Operation | | |
| 44 (SB) | 43 | Communi- cation signal (+) | Input/ Output | ON | Push the "PREVIOUS" switch. |  <small>SKIA0175E</small> | NAVI switch is not controlled. |
| 45 (B) | 43 | Communi- cation signal (-) | Input/ Output | ON | Push the "PREVIOUS" switch. |  <small>SKIA0176E</small> | NAVI switch is not controlled. |
| 47 (B/R) | 46 | Communi- cation signal (+) | Input/ Output | ON | - |  <small>SKIA0175E</small> | - |
| 48 (W/R) | 46 | Communi- cation signal (-) | Input/ Output | ON | - |  <small>SKIA0176E</small> | - |
| 56 | 57 | GPS antenna signal | Input | ON | Connector is not connected. | Approx. 5V | Navigation sys- tem GPS correc- tion is not possible. |

A

B

C

D

E

F

G

H

I

J

AV







L

M




NAVIGATION SYSTEM

Terminals and Reference Value for Display Unit

AKS003GZ

| Terminal No. (Wire color) | | Item | Signal input/ output | Condition | | Reference value | Example of symptom |
|------------------------------|--------|----------------------------------|----------------------------|--------------------|--|--|-----------------------------------|
| (+) | (-) | | | Ignition switch | Operation | | |
| 1 (B) | Ground | RGB signal (R: red) | Input | ON | Select "Color bar" of CONFIRMA- TION/ADJUST- MENT function. |  <p style="text-align: right; font-size: small;">SKIA0165E</p> | RGB screen looks bluish. |
| 2 (W) | Ground | RGB signal (G: green) | Input | ON | Select "Color bar" of CONFIRMA- TION/ADJUST- MENT function. |  <p style="text-align: right; font-size: small;">SKIA0166E</p> | RGB screen looks reddish. |
| 3 (R) | Ground | RGB signal (B: blue) | Input | ON | Select "Color bar" of CONFIRMA- TION/ADJUST- MENT function. |  <p style="text-align: right; font-size: small;">SKIA0167E</p> | RGB screen looks yellowish. |
| 4 (G) | Ground | RGB Ground | - | ON | - | Approx. 0V | - |
| 7 (P) | Ground | RGB synchro- nizing signal | Input | ON | - |  <p style="text-align: right; font-size: small;">SKIA0164E</p> | RGB screen is rolling. |
| 8 (L) | Ground | RGB area (YS) signal | Input | ON | - |  <p style="text-align: right; font-size: small;">SKIA0162E</p> | RGB screen is not shown. |
| 12 | Ground | RGB shield | - | ON | - | Approx. 0V | - |
| 13 (B) | Ground | Communica- tion signal (-) | Input/ Output | ON | Push the "PREVIOUS" switch. |  <p style="text-align: right; font-size: small;">SKIA0176E</p> | NAVI switch is not controlled. |

NAVIGATION SYSTEM



| Terminal No. (Wire color) | | Item | Signal input/ output | Condition | | Reference value | Example of symptom |
|------------------------------|--------|----------------------------------|----------------------------|--------------------|-----------------------------------|--|--|
| (+) | (-) | | | Ignition switch | Operation | | |
| 14 (SB) | 15 | Communica- tion signal (+) | Input/ Output | ON | Push the "PREVIOUS" switch. |  SKIA0175E | NAVI switch is not controlled. |
| 15 | Ground | Shield Ground | - | ON | - | Approx. 0V | - |
| 16 (G) | Ground | Communica- tion signal (-) | Input/ Output | ON | Push the "PREVIOUS" switch. |  SKIA0176E | NAVI switch is not controlled. |
| 19 (LG) | Ground | ACC power supply | Input | ACC | - | Battery voltage | System does not work prop- erly. |
| 20 (R) | Ground | Communica- tion signal (+) | Input/ Output | ON | Push the "PREVIOUS" switch. |  SKIA0175E | NAVI switch is not controlled. |
| 21 (Y) | Ground | Battery power supply | Input | OFF | - | Battery voltage | System does not work prop- erly. |
| 22 (B) | Ground | Ground | - | ON | - | Approx. 0V | - |
| 23 (Y) | Ground | Battery power supply | Input | OFF | - | Battery voltage | System does not work prop- erly. |
| 24 (B) | Ground | Ground | - | ON | - | Approx. 0V | - |

A
B
C
D
E
F
G
H
I
J
AV
L
M

NAVIGATION SYSTEM

Terminals and Reference Value for NAVI Switch

AKS003H0

| Terminal No. (Wire color) | | Item | Signal input/ output | Condition | | Reference value | Example of symptom |
|------------------------------|--------|--------------------------|----------------------------|--------------------|--|---|--|
| (+) | (-) | | | Ignition switch | Operation | | |
| 1 (LG) | Ground | ACC power supply | Input | ACC | – | Battery voltage | All operations do not work. |
| 2 (R/L) | Ground | Illumination signal (+) | Input | OFF | Lighting switch position 1st or 2nd | Approx. 12V | Night illumination for switches does not illuminate. |
| | | | | | Lighting switch position OFF | Approx. 0V | |
| 3 (R/Y) | Ground | Illumination signal (-) | – | ON | Illumination control switch is operated by lighting switch in position | Approx. 0V | NAVI switch illumination can not be controlled. |
| 4 (R) | 6 | Communication signal (+) | Input/Output | ON | Push the "PREVIOUS" switch. |  <p style="text-align: right; font-size: small;">SKIA0175E</p> | NAVI switch is not controlled. |
| 5 (G) | 6 | Communication signal (-) | Input/Output | ON | Push the "PREVIOUS" switch. |  <p style="text-align: right; font-size: small;">SKIA0176E</p> | NAVI switch is not controlled. |
| 6 | Ground | Shield Ground | – | ON | – | Approx. 0V | – |
| 7 (B) | Ground | Ground | – | ON | – | Approx. 0V | All operations do not work. |

NAVIGATION SYSTEM

AKS003H1

Self-Diagnosis Function DESCRIPTION

- Diagnosis function consists of the self-diagnosis mode performed automatically and the CONFIRMATION/ADJUSTMENT mode operated manually.
- Self-diagnosis mode checks for connections between the units constituting this system, analyzes each individual unit at the same time, and displays the results on the LCD screen.
- CONFIRMATION/ADJUSTMENT mode is used to perform trouble diagnoses that require operation and judgment by an operator (trouble that cannot be automatically judged by the system), to check/change the set value, and to display the History of Errors of the navigation system.


DIAGNOSIS ITEM

| Mode | | Description | |
|-----------------------------|-------------------|--|---|
| Self-diagnosis | | <ul style="list-style-type: none"> ● NAVI Control unit diagnosis (DVD-ROM drive will not be diagnosed when no map DVD-ROM is in it.). ● Performs diagnosis of each unit and connections between control unit and GPS antenna, as well as between control unit and each unit. | |
| CONFIRMATION/ ADJUSTMENT | Display diagnosis | Color tone and shading of the screen can be checked by the display of a color bar and a gray scale. | |
| | Vehicle signals | Analyzes the following vehicle signals: Vehicle speed signal, light signal, ignition switch signal, and reverse signal. | |
| | Navigation | Display Longitude & Latitude | Display the map. Use the joystick to adjust position. Longitude and latitude will be displayed. |
| | | Speed Calibration | Under ordinary conditions, the navigation system distance measuring function will automatically compensate for minute decreases in wheel and tire diameter caused by tire wear or low pressure. Speed calibration immediately restores system accuracy in cases such as when distance calibration is needed because of the use of tire chains in inclement weather. |
| | | Angle Adjustment | Corrects difference between actual turning angle of a vehicle and turning angle of the car mark on the display. |
| | | Initialize Location | This mode is for initializing the current location. Use when the vehicle is transported a long distance on a trailer, etc. |
| History of Errors | | Diagnosis results previously stored in the memory (before turning ignition switch ON) are displayed in this mode. Time and location when/where the errors occurred are also displayed. | |


A
B
C
D
E
F
G
H
I
J
AV
L
M

Self-Diagnosis Mode OPERATION PROCEDURE


1. Start the engine.
2. Push and hold "MAP" and "DAY/NIGHT" switches simultaneously for 5 seconds or more.
 - Push the "PREVIOUS" switch and the initial system screen will be shown.



3. The initial trouble diagnosis screen will be shown, and items "SELF-DIAGNOSIS" and "CONFIRMATION/ADJUSTMENT" will become selective.




4. Perform self-diagnosis by selecting the "SELF-DIAGNOSIS".
 - Self-diagnosis subdivision screen will be shown and the operation enters the self-diagnosis mode.
 - A bar graph shown below the self-diagnosis subdivision screen indicates progress of the diagnosis.



5. On the "Self-diagnosis" screen, each unit name will be colored according to the diagnosis result, as follows.


- Green** : No malfunctioning.
- Yellow** : Cannot be judged by self-diagnosis results.
- Red** : Unit is malfunctioning.
- Gray** : Diagnosis has not been done.

- If multiple malfunctions occur at the same time for a single unit, the screen switch colors are determined according to the following order of priority. Red > yellow > gray
- Display when it is normal
 - Between Navigation Unit and GPS antenna is connected in green.
 - Between Navigation Unit and Satellite Switch, Navigation Unit and Display, Navigation Unit and IMU are connected in gray.



NAVIGATION SYSTEM

6. Select a switch on the “Self-diagnosis” screen and comments for the diagnosis results will be shown.



SELF-DIAGNOSIS RESULT

Quick Reference Table

1. Select an applicable diagnosis No. in the diagnosis result quick reference table.
2. Find estimated malfunctioning system in the diagnosis No. table and perform check by referring to the AV communication line wiring diagram. Refer to [AV-59, "Wiring Diagram — COMM—"](#).
3. Turn the ignition switch to OFF and perform self-diagnosis again.

| Screen switch | | | | Diagnosis No. |
|---------------|-------------------------------|-------------------|-------------|---------------|
| Switch color | Navigation unit ^{*1} | IMU ^{*2} | GPS antenna | |
| Red | × | | | 1 |
| Grey | × | | | 2 |
| Yellow | × | | | 3 |
| | × | | | 4 |
| | × | × | | 5 |
| | × | | × | 6 |

*1: Navigation unit =NAVI control unit

*2: IMU =Combination meter

CAUTION:

- If display has any error, self-diagnosis cannot start.
- If AV communication between display and NAVI control unit has any error, self-diagnosis cannot start.

NAVIGATION SYSTEM



Self-Diagnosis Codes

| Diagnosis No. | Possible cause |
|---------------|--|
| 1 | NAVI control unit malfunction |
| 2 | NAVI control unit judged no map DVD-ROM is inserted. |
| 3 | When "DVD-ROM error. Please check disc." is shown. 1. Eject map DVD-ROM and check if it is compatible with the system. 2. Check ejected DVD-ROM for dirt, damage, and warp age. 3. If no error is found, insert a known good map DVD-ROM of the same type and perform self-diagnosis again. If same result is shown, the NAVI control unit is malfunctioning. If result is normal, the map DVD-ROM is malfunctioning. |
| 4 | If "Error found in DVD-ROM or DVD-ROM driver in control unit. Please perform diagnosis in accordance with service manual" is shown, carry out same inspection as diagnosis No. 3. |
| 5 | Combination meter system 1. Combination meter power supply and ground circuit 2. Communication line between combination meter and NAVI control unit |
| 6 | GPS antenna system 1. Visually check for a broken wire in the GPS antenna coaxial cable. 2. Disconnect the GPS antenna connector and check that approximately 5V is supplied from NAVI control unit. If not, the NAVI control unit is inoperative. If the voltage is supplied, replace the GPS antenna and perform self-diagnosis again. If the same result is shown, the NAVI control unit is inoperative. |

CONFIRMATION/ADJUSTMENT Mode OPERATION PROCEDURE


AKS003H3

- Start the engine.
- Push and hold "MAP" and "DAY/NIGHT" switches simultaneously for 5 seconds or more.
 - Push the "PREVIOUS" switch and the initial system screen will be shown.
- The initial trouble diagnosis screen will be shown, and items "SELF-DIAGNOSIS" and "CONFIRMATION/ADJUSTMENT" will become selective.




NAVIGATION SYSTEM

4. When "CONFIRMATION/ADJUSTMENT" is selected on the initial trouble diagnosis screen, the operation will enter the CONFIRMATION/ADJUSTMENT mode. In this mode, check and adjustment of each item will become possible.
5. Select each switch on "CONFIRMATION/ADJUSTMENT" screen to display the relevant diagnosis screen.



DISPLAY DIAGNOSIS



CAUTION:


When Display Color Spectrum Bar screen is completed after "PREVIOUS" switch is pushed, the screen color changes once. This is normal.

- When RGB signal error occurred in the RGB system, tone of the color bar will change as follows.
 - R (red) signal error** : Screen looks bluish.
 - G (green) signal error** : Screen looks reddish.
 - B (blue) signal error** : Screen looks yellowish.
- When the color of the screen looks unusual, refer to [AV-84, "Color of RGB Image Is Not Proper \(Bluish\)"](#) , [AV-85, "Color of RGB Image Is Not Proper \(Reddish\)"](#) , [AV-86, "Color of RGB Image Is Not Proper \(Yellowish\)"](#) .

NAVIGATION SYSTEM

VEHICLE SIGNALS

- A comparison check can be made of each actual vehicle signal and the signals recognized by the system.




| Diagnosis item | Display | Condition | Remarks |
|----------------|---------|---|--|
| Vehicle speed | ON | Vehicle speed > 0 km/h (0 MPH) | Changes in indication may be delayed by approx. 1.5 seconds. This is normal. |
| | OFF | Vehicle speed = 0 km/h (0 MPH) | |
| | - | Ignition switch in ACC position | |
| Lights | ON | Lighting switch ON | - |
| | OFF | Lighting switch OFF | |
| IGN | ON | Ignition switch ON | - |
| | OFF | Ignition switch ACC | |
| Reverse | ON | Selector lever in R-position | Changes in indication may be delayed by approx. 1.5 seconds. This is normal. |
| | OFF | Selector lever in other than R-position | |
| | - | Ignition switch in ACC position | |

- If vehicle speed is NG, refer to [AV-78, "Vehicle Speed Signal Check"](#) .
- If lights are NG, refer to [AV-79, "Illumination Signal Check"](#) .
- If IGN is NG, refer to [AV-79, "Ignition Signal Check"](#) .
- If reverse is NG, refer to [AV-80, "Reverse Signal Check \(With A/T\)"](#) .[AV-80, "Reverse Signal Check \(With M/T\)"](#) .

NAVIGATION

Angle Adjustment


Adjusts turning angle output detected by the gyroscope.




NAVIGATION SYSTEM

Speed Calibration

During normal driving, distance error caused by tire wear and tire pressure change is automatically adjusted for by the automatic distance correction function. This function, on the other hand, is for immediate adjustment, in cases such as driving with tire chain fitted on tires.



HISTORY OF ERRORS



DIAGNOSIS BY HISTORY OF ERRORS

The "Self-diagnosis" results indicate whether an error occurred during the period from when the ignition switch is turned to ON until "Self-diagnosis" is completed.

If an error occurred before the ignition switch was turned to ON and does not occur again until the "Self-diagnosis" is completed, the diagnosis result will be judged normal. Therefore, those errors in the past, which cannot be found by the "Self-diagnosis", must be found by diagnosing the "History of Errors".

The History of Errors displays the time and place of the most recent occurrence of that error. However, take note of the following points.

- Correct time of the error occurrence may not be displayed when the GPS antenna substrate within the NAVI control unit has malfunctioned.
- Place of the error occurrence is represented by the position of the current-location mark at the time when the error occurred. If the current-location mark has deviated from the correct position, then the place of the error occurrence may be located correctly.
- The maximum number of occurrences which can be stored is 50. For the 51st and later occurrences, the displayed number remains 50.

When a reproducible malfunction occurred but its cause cannot be identified because several errors are present, record the item, number and place (longitude/latitude) of error occurrence (or delete the History of Errors), then turn the ignition switch from OFF to ON to reproduce the malfunction. Check the History of Errors to find the items which show an increased number of occurrences, and diagnose the item.

NAVIGATION SYSTEM

| Error item | Possible causes | Example of symptom |
|--|--|--|
| | Action/symptom | |
| Gyro sensor disconnected | Communications malfunction between NAVI control unit and internal gyro | <ul style="list-style-type: none"> ● Navigation location detection performance has deteriorated. (Angular velocity cannot be detected.) |
| | <ul style="list-style-type: none"> ● Perform self-diagnosis. ● When the NAVI control unit is judged normal by self-diagnosis, the symptom may be intermittent, caused by strong radio interference. | |
| GPS disconnected | Communication error between NAVI control unit and internal GPS substrate | <ul style="list-style-type: none"> ● Navigation location detection performance has deteriorated. (Location correction using GPS is not performed.) ● GPS receiving status remains gray. |
| | <ul style="list-style-type: none"> ● Perform self-diagnosis. ● When the NAVI control unit is judged normal by self-diagnosis, the symptom may be intermittent, caused by strong radio interference. | |
| GPS transmission cable malfunction | Malfunctioning transmission wires to NAVI control unit and internal GPS substrate | <ul style="list-style-type: none"> ● During self-diagnosis, GPS diagnosis is not performed. |
| | <ul style="list-style-type: none"> ● Perform self-diagnosis. ● When the NAVI control unit is judged normal by self-diagnosis, the symptom may be intermittent, caused by strong radio interference. | |
| GPS input line connection error | Malfunctioning receiving wires to NAVI control unit and internal GPS substrate | <ul style="list-style-type: none"> ● Navigation location detection performance has deteriorated. (Location correction using GPS is not performed.) ● GPS receiving status remains gray. |
| | <ul style="list-style-type: none"> ● Perform self-diagnosis. ● When the NAVI control unit is judged normal by self-diagnosis, the symptom may be intermittent, caused by strong radio interference. | |
| GPS TCX0 over GPS TCX0 under | Oscillating frequency of the GPS substrate frequency synchronizing oscillation circuit exceeded (or below) the specification | <ul style="list-style-type: none"> ● Navigation location detection performance has deteriorated. (Location correction using GPS is not performed.) ● GPS receiving status remains gray. |
| | <ul style="list-style-type: none"> ● Perform self-diagnosis. ● When the NAVI control unit is judged normal by self-diagnosis, the symptom may be intermittent, caused by strong radio interference, or the control unit may have been subjected to excessively high or low temperatures. | |
| GPS ROM malfunction GPS RAM malfunction | Contents of ROM (or RAM) in GPS substrate are malfunctioning. | <ul style="list-style-type: none"> ● Location detection accuracy of the navigation system will deteriorate, depending on the failed area in the memory, because GPS cannot make correct positioning. (Location correction using GPS is not performed.) |
| | <ul style="list-style-type: none"> ● Perform self-diagnosis. ● When the NAVI control unit is judged normal by self-diagnosis, the symptom may be intermittent, caused by strong radio interference. | |
| GPS RTC malfunction | Clock IC in GPS substrate is malfunctioning. | <ul style="list-style-type: none"> ● Correct time may not be displayed. ● After the power is turned on, the system always takes some time until GPS positioning becomes possible. (The GPS receiver starts positioning without re-collecting the whole satellite information when it judged the data stored in the receiver is correct.) ● Correct time of error occurrence may not be stored in the "History of Errors". |
| | <ul style="list-style-type: none"> ● Perform self-diagnosis. ● When the NAVI control unit is judged normal by self-diagnosis, the symptom may be intermittent, caused by strong radio interference. | |
| GPS antenna disconnected | Malfunctioning connection between GPS substrate in NAVI control unit and GPS antenna. | <ul style="list-style-type: none"> ● Navigation location detection performance has deteriorated. (Location correction using GPS is not performed.) ● GPS receiving status remains gray. |
| | <ul style="list-style-type: none"> ● Perform self-diagnosis. ● When connection between NAVI control unit and GPS antenna is judged normal by self-diagnosis, the symptom may be intermittent, caused by impact or vibration. | |

NAVIGATION SYSTEM

| Error item | Possible causes | Example of symptom |
|---|--|--|
| | Action/symptom | |
| Low voltage of GPS | The power voltage supplied to the GPS circuit board has decreased. | <ul style="list-style-type: none"> ● Navigation location detection performance has deteriorated. (Location correction using GPS is not performed.) ● GPS receiving status remains gray. |
| | <ul style="list-style-type: none"> ● Perform self-diagnosis. ● When connection between NAVI control unit and GPS antenna is judged normal by self-diagnosis, the symptom may be intermittent, caused by impact or vibration. | |
| DVD-ROM Malfunction DVD-ROM Read error DVD-ROM Response Error | Malfunctioning NAVI control unit | - |
| | Dedicated map DVD-ROM is in the system, but the data cannot be read. | <ul style="list-style-type: none"> ● The map of a particular location cannot be displayed. ● Specific guidance information cannot be displayed. ● Map display is slow. ● Guidance information display is slow. ● System has been affected by vibration. |
| | <ul style="list-style-type: none"> ● Is map DVD-ROM damaged, warped, or dirty? <ul style="list-style-type: none"> – If damaged or warped, the map DVD-ROM is malfunctioning. – If dirty, wipe the DVD-ROM clean with a soft cloth. ● Perform self-diagnosis. ● When NAVI control unit is judged normal by self-diagnosis, the symptom is judged intermittent, caused by vibration. | |

A
B
C
D
E
F
G
H
I
J
L
M

AV

NAVIGATION SYSTEM

Power Supply and Ground Circuit Check for NAVI Control Unit

AKS003H4

1. CHECK FUSE

Check that the following fuses of the NAVI control unit are not blown.

| Terminals | | Power source | Fuse No. |
|-----------|-----------------------|---------------------------|----------|
| Connector | Terminal (Wire color) | | |
| M57 | 2 (Y) | Battery power | 37 |
| | 3 (Y) | | |
| | 6 (LG) | Ignition switch ACC or ON | 6 |

OK or NG


OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate case of malfunction before installing new fuse. Refer to [PG-4](#), "[POWER SUPPLY ROUTING CIRCUIT](#)".

2. POWER SUPPLY CIRCUIT CHECK

Check voltage between the following harness connector terminals and ground.

| Terminals | | | OFF | ACC | ON |
|-----------|-----------------------|--------|-----------------|-----------------|-----------------|
| (+) | | (-) | | | |
| Connector | Terminal (Wire color) | | | | |
| M57 | 2 (Y) | Ground | Battery voltage | Battery voltage | Battery voltage |
| | 3 (Y) | | Battery voltage | Battery voltage | Battery voltage |
| | 6 (LG) | | 0V | Battery voltage | Battery voltage |



OK or NG

OK >> GO TO 3.

NG >> Check harness for open or short between NAVI control unit and fuse.

3. GROUND CIRCUIT CHECK


1. Turn ignition switch OFF.
2. Disconnect the NAVI control unit connector.
3. Check continuity between the following NAVI control unit harness connector and ground.

| Terminals | | | Continuity |
|-----------|-----------------------|--------|------------|
| Connector | Terminal (Wire color) | | |
| M57 | 1 (B) | Ground | Yes |
| | 4 (B) | | |

OK or NG

OK >> Inspection end.

NG >> Repair harness or connector.



NAVIGATION SYSTEM

Power Supply and Ground Circuit Check for Display Unit and NAVI Switch

AKS003H5

1. CHECK FUSE

Check that the following fuses of the display unit and NAVI switch are not blown.

| Unit | Terminals | | Power source | Fuse No. |
|--------------|-----------|-----------------------|---------------------------|----------|
| | Connector | Terminal (Wire color) | | |
| Display unit | M35 | 21 (Y) | Battery power | 37 |
| | | 23 (Y) | | |
| | | 19 (LG) | | |
| NAVI switch | M37 | 1 (LG) | Ignition switch ACC or ON | 6 |

OK or NG


OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate case of malfunction before installing new fuse. Refer to [PG-4](#), "[POWER SUPPLY ROUTING CIRCUIT](#)".

2. POWER SUPPLY CIRCUIT CHECK


1. Check voltage between display unit harness connector and ground.

| Unit | Terminals | | | OFF | ACC | ON |
|--------------|-----------|-----------------------|--------|-----------------|-----------------|-----------------|
| | (+) | | (-) | | | |
| | Connector | Terminal (Wire color) | | | | |
| Display unit | M35 | 21 (Y) | Ground | Battery voltage | Battery voltage | Battery voltage |
| | | 23 (Y) | | Battery voltage | Battery voltage | Battery voltage |
| | | 19 (LG) | | 0V | Battery voltage | Battery voltage |



2. Check voltage between NAVI switch harness connector and ground.

| Unit | Terminals | | | OFF | ACC | ON |
|-------------|-----------|-----------------------|--------|-----|-----------------|-----------------|
| | (+) | | (-) | | | |
| | Connector | Terminal (Wire color) | | | | |
| NAVI switch | M37 | 1 (LG) | Ground | 0V | Battery voltage | Battery voltage |



OK or NG

OK >> GO TO 3.

NG >> Check the following.


- Harness for open or short between display unit and fuse.
- Harness for open or short between NAVI switch and fuse.

NAVIGATION SYSTEM

3. GROUND CIRCUIT CHECK

1. Turn ignition switch OFF.
2. Disconnect display unit connector and NAVI switch connector.
3. Check continuity between display unit harness connector and ground.

| Unit | Terminals | | Continuity |
|--------------|-----------|-----------------------|------------|
| | Connector | Terminal (Wire color) | |
| Display unit | M35 | 22 (B) | Ground |
| | | 24 (B) | |
| | | | Yes |




4. Check continuity between NAVI switch harness connector M37 terminal 7 (B) and ground.

Continuity should exist.

OK or NG

- OK >> Inspection end.
 NG >> Repair harness or connector.



Vehicle Speed Signal Check

1. VEHICLE SPEED OPERATION CHECK

Does speed meter is operated normally?

YES or NO

- YES >> GO TO 2.
 NO >> Check combination meter trouble diagnosis. Refer to [DI-10, "Self-Diagnosis Mode of Combination Meter"](#).

2. HARNESS CHECK

1. Turn ignition switch OFF.
2. Disconnect NAVI control unit connector and combination meter connector.
3. Check continuity between NAVI control unit harness connector M58 terminal 28 (W/G) and combination meter harness connector M19 terminal 14 (W/G).


Continuity should exist.

4. Check continuity NAVI control unit harness connector M58 terminal 28 (W/G) and ground.

Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> ● Check harness for open or short between NAVI control unit and combination meter.
 ● Check connector housings for disconnected or loose terminals.




NAVIGATION SYSTEM

3. VEHICLE SPEED SIGNAL CHECK

1. Connect NAVI control unit connector and combination meter connector.
2. Drive vehicle at a constant speed.
3. Check the signal between NAVI control unit harness connector M58 terminal 28 (W/G) and ground with CONSULT-II or oscilloscope.

28 (W/G) – Ground : Refer to [AV-61, "Terminals and Reference Value for NAVI Control Unit"](#) .



OK or NG

OK >> Replace NAVI control unit.

NG >> Check combination meter system. Refer to [DI-10, "Self-Diagnosis Mode of Combination Meter"](#) .

Illumination Signal Check

AKS003H7

1. TAIL LAMP OPERATION CHECK

When lighting switch turned 1st or 2nd position, does tail lamp illuminate?

YES or NO


Yes >> GO TO 2.

No >> Go to tail lamp trouble diagnosis. Refer to [LT-153, "Parking, License Plate and Tail Lamps Do Not Illuminate"](#) .

2. ILLUMINATION SIGNAL CHECK

Check voltage between NAVI control unit harness connector and ground.

| Terminals | | (-) | Lighting switch position | Voltage (V) |
|-----------|-----------------------|----------|--------------------------|-------------|
| (+) | Connector | | | |
| | Terminal (Wire color) | | | |
| | M58 | 25 (R/L) | 1st or 2nd position | Approx. 12V |
| | | Ground | OFF | Approx. 0V |



OK or NG

OK >> Replace NAVI control unit.

NG >> Check harness for open or short between NAVI control unit and IPDM E/R. Refer to [LT-193, "Wiring Diagram — ILL —"](#) .

Ignition Signal Check

AKS003H8

1. CHECK FUSE

Check that the following fuses of the NAVI control unit are not blown.

| Terminals | | Power source | Fuse No. |
|-----------|-----------------------|-----------------------------|----------|
| Connector | Terminal (Wire color) | | |
| M58 | 26 (Y/G) | Ignition switch ON or START | 12 |

OK or NG


OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate case of malfunction before installing new fuse. Refer to [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#) .

NAVIGATION SYSTEM

2. IGNITION SIGNAL CHECK

1. Turn ignition switch ON.
2. Check voltage between NAVI control unit harness connector and ground.



| Terminals | | (-) | Ignition switch position | |
|---------------------------|-----------------------|--------|--------------------------|------------|
| (+) Terminal (Wire color) | | | ON | OFF |
| Connector | Terminal (Wire color) | Ground | Battery voltage | Approx. 0V |
| M58 | 26 (Y/G) | Ground | Battery voltage | Approx. 0V |

OK or NG

- OK >> Replace NAVI control unit.
 NG >> Repair harness or connector.

Reverse Signal Check (With A/T)

AKS003H9

1. REVERSE LAMP CHECK


1. Turn ignition switch ON.
2. With the A/T selector lever in R-position. Is the indicator turned on?

YES or NO

- YES >> GO TO 2.
 NO >> Check back up lamp system. Refer to [LT-140, "Wiring Diagram — BACK/L —"](#) .

2. REVERSE SIGNAL CHECK

1. With the A/T selector lever in R-position.
2. Check voltage between NAVI control unit harness connector and ground.



| Terminals | | (-) | A/T selector lever position | Voltage (V) |
|---------------------------|-----------------------|--------|-----------------------------|-------------|
| (+) Terminal (Wire color) | | | | |
| Connector | Terminal (Wire color) | Ground | R-position | Approx. 12V |
| M58 | 27 (OR) | Ground | Other than R-position | Approx. 0V |

OK or NG

- OK >> Replace NAVI control unit.
 NG >> Harness for open or short between NAVI control unit and back-up lamp relay.

Reverse Signal Check (With M/T)

AKS004C8

1. REVERSE LAMP CHECK

1. Turn ignition switch ON.
2. With the shift lever in R-position. Are reverse ramps turned on?

YES or NO

- YES >> GO TO 2.
 NO >> Check back up lamp system. Refer to [LT-140, "Wiring Diagram — BACK/L —"](#) .

NAVIGATION SYSTEM

2. REVERSE SIGNAL CHECK


1. With the shift lever in R-position.
2. Check voltage between NAVI control unit harness connector and ground.

| Terminals | | (-) | Shift lever position | Voltage (V) |
|---------------|-----------------------|--------|-----------------------|-------------|
| (+) Connector | | | | |
| Connector | Terminal (Wire color) | | | |
| M58 | 27 (OR) | Ground | R-position | Approx. 12V |
| | | | Other than R-position | Approx. 0V |

OK or NG

OK >> Replace NAVI control unit.

NG >> Harness for open or short between NAVI control unit and back-up lamp switch.



Navigation System Is Not Operated by NAVI Switch

AKS00ATX

1. CHECK POWER SUPPLY AND GROUND CIRCUIT (DISPLAY UNIT AND NAVI SWITCH)

Check power supply and ground circuit. Refer to [AV-77, "Power Supply and Ground Circuit Check for Display Unit and NAVI Switch"](#).

OK or NG

OK >> GO TO 2.

NG >> Power supply and ground circuit check.

2. CHECK HARNESS (BETWEEN NAVI SWITCH AND DISPLAY UNIT)

1. Turn ignition OFF.
2. Disconnect display unit connector and NAVI switch connector.
3. Check continuity between display unit harness connector M35 terminal 16 (G), 20 (R) and NAVI switch harness connector M37 terminal 5 (G), 4 (R).

Continuity should exist.


4. Check continuity between display unit harness connector M35 terminal 16 (G), 20 (R) and ground.

Continuity should not exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.



A
B
C
D
E
F
G
H
I
J
AV
L
M

NAVIGATION SYSTEM


3. CHECK HARNESS (BETWEEN DISPLAY UNIT AND NAVI CONTROL UNIT)

1. Disconnect NAVI control unit connector and display unit connector.
2. Check continuity between NAVI control unit harness connector M58 terminal 44 (SB), 45 (B) and display unit harness connector M35 terminal 14 (SB), 13 (B).

Continuity should exist.

3. Check continuity between NAVI control unit harness connector M58 terminal 44 (SB), 45 (B) and ground.

Continuity should not exist.



OK or NG

- OK >> GO TO 4.
- NG >> Repair harness or connector.

4. CHECK NAVI SWITCH

Replace normal NAVI switch and recheck the symptom.

Is the function normal?

- YES >> Replace NAVI switch.
- NO >> GO TO 5.

5. CHECK DISPLAY UNIT

Replace normal display unit and recheck the symptom.

Is the function normal?

- YES >> Replace display unit.
- NO >> Replace NAVI control unit.

Screen Is Not Shown

AKS003HA

1. CHECK DISPLAY UNIT

Check if brightness of screen changes when DAY/NIGHT switch on NAVI switch is turned on after turning on ignition switch.

Does brightness of screen change?

- YES >> GO TO 3.
- NO >> GO TO 2.

2. CHECK DISPLAY UNIT POWER SUPPLY AND GROUND CIRCUIT

Check display unit power supply and ground circuit. Refer to [AV-77, "Power Supply and Ground Circuit Check for Display Unit and NAVI Switch"](#).

OK or NG

- OK >> Replace display unit.
- NG >> Repair malfunctioning parts.

3. CHECK NAVI CONTROL UNIT POWER SUPPLY AND GROUND CIRCUIT

Check NAVI control unit power supply and ground circuit. Refer to [AV-76, "Power Supply and Ground Circuit Check for NAVI Control Unit"](#).

OK or NG

- OK >> GO TO 4.
- NG >> Repair malfunctioning parts.

NAVIGATION SYSTEM

4. CHECK HARNESS

1. Turn ignition switch OFF.
2. Disconnect NAVI control unit connector and display unit connector.
3. Check continuity between NAVI control unit harness connector M57 terminal 12 (L) and display unit harness connector M35 terminal 8 (L).

12 (L) – 8 (L) : Continuity should exist.


4. Check continuity between NAVI control unit harness connector M57 terminal 12 (L) and ground.

12 (L) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 2.

NG >> Repair harness or connector.



5. HARNESS CHECK


1. Connect NAVI control unit connector and display unit connector.
2. Turn ignition switch ON.
3. Check signal between NAVI control unit harness connector M57 terminal 12 (L) and 17 with CONSULT-II or oscilloscope.

12 (L) – 17 : Refer to [AV-61, "Terminals and Reference Value for NAVI Control Unit"](#) .

OK or NG

OK >> GO TO 7.

NG >> Replace NAVI control unit.



6. CHECK HARNESS


1. Turn ignition switch OFF.
2. Disconnect NAVI control unit connector and cover switch connector.
3. Check continuity between NAVI control unit harness connector M57 terminal 22 (R/W) and ground.

22 (R/W) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 2.

NG >> Repair harness or connector.



NAVIGATION SYSTEM


7. CHECK NAVI CONTROL UNIT INPUT SIGNAL

1. Connect NAVI control unit connector.
2. Turn ignition switch ON.
3. Check voltage between up-and-down unit (display unit) harness connector M95 terminal 5 (R/W) and ground.

5 (R/W) – Ground : Approx. 5V

OK or NG

- OK >> Replace display unit.
 NG >> Replace NAVI control unit.



Color of RGB Image Is Not Proper (Bluish)

1. RGB HARNESS CHECK

1. Turn ignition switch OFF.
2. Disconnect NAVI control unit connector and display unit connector.
3. Check continuity between NAVI control unit harness connector and display unit harness connector.
4. Check continuity between NAVI control unit harness connector and ground.


● **When the screen looks bluish**

| Terminals | | | | Continuity |
|-------------------|-----------------------|--------------|-----------------------|------------|
| NAVI control unit | | Display unit | | |
| Connector | Terminal (Wire color) | Connector | Terminal (Wire color) | |
| M57 | 18 (B) | M35 | 1 (B) | Yes |
| | 17 | | 12 | |

| Terminals | | | Continuity |
|-------------------|-----------------------|--------|------------|
| NAVI control unit | | | |
| Connector | Terminal (Wire color) | | |
| M57 | 18 (B) | Ground | No |
| | 17 | | |

OK or NG

- OK >> GO TO 2.
 NG >> Repair harness or connector.




NAVIGATION SYSTEM

2. RGB SIGNAL CHECK

1. Connect NAVI control unit connector and display unit connector.
2. Turn ignition switch ON.
3. Display "Color bar" by "CONFIRMATION/ADJUSTMENT" mode.
4. Check the signal between NAVI control unit terminal 18 (B) and 17 with CONSULT-II or oscilloscope.

● **When the screen looks bluish**

| Terminals | | | | Voltage (V) |
|-----------------------|-----------------------|-----------------------|----------|---|
| NAVI control unit (+) | | NAVI control unit (-) | | |
| Connector | Terminal (Wire color) | Connector | Terminal | |
| M57 | 18 (B) | M57 | 17 | Refer to AV-61. "Terminals and Reference Value for NAVI Control Unit" . |



OK or NG

- OK >> Replace display unit.
- NG >> Replace NAVI control unit.

Color of RGB Image Is Not Proper (Reddish)


AKS005S6

1. RGB HARNESS CHECK

1. Turn ignition switch OFF.
2. Disconnect NAVI control unit connector and display unit connector.
3. Check continuity between NAVI control unit harness connector and display unit harness connector.
4. Check continuity between NAVI control unit harness connector and ground.

● **When the screen looks reddish.**

| Terminals | | | | Continuity |
|-------------------|-----------------------|--------------|-----------------------|------------|
| NAVI control unit | | Display unit | | |
| Connector | Terminal (Wire color) | Connector | Terminal (Wire color) | |
| M57 | 21 (W) | M35 | 2 (W) | Yes |
| | 17 | | 12 | |



| Terminals | | | | Continuity |
|-------------------|-----------------------|--|--------|------------|
| NAVI control unit | | | | |
| Connector | Terminal (Wire color) | | | |
| M57 | 21 (W) | | Ground | No |
| | 17 | | | |

OK or NG

- OK >> GO TO 2.
- NG >> Repair harness or connector.


NAVIGATION SYSTEM

2. RGB SIGNAL CHECK

1. Connect NAVI control unit connector and display unit connector.
2. Turn ignition switch ON.
3. Display "Color bar" by "CONFIRMATION/ADJUSTMENT" mode.
4. Check the signal between NAVI control unit terminal 21(W) and 17 with CONSULT-II or oscilloscope.

● **When the screen looks reddish**

| Terminals | | | | Voltage (V) |
|-----------------------|-----------------------|-----------------------|----------|---|
| NAVI control unit (+) | | NAVI control unit (-) | | |
| Connector | Terminal (Wire color) | Connector | Terminal | |
| M57 | 21 (W) | M57 | 17 | Refer to AV-61. "Terminals and Reference Value for NAVI Control Unit" . |



OK or NG

- OK >> Replace display unit.
 NG >> Replace NAVI control unit.

Color of RGB Image Is Not Proper (Yellowish)

AKS005S7


1. RGB HARNESS CHECK

1. Turn ignition switch OFF.
2. Disconnect NAVI control unit connector and display unit connector.
3. Check continuity between NAVI control unit harness connector and display unit harness connector.
4. Check continuity between NAVI control unit harness connector and ground.

● **When the screen looks yellowish**

| Terminals | | | | Continuity |
|-------------------|-----------------------|--------------|-----------------------|------------|
| NAVI control unit | | Display unit | | |
| Connector | Terminal (Wire color) | Connector | Terminal (Wire color) | |
| M57 | 15 (R) | M35 | 3 (R) | Yes |
| | 17 | | 12 | |

| Terminals | | | | Continuity |
|-------------------|-----------------------|--|--------|------------|
| NAVI control unit | | | | |
| Connector | Terminal (Wire color) | | | |
| M57 | 15 (R) | | Ground | No |
| | 17 | | | |



OK or NG

- OK >> GO TO 2.
 NG >> Repair harness or connector.


NAVIGATION SYSTEM

2. RGB SIGNAL CHECK

1. Connect NAVI control unit connector and display unit connector.
2. Turn ignition switch ON.
3. Display "Color bar" by "CONFIRMATION/ADJUSTMENT" mode.
4. Check the signal between NAVI control unit terminal 15(R) and 17 with CONSULT-II or oscilloscope.

- **When the screen looks yellowish**

| Terminals | | | | Voltage (V) |
|-----------------------|-----------------------|-----------------------|----------|---|
| NAVI control unit (+) | | NAVI control unit (-) | | |
| Connector | Terminal (Wire color) | Connector | Terminal | |
| M57 | 15 (R) | M57 | 17 | Refer to AV-61. "Terminals and Reference Value for NAVI Control Unit" . |



OK or NG

- OK >> Replace display unit.
- NG >> Replace NAVI control unit.


RGB Screen Is Rolling

AKS003HC

1. RGB SYNCHRONIZING CIRCUIT CHECK

1. Turn ignition switch OFF.
2. Disconnect NAVI control unit connector and display unit connector.
3. Check continuity between NAVI control unit harness connector and display unit harness connector.
4. Check continuity between NAVI control unit harness connector and ground.

| Terminals | | | | Continuity |
|-------------------|-----------------------|--------------|-----------------------|------------|
| NAVI control unit | | Display unit | | |
| Connector | Terminal (Wire color) | Connector | Terminal (Wire color) | |
| M57 | 16 (P) | M35 | 7 (P) | Yes |
| | 17 | | 12 | |



| Terminals | | | | Continuity |
|-------------------|-----------------------|--|--------|------------|
| NAVI control unit | | | | |
| Connector | Terminal (Wire color) | | | |
| M57 | 16 (P) | | Ground | No |
| | 17 | | | |

OK or NG

- OK >> GO TO 2.
- NG >> Repair harness or connector.

NAVIGATION SYSTEM


2. RGB SYNCHRONIZING SIGNAL CHECK

1. Connect NAVI control unit connector and display unit connector.
2. Turn ignition switch ON.
3. Push the "MAP" switch.
4. Check the signal between NAVI control unit harness connector M57 terminals 16 (P) and 17 with CONSULT-II or oscilloscope.

16 (P) - 17 : Refer to [AV-61, "Terminals and Reference Value for NAVI Control Unit"](#) .

OK or NG

- OK >> Replace display unit.
- NG >> Replace NAVI control unit.



PKIB4481E

Guide Sound Is Not Heard

1. CHECK VOICE GUIDE SETTING

- While driving in the dark pink route, voice guide does not operate. (note)
- Is volume setting not switched ON?

NOTE:

Voice guide is only available at intersections that satisfy certain conditions. Therefore, guidance may not be given even when the route on the map changes direction.


YES or NO

- YES >> GO TO 2.
- NO >> Switch the setting ON and turn the volume up.

2. VOICE GUIDE HARNESS CHECK

1. Turn ignition switch OFF.
2. Disconnect NAVI control unit connector and audio unit connector.
3. Check continuity between NAVI control unit harness connector and audio unit harness connector.
4. Check continuity between NAVI control unit harness connector and ground.

| Terminals | | | | Continuity |
|-------------------|-----------------------|------------|-----------------------|------------|
| NAVI control unit | | Audio unit | | |
| Connector | Terminal (Wire color) | Connector | Terminal (Wire color) | |
| M57 | 7 (L/W) | M39 | 32 (L/W) | Yes |
| | 8 (W/B) | | 30 (W/B) | |
| | 9 (B) | | 31 (B) | |
| | 24 (R/B) | | 24 (R/B) | |



PKIB3855E

| Terminals | | | | Continuity |
|-------------------|-----------------------|--------|--|------------|
| NAVI control unit | | | | |
| Connector | Terminal (Wire color) | | | |
| M57 | 7 (L/W) | Ground | | No |
| | 8 (W/B) | | | |
| | 24 (R/B) | | | |

OK or NG

- OK >> GO TO 3.
- NG >>
 - Check harness for open or short between NAVI control unit and audio unit.
 - Check connector housings for disconnected or loose terminals.


3. VOICE GUIDE ON SIGNAL CHECK

1. Connect NAVI control unit connector and audio unit connector.
2. Turn ignition switch ON.
3. Push "VOICE" switch.
4. Check the signal between NAVI control unit harness connector M57 terminal 24 (R/B) and 9 (B) with CONSULT-II or oscilloscope.

24 (R/B) – 9 (B) : Refer to [AV-61, "Terminals and Reference Value for NAVI Control Unit"](#) .

OK or NG

- OK >> GO TO 4.
- NG >> Replace NAVI control unit.




4. VOICE GUIDE SIGNAL CHECK

1. Push the "VOICE" switch.
2. Check the signal between NAVI control unit harness connector M57 terminal 7 (L/W) and 8 (W/B) with CONSULT-II or oscilloscope.

| Terminals | | | Reference Signal |
|-----------|-----------------------|---------|---|
| (+) | | (-) | |
| Connector | Terminal (Wire color) | | |
| M57 | 7 (L/W) | 8 (W/B) | Refer to AV-61, "Terminals and Reference Value for NAVI Control Unit" . |

Ok or NG

- OK >> Replace audio unit.
- NG >> Replace NAVI control unit



No Fuel Information Is Displayed

AKS003HG

1. SELF-DIAGNOSIS CHECK

Perform self-diagnosis. Refer to [AV-68, "Self-Diagnosis Mode"](#) .

Is self-diagnosis result OK?

- YES >> GO TO 2.
- NO >> Check applicable parts.

2. COMBINATION METER CHECK

Using CONSULT-II select "ECM SELF-DIAGNOSIS" to check CAN communication between ECM and combination meter. Refer to [EC-93, "TROUBLE DIAGNOSIS"](#) .

OK or NG

- OK >> Replace combination meter.
- NG >> Check applicable parts.

Vehicle Condition Setting Is Not Possible

AKS003HH

1. VEHICLE SPEED SIGNAL CHECK

Check vehicle speed signal check. Refer to [AV-72, "VEHICLE SIGNALS"](#) .

OK or NG

- OK >> Replace NAVI control unit.
- NG >> Check combination meter system. Refer to [DI-10, "Self-Diagnosis Mode of Combination Meter"](#) .

A
B
C
D
E
F
G
H
I
J
L
M

AV

No Warning Message Is Displayed (Combination Meter Of Warning Lamp Illuminate)

AKS003HI

1. DISPLAY CONDITION CHECK

Check display condition of warning screen.

| Warning screen | Display condition |
|----------------|--|
| Door ajar | When door switch is ON and vehicle speed is more than 5 km/h (3 MPH) |

>> GO TO 2.

2. SELF-DIAGNOSIS CHECK

Perform self-diagnosis. Refer to [AV-68, "Self-Diagnosis Mode"](#) .

Is self-diagnosis result OK?

YES >> Replace combination meter.

NO >> Check applicable parts.

The Position Of The Current-Location Mark Is Not Correct

AKS003HL

1. SELF-DIAGNOSIS

"Self-diagnosis mode" of the self-diagnosis function. Refer to [AV-68, "Self-Diagnosis Mode"](#) .

OK or NG

OK >> GO TO 2.

NG >> Check the applicable parts.

2. HISTORY OF ERRORS DIAGNOSIS

Was any error stored in [AV-73, "HISTORY OF ERRORS"](#) of the CONFIRMATION/ADJUSTMENT mode?

YES or NO

YES >> [AV-73, "HISTORY OF ERRORS"](#).

NO >> [AV-91, "Driving Test"](#).

Radio Wave From The GPS Satellite Is Not Received

AKS003HM

1. ENVIRONMENT CHECK

Check if any metal object that intercepts radio waves or an object that emits radio waves (such as a portable phone) is located near the GPS antenna. Check if the vehicle is shielded by a building.

OK or NG

OK >> ● System is normal.

The GPS antenna may not be able to receive radio waves from the GPS satellite if it is shielded by metal object or an object emitting radio waves is placed near it.

NG >> GO TO 2.

2. SELF-DIAGNOSIS

Perform self-diagnosis function. Refer to [AV-68, "Self-Diagnosis Mode"](#) .

OK or NG

OK >> Replace GPS antenna.

NG >> Check the applicable parts.

Driving Test

AKS003HN

1. DRIVING TEST 1

1. Scroll the map screen to display the area to make correction. Push "ENTER" and select "CURRENT LOCATION CORRECTION".
2. Correct direction of the vehicle mark.
3. Perform the distance correction of the CONFIRMATION/ADJUSTMENT mode.

NOTE:

Normally, adjustment is not necessary because this system has automatic distance correction function. However, when a tire chain is fitted, adjustment in accordance with the tire diameter ratio must be made.

4. Are symptoms applicable to the [AV-92, "Example of Symptoms Judged Not Malfunction"](#) present after driving the vehicle?

YES or NO

- YES >> Limit of the location detection capacity of the navigation system
 NO >> GO TO 2.

2. DRIVING TEST 2

- Did any malfunction occur when the proper test in the following test patterns is performed?
- Test pattern
 - Driving test finds the difference between the symptoms monitored with and without each sensor.
 - Test pattern 1: Test method with no GPS location correction
 Disconnect the GPS antenna connector connected to the NAVI control unit. Accurately adjust the current position and the direction, and then drive the vehicle.
 - Test pattern 2: Test method with no map-matching
 Accurately adjust the current position and the direction. Eject the map DVD-ROM from the NAVI control unit with the ignition switch turned to OFF, and then drive the vehicle. After driving, insert the map DVD-ROM back in the unit, display the track of the vehicle on the map screen and compare it with the actual road configuration.
- Sample tests
 - <To determine if the current-location mark skips at the same position, if so, whether it is caused by map-matching or by GPS>
 Perform test pattern 1.
 - <To determine if the pattern of streets displayed is correct or not>
 Perform test pattern 1 and 2.
 Compare the track of the vehicle on the map screen and the actual road configuration. For fairly accurate tracking, plotting shall be made every several hundred meters.
 - <When the distance is adjusted accurately>
 Perform test pattern 1 and 2.
 Drive on a road of which distance is accurately known (by utilizing distance posts on a highway). Calculate the rate of change (increased/decreased) of the distance by comparing with the actual distance.
 Correction = A/B
 A: Distance shown on the screen
 B: Actual distance

YES or NO

- YES >> ● If adjustment is insufficient, perform adjustment again.
 ● If any error is found in the map, please let us know.
 ● Replace NAVI control unit
- NO >> Limit of the location detection capacity of the navigation system

NAVIGATION SYSTEM

Example of Symptoms Judged Not Malfunction BASIC OPERATION

AKS003HO

| Symptom | Cause | Remedy |
|--|--|---|
| No image is shown. | Display brightness adjustment is set fully to DARK side. | Adjust the display brightness. |
| No guide sound is heard. Audio guide volume is too low or too high. | Volume control is set to OFF, MIN or MAX. | Adjust the audio guide volume. |
| | Audio guidance is not available while the vehicle is driving on a dark pink route. | System is not malfunction. |
| Screen is too dark. Motion of the image is too slow. | Temperature inside the vehicle is low. | Wait until the temperature inside the vehicle reaches the proper temperature. |
| Small black or bright spots appear on the screen. | Symptom peculiar to a liquid crystal display. | System is not malfunction. |

VEHICLE MARK

| Symptom | Cause | Remedy |
|--|--|--|
| Map screen and bird view TM Name of the place vary with the screen. | Some thinning of the character data is done to prevent the display becoming to complex. In some cases and in some locations, the display contents may differ. The same place name, street name, etc. may not be displayed every time on account of the data processing. | System does not malfunction. |
| Vehicle mark is not positioned correctly. | Vehicle is transferred by ferry or by towing after its ignition switch is turned to OFF. | Drive the vehicle for a while in the GPS satellite signal receiving condition. |
| Screen will not switch to nighttime mode after the lighting switch is turned ON. | The daytime screen is selected by the "SWITCH SCREENS" when the last time the screen dimming setting is done. Switching between daytime/nighttime screens may be inhibited by the automatic illumination adjustment function. | Perform screen dimming and select the nighttime screen by "SWITCH SCREENS". |
| Map screen will not scroll in accordance with the vehicle travel. | Current location is not displayed. | Push "MAP" switch to display the current location. |
| Vehicle mark will not be shown. | Current location is not displayed. | Push "MAP" switch to display the current location. |
| Accuracy indicator (GPS satellite mark) on the map screen stays gray. | GPS satellite signal is intercepted because the vehicle is in or behind a building. | Move the vehicle out to an open space. |
| | GPS satellite signal cannot be received because an obstacle is placed on top of the display. | Do not place anything in the center on top of the display. |
| | GPS satellites are located badly. | Wait until the location becomes better. |
| Vehicle location accuracy is low. | Accuracy indicator (GPS satellite mark) on the map screen stays gray. | Current location is not determined. |
| | Vehicle speed setting by the vehicle speed pulse has been deviated (advanced or retarded) from the actual vehicle speed because tire chain is fitted or the system has been used on another vehicle. | Drive the vehicle for a while (for approx. 30 minutes at approx. 30 km/h (19MPH)) and the deviation will be automatically adjusted. If advancement or retard still occur, perform the distance adjustment by CONFIRMATION/ADJUSTMENT mode of diagnosis function. |
| | Map data has error or omission. (Vehicle mark is always deviated to the same position.) | As a rule, an updated map DVD-ROM will be released once a year. |

DESTINATION, PASSING POINTS, AND MENU ITEMS CANNOT BE SELECTED/SET

| Symptom | Cause | Remedy |
|--|--|--|
| Destination cannot be set. | Destination to be set is on an ex-Pathway. | Set the destination on an ordinary road. |
| Passing point is not searched when re-searching the route. | The vehicle has already passed the passing point, or the system judged so. | To include the passing points that have been passed into the route again, set the route again. |

NAVIGATION SYSTEM

| Symptom | Cause | Remedy |
|---|--|---|
| Route information will not be displayed. | Route searching has not been done. | Set the destination and perform route searching. |
| | Vehicle mark is not on the recommended route. | Drive on the recommended route. |
| | Route guide is turned OFF. | Turn the route guide ON. |
| | Route information is not available on the dark pink route. | System is not malfunction. |
| After the route searching, no guide sign will appear as the vehicle goes near the entrance/exit to the toll road. | Vehicle mark is not on the recommended route. (On the display, only guide signs related to the recommended route will be shown.) | Drive on the recommended route. |
| Automatic route searching is not possible. | Vehicle is driving on a highway (gray route), or no recommended route is available. | Drive on a road to be searched. Or re-search the route manually. In this case, however, the whole route will be searched. |
| Performed automatic detour search (or detour search). However, the result is the same as that of the previous search. | Performed search with every condition considered. However, the result is the same as that of the previous search. | System is not malfunction. |
| Passing points cannot be set. | More than five passing points were set. | Passing points can be set up to five. To stop at more than five points, perform sharing in several steps. |
| When setting the route, the starting point cannot be selected. | The current vehicle location is always set as the starting point of a route. | System is not malfunction. |
| Some menu items cannot be selected. | The vehicle is being driven. | Stop the vehicle at a safe place and then operate the system. |

VOICE GUIDE

| Symptom | Cause | Remedy |
|---|--|---|
| Voice guide will not operate. | Note: Voice guide is only available at intersections that satisfy certain conditions. Therefore, guidance may not be given even when the route on the map changes direction. | System is not malfunction. |
| | The vehicle is not on the recommended route. | Return to the recommended route or re-search the route. |
| | Voice guide is turned OFF. | Turn the voice guide ON. |
| | Route guide is turned OFF. | Turn the route guide ON. |
| Voice guide does not match the actual road pattern. | Voice guide may vary with the direction to which the vehicle is turn and the connection of the road to other roads. | Drive in conformity to the actual traffic rules. |

NAVIGATION SYSTEM

ROUTE SEARCHING

| Symptom | Cause | Remedy |
|--|--|---|
| No route is shown. | No road to be searched is found around the destination. | Find wider road (orange road or wider) nearby and reset the destination and passing points onto it. Take care of the traveling direction when there are separate up and down roads. |
| | Starting point and the destination are too close. | Set the destination at more distant point. |
| | Conditional traffic regulation (day of the week/ time of the day) is set at the area around the current position or the destination. | Turn the time-regulating search conditions OFF. Turn "Avoid regulation time" in the search conditions OFF. |
| Indicated route is intermittent. | In some areas, highways (gray routes) are not used for the search ^(Note) . Therefore, the route to the current position or the passing points may be intermittent. | System is not malfunction. |
| When the vehicle has passed the recommended route, it is deleted from the screen. | A recommended route is controlled by each section. When the vehicle has passed the passing point 1, then the map data from the starting point up to the passing point 1 will be deleted. (The data may remain undeleted in some area.) | System is not malfunction. |
| Detouring route is recommended. | In some areas, highways (gray routes) are not used for the search. (Note). Therefore, detour route may be recommended. | Set the route closer to the basic route (gray route). |
| | A detour route may be shown when some traffic regulation (one-way traffic, etc.) is set at the area around the starting point or the destination. | Slightly move the starting point or the destination, or set the passing point on the route of your choice. |
| | In the area where highways (gray routes) are used for the search, left turn has priority around the current position and the destination (passing points). For this reason, the recommended route may be detouring. | System is not malfunction. |
| Landmarks on the map do not match the actual ones. | This can be happen due to omission or error in the map data. | As a rule, an updated map DVD-ROM will be released once a year. Wait until the latest map has become available. |
| Recommended route is far from the starting point, passing points, and destination. | Starting point, passing points, and destination of the route guide were set far from the desired points because route searching data around these area were not stored. | Reset the destination onto the road nearby. If this road is one of the highways (gray routes), an ordinary road nearby may be displayed as the recommended route. |


NOTE:

Except for the ordinance-designated cities and the prefectural capitals (Applicable areas may be changed in the updated map disc.)

NAVIGATION SYSTEM

EXAMPLES OF CURRENT-LOCATION MARK DISPLACEMENT

Vehicle's travel amount is calculated by reading its travel distance and turning angle. Therefore, if the vehicle is driven in the following manner, an error will occur in the vehicle's current location display. If correct location has not been restored after driving the vehicle for a while, perform location correction.









A
B
C
D
E
F
G
H
I
J





AV

L
M

NAVIGATION SYSTEM

| | Cause (condition) -: While driving ooo: Display | Driving condition | Remarks (correction, etc.) |
|-----------------------|---|--|---|
| Road configuration | <p>Y-intersections</p>  <p style="text-align: center; font-size: small;">ELK0192D</p> | <p>At a Y intersection or similar gradual division of roads, error the direction of travel deduced by the sensor may result in the current-location mark appearing on the wrong road.</p> | |
| | <p>Spiral roads</p>  <p style="text-align: center; font-size: small;">ELK0193D</p> | <p>When driving on a large, continuous spiral road (such as loop bridge), turning angle error is accumulated and the vehicle mark may deviate from the correct location.</p> | |
| | <p>Straight roads</p>  <p style="text-align: center; font-size: small;">ELK0194D</p> | <p>When driving on a long, straight road and slow curve without stopping, map-matching does not work effectively enough and distance errors may accumulate. As a result, the vehicle mark may deviate from the correct location when the vehicle turned at a corner.</p> | <p>If after traveling about 10 km (6miles) the correct location has not been restored, perform location correction and, if necessary, direction correction.</p> |
| | <p>Zigzag roads</p>  <p style="text-align: center; font-size: small;">ELK0195D</p> | <p>When driving on a zigzag road, the map may be matched to other roads in the similar direction nearby at every turn, and the vehicle mark may deviate from the correct location.</p> | |
| | <p>Roads laid out in a grid pattern</p>  <p style="text-align: center; font-size: small;">ELK0196D</p> | <p>When driving at where roads are laid out in a grid pattern, where many roads are running in the similar direction nearby, the map may be matched to them by mistake and the vehicle mark may deviate from the correct location.</p> | |
| | <p>Parallel roads</p>  <p style="text-align: center; font-size: small;">ELK0197D</p> | <p>When two roads are running in parallel (such as highway and sideway), the map may be matched to the other road by mistake and the vehicle mark may deviate from the correct location.</p> | |



NAVIGATION SYSTEM

| Cause (condition) -: While driving ooo: Display | | Driving condition | Remarks (correction, etc.) |
|---|--|---|---|
| Place | <p>In a parking lot</p>  <p style="text-align: right; font-size: small;">SEL709V</p> | <p>When driving in a parking lot, or other location where there are no roads on the map, matching may place the vehicle mark on a nearby road. When the vehicle returns to the road, the vehicle mark may have deviated from the correct location.</p> <p>When driving in circle or turning the steering wheel repeatedly, direction errors accumulate, and the vehicle mark may deviate from the correct location.</p> | <p>If after traveling about 10km (6miles) the correct location has not been restored, perform location correction and, if necessary, direction correction.</p> |
| | <p>Turn table</p>  <p style="text-align: right; font-size: small;">SEL710V</p> | <p>When the ignition switch is OFF, the navigation system cannot get the signal from the gyroscope (angular speed sensor). Therefore, the displayed direction may be wrong and the correct road may not be easily returned to after rotating the vehicle on a turn table with the ignition OFF.</p> | |
| | <p>Slippery roads</p> | <p>On snow, wet roads, gravel, or other roads where tires may slip easily, accumulated mileage errors may cause the vehicle mark to deviate from the correct road.</p> | |
| | <p>Slopes</p> | <p>When parking in sloped garages, when traveling on banked roads, or in other cases where the vehicle turns when tilted, an error in the turning angle will occur, and the vehicle mark may deviate from the road.</p> | |
| | <p>Road not displayed on the map screen</p>  <p style="text-align: right; font-size: small;">SEL699V</p> | <p>When driving on new roads or other roads not displayed on the map screen, map matching does not function correctly and matches the location to a nearby road. When the vehicle returns to a road which is on the map, the vehicle mark may deviate from the correct road.</p> | |
| Map data | <p>Different road pattern (Changed due to repair)</p>  <p style="text-align: right; font-size: small;">ELK0201D</p> | <p>If the road pattern stored in the map data and the actual road pattern are different, map matching does not function correctly and matches the location to a nearby road. The vehicle mark may deviate from the correct road.</p> | |
| Vehicle | <p>Use of tire chains</p> | <p>When tire chains are used, the mileage is not correctly detected, and the vehicle mark may deviate from the correct road.</p> | <p>Drive the vehicle for a while. If the distance is still deviated, adjust it by using the distance adjustment function. (If the tire chain is removed, recover the original value.)</p> |

A
B
C
D
E
F
G
H
I
J
L
M

AV

NAVIGATION SYSTEM

| Cause (condition) -: While driving ooo: Display | Driving condition | Remarks (correction, etc.) |
|---|---|---|
| Precautions for driving | Just after the engine is started | If the vehicle is driven off just after the engine is started when the gyroscope (angular speed sensor) correction is not completed, the vehicle can lose its direction and may have deviated from the correct location. |
| | Continuous driving without stopping | When driving long distances without stopping, direction errors may accumulate, and the current-location mark may deviate from the correct road. |
| | Abusive driving | Spinning the wheels or engaging in other kinds of abusive driving may result in the system being unable perform correct detection, and may cause the vehicle mark to deviate from the correct road. |
| How to correct location | Position correction accuracy  SEL701V | If the accuracy of location settings is poor, accuracy may be reduced when the correct road cannot be found, particularly in places where there are many roads. Enter in the road displayed on the screen with an accuracy of approx. 1mm. Caution: Whenever possible, use detailed map for the correction. |
| | Direction when location is corrected  SEL702V | If the accuracy of location settings during correction is poor, accuracy may be reduced afterwards. Perform direction correction. |

THE CURRENT POSITION MARK SHOWS A POSITION WHICH IS COMPLETELY WRONG

In the following cases, the current-location mark may appear on completely different position in the map depending on the GPS satellite signal receiving conditions. In this case, perform location correction and direction correction.

- When location correction has not been done
 - If the receiving conditions of the GPS satellite signal is poor, if the current-location mark becomes out of place, it may move to a completely different location and not come back if location correction is not done. The position will be corrected if the GPS signal can be received.
- When the vehicle has traveled by ferry, or when the vehicle has been being towed
 - Because calculation of the current location cannot be done when traveling with the ignition OFF, for example when traveling by ferry or when being towed, the location before travel is displayed. If the precise location can be detected with GPS, the location will be corrected.

THE CURRENT POSITION MARK JUMPS

In the following cases, the current-location mark may appear to jump as a result of automatic correction of the current location.

- When map matching has been done
 - If the current location and the current-location mark are different when map matching is done, the current-location mark may seem to jump. At this time, the location may be “corrected” to the wrong road or to a location which is not on a road.
- When GPS location correction has been done
 - If the current location and the current-location mark are different when the location is corrected using GPS measurements, the current-location mark may seem to jump. At this time, the location may be “corrected” to a location which is not on a road.

NAVIGATION SYSTEM

THE CURRENT LOCATION MARK IS IN A RIVER OR THE SEA

The navigation system moves the current location mark with no distinction between land and rivers or sea. If the location mark is somehow out of place, it may appear that the vehicle is driving in a river or the sea.

WHEN DRIVING ON THE SAME ROAD, SOMETIMES THE CURRENT-LOCATION MARK IS IN THE RIGHT PLACE AND SOMETIMES IT IS THE WRONG PLACE

The conditions of the GPS antenna (GPS data) and gyroscope (angular speed sensor) change gradually. Depending on the road traveled and the operation of the steering wheel, the location detection results will be different. Therefore, even on a road on which the location has never been wrong, conditions may cause the vehicle mark to deviate.

LOCATION CORRECTION BY MAP MATCHING IS SLOW

- The map matching function needs to refer to the data of the surrounding area. It is necessary to drive some distance for the function to work.
- Because map matching operates on this principle, when there are many roads running in similar directions in the surrounding area, no matching determination may be made. The location may not be corrected until some special feature is found.

ALTHOUGH THE GPS RECEIVING DISPLAY IS GREEN, THE VEHICLE MARK DOES NOT RETURN TO THE CORRECT LOCATION

- The GPS accuracy has an error of about 10 m (30ft). In some cases the current-location mark may not be on the correct street, even when GPS location-correction is done.
- The navigation system compares the results of GPS location detection with the results from map-matching location detection. The one which is determined to have higher accuracy is used.
- GPS location correction may not be performed when the vehicle is stopped.

THE NAME OF THE CURRENT PLACE IS NOT DISPLAYED

The current place name may not be displayed if there are no place names displayed on the map screen.

CONTENTS OF THE DISPLAY DIFFER FOR THE BIRD VIEW™ AND THE (FLAT) MAP SCREEN.

Difference of the Bird View™ Screen From the Flat Map Screen Are As Follows

- The current place name displays names which are primarily in the direction of vehicle travel.
- The amount of time before the vehicle travel or turn angle is updated on the screen is longer than for the (flat) map display.
- The conditions for display of place names, roads, and other data are different for nearby areas and for more distant areas.
- Some thinning of the character data is done to prevent the display becoming too complex. In some cases and in some locations, the display contents may differ.
- The same place name, street name, etc. may be displayed multiple times.


A
B
C
D
E
F
G
H
I
J
L
M

AV

NAVIGATION SYSTEM

Program Loading

AKS003HP



NOTE: Always load a program with the engine running.

SKIA2165E


NAVIGATION SYSTEM

Removal and Installation of NAVI Control Unit


AKS00CVM

REMOVAL

1. Remove center box assy. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#) .
2. Remove screws (4), and remove NAVI control unit.



3. Remove screws (4), and remove bracket.



INSTALLATION


Installation is the reverse order of removal.

Removal and Installation of GPS Antenna


AKS00CVN

REMOVAL

1. Remove instrument panel and antenna feeder installation screws on backside. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#) .



2. Remove screw and remove GPS antenna.



INSTALLATION

Installation is the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
AV
L
M


NAVIGATION SYSTEM

Removal and Installation of NAVI Switch

AKS00CVO

REMOVAL

1. Remove cluster lid C. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#) .
2. Remove audio unit and display unit assembly. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#) .
3. Remove screws (2) and remove NAVI switch from cluster lid C.



INSTALLATION


Installation is the reverse order of removal.

Removal and Installation of Display Unit

AKS00CVP

REMOVAL

1. Remove cluster lid C. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#) .
2. Remove audio unit and display unit assembly from cluster lid C. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#) .
3. Remove screws (5) and remove display unit assembly from audio unit bracket.



INSTALLATION

Installation is the reverse order of removal.