

SECTION **SE**
SEAT

A
B
C

CONTENTS

BASIC INSPECTION	4	HEATED SEAT CONTROL UNIT : Diagnosis Procedure	12	F
DIAGNOSIS AND REPAIR WORK FLOW	4	HEATED SEAT SWITCH	14	G
Work Flow	4	HEATED SEAT SWITCH : Diagnosis Procedure	14	
SYSTEM DESCRIPTION	5	HEATED SEAT SWITCH	17	
POWER SEAT	5	DRIVER SIDE	17	H
System Description	5	DRIVER SIDE : Description	17	
Component Parts Location	5	DRIVER SIDE : Component Function Check	17	
Component Description	5	DRIVER SIDE : Diagnosis Procedure	17	I
TILT&TELESCOPIC SYSTEM	6	DRIVER SIDE : Component Inspection	18	
System Description	6	PASSENGER SIDE	18	SE
Component Parts Location	6	PASSENGER SIDE : Description	18	
Component Description	7	PASSENGER SIDE :		
SIDE SUPPORT	8	Component Function Check	18	K
System Description	8	PASSENGER SIDE : Diagnosis Procedure	19	
Component Parts Location	8	PASSENGER SIDE : Component Inspection	20	L
Component Description	8	HEATED SEAT RELAY	21	
HEATED SEAT	9	Description	21	M
System Diagram	9	Component Function Check	21	
System Description	9	Diagnosis Procedure	21	
Component Parts Location	10	Component Inspection	22	N
Component Description	10	HEAT SENSOR	23	
LUMBAR SUPPORT	11	DRIVER SIDE	23	O
System Description	11	DRIVER SIDE : Description	23	
Component Parts Location	11	DRIVER SIDE : Component Function Check	23	
Component Description	11	DRIVER SIDE : Diagnosis Procedure	23	P
DTC/CIRCUIT DIAGNOSIS	12	DRIVER SIDE : Component Inspection	24	
POWER SUPPLY AND GROUND CIRCUIT	12	PASSENGER SIDE	25	
AUTOMATIC DRIVE POSITIONER CONTROL UNIT	12	PASSENGER SIDE : Description	25	
AUTOMATIC DRIVE POSITIONER CONTROL UNIT : Diagnosis Procedure	12	PASSENGER SIDE : Component Function Check	25	
HEATED SEAT CONTROL UNIT	12	PASSENGER SIDE : Diagnosis Procedure	25	
		PASSENGER SIDE : Component Inspection	27	
		SEAT CUSHION HEATER	28	

D

E

F

G

H

I

SE

K

L

M

N

O

P

DRIVER SIDE	28	LUMBAR SUPPORT	49
DRIVER SIDE : Description	28	Wiring Diagram - LUMBAR SUPPORT SYSTEM -...	49
DRIVER SIDE : Component Function Check	28	SIDE SUPPORT	52
DRIVER SIDE : Diagnosis Procedure	28	Wiring Diagram - SIDE SUPPORT SYSTEM -	52
DRIVER SIDE : Component Inspection	29	TILT & TELESCOPIC SYSTEM	55
PASSENGER SIDE	29	Wiring Diagram - TILT&TELESCOPIC SYSTEM -...	55
PASSENGER SIDE : Description	29	ECU DIAGNOSIS INFORMATION	58
PASSENGER SIDE :		AUTOMATIC DRIVE POSITIONER CON-	
Component Function Check	29	TROL UNIT	58
PASSENGER SIDE : Diagnosis Procedure	29	Reference Value	58
PASSENGER SIDE : Component Inspection	31	Wiring Diagram - AUTOMATIC DRIVE POSI-	
SEATBACK HEATER	32	TIONER CONTROL SYSTEM -	62
DRIVER SIDE	32	HEATED SEAT CONTROL UNIT	71
DRIVER SIDE : Description	32	DRIVER SIDE	71
DRIVER SIDE : Component Function Check	32	DRIVER SIDE : Reference Value	71
DRIVER SIDE : Diagnosis Procedure	32	DRIVER SIDE : Wiring Diagram - HEATED SEAT	
PASSENGER SIDE	32	SYSTEM (WITH M/T) -	72
PASSENGER SIDE : Description	32	DRIVER SIDE : Wiring Diagram - HEATED SEAT	
PASSENGER SIDE :		SYSTEM (WITH A/T) -	78
Component Function Check	32	PASSENGER SIDE	82
PASSENGER SIDE : Diagnosis Procedure	32	PASSENGER SIDE : Reference Value	83
HEATED SEAT SWITCH INDICATOR	34	PASSENGER SIDE : Wiring Diagram - HEATED	
DRIVER SIDE	34	SEAT SYSTEM (WITH M/T) -	84
DRIVER SIDE : Description	34	PASSENGER SIDE : Wiring Diagram - HEATED	
DRIVER SIDE : Component Function Check	34	SEAT SYSTEM (WITH A/T) -	90
DRIVER SIDE : Diagnosis Procedure	34	SYMPTOM DIAGNOSIS	95
PASSENGER SIDE	34	HEATED SEAT DOES NOT OPERATE	95
PASSENGER SIDE : Description	34	BOTH SIDES	95
PASSENGER SIDE :		BOTH SIDES : Diagnosis Procedure	95
Component Function Check	34	DRIVER SIDE	95
PASSENGER SIDE : Diagnosis Procedure	34	DRIVER SIDE : Diagnosis Procedure	95
TILT&TELESCOPIC SWITCH	36	PASSENGER SIDE	96
Description	36	PASSENGER SIDE : Diagnosis Procedure	96
Component Function Check	36	SEATBACK HEATER ONLY DOES NOT OP-	
Diagnosis Procedure	36	ERATE	97
Component Inspection	37	DRIVER SIDE	97
TILT&TELESCOPIC MOTOR	39	DRIVER SIDE : Diagnosis Procedure	97
Description	39	PASSENGER SIDE	97
Component Function Check	39	PASSENGER SIDE : Diagnosis Procedure	97
Diagnosis Procedure	39	CANNOT ADJUST HEATED SEAT TEMPER-	
Component Inspection	40	ATURE	98
TILT&TELESCOPIC SENSOR	41	DRIVER SIDE	98
Description	41	DRIVER SIDE : Diagnosis Procedure	98
Component Function Check	41	PASSENGER SIDE	98
Diagnosis Procedure	41	PASSENGER SIDE : Diagnosis Procedure	98
POWER SEAT	43		
Wiring Diagram - POWER SEAT SYSTEM (DRIV-			
ER SIDE) -	43		
Wiring Diagram - POWER SEAT SYSTEM (PAS-			
SENGER SIDE) -	46		

HEATED SEAT SWITCH INDICATOR DOES NOT TURN ON	99	Special Service Tool	111	
		Commercial Service Tool	111	A
DRIVER SIDE	99	REMOVAL AND INSTALLATION	112	
DRIVER SIDE : Diagnosis Procedure	99	FRONT SEAT	112	B
PASSENGER SIDE	99	Exploded View	112	
PASSENGER SIDE : Diagnosis Procedure	99	Removal and Installation	115	C
STEERING POSITION FUNCTION DOES NOT OPERATE	100	Disassembly and Assembly	116	
Diagnosis Procedure	100	REAR SEAT	124	D
TILT FUNCTION DOES NOT OPERATE	101	Exploded View	124	
Diagnosis Procedure	101	Removal and Installation	125	D
TELESCOPIC FUNCTION DOES NOT OPERATE	102	Disassembly and Assembly	125	
Diagnosis Procedure	102	AUTOMATIC DRIVE POSITIONER CONTROL UNIT	127	E
SQUEAK AND RATTLE TROUBLE DIAGNOSES	103	Removal and Installation	127	
Work Flow	103	HEATED SEAT CONTROL UNIT	128	F
Inspection Procedure	105	Exploded View	128	
Diagnostic Worksheet	107	Removal and Installation	128	G
PRECAUTION	109	POWER SEAT SWITCH	129	
PRECAUTIONS	109	Removal and Installation	129	H
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	109	SIDE SUPPORT SWITCH	130	
Service Notice	109	Removal and Installation	130	
Precaution for Work	109	LUMBAR SUPPORT SWITCH	131	I
PREPARATION	111	Removal and Installation	131	
PREPARATION	111	TILT&TELESCOPIC SWITCH	132	SE
		Removal and Installation	132	
		HEATED SEAT SWITCH	133	K
		Exploded View	133	
		Removal and Installation	133	L
				M
				N
				O
				P

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000004240955

DETAILED FLOW

1.OBTAIN INFORMATION ABOUT SYMPTOM

Interview the customer to obtain the malfunction information (conditions and environment when the malfunction occurred) as much as possible when the customer brings the vehicle in.

>> GO TO 2.

2.REPRODUCE THE MALFUNCTION INFORMATION

Check the malfunction on the vehicle that the customer describes.
Inspect the relation of the symptoms and the condition when the symptoms occur.

>> GO TO 3.

3.IDENTIFY THE MALFUNCTIONING SYSTEM WITH "SYMPTOM DIAGNOSIS"

Use "Symptom diagnosis" from the symptom inspection result in step 2. Then identify where to start performing the diagnosis based on possible causes and symptoms.

>> GO TO 4.

4.IDENTIFY MALFUNCTIONING PARTS WITH "COMPONENT DIAGNOSIS"

Perform the diagnosis with "Component diagnosis" of the applicable system.

>> GO TO 5.

5.REPAIR OR REPLACE THE MALFUNCTIONING PARTS

Repair or replace the specified malfunctioning parts.

>> GO TO 6.

6.FINAL CHECK

Is the malfunctioning part repaired or replaced?
(Check that malfunctions are not reproduced when obtaining the malfunction information from the customer, referring to the symptom inspection result in step 2.)

YES or NO

YES >> Trouble diagnosis is completed.
NO >> GO TO 2.

POWER SEAT

< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

POWER SEAT

System Description

INFOID:000000004240956

BCM can operate regardless of the ignition switch position, because battery power is supplied at all times to power seat switch.

SLIDING OPERATION

While operating the sliding switch located in power seat switch, sliding motor operates and makes possible the seat front and back position adjustment.

RECLINING OPERATION


While operating the reclining switch located in power seat switch, reclining motor operates and makes possible the seat back forward and backward position adjustment.

LIFTING OPERATION

While operating the lifting switch located in power seat switch, lifting motor operates and makes possible the seat cushion up and down position adjustment.

Component Parts Location

INFOID:000000004240957



- | | | |
|---|--|---|
| 1. Sliding switch and lifting switch
B414 (driver side)
B434 (passenger side) | 2. Reclining switch
B414 (driver side)
B434 (passenger side) | 3. Reclining motor
B415 (driver side)
B435 (passenger side) |
| 4. Lifting motor (rear)
B418 (driver side)
B438 (passenger side) | 5. Sliding motor
B416 (driver side)
B436 (passenger side) | 6. Lifting motor (front)
B417 (driver side)
B437 (passenger side) |
| A. View with seat cushion pad and seat back pad are removed. | B. View with back side of seat cushion. | |

Component Description

INFOID:000000004240958

Item	Function
BCM	Supplies at all times the power received from battery to power seat switch.
Power seat switch	Built-in reclining switch, sliding switch and lifting switch, controls the power supplied to each motor.
Reclining motor	With the power supplied to power seat switch, operates the forward and backward movement of seatback.
Sliding motor	With the power supplied to power seat switch, operates the forward and backward slide of seat.
Lifting motor (front/rear)	With the power supplied to power seat switch, operates the up and down movement of seat cushion.

TILT&TELESCOPIC SYSTEM

< SYSTEM DESCRIPTION >

TILT&TELESCOPIC SYSTEM

System Description

INFOID:000000004240959

Power from battery is supplied at all times to automatic driver positioner control unit, tilt and telescopic system can operate regardless of the ignition switch position.

TILT OPERATION


- While operating the tilt and telescopic switch, tilt motor operates, and allows up or down position adjustment of steering wheel.
- During tilt motor operation tilt sensor detects the position of steering wheel and automatically cuts the power when the operation limit is reached.

TELESCOPIC OPERATION

- Operating the tilt and telescopic switch, telescopic motor operates and allows forward and backward position regulation of steering wheel.
- During telescopic motor operation telescopic sensor detects the position of steering wheel and automatically cuts the power when the operation limit is reached.

Component Parts Location

INFOID:000000004240960



JMJIA0188ZZ

1. Automatic drive positioner control unit M51, M52

4. Tilt sensor M48

A. View with instrument driver lower panel is removed.

D. View with steering column cover is removed.

2. Tilt & telescopic switch M31

5. Telescopic motor M49

B. Steering column cover

E. View with instrument lower cover is removed.

3. Telescopic sensor M48

6. Tilt motor M49

C. View with steering column cover is removed.

TILT&TELESCOPIC SYSTEM

< SYSTEM DESCRIPTION >

Component Description

INFOID:000000004240961

Item	Function
Automatic drive positioner control unit	Detects data input signal of tilt and telescopic switch and tilt and telescopic sensor, performs tilt and telescopic motor control.
Tilt and telescopic switch	Tilt switch and telescopic switch, as a unit, transmit switch operation signal to automatic drive positioner control unit.
Tilt and telescopic motor	Operates with the power received from automatic drive control unit.
Tilt and telescopic sensor	Detects the position of steering, send signal to automatic drive positioner control unit.

A

B

C

D

E

F

G

H

I

SE

K

L

M

N

O

P

SIDE SUPPORT

< SYSTEM DESCRIPTION >

SIDE SUPPORT


System Description

INFOID:000000004240962

- While operating the side support switch, the pump located inside side support unit operates and adjust the air pressure in seat cushion and seatback side support.
- It is possible to soften the side support, by allowing some air to escape, by deflating the solenoid located inside side support.
- It is possible to adjust seat cushion and seatback differently while inflating or deflating solenoid located in side support unit.

Component Parts Location

INFOID:000000004240963



- | | | |
|--|---|---------------------------|
| 1. Side support (seat cushion)
(Side support unit B465) | 2. Side support (seat back)
(Side support unit B465) | 3. Side support unit B465 |
| 4. Side support switch (seat back side)
B464 | 5. Side support switch (cushion side)
B464 | |

A. View with seat cushion pad and seat back pad are removed.

Component Description

INFOID:000000004240964


Item	Function
Side support switch	With a built-in cushion side and seat back side, controls the power supplied to pump and to each solenoid.
Side support unit	Built-in pump, pump relay and solenoid, operates when pressing ON/OFF on side support switch.

HEATED SEAT

< SYSTEM DESCRIPTION >

HEATED SEAT

System Diagram



System Description

INFOID:000000004535416

- Heated seat is activated by heated seat switch while ignition switch is ON, and has the function to warm seat cushion and seatback.
- Heated seat equips the 6-stage temperature adjustment function that adjusts temperature by operating heated seat switch to the optimal position.
- Heated seat equips a thermostat in heater unit to prevent heater unit overheating.

OPERATION DESCRIPTION

- When operating heated seat switch to any position between 1 and 6 while ignition switch is ON, indicator illuminates, heated seat control unit supplies power supply to heater unit, and warms seat cushion and seatback.
- Heat sensor that is built in seat cushion heater detects seat cushion heater temperature and outputs to heated seat control unit.
- Heated seat control unit monitors the heated seat switch position and heater sensor temperature, and interrupts power supply to heater unit when the heat sensor temperature reaches preset temperature.
- Heated seat control unit adjusts temperature to preset temperature by supplying or interrupting power supply to heater unit.


A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

HEATED SEAT

< SYSTEM DESCRIPTION >

Component Parts Location

INFOID:000000004535417



- | | | |
|---|---|---|
| <p>1. Heated seat switch</p> <ul style="list-style-type: none"> • Driver side - With A/T M141 - With M/T M175 • Passenger side - With A/T M142 - With M/T M176 <p>4. Seat cushion heater</p> <ul style="list-style-type: none"> • Driver side B467, B424 • Passenger side B441, B444 <p>A. Behind cluster lid C</p> | <p>2. Heated seat relay M70</p> <p>5. Heated seat control unit</p> <ul style="list-style-type: none"> • Driver side B466 • Passenger side B440 <p>B. Backside of seat cushion</p> | <p>3. Seatback heater</p> <ul style="list-style-type: none"> • Driver side B425 • Passenger side B445 |
|---|---|---|

Component Description

INFOID:000000004535418

Item	Function
Heated seat switch	<ul style="list-style-type: none"> • Adjusts heated seat temperature and deactivates heated seat • Equips indicator that indicates the operating condition
Seat cushion heater	<ul style="list-style-type: none"> • Warms seat cushion • Contains heater sensor that outputs seat cushion temperature to heated seat control unit
Seatback heater	Warms seatback
Heated seat control unit	Controls heated seat temperature and is independently placed in each seat cushion (driver seat and passenger seat)

LUMBAR SUPPORT

< SYSTEM DESCRIPTION >

LUMBAR SUPPORT


System Description

INFOID:000000004240968

- Lumbar support can operate regardless of the ignition switch position because battery power is supplied to it at all times.
- While operating the lumbar support switch, lumbar support motor operates which allows forward and backward operation of seatback support.

Component Parts Location

INFOID:000000004240969



1. Lumbar support switch B457

2. Lumbar support motor B458

Component Description

INFOID:000000004240970

Item	Function
Lumbar support switch	Controls the power supplied to lumbar support motor.
Lumbar support motor	With the power supplied to lumbar support switch, operates the forward and backward movement of seatback support device.

A

B

C

D

E

F

G

H

I

SE

K

L

M

N

O

P

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

AUTOMATIC DRIVE POSITIONER CONTROL UNIT : Diagnosis Procedure

INFOID:000000004535423

1.CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not fusing.

Terminal No.	Signal name	Fuse and fusible link No.
39	Battery power supply	K (40 A)
34		10 (10 A)

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace the blown fuse and fusible link after repairing the affected circuit if fuse and fusible link are blown.

2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check voltage between automatic drive positioner control unit harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Automatic drive positioner control unit	Connector		
	Terminal	Ground	Battery voltage
	34		
	39		

Is the inspection result normal?

YES >> GO TO 3.

NO-1 >> Repair or replace harness.

NO-2 >> Check circuit breaker, and replace if NG.

3.CHECK GROUND CIRCUIT

Check continuity between automatic drive positioner control unit harness connector and ground.

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M52	40		Existed
	48		

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace harness.

HEATED SEAT CONTROL UNIT

HEATED SEAT CONTROL UNIT : Diagnosis Procedure

INFOID:000000004535424

1.CHECK FUSE

Check that the following fuses is not fusing.

Signal name	Fuse No.
Battery power supply	35 (15A)

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.

2.CHECK POWER SUPPLY 1

1. Turn ignition switch OFF.
2. Disconnect heated seat control unit connector.
3. Turn ignition switch ON.
4. Check voltage between heated seat control unit harness connector and ground.

(+)			(-)	Voltage (V) (Approx.)
Heated seat control unit				
Connector		Terminal	Ground	Battery voltage
Driver side	B466	67		
Passenger side	B440	14		

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 3.

3.CHECK POWER SUPPLY CIRCUIT 1

1. Turn ignition switch OFF.
2. Disconnect heated seat relay.
3. Check continuity between heated seat control unit harness connector and heated seat relay terminal connector.

Heated seat control unit			Heated seat relay		Continuity
Connector		Terminal	Connector	Terminal	
Driver side	B466	67	M70	3	Existed
Passenger side	B440	14			

4. Check continuity between heated seat control unit harness connector and ground.

Heated seat control unit			Ground	Continuity
Connector		Terminal		
Driver side	B466	67		Not existed
Passenger side	B440	14		

Is the inspection result normal?

YES >> Repair or replace harness between heated seat relay and fuse holder.

NO >> Repair or replace harness between heated seat control unit and heated seat relay.

4.CHECK POWER SUPPLY 2

Check voltage between heated seat control unit harness connector and ground.

(+)			(-)	Condition	Voltage (V) (Approx.)		
Heated seat control unit							
Connector		Terminal	Ground	Heated seat switch			
Driver side	B466	69				ON	Battery voltage
						OFF	0
Passenger side	B440	16				ON	Battery voltage
			OFF	0			

Is the inspection result normal?

YES >> GO TO 7.

NO >> GO TO 5.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

5. CHECK POWER SUPPLY CIRCUIT 2

1. Turn ignition switch OFF.
2. Disconnect heated seat switch connector.
3. Check continuity between heated seat control unit harness connector and heated seat switch harness connector.

Heated seat control unit		Heated seat switch		Continuity
Connector	Terminal	Connector	Terminal	
Driver side	B466	69	A/T models: M141 M/T models: M175	1 Existed
Passenger side	B440	16	A/T models: M142 M/T models: M176	

4. Check continuity between heated seat control unit harness connector and ground.

Heated seat control unit		Ground	Continuity
Connector	Terminal		
Driver side	B466	69	Not existed
Passenger side	B440	16	

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace harness.

6. CHECK HEATED SEAT SWITCH

Check heated seat switch.

- Driver side: Refer to [SE-18, "DRIVER SIDE : Component Inspection"](#).
- Passenger side: Refer to [SE-20, "PASSENGER SIDE : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 8.

NO >> Replace heated seat switch. Refer to [SE-133, "Removal and Installation"](#).

7. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between heated seat control unit harness connector and ground.

Heated seat control unit		Ground	Continuity
Connector	Terminal		
Driver side	B466	48	Existed
Passenger side	B440	2	

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace harness.

8. CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

HEATED SEAT SWITCH

HEATED SEAT SWITCH : Diagnosis Procedure

INFOID:000000004535425

1. CHECK FUSE

Check that the following fuses is not fusing.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Terminal No.	Signal name	Fuse No.
5	Ignition power supply	3 (10A)

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.

2. CHECK POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect heated seat switch connector.
3. Turn ignition switch ON.
4. Check voltage between heated seat switch harness connector and ground.

Heated seat switch		Terminal	(-)	Voltage (V) (Approx.)
Connector				
Driver side	A/T models: M141 M/T models: M175	5	Ground	Battery voltage
Passenger side	A/T models: M142 M/T models: M176			

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 3.

3. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect fuse block (J/B) connector.
3. Check continuity between heated seat switch harness connector and fuse block (J/B) harness connector.

Heated seat switch		Terminal	Fuse block (J/B)		Continuity
Connector			Connector	Terminal	
Driver side	A/T models: M141 M/T models: M175	5	M1	2A	Existed
Passenger side	A/T models: M142 M/T models: M176				

4. Check continuity between heated seat switch harness connector and ground.

Heated seat switch		Terminal	Ground	Continuity
Connector				
Driver side	A/T models: M141 M/T models: M175	5	Ground	Not existed
Passenger side	A/T models: M142 M/T models: M176			

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4. CHECK FUSE BLOCK (J/B)

1. Turn ignition switch ON.
2. Check voltage between fuse block (J/B) connector (fuse block side) and ground.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

(+)		(-)	Voltage (V) (Approx.)
Fuse block (J/B)			
Connector	Terminal		
M1	2A	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace fuse block (J/B).

5.CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [GI-41, "Intermittent Incident"](#)

>> INSPECTION END

HEATED SEAT SWITCH

< DTC/CIRCUIT DIAGNOSIS >

HEATED SEAT SWITCH DRIVER SIDE

DRIVER SIDE : Description

INFOID:000000004535426

Adjusts heated seat temperature and deactivates heated seat.

DRIVER SIDE : Component Function Check

INFOID:000000004535427

1. CHECK FUNCTION

Check that heated seat warms to preset temperature when operating heated seat switch to the optimal position.

Is the inspection result normal?

- YES >> Heated seat switch function is OK.
NO >> Refer to [SE-17, "DRIVER SIDE : Diagnosis Procedure"](#).

DRIVER SIDE : Diagnosis Procedure

INFOID:000000004535428

1. CHECK HEATED SEAT CONTROL UNIT INPUT SIGNAL

- Turn ignition switch OFF.
- Disconnect heated seat control unit connector.
- Turn ignition switch ON.
- Check voltage between heated seat control unit harness connector and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)	
Heated seat control unit					
Connector	Terminal				
B466	68	Ground	Heated seat switch position	OFF	0
				1 (Min. temperature)	12.24
				2	12.33
				3	12.49
				4	12.63
				5	12.76
			6 (Max. temperature)	12.90	

Is the inspection result normal?

- YES >> Heated seat switch circuit is OK.
NO >> GO TO 2.

2. CHECK HEATED SEAT SWITCH CIRCUIT

- Turn ignition switch OFF.
- Disconnect heated seat switch connector.
- Check continuity between heated seat switch harness connector and heated seat control unit harness connector.

Heated seat switch		Heated seat control unit		Continuity
Connector	Terminal	Connector	Terminal	
A/T models: M141 M/T models: M175	2	B466	68	Existed

- Check continuity between heated seat switch harness connector and ground.

HEATED SEAT SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Heated seat switch		Ground	Continuity
Connector	Terminal		
A/T models: M141 M/T models: M175	2		Not existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace harness.

3.CHECK HEATED SEAT SWITCH

Check heated seat switch.

Refer to [SE-18, "DRIVER SIDE : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Replace heated seat switch. Refer to [SE-133, "Removal and Installation"](#).

4.CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

DRIVER SIDE : Component Inspection

INFOID:000000004535429

1.CHECK HEATED SEAT SWITCH

1. Turn ignition switch OFF.
2. Disconnect heated seat switch connector.
3. Check resistance between heated seat switch terminals.

Heated seat switch		Condition	Resistance (KΩ) (Approx.)	
Connector	Terminal			
A/T models: M141 M/T models: M175	5	1	ON OFF	0 ∞
		2	Heated seat switch position	1 (Min. temperature) 2 3 4 5 6 (Max. temperature)

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Replace heated seat switch. Refer to [SE-133, "Removal and Installation"](#).

PASSENGER SIDE

PASSENGER SIDE : Description

INFOID:000000004535430

Adjusts heated seat temperature and deactivates heated seat.

PASSENGER SIDE : Component Function Check

INFOID:000000004535431

1.CHECK FUNCTION

Check that heated seat warms to preset temperature when operating heated seat switch to the optimal position.

HEATED SEAT SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES >> Heated seat switch function is OK.
 NO >> Refer to [SE-19, "PASSENGER SIDE : Diagnosis Procedure"](#).

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000004535432

1. CHECK HEATED SEAT CONTROL UNIT INPUT SIGNAL

- Turn ignition switch OFF.
- Disconnect heated seat control unit connector.
- Turn ignition switch ON.
- Check voltage between heated seat control unit harness connector and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)	
Heated seat control unit					
Connector	Terminal				
B440	15	Ground	Heated seat switch position	OFF	0
				1 (Min. temperature)	12.24
				2	12.33
				3	12.49
				4	12.63
				5	12.76
				6 (Max. temperature)	12.90

Is the inspection result normal?

- YES >> Heated seat switch circuit is OK.
 NO >> GO TO 2.

2. CHECK HEATED SEAT SWITCH CIRCUIT

- Turn ignition switch OFF.
- Disconnect heated seat switch connector.
- Check continuity between heated seat switch harness connector and heated seat control unit harness connector.

Heated seat switch		Heated seat control unit		Continuity
Connector	Terminal	Connector	Terminal	
A/T models: M142 M/T models: M176	2	B440	15	Existed

- Check continuity between heated seat switch harness connector and ground.

Heated seat switch		Ground	Continuity
Connector	Terminal		
A/T models: M142 M/T models: M176	2		Not existed

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair or replace harness.

3. CHECK HEATED SEAT SWITCH

Check heated seat switch.
 Refer to [SE-20, "PASSENGER SIDE : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Replace heated seat switch. Refer to [SE-133, "Removal and Installation"](#).

4. CHECK INTERMITTENT INCIDENT

HEATED SEAT SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Check intermittent incident.
Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

PASSENGER SIDE : Component Inspection

INFOID:000000004535433

1. CHECK HEATED SEAT SWITCH

1. Turn ignition switch OFF.
2. Disconnect heated seat switch connector.
3. Check resistance between heated seat switch terminals.

Heated seat switch		Condition	Resistance (K Ω) (Approx.)	
Connector	Terminal			
A/T models: M142 M/T models: M176	5	1	ON OFF	0 ∞
		2	1 (Min. temperature)	2.400
	2		1.800	
	3		1.200	
	4		0.910	
	2	5	0.620	
6 (Max. temperature)		0.348		

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace heated seat switch. Refer to [SE-133, "Removal and Installation"](#).

HEATED SEAT RELAY

< DTC/CIRCUIT DIAGNOSIS >

HEATED SEAT RELAY

Description

INFOID:000000004535434

Power is supplied to the heated seat using ignition power supply control.

Component Function Check

INFOID:000000004535435

1. CHECK FUNCTION

Check that heated seat warms to preset temperature when operating heated seat switch to the optimal position.

Is the inspection result normal?

- YES >> Heated seat relay function is OK.
- NO >> Refer to [SE-21. "Diagnosis Procedure"](#)

Diagnosis Procedure

INFOID:000000004535436

1. CHECK HEATED SEAT RELAY POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect heated seat relay.
3. Turn ignition switch ON.
4. Check voltage between heated seat relay terminal connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Heated seat relay			
Connector	Terminal	Ground	Battery voltage
M70	2		

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> GO TO 2.

2. CHECK HEATED SEAT RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect fuse block (J/B) connector.
3. Check continuity between heated seat relay terminal connector and fuse block (J/B) harness connector.

Heated seat relay		Fuse block (J/B)		Continuity
Connector	Terminal	Connector	Terminal	
M70	2	M1	2A	Existed

4. Check continuity between heated seat relay terminal connector and ground.

Heated seat relay		Ground	Continuity
Connector	Terminal		
M70	2		Not existed

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Repair or replace harness.

3. CHECK HEATED SEAT RELAY GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between heated seat relay terminal connector and ground.

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

HEATED SEAT RELAY

< DTC/CIRCUIT DIAGNOSIS >

Heated seat relay		Ground	Continuity
Connector	Terminal		
M70	1		Existed

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair or replace harness.

4.CHECK HEATED SEAT RELAY

Check heated seat relay.

Refer to [SE-22, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Heated seat relay is OK.
 NO >> Replace heated seat relay.

5.CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [GI-41, "Intermittent Incident"](#)

>> INSPECTION END

Component Inspection

INFOID:000000004535437


1.CHECK HEATED SEAT RELAY

1. Turn ignition switch OFF.
2. Disconnect heated seat relay.
3. Check continuity between heated seat relay terminals.

heated seat relay		Condition	Continuity
Terminal			
3	5	12 V direct current supply between terminals 1 and 2.	Existed
		No current supply	Not existed

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> Replace heated seat relay.



SEF497Y

HEAT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

HEAT SENSOR DRIVER SIDE

DRIVER SIDE : Description

INFOID:000000004535438

Detects seat cushion heater temperature and outputs to heated seat control unit.

DRIVER SIDE : Component Function Check

INFOID:000000004535439

1. CHECK FUNCTION

Check that heated seat warms to preset temperature when operating heated seat switch to the optimal position.

Is the inspection result normal?

YES >> Heat sensor function is OK.

NO >> Refer to [SE-23, "DRIVER SIDE : Diagnosis Procedure"](#)

DRIVER SIDE : Diagnosis Procedure

INFOID:000000004535440

1. CHECK HEAT SENSOR INPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between heated seat control unit harness connector and ground.

(+) Heated seat control unit		(-)	Condition	Voltage (V) (Approx.)	
Connector	Terminal				
B466	71	Ground	Heated seat switch position	OFF	0
				1 (Min. temperature)	10.87 – 11.02
				2	10.93 – 11.07
				3	11.04 – 11.17
				4	11.13 – 11.26
				5	11.22 – 11.34
			6 (Max. temperature)	11.31 – 11.43	

NOTE:

Voltage is repeated within the value shown as per the above list depending on heater unit temperature.

Is the inspection result normal?

YES >> heat sensor is OK.

NO >> GO TO 2.

2. CHECK HEAT SENSOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect heated seat control unit connector and seat cushion heater connector.
3. Check continuity between heated seat control unit harness connector and seat cushion heater harness connector.

Heated seat control unit		Seat cushion heater		Continuity
Connector	Terminal	Connector	Terminal	
B466	71	B467	71	Existed

4. Check continuity between heated seat control unit harness connector and ground.

Heated seat control unit		Ground	Continuity
Connector	Terminal		
B466	71		Not existed

Is the inspection result normal?

HEAT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

- YES >> GO TO 3.
NO >> Repair or replace harness.

3.CHECK HEAT SENSOR POWER SUPPLY

1. Turn ignition switch ON.
2. Heated seat switch ON.
3. Check voltage between seat cushion heater harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Seat cushion heater			
Connector	Terminal		
B467	69	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 5.
NO >> GO TO 4.

4.CHECK HEAT SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect heated seat switch connector.
3. Check continuity between heated seat control unit harness connector and seat cushion heater harness connector.

Heated seat control unit		Seat cushion heater		Continuity
Connector	Terminal	Connector	Terminal	
B466	69	B467	69	Existed

4. Check continuity between heated seat control unit harness connector and ground.

Heated seat control unit		Ground	Continuity
Connector	Terminal		
B466	69		Not existed

Is the inspection result normal?

- YES >> GO TO 6.
NO >> Repair or replace harness.

5.CHECK HEAT SENSOR

Check heat sensor. Refer to [SE-24, "DRIVER SIDE : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 6.
NO >> Replace seat cushion heater. Refer to [SE-112, "Exploded View"](#).

6.CHECK INTERMITTENT INCIDENT

Check intermittent incident.
Refer to [GI-41, "Intermittent Incident"](#)

>> INSPECTION END

DRIVER SIDE : Component Inspection

INFOID:000000004535441

1.CHECK HEAT SENSOR

1. Turn ignition switch OFF.
2. Disconnect seat cushion heater connector.
3. Check resistance between seat cushion heater terminals.

HEAT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

Seat cushion heater			Condition	Resistance (KΩ) (Approx.)
Connector	Terminal			
B467	69	71	When heat sensor temperature is 25°C (77°F)	9.9 – 10.1

NOTE:

Resistance value changes according to temperature.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace seat cushion heater. Refer to [SE-112. "Exploded View"](#).

PASSENGER SIDE

PASSENGER SIDE : Description

INFOID:000000004535442

Detects seat cushion heater temperature and outputs to heated seat control unit.

PASSENGER SIDE : Component Function Check

INFOID:000000004535443

1.CHECK FUNCTION

Check that heated seat warms to preset temperature when operating heated seat switch to the optimal position.

Is the inspection result normal?

YES >> Heat sensor function is OK.

NO >> Refer to [SE-25. "PASSENGER SIDE : Diagnosis Procedure"](#)

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000004535444

1.CHECK HEAT SENSOR INPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between heated seat control unit harness connector and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)	
Heated seat control unit					
Connector	Terminal				
B440	18	Ground	Heated seat switch position	OFF	0
				1 (Min. temperature)	10.87 – 11.02
				2	10.93 – 11.07
				3	11.04 – 11.17
				4	11.13 – 11.26
				5	11.22 – 11.34
			6 (Max. temperature)	11.31 – 11.43	

NOTE:

Voltage is repeated within the value shown as per the above list depending on heater unit temperature.

Is the inspection result normal?

YES >> heat sensor function is OK.

NO >> GO TO 2.

2.CHECK HEAT SENSOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect heated seat control unit connector and seat cushion heater connector.
3. Check continuity between heated seat control unit harness connector and seat cushion heater harness connector.

HEAT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

Heated seat control unit		Seat cushion heater		Continuity
Connector	Terminal	Connector	Terminal	
B440	18	B441	18	Existed

4. Check continuity between heated seat control unit harness connector and ground.

Heated seat control unit		Ground	Continuity
Connector	Terminal		
B440	18		Not existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3.CHECK HEAT SENSOR POWER SUPPLY

1. Turn ignition switch ON.
2. Heated seat switch ON.
3. Check voltage between seat cushion heater harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Seat cushion heater			
Connector	Terminal		
B441	16	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

4.CHECK HEAT SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect heated seat switch connector.
3. Check continuity between heated seat control unit harness connector and seat cushion heater harness connector.

Heated seat control unit		Seat cushion heater		Continuity
Connector	Terminal	Connector	Terminal	
B440	16	B441	16	Existed

4. Check continuity between heated seat control unit harness connector and ground.

Heated seat control unit		Ground	Continuity
Connector	Terminal		
B440	16		Not existed

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace harness.

5.CHECK HEAT SENSOR

Check heat sensor. Refer to [SE-27, "PASSENGER SIDE : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Replace seat cushion heater. Refer to [SE-112, "Exploded View"](#).

6.CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [GI-41, "Intermittent Incident"](#)

HEAT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

>> INSPECTION END

PASSENGER SIDE : Component Inspection

INFOID:000000004535445

1. CHECK HEAT SENSOR

1. Turn ignition switch OFF.
2. Disconnect seat cushion heater connector.
3. Check resistance between seat cushion heater terminals.

Seat cushion heater		Condition	Resistance (K Ω) (Approx.)
Connector	Terminal		
B441	16 18	When heat sensor temperature is 25°C (77°F)	9.9 – 10.1

NOTE:

Resistance value changes according to temperature.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace seat cushion heater. Refer to [SE-112, "Exploded View"](#).

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

SE

SEAT CUSHION HEATER

< DTC/CIRCUIT DIAGNOSIS >

SEAT CUSHION HEATER DRIVER SIDE

DRIVER SIDE : Description

INFOID:000000004535446

Warms the seat cushion.

DRIVER SIDE : Component Function Check

INFOID:000000004535447

1.CHECK FUNCTION

Check that heated seat warms to preset temperature when operating heated seat switch to the optimal position.

Is the inspection result normal?

YES >> Seat cushion heater function is OK.

NO >> Refer to [SE-28, "DRIVER SIDE : Diagnosis Procedure"](#).

DRIVER SIDE : Diagnosis Procedure

INFOID:000000004535448

1.CHECK SEAT CUSHION HEATER INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect seat cushion heater connector.
3. Turn ignition switch ON.
4. Check voltage between seat cushion heater harness connector and ground.

(+)		(-)	Condition		Voltage (V) (Approx.)
Seat cushion heater					
Connector	Terminal				
B467	70	Ground	Heated seat	Operated	0 – Battery voltage
				Other than above	0

NOTE:

Voltage is repeated within the value shown as per the above list depending on heater unit temperature.

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2.CHECK SEAT CUSHION HEATER CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect heated seat control unit connector.
3. Check continuity between seat cushion heater harness connector and heated seat control unit harness connector.

Seat cushion heater		Heated seat control unit		Continuity
Connector	Terminal	Connector	Terminal	
B467	70	B466	70	Existed

4. Check continuity between seat cushion heater harness connector and ground.

Seat cushion heater		Ground	Continuity
Connector	Terminal		
B467	70		Not existed

Is the inspection result normal?

YES >> Replace heated seat control unit. Refer to [SE-128, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK SEAT CUSHION HEATER

SEAT CUSHION HEATER

< DTC/CIRCUIT DIAGNOSIS >

Check seat cushion heater.

Refer to [SE-29, "DRIVER SIDE : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace seat cushion heater. Refer to [SE-112, "Exploded View"](#).

4.CHECK SEAT CUSHION HEATER GROUND CIRCUIT

Check continuity between seat cushion heater harness connector and ground.

Seat cushion heater		Ground	Continuity
Connector	Terminal		
B467	48		Existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness.

5.CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [GI-41, "Intermittent Incident"](#)

>> INSPECTION END

DRIVER SIDE : Component Inspection

INFOID:000000004535449

1.CHECK SEAT CUSHION HEATER

1. Turn ignition switch OFF.
2. Disconnect seat cushion heater connector and seatback heater connector.
3. Check resistance between seat cushion heater terminals.

Seat cushion heater		Condition	Resistance (Ω) (Approx.)
Connector	Terminal		
B467	48	70	When heat sensor temperature is 20°C (68°F) 2.6 – 3.0

NOTE:

Resistance value changes according to temperature.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace seat cushion heater. Refer to [SE-112, "Exploded View"](#)

PASSENGER SIDE

PASSENGER SIDE : Description

INFOID:000000004535450

Warms the seat cushion.

PASSENGER SIDE : Component Function Check

INFOID:000000004535451

1.CHECK FUNCTION

Check that heated seat warms to preset temperature when operating heated seat switch to the optimal position.

Is the inspection result normal?

YES >> Seat cushion heater function is OK.

NO >> Refer to [SE-29, "PASSENGER SIDE : Diagnosis Procedure"](#).

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000004535452

1.CHECK FRONT SEAT CUSHION HEATER INPUT SIGNAL

SEAT CUSHION HEATER

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect seat cushion heater connector.
3. Turn ignition switch ON.
4. Check voltage between seat cushion heater harness connector and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)	
Seat cushion heater					
Connector	Terminal				
B441	17	Ground	Heated seat	Operated	0 – Battery voltage
				Other than above	0

NOTE:

Voltage is repeated within the value shown as per the above list depending on heater unit temperature.

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 2.

2.CHECK SEAT CUSHION HEATER CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect heated seat control unit connector.
3. Check continuity between seat cushion heater harness connector and heated seat control unit harness connector.

Seat cushion heater		Heated seat control unit		Continuity
Connector	Terminal	Connector	Terminal	
B441	17	B440	17	Existed

4. Check continuity between seat cushion heater harness connector and ground.

Seat cushion heater		Ground	Continuity
Connector	Terminal		
B441	17		Not existed

Is the inspection result normal?

- YES >> Replace heated seat control unit. Refer to [SE-128. "Removal and Installation"](#).
 NO >> Repair or replace harness.

3.CHECK SEAT CUSHION HEATER

Check seat cushion heater.

Refer to [SE-31. "PASSENGER SIDE : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Replace seat cushion heater. Refer to [SE-112. "Exploded View"](#).

4.CHECK SEAT CUSHION HEATER GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between seat cushion heater harness connector and ground.

Seat cushion heater		Ground	Continuity
Connector	Terminal		
B441	2		Existed

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> Repair or replace harness.

5.CHECK INTERMITTENT INCIDENT

Check intermittent incident.

SEAT CUSHION HEATER

< DTC/CIRCUIT DIAGNOSIS >

Refer to [GI-41. "Intermittent Incident"](#)

>> INSPECTION END

PASSENGER SIDE : Component Inspection

INFOID:000000004535453

1. CHECK SEAT CUSHION HEATER

1. Turn ignition switch OFF.
2. Disconnect seat cushion heater connector and seatback heater connector.
3. Check resistance between seat cushion heater terminals.

Seat cushion heater			Condition	Resistance (Ω) (Approx.)
Connector	Terminal			
B441	2	17	When heat sensor temperature is 20°C (68°F)	2.6 – 3.0

NOTE:

Resistance value changes according to temperature.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace seat cushion heater. Refer to [SE-112. "Exploded View"](#).

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

SE

SEATBACK HEATER

< DTC/CIRCUIT DIAGNOSIS >

SEATBACK HEATER DRIVER SIDE

DRIVER SIDE : Description

INFOID:000000004535454

Warms the seat cushion.

DRIVER SIDE : Component Function Check

INFOID:000000004535455

1.CHECK FUNCTION

Check that heated seat warms to preset temperature when operating heated seat switch to the optimal position.

Is the inspection result normal?

YES >> Seatback heater function is OK.

NO >> Refer to [SE-32, "DRIVER SIDE : Diagnosis Procedure"](#).

DRIVER SIDE : Diagnosis Procedure

INFOID:000000004535456

1.CHECK SEATBACK HEATER

1. Turn ignition switch OFF.
2. Disconnect seatback heater connector.
3. Check resistance between seatback heater terminals.

Seatback heater			Condition	Resistance (Ω) (Approx.)
Connector	Terminal			
B425	1	2	When heat sensor temperature is 20°C (68°F)	4.0 – 4.7

NOTE:

Resistance value changes according to temperature.

Is the inspection result normal?

YES >> Replace seat cushion heater. Refer to [SE-112, "Exploded View"](#).

NO >> Replace seatback heater. Refer to [SE-112, "Exploded View"](#).

PASSENGER SIDE

PASSENGER SIDE : Description

INFOID:000000004535457

Warms the seat cushion.

PASSENGER SIDE : Component Function Check

INFOID:000000004535458

1.CHECK FUNCTION

Check that heated seat warms to preset temperature when operating heated seat switch to the optimal position.

Is the inspection result normal?

YES >> Seatback heater function is OK.

NO >> Refer to [SE-32, "PASSENGER SIDE : Diagnosis Procedure"](#).

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000004535459

1.CHECK SEATBACK HEATER

1. Turn ignition switch OFF.
2. Disconnect seatback heater connector.
3. Check resistance between seatback heater terminals.

SEATBACK HEATER

< DTC/CIRCUIT DIAGNOSIS >

Seatback heater			Condition	Resistance (Ω) (Approx.)
Connector	Terminal			
B445	1	2	When heat sensor temperature is 20°C (68°F)	4.0 – 4.7

NOTE:

Resistance value changes according to temperature.

Is the inspection result normal?

- YES >> Replace seat cushion heater. Refer to [SE-112, "Exploded View"](#).
- NO >> Replace seatback heater. Refer to [SE-112, "Exploded View"](#).

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

SE

HEATED SEAT SWITCH INDICATOR

< DTC/CIRCUIT DIAGNOSIS >

HEATED SEAT SWITCH INDICATOR DRIVER SIDE

DRIVER SIDE : Description

INFOID:000000004535460

Illuminates the indicator that indicates the operating status of heated seat.

DRIVER SIDE : Component Function Check

INFOID:000000004535461

1.CHECK FUNCTION

Check that the related indicator lamp illuminates when heated seat switch is set to ON.

Is the inspection result normal?

YES >> Heated seat switch indicator function is OK.

NO >> Refer to [SE-34, "DRIVER SIDE : Diagnosis Procedure"](#).

DRIVER SIDE : Diagnosis Procedure

INFOID:000000004535462

1.CHECK HEATED SEAT SWITCH INDICATOR GROUND CIRCUIT

1. Turn ignition switch OFF
2. Disconnect heated seat switch connector.
3. Check continuity between heated seat switch harness connector and ground.

Heated seat switch		Ground	Continuity
Connector	Terminal		Existed
A/T models: M141 M/T models: M175	6		Existed

Is the inspection result normal?

YES >> Replace heated seat switch. Refer to [SE-133, "Removal and Installation"](#).

NO >> Repair or replace harness.

PASSENGER SIDE

PASSENGER SIDE : Description

INFOID:000000004535463

Illuminates the indicator that indicates the operating status of heated seat.

PASSENGER SIDE : Component Function Check

INFOID:000000004535464

1.CHECK FUNCTION

Check that the related indicator lamp illuminates when heated seat switch is set to ON.

Is the inspection result normal?

YES >> Heated seat switch indicator function is OK.

NO >> Refer to [SE-34, "PASSENGER SIDE : Diagnosis Procedure"](#).

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000004535465

1.CHECK HEATED SEAT SWITCH INDICATOR GROUND CIRCUIT

1. Turn ignition switch OFF
2. Disconnect heated seat switch connector.
3. Check continuity between heated seat switch harness connector and ground.

Heated seat switch		Ground	Continuity
Connector	Terminal		Existed
A/T models: M142 M/T models: M176	6		Existed

Is the inspection result normal?

HEATED SEAT SWITCH INDICATOR

< DTC/CIRCUIT DIAGNOSIS >

YES >> Replace heated seat switch. Refer to [SE-133, "Removal and Installation"](#).
NO >> Repair or replace harness.

A

B

C

D

E

F

G

H

I

SE

K

L

M

N

O

P

TILT&TELESCOPIC SWITCH

< DTC/CIRCUIT DIAGNOSIS >

TILT&TELESCOPIC SWITCH

Description

INFOID:000000004240973

Tilt switch and telescopic switch as a unit, transmit switch operation signal to automatic drive positioner control unit.

Component Function Check

INFOID:000000004240974

1.CHECK TILT AND TELESCOPIC SWITCH FUNCTION

Check tilt and telescopic operation with tilt and telescopic switch.

Is the inspection results normal?

- YES >> Tilt and telescopic switch is OK.
 NO >> Refer to [SE-36, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004240975

1.CHECK TILT AND TELESCOPIC SWITCH FUNCTION

Check voltage between tilt and telescopic switch and ground.

Tilt and telescopic switch		(-)	Switch condition	Voltage (V) Approx.
Connector	Terminal			
M31	2	Ground	Forward position	0
			Other than above	5
	3		Backward position	0
			Other than above	5
	4		Upward position	0
			Other than above	5
	5		Downward	0
			Other than above	5

Is the inspection result normal?

- YES >> Tilt and telescopic switch is OK.
 NO >> GO TO 2.

2.CHECK TILT AND TELESCOPIC SWITCH SIGNAL CIRCUIT

- Turn ignition switch OFF.
- Disconnect tilt and telescopic switch and automatic drive positioner control unit connectors.
- Check continuity between tilt and telescopic switch and automatic drive positioner control unit.

Tilt and telescopic switch connector	Terminal	Automatic drive positioner control unit	Terminal	Continuity
M31	2	M51	11	Existed
	3		27	
	4		1	
	5		17	

- Check continuity between tilt and telescopic switch and ground.

TILT&TELESCOPIC SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Tilt and telescopic switch connector	Terminal		Continuity
M31	2	Ground	Not existed
	3		
	4		
	5		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace circuit.

3.CHECK TILT AND TELESCOPIC SWITCH GROUND CIRCUIT

Check continuity between tilt and telescopic switch and ground.

Tilt and telescopic switch connector	Terminal	Ground	Continuity
M31	1		Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace circuit.

4.CHECK TILT AND TELESCOPIC SWITCH

Check tilt and telescopic switch.

Refer to [SE-37, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace tilt and telescopic switch.

5.CHECK AUTOMATIC DRIVE POSITIONER CONTROL UNIT

1. Connect automatic drive positioner control unit connector.
2. Check voltage between automatic drive positioner control unit and ground.

Tilt and telescopic switch		(-)	Voltage (V) Approx.
Connector	Terminal		
M51	1	Ground	5
	11		
	17		
	27		

Is the inspection result normal?

YES >> GO TO 6.

NO >> Replace automatic drive positioner control unit. Refer to [SE-127, "Removal and Installation"](#).

6.CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [GI-41, "Intermittent Incident"](#)

>> INSPECTION END

Component Inspection

INFOID:000000004240976

1.CHECK TILT SWITCH

1. Turn ignition switch OFF.
2. Remove tilt and telescopic switch.
3. Check continuity between tilt and telescopic switch terminals.

TILT&TELESCOPIC SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Terminal		Switch condition	Continuity
2	1	Forward	Existed
		Other than above	Not existed
3		Backward	Existed
		Other than above	Not existed
4		Upward	Existed
		Other than above	Not existed
5		Downward	Existed
		Other than above	Not existed

Is the inspection result normal?

YES >> Tilt and telescopic switch is OK.

NO >> Replace tilt and telescopic switch. Refer to [SE-132, "Removal and Installation"](#).

TILT&TELESCOPIC MOTOR

< DTC/CIRCUIT DIAGNOSIS >

TILT&TELESCOPIC MOTOR

Description

INFOID:000000004240977

Tilt and telescopic motor operates with the power received from automatic drive positioner control unit.

Component Function Check

INFOID:000000004240978

1.CHECK TILT AND TELESCOPIC MOTOR FUNCTION

Check tilt and telescopic operation with tilt and telescopic switch.

Is the inspection results normal?

- YES >> Tilt and telescopic motor are OK.
- NO >> Refer to [SE-39, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004240979

1.CHECK MALFUNCTIONING PART

Check malfunctioning part.

Is it tilt operation or telescopic operation?

- Tilt >> GO TO 2.
- Telescopic>>GO TO 3.

2.CHECK TILT MOTOR POWER SUPPLY AND GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect tilt motor and automatic drive positioner control unit.
3. Check continuity between tilt motor and automatic drive positioner control unit.

Tilt and telescopic motor connector	Terminal	Power seat switch connector	Terminal	Continuity
M49	3	M52	42	Existed
	4		35	

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair or replace circuit.

3.CHECK TELESCOPIC MOTOR POWER SUPPLY AND GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect telescopic motor and automatic drive positioner control unit.
3. Check continuity between telescopic motor and automatic drive positioner control unit.

Tilt and telescopic motor connector	Terminal	Power seat switch connector	Terminal	Continuity
M49	1	M52	44	Existed
	2		36	

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair or replace circuit.

4.CHECK TILT AND TELESCOPIC MOTOR

Check tilt and telescopic motor.

Refer to [SE-40, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Replace tilt and telescopic motor.

5.CHECK ADP CONTROL UNIT

TILT&TELESCOPIC MOTOR

< DTC/CIRCUIT DIAGNOSIS >

1. Connect automatic drive positioner control unit connector.
2. Check voltage between automatic drive positioner control unit and ground.

Tilt and telescopic switch		(-)	Tilt and telescopic switch condition	Voltage (V) Approx.
Connector	Terminal			
M51	35	Ground	Upward	Battery voltage
			Other than above	0
	36		Forward	Battery voltage
			Other than above	0
	42		Downward	Battery voltage
			Other than above	0
	44		Backward	Battery voltage
			Other than above	0

Is the inspection result normal?

YES >> GO TO 6.

NO >> Replace automatic drive positioner control unit. Refer to [SE-127, "Removal and Installation"](#).

6.CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [GI-41, "Intermittent Incident"](#)

>> INSPECTION END

Component Inspection

INFOID:000000004240980

1.CHECK TILT AND TELESCOPIC MOTOR-I

Check visually the tilt and telescopic motor to see if any foreign object is not disturbing the functionment or if the tilt and telescopic motor is not broken.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace tilt and telescopic motor.

2.CHECK TILT AND TELESCOPIC MOTOR-II

1. Turn ignition switch OFF.
2. Disconnect tilt and telescopic motor connector.
3. Supply tilt and telescopic motor terminals with battery voltage and check operation.

Item	Terminal		Operation
	(+)	(-)	
Telescopic motor	1	2	Backward
	2	1	Forward
Tilt motor	3	4	Downward
	4	3	Upward

Is the inspection result normal?

YES >> Tilt and telescopic motor is OK.

NO >> Replace tilt and telescopic motor.

TILT&TELESCOPIC SENSOR

< DTC/CIRCUIT DIAGNOSIS >

TILT&TELESCOPIC SENSOR

Description

INFOID:000000004240981

Tilt and telescopic sensor detects the position of steering wheel and transmits signals to automatic drive positioner control unit.

Component Function Check

INFOID:000000004240982

1.CHECK TILT AND TELESCOPIC SENSOR FUNCTION

Check tilt and telescopic operation with tilt and telescopic switch.

Is the inspection results normal?

- YES >> Tilt and telescopic sensor is OK.
- NO >> Refer to [SE-41. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004240983

1.CHECK TILT AND TELESCOPIC SENSOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect tilt and telescopic sensor and automatic drive positioner control unit connector.
3. Check continuity between tilt and telescopic sensor and automatic drive positioner control unit.

Tilt and telescopic sensor connector	Terminal	Automatic drive positioner control unit	Terminal	Continuity
M48	1	M51	33	Existed
	2		23	
	3		7	
	4	M52	41	

4. Check continuity between tilt and telescopic sensor and ground.

Tilt and telescopic sensor connector	Terminal	Ground	Continuity
M48	1	Ground	Not existed
	2		
	3		
	4		

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair or replace circuit.

2.CHECK TILT AND TELESCOPIC SENSOR POWER SUPPLY

1. Connect automatic drive positioner control unit connector.
2. Check voltage between automatic drive positioner control unit and ground.

Tilt and telescopic sensor		Ground	Voltage
Connector	Terminal		
M52	33		Approx. 5V

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Replace automatic drive positioner. Refer to [SE-127. "Removal and Installation"](#).

3.CHECK TILT AND TELESCOPIC SENSOR GROUND

Check continuity between automatic drive positioner control unit and ground.

TILT&TELESCOPIC SENSOR

< DTC/CIRCUIT DIAGNOSIS >

Tilt and telescopic sensor		Ground	Continuity
Connector	Terminal		Existed
M48	4		

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace automatic drive positioner. Refer to [SE-127, "Removal and Installation"](#).

4.CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

POWER SEAT


< DTC/CIRCUIT DIAGNOSIS >

POWER SEAT

Wiring Diagram - POWER SEAT SYSTEM (DRIVER SIDE) -

INFOID:000000004240984

POWER SEAT FOR DRIVER SIDE



*: This connector is not shown in "Harness Layout".

2008/08/07

JCJWA0714GB

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

POWER SEAT

< DTC/CIRCUIT DIAGNOSIS >


POWER SEAT FOR DRIVER SIDE

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	THBDFW-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
3	V	- [Without automatic drive positioner]

Connector No.	B62
Connector Name	WIRE TO WIRE
Connector Type	MOBFW-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	V	-
2	B	-

Connector No.	B414
Connector Name	POWER SEAT SWITCH (DRIVER SIDE) (WITHOUT AUTOMATIC DRIVE POSITIONER)
Connector Type	NS1DFW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	B	-
3	G/Y	-
4	P	-
5	W	-
6	V	-
7	L/Y	-
8	L	-
9	L/R	-
10	G/W	-

Connector No.	B415
Connector Name	RECLINING MOTOR (DRIVER SIDE) (WITHOUT AUTOMATIC DRIVE POSITIONER)
Connector Type	NS2DFW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
3	G/Y	-
4	P	-

Connector No.	B416
Connector Name	SLIDING MOTOR (DRIVER SIDE) (WITHOUT AUTOMATIC DRIVE POSITIONER)
Connector Type	639B-0239



Terminal No.	Color of Wire	Signal Name [Specification]
5	W	-
6	V	-

Connector No.	B417
Connector Name	RECLINING MOTOR (DRIVER SIDE) (WITHOUT AUTOMATIC DRIVE POSITIONER)
Connector Type	NS2DFW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
9	L/R	-
10	G/W	-

Connector No.	B418
Connector Name	WIRE TO WIRE (DRIVER SIDE) (WITHOUT AUTOMATIC DRIVE POSITIONER)
Connector Type	NS2DFW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
7	L/Y	-
8	L	-

Connector No.	B421
Connector Name	WIRE TO WIRE
Connector Type	MOBFW-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	B	-


JCJWA0715GB

POWER SEAT

< DTC/CIRCUIT DIAGNOSIS >


POWER SEAT FOR DRIVER SIDE

Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4




Terminal No.	91	W	Signal Name [Specification]
Color of Wire	W		

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS06FW-M2




Terminal No.	7A	R	Signal Name [Specification]
Color of Wire	R		

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	TH80MM-CS16-TM4



Terminal No.	91	W	Signal Name [Specification]
Color of Wire	W		

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	TH80MM-CS16-TM4




Terminal No.	3	P	Signal Name [Specification]
Color of Wire	P		

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	M03PE-LC



Terminal No.	1	W	Signal Name [Specification]
Color of Wire	W		
Terminal No.	2	Y	POWER WINDOW POWER SUPPLY (BAT)
Color of Wire	Y		

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS16FW-CS



Terminal No.	11	R	Signal Name [Specification]
Color of Wire	R		
Terminal No.	13	B	BAT (FUSE)
Color of Wire	B		GND

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P


POWER SEAT

< DTC/CIRCUIT DIAGNOSIS >

Wiring Diagram - POWER SEAT SYSTEM (PASSENGER SIDE) -

INFOID:000000004240985

POWER SEAT FOR PASSENGER SIDE



2008/08/07


JCJWA0717GB

POWER SEAT

< DTC/CIRCUIT DIAGNOSIS >


POWER SEAT FOR PASSENGER SIDE

Connector No.	B201
Connector Name	WIRE TO WIRE
Connector Type	TH02FW-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
94	R	-

Connector No.	B209
Connector Name	WIRE TO WIRE
Connector Type	M06FW-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	B	-

Connector No.	B434
Connector Name	POWER SEAT SWITCH (PASSENGER SIDE)
Connector Type	NS10FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	B	-
3	G/Y	-
4	P	-
5	W	-
6	V	-
7	L/Y	-
8	L	-
9	L/R	-
10	G/W	-

Connector No.	B435
Connector Name	RECLINING MOTOR (PASSENGER SIDE)
Connector Type	NS02FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
3	G/Y	-
4	P	-

Connector No.	B436
Connector Name	SLIDING MOTOR (PASSENGER SIDE)
Connector Type	B098-0239



Terminal No.	Color of Wire	Signal Name [Specification]
5	W	-
6	V	-

Connector No.	B407
Connector Name	LIFTING MOTOR (FRONT) (PASSENGER SIDE)
Connector Type	NS02FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
9	L/R	-
10	G/W	-

Connector No.	B438
Connector Name	LIFTING MOTOR (REAR) (PASSENGER SIDE)
Connector Type	NS02FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
7	L/Y	-
8	L	-

Connector No.	B439
Connector Name	WIRE TO WIRE
Connector Type	M06MW-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	B	-

JCJWA0718GB


A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

POWER SEAT

< DTC/CIRCUIT DIAGNOSIS >


POWER SEAT FOR PASSENGER SIDE

Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	TH80PW-CS16-TM4




Terminal No.	91	W	—
Color of Wire	W	—	—
Signal Name [Specification]			

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS08FW-M2




Terminal No.	7A	R	—
Color of Wire	R	—	—
Signal Name [Specification]			

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4




Terminal No.	91	W	—
Color of Wire	W	—	—
Signal Name [Specification]			

Connector No.	M117
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4




Terminal No.	94	Y	—
Color of Wire	Y	—	—
Signal Name [Specification]			

Connector No.	M118
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	MS3PE-LC



Terminal No.	1	W	BAT (F/L)
Color of Wire	W	—	—
Signal Name [Specification]			
Terminal No.	2	Y	POWER WINDOW POWER SUPPLY(BAT)
Color of Wire	Y	—	—
Signal Name [Specification]			

Connector No.	M119
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	MS18PW-CS



Terminal No.	11	R	BAT (FUSE)
Color of Wire	R	—	—
Signal Name [Specification]			
Terminal No.	13	B	GND
Color of Wire	B	—	—
Signal Name [Specification]			

JCJWA0719GB

LUMBAR SUPPORT


< DTC/CIRCUIT DIAGNOSIS >

LUMBAR SUPPORT

Wiring Diagram - LUMBAR SUPPORT SYSTEM -

INFOID:000000004240987

LUMBAR SUPPORT



*: This connector is not shown in "Harness Layout".

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P









2008/08/07

JCJWA0726GB

LUMBAR SUPPORT

< DTC/CIRCUIT DIAGNOSIS >

LUMBAR SUPPORT

Connector No. B1	WIRE TO WIRE TH80FW-CS16-TM4		Terminal No. 3	Color of Wire SB	Signal Name [Specification] -- [With automatic drive positioner]
Connector No. B458	LUMBAR SUPPORT MOTOR C02FW		Terminal No. 57 58	Color of Wire W L	Signal Name [Specification] --
Connector No. B457	LUMBAR SUPPORT SWITCH NS04FW-CS		Terminal No. 33 48 57 58	Color of Wire R B W L	Signal Name [Specification] --
Connector No. B59	WIRE TO WIRE NS16FW-CS		Terminal No. 33 48	Color of Wire SB B	Signal Name [Specification] --
Connector No. B462	WIRE TO WIRE NS16MW-CS		Terminal No. 33 R 48 B	Color of Wire R --	Signal Name [Specification] --
Connector No. M7	WIRE TO WIRE TH80MP-CS16-TM4		Terminal No. 3	Color of Wire SB	Signal Name [Specification] -- [With automatic drive positioner]
Connector No. M8	WIRE TO WIRE TH80MP-CS16-TM4		Terminal No. 91	Color of Wire W	Signal Name [Specification] --
Connector No. E06	WIRE TO WIRE TH80PW-CS16-TM4		Terminal No. 91	Color of Wire W	Signal Name [Specification] --

JCJWA0727GB


LUMBAR SUPPORT

< DTC/CIRCUIT DIAGNOSIS >


A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

LUMBAR SUPPORT

Connector No.	M62
Connector Name	CIRCUIT BREAKER
Connector Type	MOEY-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	SB	- [With automatic drive positioner]



JCJWA0728GB


SIDE SUPPORT

< DTC/CIRCUIT DIAGNOSIS >

SIDE SUPPORT

Wiring Diagram - SIDE SUPPORT SYSTEM -

INFOID:000000004240988



2008/08/07


JCJWA0723GB

SIDE SUPPORT

< DTC/CIRCUIT DIAGNOSIS >


SIDE SUPPORT

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
3	SB	-- [With automatic drive positioner]
3	V	-- [Without automatic drive positioner]

Connector No.	B2
Connector Name	WIRE TO WIRE
Connector Type	MS6FW-LC




Terminal No.	Color of Wire	Signal Name [Specification]
1	V	--
2	B	--

Connector No.	B42
Connector Name	WIRE TO WIRE
Connector Type	MS6MW-LC




Terminal No.	Color of Wire	Signal Name [Specification]
1	R	--
2	B	--

Connector No.	B462
Connector Name	WIRE TO WIRE
Connector Type	MS18MW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
33	R	--
48	B	--

Connector No.	B464
Connector Name	SIDE SUPPORT SWITCH
Connector Type	NS06FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
48	B	--
52	G	-- [With automatic drive positioner]
53	B/R	-- [Without automatic drive positioner]
53	W/R	-- [Without automatic drive positioner]
54	V/W	-- [With automatic drive positioner]
54	BP	-- [Without automatic drive positioner]
55	R/L	-- [With automatic drive positioner]
55	LG	-- [Without automatic drive positioner]

Connector No.	B485
Connector Name	SIDE SUPPORT UNIT
Connector Type	NS06FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
33	R	--
48	B	--
52	G	-- [With automatic drive positioner]
52	GR	-- [Without automatic drive positioner]
53	B/R	-- [Without automatic drive positioner]
53	W/R	-- [Without automatic drive positioner]
54	V/W	-- [With automatic drive positioner]
54	BR	-- [Without automatic drive positioner]
55	BR	-- [With automatic drive positioner]
55	R/L	-- [Without automatic drive positioner]
55	LG	-- [Without automatic drive positioner]

Connector No.	E108
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
91	W	--

JCJWA0724GB

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

SIDE SUPPORT

Connector No.	M1
Connector Name	FUSE BLOCK (L/E)
Connector Type	NS06FW-M2



Terminal No.	7A	R	—
Color of Wire	R	—	—
Signal Name [Specification]	—	—	—

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS (E-TM4)



Terminal No.	9I	W	—
Color of Wire	W	—	—
Signal Name [Specification]	—	—	—

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS (E-TM4)



Terminal No.	3	P	—
Color of Wire	SB	—	—
Signal Name [Specification]	—	—	—
	3	P	— [Without automatic drive positioner]
	3	P	— [With automatic drive positioner]

Connector No.	M82
Connector Name	CIRCUIT BREAKER
Connector Type	M02FW-LG



Terminal No.	1	W	—
Color of Wire	W	—	—
Signal Name [Specification]	—	—	—
	2	SB	— [With automatic drive positioner]

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	M03FE-LC



Terminal No.	1	W	BAT (F/L)
Color of Wire	W	—	—
Signal Name [Specification]	BAT (F/L)	—	—
	2	Y	POWER WINDOW POWER SUPPLY (BAT)

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS16FW-CS



Terminal No.	1I	R	BAT (FUSE)
Color of Wire	R	—	—
Signal Name [Specification]	BAT (FUSE)	—	—
	13	B	GND

TILT & TELESCOPIC SYSTEM


< DTC/CIRCUIT DIAGNOSIS >

TILT & TELESCOPIC SYSTEM

Wiring Diagram - TILT&TELESCOPIC SYSTEM -

INFOID:000000004684671

TILT & TELESCOPIC SYSTEM



2008/08/07

JCJWA0720GB


A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

TILT & TELESCOPIC SYSTEM

< DTC/CIRCUIT DIAGNOSIS >


TILT & TELESCOPIC SYSTEM

Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4




Terminal No.	91	W	Signal Name [Specification]

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS06FW-M2



Terminal No.	7A	R	Signal Name [Specification]

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	TH80MM-CS16-TM4




Terminal No.	91	W	Signal Name [Specification]

Connector No.	M31
Connector Name	TILT & TELESCOPIC SWITCH
Connector Type	TK08FY




Terminal No.	1	B	Signal Name [Specification]
	2	GR	
	3	G	
	4	Y	
	5	BR	

Connector No.	M48
Connector Name	TILT & TELESCOPIC SENSOR
Connector Type	TK04FW




Terminal No.	1	W	Signal Name [Specification]
	2	P	
	3	O	
	4	Y	

Connector No.	M49
Connector Name	TILT & TELESCOPIC MOTOR
Connector Type	NS04FW-CS




Terminal No.	1	G	Signal Name [Specification]
	2	GR	
	3	O	
	4	L	

Connector No.	M61
Connector Name	AUTOMATIC DRIVE POSITIONER CONTROL UNIT
Connector Type	TH32FW-NH



Terminal No.	1	Y	Signal Name [Specification]
	7	O	TILT SW (UPWARD)
	11	GR	TILT SENSOR
	17	BR	TELESCOPIC SW (FRONTWARD)
	23	P	TILT SW (DOWNWARD)
	27	G	TELESCOPIC SW (BACKWARD)

Connector No.	M62
Connector Name	AUTOMATIC DRIVE POSITIONER CONTROL UNIT
Connector Type	NS16FW-CS



Terminal No.	33	W	Signal Name [Specification]
	34	V	POWER SUPPLY (SENSOR)
	35	L	BAT (FUSE)
	36	GR	TILT MOTOR (UPWARD)
	39	W	TELESCOPIC MOTOR (FORWARD)
	40	B	BAT (G/B)
	41	Y	GND(SIGNAL)
	42	O	TILT MOTOR (DOWNWARD)
	44	G	TELESCOPIC MOTOR (BACKWARD)
	48	B	GND(POWER)

TILT & TELESCOPIC SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

TILT & TELESCOPIC SYSTEM

Connector No.	M62
Connector Name	CIRCUIT BREAKER
Connector Type	MOEY-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	W	- [Without automatic drive positioner]

JCJWA0722GB

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


ECU DIAGNOSIS INFORMATION

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

Reference Value

INFOID:000000004730974

TERMINAL LAYOUT



PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition	Voltage (V) (Approx.)
+	-	Signal name	Input/ Output		
1 (Y)	Ground	Tilt switch upward signal	Input	Tilt switch	Operate (upward) 0
					Other than above 5
2 (LG)	Ground	Changeover switch RH signal	Input	Changeover switch position	RH 0
					Neutral or LH 5
3 (G)	Ground	Mirror switch upward signal	Input	Mirror switch	Operated (upward) 0
					Other than above 5
4 (V)	Ground	Mirror switch leftward signal	Input	Mirror switch	Operated (leftward) 0
					Other than above 5
5 (R)	Ground	Door mirror sensor (RH) upward/downward signal	Input	Mirror face (door mirror RH)	Change between 3.4 (close to peak) 0.6 (close to valley)
6 (GR)	Ground	Door mirror sensor (LH) upward/downward signal	Input	Mirror face (door mirror LH)	Change between 3.4 (close to peak) 0.6 (close to valley)
7 (O)	Ground	Tilt sensor signal	Input	Tilt position	Change between 1.2 (close to top) 3.8 (close to bottom)
9 (BR)	Ground	Memory switch 1 signal	Input	Memory switch 1	Press 0
					Other than above 5
10 (V)	Ground	UART communication (TX)	Output	Ignition switch ON	


AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Voltage (V) (Approx.)		
+	-	Signal name	Input/ Output				
11 (GR)	Ground	Telescopic switch forward signal	Input	Telescopic switch	Operate (forward)	0	A
					Other than above	5	B
12 (O)	Ground	Memory indicator 1 signal	Output	Memory indicator 1	Illuminate	1	C
					Other than above	Battery voltage	D
13 (P)	Ground	Memory indicator 2 signal	Output	Memory indicator 2	Illuminate	1	E
					Other than above	Battery voltage	F
14 (W)	Ground	Door mirror motor (RH) upward output	Output	Door mirror RH	Operate (upward)	Battery voltage	G
					Other than above	0	H
15 (O)	Ground	Door mirror motor (RH) leftward output	Output	Door mirror RH	Operate (leftward)	Battery voltage	I
					Other than above	0	SE
16 (Y)	Ground	Door mirror motor (LH) downward output	Output	Door mirror (LH)	Operate (downward)	Battery voltage	K
					Other than above	0	L
		Door mirror motor (LH) rightward output			Operate (rightward)	Battery voltage	M
					Other than above	0	N
17 (BR)	Ground	Tilt switch downward signal	Input	Tilt switch	Operate (downward)	0	O
					Other than above	5	P
18 (P)	Ground	Changeover switch LH signal	Input	Changeover switch position	LH	0	
					Neutral or RH	5	
19 (SB)	Ground	Mirror switch downward signal	Input	Mirror switch	Operate (downward)	0	
					Other than above	5	
20 (BR)	Ground	Mirror switch rightward signal	Input	Mirror switch	Operate (rightward)	0	
					Other than above	5	
21 (L)	Ground	Door mirror sensor (RH) leftward/rightward signal	Input	Door mirror RH position	Change between 3.4 (close to left edge) 0.6 (close to right edge)		
22 (G)	Ground	Door mirror sensor (LH) leftward/rightward signal	Input	Door mirror LH position	Change between 0.6 (close to left edge) 3.4 (close to right edge)		
23 (P)	Ground	Telescopic sensor signal	Input	Telescopic position	Change between 0.8 (close to top) 4.4 (close to bottom)		

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Voltage (V) (Approx.)
+	-	Signal name	Input/ Output			
24 (R)	Ground	Set switch signal	Input	Set switch	Press	0
					Other than above	5
25 (V)	Ground	Memory switch 2 signal	Input	Memory switch 2	Press	0
					Other than above	5
26 (P)	Ground	UART communication (RX)	Input	Ignition switch ON	 <p style="text-align: right; font-size: small;">JMJA0121ZZ</p>	
27 (G)	Ground	Telescopic switch back- ward signal	Input	Telescopic switch	Operate (backward)	0
					Other than above	5
30 (SB)	Ground	Door mirror motor (RH) downward output	Output	Door mirror (RH)	Operate (down- ward)	Battery voltage
		Door mirror motor (RH) rightward output			Other than above	0
					Operate (rightward)	Battery voltage
					Other than above	0
31 (G)	Ground	Door mirror motor (LH) upward output	Output	Door mirror (LH)	Operate (upward)	Battery voltage
					Other than above	0
32 (L)	Ground	Door mirror motor (LH) leftward output	Output	Door mirror (LH)	Operate (leftward)	Battery voltage
					Other than above	0
33 (W)	Ground	Sensor power supply	Input	—	5	
34 (V)	Ground	Power source (Fuse)	Input	—	Battery voltage	
35 (L)	Ground	Tilt motor upward output	Output	Steering tilt	Operate (upward)	Battery voltage
					Other than above	0
36 (GR)	Ground	Telescopic motor forward output signal	Output	Steering telescopic	Operate (forward)	Battery voltage
					Other than above	0
39 (W)	Ground	Power source (C/B)	Input	—	Battery voltage	
40 (B)	Ground	Ground	—	—	0	

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Voltage (V) (Approx.)	A	
+	-	Signal name	Input/ Output			B	
41 (Y)	Ground	Sensor ground	—	—	0	B	
42 (O)	Ground	Tilt motor downward out- put	Output	Steering tilt	Operate (down- ward)	Battery voltage	C
					Other than above	0	D
44 (G)	Ground	Telescopic motor back- ward output	Output	Steering telescop- ic	Operate (backward)	Battery voltage	E
					Other than above	0	E
48 (B)	Ground	Ground	—	—	0	F	

A
B
C
D
E
F
G
H
I

SE


K
L
M
N
O
P

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Wiring Diagram - AUTOMATIC DRIVE POSITIONER CONTROL SYSTEM -

INFOID:000000004730975




* : This connector is not shown in "Harness Layout".

2008/08/07

JCJWA0740GB

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >



JCJWA0741GB


A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

A : With A/T
M : With M/T

*: This connector is not shown in "Harness Layout".




JCJWA0742GB

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
3	SB	- [With automatic drive positioner]
14	Y	-
15	BR	-
16	LG	-
17	G	-
20	L	-
21	P	-
87	B	-
98	V	-

Connector No.	B14
Connector Name	PARKING BRAKE SWITCH (WITH M/T)
Connector Type	P01EB-A




Terminal No.	Color of Wire	Signal Name [Specification]
1	V	-

Connector No.	B16
Connector Name	FRONT DOOR SWITCH (DRIVER SIDE)
Connector Type	A03BW




Terminal No.	Color of Wire	Signal Name [Specification]
2	B	-

Connector No.	B59
Connector Name	WIRE TO WIRE
Connector Type	NS16FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
3	L	-
8	Y	-
17	LG	-
19	P	-
21	Y	-
32	B	-
33	SB	-
40	BR	-
48	B	-

Connector No.	B4E1
Connector Name	DRIVER SEAT CONTROL UNIT
Connector Type	TH82FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	L/W	RX
3	R/Y	CAN-H
8	LG	PARKING BRAKE SW
9	W/G	PULSE (RECLINING)
10	P/B	PULSE (RR LIFTING)
11	BR	SLIDING SW (BACKWARD)
12	SB	RECLINING SW (BACKWARD)
13	LG/R	FRONT LIFTING SW (DOWNWARD)
14	G/B	REAR LIFTING SW (DOWNWARD)
16	O	VCC
17	Y/R	TX

Connector No.	B4E2
Connector Name	DRIVER SEAT CONTROL UNIT
Connector Type	NS16FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
33	R	BAT (C/B)
35	W/R	SLIDING MOTOR(FORWARD)
36	G/Y	RECLINING MOTOR(FORWARD)
37	G/W	FRONT LIFTING MOTOR(DOWNWARD)
38	L/Y	REAR LIFTING MOTOR(UPWARD)
39	R/B	REAR LIFTING MOTOR(BACKWARD)
40	P/W	BATTERYUSE
42	W/B	SLIDING MOTOR(BACKWARD)
44	P	RECLINING MOTOR(BACKWARD)
45	L/R	FRONT LIFTING MOTOR(UPWARD)
48	B	GNDDPOWER

Connector No.	B4S3
Connector Name	SLIDING SENSOR
Connector Type	8898-0241



Terminal No.	Color of Wire	Signal Name [Specification]
16	O	-
24	R	-
31	GR	-

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER

Connector No.	B454
Connector Name	RECLINING MOTOR (WITH AUTOMATIC DRIVE POSITIONER)
Connector Type	NS06FW-CS



36	44
16	31
9	17

Terminal No.	Color of Wire	Signal Name [Specification]
9	W/G	-
16	O	-
31	GR	-
36	G/Y	-
44	P	-

Connector No.	B455
Connector Name	LIFTING MOTOR (FRONT) (DRIVER SIDE) (WITH AUTOMATIC DRIVE POSITIONER)
Connector Type	NS06FW-CS



45	37
16	31
25	10

Terminal No.	Color of Wire	Signal Name [Specification]
16	O	-
25	Y/B	-
31	GR	-
37	G/W	-
45	L/R	-

Connector No.	B459
Connector Name	POWER SEAT SWITCH (DRIVER SIDE) (WITH AUTOMATIC DRIVE POSITIONER)
Connector Type	NS10FW-CS



32	14
27	29
12	27
11	26
13	13
26	28
14	14
26	26
28	28
29	29
32	32

Terminal No.	Color of Wire	Signal Name [Specification]
11	BR	-
12	SB	-
13	LG/R	-
14	G/B	-
26	Y	-
27	R/G	-
28	W/B	-
29	P/L	-
32	B/W	-

Connector No.	B461
Connector Name	SLIDING MOTOR (DRIVER SIDE) (WITH AUTOMATIC DRIVE POSITIONER)
Connector Type	NS08S-0238



42	35
35	42

Terminal No.	Color of Wire	Signal Name [Specification]
35	W/R	-
42	W/B	-

Connector No.	B462
Connector Name	WIRE TO WIRE
Connector Type	NS16MW-CS



19	3	1	17	40
8	69	32	48	21
33	68	67		

Terminal No.	Color of Wire	Signal Name [Specification]
1	L/W	-
3	R/Y	-
8	LG	-
17	Y/R	-
19	V	-
21	L/Y	-
32	B/W	-
33	R	-
40	R/W	-
48	B	-

Connector No.	B463
Connector Name	LIFTING MOTOR (REAR) (DRIVER SIDE) (WITH AUTOMATIC DRIVE POSITIONER)
Connector Type	NS06FR-CS



38	39
16	31
10	10

Terminal No.	Color of Wire	Signal Name [Specification]
10	P/B	-
16	O	-
31	GR	-
38	L/Y	-
39	R/B	-

Connector No.	D1
Connector Name	WIRE TO WIRE
Connector Type	TH40PW-CS15



15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
14	13	12	11	10	9	8	7	6	5	4	3	2	1	
13	12	11	10	9	8	7	6	5	4	3	2	1		

Terminal No.	Color of Wire	Signal Name [Specification]
13	B	-
18	W	-
19	BR	-
21	R	-
22	P	-
23	O	-
24	BR	-
25	L	-
26	GR	-
27	Y	-
28	LG	-


39	G
30	GR
38	O
39	GR
40	G
43	BR
44	V
45	P
46	W

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER

Connector No.	D33
Connector Name	DOOR MIRROR (DRIVER SIDE)
Connector Type	TH12MW-NH




Terminal No.	Color of Wire	Signal Name [Specification]
5	O	- [With automatic drive positioner]
6	GR	- [With automatic drive positioner]
7	G	- [With automatic drive positioner]
9	P	-
10	BR	-
11	W	-
12	V	-

Connector No.	D33
Connector Name	DOOR MIRROR (PASSENGER SIDE)
Connector Type	TH12MW-NH




Terminal No.	Color of Wire	Signal Name [Specification]
5	O	- [Except for with A/T and automatic drive positioner]
6	GR	- [With A/T and automatic drive positioner]
7	G	- [With A/T and automatic drive positioner]
9	Y	- [Except for with A/T and automatic drive positioner]
10	BR	-
11	W	-
12	V	-

Connector No.	D5
Connector Name	SEAT MEMORY SWITCH
Connector Type	A08FW




Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	BR	-
3	GR	-
4	B	-
5	R	-
6	O	-
7	P	-

Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	TH60FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
91	W	-

Connector No.	D17
Connector Name	IGNITION MIRROR REMOTE CONTROL SWITCH (WITH AUTOMATIC DRIVE POSITIONER)
Connector Type	TK16FER




Terminal No.	Color of Wire	Signal Name [Specification]
4	BR	-
7	B	-
10	GR	-
11	LG	-
12	G	-
13	W	-
15	Y	-

Connector No.	F51
Connector Name	A/T ASSEMBLY
Connector Type	FR10FG-DGY




Terminal No.	Color of Wire	Signal Name [Specification]
3	L	-
8	P	-

Connector No.	D31
Connector Name	WIRE TO WIRE
Connector Type	TH40FW-CS15



Terminal No.	Color of Wire	Signal Name [Specification]
38	W	- [With A/T]
39	O	- [With M/T]
39	G	- [With A/T]
40	GR	- [With M/T]
40	Y	- [With A/T]
43	BR	- [With M/T]
44	V	-
45	P	-
46	W	-

Connector No.	F103
Connector Name	WIRE TO WIRE
Connector Type	TK38FW-NS10



Terminal No.	Color of Wire	Signal Name [Specification]
43	P	-
44	L	-

JCJWA0745GB


A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


AUTOMATIC DRIVE POSITIONER

Connector No.	F167
Connector Name	TOM (TRANSMISSION CONTROL MODULE)
Connector Type	SP10FG




Terminal No.	Color of Wire	Signal Name [Specification]
3	R	CAN-H
8	BR	CAN-L

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS06FW-M2



Terminal No.	Color of Wire	Signal Name [Specification]
4A	P	-
7A	R	-

Connector No.	M5
Connector Name	WIRE TO WIRE
Connector Type	TH40MW-CS15



Terminal No.	Color of Wire	Signal Name [Specification]
13	B	-
18	V	-
19	BR	-
21	W	-
22	P	-
23	O	-
24	V	-
25	BR	-
26	R	-
27	G	-
28	LG	-

29	SB	-
30	P	-
33	G	-
39	L	-
40	Y	-
43	G	-
44	Y	-
45	GR	-
46	W	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	TH60MW-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
91	W	-

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	TH60MW-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
3	SB	- [With automatic drive positioner]
14	R	- [With A/T]
14	O	- [With M/T]
15	BR	-
16	P	-
17	V	-
20	L	-
21	P	-
87	GR	-
98	O	-

Connector No.	M22
Connector Name	KEY SLOT
Connector Type	TH12FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	BAT
7	B	GND
11	SB	KEY SWITCH SIGNAL

Connector No.	M24
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FP-P



Terminal No.	Color of Wire	Signal Name [Specification]
6	L	-
14	P	-

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER

Connector No.	M43
Connector Name	TILT & TELESCOPIC SWITCH
Connector Type	TK08FY



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	GR	-
3	G	-
4	Y	-
5	BR	-

Connector No.	M48
Connector Name	TILT & TELESCOPIC SENSOR
Connector Type	TK04FW




Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	P	-
3	O	-
4	Y	-

Connector No.	M49
Connector Name	TILT & TELESCOPIC MOTOR
Connector Type	NS04FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	GR	-
3	O	-
4	L	-


Connector No.	M61
Connector Name	AUTOMATIC DRIVE POSITIONER CONTROL UNIT
Connector Type	THZ2FW-RH



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	TILT SW (UPWARD)
2	LG	MIRROR SELECT SW (RH)
3	G	MIRROR SW (UPWARD)
4	V	MIRROR SW (LEFTWARD)
5	R	MIRROR SENSOR (RH VERTICAL)
6	GR	MIRROR SENSOR (LH VERTICAL)
7	O	TILT SENSOR
8	BR	ADDRESS1
9	V	TX (UART)
10	GR	TELESCOPIC SW (FRONTWARD)
11	GR	IND1
12	O	

Terminal No.	Color of Wire	Signal Name [Specification]
13	P	IND2
14	W	MIRROR MOTOR (RH VERTICAL)
15	O	MIRROR MOTOR (RH HORIZONTAL)
16	Y	MIRROR MOTOR (LH COMMON)
17	BR	TILT SW (DOWNWARD)
18	P	MIRROR SELECT SW (LH)
19	SB	MIRROR SW (DOWNWARD)
20	BR	MIRROR SW (RIGHTWARD)
21	L	MIRROR SENSOR (RH HORIZONTAL)
22	G	MIRROR SENSOR (LH HORIZONTAL)
23	P	TELESCOPIC SENSOR
24	R	SET SW
25	V	ADDRESS2
26	P	RX (UART)
27	G	TELESCOPIC SW (BACKWARD)
30	SB	MIRROR MOTOR (RH COMMON)
31	G	MIRROR MOTOR (LH VERTICAL)
32	L	MIRROR MOTOR (LH HORIZONTAL)

Connector No.	ME2
Connector Name	AUTOMATIC DRIVE POSITIONER CONTROL UNIT
Connector Type	NS16FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
33	W	POWER SUPPLY (SENSOR)
34	V	BAT (FUSE)
35	L	TILT MOTOR (UPWARD)
36	GR	TELESCOPIC MOTOR (FORWARD)
39	W	BAT (C/E)
40	B	GNDSIGNAL
41	Y	GNDSIGNAL
42	O	TILT MOTOR (DOWNWARD)
44	G	TELESCOPIC MOTOR (BACKWARD)
48	B	GNDCOMPER

Connector No.	ME2
Connector Name	CIRCUIT BREAKER
Connector Type	ME2FW-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	SB	- [With automatic drive positioner]


A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


AUTOMATIC DRIVE POSITIONER

Connector No.	M67
Connector Name	UNIFIED METER AND A/C AMP.
Connector Type	THB2FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
56	L	CAN-H
72	P	CAN-L

Connector No.	M116
Connector Name	WIRE TO WIRE
Connector Type	TK38AW-NS10



Terminal No.	Color of Wire	Signal Name [Specification]
43	P	-
44	L	-

Connector No.	M118
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	M83FB-LC




Terminal No.	Color of Wire	Signal Name [Specification]
1	W	BAT (F/L)

Connector No.	M119
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS18FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
11	R	BAT (FUSE)
13	B	GND

Connector No.	M122
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH




Terminal No.	Color of Wire	Signal Name [Specification]
90	P	CAN-L
91	L	CAN-H
96	GR	A/T SHIFT SELECTOR POWER SUPPLY
99	R	SHIFT P [With A/T]

Connector No.	M123
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FG-NH



Terminal No.	Color of Wire	Signal Name [Specification]
121	SB	KEY SLOT SW
150	GR	DRIVER DOOR SW

Connector No.	M124
Connector Name	WIRE TO WIRE
Connector Type	TH40MW-CS15



Terminal No.	Color of Wire	Signal Name [Specification]
38	W	-
39	O	-
40	SB	-
43	L	-
44	Y	-
45	R	-
46	W	-

Connector No.	M137
Connector Name	A/T SHIFT SELECTOR
Connector Type	TH12FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
10	GR	-
11	R	-

JCJWA0748GB

HEATED SEAT CONTROL UNIT


< ECU DIAGNOSIS INFORMATION >

HEATED SEAT CONTROL UNIT DRIVER SIDE

DRIVER SIDE : Reference Value

INFOID:000000004535489

TERMINAL LAYOUT



PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition	Voltage (V) (Approx.)	
(+)	(-)	Signal name	Input/ Output			
48 (B)	Ground	Ground	-	Ignition switch ON	0	
67 (R)	Ground	IGN power supply	Input	Ignition switch	OFF or ACC ON	0 Battery voltage
				Heated seat switch	OFF	0
1 (Min. temperature)	12.24					
2	12.33					
3	12.49					
4	12.63					
5	12.76					
68 (L) ^{*1} (L/W) ^{*2}	Ground	Heated seat switch signal	Input	Heated seat	6 (Max. temperature)	12.90
				Heated seat	Operate	Battery voltage
69 (BR/W) ^{*1} (R/W) ^{*2}	Ground	Heated seat operation signal	Input		Heated seat	Other than above
				Heated seat	Operate	0 – Battery voltage*
70 (L/W) ^{*1} (R/L) ^{*2}	Ground	Heater unit power supply	Output		Heated seat	Operate
				Heated seat	Other than above	0
71 (R/B)	Ground	Heat sensor signal	Input	Heated seat switch	OFF	0
					1 (Min. temperature)	10.87 – 11.02*
					2	10.93 – 11.07*
					3	11.04 – 11.17*
					4	11.13 – 11.26*
					5	11.22 – 11.34*
6 (Max. temperature)	11.31 – 11.43*					

*: Voltage is repeated within the value shown as per the following list depending on heater unit temperature.


*1: With automatic drive positioner

*2: Without automatic drive positioner

HEATED SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

DRIVER SIDE : Wiring Diagram - HEATED SEAT SYSTEM (WITH M/T) - INFOID:000000004535490



2008/08/07

JCJWA0729GB

HEATED SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

A

B

C

D

E

F

G

H

I

SE

K



L

M

N

O

P



*: This connector is not shown in "Harness Layout".


JCJWA0730GB

HEATED SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


HEATED SEAT (WITH M/T)

Connector No.	B201
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS/8-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
6	L	-
7	V	-

Connector No.	B02
Connector Name	WIRE TO WIRE
Connector Type	MO8FW-LC




Terminal No.	Color of Wire	Signal Name [Specification]
2	B	-
14	O	-
15	GR	-
16	R	-

Connector No.	B59
Connector Name	WIRE TO WIRE
Connector Type	NS16FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
48	B	-
67	O	-
68	GR	-
69	R	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	-
2	O	-
6	R	-

Connector No.	B425
Connector Name	WIRE TO WIRE
Connector Type	MO2MW-LC




Terminal No.	Color of Wire	Signal Name [Specification]
1	-	-
2	-	-

Connector No.	B424
Connector Name	WIRE TO WIRE
Connector Type	MO2FW-LC




Terminal No.	Color of Wire	Signal Name [Specification]
1	-	-
2	-	-

Connector No.	B421
Connector Name	WIRE TO WIRE
Connector Type	MO6MW-LC



Terminal No.	Color of Wire	Signal Name [Specification]
2	B	-
14	R	-
15	L/W	-
16	R/W	-

Connector No.	B209
Connector Name	WIRE TO WIRE
Connector Type	MO8FW-LC



Terminal No.	Color of Wire	Signal Name [Specification]
2	B	-
14	L	-
15	V	-
16	BR	-

JCJWA0731GB

HEATED SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

HEATED SEAT (WITH M/T)

Connector No.	B439
Connector Name	WIRE TO WIRE
Connector Type	M02FW-LC



Terminal No.	Color of Wire	Signal Name [Specification]
2	B	-
14	R	-
15	L/W	-
16	R/W	-

Connector No.	B440
Connector Name	HEATED SEAT CONTROL UNIT (PASSENGER SIDE)
Connector Type	AMP 174923-1



Terminal No.	Color of Wire	Signal Name [Specification]
2	B	GND
14	R	HEATER (+)
15	L/W	HEATER SW
16	R/W	THERMISTOR INPUT
17	R/L	HEATER (+)
18	R/B	THERMISTOR OUTPUT

Connector No.	B445
Connector Name	WIRE TO WIRE
Connector Type	M02FW-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	-	-
2	-	-

Connector No.	B441
Connector Name	SEAT CUSHION HEATER (PASSENGER SIDE)
Connector Type	SD4FW



Terminal No.	Color of Wire	Signal Name [Specification]
2	B	-
16	R/W	-
17	R/L	-
18	R/B	-

Connector No.	B466
Connector Name	HEATED SEAT CONTROL UNIT (DRIVER SIDE)
Connector Type	AMP 174923-1



Terminal No.	Color of Wire	Signal Name [Specification]
48	B	GND
67	R	HEATER (+)
68	L	HEATER SW [With automatic drive positioner]
68	L/W	HEATER SW [Without automatic drive positioner]
69	BR/W	THERMISTOR INPUT [With automatic drive positioner]
69	R/W	THERMISTOR INPUT [Without automatic drive positioner]
70	L/W	HEATER (+) [With automatic drive positioner]
70	R/L	HEATER (+) [Without automatic drive positioner]
71	R/B	THERMISTOR OUTPUT

Connector No.	B444
Connector Name	WIRE TO WIRE
Connector Type	M02FW-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	-	-
2	-	-

Connector No.	B467
Connector Name	SEAT CUSHION HEATER (DRIVER SIDE)
Connector Type	SD4FW



Terminal No.	Color of Wire	Signal Name [Specification]
48	B	-
69	BR/W	- [With automatic drive positioner]
69	R/W	- [Without automatic drive positioner]
70	L/W	- [With automatic drive positioner]
70	R/L	- [Without automatic drive positioner]
71	R/B	-


A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

HEATED SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


HEATED SEAT (WITH M/T)

Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4




Terminal No.	97	Y	Signal Name [Specification]
--------------	----	---	-----------------------------

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS08FW-M2




Terminal No.	2A	G	Signal Name [Specification]
--------------	----	---	-----------------------------

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4




Terminal No.	97	L	Signal Name [Specification]
--------------	----	---	-----------------------------

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4




Terminal No.	1	GR	Signal Name [Specification]
Terminal No.	2	G	
Terminal No.	6	L	

Connector No.	M70
Connector Name	HEATED SEAT RELAY
Connector Type	MS02FL-M2-LC




Terminal No.	1	B	Signal Name [Specification]
Terminal No.	2	G	- [With M/T]
Terminal No.	3	G	
Terminal No.	5	L	

Connector No.	M17
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4




Terminal No.	1	GR	Signal Name [Specification]
Terminal No.	6	G	
Terminal No.	7	SB	

Connector No.	M136
Connector Name	WIRE TO WIRE
Connector Type	TH12PW-NH



Terminal No.	1	L	Signal Name [Specification]
Terminal No.	2	GR	
Terminal No.	3	G	
Terminal No.	6	G	
Terminal No.	7	B	
Terminal No.	10	GR	
Terminal No.	11	B	
Terminal No.	12	SB	

Connector No.	M174
Connector Name	WIRE TO WIRE
Connector Type	TH12MP-NH



Terminal No.	1	L	Signal Name [Specification]
Terminal No.	2	GR	
Terminal No.	3	W	
Terminal No.	6	W	
Terminal No.	7	B	
Terminal No.	10	GR	
Terminal No.	11	GR	
Terminal No.	12	SB	

JCJWA0733GB

HEATED SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

HEATED SEAT (WITH M/T)

Connector No.	MT75
Connector Name	HEATED SEAT SWITCH (DRIVER SIDE) (WITH M/T)
Connector Type	TK09FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	GR	-
5	W	-
6	B	-

Connector No.	MT76
Connector Name	HEATED SEAT SWITCH (PASSENGER SIDE) (WITH M/T)
Connector Type	TK08FBR




Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	-
2	SB	-
5	W	-
6	GR	-

HEATED SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

DRIVER SIDE : Wiring Diagram - HEATED SEAT SYSTEM (WITH A/T) -

INFOID:000000004535491



2008/08/07

JCJWA0735GB

HEATED SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

A

B

C

D

E

F

G

H

I

SE

K


L

M

N

O

P




JCJWA0736GB

HEATED SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


HEATED SEAT (WITH A/T)

Connector No.	B201
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS/8-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
6	L	-
7	V	-

Connector No.	B202
Connector Name	WIRE TO WIRE
Connector Type	MG8FW-LC




Terminal No.	Color of Wire	Signal Name [Specification]
2	B	-
14	O	-
15	GR	-
16	R	-

Connector No.	B59
Connector Name	WIRE TO WIRE
Connector Type	NS16FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
48	B	-
67	O	-
68	GR	-
69	R	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS/16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	-
2	O	-
6	R	-

Connector No.	B425
Connector Name	WIRE TO WIRE
Connector Type	MG2MW-LC




Terminal No.	Color of Wire	Signal Name [Specification]
1	-	-
2	-	-

Connector No.	B424
Connector Name	WIRE TO WIRE
Connector Type	MG2FW-LC




Terminal No.	Color of Wire	Signal Name [Specification]
1	-	-
2	-	-

Connector No.	B421
Connector Name	WIRE TO WIRE
Connector Type	MG6MW-LC



Terminal No.	Color of Wire	Signal Name [Specification]
2	B	-
14	R	-
15	L/W	-
16	R/W	-

Connector No.	B209
Connector Name	WIRE TO WIRE
Connector Type	MG8FW-LC



Terminal No.	Color of Wire	Signal Name [Specification]
2	B	-
14	L	-
15	V	-
16	BR	-

JCJWA0737GB

HEATED SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

HEATED SEAT (WITH A/T)

Connector No.	B439
Connector Name	WIRE TO WIRE
Connector Type	M02FW-LC



Terminal No.	Color of Wire	Signal Name [Specification]
2	B	-
14	R	-
15	L/W	-
16	R/W	-

Connector No.	B440
Connector Name	HEATED SEAT CONTROL UNIT (PASSENGER SIDE)
Connector Type	AMP 174923-1



Terminal No.	Color of Wire	Signal Name [Specification]
2	B	GND
14	R	HEATER (+)
15	L/W	HEATER SW
16	R/W	THERMISTOR INPUT
17	R/L	HEATER (+)
18	R/B	THERMISTOR OUTPUT

Connector No.	B445
Connector Name	WIRE TO WIRE
Connector Type	M02FW-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	-	-
2	-	-

Connector No.	B441
Connector Name	SEAT CUSHION HEATER (PASSENGER SIDE)
Connector Type	SD4FW



Terminal No.	Color of Wire	Signal Name [Specification]
2	B	-
16	R/W	-
17	R/L	-
18	R/B	-

Connector No.	B466
Connector Name	HEATED SEAT CONTROL UNIT (DRIVER SIDE)
Connector Type	AMP 174923-1



Terminal No.	Color of Wire	Signal Name [Specification]
48	B	GND
67	R	HEATER (+)
68	L	HEATER SW [With automatic drive positioner]
68	L/W	HEATER SW [Without automatic drive positioner]
69	BR/W	THERMISTOR INPUT [With automatic drive positioner]
69	R/W	THERMISTOR INPUT [Without automatic drive positioner]
70	L/W	HEATER (+) [With automatic drive positioner]
70	R/L	HEATER (+) [Without automatic drive positioner]
71	R/B	THERMISTOR OUTPUT

Connector No.	B444
Connector Name	WIRE TO WIRE
Connector Type	M02FW-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	-	-
2	-	-

Connector No.	B467
Connector Name	SEAT CUSHION HEATER (DRIVER SIDE)
Connector Type	SD4FW



Terminal No.	Color of Wire	Signal Name [Specification]
48	B	-
69	BR/W	- [With automatic drive positioner]
69	R/W	- [Without automatic drive positioner]
70	L/W	- [With automatic drive positioner]
70	R/L	- [Without automatic drive positioner]
71	R/B	-


A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

HEATED SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


HEATED SEAT (WITH A/T)

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	
2	G	
6	L	

Connector No.	M8
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
97	L	

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS08FW-M2




Terminal No.	Color of Wire	Signal Name [Specification]
2A	G	

Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
97	Y	

Connector No.	M142
Connector Name	HEATED SEAT SWITCH (PASSENGER SIDE) (WITH A/T)
Connector Type	TK08FBR




Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	
2	SB	
5	G	
6	B	

Connector No.	M141
Connector Name	HEATED SEAT SWITCH (DRIVER SIDE) (WITH A/T)
Connector Type	TK10FPW




Terminal No.	Color of Wire	Signal Name [Specification]
1	L	
2	GR	
5	G	
6	B	

Connector No.	M117
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	
6	G	
7	SB	

Connector No.	M70
Connector Name	HEATED SEAT RELAY
Connector Type	MS02FL-M2-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	
2	G	
3	G	
5	L	

PASSENGER SIDE

JCJWA0739GB


HEATED SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

PASSENGER SIDE : Reference Value

INFOID:000000004535494

TERMINAL LAYOUT



PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition	Voltage (V) (Approx.)	
(+)	(-)	Signal name	Input/ Output			
2 (B)	Ground	Ground	-	Ignition switch ON	0	
14 (R)	Ground	IGN power supply	Input	Ignition switch	OFF or ACC ON Battery voltage	
15 (L/W)	Ground	Heated seat switch signal	Input	Heated seat switch	OFF	0
					1 (Min. temperature)	12.24
					2	12.33
					3	12.49
					4	12.63
					5	12.76
16 (R/W)	Ground	Heated seat operation signal	Input	Heated seat	Operate	Battery voltage
					Other than above	0
17 (R/L)	Ground	Heater unit power supply	Output	Heated seat	Operate	0 – Battery voltage*
					Other than above	0
18 (R/B)	Ground	Heat sensor signal	Input	Heated seat switch	OFF	0
					1 (Min. temperature)	10.87 – 11.02*
					2	10.93 – 11.07*
					3	11.04 – 11.17*
					4	11.13 – 11.26*
					5	11.22 – 11.34*
6 (Max. temperature)	11.31 – 11.43*					


*: Voltage is repeated within the value shown as per the following list depending on heater unit temperature.

HEATED SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

PASSENGER SIDE : Wiring Diagram - HEATED SEAT SYSTEM (WITH M/T) -

INFOID:000000004684697





2008/08/07

JCJWA0729GB

HEATED SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P



*: This connector is not shown in "Harness Layout".


JCJWA0730GB

HEATED SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


HEATED SEAT (WITH M/T)

Connector No.	B201
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS/8-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
6	L	-
7	V	-

Connector No.	B202
Connector Name	WIRE TO WIRE
Connector Type	MO8FW-LC




Terminal No.	Color of Wire	Signal Name [Specification]
2	B	-
14	O	-
15	GR	-
16	R	-

Connector No.	B59
Connector Name	WIRE TO WIRE
Connector Type	NS16FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
48	B	-
67	O	-
68	GR	-
69	R	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS/16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	-
2	O	-
6	R	-

Connector No.	B425
Connector Name	WIRE TO WIRE
Connector Type	MO2MW-LC




Terminal No.	Color of Wire	Signal Name [Specification]
1	-	-
2	-	-

Connector No.	B424
Connector Name	WIRE TO WIRE
Connector Type	MO2FW-LC




Terminal No.	Color of Wire	Signal Name [Specification]
1	-	-
2	-	-

Connector No.	B421
Connector Name	WIRE TO WIRE
Connector Type	MO6MW-LC



Terminal No.	Color of Wire	Signal Name [Specification]
2	B	-
14	R	-
15	L/W	-
16	R/W	-

Connector No.	B209
Connector Name	WIRE TO WIRE
Connector Type	MO8FW-LC



Terminal No.	Color of Wire	Signal Name [Specification]
2	B	-
14	L	-
15	V	-
16	BR	-

JCJWA0731GB

HEATED SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

HEATED SEAT (WITH M/T)

Connector No.	B439
Connector Name	WIRE TO WIRE
Connector Type	M02FW-LC



Terminal No.	Color of Wire	Signal Name [Specification]
2	B	-
14	R	-
15	L/W	-
16	R/W	-

Connector No.	B440
Connector Name	HEATED SEAT CONTROL UNIT (PASSENGER SIDE)
Connector Type	AMP 174923-1



Terminal No.	Color of Wire	Signal Name [Specification]
2	B	GND
14	R	HEATER (+)
15	L/W	HEATER SW
16	R/W	THERMISTOR INPUT
17	R/L	HEATER (+)
18	R/B	THERMISTOR OUTPUT

Connector No.	B441
Connector Name	SEAT CUSHION HEATER (PASSENGER SIDE)
Connector Type	SD4FW



Terminal No.	Color of Wire	Signal Name [Specification]
2	B	-
16	R/W	-
17	R/L	-
18	R/B	-

Connector No.	B444
Connector Name	WIRE TO WIRE
Connector Type	M02FW-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	-	-
2	-	-

Connector No.	B445
Connector Name	WIRE TO WIRE
Connector Type	M02FW-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	-	-
2	-	-

Connector No.	B492
Connector Name	WIRE TO WIRE
Connector Type	NS16MW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
48	B	-
67	R	-
68	L	-
69	BR/W	-

Connector No.	B466
Connector Name	HEATED SEAT CONTROL UNIT (DRIVER SIDE)
Connector Type	AMP 174923-1



Terminal No.	Color of Wire	Signal Name [Specification]
48	B	GND
67	R	HEATER (+)
68	L	HEATER SW [With automatic drive positioner]
68	L/W	HEATER SW [Without automatic drive positioner]
69	BR/W	THERMISTOR INPUT [With automatic drive positioner]
69	R/W	THERMISTOR INPUT [Without automatic drive positioner]
70	L/W	HEATER (+) [With automatic drive positioner]
70	R/L	HEATER (+) [Without automatic drive positioner]
71	R/B	THERMISTOR OUTPUT

Connector No.	B467
Connector Name	SEAT CUSHION HEATER (DRIVER SIDE)
Connector Type	SD4FW



Terminal No.	Color of Wire	Signal Name [Specification]
48	B	-
69	BR/W	- [With automatic drive positioner]
69	R/W	- [Without automatic drive positioner]
70	L/W	- [With automatic drive positioner]
70	R/L	- [Without automatic drive positioner]
71	R/B	-

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

HEATED SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


HEATED SEAT (WITH M/T)

Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	97	Y	-
Color of Wire			
Signal Name [Specification]			

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS08FW-M2



Terminal No.	2A	G	-
Color of Wire			
Signal Name [Specification]			

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4




Terminal No.	97	L	-
Color of Wire			
Signal Name [Specification]			

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4




Terminal No.	1	GR	-
Color of Wire			
Signal Name [Specification]			
Terminal No.	2	G	-
Color of Wire			
Signal Name [Specification]			
Terminal No.	6	L	-
Color of Wire			
Signal Name [Specification]			

Connector No.	M70
Connector Name	HEATED SEAT RELAY
Connector Type	MS02FL-M2-LC




Terminal No.	1	B	-
Color of Wire			
Signal Name [Specification]			
Terminal No.	2	G	-
Color of Wire			
Signal Name [Specification]			
Terminal No.	3	G	-
Color of Wire			
Signal Name [Specification]			
Terminal No.	5	L	-
Color of Wire			
Signal Name [Specification]			

Connector No.	M136
Connector Name	WIRE TO WIRE
Connector Type	TH12PW-NH



Terminal No.	1	L	-
Color of Wire			
Signal Name [Specification]			
Terminal No.	2	GR	-
Color of Wire			
Signal Name [Specification]			
Terminal No.	3	G	-
Color of Wire			
Signal Name [Specification]			
Terminal No.	6	G	-
Color of Wire			
Signal Name [Specification]			
Terminal No.	7	B	-
Color of Wire			
Signal Name [Specification]			
Terminal No.	10	GR	-
Color of Wire			
Signal Name [Specification]			
Terminal No.	11	B	-
Color of Wire			
Signal Name [Specification]			
Terminal No.	12	SB	-
Color of Wire			
Signal Name [Specification]			

Connector No.	M174
Connector Name	WIRE TO WIRE
Connector Type	TH12MP-NH



Terminal No.	1	L	-
Color of Wire			
Signal Name [Specification]			
Terminal No.	2	GR	-
Color of Wire			
Signal Name [Specification]			
Terminal No.	3	W	-
Color of Wire			
Signal Name [Specification]			
Terminal No.	6	W	-
Color of Wire			
Signal Name [Specification]			
Terminal No.	7	B	-
Color of Wire			
Signal Name [Specification]			
Terminal No.	10	GR	-
Color of Wire			
Signal Name [Specification]			
Terminal No.	11	GR	-
Color of Wire			
Signal Name [Specification]			
Terminal No.	12	SB	-
Color of Wire			
Signal Name [Specification]			

HEATED SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

HEATED SEAT (WITH M/T)

Connector No.	M175
Connector Name	HEATED SEAT SWITCH (DRIVER SIDE) (WITH M/T)
Connector Type	TK09FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	GR	-
5	W	-
6	B	-

Connector No.	M176
Connector Name	HEATED SEAT SWITCH (PASSENGER SIDE) (WITH M/T)
Connector Type	TK08FBR




Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	-
2	SB	-
5	W	-
6	GR	-

HEATED SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

PASSENGER SIDE : Wiring Diagram - HEATED SEAT SYSTEM (WITH A/T) -

INFOID:000000004684698



2008/08/07

JCJWA0735GB

HEATED SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

A

B

C

D

E

F

G

H

I

SE

K


L

M

N

O

P




JCJWA0736GB

HEATED SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


HEATED SEAT (WITH A/T)

Connector No.	B201
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS/8-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
6	L	-
7	V	-

Connector No.	B202
Connector Name	WIRE TO WIRE
Connector Type	MG8FW-LC




Terminal No.	Color of Wire	Signal Name [Specification]
2	B	-
14	O	-
15	GR	-
16	R	-

Connector No.	B59
Connector Name	WIRE TO WIRE
Connector Type	NS16FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
48	B	-
67	O	-
68	GR	-
69	R	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	-
2	O	-
6	R	-

Connector No.	B425
Connector Name	WIRE TO WIRE
Connector Type	MG2MW-LC




Terminal No.	Color of Wire	Signal Name [Specification]
1	-	-
2	-	-

Connector No.	B424
Connector Name	WIRE TO WIRE
Connector Type	MG2FW-LC




Terminal No.	Color of Wire	Signal Name [Specification]
1	-	-
2	-	-

Connector No.	B421
Connector Name	WIRE TO WIRE
Connector Type	MG6MW-LC



Terminal No.	Color of Wire	Signal Name [Specification]
2	B	-
14	R	-
15	L/W	-
16	R/W	-

Connector No.	B209
Connector Name	WIRE TO WIRE
Connector Type	MG8FW-LC



Terminal No.	Color of Wire	Signal Name [Specification]
2	B	-
14	L	-
15	V	-
16	BR	-

JCJWA0737GB

HEATED SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

HEATED SEAT (WITH A/T)

Connector No.	B439
Connector Name	WIRE TO WIRE
Connector Type	M02FW-LC



Terminal No.	Color of Wire	Signal Name [Specification]
2	B	-
14	R	-
15	L/W	-
16	R/W	-

Connector No.	B440
Connector Name	HEATED SEAT CONTROL UNIT (PASSENGER SIDE)
Connector Type	AMP 174923-1



Terminal No.	Color of Wire	Signal Name [Specification]
2	B	GND
14	R	HEATER (+)
15	L/W	HEATER SW
16	R/W	THERMISTOR INPUT
17	R/L	HEATER (+)
18	R/B	THERMISTOR OUTPUT

Connector No.	B441
Connector Name	SEAT CUSHION HEATER (PASSENGER SIDE)
Connector Type	SD4FW



Terminal No.	Color of Wire	Signal Name [Specification]
2	B	-
16	R/W	-
17	R/L	-
18	R/B	-

Connector No.	B444
Connector Name	WIRE TO WIRE
Connector Type	M02FW-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	-	-
2	-	-

Connector No.	B445
Connector Name	WIRE TO WIRE
Connector Type	M02FW-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	-	-
2	-	-

Connector No.	B492
Connector Name	WIRE TO WIRE
Connector Type	INS16MW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
48	B	-
67	R	-
68	L	-
69	BR/W	-

Connector No.	B466
Connector Name	HEATED SEAT CONTROL UNIT (DRIVER SIDE)
Connector Type	AMP 174923-1



Terminal No.	Color of Wire	Signal Name [Specification]
48	B	GND
67	R	HEATER (+)
68	L	HEATER SW [With automatic drive positioner]
68	L/W	HEATER SW [Without automatic drive positioner]
69	BR/W	THERMISTOR INPUT [With automatic drive positioner]
69	R/W	THERMISTOR INPUT [Without automatic drive positioner]
70	L/W	HEATER (+) [With automatic drive positioner]
70	R/L	HEATER (+) [Without automatic drive positioner]
71	R/B	THERMISTOR OUTPUT

Connector No.	B467
Connector Name	SEAT CUSHION HEATER (DRIVER SIDE)
Connector Type	SD4FW



Terminal No.	Color of Wire	Signal Name [Specification]
48	B	-
69	BR/W	- [With automatic drive positioner]
69	R/W	- [Without automatic drive positioner]
70	L/W	- [With automatic drive positioner]
70	R/L	- [Without automatic drive positioner]
71	R/B	-


A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

HEATED SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

HEATED SEAT (WITH A/T)

Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	97	Y	-
Color of Wire			
Signal Name [Specification]			

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS08FW-M2




Terminal No.	2A	G	-
Color of Wire			
Signal Name [Specification]			

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4




Terminal No.	97	L	-
Color of Wire			
Signal Name [Specification]			

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4




Terminal No.	1	GR	-
Color of Wire			
Signal Name [Specification]			
Terminal No.	2	G	-
Color of Wire			
Signal Name [Specification]			
Terminal No.	6	L	-
Color of Wire			
Signal Name [Specification]			

Connector No.	M70
Connector Name	HEATED SEAT RELAY
Connector Type	MS02FL-M2-LC




Terminal No.	1	G	-
Color of Wire			
Signal Name [Specification]			
Terminal No.	2	G	-
Color of Wire			
Signal Name [Specification]			
Terminal No.	3	G	-
Color of Wire			
Signal Name [Specification]			
Terminal No.	5	L	-
Color of Wire			
Signal Name [Specification]			

Connector No.	M17
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4




Terminal No.	1	GR	-
Color of Wire			
Signal Name [Specification]			
Terminal No.	6	G	-
Color of Wire			
Signal Name [Specification]			
Terminal No.	7	SB	-
Color of Wire			
Signal Name [Specification]			

Connector No.	M141
Connector Name	HEATED SEAT SWITCH (DRIVER SIDE) (WITH A/T)
Connector Type	TK08FW



Terminal No.	1	L	-
Color of Wire			
Signal Name [Specification]			
Terminal No.	2	GR	-
Color of Wire			
Signal Name [Specification]			
Terminal No.	5	G	-
Color of Wire			
Signal Name [Specification]			
Terminal No.	6	B	-
Color of Wire			
Signal Name [Specification]			

Connector No.	M142
Connector Name	HEATED SEAT SWITCH (PASSENGER SIDE) (WITH A/T)
Connector Type	TK08FW



Terminal No.	1	GR	-
Color of Wire			
Signal Name [Specification]			
Terminal No.	2	SB	-
Color of Wire			
Signal Name [Specification]			
Terminal No.	5	G	-
Color of Wire			
Signal Name [Specification]			
Terminal No.	6	B	-
Color of Wire			
Signal Name [Specification]			

HEATED SEAT DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

HEATED SEAT DOES NOT OPERATE
BOTH SIDES

BOTH SIDES : Diagnosis Procedure

INFOID:000000004535500

1.CHECK HEATED SEAT SWITCH POWER SUPPLY

Check heated seat switch power supply.

Refer to [SE-14, "HEATED SEAT SWITCH : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK HEATED SEAT RELAY

Check heated seat relay.

Refer to [SE-21, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CHECK HEATED SEAT CONTROL UNIT POWER SUPPLY AND GROUND CIRCUIT

Check heated seat switch power supply and ground circuit.

Refer to [SE-12, "HEATED SEAT CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4.CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> GO TO 1.

DRIVER SIDE

DRIVER SIDE : Diagnosis Procedure

INFOID:000000004535501

1.CHECK HEATED SEAT SWITCH POWER SUPPLY

Check heated seat switch power supply.

Refer to [SE-14, "HEATED SEAT SWITCH : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK HEATED SEAT CONTROL UNIT POWER SUPPLY AND GROUND CIRCUIT

Check heated seat switch power supply and ground circuit.

Refer to [SE-12, "HEATED SEAT CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CHECK HEATED SEAT SWITCH

Check heated seat switch.

Refer to [SE-17, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

A

B

C

D

E

F

G

H

I

SE

K

L

M

N

O

P

HEATED SEAT DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

- YES >> GO TO 4.
- NO >> Repair or replace the malfunctioning parts.

4.CHECK SEAT CUSHION HEATER

Check seat cushion heater.

Refer to [SE-28, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Repair or replace the malfunctioning parts.

5.CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
- NO >> GO TO 1.

PASSENGER SIDE

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000004535502

1.CHECK HEATED SEAT SWITCH POWER SUPPLY

Check heated seat switch power supply.

Refer to [SE-14, "HEATED SEAT SWITCH : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair or replace the malfunctioning parts.

2.CHECK HEATED SEAT CONTROL UNIT POWER SUPPLY AND GROUND CIRCUIT

Check heated seat switch power supply and ground circuit.

Refer to [SE-12, "HEATED SEAT CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace the malfunctioning parts.

3.CHECK HEATED SEAT SWITCH

Check heated seat switch.

Refer to [SE-18, "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair or replace the malfunctioning parts.

4.CHECK SEAT CUSHION HEATER

Check seat cushion heater.

Refer to [SE-29, "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Repair or replace the malfunctioning parts.

5.CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
- NO >> GO TO 1.

SEATBACK HEATER ONLY DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

SEATBACK HEATER ONLY DOES NOT OPERATE DRIVER SIDE

DRIVER SIDE : Diagnosis Procedure

INFOID:000000004535503

1.CHECK SEATBACK HEATER

Check seatback heater.

Refer to [SE-32, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> GO TO 1.

PASSENGER SIDE

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000004535504

1.CHECK SEATBACK HEATER

Check seatback heater.

Refer to [SE-32, "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> GO TO 1.

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

CANNOT ADJUST HEATED SEAT TEMPERATURE

< SYMPTOM DIAGNOSIS >

CANNOT ADJUST HEATED SEAT TEMPERATURE DRIVER SIDE

DRIVER SIDE : Diagnosis Procedure

INFOID:000000004535505

1.CHECK HEATED SEAT SWITCH

Check heated seat switch.

Refer to [SE-17, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK HEAT SENSOR

Check heat sensor.

Refer to [SE-23, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> Replace heated seat control unit. Refer to [SE-128, "Removal and Installation"](#).

PASSENGER SIDE

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000004535506

1.CHECK HEATED SEAT SWITCH

Check heated seat switch.

Refer to [SE-18, "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK HEAT SENSOR

Check heat sensor.

Refer to [SE-25, "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> Replace heated seat control unit. Refer to [SE-128, "Removal and Installation"](#).

HEATED SEAT SWITCH INDICATOR DOES NOT TURN ON

< SYMPTOM DIAGNOSIS >

HEATED SEAT SWITCH INDICATOR DOES NOT TURN ON DRIVER SIDE

DRIVER SIDE : Diagnosis Procedure

INFOID:000000004535507

1.CHECK HEATED SEAT SWITCH INDICATOR

Check heated seat switch indicator.

Refer to [SE-34, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> GO TO 1.

PASSENGER SIDE

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000004535508

1.CHECK HEATED SEAT SWITCH INDICATOR

Check heated seat switch indicator.

Refer to [SE-34, "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> GO TO 1.

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

STEERING POSITION FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

STEERING POSITION FUNCTION DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000004240991

1. CHECK AUTOMATIC DRIVE POSITIONER CONTROL UNIT POWER SUPPLY AND GROUND CIRCUIT

Check automatic drive positioner control unit power supply and ground circuit.

Refer to [ADP-66, "AUTOMATIC DRIVE POSITIONER CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK TILT AND TELESCOPIC SWITCH

Check tilt and telescopic switch.

Refer to [SE-36, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK TILT AND TELESCOPIC SENSOR

Check tilt and telescopic sensor.

Refer to [SE-41, "Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

TILT FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

TILT FUNCTION DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000004240992

1.CHECK TILT AND TELESCOPIC SWITCH

Check tilt switch.

Refer to [SE-36, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK TILT AND TELESCOPIC MOTOR

Check tilt motor.

Refer to [SE-39, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CHECK TILT AND TELESCOPIC SENSOR

Check tilt sensor.

Refer to [SE-41, "Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

SE

TELESCOPIC FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

TELESCOPIC FUNCTION DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000004240993

1. CHECK TILT AND TELESCOPIC SWITCH

Check telescopic switch.

Refer to [SE-36, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK TILT AND TELESCOPIC MOTOR

Check telescopic motor.

Refer to [SE-39, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK TILT AND TELESCOPIC SENSOR

Check telescopic sensor.

Refer to [SE-41, "Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.


SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

SQUEAK AND RATTLE TROUBLE DIAGNOSES

Work Flow

INFOID:000000004684735



CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any of customer's comments; refer to [SE-107, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, perform a diagnosis and repair the noise that the customer is concerned about. This can be accomplished by performing a cruise test on the vehicle with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak – (Like tennis shoes on a clean floor)
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces = higher pitch noise/softer surfaces = lower pitch noises/edge to surface = chirping
- Creak – (Like walking on an old wooden floor)
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle – (Like shaking a baby rattle)
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock – (Like a knock on a door)
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick – (Like a clock second hand)
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump – (Heavy, muffled knock noise)
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz – (Like a bumblebee)
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending up on the person. A noise that a technician may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

DUPLICATE THE NOISE AND TEST DRIVE

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when the repair is reconfirmed.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
 - 2) Tap or push/pull around the area where the noise appears to be coming from.
 - 3) Rev the engine.
 - 4) Use a floor jack to recreate vehicle "twist".
 - 5) At idle, apply engine load (electrical load, half-clutch on M/T models, drive position on A/T models).
 - 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.
- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
 - If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

CHECK RELATED SERVICE BULLETINS

After verifying the customer concern or symptom, check ASIST for Technical Service Bulletins (TSBs) related to that concern or symptom.

If a TSB relates to the symptom, follow the procedure to repair the noise.

LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Chassis ear: J-39570, Engine ear and mechanics stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
 - Removing the components in the area that is are suspected to be the cause of the noise.
Do not use too much force when removing clips and fasteners, otherwise clips and fastener can be broken or lost during the repair, resulting in the creation of new noise.
 - Tapping or pushing/pulling the component that is are suspected to be the cause of the noise.
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
 - Feeling for a vibration by hand by touching the component(s) that is are suspected to be the cause of the noise.
 - Placing a piece of paper between components that are suspected to be the cause of the noise.
 - Looking for loose components and contact marks.
Refer to [SE-105, "Inspection Procedure"](#).

REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
 - Separate components by repositioning or loosening and retightening the component, if possible.
 - Insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. A Nissan Squeak and Rattle Kit (J-43980) is available through the authorized Nissan Parts Department.

CAUTION:

Never use excessive force as many components are constructed of plastic and may be damaged.

NOTE:

Always check with the Parts Department for the latest parts information.

The following materials are contained in the Nissan Squeak and Rattle Kit (J-43980). Each item can be ordered separately as needed.

URETHANE PADS [1.5 mm (0.059 in) thick]

Insulates connectors, harness, etc.

76268-9E005: 100 × 135 mm (3.94 × 5.31 in)/76884-71L01: 60 × 85 mm (2.36 × 3.35 in)/76884-71L02: 15 × 25 mm (0.59 × 0.98 in)

INSULATOR (Foam blocks)

Insulates components from contact. Can be used to fill space behind a panel.

73982-9E000: 45 mm (1.77 in) thick, 50 × 50 mm (1.97 × 1.97 in)/73982-

50Y00: 10 mm (0.39 in) thick, 50 × 50 mm (1.97 × 1.97 in)

INSULATOR (Light foam block)

80845-71L00: 30 mm (1.18 in) thick, 30 × 50 mm (1.18 × 1.97in)

FELT CLOTHTAPE

Used to insulate where movement does not occur. Ideal for instrument panel applications.

68370-4B000: 15 × 25 mm (0.59 × 0.98 in) pad/68239-13E00: 5 mm (0.20 in) wide tape roll

The following materials, not found in the kit, can also be used to repair squeaks and rattles.

UHMW (TEFLON) TAPE

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

Insulates where slight movement is present. Ideal for instrument panel applications.

SILICONE GREASE

Used in place of UHMW tape that is be visible or does not fit. Will only last a few months.

SILICONE SPRAY

Used when grease cannot be applied.

DUCT TAPE

Used to eliminate movement.

CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

Inspection Procedure

INFOID:000000004684736

Refer to Table of Contents for specific component removal and installation information.

INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

1. The cluster lid A and instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar garnish
4. Instrument panel to windshield
5. Instrument panel mounting pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicon spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

CAUTION:

Never use silicone spray to isolate a squeak or rattle. If the area is saturated with silicone, the recheck of repair becomes impossible.

CENTER CONSOLE

Components to pay attention to include:

1. Shifter assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

DOORS

Pay attention to the following:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. The areas can usually be insulated with felt cloth tape or insulator foam blocks from the Nissan Squeak and Rattle Kit (J-43980) to repair the noise.

TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the customer.

In addition look for the following:

1. Trunk lid dumpers out of adjustment
2. Trunk lid striker out of adjustment
3. The trunk lid torsion bars knocking together
4. A loose license plate or bracket

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

SUNROOF/HEADLINING

Noises in the sunroof/headlining area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sunvisor shaft shaking in the holder
3. Front or rear windshield touching headlining and squeaking

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

SEATS

When isolating seat noise it's important to note the position the seats in and the load placed on the seat when the noise occurs. These conditions should be duplicated when verifying and isolating the cause of the noise.

Cause of seat noise include:

1. Headrest rods and holder
2. A squeak between the seat pad cushion and frame
3. The rear seatback lock and bracket

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

Causes of transmitted underhood noise include:

1. Any component mounted to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator mounting pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

These noises can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine RPM or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting, securing, or insulating the component causing the noise.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

Diagnostic Worksheet

INFOID:000000004240996







SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

Dear Infiniti Customer:

We are concerned about your satisfaction with your Infiniti vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your Infiniti right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service consultant or technician to ensure we confirm the noise you are hearing.

I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to page 2 of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

PIIB8741E

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET - page 2

Briefly describe the location where the noise occurs:

II. WHEN DOES IT OCCUR? (please check the boxes that apply)

- | | |
|---|--|
| <input type="checkbox"/> anytime | <input type="checkbox"/> after sitting out in the rain |
| <input type="checkbox"/> 1st time in the morning | <input type="checkbox"/> when it is raining or wet |
| <input type="checkbox"/> only when it is cold outside | <input type="checkbox"/> dry or dusty conditions |
| <input type="checkbox"/> only when it is hot outside | <input type="checkbox"/> other: |

III. WHEN DRIVING:

- through driveways
- over rough roads
- over speed bumps
- only about ____ mph
- on acceleration
- coming to a stop
- on turns: left, right or either (circle)
- with passengers or cargo
- other: _____
- after driving ____ miles or ____ minutes

IV. WHAT TYPE OF NOISE

- squeak (like tennis shoes on a clean floor)
- creak (like walking on an old wooden floor)
- rattle (like shaking a baby rattle)
- knock (like a knock at the door)
- tick (like a clock second hand)
- thump (heavy, muffled knock noise)
- buzz (like a bumble bee)

TO BE COMPLETED BY DEALERSHIP PERSONNEL

Test Drive Notes:

	YES	NO	Initials of person performing
Vehicle test driven with customer	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise verified on test drive	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise source located and repaired	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Follow up test drive performed to confirm repair	<input type="checkbox"/>	<input type="checkbox"/>	_____

VIN: _____ Customer Name: _____
W.O.# _____ Date: _____

This form must be attached to Work Order

PIIB8742E

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000004240997

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIR BAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Service Notice

INFOID:000000004240998

- When removing or installing various parts, place a cloth or padding onto the vehicle body to prevent scratches.
- Handle trim, molding, instruments, grille, etc. carefully during removing or installing. Be careful not to oil or damage them.
- Apply sealing compound where necessary when installing parts.
- When applying sealing compound, be careful that the sealing compound does not protrude from parts.
- When replacing any metal parts (for example body outer panel, members, etc.), be sure to take rust prevention measures.

Precaution for Work

INFOID:000000004240999

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and keep them.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After re-installation is completed, be sure to check that each part works normally.
- Follow the steps below to clean components.
 - Water soluble foul: Dip a soft cloth into lukewarm water, and wring the water out of the cloth to wipe the fouled area.
Then rub with a soft and dry cloth.

PRECAUTIONS

< PRECAUTION >

- Oily foul: Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%), and wipe the fouled area.
Then dip a cloth into fresh water, and wring the water out of the cloth to wipe the detergent off. Then rub with a soft and dry cloth.
- Never use organic solvent such as thinner, benzene, alcohol, and gasoline.
- For genuine leather seats, use a genuine leather seat cleaner.

PREPARATION

< PREPARATION >



PREPARATION

PREPARATION

Special Service Tool




INFOID:000000004684741

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
<p>(J39570) Chassis ear</p>  <p>SIIA0993E</p>	<p>Locates the noise</p>
<p>(J43980) NISSAN Squeak and Rattle Kit</p>  <p>SIIA0994E</p>	<p>Repairs the cause of noise</p>

Commercial Service Tool

INFOID:000000004684742

Tool name	Description
<p>Engine ear</p>  <p>SIIA0995E</p>	<p>Locates the noise</p>
<p>Remover tool</p>  <p>JMKIA3050ZZ</p>	<p>Removes the clips, pawls and metal clips</p>
<p>Hook and pick tool</p>  <p>JMJA0490ZZ</p>	<p>Removes the snap pins</p>

FRONT SEAT

< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION


FRONT SEAT

Exploded View

INFOID:000000004241002

DRIVER'S SEAT

SEC. 870



JMJIA1237GB

FRONT SEAT

< REMOVAL AND INSTALLATION >

1. Headrest	2. Front outer slide cover	3. Front inner slide cover	A
4. Rear outer slide cover	5. Rear inner slide cover	6. Seatback board	
7. Headrest holder (free)	8. Headrest holder (locked)	9. Seat cushion outer finisher	
10. Seat slide and lifter switch knob	11. Seat reclining switch knob	12. Lumbar support switch	B
13. Seat control switch	14. Side support switch	15. Seat cushion inner finisher	
16. Side air bag module	17. Snap ring	18. Lumbar support lever knob	
19. Seatback trim	20. Seatback pad	21. Seatback silencer	C
22. Seatback side support bag and unit	23. Lumbar support unit	24. Lumbar support motor	
25. Seatback frame	26. Reclining device outer cover (front)	27. Reclining device outer cover (rear)	
28. Reclining device inner cover (front)	29. Reclining device inner cover (rear)	30. Seat cushion front finisher	D
31. Thigh extension pad	32. Seat cushion trim	33. Seat cushion pad	
34. Seat cushion side support bag	35. Seat slide outer finisher (outside)	36. Seat slide outer finisher (inside)	
37. Seat slide inner finisher	38. Seat control unit	39. Seat harness	E
40. Seat cushion frame			

Refer to [GI-4. "Components"](#) for symbols in the figure.

PASSENGER'S SEAT

F

G

H

I

SE

K

L

M

N


O

P

FRONT SEAT

< REMOVAL AND INSTALLATION >

SEC. 870



JMJIA1238GB

- | | | |
|---------------------------------------|--------------------------------|--------------------------------|
| 1. Headrest | 2. Front outer slide cover | 3. Front inner slide cover |
| 4. Rear outer slide cover | 5. Rear inner slide cover | 6. Seatback board |
| 7. Headrest holder (free) | 8. Headrest holder (locked) | 9. Seat cushion outer finisher |
| 10. Seat slide and lifter switch knob | 11. Seat reclining switch knob | 12. Seat control switch |
| 13. Seat cushion inner finisher | 14. Side air bag module | 15. Seatback trim |
| 16. Seatback pad | 17. Seatback silencer | 18. Seatback frame |

FRONT SEAT

< REMOVAL AND INSTALLATION >

- | | | |
|--|---|--|
| 19. Reclining device outer cover (front) | 20. Reclining device outer cover (rear) | 21. Reclining device inner cover (front) |
| 22. Reclining device inner cover (rear) | 23. Seat cushion front finisher | 24. Thigh extension pad |
| 25. Seat slide outer finisher (outside) | 26. Seat slide outer finisher (inside) | 27. Seat slide inner finisher |
| 28. Seat cushion assembly | | |

Refer to [GI-4. "Components"](#) for symbols in the figure.

Removal and Installation


INFOID:000000004241003


REMOVAL

CAUTION:


When removing and installing, use shop cloths to protect parts from damage.


1. Remove the headrest.
2. Remove the front slide cover.
 - a. Front outer slide cover
 - Slide the seat to the rearmost position.
 - Pull up the front edge of the front slide cover to release the pawls.
 - Slide the front slide cover forward to release the pawls.

 : Pawl





- b. Front inner slide cover
 - Slide the seat to the rearmost position.
 - Pull up the front edge of the front slide cover to release the pawls.
 - Slide the front slide cover forward to release the pawls.

 : Pawl



3. Remove the mounting bolts on the front side of the front seat.
4. Remove the rear slide cover.
 - a. Rear outer slide cover
 - Slide the seat to the foremost position.
 - Pull up the rear edge of the rear outer slide cover to release the pawls.
 - Open the front end of the rear outer slide cover to release the pawls.

 : Pawl





A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

FRONT SEAT

< REMOVAL AND INSTALLATION >

- b. Rear inner slide cover
- Slide the seat to the foremost position.
 - Pull up the rear edge of the rear inner slide cover to release the pawls.
 - Slide the rear inner slide cover rearward to release the pawls.

 : Pawl



5. Remove the mounting bolts on the rear side of the front seat.
6. Set seatback in a standing position.
7. Disconnect harness connector under the seat and remove harness securing clips.

CAUTION:

Before removal, turn ignition switch OFF, disconnect battery negative terminal and then wait for at least 3 minutes.

8. Remove seat from the vehicle.

CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

- **Before installation, turn ignition switch OFF, disconnect battery negative terminal and then wait for at least 3 minutes.**
- **Clamp the harness in position.**

NOTE:

After installing the driver seat, perform additional service when removing battery negative terminal. (Automatic drive positioner model only) Refer to [ADP-9, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement"](#).


Disassembly and Assembly

INFOID:000000004241004

SEATBACK

Disassembly




1. Remove the seat cushion outer finisher.
- Remove the seat slide and lifter switch knob (1) and seat reclining switch knob (2). Using a remover tool (A).




FRONT SEAT


< REMOVAL AND INSTALLATION >

- Remove the metal clips, clips and pawls, and then pull out seat cushion outer finisher.

-  : Clip
-  : Metal clip
-  : Pawl




- Disconnect the seat control switch, lumbar support switch and side support switch harness connectors.




- Remove the reclining device outer cover (front, rear).

2. Remove the seat cushion inner finisher.




- Remove the reclining device inner covers (front, rear) by releasing the metal clip and pull it up together with the cover.
- Remove the reclining device inner covers (front, rear) from the seat cushion inner finisher by releasing the pawls.


-  : Metal clip



3. Remove the back board.

- Remove the metal clips and clips, and then pull out seatback board (1).
- Pull down the seatback board to release the upper pawls.

-  : Clip
-  : Metal clip
-  : Pawl




- Remove the lumbar support lever knob. (Manual lumbar support model only.)

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P


FRONT SEAT

< REMOVAL AND INSTALLATION >


Pull snap ring (1) upward, and remove lumbar support lever knob (2) from seatback frame with hook and pick tool.




5. Remove the seatback pad and trim.
- Remove the seatback retainer (1) on the back side of the seatback.



- Remove the headrest holder.
- CAUTION:**
Before installing headrest holder check its orientation.
(front/rear and right/left)



- Remove the side air bag module.
- Remove the side support hose joint (1) located under the seat cushion. (Side support model only.)




- Disconnect the seatback heater unit harness connector.

FRONT SEAT


< REMOVAL AND INSTALLATION >


- Disconnect the reclining motor harness connector (1) and remove the harness clamp.
- Disconnect the lumbar support motor harness connector (2) and remove the harness clamp. (Power lumbar support model only.)
- Disconnect the side support unit harness connector (3) and remove the harness clamp. (Side support model only.)




- Remove the seatback pad and seatback trim from the seatback frame.
- Remove the hog rings, and separate the trim and pad.

6. Remove the seatback silencer.
7. Remove the lumbar support motor. (Power lumbar support model only.)
 - Remove the bolts, and then remove lumbar support unit.
 - Remove the screws, and then remove lumbar support motor.
8. Remove the side support bag and unit. (Side support model only.)
 - Remove the pawls, and then remove side support bag (1).
 - Remove the side support unit.

 : Pawl



9. Remove the seatback frame.
Remove the seatback frame mounting bolts (A).



Assembly

Assemble in the reverse order of disassembly.

CAUTION:

Install the hog rings of seatback trim in position, and then securely connect the trim or trim cord with the pad side wire.

SEAT CUSHION

Disassembly

CAUTION:


- **Never disassemble front passenger seat cushion assembly.**
- **Always replace as an assembly.**
- **For front passenger seat service parts, refer to the service part catalogue.**

1. Remove the seat cushion outer finisher.

FRONT SEAT


< REMOVAL AND INSTALLATION >

- Remove the seat slide and lifter switch knob (1) and seat reclining switch knob (2). Using a remover tool (A).




- Remove the metal clips, clips and pawls, and then pull out seat cushion outer finisher.

- : Clip
- : Metal clip
- △ : Pawl



- Disconnect the seat control switch, lumbar support switch and side support switch harness connectors.




- Remove the reclining device outer cover (front, rear).

2. Remove the seat cushion inner finisher.

- Remove the reclining device inner covers (front, rear) by releasing the metal clip and pull it up together with the cover.
- Remove the reclining device inner covers (front, rear) from the seat cushion inner finisher by releasing the pawls.

- : Metal clip






3. Remove the seat cushion front finisher.

FRONT SEAT

< REMOVAL AND INSTALLATION >




Remove the metal clips, and then pull out seat cushion front finisher (1).


-  : Metal clip
-  : Pawl



4. Remove the seatback board.


- Remove the metal clips and clips, and then pull out seatback board (1).
- Pull down the seatback board to release the upper pawls.

-  : Clip
-  : Metal clip
-  : Pawl




5. Remove the seatback assembly.

- Disconnect the reclining motor harness connector (1) and remove the harness clamp.
- Disconnect the lumbar support motor harness connector (2) and remove the harness clamp. (Power lumbar support model only.)
- Disconnect the side support unit harness connector (3) and remove the harness clamp. (Side support model only.)



- Remove the seat cushion retainer, and then side air bag harness clamp and seatback heater unit harness connector.
- Remove the side support hose joint (1) located under the seat cushion. (Side support model only.)




A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P


FRONT SEAT

< REMOVAL AND INSTALLATION >


- Remove the seatback mounting bolts (A), and then remove the seatback assembly.




6. Remove the thigh extension. (Thigh extension model only.)
- Remove the retainer.



- Remove the thigh extension pad.
- Remove the mounting screws (A).
- Remove the seat cushion trim wire (1) from the hooks (2).
- Remove the thigh extension frame by sliding it.



7. Remove the seat cushion pad and trim.
- Remove the clips (A). (Thigh extension model only.)





- Remove the retainer.
 - Disconnect the seat cushion heater unit harness connector.
 - Remove the hog rings, and separate the trim and pad.
8. Remove the side support bag. (Side support model only.)
- Remove the hose clamp.

FRONT SEAT


< REMOVAL AND INSTALLATION >


- Remove the pawls, and then remove side support bag (1).

 : Pawl




9. Remove the seat slide outer finisher.
- Remove the metal clips and pawls, and then pull out seat slide outer finisher (outside).
 - Remove the metal clip, and then pull out seat slide outer finisher (inside).

 : Metal clip



10. Remove the seat slide inner finisher.
Remove the metal clip, and then pull out seat slide inner finisher.

 : Metal clip



Assembly

Assemble in the reverse order of disassembly.

CAUTION:

Install the hog rings of seat cushion trim in position, and then securely connect the trim or trim cord with the pad side wire.

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

REAR SEAT


< REMOVAL AND INSTALLATION >

REAR SEAT

Exploded View

INFOID:000000004241005


REAR SEAT



- 1. Seat cushion pad
- 2. Seat cushion trim
- 3. Seat cushion hook
- 4. Seatback pad
- 5. Seatback trim
- 6. Armrest assembly

Refer to [GI-4. "Components"](#) for symbols in the figure.

ARMREST



REAR SEAT

< REMOVAL AND INSTALLATION >

- | | | |
|--------------------------------|-------------------------|-------------------------|
| 1. Cup holder | 2. Armrest side console | 3. Armrest bracket |
| 4. Armrest bracket outer cover | 5. bushing | 6. Armrest trim and pad |

Refer to [GI-4, "Components"](#) for symbols in the figure.

Removal and Installation


INFOID:000000004241006

REMOVAL

CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

1. Remove the seat cushion.
 - Pull the lock lever (1) at the front bottom of the seat cushion forward (1 for each side), and pull the seat cushion upward to release the wire (2) from the seat cushion hook. Then pull the seat cushion forward to remove.
 - Remove the seat cushion from the vehicle.



2. Remove the seatback.
 - Remove the nuts under seatback.
 - Lift up seatback from underneath, and then remove seatback from seatback hook that is fixed to the vehicle.
 - Remove the seatback from the vehicle.
3. Remove the armrest assembly.
 - Remove the fastener.
 - Remove the armrest mounting bolts.
 - Remove the clip.
 - Remove the armrest assembly from the vehicle.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

Disassembly and Assembly

INFOID:000000004241007

SEATBACK

Disassembly

Remove the hog rings, and separate the trim and pad.

Assembly

Assemble in the reverse order of disassembly.

SEAT CUSHION

Disassembly

Remove the hog rings, and separate the trim and pad.

Assembly

Assemble in the reverse order of disassembly.

ARMREST

Disassembly

1. Remove the screws, and then remove the cup holder.
2. Remove the screws, and then remove the armrest side console

REAR SEAT

< REMOVAL AND INSTALLATION >

3. Remove the bolts, and then remove the armrest bracket.
4. Remove the armrest bracket outer cover from armrest bracket.

Assembly

Assemble in the reverse order of disassembly.

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< REMOVAL AND INSTALLATION >


AUTOMATIC DRIVE POSITIONER CONTROL UNIT

Removal and Installation

INFOID:000000004241008

REMOVAL

1. Remove the instrument driver lower panel. Refer to [IP-12](#), "[Removal and Installation](#)".
2. Remove the screws (A).
3. Remove automatic drive positioner control unit (1).



INSTALLATION

Install in the reverse order of removal.

CAUTION:

- Be sure to clamp the harness to the right place.

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

HEATED SEAT CONTROL UNIT

< REMOVAL AND INSTALLATION >

HEATED SEAT CONTROL UNIT

Exploded View

INFOID:000000004535509

Refer to [SE-112, "Exploded View"](#).

Removal and Installation

INFOID:000000004535510

REMOVAL

CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

1. Remove the front seat.
2. Disconnect heated seat control unit connector.
3. Remove the heated seat control unit from the heated seat control unit stay. Refer to [SE-112, "Exploded View"](#).

INSTALLATION

Install in the reverse order of removal.

CAUTION:

Always clamp the harness to the right place.

POWER SEAT SWITCH

< REMOVAL AND INSTALLATION >

POWER SEAT SWITCH

Removal and Installation


INFOID:000000004241010

REMOVAL

CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

1. Remove the seat cushion outer finisher (1). Refer to [SE-115](#), "[Removal and Installation](#)".
2. Remove the screws (A).
3. Remove the power seat switch (2) from the seat cushion outer finisher (1).



INSTALLATION

Install in the reverse order of removal.

CAUTION:

- Be sure to clamp the harness to the right place.

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

SE

SIDE SUPPORT SWITCH

< REMOVAL AND INSTALLATION >

SIDE SUPPORT SWITCH

Removal and Installation


INFOID:000000004241011

REMOVAL

CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

1. Remove the seat cushion outer finisher (1). Refer to [SE-115. "Removal and Installation"](#).
2. Remove the screws (A).
3. Remove side support switch (2) from the seat cushion outer finisher.



INSTALLATION

Install in the reverse order of removal.

CAUTION:

- Be sure to clamp the harness to the right place.

LUMBAR SUPPORT SWITCH

< REMOVAL AND INSTALLATION >

LUMBAR SUPPORT SWITCH

Removal and Installation


INFOID:000000004241012

REMOVAL

CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

1. Remove the seat cushion outer finisher (1). Refer to [SE-115](#).
["Removal and Installation"](#)
2. Remove lumbar support switch (2).



INSTALLATION

Install in the reverse order of removal.

CAUTION:

- Be sure to clamp the harness to the right place.

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

SE

TILT&TELESCOPIC SWITCH

< REMOVAL AND INSTALLATION >

TILT&TELESCOPIC SWITCH

Removal and Installation

INFOID:000000004241013


REMOVAL

CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

1. Disconnect battery negative terminal.
2. Remove the steering column mask (1). Refer to [IP-12. "Removal and Installation"](#).
3. Press pawls and remove tilt & telescopic switch (2) from the steering column mask (1).

 Pawl



INSTALLATION

Install in the reverse order of removal.

CAUTION:

- **Be sure to clamp the harness to the right place.**

HEATED SEAT SWITCH

< REMOVAL AND INSTALLATION >

HEATED SEAT SWITCH

Exploded View

INFOID:000000004679111

Refer to [JP-23. "Exploded View"](#).

Removal and Installation


INFOID:000000004679112

REMOVAL

CAUTION:


When removing and installing, use shop cloths to protect from damage.

1. Remove the console body assembly. Refer to [JP-24. "Removal and Installation"](#)
2. Remove heated seat switch (1) from switch bracket (2) with flat-bladed screwdriver (A).

 : Pawl

NOTE:

The same procedure is performed for passenger side.



INSTALLATION

Install in the reverse order of removal.

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

SE