

SECTION **INL**

INTERIOR LIGHTING SYSTEM

A
B
C
D
E

F
G
H
I
J
K
L
M
N
O
P

INL

CONTENTS

BASIC INSPECTION	3	POWER SUPPLY AND GROUND CIRCUIT	19
DIAGNOSIS AND REPAIR WORKFLOW	3	BCM	19
Work Flow	3	BCM : Diagnosis Procedure	19
SYSTEM DESCRIPTION	5	INTERIOR ROOM LAMP POWER SUPPLY CIRCUIT	20
INTERIOR ROOM LAMP CONTROL SYSTEM	5	Description	20
System Diagram	5	Component Function Check	20
System Description	5	Diagnosis Procedure	20
Component Parts Location	7	INTERIOR ROOM LAMP CONTROL CIRCUIT	22
Component Description	8	Description	22
INTERIOR ROOM LAMP BATTERY SAVER SYSTEM	9	Component Function Check	22
System Diagram	9	Diagnosis Procedure	22
System Description	9	STEP LAMP CIRCUIT	24
Component Parts Location	10	Description	24
Component Description	10	Component Function Check	24
ILLUMINATION CONTROL SYSTEM	12	Diagnosis Procedure	24
System Diagram	12	TRUNK ROOM LAMP CIRCUIT	26
System Description	12	Description	26
Component Parts Location	13	Component Function Check	26
Component Description	13	Diagnosis Procedure	26
DIAGNOSIS SYSTEM (BCM)	14	PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT	28
COMMON ITEM	14	Description	28
COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM)	14	Component Function Check	28
INT LAMP	15	Diagnosis Procedure	28
INT LAMP : CONSULT-III Function (BCM - INT LAMP)	16	INTERIOR ROOM LAMP CONTROL SYSTEM	30
BATTERY SAVER	17	Wiring Diagram - INTERIOR ROOM LAMP -	30
BATTERY SAVER : CONSULT-III Function (BCM - BATTERY SAVER)	17	ILLUMINATION	41
DTC/CIRCUIT DIAGNOSIS	19	Wiring Diagram - ILLUMINATION -	41

BCM (BODY CONTROL MODULE)	54	Exploded View	110
Reference Value	54	Replacement	110
Wiring Diagram - BCM -	78		
Fail-safe	84		
DTC Inspection Priority Chart	86		
DTC Index	87		
COMBINATION METER	90		
Reference Value	90	Exploded View	112
Wiring Diagram - METER -	93	Replacement	112
Fail-safe	105		
DTC Index	106		
SYMPTOM DIAGNOSIS	107		
INTERIOR LIGHTING SYSTEM SYMPTOMS.	107		
Symptom Table	107	Exploded View	113
PRECAUTION	108	Removal and Installation	113
PRECAUTIONS	108	Replacement	113
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER"	108		
REMOVAL AND INSTALLATION	109		
MAP LAMP	109	TRUNK ROOM LAMP	116
Exploded View	109	Exploded View	116
Removal and Installation	109	Removal and Installation	116
Replacement	109	Replacement	116
VANITY MIRROR LAMP	110		
CIGARETTE LIGHTER ILLUMINATION	111		
Exploded View	111		
Replacement	111		
GLOVE BOX LAMP	112		
Exploded View	112		
Replacement	112		
STEP LAMP	113		
Exploded View	113		
Removal and Installation	113		
Replacement	113		
PERSONAL LAMP	114		
Exploded View	114		
Removal and Installation	114		
Replacement	115		
SERVICE DATA AND SPECIFICATIONS (SDS)	117		
SERVICE DATA AND SPECIFICATIONS (SDS)	117		
Bulb Specifications	117		

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000006205831

OVERALL SEQUENCE



JPLIA0313GB

DETAILED FLOW

1. INTERVIEW FOR MALFUNCTION

Interview the symptom to the customer.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

>> GO TO 2.

2. SYMPTOM CHECK

Check the symptom from the customer's information.

>> GO TO 3.

3. BASIC INSPECTION

Check the operation of each part. Check that any symptom occurs other than the interviewed symptom.

>> GO TO 4.

4. SELF-DIAGNOSIS WITH CONSULT-III

Perform the self-diagnosis with CONSULT-III. Check that any DTC is detected.

Is any DTC detected?

YES >> GO TO 5.

NO >> GO TO 6.

5. TROUBLE DIAGNOSIS BY DTC

Perform the trouble diagnosis for the detected DTC. Specify the malfunctioning part.

>> GO TO 9.

6. FAIL-SAFE ACTIVATION CHECK

Check that the symptom is applied to the fail-safe activation.

Does the fail-safe activate?

YES >> GO TO 7.

NO >> GO TO 8.

7. SYSTEM DIAGNOSIS

Perform the system diagnosis for the system that the fail-safe activates. Specify the malfunctioning part.

>> GO TO 9.

8. SYMPTOM DIAGNOSIS

Perform the symptom diagnosis. Specify the malfunctioning part.

>> GO TO 9.

9. MALFUNCTION PART REPAIR

Repair or replace the malfunctioning part.

>> GO TO 10.

10. REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT-III)

Perform the self-diagnosis with CONSULT-III. Check that any DTC is not detected. Erase DTC if DTC is detected before the repair. Check that DTC is not detected again.

Is any DTC detected?

YES >> GO TO 5.

NO >> GO TO 11.

11. REPAIR CHECK (OPERATION CHECK)

Check the operation of each part.

Does it operate normally?

YES >> INSPECTION END

NO >> GO TO 3.


INTERIOR ROOM LAMP CONTROL SYSTEM

< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

INTERIOR ROOM LAMP CONTROL SYSTEM

System Diagram



System Description

INFOID:000000006205833


OUTLINE

- Interior room lamps* are controlled by interior room lamp timer control function of BCM.
*: Map lamp and personal lamp (when map lamp switch is in DOOR position).
- Trunk room lamp is controlled by trunk room lamp control function of BCM.
- Step lamp is controlled by step lamp control function of BCM.
- Push-button ignition switch illumination is controlled by the push-button ignition switch illumination control function of BCM.

INL

INTERIOR ROOM LAMP TIMER CONTROL

Interior Room Lamp Timer Basic Operation



INTERIOR ROOM LAMP CONTROL SYSTEM

< SYSTEM DESCRIPTION >

- The interior room lamp turns ON and OFF (gradual brightening and dimming) by the interior room timer.
- BCM judges the vehicle condition with the following items. It activates the interior room timer.
 - Ignition switch status
 - Door switch signal (ALL)
 - Door lock/unlock signal (Remote keyless entry receiver, each request switch, key cylinder lock/unlock switch, door lock/unlock switch)

NOTE:

Each function of interior room lamp timer can be set by CONSULT-III. Refer to [INL-16, "INT LAMP : CONSULT-III Function \(BCM - INT LAMP\)"](#).

Interior Room Lamp ON Operation

- BCM always turns the interior room lamp ON when any door opens.
- BCM activates the interior room lamp timer in any of the following conditions to turn the interior room lamp ON for a period of time.
 - Any door opens before all doors close.
 - Ignition switch is turned ON → OFF.
 - Any door unlock signal is detected when all doors close with ignition switch OFF.

NOTE:

Restart the timer if new condition is input during the timer operating time.

Interior Room Lamp OFF Operation

BCM stops the timer in any of the following conditions to turns the interior room lamp OFF.

- The timer operating time is expired.
- Ignition switch position is other than OFF with all doors close.
- Any door lock operation is detected with all doors close.

TRUNK ROOM LAMP CONTROL

BCM controls the trunk room lamp (ground-side) to turn ON with the trunk room lamp switch ON.

STEP LAMP CONTROL

BCM controls the step lamp (ground-side) to turn ON with any door switch ON.

PUSH-BUTTON IGNITION SWITCH ILLUMINATION CONTROL

Push-button Ignition Switch Illumination Basic Operation

- BCM provides the power supply and the ground to turn the push-button ignition switch illumination ON.
- BCM cuts the ground supply while the each illumination (tail lamp) ON. BCM switches to the ground control with the meter illumination control function.

Push-button Ignition Switch Illumination ON Operation

BCM turns the push-button ignition switch illumination ON in the following conditions.

- Ignition switch ON
- Each illumination (tail lamp) ON
- Any of the following conditions with ignition switch OFF
 - Engine start permission is entered.
 - Intelligent Key inserted into the key slot.
 - Driver door is LOCK → UNLOCK.
 - Driver door is open.

Push-button Ignition Switch Illumination OFF Operation

BCM turns the push-button ignition switch illumination OFF in any of the following conditions.


- The push-button ignition switch illumination ON conditions do not satisfy.
- All of the following conditions with ignition switch OFF.
 - Each illumination (tail lamp) OFF
- The push-button ignition switch illumination ON conditions do not change (15 seconds after the ignition switch OFF) or the driver door is UNLOCK → LOCK

INTERIOR ROOM LAMP CONTROL SYSTEM

< SYSTEM DESCRIPTION >

Component Parts Location

INFOID:000000006205834



- | | | |
|----------------------------|-------------------------------------|----------------------------|
| 1. Key cylinder switch | 2. Request switch | 3. Step lamp |
| 4. Door switch | 5. Personal lamp | 6. Door lock/unlock switch |
| 7. Map lamp | 8. Remote keyless entry receiver | 9. BCM |
| 10. Trunk room lamp switch | 11. Trunk room lamp | C. Trunk lid lock assembly |
| A. Behind the glove box | B. Dash side lower (passenger side) | |
| D. Trunk room upward | | |

A
B
C
D
E
F
G
H
I
J
K
L
INL
M
N
O
P

INTERIOR ROOM LAMP CONTROL SYSTEM

< SYSTEM DESCRIPTION >

Component Description

INFOID:000000006205835

Part	Description
BCM	<ul style="list-style-type: none">Activates the interior room lamp timer depending on the vehicle condition to turn the interior room lamp ON/OFF.Turns the trunk room lamp ON /OFF according to the trunk room lamp switch status.Turns the step lamp ON /OFF according to any door switch status.
Remote keyless entry receiver	Transmits the lock/unlock signal to BCM.
• Door lock/unlock switch • Key cylinder lock/unlock switch	Transmits a switch signal by power window switch serial link.
• Request switch • Door switch • Trunk room lamp switch	Inputs a switch signal to BCM.


INTERIOR ROOM LAMP BATTERY SAVER SYSTEM

< SYSTEM DESCRIPTION >

INTERIOR ROOM LAMP BATTERY SAVER SYSTEM

System Diagram

INFOID:0000000006205836



JPLIA0091GB

System Description

INFOID:0000000006205837

OUTLINE

- Interior room lamp battery saver is controlled by BCM.
- BCM turns applicable lamps OFF depending on the vehicle condition. This function prevents the battery from over-discharging if the driver neglect turning OFF the any lamps.

Applicable lamps

- Map lamp
- Personal lamp
- Step lamp
- Trunk room lamp
- Vanity mirror lamp

INL

INTERIOR ROOM LAMP BATTERY SAVER FUNCTION

- When the ignition switch is turned OFF, BCM operates the timer for a period of time to cut the interior room lamp power supply.
- BCM restart the timer when any of the following signals changes while operating the timer.
 - Ignition switch status
 - Door switch signal (ALL)
 - Door lock/unlock signal (Remote keyless entry receiver, each request switch, key cylinder lock/unlock switch, door lock/unlock switch)
 - Trunk loom lamp switch signal
 - Key switch signal (Key slot)
- BCM provides the interior room lamp power supply continuously when the ignition switch position is other than OFF.

M

N

O

P

NOTE:


Each function of interior room lamp battery saver can be set by CONSULT-III. Refer to [INL-17, "BATTERY SAVER : CONSULT-III Function \(BCM - BATTERY SAVER\)"](#).

INTERIOR ROOM LAMP BATTERY SAVER SYSTEM

< SYSTEM DESCRIPTION >

Component Parts Location

INFOID:0000000006205838



JPLIA0039ZZ

- | | | |
|-------------------------|-------------------------------------|----------------------------------|
| 1. Key cylinder switch | 2. Request switch | 3. Step lamp |
| 4. Door switch | 5. Personal lamp | 6. Door lock/unlock switch |
| 7. Vanity mirror lamp | 8. Map lamp | 9. Remote keyless entry receiver |
| 10. BCM | 11. Trunk room lamp switch | 12. Trunk room lamp |
| A. Behind the glove box | B. Dash side lower (passenger side) | C. Trunk lid lock assembly |
| D. Trunk room upward | | |

Component Description

INFOID:0000000006205839

Part	Description
BCM	Operates the interior room lamp battery saver depending on the vehicle condition to cut the interior room lamp power supply.
Remote keyless entry receiver	Transmits the lock/unlock signal to BCM.

INTERIOR ROOM LAMP BATTERY SAVER SYSTEM

< SYSTEM DESCRIPTION >

Part	Description
• Door lock/unlock switch • Key cylinder lock/unlock switch	Transmits a switch signal by power window switch serial link.
• Request switch • Door switch • Trunk room lamp switch	Inputs a switch signal to BCM.
Key slot	Inputs the key switch status to BCM.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P


ILLUMINATION CONTROL SYSTEM

< SYSTEM DESCRIPTION >

ILLUMINATION CONTROL SYSTEM

System Diagram

INFOID:0000000006205840



System Description

INFOID:0000000006205841

OUTLINE

Each illumination lamp is controlled by each function of BCM, IPDM E/R and combination meter.

Control by BCM

- Combination switch reading function
- Headlamp control function

Control by IPDM E/R

- Relay control function

Control by combination meter

- Meter illumination control function (Refer to [MWI-25, "METER ILLUMINATION CONTROL : System Diagram".](#))

ILLUMINATION CONTROL

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits position light request signal to IPDM E/R and combination meter (through the unified meter and A/C amp.) according to tail lamp ON condition.

Tail lamp ON condition


- Lighting switch 1ST
- Lighting switch 2ND
- Lighting switch AUTO, and the auto light function ON judgment (With auto light system)
- IPDM E/R turns the integrated tail lamp relay ON according to position light request signal. It provides the power supply to each illumination lamp.
- Combination meter enters in the nighttime mode according to position light request signal. Under the nighttime mode the combination meter controls the illuminance by controlling the each illumination lamp (ground side).

ILLUMINATION CONTROL SYSTEM

< SYSTEM DESCRIPTION >

Component Parts Location

INFOID:000000006205842



- | | | |
|------------------------------------|--------------------------------|-------------------------------|
| 1. Combination switch | 2. Illumination control switch | 3. Combination meter |
| 4. BCM | 5. IPDM E/R | 6. Unified meter and A/C amp. |
| A Dash side lower (passenger side) | B Engine room dash panel (RH) | C Behind the cluster lid C |

Component Description

INFOID:000000006205843

INL

M

N

O

P

Part	Description
BCM	<ul style="list-style-type: none"> Detects each switch condition by the combination switch reading function. Judges the illumination lamp ON/OFF status depending on the vehicle condition. And then it transmits position light request signal to IPDM E/R and combination meter [with CAN communication (through the unified meter and A/C amp.)].
IPDM E/R	Controls the integrated relay according to the request from BCM (with CAN communication).
Combination meter	<ul style="list-style-type: none"> Enters in nighttime mode according to the request from BCM (with CAN communication). Controls the each illumination in the nighttime mode. Refer to MWI-25, "METER ILLUMINATION CONTROL : System Diagram".
Combination switch (Lighting & turn signal switch)	Refer to BCS-7, "System Diagram" .

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM)

INFOID:000000006205844

APPLICATION ITEM

CONSULT-III performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
Work Support	Changes the setting for each system function.
Self Diagnostic Result	Displays the diagnosis results judged by BCM.
CAN Diag Support Monitor	Monitors the reception status of CAN communication viewed from BCM. Refer to CONSULT-III operation manual.
Data Monitor	The BCM input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from BCM.
Ecu Identification	The BCM part number is displayed.
Configuration	This function is not used even though it is displayed.

SYSTEM APPLICATION

BCM can perform the following functions for each system.

NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

x: Applicable item

System	Sub system selection item	Diagnosis mode		
		Work Support	Data Monitor	Active Test
Door lock	DOOR LOCK	x	x	x
Rear window defogger	REAR DEFOGGER		x	x
Warning chime	BUZZER		x	x
Interior room lamp timer	INT LAMP	x	x	x
Exterior lamp	HEAD LAMP	x	x	x
Wiper and washer	WIPER	x	x	x
Turn signal and hazard warning lamps	FLASHER	x	x	x
—	AIR CONDITIONER*			
• Intelligent Key system • Engine start system	INTELLIGENT KEY	x	x	x
Combination switch	COMB SW		x	
Body control system	BCM	x		
IVIS - NATS	IMMU		x	x
Interior room lamp battery saver	BATTERY SAVER	x	x	x
Trunk lid open	TRUNK		x	x
Vehicle security system	THEFT ALM	x	x	x
RAP system	RETAINED PWR		x	
Signal buffer system	SIGNAL BUFFER		x	x
TPMS	TPMS (AIR PRESSURE MONITOR)	x	x	x

NOTE:

*: This item is displayed, but is not used.

FREEZE FRAME DATA (FFD)

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays on CONSULT-III.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

CONSULT screen item	Indication/Unit	Description	
Vehicle Speed	km/h	Vehicle speed of the moment a particular DTC is detected	
Odo/Trip Meter	km	Total mileage (Odometer value) of the moment a particular DTC is detected	
Vehicle Condition	SLEEP>LOCK	Power position status of the moment a particular DTC is detected	A
	SLEEP>OFF		B
	LOCK>ACC		C
	ACC>ON		D
	RUN>ACC		E
	CRANK>RUN		F
	RUN>URGENT		G
	ACC>OFF		H
	OFF>LOCK		I
	OFF>ACC		J
	ON>CRANK		K
	OFF>SLEEP		L
	LOCK>SLEEP		M
	LOCK		N
	OFF		O
	ACC		P
	ON		INL
	ENGINE RUN		
	CRANKING		
IGN Counter	0 - 39	<p>The number of times that ignition switch is turned ON after DTC is detected</p> <ul style="list-style-type: none"> • The number is 0 when a malfunction is detected now. • The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. • The number is fixed to 39 until the self-diagnosis results are erased if it is over 39. 	

INT LAMP


DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

INT LAMP : CONSULT-III Function (BCM - INT LAMP)

INFOID:000000006205845

WORK SUPPORT



Service item	Setting item	Setting
SET I/L D-UNLCK INTCON	ON*	With the interior room lamp timer function
	OFF	Without the interior room lamp timer function
ROOM LAMP TIMER SET	MODE 2	7.5 sec.
	MODE 3*	15 sec.
	MODE 4	30 sec.
ROOM LAMP ON TIME SET	MODE 1	0.5 sec.
	MODE 2*	1 sec.
	MODE 3	2 sec.
	MODE 4	3 sec.
	MODE 5	0 sec.
ROOM LAMP OFF TIME SET	MODE 1	0.5 sec.
	MODE 2	1 sec.
	MODE 3	2 sec.
	MODE 4*	3 sec.
R LAMP TIMER LOGIC SET	MODE 1*	Interior room lamp timer activates with synchronizing all doors.
	MODE 2	Interior room lamp timer activates with synchronizing the driver door only.

*: Factory setting

DATA MONITOR

Monitor item [Unit]	Description
REQ SW-DR [On/Off]	The switch status input from request switch (driver side)
REQ SW-AS [On/Off]	The switch status input from request switch (passenger side)
PUSH SW [On/Off]	The switch status input from push-button ignition switch
ACC RLY-F/B [On/Off]	NOTE: The item is indicated, but not monitored.
KEY SW-SLOT [On/Off]	Key switch status input from key slot

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitor item [Unit]	Description
DOOR SW-DR [On/Off]	The switch status input from front door switch (driver side)
DOOR SW-AS [On/Off]	The switch status input from front door switch (passenger side)
DOOR SW-RR [On/Off]	The switch status input from rear door switch RH
DOOR SW- RL [On/Off]	The switch status input from rear door switch LH
DOOR SW-BK [On/Off]	NOTE: The item is indicated, but not monitored.
CDL LOCK SW [On/Off]	Lock switch status received from door lock/unlock switch by power window switch serial link
CDL UNLOCK SW [On/Off]	Unlock switch status received from door lock/unlock switch by power window switch serial link
KEY CYL LK-SW [On/Off]	Lock switch status received from key cylinder switch by power window switch serial link
KEY CYL UN-SW [On/Off]	Unlock switch status received from key cylinder switch by power window switch serial link
TRNK/HAT MNTR [On/Off]	The switch status input from trunk room lamp switch
RKE-LOCK [On/Off]	Lock signal status received from remote keyless entry receiver
RKE-UNLOCK [On/Off]	Unlock signal status received from remote keyless entry receiver

ACTIVE TEST

Test item	Operation	Description
INT LAMP	On	Outputs the interior room lamp control signal to turn map lamp and personal lamp ON (Map lamp switch is in DOOR position).
	Off	Stops the interior room lamp control signal to turn map lamp and personal lamp OFF.
STEP LAMP TEST	On	Outputs the step lamp control signal to turn step lamp ON.
	Off	Stops the step lamp control signal to turn step lamp OFF.
LUGGAGE LAMP TEST	On	Outputs the trunk room lamp control signal to turn trunk room lamp ON.
	Off	Stops the trunk room lamp control signal to turn trunk room lamp OFF.

BATTERY SAVER

BATTERY SAVER : CONSULT-III Function (BCM - BATTERY SAVER)

INFOID:0000000006205846

WORK SUPPORT

Service item	Setting item	Setting	
BATTERY SAVER SET	On*	With the exterior lamp battery saver function	
	Off	Without the exterior lamp battery saver function	
ROOM LAMP BAT SAV SET	On*	With the interior room lamp battery saver function	
	Off	Without the interior room lamp battery saver function	
ROOM LAMP TIMER SET	MODE 1	30 min.	Sets the interior room lamp battery saver timer operating time.
	MODE 2	60 min.	
	MODE 3*	15 min.	

*: Factory setting

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

DATA MONITOR

Monitor item [Unit]	Description
REQ SW-DR [On/Off]	The switch status input from request switch (driver side)
REQ SW-AS [On/Off]	The switch status input from request switch (passenger side)
REQ SW-RR [On/Off]	NOTE: The item is indicated, but not monitored.
REQ SW-RL [On/Off]	
PUSH SW [On/Off]	The switch status input from push-button ignition switch
ACC RLY-F/B [On/Off]	NOTE: The item is indicated, but not monitored.
KEY SW-SLOT [On/Off]	Key switch status input from key slot
UNLK SEN-DR [On/Off]	Driver door unlock status input from unlock sensor
DOOR SW-DR [On/Off]	The switch status input from front door switch (driver side)
DOOR SW-AS [On/Off]	The switch status input from front door switch (passenger side)
DOOR SW-RR [On/Off]	The switch status input from rear door switch RH
DOOR SW- RL [On/Off]	The switch status input from rear door switch LH
DOOR SW-BK [On/Off]	NOTE: The item is indicated, but not monitored.
CDL LOCK SW [On/Off]	Lock switch status received from door lock/unlock switch by power window switch serial link
CDL UNLOCK SW [On/Off]	Unlock switch status received from door lock/unlock switch by power window switch serial link
KEY CYL LK-SW [On/Off]	Lock switch status received from key cylinder switch by power window switch serial link
KEY CYL UN-SW [On/Off]	Unlock switch status received from key cylinder switch by power window switch serial link
TRNK/HAT MNTR [On/Off]	The switch status input from trunk room lamp switch
RKE-LOCK [On/Off]	Lock signal status received from remote keyless entry receiver
RKE-UNLOCK [On/Off]	Unlock signal status received from remote keyless entry receiver

ACTIVE TEST

Test item	Operation	Description
BATTERY SAVER	Off	Cuts the interior room lamp power supply to turn interior room lamp OFF.
	On	Outputs the interior room lamp power supply to turn interior room lamp ON.*

*: Each lamp switch is in ON position.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT BCM

BCM : Diagnosis Procedure

INFOID:0000000006205847

1.CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

Signal name	Fuse and fusible link No.
Battery power supply	K
	10

Is the fuse fusing?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit if a fuse or fusible link is blown.

NO >> GO TO 2.

2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connectors.
3. Check voltage between BCM harness connector and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
BCM	Ground	
Connector	Terminal	
M118	1	
M119	11	Battery voltage

Is the measurement value normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3.CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

BCM		Continuity
Connector	Terminal	
M119	13	

Does continuity exist?

YES >> INSPECTION END

NO >> Repair harness or connector.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

INTERIOR ROOM LAMP POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

INTERIOR ROOM LAMP POWER SUPPLY CIRCUIT

Description

INFOID:0000000006205848

Provides the interior room lamp power supply. Also cuts the power supply when the interior room lamp battery saver activating.

Component Function Check

INFOID:0000000006205849

1. CHECK INTERIOR ROOM LAMP POWER SUPPLY FUNCTION

(CONSULT-III ACTIVE TEST

1. Turn the ignition switch ON.
2. Turn each interior room lamp ON.
 - Map lamp
 - Personal lamp
 - Step lamp
 - Vanity mirror lamp
 - Trunk room lamp
3. Select "BATTERY SAVER" of BCM (BATTERY SAVER) active test item.
4. With operating the test items, check that each interior room lamp turns ON/OFF.

Off : Interior room lamp OFF

On : Interior room lamp ON

Does the interior room lamp turn ON/OFF?

YES >> Interior room lamp power supply circuit is normal.

NO >> Refer to [INL-20, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000006205850

1. CHECK INTERIOR ROOM LAMP POWER SUPPLY OUTPUT

(CONSULT-III ACTIVE TEST

1. Turn the ignition switch ON.
2. Select "BATTERY SAVER" of BCM (BATTERY SAVER) active test item.
3. With operating the test item, check voltage between BCM harness connector and the ground.

Terminals		Test item	Voltage (Approx.)
(+)	(-)		
BCM		BATTERY SAVER	
Connector	Terminal		
M119	4		Off 0 V
			On Battery voltage

Is the measurement value normal?

YES >> GO TO 2.

NO >> Replace BCM.

2. CHECK INTERIOR ROOM LAMP POWER SUPPLY OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the following connectors.
 - Map lamp
 - Personal lamp
 - Vanity mirror lamp (LH)
 - Vanity mirror lamp (RH)
 - Trunk room lamp
 - Step lamp (driver side)
 - Step lamp (passenger side)

INTERIOR ROOM LAMP POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

3. Check continuity between BCM harness connector and each interior room lamp harness connector.

BCM		Each interior room lamp		Continuity
Connector	Terminal	Connector	Terminal	
M119	4	Map lamp	R15	1
		Personal lamp	R14	1
		Vanity mirror lamp (LH)	R12	2
		Vanity mirror lamp (RH)	R13	2
		Trunk room lamp	B47	1
		Step lamp (driver side)	D12	1
		Step lamp (passenger side)	D42	1

Does continuity exist?

YES >> GO TO 3.

NO >> Repair the harnesses or connectors.

3.CHECK INTERIOR ROOM LAMP POWER SUPPLY SHORT CIRCUIT

Check continuity between BCM harness connector and the ground.

BCM		Ground	Continuity
Connector	Terminal		
M119	4		Not existed

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Check that each interior room lamp has no internal short circuit.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

INTERIOR ROOM LAMP CONTROL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

INTERIOR ROOM LAMP CONTROL CIRCUIT

Description

INFOID:0000000006205851

Controls each interior room lamp (ground side) by PWM signal.

NOTE:

PWM signal control period is approximately 250 Hz (in the gradual brightening/dimming).

Component Function Check

INFOID:0000000006205852

CAUTION:

Before performing the diagnosis, check that the following is normal.

- Interior room lamp power supply
- Map lamp bulb
- Personal lamp bulb

1.CHECK INTERIOR ROOM LAMP CONTROL FUNCTION

(H)CONSULT-III ACTIVE TEST

1. Switch the map lamp switch to DOOR.
2. Turn the ignition switch ON.
3. Select "INT LAMP" of BCM (INT LAMP) active test item.
4. With operating the test items, check that each interior room lamp turns ON/OFF (gradual brightening/dimming).

On : Interior room lamp gradual brightening

Off : Interior room lamp gradual dimming

Does the interior room lamp turns ON/OFF (gradual brightening/dimming)?

YES >> Interior room lamp control circuit is normal.

NO >> Refer to [INL-22, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000006205853

1.CHECK INTERIOR ROOM LAMP CONTROL OUTPUT

(H)CONSULT-III ACTIVE TEST

1. Turn the ignition switch OFF.
2. Remove all the bulbs of map lamp and personal lamp.
3. Select "INT LAMP" of BCM (INT LAMP) active test item.
4. With operating the test item, check continuity between BCM harness connector and the ground.

BCM		Ground	Test item	Continuity
Connector	Terminal		INT LAMP	
M119	19		On	Existed
			Off	Not existed

Is the measurement value normal?

YES >> GO TO 2.

Fixed ON>>GO TO 3.

Fixed OFF>>Replace BCM.

2.CHECK INTERIOR ROOM LAMP CONTROL OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector, map lamp connector and personal lamp connector.
3. Check continuity between BCM harness connector, map lamp harness connector, and personal lamp harness connector.

INTERIOR ROOM LAMP CONTROL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

BCM		Map lamp/personal lamp			Continuity
Connector	Terminal	Connector	Terminal		
M119	19	Map lamp	R15	2	Existed
		Personal lamp	R14	3	

Does continuity exist?

YES >> Replace the map lamp or the personal lamp.

NO >> Repair the harnesses or connectors.

3.CHECK INTERIOR ROOM LAMP CONTROL SHORT CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector, map lamp connector and personal lamp connector.
3. Check continuity between BCM harness connector and the ground.

BCM		Ground	Continuity
Connector	Terminal		
M119	19		Not existed

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Replace BCM.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

STEP LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

STEP LAMP CIRCUIT

Description

INFOID:0000000006205854

Controls the step lamp (ground side) to turn the step lamp ON and OFF.

Component Function Check

INFOID:0000000006205855

CAUTION:

Before performing the diagnosis, check that the following is normal.

- Interior room lamp power supply
- Step lamp bulb

1.CHECK STEP LAMP OPERATION

(B)CONSULT-III ACTIVE TEST

1. Turn the ignition switch ON.
2. Select "STEP LAMP TEST" of BCM (INT LAMP) active test item.
3. With operating the test items, check that step lamp turns ON/OFF.

On : Step lamp ON

Off : Step lamp OFF

Does the step lamp turn ON/OFF?

YES >> Step lamp circuit is normal.

NO >> Refer to [INL-24, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000006205856

1.CHECK STEP LAMP OUTPUT

(B)CONSULT-III ACTIVE TEST

1. Turn the ignition switch OFF.
2. Remove the step lamp bulbs (driver side and passenger side).
3. Turn ignition switch ON.
4. Select "STEP LAMP TEST" of BCM (INT LAMP) active test item.
5. With operating the test item, check continuity between BCM harness connector and the ground.

BCM		Ground	Test item	Continuity
Connector	Terminal		STEP LAMP TEST	
M119	7		On	Existed
			Off	Not existed

Is the measurement value normal?

YES >> GO TO 2.

Fixed ON>>GO TO 3.

Fixed OFF>>Replace BCM.

2.CHECK STEP LAMP OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector, and step lamp connector.
3. Check continuity between BCM harness connector and step lamp harness connector.

BCM		Step lamp			Continuity
Connector	Terminal	Connector		Terminal	
M119	7	Driver side	D12	2	Existed
		Passenger side	D42	2	

STEP LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Does continuity exist?

YES >> Replace the step lamp.

NO >> Repair the harnesses or connectors.

3.CHECK STEP LAMP SHORT CIRCUIT

1. Turn the ignition switch OFF.

2. Check continuity between BCM harness connector and the ground.

BCM		Ground	Continuity
Connector	Terminal		
M119	7		Not existed

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Replace BCM.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

TRUNK ROOM LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

TRUNK ROOM LAMP CIRCUIT

Description

INFOID:0000000006205857

Controls the trunk room lamp (ground side) to turn the trunk room lamp ON and OFF.

Component Function Check

INFOID:0000000006205858

CAUTION:

Before performing the diagnosis, check that the following is normal.

- Interior room lamp power supply
- Trunk room lamp bulb

1. CHECK TRUNK ROOM LAMP OPERATION

(H) CONSULT-III ACTIVE TEST

1. Turn the ignition switch ON.
2. Select "LUGGAGE LAMP TEST" of BCM (INT LAMP) active test item.
3. With operating the test items, check that trunk room lamp turns ON/OFF.

On : Trunk room lamp ON

Off : Trunk room lamp OFF

Does the trunk room lamp turn ON/OFF?

YES >> Trunk room lamp circuit is normal.

NO >> Refer to [INL-26, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000006205859

1. CHECK TRUNK ROOM LAMP OUTPUT

(H) CONSULT-III ACTIVE TEST

1. Turn the ignition switch OFF.
2. Remove the trunk room lamp bulb.
3. Turn the ignition switch ON.
4. Select "LUGGAGE LAMP TEST" of BCM (INT LAMP) active test item.
5. With operating the test item, check continuity between BCM harness connector and the ground.

BCM		Ground	Test item	Continuity
Connector	Terminal		LUGGAGE LAMP TEST	
M120	30		On	Existed
			Off	Not existed

Is the measurement value normal?

YES >> GO TO 2.

Fixed ON>>GO TO 3.

Fixed OFF>>Replace BCM.

2. CHECK TRUNK ROOM LAMP OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector and trunk room lamp connector.
3. Check continuity between BCM harness connector and trunk room lamp harness connector.

BCM		Trunk room lamp		Continuity
Connector	Terminal	Connector	Terminal	
M120	30	B47	2	Existed

Does continuity exist?

YES >> Replace trunk room lamp.

TRUNK ROOM LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair harnesses or connectors.

3.CHECK TRUNK ROOM LAMP SHORT CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector and trunk room lamp connector.
3. Check continuity between BCM harness connector and the ground.

BCM		Ground	Continuity
Connector	Terminal		
M120	30		Not existed

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Replace BCM.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT

Description

INFOID:0000000006205860

Provides the power supply and the ground to control the push-button ignition switch illumination.

Component Function Check

INFOID:0000000006205861

1.CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION OPERATION

(B)CONSULT-III ACTIVE TEST

1. Turn the ignition switch ON.
2. Select "ENGINE SW ILLUMI" of BCM (INTELLIGENT KEY) active test item.
3. With operating the test items, check that the push-button ignition switch illumination turns ON/OFF.

On : Push-button ignition switch illumination ON

Off : Push-button ignition switch illumination OFF

Does the push-button ignition switch illumination turn ON/OFF?

YES >> Push-button ignition switch illumination circuit is normal.

NO >> Refer to [INL-28, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000006205862

1.CHECK ILLUMINATION CONTROL SWITCHING OPERATION

1. Turn the ignition switch ON.
2. With operating the lighting switch, check that the push-button ignition switch illumination turns ON/OFF.

Condition	Push-button ignition switch illumination
• Ignition switch ON • Lighting switch 1ST	ON
• Ignition switch OFF • Lighting switch OFF • Driver door LOCK	OFF

Does the push-button ignition switch illumination turn ON/OFF?

YES >> GO TO 2.

NO >> GO TO 3.

2.CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector and the push-button ignition switch connector.
3. Check continuity between BCM harness connector and the push-button ignition switch harness connector.

BCM		Push-button ignition switch		Continuity
Connector	Terminal	Connector	Terminal	
M119	14	M50	2	Existed

Does the continuity exist?

YES >> Replace BCM.

NO >> Repair the harness or the connector.

3.CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION POWER SUPPLY OUTPUT

(B)CONSULT-III ACTIVE TEST

1. Turn the ignition switch ON.
2. Select "ENGINE SW ILLUMI" of BCM (INTELLIGENT KEY) active test item.
3. With operating the test item, check voltage between BCM harness connector and the ground.

PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Terminals		Test item	Voltage (Approx.)
(+)	(-)		
BCM		Ground	ENGINE SW ILLUMI
Connector	Terminal		ON 5 V
M123	133		OFF 0 V

Is the measurement value normal?

- YES >> GO TO 4.
NO >> GO TO 5.

4.CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION POWER SUPPLY OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector and the push-button ignition switch connector.
3. Check continuity between BCM harness connector and the push-button ignition switch harness connector.

BCM		Push-button ignition switch		Continuity
Connector	Terminal	Connector	Terminal	
M123	133	M50	3	Existed

Does the continuity exist?

- YES >> Replace the push-button ignition switch.
NO >> Repair the harness or the connector.

5.CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION POWER SUPPLY SHORT CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector and the push-button ignition switch connector.
3. Check continuity between BCM harness connector and the ground.

BCM		Ground	Continuity
Connector	Terminal		
M123	133		Not existed

Does the continuity exist?

- YES >> Repair the harness or the connector.
NO >> Replace BCM.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P


INTERIOR ROOM LAMP CONTROL SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

INTERIOR ROOM LAMP CONTROL SYSTEM


Wiring Diagram - INTERIOR ROOM LAMP -

INFOID:0000000006205863



INTERIOR ROOM LAMP CONTROL SYSTEM

< DTC/CIRCUIT DIAGNOSIS >



JCLWM4629GB

A B C D E F G H I J K L M Z P O INL

INTERIOR ROOM LAMP CONTROL SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

INTERIOR ROOM LAMP		
Connector No.	Signal Name [Specification]	Terminal No.
B1	WIRE TO WIRE	1
Connector Name	TH8DFW-CS16-TM4	2
Connector Type		3
		4
		5
		6
		7
		8
		9
		10
		11
		12
		13
		14
		15
		16
		17
		18
		19
		20
		21
		22
		23
		24
		25
		26
		27
		28
		29
		30
		31
		32
		33
		34
		35
		36
		37
		38
		39
		40
		41
		42
		43
		44
		45
		46

B23		
Connector No.	Signal Name	Terminal No.
	REAR DOOR SWITCH LH	1
	A03FW	2
		3
		4
		5
		6
		7
		8
		9
		10
		11
		12
		13
		14
		15
		16
		17
		18
		19
		20
		21
		22
		23
		24
		25
		26
		27
		28
		29
		30
		31
		32
		33
		34
		35
		36
		37
		38
		39
		40
		41
		42
		43
		44
		45
		46

B47		
Connector No.	Signal Name [Specification]	Terminal No.
	TRUNK ROOM LAMP	1
	S02FW	2
		3
		4
		5
		6
		7
		8
		9
		10
		11
		12
		13
		14
		15
		16
		17
		18
		19
		20
		21
		22
		23
		24
		25
		26
		27
		28
		29
		30
		31
		32
		33
		34
		35
		36
		37
		38
		39
		40
		41
		42
		43
		44
		45
		46

B27		
Connector No.	Signal Name [Specification]	Terminal No.
	WIRE TO WIRE	1
	NS16WM-CS	2
		3
		4
		5
		6
		7
		8
		9
		10
		11
		12
		13
		14
		15
		16

JCLWM5975GB

INTERIOR ROOM LAMP CONTROL SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

A

B

C

D

M

T

G

I

INL

M

Z

O

P

INTERIOR ROOM LAMP

Connector No.	B201	Color of Wire	Signal Name [Specification]
Connector Name	WIRE TO WIRE	-	-
Connector Type	THBDFW-CS16-TM4	-	-
			
93	BR	-	[Without rear anti-pinch system]
94	R	-	-
95	G	-	-
96	BR	-	-
97	P	-	-
98	L	-	-

Connector No.	B301	Color of Wire	Signal Name [Specification]
Connector Name	WIRE TO WIRE	-	-
Connector Type	NS16FW-CS	-	-
			
93	BR	-	-
94	R	-	-
95	G	-	-
96	BR	-	-
97	P	-	-
98	L	-	-

Connector No.	B216	Color of Wire	Signal Name [Specification]
Connector Name	FRONT DOOR SWITCH (PASSENGER SIDE)	-	-
Connector Type	A03FW	-	-
			
93	BR	-	-
94	W	-	-
95	P	-	-
96	L	-	-
97	V	-	-
98	LG	-	-
99	L	-	-
100	P	-	-

Connector No.	B303	Color of Wire	Signal Name [Specification]
Connector Name	TRUNK LID LOOK ASSEMBLY	-	-
Connector Type	TB20FW	-	-
			
93	BR	-	-
94	R	-	-
95	G	-	-
96	SHIELD	-	-
97	G	-	-
98	Y	-	-
99	SHIELD	-	-
100	W	-	-
101	R	-	-
102	V	-	-
103	BR	-	-



Connector No.	B223	Color of Wire	Signal Name [Specification]
Connector Name	REAR DOOR SWITCH RH	-	-
Connector Type	A03FW	-	-
			
93	BR	-	-
94	R	-	-
95	G	-	-
96	SHIELD	-	-
97	G	-	-
98	Y	-	-
99	SHIELD	-	-
100	W	-	-
101	R	-	-
102	V	-	-
103	BR	-	-

Connector No.	B304	Color of Wire	Signal Name [Specification]
Connector Name	REAR ANTI-PINCH SYSTEM	-	-
Connector Type	TB20FW	-	-
			
93	BR	-	-
94	R	-	-
95	G	-	-
96	BR	-	-
97	R	-	-
98	V	-	-
99	BR	-	-
100	R	-	-

JCLWM5976GB

INTERIOR ROOM LAMP CONTROL SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

INTERIOR ROOM LAMP			
Connector No.	D1	Connector No.	D31
Connector Name	WIRE TO WIRE	Connector Name	WIRE TO WIRE
Connector Type	TH40FW-CS15	Connector Type	TH40FW-CS15
			
Terminal No.	Color of Wire	Signal Name [Specification]	
1	Y	1 2 3 4 5 6 7	
2	B	8 9 10 11 12 13 14 15 16	
3	SB		
4	V		
5	GR		
6	W		
7	BG		
8	L		
9	P		
10	LG		
11	BR		
12	L		
13	W		
14	G		
15	R		
16	GR		
17	L		
18	BR		
19	BG		
20	P		
21	R		
25	V		
26	R		
27	BR		
28	W		
29	Y		
30	G		
31	LG		
32	GR		
33	B		
36	W		
37	P		
38	V		
39	BR		
42	G		
43	GR		
44	BG		
47	V		

POWER WINDOW MAIN SWITCH			
Connector No.	D8	Connector No.	D12
Connector Name	POWER WINDOW MAIN SWITCH	Connector Name	STEP LAMP (DRIVER SIDE)
Connector Type	NS16FH-CS	Connector Type	TB02FW
			
Terminal No.	Color of Wire	Signal Name [Specification]	
1	W	1 2 3 4 5 6 7	
2	LG	8 9 10 11 12 13 14 15 16	
3	GR		
4	V		
5	BR		
6	L		
7	BR		
8	L		
9	BR		
10	SB		
11	G		
12	BR		
13	P		
14	V		
15	B		
			
Terminal No.	Color of Wire	Signal Name [Specification]	
1	LG	1 2 3 4 5 6	
2	P	-	
3	L	-	
4	B	-	
5	Y	-	
6	V	-	

POWER WINDOW MAIN SWITCH			
Connector No.	D9	Connector No.	D17
Connector Name	POWER WINDOW MAIN SWITCH	Connector Name	17 18 19
Connector Type	NS30FW-CS	Connector Type	
			
Terminal No.	Color of Wire	Signal Name [Specification]	
17	B	-	

JCLWM5977GB

INTERIOR ROOM LAMP CONTROL SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

A

B

C

D

M

T

G

I

K

INL

M

Z

O

P

INTERIOR ROOM LAMP


Connector No.	Color of Wire	Terminal No.	Signal Name [Specification]
D18	LG	3	-
	B	4	-
	L	8	-
	G	9	-
	Y	10	-
	B	11	-
	P	12	-
	BG	15	-
	V	16	-



Connector No.	Color of Wire	Terminal No.	Signal Name [Specification]
D12	P	15	STEP LAMP (PASSENGER SIDE)
	SB	16	-
	BR	17	-
	BR	18	-
	BR	19	-
	BR	20	-
	BR	30	-
	L	31	-
	BG	32	-
	P	33	-
	V	34	-
	B	35	-



Connector No.	Color of Wire	Terminal No.	Signal Name [Specification]
E106	GR	66	WIRE TO WIRE
	LG	67	-
	SB	68	-
	P	69	-
TH80FW-CS16-TM4		70	-
	R	80	-
	P	81	-
	G	82	-
	V	83	-
	L	84	-
	W	85	-
	L	86	-



Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	-
3	BR	-
5	LG	-
6	Y	-
7	V	-
9	R	-
10	W	-
11	V	-
12	R	-
13	L	-
14	GR	-
15	P	-
16	SB	-
17	BR	-
18	BR	-
19	BR	-
20	BR	-
31	L	-
32	BG	-
33	P	-
34	V	-
35	W	-
36	SB	-
37	Y	-
38	R	-
39	B	-
40	G	-
41	R	-
42	LG	-
43	G	-
44	GR	-
45	BR	-
46	LG	-
47	V	-
48	P	-
49	L	-
59	B	-



Terminal No.	Color of Wire	Signal Name [Specification]
1A	V	-
2A	G	-
3A	L	-
4A	P	-
5A	L	-
6A	Y	-
7A	R	-
8A	L	-



JCLWM5978GB

INTERIOR ROOM LAMP CONTROL SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

INTERIOR ROOM LAMP			
Connector No.	M5	Wire To Wire	
Connector Name	WIRE TO WIRE		
Connector Type	TH46MW-CS15		
			
Terminal No.	Color of Wire	Signal Name [Specification]	
1	Y	-	
2	B	-	
3	BG	-	
4	V	-	
5	G	-	
6	W	-	
7	LG	-	
8	SB	-	
9	G	-	
10	V	-	
11	SB	-	
12	L	-	
13	W	-	
14	B	-	
15	W	-	
16	R	-	
17	BR	-	
18	V	-	
19	BG	-	
20	P	-	
21	W	-	
25	Y	-	
26	G	-	
27	L	-	
28	Y	-	
29	G	-	
30	SB	-	
31	LG	-	
32	W	-	
33	B	-	
36	W	-	
37	GR	-	
38	Y	-	
39	B	-	
42	Y	-	
43	L	-	
44	G	- [With automatic drive positioner] - [Without automatic drive positioner]	
44	L	-	

Terminal No.	Color of Wire	Signal Name [Specification]	
I	BG	-	
3	R	-	
5	G	-	
6	LG	-	
7	W	-	
9	G	-	
10	W	-	
11	V	-	
12	R	-	
13	L	-	
14	GR	-	
15	P	-	
16	Y	-	
17	BR	-	
18	P	-	
19	L	-	
20	LG	-	
29	GR	-	
31	L	-	
32	Y	-	
33	LG	-	
34	W	-	
35	BR	-	
36	R	-	
37	Y	-	
38	R	-	
39	SB	-	
40	G	-	
41	V	-	
42	LG	-	

JCLWM5979GB

INTERIOR ROOM LAMP CONTROL SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

INTERIOR ROOM LAMP		M7		M16		M24		M50		M50	
Connector No.	Connector Name	Wire To Wire	WIRE TO WIRE	Connector No.	Connector Name	WIRE TO WIRE	WIRE TO WIRE	Connector No.	Connector Name	WIRE TO WIRE	WIRE TO WIRE
Connector Type	THBDMW-CS16-TM4			Connector Type	NIHDMW-CS10			Connector Type	NIHDMW-CS10		
45	SHIELD	-	-	7	B	GND		1	2	3	4
46	SB	-	-	11	SB	KEY SWITCH SIGNAL		5			5
55	W	-	-	56	B			6			6
58	V	-	-	59	Y			7	8	9	10
60	Y	-	-	61	W			11	12	13	14
62	R	-	-	63	G			15	16	17	18
64	B	-	-	65	SHIELD	-		19	20		
71	V	-	-	72	P						
73	SB	-	-	74	Y			2	L		
81	W	-	-	82	BR			3	SHIELD		
84	G	-	-	84	LG			4	G		
85	BG	-	-	85	LG			5	BR		
86	SB	-	-	86	B			6	BG		
87	G	-	-	87	G			7	P		
88	GR	-	-	88	LG			8			
89	L	-	-	89	V			9			
90	P	-	-	90	B			10			
91	BG	-	-	91	G			11			
92	L	-	-	92	S			12			
93	P	-	-	93	P			13			
95	BG	-	-	95	R			14			
96	Y	-	-	96	Y			15			
100	P	-	-	100	P			16			
23	P	-	-	23	P			17	SHIELD		
24	V	-	-	24	V			18	B		
25	LG	-	-	25	LG			19	Y		
26	BR	-	-	26	BR			20	R		
27	BG	-	-	27	BG						
28	LG	-	-	28	LG						
31	V	-	-	31	V						
32	LG	-	-	32	LG						
33	SHIELD	-	-	33	SHIELD						
34	GR	-	-	34	GR						
35	BR	-	-	35	BR						
36	Y	-	-	36	Y						
37	SHIELD	-	-	37	SHIELD						
38	SB	-	-	38	SB						
39	LG	-	-	39	LG						
40	O	-	-	40	O						
41	W	-	-	41	W						
42	SHIELD	-	-	42	SHIELD						
43	R	-	-	43	R						
44	G	-	-	44	G						

JCLWM5980GB

A

B

C

D

E

F

G

H

I

J

K

L

M

N

O

P

Q

R

S

INTERIOR ROOM LAMP CONTROL SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

INTERIOR ROOM LAMP			
Connector No.	M117		
Connector Name	WIRE TO WIRE		
Connector Type	TH80MW-CS 6-TM4		
			
Terminal No.	93	V	- (Without rear anti-pinch system)
	94	Y	-
	95	G	-
	96	G	-
	97	R	-
	98	BG	-
	99	P	-
	100	L	-
Connector No.	M118		
Connector Name	BCM (BODY CONTROL MODULE)		
Connector Type	MD39B-LC		
			
Terminal No.	1	LG	Signal Name [Specification]
	3	SB	-
	5	P	-
	6	G	-
	7	SB	-
	9	LG	-
	10	L	-
	31	SB	-
	32	LG	-
	33	SB	-
	34	LG	-
	40	Y	BAT (F.L.)
	2	Y	POWER WINDOW POWER SUPPLY (BAT)
	3	BG	POWER WINDOW POWER SUPPLY (BAT)
Connector No.	M119		
Connector Name	BCM (BODY CONTROL MODULE)		
Connector Type	NS16FW-CS		
			
Terminal No.	4	5	6
	11	12	13
	12	14	15
	15	16	17
	16	18	19
	80	W	-
	81	SHIELD	-
	82	P	-
	83	L	-
	84	G	-
	85	SHIELD	-
	86	W	-
	87	B	-
	88	R	-
	89	G	-
	90	Y	-
	91	V	-
	92	BR	[With rear anti-pinch system]
	93	LG	- (Without rear anti-pinch system)
	93	V	- (Without rear anti-pinch system)
Connector No.	M120		
Connector Name	BCM (BODY CONTROL MODULE)		
Connector Type	NS12FW-CS		
			
Terminal No.	20	21	22
	25	26	27
	26	28	29
	29	30	31
Connector No.	M122		
Connector Name	BCM (BODY CONTROL MODULE)		
Connector Type	TH40F-B-NH		
			
Terminal No.	1	SB	Signal Name [Specification]
	2	W	TURN SIGNAL RH (FRONT)
	3	BG	TURN SIGNAL LH (FRONT)
	4	V	INT ROOM LAMP CONN
Connector No.	M123		
Connector Name	BCM (BODY CONTROL MODULE)		
Connector Type	TH40F-B-NH		
			
Terminal No.	1	SE	Signal Name [Specification]
	2	SE	ROOM ANT 2-
	3	G	PASSENGER DOOR ANT-
	4	SE	PASSENGER DOOR ANT+
	5	BR	DRIVER DOOR ANT-
	6	V	DRIVER DOOR ANT+
	7	LG	ROOM ANT 1-
	8	Y	ROOM ANT 1+
	9	BG	NATS ANT AMP
	10	GR	NATS ANT AMP
	11	W	IGN RELAY (F/B) CONT
	12	SE	KEYLESS ENTRY RECEIVER COMM
	13	Y	COMBI SW INPUT 5
	14	Y	AC C RELAY CONT
	15	BG	A/T SHIRT SELECTOR POWER SUPPLY
	16	GR	S/L CONDITION 1
	17	BR	PUSH SW
	18	P	CAN-H
	19	L	KEY SLOT ILL
	20	LG	ON IND
	21	GR	ASD CLUTCH SW (With M/T)
	22	Y	PASSENGER DOOR REQUEST SW
	23	P	DRIVER DOOR REQUEST SW
	24	BG	BLOWER FAN MOTOR RELAY CONT
	25	P	KEYLESS ENTRY RECEIVER POWER SUPPLY
	26	SE	S/L UNIT POWER SUPPLY
	27	LG	COMBI SW INPUT 1
	28	B	REAR BUMPER ANT-
	29	W	IGN RELAY (EDM, ERI) CONT
	30	Y	STARTER RELAY CONT
	31	BG	TRUNK ROOM LAMP CONN
	32	R	STEP LAMP OUTPUT
	33	V	ALL DOOR FUEL LID LOCK OUTPUT
	34	G	DRIVER DOOR FUEL LID UNLOCK OUTPUT
	35	W	REAR DOOR UNLOCK OUTPUT
	36	P	REAR DOOR UNLOCK OUTPUT
	37	R	BAT (FUSE)
	38	GR	TRUNK LID OPENER SW
	39	BR	REAR RH DOOR SW
	40	ND	REAR LH DOOR SW
	41	LG	-
	42	LG	-
	43	R	-
	44	G	-
	45	G	-
	46	SHIELD	-
	47	P	-
	48	L	-
	49	SHIELD	-
	50	Y	-
	51	R	-
	52	L	-
	53	W	-
	54	BR	-
	55	LG	-
	56	BR	-
	57	LG	-
	58	BR	-
	59	LG	-
	60	BR	-
	61	LG	-
	62	BR	-
	63	LG	-
	64	BR	-
	65	LG	-
	66	BR	-
	67	LG	-
	68	BR	-
	69	LG	-
	70	BR	-
	71	LG	-
	72	BR	-
	73	LG	-
	74	BR	-
	75	LG	-
	76	BR	-
	77	LG	-
	78	Y	-
	79	BG	-
	80	GR	-
	81	W	-
	82	LG	-
	83	BR	-
	84	LG	-
	85	BR	-
	86	LG	-
	87	BR	-
	88	LG	-
	89	BR	-
	90	LG	-
	91	BR	-
	92	LG	-
	93	BR	-
	94	LG	-
	95	BR	-
	96	LG	-
	97	BR	-
	98	LG	-
	99	BR	-
	100	Y	-
	101	P	-
	102	BG	-
	103	P	-
	104	SE	-
	105	LG	-
	106	SE	-
	107	LG	-
	108	LG	-
	109	W	-
	110	G	-
	111	Y	-

JCLWM5981GB

INTERIOR ROOM LAMP CONTROL SYSTEM


< DTC/CIRCUIT DIAGNOSIS >

INTERIOR ROOM LAMP		Connector No. M123		Connector No. M124		Connector No. R1		Connector No. R11		Connector No. R12		Connector No. R13	
Terminal No.	Color of Wire	Terminal No.	Color of Wire	Terminal No.	Color of Wire	Terminal No.	Color of Wire	Terminal No.	Color of Wire	Terminal No.	Color of Wire	Terminal No.	Color of Wire
1	R	BCM (BODY CONTROL MODULE)		1	WIRE TO WIRE	1	WIRE TO WIRE	1	G	1	B	1	-
13	BG	Connector Name	TH40MW-CS15	2	WIRE TO WIRE	2	WIRE TO WIRE	2	B	2	P	2	-
14	R	Connector Type	TH40DFG-NH	3	OPTICAL SENSOR	3	CLUTCH INTERLOCK SW	3	GR	3	GR	3	-
16	SB			4	STOP LAMP SW 1	4	V	4	V	4	V	4	-
18	BR			5	STOP LAMP SW 2	5	P	5	BR	5	BR	5	-
19	SB			6	DR DOOR UNLOCK SENSOR	6	BR	6	Y	6	Y	6	-
21	S6			7	KEY SLOT SW	7	R	7	GR	7	GR	7	-
23	V			8	IGN FB	8	G	8	BR	8	BR	8	-
24	R			9	PASSENGER DOOR CANCEL SW	9	R	9	R	9	R	9	-
29	BG			10	TRUNK LID OPENER CANCEL SW	10	G	10	V	10	V	10	-
32	V			11	POWER WINDOW SW COMM	11	R	11	B	11	B	11	-
33	L			12	PUSH-BUTTON TENTION SWILL POWER	12	R	12	B	12	B	12	-
34	LG			13	LOCK IND	13	GR	13	Y	13	Y	13	-
37	BG			39	RECEIVER / SENSOR GND	39	L	15	R	15	R	15	-
38	V			42	RECEIVER - SENSOR POWER SUPPLY	42	BG	16	G	16	G	16	-
39	L			43	TIRE PRESSURE RECEIVER COMM	43	BG	17	SHIELD	17	SHIELD	17	-
40	B			44	WIFI / NTP	44	Y	18	B	18	B	18	-
41	W			45	SECURITY INDICATOR LAMP	45	SB	19	Y	19	Y	19	-
42	BR			47	COMBI SW OUTPUT 5	47	LG	20	R	20	R	20	-
43	P			48	COMBI SW OUTPUT 1	48	P	11	Y	11	Y	11	-
44	G			49	COMBI SW OUTPUT 2	49	Y	12	R	12	R	12	-
45	L			50	COMBI SW OUTPUT 3	50	BR						
46	SB			51	COMBI SW OUTPUT 4	52	L						
50	GR			53	DRIVER DOOR SW	53	L						
51	G			54	REAR WINDOW DEFROSTER REAY CON	54	Y						

JCLWM5982GB

INTERIOR ROOM LAMP CONTROL SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

INTERIOR ROOM LAMP		
Connector No.	R13	
Connector Name	VANITY MIRROR LAMP RH	
Connector Type	MC402FW	
 		
 		
 		
 		
Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	R	-
3	V	-
4	-	-
5	B	-
6	Y	-

JCLWM5983GB


ILLUMINATION

< DTC/CIRCUIT DIAGNOSIS >

ILLUMINATION

Wiring Diagram - ILLUMINATION -

INFOID:0000000006205864




2010/08/18

JCLWM5984GB

ILLUMINATION

< DTC/CIRCUIT DIAGNOSIS >

- (AH)** : With A/T and heated seat
- (M)** : With M/T
- (AW)** : AWD models
- (PM)** : With automatic drive positioner
- (OP)** : Without automatic drive positioner
- (SO)** : With sonar system




JCLWM5985GB

ILLUMINATION

< DTC/CIRCUIT DIAGNOSIS >

<A> : With A/T
 <M> : With M/T

* : This connector is not shown in "Harness Layout".



JCLWM5986GB

A
B
C
D
E
F
G
H
I
J
K
L
INL
M
N
O
P

ILLUMINATION

< DTC/CIRCUIT DIAGNOSIS >

ILLUMINATION

Connector No.	Color of Wire	Terminal No.	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
B1	GR	1	WIRE TO WIRE	1	W	-
Connector Name	WIRE TO WIRE	2	-	2	B	-
Connector Type	TH80FW-CS16-TM4	3	-	3	SB	-
		4	-	4	V	-
		5	-	5	GR	-
		6	R	6	W	-
		7	P	7	BG	-
		8	W	8	L	-
		9	LG	9	Y	-
		10	-	10	SB	-
		11	-	11	Y	-
		12	-	12	Y	-
		13	-	13	Y	-
		14	-	14	Y	-
		15	-	15	Y	-
		16	-	16	Y	-
		17	-	17	Y	-
		18	-	18	Y	-
		19	-	19	Y	-
		20	-	20	Y	-
		21	-	21	Y	-
		22	-	22	Y	-
		23	-	23	Y	-
		24	-	24	Y	-
		25	-	25	Y	-
		26	-	26	Y	-
		27	-	27	Y	-
		28	-	28	Y	-
		29	-	29	Y	-
		30	-	30	Y	-
		31	-	31	Y	-
		32	-	32	Y	-
		33	-	33	Y	-
		34	-	34	Y	-
		35	-	35	Y	-
		36	-	36	Y	-
		37	-	37	Y	-
		38	-	38	Y	-
		39	-	39	Y	-
		40	-	40	Y	-
		41	-	41	Y	-
		42	-	42	Y	-
		43	-	43	Y	-
		44	-	44	Y	-
		45	-	45	Y	-
		46	-	46	Y	-

JCLWM5987GB

ILLUMINATION


< DTC/CIRCUIT DIAGNOSIS >

ILLUMINATION

Connector No.	D17	Signal Name [Specification]
Connector Name	DOOR R MIRROR REMOTE CONTROL SWITCH	
Connector Type	TK16FBR	




Connector No.	E5	Signal Name [Specification]
Connector Name	DOOR L/R INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM	
Connector Type	TH20FW-CS12-M4-IV	



Connector No.	E6	Signal Name [Specification]
Connector Name	SPDR L/R INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM	
Connector Type	TH08FW-NH	




Connector No.	E106	Wire To Wire
Connector Name		
Connector Type	TH08FW-CS16-TM4	



Terminal No.	Color of Wire	Signal Name [Specification]
4	BR	-
7	B	-
8	B	-
9	R	-
10	GR	-
11	LG	-
12	G	-
13	W	-
15	Y	-



Terminal No.	Color of Wire	Signal Name [Specification]
39	P	-
40	L	-
41	B/W	-
42	GR	-
43	G	-
44	LG	-
45	V	-
46	SB	-



Connector No.	E103	FUSE BLOCK (J/E)
Connector Name	NS16FW-GS	
Connector Type	TH20FW-CS12-M4-IV	



Terminal No.	Color of Wire	Signal Name [Specification]
1F	SB	-
2F	LG	-
3F	GR	-
4F	BR	-
5F	W	-
6F	Y	-
7P	-	-
11W	-	-
12B/W	-	-
13Y	-	-
16LG	-	-
19R	-	-
25G	-	-
26Y	-	-
27EG	-	-
28L	-	-



Terminal No.	Color of Wire	Signal Name [Specification]
1F	SB	-
2F	LG	-
3F	GR	-
4F	BR	-
5F	W	-
6F	Y	-
7P	-	-
11W	-	-
12B/W	-	-
13Y	-	-
16LG	-	-
19R	-	-
25G	-	-
26Y	-	-
27EG	-	-
28L	-	-

Terminal No.	Color of Wire	Signal Name [Specification]
81	P	-
82	G	-
83	V	-
84	L	-
85	W	-
86	L	-
87	BR	-
88	GR	-
89	V	-
91	W	-
93	GR	-
95	LG	-
97	SB	-
98	SHELD	-
99	L	-
100	P	-


A B C D E F G H I J K L M N O P Q R S T Z

ILLUMINATION


< DTC/CIRCUIT DIAGNOSIS >

ILLUMINATION


Connector No.	M2
Connector Name	FUSE BLOCK (J/B)
Connector Type	NSI DFW-CS




Terminal No.	Color of Wire	Signal Name [Specification]	Signal Name [Specification]
1B	SB	-	-
3B	P	-	-
4B	G	-	-
5B	BG	-	-
6B	Y	-	-
7B	P	-	-
8B	R	-	-
9B	SB	-	-



Terminal No.	Color of Wire	Signal Name [Specification]	Signal Name [Specification]
1	Y	-	-
2	B	-	-
3	BG	-	-
4	V	-	-
5	G	-	-
6	W	-	-
7	LG	-	-
8	SB	-	-
9	G	-	-
10	V	-	-
11	SB	-	-
12	L	-	-
13	W	-	-
14	B	-	-
15	V	-	-
16	R	-	-
17	BR	-	-
18	V	-	-
19	BG	-	-
20	P	-	-
21	V	-	-
25	Y	-	-
26	G	-	-
27	L	-	-
28	Y	-	-
29	G	-	-
30	SB	-	-
31	LG	-	-
32	V	-	-
33	B	-	-
36	W	-	-
37	GR	-	-
38	Y	-	-
39	B	-	-
42	Y	-	-
43	L	-	-
44	G	-	-
44	L	-	-



Terminal No.	Color of Wire	Signal Name [Specification]	Signal Name [Specification]
1	Y	-	-
2	B	-	-
3	BG	-	-
4	V	-	-
5	G	-	-
6	W	-	-
7	LG	-	-
8	SB	-	-
9	G	-	-
10	V	-	-
11	SB	-	-
12	L	-	-
13	W	-	-
14	B	-	-
15	V	-	-
16	R	-	-
17	BR	-	-
18	V	-	-
19	BG	-	-
20	P	-	-
21	V	-	-
25	Y	-	-
26	G	-	-
27	L	-	-
28	Y	-	-
29	G	-	-
30	SB	-	-
31	LG	-	-
32	V	-	-
33	B	-	-
36	W	-	-
37	GR	-	-
38	Y	-	-
39	B	-	-
42	Y	-	-
43	L	-	-
44	G	-	-
44	L	-	-



Terminal No.	Color of Wire	Signal Name [Specification]	Signal Name [Specification]
1	Y	-	-
2	B	-	-
3	BG	-	-
4	V	-	-
5	G	-	-
6	W	-	-
7	LG	-	-
8	SB	-	-
9	G	-	-
10	V	-	-
11	SB	-	-
12	L	-	-
13	W	-	-
14	B	-	-
15	V	-	-

JCLWM5989GB

ILLUMINATION

< DTC/CIRCUIT DIAGNOSIS >

ILLUMINATION

Connector No.	M7	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
Connector Name	WIRE TO WIRE		1	GR	FR WASHER (-)
Connector Type	THBDMW-CS16-TM4		2	SB	OUTPUT 4
			5	L	OUTPUT 3
			6	B	GND
45	SHIELD	-	7	BG	INPUT 3
46	SB	-	8	BR	OUTPUT 5
55	W	-	9	W	INPUT 2
56	B	-	10	R	INPUT 4
58	V	-	11	LG	INPUT 1
59	Y	-	12	P	OUTPUT 1
60	Y	-	13	Y	INPUT 5
61	W	-	14	G	OUTPUT 2
62	R	-			
63	G	-			
64	B	-			
65	SHIELD	-			
71	V	-			
72	P	-			
73	SB	-			
74	Y	-	1	R	-
81	W	-	2	B	-
82	BR	-	3	SB	-
84	LG	-	4	B	-
85	BG	-			
86	SB	-			
87	G	-			
88	GR	-			
89	L	-			
90	P	-			
91	BG	-			
92	L	-			
93	P	-			
95	LG	-			
96	Y	-			
100	P	-			
115	R	-			
116	BR	-			
117	P	-			
118	V	-			
20	L	-			
21	P	-			
22	L	-			
23	P	-			
24	V	-			
25	LG	-			
26	BR	-			
27	BG	-			
28	LG	-			
31	V	-			
32	LG	-			
33	SHIELD	-			
34	GR	-			
35	BR	-			
36	Y	-			
37	SHIELD	-			
38	SB	-			
39	LG	-			
40	O	-			
41	W	-			
42	SHIELD	-			
43	R	-			
44	G	-			

JCLWM5990GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z

ILLUMINATION

< DTC/CIRCUIT DIAGNOSIS >

ILLUMINATION

Connector No.	M36
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Type	TK08FGY-IV
	

Connector No.	M53
Connector Name	COMBINATION METER
Connector Type	SAB09W
	

Connector No.	M54
Connector Name	METER CONTROL SWITCH
Connector Type	TH12FW-NH
	

Connector No.	M67
Connector Name	UNIFIED METER AND A/C AMP.
Connector Type	TH32FW-NH

Terminal No.	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
24	P	1	V	BATTERY POWER SUPPLY
25	SB	2	LG	COMMUNICATION SIGNAL (METER->AMP)
26	B	3	GR	COMMUNICATION SIGNAL (AMP->METER)
31	L	5	B	GROUND
32	Y	6	W	ALTERNATOR SIGNAL
33	B	7	LG	AIR BAG SIGNAL
34	LG	10	W	SECURITY SIGNAL
		15	B	GROUND
		16	BR	METER CONTROL SWITCH GROUND
		18	GR	ILL. GND
		19	B	ILL. GND
		20	R	
		21	G	IGNITION SIGNAL
		22	B	GROUND
		24	BR	COMMUNICATION SIGNAL (LCD->AMP)
		25	Y	COMMUNICATION SIGNAL (AMP->LCD)
		26	R	VEHICLE SPEED SIGNAL (3-PULSE)
		27	P	PARKING BRAKE SWITCH SIGNAL
		28	SB	Brake fluid level switch
		29	P	SEAT BELT BUCKLE SW. SIGNAL (DRIVER SIDE)
		30	G	SEAT BELT BUCKLE SW. SIGNAL (PASSENGER SIDE)
		31	L	WASHER LEVEL SWITCH SIGNAL
		33	R	ILLUMINATION CONTROL SIGNAL
		36	LG	SELECT/ SWITCH SIGNAL
		37	Y	ENTER/ SWITCH SIGNAL
		2	R	-
		3	L	-
		4	BR	TRIP A/B RESET SWITCH SIGNAL
		5	LG	ILLUMINATION CONTROL SWITCH SIGNAL (C)
		6	BG	ILLUMINATION CONTROL SWITCH SIGNAL (C)
		7	GR	COMMUNICATION SIGNAL (AMP->METER)
		8	L	VEHICLE SPEED SIGNAL (2-PULSE)
		9	SB	SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SIDE)
		10	W	-
		11	G	NON-MANUAL MODE SIGNAL
		14	BR	COMMUNICATION SIGNAL (LCD->AMP)
		20	BR	ION ON / OFF SIGNAL
		23	Y	AT SNOW SWITCH SIGNAL
		25	V	MANUAL MODE SHIFT DOWN SIGNAL
		26	G	PADDLE SHIFTER DOWN SIGNAL

Terminal No.	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
1	2	1	LG	UNIFIED METER AND A/C AMP.
2	25	2	LG	ACC POWER SUPPLY
3	26	3	GR	FUEL LEVEL SENSOR SIGNAL
4	31	4	B	INTAKE SENSOR SIGNAL
5	32	5	W	IN-VEHICLE SENSOR SIGNAL
6	33	6	LG	AMBENT SENSOR SIGNAL
7	34	7	V	SUNLOAD SENSOR SIGNAL
8		10	Y	EXHAUST GAS OUTSIDE ODOR DETECTING SENSOR SIGNAL
		15	W	IGNITION POWER SUPPLY
		16	BR	BATTERY POWER SUPPLY
		18	GR	IN-VEHICLE SENSOR GROUND
		19	LG	AMBENT SENSOR GROUND
		20	LG	Brake fluid level switch
		21	Y	FUEL LEVEL SENSOR GROUND
		22	W	INTAKE SENSOR GROUND
		24	BR	IN-VEHICLE SENSOR GROUND
		25	LG	AMBENT SENSOR GROUND
		26	LG	SUNLOAD SENSOR GROUND
		27	LG	ION CONTROL MODE OUTPUT SIGNAL
		28	Y	FUEL LEVEL SENSOR GROUND
		29	W	INTAKE SENSOR GROUND
		30	BR	IN-VEHICLE SENSOR GROUND
		31	LG	AMBENT SENSOR GROUND
		33	LG	SUNLOAD SENSOR GROUND
		36	LG	STOP LAMP SWITCH SIGNAL
		37	G	MANUAL MODE SHIFT UP SIGNAL
		38	G	PADDLE SHIFTER UP SIGNAL
		39	L	COMMUNICATION SIGNAL (LCD->AMP)
		40	BG	ION ON / OFF SIGNAL
			P	EACH DOOR MOTOR POWER SUPPLY
			R	GROUND
			GR	CAN-L

Terminal No.	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
1	2	1	LG	UNIFIED METER AND A/C AMP.
2	25	2	LG	ACC POWER SUPPLY
3	26	3	GR	FUEL LEVEL SENSOR SIGNAL
4	31	4	B	INTAKE SENSOR SIGNAL
5	32	5	W	IN-VEHICLE SENSOR SIGNAL
6	33	6	LG	AMBENT SENSOR SIGNAL
7	34	7	V	SUNLOAD SENSOR SIGNAL
8		10	Y	EXHAUST GAS OUTSIDE ODOR DETECTING SENSOR SIGNAL
		15	W	IGNITION POWER SUPPLY
		16	BR	BATTERY POWER SUPPLY
		18	GR	IN-VEHICLE SENSOR GROUND
		19	LG	AMBENT SENSOR GROUND
		20	LG	SUNLOAD SENSOR GROUND
		24	LG	STOP LAMP SWITCH SIGNAL
		25	LG	MANUAL MODE SHIFT UP SIGNAL
		26	LG	COMMUNICATION SIGNAL (LCD->AMP)
		27	LG	ION ON / OFF SIGNAL
		28	BR	EACH DOOR MOTOR POWER SUPPLY
		29	R	GROUND
		30	GR	CAN-L

JCLWM5991GB

ILLUMINATION

< DTC/CIRCUIT DIAGNOSIS >

ILLUMINATION

Connector No.	M72
Connector Name	MULTIFUNCTION SWITCH
Connector Type	TH18FW-NH

Terminal No.	Color of Wire	Signal Name [Specification]	Signal Name [Specification]
1	B	GND	SOUND SIGNAL FRONT LH (+)
3	P	ACC	SOUND SIGNAL FRONT LH (-)
4	EG	ILL.	SOUND SIGNAL REAR LH (-)
5	B	ILL. CONT.	SOUND SIGNAL REAR LH (+)
6	SB	AV COMM (L)	P
8	LG	AV COMM (L)	STRG. SW A
9	BR	SW GND	ACC
14	V	DISK EJECT SIGNAL	L
16	G	HAZARD ON	BR

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	Y

7	B	RGB AREA (VS) SIGNAL	-
8	P	COMM (DISP->CONT)	-
9	R	HP	-
10	V	SIGNAL GND	-
11	B	SIGNAL VCC	-
12	B	COMP SYNC	-
13	R	SHIELD	-
15	R	SHIELD	-
16	G	COMM (CONT->DISP)	-
17	B	SHIELD	-
18	B	OP	-
19	Y	INVERTER GND	-
20	R	INVERTER VCC	-

Connector No.	M81	
Connector Name	AV CONTROL UNIT	
Connector Type	TH18FW-CS2	
Connector No.	M118	
Connector Name	BCM (BODY CONTROL MODULE)	
Connector Type	MOSFET-IG	
Connector No.	M102	
Connector Name	GLOVE BOX LAMP	
Connector Type	ADJ/FW	
Connector No.	M106	
Connector Name	WIRE TO WIRE	
Connector Type	NH10MW-CS10	
Terminal Color of Wire	Signal Name [Specification]	
1	W	BATT (F/L)
2	Y	POWER WINDOW POWER SUPPLY (BAT)
3	BG	POWER WINDOW POWER SUPPLY (RAP)

Terminal No.	Color of Wire	Signal Name [Specification]	Signal Name [Specification]
1	R	-	-
2	B	-	-
3	Y	POWER	-
4	BR	-	-
5	LG	STRG. SW A	-
6	SB	STRG. SW B	-
7	P	SOUND SIGNAL REAR RH (+)	-
8	LG	SOUND SIGNAL REAR RH (-)	-
9	BR	SOUND SIGNAL FRONT RH (+)	-
10	SB	SOUND SIGNAL FRONT RH (-)	-
11	V	SOUND SIGNAL REAR RH (+)	-
12	G	SOUND SIGNAL REAR RH (-)	-
13	B	SOUND SIGNAL FRONT RH (+)	-
14	Y	SOUND SIGNAL FRONT RH (-)	-
15	BR	SOUND SIGNAL REAR RH (+)	-
16	LG	SOUND SIGNAL REAR RH (-)	-
17	SB	SOUND SIGNAL FRONT RH (+)	-
18	P	SOUND SIGNAL FRONT RH (-)	-
19	G	BATTERY	-
20	Y	GND	-

Terminal No.	Color of Wire	Signal Name [Specification]	Signal Name [Specification]
1	B	ILLUMINATION (-)	COMPOSITE IMAGE SIGNAL
2	L	ILLUMINATION (+)	RGB (BLUE) SIGNAL
3	B	GND	RGB (GREEN) SIGNAL
4	Y	BAT	RGB (RED) SIGNAL

43	B	RGB AREA (VS) SIGNAL	-
44	L	COMM (DISP->CONT)	-
45	R	HP	-
46	LG	SIGNAL GND	-
47	BG	SIGNAL VCC	-
48	BR	COMP SYNC	-
49	Y	SHIELD	-
50	SB	SHIELD	-
55	B	SHIELD	-
56	G	COMM (CONT->DISP)	-
57	G	OP	-
58	BR	INVERTER GND	-
59	Y	INVERTER VCC	-

JCLWM5992GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z
INL

ILLUMINATION

< DTC/CIRCUIT DIAGNOSIS >

ILLUMINATION

ILLUMINATION		
Connector No.	Color of Wire	Signal Name [Specification]
MI19	V	MATS ANT AMP
	SB	(IGN RELAY (F/B) CONT
	Y	KEYLESS ENTRY RECEIVER COMM
	Y	COMBI SW INPUT 5
	Y	COMBI SW INPUT 3
	BR	PUSH SW
	P	CAN-L
	L	OAN-H
	G	KEY SLOT ILL
	R	ON IND
	G	ACC RELAY CONT
	GR	A/T SHIFT SELECTOR POWER SUPPLY
	L	S/L CONDITION 1
	P	S/L CONDITION 2
	R	SHIFT P (High A-T)
	BR	ASCD CLUTCH SW (High M/T)
	Y	PASSENGER DOOR REQUEST SW
	P	DRIVER DOOR REQUEST SW
	G	BLOWER FAN MOTOR RELAY CONT
	P	BLower FAN MOTOR RELAY SUPPLY
	SB	STUNTING POWER SUPPLY
	Y	COMBI SW INPUT 1
	P	STEEL LAMP OUTPUT
	V	ALL DOOR FUEL LID UNLOCK OUTPUT
	G	REAR DOOR FUEL LID UNLOCK OUTPUT
	P	BAT FUSE
	R	GRID
	G	FUSH-BUTTON IGNITION SW 1 GND
	W	ACC IND
	BR	TURN SIGNAL RH (FRONT)
	W	TURN SIGNAL LH (FRONT)
	BR	INT ROOM LAMP - CONT
	V	
MI19	R	ROOM ANT 2-
	G	ROOM ANT 2-
	SB	PASSENGER DOOR ANT-
	V	DRIVER DOOR ANT-
	LG	DRIVER DOOR ANT-
	Y	ROOM ANT 1-
	BR	ROOM ANT 1-
	GR	NATS ANT AMP

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
81	V	MATS ANT AMP	132	V	POWER WINDOW SW COMM
82	SB	(IGN RELAY (F/B) CONT	133	L	PUSH-BUTTON IGNITION SW/L POWER
83	Y	KEYLESS ENTRY RECEIVER COMM	134	LG	LOCK IND
	Y	RECEIVER / SENSOR GRID	137	BG	RECEIVER / SENSOR GRID
	Y	RECEIVER / SENSOR POWER SUPPLY	138	V	RECEIVER / SENSOR POWER SUPPLY
	BR	PUSH SW	139	L	TIRE PRESSURE RECEIVER COMM
	P	CAN-L	140	B	SHIFT N/P
	L	OAN-H	141	W	SECURITY INDICATOR LAMP
	G	KEY SLOT ILL	142	BR	COMBI SW OUTPUT 5
	R	ON IND	143	P	COMBI SW OUTPUT 1
	G	ACC RELAY CONT	144	G	COMBI SW OUTPUT 2
	GR	A/T SHIFT SELECTOR POWER SUPPLY	145	L	COMBI SW OUTPUT 3
	L	S/L CONDITION 1	146	SB	COMBI SW OUTPUT 4
	P	S/L CONDITION 2	150	GR	DRIVER DOOR SW
	R	SHIFT P (High A-T)	151	G	REAR WINDOW DEFROGGER RELAY CONT
	BR	ASCD CLUTCH SW (High M/T)			
	Y	PASSENGER DOOR REQUEST SW			
	P	DRIVER DOOR REQUEST SW			
	G	BLOWER FAN MOTOR RELAY CONT			
	P	BLower FAN MOTOR RELAY SUPPLY			
	SB	STUNTING POWER SUPPLY			
	Y	COMBI SW INPUT 1			
	P	STEEL LAMP OUTPUT			
	V	ALL DOOR FUEL LID UNLOCK OUTPUT			
	G	REAR DOOR FUEL LID UNLOCK OUTPUT			
	P	BAT FUSE			
	R	GRID			
	G	FUSH-BUTTON IGNITION SW 1 GND			
	W	ACC IND			
	BR	TURN SIGNAL RH (FRONT)			
	W	TURN SIGNAL LH (FRONT)			
	BR	INT ROOM LAMP - CONT			
	V				

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
112	R	RAIN SENSOR SERIAL LINK	112	R	RAIN SENSOR SERIAL LINK
113	BR	OPTICAL SENSOR	113	BR	CLUTCH INTERLOCK SW
114	R	CLUTCH INTERLOCK SW	114	R	STOP LAMP SW 1
116	BR	STOP LAMP SW 1	116	BR	DR DOOR UNLOCK SENSOR
119	BR	DR DOOR UNLOCK SENSOR	119	BR	KEY SLOT SW
121	BR	KEY SLOT SW	121	BR	ION F/B
123	V	ION F/B	123	V	PASSENGER DOOR SW
124	R	PASSENGER DOOR CANCEL SW	124	R	TRUNK LID OPENER CANCEL SW
129	BR	TRUNK LID OPENER CANCEL SW	129	BR	

JCLWM5993GB

ILLUMINATION

< DTC/CIRCUIT DIAGNOSIS >

ILLUMINATION

<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Connector No.</th> <th colspan="2">M139</th> </tr> </thead> <tbody> <tr> <td>Connector Name</td> <td>SNOW MODE SWITCH</td> <td>Connector Name</td> <td>HEATED SEAT SWITCH (PASSENGER SIDE)</td> </tr> <tr> <td>Connector Type</td> <td>TK05FW</td> <td>Connector Type</td> <td>TH12W-NH</td> </tr> </tbody> </table> <p> </p>	Connector No.		M139		Connector Name	SNOW MODE SWITCH	Connector Name	HEATED SEAT SWITCH (PASSENGER SIDE)	Connector Type	TK05FW	Connector Type	TH12W-NH	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Connector No.</th> <th colspan="2">M142</th> </tr> </thead> <tbody> <tr> <td>Connector Name</td> <td>HEATED SEAT SWITCH (PASSENGER SIDE)</td> <td>Connector Name</td> <td>WIRE TO WIRE</td> </tr> <tr> <td>Connector Type</td> <td>TK05FBR</td> <td>Connector Type</td> <td>TH12W-NH</td> </tr> </tbody> </table> <p> </p>	Connector No.		M142		Connector Name	HEATED SEAT SWITCH (PASSENGER SIDE)	Connector Name	WIRE TO WIRE	Connector Type	TK05FBR	Connector Type	TH12W-NH	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Connector No.</th> <th colspan="2">M174</th> </tr> </thead> <tbody> <tr> <td>Connector Name</td> <td>WIRE TO WIRE</td> <td>Connector Name</td> <td>HEATED SEAT SWITCH (PASSENGER SIDE)</td> </tr> <tr> <td>Connector Type</td> <td>TH12W-NH</td> <td>Connector Type</td> <td>TK05BBR</td> </tr> </tbody> </table> <p> </p>	Connector No.		M174		Connector Name	WIRE TO WIRE	Connector Name	HEATED SEAT SWITCH (PASSENGER SIDE)	Connector Type	TH12W-NH	Connector Type	TK05BBR																																																																																																																																																																			
Connector No.		M139																																																																																																																																																																																																							
Connector Name	SNOW MODE SWITCH	Connector Name	HEATED SEAT SWITCH (PASSENGER SIDE)																																																																																																																																																																																																						
Connector Type	TK05FW	Connector Type	TH12W-NH																																																																																																																																																																																																						
Connector No.		M142																																																																																																																																																																																																							
Connector Name	HEATED SEAT SWITCH (PASSENGER SIDE)	Connector Name	WIRE TO WIRE																																																																																																																																																																																																						
Connector Type	TK05FBR	Connector Type	TH12W-NH																																																																																																																																																																																																						
Connector No.		M174																																																																																																																																																																																																							
Connector Name	WIRE TO WIRE	Connector Name	HEATED SEAT SWITCH (PASSENGER SIDE)																																																																																																																																																																																																						
Connector Type	TH12W-NH	Connector Type	TK05BBR																																																																																																																																																																																																						
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Terminal No.</th> <th>Color of Wire</th> <th>Signal Name [Specification]</th> <th>Terminal No.</th> <th>Color of Wire</th> <th>Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>R</td> <td>-</td> <td>1</td> <td>L</td> <td>-</td> </tr> <tr> <td>2</td> <td>GR</td> <td>-</td> <td>2</td> <td>GR</td> <td>-</td> </tr> <tr> <td>4</td> <td>Y</td> <td>-</td> <td>3</td> <td>W</td> <td>-</td> </tr> <tr> <td>5</td> <td>P</td> <td>-</td> <td>4</td> <td>R</td> <td>-</td> </tr> <tr> <td>6</td> <td>B</td> <td>-</td> <td>5</td> <td>W</td> <td>-</td> </tr> <tr> <td>7</td> <td>B</td> <td>-</td> <td>6</td> <td>W</td> <td>-</td> </tr> <tr> <td>8</td> <td>R</td> <td>-</td> <td>7</td> <td>B</td> <td>-</td> </tr> <tr> <td>9</td> <td>W</td> <td>-</td> <td>8</td> <td>R</td> <td>-</td> </tr> <tr> <td>10</td> <td>GR</td> <td>-</td> <td>9</td> <td>W</td> <td>-</td> </tr> <tr> <td>11</td> <td>GR</td> <td>-</td> <td>10</td> <td>SB</td> <td>-</td> </tr> <tr> <td>12</td> <td>SB</td> <td>-</td> <td></td> <td></td> <td></td> </tr> </tbody> </table>		Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	1	R	-	1	L	-	2	GR	-	2	GR	-	4	Y	-	3	W	-	5	P	-	4	R	-	6	B	-	5	W	-	7	B	-	6	W	-	8	R	-	7	B	-	9	W	-	8	R	-	10	GR	-	9	W	-	11	GR	-	10	SB	-	12	SB	-				<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Terminal No.</th> <th>Color of Wire</th> <th>Signal Name [Specification]</th> <th>Terminal No.</th> <th>Color of Wire</th> <th>Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>LG</td> <td>-</td> <td>1</td> <td>LG</td> <td>-</td> </tr> <tr> <td>2</td> <td>SG</td> <td>-</td> <td>2</td> <td>SG</td> <td>-</td> </tr> <tr> <td>3</td> <td>Y</td> <td>-</td> <td>3</td> <td>R</td> <td>-</td> </tr> <tr> <td>4</td> <td>B</td> <td>-</td> <td>4</td> <td>W</td> <td>-</td> </tr> <tr> <td>5</td> <td>BG</td> <td>-</td> <td>5</td> <td>W</td> <td>-</td> </tr> <tr> <td>6</td> <td>B</td> <td>-</td> <td>6</td> <td>GR</td> <td>-</td> </tr> <tr> <td>7</td> <td>B</td> <td>-</td> <td>7</td> <td>GR</td> <td>-</td> </tr> <tr> <td>8</td> <td>R</td> <td>-</td> <td>8</td> <td>GR</td> <td>-</td> </tr> <tr> <td>9</td> <td>W</td> <td>-</td> <td>9</td> <td>W</td> <td>-</td> </tr> <tr> <td>10</td> <td>GR</td> <td>-</td> <td>10</td> <td>GR</td> <td>-</td> </tr> <tr> <td>11</td> <td>GR</td> <td>-</td> <td>11</td> <td>GR</td> <td>-</td> </tr> <tr> <td>12</td> <td>SB</td> <td>-</td> <td>12</td> <td>SB</td> <td>-</td> </tr> <tr> <td>13</td> <td>SG</td> <td>-</td> <td>13</td> <td>SG</td> <td>-</td> </tr> <tr> <td>14</td> <td>LG</td> <td>-</td> <td>14</td> <td>LG</td> <td>-</td> </tr> <tr> <td>15</td> <td>SG</td> <td>-</td> <td>15</td> <td>SG</td> <td>-</td> </tr> <tr> <td>16</td> <td>R</td> <td>-</td> <td>16</td> <td>R</td> <td>-</td> </tr> <tr> <td>17</td> <td>W</td> <td>-</td> <td>17</td> <td>W</td> <td>-</td> </tr> <tr> <td>18</td> <td>W</td> <td>-</td> <td>18</td> <td>G</td> <td>-</td> </tr> <tr> <td>19</td> <td>GR</td> <td>-</td> <td>19</td> <td>Y</td> <td>-</td> </tr> <tr> <td>20</td> <td>GR</td> <td>-</td> <td>20</td> <td>B</td> <td>-</td> </tr> </tbody> </table>		Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	1	LG	-	1	LG	-	2	SG	-	2	SG	-	3	Y	-	3	R	-	4	B	-	4	W	-	5	BG	-	5	W	-	6	B	-	6	GR	-	7	B	-	7	GR	-	8	R	-	8	GR	-	9	W	-	9	W	-	10	GR	-	10	GR	-	11	GR	-	11	GR	-	12	SB	-	12	SB	-	13	SG	-	13	SG	-	14	LG	-	14	LG	-	15	SG	-	15	SG	-	16	R	-	16	R	-	17	W	-	17	W	-	18	W	-	18	G	-	19	GR	-	19	Y	-	20	GR	-	20	B	-
Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]																																																																																																																																																																																																				
1	R	-	1	L	-																																																																																																																																																																																																				
2	GR	-	2	GR	-																																																																																																																																																																																																				
4	Y	-	3	W	-																																																																																																																																																																																																				
5	P	-	4	R	-																																																																																																																																																																																																				
6	B	-	5	W	-																																																																																																																																																																																																				
7	B	-	6	W	-																																																																																																																																																																																																				
8	R	-	7	B	-																																																																																																																																																																																																				
9	W	-	8	R	-																																																																																																																																																																																																				
10	GR	-	9	W	-																																																																																																																																																																																																				
11	GR	-	10	SB	-																																																																																																																																																																																																				
12	SB	-																																																																																																																																																																																																							
Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]																																																																																																																																																																																																				
1	LG	-	1	LG	-																																																																																																																																																																																																				
2	SG	-	2	SG	-																																																																																																																																																																																																				
3	Y	-	3	R	-																																																																																																																																																																																																				
4	B	-	4	W	-																																																																																																																																																																																																				
5	BG	-	5	W	-																																																																																																																																																																																																				
6	B	-	6	GR	-																																																																																																																																																																																																				
7	B	-	7	GR	-																																																																																																																																																																																																				
8	R	-	8	GR	-																																																																																																																																																																																																				
9	W	-	9	W	-																																																																																																																																																																																																				
10	GR	-	10	GR	-																																																																																																																																																																																																				
11	GR	-	11	GR	-																																																																																																																																																																																																				
12	SB	-	12	SB	-																																																																																																																																																																																																				
13	SG	-	13	SG	-																																																																																																																																																																																																				
14	LG	-	14	LG	-																																																																																																																																																																																																				
15	SG	-	15	SG	-																																																																																																																																																																																																				
16	R	-	16	R	-																																																																																																																																																																																																				
17	W	-	17	W	-																																																																																																																																																																																																				
18	W	-	18	G	-																																																																																																																																																																																																				
19	GR	-	19	Y	-																																																																																																																																																																																																				
20	GR	-	20	B	-																																																																																																																																																																																																				
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Terminal No.</th> <th>Color of Wire</th> <th>Signal Name [Specification]</th> <th>Terminal No.</th> <th>Color of Wire</th> <th>Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>SB</td> <td>-</td> <td>1</td> <td>LG</td> <td>-</td> </tr> <tr> <td>2</td> <td>GR</td> <td>-</td> <td>2</td> <td>SG</td> <td>-</td> </tr> <tr> <td>3</td> <td>R</td> <td>-</td> <td>3</td> <td>W</td> <td>-</td> </tr> <tr> <td>4</td> <td>B</td> <td>-</td> <td>4</td> <td>R</td> <td>-</td> </tr> <tr> <td>5</td> <td>G</td> <td>-</td> <td>5</td> <td>W</td> <td>-</td> </tr> <tr> <td>6</td> <td>B</td> <td>-</td> <td>6</td> <td>B</td> <td>-</td> </tr> </tbody> </table>		Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	1	SB	-	1	LG	-	2	GR	-	2	SG	-	3	R	-	3	W	-	4	B	-	4	R	-	5	G	-	5	W	-	6	B	-	6	B	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Terminal No.</th> <th>Color of Wire</th> <th>Signal Name [Specification]</th> <th>Terminal No.</th> <th>Color of Wire</th> <th>Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>LG</td> <td>-</td> <td>1</td> <td>BR</td> <td>SOUND SIGNAL FRONT LH (+)</td> </tr> <tr> <td>2</td> <td>GR</td> <td>-</td> <td>2</td> <td>L</td> <td>SOUND SIGNAL FRONT LH (-)</td> </tr> <tr> <td>3</td> <td>R</td> <td>-</td> <td>3</td> <td>W</td> <td>SOUND SIGNAL REAR LH (+)</td> </tr> <tr> <td>4</td> <td>W</td> <td>-</td> <td>4</td> <td>LG</td> <td>SOUND SIGNAL REAR LH (-)</td> </tr> <tr> <td>5</td> <td>W</td> <td>-</td> <td>5</td> <td>SG</td> <td>SOUND SIGNAL REAR RH (+)</td> </tr> <tr> <td>6</td> <td>B</td> <td>-</td> <td>6</td> <td>P</td> <td>SOUND SIGNAL REAR RH (-)</td> </tr> <tr> <td>7</td> <td>B</td> <td>-</td> <td>7</td> <td>V</td> <td>ILLUMINATION</td> </tr> <tr> <td>8</td> <td>R</td> <td>-</td> <td>8</td> <td>ACC</td> <td>-</td> </tr> <tr> <td>9</td> <td>W</td> <td>-</td> <td>9</td> <td>LG</td> <td>SOUND SIGNAL FRONT RH (+)</td> </tr> <tr> <td>10</td> <td>W</td> <td>-</td> <td>10</td> <td>R</td> <td>SOUND SIGNAL FRONT RH (-)</td> </tr> <tr> <td>11</td> <td>GR</td> <td>-</td> <td>11</td> <td>L</td> <td>SOUND SIGNAL REAR RH (+)</td> </tr> <tr> <td>12</td> <td>GR</td> <td>-</td> <td>12</td> <td>W</td> <td>SOUND SIGNAL REAR RH (-)</td> </tr> <tr> <td>13</td> <td>Y</td> <td>-</td> <td>13</td> <td>P</td> <td>SOUND SIGNAL REAR RH (+)</td> </tr> <tr> <td>14</td> <td>Y</td> <td>-</td> <td>14</td> <td>B</td> <td>SOUND SIGNAL REAR RH (-)</td> </tr> <tr> <td>15</td> <td>SG</td> <td>-</td> <td>15</td> <td>SG</td> <td>STRG SW A</td> </tr> <tr> <td>16</td> <td>LG</td> <td>-</td> <td>16</td> <td>LG</td> <td>STRG SW B</td> </tr> <tr> <td>17</td> <td>SG</td> <td>-</td> <td>17</td> <td>SG</td> <td>GND</td> </tr> <tr> <td>18</td> <td>G</td> <td>-</td> <td>18</td> <td>G</td> <td>BATTERY</td> </tr> <tr> <td>19</td> <td>Y</td> <td>-</td> <td>19</td> <td>Y</td> <td>BATTERY</td> </tr> <tr> <td>20</td> <td>B</td> <td>-</td> <td>20</td> <td>B</td> <td>GND</td> </tr> </tbody> </table>	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	1	LG	-	1	BR	SOUND SIGNAL FRONT LH (+)	2	GR	-	2	L	SOUND SIGNAL FRONT LH (-)	3	R	-	3	W	SOUND SIGNAL REAR LH (+)	4	W	-	4	LG	SOUND SIGNAL REAR LH (-)	5	W	-	5	SG	SOUND SIGNAL REAR RH (+)	6	B	-	6	P	SOUND SIGNAL REAR RH (-)	7	B	-	7	V	ILLUMINATION	8	R	-	8	ACC	-	9	W	-	9	LG	SOUND SIGNAL FRONT RH (+)	10	W	-	10	R	SOUND SIGNAL FRONT RH (-)	11	GR	-	11	L	SOUND SIGNAL REAR RH (+)	12	GR	-	12	W	SOUND SIGNAL REAR RH (-)	13	Y	-	13	P	SOUND SIGNAL REAR RH (+)	14	Y	-	14	B	SOUND SIGNAL REAR RH (-)	15	SG	-	15	SG	STRG SW A	16	LG	-	16	LG	STRG SW B	17	SG	-	17	SG	GND	18	G	-	18	G	BATTERY	19	Y	-	19	Y	BATTERY	20	B	-	20	B	GND																															
Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]																																																																																																																																																																																																				
1	SB	-	1	LG	-																																																																																																																																																																																																				
2	GR	-	2	SG	-																																																																																																																																																																																																				
3	R	-	3	W	-																																																																																																																																																																																																				
4	B	-	4	R	-																																																																																																																																																																																																				
5	G	-	5	W	-																																																																																																																																																																																																				
6	B	-	6	B	-																																																																																																																																																																																																				
Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]																																																																																																																																																																																																				
1	LG	-	1	BR	SOUND SIGNAL FRONT LH (+)																																																																																																																																																																																																				
2	GR	-	2	L	SOUND SIGNAL FRONT LH (-)																																																																																																																																																																																																				
3	R	-	3	W	SOUND SIGNAL REAR LH (+)																																																																																																																																																																																																				
4	W	-	4	LG	SOUND SIGNAL REAR LH (-)																																																																																																																																																																																																				
5	W	-	5	SG	SOUND SIGNAL REAR RH (+)																																																																																																																																																																																																				
6	B	-	6	P	SOUND SIGNAL REAR RH (-)																																																																																																																																																																																																				
7	B	-	7	V	ILLUMINATION																																																																																																																																																																																																				
8	R	-	8	ACC	-																																																																																																																																																																																																				
9	W	-	9	LG	SOUND SIGNAL FRONT RH (+)																																																																																																																																																																																																				
10	W	-	10	R	SOUND SIGNAL FRONT RH (-)																																																																																																																																																																																																				
11	GR	-	11	L	SOUND SIGNAL REAR RH (+)																																																																																																																																																																																																				
12	GR	-	12	W	SOUND SIGNAL REAR RH (-)																																																																																																																																																																																																				
13	Y	-	13	P	SOUND SIGNAL REAR RH (+)																																																																																																																																																																																																				
14	Y	-	14	B	SOUND SIGNAL REAR RH (-)																																																																																																																																																																																																				
15	SG	-	15	SG	STRG SW A																																																																																																																																																																																																				
16	LG	-	16	LG	STRG SW B																																																																																																																																																																																																				
17	SG	-	17	SG	GND																																																																																																																																																																																																				
18	G	-	18	G	BATTERY																																																																																																																																																																																																				
19	Y	-	19	Y	BATTERY																																																																																																																																																																																																				
20	B	-	20	B	GND																																																																																																																																																																																																				

JCLWM5994GB

ILLUMINATION

< DTC/CIRCUIT DIAGNOSIS >

ILLUMINATION

Connector No.		Signal Name [Specification]		Terminal No.		Color of Wire		Signal Name [Specification]		Terminal No.		Color of Wire		Signal Name [Specification]		
Connector No.	M202	71	SHIELD	17	SHIELD	-	-	18	B	6	SHIELD	-	-	19	Y	
Connector Name	AV CONTROL UNIT	72	G	18	G	-	-	20	R	R	GND	-	-	21	G	
Connector Type	TH24FW-NH	73	P	19	P	-	-	22	G	G	PARKING BRAKE	-	-	23	Y	
		74	P	20	P	-	-	24	R	R	COMPOSITE IMAGE GND	-	-	25	R	
		75	G	21	G	-	-	26	G	G	COMPOSITE IMAGE SIGNAL	-	-	27	G	
		76	G	28	G	-	-	28	G	G	INVERTER VCC	-	-	29	G	
		77	G	29	G	-	-	30	R	R	INVERTER GND	-	-	31	R	
		78	G	30	G	-	-	32	R	R	RGB (R/RED) SIGNAL	-	-	33	R	
		79	L	31	L	-	-	34	R	R	RGB (G/GREEN) SIGNAL	-	-	35	R	
		80	G	32	G	-	-	36	R	R	RGB (B/BLUE) SIGNAL	-	-	37	R	
		81	G	33	G	-	-	38	R	R	COMPOSITE IMAGE GND	-	-	39	R	
		82	R	34	R	-	-	40	R	R	RGB AREA Y(S) SIGNAL	-	-	41	R	
		83	SHIELD	35	SHIELD	-	-	42	W	W	RGB SYNC	-	-	43	W	
		87	R	36	R	-	-	44	Y	Y	RGB (R/RED) SIGNAL	-	-	45	Y	
		88	SHIELD	37	SHIELD	-	-	46	Y	Y	RGB (G/GREEN) SIGNAL	-	-	47	Y	
		89	L	38	L	-	-	48	Y	Y	RGB (B/BLUE) SIGNAL	-	-	49	Y	
		90	L	39	L	-	-	50	G	G	COMPOSITE IMAGE SIGNAL	-	-	51	G	
		91	S	40	S	-	-	52	P	P	INVERTER VCC	-	-	53	P	
		92	S	41	S	-	-	54	P	P	INVERTER GND	-	-	55	P	
				42	43	44	45	46	47	48	49	50	51	52		
				53	54	55	56	57	58	59	60	61	62	63		
				64	65	66	67	68	69	70	71	72	73	74	75	
				76	77	78	79	80	81	82	83	84	85	86	87	88
				89	90	91	92	93	94	95	96	97	98	99	90	91
				96	97	98	99	90	91	92	93	94	95	96	97	98
				99	90	91	92	93	94	95	96	97	98	99	90	91

JCLWM5995GB

ILLUMINATION

< DTC/CIRCUIT DIAGNOSIS >

A

B

C

D

E

F

G

H

I

J

K

INL

M


N

O

P

ILLUMINATION

Connector No.	R11
Connector Name	WIRE TO WIRE
Connector Type	TH12MW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	B	-
3	SHIELD	-
4	R	-
5	G	-
6	B	-
7	P	-
8	GR	-
9	V	-
11	Y	-
12	R	-

Connector No.	R15
Connector Name	MAP LAMP
Connector Type	TK05FGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	V	-
3	B	-
4	-	-
5	B	-
6	Y	-

JCLWM5996GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION

BCM (BODY CONTROL MODULE)

Reference Value

INFOID:0000000006857883

VALUES ON THE DIAGNOSIS TOOL

CONSULT-III MONITOR ITEM

Monitor Item	Condition	Value/Status
FR WIPER HI	Other than front wiper switch HI	Off
	Front wiper switch HI	On
FR WIPER LOW	Other than front wiper switch LO	Off
	Front wiper switch LO	On
FR WASHER SW	Front washer switch OFF	Off
	Front washer switch ON	On
FR WIPER INT	Other than front wiper switch INT/AUTO	Off
	Front wiper switch INT/AUTO	On
FR WIPER STOP	Front wiper is not in STOP position	Off
	Front wiper is in STOP position	On
INT VOLUME	Wiper volume dial is in a dial position 1 - 7	Wiper volume dial position
TURN SIGNAL R	Other than turn signal switch RH	Off
	Turn signal switch RH	On
TURN SIGNAL L	Other than turn signal switch LH	Off
	Turn signal switch LH	On
TAIL LAMP SW	Other than lighting switch 1ST and 2ND	Off
	Lighting switch 1ST or 2ND	On
HI BEAM SW	Other than lighting switch HI	Off
	Lighting switch HI	On
HEAD LAMP SW 1	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
HEAD LAMP SW 2	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
PASSING SW	Other than lighting switch PASS	Off
	Lighting switch PASS	On
AUTO LIGHT SW	Other than lighting switch AUTO	Off
	Lighting switch AUTO	On
FR FOG SW	Front fog lamp switch OFF	Off
	Front fog lamp switch ON	On
RR FOG SW	NOTE: The item is indicated, but not monitored.	Off
DOOR SW-DR	Driver door closed	Off
	Driver door opened	On
DOOR SW-AS	Passenger door closed	Off
	Passenger door opened	On
DOOR SW-RR	Rear RH door closed	Off
	Rear LH door opened	On

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
DOOR SW-RL	Rear LH door closed	Off
	Rear LH door opened	On
DOOR SW-BK	NOTE: The item is indicated, but not monitored.	Off
CDL LOCK SW	Other than power door lock switch LOCK	Off
	Power door lock switch LOCK	On
CDL UNLOCK SW	Other than power door lock switch UNLOCK	Off
	Power door lock switch UNLOCK	On
KEY CYL LK-SW	Other than driver door key cylinder LOCK	Off
	Driver door key cylinder LOCK	On
KEY CYL UN-SW	Other than driver door key cylinder UNLOCK	Off
	Driver door key cylinder LOCK	On
KEY CYL SW-TR	NOTE: The item is indicated, but not monitored.	Off
HAZARD SW	Hazard switch is OFF	Off
	Hazard switch is ON	On
REAR DEF SW	NOTE: The item is indicated, but not monitored.	Off
H/L WASH SW	NOTE: The item is indicated, but not monitored.	Off
TR CANCEL SW	Trunk lid opener cancel switch OFF	Off
	Trunk lid opener cancel switch ON	On
TR/BD OPEN SW	Trunk lid opener switch OFF	Off
	While the trunk lid opener switch is turned ON	On
TRNK/HAT MNTR	Trunk lid closed	Off
	Trunk lid opened	On
RKE-LOCK	LOCK button of the Intelligent Key is not pressed	Off
	LOCK button of the Intelligent Key is pressed	On
RKE-UNLOCK	UNLOCK button of the Intelligent Key is not pressed	Off
	UNLOCK button of the Intelligent Key is pressed	On
RKE-TR/BD	TRUNK OPEN button of the Intelligent Key is not pressed	Off
	TRUNK OPEN button of the Intelligent Key is pressed	On
RKE-PANIC	PANIC button of the Intelligent Key is not pressed	Off
	PANIC button of the Intelligent Key is pressed	On
RKE-P/W OPEN	UNLOCK button of the Intelligent Key is not pressed	Off
	UNLOCK button of the Intelligent Key is pressed and held	On
RKE-MODE CHG	LOCK/UNLOCK button of the Intelligent Key is not pressed and held simultaneously	Off
	LOCK/UNLOCK button of the Intelligent Key is pressed and held simultaneously	On
OPTICAL SENSOR	Bright outside of the vehicle	Close to 5 V
	Dark outside of the vehicle	Close to 0 V
REQ SW -DR	Driver door request switch is not pressed	Off
	Driver door request switch is pressed	On
REQ SW -AS	Passenger door request switch is not pressed	Off
	Passenger door request switch is pressed	On

A
 B
 C
 D
 E
 F
 G
 H
 I
 J
 K
 INL
 M
 N
 O
 P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
REQ SW -RR	NOTE: The item is indicated, but not monitored.	Off
REQ SW -RL	NOTE: The item is indicated, but not monitored.	Off
REQ SW -BD/TR	Trunk lid opener request switch is not pressed	Off
	Trunk lid opener request switch is pressed	On
PUSH SW	Push-button ignition switch (push switch) is not pressed	Off
	Push-button ignition switch (push switch) is pressed	On
IGN RLY2 -F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
ACC RLY -F/B	NOTE: The item is indicated, but not monitored.	Off
CLUCH SW	The clutch pedal is not depressed	Off
	The clutch pedal is depressed	On
BRAKE SW 1	The brake pedal is depressed when No. 7 fuse is blown	Off
	The brake pedal is not depressed when No. 7 fuse is blown, or No. 7 fuse is normal	On
BRAKE SW 2	The brake pedal is not depressed	Off
	The brake pedal is depressed	On
DETE/CANCL SW	<ul style="list-style-type: none"> • Selector lever in P position (Except M/T models) • The clutch pedal is depressed (M/T models) 	Off
	<ul style="list-style-type: none"> • Selector lever in any position other than P (Except M/T models) • The clutch pedal is not depressed (M/T models) 	On
SFT PN/N SW	Selector lever in any position other than P and N	Off
	Selector lever in P or N position	On
S/L -LOCK	Steering is unlocked	Off
	Steering is locked	On
S/L -UNLOCK	Steering is locked	Off
	Steering is unlocked	On
S/L RELAY-F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
UNLK SEN -DR	Driver door is unlocked	Off
	Driver door is locked	On
PUSH SW -IPDM	Push-button ignition switch (push-switch) is not pressed	Off
	Push-button ignition switch (push-switch) is pressed	On
IGN RLY1 -F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
DETE SW -IPDM	Selector lever in any position other than P	Off
	Selector lever in P position	On
SFT PN -IPDM	<ul style="list-style-type: none"> • Selector lever in any position other than P and N (Except M/T models) • The clutch pedal is not depressed (M/T models) 	Off
	<ul style="list-style-type: none"> • Selector lever in P or N position (Except M/T models) • The clutch pedal is depressed (M/T models) 	On
SFT P -MET	Selector lever in any position other than P	Off
	Selector lever in P position	On
SFT N -MET	Selector lever in any position other than N	Off
	Selector lever in N position	On

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
ENGINE STATE	Engine stopped	Stop
	While the engine stalls	Stall
	At engine cranking	Crank
	Engine running	Run
S/L LOCK-IPDM	Steering is unlocked	Off
	Steering is locked	On
S/L UNLK-IPDM	Steering is locked	Off
	Steering is unlocked	On
S/L RELAY-REQ	Steering lock system is not the LOCK condition and the changing condition from LOCK to UNLOCK	Off
	Steering lock system is the LOCK condition or the changing condition from LOCK to UNLOCK	On
VEH SPEED 1	While driving	Equivalent to speed-ometer reading
VEH SPEED 2	While driving	Equivalent to speed-ometer reading
DOOR STAT-DR	Driver door is locked	LOCK
	Wait with selective UNLOCK operation (60 seconds)	READY
	Driver door is unlocked	UNLOCK
DOOR STAT-AS	Passenger door is locked	LOCK
	Wait with selective UNLOCK operation (60 seconds)	READY
	Passenger door is unlocked	UNLOCK
ID OK FLAG	Steering is locked	Reset
	Steering is unlocked	Set
PRMT ENG STRT	The engine start is prohibited	Reset
	The engine start is permitted	Set
PRMT RKE STRT	NOTE: The item is indicated, but not monitored.	Reset
KEY SW -SLOT	The Intelligent Key is not inserted into key slot	Off
	The Intelligent Key is inserted into key slot	On
RKE OPE COUN1	During the operation of the Intelligent Key	Operation frequency of the Intelligent Key
RKE OPE COUN2	NOTE: The item is indicated, but not monitored.	—
CONFIRM ID ALL	The key ID that the key slot receives is not recognized by any key ID registered to BCM.	Yet
	The key ID that the key slot receives is recognized by any key ID registered to BCM.	Done
CONFIRM ID4	The key ID that the key slot receives is not recognized by the fourth key ID registered to BCM.	Yet
	The key ID that the key slot receives is recognized by the fourth key ID registered to BCM.	Done
CONFIRM ID3	The key ID that the key slot receives is not recognized by the third key ID registered to BCM.	Yet
	The key ID that the key slot receives is recognized by the third key ID registered to BCM.	Done

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
INL

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
CONFIRM ID2	The key ID that the key slot receives is not recognized by the second key ID registered to BCM.	Yet
	The key ID that the key slot receives is recognized by the second key ID registered to BCM.	Done
CONFIRM ID1	The key ID that the key slot receives is not recognized by the first key ID registered to BCM.	Yet
	The key ID that the key slot receives is recognized by the first key ID registered to BCM.	Done
TP 4	The ID of fourth Intelligent Key is not registered to BCM	Yet
	The ID of fourth Intelligent Key is registered to BCM	Done
TP 3	The ID of third Intelligent Key is not registered to BCM	Yet
	The ID of third Intelligent Key is registered to BCM	Done
TP 2	The ID of second Intelligent Key is not registered to BCM	Yet
	The ID of second Intelligent Key is registered to BCM	Done
TP 1	The ID of first Intelligent Key is not registered to BCM	Yet
	The ID of first Intelligent Key is registered to BCM	Done
AIR PRESS FL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front LH tire
AIR PRESS FR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front RH tire
AIR PRESS RR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear RH tire
AIR PRESS RL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear LH tire
ID REGST FL1	ID of front LH tire transmitter is registered	Done
	ID of front LH tire transmitter is not registered	Yet
ID REGST FR1	ID of front RH tire transmitter is registered	Done
	ID of front RH tire transmitter is not registered	Yet
ID REGST RR1	ID of rear RH tire transmitter is registered	Done
	ID of rear RH tire transmitter is not registered	Yet
ID REGST RL1	ID of rear LH tire transmitter is registered	Done
	ID of rear LH tire transmitter is not registered	Yet
WARNING LAMP	Tire pressure indicator OFF	Off
	Tire pressure indicator ON	On
BUZZER	Tire pressure warning alarm is not sounding	Off
	Tire pressure warning alarm is sounding	On

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

TERMINAL LAYOUT



PHYSICAL VALUES


A
B
C
D
E
F
G
H
I
J
K
L
INL
M
N
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
		Signal name	Input/ Output		
+	-				
1 (W)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
2 (Y)	Ground	P/W power supply (BAT)	Output	Ignition switch OFF	12 V
3 (BG)	Ground	P/W power supply (RAP)	Output	Ignition switch ON	12 V
4 (LG)	Ground	Interior room lamp power supply	Output	Interior room lamp battery saver is activated. (Cuts the interior room lamp power supply)	0 V
				Interior room lamp battery saver is not activated. (Outputs the interior room lamp power supply)	12 V
5 (P)	Ground	Passenger door UN- LOCK	Output	Passenger door	UNLOCK (Actuator is acti- vated)
					Other than UNLOCK) Ac- tuator is not activated
7 (SB)	Ground	Step lamp	Output	Step lamp	ON
					OFF
8 (V)	Ground	All doors, fuel lid LOCK	Output	All doors, fuel lid	LOCK (Actuator is activated)
					Other than LOCK (Actuator is not activated)
9 (G)	Ground	Driver door, fuel lid UNLOCK	Output	Driver door, fuel lid	UNLOCK (Actuator is activated)
					Other than UNLOCK (Actuator is not activated)
10 (P)	Ground	Rear RH door and rear LH door UN- LOCK	Output	Rear RH door and rear LH door	UNLOCK (Actuator is activated)
					Other than UNLOCK (Actuator is not activated)
11 (R)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
13 (B)	Ground	Ground	—	Ignition switch ON	0 V
14 (W)	Ground	Push-button ignition switch illumination ground	Output	Tail lamp	OFF
					ON
15 (BG)	Ground	ACC indicator lamp	Output	Ignition switch	OFF (LOCK indicator is not illuminated)
					ACC





NOTE:
When the illumination brighten-
ing/dimming level is in the neutral
position



JSNIA0010GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
17 (W)	Ground	Turn signal RH (Front)	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch RH	 PKID0926E 6.5 V
18 (BG)	Ground	Turn signal LH (Front)	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch LH	 PKID0926E 6.5 V
19 (V)	Ground	Room lamp timer control	Output	Interior room lamp	OFF	12 V
					ON	0 V
20 (V)	Ground	Turn signal RH (Rear)	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch RH	 PKID0926E 6.5 V
23 (LG)	Ground	Trunk lid open	Output	Trunk lid	OPEN (Trunk lid opener actuator is activated)	12 V
					Other than OPEN (Trunk lid opener actuator is not activated)	0 V
25 (Y)	Ground	Turn signal LH (Rear)	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch LH	 PKID0926E 6.5 V
30 (P)	Ground	Trunk room lamp	Output	Trunk room lamp	ON	0 V
					OFF	12 V

A

B

C

D

E

F

G

H

I

J

K

INL

M

N


O

P


BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
34 (SB)	Ground	Trunk room antenna (-)	Output	<p>When Intelligent Key is in the passenger compartment</p> <p>When Ignition switch OFF</p>
35 (V)	Ground	Trunk room antenna (+)	Output	<p>When Intelligent Key is in the passenger compartment</p> <p>When Ignition switch OFF</p>
38 (B)	Ground	Rear bumper antenna (-)	Output	<p>When Intelligent Key is in the antenna detection area</p> <p>When the trunk lid opener request switch is operated with ignition switch OFF</p>




JMKIA0062GB




JMKIA0063GB




JMKIA0062GB



JMKIA0063GB



JMKIA0062GB




JMKIA0063GB


BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
39 (W)	Ground	Rear bumper antenna (+)	Output	When Intelligent Key is in the antenna detection area
				When the trunk lid opener request switch is operated with ignition switch OFF
47 (Y)	Ground	Ignition relay (IPDM E/R) control	Output	OFF or ACC
				ON
50 (BG)	Ground	Trunk room lamp switch	Input	OFF (Trunk lid is closed)
				ON (Trunk lid is opened)
52 (R)	Ground	Starter relay control	Ignition switch ON (A/T models)	When selector lever is in P or N position
				When selector lever is not in P or N position
			Ignition switch ON (M/T models)	When the clutch pedal is depressed
				When the clutch pedal is not depressed
61 (SB)	Ground	Trunk lid opener request switch	Input	ON (Pressed)
				OFF (Not pressed)
64 (G)	Ground	Intelligent Key warning buzzer (Engine room)	Output	Sounding
				Not sounding




JMKIA0062GB



JMKIA0063GB



JPMIA0011GB



JPMIA0016GB

1.0 V

A

B

C

D

E

F

G

H

I

J

K

INL

M

N


O

P

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
67 (GR)	Ground	Trunk lid opener switch	Input	Pressed Trunk lid opener switch Not pressed
68 (BG)	Ground	Rear RH door switch	Input	OFF (When rear RH door closes) Rear RH door switch
				ON (When rear RH door opens)
69 (L)	Ground	Rear LH door switch	Input	OFF (When rear LH door closes) Rear LH door switch
				ON (When rear LH door opens)
72 (R)	Ground	Room antenna 2 (-) (Center console)	Output	When Intelligent Key is in the passenger compartment Ignition switch OFF
				When Intelligent Key is not in the passenger compartment




JPMIA0011GB

11.8 V




JPMIA0011GB

11.8 V




JPMIA0011GB

11.8 V







JMKIA0062GB



JMKIA0063GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
73 (G)	Ground	Room antenna 2 (+) (Center console)	Output Ignition switch OFF	When Intelligent Key is in the passenger compart- ment
				 (V) 15 10 5 0 1 s JMKA0062GB
74 (SB)	Ground	Passenger door an- tenna (-)	Output When the pas- senger door re- quest switch is operated with ignition switch OFF	When Intelligent Key is not in the passenger compart- ment
				 (V) 15 10 5 0 1 s JMKA0063GB
75 (BR)	Ground	Passenger door an- tenna (+)	Output When the pas- senger door re- quest switch is operated with ignition switch OFF	When Intelligent Key is in the antenna detection area
				 (V) 15 10 5 0 1 s JMKA0062GB
				When Intelligent Key is not in the antenna detection area
				 (V) 15 10 5 0 1 s JMKA0063GB

A

B

C

D

E

F

G

H

I

J

K

INL

M

N


O

P


BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


Terminal No. (Wire color)	Description		Condition	Value (Approx.)			
	Signal name	Input/ Output					
+	-						
76 (V)	Ground	Driver door antenna (-)	Output	When Intelligent Key is in the antenna detection area			
				When the driver door request switch is operated with ignition switch OFF			
77 (LG)	Ground	Driver door antenna (+)	Output	When Intelligent Key is in the antenna detection area			
				When the driver door request switch is operated with ignition switch OFF			
78 (Y)	Ground	Room antenna 1 (-) (Instrument panel)	Output	When Intelligent Key is in the passenger compartment			
				Ignition switch OFF			




JMKIA0062GB




JMKIA0063GB




JMKIA0062GB



JMKIA0063GB








JMKIA0062GB



JMKIA0063GB


BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	
	Signal name	Input/ Output			
+	-				
79 (BR)	Ground	Room antenna 1 (+) (Instrument panel)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compart- ment
					 (V) 15 10 5 0 1 s JKMKIA0062GB
80 (GR)	Ground	NATS antenna amp.	Input/ Output	During waiting	Ignition switch is pressed while inserting the Intelli- gent Key into the key slot.
					 (V) 15 10 5 0 1 s JKMKIA0063GB
81 (W)	Ground	NATS antenna amp.	Input/ Output	During waiting	Ignition switch is pressed while inserting the Intelli- gent Key into the key slot.
					 (V) 15 10 5 0 1 s JKMKIA0063GB
82 (SB)	Ground	Ignition relay [Fuse block (J/B)] control	Output	Ignition switch	OFF or ACC
					0 V
83 (Y)	Ground	Remote keyless entry receiver communica- tion	Input/ Output	During waiting	ON
					 (V) 15 10 5 0 1 ms JKMKIA0064GB
				When operating either button on the Intelli- gent Key	 (V) 15 10 5 0 1 ms JKMKIA0065GB






BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
87 (Y)	Ground	Combination switch INPUT 5	Input	<p>All switches OFF (Wiper volume dial 4)</p>  <p>JPMIA0041GB</p> <p>1.4 V</p>
				<p>Front fog lamp switch ON (Wiper volume dial 4)</p>  <p>JPMIA0037GB</p> <p>1.3 V</p>
				<p>Any of the conditions below with all switches OFF</p> <ul style="list-style-type: none"> • Wiper volume dial 1 • Wiper volume dial 2 • Wiper volume dial 6 • Wiper volume dial 7  <p>JPMIA0040GB</p> <p>1.3 V</p>



BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	
	Signal name	Input/ Output			
+	-				
88 (BG)	Ground	Combination switch INPUT 3	Input	Combination switch	All switches OFF (Wiper volume dial 4)
					 1.4 V JPMIA0041GB
					 1.3 V JPMIA0036GB
					 1.3 V JPMIA0037GB
89 (BR)	Ground	Push-button ignition switch (Push switch)	Input	Push-button ig- nation switch (push switch)	Pressed
					Battery voltage
90 (P)	Ground	CAN-L	Input/ Output		—
91 (L)	Ground	CAN-H	Input/ Output		—
92 (LG)	Ground	Key slot illumination	Output	Key slot illumin- ation	OFF
					 0 V
					 6.5 V 12 V JPMIA0015GB






BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	+	-		
93 (GR)	Ground	ON indicator lamp	Output Ignition switch	OFF (LOCK indicator is not illuminated)
				ON
95 (BG)	Ground	ACC relay control	Output Ignition switch	OFF
				ACC or ON
96 (GR)	Ground	A/T shift selector (Detention switch) power supply	Output	—
97 (L)	Ground	Steering lock condition No. 1	Input Steering lock	LOCK status
				UNLOCK status
98 (P)	Ground	Steering lock condition No. 2	Input Steering lock	LOCK status
				UNLOCK status
99 (R) ^{*1} (BR) ^{*2}	Ground	Selector lever P position switch (A/T models)	Input Selector lever	P position
				Any position other than P
		ASCD clutch switch (M/T models without ICC)	ASCD clutch switch	OFF (Clutch pedal is depressed)
				ON (Clutch pedal is not depressed)
		ICC clutch switch (M/T models with ICC)	ICC clutch switch	OFF (Clutch pedal is depressed)
				ON (Clutch pedal is not depressed)
100 (Y)	Ground	Passenger door request switch	Input Passenger door request switch	ON (Pressed)
				OFF (Not pressed)
				 JPMIA0016GB 1.0 V
101 (P)	Ground	Driver door request switch	Input Driver door request switch	ON (Pressed)
				OFF (Not pressed)
				 JPMIA0016GB 1.0 V
102 (BG)	Ground	Blower fan motor relay control	Output Ignition switch	OFF or ACC
				ON
103 (P)	Ground	Remote keyless entry receiver power supply	Output	Ignition switch OFF
106 (SB)	Ground	Steering lock unit power supply	Output Ignition switch	OFF or ACC
				ON
				12 V
				12 V
				0 V

BCM (BODY CONTROL MODULE)




< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	
	Signal name	Input/ Output			
+	-				
107 (LG)	Ground	Combination switch INPUT 1	Combination switch (Wiper volume dial 4)	All switches OFF	 JPMIA0041GB 1.4 V
				Turn signal switch LH	 JPMIA0037GB 1.3 V
				Turn signal switch RH	 JPMIA0036GB 1.3 V
				Front wiper switch LO	 JPMIA0038GB 1.3 V
				Front washer switch ON	 JPMIA0039GB 1.3 V

A
 B
 C
 D
 E
 F
 G
 H
 I
 J
 K
 INL
 M
 N
 O
 P






BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
108 (R)	Ground	Combination switch INPUT 4	Input	 All switches OFF (Wiper volume dial 4)  Lighting switch AUTO (Wiper volume dial 4)  Lighting switch 1ST (Wiper volume dial 4)  Any of the conditions below with all switches OFF <ul style="list-style-type: none"> • Wiper volume dial 1 • Wiper volume dial 5 • Wiper volume dial 6
				JPMIA0041GB 1.4 V
				JPMIA0038GB 1.3 V
				JPMIA0036GB 1.3 V
				JPMIA0039GB 1.3 V




BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	
	Signal name	Input/ Output			
+	-				
109 (W)	Ground	Combination switch INPUT 2	Input Combination switch (Wiper volume dial 4)	All switches OFF	 JPMIA0041GB 1.4 V
				Lighting switch PASS	 JPMIA0037GB 1.3 V
				Lighting switch 2ND	 JPMIA0036GB 1.3 V
				Front wiper switch INT/ AUTO	 JPMIA0038GB 1.3 V
				Front wiper switch HI	 JPMIA0040GB 1.3 V
110 (G)	Ground	Hazard switch	Input Hazard switch	ON	0 V
				OFF	 JPMIA0012GB 1.1 V


BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)	
+	-	Signal name	Input/ Output				
111 (Y)	Ground	Steering lock unit communication	Input/ Output	Steering lock	LOCK status	12 V	
					LOCK or UNLOCK	 (V) 15 10 5 0 50 ms <small>JMKIA0066GB</small>	
					For 15 seconds after UN-LOCK	12 V	
					15 seconds or later after UNLOCK	0 V	
112 (R)	Ground	Light and rain sensor serial link	Input/ Output	Ignition switch ON		 (V) 15 10 5 0 10ms <small>JPMIA0156GB</small> 8.7 V	
113 (BG)	Ground	Optical sensor	Input	Ignition switch ON	When bright outside of the vehicle	Close to 5 V	
					When dark outside of the vehicle	Close to 0 V	
114 (R)	Ground	Clutch interlock switch	Input	Clutch interlock switch	OFF (Clutch pedal is not depressed)	0 V	
					ON (Clutch pedal is depressed)	Battery voltage	
116 (SB)	Ground	Stop lamp switch 1	Input	—		Battery voltage	
118 (BR)	Ground	Stop lamp switch 2 (Without ICC)	Input	Stop lamp switch	OFF (Brake pedal is not depressed)	0 V	
					ON (Brake pedal is depressed)	Battery voltage	
		Stop lamp switch 2 (With ICC)		Stop lamp switch OFF (Brake pedal is not depressed) and ICC brake hold relay OFF		0 V	
				Stop lamp switch ON (Brake pedal is depressed) or ICC brake hold relay ON		Battery voltage	
119 (SB)	Ground	Front door lock assembly driver side (Unlock sensor)	Input	Driver door	LOCK status (Unlock sensor switch OFF)	 (V) 15 10 5 0 10 ms <small>JPMIA0012GB</small> 1.1 V	
					UNLOCK status (Unlock switch sensor ON)	0 V	

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
121 (SB)	Ground	Key slot switch	Input	When the Intelligent Key is inserted into key slot
				12 V
123 (V)	Ground	IGN feedback	Input	When the Intelligent Key is not inserted into key slot
				0 V
124 (R)	Ground	Passenger door switch	Input	OFF or ACC
				0 V
				ON
				Battery voltage
129 (BG)	Ground	Trunk lid opener cancel switch	Input	Passenger door switch
				OFF (Door close)
				ON (Door open)
				0 V
132 (V)	Ground	Power window switch communication	Input/ Output	Trunk lid opener cancel switch
				CANCEL
				ON
				0 V
133 (L)	Ground	Push-button ignition switch illumination	Output	Ignition switch ON
				Ignition switch OFF or ACC
				ON (Tail lamps OFF)
				9.5 V
134 (LG)	Ground	LOCK indicator lamp	Output	ON (Tail lamps ON)
				NOTE: The pulse width of this wave is varied by the illumination brightening/dimming level.
				 JPMIA0159GB
137 (BG)	Ground	Receiver and sensor ground	Input	OFF
				0 V
				ON
				Battery voltage
				0 V
				0 V

A

B

C

D

E

F

G

H

I

J

K

INL

M




N

O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


Terminal No. (Wire color)	Description		Condition	Value (Approx.)	
	+	-			
138 (V)	Ground	Receiver and sensor power supply	Output	Ignition switch OFF ACC or ON	0 V
					5.0 V
139 (L)	Ground	Tire pressure receiver communication	Input/ Output	Ignition switch ON	Standby state
					 OCC3881D
140 (B)	Ground	Selector lever P/N position	Input	Selector lever	P or N position
					Except P and N positions
141 (W)	Ground	Security indicator	Output	Security indicator	ON
					 11.3 V
					OFF
142 (BR)	Ground	Combination switch OUTPUT 5	Output	Combination switch (Wiper volume dial 4)	All switches OFF
					 10.7 V
					Lighting switch 1ST
					Lighting switch HI
					Lighting switch 2ND
143 (P)	Ground	Combination switch OUTPUT 1	Output	Combination switch	Turn signal switch RH
					 10.7 V
					All switches OFF (Wiper volume dial 4)
					Front wiper switch HI (Wiper volume dial 4)
					Any of the conditions below with all switches OFF
					<ul style="list-style-type: none"> • Wiper volume dial 1 • Wiper volume dial 2 • Wiper volume dial 3 • Wiper volume dial 6 • Wiper volume dial 7

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	
	Signal name	Input/ Output			
+	-				
144 (G)	Ground	Combination switch OUTPUT 2	Output	Combination switch	All switches OFF (Wiper volume dial 4)
					Front washer switch ON (Wiper volume dial 4)
					Any of the conditions be- low with all switches OFF • Wiper volume dial 1 • Wiper volume dial 5 • Wiper volume dial 6
145 (L)	Ground	Combination switch OUTPUT 3	Output	Combination switch (Wiper volume dial 4)	All switches OFF
					Front wiper switch INT/ AUTO
					Front wiper switch LO
					Lighting switch AUTO
146 (SB)	Ground	Combination switch OUTPUT 4	Output	Combination switch (Wiper volume dial 4)	All switches OFF
					Front fog lamp switch ON
					Lighting switch 2ND
					Lighting switch PASS
					Turn signal switch LH
150 (GR)	Ground	Driver door switch	Input	Driver door switch	OFF (Door close)
					ON (Door open)
151 (G)	Ground	Rear window defog- ger relay control	Output	Rear window defogger	Active
					Not activated

- *1: A/T models
- *2: M/T models




JPMIA0033GB

10.7 V




JPMIA0034GB

10.7 V



JPMIA0035GB

10.7 V



JPMIA0011GB

11.8 V

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O


P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Wiring Diagram - BCM -

INFOID:0000000006857884




2010/08/18

JCMWM9738GB

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >



JCMWM9739GB

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >



JCMWM9740GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >




JCMW9741GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
INL

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >



JCMWM9742GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)		
Connector No.	Connector Name	Connector Type
M33	COMBINATION SWITCH	TH16FW-NH
M119	BCM (BODY CONTROL MODULE)	NS16FW-CS
M121	BCM (BODY CONTROL MODULE)	TH40FGY-NH
M122	BCM (BODY CONTROL MODULE)	TH40FB-NH
M120	BCM (BODY CONTROL MODULE)	NS12FW-CS
M113	BCM (BODY CONTROL MODULE)	MD37FB-LC

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	FR WASHER (-)	4	LG	INTERIOR ROOM AMP POWER SUPPLY
2	SB	OUTPUT 4	5	P	PASSENGER DOOR UNLOCK OUTPUT
5	L	OUTPUT 3	7	SB	STEP LAMP OUTPUT
6	B	GRND	8	V	ALL DOOR FUEL LID LOCK OUTPUT
7	BG	INPUT 3	9	G	DRIVER DOOR FUEL LID UNLOCK OUTPUT
8	BR	OUTPUT 5	10	P	REAR DOOR UNLOCK OUTPUT
9	W	INPUT 2	11	R	BAT (FUSE)
10	R	INPUT 4	13	B	GRND
11	LG	INPUT 1	14	V	PUSH-BUTTON IGNITION SW L/L GND
12	P	OUTPUT 1	15	BG	ACC IND
13	Y	INPUT 5	17	V	TURN SIGNAL RH (FRONT)
14	G	OUTPUT 2	18	BG	TURN SIGNAL LH (FRONT)
19	V	INT ROOM LAMP CONT	69	L	REAR LH DOOR SW

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
1	W	BAT (F/L)	20	V	TURN SIGNAL RH (REAR)
2	Y	POWER WINDOW POWER SUPPLY (BAT)	23	LG	TRUNK LID OPEN OUTPUT
3	BG	POWER WINDOW POWER SUPPLY (RAP)	25	Y	TURN SIGNAL LH (REAR)
30	P	TRUNK ROOM LAMP	30	P	TRUNK ROOM LAMP

JCMWM9743GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)		
Connector No.	M12/3	
Connector Name	BCM (BODY CONTROL MODULE)	
Connector Type	TH40FG-NH	
		
Terminal No.	Color of Wire	Signal Name [Specification]
112	R	RAIN SENSOR SERIAL LINK
113	BG	OPTICAL SENSOR
114	R	CLUTCH INTERLOCK SW
116	SB	STOP LAMP SW 1
118	BR	STOP LAMP SW 2
119	SB	DR DOOR UNLOCK SENSOR
121	SB	KEY SLOT SW
123	V	IGN F/B
124	R	PASSENGER DOOR SW
129	BG	TRUNK LD OPENER CANCEL SW
132	V	POWER WINDOW SW COMM
133	L	PUSH BUTTON IGNITION SW/L POWER
134	LG	LOCK IND
137	BG	RECEIVER / SENSOR GND
138	V	RECEIVER / SENSOR POWER SUPPLY
139	L	TIRE PRESSURE RECEIVER COMM
140	B	SHIFT N/P
141	W	SECURITY INDICATOR LAMP
142	BR	COMBI SW OUTPUT 5
143	P	COMBI SW OUTPUT 1
144	G	COMBI SW OUTPUT 2
145	L	COMBI SW OUTPUT 3
146	SB	COMBI SW OUTPUT 4
150	GR	DRIVER DOOR SW
151	G	REAR WINDOW DEFOGER RELAY CONT

JCMWM9744GB

INFOID:0000000006857885

Fail-safe

FAIL-SAFE CONTROL BY DTC

BCM performs fail-safe control when any DTC are detected.

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Display contents of CONSULT	Fail-safe	Cancellation
B2013: ID DISCORD BCM-S/L	Inhibit engine cranking	Erase DTC
B2014: CHAIN OF S/L-BCM	Inhibit engine cranking	Erase DTC
B2190: NATS ANTENNA AMP	Inhibit engine cranking	Erase DTC
B2191: DIFFERENCE OF KEY	Inhibit engine cranking	Erase DTC
B2192: ID DISCORD BCM-ECM	Inhibit engine cranking	Erase DTC
B2193: CHAIN OF BCM-ECM	Inhibit engine cranking	Erase DTC
B2195: ANTI-SCANNING	Inhibit engine cranking	Ignition switch ON → OFF
B2557: VEHICLE SPEED	Inhibit steering lock	When normal vehicle speed signals are received from ABS actuator and electric unit (control unit) for 500 ms
B2560: STARTER CONT RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> • Starter control relay signal • Starter relay status signal
B2601: SHIFT POSITION	Inhibit steering lock	500 ms after the following signal reception status becomes consistent <ul style="list-style-type: none"> • Selector lever P position switch signal • P range signal (CAN)
B2602: SHIFT POSITION	Inhibit steering lock	5 seconds after the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Ignition switch is in the ON position • Selector lever P position switch signal: Except P position (12 V) • Vehicle speed: 4 km/h (2.5 MPH) or more
B2603: SHIFT POSI STATUS	Inhibit steering lock	500 ms after the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Ignition switch is in the ON position • Selector lever P position switch signal: Except P position (12 V) • Selector lever P/N position signal: Except P and N positions (0 V)
B2604: PNP/CLUTCH SW	Inhibit steering lock	500 ms after any of the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Status 1 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Selector lever P/N position signal: P and N position (12 V) - P range signal or N range signal (CAN): ON • Status 2 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Selector lever P/N position signal: Except P and N positions (0 V) - P range signal and N range signal (CAN): OFF
B2605: PNP/CLUTCH SW	Inhibit steering lock	500 ms after any of the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Status 1 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Selector lever P/N position signal: Except P and N positions (0 V) - Interlock/PNP switch signal (CAN): OFF • Status 2 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Selector lever P/N position signal: P or N position (12 V) - PNP switch signal (CAN): ON
B2606: S/L RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> • Steering lock relay signal (Request signal) • Steering lock relay signal (Condition signal)
B2607: S/L RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status has becomes consistent <ul style="list-style-type: none"> • Steering lock relay signal (Request signal) • Steering lock relay signal (Condition signal)

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Display contents of CONSULT	Fail-safe	Cancellation
B2608: STARTER RELAY	Inhibit engine cranking	500 ms after the following signal communication status becomes consistent <ul style="list-style-type: none"> • Starter motor relay control signal • Starter relay status signal (CAN)
B2609: S/L STATUS	<ul style="list-style-type: none"> • Inhibit engine cranking • Inhibit steering lock 	When the following steering lock conditions agree <ul style="list-style-type: none"> • BCM steering lock control status • Steering lock condition No. 1 signal status • Steering lock condition No. 2 signal status
B260A: IGNITION RELAY	Inhibit engine cranking	500 ms after the following conditions are fulfilled <ul style="list-style-type: none"> • IGN relay (IPDM E/R) control signal: OFF (12 V) • Ignition ON signal (CAN to IPDM E/R): OFF (Request signal) • Ignition ON signal (CAN from IPDM E/R): OFF (Condition signal)
B260F: ENG STATE SIG LOST	Maintains the power supply position attained at the time of DTC detection	When any of the following conditions are fulfilled <ul style="list-style-type: none"> • Power position changes to ACC • Receives engine status signal (CAN)
B2612: S/L STATUS	<ul style="list-style-type: none"> • Inhibit engine cranking • Inhibit steering lock 	When any of the following conditions are fulfilled <ul style="list-style-type: none"> • Steering lock unit status signal (CAN) is received normally • The BCM steering lock control status matches the steering lock status recognized by the steering lock unit status signal (CAN from IPDM E/R)
B2617: BCM	Inhibit engine cranking	1 second after the starter motor relay control inside BCM becomes normal
B2618: BCM	Inhibit engine cranking	1 second after the ignition relay (IPDM E/R) control inside BCM becomes normal
B2619: BCM	Inhibit engine cranking	1 second after the steering lock unit power supply output control inside BCM becomes normal
B261E: VEHICLE TYPE	Inhibit engine cranking	BCM initialization
B26E8: CLUTCH SW	Inhibit engine cranking	When any of the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Status 1 <ul style="list-style-type: none"> - Clutch switch signal (CAN from ECM): ON - Clutch interlock switch signal: OFF (0 V) • Status 2 <ul style="list-style-type: none"> - Clutch switch signal (CAN from ECM): OFF - Clutch interlock switch signal: ON (Battery voltage)
B26E9: S/L STATUS	<ul style="list-style-type: none"> • Inhibit engine cranking • Inhibit steering lock 	When BCM transmits the LOCK request signal to steering lock unit, and receives LOCK response signal from steering lock unit, the following conditions are fulfilled <ul style="list-style-type: none"> • Steering condition No. 1 signal: LOCK (0 V) • Steering condition No. 2 signal: LOCK (12 V)

DTC Inspection Priority Chart

INFOID:0000000006857886

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	DTC
1	B2562: LOW VOLTAGE
2	<ul style="list-style-type: none"> • U1000: CAN COMM • U1010: CONTROL UNIT(CAN)
3	<ul style="list-style-type: none"> • B2190: NATS ANTENNA AMP • B2191: DIFFERENCE OF KEY • B2192: ID DISCORD BCM-ECM • B2193: CHAIN OF BCM-ECM • B2195: ANTI-SCANNING

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Priority	DTC
4	<ul style="list-style-type: none"> • B2013: ID DISCORD BCM-S/L • B2014: CHAIN OF S/L-BCM • B2553: IGNITION RELAY • B2555: STOP LAMP • B2556: PUSH-BTN IGN SW • B2557: VEHICLE SPEED • B2560: STARTER CONT RELAY • B2601: SHIFT POSITION • B2602: SHIFT POSITION • B2603: SHIFT POSI STATUS • B2604: PNP/CLUTCH SW • B2605: PNP/CLUTCH SW • B2606: S/L RELAY • B2607: S/L RELAY • B2608: STARTER RELAY • B2609: S/L STATUS • B260A: IGNITION RELAY • B260B: STEERING LOCK UNIT • B260C: STEERING LOCK UNIT • B260D: STEERING LOCK UNIT • B260F: ENG STATE SIG LOST • B2612: S/L STATUS • B2614: BCM • B2615: BCM • B2616: BCM • B2617: BCM • B2618: BCM • B2619: BCM • B261A: PUSH-BTN IGN SW • B261E: VEHICLE TYPE • B26E8: CLUTCH SW • B26E9: S/L STATUS • B26EA: KEY REGISTRATION • C1729: VHCL SPEED SIG ERR • U0415: VEHICLE SPEED
5	<ul style="list-style-type: none"> • C1704: LOW PRESSURE FL • C1705: LOW PRESSURE FR • C1706: LOW PRESSURE RR • C1707: LOW PRESSURE RL • C1708: [NO DATA] FL • C1709: [NO DATA] FR • C1710: [NO DATA] RR • C1711: [NO DATA] RL • C1716: [PRESSDATA ERR] FL • C1717: [PRESSDATA ERR] FR • C1718: [PRESSDATA ERR] RR • C1719: [PRESSDATA ERR] RL • C1734: CONTROL UNIT
6	<ul style="list-style-type: none"> • B2621: INSIDE ANTENNA • B2622: INSIDE ANTENNA • B2623: INSIDE ANTENNA

PTC Index

INFOID:0000000006857887

NOTE:-

The details of time display are as follows.

- CRNT: A malfunction is detected now.
 - PAST: A malfunction was detected in the past.

IGN counter is displayed on Freeze Frame Data. For details of Freeze Frame Data, refer to [BCS-15. "COMMON ITEM : CONSULT-III Function \(BCM - COMMON ITEM\)"](#)

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle condition	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Refer- ence page
No DTC is detected. further testing may be required.	—	—	—	—	—
U1000: CAN COMM	—	—	—	—	BCS-34
U1010: CONTROL UNIT(CAN)	—	—	—	—	BCS-35
U0415: VEHICLE SPEED	—	—	—	—	BCS-36
B2013: ID DISCORD BCM-S/L	×	×	—	—	SEC-55
B2014: CHAIN OF S/L-BCM	×	×	—	—	SEC-56
B2190: NATS ANTENNA AMP	×	—	—	—	SEC-47
B2191: DIFFERENCE OF KEY	×	—	—	—	SEC-50
B2192: ID DISCORD BCM-ECM	×	—	—	—	SEC-51
B2193: CHAIN OF BCM-ECM	×	—	—	—	SEC-53
B2195: ANTI-SCANNING	×	—	—	—	SEC-54
B2553: IGNITION RELAY	—	×	—	—	PCS-49
B2555: STOP LAMP	—	×	—	—	SEC-59
B2556: PUSH-BTN IGN SW	—	×	×	—	SEC-61
B2557: VEHICLE SPEED	×	×	×	—	SEC-63
B2560: STARTER CONT RELAY	×	×	×	—	SEC-64
B2562: LOW VOLTAGE	—	×	—	—	BCS-37
B2601: SHIFT POSITION	×	×	×	—	SEC-65
B2602: SHIFT POSITION	×	×	×	—	SEC-68
B2603: SHIFT POSI STATUS	×	×	×	—	SEC-70
B2604: PNP/CLUTCH SW	×	×	×	—	SEC-73
B2605: PNP/CLUTCH SW	×	×	×	—	SEC-75
B2606: S/L RELAY	×	×	×	—	SEC-77
B2607: S/L RELAY	×	×	×	—	SEC-78
B2608: STARTER RELAY	×	×	×	—	SEC-80
B2609: S/L STATUS	×	×	×	—	SEC-82
B260A: IGNITION RELAY	×	×	×	—	PCS-51
B260B: STEERING LOCK UNIT	—	×	×	—	SEC-86
B260C: STEERING LOCK UNIT	—	×	×	—	SEC-87
B260D: STEERING LOCK UNIT	—	×	×	—	SEC-88
B260F: ENG STATE SIG LOST	×	×	×	—	SEC-89
B2612: S/L STATUS	×	×	×	—	SEC-94
B2614: BCM	—	×	×	—	PCS-53
B2615: BCM	—	×	×	—	PCS-55
B2616: BCM	—	×	×	—	PCS-57
B2617: BCM	×	×	×	—	SEC-98
B2618: BCM	×	×	×	—	PCS-59
B2619: BCM	×	×	×	—	SEC-100
B261A: PUSH-BTN IGN SW	—	×	×	—	PCS-60
B261E: VEHICLE TYPE	×	×	×	×	SEC-101

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle condition	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Refer- ence page
B2621: INSIDE ANTENNA	—	×	—	—	DLK-59
B2622: INSIDE ANTENNA	—	×	—	—	DLK-61
B2623: INSIDE ANTENNA	—	×	—	—	DLK-63
B26E8: CLUTCH SW	×	×	×	—	SEC-90
B26E9: S/L STATUS	×	×	× (Turn ON for 15 seconds)	—	SEC-92
B26EA: KEY REGISTRATION	—	×	× (Turn ON for 15 seconds)	—	SEC-93
C1704: LOW PRESSURE FL	—	—	—	×	WT-24
C1705: LOW PRESSURE FR	—	—	—	×	
C1706: LOW PRESSURE RR	—	—	—	×	
C1707: LOW PRESSURE RL	—	—	—	×	
C1708: [NO DATA] FL	—	—	—	×	
C1709: [NO DATA] FR	—	—	—	×	WT-26
C1710: [NO DATA] RR	—	—	—	×	
C1711: [NO DATA] RL	—	—	—	×	
C1716: [PRESSDATA ERR] FL	—	—	—	×	
C1717: [PRESSDATA ERR] FR	—	—	—	×	WT-29
C1718: [PRESSDATA ERR] RR	—	—	—	×	
C1719: [PRESSDATA ERR] RL	—	—	—	×	
C1729: VHCL SPEED SIG ERR	—	—	—	×	WT-30
C1734: CONTROL UNIT	—	—	—	×	WT-31

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

COMBINATION METER

Reference Value

INFOID:0000000006857888

VALUES ON THE DIAGNOSIS TOOL



Refer to [MWI-86, "Reference Value".](#)

TERMINAL LAYOUT

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40






JSNIA0457ZZ

PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
1 (V)	Ground	Battery power supply	Input	Ignition switch OFF	—	Battery voltage
2 (LG)	Ground	Communication signal (METER→AMP.)	Output	Ignition switch ON	—	 JSNIA0027GB
3 (GR)	Ground	Communication signal (AMP.→ METER)	Input	Ignition switch ON	—	 JSNIA0027GB
5 (B)	Ground	Ground	—	Ignition switch ON	—	0 V
6 (W)	Ground	Alternator signal	Input	Ignition switch ON	Charge warning lamp ON	0 V
					Charge warning lamp OFF	12 V
7 (LG)	Ground	Air bag signal	Input	Ignition switch ON	Air bag warning lamp ON	4 V
					Air bag warning lamp OFF	0 V
10 (W)	Ground	Security signal	Input	Ignition switch OFF	Security warning lamp ON	0 V
					Security warning lamp OFF	12 V
15 (B)	Ground	Ground	—	Ignition switch ON	—	0 V


COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
16 (BR)	Ground	Meter control switch ground	—	Ignition switch ON	0 V
21 (G)	Ground	Ignition signal	Input	Ignition switch ON	12 V
22 (B)	Ground	Ground	—	Ignition switch ON	0 V
24 (BR)	Ground	Communication signal (LCD→AMP.)	Output	Ignition switch ON	 <small>JSNIA0028GB</small>
25 (Y)	Ground	Communication signal (AMP.→LCD)	Input	Ignition switch ON	 <small>JSNIA0027GB</small>
26 (R)	Ground	Vehicle speed signal (8-pulse)	Input	Ignition switch ON	<p>NOTE: The maximum voltage varies depending on the specification (destination unit).</p>  <small>JSNIA0012GB</small>
27 (P)	Ground	Parking brake switch signal	Input	Parking brake ON	0 V
				Ignition switch ON	 <small>JSNIA0007GB</small>
28 (SB)	Ground	Brake fluid level switch sig- nal	Input	Ignition switch ON	 <small>JSNIA0008GB</small>
					The brake fluid level is lower than the low level
					0 V

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >


Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
29 (P)	Ground	Seat belt buckle switch signal (driver side)	Input	Ignition switch ON	When driver seat belt is fastened	12 V
					When driver seat belt is unfastened	0 V
30 (G)	Ground	Seat belt buckle switch signal (passenger side)	Input	Ignition switch ON	• When getting in the passenger seat • When passenger seat belt is fastened	12 V
					• When getting in the passenger seat • When passenger seat belt is unfastened	0 V
31 (L)	Ground	Washer level switch signal	Input	Ignition switch ON	Washer level switch ON	0 V
					Washer level switch OFF	5 V
33 (R)	Ground	Illumination control signal	Output	Ignition switch ON	Lighting switch ON, then operate the illumination control switch.	NOTE: When brightness level is midway  JSNIA0010GB
36 (LG)	16 (BR)	Select switch signal	Input	Ignition switch ON	When  is pressed	0 V
					Other than the above	5 V
37 (Y)	16 (BR)	Enter switch signal	Input	Ignition switch ON	When  is pressed	0 V
					Other than the above	5 V
38 (G)	16 (BR)	Trip A/B reset switch signal	Input	Ignition switch ON	When trip A/B reset switch is pressed	0 V
					Other than the above	5 V
39 (P)	16 (BR)	Illumination control switch signal (-)	Input	Ignition switch ON	When  switch is pressed	0 V
					Other than the above	5 V
40 (BG)	16 (BR)	Illumination control switch signal (+)	Input	Ignition switch ON	When  switch is pressed	0 V
					Other than the above	5 V

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

Wiring Diagram - METER -

INFOID:000000006857889




COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

- A : With A/T
- NV : With NAVI
- ON : Without NAVI
- OM : With automatic drive positioner
- RM : Without rear view monitor
- PM : With paddle shifter


* : This connector is not shown in "Harness Layout".



JCNW5185GB

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >



JCNWMS5186GB

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

METER		Connector No.		Signal Name [Specification]		Terminal No.		Color of Wire		Signal Name [Specification]		Terminal No.		Color of Wire		Signal Name [Specification]	
Connector No.	B1	55	BR	-	-	4	V	-	-	42	41	39	-	46	45	44	43
Connector Name	WIRE TO WIRE	56	R	-	-	5	Y	-	-	47	46	45	-	48	47	46	45
Connector Type	TH8DFW-CS16-TM4	58	V	-	-	60	BR	-	-	49	48	47	-	50	49	48	47
		59	SB	-	-	61	Y	-	-	51	50	49	-	52	51	50	49
		60	BR	-	-	62	R	-	-	53	52	51	-	54	53	52	51
		63	L	-	-	64	Y	-	-	55	54	53	-	56	55	54	53
		65	SHIELD	-	-	71	BR	-	-	57	56	55	-	58	57	56	55
		72	GR	-	-	73	P	-	-	59	58	57	-	60	59	58	57
		74	L	-	-	81	V	-	-	61	60	59	-	62	61	60	59
		82	B	-	-	84	Y	-	-	63	62	61	-	64	63	62	61
		85	G	-	-	86	V	-	-	65	64	63	-	66	65	64	63
		87	R	-	-	88	BR	-	-	67	66	65	-	68	67	66	65
		89	Y	-	-	90	SB	-	-	69	68	67	-	70	69	68	67
		91	BR	-	-	92	BR	-	-	93	LG	LG	-	94	LG	LG	LG
		95	BR	-	-	96	Y	-	-	97	P	P	-	98	P	P	P
		99	LG	-	-	100	GR	-	-	101	BR	BR	-	102	BR	BR	BR
		103	BR	-	-	104	BR	-	-	105	BR	BR	-	106	BR	BR	BR
		107	LG	-	-	108	BR	-	-	109	BR	BR	-	110	BR	BR	BR
		109	BR	-	-	111	BR	-	-	112	BR	BR	-	113	BR	BR	BR
		114	LG	-	-	115	BR	-	-	116	BR	BR	-	117	BR	BR	BR
		118	BR	-	-	119	BR	-	-	120	BR	BR	-	121	BR	BR	BR
		122	L	-	-	123	P	-	-	124	V	-	-	125	SB	-	-
		126	G	-	-	127	W	-	-	128	R	-	-	129	SB	-	-
		130	V	-	-	131	V	-	-	132	SB	-	-	133	SHIELD	-	-
		134	W	-	-	135	BR	-	-	136	Y	-	-	137	SHIELD	-	-
		138	Y	-	-	139	SB	-	-	140	P	-	-	141	L	-	-
		142	SHIELD	-	-	143	R	-	-	144	G	-	-	145	SHIELD	-	-
		146	SB	-	-												

JCNWM5187GB

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

ICNWM5188GB

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

METER				
Connector No.	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
E51	AMBIENT SENSOR	1	GR	-
Connector Name	-	83	GR	-
Connector Type	RS232FB	89	V	-
		91	W	-
		93	GR	-
		95	LG	-
		97	SE	-
		98	SHEILD	-
		99	L	-
		100	P	-

ICC BRAKE HOLD RELAY				
Connector No.	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
E61	RS232FL-M2-LC	1	GR	-
Connector Name	-	3	BG	-
Connector Type	RS232FL-M2-LC	5	G	-
		6	Y	-
		7	V	-
		9	R	-
		10	W	-
		11	V	-
		12	R	-
		13	L	-

ICC SENSOR INTEGRATED UNIT				
Connector No.	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
E67	RS232FB-PR	1	G	-
Connector Name	-	2	P	-
Connector Type	RS232FB-PR	3	L	-
		5	W	-
		16	5F	1F
		17	5F	14F
		18	5F	13F
		19	5F	11F
		20	5F	10F
		21	5F	9F
		22	5F	8F

IGNITION				
Connector No.	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	2F	W	-
2	SB	4F	G	-
3	L	6F	BG	-
4	B	8F	L	-
6	P	9F	P	-

BRAKE HOLD RELAY DRIVE SIGNAL				
Connector No.	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
3	CAN-H	1F	SB	-
4	GRND	2F	GR	-
6	CAN-L	3F	GR	-

CAN-H				
Connector No.	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
1	WIRE TO WIRE	66	GR	-
2	-	67	LG	-
3	-	68	SB	-
4	-	69	P	-
5	-	70	G	-
6	-	81	P	-
7	-	82	G	-
8	-	83	V	-
9	-	84	L	-
10	-	85	W	-
11	-	86	L	-

JCNWM5189GB

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

METER			
Connector No.	E119	Terminal No.	V
Connector Name	STOP LAMP SWITCH	Wire	R
Connector Type	MD40W-LC		
Connector No.	F36	Signal Name [Specification]	
Connector Name	ALTERNATOR		
Connector Type	H503FB		
Terminal No.	Color of Wire	Signal Name [Specification]	
1	L	-	
2	W	-	
3	G	-	
4	V	-	
Connector No.	F30	Terminal No.	Color of Wire
Connector Name	WIRE TO WIRE	1	G
Connector Type	SAA18FB-RS10-S4Z2	2	V
		3	GR
		4	W
Terminal No.	Color of Wire	Signal Name [Specification]	
1	1	1 [With VR25HR engine]	
2	2	2 [With VR25HR engine]	
3	3	3 [With VR25HR engine]	
4	4	4 [With VR25HR engine]	
Connector No.	F37	Terminal No.	Color of Wire
Connector Name	OIL PRESSURE SWITCH	1	G
Connector Type	EU1FGY-RS-AF	2	R
		3	Y
		4	GR
		5	P
		6	Y
		7	GR
		8	P
		9	GR
		10	B
		11	Y
		12	R
		13	W
		14	Y
		15	BR
		16	R
		17	Y
		18	LG
		19	P
		20	O
		21	Y
		22	G
		23	Y
		24	LG
		25	V
		26	W
		27	GR
		28	BR
		29	L
		30	R
		31	P
		32	W
		33	SB
		34	BR
		34	O
		37	B
		37	SHIELD
		38	Y
		39	W

JCNWM5190GB

A B C D E F G H I J K L M N O P

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

METER		Connector No.	F108	Connector No.	M1	Connector No.	M3	
Connector Name	WIRE TO WIRE	Connector Name	AVID CONTROL UNIT	Connector Name	FUSE BLOCK (J/B)	Connector Name	FUSE BLOCK (J/B)	
Connector Type	TK3FW-NS10	Connector Type	TH16FW-NH	Connector Type	NS06FW-M2	Connector Type	NS12FW-CS	
1	2	3	4	5	6	7	8	
9	10	11	12	13	14	15	16	
Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
1	G	AND SOL (+)	1	A	V	-	-	-
2	W	AND SOL (-)	2	Y	AND SOL (-)	2	G	-
3	R	-	3	W	OIL TEMP (-)	3	L	-
4	B	-	7	G	IGN	4	P	-
5	G	- (With VQ25HR engine)	8	L	CAN-H	5	A	-
9	Y	- (With VQ35HR engine)	9	BG	AND SOL BAT (With VQ25HR engine)	6	A	-
10	L	- (With VQ35HR engine)	9	O	AND SOL BAT (With VQ35HR engine)	7	R	-
10	GR	- (With VQ37VHR engine)	10	B	GND	3A	L	-
19	BG	- (With VQ37VHR engine)	11	B	GND			
19	O	- (With VQ37VHR engine)	13	B	OIL TEMP (-)			
20	Y	-	15	Y	VB			
28	B	-	16	P	CAN-L			
29	LG	-						
30	R	-						
31	R	-						
33	B	-						
34	B	-						
35	L	-						
36	P	-						
37	Y	-						
38	G	-						
41	O	-						
42	BR	-						
43	P	-						
44	L	-						
45	Y	- (With VQ25HR engine)						
45	G	- (With VQ37VHR engine)						
46	V	-						
Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
1	-	VIGN	1	B	S3	-	-	-
2	-	BATT	2	B	SB	-	-	-
3	-	CAN-H	6B	Y	-	-	-	-
4	-	K-LINE	7B	P	-	-	-	-
5	-	GND	9B	R	-	-	-	-
6	-	VIGN	9B	SB	-	-	-	-
7	-	REV AMP RLY						
3	-	CAN-L						
9	-	STARTER RLY						
10	-	GND						

JCNWM5191GB

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >


METER		
Connector No.	M6	
Connector Name	WIRE TO WIRE	
Connector Type	THBDMW-CS16-TM4	
Terminal No.	59	B
Color of Wire		-
	66	Y
	67	G
	68	R
	69	W
	70	G
	80	SB
	81	B
	82	Y
	83	W
	84	L
	85	GR
	86	G
	87	R
	88	LG
	89	Y
	91	W
	93	Y
	95	Y
	97	GR
	98	SHIELD
	99	Y
	100	SB
Signal Name [Specification]		
Connector No.	M7	
Connector Name	WIRE TO WIRE	
Connector Type	THBDMW-CS16-TM4	
Terminal No.	1	GR
Color of Wire		-
	16	W
	17	BR
	18	P
	19	L
	20	L
	30	BR
	31	L
	32	Y
	33	EG
	34	W
	35	BR
	36	R
	37	Y
	38	R
	39	SB
	40	G
	41	V
	42	LG
	43	P
	44	R
	45	BR
	46	G
	47	L
	48	P
	49	L
Signal Name [Specification]		
Connector No.	M24	
Connector Name	DATA LINK CONNECTOR	
Connector Type	BD16FW-P	
Terminal No.	1	P
Color of Wire		-
	2	P
	3	P
	4	P
	5	P
	6	P
	7	P
	8	P
	9	P
	10	P
	11	P
	12	P
	13	P
	14	P
	15	P
	16	P
Signal Name [Specification]		
Connector No.	M32	
Connector Name	PADDLE SHIFTER (SHIFT-UP)	
Connector Type	A03FW	
Terminal No.	1	P
Color of Wire		-
	2	P
	3	P
	4	P
	5	P
	6	P
	7	P
	8	P
	9	P
	10	P
	11	P
	12	P
	13	P
	14	P
	15	P
	16	P
Signal Name [Specification]		
Connector No.	M33	
Connector Name	PADDLE SHIFTER (SHIFT-DOWN)	
Connector Type	A03FW	
Terminal No.	1	P
Color of Wire		-
	2	P
	3	P
	4	P
	5	P
	6	P
	7	P
	8	P
	9	P
	10	P
	11	P
	12	P
	13	P
	14	P
	15	P
	16	P
Signal Name [Specification]		
Connector No.	M34	
Connector Name	WIRE TO WIRE	
Connector Type	THBDMW-CS16-TM4	
Terminal No.	1	GR
Color of Wire		-
	2	P
	3	SB
	4	P
	5	P
	6	L
	7	W
	8	G
	9	Y
	10	Y
	11	Y
	12	Y
	13	Y
	14	Y
	15	R
	16	BR
Signal Name [Specification]		

JCNWMM5192GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z
INL

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >



JCNWM5193GB

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

METER		Connector No. M65		Connector No. M122	
Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
103	GR	AVCC-AFS 2	26	B	GND (CONT)
104	Y	GND-APS 2			
105	L	PDPRESS			
106	W	TF			
107	GR	AVCC-FIBRS			
108	Y	GND-ASCD			
109	G	NEUT-H			
110	R	TACHO			
111	Y	QND-A			
113	P	VEH CAN-L			
114	L	VEH CAN-H			
117	Y	KLINE			
121	LG	ODCV			
122	P	BRAKE			
123	B	GND			
124	B	CAN-H			
125	R	CAN-L			
126	BR	AV COMM (H)			
127	B	AV COMM (L)			
128	B	GND			
90	SB	AV COMM (H)			
91	LG	AV COMM (L)			
95	R	AUX SOUND SIGNAL RH (+)			
96	W	AUX SOUND SIGNAL LH (-)			
97	B	AUX SOUND GND			
101	BR	SW GND			
103	V	EJECT SIGNAL			
104	G	IGNITION			
105	BG	REVERSE			
106	SB	PARKING BRAKE			
107	R	VEHICLE SPEED (6-PULSE)			
Connector No. M107					
Connector Name ECM					
Connector Type R124F-GY-R28-R-LH-Z					

METER		Connector No. M65		Connector No. M116	
Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
103	GR	AVCC-AFS 2	26	B	GND (CONT)
104	Y	GND-APS 2			
105	L	PDPRESS			
106	W	TF			
107	GR	AVCC-FIBRS			
108	Y	GND-ASCD			
109	G	NEUT-H			
110	R	TACHO			
111	Y	QND-A			
113	P	VEH CAN-L			
114	L	VEH CAN-H			
117	Y	KLINE			
121	LG	ODCV			
122	P	BRAKE			
123	B	GND			
124	B	CAN-H			
125	R	CAN-L			
126	BR	AV COMM (H)			
127	B	AV COMM (L)			
128	B	GND			
90	SB	AV COMM (H)			
91	LG	AV COMM (L)			
95	R	AUX SOUND SIGNAL RH (+)			
96	W	AUX SOUND SIGNAL LH (-)			
97	B	AUX SOUND GND			
101	BR	SW GND			
103	V	EJECT SIGNAL			
104	G	IGNITION			
105	BG	REVERSE			
106	SB	PARKING BRAKE			
107	R	VEHICLE SPEED (6-PULSE)			
Connector No. M107					
Connector Name ECM					
Connector Type R124F-GY-R28-R-LH-Z					

METER		Connector No. M65		Connector No. M116	
Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
103	GR	AVCC-AFS 2	26	B	GND (CONT)
104	Y	GND-APS 2			
105	L	PDPRESS			
106	W	TF			
107	GR	AVCC-FIBRS			
108	Y	GND-ASCD			
109	G	NEUT-H			
110	R	TACHO			
111	Y	QND-A			
113	P	VEH CAN-L			
114	L	VEH CAN-H			
117	Y	KLINE			
121	LG	ODCV			
122	P	BRAKE			
123	B	GND			
124	B	CAN-H			
125	R	CAN-L			
126	BR	AV COMM (H)			
127	B	AV COMM (L)			
128	B	GND			
90	SB	AV COMM (H)			
91	LG	AV COMM (L)			
95	R	AUX SOUND SIGNAL RH (+)			
96	W	AUX SOUND SIGNAL LH (-)			
97	B	AUX SOUND GND			
101	BR	SW GND			
103	V	EJECT SIGNAL			
104	G	IGNITION			
105	BG	REVERSE			
106	SB	PARKING BRAKE			
107	R	VEHICLE SPEED (6-PULSE)			
Connector No. M107					
Connector Name ECM					
Connector Type R124F-GY-R28-R-LH-Z					


METER		Connector No. M65		Connector No. M116	
Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
103	GR	AVCC-AFS 2	26	B	GND (CONT)
104	Y	GND-APS 2			
105	L	PDPRESS			
106	W	TF			
107	GR	AVCC-FIBRS			
108	Y	GND-ASCD			
109	G	NEUT-H			
110	R	TACHO			
111	Y	QND-A			
113	P	VEH CAN-L			
114	L	VEH CAN-H			
117	Y	KLINE			
121	LG	ODCV			
122	P	BRAKE			
123	B	GND			
124	B	CAN-H			
125	R	CAN-L			
126	BR	AV COMM (H)			
127	B	AV COMM (L)			
128	B	GND			
90	SB	AV COMM (H)			
91	LG	AV COMM (L)			
95	R	AUX SOUND SIGNAL RH (+)			
96	W	AUX SOUND SIGNAL LH (-)			
97	B	AUX SOUND GND			
101	BR	SW GND			
103	V	EJECT SIGNAL			
104	G	IGNITION			
105	BG	REVERSE			
106	SB	PARKING BRAKE			
107	R	VEHICLE SPEED (6-PULSE)			
Connector No. M107					
Connector Name ECM					
Connector Type R124F-GY-R28-R-LH-Z					

METER		Connector No. M65		Connector No. M116	
Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
103	GR	AVCC-AFS 2	26	B	GND (CONT)
104	Y	GND-APS 2			
105	L	PDPRESS			
106	W	TF			
107	GR	AVCC-FIBRS			
108	Y	GND-ASCD			
109	G	NEUT-H			
110	R	TACHO			
111	Y	QND-A			
113	P	VEH CAN-L			
114	L	VEH CAN-H			
117	Y	KLINE			
121	LG	ODCV			
122	P	BRAKE			
123	B	GND			
124	B	CAN-H			
125	R	CAN-L			
126	BR	AV COMM (H)			
127	B	AV COMM (L)			
128	B	GND			
90	SB	AV COMM (H)			
91	LG	AV COMM (L)			
95	R	AUX SOUND SIGNAL RH (+)			
96	W	AUX SOUND SIGNAL LH (-)			
97	B	AUX SOUND GND			
101	BR	SW GND			
103	V	EJECT SIGNAL			
104	G	IGNITION			
105	BG	REVERSE			
106	SB	PARKING BRAKE			
107	R	VEHICLE SPEED (6-PULSE)			
Connector No. M107					
Connector Name ECM					
Connector Type R124F-GY-R28-R-LH-Z					

METER		Connector No. M65		Connector No. M116	
Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
103	GR	AVCC-AFS 2	26	B	GND (CONT)
104	Y	GND-APS 2			
105	L	PDPRESS			
106	W	TF			
107	GR	AVCC-FIBRS			
108	Y	GND-ASCD			
109	G	NEUT-H			
110	R	TACHO			
111	Y	QND-A			
113	P	VEH CAN-L			
114	L	VEH CAN-H			
117	Y	KLINE			
121	LG	ODCV			
122	P	BRAKE			
123	B	GND			
124	B	CAN-H			
125	R	CAN-L			
126	BR	AV COMM (H)			
127	B	AV COMM (L)			
128	B	GND			
90	SB	AV COMM (H)			
91	LG	AV COMM (L)			
95	R	AUX SOUND SIGNAL RH (+)			
96	W	AUX SOUND SIGNAL LH (-)			
97	B	AUX SOUND GND			
101	BR	SW GND			
103	V	EJECT SIGNAL			
104	G	IGNITION			
105	BG	REVERSE			
106	SB	PARKING BRAKE			
107	R	VEHICLE SPEED (6-PULSE)			
Connector No. M107					
Connector Name ECM					
Connector Type R124F-GY-R28-R-LH-Z					

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >



JCNWM5195GB

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

A
B
C
D
E
F
G
H
I
J
K

INL
M
N
O
P

METER	Connector No.	M210
Connector Name	AV CONTROL UNIT	
Connector Type	TH32FW-NH	
		
		
Terminal	Color No.	Signal Name [Specification]
65	SB	PARKING BRAKE
67	P	COMPOSITE IMAGE GND
68	L	COMPOSITE IMAGE SIGNAL
71	SHIELD	MICROPHONE GND
72	G	MICROPHONE VCC
73	P	COMM (CONT-DISP)
74	P	CAN-L
75	LG	AV COMM (L)
76	LG	AV COMM (L)
79	L	ILLUMINATION
80	G	IGNITION
81	BG	REVERSE
82	R	VEHICLE SPEED (6-PULSE)
83	SHIELD	SHIELD
87	R	MICROPHONE SIGNAL
88	SHIELD	SHIELD
89	L	COMM (DISP->CONT)
90	L	CAN-H
91	SB	AV COMM (H)
92	SB	AV COMM (H)

JCNWMM5196GB

INFOID:0000000006857890

Fail-safe

FAIL-SAFE

Combination meter performs fail-safe operation when unified meter and A/C amp. communication is malfunction.

Solution for communication error between the unified meter and A/C amp. and combination meter.

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

Function		Specifications
Speedometer		Reset to zero by suspending communication.
Tachometer		
Fuel gauge		
Engine coolant temperature gauge		
Information display	Door open warning	The display turns off by suspending communication.
	Parking brake release warning	
	Low tire pressure warning	
	Fuel filler cap warning	
	Instantaneous fuel warning	<ul style="list-style-type: none"> When reception time of an abnormal signal is 2 seconds or less, the last received datum is used for calculation to indicate the result. When reception time of an abnormal signal is more than two seconds, the last result calculated during normal condition is indicated.
	Average fuel consumption	
	Average vehicle speed	
	Travel distance	
Illumination control		When suspending communication, change to nighttime mode.
Buzzer		The buzzer turns off by suspending communication.
Warning lamp/indicator lamp	ABS warning lamp	The lamp turns on by suspending communication.
	SLIP indicator lamp	
	Brake warning lamp	
	CRUISE warning lamp	
	Malfunction indicator lamp	
	High beam indicator	The lamp turns off by suspending communication.
	Turn signal indicator lamp	
	Oil pressure warning lamp	
	A/T CHECK warning lamp	
	VDC OFF indicator lamp	
	AWD warning lamp	
	Low tire pressure warning lamp	
	Key warning lamp	
	AFS OFF indicator lamp	
	Master warning lamp	
	Tail lamp indicator lamp	
	Front fog lamp indicator lamp	

DTC Index

INFOID:0000000006857891

Refer to [MWI-107, "DTC Index".](#)

INTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

INTERIOR LIGHTING SYSTEM SYMPTOMS

Symptom Table

INFOID:000000006205874

CAUTION:
Perform the self-diagnosis with CONSULT-III before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom	Possible cause	Inspection item
All the following lamps do not turn ON. <ul style="list-style-type: none">• Map lamp• Personal lamp• Trunk room lamp• Step lamp• Vanity mirror lamp	<ul style="list-style-type: none">• Harness between BCM and each interior room lamp• BCM	Interior room lamp power supply circuit Refer to INL-20 .
<ul style="list-style-type: none">• Interior room lamp does not turn ON even though the door is open. (It turns ON when turning the interior room lamp ON.)• Interior room lamp does not turn OFF even though the door is closed.	<ul style="list-style-type: none">• Harness between BCM and each door switch• Harness between BCM and each interior room lamp• BCM	Door switch circuit Refer to DLK-66 . Interior room lamp control circuit Refer to INL-22 .
Interior room lamp timer does not activate. (It turns ON/ OFF when the door opens/closes.)	—	Check the interior room lamp setting. Refer to INL-16 .
Step lamps (driver side and passenger side) do not turn ON. (Map lamp and personal lamp turn ON.)	<ul style="list-style-type: none">• Harness between BCM and each step lamp• BCM	Step lamp circuit Refer to INL-24 .
Step lamps (driver side and passenger side) do not turn OFF. (Map lamp and personal lamp turn OFF.)	<ul style="list-style-type: none">• Harness between BCM and each step lamp• BCM	Step lamp circuit Refer to INL-24 .
<ul style="list-style-type: none">• Trunk room lamp does not turn ON. (Bulb is normal.)• Trunk room lamp does not turn OFF.	<ul style="list-style-type: none">• Harness between BCM and trunk room lamp switch• Harness between BCM and trunk room lamp• BCM	Trunk room lamp switch circuit Refer to DLK-78 . Trunk room lamp circuit Refer to INL-26 .
Push-button ignition switch illumination does not illuminate.	<ul style="list-style-type: none">• Harness between BCM and push-button ignition switch• BCM	Push-button ignition switch illumination circuit Refer to INL-28 .
Interior room lamp battery saver does not activate.	—	Check the interior room lamp battery saver setting. Refer to INL-17 .

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000006205875

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

MAP LAMP


< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION

MAP LAMP

Exploded View

INFOID:000000006205876



1. Map lamp assembly

2. Bulb

3. Lens

Removal and Installation

INFOID:000000006205877

Refer to [INL-109, "Exploded View"](#) for the map lamp assembly installation/removal.

Replacement

INFOID:000000006205878

CAUTION:

- Disconnect negative battery terminal or remove the fuse.
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.
- Never touch bulb by hand while it is lit or right after being turned off.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

MAP LAMP BULB

1. Insert any appropriate tool into the gap between the lens. Remove the lens.
2. Remove the bulb.

INL


VANITY MIRROR LAMP

< REMOVAL AND INSTALLATION >

VANITY MIRROR LAMP

Exploded View

INFOID:0000000006205879



JPLIA0061ZZ

1. Lens
2. Bulb

Replacement

INFOID:0000000006205880

CAUTION:

- Disconnect negative battery terminal or remove the fuse.
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.
- Never touch bulb by hand while it is lit or right after being turned off.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

VANITY MIRROR LAMP BULB

1. Insert any appropriate tool into the gap between the lens. Remove the lens.
2. Remove the bulb.


CIGARETTE LIGHTER ILLUMINATION

< REMOVAL AND INSTALLATION >

CIGARETTE LIGHTER ILLUMINATION

Exploded View

INFOID:0000000006205881



1. Bulb socket
2. Bulb
(Share with the ashtray illumination)

A Hooks

Replacement

INFOID:0000000006205882

CAUTION:

- Disconnect negative battery terminal or remove the fuse.
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.
- Never touch bulb by hand while it is lit or right after being turned off.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

CIGARETTE LIGHTER ILLUMINATION BULB

1. Remove the console finisher. Refer to [IP-34, "A/T MODELS : Exploded View"](#).
2. Insert any appropriate tool into the gap of the bulb socket. Widen the hooks and remove the bulb socket.
3. Remove the bulb.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P


GLOVE BOX LAMP

< REMOVAL AND INSTALLATION >

GLOVE BOX LAMP

Exploded View

INFOID:0000000006205883



1. Bulb

2. Bulb socket

Replacement

INFOID:0000000006205884

CAUTION:

- Disconnect negative battery terminal or remove the fuse.
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.
- Never touch bulb by hand while it is lit or right after being turned off.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

GLOVE BOX LAMP BULB

1. Remove the instrument assist lower panel. Refer to [IP-12, "A/T MODELS : Exploded View"](#).
2. Rotate the bulb socket counterclockwise and unlock it.
3. Remove the bulb.


STEP LAMP

< REMOVAL AND INSTALLATION >

STEP LAMP

Exploded View

INFOID:0000000006205885



1. Step lamp case

2. Bulb

3. Lens

A Metal clip

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

Removal and Installation

INFOID:0000000006205886

CAUTION:

Disconnect the battery negative terminal or remove the fuse.

REMOVAL

1. Insert any appropriate tool into the gap between the step lamp and the door trim. Remove the step lamp.
2. Disconnect the connector.

INSTALLATION

Install in the reverse order of removal.

Replacement

INFOID:0000000006205887

CAUTION:

- **Disconnect negative battery terminal or remove the fuse.**
- **Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.**
- **Never touch bulb by hand while it is lit or right after being turned off.**
- **Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.**

STEP LAMP BULB

1. Remove the step lamp. Refer to [INL-113, "Exploded View"](#).
2. Remove the lens.
3. Remove the bulb.


PERSONAL LAMP

< REMOVAL AND INSTALLATION >

PERSONAL LAMP

Exploded View

INFOID:0000000006205888



1. Personal lamp case
2. Personal lamp finisher
3. Bulb
4. Lens

NOTE:

Replace the personal lamp case as a set (right and left). Before installing the headlining assembly, remove the personal lamp case. Refer to [INL-114, "Removal and Installation"](#).

Removal and Installation

INFOID:0000000006205889

CAUTION:


Disconnect the battery negative terminal or remove the fuse.

REMOVAL

1. Insert any appropriate tool into the gap between the lens. Remove the lens.
2. Press the both side pawls (A) to the arrow direction (←). Remove the personal lamp finisher.

NOTE:

Replace the personal lamp case as a set (right and left). Remove the personal lamp case after installing the headlining assembly. Refer to [INT-24, "NORMAL ROOF : Exploded View"](#) (normal roof), [INT-27, "SUNROOF : Exploded View"](#) (sun roof).



INSTALLATION

Install in the reverse order of removal.


NOTE:

The following is easier to install the personal lamp finisher with the headlining installed.

PERSONAL LAMP

< REMOVAL AND INSTALLATION >

- Press the personal lamp finisher to the headlining. Pull the personal lamp case pawl to the arrow direction () with any appropriate tool.



INFOID:000000006205890

Replacement

CAUTION:

- Disconnect negative battery terminal or remove the fuse.
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.
- Never touch bulb by hand while it is lit or right after being turned off.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

PERSONAL LAMP BULB

1. Insert any appropriate tool into the gap between the lens. Remove the lens.
2. Remove the bulb.

A
B
C
D

E
F

G
H
I
J

K

INL

M
N
O
P


TRUNK ROOM LAMP

< REMOVAL AND INSTALLATION >

TRUNK ROOM LAMP

Exploded View

INFOID:0000000006205891



- | | |
|--------------------------|--------------------------------|
| 1. Trunk room lamp | 2. Bulb |
| A Pawl (for lens fixing) | B Pawl (for case installation) |

Removal and Installation


INFOID:0000000006205892

CAUTION:

Disconnect the battery negative terminal or remove the fuse.

REMOVAL

1. Widen the pawl (A). Open the lens (1).
2. Remove the bulb.
3. Pressing the pawl (B) to the arrow direction (➡). Pull out the trunk room lamp.
4. Disconnect the connector.
5. Remove the trunk room lamp.



INSTALLATION

Install in the reverse order of removal.

Replacement

INFOID:0000000006205893

CAUTION:

- Disconnect negative battery terminal or remove the fuse.
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.
- Never touch bulb by hand while it is lit or right after being turned off.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

TRUNK ROOM LAMP BULB

1. Widen the lens pawl. Open the lens.
2. Remove the bulb.

SERVICE DATA AND SPECIFICATIONS (SDS)

<SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

Bulb Specifications

INFOID:000000006205894

Item	Type	Wattage (W)
Push-button ignition switch illumination	LED	—
Map lamp	Wedge	8
Center console indirect illumination (Integrated into the map lamp assembly)	LED	—
Vanity mirror lamp	—	2
Glove box lamp	—	1.4
Cigarette lighter illumination (Shared with ash tray illumination)	—	1.4
Step lamp	Wedge	8
Personal lamp	Wedge	8
Trunk room lamp	Wedge	3.4

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P