

MWI

SECTION

METER, WARNING LAMP & INDICATOR

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

CONTENTS

BASIC INSPECTION	4	ODO/TRIP METER	27
DIAGNOSIS AND REPAIR WORK FLOW	4	ODO/TRIP METER : System Diagram	27
Work flow	4	ODO/TRIP METER : System Description	27
SYSTEM DESCRIPTION	7	ODO/TRIP METER : Component Parts Location	28
METER SYSTEM	7	ODO/TRIP METER : Component Description	29
METER SYSTEM	7	SHIFT POSITION INDICATOR	30
METER SYSTEM : System Diagram	7	SHIFT POSITION INDICATOR : System Diagram	30
METER SYSTEM : System Description	7	SHIFT POSITION INDICATOR : System Description	30
METER SYSTEM : Component Parts Location	13	SHIFT POSITION INDICATOR : Component Parts Location	31
METER SYSTEM : Component Description	14	SHIFT POSITION INDICATOR : Component Description	32
SPEEDOMETER	15	OIL PRESSURE WARNING LAMP	33
SPEEDOMETER : System Diagram	15	OIL PRESSURE WARNING LAMP : System Diagram	33
SPEEDOMETER : System Description	15	OIL PRESSURE WARNING LAMP : System Description	33
SPEEDOMETER : Component Parts Location	16	OIL PRESSURE WARNING LAMP : Component Parts Location	34
SPEEDOMETER : Component Description	17	OIL PRESSURE WARNING LAMP : Component Description	35
TACHOMETER	18	METER ILLUMINATION CONTROL	36
TACHOMETER : System Diagram	18	METER ILLUMINATION CONTROL : System Diagram	36
TACHOMETER : System Description	18	METER ILLUMINATION CONTROL : System Description	36
TACHOMETER : Component Parts Location	19	METER ILLUMINATION CONTROL : Component Parts Location	37
TACHOMETER : Component Description	20	METER ILLUMINATION CONTROL : Component Description	38
ENGINE COOLANT TEMPERATURE GAUGE	21	INFORMATION DISPLAY	39
ENGINE COOLANT TEMPERATURE GAUGE : System Diagram	21	INFORMATION DISPLAY : System Diagram	39
ENGINE COOLANT TEMPERATURE GAUGE : System Description	21	INFORMATION DISPLAY : System Description	39
ENGINE COOLANT TEMPERATURE GAUGE : Component Parts Location	22	INFORMATION DISPLAY : Component Parts Location	47
ENGINE COOLANT TEMPERATURE GAUGE : Component Description	23	INFORMATION DISPLAY : Component Description	48
FUEL GAUGE	24		
FUEL GAUGE : System Diagram	24		
FUEL GAUGE : System Description	24		
FUEL GAUGE : Component Parts Location	25		
FUEL GAUGE : Component Description	26		

MWI

UP-SHIFT INDICATOR	49	OIL PRESSURE SENSOR SIGNAL CIRCUIT...	74
UP-SHIFT INDICATOR : System Diagram	49	Description	74
UP-SHIFT INDICATOR : System Description	49	Component Function Check	74
UP-SHIFT INDICATOR : Component Parts Location	51	Diagnosis Procedure	74
UP-SHIFT INDICATOR : Component Description..	52	Component Inspection	74
DIAGNOSIS SYSTEM (METER)	54	PARKING BRAKE SWITCH SIGNAL CIRCUIT	76
Diagnosis Description	54	Description	76
CONSULT Function (METER/M&A)	55	Diagnosis Procedure	76
DTC/CIRCUIT DIAGNOSIS	61	Component Inspection	76
U1000 CAN COMM CIRCUIT	61	WASHER LEVEL SWITCH SIGNAL CIRCUIT..	78
Description	61	Description	78
DTC Logic	61	Diagnosis Procedure	78
Diagnosis Procedure	61	Component Inspection	78
U1010 CONTROL UNIT (CAN)	62	A/C AUTO AMP. CONNECTION RECOGNITION SIGNAL CIRCUIT	80
Description	62	Description	80
DTC Logic	62	Diagnosis Procedure	80
Diagnosis Procedure	62	ECU DIAGNOSIS INFORMATION	81
B2205 VEHICLE SPEED	63	COMBINATION METER	81
Description	63	Reference Value	81
DTC Logic	63	Wiring Diagram - METER -	89
Diagnosis Procedure	63	Fail-safe	98
B2267 ENGINE SPEED	64	DTC Index	100
Description	64	SYMPTOM DIAGNOSIS	102
DTC Logic	64	THE FUEL GAUGE POINTER DOES NOT MOVE	102
Diagnosis Procedure	64	Description	102
B2268 WATER TEMP	65	Diagnosis Procedure	102
Description	65	THE METER CONTROL SWITCH IS INOPERATIVE	103
DTC Logic	65	Description	103
Diagnosis Procedure	65	Diagnosis Procedure	103
B2321, B2322 OIL LEVEL SENSOR	66	THE OIL PRESSURE WARNING LAMP DOES NOT TURN ON OR OFF	104
Description	66	Description	104
DTC Logic	66	Diagnosis Procedure	104
Diagnosis Procedure	66	THE PARKING BRAKE RELEASE WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY	105
Component Inspection	67	Description	105
POWER SUPPLY AND GROUND CIRCUIT	68	Diagnosis Procedure	105
COMBINATION METER	68	THE DOOR OPEN WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY	106
COMBINATION METER : Diagnosis Procedure ...	68	Description	106
FUEL LEVEL SENSOR SIGNAL CIRCUIT	69	Diagnosis Procedure	106
Description	69	THE TRUNK OPEN WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY	107
Component Function Check	69	Description	107
Diagnosis Procedure	69	Diagnosis Procedure	107
Component Inspection (GT-R certified NISSAN dealer)	71		
METER CONTROL SWITCH SIGNAL CIRCUIT	72		
Description	72		
Diagnosis Procedure	72		
Component Inspection	73		

Diagnosis Procedure	107	Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	111
THE LOW WASHER FLUID WARNING CONTINUES DISPLAYING, or DOES NOT DISPLAY	108	Precaution for Battery Service	111
Description	108	Precautions for Removing Battery Terminal	111
Diagnosis Procedure	108	PREPARATION	112
THE AMBIENT TEMPERATURE DISPLAY IS INCORRECT	109	PREPARATION	112
Description	109	Commercial Service Tools	112
Diagnosis Procedure	109	REMOVAL AND INSTALLATION	113
NORMAL OPERATING CONDITION	110	COMBINATION METER	113
INFORMATION DISPLAY	110	Exploded View	113
INFORMATION DISPLAY : Description	110	Removal and Installation	114
PRECAUTION	111	Disassembly and Assembly	114
PRECAUTIONS	111	METER CONTROL SWITCH	115
		Exploded View	115
		Removal and Installation	115

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work flow

INFOID:000000011488233

OVERALL SEQUENCE



- Reference 1...[MWI-54, "Diagnosis Description"](#).
- Reference 2...[MWI-100, "DTC Index"](#).
- Reference 3...[MWI-72, "Diagnosis Procedure"](#).
- Reference 4...[MWI-73, "Component Inspection"](#).
- Reference 5...[MWI-68, "COMBINATION METER : Diagnosis Procedure"](#).

DETAILED FLOW

1.OBTAIN INFORMATION ABOUT SYMPTOM

Interview the customer to obtain as much information as possible about the conditions and environment under which the malfunction occurred.

>> GO TO 2.

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

2. CHECK SYMPTOM

- Check the symptom based on the information obtained from the customer.
- Check that any other malfunctions are present.

>> GO TO 3.

3. CHECK ON BOARD DIAGNOSIS OPERATION

Check that the on board diagnosis function operates. Refer to [MWI-54, "Diagnosis Description"](#).

Does the on board diagnosis function operate normally?

YES >> GO TO 4.

NO >> GO TO 6.

4. CHECK CONSULT SELF-DIAGNOSIS RESULTS

1. Connect CONSULT and perform self-diagnosis. Refer to [MWI-100, "DTC Index"](#).
2. When DTC is detected, follow the instructions below:
 - Record DTC and Freeze Frame Data.

Are self-diagnosis results normal?

YES >> GO TO 5.

NO >> GO TO 10.

5. NARROW DOWN THE MALFUNCTIONING PARTS BY SYMPTOM DIAGNOSIS

Perform symptom diagnosis and narrow down the malfunctioning parts.

>> GO TO 10.

6. CHECK METER CONTROL SWITCH SIGNAL CIRCUIT

Check meter control switch signal circuit. Refer to [MWI-72, "Diagnosis Procedure"](#).

Is inspection result OK?

YES >> GO TO 7.

NO >> GO TO 10.

7. CHECK METER CONTROL SWITCH

Check meter control switch. Refer to [MWI-73, "Component Inspection"](#).

Is inspection result OK?

YES >> GO TO 8.

NO >> GO TO 10.

8. CHECK COMBINATION METER POWER SUPPLY AND GROUND CIRCUITS

Check combination meter power supply and ground circuits. Refer to [MWI-68, "COMBINATION METER : Diagnosis Procedure"](#).

Is inspection result OK?

YES >> GO TO 9.

NO >> GO TO 10.

9. REPLACE COMBINATION METER

Replace combination meter.

>> GO TO 11.

10. REPAIR OR REPLACE MALFUNCTIONING PARTS

Repair or replace the malfunctioning parts.

NOTE:

If DTC is displayed, erase DTC after repair or replace malfunctioning parts.

>> GO TO 11.

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

11.FINAL CHECK

Check that the combination meter operates normally.

Do they operate normally?

YES >> INSPECTION END
NO >> GO TO 1.

METER SYSTEM

< SYSTEM DESCRIPTION >


SYSTEM DESCRIPTION

METER SYSTEM

METER SYSTEM

METER SYSTEM : System Diagram

INFOID:000000011488234



METER SYSTEM : System Description

INFOID:000000011488235

COMBINATION METER

- The combination meter receives the signals that are required to control the operation of each meter gauge, indicator lamp/warning lamp, and information display from each unit, switch, and sensor.
- The combination meter is equipped with the drive computer function. Using the signal obtained from each unit, switch, and sensor, the combination meter displays warnings and information to the information display.
- The combination meter incorporates a buzzer function that sounds an audible alarm with the integrated buzzer device. Refer to [WCS-5. "WARNING CHIME SYSTEM : System Description"](#) for details.
- The combination meter integrates the meter circuit check function, the dot matrix check function that checks the information display operation, and the segment check function that checks the shift position indicator operation.
- The combination meter integrates the diagnosis function, and it can perform a diagnosis using CONSULT.

METER CONTROL FUNCTION LIST

A
B
C
D
E
F
G
H
I
J
K
L
M
MWI
O
P

METER SYSTEM

< SYSTEM DESCRIPTION >

System		Description	Signal source
Meter gauges	Speedometer	Receives the vehicle speed signal, and indicates the vehicle speed.	ABS actuator and electric unit (control unit)
	Tachometer	Receives the engine speed signal, and indicates the engine speed.	ECM
	Fuel gauge	Receives the fuel level sensor signal, and indicates the remaining fuel level.	Fuel level sensor unit
	Engine coolant temperature gauge	Receives the engine coolant temperature signal, and indicates the engine coolant temperature.	ECM
Shift position indicator	Shift position indicator	Receives the shift position signal, and displays the shift position.	TCM
Oil pressure warning lamp	Oil pressure warning lamp	Receives the oil pressure sensor signal, and illuminates the lamp.	Oil pressure sensor
Up-shift indicator	Up-shift indicator	Receives the engine speed signal and shift position signal (manual mode status), and illuminates/turns off/blinks the indicator.	ECM
			TCM
Master warning lamp	Master warning lamp	Illuminates the lamp according to warning output on information display.	—
Information display	Instantaneous fuel consumption display	Calculates the instantaneous fuel consumption based on received vehicle speed signal and fuel consumption monitor signal, and displays the result.	ECM ABS actuator and electric unit (control unit)
	Vehicle speed display	Based on the received vehicle speed signal, displays the vehicle speed.	ABS actuator and electric unit (control unit)
	CRUISE control system status display	Based on the received ASCD status signal, displays the CRUISE control system setting status.	ECM

METER SYSTEM

< SYSTEM DESCRIPTION >

System	Description	Signal source		
Information display	Average fuel consumption display	Based on the received vehicle speed signal and fuel consumption monitor signal, calculates the average fuel consumption from the previous reset to the next reset, and displays the result.	ECM	A
			ABS actuator and electric unit (control unit)	B
	Average vehicle speed display	Calculates average vehicle speed in a reset-to-reset interval based on received vehicle speed signal and displays it.	ABS actuator and electric unit (control unit)	C
	Travel time display	Displays the accumulated key switch ON time from a previous reset to the next reset.	—	
	Travel distance display	Calculates accumulated travel distance in a reset-to-reset interval based on received vehicle speed signal and displays it.	ABS actuator and electric unit (control unit)	D
	Possible driving distance display	Based on the received fuel consumption monitor signal, vehicle speed signal, and fuel level sensor signal, calculates the possible driving distance, and displays the result.	ECM	E
			ABS actuator and electric unit (control unit)	
			Fuel level sensor unit	F
	Ambient air temperature display	Based on the received ambient sensor signal, corrects the ambient air temperature value, and displays the result.	Ambient sensor	
	Illumination control display	Based on the received illumination control switch signal, displays the illumination status.	Meter control switch	G
	Travel time interruption display	Displays a warning of duration after IGN ON. (If enabled)	—	H
	Low ambient air temperature display	Based on the ambient sensor signal, displays a warning when the ambient air temperature becomes 3 °C (37 °F) or less. (If enabled)	Ambient sensor	I
	Engine oil maintenance display	The distance for engine oil replacement can be set.	—	
	Engine oil maintenance warning display	Displays a warning when the arbitrarily set engine oil replacement distance is reached.	—	J
	Engine oil level normal display	Based on the received oil level sensor signal, displays that the engine oil level is at a normal value.	Oil level sensor	K
	Engine oil level display	Based on the received oil level sensor signal, displays the engine oil level.	Oil level sensor	
	Engine oil level warning display	Based on the received oil level sensor signal, displays a warning on engine oil level.	Oil level sensor	L
	Transmission oil maintenance display	The distance for transmission oil replacement can be set.	—	M
	Transmission oil maintenance warning display	Displays a warning when the arbitrarily set transmission oil replacement distance is reached.	—	
	Oil filter maintenance display	The distance for oil filter replacement can be set.	—	MWI
Oil filter maintenance warning display	Displays a warning when the arbitrarily set oil filter replacement distance is reached.	—		
Tire maintenance display	The distance for tire replacement can be set.	—	O	
Tire maintenance warning display	Displays a warning when the arbitrarily set tire replacement distance is reached.	—		
Other maintenance display	The replacement distance for the arbitrarily set parts can be set.	—	P	
Other maintenance warning display	Displays a warning when the arbitrarily set parts replacement distance is reached.	—		

METER SYSTEM

< SYSTEM DESCRIPTION >

System	Description	Signal source
Door open warning display	Based on the received door switch signal, displays a warning that a door is ajar.	BCM
Trunk open warning display	Based on the received trunk switch signal, displays a warning that the trunk is ajar.	BCM
Parking brake release warning display	Based on the received parking brake switch signal and vehicle speed signal, displays a warning that the parking brake is not released.	Parking brake switch ABS actuator and electric unit (control unit)
Low fuel warning display	Receives the fuel level sensor signal, and displays a warning if the fuel level decreases to approximately 13.5 ℓ (3-5/8 US gal, 3 Imp gal) or less [1.0 ℓ (1/4 US gal, 1/4 Imp gal) fuel residues included].	Fuel level sensor unit
Low washer fluid warning display	Based on the received washer level switch signal, displays a warning for washer level.	Washer level switch
Engine oil level sensor abnormality warning display	Based on the received oil level sensor signal, displays the engine oil level sensor malfunction warning.	Oil level sensor
Shift lever position warning display	Based on the received shift lever position warning display signal, displays the shift lever position warning.	TCM
Shift " P " warning display	Based on the received shift lever position check display signal, issues a warning to change the shift position to P range.	TCM
Transmission system check display	Based on the received transmission system check display signal, displays that the transmission system check is in progress.	TCM
Run-flat tire warning display	Based on the received run-flat tire warning display signal, displays a warning that the tire is punctured.	Low tire pressure warning control unit
Transmission clutch high temperature warning display	Based on the received transmission clutch high temperature warning display signal, displays a warning that the transmission clutch temperature is high.	TCM
Transmission oil high temperature warning display	Based on the received transmission oil high temperature warning display signal, displays a warning that the transmission oil temperature is high.	TCM
Low tire pressure warning display	Based on the received low tire pressure warning display signal, displays a warning that the tire internal pressure is low.	Low tire pressure warning control unit
AWD clutch high temperature warning display	Based on the received AWD clutch high temperature warning display signal, displays a warning that the AWD clutch temperature is high.	AWD control unit
Front/rear tire size discrepancy warning display	Based on the received front/rear tire size discrepancy warning display signal, displays a warning that there is a difference between front and rear tire speed.	AWD control unit
Transmission system warning display	Based on the received transmission system warning display signal, displays a warning that a malfunction is present in the transmission system.	TCM
Tire pressure monitoring system warning display	Based on the received tire pressure monitoring system warning display signal, displays a warning that an abnormality is present in the tire pressure warning system.	Low tire pressure warning control unit
AWD system warning display	Based on the received AWD system warning display signal, displays a warning that a malfunction is present in the AWD system.	AWD control unit

Information display

METER SYSTEM

< SYSTEM DESCRIPTION >

	System	Description	Signal source	
Information display	Anti-lock braking system (ABS) warning display	Based on the received ABS warning display signal, displays a warning that a malfunction has occurred to ABS.	ABS actuator and electric unit (control unit)	A
	Vehicle dynamic control (VDC) system warning display	Based on the received VDC warning display signal, displays a warning that a malfunction is present in VDC.	ABS actuator and electric unit (control unit)	B
	Engine system warning display	Based on the received engine status signal, displays a warning that a malfunction is present in the engine system.	ECM	C
	CRUISE control system warning display	Based on the received ASCD status signal, detects the CRUISE system malfunction, and displays a warning that an inspection is necessary.	ECM	D
	Engine oil low pressure warning display	Based on the received oil pressure sensor signal, displays a warning that the engine oil pressure is low.	Oil pressure sensor	E
	Low brake fluid warning display	Based on the received brake fluid level switch signal, displays a warning that the brake fluid is decreased.	Brake fluid level switch	F
	Reverse warning	Based on the buzzer output signal (reverse warning chime), displays a warning that the shift position is in R.	BCM	G
	Head lamp warning	Based on the low beam request signal, and LED headlamp warning signal (LH/RH), displays a warning that a malfunction has occurred to LED headlamp.	Front combination lamp BCM	H


ARRANGEMENT OF COMBINATION METER

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MWI

METER SYSTEM

< SYSTEM DESCRIPTION >



A. For U.S.A.


B. For Canada

METER SYSTEM

< SYSTEM DESCRIPTION >

METER SYSTEM : Component Parts Location

INFOID:000000011488236



- | | | |
|---------------------------------|----------------------------------|---------------------------------|
| 1. Fuel level sensor unit (Sub) | 2. Fuel level sensor unit (Main) | 3. Door switch (passenger side) |
| 4. Front combination lamp RH | 5. Oil pressure sensor | 6. Ambient sensor |
| 7. Oil level sensor | 8. Washer level switch | 9. Front combination lamp LH |

JSNIA6899ZZ

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MWI

METER SYSTEM

< SYSTEM DESCRIPTION >

10. AWD control unit	11. Brake fluid level switch	12. ABS actuator and electric unit (control unit)
13. Door switch (driver side)	14. TCM	15. Trunk switch
16. Combination meter	17. Combination switch (Lighting switch)	18. Low tire pressure warning control unit
19. Parking brake	20. BCM	21. ECM
A. Under rear seat	B. Right side of engine	C. Radiator core support (center)
D. Oil pan LH upper	E. Front RH seat under	F. Trunk room left back
G. Lower instrument panel LH	H. Dashboard side lower (passenger seat side)	I. Glove box assembly back

METER SYSTEM : Component Description

INFOID:000000011488237

Unit	Description
Combination meter	Based on received signals from each unit, switch, and sensor, controls the following items. <ul style="list-style-type: none"> • Speedometer • Engine coolant temperature gauge • Warning lamp • Information display • Tachometer • Fuel gauge • Indicator lamp
Fuel level sensor unit	Detects the fuel level in fuel tank using the fuel level sensor unit, and transmits the fuel gauge signal to the combination meter.
Oil pressure sensor	Detects the oil pressure of engine oil, and transmits the oil pressure sensor signal to the combination meter.
ECM	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> • Engine speed signal • Fuel consumption monitor signal • Engine status signal • Engine coolant temperature signal • Malfunction indicator lamp signal • ASCD status signal
ABS actuator and electric unit (control unit)	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> • Vehicle speed signal • VDC warning display signal • ABS warning display signal
BCM	Transmits signals received from each unit and switch to the combination meter via CAN communication.
TCM	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> • Shift position signal • Transmission oil high temperature warning display signal • Transmission system warning display signal • Shift lever position check display signal • Shift lever position warning display signal • Transmission clutch high temperature warning display signal • Transmission system check display signal
AWD control unit	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> • AWD clutch high temperature warning display signal • Front/rear tire size discrepancy warning display signal • AWD system warning display signal
Low tire pressure warning control unit	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> • Run-flat tire warning display signal • Tire pressure monitoring system warning display signal • Low tire pressure warning display signal

METER SYSTEM


< SYSTEM DESCRIPTION >

Unit	Description
Meter control switch	Transmits the following signals to the combination meter. <ul style="list-style-type: none"> • Illumination control switch signal (+) • Trip A/B reset switch signal • Enter switch signal • Illumination control switch signal (-) • Select switch signal
Brake fluid level switch	Transmits the brake fluid level switch signal to the combination meter.
Parking brake switch	Transmits the parking brake switch signal to the combination meter.
Oil level sensor	Transmits the oil level sensor signal to the combination meter.
Washer level switch	Transmits the washer level switch signal to the combination meter.
Ambient sensor	Transmits the ambient sensor signal to the combination meter.
Front combination lamp LH	Transmits the front combination lamp LH signal to the combination meter.
Front combination lamp RH	Transmits the front combination lamp RH signal to the combination meter.

SPEEDOMETER

SPEEDOMETER : System Diagram

INFOID:0000000011488238



SPEEDOMETER : System Description

INFOID:0000000011488239

- ABS actuator and electric unit (control unit) converts the rectangular wave signal from wheel sensor to the vehicle speed signal, and transmits the signal to the combination meter via CAN communication.
- The combination meter receives the vehicle speed signal from the ABS actuator and electric unit (control unit) via CAN communication, and indicates the vehicle speed.


MWI

METER SYSTEM

< SYSTEM DESCRIPTION >

SPEEDOMETER : Component Parts Location

INFOID:000000011488240



JSNIA6899ZZ

- | | | |
|---------------------------------|----------------------------------|---------------------------------|
| 1. Fuel level sensor unit (Sub) | 2. Fuel level sensor unit (Main) | 3. Door switch (passenger side) |
| 4. Front combination lamp RH | 5. Oil pressure sensor | 6. Ambient sensor |
| 7. Oil level sensor | 8. Washer level switch | 9. Front combination lamp LH |

METER SYSTEM

< SYSTEM DESCRIPTION >

- | | | |
|-------------------------------|---|---|
| 10. AWD control unit | 11. Brake fluid level switch | 12. ABS actuator and electric unit (control unit) |
| 13. Door switch (driver side) | 14. TCM | 15. Trunk switch |
| 16. Combination meter | 17. Combination switch (Lighting switch) | 18. Low tire pressure warning control unit |
| 19. Parking brake | 20. BCM | 21. ECM |
| A. Under rear seat | B. Right side of engine | C. Radiator core support (center) |
| D. Oil pan LH upper | E. Front RH seat under | F. Trunk room left back |
| G. Lower instrument panel LH | H. Dashboard side lower (passenger seat side) | I. Glove box assembly back |

SPEEDOMETER : Component Description

INFOID:000000011488241

Unit	Description
Combination meter	Based on received signals from each unit, switch, and sensor, controls the following items. <ul style="list-style-type: none"> Speedometer Engine coolant temperature gauge Warning lamp Information display Tachometer Fuel gauge Indicator lamp
Fuel level sensor unit	Detects the fuel level in fuel tank using the fuel level sensor unit, and transmits the fuel gauge signal to the combination meter.
Oil pressure sensor	Detects the oil pressure of engine oil, and transmits the oil pressure sensor signal to the combination meter.
ECM	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> Engine speed signal Fuel consumption monitor signal Engine status signal Engine coolant temperature signal Malfunction indicator lamp signal ASCd status signal
ABS actuator and electric unit (control unit)	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> Vehicle speed signal VDC warning display signal ABS warning display signal
BCM	Transmits signals received from each unit and switch to the combination meter via CAN communication.
TCM	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> Shift position signal Transmission oil high temperature warning display signal Transmission system warning display signal Shift lever position check display signal Shift lever position warning display signal Transmission clutch high temperature warning display signal Transmission system check display signal
AWD control unit	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> AWD clutch high temperature warning display signal Front/rear tire size discrepancy warning display signal AWD system warning display signal
Low tire pressure warning control unit	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> Run-flat tire warning display signal Tire pressure monitoring system warning display signal Low tire pressure warning display signal

METER SYSTEM


< SYSTEM DESCRIPTION >

Unit	Description
Meter control switch	Transmits the following signals to the combination meter. <ul style="list-style-type: none"> • Illumination control switch signal (+) • Trip A/B reset switch signal • Enter switch signal • Illumination control switch signal (-) • Select switch signal
Brake fluid level switch	Transmits the brake fluid level switch signal to the combination meter.
Parking brake switch	Transmits the parking brake switch signal to the combination meter.
Oil level sensor	Transmits the oil level sensor signal to the combination meter.
Washer level switch	Transmits the washer level switch signal to the combination meter.
Ambient sensor	Transmits the ambient sensor signal to the combination meter.
Front combination lamp LH	Transmits the front combination lamp LH signal to the combination meter.
Front combination lamp RH	Transmits the front combination lamp RH signal to the combination meter.

TACHOMETER

TACHOMETER : System Diagram

INFOID:000000011488242



TACHOMETER : System Description

INFOID:000000011488243


- ECM reads the crankshaft position signal from the crankshaft position sensor, and transmits the engine speed signal to the combination meter via CAN communication.
- The combination meter receives the engine speed signal from ECM via CAN communication, and indicates the engine speed.

METER SYSTEM

< SYSTEM DESCRIPTION >

TACHOMETER : Component Parts Location

INFOID:000000011488244



- | | | |
|---------------------------------|----------------------------------|---------------------------------|
| 1. Fuel level sensor unit (Sub) | 2. Fuel level sensor unit (Main) | 3. Door switch (passenger side) |
| 4. Front combination lamp RH | 5. Oil pressure sensor | 6. Ambient sensor |
| 7. Oil level sensor | 8. Washer level switch | 9. Front combination lamp LH |

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MWI

METER SYSTEM

< SYSTEM DESCRIPTION >

10. AWD control unit	11. Brake fluid level switch	12. ABS actuator and electric unit (control unit)
13. Door switch (driver side)	14. TCM	15. Trunk switch
16. Combination meter	17. Combination switch (Lighting switch)	18. Low tire pressure warning control unit
19. Parking brake	20. BCM	21. ECM
A. Under rear seat	B. Right side of engine	C. Radiator core support (center)
D. Oil pan LH upper	E. Front RH seat under	F. Trunk room left back
G. Lower instrument panel LH	H. Dashboard side lower (passenger seat side)	I. Glove box assembly back

TACHOMETER : Component Description

INFOID:000000011488245

Unit	Description
Combination meter	Based on received signals from each unit, switch, and sensor, controls the following items. <ul style="list-style-type: none"> Speedometer Engine coolant temperature gauge Warning lamp Information display Tachometer Fuel gauge Indicator lamp
Fuel level sensor unit	Detects the fuel level in fuel tank using the fuel level sensor unit, and transmits the fuel gauge signal to the combination meter.
Oil pressure sensor	Detects the oil pressure of engine oil, and transmits the oil pressure sensor signal to the combination meter.
ECM	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> Engine speed signal Fuel consumption monitor signal Engine status signal Engine coolant temperature signal Malfunction indicator lamp signal ASCD status signal
ABS actuator and electric unit (control unit)	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> Vehicle speed signal VDC warning display signal ABS warning display signal
BCM	Transmits signals received from each unit and switch to the combination meter via CAN communication.
TCM	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> Shift position signal Transmission oil high temperature warning display signal Transmission system warning display signal Shift lever position check display signal Shift lever position warning display signal Transmission clutch high temperature warning display signal Transmission system check display signal
AWD control unit	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> AWD clutch high temperature warning display signal Front/rear tire size discrepancy warning display signal AWD system warning display signal
Low tire pressure warning control unit	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> Run-flat tire warning display signal Tire pressure monitoring system warning display signal Low tire pressure warning display signal

METER SYSTEM


< SYSTEM DESCRIPTION >

Unit	Description
Meter control switch	Transmits the following signals to the combination meter. <ul style="list-style-type: none"> • Illumination control switch signal (+) • Trip A/B reset switch signal • Enter switch signal • Illumination control switch signal (-) • Select switch signal
Brake fluid level switch	Transmits the brake fluid level switch signal to the combination meter.
Parking brake switch	Transmits the parking brake switch signal to the combination meter.
Oil level sensor	Transmits the oil level sensor signal to the combination meter.
Washer level switch	Transmits the washer level switch signal to the combination meter.
Ambient sensor	Transmits the ambient sensor signal to the combination meter.
Front combination lamp LH	Transmits the front combination lamp LH signal to the combination meter.
Front combination lamp RH	Transmits the front combination lamp RH signal to the combination meter.

ENGINE COOLANT TEMPERATURE GAUGE

ENGINE COOLANT TEMPERATURE GAUGE : System Diagram

INFOID:000000011488246



ENGINE COOLANT TEMPERATURE GAUGE : System Description

INFOID:000000011488247

- ECM reads the engine coolant temperature signal from the engine coolant temperature sensor, and transmits the signal to the combination meter via CAN communication.
- The combination meter receives the engine coolant temperature signal from ECM via CAN communication, and indicates the engine coolant temperature.


MWI

METER SYSTEM

< SYSTEM DESCRIPTION >

ENGINE COOLANT TEMPERATURE GAUGE : Component Parts Location

INFOID:000000011488248



JSNIA6899ZZ

- | | | |
|---------------------------------|----------------------------------|---------------------------------|
| 1. Fuel level sensor unit (Sub) | 2. Fuel level sensor unit (Main) | 3. Door switch (passenger side) |
| 4. Front combination lamp RH | 5. Oil pressure sensor | 6. Ambient sensor |
| 7. Oil level sensor | 8. Washer level switch | 9. Front combination lamp LH |

METER SYSTEM

< SYSTEM DESCRIPTION >

- | | | |
|-------------------------------|---|---|
| 10. AWD control unit | 11. Brake fluid level switch | 12. ABS actuator and electric unit (control unit) |
| 13. Door switch (driver side) | 14. TCM | 15. Trunk switch |
| 16. Combination meter | 17. Combination switch (Lighting switch) | 18. Low tire pressure warning control unit |
| 19. Parking brake | 20. BCM | 21. ECM |
| A. Under rear seat | B. Right side of engine | C. Radiator core support (center) |
| D. Oil pan LH upper | E. Front RH seat under | F. Trunk room left back |
| G. Lower instrument panel LH | H. Dashboard side lower (passenger seat side) | I. Glove box assembly back |

A
B
C
D
E
F
G
H
I
J
K
L
M
MWI
O
P

ENGINE COOLANT TEMPERATURE GAUGE : Component Description

INFOID:000000011488249

Unit	Description
Combination meter	Based on received signals from each unit, switch, and sensor, controls the following items. <ul style="list-style-type: none"> Speedometer Engine coolant temperature gauge Warning lamp Information display Tachometer Fuel gauge Indicator lamp
Fuel level sensor unit	Detects the fuel level in fuel tank using the fuel level sensor unit, and transmits the fuel gauge signal to the combination meter.
Oil pressure sensor	Detects the oil pressure of engine oil, and transmits the oil pressure sensor signal to the combination meter.
ECM	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> Engine speed signal Fuel consumption monitor signal Engine status signal Engine coolant temperature signal Malfunction indicator lamp signal ASCd status signal
ABS actuator and electric unit (control unit)	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> Vehicle speed signal VDC warning display signal ABS warning display signal
BCM	Transmits signals received from each unit and switch to the combination meter via CAN communication.
TCM	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> Shift position signal Transmission oil high temperature warning display signal Transmission system warning display signal Shift lever position check display signal Shift lever position warning display signal Transmission clutch high temperature warning display signal Transmission system check display signal
AWD control unit	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> AWD clutch high temperature warning display signal Front/rear tire size discrepancy warning display signal AWD system warning display signal
Low tire pressure warning control unit	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> Run-flat tire warning display signal Tire pressure monitoring system warning display signal Low tire pressure warning display signal

METER SYSTEM


< SYSTEM DESCRIPTION >

Unit	Description
Meter control switch	Transmits the following signals to the combination meter. <ul style="list-style-type: none"> • Illumination control switch signal (+) • Trip A/B reset switch signal • Enter switch signal • Illumination control switch signal (-) • Select switch signal
Brake fluid level switch	Transmits the brake fluid level switch signal to the combination meter.
Parking brake switch	Transmits the parking brake switch signal to the combination meter.
Oil level sensor	Transmits the oil level sensor signal to the combination meter.
Washer level switch	Transmits the washer level switch signal to the combination meter.
Ambient sensor	Transmits the ambient sensor signal to the combination meter.
Front combination lamp LH	Transmits the front combination lamp LH signal to the combination meter.
Front combination lamp RH	Transmits the front combination lamp RH signal to the combination meter.

FUEL GAUGE

FUEL GAUGE : System Diagram

INFOID:000000011488250



FUEL GAUGE : System Description

INFOID:000000011488251

CONTROL OUTLINE

The combination meter reads the fuel level sensor signal (resistance value) from the fuel level sensor unit, and indicates the fuel level to the fuel gauge.

REFUEL CONTROL

When the ignition switch is turned from OFF to ON, or when all the following conditions are met, it performs a control to move the fuel gauge pointer faster than normal.


- Ignition switch ON
- Vehicle stop status
- Fuel level fluctuation is 15 ℓ (4 US gal, 3-1/4 Imp gal) or more.

METER SYSTEM

< SYSTEM DESCRIPTION >

FUEL GAUGE : Component Parts Location

INFOID:000000011488252



- | | | |
|---------------------------------|----------------------------------|---------------------------------|
| 1. Fuel level sensor unit (Sub) | 2. Fuel level sensor unit (Main) | 3. Door switch (passenger side) |
| 4. Front combination lamp RH | 5. Oil pressure sensor | 6. Ambient sensor |
| 7. Oil level sensor | 8. Washer level switch | 9. Front combination lamp LH |

JSNIA6899ZZ

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MWI

METER SYSTEM

< SYSTEM DESCRIPTION >

10. AWD control unit	11. Brake fluid level switch	12. ABS actuator and electric unit (control unit)
13. Door switch (driver side)	14. TCM	15. Trunk switch
16. Combination meter	17. Combination switch (Lighting switch)	18. Low tire pressure warning control unit
19. Parking brake	20. BCM	21. ECM
A. Under rear seat	B. Right side of engine	C. Radiator core support (center)
D. Oil pan LH upper	E. Front RH seat under	F. Trunk room left back
G. Lower instrument panel LH	H. Dashboard side lower (passenger seat side)	I. Glove box assembly back

FUEL GAUGE : Component Description

INFOID:000000011488253

Unit	Description
Combination meter	Based on received signals from each unit, switch, and sensor, controls the following items. <ul style="list-style-type: none"> • Speedometer • Engine coolant temperature gauge • Warning lamp • Information display • Tachometer • Fuel gauge • Indicator lamp
Fuel level sensor unit	Detects the fuel level in fuel tank using the fuel level sensor unit, and transmits the fuel gauge signal to the combination meter.
Oil pressure sensor	Detects the oil pressure of engine oil, and transmits the oil pressure sensor signal to the combination meter.
ECM	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> • Engine speed signal • Fuel consumption monitor signal • Engine status signal • Engine coolant temperature signal • Malfunction indicator lamp signal • ASCD status signal
ABS actuator and electric unit (control unit)	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> • Vehicle speed signal • VDC warning display signal • ABS warning display signal
BCM	Transmits signals received from each unit and switch to the combination meter via CAN communication.
TCM	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> • Shift position signal • Transmission oil high temperature warning display signal • Transmission system warning display signal • Shift lever position check display signal • Shift lever position warning display signal • Transmission clutch high temperature warning display signal • Transmission system check display signal
AWD control unit	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> • AWD clutch high temperature warning display signal • Front/rear tire size discrepancy warning display signal • AWD system warning display signal
Low tire pressure warning control unit	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> • Run-flat tire warning display signal • Tire pressure monitoring system warning display signal • Low tire pressure warning display signal


METER SYSTEM

< SYSTEM DESCRIPTION >

Unit	Description
Meter control switch	Transmits the following signals to the combination meter. <ul style="list-style-type: none"> • Illumination control switch signal (+) • Trip A/B reset switch signal • Enter switch signal • Illumination control switch signal (-) • Select switch signal
Brake fluid level switch	Transmits the brake fluid level switch signal to the combination meter.
Parking brake switch	Transmits the parking brake switch signal to the combination meter.
Oil level sensor	Transmits the oil level sensor signal to the combination meter.
Washer level switch	Transmits the washer level switch signal to the combination meter.
Ambient sensor	Transmits the ambient sensor signal to the combination meter.
Front combination lamp LH	Transmits the front combination lamp LH signal to the combination meter.
Front combination lamp RH	Transmits the front combination lamp RH signal to the combination meter.

ODO/TRIP METER

ODO/TRIP METER : System Diagram



ODO/TRIP METER : System Description

INFOID:0000000011488255

- ABS actuator control unit reads the rectangular wave signal received from wheel sensor, and transmits the vehicle speed signal to the combination meter via CAN communication.
- The combination meter receives the vehicle speed signal from the ABS actuator and electric unit (control unit) via CAN communication, then calculates and displays the travel distance.


MWI

METER SYSTEM

< SYSTEM DESCRIPTION >

ODO/TRIP METER : Component Parts Location

INFOID:000000011488256



JSNIA6899ZZ

- | | | |
|---------------------------------|----------------------------------|---------------------------------|
| 1. Fuel level sensor unit (Sub) | 2. Fuel level sensor unit (Main) | 3. Door switch (passenger side) |
| 4. Front combination lamp RH | 5. Oil pressure sensor | 6. Ambient sensor |
| 7. Oil level sensor | 8. Washer level switch | 9. Front combination lamp LH |

METER SYSTEM

< SYSTEM DESCRIPTION >

- | | | |
|-------------------------------|---|---|
| 10. AWD control unit | 11. Brake fluid level switch | 12. ABS actuator and electric unit (control unit) |
| 13. Door switch (driver side) | 14. TCM | 15. Trunk switch |
| 16. Combination meter | 17. Combination switch (Lighting switch) | 18. Low tire pressure warning control unit |
| 19. Parking brake | 20. BCM | 21. ECM |
| A. Under rear seat | B. Right side of engine | C. Radiator core support (center) |
| D. Oil pan LH upper | E. Front RH seat under | F. Trunk room left back |
| G. Lower instrument panel LH | H. Dashboard side lower (passenger seat side) | I. Glove box assembly back |

ODO/TRIP METER : Component Description

INFOID:000000011488257

Unit	Description
Combination meter	Based on received signals from each unit, switch, and sensor, controls the following items. <ul style="list-style-type: none"> Speedometer Engine coolant temperature gauge Warning lamp Information display Tachometer Fuel gauge Indicator lamp
Fuel level sensor unit	Detects the fuel level in fuel tank using the fuel level sensor unit, and transmits the fuel gauge signal to the combination meter.
Oil pressure sensor	Detects the oil pressure of engine oil, and transmits the oil pressure sensor signal to the combination meter.
ECM	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> Engine speed signal Fuel consumption monitor signal Engine status signal Engine coolant temperature signal Malfunction indicator lamp signal ASCd status signal
ABS actuator and electric unit (control unit)	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> Vehicle speed signal VDC warning display signal ABS warning display signal
BCM	Transmits signals received from each unit and switch to the combination meter via CAN communication.
TCM	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> Shift position signal Transmission oil high temperature warning display signal Transmission system warning display signal Shift lever position check display signal Shift lever position warning display signal Transmission clutch high temperature warning display signal Transmission system check display signal
AWD control unit	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> AWD clutch high temperature warning display signal Front/rear tire size discrepancy warning display signal AWD system warning display signal
Low tire pressure warning control unit	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> Run-flat tire warning display signal Tire pressure monitoring system warning display signal Low tire pressure warning display signal

METER SYSTEM


< SYSTEM DESCRIPTION >

Unit	Description
Meter control switch	Transmits the following signals to the combination meter. <ul style="list-style-type: none"> • Illumination control switch signal (+) • Trip A/B reset switch signal • Enter switch signal • Illumination control switch signal (-) • Select switch signal
Brake fluid level switch	Transmits the brake fluid level switch signal to the combination meter.
Parking brake switch	Transmits the parking brake switch signal to the combination meter.
Oil level sensor	Transmits the oil level sensor signal to the combination meter.
Washer level switch	Transmits the washer level switch signal to the combination meter.
Ambient sensor	Transmits the ambient sensor signal to the combination meter.
Front combination lamp LH	Transmits the front combination lamp LH signal to the combination meter.
Front combination lamp RH	Transmits the front combination lamp RH signal to the combination meter.

SHIFT POSITION INDICATOR

SHIFT POSITION INDICATOR : System Diagram

INFOID:000000011488258



SHIFT POSITION INDICATOR : System Description

INFOID:000000011488259


- The combination meter receives the shift position signal from TCM via CAN communication, and displays the shift position to the shift position indicator.
- The combination meter receives the shift position signal from TCM via CAN communication. If the status does not allow a shift change, it blinks the shift position indicator.

METER SYSTEM

< SYSTEM DESCRIPTION >

SHIFT POSITION INDICATOR : Component Parts Location

INFOID:000000011488260



- | | | |
|---------------------------------|----------------------------------|---------------------------------|
| 1. Fuel level sensor unit (Sub) | 2. Fuel level sensor unit (Main) | 3. Door switch (passenger side) |
| 4. Front combination lamp RH | 5. Oil pressure sensor | 6. Ambient sensor |
| 7. Oil level sensor | 8. Washer level switch | 9. Front combination lamp LH |

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MWI

JSNIA6899ZZ

METER SYSTEM

< SYSTEM DESCRIPTION >

10. AWD control unit	11. Brake fluid level switch	12. ABS actuator and electric unit (control unit)
13. Door switch (driver side)	14. TCM	15. Trunk switch
16. Combination meter	17. Combination switch (Lighting switch)	18. Low tire pressure warning control unit
19. Parking brake	20. BCM	21. ECM
A. Under rear seat	B. Right side of engine	C. Radiator core support (center)
D. Oil pan LH upper	E. Front RH seat under	F. Trunk room left back
G. Lower instrument panel LH	H. Dashboard side lower (passenger seat side)	I. Glove box assembly back

SHIFT POSITION INDICATOR : Component Description

INFOID:000000011488261

Unit	Description
Combination meter	Based on received signals from each unit, switch, and sensor, controls the following items. <ul style="list-style-type: none"> • Speedometer • Engine coolant temperature gauge • Warning lamp • Information display • Tachometer • Fuel gauge • Indicator lamp
Fuel level sensor unit	Detects the fuel level in fuel tank using the fuel level sensor unit, and transmits the fuel gauge signal to the combination meter.
Oil pressure sensor	Detects the oil pressure of engine oil, and transmits the oil pressure sensor signal to the combination meter.
ECM	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> • Engine speed signal • Fuel consumption monitor signal • Engine status signal • Engine coolant temperature signal • Malfunction indicator lamp signal • ASCD status signal
ABS actuator and electric unit (control unit)	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> • Vehicle speed signal • VDC warning display signal • ABS warning display signal
BCM	Transmits signals received from each unit and switch to the combination meter via CAN communication.
TCM	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> • Shift position signal • Transmission oil high temperature warning display signal • Transmission system warning display signal • Shift lever position check display signal • Shift lever position warning display signal • Transmission clutch high temperature warning display signal • Transmission system check display signal
AWD control unit	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> • AWD clutch high temperature warning display signal • Front/rear tire size discrepancy warning display signal • AWD system warning display signal
Low tire pressure warning control unit	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> • Run-flat tire warning display signal • Tire pressure monitoring system warning display signal • Low tire pressure warning display signal

METER SYSTEM


< SYSTEM DESCRIPTION >

Unit	Description
Meter control switch	Transmits the following signals to the combination meter. <ul style="list-style-type: none"> • Illumination control switch signal (+) • Trip A/B reset switch signal • Enter switch signal • Illumination control switch signal (-) • Select switch signal
Brake fluid level switch	Transmits the brake fluid level switch signal to the combination meter.
Parking brake switch	Transmits the parking brake switch signal to the combination meter.
Oil level sensor	Transmits the oil level sensor signal to the combination meter.
Washer level switch	Transmits the washer level switch signal to the combination meter.
Ambient sensor	Transmits the ambient sensor signal to the combination meter.
Front combination lamp LH	Transmits the front combination lamp LH signal to the combination meter.
Front combination lamp RH	Transmits the front combination lamp RH signal to the combination meter.

OIL PRESSURE WARNING LAMP

OIL PRESSURE WARNING LAMP : System Diagram

INFOID:000000011488262



OIL PRESSURE WARNING LAMP : System Description

INFOID:000000011488263

OIL PRESSURE WARNING LAMP

Control Outline

The combination meter reads the oil pressure sensor signal from oil pressure sensor, and illuminates/turns off the oil pressure warning lamp.

NOTE:

The display of engine oil pressure warning on the information display is shown/turned off simultaneously with the illumination/turning off of the oil pressure warning lamp.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P


MWI

METER SYSTEM

< SYSTEM DESCRIPTION >

OIL PRESSURE WARNING LAMP : Component Parts Location

INFOID:000000011488264



JSNIA6899ZZ

- | | | |
|---------------------------------|----------------------------------|---------------------------------|
| 1. Fuel level sensor unit (Sub) | 2. Fuel level sensor unit (Main) | 3. Door switch (passenger side) |
| 4. Front combination lamp RH | 5. Oil pressure sensor | 6. Ambient sensor |
| 7. Oil level sensor | 8. Washer level switch | 9. Front combination lamp LH |

METER SYSTEM

< SYSTEM DESCRIPTION >

- | | | |
|-------------------------------|---|---|
| 10. AWD control unit | 11. Brake fluid level switch | 12. ABS actuator and electric unit (control unit) |
| 13. Door switch (driver side) | 14. TCM | 15. Trunk switch |
| 16. Combination meter | 17. Combination switch (Lighting switch) | 18. Low tire pressure warning control unit |
| 19. Parking brake | 20. BCM | 21. ECM |
| A. Under rear seat | B. Right side of engine | C. Radiator core support (center) |
| D. Oil pan LH upper | E. Front RH seat under | F. Trunk room left back |
| G. Lower instrument panel LH | H. Dashboard side lower (passenger seat side) | I. Glove box assembly back |

OIL PRESSURE WARNING LAMP : Component Description

INFOID:000000011488265

Unit	Description
Combination meter	Based on received signals from each unit, switch, and sensor, controls the following items. <ul style="list-style-type: none"> Speedometer Engine coolant temperature gauge Warning lamp Information display Tachometer Fuel gauge Indicator lamp
Fuel level sensor unit	Detects the fuel level in fuel tank using the fuel level sensor unit, and transmits the fuel gauge signal to the combination meter.
Oil pressure sensor	Detects the oil pressure of engine oil, and transmits the oil pressure sensor signal to the combination meter.
ECM	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> Engine speed signal Fuel consumption monitor signal Engine status signal Engine coolant temperature signal Malfunction indicator lamp signal ASCd status signal
ABS actuator and electric unit (control unit)	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> Vehicle speed signal VDC warning display signal ABS warning display signal
BCM	Transmits signals received from each unit and switch to the combination meter via CAN communication.
TCM	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> Shift position signal Transmission oil high temperature warning display signal Transmission system warning display signal Shift lever position check display signal Shift lever position warning display signal Transmission clutch high temperature warning display signal Transmission system check display signal
AWD control unit	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> AWD clutch high temperature warning display signal Front/rear tire size discrepancy warning display signal AWD system warning display signal
Low tire pressure warning control unit	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> Run-flat tire warning display signal Tire pressure monitoring system warning display signal Low tire pressure warning display signal

METER SYSTEM


< SYSTEM DESCRIPTION >

Unit	Description
Meter control switch	Transmits the following signals to the combination meter. <ul style="list-style-type: none"> • Illumination control switch signal (+) • Trip A/B reset switch signal • Enter switch signal • Illumination control switch signal (-) • Select switch signal
Brake fluid level switch	Transmits the brake fluid level switch signal to the combination meter.
Parking brake switch	Transmits the parking brake switch signal to the combination meter.
Oil level sensor	Transmits the oil level sensor signal to the combination meter.
Washer level switch	Transmits the washer level switch signal to the combination meter.
Ambient sensor	Transmits the ambient sensor signal to the combination meter.
Front combination lamp LH	Transmits the front combination lamp LH signal to the combination meter.
Front combination lamp RH	Transmits the front combination lamp RH signal to the combination meter.

METER ILLUMINATION CONTROL

METER ILLUMINATION CONTROL : System Diagram

INFOID:000000011488266




METER ILLUMINATION CONTROL : System Description

INFOID:000000011488267

METER ILLUMINATION CONTROL FUNCTION

Every time when the illumination control switch (1) is pressed, the illuminance of meter illumination can be adjusted in 22 steps. (Illuminance can be adjusted both in daytime and nighttime modes.)




METER SYSTEM

< SYSTEM DESCRIPTION >

METER ILLUMINATION CONTROL : Component Parts Location

INFOID:000000011488268



- | | | |
|---------------------------------|----------------------------------|---------------------------------|
| 1. Fuel level sensor unit (Sub) | 2. Fuel level sensor unit (Main) | 3. Door switch (passenger side) |
| 4. Front combination lamp RH | 5. Oil pressure sensor | 6. Ambient sensor |
| 7. Oil level sensor | 8. Washer level switch | 9. Front combination lamp LH |

JSNIA6899ZZ

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MWI

METER SYSTEM

< SYSTEM DESCRIPTION >

10. AWD control unit	11. Brake fluid level switch	12. ABS actuator and electric unit (control unit)
13. Door switch (driver side)	14. TCM	15. Trunk switch
16. Combination meter	17. Combination switch (Lighting switch)	18. Low tire pressure warning control unit
19. Parking brake	20. BCM	21. ECM
A. Under rear seat	B. Right side of engine	C. Radiator core support (center)
D. Oil pan LH upper	E. Front RH seat under	F. Trunk room left back
G. Lower instrument panel LH	H. Dashboard side lower (passenger seat side)	I. Glove box assembly back

METER ILLUMINATION CONTROL : Component Description

INFOID:000000011488269

Unit	Description
Combination meter	Based on received signals from each unit, switch, and sensor, controls the following items. <ul style="list-style-type: none"> Speedometer Engine coolant temperature gauge Warning lamp Information display Tachometer Fuel gauge Indicator lamp
Fuel level sensor unit	Detects the fuel level in fuel tank using the fuel level sensor unit, and transmits the fuel gauge signal to the combination meter.
Oil pressure sensor	Detects the oil pressure of engine oil, and transmits the oil pressure sensor signal to the combination meter.
ECM	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> Engine speed signal Fuel consumption monitor signal Engine status signal Engine coolant temperature signal Malfunction indicator lamp signal ASCD status signal
ABS actuator and electric unit (control unit)	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> Vehicle speed signal VDC warning display signal ABS warning display signal
BCM	Transmits signals received from each unit and switch to the combination meter via CAN communication.
TCM	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> Shift position signal Transmission oil high temperature warning display signal Transmission system warning display signal Shift lever position check display signal Shift lever position warning display signal Transmission clutch high temperature warning display signal Transmission system check display signal
AWD control unit	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> AWD clutch high temperature warning display signal Front/rear tire size discrepancy warning display signal AWD system warning display signal
Low tire pressure warning control unit	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> Run-flat tire warning display signal Tire pressure monitoring system warning display signal Low tire pressure warning display signal

METER SYSTEM


< SYSTEM DESCRIPTION >

Unit	Description
Meter control switch	Transmits the following signals to the combination meter. <ul style="list-style-type: none"> • Illumination control switch signal (+) • Trip A/B reset switch signal • Enter switch signal • Illumination control switch signal (-) • Select switch signal
Brake fluid level switch	Transmits the brake fluid level switch signal to the combination meter.
Parking brake switch	Transmits the parking brake switch signal to the combination meter.
Oil level sensor	Transmits the oil level sensor signal to the combination meter.
Washer level switch	Transmits the washer level switch signal to the combination meter.
Ambient sensor	Transmits the ambient sensor signal to the combination meter.
Front combination lamp LH	Transmits the front combination lamp LH signal to the combination meter.
Front combination lamp RH	Transmits the front combination lamp RH signal to the combination meter.

INFORMATION DISPLAY

INFORMATION DISPLAY : System Diagram

INFOID:000000011488270



INFORMATION DISPLAY : System Description

INFOID:000000011488271

DESCRIPTION

- The combination meter inputs the information required to control the operation of information display by using the communication signals and others from each unit.
- The combination meter integrates the drive computer function, and performs the warning display/information display by using the signals received from each unit, sensor, and switch.
- When the enter switch signal or select switch signal is received, the combination meter can check, change screens, perform setting, or reset the warning, indication, information, and setting on the information display.

INSTANTANEOUS FUEL CONSUMPTION

Control Outline

METER SYSTEM

< SYSTEM DESCRIPTION >

- The combination meter receives the fuel consumption monitor signal from ECM and the vehicle speed signal from the ABS actuator control unit via CAN communication.
- Based on the fuel consumption monitor signal and vehicle speed signal that are received via CAN communication, the combination meter calculates the instantaneous fuel consumption, and displays the result.

VEHICLE SPEED

Control Outline

- The combination meter receives the vehicle speed signal from the ABS actuator and electric unit (control unit) via CAN communication.
- Based on the vehicle speed signal received via CAN communication, the combination meter displays the vehicle speed.

CRUISE CONTROL SYSTEM STATUS

Control Outline

- The combination meter receives the ASCD status signal from ECM via CAN communication.
- Based on the ASCD status signal received via CAN communication, the combination meter displays the CRUISE control system setting status.

NOTE:

When the CRUISE control system is OFF, the CRUISE control system status is not displayed.

AVERAGE FUEL CONSUMPTION

Control Outline

- The combination meter receives the fuel consumption monitor signal from ECM and the vehicle speed signal from the ABS actuator control unit via CAN communication.
- Based on the fuel consumption monitor signal and vehicle speed signal that are received via CAN communication, the combination meter calculates the average fuel consumption, and displays the result.
- The average fuel consumption displayed on the information display is updated at approximately 30-second intervals.

NOTE:

“—” is displayed for approximately 30 seconds just after the reset operation and after the ignition switch is OFF → ON. It is displayed simultaneously until the vehicle is driven approximately 500 m (0.3 mile).

AVERAGE VEHICLE SPEED

Control Outline

- The combination meter receives the vehicle speed signal from the ABS actuator and electric unit (control unit) via CAN communication.
- Based on the vehicle speed signal received via CAN communication and on the travel time measured in combination meter, the combination meter calculates the average vehicle speed, and displays the result.
- The average vehicle speed displayed on the information display is updated at approximately 30-second intervals.

NOTE:

“—” is displayed for 30 seconds just after the reset operation and after the ignition switch is OFF → ON. It is displayed simultaneously until the vehicle is driven approximately 500 m (0.3 mile).

TRAVEL TIME

Control Outline

The combination meter measures and displays travel time (ignition switch ON time).

TRAVEL DISTANCE

Control Outline

The combination meter receives the vehicle speed signal from the ABS actuator and electric unit (control unit) via CAN communication, then calculates and displays the travel distance.

POSSIBLE DRIVING DISTANCE

Control Outline

- The combination meter receives the fuel consumption monitor signal from ECM and the vehicle speed signal from the ABS actuator control unit via CAN communication.
- Based on the signal received via CAN communication and on the fuel level sensor signal received from the fuel level sensor unit, the combination meter calculates the possible driving distance, and displays the result.

METER SYSTEM

< SYSTEM DESCRIPTION >

NOTE:

- “_____” is displayed for 30 seconds after the ignition switch is OFF → ON. It is displayed simultaneously until the vehicle is driven approximately 500 m (0.3 mile).
- The indicated values may not match each other when refueling with the ignition switch ON. Refer to [MWI-24, "FUEL GAUGE : System Description"](#).

AMBIENT AIR TEMPERATURE

- Combination meter calculates outside air temperature based on the signal received from ambient sensor, and displays the result on information display.
- Combination meter corrects the indicated temperature using ignition switch signal, ambient sensor signal and vehicle speed signal.

Correction Process (Right after ignition switch is turned ON)

The detected temperature by ambient sensor is displayed when the vehicle enters in both of the following condition.

- When the detected temperature is higher than the indicated temperature on information display.
- When the duration of ignition switch OFF to ON is long.

The last indicated temperature is displayed when the vehicle enters in either of the following conditions.

- When the detected temperature by ambient sensor is lower than the indicated temperature on information display.
- When the duration of ignition switch OFF to ON is short.

Correction Process (When the ignition switch is ON)

The detected temperature by ambient sensor is displayed under the following condition.

- When the detected temperature is lower than the indicated temperature on information display.

The indicated temperature is not updated under the following condition.

- When the detected temperature by ambient sensor is higher than the indicated temperature on information display [at a speed of 20 km/h (12 MPH) or less].

The indicated temperature on information display rises slowly to reach the detected temperature by ambient sensor under the following condition.

- When the detected temperature is higher than the indicated temperature on information display [at a speed of more than 20 km/h (12 MPH)].

The indicated temperature on information display rises to reach the detected temperature by ambient sensor under the following condition.

- When the detected temperature is higher than the indicated temperature on information display [while driving a certain period of time at a speed of more than 20 km/h (12 MPH)].

NOTE:

- “_____” is displayed for 2.5 seconds right after ignition switch is turned ON.
- The input value of ambient sensor, displayed on CONSULT data monitor, is the direct reading before correction. (This means that the reading may not match the indicated temperature on information display.)
- If a battery or combination meter is removed and installed, the detected temperature by ambient sensor is displayed, right after ignition switch is turned ON.
- The indicated temperature may be higher than the actual temperature because of heat radiation from engine or reflection of heat on road surface.

SETTING

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

METER SYSTEM

< SYSTEM DESCRIPTION >

Setting item list

Items			Setting range	Setting unit (Press and hold for 1 second or more)	Description	
Alert	Up shift		AUTO, OFF, 3000 rpm – 6300 rpm	100 rpm (500 rpm)	The engine speed signal is received from ECM via CAN communication, and the up-shift indicator can be set to ON/blink/OFF depending on the engine speed.	
	Timer		OFF, 0.5HOUR–6HOUR	30 minutes (60 minutes)	An alarm message is displayed on the information display when the set travel time is reached.	
	ICY		ON/OFF	—	When the ambient air temperature becomes 3 °C (37 °F) or lower, the ambient sensor signal is received from the ambient sensor and a freeze caution alarm message is displayed on the information display.	
Maintenance	Oil	Engine	Replacement distance	No setting – 15000 km No setting – 9500 miles	500 km (1000 km) 250 miles (500 miles)	<ul style="list-style-type: none"> An engine oil replacement distance warning is displayed on the information display. When the set distance is reached, a warning is displayed requesting replacement of the engine oil.
			Remaining amount	—	—	<ul style="list-style-type: none"> The oil level sensor signal is received from oil level sensor, and the engine oil level is displayed in 5 steps. The oil level sensor signal is received from the oil level sensor, and an indication is displayed that the engine oil level is at a normal value. The oil level sensor signal is received from the oil level sensor, and an indication is displayed that the engine oil level is abnormal.
		Transmission	Replacement distance	No setting – 90000 km No setting – 55500 miles	500 km (1000 km) 250 miles (500 miles)	When the set distance is reached, a warning is displayed requesting replacement of the transmission oil.
	Filter		Replacement distance	No setting – 15000 km No setting – 9500 miles	500 km (1000 km) 250 miles (500 miles)	When the set distance is reached, a warning is displayed requesting replacement of the oil filter.
	Tire		Replacement distance	No setting – 30000 km No setting – 18500 miles	500 km (1000 km) 250 miles (500 miles)	When the set distance is reached, a warning is displayed requesting replacement of the tires.
Options	Language	ENGLISH/FRANCAIS		—	—	Changing the language setting can be performed.
	Unit	METRIC/US		—	—	Changing the unit setting can be performed.

NOTE:
Engine oil level display

METER SYSTEM

< SYSTEM DESCRIPTION >

When the following conditions are satisfied, the combination meter reads the resistance value of oil level sensor, and displays the oil level on the information display. The combination meter does not read the oil level sensor resistance value within 5 minutes after the previous reading of oil level sensor resistance value by the combination meter.

1. Turn the ignition switch OFF.
2. Wait for 5 minutes or more, then open the driver door.

DOOR OPEN WARNING

Control Outline

The combination meter receives the door switch signal from BCM via CAN communication, then judges and displays the door open warning.

TRUNK OPEN WARNING

Control Outline

The combination meter receives the trunk switch signal from BCM via CAN communication, then judges and displays the trunk open warning.

PARKING BRAKE RELEASE WARNING

Control Outline

Based on the vehicle speed signal received from ABS actuator and electric unit (control unit) via CAN communication and on the parking brake switch signal received from parking brake switch, the combination meter judges and displays the parking brake release warning.

Warning Operation Condition

The system judges that the parking brake is not released when the following conditions are satisfied.

- Vehicle speed is 7 km/h (4.3 MPH) or higher
- Parking brake switch ON

LOW FUEL WARNING

Control Outline

- Using the fuel gauge signal sent from the fuel level sensor unit, the combination meter judges and displays the fuel level warning.

Warning Operation Condition

- Fuel level: Approximately 13.5 ℓ (3-5/8 US gal, 3 Imp gal) or less [1.0 ℓ (1/4 US gal, 1/4 Imp gal) fuel residues included].


LOW WASHER FLUID WARNING

Control Outline

- The combination meter receives the washer level switch signal from the washer level switch.
- Based on the received washer level switch signal, the combination meter displays the low washer fluid warning.

Warning Operation Condition

- The low washer fluid warning is displayed if the washer level switch remains ON for 180 seconds or more.
- Even when the washer level switch is turned OFF while displaying the low washer fluid warning, the warning remains displayed if it is within 30 seconds.



ENGINE OIL LEVEL SENSOR ABNORMALITY WARNING

Control Outline

A
B
C
D
E
F
G
H
I
J
K
L
M
MWI
O
P

METER SYSTEM

< SYSTEM DESCRIPTION >

Under the following conditions, the combination meter displays the oil level sensor warning.

- Oil level sensor is open (resistance value of oil level sensor signal circuit exceeds 20 Ω).
- Oil level sensor is shorted (resistance value of oil level sensor signal circuit is less than 3 Ω).

SHIFT LEVER POSITION WARNING

Control Outline

- The combination meter receives the shift lever position warning display signal from TCM via CAN communication.
- Based on the shift lever position warning display signal received via CAN communication, the combination meter displays the shift lever position warning.

SHIFT “ P ” WARNING

Control Outline

- The combination meter receives the shift lever position check display signal from TCM via CAN communication.
- Based on the shift lever position check display signal received via CAN communication, the combination meter displays the shift “ P ” warning.

TRANSMISSION SYSTEM CHECK

Control Outline

- The combination meter receives the transmission system check display signal from TCM via CAN communication.
- Based on the transmission system check display signal received via CAN communication, the combination meter displays the transmission system check.

RUN-FLAT TIRE WARNING

Control Outline

- The combination meter receives the run-flat tire warning display signal from the low tire pressure warning control unit via CAN communication.
- Based on the run-flat tire warning display signal received via CAN communication, the combination meter displays the run-flat tire warning.

TRANSMISSION CLUTCH HIGH TEMPERATURE WARNING

Control Outline

- The combination meter receives the transmission clutch high temperature warning display signal from TCM via CAN communication.
- Based on the transmission clutch high temperature warning display signal received via CAN communication, the combination meter displays the transmission clutch high temperature warning.

TRANSMISSION OIL HIGH TEMPERATURE WARNING

- The combination meter receives the transmission oil high temperature warning display signal from TCM via CAN communication.
- Based on the transmission oil high temperature warning display signal received via CAN communication, the combination meter displays the transmission oil high temperature warning.

LOW TIRE PRESSURE WARNING

Control Outline

- The combination meter receives the low tire pressure warning display signal from the low tire pressure warning control unit via CAN communication.
- Based on the low tire pressure warning display signal received via CAN communication, the combination meter displays the low tire pressure warning.

AWD CLUTCH HIGH TEMPERATURE WARNING

Control Outline

- The combination meter receives the AWD clutch high temperature warning display signal from the AWD control unit via CAN communication.
- Based on the AWD clutch high temperature warning display signal received via CAN communication, the combination meter displays the AWD clutch high temperature warning.

FRONT/REAR TIRE SIZE DISCREPANCY WARNING

METER SYSTEM

< SYSTEM DESCRIPTION >

Control Outline

- The combination meter receives the front/rear tire discrepancy warning display signal from the AWD control unit via CAN communication. A
- Based on the front/rear tire discrepancy warning display signal received via CAN communication, the combination meter displays the front/rear tire discrepancy warning. B

TRANSMISSION SYSTEM WARNING

Control Outline

- The combination meter receives the transmission system warning display signal from TCM via CAN communication. C
- Based on the transmission system warning display signal received via CAN communication, the combination meter displays the transmission system warning. D

TIRE PRESSURE MONITORING SYSTEM WARNING

Control Outline

- The combination meter receives the tire pressure monitoring system warning display signal from the low tire pressure warning control unit via CAN communication. E
- Based on the tire pressure monitoring system warning display signal received via CAN communication, the combination meter displays the tire pressure monitoring system warning. F

AWD SYSTEM WARNING

Control Outline

- The combination meter receives the AWD system warning display signal from the AWD control unit via CAN communication. G
- Based on the AWD system warning display signal received via CAN communication, the combination meter displays the AWD system warning. H

ANTI-LOCK BRAKING SYSTEM (ABS) WARNING

Control Outline

- The combination meter receives the ABS warning display signal from the ABS control unit via CAN communication. I
- Based on the ABS warning display signal received via CAN communication, the combination meter displays the anti-lock braking system (ABS) warning. J

VEHICLE DYNAMIC CONTROL (VDC) SYSTEM WARNING

Control Outline

- The combination meter receives the VDC warning display signal from the ABS control unit via CAN communication. K
- Based on the VDC warning display signal received via CAN communication, the combination meter displays the vehicle dynamic control (VDC) system warning. L

ENGINE SYSTEM WARNING

Control Outline

- The combination meter receives the engine status signal from ECM via CAN communication.
- Based on the engine status signal received via CAN communication, the combination meter displays the engine system warning. M

CRUISE CONTROL SYSTEM WARNING

Control Outline

- The combination meter receives the ASCD status signal from ECM via CAN communication.
- Based on the ASCD status signal received via CAN communication, the combination meter displays the cruise control system warning. O

ENGINE OIL LOW PRESSURE WARNING

Control Outline

- The combination meter receives the oil pressure sensor signal from the oil pressure sensor.
- Based on the received oil pressure sensor signal, the combination meter displays the insufficient engine oil low pressure warning. P

MWI

METER SYSTEM

< SYSTEM DESCRIPTION >

LOW BRAKE FLUID WARNING

Control Outline

- The combination meter receives the brake fluid level switch signal from the brake fluid level switch.
- Based on the received brake fluid level switch signal, the combination meter displays the low brake fluid warning.

REVERSE WARNING

Control Outline

- The combination meter receives the buzzer output signal (reverse warning chime) from the BCM via CAN communication.
- Based on the received buzzer output signal (reverse warning chime), the combination meter displays the reverse warning.

HEADLAMP WARNING

Control Outline


- The combination meter receives the low beam request signal from the BCM via CAN communication.
- The combination meter receives the LED headlamp warning signal (LH/RH) from the front combination lamp (LH/RH).
- Based on the received low beam request signal, and LED headlamp warning signal (LH/RH) the combination meter displays the headlamp warning.

METER SYSTEM

< SYSTEM DESCRIPTION >

INFORMATION DISPLAY : Component Parts Location

INFOID:000000011488272



- | | | |
|---------------------------------|----------------------------------|---------------------------------|
| 1. Fuel level sensor unit (Sub) | 2. Fuel level sensor unit (Main) | 3. Door switch (passenger side) |
| 4. Front combination lamp RH | 5. Oil pressure sensor | 6. Ambient sensor |
| 7. Oil level sensor | 8. Washer level switch | 9. Front combination lamp LH |

JSNIA6899ZZ

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MWI

METER SYSTEM

< SYSTEM DESCRIPTION >

- | | | |
|-------------------------------|---|---|
| 10. AWD control unit | 11. Brake fluid level switch | 12. ABS actuator and electric unit (control unit) |
| 13. Door switch (driver side) | 14. TCM | 15. Trunk switch |
| 16. Combination meter | 17. Combination switch (Lighting switch) | 18. Low tire pressure warning control unit |
| 19. Parking brake | 20. BCM | 21. ECM |
| A. Under rear seat | B. Right side of engine | C. Radiator core support (center) |
| D. Oil pan LH upper | E. Front RH seat under | F. Trunk room left back |
| G. Lower instrument panel LH | H. Dashboard side lower (passenger seat side) | I. Glove box assembly back |

INFORMATION DISPLAY : Component Description

INFOID:000000011488273

Unit	Description
Combination meter	Based on received signals from each unit, switch, and sensor, controls the following items. <ul style="list-style-type: none"> Speedometer Engine coolant temperature gauge Warning lamp Information display Tachometer Fuel gauge Indicator lamp
Fuel level sensor unit	Detects the fuel level in fuel tank using the fuel level sensor unit, and transmits the fuel gauge signal to the combination meter.
Oil pressure sensor	Detects the oil pressure of engine oil, and transmits the oil pressure sensor signal to the combination meter.
ECM	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> Engine speed signal Fuel consumption monitor signal Engine status signal Engine coolant temperature signal Malfunction indicator lamp signal ASCD status signal
ABS actuator and electric unit (control unit)	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> Vehicle speed signal VDC warning display signal ABS warning display signal
BCM	Transmits signals received from each unit and switch to the combination meter via CAN communication.
TCM	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> Shift position signal Transmission oil high temperature warning display signal Transmission system warning display signal Shift lever position check display signal Shift lever position warning display signal Transmission clutch high temperature warning display signal Transmission system check display signal
AWD control unit	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> AWD clutch high temperature warning display signal Front/rear tire size discrepancy warning display signal AWD system warning display signal
Low tire pressure warning control unit	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> Run-flat tire warning display signal Tire pressure monitoring system warning display signal Low tire pressure warning display signal


METER SYSTEM

< SYSTEM DESCRIPTION >

Unit	Description
Meter control switch	Transmits the following signals to the combination meter. <ul style="list-style-type: none"> • Illumination control switch signal (+) • Trip A/B reset switch signal • Enter switch signal • Illumination control switch signal (-) • Select switch signal
Brake fluid level switch	Transmits the brake fluid level switch signal to the combination meter.
Parking brake switch	Transmits the parking brake switch signal to the combination meter.
Oil level sensor	Transmits the oil level sensor signal to the combination meter.
Washer level switch	Transmits the washer level switch signal to the combination meter.
Ambient sensor	Transmits the ambient sensor signal to the combination meter.
Front combination lamp LH	Transmits the front combination lamp LH signal to the combination meter.
Front combination lamp RH	Transmits the front combination lamp RH signal to the combination meter.

UP-SHIFT INDICATOR

UP-SHIFT INDICATOR : System Diagram



UP-SHIFT INDICATOR : System Description

INFOID:000000011488275

- The combination meter receives the engine speed signal from ECM and the shift position signal (manual mode range) from TCM via CAN communication, and illuminates/turns off/blinks the up-shift indicator.
- The engine speed at which the up-shift indicator is illuminated/turned off/blinked can be set with the setting function of information display.
 - OFF: All of the up-shift indicators do not illuminate.
 - 3,000 to 6,300 rpm: Engine speed can be set at which the up-shift indicator (green) is illuminated.
 - AUTO: Up-shift indicator (green) does not illuminate. The up-shift indicator (yellow) and up-shift indicator (red) is turned on/off according to the set value.

UP-SHIFT INDICATOR (GREEN)

- Using the setting function of information display, the up-shift warning speed can be set.
- The up-shift indicator (green) is illuminated/turned off/blinked according to the engine speed.
 - OFF: If the actual engine speed is lower than the arbitrarily set engine speed, which is 3,000 to 6,300 rpm set by the setting function of information display, by 500 rpm or more, the up-shift warning lamp is turned OFF.

Also, while the up-shift indicator (green) is blinking or illuminated, if the actual engine speed becomes lower than the arbitrarily set engine speed by 600 rpm or more, the up-shift warning lamp is turned OFF.
 - Blink: If the actual engine speed is lower than the arbitrarily set engine speed by 500 rpm or more, the up-shift indicator (green) is blinked.
 - ON: When the actual engine speed exceeds the arbitrarily set engine speed, the up-shift indicator (green) is illuminated.

METER SYSTEM

< SYSTEM DESCRIPTION >

Also, while the up-shift indicator (green) is blinking or illuminated, if the actual engine speed becomes lower than the arbitrarily set engine speed by 100 rpm or more, the up-shift indicator is blinked.

UP-SHIFT INDICATOR (YELLOW)

The up-shift indicator (yellow) is turned ON/OFF according to the engine speed.

- OFF: When the engine speed is less than 6,300 rpm, the up-shift indicator (yellow) does not illuminate. Also, while the up-shift indicator (yellow) is illuminated, when the engine speed becomes 6,200 rpm or lower, the up-shift indicator (yellow) is turned OFF.
- ON: When the engine speed becomes 6,300 rpm or more, the up-shift indicator (yellow) is illuminated.

UP-SHIFT INDICATOR (RED)

The up-shift indicator (red) is turned ON/OFF according to the engine speed.


- OFF: When the engine speed is less than 6,800 rpm, the up-shift indicator (red) does not illuminate. Also, while the up-shift indicator (red) is illuminated, when the engine speed becomes 6,700 rpm or lower, the up-shift indicator (red) is turned OFF.
- ON: When the engine speed becomes 6,800 rpm or more, the up-shift indicator (red) is illuminated.

METER SYSTEM

< SYSTEM DESCRIPTION >

UP-SHIFT INDICATOR : Component Parts Location

INFOID:000000011488276



- | | | |
|---------------------------------|----------------------------------|---------------------------------|
| 1. Fuel level sensor unit (Sub) | 2. Fuel level sensor unit (Main) | 3. Door switch (passenger side) |
| 4. Front combination lamp RH | 5. Oil pressure sensor | 6. Ambient sensor |
| 7. Oil level sensor | 8. Washer level switch | 9. Front combination lamp LH |

JSNIA6899ZZ

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MWI

METER SYSTEM

< SYSTEM DESCRIPTION >

10. AWD control unit	11. Brake fluid level switch	12. ABS actuator and electric unit (control unit)
13. Door switch (driver side)	14. TCM	15. Trunk switch
16. Combination meter	17. Combination switch (Lighting switch)	18. Low tire pressure warning control unit
19. Parking brake	20. BCM	21. ECM
A. Under rear seat	B. Right side of engine	C. Radiator core support (center)
D. Oil pan LH upper	E. Front RH seat under	F. Trunk room left back
G. Lower instrument panel LH	H. Dashboard side lower (passenger seat side)	I. Glove box assembly back

UP-SHIFT INDICATOR : Component Description

INFOID:000000011488277

Unit	Description
Combination meter	Based on received signals from each unit, switch, and sensor, controls the following items. <ul style="list-style-type: none"> Speedometer Engine coolant temperature gauge Warning lamp Information display Tachometer Fuel gauge Indicator lamp
Fuel level sensor unit	Detects the fuel level in fuel tank using the fuel level sensor unit, and transmits the fuel gauge signal to the combination meter.
Oil pressure sensor	Detects the oil pressure of engine oil, and transmits the oil pressure sensor signal to the combination meter.
ECM	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> Engine speed signal Fuel consumption monitor signal Engine status signal Engine coolant temperature signal Malfunction indicator lamp signal ASCD status signal
ABS actuator and electric unit (control unit)	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> Vehicle speed signal VDC warning display signal ABS warning display signal
BCM	Transmits signals received from each unit and switch to the combination meter via CAN communication.
TCM	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> Shift position signal Transmission oil high temperature warning display signal Transmission system warning display signal Shift lever position check display signal Shift lever position warning display signal Transmission clutch high temperature warning display signal Transmission system check display signal
AWD control unit	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> AWD clutch high temperature warning display signal Front/rear tire size discrepancy warning display signal AWD system warning display signal
Low tire pressure warning control unit	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> Run-flat tire warning display signal Tire pressure monitoring system warning display signal Low tire pressure warning display signal

METER SYSTEM

< SYSTEM DESCRIPTION >

Unit	Description
Meter control switch	Transmits the following signals to the combination meter. <ul style="list-style-type: none"> • Illumination control switch signal (+) • Trip A/B reset switch signal • Enter switch signal • Illumination control switch signal (-) • Select switch signal
Brake fluid level switch	Transmits the brake fluid level switch signal to the combination meter.
Parking brake switch	Transmits the parking brake switch signal to the combination meter.
Oil level sensor	Transmits the oil level sensor signal to the combination meter.
Washer level switch	Transmits the washer level switch signal to the combination meter.
Ambient sensor	Transmits the ambient sensor signal to the combination meter.
Front combination lamp LH	Transmits the front combination lamp LH signal to the combination meter.
Front combination lamp RH	Transmits the front combination lamp RH signal to the combination meter.

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

DIAGNOSIS SYSTEM (METER)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (METER)

Diagnosis Description

INFOID:000000011488278

SELF-DIAGNOSIS MODE

Using the self-diagnosis mode function, the combination meter can check the drive circuit of each meter (speedometer, tachometer, engine coolant temperature gauge, and fuel gauge), dot matrix (odo/trip meter, information display), and the LCD function of segment (shift position indicator).


OPERATION PROCEDURE

1. Turn the ignition switch ON, and switch the tripmeter to "trip A" or "trip B".


NOTE:

If the diagnosis function is activated with "trip A" displayed, the mileage on "trip A" is reset to "0000.0". (The same way for "trip B".)

2. Turn the ignition switch OFF.
3. While pressing the trip A/B reset switch (1), turn the ignition switch ON again.
4. Check that the tripmeter displays "0000.0".
5. Press the trip A/B reset switch at least 3 times (within 7 seconds after the ignition switch is turned ON).



6. The combination meter self-diagnosis mode starts.
 - On the information display (1), the dots of the dot matrix blink alternately.
 - Pointers of speedometer, tachometer, and engine coolant temperature gauge return to zero, and all of the segments of shift position indicator illuminate.




NOTE:

- If the self diagnosis mode of combination meter does not start, check the combination meter power supply and ground circuit. When everything is normal, replace the combination meter.
- If any section of the dot matrix on information display or of the segment in shift position indicator does not illuminate, replace the combination meter.

DIAGNOSIS SYSTEM (METER)

< SYSTEM DESCRIPTION >

7. When the trip A/B reset switch is pressed, (while the trip A/B reset switch is pressed) each meter operates.



NOTE:

If any meter does not operate, replace the combination meter.
The figure is reference.

CONSULT Function (METER/M&A)

INFOID:000000011488279

CONSULT can perform the following diagnosis modes by the CAN communication with combination meter.

Diagnosis mode	Description
Self Diagnosis Result	Displays names of malfunctioning systems judged by and stored in combination meter.
Data Monitor	Displays combination meter input/output data in real time.
Warning History	Displays the illumination record of warning lamp and indicator lamp.

SELF DIAGNOSTIC RESULT

NOTE:

Details of time display

- CRNT: Displays during the current malfunctioning detection.
- PAST: Displays if any previous malfunction is present when the current status is normal.

IGN counter

- The IGN counter is displayed on the freeze frame data (FFD).
- The IGN counter indicates the number of times ignition switch is turned ON after the DTC detection.
- The number is 0 when a malfunction is detected now.
- The number increases like 1 → 2 → 3 → ... 38 → 39 after returning to the normal condition whenever the ignition switch is turned OFF → ON.
- The number is fixed to 39 unit the self-diagnosis results are erased if it is over 39.

Display contents of CONSULT	Diagnostic item is detected if ...
CAN COMM CIRCUIT [U1000]	Combination meter cannot communicate CAN communication signal for 2 seconds or more.
CONTROL UNIT (CAN) [U1010]	Malfunction is detected during initial diagnosis of combination meter CAN controller.
VEHICLE SPEED [B2205]	Abnormal vehicle speed signal is received from ABS actuator and electric unit (control unit).
ENGINE SPEED [B2267]	ECM continuously transmits abnormal engine speed signal for 2 seconds or more.
WATER TEMP [B2268]	ECM continuously transmits abnormal engine coolant temperature signal for 60 seconds or more.

DIAGNOSIS SYSTEM (METER)

< SYSTEM DESCRIPTION >

OIL LEV SEN OPEN [B2321]	Signal from oil level sensor is broken (resistance value of oil level sensor exceeds 20 Ω).
OIL LEV SEN SHORT [B2322]	Signal from oil level sensor is shorted (resistance value of oil level sensor is less than 3 Ω).

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor item	MAIN ITEMS	Description
SPEED METER [km/h]	X	Vehicle speed signal value received from ABS actuator and electric unit (control unit) via CAN communication. NOTE: 655.35 is displayed when the malfunction signal is received.
SPEED OUTPUT [km/h]	X	Vehicle speed signal value transmitted to other units via CAN communication. NOTE: 655.35 is displayed when the malfunction signal is received.
ODO OUTPUT [km]		Odometer value transmitted to other units via CAN communication.
TACHO METER [rpm]	X	Engine speed signal value received from ECM via CAN communication. NOTE: 8191.875 is displayed when the malfunction signal is received.
FUEL METER [L]	X	Fuel level value indicated on combination meter.
W TEMP METER [°C]	X	Engine coolant temperature signal value received from ECM via CAN communication. NOTE: 215 is displayed when the malfunction signal is received.
ABS W/L [On/Off]		ABS warning lamp status judged by the ABS malfunction signal received from ABS actuator and electric unit (control unit) via CAN communication.
VDC/TCS IND [On/Off]		VDC OFF indicator lamp status judged by the VDC OFF indicator lamp signal received from ABS actuator and electric unit (control unit) via CAN communication.
SLIP IND [On/Off]		VDC warning lamp status judged by the VDC warning lamp signal received from ABS actuator and electric unit (control unit) via CAN communication.
BRAKE W/L [On/Off]		Brake warning lamp status judged by the brake warning lamp signal received from ABS actuator and electric unit (control unit) via CAN communication. NOTE: OFF is displayed when the bulb check is operating, when the brake fluid level switch is ON, or when the brake warning lamp is illuminated when the parking brake switch is ON or the brake fluid level switch is ON during the bulb check operation.
DOOR W/L [On/Off]		Door open warning status judged by the door switch signal received from BCM via CAN communication.
HI-BEAM IND [On/Off]		High beam indicator lamp status judged by the high beam request signal received from BCM via CAN communication.
TURN IND [On/Off]		Turn signal indicator lamp status judged by the turn indicator signal received from BCM via CAN communication.
RR FOG IND [Off]		NOTE: This Item is displayed, but cannot be monitored.
OIL W/L [On/Off]		Oil pressure warning lamp status judged by the oil pressure sensor signal received from oil pressure sensor.
LIGHT IND [On/Off]		Tail lamp indicator lamp status judged by the tail lamp request signal received from BCM via CAN communication.
MIL [On/Off]		MIL status judged by the malfunction indicator lamp received from ECM via CAN communication.
CRUISE IND [On/Off]		CRUISE indicator lamp status judged by the ASCD status signal received from ECM via CAN communication.

DIAGNOSIS SYSTEM (METER)

< SYSTEM DESCRIPTION >

Monitor item	MAIN ITEMS	Description
SET IND [On/Off]		SET indicator lamp status judged by the ASCD status signal received from ECM via CAN communication.
ATC/T-AMT W/L [On/Off]		Transmission check warning lamp status judged by the transmission warning light signal received from TCM via CAN communication.
4WD W/L [On/Off]		AWD warning lamp status judged by the AWD warning lamp signal received from AWD control unit via CAN communication.
FUEL W/L [On/Off]		Low fuel warning status judged by the fuel level sensor signal received from fuel level sensor unit.
WASHER W/L [On/Off]		Low washer fluid warning status judged by the washer level switch signal received from washer level switch.
AIR PRES W/L [On/Off]		Tire pressure warning lamp status judged by the tire pressure warning lamp signal received from low tire pressure warning control unit via CAN communication.
KEY G/Y W/L [On/Off]		KEY warning lamp (green/yellow) status judged by the KEY warning lamp signal received from BCM via CAN communication.
LCD [B&P N, B&P I, ID NG, ROTAT, SFT P, INSRT, BATT, NO KY, OUTKY, LK WN]		Displays status of Intelligent Key system warning detected from meter display signal is received from BCM via CAN communication.
SHIFT IND [P/R/N/A1/A2/A3/A4/A5/A6/M1/M2/M3/M4/M5/M6]		Shift position status judged by the shift position signal received from TCM via CAN communication.
PKB SW [On/Off]		Parking brake switch status judged by the parking brake switch signal received from parking brake switch.
BUCKLE SW [On/Off]		Seat belt buckle switch (driver side) status judged by the seat belt buckle switch signal (driver side) received from seat belt buckle switch (driver side).
BRAKE OIL SW [On/Off]		Brake fluid level switch status judged by the brake fluid level switch signal received from brake fluid level switch.
A/C AMP CONN [On/Off]		A/C auto amp. connection recognition status judged by the A/C auto amp. connection recognition signal received from A/C auto amp.
ENTER SW [On/Off]		Enter switch status judged by the enter switch signal received from meter control switch.
SELECT SW [On/Off]		Select switch status judged by the select switch signal received from meter control switch.
DISTANCE [km]		Possible driving distance value judged by combination meter.
OUTSIDE TEMP [°C]		Ambient sensor value converted from ambient sensor signal received from ambient sensor. NOTE: This may not match the temperature value indicated on information display. (Because the information display value is a corrected value from the ambient sensor input value.)
FUEL LOW SIG [On/Off]		Low fuel warning signal status that is output to AV control unit via CAN communication.
CRANKING SIG [On/Off]		Cranking status judged by the engine status signal received from ECM via CAN communication.
ST CNT SIG [On/Off]		Starter relay status judged by the starter relay status signal received from BCM via CAN communication.
BUZZER [On/Off]	X	Status of buzzer integrated in combination meter judged with buzzer output signal received from each unit via CAN communication and with warning output condition of combination meter.
ENG OIL TMP [°C]		Engine oil temperature status judged by the engine oil temperature signal received from ECM via CAN communication.

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

DIAGNOSIS SYSTEM (METER)

< SYSTEM DESCRIPTION >

Monitor item	MAIN ITEMS	Description
ENG OIL PRESS [MPa]		Engine oil pressure value judged by the oil pressure sensor signal received from oil pressure sensor.
TM OIL TMP [°C]		Transmission oil temperature value judged by the transmission oil temperature signal received from TCM via CAN communication.
TM OIL PRESS [MPa]		Transmission oil pressure value judged by the transmission oil pressure signal received from TCM via CAN communication.
A/F RATIO		Air-fuel ratio value judged by the air-fuel ratio signal received from ECM via CAN communication.
BOOST PRESS [kPa]		Boost pressure value judged by the boost pressure signal received from ECM via CAN communication.
THRTL POSI [%]		Throttle position value judged by the throttle position signal received from ECM via CAN communication.
TRQ DSTRBT [%]		Front torque distribution rate value judged by the front torque distribution rate signal received from AWD control unit via CAN communication.
AMT P SFT [On/Off]		P engagement warning display status judged by the shift lever position check display signal received from TCM via CAN communication.
AMT SYS CHCK		Transmission system check display status judged by the transmission system check display signal received from TCM via CAN communication.
AMT SFT POSI [On/Off]		Shift lever position warning display status judged by the shift lever position warning display signal received from TCM via CAN communication.
AMT OIL TMP H [On/Off]		Transmission oil high temperature warning display status judged by the transmission oil high temperature warning display signal received from TCM via CAN communication.
AMT CL TMP H [On/Off]		Transmission clutch high temperature warning display status judged by the transmission clutch high temperature warning display signal received from TCM via CAN communication.
AMT CHCK [Off]		NOTE: This Item is displayed, but cannot be monitored.
AMT MALF [On/Off]		Transmission system warning display status judged by the transmission system warning display signal received from TCM via CAN communication.
TPMS FLT TIRE [On/Off]		Run-flat tire warning display status judged by the run-flat tire warning display signal received from low tire pressure warning control unit via CAN communication.
TPMS PRESS L [On/Off]		Low tire pressure warning display status judged by the low tire pressure warning display signal received from low tire pressure warning control unit via CAN communication.
TPMS MALF [On/Off]		Tire pressure monitoring system warning display status judged by the tire pressure monitoring system warning display signal received from low tire pressure warning control unit via CAN communication.
4WD CL TMP H [On/Off]		Display status of AWD clutch high temperature warning display signal judged by the AWD clutch high temperature warning display signal received from AWD control unit via CAN communication.
4WD TIRE CHCK [On/Off]		Display status of front/rear tire size discrepancy warning display judged by the front/rear tire size discrepancy warning display signal received from AWD control unit via CAN communication.
4WD SYS MALF [On/Off]		Display status of AWD system warning display signal judged by the AWD system warning display signal received from AWD control unit via CAN communication.
ABS MALF [On/Off]		Display status of anti-lock braking system (ABS) warning display judged by the ABS warning display signal received from ABS actuator and electric unit (control unit) via CAN communication.
VDC MALF [On/Off]		Display status of vehicle dynamic control (VDC) system warning display judged by the VDC system warning display signal received from ABS actuator and electric unit (control unit) via CAN communication.
ENG SYS CHCK [On/Off]		Display status of engine system warning display judged by the engine status signal received from ECM via CAN communication.

DIAGNOSIS SYSTEM (METER)

< SYSTEM DESCRIPTION >

Monitor item	MAIN ITEMS	Description
ASCD SYS MALF [On/Off]		Display status of cruise control system warning display judged by the ASCD status signal received from ECM via CAN communication.
ASCD REQ SPD [km]		ASCD set vehicle speed value that is judged by the ASCD status signal received from ECM via CAN communication.
ASCD STATUS [Off, ASCD]		Display status of ASCD status display judged by the ASCD status signal received from ECM via CAN communication.
ASCD SPD BLNK [On/Off]		Blinking status of ASCD set vehicle speed that is judged by the ASCD status signal received from ECM via CAN communication.
LED LMP R OPEN [On/Off]		Status of front combination lamp RH judged based on LED headlamp (RH) warning signal input from front combination lamp RH.
LED LMP L OPEN [On/Off]		Status of front combination lamp LH judged based on LED headlamp (LH) warning signal input from front combination lamp LH.

NOTE:

Some items are not available according to vehicle specifications.

WARNING HISTORY

- Stores histories when warning/indicator lamp is turned on.
- “Warning History” indicates the “TIME” when the warning/indicator lamp is turned on.
- The “Time” above is :
 - 0: The condition that the warning/indicator lamp has been turned on 1 or more times after starting the engine and waiting for 30 seconds.
 - 1 - 39: The number of times the engine was restarted after the 0 condition.
 - NO Warning History : Stores NO (0) turning on history of warning/indicator lamp.

NOTE:

- Warning History is not stored for approximately 30 seconds after the engine starts.
- Brake warning lamp does not store any history when the parking the brake is applied or the brake fluid level gets low.

Display Item

Display Item	Description
ABS W/L	Lighting history of ABS warning lamp.
VDC & TCS OFF W/L	Lighting history of VDC OFF indicator lamp.
SLIP IND	Lighting history of VDC warning lamp.
BRAKE W/L	Lighting history of brake warning lamp.
DOOR W/L	Lighting history of door open warning indication.
TRUNK/GLASS HATCH	Lighting history of trunk open warning indication.
OIL W/L	Lighting history of oil pressure warning lamp.
C-ENG W/L	Lighting history of malfunction indicator lamp (MIL).
CRUISE IND	Lighting history of CRUISE indicator lamp.
SET IND	Lighting history of SET indicator lamp.
ATC/T-AMT W/L	Lighting history of transmission warning lamp.
AT OIL TEMP W/L	Lighting history of transmission oil high-temperature warning.
4WD W/L	Lighting history of AWD warning lamp.
FUEL W/L	Lighting history of low fuel warning.
WASHER W/L	Lighting history of low washer fluid warning.
TIRE PRESS W/L	Lighting history of tire pressure warning lamp.
KEY GREEN/YELLOW IND	Lighting history of KEY warning lamp (green/yellow).
KEY RED W/L	Lighting history of KEY warning lamp (red).
SFT OPERATION W/L	Lighting history of shift lever position check warning.

DIAGNOSIS SYSTEM (METER)

< SYSTEM DESCRIPTION >

Display Item	Description
CHARGE W/L	Lighting history of charge warning lamp.
OIL LEV LOW	Lighting history of oil level warning.

NOTE:

In items displayed on the CONSULT screen, only those listed in the above table are used.

U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

U1000 CAN COMM CIRCUIT

Description

INFOID:0000000011488280

CAN (Controller Area Network) is a serial communication line for real time applications. It is an on-board multiplex communication line with high data communication speed and excellent error detection ability. A modern vehicle is equipped with many ECUs, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, 2 control units are connected with 2 communication lines (CAN-L-line and CAN-H-line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Refer to [LAN-24, "CAN Communication Signal Chart"](#) for details of the communication signal.

DTC Logic

INFOID:0000000011488281

DTC DETECTION LOGIC

DTC	Display contents of CONSULT	Diagnostic item is detected if ...	Probable malfunction location
U1000	CAN COMM CIRCUIT	Combination meter cannot communicate CAN communication signal for 2 seconds or more	CAN communication system

Diagnosis Procedure

INFOID:0000000011488282

1. PERFORM THE SELF-DIAGNOSIS

1. Turn the ignition switch ON and wait for 2 seconds or more.
2. Check the self diagnosis result of the "METER/M&A".

Is CAN communication system displayed?

- YES >> Refer to [LAN-15, "Trouble Diagnosis Flow Chart"](#).
NO >> Refer to [GI-39, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

U1010 CONTROL UNIT (CAN)

Description

INFOID:000000011488283

Initial diagnosis of combination meter

DTC Logic

INFOID:000000011488284

DTC DETECTION LOGIC

DTC	Display contents of CONSULT	Diagnostic item is detected if ...	Probable malfunction location
U1010	CONTROL UNIT (CAN)	Malfunction is detected during initial diagnosis of combination meter CAN controller	Combination meter

Diagnosis Procedure

INFOID:000000011488285

1. REPLACE THE COMBINATION METER.

If DTC U1010 is detected, replace the combination meter.

>> INSPECTION END

B2205 VEHICLE SPEED

< DTC/CIRCUIT DIAGNOSIS >

B2205 VEHICLE SPEED

Description

INFOID:000000011488286

The vehicle speed signal is transmitted from the ABS actuator and electric unit (control unit) to the combination meter via CAN communication.

DTC Logic

INFOID:000000011488287

DTC DETECTION LOGIC

DTC	Display contents of CONSULT	Diagnostic item is detected if ...	Probable malfunction location
B2205	VEHICLE SPEED	Abnormal vehicle speed signal is received from ABS actuator and electric unit (control unit) for 2 seconds or more	ABS actuator and electric unit (control unit)

Diagnosis Procedure

INFOID:000000011488288

1. PERFORM SELF-DIAGNOSIS OF ABS ACTUATOR AND CONTROL UNIT

Perform Self Diagnostic Result of ABS actuator and electric unit (control unit). Repair or replace the malfunctioning parts.

>> Refer to [BRC-133, "DTC No. Index \(GT-R certified NISSAN dealer\)"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

B2267 ENGINE SPEED

< DTC/CIRCUIT DIAGNOSIS >

B2267 ENGINE SPEED

Description

INFOID:000000011488289

The engine speed signal is transmitted from ECM to the combination meter via CAN communication.

DTC Logic

INFOID:000000011488290

DTC DETECTION LOGIC

DTC	Display contents of CONSULT	Diagnostic item is detected if ...	Probable malfunction location
B2267	ENGINE SPEED	ECM continuously transmits abnormal engine speed signal for 2 seconds or more	ECM

Diagnosis Procedure

INFOID:000000011488291

1. PERFORM ECM SELF DIAGNOSIS

Perform Self Diagnostic Result of ECM. Repair or replace the malfunctioning parts.

>> Refer to [EC-592, "DTC Index"](#).

B2268 WATER TEMP

< DTC/CIRCUIT DIAGNOSIS >

B2268 WATER TEMP

Description

INFOID:000000011488292

The coolant temperature is transmitted from ECM to the combination meter via CAN communication.

DTC Logic

INFOID:000000011488293

DTC DETECTION LOGIC

DTC	Display contents of CONSULT	Diagnostic item is detected if ...	Probable malfunction location
B2268	WATER TEMP	ECM continuously transmits abnormal coolant temperature signal for 60 seconds or more	ECM

Diagnosis Procedure

INFOID:000000011488294

1. PERFORM ECM SELF DIAGNOSIS

Perform Self Diagnostic Result of ECM. Repair or replace the malfunctioning parts.

>> Refer to [EC-592, "DTC Index"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

B2321, B2322 OIL LEVEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

B2321, B2322 OIL LEVEL SENSOR

Description

INFOID:000000011488295

The oil level sensor detects the level of engine oil, and then transmits the oil level signal to the combination meter.

DTC Logic

INFOID:000000011488296

DTC DETECTION LOGIC

DTC	Display contents of CONSULT	Diagnostic item is detected if ...	Probable malfunction location
B2321	OIL LEV SEN OPEN	Oil level sensor signal circuit is open. (Resistance value of oil level sensor exceeds 20 Ω)	<ul style="list-style-type: none">Oil level sensor signal circuitOil level sensor
B2322	OIL LEV SEN SHORT	Oil level sensor signal circuit is shorted. (Resistance value of oil level sensor is less than 3 Ω)	

NOTE:

When the following conditions are satisfied, the combination meter reads the resistance value of oil level sensor. The combination meter does not read the oil level sensor resistance value within 5 minutes after the previous reading of oil level sensor resistance value by the combination meter.

- Turn the ignition switch OFF.
 - Wait for 5 minutes or more, then open the driver door.
- DTC (B2321: OIL LEV SEN OPEN, B2322: OIL LEV SEN SHORT) is also detected at the timing described above.

Diagnosis Procedure

INFOID:000000011488297

1.CHECK OIL LEVEL SENSOR SIGNAL CIRCUIT

- Turn the ignition switch OFF.
- Disconnect the connectors of combination meter and oil level sensor.
- Check for continuity between the combination meter harness connector and the oil level sensor harness connector.

Combination meter		Oil level sensor		Continuity
Connector	Terminal	Connector	Terminal	
M53	20	F38	3	Existed

- Check for continuity between the combination meter harness connector and the ground.

Combination meter		Ground	Continuity
Connector	Terminal		
M53	20		Not existed

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the harnesses or connectors.

2.CHECK OIL LEVEL SENSOR GROUND CIRCUIT

Check for continuity between the combination meter harness connector and the oil level sensor harness connector.

Combination meter		Oil level sensor		Continuity
Connector	Terminal	Connector	Terminal	
M53	19	F38	1	Existed

Is the inspection result normal?

B2321, B2322 OIL LEVEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

- YES >> INSPECTION END
NO >> Repair the harnesses or connectors.

A

Component Inspection

INFOID:000000011488298

1. CHECK OIL LEVEL SENSOR

B

1. Turn the ignition switch OFF.
2. Disconnect the oil level sensor connector.
3. Check the resistance between oil level sensor terminals 1 and 3.

C

Terminal		Resistance value (Ω)
1	3	5 - 11

D

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Replace the oil level sensor.

E

F

G

H

I

J

K

L

M

MWI

O

P

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

POWER SUPPLY AND GROUND CIRCUIT COMBINATION METER

COMBINATION METER : Diagnosis Procedure

INFOID:000000011488299

1.CHECK FUSES

Check that the following fuses are not blown:

Power source	Fuse No.
Battery	11
Ignition switch ON or START	4

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace the fuse with a new one after repairing the applicable circuit.

2.CHECK POWER SUPPLY CIRCUIT

Check the voltage between the combination meter harness connector terminals and the ground.

Terminal No.	Signal name	Ignition switch	Voltage
1	Battery power supply	OFF	Battery voltage
2	Ignition signal	ON	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the harness between the fuse and the combination meter.

3.CHECK GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the combination meter connector.
3. Check for continuity between the combination meter harness connector terminals and the ground.

Combination meter		Ground	Continuity
Connector	Terminal		
M53	3		Existed
	5		

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair the harnesses or connectors.

FUEL LEVEL SENSOR SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

FUEL LEVEL SENSOR SIGNAL CIRCUIT

Description

INFOID:000000011488300

Detects the fuel level in fuel tank using the fuel level sensor unit, and transmits the fuel level sensor signal to the combination meter.

Component Function Check

INFOID:000000011488301

1.PERFORM COMPONENT FUNCTION CHECK (1)

1. Turn ignition switch OFF.
2. Disconnect the connectors of the fuel level sensor unit (sub) and the fuel level sensor unit and fuel pump (main).
3. Connect variable resistor between harness connector terminals located on the vehicle side of the fuel level sensor unit (sub) and the fuel level sensor unit and fuel pump (main).

Fuel level sensor unit (sub)		Fuel level sensor unit and fuel pump (main)	
Connector	Terminals	Connector	Terminals
B27	1	B225	3

4. Set variable resistor according to the resistance value shown in the following table and turn ignition switch ON.

Resistance (Ω)* (Approx.)	Fuel gauge indication position (Approx.)
Less than 12	F
27	3/4
46	1/2
61	1/4
More than 82	E

*: Reference resistance values used when the combination meter judges the indication position of the fuel gauge.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refer to [MWI-69. "Diagnosis Procedure"](#).

2.PERFORM COMPONENT FUNCTION CHECK (2)

Check the fuel level sensor unit (sub) and the fuel level sensor unit and fuel pump (main). Refer to [MWI-71. "Component Inspection \(GT-R certified NISSAN dealer\)"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace the fuel level sensor unit (sub) or the fuel level sensor unit and fuel pump (main). Refer to [MWI-FL-6. "Removal and Installation \(GT-R certified NISSAN dealer\)"](#).

Diagnosis Procedure

INFOID:000000011488302

1.CHECK FUEL LEVEL SENSOR UNIT (SUB) CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the connectors of combination meter and fuel level sensor unit (sub).
3. Check for continuity between the combination meter harness connector and the fuel level sensor unit (sub) harness connector.

FUEL LEVEL SENSOR SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Combination meter		Fuel level sensor unit (sub)		Continuity
Connector	Terminal	Connector	Terminal	
M53	38	B27	1	Existed

4. Check for continuity between the combination meter harness connector and the ground.

Combination meter		Ground	Continuity
Connector	Terminal		
M53	38		Not existed

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the harnesses or connectors.

2. CHECK FUEL LEVEL SENSOR UNIT (MAIN-SUB) CIRCUIT

1. Disconnect fuel level sensor unit and fuel pump (main) connector.
2. Check for continuity between the fuel level sensor unit (sub) harness connector and the fuel level sensor unit and fuel pump (main) harness connector.

Fuel level sensor unit (sub)		Fuel level sensor unit and fuel pump (main)		Continuity
Connector	Terminal	Connector	Terminal	
B27	2	B225	2	Existed

3. Check for continuity between the fuel level sensor unit (sub) harness connector and the ground.

Fuel level sensor unit (sub)		Ground	Continuity
Connector	Terminal		
B27	2		Not existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the harnesses or connectors.

3. CHECK FUEL LEVEL SENSOR UNIT AND FUEL PUMP (MAIN) CIRCUIT

1. Check for continuity between the fuel level sensor unit and fuel pump (main) harness connector and the combination meter harness connector.

Fuel level sensor unit and fuel pump (main)		Combination meter		Continuity
Connector	Terminal	Connector	Terminal	
B225	3	M53	18	Existed

2. Check for continuity between the fuel level sensor unit and fuel pump (main) harness connector and the ground.

Fuel level sensor unit and fuel pump (main)		Ground	Continuity
Connector	Terminal		
B225	3		Not existed

Is the inspection result normal?

YES >> Replace combination meter. Refer to [MWI-114. "Removal and Installation"](#).

NO >> Repair the harnesses or connectors.

FUEL LEVEL SENSOR SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >


Component Inspection (GT-R certified NISSAN dealer)

INFOID:000000011488303

1. CHECK FUEL LEVEL SENSOR UNIT (MAIN)

Check the resistance value of fuel level sensor unit (main).

2 - 3	
Full	:Approx. 3.0 Ω
Empty	:Approx. 90.0 Ω



Standard float position

Full (A) [mm (in)]	:Approx. 282.2 (11.11)
Empty (B) [mm (in)]	:Approx. 19.2 (0.756)

Is the inspection result normal?


YES >> GO TO 2.

NO >> Replace the fuel level sensor unit (main).

2. CHECK FUEL LEVEL SENSOR UNIT (SUB)

Check the resistance value of fuel level sensor unit (sub).

1 - 2	
Full	:Approx. 3.0 Ω
Empty	:Approx. 45.9 Ω



Standard float position

Full (A) [mm (in)]	:Approx. 29.9 (1.177)
Empty (B) [mm (in)]	:Approx. 218.3 (8.59)

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace the fuel level sensor unit (sub).

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

METER CONTROL SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

METER CONTROL SWITCH SIGNAL CIRCUIT

Description

INFOID:000000011488304

Transmits the following signals to the combination meter.



- Illumination control switch signal (+)
- Trip A/B reset switch signal
- Enter switch signal
- Illumination control switch signal (-)
- Select switch signal

Diagnosis Procedure

INFOID:000000011488305

1. CHECK METER CONTROL SWITCH INPUT SIGNAL

1. Turn the ignition switch ON.
2. Measure voltage between the following terminals of the combination meter.

Terminal No.	Condition	Voltage (Approx.)
23 - 6	When  switch is pressed	0 V
	Other than the above	5 V
24 - 6	When  switch is pressed	0 V
	Other than the above	5 V
25 - 6	When trip A/B reset switch is pressed	0 V
	Other than the above	5 V
26 - 6	When enter switch is pressed	0 V
	Other than the above	5 V
27 - 6	When select switch is pressed	0 V
	Other than the above	5 V

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2. CHECK METER CONTROL SWITCH SIGNAL CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the connectors of combination meter and meter control switch.
3. Check for continuity between the combination meter harness connector terminal and the meter control switch harness connector.

Combination meter		Meter control switch		Continuity
Connector	Terminal	Connector	Terminal	
M53	6	M54	2	Existed
	23		3	
	24		1	
	25		8	
	26		6	
	27		7	

4. Check for continuity between the combination meter harness connector and the ground.

METER CONTROL SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Combination meter			Continuity
Connector	Terminal		
M53	6	Ground	Not existed
	23		
	24		
	25		
	26		
	27		

Is the inspection result normal?

YES >> INSPECTION END



NO >> Repair the harnesses or connectors.

Component Inspection

INFOID:000000011488306

1. UNIT INSPECTION OF METER CONTROL SWITCH

1. Turn the ignition switch OFF.
2. Disconnect the meter control switch connector.
3. Check the continuity of meter control switch.

Terminal No.		Operation and status	Continuity
6	2	Press the enter switch	Existed
		Other than the above	Not existed
7	2	Press the select switch	Existed
		Other than the above	Not existed
8	2	Press the trip A/B reset switch.	Existed
		Other than the above	Not existed
3	2	Press the  switch	Existed
		Other than the above	Not existed
1	2	Press the  switch	Existed
		Other than the above	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace the meter control switch.

MWI

OIL PRESSURE SENSOR SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

OIL PRESSURE SENSOR SIGNAL CIRCUIT

Description

INFOID:000000011488307

Detects the engine oil pressure and transmits the oil pressure sensor signal to the combination meter.

Component Function Check

INFOID:000000011488308

1. CHECK COMBINATION METER INPUT SIGNAL

1. Connect CONSULT.
2. Select the "DATA MONITOR" for the "METER/M&A", and then check the "OIL W/L" monitor value.

OIL W/L

Ignition switch ON :On

Engine running :Off

>> INSPECTION END

Diagnosis Procedure

INFOID:000000011488309

1. CHECK OIL PRESSURE SENSOR CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the connectors of combination meter and oil pressure sensor.
3. Check for continuity between the combination meter harness connector and the oil pressure sensor harness connector.

Combination meter		Oil pressure sensor		Continuity
Connector	Terminal	Connector	Terminal	
M53	34	E255	1	Existed
M53	35	E255	2	Existed
M53	14	E255	3	Existed

4. Check for continuity between the combination meter harness connector and the ground.

Combination meter		Ground	Continuity
Connector	Terminal		
M53	34	Ground	Not existed
M53	35		Not existed
M53	14		Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair the harnesses or connectors.

Component Inspection

INFOID:000000011488310

1. CHECK OIL PRESSURE SENSOR

Check the voltage between the combination meter terminal 35 and the ground.

Condition	Measuring condition	Voltage (V)
Engine stop	Ignition switch ON	Approx. 1
Engine running	Oil pressure is at 500 kPa	Approx. 3

Is the inspection result normal?

OIL PRESSURE SENSOR SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

YES >> INSPECTION END
NO >> Replace the oil pressure switch.

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

PARKING BRAKE SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

PARKING BRAKE SWITCH SIGNAL CIRCUIT

Description

INFOID:000000011488311

Transmits the parking brake switch signal to the combination meter.

Diagnosis Procedure

INFOID:000000011488312

1. CHECK COMBINATION METER INPUT SIGNAL

1. Turn the ignition switch ON.
2. Check the voltage between the combination meter harness connector and the ground.

Probe		Measuring condition	Voltage (Approx.)
(+)	(-)		
Combination meter			
Connector	Terminal	Parking brake operated	0 V
M53	31	Parking brake released	5 V

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2. CHECK PARKING BRAKE SWITCH SIGNAL CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the connectors of combination meter and parking brake switch.
3. Check for continuity between the combination meter harness connector and the parking brake switch harness connector.

Combination meter		Parking brake switch		Continuity
Connector	Terminal	Connector	Terminal	
M53	31	M132	1	Existed

4. Check for continuity between the combination meter harness connector and the ground.

Combination meter		Ground	Continuity
Connector	Terminal		
M53	31		Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair the harnesses or connectors.

Component Inspection

INFOID:000000011488313

1. CHECK PARKING BRAKE SWITCH

1. Turn the ignition switch OFF.
2. Disconnect the parking brake switch connector.
3. Check for continuity between the parking brake switch connector and the ground.

Parking brake switch		Measuring condition	Continuity
(+)	(-)		
1	Ground	Parking brake applied	Existed
		Parking brake released	Not exist

YES >> INSPECTION END

PARKING BRAKE SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

NO >> Replace the parking brake switch.

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

WASHER LEVEL SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

WASHER LEVEL SWITCH SIGNAL CIRCUIT

Description

INFOID:000000011488314

When the washer fluid in washer tank is less than the specified level, and washer level switch is turned ON, the washer level switch transmits the washer level switch signal to the combination meter.

Diagnosis Procedure

INFOID:000000011488315

1. CHECK COMBINATION METER INPUT SIGNAL

1. Turn the ignition switch ON.
2. Check the voltage between the combination meter harness connector and the ground.

Probe (+)		(-)	Measuring condition	Voltage (Approx.)
Combination meter				
Connector	Terminal	Ground	Washer level switch ON	0 V
M53	33		Ground	Washer level switch OFF

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2. CHECK WASHER LEVEL SWITCH CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the connectors of combination meter and washer level switch.
3. Check for continuity between the combination meter harness connector and the washer level switch harness connector.

Combination meter		Washer level switch		Continuity
Connector	Terminal	Connector	Terminal	
M53	33	E30	1	Existed

4. Check for continuity between the combination meter harness connector and the ground.

Combination meter		Ground	Continuity
Connector	Terminal		
M53	33		Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair the harnesses or connectors.

Component Inspection

INFOID:000000011488316

1. CHECK WASHER LEVEL SWITCH

1. Turn the ignition switch OFF.
2. Disconnect the washer level switch connector.
3. Check the washer level switch.

Terminal	Washer level switch	Continuity
1 - 2	ON	Existed
	OFF	Not existed

Is the inspection result normal?

YES >> INSPECTION END

WASHER LEVEL SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

NO >> Replace the washer level switch.

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

A/C AUTO AMP. CONNECTION RECOGNITION SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

A/C AUTO AMP. CONNECTION RECOGNITION SIGNAL CIRCUIT

Description

INFOID:000000011488317

A/C auto amp. transmit the A/C auto amp. connection recognition signal to the combination meter.

Diagnosis Procedure

INFOID:000000011488318

1. CHECK A/C AUTO AMP. CONNECTION RECOGNITION SIGNAL

1. Turn ignition switch ON.
2. Check voltage between combination meter harness connector terminal and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
Combination meter		5 V
Connector	Terminal	
M53	7	

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2. CHECK A/C AUTO AMP. CONNECTION RECOGNITION SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector and A/C auto amp. connector.
3. Check continuity between combination meter harness connector terminal and A/C auto amp. harness connector terminal.

Combination meter		A/C auto amp.		Continuity
Connector	Terminal	Connector	terminal	
M53	7	M66	34	Existed

4. Check continuity between combination meter harness connector and ground.

Combination meter		Ground	Continuity
Connector	Terminal		
M53	7		Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair harness or connector.

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION

COMBINATION METER

Reference Value

INFOID:000000011488319

CONSULT DATA MONITOR REFERENCE VALUES

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor item	Measuring condition		Standard/Status
SPEED METER [km/h]	Ignition switch ON	While driving	Equivalent to speedometer reading NOTE: 655.35 is displayed when the malfunction signal is received
SPEED OUTPUT [km/h]	Ignition switch ON	While driving	Equivalent to speedometer reading NOTE: 655.35 is displayed when the malfunction signal is received
ODO OUTPUT [km]	Ignition switch ON	—	Equivalent to odometer reading in combination meter
TACHO METER [rpm]	Ignition switch ON	While driving	Approximately the same as tachometer reading NOTE: 8191.875 is displayed when the malfunction signal is received
FUEL METER [L]	Ignition switch ON	—	Values according to fuel level
W TEMP METER [°C]	Ignition switch ON	—	Values according to engine coolant temperature NOTE: 215 is displayed when the malfunction signal is input
ABS W/L	Ignition switch ON	ABS warning lamp ON	On
		ABS warning lamp OFF	Off
VDC/TCS IND	Ignition switch ON	VDC OFF indicator lamp ON	On
		VDC OFF indicator lamp OFF	Off
SLIP IND	Ignition switch ON	VDC warning lamp ON	On
		VDC warning lamp OFF	Off
BRAKE W/L	Ignition switch ON	Brake warning lamp ON	On
		Brake warning lamp OFF	Off
DOOR W/L	Ignition switch ON	<ul style="list-style-type: none"> • Door open warning display • Trunk open warning display 	On
		<ul style="list-style-type: none"> • Door open warning is not displayed • Trunk open warning is not displayed 	Off
HI-BEAM IND	Ignition switch ON	High beam indicator lamp ON	On
		High beam indicator lamp OFF	Off
TURN IND	Ignition switch ON	Turn signal indicator lamp ON	On
		Turn signal indicator lamp OFF	Off
RR FOG IND	Ignition switch ON	This item is displayed, but cannot be monitored.	Off
OIL W/L	Ignition switch ON	Oil pressure warning lamp ON	On
		Oil pressure warning lamp OFF	Off

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MWI

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

Monitor item	Measuring condition		Standard/Status
LIGHT IND	Ignition switch ON	Tail lamp indicator lamp ON	On
		Tail lamp indicator lamp OFF	Off
MIL	Ignition switch ON	Malfunction indicator lamp (MIL) ON	On
		Malfunction indicator lamp (MIL) OFF	Off
CRUISE IND	Ignition switch ON	CRUISE indicator lamp ON	On
		CRUISE indicator lamp OFF	Off
SET IND	Ignition switch ON	SET indicator lamp ON	On
		SET indicator lamp OFF	Off
ATC/T-AMT W/L	Ignition switch ON	Transmission warning lamp ON	On
		Transmission warning lamp OFF	Off
4WD W/L	Ignition switch ON	AWD warning lamp ON	On
		AWD warning lamp OFF	Off
FUEL W/L	Ignition switch ON	Low fuel warning display	On
		Low fuel warning is not displayed	Off
WASHER W/L	Ignition switch ON	Low washer fluid warning display	On
		Low washer fluid warning is not displayed	Off
AIR PRES W/L	Ignition switch ON	Tire pressure warning lamp ON	On
		Tire pressure warning lamp OFF	Off
KEY G/Y W/L	Ignition switch ON	KEY warning lamp (green/yellow) ON	On
		KEY warning lamp (green/yellow) OFF	Off
LCD	Ignition switch ON	Engine start indication is displayed	B&P I
	Ignition switch ACC	Engine start indication is displayed	B&P N
	Ignition switch LOCK	Key ID NG warning is displayed	ID NG
	Ignition switch LOCK	Steering lock rotation operation signal illuminated	ROTAT
	Ignition switch LOCK	P engagement warning is displayed	SFT P
	Ignition switch LOCK	Key insertion indication is displayed	INSRT
	Ignition switch LOCK	Intelligent Key low battery notice warning is displayed	BATT
	Ignition switch ON	Key removal warning is displayed	NO KY
	Ignition switch LOCK	Key reminder warning is displayed	OUT KY
	Ignition switch ON	ACC warning is displayed	LK WN

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

Monitor item	Measuring condition		Standard/Status
SHIFT IND	Ignition switch ON	Shift position P is displayed	P
		Shift position R is displayed	R
		Shift position N is displayed	N
		Shift position A1 is displayed	A1
		Shift position A2 is displayed	A2
		Shift position A3 is displayed	A3
		Shift position A4 is displayed	A4
		Shift position A5 is displayed	A5
		Shift position A6 is displayed	A6
		Shift position M1 is displayed	M1
		Shift position M2 is displayed	M2
		Shift position M3 is displayed	M3
		Shift position M4 is displayed	M4
		Shift position M5 is displayed	M5
Shift position M6 is displayed	M6		
PKB SW	Ignition switch ON	Parking brake switch ON	On
		Parking brake switch OFF	Off
BUCKLE SW	Ignition switch ON	Seat belt not fastened	On
		Seat belt fastened	Off
BRAKE OIL SW	Ignition switch ON	Brake fluid level switch ON	On
		Brake fluid level switch OFF	Off
A/C AMP CONN	Ignition switch ON	A/C auto amp. is not connected	On
		A/C auto amp. is connected	Off
ENTER SW	Ignition switch ON	Enter switch is being pressed	On
		Enter switch is not pressed	Off
SELECT SW	Ignition switch ON	Select switch is being pressed	On
		Select switch is not pressed	Off
DISTANCE [km]	Ignition switch ON	—	Possible driving distance calculated by combination meter
OUTSIDE TEMP [°C]	Ignition switch ON	—	Equivalent to ambient air temperature NOTE: This may not match the indicated value on information display.
FUEL LOW SIG	Ignition switch ON	Low fuel warning is displayed	On
		Low fuel warning is not displayed	Off
CRANKING SIG	At engine cranking		On
	Ignition switch ON		Off
ST CNT SIG	At engine cranking		On
	Ignition switch ON		Off
BUZZER	Ignition switch ON	Buzzer ON	On
		Buzzer OFF	Off
ENG OIL TMP	Ignition switch ON	—	Values according to engine oil temperature
ENG OIL PRESS	Ignition switch ON	—	Values according to engine oil pressure

A
B
C
D
E
F
G
H
I
J
K
L
M

MWI

O
P

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

Monitor item	Measuring condition		Standard/Status
TM OIL TMP	Ignition switch ON	—	Values according to transmission oil temperature
TM OIL PRESS	Ignition switch ON	—	Values according to transmission oil pressure
A/F RATIO	Ignition switch ON	—	Values according to engine air-fuel ratio
BOOST PRESS	Ignition switch ON	—	Values according to boost pressure
THRTL POSI	Ignition switch ON	—	Values according to throttle position
TRQ DSTRBT	Ignition switch ON	—	Values according to front torque distribution rate
AMT P SFT	Ignition switch ON	Shift " P " warning display ON	On
		Shift " P " warning display OFF	Off
AMT SYS CHCK	Ignition switch ON	Transmission system check display ON	On
		Transmission system check display OFF	Off
AMT SFT POSI	Ignition switch ON	Shift lever position warning display ON	On
		Shift lever position warning display OFF	Off
AMT OIL TMP H	Ignition switch ON	Transmission oil high temperature warning display ON	On
		Transmission oil high temperature warning display OFF	Off
AMT CL TMP H	Ignition switch ON	Transmission clutch high temperature warning display ON	On
		Transmission clutch high temperature warning display OFF	Off
AMT CHCK	Ignition switch ON	It is displayed, but not used.	Off
AMT MALF	Ignition switch ON	Transmission system warning display ON	On
		Transmission system warning display OFF	Off
TPMS FLT TIRE	Ignition switch ON	Run-flat tire warning display ON	On
		Run-flat tire warning display OFF	Off
TPMS PRESS L	Ignition switch ON	Low tire pressure warning display ON	On
		Low tire pressure warning display OFF	Off
TPMS MALF	Ignition switch ON	Tire pressure monitoring system warning display ON	On
		Tire pressure monitoring system warning display OFF	Off
4WD CL TMP H	Ignition switch ON	AWD clutch high temperature warning display ON	On
		AWD clutch high temperature warning display OFF	Off
4WD TIRE CHCK	Ignition switch ON	Front/rear tire size discrepancy warning display ON	On
		Front/rear tire size discrepancy warning display OFF	Off
4WD SYS MALF	Ignition switch ON	AWD system warning display ON	On
		AWD system warning display OFF	Off

COMBINATION METER


< ECU DIAGNOSIS INFORMATION >

Monitor item	Measuring condition		Standard/Status
ABS MALF	Ignition switch ON	Anti-lock braking system (ABS) warning display ON	On
		Anti-lock braking system (ABS) warning display OFF	Off
VDC MALF	Ignition switch ON	Vehicle dynamic control (VDC) system warning display ON	On
		Vehicle dynamic control (VDC) system warning display OFF	Off
ENG SYS CHCK	Ignition switch ON	Engine system warning display ON	On
		Engine system warning display OFF	Off
ASCD SYS MALF	Ignition switch ON	CRUISE control system warning display ON	On
		CRUISE control system warning display OFF	Off
ASCD REQ SPD	Ignition switch ON	While driving	Same value as ASCD set vehicle speed
ASCD STATUS	Ignition switch ON	ASCD system OFF	Off
		ASCD system ON	ASCD
ASCD SPD BLNK	Ignition switch ON	Blinking status of ASCD set vehicle speed (displayed)	On
		Blinking status of ASCD set vehicle speed (not displayed)	Off
LED LMP R OPEN	Ignition switch ON	Front combination lamp RH malfunction	On
		Front combination lamp RH normal	Off
LED LMP L OPEN	Ignition switch ON	Front combination lamp LH malfunction	On
		Front combination lamp LH normal	Off

NOTE:

Some items are not available according to vehicle specifications.

TERMINAL LAYOUT





INPUT/OUTPUT SIGNAL STANDARD

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
1 (V)	Ground	Battery power supply	Input	Ignition switch OFF	—	Battery voltage
2 (W)	Ground	Ignition power supply	Input	Ignition switch ON	—	Battery voltage



COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
3 (B)	Ground	Ground	—	Igni- tion switch ON	—	0 V
5 (B)	Ground	Ground	—	Igni- tion switch ON	—	0 V
6 (W)	Ground	Meter control switch ground	—	Igni- tion switch ON	—	0 V
7 (Y)	Ground	A/C auto amp. connection recognition signal	Input	Igni- tion switch ON	—	5 V
8 (SB)	Ground	Ambient sensor ground	—	Igni- tion switch ON	—	0 V
9 (P)	Ground	Ambient sensor	Input	Igni- tion switch ON	—	Refer to HAC-44, "Component Inspection" .
12 (L)	Ground	Vehicle speed signal (2- pulse)	Output	Igni- tion switch ON	Vehicle speed is approxi- mately 40 km/h (25 MPH)	<p>NOTE: The maximum voltage varies de- pending on the specification (destination unit).</p>  <p style="text-align: right; font-size: small;">JSNIA0015GB</p>
13 (V)	Ground	Vehicle speed signal (8- pulse)	Output	Igni- tion switch ON	Vehicle speed is approxi- mately 40 km/h (25 MPH)	<p>NOTE: The maximum voltage varies de- pending on the specification (destination unit).</p>  <p style="text-align: right; font-size: small;">JSNIA0012GB</p>
14 (B)	Ground	Oil pressure sensor ground	—	Igni- tion switch ON	—	0 V
15 (R)	Ground	Air bag signal	Input	Igni- tion switch ON	Air bag warning lamp ON	5 V
					Air bag warning lamp OFF	0 V

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >


Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
16 (R)	Ground	LED headlamp (RH) warning signal	Input	Ignition switch ON	Headlamp ON	1 V
					Headlamp OFF	12 V
18 (L)	Ground	Fuel level sensor signal ground	—	Ignition switch ON	—	0 V
19 (R)	Ground	Oil level sensor ground	—	Ignition switch ON	—	0 V
20 (W)	Ground	Oil level sensor signal	Input	Ignition switch ON	—	Refer to MWI-67. "Component Inspection" .
21 (L)	Ground	CAN-H	—	Ignition switch ON	—	—
22 (P)	Ground	CAN-L	—	Ignition switch ON	—	—
23 (LG)	6 (W)	Illumination control switch signal (-)	Input	Ignition switch ON	When  - switch is pressed	0 V
					Other than the above	5 V
24 (BR)	6 (W)	Illumination control switch signal (+)	Input	Ignition switch ON	When  + switch is pressed	0 V
					Other than the above	5 V
25 (G)	6 (W)	Trip A/B reset switch signal	Input	Ignition switch ON	When trip A/B reset switch is pressed	0 V
					Other than the above	5 V
26 (BG)	6 (W)	Enter switch signal	Input	Ignition switch ON	When enter switch is pressed	0 V
					Other than the above	5 V
27 (SB)	6 (W)	Select switch signal	Input	Ignition switch ON	When select switch is pressed	0 V
					Other than the above	5 V
28 (BR)	Ground	Alternator signal	Input	Ignition switch ON	Charging warning lamp ON	0 V
					Charging warning lamp OFF	12 V


A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
29 (G)	Ground	Seat belt buckle switch signal (passenger side)	Input	Ignition switch ON	<ul style="list-style-type: none"> When getting in the passenger seat When passenger seat belt is fastened. 	12 V
					<ul style="list-style-type: none"> When getting in the passenger seat When passenger seat belt is unfastened 	0 V
30 (LG)	Ground	Seat belt buckle switch signal (driver side)	Input	Ignition switch ON	When driver seat belt is fastened	12 V
					When driver seat belt is unfastened	0 V
31 (V)	Ground	Parking brake switch signal	Input	Ignition switch ON	Parking brake applied	0 V
					Parking brake released	5 V
32 (V)	Ground	Brake fluid level switch signal	Input	Ignition switch ON	Brake fluid level is normal	0 V
					Brake fluid level is MIN level or less	5 V
33 (L)	Ground	Washer level switch signal	Input	Ignition switch ON	Low washer fluid warning display ON	0 V
					Low washer fluid warning display OFF	5 V
34 (GR)	Ground	Oil pressure sensor power	Output	Ignition switch ON	—	5 V
35 (W)	Ground	Oil pressure sensor signal	Input	Ignition switch ON	—	Refer to MWI-74. "Component Inspection" .
38 (BG)	Ground	Fuel level sensor signal	Input	Ignition switch ON	—	 <p style="text-align: right; font-size: small;">NNNIA0108ZZ</p>
39 (Y)	Ground	LED headlamp (LH) warning signal	Input	Ignition switch ON	Headlamp ON	1 V
					Headlamp OFF	12 V




NNNIA0108ZZ

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

Wiring Diagram - METER -

INFOID:000000011488320



2014/10/01


JRNWE11919B

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MWI

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >




JRNWE1192GB

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

METER

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-C516-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	-	-
2	P	-
3	V	-
4	W	-
5	Y	-
6	Y	-
7	Y	-
8	Y	-
9	Y	-
10	R	-
11	Y	-
12	GR	-
13	BG	-
14	Y	-
15	BR	-
16	R	-
17	W	-
18	BR	-
19	W	-
20	GR	-
21	SB	-
22	W	-
23	G	-
24	BG	-
25	L	-
26	P	-
27	GR	-
28	BG	-
29	GR	-
30	V	-
31	GR	-
32	L	-
33	V	-
34	BG	-
35	G	-
36	LG	-
37	V	-
38	Y	-
39	G	-
40	LG	-
41	V	-
42	SB	-
43	P	-
44	R	-
45	Y	-
46	R	-
47	Y	-
48	B	-

49	W	-
50	SHIELD	-
51	SB	-
52	B	-
53	R	-
54	B	-
55	R	-
56	G	-
57	G	-
58	G	-
59	R	-
60	BR	-
61	Y	-
62	SHIELD	-
63	LG	-
64	R	-
65	G	-
66	BR	-
67	BG	-
68	P	-
69	P	-
70	L	-
71	SHIELD	-
72	SHIELD	- [Without active noise control unit] - [With active noise control unit]
73	SB	-
74	R	-
75	R	-
76	R	-
77	SB	-
78	G	-
79	Y	-
80	R	-
81	G	-
82	BR	- [Without active noise control unit] - [With active noise control unit]
83	R	- [With active noise control unit] - [Without active noise control unit]
84	SHIELD	-
85	V	-
86	SB	- [Without active noise control unit] - [With active noise control unit]
87	W	-
88	L	-
89	P	-
90	SHIELD	-
91	V	-
92	BR	-
93	SB	-
94	GR	-
95	BG	-
96	Y	-
97	Y	-
98	LG	-

99	R	-
100	G	-

Connector No.	B12
Connector Name	SEAT BELT BUCKLE SWITCH (DRIVER SIDE)
Connector Type	TK03FW




Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	B	-
3	SB	-

Connector No.	B27
Connector Name	FUEL LEVEL SENSOR UNIT (SUB)
Connector Type	SG202FGY



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	G	-

Connector No.	B45
Connector Name	TCM
Connector Type	PH40FB-Z2L-LH-Z



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	POWER SUPPLY (MEMORY BACK-UP) 2
2	B	GROUND
3	B	GROUND
4	W	POWER SUPPLY (MEMORY BACK-UP) 3
5	W	GROUND
6	B	GROUND
7	B	GROUND
8	B	GROUND
9	P	POWER SUPPLY (MEMORY BACK-UP) 1
10	LG	BACK-UP LAMP SIGNAL
11	L	CANH
12	L	POWER OFF
13	V	CANL
14	P	STOP LAMP SWITCH SIGNAL
15	W	IGNITION SWITCH SIGNAL
16	Y	STARTER RELAY SIGNAL
17	Y	IGNITION SWITCH SIGNAL
18	GR	STARTER RELAY SIGNAL
19	GR	AUTOMANUAL RANGE CHANGE SWITCH 1 SIGNAL
20	BR	AUTOMANUAL RANGE CHANGE SWITCH 2 SIGNAL
21	L	RANGE SENSOR POWER SOURCE 1
22	LG	RANGE SENSOR POWER SOURCE 2
23	LG	RANGE SENSOR NO. 1 SIGNAL
24	G	RANGE SENSOR NO. 2 SIGNAL
25	V	AUTOMANUAL RANGE CHANGE SWITCH 1 SIGNAL
26	V	ENGINE SPEED SIGNAL
27	V	ENGINE SPEED SIGNAL
28	V	SAVE MODE SWITCH NO. 1 SIGNAL
29	BG	SAVE MODE SWITCH NO. 2 SIGNAL
30	G	RANGE SENSOR NO. 3 SIGNAL
31	GR	R MODE SWITCH SIGNAL
32	R	RANGE SENSOR NO. 2 SIGNAL
33	R	RANGE SENSOR NO. 4 SIGNAL
34	W	PADDLE SHIFTER (SHIFT UP) SWITCH SIGNAL
35	L	PADDLE SHIFTER (SHIFT DOWN) SWITCH SIGNAL
36	L	RANGE SENSOR NO. 4 SIGNAL
37	P	RANGE SENSOR NO. 5 SIGNAL
38	GR	R MODE LAMP SIGNAL
39	BG	R MODE LAMP SIGNAL
40	W	SHIFT LOCK SOLENOID CONTROL SIGNAL
41	W	SHIFT LOCK SOLENOID CONTROL SIGNAL
42	W	SAVE MODE LAMP SIGNAL
43	G	SAVE MODE LAMP SIGNAL
44	G	SAVE MODE LAMP SIGNAL
45	G	SAVE MODE LAMP SIGNAL
46	G	SAVE MODE LAMP SIGNAL
47	G	SAVE MODE LAMP SIGNAL

JRNWE1193GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


MWI

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >


METER

Connector No.	B252
Connector Name	WIRE TO WIRE
Connector Type	TH12/MV-NH




Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	
2	Y	
3	SB	
4	G	
5	W	
6	W	
7	R	
8	G	
9	BG	
10	GR	
11	LG	
12	SHIELD	

Connector No.	B268
Connector Name	AIR BAG DIAGNOSIS SENSOR UNIT
Connector Type	NH22/FY-IV-EX



Terminal No.	Color Of Wire	Signal Name [Specification]
10	Y	PRH(+)
11	Y	PRH(-)
26	V	ODS_INPUIT
29	BG	RH BUCKLE SW (INPUT)
31	Y	SRH(+)
32	Y	SRH(-)
35	P	GRH(+)
36	L	GRH(-)

Connector No.	B213
Connector Name	AWD CONTROL UNIT
Connector Type	TH16/FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	SOL+
2	G	SOL-
3	V	
4	W	
5	L	IGN
6	W	CANH
7	L	CANL
8	L	
9	Y	SOLUB
10	B	GROUND
11	B	GROUND
12	P	CANL

Connector No.	B225
Connector Name	FUEL LEVEL SENSOR UNIT AND FUEL PUMP (MAIN)
Connector Type	SG205/FGY



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	
2	SB	
3	L	
4	BR	
5	G	


40	P	
41	GR	
42	Y	
43	Y	
44	V	
45	W	
51	SB	
52	G	
53	BR	
54	V	
60	R	
61	P	
62	L	
63	LG	
64	GR	
69	P	
70	L	
71	R	
80	L	
81	SB	
82	V	
83	B	
84	Y	
85	BR	
86	SHIELD	
87	W	
96	Y	
98	BG	
99	BR	
100	W	

Connector No.	B212
Connector Name	SEAT BELT BUCKLE SWITCH (PASSENGER SIDE)
Connector Type	TK03FW




Terminal No.	Color Of Wire	Signal Name [Specification]
2	B	
3	BG	

Connector No.	B61
Connector Name	WIRE TO WIRE
Connector Type	TH12/FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	
2	W	
3	G	
4	V	
5	W	
6	W	
7	V	
8	L	
9	BG	
10	GR	
11	LG	

Connector No.	B201
Connector Name	WIRE TO WIRE
Connector Type	TH80/FW-CST6-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
6	G	
7	V	
8	BG	
9	W	
10	R	
31	V	
32	LG	
33	BR	
34	L	

JRNWE1194GB

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

METER

47	G	SATELLITE RH(+)
48	R	SATELLITE RH(-)
55	SHIELD	GROUND

Connector No.	E30
Connector Name	WASHER LEVEL SWITCH
Connector Type	Z02FBR




Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
2	BW	-

Connector No.	E40
Connector Name	FRONT COMBINATION LAMP LH
Connector Type	RS08FB-FR



Terminal No.	Color Of Wire	Signal Name [Specification]
1	BW	-
2	B/G	-
3	Y	-
4	B/P	-
5	P	-
6	G	-
7	EG	-
8	R	-

Connector No.	E41
Connector Name	ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)
Connector Type	AEZ43FB-AJZA



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	UBNR
2	V	DMS-K
3	GR	VDC OFF SW
4	W	BLS
6	G	VDC UP SW
11	Y	CAN-H
15	P	CAN-L
16	B	GROUND
26	W	CAN-L
27	BR	G SENSOR GROUND
29	BG	LZ
30	L	CAN-H
32	BG	UBVR
33	W	DS FR
34	BG	DP FR
35	Y	VDC TOP POSITION LED
36	L	DP RL
37	R	DS RL
38	V	BRAKE FLUID LEVEL SW
39	G	G SENSOR POWER
42	V	DS RR
43	LG	DP RR
44	SB	VDC TOP POSITION LED
45	W	DP FL
46	R	DS FL
47	B	GROUND

Connector No.	E47
Connector Name	BRAKE FLUID LEVEL SWITCH
Connector Type	YV02FGY



Terminal No.	Color Of Wire	Signal Name [Specification]
1	V	-
2	BW	-

Connector No.	E49
Connector Name	WIRE TO WIRE
Connector Type	RH08MB



Terminal No.	Color Of Wire	Signal Name [Specification]
2	V	-
3	BR	-
4	P	-
6	P	-
7	B	-
8	Y	-

Connector No.	E59
Connector Name	FRONT COMBINATION LAMP RH
Connector Type	RS08FB-FR



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
2	BR	-
3	R	-
4	BO	-
5	R	-
6	V	-
7	BR	-
8	BG	-

Connector No.	E76
Connector Name	AMBIENT SENSOR
Connector Type	RS02FB



Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	AMBIENT SENSOR SIGNAL
2	P	SENSOR GROUND

JRNWE1195GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P




COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

METER

Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	TH89FW-C516-TM4



Terminal No.	Color	Wire	Signal Name [Specification]
1	V	-	-
2	EG	-	-
3	EG	-	-
4	EG	-	-
5	P	-	-
6	P	-	-
7	EG	-	-
8	W	-	-
9	W	-	-
10	Y	-	-
11	SB	-	-
12	EG	-	-
13	P	-	-
14	L	-	-
15	SB	-	-
16	EG	-	-
17	SHIELD	-	-
18	L	-	-
19	P	-	-
20	B	-	-
21	Y	-	-
22	V	-	-
23	Y	-	-
24	V	-	-
25	BR	-	-
26	L	-	-
27	SHIELD	-	-
28	G	-	-
29	R	-	-
30	W	-	-
31	V	-	-
32	G	-	-
33	GR	-	-
34	GP	-	-
35	LG	-	-
36	G	-	-
37	Y	-	-

38	SB	-	-
39	GR	-	-
40	G	-	-
41	V	-	-
42	V	-	-
43	L	-	-
44	BR	-	-
45	G	-	-
46	SB	-	-
47	EG	-	-
48	EG	-	-
49	L	-	-
50	R	-	-
51	SHIELD	-	-
60	P	-	-
61	L	-	-
71	LG	-	-
72	SB	-	-
74	P	-	-
75	BR	-	-
76	LG	-	-
77	V	-	-
78	BR	-	-
79	W	-	-
80	Y	-	-
81	GR	-	-
82	EG	-	-
84	P	-	-
85	P	-	-
86	GR	-	-
87	R	-	-
88	L	-	-
89	EG	-	-
90	G	-	-
91	GR	-	-
92	R	-	-
93	R	-	-
94	LG	-	-
95	G	-	-
96	GR	-	-
97	L	-	-
98	LG	-	-
99	EG	-	-
100	L	-	-

Connector No.	E155
Connector Name	WIRE TO WIRE
Connector Type	TH94FW-NH



Terminal No.	Color	Wire	Signal Name [Specification]
1	R	-	-
3	Y	-	-
4	R	-	-

Connector No.	E254
Connector Name	ALTERNATOR
Connector Type	HS03FB



Terminal No.	Color	Wire	Signal Name [Specification]
2	BR	-	L
3	V	-	S
4	P	-	C

Connector No.	E251
Connector Name	WIRE TO WIRE
Connector Type	RH08FB



Terminal No.	Color	Wire	Signal Name [Specification]
2	GR	-	-
3	BR	-	-
4	V	-	-
6	P	-	-
7	B	-	-
8	W	-	-

Connector No.	E255
Connector Name	OIL PRESSURE SENSOR
Connector Type	FK03FB



Terminal No.	Color	Wire	Signal Name [Specification]
1	GR	-	-
2	W	-	-
3	B	-	-

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >


METER

Connector No.	F38
Connector Name	OIL LEVEL SENSOR
Connector Type	RS03FSE-GY



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	OIL LEVEL SENSOR GROUND
3	GR	OIL LEVEL SENSOR SIGNAL


Connector No.	F103
Connector Name	WIRE TO WIRE
Connector Type	TK36FW-NS10



Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	-
2	R	-
3	W	-
6	O	-
7	B	-
8	B	-
9	W	-
11	B	-
12	LG	-
13	SB	-
14	LG	-
15	G	-
18	W	-
19	GR	-
20	R	-
21	O	-
26	L	-
27	P	-


28	LG	-
29	R	-
30	L	-
31	R	-
32	W	-
33	W	-
34	Y	-
39	Y	-

Connector No.	M1
Connector Name	FUSE BLOCK (JIB)
Connector Type	NS06FW-M2




Terminal No.	Color Of Wire	Signal Name [Specification]
1A	V	-
2A	G	-
3A	L	-
4A	LG	-
5A	SB	-
6A	Y	-
7A	R	-
8A	L	-

Connector No.	M3
Connector Name	FUSE BLOCK (JIB)
Connector Type	NS12FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
10C	L	-
11C	R	-
12C	W	-
6C	R	-
7C	B	-
9C	BR	-

Connector No.	M5
Connector Name	WIRE TO WIRE
Connector Type	TI-80MW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
3	R	-
4	G	-
5	Y	-
6	P	-
7	W	-
8	V	-
9	L	-
10	Y	-
11	G	-
12	BG	-
13	R	-
14	L	-
15	BR	-
16	R	-
17	SHIELD	-
18	L	-
19	P	-
20	B	-
21	W	-
22	GR	-
23	L	-
24	V	-
25	BR	-
26	G	-
27	SHIELD	-

28	G	-
29	R	-
30	W	-
31	V	-
32	G	-
33	GR	-
34	LG	-
35	P	-
36	L	-
37	W	-
38	Y	-
39	GR	-
40	BG	-
41	W	-
42	R	-
43	V	-
44	BR	-
45	G	-
46	LG	-
48	W	-
49	L	-
50	R	-
51	SHIELD	-
60	SB	-
61	V	-
71	W	-
72	LG	-
74	R	-
75	BR	-
76	LG	-
77	R	-
78	BR	-
79	W	-
80	Y	-
81	BG	-
82	SB	-
84	Y	-
85	P	-
86	GR	-
87	R	-
88	L	-
89	G	-
90	P	-
91	W	-
92	R	-
93	LG	-
94	W	-
95	SB	-
96	L	-
97	L	-

A
B
C
D
E
F
G
H
I
J
K
L
M
MWI
O
P


COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

METER

98	Y	-
99	BG	-
100	L	-

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	TH-R00MW-CS16-TM4




Terminal No.	Color	Wire	Signal Name (Specification)
2	L	-	-
3	P	-	-
6	L	-	-
7	W	-	-
8	W	-	-
9	G	-	-
10	R	-	-
11	W	-	-
12	SB	-	-
13	G	-	-
14	W	-	-
15	BR	-	-
16	R	-	-
17	BG	-	-
18	SB	-	-
20	GR	-	-
21	L	-	-
22	R	-	-
23	G	-	-
24	BR	-	-
25	L	-	-
26	LG	-	-
27	W	-	-
28	R	-	-
31	GR	-	-
32	V	-	-
33	V	-	-
34	BG	-	-
39	W	-	-
40	BG	-	-
41	R	-	-

42	V	-
43	W	-
47	G	-
48	R	-
49	W	-
50	SHIELD	-
51	SB	-
52	B	-
53	R	-
54	B	-
56	R	-
57	G	-
58	G	-
59	R	-
60	BR	-
61	Y	-
62	SHIELD	-
63	GR	-
64	R	-
65	G	-
66	BR	-
67	BG	-
69	P	-
70	L	-
71	SHIELD	-
72	V	- [Without active noise control unit] - [With active noise control unit]
73	LG	-
76	R	-
77	SB	-
78	G	-
79	Y	-
80	R	-
81	G	-
82	BR	- [Without active noise control unit] - [With active noise control unit]
83	R	- [Without active noise control unit]
84	SHIELD	-
85	V	-
86	LG	- [Without active noise control unit] - [With active noise control unit]
87	L	-
88	P	-
89	SHIELD	-
90	V	-
92	LG	-
93	Y	-
94	G	-
95	R	-

96	Y	-
97	R	-
98	G	-
99	L	-
100	W	-

Connector No.	M14
Connector Name	LOW TIRE PRESSURE WARNING CONTROL UNIT
Connector Type	TH-R2FW-NH



Terminal No.	Color	Wire	Signal Name (Specification)
1	P	-	CANL
2	L	-	CANH
3	BG	-	RR TUNER (SIG)
4	L	-	RL TUNER (SIG)
5	R	-	FR TUNER (SIG)
6	W	-	FL TUNER (SIG)
7	SB	-	RR TUNER (PWR)
8	GR	-	RL TUNER (PWR)
9	R	-	FR TUNER (PWR)
10	LG	-	FL TUNER (PWR)
12	W	-	SW SIG
15	G	-	IGN
19	R	-	RR TUNER (RSSI)
20	BG	-	RL TUNER (RSSI)
21	P	-	FR TUNER (RSSI)
22	G	-	FL TUNER (RSSI)
23	GR	-	RR TUNER (GND)
24	V	-	RL TUNER (GND)
25	L	-	FR TUNER (GND)
26	BR	-	FL TUNER (GND)
30	G	-	FLASHER SIG
32	B	-	GROUND

Connector No.	M24
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FW



Terminal No.	Color	Wire	Signal Name (Specification)
3	R	-	-
4	B	-	-
5	B	-	-
6	L	-	-
7	V	-	-
8	G	-	-
11	G	-	-
14	P	-	-
16	Y	-	-

Connector No.	M53
Connector Name	COMBINATION METER
Connector Type	ISAB40FW



Terminal No.	Color	Wire	Signal Name (Specification)
1	V	-	BATTERY POWER SUPPLY
2	W	-	IGNITION POWER SUPPLY
3	B	-	GROUND
4	B	-	ILLUMINATION GROUND
5	B	-	GROUND
6	W	-	METER CONTROL SWITCH GROUND
7	V	-	AC AUTO AMP COMPACTOR MOTOR SIGNAL
8	SB	-	AMBIENT SENSOR GROUND
9	P	-	AMBIENT SENSOR SIGNAL
12	L	-	VEHICLE SPEED SIGNAL (2-PULSE)
13	V	-	VEHICLE SPEED SIGNAL (8-PULSE)


COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

METER

Terminal No.	Wire	Signal Name [Specification]
14	B	OIL PRESSURE SENSOR GROUND
15	R	AIR BAG SIGNAL
16	R	LED HEAD LAMP (RH) WARNING SIGNAL
18	L	FUEL LEVEL SENSOR GROUND
19	R	OIL LEVEL SENSOR GROUND
20	W	OIL LEVEL SENSOR SIGNAL
21	L	CANH
22	P	CANH
23	LG	ILLUMINATION CONTROL SWITCH SIGNAL (L)
24	BR	ILLUMINATION CONTROL SWITCH SIGNAL (R)
25	G	TRIP AB RESET SWITCH SIGNAL
26	BG	ENTER SWITCH SIGNAL
27	SB	SELECT SWITCH SIGNAL
28	BR	ALTERNATOR
29	G	SEAT BELT PRECISE EMERGENCY SIGNAL (PASSENGER SIDE)
30	LG	SEAT BELT PRECISE EMERGENCY SIGNAL (DRIVER SIDE)
31	V	PARKING BRAKE SWITCH SIGNAL
32	V	BRAKE FLUID LEVEL SWITCH SIGNAL
33	L	WASHER LEVEL SWITCH SIGNAL
34	GR	OIL PRESSURE SENSOR POWER
35	W	OIL PRESSURE SENSOR SIGNAL
38	BG	FUEL LEVEL SENSOR SIGNAL
39	Y	LED HEAD LAMP (LH) WARNING SIGNAL
40	V	ILLUMINATION CONTROL

Connector No.	M54
Connector Name	METER CONTROL SWITCH
Connector Type	TH12FW-NH




Terminal No.	Wire	Signal Name [Specification]
1	BR	-
2	W	-
3	LG	-
4	R	-
5	V	-
6	BG	-
7	SB	-
8	G	-

Connector No.	M66
Connector Name	A/C AUTO AMP.
Connector Type	SAB40FW



Terminal No.	Wire	Signal Name [Specification]
1	L	CANH
2	P	CANH
10	L	A/C LAMP SIGNAL
11	R	EACH DOOR MOTOR POWER SUPPLY
15	BG	SUNLOAD SENSOR SIGNAL
16	R	INTAKE SENSOR SIGNAL
17	SB	ACC POWER SUPPLY
19	B	GROUND
20	G	IGNITION POWER SUPPLY
24	BG	ECV SIGNAL
32	L	BLOWER MOTOR CONTROL SIGNAL
34	Y	A/C AUTO AMP CONNECTION SIGNAL
35	P	AMBIENT SENSOR SIGNAL
36	LG	IN-VEHICLE SENSOR SIGNAL
37	BG	SENSOR GROUND
39	B	GROUND
40	Y	BATTERY POWER SUPPLY

Connector No.	M107
Connector Name	ECM
Connector Type	RH24FGY-R28-RLH-Z



Terminal No.	Wire	Signal Name [Specification]
97	P	CAN COMMUNICATION LINE
99	SB	SENSOR POWER SUPPLY
100	BR	SENSOR POWER SUPPLY

Terminal No.	Wire	Signal Name [Specification]
101	L	CAN COMMUNICATION LINE
102	G	ASCD STEERING SWITCH
103	GR	SENSOR GROUND
104	P	ACCELERATOR PEDAL POSITION SENSOR 1
105	W	ECM RELAY (SELF SHUT-OFF)
106	LG	IGNITION SWITCH
107	BG	SENSOR GROUND
108	L	ACCELERATOR PEDAL POSITION SENSOR 2
109	L	SAVALVERLY
110	P	STOP LAMP SWITCH
111	GR	PNP SIGNAL
113	SB	ENGINE SPEED OUTPUT SIGNAL
114	V	DATA LINK CONNECTOR
117	R	ASCD BRAKE SWITCH
118	W	POWER SUPPLY FOR ECM (BACK-UP)
120	BR	SAPMERLY
121	P	POWER SUPPLY FOR ECM
122	V	POWER SUPPLY FOR ECM
124	B	ECM GROUND
126	L	FUEL PUMP RELAY
127	G	THROTTLE CONTROL MOTOR RELAY
128	B	ECM GROUND


Connector No.	M116
Connector Name	WIRE TO WIRE
Connector Type	TK36MM-NS10



Terminal No.	Wire	Signal Name [Specification]
1	G	-
2	R	-
3	W	-
6	P	-
7	B	-
8	B	-
9	W	-
11	B	-
12	LG	-
13	B	-
14	BR	-
15	G	-

Terminal No.	Wire	Signal Name [Specification]
16	W	-
19	W	-
20	R	-
21	BG	-
26	L	-
27	Y	-
28	LG	-
29	BR	-
30	Y	-
31	R	-
32	LG	-
33	LG	-
34	Y	-
39	V	-

Connector No.	M117
Connector Name	WIRE TO WIRE
Connector Type	TR80MM-CS16-TM4



Terminal No.	Wire	Signal Name [Specification]
6	G	-
7	V	-
8	G	-
9	W	-
10	L	-
31	Y	-
32	LG	-
33	BR	-
34	L	-
40	G	-
41	R	-
42	SB	-
43	L	-
44	R	-
45	C	-
51	SB	-
52	BG	-
53	R	-
54	GR	-
60	L	-

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MWI

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

Terminal No.	Color Of Wire	Signal Name (Specification)
53	Y	SIDE SENS LH2+
54	BR	SIDE SENS LH2-
59	L	CAN-H
60	P	CAN-L

Connector No.	M203
Connector Name	AV CONTROL UNIT
Connector Type	TH32FM-NH

Terminal No.	Wire	Signal Name (Specification)
85	R	PARKING BRAKE
87	W	COMPOSITE IMAGE GND
88	R	COMPOSITE IMAGE SIGNAL
71	SHIELD	MICROPHONE GND
72	L	MICROPHONE VCC
73	V	COMM (CONT-DISP)
74	P	CANL
75	R	AV COMM (L)
76	R	AV COMM (L)
79	R	ILLUMINATION
80	W	IGNITION
81	BG	REVERSE
82	V	VEHICLE SPEED (8-PULSE)
83	SHIELD	SHIELD
84	B	COMPOSITE SYNCHRONIZING SIGNAL
87	P	MICROPHONE SIGNAL
88	SHIELD	SHIELD
89	SB	COMM (DISP-CONT)
90	L	CAN-H
91	G	AV COMM (H)
92	G	AV COMM (H)

Connector No.	M142
Connector Name	WIFE TO WIRE
Connector Type	TH4MMV-NH

Terminal No.	Wire	Signal Name (Specification)
1	R	IGN
2	B	GROUND
3	Y	DR1 (-) DR2 (-)
4	Y	DR1 (+)
5	Y	DR2 (+)
6	Y	AS2 (+)
7	Y	AS1 (-)
8	Y	AS2 (+)
9	Y	AS2 (-)
18	SB	EC2S (+)
19	V	EC2S (-)
22	SHIELD	GROUND
23	R	AIR BAG W/L
24	G	SEAT BELT
25	R	CUTOFF TAIL
51	R	SIDE SENS RH2-
52	G	SIDE SENS RH2-

Connector No.	M157
Connector Name	AIR BAG DIAGNOSIS SENSOR UNIT
Connector Type	IN258FV-EX

Terminal No.	Wire	Signal Name (Specification)
1	R	IGN
2	B	GROUND
3	Y	DR1 (-) DR2 (-)
4	Y	DR1 (+)
5	Y	DR2 (+)
6	Y	AS2 (+)
7	Y	AS1 (-)
8	Y	AS2 (+)
9	Y	AS2 (-)
18	SB	EC2S (+)
19	V	EC2S (-)
22	SHIELD	GROUND
23	R	AIR BAG W/L
24	G	SEAT BELT
25	R	CUTOFF TAIL
51	R	SIDE SENS RH2-
52	G	SIDE SENS RH2-

Terminal No.	Wire	Signal Name (Specification)
1	V	-

Connector No.	M132
Connector Name	PARKING BRAKE SWITCH
Connector Type	P01FB-A

Terminal No.	Wire	Signal Name (Specification)
1	V	-

Connector No.	M122
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH

Terminal No.	Wire	Signal Name (Specification)
72	R	ROOM ANT2-
73	G	ROOM ANT2+
74	SB	PASSENGER DOOR ANT-
75	BR	PASSENGER DOOR ANT+
76	V	DRIVER DOOR ANT-
77	LG	DRIVER DOOR ANT+
78	Y	ROOM ANT1-
79	BR	ROOM ANT1+
80	GR	IMMOBI ANTENNA CONTROL
81	GR	IMMOBI ANTENNA SIGNAL
82	R	IGN RELAY (FB) CONT
83	Y	KEYLESS ENTRY RECEIVER COMM
87	BR	COMBI SW INPUT 3
88	V	COMBI SW INPUT 3
89	BR	PUSH SW

Terminal No.	Wire	Signal Name (Specification)
90	P	CAN-L
91	L	CAN-H
92	LG	KEY SLOT ILL OUTPUT
93	V	ON IND
95	BG	ACC RELAY CONT
96	SB	A/T SHIFT SELECTOR POWER SUPPLY
97	L	S/L CONDITION 1
98	R	S/L CONDITION 2
99	G	SHIFT P
100	W	PASSENGER DOOR REQUEST SW
101	V	DRIVER DOOR REQUEST SW
102	BG	BLOWER FAN MOTOR RELAY CONT
103	LG	KEYLESS ENTRY RECEIVER POWER SUPPLY
106	P	S/L UNIT POWER SUPPLY
107	LG	COMBI SW INPUT 1
108	R	COMBI SW INPUT 4
109	Y	COMBI SW INPUT 2
110	G	HAZARD SW
111	Y	S/L UNIT COMM

Connector No.	M132
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH

Terminal No.	Wire	Signal Name (Specification)
61	P	-
62	L	-
63	Y	-
64	LG	-
69	P	-
70	L	-
80	L	-
81	G	-
82	BR	-
83	B	-
84	V	-
85	SB	-
86	SHIELD	-
87	W	-
86	Y	-
88	G	-
89	V	-
100	W	-

METER

Fail-safe

FAIL-SAFE

If the CAN communication with each unit is activates, the combination meter broken the fail-safe control.

JRNWE1200GB

INFOID:000000011488321

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

System	Processing	A
Speedometer	Returns to zero when communication is blocked.	B
Tachometer		
Engine coolant temperature gauge		
Meter illumination control	Shifts to night mode when communication is blocked.	C
Shift position indicator	Turned OFF when communication is blocked.	
Information display	Door open warning	Indication is turned OFF when communication is blocked.
	Trunk open warning	
	Parking brake release warning	
	Shift " P " warning	
	Transmission system check	
	Shift lever position warning	
	Transmission clutch high temperature warning	
	Transmission oil high temperature warning	
	Transmission system warning	
	Run-flat tire warning	
	Low tire pressure warning	
	Tire pressure monitoring system warning	
	AWD clutch high temperature warning	
	Front/rear tire size discrepancy warning	
	AWD system warning	
	Anti-lock braking system (ABS) warning	
	Vehicle dynamic control (VDC) system warning	
	Engine system warning	
	CRUISE control system warning	
	CRUISE control system status	
Reverse warning		
Vehicle speed display	0 km/h (0 MPH) is indicated when communication is blocked.	L
Possible driving distance	Displays the last calculation result calculated under a normal status when communication is blocked.	M
Average fuel consumption		
Instantaneous fuel consumption		
Average vehicle speed		
Warning buzzer	Warning is turned OFF when communication is blocked.	MWI

O

P

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

	System	Processing
Warning lamp/indicator lamp	ABS warning lamp	Turned ON when communication is broken.
	VDC warning lamp	
	Brake warning lamp	
	AWD warning lamp	
	Malfunction indicator lamp (MIL)	
	Tire pressure warning lamp	Blinks first, then illuminates after approximately 1 minute.
	High beam indicator lamp	Turned OFF when communication is broken.
	Turn signal indicator lamp	
	Tail lamp indicator lamp	
	CRUISE indicator lamp	
	SET indicator lamp	
	KEY warning lamp	
	Up-shift indicator (green)	
	Up-shift indicator (yellow)	
	Up-shift indicator (red)	
Transmission check warning lamp		
VDC OFF indicator lamp		

DTC Index

INFOID:0000000011488322

NOTE:

Details of time display

- CRNT: Displays during the current malfunctioning detection.
- PAST: Displays if any previous malfunction is present when the current status is normal.

IGN counter

- The IGN counter is displayed in the freeze frame data (FFD).
- The IGN counter indicates the number of times ignition switch is turned ON after the DTC detection.
- When a trouble is currently being detected, it displays "0".
- After the status returns to normal, the indication value is incremented as "1 → 2 → 3 → ... 38 → 39" every time the ignition switch is turned OFF → ON.
- When the operation count of ignition switch OFF → ON exceeds 39, the indication will be fixed at "39" until the self-diagnosis is deleted.

Display contents of CONSULT	Diagnostic item is detected if ...	Refer to
CAN COMM CIRCUIT [U1000]	Combination meter cannot communicate CAN communication signal for 2 seconds or more	MWI-61. "Diagnosis Procedure"
CONTROL UNIT (CAN) [U1010]	Malfunction is detected during initial diagnosis of combination meter CAN controller	MWI-62. "Diagnosis Procedure"
VEHICLE SPEED [B2205]	Abnormal vehicle speed signal is received from ABS actuator and electric unit (control unit) for 2 seconds or more	MWI-63. "Diagnosis Procedure"
ENGINE SPEED [B2267]	ECM continuously transmits abnormal engine speed signal for 2 seconds or more	MWI-64. "Diagnosis Procedure"

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

Display contents of CONSULT	Diagnostic item is detected if ...	Refer to
WATER TEMP [B2268]	ECM continuously transmits abnormal coolant temperature signal for 60 seconds or more	MWI-65. "Diagnosis Procedure"
OIL LEV SEN OPEN [B2321]	Signal from oil level sensor is open (resistance value of oil level sensor is larger than 20 Ω).	MWI-66. "Diagnosis Procedure"
OIL LEV SEN SHORT [B2322]	Signal from oil level sensor is shorted (resistance value of oil level sensor is smaller than 3 Ω).	MWI-66. "Diagnosis Procedure"

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

THE FUEL GAUGE POINTER DOES NOT MOVE

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

THE FUEL GAUGE POINTER DOES NOT MOVE

Description

INFOID:000000011488323

Fuel gauge pointer does not move from a certain position

Diagnosis Procedure

INFOID:000000011488324

1. CONDUCTING THE COMBINATION METER SELF-DIAGNOSIS MODE

Perform the self-diagnosis mode of combination meter, and then check that the fuel gauge operates normally. Refer to [MWI-54, "Diagnosis Description"](#).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Replace the combination meter.

2. CHECK FLOAT INTERFERENCE

Check that the float arm interferes with or binds to other components in the fuel tank.

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace malfunctioning part.

3. CHECK FUEL LEVEL SENSOR SIGNAL CIRCUIT

Check the fuel level sensor signal circuit. Refer to [MWI-69, "Component Function Check"](#).

Is the inspection result normal?

- YES >> Refer to [GI-39, "Intermittent Incident"](#).
- NO >> Repair or replace malfunctioning parts.

THE METER CONTROL SWITCH IS INOPERATIVE

< SYMPTOM DIAGNOSIS >

THE METER CONTROL SWITCH IS INOPERATIVE

Description

INFOID:000000011488325

If any of the following malfunctions are found for the meter control switch operation

- All switches are inoperative
- The specified switch cannot be operated

Diagnosis Procedure

INFOID:000000011488326

1.CHECK METER CONTROL SWITCH SIGNAL CIRCUIT

Perform the meter control switch signal circuit inspection. Refer to [MWI-72, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the harnesses or connectors.

2.CHECK METER CONTROL SWITCH

Perform the unit inspection of meter control switch. Refer to [MWI-73, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace the combination meter.

NO >> Replace the meter control switch.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

THE OIL PRESSURE WARNING LAMP DOES NOT TURN ON OR OFF

< SYMPTOM DIAGNOSIS >

THE OIL PRESSURE WARNING LAMP DOES NOT TURN ON OR OFF

Description

INFOID:000000011488327

Oil pressure warning lamp does not illuminate when ignition switch turns ON, or oil pressure warning lamp stays illuminated while engine is running (when oil pressure is normal).

Diagnosis Procedure

INFOID:000000011488328

1. CHECK COMBINATION METER INPUT SIGNAL

Connect CONSULT, and perform the combination meter input signal inspection. Refer to [MWI-74, "Component Function Check"](#).

Is the inspection result normal?

YES >> Replace the combination meter.

NO >> GO TO 2.

2. CHECK OIL PRESSURE SENSOR SIGNAL CIRCUIT

Perform the oil pressure sensor signal circuit inspection. Refer to [MWI-74, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the harnesses or connectors.

3. CHECK OIL PRESSURE SENSOR

Perform the unit inspection of oil pressure sensor. Refer to [MWI-74, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace the combination meter.

NO >> Replace the oil pressure sensor.

THE PARKING BRAKE RELEASE WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

< SYMPTOM DIAGNOSIS >

THE PARKING BRAKE RELEASE WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

Description

INFOID:000000011488329

- The parking brake warning is displayed during vehicle travel even though the parking brake is released
- The parking brake warning is not displayed even though the vehicle is being driven with the parking brake applied

Diagnosis Procedure

INFOID:000000011488330

1. BRAKE WARNING LAMP OPERATION CHECK

1. Start the engine.
2. Operate the parking brake, then check the illumination status of brake warning lamp.

Parking brake applied	:ON
Parking brake released	:OFF

Is the inspection result normal?

- YES >> Replace the combination meter.
NO >> GO TO 2.

2. CHECK PARKING BRAKE SWITCH SIGNAL CIRCUIT

Perform the parking brake switch signal circuit inspection. Refer to [MWI-76, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair the harnesses or connectors.

3. CHECK PARKING BRAKE SWITCH

Perform the unit inspection of parking brake switch. Refer to [MWI-76, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace the combination meter.
NO >> Replace the parking brake switch.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

THE DOOR OPEN WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

< SYMPTOM DIAGNOSIS >

THE DOOR OPEN WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

Description

INFOID:000000011488331

- The door open warning is displayed while all doors are fully closed.
- The door open warning is not displayed while a door is not fully closed.

Diagnosis Procedure

INFOID:000000011488332

1. CHECK BCM INPUT SIGNAL

Connect CONSULT and inspect the BCM input signals. Refer to [DLK-63, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> GO TO 3.

2. CHECK COMBINATION METER INPUT SIGNAL

1. Connect CONSULT.
2. Select "DATA MONITOR" for the "METER/M&A", and then check the "DOOR W/L" monitor value.

DOOR W/L	
Door open	: On
Door closed	: Off

Is the inspection result normal?

- YES >> Replace the combination meter.
- NO >> Replace BCM. Refer to [BCS-89, "Removal and Installation"](#).

3. CHECK DOOR SWITCH SIGNAL CIRCUIT

Perform the door switch signal circuit inspection. Refer to [DLK-63, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair the harnesses or connectors.

4. CHECK DOOR SWITCH

Perform the unit inspection of door switch. Refer to [DLK-64, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace the combination meter.
- NO >> Replace the malfunctioning door switch. Refer to [DLK-258, "Removal and Installation"](#).

THE TRUNK OPEN WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

< SYMPTOM DIAGNOSIS >

THE TRUNK OPEN WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

Description

INFOID:000000011488333

- The trunk warning while the trunk lid is fully closed.
- Trunk warning is not displayed while the trunk lid is not fully closed.

Diagnosis Procedure

INFOID:000000011488334

1.CHECK BCM INPUT SIGNAL

Connect CONSULT and inspect the BCM input signals. Refer to [DLK-63, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> GO TO 3.

2.CHECK COMBINATION METER INPUT SIGNAL

1. Connect CONSULT.
2. Select "DATA MONITOR" for the "METER/M&A", and then check the "DOOR W/L" monitor value.

DOOR W/L

Trunk lid open : On

Trunk lid closed : Off

Is the inspection result normal?

- YES >> Replace the combination meter.
- NO >> Replace BCM. Refer to [BCS-89, "Removal and Installation"](#).

3.CHECK TRUNK LID OPENER SWITCH SIGNAL CIRCUIT

Perform the trunk lid opener switch signal circuit inspection. Refer to [DLK-77, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair the harnesses or connectors.

4.CHECK TRUNK LID OPENER SWITCH

Perform the unit inspection of trunk lid opener switch. Refer to [DLK-78, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace the combination meter.
- NO >> Replace the trunk lid opener switch. Refer to [DLK-266, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M

MWI

THE LOW WASHER FLUID WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

< SYMPTOM DIAGNOSIS >

THE LOW WASHER FLUID WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

Description

INFOID:000000011488335

- Low washer fluid warning is still displayed even after washer fluid is added.
- Low washer fluid warning is not displayed even when washer fluid is not filled.

Diagnosis Procedure

INFOID:000000011488336

1.CHECK WASHER LEVEL SWITCH SIGNAL CIRCUIT

Check the washer level switch signal circuit. Refer to [MWI-78. "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the harnesses or connectors.

2.CHECK WASHER LEVEL SWITCH COMPONENT PARTS

Perform the inspection of washer level switch component parts. Refer to [MWI-78. "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace the combination meter.

NO >> Replace the washer level switch. Refer to [WW-94. "Removal and Installation"](#).

THE AMBIENT TEMPERATURE DISPLAY IS INCORRECT

< SYMPTOM DIAGNOSIS >

THE AMBIENT TEMPERATURE DISPLAY IS INCORRECT

Description

INFOID:000000011488337

- The displayed ambient air temperature is higher than the actual temperature.
- The displayed ambient air temperature is lower than the actual temperature.

Diagnosis Procedure

INFOID:000000011488338

NOTE:

Before starting diagnosis, check if the symptom is applicable to the "Symptom by normal operation". Refer to [MWI-110, "INFORMATION DISPLAY : Description"](#).

1.CHECK A/C AUTO AMP. CONNECTION RECOGNITION SIGNAL CIRCUIT

Perform the A/C auto amp. connection recognition signal circuit inspection. Refer to [MWI-80, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the harnesses or connectors.

2.CHECK AMBIENT SENSOR SIGNAL CIRCUIT

Perform the ambient sensor signal circuit inspection. Refer to [HAC-43, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the harnesses or connectors.

3.CHECK AMBIENT SENSOR

Perform the unit inspection of ambient sensor. Refer to [HAC-44, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace the combination meter.

NO >> Replace the ambient sensor.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

NORMAL OPERATING CONDITION INFORMATION DISPLAY

INFORMATION DISPLAY : Description

INFOID:000000011488339

OIL LEVEL DISPLAY

After mounting/removing of battery or combination meter, the combination meter power supply is cut off temporarily. Therefore, the engine oil amount data may be erased from the combination meter, causing the oil level to be not displayed. Refer to [MWI-39, "INFORMATION DISPLAY : System Description"](#) for the condition that the combination meter reads the resistance of oil level sensor.

AMBIENT AIR TEMPERATURE

For the ambient air temperature display, the value is displayed on the information display after the signal from ambient sensor is corrected by the combination meter. Therefore, the indication value may not match the actual ambient air temperature. Refer to [MWI-39, "INFORMATION DISPLAY : System Description"](#) for details on the correction process.

POSSIBLE DRIVING DISTANCE

The calculated distance to empty may differ from the actual distance to empty if the refueling amount is approximately 15 ℓ (4 US gal, 3-1/4 Imp gal) or less. This is because the refuel control (moves the fuel gauge needle quicker than normal judging that the driver is refueling the vehicle) is not performed in such a case.

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000011488340

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precaution for Battery Service

INFOID:000000011488341

Before disconnecting the battery, lower both the driver and passenger windows. This will prevent any interference between the window edge and the vehicle when the door is opened/closed. During normal operation, the window slightly raises and lowers automatically to prevent any window to vehicle interference. The automatic window function will not work with the battery disconnected.

Precautions for Removing Battery Terminal

INFOID:000000011488342

- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.

NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.


NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.



A
B
C
D
E
F
G
H
I
J
K
L
M

MWI

O
P

PREPARATION


< PREPARATION >

PREPARATION

PREPARATION

Commercial Service Tools

INFOID:000000011488343

Tool name	Description
<p data-bbox="162 520 272 546">Power tool</p>  <p data-bbox="829 632 899 646">PBIC0191E</p>	<p data-bbox="1008 520 1192 546">Loosening screws</p>

COMBINATION METER

< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION

COMBINATION METER

Exploded View


INFOID:000000011488344

REMOVAL

Cluster Lid A


Refer to [IP-12, "Exploded View"](#).

Combination Meter



- | | | |
|------------------------------|-------------------------|------------------------------|
| 1. Cluster lid A rear cover | 2. Combination meter | 3. Bracket |
| 4. Meter housing | 5. Meter control switch | 6. Cluster lid A under cover |
| 7. Cluster lid A front cover | | |

DISASSEMBLY



- | | | |
|--------------------------------|------------------|----------------|
| 1. Meter control unit assembly | 2. Upper housing | 3. Front cover |
|--------------------------------|------------------|----------------|

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MWI

COMBINATION METER


< REMOVAL AND INSTALLATION >

Removal and Installation


INFOID:000000011488345

REMOVAL

1. Remove the cluster lid A from the vehicle. Refer to [IP-13. "Removal and Installation"](#).
2. Remove the meter control switch connector (1) from the combination meter (2).
3. Remove the screws (A), and then remove the cluster lid A rear cover (3).
4. Remove screws (B).



5. Remove the screws (A), and then remove the combination meter (1).



INSTALLATION

Install in the reverse order of removal.

Disassembly and Assembly

INFOID:000000011488346

DISASSEMBLY

1. Remove the tabs, and then remove the upper housing.
2. Remove the tabs, and then remove the front cover.

ASSEMBLY

Assemble the reverse order of disassembly.

METER CONTROL SWITCH

< REMOVAL AND INSTALLATION >

METER CONTROL SWITCH


Exploded View

INFOID:000000011488347

REMOVAL

Refer to [IP-12, "Exploded View"](#).

DISASSEMBLY




- | | | |
|------------------------------|------------------------------|-------------------------|
| 1. Bracket | 2. Meter housing | 3. Meter control switch |
| 4. Cluster lid A under cover | 5. Cluster lid A front cover | |

Removal and Installation


INFOID:000000011488348

REMOVAL

1. Remove the combination meter.
2. Remove the screws (A), and then remove the cluster lid A front cover (1).



3. Remove the screws (A), and then remove the bracket and meter housing (1).



A
B
C
D
E
F
G
H
I
J
K
L
M


MWI

O
P

METER CONTROL SWITCH

< REMOVAL AND INSTALLATION >

4. Remove the screws (A), and then remove the drive computer switch (1), illumination control switch, and trip A/B reset switch (2).



INSTALLATION

Install in the reverse order of removal.