ENGINE CONTROL SYSTEM

SECTION EF & EC

CONTENTS

VG30E	
ENGINE AND EMISSION CONTROL OVERALL SYSTEM	2
ECCS Component Parts Location	
System Chart	
System Diagram	
Vacuum Hose Drawing	
Wiring Diagram	
Circuit Diagram	
IDLE SPEED/IGNITION TIMING/IDLE	9
Preparation	9
Overall inspection sequence	9
Idle check and set procedure1	0
TROUBLE DIAGNOSES 1	4
On-board Diagnostic System — Diagnostic	
Test Mode III	
Self-diagnostic Results1	4
Procedure1	
Diagnostic Procedure 221	5
Main Power Supply And Ground Circuit	
(Not self-diagnostic item)1	
Harness layout1	
Diagnostic Procedure 231	6
Camshaft Position Sensor (Diagnostic	
trouble code No. 11)1	
Harness layout1	
Diagnostic Procedure 241	8
Mass Air Flow Sensor (Diagnostic trouble	
code No. 12) CHECK (Malfunction Indicator	
Lamp Item)1	
Harness layout1	
Diagnostic Procedure 251	9
Engine Coolant Temperature Sensor	
(Diagnostic trouble code No. 13)	_
Hoheck (Malfunction Indicator Lamp Item)1	
Harness layout1	
Diagnostic Procedure 262	U

Vehicle Speed Sensor (Diagnostic trouble	
code No. 14) (Switch On/Off diagnostic	
item) HCHECK (Malfunction Indicator Lamp	
Item)	20
Harness layout	
Diagnostic Procedure 27	
Ignition Signal (Diagnostic trouble code No.	
21)	21
Hamess layout	21
Diagnostic Procedure 29	24
EGR Function (Diagnostic trouble code No.	
32) Heneck (Malfunction Indicator Lamp	
Item)	24
Harness layout	24
Diagnostic Procedure 30	
Heated Oxygen Sensor (Diagnostic trouble	
code No. 33) Hoheck (Malfunction Indicator	
Lamp Item)	25
Harness layout	
Diagnostic Procedure 31	
Knock Sensor (Diagnostic trouble code No.	
34)	28
Harness layout	
Diagnostic Procedure 32	
EGR Temperature Sensor (Diagnostic	
trouble code No. 35) HEHERE (Malfunction	
Indicator Lamp Item)	29
Harness layout	
Diagnostic Procedure 33	
Throttle Position Sensor (Diagnostic trouble	
code No. 43) الصادية (Malfunction Indicator	
Lamp Item)	30
Harness layout	
Diagnostic Procedure 35	
Injector Circuit (Diagnostic trouble code No.	
51) Hoheck (Malfunction Indicator Lamp	
Item)	31
11	

CONTENTS (Cont'd.)

Diagnostic Procedure 3632	Inrottle Position Sensor (IPS) & Soft Closed	GI
Closed Throttle Position Switch (Switch On/	Throttle Position (CTP) Switch54	(SI)
Off diagnostic item)32	Fuel Injector54	
Harness layout32	EGR Control (EGRC)-Solenoid Valve54	MA
Diagnostic Procedure 3733	Canister Control Solenoid Valve55	2015
Start Signal (Switch On/Off diagnostic item)33	SCV Control Solenoid Valve55	
Harness layout33	Canister Purge Control Valve55	EM.
Diagnostic Procedure 3834	Fuel Temperature Sensor55	
Fuel Pump (Not self-diagnostic item)34	Air Conditioner Cut Control56	п ф
Harness layout34	Input/Output Signal Line56	LC
Diagnostic Procedure 3936	System Description56	
IACV-Air Regulator (Not self-diagnostic	Canister Control56	
item)36	Input/Output Signal Line56	EC
Harness layout36	System Description56	
Diagnostic Procedure 4037	Canister Purge Control57	FE
IACV-AAC Valve (Not self-diagnostic item)37	Input/Output Signal Line57	
Harness layout37	System Description57	
Diagnostic Procedure 4138	On-board Diagnostic System — Description58	/S) II
Power Steering Oil Pressure Switch (Not	Malfunction Indicator Lamp Hoheck58	
self-diagnostic item)38	On-board Diagnostic System — Diagnostic	D.055
Harness layout38	Test Mode III (Self-diagnostic Results)59	MT
Diagnostic Procedure 4239	Display Diagnostic Trouble Code Table59	
Neutral Position/Inhibitor Switch (Not self-	Decoding Chart60	AT
diagnostic item)39	Diagnostic Procedure 2261	2.40
Harness layout39	Main Power Supply And Ground Circuit	
Electrical Components Inspection40	(Not self-diagnostic item)61	TF
ECM Harness Connector Terminal Layout 40	Harness layout61	
ECM Inspection table41	Diagnostic Procedure 2362	-
Resistor45	Camshaft Position Sensor (Diagnostic	PD
Heated Oxygen Sensor45	trouble code No. 11)62	
Heated Oxygen Sensor Heater45	Harness layout62	FA
Fuel Pump45	Diagnostic Procedure 2463	IF/AL
SERVICE DATA AND SPECIFICATIONS (SDS) 46	Mass Air Flow Sensor (Diagnostic trouble	
Inspection and Adjustment46	code No. 12) Higheck (Malfunction Indicator	RA
Fuel Pump46	Lamp Item)63	
Heated Oxygen Sensor Heater46	Harness layout63	
· · · · · · · · · · · · · · · · · · ·	Diagnostic Procedure 2564	BR
KA24E	Engine Coolant Temperature Sensor	
ENGINE AND EMISSION CONTROL OVERALL	(Diagnostic trouble code No. 13)	2025
SYSTEM		ST
ECCS Component Parts Location47	Harness layout64	
2WD M/T MODELS FOR CALIFORNIA48	Diagnostic Procedure 2665	BF
Except 2WD M/T Models For California49	Vehicle Speed Sensor (Diagnostic trouble	ں ح
System Diagram (2WD M/T models for	code No. 14) (Switch On/Off diagnostic	
California)50	item) Hoheck (Malfunction Indicator Lamp	HA
System Diagram (Except 2WD M/T models for	Item)	
California)51	Harness layout	
System Chart52	Diagnostic Procedure 2767	ĒĹ
ECCS Control System	Ignition Signal (Diagnostic trouble code	
Circuit Diagram53	No. 21)67	[DX
Ollouit Diagraff	140. 21/0/	אשוו

CONTENTS (Cont'd.)

Harness layout67	Neutral Position/Inhibitor Switch (Not self-	
Diagnostic Procedure 2970	diagnostic item)	89
EGR Function (Diagnostic trouble code No.	Harness layout	89
32) Існеск (Malfunction Indicator Lamp	Diagnostic Procedure 43	90
Item)70	Torque Converter Clutch Solenoid Valve	
Harness layout70	(Not self-diagnostic item)	90
Diagnostic Procedure 3073	Harness layout	90
Oxygen Sensor (Diagnostic trouble code	Diagnostic Procedure 44	
No. 33) HCHECK (Malfunction Indicator Lamp	Fuel Temperature Sensor (Diagnostic	
ltem)73	trouble code No. 42)	91
Harness layout73	Harness layout	
Diagnostic Procedure 3174	Diagnostic Procedure 45	
EGR Temperature Sensor (Diagnostic	Closed Throttle Position Switch (Not self-	
trouble code No. 35) HOHECK (Malfunction	diagnostic item)	93
Indicator Lamp Item)74	Harness layout	
Harness layout74	Diagnostic Procedure 46	
Diagnostic Procedure 3275	Canister Control Solenoid Valve (Not self-	
Intake Air Temperature Sensor (Diagnostic	diagnostic item)	95
trouble code No. 41)75	Harness layout	
Harness layout	Diagnostic Procedure 47	
Diagnostic Procedure 33	Canister Purge Control Valve (Not	00
Throttle Position Sensor (Diagnostic trouble	self-diagnostic item)	QR
code No. 43) CHECK (Malfunction Indicator	Harness layout	
Lamp Item)76	Electrical Components Inspection	
Harness layout	ECM Harness Connector Terminal Layout	
-	ECM inspection table	
Diagnostic Procedure 35	•	. 102
Start Signal (Switch On/Off diagnostic item)77	EGRC-Solenoid Valve, PAIRC-Solenoid	
Harness layout	Valve and SCV Control Solenoid Valve,	100
Diagnostic Procedure 36	Canister Control Solenoid Valve	. 100
PAIR Valve System (Not self-diagnostic	Canister Purge Control Valve (2WD M/T	100
item)	models for California)	. 100
Harness layout	Fuel Temperature Sensor (2WD M/T	100
Diagnostic Procedure 37	models for California)	
Injector (Not self-diagnostic item)81	Throttle Position Sensor	
Harness layout	Adjustment	. 107
Diagnostic Procedure 38	Closed Throttle Position (2WD M/T models	407
Fuel Pump (Not self-diagnostic item)83	for California)	
Harness layout83	Fuel Pump	
Diagnostic Procedure 3984	Resistor	
SCV Control (Not self-diagnostic item)84	Injector Removal and Installation	. 108
Harness layout84	EVAPORATIVE EMISSION SYSTEM — 2WD	
Diagnostic Procedure 4087	M/T Models for California	
IACV-AAC Valve (Not self-diagnostic item)87	Description	
Harness layout87	Inspection	
Diagnostic Procedure 4188	Canister	
Power Steering Oil Pressure Switch (Not	Canister Purge Cut Valve	
self-diagnostic item)88	Vacuum Control Valve	
Harness layout88	Fuel Tank Vacuum Relief Valve	. 110
Diagnostic Procedure 4289	EVAPORATIVE EMISSION SYSTEM — Except	
	2WD M/T Models for California	. 111

CONTENTS (Cont'd.)

Description	. 111	Check valve operation112	اھ اھ
Inspection	. 111	Check valve operation112 Rollover valve operation	(III
Canister	. 111	Fuel Tank Vacuum Relief Valve112	
Fuel Check Valve (With rollover valve)	112		MA

When you read wiring diagrams:

- Read GI section, "HOW TO READ WIRING DIAGRAMS".
 See EL section, "POWER SUPPLY ROUTING" for power distribution circuit.
 When you perform trouble diagnoses, read GI section, "HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES".

LC

EM

EC

FE

CL

MT

AT

TF

PD

FA

 $\mathbb{R}\mathbb{A}$

BR


ST

BF


HA

IDX

ECCS Component Parts Location




^{*}Truck models for California and Wagon models.




耴

IDX

System Diagram



Vacuum Hose Drawing



- ① EGRC-solenoid valve to Throttle body
- ② EGRC-solenoid valve to EGR valve
- EGRC-solenoid valve to Air duct
 Fuel pressure regulator to intake manifold collector
- ⑤ Carbon canister vacuum port to Throttle body
- 6 Carbon canister purge port to Vapor purge tube

61

MA

EM

LC

CL

MT

AT

ŢF

PD

FA

RA

BR

ST


BF

HA


EL

IDX


Wiring Diagram



Wiring Diagram (Cont'd)



Circuit Diagram



PREPARATION


- 1. Make sure that the following parts are in good order.
- **Battery**
- lanition system
- Engine oil and coolant levels
- **Fuses**
- **ECM SMJ** harness connector
- Vacuum hoses
- Air intake system (Oil filler cap, oil level gauge, etc.)
- **Fuel pressure**
- **Engine compression**
- EGR valve operation
- Throttle valve

- 2. On air conditioner equipped models, checks should be carried out while the air conditioner is "OFF".
- 3. On automatic transmission equipped models, when checking idle rpm, ignition MA timing and mixture ratio, checks should be carried out while shift lever is in "N" position.
- 4. When measuring "CO" percentage, insert probe more than 40 cm (15.7 in) into tail
- 5. Turn off headlamps, heater blower, rear defogger.
- 6. Keep front wheels pointed straight ahead.
- 7. Make the check after the cooling fan has stopped.

WARNING:

Apply parking brake and block both front and rear wheels with chocks.

Overall inspection sequence



EF & EC-9

LC

FE

CL

MT

 $\mathbb{R}\mathbb{A}$


\$T


85

HA


剧


 \mathbb{Z}






EF & EC-11





On-board Diagnostic System — Diagnostic Test Mode III Self-diagnostic Results

PROCEDURE



CAUTION:

• During display of a Diagnostic trouble code No. in on-board diagnostic system mode (Diagnostic Test Mode III), if another diagnostic test mode is to be performed, be sure to note the malfunction Diagnostic trouble code No. before turning diagnostic test mode selector on ECM fully clockwise. When selecting an alternative, select the diagnosis mode after turning switch "OFF". Otherwise, on-board diagnostic system information in the ECM memory will be lost.

G[

MA

LC

EF &

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

BF


AK

EL


IDX


Diagnostic Procedure 22

MAIN POWER SUPPLY AND GROUND CIRCUIT (Not self-diagnostic item)




Harness layout








197


CAMSHAFT POSITION SENSOR (Diagnostic trouble code No. 11)















IDX

MASS AIR FLOW SENSOR (Diagnostic trouble code No. 12) (MALFUNCTION INDICATOR LAMP ITEM)












ENGINE COOLANT TEMPERATURE SENSOR (Diagnostic trouble code No. 13)



Harness layout





GI

MA

EM

LC

EF &

FE

©[_

MT

AT

TF

PD

FA

RA

98


ST


3F

KA


IDX

VEHICLE SPEED SENSOR (Diagnostic trouble code No. 14) (Switch ON/OFF diagnostic item) HERE (MALFUNCTION INDICATOR LAMP ITEM)








IGNITION SIGNAL (Diagnostic trouble code No. 21)



Harness layout







MA

GI

em

LC

EF & EC

FE

ŒL.

MT

AT

TF

PD

FA

RA

BR

ST


BF

HA

EL


iDX

Diagnostic Procedure 27 (Cont'd)



Diagnostic Procedure 27 (Cont'd)

Perform FINAL CHECK by the following procedure after repair is completed.



MA

G

EM

LC

EF & FC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST


BF


HA


EL

IDX


EGR FUNCTION (Diagnostic trouble code No. 32) (MALFUNCTION INDICATOR LAMP ITEM)










HEATED OXYGEN SENSOR (Diagnostic trouble code No. 33) HORE (MALFUNCTION **INDICATOR LAMP ITEM)**



Harness layout







GI

MA

LC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST


BF

HA

EL

 $\mathbb{D}X$

EF & EC-25




nector and retest.

nector. Reconnect ECM harness con-

Diagnostic Procedure 30 (Cont'd)

Perform FINAL CHECK by the following procedure after repair is completed.



G1

MA

EM

LC

EF & EC

FE

CL

MT

ΑŢ

TF

PD

FA

RA

BR


ST


BF


HA


[DX]

KNOCK SENSOR (Diagnostic trouble code No. 34)












EGR TEMPERATURE SENSOR (Diagnostic trouble code No. 35) (MALFUNCTION INDICATOR LAMP ITEM)



Harness layout





G!

MA

LC

EF & EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST


36


HA


Œ


1DX

THROTTLE POSITION SENSOR (Diagnostic trouble code No. 43) (MALFUNCTION INDICATOR LAMP ITEM)












INJECTOR CIRCUIT (Diagnostic trouble code No. 51) (MALFUNCTION INDICATOR LAMP ITEM)



Harness layout





Œ

MA

LC

EF & EC

FE

CL

MT

AT

TF

PD

FA

 $\mathbb{R}\mathbb{A}$

BR


ST


BF


HA

EL


Diagnostic Procedure 36 CLOSED THROTTLE POSITION SWITCH (Switch ON/OFF diagnostic item)








START SIGNAL (Switch ON/OFF diagnostic item)



Harness layout



G

MA

EM

LC

EF & EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST


BF

HA


EL


1DX


Diagnostic Procedure 38 FUEL PUMP (Not self-diagnostic item)




Harness layout









G

MA

ĹĈ

EC

CL.

MT

AT

TF

PD

FA

RA

BR

ST


BF


HA


EL


IDX


Diagnostic Procedure 38 (Cont'd)












Trouble is not fixed.

nector and retest.


Check ECM pin terminals for damage


or the connection of ECM harness connector. Reconnect ECM harness con-

IACV-AIR REGULATOR (Not self-diagnostic item)




Harness layout







IACV-AAC VALVE (Not self-diagnostic item)



Harness layout





Gl

MA

LC

FE

C[

MT

AT

PD

FA

RA


BR

ST


BF


HA

POWER STEERING OIL PRESSURE SWITCH (Not self-diagnostic item)




Harness layout








NEUTRAL POSITION/INHIBITOR SWITCH (Not self-diagnostic item)



Harness layout







G|

MA

EM

L©

EF & EC

FE

CL

MT

AT

TF

FA

RA


BR

ST

BF

HA

Electrical Components Inspection ECM HARNESS CONNECTOR TERMINAL LAYOUT



Electrical Components Inspection (Cont'd)

ECM Inspection table

*Data	are	refer	ence	values.	

			*Data are reference values
TERMI- NAL NO.	ITEM	CONDITION	*DATA
1	Ignition signal	Engine is running. Idle speed	0.3 - 0.6V
'	igiruon signai	Engine is running. Engine speed is 2,000 rpm.	1.0 - 1.3V
•		Engine is running. Idle speed	Approximately 1.0V
2	Tachometer	Engine is running. Engine speed is 2,000 rpm.	Approximately 4V
3	Ignition check	Engine is running. Idle speed	9 - 12V
4	ECM power source	Ignition switch "ON". Engine is running. Idle speed	0 - 1V
4	(Self-shutoff)	Ignition switch "OFF". A few seconds after turning ignition switch "OFF" and thereafter.	BATTERY VOLTAGE (11 - 14V).
	500	Engine is running.	3.0 - 4.0V
8	EGR temperature sensor	Engine is running. (Racing) After warming up	0 - 1.0V
11	Air conditioner relay	Engine is running. Both A/C switch and blower switch are "ON".	0 - 1.0V
		Engine is running. A/C switch is "OFF".	BATTERY VOLTAGE (11 - 14V)
40	Power steering oil pressure	Engine is running. Steering wheel is being turned.	Approximately 0V
12	switch	Engine is running. Steering wheel is not being turned.	Approximately 5V

Electrical Components Inspection (Cont'd)

*Data are reference values.

			*Data are reference values.
TERMI- NAL NO.	ITEM	CONDITION	*DATA
16	Mass air flow sensor	Engine is running.	1.0 - 3.0V Output voltage varies with engine speed.
18	Engine coolant temperature sensor	Engine is running.	1.0 - 3.0V Output voltage varies with engine coolant temperature.
19	Heated oxygen sensor	Engine is running. After warming up sufficiently.	0 - Approximately 1.0V
20	Throttle position sensor	Ignition switch "ON"	0.4 - Approximately 4V Output voltage varies with the throttle valve opening angle.
22 30	Camshaft position sensor (Reference signal)	Engine is running. Do not run engine at high speed under no-load.	0.2 - 0.5V
27	Knock sensor	Engine is running. Idle speed	Approximately 2.5V
28	Throttle opening signal	Ignition switch "ON"	0.3 - Approximately 3V
31	Camshaft position sensor (Position signal)	Engine is running. Do not run engine at high speed under no-load.	2.0 - 3.0V
	Closed throttle position switch	Ignition switch "ON" Throttle valve: Idle position	Approximately 8 - 10V
33	(⊝ side)	Ignition switch "ON" Throttle valve: Any position except idle position	ov
34	Start signal	Cranking	8 - 12V
35	Neutral position switch & Inhibi-	Ignition switch "ON" Neutral position/Parking	ov
	tor switch	Ignition switch "ON" Except the above gear position	Approximately 5V

Electrical Components Inspection (Cont'd)


*Data are reference values.

			
TERMI- NAL NO.	ITEM	CONDITION	*DATA
36	Impition quitab	Ignition switch "OFF"	ov
30	Ignition switch	Ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)
37	Throttle position sensor power supply	Ignition switch "ON"	Approximately 5V
38 47	Power supply for ECM	Ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)
41	Air conditioner switch	Engine is running. Both air conditioner switch and blower switch are "ON".	oV
		Engine is running. Air conditioner switch is "OFF".	BATTERY VOLTAGE (11 - 14V)
	Closed throttle position switch	Ignition switch "ON" Throttle valve: Idle position	Approximately 9 - 10V
44	(⊕ side)	Ignition switch "ON" Throttle valve: Except idle position	BATTERY VOLTAGE (11 - 14V)
46	Power supply (Back-up)	Ignition switch "OFF"	BATTERY VOLTAGE (11 - 14V)
101	Injector No. 1		·
103	Injector No. 3		
105	Injector No. 5	Engine is running.	BATTERY VOLTAGE (11 - 14V)
110	Injector No. 2		
112	Injector No. 4		
	Injector No. 6		

Electrical Components Inspection (Cont'd)

*Data are reference values.

			*Data are reference values.
TERMI- NAL NO.	ITEM	ITEM CONDITION	
		Engine is running. (Warm-up condition) Idle speed (Jack up drive wheels and set shift lever to 1st position.)	0.7 - 0.9V
102	EGRC-solenoid valve	Engine is running. (Warm-up condition) Engine speed is 2,000 rpm. (Jack up drive wheels and set shift lever to 1st position.)	BATTERY VOLTAGE (11 - 14V)
		Engine is running. (Warm-up condition) Engine speed is above 3,100 rpm. (A/T model) Engine speed is above 2,600 rpm. (M/T model) (Jack up drive wheels and set shift lever to 1st position.)	0.8 - 0.9V
		Ignition switch "ON" For 5 seconds after turning ignition switch "ON"	0.7 - 0.9V
104 Fuel pump relay	Ignition switch "ON" 5 seconds after turning ignition switch "ON" and thereafter.	BATTERY VOLTAGE (11 - 14V)	
106	Heated oxygen sensor heater	Engine is running. Engine speed is below 4,200 rpm.	Approximately 0V
100	Treated oxygen sensor heater	Engine is running. Engine speed is above 4,200 rpm.	BATTERY VOLTAGE (11 - 14V)
		Engine is running. Idle speed	7 - 10V
113	113 IACV-AAC valve	Engine is running. Steering wheel is being turned. Air conditioner is operating. Rear defogger is "ON". Headlamps are in high position.	4 - 7V



Electrical Components Inspection (Cont'd) RESISTOR

- 1. Disconnect resistor harness connector.
- 2. Check resistance between terminals. Resistance: Approximately 2.2 Ω If NG, replace resistor.

G[

MA

EM

LC

HEATED OXYGEN SENSOR

Refer to "Diagnostic Procedure 30".

HEATED OXYGEN SENSOR HEATER

Check resistance between terminals (a) and (c) Resistance: 3 - 1,000 Ω If NG, replace heated oxygen sensor.

EF & EC

三司

CL

MT

AT

ŢŢ

PD


FA


RA

BR

ST

HA





FUEL PUMP

- 1. Disconnect fuel pump harness connector.
- 2. Check resistance between terminals d and f. Resistance: 0.2 5 Ω If NG, replace fuel pump.

Inspection and Adjustment


FUEL PUMP

Resistance	Ω	0.2 - 5	
	l.		

HEATED OXYGEN SENSOR HEATER

	7	
Resistance	Ω	3 - 1,000

ECCS Component Parts Location



G

MA

LC

EF & EC

FE

CL.

MT

AT

TF

PD

FA

RA

BR

ST

BF


HA

EL

]DX


ECCS Component Parts Location (Cont'd)

2WD M/T MODELS FOR CALIFORNIA




ECCS Component Parts Location (Cont'd)


EXCEPT 2WD M/T MODELS FOR CALIFORNIA



System Diagram (2WD M/T models for California)



System Diagram (Except 2WD M/T models for California)



GI

MA

EM

LC

EF & EC

FE

©iL

MT

AT

TF PD

FA

 $\mathbb{R}\mathbb{A}$

BR

ST


BE

AK


EL


System Chart

ECCS CONTROL SYSTEM



Circuit Diagram







Throttle Position Sensor (TPS) & Soft Closed Throttle Position (CTP) Switch

The throttle position sensor responds to the throttle position which, in turn, is determined by accelerator pedal movement. This sensor is a kind of potentiometer which transforms the throttle position into an output voltage, and transmits it to the ECM. The sensor also detects the opening and closing speed of the throttle valve and feeds this information as a voltage signal to the ECM too.

Closed throttle position is determined by the ECM. This positioning system is called the "soft closed throttle position switch" and controls engine operations such as fuel cut.






Fuel Injector


The fuel injector is a small, elaborate solenoid valve. As the ECM sends injection signals to the injector, the coil in the injector pulls the needle valve back and fuel is released into the intake manifold through the nozzle. The injected fuel is controlled by the ECM in terms of injection pulse duration.

Brass wire is used in the injector coil and thus the resistance is higher than a conventional injector.



EGR Control (EGRC)-Solenoid Valve

The EGR system is controlled only by the ECM. At both low- and high-speed engine speeds, the solenoid valve turns on and accordingly the EGR valve cuts the exhaust gas leading to the intake manifold.



Canister Control Solenoid Valve

The canister control solenoid valve responds to signals from the ECM. When the ECM sends an OFF signal, the vacuum signal (from the intake manifold to the canister purge cut valve) is cut. When the ECM sends an ON (ground) signal, the vacuum signal passes through the solenoid valve. The signal then reaches the canister purge cut valve.

SCV Control Solenoid Valve

The SCV control solenoid valve cuts the intake manifold vacuum signal for swirl control valve. It responds to the ON/OFF signal from the ECM. When the solenoid is off, the vacuum signal from the intake manifold is cut. When the ECM sends an ON signal the coil pulls the plunger and feeds the vacuum signal to the swirl control valve actuator.




EC


CL

MT

MA

EM





Canister Purge Control Valve

The canister purge control valve is operated by a step motor. This motor has four winding phases. It is actuated by the output pulse signal of the ECM which turns ON and OFF two windings each in sequence. Each time the valve opens or closes to change the flow rate, an ON pulse is issued. When no change in the flow rate is needed, the valve remains at a certain opening, hence no pulse signal is issued.



RA

PD

Fuel Temperature Sensor

The fuel temperature sensor is used to detect the fuel temperature inside the fuel tank. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the fuel temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.



ST


36

AK

]DX

Air Conditioner Cut Control

INPUT/OUTPUT SIGNAL LINE




SYSTEM DESCRIPTION

When accelerator pedal is fully depressed, air conditioner is turned off for a few seconds. This system improves acceleration when air conditioner is used.

Canister Control

INPUT/OUTPUT SIGNAL LINE



SYSTEM DESCRIPTION

The system precisely cuts and controls the vacuum applied to the canister purge cut valve to suit engine operating conditions.


This cut-and-control operation is accomplished through the ECM. When the ECM detects any of the following conditions, current does not flow through the solenoid valve.

This causes the port vacuum to be discharged into the atmosphere so that the canister purge cut valve remains closed.

- 1) Start switch "ON"
- 2) Closed throttle position
- 3) Low and high engine coolant temperature
- 4) During deceleration
- 5) Engine stopped
- 6) Low vehicle speed

Canister Purge Control

INPUT/OUTPUT SIGNAL LINE



SYSTEM DESCRIPTION

This system controls flow rate of fuel vapor from canister. The canister purge control valve changes the opening of the vapor by-pass passage to control the flow rate. This valve is actuated by a step motor built inside in the axial direction corresponding to the ECM output pulses. The opening of the valve is varied to allow for optimum engine control. When the engine operates, the flow rate is proportionally regulated as the air flow increases.

PD

TF

FA


RA

BR

ST

BF

HA



On-board Diagnostic System — Description MALFUNCTION INDICATOR LAMP (GREEK)

This vehicle has a malfunction indicator lamp on the instrument panel. This light comes ON under the following conditions:

- 1) When ignition switch is turned "ON" (for bulb check).
- 2) When systems related to emission performance malfunction in Diagnostic Test Mode I (with engine running).
- This malfunction indicator lamp always illuminates and is synchronous with red LED.
- Malfunction systems related to emission performance can be detected by on-board diagnostic system, and they are clarified as diagnostic trouble codes in Diagnostic Test Mode III.
- Malfunction indicator lamp will come "ON" only when malfunction is sensed.

The malfunction indicator lamp will turn off when normal operation is resumed. Diagnostic Test Mode III memory must be cleared as the contents remain stored.

Diagnostic trouble code No.	Malfunction
12	Mass air flow sensor circuit
13	Engine coolant temperature sensor circuit
14	Vehicle speed sensor circuit
31	ECM (ECCS control module)
32	EGR function
33	Oxygen sensor circuit
35	EGR temperature sensor circuit
42	Fuel temperature sensor circuit (2WD M/T models for California)
43	Throttle position sensor circuit
45	Injector leak

On-board Diagnostic System — Diagnostic Test Mode III (Self-diagnostic Results)

The ECM constantly monitors the function of these sensors and actuators, regardless of ignition key position. If a malfunction occurs, the information is stored in the ECM and can be retrieved from the memory by turning on the diagnostic test mode selector, located on the side of the ECM. When activated, the malfunction is indicated by flashing a red and a green LED (Light Emitting Diode), also located on the ECM. Since all the self-diagnostic results are stored in the ECM's memory even intermittent malfunctions can be diagnosed.

A malfunction is indicated by the number of both red and green flashing LEDs. First, the red LED flashes and the green flashes follow. The red LED corresponds to units of ten and the green LED corresponds to units of one. For example, when the red LED flashes once and the green LED flashes twice, this signifies the number "12", showing that the mass air flow sensor signal is malfunctioning. All problems are classified by diagnostic trouble code numbers in this way.

- When the engine fails to start, crank it two or more seconds before beginning on-board diagnostic system.
- Read out self-diagnostic results first and then erase the malfunction records which are stored in the ECM memory. If it is erased, the on-board diagnostic system function for intermittent malfunctions will be lost.

DISPLAY DIAGNOSTIC TROUBLE CODE TABLE

Diagnostic trouble code No.	Detected items
11	Camshaft position sensor circuit
12	Mass air flow sensor circuit
13	Engine coolant temperature sensor circuit
14	Vehicle speed sensor circuit
21	Ignition signal missing in primary coil
31	Engine control module (ECM)
32	EGR function
33	Oxygen sensor circuit
35	EGR temperature sensor circuit
41	Intake air temperature sensor circuit
42	Fuel temperature sensor circuit (2WD M/T models for California)
43	Throttle position sensor circuit
45	Injector leak
55	No malfunction in the above circuit

(G)

MA

EM2

EF &

SE

~ m

Ľ

MT

AT

TF

PD

FA

RA

88

ST

8F

....

KA El

On-board Diagnostic System — Diagnostic Test Mode III (Self-diagnostic Results) (Cont'd)


DECODING CHART

DISPLAY DIAGNOSTIC TROUBLE CODE


MALFUNCTIONING CIRCUIT OR PARTS

ECM SHOWS A
MALFUNCTION SIGNAL WHEN
THE FOLLOWING CONDITIONS
ARE DETECTED.


INTAKE AIR TEMPERATURE SENSOR









MAIN POWER SUPPLY AND GROUND CIRCUIT (Not self-diagnostic item)



Harness layout





MA

GI

EM

LC

EC

FE

CL.

MT

AT

TF

PD

FA

RA

BR


ST

BF


XX


EL


CAMSHAFT POSITION SENSOR (Diagnostic trouble code No. 11)



Harness layout










MEF459F


MASS AIR FLOW SENSOR (Diagnostic trouble code No. 12) (MALFUNCTION INDICATOR LAMP ITEM)



Harness layout







EF & EC-63

Gi

MA

EM

LC

EF & EC

FE

©[_

MT

AT

TF

PD

FA

RA

BR

ST


BF

HA


IDX


245

ENGINE COOLANT TEMPERATURE SENSOR (Diagnostic trouble code No. 13)




Harness layout






VEHICLE SPEED SENSOR (Diagnostic trouble code No. 14) (Switch ON/OFF diagnostic item) (MALFUNCTION INDICATOR LAMP ITEM)



Harness layout



Œ1

MA

L©

EF & EC

窕

CL

MT

AT

TF

PD

FA

RA

BR


ST


BF

HA

EL

Diagnostic Procedure 26 (Cont'd)





INSPECTION START

Check vehicle speed sensor and its circuit. (Refer to EL section.)

CHECK INPUT SIGNAL CIRCUIT.

- 1) Turn ignition switch "OFF".
- 2) Disconnect ECM harness connector.
- 3) Disconnect combination meter harness connecto (15)
- Check harness continuity between ECM terminal 32 and terminal g.
 Continuity should exist.

Check the following.

NG

- Harness connectors
- Harness continuity between ECM and combination meter
 If NG, repair harness or connectors.


Disconnect and reconnect harness connectors in the circuit. Then retest.

OK

Trouble is not fixed.

Check ECM pin terminals for damage or the connection of ECM harness connector. Reconnect ECM harness connector and retest.

Perform FINAL CHECK by the following procedure after repair is completed.



G

MA

LC

Æ

CL

MT

AT


TF

PD


EF & EC


Diagnostic Procedure 27


IGNITION SIGNAL (Diagnostic trouble code No. 21)



Harness layout







EF & EC-67













HA


EL



Diagnostic Procedure 27 (Cont'd)



Perform FINAL CHECK by the following procedure after repair is completed.




HA


EL


MT


EGR FUNCTION (Diagnostic trouble code No. 32) (MALFUNCTION INDICATOR LAMP ITEM)




Harness layout







Diagnostic Procedure 29 (Cont'd)



Diagnostic Procedure 29 (Cont'd)

ROAD TEST Test conditions Drive vehicle under the following conditions with suitable gear position. (1) Engine speed: A/T models: $2,200 \pm 200 \text{ rpm}$ M/T models: 2,500 ± 500 rpm (2) Intake manifold vacuum: 2WD models with A/T: -40.0 ± 4.0 kPa $(-300 \pm 30 \text{ mmHg}, -11.81 \pm 1.18 \text{ inHg})$ 2WD models with M/T: -46.7 ± 6.7 kPa $(-350 \pm 50 \text{ mmHg}, -13.78 \pm 1.97 \text{ inHg})$ 4WD models: -48.32 ± 5.00 kPa $(-362.5 \pm 37.5 \text{ mmHg}, -14.272 \pm 1.476 \text{ inHg})$ **Driving mode** A: Test (\mathbf{B}) condition Vehicle (A) : Total of driving (5) 20 seconds or more 4

Until red LED goes off. Start engine and warm it up sufficiently.

Engine

running Ignition

switch:


OFF


- 2 Turn off ignition switch and keep it off until red LED goes off.
- ③ Start engine and make sure that air conditioning switch and rear defogger are turned "OFF" during test drive.
- 4 Keep engine running for at least 4 minutes.
- 5 Shift to suitable gear position and drive in "Test condition" for a total 20 seconds or more.

Note: If engine stalls or ignition switch is turned off within step 3, return to step 2.


SEF560NA


FINAL CHECK






Perform FINAL CHECK by the following procedure after repair is completed.








OXYGEN SENSOR (Diagnostic trouble code No. 33) (MALFUNCTION INDICATOR LAMP ITEM)



Harness layout







G]

MA

LC

EF & EC

=[=

CL

MT

AT

TF

PD

FA

RA

BR

ST

BF

HA


ĒL

[DX


255


EF & EC-73

EGR TEMPERATURE SENSOR (Diagnostic trouble code No. 35) (MALFUNCTION INDICATOR LAMP ITEM)




Harness layout







INTAKE AIR TEMPERATURE SENSOR (Diagnostic trouble code No. 41)



Harness layout





em lc

G

MA

EF & EC

FE

CL

AT

MT

TF

PD

FA

RA

BR

ST


BF

MA


ΞĹ


IDX


THROTTLE POSITION SENSOR (Diagnostic trouble code No. 43) (MALFUNCTION INDICATOR LAMP ITEM)




Harness layout








START SIGNAL (Switch ON/OFF diagnostic item)



Harness layout



EF & EC

G]

MA

FE

©L

AT

MT

ŢF

PD

FA

RA

<u>8</u>R


\$T

BĒ


HA


]DX

PAIR VALVE SYSTEM (Not self-diagnostic item)





Harness layout








Diagnostic Procedure 36 (Cont'd)



















nector. Reconnect ECM harness con-


nector and retest.

INJECTOR (Not self-diagnostic item)



Harness layout





EM

MA

Gi

LC

EF & EC

FE

<u>CL</u>

MT

AT

TF

PD

FA


RA

BR

ST

BF


MA




nector and retest.


Check ECM pin terminals for damage or the connection of ECM harness connector. Reconnect ECM harness con-


FUEL PUMP (Not self-diagnostic item)



Harness layout







MA

G]

EM

LC

EF &

FE

CL.

MT

AT

TF

PD

FA

RA

BR

ST


8F

HA

EL


IDX


SCV CONTROL (Not self-diagnostic item)



Harness layout


Fuel filter __ connector







SCV control solenoid valve harness


AEC658





Diagnostic Procedure 39 (Cont'd)
















]DX

(A)


Diagnostic Procedure 39 (Cont'd)




IACV-AAC VALVE (Not self-diagnostic item)



Harness layout





MA

GI

EM

EF &

LC

FE

©L

MT

AT

TF

PD

FA

RA

BR


ST

BF


HA


EL

POWER STEERING OIL PRESSURE SWITCH (Not self-diagnostic item)



Harness layout





 \mathbb{G}

MA

LC

EF &

EC

FE

CL.

MT

AT

TF

PD


FA

RA


BR


Diagnostic Procedure 42


NEUTRAL POSITION/INHIBITOR SWITCH (Not self-diagnostic item)



Harness layout








ST BF

HA


EL


IDX

Diagnostic Procedure 43 TORQUE CONVERTER CLUTCH SOLENOID VALVE (Not self-diagnostic item)



Harness layout





G

MA

EM

LC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST


BF

HA


EF & EC


Diagnostic Procedure 44

FUEL TEMPERATURE SENSOR (Diagnostic trouble code No. 42)



Harness layout






IDX

Diagnostic Procedure 44 (Cont'd) Α INSPECTION START Α NG CHECK POWER SUPPLY. Check the following. 1) Disconnect fuel temperature sensor Harness connectors harness connector. (304M) , (17C) 2) Turn ignition switch "ON". Harness continuity Check voltage between terminal (b) between ECM and fuel temperature sensor. and ground. Voltage: Approximately 5V If NG, repair harness or MEF409G connectors. OK В В NG CHECK GROUND CIRCUIT. Check the following. 1) Turn ignition switch "OFF". Harness connectors 2) Check harness continuity between (304M) , (17C) terminal d and engine ground. Harness continuity Continuity should exist. between fuel temperature sensor and body OK around IF NG, repair harness or connectors. MEF410G NG CHECK COMPONENT Replace fuel temperature (Fuel temperature sensor). sensor. Refer to "Electrical Components Inspection", EF & EC-96 in this Supplement. OK Disconnect and reconnect harness connectors in the circuit. Then retest. Trouble is not fixed.

Check ECM pin terminals for damage or the connection of ECM harness connector. Reconnect ECM harness con-

nector and retest.

Perform FINAL CHECK by the following procedure after repair is completed.



Gi

MA

L©

FE

©[_

MT

AT

TF

PD

FA

 $\mathbb{R}\mathbb{A}$

BR

ST


86

HA


EF & EC


Diagnostic Procedure 45

CLOSED THROTTLE POSITION SWITCH (Not self-diagnostic item)



Harness layout







275

IDX


Diagnostic Procedure 45 (Cont'd)




CANISTER CONTROL SOLENOID VALVE (Not self-diagnostic item)



Harness layout





EF & EC

GI:

MA

EM

LC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST


BF


HA


EL


1DX


Diagnostic Procedure 46 (Cont'd)














В OK CHECK CONTROL FUNCTION. 1) Check voltage between ECM terminal (114) and ground under the following conditions. Voltage: At idle Approximately 0V

> Engine speed is about 2,000 rpm (in "1" position)

Battery voltage

NG

(in "1" position)

Vacuum should exist.

clogging, cracks and proper connection.

С

D CHECK POWER SUPPLY. 1) Stop engine. 2) Disconnect canister control solenoid valve harness connector. 3) Turn ignition switch "ON".

NG

4) Check voltage between terminal (a) and ground. Voltage: Battery voltage

Lok

NG

Check the following.


Check vacuum hose for

• 10A fuse

 Harness continuity between canister control solenoid valve and fuse

If NG, repair harness or connectors.

Diagnostic Procedure 46 (Cont'd)



279

PD

FA

RA


BR

ST


36


HA

CANISTER PURGE CONTROL VALVE (Not self-diagnostic item)



Harness layout





@1

MA

EM

LC

Æ

CL

MT


AT


TF


PD


FA

Diagnostic Procedure 47 (Cont'd)









(e) and ground. connectors. Voltage: Battery voltage OK NG CHECK OUTPUT SIGNAL CIRCUIT. 1) Turn ignition switch "OFF". nectors. 2) Disconnect ECM harness connector. 3) Check harness continuity between ECM terminal (7) and terminal (c), ECM terminal (9) and terminal (1), ECM terminal (10) and terminal (a),

2) Disconnect canister purge control

Check voltage between terminals (b),

ECM terminal (4) and terminal (d).

(A)

Continuity should exist.

valve harness connector.

Turn ignition switch "ON".

С

Repair harness or con-

between canister purge

control valve and

If NG, repair harness or

ECCS relay

RA

BR

ST


BF

HA

EL

IDX

Diagnostic Procedure 47 (Cont'd)



Electrical Components Inspection ECM HARNESS CONNECTOR TERMINAL LAYOUT

16 17 18 19 20 21 22 0 23 24 25 26 27 × 29 30 40 41 42 43 8 9 10 11 12 13 14 LC MEF420G

G

MA

EM

EF & EC

FE

CL

MT

AT

TF

PD

FA

 $\mathbb{R}\mathbb{A}$

BR

ST

BF

HA

ENGINE AND EMISSION CONTROL OVERALL SYSTEM

Electrical Components Inspection (Cont'd)

ECM inspection table

*Data are reference values.

		<u> </u>	*Data are reference values.
TERMI- NAL NO.	ITEM	CONDITION	*DATA
1	Ignition signal	Engine is running. Idle speed	0.3 - 0.6V
'	ingritteri digital	Engine is running. Engine speed is 2,000 rpm.	1.2 - 1.5V
		Engine is running. - Idle speed	Approximately 1.0V
. 2	Tachometer	Engine is running. Engine speed is 2,000 rpm.	Approximately 2.7V
3	Ignition check	Engine is running. Idle speed	9 - 12V
4	ECCS relay (Main relay)	Ignition switch "OFF" Within a few seconds after turning ignition switch "OFF"	0 - 1V
	(Main relay)	Ignition switch "OFF" A few seconds after turning ignition switch "OFF" and thereafter.	BATTERY VOLTAGE (11 - 14V)
7 9	Conjeter pure control volve	Engine is running. Idle speed	Approximately 0 - 0.4V
10 14	- Canister purge control valve	Engine is running. Idle speed	BATTERY VOLTAGE (11 - 14V)
	FOR towns and an angles	Engine is running.	3.0 - 4.0V
8	EGR temperature sensor	Engine is running. (Racing) After warming up	0 - 3.0V
11	Air conditioner relay	Engine is running. Both A/C switch and blower switch are "ON".	0 - 1.0V
		Engine is running. A/C switch is "OFF".	ov

ENGINE AND EMISSION CONTROL OVERALL SYSTEM

Electrical Components Inspection (Cont'd)

			*Data are reference values.	
TERMI- NAL NO.	ITEM	CONDITION	*DATA	GI
12	SCV control solenoid valve	Engine is running. Idle speed Engine is running. Engine speed is 3,600 rpm.	0 - 1.0V BATTERY VOLTAGE (11 - 14V)	M.
16	Mass air flow sensor	Engine is running.	1.0 - 3.0V Output voltage varies with engine speed.	L
18	Engine coolant temperature sensor	Engine is running.	1.0 - 3.0V Output voltage varies with engine coolant temperature,	E
19	Oxygen sensor	Engine is running. After warming up sufficiently.	0 - Approximately 1.0V	FE
20	Throttle position sensor	Ignition switch "ON" After warming up sufficiently.	0.5 - Approximately 4V Output voltage varies with the throttle valve opening angle.	Gl
22 30	Camshaft position sensor (Reference signal)	Engine is running. Do not run engine at high speed under no-load.	0.3 - 0.4V	M At
26		Ignition switch "ON" Intake air temperature is 20°C (68°F).	Approximately 2.4V	77
26	Intake air temperature sensor	Ignition switch "ON" Intake air temperature is 80°C (176°F).	Approximately 0.3V	P[F/
27	Fuel temperature sensor	Ignition switch "ON"	0 - 5V Output voltage varies with fuel temperature.	R
31 40	Camshaft position sensor (Position signal)	Engine is running. Do not run engine at high speed under no-load.	2.0 - 3.0V	8
33	Closed throttle position switch	Ignition switch "ON" Accelerator pedal is fully released after warming-up. Ignition switch "ON" Accelerator pedal is depressed.	BATTERY VOLTAGE (11 - 14V) Approximately 0V	ST BF
34	Start signal	Cranking	8 - 12V	HÆ
35	Neutral position switch &	Ignition switch "ON" Neutral position/Parking	ov	
55	Inhibitor switch	Ignition switch "ON" Except the above gear position	6 - 7V	ID)

ENGINE AND EMISSION CONTROL OVERALL SYSTEM

Electrical Components Inspection (Cont'd)

*Data are reference values.

	· · · · · · · · · · · · · · · · · · ·		*Data are reference values.
TERMI- NAL NO.	ITEM	CONDITION	*DATA
		Ignition switch "OFF"	ov
36	Ignition switch	Ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)
37	Throttle position sensor power supply	Ignition switch "ON"	Approximately 5V
38 47	Power supply for ECM	Ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)
41	Air conditioner switch	Engine is running. Both air conditioner switch and blower switch are "ON".	ov
	All conditioner switch	Engine is running. Air conditioner switch is "OFF".	BATTERY VOLTAGE (11 - 14V)
		Engine is running. Steering wheel is being turned.	0.1 - 0.3V
43	Power steering oil pressure switch	Engine is running. Steering wheel is not being turned.	Approximately 5V
46	Power supply (Back-up)	Ignition switch "OFF"	BATTERY VOLTAGE (11 - 14V)
101	Injector No. 1	·	
103	Injector No. 3	Engine is gamping	BATTERY VOLTAGE
110	Injector No. 2	Engine is running.	(11 - 14V)
112	Injector No. 4		
		Engine is running. Engine is cold. Engine coolant temperature is below 60°C (140°F).	0.7 - 0.9V
105	EGRC-solenoid valve	Engine is running. (Racing) After warming up Engine coolant temperature is between 60°C (140°F) and 105°C (221°F).	BATTERY VOLTAGE (11 - 14V)
		Engine is running. Idle speed	Approximately 0V
102	PAIRC-solenoid valve	Engine is running. Except at idle Do not run engine at high speed under no-load.	BATTERY VOLTAGE (11 - 14V)



Electrical Components Inspection (Cont'd)

*Data are reference values.


TERMI- NAL NO.	ITEM	CONDITION	*DATA	(
104	Fuel pump relay	Ignition switch "ON" For 5 seconds after turning ignition switch "ON" Engine is running. Ignition switch "ON" Within 5 seconds after turning	0.7 - 0.9V BATTERY VOLTAGE (11 - 14V)	
		ignition switch "ON" Engine is running.	(11 - 140)	
		Idle speed	7 - 10V	
113	IACV-AAC valve	Engine is running. — Steering wheel is being turned. — Air conditioner is operating. — Rear defogger is "ON". Headlamps are in high position.	4 - 7V	(
		Engine is running.	BATTERY VOLTAGE (11-14V)	[
114	4 Canister control solenoid valve	Engine is running. Engine speed is about 2,000 rpm in "1" position after warming up.	Approximately 0V	
	Torque converter el tel colonid	Engine is running. Idle speed Engine coolant temperature is below 40°C (104°F).	Approximately 0V	[
115	Torque converter clutch solenoid valve	Engine is running. After warming up Engine coolant temperature is above 40°C (104°F). Engine speed is 2,000 rpm	BATTERY VOLTAGE (11 - 14V)	[

IDX

ST

BF


KA



Electrical Components Inspection (Cont'd) EGRC-SOLENOID VALVE, PAIRC-SOLENOID VALVE AND SCV CONTROL SOLENOID VALVE, CANISTER CONTROL SOLENOID VALVE


Check air passages continuity.

Condition	Air passage continuity between (A) and (B)	Air passage continuity between (A) and (C)
12V direct current supply between terminals 1 and 2	Yes	No
No supply	No	Yes



CANISTER PURGE CONTROL VALVE (2WD M/T models for California)

Turn switch "ON" and "OFF" and ensure the canister purge control valve makes an operating sound. If NG, replace the canister purge control valve.





FUEL TEMPERATURE SENSOR (2WD M/T models for California)

Check resistance as shown in the figure.

Resistance k Ω
2.3 - 2.7
0.79 - 0.90

If NG, replace fuel temperature sensor.





Electrical Components Inspection (Cont'd) THROTTLE POSITION SENSOR

Make sure that resistance between terminals (e) and (f) changes when opening throttle valve manually.

Resistance should change.


If NG, replace throttle position sensor.

Adjustment

If throttle position sensor is replaced or removed, it is necessary to install it in the proper position.


Except 2WD M/T models for California.

- Install throttle position sensor body in throttle body. Do not tighten bolts.
- Connect throttle position sensor harness connector.
- 3. Start engine and warm it up sufficiently.
- 4. Measure output voltage of throttle position sensor using voltmeter.
- Adjust by rotating throttle position sensor body so that output voltage is 0.4 to 0.6V.
- Tighten mounting bolts.
- 7. Disconnect throttle position sensor harness connector for a few seconds and then reconnect it.



2WD M/T models for California

- Install throttle position sensor body in throttle body. Do not tighten bolts.
- Connect closed throttle position switch harness connector.Do not connect throttle position sensor connector.
- Start engine and warm it up sufficiently.
- 4. Turn diagnostic test mode to mode IV.
- 5. Depress accelerator pedal and release slowly.
- Check engine rpm when red LED on ECM is turned on.
 Closed throttle position switch ON-OFF: 1,000±150 rpm
- 7. If it is out of specification, adjust switch by turning throttle position sensor body.
- Turn engine off and remove air duct.
- 9. Tighten securing bolts, install air duct and connect throttle position sensor connector.
- 10. Recheck engine ON-OFF rpm.



CLOSED THROTTLE POSITION (2WD M/T models for California)

Check continuity between terminals (B) and (C) while moving throttle valve.

Yes
No



<u>G</u>[

MA

EM

LC



MT

FE

TF

AT

PD

FA

RA

BR


ST

BF

HA




IDX




Electrical Components Inspection (Cont'd) FUEL PUMP

Check resistance between terminals d and f. Resistance: 0.2 - 5.0 Ω



RESISTOR

- 1. Disconnect resistor harness connector.
- 2. Check resistance between terminals. Resistance: Approximately 2.2k Ω If NG, replace resistor.



Injector Removal and Installation

- 1. Release fuel pressure to zero.
- 2. Remove or disconnect the following:
- EGRC-BPT valve
- Fuel tube securing bolts
- 3. Remove injectors with fuel tube assembly.
- 4. Remove injector from fuel tube.

Push out injector from fuel tube assembly. Do not extract injector by pinching electric connector.

5. Install injector to fuel tube after cleaning exterior of injector.

Use new O-rings and insulators.


Lubricate O-rings with a smear of silicone oil.

CALITION

After properly connecting injectors to fuel tube, check connection for fuel leakage.

6. Assemble injectors with fuel pipe to intake manifold.

Description



The evaporative emission system is used to reduce hydrocarbons emitted into the atmosphere from the fuel system. This reduction of hydrocarbons is accomplished by activated charcoals in the canister.


The fuel vapor in the sealed fuel tank is led into the canister which contains activated carbon. The vapor is stored there when the engine is not operating.

The vapor in the canister is purged by the air through the purge line to the intake manifold when the engine is operating.

Canister purge control valve is controlled by engine control module. When the engine operates, the flow rate of vapor is proportionally regulated as the air flow increases.

Canister purge cut valve shuts off the vapor purge line during decelerating and idling. Under normal operating conditions the valve is usually open.

Evaporation shut valve shuts off the vapor charge line when fuel is being supplied to the fuel tank.



Inspection

CANISTER

Check canister as follows:

- Pinch the breezer hose.
- 2. Blow air in port (A) and ensure free flow out of port (B).

G!

MA

EM

LC

EF & FC

GL.

MT

AT

RA

BR


T


EA


F://

2.

SEF284P







Inspection (Cont'd) **CANISTER PURGE CUT VALVE**

Check canister purge cut valve as follows:

- Blow air in port (A) and ensure that there is no leakage.
- Apply vacuum to port (A). [Approximately-13.3 to -20.0 kPa (-100 to -150 mmHg, -3.94 to -5.91 inHg)]
- Blow air in port © and ensure free flow out of port (B).

VACUUM CONTROL VALVE


Check vacuum control valve as follows:

- Apply vacuum to port (A) and ensure that there is no leak-
- Apply vacuum to port (B) and ensure that there is leakage.
- 3. Blow air in port (B) and ensure free flow out of port (A).

FUEL TANK VACUUM RELIEF VALVE

- Wipe clean valve housing.
- Suck air through the cap. A slight resistance accompanied by valve clicks indicates that valve A is in good mechanical condition. Note also that, by further sucking air, the resistance should disappear with valve clicks.
- 3. Blow air on fuel tank side and ensure that continuity of air passage exists through valve B.
- 4. If valve is clogged or if no resistance is felt, replace cap as an assembly.

Description




The evaporative emission system is used to reduce hydrocarbons emitted to the atmosphere from the fuel system. This reduction of hydrocarbons is accomplished by activated charcoals in the canister.

The fuel vapor from the sealed fuel tank is led into the canister which contains activated carbon and the vapor is stored there when the engine is not running.

The canister retains the fuel vapor until the canister is purged by the air drawn through the bottom of the canister to the intake manifold when the engine is running. When the engine runs at idle, the purge control valve is closed.

Only a small amount of stored vapor flows into the intake manifold through the constant purge orifice. As the engine speed increases, and the throttle vacuum increases, the purge control valve opens and the vapor is sucked into the intake manifold through both the main purge orifice and the constant purge orifice.



Inspection

CANISTER

Check canister as follows:

- Blow air in port (A) and ensure that there is no leakage.
- 2.
- Apply vacuum to port (A).
- Cover port (D) with hand.
- Blow air in port © and ensure free flow out of port B.

GI

MA

EM

LC.

EC

FE

CL

MT

AT

RA


BR

BF

HA

EL

1DX



Inspection (Cont'd)


FUEL CHECK VALVE (With rollover valve)

Check valve operation

- Blow air through connector on fuel tank side.
 A considerable resistance should be felt and a portion of air flow should be directed toward the canister side.
- Blow air through connector on canister side.Air flow should be smoothly directed toward fuel tank side.
- 3. If fuel check valve is suspected of not properly functioning in steps 1 and 2 above, replace it.

Rollover valve operation

Ensure that continuity of air passage does not exist when the installed rollover valve is tilted to 90° or 180°.



FUEL TANK VACUUM RELIEF VALVE

- 1. Wipe clean valve housing.
- Suck air through the cap. A slight resistance accompanied by valve clicks indicates that valve A is in good mechanical condition. Note also that, by further sucking air, the resistance should disappear with valve clicks.
- 3. Blow air on fuel tank side and ensure that continuity of air passage exists through valve B.
- If valve is clogged or if no resistance is felt, replace cap as an assembly.