

SECTION **MT**

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX









CONTENTS

PREPARATION	2	DISASSEMBLY	12
Special Service Tools.....	2	REPAIR FOR COMPONENT PARTS	15
Commercial Service Tools.....	4	Input Shaft and Gears.....	15
ON-VEHICLE SERVICE/REMOVAL AND		Mainshaft and Gears.....	20
INSTALLATION	5	Final Drive.....	24
Replacing Oil Seal.....	5	Shift Control Components.....	30
Check of Position Switch.....	6	Case Components.....	30
Viscous Coupling Check.....	6	ADJUSTMENT	31
Removal.....	6	Input Shaft End Play and Differential Side	
Installation.....	7	Bearing Preload.....	31
TRANSAXLE GEAR CONTROL	8	Mainshaft Bearing Preload.....	32
MAJOR OVERHAUL	9	ASSEMBLY	35
Case Components.....	9	SERVICE DATA AND SPECIFICATIONS (SDS)	39
Gear Components.....	10	General Specifications.....	39
Shift Control Components.....	11	Inspection and Adjustment.....	39

PREPARATION










Special Service Tools

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description	
KV38105210 (—) Preload adapter		Measuring turning torque of final drive assembly Measuring total turning torque NT075
KV32101000 (J25689-A) Pin punch		Removing and installing retaining pin a: 4 mm (0.16 in) dia. NT410
ST22730000 (J25681) Puller		Removing mainshaft front and rear bearing inner race a: 82 mm (3.23 in) dia. b: 30 mm (1.18 in) dia. NT411
ST30031000 (J22912-01) Puller		Removing input shaft front and rear bearing Removing 4th & 5th main gear a: 90 mm (3.54 in) dia. b: 50 mm (1.97 in) dia. NT411
ST30021000 (J22912-01) Puller		Removing 5th synchronizer Removing 3rd & 4th synchronizer Removing 2nd & 3rd main gear a: 110 mm (4.33 in) dia. b: 68 mm (2.68 in) dia. NT411
ST3306S001 (—) Differential side bearing puller set ① ST33051001 (—) Puller ② ST33061000 (J8107-2) Adapter		Removing differential side bearing inner race a: 38 mm (1.50 in) dia. b: 28.5 mm (1.122 in) dia. c: 130 mm (5.12 in) d: 135 mm (5.31 in) e: 100 mm (3.94 in) NT413
ST33290001 (J34286) Puller		Removing differential oil seal Removing mainshaft rear bearing outer race Removing differential side bearing outer race a: 250 mm (9.84 in) b: 160 mm (6.30 in) NT414
ST33400001 (J26082) Drift		Installing differential oil seal (50A and 50V right side) a: 60 mm (2.36 in) dia. b: 47 mm (1.85 in) dia. NT086



PREPARATION

Special Service Tools (Cont'd)





Tool number (Kent-Moore No.) Tool name	Description	GI
ST3060000 (J25863-01) Drift	 <p>NT065</p> <p>Installing input shaft front bearing</p> <p>a: 36 mm (1.42 in) dia. b: 31 mm (1.22 in) dia.</p>	MA
ST22452000 () Drift	 <p>NT065</p> <p>Installing 3rd, 4th and 5th main gear</p> <p>a: 45 mm (1.77 in) dia. b: 36 mm (1.42 in) dia.</p>	EM
ST30621000 (J25742-5) Drift	 <p>NT073</p> <p>Installing mainshaft rear bearing outer race (Use with ST30611000.)</p> <p>a: 79 mm (3.11 in) dia. b: 59 mm (2.32 in) dia.</p>	EC
ST30611000 (J25742-1)	 <p>NT419</p> <p>(Use with ST30621000.)</p> <p>a: 15 mm (0.59 in) b: 335 mm (13.19 in) c: 25 mm (0.98 in) dia. d: M12 x 1.5P</p>	CL
KV38100300 () Drift	 <p>NT085</p> <p>Installing differential side bearing</p> <p>a: 54 mm (2.13 in) dia. b: 46 mm (1.81 in) dia. c: 32 mm (1.26 in) dia.</p>	AT
ST30613000 () Drift	 <p>NT073</p> <p>Installing differential side bearing</p> <p>a: 72 mm (2.83 in) dia. b: 48 mm (1.89 in) dia.</p>	RA
(J34290) Shim selecting tool set	 <p>NT080</p> <p>Selecting differential side bearing adjusting shim</p>	ST
(J34305) Snap ring remover and installer	 <p>NT081</p> <p>Removing and installing stopper ring of shift fork</p>	RS
(J25407-2)	 <p>NT082</p> <p>Measuring reverse baulk ring wear</p>	BT


PREPARATION

Special Service Tools (Cont'd)

Tool number (Kent-Moore No.) Tool name	Description	
KV38106500 (J34284) Preload adapter	 NT087	Measuring turning torque of final drive assembly
(J34291) Shim setting gauge set	 NT101	Selecting side gear thrust washer

Commercial Service Tools


Tool name	Description	
Drift	 NT065	Installing differential side bearing inner race a: 45 mm (1.77 in) dia. b: 41 mm (1.61 in) dia.
Drift	 NT065	Installing differential side bearing outer race a: 69 mm (2.72 in) dia. b: 64 mm (2.52 in) dia.
Drift	 NT065	Installing striking rod oil seal a: 38 mm (1.50 in) dia. b: 20 mm (0.79 in) dia.
Drift	 NT065	Installing differential oil seal (50V left side) a: 92 mm (3.62 in) dia. b: 72 mm (2.83 in) dia.




Replacing Oil Seal

DIFFERENTIAL OIL SEAL

1. Drain gear oil from transaxle.
2. Remove drive shafts — Refer to FA section.
3. Remove differential oil seal.




4. Install differential oil seal.
 - **Apply multi-purpose grease to seal lip of oil seal before installing.**
5. Install drive shafts — Refer to FA section.




STRIKING ROD OIL SEAL

1. Remove transaxle control rod from yoke.
2. Remove retaining pin of yoke.
 - **Be careful not to damage boot.**



3. Remove striking rod oil seal.



4. Install striking rod oil seal.
 - **Apply multi-purpose grease to seal lip of oil seal before installing.**

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST


RS

BT

HA

EL

IDX




Check of Position Switch

REVERSE LAMP SWITCH AND NEUTRAL POSITION SWITCH

- Check continuity.

Gear position	Continuity
Reverse	2 - 4
Neutral	1 - 3
Except reverse and neutral	No



Viscous Coupling Check


1. Apply parking brake firmly and place shift lever in the neutral position.
2. Jack up front wheels.
3. Rotate one front wheel and check turning direction of the other front wheel.

Turning direction of the two wheels is opposite:

The viscous coupling is not functioning normally.

Turning direction of the two wheels is the same:

If differential side gear and pinion mate gear thrust washers are OK, viscous coupling is functioning normally.




Removal

CAUTION:




When removing the transaxle assembly, first remove the crankshaft position sensor (POS) from the assembly.

Be careful not to damage sensor edge.

1. Remove battery and its bracket.
2. Remove air cleaner box with mass air flow sensor.
3. Remove clutch operating cylinder from transaxle.
4. Remove clutch hose clamp.
5. Disconnect speedometer pinion, position switch and ground harness connectors.
6. Remove starter motor from transaxle.
7. Remove crankshaft position sensor (POS) from transaxle front side.



ON-VEHICLE SERVICE/REMOVAL AND INSTALLATION



Removal (Cont'd)

8. Remove shift control rod and support rod bracket from transaxle.
9. Drain gear oil from transaxle.
10. Draw out drive shafts from transaxle. — Refer to FA section.
11. Support engine of transaxle by placing a jack under oil pan.

CAUTION:

Do not place jack under oil pan drain plug.

12. Remove bolts securing center member.
13. Remove LH mounts.
14. Remove bolts securing transaxle.
15. Lower transaxle while supporting it with a jack.

Installation

- Tighten all transaxle bolts.


Bolt No.	Tightening torque N-m (kg-m, ft-lb)	"ℓ" mm (in)
①	70 - 79 (7.1 - 8.1, 51 - 59)	52 (2.05)
②	70 - 79 (7.1 - 8.1, 51 - 59)	65 (2.56)
③	70 - 79 (7.1 - 8.1, 51 - 59)	124 (4.88)
④	35.1 - 47.1 (3.58 - 4.80, 25.89 - 34.74)	40 (1.57)
⑤	35.1 - 47.1 (3.58 - 4.80, 25.89 - 34.74)	40 (1.57)

- ③ with starter
- ④ with support rod bracket

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TRANSAXLE GEAR CONTROL

SEC. 341




SMT720CA

- | | | |
|------------------------|-----------------|-----------------------------|
| ① Control lever knob | ⑦ Upper bearing | ⑬ Plate bolt |
| ② Boot retainer | ⑧ Lower bearing | ⑭ Transaxle hole cover |
| ③ Boot | ⑨ Bushing | ⑮ Return spring |
| ④ Control lever socket | ⑩ O-ring | ⑯ Support rod |
| ⑤ Bearing seat | ⑪ Collar | ⑰ Shift control rod |
| ⑥ Control lever | ⑫ Dust boot | ⑱ Shift support rod bracket |

MAJOR OVERHAUL

Case Components

SEC. 321



SMT744C

- ① Speedometer pinion
- ② Differential oil seal
- ③ Drain plug
- ④ Boot
- ⑤ Striking rod oil seal
- ⑥ Magnet
- ⑦ Clutch housing

- ⑧ Input shaft oil seal
- ⑨ Oil channel (Mainshaft)
- ⑩ Oil pocket
- ⑪ Box breather
- ⑫ Oil gutter
- ⑬ Oil channel (Input shaft)
- ⑭ Transmission case

- ⑮ Filler plug
- ⑯ O-ring
- ⑰ Movable plate assembly
- ⑱ Position switch
- ⑲ Breather hose
- ⑳ Breather pipe




GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX


MAJOR OVERHAUL

Gear Components

SEC. 322

Apply gear oil to gears, shifts, synchronizers and bearings when assembling.

-  : N·m (kg-m, in-lb)
-  : N·m (kg-m, ft-lb)
- ★ : Select proper thickness.
-  : Apply recommended sealant (Nissan genuine part: KP610-00250) or equivalent.




SMT745C

- | | | |
|--------------------------------------|---------------------------------------|--|
| ① Input shaft | ⑱ 5th baulk ring | ⑳ Differential side bearing |
| ② Input shaft front bearing | ⑳ 1st baulk ring | ㉑ Speedometer drive gear |
| ③ 3rd input gear | ㉑ 2nd inner baulk ring | ㉒ Differential case |
| ④ 3rd & 4th synchronizer hub | ㉒ Snap ring | ㉓ Viscous coupling |
| ⑤ Snap ring | ㉓ Mainshaft bearing spacer | ㉔ Final gear |
| ⑥ Coupling sleeve | ㉔ Mainshaft front bearing | ㉕ Reverse idler gear |
| ⑦ 4th baulk ring | ㉕ Mainshaft | ㉖ Pinion mate gear thrust washer |
| ⑧ 4th input gear | ㉖ 1st main gear | ㉗ Pinion mate gear |
| ⑨ Reverse baulk ring | ㉗ 1st & 2nd synchronizer hub | ㉘ Pinion mate shaft |
| ⑩ Reverse synchronizer cone | ㉘ Reverse main gear (Coupling sleeve) | ㉙ Side gear |
| ⑪ 5th synchronizer hub | ㉙ 2nd outer baulk ring | ㉚ Side gear thrust washer |
| ⑫ Input shaft rear bearing | ㉚ 2nd gear synchronizer cone | ㉛ Differential side bearing |
| ⑬ Input shaft bearing adjusting shim | ㉛ 2nd main gear | ㉜ Differential side bearing adjusting shim |
| ⑭ 3rd baulk ring | ㉜ 3rd main gear | ㉝ Bushing |
| ⑮ Insert spring | ㉝ 4th main gear | ㉞ Reverse idler shaft |
| ⑯ 4th input gear thrust washer | ㉞ 5th main gear | ㉟ Retaining pin |
| ⑰ Thrust washer ring | ㉟ Mainshaft rear bearing | |
| ⑱ 5th input gear | ㊱ Mainshaft bearing adjusting shim | |

MAJOR OVERHAUL

Shift Control Components




- ① Retaining pin
- ② 1st & 2nd shift fork
- ③ 1st & 2nd check plug
- ④ Return spring
- ⑤ Check ball
- ⑥ 1st & 2nd fork rod
- ⑦ 1st & 2nd bracket
- ⑧ Interlock plunger
- ⑨ 3rd & 4th bracket
- ⑩ Return spring
- ⑪ Reverse gate
- ⑫ Select arm
- ⑬ Return bearing


- ⑭ Bush
- ⑮ Yoke
- ⑯ Striking rod
- ⑰ Striking lever
- ⑱ Selector
- ⑲ Selector shaft
- ⑳ O-ring
- ㉑ Return spring
- ㉒ Cam pin
- ㉓ Reverse check cam
- ㉔ Check ball
- ㉕ Select check spring
- ㉖ Interlock plunger

- ㉗ 3rd & 4th fork rod
- ㉘ Interlock ball
- ㉙ Stopper ring
- ㉚ 3rd & 4th check plug
- ㉛ 3rd & 4th shift fork
- ㉜ 5th shift fork
- ㉝ 5th fork rod
- ㉞ 5th & reverse check plug
- ㉟ Reverse lever spring
- ㊱ Reverse lock spring
- ㊲ 5th & reverse bracket
- ㊳ Reverse lever assembly
- ㊴ Reverse arm shaft


DISASSEMBLY




1. Before removing transmission case, remove bolts and plugs as shown left.
2. Remove transmission case.




3. Remove position switch.



4. Mesh 4th gear, and then remove reverse idler shaft and reverse idler gear.




5. Pull out retaining pin from clutch housing.




6. Remove reverse lever spring and reverse lock spring from reverse lever assembly.


DISASSEMBLY




7. Remove reverse arm shaft while rotating it.



8. Remove reverse lever assembly.




9. Remove 5th & reverse check plug, spring and ball.



10. Remove stopper rings and retaining pins from 5th and 3rd & 4th fork rods.

11. Remove 5th and 3rd & 4th fork rods. Then remove forks and brackets.



12. Remove both input and mainshafts with 1st & 2nd fork and fork rod as a set.

13. Remove final drive assembly.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS


BT

HA


EL

IDX



DISASSEMBLY




14. Remove reverse gate assembly.
Be careful not to lose check ball.



15. Remove retaining pin and detach the selector.








16. Remove drain plug for convenience in removing retaining pin which holds striking lever to striking rod.



17. Remove retaining pin and then withdraw striking lever and striking rod.

REPAIR FOR COMPONENT PARTS



Input Shaft and Gears

DISASSEMBLY

1. Before disassembly, check 3rd, 4th and 5th input gear end plays.

Gear end play

Unit: mm (in)

Gears	End play
3rd input gear	0.23 - 0.43 (0.0091 - 0.0169)
4th input gear	0.25 - 0.55 (0.0098 - 0.0217)
5th input gear	0.23 - 0.48 (0.0091 - 0.0189)

- If not within specification, disassemble and check contact surface of gear, shaft and hub. Then check clearance of snap ring and thrust washer — Refer to "Assembly", MT-17.

2. Remove input shaft rear bearing.

3. Remove 5th & reverse synchronizer and 5th input gear.

4. Remove thrust washer ring, 4th input gear thrust washers and 4th input gear.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT


HA

EL


IDX

REPAIR FOR COMPONENT PARTS


Input Shaft and Gears (Cont'd)




5. Remove snap ring.



6. Remove 3rd & 4th synchronizer and 3rd input gear.




7. Remove input shaft front bearing.



INSPECTION

Gear and shaft

- Check shaft for cracks, wear or bending.
- Check gears for excessive wear, chips or cracks.




Synchronizer

- Check spline portion of coupling sleeves, hubs and gears for wear or cracks.
- Check baulk rings for cracks or deformation.
- Check insert springs for wear or deformation.

REPAIR FOR COMPONENT PARTS

Input Shaft and Gears (Cont'd)



- Measure clearance between baulk ring and gear (4th and 5th).

Clearance between baulk ring and gear:

Standard

1.0 - 1.35 mm (0.0394 - 0.0531 in)


Wear limit

0.7 mm (0.028 in)

GI

MA

EM



- **Measure wear of reverse baulk ring.**

a. Place reverse baulk ring on Tool and then place reverse synchronizer cone on reverse baulk ring.

- **Make sure projection of synchronizer cone is positioned over the recess on Tool.**

b. While holding reverse synchronizer cone against reverse baulk ring as firmly as possible, measure dimension "A" with dial indicator.

Wear limit:

Dimension "A" 1.2 mm (0.047 in)

c. If dimension "A" is smaller than the wear limit, replace baulk ring.

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST


RS

BT

HA

EL

IX




Bearing

- Make sure bearings roll freely and are free from noise, cracks, pitting or wear.






IX

ASSEMBLY



REPAIR FOR COMPONENT PARTS

Input Shaft and Gears (Cont'd)




1. Place inserts in three grooves on coupling sleeve (3rd & 4th synchronizer).
2. Install 3rd input gear and 3rd baulk ring.
3. Press on 3rd & 4th synchronizer hub.
 - **Pay attention to its direction.**
4. Select proper snap ring of 3rd & 4th synchronizer hub to minimize clearance of groove, and then install it.
 - Allowable clearance of groove:**
0 - 0.1 mm (0 - 0.004 in)
 - Snap ring of 3rd & 4th synchronizer hub:**
Refer to SDS, MT-40.

5. Install 4th input gear.
6. Select proper thrust washers to minimize clearance of groove.
Then install them and thrust washer ring.
 - Allowable clearance of groove:**
0 - 0.06 mm (0 - 0.0024 in)
 - 4th input gear thrust washer:**
Refer to SDS, MT-40.

7. Install 5th & reverse synchronizer assembly.
 - a. Hook insert springs on reverse baulk ring.

REPAIR FOR COMPONENT PARTS

Input Shaft and Gears (Cont'd)




- b. Install insert springs with reverse baulk ring onto coupling sleeve.
- **Pay attention to position of insert springs.**
- c. Place 5th baulk ring on 5th input gear.
- d. Install reverse synchronizer cone on reverse baulk ring.

GI

MA

EM




- e. Place reverse synchronizer assembly on 5th input gear.
- **Mesh recesses of 5th Input gear with projections of reverse synchronizer cone.**
- **Put insert spring mounts on reverse baulk ring upon those on 5th baulk ring.**

LC

EC

FE

CL




- f. Press on 5th & reverse synchronizer assembly with 5th input gear.

MT

AT

FA

RA




8. Install input shaft front and rear bearings.
9. Measure gear end play as the final check — Refer to "Disassembly", MT-15.

BR

ST

RS


BT



HA

EL

IDX



Mainshaft and Gears

DISASSEMBLY

1. Before disassembly, check 1st and 2nd main gear end plays.


Gear end play

Unit: mm (in)


Gears	End play
1st main gear	0.23 - 0.43 (0.0091 - 0.0169)
2nd main gear	0.23 - 0.58 (0.0091 - 0.0228)

If not within specification, disassemble and check contact surface of gear, shaft and hub. Then check clearance of snap ring — Refer to "Assembly", MT-22.


2. Press out mainshaft rear bearing.




3. Remove thrust washer and snap ring.



4. Press out 5th main gear and 4th main gear.




5. Press out 3rd main gear and 2nd main gear.




REPAIR FOR COMPONENT PARTS


Mainshaft and Gears (Cont'd)




6. Remove snap ring.



7. Remove 1st & 2nd synchronizer hub and 1st main gear.




8. Remove mainshaft front bearing.



INSPECTION

Gear and shaft

- Check shaft for cracks, wear or bending.
- Check gears for excessive wear, chips or cracks.



Synchronizer

- Check spline portion of coupling sleeves, hubs and gears for wear or cracks.
- Check baulk rings for cracks or deformation.
- Check insert springs for deformation.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT


HA

EL

IDX

REPAIR FOR COMPONENT PARTS

Mainshaft and Gears (Cont'd)



- Measure clearance between baulk ring and gear (1st).


Clearance between baulk ring and gear:

Standard

1.0 - 1.35 mm (0.0394 - 0.0531 in)

Wear limit

0.7 mm (0.028 in)



- Measure wear of 2nd baulk rings.

a. Place baulk rings in position on synchronizer cone.

b. While holding baulk ring against synchronizer cone as far as it will go, measure dimensions "A" and "B".

Standard:


A 0.6 - 0.8 mm (0.024 - 0.031 in)

B 0.6 - 1.1 mm (0.024 - 0.043 in)

Wear limit:

0.2 mm (0.008 in)


c. If dimension "A" or "B" is smaller than the wear limit, replace baulk ring.



Bearing

- Make sure bearings roll freely and are free from noise, cracks, pitting or wear.


- **When replacing tapered roller bearing, replace outer and inner race as a set.**



ASSEMBLY

REPAIR FOR COMPONENT PARTS

Mainshaft and Gears (Cont'd)



1. Press on 1st main gear, 1st baulk ring and 1st & 2nd synchronizer hub.
- **Pay attention to direction of 1st & 2nd synchronizer hub.**
2. Select proper snap ring of 1st & 2nd synchronizer hub to minimize clearance of groove and then install it.

Allowable clearance of groove:

0 - 0.1 mm (0 - 0.004 in)

Snap ring of 1st & 2nd synchronizer hub:

Refer to SDS, MT-40.

GI

MA


EM

LC


EC

FE

CL



MT



3. Install 2nd synchronizer cone, inner & outer baulk rings. Insert springs and 1st & 2nd coupling sleeve.


4. Install 2nd main gear.

- Ensure four protrusions of 2nd synchronizer cone are set in holes of 2nd main gear.

AT

FA

RA



5. Press on 3rd main gear.


6. Press on 4th main gear.

BR

ST

RS

BT



7. Press on 5th main gear.

8. Select proper snap ring of 5th main gear to minimize clearance of groove and then install it.

Allowable clearance of groove:

0 - 0.15 mm (0 - 0.0059 in)

Snap ring of 5th main gear:

Refer to SDS, MT-40.


HA

EL

IDX

REPAIR FOR COMPONENT PARTS

Mainshaft and Gears (Cont'd)




9. Press on thrust washer and press on mainshaft rear bearing.
10. Press on mainshaft front bearing.
11. Measure gear end play as the final check — Refer to "Disassembly", MT-20.

Final Drive


DISASSEMBLY

— RS5F50A —

1. Remove final gear.
 2. Remove speedometer drive gear by cutting it.
 3. Press out differential side bearings.
- **Be careful not to mix up the right and left bearings.**




4. Drive out retaining pin and draw out pinion mate shaft.
5. Remove pinion mate gears and side gears.




— RS5F50V —

1. Remove final gear.




2. Press out differential side bearings.




REPAIR FOR COMPONENT PARTS

Final Drive (Cont'd)


3. Remove speedometer drive gear.




4. Remove viscous coupling.



5. Separate differential cases. Make paint marks to identify their original positions.



6. Remove pinion mate shaft with gears.



INSPECTION

Gear, washer, shaft and case

- Check mating surfaces of differential case, viscous coupling, side gears and pinion mate gears.
- Check washers for wear.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL



IDX

REPAIR FOR COMPONENT PARTS

Final Drive (Cont'd)

Viscous coupling

- Check case for cracks.
- Check silicone oil for leakage




Bearings

- Make sure bearings roll freely and are free from noise, cracks, pitting or wear.
- **When replacing taper roller bearing, replace outer and inner race as a set.**


ASSEMBLY

1. Attach side gear thrust washers to side gears, then install pinion mate washers and pinion mate gears in place.



2. Insert pinion mate shaft.

- **When inserting, be careful not to damage pinion mate thrust washers.**




— RS5F50A —

3. Measure clearance between side gear and differential case with washers following the procedure below:
 - a. Set Tool and dial indicator on side gear.
 - b. Move side gear up and down to measure dial indicator deflection. Always measure indicator deflection on both side gears.


Clearance between side gear and differential case with washers:

0.1 - 0.2 mm (0.004 - 0.008 in)




REPAIR FOR COMPONENT PARTS

Final Drive (Cont'd)




- c. If not within specification, adjust clearance by changing thickness of side gear thrust washers.


**Side gear thrust washer:
Refer to SDS, AT-41.**




4. Install retaining pin.
● **Make sure that retaining pin is flush with case.**



5. Install final gear.
6. Install speedometer drive gear.



7. Press on differential side bearings.



— RS5F50V —

3. Measure clearance between side gear and differential case & viscous coupling with washers using the following procedure:

Differential case side

- a. Set tool on the differential case and lock gauging cylinder in place with set screw.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT


HA

EL


IDX

REPAIR FOR COMPONENT PARTS


Final Drive (Cont'd)



- b. Install gauging plunger into cylinder.




- c. Install pinion mate gears and side gear with thrust washer on differential case.
- d. Set tool and allow gauging plunger to rest on side gear thrust washer.
- e. Measure gap between plunger and cylinder. This measurement should give exact clearance between side gear and differential case with washers.
- Standard clearance: 0.1 - 0.2 mm (0.004 - 0.008 in)**
- f. If not within specification adjust clearance by changing thickness of side gear thrust washer. **Side gear thrust washers for differential case side: Refer to SDS, MT-40.**




Viscous coupling side

- a. Place side gear and thrust washer on pinion mate gears installed on differential case.
- b. Measure dimension X.
- **Measure dimension X in at least four places.**
- a. Set tool on viscous coupling and lock gauging cylinder in place with set screw.



- b. Install gauging plunger into cylinder.



- c. Install pinion mate gears and side gears with original washers on differential cases.

Align paint marks.


- d. Tighten differential case bolts.
- e. Set tool and allow plunger to rest on side gear thrust washer.
- f. Measure gap between plunger and cylinder. This measurement should give exact clearance between side gear and differential case with washers.
- Standard clearance: 0.1 - 0.2 mm (0.004 - 0.008 in)**

REPAIR FOR COMPONENT PARTS


Final Drive (Cont'd)

- g. If not within specification, adjust clearance by changing thickness of side gear thrust washer.

Side gear thrust washers for viscous coupling side: Refer to SDS, MT-40.




4. Install viscous coupling.




5. Install speedometer drive gear on differential case.

- **Align the projection of speedometer drive gear with the groove of differential case.**



6. Press differential side bearings on differential case.



7. Install final gear and tighten fixing bolts in a crisscross pattern.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA


EL

IDX

Shift Control Components

INSPECTION


- Check contact surface and sliding surface for wear, scratches, projections or other damage.




Case Components

REMOVAL AND INSTALLATION

Input shaft oil seal




- Apply multi-purpose grease to seal lip of oil seal before installing.



Mainshaft front bearing outer race

Mainshaft rear bearing outer race — Refer to “ADJUSTMENT”, MT-32.

Differential side bearing outer race — Refer to “ADJUSTMENT”, MT-31.



ADJUSTMENT

Input Shaft End Play and Differential Side Bearing Preload

If any of the following parts are replaced, adjust input shaft end play.

- Input shaft
- Input shaft bearing
- Clutch housing
- Transmission case

If any of the following parts are replaced, adjust differential side bearing preload.

- Differential case
- Differential side bearing
- Clutch housing
- Transmission case

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST




RS

BT

HA

EL

IDX



1. Remove differential side bearing outer race (transmission case side) and shim(s).


2. Reinstall differential side bearing outer race without shim(s).
3. Install input shaft and final drive assembly on clutch housing.
4. Install transmission case without input shaft bearing shim(s). Then tighten it to the specified torque. Refer to MT-9.

5. Using the following procedures, measure clearance between bearings and transmission case.


- **Differential side**
 - a. Attach dial indicator. If clamp diameter of dial indicator is too small or too large, attach dial indicator using a magnetic stand.

ADJUSTMENT


Input Shaft End Play and Differential Side Bearing Preload (Cont'd)




- b. Insert Tool all the way into differential side gear. Move Tool up and down and measure dial indicator deflection.



- **Input shaft side**
 - a. Set dial indicator on end of input shaft.
 - b. Move input shaft up and down and measure dial indicator deflection.
- 6. Select shims with proper thickness with SDS table as a guide. Refer to MT-43.
- 7. Install selected differential side bearing adjusting shim and differential side bearing outer race.



8. Check differential side bearing turning torque.
 - a. Install final drive assembly on clutch housing.
 - b. Install transmission case on clutch housing.
- **Tighten transmission case fixing bolts to the specified torque.**



- c. Measure turning torque of final drive assembly.

**Turning torque of final drive assembly
(New bearing):**
4.9 - 7.8 N·m (50 - 80 kg-cm, 43 - 69 in-lb)
- **When old bearing is used again, turning torque will be slightly less than the above.**
- **Make sure torque is close to the specified range.**






Mainshaft Bearing Preload

If any of the following parts are replaced, adjust mainshaft bearing preload.

- **Mainshaft**
- **Mainshaft bearings**
- **Clutch housing**
- **Transmission case**

ADJUSTMENT

Mainshaft Bearing Preload (Cont'd)



1. Remove mainshaft rear bearing outer race and shim(s).
2. Reinstall mainshaft rear bearing outer race without shims.
3. Clean mating surfaces of clutch housing and transmission case with solvent.
4. Install mainshaft and mainshaft front bearing outer race into transmission case. Turn mainshaft while holding bearing outer race so that bearings are properly seated.
5. Place Tools (bridge and gauging cylinder) onto machined surface of transmission case. Allow gauging cylinder to rest on surface of mainshaft front bearing outer race. Use proper screw in bridge to lock gauging cylinder in place.
6. Turn bridge over and place Tool (gauging plunger) into gauging cylinder.
7. Place bridge, legs up, onto machined surface of clutch housing. Allow gauging plunger to rest upon mating surface where mainshaft front bearing outer race fits.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT


HA

EL

IDX

ADJUSTMENT

Mainshaft Bearing Preload (Cont'd)




8. Measure with feeler gauge distance between gauging cylinder and shoulder of gauging plunger.
9. Use feeler gauge reading to select correct mainshaft preload shim(s).


Mainshaft bearing adjusting shim:

Refer to SDS, MT-41.


10. Install selected mainshaft bearing adjusting shim and mainshaft bearing outer race.
11. Check total turning torque after assembly — Refer to "ASSEMBLY", MT-38.




ASSEMBLY




1. Install striking lever and striking rod.




2. Install selector and retaining pin.



3. Install reverse gate assembly.
Be careful not to lose check ball.



4. Install final drive assembly.
5. Install input shaft and mainshaft with 1st & 2nd shift fork assembly.
● **Be careful not to damage input shaft oil seal.**



6. Install interlock balls and plunger.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS


BT

HA


EL

IDX


ASSEMBLY




7. Install 3rd & 4th shift fork and bracket, then install 3rd & 4th fork rod, stopper ring and retaining pin.




8. Install interlock balls.



9. Install 5th shift fork, then install fork rod, stopper ring and retaining pin.




10. Install 5th & reverse check plug, spring and ball.




11. Install reverse lock spring on 5th & reverse bracket.
● **Pay attention to its direction.**


ASSEMBLY




12. Install check ball and reverse lever spring on reverse lever assembly.
 - Apply multi-purpose grease to check ball.
 - Pay attention to direction of reverse lever spring.




13. Install reverse lever assembly on clutch housing.



14. Install reverse arm shaft and retaining pin.



15. Hook reverse lock spring and reverse lever spring on reverse lever assembly.



16. Mesh 4th gear, then install reverse idler gear and shaft.
 - Pay attention to direction of tapped hole.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS


BT

HA


EL

IDX

ASSEMBLY



17. Place magnet on clutch housing.




18. If bearing preload of mainshaft was adjusted, install selected shim(s) into transmission case.

- To aid in installation of transmission case, place shift selector in the 1st and 2nd shift bracket or between 1st and 2nd bracket and 3rd and 4th bracket.


19. Apply sealant to mating surface of transmission case and install it.

20. Install position switch.



21. Apply sealant to threads of check plugs. Install balls, springs and plugs.

22. After assembly, check that you can shift into each gear smoothly.



23. Measure total turning torque.

Total turning torque (New bearing):

8.8 - 21.6 N·m (90 - 220 kg-cm, 78 - 191 in-lb)

- When old bearing is used again, preload will be slightly less than the above. Make sure torque is close to the specified range.

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

TRANSAXLE

Engine	VQ30DE		
Transaxle model	RS5F50A	RS5F50V	
Number of speeds	5		
Synchromesh type	Warner		
Shift pattern			
	Gear ratio	Number of teeth	
		Input gear	Main gear
1st	3.285	14	46
2nd	1.850	20	37
3rd	1.272	33	42
4th	0.954	44	42
5th	0.795	49	39
Rev.	3.428	14	48
Reverse idler gear	29		
Oil capacity liter (US pt, Imp pt)	4.5 - 4.8 (9-1/2 - 10-1/8, 7-7/8 - 8-1/2)	4.3 - 4.5 (9-1/8 - 9-1/2, 7-5/8 - 7-7/8)	
Remarks	Double balk ring type syn- chronizer	2nd synchronizer	

FINAL GEAR

Engine	VQ30DE	
Transaxle model	RS5F50A	RS5F50V
Final gear ratio	3.823	
Number of teeth	65/17	
Final gear/Pinion		
Side gear/Pinion	14/10	16/10

Inspection and Adjustment

GEAR END PLAY

Unit: mm (in)

Gear	End play
1st main gear	0.23 - 0.43 (0.0091 - 0.0169)
2nd main gear	0.23 - 0.58 (0.0091 - 0.0228)
3rd input gear	0.23 - 0.43 (0.0091 - 0.0169)
4th input gear	0.25 - 0.55 (0.0098 - 0.0217)
5th input gear	0.23 - 0.48 (0.0091 - 0.0189)

CLEARANCE BETWEEN BAULK RING AND GEAR

1st, 3rd, 4th & 5th

Unit: mm (in)


	Standard	Wear limit
1st	1.0 - 1.35 (0.0394 - 0.0531)	0.7 (0.028)
3rd & 4th	1.0 - 1.35 (0.0394 - 0.0531)	0.7 (0.028)
5th	1.0 - 1.35 (0.0394 - 0.0531)	0.7 (0.028)

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)

2nd double baulk ring


Unit: mm (in)



SMT806B

Dimension	Standard	Wear limit
A	0.6 - 0.8 (0.024 - 0.031)	0.2 (0.008)
B	0.6 - 1.1 (0.024 - 0.043)	

Reverse baulk ring



SMT581B

Dimension	Wear limit
A	1.2 mm (0.047 in)

AVAILABLE SNAP RING

1st & 2nd synchronizer hub (At mainshaft)

Thickness mm (in)	Part number
1.95 (0.0768)	32269-03E03
2.00 (0.0787)	32269-03E00
2.05 (0.0807)	32269-03E01
2.10 (0.0827)	32269-03E02

3rd & 4th synchronizer hub (At input shaft)

Thickness mm (in)	Part number
1.95 (0.0768)	32269-03E03
2.00 (0.0787)	32269-03E00
2.05 (0.0807)	32269-03E01
2.10 (0.0827)	32269-03E02

5th main gear (At mainshaft)

Thickness mm (in)	Part number
1.95 (0.0768)	32348-05E00
2.05 (0.0807)	32348-05E01
2.15 (0.0846)	32348-05E02
2.25 (0.0886)	32348-05E03

AVAILABLE THRUST WASHER

4th input gear (At input shaft)

Thickness mm (in)	Part number
4.500 (0.1772)	32278-03E01
4.525 (0.1781)	32278-03E02
4.550 (0.1791)	32278-03E03
4.575 (0.1801)	32278-03E04

Differential side gear thrust washer — RS5F50V

Allowable clearance between side gear and (differential case or viscous coupling) with washer

	Thickness mm (in)	Part number
Differential case side	0.75 - 0.80 (0.0295 - 0.0315)	38424-E3000
	0.80 - 0.85 (0.0315 - 0.0335)	38424-E3001
	0.85 - 0.90 (0.0335 - 0.0354)	38424-E3002
	0.90 - 0.95 (0.0354 - 0.0374)	38424-E3003
Viscous coupling side	0.43 - 0.45 (0.0169 - 0.0177)	38424-51E10
	0.52 - 0.54 (0.0205 - 0.0213)	38424-51E11
	0.61 - 0.63 (0.0240 - 0.0248)	38424-51E12
	0.70 - 0.72 (0.0276 - 0.0283)	38424-51E13
	0.79 - 0.81 (0.0311 - 0.0319)	38424-51E14

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)

Differential side gear thrust washer — RS5F50A

Allowable clearance between side gear and differential case with washer	0.1 - 0.2 mm (0.004 - 0.008 in)
Thickness mm (in)	Part number
0.75 - 0.80 (0.0295 - 0.0315)	38424-E3020
0.80 - 0.85 (0.0315 - 0.0335)	38424-E3021
0.85 - 0.90 (0.0335 - 0.0354)	38424-E3022
0.90 - 0.95 (0.0354 - 0.0374)	38424-E3023

AVAILABLE SHIM

— INPUT SHAFT END PLAY AND MAINSHAFT AND DIFFERENTIAL SIDE BEARING PRELOAD AND ADJUSTING SHIM

Bearing preload and end play

Unit: mm (in)

Mainshaft bearing preload	0.06 - 0.11 (0.0024 - 0.0043)
Input shaft end play	0 - 0.05 (0 - 0.0020)
Differential side bearing preload	0.40 - 0.45 (0.0157 - 0.0177)

Turning torque (New bearing)

Unit: N·m (kg-cm, in-lb)


Final drive only	4.9 - 7.8 (50 - 80, 43 - 69)
Total	8.8 - 21.6 (90 - 220, 78 - 191)

Mainshaft bearing adjusting shim

Thickness mm (in)	Part number
0.40 (0.0157)	32139-03E11
0.44 (0.0173)	32139-03E00
0.48 (0.0189)	32139-03E01
0.52 (0.0205)	32139-03E12
0.56 (0.0220)	32139-03E02
0.60 (0.0236)	32139-03E03
0.64 (0.0252)	32139-03E04
0.68 (0.0268)	32139-03E05
0.72 (0.0283)	32139-03E06
0.76 (0.0299)	32139-03E07
0.80 (0.0315)	32139-03E08
1.20 (0.0472)	32139-03E13

Table for selecting mainshaft bearing adjusting shim

Unit: mm (in)



SMT467B

Dimension "C"	Suitable shim(s)
0.30 - 0.34 (0.0118 - 0.0134)	0.40 (0.0157)
0.34 - 0.38 (0.0134 - 0.0150)	0.44 (0.0173)
0.38 - 0.42 (0.0150 - 0.0165)	0.48 (0.0189)
0.42 - 0.46 (0.0165 - 0.0181)	0.52 (0.0205)
0.46 - 0.50 (0.0181 - 0.0197)	0.56 (0.0220)
0.50 - 0.54 (0.0197 - 0.0213)	0.60 (0.0236)
0.54 - 0.58 (0.0213 - 0.0228)	0.64 (0.0252)
0.58 - 0.62 (0.0228 - 0.0244)	0.68 (0.0268)
0.62 - 0.66 (0.0244 - 0.0260)	0.72 (0.0283)
0.66 - 0.70 (0.0260 - 0.0276)	0.76 (0.0299)
0.70 - 0.74 (0.0276 - 0.0291)	0.80 (0.0315)
0.74 - 0.78 (0.0291 - 0.0307)	0.40 + 0.44 (0.0157 + 0.0173)
0.78 - 0.82 (0.0307 - 0.0323)	0.44 + 0.44 (0.0173 + 0.0173)
0.82 - 0.86 (0.0323 - 0.0339)	0.44 + 0.48 (0.0173 + 0.0189)
0.86 - 0.90 (0.0339 - 0.0354)	0.48 + 0.48 (0.0189 + 0.0189)
0.90 - 0.94 (0.0354 - 0.0370)	0.48 + 0.52 (0.0189 + 0.0205)
0.94 - 0.98 (0.0370 - 0.0386)	0.52 + 0.52 (0.0205 + 0.0205)
0.98 - 1.02 (0.0386 - 0.0402)	0.52 + 0.56 (0.0205 + 0.0220)
1.02 - 1.06 (0.0402 - 0.0417)	0.56 + 0.56 (0.0220 + 0.0220)
1.06 - 1.10 (0.0417 - 0.0433)	0.56 + 0.60 (0.0220 + 0.0236)
1.10 - 1.14 (0.0433 - 0.0449)	0.60 + 0.60 (0.0236 + 0.0236)
1.14 - 1.18 (0.0449 - 0.0465)	0.60 + 0.64 (0.0236 + 0.0252)
1.18 - 1.22 (0.0465 - 0.0480)	0.64 + 0.64 (0.0252 + 0.0252)
1.22 - 1.26 (0.0480 - 0.0496)	0.64 + 0.68 (0.0252 + 0.0268)
1.26 - 1.30 (0.0496 - 0.0512)	0.68 + 0.68 (0.0268 + 0.0268)
1.30 - 1.34 (0.0512 - 0.0528)	0.68 + 0.72 (0.0268 + 0.0283)
1.34 - 1.38 (0.0528 - 0.0543)	0.72 + 0.72 (0.0283 + 0.0283)
1.38 - 1.42 (0.0543 - 0.0559)	0.72 + 0.76 (0.0283 + 0.0299)
1.42 - 1.46 (0.0559 - 0.0575)	0.76 + 0.76 (0.0299 + 0.0299)
1.46 - 1.50 (0.0575 - 0.0591)	0.76 + 0.80 (0.0299 + 0.0315)

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)

Input shaft bearing adjusting shim

Thickness mm (in)	Part number
0.40 (0.0157)	32225-08E00
0.44 (0.0173)	32225-08E01
0.48 (0.0189)	32225-08E02
0.52 (0.0205)	32225-08E03
0.56 (0.0220)	32225-08E04
0.60 (0.0236)	32225-08E05
0.64 (0.0252)	32225-08E06
0.68 (0.0268)	32225-08E07
0.72 (0.0283)	32225-08E08
0.76 (0.0299)	32225-08E09
0.80 (0.0315)	32225-08E10
1.20 (0.0472)	32225-08E11

Table for selecting input shaft bearing adjusting shim

Unit: mm (in)

Dial indicator indication	Suitable shim(s)
0.65 - 0.69 (0.0256 - 0.0272)	0.64 (0.0252)
0.69 - 0.73 (0.0272 - 0.0287)	0.68 (0.0268)
0.73 - 0.77 (0.0287 - 0.0303)	0.72 (0.0283)
0.77 - 0.81 (0.0303 - 0.0319)	0.76 (0.0299)
0.81 - 0.85 (0.0319 - 0.0335)	0.80 (0.0315)
0.85 - 0.89 (0.0335 - 0.0350)	0.40 + 0.44 (0.0157 + 0.0173)
0.89 - 0.93 (0.0350 - 0.0366)	0.44 + 0.44 (0.0173 + 0.0173)
0.93 - 0.97 (0.0366 - 0.0382)	0.44 + 0.48 (0.0173 + 0.0189)
0.97 - 1.01 (0.0382 - 0.0398)	0.48 + 0.48 (0.0189 + 0.0189)
1.01 - 1.05 (0.0398 - 0.0413)	0.48 + 0.52 (0.0189 + 0.0205)
1.05 - 1.09 (0.0413 - 0.0429)	0.52 + 0.52 (0.0205 + 0.0205)
1.09 - 1.13 (0.0429 - 0.0445)	0.52 + 0.56 (0.0205 + 0.0220)
1.13 - 1.17 (0.0445 - 0.0461)	0.56 + 0.56 (0.0220 + 0.0220)
1.17 - 1.21 (0.0461 - 0.0476)	0.56 + 0.60 (0.0220 + 0.0236)
1.21 - 1.25 (0.0476 - 0.0492)	0.60 + 0.60 (0.0236 + 0.0236)
1.25 - 1.29 (0.0492 - 0.0508)	0.60 + 0.64 (0.0236 + 0.0252)
1.29 - 1.33 (0.0508 - 0.0524)	0.64 + 0.64 (0.0252 + 0.0252)
1.33 - 1.37 (0.0524 - 0.0539)	0.64 + 0.68 (0.0252 + 0.0268)
1.37 - 1.41 (0.0539 - 0.0555)	0.68 + 0.68 (0.0268 + 0.0268)
1.41 - 1.45 (0.0555 - 0.0571)	0.68 + 0.72 (0.0268 + 0.0283)
1.45 - 1.49 (0.0571 - 0.0587)	0.72 + 0.72 (0.0283 + 0.0283)
1.49 - 1.53 (0.0587 - 0.0602)	0.72 + 0.76 (0.0283 + 0.0299)
1.53 - 1.57 (0.0602 - 0.0618)	0.76 + 0.76 (0.0299 + 0.0299)
1.57 - 1.61 (0.0618 - 0.0634)	0.76 + 0.80 (0.0299 + 0.0315)
1.61 - 1.65 (0.0634 - 0.0650)	0.80 + 0.80 (0.0315 + 0.0315)
1.65 - 1.69 (0.0650 - 0.0665)	0.44 + 1.20 (0.0173 + 0.0472)

Differential side bearing adjusting shim — RS5F50V

Thickness mm (in)	Part number
0.36 (0.0142)	38753-56E00
0.40 (0.0157)	38753-56E01
0.44 (0.0173)	38753-56E02
0.48 (0.0189)	38753-56E03
0.52 (0.0205)	38753-56E04
0.56 (0.0220)	38753-56E05
0.60 (0.0236)	38753-56E06
0.64 (0.0252)	38753-56E07
0.68 (0.0268)	38753-56E08
0.72 (0.0283)	38753-56E09
0.76 (0.0299)	38753-56E10
0.80 (0.0315)	38753-56E11
0.84 (0.0331)	38753-56E12
0.88 (0.0346)	38753-56E13
0.92 (0.0362)	38753-56E14

Differential side bearing adjusting shim — RS5F50A

Thickness mm (in)	Part number
0.40 (0.0157)	38453-96E00
0.44 (0.0173)	38453-96E01
0.48 (0.0189)	38453-96E02
0.52 (0.0205)	38453-96E03
0.56 (0.0220)	38453-96E04
0.60 (0.0236)	38453-96E05
0.64 (0.0252)	38453-96E06
0.68 (0.0268)	38453-96E07
0.72 (0.0283)	38453-96E08
0.76 (0.0299)	38453-96E09
0.80 (0.0315)	38453-96E10
0.84 (0.0331)	38453-96E11
0.88 (0.0346)	38453-96E12
1.20 (0.0472)	38453-96E13

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)

Table for selecting differential side bearing adjusting shim(s)

Unit: mm (in)

Dial indicator deflection	Suitable shim(s)
0.47 - 0.51 (0.0185 - 0.0201)	0.44 + 0.48 (0.0173 + 0.0189)
0.51 - 0.55 (0.0201 - 0.0217)	0.48 + 0.48 (0.0189 + 0.0189)
0.55 - 0.59 (0.0217 - 0.0232)	0.48 + 0.52 (0.0189 + 0.0205)
0.59 - 0.63 (0.0232 - 0.0248)	0.52 + 0.52 (0.0205 + 0.0205)
0.63 - 0.67 (0.0248 - 0.0264)	0.52 + 0.56 (0.0205 + 0.0220)
0.67 - 0.71 (0.0264 - 0.0280)	0.56 + 0.56 (0.0220 + 0.0220)
0.71 - 0.75 (0.0280 - 0.0295)	0.56 + 0.60 (0.0220 + 0.0236)
0.75 - 0.79 (0.0295 - 0.0311)	0.60 + 0.60 (0.0236 + 0.0236)
0.79 - 0.83 (0.0311 - 0.0327)	0.60 + 0.64 (0.0236 + 0.0252)
0.83 - 0.87 (0.0327 - 0.0343)	0.64 + 0.64 (0.0252 + 0.0252)
0.87 - 0.91 (0.0343 - 0.0358)	0.64 + 0.68 (0.0252 + 0.0268)
0.91 - 0.95 (0.0358 - 0.0374)	0.68 + 0.68 (0.0268 + 0.0268)
0.95 - 0.99 (0.0374 - 0.0390)	0.68 + 0.72 (0.0268 + 0.0283)
0.99 - 1.03 (0.0390 - 0.0406)	0.72 + 0.72 (0.0283 + 0.0283)
1.03 - 1.07 (0.0406 - 0.0421)	0.72 + 0.76 (0.0283 + 0.0299)
1.07 - 1.11 (0.0421 - 0.0437)	0.76 + 0.76 (0.0299 + 0.0299)
1.11 - 1.15 (0.0437 - 0.0453)	0.76 + 0.80 (0.0299 + 0.0315)
1.15 - 1.19 (0.0453 - 0.0469)	0.80 + 0.80 (0.0315 + 0.0315)
1.19 - 1.23 (0.0469 - 0.0484)	0.72 + 0.92 (0.0283 + 0.0362)
1.23 - 1.27 (0.0484 - 0.0500)	0.76 + 0.92 (0.0299 + 0.0362)
1.27 - 1.31 (0.0500 - 0.0516)	0.80 + 0.92 (0.0315 + 0.0362)

GI

MA

EW

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX