

SECTION HAC

HEATER & AIR CONDITIONING CONTROL SYSTEM

CONTENTS

AUTOMATIC AIR CONDITIONING		
PRECAUTION	5	
PRECAUTIONS	5	
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	5	
Working with HFC-134a (R-134a)	5	
Precaution for Service Equipment	6	
SYSTEM DESCRIPTION	7	
COMPONENT PARTS	7	
FRONT AUTOMATIC AIR CONDITIONING SYSTEM	7	
FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Component Parts Location	7	
FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Component Description	8	
REAR AUTOMATIC AIR CONDITIONING SYSTEM	10	
REAR AUTOMATIC AIR CONDITIONING SYSTEM : Component Parts Location	11	
REAR AUTOMATIC AIR CONDITIONING SYSTEM : Component Description	12	
ACCS (ADVANCED CLIMATE CONTROL SYSTEM)	13	
ACCS (ADVANCED CLIMATE CONTROL SYSTEM) : Component Parts Location	13	
ACCS (ADVANCED CLIMATE CONTROL SYSTEM) : Component Description	14	
SYSTEM	15	
FRONT AUTOMATIC AIR CONDITIONING SYSTEM	15	
FRONT AUTOMATIC AIR CONDITIONING SYSTEM : System Diagram	15	
FRONT AUTOMATIC AIR CONDITIONING SYSTEM : System Description	15	
FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Intelligent Key Interlock Function	16	
FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Air Flow Control	17	
FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Air Inlet Control	18	
FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Air Outlet Control	18	
FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Compressor Control	19	
FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Door Control	20	
FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Temperature Control	22	
FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Fail-safe	22	
REAR AUTOMATIC AIR CONDITIONING SYSTEM	22	
REAR AUTOMATIC AIR CONDITIONING SYSTEM : System Diagram	23	
REAR AUTOMATIC AIR CONDITIONING SYSTEM : System Description	23	
REAR AUTOMATIC AIR CONDITIONING SYSTEM : Intelligent Key Interlock Function	24	
REAR AUTOMATIC AIR CONDITIONING SYSTEM : Air Flow Control	24	
REAR AUTOMATIC AIR CONDITIONING SYSTEM : Air Outlet Control	26	
REAR AUTOMATIC AIR CONDITIONING SYSTEM : Door Control	26	
REAR AUTOMATIC AIR CONDITIONING SYSTEM : Temperature Control	27	
ACCS (ADVANCED CLIMATE CONTROL SYSTEM)	27	
ACCS (ADVANCED CLIMATE CONTROL SYSTEM) : System Diagram	28	

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

ACCS (ADVANCED CLIMATE CONTROL SYSTEM) : System Description	28	ACCS (ADVANCED CLIMATE CONTROL SYSTEM)	76
ACCS (ADVANCED CLIMATE CONTROL SYSTEM) : Intelligent Key Interlock Function	28	ACCS (ADVANCED CLIMATE CONTROL SYSTEM) : Work Procedure	76
ACCS (ADVANCED CLIMATE CONTROL SYSTEM) : Automatic Intake Control (Exhaust Gas / Outside Odor Detecting Mechanism)	29	SYSTEM SETTING	78
ACCS (ADVANCED CLIMATE CONTROL SYSTEM) : Plasmacluster Control	29	FRONT AUTOMATIC AIR CONDITIONING SYSTEM	78
OPERATION	30	FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Temperature Setting Trimmer (Front)	78
FRONT AUTOMATIC AIR CONDITIONING SYSTEM	30	FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Foot Position Setting Trimmer	78
FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Switch Name and Function	30	FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Inlet Port Memory Function (FRE)	79
REAR AUTOMATIC AIR CONDITIONING SYSTEM	32	FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Inlet Port Memory Function (REC)	79
REAR AUTOMATIC AIR CONDITIONING SYSTEM : Switch Name and Function	32	REAR AUTOMATIC AIR CONDITIONING SYSTEM	79
ACCS (ADVANCED CLIMATE CONTROL SYSTEM)	34	REAR AUTOMATIC AIR CONDITIONING SYSTEM : Temperature Setting Trimmer (Rear)	79
ACCS (ADVANCED CLIMATE CONTROL SYSTEM) : Switch Name and Function	34	ACCS (ADVANCED CLIMATE CONTROL SYSTEM)	80
DIAGNOSIS SYSTEM (HVAC)	37	ACCS (ADVANCED CLIMATE CONTROL SYSTEM) : Exhaust Gas / Outside Odor Detecting Sensor Sensitivity Adjustment Function	80
Description	37	ACCS (ADVANCED CLIMATE CONTROL SYSTEM) : Auto Intake Switch Interlocking Movement Change Function	80
CONSULT Function	37	DTC/CIRCUIT DIAGNOSIS	82
ECU DIAGNOSIS INFORMATION	40	U1000 CAN COMM CIRCUIT	82
A/C AUTO AMP.	40	Description	82
Reference Value	40	DTC Logic	82
Fail-safe	44	Diagnosis Procedure	82
DTC Index	44	U1010 CONTROL UNIT (CAN)	83
ECM, IPDM E/R, BCM	46	Description	83
List of ECU Reference	46	DTC Logic	83
WIRING DIAGRAM	47	Diagnosis Procedure	83
AUTOMATIC AIR CONDITIONING SYSTEM ...	47	B2578, B2579 IN-VEHICLE SENSOR	84
Wiring Diagram	47	DTC Logic	84
BASIC INSPECTION	69	Diagnosis Procedure	84
DIAGNOSIS AND REPAIR WORK FLOW	69	Component Inspection	85
Work Flow	69	B257B, B257C AMBIENT SENSOR	87
OPERATION INSPECTION	72	DTC Logic	87
FRONT AUTOMATIC AIR CONDITIONING SYSTEM	72	Diagnosis Procedure	87
FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Work Procedure	72	Component Inspection	88
REAR AUTOMATIC AIR CONDITIONING SYSTEM	73	B2581, B2582 INTAKE SENSOR	90
REAR AUTOMATIC AIR CONDITIONING SYSTEM : Work Procedure	74	DTC Logic	90
		Diagnosis Procedure	90
		Component Inspection	91

B262A, B262B, B2657, B2658 EXHAUST GAS/OUTSIDE ODOR DETECTING SENSOR	93	AIR MIX DOOR MOTOR (DRIVER SIDE) : Diagnosis Procedure	116	A
DTC Logic	93	AIR MIX DOOR MOTOR (PASSENGER SIDE)	117	B
Diagnosis Procedure	93	AIR MIX DOOR MOTOR (PASSENGER SIDE) : Diagnosis Procedure	117	B
B2630, B2631 SUNLOAD SENSOR	96	AIR MIX DOOR MOTOR (REAR)	118	C
DTC Logic	96	AIR MIX DOOR MOTOR (REAR) : Diagnosis Procedure	118	C
Diagnosis Procedure	96	MODE DOOR MOTOR (FRONT)	119	D
Component Inspection	97	MODE DOOR MOTOR (FRONT) : Diagnosis Procedure	119	D
B2632, B2633 AIR MIX DOOR MOTOR (DRIVER SIDE)	99	MODE DOOR MOTOR (REAR)	120	E
DTC Logic	99	MODE DOOR MOTOR (REAR) : Diagnosis Procedure	120	E
Diagnosis Procedure	99	INTAKE DOOR MOTOR	121	F
B2634, B2635 AIR MIX DOOR MOTOR (PASSENGER SIDE)	101	INTAKE DOOR MOTOR : Diagnosis Procedure ..	121	F
DTC Logic	101	REAR SHUT-OFF DOOR MOTOR	122	G
Diagnosis Procedure	101	REAR SHUT-OFF DOOR MOTOR : Diagnosis Procedure	122	G
B2636, B2637, B2638, B2639, B2654 MODE DOOR MOTOR (FRONT)	103	REAR A/C CONTROL	123	H
DTC Logic	103	REAR A/C CONTROL : Diagnosis Procedure	123	H
Diagnosis Procedure	103	DOOR MOTOR	125	HAC
B263D, B263E, B263F INTAKE DOOR MOTOR	105	Diagnosis Procedure	125	HAC
DTC Logic	105	DOOR MOTOR COMMUNICATION CIRCUIT.	127	J
Diagnosis Procedure	105	Diagnosis Procedure	127	J
B2799, B279A AIR MIX DOOR MOTOR (REAR)	107	FRONT BLOWER MOTOR	129	K
DTC Logic	107	Diagnosis Procedure	129	K
Diagnosis Procedure	107	Component Inspection (Front Blower Motor)	130	K
B279B, B279C MODE DOOR MOTOR (REAR)	109	Component Inspection (Front Blower Motor Relay)	130	L
DTC Logic	109	IONIZER	132	L
Diagnosis Procedure	109	Component Function Check	132	L
B279D, B279E REAR SHUT-OFF DOOR MOTOR	111	Diagnosis Procedure	132	M
DTC Logic	111	MAGNET CLUTCH	134	M
Diagnosis Procedure	111	Component Function Check	134	M
B2796, B2797, B2798 COMMUNICATION ERROR	113	Diagnosis Procedure	134	N
DTC Logic	113	PTC HEATER RELAY	135	N
Diagnosis Procedure	113	Description	135	O
B27B0 A/C AUTO AMP.	115	Component Function Check	135	O
DTC Logic	115	Diagnosis Procedure	135	O
Diagnosis Procedure	115	Component Inspection	136	P
POWER SUPPLY AND GROUND CIRCUIT ...	116	PTC HEATER	137	P
A/C AUTO AMP.	116	Diagnosis Procedure	137	P
A/C AUTO AMP. : Diagnosis Procedure	116	REAR BLOWER MOTOR	139	P
AIR MIX DOOR MOTOR (DRIVER SIDE)	116	Diagnosis Procedure	139	P
		Component Inspection (Rear Blower Motor)	143	P
		Component Inspection (Rear Blower Motor Relay) ..	143	P

Component Inspection (Rear Blower Motor Resistor)	143	A/C AUTO AMP.	157
SYMPTOM DIAGNOSIS	145	Exploded View	157
FRONT AUTOMATIC AIR CONDITIONING SYSTEM	145	Removal and Installation	157
Diagnosis Chart By Symptom	145	AMBIENT SENSOR	158
REAR AUTOMATIC AIR CONDITIONING SYSTEM	147	Removal and Installation	158
Diagnosis Chart By Symptom	147	IN-VEHICLE SENSOR	159
ACCS (ADVANCED CLIMATE CONTROL SYSTEM)	148	Removal and Installation	159
Symptom Table	148	SUNLOAD SENSOR	160
INSUFFICIENT COOLING	149	Removal and Installation	160
FRONT AIR CONDITIONER	149	INTAKE SENSOR	161
FRONT AIR CONDITIONER : Description	149	Removal and Installation	161
FRONT AIR CONDITIONER : Diagnosis Procedure	149	EXHAUST GAS/OUTSIDE ODOR DETECTING SENSOR	162
REAR AIR CONDITIONER	150	Removal and Installation	162
REAR AIR CONDITIONER : Description	150	REFRIGERANT PRESSURE SENSOR	163
REAR AIR CONDITIONER : Diagnosis Procedure	150	Removal and Installation	163
INSUFFICIENT HEATING	151	DOOR MOTOR	164
FRONT AIR CONDITIONER	151	Exploded View - Front Door Motors	164
FRONT AIR CONDITIONER : Description	151	MODE DOOR MOTOR	165
FRONT AIR CONDITIONER : Diagnosis Procedure	151	MODE DOOR MOTOR : Removal and Installation	165
REAR AIR CONDITIONER	152	- Mode Door Motor (Front)	165
REAR AIR CONDITIONER : Description	152	MODE DOOR MOTOR : Removal and Installation	165
REAR AIR CONDITIONER : Diagnosis Procedure	152	- Mode Door Motor (Rear)	165
INTELLIGENT KEY INTERLOCK FUNCTION DOES NOT OPERATE	153	AIR MIX DOOR MOTOR	165
Description	153	AIR MIX DOOR MOTOR : Removal and Installation - Air Mix Door Motor (Driver Side)	165
Diagnosis Procedure	153	AIR MIX DOOR MOTOR : Removal and Installation - Air Mix Door Motor (Passenger Side)	165
COMPRESSOR DOES NOT OPERATE	154	AIR MIX DOOR MOTOR : Removal and Installation - Air Mix Door Motor (Rear)	165
Description	154	INTAKE DOOR MOTOR	166
Diagnosis Procedure	154	INTAKE DOOR MOTOR : Removal and Installation	166
REMOVAL AND INSTALLATION	156	REAR SHUT-OFF DOOR MOTOR	166
A/C SWITCH	156	REAR SHUT-OFF DOOR MOTOR : Removal and Installation	166
Removal and Installation	156	BLOWER MOTOR RESISTOR	167
		Removal and Installation	167
		IONIZER	168
		Exploded View	168
		Removal and Installation	168

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000008487412

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes dual stage front air bag modules. The SRS system may only deploy one front air bag, depending on the severity of a collision and whether the front passenger seat is occupied. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Working with HFC-134a (R-134a)

INFOID:000000008360351

WARNING:

- CFC-12 (R-12) refrigerant and HFC-134a (R-134a) refrigerant are not compatible. If the refrigerants are mixed compressor failure is likely to occur. Refer to [HA-22, "Inspection"](#). To determine the purity of HFC-134a (R-134a) in the vehicle and recovery tank, use Refrigerant Recovery/Recycling Recharging equipment and Refrigerant Identifier.
- Use only specified oil for the HFC-134a (R-134a) A/C system and HFC-134a (R-134a) components. If oil other than that specified is used, compressor failure is likely to occur.
- The specified HFC-134a (R-134a) oil rapidly absorbs moisture from the atmosphere. The following handling precautions must be observed:
 - When removing refrigerant components from a vehicle, immediately cap (seal) the component to minimize the entry of moisture from the atmosphere.
 - When installing refrigerant components to a vehicle, do not remove the caps (unseal) until just before connecting the components. Connect all refrigerant loop components as quickly as possible to minimize the entry of moisture into system.
 - Only use the specified oil from a sealed container. Immediately reseal containers of oil. Without proper sealing, oil will become moisture saturated and should not be used.
 - Avoid breathing A/C refrigerant and oil vapor or mist. Exposure may irritate eyes, nose and throat. Remove HFC-134a (R-134a) from the A/C system using certified service equipment meeting requirements of SAE J2210 [HFC-134a (R-134a) recycling equipment], or J2209 [HFC-134a (R-134a) recycling equipment], If accidental system discharge occurs, ventilate work area before resuming service. Additional health and safety information may be obtained from refrigerant and oil manufacturers.
 - Do not allow A/C oil to come in contact with styrofoam parts. Damage may result.

CONTAMINATED REFRIGERANT

If a refrigerant other than pure HFC-134a (R-134a) is identified in a vehicle, your options are:

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

HAC

PRECAUTIONS

[AUTOMATIC AIR CONDITIONING]

< PRECAUTION >


- Explain to the customer that environmental regulations prohibit the release of contaminated refrigerant into the atmosphere.
- Explain that recovery of the contaminated refrigerant could damage your service equipment and refrigerant supply.
- Suggest the customer return the vehicle to the location of previous service where the contamination may have occurred.
- If you choose to perform the repair, recover the refrigerant using only **dedicated equipment and containers. Do not recover contaminated refrigerant into your existing service equipment.** If your facility does not have dedicated recovery equipment, you may contact a local refrigerant product retailer for available service. This refrigerant must be disposed of in accordance with all federal and local regulations. In addition, replacement of all refrigerant system components on the vehicle is recommended.
- If the vehicle is within the warranty period, the air conditioner warranty is void. Please contact NISSAN Customer Affairs for further assistance.

Precaution for Service Equipment

INFOID:000000008360352


MANIFOLD GAUGE SET

Be certain that the gauge face indicates R-134a or 134a. Make sure the gauge set has 1/2"-16 ACME threaded connections for service hoses. Confirm the set has been used only with refrigerant HFC-134a (R-134a) along with specified oil.



SERVICE HOSES


Be certain that the service hoses display the markings described (colored hose with black stripe). All hoses must include positive shut-off devices (either manual or automatic) near the end of the hoses opposite the manifold gauge.



SERVICE COUPLERS

Never attempt to connect HFC-134a (R-134a) service couplers to a CFC-12 (R-12) A/C system. The HFC-134a (R-134a) couplers will not properly connect to the CFC-12 (R-12) system. However, if an improper connection is attempted, discharging and contamination may occur.

Shut-off valve rotation	A/C service valve
Clockwise	Open
Counterclockwise	Close



< SYSTEM DESCRIPTION >


SYSTEM DESCRIPTION

COMPONENT PARTS

FRONT AUTOMATIC AIR CONDITIONING SYSTEM

FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Component Parts Location

INFOID:000000008179907



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


HAC

ALL11A054622

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[AUTOMATIC AIR CONDITIONING]



- | | | |
|---|--|---|
| 1. ECM | 2. BCM (view with combination meter removed) | 3. IPDM E/R. |
| 4. A/C and AV switch assembly | 5. AV control unit | 6. A/C auto amp. |
| 7. Display unit | 8. Fuse block (J/B) | 9. Fuse block (J/B) |
| 10. Front blower motor relay | 11. Accessory relay-2 | 12. A/C compressor |
| 13. Sunload sensor | 14. Refrigerant pressure sensor (view with front bumper fascia removed) | 15. Ambient sensor |
| 16. In-vehicle sensor | 17. Intake door motor (view with fresh air intake duct removed from vehicle) | 18. Front blower motor |
| 19. Mode door motor (front) (view with front A/C assembly removed from vehicle) | 20. Air mix door motor (driver side) | 21. Air mix door motor (passenger side) (view with front A/C assembly removed from vehicle) |
| 22. Intake sensor | | |

FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Component Description

INFOID:000000008179908

Component	Description
A/C and AV switch assembly	Front A/C control operation signal is transmitted from the A/C and AV switch assembly to AV control unit via communication line.
A/C auto amp.	A/C auto amp. controls front automatic air conditioning system by inputting and calculating signals from each sensor and each switch.
A/C Compressor	Vaporized refrigerant is drawn into the A/C compressor from the evaporator, where it is compressed to a high pressure, high temperature vapor. The hot, compressed vapor is then discharged to the condenser.
Air mix door motor (Driver side)	The air mix door controls the mix of hot or cold air that enters the ventilation system. It is controlled by the A/C auto amp. based on the position of the temperature dial. The air mix door motor receives position commands from the A/C auto amp. and reports actual door position back via an LCU (Local Control Unit) installed inside the motor. Commands and responses are sent across the LIN (Local Interconnect Network) to each motor simultaneously, with each motor having its own unique address, thereby only responding to requests sent to its specific address. The LCU reads the door positioning from a Position Balanced Resistor (PBR), also part of the motor, and returns that information to the A/C auto amp.. The LCU switches the polarity of the circuits connected to the DC motor to drive the motor forward or backward as requested by the front air control. If the air mix door moves to a position less than 5% or more than 95% of its expected or allowed positions, the A/C auto amp. will set a DTC.

COMPONENT PARTS

[AUTOMATIC AIR CONDITIONING]

< SYSTEM DESCRIPTION >

Component	Description
Air mix door motor (Passenger side)	The air mix door controls the mix of hot or cold air that enters the ventilation system. It is controlled by the A/C auto amp. based on the position of the temperature dial. The air mix door motor receives position commands from the A/C auto amp. and reports actual door position back via an LCU (Local Control Unit) installed inside the motor. Commands and responses are sent across the LIN (Local Interconnect Network) to each motor simultaneously, with each motor having its own unique address, thereby only responding to requests sent to its specific address. The LCU reads the door position from a Position Balanced Resistor (PBR), also part of the motor, and returns that information to the A/C auto amp.. The LCU switches the polarity of the circuits connected to the DC motor to drive the motor forward or backward as requested by the front air control. If the air mix door moves to a position less than 5% or more than 95% of its expected or allowed positions, the A/C auto amp. will set a DTC.
Ambient sensor	The ambient sensor measures the temperature of the air surrounding the vehicle. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.
AV control unit	AV control unit transmits A/C and AV switch assembly operation signal to A/C auto amp. via CAN communication line.
BCM	BCM transmits blower motor ON signal to the front and rear blower motor relays.
Display unit	The display unit indicates operation status of the front and rear automatic air conditioning system.
ECM	The ECM sends a compressor ON request to the IPDM E/R based on the status of engine operation and load as well as refrigerant pressure information. If all the conditions are met for A/C operation, the ECM transmits the compressor ON request to the IPDM E/R. The ECM shares the refrigerant pressure sensor signal, engine RPM, and engine coolant temperature with the A/C auto amp. via CAN communication line.
Front blower motor	The front blower motor varies the speed at which the air flows through the ventilation system.
Front blower motor relay	The front blower motor relay controls the flow of current to fuse 17 and 27 in the Fuse Block (J/B). The relay is connected directly to ground, and is controlled by the BCM.
Fuse block (J/B)	Located in the passenger compartment, behind the left lower IP, the Fuse Block (J/B) contains the front blower motor relay and several fuses required for the air conditioner control system.
IPDM E/R	A/C relay is integrated in IPDM E/R. IPDM E/R operates A/C relay when A/C compressor request signal is received from ECM via CAN communication line.
Intake door motor	The intake door motor controls the position of the intake door. Fresh air is allowed to enter the cabin in one position, and recirculated inside air is allowed to enter in the other position. At times the A/C auto amp. may command partial fresh or recirculation based on evaporator or coolant temperatures. The intake door motor receives position commands from the front air control and reports actual door position back via an LCU (Local Control Unit) installed inside the motor. Commands and responses are sent across the LIN (Local Interconnect Network) to each motor simultaneously, with each motor having its own unique address, thereby only responding to requests sent to its specific address. The LCU reads the door position from a Position Balanced Resistor (PBR), also part of the motor, and returns that information to the front air control. The LCU switches the polarity of the circuits connected to the DC motor to drive the motor forward or backward as requested by the front air control. If the recirculation door moves to a position less than 5% or more than 95% of its expected or allowed positions, the front air control will set a DTC.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

HAC

COMPONENT PARTS

[AUTOMATIC AIR CONDITIONING]

< SYSTEM DESCRIPTION >

Component	Description
Intake sensor	Intake sensor measures temperature of front evaporator fin temperature. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.
In-vehicle sensor	In-vehicle sensor measures temperature of intake air that flows through aspirator to passenger room. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.
Mode door motor (Front)	The mode door (front) controls the direction the conditioned air passes through the ventilation system. Through a series of levers and gears, the mode door controls the defrost door, the foot door, and the vent door. There are 5 preset positions: VENT, B/L, FOOT, D/F and DEF. The FOOT position can be set to allow some airflow through to the defroster vent or to completely block the defroster vent using the CONSULT. The mode door motor receives position commands from the A/C auto amp. and reports actual door position back via an LCU (Local Control Unit) installed inside the motor. Commands and responses are sent across the LIN (Local Interconnect Network) to each motor simultaneously, with each motor having its own unique address, thereby only responding to requests sent to its specific address. The LCU reads the door position from a Position Balanced Resistor (PBR), also part of the motor, and returns that information to the front air control. The LCU switches the polarity of the circuits connected to the DC motor to drive the motor forward or backward as requested by the front air control. The mode door has 5 expected positions and, therefore, can set up to 5 DTCs if the expected position is not reported back to the A/C auto amp.
Refrigerant pressure sensor	Refer to EC-31. "Refrigerant Pressure Sensor" .
Sunload sensor	Sunload sensor measures sunload amount. This sensor converts sunload amount to voltage signal by photodiode and transmits to A/C auto amp.

REAR AUTOMATIC AIR CONDITIONING SYSTEM


COMPONENT PARTS

[AUTOMATIC AIR CONDITIONING]

< SYSTEM DESCRIPTION >

REAR AUTOMATIC AIR CONDITIONING SYSTEM : Component Parts Location

INFOID:000000008179909



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

HAC

- | | | |
|---|---|--|
| 1. Rear blower motor relay (view with instrument panel removed) | 2. PTC relay 1 | 3. PTC relay 2 |
| 4. Rear air control | 5. A/C and AV switch assembly | 6. AV control unit |
| 7. A/C auto amp. | 8. Display unit | 9. BCM (view with combination meter removed) |
| 10. Air mix door motor (rear) (view with front A/C assembly removed from vehicle) | 11. PTC heater (view with rear booster assembly removed from vehicle) | 12. Rear blower motor resistor 1 |

ALLIA0550ZZ

COMPONENT PARTS

[AUTOMATIC AIR CONDITIONING]

< SYSTEM DESCRIPTION >

- | | | |
|---|---|----------------------------|
| 13. Rear blower motor 1 | 14. Rear shut-off door motor (view with rear booster assembly removed from vehicle) | 15. Mode door motor (rear) |
| 16. Rear blower motor resistor 2 (view with luggage side lower finisher RH removed) | 17. Rear blower motor 2 | |

REAR AUTOMATIC AIR CONDITIONING SYSTEM : Component Description

INFOID:000000008179910

Component	Description
A/C auto amp.	A/C auto amp. controls the automatic air conditioning system by inputting and calculating signals from each sensor and each switch.
A/C and AV switch assembly	Rear air control operation signal is transmitted from the A/C and AV switch assembly to AV control unit via communication line.
Air mix door motor (Rear)	The air mix door (rear) controls the mix of hot or cold air that enters the ventilation system. It is controlled by the A/C auto amp. based on the position of the temperature dial. The air mix door motor (rear) receives position commands from the A/C auto amp. and reports actual door position back via an LCU (Local Control Unit) installed inside the motor. Commands and responses are sent across the LIN (Local Interconnect Network) to each motor simultaneously, with each motor having its own unique address, thereby only responding to requests sent to its specific address. The LCU reads the door position from a Position Balanced Resistor (PBR), also part of the motor, and returns that information to the A/C auto amp.. The LCU switches the polarity of the circuits connected to the DC motor to drive the motor forward or backward as requested by the front air control. If the air mix door (rear) moves to a position less than 5% or more than 95% of its expected or allowed positions, the A/C auto amp. will set a DTC.
AV control unit	AV control unit transmits A/C and AV switch assembly operation signal to A/C auto amp. via CAN communication line.
BCM	BCM transmits blower motor ON signal to the rear blower motor relay.
Display unit	The display unit indicates operation status of the front and rear automatic air conditioning system.
Mode door motor (Rear)	The mode door (rear) controls the direction the conditioned air passes through the ventilation system. The mode door motor (rear) receives position commands from the A/C auto amp. and reports actual door position back via an LCU (Local Control Unit) installed inside the motor. Commands and responses are sent across the LIN (Local Interconnect Network) to each motor simultaneously, with each motor having its own unique address, thereby only responding to requests sent to its specific address. The LCU reads the door position from a Position Balanced Resistor (PBR), also part of the motor, and returns that information to the front air control. The LCU switches the polarity of the circuits connected to the DC motor to drive the motor forward or backward as requested by the A/C auto amp.. The mode door has 2 expected positions and, therefore, can set up to 2 DTCs if the expected position is not reported back to the A/C auto amp.
PTC heater	The positive temperature coefficient (PTC) heater provides supplemental heat to the rear seating by warming the air as it flows through its electrically controlled heating grid.
PTC heater relay	The PTC heater relay controls the flow of current to the PTC heater. The relay is controlled by the A/C auto amp.
Rear blower motor 1	The rear blower motor-1 varies the speed at which the air flows through the ventilation system.
Rear blower motor 2	The rear blower motor-2 varies the speed at which the air flows through the ventilation system.

COMPONENT PARTS

[AUTOMATIC AIR CONDITIONING]

< SYSTEM DESCRIPTION >

Component	Description
Rear blower motor relay	The rear blower motor relay controls the flow of current to the rear blower motor. The relay is connected directly to ground, and is controlled by the BCM.
Rear shut-off door motor	The rear shut-off door controls the conditioned air through the ventilation system. The rear shut-off door motor receives position commands from the A/C auto amp. and reports actual door position back via an LCU (Local Control Unit) installed inside the motor. Commands and responses are sent across the LIN (Local Interconnect Network) to each motor simultaneously, with each motor having its own unique address, thereby only responding to requests sent to its specific address. The LCU reads the door position from a Position Balanced Resistor (PBR), also part of the motor, and returns that information to the front air control. The LCU switches the polarity of the circuits connected to the DC motor to drive the motor forward or backward as requested by the A/C auto amp.. The mode door has 2 expected positions and therefore will set a DTC if the expected position is not reported back to the A/C auto amp.


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

HAC

ACCS (ADVANCED CLIMATE CONTROL SYSTEM)

ACCS (ADVANCED CLIMATE CONTROL SYSTEM) : Component Parts Location

INFOID:000000008179911



ALLIA0549ZZ

COMPONENT PARTS

[AUTOMATIC AIR CONDITIONING]

< SYSTEM DESCRIPTION >

- | | | |
|--|---|------------------|
| 1. Exhaust gas / outside odor detecting sensor (view with front bumper fascia removed) | 2. Intake door motor (view with fresh air intake duct removed from vehicle) | 3. Ionizer |
| 4. A/C and AV switch assembly | 5. AV control unit | 6. A/C auto amp. |
| 7. Display unit | | |

ACCS (ADVANCED CLIMATE CONTROL SYSTEM) : Component Description

INFOID:000000008179912

Component	Description
A/C and AV switch assembly	Front A/C control operation signal is transmitted from the A/C and AV switch assembly to AV control unit via communication line.
A/C auto amp.	A/C auto amp. controls ACCS (advanced climate control system) by inputting and calculating signals from each sensor and each switch. A/C auto amp. has self-diagnosis function. Diagnosis of ACCS (advanced climate control system) can be performed quickly.
AV control unit	AV control unit transmits A/C switch operation signal to A/C auto amp. via CAN communication line.
Display unit	Display unit indicates operation status of ACCS (advanced climate control system).
Exhaust gas / outside odor detecting sensor	Exhaust gas / outside odor detecting sensor measures exhaust gas outside of the passenger room. In addition to previous exhaust gas detection function, unpleasant odor in ambient atmosphere is also measured.
Intake door motor	The intake door motor controls the position of the intake door. Fresh air is allowed to enter the cabin in one position, and recirculated inside air is allowed to enter in the other position. At times the front air control may command partial fresh or recirculation based on evaporator or coolant temperatures. The intake door motor receives position commands from the A/C auto amp. and reports actual door position back via an LCU (Local Control Unit) installed inside the motor. Commands and responses are sent across the LIN (Local Interconnect Network) to each motor simultaneously, with each motor having its own unique address, thereby only responding to requests sent to its specific address. The LCU reads the door position from a Position Balanced Resistor (PBR), also part of the motor, and returns that information to the front air control. The LCU switches the polarity of the circuits connected to the DC motor to drive the motor forward or backward as requested by the front air control. If the recirculation door moves to a position less than 5% or more than 95% of its expected or allowed positions, the A/C auto amp will set a DTC.
Ionizer	Ionizer generates an approximately equal proportional amount of positive and negative ions in the air.

SYSTEM

[AUTOMATIC AIR CONDITIONING]


< SYSTEM DESCRIPTION >

SYSTEM

FRONT AUTOMATIC AIR CONDITIONING SYSTEM

FRONT AUTOMATIC AIR CONDITIONING SYSTEM : System Diagram

INFOID:000000008179917



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

HAC

FRONT AUTOMATIC AIR CONDITIONING SYSTEM : System Description

INFOID:000000008179918

- Front automatic air conditioning system is controlled by each function of A/C auto amp., ECM, IPDM E/R and BCM.

Control by A/C auto amp.

- [HAC-17, "FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Air Flow Control"](#)
- [HAC-18, "FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Air Inlet Control"](#)

SYSTEM

[AUTOMATIC AIR CONDITIONING]

< SYSTEM DESCRIPTION >

- [HAC-18. "FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Air Outlet Control"](#)
- [HAC-19. "FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Compressor Control"](#)
- [HAC-20. "FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Door Control"](#)
- [HAC-22. "FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Temperature Control"](#)
- [HAC-16. "FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Intelligent Key Interlock Function"](#)
- Correction for input value of each sensor

Ambient sensor (setting temperature correction)

- A/C auto amp. controls passenger room temperature so that the optimum level always matches the temperature level that the passenger may feel. Correction is applied to the target temperature that is set using temperature control dial, according to ambient temperature detected by ambient sensor.

In-vehicle sensor [in-vehicle temperature (front side) correction]

- Passenger room temperature (front side) detected by in-vehicle sensor is corrected for each front air conditioning control (driver side and passenger side).

Intake sensor (intake temperature correction)

- A/C auto amp. performs correction to change recognition intake temperature of A/C auto amp. quickly when difference is large between recognition intake temperature and intake temperature detected by intake temperature sensor. The correction is performed to change recognition intake temperature slowly when difference is small.

Sunload sensor (sunload amount correction)

- Sunload amount detected by sunload sensor is corrected for each air conditioning control.
- A/C auto amp. performs correction to change recognition sunload amount of A/C auto amp. slowly when sunload amount changes quickly, for example when entering or exiting a tunnel.

Control by ECM

- Cooling fan control
Refer to [EC-49. "COOLING FAN CONTROL : System Description"](#).
- Air conditioning cut control
Refer to [EC-47. "AIR CONDITIONING CUT CONTROL : System Description"](#).

Control by IPDM E/R

- Relay control
Refer to [PCS-6. "RELAY CONTROL SYSTEM : System Description"](#).
- Cooling fan control
Refer to [EC-49. "COOLING FAN CONTROL : System Description"](#).

Control by BCM

- Relay control
Refer to [BCS-6. "BODY CONTROL SYSTEM : System Description"](#).
- Front A/C control (A/C and AV switch assembly) transmits the commands for front automatic air conditioning system operation to AV control unit via communication line, then AV control unit transmits the commands to A/C auto amp. via CAN communication. A/C auto amp. transmits each indication information to AV control unit via CAN communication. AV control unit displays each indication information that is received.

FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Intelligent Key Interlock Function

INFOID:000000008267003

DESCRIPTION

- Setting value of air conditioning system when ignition switch is previously OFF can be memorized for each Intelligent Key. Air conditioning system is automatically operated by the setting value.

NOTE:

- Setting value can be memorized for up to 3 Intelligent Keys.
- Interlock items are as per the following table.

SYSTEM

< SYSTEM DESCRIPTION >

[AUTOMATIC AIR CONDITIONING]

Operation	Conditions
A/C and AV switch assembly	AUTO switch (ON / OFF)
	Setting temperature (Setting value)
	Air flow (Setting value)
	Air inlet (FRE / REC)
	Air outlet (VENT / B/L / FOOT / D/F / DEF)
"Climate" menu screen	"A/C" (ON / OFF)
	"DUAL" (ON / OFF)

Operation Description

Memory

1. Unlock door using Intelligent Key or driver door request switch.
2. BCM transmits Key ID signal to A/C auto amp. via CAN communication line.
3. When ignition switch turns OFF, A/C auto amp. memorizes setting information (setting temperature, air inlet status, and others) of air conditioning system to memory for each Key ID.

Readout

1. Unlock door using Intelligent Key or driver door request switch.
2. BCM transmits Key ID signal to A/C auto amp. via CAN communication line.
3. When ignition switch turns ON, A/C auto amp. operates automatically air conditioning system according to setting information of Key ID that is received.

NOTE:

When Intelligent Key interlock function operates, "Connection with the key has been done." is displayed.

FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Air Flow Control

INFOID:000000008179919


HAC

DESCRIPTION

- A/C auto amp. changes duty ratio of blower motor drive signal and controls air flow continuously. When air flow is increased, duty ratio of front blower motor control signal gradually increases to prevent a sudden increase in air flow.
- In addition to manual control and automatic control, air flow control is consist of starting fan speed control, low coolant temperature starting control, high in-vehicle temperature starting control and fan speed control at door motor operation

AUTOMATIC AIR FLOW CONTROL

- A/C auto amp. decides target air flow depending on target air mix door (front) opening angle.
- A/C auto amp. changes duty ratio of front blower motor control signal and controls the air flow continuously so that air flow matches the target air flow.
- When air outlet is VENT or B/L, the minimum air flow is changed depending on sunload.




STARTING AIR FLOW CONTROL

SYSTEM

< SYSTEM DESCRIPTION >


[AUTOMATIC AIR CONDITIONING]

- When front blower motor is activated, A/C auto amp. gradually increases duty ratio of front blower motor control signal to prevent a sudden increase in discharge air flow.
- It takes approximately 8 seconds for air flow to reach HI from LOW.



LOW COOLANT TEMPERATURE STARTING CONTROL

If the engine coolant temperature is 56°C (133°F) or less, to prevent a cold discharged air flow, A/C auto amp. suspends front blower motor activation for the maximum 150 seconds depending on target air mix door (front) opening angle. After this, front blower motor control signal is increased gradually, and front blower motor is activated.



HIGH IN-VEHICLE TEMPERATURE STARTING CONTROL

When front evaporator fin temperature is high [intake sensor value is 35°C (95°F) or more], to prevent a hot discharged air flow, A/C auto amp. suspends front blower motor activation for approximately 3 seconds so that front evaporator is cooled by refrigerant.


FAN SPEED CONTROL AT DOOR MOTOR OPERATION

When mode door motor (front) is activated while air flow is more than the specified value, A/C auto amp. reduces fan speed temporarily so that mode door (front) moves smoothly.

FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Air Inlet Control

INFOID:000000008179920


The intake door is automatically controlled by the temperature setting, ambient temperature, in-vehicle temperature, intake temperature, amount of sunload and ON/OFF operation of the compressor. Intake door automatic control selects FRE, 20% FRE, or REC depending on a target air mix door (front) opening angle, based on in-vehicle temperature, ambient temperature, and sunload.



FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Air Outlet Control

INFOID:000000008179921

- While air outlet is in automatic control, A/C auto amp. selects the mode door (front) position depending on a target air mix door (front) angle and outlet air temperature calculated from sunload.
- If ambient temperature is excessively low, D/F is selected to prevent windshield fogging when air outlet is set to FOOT.



FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Compressor Control

INFOID:000000008179922

DESCRIPTION

- When the compressor activation condition is satisfied while blower motor is activated, A/C auto amp. transmits A/C ON signal and blower fan ON signal to ECM via CAN communication.
- ECM judges that the compressor can be activated depending on each sensors state (refrigerant pressure sensor signal and others) and transmits A/C compressor request signal to IPDM E/R via CAN communication.
- IPDM E/R turns A/C relay ON and activates the compressor depending on request from ECM.

COMPRESSOR PROTECTION CONTROL AT PRESSURE MALFUNCTION

When high-pressure side value that is detected by refrigerant pressure sensor is as per the following state, ECM requests IPDM E/R to turn A/C relay OFF and stops the compressor.


- 3.12 MPa (31.82 kg/cm², 452.4 psi) or more (When the engine speed is less than 1,500 rpm)
- 2.74 MPa (27.95 kg/cm², 397.3 psi) or more (When the engine speed is 1,500 rpm or more)
- 0.14 MPa (1.43 kg/cm², 20.3 psi) or less

COMPRESSOR OIL CIRCULATION CONTROL

When the engine starts while the engine coolant temperature is 56°C (133°F) or less, ECM activates the compressor for approximately 6 seconds and circulates the compressor lubricant once.

LOW TEMPERATURE PROTECTION CONTROL

- When intake sensor detects that front evaporator fin temperature is 2.5°C (37°F) or less, A/C auto amp. requests ECM to turn compressor OFF, and stops the compressor.
- When the front evaporator fin temperature returns to 5.0°C (41°F) or more, the compressor is activated.



OPERATING RATE CONTROL

When set temperature is other than fully cold or air outlet is “VENT”, “B/L” or “FOOT” A/C auto amp. controls the compressor activation depending on ambient temperature.

AIR CONDITIONING CUT CONTROL

When set engine is running is excessively high load condition, ECM requests IPDM E/R to turn A/C relay OFF, and stops the compressor. Refer to [EC-47, "AIR CONDITIONING CUT CONTROL : System Description"](#) for details.

SYSTEM


[AUTOMATIC AIR CONDITIONING]

< SYSTEM DESCRIPTION >

FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Door Control

INFOID:000000008219101


DOOR MOTOR CONTROL



AL11A0580GB

- LCU (Local Control Unit) is built into each door motor, and detects door position by PBR (Potentiometer Balance Resistor).
- A/C auto amp. communicates with each LCU via communication line and receives each door position feedback signal from each LCU.
- Each LCU controls each door to the appropriate position depending on the control signal from A/C auto amp.
- Each LCU transmits the signal of door movement completion to A/C auto amp., when the door movement is completed.

SWITCH AND THEIR CONTROL FUNCTION



JMI1A1778ZZ

SYSTEM

< SYSTEM DESCRIPTION >

[AUTOMATIC AIR CONDITIONING]

- | | | |
|---------------------|-------------------------|-------------------------|
| 1. Intake door | 2. Front blower motor | 3. In-cabin microfilter |
| 4. Front evaporator | 5. Air mix door (front) | 6. Front heater core |
| 7. Foot door | 8. Ventilator door | 9. Defroster door |
| 10. Max. cool door | | |
-
- | | | |
|------------|-------------------|-----------------|
| Fresh air | Recirculation air | Discharge air |
| Defroster | Center ventilator | Side ventilator |
| Front foot | Rear foot | |

Switch position		Door position							
		Mode door (front)				Intake door	Air mix door (front)		
		Ventilator door	Max. cool door	Defroster door	Foot door		(Driver side)	(Passenger side)	
AUTO switch		AUTO							
MODE switch			A	A	A	A	—	—	—
			B	B	A	B			
			C	C	B	B			
			C	B	B	B			
DEF switch			C	A	C	C			
Intake switch*							A		
Temperature control switch (Driver side)	DUAL switch: OFF	Full cold [18°C (60°F)]						A	
		18.5°C – 31.5°C (61°F – 89 °F)						AUTO	
		Full hot [32°C (90°F)]						B	
Temperature control switch (Driver side)	DUAL switch: ON	Full cold [18°C (60°F)]	—	—	—	—	—	A	—
		18.5°C – 31.5°C (61°F – 89 °F)						AUTO	
		Full hot [32°C (90°F)]						B	
Temperature control switch (Passenger side)	DUAL switch: ON	Full cold [18°C (60°F)]							A
		18.5°C – 31.5°C (61°F – 89 °F)							AUTO
		Full hot [32°C (90°F)]							B
ON-OFF switch		OFF	C	C	B	B	B		—

*: Inlet status is displayed by indicator during activating automatic control

AIR DISTRIBUTION

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

SYSTEM

< SYSTEM DESCRIPTION >


[AUTOMATIC AIR CONDITIONING]

Discharge air flow						
MODE/DEF set position	Condition	Air outlet/distribution				
		Ventilator		Foot		Defroster
		Center	Side	Front	Rear	
	DUAL switch: OFF	50%	50%	—		—
		26%	30%	30%	14%	—
		—	14%	40%	16.5%	29.5%
		—	14%	35%	16%	35%
		—	12%	—		88%

FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Temperature Control

INFOID:000000008179924

- When ignition switch is in the ON position, A/C auto amp. always automatically controls temperature regardless of front air conditioning operational state.
- A/C auto amp. calculates the target air mix door (front) opening angle depending on set temperature, in-vehicle temperature, ambient temperature, and sunload.
- Air mix door (front) is controlled depending on the comparison of current air mix door (front) opening angle and target air mix door (front) opening angle.
- Regardless of in-vehicle temperature, ambient temperature, and sunload, air mix door (front) is fixed at the fully cold position when set temperature is 18.0°C (60°F), and at the fully hot position when set temperature is 32.0°C (90°F).



FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Fail-safe

INFOID:000000008179926

FAIL-SAFE FUNCTION

If a communication error exists between the A/C auto amp., and the AV control unit and preset switch for 30 seconds or longer, air conditioning is controlled under the following conditions:

When ambient temperature is less than 3°C (37°F) and engine coolant temperature is less than 56°C (133°F)

- Compressor** : ON
- Air outlet** : DEF
- Air inlet** : FRE (Fresh air intake)
- Blower fan speed** : AUTO
- Set temperature** : Setting before communication error occurs

When ambient temperature is 3°C (37°F) or more, or engine coolant temperature is 56°C (133°F) or more

- Compressor** : ON
- Air outlet** : AUTO
- Air inlet** : 20% FRE (20% fresh air intake)
- Blower fan speed** : AUTO
- Set temperature** : Setting before communication error occurs

REAR AUTOMATIC AIR CONDITIONING SYSTEM


SYSTEM

[AUTOMATIC AIR CONDITIONING]

< SYSTEM DESCRIPTION >

REAR AUTOMATIC AIR CONDITIONING SYSTEM : System Diagram

INFOID:000000008179927



REAR AUTOMATIC AIR CONDITIONING SYSTEM : System Description

INFOID:000000008179928

- Rear automatic air conditioning system is controlled by each function of A/C auto amp.

Control by A/C auto amp.

- [HAC-24, "REAR AUTOMATIC AIR CONDITIONING SYSTEM : Air Flow Control"](#)
- [HAC-26, "REAR AUTOMATIC AIR CONDITIONING SYSTEM : Air Outlet Control"](#)
- [HAC-26, "REAR AUTOMATIC AIR CONDITIONING SYSTEM : Door Control"](#)
- [HAC-27, "REAR AUTOMATIC AIR CONDITIONING SYSTEM : Temperature Control"](#)
- [HAC-24, "REAR AUTOMATIC AIR CONDITIONING SYSTEM : Intelligent Key Interlock Function"](#)
- Correction for input value of each sensor

SYSTEM

[AUTOMATIC AIR CONDITIONING]

< SYSTEM DESCRIPTION >

Ambient sensor (setting temperature correction)

- A/C auto amp. controls passenger room temperature so that the optimum level always matches the temperature level that passenger may feel. Correction is applied to the target temperature that is set using temperature control dial, according to ambient temperature detected by ambient sensor.

Intake sensor (intake temperature correction)

- A/C auto amp. performs correction to change recognition intake temperature of A/C auto amp. quickly when difference is large between recognition intake temperature and intake temperature detected by intake temperature sensor. The correction is performed to change recognition intake temperature slowly when difference is small.

Sunload sensor (sunload amount correction)

- Sunload amount detected by sunload sensor is corrected for each rear automatic air conditioning control.
- A/C auto amp. performs correction to change recognition sunload amount of A/C auto amp. slowly when sunload amount changes quickly, for example when entering or exiting a tunnel.

Operation by front controller

- Front A/C control (A/C and AV switch assembly) transmits the commands for rear automatic air conditioning system operation to AV control unit via communication line, then AV control unit transmits the commands to A/C auto amp. via CAN communication. A/C auto amp. transmits each indication information to AV control unit via CAN communication. AV control unit displays each indication information that is received.

Operation by rear controller

- Rear air control transmits the commands for rear automatic air conditioning system operation to A/C auto amp. via communication line.

REAR AUTOMATIC AIR CONDITIONING SYSTEM : Intelligent Key Interlock Function

INFOID:000000008267004

DESCRIPTION

- Setting value of rear air conditioning system when ignition switch is previously OFF can be memorized for each Intelligent Key. Rear air conditioning system is automatically operated by the setting value.

NOTE:

Setting value can be memorized for up to 3 Intelligent Keys.

- Interlock items are as per the following table.

Operation	Conditions
A/C and AV switch assembly / Rear air control	AUTO switch (ON/OFF)
	Setting temperature (Setting value)
	Air flow (Setting value)
	Air outlet (VENT / FOOT)

Operation Description

Memory

1. Unlock door using Intelligent Key or driver door request switch.
2. BCM transmits Key ID signal to A/C auto amp. via CAN communication line.
3. When ignition switch turns OFF, A/C auto amp. memorizes setting information (setting temperature, air outlet status, and others) of rear air conditioning system to memory for each Key ID.

Readout

1. Unlock door using Intelligent Key or driver door request switch.
2. BCM transmits Key ID signal to A/C auto amp. via CAN communication line.
3. When ignition switch turns ON, A/C auto amp. operates automatically rear air conditioning system according to setting information of Key ID that is received.

NOTE:

When Intelligent Key interlock function operates, "Connection with the key has been done." is displayed.

REAR AUTOMATIC AIR CONDITIONING SYSTEM : Air Flow Control

INFOID:000000008179929

DESCRIPTION

SYSTEM


[AUTOMATIC AIR CONDITIONING]

< SYSTEM DESCRIPTION >

- A/C auto amp. changes duty ratio of rear blower motor drive signal and controls air flow continuously. When air flow is increased, duty ratio of rear blower motor control signal gradually increases to prevent a sudden increase in air flow.
- In addition to manual control and automatic control, air flow control is composed of starting fan speed control, low coolant temperature starting control, high in-vehicle temperature starting control and fan speed control at door motor operation


AUTOMATIC AIR FLOW CONTROL

- A/C auto amp. decides target air flow depending on target air mix door (rear) opening angle.
- A/C auto amp. changes duty ratio of rear blower motor control signal and controls the air flow continuously so that air flow matches to target air flow.
- When air outlet is VENT, the minimum air flow is changed depending on sunload.




STARTING AIR FLOW CONTROL

- When rear blower motor is activated, A/C auto amp. gradually increases duty ratio of rear blower motor control signal to prevent a sudden increase in discharge air flow.
- It takes approximately 8 seconds for air flow to reach HI from LOW.



LOW COOLANT TEMPERATURE STARTING CONTROL

If the engine coolant temperature is 56°C (133°F) or less, to prevent a cold discharged air flow, A/C auto amp. suspends rear blower motor activation for the maximum 150 seconds depending on target air mix door (rear) opening angle. After this, rear blower motor control signal is increased gradually, and rear blower motor is activated.



HIGH IN-VEHICLE TEMPERATURE STARTING CONTROL

When front evaporator fin temperature is high [intake sensor value is 35°C (95°F) or more], to prevent a hot discharged air flow, A/C auto amp. suspends rear blower motor activation for approximately 3 seconds so that rear evaporator is cooled by refrigerant.

FAN SPEED CONTROL AT DOOR MOTOR OPERATION

When mode door motor (rear) is activated while air flow is more than the specified value, A/C auto amp. reduces temporarily fan speed so that mode door (rear) moves smoothly.

SYSTEM


< SYSTEM DESCRIPTION >

[AUTOMATIC AIR CONDITIONING]

REAR AUTOMATIC AIR CONDITIONING SYSTEM : Air Outlet Control

INFOID:000000008179930


- While air outlet is in automatic control, A/C auto amp. selects the mode door (rear) position depending on a target air mix door (rear) angle and outlet air temperature calculated from sunload.



REAR AUTOMATIC AIR CONDITIONING SYSTEM : Door Control


INFOID:000000008179931

DOOR MOTOR CONTROL



- LCU (Local Control Unit) is built in to each door motor, and detects door position by PBR (Potentiometer Balance Resistor).
- A/C auto amp. communicates with each LCU via communication line and receives each door position feedback signal from each LCU.
- Each LCU controls each door to the appropriate position depending on the control signal from A/C auto amp. when the door movement is complete, transmits the signal of door movement completion to A/C auto amp.

SWITCHES AND THEIR CONTROL FUNCTION



SYSTEM

< SYSTEM DESCRIPTION >

[AUTOMATIC AIR CONDITIONING]

- | | | |
|-----------------------|------------------------|---------------------|
| 1. Rear shut-off door | 2. Rear blower motor 1 | 3. Mode door (rear) |
| 4. PTC heater | | |
| ← Recirculation air | ■ Rear ventilator | ● Rear A/C foot |


Switch/Dial position		Door position		
		Mode door (rear)	Rear shut-off door	
AUTO switch	Front A/C control	☀	AUTO	B
	Rear air control	AUTO		
	VENT	↶	C	—
	FOOT	↷	D	—
OFF switch			AUTO	A

AIR DISTRIBUTION

Discharge air flow		
Mode position	Air outlet/distribution	
	VENT	FOOT
↶	100%	—
↷	—	100%

REAR AUTOMATIC AIR CONDITIONING SYSTEM : Temperature Control INFOID:000000008179932

- When ignition switch is in the ON position, A/C auto amp. always automatically controls temperature regardless of rear air conditioning operational state.
- A/C auto amp. calculates the target air mix door (rear) opening angle depending on set temperature, ambient temperature, and sunload.
- Air mix door (rear) is controlled depending on the comparison of current air mix door (rear) opening angle and target air mix door (front) opening angle.
- Regardless of ambient temperature, and sunload, air mix door (rear) is fixed at the fully cold position when set temperature is 18.0°C (60°F), and at the fully hot position when set temperature is 32.0°C (90°F).



ACCS (ADVANCED CLIMATE CONTROL SYSTEM)


SYSTEM

< SYSTEM DESCRIPTION >

[AUTOMATIC AIR CONDITIONING]

ACCS (ADVANCED CLIMATE CONTROL SYSTEM) : System Diagram

INFOID:000000008179934



ACCS (ADVANCED CLIMATE CONTROL SYSTEM) : System Description

INFOID:000000008179935

- ACCS (advanced climate control system) controls passenger room air. It maintains the cleanliness of the passenger room air using an in-cabin microfilter and a combination of each of the following functions.
- [HAC-29. "ACCS \(ADVANCED CLIMATE CONTROL SYSTEM\) : Automatic Intake Control \(Exhaust Gas / Outside Odor Detecting Mechanism\)"](#)
- [HAC-29. "ACCS \(ADVANCED CLIMATE CONTROL SYSTEM\) : Plasmacluster Control"](#)

NOTE:

- Plasmacluster™ ion technology developed by Sharp Corporation is installed in this item.
- Plasmacluster™ is a trademark of Sharp Corporation.
- Various operations of ACCS (advanced climate control system) are transmitted from A/C and AV switch assembly to AV control unit via communication line and from AV control unit to A/C auto amp. via CAN communication. A/C auto amp. sends each indication information to AV control unit via CAN communication. AV control unit displays each indication information that is received.

ACCS (ADVANCED CLIMATE CONTROL SYSTEM) : Intelligent Key Interlock Function

INFOID:000000008267005

DESCRIPTION

- Setting value of ACCS (Advanced Climate Control System) when ignition switch is previously OFF can be memorized for each Intelligent Key. ACCS (Advanced Climate Control System) is automatically operated by the setting value.

NOTE:

- Setting value can be memorized for up to 3 Intelligent Keys.
- Interlock items are as per the following table.

Operation	Conditions
A/C and AV switch assembly	AUTO intake switch (ON/OFF)

Operation Description

SYSTEM

[AUTOMATIC AIR CONDITIONING]

< SYSTEM DESCRIPTION >

Memory

1. Unlock door using Intelligent Key or driver door request switch.
2. BCM transmits Key ID signal to A/C auto amp. via CAN communication line.
3. When ignition switch turns OFF, A/C auto amp. memorizes setting information (AUTO intake switch status) of ACCS (Advanced Climate Control System) to memory for each Key ID.

Readout

1. Unlock door using Intelligent Key or driver door request switch.
2. BCM transmits Key ID signal to A/C auto amp. via CAN communication line.
3. When ignition switch turns ON, A/C auto amp. operates automatically ACCS (Advanced Climate Control System) according to setting information of Key ID that is received.

NOTE:

When Intelligent Key interlock function operates, "Connection with the key has been done." is displayed.

ACCS (ADVANCED CLIMATE CONTROL SYSTEM) : Automatic Intake Control (Exhaust Gas / Outside Odor Detecting Mechanism)

INFOID:000000008179936

DESCRIPTION

In addition to air inlet automatic control of front automatic air conditioning system, A/C auto amp. controls automatically air inlet according to signal from exhaust gas / outside odor detecting sensor, so that unpleasant outside odor does not enter in passenger room.

OPERATION DESCRIPTION

- When pressing auto intake switch while front blower motor is operated and DEF switch is OFF, auto intake switch indicator lamp and intake switch indicator lamp turn ON. Air inlet is fixed to recirculation for approximately 5 minutes, and then is switched to automatic intake control (exhaust gas / outside odor detecting mechanism).
- Air inlet switches to recirculation when exhaust gas or outside odor is detected while automatic intake control (exhaust gas / outside odor detecting mechanism) is operated. After that, air inlet switches to fresh air intake when exhaust gas or outside odor becomes not detectable.

NOTE:

- Sensitivity of exhaust gas / outside odor detecting sensor can be changed by "GAS SENSOR ADJUSTMENT" in "WORK SUPPORT" mode of CONSULT. Refer to [HAC-80, "ACCS \(ADVANCED CLIMATE CONTROL SYSTEM\) : Exhaust Gas / Outside Odor Detecting Sensor Sensitivity Adjustment Function"](#).
- Automatic intake control (exhaust gas / outside odor detecting mechanism) does not operate when ambient temperature is -2°C (28°F) or less. In this case, control is only for control of automatic air inlet of automatic air conditioning system.

ACCS (ADVANCED CLIMATE CONTROL SYSTEM) : Plasmacluster Control

INFOID:000000008179937

DESCRIPTION

Plasmacluster™ control eliminates microbes and reduces odor on interior surface by including high density Plasmacluster™ ion in air conditioning outlet air flow.

OPERATION DESCRIPTION

- Plasmacluster™ control operates by interlocking to blower motor. Plasmacluster™ control operates when blower motor operates.
- Control status is displayed on front air conditioning system display screen. Refer to [HAC-34, "ACCS \(ADVANCED CLIMATE CONTROL SYSTEM\) : Switch Name and Function"](#).

NOTE:

- Plasmacluster™ ion technology developed by Sharp Corporation is installed in this item.
- Plasmacluster™ is a trademark of Sharp Corporation.

OPERATION

FRONT AUTOMATIC AIR CONDITIONING SYSTEM


FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Switch Name and Function

INFOID:000000008179940


A/C Display

- Front air conditioning system state is indicated on the display.
- When "STATUS" on the A/C and AV switch assembly is pressed while front air conditioning system is in the ON position, the display changes to state indication display of front air conditioning system. When front air conditioning system is operated while navigation system or audio system is displayed, front air conditioning system state is indicated in the lower portion of display for several seconds.
- When MODE switch is pressed while front air conditioning system is in the OFF position, state indication display is indicated for several seconds.

Display Screen



Controller (A/C and AV switch assembly)



- | | | |
|------------------|--|-------------------|
| 1. DEF switch | 2. Temperature control (Driver side) | 3. MODE switch |
| 4. DUAL switch | 5. Temperature control dial (passenger side) | 6. Climate switch |
| 7. Intake switch | 8. AUTO switch | 9. Fan switch |
| 10. OFF switch | | |

Switch Operation

OPERATION

< SYSTEM DESCRIPTION >

[AUTOMATIC AIR CONDITIONING]

AUTO switch	<p>Turns the switch indicator lamp and "AUTO" indicator on the display ON, and then front air conditioning system becomes the following state.</p> <ul style="list-style-type: none"> • Air inlet: Automatic control • Air outlet: Automatic control • Blower fan: Automatic control • Compressor: ON 	A
Climate switch	Turns the display unit to climate mode.	B
Defroster (DEF) switch	<p>Turns DEF mode (switch indicator) between ON ↔ OFF each time.</p> <p>When DEF switch is pressed while front air conditioning system is in the ON position.</p> <ul style="list-style-type: none"> • When DEF mode is turned ON, front air conditioning system becomes the following state. <ul style="list-style-type: none"> - Air inlet: Fresh air intake - Air outlet: DEF - Blower fan: Automatic control (If fan speed other than AUTO is selected before pressing DEF switch, fan speed is manual control.) - Compressor: ON • When DEF mode is turned OFF, front air conditioning system state returns to the previous state before DEF mode is selected. But, the following state is continued. <ul style="list-style-type: none"> - Air inlet: Fresh air intake - Compressor: ON <p>When DEF switch is pressed while front air conditioning system is in the OFF position.</p> <ul style="list-style-type: none"> • When DEF mode is turned ON, front air conditioning system becomes the following state. <ul style="list-style-type: none"> - Air inlet: Fresh air intake - Air outlet: DEF - Blower fan: Automatic control - Compressor: ON • When DEF mode is turned OFF, entire front air conditioning system is set to auto mode. <p>NOTE: When DEF mode turns ON while front air conditioning system is in automatic control ("AUTO" is indicated), automatic control is released ("AUTO" turns OFF).</p>	C D E F G
DUAL switch	<ul style="list-style-type: none"> • Turns left and right ventilation temperature separately control (switch indicator) between ON ↔ OFF each time. • When DUAL switch indicator is ON, the driver side and passenger side temperatures can each be set independently. • When DUAL switch indicator is OFF, the driver side outlet and setting temperature is applied to both sides. • Left and right ventilation temperature separately control is cancelled by turning the DEF mode ON. <p>NOTE: When front air conditioning system is in the OFF position, left and right ventilation temperature separately control can be selected only while front air conditioning system state (when MODE switch is pressed) is indicated on the display.</p>	H I J K
Fan switch (UP/DOWN)	<p>Blower fan speed is manually controlled with these switches. Seven speeds are available for manual control (as shown on the display screen).</p> <p>NOTE:</p> <ul style="list-style-type: none"> • When fan switch is pressed while front air conditioning system is in OFF, front air conditioning system is activated. (Compressor control state returns to the previous state before front air conditioning system OFF.) • When fan switch is pressed while front air conditioning system is in automatic control ("AUTO" is indicated), automatic control is released ("AUTO" turns OFF). 	L M N
MODE switch	<p>Selects air outlet sequentially from VENT ⇒ B/L ⇒ FOOT ⇒ D/F ⇒ VENT each time.</p> <p>NOTE:</p> <ul style="list-style-type: none"> • When front air conditioning system is in the OFF position, air outlet can be selected. • When MODE switch is pressed while front air conditioning system is in automatic control ("AUTO" is indicated), automatic control is released ("AUTO" turns OFF). 	O
OFF switch	<ul style="list-style-type: none"> • Turns front air conditioning system OFF. • When front air conditioning system turns OFF, air inlet and air outlet become the automatic control. 	P

HAC

OPERATION

[AUTOMATIC AIR CONDITIONING]

< SYSTEM DESCRIPTION >

Intake switch	<p>Air inlet changes between recirculation (REC) ↔ fresh air intake (FRE) each time this switch is pressed.</p> <ul style="list-style-type: none"> • Intake switch indicator ON: Recirculation • Intake switch indicator OFF: Fresh air intake <p>NOTE:</p> <ul style="list-style-type: none"> • When front air conditioning system is in the OFF position, air inlet can be selected. • When MODE switch and DEF switch is in the D/F or DEF position, air inlet cannot be selected to recirculation (REC).
Temperature control switch (Driver side)	<p>Setting temperature is selected using this switch within a range between 18°C (60°F) and 32°C (90°F) at a rate of 0.5°C (1.0°F) per adjustment.</p> <ul style="list-style-type: none"> • ▲ Press: Setting temperature increases • ▼ Press: Setting temperature decreases <p>NOTE:</p> <p>When air conditioning system is OFF, setting temperature can be selected only while air conditioning system status screen [only when MODE switch (driver side) is pressed] is indicated on display.</p>
Temperature control switch (Passenger side)	<ul style="list-style-type: none"> • The system is set to LH/RH independent status (“DUAL” displays) by operating this switch. Outlet air flow temperature of passenger side can be changed without changing outlet air flow temperature of driver side. • Setting temperature is selected using this switch within a range between 18°C (60°F) and 32°C (90°F) at a rate of 0.5°C (1.0°F) per adjustment. - ▲ Press: Setting temperature increases - ▼ Press: Setting temperature decreases <p>NOTE:</p> <ul style="list-style-type: none"> • When air conditioning system is OFF, setting temperature can be selected only while air conditioning system status screen [only when MODE switch (passenger side) is pressed] is indicated on display. • When DEF mode is ON, temperature control switch (passenger side) is inoperative.

REAR AUTOMATIC AIR CONDITIONING SYSTEM

REAR AUTOMATIC AIR CONDITIONING SYSTEM : Switch Name and Function


INFOID:000000008179941

FRONT CONTROLLER OPERATION

A/C Display

- Rear air conditioning system state is indicated on the display unit.
- When REAR switch is pressed while air conditioning system is in the ON position, the display unit changes to state indication display (rear control mode) of rear air conditioning system.

Display screen




Controller (A/C and AV switch assembly)

OPERATION

[AUTOMATIC AIR CONDITIONING]

< SYSTEM DESCRIPTION >



- | | | |
|----------------|--------------------------------------|----------------|
| 1. OFF switch | 2. Temperature control (Driver side) | 3. MODE switch |
| 4. REAR switch | 5. AUTO switch | 6. Fan switch |

Switch Operation

AUTO switch	<p>Turns the switch indicator lamp and "AUTO" indicator on the display unit ON, and then rear air conditioning system becomes the following state.</p> <ul style="list-style-type: none"> • Air outlet: Automatic control • Blower fan: Automatic control • Compressor: ON
Fan switch (UP/DOWN)	<p>Blower fan speed is manually controlled with these switches. Seven speeds are available for manual control (as shown on the display screen).</p> <p>NOTE: When fan switch is pressed while air conditioning system is in automatic control ("AUTO" is indicated), automatic control is released ("AUTO" turns OFF).</p>
MODE switch	<p>Selects air outlet sequentially from VENT ⇒ B/L ⇒ FOOT ⇒ VENT each time.</p> <p>NOTE: When MODE switch is pressed while air conditioning system is in automatic control ("AUTO" is indicated), automatic control is released ("AUTO" turns OFF).</p>
OFF switch	<ul style="list-style-type: none"> • Turns rear air conditioning system OFF. (When rear control mode is ON) • When rear air conditioning system turns OFF, air outlet become the automatic control.
REAR switch	<ul style="list-style-type: none"> • Turns the switch indicator lamp and rear control mode on the display unit ON, and then rear air conditioning system becomes the following state. - Air outlet: Automatic control - Blower fan: Automatic control - Compressor: ON • Rear control mode is released when switch is pressed again (rear air conditioning system operates continuously).
Temperature control switch (Driver side)	<p>Setting temperature is selected using this switch within a range between 18°C (60°F) and 32°C (90°F) at a rate of 0.5°C (1.0°F) per adjustment.</p> <ul style="list-style-type: none"> • ▲ Press: Setting temperature increases • ▼ Press: Setting temperature decreases <p>NOTE: When air conditioning system is OFF, setting temperature can be selected only while air conditioning system status screen [only when MODE switch (driver side) is pressed] is indicated on display.</p>


REAR CONTROLLER OPERATION

Controller (Rear Air Control)

OPERATION

< SYSTEM DESCRIPTION >

[AUTOMATIC AIR CONDITIONING]



- | | | |
|-------------------------------|----------------|------------|
| 1. OFF switch | 2. Fan switch | 3. Display |
| 4. Temperature control switch | 5. AUTO switch | |

AL11A0557ZZ

Switch Operation

AUTO switch	<p>Turns the switch indicator lamp and "AUTO" indicator on the display ON, and then rear air conditioning system becomes the following state.</p> <ul style="list-style-type: none"> • Air outlet: Automatic control • Blower fan: Automatic control • Compressor: ON
Fan switch (UP/DOWN)	<p>Blower fan speed is manually controlled with these switches. Seven speeds are available for manual control (as shown on the display screen).</p> <p>NOTE: When fan switch is pressed while air conditioning system is in automatic control ("AUTO" is indicated), automatic control is released ("AUTO" turns OFF).</p>
OFF switch	<ul style="list-style-type: none"> • Turns rear air conditioning system OFF. • When rear air conditioning system turns OFF, air outlet become the automatic control.
Temperature control switch	<p>Setting temperature is selected using this switch with in a range between 18.0°C (60°F) – 32.0°C (90°F) at a rate of 0.5°C (1°F) per adjustment.</p> <ul style="list-style-type: none"> • ▲: Press: Set temperature increases. • ▼: Press: Set temperature decreases.

ACCS (ADVANCED CLIMATE CONTROL SYSTEM)

ACCS (ADVANCED CLIMATE CONTROL SYSTEM) : Switch Name and Function

INFOID:000000008179942

OPERATION AND DISPLAY

Plasmacluster™ ion display

- Plasmacluster™ control state is indicated on the display unit.
- Plasmacluster™ ion display is switched as shown in the figure depending on air flow.

NOTE:


- Plasmacluster™ ion technology developed by Sharp Corporation is installed in this item.
- Plasmacluster™ is a trademark of Sharp Corporation.

OPERATION

[AUTOMATIC AIR CONDITIONING]


< SYSTEM DESCRIPTION >

- When air flow is small




A
B
C

- When air flow is large



D
E
F
G

Controller (A/C and AV switch assembly)



H
HAC

1. Auto switch

2. Intake switch

J
K
L
M
N
O
P

OPERATION

< SYSTEM DESCRIPTION >

[AUTOMATIC AIR CONDITIONING]

Switch name	Function
AUTO switch	<p>Turns the switch indicator lamp and "AUTO" indicator on the display ON, and then front air conditioning system becomes the following state.</p> <ul style="list-style-type: none">• Air inlet: Automatic control• Air outlet: Automatic control• Blower fan: Automatic control• Compressor: ON
Intake switch	<ul style="list-style-type: none">• Automatic intake control (exhaust gas / outside odor detecting mechanism) mode (switch indicator) changes between ON ⇔ OFF each time when auto intake switch is pressed while front blower motor is activated.• When auto intake switch turns ON, front air conditioning system becomes the following status.<ul style="list-style-type: none">- A/C switch: ON- Air inlet: Recirculation [After approximately 5 minutes, air inlet is switched to automatic intake control (exhaust gas / outside odor detecting mechanism).]• When auto intake switch turns ON ⇒ OFF, air inlet becomes the fresh air intake. <p>NOTE:</p> <ul style="list-style-type: none">• Interlocking condition of A/C switch can be changed. Refer to HAC-80, "ACCS (ADVANCED CLIMATE CONTROL SYSTEM) : Auto Intake Switch Interlocking Movement Change Function".• Auto intake switch does not turn ON during the following status.<ul style="list-style-type: none">- Air outlet: DEF- Ambient temperature: -2°C (28°F) or less

DIAGNOSIS SYSTEM (HVAC)

[AUTOMATIC AIR CONDITIONING]

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (HVAC)

Description

INFOID:000000008179943

Air conditioning system performs self-diagnosis, operation check, function diagnosis, and various settings using diagnosis function of each control unit.

ECU	Diagnostic item (CONSULT)	
A/C auto amp.	HVAC	Self Diagnostic Result
		Data Monitor
		Active Test
		Work support
AV control unit	MULTI AV	Self Diagnostic Result
	Multi AV system on board diagnosis function	
ECM	ENGINE	Self Diagnostic Result
		Data Monitor
IPDM E/R	IPDM E/R	Self Diagnostic Result
		Data Monitor
	Auto active test	

CONSULT Function

INFOID:000000008179944

CONSULT performs the following functions via CAN communication with A/C auto amp.

APPLICATION ITEMS

Diagnostic mode	Description
Self Diagnostic Result	Displays the diagnosis results judged by A/C auto amp.
Data Monitor	Displays the input/output signal of A/C auto amp.
Active Test	The signals used to activate each device are forcibly supplied from A/C auto amp.
Work support	Changes the setting for each setting function.
ECU identification	Displays the part number of A/C auto amp.

NOTE:

Diagnosis should be performed with engine running. Door motor operation speeds become slower and NO results may be returned even for normal operation if battery voltage drops below 12 V during self-diagnosis.

SELF-DIAGNOSIS RESULTS

Refer to [HAC-44, "DTC Index"](#).

ACTIVE TEST

Test item	Description
HVAC TEST	The operation check of air conditioning system can be performed by selecting the mode. Refer to the following table for the conditions of each mode.

Check each output device

	Test item						
	MODE 1	MODE 2	MODE 3	MODE 4	MODE 5	MODE 6	MODE 7
Mode door motor (front) position	VENT	VENT	B/L	D/F	D/F	DEF	DEF
Intake door motor position	REC	REC	20% FRE	FRE	FRE	FRE	FRE

DIAGNOSIS SYSTEM (HVAC)

[AUTOMATIC AIR CONDITIONING]

< SYSTEM DESCRIPTION >

	Test item						
	MODE 1	MODE 2	MODE 3	MODE 4	MODE 5	MODE 6	MODE 7
Air mix door motor (driver side) position	FULL COLD	FULL COLD	FULL COLD	FULL HOT	FULL HOT	FULL HOT	FULL HOT
Air mix door motor (passenger side) position	FULL COLD	FULL COLD	FULL COLD	FULL HOT	FULL HOT	FULL HOT	FULL HOT
Front blower motor control signal duty ratio	30%	30%	60%	HI	HI	60%	HI
Magnet clutch	ON	ON	ON	OFF	OFF	ON	ON
Mode door motor (rear) position	VENT	VENT	FOOT	FOOT	FOOT	FOOT	FOOT
Air mix door motor (rear) position	FULL COLD	FULL COLD	FULL COLD	FULL HOT	FULL HOT	FULL HOT	FULL HOT
Rear shut-off door motor position	FR / INT CLOSE	FR / INT CLOSE	FR / INT CLOSE	FR / INT CLOSE	FR / INT OPEN	FR / INT OPEN	FR / INT OPEN
PTC heater 1	OFF	ON	ON	ON	ON	OFF	ON
PTC heater 2	OFF	OFF	OFF	ON	ON	OFF	ON
Rear blower motor 1 control signal	3V	3V	7V	HI	HI	7V	3V
Rear blower motor 2 control signal	3V	3V	7V	HI	HI	7V	3V
Ionizer*	ON	ON	OFF	ON	ON	OFF	OFF
Display unit (Ion mode)*	CLEAN	CLEAN	OFF	QUICK CLEAN	QUICK CLEAN	OFF	OFF

*: With ACCS (advanced climate control system)

NOTE:

Perform the inspection of each output device after starting the engine because the compressor is operated.

DATA MONITOR

Display item list

Monitor item [Unit]	Description
AMB TEMP SEN [°C (°F)]	Ambient sensor value converted from ambient sensor signal received from ambient sensor.
IN-VEH TEMP [°C (°F)]	In-vehicle sensor value converted from in-vehicle sensor signal received from in-vehicle sensor.
INT TEMP SEN [°C (°F)]	Intake sensor value converted from intake sensor signal received from intake sensor.
SUNLOAD SEN [w/m ²]	Sunload sensor value converted from sunload sensor signal received from sunload sensor.
AMB SEN CAL [°C (°F)]	Ambient temperature value calculated by A/C auto amp.
IN-VEH CAL [°C (°F)]	In-vehicle temperature value calculated by A/C auto amp.
INT TEMP CAL [°C (°F)]	Front evaporator fin temperature value calculated by A/C auto amp.
SUNL SEN CAL [w/m ²]	Sunload value calculated by A/C auto amp.
COMP REQ SIG [On/Off]	Displays A/C switch ON/OFF status transmitted to other units via CAN communication.
FAN REQ SIG [On/Off]	Displays front blower motor ON/OFF status transmitted to other units via CAN communication.
FAN DUTY	Duty ratio of front blower motor judged by A/C auto amp.
XM	Target discharge front air temperature (driver side) judged by A/C auto amp. depending on the temperature setting and the value from each sensor.
RR XM	Target discharge rear air temperature judged by A/C auto amp. depending on the temperature setting and the value from each sensor.
PA TARGET A/TEMP	Target discharge front air temperature (passenger side) judged by A/C auto amp. depending on the temperature setting and the value from each sensor.

DIAGNOSIS SYSTEM (HVAC)

[AUTOMATIC AIR CONDITIONING]

< SYSTEM DESCRIPTION >

Monitor item [Unit]	Description
RRFAN REQ SIG [On/Off]	Displays rear blower motor ON/OFF status transmitted to other units via CAN communication.
RR FAN DUTY	Duty ratio of rear blower motor judged by A/C auto amp.
ENG COOL TEMP [°C (°F)]	Engine coolant temperature signal value received from ECM via CAN communication.
VEHICLE SPEED [km/h (mph)]	Vehicle speed signal value received from combination meter via CAN communication.
GAS SENSOR DETECTION LEVEL	Displays value according to contamination of ambient air.
XM TRI ZONE	Target discharge tri zone air temperature judged by A/C auto amp. depending on the temperature setting and the value from each sensor.
BOOSTER FAN REQUEST SIG [On/Off]	Displays rear blower motor ON/OFF status transmitted to other units via CAN communication.
BOOSTER FAN DUTY	Duty ratio of rear blower motor judged by A/C auto amp.

WORK SUPPORT

Work item	Description	Refer to
REAR TEMP SET CORRECT	Setting change of temperature setting trimmer (rear) can be performed.	HAC-78. "FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Temperature Setting Trimmer (Front)"
TEMP SET CORRECT	Setting change of temperature setting trimmer (front) can be performed.	HAC-78. "FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Temperature Setting Trimmer (Front)"
REC MEMORY SET	Setting change of inlet port memory function (REC) can be performed.	HAC-79. "FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Inlet Port Memory Function (REC)"
FRE MEMORY SET	Setting change of inlet port memory function (FRE) can be performed.	HAC-79. "FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Inlet Port Memory Function (FRE)"
BLOW SET	Setting change of foot position setting trimmer can be performed.	HAC-78. "FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Foot Position Setting Trimmer"
GAS SENSOR ADJUSTMENT*	Setting change of exhaust gas / outside odor detecting sensor sensitivity adjustment function can be performed.	HAC-80. "ACCS (ADVANCED CLIMATE CONTROL SYSTEM) : Exhaust Gas / Outside Odor Detecting Sensor Sensitivity Adjustment Function"
CLEAN SW SET*	Setting change of auto intake switch interlocking movement change function can be performed.	HAC-80. "ACCS (ADVANCED CLIMATE CONTROL SYSTEM) : Auto Intake Switch Interlocking Movement Change Function"

*: With ACCS (advanced climate control system)

NOTE:

When the battery cable is disconnected from the negative terminal or when the battery voltage becomes 10 V or less, the setting of WORK SUPPORT may be cancelled.

A/C AUTO AMP.

< ECU DIAGNOSIS INFORMATION >

[AUTOMATIC AIR CONDITIONING]

ECU DIAGNOSIS INFORMATION

A/C AUTO AMP.

Reference Value

INFOID:000000008179945

VALUES ON THE DIAGNOSIS TOOL

Monitor item	Condition		Value/Status
AMB TEMP SEN	Ignition switch ON	—	Equivalent to ambient temperature
IN-VEH TEMP	Ignition switch ON	—	Equivalent to in-vehicle temperature (front side)
INT TEMP SEN	Ignition switch ON	—	Equivalent to front evaporator fin temperature
SUNLOAD SEN	Ignition switch ON	—	Equivalent to sunload (driver side)
AMB SEN CAL	Ignition switch ON	—	Equivalent to ambient temperature
IN-VEH CAL	Ignition switch ON	—	Equivalent to in-vehicle temperature (front side)
INT TEMP CAL	Ignition switch ON	—	Equivalent to front evaporator fin temperature
SUNL SEN CAL	Ignition switch ON	—	Equivalent to sunload (driver side)
COMP REQ SIG	Engine: Run at idle after warming up	A/C switch: ON (Compressor operation status)	On
		A/C switch: OFF	Off
FAN REQ SIG	Engine: Run at idle after warming up	Front blower motor: ON	On
		Front blower motor: OFF	Off
FAN DUTY	Engine: Run at idle after warming up	Front blower motor: ON	25 – 81
		Front blower motor: OFF	0
XM	Ignition switch ON	—	Value according to target air flow temperature (driver side)
RR XM	Ignition switch ON	—	Value according to target air flow temperature (rear side)
PA TARGET A/TEMP	Ignition switch ON	—	Value according to target air flow temperature (passenger side)
RRFAN REQ SIG	Engine: Run at idle after warming up	Rear blower motor: ON	On
		Rear blower motor: OFF	Off
RR FAN DUTY	Engine: Run at idle after warming up	Rear blower motor: ON	25 – 81
		Rear blower motor: OFF	0
ENG COOL TEMP	Ignition switch ON	—	Equivalent to engine coolant temperature
VEHICLE SPEED	Driving	—	Equivalent to speedometer reading
GAS SENSOR DETECTION LEVEL	Ignition switch ON	—	Value according to contamination of ambient air
XM TRIZONE	Ignition switch ON	—	Value according to target air flow temperature (rear side)


A/C AUTO AMP.

< ECU DIAGNOSIS INFORMATION >

[AUTOMATIC AIR CONDITIONING]

Monitor item	Condition		Value/Status
BOOSTER FAN REQUEST SIGNAL	Engine: Run at idle after warming up	Rear blower motor: ON	On
		Rear blower motor: OFF	Off
BOOSTER FAN DUTY	Engine: Run at idle after warming up	Rear blower motor: ON	25 – 81
		Rear blower motor: OFF	0

TERMINAL LAYOUT





PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
1 (L)	—	CAN-H	Input/ Output	—	—
2 (GR)	—	Ground	—	—	—
3 (G)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
5 (G)	Ground	Communication signal (A/C auto amp. → Rear air control)	Output	Ignition switch ON	
7 (G)	Ground	Ambient sensor signal	Input	Ignition switch ON	0 – 4.8 V Output voltage varies with ambient temperature
8*2 (G)	Ground	Heated steering wheel switch signal	Input	Ignition switch ON	0 V
				Other than the above	12 V
9 (W)	Ground	Sunload sensor signal	Input	Ignition switch ON	0 – 4.8 V Output voltage varies with sunload amount
10 (SB)	Ground	Drive mode select switch (SNOW) signal	Input	• Ignition switch ON • Drive mode select switch position: SNOW	0 V
				Other than the above	12 V

A/C AUTO AMP.

< ECU DIAGNOSIS INFORMATION >



[AUTOMATIC AIR CONDITIONING]

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
11 (G)	Ground	Drive mode select switch (STANDARD) signal	Input	<ul style="list-style-type: none"> • Ignition switch ON • Drive mode select switch position: STANDARD 		0 V
				Other than the above		12 V
12 (G)	Ground	Fan control amp. control signal	Output	<ul style="list-style-type: none"> • Ignition switch ON • Blower speed: OFF 		0 V
				<ul style="list-style-type: none"> • Ignition switch ON • Blower speed: 1st - 23rd 		2.5 - 3.5 V
				<ul style="list-style-type: none"> • Ignition switch ON • Blower speed: 24th - 25th 		10 V
13 (W)	Ground	IGN 2	Input	Ignition switch ON		Battery voltage
14 (W)	Ground	Fan control amp. control signal	Output	<ul style="list-style-type: none"> • Ignition switch ON • Blower speed: OFF 		0 V
				<ul style="list-style-type: none"> • Ignition switch ON • Blower speed: 1st - 23rd 		2.5 - 3.5 V
				<ul style="list-style-type: none"> • Ignition switch ON • Blower speed: 24th - 25th 		10 V
16 (Y)	Ground	Each door motor LIN signal	Input/ Output	Ignition switch ON		 <small>SJ1A1453J</small>
17 (LG)	Ground	Each door motor power supply	Output	Ignition switch ON		12 V
18 (W)	Ground	Front blower motor control signal	Output	<ul style="list-style-type: none"> • Ignition switch ON • Front fan speed: 1st speed (manual) 		 <small>JS1IA0096ZZ</small>
19 (W)	Ground	PTC1 relay output signal	Input	Ignition switch ON	PTC heater: ON	0 V
					PTC heater: OFF	12 V
20*2 (BR)	Ground	Heated steering wheel relay control signal	Output	Ignition switch ON	Within 30 seconds after turning ON the heated steering switch.	0 V
					Other than the above	12 V
21 (P)	—	CAN-L	Input/ Output	—		—

A/C AUTO AMP.

< ECU DIAGNOSIS INFORMATION >

[AUTOMATIC AIR CONDITIONING]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
22 (GR)	—	Ground	—	—	—
23 (LG)	Ground	Ignition power supply	Input	Ignition switch ON	Battery voltage
25 (W)	Ground	Communication signal (Rear air control→A/C auto amp.)	Input	Ignition switch ON	 <p style="text-align: right; font-size: small;">SJIA1522J</p>
26 (G)	—	Sensor ground	—	—	—
27 (W)	Ground	In-vehicle sensor signal	Input	Ignition switch ON	0 – 4.8 V Output voltage varies with in-vehicle temperature
28 (W)	Ground	Intake sensor signal	Input	Ignition switch ON	0 – 4.8 V Output voltage varies with front evaporator fin temperature
29 (P)	Ground	Drive mode select switch (ECO) signal	Input	<ul style="list-style-type: none"> • Ignition switch ON • Drive mode select switch position: ECO 	0 V
				Other than the above	12 V
30*1 (R)	Ground	Exhaust gas / outside odor detecting sensor signal	Input	Ignition switch ON NOTE: The signal is depending on measurement environment of the vehicle	 <p style="text-align: right; font-size: small;">JMIA2115GB</p>
31 (BG)	Ground	Drive mode select switch (SPORT) signal	Input	<ul style="list-style-type: none"> • Ignition switch ON • Drive mode select switch position: SPORT 	0 V
				Other than the above	12 V
32 (L)	Ground	Blower motor feedback	Input	<ul style="list-style-type: none"> • Ignition switch ON • Blower speed: OFF 	Battery voltage
				<ul style="list-style-type: none"> • Ignition switch ON • Blower speed: 1st 	10 V
				<ul style="list-style-type: none"> • Ignition switch ON • Blower speed: 25th 	0 V
34 (L)	Ground	Blower motor feedback	Input	<ul style="list-style-type: none"> • Ignition switch ON • Blower speed: OFF 	Battery voltage
				<ul style="list-style-type: none"> • Ignition switch ON • Blower speed: 1st 	10 V
				<ul style="list-style-type: none"> • Ignition switch ON • Blower speed: 25th 	0 V
37 (BR)	—	Ground	—	—	—

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

A/C AUTO AMP.

< ECU DIAGNOSIS INFORMATION >

[AUTOMATIC AIR CONDITIONING]

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
38*1 (P)	Ground	Ionizer (ON/OFF) control signal	Output	Ignition switch ON	Front blower motor: ON	0 V
					Front blower motor: OFF	12 V
39 (L)	Ground	PTC2 relay output signal	Input	Ignition switch ON	PTC heater: ON	0 V
					PTC heater: OFF	12 V

*1: With ACCS (advanced climate control system)

*2: With heated steering wheel

Fail-safe

INFOID:000000008179946

FAIL-SAFE FUNCTION

If a communication error exists between the A/C auto amp., and the AV control unit and preset switch for 30 seconds or longer, air conditioning is controlled under the following conditions:

When ambient temperature is less than 3°C (37°F) and engine coolant temperature is less than 56°C (133°F)

Compressor : ON
Air outlet : DEF
Air inlet : FRE (Fresh air intake)
Blower fan speed : AUTO
Set temperature : Setting before communication error occurs

When ambient temperature is 3°C (37°F) or more, or engine coolant temperature is 56°C (133°F) or more

Compressor : ON
Air outlet : AUTO
Air inlet : 20% FRE (20% fresh air intake)
Blower fan speed : AUTO
Set temperature : Setting before communication error occurs

DTC Index

INFOID:000000008179947

DTC	Items (CONSULT screen terms)	Reference
U1000	CAN COMM CIRCUIT	HAC-82, "DTC Logic"
U1010	CONTROL UNIT (CAN)	HAC-83, "DTC Logic"
B2578	IN-VEHICLE SENSOR	HAC-84, "DTC Logic"
B2579	IN-VEHICLE SENSOR	HAC-84, "DTC Logic"
B257B	AMBIENT SENSOR	HAC-87, "DTC Logic"
B257C	AMBIENT SENSOR	HAC-87, "DTC Logic"
B2581	INTAKE SENSOR	HAC-90, "DTC Logic"
B2582	INTAKE SENSOR	HAC-90, "DTC Logic"
B262A*1	GAS SENSOR	HAC-93, "DTC Logic"
B262B*1	GAS SENSOR	HAC-93, "DTC Logic"
B2630*2	SUNLOAD SENSOR	HAC-96, "DTC Logic"
B2631*2	SUNLOAD SENSOR	HAC-96, "DTC Logic"

A/C AUTO AMP.

< ECU DIAGNOSIS INFORMATION >

[AUTOMATIC AIR CONDITIONING]

DTC	Items (CONSULT screen terms)	Reference
B2632	DR AIR MIX DOOR MOT	HAC-99. "DTC Logic"
B2633	DR AIR MIX DOOR MOT	HAC-99. "DTC Logic"
B2634	PASS AIR MIX DOOR MOT	HAC-101. "DTC Logic"
B2635	PASS AIR MIX DOOR MOT	HAC-101. "DTC Logic"
B2636	DR VENT DOOR FAIL	HAC-103. "DTC Logic"
B2637	DR B/L DOOR FAIL	HAC-103. "DTC Logic"
B2638	DR D/F1 DOOR FAIL	HAC-103. "DTC Logic"
B2639	DR DEF DOOR FAIL	HAC-103. "DTC Logic"
B263D	FRE DOOR FAIL	HAC-105. "DTC Logic"
B263E	20P FRE DOOR FAIL	HAC-105. "DTC Logic"
B263F	REC DOOR FAIL	HAC-105. "DTC Logic"
B2654	D/F2 DOOR FAIL	HAC-103. "DTC Logic"
B2657 ^{*1}	GAS SENSOR CIRCUIT	HAC-93. "DTC Logic"
B2658 ^{*1}	GAS SENSOR CIRCUIT	HAC-93. "DTC Logic"
B2796	COMMUNICATION ERROR	HAC-107. "DTC Logic"
B2797	COMMUNICATION ERROR	HAC-107. "DTC Logic"
B2798	COMMUNICATION ERROR	HAC-107. "DTC Logic"
B2799	REAR AIR MIX DOOR MOT	HAC-107. "DTC Logic"
B279A	REAR AIR MIX DOOR MOT	HAC-107. "DTC Logic"
B279B	REAR MODE DOOR MOT	HAC-109. "DTC Logic"
B279C	REAR MODE DOOR MOT	HAC-109. "DTC Logic"
B279D	REAR SHUT-OFF DOOR MOT	HAC-109. "DTC Logic"
B279E	REAR SHUT-OFF DOOR MOT	HAC-109. "DTC Logic"
B27B0	A/C AUTO AMP.	HAC-115. "DTC Logic"

*1: With ACCS (advanced climate control system)

*2: Perform self-diagnosis under sunshine. When performing indoors, aim a light (more than 60 W) at sunload sensor, otherwise self-diagnosis indicates even though the sunload sensor is functioning normally.

NOTE:

If all of door motor DTCs (B2632, B2633, B2634, B2635, B2636, B2637, B2638, B2639, B263D, B263E, B263F, B2654, B2799, B279A, B279B, B279C, B279D, and B279E) are detected, check door motor communication circuit. Refer to [HAC-127. "Diagnosis Procedure"](#).

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

ECM, IPDM E/R, BCM

< ECU DIAGNOSIS INFORMATION >

[AUTOMATIC AIR CONDITIONING]

ECM, IPDM E/R, BCM

List of ECU Reference

INFOID:000000008179948

ECU	Reference
ECM	EC-90, "Reference Value"
	EC-90, "Reference Value"
	EC-106, "DTC Inspection Priority Chart"
	EC-108, "DTC Index"
IPDM E/R	PCS-12, "Reference Value"
	PCS-18, "Fail Safe"
	PCS-19, "DTC Index"
BCM	BCS-27, "Reference Value"
	BCS-47, "Fail Safe"
	BCS-47, "DTC Inspection Priority Chart"
	BCS-49, "DTC Index"

AUTOMATIC AIR CONDITIONING SYSTEM

[AUTOMATIC AIR CONDITIONING]


< WIRING DIAGRAM >

WIRING DIAGRAM

AUTOMATIC AIR CONDITIONING SYSTEM

Wiring Diagram

INFOID:000000007884328




ABIWA0241GB

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

AUTOMATIC AIR CONDITIONING SYSTEM

[AUTOMATIC AIR CONDITIONING]

< WIRING DIAGRAM >




ABIWA0242GB

AUTOMATIC AIR CONDITIONING SYSTEM

[AUTOMATIC AIR CONDITIONING]

< WIRING DIAGRAM >




A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

AUTOMATIC AIR CONDITIONING SYSTEM

[AUTOMATIC AIR CONDITIONING]

< WIRING DIAGRAM >

- <BV> : WITH BOSE AUDIO SYSTEM - WITHOUT SURROUND SOUND SYSTEM
- <BZ> : WITH BOSE AUDIO SYSTEM - WITH SURROUND SOUND SYSTEM
- <OB> : WITHOUT BOSE AUDIO SYSTEM
- <WB> : WITH BOSE AUDIO SYSTEM



ABIWA0244GB


AUTOMATIC AIR CONDITIONING SYSTEM

[AUTOMATIC AIR CONDITIONING]

< WIRING DIAGRAM >

AIR CONDITIONER CONTROL CONNECTORS

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3N	L	-
8N	L	-

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7P	LG	-
16P	W	-

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	Y	-
2	BR	-
3	LG	-

Connector No.	M8
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	V	-

Connector No.	M12
Connector Name	REAR SHUT-OFF DOOR MOTOR
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	LG	-
2	Y	-
3	BR	-

Connector No.	M13
Connector Name	MODE DOOR MOTOR (REAR)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	LG	-
2	Y	-
3	BR	-

AB11A0869GB

A B C D E F G H HAC J K L M N O P


AUTOMATIC AIR CONDITIONING SYSTEM

< WIRING DIAGRAM >


[AUTOMATIC AIR CONDITIONING]

Terminal No.	Color of Wire	Signal Name
3G	P	-
8G	G	-
11G	R	-
12G	G	-
13G	G	-
21G	R	-
35G	P	-
36G	L	-
37G	L	-
38G	W	-
50G	L	-
63G	P	-
94G	O	-

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
59	P	CAN-L
60	L	CAN-H
66	W	BLOWER FAN RELAY OUT
70	P	IGN USM OUT1

AB11A0870GB

AUTOMATIC AIR CONDITIONING SYSTEM

< WIRING DIAGRAM >

[AUTOMATIC AIR CONDITIONING]


Connector No.	M41
Connector Name	JOINT CONNECTOR-M18
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

Terminal No.	Color of Wire	Signal Name
89A	L	-
90A	P	-

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M45
Connector Name	AV CONTROL UNIT (BASE AUDIO SYSTEM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
61	B	DISP IT
72	SHIELD	SHIELD
73	W	IT DISP

Connector No.	M43
Connector Name	JOINT CONNECTOR-M17
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

Connector No.	M42
Connector Name	AV CONTROL UNIT (BASE AUDIO SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
11	L	CAN-H
12	P	CAN-L
13	SB	M-CAN1 H
14	LG	M-CAN1 L

AB1IA0871GB

A B C D E F G H HAC J K L M N O P

AUTOMATIC AIR CONDITIONING SYSTEM

< WIRING DIAGRAM >

[AUTOMATIC AIR CONDITIONING]

Connector No.	M50
Connector Name	A/C AUTO AMP.
Connector Color	WHITE



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

Terminal No.	Color of Wire	Signal Name
1	L	CAN-H
2	GR	GND
3	G	BATT
4	-	-
5	G	TX RR
6	-	-
7	G	AMB SENS

Connector No.	M64
Connector Name	WIRE TO WIRE
Connector Color	WHITE



7	6	5	4	3	2	1		
16	15	14	13	12	11	10	9	8

Terminal No.	Color of Wire	Signal Name
3	B	-

Terminal No.	Color of Wire	Signal Name
8	G	STRG HTR SW
9	W	SUN SENS
10	SB	MODE1
11	G	MODE3
12	G	FAN OUT (COOLER)
13	W	IGN2
14	W	FAN OUT (BOOSTER)
15	-	-
16	Y	ACTR (LIN)
17	LG	VACTR
18	W	FR FAN PWM
19	W	PTC1
20	BR	STRG HTR RLY
21	P	CAN-L
22	GR	GND (POWER)
23	LG	IGN
24	-	-

Connector No.	M65
Connector Name	WIRE TO WIRE
Connector Color	WHITE



16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
32	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17

Terminal No.	Color of Wire	Signal Name
17	SB	-
18	P	-
19	G	-
20	BG	-
25	G	-
26	W	-
27	LG	-

Terminal No.	Color of Wire	Signal Name
25	W	RX RR
26	G	SENS GND
27	W	INC SENS
28	W	INT SENS
29	P	MODE2
30	R	GAS SENS
31	BG	MODE4
32	L	FAN F/B (COOLER)
33	-	-
34	L	FAN F/B (BOOSTER)
35	-	-
36	-	-
37	BR	ACTR GND
38	P	ION ON/OFF
39	L	PTC2
40	-	-

Connector No.	M68
Connector Name	FUSE BLOCK (J/B)
Connector Color	BROWN



7R	6R	5R	4R	3R	2R	1R		
16R	15R	14R	13R	12R	11R	10R	9R	8R

Terminal No.	Color of Wire	Signal Name
3R	G	-
13R	GR	-

AUTOMATIC AIR CONDITIONING SYSTEM

[AUTOMATIC AIR CONDITIONING]

< WIRING DIAGRAM >

Connector No.	M75
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	G	-
3	W	-

Connector No.	M80
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
113	L	ACC RELAY OUT

Connector No.	M84
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
13	G	-
17	L	-
18	P	-

Connector No.	M92
Connector Name	DISPLAY UNIT (EXCEPT BASE AUDIO SYSTEM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
9	B	FRONT DISP IT
10	W	IT FRONT DISP
22	SHIELD	SHIELD

Connector No.	M93
Connector Name	DISPLAY UNIT (BASE AUDIO SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
11	W	UART IN
22	B	UART OUT
23	SHIELD	UART GND

Connector No.	M98
Connector Name	A/C AND AV SWITCH ASSEMBLY
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	GR	-
3	P	-
6	SB	-
8	LG	-

AB11A0873GB

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

AUTOMATIC AIR CONDITIONING SYSTEM

[AUTOMATIC AIR CONDITIONING]

< WIRING DIAGRAM >

Connector No.	M103
Connector Name	INTAKE SENSOR
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	-
2	G	-

Connector No.	M102
Connector Name	IN-VEHICLE SENSOR
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	-
2	G	-

Connector No.	M101
Connector Name	SUNLOAD SENSOR
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W	-
2	G	-

Connector No.	M108
Connector Name	REAR BLOWER MOTOR RELAY
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	W	-
2	GR	-
3	O	-
5	W	-
6	G	-
7	V	-

Connector No.	M107
Connector Name	REAR BLOWER MOTOR 1
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	-
2	L	-

Connector No.	M104
Connector Name	REAR BLOWER MOTOR RESISTOR 1
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	W	-
3	B	-


ABIIA0874GB

AUTOMATIC AIR CONDITIONING SYSTEM

< WIRING DIAGRAM >

[AUTOMATIC AIR CONDITIONING]

Connector No.	M118
Connector Name	PTC HEATER
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	W	-
3	G	-

Connector No.	M117
Connector Name	PTC HEATER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	GR	-
4	B	-

Connector No.	M112
Connector Name	FRONT BLOWER MOTOR
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	GR	-
3	W	-
4	L	-

Connector No.	M127
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	GR	-
2	GR	-
3	GR	-

Connector No.	M124
Connector Name	AV CONTROL UNIT (BOSE AUDIO SYSTEM - WITHOUT SURROUND SOUND SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
61	W	IT DISP
62	P	CAN-L
63	LG	M-CAN L
76	SHIELD	DISP SHIELD
77	B	DISP IT
78	L	CAN-H
79	SB	M-CAN H

Connector No.	M119
Connector Name	IONIZER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	LG	-
3	B	-
4	P	-

AB11A0875GB


A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

AUTOMATIC AIR CONDITIONING SYSTEM

< WIRING DIAGRAM >


[AUTOMATIC AIR CONDITIONING]

Connector No.	M130
Connector Name	AIR MIX DOOR MOTOR DRIVER SIDE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	GR	-
2	GR	-
3	GR	-

Connector No.	M129
Connector Name	MODE DOOR MOTOR (FRONT)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	GR	-
2	GR	-
3	GR	-

Connector No.	M128
Connector Name	INTAKE DOOR MOTOR
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	GR	-
2	GR	-
3	GR	-

Connector No.	M157
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
13	L	-

Connector No.	M132
Connector Name	AIR MIX DOOR MOTOR (REAR)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	GR	-
2	GR	-
3	GR	-

Connector No.	M131
Connector Name	AIR MIX DOOR MOTOR PASSENGER SIDE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	GR	-
2	GR	-
3	GR	-

ABIIA0876GB

AUTOMATIC AIR CONDITIONING SYSTEM

[AUTOMATIC AIR CONDITIONING]


< WIRING DIAGRAM >

Connector No.	M176
Connector Name	JOINT CONNECTOR-M56
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	SB	-
2	SB	-

Connector No.	M170
Connector Name	JOINT CONNECTOR-M09
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
12	G	-
14	G	-
15	G	-
16	G	-
17	G	-

Connector No.	M163
Connector Name	AV CONTROL UNIT (BOSE AUDIO SYSTEM - WITH SURROUND SOUND SYSTEM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
61	W	IT DISP
62	P	CAN-L
63	LG	M-CAN L
76	SHIELD	DISP SHIELD
77	B	DISP IT
78	L	CAN-H
79	SB	M-CAN H

Connector No.	M211
Connector Name	DRIVE MODE SELECT SWITCH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W	-
2	L	-
3	G	-
4	Y	-
6	B	-

Connector No.	M202
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
13	B	-
14	LG	-
15	W	-
16	G	-

Connector No.	M177
Connector Name	JOINT CONNECTOR-M57
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	LG	-
2	LG	-

AB11A0877GB


A B C D E F G H HAC I J K L M N O P

AUTOMATIC AIR CONDITIONING SYSTEM

< WIRING DIAGRAM >


[AUTOMATIC AIR CONDITIONING]

Connector No.	M257
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
13	B	-
14	LG	-
15	W	-
16	G	-

Connector No.	M217
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
17	W	-
18	L	-
19	G	-
20	Y	-
25	G	-
26	W	-
27	LG	-

Connector No.	M216
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	B	-

Connector No.	E5
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
10	G	-
12	P	-

Connector No.	E2
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
12	Y	-
13	LG	-
14	V	-

Connector No.	M258
Connector Name	REAR AIR CONTROL
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	GND
5	R	ILL(+)
6	B	ILL(-)
9	G	Rx (Fr→Rr)
10	W	Tx (Rr→Fr)
12	LG	IGN


ABIIA0878GB

AUTOMATIC AIR CONDITIONING SYSTEM

[AUTOMATIC AIR CONDITIONING]

< WIRING DIAGRAM >

Connector No.	E16
Connector Name	ECM
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
113	P	CAN-L
114	L	CAN-H

Connector No.	E12
Connector Name	PTC RELAY-2
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
1	R	-
2	BG	-
3	W	-
5	P	-

Connector No.	E11
Connector Name	PTC RELAY-1
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	R	-
2	W	-
3	W	-
5	Y	-

Connector No.	E26
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
18	P	-
19	W	-

Connector No.	E22
Connector Name	ACCESSORY RELAY-2
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	G	-
2	B	-
3	R	-
5	P	-

Connector No.	E19
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
10	B	-

AB11A0879GB


A B C D E F G H HAC J K L M N O P

AUTOMATIC AIR CONDITIONING SYSTEM

< WIRING DIAGRAM >


[AUTOMATIC AIR CONDITIONING]

Connector No.	E28
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1M	R	-

Connector No.	E36
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	P	-
3	Y	-

Connector No.	E44
Connector Name	JOINT CONNECTOR-E01
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
15	GR	-
17	B	-

Connector No.	E45
Connector Name	JOINT CONNECTOR-E12
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-
4	L	-
7	P	-
8	P	-
10	P	-

Connector No.	E70
Connector Name	JOINT CONNECTOR-E14
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

Connector No.	E71
Connector Name	JOINT CONNECTOR-E15
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

ABIIA0880GB

AUTOMATIC AIR CONDITIONING SYSTEM

[AUTOMATIC AIR CONDITIONING]

< WIRING DIAGRAM >

Connector No.	E121	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Name		
Connector Color	WHITE	

7	8	9	10	11		
12	13	14	15	16	17	18

Terminal No.	Color of Wire	Signal Name
7	B	GND (POWER)

Terminal No.	Color of Wire	Signal Name
28	P	CAN-L
29	L	CAN-H
41	B	GND (SIGNAL)
43	L	IGN SIGNAL
45	LG	PD SENS SIG-E/R
47	Y	PD SENS PWR-E/R
48	V	PD SENS GND-E/R


Connector No.	E119	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Name		
Connector Color	WHITE	

19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34
35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50

Connector No.	E206	AMBIENT SENSOR
Connector Name		
Connector Color	BLACK	

Terminal No.	Color of Wire	Signal Name
1	L	-
2	Y	-

Terminal No.	Color of Wire	Signal Name
3G	P	-
8G	G	-
11G	G	-
12G	P	-
13G	W	-
21G	P	-
35G	P	-
36G	L	-
37G	BG	-
38G	W	-
50G	G	-
63G	L	-
94G	Y	-



AB11A0881GB


A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

AUTOMATIC AIR CONDITIONING SYSTEM

< WIRING DIAGRAM >


[AUTOMATIC AIR CONDITIONING]

Connector No.	E218
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
82	P	PD SENS SIG-FEM
83	G	PD SENS PWR-FEM
86	L	PD SENS GND-FEM

Connector No.	E209
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
18	L	-
19	Y	-

Connector No.	E207
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
10	G	-
12	R	-

Connector No.	F3
Connector Name	A/C COMPRESSOR
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	SB	-
2	B	-

Connector No.	E244
Connector Name	REFRIGERANT PRESSURE SENSOR
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	G	-
2	P	-
3	L	-

Connector No.	E227
Connector Name	EXHAUST GAS/OUTSIDE ODOR DETECTING SENSOR
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	R	-
2	B	-
3	G	-


ABIIA0882GB

AUTOMATIC AIR CONDITIONING SYSTEM

[AUTOMATIC AIR CONDITIONING]


< WIRING DIAGRAM >

Connector No.	F33
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	10	Color of Wire	B	Signal Name	-
--------------	----	---------------	---	-------------	---

Connector No.	F32
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	12	Color of Wire	P	Signal Name	-
	13	Color of Wire	SB	Signal Name	-
	14	Color of Wire	V	Signal Name	-

Connector No.	F19
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	56	Color of Wire	SB	Signal Name	A/C COMP
--------------	----	---------------	----	-------------	----------

Connector No.	B12
Connector Name	JOINT CONNECTOR-B10
Connector Color	WHITE




Terminal No.	1	Color of Wire	L	Signal Name	-
	2	Color of Wire	L	Signal Name	-

Connector No.	B11
Connector Name	JOINT CONNECTOR-B09
Connector Color	WHITE



Terminal No.	1	Color of Wire	P	Signal Name	-
	2	Color of Wire	P	Signal Name	-

Connector No.	F52
Connector Name	ECM
Connector Color	BROWN



Terminal No.	63	Color of Wire	SB	Signal Name	PDPRES
	64	Color of Wire	V	Signal Name	GND A-PDPRES
	96	Color of Wire	P	Signal Name	AVCC2-PDPRES

AB11A0883GB

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

AUTOMATIC AIR CONDITIONING SYSTEM

[AUTOMATIC AIR CONDITIONING]

< WIRING DIAGRAM >

Connector No.	B16
Connector Name	JOINT CONNECTOR-B11
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

Connector No.	B17
Connector Name	JOINT CONNECTOR-B12
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

Connector No.	B32
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
18	L	-
19	P	-

Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
89A	L	-
90A	P	-

Connector No.	B101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
13	W	-
17	L	-
18	P	-

AB11A0884GB

AUTOMATIC AIR CONDITIONING SYSTEM

[AUTOMATIC AIR CONDITIONING]

< WIRING DIAGRAM >

Connector No.	B106
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	-

Connector No.	B103
Connector Name	JOINT CONNECTOR-B15
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

Connector No.	B102
Connector Name	JOINT CONNECTOR-B14
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

Connector No.	B134
Connector Name	REAR BLOWER MOTOR 2
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	W	-
2	SB	-

Connector No.	B133
Connector Name	REAR BLOWER MOTOR RESISTOR 2
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	SB	-
2	W	-
3	GR	-

Connector No.	B124
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
18	L	-
19	P	-

AB11A0885GB

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

AUTOMATIC AIR CONDITIONING SYSTEM

< WIRING DIAGRAM >

[AUTOMATIC AIR CONDITIONING]

Connector No.	B161
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3	4	5	6	7
8	9	10	11	12	13	14
						15
						16

Terminal No.	Color of Wire	Signal Name
13	SB	-

AB11A0886GB

DIAGNOSIS AND REPAIR WORK FLOW

[AUTOMATIC AIR CONDITIONING]

< BASIC INSPECTION >


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000008179949

OVERALL SEQUENCE



DETAILED FLOW

JMK1A8652GB

DIAGNOSIS AND REPAIR WORK FLOW

[AUTOMATIC AIR CONDITIONING]

< BASIC INSPECTION >

1. GET INFORMATION FOR SYMPTOM

1. Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurs).
2. Check operation condition of the function that is malfunctioning.

>> GO TO 2.

2. CHECK DTC

1. Check DTC.
2. Perform the following procedure if DTC is detected.
 - Record DTC and freeze frame data (Print them out using CONSULT.)
 - Erase DTC.
 - Study the relationship between the cause detected by DTC and the symptom described by the customer.
3. Check related service bulletins for information.

Are any symptoms described and any DTC detected?

Symptom is described, DTC is detected>>GO TO 3.

Symptom is described, DTC is not detected>>GO TO 4.

Symptom is not described, DTC is detected>>GO TO 5.

3. CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Also study the normal operation and fail-safe related to the symptom.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5.

4. CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6.

5. PERFORM DTC CONFIRMATION PROCEDURE

Perform DTC CONFIRMATION PROCEDURE for the detected DTC, and then check that DTC is detected again. At this time, always connect CONSULT to the vehicle, and check self diagnostic results in real time. If two or more DTCs are detected, refer to DTC INSPECTION PRIORITY CHART, and determine trouble diagnosis order.

NOTE:

- Freeze frame data is useful if the DTC is not detected.
- Perform Component Function Check if DTC CONFIRMATION PROCEDURE is not included on Service Manual. This simplified check procedure is an effective alternative though DTC cannot be detected during this check.
If the result of Component Function Check is NG, it is the same as the detection of DTC by DTC CONFIRMATION PROCEDURE.

Is DTC detected?

YES >> GO TO 7.

NO >> Check according to [GI-53. "Intermittent Incident"](#).

6. DETECT MALFUNCTIONING SYSTEM BY SYMPTOM DIAGNOSIS

Detect malfunctioning system according to SYMPTOM DIAGNOSIS based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

Is the symptom described?

YES >> GO TO 7.

NO >> Monitor input data from related sensors or check voltage of related module terminals using CONSULT.

7. DETECT MALFUNCTIONING PART BY DIAGNOSIS PROCEDURE

DIAGNOSIS AND REPAIR WORK FLOW

[AUTOMATIC AIR CONDITIONING]

< BASIC INSPECTION >

Inspect according to Diagnosis Procedure of the system.

Is malfunctioning part detected?

YES >> GO TO 8.

NO >> Check according to [GI-53. "Intermittent Incident"](#).

8. REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnosis Procedure again after repair and replacement.
3. Check DTC. If DTC is detected, erase it.

>> GO TO 9.

9. FINAL CHECK

When DTC is detected in step 2, perform DTC CONFIRMATION PROCEDURE again, and then check that the malfunction is repaired securely.

When symptom is described by the customer, refer to confirmed symptom in step 3 or 4, and check that the symptom is not detected.

Is DTC detected and does symptom remain?

YES-1 >> DTC is detected: GO TO 7.

YES-2 >> Symptom remains: GO TO 4.

NO >> Before returning the vehicle to the customer, always erase DTC.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

OPERATION INSPECTION

FRONT AUTOMATIC AIR CONDITIONING SYSTEM

FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Work Procedure

INFOID:000000008179950

DESCRIPTION

The purpose of the operational check is to check that the individual system operates normally.

Check condition : Engine running at normal operating temperature.

OPERATION INSPECTION

1. CHECK MEMORY FUNCTION

1. Set temperature control (driver side) to 32.0°C (90°F).
2. Press OFF switch.
3. Turn ignition switch OFF.
4. Turn ignition switch ON.
5. Press AUTO switch.
6. Check that set temperature is maintained.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> GO TO 10.

2. CHECK FRONT BLOWER MOTOR

1. Start engine.
2. Operate fan switch.
3. Check that fan speed changes. Check operation for all fan speeds.

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 10.

3. CHECK DISCHARGE AIR (MODE SWITCH AND DEF SWITCH)

1. Operate fan switch to set the fan speed to maximum speed.
2. Operate MODE switch and DEF switch.
3. Check that air outlets change according to each indicated air outlet by placing a hand in front of the outlets. Refer to [HAC-15, "FRONT AUTOMATIC AIR CONDITIONING SYSTEM : System Description"](#).

Is the inspection result normal?

- YES >> GO TO 4.
NO >> GO TO 10.

4. CHECK INTAKE AIR

1. Press REC switch to set the air inlet to recirculation. The REC switch indicator turns ON.
2. Listen to intake sound and confirm air inlets change.
3. Press REC switch again to set the air inlet to fresh air intake. The REC switch indicator turns OFF.
4. Listen to intake sound and confirm air inlets change.

Is the inspection result normal?

- YES >> GO TO 5.
NO >> GO TO 10.

5. CHECK DISCHARGE AIR TEMPERATURE (LH/RH INDEPENDENT TEMPERATURE ADJUSTMENT FUNCTION)

1. Operate temperature control dial (driver side).
2. Check that discharge air temperature (driver side) changes.
3. Operate temperature control (passenger side). The DUAL switch indicator is turns ON.
4. Check that the discharge air temperature (passenger side) changes.
5. Press DUAL switch. The DUAL switch indicator turns OFF.
6. Check that air temperature setting (LH/RH) is unified to the driver side temperature setting.

Is the inspection result normal?

OPERATION INSPECTION

[AUTOMATIC AIR CONDITIONING]

< BASIC INSPECTION >

- YES >> GO TO 6.
NO >> GO TO 10.

6. CHECK WITH TEMPERATURE SETTING LOWERED

1. Operate compressor.
2. Operate temperature control (driver side) and lower the set temperature to 18°C (60°F).
3. Check that cool air blows from the air outlets.

Is the inspection result normal?

- YES >> GO TO 7.
NO >> GO TO 10.

7. CHECK TEMPERATURE INCREASE

1. Operate temperature control (driver side) and raise the set temperature to 32°C (90°F).
2. Check that warm air blows from the air outlets.

Is the inspection result normal?

- YES >> GO TO 8.
NO >> GO TO 10.

8. CHECK AUTO MODE

1. Press AUTO switch to confirm that "AUTO" is indicated on the display.
2. Operate temperature control (driver side) to check that fan speed or air outlet changes (the air outlet or fan speed varies depending on the ambient temperature, in-vehicle temperature, set temperature, etc.).

Is the inspection result normal?

- YES >> GO TO 9.
NO >> GO TO 10.

9. CHECK INTELLIGENT KEY INTERLOCK FUNCTION

1. Operate temperature control dial (driver side) to 32.0°C (90°F).
2. Operate fan switch. Set fan speed to 1st speed.
3. Turn ignition switch OFF.
4. Lock door using Intelligent Key or driver door request switch.
5. Switch to another Intelligent Key and unlock door using Intelligent Key or driver door request switch.
6. Turn ignition switch ON.
7. Operate fan switch. Set fan speed to 7th speed.
8. Operate temperature control dial (driver side). Decrease setting temperature to 18.0°C (60°F).
9. Turn ignition switch OFF.
10. Lock door using Intelligent Key or driver door request switch.
11. Switch to another Intelligent Key and unlock door using Intelligent Key or driver door request switch.
12. Turn ignition switch ON.
13. Check that "Connection with the key has been done." is indicated on display and that air conditioning system starts to operate automatically by setting temperature to 32.0°C (90°F) and fan speed to 1st.

Is the inspection result normal?

- YES >> Inspection End.
NO >> GO TO 10.

10. CHECK SELF-DIAGNOSIS WITH CONSULT

1. Perform self-diagnosis with CONSULT.
2. Check that any DTC is detected.

Is any DTC detected?

- YES >> Refer to [HAC-44, "DTC Index"](#) and perform the appropriate diagnosis.
NO >> GO TO 11.

11. CHECK FAIL-SAFE ACTIVATION

Check that symptom is applied to the fail-safe activation. Refer to [HAC-44, "Fail-safe"](#).

>> Refer to [HAC-145, "Diagnosis Chart By Symptom"](#) and perform the appropriate diagnosis.

REAR AUTOMATIC AIR CONDITIONING SYSTEM

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

OPERATION INSPECTION

[AUTOMATIC AIR CONDITIONING]

< BASIC INSPECTION >

REAR AUTOMATIC AIR CONDITIONING SYSTEM : Work Procedure

INFOID:000000008179951

DESCRIPTION

The purpose of the operational check is to check that the individual system operates normally.

NOTE:

Check that front automatic air conditioning system operates normally. Refer to [HAC-145. "Diagnosis Chart By Symptom"](#).

Check condition : Engine running at normal operating temperature.
: Front air conditioning system operate.

OPERATION INSPECTION

Front A/C Control Operation

1. CHECK REAR CONTROL MODE FUNCTION

1. Press REAR switch. The REAR switch indicator turns ON.
2. Check that display unit changes to state indication display (rear control mode) and that rear automatic air conditioning system starts.
3. Press REAR switch again. The REAR switch indicator turns OFF.
4. Check that rear control mode released. (rear automatic air conditioning system operates continuously)

Is the inspection result normal?

YES >> GO TO 2.
NO >> GO TO 8.

2. CHECK REAR BLOWER MOTOR

1. Press REAR switch.
2. Operate fan switch.
3. Check that fan speed changes. Check operation for all fan speeds.

Is the inspection result normal?

YES >> GO TO 3.
NO >> GO TO 8.

3. CHECK DISCHARGE AIR

1. Operate fan switch to set the fan speed to maximum speed.
2. Operate MODE switch.
3. Check that air outlets change according to each indicated air outlet by placing a hand in front of the outlets. Refer to [HAC-23. "REAR AUTOMATIC AIR CONDITIONING SYSTEM : System Description"](#).

Is the inspection result normal?

YES >> GO TO 4.
NO >> GO TO 8.

4. CHECK DISCHARGE AIR TEMPERATURE

1. Operate temperature control dial (driver side).
2. Check that discharge air temperature changes.

Is the inspection result normal?

YES >> GO TO 5.
NO >> GO TO 8.

5. CHECK WITH TEMPERATURE SETTING LOWERED

1. Operate temperature control dial (driver side) and lower the set temperature to 18°C (60°F).
2. Check that cool air blows from the air outlets.

Is the inspection result normal?

YES >> GO TO 6.
NO >> GO TO 8.

6. CHECK TEMPERATURE INCREASE

1. Operate temperature control dial (driver side) and raise the set temperature to 32°C (90°F).

OPERATION INSPECTION

[AUTOMATIC AIR CONDITIONING]

< BASIC INSPECTION >

2. Check that warm air blows from the air outlets.

Is the inspection result normal?

- YES >> GO TO 7.
NO >> GO TO 8.

7.CHECK AUTO MODE

1. Press AUTO switch.
2. Operate temperature control dial (driver side) to check that fan speed or air outlet changes (the air outlet or fan speed varies depending on the ambient temperature, in-vehicle temperature, set temperature, and etc.).

Is the inspection result normal?

- YES >> Inspection End.
NO >> GO TO 8.

8.CHECK SELF-DIAGNOSIS WITH CONSULT

1. Perform self-diagnosis with CONSULT.
2. Check that any DTC is detected.

Is any DTC detected?

- YES >> Refer to [HAC-44, "DTC Index"](#) and perform the appropriate diagnosis.
NO >> Refer to [HAC-147, "Diagnosis Chart By Symptom"](#) and perform the appropriate diagnosis.

Rear Air Control Operation

1.CHECK REAR BLOWER MOTOR

1. Press AUTO switch.
2. Operate fan switch.
3. Check that fan speed changes. Check operation for all fan speeds.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> GO TO 7.

2.CHECK DISCHARGE AIR

1. Operate fan switch to set the fan speed to maximum speed.
2. Operate MODE switch.
3. Check that air outlets change according to each indicated air outlet by placing a hand in front of the outlets. Refer to [HAC-23, "REAR AUTOMATIC AIR CONDITIONING SYSTEM : System Description"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 7.

3.CHECK DISCHARGE AIR TEMPERATURE

1. Operate temperature control switch.
2. Check that discharge air temperature changes.

Is the inspection result normal?

- YES >> GO TO 4.
NO >> GO TO 7.

4.CHECK WITH TEMPERATURE SETTING LOWERED

1. Operate temperature control switch and lower the set temperature to 18°C.
2. Check that cool air blows from the air outlets.

Is the inspection result normal?

- YES >> GO TO 5.
NO >> GO TO 7.

5.CHECK TEMPERATURE INCREASE

1. Operate temperature control switch and raise the set temperature to 32°C.
2. Check that warm air blows from the air outlets.

Is the inspection result normal?

A

B

C

D

E

F

G

H

HAC

J

K

L

M

N

O

P

OPERATION INSPECTION

[AUTOMATIC AIR CONDITIONING]

< BASIC INSPECTION >

- YES >> GO TO 6.
- NO >> GO TO 7.

6. CHECK AUTO MODE

1. Press AUTO switch.
2. Operate temperature control switch to check that fan speed or air outlet changes (the air outlet or fan speed varies depending on the ambient temperature, in-vehicle temperature (rear side), set temperature, and etc.).

Is the inspection result normal?

- YES >> Inspection End.
- NO >> GO TO 7.

7. CHECK SELF-DIAGNOSIS WITH CONSULT

1. Perform self-diagnosis with CONSULT.
2. Check that any DTC is detected.

Is any DTC detected?

- YES >> Refer to [HAC-44. "DTC Index"](#) and perform the appropriate diagnosis.
- NO >> Refer to [HAC-147. "Diagnosis Chart By Symptom"](#) and perform the appropriate diagnosis.

ACCS (ADVANCED CLIMATE CONTROL SYSTEM)

ACCS (ADVANCED CLIMATE CONTROL SYSTEM) : Work Procedure

INFOID:000000008179952

DESCRIPTION

The purpose of the operational check is to check that the individual system operates normally.

NOTE:

Check that front automatic air conditioning system operates normally. Refer to [HAC-72. "FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Work Procedure"](#).

Check condition : Engine running

OPERATION INSPECTION

1. CHECK PLASMACLUSTER™ CONTROL

Check the ionizer operation sound (whirring sound) in the duct by putting an ear to the center ventilator grille (driver side) outlet while pressing fan switch and OFF switch alternately.

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> GO TO 4.

2. CHECK PLASMACLUSTER™ CONTROL OPERATION STATUS

Operate fan switch. Visually check that status indicator in display unit changes in accordance with the following table.

Fan speed	Display unit (ion indicator)
2nd	CLEAN
5th	QUICK CLEAN

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> GO TO 4.

3. CHECK AUTOMATIC INTAKE CONTROL (EXHAUST GAS / OUTSIDE ODOR DETECTING MECHANISM)

1. Operate fan switch to set the fan speed to maximum speed.
2. Press auto intake switch to set the air inlet to recirculation. The auto intake switch indicator and intake switch indicator turn ON.
3. Listen to intake sound and confirm air inlets change.
4. Wait approximately for 5 minutes until air inlet switches to fresh air intake.
5. Apply cigarette smoke or similar substance to exhaust gas / outside odor detecting sensor portion.

OPERATION INSPECTION

[AUTOMATIC AIR CONDITIONING]

< BASIC INSPECTION >

6. Listen to intake sound and confirm air inlets change to recirculation.

Is the inspection result normal?

YES >> Inspection End.

NO >> GO TO 4.

4. CHECK SELF-DIAGNOSIS WITH CONSULT

1. Perform self-diagnosis with CONSULT.

2. Check that any DTC is detected.

Is any DTC detected?

YES >> Refer to [HAC-44, "DTC Index"](#) and perform the appropriate diagnosis.

NO >> Refer to [HAC-147, "Diagnosis Chart By Symptom"](#) and perform the appropriate diagnosis.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

SYSTEM SETTING

[AUTOMATIC AIR CONDITIONING]

< BASIC INSPECTION >

SYSTEM SETTING

FRONT AUTOMATIC AIR CONDITIONING SYSTEM

FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Temperature Setting Trimmer (Front)

INFOID:000000008179953

DESCRIPTION

If the temperature felt by the customer is different from the front air flow temperature controlled by the temperature setting, the A/C auto amp. control temperature can be adjusted to compensate for the temperature setting.

HOW TO SET

 With CONSULT

Perform "TEMP SET CORRECT" of HVAC work support item.

Work support items	Display (°C)	Display (°F)
TEMP SET CORRECT	3.0	6
	2.5	5
	2.0	4
	1.5	3
	1.0	2
	0.5	1
	0 (initial status)	0 (initial status)
	-0.5	-1
	-1.0	-2
	-1.5	-3
	-2.0	-4
	-2.5	-5
	-3.0	-6

NOTE:

- When -3.0°C (-6°F) is corrected on the temperature setting set as 25.0°C (77°F) the temperature controlled by A/C auto amp. is 25.0°C (77°F) -3.0°C (-6°F) = 22.0°C (72°F) and the temperature becomes lower than the temperature setting.
- When the battery cable is disconnected from the negative terminal or when the battery voltage becomes 10 V or less, the setting of the difference between the set temperature and control temperature may be cancelled.

FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Foot Position Setting Trimmer

INFOID:000000008179954

DESCRIPTION

In FOOT mode, the air blowing to DEF can change ON/OFF.

HOW TO SET

 With CONSULT

Perform the "BLOW SET" of HVAC work support item.

Work support items	Display	Defroster door position	
		Auto control	Manual control
BLOW SET	Mode1	OPEN	CLOSE
	Mode2 (initial status)	OPEN	OPEN
	Mode3	CLOSE	OPEN
	Mode4	CLOSE	CLOSE

SYSTEM SETTING

[AUTOMATIC AIR CONDITIONING]

< BASIC INSPECTION >

NOTE:

When the battery cable is disconnected from the negative terminal or when the battery voltage becomes 10 V or less, the setting of the discharge air mix ratio in FOOT mode may be cancelled.

FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Inlet Port Memory Function (FRE)

INFOID:000000008179955

DESCRIPTION

- If the ignition switch is turned to the OFF position while the intake switch is set to OFF (fresh air intake), “Perform the memory” or “Do not perform the memory” of intake switch OFF (fresh air intake) condition can be selected.
- If “Perform the memory” was set, the intake switch will be OFF (fresh air intake) when turning the ignition switch to the ON position again.
- If “Do not perform the memory” was set, the air inlets will be controlled automatically when turning the ignition switch to the ON position again.

HOW TO SET

ⓅWith CONSULT

Perform the “FRE MEMORY SET” of HVAC work support item.

Work support items	Display	Setting
FRE MEMORY SET	WITHOUT	Perform the memory of manual FRE
	WITH (initial status)	Do not perform the memory of manual FRE (auto control)

NOTE:

When the battery cable is disconnected from the negative terminal or when the battery voltage becomes 10 V or less, the setting of the FRE memory function may be cancelled.

FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Inlet Port Memory Function (REC)

INFOID:000000008179956

DESCRIPTION

- If the ignition switch is turned to the OFF position while the intake switch is set to ON (recirculation), “Perform the memory” or “Do not perform the memory” of intake switch ON (recirculation) condition can be selected.
- If “Perform the memory” was set, the intake switch will be ON (recirculation) when turning the ignition switch to the ON position again.
- If “Do not perform the memory” was set, the air inlets will be controlled automatically when turning the ignition switch to the ON position again.

HOW TO SET

ⓅWith CONSULT

Perform the “REC MEMORY SET” of HVAC work support item.

Work support items	Display	Setting
REC MEMORY SET	WITHOUT (initial status)	Perform the memory of manual REC
	WITH	Do not perform the memory of manual REC (auto control)

NOTE:

When the battery cable is disconnected from the negative terminal or when the battery voltage becomes 10 V or less, the setting of the REC memory function may be cancelled.

REAR AUTOMATIC AIR CONDITIONING SYSTEM

REAR AUTOMATIC AIR CONDITIONING SYSTEM : Temperature Setting Trimmer (Rear)

INFOID:000000008179957

DESCRIPTION

SYSTEM SETTING

[AUTOMATIC AIR CONDITIONING]

< BASIC INSPECTION >

If the temperature felt by the customer is different from the rear air flow temperature controlled by the temperature setting, the A/C auto amp. control temperature can be adjusted to compensate for the temperature setting.

HOW TO SET

 With CONSULT

Perform "REAR TEMP SET CORRECT" of HVAC work support item.

Work support items	Display (°C)	Display (°F)
REAR TEMP SET CORRECT	3.0	6
	2.5	5
	2.0	4
	1.5	3
	1.0	2
	0.5	1
	0 (initial status)	0 (initial status)
	-0.5	-1
	-1.0	-2
	-1.5	-3
	-2.0	-4
	-2.5	-5
	-3.0	-6

NOTE:

- When -3.0°C (-6°F) is corrected on the temperature setting set as 25.0°C (77°F) the temperature controlled by A/C auto amp. is 25.0°C (77°F) -3.0°C (-6°F) = 22.0°C (72°F) and the temperature becomes lower than the temperature setting.
- When the battery cable is disconnected from the negative terminal or when the battery voltage becomes 10 V or less, the setting of the difference between the set temperature and control temperature may be cancelled.

ACCS (ADVANCED CLIMATE CONTROL SYSTEM)

ACCS (ADVANCED CLIMATE CONTROL SYSTEM) : Exhaust Gas / Outside Odor Detecting Sensor Sensitivity Adjustment Function

INFOID:000000008179958

DESCRIPTION

According to customer's sense of smell, exhaust gas / outside odor detecting sensor sensitivity can be changed.

HOW TO SET

 With CONSULT

Perform the "GAS SENSOR ADJUSTMENT" of HVAC work support item.

Work support items	Display	Setting
GAS SENSOR ADJUSTMENT	2	More sensitive setting than display 1 (REC earlier than display 1).
	1	More sensitive setting than normal setting (REC earlier than normal operation).
	0 (initial status)	Normal
	-1	Less sensitive setting than normal setting (REC later than normal operation).
	-2	Less sensitive setting than display -1 (REC later than display -1).

NOTE:

When the battery cable is disconnected from the negative terminal or when the battery voltage becomes 10 V or less, the setting of WORK SUPPORT may be cancelled.

ACCS (ADVANCED CLIMATE CONTROL SYSTEM) : Auto Intake Switch Interlocking

SYSTEM SETTING

[AUTOMATIC AIR CONDITIONING]

< BASIC INSPECTION >

Movement Change Function

INFOID:000000008179959

DESCRIPTION

Condition for interlocking movement of auto intake switch and A/C switch can be changed. In addition operation of the auto intake switch, which activates the automatic intake control (exhaust gas / outside odor detecting mechanism), can be set to become available when the A/C switch is ON.

HOW TO SET

 With CONSULT

Perform the "CLEAN SW SET" of HVAC work support item.

Work support items	Display	Setting
CLEAN SW SET	Mode1	Initial setting
	Mode2	Setting 1
	Mode3	Setting 2
	Mode4	Setting 3

Initial setting	When the auto intake switch is ON, the A/C switch is also turned ON in synchronization with the auto intake switch. Control of the auto intake switch is functional even when the A/C switch is turned OFF.
Setting 1	When the auto intake switch is ON, the A/C switch is not turned ON in synchronization with the auto intake switch. Control of the auto intake switch is functional even when the A/C switch is turned OFF.
Setting 2	When the auto intake switch is ON, the A/C switch is also turned ON in synchronization with the auto intake switch. When the A/C switch is turned OFF, the auto intake switch is turned OFF in synchronization with the A/C switch.
Setting 3	Auto intake switch can be turned ON only when A/C switch is ON. When the A/C switch is turned OFF, the auto intake switch is turned OFF in synchronization with the A/C switch.

NOTE:

When the battery cable is disconnected from the negative terminal or when the battery voltage becomes 10 V or less, the setting of WORK SUPPORT may be cancelled.

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

DTC/CIRCUIT DIAGNOSIS

U1000 CAN COMM CIRCUIT

Description

INFOID:000000008179960

CAN (Controller Area Network) is a serial communication system for real time application. It is an on-vehicle multiplex communication system with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto vehicles, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with two communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only. Refer to [LAN-39, "CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart"](#).

DTC Logic

INFOID:000000008179961

DTC DETECTION LOGIC

DTC	Items (CONSULT screen terms)	DTC detection condition	Possible cause
U1000	CAN COMM CIRCUIT	When A/C auto amp. is not transmitting or receiving CAN communication signal for 2 or more seconds.	CAN communication system

DTC CONFIRMATION PROCEDURE

1.PERFORM SELF-DIAGNOSIS

 With CONSULT

1. Turn ignition switch ON and wait for 2 seconds or more.
2. Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
3. Check if any DTC No. is displayed in the self-diagnosis results.

Is DTC detected?

- YES >> Refer to [HAC-82, "Diagnosis Procedure"](#).
 NO >> Refer to [GI-53, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000008179962

1.CHECK CAN COMMUNICATION SYSTEM

Check CAN communication system. Refer to [LAN-22, "Trouble Diagnosis Flow Chart"](#).

>> Inspection End.

U1010 CONTROL UNIT (CAN)

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

U1010 CONTROL UNIT (CAN)

Description

INFOID:000000008179963

Initial diagnosis of A/C auto amp.

DTC Logic

INFOID:000000008179964

DTC DETECTION LOGIC

DTC	Items (CONSULT screen terms)	DTC detection condition	Possible cause
U1010	CONTROL UNIT (CAN)	When detecting error during the initial diagnosis of CAN controller of A/C auto amp.	A/C auto amp.

DTC CONFIRMATION PROCEDURE

1.PERFORM SELF-DIAGNOSIS

 With CONSULT

1. Turn ignition switch ON.
2. Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
3. Check if any DTC No. is displayed in the self-diagnosis results.

Is DTC detected?

- YES >> Refer to [HAC-83. "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000008179965

1.REPLACE A/C AUTO AMP.

Replace A/C auto amp. Refer to [HAC-157. "Removal and Installation"](#).

>> Inspection End.

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

B2578, B2579 IN-VEHICLE SENSOR

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

B2578, B2579 IN-VEHICLE SENSOR

DTC Logic

INFOID:000000008179966

DTC DETECTION LOGIC

NOTE:

- If DTC is displayed along with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [HAC-82, "DTC Logic"](#).
- If DTC is displayed along with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [HAC-83, "DTC Logic"](#).

DTC	Items (CONSULT screen terms)	DTC detection condition	Possible cause
B2578	IN-VEHICLE SENSOR	The in-vehicle sensor recognition temperature is too high.	<ul style="list-style-type: none">• In-vehicle sensor• A/C auto amp.• Harness or connectors (The sensor circuit is open or shorted.)
B2579		The in-vehicle sensor recognition temperature is too low.	

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

Ⓜ With CONSULT

1. Turn ignition switch ON.
2. Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
3. Check if any DTC No. is displayed in the self-diagnosis results.

Is DTC detected?

- YES >> Refer to [HAC-84, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000008179967

Regarding Wiring Diagram information, refer to [HAC-47, "Wiring Diagram"](#).

1. CHECK IN-VEHICLE SENSOR POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect in-vehicle sensor connector.
3. Turn ignition switch ON.
4. Check voltage between in-vehicle sensor harness connector and ground.

+		-	Voltage (Approx.)
In-vehicle sensor			
Connector	Terminal		
M102	1	Ground	5 V

Is the inspection result normal?

- YES >> GO TO 2.
NO >> GO TO 4.

2. CHECK IN-VEHICLE SENSOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between front in-vehicle sensor harness connector and ground.

B2578, B2579 IN-VEHICLE SENSOR

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

In-vehicle sensor		—	Continuity
Connector	Terminal		
M102	2	Ground	Yes

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3. CHECK IN-VEHICLE SENSOR

Check in-vehicle sensor. Refer to [HAC-85, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace A/C auto amp. Refer to [HAC-157, "Removal and Installation"](#).

NO >> Replace in-vehicle sensor. Refer to [HAC-159, "Removal and Installation"](#).

4. CHECK IN-VEHICLE SENSOR POWER SUPPLY CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect A/C auto amp. connector.
3. Check continuity between in-vehicle sensor harness connector and A/C auto amp. harness connector.

In-vehicle sensor		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M102	1	M50	27	Yes

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair harness or connector.

5. CHECK IN-VEHICLE SENSOR POWER SUPPLY CIRCUIT FOR GROUND SHORT

Check continuity between in-vehicle sensor harness connector and ground.

In-vehicle sensor		—	Continuity
Connector	Terminal		
M102	1	Ground	No

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair harness or connector.

6. CHECK IN-VEHICLE SENSOR POWER SUPPLY CIRCUIT FOR POWER SHORT

1. Turn ignition switch ON.
2. Check voltage between in-vehicle sensor harness connector and ground.

+		-	Voltage (Approx.)
In-vehicle sensor			
Connector	Terminal		
M102	1	Ground	0 V

Is the inspection result normal?

YES >> Replace A/C auto amp. Refer to [HAC-157, "Removal and Installation"](#).

NO >> Repair harness or connector.

Component Inspection

INFOID:000000008179968

1. CHECK IN-VEHICLE SENSOR

1. Turn ignition switch OFF.
2. Disconnect in-vehicle sensor connector.

B2578, B2579 IN-VEHICLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONING]

3. Check resistance between in-vehicle sensor terminals.

Terminal		Condition	Resistance: kΩ
		Temperature: °C (°F)	
1	2	-15 (5)	12.73
		-10 (14)	9.92
		-5 (23)	7.80
		0 (32)	6.19
		5 (41)	4.95
		10 (50)	3.99
		15 (59)	3.24
		20 (68)	2.65
		25 (77)	2.19
		30 (86)	1.81
		35 (95)	1.51
		40 (104)	1.27
		45 (113)	1.07

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace in-vehicle sensor. Refer to [HAC-159. "Removal and Installation"](#).

B257B, B257C AMBIENT SENSOR

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

B257B, B257C AMBIENT SENSOR

DTC Logic

INFOID:000000008179969

DTC DETECTION LOGIC

NOTE:

- If DTC is displayed along with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [HAC-82, "DTC Logic"](#).
- If DTC is displayed along with DTC U1010, first perform the trouble diagnosis for DTC U1010. [HAC-83, "DTC Logic"](#).

DTC	Items (CONSULT screen terms)	DTC detection condition	Possible cause
B257B	AMBIENT SENSOR	The ambient sensor recognition temperature is too high.	<ul style="list-style-type: none">• Ambient sensor• A/C auto amp.• Harness or connectors (The sensor circuit is open or shorted.)
B257C		The ambient sensor recognition temperature is too low.	

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

Ⓜ With CONSULT

1. Turn ignition switch ON.
2. Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
3. Check if any DTC No. is displayed in the self-diagnosis results.

Is DTC detected?

- YES >> Refer to [HAC-87, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000008179970

Regarding Wiring Diagram information, refer to [HAC-47, "Wiring Diagram"](#).

1. CHECK AMBIENT SENSOR POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect ambient sensor connector.
3. Turn ignition switch ON.
4. Check voltage between ambient sensor harness connector and ground.

+		-	Voltage (Approx.)
Ambient sensor			
Connector	Terminal		
E206	1	Ground	5 V

Is the inspection result normal?

- YES >> GO TO 2.
NO >> GO TO 4.

2. CHECK AMBIENT SENSOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between ambient sensor harness connector and ground.

B257B, B257C AMBIENT SENSOR

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

Ambient sensor		—	Continuity
Connector	Terminal		
E206	2	Ground	Yes

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3.CHECK AMBIENT SENSOR

Check ambient sensor. Refer to [HAC-88, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace A/C auto amp. Refer to [HAC-157, "Removal and Installation"](#).

NO >> Replace ambient sensor. Refer to [HAC-158, "Removal and Installation"](#).

4.CHECK AMBIENT SENSOR POWER SUPPLY CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect A/C auto amp.connector.
3. Check continuity between ambient sensor harness connector and A/C auto amp. harness connector.

Ambient sensor		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
E206	1	M50	7	Yes

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair harness or connector.

5.CHECK AMBIENT SENSOR POWER SUPPLY CIRCUIT FOR GROUND SHORT

Check continuity between ambient sensor harness connector and ground.

Ambient sensor		—	Continuity
Connector	Terminal		
E206	1	Ground	No

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair harness or connector.

6.CHECK AMBIENT SENSOR POWER SUPPLY CIRCUIT FOR POWER SHORT

1. Turn ignition switch ON.
2. Check voltage between ambient sensor harness connector and ground.

+		—	Voltage (Approx.)
Ambient sensor			
Connector	Terminal		
E206	1	Ground	0 V

Is the inspection result normal?

YES >> Replace A/C auto amp. Refer to [HAC-157, "Removal and Installation"](#).

NO >> Repair harness or connector.

Component Inspection

INFOID:000000008179971

1.CHECK AMBIENT SENSOR

1. Turn ignition switch OFF.
2. Disconnect ambient sensor connector.

B257B, B257C AMBIENT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONING]

3. Check resistance between ambient sensor terminals.

Terminal		Condition	Resistance: kΩ
		Temperature: °C (°F)	
1	2	-15 (5)	12.73
		-10 (14)	9.92
		-5 (23)	7.80
		0 (32)	6.19
		5 (41)	4.95
		10 (50)	3.99
		15 (59)	3.24
		20 (68)	2.65
		25 (77)	2.19
		30 (86)	1.81
		35 (95)	1.51
		40 (104)	1.27
45 (113)	1.07		

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace ambient sensor. Refer to [HAC-158. "Removal and Installation"](#).

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

B2581, B2582 INTAKE SENSOR

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

B2581, B2582 INTAKE SENSOR

DTC Logic

INFOID:000000008179972

DTC DETECTION LOGIC

NOTE:

- If DTC is displayed along with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [HAC-82, "DTC Logic"](#).
- If DTC is displayed along with DTC U1010, first perform the trouble diagnosis for DTC U1010. [HAC-83, "DTC Logic"](#).

DTC	Items (CONSULT screen terms)	DTC detection condition	Possible cause
B2581	INTAKE SENSOR	The intake sensor recognition temperature is too high.	<ul style="list-style-type: none">• Intake sensor• A/C auto amp.• Harness or connectors (The sensor circuit is open or shorted.)
B2582		The intake sensor recognition temperature is too low.	

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

④ With CONSULT

1. Turn ignition switch ON.
2. Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
3. Check if any DTC No. is displayed in the self-diagnosis results.

Is DTC detected?

- YES >> Refer to [HAC-90, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000008179973

Regarding Wiring Diagram information, refer to [HAC-47, "Wiring Diagram"](#).

1. CHECK INTAKE SENSOR POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect intake sensor connector.
3. Turn ignition switch ON.
4. Check voltage between intake sensor harness connector and ground.

+		-	Voltage (Approx.)
Intake sensor			
Connector	Terminal		
M103	1	Ground	5 V

Is the inspection result normal?

- YES >> GO TO 2.
NO >> GO TO 4.

2. CHECK INTAKE SENSOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between intake sensor harness connector and ground.

B2581, B2582 INTAKE SENSOR

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

Intake sensor		—	Continuity
Connector	Terminal		
M103	2	Ground	Yes

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3.CHECK INTAKE SENSOR

Check intake sensor. Refer to [HAC-91, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace A/C auto amp. Refer to [HAC-157, "Removal and Installation"](#).

NO >> Replace intake sensor. Refer to [HAC-161, "Removal and Installation"](#).

4.CHECK INTAKE SENSOR POWER SUPPLY CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect A/C auto amp. connector.
3. Check continuity between intake sensor harness connector and A/C auto amp. harness connector.

Intake sensor		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M103	1	M50	28	Yes

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair harness or connector.

5.CHECK INTAKE SENSOR POWER SUPPLY CIRCUIT FOR GROUND SHORT

Check continuity between intake sensor harness connector and ground.

Intake sensor		—	Continuity
Connector	Terminal		
M103	1	Ground	No

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair harness or connector.

6.CHECK INTAKE SENSOR POWER SUPPLY CIRCUIT FOR POWER SHORT

1. Turn ignition switch ON.
2. Check voltage between intake sensor harness connector and ground.

+		-	Voltage (Approx.)
Intake sensor			
Connector	Terminal		
M103	1	Ground	0 V

Is the inspection result normal?

YES >> Replace A/C auto amp. Refer to [HAC-157, "Removal and Installation"](#).

NO >> Repair harness or connector.

Component Inspection

INFOID:000000008179974

1.CHECK INTAKE SENSOR

1. Turn ignition switch OFF.
2. Disconnect intake sensor connector.

B2581, B2582 INTAKE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONING]

3. Check resistance between intake sensor terminals.

Terminal		Condition	Resistance: kΩ
		Temperature: °C (°F)	
1	2	-15 (5)	17.73
		-10 (14)	13.46
		-5 (23)	10.33
		0 (32)	8.00
		5 (41)	6.25
		10 (50)	4.93
		15 (59)	3.92
		20 (68)	3.14
		25 (77)	2.54
		30 (86)	2.06
		35 (95)	1.69
		40 (104)	1.39
		45 (113)	1.15

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace intake sensor. Refer to [HAC-161, "Removal and Installation"](#).

B262A, B262B, B2657, B2658 EXHAUST GAS/OUTSIDE ODOR DETECTING SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONING]

B262A, B262B, B2657, B2658 EXHAUST GAS/OUTSIDE ODOR DETECTING SENSOR

DTC Logic

INFOID:000000008179975

DTC DETECTION LOGIC

NOTE:

- If DTC is displayed along with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [HAC-82, "DTC Logic"](#).
- If DTC is displayed along with DTC U1010, first perform the trouble diagnosis for DTC U1010. [HAC-83, "DTC Logic"](#).

DTC	Items (CONSULT screen terms)	DTC detection condition	Possible cause
B262A	GAS SENSOR	Exhaust gas / outside odor detecting sensor duty ratio 15% or less.	<ul style="list-style-type: none">• Exhaust gas / outside odor detecting sensor• A/C auto amp.• Harness or connectors (The sensor circuit is open or shorted.)
B262B		Exhaust gas / outside odor detecting sensor duty ratio 85% or more.	
B2657	CAS SENSOR CIRCUIT	Exhaust gas / outside odor detecting sensor duty ratio 0%.	
B2658		Exhaust gas / outside odor detecting sensor duty ratio 100%.	

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

Ⓜ With CONSULT

1. Turn ignition switch ON.
2. Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
3. Check if any DTC No. is displayed in the self-diagnosis results.

Is DTC detected?

- YES >> Refer to [HAC-93, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000008179976

Regarding Wiring Diagram information, refer to [HAC-47, "Wiring Diagram"](#).

1. CHECK FUSE

1. Turn ignition switch OFF.
2. Check 10A fuse [No. 30, located in fuse block (J/B)]

NOTE:

Refer to [PG-83, "Terminal Arrangement"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> If a fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.

2. CHECK EXHAUST GAS / OUTSIDE ODOR DETECTING SENSOR POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect exhaust gas / outside odor detecting sensor connector.
3. Turn ignition switch ON.
4. Check voltage between exhaust gas / outside odor detecting sensor harness and ground.

B262A, B262B, B2657, B2658 EXHAUST GAS/OUTSIDE ODOR DETECTING SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONING]

+		-	Voltage (Approx.)
Exhaust gas / outside odor detecting sensor			
Connector	Terminal		
E227	1	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector between exhaust gas / outside odor detecting sensor and fuse block (J/B).

3. CHECK EXHAUST GAS / OUTSIDE ODOR DETECTING SENSOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between exhaust gas / outside odor detecting sensor harness connector and ground.

+		—	Continuity
Exhaust gas / outside odor detecting sensor			
Connector	Terminal		
E227	2	Ground	Yes

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair harness or connector.

4. CHECK EXHAUST GAS / OUTSIDE ODOR DETECTING SENSOR SIGNAL CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between exhaust gas / outside odor detecting sensor harness connector and ground.

+		-	Voltage (Approx.)
Exhaust gas / outside odor detecting sensor			
Connector	Terminal		
E227	3	Ground	Battery voltage

Is the inspection result normal?

YES >> Replace exhaust gas / outside odor detecting sensor. Refer to [HAC-162, "Removal and Installation"](#).

NO >> GO TO 5.

5. CHECK EXHAUST GAS / OUTSIDE ODOR DETECTING SENSOR SIGNAL CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect A/C auto amp. connector.
3. Check continuity between exhaust gas / outside odor detecting sensor harness connector and A/C auto amp. connector.

+		A/C auto amp.		Continuity
Exhaust gas / outside odor detecting sensor				
Connector	Terminal	Connector	Terminal	
E227	3	M50	30	Yes

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair harness or connector.

6. CHECK EXHAUST GAS / OUTSIDE ODOR DETECTING SENSOR SIGNAL CIRCUIT FOR GROUND SHORT

Check continuity between exhaust gas / outside odor detecting sensor harness connector and ground.

B262A, B262B, B2657, B2658 EXHAUST GAS/OUTSIDE ODOR DETECTING SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONING]

Exhaust gas / outside odor detecting sensor		—	Continuity
Connector	Terminal		
E227	3	Ground	No

A
B

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair harness or connector.

C

7. CHECK EXHAUST GAS / OUTSIDE ODOR DETECTING SENSOR SIGNAL CIRCUIT FOR POWER SHORT

D

Check voltage between exhaust gas / outside odor detecting sensor harness and ground.

+			
Exhaust gas / outside odor detecting sensor		-	Voltage (Approx.)
Connector	Terminal		
E227	3	Ground	0 V

E
F

Is the inspection result normal?

YES >> Replace A/C auto amp. Refer to [HAC-157. "Removal and Installation"](#).

NO >> Repair harness or connector.

G

H

HAC

J

K

L

M

N

O

P

B2630, B2631 SUNLOAD SENSOR

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

B2630, B2631 SUNLOAD SENSOR

DTC Logic

INFOID:000000008242325

DTC DETECTION LOGIC

NOTE:

- If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-82. "DTC Logic"](#) or [HAC-83. "DTC Logic"](#).
- Sunload sensor may register a malfunction when indoors, at dusk, or at other times when light is insufficient. When performing the diagnosis indoors, light the sunload sensor with a lamp (60W or more).

DTC	Items (CONSULT screen terms)	Diagnostic item is detected when...	Possible cause
B2630	SUNLOAD SEN (SHORT)	Detected calorie at sunload sensor 1395 w/m ² (1200 kcal/m ² ·h) or more	• Sunload sensor • A/C auto amp. • Harness and connector (Sunload sensor circuit is open, or there is a short in the circuit)
B2631	SUNLOAD SEN (OPEN)	Detected calorie at sunload sensor 0 w/m ² (0 kcal/m ² ·h)	

DTC CONFIRMATION PROCEDURE

1. CHECK WITH SELF-DIAGNOSIS FUNCTION OF CONSULT

1. Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
2. Check if any DTC No. is displayed in the self-diagnosis results.

NOTE:

- If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-82. "DTC Logic"](#) or [HAC-83. "DTC Logic"](#).
- Sunload sensor may register a malfunction when indoors, at dusk, or at other times when light is insufficient. When performing the diagnosis indoors, light the sunload sensor with a lamp (60W or more).

Is DTC No. "B2630" or "B2631" displayed?

- YES >> Perform trouble diagnosis for the sunload sensor. Refer to [HAC-96. "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000008242326

Regarding Wiring Diagram information, refer to [HAC-47. "Wiring Diagram"](#).

1. CHECK SUNLOAD SENSOR POWER SUPPLY

1. Disconnect sunload sensor connector.
2. Turn ignition switch ON.
3. Check voltage between sunload sensor harness connector M101 terminal 1 and ground.

+		-	Voltage (Approx.)
Sunload sensor			
Connector	Terminal	Ground	5 V
M101	1		

Is the inspection result normal?

- YES >> GO TO 2.
NO >> GO TO 4.

2. CHECK CONTINUITY BETWEEN SUNLOAD SENSOR AND A/C AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect A/C auto amp. connector.

B2630, B2631 SUNLOAD SENSOR

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

3. Check continuity between sunload sensor harness connector M101 terminal 2 and A/C auto amp. harness connector M50 terminal 26.

Sunload sensor		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M101	2	M50	26	Yes

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3.CHECK SUNLOAD SENSOR

1. Reconnect sunload sensor connector and A/C auto amp. connector.
2. Check sunload sensor. Refer to [HAC-97, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace A/C auto amp. Refer to [HAC-157, "Removal and Installation"](#).

NO >> Replace sunload sensor. Refer to [HAC-160, "Removal and Installation"](#).

4.CHECK CONTINUITY BETWEEN SUNLOAD SENSOR AND A/C AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect A/C auto amp. connector.
3. Check continuity between sunload sensor harness connector M101 terminal 1 and A/C auto amp. harness connector M50 terminal 9.

Sunload sensor		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M101	1	M50	9	Yes

4. Check continuity between sunload sensor harness connector M101 terminal 1 and ground.

Sunload sensor		—	Continuity
Connector	Terminal		
M101	1	Ground	No

Is the inspection result normal?

YES >> Replace A/C auto amp. Refer to [HAC-157, "Removal and Installation"](#).

NO >> Repair harness or connector.

Component Inspection

INFOID:000000008242327

1.CHECK SUNLOAD SENSOR


1. Turn ignition switch ON.
2. Check voltage between A/C auto amp. harness connector and ground.

(+)		(-)	
A/C auto amp.		—	
Connector	Terminal		
M50	9	Ground	

B2630, B2631 SUNLOAD SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONING]



NOTE:

Select a place in direct sunlight when checking sunload sensor.

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace sunload sensor. Refer to [HAC-160, "Removal and Installation"](#).

B2632, B2633 AIR MIX DOOR MOTOR (DRIVER SIDE)

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

B2632, B2633 AIR MIX DOOR MOTOR (DRIVER SIDE)

DTC Logic

INFOID:000000008179980

DTC DETECTION LOGIC

DTC	Items (CONSULT screen terms)	DTC detection condition	Possible cause
B2632	DR AIR MIX DOOR MOT	Air mix door motor (driver side) PBR position 95% or more	<ul style="list-style-type: none"> Air mix door motor (driver side) (PBR internal circuit is open or shorted) Air mix door motor (driver side) installation condition A/C auto amp. Harness and connector (LIN communication line is open or shorted)
B2633		Air mix door motor (driver side) PBR position 5% or less	

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

With CONSULT

- Turn ignition switch ON.
- Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
- Check if any DTC No. is displayed in the self-diagnosis results.

Is DTC detected?

YES >> Refer to [HAC-99, "Diagnosis Procedure"](#).

NO >> Inspection End.

Diagnosis Procedure

INFOID:000000008179981

Regarding Wiring Diagram information, refer to [HAC-47, "Wiring Diagram"](#).

1. CHECK AIR MIX DOOR MOTOR (DRIVER SIDE) COMMUNICATION SIGNAL

- Turn ignition switch ON.
- Check output waveform between air mix door motor (driver side) harness connector and ground with the oscilloscope.

+		-	Output waveform
Air mix door motor (driver side)			
Connector	Terminal		
M130	2	Ground	

Is the inspection result normal?

YES >> GO TO 2.

NO >> GO TO 3.

2. CHECK INSTALLATION OF AIR MIX DOOR MOTOR (DRIVER SIDE)

B2632, B2633 AIR MIX DOOR MOTOR (DRIVER SIDE)

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

Check air mix door motor (driver side) is properly installed. Refer to [HAC-164. "Exploded View - Front Door Motors"](#).

Is the inspection result normal?

YES >> Replace air mix door motor (driver side). Refer to [HAC-165. "AIR MIX DOOR MOTOR : Removal and Installation - Air Mix Door Motor \(Driver Side\)"](#).

NO >> Repair or replace malfunctioning part.

3. CHECK AIR MIX DOOR MOTOR (DRIVER SIDE) COMMUNICATION SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect air mix door motor (driver side) and A/C auto amp. connector.
3. Check continuity between air mix door motor (driver side) harness connector and A/C auto amp. harness connector.

Air mix door motor (driver side)		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M130	2	M50	16	Yes

Is the inspection result normal?

YES >> Replace A/C auto amp. Refer to [HAC-157. "Removal and Installation"](#).

NO >> Repair harness or connector.

B2634, B2635 AIR MIX DOOR MOTOR (PASSENGER SIDE)

< DTC/CIRCUIT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONING]

B2634, B2635 AIR MIX DOOR MOTOR (PASSENGER SIDE)

DTC Logic

INFOID:000000008179982

DTC DETECTION LOGIC

DTC	Items (CONSULT screen terms)	DTC detection condition	Possible cause
B2634	PASS AIR MIX DOOR MOT	Air mix door motor (passenger side) PBR position 95% or more	<ul style="list-style-type: none"> Air mix door motor (passenger side) (PBR internal circuit is open or shorted) Air mix door motor (passenger side) installation condition A/C auto amp. Harness and connector (LIN communication line is open or shorted)
B2635		Air mix door motor (passenger side) PBR position 5% or less	

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

With CONSULT

- Turn ignition switch ON.
- Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
- Check if any DTC No. is displayed in the self-diagnosis results.

Is DTC detected?

YES >> Refer to [HAC-101, "Diagnosis Procedure"](#).

NO >> Inspection End.

Diagnosis Procedure

INFOID:000000008179983

Regarding Wiring Diagram information, refer to [HAC-47, "Wiring Diagram"](#).

1. CHECK AIR MIX DOOR MOTOR (PASSENGER SIDE) COMMUNICATION SIGNAL

- Turn ignition switch ON.
- Check output waveform between front air mix door motor RH harness connector and ground with the oscilloscope.

+		-	Output waveform
Air mix door motor (passenger side)			
Connector	Terminal		
M131	2	Ground	

Is the inspection result normal?

YES >> GO TO 2.

NO >> GO TO 3.

2. CHECK INSTALLATION OF AIR MIX DOOR MOTOR (PASSENGER SIDE)

B2634, B2635 AIR MIX DOOR MOTOR (PASSENGER SIDE)

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

Check air mix door motor (passenger side) is properly installed. Refer to [HAC-164. "Exploded View - Front Door Motors"](#).

Is the inspection result normal?

YES >> Replace air mix door motor (passenger side). Refer to [HAC-165. "AIR MIX DOOR MOTOR : Removal and Installation - Air Mix Door Motor \(Passenger Side\)"](#).

NO >> Repair or replace malfunctioning part.

3. CHECK AIR MIX DOOR MOTOR (PASSENGER SIDE) COMMUNICATION SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect air mix door motor (passenger side) and A/C auto amp. connector.
3. Check continuity between air mix door motor (passenger side) harness connector and A/C auto amp. harness connector.

Air mix door motor (passenger side)		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M131	2	M50	16	Yes

Is the inspection result normal?

YES >> Replace A/C auto amp. Refer to [HAC-157. "Removal and Installation"](#).

NO >> Repair harness or connector.

B2636, B2637, B2638, B2639, B2654 MODE DOOR MOTOR (FRONT)

< DTC/CIRCUIT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONING]

B2636, B2637, B2638, B2639, B2654 MODE DOOR MOTOR (FRONT)

DTC Logic

INFOID:000000008179984

DTC DETECTION LOGIC

DTC	Items (CONSULT screen terms)	DTC detection condition	Possible cause
B2636	DR VENT DOOR FAIL	When the malfunctioning door position is detected at VENT position	<ul style="list-style-type: none"> Mode door motor (front) (PBR internal circuit is open or shorted) Mode door motor (front) control linkage installation condition A/C auto amp. Harness and connector (LIN communication line is open or shorted)
B2637	DR B/L DOOR FAIL	When the malfunctioning door position is detected at B/L position	
B2638	DR D/F1 DOOR FAIL	When the malfunctioning door position is detected at FOOT position	
B2639	DR DEF DOOR FAIL	When the malfunctioning door position is detected at DEF position	
B2654	D/F2 VENT DOOR FAIL	When the malfunctioning door position is detected at D/F position	

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

Ⓜ With CONSULT

- Turn ignition switch ON.
- Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
- Check if any DTC No. is displayed in the self-diagnosis results.

Is DTC detected?

- YES >> Refer to [HAC-103, "Diagnosis Procedure"](#).
- NO >> Inspection End.

Diagnosis Procedure

INFOID:000000008179985

Regarding Wiring Diagram information, refer to [HAC-47, "Wiring Diagram"](#).

1. CHECK MODE DOOR MOTOR (FRONT) COMMUNICATION SIGNAL

- Turn ignition switch ON.
- Check output waveform between mode door motor (front) harness connector and ground with the oscilloscope.

+		-	Output waveform
Mode door motor (front)			
Connector	Terminal		
M129	2	Ground	

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> GO TO 3.

B2636, B2637, B2638, B2639, B2654 MODE DOOR MOTOR (FRONT)

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

2. CHECK INSTALLATION OF MODE DOOR MOTOR (FRONT)

Check mode door motor (front) is properly installed. Refer to [HAC-164, "Exploded View - Front Door Motors"](#).

Is the inspection result normal?

YES >> Replace mode door motor (front). Refer to [HAC-165, "MODE DOOR MOTOR : Removal and Installation - Mode Door Motor \(Front\)"](#).

NO >> Repair or replace malfunctioning part.

3. CHECK MODE DOOR MOTOR (FRONT) COMMUNICATION SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect mode door motor (front) and A/C auto amp. connector.
3. Check continuity between mode door motor (front) harness connector and A/C auto amp. harness connector.

Mode door motor (front)		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M129	2	M50	16	Yes

Is the inspection result normal?

YES >> Replace A/C auto amp. Refer to [HAC-157, "Removal and Installation"](#).

NO >> Repair harness or connector.

B263D, B263E, B263F INTAKE DOOR MOTOR

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

B263D, B263E, B263F INTAKE DOOR MOTOR

DTC Logic

INFOID:000000008179986

DTC DETECTION LOGIC

DTC	Items (CONSULT screen terms)	DTC detection condition	Possible cause
B263D	FRE DOOR FAIL	When the malfunctioning intake door position is detected at FRE position	<ul style="list-style-type: none"> Intake door motor (PBR internal circuit is open or shorted) A/C auto amp. Harness and connector (LIN communication line is open or shorted)
B263E	20P FRE DOOR FAIL	When the malfunctioning intake door position is detected at 20% FRE position	
B263F	REC DOOR FAIL	When the malfunctioning intake door position is detected at REC position	

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

Ⓟ With CONSULT

- Turn ignition switch ON.
- Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
- Check if any DTC No. is displayed in the self-diagnosis results.

Is DTC detected?

- YES >> Refer to [HAC-105. "Diagnosis Procedure"](#).
 NO >> Inspection End.


Diagnosis Procedure

INFOID:000000008179987

Regarding Wiring Diagram information, refer to [HAC-47. "Wiring Diagram"](#).

1. CHECK INTAKE DOOR MOTOR COMMUNICATION SIGNAL

- Turn ignition switch ON.
- Check output waveform between intake door motor harness connector and ground with the oscilloscope.

+		-	Output waveform
Intake door motor			
Connector	Terminal		
M128	2	Ground	 <p style="text-align: right;">SJIA1453J</p>

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> GO TO 3.

2. CHECK INSTALLATION OF INTAKE DOOR MOTOR

Check intake door motor is properly installed. Refer to [HAC-164. "Exploded View - Front Door Motors"](#).

Is the inspection result normal?

B263D, B263E, B263F INTAKE DOOR MOTOR

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

- YES >> Replace intake door motor. Refer to [HAC-166, "INTAKE DOOR MOTOR : Removal and Installation"](#).
- NO >> Repair or replace malfunctioning part.

3. CHECK INTAKE DOOR MOTOR COMMUNICATION SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect intake door motor and A/C auto amp. connector.
3. Check continuity between intake door motor harness connector and A/C auto amp. harness connector.

Intake door motor		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M128	2	M50	16	Yes

Is the inspection result normal?

- YES >> Replace A/C auto amp. Refer to [HAC-157, "Removal and Installation"](#).
- NO >> Repair harness or connector.

B2799, B279A AIR MIX DOOR MOTOR (REAR)

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

B2799, B279A AIR MIX DOOR MOTOR (REAR)

DTC Logic

INFOID:000000008179990

DTC DETECTION LOGIC

DTC	Items (CONSULT screen terms)	DTC detection condition	Possible cause
B2664	REAR AIR MIX DOOR MOT	Air mix door motor (rear) PBR position 95% or more	<ul style="list-style-type: none"> Air mix door motor (rear) (PBR internal circuit is open or shorted) Air mix door motor (rear) installation condition A/C auto amp. Harness and connector (LIN communication line is open or shorted)
B2665		Air mix door motor (rear) PBR position 5% or less	

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

With CONSULT

- Turn ignition switch ON.
- Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
- Check if any DTC No. is displayed in the self-diagnosis results.

Is DTC detected?

- YES >> Refer to [HAC-107, "Diagnosis Procedure"](#).
 NO >> Inspection End.

Diagnosis Procedure

INFOID:000000008179991

Regarding Wiring Diagram information, refer to [HAC-47, "Wiring Diagram"](#).

1. CHECK AIR MIX DOOR MOTOR (REAR) COMMUNICATION SIGNAL

- Turn ignition switch ON.
- Check output waveform between air mix door motor (rear) harness connector and ground with the oscilloscope.

+		-	Output waveform
Air mix door motor (rear)			
Connector	Terminal		
M132	2	Ground	

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> GO TO 3.

2. CHECK INSTALLATION OF AIR MIX DOOR MOTOR (REAR)

Check air mix door motor (rear) is properly installed. Refer to [HAC-164, "Exploded View - Front Door Motors"](#).

B2799, B279A AIR MIX DOOR MOTOR (REAR)

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES >> Replace air mix door motor (rear). Refer to [HAC-165, "AIR MIX DOOR MOTOR : Removal and Installation - Air Mix Door Motor \(Driver Side\)"](#).
- NO >> Repair or replace malfunctioning part.

3. CHECK AIR MIX DOOR MOTOR (REAR) COMMUNICATION SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect air mix door motor (rear) and A/C auto amp. connector.
3. Check continuity between air mix door motor (rear) harness connector and A/C auto amp. harness connector.

Air mix door motor (rear)		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M132	2	M50	16	Yes

Is the inspection result normal?

- YES >> Replace A/C auto amp. Refer to [HAC-157, "Removal and Installation"](#).
- NO >> Repair harness or connector.

B279B, B279C MODE DOOR MOTOR (REAR)

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

B279B, B279C MODE DOOR MOTOR (REAR)

DTC Logic

INFOID:000000008179992

DTC DETECTION LOGIC

DTC	Items (CONSULT screen terms)	DTC detection condition	Possible cause
B279B	REAR MODE DOOR MOT	When the malfunctioning door position is detected at VENT position	<ul style="list-style-type: none"> Mode door motor (rear) (PBR internal circuit is open or shorted) A/C auto amp. Harness and connector (LIN communication line is open or shorted)
B279C		When the malfunctioning door position is detected at FOOT position	

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

ⓐ With CONSULT

- Turn ignition switch ON.
- Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
- Check if any DTC No. is displayed in the self-diagnosis results.

Is DTC detected?

- YES >> Refer to [HAC-109, "Diagnosis Procedure"](#).
 NO >> Inspection End.

Diagnosis Procedure


INFOID:000000008179993

HAC

Regarding Wiring Diagram information, refer to [HAC-47, "Wiring Diagram"](#).

1. CHECK MODE DOOR MOTOR (REAR) COMMUNICATION SIGNAL

- Turn ignition switch ON.
- Check output waveform between mode door motor (rear) harness connector and ground with the oscilloscope.

+		-	Output waveform
Mode door motor (rear)	Terminal		
Connector	Terminal		
M13	2	Ground	

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> GO TO 3.

2. CHECK INSTALLATION OF MODE DOOR MOTOR (REAR)

Check mode door motor (rear) is properly installed. Refer to [HAC-164, "Exploded View - Front Door Motors"](#).

Is the inspection result normal?

B279B, B279C MODE DOOR MOTOR (REAR)

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

- YES >> Replace mode door motor (rear). Refer to [HAC-166. "REAR SHUT-OFF DOOR MOTOR : Removal and Installation"](#).
- NO >> Repair or replace malfunctioning part.

3. CHECK MODE DOOR MOTOR (REAR) COMMUNICATION SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect mode door motor (rear) and A/C auto amp. connector.
3. Check continuity between mode door motor (rear) harness connector and A/C auto amp. harness connector.

Mode door motor (rear)		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M13	2	M50	16	Yes

Is the inspection result normal?

- YES >> Replace A/C auto amp. Refer to [HAC-157. "Removal and Installation"](#).
- NO >> Repair harness or connector.

B279D, B279E REAR SHUT-OFF DOOR MOTOR

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

B279D, B279E REAR SHUT-OFF DOOR MOTOR

DTC Logic

INFOID:000000008212515

DTC DETECTION LOGIC

DTC	Items (CONSULT screen terms)	DTC detection condition	Possible cause
B279D	REAR SHUT DOOR MOT	When the malfunctioning door position is detected at open position	<ul style="list-style-type: none"> Rear shut door motor (PBR internal circuit is open or shorted) A/C auto amp. Harness and connector (LIN communication line is open or shorted)
B279E		When the malfunctioning door position is detected at closed position	

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

Ⓜ With CONSULT

- Turn ignition switch ON.
- Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
- Check if any DTC No. is displayed in the self-diagnosis results.

Is DTC detected?

- YES >> Refer to [HAC-111, "Diagnosis Procedure"](#).
 NO >> Inspection End.

Diagnosis Procedure

INFOID:000000008212516

HAC

Regarding Wiring Diagram information, refer to [HAC-47, "Wiring Diagram"](#).

1. CHECK REAR SHUT-OFF DOOR MOTOR COMMUNICATION SIGNAL

- Turn ignition switch ON.
- Check output waveform between rear shut-off door motor harness connector and ground with the oscilloscope.

+		-	Output waveform
Mode door motor (rear)			
Connector	Terminal		
M12	2	Ground	

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> GO TO 3.

2. CHECK INSTALLATION OF REAR SHUT-OFF DOOR MOTOR

Check rear shut-off door motor is properly installed. Refer to [HAC-164, "Exploded View - Front Door Motors"](#).

Is the inspection result normal?

B279D, B279E REAR SHUT-OFF DOOR MOTOR

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

- YES >> Replace shut-off door motor. Refer to [HAC-166. "REAR SHUT-OFF DOOR MOTOR : Removal and Installation"](#).
- NO >> Repair or replace malfunctioning part.

3. CHECK MODE DOOR MOTOR (REAR) COMMUNICATION SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear shut-off door motor and A/C auto amp. connector.
3. Check continuity between rear shut-off door motor harness connector and A/C auto amp. harness connector.

Rear shut-off door motor		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M12	2	M50	16	Yes

Is the inspection result normal?

- YES >> Replace A/C auto amp. Refer to [HAC-157. "Removal and Installation"](#).
- NO >> Repair harness or connector.

B2796, B2797, B2798 COMMUNICATION ERROR

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

B2796, B2797, B2798 COMMUNICATION ERROR

DTC Logic

INFOID:000000008212517

DTC DETECTION LOGIC

DTC	Items (CONSULT screen terms)	DTC detection condition	Possible cause
B2796	Communication error	When A/C auto amp. is not transmitting or receiving communication signal for 2 or more seconds.	<ul style="list-style-type: none"> • Rear control unit • A/C auto amp. • Harness and connector (Communication line is open or shorted)
B2797		When display unit is not transmitting or receiving communication signal for 2 or more seconds.	
B2798		When rear control unit is not transmitting or receiving communication signal for 2 or more seconds.	

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

 With CONSULT

1. Turn ignition switch ON.
2. Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
3. Check if any DTC No. is displayed in the self-diagnosis results.

Is DTC detected?

- YES >> Refer to [HAC-113. "Diagnosis Procedure"](#).
 NO >> Inspection End.

Diagnosis Procedure

INFOID:000000008242328

Regarding Wiring Diagram information, refer to [HAC-47. "Wiring Diagram"](#).

1. CHECK COMMUNICATION SIGNAL CIRCUIT (A/C AUTO AMP. → REAR AIR CONTROL) FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect rear air control and A/C auto amp. connector.
3. Check continuity between rear air control harness connector and A/C auto amp. harness connector.

Rear air control		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M258	9	M50	5	Yes

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair harness or connector.

2. CHECK COMMUNICATION SIGNAL CIRCUIT (A/C AUTO AMP. → REAR AIR CONTROL) FOR SHORT

Check continuity between rear air control harness connector and ground.

Rear air control		—	Continuity
Connector	Terminal		
M258	9	Ground	No

Is the inspection result normal?

- YES >> GO TO 3.

B2796, B2797, B2798 COMMUNICATION ERROR

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair harness or connector.

3. CHECK COMMUNICATION SIGNAL CIRCUIT (REAR AIR CONTROL → A/C AUTO AMP.) CIRCUIT FOR OPEN

Check continuity between rear air control harness connector and A/C auto amp. harness connector.

Rear air control		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M258	10	M50	25	Yes

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair harness or connector.

4. CHECK COMMUNICATION SIGNAL CIRCUIT (REAR AIR CONTROL → A/C AUTO AMP.) CIRCUIT FOR SHORT

Check continuity between rear air control harness connector and ground.

Rear air control		—	Continuity
Connector	Terminal		
M258	10	Ground	No

Is the inspection result normal?

YES >> Replace A/C auto amp. Refer to [HAC-157. "Removal and Installation"](#).

NO >> Repair harness or connector.

B27B0 A/C AUTO AMP.

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

B27B0 A/C AUTO AMP.

DTC Logic

INFOID:000000008180000

DTC DETECTION LOGIC

NOTE:

- If DTC is displayed along with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [HAC-82, "DTC Logic"](#).
- If DTC is displayed along with DTC U1010, first perform the trouble diagnosis for DTC U1010. [HAC-83, "DTC Logic"](#).

DTC	Items (CONSULT screen terms)	DTC detection condition	Possible cause
B27B0	A/C AUTO AMP.	A/C auto amp. EEPROM system is malfunctioning.	A/C auto amp.

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

Ⓟ With CONSULT

1. Turn ignition switch ON.
2. Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
3. Check if any DTC No. is displayed in the self-diagnosis results.

Is DTC detected?

- YES >> Refer to [HAC-115, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000008180001

HAC

1. PERFORM SELF DIAGNOSTIC

Ⓟ With CONSULT

1. Turn ignition switch ON.
2. Select "Self Diagnostic Result" mode of "HVAC" using CONSULT.
3. Touch "ERASE".
4. Turn ignition switch OFF.
5. Turn ignition switch ON.
6. Perform "DTC CONFIRMATION PROCEDURE". Refer to [HAC-115, "DTC Logic"](#).

Is DTC detected again?

- YES >> Replace A/C auto amp. Refer to [HAC-157, "Removal and Installation"](#).
NO >> Inspection End.

POWER SUPPLY AND GROUND CIRCUIT

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

POWER SUPPLY AND GROUND CIRCUIT

A/C AUTO AMP.

A/C AUTO AMP. : Diagnosis Procedure

INFOID:000000008180002

Regarding Wiring Diagram information, refer to [HAC-47. "Wiring Diagram"](#).

1. CHECK FUSE

Check fuses [No. 14 and 30, located in the fuse block (J/B)].

NOTE:

Refer to [PG-83. "Terminal Arrangement"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace the blown fuse after repairing the affected circuit.

2. CHECK A/C AUTO AMP. POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect A/C auto amp. connector.
3. Check voltage between A/C auto amp. harness connector and ground.

+		-	Voltage		
A/C auto amp.			Ignition switch position		
Connector	Terminal		OFF	ACC	ON
M50	23	Ground	Approx. 0 V	Approx. 0 V	Battery voltage
	3		Battery voltage	Battery voltage	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector between A/C auto amp. and fuse block (J/B).

3. CHECK A/C AUTO AMP. GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between A/C auto amp. harness connector and ground.

A/C auto amp.		—	Continuity
Connector	Terminal		
M50	2	Ground	Yes
	22		

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair harness or connector.

AIR MIX DOOR MOTOR (DRIVER SIDE)

AIR MIX DOOR MOTOR (DRIVER SIDE) : Diagnosis Procedure

INFOID:000000008180003

Regarding Wiring Diagram information, refer to [HAC-47. "Wiring Diagram"](#).

1. CHECK AIR MIX DOOR MOTOR (DRIVER SIDE) POWER SUPPLY

1. Turn ignition switch ON.
2. Check voltage between air mix door motor (driver side) harness connector and ground.

POWER SUPPLY AND GROUND CIRCUIT

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

+		-	Voltage (Approx.)
Connector	Terminal		
M130	1	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 2.

NO >> GO TO 4.

2. CHECK AIR MIX DOOR MOTOR (DRIVER SIDE) GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect air mix door motor (driver side) connector.
3. Check continuity between air mix door motor (driver side) harness connector and ground.

Air mix door motor (driver side)		—	Continuity
Connector	Terminal		
M130	3	Ground	Yes

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3. CHECK INSTALLATION OF AIR MIX DOOR MOTOR (DRIVER SIDE)

Check air mix door motor (driver side) is properly installed. Refer to [HAC-164, "Exploded View - Front Door Motors"](#).

Is the inspection result normal?

YES >> Replace air mix door motor (driver side). Refer to [HAC-165, "AIR MIX DOOR MOTOR : Removal and Installation - Air Mix Door Motor \(Driver Side\)"](#).

NO >> Repair or replace malfunctioning part.

4. CHECK AIR MIX DOOR MOTOR (DRIVER SIDE) POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect air mix door motor (driver side) connector and A/C auto amp. connector.
3. Check continuity between air mix door motor (driver side) harness connector and A/C auto amp. harness connector.

Air mix door motor (driver side)		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M130	1	M50	17	Yes

Is the inspection result normal?

YES >> Replace A/C auto amp. Refer to [HAC-157, "Removal and Installation"](#).

NO >> Repair harness or connector.

AIR MIX DOOR MOTOR (PASSENGER SIDE)

AIR MIX DOOR MOTOR (PASSENGER SIDE) : Diagnosis Procedure

INFOID:000000008180004

Regarding Wiring Diagram information, refer to [HAC-47, "Wiring Diagram"](#).

1. CHECK AIR MIX DOOR MOTOR (PASSENGER SIDE) POWER SUPPLY

1. Turn ignition switch ON.
2. Check voltage between air mix door motor (passenger side) harness connector and ground.

POWER SUPPLY AND GROUND CIRCUIT

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

+		-	Voltage (Approx.)
Connector	Terminal		
M131	1	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 2.

NO >> GO TO 4.

2. CHECK AIR MIX DOOR MOTOR (PASSENGER SIDE) GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect air mix door motor (passenger side) connector.
3. Check continuity between air mix door motor (passenger side) harness connector and ground.

Air mix door motor (passenger side)		—	Continuity
Connector	Terminal		
M131	3	Ground	Yes

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3. CHECK INSTALLATION OF AIR MIX DOOR MOTOR (PASSENGER SIDE)

Check air mix door motor (passenger side) is properly installed. Refer to [HAC-164, "Exploded View - Front Door Motors"](#).

Is the inspection result normal?

YES >> Replace air mix door motor (passenger side). Refer to [HAC-165, "AIR MIX DOOR MOTOR : Removal and Installation - Air Mix Door Motor \(Passenger Side\)"](#).

NO >> Repair or replace malfunctioning part.

4. CHECK AIR MIX DOOR MOTOR (PASSENGER SIDE) POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect air mix door motor (passenger side) connector and A/C auto amp. connector.
3. Check continuity between air mix door motor (passenger side) harness connector and A/C auto amp. harness connector.

Air mix door motor (passenger side)		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M131	1	M50	17	Yes

Is the inspection result normal?

YES >> Replace A/C auto amp. Refer to [HAC-157, "Removal and Installation"](#).

NO >> Repair harness or connector.

AIR MIX DOOR MOTOR (REAR)

AIR MIX DOOR MOTOR (REAR) : Diagnosis Procedure

INFOID:000000008180007

Regarding Wiring Diagram information, refer to [HAC-47, "Wiring Diagram"](#).

1. CHECK AIR MIX DOOR MOTOR (REAR) POWER SUPPLY

1. Turn ignition switch ON.
2. Check voltage between air mix door motor (rear) harness connector and ground.

POWER SUPPLY AND GROUND CIRCUIT

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

+		-	Voltage (Approx.)
Connector	Terminal		
M132	1	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> GO TO 4.

2. CHECK AIR MIX DOOR MOTOR (REAR) GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect air mix door motor (rear) connector.
3. Check continuity between air mix door motor (rear) harness connector and ground.

Air mix door motor (rear)		—	Continuity
Connector	Terminal		
M132	3	Ground	Yes

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair harness or connector.

3. CHECK INSTALLATION OF AIR MIX DOOR MOTOR (REAR)

Check air mix door motor (rear) is properly installed.

Is the inspection result normal?

- YES >> Replace air mix door motor (rear). Refer to [HAC-165. "AIR MIX DOOR MOTOR : Removal and Installation - Air Mix Door Motor \(Rear\)"](#).
- NO >> Repair or replace malfunctioning part.

4. CHECK AIR MIX DOOR MOTOR (REAR) POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect air mix door motor (rear) connector and A/C auto amp. connector.
3. Check continuity between air mix door motor (rear) harness connector and A/C auto amp. harness connector.

Air mix door motor (rear)		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M132	1	M50	17	Yes

Is the inspection result normal?

- YES >> Replace A/C auto amp. Refer to [HAC-157. "Removal and Installation"](#).
- NO >> Repair harness or connector.

MODE DOOR MOTOR (FRONT)

MODE DOOR MOTOR (FRONT) : Diagnosis Procedure

INFOID:000000008180005

Regarding Wiring Diagram information, refer to [HAC-47. "Wiring Diagram"](#).

1. CHECK MODE DOOR MOTOR (FRONT) POWER SUPPLY

1. Turn ignition switch ON.
2. Check voltage between mode door motor (front) harness connector and ground.

POWER SUPPLY AND GROUND CIRCUIT

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

+		-	Voltage (Approx.)
Connector	Terminal		
M129	1	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 2.

NO >> GO TO 4.

2. CHECK MODE DOOR MOTOR (FRONT) GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect mode door motor (front) connector.
3. Check continuity between mode door motor (front) harness connector and ground.

Mode door motor (front)		—	Continuity
Connector	Terminal		
M129	3	Ground	Yes

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3. CHECK INSTALLATION OF MODE DOOR MOTOR (FRONT) CONTROL LINKAGE

Check mode door motor (front) control linkage is properly installed. Refer to [HAC-164, "Exploded View - Front Door Motors"](#).

Is the inspection result normal?

YES >> Replace mode door motor (front). Refer to [HAC-165, "MODE DOOR MOTOR : Removal and Installation - Mode Door Motor \(Front\)"](#).

NO >> Repair or replace malfunctioning part.

4. CHECK MODE DOOR MOTOR (FRONT) POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect mode door motor (front) connector and A/C auto amp. connector.
3. Check continuity between mode door motor (front) harness connector and A/C auto amp. harness connector.

Mode door motor (front)		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M129	1	M50	17	Yes

Is the inspection result normal?

YES >> Replace A/C auto amp. Refer to [HAC-157, "Removal and Installation"](#).

NO >> Repair harness or connector.

MODE DOOR MOTOR (REAR)

MODE DOOR MOTOR (REAR) : Diagnosis Procedure

INFOID:000000008180009

Regarding Wiring Diagram information, refer to [HAC-47, "Wiring Diagram"](#).

1. CHECK MODE DOOR MOTOR (REAR) POWER SUPPLY

1. Turn ignition switch ON.
2. Check voltage between mode door motor (rear) harness connector and ground.

POWER SUPPLY AND GROUND CIRCUIT

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

+		-	Voltage (Approx.)
Mode door motor (rear)			
Connector	Terminal		
M13	1	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> GO TO 4.

2. CHECK MODE DOOR MOTOR (REAR) GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect mode door motor (rear) connector.
3. Check continuity between mode door motor (rear) harness connector and ground.

Mode door motor (rear)		—	Continuity
Connector	Terminal		
M13	3	Ground	Yes

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair harness or connector.

3. CHECK INSTALLATION OF MODE DOOR MOTOR (REAR)

Check mode door motor (rear) is properly installed. Refer to [HAC-164. "Exploded View - Front Door Motors"](#).

Is the inspection result normal?

- YES >> Replace mode door motor (rear). Refer to [HAC-166. "REAR SHUT-OFF DOOR MOTOR : Removal and Installation"](#).
- NO >> Repair or replace malfunctioning part.

4. CHECK MODE DOOR MOTOR (REAR) POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect mode door motor (rear) connector and A/C auto amp. connector.
3. Check continuity between mode door motor (rear) harness connector and A/C auto amp. harness connector.

Mode door motor (rear)		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M13	1	M50	17	Yes

Is the inspection result normal?

- YES >> Replace A/C auto amp. Refer to [HAC-157. "Removal and Installation"](#).
- NO >> Repair harness or connector.

INTAKE DOOR MOTOR

INTAKE DOOR MOTOR : Diagnosis Procedure

INFOID:000000008180006

Regarding Wiring Diagram information, refer to [HAC-47. "Wiring Diagram"](#).

1. CHECK INTAKE MODE DOOR MOTOR POWER SUPPLY

1. Turn ignition switch ON.
2. Check voltage between intake mode door motor harness connector and ground.

POWER SUPPLY AND GROUND CIRCUIT

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

+		-	Voltage (Approx.)
Intake mode door motor Connector	Terminal		
M128	1	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> GO TO 4.

2. CHECK INTAKE MODE DOOR MOTOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect intake mode door motor connector.
3. Check continuity between intake mode door motor harness connector and ground.

Intake mode door motor		—	Continuity
Connector	Terminal		
M128	3	Ground	Yes

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair harness or connector.

3. CHECK INSTALLATION OF INTAKE MODE DOOR MOTOR

Check intake mode door motor is properly installed. Refer to [HAC-164, "Exploded View - Front Door Motors"](#).

Is the inspection result normal?

- YES >> Replace intake mode door motor. Refer to [HAC-166, "INTAKE DOOR MOTOR : Removal and Installation"](#).
- NO >> Repair or replace malfunctioning part.

4. CHECK INTAKE MODE DOOR MOTOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect intake mode door motor connector and A/C auto amp. connector.
3. Check continuity between intake mode door motor harness connector and A/C auto amp. harness connector.

Intake mode door motor		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M128	1	M50	17	Yes

Is the inspection result normal?

- YES >> Replace A/C auto amp. Refer to [HAC-157, "Removal and Installation"](#).
- NO >> Repair harness or connector.

REAR SHUT-OFF DOOR MOTOR

REAR SHUT-OFF DOOR MOTOR : Diagnosis Procedure

INFOID:000000008180010

Regarding Wiring Diagram information, refer to [HAC-47, "Wiring Diagram"](#).

1. CHECK SHUT-OFF DOOR MOTOR POWER SUPPLY

1. Turn ignition switch ON.
2. Check voltage between shut-off door motor harness connector and ground.

POWER SUPPLY AND GROUND CIRCUIT

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

+		-	Voltage (Approx.)
Shut-off door motor			
Connector	Terminal		
M12	1	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 2.

NO >> GO TO 4.

2. CHECK SHUT-OFF DOOR MOTOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect shut-off door motor connector.
3. Check continuity between shut-off door motor harness connector and ground.

Shut-off door motor		—	Continuity
Connector	Terminal		
M12	3	Ground	Yes

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3. CHECK INSTALLATION OF SHUT-OFF DOOR MOTOR

Check shut-off door motor is properly installed. Refer to [HAC-164, "Exploded View - Front Door Motors"](#).

Is the inspection result normal?

YES >> Replace shut-off door motor. Refer to [HAC-166, "REAR SHUT-OFF DOOR MOTOR : Removal and Installation"](#).

NO >> Repair or replace malfunctioning part.

4. CHECK SHUT-OFF DOOR MOTOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect shut-off door motor connector and A/C auto amp. connector.
3. Check continuity between shut-off door motor harness connector and A/C auto amp. harness connector.

Shut-off door motor		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M12	1	M50	17	Yes

Is the inspection result normal?

YES >> Replace A/C auto amp. Refer to [HAC-157, "Removal and Installation"](#).

NO >> Repair harness or connector.

REAR A/C CONTROL

REAR A/C CONTROL : Diagnosis Procedure

INFOID:000000008180008

Regarding Wiring Diagram information, refer to [HAC-47, "Wiring Diagram"](#).

1. CHECK FUSE

Check 10A fuse [No. 30, located in the fuse block (J/B)].

NOTE:

Refer to [PG-83, "Terminal Arrangement"](#).

Is the inspection result normal?

YES >> GO TO 2.

POWER SUPPLY AND GROUND CIRCUIT

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Replace the blown fuse after repairing the affected circuit.

2. CHECK REAR AIR CONTROL POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect rear air control connector.
3. Turn ignition switch ON.
4. Check voltage between rear air control harness connector and ground.

+		-	Voltage (Approx.)
Rear air control			
Connector	Terminal		
M258	12	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector between rear air control and fuse block (J/B).

3. CHECK REAR AIR CONTROL GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between rear air control harness connector and ground.

Rear air control		—	Continuity
Connector	Terminal		
M258	1	Ground	Yes

Is the inspection result normal?

YES >> Replace rear air control. Refer to [HAC-156. "Removal and Installation"](#).

NO >> Repair harness or connector.

DOOR MOTOR

Diagnosis Procedure

INFOID:000000008180011

Regarding Wiring Diagram information, refer to [HAC-47, "Wiring Diagram"](#).

1. CHECK EACH DOOR MOTOR POWER SUPPLY

1. Turn ignition switch ON.
2. Check voltage between intake door motor harness connector and ground.

+		-	Voltage (Approx.)
Intake door motor			
Connector	Terminal		
M128	1	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> GO TO 3.

2. CHECK EACH DOOR MOTOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect intake door motor connector.
3. Check continuity between intake door motor harness connector and ground.

Intake door motor		—	Continuity
Connector	Terminal		
M128	3	Ground	Yes

Is the inspection result normal?

- YES >> Inspection End.
 NO >> Repair harness or connector.

3. CHECK EACH DOOR MOTOR POWER SUPPLY CIRCUIT FOR OPEN

1. Disconnect A/C auto amp. connector.
2. Check continuity between intake door motor harness connector and A/C auto amp. harness connector.

Intake door motor		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M128	1	M50	17	Yes

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair harness or connector.

4. CHECK EACH DOOR MOTOR POWER SUPPLY CIRCUIT FOR SHORT

1. Disconnect following connectors.
 - Air mix door motor (driver side)
 - Air mix door motor (passenger side)
 - Mode door motor (front)
 - Rear shut-off door motor
 - Air mix door motor (rear)
 - Mode door motor (rear)
2. Check continuity between intake door motor harness connector and ground.

DOOR MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONING]

Intake door motor		—	Continuity
Connector	Terminal		
M128	1	Ground	No

Is the inspection result normal?

YES >> Replace A/C auto amp. Refer to [HAC-157, "Removal and Installation"](#).

NO >> Repair harness or connector.

DOOR MOTOR COMMUNICATION CIRCUIT

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

DOOR MOTOR COMMUNICATION CIRCUIT

Diagnosis Procedure

INFOID:000000008180012

Regarding Wiring Diagram information, refer to [HAC-47, "Wiring Diagram"](#).

NOTE:

If all of door motor DTCs are detected, check this circuit.

1. CHECK EACH DOOR MOTOR COMMUNICATION SIGNAL

1. Turn ignition switch ON.
2. Check output waveform between A/C auto amp. harness connector and ground with the oscilloscope.

+		-	Output waveform
A/C auto amp.			
Connector	Terminal		
M50	16	Ground	

Is the inspection result normal?

- YES >> GO TO 2.
NO >> GO TO 3.

2. CHECK EACH DOOR MOTOR COMMUNICATION SIGNAL CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect A/C auto amp. connector and intake door motor connector.
3. Check continuity between A/C auto amp. harness connector and intake door motor harness connector.

A/C auto amp.		Intake door motor		Continuity
Connector	Terminal	Connector	Terminal	
M50	16	M128	2	Yes

Is the inspection result normal?

- YES >> Inspection End.
NO >> Repair harness or connector.

3. CHECK EACH DOOR MOTOR COMMUNICATION SIGNAL CIRCUIT FOR SHORT

1. Disconnect following connectors.
 - Air mix door motor (driver side)
 - Air mix door motor (passenger side)
 - Mode door motor (front)
 - Rear shut-off door motor
 - Air mix door motor (rear)
 - Mode door motor (rear)
2. Check continuity between A/C auto amp. harness connector and ground.

A/C auto amp.		—	Continuity
Connector	Terminal		
M50	16	Ground	No

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

DOOR MOTOR COMMUNICATION CIRCUIT

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> Replace A/C auto amp. Refer to [HAC-157, "Removal and Installation"](#).

NO >> Repair harness or connector.

FRONT BLOWER MOTOR

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

FRONT BLOWER MOTOR

Diagnosis Procedure

INFOID:000000008180013

Regarding Wiring Diagram information, refer to [HAC-47, "Wiring Diagram"](#).

1. CHECK FUSE

1. Turn ignition switch OFF.
2. Check 15A fuses [Nos. 17 and 27, located in fuse block (J/B)].

NOTE:

Refer to [PG-83, "Terminal Arrangement"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace the blown fuse after repairing the affected circuit.

2. CHECK FRONT BLOWER MOTOR POWER SUPPLY

1. Disconnect front blower motor connector.
2. Turn ignition switch ON.
3. Check voltage between front blower motor harness connector and ground.

+		-	Voltage
Front blower motor			
Connector	Terminal		
M112	4	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 6.

3. CHECK FRONT BLOWER MOTOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between front blower motor harness connector and ground.

Front blower motor		—	Continuity
Connector	Terminal		
M112	1	Ground	Yes

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair harness or connector.

4. CHECK FRONT BLOWER MOTOR CONTROL SIGNAL CIRCUIT

1. Disconnect A/C auto amp. connector.
2. Check continuity between front blower motor harness connector and A/C auto amp. harness connector.

Front blower motor		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M112	3	M50	18	Yes

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair the harness or connector.

5. CHECK FRONT BLOWER MOTOR CONTROL SIGNAL

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

FRONT BLOWER MOTOR

[AUTOMATIC AIR CONDITIONING]


< DTC/CIRCUIT DIAGNOSIS >

1. Reconnect front blower motor connector and A/C auto amp. connector.
2. Turn ignition switch ON.
3. Operate MODE switch to set air outlet to VENT.
4. Change fan speed from Lo to Hi, and check duty ratios between front blower motor harness connector and ground by using an oscilloscope.

NOTE:

Calculate drive signal duty ratio as shown in the figure.
T2 = Approx. 1.6 ms

Front blower motor		Condition	Duty ratio (Approx.)
Connector	Terminal	Fan speed (manual) VENT mode	
M112	3	1st	25 %
		2nd	33 %
		3rd	41 %
		4th	51 %
		5th	61 %
		6th	69 %
		7th	81 %



Is the inspection result normal?

YES >> Replace front blower motor. Refer to [VTL-19, "FRONT BLOWER MOTOR : Removal and Installation"](#).

NO >> Replace A/C auto amp. Refer to [HAC-157, "Removal and Installation"](#).

6. CHECK FRONT BLOWER MOTOR RELAY GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between fuse block (J/B) harness connector and ground.

Fuse block (J/B)		—	Continuity
Connector	Terminal		
M68	13R	Ground	Yes

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair harness or connector.

7. CHECK FRONT BLOWER RELAY

Check front blower motor relay. Refer to [HAC-130, "Component Inspection \(Front Blower Motor Relay\)"](#).

Is the inspection result normal?

YES >> Repair harness or connector between front blower motor and fuse block (J/B).

NO >> Replace front blower relay.

Component Inspection (Front Blower Motor)

INFOID:000000008242813

1. CHECK FRONT BLOWER MOTOR

1. Connect battery voltage to terminal 1 of front blower motor.
2. Connect ground to terminal 2 of front blower motor.

Does the front blower fan operate?

YES >> Intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

NO >> Replace front blower motor. Refer to [VTL-19, "FRONT BLOWER MOTOR : Removal and Installation"](#).

Component Inspection (Front Blower Motor Relay)

INFOID:000000008180015

1. CHECK BLOWER RELAY

FRONT BLOWER MOTOR

[AUTOMATIC AIR CONDITIONING]


< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Remove front blower motor relay.
3. Check continuity between front blower motor relay terminals 3 and 5 when voltage is supplied between terminals 1 and 2.

Terminals		Voltage	Continuity
3	5	ON	Yes
		OFF	No

Is the inspection result normal?

- YES >> Inspection End.
NO >> Replace front blower motor relay.



A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

IONIZER

Component Function Check

INFOID:000000008180016

1.CHECK IONIZER OPERATION SOUND

1. Turn ignition switch ON.
2. Check ionizer operation sound (whirring sound) in duct by putting an ear to the side ventilator grille (driver side) outlet while pressing fan switch and OFF switch alternately.

Is the inspection result normal?

- YES >> Inspection End.
 NO >> Refer to [HAC-132, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008180017

Regarding Wiring Diagram information, refer to [HAC-47, "Wiring Diagram"](#).

1.CHECK FUSE

1. Turn ignition switch OFF.
2. Check 10A fuse [No.30, located in fuse block (J/B)].

NOTE:

Refer to [PG-83, "Terminal Arrangement"](#).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Replace the blown fuse after repairing the affected circuit.

2.CHECK IONIZER POWER SUPPLY

1. Disconnect ionizer connector.
2. Turn ignition switch ON.
3. Check voltage between ionizer harness connector and ground.

+		-	Voltage (Approx.)
Ionizer			
Connector	Terminal		
M119	1	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair harness or connector between ionizer and fuse block (J/B).

3.CHECK IONIZER GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between ionizer harness connector and ground.

Ionizer		—	Continuity
Connector	Terminal		
M119	3	Ground	Yes

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair harness or connector.

4.CHECK IONIZER (ON/OFF) CONTROL SIGNAL CIRCUIT

1. Connect ionizer connector.
2. Disconnect A/C auto amp. connector.

IONIZER

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

- Turn ignition switch ON.
- Check voltage between A/C auto amp. harness connector and ground.

+		-	Voltage (Approx.)
A/C auto amp.			
Connector	Terminal		
M50	38	Ground	Battery voltage

Is the inspection result normal?

- YES >> Replace A/C auto amp. Refer to [HAC-157, "Removal and Installation"](#).
NO >> GO TO 5.

5. CHECK IONIZER (ON/OFF) CONTROL SIGNAL CIRCUIT FOR OPEN

- Turn ignition switch OFF.
- Disconnect ionizer connector.
- Check continuity between A/C auto amp. harness connector and ionizer harness connector.

A/C auto amp.		Ionizer		Continuity
Connector	Terminal	Connector	Terminal	
M50	38	M119	4	Yes

Is the inspection result normal?

- YES >> GO TO 6.
NO >> Repair harness or connector.

6. CHECK IONIZER (ON/OFF) CONTROL SIGNAL CIRCUIT FOR SHORT

Check continuity between A/C auto amp. harness connector and ground.

A/C auto amp.		—	Continuity
Connector	Terminal		
M50	38	Ground	No

Is the inspection result normal?

- YES >> Replace ionizer. Refer to [HAC-168, "Removal and Installation"](#).
NO >> Repair harness or connector.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

MAGNET CLUTCH

Component Function Check

INFOID:000000008180018

1. CHECK MAGNET CLUTCH OPERATION

Perform auto active test of IPDM E/R. Refer to [PCS-8, "Diagnosis Description"](#).

Does it operate normally?

YES >> Inspection End.

NO >> Refer to [HAC-134, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008180019

Regarding Wiring Diagram information, refer to [HAC-47, "Wiring Diagram"](#).

1. CHECK FUSE

1. Turn ignition switch OFF.
2. Check 10A fuse (No. 53, located in IPDM E/R).

NOTE:

Refer to [PG-84, "Terminal Arrangement"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace the blown fuse after repairing the affected circuit.

2. CHECK MAGNET CLUTCH POWER SUPPLY CIRCUIT

1. Disconnect compressor connector and IPDM E/R connector.
2. Check continuity between compressor harness connector and IPDM E/R harness connector.

Compressor		IPDM E/R		Continuity
Connector	Terminal	Connector	Terminal	
F3	1	F19	56	Yes

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3. CHECK MAGNET CLUTCH GROUND CIRCUIT

1. Disconnect compressor connector.
2. Check continuity between compressor harness connector and ground.

Compressor			Continuity
Connector	Terminal		
F3	2	Ground	Yes

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair harness or connector.

4. CHECK MAGNET CLUTCH

Directly apply battery voltage to the magnet clutch. Check operation visually and by sound.

Does it operate normally?

YES >> Replace IPDM E/R. Refer to [PCS-32, "Removal and Installation"](#).

NO >> Replace magnet clutch. Refer to [HA-32, "MAGNET CLUTCH : Removal and Installation of Compressor Clutch"](#).

PTC HEATER RELAY

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

PTC HEATER RELAY

Description

INFOID:000000008249320

Power is supplied to the PTC heater with A/C auto amp. control.

Component Function Check

INFOID:000000008249321

1. CHECK REAR WINDOW DEFOGGER RELAY POWER SUPPLY CIRCUIT

Check that an operation noise of PTC heater relay (located in relay box) can be heard when operating the rear air conditioning system in heat mode.

Is the inspection result normal?

- YES >> PTC heater relay power supply circuit is OK.
- NO >> Refer to [HAC-135, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008249322

Regarding Wiring Diagram information, refer to [HAC-47, "Wiring Diagram"](#).

1. CHECK PTC HEATER RELAY GROUND CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between A/C auto amp. connector and ground.

Terminals		Voltage (V) (Approx.)	
(+)	(-)		
A/C auto amp.	Terminal	Ground	Battery voltage
M50	19		
	39		

Is the inspection result normal?

- YES >> Replace A/C auto amp. Refer to [HAC-157, "Removal and Installation"](#).
- NO >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect A/C auto amp. and PTC heater relay connector.
3. Check continuity between A/C auto amp. connector and PTC heater relay connector.

A/C auto amp. connector	Terminal	PTC heater relay connector	Terminal	Continuity
M50	19	E11	2	Yes
	39	E12		

4. Check continuity between A/C auto amp. connector and ground.

A/C auto amp. connector	Terminal	Ground	Continuity
M50	19	Ground	No
	39		

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace harness.

3. CHECK PTC HEATER RELAY

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

PTC HEATER RELAY

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

Check PTC heater relay. Refer to [HAC-136. "Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-53. "Intermittent Incident"](#).
- NO >> Replace PTC heater relay.

Component Inspection

INFOID:000000008249325


1. CHECK PTC HEATER RELAY

1. Turn ignition switch OFF.
2. Remove PTC heater relay.
3. Check continuity between PTC heater relay terminal 3 and 5 when voltage is supplied between terminal 1 and 2.

Terminal		Voltage	Continuity
3	5	ON	Yes
		OFF	No

Is the inspection result normal?

- YES >> Inspection End.
- NO >> Replace blower relay.



PTC HEATER

Diagnosis Procedure

INFOID:000000008242833

Regarding Wiring Diagram information, refer to [HAC-47, "Wiring Diagram"](#).

1. CHECK FUSE

1. Turn ignition switch OFF.
2. Check 30A fuse [No. 59 and 60, located in relay box].

NOTE:

Refer to [PG-84, "Terminal Arrangement"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace the blown fuse after repairing the affected circuit.

2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between PTC heater connector and ground.

Terminals		Condition of rear window defogger switch	Voltage (V) (Approx.)
(+)			
PTC heater connector	Terminal	(-)	
M118	1	ON	Battery voltage
		OFF	0
	3	ON	Battery voltage
		OFF	0

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 4.

3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect PTC heater connector.
3. Check continuity between PTC heater connector and ground.

Rear window defogger connector	Terminal	Ground	Continuity
M117	2		
	4		

Is the inspection result normal?

YES >> Replace PTC heater. Refer to [VTL-19, "CENTER BLOWER UNIT : Removal and Installation"](#).

NO >> Repair or replace harness.

4. CHECK HARNESS CONTINUITY

1. Disconnect PTC relay connectors.
2. Check continuity between PTC heater connector and PTC relay connector.

PTC heater connector	Terminal	PTC heater relay connector	Terminal	Continuity

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

PTC HEATER

< DTC/CIRCUIT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONING]

M118	1	E11	5	Yes
	3	E12		

3. Check continuity between PTC heater connector and ground.

PTC heater connector	Terminal	Ground	Continuity
M118	1		Ground
	3		

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

NO >> Replace or repair harness.

REAR BLOWER MOTOR

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

REAR BLOWER MOTOR

Diagnosis Procedure

INFOID:000000008242331

Regarding Wiring Diagram information, refer to [HAC-47, "Wiring Diagram"](#).

REAR BLOWER MOTOR 1

1. CHECK FUSE

Check 20A fuse [No. 70, located in the fuse block (J/B)].

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace the blown fuse after repairing the affected circuit.

2. CHECK POWER SUPPLY FOR BLOWER MOTOR

1. Turn ignition switch ON.
2. Check voltage between rear blower motor harness connector and ground.

(+)		(-)	Voltage (Approx.)
Rear blower motor			
Connector	Terminal	Ground	Battery voltage
M107	1		

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 7.

3. CHECK POWER SUPPLY FOR REAR BLOWER MOTOR RESISTOR 1

Check voltage between rear blower motor resistor 1 harness connector and ground.

(+)		(-)	Voltage (Approx.)
Rear blower motor resistor 1			
Connector	Terminal	Ground	Battery voltage
M104	1		

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 8.

4. CHECK BLOWER MOTOR CONTROL SIGNAL

1. Turn mode control to VENT.
2. Turn fan control to 1st speed.
3. Check voltage between rear blower motor resistor 1 harness connector and ground.

(+)		(-)	Voltage (Approx.)
Rear blower motor resistor 1			
Connector	Terminal	Ground	2.5 V
M104	2		

Is the inspection result normal?

YES >> GO TO 5.

NO-1 >> Less than approximately 2.5 V: GO TO 9.

NO-2 >> More than approximately 10 V: Replace auto amp.

5. CHECK REAR BLOWER MOTOR RESISTOR 1 GROUND CIRCUIT

1. Disconnect rear blower motor resistor 1 connector.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

REAR BLOWER MOTOR

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

2. Check continuity between rear blower motor resistor 1 harness connector and ground.

Rear blower motor resistor 1		—	Continuity
Connector	Terminal		
M104	3	Ground	Yes

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair harness or connector.

6. CHECK BLOWER MOTOR FEEDBACK SIGNAL

1. Reconnect rear blower motor resistor 1 connector.
2. Turn ignition switch ON.
3. Turn fan control to 1st speed.
4. Check voltage between auto amp. harness connector and ground.

(+)		(-)	Condition	Voltage (Approx.)
Auto amp.				
Connector	Terminal			
M50	34	Ground	Blower speed: 1st (Blower motor operating)	10 V

Is the inspection result normal?

YES >> Replace auto amp.

NO >> Repair harness or connector.

7. CHECK POWER SUPPLY OF BLOWER RELAY

1. Turn ignition switch OFF.
2. Remove blower relay.
3. Turn ignition switch ON.
4. Check voltage between rear blower relay connector terminals and ground.

(+)		(-)	Voltage (Approx.)
Rear blower relay			
Connector	Terminal		
M108	1	Ground	Battery voltage
	3		
	6		

Is the inspection result normal?

YES >> Check rear blower motor relay. Refer to [HAC-143, "Component Inspection \(Rear Blower Motor Relay\)"](#).

NO >> Repair harness or connector.

8. CHECK CIRCUIT CONTINUITY BETWEEN BLOWER MOTOR AND REAR BLOWER MOTOR RESISTOR

1

1. Turn ignition switch OFF.
2. Disconnect rear blower motor resistor 1 connector.
3. Check continuity between blower motor harness connector and rear blower motor resistor 1 harness connector.

Blower motor		Rear blower motor resistor 1		Continuity
Connector	Terminal	Connector	Terminal	
M107	2	M104	1	Yes

Is the inspection result normal?

REAR BLOWER MOTOR

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

- YES >> Replace blower motor.
NO >> Repair harness or connector.

9. CHECK REAR BLOWER MOTOR RESISTOR 1

Check rear blower motor resistor 1 Refer to [HAC-143, "Component Inspection \(Rear Blower Motor Relay\)"](#).

Is the inspection result normal?

- YES >> Replace auto amp.
NO >> Replace rear blower motor resistor 1.

REAR BLOWER MOTOR 2

1. CHECK FUSE

Check 20A fuse [Nos. 71, located in the fuse block (J/B)].

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Replace fuse after repairing the affected circuit.

2. CHECK POWER SUPPLY FOR BLOWER MOTOR

1. Turn ignition switch ON.
2. Check voltage between rear blower motor harness connector and ground.

(+)		(-)	Voltage (Approx.)
Rear blower motor			
Connector	Terminal	Ground	Battery voltage
B134	1		

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 7.

3. CHECK POWER SUPPLY FOR REAR BLOWER MOTOR RESISTOR 2

Check voltage between rear blower motor resistor 2 harness connector and ground.

(+)		(-)	Voltage (Approx.)
Rear blower motor resistor 2			
Connector	Terminal	Ground	Battery voltage
B133	1		

Is the inspection result normal?

- YES >> GO TO 4.
NO >> GO TO 8.

4. CHECK BLOWER MOTOR CONTROL SIGNAL

1. Turn mode control to VENT.
2. Turn fan control to 1st speed.
3. Check voltage between rear blower motor resistor 2 harness connector and ground.

(+)		(-)	Voltage (Approx.)
Rear blower motor resistor 2			
Connector	Terminal	Ground	2.5 V
B133	2		

Is the inspection result normal?

- YES >> GO TO 5.
NO-1 >> Less than approximately 2.5 V: GO TO 9.
NO-2 >> More than approximately 10 V: Replace auto amp.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

REAR BLOWER MOTOR

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

5. CHECK REAR BLOWER MOTOR RESISTOR 2 GROUND CIRCUIT

1. Disconnect rear blower motor resistor 2 connector.
2. Check continuity between rear blower motor resistor 2 harness connector and ground.

Rear blower motor resistor 2		—	Continuity
Connector	Terminal		
B133	3	Ground	Yes

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair harness or connector.

6. CHECK BLOWER MOTOR FEEDBACK SIGNAL

1. Reconnect rear blower motor resistor 2 connector.
2. Turn ignition switch ON.
3. Turn fan control to 1st speed.
4. Check voltage between auto amp. harness connector and ground.

(+) Auto amp.		(-)	Condition	Voltage (Approx.)
Connector	Terminal			
M50	32	Ground	Blower speed: 1st (Blower motor operating)	10 V

Is the inspection result normal?

YES >> Replace auto amp.

NO >> Repair harness or connector.

7. CHECK POWER VOLTAGE OF BLOWER RELAY

1. Turn ignition switch OFF.
2. Remove blower relay.
3. Turn ignition switch ON.
4. Check voltage between rear blower relay connector terminals and ground.

(+) Rear blower relay		(-)	Voltage (Approx.)
Connector	Terminal		
M108	1	Ground	Battery voltage
	3		
	6		

Is the inspection result normal?

YES >> Check rear blower motor relay. Refer to [HAC-143, "Component Inspection \(Rear Blower Motor Relay\)"](#).

NO >> Repair harness or connector.

8. CHECK CIRCUIT CONTINUITY BETWEEN BLOWER MOTOR AND REAR BLOWER MOTOR RESISTOR

2

1. Turn ignition switch OFF.
2. Disconnect rear blower motor resistor 2 connector.
3. Check continuity between blower motor harness connector and rear blower motor resistor 2 harness connector.

REAR BLOWER MOTOR

[AUTOMATIC AIR CONDITIONING]

< DTC/CIRCUIT DIAGNOSIS >

Blower motor		Rear blower motor resistor 2		Continuity
Connector	Terminal	Connector	Terminal	
B134	2	B133	1	Yes

Is the inspection result normal?

- YES >> Replace blower motor.
- NO >> Repair harness or connector.

9. CHECK REAR BLOWER MOTOR RESISTOR 2

Check rear blower motor resistor 2. Refer to [HAC-143, "Component Inspection \(Rear Blower Motor Resistor\)"](#).

Is the inspection result normal?

- YES >> Replace auto amp.
- NO >> Replace rear blower motor resistor 2.

Component Inspection (Rear Blower Motor)

INFOID:000000008242338

1. CHECK FRONT BLOWER MOTOR

1. Connect battery voltage to terminal 1 of front blower motor.
2. Connect ground to terminal 2 of front blower motor.

Does the front blower fan operate?

- YES >> Intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).
- NO >> Replace front blower motor. Refer to [VTL-19, "FRONT BLOWER MOTOR : Removal and Installation"](#).


Component Inspection (Rear Blower Motor Relay)

INFOID:000000008242830

1. CHECK REAR BLOWER RELAY

1. Remove rear blower relay. Refer to [PG-84, "Terminal Arrangement"](#).
2. Check continuity between rear blower relay terminals 3 and 5, then 6 and 7 when voltage is supplied between terminals 1 and 2.

Terminal		Voltage	Continuity
3	5	ON	Yes
		OFF	No
6	7	ON	Yes
		OFF	No



Is the inspection result normal?

- YES >> Inspection End.
- NO >> Replace rear blower relay.

Component Inspection (Rear Blower Motor Resistor)

INFOID:000000008242333

1. CHECK FAN CONTROL AMP.

1. Turn ignition switch OFF.
2. Remove rear blower motor resistor. Refer to [HAC-167, "Removal and Installation"](#).
3. Check continuity between the rear blower motor resistor terminals using analog circuit tester.

Terminal		Continuity
(+)	(-)	
3	2	Yes
2	3	No

Is the inspection result normal?

REAR BLOWER MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONING]

YES >> Inspection End.

NO >> Replace rear blower motor resistor.

FRONT AUTOMATIC AIR CONDITIONING SYSTEM

[AUTOMATIC AIR CONDITIONING]

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

FRONT AUTOMATIC AIR CONDITIONING SYSTEM

Diagnosis Chart By Symptom

INFOID:000000008180025

NOTE:

Perform the self-diagnoses with CONSULT before performing the symptom diagnosis. If DTC is detected, perform the corresponding diagnosis.

Symptom	Corresponding malfunction part	Reference
<ul style="list-style-type: none"> Front air conditioning does not activate. Front air conditioning cannot be controlled. Operation status of air conditioning is not indicated on display. 	<ul style="list-style-type: none"> A/C auto amp. ignition power supply circuit Front A/C control (A/C auto amp.) 	HAC-116. "A/C AUTO AMP. : Diagnosis Procedure"
<ul style="list-style-type: none"> Air outlet does not change. Mode door motor (front) does not operate normally. 	<ul style="list-style-type: none"> Circuit between mode door motor (front) and A/C auto amp. Mode door motor (front) control linkage Mode door motor (front) A/C auto amp. 	HAC-119. "MODE DOOR MOTOR (FRONT) : Diagnosis Procedure"
<ul style="list-style-type: none"> Discharge air temperature of driver side does not change. Air mix door motor (driver side) does not operate normally. 	<ul style="list-style-type: none"> Circuit between air mix door motor (driver side) and A/C auto amp. Air mix door motor (driver side) installation condition Air mix door motor (driver side) A/C auto amp. 	HAC-116. "AIR MIX DOOR MOTOR (DRIVER SIDE) : Diagnosis Procedure"
<ul style="list-style-type: none"> Discharge air temperature of passenger side does not change. Air mix door motor (passenger side) does not operate normally. 	<ul style="list-style-type: none"> Circuit between air mix door motor (passenger side) and A/C auto amp. Air mix door motor (passenger side) installation condition Air mix door motor (passenger side) A/C auto amp. 	HAC-117. "AIR MIX DOOR MOTOR (PASSENGER SIDE) : Diagnosis Procedure"
<ul style="list-style-type: none"> Intake door does not change. Intake door motor does not operate normally. 	<ul style="list-style-type: none"> Circuit between intake door motor and A/C auto amp. Intake door motor control linkage Intake door motor A/C auto amp. 	HAC-121. "INTAKE DOOR MOTOR : Diagnosis Procedure"
All door motors do not operate normally.	<ul style="list-style-type: none"> Each door motor power supply and ground circuit A/C auto amp. 	HAC-125. "Diagnosis Procedure"
Front blower motor operation is malfunctioning.	<ul style="list-style-type: none"> Power supply system of front blower motor Circuit between front blower motor and A/C auto amp. Front blower motor A/C auto amp. 	HAC-129. "Diagnosis Procedure"
Compressor does not operate.	<ul style="list-style-type: none"> Circuit between magnet clutch and IPDM E/R Magnet clutch IPDM E/R (A/C relay) Circuit between ECM and refrigerant pressure sensor Refrigerant pressure sensor CAN communication circuit A/C auto amp. 	HAC-134. "Diagnosis Procedure"

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

FRONT AUTOMATIC AIR CONDITIONING SYSTEM

[AUTOMATIC AIR CONDITIONING]

< SYMPTOM DIAGNOSIS >

Symptom	Corresponding malfunction part	Reference	
<ul style="list-style-type: none"> • Insufficient cooling. • No cool air comes out. (Air flow volume is normal.) 	<ul style="list-style-type: none"> • Magnet clutch control system • Drive belt slipping • Refrigerant cycle • Air leakage from each duct • A/C auto amp. connection recognition signal circuit • Temperature setting trimmer (front) 	HAC-149. "FRONT AIR CONDITIONER : Diagnosis Procedure"	
<ul style="list-style-type: none"> • Insufficient heating. • No warm air comes out. (Air flow volume is normal.) 	<ul style="list-style-type: none"> • Engine cooling system • Heater hose • Heater core • Air leakage from each duct • Temperature setting trimmer (front) 	HAC-151. "FRONT AIR CONDITIONER : Diagnosis Procedure"	
Noise is heard when front air conditioning system operates.	During compressor operation	Refrigerant cycle	HA-28. "Symptom Table"
	During front blower motor operation	<ul style="list-style-type: none"> • Mixing any foreign object in front blower motor • Front blower motor fan breakage • Front blower motor rotation inferiority 	HAC-130. "Component Inspection (Front Blower Motor)"
<ul style="list-style-type: none"> • Memory function does not operate. • Setting temperature is not memorized. 	<ul style="list-style-type: none"> • Battery power supply system of A/C auto amp. • A/C auto amp. 	HAC-116. "A/C AUTO AMP. : Diagnosis Procedure"	
Intelligent Key interlock function does not operate.	<ul style="list-style-type: none"> • Door lock system • CAN communication circuit • A/C auto amp. 	HAC-153. "Diagnosis Procedure"	

REAR AUTOMATIC AIR CONDITIONING SYSTEM

[AUTOMATIC AIR CONDITIONING]

< SYMPTOM DIAGNOSIS >

REAR AUTOMATIC AIR CONDITIONING SYSTEM

Diagnosis Chart By Symptom

INFOID:000000008180026

NOTE:

- Perform the self-diagnoses with CONSULT before performing the symptom diagnosis. If DTC is detected, perform the corresponding diagnosis.
- The following table is based on the condition that front automatic air conditioning system operates normally.

Symptom		Corresponding malfunction part	Reference
<ul style="list-style-type: none"> • Rear air conditioning cannot be controlled by front A/C control. • Operation status of rear air conditioning is not indicated on front A/C control display. 		A/C auto amp.	Replace A/C auto amp. Refer to HAC-157. "Removal and Installation" .
Rear air conditioning cannot be controlled by rear air control.	Operation status of rear air conditioning is indicated on rear air control display.	Communication signal (rear air control → A/C auto amp.)	Refer to HAC-113. "Diagnosis Procedure" .
	Operation status of rear air conditioning is not indicated on rear air control display.	Communication signal (A/C auto amp. → rear air control) Rear air control power supply circuit	Refer to HAC-113. "Diagnosis Procedure" . Refer to HAC-123. "REAR A/C CONTROL : Diagnosis Procedure" .
<ul style="list-style-type: none"> • Air outlet does not change. • Mode door motor (rear) does not operate normally. 		<ul style="list-style-type: none"> • Circuit between mode door motor (rear) and A/C auto amp. • Mode door motor (rear) control linkage • Mode door motor (rear) • A/C auto amp. 	HAC-120. "MODE DOOR MOTOR (REAR) : Diagnosis Procedure"
<ul style="list-style-type: none"> • Discharge air temperature does not change. • Air mix door motor (rear) does not operate normally. 		<ul style="list-style-type: none"> • Circuit between air mix door motor (rear) and A/C auto amp. • Air mix door motor (rear) installation condition • Air mix door motor (rear) • A/C auto amp. 	HAC-118. "AIR MIX DOOR MOTOR (REAR) : Diagnosis Procedure"
Rear blower motor operation is malfunctioning.		<ul style="list-style-type: none"> • Power supply system of rear blower motor • Circuit between rear blower motor and A/C auto amp. • Rear blower motor • A/C auto amp. 	HAC-139. "Diagnosis Procedure"
<ul style="list-style-type: none"> • Insufficient cooling. • No cool air comes out. (Air flow volume is normal.) 		<ul style="list-style-type: none"> • A/C auto amp. • Refrigerant cycle • Air leakage from each duct • Temperature setting trimmer (rear) 	HAC-116. "A/C AUTO AMP. : Diagnosis Procedure"
<ul style="list-style-type: none"> • Insufficient heating. • No warm air comes out. (Air flow volume is normal.) 		<ul style="list-style-type: none"> • PTC heater • Air leakage from each duct • Temperature setting trimmer (rear) 	HAC-137. "Diagnosis Procedure"
Noise is heard when rear blower motor operates.		<ul style="list-style-type: none"> • Mixing any foreign object in rear blower motor • Rear blower motor fan breakage • Rear blower motor rotation inferiority 	HAC-143. "Component Inspection (Rear Blower Motor)"

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

ACCS (ADVANCED CLIMATE CONTROL SYSTEM)

[AUTOMATIC AIR CONDITIONING]

< SYMPTOM DIAGNOSIS >

ACCS (ADVANCED CLIMATE CONTROL SYSTEM)

Symptom Table

INFOID:000000008180027

NOTE:

- Perform the self-diagnoses with CONSULT before performing the symptom diagnosis. If DTC is detected, perform the corresponding diagnosis.
- The following table is based on the condition that front automatic air conditioning system operates normally.

Symptom	Corresponding malfunction part	Reference
Auto intake switch cannot be operated. [Automatic intake control (exhaust gas / outside odor detecting mechanism) does not operate]	A/C and AV switch assembly	Replace the A/C and AV switch assembly. Refer to HAC-156. "Removal and Installation" .
Plasmacluster™ control does not operate.	<ul style="list-style-type: none">• Power supply system of ionizer• The circuit between ionizer and A/C auto amp.• Ionizer• A/C auto amp.	Refer to HAC-132. "Diagnosis Procedure" .
Operation status of Plasmacluster™ control does not switch according to air flow.	A/C auto amp.	Replace A/C auto amp. Refer to HAC-157. "Removal and Installation" .

INSUFFICIENT COOLING

[AUTOMATIC AIR CONDITIONING]

< SYMPTOM DIAGNOSIS >

INSUFFICIENT COOLING FRONT AIR CONDITIONER

FRONT AIR CONDITIONER : Description

INFOID:000000008180028

Symptom

- Insufficient cooling
- No cool air comes out. (Air flow volume is normal.)

FRONT AIR CONDITIONER : Diagnosis Procedure

INFOID:000000008180029

NOTE:

Perform self-diagnoses with CONSULT before performing symptom diagnosis. If any DTC is detected, perform the corresponding diagnosis.

1.CHECK MAGNET CLUTCH OPERATION

1. Turn ignition switch ON.
2. Operate fan switch.
3. Press A/C switch.
4. Check that A/C indicator turns ON. Check visually and by sound that compressor operates.
5. Press A/C switch again.
6. Check that A/C indicator turns OFF. Check that compressor stops.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Perform diagnosis of "COMPRESSOR DOES NOT OPERATE" in "SYMPTOM DIAGNOSIS".
Refer to [HAC-154, "Diagnosis Procedure"](#).

2.CHECK DRIVE BELT

Check tension of drive belt. Refer to [MA-13, "DRIVE BELTS : Checking Drive Belts"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Adjust or replace drive belt depending on the inspection results.

3.CHECK REFRIGERANT CYCLE

Connect recovery/recycling recharging equipment to the vehicle and perform pressure inspection with gauge. Refer to [HA-28, "Symptom Table"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace parts depending on the inspection results.

4.CHECK AIR LEAKAGE FROM EACH DUCT

Check duct and nozzle, etc. of the front air conditioning system for leakage.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace parts depending on the inspection results.

5.CHECK AMBIENT TEMPERATURE DISPLAY

Check that there is not much difference between actual ambient temperature and indicated temperature on information display in combination meter.

Is the inspection result normal?

YES >> GO TO 6.

NO >> Perform diagnosis for the A/C auto amp. connection recognition signal circuit. Refer to [HAC-87, "Diagnosis Procedure"](#).

6.CHECK SETTING OF TEMPERATURE SETTING TRIMMER (FRONT)

1. Check setting value of temperature setting trimmer (front). Refer to [HAC-78, "FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Temperature Setting Trimmer \(Front\)"](#).
2. Check that temperature setting trimmer (front) is set to "+ direction".

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

INSUFFICIENT COOLING

[AUTOMATIC AIR CONDITIONING]

< SYMPTOM DIAGNOSIS >

NOTE:

The control temperature can be set with the setting of the temperature setting trimmer (front).

3. Set difference between set temperature and control temperature to "0".

Is inspection result normal?

YES >> Inspection End.

NO >> Replace A/C auto amp. Refer to [HAC-157, "Removal and Installation"](#).

REAR AIR CONDITIONER

REAR AIR CONDITIONER : Description

INFOID:000000008180030

Symptom

- Insufficient cooling
- No cool air comes out. (Air flow volume is normal.)

REAR AIR CONDITIONER : Diagnosis Procedure

INFOID:000000008180031

NOTE:

Perform self-diagnoses with CONSULT before performing symptom diagnosis. If any DTC is detected, perform the corresponding diagnosis.

1. CHECK REFRIGERANT CYCLE

Connect recovery/recycling recharging equipment to the vehicle and perform pressure inspection with gauge. Refer to [HA-28, "Symptom Table"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace parts depending on the inspection results.

2. CHECK AIR LEAKAGE FROM EACH DUCT

Check duct and nozzle, etc. of the rear air conditioning system for leakage.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace parts depending on the inspection results.

3. CHECK SETTING OF TEMPERATURE SETTING TRIMMER (REAR)

1. Check setting value of temperature setting trimmer (rear). Refer to [HAC-79, "REAR AUTOMATIC AIR CONDITIONING SYSTEM : Temperature Setting Trimmer \(Rear\)"](#).
2. Check that temperature setting trimmer (rear) is set to "+ direction".

NOTE:

The control temperature can be set with the setting of the temperature setting trimmer (rear).

3. Set difference between set temperature and control temperature to "0".

Is inspection result normal?

YES >> Inspection End.

NO >> Replace A/C auto amp. Refer to [HAC-157, "Removal and Installation"](#).

INSUFFICIENT HEATING

[AUTOMATIC AIR CONDITIONING]

< SYMPTOM DIAGNOSIS >

INSUFFICIENT HEATING FRONT AIR CONDITIONER

FRONT AIR CONDITIONER : Description

INFOID:000000008180032

Symptom

- Insufficient heating
- No warm air comes out. (Air flow volume is normal.)

FRONT AIR CONDITIONER : Diagnosis Procedure

INFOID:000000008180033

NOTE:

Perform self-diagnoses with on board diagnosis and CONSULT before performing symptom diagnosis. If DTC is detected, perform the corresponding diagnosis.

1. CHECK COOLING SYSTEM

1. Check engine coolant level and check leakage. Refer to [MA-13, "ENGINE COOLANT : System Inspection"](#).
2. Check reservoir tank cap. Refer to [MA-13, "ENGINE COOLANT : System Inspection"](#).
3. Check water flow sounds of the engine coolant. Refer to [MA-13, "ENGINE COOLANT : System Inspection"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refill engine coolant and repair or replace parts depending on the inspection results.

2. CHECK HEATER HOSE

Check installation of heater hose visually or by touching.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace parts depending on the inspection results.

3. CHECK HEATER CORE

1. Check temperature of inlet hose and outlet hose of front heater core.
2. Check that inlet side of heater core is hot and the outlet side is slightly lower than/almost equal to the inlet side.

CAUTION:

Always perform the temperature inspection in a short period of time because the engine coolant temperature is very hot.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace heater core. Refer to [HA-49, "Removal and Installation"](#).

4. CHECK AIR LEAKAGE FROM EACH DUCT

Check duct and nozzle, etc. of front air conditioning system for air leakage.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace parts depending on the inspection results.

5. CHECK SETTING OF TEMPERATURE SETTING TRIMMER (FRONT)

1. Check setting value of temperature setting trimmer (front). Refer to [HAC-78, "FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Temperature Setting Trimmer \(Front\)"](#).
2. Check that temperature setting trimmer (front) is set to "– direction".

NOTE:

The control temperature can be set by the temperature setting trimmer (front).

3. Set difference between the set temperature and control temperature to "0".

Are the symptoms solved?

YES >> Inspection End.

NO >> Replace A/C auto amp. Refer to [HAC-157, "Removal and Installation"](#).

INSUFFICIENT HEATING

[AUTOMATIC AIR CONDITIONING]

< SYMPTOM DIAGNOSIS >

REAR AIR CONDITIONER

REAR AIR CONDITIONER : Description

INFOID:000000008180034

Symptom

- Insufficient heating
- No warm air comes out. (Air flow volume is normal.)

REAR AIR CONDITIONER : Diagnosis Procedure

INFOID:000000008180035

CAUTION:

Perform the self-diagnoses with on board diagnosis and CONSULT before performing symptom diagnosis. If any malfunction result or DTC is detected, perform the corresponding diagnosis.

1. CHECK PTC HEATER

Check PTC heater. Refer to [HAC-137, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace PTC heater. Refer to [VTL-20, "CENTER BLOWER MOTOR : Removal and Installation"](#).

2. CHECK AIR LEAKAGE FROM EACH DUCT

Check duct and nozzle, etc. of the rear air conditioning system for air leakage.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace parts depending on the inspection results.

3. CHECK SETTING OF TEMPERATURE SETTING TRIMMER (REAR)

1. Check setting value of temperature setting trimmer (rear). Refer to [HAC-79, "REAR AUTOMATIC AIR CONDITIONING SYSTEM : Temperature Setting Trimmer \(Rear\)"](#).
2. Check that the temperature setting trimmer is set to "– direction".

NOTE:

The control temperature can be set by the temperature setting trimmer (rear).

3. Set the difference between the set temperature (rear) and control temperature to "0".

Are the symptoms solved?

YES >> Inspection End.

NO >> Replace A/C auto amp. Refer to [HAC-157, "Removal and Installation"](#).

INTELLIGENT KEY INTERLOCK FUNCTION DOES NOT OPERATE

[AUTOMATIC AIR CONDITIONING]

< SYMPTOM DIAGNOSIS >

INTELLIGENT KEY INTERLOCK FUNCTION DOES NOT OPERATE

Description

INFOID:000000008267006

Symptom: Intelligent Key interlock function does not operate.

Diagnosis Procedure

INFOID:000000008267007

1.CHECK DOOR LOCK SYSTEM

Check door lock system.

Refer to [DLK-104, "Work Flow"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace malfunctioning parts.

2.CHECK INTERMITTENT INCIDENT

Refer to [GI-53, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Replace A/C auto amp. Refer to [HAC-157, "Removal and Installation"](#).

NO >> Repair or replace malfunctioning parts.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

COMPRESSOR DOES NOT OPERATE

[AUTOMATIC AIR CONDITIONING]

< SYMPTOM DIAGNOSIS >

COMPRESSOR DOES NOT OPERATE

Description

INFOID:000000008180038

Symptom: Compressor does not operate.

Diagnosis Procedure

INFOID:000000008180039

NOTE:

- Perform self-diagnoses with CONSULT before performing symptom diagnosis. If DTC is detected, perform the corresponding diagnosis.
- Check that refrigerant system is properly charged. If refrigerant amount is below the proper amount, perform inspection of refrigerant leakage.

1. CHECK MAGNET CLUTCH OPERATION

Check magnet clutch. Refer to [HAC-134, "Component Function Check"](#).

Does it operate normally?

YES >> GO TO 2.

NO >> Repair or replace malfunctioning parts.

2. CHECK REFRIGERANT PRESSURE SENSOR

Check refrigerant pressure sensor. Refer to [EC-474, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning parts.

3. CHECK A/C AUTO AMP. OUTPUT SIGNAL

 With CONSULT

Check "COMP REQ SIG" and "FAN REQ SIG" in "DATA MONITOR" mode of "HVAC" using CONSULT.


Monitor item	Condition	Status	
COMP REQ SIG	A/C switch	ON	On
		OFF	Off
FAN REQ SIG	Front blower motor	ON	On
		OFF	Off

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace A/C auto amp. Refer to [HAC-157, "Removal and Installation"](#).

4. CHECK ECM INPUT SIGNAL

 With CONSULT

Check "AIR COND SIG" and "HEATER FAN SW" in "DATA MONITOR" mode of "ECM" using CONSULT.


Monitor item	Condition	Status	
AIR COND SIG	A/C switch	ON	On
		OFF	Off
HEATER FAN SW	Front blower motor	ON	On
		OFF	Off

Is the inspection result normal?

YES >> GO TO 5.

NO >> Check CAN communication system. Refer to [LAN-22, "Trouble Diagnosis Flow Chart"](#).

5. CHECK IPDM E/R INPUT SIGNAL

 With CONSULT

1. Start engine.

COMPRESSOR DOES NOT OPERATE

[AUTOMATIC AIR CONDITIONING]

< SYMPTOM DIAGNOSIS >

2. Check "AC COMP REQ" in "DATA MONITOR" mode of "IPDM E/R" using CONSULT.

Monitor item	Condition	Status
AC COMP REQ	A/C switch	ON
		OFF
		On
		Off

Is the inspection result normal?

YES >> Inspection End.

NO >> Check CAN communication system. Refer to [LAN-22. "Trouble Diagnosis Flow Chart"](#).

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

HAC

REMOVAL AND INSTALLATION


A/C SWITCH

Removal and Installation

INFOID:000000007884435

REMOVAL

1. Remove cluster lid C lower. Refer to [IP-21. "Removal and Installation - Cluster Lid C Lower"](#).
2. Remove the A/C and AV switch assembly screws (A).



3. Disconnect the harness connectors from the A/C and AV switch assembly and remove.


INSTALLATION

Installation is in the reverse order of removal.

A/C AUTO AMP.

Exploded View

INFOID:000000007884436



A

B

C

D

E

F

G

H

HAC

J

K

L

M

N

O

P

- 1. AV control unit
- 2. AV control unit bracket LH
- 3. A/C auto amp.
- 4. AV control unit bracket RH

Removal and Installation

INFOID:000000007884437

REMOVAL

1. Remove the AV control unit. Refer to [AV-668. "Removal and Installation - AV Control Unit"](#) (BASE AUDIO), or [AV-388. "Removal and Installation - AV Control Unit"](#) (BOSE AUDIO W/O SURROUND SOUND), or [AV-128. "Removal and Installation - AV Control Unit"](#) (BOSE AUDIO WITH SURROUND SOUND), or [AV-825. "Removal and Installation - AV Control Unit"](#) (TELEMATICS SYSTEM).
2. Remove the screws and one of the A/C auto amp. brackets (LH or RH).
3. Remove the A/C auto amp.

INSTALLATION

Installation is in the reverse order of removal.

AMBIENT SENSOR

< REMOVAL AND INSTALLATION >

[AUTOMATIC AIR CONDITIONING]


AMBIENT SENSOR

Removal and Installation

INFOID:000000007884438

REMOVAL

1. Remove the radiator core support upper cover. Refer to [HA-40, "Exploded View"](#).
2. Disconnect the harness connector from the ambient sensor.
3. Release the ambient sensor clip, then remove the ambient sensor (1).



INSTALLATION

Installation is in the reverse order of removal.

IN-VEHICLE SENSOR

< REMOVAL AND INSTALLATION >

[AUTOMATIC AIR CONDITIONING]


IN-VEHICLE SENSOR

Removal and Installation

INFOID:000000007884439

REMOVAL

1. Remove instrument lower panel LH. Refer to [IP-23, "Removal and Installation"](#).
2. Disconnect the aspirator hose from the in-vehicle sensor.
3. Disconnect the harness connector from the in-vehicle sensor.
4. Remove the in-vehicle sensor screw (A), then remove in-vehicle sensor (1).



INSTALLATION

Installation is in the reverse order of removal.

- Make sure that the aspirator hose is securely attached to the in-vehicle sensor when installing the instrument lower panel LH.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

SUNLOAD SENSOR

< REMOVAL AND INSTALLATION >

[AUTOMATIC AIR CONDITIONING]


SUNLOAD SENSOR

Removal and Installation

INFOID:000000007884440

REMOVAL

1. Remove the instrument panel tweeter grille LH. Refer to [IP-14, "Exploded View"](#).
2. Disconnect the harness connector from the sunload sensor.
3. Release the pawls, then remove sunload sensor (1) from the instrument panel tweeter grille LH.



INSTALLATION

Installation is in the reverse order of removal.

INTAKE SENSOR

< REMOVAL AND INSTALLATION >

[AUTOMATIC AIR CONDITIONING]

INTAKE SENSOR

Removal and Installation


INFOID:000000007884444

REMOVAL

1. Remove the front evaporator. Refer to [HA-46, "Removal and Installation - Front Heating and Cooling Unit Assembly"](#).
2. Remove the intake sensor (2) by pulling out of the front evaporator (1).

CAUTION:

- Mark the mounting position of the intake sensor.
- Do not damage the evaporator core.



INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

Mount the intake sensor in the same position as the original intake sensor on the evaporator core.

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

EXHAUST GAS/OUTSIDE ODOR DETECTING SENSOR

< REMOVAL AND INSTALLATION >

[AUTOMATIC AIR CONDITIONING]


EXHAUST GAS/OUTSIDE ODOR DETECTING SENSOR

Removal and Installation

INFOID:000000007884447

REMOVAL

1. Remove the radiator core support upper cover. Refer to [HA-40, "Exploded View"](#).
2. Disconnect the harness connector from the exhaust gas/outside odor sensor.
3. Remove the exhaust gas/outside odor detecting sensor nut (A), then remove the exhaust gas/outside odor detecting sensor (1).



INSTALLATION

Installation is in the reverse order of removal.

REFRIGERANT PRESSURE SENSOR

[AUTOMATIC AIR CONDITIONING]

< REMOVAL AND INSTALLATION >

REFRIGERANT PRESSURE SENSOR

Removal and Installation

INFOID:000000008487406

REMOVAL

1. Discharge the refrigerant. Refer to [HA-20, "Recycle Refrigerant"](#).
2. Remove the radiator core support upper cover. Refer to [HA-40, "Exploded View"](#).
3. Disconnect the harness connector from the refrigerant pressure sensor.
4. Remove the refrigerant pressure sensor.

CAUTION:

Cap or wrap the opening of the refrigerant pressure sensor with suitable material such as vinyl tape to avoid the entry of air.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Do not reuse O-ring.
- Apply A/C oil to the O-ring of the refrigerant pressure sensor for installation.
- After charging the refrigerant, check for leaks. Refer to [HA-18, "Leak Test"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

HAC

DOOR MOTOR


< REMOVAL AND INSTALLATION >

[AUTOMATIC AIR CONDITIONING]

DOOR MOTOR

Exploded View - Front Door Motors

INFOID:000000007884448



AW11A1578ZZ

- | | | |
|--|------------------------------|--|
| 1. Intake door motor | 2. Mode door motor (front) | 3. Air mix door motor (driver side) |
| 4. Air mix door motor (passenger side) | 5. Air mix door motor (rear) | 6. Front heating and cooling unit assembly |

DOOR MOTOR

[AUTOMATIC AIR CONDITIONING]

< REMOVAL AND INSTALLATION >

MODE DOOR MOTOR

MODE DOOR MOTOR : Removal and Installation - Mode Door Motor (Front)

INFOID:000000007884449

REMOVAL

1. Remove the center console side finisher LH. Refer to [IP-18, "Exploded View"](#).
2. Remove the upper floor connecting duct LH. Refer to [HA-45, "Exploded View - Front Heating and Cooling Unit Assembly"](#).
3. Remove the mode door motor (front) screws.
4. Disconnect the harness connector from the mode door motor (front) and remove.

INSTALLATION

Installation is in the reverse order of removal.

MODE DOOR MOTOR : Removal and Installation - Mode Door Motor (Rear)

INFOID:000000008272223

REMOVAL

1. Remove the center console assembly. Refer to [IP-18, "Removal and Installation"](#).
2. Disconnect the harness connectors from the PTC heater.
3. Remove the screws from the mode door motor (rear).
4. Disconnect the harness connector from the mode door motor (rear) and remove.

INSTALLATION

Installation is in the reverse order of removal.

AIR MIX DOOR MOTOR

AIR MIX DOOR MOTOR : Removal and Installation - Air Mix Door Motor (Driver Side)

INFOID:000000007884450

REMOVAL

1. Remove the center console side finisher LH. Refer to [IP-18, "Exploded View"](#).
2. Remove the upper floor connecting duct LH. Refer to [HA-45, "Exploded View - Front Heating and Cooling Unit Assembly"](#).
3. Remove the air mix door motor (driver side) screws.
4. Disconnect the harness connector from the air mix door motor (driver side) and remove.

INSTALLATION

Installation is in the reverse order of removal.

AIR MIX DOOR MOTOR : Removal and Installation - Air Mix Door Motor (Passenger Side)

INFOID:000000008272226

REMOVAL

1. Remove the upper floor connecting duct RH. Refer to [HA-45, "Exploded View - Front Heating and Cooling Unit Assembly"](#).
2. Remove the air mix door motor (passenger side) screws.
3. Disconnect the harness connector from the air mix door motor (passenger side) and remove.

INSTALLATION

Installation is in the reverse order of removal.

AIR MIX DOOR MOTOR : Removal and Installation - Air Mix Door Motor (Rear)

INFOID:000000008272227

REMOVAL

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

HAC

DOOR MOTOR

[AUTOMATIC AIR CONDITIONING]

< REMOVAL AND INSTALLATION >

1. Remove the glove box assembly. Refer to [IP-24, "Removal and Installation"](#).
2. Remove the upper floor connecting duct RH. Refer to [HA-45, "Exploded View - Front Heating and Cooling Unit Assembly"](#).
3. Remove the air mix door motor (rear) screws.
4. Disconnect the harness connector from the air mix door motor (rear) and remove.

INSTALLATION

Installation is in the reverse order of removal.

INTAKE DOOR MOTOR

INTAKE DOOR MOTOR : Removal and Installation

INFOID:000000007884451

REMOVAL

1. Remove the glove box assembly. Refer to [IP-24, "Removal and Installation"](#).
2. Remove the intake door motor screws.
3. Disconnect the harness connector from the intake door motor and remove.

INSTALLATION

Installation is in the reverse order of removal.

REAR SHUT-OFF DOOR MOTOR

REAR SHUT-OFF DOOR MOTOR : Removal and Installation

INFOID:000000007884453

REMOVAL

1. Remove the center console rear brace. Refer to [IP-18, "Exploded View"](#).
2. Remove the rear shut-off door motor screws.
3. Disconnect the harness connector from the rear shut-off door motor and remove.

INSTALLATION

Installation is in the reverse order of removal.

BLOWER MOTOR RESISTOR

[AUTOMATIC AIR CONDITIONING]

< REMOVAL AND INSTALLATION >

BLOWER MOTOR RESISTOR

Removal and Installation

INFOID:000000008297260

REMOVAL

1. Remove the luggage side lower finisher RH. Refer to [INT-29, "LUGGAGE SIDE LOWER FINISHER : Removal and Installation"](#).
2. Disconnect the harness connector from the blower motor resistor.
3. Remove the blower motor resistor screws and remove.

INSTALLATION


Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

IONIZER

Exploded View

INFOID:000000007884456



1. Ionizer

2. Center ventilator duct

Removal and Installation

INFOID:000000007884457

Removal

1. Remove instrument panel assembly. Refer to [IP-15, "Removal and Installation"](#).
2. Disconnect the harness connector from the ionizer.
3. Release the ionizer clips, then remove ionizer from the center ventilator duct.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- If there is dirt, use a clean cloth and clean the discharge electrode (ceramic part) of the ionizer.
- Do not touch the surface (ceramic part) of the ionizer, it is the discharge electrode.