

TM
SECTION
TRANSAXLE & TRANSMISSION

A
B
C

TM

CONTENTS

E

6MT: RS6F94R

<p>PRECAUTION 6</p> <p>PRECAUTIONS 6</p> <p style="padding-left: 20px;">Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" 6</p> <p style="padding-left: 20px;">Precaution for Procedure without Cowl Top Cover..... 6</p> <p style="padding-left: 20px;">Service Notice or Precautions for Manual Transaxle 6</p> <p>PREPARATION 8</p> <p>PREPARATION 8</p> <p style="padding-left: 20px;">Special Service Tools 8</p> <p style="padding-left: 20px;">Commercial Service Tools 10</p> <p>SYSTEM DESCRIPTION 12</p> <p>COMPONENT PARTS 12</p> <p style="padding-left: 20px;">Component Parts Location 12</p> <p>STRUCTURE AND OPERATION 13</p> <p style="padding-left: 20px;">Sectional View 13</p> <p style="padding-left: 20px;">System Description 13</p> <p>DTC/CIRCUIT DIAGNOSIS 15</p> <p>POSITION SWITCH 15</p> <p>BACK-UP LAMP SWITCH 15</p> <p style="padding-left: 20px;">BACK-UP LAMP SWITCH : Component Inspection 15</p> <p>PARK/NEUTRAL POSITION (PNP) SWITCH 15</p> <p style="padding-left: 20px;">PARK/NEUTRAL POSITION (PNP) SWITCH : Component Inspection 15</p> <p>SYMPTOM DIAGNOSIS 16</p> <p>NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING 16</p>	<p>NVH Troubleshooting Chart 16</p> <p>PERIODIC MAINTENANCE 17</p> <p>GEAR OIL 17</p> <p style="padding-left: 20px;">Inspection 17</p> <p style="padding-left: 20px;">Draining 17</p> <p style="padding-left: 20px;">Refilling 17</p> <p>REMOVAL AND INSTALLATION 18</p> <p>SIDE OIL SEAL 18</p> <p style="padding-left: 20px;">Removal and Installation 18</p> <p style="padding-left: 20px;">Inspection 18</p> <p>POSITION SWITCH 19</p> <p style="padding-left: 20px;">Removal and Installation 19</p> <p style="padding-left: 20px;">Inspection 19</p> <p>CONTROL LINKAGE 20</p> <p style="padding-left: 20px;">Exploded View 20</p> <p style="padding-left: 20px;">Removal and Installation 20</p> <p style="padding-left: 20px;">Inspection 23</p> <p>AIR BREATHER HOSE 24</p> <p style="padding-left: 20px;">Exploded View 24</p> <p style="padding-left: 20px;">Removal and Installation 24</p> <p>UNIT REMOVAL AND INSTALLATION 25</p> <p>TRANSAXLE ASSEMBLY 25</p> <p style="padding-left: 20px;">Exploded View 25</p> <p style="padding-left: 20px;">Removal and Installation 25</p> <p style="padding-left: 20px;">Inspection 26</p> <p>UNIT DISASSEMBLY AND ASSEMBLY ... 27</p> <p>TRANSAXLE ASSEMBLY 27</p> <p style="padding-left: 20px;">Exploded View 27</p> <p style="padding-left: 20px;">Disassembly 32</p> <p style="padding-left: 20px;">Assembly 37</p> <p style="padding-left: 20px;">Inspection 43</p>
--	--

F

G

H

I

J

K

L

M

N

O

P

INPUT SHAFT AND GEAR	44	CVT CONTROL SYSTEM : Component Description	70
Exploded View	44	CVT CONTROL SYSTEM : TCM	71
Disassembly	44	CVT CONTROL SYSTEM : Transmission Range Switch	71
Assembly	46	CVT CONTROL SYSTEM : Primary Speed Sensor	71
Inspection	48	CVT CONTROL SYSTEM : Secondary Speed Sensor	72
MAINSHAFT AND GEAR	50	CVT CONTROL SYSTEM : CVT Fluid Temperature Sensor	72
Exploded View	50	CVT CONTROL SYSTEM : Secondary Pressure Sensor	72
Disassembly	51	CVT CONTROL SYSTEM : Line Pressure Solenoid Valve	73
Assembly	52	CVT CONTROL SYSTEM : Secondary Pressure Solenoid Valve	73
Inspection	54	CVT CONTROL SYSTEM : Torque Converter Clutch Solenoid Valve	73
REVERSE IDLER SHAFT AND GEAR	56	CVT CONTROL SYSTEM : Lock-up Select Solenoid Valve	73
Exploded View	56	CVT CONTROL SYSTEM : Step Motor	74
Disassembly	56	CVT CONTROL SYSTEM : Manual Mode Switch... ..	74
Assembly	57	CVT CONTROL SYSTEM : CVT Indicator	74
Inspection	57	CVT CONTROL SYSTEM : Shift Position Indicator	74
FINAL DRIVE	59	CVT CONTROL SYSTEM : Manual Mode Indicator	74
Exploded View	59	SHIFT LOCK SYSTEM	74
Disassembly	59	SHIFT LOCK SYSTEM : Component Parts Location	75
Assembly	60	SHIFT LOCK SYSTEM : Component Description... ..	75
Inspection	60	STRUCTURE AND OPERATION	76
SERVICE DATA AND SPECIFICATIONS (SDS)	62	TRANSAXLE	76
SERVICE DATA AND SPECIFICATIONS (SDS)	62	TRANSAXLE : Cross-Sectional View	76
General Specifications	62	TRANSAXLE : Main Component Elements	77
CVT: RE0F10B		TRANSAXLE : Belt & Pulley	78
PRECAUTION	63	FLUID COOLER & FLUID WARMER SYSTEM	79
PRECAUTIONS	63	FLUID COOLER & FLUID WARMER SYSTEM : System Description	79
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	63	MECHANICAL SYSTEM	80
Precaution for Procedure without Cowl Top Cover... ..	63	MECHANICAL SYSTEM : System Diagram	81
Precaution for On Board Diagnosis (OBD) System of CVT and Engine	63	MECHANICAL SYSTEM : System Description	81
Precaution for TCM and Transaxle Assembly or Control Valve Replacement	64	MECHANICAL SYSTEM : Component Description	85
Removal and Installation Procedure for CVT Unit Connector	64	SYSTEM	87
General Precautions	65	CVT CONTROL SYSTEM	87
Service Notice or Precaution	66	CVT CONTROL SYSTEM : System Description	87
PREPARATION	67	CVT CONTROL SYSTEM : System Diagram	88
PREPARATION	67	CVT CONTROL SYSTEM : Fail-Safe	88
Special Service Tool	67	OIL PRESSURE CONTROL SYSTEM	90
Commercial Service Tool	67	OIL PRESSURE CONTROL SYSTEM : System Diagram	90
SYSTEM DESCRIPTION	69		
COMPONENT PARTS	69		
CVT CONTROL SYSTEM	69		
CVT CONTROL SYSTEM : Component Parts Location	69		

OIL PRESSURE CONTROL SYSTEM : System Description	90	DIAGNOSIS AND REPAIR WORKFLOW	120	
CONTROL SYSTEM	91	Work Flow	120	A
CONTROL SYSTEM : System Diagram	92	Diagnostic Work Sheet	121	
CONTROL SYSTEM : System Description	92	ADDITIONAL SERVICE WHEN REPLACING TCM	123	B
CONTROL SYSTEM : CAN Communication	93	Description	123	
CONTROL SYSTEM : Engine and CVT Integrated Control (CAN Communication Control)	93	Work Procedure	123	C
CONTROL SYSTEM : Control between CVT and Combination Meter (CAN Communication Control)	93	ADDITIONAL SERVICE WHEN REPLACING CONTROL VALVE OR TRANSAXLE ASSEMBLY	125	TM
CONTROL SYSTEM : Control between CVT and BCM (CAN Communication Control)	93	Description	125	
LOCK-UP AND SELECT CONTROL SYSTEM	93	Work Procedure	125	
LOCK-UP AND SELECT CONTROL SYSTEM : System Diagram	94	CVT FLUID COOLER SYSTEM	127	E
LOCK-UP AND SELECT CONTROL SYSTEM : System Description	94	Cleaning	127	
SHIFT CONTROL SYSTEM	94	STALL TEST	130	F
SHIFT CONTROL SYSTEM : System Diagram	95	Inspection and Judgment	130	
SHIFT CONTROL SYSTEM : System Description	95	LINE PRESSURE TEST	132	G
INTEGRATED CONTROL SYSTEM	97	Inspection and Judgment	132	
INTEGRATED CONTROL SYSTEM : System Diagram	98	ROAD TEST	134	H
INTEGRATED CONTROL SYSTEM : System Description	98	Description	134	
SHIFT LOCK SYSTEM	99	Check before Engine Is Started	134	I
SHIFT LOCK SYSTEM : System Description	99	Check at Idle	134	
KEY LOCK SYSTEM	100	Cruise Test	135	J
KEY LOCK SYSTEM : System Description	100	CVT POSITION	137	
ON BOARD DIAGNOSTIC (OBD) SYSTEM ...	101	Inspection and Adjustment	137	K
Diagnosis Description	101	DTC/CIRCUIT DIAGNOSIS	138	
DIAGNOSIS SYSTEM (TCM)	103	U0100 LOST COMMUNICATION (ECM A)	138	L
CONSULT Function	103	DTC Logic	138	
ATFTEMP COUNT Conversion Table	107	Diagnosis Procedure	138	M
Diagnostic Tool Function	107	U1000 CAN COMM CIRCUIT	139	
ECU DIAGNOSIS INFORMATION	108	Description	139	N
TCM	108	DTC Logic	139	
Reference Value	108	Diagnosis Procedure	139	
Fail-Safe	113	U1010 CONTROL UNIT (CAN)	140	O
DTC Inspection Priority Chart	115	Description	140	
DTC Index	116	DTC Logic	140	
WIRING DIAGRAM	118	Diagnosis Procedure	140	P
CVT CONTROL SYSTEM	118	P0703 BRAKE SWITCH B	141	
Wiring Diagram	118	Description	141	
CVT SHIFT LOCK SYSTEM	119	DTC Logic	141	
Wiring Diagram	119	Diagnosis Procedure	141	
BASIC INSPECTION	120	Component Inspection (Stop Lamp Switch)	142	
		P0705 TRANSMISSION RANGE SENSOR A .	144	
		DTC Logic	144	
		Diagnosis Procedure	144	
		Component Inspection (Transmission Range Switch)	146	

P0710 TRANSMISSION FLUID TEMPERATURE SENSOR A	147	Description	178
DTC Logic	147	DTC Logic	178
Diagnosis Procedure	148	Diagnosis Procedure	178
P0715 INPUT SPEED SENSOR A	150	P1701 TCM	180
DTC Logic	150	Description	180
Diagnosis Procedure	150	DTC Logic	180
P0720 OUTPUT SPEED SENSOR	153	Diagnosis Procedure	180
DTC Logic	153	P1705 TP SENSOR	183
Diagnosis Procedure	153	Description	183
P0725 ENGINE SPEED	156	DTC Logic	183
Description	156	Diagnosis Procedure	183
DTC Logic	156	P1709 INCOMPLETED DATA WRITING	184
Diagnosis Procedure	156	Description	184
P0740 TORQUE CONVERTER	157	DTC Logic	184
DTC Logic	157	Diagnosis Procedure	184
Diagnosis Procedure	157	P1722 VEHICLE SPEED	186
P0744 TORQUE CONVERTER	160	Description	186
Description	160	DTC Logic	186
DTC Logic	160	Diagnosis Procedure	186
Diagnosis Procedure	160	P1723 SPEED SENSOR	187
P0745 PRESSURE CONTROL SOLENOID A 162		Description	187
DTC Logic	162	DTC Logic	187
Diagnosis Procedure	162	Diagnosis Procedure	187
P0746 PRESSURE CONTROL SOLENOID A 164		P1726 THROTTLE CONTROL SIGNAL	189
Description	164	Description	189
DTC Logic	164	DTC Logic	189
Diagnosis Procedure	164	Diagnosis Procedure	189
P0776 PRESSURE CONTROL SOLENOID B 166		P1740 SELECT SOLENOID	190
Description	166	DTC Logic	190
DTC Logic	166	Diagnosis Procedure	190
Diagnosis Procedure	166	P1777 STEP MOTOR	192
P0778 PRESSURE CONTROL SOLENOID B 168		DTC Logic	192
DTC Logic	168	Diagnosis Procedure	192
Diagnosis Procedure	168	P1778 STEP MOTOR	195
P0826 UP AND DOWN SHIFT SW	170	Description	195
DTC Logic	170	DTC Logic	195
Diagnosis Procedure	171	Diagnosis Procedure	196
Component Inspection (Manual Mode Switch)	172	SHIFT POSITION INDICATOR CIRCUIT	197
P0840 TRANSMISSION FLUID PRESSURE SEN/SW A	173	Description	197
DTC Logic	173	Component Function Check	197
Diagnosis Procedure	173	Diagnosis Procedure	197
P0841 TRANSMISSION FLUID PRESSURE SEN/SW A	176	SHIFT LOCK SYSTEM	198
Description	176	Component Function Check	198
DTC Logic	176	Diagnosis Procedure	198
Diagnosis Procedure	176	Component Inspection (Shift Lock Solenoid)	200
P0868 TRANSMISSION FLUID PRESSURE	178	Component Inspection (Park Position Switch)	200
		Component Inspection (CVT Shift Selector Harness)	200
		Component Inspection (Stop Lamp Switch)	201
		SYMPTOM DIAGNOSIS	202

SYSTEM SYMPTOM	202	2WD	238	
Symptom Table	202	2WD : Exploded View	238	A
PERIODIC MAINTENANCE	213	2WD : Removal and Installation	238	
CVT FLUID	213	2WD : Inspection	239	
Inspection	213	AWD	239	B
Changing	214	AWD : Exploded View	239	
REMOVAL AND INSTALLATION	215	AWD : Removal and Installation	240	C
CVT SHIFT SELECTOR	215	AWD : Inspection	240	
Exploded View	215	OIL PUMP FITTING BOLT	241	
Removal and Installation	215	Description	241	TM
Disassembly and Assembly	216	Exploded View	241	
Inspection	216	Removal and Installation	241	
CONTROL CABLE	218	Inspection	241	E
Exploded View	218	WATER HOSE	242	
Removal and Installation	219	Exploded View	242	F
Inspection	221	Removal and Installation	242	
KEY INTERLOCK CABLE	222	Inspection	243	
Exploded View	222	UNIT REMOVAL AND INSTALLATION ...	245	G
Removal and Installation	222	TRANSAXLE ASSEMBLY	245	
Inspection	223	2WD	245	H
TRANSMISSION RANGE SWITCH	224	2WD : Exploded View	245	
Exploded View	224	2WD : Removal and Installation	245	I
Removal and Installation	224	2WD : Inspection and Adjustment	248	
Inspection and Adjustment	224	AWD	248	J
TCM	226	AWD : Exploded View	249	
Exploded View	226	AWD : Removal and Installation	249	
Removal and Installation	226	AWD : Inspection and Adjustment	252	
Adjustment	226	UNIT DISASSEMBLY AND ASSEMBLY .	253	K
AIR BREATHER HOSE	227	TORQUE CONVERTER AND CONVERTER		L
Removal and Installation	227	HOUSING OIL SEAL	253	
CONTROL VALVE	228	Exploded View	253	
Exploded View	228	Disassembly	253	
Removal and Installation	228	Assembly	253	
Inspection and Adjustment	234	Inspection	254	M
PRIMARY SPEED SENSOR	235	SERVICE DATA AND SPECIFICATIONS		N
Exploded View	235	(SDS)	255	
Removal and Installation	235	SERVICE DATA AND SPECIFICATIONS		O
Inspection	235	(SDS)	255	
SECONDARY SPEED SENSOR	236	General Specification	255	
Exploded View	236	Shift Characteristics	255	
Removal and Installation	236	Stall Speed	255	
Inspection	236	Line Pressure	255	
DIFFERENTIAL SIDE OIL SEAL	238	Torque Converter	255	P
		Heater Thermostat	256	

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000008273945

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:


Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precaution for Procedure without Cowl Top Cover

INFOID:000000008273946

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc to prevent damage to windshield.



Service Notice or Precautions for Manual Transaxle

INFOID:000000008273947

CAUTION:

- Never reuse CSC (Concentric Slave Cylinder). Because CSC slides back to the original position every time when removing transaxle assembly. At this timing, dust on the sliding parts may damage a seal of CSC and may cause clutch fluid leakage. Refer to [CL-17, "Removal and Installation"](#).
- Never reuse transaxle gear oil, once it has been drained.
- Check oil level or replace gear oil with vehicle on level surface.
- During removal or installation, keep inside of transaxle clear of dust or dirt.
- Check for the correct installation status prior to removal or disassembly. If matching marks are required, be certain they never interfere with the function of the parts they are applied.

PRECAUTIONS

< PRECAUTION >

[6MT: RS6F94R]

- In principle, tighten bolts or nuts gradually in several steps working diagonally from inside to outside. If tightening sequence is specified, use it.
- Never damage sliding surfaces and mating surfaces.

A

B

C

TM

E

F

G

H

I

J

K

L

M

N

O

P

PREPARATION

< PREPARATION >

[6MT: RS6F94R]






PREPARATION

PREPARATION

Special Service Tools

INFOID:000000008273948







The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
KV381054S0 (J-34286) Puller  ZZA0601D	Removing mainshaft front bearing outer race
KV38100200 (-) Drift a: 65 mm (2.56 in) dia. b: 49 mm (1.93 in) dia.  ZZA1143D	<ul style="list-style-type: none"> • Installing mainshaft front bearing outer race • Installing mainshaft rear bearing outer race • Installing differential side bearing outer race (clutch housing side)
ST33220000 (-) Drift a: 37 mm (1.46 in) dia. b: 31 mm (1.22 in) dia. c: 22 mm (0.87 in) dia.  ZZA1046D	Installing input shaft oil seal
ST33400001 (J-26082) Drift a: 60 mm (2.36 in) dia. b: 47 mm (1.85 in) dia.  ZZA0814D	Installing differential side bearing outer race (transaxle case side)
KV32500QAA (-) (Renault SST: B.vi 1666) Drift set 1. — (-) (Stamping number: B.vi 1666-A) Drift a: 54.3 mm (2.138 in) dia. b: 45 mm (1.77 in) dia. c: 26.6 mm (1.047 in) dia. 2. — (-) (Stamping number: B.vi 1666-B) Drift d: 54 mm (2.13 in) dia. e: 48.6 mm (1.913 in) dia. f: 26.6 mm (1.047 in) dia.  JPDIC0730ZZ	Installing differential side oil seal

PREPARATION

< PREPARATION >

[6MT: RS6F94R]

Tool number (Kent-Moore No.) Tool name	Description	
ST36720030 (-) Drift a: 70 mm (2.76 in) dia. b: 40 mm (1.57 in) dia. c: 29 mm (1.14 in) dia.	 <p style="text-align: center; font-size: small;">ZZA0978D</p>	A B C
ST33052000 (-) Drift a: 22 mm (0.87 in) dia. b: 28 mm (1.10 in) dia.	 <p style="text-align: center; font-size: small;">ZZA0969D</p>	TM E F G
KV32102700 (-) Drift a: 48.6 mm (1.913 in) dia. b: 41.6 mm (1.638 in) dia.	 <p style="text-align: center; font-size: small;">S-NT065</p>	H I
ST30901000 (J-26010-01) Drift a: 79 mm (3.11 in) dia. b: 45 mm (1.77 in) dia. c: 35.2 mm (1.386 in) dia.	 <p style="text-align: center; font-size: small;">ZZA0978D</p>	J K
ST33061000 (J-8107-2) Drift a: 28.5 mm (1.122 in) dia. b: 38 mm (1.50 in) dia.	 <p style="text-align: center; font-size: small;">ZZA0969D</p>	L M N
KV32300QAM (-) (Renault SST: B.vi 1823) Drift	 <p style="text-align: center; font-size: small;">PCIB2078J</p>	O P







PREPARATION

< PREPARATION >

[6MT: RS6F94R]

Commercial Service Tools






INFOID:000000008273949

Tool name	Description
<p>Socket a: 8 mm (0.31 in) b: 5 mm (0.20 in)</p>  <p>PCIB1776E</p>	<p>Removing and installing drain plug</p>
<p>Spacer a: 25 mm (0.98 in) dia. b: 25 mm (0.98 in)</p>  <p>PCIB1780E</p>	<p>Removing mainshaft front bearing outer race</p>
<p>Drift a: 17 mm (0.67 in) dia.</p>  <p>S-NT063</p>	<p>Installing bushing</p>
<p>Drift a: 24 mm (0.94 in) dia.</p>  <p>PCIB1779E</p>	<p>Removing input shaft rear bearing</p>
<p>Drift a: 35 mm (1.38 in) dia. b: 25 mm (0.98 in) dia.</p>  <p>S-NT065</p>	<p>Installing input shaft front bearing</p>
<p>Drift a: 43 mm (1.69 in) dia.</p>  <p>NT109</p>	<ul style="list-style-type: none"> • Installing input shaft rear bearing • Removing differential side bearing inner race (transaxle case side)

PREPARATION

< PREPARATION >

[6MT: RS6F94R]

Tool name	Description	
Drift a: 45 mm (1.77 in) dia. b: 39 mm (1.54 in) dia.	Installing differential side bearing inner race (clutch housing side)	A
 <p style="text-align: center;">S-NT474</p>		B
Drift a: 52 mm (2.05 in) dia. b: 45 mm (1.77 in) dia.	Installing differential side bearing inner race (transaxle case side)	C
 <p style="text-align: center;">S-NT474</p>		TM
Puller	<ul style="list-style-type: none"> • Removing differential side bearing inner race (clutch housing side) • Removing differential side bearing inner race (transaxle case side) 	E
 <p style="text-align: center;">NT077</p>		F
Puller	<ul style="list-style-type: none"> • Removing differential side bearing inner race (clutch housing side) • Removing differential side bearing inner race (transaxle case side) • Removing input shaft rear bearing • Removing input shaft front bearing • Removing mainshaft rear bearing inner race • Removing 6th main gear • Removing 4th main gear • Removing 5th main gear • Removing 1st main gear • Removing 1st-2nd synchronizer hub assembly • Removing 2nd main gear • Removing 3rd main gear • Removing mainshaft front bearing inner race 	G
 <p style="text-align: center;">ZZB0823D</p>		H
Remover	<ul style="list-style-type: none"> • Removing bushing • Removing mainshaft rear bearing outer race 	I
 <p style="text-align: center;">S-NT134</p>		J

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION


COMPONENT PARTS

Component Parts Location

INFOID:000000008273950

POSITION SWITCH

1 : Position switch



STRUCTURE AND OPERATION


< SYSTEM DESCRIPTION >

[6MT: RS6F94R]

STRUCTURE AND OPERATION

Sectional View

INFOID:000000008273951



JPDIC0631ZZ

- | | | |
|---------------------------------------|--------------------------------------|------------------------|
| 1. 3rd input gear | 2. 3rd-4th synchronizer hub assembly | 3. 4th input gear |
| 4. 5th input gear | 5. 5th-6th synchronizer hub assembly | 6. 6th input gear |
| 7. Transaxle case | 8. 6th main gear | 9. 5th main gear |
| 10. 4th main gear | 11. 3rd main gear | 12. 2nd main gear |
| 13. 1st-2nd synchronizer hub assembly | 14. 1st main gear | 15. Differential |
| 16. Final gear | 17. Mainshaft | 18. Input shaft |
| 19. Clutch housing | 20. Reverse idler shaft | 21. Reverse input gear |
| 22. Reverse output gear | | |

System Description

INFOID:000000008273952

TRIPLE-CONE SYNCHRONIZER

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P


STRUCTURE AND OPERATION

< SYSTEM DESCRIPTION >

[6MT: RS6F94R]

Triple-cone synchronizers are adopted for the 1st and the 2nd gears to reduce operating force of the shifter lever.


- 1 : 1st main gear
- 2 : 1st-2nd coupling sleeve
- 3 : Insert key
- 4 : Outer baulk ring
- 5 : 2nd main gear
- 6 : Synchronizer cone
- 7 : Inner baulk ring
- 8 : 1st-2nd synchronizer hub



REVERSE GEAR NOISE PREVENTION FUNCTION (SYNCHRONIZING METHOD)

Reverse gear assembly consists of reverse input gear, return spring, reverse baulk ring, and reverse output gear. When the shifter lever is shifted to the reverse position, the construction allows smooth shift operation by stopping the reverse idler shaft rotation by frictional force of synchronizer.

- 1 : Reverse fork rod
- 2 : Reverse output gear
- 3 : Return spring
- 4 : Reverse baulk ring
- 5 : Reverse input gear



DTC/CIRCUIT DIAGNOSIS

POSITION SWITCH

BACK-UP LAMP SWITCH


BACK-UP LAMP SWITCH : Component Inspection

INFOID:000000008273953

1. CHECK BACK-UP LAMP SWITCH

1. Disconnect position switch connector. Refer to [TM-19, "Removal and Installation"](#).
2. Check continuity between position switch terminals.

Terminals		Condition	Continuity
1	2	Reverse gear position	Existed
		Except reverse gear position	Not existed



Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace position switch. Refer to [TM-19, "Removal and Installation"](#).

PARK/NEUTRAL POSITION (PNP) SWITCH


PARK/NEUTRAL POSITION (PNP) SWITCH : Component Inspection

INFOID:000000008273954

1. CHECK PARK/NEUTRAL POSITION (PNP) SWITCH

1. Disconnect position switch connector. Refer to [TM-19, "Removal and Installation"](#).
2. Check continuity between position switch terminals.

Terminals		Condition	Continuity
2	3	Neutral gear position	Existed
		Except neutral gear position	Not existed



Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace position switch. Refer to [TM-19, "Removal and Installation"](#).

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

< SYMPTOM DIAGNOSIS >

[6MT: RS6F94R]

SYMPTOM DIAGNOSIS

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

NVH Troubleshooting Chart

INFOID:000000008273955

Use the chart below to find the cause of the symptom. The numbers indicate the order of the inspection. If necessary, repair or replace these parts.

SUSPECTED PARTS (Possible cause)													
		OIL (Oil level is low)	OIL (Wrong oil)	OIL (Oil level is high)	GASKET (Damaged)	OIL SEAL (Worn or damaged)	O-RING (Worn or damaged)	SHIFT CONTROL LINKAGE (Worn)	SHIFT FORK (Worn)	GEAR (Worn or damaged)	BEARING (Worn or damaged)	BAULK RING (Worn or damaged)	INSERT SPRING (Damaged)
Reference		TM-17			TM-27			TM-23	TM-27	TM-27			
Symptoms	Noise	1	2							3	3		
	Oil leakage		3	1	2	2	2						
	Hard to shift or will not shift		1	1				2				3	3
	Jumps out of gear							1	2	2			

PERIODIC MAINTENANCE

GEAR OIL

Inspection


INFOID:000000008273956

OIL LEAKAGE

Make sure that gear oil is not leaking from transaxle or around it.

OIL LEVEL


1. Remove filler plug (1) and gasket from transaxle case.
2. Check the oil level from filler plug mounting hole as shown in the figure.
CAUTION:
Never start engine while checking oil level.
3. Set a gasket on filler plug and then install it to transaxle case.
CAUTION:
Never reuse gasket.
4. Tighten filler plug to the specified torque. Refer to [TM-27](#), "[Exploded View](#)".



INFOID:000000008273957

Draining

1. Start engine and let it run to warm up transaxle.
2. Stop engine. Remove drain plug (1) and gasket, using a socket [Commercial service tool] and then drain gear oil.
3. Set a gasket on drain plug and install it to clutch housing, using a socket [Commercial service tool].
CAUTION:
Never reuse gasket.
4. Tighten drain plug to the specified torque. Refer to [TM-27](#), "[Exploded View](#)".



INFOID:000000008273958


Refilling

1. Remove filler plug (1) and gasket from transaxle case.
2. Fill with new gear oil until oil level reaches the specified limit at filler plug mounting hole as shown in the figure.

Oil grade and viscosity : Refer to [MA-10](#), "[Fluids and Lubricants](#)".

Oil capacity : Refer to [TM-62](#), "[General Specifications](#)".

3. After refilling gear oil, check the oil level. Refer to [TM-17](#), "[Inspection](#)".
4. Set a gasket on filler plug and then install it to transaxle case.
CAUTION:
Never reuse gasket.
5. Tighten filler plug to the specified torque. Refer to [TM-27](#), "[Exploded View](#)".



A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

REMOVAL AND INSTALLATION

SIDE OIL SEAL

Removal and Installation

INFOID:000000008273959


REMOVAL

1. Remove front drive shafts. Refer to [FAX-19, "LEFT SIDE : Removal and Installation"](#) (LEFT SIDE) and [FAX-21, "RIGHT SIDE : Removal and Installation"](#) (RIGHT SIDE).

2. Remove differential side oil seals (1) from clutch housing and transaxle case, using an oil seal remover.

CAUTION:

Never damage transaxle case and clutch housing.



INSTALLATION

Note the following, and install in the reverse order of removal.

- Install differential side oil seals (1) to clutch housing and transaxle case, using the drift [Stamping number: B.vi 1666-B] of the drift set [SST: KV32500QAA (-)].

A : Transaxle case side


B : Clutch housing side

Dimension "L1" : 1.2 – 1.8 mm (0.047 – 0.071 in)

Dimension "L2" : 2.7 – 3.3 mm (0.106 – 0.130 in)

CAUTION:

- **Never incline differential side oil seal.**
- **Never damage clutch housing and transaxle case.**



Inspection

INFOID:000000008273960

INSPECTION AFTER INSTALLATION

Check the oil level and oil leakage. Refer to [TM-17, "Inspection"](#).

POSITION SWITCH

< REMOVAL AND INSTALLATION >

[6MT: RS6F94R]

POSITION SWITCH

Removal and Installation

INFOID:000000008273961

REMOVAL

1. Remove battery. Refer to [PG-96, "Removal and Installation"](#).
2. Disconnect position switch connector.
3. Remove position switch from transaxle case.

INSTALLATION

1. Apply recommended sealant to threads of position switch.
 - Use Genuine Silicone RTV or an equivalent. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).

CAUTION:

Remove old sealant and oil adhering to threads.

2. Install position switch to transaxle case.
3. Tighten position switch to the specified torque. Refer to [TM-27, "Exploded View"](#).
4. For the next step and after, install in the reverse order of removal.

Inspection

INFOID:000000008273962

INSPECTION AFTER INSTALLATION

- Check continuity between position switch terminals. Refer to [TM-15, "BACK-UP LAMP SWITCH : Component Inspection"](#) (Back-up lamp switch) and [TM-15, "PARK/NEUTRAL POSITION \(PNP\) SWITCH : Component Inspection"](#) (PNP switch).
- Check the oil leakage. Refer to [TM-17, "Inspection"](#).

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

CONTROL LINKAGE


< REMOVAL AND INSTALLATION >

[6MT: RS6F94R]

CONTROL LINKAGE

Exploded View

INFOID:000000008273963



JPDIC0830GB

- | | | |
|--------------------|------------------------|--------------------------------|
| 1. Bracket | 2. Shifter cable | 3. Selector lever |
| 4. Shifter lever A | 5. Tapping bolt | 6. Cable mounting bracket |
| 7. Selector cable | 8. Grommet | 9. M/T shift selector assembly |
| 10. Shifter lever | 11. Shifter lever knob | |

⊗: Always replace after every disassembly.

⊞: N-m (kg-m, ft-lb)

⊞: N-m (kg-m, in-lb)

Removal and Installation

INFOID:000000008273964

REMOVAL

1. Shift the shifter lever to the neutral position.
2. Remove air cleaner case. Refer to [EM-25, "Removal and Installation"](#).

CONTROL LINKAGE


< REMOVAL AND INSTALLATION >

[6MT: RS6F94R]



3. Remove bracket (1), as per the following procedure.

↶ : Vehicle front


- Disconnect clips (A) from bracket.
- Remove bolts (B) from bracket.
- Remove bracket.
- Pull out and disconnect the each cable from the shifter lever A and the selector lever, using a suitable remover.



- While pressing the lock of the selector cable in the direction of the arrow shown in the figure, remove the selector cable from the cable mounting bracket.
- While pressing the lock of the shifter cable in the direction of the arrow shown in the figure, remove the shifter cable from the cable mounting bracket.
- Remove cable mounting bracket from transaxle case.
- Pull the shifter lever knob upward to remove.
- Remove center console assembly. Refer to [JP-22, "Removal and Installation"](#).
- Pull out and disconnect the shifter cable from the pin of the M/T shift selector assembly, using a suitable remover.
- Pull up the stopper (A) of the selector cable in the direction of the arrow as shown in the figure.
- Pull out and disconnect the selector cable from the pin of the M/T shift selector assembly, using a suitable remover.



- While pressing the lock of the selector cable in the direction of the arrow shown in the figure, remove the selector cable from the M/T shift selector assembly.
- While pressing the lock of the shifter cable in the direction of the arrow shown in the figure, remove the shifter cable from the M/T shift selector assembly.
- Remove the M/T shift selector assembly.
- Remove three way catalyst and heat plate. Refer to [EX-8, "Removal and Installation"](#).
- Remove the bracket from the vehicle.




CONTROL LINKAGE

< REMOVAL AND INSTALLATION >

[6MT: RS6F94R]

18. Disengage the pawls (A) of the grommet (1), and pull downwards to remove.
19. Remove the shifter cable and selector cable from the vehicle.



INSTALLATION

Note the following, and install in the reverse order of removal.

CAUTION:

- Install each cable without causing interference with other parts, a 120 mm (4.72 in)-or-less bend, and a 180-degrees-or-more twist.
- Install boot of each cable without causing interference with other parts and a 90-degrees-or-more twist.
- Fit boot of to center console assembly the groove on shifter lever knob.
- To install the shifter lever knob, press it into the shifter lever.


CAUTION:

- Never reuse shifter lever knob.
- Be careful with orientation of shifter lever knob.
- Tapping work for tapping bolts is not applied to new transaxle case. Do not perform tapping by other than screwing tapping bolts because tapping is formed by screwing tapping bolts into transaxle case.

CAUTION:

Never reuse tapping bolt.

- Insert the each cable until it reaches the cable mounting bracket and M/T shift selector assembly.
- Insert the each cable until it reaches the shifter lever A and the selector lever.
- Shift the shifter lever to the neutral position.
- Install the shifter cable (1) and the selector cable (2) to the bracket (3) as shown in the figure.



Install the selector cable (the M/T shift selector assembly side), as per the following procedure.


When M/T shift selector assembly is replaced:

1. Install the selector cable to the M/T shift selector assembly.
2. Shift the shifter lever to the neutral position.
3. Install the lever stopper (A) to the M/T shift selector assembly as shown in the figure.

CAUTION:

Selector cable cannot be adjusted accurately without using the lever stopper.

4. Check that the shifter lever does not move in the direction of the select. If it moves, repeat step 3.




CONTROL LINKAGE

< REMOVAL AND INSTALLATION >

[6MT: RS6F94R]


5. Insert the stopper (A) until it reaches the selector cable.
6. Remove the lever stopper from the M/T shift selector assembly.
7. Shift the shifter lever to each gear position to check that there are no bindings. If any, repeat step 3.




When M/T shift selector assembly is not replaced:

1. Install the selector cable to the M/T shift selector assembly.
2. Shift the shifter lever to the 4th gear position.
3. Adjust the length "L" between the stopper (A) and the lever to the standard value.

Length "L" : 3.51 – 4.11 mm (0.1382 – 0.1618 in)



4. Insert the stopper (A) until it reaches the selector cable.
5. Shift the shifter lever to each gear position to check that there are no bindings. If any, repeat step 3.



Inspection

INSPECTION AFTER INSTALLATION

Shifter Lever Knob

Check that the shifter lever knob is installed in the right position.

Shifter Cable and Selector Cable

- Pull each cable in the removal direction to check that it does not disconnect from the cable mounting bracket.
- Pull each cable in the removal direction to check that it does not disconnect from the M/T shift selector assembly.
- Pull grommet in the removal direction to check that it does not disconnect from the vehicle.

M/T Shift Selector Assembly and Shifter Lever

- Check that there is no tangle, hook, abnormal sound, looseness, and interference when the shifter lever is moved to each position. If there is a malfunction, then repair or replace the malfunctioning part.
- Check that the shifter lever smoothly returns to the neutral position after moving the lever from 1st to 2nd gear and moving hands off the lever. If there is a malfunction, then repair or replace the malfunctioning part.
- Check that the shifter lever smoothly returns to the neutral position after moving the lever from 5th to 6th gear and moving hands off the lever. If there is a malfunction, then repair or replace the malfunctioning part.

INFOID:000000008273965

AIR BREATHER HOSE


< REMOVAL AND INSTALLATION >

[6MT: RS6F94R]

AIR BREATHER HOSE

Exploded View

INFOID:000000008273966



1. Clip

2. Air breather hose

3. 2 way connector

Removal and Installation

INFOID:000000008273967

REMOVAL


1. Remove air cleaner case. Refer to [EM-25, "Removal and Installation"](#).
2. Remove clips (1).

← : Vehicle front

3. Remove air breather hose from the 2 way connector.

CAUTION:

When removing air breather hose, be sure to hold 2 way connector securely.



INSTALLATION

Note the following, and install in the reverse order of removal.

CAUTION:


- Install air breather hose, preventing crush and clogging caused by bending.
- Insert the allowance of air breather hose to the spool of the 2 way connector.
- Install air breather hose to the 2 way connector with the paint mark faced forward of the vehicle.
- Securely engage the clips in the mounting hole.

UNIT REMOVAL AND INSTALLATION

TRANSAXLE ASSEMBLY

Exploded View

INFOID:000000008273968



1. Transaxle assembly

△ : Refer to "INSTALLATION" in [TM-25, "Removal and Installation"](#) for the locations and tightening torque.

Removal and Installation

INFOID:000000008273969

CAUTION:

Never reuse CSC (Concentric Slave Cylinder). Because CSC slides back to the original position every time when removing transaxle assembly. At this timing, dust on the sliding parts may damage a seal of CSC and may cause clutch fluid leakage. Refer to [CL-17, "Removal and Installation"](#).

REMOVAL

1. Disconnect battery cable from negative terminal. Refer to [PG-96, "Removal and Installation"](#).
 2. Shift the shifter lever to the neutral position.
 3. Remove battery. Refer to [PG-96, "Removal and Installation"](#).
 4. Remove air cleaner case. Refer to [EM-25, "Removal and Installation"](#).
 5. Remove air breather hose. Refer to [TM-24, "Removal and Installation"](#).
 6. Disconnect position switch connector. Refer to [TM-19, "Removal and Installation"](#).
 7. Remove harness clip from transaxle assembly.
 8. Disconnect selector cable and shifter cable from transaxle assembly. Refer to [TM-20, "Removal and Installation"](#).
 9. Remove starter motor. Refer to [STR-24, "Removal and Installation"](#).
 10. Remove clutch tube from CSC (Concentric Slave Cylinder). Refer to [CL-15, "Removal and Installation"](#).
- CAUTION:**
- Keep painted surface on the body or other parts free of clutch fluid. If it spills, wipe up immediately and wash the affected area with water.
 - Never depress clutch pedal during removal procedure.
11. Remove engine under cover.
 12. Remove fender protector LH. Refer to [EXT-26, "Removal and Installation"](#).
 13. Disconnect ground cable.
 14. Remove front suspension member. Refer to [FSU-14, "Removal and Installation"](#).

TRANSAXLE ASSEMBLY

< UNIT REMOVAL AND INSTALLATION >

[6MT: RS6F94R]

15. Remove front drive shafts. Refer to [FAX-19, "LEFT SIDE : Removal and Installation"](#) (LEFT SIDE) and [FAX-21, "RIGHT SIDE : Removal and Installation"](#) (RIGHT SIDE).

NOTE:

Insert a suitable plug into differential side oil seal after removing front drive shaft.

16. Set a suitable jack to transaxle assembly and then set a suitable jack to engine assembly.

CAUTION:

When setting a suitable jack, be careful so that it does not contact with the switch.

17. Remove engine mounting bracket (LH) mounting bolts from transaxle assembly. Refer to [EM-60, "2WD : Removal and Installation"](#).

18. Remove rear torque rod bracket and rear torque rod. Refer to [EM-60, "2WD : Removal and Installation"](#).

19. Remove transaxle assembly mounting bolts.

20. Remove transaxle assembly from the engine.

CAUTION:

- Fix transaxle assembly to a suitable jack.
- The transaxle assembly must not interfere with the wire harnesses and clutch tube.

21. Remove CSC. Refer to [CL-17, "Removal and Installation"](#).


INSTALLATION

Note the following, and install in the reverse order of removal.

CAUTION:

- Fix transaxle assembly to a suitable jack.
- The transaxle assembly must not interfere with the wire harnesses and clutch tube.
- When installing transaxle assembly, never bring input shaft into contact with clutch cover.
- Tapping work for tapping bolts is not applied to new transaxle case. Do not perform tapping by other than screwing tapping bolts because tapping is formed by screwing tapping bolts into transaxle case.
- Tighten transaxle assembly mounting bolts to the specified torque. The figure is the view from the engine.

Bolt symbol	A	B
Insertion direction	Transaxle to engine	Engine to transaxle
Quantity	3	6
Bolt length "ℓ" mm (in)	60 (2.36)	50 (1.97)
Tightening torque N·m (kg·m, ft·lb)	62.0 (6.3, 46)	



Inspection

INFOID:000000008273970

INSPECTION AFTER INSTALLATION

- Check the operation of the control linkage. Refer to [TM-23, "Inspection"](#).
- Check the oil leakage and the oil level. Refer to [TM-17, "Inspection"](#).

TRANSAXLE ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F94R]


UNIT DISASSEMBLY AND ASSEMBLY

TRANSAXLE ASSEMBLY

Exploded View

INFOID:000000008273971

CASE AND HOUSING



- | | | |
|--------------------------------|--------------------|---------------------|
| 1. Filler plug | 2. Gasket | 3. Transaxle case |
| 4. Bushing | 5. Snap ring | 6. Oil channel |
| 7. Oil gutter | 8. Position switch | 9. Bracket |
| 10. Differential side oil seal | 11. Magnet | 12. Drain plug |
| 13. Input shaft oil seal | 14. Clutch housing | 15. 2 way connector |
| 16. Plug | 17. Pinion shaft | 18. Pinion gear |

: Apply Genuine Silicone RTV or an equivalent. Refer to [GI-22. "Recommended Chemical Products and Sealants"](#).

: Always replace after every disassembly.

TRANSAXLE ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >


[6MT: RS6F94R]

★ : Select with proper thickness.

: N·m (kg·m, ft·lb)

: N·m (kg·m, in·lb)

SHAFT AND GEAR



- | | | |
|------------------------------|-----------------------------|------------------------------|
| 1. Input shaft front bearing | 2. Input shaft | 3. 3rd input gear |
| 4. Spacer | 5. Snap ring | 6. 3rd baulk ring |
| 7. 3rd-4th coupling sleeve | 8. 3rd-4th synchronizer hub | 9. Insert key |
| 10. 4th baulk ring | 11. 4th input gear | 12. 5th input gear |
| 13. 5th baulk ring | 14. 5th-6th coupling sleeve | 15. 5th-6th synchronizer hub |
| 16. 6th baulk ring | 17. Needle bearing | 18. 6th input gear |
| 19. Input shaft rear bearing | | |
| A. First step | B. Final step | |

: Apply gear oil.

: Replace the parts as a set.


: Always replace after every disassembly.

: N·m (kg·m, ft·lb)

TRANSAXLE ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F94R]



- | | | |
|---------------------------------------|---------------------------------------|---|
| 1. Mainshaft front bearing outer race | 2. Mainshaft front bearing inner race | 3. Mainshaft |
| 4. 1st main gear | 5. 1st inner baulk ring | 6. 1st synchronizer cone |
| 7. 1st outer baulk ring | 8. 1st-2nd coupling sleeve | 9. Insert key |
| 10. 1st-2nd synchronizer hub | 11. 2nd outer baulk ring | 12. 2nd synchronizer cone |
| 13. 2nd inner baulk ring | 14. 2nd main gear | 15. Bushing |
| 16. 3rd main gear | 17. Mainshaft adjusting shim | 18. 4th main gear |
| 19. 5th main gear | 20. 6th main gear | 21. Mainshaft rear bearing inner race |
| 22. Mainshaft rear bearing outer race | 23. Snap ring | 24. Mainshaft rear bearing adjusting shim |



: Apply gear oil.



: Replace the parts as a set.

★ : Select with proper thickness.




: Always replace after every disassembly.

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

TRANSAXLE ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F94R]



- | | | |
|------------------------|-------------------|-----------------------|
| 1. Reverse output gear | 2. Snap ring | 3. Reverse baulk ring |
| 4. Return spring | 5. Needle bearing | 6. Seal washer |
| 7. Reverse idler shaft | 8. Spacer | 9. Reverse input gear |
| 10. Lock washer | 11. Spring washer | |

■: Replace the parts as a set.

⊗: Always replace after every disassembly.


🔩: N·m (kg-m, ft-lb)

SHIFT FORK AND FORK ROD

TRANSAXLE ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F94R]



- | | | |
|---------------------|--------------------|---------------------|
| 1. Shifter lever A | 2. Shifter lever B | 3. Retaining pin |
| 4. Selector | 5. Selector lever | 6. Reverse fork rod |
| 7. 1st-2nd fork rod | 8. Fork rod | |

■ : Replace the parts as a set.

⊗ : Always replace after every disassembly.


FINAL DRIVE

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

TRANSAXLE ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F94R]



- | | | |
|---|---|---|
| 1. Shim | 2. Differential side bearing outer race (transaxle case side) | 3. Differential side bearing inner race (transaxle case side) |
| 4. Final gear | 5. Differential case | 6. Differential side bearing inner race (clutch housing side) |
| 7. Differential side bearing outer race (clutch housing side) | | |


■ : Replace the parts as a set.

☞ : N·m (kg-m, ft-lb)

Disassembly

INFOID:000000008273972

1. Remove drain plug and gasket from clutch housing, using a socket [Commercial service tool] and then drain gear oil.
2. Remove filler plug and gasket from transaxle case.
3. Remove selector lever (1) retaining pin with a pin punch to remove selector lever.
4. Remove bracket (2) and position switch (3) from transaxle case.




TRANSAXLE ASSEMBLY


< UNIT DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F94R]


5. Remove transaxle case mounting bolts (←).




6. Remove reverse idler shaft mounting bolt (←) and seal washer.




7. Remove transaxle case (2) while rotating shifter lever A (1) in the direction as shown in the figure.



8. Remove selector spring (1) from return bushing (A).



9. Shift 1st-2nd fork rod (1), fork rod (2), and reverse fork rod (3) to the neutral position.
10. Remove selector (4) from clutch housing.



A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

TRANSAXLE ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F94R]

11. Remove reverse idler shaft assembly (1), as per the following procedure.


- a. Pull up input shaft assembly (2), mainshaft assembly (3), fork rod (4), and 1st-2nd fork rod (5).

NOTE:

It is easier to pull up when shifting each fork rod to each shaft side.

- b. Remove reverse idler shaft assembly and reverse fork rod (6) from clutch housing.


12. Remove spring washer from clutch housing.



13. Pull up and remove input shaft assembly (1), mainshaft assembly (2), fork rod (3), and 1st-2nd fork rod (4) from clutch housing.


NOTE:

It is easier to pull up when shifting each fork rod to each shaft side.



14. Remove final drive assembly (1) from clutch housing.


15. Remove magnet from clutch housing.



16. Remove differential side oil seals (1) from clutch housing and transaxle case.

CAUTION:


Never damage clutch housing and transaxle case.



17. Remove differential side bearing outer race (1) from clutch housing, using a brass rod.

CAUTION:

Never damage clutch housing.



TRANSAXLE ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >


[6MT: RS6F94R]

18. Remove differential side bearing outer race (1) from transaxle case, using a brass rod.


CAUTION:

Never damage transaxle case.


19. Remove shim (2) from transaxle case.




20. Remove shifter lever A (1) retaining pin, using a pin punch.
21. Remove shifter lever A from transaxle case.




22. Remove shifter lever B (1) from transaxle case.



23. Remove oil gutter (1) from transaxle case.



24. Remove bushings (1) from transaxle case, using a remover [Commercial service tool].




A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

TRANSAXLE ASSEMBLY


< UNIT DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F94R]

25. Remove mainshaft rear bearing outer race from transaxle case, using a remover [Commercial service tool].
26. Remove mainshaft rear bearing adjusting shim from transaxle case.




27. Remove snap ring (1) and oil channel (2) from transaxle case.




28. Remove input shaft oil seal (1) from clutch housing, using an oil seal remover.

CAUTION:
Never damage clutch housing.




29. Remove mainshaft front bearing outer race (1) from clutch housing, using the puller (A) [SST: KV381054S0 (J-34286)] and a spacer (B) [Commercial service tool].

30. Remove oil channel (2) from clutch housing.



31. Remove bushing (1) from clutch housing, using a remover [Commercial service tool].




TRANSAXLE ASSEMBLY


< UNIT DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F94R]

32. Remove 2 way connector (1) from clutch housing.
33. Remove plug from clutch housing.




34. Remove pinion gear (1) and pinion shaft (2) from clutch housing.




Assembly

INFOID:000000008273973

1. Install pinion gear (1) and pinion shaft (2) to clutch housing.
CAUTION:
Replace transaxle assembly when replacing clutch housing.
2. Install plug to clutch housing.



3. Install 2 way connector (1) to clutch housing.



A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

TRANSAXLE ASSEMBLY


< UNIT DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F94R]

4. Install bushings (1) so that they become even to clutch housing edge surface, using a drift (A) [Commercial service tool].
5. Install oil channel to clutch housing.

CAUTION:


Never reuse oil channel.




6. Install mainshaft front bearing outer race to clutch housing, using the drift (A) [SST: KV38100200 (-)].

CAUTION:

Replace mainshaft front bearing outer race and mainshaft front bearing inner race as a set.



7. Install input shaft oil seal (1) to clutch housing, using the drift (A) [SST: ST33220000 (-)].



8. Install snap ring (1) and oil channel (2) to transaxle case.

CAUTION:


- Select and install snap ring that has the same thickness as previous one.
- Replace transaxle assembly when replacing transaxle case.

9. Install mainshaft rear bearing adjusting shim to transaxle case.

CAUTION:

Select mainshaft rear bearing adjusting shim, as per the following procedure when replacing mainshaft adjusting shim, 6th main gear, 5th main gear, or 4th main gear.

- Replace mainshaft adjusting shim.
 - If new mainshaft adjusting shim is thinner than previous one, offset the thickness difference by selecting thicker mainshaft rear bearing adjusting shim.
 - If new mainshaft adjusting shim is thicker than previous one, offset the thickness difference by selecting thinner mainshaft rear bearing adjusting shim.
- Replace 6th main gear, 5th main gear, or 4th main gear.
 - Measure the thickness of the main gear used before and the new main gear
 - Increase the thickness of the mainshaft rear bearing adjusting shim, if the difference is smaller than 0.025 mm (0.0010 in).
 - Decrease the thickness of the mainshaft rear bearing adjusting shim, if the difference is greater than 0.025 mm (0.0010 in).



TRANSAXLE ASSEMBLY


< UNIT DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F94R]


10. Install mainshaft rear bearing outer race to transaxle case, using the drift (A) [SST: KV38100200 (-)].

CAUTION:


Replace mainshaft rear bearing outer race and mainshaft rear bearing inner race as a set.



11. Install bushings (1) to transaxle case, using a drift (A) [Commercial service tool].



12. Install oil gutter (1) to transaxle case.



13. Install shifter lever B (1) to transaxle case.


CAUTION:

Replace shifter lever A and shifter lever B as a set.

14. Install shifter lever A to transaxle case.

CAUTION:

Replace shifter lever A and shifter lever B as a set.




15. Install retaining pin to shifter lever A (1), using a pin punch.

CAUTION:

Never reuse retaining pin.

16. Install shim to transaxle case.



A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

TRANSAXLE ASSEMBLY


< UNIT DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F94R]

17. Install differential side bearing outer race (transaxle case side) to transaxle case, using the drift (A) [SST: ST33400001 (J-26082)].

CAUTION:


Replace differential side bearing outer race (transaxle case side) and differential side bearing inner race (transaxle case side) as a set.



18. Install differential side bearing outer race (clutch housing side) to clutch housing, using the drift (A) [SST: KV38100200 (-)].

CAUTION:

Replace differential side bearing outer race (clutch housing side) and differential side bearing inner race (clutch housing side) as a set.



19. Install differential side oil seals (1) to clutch housing and transaxle case, using the drift [Stamping number: B.vi 1666-B] of the drift set [SST: KV32500QAA (-)].

A : Transaxle case side


B : Clutch housing side

Dimension "L1" : 1.2 – 1.8 mm (0.047 – 0.071 in)


Dimension "L2" : 2.7 – 3.3 mm (0.106 – 0.130 in)

CAUTION:

- Never incline differential side oil seal.
- Never damage clutch housing and transaxle case.



20. Install magnet to clutch housing.
21. Install final drive assembly to clutch housing.
22. Set fork rod (1) to input shaft assembly (2), and then install them to clutch housing.




TRANSAXLE ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F94R]

23. Install mainshaft assembly (1), as per the following procedure.

- Pull up input shaft assembly (2) and fork rod (3).
- Set 1st-2nd fork rod (4) to mainshaft assembly, and then install them to clutch housing.




24. Install reverse idler shaft assembly (1), as per the following procedure.

- Install spring washer to clutch housing.
- Pull up input shaft assembly (2), mainshaft assembly (3), fork rod (4), and 1st-2nd fork rod (5).

NOTE:

It is easier to pull up when shifting each fork rod to each shaft side.

- Set reverse fork rod (6) to reverse idler shaft assembly, and then install them to clutch housing.




25. Shift 1st-2nd fork rod (1), fork rod (2), and reverse fork rod (3) to the neutral position.

26. Install selector (4) to clutch housing.

CAUTION:

Replace selector lever and selector as a set.




27. Install selector spring (1) to return bushing (A).

28. Apply recommended sealant to mounting surface of transaxle case.


- Use Genuine Silicone RTV or an equivalent. Refer to [GI-22. "Recommended Chemical Products and Sealants"](#).

CAUTION:

- Never allow old liquid gasket, moisture, oil, or foreign matter to remain on mounting surface.
- Check that mounting surface is not damaged.
- Apply sealant bead continuously.



29. Install transaxle case to clutch housing while rotating shifter lever A (1) in the direction as shown in the figure.



A

B

C

TM

E

F

G

H

I

J

K

L

M

N

O

P

TRANSAXLE ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F94R]


30. Install reverse idler shaft mounting bolt (←), as per the following procedure.

a. Install seal washer to reverse idler shaft mounting bolt, and install reverse idler shaft mounting bolt to transaxle case.


CAUTION:

Never reuse seal washer.

b. Tighten reverse idler shaft mounting bolt to the specified torque.



31. Tighten transaxle case mounting bolts (←) to the specified torque.



32. Install position switch (1), as per the following procedure.

a. Apply recommended sealant to threads of position switch.

• Use Genuine Silicone RTV or an equivalent. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).

CAUTION:

Never allow old liquid gasket, moisture, oil, or foreign matter to remain on thread.

b. Install position switch to transaxle case, and tighten it to the specified torque.

33. Install bracket (2) to transaxle case, and tighten mounting bolt to the specified torque.

34. Install selector lever (3), as per the following procedure.

a. Install selector lever to transaxle case.

CAUTION:

Replace selector lever and selector as a set.

b. Install retaining pin to selector lever, using a pin punch.

CAUTION:

Never reuse retaining pin.

35. Install drain plug, as per the following procedure.

a. Install gasket to drain plug.

CAUTION:

Never reuse gasket.

b. Install drain plug to clutch housing, using a socket [Commercial service tool].

c. Tighten drain plug to the specified torque.

36. Install filler plug, as per the following procedure.

a. Install gasket to filler plug, and then install them to transaxle case.


CAUTION:

Never reuse gasket.

b. Tighten filler plug to the specified torque.

CAUTION:

Fill with gear oil before tighten filler plug to the specified torque.



TRANSAXLE ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >


[6MT: RS6F94R]

Inspection

INFOID:000000008273974

INSPECTION AFTER DISASSEMBLY

Check contact surface and sliding surface for excessive wear, uneven wear, bend, and damage. Replace if necessary.



A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

INPUT SHAFT AND GEAR


< UNIT DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F94R]

INPUT SHAFT AND GEAR

Exploded View

INFOID:000000008273975



JPDIC0407GB

- | | | |
|------------------------------|-----------------------------|------------------------------|
| 1. Input shaft front bearing | 2. Input shaft | 3. 3rd input gear |
| 4. Spacer | 5. Snap ring | 6. 3rd baulk ring |
| 7. 3rd-4th coupling sleeve | 8. 3rd-4th synchronizer hub | 9. Insert key |
| 10. 4th baulk ring | 11. 4th input gear | 12. 5th input gear |
| 13. 5th baulk ring | 14. 5th-6th coupling sleeve | 15. 5th-6th synchronizer hub |
| 16. 6th baulk ring | 17. Needle bearing | 18. 6th input gear |
| 19. Input shaft rear bearing | | |
- A. First step B. Final step

: Apply gear oil.

: Replace the parts as a set.

: Always replace after every disassembly.

: N·m (kg·m, ft·lb)

Disassembly

INFOID:000000008273976


CAUTION:

INPUT SHAFT AND GEAR


< UNIT DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F94R]


- Fix input shaft in a vise with back plate, and then remove gears and snap rings.
- For removal of snap ring, set snap ring pliers and flat pliers at both sides of snap ring. While expanding snap ring with snap ring pliers, move snap ring with flat pliers.
- Disassemble gear components putting direction marks on the parts that do not affect any functions.




1. Remove input shaft rear bearing mounting bolt (1), using the drift (A) [SST: KV32300QAM (-)].



2. Remove input shaft rear bearing (1), as per the following procedure.
 - a. Set a puller [Commercial service tool] to input shaft rear bearing.
 - b. Remove input shaft rear bearing, using a drift (A) [Commercial service tool].



3. Remove spacer (1), 6th input gear (2), needle bearing, 6th baulk ring, and 5th-6th synchronizer hub assembly (3).
4. Remove insert keys and 5th-6th coupling sleeve from 5th-6th synchronizer hub.




A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

INPUT SHAFT AND GEAR


< UNIT DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F94R]


5. Remove snap ring (1).
6. Remove spacer, 5th baulk ring, 5th input gear (2), and spacer.




7. Remove snap ring (1).
8. Remove spacer, 4th input gear (2), 4th baulk ring, and 3rd-4th synchronizer hub assembly (3).
9. Remove insert keys and 3rd-4th coupling sleeve from 3rd-4th synchronizer hub.



10. Remove snap ring (1).
11. Remove spacer, 3rd baulk ring, and 3rd input gear (2).



12. Set a puller [Commercial service tool] to input shaft front bearing (1), and then remove input shaft front bearing.



INFOID:000000008273977

Assembly

Note the following procedures, and assemble in the reverse order of disassembly.

CAUTION:


- Replace transaxle assembly when replacing input shaft.

INPUT SHAFT AND GEAR

< UNIT DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F94R]


- For installation of snap ring, set snap ring pliers and flat pliers at both sides of snap ring. While expanding snap ring with snap ring pliers, move snap ring with flat pliers.
- Never reuse snap ring.
- Check that snap ring is securely installed in a groove.
- Replace 3rd-4th coupling sleeve and 3rd-4th synchronizer hub as a set.
- Replace 5th-6th coupling sleeve and 5th-6th synchronizer hub as a set.



- Be careful to install 3rd-4th synchronizer hub according to the specified direction.

A : 3rd input gear side


B : 4th input gear side




- Be careful to install 5th-6th synchronizer hub according to the specified direction.

A : 5th input gear side

B : 6th input gear side



- Install input shaft front bearing (1), using a drift (A) [Commercial service tool].




A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

INPUT SHAFT AND GEAR

< UNIT DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F94R]

- Install input shaft rear bearing (1), using a drift (A) [Commercial service tool] and the drift (B) [SST: ST36720030 (-)].
- Apply gear oil to 3rd baulk ring, 4th baulk ring, 5th baulk ring, and 6th baulk ring.




- Install input shaft rear bearing mounting bolt (1), as per the following procedure.

CAUTION:

Follow the procedures. Otherwise it may cause a transaxle malfunction.

1. Fix the drift (A) [SST: KV32300QAM (-)] in a vise, and then set input shaft assembly.
2. Install input shaft rear bearing mounting bolt, and then tighten it to the specified torque of the first step.
3. Loosen input shaft rear bearing mounting bolt by a half turn.
4. Tighten input shaft rear bearing mounting bolt to the specified torque of the final step.



Inspection


INFOID:000000008273978

INSPECTION AFTER DISASSEMBLY

Input Shaft and Gear

Check the following items and replace if necessary.


- Damage, peeling, bend, uneven wear, and distortion of shaft.
- Excessive wear, damage, and peeling of gear.



Synchronizer Hub and Coupling Sleeve

Check the following items and replace if necessary.

- Breakage, damage, and unusual wear on contact surface of coupling sleeve, synchronizer hub, and insert key.
- Coupling sleeve and synchronizer hub move smoothly.




Baulk Ring

INPUT SHAFT AND GEAR

< UNIT DISASSEMBLY AND ASSEMBLY >


[6MT: RS6F94R]

Check contact surface of baulk ring cam and insert key for excessive wear, uneven wear, bend, and damage. Replace if necessary.



Bearing

Check bearing for damage and unsmooth rotation. Replace if necessary.



A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

MAINSHAFT AND GEAR


< UNIT DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F94R]

MAINSHAFT AND GEAR


Exploded View


INFOID:000000008273979




SFIA3293E

- | | | |
|---------------------------------------|---------------------------------------|---|
| 1. Mainshaft front bearing outer race | 2. Mainshaft front bearing inner race | 3. Mainshaft |
| 4. 1st main gear | 5. 1st inner baulk ring | 6. 1st synchronizer cone |
| 7. 1st outer baulk ring | 8. 1st-2nd coupling sleeve | 9. Insert key |
| 10. 1st-2nd synchronizer hub | 11. 2nd outer baulk ring | 12. 2nd synchronizer cone |
| 13. 2nd inner baulk ring | 14. 2nd main gear | 15. Bushing |
| 16. 3rd main gear | 17. Mainshaft adjusting shim | 18. 4th main gear |
| 19. 5th main gear | 20. 6th main gear | 21. Mainshaft rear bearing inner race |
| 22. Mainshaft rear bearing outer race | 23. Snap ring | 24. Mainshaft rear bearing adjusting shim |

 : Apply gear oil.

 : Replace the parts as a set.

★ : Select with proper thickness.

 : Always replace after every disassembly.

MAINSHAFT AND GEAR

< UNIT DISASSEMBLY AND ASSEMBLY >


[6MT: RS6F94R]

Disassembly


INFOID:000000008273980

CAUTION:


- Fix mainshaft in a vise with back plate, and then remove gears and snap rings.
- For removal of snap ring, set snap ring pliers and flat pliers at both sides of snap ring. While expanding snap ring with snap ring pliers, move snap ring with flat pliers.
- Disassemble gear components putting direction marks on the parts that never affect any functions.




1. Remove snap ring (1).



2. Remove 6th main gear (1) and mainshaft rear bearing inner race (2), as per the following procedure.
 - a. Set a puller [Commercial service tool] to 6th main gear.
 - b. Remove mainshaft rear bearing inner race and 6th main gear, using the drift (A) [SST: ST33052000 (-)].



3. Remove 4th main gear (1) and 5th main gear (2), as per the following procedure.
 - a. Set a puller [Commercial service tool] to 4th main gear.
 - b. Remove 5th main gear and 4th main gear, using the drift (A) [SST: ST33052000 (-)].
4. Remove mainshaft adjusting shim.





A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

MAINSHAFT AND GEAR

< UNIT DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F94R]

5. Remove 1st main gear (1), 1st-2nd synchronizer hub assembly (2), 2nd main gear (3), and 3rd main gear (4), as per the following procedure.
 - a. Set a puller [Commercial service tool] to 1st main gear.
 - b. Remove 3rd main gear, busing, 2nd main gear, 2nd inner baulk ring, 2nd synchronizer cone, 2nd outer baulk ring, 1st-2nd synchronizer hub assembly, 1st outer baulk ring, 1st synchronizer cone, 1st inner baulk ring, and 1st main gear, using the drift (A) [SST: ST33052000 (-)].
 - c. Remove insert keys and 1st-2nd coupling sleeve from 1st-2nd synchronizer hub.
6. Remove mainshaft front bearing inner race (1), as per the following procedure.
 - a. Set a puller [Commercial service tool] to mainshaft front bearing inner race.
 - b. Remove mainshaft front bearing inner race, using the drift (A) [SST: ST33052000 (-)].




Assembly

INFOID:000000008273981

CAUTION:

- Select mainshaft rear bearing adjusting shim, as per the following procedure when replacing mainshaft adjusting shim, 6th main gear, 5th main gear, or 4th main gear.
- Replace mainshaft adjusting shim.
- If new mainshaft adjusting shim is thinner than previous one, offset the thickness difference by selecting thicker mainshaft rear bearing adjusting shim.
- If new mainshaft adjusting shim is thicker than previous one, offset the thickness difference by selecting thinner mainshaft rear bearing adjusting shim.
- Replace 6th main gear, 5th main gear, or 4th main gear.
- Measure the thickness of the main gear used before and the new main gear
- Increase the thickness of the mainshaft rear bearing adjusting shim, if the difference is smaller than 0.025 mm (0.0010 in).
- Replace transaxle assembly when replacing mainshaft.
- For installation of snap ring, set snap ring pliers and flat pliers at both sides of snap ring. While expanding snap ring with snap ring pliers, move snap ring with flat pliers.



MAINSHAFT AND GEAR

< UNIT DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F94R]

1. Install mainshaft front bearing inner race (1), using the drift (A) [SST: ST36720030 (-)].

CAUTION:

Replace mainshaft front bearing outer race and mainshaft front bearing inner race as a set.

2. Apply gear oil to 1st inner baulk ring, 1st synchronizer cone, 1st outer baulk ring, 2nd inner baulk ring, 2nd synchronizer cone, and 2nd outer baulk ring.

CAUTION:

- **Replace 1st inner baulk ring, 1st synchronizer cone, and 1st outer baulk ring as a set.**
- **Replace 2nd inner baulk ring, 2nd synchronizer cone, and 2nd outer baulk ring as a set.**


3. Install insert keys and 1st-2nd coupling sleeve to 1st-2nd synchronizer hub.

CAUTION:

Replace 1st-2nd synchronizer hub and 1st-2nd coupling sleeve as a set.

4. Install 1st main gear (1), 1st inner baulk ring, 1st synchronizer cone, 1st outer baulk ring, 1st-2nd synchronizer hub assembly (2), 2nd inner baulk ring, 2nd synchronizer cone, and 2nd outer baulk ring.


5. Install bushing (3), using the drift (A) [SST: KV32102700 (-)].



A
B
C

TM

6. Install 3rd main gear (1) and 2nd main gear (2), using the drift (A) [SST: KV32102700 (-)].




E
F
G
H

7. Measure dimension "L" as shown in the figure. Select mainshaft adjusting shim (1) according to the following list, and then install it to mainshaft.


- 2 : Mainshaft
- 3 : 3rd main gear

Unit: mm (in)

Dimension "L"	Mainshaft adjusting shim thickness
147.690 – 147.666 (5.8146 – 5.8136)	1.500 (0.0591)
147.665 – 147.641 (5.8136 – 5.8126)	1.525 (0.0600)
147.640 – 147.616 (5.8126 – 5.8116)	1.550 (0.0610)
147.615 – 147.591 (5.8116 – 5.8107)	1.575 (0.0620)
147.590 – 147.566 (5.8106 – 5.8097)	1.600 (0.0630)
147.565 – 147.541 (5.8096 – 5.8087)	1.625 (0.0640)
147.540 – 147.516 (5.8086 – 5.8077)	1.650 (0.0650)
147.515 – 147.491 (5.8077 – 5.8067)	1.675 (0.0659)



I
J
K
L



M
N
O
P


MAINSHAFT AND GEAR

< UNIT DISASSEMBLY AND ASSEMBLY >


[6MT: RS6F94R]

Dimension "L"	Mainshaft adjusting shim thickness
147.490 – 147.466 (5.8067 – 5.8057)	1.700 (0.0669)
147.465 – 147.441 (5.8057 – 5.8048)	1.725 (0.0679)
147.440 – 147.416 (5.8047 – 5.8038)	1.750 (0.0689)
147.415 – 147.391 (5.8037 – 5.8028)	1.775 (0.0699)


8. Install 4th main gear (1), using the drift (A) [SST: KV32102700 (-)].



9. Install 5th main gear (1), using the drift (A) [SST: KV32102700 (-)].



10. Install 6th main gear (1), using the drift (A) [SST: KV32102700 (-)].



11. Install mainshaft rear bearing inner race (1), using the drift (A) [SST: ST30901000 (J-26010-01)].


CAUTION:

Replace mainshaft rear bearing inner race and mainshaft rear bearing outer race as a set.

12. Install snap ring.

CAUTION:

Never reuse snap ring.



Inspection

INFOID:000000008273982

INSPECTION AFTER DISASSEMBLY

Mainshaft and Gear


MAINSHAFT AND GEAR

< UNIT DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F94R]

Check the following items and replace if necessary.

- Damage, peeling, bend, uneven wear, and distortion of shaft.
- Excessive wear, damage, and peeling of gear.




A
B
C

Synchronizer Hub and Coupling Sleeve

Check the following items and replace if necessary.

- Breakage, damage, and unusual wear on contact surface of coupling sleeve, synchronizer hub, and insert key.
- Coupling sleeve and synchronizer hub move smoothly.



TM


E

F

G

Baulk Ring

Check contact surface of baulk ring cam and insert key for excessive wear, uneven wear, bend, and damage. Replace if necessary.



H

I

J


K

Bearing

Check bearing for damage and unsmooth rotation. Replace if necessary.

CAUTION:

- Replace mainshaft front bearing outer race and mainshaft front bearing inner race as a set.
- Replace mainshaft rear bearing inner race and mainshaft rear bearing outer race as a set.



L

M

N

O

P

REVERSE IDLER SHAFT AND GEAR


< UNIT DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F94R]

REVERSE IDLER SHAFT AND GEAR

Exploded View

INFOID:000000008273983



- | | | |
|------------------------|-------------------|-----------------------|
| 1. Reverse output gear | 2. Snap ring | 3. Reverse baulk ring |
| 4. Return spring | 5. Needle bearing | 6. Seal washer |
| 7. Reverse idler shaft | 8. Spacer | 9. Reverse input gear |
| 10. Lock washer | 11. Spring washer | |

■: Replace the parts as a set.


⊗: Always replace after every disassembly.

Ⓜ: N·m (kg-m, ft-lb)

Disassembly

INFOID:000000008273984

1. Remove reverse output gear (1).




REVERSE IDLER SHAFT AND GEAR


< UNIT DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F94R]


2. Remove snap ring (1).




3. Remove reverse baulk ring (1) and return spring (2).



4. Remove snap ring (1), lock washer (2), and reverse input gear (3).



5. Remove needle bearings (1) and washer.



Assembly

INFOID:000000008273985

Note the following procedures, and assemble in the reverse order of disassembly.

CAUTION:

- Never reuse snap ring.
- Check that snap ring is securely installed in a groove.
- Replace reverse output gear, snap ring, reverse baulk ring, return spring, needle bearing, reverse idler shaft, spacer, reverse input gear, and lock washer as a set.

Inspection

INFOID:000000008273986

INSPECTION AFTER DISASSEMBLY

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

REVERSE IDLER SHAFT AND GEAR

< UNIT DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F94R]

Shaft and Gear

Check the following items. Replace reverse output gear, snap ring, reverse baulk ring, return spring, needle bearing, reverse idler shaft, spacer, reverse input gear, and lock washer as a set, if necessary.

- Damage, peeling, bend, uneven wear, and distortion of shaft
- Excessive wear, damage, and peeling of gear

Bearing

Check damage and rotation of bearing. Replace reverse output gear, snap ring, reverse baulk ring, return spring, needle bearing, reverse idler shaft, spacer, reverse input gear, and lock washer as a set, if necessary.

FINAL DRIVE


< UNIT DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F94R]

FINAL DRIVE

Exploded View

INFOID:000000008273987



- | | | |
|---|---|---|
| 1. Shim | 2. Differential side bearing outer race (transaxle case side) | 3. Differential side bearing inner race (transaxle case side) |
| 4. Final gear | 5. Differential case | 6. Differential side bearing inner race (clutch housing side) |
| 7. Differential side bearing outer race (clutch housing side) | | |


■ : Replace the parts as a set.

⊕ : N·m (kg-m, ft-lb)

Disassembly

INFOID:000000008273988

1. Remove differential side bearing inner race (clutch housing side) (1), as per the following procedure.
 - a. Set a puller [Commercial service tool] to differential side bearing inner race (clutch housing side).
 - b. Remove differential side bearing inner race (clutch housing side), using the drift (A) [SST: ST33061000 (J-8107-2)].




FINAL DRIVE


< UNIT DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F94R]

2. Remove final gear mounting bolts, and then remove final gear (1).



3. Remove differential side bearing inner race (transaxle case side) (1), as per the following procedure.
 - a. Set a puller [Commercial service tool] to differential side bearing inner race (transaxle case side).
 - b. Remove differential side bearing inner race (transaxle case side), using a drift (A) [Commercial service tool].



Assembly

INFOID:000000008273989

1. Install final gear, and then tighten final gear mounting bolts to the specified torque.


CAUTION:

Replace final gear and differential case as a set.

2. Install differential side bearing inner race (clutch housing side), using a drift (A) [Commercial service tool].

CAUTION:


Replace differential side bearing inner race (clutch housing side) and differential side bearing outer race (clutch housing side) as a set.



3. Install differential side bearing inner race (transaxle case side), using a drift (A) [Commercial service tool].

CAUTION:

Replace differential side bearing inner race (transaxle case side) and differential side bearing outer race (transaxle case side) as a set.



Inspection

INFOID:000000008273990

INSPECTION AFTER DISASSEMBLY

Gear and Case

Check final gear and differential case. Replace if necessary.


FINAL DRIVE

< UNIT DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F94R]

Bearing

Check bearing for damage and unsmooth rotation. Replace if necessary.



A
B
C

TM

E
F
G
H
I
J
K
L
M
N
O
P

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)


[6MT: RS6F94R]

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

INFOID:000000008273991

Transaxle type		RS6F94R	
Engine type		MR16DDT	
Axle type		2WD	
Number of speed		6	
Synchromesh type		Warner	
Shift pattern			
Gear ratio	1st	3.3636	
	2nd	1.9474	
	3rd	1.3929	
	4th	1.1143	
	5th	0.9143	
	6th	0.7674	
	Reverse	3.2915	
	Final gear	4.2143	
Number of teeth	Input gear	1st	11
		2nd	19
		3rd	28
		4th	35
		5th	35
		6th	43
		Reverse	11
	Main gear	1st	37
		2nd	37
		3rd	39
		4th	39
		5th	32
		6th	33
		Reverse	42
	Reverse idler gear	Input/Output	25/29
Final gear	Final gear/Pinion	59/14	
	Side gear/Pinion mate gear	13/10	
Oil capacity (Reference)		ℓ (US pt, Imp pt)	Approx. 2.0 (4-1/4, 3-1/2)
Remarks	Reverse synchronizer	Installed	
	Triple-cone synchronizer	1st and 2nd	

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000008273992

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:


Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precaution for Procedure without Cowl Top Cover

INFOID:000000008273993

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc to prevent damage to windshield.



Precaution for On Board Diagnosis (OBD) System of CVT and Engine

INFOID:000000008273994

The ECM has an on board diagnostic system. It will light up the malfunction indicator lamp (MIL) to warn the driver of a malfunction causing emission deterioration.

CAUTION:

- Be sure to turn the ignition switch OFF and disconnect the battery cable from the negative terminal before any repair or inspection work. The open/short circuit of related switches, sensors, solenoid valves, etc. will cause the MIL to light up.
- Be sure to connect and lock the connectors securely after work. A loose (unlocked) connector will cause the MIL to light up due to an open circuit. (Be sure the connector is free from water, grease, dirt, bent terminals, etc.)

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

PRECAUTIONS

< PRECAUTION >

[CVT: RE0F10B]

- Be sure to route and secure the harnesses properly after work. Interference of the harness with a bracket, etc. may cause the MI to light up due to a short circuit.
- Be sure to connect rubber tubes properly after work. A misconnected or disconnected rubber tube may cause the MIL to light up due to a malfunction of the EVAP system or fuel injection system, etc.
- Be sure to erase the unnecessary malfunction information (repairs completed) from the TCM and ECM before returning the vehicle to the customer.

Precaution for TCM and Transaxle Assembly or Control Valve Replacement

INFOID:000000008273995

CAUTION:


- To replace TCM, refer to [TM-123, "Description"](#).
- To replace transaxle assembly, refer to [TM-125, "Description"](#).
- To replace control valve, refer to [TM-125, "Description"](#).

Removal and Installation Procedure for CVT Unit Connector

INFOID:000000008273996


REMOVAL

Rotate bayonet ring (1) counterclockwise, pull out CVT unit harness connector (2) upward and remove it.




INSTALLATION

1. Align Δ marking on CVT unit harness connector terminal body with \square marking on bayonet ring, insert CVT unit harness connector, and then rotate bayonet ring clockwise.



2. Rotate bayonet ring clockwise until Δ marking on CVT unit harness connector terminal body is aligned with the slit on bayonet ring as shown in the figure (correctly fitting condition), install CVT unit harness connector to CVT unit harness connector terminal body.




CAUTION:

PRECAUTIONS

< PRECAUTION >

[CVT: RE0F10B]


- Securely align Δ marking on CVT unit harness connector terminal body with bayonet ring slit. Then, be careful not to make a half fit condition as shown in the figure.
- Never mistake the slit of bayonet ring for other dent portion.




General Precautions

INFOID:000000008273997


- Before connecting or disconnecting the TCM harness connector, turn ignition switch OFF and disconnect negative battery cable. Because battery voltage is applied to TCM even if ignition switch is turned OFF.



- When connecting or disconnecting pin connectors into or from TCM, take care not to damage pin terminals (bend or break).
When connecting pin connectors make sure that there are not any bends or breaks on TCM pin terminal.



- Before replacing TCM, perform TCM input/output signal inspection and make sure whether TCM functions properly or not. Refer to [TM-108. "Reference Value"](#).




A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

PRECAUTIONS

[CVT: RE0F10B]

< PRECAUTION >

- After performing each TROUBLE DIAGNOSIS, perform “DTC Confirmation Procedure”.
If the repair is completed the DTC should not be displayed in the “DTC Confirmation Procedure”.
- Always use the specified brand of CVT fluid. Refer to [MA-10, "Fluids and Lubricants"](#).
- Use lint-free paper, not cloth rags, during work.
- After replacing the CVT fluid, dispose of the waste oil using the methods prescribed by law, ordinance, etc.



INFOID:000000008273998

Service Notice or Precaution

OBD-II SELF-DIAGNOSIS

- CVT self-diagnosis is performed by the TCM in combination with the ECM. The results can be read through the blinking pattern of the malfunction indicator lamp (MIL). Refer to the table on [TM-103, "CONSULT Function"](#) for the indicator used to display each self-diagnostic result.
- The self-diagnostic results indicated by the MI are automatically stored in both the ECM and TCM memories. **Always perform the procedure on [TM-101, "Diagnosis Description"](#) to complete the repair and avoid unnecessary blinking of the MIL.**

For details of OBD-II, refer to [EC-62, "Diagnosis Description"](#).

- **Certain systems and components, especially those related to OBD-II, may use the new style slide-locking type harness connector. For description and how to disconnect, refer to [PG-5, "Harness Connector"](#).**

PREPARATION

< PREPARATION >

[CVT: RE0F10B]

PREPARATION

PREPARATION

Special Service Tool

INFOID:000000008273999

The actual shapes of TechMate tools may differ from those of special service tools illustrated here.

Tool number (TechMate No.) Tool name	Description
— (OTC3492) Oil pressure gauge set	Measuring line pressure
1. ST25054000 (—) Adapter 2. ST25055000 (—) Adapter	Measuring line pressure
KV31103600 (J-45674) Joint pipe adapter (With ST25054000)	Measuring line pressure
KV38107900 (—) Protector a: 32 mm (1.26 in) dia.	Installing drive shaft

Commercial Service Tool






INFOID:000000008274000

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

PREPARATION

< PREPARATION >

[CVT: RE0F10B]


Tool number Tool name	Description
Power tool  <p style="text-align: center; font-size: small;">PBIC0190E</p>	Loosening nuts and bolts
31197CA000 Drive plate location guide a: 14 mm (0.55 in) dia.	Installing transaxle assembly
 <p style="text-align: center; font-size: small;">SCIA2013E</p>	
Drift a: 54 mm (2.13 in) dia. b: 50 mm (1.97 in) dia.	<ul style="list-style-type: none"> • Installing differential side oil seal (transaxle case side) • Installing differential side oil seal (converter housing side) (2WD)
 <p style="text-align: center; font-size: small;">NT115</p>	
Drift a: 60 mm (2.36 in) dia.	Installing differential side oil seal (converter housing side) (AWD)
 <p style="text-align: center; font-size: small;">SCIA5338E</p>	
Drift a: 65 mm (2.13 in) dia. b: 60 mm (1.97 in) dia.	Installing converter housing oil seal
 <p style="text-align: center; font-size: small;">NT115</p>	

SYSTEM DESCRIPTION

COMPONENT PARTS
CVT CONTROL SYSTEM

CVT CONTROL SYSTEM : Component Parts Location

INFOID:000000008274001



- | | | |
|---|---|--|
| <p>1. Multi display unit (MDU)*1
Refer to DMS-3, "Component Parts Location".</p> <p>4. IPDM E/R
Refer to PCS-5, "Component Parts Location" (With Intelligent Key system), PCS-38, "Component Parts Location" (Without Intelligent Key system).</p> <p>7. Manual mode indicator
(On the combination meter)</p> <p>10. Secondary speed sensor</p> <p>13. Primary speed sensor</p> | <p>2. ABS actuator and electric unit (control unit)
Refer to BRC-8, "Component Parts Location".</p> <p>5. BCM
Refer to BCS-6, "BODY CONTROL SYSTEM: Component Parts Location" (With Intelligent Key system), BCS-84, "BODY CONTROL SYSTEM: Component Parts Location" (Without Intelligent Key system)</p> <p>8. Shift position indicator
(On the combination meter)</p> <p>11. Control valve*2</p> <p>14. Transmission range switch</p> | <p>3. ECM
Refer to EC-16, "ENGINE CONTROL SYSTEM: Component Parts Location".</p> <p>6. Combination meter</p> <p>9. CVT indicator
(On the combination meter)</p> <p>12. CVT unit connector</p> <p>15. TCM</p> |
|---|---|--|

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[CVT: RE0F10B]

- | | | |
|--------------------------------|------------------------|-----------------------|
| 16. Stop lamp switch | 17. Manual mode switch | |
| A. Transaxle assembly | B. Engine room | C. Brake pedal, upper |
| D. CVT shift selector assembly | | |

*1: With Integrated Control System

*2: Control valve is installed in transaxle assembly.

NOTE:

- The following components are included in control valve assembly (11).
 - CVT fluid temperature sensor
 - Secondary pressure sensor
 - Line pressure solenoid valve
 - Torque converter clutch solenoid valve
 - Lock-up select solenoid valve
 - Step motor
 - ROM assembly
- The following components are included in manual mode switch (17).
 - Mode select switch
 - Select position switch

CVT CONTROL SYSTEM : Component Description

INFOID:000000008274002

Name	Function
TCM	TM-71, "CVT CONTROL SYSTEM : TCM"
Transmission range switch	TM-71, "CVT CONTROL SYSTEM : Transmission Range Switch"
Primary speed sensor	TM-71, "CVT CONTROL SYSTEM : Primary Speed Sensor"
Secondary speed sensor	TM-72, "CVT CONTROL SYSTEM : Secondary Speed Sensor"
CVT fluid temperature sensor	TM-72, "CVT CONTROL SYSTEM : CVT Fluid Temperature Sensor"
Secondary pressure sensor	TM-72, "CVT CONTROL SYSTEM : Secondary Pressure Sensor"
Line pressure solenoid valve	TM-73, "CVT CONTROL SYSTEM : Line Pressure Solenoid Valve"
Secondary pressure solenoid valve	TM-73, "CVT CONTROL SYSTEM : Secondary Pressure Solenoid Valve"
Torque converter clutch solenoid valve	TM-73, "CVT CONTROL SYSTEM : Torque Converter Clutch Solenoid Valve"
Lock-up select solenoid valve	TM-73, "CVT CONTROL SYSTEM : Lock-up Select Solenoid Valve"
Step motor	TM-74, "CVT CONTROL SYSTEM : Step Motor"
Manual mode switch	TM-74, "CVT CONTROL SYSTEM : Manual Mode Switch"
Shift position indicator	TM-74, "CVT CONTROL SYSTEM : Shift Position Indicator"
Manual mode indicator	TM-74, "CVT CONTROL SYSTEM : Manual Mode Indicator"
Accelerator pedal position sensor	EC-22, "Accelerator Pedal Position Sensor"
Stop lamp switch	BRC-12, "Stop Lamp Switch"
ECM	<ul style="list-style-type: none"> • For purposes including improving the feeling when shifting speeds and preventing drops in engine speed, control signals are exchanged between the ECM and TCM, and real-time cooperative control is performed according to the vehicle driving conditions. (Engine and CVT integrated control) <ul style="list-style-type: none"> - Engine and CVT integrated control signal NOTE: General term for the communication (torque-down permission, torque-down request, etc.) exchanged between the ECM and TCM. • The TCM receives the following signal via CAN communications from the ECM for judging the vehicle driving conditions. <ul style="list-style-type: none"> - Engine speed signal - Accelerator pedal position signal - Closed throttle position signal

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[CVT: RE0F10B]

Name	Function
BCM	The TCM receives the following signal via CAN communications from the BCM for judging the vehicle driving conditions. <ul style="list-style-type: none"> • Stop lamp switch signal
ABS actuator and electric unit (control unit)	The TCM receives the following signal via CAN communications from the ABS actuator and electric unit (control unit) for judging the vehicle driving conditions. <ul style="list-style-type: none"> • Vehicle speed signal (ABS) • ABS operation signal
Combination meter	The TCM receives the following signal via CAN communications from the combination meter for judging the driving request from the driver. <ul style="list-style-type: none"> • Manual mode signal • Non-manual mode signal • Manual mode shift up signal • Manual mode shift down signal
IPDM E/R	The TCM receives the following signal via CAN communications from the ABS actuator and electric unit (control unit) for judging the vehicle driving conditions. <ul style="list-style-type: none"> • A/C compressor feedback signal
MDU*	The TCM receives the following signals from MDU via CAN communication to switch driving mode of the Integrated Control System. <ul style="list-style-type: none"> • NORMAL mode signal • ECO mode signal • SPORT mode signal

*: With Integrated Control System

CVT CONTROL SYSTEM : TCM

INFOID:000000008274003

- The vehicle driving status is judged based on the signals from the sensors, switches, and other control units, and the optimal transaxle control is performed.
- For TCM control items, refer to [TM-92. "CONTROL SYSTEM : System Description"](#).

CVT CONTROL SYSTEM : Transmission Range Switch


INFOID:000000008274004

- The transmission range switch is installed to upper part of transaxle case.
- The transmission range switch detects the selector lever position.

CVT CONTROL SYSTEM : Primary Speed Sensor

INFOID:000000008274005

- The primary speed sensor is installed to front part of transaxle assembly.
- The primary speed sensor detects primary pulley speed.
- The primary speed sensor generates the ON-OFF pulse (short waveform) in proportion to the rotating body speed which is "The higher the rotating body speed is, the faster the change cycle is". The TCM judges the rotating speed from the changing cycle of this pulse signal.



JSDIA1824GB

COMPONENT PARTS


< SYSTEM DESCRIPTION >

[CVT: RE0F10B]

CVT CONTROL SYSTEM : Secondary Speed Sensor

INFOID:000000008274006


- The secondary speed sensor is installed to upper part of converter housing.
- The secondary speed sensor detects secondary pulley speed.
- The secondary speed sensor generates the ON-OFF pulse (short waveform) in proportion to the rotating body speed which is "The higher the rotating body speed is, the faster the change cycle is". The TCM judges the rotating speed from the changing cycle of this pulse signal.



CVT CONTROL SYSTEM : CVT Fluid Temperature Sensor

INFOID:000000008274007

- The CVT fluid temperature sensor is installed to control valve.
- The CVT fluid temperature sensor detects CVT fluid temperature in oil pan.
- The fluid temperature sensor uses a thermistor, and changes the signal voltage by converting changes in the CVT fluid temperature to a resistance value. TCM evaluates the CVT fluid temperature from the signal voltage value.



CVT CONTROL SYSTEM : Secondary Pressure Sensor

INFOID:000000008274008


- The secondary pressure sensor is installed to control valve.
- The secondary pressure sensor detects the pressure applied to the secondary pulley.

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[CVT: RE0F10B]

- When pressure is applied to the ceramic device in the secondary pressure sensor, the ceramic device is deformed, resulting in voltage change. TCM evaluates the secondary pressure from its voltage change. Voltage is increased along with pressure increase.



CVT CONTROL SYSTEM : Line Pressure Solenoid Valve

INFOID:000000008274009

- The line pressure solenoid valve is installed to control valve.
- The line pressure solenoid valve controls the pressure regulator valve. For information about the pressure regulator valve, refer to [TM-85. "MECHANICAL SYSTEM : Component Description"](#).
- The line pressure solenoid valve uses the linear solenoid valve [N/H (normal high) type].

NOTE:

- The principle of the linear solenoid valve utilizes the fact that the force pressing on the valve spool installed inside the coil increases nearly in proportion to the current. This allows it to produce a fluid pressure that is proportional to this pressing force.
- The N/H (normal high) produces hydraulic control when the coil is not energized.

CVT CONTROL SYSTEM : Secondary Pressure Solenoid Valve

INFOID:000000008274010

- The secondary pressure solenoid valve is installed to control valve.
- The secondary pressure solenoid valve controls the secondary valve. For information about the secondary valve, refer to [TM-85. "MECHANICAL SYSTEM : Component Description"](#).
- The secondary pressure solenoid valve uses the linear solenoid valve [N/H (normal high) type].

NOTE:

- The principle of the linear solenoid valve utilizes the fact that the force pressing on the valve spool installed inside the coil increases nearly in proportion to the current. This allows it to produce a fluid pressure that is proportional to this pressing force.
- The N/H (normal high) produces hydraulic control when the coil is not energized.

CVT CONTROL SYSTEM : Torque Converter Clutch Solenoid Valve

INFOID:000000008274011

- The torque converter clutch solenoid valve is installed to control valve.
- The torque converter clutch solenoid valve controls the torque converter clutch control valve. For information about the torque converter clutch control valve, refer to [TM-85. "MECHANICAL SYSTEM : Component Description"](#).
- The torque converter clutch solenoid valve utilizes a linear solenoid valve [N/L (normal low) type].

NOTE:

- The principle of the linear solenoid valve utilizes the fact that the force pressing on the valve spool installed inside the coil increases nearly in proportion to the current. This allows it to produce a fluid pressure that is proportional to this pressing force.
- The N/L (normal low) type does not produce hydraulic control when the coil is not energized.

CVT CONTROL SYSTEM : Lock-up Select Solenoid Valve

INFOID:000000008274012

- The lock-up select solenoid valve is installed to control valve.
- The lock-up select solenoid valve controls the select switch valve. For information about the select switch valve, refer to [TM-85. "MECHANICAL SYSTEM : Component Description"](#).
- The lock-up select solenoid valve utilizes an ON-OFF solenoid valve.

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[CVT: RE0F10B]

NOTE:

- The only operations of the valve spool installed inside the coil are pressing or not pressing the ball which seals the hydraulic supply section into the seat. This A/T uses N/L (normal low) type.
- When voltage is not applied to the coil, the force of the pilot pressure presses the ball against the seat, stopping the pilot pressure at that point.
- When voltage is applied to the coil, the valve is pulled in the direction of the coil, disengaging the hydraulic seal which the ball creates. This supplies pilot pressure to the operating locations.

CVT CONTROL SYSTEM : Step Motor

INFOID:000000008274013

The step motor changes the step with turning 4 coils ON/OFF according to the signal from TCM. As a result, the flow of line pressure to primary pulley is changed and pulley ratio is controlled.

CVT CONTROL SYSTEM : Manual Mode Switch

INFOID:000000008274014

- The manual mode switch [mode select switch and position select switch (shift-up/shift-down)] is installed in the CVT shift selector assembly.
- The mode select switch detects the position (the main shift gate side or manual shift gate side) of the selector lever and transmits a manual mode signal or a not manual mode signal to the combination meter. Then, the TCM receives a manual mode signal or non-manual mode signal from the combination meter.
- The position select switch (shift-up) detects that the selector lever is shifted to the shift-up side of the manual shift gate and transmits a manual mode shift up signal to the combination meter. Then, the TCM receives a manual mode shift up signal from the combination meter.
- The position select switch (shift-down) detects that the selector lever is shifted to the shift-down side of the manual shift gate and transmits a manual mode shift down signal to the combination meter. Then, the TCM receives a manual mode shift down signal from the combination meter.

CVT CONTROL SYSTEM : CVT Indicator

INFOID:000000008274015

- CVT indicator is positioned on the combination meter.
- CVT indicator turns on for a certain period of time when the ignition switch turns ON, and then turns OFF.

Condition (status)	CVT indicator
Ignition switch OFF.	OFF
Ignition switch ON.	ON (Approx. 2sec.)

CVT CONTROL SYSTEM : Shift Position Indicator

INFOID:000000008274016


TCM transmits shift position signal to combination meter via CAN communication. The actual shift position is displayed on combination meter according to the signal.

CVT CONTROL SYSTEM : Manual Mode Indicator

INFOID:000000008274017

- Manual mode indicator (A) is positioned on the combination meter.
- The manual mode indicator illuminates when the selector lever is operated to the manual shift gate side. It also displays the gear position (M1↔M6) when the selector lever is operated to the + side or – side. (Operates only during driving.)
- The manual mode indicator turns off when the selector lever is operated to the main shift gate side.

Condition (status)	Manual mode indicator
Selector lever is operated to the manual shift gate side.	Display
Selector lever is operated to the + side or – side.	M1↔M6
Selector lever is operated to the main shift gate side.	Nothing displayed.



JSDIA2386ZZ

SHIFT LOCK SYSTEM


COMPONENT PARTS

< SYSTEM DESCRIPTION >

[CVT: RE0F10B]

SHIFT LOCK SYSTEM : Component Parts Location

INFOID:000000008274018



1. Shift lock release button cover* 2. Shift lock solenoid 3. Park position switch
 4. Stop lamp switch
 A: CVT shift selector assembly B: Brake pedal, upper

*: Shift lock release button becomes operative by removing shift lock cover.

SHIFT LOCK SYSTEM : Component Description

INFOID:000000008274019

Component	Function
Shift lock solenoid	It operates according to the signal from the stop lamp switch and moves the lock lever.
Lock lever	<ul style="list-style-type: none"> Rotates according to shift lock solenoid activation and releases the shift lock. If shift lock solenoid does not activate, lock lever can be rotated when shift lock release button is pressed and shift lock is released.
Detent rod	It links with the selector button and restricts the selector lever movement.
Park position switch	It detects that the selector lever is in "P" position.
Shift lock release button	Forcibly releases the shift lock when pressed.
Stop lamp switch	<ul style="list-style-type: none"> The stop lamp switch turns ON when the brake pedal is depressed. When the stop lamp switch turns ON, the shift lock solenoid is energized.

STRUCTURE AND OPERATION


< SYSTEM DESCRIPTION >

[CVT: RE0F10B]

STRUCTURE AND OPERATION TRANSAXLE

TRANSAXLE : Cross-Sectional View

INFOID:000000008274020



- | | | |
|--------------------------|----------------------|--------------------|
| 1. Converter housing | 2. Driven sprocket | 3. Chain |
| 4. Reverse brake | 5. Oil pump | 6. Forward clutch |
| 7. Planetary carrier | 8. Primary pulley | 9. Sun gear |
| 10. Steel belt | 11. Side cover | 12. Internal gear |
| 13. Parking gear | 14. Secondary pulley | 15. Final gear |
| 16. Differential case | 17. Idler gear | 18. Reduction gear |
| 19. Taper roller bearing | 20. Output gear | 21. Drive sprocket |
| 22. Input shaft | 23. Torque converter | |

TRANSAXLE : Main Component Elements

INFOID:000000008274021

TORQUE CONVERTER (WITH LOCK-UP FUNCTION)


In the same way as a conventional A/T, the torque converter is a system that increases the engine torque and transmits the torque to the transaxle. A symmetrical 3-element, 1-stage, 2-phase type is used here.

OIL PUMP

Utilizes a vane-type oil pump that is driven by the engine through the oil pump drive chain in order to increase efficiency of pump discharge volume in low-speed zone and optimize pump discharge volume in high-speed zone. Discharged oil from oil pump is transmitted to control valve. It is used as the oil of primary and secondary pulley operation, the oil of clutch operation, and the lubricant for each part.

FORWARD/REVERSE SELECTION UNIT


- A planetary gear type of forward/reverse selector mechanism is installed between the torque converter and primary pulley.
- The power from the torque converter is input via the input shaft, operating a wet multi-plate clutch by means of hydraulic pressure to switch between forward and reverse driving.



FINAL DRIVE AND DIFFERENTIAL

The deceleration gears are composed of 2 stages: primary deceleration (output gear, idler gear pair) and secondary deceleration (reduction gear, final gear pair). All of these gears are helical gears.

The lubrication oil is the same as the fluid (Genuine CVT fluid) which lubricates the entire transaxle.



STRUCTURE AND OPERATION


< SYSTEM DESCRIPTION >

[CVT: RE0F10B]

TRANSAXLE : Belt & Pulley

INFOID:000000008274022

STRUCTURE



MECHANISM


It is composed of a pair of pulleys (the groove width is changed freely in the axial direction) and the steel belt (the steel plates are placed continuously and the belt is guided with the multilayer steel rings on both sides). The groove width changes according to wrapping radius of steel belt and pulley from low status to overdrive status continuously with non-step. It is controlled with the oil pressures of primary pulley and secondary pulley.

STEEL BELT

It is composed of multiple steel plates (A) and two steel rings (B) stacked to a several number. The feature of this steel belt transmits power with compression of the steel plate in contrast with transmission of power in pulling with a rubber belt. Friction force is required with the pulley slope to transmit power from the steel plate. The force is generated with the following mechanism:

Oil pressure applies to the secondary pulley to nip the plate. ⇒The plate is pushed and extended outward. ⇒The steel ring shows withstands. ⇒Pulling force is generated on the steel ring. ⇒The plate of the primary pulley is nipped between the pulley. ⇒Friction force is generated between the steel belt and the pulley.

Therefore, responsibilities are divided by the steel plate that transmits the power with compression and the steel ring that maintains necessary friction force. In this way, the



STRUCTURE AND OPERATION

< SYSTEM DESCRIPTION >


[CVT: RE0F10B]

tension of the steel ring is distributed on the entire surface and stress variation is limited, resulting in good durability.

PULLEY

The primary pulley (input shaft side) and the secondary pulley (output shaft side) have the shaft with slope (fixed cone surface), movable sheave (movable cone surface that can move in the axial direction) and oil pressure chamber at the back of the movable sheave.

The movable sheave slides on the shaft to change the groove width of the pulley. Input signals of engine load (accelerator pedal opening), primary pulley speed and secondary pulley speed change the operation pressures of the primary pulley and the secondary pulley, and controls the pulley groove width.



FLUID COOLER & FLUID WARMER SYSTEM

FLUID COOLER & FLUID WARMER SYSTEM : System Description


INFOID:000000008274023

CVT FLUID COOLER SCHEMATIC

STRUCTURE AND OPERATION

< SYSTEM DESCRIPTION >


[CVT: RE0F10B]



COMPONENT DESCRIPTION


CVT Oil Warmer

- The CVT oil warmer (1) is installed on the front part of transaxle assembly.
- When engine is started while engine and CVT are cold, engine coolant temperature rises more quickly than CVT fluid temperature. CVT oil warmer is provided with two circuits for CVT and engine coolant respectively so that warmed engine coolant warms CVT quickly. This helps shorten CVT warming up time, improving fuel economy.
- A cooling effect is obtained when A/T fluid temperature is high.



Heater Thermostat

The heater thermostat (1) is installed on the front part of transaxle assembly.



MECHANICAL SYSTEM


STRUCTURE AND OPERATION

< SYSTEM DESCRIPTION >

[CVT: RE0F10B]

MECHANICAL SYSTEM : System Diagram

INFOID:000000008274024



MECHANICAL SYSTEM : System Description

INFOID:000000008274025

Traction force of engine is transmitted to wheel via torque converter, planetary gear, belt, pulley, differential gear, and others. Also includes a parking mechanism that mechanically fixes secondary pulley when selector lever is shifted to the “P” position.

ACTIVATION STATE ACCORDING TO EACH SHIFTING

×: Operates

Selector lever position	Secondary pressure sensor	Solenoid valve				Step motor
		Line pressure solenoid valve	Secondary pressure solenoid valve	Torque converter solenoid valve	Lock-up select solenoid valve	
P	×	×	×		×	
R	×	×	×		×	×
N	×	×	×		×	×
D (Low)	×	×	×	×		×
D (High)	×	×	×	×		×
D (Lock-up)	×	×	×	×		×

POWER TRANSMISSION


“P” position

- Traction force from input shaft is not transmitted to primary pulley because forward clutch and reverse brake are not engaged and run idle.
- Torque from the wheels is not transmitted to secondary pulley because secondary pulley is mechanically fixed when parking pole that is linked with selector lever is engaged with parking gear that is integrated with secondary pulley.

STRUCTURE AND OPERATION

< SYSTEM DESCRIPTION >

[CVT: RE0F10B]



Planetary gear

Name	Sun gear	Planet carrier	Internal gear
Condition	Stop	Idled	Input
Direction of rotation	—	—	Clockwise revolution


“R” position

- Traction force from input shaft rotates sun gear in opposite direction of input shaft rotation because reverse brake is engaged and planetary gear is fixed.
- Therefore primary pulley rotates in opposite direction of input shaft rotation and traction force output is in opposite direction rotation.

STRUCTURE AND OPERATION

< SYSTEM DESCRIPTION >

[CVT: RE0F10B]



Planetary gear

Name	Sun gear	Planet carrier	Internal gear
Condition	Output	Fixed	Input
Direction of rotation	Counterclockwise revolution	—	Clockwise revolution

“N” position


- Traction force from input shaft is not transmitted to primary pulley because forward clutch and reverse brake are not engaged and run idle.
- Torque from wheel is not transmitted to input shaft because forward clutch and reverse brake are not engaged and planetary carrier runs idle.

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

STRUCTURE AND OPERATION

< SYSTEM DESCRIPTION >

[CVT: RE0F10B]



Planetary gear

Name	Sun gear	Planet carrier	Internal gear
Condition	Stop	Idle	Input
Direction of rotation	—	—	Clockwise revolution


“D” position

- Traction force from input shaft rotates sun gear via forward clutch in the same direction of input shaft because forward clutch is engaged.
- Therefore primary pulley rotates in the same direction of input shaft rotation and traction force output is in the same direction rotation.

STRUCTURE AND OPERATION

< SYSTEM DESCRIPTION >

[CVT: RE0F10B]



Planetary gear

Name	Sun gear	Planet carrier	Internal gear
Condition	Input/output	Idle	Input
Direction of rotation	Clockwise revolution	—	Clockwise revolution

MECHANICAL SYSTEM : Component Description

INFOID:000000008274026

Part name	Function
Torque converter	Increases engine torque and transmits it to the transaxle.
Oil pump	Utilizes a vane-type oil pump that is driven by the engine through the oil pump drive chain in order to increase efficiency of pump discharge volume in low-speed zone and optimize pump discharge volume in high-speed zone. Discharged oil from oil pump is transmitted to control valve. It is used as the oil of primary and secondary pulley operation, the oil of clutch operation, and the lubricant for each part.
Forward clutch	The forward clutch is wet and multiple plate type clutch that consists of clutch drum, piston, drive plate, and driven plate. It is a clutch to move the vehicle forward by activating piston hydraulically, engaging plates, and directly connecting sun gear and input shaft.
Reverse brake	The reverse brake is a wet multiple-plate type brake that consists of transaxle case, piston, drive plate, and driven plate. It is a brake to move the vehicle in reverse by activating piston hydraulically, engaging plates, and fixing planetary gear.
Internal gear	The internal gear is directly connected to forward clutch drum. It is a gear that moves the outer edge of pinion planet of planet carrier. It transmits power to move the vehicle in reverse when the planet carrier is fixed.
Planet carrier	Composed of a carrier, pinion planet, and pinion shaft. This gear fixes and releases the planet carrier in order to switch between forward and reverse driving.
Sun gear	Sun gear is a set part with planet carrier and internal gear. It transmits transmitted force to primary fixed sheave. It rotates in forward or reverse direction according to activation of either forward clutch or reverse brake.
Input shaft	The input shaft is directly connected to forward clutch drum and transmits traction force from torque converter. In shaft center, there are holes for hydraulic distribution to primary pulley and hydraulic distribution for lockup ON/OFF.

STRUCTURE AND OPERATION

< SYSTEM DESCRIPTION >

[CVT: RE0F10B]

Part name	Function
Primary pulley	It is composed of a pair of pulleys (the groove width is changed freely in the axial direction) and the steel belt (the steel plates are placed continuously and the belt is guided with the multilayer steel rings on both sides). The groove width changes according to wrapping radius of steel belt and pulley from low status to overdrive status continuously with non-step. It is controlled with the oil pressures of primary pulley and secondary pulley.
Secondary pulley	
Steel belt	
Manual shaft	When the manual shaft is in the P position, the parking rod that is linked to the manual shaft rotates the parking pole. When the parking pole rotates, it engages with the parking gear, fixing the parking gear. As a result, the secondary pulley that is integrated with the parking gear is fixed.
Parking rod	
Parking pawl	
Parking gear	
Output gear	The deceleration gears are composed of 2 stages: primary deceleration (output gear, idler gear pair) and secondary deceleration (reduction gear, final gear pair). All of these gears are helical gears.
Idler gear	
Reduction gear	
Differential	
Torque converter regulator valve	Adjusts the feed pressure to the torque converter to the optimum pressure corresponding to the driving condition.
Pressure regulator valve	Adjusts the discharge pressure from the oil pump to the optimum pressure (line pressure) corresponding to the driving condition.
Torque converter clutch control valve	Adjusts the torque converter engage and disengage pressures.
Shift control valve	Controls the line pressure that is applied to the primary pulley according to the stroke difference between the step motor and primary pulley.
Secondary valve	Reduces the line pressure and adjusts the secondary pressure.
Clutch regulator valve	Adjusts the clutch operating pressure according to the driving conditions.
Manual valve	Distributes the clutch operation pressure to each circuit according to the selector lever position.
Select control valve	Engages when selected. Adjusts the forward clutch pressure and reverse brake pressure.
Select switch valve	Performs switching control of the torque converter clutch solenoid valve control pressure when lock-up is engaged/disengaged, and when the forward/reverse clutches (forward clutch and reverse brake) are engaged/disengaged.
Step motor	<ul style="list-style-type: none"> • Step motor changes step by turning 4 coils ON or OFF according to signal from TCM. • By changing step, step motor controls outward flow and inward flow of line pressure to primary pulley, determines the primary pulley position, and controls gear ratio.

SYSTEM

[CVT: RE0F10B]


< SYSTEM DESCRIPTION >

SYSTEM

CVT CONTROL SYSTEM

CVT CONTROL SYSTEM : System Description


INFOID:000000008274027



A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

CVT CONTROL SYSTEM : System Diagram

INFOID:000000008274028



CVT CONTROL SYSTEM : Fail-Safe

INFOID:000000009296915

The TCM has an electrical fail-safe mode. In this mode TCM is operator even if there is an error in a main electronic control input/output signal circuit.

DESCRIPTION

When a malfunction is detected in each sensor, switch, solenoid or others, this function provides control to minimize reduction of drivability so that durability of transmission assembly can be acquired.

DTC	Condition	Vehicle behavior
P0703	—	<ul style="list-style-type: none"> Start is slow Acceleration is slow
P0705	—	<ul style="list-style-type: none"> Position indicator on combination meter is not displayed Selector shock is large Start is slow Acceleration at high load state is slow Manual mode is not activated Lock-up is not performed
P0710	Engine coolant temperature when engine starts is 10°C (50°F) or more	Start is slow
	Engine coolant temperature when engine starts is 10°C (50°F) or less	<ul style="list-style-type: none"> Start is slow Acceleration is slow Vehicle speed is not increased
	Engine coolant temperature when engine starts is -35°C (-31°F) or less	Vehicle speed is not increased

SYSTEM

< SYSTEM DESCRIPTION >

[CVT: RE0F10B]

DTC	Condition	Vehicle behavior	
P0715	—	<ul style="list-style-type: none"> • Acceleration is slow • Re-start is slow after vehicle is stop by strong deceleration • Manual mode is not activated • Lock-up is not performed 	A
P0720	—	<ul style="list-style-type: none"> • Start is slow • Acceleration is slow • Re-start is slow after vehicle is stop by strong deceleration • Manual mode is not activated • Lock-up is not performed 	B C
P0725	—	Lock-up is not performed	TM
P0740	—	<ul style="list-style-type: none"> • Selector shock is large • Lock-up is not performed 	E
P0744	—	Lock-up is not performed	
P0746	A malfunction is detected	<ul style="list-style-type: none"> • Start is slow • Acceleration is slow • Lock-up is not performed 	F
	Function is excessively reduced after a malfunction is detected	<ul style="list-style-type: none"> • Start is difficult • Drive is difficult • Lock-up is not performed 	G
P0778	—	Vehicle speed is not increased	
P0826	—	Manual mode is not activated	H
P0840	—	<ul style="list-style-type: none"> • Start is slow • Acceleration is slow 	
P0841	—	<ul style="list-style-type: none"> • Start is slow • Acceleration is slow 	I
P0845	—	<ul style="list-style-type: none"> • Start is slow • Acceleration is slow 	J
P0868	—	<ul style="list-style-type: none"> • Start is slow • Acceleration is slow 	
P1701	—	<ul style="list-style-type: none"> • Start is slow • Acceleration is slow 	K
P1705	—	<ul style="list-style-type: none"> • Acceleration is slow • Lock-up is not performed 	L
P1709	—	<ul style="list-style-type: none"> • Start is slow • Acceleration is slow • Shift position indicator (P, N) is not displayed, or is displayed with delay. 	M
P1722	—	Lock-up is not activated in coast state	
P1723	A malfunction is detected in primary pulley speed sensor side	<ul style="list-style-type: none"> • Acceleration is slow • Re-start is slow after vehicle is stop by strong deceleration • Manual mode is not activated • Lock-up is not performed 	N
	A malfunction is detected in secondary pulley speed sensor	<ul style="list-style-type: none"> • Start is slow • Acceleration is slow • Re-start is slow after vehicle is stop by strong deceleration • Manual mode is not activated • Lock-up is not performed 	O P
P1726	—	Acceleration is slow	
P1740	—	<ul style="list-style-type: none"> • Selector shock is large • Lock-up is not performed 	

SYSTEM

< SYSTEM DESCRIPTION >


[CVT: RE0F10B]

DTC	Condition	Vehicle behavior
P1777	A malfunction is detected in low side (when vehicle is stopped)	<ul style="list-style-type: none"> • Vehicle speed is not increased • Lock-up is not performed
	A malfunction is detected in high side (during driving)	<ul style="list-style-type: none"> • Start is slow • Acceleration is slow • Lock-up is not performed
U0100	—	<ul style="list-style-type: none"> • Start is slow • Acceleration is slow • Vehicle speed is not increased
U1000	—	<ul style="list-style-type: none"> • Start is slow • Acceleration is slow • Vehicle speed is not increased
U1010	—	<ul style="list-style-type: none"> • Start is slow • Acceleration is slow • Vehicle speed is not increased

OIL PRESSURE CONTROL SYSTEM

OIL PRESSURE CONTROL SYSTEM : System Diagram

INFOID:000000008274030



JSDIA2384GB

OIL PRESSURE CONTROL SYSTEM : System Description

INFOID:000000008274031

The hydraulic control mechanism consists of the oil pump directly driven by the engine, the hydraulic control valve that controls line pressure and transmission, and the input signal line.

LINE PRESSURE AND SECONDARY PRESSURE CONTROL


- When an input torque signal equivalent to the engine driving force is transmitted from the ECM to the TCM, the TCM controls the line pressure solenoid valve and secondary pressure solenoid valve.

SYSTEM

< SYSTEM DESCRIPTION >

[CVT: RE0F10B]

- Highly accurate line pressure control and secondary pressure control reduces friction for improvement of fuel economy.



Normal Oil Pressure Control

Appropriate line pressure and secondary pressure suitable for driving condition are determined based on the accelerator pedal position, engine speed, primary pulley (input) speed, secondary pulley (output) speed, input torque, stop lamp switch signal, transmission range switch signal, lock-up signal, power voltage, target shift ratio, oil temperature and oil pressure.


Secondary Pressure Feedback Control

In normal oil pressure control and oil pressure control in shifting, highly accurate secondary pressure is determined by detecting the secondary pressure using an oil pressure sensor and by feedback control.

CONTROL SYSTEM

CONTROL SYSTEM : System Diagram

INFOID:000000008274032



CONTROL SYSTEM : System Description

INFOID:000000008274033

The TCM senses vehicle operating conditions through various sensors or signals. It always controls the optimum shift position and reduces shifting and lock-up shocks.

TCM FUNCTION

The function of the TCM is to:

- Receive input signals transmitted from various switches and sensors.
- Determine required line pressure, shifting point, lock-up operation, etc.
- Transmit required output signals to the respective solenoids.

Sensor (or signal)	⇒	TCM function	⇒	Actuator
Transmission range switch CVT fluid temperature sensor Secondary pressure sensor Primary speed sensor Secondary speed sensor Engine speed signal Accelerator pedal position signal Closed throttle position signal Stop lamp switch signal Manual mode switch signal Vehicle speed signal		Shift control Line pressure control Primary oil pressure control Secondary oil pressure control Lock-up control Engine brake control Vehicle speed control Integrated Control System Fail-safe function Self-diagnosis function Communication function with CONSULT CAN communication control		Line pressure solenoid valve Secondary pressure solenoid valve Torque converter clutch solenoid valve Lock-up select solenoid valve Step motor Shift position indicator Manual mode indicator

TCM INPUT/OUTPUT SIGNAL

SYSTEM

< SYSTEM DESCRIPTION >

[CVT: RE0F10B]

Control item		Line pressure control	Select control	Shift control	Lock-up control	CAN communication control	Fail-safe function*2
Input	Transmission range switch	×	×	×	×	×	×
	CVT fluid temperature sensor	×	×	×	×		×
	Secondary pressure sensor	×		×			×
	Primary speed sensor	×		×	×	×	×
	Secondary speed sensor	×	×	×	×	×	×
	Engine speed signal*1	×	×		×	×	×
	Accelerator pedal position signal*1	×	×	×	×	×	×
	Closed throttle position signal*1	×		×	×	×	
	Stop lamp switch signal*1	×		×	×	×	
	Manual mode signal*1	×		×	×	×	×
	TCM power supply	×	×	×	×	×	×
Output	Line pressure solenoid	×	×	×			×
	Secondary pressure solenoid	×		×			×
	Torque converter clutch solenoid		×		×		×
	Lock-up select solenoid valve		×		×		×
	Step motor			×			×

*1: Input by CAN communications.

*2: If these input/output signals show errors, TCM activates the fail-safe function.

CONTROL SYSTEM : CAN Communication

INFOID:000000008274034

- CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent malfunction detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H and CAN-L) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.
- For a list of CAN communication signals, refer to [LAN-28, "CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart"](#).

CONTROL SYSTEM : Engine and CVT Integrated Control (CAN Communication Control)

INFOID:000000008274035

- For purposes including improving the feeling when shifting speeds and preventing drops in engine speed, engine output control signals are exchanged between the ECM and TCM, and real-time cooperative control is performed according to the vehicle driving conditions.
- TCM sends the sudden deceleration signal, lock-up engaged signal, torque-down request signal, and other information to ECM, and also receives the torque-down permission/prohibit signals, lock-up permission/prohibit signals, accelerator position, and other information from ECM.

CONTROL SYSTEM : Control between CVT and Combination Meter (CAN Communication Control)

INFOID:000000008274036

TCM sends the manual mode display request, shift position indicator signal, and other information to the combination meter, and also receives the manual mode signal and other information from the combination meter.

CONTROL SYSTEM : Control between CVT and BCM (CAN Communication Control)

INFOID:000000008274037

TCM receives signals from the stop lamp switch via BCM.

LOCK-UP AND SELECT CONTROL SYSTEM


SYSTEM

< SYSTEM DESCRIPTION >

[CVT: RE0F10B]

LOCK-UP AND SELECT CONTROL SYSTEM : System Diagram


INFOID:000000008274038



LOCK-UP AND SELECT CONTROL SYSTEM : System Description

INFOID:000000008274039

- The torque converter clutch piston in the torque converter is engaged to eliminate torque converter slip to increase power transmission efficiency.
- The torque converter clutch control valve operation is controlled by the torque converter clutch solenoid valve, which is controlled by a signal from TCM. The torque converter clutch engages or releases the torque converter clutch piston.
- When shifting between "N" ("P") ⇒ "D" ("R"), torque converter clutch solenoid valve controls engagement power of forward clutch and reverse brake.
- The lock-up applied gear range was expanded by locking up the torque converter at a lower vehicle speed than conventional A/T models.
- If the CVT fluid temperature is low or the vehicle is in fail-safe mode due to malfunction, lock-up control is prohibited.



TORQUE CONVERTER CLUTCH AND SELECT CONTROL VALVE CONTROL

Lock-up Released

In the lock-up released state, the torque converter clutch control valve is set into the unlocked state by the torque converter clutch solenoid valve and the lock-up apply pressure is drained. In this way, the torque converter clutch piston is not coupled.

Lock-up Applied

In the lock-up applied state, the torque converter clutch control valve is set into the locked state by the torque converter clutch solenoid valve and lock-up apply pressure is generated. In this way, the torque converter clutch piston is pressed and coupled.


Select Control

When shifting between "N" ("P") ⇒ "D" ("R"), optimize the operating pressure on the basis of the throttle position, the engine speed, and the secondary pulley (output) revolution speed to lessen the shift shock.

SHIFT CONTROL SYSTEM

SHIFT CONTROL SYSTEM : System Diagram

INFOID:000000008274040




NOTE:

The gear ratio is set for each position separately.

SHIFT CONTROL SYSTEM : System Description

INFOID:000000008274041


- To select the gear ratio that can give the driving force to meet driver's intent or vehicle situation, the vehicle driving condition such as vehicle speed or accelerator pedal position is detected and the most appropriate gear ratio is selected and the shifting method before reaching the speed is determined. The information is output to the primary pressure solenoid valve to control the line pressure input/output to the primary pulley, to determine the primary pulley (movable pulley) position and to control the gear position.



- The gear ratio is set for each position separately.

“D” POSITION

Gear shifting is performed in all shifting ranges from the lowest to the highest gear ratio.



“M” POSITION


When the selector lever is put in the manual shift gate side, the fixed changing gear line is set. By moving the selector lever to + side or - side, the manual mode switch is changed over, and shift change like M/T becomes possible following the changing gear set line step by step.

SYSTEM


< SYSTEM DESCRIPTION >

[CVT: RE0F10B]

- Except for JUKE NISMO



- For JUKE NISMO



Manual Mode Information

The TCM transmits the manual mode shift refusal signal to the combination meter if the TCM refuses the transaxle from the driving status of vehicle when the selector lever shifts to “UP (+ side)” or “DOWN (– side)” side. The combination meter blinks shift position indicator on the combination meter and sounds the buzzer to indicate the driver that the shifting is not performed when receiving this signal. However, the TCM does not transmit the manual mode shift refusal signal in the conditions as per the following.

- When the selector lever shifts to “DOWN (– side)” side while driving in M1.
- When the selector lever shifts to “UP (+ side)” side while driving in M6 (M7*).

*: For JUKE NISMO

BLIPPING CONTROL

Using engine torque, the blipping control enables a faster and more responsive gear shifting by compensating inertia torque generated from the rotational change during gear shifting in real time.

Operation

- The blipping control is activated when the driver shifts up/down the transaxle in manual mode or when the transaxle is shifted up/down in “D” position SPORT mode.

NOTE:

The blipping control is not activated when the vehicle is in the following conditions:


- When CAN communication is abnormal.
- During the retard inhibit signal transmission from ECM within the engine-CVT integrated control.
- Engine coolant temperature is less than 20°C (68°F).
- CVT fluid temperature is more than 120°C (248°F).
- Vehicle speed is less than 20 km/h (12 MPH).
- When ABS, TCS or VDC is active.
- During wheel spin.
- ECM selects blipping control or normal shift control according to the gear position, the selector lever position, etc.
- The blipping control is activated when ECM judges it controllable after receiving a control permit signal from TCM.

SYSTEM

< SYSTEM DESCRIPTION >

[CVT: RE0F10B]

- ECM controls engine torque, based on generated inertia torque.




HILL CLIMBING AND DESCENDING CONTROL

If a downhill is detected with the accelerator pedal is released, the system performs downshift to increase the engine brake force so that vehicle may not be accelerated more than necessary. If a climbing hill is detected, the system improves the acceleration performance in re-acceleration by limiting the gear shift range on the high side.

NOTE:

For engine brake control on a downhill, the control can be stopped with CONSULT.




CONTROL IN ACCELERATION

From change of the vehicle speed or accelerator pedal position, the acceleration request level of the driver or driving scene is evaluated. In start or acceleration during driving, the gear shift characteristics with linearity of revolution increase and vehicle speed increase are gained to improve the acceleration feel.

INTEGRATED CONTROL SYSTEM

INTEGRATED CONTROL SYSTEM : System Diagram

INFOID:000000008274042



INTEGRATED CONTROL SYSTEM : System Description

INFOID:000000008274043

- TCM receives the NORMAL mode signal, ECO mode signal or SPORT mode signal from the multi display unit through CAN communication.
- TCM sends the recognized control mode to ECM through CAN communication (drive mode select signal).
- With operation on the multi display unit, the mode is changed on the display, but the mode is actually not changed due to CAN communication malfunction.
- When the selector lever is in any position other than D position, the gear shift line is not changed according to changes in the control mode.

CONTROL DETAILS OF EACH MODE

Control mode	Control
NORMAL mode	Driving mode that automatically selects the shift schedule considering the balance of fuel economy and driving performance based on the driving condition and driving trend.
SPORT mode	Keeps high engine speed and provides direct feel and acceleration performance suitable for driving on winding road. This driving mode also provides a rhythmical feel obtained by A/T like shifting, and produces sporty driving.
ECO mode	Driving mode that selects the shift schedule with priority on fuel economy which gives low engine revolution.

FAIL-SAFE

If CAN communication malfunction occurs between TCM and the multi display unit, the mode when the malfunction occurs is maintained for approximately 30 seconds and the mode is changed to NORMAL mode when the accelerator pedal is released.

SHIFT LOCK SYSTEM

SHIFT LOCK SYSTEM : System Description

INFOID:000000008274044


- The shift lock is the mechanism provided to prevent quick start of a vehicle by incorrect operation of a drive when the selector lever is in P position.
- Selector lever can be shifted from the P position to another position when the following conditions are satisfied.
 - Ignition switch is ON.
 - Stop lamp switch ON (brake pedal is depressed)
 - Press the selector button.

SHIFT LOCK OPERATION AT P POSITION

When brake pedal is not depressed (no selector operation allowed)


When the brake pedal is not depressed with the ignition switch ON, the shift lock solenoid (A) is OFF (not energized) and the solenoid rod (B) is extended with spring.

The connecting lock lever (C) is located at the position shown in the figure when the solenoid rod is extended. It prevents the movement of the detent rod (D). The selector lever cannot be shifted from the P position for this reason.



When brake pedal is depressed (selector lever operation allowed)

The shift lock solenoid (A) is turned ON (energized) when the brake pedal is depressed with the ignition switch ON. The solenoid rod (B) is compressed with the electromagnetic force. The connecting lock lever (C) rotates when the solenoid rod is compressed. Therefore, the detent rod (D) can be moved. The selector lever can be shifted to other positions for this reason.



P POSITION HOLD MECHANISM (IGNITION SWITCH LOCK)


SYSTEM

< SYSTEM DESCRIPTION >

[CVT: RE0F10B]

The shift lock solenoid (A) is not energized when the ignition switch is in any position other than ON. The shift mechanism is locked and P position is held. The operation cannot be performed from P position if the brake pedal is depressed with the ignition switch ON when the operation system of shift lock solenoid is malfunctioning. However, the lock lever (B) is forcibly rotated and the shift lock is released when the shift lock release button (C) is pressed from above. The selector operation from P position can be performed.

D : Detent rod



CAUTION:

Use the shift lock release button only when the selector lever cannot be operated even if the brake pedal is depressed with the ignition switch ON.

KEY LOCK SYSTEM

KEY LOCK SYSTEM : System Description


INFOID:000000008274045

KEY LOCK MECHANISM

The key is not set to LOCK when the selector lever is not selected to P position. This prevents the key from being removed from the key cylinder.


Key lock status

The slider (B) in the key cylinder (A) is moved to the left side of the figure when the selector lever is in any position other than P position. The rotator (D) that rotates together with the key (C) cannot be rotated for this reason. The key cannot be removed from the key cylinder because it cannot be turned to LOCK (E).



Key unlock status

The slider (B) in the key cylinder (A) is moved to the right side of the figure when the selector lever is in P position and the finger is removed from the selector button. The rotator (C) can be rotated for this reason. The key (D) can be removed from the key cylinder because it can be turned to LOCK (E).



ON BOARD DIAGNOSTIC (OBD) SYSTEM

Diagnosis Description

INFOID:000000008274046

DESCRIPTION

The CVT system has two self-diagnostic systems.

The first is the emission-related on board diagnostic system (OBD-II) performed by the TCM in combination with the ECM. The malfunction is indicated by the MIL (malfunction indicator lamp) and is stored as a DTC in the ECM memory, and the TCM memory.

The second is the TCM original self-diagnosis performed by the TCM. The malfunction is stored in the TCM memory. The detected items are overlapped with OBD-II self-diagnostic items. For detail, refer to [TM-103](#), "[CONSULT Function](#)".

OBD-II FUNCTION

The ECM provides emission-related on board diagnostic (OBD-II) functions for the CVT system. One function is to receive a signal from the TCM used with OBD-related parts of the CVT system. The signal is sent to the ECM when a malfunction occurs in the corresponding OBD-related part. The other function is to indicate a diagnostic result by means of the MIL (malfunction indicator lamp) on the instrument panel. Sensors, switches and solenoid valves are used as sensing elements.

The MIL automatically illuminates in "One or Two Trip Detection Logic" when a malfunction is sensed in relation to CVT system parts.

ONE OR TWO TRIP DETECTION LOGIC OF OBD-II

One Trip Detection Logic

If a malfunction is sensed during the first test drive, the MIL will illuminate and the malfunction will be stored in the ECM memory as a DTC. The TCM is not provided with such a memory function.

Two Trip Detection Logic

When a malfunction is sensed during the first test drive, it is stored in the ECM memory as a 1st trip DTC (diagnostic trouble code) or 1st trip freeze frame data. At this point, the MIL will not illuminate. — 1st trip



If the same malfunction as that experienced during the first test drive is sensed during the second test drive, the MIL will illuminate. — 2nd trip

The "trip" in the "One or Two Trip Detection Logic" means a driving mode in which self-diagnosis is performed during vehicle operation.

OBD-II DIAGNOSTIC TROUBLE CODE (DTC)

How to Read DTC and 1st Trip DTC

DTC and 1st trip DTC can be read by the following methods.

( with CONSULT or  GST) CONSULT or GST (Generic Scan Tool) Examples: P0705, P0720 etc.

These DTC are prescribed by SAE J2012.

(CONSULT also displays the malfunctioning component or system.)

- **1st trip DTC No. is the same as DTC No.**
- **Output of the diagnostic trouble code indicates that the indicated circuit has a malfunction. However, in case of the Mode II and GST, they do not indicate whether the malfunction is still occurring or occurred in the past and returned to normal.**

CONSULT can identify them as shown below, therefore, CONSULT (if available) is recommended.

- DTC or 1st trip DTC of a malfunction is displayed in SELF-DIAGNOSTIC RESULTS mode for "ENGINE" with CONSULT. Time data indicates how many times the vehicle was driven after the last detection of a DTC.
- If the DTC is being detected currently, the time data will be "0".
- If a 1st trip DTC is stored in the ECM, the time data will be "1t".

Freeze Frame Data and 1st Trip Freeze Frame Data

- The ECM has a memory function, which stores the driving condition such as fuel system status, calculated load value, engine coolant temperature, short term fuel trim, long term fuel trim, engine speed and vehicle speed at the moment the ECM detects a malfunction.

Data which are stored in the ECM memory, along with the 1st trip DTC, are called 1st trip freeze frame data, and the data, stored together with the DTC data, are called freeze frame data and displayed on CONSULT or GST. The 1st trip freeze frame data can only be displayed on the CONSULT screen, not on the GST. For details, refer to [EC-73](#), "[CONSULT Function](#)".

Only one set of freeze frame data (either 1st trip freeze frame data or freeze frame data) can be stored in the ECM. 1st trip freeze frame data is stored in the ECM memory along with the 1st trip DTC. There is no priority

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[CVT: RE0F10B]

< SYSTEM DESCRIPTION >

for 1st trip freeze frame data, and it is updated each time a different 1st trip DTC is detected. However, once freeze frame data (2nd trip detection/MIL on) is stored in the ECM memory, 1st trip freeze frame data is no longer stored. Remember, only one set of freeze frame data can be stored in the ECM. The ECM has the following priorities to update the data.

Priority	Items	
1	Freeze frame data	Misfire — DTC: P0300 - P0304 Fuel Injection System Function — DTC: P0171, P0172
2		Except the above items (Includes CVT related items)
3	1st trip freeze frame data	

Both 1st trip freeze frame data and freeze frame data (along with the DTC) are cleared when the ECM memory is erased.

How to Erase DTC

- The diagnostic trouble code can be erased by CONSULT, GST or ECM DIAGNOSTIC TEST MODE as described following.
 - **If the battery cable is disconnected, the diagnostic trouble code will be lost within 24 hours.**
 - **When you erase the DTC, using CONSULT or GST is easier and quicker than switching the mode selector on the ECM.**
- The following emission-related diagnostic information is cleared from the ECM memory when erasing DTC related to OBD-II. For details, refer to [EC-102, "DTC Index"](#).
 - **Diagnostic trouble codes (DTC)**
 - **1st trip diagnostic trouble codes (1st trip DTC)**
 - **Freeze frame data**
 - **1st trip freeze frame data**
 - **System readiness test (SRT) codes**
 - **Test values**

📖 How to Erase DTC (With CONSULT)

The emission related diagnostic information in the TCM and ECM can be erased by selecting "ALL Erase" in the "Description" of "FINAL CHECK" mode with CONSULT.

🔧 How to Erase DTC (With GST)


1. If the ignition switch stays ON after repair work, be sure to turn ignition switch OFF once. Wait at least 10 seconds and then turn it ON (engine stopped) again.
2. Select Mode 4 with GST (Generic Scan Tool).

MALFUNCTION INDICATOR LAMP (MIL)

Description

The MIL is located on the instrument panel.

1. The MIL will light up when the ignition switch is turned ON without the engine running. This is a bulb check.
 - If the MIL does not light up, refer to [EC-527, "Component Function Check"](#).
2. When the engine is started, the MIL should go off. If the MIL remains on, the on board diagnostic system has detected an engine system malfunction.



DIAGNOSIS SYSTEM (TCM)

[CVT: RE0F10B]

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (TCM)

CONSULT Function

INFOID:000000008274047

APPLICATION ITEMS

Conditions	Function
Work Support	This mode enables a technician to adjust some devices faster and more accurately.
Self Diagnostic Results	Retrieve DTC from ECU and display diagnostic items.
Data Monitor	Monitor the input/output signal of the control unit in real time.
ECU Identification	Display the ECU identification number (part number etc.) of the selected system.
CALIB DATA	The calibration data status of TCM can be checked.

SELF DIAGNOSTIC RESULTS

Refer to [TM-116, "DTC Index"](#).

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

X: Application ▼: Optional selection

Monitored item (Unit)	(Unit)	Monitor item selection		Remarks
		MAIN SIGNALS	ECU INPUT SIGNALS	
VSP SENSOR	(km/h or mph)	▼	X	Displays the vehicle speed calculated from the CVT output shaft speed.
ESTM VSP SIG	(km/h or mph)	▼	X	Displays the vehicle speed signal (ABS) received through CAN communication.
PRI SPEED SEN	(rpm)	▼	X	Displays the primary pulley speed calculated from the pulse signal of the primary speed sensor.
ENG SPEED SIG	(rpm)	▼	X	Displays the engine speed received through CAN communication.
SEC HYDR SEN	(V)	▼	X	Displays the signal voltage of the secondary pressure sensor.
PRI HYDR SEN	(V)	▼	X	<ul style="list-style-type: none"> Displays the signal voltage of the primary pressure sensor. It is displayed although not equipped.
ATF TEMP SEN	(V)	▼	X	Displays the signal voltage of the CVT fluid temperature sensor.
VIGN SEN	(V)	▼	X	Displays the battery voltage applied to TCM.
VEHICLE SPEED	(km/h or mph)	X	▼	Vehicle speed recognized by the TCM.
PRI SPEED	(rpm)	X	▼	Displays the primary pulley speed recognized by TCM.
SEC SPEED	(rpm)	▼	▼	Displays the secondary pulley speed recognized by TCM.
ENG SPEED	(rpm)	X	▼	Displays the engine speed recognized by TCM.
SLIP REV	(rpm)	X	▼	Displays the speed difference between the input shaft speed of CVT and the engine speed.
GEAR RATIO		X	▼	Displays the pulley gear ratio calculated from primary pulley speed/secondary pulley speed.
G SPEED	(G)	▼	▼	Displays the acceleration and deceleration speed of the vehicle calculated from vehicle speed change.

DIAGNOSIS SYSTEM (TCM)

< SYSTEM DESCRIPTION >

[CVT: RE0F10B]

Monitored item (Unit)	(Unit)	Monitor item selection		Remarks
		MAIN SIGNALS	ECU INPUT SIGNALS	
ACC PEDAL OPEN	(0.0/8)	X	X	Displays the estimated throttle position received through CAN communication.
SEC PRESS	(MPa)	X	▼	Displays the secondary pressure calculated from the signal voltage of the secondary pressure sensor.
PRI PRESS	(MPa)	X	▼	<ul style="list-style-type: none"> • Displays the primary pressure calculated from the signal voltage of the primary pressure sensor. • It is displayed although not equipped.
ATFTEMP COUNT		X	▼	Means CVT fluid temperature. Actual oil temperature (° numeric value is converted. Refer to TM-107
DSR REV	(rpm)	▼	▼	Displays the target primary pulley speed calculated from processing of gear shift control.
DGEAR RATIO		▼	▼	Displays the target gear ratio.
DSTM STEP	(step)	▼	▼	Displays the target number of steps of the step motor, calculated from processing of gear shift control.
STM STEP	(step)	X	▼	Displays the actual number of steps of the step motor, calculated from processing of gear shift control.
LU PRS	(MPa)	▼	▼	Displays the target oil pressure of the torque converter clutch solenoid valve calculated from oil pressure processing of gear shift control.
LINE PRS	(MPa)	▼	▼	Displays the target oil pressure of the line pressure solenoid valve calculated from oil pressure processing of gear shift control.
TGT SEC PRESS	(MPa)	▼	▼	Displays the target oil pressure of the secondary pressure solenoid valve calculated from oil pressure processing of gear shift control.
ISOLT1	(A)	X	▼	Displays the command current from TCM to the torque converter clutch solenoid valve.
ISOLT2	(A)	X	▼	Displays the command current from TCM to the line pressure solenoid valve.
ISOLT3	(A)	X	▼	Display the command current from TCM to the secondary pressure solenoid valve.
SOLMON1	(A)	X	X	Monitors the command current from TCM to the torque converter clutch solenoid valve and displays the monitored value.
SOLMON2	(A)	X	X	Monitors the command current from TCM to the line pressure solenoid valve and displays the monitored value.
SOLMON3	(A)	X	X	Monitors the command current from TCM to the secondary pressure solenoid valve and displays the monitored value.
BRAKE SW	(On/Off)	X	X	Displays the reception status of the stop lamp switch signal received through CAN communication.
FULL SW	(On/Off)	X	X	<ul style="list-style-type: none"> • Displays the reception status of the wide open throttle position signal received through CAN communication. • It is displayed although not equipped.
IDLE SW	(On/Off)	X	X	Displays the reception status of the closed throttle position signal received through CAN communication.
SPORT MODE SW	(On/Off)	X	X	<ul style="list-style-type: none"> • Displays the reception status of the sport mode switch signal received through CAN communication. • It is displayed although not equipped.

DIAGNOSIS SYSTEM (TCM)

< SYSTEM DESCRIPTION >

[CVT: RE0F10B]

Monitored item (Unit)	(Unit)	Monitor item selection		Remarks
		MAIN SIGNALS	ECU INPUT SIGNALS	
STRDWSW	(On/Off)	▼	X	<ul style="list-style-type: none"> Displays the operation status of the paddle shifter (down switch). It is displayed although not equipped.
STRUPSW	(On/Off)	▼	X	<ul style="list-style-type: none"> Displays the operation status of the paddle shifter (up switch). It is displayed although not equipped.
DOWNLVR	(On/Off)	▼	X	Displays the operation status of the selector lever (down switch).
UPLVR	(On/Off)	▼	X	Displays the operation status of the selector lever (up switch).
NONMMODE	(On/Off)	▼	X	Displays if the selector lever position is not at the manual shift gate.
MMODE	(On/Off)	▼	X	Displays if the selector lever position is at the manual shift gate.
INDLRNG	(On/Off)	▼	▼	<ul style="list-style-type: none"> Displays the transmission status of the shift position (L position) signal transmitted through CAN communication. It is displayed although not equipped.
INDDRNG	(On/Off)	▼	▼	Displays the transmission status of the shift position (D position) signal transmitted through CAN communication.
INDNRNG	(On/Off)	▼	▼	Displays the transmission status of the shift position (N position) signal transmitted through CAN communication.
INDRRNG	(On/Off)	▼	▼	Displays the transmission status of the shift position (R position) signal transmitted through CAN communication.
INDPRNG	(On/Off)	▼	▼	Displays the transmission status of the shift position (P position) signal transmitted through CAN communication.
CVT LAMP	(On/Off)	▼	▼	Displays the transmission status of the CVT indicator signal transmitted through CAN communication.
SPORT MODE IND	(On/Off)	▼	▼	<ul style="list-style-type: none"> Displays the transmission status of the S mode indicator signal transmitted through CAN communication. It is displayed although not equipped.
MMODE IND	(On/Off)	▼	▼	Displays the transmission status of the manual mode signal transmitted through CAN communication.
SMCOIL D	(On/Off)	▼	▼	Displays the energizing status of step motor coil "D".
SMCOIL C	(On/Off)	▼	▼	Displays the energizing status of step motor coil "C".
SMCOIL B	(On/Off)	▼	▼	Displays the energizing status of step motor coil "B".
SMCOIL A	(On/Off)	▼	▼	Displays the energizing status of step motor coil "A".
LUSEL SOL OUT	(On/Off)	▼	▼	Displays the command value from TCM to the lock-up select solenoid valve.
LUSEL SOL MON	(On/Off)	▼	▼	Monitors the command value from TCM to the lock-up select solenoid valve and displays the monitored value.
VDC ON	(On/Off)	▼	X	Displays the reception status of the VDC operation signal received through CAN communication.
TCS ON	(On/Off)	▼	X	Displays the reception status of the TCS operation signal received through CAN communication.

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

DIAGNOSIS SYSTEM (TCM)

< SYSTEM DESCRIPTION >

[CVT: RE0F10B]

Monitored item (Unit)	(Unit)	Monitor item selection		Remarks
		MAIN SIGNALS	ECU INPUT SIGNALS	
ABS ON	(On/Off)	▼	X	Displays the reception status of the ABS operation signal received through CAN communication.
ACC ON	(On/Off)	▼	X	It is displayed although not equipped.
RANGE		X	▼	Displays the gear position recognized by TCM.
M GEAR POS		X	▼	Display the target gear of manual mode
D POSITION SW	(On/Off)	▼	X	Displays the operation status of the transmission range switch (D position).
N POSITION SW	(On/Off)	▼	X	Displays the operation status of the transmission range switch (N position).
L POSITION SW	(On/Off)	▼	X	Displays the operation status of the transmission range switch (L position).
P POSITION SW	(On/Off)	▼	X	Displays the operation status of the transmission range switch (P position).
R POSITION SW	(On/Off)	▼	X	Displays the operation status of the transmission range switch (R position).
DRIVE MODE STATS	(On/Off)	▼	▼	<ul style="list-style-type: none"> • Displays the drive mode status recognized by TCM. • Only vehicle with Integrated Control System are displayed.
SNOW MODE	(On/Off)	▼	▼	<ul style="list-style-type: none"> • Display the drive mode (SNOW switch status) of Integrated Control System received through CAN communication. • Only vehicle with Integrated Control System are displayed. • It is displayed although not equipped.
ECO MODE	(On/Off)	▼	▼	<ul style="list-style-type: none"> • Display the driving mode (ECO switch status) of Integrated Control System received through CAN communication. • Only vehicle with Integrated Control System are displayed.
NORMAL MODE	(On/Off)	▼	▼	<ul style="list-style-type: none"> • Display the driving mode (AUTO switch status) of Integrated Control System received through CAN communication. • Only vehicle with Integrated Control System are displayed.
SPORT MODE	(On/Off)	▼	▼	<ul style="list-style-type: none"> • Display the driving mode (SPORT switch status) of Integrated Control System received through CAN communication. • Only vehicle with Integrated Control System are displayed.
CVT-A	(On/Off)	—	—	This monitor item does not use.
CVT-B	(On/Off)	—	—	This monitor item does not use.

WORK SUPPORT

Item name	Description
ENGINE BRAKE ADJ.	The engine brake level setting can be canceled.
CONFORM CVTF DETERIORTN	Display the CVT fluid deterioration level.

Engine Brake Adjustment

“ENGINE BRAKE LEVEL”

DIAGNOSIS SYSTEM (TCM)

< SYSTEM DESCRIPTION >

[CVT: RE0F10B]

0: Initial set value (Engine brake level control is activated)

OFF: Engine brake level control is deactivated.

CAUTION:

Mode of “+1”“0”“-1”“-2”“OFF” can be selected by pressing the “UP”“DOWN” on CONSULT screen. However, do not select mode other than “0” and “OFF”. If the “+1” or “-1” or “-2” is selected, that might cause the irregular driveability.

Check CVT Fluid Deterioration Date

“CVTF DETERIORATION DATE”

210000 or more:

It is necessary to change CVT fluid.

Less than 210000:

It is not necessary to change CVT fluid.

CAUTION:

Touch “CLEAR” after changing CVT fluid, and then erase “CVTF DETERIORATION DATE”.

ATFTEMP COUNT Conversion Table

INFOID:000000008274048

ATFTEMP COUNT	Temperature °C (°F)	ATFTEMP COUNT	Temperature °C (°F)
4	-30 (-22)	177	90 (194)
8	-20 (-4)	183	95 (203)
13	-10 (14)	190	100 (212)
17	-5 (23)	196	105 (221)
21	0 (32)	201	110 (230)
27	5 (41)	206	115 (239)
32	10 (50)	210	120 (248)
39	15 (59)	214	125 (257)
47	20 (68)	218	130 (266)
55	25 (77)	221	135 (275)
64	30 (86)	224	140 (284)
73	35 (95)	227	145 (293)
83	40 (104)	229	150 (302)
93	45 (113)	231	155 (311)
104	50 (122)	233	160 (320)
114	55 (131)	235	165 (329)
124	60 (140)	236	170 (338)
134	65 (149)	238	175 (347)
143	70 (158)	239	180 (356)
152	75 (167)	241	190 (374)
161	80 (176)	243	200 (392)
169	85 (185)	—	—

Diagnostic Tool Function

INFOID:000000008274049

OBD-II SELF-DIAGNOSTIC PROCEDURE (WITH GST)

Refer to [EC-62, "GST \(Generic Scan Tool\)"](#).

ECU DIAGNOSIS INFORMATION

TCM

Reference Value

INFOID:000000008274050

VALUES ON THE DIAGNOSIS TOOL

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Item name	Condition	Display value (Approx.)
VSP SENSOR	During driving	Approximately matches the speedometer reading.
ESTM VSP SIG	During driving	Approximately matches the speedometer reading.
PRI SPEED SEN	During driving (lock-up ON)	Approximately matches the engine speed.
ENG SPEED SIG	Engine running	Closely matches the tachometer reading.
SEC HYDR SEN	<ul style="list-style-type: none"> Selector lever: "N" position At idle 	Approx. 1.0 V
ATF TEMP SEN	CVT fluid: Approx. 20°C (68°F)	Approx. 2.01 – 2.05 V
	CVT fluid: Approx. 50°C (122°F)	Approx. 1.45 – 1.50 V
	CVT fluid: Approx. 80°C (176°F)	Approx. 0.90 – 0.94 V
VIGN SEN	Ignition switch: ON	10 – 16 V
VEHICLE SPEED	During driving	Approximately matches the speedometer reading.
PRI SPEED	During driving (lock-up ON)	Approximately matches the engine speed.
SEC SPEED	During driving	48 X Approximately matches the speedometer reading.
ENG SPEED	Engine running	Closely matches the tachometer reading.
SLIP REV	During driving	engine speed – primary speed
GEAR RATIO	During driving	Approx. 2.34 – 0.39
G SPEED	Vehicle stopped	Approx. 0.00 G
	During acceleration	The value changes to the positive side along with acceleration.
	During deceleration	The value changes to the positive side along with deceleration.
ACC PEDAL OPEN	Released accelerator pedal - Fully depressed accelerator pedal	0.0/8 – 8.0/8
SEC PRESS	<ul style="list-style-type: none"> After engine warm up Selector lever: "N" position At idle 	Approx. 1.0 MPa
ATFTEMP COUNT*1	CVT fluid: Approx. 20°C (68°F)	47
	CVT fluid: Approx. 50°C (122°F)	104
	CVT fluid: Approx. 80°C (176°F)	161
DSR REV	During driving	The value changes to the positive side along with deceleration.
DGEAR RATIO	During driving	The value changes to the positive side along with deceleration.
DSTM STEP	During driving	Approx. –20 step – 190 step
STM STEP	During driving	Approx. –20 step – 177 step

TCM

< ECU DIAGNOSIS INFORMATION >

[CVT: RE0F10B]

Item name	Condition	Display value (Approx.)	
LU PRS	<ul style="list-style-type: none"> • Engine started • Vehicle is stopped. 	Approx. -0.400 MPa	A
	<ul style="list-style-type: none"> • Selector lever: "D" position • Accelerator pedal position: 1/8 or less • Vehicle speed: 20 km/h (12 MPH) or more 	Approx. 0.400 MPa	B
LINE PRS	<ul style="list-style-type: none"> • After engine warm up • Selector lever: "N" position • At idle 	Approx. 0.750 MPa	C
	<ul style="list-style-type: none"> • After engine warm up • Selector lever: "N" position • Depress the accelerator pedal fully 	Approx. 4.930 – 5.430 MPa	TM
TGT SEC PRESS	<ul style="list-style-type: none"> • After engine warm up • Selector lever: "N" position • At idle 	Approx. 0.700 MPa	E
ISOLT1	—	—	
ISOLT2	—	—	
ISOLT3	—	—	F
SOLMON1	—	—	
SOLMON2	—	—	G
SOLMON3	—	—	
BRAKE SW	Depressed brake pedal	On	
	Released brake pedal	Off	H
FULL SW	Always	Off	
IDLE SW	Released accelerator pedal	On	I
	Fully depressed accelerator pedal	Off	
SPORT MODE SW	Always	Off	
STRDWSW	Always	Off	J
STRUPSW	Always	Off	
DOWNLVR	Selector lever: - side	On	
	Other than the above	Off	K
UPLVR	Selector lever: + side	On	
	Other than the above	Off	L
NONMMODE	Manual shift gate position (neutral, +side, -side)	Off	
	Other than the above	On	M
MMODE	Manual shift gate position (neutral)	On	
	Other than the above	Off	
INDLRNG	Always	Off	N
INDDRNG	Selector lever in "D" position	On	
	When setting selector lever to other positions	Off	
INDNRNG	Selector lever in "N" position	On	O
	When setting selector lever to other positions	Off	
INDRRNG	Selector lever in "R" position	On	
	When setting selector lever to other positions	Off	P
INDPRNG	Selector lever in "P" position	On	
	When setting selector lever to other positions	Off	
CVT LAMP	Approx. 2 seconds after ignition switch ON	On	
	Other conditions	Off	

TCM

< ECU DIAGNOSIS INFORMATION >

[CVT: RE0F10B]

Item name	Condition	Display value (Approx.)
SPORT MODE IND	Always	Off
MMODE IND	In manual mode	On
	Other conditions	Off
SMCOIL D	During driving	Changes On ⇔ Off
SMCOIL C	During driving	Changes On ⇔ Off
SMCOIL B	During driving	Changes On ⇔ Off
SMCOIL A	During driving	Changes On ⇔ Off
LUSEL SOL OUT	Selector lever: "P", "N" positions	On
	Wait at least for 5 seconds with the selector lever in "R", "D" positions	Off
LUSEL SOL MON	Selector lever: "P", "N" positions	On
	Wait at least for 5 seconds with the selector lever in "R", "D" positions	Off
VDC ON	ESP is activated	On
	Other conditions	Off
TCS ON	TCS is activated	On
	Other conditions	Off
ABS ON	ABS is activated	On
	Other conditions	Off
ACC ON	Always	Off
RANGE	Selector lever in "N" or "P" position	N·P
	Selector lever in "R" position	R
	Selector lever in "D" position	D
M GEAR POS	Gear position: M1	1
	Gear position: M2	2
	Gear position: M3	3
	Gear position: M4	4
	Gear position: M5	5
	Gear position: M6	6
	Gear position: M7	7
D POSITION SW	Selector lever in "D" position	On
	Other than the above position	Off
N POSITION SW	Selector lever in "N" position	On
	Other than the above position	Off
L POSITION SW	Always	Off
P POSITION SW	Selector lever in "P" position	On
	Other than the above position	Off
R POSITION SW	Selector lever in "R" position	On
	Other than the above position	Off
DRIVE MODE STATS*2	Integrated Control System: NORMAL mode	NORMAL
	Integrated Control System: ECO mode	ECO
	Integrated Control System: SPORT mode	SPORT
SPORT MODE*2	Integrated Control System: SPORT mode	On
	Other conditions	Off

TCM

< ECU DIAGNOSIS INFORMATION >


[CVT: RE0F10B]

Item name	Condition	Display value (Approx.)
NORMAL MODE*2	Integrated Control System: NORMAL mode	On
	Other conditions	Off
ECO MODE*2	Integrated Control System: ECO mode	On
	Other conditions	Off
SNOW MODE*2	Always	Off
CVT-A	—	—
CVT-B	—	—

*1: Means CVT fluid temperature. Convert numerical values for actual fluid temperature °C (°F). Refer to [TM-107, "ATFTEMP COUNT Conversion Table"](#).

*2: With Integrated Control System

TERMINAL LAYOUT





PHYSICAL VALUES

Terminal No. (wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/Output		
1 (G)	Ground	R RANGE SW	Input	Selector lever in "R" position	10 – 16 V
				Other than the above position	0 V
2 (Y)	Ground	N RANGE SW	Input	Selector lever in "N" position	10 – 16 V
				Other than the above position	0 V
3 (W)	Ground	D RANGE SW	Input	Selector lever in "D" positions	10 – 16 V
				Other than the above position	0 V
4*1 (V)	—	—	—	—	—
5 (B)	Ground	Ground	Output	Always	0 V
8 (BR)	—	CLOCK (SEL2)	—	—	—
9 (G)	—	CHIP SELECT (SEL1)	—	—	—
10 (W)	—	DATA I/O (SEL3)	—	—	—

TCM

< ECU DIAGNOSIS INFORMATION >

[CVT: RE0F10B]

Terminal No. (wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/Output			
11 (L)	Ground	P RANGE SW	Input	Ignition switch ON	Selector lever in "P" position	10 – 16 V
					Other than the above position	0 V
13 (SB)	Ground	CVT fluid temperature sensor	Input	Ignition switch ON	When CVT fluid temperature is 20°C (68°F)	2.0 V
					When CVT fluid temperature is 80°C (176°F)	1.0 V
15 (P)	Ground	Secondary pressure sensor	Input	<ul style="list-style-type: none"> Selector lever: "N" position Idle speed 		1.0 V
25 (Y)	Ground	Sensor ground	Input	Always		0 V
26 (LG)	Ground	Sensor power supply	Output	Ignition switch ON		5.0 V
				Ignition switch OFF		0 V
27 (GR)	Ground	Step motor D	Output	Within 2 seconds after ignition switch ON, the time measurement by using the pulse width measurement function (Hi level) of CONSULT.*2 CAUTION: Connect the diagnosis data link cable to the vehicle diagnosis connector.		10.0 msec
28 (V)	Ground	Step motor C	Output			30.0 msec
29 (BG)	Ground	Step motor B	Output			10.0 msec
30 (R)	Ground	Step motor A	Output			30.0 msec
31 (P)	—	CAN-L	Input/Output	—		—
32 (L)	—	CAN-H	Input/Output	—		—
33 (BG)	Ground	Primary speed sensor	Input	<ul style="list-style-type: none"> Selector lever: "M1" position While driving at 20 km/h (12 MPH) 		720 Hz  <small>JPDIA0819ZZ</small>
34 (R)	Ground	Secondary speed sensor	Input	<ul style="list-style-type: none"> Selector lever: "M1" position While driving at 20 km/h (12 MPH) 		480 Hz  <small>JPDIA0901ZZ</small>
37 (L)	Ground	Lock-up select solenoid valve	Output	Ignition switch ON	Selector lever in "P" or "N" positions	10 – 16 V
					Wait at least for 5 seconds with the selector lever in "R" or "D" positions.	0 V

TCM

< ECU DIAGNOSIS INFORMATION >

[CVT: RE0F10B]

Terminal No. (wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/Output			
38 (G)	Ground	Torque converter clutch solenoid valve	Output	When vehicle cruises in "D" position	When CVT performs lock-up	6.0 V
					When CVT does not perform lock-up	1.5 V
39 (W)	Ground	Secondary pressure solenoid valve	Output	"P" or "N" position idle	Release your foot from the accelerator pedal.	5.0 – 7.0 V
					Press the accelerator pedal all the way down.	3.0 – 4.0 V
40 (Y)	Ground	Line pressure solenoid valve	Output		Release your foot from the accelerator pedal.	5.0 – 7.0 V
					Press the accelerator pedal all the way down.	1.0 V
42 (B)	Ground	Ground	Output	Always		0 V
46 (LG)	Ground	Ignition power supply	Input	Ignition switch ON	—	10 – 16 V
				Ignition switch OFF	—	0 V
47 (BG)	Ground	Battery power supply (memory back-up)	Input	Always		10 – 16 V
48 (Y)	Ground	Ignition power supply	Input	Ignition switch ON	—	10 – 16 V
				Ignition switch OFF	—	0 V

*1: This harness is not used.

*2: A circuit tester cannot be used to test this item.

Fail-Safe

INFOID:000000008274051

The TCM has an electrical fail-safe mode. In this mode TCM is operator even if there is an error in a main electronic control input/output signal circuit.

DESCRIPTION

When a malfunction is detected in each sensor, switch, solenoid or others, this function provides control to minimize reduction of drivability so that durability of transmission assembly can be acquired.

DTC	Condition	Vehicle behavior
P0703	—	<ul style="list-style-type: none"> Start is slow Acceleration is slow
P0705	—	<ul style="list-style-type: none"> Position indicator on combination meter is not displayed Selector shock is large Start is slow Acceleration at high load state is slow Manual mode is not activated Lock-up is not performed

TCM

< ECU DIAGNOSIS INFORMATION >

[CVT: RE0F10B]

DTC	Condition	Vehicle behavior
P0710	Engine coolant temperature when engine starts is 10°C (50°F) or more	Start is slow
	Engine coolant temperature when engine starts is 10°C (50°F) or less	<ul style="list-style-type: none"> • Start is slow • Acceleration is slow • Vehicle speed is not increased
	Engine coolant temperature when engine starts is -35°C (-31°F) or less	Vehicle speed is not increased
P0715	—	<ul style="list-style-type: none"> • Acceleration is slow • Re-start is slow after vehicle is stop by strong deceleration • Manual mode is not activated • Lock-up is not performed
P0720	—	<ul style="list-style-type: none"> • Start is slow • Acceleration is slow • Re-start is slow after vehicle is stop by strong deceleration • Manual mode is not activated • Lock-up is not performed
P0725	—	Lock-up is not performed
P0740	—	<ul style="list-style-type: none"> • Selector shock is large • Lock-up is not performed
P0744	—	Lock-up is not performed
P0746	A malfunction is detected	<ul style="list-style-type: none"> • Start is slow • Acceleration is slow • Lock-up is not performed
	Function is excessively reduced after a malfunction is detected	<ul style="list-style-type: none"> • Start is difficult • Drive is difficult • Lock-up is not performed
P0778	—	Vehicle speed is not increased
P0826	—	Manual mode is not activated
P0840	—	<ul style="list-style-type: none"> • Start is slow • Acceleration is slow
P0841	—	<ul style="list-style-type: none"> • Start is slow • Acceleration is slow
P0845	—	<ul style="list-style-type: none"> • Start is slow • Acceleration is slow
P0868	—	<ul style="list-style-type: none"> • Start is slow • Acceleration is slow
P1701	—	<ul style="list-style-type: none"> • Start is slow • Acceleration is slow
P1705	—	<ul style="list-style-type: none"> • Acceleration is slow • Lock-up is not performed
P1709	—	<ul style="list-style-type: none"> • Start is slow • Acceleration is slow • Shift position indicator (P, N) is not displayed, or is displayed with delay.
P1722	—	Lock-up is not activated in coast state

TCM

< ECU DIAGNOSIS INFORMATION >

[CVT: RE0F10B]

DTC	Condition	Vehicle behavior
P1723	A malfunction is detected in primary pulley speed sensor side	<ul style="list-style-type: none"> • Acceleration is slow • Re-start is slow after vehicle is stop by strong deceleration • Manual mode is not activated • Lock-up is not performed
	A malfunction is detected in secondary pulley speed sensor	<ul style="list-style-type: none"> • Start is slow • Acceleration is slow • Re-start is slow after vehicle is stop by strong deceleration • Manual mode is not activated • Lock-up is not performed
P1726	—	Acceleration is slow
P1740	—	<ul style="list-style-type: none"> • Selector shock is large • Lock-up is not performed
P1777	A malfunction is detected in low side (when vehicle is stopped)	<ul style="list-style-type: none"> • Vehicle speed is not increased • Lock-up is not performed
	A malfunction is detected in high side (during driving)	<ul style="list-style-type: none"> • Start is slow • Acceleration is slow • Lock-up is not performed
U0100	—	<ul style="list-style-type: none"> • Start is slow • Acceleration is slow • Vehicle speed is not increased
U1000	—	<ul style="list-style-type: none"> • Start is slow • Acceleration is slow • Vehicle speed is not increased
U1010	—	<ul style="list-style-type: none"> • Start is slow • Acceleration is slow • Vehicle speed is not increased

DTC Inspection Priority Chart

INFOID:000000008274052

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	Detected items (DTC)	Reference
1	P1709 INCOMPLETED DATA WRITING	TM-184, "DTC Logic"
	U0100 LOST COMM (ECM A)	TM-138, "DTC Logic"
	U1000 CAN COMM CIRCUIT	TM-139, "DTC Logic"
	U1010 CONTROL UNIT (CAN)	TM-140, "DTC Logic"
2	P0725 ENGINE SPEED	TM-156, "DTC Logic"
	P1705 TP SENSOR	TM-183, "DTC Logic"
	P1726 THROTTLE CONTROL SIG	TM-189, "DTC Logic"

TCM

< ECU DIAGNOSIS INFORMATION >

[CVT: RE0F10B]

Priority	Detected items (DTC)	Reference
3	P0703 BRAKE SWITCH B	TM-141, "DTC Logic"
	P0705 T/M RANGE SENSOR A	TM-144, "DTC Logic"
	P0710 FLUID TEMP SENSOR A	TM-147, "DTC Logic"
	P0715 INPUT SPEED SENSOR A	TM-150, "DTC Logic"
	P0720 OUTPUT SPEED SENSOR	TM-153, "DTC Logic"
	P0740 TORQUE CONVERTER	TM-157, "DTC Logic"
	P0745 PC SOLENOID A	TM-162, "DTC Logic"
	P0778 PC SOLENOID B	TM-168, "DTC Logic"
	P0826 UP/DOWN SHIFT SWITCH	TM-170, "DTC Logic"
	P0840 FLUID PRESS SEN/SW A	TM-173, "DTC Logic"
	P1701 TCM	TM-180, "DTC Logic"
	P1722 VEHICLE SPEED	TM-186, "DTC Logic"
	P1740 SLCT SOLENOID	TM-190, "DTC Logic"
	P1777 STEP MOTOR	TM-192, "DTC Logic"
4	P0744 TORQUE CONVERTER	TM-160, "DTC Logic"
	P0746 PC SOLENOID A	TM-164, "DTC Logic"
	P0776 PC SOLENOID B	TM-166, "DTC Logic"
	P0841 FLUID PRESS SEN/SW A	TM-176, "DTC Logic"
	P0868 FLUID PRESS LOW	TM-178, "DTC Logic"
	P1723 SPEED SENSOR	TM-187, "DTC Logic"
	P1778 STEP MOTOR	TM-195, "DTC Logic"

DTC Index

INFOID:000000008274053

NOTE:

If multiple malfunction codes are detected at the same time, check each code according to the "DTC check priority list". [TM-115, "DTC Inspection Priority Chart"](#).

DTC		Items (CONSULT screen terms)	Reference
"ENGINE" with CONSULT or GST*	"TRANSMISSION" with CONSULT		
—	P0703	BRAKE SWITCH B	TM-141
P0705	P0705	T/M RANGE SENSOR A	TM-144
P0710	P0710	FLUID TEMP SENSOR A	TM-147
P0715	P0715	INPUT SPEED SENSOR A	TM-150
P0720	P0720	OUTPUT SPEED SENSOR	TM-153
—	P0725	ENGINE SPEED	TM-156
P0740	P0740	TORQUE CONVERTER	TM-157
P0744	P0744	TORQUE CONVERTER	TM-160
P0745	P0745	PC SOLENOID A	TM-162
P0746	P0746	PC SOLENOID A	TM-164
P0776	P0776	PC SOLENOID B	TM-166
P0778	P0778	PC SOLENOID B	TM-168
—	P0826	UP/DOWN SHIFT SWITCH	TM-170
P0840	P0840	FLUID PRESS SEN/SW A	TM-173
—	P0841	FLUID PRESS SEN/SW A	TM-176

TCM

< ECU DIAGNOSIS INFORMATION >

[CVT: RE0F10B]

DTC		Items (CONSULT screen terms)	Reference
"ENGINE" with CONSULT or GST*	"TRANSMISSION" with CONSULT		
—	P0868	FLUID PRESS LOW	TM-178
—	P1701	TCM	TM-180
—	P1705	TP SENSOR	TM-183
—	P1709	INCOMPLETED DATA WRITING	TM-184
—	P1722	VEHICLE SPEED	TM-186
—	P1723	SPEED SENSOR	TM-187
—	P1726	THROTTLE CONTROL SIG	TM-189
P1740	P1740	SLCT SOLENOID	TM-190
P1777	P1777	STEP MOTOR	TM-192
P1778	P1778	STEP MOTOR	TM-195
U0100	U0100	LOST COMM (ECM A)	TM-138
—	U1000	CAN COMM CIRCUIT	TM-139
—	U1010	CONTROL UNIT (CAN)	TM-140

*: These numbers are prescribed by SAE J2012.

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

< WIRING DIAGRAM >


WIRING DIAGRAM

CVT CONTROL SYSTEM

Wiring Diagram

INFOID:000000008274054

For connector terminal arrangements, harness layouts, and alphabets in a (option abbreviation; if not described in wiring diagram), refer to [GI-12. "Connector Information"](#).



CVT SHIFT LOCK SYSTEM


< WIRING DIAGRAM >

[CVT: RE0F10B]


CVT SHIFT LOCK SYSTEM

Wiring Diagram

INFOID:000000008274055

For connector terminal arrangements, harness layouts, and alphabets in a  (option abbreviation; if not described in wiring diagram), refer to [GI-12, "Connector Information"](#).

*: This connector is not shown in "Harness Layout".



SHIFT LOCK SYSTEM

2010/08/30

JCDWA0672GB

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow


INFOID:000000008274056

INTRODUCTION

The TCM receives a signal from the vehicle speed sensor, transmission range switch and provides shift control or lock-up control via CVT solenoid valves.


The TCM also communicates with the ECM by means of a signal sent from sensing elements used with the OBD-related parts of the CVT system for malfunction-diagnostic purposes. The TCM is capable of diagnosing malfunctioning parts while the ECM can store malfunctions in its memory.

Input and output signals must always be correct and stable in the operation of the CVT system. The CVT system must be in good operating condition and be free of valve seizure, solenoid valve malfunction, etc.



It is much more difficult to diagnose an error that occurs intermittently rather than continuously. Most intermittent errors are caused by poor electric connections or improper wiring. In this case, careful checking of suspected circuits may help prevent the replacement of good parts.


A visual check only may not find the cause of the errors. A road test with CONSULT (or GST) or a circuit tester connected should be performed. Follow the "DETAILED FLOW".



Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a driveability complaint. The customer can supply good information about such errors, especially intermittent ones. Find out what symptoms are present and under what conditions they occur. A "Diagnostic Work Sheet" as shown on the example (Refer to [TM-121](#)) should be used.

Start your diagnosis by looking for "conventional" errors first. This will help troubleshoot driveability errors on an electronically controlled engine vehicle.

Also check related Service bulletins.



DETAILED FLOW

1. COLLECT THE INFORMATION FROM THE CUSTOMER

Get the detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred) using diagnosis worksheet. Refer to [TM-121, "Diagnostic Work Sheet"](#).

>> GO TO 2.

2. CHECK SYMPTOM 1

Check the following items based on the information obtained from the customer.

- Fail-safe. Refer to [TM-113, "Fail-Safe"](#).
- CVT fluid inspection. Refer to [TM-213, "Inspection"](#).
- Line pressure test. Refer to [TM-132, "Inspection and Judgment"](#).

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[CVT: RE0F10B]

- Stall test. Refer to [TM-130, "Inspection and Judgment"](#).

>> GO TO 3.

3. CHECK DTC

1. Check DTC.
2. Perform the following procedure if DTC is detected.
 - Record DTC.
 - Erase DTC. Refer to [TM-101, "Diagnosis Description"](#).

Is any DTC detected?

- YES >> GO TO 4.
NO >> GO TO 5.

4. PERFORM DIAGNOSTIC PROCEDURE

Perform "Diagnostic Procedure" for the displayed DTC.

>> GO TO 5.

5. PERFORM DTC CONFIRMATION PROCEDURE

Perform "DTC CONFIRMATION PROCEDURE" for the displayed DTC.

Is DTC detected?

- YES >> GO TO 4.
NO >> GO TO 6.

6. CHECK SYMPTOM 2

Confirm the symptom described by the customer.

Is any malfunction present?

- YES >> GO TO 7.
NO >> **INSPECTION END**

7. RODE TEST

Perform "RODE TEST". Refer to [TM-134, "Description"](#).

>> GO TO 8.

8. CHECK SYMPTOM 3

Confirm the symptom described by the customer.

Is any malfunction present?

- YES >> GO TO 2.
NO >> **INSPECTION END**

Diagnostic Work Sheet

INFOID:000000008274057

INFORMATION FROM CUSTOMER

KEY POINTS

- **WHAT**..... Vehicle & CVT model
- **WHEN**..... Date, Frequencies
- **WHERE**..... Road conditions
- **HOW**..... Operating conditions, Symptoms

Customer name MR/MS	Model & Year	VIN
Trans. Model	Engine	Mileage
Malfunction Date	Manuf. Date	In Service Date
Frequency	<input type="checkbox"/> Continuous <input type="checkbox"/> Intermittent (times a day)	

ADDITIONAL SERVICE WHEN REPLACING TCM

< BASIC INSPECTION >

[CVT: RE0F10B]

ADDITIONAL SERVICE WHEN REPLACING TCM

Description

INFOID:000000008274058

When replacing the TCM, perform the following work.

TCM PROGRAMMING

- Since vehicle specifications are not yet written in a new TCM, it is necessary to write them with CONSULT.

CAUTION:

When replacing TCM, save TCM data on CONSULT before removing TCM.

LOADING AND STORING OF CALIBRATION DATA

- The TCM acquires calibration data (individual characteristic value) of each solenoid that is stored in the ROM assembly (in the control valve). This enables the TCM to perform accurate control. After the TCM is replaced, check that the calibration data is correctly loaded and stored.

CAUTION:

When replacing TCM and transaxle assembly/control valve simultaneously, replace transaxle assembly first and then replace TCM.

Work Procedure

INFOID:000000008274059

CAUTION:

Immediately after TCM is replaced or after control valve or transaxle assembly is replaced (after TCM initialization is complete), self-diagnosis result of "P1701", "P1709" may be displayed. In this case, erase self-diagnosis result using CONSULT. After erasing self-diagnosis result, perform DTC "P1701", "P1709" reproduction procedure and check that malfunction is not detected. Refer to [TM-180, "DTC Logic"](#) (P1701), [TM-184, "DTC Logic"](#) (P1709).

1. CHECK NEW TCM PART NUMBER

Check new TCM part number to see whether it is blank TCM or not.

NOTE:

- Part number of blank TCM is 310F6-XXXXX.
- Check the part number when ordering TCM or with the one included in the label on the container box.

Is the new TCM a blank TCM?

- YES >> GO TO 2.
- NO >> GO TO 3.

2. SAVING TCM DATA (VEHICLE SPECIFICATIONS)

NOTE:

Save necessary data stored in TCM in CONSULT according to the following instructions:

Ⓜ With CONSULT

1. Turn ignition switch OFF.
2. Turn ignition switch ON.
3. Select "Re/programming, Configuration".
4. Select "AT/CVT".

NOTE:

If "AT/CVT" is not displayed and TCM data cannot be saved on CONSULT, GO TO 3.

5. Select "Programming".
6. Save TCM data on CONSULT according to the CONSULT display.

>> GO TO 3.

3. REPLACE TCM

1. Turn ignition switch OFF and wait for 10 seconds.
2. Replace TCM. Refer to [TM-226, "Removal and Installation"](#).

>> GO TO 4.

4. LOAD CALIBRATION DATA

1. Shift the selector lever to the "P" position.

ADDITIONAL SERVICE WHEN REPLACING TCM

[CVT: RE0F10B]

< BASIC INSPECTION >

2. Turn ignition switch ON.
3. Check that "P" is displayed on shift position indicator on combination meter.

NOTE:

Displayed approximately 1 – 2 seconds after the selector lever is moved to the "P" position.

Does the shift position indicator display "P"?

YES >> GO TO 5.

NO >> GO TO 7.

5.STORE CALIBRATION DATA

1. Turn ignition switch OFF and wait for 5 seconds.
2. Turn ignition switch ON.

Does the shift position indicator display "P" at the same time when turning ON the ignition switch?

YES-1 (New TCM is blank)>>GO TO 6.

YES-2 (New TCM is not blank)>>WORK END

NO >> Check harness between battery and TCM harness connector terminal. Refer to [TM-180. "Diagnosis Procedure"](#).

6.WRITE TCM DATA (VEHICLE SPECIFICATIONS)

NOTE:

Write data saved in CONSULT into a new TCM according to the following instructions:

ⓅWith CONSULT

1. Select "Programming".
2. Perform programming according to the CONSULT display.

>> WORK END

7.DETECT MALFUNCTIONING ITEM

Check the following items:

- Harness between the TCM and the ROM assembly inside the transaxle assembly is open or shorted.
- Disconnected, loose, bent, collapsed, or otherwise abnormal connector housing terminals

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

ADDITIONAL SERVICE WHEN REPLACING CONTROL VALVE OR TRANSAXLE ASSEMBLY

< BASIC INSPECTION >

[CVT: RE0F10B]

ADDITIONAL SERVICE WHEN REPLACING CONTROL VALVE OR TRANSAXLE ASSEMBLY

Description

INFOID:000000008274060

When replacing the transaxle assembly/control valve, perform the following work.

ERASING, LOADING AND STORING OF CALIBRATION DATA

- The TCM acquires calibration data (individual characteristic value) of each solenoid that is stored in the ROM assembly (in the control valve). This enables the TCM to perform accurate control. For this reason, after the transaxle assembly/control valve is replaced, it is necessary to erase the calibration data previously stored in TCM, to load new calibration data, and to store them.

ERASING OF CVT FLUID DEGRADATION LEVEL DATA

- TCM records the degradation level of the CVT fluid calculated from the vehicle driving status. Therefore, if the transaxle assembly/control valve is replaced, it is necessary to erase the CVT fluid degradation level data recorded by TCM.

Work Procedure

INFOID:000000008274061

CAUTION:

Immediately after TCM is replaced or after control valve or transaxle assembly is replaced (after TCM initialization is complete), self-diagnosis result of "P1701", "P1709" may be displayed. In this case, erase self-diagnosis result using CONSULT. After erasing self-diagnosis result, perform DTC "P1701", "P1709" reproduction procedure and check that malfunction is not detected. Refer to [TM-180, "DTC Logic" \(P1701\)](#), [TM-184, "DTC Logic" \(P1709\)](#).

1. PREPARATION BEFORE WORK

With CONSULT

1. Start the engine.

CAUTION:

Never drive the vehicle.

2. Select "Data Monitor" in "TRANSMISSION".
3. Select "ATFTEMP COUNT".

Is "ATFTEMP COUNT" 47 [equivalent to 20°C (68°F)] or more?

YES >> GO TO 2.

- NO >> 1. Warm up the transaxle assembly until "ATFTEMP COUNT" reaches "47" [equivalent to 20°C (68°F)] or more.
2. GO TO 2.

2. PERFORM TCM INITIALIZATION

With CONSULT

1. Turn ignition switch OFF.
 2. Turn ignition switch ON.
- #### CAUTION:
- Never start the engine.**
3. Select "Self Diagnostic Results" in "TRANSMISSION".
 4. Shift selector lever to "R" position.
 5. Depress slightly the accelerator pedal (Pedal angle: 2.0/8) while depressing the brake pedal.
 6. Select "Erase" with step 5.
 7. Release brake pedal and accelerator pedal.
 8. Select "CALIB DATA" in "TRANSMISSION".
 9. Check that "CALIB DATA" value is as shown as in the following table.

Item name	Display value
UNIT CLB ID 1	00
UNIT CLB ID 2	00
UNIT CLB ID 3	00
UNIT CLB ID 4	00

ADDITIONAL SERVICE WHEN REPLACING CONTROL VALVE OR TRANSAXLE ASSEMBLY

< BASIC INSPECTION >

[CVT: RE0F10B]

Item name	Display value
UNIT CLB ID 5	00
UNIT CLB ID 6	00

Is "CALIB DATA" value it?

YES >> GO TO 3.

NO >> GO TO 1.

3. LOAD CALIBRATION DATA

1. Shift selector lever to "P" position.
2. Check that "P" is displayed on shift position indicator on combination meter.

NOTE:

It indicates approximately 1 – 2 seconds after shifting the selector lever to "P" position.

Does shift position indicator display "P"?

YES >> GO TO 5.

NO >> GO TO 4.

4. DETECT MALFUNCTIONING ITEM

Check the following items:

- Harness between the TCM and the ROM assembly inside the transaxle assembly is open or shorted.
- Disconnected, loose, bent, collapsed, or otherwise abnormal connector housing terminals
- Power supply and ground of TCM. (Refer to [TM-180. "Diagnosis Procedure"](#).)

Is the inspection result normal?

YES >> GO TO 1.

NO >> Repair or replace the malfunctioning parts.

5. STORE CALIBRATION DATA

1. Turn ignition switch OFF and wait for 5 seconds.
2. Turn ignition switch ON.

Does the shift position indicator display "P" at the same time when turning ON the ignition switch?

YES >> GO TO 6.

NO >> Check harness between battery and TCM harness connector terminal. Refer to [TM-180. "Diagnosis Procedure"](#).

6. ERASE CVT FLUID DEGRADATION LEVEL DATA

With CONSULT

1. Select "WORK SUPPORT" in "TRANSMISSION".
2. Select "CONFORM CVTF DETERIORATION".
3. Touch "Clear".

>> WORK END

CVT FLUID COOLER SYSTEM

Cleaning

INFOID:000000008274062

Whenever an automatic transaxle is repaired, overhauled, or replaced, the CVT fluid cooler mounted in the radiator must be inspected and cleaned.

Metal debris and friction material, if present, can be trapped or be deposited in the CVT fluid cooler. This debris can contaminate the newly serviced CVT or, in severe cases, can block or restrict the flow of CVT fluid. In either case, malfunction of the newly serviced CVT may occur.

Debris, if present, may deposit as CVT fluid enters the cooler inlet. It will be necessary to back flush the cooler through the cooler outlet in order to flush out any built up debris.


CVT FLUID COOLER CLEANING PROCEDURE

1. Position an oil pan under the transaxle's inlet and outlet cooler hoses.
2. Identify the inlet and outlet fluid cooler hoses.
3. Disconnect the fluid cooler inlet and outlet rubber hoses from the steel cooler tubes or bypass valve.

NOTE:

Replace the cooler hoses if rubber material from the hose remains on the tube fitting.

4. Allow any CVT fluid that remains in the cooler hoses to drain into the oil pan.




5. Insert the extension adapter hose of a can of Transmission Cooler Cleaner (Nissan P/N 999MP-AM006) into the cooler outlet hose.

CAUTION:

- **Wear safety glasses and rubber gloves when spraying the Transmission Cooler Cleaner.**
- **Spray Transmission Cooler Cleaner only with adequate ventilation.**
- **Avoid contact with eyes and skin.**
- **Never breath vapors or spray mist.**

6. Hold the hose and can as high as possible and spray Transmission Cooler Cleaner in a continuous stream into the cooler outlet hose until CVT fluid flows out of the cooler inlet hose for 5 seconds.



7. Insert the tip of an air gun into the end of the cooler outlet hose.
8. Wrap a shop rag around the air gun tip and end of the cooler outlet hose.

9. Blow compressed air regulated to 5 to 9 kg/cm² (70 to 130 psi) through the cooler outlet hose for 10 seconds to force out any remaining CVT fluid.

10. Repeat steps 5 through 9 three additional times.

11. Position an oil pan under the banjo bolts that connect the CVT fluid cooler steel lines to the transaxle.


12. Remove the banjo bolts.

13. Flush each steel line from the cooler side back toward the transaxle by spraying Transmission Cooler Cleaner in a continuous stream for 5 seconds.

14. Blow compressed air regulated to 5 to 9 kg/cm² (70 to 130 psi) through each steel line from the cooler side back toward the transaxle for 10 seconds to force out any remaining CVT fluid.

15. Ensure all debris is removed from the steel cooler lines.

16. Ensure all debris is removed from the banjo bolts and fittings.



CVT FLUID COOLER SYSTEM

< BASIC INSPECTION >

[CVT: RE0F10B]

17. Perform "CVT FLUID COOLER DIAGNOSIS PROCEDURE".

CVT FLUID COOLER DIAGNOSIS PROCEDURE

NOTE:



Insufficient cleaning of the cooler inlet hose exterior may lead to inaccurate debris identification.

1. Position an oil pan under the transaxle's inlet and outlet cooler hoses.
2. Clean the exterior and tip of the cooler inlet hose.
3. Insert the extension adapter hose of a can of Transmission Cooler Cleaner (Nissan P/N 999MP-AM006) into the cooler outlet hose.


CAUTION:

- Wear safety glasses and rubber gloves when spraying the Transmission Cooler Cleaner.
- Spray Transmission Cooler Cleaner only with adequate ventilation.
- Avoid contact with eyes and skin.
- Never breath vapors or spray mist.

4. Hold the hose and can as high as possible and spray Transmission Cooler Cleaner in a continuous stream into the cooler outlet hose until CVT fluid flows out of the cooler inlet hose for 5 seconds.
5. Tie a common white, basket-type coffee filter to the end of the cooler inlet hose.




6. Insert the tip of an air gun into the end of the cooler outlet hose.
7. Wrap a shop rag around the air gun tip and end of cooler outlet hose.
8. Blow compressed air regulated to 5 to 9 kg/cm² (70 to 130 psi) through the cooler outlet hose to force any remaining CVT fluid into the coffee filter.
9. Remove the coffee filter from the end of the cooler inlet hose.
10. Perform "CVT FLUID COOLER INSPECTION PROCEDURE".



CVT FLUID COOLER INSPECTION PROCEDURE

1. Inspect the coffee filter for debris.
 - a. If small metal debris less than 1 mm (0.040 in) in size or metal powder is found in the coffee filter, this is normal. If normal debris is found, the CVT fluid cooler/radiator can be reused and the procedure is ended.




CVT FLUID COOLER SYSTEM

< BASIC INSPECTION >

[CVT: RE0F10B]

- b. If one or more pieces of debris are found that are over 1 mm (0.040 in) in size and/or peeled clutch facing material is found in the coffee filter, the fluid cooler is not serviceable. The radiator/fluid cooler must be replaced and the inspection procedure is ended.



CVT FLUID COOLER FINAL INSPECTION

After performing all procedures, ensure that all remaining oil is cleaned from all components.

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

STALL TEST

< BASIC INSPECTION >

[CVT: RE0F10B]


STALL TEST

Inspection and Judgment


INFOID:000000008274063

INSPECTION


1. Inspect the amount of engine oil. Replenish the engine oil if necessary.
2. Drive for about 10 minutes to warm up the vehicle so that the CVT fluid temperature is 50 to 80°C (122 to 176°F). Inspect the amount of CVT fluid. Replenish if necessary.



3. Securely engage the parking brake so that the tires do not turn.
4. Install a tachometer where it can be seen by driver during test.
NOTE:
It is good practice to mark the point of specified engine rpm on indicator.
5. Start engine, apply foot brake, and place selector lever in "D" position.



6. While holding down the foot brake, gradually press down the accelerator pedal.
7. Quickly read off the stall speed, and then quickly remove your foot from the accelerator pedal.
CAUTION:
Never hold down the accelerator pedal for more than 5 seconds during this test.



Stall speed : Refer to [TM-255, "Stall Speed"](#).

8. Move the selector lever to the "N" position.
9. Cool down the CVT fluid.
CAUTION:
Run the engine at idle for at least 1 minute.
10. Repeat steps 6 through 9 with selector lever in "R" position.

JUDGMENT

STALL TEST

< BASIC INSPECTION >

[CVT: RE0F10B]

	Selector lever position		Expected problem location
	"D"	"R"	
Stall rotation	H	O	<ul style="list-style-type: none"> • Forward clutch
	O	H	<ul style="list-style-type: none"> • Reverse brake
	L	L	<ul style="list-style-type: none"> • Engine and torque converter one-way clutch
	H	H	<ul style="list-style-type: none"> • Line pressure low • Primary pulley • Secondary pulley • Steel belt

O: Stall speed within standard value position.

H: Stall speed is higher than standard value.

L: Stall speed is lower than standard value.

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

LINE PRESSURE TEST

< BASIC INSPECTION >

[CVT: RE0F10B]

LINE PRESSURE TEST


Inspection and Judgment

INFOID:000000008274064

INSPECTION

Line Pressure Test Port

A : Line pressure test port



Line Pressure Test Procedure

1. Inspect the amount of engine oil and replenish if necessary.
2. Drive the car for about 10 minutes to warm it up so that the CVT fluid reaches in the range of 50 to 80°C (122 to 176°F), then inspect the amount of CVT fluid and replenish if necessary.


NOTE:

The CVT fluid temperature rises in the range of 50 to 80°C (122 to 176°F) during 10 minutes of driving.


3. After warming up CVT, remove the oil pressure detection plug and install the joint pipe adapter (SST: KV31103600) (A), adapter (SST: 25054000) (B), oil pressure gauge set (commercial service tool) (C).

CAUTION:

When using the oil pressure gauge, be sure to use the O-ring attached to the oil pressure detection plug.



4. Securely engage the parking brake so that the tires do not turn.



LINE PRESSURE TEST

[CVT: RE0F10B]


< BASIC INSPECTION >

5. Start the engine, and then measure the line pressure at both idle and the stall speed.

CAUTION:

- Keep the brake pedal pressed all the way down during measurement.
- When measuring the line pressure at the stall speed, refer to [TM-130, "Inspection and Judgment"](#).

Line pressure : Refer to [TM-255, "Line Pressure"](#).



6. After the measurements are complete, install the oil pressure detection plug and tighten to the specified torque below.

: 7.5 N·m (0.77 kg·m, 66 in·lb)

CAUTION:

- Never reuse O-ring.
- Apply CVT fluid to O-ring.

JUDGMENT

Judgment		Possible cause
Idle speed	Low for all positions ("P", "R", "N", "D")	Possible causes include malfunctions in the pressure supply system and low oil pump output. For example <ul style="list-style-type: none"> • Oil pump wear • Pressure regulator valve or plug sticking or spring fatigue • Oil strainer ⇒ oil pump ⇒ pressure regulator valve passage oil leak • Engine idle speed too low
	Only low for a specific position	Possible causes include an oil pressure leak in a passage or device related to the position after the pressure is distributed by the manual valve.
	High	Possible causes include a sensor malfunction or malfunction in the line pressure adjustment function. For example <ul style="list-style-type: none"> • Accelerator pedal position signal malfunction • CVT fluid temperature sensor malfunction • Line pressure solenoid malfunction (sticking in OFF state, filter clog, cut line) • Pressure regulator valve or plug sticking
Stall speed	Line pressure does not rise higher than the line pressure for idle.	Possible causes include a sensor malfunction or malfunction in the pressure adjustment function. For example <ul style="list-style-type: none"> • Accelerator pedal position signal malfunction • TCM malfunction • Line pressure solenoid malfunction (shorting, sticking in ON state) • Pressure regulator valve or plug sticking
	The pressure rises, but does not enter the standard position.	Possible causes include malfunctions in the pressure supply system and malfunction in the pressure adjustment function. For example <ul style="list-style-type: none"> • Accelerator pedal position signal malfunction • Line pressure solenoid malfunction (sticking, filter clog) • Pressure regulator valve or plug sticking
	Only low for a specific position	Possible causes include an oil pressure leak in a passage or device related to the position after the pressure is distributed by the manual valve.


ROAD TEST

Description

INFOID:000000008274065

DESCRIPTION

- The purpose of the test is to determine overall performance of CVT and analyze causes of problems.
- The road test consists of the following three parts:
 1. "Check Before Engine Is Started" [TM-134](#).
 2. "Check at Idle" [TM-134](#).
 3. "Cruise Test" [TM-135](#).



- Before road test, familiarize yourself with all test procedures and items to check.
- Perform tests on all items until specified symptom is found. Troubleshoot items the malfunctioning items after road test.



Check before Engine Is Started

INFOID:000000008274066

1.CHECK CVT INDICATOR LAMP

1. Park vehicle on flat surface.
2. Move selector lever to "P" position.
3. Turn ignition switch OFF. Wait at least 5 seconds.
4. Turn ignition switch ON. (Do not start engine.)

Is shift position indicator activated for about 2 seconds?

- YES >> 1. Turn ignition switch OFF.
 2. Perform self-diagnosis and note NG items.
 Refer to [TM-103, "CONSULT Function"](#).
 3. Go to [TM-134, "Check at Idle"](#).
- NO >> Stop "Road Test". Refer to [TM-202, "Symptom Table"](#).

Check at Idle

INFOID:000000008274067

1.CHECK STARTING THE ENGINE

1. Park vehicle on flat surface.
2. Move selector lever to "P" or "N" position.
3. Turn ignition switch OFF.
4. Turn ignition switch to "START" position.

Is engine started?

- YES >> GO TO 2.
 NO >> Stop "Road Test". Refer to [TM-202, "Symptom Table"](#).

2.CHECK STARTING THE ENGINE

1. Turn ignition switch ON.
2. Move selector lever to "D", "M" or "R" position.
3. Turn ignition switch to "START" position.

ROAD TEST

< BASIC INSPECTION >

[CVT: RE0F10B]

Is engine started?

- YES >> Stop "Road Test". Refer to [TM-202, "Symptom Table"](#).
NO >> GO TO 3.

3.CHECK "P" POSITION FUNCTION

1. Move selector lever to "P" position.
2. Turn ignition switch OFF.
3. Release parking brake.
4. Push vehicle forward or backward.
5. Apply parking brake.

Does vehicle move forward or backward?

- YES >> Refer to [TM-202, "Symptom Table"](#). Continue "Road Test".
NO >> GO TO 4.

4.CHECK "N" POSITION FUNCTION

1. Start engine.
2. Move selector lever to "N" position.
3. Release parking brake.

Does vehicle move forward or backward?

- YES >> Refer to [TM-202, "Symptom Table"](#). Continue "Road Test".
NO >> GO TO 5.

5.CHECK SHIFT SHOCK

1. Apply foot brake.
2. Move selector lever to "R" position.

Is there large shock when changing from "N" to "R" position?

- YES >> Refer to [TM-202, "Symptom Table"](#). Continue "Road Test".
NO >> GO TO 6.

6.CHECK "R" POSITION FUNCTION

Release foot brake for several seconds.

Does vehicle creep backward when foot brake is released?

- YES >> GO TO 7.
NO >> Refer to [TM-202, "Symptom Table"](#). Continue "Road Test".

7.CHECK "D" POSITION FUNCTION

Move selector lever to "D" position and check if vehicle creeps forward.

Does vehicle creep forward in all positions?

- YES >> Go to [TM-135, "Cruise Test"](#).
NO >> Stop "Road Test". Refer to [TM-202, "Symptom Table"](#).

Cruise Test

INFOID:000000008274068

1.CHECK VEHICLE SPEED WHEN SHIFTING GEARS — PART 1

1. Drive vehicle for approximately 10 minutes to warm engine oil and CVT fluid up to operating temperature.

CVT fluid operating temperature: 50 – 80°C (122 – 176°F)

2. Park vehicle on flat surface.
3. Move selector lever to "P" position.
4. Start engine.
5. Move selector lever to "D" position.

ROAD TEST

[CVT: RE0F10B]


< BASIC INSPECTION >

6. Accelerate vehicle to 2/8-way throttle depressing accelerator pedal constantly.

Read vehicle speed and engine speed. Refer to [TM-255, "Shift Characteristics"](#).

OK or NG

- OK >> GO TO 2.
NG >> Refer to [TM-202, "Symptom Table"](#). Continue "Road Test".




2. CHECK VEHICLE SPEED WHEN SHIFTING GEARS — PART 2

1. Park vehicle on flat surface.
2. Move selector lever to "D" position.
3. Accelerate vehicle to full depression depressing accelerator pedal constantly.

Read vehicle speed and engine speed. Refer to [TM-255, "Shift Characteristics"](#).

OK or NG

- OK >> GO TO 3.
NG >> Refer to [TM-202, "Symptom Table"](#). Continue "Road Test".



3. CHECK MANUAL MODE FUNCTION

Move to manual mode from "D" position.

Does it switch to manual mode?

- YES >> GO TO 4.
NO >> Refer to [TM-202, "Symptom Table"](#). Continue "Road Test".

4. CHECK SHIFT-UP FUNCTION

During manual mode driving, is upshift from M1 → M2 → M3 → M4 → M5 → M6 performed?

Read the gear position. Refer to [TM-103, "CONSULT Function"](#).

Is upshifting correctly performed?

- YES >> GO TO 5.
NO >> Refer to [TM-202, "Symptom Table"](#). Continue "Road Test".

5. CHECK SHIFT-DOWN FUNCTION

During manual mode driving, is downshift from M6 → M5 → M4 → M3 → M2 → M1 performed?

Read the gear position. Refer to [TM-103, "CONSULT Function"](#).

Is downshifting correctly performed?

- YES >> GO TO 6.
NO >> Refer to [TM-202, "Symptom Table"](#). Continue "Road Test".

6. CHECK ENGINE BRAKE FUNCTION

Check engine brake.

Does engine braking effectively reduce speed in M1 position?

- YES >> 1. Stop the vehicle.
2. Perform self-diagnosis. Refer to [TM-103, "CONSULT Function"](#).
NO >> Refer to [TM-202, "Symptom Table"](#). Then continue trouble diagnosis.


CVT POSITION

Inspection and Adjustment

INFOID:000000008274069


INSPECTION

1. Place selector lever in "P" position, and turn ignition switch ON (engine stop).
2. Make sure that selector lever can be shifted to other than "P" position when brake pedal is depressed. Also make sure that selector lever can be shifted from "P" position only when brake pedal is depressed.
3. Move the selector lever and check for excessive effort, sticking, noise or rattle.
4. Confirm the selector lever stops at each position with the feel of engagement when it is moved through all the positions. Check that the actual position of the selector lever matches the position shown by the shift position indicator and the manual lever on the transaxle.
5. The method of operating the selector lever to individual positions correctly should be as shown.
6. When selector button is pressed in "P", "R" or "N" position without applying forward/backward force to selector lever, check button operation for sticking.
7. Confirm the back-up lamps illuminate only when selector lever is placed in the "R" position. Confirm the back-up lamps do not illuminate when the selector lever is pushed toward the "R" position when in the "P" or "N" position.
8. Confirm the engine can only be started with the selector lever in the "P" and "N" positions.
9. Make sure transaxle is locked completely in "P" position.
10. When selector lever is set to manual shift gate, make sure that manual mode is displayed on combination meter.
Shift selector lever to "+" and "-" sides, and check that set shift position changes.



ADJUSTMENT

1. Place selector lever in "P" position.
CAUTION:
Turn wheels more than 1/4 rotations and apply the park lock.
2. Loosen nut (A) and place manual lever (B) in "P" position.
CAUTION:
Never apply any force to the manual lever.
3. Tighten nut. Refer to [TM-219, "Removal and Installation"](#).
CAUTION:
Fix the manual lever when tightening.



U0100 LOST COMMUNICATION (ECM A)

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

DTC/CIRCUIT DIAGNOSIS

U0100 LOST COMMUNICATION (ECM A)

DTC Logic

INFOID:000000008831856

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
U0100	Lost Communication With ECM/PCM A	When the ignition switch is ON, TCM is unable to receive the CAN communications signal from ECM continuously for 2 seconds or more.	<ul style="list-style-type: none">• ECM• Harness or connector (CAN communication line is open or shorted)

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Start the engine and wait for at least 5 seconds.
2. Check the first trip DTC.

Is "U0100" detected?

- YES >> Go to [TM-138, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008831857

For the diagnosis procedure, refer to [LAN-15, "Trouble Diagnosis Flow Chart"](#).

U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

U1000 CAN COMM CIRCUIT

Description

INFOID:000000008274070

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent malfunction detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H and CAN-L) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

DTC Logic

INFOID:000000008274071

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
U1000	CAN Communication Line	When the ignition switch is ON, TCM cannot send the CAN communication signal continuously for 2 seconds or more.	Harness or connector (CAN communication line is open or shorted)

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

With CONSULT

1. Start the engine and wait for at least 5 seconds.
2. Run engine for at least 2 consecutive seconds at idle speed.
3. Select "Self Diagnostic Results" in "TRANSMISSION".

Is "U1000" detected?

- YES >> Go to [TM-139, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008274072

For the diagnosis procedure, refer to [LAN-15, "Trouble Diagnosis Flow Chart"](#).

U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

U1010 CONTROL UNIT (CAN)

Description

INFOID:000000008274073

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent malfunction detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H and CAN-L) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

DTC Logic

INFOID:000000008274074

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
U1010	TCM Communication Malfunction	When detecting error during the initial diagnosis of CAN controller to TCM.	TCM

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

With CONSULT

1. Start the engine.
2. Run engine for at least 6 consecutive seconds at idle speed.
3. Select "Self Diagnostic Results" in "TRANSMISSION".

With GST

Follow the procedure "With CONSULT".

Is "U1010" detected?

- YES >> Go to [TM-140, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008274075

1. CHECK INTERMITTENT INCIDENT

Refer to [GI-43, "Intermittent Incident"](#).

Is the inspection result normal?

- YES >> Replace the TCM. Refer to [TM-226, "Removal and Installation"](#).
NO >> Repair or replace damaged parts.

P0703 BRAKE SWITCH B

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

P0703 BRAKE SWITCH B

Description

INFOID:000000008274076

BCM detects ON/OFF state of the stop lamp switch and transmits the data to the CVT control unit via CAN communication by converting the data to a signal.

DTC Logic

INFOID:000000008274077

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P0703	Brake Switch B Circuit	<ul style="list-style-type: none"> • TCM detects malfunction in CAN communication between BCM. • TCM detects a state that ON/OFF of stop lamp switch signal is not switched. 	<ul style="list-style-type: none"> • Harness or connectors <ul style="list-style-type: none"> - (Stop lamp switch, and BCM circuit are open or shorted.) - (CAN communication line is open or shorted.) • Stop lamp switch • BCM

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

With CONSULT

1. Start the engine.
2. Select "Data Monitor" in "TRANSMISSION".
3. Select "VEHICLE SPEED".
4. Drive the vehicle.
5. Maintain the following condition for 10 seconds or more.

VEHICLE SPEED : 30 km/h (19 MPH)

6. Stop the vehicle.
7. Select "Self Diagnostic Results" in "TRANSMISSION".

Is "P0703" detected?

- YES >> Go to [TM-141, "Diagnosis Procedure"](#).
- NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008274078

1. CHECK STOP LAMP SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch connector.
3. Check voltage between stop lamp switch harness connector terminal and ground.

+		-	Voltage
Connector	Terminal		
E102	1	Ground	Battery voltage

Is the inspection result normal?

< DTC/CIRCUIT DIAGNOSIS >

- YES >> GO TO 2.
- NO >> GO TO 6.

2.CHECK CIRCUIT BETWEEN STOP LAMP SWITCH AND BCM (PART 1)

1. Disconnect BCM connector.
2. Check continuity between stop lamp switch harness connector terminal and BCM harness connector terminal.

Without intelligent key system

Stop lamp switch		BCM		Continuity
Connector	Terminal	Connector	Terminal	
E102	2	M65	9	Existed

With intelligent key system

Stop lamp switch		BCM		Continuity
Connector	Terminal	Connector	Terminal	
E102	2	M68	9	Existed

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace damaged parts.

3.CHECK CIRCUIT BETWEEN STOP LAMP SWITCH AND BCM (PART 2)

Check short circuit in harness between stop lamp switch harness connector terminal 2 and BCM harness connector terminal 9.

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair or replace damaged parts.

4.CHECK INSTALLATION POSITION OF STOP LAMP SWITCH

Check stop lamp switch mounting position. Refer to [BR-7, "Inspection and Adjustment"](#).

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Adjust stop lamp switch mounting position.

5.CHECK STOP LAMP SWITCH

Check stop lamp switch. Refer to [TM-142, "Component Inspection \(Stop Lamp Switch\)"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).
- NO >> Repair or replace stop lamp switch.

6.DETECT MALFUNCTIONING ITEM

Check the following items:

- Open circuit or short circuit in harness between battery and stop lamp switch connector terminal 1. Refer to [PG-11, "Wiring Diagram - BATTERY POWER SUPPLY -"](#).
- Battery
- 10A fuse [No.38, located in fuse block (J/B)]. Refer to [PG-31, "Fuse, Connector and Terminal Arrangement"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).
- NO >> Repair or replace damaged parts.

Component Inspection (Stop Lamp Switch)

INFOID:000000008274079

1.CHECK STOP LAMP SWITCH

Check continuity between stop lamp switch connector terminals.

P0703 BRAKE SWITCH B

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

Stop lamp switch Terminal	Condition	Continuity
1 - 2	Depressed brake pedal	Existed
	Released brake pedal	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace the stop lamp switch. Refer to [BR-18. "Exploded View"](#).

A

B

C

TM

E

F

G

H

I

J

K

L

M

N

O

P

P0705 TRANSMISSION RANGE SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

P0705 TRANSMISSION RANGE SENSOR A

DTC Logic

INFOID:000000008274080

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P0705	Transmission Range Sensor A Circuit (PRNDL Input)	<ul style="list-style-type: none">Range signal is not input to TCM.2 or more position signals are input to TCM.	<ul style="list-style-type: none">Harness or connectors (Transmission range switches circuit is open or shorted.)Transmission range switch

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. PREPARATION BEFORE WORK (PART 2)

Perform function check of combination meter. Refer to [MWI-19. "On Board Diagnosis Function"](#).

>> GO TO 3.

3. PERFORM FUNCTION CHECK

NOTE:

DTC cannot be identified through this inspection.

- Turn ignition switch ON.
- Check that the shift position indicator on the combination meter is displayed correctly when the selector lever is shifted to each position ("P", "R", "N", "D").

Is the check result normal?

- YES >> Go to [TM-144, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008274081

1. CHECK TRANSMISSION RANGE SWITCH POWER CIRCUIT

- Turn ignition switch OFF.
- Disconnect transmission range switch connector.
- Turn ignition switch ON.
- Check voltage between transmission range switch harness connector terminal and ground.

+		-	Condition	Voltage
Connector	Terminal			
F27	3	Ground	Ignition switch: ON	10 – 16 V
			Ignition switch: OFF	Approx. 0 V

Is the check result normal?

- YES >> GO TO 2.
NO >> GO TO 6.

2. CHECK HARNESS BETWEEN TCM AND TRANSMISSION RANGE SWITCH (PART 1)

- Turn ignition switch OFF.

P0705 TRANSMISSION RANGE SENSOR A

[CVT: RE0F10B]

< DTC/CIRCUIT DIAGNOSIS >

2. Disconnect TCM connector.
3. Check continuity between TCM harness connector terminals and transmission range switch harness connector terminals.

TCM		Transmission range switch		Continuity
Connector	Terminal	Connector	Terminal	
F81	1	F27	5	Existed
	2		6	
	3		7	
	11		4	

Is the check result normal?

- YES >> GO TO 3.
 NO >> Repair or replace damaged parts.

3.CHECK HARNESS BETWEEN TCM AND TRANSMISSION RANGE SWITCH (PART 2)

Check continuity between TCM harness connector terminals and ground.

TCM		—	Continuity
Connector	Terminal		
F81	1	Ground	Not existed
	2		
	3		
	11		

Is the check result normal?

- YES >> GO TO 4.
 NO >> Repair or replace damaged parts.

4.CHECK TRANSMISSION RANGE SWITCH MOUNTING POSITION

1. Remove control cable from manual lever. Refer to [TM-218, "Exploded View"](#).
2. Check transmission range switch mounting position. Refer to [TM-224, "Inspection and Adjustment"](#).

Is the check result normal?

- YES >> GO TO 5.
 NO >> Adjust transmission range switch mounting position.

5.CHECK TRANSMISSION RANGE SWITCH

1. Install control cable to manual lever. Refer to [TM-218, "Exploded View"](#).
2. Check transmission range switch. Refer to [TM-146, "Component Inspection \(Transmission Range Switch\)"](#).

Is the check result normal?

- YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).
 NO >> Replace transmission range switch.

6.CHECK HARNESS BETWEEN TRANSMISSION RANGE SWITCH AND IPDM E/R

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between transmission range switch harness connector terminal and IPDM E/R harness connector terminal.

IPDM E/R		Transmission range switch		Continuity
Connector	Terminal	Connector	Terminal	
E15	57	F27	3	Existed

Is the check result normal?

- YES >> GO TO 7.

P0705 TRANSMISSION RANGE SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

NO >> Repair or replace damaged parts.

7. DETECT MALFUNCTIONING ITEM

Check the following items:

- Open circuit or short circuit in harness between ignition switch and IPDM E/R. Refer to [PG-23. "Wiring Diagram - IGNITION POWER SUPPLY -"](#).
- Short circuit in harness between IPDM E/R harness connector terminal 57 and transmission range switch harness connector terminal 5.
- 10A fuse (No.55, IPDM E/R). Refer to [PG-33. "Fuse, Connector and Terminal Arrangement"](#).
- IPDM E/R

Is the check result normal?

YES >> Check intermittent incident. Refer to [GI-43. "Intermittent Incident"](#).

NO >> Repair or replace damaged parts.

Component Inspection (Transmission Range Switch)

INFOID:000000008274082

1. CHECK TRANSMISSION RANGE SWITCH

Check continuity between transmission range switch connector terminals.

Transmission range switch Terminal	Condition	Continuity
1 – 2	Manual lever: "P" and "N" position	Existed
	Other than the above	Not existed
3 – 4	Manual lever: "P" position	Existed
	Other than the above	Not existed
3 – 5	Manual lever: "R" position	Existed
	Other than the above	Not existed
3 – 6	Manual lever: "N" position	Existed
	Other than the above	Not existed
3 – 7	Manual lever: "D" position	Existed
	Other than the above	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace transmission range switch. Refer to [TM-224. "Removal and Installation"](#).

P0710 TRANSMISSION FLUID TEMPERATURE SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

P0710 TRANSMISSION FLUID TEMPERATURE SENSOR A

DTC Logic

INFOID:000000008274083

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P0710	Transmission Fluid Temperature Sensor A Circuit	<ul style="list-style-type: none"> Detected value from CVT fluid temperature sensor received by TCM is less than 20°C (68°F) for a certain length of time. CVT Fluid temperature sensor value that TCM receives is more than 180°C (356°F). 	<ul style="list-style-type: none"> Harness or connectors (Sensor circuit is open or shorted.) CVT fluid temperature sensor
		A/T fluid temperature does not rise to the specified temperature after driving for a certain period of time with the TCM-received fluid temperature sensor value between -40°C (-40°F) and 20°C (68°F).	<ul style="list-style-type: none"> Harness or connectors (Sensor circuit is stuck.) A/T fluid temperature sensor
		The following conditions are maintained for 5 minutes after the completion of engine diagnosis P0111, P0116, and P0196: <ul style="list-style-type: none"> A/T fluid temperature – Engine coolant temperature > 53°C (127°F) A/T fluid temperature – Engine coolant temperature < -27°C (-16.6°F) 	A/T fluid temperature sensor

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

1. PREPARATION BEFORE WORK (PART 1)

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. PREPARATION BEFORE WORK (PART 2)

With CONSULT

- Turn ignition switch ON.
- Select "Data Monitor" in "TRANSMISSION".
- Select "ATF TEMP SEN".

Is the value of "ATF TEMP SEN" within 2.03 – 0.16 V?

YES >> INSPECTION END

NO-1 ("ATF TEMP SEN" indicates 0.15 or less) >> Go to [TM-148. "Diagnosis Procedure"](#).

NO-2 ("ATF TEMP SEN" indicates 2.04 or more) >> GO TO 3.

3. CHECK DTC DETECTION

With CONSULT

- Start the engine.
- Select "Data Monitor" in "TRANSMISSION".
- Select "RANGE", "ACC PEDAL OPEN" and "VEHICLE SPEED".
- Drive the vehicle.
- Maintain the following conditions for at least 14 minutes (Total).

RANGE	: "D" position
ACC PEDAL OPEN	: 1.0/8 or more
VEHICLE SPEED	: 10 km/h (7 MPH) or more

- Stop the vehicle.
- Select "Self Diagnostic Results" in "TRANSMISSION".

P0710 TRANSMISSION FLUID TEMPERATURE SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

With GST

Follow the procedure "With CONSULT".

Is "P0710" detected?

- YES >> Go to [TM-148, "Diagnosis Procedure"](#).
- NO >> GO TO 4.

4. CHECK CVT FLUID TEMPERATURE SENSOR

1. Turn ignition switch OFF.
2. Disconnect CVT unit connector.
3. Check resistance between CVT unit connector terminals.

CVT unit		Condition	Resistance
Connector	Terminal		
F209	17 - 19	CVT fluid temperature: 20°C (68°F)	Approx. 6.83 – 6.29 kΩ
		CVT fluid temperature: 50°C (122°F)	Approx. 2.25 – 2.10 kΩ
		CVT fluid temperature: 80°C (176°F)	Approx. 0.90 – 0.85 kΩ

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> There is a malfunction of the CVT fluid temperature sensor. Replace the control valve. Refer to [TM-228, "Removal and Installation"](#).

Diagnosis Procedure

INFOID:000000008274084

1. CHECK CVT FLUID TEMPERATURE SENSOR

1. Turn ignition switch OFF.
2. Disconnect CVT unit connector.
3. Check resistance between CVT unit connector terminals.

CVT unit		Condition	Resistance
Connector	Terminal		
F209	17 - 19	CVT fluid temperature: 20°C (68°F)	Approx. 6.83 – 6.29 kΩ
		CVT fluid temperature: 50°C (122°F)	Approx. 2.25 – 2.10 kΩ
		CVT fluid temperature: 80°C (176°F)	Approx. 0.90 – 0.85 kΩ

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> GO TO 4.

2. CHECK CIRCUIT BETWEEN TCM AND CVT UNIT (CVT FLUID TEMPERATURE SENSOR) (PART 1)

1. Disconnect the TCM connector.
2. Check continuity between TCM harness connector terminals and CVT unit harness connector terminals.

TCM		CVT unit		Continuity
Connector	Terminal	Connector	Terminal	
F81	13	F51	17	Existed
	25		19	

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace damaged parts.

3. CHECK CIRCUIT BETWEEN TCM AND CVT UNIT (CVT FLUID TEMPERATURE SENSOR) (PART 2)

Check continuity between TCM harness connector terminals and ground.

P0710 TRANSMISSION FLUID TEMPERATURE SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

TCM		Ground	Continuity
Connector	Terminal		
F81	13	Ground	Not existed
	25		

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).
 NO >> Repair or replace damaged parts.

4. CHECK TERMINAL CORD ASSEMBLY (PART 1)

- Remove terminal cord assembly. Refer to [TM-228, "Exploded View"](#).
- Check continuity between CVT unit harness connector terminals and control valve harness connector terminals.

CVT unit		Control valve		Continuity
Connector	Terminal	Connector	Terminal	
F209	17	F208	22	Existed
	19		21	

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> Repair or replace damaged parts.

5. CHECK TERMINAL CORD ASSEMBLY (PART 2)

Check terminal cord assembly harness cladding for damage.

Is the inspection result normal?

- YES >> GO TO 6.
 NO >> Repair or replace damaged parts.

6. CHECK DTC (TCM)

 **With CONSULT**

- Perform "DTC CONFIRMATION PROCEDURE". Refer to [TM-147, "DTC Logic"](#).
- Select "Self Diagnostic Results" in "TRANSMISSION".

Is "P0710" detected?

- YES-1 ("P0710" only)>>There is a malfunction of the CVT fluid temperature sensor. Replace the control valve. Refer to [TM-228, "Removal and Installation"](#).
 YES-2 ("P0710" and other DTC)>>Replace the transaxle assembly. Refer to [TM-245, "2WD : Removal and Installation"](#) (2WD) or [TM-249, "AWD : Removal and Installation"](#) (AWD).
 NO >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

P0715 INPUT SPEED SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

P0715 INPUT SPEED SENSOR A

DTC Logic

INFOID:000000008274085

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P0715	Input/Turbine Speed Sensor A Circuit	<ul style="list-style-type: none"> Primary speed signal is not input to TCM Primary pulley speed sensor value is less than 150 rpm while secondary pulley speed is 500 rpm or more 	<ul style="list-style-type: none"> Harness or connectors (Sensor circuit is open or shorted.) Primary speed sensor

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

With CONSULT

- Start the engine.
- Select "Data Monitor" in "TRANSMISSION".
- Select "SEC SPEED" and "VEHICLE SPEED".
- Drive the vehicle.
- Maintain the following conditions for 5 seconds or more.

SEC SPEED	: 500 rpm or more
VEHICLE SPEED	: 10 km/h (7 MPH) or more

- Stop the vehicle.
- Select "Self Diagnostic Results" in "TRANSMISSION".

With GST

Follow the procedure "With CONSULT".

Is "P0715" detected?

- YES >> Go to [TM-150, "Diagnosis Procedure"](#).
- NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008274086

1. CHECK PRIMARY SPEED SENSOR POWER SUPPLY CIRCUIT

- Turn ignition switch OFF.
- Disconnect primary speed sensor connector.
- Turn ignition switch ON.
- Check voltage between primary speed sensor harness connector terminal and ground.

+		-	Voltage
Connector	Terminal		
F55	3	Ground	10 V – 16 V

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> GO TO 5.


P0715 INPUT SPEED SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

2. CHECK TCM INPUT SIGNAL

1. Turn ignition switch OFF.
2. Connect primary speed sensor connector.
3. Lift up the vehicle.
4. Start the engine.
5. Check frequency of primary speed sensor.

TCM			Condition	Frequency (Approx.)
Connector	+	-		
	Terminal			
F81	33	25	<ul style="list-style-type: none"> • Selector lever: "M1" position • Vehicle speed: 20 km/h (12 MPH) 	<p>720 Hz</p>  <p style="text-align: right; font-size: small;">JPDIA0819ZZ</p>

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).
 NO >> GO TO 3.

3. CHECK CIRCUIT BETWEEN TCM AND PRIMARY SPEED SENSOR (PART 1)

1. Turn ignition switch OFF.
2. Disconnect TCM connector and primary speed sensor connector.
3. Check continuity between TCM harness connector terminals and primary speed sensor harness connector terminals.

TCM		Primary speed sensor		Continuity
Connector	Terminal	Connector	Terminal	
F81	25	F55	1	Existed
	33		2	

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair or replace damaged parts.

4. CHECK CIRCUIT BETWEEN TCM AND PRIMARY SPEED SENSOR (PART 2)

Check continuity between TCM harness connector terminals and ground.

TCM		—	Continuity
Connector	Terminal		
F81	25	Ground	Not existed
	33		

Is the inspection result normal?

- YES >> Replace primary speed sensor. Refer to [TM-235, "Removal and Installation"](#).
 NO >> Repair or replace damaged parts.

5. CHECK CIRCUIT BETWEEN PRIMARY SPEED SENSOR AND IPDM E/R

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between primary speed sensor harness connector terminal and IPDM E/R harness connector terminal.

P0715 INPUT SPEED SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

Primary speed sensor		IPDM E/R		Continuity
Connector	Terminal	Connector	Terminal	
F55	3	E15	57	Existed

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace damaged parts.

6. DETECT MALFUNCTIONING ITEM

Check the following items:

- Open circuit or short circuit in harness between ignition switch and IPDM E/R. Refer to [PG-23. "Wiring Diagram - IGNITION POWER SUPPLY -"](#).
- Short circuit in harness between IPDM E/R harness connector terminal 57 and primary speed sensor harness connector terminal 3.
- 10A fuse (No.55, located in IPDM E/R). Refer to [PG-33. "Fuse, Connector and Terminal Arrangement"](#).
- IPDM E/R

Is the check result normal?

YES >> Check intermittent incident. Refer to [GI-43. "Intermittent Incident"](#).

NO >> Repair or replace damaged parts.

P0720 OUTPUT SPEED SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

P0720 OUTPUT SPEED SENSOR

DTC Logic

INFOID:000000008274087

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P0720	Output Speed Sensor Circuit	<ul style="list-style-type: none"> Secondary speed sensor signal is not input to TCM. Secondary pulley speed sensor value is less than 150 rpm while primary pulley speed is 1,000 rpm or more. 	<ul style="list-style-type: none"> Harness or connectors (Sensor circuit is open or shorted.) Output speed sensor

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

With CONSULT

- Start the engine.
- Select "Data Monitor" in "TRANSMISSION".
- Select "PRI SPEED" and "VEHICLE SPEED".
- Drive the vehicle.
- Maintain the following conditions for 5 seconds or more.

PRI SPEED	: 1,000 rpm or more
VEHICLE SPEED	: 10 km/h (7 MPH) or more

- Stop the vehicle.
- Select "Self Diagnostic Results" in "TRANSMISSION".

With GST

Follow the procedure "With CONSULT".

Is "P0720" detected?

- YES >> Go to [TM-153, "Diagnosis Procedure"](#).
- NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008274088

1. CHECK SECONDARY SPEED SENSOR POWER SUPPLY CIRCUIT

- Turn ignition switch OFF.
- Disconnect secondary speed sensor connector.
- Turn ignition switch ON.
- Check voltage between secondary speed sensor harness connector terminal and ground.

+		-	Voltage
Connector	Terminal		
F19	3	Ground	10 V – 16 V

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> GO TO 5.


P0720 OUTPUT SPEED SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

2. CHECK TCM INPUT SIGNAL

1. Turn ignition switch OFF.
2. Connect secondary speed sensor connector.
3. Lift up the vehicle.
4. Start the engine.
5. Check frequency of secondary speed sensor.

TCM			Condition	Frequency (Approx.)
Connector	+	-		
	Terminal			
F81	34	25	<ul style="list-style-type: none"> • Selector lever: "M1" position • Vehicle speed: 20 km/h (12 MPH) 	<p>480 Hz</p>  <p>JPDIA0901ZZ</p>

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-43. "Intermittent Incident"](#).
 NO >> GO TO 3.

3. CHECK CIRCUIT BETWEEN TCM AND SECONDARY SPEED SENSOR (PART 1)

1. Turn ignition switch OFF.
2. Disconnect TCM connector and secondary speed sensor connector.
3. Check continuity between TCM harness connector terminals and secondary speed sensor harness connector terminals.

TCM		Secondary speed sensor		Continuity
Connector	Terminal	Connector	Terminal	
F81	25	F19	1	Existed
	34		2	

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair or replace damaged parts.

4. CHECK CIRCUIT BETWEEN TCM AND SECONDARY SPEED SENSOR (PART 2)

Check continuity between TCM harness connector terminals and ground.

TCM		—	Continuity
Connector	Terminal		
F81	25	Ground	Not existed
	34		

Is the inspection result normal?

- YES >> Replace secondary speed sensor. Refer to [TM-235. "Removal and Installation"](#).
 NO >> Repair or replace damaged parts.

5. CHECK CIRCUIT BETWEEN SECONDARY SPEED SENSOR AND IPDM E/R

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between secondary speed sensor harness connector terminal and IPDM E/R harness connector terminal.

P0720 OUTPUT SPEED SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

Secondary speed sensor		IPDM E/R		Continuity
Connector	Terminal	Connector	Terminal	
F19	3	E15	57	Existed

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace damaged parts.

6. DETECT MALFUNCTIONING ITEM

Check the following items:

- Open circuit or short circuit in harness between ignition switch and IPDM E/R. Refer to [PG-23. "Wiring Diagram - IGNITION POWER SUPPLY -"](#).
- Short circuit in harness between IPDM E/R harness connector terminal 57 and secondary speed sensor harness connector terminal 3.
- 10A fuse (No.55, located in IPDM E/R). Refer to [PG-33. "Fuse, Connector and Terminal Arrangement"](#).
- IPDM E/R

Is the check result normal?

YES >> Check intermittent incident. Refer to [GI-43. "Intermittent Incident"](#).

NO >> Repair or replace damaged parts.

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

P0725 ENGINE SPEED

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

P0725 ENGINE SPEED

Description

INFOID:000000008274089

The engine speed signal is transmitted from ECM to TCM by CAN communication line.

DTC Logic

INFOID:000000008274090

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P0725	Engine Speed Input Circuit	<ul style="list-style-type: none">TCM detects a malfunction of CAN communication between ECM.A DTC is set if the engine speed (CAN communication) is less than 450 rpm when the primary pulley speed is 1,000 rpm or more.	<ul style="list-style-type: none">Harness or connectors (The ECM to the TCM circuit is open or shorted.)ECM

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

With CONSULT

- Start the engine.
- Select "Data Monitor" in "TRANSMISSION".
- Select "PRI SPEED".
- Drive the vehicle.
- Maintain the following condition for 10 seconds or more.

PRI SPEED : 1,000 rpm or more

- Stop the vehicle.
- Select "Self Diagnostic Results" in "TRANSMISSION".

Is "P0725" detected?

- YES >> Go to [TM-156, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008274091

1. CHECK DTC (ECM)

With CONSULT

- Turn ignition switch ON.
- Select "Self Diagnostic Results" in "ENGINE".

Is any DTC detected?

- YES >> Check DTC detected item. Refer to [EC-102, "DTC Index"](#).
NO >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

P0740 TORQUE CONVERTER

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

P0740 TORQUE CONVERTER

DTC Logic

INFOID:000000008274092

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P0740	Torque Converter Clutch Circuit/Open	<ul style="list-style-type: none">• TCM monitor voltage value for torque converter clutch solenoid valve is less than 70% of target voltage value for torque converter clutch solenoid valve.• There is a large difference between TCM monitor current command value for torque converter clutch solenoid valve and current monitor value for torque converter clutch solenoid valve.	<ul style="list-style-type: none">• Harness or connectors (Solenoid circuit is open or shorted.)• Torque converter clutch solenoid valve

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

1. PREPARATION BEFORE WORK (PART 1)

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. PREPARATION BEFORE WORK (PART 2)

With CONSULT

1. Start the engine.
2. Select "Data Monitor" in "TRANSMISSION".
3. Select "ATF TEMP SEN".

Is the value of "ATF TEMP SEN" 2.17 V or less?

YES >> GO TO 3.

- NO >> 1. Warm the transaxle.
2. GO TO 3.

3. CHECK DTC DETECTION

With CONSULT

1. Start the engine.
2. Select "Data Monitor" in "TRANSMISSION".
3. Select "VEHICLE SPEED".
4. Drive the vehicle.
5. Maintain the following condition for 5 seconds or more.

VEHICLE SPEED : 40 km/h (25 MPH) or more

6. Stop the vehicle.
7. Select "Self Diagnostic Results" in "TRANSMISSION".

With GST

Follow the procedure "With CONSULT".

Is "P0740" detected?

YES >> Go to [TM-157, "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008274093

1. CHECK TORQUE CONVERTER CLUTCH SOLENOID VALVE

1. Turn ignition switch OFF.

P0740 TORQUE CONVERTER

[CVT: RE0F10B]

< DTC/CIRCUIT DIAGNOSIS >

2. Disconnect CVT unit connector.
3. Check continuity between CVT unit harness connector terminal and ground.

CVT unit		Ground	Condition	Resistance
Connector	Terminal			
F209	12	Ground	CVT fluid temperature: 20°C (68°F)	Approx. 5.60 – 6.60 Ω
			CVT fluid temperature: 50°C (122°F)	Approx. 6.76 – 6.87 Ω
			CVT fluid temperature: 80°C (176°F)	Approx. 7.47 – 7.59 Ω

Is the inspection result normal?

- YES >> GO TO 2.
NO >> GO TO 4.

2. CHECK CIRCUIT BETWEEN TCM AND CVT UNIT (TORQUE CONVERTER CLUTCH SOLENOID VALVE) (PART 1)

1. Disconnect TCM harness connector.
2. Check continuity between TCM harness connector terminal and CVT unit harness connector terminal.

TCM		CVT unit		Continuity
Connector	Terminal	Connector	Terminal	
F81	38	F51	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace damaged parts.

3. CHECK CIRCUIT BETWEEN TCM AND CVT UNIT (TORQUE CONVERTER CLUTCH SOLENOID VALVE) (PART 2)

Check continuity between TCM harness connector terminal and ground.

TCM		Ground	Continuity
Connector	Terminal		
F81	38	Ground	Not existed

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).
NO >> Repair or replace damaged parts.

4. CHECK TERMINAL CORD ASSEMBLY (PART 1)

1. Remove terminal cord assembly. Refer to [TM-228, "Exploded View"](#).
2. Check continuity between CVT unit harness connector terminals and control valve harness connector terminals.

CVT unit		Control valve		Continuity
Connector	Terminal	Connector	Terminal	
F209	12	F208	10	Existed

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Repair or replace damaged parts.

5. CHECK TERMINAL CORD ASSEMBLY (PART 2)

Check terminal cord assembly harness cladding for damage.

Is the inspection result normal?

- YES >> GO TO 6.
NO >> Repair or replace damaged parts.

P0740 TORQUE CONVERTER

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

6. CHECK DTC (TCM)

With CONSULT

1. Perform "DTC CONFIRMATION PROCEDURE". Refer to [TM-157, "DTC Logic"](#).
2. Select "Self Diagnostic Results" in "TRANSMISSION".

Is "P0740" detected?

YES-1 (Only "P0740" is detected)>>There is a malfunction of the torque converter clutch solenoid valve.
Replace the control valve. Refer to [TM-228, "Removal and Installation"](#).

YES-2 ("P0740" and other than "P0740" are detected)>>Replace the transaxle assembly. Refer to [TM-245, "2WD : Removal and Installation"](#) (2WD) or [TM-249, "AWD : Removal and Installation"](#) (AWD).

NO >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

P0744 TORQUE CONVERTER

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

P0744 TORQUE CONVERTER

Description

INFOID:000000008274094

This malfunction is detected when the torque converter clutch does not lock-up as instructed by the TCM. This is not only caused by electrical malfunction (circuits open or shorted), but also by mechanical malfunction such as control valve sticking, improper solenoid valve operation, etc.

DTC Logic

INFOID:000000008274095

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P0744	Torque Converter Clutch Circuit Intermittent	Torque converter slip speed is more than a certain value (40 rpm + Vehicle speed × 0.8) while TCM is in lock-up command state	<ul style="list-style-type: none">Hydraulic control circuitTorque converter clutch solenoid valveLock-up select solenoid valve

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

With CONSULT

- Start the engine.
- Select "Data Monitor" in "TRANSMISSION".
- Select "RANGE", "ATF TEMP SEN", "ACC PEDAL OPEN" and "VEHICLE SPEED".
- Drive the vehicle.
- Maintain the following condition for 30 seconds or more.

RANGE	: D position
ATF TEMP SEN	: 2.03 V or less
ACC PEDAL OPEN	: 0.0/8 – 1.0/8
VEHICLE SPEED	: 40 km/h (25 MPH)

- Stop the vehicle.
- Select "Self Diagnostic Results" in "TRANSMISSION".

With GST

Follow the procedure "With CONSULT".

Is "P0744" detected?

- YES >> Go to [TM-160, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008274096

1. CHECK LINE PRESSURE

Perform line pressure test. Refer to [TM-132, "Inspection and Judgment"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace damaged parts. Refer to [TM-132, "Inspection and Judgment"](#).

2. CHECK TORQUE CONVERTER CLUTCH SOLENOID VALVE

Check torque converter clutch solenoid valve. Refer to [TM-157, "DTC Logic"](#).

P0744 TORQUE CONVERTER

[CVT: RE0F10B]

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 6.

3.CHECK LOCK-UP SELECT SOLENOID VALVE

Check lock-up select solenoid valve. Refer to [TM-190, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace damaged parts.

4.CHECK PRIMARY SPEED SENSOR SYSTEM

Check primary speed sensor system. Refer to [TM-150, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace damaged parts.

5.CHECK SECONDARY SPEED SENSOR SYSTEM

Check secondary speed sensor system. Refer to [TM-153, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace damaged parts.

6.CHECK DTC (TCM)

With CONSULT

1. Perform "DTC CONFIRMATION PROCEDURE". Refer to [TM-160, "DTC Logic"](#).

2. Select "Self Diagnostic Results" in "TRANSMISSION".

Is "P0744" detected?

YES-1 (Only "P0744" is detected)>>There is a malfunction of the torque converter clutch solenoid valve.
Replace the control valve. Refer to [TM-228, "Removal and Installation"](#).

YES-2 ("P0744" and other than "P0744" are detected)>>Replace the transaxle assembly. Refer to [TM-245, "2WD : Removal and Installation"](#) (2WD) or [TM-249, "AWD : Removal and Installation"](#) (AWD).

NO >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

P0745 PRESSURE CONTROL SOLENOID A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

P0745 PRESSURE CONTROL SOLENOID A

DTC Logic

INFOID:000000008274097

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P0745	Pressure Control Solenoid A	<ul style="list-style-type: none">TCM monitor voltage value for torque converter clutch solenoid valve is less than 70% of target voltage value for torque converter clutch solenoid valve.There is a large difference between TCM current monitor command value for line pressure solenoid valve and current monitor value for line pressure solenoid valve.	<ul style="list-style-type: none">Harness or connectors (Solenoid circuit is open or shorted.)Line pressure solenoid valve

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

With CONSULT

- Start the engine.
- Drive the vehicle for 10 seconds or more.
- Stop the vehicle.
- Select "Self Diagnostic Results" in "TRANSMISSION".

With GST

Follow the procedure "With CONSULT".

Is "P0745" detected?

YES >> Go to [TM-162, "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008274098

1. CHECK LINE PRESSURE SOLENOID VALVE

- Turn ignition switch OFF.
- Disconnect CVT unit connector.
- Check resistance between CVT unit connector terminal and ground.

CVT unit		Ground	Condition	Resistance
Connector	Terminal			
F209	2	Ground	CVT fluid temperature: 20°C (68°F)	Approx. 5.60 – 6.60 Ω
			CVT fluid temperature: 50°C (122°F)	Approx. 6.76 – 6.87 Ω
			CVT fluid temperature: 80°C (176°F)	Approx. 7.47 – 7.59 Ω

Is the inspection result normal?

YES >> GO TO 2.

NO >> GO TO 4.

2. CHECK CIRCUIT BETWEEN TCM AND LINE PRESSURE SOLENOID VALVE (PART 1)

- Disconnect TCM connector.
- Check continuity between TCM harness connector terminal and CVT unit harness connector terminal.

P0745 PRESSURE CONTROL SOLENOID A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

TCM		CVT unit		Continuity
Connector	Terminal	Connector	Terminal	
F81	40	F51	2	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace damaged parts.

3. CHECK CIRCUIT BETWEEN TCM AND LINE PRESSURE SOLENOID VALVE (PART 2)

Check continuity between TCM harness connector terminal and ground.

TCM		Ground	Continuity
Connector	Terminal		
F81	40	Ground	Not existed

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> Repair or replace damaged parts.

4. CHECK TERMINAL CORD ASSEMBLY (PART 1)

1. Remove terminal cord assembly. Refer to [TM-228, "Exploded View"](#).
2. Check continuity between CVT unit harness connector terminal and control valve harness connector terminal.

CVT unit		Control valve		Continuity
Connector	Terminal	Connector	Terminal	
F209	2	F208	8	Existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace damaged parts.

5. CHECK TERMINAL CORD ASSEMBLY (PART 2)

Check terminal cord assembly harness cladding for damage.

Is the inspection result normal?

YES >> Replace the transaxle assembly. Refer to [TM-245, "2WD : Removal and Installation"](#) (2WD) or [TM-249, "AWD : Removal and Installation"](#) (AWD).

NO >> Repair or replace damaged parts.

P0746 PRESSURE CONTROL SOLENOID A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

P0746 PRESSURE CONTROL SOLENOID A

Description

INFOID:000000008274099

The line pressure solenoid valve regulates the oil pump discharge pressure to suit the driving condition in response to a signal sent from the TCM.

DTC Logic

INFOID:000000008274100

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P0746	Pressure Control Solenoid A Performance/Stuck Off	TCM detects a state that gear ratio is more than 2.7	<ul style="list-style-type: none">Line pressure solenoid fluid circuitLine pressure solenoid valvePrimary speed sensorSecondary speed sensor

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

With CONSULT

- Start the engine.
- Select "Data Monitor" in "TRANSMISSION".
- Select "ENG SPEED SIG", "PRI SPEED" and "VEHICLE SPEED".
- Drive the vehicle.
- Maintain the following condition for 1 second or more.

ENG SPEED SIG : 600 rpm or more
PRI SPEED : 500 rpm or more
VEHICLE SPEED : 10 km/h (7 MPH) or more

- Stop the vehicle.
- Select "Self Diagnostic Results" in "TRANSMISSION".

With GST

Follow the procedure "With CONSULT".

Is "P0746" detected?

- YES >> Go to [TM-164, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008274101

1. CHECK LINE PRESSURE

Perform line pressure test. Refer to [TM-132, "Inspection and Judgment"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace damaged parts. Refer to [TM-132, "Inspection and Judgment"](#).

2. CHECK LINE PRESSURE SOLENOID VALVE

Check line pressure solenoid valve. Refer to [TM-162, "DTC Logic"](#).

Is the inspection result normal?

P0746 PRESSURE CONTROL SOLENOID A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

- YES >> GO TO 3.
- NO >> Repair or replace damaged parts.

A

3.CHECK PRIMARY SPEED SENSOR SYSTEM

Check primary speed sensor system. Refer to [TM-150. "DTC Logic"](#).

B

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair or replace damaged parts.

C

4.CHECK SECONDARY SPEED SENSOR SYSTEM

Check secondary speed sensor system. Refer to [TM-153. "DTC Logic"](#).

TM

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Repair or replace damaged parts.

E

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-43. "Intermittent Incident"](#).

Is the inspection result normal?

F

- YES >> Replace transaxle assembly. Refer to [TM-245. "2WD : Removal and Installation"](#) (2WD) or [TM-249. "AWD : Removal and Installation"](#) (AWD).
- NO >> Repair or replace damaged parts.

G

H

I

J

K

L

M

N

O

P

P0776 PRESSURE CONTROL SOLENOID B

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

P0776 PRESSURE CONTROL SOLENOID B

Description

INFOID:000000008274102

The secondary pressure solenoid valve regulates the secondary pressure to suit the driving condition in response to a signal sent from the TCM.

DTC Logic

INFOID:000000008274103

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P0776	Pressure Control Solenoid B Performance/Stuck Off	Difference of secondary pressure target value of TCM and secondary pressure actual value is more than 1.2 MPa	<ul style="list-style-type: none">• Secondary pressure solenoid valve• Secondary pressure sensor• Secondary pressure solenoid valve oil circuit• Line pressure solenoid valve oil circuit

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

With CONSULT

1. Start the engine.
2. Select "Data Monitor" in "TRANSMISSION".
3. Select "RANGE", "VIGN SEN", "ATF TEMP SEN", "ACC PEDAL OPEN" and "VEHICLE SPEED".
4. Drive the vehicle.
5. Maintain the following condition for 5 seconds or more.

RANGE	: "D" position
VING SEN	: 10 V or more
ATF TEMP SEN	: 2.03 – 0.16 V
ACC PEDAL OPEN	: 1.0/8 or more
VEHICLE SPEED	: 10 km/h (7 MPH) or more

6. Stop the vehicle.
7. Select "Self Diagnostic Results" in "TRANSMISSION".

With GST

Follow the procedure "With CONSULT".

Is "P0776" detected?

- YES >> Go to [TM-166. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008274104

1. CHECK LINE PRESSURE

Perform line pressure test. Refer to [TM-132. "Inspection and Judgment"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace damaged parts. Refer to [TM-132. "Inspection and Judgment"](#).

2. CHECK SECONDARY PRESSURE SOLENOID VALVE

P0776 PRESSURE CONTROL SOLENOID B

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

Check secondary pressure solenoid valve. Refer to [TM-168, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace damaged parts.

3.CHECK SECONDARY PRESSURE SENSOR SYSTEM

Check secondary pressure sensor system. Refer to [TM-173, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace damaged parts.

4.CHECK INTERMITTENT INCIDENTE

Refer to [GI-43, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Replace transaxle assembly. Refer to [TM-245, "2WD : Removal and Installation"](#) (2WD) or [TM-249, "AWD : Removal and Installation"](#) (AWD)

NO >> Repair or replace damaged parts.

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

P0778 PRESSURE CONTROL SOLENOID B

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

P0778 PRESSURE CONTROL SOLENOID B

DTC Logic

INFOID:000000008274105

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P0778	Pressure Control Solenoid B Electrical	<ul style="list-style-type: none"> TCM monitor voltage value for torque secondary pressure solenoid valve is less than 70% of target voltage value for secondary pressure solenoid valve. There is a large difference between TCM current monitor command value for secondary pressure solenoid valve and current monitor value for secondary pressure solenoid valve. 	<ul style="list-style-type: none"> Harness or connectors (Sensor circuit is open or shorted.) Secondary pressure solenoid valve

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

With CONSULT

- Start the engine.
- Drive the vehicle for 10 seconds or more.
- Stop the vehicle.
- Select "Self Diagnostic Results" in "TRANSMISSION".

With GST

Follow the procedure "With CONSULT".

Is "P0778" detected?

- YES >> Go to [TM-168, "Diagnosis Procedure"](#).
- NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008274106

1. CHECK SECONDARY PRESSURE SOLENOID VALVE

- Turn ignition switch OFF.
- Disconnect CVT unit connector.
- Check resistance between CVT unit connector terminal and ground.

CVT unit		Ground	Condition	Resistance
Connector	Terminal			
F209	3	Ground	CVT fluid temperature: 20°C (68°F)	Approx. 5.60 – 6.60 Ω
			CVT fluid temperature: 50°C (122°F)	Approx. 6.76 – 6.87 Ω
			CVT fluid temperature: 80°C (176°F)	Approx. 7.47 – 7.59 Ω

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> GO TO 4.

2. CHECK CIRCUIT BETWEEN TCM AND CVT UNIT (SECONDARY PRESSURE SOLENOID VALVE) (PART 1)

P0778 PRESSURE CONTROL SOLENOID B

[CVT: RE0F10B]

< DTC/CIRCUIT DIAGNOSIS >

1. Disconnect TCM connector.
2. Check continuity between TCM harness connector terminal and CVT unit harness connector terminal.

TCM		CVT unit		Continuity
Connector	Terminal	Connector	Terminal	
F81	39	F51	3	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace damaged parts.

3. CHECK CIRCUIT BETWEEN TCM AND CVT UNIT (SECONDARY PRESSURE SOLENOID VALVE) (PART 2)

Check continuity between TCM harness connector terminal and ground.

TCM		Ground	Continuity
Connector	Terminal		
F81	39	Ground	Not existed

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).
NO >> Repair or replace damaged parts.

4. CHECK TERMINAL CORD ASSEMBLY (PART 1)

1. Remove terminal cord assembly. Refer to [TM-228, "Exploded View"](#).
2. Check continuity between CVT unit harness connector terminal and control valve harness connector terminal.

CVT unit		Control valve		Continuity
Connector	Terminal	Connector	Terminal	
F209	3	F208	9	Existed

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Repair or replace damaged parts.

5. CHECK TERMINAL CORD ASSEMBLY (PART 2)

Check terminal cord assembly harness cladding for damage.

Is the inspection result normal?

- YES >> Replace the transaxle assembly. Refer to [TM-245, "2WD : Removal and Installation"](#) (2WD) or [TM-249, "AWD : Removal and Installation"](#) (AWD).
NO >> Repair or replace damaged parts.

P0826 UP AND DOWN SHIFT SW

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

P0826 UP AND DOWN SHIFT SW

DTC Logic

INFOID:000000008274107

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P0826	Up and Down Shift Switch Circuit	When an impossible pattern of switch signals is detected, a malfunction is detected.	<ul style="list-style-type: none">• Manual mode select switch• Manual mode position select switch• Combination meter• Harness or connectors- (Manual mode switch circuit are open or shorted.)- (CAN communication line is open or shorted.)

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION (PART 1)

With CONSULT

1. Start the engine.
2. Shift the selector lever to "D" position and wait for 1 second or more.
3. Select "Self Diagnostic Results" in "TRANSMISSION".

Is "P0826" detected?

YES >> Go to [TM-171, "Diagnosis Procedure"](#).

NO >> GO TO 3.

3. CHECK DTC DETECTION (PART 2)

With CONSULT

1. Shift the selector lever to manual shift gate and wait for 1 second or more.
2. Select "Self Diagnostic Results" in "TRANSMISSION".

Is "P0826" detected?

YES >> Go to [TM-171, "Diagnosis Procedure"](#).

NO >> GO TO 4.

4. CHECK DTC DETECTION (PART 3)

With CONSULT

1. Shift the selector lever to "UP side (+ side)" and wait for 1 second or more.
2. Select "Self Diagnostic Results" in "TRANSMISSION".

Is "P0826" detected?

YES >> Go to [TM-171, "Diagnosis Procedure"](#).

NO >> GO TO 5.

5. CHECK DTC DETECTION (PART 4)

With CONSULT

1. Shift the selector lever to "DOWN side (- side)" and wait for 1 second or more.
2. Select "Self Diagnostic Results" in "TRANSMISSION".

Is "P0826" detected?

YES >> Go to [TM-171, "Diagnosis Procedure"](#).

NO >> INSPECTION END

P0826 UP AND DOWN SHIFT SW

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

INFOID:000000008274108

Diagnosis Procedure

1. CHECK DTC (COMBINATION METER)

Ⓜ With CONSULT

- Turn ignition switch ON.
- Select "Self Diagnostic Results" in "METER/M&A".

Is any DTC detected?

- YES >> Check DTC detected item. Refer to [MWI-31, "DTC Index"](#).
 NO >> GO TO 2.

2. CHECK MANUAL MODE SWITCH POWER SUPPLY CIRCUIT

- Turn ignition switch OFF.
- Disconnect CVT shift selector connector.
- Turn ignition switch ON.
- Check voltage between CVT shift selector harness connector terminal and ground.

+		-	Condition	Voltage (Approx.)
CVT shift selector				
Connector	Terminal			
M57	7	Ground	Ignition switch: ON	12 V
			Ignition switch: OFF	0 V
	8		Ignition switch: ON	12 V
			Ignition switch: OFF	0 V
	9		Ignition switch: ON	12 V
			Ignition switch: OFF	0 V
	11		Ignition switch: ON	12 V
			Ignition switch: OFF	0 V

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 4.

3. CHECK MANUAL MODE SWITCH

- Turn ignition switch OFF.
- Check manual mode switch. Refer to [TM-172, "Component Inspection \(Manual Mode Switch\)"](#).

Is the inspection result normal?

- YES >> GO TO 6.
 NO >> Repair or replace damaged parts.

4. CHECK CIRCUIT BETWEEN CVT SHIFT SELECTOR AND COMBINATION METER (PART 1)

- Turn ignition switch OFF.
- Disconnect combination meter connector.
- Check continuity between CVT shift selector harness connector terminals and combination meter harness connector terminals.

CVT shift selector		Combination meter		Continuity
Connector	Terminal	Connector	Terminal	
M57	7	M34	36	Existed
	8		16	
	9		14	
	11		37	

Is the inspection result normal?

- YES >> GO TO 5.

P0826 UP AND DOWN SHIFT SW

[CVT: RE0F10B]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair or replace damaged parts.

5.CHECK CIRCUIT BETWEEN CVT SHIFT SELECTOR AND COMBINATION METER (PART 2)

Check continuity between CVT shift selector harness connector terminals and ground.

CVT shift selector		—	Continuity
Connector	Terminal		
M57	7	Ground	Not existed
	8		
	9		
	11		

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> Repair or replace damaged parts.

6.CHECK GROUND CIRCUIT

Check continuity between CVT shift selector harness connector terminal and ground.

CVT shift selector		—	Continuity
Connector	Terminal		
M57	10	Ground	Existed

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> Repair or replace damaged parts.

Component Inspection (Manual Mode Switch)

INFOID:000000008274109

MANUAL MODE SWITCH

1.MANUAL MODE SWITCH

Check continuity between CVT shift selector connector terminals.

CVT shift selector Terminal	Condition	Continuity
7 – 10	Manual shift gate position (neutral)	Existed
	Other than the above	Not existed
8 – 10	Selector lever: DOWN (– side)	Existed
	Other than the above	Not existed
9 – 10	Selector lever: UP (+ side)	Existed
	Other than the above	Not existed
11 – 10	Manual shift gate position	Not existed
	Other than the above	Existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> There is a malfunction of the manual mode switch. Replace the CVT shift selector assembly.
Refer to [TM-215, "Removal and Installation"](#).

P0840 TRANSMISSION FLUID PRESSURE SEN/SW A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

P0840 TRANSMISSION FLUID PRESSURE SEN/SW A

DTC Logic

INFOID:000000008274110

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P0840	Transmission Fluid Pressure Sensor/Switch A Circuit	<ul style="list-style-type: none"> Secondary pressure sensor voltage that TCM receives is more than 4.7 V Secondary pressure sensor voltage that TCM receives is less than 0.9 V 	<ul style="list-style-type: none"> Harness or connectors (Secondary pressure sensor circuit is open or shorted.) Secondary pressure sensor

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

With CONSULT

- Start the engine.
- Select "Data Monitor" in "TRANSMISSION".
- Select "ATF TEMP SEN".
- Maintain the following condition for 5 seconds or more.

ATF TEMP SEN : 2.41 V or less

- Select "Self Diagnostic Results" in "TRANSMISSION".

With GST

Follow the procedure "With CONSULT".

Is "P0840" detected?

YES >> Go to [TM-173. "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008274111

1. CHECK TCM INPUT SIGNAL

- Start the engine.
- Check voltage between TCM connector terminals.

Connector	TCM		Condition	Voltage (Approx.)
	+	-		
Terminal				
F81	15	25	<ul style="list-style-type: none"> Selector lever : "N" position At idle 	1.0 V

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43. "Intermittent Incident"](#).

NO >> GO TO 2.

2. CHECK SENSOR POWER AND SENSOR GROUND

Check voltage between TCM connector terminals.

P0840 TRANSMISSION FLUID PRESSURE SEN/SW A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

TCM			Condition	Voltage (Approx.)
Connector	+	-		
	Terminal			
F81	26	25	Ignition switch: ON	5.0 V
			Ignition switch: OFF	0 V

Is the inspection result normal?

YES >> GO TO 3.

NO >> Go to [TM-180, "Diagnosis Procedure"](#).

3. CHECK CIRCUIT BETWEEN TCM AND CVT UNIT (SECONDARY PRESSURE SENSOR) (PART 1)

1. Turn ignition switch OFF.
2. Disconnect TCM connector and CVT unit connector.
3. Check continuity between TCM harness connector terminals and CVT unit harness connector terminals.

TCM		CVT unit		Continuity
Connector	Terminal	Connector	Terminal	
F81	15	F51	23	Existed
	25		19	
	26		20	

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace damaged parts.

4. CHECK CIRCUIT BETWEEN TCM AND CVT UNIT (SECONDARY PRESSURE SENSOR) (PART 2)

Check continuity between TCM harness connector terminals and ground.

TCM		—	Continuity
Connector	Terminal		
F81	15	Ground	Not existed
	25		
	26		

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace damaged parts.

5. CHECK TERMINAL CORD ASSEMBLY (PART 1)

1. Remove terminal cord assembly. Refer to [TM-228, "Exploded View"](#).
2. Check continuity between CVT unit harness connector terminals and control valve harness connector terminals.

CVT unit		Control valve		Continuity
Connector	Terminal	Connector	Terminal	
F209	19	F208	21	Existed
	20		19	
	23		20	

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace damaged parts.

6. CHECK TERMINAL CORD ASSEMBLY (PART 2)

P0840 TRANSMISSION FLUID PRESSURE SEN/SW A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

Check terminal cord assembly harness cladding for damage.

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace damaged parts.

7. CHECK DTC (TCM)

With CONSULT

1. Perform "DTC CONFIRMATION PROCEDURE". Refer to [TM-173, "DTC Logic"](#).

2. Select "Self Diagnostic Results" in "TRANSMISSION".

Is "P0840" detected?

YES-1 (Only "P0840" is detected)>>There is a malfunction of the secondary pressure sensor. Replace the control valve. Refer to [TM-228, "Removal and Installation"](#).

YES-2 ("P0840" and other than "P0840" are detected)>>Replace the transaxle assembly. Refer to [TM-245, "2WD : Removal and Installation"](#) (2WD) or [TM-249, "AWD : Removal and Installation"](#) (AWD).

NO >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

P0841 TRANSMISSION FLUID PRESSURE SEN/SW A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

P0841 TRANSMISSION FLUID PRESSURE SEN/SW A

Description

INFOID:000000008274112

Using the engine load (throttle position), the primary pulley revolution speed, and the secondary pulley revolution speed as input signal, TCM changes the operating pressure of the primary pulley and the secondary pulley and changes the groove width of the pulley to control the gear ratio.

DTC Logic

INFOID:000000008274113

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P0841	Transmission Fluid Pressure Sensor/Switch A Circuit Range/Performance	Secondary pressure sensor value exceeds line pressure value	<ul style="list-style-type: none">• Harness or connectors (Sensor circuit is open or shorted.)• Secondary pressure sensor

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

With CONSULT

1. Start the engine.
2. Select "Data Monitor" in "TRANSMISSION".
3. Select "VEHICLE SPEED".
4. Drive the vehicle.
5. Maintain the following condition for 5 seconds or more.

VEHICLE SPEED : 30 km/h (19 MPH) or more

6. Stop the vehicle.
7. Select "Self Diagnostic Results" in "TRANSMISSION".

Is "P0841" detected?

- YES >> Go to [TM-176, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008274114

1. CHECK LINE PRESSURE

Perform line pressure test. Refer to [TM-132, "Inspection and Judgment"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace damaged parts. Refer to [TM-132, "Inspection and Judgment"](#).

2. CHECK SECONDARY PRESSURE SENSOR SYSTEM

Check secondary pressure sensor system. Refer to [TM-173, "DTC Logic"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace damaged parts.

3. CHECK LINE PRESSURE SOLENOID VALVE

Check line pressure solenoid valve. Refer to [TM-162, "DTC Logic"](#).

P0841 TRANSMISSION FLUID PRESSURE SEN/SW A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace damaged parts.

4.CHECK SECONDARY PRESSURE SOLENOID VALVE

Check secondary pressure solenoid valve. Refer to [TM-168, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace damaged parts.

5.CHECK STEP MOTOR SYSTEM

Check step motor system. Refer to [TM-192, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace damaged parts.

6.CHECK INTERMITTENT INCIDENT

Refer to [GI-43, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Replace the transaxle assembly. Refer to [TM-245, "2WD : Removal and Installation"](#) (2WD) or [TM-249, "AWD : Removal and Installation"](#) (AWD).

NO >> Repair or replace damaged parts.

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

P0868 TRANSMISSION FLUID PRESSURE

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

P0868 TRANSMISSION FLUID PRESSURE

Description

INFOID:000000008274115

The secondary pressure solenoid valve regulates the secondary pressure to suit the driving condition in response to a signal sent from the TCM.

DTC Logic

INFOID:000000008274116

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P0868	Transmission Fluid Pressure Low	Secondary pressure is abnormally low compared with the target secondary pressure during ordinary driving.	<ul style="list-style-type: none">• Harness or connectors (Sensor circuit is open or shorted.)• Line pressure control system• Secondary pressure solenoid valve system• Secondary pressure sensor

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

Ⓟ With CONSULT

1. Start the engine.
2. Select "Data Monitor" in "TRANSMISSION".
3. Select "RANGE", "ATF TEMP SEN", "ACC PEDAL OPEN", "BRAKE SW" and "VEHICLE SPEED".
4. Drive the vehicle.
5. Maintain the following condition for 30 seconds or more.

RANGE	: "D" position
ATF TEMP SEN	: 2.41 V or less
ACC PEDAL OPEN	: 0.5/8 – 1.0/8
BRAKE SW	: Off
VEHICLE SPEED	: 40 km/h (25 MPH) or more

6. Stop the vehicle.
7. Select "Self Diagnostic Results" in "TRANSMISSION".

Is "P0868" detected?

- YES >> Go to [TM-178, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008274117

1. CHECK LINE PRESSURE

Perform line pressure test. Refer to [TM-132, "Inspection and Judgment"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace damaged parts. Refer to [TM-132, "Inspection and Judgment"](#).

2. CHECK LINE PRESSURE SOLENOID VALVE

Check line pressure solenoid valve. Refer to [TM-162, "DTC Logic"](#).

P0868 TRANSMISSION FLUID PRESSURE

[CVT: RE0F10B]

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace damaged parts.

3.CHECK SECONDARY PRESSURE SOLENOID VALVE

Check secondary pressure solenoid valve. Refer to [TM-168, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace damaged parts.

4.CHECK SECONDARY PRESSURE SENSOR SYSTEM

Check secondary pressure sensor system. Refer to [TM-173, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace damaged parts.

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-43, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Replace the transaxle assembly. Refer to [TM-245, "2WD : Removal and Installation"](#) (2WD) or [TM-249, "AWD : Removal and Installation"](#) (AWD).

NO >> Repair or replace damaged parts.

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

P1701 TCM

Description

INFOID:000000008274118

When the power supply to the TCM is cut OFF, for example because the battery is removed, and the self-diagnosis memory function stops, malfunction is detected.

CAUTION:

Immediately after TCM is replaced or after control valve or transaxle assembly is replaced (after TCM initialization is complete), self-diagnosis result of "P1701" may be displayed. In this case, erase self-diagnosis result using CONSULT. After erasing self-diagnosis result, perform DTC P1701 reproduction procedure and check that malfunction is not detected.

DTC Logic

INFOID:000000008274119

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P1701	Power Supply Circuit	Power supply (backup) of TCM is not supplied and learning function stops	<ul style="list-style-type: none"> Harness or connectors (TCM power supply circuit is open or shorted.)

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

 With CONSULT

1. Start the engine.
2. Run engine for 10 seconds or more at idle speed.
3. Drive the vehicle for 10 seconds or more.
4. Select "Data Monitor" in "TRANSMISSION".
5. Stop the vehicle.
6. Turn ignition switch OFF and wait for 2 seconds or more.
7. Start the engine.
8. Select "Self Diagnostic Results" in "TRANSMISSION".

Is "P1701" detected?

- YES >> Go to [TM-180, "Diagnosis Procedure"](#).
- NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008274120

1. CHECK TCM POWER SUPPLY CIRCUIT (PART 1)

1. Turn ignition switch OFF.
2. Disconnect TCM connector.
3. Turn ignition switch ON.
4. Check voltage between TCM harness connector terminals and ground.

< DTC/CIRCUIT DIAGNOSIS >

+		-	Condition	Voltage
TCM				
Connector	Terminal			
F81	46	Ground	Ignition switch: ON	10 V – 16 V
			Ignition switch: OFF	Approx. 0 V
	48		Ignition switch: ON	10 V – 16 V
			Ignition switch: OFF	Approx. 0 V

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> GO TO 3.

2. CHECK TCM POWER SUPPLY CIRCUIT (PART 2)

1. Turn ignition switch OFF.
2. Check voltage between TCM harness connector terminal and ground.

+		-	Voltage
TCM			
Connector	Terminal		
F81	47	Ground	10 V – 16 V

Is the inspection result normal?

- YES >> GO TO 6.
- NO >> GO TO 5.

3. CHECK CIRCUIT BETWEEN TCM AND IPDM E/R

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between TCM harness connector terminals and IPDM E/R harness connector terminal.

TCM		IPDM E/R		Continuity
Connector	Terminal	Connector	Terminal	
F81	46	E15	57	Existed
	48			

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair or replace damaged parts.

4. DETECT MALFUNCTIONING ITEM

Check the following:

- Open circuit or short circuit in harness between ignition switch and IPDM E/R. Refer to [PG-23, "Wiring Diagram - IGNITION POWER SUPPLY -"](#).
- Short circuit in harness between IPDM E/R harness connector terminal 57 and TCM harness connector terminal 46, and 48.
- 10A fuse (No. 55, located in IPDM E/R). Refer to [PG-33, "Fuse, Connector and Terminal Arrangement"](#).
- IPDM E/R
- Ignition switch

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).
- NO >> Repair or replace damaged parts.

5. DETECT MALFUNCTIONING ITEM

Check the following:

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

P1701 TCM

[CVT: RE0F10B]

< DTC/CIRCUIT DIAGNOSIS >

- Open circuit or short circuit in harness between battery and TCM harness connector terminal 47. Refer to [PG-11, "Wiring Diagram - BATTERY POWER SUPPLY -"](#).
- 10A fuse (No. 33, located in fuse and fusible link block). Refer to [PG-32, "Fuse and Fusible Link Arrangement"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> Repair or replace damaged parts.

6. CHECK CIRCUIT BETWEEN TCM AND GROUND

Check continuity between TCM harness connector terminals and ground.

TCM		—	Continuity
Connector	Terminal		
F81	5	Ground	Existed
	42		

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> Repair or replace damaged parts.

P1705 TP SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

P1705 TP SENSOR

Description

INFOID:000000008274121

Electric throttle control actuator consists of throttle control motor, accelerator pedal position sensor, throttle position sensor etc. The actuator sends a signal to the ECM, and ECM sends the signal to TCM with CAN communication.

DTC Logic

INFOID:000000008274122

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P1705	Accelerator Pedal Position Sensor Signal Circuit	TCM detects that difference between the 2 accelerator pedal position signals (CAN communication) from ECM is 1/8 or more	<ul style="list-style-type: none">• Harness or connectors (CAN communication line is open or shorted.) (Accelerator pedal position sensor circuit is open or shorted.)• ECM

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

With CONSULT

1. Start the engine.
2. Apply the parking brake.
3. Depress the accelerator pedal gradually.
4. Release your foot from the accelerator pedal.
5. Select "Self Diagnostic Results" in "TRANSMISSION".

Is "P1705" detected?

- YES >> Go to [TM-183, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008274123

1. CHECK DTC (ECM)

With CONSULT

1. Turn ignition switch ON.
2. Select "Self Diagnostic results" in "ENGINE".

Is any DTC detected?

- YES >> Check DTC detected item. Refer to [EC-102, "DTC Index"](#).
NO >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

P1709 INCOMPLETED DATA WRITING

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

P1709 INCOMPLETED DATA WRITING

Description

INFOID:000000008274124

When TCM does not store calibration data (individual characteristic value) of each solenoid valve that is stored in the ROM assembly (in the control valve), a malfunction is detected.

CAUTION:

Immediately after TCM is replaced or after control valve or transaxle assembly is replaced (after TCM initialization is complete), self-diagnosis result of "P1709" may be displayed. In this case, erase self-diagnosis result using CONSULT. After erasing self-diagnosis result, perform DTC P1701 reproduction procedure and check that malfunction is not detected.

DTC Logic

INFOID:000000008274125

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC is detected if...	Possible cause
P1709	Incompleted Data Writing	When TCM does not store calibration data (individual characteristic value) of each solenoid valve that is stored in the ROM assembly (in the control valve).	<ul style="list-style-type: none">• Harness or connectors (ROM assembly circuit is open or shorted.)• TCM• ROM assembly (in the control valve)

DTC CONFIRMATION PROCEDURE

NOTE:

Immediately after performing any "DTC CONFIRMATION PROCEDURE", always turn ignition switch OFF. Then wait at least 10 seconds before performing the next test.

1. CHECK DTC DETECTION

ⓑ With CONSULT

1. Turn ignition switch OFF.
2. Wait for at least 10 consecutive seconds.
3. Turn ignition switch ON.
4. Perform "Self Diagnostic Results" in "TRANSMISSION".

Is "P1709" detected?

- YES >> Go to [TM-184, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008274126

1. CHECK HARNESS BETWEEN TCM AND CVT UNIT HARNESS CONNECTOR (ROM ASSEMBLY) (PART 1)

1. Turn ignition switch OFF.
2. Disconnect TCM connector and CVT unit connector.
3. Check continuity between TCM vehicle side harness connector terminals and CVT unit vehicle side harness connector terminals.

TCM		CVT unit		Continuity
Connector	Terminal	Connector	Terminal	
F81	8	F51	11	Existed
	9		1	
	10		16	
	25		19	
	26		20	

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace damaged parts.

P1709 INCOMPLETED DATA WRITING

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

2. CHECK HARNESS BETWEEN TCM AND CVT UNIT HARNESS CONNECTOR (ROM ASSEMBLY) (PART 2)

Check continuity between TCM vehicle side harness connector terminals and ground.

TCM		—	Continuity
Connector	Terminal		
F81	8	Ground	Not existed
	9		
	10		
	25		
	26		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace damaged parts.

3. CHECK TERMINAL CORD ASSEMBLY

1. Remove terminal cord assembly. Refer to [TM-228, "Exploded View"](#).
2. Check continuity between CVT unit harness terminals and control valve harness connector terminals.

CVT unit		Control valve		Continuity
Connector	Terminal	Connector	Terminal	
F209	1	F207	2	Existed
	11		3	
	16		4	
	19		5	
	20		1	

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace damaged parts.

4. CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [TM-180, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace damaged parts.

5. REPLACE TCM

1. Replace TCM. Refer to [TM-226, "Removal and Installation"](#).
2. Perform "DTC CONFIRMATION PROCEDURE". Refer to [TM-184, "DTC Logic"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace transaxle assembly. Refer to [TM-245, "2WD : Removal and Installation"](#) (2WD) or [TM-245, "2WD : Removal and Installation"](#) (AWD).

P1722 VEHICLE SPEED

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

P1722 VEHICLE SPEED

Description

INFOID:000000008274127

The vehicle speed signal is transmitted from ABS actuator and electric unit (control unit) to TCM by CAN communication line.

DTC Logic

INFOID:000000008274128

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P1722	Vehicle Speed Signal Circuit	<ul style="list-style-type: none">• TCM detects malfunction in CAN communication with ABS actuator and electric unit (control unit).• When vehicle speed that TCM detects is 10 km/h (7 MPH) or more, vehicle speed signal (CAN communication) that is received from ABS actuator and electric unit (control unit) is 2 km/h (2 MPH) or less.• Change of vehicle speed signal (CAN communication) that TCM receives is large	<ul style="list-style-type: none">• Harness or connectors (CAN communication line is open or shorted.) (Vehicle speed signal circuit is open or shorted.)• ABS actuator and electric unit (control unit)

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

Ⓜ With CONSULT

1. Start the engine.
2. Select "Data Monitor" in "TRANSMISSION".
3. Select "VSP SENSOR".
4. Drive the vehicle.
5. Maintain the following condition for 10 seconds or more.

VSP SENSOR : 10 km/h (7 MPH) or more

6. Stop the vehicle.
7. Select "Self Diagnostic Results" in "TRANSMISSION".

Is "P1722" detected?

- YES >> Go to [TM-186, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008274129

1. CHECK DTC [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

Ⓜ With CONSULT

1. Turn ignition switch ON.
2. Select "Self Diagnostic Results" in "ABS".

Is any DTC detected?

- YES >> Check DTC detected item. Refer to [BRC-49, "DTC Index"](#)
NO >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

P1723 SPEED SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

P1723 SPEED SENSOR

Description

INFOID:000000008274130

The secondary speed sensor detects the revolution of parking gear and generates a pulse signal. The pulse signal is sent to the TCM, which converts it into vehicle speed.
The primary speed sensor detects the primary pulley revolution speed and sends a signal to the TCM.

DTC Logic

INFOID:000000008274131

DTC DETECTION LOGIC

CAUTION:

One of the "P0715", or the "P0720" is displayed with the DTC at the same time.

A
B
C
TM

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P1723	Speed Sensor Circuit	TCM detects that high frequency components that are extracted from primary pulley speed and secondary pulley speed exceed a certain value	<ul style="list-style-type: none"> Harness or connectors (Primary speed sensor circuit is open or shorted.) (Secondary speed sensor circuit is open or shorted.)

E
F

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

 **With CONSULT**

- Start the engine.
- Select "Data Monitor" in "TRANSMISSION".
- Select "RANGE" and "VEHICLE SPEED".
- Drive the vehicle.
- Maintain the following condition for 1 second or more.

RANGE	:	"D" position
VEHICLE SPEED	:	20 km/h (13 MPH) or more

- Stop the vehicle.
- Select "Self Diagnostic Results" in "TRANSMISSION".

Is "P1723" detected?

- YES >> Go to [TM-187, "Diagnosis Procedure"](#).
NO >> INSPECTION END

H
I
J
K
L
M
N

Diagnosis Procedure

INFOID:000000008274132

1. CHECK SECONDARY SPEED SENSOR SYSTEM

Check secondary speed sensor system. Refer to [TM-153, "DTC Logic"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace damaged parts.

2. CHECK PRIMARY SPEED SENSOR SYSTEM

Check primary speed sensor system. Refer to [TM-150, "DTC Logic"](#).

Is the inspection result normal?

O
P

P1723 SPEED SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

-
- YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).
NO >> Repair or replace damaged parts.

P1726 THROTTLE CONTROL SIGNAL

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

P1726 THROTTLE CONTROL SIGNAL

Description

INFOID:000000008274133

Electric throttle control actuator consists of throttle control motor, accelerator pedal position sensor, throttle position sensor etc. The actuator sends a signal to the ECM, and ECM sends the signal to TCM with CAN communication.

DTC Logic

INFOID:000000008274134

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P1726	Throttle Control Signal Circuit	TCM receives a malfunction signal of engine system from ECM	Harness or connectors (Electronically controlled throttle sensor signal circuit is open or shorted.)

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

With CONSULT

1. Start the engine.
2. Run engine for at least 10 consecutive seconds at idle speed.
3. Select "Self Diagnostic Results" in "TRANSMISSION".

Is "P1726" detected?

- YES >> Go to [TM-189, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008274135

1. CHECK DTC (ECM)

With CONSULT

1. Turn ignition switch ON.
2. Select "Self Diagnostic Results" in "ENGINE".

Is any DTC detected?

- YES >> Check DTC detected item. Refer to [EC-102, "DTC Index"](#).
NO >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

P1740 SELECT SOLENOID

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

P1740 SELECT SOLENOID

DTC Logic

INFOID:000000008274136

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P1740	Lock-up Select Solenoid Valve Circuit	<ul style="list-style-type: none">• Monitor value for lock-up select solenoid valve is OFF when TCM command value for lock-up select solenoid valve is ON.• Monitor value for lock-up select solenoid valve is ON when TCM command value for lock-up select solenoid valve is OFF.	<ul style="list-style-type: none">• Harness or connectors (Lock-up select solenoid circuit is open or shorted.)• Lock-up select solenoid valve

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION (PART 1)

With CONSULT

1. Start the engine.
2. Select "Data Monitor" in "TRANSMISSION".
3. Select "RANGE".
4. Maintain the following condition for 1 second or more.

RANGE : "P" or "N" position

5. Select "Self Diagnostic Results" in "TRANSMISSION".

With GST

Follow the procedure "With CONSULT".

Is "P1740" detected?

- YES >> Go to [TM-190. "Diagnosis Procedure"](#).
NO >> GO TO 3.

3. CHECK DTC DETECTION (PART 2)

With CONSULT

1. Select "Data Monitor" in "TRANSMISSION".
2. Select "RANGE".
3. Maintain the following condition for 1 second or more.

RANGE : "R" or "D" position

4. Select "Self Diagnostic Results" in "TRANSMISSION".

With GST

Follow the procedure "With CONSULT".

Is "P1740" detected?

- YES >> Go to [TM-190. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008274137

1. CHECK LOCK-UP SELECT SOLENOID VALVE

1. Turn ignition switch OFF.

P1740 SELECT SOLENOID

[CVT: RE0F10B]

< DTC/CIRCUIT DIAGNOSIS >

2. Disconnect CVT unit connector.
3. Check resistance between CVT unit connector terminal and ground.

CVT unit		Ground	Condition	Resistance
Connector	Terminal			
F209	13	Ground	CVT fluid temperature: 20°C (68°F)	Approx. 26.0 – 30.0 Ω
			CVT fluid temperature: 50°C (122°F)	Approx. 29.0 – 34.0 Ω
			CVT fluid temperature: 80°C (176°F)	Approx. 32.0 – 37.0 Ω

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> GO TO 4.

2.CHECK CIRCUIT BETWEEN TCM AND CVT UNIT (LOCK-UP SELECT SOLENOID VALVE) (PART 1)

1. Disconnect TCM connector.
2. Check continuity between TCM harness connector terminal and CVT unit harness connector terminal.

TCM		CVT unit		Continuity
Connector	Terminal	Connector	Terminal	
F81	37	F51	13	Existed

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair or replace damaged parts.

3.CHECK CIRCUIT BETWEEN TCM AND CVT UNIT (LOCK-UP SELECT SOLENOID VALVE) (PART 2)

Check continuity between TCM harness connector terminal and ground.

TCM		Ground	Continuity
Connector	Terminal		
F81	37	Ground	Not existed

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).
 NO >> Repair or replace damaged parts.

4.CHECK TERMINAL CORD ASSEMBLY (PART 1)

1. Remove terminal cord assembly. Refer to [TM-228, "Removal and Installation"](#).
2. Check continuity between CVT unit harness connector terminal and control valve harness connector terminal.

CVT unit		Control valve		Continuity
Connector	Terminal	Connector	Terminal	
F209	13	F208	11	Existed

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> Repair or replace damaged parts.

5.CHECK TERMINAL CORD ASSEMBLY (PART 2)

Check terminal cord assembly harness cladding for damage.

Is the inspection result normal?

- YES >> Replace the transaxle assembly. Refer to [TM-245, "2WD : Removal and Installation"](#) (2WD), [TM-249, "AWD : Removal and Installation"](#) (AWD).
 NO >> Repair or replace damaged parts.

P1777 STEP MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

P1777 STEP MOTOR

DTC Logic

INFOID:000000008274138

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P1777	Step Motor Circuit	<ul style="list-style-type: none"> Step motor monitor value is OFF when step motor command value of TCM is ON Step motor monitor value is ON when step motor command value of TCM is OFF 	<ul style="list-style-type: none"> Harness or connectors (Step motor circuit is open or shorted.) Step motor

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

With CONSULT

- Start the engine.
- Select "Data Monitor" in "TRANSMISSION".
- Select "RANGE" and "VEHICLE SPEED".
- Drive the vehicle.
- Maintain the following condition for 1 second or more.

RANGE	: "D" position
VEHICLE SPEED	: 20 km/h (13 MPH) or more

- Stop the vehicle.
- Select "Self Diagnostic Results" in "TRANSMISSION".

With GST

Follow the procedure "With CONSULT".

Is "P1777" detected?

- YES >> Go to [TM-192, "Diagnosis Procedure"](#).
- NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000008274139

1. CHECK STEP MOTOR CIRCUIT (PART 1)

- Turn ignition switch OFF.
- Disconnect TCM connector.
- Check resistance between TCM harness connector terminals.

TCM		Resistance
Connector	Terminal	
F81	27 – 28	Approx. 30.0 Ω
	29 – 30	

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> GO TO 3.

2. CHECK STEP MOTOR CIRCUIT (PART 2)

P1777 STEP MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

Check resistance between TCM harness connector terminals and ground.

TCM		Ground	Resistance
Connector	Terminal		
F81	27	Ground	Approx. 15.0 Ω
	28		
	29		
	30		

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43. "Intermittent Incident"](#).

NO >> GO TO 3.

3.CHECK STEP MOTOR

1. Disconnect CVT unit connector.
2. Check resistance between CVT unit connector terminals.

CVT unit		Resistance
Connector	Terminal	
F209	6 – 7	Approx. 30.0 Ω
	8 – 9	

3. Check resistance between CVT unit connector terminals and ground.

CVT unit		Ground	Resistance
Connector	Terminal		
F209	6	Ground	Approx. 15.0 Ω
	7		
	8		
	9		

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 6.

4.CHECK CIRCUIT BETWEEN TCM AND CVT UNIT (STEP MOTOR) (PART 1)

Check continuity between TCM harness connector terminals and CVT unit harness connector terminals.

TCM		CVT unit		Continuity
Connector	Terminal	Connector	Terminal	
F81	27	F51	9	Existed
	28		8	
	29		7	
	30		6	

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace damaged parts.

5.CHECK CIRCUIT BETWEEN TCM AND CVT UNIT (STEP MOTOR) (PART 2)

Check continuity between TCM harness connector terminals and ground.

P1777 STEP MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

TCM		Ground	Continuity
Connector	Terminal		
F81	27	Ground	Not existed
	28		
	29		
	30		

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).
 NO >> Repair or replace damaged parts.

6. CHECK TERMINAL CORD ASSEMBLY (PART 1)

- Remove terminal cord assembly. Refer to [TM-228, "Exploded View"](#).
- Check continuity between CVT unit harness connector terminals and control valve harness connector terminals.

CVT unit		Control valve		Continuity
Connector	Terminal	Connector	Terminal	
F209	6	F208	14	Existed
	7		15	
	8		16	
	9		17	

Is the inspection result normal?

- YES >> GO TO 7.
 NO >> Repair or replace damaged parts.

7. CHECK TERMINAL CORD ASSEMBLY (PART 2)

Check terminal cord assembly harness cladding for damage.

Is the inspection result normal?

- YES >> GO TO 8.
 NO >> Repair or replace damaged parts.

8. CHECK DTC (TCM)

With CONSULT

- Perform "DTC CONFIRMATION PROCEDURE". Refer to [TM-192, "DTC Logic"](#).
- Select "Self Diagnostic Results" in "TRANSMISSION".

Is "P1777" detected?

- YES-1 (Only "P1777" is detected)>>There is a malfunction of the step motor. Replace the control valve. Refer to [TM-228, "Removal and Installation"](#).
 YES-2 ("P1777" and "P0725"/"P1777" and "U1000"/"P1777", "P0725" and "U1000" are detected)>>Replace the control valve. Refer to [TM-228, "Removal and Installation"](#).
 YES-3 (Other than YES-1 and YES-2)>>Replace the transaxle assembly. Refer to [TM-245, "2WD : Removal and Installation"](#) (2WD) or [TM-249, "AWD : Removal and Installation"](#) (AWD).
 NO >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

P1778 STEP MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

P1778 STEP MOTOR

Description

INFOID:000000008274140

- The step motor's 4 aspects of ON/OFF change according to the signal from TCM. As a result, the flow of line pressure to primary pulley is changed and pulley ratio is controlled.
- This diagnosis item is detected when electrical system is OK, but mechanical system is NG.
- This diagnosis item is detected when the state of the changing the speed mechanism in unit does not operate normally.

DTC Logic

INFOID:000000008274141

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P1778	Step Motor Circuit Intermittent	There is a large difference between the primary pulley speed sensor value and the primary pulley speed estimated from the secondary speed sensor value, or there is a large difference between the target pulley ratio and actual pulley ratio.	Step motor

DTC CONFIRMATION PROCEDURE

CAUTION:

- Always drive vehicle at a safe speed.
- Before starting "DTC CONFIRMATION PROCEDURE", confirm "Hi" or "Mid" or "Low" fixation by "PRI SPEED" and "VEHICLE SPEED" on "DATA MONITOR MODE".
- If hi-gear fixation occurred, go to [TM-196, "Diagnosis Procedure"](#).

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

With CONSULT

1. Start the engine.
2. Select "Data Monitor" in "TRANSMISSION".
3. Select "RANGE", "ATF TEMP SEN", "ACC PEDAL OPEN", "PRI SPEED" and "VEHICLE SPEED".
4. Drive the vehicle.
5. Maintain the following condition for 5 seconds or more.

RANGE	: "D" position
ATF TEMP SEN	: 2.03 – 0.16 V
ACC PEDAL OPEN	: 1.0/8 or more
PRI SPEED	: 1,000 rpm or more
VEHICLE SPEED	: 10 km/h (7 MPH) or more

6. Stop the vehicle.
7. Select "Self Diagnostic Results" in "TRANSMISSION".

With GST

Follow the procedure "With CONSULT".

Is "P1778" detected?

- YES >> Go to [TM-196, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

1. CHECK STEP MOTOR SYSTEM

Check step motor system. Refer to [TM-192, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace damaged parts. Refer to [TM-132, "Inspection and Judgment"](#).

2. CHECK PRIMARY SPEED SENSOR SYSTEM

Check primary speed sensor system. Refer to [TM-150, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace damaged parts.

3. CHECK SECONDARY SPEED SENSOR SYSTEM

Check secondary speed sensor system. Refer to [TM-153, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace damaged parts.

4. CHECK INTERMITTENT INCIDENT

Refer to [GI-43, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Replace transaxle assembly. Refer to [TM-245, "2WD : Removal and Installation"](#) (2WD) or [TM-249, "AWD : Removal and Installation"](#) (AWD).

NO >> Repair or replace damaged parts.

SHIFT POSITION INDICATOR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

SHIFT POSITION INDICATOR CIRCUIT

Description

INFOID:000000008274143

- TCM sends position indicator signals to combination meter by CAN communication line.
- Manual mode switch position is indicated on shift position indicator.

Component Function Check

INFOID:000000008274144

1. CHECK SHIFT POSITION INDICATOR

CAUTION:

Always drive vehicle at a safe speed.

1. Start engine.
2. Check if correct selector lever position ("P", "N", "R" or "D") is displayed as selector lever is moved into each position.
3. Drive vehicle in the manual mode, and confirm that the actual gear position and the meter's indication of the position mutually coincide when the selector lever is shifted to the "UP (+ side)" or "DOWN (- side)" side [1st ↔ 6th (7th*) gear].
*: For JUKE NISMO

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Go to [TM-197, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008274145

1. CHECK INPUT SIGNALS

With CONSULT

1. Start engine.
2. Check if correct selector lever position ("P", "N", "R" or "D") is displayed as selector lever is moved into each position.
3. Select "RENGE" on "DATA MONITOR" and read out the value.
4. Drive vehicle in the manual mode, and confirm that the actual gear position and the meter's indication of the position mutually coincide when the selector lever is shifted to the "UP (+ side)" or "DOWN (- side)" side [1st ↔ 6th (7th*) gear].
*: For JUKE NISMO

Is the inspection result normal?

- YES >> INSPECTION END
- NO - 1 >> The actual gear position does not change, or shifting into the manual mode is not possible (no gear shifting in the manual mode possible). Or the shift position indicator is not indicated.
- Check manual mode switch. Refer to [TM-172, "Component Inspection \(Manual Mode Switch\)"](#).
 - Check CVT main system (Fail-safe function actuated).
 - Perform "SELF-DIAG RESULTS" mode for "TRANSMISSION". Refer to [TM-103, "CONSULT Function"](#).
- NO - 2 >> The actual gear position changes, but the shift position indicator is not indicated.
- Perform "SELF-DIAG RESULTS" mode for "TRANSMISSION". Refer to [TM-103, "CONSULT Function"](#).
- NO - 3 >> The actual gear position and the indication on the shift position indicator do not coincide.
- Perform "SELF-DIAG RESULTS" mode for "TRANSMISSION". Refer to [TM-103, "CONSULT Function"](#).
- NO - 4 >> Only a specific position or positions is/are not indicated on the shift position indicator.
- Check the combination meter. Refer to [MWI-35, "Work flow"](#).

SHIFT LOCK SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

SHIFT LOCK SYSTEM

Component Function Check

INFOID:000000008274146

1. CHECK SHIFT LOCK OPERATION (PART 1)

1. Turn ignition switch ON.
2. Shift the selector lever to "P" position.
3. Attempt to shift the selector lever to any other than position with the brake pedal released.

Can the selector lever be shifted to any other position?

- YES >> Go to [TM-198, "Diagnosis Procedure"](#).
NO >> GO TO 2.

2. CHECK SHIFT LOCK OPERATION (PART 2)

Attempt to shift the selector lever to any other than position with the brake pedal depressed.

Can the selector lever be shifted to any other position?

- YES >> INSPECTION END
NO >> Go to [TM-198, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008274147

1. CHECK POWER SOURCE

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch connector
3. Turn ignition switch ON.
4. Check the voltage between the stop lamp switch harness connector terminal and ground.

+		-	Voltage
Stop lamp switch			
Connector	Terminal		
E102	3	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 2.
NO >> GO TO 9.

2. CHECK STOP LAMP SWITCH (PART 1)

Check stop lamp switch. Refer to [TM-201, "Component Inspection \(Stop Lamp Switch\)"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 10.

3. CHECK CIRCUIT BETWEEN STOP LAMP SWITCH AND CVT SHIFT SELECTOR (PART 1)

1. Disconnect CVT shift selector connector
2. Check the continuity between the stop lamp switch harness connector terminal and the CVT shift selector harness connector terminal.

Stop lamp switch		CVT shift selector		Continuity
Connector	Terminal	Connector	Terminal	
E102	4	M57	3	Existed

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace the malfunctioning parts.

4. CHECK CIRCUIT BETWEEN STOP LAMP SWITCH AND CVT SHIFT SELECTOR (PART 2)

Check the continuity between the stop lamp switch harness connector terminal and ground.

SHIFT LOCK SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

Stop lamp switch		—	Continuity
Connector	Terminal		
E102	4	Ground	Not existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5.CHECK GROUND CIRCUIT

Check the continuity between the CVT shift selector harness connector terminal and ground.

CVT shift selector		—	Continuity
Connector	Terminal		
M57	4	Ground	Existed

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the malfunctioning parts.

6.CHECK PART POSITION SWITCH

1. Disconnect park position switch connector.
2. Check park position switch. Refer to [TM-200, "Component Inspection \(Park Position Switch\)"](#).

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace the malfunctioning parts.

7.CHECK SHIFT LOCK SOLENOID

1. Disconnect shift lock solenoid connector.
2. Check shift lock solenoid. Refer to [TM-200, "Component Inspection \(Shift Lock Solenoid\)"](#).

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair or replace the malfunctioning parts.

8.CHECK CVT SHIFT SELECTOR HARNESS

Check CVT shift selector harness. Refer to [TM-200, "Component Inspection \(CVT Shift Selector Harness\)"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

9.DETECT MALFUNCTIONING ITEM

Check the following items:

- Open or short circuit in harness between ignition switch and stop lamp switch connector terminal 3. Refer to [PG-23, "Wiring Diagram - IGNITION POWER SUPPLY -"](#).
- Ignition switch
- 10A fuse [No.3, fuse block (J/B)]. Refer to [PG-31, "Fuse, Connector and Terminal Arrangement"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

10.CHECK INSTALLATION POSITION OF STOP LAMP SWITCH

Adjust stop lamp switch position. Refer to [BR-7, "Inspection and Adjustment"](#).

>> GO TO 11.

11.CHECK STOP LAMP SWITCH (PART 2)

Check stop lamp switch. Refer to [TM-201, "Component Inspection \(Stop Lamp Switch\)"](#).

SHIFT LOCK SYSTEM

[CVT: RE0F10B]

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace the malfunctioning parts.

Component Inspection (Shift Lock Solenoid)

INFOID:000000008274148

1.CHECK SHIFT LOCK SOLENOID

Apply voltage to terminals of shift lock solenoid connector and check that shift lock solenoid is activated.

CAUTION:

- Connect the fuse between the terminals when applying the voltage.
- Never cause shorting between terminals.

Shift lock solenoid		Condition	Status
+	-		
Terminal			
1	2	Apply battery voltage between terminals 1 and 2.	Shift lock solenoid operates

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace the shift lock unit. Refer to [TM-216. "Disassembly and Assembly"](#).

Component Inspection (Park Position Switch)

INFOID:000000008274149

1.CHECK PARK POSITION SWITCH

Check the continuity between park position switch connector terminals.

CAUTION:

- Connect the fuse between the terminals when applying the voltage.
- Never cause shorting between terminals.

Park position switch	Condition	Continuity
Terminal		
1 - 2	Shift the selector lever to "P" position.	Existed
	Other than above	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace the park position switch. Refer to [TM-216. "Disassembly and Assembly"](#).

Component Inspection (CVT Shift Selector Harness)

INFOID:000000008274150

1.CHECK CVT SHIFT SELECTOR HARNESS (PART 1)

Check the continuity between the CVT shift selector harness connector terminal and the shift lock solenoid harness connector terminal.

CVT shift selector		Shift lock solenoid		Continuity
Connector	Terminal	Connector	Terminal	
M324	3	M326	1	Existed

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace the CVT shift selector harness. Refer to [TM-216. "Disassembly and Assembly"](#).

2.CHECK CVT SHIFT SELECTOR HARNESS (PART 2)

Check the continuity between the shift lock solenoid harness connector terminal and the park position switch harness connector terminal.

SHIFT LOCK SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10B]

Shift lock solenoid		Park position switch		Continuity
Connector	Terminal	Connector	Terminal	
M326	2	M325	1	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the CVT shift selector harness. Refer to [TM-216, "Disassembly and Assembly"](#).

3.CHECK CVT SHIFT SELECTOR HARNESS (PART 3)

Check the continuity between the park switch harness connector terminal and the CVT shift selector harness connector terminal.

Park switch		CVT shift selector		Continuity
Connector	Terminal	Connector	Terminal	
M325	2	M324	4	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace the CVT shift selector harness. Refer to [TM-216, "Disassembly and Assembly"](#).

4.CHECK CVT SHIFT SELECTOR HARNESS (PART 4)

Check harness cladding CVT shift selector harness for damage.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace the CVT shift selector harness. Refer to [TM-216, "Disassembly and Assembly"](#).

Component Inspection (Stop Lamp Switch)

INFOID:000000008274151

1.CHECK STOP LAMP SWITCH

Check the continuity between the stop lamp switch connector terminals.

Stop lamp switch	Condition	Continuity
Terminal		
3 – 4	Depressed brake pedal	Existed
	Released brake pedal	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace stop lamp switch. Refer to [BR-18, "Exploded View"](#).

SYSTEM SYMPTOM

< SYMPTOM DIAGNOSIS >

[CVT: RE0F10B]

SYMPTOM DIAGNOSIS

SYSTEM SYMPTOM

Symptom Table

INFOID:000000008274152

The diagnostics item numbers show the sequence for inspection. Inspect in order from item 1.

No.	Item	Symptom	Condition	Diagnostic Item	Reference
1	Shift Shock	Large shock. ("N"→ "D" position)	ON vehicle	1. Engine idle speed	EC-125
				2. Engine speed signal	TM-156
				3. Accelerator pedal position sensor	TM-183
				4. CVT position	TM-137
				5. CVT fluid temperature sensor	TM-147
				6. CAN communication line	TM-139
				7. CVT fluid level and state	TM-213
				8. Line pressure test	TM-132
				9. Torque converter clutch solenoid valve	TM-157
				10. Lock-up select solenoid valve	TM-190
				11. Transmission range switch	TM-144
				12. Control valve	TM-228
			OFF vehicle	13. Forward clutch	TM-249
2	Shift Shock	Large shock. ("N"→ "R" position)	ON vehicle	1. Engine idle speed	EC-125
				2. Engine speed signal	TM-156
				3. Accelerator pedal position sensor	TM-183
				4. CVT position	TM-137
				5. CVT fluid temperature sensor	TM-147
				6. CAN communication line	TM-139
				7. CVT fluid level and state	TM-213
				8. Line pressure test	TM-132
				9. Torque converter clutch solenoid valve	TM-157
				10. Lock-up select solenoid valve	TM-190
				11. Transmission range switch	TM-144
				12. Control valve	TM-228
			OFF vehicle	13. Reverse brake	TM-249
3	Shift Shock	Shock is too large for lock-up.	ON vehicle	1. CVT position	TM-137
				2. Engine speed signal	TM-156
				3. CAN communication line	TM-139
				4. CVT fluid level and state	TM-213
				5. Control valve	TM-228
			OFF vehicle	6. Torque converter	TM-253

SYSTEM SYMPTOM

< SYMPTOM DIAGNOSIS >

[CVT: RE0F10B]

No.	Item	Symptom	Condition	Diagnostic Item	Reference
4	Slips/Will Not Engage	Vehicle cannot be started from "D" position.	ON vehicle	1. CVT fluid level and state	TM-213
				2. CVT position	TM-137
				3. CAN communication line	TM-139
				4. Line pressure test	TM-132
				5. Stall test	TM-130
				6. Step motor	TM-192
				7. Primary speed sensor	TM-150
				8. Secondary speed sensor	TM-153
				9. Accelerator pedal position sensor	TM-183
				10. CVT fluid temperature sensor	TM-147
				11. Secondary pressure sensor	TM-173
				12. Power supply	TM-180
				13. Control valve	TM-228
			OFF vehicle	14. Oil pump assembly	TM-249
				15. Forward clutch	
				16. Parking components	
5	Slips/Will Not Engage	Vehicle cannot be started from "R" position.	ON vehicle	1. CVT fluid level and state	TM-213
				2. CVT position	TM-137
				3. CAN communication line	TM-139
				4. Line pressure test	TM-132
				5. Stall test	TM-130
				6. Step motor	TM-192
				7. Primary speed sensor	TM-150
				8. Secondary speed sensor	TM-153
				9. Accelerator pedal position sensor	TM-183
				10. CVT fluid temperature sensor	TM-147
				11. Secondary pressure sensor	TM-173
				12. Power supply	TM-180
				13. Control valve	TM-228
			OFF vehicle	14. Oil pump assembly	TM-249
				15. Reverse brake	
				16. Parking components	

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

SYSTEM SYMPTOM

< SYMPTOM DIAGNOSIS >

[CVT: RE0F10B]

No.	Item	Symptom	Condition	Diagnostic Item	Reference
6	Slips/Will Not Engage	Does not lock-up.	ON vehicle	1. CVT fluid level and state	TM-213
				2. Line pressure test	TM-132
				3. Engine speed signal	TM-156
				4. Primary speed sensor	TM-150
				5. Torque converter clutch solenoid valve	TM-157
				6. CAN communication line	TM-139
				7. Stall test	TM-130
				8. Step motor	TM-192
				9. Transmission range switch	TM-144
				10. Lock-up select solenoid valve	TM-190
				11. CVT fluid temperature sensor	TM-147
				12. Secondary speed sensor	TM-153
				13. Secondary pressure sensor	TM-173
				14. Control valve	TM-228
			OFF vehicle	15. Torque converter	TM-253
				16. Oil pump assembly	TM-249
7	Slips/Will Not Engage	Does not hold lock-up condition.	ON vehicle	1. CVT fluid level and state	TM-213
				2. Line pressure test	TM-132
				3. Engine speed signal	TM-156
				4. Primary speed sensor	TM-150
				5. Torque converter clutch solenoid valve	TM-157
				6. CAN communication line	TM-139
				7. Stall test	TM-130
				8. Step motor	TM-192
				9. Transmission range switch	TM-144
				10. Lock-up select solenoid valve	TM-190
				11. CVT fluid temperature sensor	TM-147
				12. Secondary speed sensor	TM-153
				13. Secondary pressure sensor	TM-173
				14. Control valve	TM-228
			OFF vehicle	15. Torque converter	TM-253
				16. Oil pump assembly	TM-249

SYSTEM SYMPTOM

< SYMPTOM DIAGNOSIS >

[CVT: RE0F10B]

No.	Item	Symptom	Condition	Diagnostic Item	Reference
8		Lock-up is not released.	ON vehicle	1. CVT fluid level and state	TM-213
				2. Line pressure test	TM-132
				3. Engine speed signal	TM-156
				4. Primary speed sensor	TM-150
				5. Torque converter clutch solenoid valve	TM-157
				6. CAN communication line	TM-139
				7. Stall test	TM-130
				8. Control valve	TM-228
			OFF vehicle	9. Torque converter	TM-253
				10. Oil pump assembly	TM-249
9	Slips/Will Not Engage	With selector lever in "D" position, acceleration is extremely poor.	ON vehicle	1. CVT fluid level and state	TM-213
				2. Line pressure test	TM-132
				3. Stall test	TM-130
				4. Accelerator pedal position sensor	TM-183
				5. CAN communication line	TM-139
				6. Transmission range switch	TM-144
				7. CVT position	TM-137
				8. Step motor	TM-192
				9. Primary speed sensor	TM-150
				10. Secondary speed sensor	TM-153
				11. Accelerator pedal position sensor	TM-183
				12. Secondary pressure sensor	TM-173
				13. CVT fluid temperature sensor	TM-147
				14. Power supply	TM-180
				15. Control valve	TM-228
			OFF vehicle	16. Torque converter	TM-253
				17. Oil pump assembly	TM-249
				18. Forward clutch	

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

SYSTEM SYMPTOM

< SYMPTOM DIAGNOSIS >

[CVT: RE0F10B]

No.	Item	Symptom	Condition	Diagnostic Item	Reference
10	Slips/Will Not Engage	With selector lever in "R" position, acceleration is extremely poor.	ON vehicle	1. CVT fluid level and state	TM-213
				2. Line pressure test	TM-132
				3. Stall test	TM-130
				4. Accelerator pedal position sensor	TM-183
				5. CAN communication line	TM-139
				6. Transmission range switch	TM-144
				7. CVT position	TM-137
				8. Step motor	TM-192
				9. Primary speed sensor	TM-150
				10. Secondary speed sensor	TM-153
				11. Accelerator pedal position sensor	TM-183
				12. Secondary pressure sensor	TM-173
				13. CVT fluid temperature sensor	TM-147
				14. Power supply	TM-180
				15. Control valve	TM-228
			OFF vehicle	16. Torque converter	TM-253
				17. Oil pump assembly	TM-249
				18. Reverse brake	
11	Slips at lock-up.		ON vehicle	1. CVT fluid level and state	TM-213
				2. Line pressure test	TM-132
				3. Engine speed signal	TM-156
				4. Primary speed sensor	TM-150
				5. Torque converter clutch solenoid valve	TM-157
				6. CAN communication line	TM-139
				7. Stall test	TM-130
				8. Step motor	TM-192
				9. Transmission range switch	TM-144
				10. Lock-up select solenoid valve	TM-190
				11. CVT fluid temperature sensor	TM-147
				12. Secondary speed sensor	TM-153
				13. Secondary pressure sensor	TM-173
				14. Control valve	TM-228
			OFF vehicle	15. Torque converter	TM-253
				16. Oil pump assembly	TM-249

SYSTEM SYMPTOM

< SYMPTOM DIAGNOSIS >

[CVT: RE0F10B]

No.	Item	Symptom	Condition	Diagnostic Item	Reference
12	Other	No creep at all.	ON vehicle	1. CVT fluid level and state	TM-213
				2. Line pressure test	TM-132
				3. Accelerator pedal position sensor	TM-183
				4. Transmission range switch	TM-144
				5. CAN communication line	TM-139
				6. Stall test	TM-130
				7. CVT position	TM-137
				8. Step motor	TM-192
				9. Primary speed sensor	TM-150
				10. Secondary speed sensor	TM-153
				11. Accelerator pedal position sensor	TM-183
				12. CVT fluid temperature sensor	TM-147
				13. Secondary pressure sensor	TM-173
				14. Power supply	TM-180
				15. Control valve	TM-228
			OFF vehicle	16. Torque converter	TM-253
				17. Oil pump assembly	TM-249
				18. Gear system	
				19. Forward clutch	
				20. Reverse brake	
13	Other	Vehicle cannot run in all positions.	ON vehicle	1. CVT fluid level and state	TM-213
				2. Line pressure test	TM-132
				3. Transmission range switch	TM-144
				4. Stall test	TM-130
				5. CVT position	TM-137
				6. Step motor	TM-192
				7. Primary speed sensor	TM-150
				8. Secondary speed sensor	TM-153
				9. Accelerator pedal position sensor	TM-183
				10. CVT fluid temperature sensor	TM-147
				11. Secondary pressure sensor	TM-173
				12. Power supply	TM-180
				13. Control valve	TM-228
			OFF vehicle	14. Torque converter	TM-253
				15. Oil pump assembly	TM-249
				16. Gear system	
				17. Forward clutch	
				18. Reverse brake	
				19. Parking components	

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

SYSTEM SYMPTOM

< SYMPTOM DIAGNOSIS >

[CVT: RE0F10B]

No.	Item	Symptom	Condition	Diagnostic Item	Reference
14	Other	With selector lever in "D" position, driving is not possible.	ON vehicle	1. CVT fluid level and state	TM-213
				2. Line pressure test	TM-132
				3. Transmission range switch	TM-144
				4. Stall test	TM-130
				5. CVT position	TM-137
				6. Step motor	TM-192
				7. Primary speed sensor	TM-150
				8. Secondary speed sensor	TM-153
				9. Accelerator pedal position sensor	TM-183
				10. CVT fluid temperature sensor	TM-147
				11. Secondary pressure sensor	TM-173
				12. Power supply	TM-180
				13. Control valve	TM-228
			OFF vehicle	14. Torque converter	TM-253
				15. Oil pump assembly	TM-249
				16. Gear system	
				17. Forward clutch	
				18. Parking components	
15	Other	With selector lever in "R" position, driving is not possible.	ON vehicle	1. CVT fluid level and state	TM-213
				2. Line pressure test	TM-132
				3. Transmission range switch	TM-144
				4. Stall test	TM-130
				5. CVT position	TM-137
				6. Step motor	TM-192
				7. Primary speed sensor	TM-150
				8. Secondary speed sensor	TM-153
				9. Accelerator pedal position sensor	TM-183
				10. CVT fluid temperature sensor	TM-147
				11. Secondary pressure sensor	TM-173
				12. Power supply	TM-180
				13. Control valve	TM-228
			OFF vehicle	14. Torque converter	TM-253
				15. Oil pump assembly	TM-249
				16. Gear system	
				17. Reverse brake	
				18. Parking components	

SYSTEM SYMPTOM

< SYMPTOM DIAGNOSIS >

[CVT: RE0F10B]

No.	Item	Symptom	Condition	Diagnostic Item	Reference
16	Other	Judder occurs during lock-up.	ON vehicle	1. CVT fluid level and state	TM-213
				2. Engine speed signal	TM-156
				3. Primary speed sensor	TM-150
				4. Secondary speed sensor	TM-153
				5. Accelerator pedal position sensor	TM-183
				6. CAN communication line	TM-139
				7. Torque converter clutch solenoid valve	TM-157
				8. Control valve	TM-228
			OFF vehicle	9. Torque converter	TM-253
17	Other	Strange noise in "D" position.	ON vehicle	1. CVT fluid level and state	TM-213
				2. Engine speed signal	TM-156
				3. CAN communication line	TM-139
				4. Control valve	TM-228
			OFF vehicle	5. Torque converter	TM-253
				6. Oil pump assembly	TM-249
				7. Gear system	
				8. Forward clutch	
				9. Bearing	
18	Other	Strange noise in "R" position.	ON vehicle	1. CVT fluid level and state	TM-213
				2. Engine speed signal	TM-156
				3. CAN communication line	TM-139
				4. Control valve	TM-228
			OFF vehicle	5. Torque converter	TM-253
				6. Oil pump assembly	TM-249
				7. Gear system	
				8. Reverse brake	
19	Other	Strange noise in "N" position.	ON vehicle	1. CVT fluid level and state	TM-213
				2. Engine speed signal	TM-156
				3. CAN communication line	TM-139
				4. Control valve	TM-228
			OFF vehicle	5. Torque converter	TM-253
				6. Oil pump assembly	TM-249
				7. Gear system	

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

SYSTEM SYMPTOM

< SYMPTOM DIAGNOSIS >

[CVT: RE0F10B]

No.	Item	Symptom	Condition	Diagnostic Item	Reference
20		Vehicle does not decelerate by engine brake.	ON vehicle	1. CVT fluid level and state	TM-213
				2. CVT position	TM-137
				3. CAN communication line	TM-139
				4. Step motor	TM-192
				5. Primary speed sensor	TM-150
				6. Secondary speed sensor	TM-153
				7. Line pressure test	TM-132
				8. Engine speed signal	TM-156
				9. Accelerator pedal position sensor	TM-183
				10. Control valve	TM-249
21	Other	Maximum speed low.	ON vehicle	1. CVT fluid level and state	TM-213
				2. Line pressure test	TM-132
				3. Accelerator pedal position sensor	TM-183
				4. CAN communication line	TM-139
				5. Stall test	TM-130
				6. Step motor	TM-192
				7. Primary speed sensor	TM-150
				8. Secondary speed sensor	TM-153
				9. Secondary pressure sensor	TM-173
				10. CVT fluid temperature sensor	TM-147
				11. Control valve	TM-228
			OFF vehicle	12. Torque converter	TM-253
				13. Oil pump assembly	TM-249
				14. Gear system	
				15. Forward clutch	
22		With selector lever in "P" position, vehicle does not enter parking condition or, with selector lever in another position, parking condition is not cancelled.	ON vehicle	1. Transmission range switch	TM-144
				2. CVT position	TM-137
			OFF vehicle	3. Parking components	TM-249
				23	
2. CVT fluid level and state	TM-213				
3. CVT position	TM-137				
4. Control valve	TM-228				
OFF vehicle	5. Parking components	TM-249			
	6. Gear system				

SYSTEM SYMPTOM

< SYMPTOM DIAGNOSIS >

[CVT: RE0F10B]

No.	Item	Symptom	Condition	Diagnostic Item	Reference
24	Other	Vehicle runs with CVT in "N" position.	ON vehicle	1. Transmission range switch	TM-144
				2. CVT fluid level and state	TM-213
				3. CVT position	TM-137
				4. Control valve	TM-228
			OFF vehicle	5. Gear system	TM-249
				6. Forward clutch	
				7. Reverse brake	
25	Other	Engine stall.	ON vehicle	1. CVT fluid level and state	TM-213
				2. Engine speed signal	TM-156
				3. Primary speed sensor	TM-150
				4. Torque converter clutch solenoid valve	TM-157
				5. CAN communication line	TM-139
				6. Stall test	TM-130
				7. Secondary pressure sensor	TM-173
				8. Control valve	TM-228
			OFF vehicle	9. Torque converter	TM-253
26	Other	Engine stalls when selector lever shifted "N"→"D" or "R".	ON vehicle	1. CVT fluid level and state	TM-213
				2. Engine speed signal	TM-156
				3. Primary speed sensor	TM-150
				4. Torque converter clutch solenoid valve	TM-157
				5. CAN communication line	TM-139
				6. Stall test	TM-130
				7. Control valve	TM-228
			OFF vehicle	8. Torque converter	TM-253
27	Other	Engine speed does not return to idle.	ON vehicle	1. CVT fluid level and state	TM-213
				2. Accelerator pedal position sensor	TM-183
				3. Secondary speed sensor	TM-153
				4. CAN communication line	TM-139
				5. Control valve	TM-249

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

SYSTEM SYMPTOM

< SYMPTOM DIAGNOSIS >

[CVT: RE0F10B]

No.	Item	Symptom	Condition	Diagnostic Item	Reference
28		CVT does not shift	ON vehicle	1. CVT fluid level and state	TM-213
				2. CVT position	TM-137
				3. Line pressure test	TM-132
				4. Engine speed signal	TM-156
				5. Accelerator pedal position sensor	TM-183
				6. CAN communication line	TM-139
				7. Primary speed sensor	TM-150
				8. Secondary speed sensor	TM-153
				9. Step motor	TM-192
				10. Control valve	TM-228
				OFF vehicle	11. Oil pump assembly
29		Engine does not start in "N" or "P" position.	ON vehicle	1. Ignition switch and starter	PG-23 , STR-22
				2. CVT position	TM-137
				3. Transmission range switch	TM-144
30	Other	Engine starts in positions other than "N" or "P".	ON vehicle	1. Ignition switch and starter	PG-23 , STR-22
				2. CVT position	TM-137
				3. Transmission range switch	TM-144
31		When brake pedal is depressed with ignition switch ON, selector lever cannot be shifted from "P" position to other position.	ON vehicle	1. Stop lamp switch	TM-198
				2. Shift lock solenoid	
				3. CVT shift selector	
32		When brake pedal is not depressed with ignition switch ON, selector lever can be shifted from "P" position to other position.	ON vehicle	1. Stop lamp switch	TM-198
				2. Shift lock solenoid	
				3. CVT shift selector	
33		Cannot be changed to manual mode.	ON vehicle	1. Manual mode switch	TM-170
				2. CAN communication line	TM-139
				3. Combination meters	MWI-42
34		CVT indicator lamp does not come on.	ON vehicle	1. CAN communication line	TM-139
				2. Combination meters	MWI-42
				3. TCM power supply and ground	TM-180

PERIODIC MAINTENANCE

CVT FLUID


Inspection

INFOID:000000008274153


CHECKING CVT FLUID

The fluid level should be checked with the fluid warmed up to 50 to 80°C (122 to 176°F). The fluid level check procedure is as follows:

1. Check for fluid leakage.
2. With the engine warmed up, drive the vehicle in an urban area. When ambient temperature is 20°C (68°F), it takes about 10 minutes for the CVT fluid to warm up to 50 to 80°C (122 to 176°F).
3. Park the vehicle on a level surface.
4. Apply parking brake firmly.
5. With engine at idle, while depressing brake pedal, move shift selector throughout the entire shift range.




6. Pull out the CVT fluid level gauge from the CVT fluid charging pipe after pressing the tab on the CVT fluid level gauge to release the lock.



7. Wipe fluid off the CVT fluid level gauge. Insert the CVT fluid level gauge rotating 180° from the originally installed position, then securely push the CVT fluid level gauge until it meets the top end of the CVT fluid charging pipe.

CAUTION:


When wiping away the CVT fluid level gauge, always use lint-free paper, not a cloth rag.



8. Place the selector lever in "P" or "N" and check that the fluid level is within the specified range.

CAUTION:

When reinstalling CVT fluid level gauge, insert it into the CVT fluid charging pipe and rotate it to the original installation position until securely locked.



CVT FLUID CONDITION


CVT FLUID

< PERIODIC MAINTENANCE >

[CVT: RE0F10B]

Check CVT fluid condition.

- If CVT fluid is very dark or smells burned, check operation of CVT. Flush cooling system after repair of CVT.
- If CVT fluid contains frictional material (clutches, brakes, etc.), replace radiator and flush cooler line using cleaning solvent and compressed air after repair of CVT. Refer to [TM-127, "Cleaning"](#).



Fluid status	Conceivable cause	Required operation
Varnished (viscous varnish state)	CVT fluid become degraded due to high temperatures.	Replace the CVT fluid and check the CVT main unit and the vehicle for malfunctions (wire harnesses, cooler pipes, etc.)
Milky white or cloudy	Water in the fluid	Replace the CVT fluid and check for places where water is getting in.
Large amount of metal powder mixed in	Unusual wear of sliding parts within CVT	Replace the CVT fluid and check for improper operation of the CVT.

Changing

INFOID:000000008274154

CAUTION:

Replace drain plug gasket with new ones at the final stage of the operation when installing.

1. Remove drain plug from oil pan.
2. Remove drain plug gasket from drain plug.
3. Install drain plug gasket to drain plug.

CAUTION:

Never reuse drain plug gasket.

4. Install drain plug to oil pan.

Drain plug – tightening torque : Refer to [TM-228, "Exploded View"](#).

5. Fill CVT fluid from CVT fluid charging pipe to the specified level.

CVT fluid : Refer to [MA-10, "Fluids and Lubricants"](#).

Fluid capacity : Refer to [MA-10, "Fluids and Lubricants"](#).

CAUTION:

- Use only Genuine CVT fluid. Never mix with other fluid.
- Using CVT fluid other than Genuine CVT fluid will deteriorate in driveability and CVT durability, and may damage the CVT, which is not covered by the NISSAN new vehicle limited warranty.
- When filling CVT fluid, take care not to scatter heat generating parts such as exhaust.
- Sufficiently shake the container of CVT fluid before using.
- Delete CVT fluid deterioration date with CONSULT after changing CVT fluid.

6. With the engine warmed up, drive the vehicle in an urban area.

NOTE:

When ambient temperature is 20°C (68°F), it takes about 10 minutes for the CVT fluid to warm up to 50 to 80°C (122 to 176°F).

7. Check CVT fluid level and condition.
8. Repeat steps 1 to 5 if CVT fluid has been contaminated.
9. Select "Data Monitor" in "TRANSMISSION" using CONSULT.
10. Select "CONFORM CVTF DETERIORTN".
11. Select "Erase".

CVT SHIFT SELECTOR

< REMOVAL AND INSTALLATION >


[CVT: RE0F10B]

REMOVAL AND INSTALLATION


CVT SHIFT SELECTOR

Exploded View

INFOID:000000008274155



- | | | |
|------------------------------|--------------------------------|--------------------|
| 1. Selector lever knob | 2. Lock pin | 3. Knob cover |
| 4. Position indication panel | 5. CVT shift selector assembly | 6. Shift lock unit |
| 7. Key interlock rod* | 8. Position indicator bulb | |

 :N·m (kg·m, in·lb)

*: Without push engine starter

Removal and Installation

INFOID:000000008274156

REMOVAL

CAUTION:

Always apply the parking brake before performing removal and installation.

1. Disconnect battery cable from negative terminal. Refer to [PG-96, "Removal and Installation"](#).
2. Shift the selector lever to "N" position.
3. Remove the center console. Refer to [IP-22, "Removal and Installation"](#).
4. Disconnect the CVT shift selector connector.
5. Shift the selector lever to "P" position.
6. Remove the key interlock cable from the CVT shift selector assembly. Refer to [TM-222, "Removal and Installation"](#) (Without push starter system).
7. Remove the control cable from the CVT shift selector assembly. Refer to [TM-219, "Removal and Installation"](#).
8. Remove the CVT shift selector assembly.

INSTALLATION


Note the following, and install in the reverse order of removal.

CVT SHIFT SELECTOR

< REMOVAL AND INSTALLATION >

[CVT: RE0F10B]

- When connecting the control cable (1) to the CVT shift selector assembly (2), face the grooved surface of the rib (A) up and insert the control cable until it stops.




Disassembly and Assembly


INFOID:000000008274157

DISASSEMBLY

- Slide the selector lever knob cover (1) down.
CAUTION:
Never damage the knob cover.
- Pull out the lock pin (2).
- Pull the selector lever knob (3) and knob cover upwards to remove them.
- Remove the position lamp.



- Disengage the hooks (A) (4 locations), and lift up the position indication panel (1) to separate it from the CVT shift selector assembly (2).
CAUTION:
Never damage the CVT shift selector assembly.
- Remove the shift lock unit from the CVT shift selector assembly.
- Disconnect the park position switch connector, detent switch connector, and shift lock solenoid connector from the shift lock unit.



ASSEMBLY


Note the following, and assemble in the reverse order of disassembly.

- Follow the procedure below and place the selector knob onto the CVT shift selector.

- Install the lock pin (2) onto the selector lever knob (3).
- Install the knob cover (1) onto the selector lever knob.
- Press the selector lever knob onto the selector lever until it clicks.

CAUTION:

- When pressing the selector lever knob onto the selector lever, never press the selector lever knob button.
- Never strike the selector lever knob to press it into place.



Inspection

INFOID:000000008274158

INSPECTION AFTER INSTALLATION

- Check the CVT position. If a malfunction is found, adjust the CVT position. Refer to [TM-137, "Inspection and Adjustment"](#).

CVT SHIFT SELECTOR

< REMOVAL AND INSTALLATION >

[CVT: RE0F10B]

- The key can be removed only when the selector lever is in the "P" position. (With key interlock)
- It must not be possible to turn the ignition switch to LOCK when the selector lever is not in the "P" position. (With key interlock)

A

B

C

TM

E

F

G

H

I

J

K

L

M

N

O

P

CONTROL CABLE

< REMOVAL AND INSTALLATION >


[CVT: RE0F10B]

CONTROL CABLE

Exploded View

INFOID:000000008274159

2WD MODELS



- 1. Bracket B
 - 2. Lock plate
 - 3. Bracket A
 - 4. Transaxle assembly
 - 5. Control cable
 - 6. CVT shift selector assembly
- A: Manual lever
- B: Grommet

: N·m (kg-m, ft-lb)


: N·m (kg-m, in-lb)

AWD MODELS

CONTROL CABLE

< REMOVAL AND INSTALLATION >

[CVT: RE0F10B]



- 1. Lock plate
 - 2. Bracket A
 - 3. Transaxle assembly
 - 4. Control cable
 - 5. Bracket B
 - 6. CVT shift selector assembly
- A: Manual lever
B: Grommet

: N·m (kg-m, ft-lb)

: N·m (kg-m, in-lb)

Removal and Installation


INFOID:000000008274160

REMOVAL

CAUTION:

Always apply the parking brake before performing removal and installation.

1. Remove the battery. Refer to [PG-96. "Removal and Installation"](#).
2. Remove the control cable from the CVT shift selector assembly. Refer to [TM-215. "Removal and Installation"](#).
3. Disengage the pawls (B) of the grommet (A), and pull downwards to remove.
4. Remove the control cable installation nut from the manual lever.




CONTROL CABLE

[CVT: RE0F10B]

< REMOVAL AND INSTALLATION >


5. Remove the lock plate (1).
6. Remove center muffler from the mounting rubber and lower the center muffler downward. Refer to [EX-8. "Removal and Installation"](#).
7. Lift up the heat plate.



8. Remove the control cable (1) from the bracket (2).

← :Vehicle front

9. Remove the control cable from the vehicle.
10. Remove bracket.




INSTALLATION

Note the following, and install in the reverse order of removal.

- From below the vehicle, press the grommet (A) into place until the pawls (B) make a click sound.


CAUTION:

- Place the grommet on the floor, then fasten it in place from below the vehicle.
- Check that pulling down on the grommet does not disconnect it.



- Pay attention to the following when connecting the control cable to the CVT shift selector.

1. When connecting the control cable (1) to the CVT shift selector assembly (2), face the grooved surface of the rib (A) up and insert the control cable until it stops.



CONTROL CABLE


< REMOVAL AND INSTALLATION >

[CVT: RE0F10B]

2. Install the socket (A) onto the CVT shift selector.

CAUTION:

- Place the socket onto the CVT shift lever, then fasten it in place from above.
- Check that the pulling on the socket does not disconnect it.



Inspection

INFOID:000000008274161

INSPECTION AFTER INSTALLATION

Check the CVT position. If a malfunction is found, adjust the CVT position. Refer to [TM-137. "Inspection and Adjustment"](#).

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

KEY INTERLOCK CABLE


< REMOVAL AND INSTALLATION >

[CVT: RE0F10B]

KEY INTERLOCK CABLE

Exploded View

INFOID:000000008274162



- 1. CVT shift selector assembly
- 2. Key interlock cable
- A: Key cylinder
- B: Clip
- C: Clip

Removal and Installation

INFOID:000000008274163

REMOVAL


CAUTION:

Always apply the parking brake before performing removal and installation.

1. Shift the selector lever to the "N" position.
2. Remove the selector lever knob. Refer to [TM-216, "Disassembly and Assembly"](#).
3. Shift the selector lever to the "P" position.
4. Remove the center console. Refer to [IP-22, "Removal and Installation"](#).
5. Press the pawls (B) of the key interlock cable slider (A) while sliding it in the direction of the casing cap (C), and separate the adjusting holder (D) and slider.

E :Key interlock rod

6. Remove the key interlock cable from the CVT shift selector.
7. Remove the steering column lower cover and driver instrument lower panel. Refer to [IP-12, "Removal and Installation"](#).



KEY INTERLOCK CABLE


< REMOVAL AND INSTALLATION >

[CVT: RE0F10B]

8. Lift clip (A) in the direction of the arrow (←C) and remove in the direction of the arrow (←D).

- 1 :Key interlock cable
B :Key cylinder

9. Disconnect the key interlock cable from the key cylinder.
10. Disengage the clip and disconnect the key interlock cable from the vehicle.




INSTALLATION

Note the following, and install in the reverse order of removal.

- Install the adjusting holder (A) onto the key interlock rod (B), then install the casing cap (C) onto the CVT shift selector cable bracket (D).

CAUTION:


- When installing the key interlock cable, never bend or twist the cable forcefully.
- After connecting the key interlock cable to the CVT shift selector cable bracket, be sure to check that the casing cap is completely fastened to the cable bracket. If the casing cap is easily displaced, replace the key interlock cable.



- While pressing the detent rod (B) down, slide the key interlock cable slider (A) toward the key interlock rod (D) side, and install the adjusting holder (C) and key interlock rod.

CAUTION:

- Never squeeze the pawls on the key interlock cable slider when holding the slider.
- Never apply force in a perpendicular direction to the key interlock rod when sliding the slider.



INFOID:000000008274164

Inspection

INSPECTION AFTER INSTALLATION

- Check the CVT position. If a malfunction is found, adjust the CVT position. Refer to [TM-137, "Inspection and Adjustment"](#).
- The key can be removed only when the selector lever is in the "P" position.
- It must not be possible to turn the ignition switch to LOCK when the selector lever is not in the "P" position.

TRANSMISSION RANGE SWITCH


< REMOVAL AND INSTALLATION >

[CVT: RE0F10B]


TRANSMISSION RANGE SWITCH

Exploded View

INFOID:000000008274165



1. Transmission range switch
2. Transaxle assembly

 : N·m (kg·m, in·lb)

Removal and Installation

INFOID:000000008274166

REMOVAL

1. Remove battery. Refer to [PG-96, "Removal and Installation"](#).
2. Remove transmission range switch connector.
3. Remove control cable. Refer to [TM-219, "Removal and Installation"](#).
4. Remove transmission range switch from transaxle assembly.

INSTALLATION

Install in the reverse order of removal.

Inspection and Adjustment

INFOID:000000008274167

ADJUSTMENT OF TRANSMISSION RANGE SWITCH


1. Move selector lever to "N" position.
2. Remove control cable from manual lever.

TRANSMISSION RANGE SWITCH

< REMOVAL AND INSTALLATION >

[CVT: RE0F10B]

3. Loosen mounting bolts (←) of transmission range switch. Insert a pin ($\phi 4$ mm) into the adjusting holes (A) on both transmission range switch and manual lever for adjusting the position.
4. Tighten mounting bolts of transmission range switch.
5. Connect control cable on manual lever. Refer to [TM-137, "Inspection and Adjustment"](#).



ADJUSTMENT AFTER INSTALLATION

Adjust the CVT positions after installing the CVT shift selector. Refer to [TM-137, "Inspection and Adjustment"](#).

INSPECTION AFTER INSTALLATION


Check the CVT positions after adjusting the CVT positions. Refer to [TM-137, "Inspection and Adjustment"](#).

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

TCM

Exploded View

INFOID:000000008274168



- 1. Bracket
- 2. TCM

↔ :Vehicle front

⊙ : N-m (kg-m, in-lb)

Removal and Installation

INFOID:000000008274169

CAUTION:

- Never impact on TCM when removing or installing TCM.
- When replacing TCM, note the “CVTF DETERIORATION DATE” value displayed on CONSULT “CONFORM CVTF DETERIORATION” in MAINTENANCE BOOKLET, before start the operation.
- When replacing TCM and transaxle assembly simultaneously, replace transaxle assembly first and then replace TCM.
- Before replacing TCM, perform “ADDITIONAL SERVICE WHEN REPLACING TCM”. Refer to [TM-123, "Work Procedure"](#).

REMOVAL

1. Remove the battery. Refer to [PG-96, "Removal and Installation"](#).
2. Remove air duct (inlet) and air cleaner case. Refer to [EM-25, "Removal and Installation"](#).
3. Disconnect the TCM connector.
4. Remove the TCM.
5. Remove the bracket.

INSTALLATION

Installation is the reverse order of removal.

Adjustment

INFOID:000000008274170

ADJUSTMENT AFTER INSTALLATION

When replaced TCM, perform "ADDITIONAL SERVICE WHEN REPLACING TCM". Refer to [TM-123, "Work Procedure"](#).

AIR BREATHER HOSE

< REMOVAL AND INSTALLATION >

[CVT: RE0F10B]


AIR BREATHER HOSE

Removal and Installation

INFOID:000000008274171

REMOVAL

1. Remove air cleaner case. Refer to [EM-25, "Removal and Installation"](#).
2. Remove clip (A) from bracket.
3. Remove air breather hose (1) from transaxle assembly.




INSTALLATION


Note the following, and install in the reverse order of removal.

CAUTION:

- Never bend the air breather hose to prevent damage to the hose.
- Install air breather hose (1) to transaxle tube (A) all the way to the curve of the tube.
- Install air breather hose to transaxle tube so that the paint mark (B) is facing upward.



- Securely install the clip (A) to the bracket.



A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

CONTROL VALVE

< REMOVAL AND INSTALLATION >


[CVT: RE0F10B]

CONTROL VALVE

Exploded View

INFOID:000000008274172

COMPONENT PARTS LOCATION



- | | | |
|-----------------------|--------------------------|----------------------------|
| 1. Transaxle assembly | 2. Control valve | 3. Bracket |
| 4. O-ring | 5. Oil strainer assembly | 6. Magnet |
| 7. Drain plug gasket | 8. Drain plug | 9. Oil pan mounting bolt |
| 10. Oil pan | 11. Oil pan gasket | 12. Lock nut |
| 13. Washer | 14. Manual plate | 15. Collar |
| 16. Lip seal | 17. Snap ring | 18. Terminal cord assembly |

⊗ : Always replace after every disassembly.

⊙ : N·m (kg-m, ft-lb)

⊙ : N·m (kg-m, in-lb)

⊙ : Apply CVT fluid

Removal and Installation

INFOID:000000008274173


REMOVAL

CONTROL VALVE

< REMOVAL AND INSTALLATION >

[CVT: RE0F10B]

1. Disconnect battery cable from negative terminal. Refer to [PG-96, "Exploded View"](#).
2. Remove drain plug from oil pan and then drain the CVT fluid.
3. Remove drain plug gasket.
4. Disconnect the CVT unit connector. Refer to [TM-64, "Removal and Installation Procedure for CVT Unit Connector"](#).
5. Remove the snap ring (1) from the CVT unit connector (A).




6. Press the CVT unit connector (A) into the transaxle case.

CAUTION:

Never damage the CVT unit connector.

NOTE:

Clean around the connector to prevent foreign materials from entering into the transaxle case.




7. Remove the oil pan mounting bolts, and then remove the oil pan and oil pan gasket.
8. Remove the magnets from the oil pan.
9. Remove the lock nut (1) and washer (2), and then remove the manual plate (3).

← : Vehicle front

10. Remove the collar (4) from the manual shaft (A).

CAUTION:


Never drop the collar.



11. Disconnect the control valve connectors (A) and (B).

← : Clip

← : Vehicle front



CONTROL VALVE


< REMOVAL AND INSTALLATION >

[CVT: RE0F10B]

12. Remove the oil strainer assembly mounting bolts (A) and (B), and then remove the oil strainer assembly (1).

⇐ : Vehicle front


13. Remove O-ring from oil strainer assembly.



14. Remove the bracket (1).

← : Bolt

⇐ : Vehicle front




15. Remove the control valve mounting bolts (A) and (B), and then remove the control valve from the transaxle case.


⇐ : Vehicle front

CAUTION:

Never drop the control valve, ratio control valve and manual shaft.




16. Remove terminal cord assembly (1) from the transaxle case inside.



17. Remove the lip seal (1) from the transaxle case.

⇐ : Vehicle front



CONTROL VALVE


< REMOVAL AND INSTALLATION >

[CVT: RE0F10B]

INSTALLATION

1. Install the lip seal (1) to the transaxle case.


← : Vehicle front



2. Install terminal cord assembly (1) to the transaxle case.

CAUTION:

Connect the CVT unit connector with the stopper facing up, and then press in until it clicks.





3. Press in the ratio control valve (B) in the (←) direction, and then fix the linkage in the position shown in the figure with the linkage fixing pin (A) from the back of control valve through the hole for fixing.

4. Check that one end of linkage engages with the step motor end (C) and that the linkage is in the direction shown in the figure.

5. Install the control valve to the transaxle case.

CAUTION:

- Never drop the linkage fixing pin. If it is dropped, repeat the installation procedure from step 3.
- Never pinch the harness into between the control valve and the transaxle case.
- Never drop the control valve, ratio control valve and manual shaft.



A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

CONTROL VALVE


[CVT: RE0F10B]

< REMOVAL AND INSTALLATION >

6. Fix the control valve using the control valve mounting bolts (A) and (B).

↩ : Vehicle front

Bolt	Bolt length (mm)	Number of bolts
A	54	10
B	44	1




7. Pull the linkage fixing pin out.
8. Connect the control valve connectors (A) and (B).

← : Clip

↩ : Vehicle front

CAUTION:

- Never pinch the harness into between the control valve and the transaxle case.
- Securely insert the connector until it clicks and locks.



9. Install the bracket (1).


← : Bolt

↩ : Vehicle front

10. Install O-ring to oil strainer assembly.

CAUTION:

- Never reuse O-ring.
- Apply CVT fluid to O-ring.



11. Install the oil strainer assembly (1) using the oil strainer assembly mounting bolts (A) and (B).

↩ : Vehicle front

Bolt	Bolt length (mm)	Number of bolts
A	12	2
B	44	1


NOTE:

Remove the bracket and adjust the position again if the bolt hole positions are not aligned.

12. Install the collar to the manual shaft.

CAUTION:

Never drop the collar.



CONTROL VALVE

< REMOVAL AND INSTALLATION >

[CVT: RE0F10B]


13. Install the manual plate (1) while aligning with the groove (A) of the manual valve.

CAUTION:

Assemble the manual plate while aligning its end with the cutout (←) of the manual valve.

← : Vehicle front

14. Install the washer (2) and the lock-nut (3), and then tighten to the specified torque.



15. Install the snap ring (1) to the CVT unit connector (A).

16. Connect the CVT unit connector. Refer to [TM-64, "Removal and Installation Procedure for CVT Unit Connector"](#).

17. Install the magnet while aligning it with the convex side of oil pan.

CAUTION:

Completely eliminate the iron powder from the magnet mounting area of oil pan and the magnet.

18. Install the oil pan to the transaxle case with the following procedure.

1. Install the oil pan gasket to the oil pan.


CAUTION:

- Completely wipe out any moisture, oil, and old gasket from the oil pan gasket mounting surface and bolt mounting hole of oil pan and transaxle case.
- Never reuse oil pan gasket.

2. Install the oil pan assembly to the transaxle case, and then temporarily tighten the oil pan mounting bolt.

3. Tighten the oil pan mounting bolts in the order shown in the figure to the specified torque.

4. Tighten the oil pan mounting bolts again clockwise from (1) shown in the figure to the specified torque.




19. Install drain plug gasket to drain plug.

CAUTION:

Never reuse drain plug gasket.

20. Install drain plug to oil pan.

21. Fill CVT fluid from CVT fluid charging pipe to the specified level.



CVT fluid : Refer to [MA-10, "Fluids and Lubricants"](#).
Fluid capacity

CAUTION:

- Use only Genuine CVT fluid. Never mix with other fluid.
- Using CVT fluid other than Genuine CVT fluid will deteriorate in driveability and CVT durability, and may damage the CVT, which is not covered by the warranty.
- When filling CVT fluid, take care not to scatter heat generating parts such as exhaust.
- Sufficiently shake the container of CVT fluid before using.
- Delete CVT fluid deterioration date with CONSULT after changing CVT fluid. Refer to [TM-103, "CONSULT Function"](#).

22. With the engine warmed up, drive the vehicle in an urban area.

NOTE:

When ambient temperature is 20°C (68°F), it takes about 10 minutes for the CVT fluid to warm up to 50 to 80°C (122 to 176°F).

23. Check CVT fluid level and condition. Refer to [TM-213, "Inspection"](#).

24. Connect battery cable to negative terminal. Refer to [PG-96, "Exploded View"](#).

CONTROL VALVE

< REMOVAL AND INSTALLATION >

[CVT: RE0F10B]

INFOID:000000008274174

Inspection and Adjustment

INSPECTION AFTER REMOVAL

Check oil pan for foreign material.

- If a large amount of worn material is found, clutch plate may be worn.
 - If iron powder is found, bearings, gears, or clutch plates may be worn.
 - If aluminum powder is found, bushing may be worn, or chips or burrs of aluminum casting parts may enter.
- Check points where wear is found in all cases.

INSPECTION AFTER INSTALLATION

Check the CVT fluid level and leakage. Refer to [TM-213, "Inspection"](#).

ADJUSTMENT AFTER INSTALLATION

When replaced control valve, perform "ADDITIONAL SERVICE WHEN REPLACING CONTROL VALVE OR TRANSAXLE ASSEMBLY". Refer to [TM-125, "Work Procedure"](#).

PRIMARY SPEED SENSOR


< REMOVAL AND INSTALLATION >

[CVT: RE0F10B]

PRIMARY SPEED SENSOR

Exploded View

INFOID:000000008274175



1. Transaxle assembly 2. O-ring 3. Primary speed sensor

⊗ : Always replace after every disassembly.

Ⓜ : N·m (kg·m, in·lb)

🔧 : Apply CVT fluid

Removal and Installation

INFOID:000000008274176

REMOVAL

1. Remove the battery. Refer to [PG-96, "Removal and Installation"](#).
2. Remove ECM and bracket as a set.
3. Remove primary speed sensor connector.
4. Remove primary speed sensor.
5. Remove O-ring from primary speed sensor.

INSTALLATION

Note the following, and install in the reverse order of removal.

CAUTION:

- Never reuse O-ring.
- Apply CVT fluid to O-ring.

Inspection

INFOID:000000008274177

INSPECTION AFTER INSTALLATION

Check for CVT fluid leakage and CVT fluid level. Refer to [TM-213, "Inspection"](#).

SECONDARY SPEED SENSOR


< REMOVAL AND INSTALLATION >

[CVT: RE0F10B]

SECONDARY SPEED SENSOR

Exploded View

INFOID:000000008274178



1. Transaxle assembly 2. Shim 3. O-ring

4. Secondary speed sensor

⊗ : Always replace after every disassembly.

Ⓜ : N·m (kg-m, in-lb)


🔧 : Apply CVT fluid

Removal and Installation

INFOID:000000008274179

REMOVAL

1. Remove air cleaner case. Refer to [EM-25. "Removal and Installation"](#).
2. Remove secondary speed sensor connector.
3. Remove secondary speed sensor (1) and shims (2).
4. Remove O-ring (3) from secondary speed sensor.



INSTALLATION

Note the following, and install in the reverse order of removal.

CAUTION:

- Never reuse O-ring.
- Apply CVT fluid to O-ring.
- Install two pieces of shims.

Inspection

INFOID:000000008274180

INSPECTION AFTER INSTALLATION

SECONDARY SPEED SENSOR

< REMOVAL AND INSTALLATION >

[CVT: RE0F10B]

Check for CVT fluid leakage and CVT fluid level. Refer to [TM-213, "Inspection"](#).

A

B

C

TM

E

F

G

H

I

J

K

L

M

N

O

P

DIFFERENTIAL SIDE OIL SEAL

< REMOVAL AND INSTALLATION >


[CVT: RE0F10B]

DIFFERENTIAL SIDE OIL SEAL

2WD

2WD : Exploded View

INFOID:000000008274181



1. Transaxle assembly

2. Differential side oil seal (Converter housing side)

3. Differential side oil seal (Transaxle case side)

⊗ : Always replace after every disassembly.

☰ : Apply CVT fluid

2WD : Removal and Installation

INFOID:000000008274182

REMOVAL

NOTE:

Cap or plug openings to prevent fluid from spilling.

1. Remove the left/right front drive shaft. Refer to [FAX-19, "LEFT SIDE : Removal and Installation"](#) (left side), [FAX-21, "RIGHT SIDE : Removal and Installation"](#) (right side).

2. Use oil seal remover or a similar means and remove the differential side oil seal.

CAUTION:

When removing the differential side oil seal, be careful not to scratch the oil seal mounting surfaces of the transaxle case and converter housing.

INSTALLATION

Note the following, and install in the reverse order of removal.

CAUTION:

- Never reuse differential side oil seal.
- Apply Genuine CVT fluid to the differential side oil seal lip and around the oil seal.
- When inserting the drive shaft, be sure to use a protector (SST: KV38107900).

DIFFERENTIAL SIDE OIL SEAL

< REMOVAL AND INSTALLATION >


[CVT: RE0F10B]

Use a drift (commercial service tool) and drive the differential side oil seal in until the amount of oil seal projection from the case edge matches dimensions (C) and (D).

CAUTION:

Be careful not to scratch the lip of the differential side oil seal when press-fitting it.

- A : Transaxle case side
- B : Converter housing side



Dimension "C" :Height difference from case end surface is within 1.8 ± 0.5 mm (0.071 ± 0.020 in).

Dimension "D" :Height difference from case end surface is within 2.2 ± 0.5 mm (0.087 ± 0.020 in).

NOTE:

The reference is the pull-in direction of the differential side oil seal.

Drift to be used:

Location	Commercial Service Tools
Transaxle case side	Commercial service tool with outer dia. 54 mm (2.13 in) and inner dia. 50 mm (1.97 in)
Converter housing side	

2WD : Inspection

INFOID:000000008274183


INSPECTION AFTER INSTALLATION

Check for CVT fluid leakage and CVT fluid level. Refer to [TM-213, "Inspection"](#).

AWD

AWD : Exploded View

INFOID:000000008274184



- 1. Transaxle assembly
- 2. Differential side oil seal (Converter housing side)
- 3. Differential side oil seal (Transaxle case side)

: Always replace after every disassembly.

: Genuine CVT fluid

DIFFERENTIAL SIDE OIL SEAL

< REMOVAL AND INSTALLATION >

[CVT: RE0F10B]

AWD : Removal and Installation

INFOID:000000008274185

REMOVAL

NOTE:

Cap or plug openings to prevent fluid from spilling.

1. Remove the left front drive shaft. Refer to [FAX-19, "LEFT SIDE : Removal and Installation"](#).
2. Remove the transfer assembly. Refer to [DLN-90, "Removal and Installation"](#).
3. Use oil seal remover or a similar means and remove the differential side oil seal.

CAUTION:

When removing the differential side oil seal, be careful not to scratch the oil seal mounting surfaces of the transaxle case and converter housing.

INSTALLATION

Note the following, and install in the reverse order of removal.

CAUTION:


- Never reuse differential side oil seal.
- Apply Genuine CVT fluid to the differential side oil seal lip and around the oil seal.
- When inserting the drive shaft, be sure to use a protector (SST: KV38107900).

Use a drift (commercial service tool) and drive the differential side oil seal in until the amount of oil seal projection from the case edge matches dimensions (C) and (D).

CAUTION:

Be careful not to scratch the lip of the differential side oil seal when press-fitting it.

- A : Transaxle case side
B : Converter housing side



Dimension "C" :Height difference from case end surface is within 1.8 ± 0.5 mm (0.071 ± 0.020 in).

Dimension "D" :Height difference from case end surface is within 1.0 ± 0.5 mm (0.039 ± 0.020 in).

NOTE:

The reference is the pull-in direction of the differential side oil seal.

Drift to be used:

Location	Commercial Service Tools
Transaxle case side	Commercial service tool with outer dia. 54 mm (2.13 in) and inner dia. 50 mm (1.97 in)
Converter housing side	Commercial service tool with outer dia. 60 mm (2.36 in)

AWD : Inspection

INFOID:000000008274186

INSPECTION AFTER INSTALLATION

Check for CVT fluid leakage and CVT fluid level. Refer to [TM-213, "Inspection"](#).

OIL PUMP FITTING BOLT

< REMOVAL AND INSTALLATION >

[CVT: RE0F10B]

OIL PUMP FITTING BOLT


Description

INFOID:000000008274187

Replace the oil pump fitting bolt and the O-ring if oil leakage or exudes from the oil pump fitting bolt.

Exploded View

INFOID:000000008274188



1. Oil pump fitting bolt

2. O-ring

3. Transaxle assembly

⊗ : Always replace after every disassembly.

Ⓒ : N·m (kg-m, ft-lb)


👉 : Apply CVT fluid

Removal and Installation

INFOID:000000008274189

REMOVAL

1. Remove Oil pump fitting bolt (1) from transaxle assembly.
2. Remove O-ring from oil pump fitting bolt.



INSTALLATION

Note the following, and install in the reverse order of removal.

CAUTION:

- Never reuse O-ring.
- Apply CVT fluid to O-ring.

Inspection

INFOID:000000008274190

INSPECTION AFTER INSTALLATION

Check for CVT fluid leakage and CVT fluid level. Refer to [TM-213, "Inspection"](#).

WATER HOSE


< REMOVAL AND INSTALLATION >

[CVT: RE0F10B]


WATER HOSE

Exploded View

INFOID:000000008274191



- | | | |
|-------------------------------|-------------------|--------------------------|
| 1. Heater thermostat assembly | 2. Hose clamp | 3. Water hose |
| A. Water outlet | B. CVT oil warmer | C. To thermostat housing |
| D. To oil cooler | | |

 : N·m (kg-m, ft-lb)

Removal and Installation

INFOID:000000008274192

REMOVAL

WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could occur from high pressure coolant escaping from the radiator.

CAUTION:

Perform these steps after the coolant temperature has cooled sufficiently.

1. Remove the battery. Refer to [PG-96, "Removal and Installation"](#).
2. Remove the ECM and bracket as a set.
3. Remove the water hose.
4. Remove the heater thermostat.

INSTALLATION

Note the following, and Install in the reverse order of removal.


- Refer to the following when installing water hoses.

Water hose (1)	Installation side tube (2)	Direction of paint mark	Hose insertion depth "L"
Water hose	Water outlet	Upward	A: 27 mm (1.06 in) [End reaches the 2-stage bulge.]
	CVT oil warmer	Leftward	B: 27 mm (1.06 in) [End reaches the tube bend R position].]
Heater thermostat assembly	CVT oil warmer	Leftward	

WATER HOSE

< REMOVAL AND INSTALLATION >

[CVT: RE0F10B]




- Refer to the followings when installing hose clamp.

CAUTION:

Hose clamp should not interfere with the bulge of fluid cooler tube.

Water hose (1)	Installation side tube (2)	Hose clamp (3)	
		Direction of tab	Clamping position
Water hose	Water outlet	Backward	A: 5 – 7 mm (0.20 – 0.28 in) (L) from hose end
	CVT oil warmer	Upward	
Heater thermostat assembly	CVT oil warmer	Upward	B: Align with the end of paint mark (C)




Inspection

INFOID:000000008274193

INSPECTION AFTER REMOVAL

Heater Thermostat

- Fully immerse the heater thermostat (1) in a container (A) filled with water. Continue heating the water while stirring.
- Continue heating the heater thermostat for 5 minutes or more after bringing the water to a boil.
- Quickly take the heater thermostat out of the hot water, measure the heater thermostat within 10 seconds.



JPBIA0318ZZ

WATER HOSE


[CVT: RE0F10B]

< REMOVAL AND INSTALLATION >

- Place dial indicator (A) on the pellet (B) and measure the elongation from the initial state.

Standard : Refer to [TM-256, "Heater Thermostat"](#).

- If out of standard, replace heater thermostat.



INSPECTION AFTER INSTALLATION

Start the engine, and check the joints for coolant leakage. Refer to [TM-213, "Inspection"](#).

TRANSAXLE ASSEMBLY

< UNIT REMOVAL AND INSTALLATION >

[CVT: RE0F10B]


UNIT REMOVAL AND INSTALLATION

TRANSAXLE ASSEMBLY

2WD

2WD : Exploded View


INFOID:000000008274194





- 1. Transaxle assembly
- 2. O-ring
- 3. CVT fluid charging pipe


- 4. CVT fluid level gauge

- A. For tightening torque, refer to [TM-245, "2WD : Removal and Installation"](#).

 : Always replace after every disassembly.

 : N·m (kg·m, ft·lb)

 : N·m (kg·m, in·lb)

 : Apply petroleum jelly

2WD : Removal and Installation

INFOID:000000008274195

REMOVAL

WARNING:

Never remove the reservoir tank cap when the engine is hot. Serious burns could occur from high pressure engine coolant escaping from the reservoir tank.

CAUTION:

Perform this step engine is cold.

NOTE:

Cap or cover any transaxle openings to prevent transaxle fluid from spilling.



1. Remove the battery. Refer to [PG-96, "Removal and Installation"](#).

TRANSAXLE ASSEMBLY

[CVT: RE0F10B]

< UNIT REMOVAL AND INSTALLATION >

2. Drain engine coolant. Refer to [CO-8, "Draining"](#).
3. Remove the air duct and air cleaner case. Refer to [EM-25, "Removal and Installation"](#).
4. Remove air breather hose. Refer to [TM-227, "Removal and Installation"](#).
5. Remove the ECM and bracket as a set.
6. Remove CVT fluid level gauge.
7. Remove CVT fluid charging pipe from transaxle assembly.
8. Remove O-ring from CVT fluid charging pipe.
9. Disconnect following harness connector and wire harness.
 - CVT unit harness connector (A).
 - Primary speed sensor harness connector (B).
 - Secondary speed sensor harness connector (C).
 - Transmission range switch connector (D).
10. Remove harness and clip from the transaxle assembly.
11. Remove water hose. Refer to [TM-242, "Removal and Installation"](#).
12. Remove control cable from transaxle assembly. Refer to [TM-219, "Removal and Installation"](#).
13. Remove starter motor. Refer to [STR-24, "Removal and Installation"](#).
14. Turn crankshaft, and remove the four tightening nuts (←) for drive plate and torque converter.
CAUTION:
When turning crankshaft, turn it clockwise as viewed from the front of the engine.
15. Remove exhaust front tube. Refer to [EX-5, "Exploded View"](#).
16. Remove front drive shafts. Refer to [FAX-19, "LEFT SIDE : Removal and Installation"](#) (left side), [FAX-21, "RIGHT SIDE : Removal and Installation"](#) (right side).
17. Remove front suspension member from vehicle. Refer to [FSU-16, "Removal and Installation"](#).
18. Support transaxle assembly with a transmission jack.
CAUTION:
When setting the transmission jack, be careful not to collide against the drain plug.
19. Support engine assembly with a transmission jack.
CAUTION:
When setting the transmission jack, be careful not to collide against the drain plug.
20. Remove engine mounting insulator (LH). Refer to [EM-59, "2WD : Exploded View"](#).
21. Remove bolts fixing transaxle assembly to engine assembly.
22. Remove transaxle assembly from vehicle.
CAUTION:
 - Secure torque converter to prevent it from dropping.
 - Secure transaxle assembly to a transmission jack.
23. Remove heater thermostat. Refer to [TM-242, "Removal and Installation"](#).



INSTALLATION

Note following, and install in the reverse order of removal.


CAUTION:

TRANSAXLE ASSEMBLY


< UNIT REMOVAL AND INSTALLATION >

[CVT: RE0F10B]

- Check fitting of dowel pin (◀) when installing transaxle assembly to engine assembly.




- When installing transaxle assembly to the engine assembly, attach the fixing bolts in accordance with the following.




Insertion direction	Transaxle to engine	Engine to transaxle
Bolt No.	A	B
Number of bolts	2	7
Bolt length mm (in)	55 (2.17)	50 (1.97)
Tightening torque N·m (kg·m, ft·lb)	62 (6.3, 46)	

- Set and screw in the drive plate location guide (commercial service tool: 31197CA000) (A) onto the stud bolts for the torque converter locate.



- When not using drive plate location guide, rotate torque converter so that the stud bolt (A) for mounting the drive plate location guide of torque converter aligns with the mounting position of starter motor.



A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

TRANSAXLE ASSEMBLY

< UNIT REMOVAL AND INSTALLATION >

[CVT: RE0F10B]


- Rotate crankshaft so that the hole (A) for inserting drive plate location guide of drive plate aligns with the mounting position (B) of starter motor.

NOTE:

When not using drive plate location guide, insert stud bolt of torque converter into the hole of drive plate, aligning the drive plate hole position and torque converter.

CAUTION:


Note that the stud bolt strikes the drive plate hole position is not aligned the torque converter stud bolt.



- Align the position of tightening nuts (←) for drive plate with those of the torque converter, and temporarily tighten the nuts. Then, tighten the bolts with the specified torque.

CAUTION:

- When turning crankshaft, turn it clockwise as viewed from the front of the engine.
- When tightening the tightening nuts for the torque converter after fixing the crankshaft pulley bolts, confirm the tightening torque of the crankshaft pulley mounting bolts. Refer to .
- After converter is installed to drive plate, rotate crankshaft several turns and check that transaxle rotates freely without binding.



2WD : Inspection and Adjustment

INFOID:000000008274196


INSPECTION BEFORE INSTALLATION

After inserting a torque converter to the CVT, check dimension (A) with in the reference value limit.

B : Scale

C : Straightedge

Dimension (A) : Refer to [TM-255, "Torque Converter"](#).



INSPECTION AFTER INSTALLATION

- Check for CVT fluid leakage and check CVT fluid level. Refer to [TM-213, "Inspection"](#).
- Check CVT position. Refer to [TM-137, "Inspection and Adjustment"](#).
- Start and warm up the engine. Visually check that there is no leakage of engine coolant and CVT fluid.

ADJUSTMENT AFTER INSTALLATION

When replaced transaxle assembly, perform "ADDITIONAL SERVICE WHEN REPLACING CONTROL VALVE OR TRANSAXLE ASSEMBLY". Refer to [TM-125, "Work Procedure"](#).

AWD


TRANSAXLE ASSEMBLY

< UNIT REMOVAL AND INSTALLATION >

[CVT: RE0F10B]

AWD : Exploded View

INFOID:000000008274197



- 1. Transaxle assembly
- 2. O-ring
- 3. CVT fluid charging pipe

- 4. CVT fluid level gauge

- A. For tightening torque, refer to [TM-249, "AWD : Removal and Installation"](#).

: Always replace after every disassembly.

: N·m (kg·m, ft·lb)

: N·m (kg·m, in·lb)

: Apply petroleum jelly

AWD : Removal and Installation

INFOID:000000008274198

REMOVAL

WARNING:

Never remove the reservoir tank cap when the engine is hot. Serious burns could occur from high pressure engine coolant escaping from the reservoir tank.

CAUTION:

Perform this step engine is cold.

NOTE:

Cap or cover any transaxle openings to prevent transaxle fluid from spilling.

1. Remove the battery. Refer to [PG-96, "Removal and Installation"](#).
2. Drain engine coolant. Refer to [CO-8, "Draining"](#).
3. Remove the air duct and air cleaner case. Refer to [EM-25, "Removal and Installation"](#).
4. Remove air breather hose. Refer to [TM-227, "Removal and Installation"](#).
5. Remove the ECM and bracket as a set.

TRANSAXLE ASSEMBLY

< UNIT REMOVAL AND INSTALLATION >

[CVT: RE0F10B]

6. Remove CVT fluid level gauge.
7. Remove CVT fluid charging pipe from transaxle assembly.
8. Remove O-ring from CVT fluid charging pipe.
9. Disconnect following harness connector and wire harness.
 - CVT unit harness connector (A).
 - Primary speed sensor harness connector (B).
 - Secondary speed sensor harness connector (C).
 - Transmission range switch connector (D).
10. Remove harness and clip from the transaxle assembly.
11. Remove water hose. Refer to [TM-242, "Removal and Installation"](#).
12. Remove control cable from transaxle assembly. Refer to [TM-219, "Removal and Installation"](#).
13. Remove starter motor. Refer to [STR-24, "Removal and Installation"](#).
14. Turn crankshaft, and remove the four tightening nuts (←) for drive plate and torque converter.

CAUTION:



When turning crankshaft, turn it clockwise as viewed from the front of the engine.

15. Remove exhaust front tube. Refer to [EX-5, "Exploded View"](#).
16. Separate the propeller shaft. Refer to [DLN-120, "Removal and Installation"](#).
17. Remove front drive shafts. Refer to [FAX-19, "LEFT SIDE : Removal and Installation"](#) (left side), [FAX-21, "RIGHT SIDE : Removal and Installation"](#) (right side).
18. Remove front suspension member from vehicle. Refer to [FSU-16, "Removal and Installation"](#).
19. Remove transfer assembly from transaxle assembly with power tool. Refer to [DLN-90, "Removal and Installation"](#).
20. Support transaxle assembly with a transmission jack.

CAUTION:
When setting the transmission jack, be careful not to collide against the drain plug.
21. Support engine assembly with a transmission jack.

CAUTION:
When setting the transmission jack, be careful not to collide against the drain plug.
22. Remove engine mounting insulator (LH). Refer to [EM-64, "4WD \(AWD\) : Exploded View"](#).
23. Remove bolts fixing transaxle assembly to engine assembly.
24. Remove transaxle assembly from vehicle.

CAUTION:
 - **Secure torque converter to prevent it from dropping.**
 - **Secure transaxle assembly to a transmission jack.**
25. Remove heater thermostat. Refer to [TM-242, "Removal and Installation"](#).



INSTALLATION

Note following, and install in the reverse order of removal.


CAUTION:

TRANSAXLE ASSEMBLY


< UNIT REMOVAL AND INSTALLATION >

[CVT: RE0F10B]

- Check fitting of dowel pin (←) when installing transaxle assembly to engine assembly.




- When installing transaxle assembly to the engine assembly, attach the fixing bolts in accordance with the following.




Insertion direction	Transaxle to engine	Engine to transaxle
Bolt No.	A	B
Number of bolts	2	6
Bolt length mm (in)	55 (2.17)	50 (1.97)
Tightening torque N·m (kg·m, ft·lb)	62 (6.3, 46)	

- Set and screw in the drive plate location guide (commercial service tool: 31197CA000) (A) onto the stud bolts for the torque converter locate.



- When not using drive plate location guide, rotate torque converter so that the stud bolt (A) for mounting the drive plate location guide of torque converter aligns with the mounting position of starter motor.



A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

TRANSAXLE ASSEMBLY

< UNIT REMOVAL AND INSTALLATION >

[CVT: RE0F10B]


- Rotate crankshaft so that the hole (A) for inserting drive plate location guide of drive plate aligns with the mounting position (B) of starter motor.

NOTE:

When not using drive plate location guide, insert stud bolt of torque converter into the hole of drive plate, aligning the drive plate hole position and torque converter.

CAUTION:


Note that the stud bolt strikes the drive plate hole position is not aligned the torque converter stud bolt.



- Align the position of tightening nuts (←) for drive plate with those of the torque converter, and temporarily tighten the nuts. Then, tighten the bolts with the specified torque.

CAUTION:

- When turning crankshaft, turn it clockwise as viewed from the front of the engine.
- When tightening the tightening nuts for the torque converter after fixing the crankshaft pulley bolts, confirm the tightening torque of the crankshaft pulley mounting bolts. Refer to .
- After converter is installed to drive plate, rotate crankshaft several turns and check that transaxle rotates freely without binding.



AWD : Inspection and Adjustment

INFOID:000000008274199


INSPECTION BEFORE INSTALLATION

After inserting a torque converter to the CVT, check dimension (A) with in the reference value limit.

B : Scale

C : Straightedge

Dimension (A) : Refer to [TM-255, "Torque Converter"](#).



INSPECTION AFTER INSTALLATION

- Check for CVT fluid leakage and check CVT fluid level. Refer to [TM-213, "Inspection"](#).
- Check CVT position. Refer to [TM-137, "Inspection and Adjustment"](#).
- Start and warm up the engine. Visually check that there is no leakage of engine coolant and CVT fluid.

ADJUSTMENT AFTER INSTALLATION

When replaced transaxle assembly, perform "ADDITIONAL SERVICE WHEN REPLACING CONTROL VALVE OR TRANSAXLE ASSEMBLY". Refer to [TM-125, "Work Procedure"](#).

TORQUE CONVERTER AND CONVERTER HOUSING OIL SEAL

< UNIT DISASSEMBLY AND ASSEMBLY >


[CVT: RE0F10B]

UNIT DISASSEMBLY AND ASSEMBLY

TORQUE CONVERTER AND CONVERTER HOUSING OIL SEAL

Exploded View

INFOID:000000008274200



1. Transaxle assembly
2. Converter housing oil seal
3. Torque converter

: Always replace after every disassembly.

: Apply CVT fluid

Disassembly

INFOID:000000008274201

1. Remove transaxle assembly. Refer to [TM-249, "AWD : Removal and Installation"](#).

2. Remove torque converter from transaxle assembly.

CAUTION:

Never damage bush on the inside of torque converter sleeve when removing torque converter.

3. Remove converter housing oil seal using a flat-bladed screwdriver.

CAUTION:

Be careful not to scratch converter housing.

Assembly


INFOID:000000008274202

Note the following, and install in the reverse order of removal.

- Drive converter housing oil seal (1) evenly using a drift (A) (commercial service tool) so that converter housing oil seal protrudes by the dimension (B) respectively.

Unit: mm (in)	
Commercial service tool: A	Outer diameter: 65 (2.56)
	Inner diameter: 60 (2.36)

2 : Transaxle assembly



SCIA7908J

TORQUE CONVERTER AND CONVERTER HOUSING OIL SEAL

< UNIT DISASSEMBLY AND ASSEMBLY >


[CVT: RE0F10B]

Unit: mm (in)	
Dimension B	1.0 ± 0.5 (0.039 ± 0.020)

NOTE:

Converter housing oil seal pulling direction is used as the reference.

- After completing installation, check for CVT fluid leakage and CVT fluid level. Refer to [TM-213, "Inspection"](#).





SCIA7909J

- Attach the pawl (A) of the torque converter to the drive sprocket hole (B) on the transaxle assembly side.

CAUTION:

- Rotate the torque converter for installing torque converter.
- Never damage the bushing inside the torque converter sleeve when installing the converter housing oil seal.



SCIA7907J

Inspection

INFOID:000000008274203


INSPECTION AFTER INSTALLATION

- After inserting a torque converter to the CVT, check dimension (A) with in the reference value limit.

B : Scale

C : Straightedge

Dimension (A) : Refer to [TM-255, "Torque Converter"](#).



JPDIA0115ZZ

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[CVT: RE0F10B]

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specification

INFOID:000000008274204

Applied model		MR16DDT	
		2WD	AWD
CVT model		RE0F10B	
CVT assembly	Model code number	3TX0A	3TX0C
Transmission gear ratio	D range	2.349 – 0.394	
	Reverse	1.750	
	Final drive	5.798	
Recommended fluid		Refer to MA-10, "Fluids and Lubricants" .	
Fluid capacity		Refer to MA-10, "Fluids and Lubricants" .	

Shift Characteristics

INFOID:000000008274205

Numerical value data are reference values.

Unit: rpm

Throttle position	Shift pattern	CVT input speed	
		At 40 km/h (25 MPH)	At 60 km/h (37 MPH)
2/8	"D" position	1,500 – 3,100	1,600 – 3,400
	ECO mode*	1,500 – 2,400	1,600 – 2,500
8/8	"D" position	3,300 – 4,200	4,300 – 5,200
	ECO mode*	3,300 – 4,200	4,300 – 5,200

*: With Integrated Control System

NOTE:

Lock-up clutch is engaged when vehicle speed is approximately 18 km/h (11 MPH) to 90 km/h (56 MPH).

Stall Speed

INFOID:000000008274206

Stall speed	3,000 – 3,500 rpm
-------------	-------------------

Line Pressure

INFOID:000000008274207

Unit: kPa (bar, kg/cm², psi)

Engine speed	Line pressure
	"R" and "D" positions
At idle	750 (7.50, 7.65, 108.8)
At stall	5,700 (57.00, 58.14, 826.5)*

*: Reference values

Torque Converter

INFOID:000000008274208

Dimension between end of converter housing and torque converter	14.4 mm (0.567 in)
---	--------------------

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[CVT: RE0F10B]

Heater Thermostat

INFOID:000000008274209

Standard

Valve opening temperature	69 – 73°C (156 – 163°F)
Maximum valve lift	5.0 mm/85°C (0.197 in/185°F)
Valve closing temperature	65°C (149°F)