

SECTION DMS

DRIVE MODE SYSTEM

CONTENTS

INTEGRATED CONTROL SYSTEM	
PRECAUTION	2
PRECAUTIONS	2
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER"	2
Precautions for Removing Battery Terminal	2
SYSTEM DESCRIPTION	4
COMPONENT PARTS	4
Component Parts Location	4
Component Description	5
Multi Display Unit	5
SYSTEM	7
System Description	7
HANDLING PRECAUTION	9
NISSAN Dynamic Control System	9
ECU DIAGNOSIS INFORMATION	10
MULTI DISPLAY UNIT	10
List of ECU Reference	10
WIRING DIAGRAM	11
INTEGRATED CONTROL SYSTEM	11
Wiring Diagram	11
BASIC INSPECTION	15
DIAGNOSIS AND REPAIR WORK FLOW	15
Work Flow	15
REMOVAL AND INSTALLATION	17
MULTI DISPLAY UNIT	17
Exploded View	17
Removal and Installation	17

A
B
C
D
EF
G
H
I
J
K
L
M
N
P

DMS

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000012201592

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, it is recommended that all maintenance and repair be performed by an authorized NISSAN/INFINITI dealer.
- Improper repair, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery or batteries, and wait at least 3 minutes before performing any service.


Precautions for Removing Battery Terminal

INFOID:0000000012947014

When disconnecting the battery terminal, pay attention to the following.

- Always use a 12V battery as power source.
- Never disconnect battery terminal while engine is running.
- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.
- For vehicles with the engine listed below, remove the battery terminal after a lapse of the specified time:

D4D engine	: 20 minutes	YS23DDT	: 4 minutes
HRA2DDT	: 12 minutes	YS23DDTT	: 4 minutes
K9K engine	: 4 minutes	ZD30DDTi	: 60 seconds
M9R engine	: 4 minutes	ZD30DDTT	: 60 seconds
R9M engine	: 4 minutes		
V9X engine	: 4 minutes		
YD25DDTi	: 2 minutes		



SEF289H

NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- After high-load driving, if the vehicle is equipped with the V9X engine, turn the ignition switch OFF and wait for at least 15 minutes to remove the battery terminal.

NOTE:

PRECAUTIONS

< PRECAUTION >

- Turbocharger cooling pump may operate in a few minutes after the ignition switch is turned OFF.
- Example of high-load driving
 - Driving for 30 minutes or more at 140 km/h (86 MPH) or more.
 - Driving for 30 minutes or more on a steep slope.
- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.

NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.

[INTEGRATED CONTROL SYSTEM]

A

B

C

D

E

F

G

H

I

J

K

L

M

N

DMS


P

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:0000000012201594



JSNIA7514ZZ

1. A/C auto amp
Refer to [HAC-7, "Component Parts Location"](#).
 2. ECM
Refer to [EC-27, "ENGINE CONTROL SYSTEM : Component Parts Location"](#) (MR FOR NISMO RS MODELS) or [EC-600, "ENGINE CONTROL SYSTEM : Component Parts Location"](#) (MR EXCEPT FOR NISMO RS MODELS).
 3. TCM
Refer to [TM-156, "CVT CONTROL SYSTEM : Component Parts Location"](#) (RE0F10B) or [TM-361, "CVT CONTROL SYSTEM : Component Parts Location"](#) (RE0F10D).
 4. EPS control unit
Refer to [STC-5, "Component Parts Location"](#).
 5. Drive mode switch
 - NORMAL switch
 - SPORT switch
 - ECO switch
 6. D-MODE select switch
- A. Multi display unit

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[INTEGRATED CONTROL SYSTEM]

Component Description

INFOID:000000012201595

A

B

C

D

E

F

G

H

I

J

K

L

M

N

DMS

P


Part name	Description
Multi display unit	Transmits the ON/OFF status of each mode of the drive mode switch (NORMAL, SPORT, ECO) to TCM (CVT models), ECM (M/T models), EPS control unit and the A/C auto amp via CAN communication.
ECM	Based on the mode signals received from TCM (CVT models) or multi display unit (M/T models) via CAN communication, changes over the throttle position and other characteristics.
TCM	Based on the mode signals received from the multi display unit via CAN communication, changes over the gear shift line and other characteristics.
EPS control unit	Based on the mode signals received from the multi display unit via CAN communication, changes over the steering assist characteristic.
A/C auto amp	Based on the ECO mode signal received from the multi display unit via CAN communication, changes over the set temperature correction.

Multi Display Unit

INFOID:000000012201596

DESCRIPTION

- The multi display unit connects to other units via CAN communication and performs the drive mode control.
- The following 3 drive modes are available, NORMAL, SPORT, and ECO.
- The drive mode can be changed over as desired by pressing the D-MODE select switch. The characteristics of the engine, CVT, steering and air conditioner are changed accordingly.
- The display shows the current drive mode (NORMAL, SPORT, ECO) as well as the vehicle information for the mode.



JSNIA3473ZZ

VEHICLE INFORMATION DISPLAY

Drive Mode

Item	Display content	Display
NORMAL mode	<ul style="list-style-type: none"> Displays the input voltage to the multi display unit in 5 grades. Displays the engine torque in 5 grades. 	 AVA1251

COMPONENT PARTS


< SYSTEM DESCRIPTION >

[INTEGRATED CONTROL SYSTEM]

Item	Display content	Display
SPORT mode	Displays the boost pressure in 5 grades.	 <small>AVA1257</small>
ECO mode	Displays the instantaneous fuel consumption in 5 grades.	 <small>AVA1305</small>

SYSTEM**System Description**

INFOID:0000000012201597

SYSTEM DIAGRAM

- The multi display unit transmits the operation status of the drive mode switch to other units via CAN communication as the mode signal (refer below).
 - NORMAL: ON/OFF
 - SPORT: ON/OFF
 - ECO: ON/OFF
- Based on the mode signals received from TCM (CVT models) or multi display unit (M/T models) via CAN communication, ECM changes over the throttle position and other characteristics.
- Based on the mode signals received from the multi display unit via CAN communication, TCM changes over the gear shift line and other characteristics.
- Based on the mode signals received from the multi display unit via CAN communication, EPS C/U changes the steering assist characteristic.
- Based on the ECO mode signal received from the multi display unit via CAN communication, the A/C auto amp changes over the set temperature correction.

CONTROL DESCRIPTION

- The drive mode switch in the controller of the multi display unit is used to change over the vehicle mode and thus change the control characteristics for the engine, transaxle, steering, and air conditioner.

Function Apply List

		MR16DDT	
		M/T	CVT
SPORTS	ENGINE	×	×
	CVT		×
ECO	STEERING	×	×
	ENGINE	×	×
	CVT		×
AIR CONDITIONER		×	×

- With the NORMAL mode as the base mode, the control of vehicle characteristics is changed over to the following modes.
 - SPORT: The control characteristics for the engine, transaxle, and steering system are changed so that a sporty feel is created in the driving behavior.
 - ECO: The control characteristics for the engine, transaxle, and automatic air conditioner are changed to help improve the practical fuel economy.

A

B

C

D

E

F

G

H

I

J

K

L

M

N

DMS

P

SYSTEM

< SYSTEM DESCRIPTION >

[INTEGRATED CONTROL SYSTEM]

Control item		Control mode			Control
		SPORT	NORMAL	ECO	
ENGINE	Throttle position characteristic	×	Half open	—	Improves the engine response to acceleration pedal operation and enhances the torque feel.
		—	—	×	Accelerates gently to assist in ECO driving.
	Speed limiter for throttle position	—	—	×	Controls the throttle position to a smaller level than NORMAL to help improve the practical fuel consumption.
TRANSAXLE	High speed gear shift line	×	—	—	Keeps the engine speed at a high level and improves the acceleration dynamism and response.
	Step shift	×	—	—	Performs gear shifting like A/T does.
	Downshift upon braking	×	—	—	performs downshift upon braking before cornering to prevent a drop in the engine speed.
	Cornering ratio hold	×	—	—	Helps the vehicle clear a curve smoothly by restricting shift changes during cornering.
	Acceleration off ratio hold	×	—	—	Quick accelerator pedal release avoids upshifting and maintains constant gear ratio. This brings a direct feel of acceleration when the accelerator pedal is depressed again.
	Low speed gear shift line	—	—	×	Improves the practical fuel economy by controlling the engine speed to a low level.
STEERING	Assist characteristic	×	—	—	Changes the steering assist characteristic to enhance a stable steering feel.
AIR CONDITIONER	Air inlet control	—	—	×	Reduces the engine load by optimizing the air conditioner control to a level that does not adversely affect the interior comfort and thus helps improve the practical fuel economy.
	Blower fan control	—	—	×	

ENGINE, TRANSAXLE, STEERING, AIR CONDITIONER CONTROL

- For details on the engine control, refer to [EC-69, "INTEGRATED CONTROL SYSTEM : System Description"](#) (MR FOR NISMO RS MODELS) or [EC-654, "INTEGRATED CONTROL SYSTEM : System Description"](#) (MR EXCEPT FOR NISMO RS MODELS).
- For details on the transaxle control, refer to [TM-185, "INTEGRATED CONTROL SYSTEM : System Description"](#) (RE0F10B) or [TM-391, "INTEGRATED CONTROL SYSTEM : System Description"](#) (RE0F10D).
- For details on the steering control, refer to [STC-7, "EPS SYSTEM : System Description"](#).
- For details on the air conditioner control, refer to [HAC-19, "ECO Mode Control"](#).

HANDLING PRECAUTION**NISSAN Dynamic Control System**

INFOID:0000000012201598

- The engine torque, engine power, boost pressure, and instantaneous fuel consumption are provided for information purposes only. They are not intended to prompt the driver to adjust driving style. The readings may be slightly delayed relative to the actual vehicle behaviors. This is not a malfunction.
- The voltmeter reading cannot be used as an indicator for battery replacement because it indicates the input voltage to the multi display unit, not the battery voltage.
- The ECO information screen is operable only while the vehicle is stopped.
- If no time setting is performed, the daily and weekly fuel consumption history data are not displayed.
- The readings may differ from the actual values depending on driving conditions.

A

B

C

D

E

F

G

H

I

J

K

L

M

N

DMS

P

ECU DIAGNOSIS INFORMATION**MULTI DISPLAY UNIT**

List of ECU Reference

INFOID:0000000012201599

ECU	Reference
Multi display unit	AV-212, "Reference Value"
	AV-214, "DTC Inspection Priority Chart"
	AV-215, "DTC Index"

INTEGRATED CONTROL SYSTEM

< WIRING DIAGRAM >

[INTEGRATED CONTROL SYSTEM]


WIRING DIAGRAM

INTEGRATED CONTROL SYSTEM

Wiring Diagram

INFOID:000000012857734

INTEGRATED CONTROL SYSTEM



2015/08/18

JRNWF0753GB


DMS

INTEGRATED CONTROL SYSTEM


< WIRING DIAGRAM >

[INTEGRATED CONTROL SYSTEM]

INTEGRATED CONTROL SYSTEM




40	V	MODE DRIVE SIGNAL 1
Connector No.	M68	
Connector Name	BGM (BODY CONTROL MODULE)	
Connector Type	T+40FB-NH	
Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	CAN-L
2	L	CAN-H
4	LG	IGN
Connector No.	M50	
Connector Name	A/C/AUTO AMP	




Terminal No.	Color Of Wire	Signal Name [Specification]
2	GR	COMBI SW INPUT 5
3	BR	COMBI SW INPUT 4
4	G	COMBI SW INPUT 3
5	W	COMBI SW INPUT 1
6	L	KET CYL UNLOCK SW
7	R	STOP LAMP SW 1
8		-
9		-
10	W	DOOR CLK & UNLK SW LOCK
11	GR	DOOR CLK & UNLK SW UNLOCK
12	BR	DOOR CLK & UNLK SW UNLOCK
13		-

Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	CAN_H
2	P	CAN_L
4	V	VEHICLE SPEED SIGNAL (V.PULSE)
5	G	PADDLE SHIFTER UP/SWITCH SIGNAL



Connector No.	F83
Connector Name	TCM
Connector Type	RHD02B-R225-L-RH




JRNWF0755GB

INTEGRATED CONTROL SYSTEM

< WIRING DIAGRAM >

[INTEGRATED CONTROL SYSTEM]

INTEGRATED CONTROL SYSTEM



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	BATTERY POWER SUPPLY
2	V	ILLUMINATION SIGNAL
5	GR	ILLUMINATION CONTROL SIGNAL
6	L	CANH
7	IG	IGNITION SIGNAL
10	B	GROUND
11	B	GROUND
12	P	CANL




The diagram illustrates the M.2 connector's physical layout and pin assignments. It features a central rectangular body with two vertical metal contacts on either side. The top contact is labeled '1' and the bottom contact is labeled '1'. Between the contacts, there are four horizontal pins labeled '2', '3', '4', and '5' from left to right. To the right of the contacts, there is a vertical label '19' above '18' and a horizontal label '77' below them. To the left of the contacts, there is a vertical label '15' above '16' and a horizontal label '77' below them. A small 'hs.' logo is located at the bottom right.



Connector No.	Part No.
12	Y
13	Y
14	Y
15	Y
17	IG
18	R
19	R
20	R



Connector No.	M136	
Connector Name	JOINT CONNECTOR:M07	
Connector Type	NH20PFLDC	
HS		
Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	-
2	P	-
3	P	-
4	P	-
5	P	-
6	P	-
7	P	-



Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	-
2	LG	-
3	LG	-
5	LG	-
7	LG	-
8	LG	-
9	LG	-
10	Y	-



< BASIC INSPECTION >


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000012201601

DESCRIPTION OF TROUBLE DIAGNOSIS FLOWCHART



JSNIA4500GB

DETAILS OF TROUBLE DIAGNOSIS FLOWCHART

1. OBTAIN INFORMATION ABOUT SYMPTOM

Interview the customer to obtain as much information as possible about the conditions and environment under which the malfunction occurs.

>> GO TO 2.

2. CHECK SYMPTOM

- Check the symptom based on the information obtained from the customer.
- Check if any other malfunctions are present.

>> GO TO 3.

3. CONSULT SELF-DIAGNOSIS

1. Perform "MULTI DISPLAY" "self diagnosis" by connecting CONSULT.
2. When DTC is detected, follow the instructions below:
- Record DTC and Freeze Frame Data.

NOTE:

If "CAN COM CIRC [U1000]" is displayed, start the diagnosis from the CAN communication system. Refer to [AV-222, "Diagnosis Procedure"](#).

Is any DTC No. displayed?

- YES >> GO TO 4.
NO >> GO TO 5.

4. DTC/SYSTEM DIAGNOSIS

DMS

P

DIAGNOSIS AND REPAIR WORK FLOW

[INTEGRATED CONTROL SYSTEM]

< BASIC INSPECTION >

1. Perform a DTC/system diagnosis and repair or replace any malfunctioning part.
2. When DTC is detected, follow the instructions below:
 - Record DTC and Freeze Frame Data.

>> GO TO 6.

5. PERFORM DIAGNOSIS BY SYMPTOM

Perform a diagnosis by symptom and repair or replace any malfunctioning part.

>> GO TO 6.

6. FINAL CHECK


Check that the multi display unit functions normally.

Does it operate normally?

- YES >> End of trouble diagnosis
NO >> GO TO 2.

REMOVAL AND INSTALLATION**MULTI DISPLAY UNIT****Exploded View**

INFOID:0000000012201602

REMOVALRefer to [IP-12, "Exploded View"](#).**DISASSEMBLY**

- | | | |
|------------------|-----------------------|------------------|
| 1. Silencer tape | 2. Multi display unit | 3. Silencer tape |
| 4. Clip | 5. Control finisher | |

Removal and Installation

INFOID:0000000012201603

REMOVALRefer to [IP-12, "Exploded View"](#).**CAUTION:**

- When performing the work, use a shop cloth to protect the parts from damage.
- Always fix the harness clamp in position.

INSTALLATION

Install in the reverse order of removal.

DMS

P