

A  
B  
C

# EXL

## SECTION EXL

### EXTERIOR LIGHTING SYSTEM

## CONTENTS

<b>XENON TYPE</b>		D
<b>PRECAUTION</b> .....	<b>TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM</b> .....	F
6	15	
<b>PRECAUTIONS</b> .....	TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : System Diagram .....	G
6	15	
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : System Description .....	H
6	15	
Precaution for Procedure without Cowl Top Cover.....	<b>PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM</b> .....	I
6	16	
Precautions For Xenon Headlamp Service .....	PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM : System Diagram .....	J
6	16	
Precautions for Removing Battery Terminal .....	PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM : System Description.....	K
7	16	
<b>SYSTEM DESCRIPTION</b> .....	PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM : Fail-Safe .....	EXL
8	16	
<b>COMPONENT PARTS</b> .....	<b>FRONT FOG LAMP SYSTEM</b> .....	M
8	17	
<b>EXTERIOR LIGHTING SYSTEM</b> .....	FRONT FOG LAMP SYSTEM : System Diagram.....	N
8	17	
EXTERIOR LIGHTING SYSTEM : Component Parts Location .....	FRONT FOG LAMP SYSTEM : System Description .....	O
8	17	
EXTERIOR LIGHTING SYSTEM : Component Description .....	FRONT FOG LAMP SYSTEM : Fail-Safe .....	P
9	17	
<b>HEADLAMP ASSEMBLY</b> .....	<b>EXTERIOR LAMP BATTERY SAVER SYSTEM</b> .....	
9	17	
HEADLAMP ASSEMBLY : Xenon Headlamp .....	EXTERIOR LAMP BATTERY SAVER SYSTEM : System Diagram .....	
9	18	
HEADLAMP ASSEMBLY : HID control unit .....	EXTERIOR LAMP BATTERY SAVER SYSTEM : System Description .....	
10	18	
<b>SYSTEM</b> .....	<b>DIAGNOSIS SYSTEM (BCM)</b> .....	
11	19	
<b>HEADLAMP SYSTEM</b> .....	<b>COMMON ITEM</b> .....	
11	19	
HEADLAMP SYSTEM : System Diagram .....	COMMON ITEM : CONSULT Function (BCM - COMMON ITEM) .....	
11	19	
HEADLAMP SYSTEM : System Description .....	<b>HEADLAMP</b> .....	
11	20	
HEADLAMP SYSTEM : Fail-Safe .....	HEADLAMP : CONSULT Function (BCM - HEAD LAMP) (XENON TYPE) .....	
12	20	
<b>AUTO LIGHT SYSTEM</b> .....	<b>FLASHER</b> .....	
12	23	
AUTO LIGHT SYSTEM : System Diagram .....	FLASHER : CONSULT Function (BCM - FLASHER) (XENON TYPE) .....	
12	23	
AUTO LIGHT SYSTEM : System Description .....	<b>DIAGNOSIS SYSTEM (IPDM E/R)</b> .....	
12	25	
<b>DAYTIME RUNNING LIGHT SYSTEM</b> .....		
13		
DAYTIME RUNNING LIGHT SYSTEM : System Diagram .....		
14		
DAYTIME RUNNING LIGHT SYSTEM : System Description .....		
14		

Diagnosis Description .....	25	Component Function Check .....	71
CONSULT Function (IPDM E/R) .....	27	Diagnosis Procedure .....	71
<b>ECU DIAGNOSIS INFORMATION .....</b>	<b>30</b>	<b>OPTICAL SENSOR .....</b>	<b>74</b>
<b>BCM, IPDM E/R .....</b>	<b>30</b>	Component Function Check .....	74
List of ECU Reference .....	30	Diagnosis Procedure .....	74
<b>WIRING DIAGRAM .....</b>	<b>31</b>	<b>HAZARD SWITCH .....</b>	<b>77</b>
<b>EXTERIOR LIGHTING SYSTEM .....</b>	<b>31</b>	Component Function Check .....	77
Wiring Diagram .....	31	Diagnosis Procedure .....	77
<b>BASIC INSPECTION .....</b>	<b>47</b>	<b>SYMPTOM DIAGNOSIS .....</b>	<b>79</b>
<b>DIAGNOSIS AND REPAIR WORK FLOW .....</b>	<b>47</b>	<b>EXTERIOR LIGHTING SYSTEM SYMPTOMS..</b>	<b>79</b>
Work Flow .....	47	Symptom Table .....	79
<b>DTC/CIRCUIT DIAGNOSIS .....</b>	<b>50</b>	<b>NORMAL OPERATING CONDITION .....</b>	<b>86</b>
<b>HEADLAMP (HI) CIRCUIT .....</b>	<b>50</b>	Description .....	86
Component Function Check .....	50	<b>BOTH SIDE HEADLAMPS (HI) ARE NOT</b>	
Diagnosis Procedure .....	50	<b>TURNED ON .....</b>	<b>87</b>
Component Inspection .....	52	Description .....	87
<b>HEADLAMP (LO) CIRCUIT .....</b>	<b>53</b>	Diagnosis Procedure .....	87
Component Function Check .....	53	<b>BOTH SIDE HEADLAMPS (LO) ARE NOT</b>	
Diagnosis Procedure .....	53	<b>TURNED ON .....</b>	<b>88</b>
<b>XENON HEADLAMP .....</b>	<b>55</b>	Description .....	88
Diagnosis Procedure .....	55	Diagnosis Procedure .....	88
<b>PARKING LAMP CIRCUIT .....</b>	<b>56</b>	<b>PARKING, LICENSE PLATE, SIDE MARKER</b>	
Component Function Check .....	56	<b>AND TAIL LAMPS ARE NOT TURNED ON ....</b>	<b>89</b>
Diagnosis Procedure .....	56	Description .....	89
<b>FRONT SIDE MARKER LAMP CIRCUIT .....</b>	<b>58</b>	Diagnosis Procedure .....	89
Component Function Check .....	58	<b>BOTH SIDE FRONT FOG LAMPS ARE NOT</b>	
Diagnosis Procedure .....	58	<b>TURNED ON .....</b>	<b>90</b>
<b>TAIL LAMP CIRCUIT .....</b>	<b>60</b>	Description .....	90
Component Function Check .....	60	Diagnosis Procedure .....	90
Diagnosis Procedure .....	60	<b>PERIODIC MAINTENANCE .....</b>	<b>91</b>
<b>LICENSE PLATE LAMP CIRCUIT .....</b>	<b>62</b>	<b>HEADLAMP AIMING ADJUSTMENT .....</b>	<b>91</b>
Component Function Check .....	62	Description .....	91
Diagnosis Procedure .....	62	Aiming Adjustment Procedure .....	91
<b>DAYTIME RUNNING LIGHT RELAY CIRCUIT</b>		<b>FRONT FOG LAMP AIMING ADJUSTMENT ...</b>	<b>93</b>
.....	<b>64</b>	Description .....	93
Component Function Check .....	64	Aiming Adjustment Procedure .....	93
Diagnosis Procedure .....	64	<b>REMOVAL AND INSTALLATION .....</b>	<b>95</b>
Component Inspection .....	65	<b>HEADLAMP .....</b>	<b>95</b>
<b>DAYTIME RUNNING LIGHT CIRCUIT .....</b>	<b>67</b>	Exploded View .....	95
Component Function Check .....	67	Removal and Installation .....	96
Diagnosis Procedure .....	67	Replacement .....	96
<b>FRONT FOG LAMP CIRCUIT .....</b>	<b>69</b>	Disassembly and Assembly .....	97
Component Function Check .....	69	<b>FRONT COMBINATION LAMP .....</b>	<b>99</b>
Diagnosis Procedure .....	69	Exploded View .....	99
<b>TURN SIGNAL LAMP CIRCUIT .....</b>	<b>71</b>	Removal and Installation .....	100
		Replacement .....	100
		Disassembly and Assembly .....	100

<b>DAYTIME RUNNING LIGHT</b> .....	<b>101</b>	Precaution for Procedure without Cowl Top Cover. 119	
Exploded View .....	101	Precautions for Removing Battery Terminal .....	119
Removal and Installation .....	101		
Replacement .....	101		
<b>FRONT FOG LAMP</b> .....	<b>102</b>	<b>SYSTEM DESCRIPTION</b> .....	<b>121</b>
Exploded View .....	102	<b>COMPONENT PARTS</b> .....	<b>121</b>
Removal and Installation .....	102	Component Parts Location .....	121
Replacement .....	103	Component Description .....	122
<b>SIDE TURN SIGNAL LAMP</b> .....	<b>104</b>	<b>SYSTEM</b> .....	<b>123</b>
Exploded View .....	104	<b>HEADLAMP SYSTEM</b> .....	<b>123</b>
Removal and Installation .....	104	HEADLAMP SYSTEM : System Diagram .....	123
Replacement .....	104	HEADLAMP SYSTEM : System Description .....	123
<b>OPTICAL SENSOR</b> .....	<b>105</b>	HEADLAMP SYSTEM : Fail-Safe .....	124
Exploded View .....	105	<b>AUTO LIGHT SYSTEM</b> .....	<b>124</b>
Removal and Installation .....	105	AUTO LIGHT SYSTEM : System Diagram .....	124
<b>LIGHTING &amp; TURN SIGNAL SWITCH</b> .....	<b>106</b>	AUTO LIGHT SYSTEM : System Description .....	124
Removal and Installation .....	106	<b>DAYTIME RUNNING LIGHT SYSTEM</b> .....	<b>125</b>
<b>HAZARD SWITCH</b> .....	<b>107</b>	DAYTIME RUNNING LIGHT SYSTEM : System	
Exploded View .....	107	Diagram .....	126
Removal and Installation .....	107	DAYTIME RUNNING LIGHT SYSTEM : System	
<b>REAR COMBINATION LAMP</b> .....	<b>108</b>	Description .....	126
Exploded View .....	108	<b>TURN SIGNAL AND HAZARD WARNING LAMP</b>	
Removal and Installation .....	109	<b>SYSTEM</b> .....	<b>127</b>
Replacement .....	109	TURN SIGNAL AND HAZARD WARNING LAMP	
<b>HIGH-MOUNTED STOP LAMP</b> .....	<b>111</b>	SYSTEM : System Diagram .....	127
Exploded View .....	111	TURN SIGNAL AND HAZARD WARNING LAMP	
Removal and Installation .....	111	SYSTEM : System Description .....	127
<b>LICENSE PLATE LAMP</b> .....	<b>113</b>	<b>PARKING, LICENSE PLATE, SIDE MARKER AND</b>	
Exploded View .....	113	<b>TAIL LAMP SYSTEM</b> .....	<b>128</b>
Removal and Installation .....	113	PARKING, LICENSE PLATE, SIDE MARKER	
Replacement .....	113	AND TAIL LAMP SYSTEM : System Diagram .....	128
<b>REAR FOG LAMP</b> .....	<b>115</b>	PARKING, LICENSE PLATE, SIDE MARKER	
Exploded View .....	115	AND TAIL LAMP SYSTEM : System Description..	128
Removal and Installation .....	115	PARKING, LICENSE PLATE, SIDE MARKER	
<b>REAR REFLEX REFLECTOR</b> .....	<b>116</b>	AND TAIL LAMP SYSTEM : Fail-Safe .....	128
Exploded View .....	116	<b>FRONT FOG LAMP SYSTEM</b> .....	<b>129</b>
Removal and Installation .....	116	FRONT FOG LAMP SYSTEM : System Diagram..	129
<b>SERVICE DATA AND SPECIFICATIONS</b>		FRONT FOG LAMP SYSTEM : System Descrip-	
<b>(SDS)</b> .....	<b>118</b>	tion .....	129
<b>SERVICE DATA AND SPECIFICATIONS</b>		FRONT FOG LAMP SYSTEM : Fail-Safe .....	129
<b>(SDS)</b> .....	<b>118</b>	<b>EXTERIOR LAMP BATTERY SAVER SYSTEM</b> ....	<b>129</b>
Bulb Specifications .....	118	EXTERIOR LAMP BATTERY SAVER SYSTEM :	
<b>HALOGEN TYPE</b>		System Diagram .....	130
<b>PRECAUTION</b> .....	<b>119</b>	EXTERIOR LAMP BATTERY SAVER SYSTEM :	
<b>PRECAUTIONS</b> .....	<b>119</b>	System Description .....	130
Precaution for Supplemental Restraint System		<b>DIAGNOSIS SYSTEM (BCM)</b> .....	<b>131</b>
(SRS) "AIR BAG" and "SEAT BELT PRE-TEN-		<b>COMMON ITEM</b> .....	<b>131</b>
SIONER" .....	119	COMMON ITEM : CONSULT Function (BCM -	
		COMMON ITEM) .....	131
		<b>HEADLAMP</b> .....	<b>132</b>
		HEADLAMP : CONSULT Function (BCM - HEAD	
		LAMP) (HALOGEN TYPE) .....	132

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

<b>FLASHER</b> .....	<b>135</b>	<b>TURN SIGNAL LAMP CIRCUIT</b> .....	<b>182</b>
FLASHER : CONSULT Function (BCM - FLASH- ER) (HALOGEN TYPE) .....	135	Component Function Check .....	182
<b>DIAGNOSIS SYSTEM (IPDM E/R)</b> .....	<b>137</b>	Diagnosis Procedure .....	182
Diagnosis Description .....	137	<b>OPTICAL SENSOR</b> .....	<b>185</b>
CONSULT Function (IPDM E/R) .....	139	Component Function Check .....	185
<b>ECU DIAGNOSIS INFORMATION</b> .....	<b>142</b>	Diagnosis Procedure .....	185
<b>BCM, IPDM E/R</b> .....	<b>142</b>	<b>HAZARD SWITCH</b> .....	<b>188</b>
List of ECU Reference .....	142	Component Function Check .....	188
<b>WIRING DIAGRAM</b> .....	<b>143</b>	Diagnosis Procedure .....	188
<b>EXTERIOR LIGHTING SYSTEM</b> .....	<b>143</b>	<b>SYMPTOM DIAGNOSIS</b> .....	<b>190</b>
Wiring Diagram .....	143	<b>EXTERIOR LIGHTING SYSTEM SYMPTOMS</b> .....	<b>190</b>
<b>BASIC INSPECTION</b> .....	<b>159</b>	Symptom Table .....	190
<b>DIAGNOSIS AND REPAIR WORK FLOW</b> .....	<b>159</b>	<b>NORMAL OPERATING CONDITION</b> .....	<b>197</b>
Work Flow .....	159	Description .....	197
<b>DTC/CIRCUIT DIAGNOSIS</b> .....	<b>162</b>	<b>BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON</b> .....	<b>198</b>
<b>HEADLAMP (HI) CIRCUIT</b> .....	<b>162</b>	Description .....	198
Component Function Check .....	162	Diagnosis Procedure .....	198
Diagnosis Procedure .....	162	<b>BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON</b> .....	<b>199</b>
Component Inspection .....	164	Description .....	199
<b>HEADLAMP (LO) CIRCUIT</b> .....	<b>165</b>	Diagnosis Procedure .....	199
Component Function Check .....	165	<b>PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS ARE NOT TURNED ON</b> ...	<b>200</b>
Diagnosis Procedure .....	165	Description .....	200
<b>PARKING LAMP CIRCUIT</b> .....	<b>167</b>	Diagnosis Procedure .....	200
Component Function Check .....	167	<b>BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON</b> .....	<b>201</b>
Diagnosis Procedure .....	167	Description .....	201
<b>FRONT SIDE MARKER LAMP CIRCUIT</b> .....	<b>169</b>	Diagnosis Procedure .....	201
Component Function Check .....	169	<b>PERIODIC MAINTENANCE</b> .....	<b>202</b>
Diagnosis Procedure .....	169	<b>HEADLAMP AIMING ADJUSTMENT</b> .....	<b>202</b>
<b>TAIL LAMP CIRCUIT</b> .....	<b>171</b>	Description .....	202
Component Function Check .....	171	Aiming Adjustment Procedure .....	202
Diagnosis Procedure .....	171	<b>FRONT FOG LAMP AIMING ADJUSTMENT</b> ..	<b>204</b>
<b>LICENSE PLATE LAMP CIRCUIT</b> .....	<b>173</b>	Description .....	204
Component Function Check .....	173	Aiming Adjustment Procedure .....	204
Diagnosis Procedure .....	173	<b>REMOVAL AND INSTALLATION</b> .....	<b>206</b>
<b>DAYTIME RUNNING LIGHT RELAY CIRCUIT</b> .....	<b>175</b>	<b>HEADLAMP</b> .....	<b>206</b>
Component Function Check .....	175	Exploded View .....	206
Diagnosis Procedure .....	175	Removal and Installation .....	207
Component Inspection .....	176	Replacement .....	207
<b>DAYTIME RUNNING LIGHT CIRCUIT</b> .....	<b>178</b>	Disassembly and Assembly .....	208
Component Function Check .....	178	<b>FRONT COMBINATION LAMP</b> .....	<b>210</b>
Diagnosis Procedure .....	178	Exploded View .....	210
<b>FRONT FOG LAMP CIRCUIT</b> .....	<b>180</b>	Removal and Installation .....	211
Component Function Check .....	180	Replacement .....	211
Diagnosis Procedure .....	180		

Disassembly and Assembly .....	211	<b>REAR COMBINATION LAMP .....</b>	<b>219</b>	
<b>DAYTIME RUNNING LIGHT .....</b>	<b>212</b>	Exploded View .....	219	A
Exploded View .....	212	Removal and Installation .....	220	
Removal and Installation .....	212	Replacement .....	220	
Replacement .....	212	<b>HIGH-MOUNTED STOP LAMP .....</b>	<b>222</b>	B
<b>FRONT FOG LAMP .....</b>	<b>213</b>	Exploded View .....	222	
Exploded View .....	213	Removal and Installation .....	222	C
Removal and Installation .....	213	<b>LICENSE PLATE LAMP .....</b>	<b>224</b>	
Replacement .....	214	Exploded View .....	224	
<b>SIDE TURN SIGNAL LAMP .....</b>	<b>215</b>	Removal and Installation .....	224	D
Exploded View .....	215	Replacement .....	224	
Removal and Installation .....	215	<b>REAR FOG LAMP .....</b>	<b>226</b>	E
Replacement .....	215	Exploded View .....	226	
<b>OPTICAL SENSOR .....</b>	<b>216</b>	Removal and Installation .....	226	
Exploded View .....	216	<b>REAR REFLEX REFLECTOR .....</b>	<b>227</b>	F
Removal and Installation .....	216	Exploded View .....	227	
<b>LIGHTING &amp; TURN SIGNAL SWITCH .....</b>	<b>217</b>	Removal and Installation .....	227	
Removal and Installation .....	217	<b>SERVICE DATA AND SPECIFICATIONS</b>		G
<b>HAZARD SWITCH .....</b>	<b>218</b>	<b>(SDS) .....</b>	<b>229</b>	
Exploded View .....	218	<b>SERVICE DATA AND SPECIFICATIONS</b>		H
Removal and Installation .....	218	<b>(SDS) .....</b>	<b>229</b>	
		Bulb Specifications .....	229	I
				J
				K
				EXL
				M
				N
				O
				P

# PRECAUTIONS

< PRECAUTION >

[XENON TYPE]

## PRECAUTION

### PRECAUTIONS

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000012201604

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

#### **WARNING:**

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, it is recommended that all maintenance and repair be performed by an authorized NISSAN/INFINITI dealer.
- Improper repair, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**


Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery or batteries, and wait at least 3 minutes before performing any service.

#### Precaution for Procedure without Cowl Top Cover

INFOID:000000012964925

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc to prevent damage to windshield.



#### Precautions For Xenon Headlamp Service

INFOID:000000012201605

#### **WARNING:**

Comply with the following warnings to prevent any serious accident.

- Disconnect the battery cable (negative terminal) or the power supply fuse before installing, removing, or touching the xenon headlamp (bulb included). The xenon headlamp contains high-voltage generated parts.
- Never work with wet hands.
- Check the xenon headlamp ON-OFF status after assembling it to the vehicle. Never turn the xenon headlamp ON in other conditions. Connect the power supply to the vehicle-side connector.

# PRECAUTIONS

< PRECAUTION >

[XENON TYPE]

(Turning it ON outside the lamp case may cause fire or visual impairments.)

- Never touch the bulb glass immediately after turning it OFF. It is extremely hot.

**CAUTION:**

Comply with the following cautions to prevent any error and malfunction.

- Install the xenon bulb securely. (Insufficient bulb socket installation may melt the bulb, the connector, the housing, etc. by high-voltage leakage or corona discharge.)
- Never perform HID circuit inspection with a tester.
- Never touch the xenon bulb glass with hands. Never put oil and grease on it.
- Dispose of the used xenon bulb after packing it in thick vinyl without breaking it.
- Never wipe out dirt and contamination with organic solvent (thinner, gasoline, etc.).


## Precautions for Removing Battery Terminal

INFOID:000000012964926

When disconnecting the battery terminal, pay attention to the following.

- Always use a 12V battery as power source.
- Never disconnect battery terminal while engine is running.
- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.
- For vehicles with the engine listed below, remove the battery terminal after a lapse of the specified time:

D4D engine	: 20 minutes	YS23DDT	: 4 minutes
HRA2DDT	: 12 minutes	YS23DDTT	: 4 minutes
K9K engine	: 4 minutes	ZD30DDTi	: 60 seconds
M9R engine	: 4 minutes	ZD30DDTT	: 60 seconds
R9M engine	: 4 minutes		
V9X engine	: 4 minutes		
YD25DDTi	: 2 minutes		



**NOTE:**

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- After high-load driving, if the vehicle is equipped with the V9X engine, turn the ignition switch OFF and wait for at least 15 minutes to remove the battery terminal.

**NOTE:**

- Turbocharger cooling pump may operate in a few minutes after the ignition switch is turned OFF.
- Example of high-load driving
  - Driving for 30 minutes or more at 140 km/h (86 MPH) or more.
  - Driving for 30 minutes or more on a steep slope.
- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.

**NOTE:**

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

**NOTE:**

The removal of 12V battery may cause a DTC detection error.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P


## SYSTEM DESCRIPTION

### COMPONENT PARTS

#### EXTERIOR LIGHTING SYSTEM

#### EXTERIOR LIGHTING SYSTEM : Component Parts Location

INFOID:000000012201607



- |   |  |   |
|---|--|---|
| 1. Hazard switch  | 2. Front turn signal lamp  | 3. Front side marker lamp   |
| 4. Parking lamp   | 5. Front fog lamp*1  | 6. Headlamp LO (Xenon headlamp)   |
|   | ECM*2<br>Refer to <a href="#">EC-27. "ENGINE CONTROL SYSTEM : Component Parts Location"</a> (NISMO RS models) or <a href="#">EC-600. "ENGINE CONTROL SYSTEM : Component Parts Location"</a> (Except for NISMO RS models).                    |   |
| 7. Headlamp HI (Halogen headlamp)   | 8. <a href="#">ECM*2</a><br>Refer to <a href="#">EC-27. "ENGINE CONTROL SYSTEM : Component Parts Location"</a> (NISMO RS models) or <a href="#">EC-600. "ENGINE CONTROL SYSTEM : Component Parts Location"</a> (Except for NISMO RS models). | 9. IPDM E/R<br>Refer to <a href="#">PCS-5. "Component Parts Location"</a> . |
|   | BCM<br>Refer to <a href="#">BCS-5. "BODY CONTROL SYSTEM : Component Parts Location"</a> .  |   |
| 10. <a href="#">BCM</a><br>Refer to <a href="#">BCS-5. "BODY CONTROL SYSTEM : Component Parts Location"</a> . | 11. Combination switch   | 12. Combination meter   |
| 13. Optical sensor*3  | 14. Side turn signal lamp  | 15. Front door switch (driver side)   |
| 16. Stop lamp / Tail lamp   | 17. Rear turn signal lamp  | 18. Tail lamp   |
| 19. License plate lamp  | 20. Daytime running light relay*4  | 21. HID control unit  |
| A. Engine room (RH)   | B. Headlamp (back)   |   |

\*1: With front fog lamp



# COMPONENT PARTS

[XENON TYPE]

< SYSTEM DESCRIPTION >

\*2: With daytime running light system

\*3: With auto light system

\*4: Except for NISMO models with daytime running light system

## EXTERIOR LIGHTING SYSTEM : Component Description

INFOID:000000012201608

Part	Description
BCM	<ul style="list-style-type: none"> <li>• Detects each switch condition by the combination switch reading function</li> <li>• Judges that the headlamp is turned ON according to the vehicle condition</li> <li>• Requests the headlamp relay (High/Low) ON to IPDM E/R (via CAN communication)</li> <li>• Requests the high beam indicator lamp and position lamp indicator lamp ON to the combination meter (via CAN communication)</li> <li>• Judges the outside brightness from the optical sensor signal.</li> <li>• Judges the ON/OFF status of the exterior lamp from the outside brightness and the vehicle condition.</li> </ul>
IPDM E/R	Controls the integrated relay and daytime running light relay, and supplies voltage to the load according to the request from BCM (via CAN communication).
Combination meter	<ul style="list-style-type: none"> <li>• Turns the high beam indicator lamp and position lamp indicator lamp ON according to the request from BCM (via CAN communication).</li> <li>• Blinks the turn signal indicator lamp and outputs the turn signal operating sound with integrated buzzer according to the request from BCM (via CAN communication).</li> <li>• Combination meter transmits parking brake switch signal to BCM via CAN communication.</li> </ul>
ECM*1	ECM transmits engine status signal to BCM via CAN communication.
Headlamp assembly	HID control unit Refer to <a href="#">EXL-10. "HEADLAMP ASSEMBLY : HID control unit"</a> .
	Xenon headlamp Refer to <a href="#">EXL-9. "HEADLAMP ASSEMBLY : Xenon Headlamp"</a> .
Optical sensor*2	Optical sensor converts the outside brightness (lux) to voltage and transmits the optical sensor signal to BCM.
Door switch	Refer to <a href="#">DLK-10. "Component Description"</a> .
Combination switch (Lighting & turn signal switch)	Refer to <a href="#">BCS-8. "COMBINATION SWITCH READING SYSTEM : System Description"</a> .
Hazard switch	Inputs the hazard switch ON/OFF signal to BCM.

\*1: With daytime running light system

\*2: With auto light system

## HEADLAMP ASSEMBLY

### HEADLAMP ASSEMBLY : Xenon Headlamp

INFOID:000000012201609

#### OUTLINE

- The lamp light source is by the arch discharge by applying high voltage into the xenon gas-filled bulb instead of the halogen bulb filament.
- Sight becomes more natural and brighter because the amount of light are gained adequately and the color of light is sunshine-like white.
- The xenon bulb drops the amount of light, repeats blinking, and illuminates in red if the bulb reaches the service life.

#### ILLUMINATION PRINCIPLE

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

## COMPONENT PARTS


### < SYSTEM DESCRIPTION >

[XENON TYPE]

1. Discharging starts in high voltage pulse between bulb electrodes.
2. Xenon gas is activated by current between electrodes. Pale light is emitted.
3. The luminous tube (bulb) temperature elevates. Evaporated halide is activated by discharge. The color of light changes into white.

#### NOTE:

- Brightness and the color of light may change slightly immediately after the headlamp turned ON until the xenon bulb becomes stable. This is not malfunction.
- Illumination time lag may occur between right and left. This is not malfunction.



### PRECAUTIONS FOR TROUBLE DIAGNOSIS

Representative malfunction examples are; "Light does not turn ON", "Light blinks", and "Brightness is inadequate." The cause often be the xenon bulb. Such malfunctions, however, are occurred occasionally by HID control unit malfunction or lamp case malfunction. Specify the malfunctioning part with diagnosis procedure.

#### WARNING:

- **Never touch the harness, HID control unit, the inside and metal part of lamp when turning the headlamp ON or operating the lighting switch.**
- **Never work with wet hands.**

#### CAUTION:

- **Never perform HID control unit circuit diagnosis with a circuit tester or an equivalent.**
- **Temporarily install the headlamps on the vehicle. Connect the battery to the connector (vehicle side) when checking ON/OFF status.**
- **Disconnect the battery negative terminal before disconnecting the lamp socket connector or the harness connector.**
- **Check for blown (open) of the fusible link(s), open around connector, short, disconnection if the symptom is caused by electric error.**

#### NOTE:

- Turn the switch OFF once before turning ON, if the ON/OFF is inoperative.
- The xenon bulb drops the amount of light, repeats blinking, and illuminates in red if the bulb reaches the service life.

### HEADLAMP ASSEMBLY : HID control unit

INFOID:000000012201610


Headlamp (LO) circuit is connected to HID control unit integrated in the headlamp. Headlamp (LO) circuit turns xenon headlamp ON.

For the details of HID control unit and the xenon headlamp, refer to [EXL-9, "HEADLAMP ASSEMBLY : Xenon Headlamp"](#).

SYSTEM

HEADLAMP SYSTEM

HEADLAMP SYSTEM : System Diagram



HEADLAMP SYSTEM : System Description

INFOID:0000000012201612

OUTLINE

Headlamp is controlled by combination switch reading function and headlamp control function of BCM, and relay control function of IPDM E/R.

HEADLAMP (LO) OPERATION

- BCM detects the combination switch condition with the combination switch reading function.
- BCM transmits the low beam request signal to IPDM E/R via CAN communication according to the headlamp (LO) ON condition.

Headlamp (LO) ON condition

- Lighting switch 2ND
- Lighting switch AUTO (Only when the illumination judgment by auto light system is ON. For details, refer to [EXL-12, "AUTO LIGHT SYSTEM : System Description"](#).)
- Lighting switch PASS
- IPDM E/R turns the integrated headlamp low relay ON, and turns the headlamp (LO) ON according to the low beam request signal.

HEADLAMP (HI) OPERATION

- BCM transmits the high beam request signal to IPDM E/R and the combination meter via CAN communication according to the headlamp (HI) ON condition.

Headlamp (HI) ON condition

- Lighting switch HI with the lighting switch 2ND
- Lighting switch HI with the lighting switch AUTO (Only when the illumination judgment by auto light system is ON. For details, refer to [EXL-12, "AUTO LIGHT SYSTEM : System Description"](#).)
- Lighting switch PASS
- Combination meter turns the high beam indicator lamp ON according to the high beam request signal.
- IPDM E/R turns the integrated headlamp high relay ON, and turns the headlamp (HI) ON according to the high beam request signal.

FOLLOW ME HOME FUNCTION

When the driver is moving to the house entrance from the own vehicle, headlamp is kept still ON by the follow me home function of BCM.

- When BCM detects the input of lighting switch PASS while all of following conditions satisfied, it transmits the low beam request signal for a period of time to IPDM E/R through CAN communication.

Follow me home ON condition

- Ignition switch OFF

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# SYSTEM

[XENON TYPE]

## < SYSTEM DESCRIPTION >

- Lighting switch OFF
- IPDM E/R turns the integrated headlamp low relay ON, and turns the headlamp (LO) ON according to the low beam request signal.
- When in any of following conditions, follow me home function can be cancelled while follow me home function is operating.

Follow me home OFF condition

- Ignition switch is turned from OFF→ACC or ON
- Lighting switch is turned from OFF→ON

### NOTE:

- Flash-to-pass operation illumination time for 1 time can be extended to approximately 30 seconds during operation of follow me home function.
- Flash-to-pass operation can be illuminated continuously for approximately 60 seconds (flash-to-pass operation, 2 times), approximately 90 seconds (flash-to-pass operation, 3 times), and a maximum of approximately 120 seconds (flash-to-pass operation, 4 times).
- Follow me home function activating time can be set by CONSULT. Refer to [EXL-20, "HEADLAMP : CONSULT Function \(BCM - HEAD LAMP\) \(XENON TYPE\)"](#).

## HEADLAMP SYSTEM : Fail-Safe

INFOID:000000012201613

### CAN COMMUNICATION CONTROL

When CAN communication with BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.


If No CAN Communication Is Available With BCM

Control part	Fail-safe operation
Headlamp	<ul style="list-style-type: none"> <li>• Turns ON the headlamp low relay when the ignition switch is turned ON</li> <li>• Turns OFF the headlamp low relay when the ignition switch is turned OFF</li> <li>• Headlamp high relay OFF</li> </ul>

## AUTO LIGHT SYSTEM

### AUTO LIGHT SYSTEM : System Diagram

INFOID:000000012201614



### AUTO LIGHT SYSTEM : System Description

INFOID:000000012201615

#### OUTLINE

- Auto light system is controlled by each function of BCM and IPDM E/R.

Control by BCM

- Combination switch reading function
- Headlamp control function

## &lt; SYSTEM DESCRIPTION &gt;

- Auto light function
- Delay timer function
- Wiper linked auto lighting function

Control by IPDM E/R

- Relay control function
- Auto light system has the auto light function (with twilight lighting function), wiper linked auto lighting function and delay timer function.
- Auto light function automatically turns ON/OFF the exterior lamps\* and each illumination automatically, depending on the outside brightness.
- Wiper linked auto lighting function automatically turns ON/OFF the exterior lamps\* and each illumination when the light switch is in the AUTO position, according to a front wiper operation.
- When auto light system turns the exterior lamps ON with the ignition switch OFF, delay timer function turns the exterior lamps OFF, depending on the vehicle condition with the auto light function after a certain period of time.

\*: Headlamp (LO/HI), front fog lamp, parking lamp, license plate lamp, tail lamp and side marker lamp (Headlamp HI and front fog lamp depend on the combination switch condition.)

**NOTE:**

The settings of the twilight lighting function and the wiper linked auto lighting function can be changed with CONSULT. Refer to [EXL-20. "HEADLAMP : CONSULT Function \(BCM - HEAD LAMP\) \(XENON TYPE\)".](#)

## AUTO LIGHT FUNCTION (WITH TWILIGHT LIGHTING FUNCTION)

Description

- BCM detects the combination switch condition with the combination switch reading function.
- BCM supplies voltage to the optical sensor when the ignition switch is turned ON.
- Optical sensor converts outside brightness (lux) to voltage and transmits the optical sensor signal to BCM.
- BCM filters outside brightness based on the optical sensor signal and judges outside brightness.
- BCM detects change status of outside brightness according to outside brightness from the optical sensor signal and filtered outside brightness. Based on the change status, BCM judges ON/OFF condition of the exterior lamp.
- BCM transmits each request signal to IPDM E/R and combination meter via CAN communication, according to ON/OFF condition by the auto light function.

**NOTE:**

As to ON/OFF timing, the sensitivity depends on settings. The settings can be changed with CONSULT. Refer to [EXL-20. "HEADLAMP : CONSULT Function \(BCM - HEAD LAMP\) \(XENON TYPE\)".](#)

## DELAY TIMER FUNCTION

- BCM turns the headlamp (LO) OFF depending on the vehicle condition with the auto light function when the ignition switch is turned OFF.
- Turns the headlamp (LO) OFF 5 minutes after the ignition switch is turned OFF.
- Turns the headlamp (LO) OFF 5 minutes after detecting that any door opens. (Door switch ON).
- Turns the headlamp (LO) OFF a certain period of time\* after closing all doors. (Door switch ON → OFF).
- Delay timer function turns OFF, when the ignition switch is other than OFF or the lighting switch is other than AUTO.

\*: The preset time is 45 seconds. The timer operating time can be set by CONSULT. Refer to [EXL-20. "HEAD-LAMP : CONSULT Function \(BCM - HEAD LAMP\) \(XENON TYPE\)".](#)

**NOTE:**

When any position other than the lighting switch AUTO is set, the auto light system function switches to the exterior lamp battery saver function.

## WIPER LINKED AUTO LIGHTING FUNCTION

BCM turns the exterior lamps ON when detecting 4 operations of the front wiper work the light switch in AUTO position.

**NOTE:**

BCM turns OFF the headlamps 3 seconds after the front wiper switch is turned from ON⇒OFF.

## DAYTIME RUNNING LIGHT SYSTEM

# SYSTEM


< SYSTEM DESCRIPTION >

[XENON TYPE]


## DAYTIME RUNNING LIGHT SYSTEM : System Diagram

INFOID:000000012201616

EXCEPT FOR NISMO MODELS



NISMO MODELS



## DAYTIME RUNNING LIGHT SYSTEM : System Description

INFOID:000000012201617

### OUTLINE

Except for NISMO Models

- Turns the headlamp (HI) ON [Headlamp (HI) at approximately half illumination] as the daytime running light.
- Daytime running light is controlled by daytime running light control function and combination switch reading function of BCM, and relay control function of IPDM E/R.

NISMO Models

Daytime running light is controlled by daytime running light control function and combination switch reading function of BCM, and relay control function of IPDM E/R.

### DAYTIME RUNNING LIGHT OPERATION

Except for NISMO Models

- BCM detects the combination switch condition by the combination switch reading function.
- BCM detects vehicle condition depending on the following signals.
  - Engine status signal (received from ECM via CAN communication)
  - Parking brake switch signal (received from combination meter via CAN communication)
- BCM transmits the daytime running light request signal to IPDM E/R via CAN communication according to the daytime running light ON condition.

Daytime running light ON condition

- Engine running with the parking brake released, and any following conditions are satisfied.

# SYSTEM

< SYSTEM DESCRIPTION >

[XENON TYPE]

- Lighting switch OFF
- Lighting switch 1ST
- IPDM E/R controls the daytime running light relay (ground-side) to turn ON according to the daytime running light request signal.
- Power is supplied from the daytime running light relay through headlamp high RH and IPDM E/R to headlamp high LH. And high beam headlamps are illuminated (approximately half illumination) as the daytime running light.

## NISMO Models


- BCM detects the combination switch condition by the combination switch reading function.
- BCM detects vehicle condition depending on the following signals.
  - Engine status signal (received from ECM via CAN communication)
  - Parking brake switch signal (received from combination meter via CAN communication)
- BCM transmits the daytime running light request signal to IPDM E/R via CAN communication according to the daytime running light ON condition.

## Daytime running light ON condition

- Engine running with the parking brake released, and any following conditions are satisfied.
  - Lighting switch OFF
  - Lighting switch 1ST
  - IPDM E/R turns the integrated daytime running light relay ON, and turns the daytime running light ON according to the daytime running light request signal.

## TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

### TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : System Diagram



### TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : System Description

INFOID:000000012201619

## OUTLINE

Turn signal lamp and hazard warning lamp is controlled by combination switch reading function and the flasher control function of BCM.

## TURN SIGNAL LAMP OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM supplies voltage to the right (left) turn signal lamp circuit when the ignition switch is ON and the turn signal switch is in the right (left) position. BCM blinks the turn signal lamp.

## HAZARD WARNING LAMP OPERATION

BCM supplies voltage to both turn signal lamp circuits when the hazard switch is ON. BCM blinks the hazard warning lamp.

## TURN SIGNAL INDICATOR LAMP AND TURN SIGNAL SOUND OPERATION

- BCM transmits the turn indicator signal to the combination meter using CAN communication while the turn signal lamp and the hazard warning lamp are operating.

# SYSTEM

[XENON TYPE]

## < SYSTEM DESCRIPTION >

- Combination meter outputs the turn signal sound with the integrated buzzer while blinking the turn signal indicator lamp according to the turn indicator signal.

### 3-TIME FLASHER FUNCTION

- By a short touch of the turn signal lever, BCM blinks the turn signal lamps 3 times in the selected direction.
- Cancels the operation when short touch of the turn signal lever in the reverse direction during the 3-time flasher function operation.

### HIGH FLASHER OPERATION


- BCM detects the turn signal lamp circuit status from the current value.
- BCM increases the turn signal lamp blinking speed if the bulb or harness open is detected with the turn signal lamp operating.

#### NOTE:

The blinking speed is normal while operating the hazard warning lamp.

## PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM

### PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM : System Diagram



### PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM : System Description

INFOID:000000012201621

#### OUTLINE

Parking, license plate, side marker and tail lamps are controlled by combination switch reading function and parking, license plate, side marker and tail lamps control function of BCM, and relay control function of IPDM E/R.

#### PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits the position light request signal to IPDM E/R and the combination meter via CAN communication according to the parking, license plate, side marker and tail lamps ON condition.

Parking, license plate, side marker and tail lamps ON condition (When any of the following conditions are satisfied)

- Lighting switch 1ST
- Lighting switch 2ND
- Lighting switch AUTO (Only when the illumination judgment by auto light system is ON. For details, refer to [EXL-12, "AUTO LIGHT SYSTEM : System Description".](#))
- IPDM E/R turns the integrated tail lamp relay ON and turns the parking, license plate and tail lamps ON according to the position light request signal.
- Combination meter turns the tail lamp indicator lamp ON according to the position light request signal.

### PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM : Fail-Safe

INFOID:000000012201622

#### CAN COMMUNICATION CONTROL



# SYSTEM

## < SYSTEM DESCRIPTION >

[XENON TYPE]


When CAN communication with BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If No CAN Communication Is Available With BCM

Control part	Fail-safe operation
<ul style="list-style-type: none"> <li>• Parking lamp</li> <li>• License plate lamp</li> <li>• Tail lamp</li> </ul>	<ul style="list-style-type: none"> <li>• Turns ON the tail lamp relay when the ignition switch is turned ON</li> <li>• Turns OFF the tail lamp relay when the ignition switch is turned OFF</li> </ul>

## FRONT FOG LAMP SYSTEM

### FRONT FOG LAMP SYSTEM : System Diagram



### FRONT FOG LAMP SYSTEM : System Description

INFOID:0000000012201624

#### OUTLINE

Front fog lamp is controlled by combination switch reading function and front fog lamp control function of BCM, and relay control function of IPDM E/R.

#### FRONT FOG LAMP OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits the front fog light request signal to IPDM E/R via CAN communication according to the front fog lamp ON condition.

Front fog lamp ON condition

- Front fog lamp switch ON, and any of the following conditions are satisfied. [Except headlamp (HI) ON condition]

- Lighting switch 2ND
- Lighting switch AUTO (Only when the illumination judgment by auto light system is ON. For details, refer to [EXL-12. "AUTO LIGHT SYSTEM : System Description".](#))
- IPDM E/R turns the integrated front fog lamp relay ON, and turns the front fog lamp ON according to the front fog light request signal.

### FRONT FOG LAMP SYSTEM : Fail-Safe

INFOID:0000000012201625

#### CAN COMMUNICATION CONTROL

When CAN communication with ECM and BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If No CAN Communication Is Available With BCM

Control part	Fail-safe operation
Front fog lamp	Front fog lamp relay OFF

## EXTERIOR LAMP BATTERY SAVER SYSTEM


# SYSTEM

< SYSTEM DESCRIPTION >

[XENON TYPE]

## EXTERIOR LAMP BATTERY SAVER SYSTEM : System Diagram

INFOID:000000012201626



## EXTERIOR LAMP BATTERY SAVER SYSTEM : System Description

INFOID:000000012201627

### OUTLINE

- Exterior lamp battery saver system is controlled by combination switch reading function and exterior lamp battery saver function of BCM, and relay control function of IPDM E/R.
  - BCM turns the exterior lamp\* OFF, according to the vehicle status when ignition switch is turned OFF while exterior lamp is ON, for preventing battery discharge.
- \*: Headlamp (LO/HI), front fog lamp, parking lamp, license plate lamp, side marker lamp and tail lamp

### EXTERIOR LAMP BATTERY SAVER ACTIVATION

- BCM activates the timer and turns the exterior lamp OFF 45 seconds after the ignition switch is turned from ON → OFF with the exterior lamps ON.
- When in any of following conditions (after the exterior lamp battery saver is activated), exterior lamps can be turned ON.
  - Ignition switch is turned from OFF → ON
  - Lighting switch is changed
  - Front fog lamp switch is changed

# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[XENON TYPE]

## DIAGNOSIS SYSTEM (BCM)

### COMMON ITEM

### COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000012962262

### APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
Work Support	Changes the setting for each system function.
Self Diagnostic Result	Displays the diagnosis results judged by BCM.
CAN Diag Support Monitor	Monitors the reception status of CAN communication viewed from BCM.
Data Monitor	The BCM input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from BCM.
Ecu Identification	The BCM part number is displayed.
Configuration	<ul style="list-style-type: none"> <li>Read and save the vehicle specification.</li> <li>Write the vehicle specification when replacing BCM.</li> </ul>

### SYSTEM APPLICATION

BCM can perform the following functions for each system.

#### NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

×: Applicable item

System	Sub system selection item	Diagnosis mode		
		Work Support	Data Monitor	Active Test
Door lock	DOOR LOCK	×	×	×
Rear window defogger	REAR DEFOGGER		×	×
Warning chime	BUZZER		×	×
Interior room lamp timer	INT LAMP	×	×	×
Exterior lamp	HEAD LAMP	×	×	×
Wiper and washer	WIPER	×	×	×
Turn signal and hazard warning lamps	FLASHER	×	×	×
Air conditioning system	AIR CONDITONER		×	×*
<ul style="list-style-type: none"> <li>Intelligent Key system</li> <li>Engine start system</li> </ul>	INTELLIGENT KEY	×	×	×
Combination switch	COMB SW		×	
Body control system	BCM	×		
NVIS - NATS	IMMU	×	×	×
Interior room lamp battery saver	BATTERY SAVER	×	×	×
Back door open	TRUNK		×	
Theft warning alarm	THEFT ALM	×	×	×
RAP	RETAINED PWR		×	
Signal buffer system	SIGNAL BUFFER		×	×
TPMS	AIR PRESSURE MONITOR	×	×	×

#### NOTE:

\*: For models with automatic A/C, this diagnosis mode is not used.

### FREEZE FRAME DATA (FFD)

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays on CONSULT.

# DIAGNOSIS SYSTEM (BCM)

[XENON TYPE]

< SYSTEM DESCRIPTION >

CONSULT screen item	Indication/Unit	Description	
Vehicle Speed	km/h	Vehicle speed of the moment a particular DTC is detected	
Odo/Trip Meter	km	Total mileage (Odometer value) of the moment a particular DTC is detected	
Vehicle Condition	SLEEP>LOCK	Power position status of the moment a particular DTC is detected	While turning BCM status from low power consumption mode to normal mode (Power position is "LOCK"*.)
	SLEEP>OFF		While turning BCM status from low power consumption mode to normal mode (Power position is "OFF".)
	LOCK>ACC		While turning power position from "LOCK"* to "ACC"
	ACC>ON		While turning power position from "ACC" to "IGN"
	RUN>ACC		While turning power position from "RUN" to "ACC" (Vehicle is stopping and selector lever is except P position.)
	CRANK>RUN		While turning power position from "CRANKING" to "RUN" (From cranking up the engine to run it)
	RUN>URGENT		While turning power position from "RUN" to "ACC" (Emergency stop operation)
	ACC>OFF		While turning power position from "ACC" to "OFF"
	OFF>LOCK		While turning power position from "OFF" to "LOCK"*
	OFF>ACC		While turning power position from "OFF" to "ACC"
	ON>CRANK		While turning power position from "IGN" to "CRANKING"
	OFF>SLEEP		While turning BCM status from normal mode (Power position is "OFF".) to low power consumption mode
	LOCK>SLEEP		While turning BCM status from normal mode (Power position is "LOCK"*. ) to low power consumption mode
	LOCK		Power position is "LOCK"*
	OFF		Power position is "OFF" (Ignition switch OFF)
	ACC		Power position is "ACC" (Ignition switch ACC)
	ON		Power position is "IGN" (Ignition switch ON with engine stopped)
ENGINE RUN	Power position is "RUN" (Ignition switch ON with engine running)		
CRANKING	Power position is "CRANKING" (At engine cranking)		
IGN Counter	0 - 39	The number of times that ignition switch is turned ON after DTC is detected <ul style="list-style-type: none"> <li>• The number is 0 when a malfunction is detected now.</li> <li>• The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON.</li> <li>• The number is fixed to 39 until the self-diagnosis results are erased if it is over 39.</li> </ul>	

**NOTE:**

\*: Power position shifts to "LOCK" from "OFF", when ignition switch is in the OFF position, selector lever is in the P position (A/T models and CVT models), and any of the following conditions are met.

- Closing door
- Opening door
- Door is locked using door request switch
- Door is locked using Intelligent Key

The power position shifts to "ACC" when the push-button ignition switch (push switch) is pushed at "LOCK".

## HEADLAMP

### HEADLAMP : CONSULT Function (BCM - HEAD LAMP) (XENON TYPE)

INFOID:000000012201629

### WORK SUPPORT

# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[XENON TYPE]

Service item	Setting item	Setting	
CUSTOM A/LIGHT SETTING* <sup>1</sup>	MODE1* <sup>2</sup>	Normal	A
	MODE2	More sensitive setting than normal setting (Turns ON earlier than normal operation)	B
	MODE3	More sensitive setting than MODE2 (Turns ON earlier than MODE2)	
	MODE4	Less sensitive setting than normal setting (Turns ON later than normal operation)	
BATTERY SAVER SET	On* <sup>2</sup>	With the exterior lamp battery saver function	C
	Off	Without the exterior lamp battery saver function	
ILL DELAY SET* <sup>1</sup>	MODE1* <sup>2</sup>	45 sec.	D
	MODE2	Without the function	
	MODE3	30 sec.	E
	MODE4	60 sec.	
	MODE5	90 sec.	F
	MODE6	120 sec.	
	MODE7	150 sec.	G
	MODE8	180 sec.	
HEAD LIGHT TIMER	MODE1	10 sec.	H
	MODE2* <sup>2</sup>	30 sec.	
AUTO LIGHT LOGIC SET* <sup>1</sup>	MODE1* <sup>2</sup>	With twilight ON custom & with wiper INT, LO and HI	I
	MODE2	With twilight ON custom & with wiper LO and HI	
	MODE3	With twilight ON custom & without	J
	MODE4	Without twilight ON custom & with wiper INT, LO and HI	
	MODE5	Without twilight ON custom & with wiper LO and HI	K
	MODE6	Without twilight ON custom & without	

\*<sup>1</sup>: For models without auto light system, this item cannot be used.

\*<sup>2</sup>: Factory setting

## DATA MONITOR

### NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

EXL

Monitor item [Unit]	Description	
PUSH SW [On/Off]	Indicates [On/Off] condition of push-button ignition switch	M
ENGINE STATE [STOP/STALL/CRANK/RUN]	Indicates [STOP/STALL/CRANK/RUN] condition of engine states	N
VEH SPEED 1 [km/h]	Display the vehicle speed signal received from combination meter by numerical value [km/h]	O

P

# DIAGNOSIS SYSTEM (BCM)

[XENON TYPE]

## < SYSTEM DESCRIPTION >

Monitor item [Unit]	Description
TURN SIGNAL R [On/Off]	Each switch status that BCM judges from the combination switch reading function
TURN SIGNAL L [On/Off]	
TAIL LAMP SW [On/Off]	
HI BEAM SW [On/Off]	
HEAD LAMP SW 1 [On/Off]	
HEAD LAMP SW 2 [On/Off]	
PASSING SW [On/Off]	
AUTO LIGHT SW*1 [On/Off]	
FR FOG SW*2 [On/Off]	
DOOR SW-DR [On/Off]	Indicated [On/Off] condition of front door switch (driver side)
DOOR SW-AS [On/Off]	Indicated [On/Off] condition of front door switch (passenger side)
DOOR SW-RR [On/Off]	Indicated [On/Off] condition of rear door switch RH
DOOR SW-RL [On/Off]	Indicated [On/Off] condition of rear door switch LH
DOOR SW-BK [On/Off]	Indicated [On/Off] condition of back door switch
OPTI SEN (DTCT) [V]	The value of outside brightness voltage input from the optical sensor
OPTI SEN (FILT) [V]	The value of outside brightness voltage filtered by BCM
OPTICAL SENSOR [On/Off/NG]	<b>NOTE:</b> This item cannot be monitored

\*1: For models without auto light system, this item cannot be monitored.

\*2: For models without front fog lamp, this item cannot be monitored.

## ACTIVE TEST

Test item	Operation	Description
TAIL LAMP	On	<ul style="list-style-type: none"> <li>• Transmits the position light request signal to IPDM E/R via CAN communication to turn the parking, license plate and tail lamps ON</li> <li>• Transmits the position light request signal to combination meter via CAN communication to turn the position lamp indicator lamp ON</li> </ul>
	Off	Stops the position light request signal transmission
HEAD LAMP	HI	<ul style="list-style-type: none"> <li>• Transmits the high beam request signal to IPDM E/R via CAN communication to turn the headlamp (HI) ON</li> <li>• Transmits the high beam request signal to combination meter via CAN communication to turn the high beam indicator lamp ON</li> </ul>
	Low	Transmits the low beam request signal to IPDM E/R via CAN communication to turn the headlamp (LO) ON
	Off	Stops the high beam request signal and low beam request signal transmission

# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[XENON TYPE]

Test item	Operation	Description
FR FOG LAMP*1	On	<ul style="list-style-type: none"> <li>Transmits the front fog light request signal to IPDM E/R via CAN communication to turn the front fog lamp ON (With front fog lamp)</li> <li>Transmits the daytime running light request signal to IPDM E/R via CAN communication to turn the daytime running light ON (NISMO models with daytime running light system)</li> </ul>
	Off	<ul style="list-style-type: none"> <li>Stops the front fog light request signal transmission (With front fog lamp)</li> <li>Stops the front fog light request signal transmission (NISMO models with daytime running light system)</li> </ul>
DAYTIME RUNNING LIGHT*2	On	Transmits the daytime running light request signal to IPDM E/R via CAN communication to turn the headlamp (HI) ON [Headlamp (HI) at approximately half illumination]
	Off	Stops the daytime running light request signal transmission
ILL DIM SIGNAL	On	<b>NOTE:</b> This item cannot be tested
	Off	

\*1: For models without front fog lamp and except for NISMO models with daytime running light system, this item cannot be tested.

\*2: For models without daytime running light system and NISMO models with daytime running light system, this item cannot be tested.

## FLASHER

### FLASHER : CONSULT Function (BCM - FLASHER) (XENON TYPE)

INFOID:000000012201630

#### WORK SUPPORT

Service item	Setting item	Setting	
HAZARD ANSWER BACK	Lock Only	With locking only	Sets the hazard warning lamp answer back function when the door is lock/unlock with the door request switch and Intelligent Key
	Unlock Only	With unlocking only	
	Lock/Unlock*	With locking/unlocking	
	Off	Without the function	

\*: Factory setting

#### DATA MONITOR

##### NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor item [Unit]	Description
REQ SW -DR [On/Off]	Indicates [On/Off] condition of door request switch (driver side)
REQ SW -AS [On/Off]	Indicates [On/Off] condition of door request switch (passenger side)
PUSH SW [On/Off]	Indicates [On/Off] condition of push-button ignition switch
TURN SIGNAL R [On/Off]	Each switch status that BCM detects from the combination switch reading function
TURN SIGNAL L [On/Off]	
HAZARD SW [On/Off]	The switch status input from the hazard switch

# DIAGNOSIS SYSTEM (BCM)

[XENON TYPE]

## < SYSTEM DESCRIPTION >

Monitor item [Unit]	Description
RKE-LOCK [On/Off]	Indicates [On/Off] condition of LOCK signal from Intelligent Key
RKE-UNLOCK [On/Off]	Indicates [On/Off] condition of UNLOCK signal from Intelligent Key
RKE-PANIC* [On/Off]	Indicates [On/Off] condition of PANIC button of Intelligent Key

\*: For models without panic alarm function, this item cannot be used.

## ACTIVE TEST

Test item	Operation	Description
FLASHER	RH	<ul style="list-style-type: none"><li>• Outputs voltage to turn the right side turn signal lamps ON</li><li>• Transmits the turn indicator signal to combination meter via CAN communication to turn the turn signal indicator lamp (RH) ON</li></ul>
	LH	<ul style="list-style-type: none"><li>• Outputs voltage to turn the left side turn signal lamps ON</li><li>• Transmits the turn indicator signal to combination meter via CAN communication to turn the turn signal indicator lamp (LH) ON</li></ul>
	Off	<ul style="list-style-type: none"><li>• Stops the voltage to turn the turn signal lamps OFF</li><li>• Stops the turn indicator signal transmission</li></ul>



## DIAGNOSIS SYSTEM (IPDM E/R)

### Diagnosis Description

INFOID:000000012962263

#### AUTO ACTIVE TEST

##### Description

In auto active test mode, the IPDM E/R sends a drive signal to the following systems to check their operation.

- Rear window defogger
- Front wiper motor
- Parking lamp
- License plate lamp
- Tail lamp
- Side marker lamp
- Front fog lamp
- Headlamp (LO, HI)
- A/C compressor (magnet clutch)
- Cooling fan

##### Operation Procedure

**CAUTION:**

**Wiper arm interferes with hood when wiper is operated while wiper arm is in the raised position. Always perform auto active test without setting wiper arm in the raised position. Always pour water on front windshield glass in advance to auto active test so that damage on front windshield glass surface is prevented.**

1. Turn the ignition switch OFF.
2. Turn the ignition switch ON, and within 20 seconds, press the driver door switch 10 times. Then turn the ignition switch OFF.

**CAUTION:**

**Close passenger door.**

3. Turn the ignition switch ON within 10 seconds. After that the horn sounds once and the auto active test starts.

**CAUTION:**

**Engine starts when ignition switch is turned ON while brake pedal is depressed.**

4. After a series of the following operations is repeated 3 times, auto active test is completed.

**NOTE:**

- When auto active test mode has to be cancelled halfway through test, turn the ignition switch OFF.
- When auto active test is not activated, door switch may be the cause. Check door switch. Refer to [DLK-77](#), "[Component Function Check](#)".

##### Inspection in Auto Active Test Mode

When auto active test mode is actuated, the following operation sequence is repeated 3 times.

Operation sequence	Inspection location	Operation
1	Rear window defogger	10 seconds
2	Front wiper motor	LO for 5 seconds → HI for 5 seconds
3	<ul style="list-style-type: none"> <li>• Parking lamp</li> <li>• License plate lamp</li> <li>• Tail lamp</li> <li>• Side marker lamp</li> <li>• Front fog lamp</li> </ul>	10 seconds
4	Headlamp	LO for 10 seconds → HI ON ⇔ OFF 5 times
5	A/C compressor (magnet clutch)	ON ⇔ OFF 5 times
6	Cooling fan	50% duty for 5 seconds → 100% duty for 5 seconds


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# DIAGNOSIS SYSTEM (IPDM E/R)

[XENON TYPE]

## < SYSTEM DESCRIPTION >

### Concept of auto active test



- IPDM E/R starts the auto active test with the door switch signals transmitted by BCM via CAN communication. Therefore, the CAN communication line between IPDM E/R and BCM is considered normal if the auto active test starts successfully.
- The auto active test facilitates troubleshooting if any systems controlled by IPDM E/R cannot be operated.

### Diagnosis chart in auto active test mode

Symptom	Inspection contents	Possible cause
Rear window defogger does not operate	Perform auto active test. Does the rear window defogger operate?	YES BCM signal input circuit
		NO <ul style="list-style-type: none"> <li>• Rear window defogger</li> <li>• Rear window defogger ground circuit</li> <li>• Harness or connector between IPDM E/R and rear window defogger</li> <li>• IPDM E/R</li> </ul>
Any of the following components do not operate <ul style="list-style-type: none"> <li>• Parking lamp</li> <li>• License plate lamp</li> <li>• Tail lamp</li> <li>• Side marker lamp</li> <li>• Front fog lamp</li> <li>• Headlamp (HI, LO)</li> <li>• Front wiper motor</li> </ul>	Perform auto active test. Does the applicable system operate?	YES BCM signal input circuit
		NO <ul style="list-style-type: none"> <li>• Lamp or motor</li> <li>• Lamp or motor ground circuit</li> <li>• Harness or connector between IPDM E/R and applicable system</li> <li>• IPDM E/R</li> </ul>
A/C compressor does not operate	Perform auto active test. Does the magnet clutch operate?	YES <ul style="list-style-type: none"> <li>• A/C amp. signal input circuit</li> <li>• CAN communication signal between A/C amp. and ECM</li> <li>• CAN communication signal between ECM and IPDM E/R</li> </ul>
		NO <ul style="list-style-type: none"> <li>• Magnet clutch</li> <li>• Harness or connector between IPDM E/R and magnet clutch</li> <li>• IPDM E/R</li> </ul>

# DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

[XENON TYPE]

Symptom	Inspection contents		Possible cause
Cooling fan does not operate	Perform auto active test. Does the cooling fan operate?	YES	<ul style="list-style-type: none"> <li>• ECM signal input circuit</li> <li>• CAN communication signal between ECM and IPDM E/R</li> </ul>
		NO	<ul style="list-style-type: none"> <li>• Harness or connector between IPDM E/R and cooling fan relay</li> <li>• Harness or connector between IPDM E/R and cooling fan control module.</li> <li>• Harness or connector between cooling fan control module and cooling fan motor</li> <li>• Cooling fan motor</li> <li>• Cooling fan relay</li> <li>• Cooling fan control module</li> <li>• IPDM E/R</li> </ul>

## CONSULT Function (IPDM E/R)

INFOID:000000012962264

### APPLICATION ITEM

CONSULT performs the following functions via CAN communication with IPDM E/R.

Diagnosis mode	Description
Ecu Identification	Allows confirmation of IPDM E/R part number.
Self Diagnostic Result	Displays the diagnosis results judged by IPDM E/R.
Data Monitor	Displays the real-time input/output data from IPDM E/R input/output data.
Active Test	IPDM E/R can provide a drive signal to electronic components to check their operations.
CAN Diag Support Monitor	The results of transmit/receive diagnosis of CAN communication can be read.

### SELF DIAGNOSTIC RESULT

Refer to [PCS-24, "DTC Index"](#).

### DATA MONITOR

#### NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor Item [Unit]	MAIN SIGNALS	Description
RAD FAN REQ [%]	×	Displays the value of the cooling fan speed request signal received from ECM via CAN communication.
AC COMP REQ [Off/On]	×	Displays the status of the A/C compressor request signal received from ECM via CAN communication.
TAIL&CLR REQ [Off/On]	×	Displays the status of the position light request signal received from BCM via CAN communication.
HL LO REQ [Off/On]	×	Displays the status of the low beam request signal received from BCM via CAN communication.
HL HI REQ [Off/On]	×	Displays the status of the high beam request signal received from BCM via CAN communication.
FR FOG REQ [Off/On]	×	Displays the status of the front fog light request signal received from BCM via CAN communication.
FR WIP REQ [Stop/1LOW/Low/Hi]	×	Displays the status of the front wiper request signal received from BCM via CAN communication.
WIP AUTO STOP [STOP P/ACT P]	×	Displays the status of the front wiper auto stop signal judged by IPDM E/R.
WIP PROT [Off/BLOCK]	×	Displays the status of the front wiper fail-safe operation judged by IPDM E/R.
IGN RLY1 -REQ [Off/On]		Displays the status of the ignition switch ON signal received from BCM via CAN communication.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

# DIAGNOSIS SYSTEM (IPDM E/R)

[XENON TYPE]

## < SYSTEM DESCRIPTION >

Monitor Item [Unit]	MAIN SIGNALS	Description
IGN RLY [Off/On]	×	Displays the status of the ignition relay judged by IPDM E/R.
PUSH SW [Off/On]		Displays the status of the push-button ignition switch judged by IPDM E/R.
INTER/NP SW [Off/On]		Displays the status of the ignition power supply (M/T models) or shift position (CVT models) judged by IPDM E/R.
ST RLY CONT [Off/On]		Displays the status of the starter relay status signal received from BCM via CAN communication.
IHBT RLY -REQ [Off/On]		Displays the status of the starter control relay signal received from BCM via CAN communication.
ST/INH RLY [Off/ ST ON/INH ON/UNKWN]		Displays the status of the starter relay and starter control relay judged by IPDM E/R.
DETENT SW [Off/On]		Displays the status of the CVT shift selector (detention switch) judged by IPDM E/R.
S/L RLY -REQ [Off/On]		<b>NOTE:</b> This item is indicated, but not monitored.
S/L STATE [LOCK/UNLK/UNKWN]		<b>NOTE:</b> This item is indicated, but not monitored.
DTRL REQ [Off/On]		Displays the status of the daytime running light request signal received from BCM via CAN communication. <b>NOTE:</b> This item is monitored only for the except for NISMO models.
OIL P SW [Open/Close]		<b>NOTE:</b> This item is indicated, but not monitored.
HOOD SW [Off/On]		<b>NOTE:</b> This item is indicated, but not monitored.
HL WASHER REQ [Off/On]		<b>NOTE:</b> This item is indicated, but not monitored.
THFT HRN REQ [Off/On]		Displays the status of the theft warning horn request signal received from BCM via CAN communication.
HORN CHIRP [Off/On]		Displays the status of the horn reminder request signal received from BCM via CAN communication.

## ACTIVE TEST

### Test item

Test item	Operation	Description
HORN	On	Operates horn relay for 20 ms.
REAR DEFOGGER	Off	OFF
	On	Operates the rear window defogger relay.
FRONT WIPER	Off	OFF
	Lo	Operates the front wiper relay.
	Hi	Operates the front wiper relay and front wiper high relay.
MOTOR FAN	1	OFF
	2	Transmits 50% pulse duty signal (PWM signal) to the cooling fan control module.
	3	Transmits 75% pulse duty signal (PWM signal) to the cooling fan control module.
	4	Transmits 100% pulse duty signal (PWM signal) to the cooling fan control module.
HEAD LAMP WASHER	On	<b>NOTE:</b> This item is indicated, but cannot be tested.

# DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

[XENON TYPE]

Test item	Operation	Description
EXTERNAL LAMPS	Off	OFF
	TAIL	Operates the tail lamp relay.
	Lo	Operates the headlamp low relay.
	Hi	Operates the headlamp low relay and ON/OFF the headlamp high relay at 1 second intervals.
	Fog	Operates the front fog lamp relay.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

EXL

# ECU DIAGNOSIS INFORMATION

## BCM, IPDM E/R

### List of ECU Reference

INFOID:0000000012201633


ECU	Reference
BCM	<a href="#">BCS-39, "Reference Value"</a>
	<a href="#">BCS-60, "Fail-safe"</a>
	<a href="#">BCS-61, "DTC Inspection Priority Chart"</a>
	<a href="#">BCS-62, "DTC Index"</a>
IPDM E/R	<a href="#">PCS-17, "Reference Value"</a>
	<a href="#">PCS-23, "Fail-safe"</a>
	<a href="#">PCS-24, "DTC Index"</a>



# EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]




JRLWF5312GB



# EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]



JRLWF5313GB


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]



JRLWF5314GB


# EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]


## EXTERIOR LIGHTING SYSTEM

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	NS160WV-C5



Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	-
2	GR	-
6	SB	-
10	W	-
11	L	-
12	R	-
13	GR	-
14	Y	-
15	LG	-
16	BR	-

Connector No.	B2
Connector Name	WIRE TO WIRE
Connector Type	NS160WV-C5



Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	-
2	L	-
4	Y	-
7	V	-
9	SB	-
10	V	-
11	Y	-
12	GR	-
13	R	-


14	P	-
15	L	-
16	G	-

Connector No.	B7
Connector Name	WIRE TO WIRE
Connector Type	TH24FW-WH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	W	-
3	V	-
5	G	-
6	LG	-
7	R	-
8	P	-
9	L	-
10	LG	-
11	LG	-
12	R	-
13	L	-
14	L	-
15	BR	-
16	BR	-
17	L	-
18	P	-
19	B	-
20	G	-
21	W	-
22	R	-
23	SHIELD	-

Connector No.	B10
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA05P-FH05-5A




Terminal No.	Color Of Wire	Signal Name [Specification]
43	P	-
44	LG	BACK DOOR SW
45	R	REAR WIPER STOP POSITION
46	LG	PASSENGER DOOR SW
47	SB	DRIVER DOOR SW
48	BR	REAR LH DOOR SW
49	L	LUGGAGE LAMP OUTPUT
51	Y	BACK DOOR RED SW
53	GR	BK DOOR OPER OUTPUT
54	P	REAR WIPER OUTPUT
55	G	RR DOOR UNLK OUTPUT

Connector No.	B19
Connector Name	WIRE TO WIRE
Connector Type	M0230B-P-LC




Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
2	R	-

Connector No.	B20
Connector Name	WIRE TO WIRE
Connector Type	WH100WV-C510



Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	-
7	GR	-
8	LG	-
9	R	-
10	B	-
12	R	-
13	Y	-
14	SHIELD	-
15	W	-
16	L	-
17	P	-
18	GR	-

Connector No.	B48
Connector Name	FRONT DOOR SWITCH (DRIVER SIDE)
Connector Type	JAG3FN



Terminal No.	Color Of Wire	Signal Name [Specification]
2	SB	-

JRLWF5315GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL


# EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

## EXTERIOR LIGHTING SYSTEM

Connector No.	B89
Connector Name	FRONT DOOR SWITCH (PASSENGER SIDE)
Connector Type	A03FW




Terminal No.	2	Color Of Wire	R	Signal Name [Specification]	-
--------------	---	---------------	---	-----------------------------	---

Connector No.	B83
Connector Name	REAR DOOR SWITCH RH
Connector Type	A03FW



Terminal No.	2	Color Of Wire	LG	Signal Name [Specification]	-
--------------	---	---------------	----	-----------------------------	---

Connector No.	B89
Connector Name	REAR COMBINATION LAMP RH
Connector Type	N066WVCS



Terminal No.	2	Color Of Wire	GR	Signal Name [Specification]	-
3	8	W	-	-	-
5	W	-	-	-	-
6	G	-	-	-	-

Connector No.	B71
Connector Name	REAR DOOR SWITCH LH
Connector Type	A03FW




Terminal No.	2	Color Of Wire	BR	Signal Name [Specification]	-
--------------	---	---------------	----	-----------------------------	---

Connector No.	B75
Connector Name	JOINT CONNECTOR-B01
Connector Type	G20FB



Terminal No.	2	Color Of Wire	G	Signal Name [Specification]	-
3	G	-	-	-	-
4	G	-	-	-	-
12	V	-	-	-	-
13	V	-	-	-	-
14	V	-	-	-	-
15	R	-	-	-	-
16	R	-	-	-	-
17	R	-	-	-	-

Connector No.	B76
Connector Name	JOINT CONNECTOR-B02
Connector Type	G20FB




Terminal No.	2	Color Of Wire	R	Signal Name [Specification]	-
3	R	-	-	-	-
4	R	-	-	-	-
7	GR	-	-	-	-
8	GR	-	-	-	-
9	GR	-	-	-	-
10	GR	-	-	-	-
12	W	-	-	-	-
13	W	-	-	-	-
14	W	-	-	-	-

Connector No.	B80
Connector Name	REAR COMBINATION LAMP LH
Connector Type	N066WVCS



Terminal No.	1	Color Of Wire	R	Signal Name [Specification]	-
2	GR	-	-	-	-
3	B	-	-	-	-
5	V	-	-	-	-
6	G	-	-	-	-

Connector No.	B2
Connector Name	WIRE TO WIRE
Connector Type	TH048FW-CS15



Terminal No.	1	Color Of Wire	R	Signal Name [Specification]	-
2	G	-	-	-	-
3	Y	-	-	-	-
4	V	-	-	-	-
13	W	-	-	-	-
14	SB	-	-	-	-
15	L	-	-	-	-
16	GR	-	-	-	-
17	Y	-	-	-	-
18	W	-	-	-	-
19	R	-	-	-	-
24	R	-	-	-	-
25	G	-	-	-	-
38	G	-	-	-	-
39	LG	-	-	-	-
43	Y	-	-	-	-
44	V	-	-	-	-
45	W	-	-	-	-
46	BG	-	-	-	-
50	P	-	-	-	-


# EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

## EXTERIOR LIGHTING SYSTEM

Connector No.	D19
Connector Name	DOOR MIRROR (PASSENGER SIDE)
Connector Type	TH16SW-NI



Terminal No.	Color Of Wire	Signal Name [Specification]
1	V	-
2	B	-
3	P	-
4	B	-
6	W	-
7	GR	-
11	BG	-
12	W	-
13	G	-
14	R	-
15	Y	-

Connector No.	D22
Connector Name	WIRE TO WIRE
Connector Type	TH48FW-CS15



Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	-
2	W	-
3	SB	-
4	V	-
5	B	-
6	G	-
7	LG	-
8	BG	-
9	LG	-
10	Y	-
11	W	-

12	SB	-
13	B	-
14	P	-
15	LG	-
16	BR	-
17	BR	-
18	P	-
19	V	-
24	G	-
25	R	-
38	G	-
39	B	-
40	V	-
41	P	-
42	R	-
43	GR	-
44	W	-
45	Y	-
46	BG	-
47	G	-
48	L	-
49	R	-
50	LG	-
52	BR	-

Connector No.	D30
Connector Name	DOOR MIRROR (DRIVER SIDE)
Connector Type	TH16SW-NI



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	B	-
3	GR	-
4	B	-
6	P	-
7	LG	-
11	BG	-
12	Y	-
13	G	-
14	V	-

Connector No.	D15
Connector Name	BR
Connector Type	-



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	B	-
3	SB	-
4	B	-
5	V	-
6	B	-

Connector No.	D121
Connector Name	HIGH-MOUNTED STOP LAMP
Connector Type	TH02FW




Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	B	-

Connector No.	D126
Connector Name	WIRE TO WIRE
Connector Type	TH02FB-IC



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
2	R	-

Connector No.	D127
Connector Name	WIRE TO WIRE
Connector Type	TH10DFW-CS10



Terminal No.	Color Of Wire	Signal Name [Specification]
7	GR	-
8	LG	-
9	R	-
10	B	-
12	R	-
13	SB	-
34	B	-
15	Y	-
16	L	-
17	P	-
18	V	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

## EXTERIOR LIGHTING SYSTEM

Connector No.	F6
Connector Name	WIRE TO WIRE
Connector Type	SA43BMP-RS10-SR2



1	19	20	21	22	23	24	25
2	26	27	28	29	30	31	32
3	33	34	35	36	37	38	39
4	40	41	42	43	44	45	46

Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	-
2	L	-
3	O	-
4	LG	- [For NISMO RS]
5	V	- [Except for NISMO RS]
6	O	-
7	BR	-
10	R	-
11	G	- [Except for NISMO RS]
11	O	- [For NISMO RS]
12	G	-
13	B	- [Except for NISMO RS]
13	Y	- [For NISMO RS]
14	L	- [For NISMO RS]
14	G	- [Except for NISMO RS]
15	R	-
16	SB	-
17	GR	-
18	WT	-
19	L/B	-
20	L/W	-
21	G	-
22	Y	- [For NISMO RS]
22	G	- [Except for NISMO RS]
23	B	- [Except for NISMO RS]
23	SHIELD	- [For NISMO RS]
24	P	-
25	R	-
26	B	-
27	B	-
28	LG	-
29	SB	-
30	G	- [Except for NISMO RS]
30	P	- [For NISMO RS]
31	G	-
32	Y	-

33	BR	-	-	-	-	-	-
34	W	-	-	-	-	-	-
37	L	-	-	-	-	-	-
37	LG	-	-	-	-	-	-
38	SB	-	-	-	-	-	-
39	B	-	-	-	-	-	-
40	P	-	-	-	-	-	-
41	V	-	-	-	-	-	-
42	L	-	-	-	-	-	-
43	BR	-	-	-	-	-	-
43	W	-	-	-	-	-	-
44	BR	-	-	-	-	-	-
44	G	-	-	-	-	-	-
45	BR	-	-	-	-	-	-
46	Y	-	-	-	-	-	-
47	SB	-	-	-	-	-	-
48	LG	-	-	-	-	-	-
48	Y	-	-	-	-	-	-

Connector No.	E11
Connector Name	POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	IM06FB-LC



10	9
14	14

Terminal No.	Color Of Wire	Signal Name [Specification]
9	B/Y	-
10	L	-
14	R	-

Connector No.	E12
Connector Name	POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	NS08BRC-CS



20	19	18
19	18	17

Terminal No.	Color Of Wire	Signal Name [Specification]
18	GR	-
19	R	- [Without front fog lamp]
19	W	- [With front fog lamp]
20	G	- [Without front fog lamp]
20	V	- [With front fog lamp]

Connector No.	E13
Connector Name	POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	TH127W-NH



28	27	26	25	23
34	33	32	31	30

Terminal No.	Color Of Wire	Signal Name [Specification]
23	SB	-
25	BR	-
26	P	-
27	L	-
28	Y	-
30	V	-
31	Y	-
32	R	-
33	G	-
34	L	-

Connector No.	E14
Connector Name	POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	NS12BRC-CS



39	37	36	35	
45	44	43	42	41

Terminal No.	Color Of Wire	Signal Name [Specification]
35	G	-
36	P	-
37	L	-
39	L	-
41	BR	-
42	Y	-
43	L	-
44	BR	-
45	W	-
46	LG	-

Connector No.	E15
Connector Name	POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	NS14BFW-CS



52	51	50	49	48				
62	61	60	59	58	57	56	55	54

Terminal No.	Color Of Wire	Signal Name [Specification]
48	BR	-
49	Y	-
50	G	-
51	L	-
52	P	-
54	P	-
55	G	-
56	SB	-
57	O	-
58	LG	-

# EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

## EXTERIOR LIGHTING SYSTEM


59	V	-	-
60	SB	-	-
61	SG	-	-
62	SE	-	-

Connector No.	E18
Connector Name	ECM
Connector Type	RH24FGV-R26-R-RH



Terminal No.	Color Of Wire	Signal Name [Specification]
99	P	CAN COMMUNICATION LINE (CAN-L)
100	L	CAN COMMUNICATION LINE (CAN-H)
101	V	SENSOR POWER SUPPLY
102	R	ACCELERATOR PEDAL POSITION SENSOR 1
103	BR	PNP SIGNAL
104	R	DATA LINK CONNECTOR
105	GR	SENSOR GROUND
106	Y	POWER SUPPLY FOR ECM (BACKUP)
108	GR	CLUTCH PEDAL POSITION SWITCH
109	O	IGNITION SWITCH
110	G	ASCD STEERING SWITCH
111	B	SENSOR GROUND
112	BR	ECM RELAY (EIS START OFF)
115	R	STOP LAMP SWITCH
116	G	BRAKE PEDAL POSITION SWITCH
117	Y	FUEL PUMP RELAY
118	O	SENSOR POWER SUPPLY
119	W	ACCELERATOR PEDAL POSITION SENSOR 2
120	Y	SENSOR GROUND
121	G	POWER SUPPLY FOR ECM
122	G	THROTTLE CONTROL MOTOR POWER SUPPLY
123	GR	ECM GROUND
124	GR	ECM GROUND
125	L	A/F SENSOR 1 HEATER
126	W	HEATED OXYGEN SENSOR 2 HEATER
127	GR	ECM GROUND

Connector No.	E19
Connector Name	ECM
Connector Type	RH24FB-R28-L-LH



Terminal No.	Color Of Wire	Signal Name [Specification]
121	L	EVAP CONTROL SYSTEM PRESSURE SENSOR
123	P	CAN COMMUNICATION LINE (CAN-L)
124	L	CAN COMMUNICATION LINE (CAN-H)
125	G	SENSOR POWER SUPPLY
128	SB	FUEL TANK TEMPERATURE SENSOR
132	GR	CLUTCH PEDAL POSITION SWITCH
133	LG	IGNITION SWITCH
134	P	ASCD STEERING SWITCH
135	B	SENSOR GROUND
139	R	STOP LAMP SWITCH
140	G	BRAKE PEDAL POSITION SWITCH
141	L	EVAP CANISTER VENT CONTROL VALVE
142	O	SENSOR POWER SUPPLY
143	W	ACCELERATOR PEDAL POSITION SENSOR 2
144	Y	SENSOR GROUND
145	G	POWER SUPPLY FOR ECM
146	G	SENSOR POWER SUPPLY
147	GR	ECM GROUND
148	Y	SENSOR GROUND
149	GR	ECM GROUND
150	R	ACCELERATOR PEDAL POSITION SENSOR 1
151	GR	SENSOR GROUND
152	GR	ECM GROUND

Connector No.	E28
Connector Name	PARKING LAMP LH
Connector Type	HS02FGY



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	B	-

Connector No.	E32
Connector Name	FRONT FOG LAMP LH
Connector Type	FH22FB



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	B	-

Connector No.	E31
Connector Name	FRONT SIDE MARKER LAMP LH
Connector Type	T02FB



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	B/R	-

Connector No.	E32
Connector Name	FRONT SIDE MARKER LAMP RH
Connector Type	T02FB



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	B	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

EXL

# EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

## EXTERIOR LIGHTING SYSTEM

Connector No.	E34
Connector Name	FRONT TURN SIGNAL LAMP LH
Connector Type	HS02FGY-1V



Terminal No.	Color Of Wire	Signal Name [Specification]
1	V	-
2	B	-

Connector No.	E35
Connector Name	ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)
Connector Type	RH28FB-NU4-LH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	BAT (MTR)
2	L	BAT (SQU)
3	B	GND (SQU)
4	B	GND (MTR)
5	R	VDC OFF SW
6	G	ASCD CANCEL SW
8	R	STOP LAMP SW
9	P	CAN-L
11	BR	DP RR
12	W	DS FR
13	G	VCC
14	R	SERIAL+
15	Y	DS RR
16	V	IGN
17	W	REVERSE SIGNAL
21	Y	DP FR
22	L	CANH
23	LG	DP FL

25	G	RR LH SEQS VP
26	BR	GR RE
27	W	SEBAL-
28	W	SEBAL-
30	BE	RR LH SEQS SIG

Connector No.	E44
Connector Name	PARKING LAMP RH
Connector Type	RS02FGY



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	B	-

Connector No.	E47
Connector Name	FRONT TURN SIGNAL LAMP RH
Connector Type	HS02FGY-1V



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
2	B	-

Connector No.	E48
Connector Name	FRONT FOG LAMP RH
Connector Type	HS02FB



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	B	-

Connector No.	E54
Connector Name	HEADLAMP LH
Connector Type	RS04FGYPR




Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	-
2	B	- [With halogen lamp]
3	B	- [With xenon lamp]
4	L	-

Connector No.	E55
Connector Name	HEADLAMP RH
Connector Type	RS04FGYPR



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
2	B	- [With halogen lamp]
3	B	- [With xenon lamp]
3	GR	- [Without daytime running light system] [With halogen lamp]
3	W	- [Without daytime running light system] [With xenon lamp]
4	P	- [With daytime running light system]

Connector No.	E65
Connector Name	DAYTIME RUNNING LIGHT RELAY
Connector Type	MS03FB-M2-LC



Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	-
2	Y	-
3	W	-
4	B	-
5	LG	-



# EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

## EXTERIOR LIGHTING SYSTEM

Connector No.	E75
Connector Name	DAYTIME RUNNING LIGHT RH
Connector Type	RS02FB



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	B	-

Connector No.	E75
Connector Name	DAYTIME RUNNING LIGHT LH
Connector Type	RS02FB



Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	-
2	BR	-

Connector No.	E81
Connector Name	JOINT CONNECTOR-E81
Connector Type	A32FL



Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	-
2	BR	-
3	BR	-
4	BR	-
6	R	-
8	R	-
9	R	-
10	R	-
11	R	-
12	R	-

Connector No.	E83
Connector Name	JOINT CONNECTOR-E84
Connector Type	PH10FB




Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	- [For NISMO RS]
2	LG	- [Except for NISMO RS]
3	Y	-
4	Y	-
5	Y	-
6	LG	- [For NISMO RS]
8	V	- [Except for NISMO RS]
9	V	-

Connector No.	E84
Connector Name	JOINT CONNECTOR-E82
Connector Type	A32FL



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	L	-
3	L	-
4	L	-
5	L	-
6	L	-
7	P	-
8	P	-
9	P	-
10	P	-
11	P	-
12	P	-

Connector No.	E82
Connector Name	STOP LAMP SWITCH
Connector Type	MD4FM-LC



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	R	-
3	BE	-
4	P	-

Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	TH803AW-CS16-7M4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
4	Y	-
6	P	-
10	R	-
11	W	-
12	B	-
13	R	-
14	SHIELD	-
34	BE	-
35	R	-
36	B	-
37	P	-
52	R	-
53	BR	-
54	V	-
55	BE	-
56	Y	-
62	Y	-
63	V	-
64	LG	-
65	L	-
66	R	-
67	W	-
68	5B	-
70	BR	-
71	LG	-
72	V	-
73	L	-
76	R	-
78	B	-
79	W	-
80	L	-
83	Y	-
84	LG	-
85	P	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

## EXTERIOR LIGHTING SYSTEM

86	GE	-
87	SHIELD	-
88	P	-
89	B	-
90	GR	-
91	BR	-
92	BR	-
93	BR	-
94	P	-
95	GR	-
96	W	-
97	V	-
98	W	-
99	W	-
100	O	-

Connector No.	E107
Connector Name	WIRE TO WIRE
Connector Type	TRIZAKW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	V	-
3	G	-
4	G	-
5	O	- [Except for NISMO RS]
6	O	- [Except for NISMO RS]
7	R	-
8	SB	-
9	Y	- [For NISMO RS]
10	G	- [Except for NISMO RS]
11	L	-
12	Y	-
13	P	-
14	L	-
15	G	-
16	BE	-
17	BR	-
18	Y	-
19	G	-
20	B	-
21	W	-
22	R	-
23	SHIELD	-

Connector No.	E118
Connector Name	STOP LAMP SWITCH
Connector Type	MODF-BLC



Terminal No.	1	2
Color Of Wire	W	R
Signal Name [Specification]	-	

Connector No.	F1
Connector Name	WIRE TO WIRE
Connector Type	5SA34FB-RS1D-S4Z2



Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	-
2	L	-
3	W	- [Except for NISMO RS]
4	Y	- [For NISMO RS]
5	GR	- [Except for NISMO RS]
6	GR	- [Except for NISMO RS]
7	G	-
8	G	-
9	R	-
10	R	- [Except for NISMO RS]
11	Y	- [For NISMO RS]
12	G	- [Except for NISMO RS]
13	B	-
14	W	-
15	BR	- [For NISMO RS]
16	BR	- [For NISMO RS]
17	V	-
18	V	-
19	V	-
20	V	-


15	P	-
17	SB	-
18	G	-
19	G	-
20	BR	-
21	G	-
22	BR	- [For NISMO RS]
23	Y	- [Except for NISMO RS]
24	B	-
25	R	-
26	B	-
27	B	-
28	R	-
29	W	-
30	GR	- [Except for NISMO RS]
31	R	- [For NISMO RS]
32	LG	-
33	BR	-
34	G	- [For NISMO RS]
35	P	- [Except for NISMO RS]
36	GR	- [With Intelligent Key]
37	GR	- [Without Intelligent Key]
38	R	-
39	GR	-
40	P	-
41	BR	- [For NISMO RS]
42	V	- [Except for NISMO RS]
43	V	- [For NISMO RS]
44	W	- [Except for NISMO RS]
45	L	- [For NISMO RS]
46	W	- [Except for NISMO RS]
47	Y	-
48	GR	- [With Intelligent Key]
49	Y	- [Without Intelligent Key]

Connector No.	F27
Connector Name	TRANSMISSION RANGE SWITCH
Connector Type	RK08EG



Terminal No.	1	2	3	4	5	6	7	8
Color Of Wire	GR	BR	LG	L	G	Y	W	V
Signal Name [Specification]	-							

Connector No.	F30
Connector Name	TRANSMISSION RANGE SWITCH
Connector Type	YD0XGFB-H54



Terminal No.	1	2	3	4	5	6	7	8
Color Of Wire	GR	BR	LG	SB	G	LG	W	BR
Signal Name [Specification]	-							

# EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

## EXTERIOR LIGHTING SYSTEM

Connector No.	149
Connector Name	PARK / NEUTRAL POSITION SWITCH
Connector Type	FEA03FG-LC





Terminal No.	Color Of Wire	Signal Name (Specification)
1	G	-
2	SB	-
3	BR	-

Connector No.	157
Connector Name	BACK-UP LAMP SWITCH
Connector Type	RM02FB



Terminal No.	Color Of Wire	Signal Name (Specification)
1	G	-
2	SB	-

Connector No.	1103
Connector Name	JOINT CONNECTOR-FB3
Connector Type	SEA23F#J





Terminal No.	Color Of Wire	Signal Name (Specification)
1	L	-
2	L	-
3	L	-
4	GR	-
5	GR	-
6	GR	-
7	SB	-
8	SB	-
10	SB	-
11	SB	-
13	Y	-
14	Y	-
15	Y	-
16	Y	-
18	LG	-
19	LG	-
20	GR	-
21	BR	-
22	BR	-
23	Y	-
24	BR	-

Connector No.	M4
Connector Name	DATA LINK CONNECTOR
Connector Type	BD31FW



Terminal No.	Color Of Wire	Signal Name (Specification)
4	B	-
5	B	-
6	L	-
7	W	-
8	LG	-
14	P	-
16	Y	-



Connector No.	M10
Connector Name	WIRE TO WIRE
Connector Type	T140MW-CS15



Terminal No.	Color Of Wire	Signal Name (Specification)
1	R	-
2	G	-
3	SB	-
4	V	-
13	GR	-
14	GR	-
15	L	-
16	SHIELD	-
17	Y	-
18	G	-
19	L	-
24	R	-
25	G	-

38	Y	-
39	B	-
40	BR	-
41	Y	-
42	V	-
45	LG	-
46	BR	-
50	P	-

Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Type	T140MW-CS15



Terminal No.	Color Of Wire	Signal Name (Specification)
1	GR	-
2	W	-
3	SB	-
4	V	-
6	R	-
8	G	-
10	Y	-
11	GR	-
12	GR	-
13	B	-
14	L	-
15	P	-
16	SHIELD	-
17	R	-
18	B	-
19	W	-
24	BR	-
25	Y	-
38	W	-
39	B	-
40	V	-
41	P	-
42	GR	-
43	V	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# EXTERIOR LIGHTING SYSTEM


< WIRING DIAGRAM >

[XENON TYPE]

## EXTERIOR LIGHTING SYSTEM


44	P	-
45	G	-
46	Y	-
47	GR	-
48	L	-
49	R	-
50	LG	-
52	BR	-

Connector No. M18  
 Connector Name WIRE TO WIRE  
 Connector Type NS16FW-CS




Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	L	-
6	V	-
10	W	-
11	BR	-
12	V	-
14	Y	-
15	LG	-
16	L	-

Connector No. M19  
 Connector Name WIRE TO WIRE  
 Connector Type NS16FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	-
2	Y	-
4	W	-
7	V	-
9	BR	-
10	V	-
11	LG	-
12	V	-
13	R	-
14	G	-
15	L	-
16	G	-


Connector No. M27  
 Connector Name COMBINATION SWITCH  
 Connector Type TH16FW-AH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	WASHER (RR)
2	GR	OUTPUT 4
3	R	WASHER (FR)
4	W	IGN
5	BR	OUTPUT 3
6	B	GND
7	V	OUTPUT 3
8	L	OUTPUT 5

Connector No. M34  
 Connector Name COMBINATION METER  
 Connector Type TH16FW-AH

Terminal No.	Color Of Wire	Signal Name [Specification]
9	R	INPUT 2
10	Y	INPUT 4
11	P	INPUT 4
12	W	OUTPUT 1
13	LG	INPUT 5
14	G	OUTPUT 2



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	CAN-H
2	P	CAN-L
4	Y	VEHICLE SPEED SIGNAL (8-PULSE)
5	G	PADDLE SHIFTER UP SWITCH SIGNAL
6	BR	FUEL LEVEL SENSOR SIGNAL
7	R	AIR BAG SIGNAL
8	W	SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SEAT)
10	SP	PARKING BRAKE SWITCH SIGNAL
11	G	FRONT WIPER SWITCH SIGNAL
13	GR	ILLUMINATION CONTROL SIGNAL
14	R	MANUAL MODE SHIFT UP SIGNAL
15	L	ACC POWER SUPPLY
16	W	MANUAL MODE SHIFT DOWN SIGNAL
17	G	WASHER LEVEL SWITCH SIGNAL
18	R	SECURITY SIGNAL
19	GR	AMBIENT SENSOR SIGNAL
20	R	AMBIENT SENSOR GROUND
21	B	GROUND
22	B	GROUND
23	B	GROUND
24	L	FUEL LEVEL SENSOR GROUND
25	B	VDC GROUND
26	V	PADDLE SHIFTER DOWN SWITCH SIGNAL
27	LG	BATTERY POWER SUPPLY
28	GR	IGNITION SIGNAL
29	V	PASSENGER SEAT BELT WARNING SIGNAL
31	P	A/C AUTO APP. CONNECTION RECOGNITION SIGNAL


Connector No. M45  
 Connector Name HAZARD SWITCH  
 Connector Type TK04FW

35	Y	MANUAL MODE SIGNAL
37	G	NON-MANUAL MODE SIGNAL
38	P	ALTERNATOR SIGNAL



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
2	SB	-
3	V	-
4	GR	-

Connector No. M58  
 Connector Name BCM (BODY CONTROL MODULE)  
 Connector Type TH16FB-AH



Terminal No.	Color Of Wire	Signal Name [Specification]
2	L	COMBI SW INPUT 5
3	GR	COMBI SW INPUT 4
4	BR	COMBI SW INPUT 3
5	G	COMBI SW INPUT 2
6	W	COMBI SW INPUT 1
7	L	KEY CYL UNLOCK SW
8	R	KEY CYL LOCK SW
9	R	STOP LAMP SW 1
10	W	-
12	GR	DOOR LK & UNLK SW LOCK
13	BR	DOOR LK & UNLK SW UNLOCK

# EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

## EXTERIOR LIGHTING SYSTEM

14	SB	OPTICAL SENS
15	W	REAR WINDOW DEF SW
16	V	OPTICAL SENS PWR SPLY
18	V	REAR WASH AMP
21	P	WAS ANT AMP
22	R	SECURITY AND LAMP CONT
23	R	DONGLE LINK
24	SB	WAS ANT AMP
25	LG	WAS ANT AMP
26	BR	THERMO AMP
27	Y	A/C SW
28	LG	BLOWER FAN SW
29	SB	HAZARD SW
30	L	BK DOOR OPENER SW
31	GR	DR DOOR UNLK SENS
32	LG	COMBI SW OUTPUT 5
33	Y	COMBI SW OUTPUT 4
34	V	COMBI SW OUTPUT 3
35	R	COMBI SW OUTPUT 2
36	P	COMBI SW OUTPUT 1
37	G	DEFENT SW
38	SB	RECEIVER COMM
39	L	CANH
40	P	CANL

Connector No.	M69
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEADSPW-FHMS-A



Terminal No.	Color Of Wire	Signal Name [Specification]
56	P	INT ROOM LAMP PWR SPLY
57	P	BATT(FUSE)
59	SB	PASS DOOR UNLK OUTPUT
60	V	TURN SIG LH OUTPUT
61	W	TURN SIG RH OUTPUT
63	BR	INT ROOM LAMP CONT
64	R	REVERSE SW
65	V	ALL DOOR LOCK OUTPUT
66	SB	DR DOOR UNLK OUTPUT
67	B	GND
68	L	PWR PWR SPLY (IGN)

69	P	PWR PWR SPLY (BATT)
70	Y	BAT(FU)

Connector No.	M70
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40TW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
72	SB	A/C IND OUTPUT
75	LG	DR DOOR REQ SW
76	LG	PUSH SW
78	P	DRIVER DOOR ANT+
79	V	DRIVER DOOR ANT-
80	BR	PASS DOOR ANT+
81	G	PASS DOOR ANT-
82	W	REAR BRRP ANT+
83	B	REAR BRRP ANT-
84	BR	ROD ANT L+
85	GR	ROD ANT L-
86	V	ROD ANT R+
87	G	ROD ANT R-
89	W	PUSH SW (FOR M/T MODELS)
90	V	ACC COND SW
91	V	PUSH SW (IGN SW) ALL GND
92	R	ACC COND SW
93	GR	KEY WARN BUZZER
94	GR	ACC RELAY CONT
95	BR	STARTER RELAY CONT
97	SB	IGN RELAY (IPDM/ER) CONT
98	P	PASS DOOR REQ SW
99	R	CLUTCH INTERLOCK SW (FOR M/T MODELS)
100	P	IGN RELAY (F/B) CONT
101	Y	IGN SW (NOZ. EXCEPT FOR M/T MODELS)
102	L	NEUTRAL SW (FOR M/T MODELS)
103	L	P/N POSITION (EXCEPT FOR M/T MODELS)
104	G	FR DEFECT SW
105	SB	CVT SHIFT SELECT PWR SPLY
106	Y	STOP LAMP SW 2
		BLWR RELAY CONT

Connector No.	M77
Connector Name	WIRE TO WIRE
Connector Type	TH88FW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	
4	V	
6	P	
10	R	
11	R	
12	LG	
13	V	
14	SHIELD	
34	LG	
35	SB	
36	B	
37	P	
52	R	
53	L	
54	SB	
55	P	
56	LG	
58	V	
59	W	
62	Y	
63	W	
64	G	
65	GR	
66	Y	
67	V	
68	R	
70	V	
71	R	
72	GR	
73	G	
76	W	
78	LG	
79	V	
80	LG	
83	P	
84	G	
85	BR	

86	LG	
90	SHIELD	
91	V	
92	BR	
95	L	
96	L	
97	GR	
98	G	
99	R	
100	LG	

Connector No.	M84
Connector Name	OPTICAL SENSOR
Connector Type	TKG3FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	
2	SB	
3	V	

Connector No.	M103
Connector Name	PUSH-BUTTON IGNITION SWITCH
Connector Type	TKG8BB



Terminal No.	Color Of Wire	Signal Name [Specification]
3	G	
4	B	
5	W	
6	R	
7	V	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# EXTERIOR LIGHTING SYSTEM


< WIRING DIAGRAM >

[XENON TYPE]

## EXTERIOR LIGHTING SYSTEM


8	LG	-
---	----	---

Connector No.	M132
Connector Name	JOINT CONNECTOR-M02
Connector Type	NH2DFLDC



Terminal No.	Color Of Wire	Signal Name (Specification)
1	B	-
2	B	-
3	B	-
4	B	-
5	B	-
6	B	-
7	B	-
8	B	-
9	B	-
10	LG	-
11	LG	-
13	LG	-
16	LG	-


Connector No.	M133
Connector Name	JOINT CONNECTOR-M04
Connector Type	NH2DFLDC



Terminal No.	Color Of Wire	Signal Name (Specification)
1	P	-
2	P	-
3	P	-
5	P	-
7	P	-

7	P	-
11	L	-
12	L	-
13	L	-
15	L	-
17	L	-
18	W	-
19	W	-

Connector No.	M136
Connector Name	JOINT CONNECTOR-M07
Connector Type	NH2DFLDC



Terminal No.	Color Of Wire	Signal Name (Specification)
1	P	-
2	P	-
3	P	-
4	P	-
5	P	-
6	P	-
7	P	-
8	P	-
10	L	-
11	L	-
12	L	-
13	L	-
14	L	-
15	L	-
16	L	-
17	L	-
18	GR	-
19	GR	-
20	GR	-

JRLWF5326GB

# DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[XENON TYPE]


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000012201635

OVERALL SEQUENCE



DETAILED FLOW

# DIAGNOSIS AND REPAIR WORK FLOW

[XENON TYPE]

< BASIC INSPECTION >

---

## 1. GET INFORMATION FOR SYMPTOM

---

1. Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurs).
2. Check operation condition of the function that is malfunctioning.

>> GO TO 2.

---

## 2. CHECK DTC

---

1. Check DTC.
2. Perform the following procedure if DTC is detected.
  - Record DTC and freeze frame data (Print them out using CONSULT.)
  - Erase DTC.
  - Study the relationship between the cause detected by DTC and the symptom described by the customer.
3. Check related service bulletins for information.

Are any symptoms described and any DTC detected?

Symptom is described, DTC is detected>>GO TO 3.

Symptom is described, DTC is not detected>>GO TO 4.

Symptom is not described, DTC is detected>>GO TO 5.

---

## 3. CONFIRM THE SYMPTOM

---

Try to confirm the symptom described by the customer.

Also study the normal operation and fail-safe related to the symptom.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5.

---

## 4. CONFIRM THE SYMPTOM

---

Try to confirm the symptom described by the customer.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6.

---

## 5. PERFORM DTC CONFIRMATION PROCEDURE

---

Perform DTC CONFIRMATION PROCEDURE for the detected DTC, and then check that DTC is detected again. At this time, always connect CONSULT to the vehicle, and check self diagnostic results in real time. If two or more DTCs are detected, refer to DTC INSPECTION PRIORITY CHART, and determine trouble diagnosis order.

**NOTE:**

- Freeze frame data is useful if the DTC is not detected.
- Perform Component Function Check if DTC CONFIRMATION PROCEDURE is not included on Service Manual. This simplified check procedure is an effective alternative though DTC cannot be detected during this check.  
If the result of Component Function Check is NG, it is the same as the detection of DTC by DTC CONFIRMATION PROCEDURE.

Is DTC detected?

YES >> GO TO 7.

NO >> Check according to [GI-45. "Intermittent Incident"](#).

---

## 6. DETECT MALFUNCTIONING SYSTEM BY SYMPTOM DIAGNOSIS

---

Detect malfunctioning system according to SYMPTOM DIAGNOSIS based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

Is the symptom described?

YES >> GO TO 7.

NO >> Monitor input data from related sensors or check voltage of related module terminals using CONSULT.

---

## 7. DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

---



# DIAGNOSIS AND REPAIR WORK FLOW

[XENON TYPE]

## < BASIC INSPECTION >

Inspect according to Diagnostic Procedure of the system.

Is malfunctioning part detected?

YES >> GO TO 8.

NO >> Check according to [GI-45. "Intermittent Incident"](#).

## 8. REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnostic Procedure again after repair and replacement.
3. Check DTC. If DTC is detected, erase it.

>> GO TO 9.

## 9. FINAL CHECK

When DTC is detected in step 2, perform DTC CONFIRMATION PROCEDURE again, and then check that the malfunction is repaired securely.

When symptom is described by the customer, refer to confirmed symptom in step 3 or 4, and check that the symptom is not detected.

Is DTC detected and does symptom remain?

YES-1 >> DTC is detected: GO TO 7.

YES-2 >> Symptom remains: GO TO 4.

NO >> Before returning the vehicle to the customer, always erase DTC.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# HEADLAMP (HI) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

## DTC/CIRCUIT DIAGNOSIS

### HEADLAMP (HI) CIRCUIT

#### Component Function Check

INFOID:0000000012201636

#### 1. CHECK HEADLAMP (HI) OPERATION

##### With CONSULT

1. Turn ignition switch ON.
2. Select "EXTERNAL LAMPS" in "Active Test" mode of "IPDM E/R" using CONSULT.
3. With operating the test items, check that the headlamp (HI) blinks.

**Hi** : Headlamp (HI) blinks (ON/OFF is repeated 1 second each.)

**Off** : Headlamp (HI) OFF

##### Without CONSULT

1. Start IPDM E/R auto active test. Refer to [PCS-12, "Diagnosis Description"](#).
2. Check that the headlamp (HI) blinks.

Is the inspection result normal?

YES >> Headlamp (HI) circuit is normal.

NO >> Refer to [EXL-50, "Diagnosis Procedure"](#).

#### Diagnosis Procedure

INFOID:0000000012201637

#### 1. CHECK HEADLAMP (HI) FUSE

1. Turn ignition switch OFF.
2. Check that the following fuses are not blown (open).

Unit	Location	Fuse No.	Capacity
Headlamp HI (RH)	IPDM E/R	#51	10 A
Headlamp HI (LH)		#52	

Is the fuse blown (open)?

YES >> Replace the blown fuse after repairing the affected circuit if a fuse is blown (open).

NO >> GO TO 2.

#### 2. CHECK HEADLAMP (HI) POWER SUPPLY

##### With CONSULT

1. Turn ignition switch ON.
2. Select "EXTERNAL LAMPS" in "Active Test" mode of "IPDM E/R" using CONSULT.
3. With operating the test items, check voltage between IPDM E/R harness connector and ground.

+			-	Test item	Voltage	
IPDM E/R						
Connector	Terminal					
RH	E15	49	Ground	EXTERNAL LAMPS	Hi	9 – 16 V (Repeated 1 second)
					Off	0 – 1 V
LH		50			Hi	9 – 16 V (Repeated 1 second)
					Off	0 – 1 V

Is the inspection result normal?

YES >> GO TO 3.

# HEADLAMP (HI) CIRCUIT

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Replace IPDM E/R. Refer to [PCS-37, "Removal and Installation"](#).

## 3. CHECK HEADLAMP (HI) POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and headlamp connector.
3. Check continuity between IPDM E/R harness connector and headlamp harness connector.

IPDM E/R		Headlamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E15	E55	1	Existed
LH		49		
		E54		

Is the inspection result normal?

YES-1 >> Without daytime running light system: GO TO 4.

YES-2 >> NISMO models with daytime running light system: GO TO 4.

YES-3 >> Except for NISMO models with daytime running light system: GO TO 6.

NO >> Repair or replace harness.

## 4. CHECK HEADLAMP (HI) GROUND CIRCUIT

Check continuity between headlamp harness connector and ground.

Headlamp		—	Continuity	
Connector	Terminal			
RH	E55	3	Ground	Existed
LH	E54			

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness.

## 5. CHECK HEADLAMP (HI) BULB

Check the applicable headlamp (HI) bulb.

Is the inspection result normal?

YES >> Check the corresponding headlamp (HI) harness. Repair or replace if necessary.

NO >> Replace the corresponding headlamp (HI) bulb. Refer to [EXL-96, "Replacement"](#).

## 6. CHECK ILLUMINATION STATUS OF HEADLAMPS

Check illumination status of headlamps.

Which headlamp does not turn ON?

RH >> GO TO 7.

LH >> GO TO 11.

## 7. CHECK HEADLAMP (HI) RH GROUND CIRCUIT-1

1. Remove daytime running light relay.
2. Check continuity between headlamp harness connector and daytime running light relay harness connector.

Headlamp		Daytime running light relay		Continuity
Connector	Terminal	Connector	Terminal	
E55	3	E65	3	Existed

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair or replace harness.

## 8. CHECK HEADLAMP (HI) RH GROUND CIRCUIT-2

Check continuity between daytime running light relay harness connector and ground.

# HEADLAMP (HI) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

Daytime running light relay		—	Continuity
Connector	Terminal		
E65	4	Ground	Existed

Is the inspection result normal?

YES >> GO TO 9.

NO >> Repair or replace harness.

## 9.CHECK DAYTIME RUNNING LIGHT RELAY

Check daytime running light relay. Refer to [EXL-52, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 10.

NO >> Replace daytime running light relay.

## 10.CHECK HEADLAMP (HI) RH BULB

Check the headlamp (HI) RH bulb.

Is the inspection result normal?

YES >> Check the headlamp (HI) RH harness. Repair or replace if necessary.

NO >> Replace headlamp (HI) RH bulb. Refer to [EXL-96, "Replacement"](#).

## 11.CHECK HEADLAMP (HI) LH GROUND CIRCUIT

Check continuity between headlamp harness connector and ground.

Headlamp		—	Continuity
Connector	Terminal		
E54	3	Ground	Existed

Is the inspection result normal?

YES >> GO TO 12.

NO >> Repair or replace harness.

## 12.CHECK HEADLAMP (HI) LH BULB

Check the headlamp (HI) LH bulb.

Is the inspection result normal?

YES >> Check the headlamp (HI) LH harness. Repair or replace if necessary.

NO >> Replace headlamp (HI) LH bulb. Refer to [EXL-96, "Replacement"](#).

## Component Inspection

INFOID:0000000012201638

## 1.CHECK DAYTIME RUNNING LIGHT RELAY

1. Turn ignition switch OFF.
2. Remove daytime running light relay.
3. Apply battery voltage to daytime running light relay between terminals 2 and 1.
4. Check continuity of daytime running light relay terminals.

Daytime running light relay		Condition		Continuity
Terminal				
3	4	Battery voltage	Apply	Not existed
			Not apply	Existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace daytime running light relay.

# HEADLAMP (LO) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

## HEADLAMP (LO) CIRCUIT

### Component Function Check

INFOID:000000012201639

#### 1. CHECK HEADLAMP (LO) OPERATION

With CONSULT

1. Turn ignition switch ON.
2. Select "EXTERNAL LAMPS" in "Active Test" mode of "IPDM E/R" using CONSULT.
3. With operating the test items, check that the headlamp (LO) is turned ON.

**Lo** : Headlamp (LO) ON

**Off** : Headlamp (LO) OFF

Without CONSULT

1. Start IPDM E/R auto active test. Refer to [PCS-12, "Diagnosis Description"](#).
2. Check that the headlamp (LO) is turned ON.

Is the inspection result normal?

YES >> Headlamp (LO) circuit is normal.

NO >> Refer to [EXL-53, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000012201640

#### 1. CHECK HEADLAMP (LO) FUSE

1. Turn ignition switch OFF.
2. Check that the following fuses are not blown (open).

Unit	Location	Fuse No.	Capacity
Headlamp LO (RH)	IPDM E/R	#54	15 A
Headlamp LO (LH)		#53	

Is the fuse blown (open)?

YES >> Replace the blown fuse after repairing the affected circuit if a fuse is blown (open).

NO >> GO TO 2.

#### 2. CHECK HEADLAMP (LO) POWER SUPPLY

With CONSULT

1. Turn ignition switch ON.
2. Select "EXTERNAL LAMPS" in "Active Test" mode of "IPDM E/R" using CONSULT.
3. With operating the test items, check voltage between IPDM E/R harness connector and ground.

+		Terminal	-	Test item	Voltage		
IPDM E/R							
Connector							
RH	E15	52	Ground	EXTERNAL LAMPS	LO	9 – 16 V	
						Off	0 – 1 V
LH		51				LO	9 – 16 V
						Off	0 – 1 V

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace IPDM E/R. Refer to [PCS-37, "Removal and Installation"](#).

#### 3. CHECK HEADLAMP (LO) POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and headlamp connector.
3. Check continuity between IPDM E/R harness connector and headlamp harness connector.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# HEADLAMP (LO) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

IPDM E/R		Headlamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E15	E55	4	Existed
LH		51		

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

## 4. CHECK HEADLAMP (LO) GROUND CIRCUIT

Check continuity between headlamp harness connector and ground.

Headlamp		Terminal	—	Continuity
Connector	Terminal			
RH	E55	2	Ground	Existed
LH	E54			

Is the inspection result normal?

YES >> Perform the xenon headlamp diagnosis. Refer to [EXL-55. "Diagnosis Procedure"](#).

NO >> Repair or replace harness.

# XENON HEADLAMP

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

## XENON HEADLAMP

### Diagnosis Procedure

INFOID:000000012201641

#### 1.CHECK XENON BULB

Install the normal bulb to the applicable headlamp. Check that the headlamp (LO) is turned ON.

Is the headlamp (LO) turned ON?

- YES >> Replace the corresponding xenon bulb. Refer to [EXL-96. "Replacement"](#).
- NO >> GO TO 2.

#### 2.CHECK XENON HEADLAMP

Install the normal headlamp assembly to the applicable headlamp. Check that the headlamp (LO) is turned ON.

Is the headlamp (LO) turned ON?

- YES >> Replace the corresponding headlamp assembly. Refer to [EXL-96. "Removal and Installation"](#).
- NO >> Xenon headlamp is normal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# PARKING LAMP CIRCUIT

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

## PARKING LAMP CIRCUIT

### Component Function Check

INFOID:000000012201642

#### 1. CHECK TAIL LAMP OPERATION

Check that the tail lamp is turned ON.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check tail lamp circuit. Refer to [EXL-60, "Component Function Check"](#).

#### 2. CHECK PARKING LAMP OPERATION

With CONSULT

1. Turn ignition switch ON.
2. Select "EXTERNAL LAMPS" in "Active Test" mode of "IPDM E/R" using CONSULT.
3. With operating the test items, check that the parking lamp is turned ON.

**TAIL : Parking lamp ON**  
**Off : Parking lamp OFF**

Without CONSULT

1. Start IPDM E/R auto active test. Refer to [PCS-12, "Diagnosis Description"](#).
2. Check that the parking lamp is turned ON.

Is the inspection result normal?

YES >> Parking lamp circuit is normal.

NO >> Refer to [EXL-56, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000012201643

#### 1. CHECK PARKING LAMP POWER SUPPLY

With CONSULT

1. Turn ignition switch ON.
2. Select "EXTERNAL LAMPS" in "Active Test" mode of "IPDM E/R" using CONSULT.
3. With operating the test items, check voltage between IPDM E/R harness connector and ground.

+		-	Test item	Voltage	
IPDM E/R					
Connector	Terminal				
E14	43	Ground	EXTERNAL LAMPS	TAIL	9 – 16 V
				Off	0 – 1 V

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace IPDM E/R. Refer to [PCS-37, "Removal and Installation"](#).

#### 2. CHECK PARKING LAMP POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and parking lamp connector.
3. Check continuity between IPDM E/R harness connector and parking lamp harness connector.

IPDM E/R		Parking lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E14	43	E44	Existed
LH			E28	

Is the inspection result normal?

YES >> GO TO 3.



# PARKING LAMP CIRCUIT

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair or replace harness.

## 3. CHECK PARKING LAMP GROUND CIRCUIT

Check continuity between parking lamp harness connector and ground.

Parking lamp		Terminal	—	Continuity
Connector				
RH	E44	2	Ground	Existed
LH	E28			

Is the inspection result normal?

YES >> Replace the corresponding front combination lamp. Refer to [EXL-100. "Removal and Installation"](#).

NO >> Repair or replace harness.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# FRONT SIDE MARKER LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

## FRONT SIDE MARKER LAMP CIRCUIT

### Component Function Check

INFOID:000000012201644

#### 1. CHECK PARKING LAMP OPERATION

Check that the parking lamp is turned ON.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check parking lamp circuit. Refer to [EXL-56, "Component Function Check"](#).

#### 2. CHECK FRONT SIDE MARKER LAMP OPERATION

Ⓟ With CONSULT

1. Turn ignition switch ON.
2. Select "EXTERNAL LAMPS" in "Active Test" mode of "IPDM E/R" using CONSULT.
3. With operating the test items, check that the front side marker lamp is turned ON.

**TAIL : Front side marker lamp ON**

**Off : Front side marker lamp OFF**

ⓧ Without CONSULT

1. Start IPDM E/R auto active test. Refer to [PCS-12, "Diagnosis Description"](#).
2. Check that the front side marker lamp is turned ON.

Is the inspection result normal?

YES >> Front side marker lamp circuit is normal.

NO >> Refer to [EXL-58, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000012201645

#### 1. CHECK FRONT SIDE MARKER LAMP POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and front side marker lamp connector.
3. Check continuity between IPDM E/R harness connector and front side marker lamp harness connector.

IPDM E/R		Front side marker lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E14	E32	1	Existed
LH		E31		

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness.

#### 2. CHECK FRONT SIDE MARKER LAMP GROUND CIRCUIT

Check continuity between front side marker lamp harness connector and ground.

Front side marker lamp		Terminal	—	Continuity
Connector	Terminal			
RH	E32	2	Ground	Existed
LH	E31			

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

#### 3. CHECK FRONT SIDE MARKER LAMP BULB

Check the applicable front side marker lamp bulb.

# FRONT SIDE MARKER LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

Is the inspection result normal?

YES >> Check the corresponding front side marker lamp bulb socket. Repair or replace if necessary.

NO >> Replace the corresponding front side marker lamp bulb. Refer to [EXL-100, "Replacement"](#).

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

# TAIL LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

## TAIL LAMP CIRCUIT

### Component Function Check

INFOID:0000000012201646

#### 1. CHECK TAIL LAMP OPERATION

##### ④ With CONSULT

1. Turn ignition switch ON.
2. Select "EXTERNAL LAMPS" in "Active Test" mode of "IPDM E/R" using CONSULT.
3. With operating the test items, check that the tail lamp is turned ON.

**TAIL** : Tail lamp ON  
**Off** : Tail lamp OFF

##### ⊗ Without CONSULT

1. Start IPDM E/R auto active test. Refer to [PCS-12, "Diagnosis Description"](#).
2. Check that the tail lamp is turned ON.

Is the inspection result normal?

- YES >> Tail lamp circuit is normal.  
 NO >> Refer to [EXL-60, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000012201647

#### 1. CHECK FUSE

1. Turn ignition switch OFF.
2. Check that the following fuse is not blown (open).

Unit	Location	Fuse No.	Capacity
<ul style="list-style-type: none"> <li>• Parking lamp RH</li> <li>• Parking lamp LH</li> <li>• Front side marker lamp RH</li> <li>• Front side marker lamp LH</li> <li>• Tail lamp RH</li> <li>• Tail lamp LH</li> <li>• License plate lamp RH</li> <li>• License plate lamp LH</li> </ul>	IPDM E/R	#47	10 A

Is the fuse blown (open)?

- YES >> Replace the blown fuse after repairing the affected circuit if a fuse is blown (open).  
 NO >> GO TO 2.

#### 2. CHECK TAIL LAMP POWER SUPPLY

##### ④ With CONSULT

1. Turn ignition switch ON.
2. Select "EXTERNAL LAMPS" in "Active Test" mode of "IPDM E/R" using CONSULT.
3. With operating the test items, check voltage between IPDM E/R harness connector and ground.

+		-	Test item	Voltage	
IPDM E/R					
Connector	Terminal				
E14	44	Ground	EXTERNAL LAMPS	TAIL	9 – 16 V
				Off	0 – 1 V

Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> Replace IPDM E/R. Refer to [PCS-37, "Removal and Installation"](#).

#### 3. CHECK TAIL LAMP POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.

# TAIL LAMP CIRCUIT

[XENON TYPE]

## < DTC/CIRCUIT DIAGNOSIS >

2. Disconnect IPDM E/R connector and rear combination lamp connector.
3. Check continuity between IPDM E/R harness connector and rear combination lamp harness connector.

IPDM E/R		Rear combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E14	44	B59	Existed
LH			B80	

Is the inspection result normal?

- YES >> GO TO 4.  
 NO >> Repair or replace harness.

### 4. CHECK TAIL LAMP GROUND CIRCUIT

Check continuity between rear combination lamp harness connector and ground.

Rear combination lamp		Terminal	—	Continuity
Connector	Terminal			
RH	B59	3	Ground	Existed
LH	B80			

Is the inspection result normal?

- YES-1 >> Stop lamp / tail lamp (Bulb side): GO TO 5.  
 YES-2 >> Tail lamp (LED side): Check the corresponding tail lamp harness, and if check result is normal, replace the corresponding rear combination lamp. Refer to [EXL-109, "Removal and Installation"](#).  
 NO >> Repair or replace harness.

### 5. CHECK STOP LAMP / TAIL LAMP BULB

Check the applicable stop lamp / tail lamp bulb.

Is the inspection result normal?

- YES >> Check the corresponding stop lamp / tail lamp bulb socket and harness. Repair or replace if necessary.  
 NO >> Repair or replace the corresponding stop lamp / tail lamp bulb. Refer to [EXL-109, "Replacement"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

EXL

# LICENSE PLATE LAMP CIRCUIT

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

## LICENSE PLATE LAMP CIRCUIT

### Component Function Check

INFOID:000000012201648

#### 1. CHECK TAIL LAMP OPERATION

Check that the tail lamp is turned ON.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check tail lamp circuit. Refer to [EXL-60, "Component Function Check"](#).

#### 2. CHECK LICENSE PLATE LAMP OPERATION

Ⓟ With CONSULT

1. Turn ignition switch ON.
2. Select "EXTERNAL LAMPS" in "Active Test" mode of "IPDM E/R" using CONSULT.
3. With operating the test items, check that the license plate lamp is turned ON.

**TAIL : License plate lamp ON**

**Off : License plate lamp OFF**

ⓧ Without CONSULT

1. Start IPDM E/R auto active test. Refer to [PCS-12, "Diagnosis Description"](#).
2. Check that the license plate lamp is turned ON.

Is the inspection result normal?

YES >> License plate lamp circuit is normal.

NO >> Refer to [EXL-62, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000012201649

#### 1. CHECK LICENSE PLATE LAMP POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and back door opener switch connector.
3. Check continuity between IPDM E/R harness connector and back door opener switch harness connector.

IPDM E/R		Back door opener switch		Continuity
Connector	Terminal	Connector	Terminal	
E14	44	D107	5	Existed

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness.

#### 2. CHECK LICENSE PLATE LAMP GROUND CIRCUIT

Check continuity between back door opener switch harness connector and ground.

Back door opener switch		—	Continuity
Connector	Terminal		
D107	6	Ground	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

#### 3. CHECK LICENSE PLATE LAMP BULB

Check the applicable license plate lamp bulb.

Is the inspection result normal?

# LICENSE PLATE LAMP CIRCUIT

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

- YES >> Check the corresponding license plate lamp bulb socket and harness. Repair or replace if necessary.
- NO >> Replace the corresponding license plate lamp bulb. Refer to [EXL-113. "Replacement"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# DAYTIME RUNNING LIGHT RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

## DAYTIME RUNNING LIGHT RELAY CIRCUIT

### Component Function Check

INFOID:0000000012201650

#### 1. CHECK DAYTIME RUNNING LIGHT OPERATION

Ⓟ With CONSULT

1. Select "HEAD LAMP" of "BCM" using CONSULT.
2. Select "DAYTIME RUNNING LIGHT" in "Active Test" mode.
3. With operating the test items, check that the daytime running light is turned ON [Headlamp (HI) at approximately half illumination].

**On** : Daytime running light ON [Headlamp (HI) at approximately half illumination]

**Off** : Daytime running light OFF

Is the inspection result normal?

- YES >> Daytime running light relay circuit is normal.  
NO >> Refer to [EXL-64, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000012201651

#### 1. CHECK DAYTIME RUNNING LIGHT RELAY FUSE

1. Turn ignition switch OFF.
2. Check that the following fuses are not blown (open).

Unit	Fuse No.	Capacity
Daytime running light relay	#24	10 A

Is the fuse blown (open)?

- YES >> Replace the blown fuse after repairing the affected circuit if a fuse is blown (open).  
NO >> GO TO 2.

#### 2. CHECK DAYTIME RUNNING LIGHT RELAY POWER SUPPLY

1. Remove daytime running light relay.
2. Check voltage between daytime running light relay harness connector and ground.

+		-	Voltage (Approx.)
Connector	Terminal		
E65	1	Ground	Battery voltage
	5		

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair or replace harness.

#### 3. CHECK DAYTIME RUNNING LIGHT RELAY

Check daytime running light relay. Refer to [EXL-65, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Replace daytime running light relay.

#### 4. CHECK DAYTIME RUNNING LIGHT RELAY CONTROL SIGNAL

Ⓟ With CONSULT

1. Install daytime running light relay.
2. Turn ignition switch ON.
3. Select "HEAD LAMP" of "BCM" using CONSULT.
4. Select "DAYTIME RUNNING LIGHT" in "Active Test" mode.



# DAYTIME RUNNING LIGHT RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

5. With operating the test item, check voltage between IPDM E/R harness connector and ground.

+		-	Test item	Voltage	
IPDM E/R					
Connector	Terminal				
E13	28	Ground	DAYTIME RUNNING LIGHT	On	0 – 1 V
				Off	9 – 16 V

Is the inspection result normal?

- YES >> Daytime running light relay circuit is normal.  
 NO-1 >> Fixed at 0 – 1 V: GO TO 6.  
 NO-2 >> Fixed at 9 – 16 V: GO TO 5.

## 5.CHECK DAYTIME RUNNING LIGHT REQUEST SIGNAL

④ With CONSULT

- Select "DTRL REQ" in "Data Monitor" mode of "IPDM E/R" using CONSULT.
- With operating the daytime running light ON condition, check the monitor status.

Monitor item	Condition	Monitor status	
DTRL REQ	Daytime running light	ON condition	On
		OFF condition	Off

Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-37, "Removal and Installation"](#).  
 NO >> Replace BCM. Refer to [BCS-94, "Removal and Installation"](#).

## 6.CHECK DAYTIME RUNNING LIGHT RELAY CONTROL SIGNAL CIRCUIT

- Turn ignition switch OFF.
- Remove daytime running light relay.
- Disconnect IPDM E/R harness connector.
- Check continuity between IPDM E/R harness connector and daytime running light relay harness connector.

IPDM E/R		Daytime running light relay		Continuity
Connector	Terminal	Connector	Terminal	
E13	28	E65	2	Existed

Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-37, "Removal and Installation"](#).  
 NO >> Repair or replace harness.

## Component Inspection

INFOID:000000012201652

### 1.CHECK DAYTIME RUNNING LIGHT RELAY

- Turn ignition switch OFF.
- Remove daytime running light relay.
- Apply battery voltage to daytime running light relay between terminals 1 and 2.
- Check continuity of daytime running light relay terminals.

Daytime running light relay		Condition	Continuity	
Terminal				
5	3	Battery voltage	Apply	Existed
			Not apply	Not existed

Is the inspection result normal?

- YES >> INSPECTION END

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

## DAYTIME RUNNING LIGHT RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

---

NO >> Replace daytime running light relay.

# DAYTIME RUNNING LIGHT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

## DAYTIME RUNNING LIGHT CIRCUIT

### Component Function Check

INFOID:000000012201653

#### 1. CHECK DAYTIME RUNNING LIGHT OPERATION

With CONSULT

1. Select "EXTERNAL LAMPS" in "Active Test" mode of "IPDM E/R" using CONSULT.
2. With operating the test items, check that the daytime running light is turned ON.

**Fog : Daytime running light ON**

**Off : Daytime running light OFF**

Without CONSULT

1. Start IPDM E/R auto active test. Refer to [PCS-12, "Diagnosis Description"](#).
2. Check that the daytime running light is turned ON.

Is the measurement normal?

YES >> Daytime running light circuit is normal.

NO >> Refer to [EXL-67, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000012201654

#### 1. CHECK DAYTIME RUNNING LIGHT FUSE

1. Turn ignition switch OFF.
2. Check that the following fuse is not blown (open).

Unit	Location	Fuse No.	Capacity
Daytime running light	IPDM E/R	#50	15 A

Is the fuse blown (open)?

YES >> Replace the blown fuse after repairing the affected circuit if a fuse is blown (open).

NO >> GO TO 2.

#### 2. CHECK DAYTIME RUNNING LIGHT POWER SUPPLY

With CONSULT

1. Turn ignition switch ON.
2. Select "EXTERNAL LAMPS" in "Active Test" mode of "IPDM E/R" using CONSULT.
3. With operating the test items, check the voltage between IPDM E/R harness connector and ground.

+		Terminal	-	Test item	Voltage	
IPDM E/R						
Connector						
RH	E12	19	Ground	EXTERNAL LAMPS	Fog	9 – 16 V
					Off	0 – 1 V
LH		20			Fog	9 – 16 V
					Off	0 – 1 V

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace IPDM E/R. Refer to [PCS-37, "Removal and Installation"](#).

#### 3. CHECK DAYTIME RUNNING LIGHT POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and daytime running light connector.
3. Check continuity between IPDM E/R harness connector and daytime running light harness connector.

# DAYTIME RUNNING LIGHT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

IPDM E/R		Daytime running light		Continuity
Connector	Terminal	Connector	Terminal	
RH	E12	E75	1	Existed
LH		20		

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

## 4. CHECK DAYTIME RUNNING LIGHT GROUND CIRCUIT

Check continuity between daytime running light harness connector and ground.

Daytime running light		Terminal	—	Continuity
Connector	Terminal			
RH	E75	2	Ground	Existed
LH	E76			

Is the inspection result normal?

YES >> Replace the corresponding daytime running light. Refer to [EXL-101. "Removal and Installation"](#).

NO >> Repair or replace harness.

# FRONT FOG LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

## FRONT FOG LAMP CIRCUIT

### Component Function Check

INFOID:000000012201655

#### 1. CHECK FRONT FOG LAMP OPERATION

With CONSULT

1. Select "EXTERNAL LAMPS" in "Active Test" mode of "IPDM E/R" using CONSULT.
2. With operating the test items, check that the front fog lamp is turned ON.

**Fog** : Front fog lamp ON  
**Off** : Front fog lamp OFF

Without CONSULT

1. Start IPDM E/R auto active test. Refer to [PCS-12, "Diagnosis Description"](#).
2. Check that the front fog lamp is turned ON.

Is the measurement normal?

- YES >> Front fog lamp circuit is normal.  
 NO >> Refer to [EXL-69, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000012201656

#### 1. CHECK FRONT FOG LAMP FUSE

1. Turn ignition switch OFF.
2. Check that the following fuses are not blown (open).

Unit	Location	Fuse No.	Capacity
Front fog lamp	IPDM E/R	#50	15 A

Is the fuse blown (open)?

- YES >> Replace the blown fuse after repairing the affected circuit if a fuse is blown (open).  
 NO >> GO TO 2.

#### 2. CHECK FRONT FOG LAMP POWER SUPPLY

With CONSULT

1. Disconnect front fog lamp connector.
2. Turn ignition switch ON.
3. Select "EXTERNAL LAMPS" in "Active Test" mode of "IPDM E/R" using CONSULT.
4. With operating the test items, check the voltage between IPDM E/R harness connector and ground.

+		-	Test item	Voltage	
IPDM E/R					
Connector	Terminal				
RH	E12	19	EXTERNAL LAMPS	Fog	9 – 16 V
				Off	0 – 1 V
LH		20		Fog	9 – 16 V
				Off	0 – 1 V

Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> Replace IPDM E/R. Refer to [PCS-37, "Removal and Installation"](#).

#### 3. CHECK FRONT FOG LAMP POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and front fog lamp harness connector.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

EXL

# FRONT FOG LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

IPDM E/R		Front fog lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E12	19	E48	Existed
LH		20	E30	

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

## 4. CHECK FRONT FOG LAMP GROUND CIRCUIT

Check continuity between front fog lamp harness connector and ground.

Front fog lamp		Terminal	—	Continuity
Connector	Terminal			
RH	E48	2	Ground	Existed
LH	E30			

Is the inspection result normal?

YES >> Replace the corresponding front fog lamp bulb. Refer to [EXL-103. "Replacement"](#).

NO >> Repair or replace harness.

# TURN SIGNAL LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

## TURN SIGNAL LAMP CIRCUIT

### Component Function Check

INFOID:000000012201657

#### 1. CHECK TURN SIGNAL LAMP OPERATION

Ⓜ With CONSULT

1. Turn ignition switch ON.
2. Select "FLASHER" of "BCM" using CONSULT.
3. Select "FLASHER" in "Active Test" mode.
4. With operating the test items, check that the turn signal lamps is turned ON.

**RH : Turn signal lamps (RH) ON**

**LH : Turn signal lamps (LH) ON**

**Off : Turn signal lamps OFF**

Is the inspection result normal?

- YES >> Turn signal lamp circuit is normal.  
 NO >> Refer to [EXL-71, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000012201658

#### 1. CHECK TURN SIGNAL LAMP POWER SUPPLY

Ⓜ With CONSULT

1. Turn ignition switch OFF.
2. Disconnect the following connectors.
  - Front turn signal lamp
  - Door mirror
  - Rear combination lamp
3. Turn ignition switch ON.
4. Select "FLASHER" of "BCM" using CONSULT.
5. Select "FLASHER" in "Active Test" mode.
6. With operating the test items, check voltage between BCM harness connector and ground.

+			-	Test item	Voltage		
BCM							
Connector	Terminal						
RH	M69	61	Ground	FLASHER	RH	9 – 16 V	
						Off	0 V
LH		60				LH	9 – 16 V
						Off	0 V

Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> GO TO 2.

#### 2. CHECK TURN SIGNAL LAMP POWER SUPPLY CIRCUIT (SHORT)

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and ground.

BCM			—	Continuity
Connector	Terminal			
RH	M69	61	Ground	Not existed
LH				

Is the inspection result normal?

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# TURN SIGNAL LAMP CIRCUIT

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

- YES >> Replace BCM. Refer to [BCS-94, "Removal and Installation"](#).  
 NO >> Repair or replace harness.

## 3. CHECK TURN SIGNAL LAMP POWER SUPPLY CIRCUIT (OPEN)

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and each turn signal lamp harness connector.

Front turn signal lamp

BCM			Front turn signal lamp		Continuity
Connector		Terminal	Connector	Terminal	
RH	M69	61	E47	1	Existed
LH		60	E34		

Side turn signal lamp

BCM			Door mirror		Continuity
Connector		Terminal	Connector	Terminal	
RH	M69	61	D9	13	Existed
LH		60	D30		

Rear turn signal lamp

BCM			Rear combination lamp		Continuity
Connector		Terminal	Connector	Terminal	
RH	M69	61	B59	5	Existed
LH		60	B80		

Is the inspection result normal?

- YES >> GO TO 4.  
 NO >> Repair or replace harness.

## 4. CHECK TURN SIGNAL LAMP GROUND CIRCUIT

Check continuity between each turn signal lamp harness connector and ground.

Front turn signal lamp

Front turn signal lamp			—	Continuity
Connector		Terminal		
RH	E47	2	Ground	Existed
LH				

Side turn signal lamp

Door mirror			—	Continuity
Connector		Terminal		
RH	D9	2	Ground	Existed
LH				

Rear turn signal lamp

Rear combination lamp			—	Continuity
Connector		Terminal		
RH	B59	3	Ground	Existed
LH				

Is the inspection result normal?

- YES-1 >> Front turn signal lamp or rear turn signal lamp: GO TO 5.  
 YES-2 >> Side turn signal lamp: Replace the corresponding side turn signal lamp. Refer to [EXL-104, "Removal and Installation"](#).  
 NO >> Repair or replace harness.



# TURN SIGNAL LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

## 5. CHECK TURN SIGNAL LAMP BULB

Check the applicable turn signal lamp bulb.

Is the inspection result normal?

YES-1 >> Front turn signal lamp: Check the corresponding front turn signal lamp bulb socket. Repair or replace if necessary.

YES-2 >> Rear turn signal lamp: Check the corresponding rear turn signal lamp bulb socket and harness. Repair or replace if necessary.

NO >> Replace the corresponding turn signal lamp bulb. Refer to [EXL-100, "Replacement"](#) (front turn signal lamp) or [EXL-109, "Replacement"](#) (rear turn signal lamp).

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

## OPTICAL SENSOR

## Component Function Check

INFOID:000000012201659

## 1.CHECK OPTICAL SENSOR SIGNAL

## ④ With CONSULT

1. Turn ignition switch ON.
2. Select "HEAD LAMP" of "BCM" using CONSULT.
3. Select "OPTI SEN (DTCT)" in "Data Monitor" mode.
4. Turn lighting switch AUTO.
5. With the optical sensor illuminating, check the monitor status.

Monitor item	Condition		Voltage (Approx.)
OPTI SEN (DTCT)	Optical sensor	When illuminating	3.1 V or more *
		When shutting off light	0.6 V or less

\*: Illuminates the optical sensor. The value may be less than the standard value if brightness is weak.

Is the inspection result normal?

- YES >> Optical sensor is normal.  
 NO >> Refer to [EXL-74, "Diagnosis Procedure"](#).

## Diagnosis Procedure

INFOID:000000012201660

## 1.CHECK OPTICAL SENSOR POWER SUPPLY

1. Turn ignition switch ON.
2. Turn lighting switch AUTO.
3. Check voltage between optical sensor harness connector and ground.

+		-	Voltage (Approx.)
Optical sensor			
Connector	Terminal		
M84	1	Ground	5 V

Is the inspection result normal?

- YES >> GO TO 2.  
 NO >> GO TO 4.

## 2.CHECK OPTICAL SENSOR GROUND

Check voltage between optical sensor harness connector and ground.

+		-	Voltage (Approx.)
Optical sensor			
Connector	Terminal		
M84	3	Ground	0 V

Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> GO TO 6.

## 3.CHECK OPTICAL SENSOR SIGNAL

With illuminating the optical sensor, check voltage between optical sensor harness connector and ground.

# OPTICAL SENSOR

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

+		-	Condition	Voltage (Approx.)	
Optical sensor					
Connector	Terminal				
M84	2	Ground	Optical sensor	When illuminating	3.1 V or more*
				When shutting off light	0.6 V or less

\*: Illuminate the optical sensor. The value may be less than the standard if brightness is weak.

Is the inspection result normal?

YES >> GO TO 7.

NO >> Replace optical sensor. Refer to [EXL-105. "Removal and Installation"](#).

## 4. CHECK OPTICAL SENSOR POWER SUPPLY CIRCUIT (OPEN)

1. Turn ignition switch OFF.
2. Disconnect optical sensor connector and BCM connector.
3. Check continuity between optical sensor harness connector and BCM harness connector.

Optical sensor		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M84	1	M68	17	Existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness.

## 5. CHECK OPTICAL SENSOR POWER SUPPLY CIRCUIT (SHORT)

Check continuity between optical sensor harness connector and ground.

Optical sensor		—	Continuity
Connector	Terminal		
M84	1	Ground	Not existed

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-94. "Removal and Installation"](#).

NO >> Repair or replace harness.

## 6. CHECK OPTICAL SENSOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect optical sensor connector and BCM connector.
3. Check continuity between optical sensor harness connector and BCM harness connector.

Optical sensor		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M84	3	M68	18	Existed

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-94. "Removal and Installation"](#).

NO >> Repair or replace harness.

## 7. CHECK OPTICAL SENSOR SIGNAL CIRCUIT (OPEN)

1. Turn ignition switch OFF.
2. Disconnect optical sensor connector and BCM connector.
3. Check continuity between optical sensor harness connector and BCM harness connector.

# OPTICAL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

Optical sensor		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M84	2	M68	14	Existed

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair or replace harness.

## 8. CHECK OPTICAL SENSOR SIGNAL CIRCUIT (SHORT)

Check continuity between optical sensor harness connector and ground.

Optical sensor		—	Continuity
Connector	Terminal		
M84	2	Ground	Not existed

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-94, "Removal and Installation"](#).

NO >> Repair or replace harness.

# HAZARD SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

## HAZARD SWITCH

### Component Function Check

INFOID:000000012201661

#### 1.CHECK HAZARD SWITCH SIGNAL

Ⓜ With CONSULT

1. Turn ignition switch ON.
2. Select "FLASHER" of "BCM" using CONSULT.
3. Select "HAZARD SW" in "Data Monitor" mode.
4. With operating the hazard switch, check the monitor status.

Monitor item	Condition		Monitor status
HAZARD SW	Hazard switch	ON	On
		OFF	Off

Is the inspection result normal?

- YES >> Hazard switch circuit is normal.  
 NO >> Refer to [EXL-77, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000012201662

#### 1.CHECK HAZARD SWITCH SIGNAL

1. Turn ignition switch OFF.
2. Disconnect hazard switch connector.
3. Check voltage between hazard switch connector and ground.

+		-	Voltage (Approx.)
Hazard switch			
Connector	Terminal	Ground	12 V
M45	2		

Is the inspection result normal?

- YES >> GO TO 4.  
 NO >> GO TO 2.

#### 2.CHECK HAZARD SWITCH SIGNAL CIRCUIT (OPEN)

1. Disconnect BCM connector.
2. Check continuity between hazard switch harness connector and BCM harness connector.

Hazard switch		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M45	2	M68	29	Existed

Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> Repair or replace harness.

#### 3.CHECK HAZARD SWITCH SIGNAL CIRCUIT (SHORT)

Check continuity between hazard switch harness connector and ground.

Hazard switch		—	Continuity
Connector	Terminal		
M45	2	Ground	Not existed

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-94, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

EXL

# HAZARD SWITCH

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair or replace harness.

## 4. CHECK HAZARD SWITCH GROUND CIRCUIT

Check continuity between hazard switch harness connector and ground.

Hazard switch		—	Continuity
Connector	Terminal		
M45	1	Ground	Existed

Is the inspection result normal?

YES >> Replace hazard switch. Refer to [EXL-107. "Removal and Installation"](#).

NO >> Repair or replace harness.

# EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

## SYMPTOM DIAGNOSIS

### EXTERIOR LIGHTING SYSTEM SYMPTOMS

#### Symptom Table

INFOID:0000000012201663

EXCEPT FOR NISMO MODELS

Without Daytime Running Light System

**NOTE:**

Perform the self-diagnosis with CONSULT before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom		Possible cause	Inspection item
Headlamp (HI) is not turned ON	One side	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Headlamp (HI) power supply/ ground circuit</li> <li>• Headlamp (HI) bulb</li> <li>• Headlamp assembly</li> <li>- Harness</li> <li>• IPDM E/R</li> </ul>	Headlamp (HI) circuit Refer to <a href="#">EXL-50, "Component Function Check"</a> .
	Both sides	<b>Symptom diagnosis</b> "BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON" Refer to <a href="#">EXL-87, "Diagnosis Procedure"</a> .	
High beam indicator lamp is not turned ON [Headlamp (HI) is turned ON]		Combination meter	<ul style="list-style-type: none"> <li>• Combination meter</li> <li>Data monitor "HI-BEAM IND"</li> <li>• BCM (HEAD LAMP)</li> <li>Active test "HEAD LAMP"</li> </ul>
Headlamp (LO) is not turned ON	One side	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Headlamp (LO) power supply/ ground circuit</li> <li>• Headlamp (LO) bulb (Xenon bulb)</li> <li>• Headlamp assembly</li> <li>- HID control unit</li> <li>- Xenon bulb socket</li> <li>- Harness</li> <li>• IPDM E/R</li> </ul>	Headlamp (LO) circuit Refer to <a href="#">EXL-53, "Component Function Check"</a> .
	Both sides	<b>Symptom diagnosis</b> "BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON" Refer to <a href="#">EXL-88, "Diagnosis Procedure"</a> .	
Each lamp is not turned ON/OFF with lighting switch AUTO		<ul style="list-style-type: none"> <li>• Combination switch input/output signal circuit</li> <li>• Combination switch</li> <li>• BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-92, "Symptom Table"</a> .
		<ul style="list-style-type: none"> <li>• Optical sensor power supply/ ground/signal circuit</li> <li>• Optical sensor</li> <li>• BCM</li> </ul>	Optical sensor Refer to <a href="#">EXL-74, "Component Function Check"</a> .
Parking lamp is not turned ON		<ul style="list-style-type: none"> <li>• Parking lamp power supply/ ground circuit</li> <li>• Front combination lamp</li> <li>- LED (Parking lamp)</li> <li>- Harness</li> <li>• IPDM E/R</li> </ul>	Parking lamp circuit Refer to <a href="#">EXL-56, "Component Function Check"</a> .
Front side marker lamp is not turned ON		<ul style="list-style-type: none"> <li>• Front side marker lamp power supply/ground circuit</li> <li>• Front side marker lamp bulb</li> <li>• Front side marker lamp bulb socket</li> </ul>	Front side marker lamp circuit Refer to <a href="#">EXL-58, "Component Function Check"</a> .

# EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

Symptom		Possible cause	Inspection item
Tail lamp is not turned ON	Stop lamp / Tail lamp (Bulb side)	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Tail lamp power supply/ground circuit</li> <li>• Stop lamp / Tail lamp bulb</li> <li>• Stop lamp / Tail lamp bulb socket/harness</li> <li>• IPDM E/R</li> </ul>	Tail lamp circuit Refer to <a href="#">EXL-60, "Component Function Check"</a> .
	Tail lamp (LED side)	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Tail lamp power supply/ground circuit</li> <li>• Rear combination lamp internal circuit</li> <li>- LED (Tail lamp)</li> <li>• Tail lamp harness</li> <li>• IPDM E/R</li> </ul>	
License plate lamp is not turned ON		<ul style="list-style-type: none"> <li>• License plate lamp power supply/ground circuit</li> <li>• License plate lamp bulb</li> <li>• License plate lamp bulb socket/harness</li> </ul>	License plate lamp circuit Refer to <a href="#">EXL-62, "Component Function Check"</a> .
Parking lamp, license plate lamp, side marker lamp and tail lamp are not turned ON		<p><b>Symptom diagnosis</b>                      "PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS ARE NOT TURNED ON"                      Refer to <a href="#">EXL-89, "Diagnosis Procedure"</a>.</p>	
Position lamp indicator is not turned ON (Parking lamp, license plate lamp, side marker lamp and tail lamp are turned ON)		Combination meter	<ul style="list-style-type: none"> <li>• Combination meter Data monitor "LIGHT IND"</li> <li>• BCM (HEAD LAMP) Active test "TAIL LAMP"</li> </ul>
Front fog lamp is not turned ON	One side	<ul style="list-style-type: none"> <li>• Front fog lamp power supply/ground circuit</li> <li>• Front fog lamp bulb</li> <li>• IPDM E/R</li> </ul>	Front fog lamp circuit Refer to <a href="#">EXL-69, "Component Function Check"</a> .
	Both sides	<p><b>Symptom diagnosis</b>                      "BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON"                      Refer to <a href="#">EXL-90, "Diagnosis Procedure"</a>.</p>	
Turn signal lamp does not blink	Indicator lamp is normal (Applicable side performs high flasher activation)	<ul style="list-style-type: none"> <li>• Front turn signal lamp</li> <li>- Front turn signal lamp power supply/ground circuit</li> <li>- Front turn signal lamp bulb</li> <li>- Front turn signal lamp bulb socket</li> <li>- BCM</li> <li>• Side turn signal lamp</li> <li>- Side turn signal lamp power supply/ground circuit</li> <li>- Side turn signal lamp</li> <li>- BCM</li> <li>• Rear turn signal lamp</li> <li>- Rear turn signal lamp power supply/ground circuit</li> <li>- Rear turn signal lamp bulb</li> <li>- Rear turn signal lamp bulb socket/harness</li> <li>- BCM</li> </ul>	Turn signal lamp circuit Refer to <a href="#">EXL-71, "Component Function Check"</a> .
	Indicator lamp is included	<ul style="list-style-type: none"> <li>• Combination switch input/output signal circuit</li> <li>• Combination switch</li> <li>• BCM</li> </ul>	



# EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

Symptom	Possible cause	Inspection item
Turn signal indicator lamp does not blink (Turn signal lamp is normal)	One side	Combination meter
	Both sides (Always)	<ul style="list-style-type: none"> <li>• Turn indicator signal</li> <li>• BCM</li> <li>• Combination meter</li> </ul>
	Both sides (Only when activating hazard warning lamp with ignition switch OFF)	<ul style="list-style-type: none"> <li>• Combination meter power supply/ground circuit</li> <li>• Combination meter</li> </ul>
<ul style="list-style-type: none"> <li>• Hazard warning lamp does not activate (Turn signal is normal)</li> <li>• Hazard warning lamp continues activating</li> </ul>	<ul style="list-style-type: none"> <li>• Hazard switch signal/ground circuit</li> <li>• Hazard switch</li> <li>• BCM</li> </ul>	Hazard switch Refer to <a href="#">EXL-77, "Component Function Check"</a> .

With Daytime Running Light System

**NOTE:**

Perform the self-diagnosis with CONSULT before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom	Possible cause	Inspection item
Headlamp (HI) is not turned ON	One side	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Headlamp (HI) power supply/ground circuit</li> <li>• Daytime running light relay</li> <li>• Headlamp (HI) bulb</li> <li>• Headlamp assembly</li> <li>- Harness</li> <li>• IPDM E/R</li> </ul>
	Both sides	<p><b>Symptom diagnosis</b> "BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON" Refer to <a href="#">EXL-87, "Diagnosis Procedure"</a>.</p>
High beam indicator lamp is not turned ON [Headlamp (HI) is turned ON]	Combination meter	<ul style="list-style-type: none"> <li>• Combination meter</li> <li>• Data monitor "HI-BEAM IND"</li> <li>• BCM (HEAD LAMP)</li> <li>• Active test "HEAD LAMP"</li> </ul>
Headlamp (LO) is not turned ON	One side	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Headlamp (LO) power supply/ground circuit</li> <li>• Headlamp (LO) bulb (Xenon bulb)</li> <li>• Headlamp assembly</li> <li>- HID control unit</li> <li>- Xenon bulb socket</li> <li>- Harness</li> <li>• IPDM E/R</li> </ul>
	Both sides	<p><b>Symptom diagnosis</b> "BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON" Refer to <a href="#">EXL-88, "Diagnosis Procedure"</a>.</p>
Parking lamp is not turned ON	<ul style="list-style-type: none"> <li>• Parking lamp power supply/ground circuit</li> <li>• Front combination lamp</li> <li>- LED (Parking lamp)</li> <li>- Harness</li> <li>• IPDM E/R</li> </ul>	Parking lamp circuit Refer to <a href="#">EXL-56, "Component Function Check"</a> .
Front side marker lamp is not turned ON	<ul style="list-style-type: none"> <li>• Front side marker lamp power supply/ground circuit</li> <li>• Front side marker lamp bulb</li> <li>• Front side marker lamp bulb socket</li> </ul>	Front side marker lamp circuit Refer to <a href="#">EXL-58, "Component Function Check"</a> .

# EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

Symptom		Possible cause	Inspection item
Tail lamp is not turned ON	Stop lamp / Tail lamp (Bulb side)	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Tail lamp power supply/ground circuit</li> <li>• Stop lamp / Tail lamp bulb</li> <li>• Stop lamp / Tail lamp bulb socket/harness</li> <li>• IPDM E/R</li> </ul>	Tail lamp circuit Refer to <a href="#">EXL-60, "Component Function Check"</a> .
	Tail lamp (LED side)	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Tail lamp power supply/ground circuit</li> <li>• Rear combination lamp internal circuit</li> <li>- LED (Tail lamp)</li> <li>• Tail lamp harness</li> <li>• IPDM E/R</li> </ul>	
License plate lamp is not turned ON		<ul style="list-style-type: none"> <li>• License plate lamp power supply/ground circuit</li> <li>• License plate lamp bulb</li> <li>• License plate lamp bulb socket/harness</li> </ul>	License plate lamp circuit Refer to <a href="#">EXL-62, "Component Function Check"</a> .
Parking lamp, license plate lamp, side marker lamp and tail lamp are not turned ON		<p><b>Symptom diagnosis</b>            "PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS ARE NOT TURNED ON"            Refer to <a href="#">EXL-89, "Diagnosis Procedure"</a>.</p>	
Position lamp indicator is not turned ON (Parking lamp, license plate lamp, side marker lamp and tail lamp are turned ON)		Combination meter	<ul style="list-style-type: none"> <li>• Combination meter</li> <li>Data monitor "LIGHT IND"</li> <li>• BCM (HEAD LAMP)</li> <li>Active test "TAIL LAMP"</li> </ul>
Daytime running light is not turned ON [Headlamp (HI) at approximately half illumination] [Headlamp (HI) is turned ON]		<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Daytime running light relay power supply/control signal circuit</li> <li>• Daytime running light relay</li> <li>• IPDM E/R</li> <li>• BCM</li> <li>• ECM</li> <li>• Combination meter</li> </ul>	<ul style="list-style-type: none"> <li>• Daytime running light relay circuit</li> <li>Refer to <a href="#">EXL-64, "Component Function Check"</a>.</li> <li>• BCM (HEAD LAMP)</li> <li>Data monitor "ENGINE STATE"</li> <li>• Combination meter</li> <li>Data monitor "PKB SW"</li> </ul>
Front fog lamp is not turned ON	One side	<ul style="list-style-type: none"> <li>• Front fog lamp power supply/ground circuit</li> <li>• Front fog lamp bulb</li> <li>• IPDM E/R</li> </ul>	Front fog lamp circuit Refer to <a href="#">EXL-69, "Component Function Check"</a> .
	Both sides	<p><b>Symptom diagnosis</b>            "BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON"            Refer to <a href="#">EXL-90, "Diagnosis Procedure"</a>.</p>	

# EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

Symptom	Possible cause	Inspection item	
Turn signal lamp does not blink	<ul style="list-style-type: none"> <li>• Front turn signal lamp</li> <li>- Front turn signal lamp power supply/ground circuit</li> <li>- Front turn signal lamp bulb</li> <li>- Front turn signal lamp bulb socket</li> <li>- BCM</li> <li>• Side turn signal lamp</li> <li>- Side turn signal lamp power supply/ground circuit</li> <li>- Side turn signal lamp</li> <li>- BCM</li> <li>• Rear turn signal lamp</li> <li>- Rear turn signal lamp power supply/ground circuit</li> <li>- Rear turn signal lamp bulb</li> <li>- Rear turn signal lamp bulb socket/harness</li> <li>- BCM</li> </ul>	Turn signal lamp circuit Refer to <a href="#">EXL-71, "Component Function Check"</a> .	
	Indicator lamp is included	<ul style="list-style-type: none"> <li>• Combination switch input/output signal circuit</li> <li>• Combination switch</li> <li>• BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-92, "Symptom Table"</a> .
Turn signal indicator lamp does not blink (Turn signal lamp is normal)	One side	Combination meter —	
	Both sides (Always)	<ul style="list-style-type: none"> <li>• Turn indicator signal</li> <li>• BCM</li> <li>• Combination meter</li> </ul>	<ul style="list-style-type: none"> <li>• Combination meter</li> <li>Data monitor "TURN IND"</li> <li>• BCM (FLASHER)</li> <li>Active test "FLASHER"</li> </ul>
	Both sides (Only when activating hazard warning lamp with ignition switch OFF)	<ul style="list-style-type: none"> <li>• Combination meter power supply/ground circuit</li> <li>• Combination meter</li> </ul>	Combination meter Power supply and ground circuit Refer to <a href="#">MWI-53, "COMBINATION METER : Diagnosis Procedure"</a> .
<ul style="list-style-type: none"> <li>• Hazard warning lamp does not activate (Turn signal is normal)</li> <li>• Hazard warning lamp continues activating</li> </ul>	<ul style="list-style-type: none"> <li>• Hazard switch signal/ground circuit</li> <li>• Hazard switch</li> <li>• BCM</li> </ul>	Hazard switch Refer to <a href="#">EXL-77, "Component Function Check"</a> .	

## NISMO MODELS

### NOTE:

Perform the self-diagnosis with CONSULT before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom	Possible cause	Inspection item
Headlamp (HI) is not turned ON	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Headlamp (HI) power supply/ground circuit</li> <li>• Headlamp (HI) bulb</li> <li>• Headlamp assembly</li> <li>- Harness</li> <li>• IPDM E/R</li> </ul>	Headlamp (HI) circuit Refer to <a href="#">EXL-50, "Component Function Check"</a> .
	Both sides	<b>Symptom diagnosis</b> "BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON" Refer to <a href="#">EXL-87, "Diagnosis Procedure"</a> .
High beam indicator lamp is not turned ON [Headlamp (HI) is turned ON]	Combination meter	<ul style="list-style-type: none"> <li>• Combination meter</li> <li>Data monitor "HI-BEAM IND"</li> <li>• BCM (HEAD LAMP)</li> <li>Active test "HEAD LAMP"</li> </ul>

# EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

Symptom		Possible cause	Inspection item
Headlamp (LO) is not turned ON	One side	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Headlamp (LO) power supply/ ground circuit</li> <li>• Headlamp (LO) bulb (Xenon bulb)</li> <li>• Headlamp assembly</li> <li>- HID control unit</li> <li>- Xenon bulb socket</li> <li>- Harness</li> <li>• IPDM E/R</li> </ul>	Headlamp (LO) circuit Refer to <a href="#">EXL-53, "Component Function Check"</a> .
	Both sides	<b>Symptom diagnosis</b> "BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON" Refer to <a href="#">EXL-88, "Diagnosis Procedure"</a> .	
Parking lamp is not turned ON		<ul style="list-style-type: none"> <li>• Parking lamp power supply/ ground circuit</li> <li>• Front combination lamp</li> <li>- LED (Parking lamp)</li> <li>- Harness</li> <li>• IPDM E/R</li> </ul>	Parking lamp circuit Refer to <a href="#">EXL-56, "Component Function Check"</a> .
Front side marker lamp is not turned ON		<ul style="list-style-type: none"> <li>• Front side marker lamp power supply/ground circuit</li> <li>• Front side marker lamp bulb</li> <li>• Front side marker lamp bulb socket</li> </ul>	Front side marker lamp circuit Refer to <a href="#">EXL-58, "Component Function Check"</a> .
Tail lamp is not turned ON	Stop lamp / Tail lamp (Bulb side)	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Tail lamp power supply/ground circuit</li> <li>• Stop lamp / Tail lamp bulb</li> <li>• Stop lamp / Tail lamp bulb socket/ harness</li> <li>• IPDM E/R</li> </ul>	Tail lamp circuit Refer to <a href="#">EXL-60, "Component Function Check"</a> .
	Tail lamp (LED side)	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Tail lamp power supply/ground circuit</li> <li>• Rear combination lamp internal circuit</li> <li>- LED (Tail lamp)</li> <li>• Tail lamp harness</li> <li>• IPDM E/R</li> </ul>	
License plate lamp is not turned ON		<ul style="list-style-type: none"> <li>• License plate lamp power supply/ ground circuit</li> <li>• License plate lamp bulb</li> <li>• License plate lamp bulb socket/ harness</li> </ul>	License plate lamp circuit Refer to <a href="#">EXL-62, "Component Function Check"</a> .
Parking lamp, license plate lamp, side marker lamp and tail lamp are not turned ON		<b>Symptom diagnosis</b> "PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS ARE NOT TURNED ON" Refer to <a href="#">EXL-89, "Diagnosis Procedure"</a> .	
Position lamp indicator is not turned ON (Parking lamp, license plate lamp, side marker lamp and tail lamp are turned ON)		Combination meter	<ul style="list-style-type: none"> <li>• Combination meter</li> <li>Data monitor "LIGHT IND"</li> <li>• BCM (HEAD LAMP)</li> <li>Active test "TAIL LAMP"</li> </ul>
Daytime running light is not turned ON		<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Daytime running light power supply/ground circuit</li> <li>• Daytime running light</li> <li>• IPDM E/R</li> <li>• BCM</li> <li>• ECM</li> <li>• Combination meter</li> </ul>	<ul style="list-style-type: none"> <li>• Daytime running light circuit</li> <li>Refer to <a href="#">EXL-67, "Component Function Check"</a>.</li> <li>• BCM (HEAD LAMP)</li> <li>Data monitor "ENGINE STATE"</li> <li>• Combination meter</li> <li>Data monitor "PKB SW"</li> </ul>

# EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

Symptom	Possible cause	Inspection item	
Turn signal lamp does not blink	<ul style="list-style-type: none"> <li>• Front turn signal lamp</li> <li>- Front turn signal lamp power supply/ground circuit</li> <li>- Front turn signal lamp bulb</li> <li>- Front turn signal lamp bulb socket</li> <li>- BCM</li> <li>• Side turn signal lamp</li> <li>- Side turn signal lamp power supply/ground circuit</li> <li>- Side turn signal lamp</li> <li>- BCM</li> <li>• Rear turn signal lamp</li> <li>- Rear turn signal lamp power supply/ground circuit</li> <li>- Rear turn signal lamp bulb</li> <li>- Rear turn signal lamp bulb socket/harness</li> <li>- BCM</li> </ul>	Turn signal lamp circuit Refer to <a href="#">EXL-71, "Component Function Check"</a> .	
	Indicator lamp is included	<ul style="list-style-type: none"> <li>• Combination switch input/output signal circuit</li> <li>• Combination switch</li> <li>• BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-92, "Symptom Table"</a> .
Turn signal indicator lamp does not blink (Turn signal lamp is normal)	One side	Combination meter  —	
	Both sides (Always)	<ul style="list-style-type: none"> <li>• Turn indicator signal</li> <li>• BCM</li> <li>• Combination meter</li> </ul>	<ul style="list-style-type: none"> <li>• Combination meter Data monitor "TURN IND"</li> <li>• BCM (FLASHER) Active test "FLASHER"</li> </ul>
	Both sides (Only when activating hazard warning lamp with ignition switch OFF)	<ul style="list-style-type: none"> <li>• Combination meter power supply/ground circuit</li> <li>• Combination meter</li> </ul>	Combination meter Power supply and ground circuit Refer to <a href="#">MWI-53, "COMBINATION METER : Diagnosis Procedure"</a> .
<ul style="list-style-type: none"> <li>• Hazard warning lamp does not activate (Turn signal is normal)</li> <li>• Hazard warning lamp continues activating</li> </ul>	<ul style="list-style-type: none"> <li>• Hazard switch signal/ground circuit</li> <li>• Hazard switch</li> <li>• BCM</li> </ul>	Hazard switch Refer to <a href="#">EXL-77, "Component Function Check"</a> .	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K

EXL

## NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

---

### NORMAL OPERATING CONDITION

#### Description

*INFOID:000000012201664*

#### XENON HEADLAMP

- Brightness and the color of light may change slightly immediately after turning the headlamp ON until the xenon bulb becomes stable. This is normal.
- Illumination time lag may occur between right and left. This is normal.

#### AUTO LIGHT SYSTEM

The headlamp may not be turned ON/OFF immediately after passing dark area or bright area (short tunnel, sky bridge, shadowed area, etc.) while using the auto light system. This is caused by for the control difference. This is normal.

# BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

## BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON

### Description

INFOID:000000012201665

Both side headlamps (HI) are not turned ON when setting to the lighting switch HI or PASS.

### Diagnosis Procedure

INFOID:000000012201666

#### 1.COMBINATION SWITCH INSPECTION

Check combination switch. Refer to [BCS-92, "Symptom Table"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

#### 2.CHECK HIGH BEAM REQUEST SIGNAL

Ⓜ With CONSULT

1. Turn ignition switch ON.
2. Select "HL HI REQ" in "Data Monitor" mode of "IPDM E/R" using CONSULT.
3. With operating the lighting switch, check the monitor status.

Monitor item	Condition		Monitor status
HL HI REQ	Lighting switch (2ND)	HI or PASS	On
		LO	Off

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-37, "Removal and Installation"](#).

NO >> Replace BCM. Refer to [BCS-94, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

## BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON

### Description

INFOID:000000012201667

Both side headlamps (LO) are not turned ON in any condition.

### Diagnosis Procedure

INFOID:000000012201668

#### 1.COMBINATION SWITCH INSPECTION

Check combination switch. Refer to [BCS-92, "Symptom Table"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

#### 2.CHECK LOW BEAM REQUEST SIGNAL

Ⓟ With CONSULT

1. Turn ignition switch ON.
2. Select "HL LO REQ" in "Data Monitor" mode of "IPDM E/R" using CONSULT.
3. With operating the lighting switch, check the monitor status.

Monitor item	Condition		Monitor status
HL LO REQ	Lighting switch	2ND	On
		OFF	Off

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-37, "Removal and Installation"](#).

NO >> Replace BCM. Refer to [BCS-94, "Removal and Installation"](#).



# PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

## PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS ARE NOT TURNED ON

### Description

INFOID:000000012201669

The parking, license plate, side marker and tail lamps are not turned ON in any condition.

### Diagnosis Procedure

INFOID:000000012201670

#### 1.COMBINATION SWITCH INSPECTION


Check combination switch. Refer to [BCS-92, "Symptom Table"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

#### 2.CHECK POSITION LIGHT REQUEST SIGNAL

 With CONSULT

1. Turn ignition switch ON.
2. Select "TAIL & CLR REQ" in "Data Monitor" mode of "IPDM E/R" using CONSULT.
3. With operating the lighting switch, check the monitor status.

Monitor item	Condition	Monitor status
TAIL & CLR REQ	Lighting switch	1ST On
		OFF Off

Is the inspection result normal?

YES >> Perform the tail lamp diagnosis. Refer to [EXL-60, "Component Function Check"](#).

NO >> Replace BCM. Refer to [BCS-94, "Removal and Installation"](#).

# BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

## BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON

### Description

INFOID:000000012201671

Both side front fog lamps are not turned ON in any condition.

### Diagnosis Procedure

INFOID:000000012201672

#### 1.COMBINATION SWITCH INSPECTION

Check combination switch. Refer to [BCS-92, "Symptom Table"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

#### 2.CHECK FRONT FOG LIGHT REQUEST SIGNAL

Ⓟ With CONSULT

1. Turn ignition switch ON.
2. Select "FR FOG REQ" in "Data Monitor" mode of "IPDM E/R" using CONSULT.
3. With operating the front fog lamp switch, check the monitor status.

Monitor item	Condition		Monitor status
FR FOG REQ	Front fog lamp switch (With lighting switch 1ST)	ON	On
		OFF	Off

Is the inspection result normal?

YES >> Perform the front fog lamp diagnosis. Refer to [EXL-69, "Component Function Check"](#).

NO >> Replace BCM. Refer to [BCS-94, "Removal and Installation"](#).

# HEADLAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >

[XENON TYPE]

## PERIODIC MAINTENANCE

### HEADLAMP AIMING ADJUSTMENT

#### Description

INFOID:0000000012201673

#### PREPARATION BEFORE ADJUSTING

##### NOTE:

- For details, refer to the regulations in your own country.
- Perform aiming if the vehicle front body has been repaired and/or the headlamp assembly has been replaced.

Before performing aiming adjustment, check the following.

- Adjust the tire pressure to the specification.
- Fill with fuel, engine coolant and each oil.
- Maintain the unloaded vehicle condition. (Remove luggage from the passenger compartment and the trunk room.)

##### NOTE:

Do not remove the temporary tire, jack and on-vehicle tool.


- Wipe out dirt on the headlamp.

##### CAUTION:

**Never use organic solvent (thinner, gasoline etc.).**

- Ride alone on the driver seat.

#### AIMING ADJUSTMENT SCREW



A. Headlamp RH (UP/DOWN) adjustment screw B. Headlamp LH (UP/DOWN) adjustment screw

↔ : Vehicle front

Adjustment screw	Screw driver rotation	Facing direction
A Headlamp LH (UP/DOWN)	Clockwise	DOWN
	Counterclockwise	UP
B Headlamp RH (UP/DOWN)	Clockwise	DOWN
	Counterclockwise	UP

#### Aiming Adjustment Procedure

INFOID:0000000012201674

1. Place the screen.

##### NOTE:

- Stop the vehicle facing the wall.
- Place the board on a plain road vertically.

# HEADLAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >

[XENON TYPE]

2. Face the vehicle with the screen. Maintain 10 m (32.8 ft) between the headlamp center and the screen.
3. Start the engine. Turn the headlamp (LO) ON.

**CAUTION:**

Never cover the lens surface with a tape etc. The lens is made of resin.


**NOTE:**

Shut off the headlamp light with the board to prevent from illuminating the adjustment screen.

4. Measure the distance (X) between the horizontal center line of headlamp (H) and the cutoff line (A) within the light axis measurement range (R) from the vertical center line ahead of headlamp (V).

**Light axis measurement range (R) : 350 ± 175 mm (13.78 ± 6.89 in)**

Low beam distribution on the screen




5. Adjust the cutoff line height (X) with the aiming adjustment screw so as to enter in the adjustment range (M–N) according to the horizontal center line of headlamp (H).

unit: mm (in)

Horizontal center line of headlamp (H)	Highest cutoff line height (M)	Lowest cutoff line height (N)
700 (27.56) or less	4 (0.16)	30 (1.18)
701(27.60) – 800 (31.50)	4 (0.16)	30 (1.18)
801 (31.54) or more	17 (0.67)	44 (1.73)

Side view



**Distance between the headlamp center and the screen (L) : 10 m (32.8 ft)**

# FRONT FOG LAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >

[XENON TYPE]

## FRONT FOG LAMP AIMING ADJUSTMENT

### Description

INFOID:000000012201675

### PREPARATION BEFORE ADJUSTING

#### NOTE:

- For details, refer to the regulations in your own country.
- Perform aiming if the vehicle front body has been repaired and/or the headlamp assembly has been replaced.

Before performing aiming adjustment, check the following.

- Adjust the tire pressure to the specification.
- Fill with fuel, engine coolant and each oil.
- Maintain the unloaded vehicle condition. (Remove luggage from the passenger compartment and the trunk room.)

#### NOTE:

Do not remove the temporary tire, jack and on-vehicle tool.

- Wipe out dirt on the headlamp.

#### CAUTION:

**Never use organic solvent (thinner, gasoline etc.).**

- Ride alone on the driver seat.

### AIMING ADJUSTMENT SCREW

- Turn the aiming adjusting screw for adjustment.


A: UP

B: DOWN

- For the position and direction of the adjusting screw, refer to the figure.

#### NOTE:

A screwdriver or hexagonal wrench [6 mm (0.24 in)] can be used for adjustment.



### Aiming Adjustment Procedure

INFOID:000000012201676

1. Place the screen.

#### NOTE:

- Stop the vehicle facing the wall.
- Place the board on a plain road vertically.

2. Face the vehicle with the screen. Maintain 10 m (32.8 ft) between the front fog lamp center and the screen.

3. Start the engine. Turn the front fog lamp ON.

#### CAUTION:

**Never cover the lens surface with a tape etc. The lens is made of resin.**

#### NOTE:

Shut off the headlamp light with the board to prevent from illuminating the adjustment screen.

4. Adjust the cutoff line height (A) with the aiming adjustment screw so that the distance (X) between the horizontal center line of front fog lamp (H) and (A) becomes 150 mm (5.91 in).


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# FRONT FOG LAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >

[XENON TYPE]

Front fog lamp light distribution on the screen



- A : Cutoff line
- B : High illuminance area
- H : Horizontal center line of front fog lamp
- V : Vertical center line of front fog lamp
- X : Cutoff line height

# HEADLAMP

< REMOVAL AND INSTALLATION >

[XENON TYPE]


## REMOVAL AND INSTALLATION

### HEADLAMP

Exploded View


INFOID:000000012201677

#### REMOVAL



1. Headlamp assembly

← : Vehicle front

 : N·m (kg-m, in-lb)


#### DISASSEMBLY

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# HEADLAMP

< REMOVAL AND INSTALLATION >

[XENON TYPE]



- |                      |                    |                 |
|----------------------|--------------------|-----------------|
| 1. Headlamp assembly | 2. Xenon bulb (LO) | 3. Back cover A |
| 4. Halogen bulb (HI) | 5. Back cover B    |                 |
- ⇐ : Vehicle front

## Removal and Installation

INFOID:000000012201678

### CAUTION:

Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-7, "Precautions for Removing Battery Terminal"](#).

### REMOVAL

1. Remove front bumper fascia. Refer to [EXT-17, "Removal and Installation"](#).
2. Remove headlamp assembly mounting bolts.
3. Pull out headlamp assembly forward the vehicle, and then disconnect the connector before removing the headlamp assembly.

### INSTALLATION

Note the following item, and then install in the reverse order of removal.

### CAUTION:

After installation, perform aiming adjustment. Refer to [EXL-91, "Description"](#).

## Replacement

INFOID:000000012201679

### CAUTION:

- Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-7, "Precautions for Removing Battery Terminal"](#).
- After installing the bulb, install the back cover and the bulb socket securely for watertightness.
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.
- Never touch bulb by hand while it is lit or right after being turned off.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

## XENON BULB (LO)



# HEADLAMP


[XENON TYPE]

## < REMOVAL AND INSTALLATION >

### Left Side of The Vehicle

1. Remove fixing clips (A) of air cleaner assembly (1).
2. While pulling up on the (B) portion of the air duct inlet (upper) (2), disengage of the portion (C), and then remove air duct inlet (upper) as shown by the arrow in the figure.

← : Vehicle front



3. Remove back cover A.
4. Rotate xenon bulb socket counterclockwise and unlock it.
5. Remove retaining spring lock, and then remove xenon bulb from headlamp assembly.

### Right Side of The Vehicle

1. Remove washer tank inlet. Refer to [WW-43, "Removal and Installation"](#).
2. Remove back cover A.
3. Rotate xenon bulb socket counterclockwise and unlock it.
4. Remove retaining spring lock, and then remove xenon bulb from headlamp assembly.

### CAUTION:


**Never break xenon bulb ceramic tube when replacing bulb.**

### HALOGEN BULB (HI)

#### Left Side of The Vehicle

1. Remove fixing clips (A) of air cleaner assembly (1).
2. While pulling up on the (B) portion of the air duct inlet (upper) (2), disengage of the portion (C), and then remove air duct inlet (upper) as shown by the arrow in the figure.

← : Vehicle front



3. Remove back cover B.
4. Disconnect halogen bulb harness connector.
5. Rotate halogen bulb clockwise and unlock it, and then remove halogen bulb from headlamp assembly.

#### Right Side of The Vehicle

1. Remove washer tank inlet. Refer to [WW-43, "Removal and Installation"](#).
2. Remove back cover B.
3. Disconnect halogen bulb harness connector.
4. Rotate halogen bulb counterclockwise and unlock it, and then remove halogen bulb from headlamp assembly.

## Disassembly and Assembly

INFOID:0000000012201680

### DISASSEMBLY

1. Remove back cover (A and B).
2. Rotate xenon bulb socket counterclockwise and unlock it.
3. Remove retaining spring lock, and then remove xenon bulb from headlamp assembly.

## HEADLAMP

[XENON TYPE]

### < REMOVAL AND INSTALLATION >

---

4. Disconnect halogen bulb harness connector.
5. Remove halogen bulb.

Left side of the vehicle

- Rotate halogen bulb clockwise and unlock it, and then remove halogen bulb from headlamp assembly.

Right side of the vehicle

- Rotate halogen bulb counterclockwise and unlock it, and then remove halogen bulb from headlamp assembly.

### ASSEMBLY

Assemble in the reverse order of disassembly.

# FRONT COMBINATION LAMP

< REMOVAL AND INSTALLATION >


[XENON TYPE]

## FRONT COMBINATION LAMP


Exploded View

INFOID:000000012201681


### REMOVAL



1. Front combination lamp

 : N·m (kg·m, in·lb)

### DISASSEMBLY



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# FRONT COMBINATION LAMP

< REMOVAL AND INSTALLATION >

[XENON TYPE]

1. Front combination lamp
2. Front turn signal lamp bulb
3. Front turn signal lamp bulb socket
4. Front side marker lamp bulb
5. Front side marker lamp bulb socket

↶ : Vehicle front

## Removal and Installation

INFOID:000000012201682

### CAUTION:

Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-7, "Precautions for Removing Battery Terminal"](#).

### REMOVAL

1. Remove front bumper fascia. Refer to [EXT-17, "Removal and Installation"](#).
2. Remove front combination lamp mounting bolts and nut.
3. Pull out front combination lamp forward the vehicle, and then disconnect connector before removing the front combination lamp.

### INSTALLATION

Note the following item, and then install in the reverse order of removal.

### CAUTION:

Interference of front combination lamp lens with front fender may cause intrusion of water into front combination lamp or rusting of fender due to damage of painted surface. Be careful to operate without allowing parts to interfere with each other.

## Replacement

INFOID:000000012201683

### CAUTION:

- Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-7, "Precautions for Removing Battery Terminal"](#).
- After installing the bulb, install the bulb socket securely for watertightness.
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.
- Never touch bulb by hand while it is lit or right after being turned off.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

### PARKING LAMP BULB

### CAUTION:

Replacement of a single part is not possible due to the adoption of LED. For replacement, replace front combination lamp as a set. Refer to [EXL-100, "Removal and Installation"](#).

### FRONT TURN SIGNAL LAMP BULB

1. Rotate the front turn signal lamp bulb socket counterclockwise and unlock it.
2. Remove front turn signal lamp bulb from the front turn signal lamp bulb socket.

### FRONT SIDE MARKER LAMP BULB

1. Rotate the front side marker lamp bulb socket counterclockwise and unlock it.
2. Remove front side marker lamp bulb from the front side marker lamp bulb socket.

## Disassembly and Assembly

INFOID:000000012201684

### DISASSEMBLY

1. Rotate the front turn signal lamp bulb socket counterclockwise and unlock it.
2. Remove front turn signal lamp bulb from the front turn signal lamp bulb socket.
3. Rotate the front side marker lamp bulb socket counterclockwise and unlock it.
4. Remove front side marker lamp bulb from the front side marker lamp bulb socket.

### ASSEMBLY

Note the following item, and then assemble in the reverse order of disassembly.

### CAUTION:

After installing the bulb, install the bulb socket securely for watertightness.

# DAYTIME RUNNING LIGHT


< REMOVAL AND INSTALLATION >

[XENON TYPE]


## DAYTIME RUNNING LIGHT

Exploded View

INFOID:000000012201685



1. Daytime running light  
2. Front bumper fascia assembly  
3. U nut  
4. Harness connector assembly

 N·m (kg-m, in-lb)

### Removal and Installation

INFOID:000000012201686

#### CAUTION:

Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-7, "Precautions for Removing Battery Terminal"](#).

#### REMOVAL

1. Remove front bumper fascia lower. Refer to [EXT-17, "Removal and Installation"](#).
2. Disconnect daytime running light harness connector.
3. Remove daytime running light mounting nuts.
4. Remove daytime running light from front bumper fascia lower.

#### INSTALLATION

Install in the reverse order of removal.

### Replacement

INFOID:000000012201687

#### CAUTION:

Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-7, "Precautions for Removing Battery Terminal"](#).

#### DAYTIME RUNNING LIGHT

#### CAUTION:

Replacement of a single part is not possible due to the adoption of LED. For replacement, replace daytime running light as a set. Refer to [EXL-101, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# FRONT FOG LAMP


< REMOVAL AND INSTALLATION >

[XENON TYPE]

## FRONT FOG LAMP


Exploded View

INFOID:000000012201688



- |                                 |                           |                        |
|---------------------------------|---------------------------|------------------------|
| 1. Front bumper fascia assembly | 2. Front fog lamp bracket | 3. Front fog lamp bulb |
| 4. Front fog lamp               | 5. U nut                  |                        |

← : Vehicle front

 : N·m (kg-m, in-lb)

## Removal and Installation

INFOID:000000012201689

### CAUTION:

Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-7, "Precautions for Removing Battery Terminal"](#).

### REMOVAL

1. Remove front fender protector to make work space. Refer to [EXT-31, "Removal and Installation"](#).
2. Disconnect front fog lamp harness connector.
3. Remove front fog lamp fixing screws, and then remove front fog lamp from front fog lamp bracket.
4. Remove front fog lamp bracket mounting bolt and fixing clips, and then remove front fog lamp bracket.

# FRONT FOG LAMP

< REMOVAL AND INSTALLATION >

[XENON TYPE]

## INSTALLATION

Note the following item, and then install in the reverse order of removal.

### NOTE:

After installation, perform aiming adjustment. Refer to [EXL-93. "Description"](#).

## Replacement


INFOID:000000012201690

### CAUTION:

- Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-7. "Precautions for Removing Battery Terminal"](#).
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.
- Never touch bulb by hand while it is lit or right after being turned off.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

## FRONT FOG LAMP BULB

1. Remove fender protector to make work space. Refer to [EXT-31. "Removal and Installation"](#).
2. Remove front fog lamp bulb connector (1).
3. Rotate front fog lamp bulb (2) counterclockwise and unlock it.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# SIDE TURN SIGNAL LAMP

< REMOVAL AND INSTALLATION >

[XENON TYPE]

## SIDE TURN SIGNAL LAMP

### Exploded View

INFOID:000000012201691

Refer to [MIR-17, "Exploded View"](#).

### Removal and Installation


INFOID:000000012201692

#### **CAUTION:**

Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-7, "Precautions for Removing Battery Terminal"](#).

#### REMOVAL

1. Remove door mirror cover. Refer to [MIR-20, "DOOR MIRROR COVER : Removal and Installation"](#).
2. Remove side turn signal lamp fixing screws (A), and then disconnect side turn signal lamp harness connector (B).



3. Remove side turn signal lamp.

#### INSTALLATION

Install in the reverse order of removal.

#### Replacement

INFOID:000000012201693

#### **CAUTION:**

Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-7, "Precautions for Removing Battery Terminal"](#).

#### SIDE TURN SIGNAL LAMP BULB

#### **CAUTION:**


Replacement of a single part is not possible due to the adoption of LED. For replacement, replace side turn signal lamp as a set. Refer to [EXL-104, "Removal and Installation"](#).



## OPTICAL SENSOR

### Exploded View

INFOID:000000012201694



1. Optical sensor

2. Switch panel

: Pawl

### Removal and Installation

INFOID:000000012201695

#### REMOVAL

1. Insert an appropriate tool between the switch panel and the instrument upper panel. Pull out the optical sensor upward.
2. Disconnect the optical sensor connector.
3. Remove optical sensor from switch panel.

#### INSTALLATION

Install in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K

EXL

M  
N  
O  
P

## LIGHTING & TURN SIGNAL SWITCH

< REMOVAL AND INSTALLATION >

[XENON TYPE]

---

### LIGHTING & TURN SIGNAL SWITCH

#### Removal and Installation

INFOID:000000012201696

#### REMOVAL

Remove light & turn signal switch. Refer to [BCS-95. "Removal and Installation"](#).

#### INSTALLATION

Install in the reverse order of removal.

# HAZARD SWITCH


< REMOVAL AND INSTALLATION >

[XENON TYPE]


## HAZARD SWITCH

Exploded View

INFOID:000000012201697



1. Instrument panel assembly
2. Hazard switch

 : Pawl

### Removal and Installation

INFOID:000000012201698

#### **CAUTION:**

Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-7, "Precautions for Removing Battery Terminal"](#).

#### REMOVAL

1. Remove audio unit. Refer to [AV-50, "Removal and Installation"](#).
2. Disengage fixing pawls, and then remove hazard switch from instrument panel inside to outside.

#### INSTALLATION

Install in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K

EXL

M  
N  
O  
P

# REAR COMBINATION LAMP

< REMOVAL AND INSTALLATION >


[XENON TYPE]

## REAR COMBINATION LAMP

Exploded View

INFOID:000000012201699

REMOVAL



1. Grommet

2. Grommet

3. Rear combination lamp

○ : Clip


⊙ : N·m (kg-m, in-lb)

DISASSEMBLY

# REAR COMBINATION LAMP

< REMOVAL AND INSTALLATION >

[XENON TYPE]



- |                               |   |                      |
|-------------------------------|---|----------------------|
| 1. Rear combination lamp      | 2. Back-up lamp bulb                              | 3. Harness connector |
| 4. Rear turn signal lamp bulb | 5. Stop/Tail lamp bulb<br>(Rear side marker lamp) |                      |

## Removal and Installation

INFOID:0000000012201700

### CAUTION:

- Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-7, "Precautions for Removing Battery Terminal"](#).
- When removing, always use a remover tool that is made of plastic.

### REMOVAL

1. Full open back door.
2. Remove luggage side lower finisher. Refer to [INT-35, "LUGGAGE SIDE LOWER FINISHER : Removal and Installation"](#).
3. Remove rear combination lamp mounting bolts.
4. Insert a remover tool into the rear combination lamp and rear fender to disengage the clips.
5. Pull up rear combination lamp, and then remove rear combination lamp.
6. Disconnect rear combination lamp connector.

### INSTALLATION

Install in the reverse order of removal.

### Replacement

INFOID:0000000012201701

### CAUTION:

- Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-7, "Precautions for Removing Battery Terminal"](#).
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.

## REAR COMBINATION LAMP

< REMOVAL AND INSTALLATION >

[XENON TYPE]

- Never touch bulb by hand while it is lit or right after being turned off.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

TAIL LAMP (LED)

**CAUTION:**

Replacement of a single part is not possible due to the adoption of LED. For replacement, replace rear combination lamp as a set. Refer to [EXL-109, "Removal and Installation"](#).

STOP/TAIL LAMP BULB (REAR SIDE MARKER LAMP)

1. Remove rear combination lamp assembly. Refer to [EXL-109, "Removal and Installation"](#).
2. Rotate stop/tail lamp bulb socket counterclockwise, and then remove stop/tail lamp bulb socket.
3. Remove stop/tail lamp bulb from stop/tail lamp bulb socket.

REAR TURN SIGNAL LAMP BULB

1. Remove rear combination lamp assembly. Refer to [EXL-109, "Removal and Installation"](#).
2. Rotate rear turn signal lamp bulb socket counterclockwise, and then remove rear turn signal lamp bulb socket.
3. Remove rear turn signal lamp bulb from rear turn signal lamp bulb socket.

BACK-UP LAMP BULB

1. Remove rear combination lamp assembly. Refer to [EXL-109, "Removal and Installation"](#).
2. Rotate back-up lamp bulb socket counterclockwise, and then remove back-up lamp bulb socket.
3. Remove back-up lamp bulb from back-up lamp bulb socket.

# HIGH-MOUNTED STOP LAMP

< REMOVAL AND INSTALLATION >


[XENON TYPE]

## HIGH-MOUNTED STOP LAMP

Exploded View

INFOID:000000012201702


EXCEPT FOR NISMO AND NISMO RS



1. High-mounted stop lamp      2. Seal packing

: N·m (kg-m, in-lb)

NISMO AND NISMO RS



1. Rear spoiler      2. High-mounted stop lamp      3. High-mounted stop lamp cover

## Removal and Installation

INFOID:000000012201703

### CAUTION:

Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-7, "Precautions for Removing Battery Terminal"](#).

### REMOVAL

Except for NISMO and NISMO RS

1. Remove blind seal from back door inside.

### CAUTION:

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

## HIGH-MOUNTED STOP LAMP

[XENON TYPE]

< REMOVAL AND INSTALLATION >

---

**Never damage the blind seal, so that it can be reused.**

2. Remove high-mounted stop lamp mounting nuts and connector.
3. Pull high-mounted stop lamp toward vehicle upside, and then remove high-mounted stop lamp.

NISMO and NISMO RS

1. Remove rear spoiler. Refer to [EXT-49. "Removal and Installation"](#).
2. Remove high-mounted stop lamp cover mounting bolts, and then remove high-mounted stop lamp cover.
3. Remove high-mounted stop lamp harness connector from rear spoiler.
4. Pull out high-mounted stop lamp, and then remove high-mounted stop lamp.

### INSTALLATION

Note the following item, and then install in the reverse order of removal.

**CAUTION:**

**Seal packing cannot be reused.**



# LICENSE PLATE LAMP


< REMOVAL AND INSTALLATION >

[XENON TYPE]


## LICENSE PLATE LAMP

### Exploded View

INFOID:000000012201704



1. License plate lamp housing assembly
2. Bulb
3. License plate lamp bulb socket

 : Pawl

### Removal and Installation


INFOID:000000012201705

#### CAUTION:

Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-7, "Precautions for Removing Battery Terminal"](#).

#### REMOVAL

1. While pressing the license plate lamp to direction right side, pull it to direction outside and then remove it.
2. Disconnect license plate lamp connector.



#### INSTALLATION

Install in the reverse order of removal.

### Replacement

INFOID:000000012201706

#### CAUTION:

- Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-7, "Precautions for Removing Battery Terminal"](#).
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.
- Never touch bulb by hand while it is lit or right after being turned off.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

#### LICENSE PLATE LAMP BULB

1. Remove license plate lamp. Refer to [EXL-113, "Removal and Installation"](#).
2. Rotate the bulb socket counterclockwise and unlock it.

## LICENSE PLATE LAMP

< REMOVAL AND INSTALLATION >

[XENON TYPE]

---

3. Remove the bulb from the socket.

# REAR FOG LAMP

< REMOVAL AND INSTALLATION >


[XENON TYPE]

## REAR FOG LAMP

Exploded View

INFOID:000000012201707


### REMOVAL



1. Rear fog lamp housing

2. Rear bumper fascia lower

3. Rear fog lamp housing bracket

 N·m (kg-m, in-lb)

 : Vehicle front

### Removal and Installation

INFOID:000000012201708

#### REMOVAL

1. Remove rear bumper fascia lower. Refer to [EXT-23, "Removal and Installation"](#).
2. Remove rear fog lamp housing mounting nuts.
3. Remove rear fog lamp housing from the rear bumper fascia lower.
4. Remove rear fog lamp housing bracket from rear bumper fascia lower.

#### INSTALLATION

Installation is the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# REAR REFLEX REFLECTOR

< REMOVAL AND INSTALLATION >


[XENON TYPE]

## REAR REFLEX REFLECTOR

Exploded View

INFOID:000000012201709

EXCEPT FOR NISMO AND NISMO RS




1. Rear bumper fascia lower      2. Rear reflex reflector LH      3. Rear reflex reflector RH

: Pawl

: N·m (kg-m, in-lb)

NISMO AND NISMO RS



1. Rear bumper fascia lower      2. Rear reflex reflector RH      3. Rear reflex reflector LH

: Metal clip

: Vehicle front

## Removal and Installation

INFOID:000000012201710

### REMOVAL

Except for NISMO and NISMO RS

1. Remove rear bumper fascia lower. Refer to [EXT-23, "Removal and Installation"](#).

## REAR REFLEX REFLECTOR


[XENON TYPE]

### < REMOVAL AND INSTALLATION >

2. Remove rear reflex reflector fixing screw.
3. Disengage rear reflex reflector fixing pawls, and then remove rear reflex reflector.

#### NISMO and NISMO RS

1. Remove rear bumper fascia lower. Refer to [EXT-23. "Removal and Installation"](#).
2. Disengage rear reflex reflector fixing metal clip, and then remove rear reflex reflector according to numerical order 1→3 indicated by arrows as shown in the figure.



### INSTALLATION

Install in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[XENON TYPE]

## SERVICE DATA AND SPECIFICATIONS (SDS)

### SERVICE DATA AND SPECIFICATIONS (SDS)

#### Bulb Specifications

INFOID:0000000012201711

#### EXCEPT FOR NISMO AND NISMO RS

Item	Type	Wattage (W)	
Headlamp	High Beam	HB3 (Halogen)	60
	Low Beam	D2S (Xenon)	35
Front combination lamp	Front turn signal lamp	WY21W (Amber)	21
	Front side marker lamp	W5W	5
	Parking lamp	LED	—
Front fog lamp	H11	55	
Side turn signal lamp	LED	—	
Rear combination lamp	Tail lamp (LED)	LED	—
	Stop lamp/Tail lamp (Rear side marker)	W21/5W	21/5
	Rear turn signal lamp	WY21W (Amber)	21
	Back-up lamp	W16W	16
High-mounted stop lamp	LED	—	
License plate lamp	W5W	5	

#### NISMO AND NISMO RS

Item	Type	Wattage (W)	
Headlamp	High Beam	HB3 (Halogen)	60
	Low Beam	D2S (Xenon)	35
Front combination lamp	Front turn signal lamp	WY21W (Amber)	21
	Front side marker lamp	W5W	5
	Parking lamp	LED	—
Daytime running light	LED	—	
Side turn signal lamp	LED	—	
Rear combination lamp	Tail lamp (LED)	LED	—
	Stop lamp/Tail lamp (Rear side marker)	W21/5W	21/5
	Rear turn signal lamp	WY21W (Amber)	21
	Back-up lamp	W16W	16
High-mounted stop lamp	LED	—	
License plate lamp	W5W	5	

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000012201712

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

**WARNING:**

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, it is recommended that all maintenance and repair be performed by an authorized NISSAN/INFINITI dealer.
- Improper repair, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

**WARNING:**


Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery or batteries, and wait at least 3 minutes before performing any service.

Precaution for Procedure without Cowl Top Cover

INFOID:000000012965028

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc to prevent damage to windshield.



Precautions for Removing Battery Terminal

INFOID:000000012965039

When disconnecting the battery terminal, pay attention to the following.

- Always use a 12V battery as power source.
- Never disconnect battery terminal while engine is running.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P


# PRECAUTIONS

[HALOGEN TYPE]

## < PRECAUTION >

- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.
- For vehicles with the engine listed below, remove the battery terminal after a lapse of the specified time:

D4D engine	: 20 minutes	YS23DDT	: 4 minutes
HRA2DDT	: 12 minutes	YS23DDTT	: 4 minutes
K9K engine	: 4 minutes	ZD30DDTi	: 60 seconds
M9R engine	: 4 minutes	ZD30DDTT	: 60 seconds
R9M engine	: 4 minutes		
V9X engine	: 4 minutes		
YD25DDTi	: 2 minutes		



### NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- After high-load driving, if the vehicle is equipped with the V9X engine, turn the ignition switch OFF and wait for at least 15 minutes to remove the battery terminal.

### NOTE:

- Turbocharger cooling pump may operate in a few minutes after the ignition switch is turned OFF.
- Example of high-load driving
  - Driving for 30 minutes or more at 140 km/h (86 MPH) or more.
  - Driving for 30 minutes or more on a steep slope.
- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.

### NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

### NOTE:

The removal of 12V battery may cause a DTC detection error.




## SYSTEM DESCRIPTION

### COMPONENT PARTS

#### Component Parts Location

INFOID:0000000012201714



- |   |   |   |
|---|---|---|
| 1. Hazard switch  | 2. Front turn signal lamp   | 3. Front side marker lamp   |
| 4. Parking lamp   | 5. Front fog lamp* <sup>1</sup>   | 6. Headlamp LO (Halogen headlamp)   |
|   | ECM* <sup>2</sup><br>Refer to <a href="#">EC-27. "ENGINE CONTROL SYSTEM : Component Parts Location"</a> (NISMO RS models) or <a href="#">EC-600. "ENGINE CONTROL SYSTEM : Component Parts Location"</a> (Except for NISMO RS models). | 9. IPDM E/R<br>Refer to <a href="#">PCS-5. "Component Parts Location"</a> . |
| 7. Headlamp HI (Halogen headlamp)   | 8. <a href="#">Component Parts Location</a> (NISMO RS models) or <a href="#">EC-600. "ENGINE CONTROL SYSTEM : Component Parts Location"</a> (Except for NISMO RS models).   |   |
| 10. BCM<br>Refer to <a href="#">BCS-5. "BODY CONTROL SYSTEM : Component Parts Location"</a> . | 11. Combination switch  | 12. Combination meter   |
| 13. Optical sensor* <sup>3</sup>  | 14. Side turn signal lamp   | 15. Front door switch (driver side)   |
| 16. Stop lamp / Tail lamp   | 17. Rear turn signal lamp   | 18. Tail lamp   |
| 19. License plate lamp  | 20. Daytime running light relay* <sup>4</sup>   |   |
| A. Engine room (RH)   |   |   |

\*<sup>1</sup>: With front fog lamp

\*<sup>2</sup>: With daytime running light system

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K

EXL

M  
N  
O  
P

# COMPONENT PARTS

[HALOGEN TYPE]

< SYSTEM DESCRIPTION >

\*3: With auto light system

\*4: Except for NISMO models with daytime running light system

## Component Description

INFOID:0000000012201715

Part	Description
BCM	<ul style="list-style-type: none"> <li>• Detects each switch condition by the combination switch reading function</li> <li>• Judges that the headlamp is turned ON according to the vehicle condition</li> <li>• Requests the headlamp relay (High/Low) ON to IPDM E/R (via CAN communication)</li> <li>• Requests the high beam indicator lamp and position lamp indicator lamp ON to the combination meter (via CAN communication)</li> <li>• Judges the outside brightness from the optical sensor signal.</li> <li>• Judges the ON/OFF status of the exterior lamp from the outside brightness and the vehicle condition.</li> </ul>
IPDM E/R	Controls the integrated relay and daytime running light relay, and supplies voltage to the load according to the request from BCM (via CAN communication).
Combination meter	<ul style="list-style-type: none"> <li>• Turns the high beam indicator lamp and position lamp indicator lamp ON according to the request from BCM (via CAN communication).</li> <li>• Blinks the turn signal indicator lamp and outputs the turn signal operating sound with integrated buzzer according to the request from BCM (via CAN communication).</li> <li>• Combination meter transmits parking brake switch signal to BCM via CAN communication.</li> </ul>
ECM*1	ECM transmits engine status signal to BCM via CAN communication.
Optical sensor*2	Optical sensor converts the outside brightness (lux) to voltage and transmits the optical sensor signal to BCM.
Door switch	Refer to <a href="#">DLK-10, "Component Description"</a> .
Combination switch (Lighting & turn signal switch)	Refer to <a href="#">BCS-8, "COMBINATION SWITCH READING SYSTEM : System Description"</a> .
Hazard switch	Inputs the hazard switch ON/OFF signal to BCM.


\*1: With daytime running light system

\*2: With auto light system

## SYSTEM

## HEADLAMP SYSTEM

## HEADLAMP SYSTEM : System Diagram



## HEADLAMP SYSTEM : System Description

INFOID:0000000012201717

## OUTLINE

Headlamp is controlled by combination switch reading function and headlamp control function of BCM, and relay control function of IPDM E/R.

## HEADLAMP (LO) OPERATION

- BCM detects the combination switch condition with the combination switch reading function.
- BCM transmits the low beam request signal to IPDM E/R via CAN communication according to the headlamp (LO) ON condition.

## Headlamp (LO) ON condition

- Lighting switch 2ND
- Lighting switch AUTO (Only when the illumination judgment by auto light system is ON. For details, refer to [EXL-124, "AUTO LIGHT SYSTEM : System Description"](#).)
- Lighting switch PASS
- IPDM E/R turns the integrated headlamp low relay ON, and turns the headlamp (LO) ON according to the low beam request signal.

## HEADLAMP (HI) OPERATION

- BCM transmits the high beam request signal to IPDM E/R and the combination meter via CAN communication according to the headlamp (HI) ON condition.

## Headlamp (HI) ON condition

- Lighting switch HI with the lighting switch 2ND
- Lighting switch HI with the lighting switch AUTO (Only when the illumination judgment by auto light system is ON. For details, refer to [EXL-124, "AUTO LIGHT SYSTEM : System Description"](#).)
- Lighting switch PASS
- Combination meter turns the high beam indicator lamp ON according to the high beam request signal.
- IPDM E/R turns the integrated headlamp high relay ON, and turns the headlamp (HI) ON according to the high beam request signal.

## FOLLOW ME HOME FUNCTION

When the driver is moving to the house entrance from the own vehicle, headlamp is kept still ON by the follow me home function of BCM.

- When BCM detects the input of lighting switch PASS while all of following conditions satisfied, it transmits the low beam request signal for a period of time to IPDM E/R through CAN communication.

## Follow me home ON condition

- Ignition switch OFF

# SYSTEM

[HALOGEN TYPE]

## < SYSTEM DESCRIPTION >

- Lighting switch OFF
- IPDM E/R turns the integrated headlamp low relay ON, and turns the headlamp (LO) ON according to the low beam request signal.
- When in any of following conditions, follow me home function can be cancelled while follow me home function is operating.

Follow me home OFF condition

- Ignition switch is turned from OFF→ACC or ON
- Lighting switch is turned from OFF→ON

### NOTE:

- Flash-to-pass operation illumination time for 1 time can be extended to approximately 30 seconds during operation of follow me home function.
- Flash-to-pass operation can be illuminated continuously for approximately 60 seconds (flash-to-pass operation, 2 times), approximately 90 seconds (flash-to-pass operation, 3 times), and a maximum of approximately 120 seconds (flash-to-pass operation, 4 times).
- Follow me home function activating time can be set by CONSULT. Refer to [EXL-132, "HEADLAMP : CONSULT Function \(BCM - HEAD LAMP\) \(HALOGEN TYPE\)"](#).

## HEADLAMP SYSTEM : Fail-Safe

INFOID:000000012201718

### CAN COMMUNICATION CONTROL

When CAN communication with BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.


If No CAN Communication Is Available With BCM

Control part	Fail-safe operation
Headlamp	<ul style="list-style-type: none"> <li>• Turns ON the headlamp low relay when the ignition switch is turned ON</li> <li>• Turns OFF the headlamp low relay when the ignition switch is turned OFF</li> <li>• Headlamp high relay OFF</li> </ul>

## AUTO LIGHT SYSTEM

### AUTO LIGHT SYSTEM : System Diagram

INFOID:000000012201719



### AUTO LIGHT SYSTEM : System Description

INFOID:000000012201720

#### OUTLINE

- Auto light system is controlled by each function of BCM and IPDM E/R.

Control by BCM

- Combination switch reading function
- Headlamp control function

- Auto light function
- Delay timer function
- Wiper linked auto lighting function

Control by IPDM E/R

- Relay control function
- Auto light system has the auto light function (with twilight lighting function), wiper linked auto lighting function and delay timer function.
- Auto light function automatically turns ON/OFF the exterior lamps\* and each illumination automatically, depending on the outside brightness.
- Wiper linked auto lighting function automatically turns ON/OFF the exterior lamps\* and each illumination when the light switch is in the AUTO position, according to a front wiper operation.
- When auto light system turns the exterior lamps ON with the ignition switch OFF, delay timer function turns the exterior lamps OFF, depending on the vehicle condition with the auto light function after a certain period of time.

\*: Headlamp (LO/HI), front fog lamp, parking lamp, license plate lamp, tail lamp and side marker lamp (Head-lamp HI and front fog lamp depend on the combination switch condition.)

**NOTE:**

The settings of the twilight lighting function and the wiper linked auto lighting function can be changed with CONSULT. Refer to [EXL-132. "HEADLAMP : CONSULT Function \(BCM - HEAD LAMP\) \(HALOGEN TYPE\)".](#)

### AUTO LIGHT FUNCTION (WITH TWILIGHT LIGHTING FUNCTION)

Description

- BCM detects the combination switch condition with the combination switch reading function.
- BCM supplies voltage to the optical sensor when the ignition switch is turned ON.
- Optical sensor converts outside brightness (lux) to voltage and transmits the optical sensor signal to BCM.
- BCM filters outside brightness based on the optical sensor signal and judges outside brightness.
- BCM detects change status of outside brightness according to outside brightness from the optical sensor signal and filtered outside brightness. Based on the change status, BCM judges ON/OFF condition of the exterior lamp.
- BCM transmits each request signal to IPDM E/R and combination meter via CAN communication, according to ON/OFF condition by the auto light function.

**NOTE:**

As to ON/OFF timing, the sensitivity depends on settings. The settings can be changed with CONSULT. Refer to [EXL-132. "HEADLAMP : CONSULT Function \(BCM - HEAD LAMP\) \(HALOGEN TYPE\)".](#)

### DELAY TIMER FUNCTION

- BCM turns the headlamp (LO) OFF depending on the vehicle condition with the auto light function when the ignition switch is turned OFF.
- Turns the headlamp (LO) OFF 5 minutes after the ignition switch is turned OFF.
- Turns the headlamp (LO) OFF 5 minutes after detecting that any door opens. (Door switch ON).
- Turns the headlamp (LO) OFF a certain period of time\* after closing all doors. (Door switch ON → OFF).
- Delay timer function turns OFF, when the ignition switch is other than OFF or the lighting switch is other than AUTO.

\*: The preset time is 45 seconds. The timer operating time can be set by CONSULT. Refer to [EXL-132. "HEADLAMP : CONSULT Function \(BCM - HEAD LAMP\) \(HALOGEN TYPE\)".](#)

**NOTE:**

When any position other than the lighting switch AUTO is set, the auto light system function switches to the exterior lamp battery saver function.

### WIPER LINKED AUTO LIGHTING FUNCTION

BCM turns the exterior lamps ON when detecting 4 operations of the front wiper work the light switch in AUTO position.

**NOTE:**

BCM turns OFF the headlamps 3 seconds after the front wiper switch is turned from ON⇒OFF.

### DAYTIME RUNNING LIGHT SYSTEM

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

EXL

# SYSTEM


< SYSTEM DESCRIPTION >

[HALOGEN TYPE]


## DAYTIME RUNNING LIGHT SYSTEM : System Diagram

INFOID:000000012201721

EXCEPT FOR NISMO MODELS



NISMO MODELS



## DAYTIME RUNNING LIGHT SYSTEM : System Description

INFOID:000000012201722

### OUTLINE

Except for NISMO Models

- Turns the headlamp (HI) ON [Headlamp (HI) at approximately half illumination] as the daytime running light.
- Daytime running light is controlled by daytime running light control function and combination switch reading function of BCM, and relay control function of IPDM E/R.

NISMO Models

Daytime running light is controlled by daytime running light control function and combination switch reading function of BCM, and relay control function of IPDM E/R.

### DAYTIME RUNNING LIGHT OPERATION

Except for NISMO Models

- BCM detects the combination switch condition by the combination switch reading function.
- BCM detects vehicle condition depending on the following signals.
  - Engine status signal (received from ECM via CAN communication)
  - Parking brake switch signal (received from combination meter via CAN communication)
- BCM transmits the daytime running light request signal to IPDM E/R via CAN communication according to the daytime running light ON condition.

Daytime running light ON condition

- Engine running with the parking brake released, and any following conditions are satisfied.

# SYSTEM

< SYSTEM DESCRIPTION >

[HALOGEN TYPE]

- Lighting switch OFF
- Lighting switch 1ST
- IPDM E/R controls the daytime running light relay (ground-side) to turn ON according to the daytime running light request signal.
- Power is supplied from the daytime running light relay through headlamp high RH and IPDM E/R to headlamp high LH. And high beam headlamps are illuminated (approximately half illumination) as the daytime running light.

## NISMO Models


- BCM detects the combination switch condition by the combination switch reading function.
- BCM detects vehicle condition depending on the following signals.
  - Engine status signal (received from ECM via CAN communication)
  - Parking brake switch signal (received from combination meter via CAN communication)
- BCM transmits the daytime running light request signal to IPDM E/R via CAN communication according to the daytime running light ON condition.

## Daytime running light ON condition

- Engine running with the parking brake released, and any following conditions are satisfied.
  - Lighting switch OFF
  - Lighting switch 1ST
  - IPDM E/R turns the integrated daytime running light relay ON, and turns the daytime running light ON according to the daytime running light request signal.

## TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

### TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : System Diagram



### TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : System Description

INFOID:000000012201724

## OUTLINE

Turn signal lamp and hazard warning lamp is controlled by combination switch reading function and the flasher control function of BCM.

## TURN SIGNAL LAMP OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM supplies voltage to the right (left) turn signal lamp circuit when the ignition switch is ON and the turn signal switch is in the right (left) position. BCM blinks the turn signal lamp.

## HAZARD WARNING LAMP OPERATION

BCM supplies voltage to both turn signal lamp circuits when the hazard switch is ON. BCM blinks the hazard warning lamp.

## TURN SIGNAL INDICATOR LAMP AND TURN SIGNAL SOUND OPERATION

- BCM transmits the turn indicator signal to the combination meter using CAN communication while the turn signal lamp and the hazard warning lamp are operating.

# SYSTEM

[HALOGEN TYPE]

## < SYSTEM DESCRIPTION >

- Combination meter outputs the turn signal sound with the integrated buzzer while blinking the turn signal indicator lamp according to the turn indicator signal.

### 3-TIME FLASHER FUNCTION

- By a short touch of the turn signal lever, BCM blinks the turn signal lamps 3 times in the selected direction.
- Cancels the operation when short touch of the turn signal lever in the reverse direction during the 3-time flasher function operation.

### HIGH FLASHER OPERATION


- BCM detects the turn signal lamp circuit status from the current value.
- BCM increases the turn signal lamp blinking speed if the bulb or harness open is detected with the turn signal lamp operating.

#### NOTE:

The blinking speed is normal while operating the hazard warning lamp.

## PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM

### PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM : System Diagram



### PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM : System Description

INFOID:000000012201726

#### OUTLINE

Parking, license plate, side marker and tail lamps are controlled by combination switch reading function and parking, license plate, side marker and tail lamps control function of BCM, and relay control function of IPDM E/R.

#### PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits the position light request signal to IPDM E/R and the combination meter via CAN communication according to the parking, license plate, side marker and tail lamps ON condition.

Parking, license plate, side marker and tail lamps ON condition (When any of the following conditions are satisfied)

- Lighting switch 1ST
- Lighting switch 2ND
- Lighting switch AUTO (Only when the illumination judgment by auto light system is ON. For details, refer to [EXL-124, "AUTO LIGHT SYSTEM : System Description".](#))
- IPDM E/R turns the integrated tail lamp relay ON and turns the parking, license plate and tail lamps ON according to the position light request signal.
- Combination meter turns the tail lamp indicator lamp ON according to the position light request signal.

### PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM : Fail-Safe

INFOID:000000012201727

#### CAN COMMUNICATION CONTROL



# SYSTEM

## < SYSTEM DESCRIPTION >

[HALOGEN TYPE]


When CAN communication with BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If No CAN Communication Is Available With BCM

Control part	Fail-safe operation
<ul style="list-style-type: none"> <li>• Parking lamp</li> <li>• License plate lamp</li> <li>• Tail lamp</li> </ul>	<ul style="list-style-type: none"> <li>• Turns ON the tail lamp relay when the ignition switch is turned ON</li> <li>• Turns OFF the tail lamp relay when the ignition switch is turned OFF</li> </ul>

## FRONT FOG LAMP SYSTEM

### FRONT FOG LAMP SYSTEM : System Diagram



### FRONT FOG LAMP SYSTEM : System Description

INFOID:0000000012201729

#### OUTLINE

Front fog lamp is controlled by combination switch reading function and front fog lamp control function of BCM, and relay control function of IPDM E/R.

#### FRONT FOG LAMP OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits the front fog light request signal to IPDM E/R via CAN communication according to the front fog lamp ON condition.

Front fog lamp ON condition

- Front fog lamp switch ON, and any of the following conditions are satisfied. [Except headlamp (HI) ON condition]

- Lighting switch 2ND
- Lighting switch AUTO (Only when the illumination judgment by auto light system is ON. For details, refer to [EXL-124. "AUTO LIGHT SYSTEM : System Description".](#))
- IPDM E/R turns the integrated front fog lamp relay ON, and turns the front fog lamp ON according to the front fog light request signal.

### FRONT FOG LAMP SYSTEM : Fail-Safe

INFOID:0000000012201730

#### CAN COMMUNICATION CONTROL

When CAN communication with ECM and BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If No CAN Communication Is Available With BCM

Control part	Fail-safe operation
Front fog lamp	Front fog lamp relay OFF

## EXTERIOR LAMP BATTERY SAVER SYSTEM


# SYSTEM

< SYSTEM DESCRIPTION >

[HALOGEN TYPE]

## EXTERIOR LAMP BATTERY SAVER SYSTEM : System Diagram

INFOID:000000012201731



## EXTERIOR LAMP BATTERY SAVER SYSTEM : System Description

INFOID:000000012201732

### OUTLINE

- Exterior lamp battery saver system is controlled by combination switch reading function and exterior lamp battery saver function of BCM, and relay control function of IPDM E/R.
  - BCM turns the exterior lamp\* OFF, according to the vehicle status when ignition switch is turned OFF while exterior lamp is ON, for preventing battery discharge.
- \*: Headlamp (LO/HI), front fog lamp, parking lamp, license plate lamp, side marker lamp and tail lamp

### EXTERIOR LAMP BATTERY SAVER ACTIVATION

- BCM activates the timer and turns the exterior lamp OFF 45 seconds after the ignition switch is turned from ON → OFF with the exterior lamps ON.
- When in any of following conditions (after the exterior lamp battery saver is activated), exterior lamps can be turned ON.
  - Ignition switch is turned from OFF → ON
  - Lighting switch is changed
  - Front fog lamp switch is changed

# DIAGNOSIS SYSTEM (BCM)

[HALOGEN TYPE]

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (BCM)

### COMMON ITEM

### COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000012962265

### APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
Work Support	Changes the setting for each system function.
Self Diagnostic Result	Displays the diagnosis results judged by BCM.
CAN Diag Support Monitor	Monitors the reception status of CAN communication viewed from BCM.
Data Monitor	The BCM input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from BCM.
Ecu Identification	The BCM part number is displayed.
Configuration	<ul style="list-style-type: none"> <li>Read and save the vehicle specification.</li> <li>Write the vehicle specification when replacing BCM.</li> </ul>

### SYSTEM APPLICATION

BCM can perform the following functions for each system.

#### NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

×: Applicable item

System	Sub system selection item	Diagnosis mode		
		Work Support	Data Monitor	Active Test
Door lock	DOOR LOCK	×	×	×
Rear window defogger	REAR DEFOGGER		×	×
Warning chime	BUZZER		×	×
Interior room lamp timer	INT LAMP	×	×	×
Exterior lamp	HEAD LAMP	×	×	×
Wiper and washer	WIPER	×	×	×
Turn signal and hazard warning lamps	FLASHER	×	×	×
Air conditioning system	AIR CONDITONER		×	×*
<ul style="list-style-type: none"> <li>Intelligent Key system</li> <li>Engine start system</li> </ul>	INTELLIGENT KEY	×	×	×
Combination switch	COMB SW		×	
Body control system	BCM	×		
NVIS - NATS	IMMU	×	×	×
Interior room lamp battery saver	BATTERY SAVER	×	×	×
Back door open	TRUNK		×	
Theft warning alarm	THEFT ALM	×	×	×
RAP	RETAINED PWR		×	
Signal buffer system	SIGNAL BUFFER		×	×
TPMS	AIR PRESSURE MONITOR	×	×	×

#### NOTE:

\*: For models with automatic A/C, this diagnosis mode is not used.

### FREEZE FRAME DATA (FFD)

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays on CONSULT.

# DIAGNOSIS SYSTEM (BCM)

[HALOGEN TYPE]

< SYSTEM DESCRIPTION >

CONSULT screen item	Indication/Unit	Description	
Vehicle Speed	km/h	Vehicle speed of the moment a particular DTC is detected	
Odo/Trip Meter	km	Total mileage (Odometer value) of the moment a particular DTC is detected	
Vehicle Condition	SLEEP>LOCK	Power position status of the moment a particular DTC is detected	While turning BCM status from low power consumption mode to normal mode (Power position is "LOCK"*.)
	SLEEP>OFF		While turning BCM status from low power consumption mode to normal mode (Power position is "OFF".)
	LOCK>ACC		While turning power position from "LOCK"* to "ACC"
	ACC>ON		While turning power position from "ACC" to "IGN"
	RUN>ACC		While turning power position from "RUN" to "ACC" (Vehicle is stopping and selector lever is except P position.)
	CRANK>RUN		While turning power position from "CRANKING" to "RUN" (From cranking up the engine to run it)
	RUN>URGENT		While turning power position from "RUN" to "ACC" (Emergency stop operation)
	ACC>OFF		While turning power position from "ACC" to "OFF"
	OFF>LOCK		While turning power position from "OFF" to "LOCK"*
	OFF>ACC		While turning power position from "OFF" to "ACC"
	ON>CRANK		While turning power position from "IGN" to "CRANKING"
	OFF>SLEEP		While turning BCM status from normal mode (Power position is "OFF".) to low power consumption mode
	LOCK>SLEEP		While turning BCM status from normal mode (Power position is "LOCK"*. ) to low power consumption mode
	LOCK		Power position is "LOCK"*
	OFF		Power position is "OFF" (Ignition switch OFF)
	ACC		Power position is "ACC" (Ignition switch ACC)
	ON		Power position is "IGN" (Ignition switch ON with engine stopped)
ENGINE RUN	Power position is "RUN" (Ignition switch ON with engine running)		
CRANKING	Power position is "CRANKING" (At engine cranking)		
IGN Counter	0 - 39	The number of times that ignition switch is turned ON after DTC is detected <ul style="list-style-type: none"> <li>• The number is 0 when a malfunction is detected now.</li> <li>• The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON.</li> <li>• The number is fixed to 39 until the self-diagnosis results are erased if it is over 39.</li> </ul>	

**NOTE:**

\*: Power position shifts to "LOCK" from "OFF", when ignition switch is in the OFF position, selector lever is in the P position (A/T models and CVT models), and any of the following conditions are met.

- Closing door
- Opening door
- Door is locked using door request switch
- Door is locked using Intelligent Key

The power position shifts to "ACC" when the push-button ignition switch (push switch) is pushed at "LOCK".

## HEADLAMP

### HEADLAMP : CONSULT Function (BCM - HEAD LAMP) (HALOGEN TYPE)

INFOID:000000012201734

## WORK SUPPORT

# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[HALOGEN TYPE]

Service item	Setting item	Setting	
CUSTOM A/LIGHT SETTING*1	MODE1*2	Normal	A
	MODE2	More sensitive setting than normal setting (Turns ON earlier than normal operation)	B
	MODE3	More sensitive setting than MODE2 (Turns ON earlier than MODE2)	
	MODE4	Less sensitive setting than normal setting (Turns ON later than normal operation)	
BATTERY SAVER SET	On*2	With the exterior lamp battery saver function	C
	Off	Without the exterior lamp battery saver function	
ILL DELAY SET*1	MODE1*2	45 sec.	D E F G H I J
	MODE2	Without the function	
	MODE3	30 sec.	
	MODE4	60 sec.	
	MODE5	90 sec.	
	MODE6	120 sec.	
	MODE7	150 sec.	
	MODE8	180 sec.	
HEAD LIGHT TIMER	MODE1	10 sec.	Sets follow me home function activating time
	MODE2*2	30 sec.	
AUTO LIGHT LOGIC SET*1	MODE1*2	With twilight ON custom & with wiper INT, LO and HI	H
	MODE2	With twilight ON custom & with wiper LO and HI	
	MODE3	With twilight ON custom & without	I
	MODE4	Without twilight ON custom & with wiper INT, LO and HI	
	MODE5	Without twilight ON custom & with wiper LO and HI	
	MODE6	Without twilight ON custom & without	J

\*1: For models without auto light system, this item cannot be used.

\*2: Factory setting

## DATA MONITOR

### NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

EXL

Monitor item [Unit]	Description	
PUSH SW [On/Off]	Indicates [On/Off] condition of push-button ignition switch	M
ENGINE STATE [STOP/STALL/CRANK/RUN]	Indicates [STOP/STALL/CRANK/RUN] condition of engine states	N
VEH SPEED 1 [km/h]	Display the vehicle speed signal received from combination meter by numerical value [km/h]	O

P

# DIAGNOSIS SYSTEM (BCM)

[HALOGEN TYPE]

## < SYSTEM DESCRIPTION >

Monitor item [Unit]	Description
TURN SIGNAL R [On/Off]	Each switch status that BCM judges from the combination switch reading function
TURN SIGNAL L [On/Off]	
TAIL LAMP SW [On/Off]	
HI BEAM SW [On/Off]	
HEAD LAMP SW 1 [On/Off]	
HEAD LAMP SW 2 [On/Off]	
PASSING SW [On/Off]	
AUTO LIGHT SW*1 [On/Off]	
FR FOG SW*2 [On/Off]	
DOOR SW-DR [On/Off]	Indicated [On/Off] condition of front door switch (driver side)
DOOR SW-AS [On/Off]	Indicated [On/Off] condition of front door switch (passenger side)
DOOR SW-RR [On/Off]	Indicated [On/Off] condition of rear door switch RH
DOOR SW-RL [On/Off]	Indicated [On/Off] condition of rear door switch LH
DOOR SW-BK [On/Off]	Indicated [On/Off] condition of back door switch
OPTI SEN (DTCT) [V]	The value of outside brightness voltage input from the optical sensor
OPTI SEN (FILT) [V]	The value of outside brightness voltage filtered by BCM
OPTICAL SENSOR [On/Off/NG]	<b>NOTE:</b> This item cannot be monitored

\*1: For models without auto light system, this item cannot be monitored.

\*2: For models without front fog lamp, this item cannot be monitored.

## ACTIVE TEST

Test item	Operation	Description
TAIL LAMP	On	<ul style="list-style-type: none"> <li>• Transmits the position light request signal to IPDM E/R via CAN communication to turn the parking, license plate and tail lamps ON</li> <li>• Transmits the position light request signal to combination meter via CAN communication to turn the position lamp indicator lamp ON</li> </ul>
	Off	Stops the position light request signal transmission
HEAD LAMP	HI	<ul style="list-style-type: none"> <li>• Transmits the high beam request signal to IPDM E/R via CAN communication to turn the headlamp (HI) ON</li> <li>• Transmits the high beam request signal to combination meter via CAN communication to turn the high beam indicator lamp ON</li> </ul>
	Low	Transmits the low beam request signal to IPDM E/R via CAN communication to turn the headlamp (LO) ON
	Off	Stops the high beam request signal and low beam request signal transmission

# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[HALOGEN TYPE]

Test item	Operation	Description
FR FOG LAMP*1	On	<ul style="list-style-type: none"> <li>Transmits the front fog light request signal to IPDM E/R via CAN communication to turn the front fog lamp ON (With front fog lamp)</li> <li>Transmits the daytime running light request signal to IPDM E/R via CAN communication to turn the daytime running light ON (NISMO models with daytime running light system)</li> </ul>
	Off	<ul style="list-style-type: none"> <li>Stops the front fog light request signal transmission (With front fog lamp)</li> <li>Stops the front fog light request signal transmission (NISMO models with daytime running light system)</li> </ul>
DAYTIME RUNNING LIGHT*2	On	Transmits the daytime running light request signal to IPDM E/R via CAN communication to turn the headlamp (HI) ON [Headlamp (HI) at approximately half illumination]
	Off	Stops the daytime running light request signal transmission
ILL DIM SIGNAL	On	<b>NOTE:</b> This item cannot be tested
	Off	

\*1: For models without front fog lamp and except for NISMO models with daytime running light system, this item cannot be tested.

\*2: For models without daytime running light system and NISMO models with daytime running light system, this item cannot be tested.

## FLASHER

### FLASHER : CONSULT Function (BCM - FLASHER) (HALOGEN TYPE)

INFOID:000000012201735

#### WORK SUPPORT

Service item	Setting item	Setting	
HAZARD ANSWER BACK	Lock Only	With locking only	Sets the hazard warning lamp answer back function when the door is lock/unlock with the door request switch and Intelligent Key
	Unlock Only	With unlocking only	
	Lock/Unlock*	With locking/unlocking	
	Off	Without the function	

\*: Factory setting

#### DATA MONITOR

##### NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor item [Unit]	Description
REQ SW -DR [On/Off]	Indicates [On/Off] condition of door request switch (driver side)
REQ SW -AS [On/Off]	Indicates [On/Off] condition of door request switch (passenger side)
PUSH SW [On/Off]	Indicates [On/Off] condition of push-button ignition switch
TURN SIGNAL R [On/Off]	Each switch status that BCM detects from the combination switch reading function
TURN SIGNAL L [On/Off]	
HAZARD SW [On/Off]	The switch status input from the hazard switch

# DIAGNOSIS SYSTEM (BCM)

[HALOGEN TYPE]

## < SYSTEM DESCRIPTION >

Monitor item [Unit]	Description
RKE-LOCK [On/Off]	Indicates [On/Off] condition of LOCK signal from Intelligent Key
RKE-UNLOCK [On/Off]	Indicates [On/Off] condition of UNLOCK signal from Intelligent Key
RKE-PANIC* [On/Off]	Indicates [On/Off] condition of PANIC button of Intelligent Key

\*: For models without panic alarm function, this item cannot be used.

## ACTIVE TEST

Test item	Operation	Description
FLASHER	RH	<ul style="list-style-type: none"><li>• Outputs voltage to turn the right side turn signal lamps ON</li><li>• Transmits the turn indicator signal to combination meter via CAN communication to turn the turn signal indicator lamp (RH) ON</li></ul>
	LH	<ul style="list-style-type: none"><li>• Outputs voltage to turn the left side turn signal lamps ON</li><li>• Transmits the turn indicator signal to combination meter via CAN communication to turn the turn signal indicator lamp (LH) ON</li></ul>
	Off	<ul style="list-style-type: none"><li>• Stops the voltage to turn the turn signal lamps OFF</li><li>• Stops the turn indicator signal transmission</li></ul>



DIAGNOSIS SYSTEM (IPDM E/R)

Diagnosis Description

INFOID:000000012962266

AUTO ACTIVE TEST

Description

In auto active test mode, the IPDM E/R sends a drive signal to the following systems to check their operation.

- Rear window defogger
- Front wiper motor
- Parking lamp
- License plate lamp
- Tail lamp
- Side marker lamp
- Front fog lamp
- Headlamp (LO, HI)
- A/C compressor (magnet clutch)
- Cooling fan

Operation Procedure

**CAUTION:**

**Wiper arm interferes with hood when wiper is operated while wiper arm is in the raised position. Always perform auto active test without setting wiper arm in the raised position. Always pour water on front windshield glass in advance to auto active test so that damage on front windshield glass surface is prevented.**

1. Turn the ignition switch OFF.
2. Turn the ignition switch ON, and within 20 seconds, press the driver door switch 10 times. Then turn the ignition switch OFF.

**CAUTION:**

**Close passenger door.**

3. Turn the ignition switch ON within 10 seconds. After that the horn sounds once and the auto active test starts.

**CAUTION:**

**Engine starts when ignition switch is turned ON while brake pedal is depressed.**

4. After a series of the following operations is repeated 3 times, auto active test is completed.

**NOTE:**

- When auto active test mode has to be cancelled halfway through test, turn the ignition switch OFF.
- When auto active test is not activated, door switch may be the cause. Check door switch. Refer to [DLK-77](#), "[Component Function Check](#)".

Inspection in Auto Active Test Mode

When auto active test mode is actuated, the following operation sequence is repeated 3 times.

Operation sequence	Inspection location	Operation
1	Rear window defogger	10 seconds
2	Front wiper motor	LO for 5 seconds → HI for 5 seconds
3	<ul style="list-style-type: none"> <li>• Parking lamp</li> <li>• License plate lamp</li> <li>• Tail lamp</li> <li>• Side marker lamp</li> <li>• Front fog lamp</li> </ul>	10 seconds
4	Headlamp	LO for 10 seconds → HI ON ⇔ OFF 5 times
5	A/C compressor (magnet clutch)	ON ⇔ OFF 5 times
6	Cooling fan	50% duty for 5 seconds → 100% duty for 5 seconds


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# DIAGNOSIS SYSTEM (IPDM E/R)

[HALOGEN TYPE]

## < SYSTEM DESCRIPTION >

Concept of auto active test



- IPDM E/R starts the auto active test with the door switch signals transmitted by BCM via CAN communication. Therefore, the CAN communication line between IPDM E/R and BCM is considered normal if the auto active test starts successfully.
- The auto active test facilitates troubleshooting if any systems controlled by IPDM E/R cannot be operated.

Diagnosis chart in auto active test mode

Symptom	Inspection contents	Possible cause
Rear window defogger does not operate	Perform auto active test. Does the rear window defogger operate?	YES BCM signal input circuit
		NO <ul style="list-style-type: none"> <li>• Rear window defogger</li> <li>• Rear window defogger ground circuit</li> <li>• Harness or connector between IPDM E/R and rear window defogger</li> <li>• IPDM E/R</li> </ul>
Any of the following components do not operate <ul style="list-style-type: none"> <li>• Parking lamp</li> <li>• License plate lamp</li> <li>• Tail lamp</li> <li>• Side marker lamp</li> <li>• Front fog lamp</li> <li>• Headlamp (HI, LO)</li> <li>• Front wiper motor</li> </ul>	Perform auto active test. Does the applicable system operate?	YES BCM signal input circuit
		NO <ul style="list-style-type: none"> <li>• Lamp or motor</li> <li>• Lamp or motor ground circuit</li> <li>• Harness or connector between IPDM E/R and applicable system</li> <li>• IPDM E/R</li> </ul>
A/C compressor does not operate	Perform auto active test. Does the magnet clutch operate?	YES <ul style="list-style-type: none"> <li>• A/C amp. signal input circuit</li> <li>• CAN communication signal between A/C amp. and ECM</li> <li>• CAN communication signal between ECM and IPDM E/R</li> </ul>
		NO <ul style="list-style-type: none"> <li>• Magnet clutch</li> <li>• Harness or connector between IPDM E/R and magnet clutch</li> <li>• IPDM E/R</li> </ul>

# DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

[HALOGEN TYPE]

Symptom	Inspection contents		Possible cause
Cooling fan does not operate	Perform auto active test. Does the cooling fan operate?	YES	<ul style="list-style-type: none"> <li>• ECM signal input circuit</li> <li>• CAN communication signal between ECM and IPDM E/R</li> </ul>
		NO	<ul style="list-style-type: none"> <li>• Harness or connector between IPDM E/R and cooling fan relay</li> <li>• Harness or connector between IPDM E/R and cooling fan control module.</li> <li>• Harness or connector between cooling fan control module and cooling fan motor</li> <li>• Cooling fan motor</li> <li>• Cooling fan relay</li> <li>• Cooling fan control module</li> <li>• IPDM E/R</li> </ul>

## CONSULT Function (IPDM E/R)

INFOID:000000012962267

### APPLICATION ITEM

CONSULT performs the following functions via CAN communication with IPDM E/R.

Diagnosis mode	Description
Ecu Identification	Allows confirmation of IPDM E/R part number.
Self Diagnostic Result	Displays the diagnosis results judged by IPDM E/R.
Data Monitor	Displays the real-time input/output data from IPDM E/R input/output data.
Active Test	IPDM E/R can provide a drive signal to electronic components to check their operations.
CAN Diag Support Monitor	The results of transmit/receive diagnosis of CAN communication can be read.

### SELF DIAGNOSTIC RESULT

Refer to [PCS-24, "DTC Index"](#).

### DATA MONITOR

#### NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor Item [Unit]	MAIN SIGNALS	Description
RAD FAN REQ [%]	×	Displays the value of the cooling fan speed request signal received from ECM via CAN communication.
AC COMP REQ [Off/On]	×	Displays the status of the A/C compressor request signal received from ECM via CAN communication.
TAIL&CLR REQ [Off/On]	×	Displays the status of the position light request signal received from BCM via CAN communication.
HL LO REQ [Off/On]	×	Displays the status of the low beam request signal received from BCM via CAN communication.
HL HI REQ [Off/On]	×	Displays the status of the high beam request signal received from BCM via CAN communication.
FR FOG REQ [Off/On]	×	Displays the status of the front fog light request signal received from BCM via CAN communication.
FR WIP REQ [Stop/1LOW/Low/Hi]	×	Displays the status of the front wiper request signal received from BCM via CAN communication.
WIP AUTO STOP [STOP P/ACT P]	×	Displays the status of the front wiper auto stop signal judged by IPDM E/R.
WIP PROT [Off/BLOCK]	×	Displays the status of the front wiper fail-safe operation judged by IPDM E/R.
IGN RLY1 -REQ [Off/On]		Displays the status of the ignition switch ON signal received from BCM via CAN communication.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

# DIAGNOSIS SYSTEM (IPDM E/R)

[HALOGEN TYPE]

## < SYSTEM DESCRIPTION >

Monitor Item [Unit]	MAIN SIGNALS	Description
IGN RLY [Off/On]	×	Displays the status of the ignition relay judged by IPDM E/R.
PUSH SW [Off/On]		Displays the status of the push-button ignition switch judged by IPDM E/R.
INTER/NP SW [Off/On]		Displays the status of the ignition power supply (M/T models) or shift position (CVT models) judged by IPDM E/R.
ST RLY CONT [Off/On]		Displays the status of the starter relay status signal received from BCM via CAN communication.
IHBT RLY -REQ [Off/On]		Displays the status of the starter control relay signal received from BCM via CAN communication.
ST/INH RLY [Off/ ST ON/INH ON/UNKWN]		Displays the status of the starter relay and starter control relay judged by IPDM E/R.
DETENT SW [Off/On]		Displays the status of the CVT shift selector (detention switch) judged by IPDM E/R.
S/L RLY -REQ [Off/On]		<b>NOTE:</b> This item is indicated, but not monitored.
S/L STATE [LOCK/UNLK/UNKWN]		<b>NOTE:</b> This item is indicated, but not monitored.
DTRL REQ [Off/On]		Displays the status of the daytime running light request signal received from BCM via CAN communication. <b>NOTE:</b> This item is monitored only for the except for NISMO models.
OIL P SW [Open/Close]		<b>NOTE:</b> This item is indicated, but not monitored.
HOOD SW [Off/On]		<b>NOTE:</b> This item is indicated, but not monitored.
HL WASHER REQ [Off/On]		<b>NOTE:</b> This item is indicated, but not monitored.
THFT HRN REQ [Off/On]		Displays the status of the theft warning horn request signal received from BCM via CAN communication.
HORN CHIRP [Off/On]		Displays the status of the horn reminder request signal received from BCM via CAN communication.

## ACTIVE TEST

### Test item

Test item	Operation	Description
HORN	On	Operates horn relay for 20 ms.
REAR DEFOGGER	Off	OFF
	On	Operates the rear window defogger relay.
FRONT WIPER	Off	OFF
	Lo	Operates the front wiper relay.
	Hi	Operates the front wiper relay and front wiper high relay.
MOTOR FAN	1	OFF
	2	Transmits 50% pulse duty signal (PWM signal) to the cooling fan control module.
	3	Transmits 75% pulse duty signal (PWM signal) to the cooling fan control module.
	4	Transmits 100% pulse duty signal (PWM signal) to the cooling fan control module.
HEAD LAMP WASHER	On	<b>NOTE:</b> This item is indicated, but cannot be tested.

# DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

[HALOGEN TYPE]

Test item	Operation	Description
EXTERNAL LAMPS	Off	OFF
	TAIL	Operates the tail lamp relay.
	Lo	Operates the headlamp low relay.
	Hi	Operates the headlamp low relay and ON/OFF the headlamp high relay at 1 second intervals.
	Fog	Operates the front fog lamp relay.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# ECU DIAGNOSIS INFORMATION

## BCM, IPDM E/R

### List of ECU Reference

INFOID:000000012201738


ECU	Reference
BCM	<a href="#">BCS-39, "Reference Value"</a>
	<a href="#">BCS-60, "Fail-safe"</a>
	<a href="#">BCS-61, "DTC Inspection Priority Chart"</a>
	<a href="#">BCS-62, "DTC Index"</a>
IPDM E/R	<a href="#">PCS-17, "Reference Value"</a>
	<a href="#">PCS-23, "Fail-safe"</a>
	<a href="#">PCS-24, "DTC Index"</a>



# EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[HALOGEN TYPE]




JRLWF5312GB



# EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[HALOGEN TYPE]



JRLWF5313GB


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[HALOGEN TYPE]



JRLWF5314GB


# EXTERIOR LIGHTING SYSTEM

[HALOGEN TYPE]

< WIRING DIAGRAM >


## EXTERIOR LIGHTING SYSTEM

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	NS160WV-C5



Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	-
2	GR	-
6	SB	-
10	W	-
11	L	-
12	R	-
13	GR	-
14	Y	-
15	LG	-
16	BR	-

Connector No.	B2
Connector Name	WIRE TO WIRE
Connector Type	NS160WV-C5



Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	-
2	L	-
4	Y	-
7	V	-
9	SB	-
10	V	-
11	Y	-
12	GR	-
13	R	-


14	P	-
15	L	-
16	G	-

Connector No.	B7
Connector Name	WIRE TO WIRE
Connector Type	TH24FW-WH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	W	-
3	V	-
5	G	-
6	LG	-
7	R	-
8	P	-
9	L	-
10	LG	-
11	LG	-
12	R	-
13	L	-
14	L	-
15	BR	-
16	BR	-
17	L	-
18	P	-
19	B	-
20	G	-
21	W	-
22	R	-
23	SHIELD	-

Connector No.	B10
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA05P-FH05-5A




Terminal No.	Color Of Wire	Signal Name [Specification]
43	P	-
44	LG	BACK DOOR SW
45	R	REAR WIPER STOP POSITION
46	LG	PASSENGER DOOR SW
47	SB	DRIVER DOOR SW
48	BR	REAR LH DOOR SW
49	L	LUGGAGE LAMP OUTPUT
51	Y	BACK DOOR RECSW
53	GR	BK DOOR OPER OUTPUT
54	P	REAR WIPER OUTPUT
55	G	RR DOOR UNLK OUTPUT

Connector No.	B19
Connector Name	WIRE TO WIRE
Connector Type	MS230B-P-1C



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
2	R	-

Connector No.	B20
Connector Name	WIRE TO WIRE
Connector Type	NS100WV-C510



Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	-
7	GR	-
8	LG	-
9	R	-
10	B	-
12	R	-
13	Y	-
14	SHIELD	-
15	W	-
16	L	-
17	P	-
18	GR	-

Connector No.	B48
Connector Name	FRONT DOOR SWITCH (DRIVER SIDE)
Connector Type	FA03FN



Terminal No.	Color Of Wire	Signal Name [Specification]
2	SB	-

JRLWF5315GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL


# EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[HALOGEN TYPE]


## EXTERIOR LIGHTING SYSTEM

Connector No.	B89
Connector Name	FRONT DOOR SWITCH (PASSENGER SIDE)
Connector Type	A03FW




Terminal No.	Color Of Wire	Signal Name [Specification]
2	R	-

Connector No.	B83
Connector Name	REAR DOOR SWITCH RH
Connector Type	A03FW




Terminal No.	Color Of Wire	Signal Name [Specification]
2	LG	-

Connector No.	B89
Connector Name	REAR COMBINATION LAMP RH
Connector Type	N066WVCS




Terminal No.	Color Of Wire	Signal Name [Specification]
2	GR	-
3	GR	-
5	W	-
6	G	-

Connector No.	B71
Connector Name	REAR DOOR SWITCH LH
Connector Type	A03FW




Terminal No.	Color Of Wire	Signal Name [Specification]
2	BR	-

Connector No.	B75
Connector Name	JOINT CONNECTOR-B01
Connector Type	G20FB



Terminal No.	Color Of Wire	Signal Name [Specification]
2	G	-
3	G	-
4	G	-
12	V	-
13	V	-
14	V	-
15	R	-
16	R	-
17	R	-

Connector No.	B76
Connector Name	JOINT CONNECTOR-B02
Connector Type	G20FB




Terminal No.	Color Of Wire	Signal Name [Specification]
2	R	-
3	R	-
4	R	-
7	GR	-
8	GR	-
9	GR	-
10	GR	-
12	W	-
13	W	-
14	W	-

Connector No.	B80
Connector Name	REAR COMBINATION LAMP LH
Connector Type	N066WVCS



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	GR	-
3	B	-
5	V	-
6	G	-

Connector No.	B2
Connector Name	WIRE TO WIRE
Connector Type	TH048FW-CS15



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	G	-
3	Y	-
4	V	-
13	W	-
14	SB	-
15	L	-
16	GR	-
17	Y	-
18	W	-
19	R	-
21	R	-
25	G	-
38	G	-
39	LG	-
41	Y	-
43	P	-
44	V	-
45	WM	-
46	BG	-
50	P	-


# EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[HALOGEN TYPE]

## EXTERIOR LIGHTING SYSTEM

Connector No.	D19
Connector Name	DOOR MIRROR (PASSENGER SIDE)
Connector Type	TH16SW-NI



Terminal No.	Color Of Wire	Signal Name [Specification]
1	V	-
2	B	-
3	P	-
4	B	-
6	W	-
7	GR	-
11	BG	-
12	W	-
13	G	-
14	R	-
15	Y	-

Connector No.	D22
Connector Name	WIRE TO WIRE
Connector Type	TH48FW-CS15



Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	-
2	W	-
3	SB	-
4	V	-
7	G	-
8	BG	-
9	LG	-
10	Y	-
11	W	-

12	SB	-
13	B	-
14	P	-
15	LG	-
16	BR	-
17	BR	-
18	P	-
19	V	-
24	G	-
25	R	-
38	G	-
39	B	-
40	V	-
41	P	-
42	R	-
43	GR	-
44	W	-
45	Y	-
46	BG	-
47	G	-
48	L	-
49	R	-
50	LG	-
52	BR	-

Connector No.	D30
Connector Name	DOOR MIRROR (DRIVER SIDE)
Connector Type	TH16SW-NI



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	B	-
3	GR	-
4	B	-
6	P	-
7	LG	-
11	BG	-
12	Y	-
13	G	-
14	V	-

Connector No.	D107
Connector Name	BACK DOOR OPENER SWITCH
Connector Type	TK06SW-1V



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	B	-
3	SB	-
4	B	-
5	V	-
6	B	-

Connector No.	D121
Connector Name	HIGH-MOUNTED STOP LAMP
Connector Type	TK02FW




Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	B	-

Connector No.	D126
Connector Name	WIRE TO WIRE
Connector Type	TM02FB-1C



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
2	R	-

Connector No.	D127
Connector Name	WIRE TO WIRE
Connector Type	NH10FW-CS10



Terminal No.	Color Of Wire	Signal Name [Specification]
6	5	-
4	4	-
3	3	-
2	1	-
1	13	-
2	12	-
11	10	-
9	8	-
20	19	-
18	17	-
16	15	-
14	7	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P


# EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[HALOGEN TYPE]


## EXTERIOR LIGHTING SYSTEM

Connector No.	E8
Connector Name	WIRE TO WIRE
Connector Type	SA43BMP-RS10-SR2



Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	-
2	L	-
3	O	-
4	LG	- [For NISMO RS]
4	V	- [Except for NISMO RS]
5	O	-
7	BR	-
10	R	-
11	G	- [Except for NISMO RS]
11	O	- [For NISMO RS]
12	G	-
13	B	- [Except for NISMO RS]
13	Y	- [For NISMO RS]
14	L	- [Except for NISMO RS]
14	G	- [For NISMO RS]
15	R	- [Except for NISMO RS]
16	SB	-
17	GR	-
18	WT	-
19	L/B	-
20	L/W	-
21	G	-
22	Y	- [Except for NISMO RS]
22	B	- [For NISMO RS]
23	SHIELD	- [Except for NISMO RS]
24	P	- [For NISMO RS]
25	R	-
26	B	-
27	B	-
28	LG	-
29	SB	-
30	G	- [Except for NISMO RS]
30	P	- [For NISMO RS]
31	G	-
32	Y	-

33	BR	-
34	W	- [Except for NISMO RS]
34	W	- [For NISMO RS]
37	L	- [Without intelligent key]
37	LG	- [With intelligent key]
38	SB	-
39	B	-
40	P	-
41	V	-
42	L	-
43	BR	- [For NISMO RS]
43	W	- [Except for NISMO RS]
44	BR	- [For NISMO RS]
44	G	- [For NISMO RS]
45	BR	-
46	Y	-
47	SB	-
48	LG	- [With intelligent key]
48	Y	- [Without intelligent key]



Connector No.	E12
Connector Name	POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	NS08BRC-CS




Connector No.	E14
Connector Name	POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	NS12BRC-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
18	GR	-
19	R	- [Without front fog lamp]
19	W	- [With front fog lamp]
20	G	- [Without front fog lamp]
20	V	- [With front fog lamp]

Connector No.	E13
Connector Name	POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	TH127W-NH




Terminal No.	Color Of Wire	Signal Name [Specification]
35	G	-
36	P	-
37	L	-
39	L	-
41	BR	-
42	Y	-
43	L	-
44	BR	-
45	W	-
46	LG	-



Terminal No.	Color Of Wire	Signal Name [Specification]
23	SB	-
25	BR	-
26	P	-
27	L	-
28	Y	-
30	V	-
31	Y	-
32	R	-
33	G	-
34	L	-

Connector No.	E15
Connector Name	POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	NS14PW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
48	BR	-
49	Y	-
50	G	-
51	L	-
52	P	-
54	P	-
55	G	-
56	SB	-
57	O	-
58	LG	-

# EXTERIOR LIGHTING SYSTEM

[HALOGEN TYPE]

< WIRING DIAGRAM >

## EXTERIOR LIGHTING SYSTEM


59	V	-	-
60	SB	-	-
61	SG	-	-
62	SE	-	-

Connector No.	E18
Connector Name	ECM
Connector Type	RH24FGV-R26-R-RH



Terminal No.	Color Of Wire	Signal Name [Specification]
99	P	CAN COMMUNICATION LINE (CAN-L)
100	L	CAN COMMUNICATION LINE (CAN-H)
101	V	SENSOR POWER SUPPLY
102	R	ACCELERATOR PEDAL POSITION SENSOR 1
103	BR	PNP SIGNAL
104	R	DATA LINK CONNECTOR
105	GR	SENSOR GROUND
106	Y	POWER SUPPLY FOR ECM (BACKUP)
108	GR	CLUTCH PEDAL POSITION SWITCH
109	O	IGNITION SWITCH
110	B	ASCD STEERING SWITCH
111	R	SENSOR GROUND
115	R	ECM RELAY (ELECT OFF)
116	G	STOP LAMP SWITCH
117	Y	BRAKE PEDAL POSITION SWITCH
118	O	FUEL PUMP RELAY
119	W	SENSOR POWER SUPPLY
120	Y	ACCELERATOR PEDAL POSITION SENSOR 2
121	G	SENSOR GROUND
122	G	POWER SUPPLY FOR ECM
123	G	THROTTLE CONTROL MOTOR POWER SUPPLY
124	GR	ECM GROUND
125	L	ECM GROUND
126	W	A/F SENSOR 1 HEATER
127	GR	HEATED OXYGEN SENSOR 2 HEATER
		ECM GROUND

Connector No.	E19
Connector Name	ECM
Connector Type	RH24FB-R28-L-LH



Terminal No.	Color Of Wire	Signal Name [Specification]
121	L	EVAP CONTROL SYSTEM PRESSURE SENSOR
123	P	CAN COMMUNICATION LINE (CAN-L)
124	L	CAN COMMUNICATION LINE (CAN-H)
125	G	SENSOR POWER SUPPLY
128	SB	FUEL TANK TEMPERATURE SENSOR
132	GR	CLUTCH PEDAL POSITION SWITCH
133	LG	IGNITION SWITCH
134	P	ASCD STEERING SWITCH
135	B	SENSOR GROUND
139	R	STOP LAMP SWITCH
140	G	BRAKE PEDAL POSITION SWITCH
141	L	EVAP CANISTER VENT CONTROL VALVE
142	O	SENSOR POWER SUPPLY
143	W	ACCELERATOR PEDAL POSITION SENSOR 2
144	Y	SENSOR GROUND
145	G	POWER SUPPLY FOR ECM
146	G	SENSOR GROUND
147	GR	ECM GROUND
148	Y	ECM GROUND
149	GR	ECM GROUND
150	R	ACCELERATOR PEDAL POSITION SENSOR 1
151	GR	SENSOR GROUND
152	GR	ECM GROUND

Connector No.	E28
Connector Name	PARKING LAMP LH
Connector Type	FH20FGY



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	B	-

Connector No.	E32
Connector Name	FRONT FOG LAMP LH
Connector Type	FH20ZFB



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	B	-

Connector No.	E31
Connector Name	FRONT SIDE MARKER LAMP LH
Connector Type	T02FB



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	B/R	-

Connector No.	E32
Connector Name	FRONT SIDE MARKER LAMP RH
Connector Type	T02FB



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	B	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# EXTERIOR LIGHTING SYSTEM

[HALOGEN TYPE]

< WIRING DIAGRAM >

## EXTERIOR LIGHTING SYSTEM

Connector No.	E54
Connector Name	FRONT TURN SIGNAL LAMP LH
Connector Type	HS02FG-1V



Terminal No.	Color Of Wire	Signal Name [Specification]
1	V	-
2	B	-

Connector No.	E55
Connector Name	ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)
Connector Type	RH28FB-NU4-LH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	BAT (MTR)
2	L	L
3	B	GND (SQU)
4	B	GND (MTR)
5	R	VDC OFF SW
6	G	ASCD CANCEL SW
8	R	STOP LAMP SW
9	P	CAN-L
11	BR	DP RR
12	W	DS FR
13	G	VCC
14	R	SERIAL+
15	Y	IGN
16	V	REVERSE SIGNAL
17	W	DP FR
21	Y	DP FR
22	L	CANH
23	LG	DP FL

25	G	RR LH SEQS VP
26	BR	GR RE
27	W	SEBAL-
28	W	SEBAL-
30	BE	RR LH SEQS SIG

Connector No.	E44
Connector Name	PARKING LAMP RH
Connector Type	RS02FG



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	B	-

Connector No.	E47
Connector Name	FRONT TURN SIGNAL LAMP RH
Connector Type	HS02FG-1V



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
2	B	-

Connector No.	E48
Connector Name	FRONT FOG LAMP RH
Connector Type	HS02FB



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	B	-

Connector No.	E54
Connector Name	HEADLAMP LH
Connector Type	RS04FGYPR




Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	-
2	B	- [With halogen lamp]
3	B	- [With xenon lamp]
4	L	-

Connector No.	E55
Connector Name	HEADLAMP RH
Connector Type	RS04FGYPR



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
2	B	- [With halogen lamp]
3	B	- [With xenon lamp]
3	GR	- [Without daytime running light system] [With halogen lamp]
3	W	- [Without daytime running light system] [With xenon lamp]
4	P	- [With daytime running light system]

Connector No.	E65
Connector Name	DAYTIME RUNNING LIGHT RELAY
Connector Type	MS03FB-M2-LC



Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	-
2	Y	-
3	W	-
4	B	-
5	LG	-



# EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[HALOGEN TYPE]

## EXTERIOR LIGHTING SYSTEM

Connector No.	E75
Connector Name	DAYTIME RUNNING LIGHT RH
Connector Type	RS02FB



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	B	-

Connector No.	E75
Connector Name	DAYTIME RUNNING LIGHT LH
Connector Type	RS02FB



Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	-
2	BR	-

Connector No.	E81
Connector Name	JOINT CONNECTOR-E81
Connector Type	A32FL



Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	-
2	BR	-
3	BR	-
4	BR	-
6	R	-
8	R	-
9	R	-
10	R	-
11	R	-
12	R	-

Connector No.	E83
Connector Name	JOINT CONNECTOR-E84
Connector Type	PH10FB




Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	- [For NISMO RS]
1	V	- [Except for NISMO RS]
2	LG	-
3	Y	-
4	Y	-
5	Y	-
6	LG	- [For NISMO RS]
6	V	- [Except for NISMO RS]
8	V	-
9	V	-

Connector No.	E84
Connector Name	JOINT CONNECTOR-E82
Connector Type	A32FL



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	L	-
3	L	-
4	L	-
5	L	-
6	L	-
7	P	-
8	P	-
9	P	-
10	P	-
11	P	-
12	P	-

Connector No.	E82
Connector Name	STOP LAMP SWITCH
Connector Type	MD4FM-LC



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	R	-
3	BE	-
4	P	-

Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	TH808WV-CS16-7M4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
4	Y	-
6	P	-
10	R	-
11	W	-
12	B	-
13	R	-
14	SHIELD	-
34	BE	-
35	R	-
36	B	-
37	P	-
52	R	-
53	BR	-
54	V	-
55	BE	-
56	Y	-
57	Y	-
63	V	-
64	LG	-
65	L	-
66	R	-
67	W	-
68	5B	-
70	BR	-
71	LG	-
72	V	-
73	L	-
76	R	-
78	B	-
79	W	-
80	L	-
83	Y	-
84	LG	-
85	P	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[HALOGEN TYPE]

## EXTERIOR LIGHTING SYSTEM

86	GE	-
87	SHIELD	-
88	P	-
89	B	-
90	GR	-
91	BR	-
92	BR	-
93	BR	-
94	P	-
95	GR	-
96	W	-
97	V	-
98	W	-
99	W	-
100	O	-

Connector No.	E107
Connector Name	WIRE TO WIRE
Connector Type	TRIZAKW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	V	-
3	G	-
4	G	-
5	O	- [Except for NISMO RS]
6	O	- [Except for NISMO RS]
7	R	-
8	SB	-
9	Y	- [For NISMO RS]
10	G	- [Except for NISMO RS]
11	L	-
12	Y	-
13	P	-
14	L	-
15	G	-
16	BE	-
17	BR	-
18	Y	-
19	G	-
20	B	-
21	W	-
22	R	-
23	SHIELD	-

Connector No.	E118
Connector Name	STOP LAMP SWITCH
Connector Type	MODFB-LC



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	R	-

Connector No.	F1
Connector Name	WIRE TO WIRE
Connector Type	5SA34FB-RS1D-S4Z2



Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	-
2	L	-
3	W	- [Except for NISMO RS]
4	Y	- [For NISMO RS]
5	GR	- [Except for NISMO RS]
6	GR	- [Except for NISMO RS]
7	G	-
8	G	-
9	R	-
10	R	- [Except for NISMO RS]
11	G	- [For NISMO RS]
12	Y	- [Except for NISMO RS]
13	B	-
14	B	- [Except for NISMO RS]
15	B	- [For NISMO RS]
16	L	-
17	V	-
18	V	- [Except for NISMO RS]
19	V	- [For NISMO RS]
20	W	-
21	L	-
22	R	-
23	SHIELD	-
24	SHIELD	-


15	P	-
17	SB	-
18	G	-
19	G	-
20	BR	-
21	GR	-
22	GR	- [For NISMO RS]
23	Y	- [Except for NISMO RS]
24	B	-
25	R	-
26	B	-
27	B	-
28	R	-
29	W	-
30	GR	- [Except for NISMO RS]
31	R	- [For NISMO RS]
32	LG	-
33	BR	-
34	G	- [For NISMO RS]
35	P	- [Except for NISMO RS]
36	GR	- [With Intelligent Key]
37	GR	- [Without Intelligent Key]
38	R	-
39	GR	-
40	P	-
41	BR	- [For NISMO RS]
42	V	- [Except for NISMO RS]
43	V	- [For NISMO RS]
44	W	- [Except for NISMO RS]
45	L	- [For NISMO RS]
46	W	- [Except for NISMO RS]
47	Y	-
48	GR	- [With Intelligent Key]
49	Y	- [Without Intelligent Key]

Connector No.	F27
Connector Name	TRANSMISSION RANGE SWITCH
Connector Type	RK08EG



Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	-
2	BR	-
3	LG	-
4	L	-
5	G	-
6	Y	-
7	W	-
8	V	-

Connector No.	F30
Connector Name	TRANSMISSION RANGE SWITCH
Connector Type	YD00GFB-H54



Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	-
2	BR	-
3	LG	-
4	SB	-
5	G	-
6	LG	-
7	W	-
8	BR	-

# EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[HALOGEN TYPE]

## EXTERIOR LIGHTING SYSTEM

Connector No.	149
Connector Name	PARK / NEUTRAL POSITION SWITCH
Connector Type	FEA03FG-LC




Terminal No.	Color Of Wire	Signal Name (Specification)
1	G	-
2	SB	-
3	BR	-

Connector No.	157
Connector Name	BACK-UP LAMP SWITCH
Connector Type	RM02FB




Terminal No.	Color Of Wire	Signal Name (Specification)
1	G	-
2	SB	-

Connector No.	1103
Connector Name	JOINT CONNECTOR-FB3
Connector Type	SEA23F#J




Terminal No.	Color Of Wire	Signal Name (Specification)
1	L	-
2	L	-
3	L	-
4	GR	-
5	GR	-
6	GR	-
7	SB	-
8	SB	-
10	SB	-
11	SB	-
13	Y	-
14	Y	-
15	Y	-
16	Y	-
18	LG	-
19	LG	-
20	GR	-
21	BR	-
22	BR	-
23	Y	-
24	BR	-

Connector No.	M4
Connector Name	DATA LINK CONNECTOR
Connector Type	BD31FW



Terminal No.	Color Of Wire	Signal Name (Specification)
4	B	-
5	B	-
6	L	-
7	W	-
8	LG	-
14	P	-
15	Y	-


Connector No.	M10
Connector Name	WIRE TO WIRE
Connector Type	TH40MW-CS15



Terminal No.	Color Of Wire	Signal Name (Specification)
1	R	-
2	G	-
3	SB	-
4	V	-
13	GR	-
14	GR	-
15	L	-
16	SHIELD	-
17	Y	-
18	G	-
19	L	-
24	R	-
25	G	-

38	Y	-
39	B	-
40	BR	-
41	Y	-
42	V	-
45	LG	-
46	BR	-
50	P	-

Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Type	TH40MW-CS15



Terminal No.	Color Of Wire	Signal Name (Specification)
1	GR	-
2	W	-
3	SB	-
4	V	-
6	R	-
8	G	-
10	Y	-
11	GR	-
12	GR	-
13	B	-
14	L	-
15	P	-
16	SHIELD	-
17	R	-
18	B	-
19	W	-
24	BR	-
25	Y	-
36	W	-
39	B	-
40	V	-
41	P	-
42	GR	-
43	V	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# EXTERIOR LIGHTING SYSTEM


< WIRING DIAGRAM >

[HALOGEN TYPE]

## EXTERIOR LIGHTING SYSTEM


44	P	-
45	G	-
46	Y	-
47	GR	-
48	L	-
49	R	-
50	LG	-
52	BR	-

Connector No. M18  
 Connector Name WIRE TO WIRE  
 Connector Type NS16FW-CS




Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	L	-
6	V	-
10	W	-
11	BR	-
12	V	-
14	Y	-
15	LG	-
16	L	-

Connector No. M19  
 Connector Name WIRE TO WIRE  
 Connector Type NS16FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	-
2	Y	-
4	W	-
7	V	-
9	BR	-
10	V	-
11	LG	-
12	V	-
13	R	-
14	G	-
15	L	-
16	G	-


Connector No. M27  
 Connector Name COMBINATION SWITCH  
 Connector Type TH16FW-AH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	WASHER (RR)
2	GR	OUTPUT 4
3	R	WASHER (FR)
4	W	IGN
5	BR	OUTPUT 3
6	B	GND
7	V	OUTPUT 3
8	L	OUTPUT 5

Connector No. M34  
 Connector Name COMBINATION METER  
 Connector Type TH16FW-AH

Terminal No.	Color Of Wire	Signal Name [Specification]
9	R	INPUT 2
10	Y	INPUT 4
11	P	INPUT 4
12	W	OUTPUT 1
13	LG	INPUT 5
14	G	OUTPUT 2



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	CANH
2	P	CANL
4	Y	VEHICLE SPEED SIGNAL (8-PULSE)
5	G	PADDLE SHIFTER UP SWITCH SIGNAL
6	BR	FUEL LEVEL SENSOR SIGNAL
7	R	AIR BAG SIGNAL
8	W	SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SEAT)
10	SP	PARKING BRAKE SWITCH SIGNAL
11	G	BRAKE FLUID LEVEL SWITCH SIGNAL
13	GR	ILLUMINATION CONTROL SIGNAL
14	R	MANUAL MODE SHIFT UP SIGNAL
15	L	ACC POWER SUPPLY
16	W	MANUAL MODE SHIFT DOWN SIGNAL
17	G	WASHER LEVEL SWITCH SIGNAL
18	R	SECURITY SIGNAL
19	GR	AMBIENT SENSOR SIGNAL
20	R	AMBIENT SENSOR GROUND
21	B	GROUND
22	B	GROUND
23	B	GROUND
24	L	FUEL LEVEL SENSOR GROUND
25	B	VDC GROUND
26	V	PADDLE SHIFTER DOWN SWITCH SIGNAL
27	LG	BATTERY POWER SUPPLY
28	GR	IGNITION SIGNAL
29	V	PASSENGER SEAT BELT WARNING SIGNAL
31	P	A/C AUTO APP. CONNECTION RECOGNITION SIGNAL


Connector No. M45  
 Connector Name HAZARD SWITCH  
 Connector Type TK04FW

35	Y	MANUAL MODE SIGNAL
37	G	NON-MANUAL MODE SIGNAL
38	P	ALTERNATOR SIGNAL



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
2	SB	-
3	V	-
4	GR	-

Connector No. M58  
 Connector Name BCM (BODY CONTROL MODULE)  
 Connector Type TH16FB-AH



Terminal No.	Color Of Wire	Signal Name [Specification]
2	L	COMBI SW INPUT 5
3	GR	COMBI SW INPUT 4
4	BR	COMBI SW INPUT 3
5	G	COMBI SW INPUT 2
6	W	COMBI SW INPUT 1
7	L	KEY CYL UNLOCK SW
8	R	KEY CYL LOCK SW
9	R	STOP LAMP SW 1
10	W	-
12	GR	DOOR LK & UNLK SW LOCK
13	BR	DOOR LK & UNLK SW UNLOCK

# EXTERIOR LIGHTING SYSTEM

[HALOGEN TYPE]

< WIRING DIAGRAM >

## EXTERIOR LIGHTING SYSTEM

14	SB	OPTICAL SENS
15	W	REAR WINDOW DEF SW
16	V	OPTICAL SENS PWR SPLY
18	V	REAR WASH AMP
21	P	WAS ANT AMP
22	R	SECURITY AND LAMP CONT
24	SB	DONGLE LINK
25	LG	WAS ANT AMP
26	BR	THERMO AMP
27	Y	A/C SW
28	LG	BLOWER FAN SW
29	SB	HAZARD SW
30	L	BK DOOR OPENER SW
31	GR	DR DOOR UNLK SENS
32	LG	COMBI SW OUTPUT 5
33	Y	COMBI SW OUTPUT 4
34	V	COMBI SW OUTPUT 3
35	R	COMBI SW OUTPUT 2
36	P	COMBI SW OUTPUT 1
37	G	DEFENT SW
38	SB	RECEIVER COMM
39	L	CANH
40	P	CANL

Connector No.	M69
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FE48PWH-FH4E-SA



Terminal No.	Color Of Wire	Signal Name [Specification]
56	P	INT ROOM LAMP PWR SPLY
57	P	BATT(FUSE)
59	SB	PASS DOOR UNLK OUTPUT
60	V	TURN SIG LH OUTPUT
61	W	TURN SIG RH OUTPUT
63	BR	INT ROOM LAMP CONT
64	R	REVERSE SW
65	V	ALL DOOR LOCK OUTPUT
66	SB	DR DOOR UNLK OUTPUT
67	B	GND
68	L	PWR PWR SPLY (IGN)

69	P	PWR PWR SPLY (BATT)
70	Y	BAT(FU)

Connector No.	M70
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40TW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
72	SB	A/C IND OUTPUT
75	LG	DR DOOR REQ SW
76	LG	PUSH SW
78	P	DRIVER DOOR ANT+
79	V	DRIVER DOOR ANT-
80	BR	PASS DOOR ANT+
81	G	PASS DOOR ANT-
82	W	REAR BRRP ANT+
83	B	REAR BRRP ANT-
84	BR	ROD ANT L+
85	GR	ROD ANT L-
86	V	ROD ANT R+
87	G	ROD ANT R-
89	W	PUSH SW (FOR M/T MODELS)
90	V	ACC COND SW
92	R	PUSH SW (IGN SW) ALL GND
93	GR	KEY WARN BUZZER
96	BR	ACC RELAY CONT
97	SB	STARTER RELAY CONT
98	P	IGN RELAY (IPDM/ER) CONT
99	R	IGN RELAY (F/B) CONT
100	P	PASS DOOR REQ SW
101	Y	CLUTCH INTERLOCK SW (FOR M/T MODELS)
101	Y	IGN SW (NOZ. EXCEPT FOR M/T MODELS)
102	L	NEUTRAL SW (FOR M/T MODELS)
102	L	P/N POSITION (EXCEPT FOR M/T MODELS)
103	G	FR DEFECT SW
104	SB	CVT SHIFT SELECT PWR SPLY
105	V	STOP LAMP SW 2
106	Y	BLWR RELAY CONT

Connector No.	M77
Connector Name	WIRE TO WIRE
Connector Type	TH88PWC-S16-TM4

Connector No.	M77
Connector Name	WIRE TO WIRE
Connector Type	TH88PWC-S16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	
4	V	
6	P	
10	R	
11	R	
12	LG	
13	V	
14	SHIELD	
34	LG	
35	SB	
36	B	
37	P	
52	R	
53	L	
54	SB	
55	P	
58	LG	
59	V	
62	Y	
63	W	
64	G	
65	GR	
66	Y	
67	V	
68	R	
70	V	
71	R	
72	GR	
73	G	
76	W	
78	LG	
79	V	
80	LG	
83	P	
84	G	
85	BR	

86	LG	
90	SHIELD	
91	V	
92	BR	
95	L	
96	L	
97	GR	
98	G	
99	R	
100	LG	

Connector No.	M84
Connector Name	OPTICAL SENSOR
Connector Type	TKG3FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	
2	SB	
3	V	

Connector No.	M103
Connector Name	PUSH-BUTTON IGNITION SWITCH
Connector Type	TKG8BB



Terminal No.	Color Of Wire	Signal Name [Specification]
3	G	
4	B	
5	W	
6	R	
7	V	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# EXTERIOR LIGHTING SYSTEM


< WIRING DIAGRAM >

[HALOGEN TYPE]

## EXTERIOR LIGHTING SYSTEM


8	LG	-
---	----	---

Connector No.	M132
Connector Name	JOINT CONNECTOR-M02
Connector Type	NH2DFL-DC



Terminal No.	Color Of Wire	Signal Name (Specification)
1	B	-
2	B	-
3	B	-
4	B	-
5	B	-
6	B	-
7	B	-
8	B	-
9	B	-
10	LG	-
11	LG	-
12	LG	-
13	LG	-
14	LG	-


Connector No.	M133
Connector Name	JOINT CONNECTOR-M04
Connector Type	NH2DFL-DC



Terminal No.	Color Of Wire	Signal Name (Specification)
1	P	-
2	P	-
3	P	-
5	P	-

7	P	-
11	L	-
12	L	-
13	L	-
15	L	-
17	L	-
18	W	-
19	W	-

Connector No.	M136
Connector Name	JOINT CONNECTOR-M07
Connector Type	NH2DFL-DC



Terminal No.	Color Of Wire	Signal Name (Specification)
1	P	-
2	P	-
3	P	-
4	P	-
5	P	-
6	P	-
7	P	-
8	P	-
10	L	-
11	L	-
12	L	-
13	L	-
14	L	-
15	L	-
16	L	-
17	L	-
18	GR	-
19	GR	-
20	GR	-

JRLWF5326GB

# DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[HALOGEN TYPE]


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000012201740

OVERALL SEQUENCE



DETAILED FLOW

# DIAGNOSIS AND REPAIR WORK FLOW

[HALOGEN TYPE]

< BASIC INSPECTION >

---

## 1. GET INFORMATION FOR SYMPTOM

---

1. Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurs).
2. Check operation condition of the function that is malfunctioning.

>> GO TO 2.

---

## 2. CHECK DTC

---

1. Check DTC.
2. Perform the following procedure if DTC is detected.
  - Record DTC and freeze frame data (Print them out using CONSULT.)
  - Erase DTC.
  - Study the relationship between the cause detected by DTC and the symptom described by the customer.
3. Check related service bulletins for information.

### Are any symptoms described and any DTC detected?

Symptom is described, DTC is detected>>GO TO 3.

Symptom is described, DTC is not detected>>GO TO 4.

Symptom is not described, DTC is detected>>GO TO 5.

---

## 3. CONFIRM THE SYMPTOM

---

Try to confirm the symptom described by the customer.

Also study the normal operation and fail-safe related to the symptom.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5.

---

## 4. CONFIRM THE SYMPTOM

---

Try to confirm the symptom described by the customer.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6.

---

## 5. PERFORM DTC CONFIRMATION PROCEDURE

---

Perform DTC CONFIRMATION PROCEDURE for the detected DTC, and then check that DTC is detected again. At this time, always connect CONSULT to the vehicle, and check self diagnostic results in real time. If two or more DTCs are detected, refer to DTC INSPECTION PRIORITY CHART, and determine trouble diagnosis order.

### **NOTE:**

- Freeze frame data is useful if the DTC is not detected.
- Perform Component Function Check if DTC CONFIRMATION PROCEDURE is not included on Service Manual. This simplified check procedure is an effective alternative though DTC cannot be detected during this check.

If the result of Component Function Check is NG, it is the same as the detection of DTC by DTC CONFIRMATION PROCEDURE.

### Is DTC detected?

YES >> GO TO 7.

NO >> Check according to [GI-45. "Intermittent Incident"](#).

---

## 6. DETECT MALFUNCTIONING SYSTEM BY SYMPTOM DIAGNOSIS

---

Detect malfunctioning system according to SYMPTOM DIAGNOSIS based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

### Is the symptom described?

YES >> GO TO 7.

NO >> Monitor input data from related sensors or check voltage of related module terminals using CONSULT.

---

## 7. DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

---



# DIAGNOSIS AND REPAIR WORK FLOW

[HALOGEN TYPE]

## < BASIC INSPECTION >

Inspect according to Diagnostic Procedure of the system.

Is malfunctioning part detected?

YES >> GO TO 8.

NO >> Check according to [GI-45. "Intermittent Incident"](#).

## 8. REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnostic Procedure again after repair and replacement.
3. Check DTC. If DTC is detected, erase it.

>> GO TO 9.

## 9. FINAL CHECK

When DTC is detected in step 2, perform DTC CONFIRMATION PROCEDURE again, and then check that the malfunction is repaired securely.

When symptom is described by the customer, refer to confirmed symptom in step 3 or 4, and check that the symptom is not detected.

Is DTC detected and does symptom remain?

YES-1 >> DTC is detected: GO TO 7.

YES-2 >> Symptom remains: GO TO 4.

NO >> Before returning the vehicle to the customer, always erase DTC.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

## DTC/CIRCUIT DIAGNOSIS

### HEADLAMP (HI) CIRCUIT

#### Component Function Check

INFOID:0000000012201741

#### 1. CHECK HEADLAMP (HI) OPERATION

With CONSULT

1. Turn ignition switch ON.
2. Select "EXTERNAL LAMPS" in "Active Test" mode of "IPDM E/R" using CONSULT.
3. With operating the test items, check that the headlamp (HI) blinks.

**Hi** : Headlamp (HI) blinks (ON/OFF is repeated 1 second each.)

**Off** : Headlamp (HI) OFF

Without CONSULT

1. Start IPDM E/R auto active test. Refer to [PCS-12, "Diagnosis Description"](#).
2. Check that the headlamp (HI) blinks.

Is the inspection result normal?

YES >> Headlamp (HI) circuit is normal.

NO >> Refer to [EXL-162, "Diagnosis Procedure"](#).

#### Diagnosis Procedure

INFOID:0000000012201742

#### 1. CHECK HEADLAMP (HI) FUSE

1. Turn ignition switch OFF.
2. Check that the following fuses are not blown (open).

Unit	Location	Fuse No.	Capacity
Headlamp HI (RH)	IPDM E/R	#51	10 A
Headlamp HI (LH)		#52	

Is the fuse blown (open)?

YES >> Replace the blown fuse after repairing the affected circuit if a fuse is blown (open).

NO >> GO TO 2.

#### 2. CHECK HEADLAMP (HI) POWER SUPPLY

With CONSULT

1. Turn ignition switch ON.
2. Select "EXTERNAL LAMPS" in "Active Test" mode of "IPDM E/R" using CONSULT.
3. With operating the test items, check voltage between IPDM E/R harness connector and ground.

+			-	Test item	Voltage	
IPDM E/R		Terminal				
Connector						
RH	E15	49	Ground	EXTERNAL LAMPS	Hi	9 – 16 V (Repeated 1 second)
					Off	0 – 1 V
LH		50			Hi	9 – 16 V (Repeated 1 second)
					Off	0 – 1 V

Is the inspection result normal?

YES >> GO TO 3.

# HEADLAMP (HI) CIRCUIT

[HALOGEN TYPE]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Replace IPDM E/R. Refer to [PCS-37, "Removal and Installation"](#).

## 3. CHECK HEADLAMP (HI) POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and headlamp connector.
3. Check continuity between IPDM E/R harness connector and headlamp harness connector.

IPDM E/R		Headlamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E15	E55	1	Existed
LH		49		
		E54		

Is the inspection result normal?

YES-1 >> Without daytime running light system: GO TO 4.

YES-2 >> NISMO models with daytime running light system: GO TO 4.

YES-3 >> Except for NISMO models with daytime running light system: GO TO 6.

NO >> Repair or replace harness.

## 4. CHECK HEADLAMP (HI) GROUND CIRCUIT

Check continuity between headlamp harness connector and ground.

Headlamp		—	Continuity	
Connector	Terminal			
RH	E55	3	Ground	Existed
LH	E54			

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness.

## 5. CHECK HEADLAMP (HI) BULB

Check the applicable headlamp (HI) bulb.

Is the inspection result normal?

YES >> Check the corresponding headlamp (HI) harness. Repair or replace if necessary.

NO >> Replace the corresponding headlamp (HI) bulb. Refer to [EXL-207, "Replacement"](#).

## 6. CHECK ILLUMINATION STATUS OF HEADLAMPS

Check illumination status of headlamps.

Which headlamp does not turn ON?

RH >> GO TO 7.

LH >> GO TO 11.

## 7. CHECK HEADLAMP (HI) RH GROUND CIRCUIT-1

1. Remove daytime running light relay.
2. Check continuity between headlamp harness connector and daytime running light relay harness connector.

Headlamp		Daytime running light relay		Continuity
Connector	Terminal	Connector	Terminal	
E55	3	E65	3	Existed

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair or replace harness.

## 8. CHECK HEADLAMP (HI) RH GROUND CIRCUIT-2

Check continuity between daytime running light relay harness connector and ground.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# HEADLAMP (HI) CIRCUIT

[HALOGEN TYPE]

< DTC/CIRCUIT DIAGNOSIS >

Daytime running light relay		—	Continuity
Connector	Terminal		
E65	4	Ground	Existed

Is the inspection result normal?

- YES >> GO TO 9.
- NO >> Repair or replace harness.

## 9.CHECK DAYTIME RUNNING LIGHT RELAY

Check daytime running light relay. Refer to [EXL-164, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 10.
- NO >> Replace daytime running light relay.

## 10.CHECK HEADLAMP (HI) RH BULB

Check the headlamp (HI) RH bulb.

Is the inspection result normal?

- YES >> Check the headlamp (HI) RH harness. Repair or replace if necessary.
- NO >> Replace headlamp (HI) RH bulb. Refer to [EXL-207, "Replacement"](#).

## 11.CHECK HEADLAMP (HI) LH GROUND CIRCUIT

Check continuity between headlamp harness connector and ground.

Headlamp		—	Continuity
Connector	Terminal		
E54	3	Ground	Existed

Is the inspection result normal?

- YES >> GO TO 12.
- NO >> Repair or replace harness.

## 12.CHECK HEADLAMP (HI) LH BULB

Check the headlamp (HI) LH bulb.

Is the inspection result normal?

- YES >> Check the headlamp (HI) LH harness. Repair or replace if necessary.
- NO >> Replace headlamp (HI) LH bulb. Refer to [EXL-207, "Replacement"](#).

## Component Inspection

INFOID:0000000012201743

## 1.CHECK DAYTIME RUNNING LIGHT RELAY

1. Turn ignition switch OFF.
2. Remove daytime running light relay.
3. Apply battery voltage to daytime running light relay between terminals 2 and 1.
4. Check continuity of daytime running light relay terminals.

Daytime running light relay		Condition		Continuity
Terminal				
3	4	Battery voltage	Apply	Not existed
			Not apply	Existed

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> Replace daytime running light relay.

# HEADLAMP (LO) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN TYPE]

## HEADLAMP (LO) CIRCUIT

### Component Function Check

INFOID:000000012201744

#### 1. CHECK HEADLAMP (LO) OPERATION

With CONSULT

1. Turn ignition switch ON.
2. Select "EXTERNAL LAMPS" in "Active Test" mode of "IPDM E/R" using CONSULT.
3. With operating the test items, check that the headlamp (LO) is turned ON.

**Lo** : Headlamp (LO) ON

**Off** : Headlamp (LO) OFF

Without CONSULT

1. Start IPDM E/R auto active test. Refer to [PCS-12, "Diagnosis Description"](#).
2. Check that the headlamp (LO) is turned ON.

Is the inspection result normal?

YES >> Headlamp (LO) circuit is normal.

NO >> Refer to [EXL-165, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000012201745

#### 1. CHECK HEADLAMP (LO) FUSE

1. Turn ignition switch OFF.
2. Check that the following fuses are not blown (open).

Unit	Location	Fuse No.	Capacity
Headlamp LO (RH)	IPDM E/R	#54	15 A
Headlamp LO (LH)		#53	

Is the fuse blown (open)?

YES >> Replace the blown fuse after repairing the affected circuit if a fuse is blown (open).

NO >> GO TO 2.

#### 2. CHECK HEADLAMP (LO) POWER SUPPLY

With CONSULT

1. Turn ignition switch ON.
2. Select "EXTERNAL LAMPS" in "Active Test" mode of "IPDM E/R" using CONSULT.
3. With operating the test items, check voltage between IPDM E/R harness connector and ground.

+		Terminal	-	Test item	Voltage		
IPDM E/R							
Connector		Terminal					
RH	E15	52	Ground	EXTERNAL LAMPS	LO	9 – 16 V	
						Off	0 – 1 V
LH		51				LO	9 – 16 V
						Off	0 – 1 V

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace IPDM E/R. Refer to [PCS-37, "Removal and Installation"](#).

#### 3. CHECK HEADLAMP (LO) POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and headlamp connector.
3. Check continuity between IPDM E/R harness connector and headlamp harness connector.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# HEADLAMP (LO) CIRCUIT

[HALOGEN TYPE]

< DTC/CIRCUIT DIAGNOSIS >

IPDM E/R		Headlamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E15	E55	4	Existed
LH		51		

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

## 4.CHECK HEADLAMP (LO) GROUND CIRCUIT

Check continuity between headlamp harness connector and ground.

Headlamp		Terminal	—	Continuity
Connector	Terminal			
RH	E55	2	Ground	Existed
LH	E54			

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness.

## 5.CHECK HEADLAMP (LO) BULB

Check the applicable headlamp (LO) bulb.

Is the inspection result normal?

YES >> Check the corresponding headlamp (LO) harness. Repair or replace if necessary.

NO >> Replace the corresponding headlamp (LO) bulb. Refer to [EXL-207, "Replacement"](#).

# PARKING LAMP CIRCUIT

[HALOGEN TYPE]

< DTC/CIRCUIT DIAGNOSIS >

## PARKING LAMP CIRCUIT

### Component Function Check

INFOID:000000012201746

#### 1. CHECK TAIL LAMP OPERATION

Check that the tail lamp is turned ON.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check tail lamp circuit. Refer to [EXL-171, "Component Function Check"](#).

#### 2. CHECK PARKING LAMP OPERATION

With CONSULT

1. Turn ignition switch ON.
2. Select "EXTERNAL LAMPS" in "Active Test" mode of "IPDM E/R" using CONSULT.
3. With operating the test items, check that the parking lamp is turned ON.

**TAIL : Parking lamp ON**  
**Off : Parking lamp OFF**

Without CONSULT

1. Start IPDM E/R auto active test. Refer to [PCS-12, "Diagnosis Description"](#).
2. Check that the parking lamp is turned ON.

Is the inspection result normal?

YES >> Parking lamp circuit is normal.

NO >> Refer to [EXL-167, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000012201747

#### 1. CHECK PARKING LAMP POWER SUPPLY

With CONSULT

1. Turn ignition switch ON.
2. Select "EXTERNAL LAMPS" in "Active Test" mode of "IPDM E/R" using CONSULT.
3. With operating the test items, check voltage between IPDM E/R harness connector and ground.

+		-	Test item	Voltage	
IPDM E/R					
Connector	Terminal				
E14	43	Ground	EXTERNAL LAMPS	TAIL	9 – 16 V
				Off	0 – 1 V

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace IPDM E/R. Refer to [PCS-37, "Removal and Installation"](#).

#### 2. CHECK PARKING LAMP POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and parking lamp connector.
3. Check continuity between IPDM E/R harness connector and parking lamp harness connector.

IPDM E/R			Parking lamp		Continuity
Connector	Terminal		Connector	Terminal	
RH	E14	43	E44	1	Existed
LH			E28		

Is the inspection result normal?

YES >> GO TO 3.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

## PARKING LAMP CIRCUIT

[HALOGEN TYPE]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair or replace harness.

### 3. CHECK PARKING LAMP GROUND CIRCUIT

Check continuity between parking lamp harness connector and ground.

Parking lamp		Terminal	—	Continuity
Connector				
RH	E44	2	Ground	Existed
LH	E28			

Is the inspection result normal?

YES >> Replace the corresponding front combination lamp. Refer to [EXL-211, "Removal and Installation"](#).

NO >> Repair or replace harness.



# FRONT SIDE MARKER LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN TYPE]

## FRONT SIDE MARKER LAMP CIRCUIT

### Component Function Check

INFOID:000000012201748

#### 1. CHECK PARKING LAMP OPERATION

Check that the parking lamp is turned ON.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check parking lamp circuit. Refer to [EXL-167, "Component Function Check"](#).

#### 2. CHECK FRONT SIDE MARKER LAMP OPERATION

With CONSULT

1. Turn ignition switch ON.
2. Select "EXTERNAL LAMPS" in "Active Test" mode of "IPDM E/R" using CONSULT.
3. With operating the test items, check that the front side marker lamp is turned ON.

**TAIL : Front side marker lamp ON**

**Off : Front side marker lamp OFF**

Without CONSULT

1. Start IPDM E/R auto active test. Refer to [PCS-12, "Diagnosis Description"](#).
2. Check that the front side marker lamp is turned ON.

Is the inspection result normal?

YES >> Front side marker lamp circuit is normal.

NO >> Refer to [EXL-169, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000012201749

#### 1. CHECK FRONT SIDE MARKER LAMP POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and front side marker lamp connector.
3. Check continuity between IPDM E/R harness connector and front side marker lamp harness connector.

IPDM E/R		Front side marker lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E14	43	E32	Existed
LH			E31	

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness.

#### 2. CHECK FRONT SIDE MARKER LAMP GROUND CIRCUIT

Check continuity between front side marker lamp harness connector and ground.

Front side marker lamp		Terminal	Continuity
Connector	Terminal		
RH	E32	2	Existed
LH	E31		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

#### 3. CHECK FRONT SIDE MARKER LAMP BULB

Check the applicable front side marker lamp bulb.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

## FRONT SIDE MARKER LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN TYPE]

---

Is the inspection result normal?

- YES >> Check the corresponding front side marker lamp bulb socket. Repair or replace if necessary.
- NO >> Replace the corresponding front side marker lamp bulb. Refer to [EXL-211. "Replacement"](#).

# TAIL LAMP CIRCUIT

[HALOGEN TYPE]

< DTC/CIRCUIT DIAGNOSIS >

## TAIL LAMP CIRCUIT

### Component Function Check

INFOID:0000000012201750

#### 1.CHECK TAIL LAMP OPERATION

With CONSULT

1. Turn ignition switch ON.
2. Select "EXTERNAL LAMPS" in "Active Test" mode of "IPDM E/R" using CONSULT.
3. With operating the test items, check that the tail lamp is turned ON.

**TAIL** : Tail lamp ON  
**Off** : Tail lamp OFF

Without CONSULT

1. Start IPDM E/R auto active test. Refer to [PCS-12. "Diagnosis Description"](#).
2. Check that the tail lamp is turned ON.

Is the inspection result normal?

- YES >> Tail lamp circuit is normal.  
 NO >> Refer to [EXL-171. "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000012201751

#### 1.CHECK FUSE

1. Turn ignition switch OFF.
2. Check that the following fuse is not blown (open).

Unit	Location	Fuse No.	Capacity
<ul style="list-style-type: none"> <li>• Parking lamp RH</li> <li>• Parking lamp LH</li> <li>• Front side marker lamp RH</li> <li>• Front side marker lamp LH</li> <li>• Tail lamp RH</li> <li>• Tail lamp LH</li> <li>• License plate lamp RH</li> <li>• License plate lamp LH</li> </ul>	IPDM E/R	#47	10 A

Is the fuse blown (open)?

- YES >> Replace the blown fuse after repairing the affected circuit if a fuse is blown (open).  
 NO >> GO TO 2.

#### 2.CHECK TAIL LAMP POWER SUPPLY

With CONSULT

1. Turn ignition switch ON.
2. Select "EXTERNAL LAMPS" in "Active Test" mode of "IPDM E/R" using CONSULT.
3. With operating the test items, check voltage between IPDM E/R harness connector and ground.

+		-	Test item	Voltage	
IPDM E/R					
Connector	Terminal				
E14	44	Ground	EXTERNAL LAMPS	TAIL	9 – 16 V
				Off	0 – 1 V

Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> Replace IPDM E/R. Refer to [PCS-37. "Removal and Installation"](#).

#### 3.CHECK TAIL LAMP POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

EXL

## TAIL LAMP CIRCUIT

[HALOGEN TYPE]

< DTC/CIRCUIT DIAGNOSIS >

2. Disconnect IPDM E/R connector and rear combination lamp connector.
3. Check continuity between IPDM E/R harness connector and rear combination lamp harness connector.

IPDM E/R			Rear combination lamp		Continuity
Connector		Terminal	Connector	Terminal	
RH	E14	44	B59	2	Existed
LH			B80		

Is the inspection result normal?

- YES >> GO TO 4.  
 NO >> Repair or replace harness.

### 4. CHECK TAIL LAMP GROUND CIRCUIT

Check continuity between rear combination lamp harness connector and ground.

Rear combination lamp			—	Continuity
Connector		Terminal		
RH	B59	3	Ground	Existed
LH	B80			

Is the inspection result normal?

- YES-1 >> Stop lamp / tail lamp (Bulb side): GO TO 5.  
 YES-2 >> Tail lamp (LED side): Check the corresponding tail lamp harness, and if check result is normal, replace the corresponding rear combination lamp. Refer to [EXL-220. "Removal and Installation"](#).  
 NO >> Repair or replace harness.

### 5. CHECK STOP LAMP / TAIL LAMP BULB

Check the applicable stop lamp / tail lamp bulb.

Is the inspection result normal?

- YES >> Check the corresponding stop lamp / tail lamp bulb socket and harness. Repair or replace if necessary.  
 NO >> Repair or replace the corresponding stop lamp / tail lamp bulb. Refer to [EXL-220. "Replacement"](#).

# LICENSE PLATE LAMP CIRCUIT

[HALOGEN TYPE]

< DTC/CIRCUIT DIAGNOSIS >

## LICENSE PLATE LAMP CIRCUIT

### Component Function Check

INFOID:000000012201752

#### 1. CHECK TAIL LAMP OPERATION

Check that the tail lamp is turned ON.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check tail lamp circuit. Refer to [EXL-171, "Component Function Check"](#).

#### 2. CHECK LICENSE PLATE LAMP OPERATION

With CONSULT

1. Turn ignition switch ON.
2. Select "EXTERNAL LAMPS" in "Active Test" mode of "IPDM E/R" using CONSULT.
3. With operating the test items, check that the license plate lamp is turned ON.

**TAIL : License plate lamp ON**

**Off : License plate lamp OFF**

Without CONSULT

1. Start IPDM E/R auto active test. Refer to [PCS-12, "Diagnosis Description"](#).
2. Check that the license plate lamp is turned ON.

Is the inspection result normal?

YES >> License plate lamp circuit is normal.

NO >> Refer to [EXL-173, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000012201753

#### 1. CHECK LICENSE PLATE LAMP POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and back door opener switch connector.
3. Check continuity between IPDM E/R harness connector and back door opener switch harness connector.

IPDM E/R		Back door opener switch		Continuity
Connector	Terminal	Connector	Terminal	
E14	44	D107	5	Existed

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness.

#### 2. CHECK LICENSE PLATE LAMP GROUND CIRCUIT

Check continuity between back door opener switch harness connector and ground.

Back door opener switch		—	Continuity
Connector	Terminal		
D107	6	Ground	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

#### 3. CHECK LICENSE PLATE LAMP BULB

Check the applicable license plate lamp bulb.

Is the inspection result normal?

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

## LICENSE PLATE LAMP CIRCUIT

[HALOGEN TYPE]

< DTC/CIRCUIT DIAGNOSIS >

---

- YES >> Check the corresponding license plate lamp bulb socket and harness. Repair or replace if necessary.
- NO >> Replace the corresponding license plate lamp bulb. Refer to [EXL-224, "Replacement"](#).

# DAYTIME RUNNING LIGHT RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN TYPE]

## DAYTIME RUNNING LIGHT RELAY CIRCUIT

### Component Function Check

INFOID:000000012201754

#### 1. CHECK DAYTIME RUNNING LIGHT OPERATION

Ⓜ With CONSULT

1. Select "HEAD LAMP" of "BCM" using CONSULT.
2. Select "DAYTIME RUNNING LIGHT" in "Active Test" mode.
3. With operating the test items, check that the daytime running light is turned ON [Headlamp (HI) at approximately half illumination].

**On** : Daytime running light ON [Headlamp (HI) at approximately half illumination]

**Off** : Daytime running light OFF

Is the inspection result normal?

- YES >> Daytime running light relay circuit is normal.  
 NO >> Refer to [EXL-175, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000012201755

#### 1. CHECK DAYTIME RUNNING LIGHT RELAY FUSE

1. Turn ignition switch OFF.
2. Check that the following fuses are not blown (open).

Unit	Fuse No.	Capacity
Daytime running light relay	#24	10 A

Is the fuse blown (open)?

- YES >> Replace the blown fuse after repairing the affected circuit if a fuse is blown (open).  
 NO >> GO TO 2.

#### 2. CHECK DAYTIME RUNNING LIGHT RELAY POWER SUPPLY

1. Remove daytime running light relay.
2. Check voltage between daytime running light relay harness connector and ground.

+		-	Voltage (Approx.)
Connector	Terminal		
E65	1	Ground	Battery voltage
	5		

Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> Repair or replace harness.

#### 3. CHECK DAYTIME RUNNING LIGHT RELAY

Check daytime running light relay. Refer to [EXL-176, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 4.  
 NO >> Replace daytime running light relay.

#### 4. CHECK DAYTIME RUNNING LIGHT RELAY CONTROL SIGNAL

Ⓜ With CONSULT

1. Install daytime running light relay.
2. Turn ignition switch ON.
3. Select "HEAD LAMP" of "BCM" using CONSULT.
4. Select "DAYTIME RUNNING LIGHT" in "Active Test" mode.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# DAYTIME RUNNING LIGHT RELAY CIRCUIT

[HALOGEN TYPE]

< DTC/CIRCUIT DIAGNOSIS >

- With operating the test item, check voltage between IPDM E/R harness connector and ground.

+		-	Test item	Voltage	
IPDM E/R					
Connector	Terminal				
E13	28	Ground	DAYTIME RUNNING LIGHT	On	0 – 1 V
			Off	9 – 16 V	

Is the inspection result normal?

- YES >> Daytime running light relay circuit is normal.  
 NO-1 >> Fixed at 0 – 1 V: GO TO 6.  
 NO-2 >> Fixed at 9 – 16 V: GO TO 5.

## 5.CHECK DAYTIME RUNNING LIGHT REQUEST SIGNAL

④With CONSULT

- Select "DTRL REQ" in "Data Monitor" mode of "IPDM E/R" using CONSULT.
- With operating the daytime running light ON condition, check the monitor status.

Monitor item	Condition		Monitor status
DTRL REQ	Daytime running light	ON condition	On
		OFF condition	Off

Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-37, "Removal and Installation"](#).  
 NO >> Replace BCM. Refer to [BCS-94, "Removal and Installation"](#).

## 6.CHECK DAYTIME RUNNING LIGHT RELAY CONTROL SIGNAL CIRCUIT

- Turn ignition switch OFF.
- Remove daytime running light relay.
- Disconnect IPDM E/R harness connector.
- Check continuity between IPDM E/R harness connector and daytime running light relay harness connector.

IPDM E/R		Daytime running light relay		Continuity
Connector	Terminal	Connector	Terminal	
E13	28	E65	2	Existed

Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-37, "Removal and Installation"](#).  
 NO >> Repair or replace harness.

## Component Inspection

INFOID:000000012201756

### 1.CHECK DAYTIME RUNNING LIGHT RELAY

- Turn ignition switch OFF.
- Remove daytime running light relay.
- Apply battery voltage to daytime running light relay between terminals 1 and 2.
- Check continuity of daytime running light relay terminals.

Daytime running light relay		Condition	Continuity	
Terminal				
5	3	Battery voltage	Apply	Existed
		Not apply	Not existed	

Is the inspection result normal?

- YES >> INSPECTION END



# DAYTIME RUNNING LIGHT RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN TYPE]

NO >> Replace daytime running light relay.

A

B

C

D

E

F

G

H

I

J

K

**EXL**

M

N

O

P

# DAYTIME RUNNING LIGHT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN TYPE]

## DAYTIME RUNNING LIGHT CIRCUIT

### Component Function Check

INFOID:000000012201757

#### 1. CHECK DAYTIME RUNNING LIGHT OPERATION

With CONSULT

1. Select "EXTERNAL LAMPS" in "Active Test" mode of "IPDM E/R" using CONSULT.
2. With operating the test items, check that the daytime running light is turned ON.

**Fog : Daytime running light ON**

**Off : Daytime running light OFF**

Without CONSULT

1. Start IPDM E/R auto active test. Refer to [PCS-12, "Diagnosis Description"](#).
2. Check that the daytime running light is turned ON.

Is the measurement normal?

YES >> Daytime running light circuit is normal.

NO >> Refer to [EXL-178, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000012201758

#### 1. CHECK DAYTIME RUNNING LIGHT FUSE

1. Turn ignition switch OFF.
2. Check that the following fuse is not blown (open).

Unit	Location	Fuse No.	Capacity
Daytime running light	IPDM E/R	#50	15 A

Is the fuse blown (open)?

YES >> Replace the blown fuse after repairing the affected circuit if a fuse is blown (open).

NO >> GO TO 2.

#### 2. CHECK DAYTIME RUNNING LIGHT POWER SUPPLY

With CONSULT

1. Turn ignition switch ON.
2. Select "EXTERNAL LAMPS" in "Active Test" mode of "IPDM E/R" using CONSULT.
3. With operating the test items, check the voltage between IPDM E/R harness connector and ground.

+		Terminal	-	Test item	Voltage		
IPDM E/R							
Connector							
RH	E12	19	Ground	EXTERNAL LAMPS	Fog	9 – 16 V	
						Off	0 – 1 V
LH		20				Fog	9 – 16 V
						Off	0 – 1 V

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace IPDM E/R. Refer to [PCS-37, "Removal and Installation"](#).

#### 3. CHECK DAYTIME RUNNING LIGHT POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and daytime running light connector.
3. Check continuity between IPDM E/R harness connector and daytime running light harness connector.

# DAYTIME RUNNING LIGHT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN TYPE]

IPDM E/R		Daytime running light		Continuity
Connector	Terminal	Connector	Terminal	
RH	E12	19	E75	Existed
LH		20	E76	

A

B

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

C

## 4. CHECK DAYTIME RUNNING LIGHT GROUND CIRCUIT

Check continuity between daytime running light harness connector and ground.

D

Daytime running light		Terminal	—	Continuity
Connector	Terminal			
RH	E75	2	Ground	Existed
LH	E76			

E

F

Is the inspection result normal?

YES >> Replace the corresponding daytime running light. Refer to [EXL-212. "Removal and Installation"](#).

NO >> Repair or replace harness.

G

H

I

J

K

EXL

M

N

O

P

# FRONT FOG LAMP CIRCUIT

[HALOGEN TYPE]

< DTC/CIRCUIT DIAGNOSIS >

## FRONT FOG LAMP CIRCUIT

### Component Function Check

INFOID:000000012201759

#### 1. CHECK FRONT FOG LAMP OPERATION

Ⓜ With CONSULT

1. Select "EXTERNAL LAMPS" in "Active Test" mode of "IPDM E/R" using CONSULT.
2. With operating the test items, check that the front fog lamp is turned ON.

**Fog** : Front fog lamp ON  
**Off** : Front fog lamp OFF

ⓧ Without CONSULT

1. Start IPDM E/R auto active test. Refer to [PCS-12, "Diagnosis Description"](#).
2. Check that the front fog lamp is turned ON.

Is the measurement normal?

- YES >> Front fog lamp circuit is normal.  
NO >> Refer to [EXL-180, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000012201760

#### 1. CHECK FRONT FOG LAMP FUSE

1. Turn ignition switch OFF.
2. Check that the following fuses are not blown (open).

Unit	Location	Fuse No.	Capacity
Front fog lamp	IPDM E/R	#50	15 A

Is the fuse blown (open)?

- YES >> Replace the blown fuse after repairing the affected circuit if a fuse is blown (open).  
NO >> GO TO 2.

#### 2. CHECK FRONT FOG LAMP POWER SUPPLY

Ⓜ With CONSULT

1. Disconnect front fog lamp connector.
2. Turn ignition switch ON.
3. Select "EXTERNAL LAMPS" in "Active Test" mode of "IPDM E/R" using CONSULT.
4. With operating the test items, check the voltage between IPDM E/R harness connector and ground.

+		-	Test item	Voltage			
IPDM E/R							
Connector	Terminal	Ground	EXTERNAL LAMPS				
RH	E12				19	Fog	9 – 16 V
						Off	0 – 1 V
LH	E12				20	Fog	9 – 16 V
			Off	0 – 1 V			

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Replace IPDM E/R. Refer to [PCS-37, "Removal and Installation"](#).

#### 3. CHECK FRONT FOG LAMP POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and front fog lamp harness connector.

# FRONT FOG LAMP CIRCUIT

[HALOGEN TYPE]

< DTC/CIRCUIT DIAGNOSIS >

IPDM E/R		Front fog lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E12	19	E48	Existed
LH		20	E30	

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

## 4. CHECK FRONT FOG LAMP GROUND CIRCUIT

Check continuity between front fog lamp harness connector and ground.

Front fog lamp		Terminal	—	Continuity
Connector	Terminal			
RH	E48	2	Ground	Existed
LH	E30			

Is the inspection result normal?

YES >> Replace the corresponding front fog lamp bulb. Refer to [EXL-214, "Replacement"](#).

NO >> Repair or replace harness.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# TURN SIGNAL LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN TYPE]

## TURN SIGNAL LAMP CIRCUIT

### Component Function Check

INFOID:0000000012201761

#### 1. CHECK TURN SIGNAL LAMP OPERATION

④ With CONSULT

1. Turn ignition switch ON.
2. Select "FLASHER" of "BCM" using CONSULT.
3. Select "FLASHER" in "Active Test" mode.
4. With operating the test items, check that the turn signal lamps is turned ON.

**RH : Turn signal lamps (RH) ON**

**LH : Turn signal lamps (LH) ON**

**Off : Turn signal lamps OFF**

Is the inspection result normal?

YES >> Turn signal lamp circuit is normal.

NO >> Refer to [EXL-182, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000012201762

#### 1. CHECK TURN SIGNAL LAMP POWER SUPPLY

④ With CONSULT

1. Turn ignition switch OFF.
2. Disconnect the following connectors.
  - Front turn signal lamp
  - Door mirror
  - Rear combination lamp
3. Turn ignition switch ON.
4. Select "FLASHER" of "BCM" using CONSULT.
5. Select "FLASHER" in "Active Test" mode.
6. With operating the test items, check voltage between BCM harness connector and ground.

+			-	Test item	Voltage		
BCM							
Connector	Terminal						
RH	M69	61	Ground	FLASHER	RH	9 – 16 V	
						Off	0 V
LH		60				LH	9 – 16 V
						Off	0 V

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

#### 2. CHECK TURN SIGNAL LAMP POWER SUPPLY CIRCUIT (SHORT)

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and ground.

BCM			—	Continuity
Connector	Terminal			
RH	M69	61	Ground	Not existed
LH				

Is the inspection result normal?

# TURN SIGNAL LAMP CIRCUIT

[HALOGEN TYPE]

< DTC/CIRCUIT DIAGNOSIS >

YES >> Replace BCM. Refer to [BCS-94. "Removal and Installation"](#).

NO >> Repair or replace harness.

## 3. CHECK TURN SIGNAL LAMP POWER SUPPLY CIRCUIT (OPEN)

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and each turn signal lamp harness connector.

Front turn signal lamp

BCM			Front turn signal lamp		Continuity
Connector		Terminal	Connector	Terminal	
RH	M69	61	E47	1	Existed
LH		60	E34		

Side turn signal lamp

BCM			Door mirror		Continuity
Connector		Terminal	Connector	Terminal	
RH	M69	61	D9	13	Existed
LH		60	D30		

Rear turn signal lamp

BCM			Rear combination lamp		Continuity
Connector		Terminal	Connector	Terminal	
RH	M69	61	B59	5	Existed
LH		60	B80		

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

## 4. CHECK TURN SIGNAL LAMP GROUND CIRCUIT

Check continuity between each turn signal lamp harness connector and ground.

Front turn signal lamp

Front turn signal lamp			—	Continuity
Connector		Terminal		
RH	E47	2	Ground	Existed
LH				

Side turn signal lamp

Door mirror			—	Continuity
Connector		Terminal		
RH	D9	2	Ground	Existed
LH				

Rear turn signal lamp

Rear combination lamp			—	Continuity
Connector		Terminal		
RH	B59	3	Ground	Existed
LH				

Is the inspection result normal?

YES-1 >> Front turn signal lamp or rear turn signal lamp: GO TO 5.

YES-2 >> Side turn signal lamp: Replace the corresponding side turn signal lamp. Refer to [EXL-215. "Removal and Installation"](#).

NO >> Repair or replace harness.

## TURN SIGNAL LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN TYPE]

---

### 5. CHECK TURN SIGNAL LAMP BULB

---

Check the applicable turn signal lamp bulb.

Is the inspection result normal?

- YES-1 >> Front turn signal lamp: Check the corresponding front turn signal lamp bulb socket. Repair or replace if necessary.
- YES-2 >> Rear turn signal lamp: Check the corresponding rear turn signal lamp bulb socket and harness. Repair or replace if necessary.
- NO >> Replace the corresponding turn signal lamp bulb. Refer to [EXL-211. "Replacement"](#) (front turn signal lamp) or [EXL-220. "Replacement"](#) (rear turn signal lamp).



OPTICAL SENSOR

Component Function Check

INFOID:000000012201763

1.CHECK OPTICAL SENSOR SIGNAL

Ⓜ With CONSULT

1. Turn ignition switch ON.
2. Select "HEAD LAMP" of "BCM" using CONSULT.
3. Select "OPTI SEN (DTCT)" in "Data Monitor" mode.
4. Turn lighting switch AUTO.
5. With the optical sensor illuminating, check the monitor status.

Monitor item	Condition		Voltage (Approx.)
OPTI SEN (DTCT)	Optical sensor	When illuminating	3.1 V or more *
		When shutting off light	0.6 V or less

\*: Illuminates the optical sensor. The value may be less than the standard value if brightness is weak.

Is the inspection result normal?

- YES >> Optical sensor is normal.  
 NO >> Refer to [EXL-185, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000012201764

1.CHECK OPTICAL SENSOR POWER SUPPLY

1. Turn ignition switch ON.
2. Turn lighting switch AUTO.
3. Check voltage between optical sensor harness connector and ground.

+			Voltage (Approx.)
Optical sensor			
Connector	Terminal		
M84	1	Ground	5 V

Is the inspection result normal?

- YES >> GO TO 2.  
 NO >> GO TO 4.

2.CHECK OPTICAL SENSOR GROUND

Check voltage between optical sensor harness connector and ground.

+			Voltage (Approx.)
Optical sensor			
Connector	Terminal		
M84	3	Ground	0 V

Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> GO TO 6.

3.CHECK OPTICAL SENSOR SIGNAL

With illuminating the optical sensor, check voltage between optical sensor harness connector and ground.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

EXL

# OPTICAL SENSOR

[HALOGEN TYPE]

< DTC/CIRCUIT DIAGNOSIS >

+		-	Condition		Voltage (Approx.)
Optical sensor					
Connector	Terminal				
M84	2	Ground	Optical sensor	When illuminating	3.1 V or more*
				When shutting off light	0.6 V or less

\*: Illuminate the optical sensor. The value may be less than the standard if brightness is weak.

Is the inspection result normal?

YES >> GO TO 7.

NO >> Replace optical sensor. Refer to [EXL-216. "Removal and Installation"](#).

## 4. CHECK OPTICAL SENSOR POWER SUPPLY CIRCUIT (OPEN)

1. Turn ignition switch OFF.
2. Disconnect optical sensor connector and BCM connector.
3. Check continuity between optical sensor harness connector and BCM harness connector.

Optical sensor		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M84	1	M68	17	Existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness.

## 5. CHECK OPTICAL SENSOR POWER SUPPLY CIRCUIT (SHORT)

Check continuity between optical sensor harness connector and ground.

Optical sensor		—	Continuity
Connector	Terminal		
M84	1	Ground	Not existed

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-94. "Removal and Installation"](#).

NO >> Repair or replace harness.

## 6. CHECK OPTICAL SENSOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect optical sensor connector and BCM connector.
3. Check continuity between optical sensor harness connector and BCM harness connector.

Optical sensor		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M84	3	M68	18	Existed

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-94. "Removal and Installation"](#).

NO >> Repair or replace harness.

## 7. CHECK OPTICAL SENSOR SIGNAL CIRCUIT (OPEN)

1. Turn ignition switch OFF.
2. Disconnect optical sensor connector and BCM connector.
3. Check continuity between optical sensor harness connector and BCM harness connector.

# OPTICAL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN TYPE]

Optical sensor		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M84	2	M68	14	Existed

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair or replace harness.

## 8. CHECK OPTICAL SENSOR SIGNAL CIRCUIT (SHORT)

Check continuity between optical sensor harness connector and ground.

Optical sensor		—	Continuity
Connector	Terminal		
M84	2	Ground	Not existed

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-94, "Removal and Installation"](#).

NO >> Repair or replace harness.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

## HAZARD SWITCH

## Component Function Check

INFOID:000000012201765

## 1.CHECK HAZARD SWITCH SIGNAL

## ④ With CONSULT

1. Turn ignition switch ON.
2. Select "FLASHER" of "BCM" using CONSULT.
3. Select "HAZARD SW" in "Data Monitor" mode.
4. With operating the hazard switch, check the monitor status.

Monitor item	Condition		Monitor status
HAZARD SW	Hazard switch	ON	On
		OFF	Off

Is the inspection result normal?

- YES >> Hazard switch circuit is normal.  
 NO >> Refer to [EXL-188, "Diagnosis Procedure"](#).

## Diagnosis Procedure

INFOID:000000012201766

## 1.CHECK HAZARD SWITCH SIGNAL

1. Turn ignition switch OFF.
2. Disconnect hazard switch connector.
3. Check voltage between hazard switch connector and ground.

+		-	Voltage (Approx.)
Hazard switch			
Connector	Terminal	Ground	12 V
M45	2		

Is the inspection result normal?

- YES >> GO TO 4.  
 NO >> GO TO 2.

## 2.CHECK HAZARD SWITCH SIGNAL CIRCUIT (OPEN)

1. Disconnect BCM connector.
2. Check continuity between hazard switch harness connector and BCM harness connector.

Hazard switch		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M45	2	M68	29	Existed

Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> Repair or replace harness.

## 3.CHECK HAZARD SWITCH SIGNAL CIRCUIT (SHORT)

Check continuity between hazard switch harness connector and ground.

Hazard switch		—	Continuity
Connector	Terminal		
M45	2	Ground	Not existed

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-94, "Removal and Installation"](#).

# HAZARD SWITCH

[HALOGEN TYPE]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair or replace harness.

## 4. CHECK HAZARD SWITCH GROUND CIRCUIT

Check continuity between hazard switch harness connector and ground.

Hazard switch		—	Continuity
Connector	Terminal		
M45	1	Ground	Existed

Is the inspection result normal?

YES >> Replace hazard switch. Refer to [EXL-218. "Removal and Installation"](#).

NO >> Repair or replace harness.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[HALOGEN TYPE]

## SYMPTOM DIAGNOSIS

### EXTERIOR LIGHTING SYSTEM SYMPTOMS

#### Symptom Table

INFOID:000000012201767

EXCEPT FOR NISMO MODELS

Without Daytime Running Light System

**NOTE:**

Perform the self-diagnosis with CONSULT before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom		Possible cause	Inspection item
Headlamp (HI) is not turned ON	One side	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Headlamp (HI) power supply/ ground circuit</li> <li>• Headlamp (HI) bulb</li> <li>• Headlamp assembly</li> <li>- Harness</li> <li>• IPDM E/R</li> </ul>	Headlamp (HI) circuit Refer to <a href="#">EXL-162</a> . "Component Function Check".
	Both sides	<b>Symptom diagnosis</b> "BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON" Refer to <a href="#">EXL-198</a> . "Diagnosis Procedure".	
High beam indicator lamp is not turned ON [Headlamp (HI) is turned ON]		Combination meter	<ul style="list-style-type: none"> <li>• Combination meter</li> <li>Data monitor "HI-BEAM IND"</li> <li>• BCM (HEAD LAMP)</li> <li>Active test "HEAD LAMP"</li> </ul>
Headlamp (LO) is not turned ON	One side	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Headlamp (LO) power supply/ ground circuit</li> <li>• Headlamp (LO) bulb (Xenon bulb)</li> <li>• Headlamp assembly</li> <li>- HID control unit</li> <li>- Xenon bulb socket</li> <li>- Harness</li> <li>• IPDM E/R</li> </ul>	Headlamp (LO) circuit Refer to <a href="#">EXL-165</a> . "Component Function Check".
	Both sides	<b>Symptom diagnosis</b> "BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON" Refer to <a href="#">EXL-199</a> . "Diagnosis Procedure".	
Each lamp is not turned ON/OFF with lighting switch AUTO	<ul style="list-style-type: none"> <li>• Combination switch input/output signal circuit</li> <li>• Combination switch</li> <li>• BCM</li> </ul>		Combination switch Refer to <a href="#">BCS-92</a> . "Symptom Table".
	<ul style="list-style-type: none"> <li>• Optical sensor power supply/ ground/signal circuit</li> <li>• Optical sensor</li> <li>• BCM</li> </ul>		Optical sensor Refer to <a href="#">EXL-185</a> . "Component Function Check".
Parking lamp is not turned ON		<ul style="list-style-type: none"> <li>• Parking lamp power supply/ ground circuit</li> <li>• Front combination lamp</li> <li>- LED (Parking lamp)</li> <li>- Harness</li> <li>• IPDM E/R</li> </ul>	Parking lamp circuit Refer to <a href="#">EXL-167</a> . "Component Function Check".
Front side marker lamp is not turned ON		<ul style="list-style-type: none"> <li>• Front side marker lamp power supply/ground circuit</li> <li>• Front side marker lamp bulb</li> <li>• Front side marker lamp bulb socket</li> </ul>	Front side marker lamp circuit Refer to <a href="#">EXL-169</a> . "Component Function Check".

# EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[HALOGEN TYPE]

Symptom	Possible cause	Inspection item
Tail lamp is not turned ON	Stop lamp / Tail lamp (Bulb side) <ul style="list-style-type: none"> <li>• Fuse</li> <li>• Tail lamp power supply/ground circuit</li> <li>• Stop lamp / Tail lamp bulb</li> <li>• Stop lamp / Tail lamp bulb socket/harness</li> <li>• IPDM E/R</li> </ul>	Tail lamp circuit Refer to <a href="#">EXL-171, "Component Function Check"</a> .
	Tail lamp (LED side) <ul style="list-style-type: none"> <li>• Fuse</li> <li>• Tail lamp power supply/ground circuit</li> <li>• Rear combination lamp internal circuit</li> <li>- LED (Tail lamp)</li> <li>• Tail lamp harness</li> <li>• IPDM E/R</li> </ul>	
License plate lamp is not turned ON	<ul style="list-style-type: none"> <li>• License plate lamp power supply/ground circuit</li> <li>• License plate lamp bulb</li> <li>• License plate lamp bulb socket/harness</li> </ul>	License plate lamp circuit Refer to <a href="#">EXL-173, "Component Function Check"</a> .
Parking lamp, license plate lamp, side marker lamp and tail lamp are not turned ON	<b>Symptom diagnosis</b> "PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS ARE NOT TURNED ON" Refer to <a href="#">EXL-200, "Diagnosis Procedure"</a> .	
Position lamp indicator is not turned ON (Parking lamp, license plate lamp, side marker lamp and tail lamp are turned ON)	Combination meter	<ul style="list-style-type: none"> <li>• Combination meter</li> <li>Data monitor "LIGHT IND"</li> <li>• BCM (HEAD LAMP)</li> <li>Active test "TAIL LAMP"</li> </ul>
Front fog lamp is not turned ON	One side	<ul style="list-style-type: none"> <li>• Front fog lamp power supply/ground circuit</li> <li>• Front fog lamp bulb</li> <li>• IPDM E/R</li> </ul> Front fog lamp circuit Refer to <a href="#">EXL-180, "Component Function Check"</a> .
	Both sides	<b>Symptom diagnosis</b> "BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON" Refer to <a href="#">EXL-201, "Diagnosis Procedure"</a> .
Turn signal lamp does not blink	Indicator lamp is normal (Applicable side performs high flasher activation) <ul style="list-style-type: none"> <li>• Front turn signal lamp</li> <li>- Front turn signal lamp power supply/ground circuit</li> <li>- Front turn signal lamp bulb</li> <li>- Front turn signal lamp bulb socket</li> <li>- BCM</li> <li>• Side turn signal lamp</li> <li>- Side turn signal lamp power supply/ground circuit</li> <li>- Side turn signal lamp</li> <li>- BCM</li> <li>• Rear turn signal lamp</li> <li>- Rear turn signal lamp power supply/ground circuit</li> <li>- Rear turn signal lamp bulb</li> <li>- Rear turn signal lamp bulb socket/harness</li> <li>- BCM</li> </ul>	Turn signal lamp circuit Refer to <a href="#">EXL-182, "Component Function Check"</a> .
	Indicator lamp is included	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

EXL

# EXTERIOR LIGHTING SYSTEM SYMPTOMS

[HALOGEN TYPE]

< SYMPTOM DIAGNOSIS >

Symptom	Possible cause	Inspection item	
Turn signal indicator lamp does not blink (Turn signal lamp is normal)	One side	Combination meter —	
	Both sides (Always)	<ul style="list-style-type: none"> <li>• Turn indicator signal</li> <li>• BCM</li> <li>• Combination meter</li> </ul>	<ul style="list-style-type: none"> <li>• Combination meter</li> <li>Data monitor "TURN IND"</li> <li>• BCM (FLASHER)</li> <li>Active test "FLASHER"</li> </ul>
	Both sides (Only when activating hazard warning lamp with ignition switch OFF)	<ul style="list-style-type: none"> <li>• Combination meter power supply/ground circuit</li> <li>• Combination meter</li> </ul>	Combination meter Power supply and ground circuit Refer to <a href="#">MWI-53, "COMBINATION METER : Diagnosis Procedure"</a> .
<ul style="list-style-type: none"> <li>• Hazard warning lamp does not activate (Turn signal is normal)</li> <li>• Hazard warning lamp continues activating</li> </ul>	<ul style="list-style-type: none"> <li>• Hazard switch signal/ground circuit</li> <li>• Hazard switch</li> <li>• BCM</li> </ul>	Hazard switch Refer to <a href="#">EXL-188, "Component Function Check"</a> .	

With Daytime Running Light System

**NOTE:**

Perform the self-diagnosis with CONSULT before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom	Possible cause	Inspection item	
Headlamp (HI) is not turned ON	One side	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Headlamp (HI) power supply/ground circuit</li> <li>• Daytime running light relay</li> <li>• Headlamp (HI) bulb</li> <li>• Headlamp assembly</li> <li>- Harness</li> <li>• IPDM E/R</li> </ul>	Headlamp (HI) circuit Refer to <a href="#">EXL-162, "Component Function Check"</a> .
	Both sides	<b>Symptom diagnosis</b> "BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON" Refer to <a href="#">EXL-198, "Diagnosis Procedure"</a> .	
High beam indicator lamp is not turned ON [Headlamp (HI) is turned ON]	Combination meter	<ul style="list-style-type: none"> <li>• Combination meter</li> <li>Data monitor "HI-BEAM IND"</li> <li>• BCM (HEAD LAMP)</li> <li>Active test "HEAD LAMP"</li> </ul>	
Headlamp (LO) is not turned ON	One side	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Headlamp (LO) power supply/ground circuit</li> <li>• Headlamp (LO) bulb (Xenon bulb)</li> <li>• Headlamp assembly</li> <li>- HID control unit</li> <li>- Xenon bulb socket</li> <li>- Harness</li> <li>• IPDM E/R</li> </ul>	Headlamp (LO) circuit Refer to <a href="#">EXL-165, "Component Function Check"</a> .
	Both sides	<b>Symptom diagnosis</b> "BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON" Refer to <a href="#">EXL-199, "Diagnosis Procedure"</a> .	
Parking lamp is not turned ON	<ul style="list-style-type: none"> <li>• Parking lamp power supply/ground circuit</li> <li>• Front combination lamp</li> <li>- LED (Parking lamp)</li> <li>- Harness</li> <li>• IPDM E/R</li> </ul>	Parking lamp circuit Refer to <a href="#">EXL-167, "Component Function Check"</a> .	
Front side marker lamp is not turned ON	<ul style="list-style-type: none"> <li>• Front side marker lamp power supply/ground circuit</li> <li>• Front side marker lamp bulb</li> <li>• Front side marker lamp bulb socket</li> </ul>	Front side marker lamp circuit Refer to <a href="#">EXL-169, "Component Function Check"</a> .	



# EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[HALOGEN TYPE]

Symptom	Possible cause	Inspection item	
Tail lamp is not turned ON	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Tail lamp power supply/ground circuit</li> <li>• Stop lamp / Tail lamp bulb</li> <li>• Stop lamp / Tail lamp bulb socket/harness</li> <li>• IPDM E/R</li> </ul>	Tail lamp circuit Refer to <a href="#">EXL-171, "Component Function Check"</a> .	
	Tail lamp (LED side)		<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Tail lamp power supply/ground circuit</li> <li>• Rear combination lamp internal circuit</li> <li>- LED (Tail lamp)</li> <li>• Tail lamp harness</li> <li>• IPDM E/R</li> </ul>
License plate lamp is not turned ON	<ul style="list-style-type: none"> <li>• License plate lamp power supply/ground circuit</li> <li>• License plate lamp bulb</li> <li>• License plate lamp bulb socket/harness</li> </ul>	License plate lamp circuit Refer to <a href="#">EXL-173, "Component Function Check"</a> .	
Parking lamp, license plate lamp, side marker lamp and tail lamp are not turned ON	<p><b>Symptom diagnosis</b>                      "PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS ARE NOT TURNED ON"                      Refer to <a href="#">EXL-200, "Diagnosis Procedure"</a>.</p>		
Position lamp indicator is not turned ON (Parking lamp, license plate lamp, side marker lamp and tail lamp are turned ON)	Combination meter	<ul style="list-style-type: none"> <li>• Combination meter</li> <li>Data monitor "LIGHT IND"</li> <li>• BCM (HEAD LAMP)</li> <li>Active test "TAIL LAMP"</li> </ul>	
Daytime running light is not turned ON [Headlamp (HI) at approximately half illumination] [Headlamp (HI) is turned ON]	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Daytime running light relay power supply/control signal circuit</li> <li>• Daytime running light relay</li> <li>• IPDM E/R</li> <li>• BCM</li> <li>• ECM</li> <li>• Combination meter</li> </ul>	<ul style="list-style-type: none"> <li>• Daytime running light relay circuit</li> <li>Refer to <a href="#">EXL-175, "Component Function Check"</a>.</li> <li>• BCM (HEAD LAMP)</li> <li>Data monitor "ENGINE STATE"</li> <li>• Combination meter</li> <li>Data monitor "PKB SW"</li> </ul>	
Front fog lamp is not turned ON	One side	<ul style="list-style-type: none"> <li>• Front fog lamp power supply/ground circuit</li> <li>• Front fog lamp bulb</li> <li>• IPDM E/R</li> </ul>	Front fog lamp circuit Refer to <a href="#">EXL-180, "Component Function Check"</a> .
	Both sides	<p><b>Symptom diagnosis</b>                      "BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON"                      Refer to <a href="#">EXL-201, "Diagnosis Procedure"</a>.</p>	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# EXTERIOR LIGHTING SYSTEM SYMPTOMS

[HALOGEN TYPE]

< SYMPTOM DIAGNOSIS >

Symptom	Possible cause	Inspection item	
Turn signal lamp does not blink	Indicator lamp is normal (Applicable side performs high flasher activation)	<ul style="list-style-type: none"> <li>• Front turn signal lamp</li> <li>- Front turn signal lamp power supply/ground circuit</li> <li>- Front turn signal lamp bulb</li> <li>- Front turn signal lamp bulb socket</li> <li>- BCM</li> <li>• Side turn signal lamp</li> <li>- Side turn signal lamp power supply/ground circuit</li> <li>- Side turn signal lamp</li> <li>- BCM</li> <li>• Rear turn signal lamp</li> <li>- Rear turn signal lamp power supply/ground circuit</li> <li>- Rear turn signal lamp bulb</li> <li>- Rear turn signal lamp bulb socket/harness</li> <li>- BCM</li> </ul>	Turn signal lamp circuit Refer to <a href="#">EXL-182, "Component Function Check"</a> .
	Indicator lamp is included	<ul style="list-style-type: none"> <li>• Combination switch input/output signal circuit</li> <li>• Combination switch</li> <li>• BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-92, "Symptom Table"</a> .
Turn signal indicator lamp does not blink (Turn signal lamp is normal)	One side	Combination meter	—
	Both sides (Always)	<ul style="list-style-type: none"> <li>• Turn indicator signal</li> <li>• BCM</li> <li>• Combination meter</li> </ul>	<ul style="list-style-type: none"> <li>• Combination meter</li> <li>Data monitor "TURN IND"</li> <li>• BCM (FLASHER)</li> <li>Active test "FLASHER"</li> </ul>
	Both sides (Only when activating hazard warning lamp with ignition switch OFF)	<ul style="list-style-type: none"> <li>• Combination meter power supply/ground circuit</li> <li>• Combination meter</li> </ul>	Combination meter Power supply and ground circuit Refer to <a href="#">MWI-53, "COMBINATION METER : Diagnosis Procedure"</a> .
<ul style="list-style-type: none"> <li>• Hazard warning lamp does not activate (Turn signal is normal)</li> <li>• Hazard warning lamp continues activating</li> </ul>	<ul style="list-style-type: none"> <li>• Hazard switch signal/ground circuit</li> <li>• Hazard switch</li> <li>• BCM</li> </ul>	Hazard switch Refer to <a href="#">EXL-188, "Component Function Check"</a> .	

## NISMO MODELS

### NOTE:

Perform the self-diagnosis with CONSULT before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom	Possible cause	Inspection item	
Headlamp (HI) is not turned ON	One side	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Headlamp (HI) power supply/ground circuit</li> <li>• Headlamp (HI) bulb</li> <li>• Headlamp assembly</li> <li>- Harness</li> <li>• IPDM E/R</li> </ul>	Headlamp (HI) circuit Refer to <a href="#">EXL-162, "Component Function Check"</a> .
	Both sides	<b>Symptom diagnosis</b> "BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON" Refer to <a href="#">EXL-198, "Diagnosis Procedure"</a> .	
High beam indicator lamp is not turned ON [Headlamp (HI) is turned ON]	Combination meter	<ul style="list-style-type: none"> <li>• Combination meter</li> <li>Data monitor "HI-BEAM IND"</li> <li>• BCM (HEAD LAMP)</li> <li>Active test "HEAD LAMP"</li> </ul>	

# EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[HALOGEN TYPE]

Symptom	Possible cause	Inspection item		
Headlamp (LO) is not turned ON	One side	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Headlamp (LO) power supply/ground circuit</li> <li>• Headlamp (LO) bulb (Xenon bulb)</li> <li>• Headlamp assembly</li> <li>- HID control unit</li> <li>- Xenon bulb socket</li> <li>- Harness</li> <li>• IPDM E/R</li> </ul>	Headlamp (LO) circuit Refer to <a href="#">EXL-165, "Component Function Check"</a> .	A B C
	Both sides	<b>Symptom diagnosis</b> "BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON" Refer to <a href="#">EXL-199, "Diagnosis Procedure"</a> .		D
Parking lamp is not turned ON	<ul style="list-style-type: none"> <li>• Parking lamp power supply/ground circuit</li> <li>• Front combination lamp</li> <li>- LED (Parking lamp)</li> <li>- Harness</li> <li>• IPDM E/R</li> </ul>	Parking lamp circuit Refer to <a href="#">EXL-167, "Component Function Check"</a> .	E F	
Front side marker lamp is not turned ON	<ul style="list-style-type: none"> <li>• Front side marker lamp power supply/ground circuit</li> <li>• Front side marker lamp bulb</li> <li>• Front side marker lamp bulb socket</li> </ul>	Front side marker lamp circuit Refer to <a href="#">EXL-169, "Component Function Check"</a> .	G	
Tail lamp is not turned ON	Stop lamp / Tail lamp (Bulb side)	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Tail lamp power supply/ground circuit</li> <li>• Stop lamp / Tail lamp bulb</li> <li>• Stop lamp / Tail lamp bulb socket/harness</li> <li>• IPDM E/R</li> </ul>	Tail lamp circuit Refer to <a href="#">EXL-171, "Component Function Check"</a> .	H I
	Tail lamp (LED side)	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Tail lamp power supply/ground circuit</li> <li>• Rear combination lamp internal circuit</li> <li>- LED (Tail lamp)</li> <li>• Tail lamp harness</li> <li>• IPDM E/R</li> </ul>		J K
License plate lamp is not turned ON	<ul style="list-style-type: none"> <li>• License plate lamp power supply/ground circuit</li> <li>• License plate lamp bulb</li> <li>• License plate lamp bulb socket/harness</li> </ul>	License plate lamp circuit Refer to <a href="#">EXL-173, "Component Function Check"</a> .	EXL M	
Parking lamp, license plate lamp, side marker lamp and tail lamp are not turned ON	<b>Symptom diagnosis</b> "PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS ARE NOT TURNED ON" Refer to <a href="#">EXL-200, "Diagnosis Procedure"</a> .		N	
Position lamp indicator is not turned ON (Parking lamp, license plate lamp, side marker lamp and tail lamp are turned ON)	Combination meter	<ul style="list-style-type: none"> <li>• Combination meter</li> <li>Data monitor "LIGHT IND"</li> <li>• BCM (HEAD LAMP)</li> <li>Active test "TAIL LAMP"</li> </ul>	O	
Daytime running light is not turned ON	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Daytime running light power supply/ground circuit</li> <li>• Daytime running light</li> <li>• IPDM E/R</li> <li>• BCM</li> <li>• ECM</li> <li>• Combination meter</li> </ul>	<ul style="list-style-type: none"> <li>• Daytime running light circuit</li> <li>Refer to <a href="#">EXL-178, "Component Function Check"</a>.</li> <li>• BCM (HEAD LAMP)</li> <li>Data monitor "ENGINE STATE"</li> <li>• Combination meter</li> <li>Data monitor "PKB SW"</li> </ul>	P	

# EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[HALOGEN TYPE]

Symptom	Possible cause	Inspection item	
Turn signal lamp does not blink	<ul style="list-style-type: none"> <li>• Indicator lamp is normal (Applicable side performs high flasher activation)</li> </ul>	<ul style="list-style-type: none"> <li>• Front turn signal lamp</li> <li>- Front turn signal lamp power supply/ground circuit</li> <li>- Front turn signal lamp bulb</li> <li>- Front turn signal lamp bulb socket</li> <li>- BCM</li> <li>• Side turn signal lamp</li> <li>- Side turn signal lamp power supply/ground circuit</li> <li>- Side turn signal lamp</li> <li>- BCM</li> <li>• Rear turn signal lamp</li> <li>- Rear turn signal lamp power supply/ground circuit</li> <li>- Rear turn signal lamp bulb</li> <li>- Rear turn signal lamp bulb socket/harness</li> <li>- BCM</li> </ul>	Turn signal lamp circuit Refer to <a href="#">EXL-182, "Component Function Check"</a> .
	Indicator lamp is included	<ul style="list-style-type: none"> <li>• Combination switch input/output signal circuit</li> <li>• Combination switch</li> <li>• BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-92, "Symptom Table"</a> .
Turn signal indicator lamp does not blink (Turn signal lamp is normal)	One side	Combination meter	—
	Both sides (Always)	<ul style="list-style-type: none"> <li>• Turn indicator signal</li> <li>• BCM</li> <li>• Combination meter</li> </ul>	<ul style="list-style-type: none"> <li>• Combination meter</li> <li>Data monitor "TURN IND"</li> <li>• BCM (FLASHER)</li> <li>Active test "FLASHER"</li> </ul>
	Both sides (Only when activating hazard warning lamp with ignition switch OFF)	<ul style="list-style-type: none"> <li>• Combination meter power supply/ground circuit</li> <li>• Combination meter</li> </ul>	Combination meter Power supply and ground circuit Refer to <a href="#">MWI-53, "COMBINATION METER : Diagnosis Procedure"</a> .
<ul style="list-style-type: none"> <li>• Hazard warning lamp does not activate (Turn signal is normal)</li> <li>• Hazard warning lamp continues activating</li> </ul>	<ul style="list-style-type: none"> <li>• Hazard switch signal/ground circuit</li> <li>• Hazard switch</li> <li>• BCM</li> </ul>	Hazard switch Refer to <a href="#">EXL-188, "Component Function Check"</a> .	

# NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[HALOGEN TYPE]

## NORMAL OPERATING CONDITION

### Description

INFOID:000000012201768

#### AUTO LIGHT SYSTEM

The headlamp may not be turned ON/OFF immediately after passing dark area or bright area (short tunnel, sky bridge, shadowed area, etc.) while using the auto light system. This is caused by for the control difference. This is normal.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

# BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[HALOGEN TYPE]

## BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON

### Description

INFOID:000000012201769

Both side headlamps (HI) are not turned ON when setting to the lighting switch HI or PASS.

### Diagnosis Procedure

INFOID:000000012201770

#### 1.COMBINATION SWITCH INSPECTION

Check combination switch. Refer to [BCS-92, "Symptom Table"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

#### 2.CHECK HIGH BEAM REQUEST SIGNAL

Ⓜ With CONSULT

1. Turn ignition switch ON.
2. Select "HL HI REQ" in "Data Monitor" mode of "IPDM E/R" using CONSULT.
3. With operating the lighting switch, check the monitor status.

Monitor item	Condition		Monitor status
HL HI REQ	Lighting switch (2ND)	HI or PASS	On
		LO	Off

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-37, "Removal and Installation"](#).

NO >> Replace BCM. Refer to [BCS-94, "Removal and Installation"](#).

# BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[HALOGEN TYPE]

## BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON

### Description

INFOID:000000012201771

Both side headlamps (LO) are not turned ON in any condition.

### Diagnosis Procedure

INFOID:000000012201772

#### 1.COMBINATION SWITCH INSPECTION

Check combination switch. Refer to [BCS-92, "Symptom Table"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

#### 2.CHECK LOW BEAM REQUEST SIGNAL

Ⓜ With CONSULT

1. Turn ignition switch ON.
2. Select "HL LO REQ" in "Data Monitor" mode of "IPDM E/R" using CONSULT.
3. With operating the lighting switch, check the monitor status.

Monitor item	Condition		Monitor status
HL LO REQ	Lighting switch	2ND	On
		OFF	Off

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-37, "Removal and Installation"](#).

NO >> Replace BCM. Refer to [BCS-94, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[HALOGEN TYPE]

## PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS ARE NOT TURNED ON

### Description

INFOID:000000012201773

The parking, license plate, side marker and tail lamps are not turned ON in any condition.

### Diagnosis Procedure

INFOID:000000012201774

#### 1.COMBINATION SWITCH INSPECTION

Check combination switch. Refer to [BCS-92, "Symptom Table"](#).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair or replace the malfunctioning part.

#### 2.CHECK POSITION LIGHT REQUEST SIGNAL

Ⓔ With CONSULT

1. Turn ignition switch ON.
2. Select "TAIL & CLR REQ" in "Data Monitor" mode of "IPDM E/R" using CONSULT.
3. With operating the lighting switch, check the monitor status.

Monitor item	Condition		Monitor status
TAIL & CLR REQ	Lighting switch	1ST	On
		OFF	Off

Is the inspection result normal?

- YES >> Perform the tail lamp diagnosis. Refer to [EXL-171, "Component Function Check"](#).
- NO >> Replace BCM. Refer to [BCS-94, "Removal and Installation"](#).



# BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[HALOGEN TYPE]

## BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON

### Description

INFOID:000000012201775

Both side front fog lamps are not turned ON in any condition.

### Diagnosis Procedure

INFOID:000000012201776

#### 1.COMBINATION SWITCH INSPECTION

Check combination switch. Refer to [BCS-92, "Symptom Table"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

#### 2.CHECK FRONT FOG LIGHT REQUEST SIGNAL

Ⓜ With CONSULT

1. Turn ignition switch ON.
2. Select "FR FOG REQ" in "Data Monitor" mode of "IPDM E/R" using CONSULT.
3. With operating the front fog lamp switch, check the monitor status.

Monitor item	Condition	Monitor status	
FR FOG REQ	Front fog lamp switch (With lighting switch 1ST)	ON	On
		OFF	Off

Is the inspection result normal?

YES >> Perform the front fog lamp diagnosis. Refer to [EXL-180, "Component Function Check"](#).

NO >> Replace BCM. Refer to [BCS-94, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# HEADLAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >

[HALOGEN TYPE]

## PERIODIC MAINTENANCE

### HEADLAMP AIMING ADJUSTMENT

#### Description

INFOID:000000012201777

#### PREPARATION BEFORE ADJUSTING

##### NOTE:

- For details, refer to the regulations in your own country.
- Perform aiming if the vehicle front body has been repaired and/or the headlamp assembly has been replaced.

Before performing aiming adjustment, check the following.

- Adjust the tire pressure to the specification.
- Fill with fuel, engine coolant and each oil.
- Maintain the unloaded vehicle condition. (Remove luggage from the passenger compartment and the trunk room.)

##### NOTE:

Do not remove the temporary tire, jack and on-vehicle tool.


- Wipe out dirt on the headlamp.

##### CAUTION:

**Never use organic solvent (thinner, gasoline etc.).**

- Ride alone on the driver seat.

#### AIMING ADJUSTMENT SCREW



A. Headlamp RH (UP/DOWN) adjustment screw B. Headlamp LH (UP/DOWN) adjustment screw

← : Vehicle front

	Adjustment screw	Screw driver rotation	Facing direction
A	Headlamp LH (UP/DOWN)	Clockwise	DOWN
		Counterclockwise	UP
B	Headlamp RH (UP/DOWN)	Clockwise	DOWN
		Counterclockwise	UP

#### Aiming Adjustment Procedure

INFOID:000000012201778

1. Place the screen.

##### NOTE:

- Stop the vehicle facing the wall.
- Place the board on a plain road vertically.

# HEADLAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >

[HALOGEN TYPE]

2. Face the vehicle with the screen. Maintain 10 m (32.8 ft) between the headlamp center and the screen.
3. Start the engine. Turn the headlamp (LO) ON.

**CAUTION:**

Never cover the lens surface with a tape etc. The lens is made of resin.


**NOTE:**

Shut off the headlamp light with the board to prevent from illuminating the adjustment screen.

4. Measure the distance (X) between the horizontal center line of headlamp (H) and the cutoff line (A) within the light axis measurement range (R) from the vertical center line ahead of headlamp (V).

**Light axis measurement range (R) : 350 ± 175 mm (13.78 ± 6.89 in)**

Low beam distribution on the screen




5. Adjust the cutoff line height (X) with the aiming adjustment screw so as to enter in the adjustment range (M–N) according to the horizontal center line of headlamp (H).

unit: mm (in)

Horizontal center line of headlamp (H)	Highest cutoff line height (M)	Lowest cutoff line height (N)
700 (27.56) or less	4 (0.16)	30 (1.18)
701(27.60) – 800 (31.50)	4 (0.16)	30 (1.18)
801 (31.54) or more	17 (0.67)	44 (1.73)

Side view



**Distance between the headlamp center and the screen (L) : 10 m (32.8 ft)**

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# FRONT FOG LAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >

[HALOGEN TYPE]

## FRONT FOG LAMP AIMING ADJUSTMENT

### Description

INFOID:000000012201779

### PREPARATION BEFORE ADJUSTING

#### NOTE:

- For details, refer to the regulations in your own country.
- Perform aiming if the vehicle front body has been repaired and/or the headlamp assembly has been replaced.

Before performing aiming adjustment, check the following.

- Adjust the tire pressure to the specification.
- Fill with fuel, engine coolant and each oil.
- Maintain the unloaded vehicle condition. (Remove luggage from the passenger compartment and the trunk room.)

#### NOTE:

Do not remove the temporary tire, jack and on-vehicle tool.

- Wipe out dirt on the headlamp.

#### CAUTION:

**Never use organic solvent (thinner, gasoline etc.).**

- Ride alone on the driver seat.

### AIMING ADJUSTMENT SCREW

- Turn the aiming adjusting screw for adjustment.


A: UP

B: DOWN

- For the position and direction of the adjusting screw, refer to the figure.

#### NOTE:

A screwdriver or hexagonal wrench [6 mm (0.24 in)] can be used for adjustment.



JMLIA1249ZZ

### Aiming Adjustment Procedure

INFOID:000000012201780

1. Place the screen.

#### NOTE:

- Stop the vehicle facing the wall.
- Place the board on a plain road vertically.

2. Face the vehicle with the screen. Maintain 10 m (32.8 ft) between the front fog lamp center and the screen.

3. Start the engine. Turn the front fog lamp ON.

#### CAUTION:

**Never cover the lens surface with a tape etc. The lens is made of resin.**

#### NOTE:

Shut off the headlamp light with the board to prevent from illuminating the adjustment screen.


4. Adjust the cutoff line height (A) with the aiming adjustment screw so that the distance (X) between the horizontal center line of front fog lamp (H) and (A) becomes 150 mm (5.91 in).

# FRONT FOG LAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >

[HALOGEN TYPE]

Front fog lamp light distribution on the screen



- A : Cutoff line
- B : High illuminance area
- H : Horizontal center line of front fog lamp
- V : Vertical center line of front fog lamp
- X : Cutoff line height

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# HEADLAMP

< REMOVAL AND INSTALLATION >

[HALOGEN TYPE]


## REMOVAL AND INSTALLATION

### HEADLAMP

Exploded View


INFOID:000000012201781

#### REMOVAL



1. Headlamp assembly

← : Vehicle front


 : N·m (kg-m, in-lb)

#### DISASSEMBLY

# HEADLAMP

< REMOVAL AND INSTALLATION >

[HALOGEN TYPE]



- 1. Headlamp assembly
- 2. Halogen bulb (LO)
- 3. Back cover A
- 4. Halogen bulb (HI)
- 5. Back cover B

⇐ : Vehicle front

## Removal and Installation

INFOID:0000000012201782

### CAUTION:

Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-119, "Precautions for Removing Battery Terminal"](#).

### REMOVAL

1. Remove front bumper fascia. Refer to [EXT-17, "Removal and Installation"](#).
2. Remove headlamp mounting bolts.
3. Pull out headlamp assembly forward the vehicle, and then disconnect the connector before removing the headlamp assembly.

### INSTALLATION

Note the following item, and then install in the reverse order of removal.

### CAUTION:

After installation, perform aiming adjustment. Refer to [EXL-202, "Description"](#).

## Replacement

INFOID:0000000012201783

### CAUTION:

- Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-119, "Precautions for Removing Battery Terminal"](#).
- After installing the bulb, install the back cover and the bulb socket securely for watertightness.
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.
- Never touch bulb by hand while it is lit or right after being turned off.

# HEADLAMP

[HALOGEN TYPE]

## < REMOVAL AND INSTALLATION >


- **Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.**

### HALOGEN BULB (LO)

#### Left Side of The Vehicle

1. Remove fixing clips (A) of air cleaner assembly (1).
2. While pulling up on the (B) portion of the air duct inlet (upper) (2), disengage of the portion (C), and then remove air duct inlet (upper) as shown by the arrow in the figure.

⇐ : Vehicle front



3. Remove back cover A.
4. Disconnect halogen bulb harness connector.
5. Rotate halogen bulb (LO) counterclockwise and lock it, and then remove halogen bulb.

#### Right Side of The Vehicle


1. Remove washer tank inlet. Refer to [WW-43, "Removal and Installation"](#).
2. Remove back cover A.
3. Disconnect halogen bulb harness connector.
4. Rotate halogen bulb (LO) counterclockwise and lock it, and then remove halogen bulb.

### HALOGEN BULB (HI)

#### Left Side of The Vehicle

1. Remove fixing clips (A) of air cleaner assembly (1).
2. While pulling up on the (B) portion of the air duct inlet (upper) (2), disengage of the portion (C), and then remove air duct inlet (upper) as shown by the arrow in the figure.

⇐ : Vehicle front



3. Remove back cover B.
4. Disconnect halogen bulb harness connector.
5. Rotate halogen bulb clockwise and unlock it, and then remove halogen bulb from headlamp assembly.

#### Right Side of The Vehicle

1. Remove washer tank inlet. Refer to [WW-43, "Removal and Installation"](#).
2. Remove back cover B.
3. Disconnect halogen bulb harness connector.
4. Rotate halogen bulb counterclockwise and unlock it, and then remove halogen bulb from headlamp assembly.

## Disassembly and Assembly

INFOID:000000012201784

### DISASSEMBLY

1. Remove back cover A.
2. Disconnect halogen bulb harness connector.



# HEADLAMP

[HALOGEN TYPE]

## < REMOVAL AND INSTALLATION >

3. Rotate halogen bulb (LO) counterclockwise and lock it, and then remove halogen bulb.
4. Remove back cover B.
5. Disconnect halogen bulb harness connector.
6. Remove halogen bulb (HI).

Left side of the vehicle

- Rotate halogen bulb (HI) clockwise and lock it, and then remove halogen bulb.

Right side of the vehicle

- Rotate halogen bulb (HI) counterclockwise and lock it, and then remove halogen bulb.

## ASSEMBLY

Note the following item, and then assemble in the reverse order of disassembly.

### **CAUTION:**

**After installing the bulb, install the back cover and the bulb socket securely for watertightness.**

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# FRONT COMBINATION LAMP

< REMOVAL AND INSTALLATION >


[HALOGEN TYPE]

## FRONT COMBINATION LAMP


Exploded View

INFOID:000000012201785


### REMOVAL



1. Front combination lamp

 : N·m (kg-m, in-lb)

### DISASSEMBLY



# FRONT COMBINATION LAMP

< REMOVAL AND INSTALLATION >

[HALOGEN TYPE]

- |                                |                                       |                                       |
|--------------------------------|---------------------------------------|---------------------------------------|
| 1. Front combination lamp      | 2. Front turn signal lamp bulb        | 3. Front turn signal lamp bulb socket |
| 4. Front side marker lamp bulb | 5. Front side marker lamp bulb socket |                                       |

↔ : Vehicle front

## Removal and Installation

INFOID:000000012201786

### CAUTION:

Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-119, "Precautions for Removing Battery Terminal"](#).

### REMOVAL

1. Remove front bumper fascia. Refer to [EXT-17, "Removal and Installation"](#).
2. Remove front combination lamp mounting bolts and nut.
3. Pull out front combination lamp forward the vehicle, and then disconnect connector before removing the front combination lamp.

### INSTALLATION

Note the following item, and then install in the reverse order of removal.

### CAUTION:

Interference of front combination lamp lens with front fender may cause intrusion of water into front combination lamp or rusting of fender due to damage of painted surface. Be careful to operate without allowing parts to interfere with each other.

## Replacement

INFOID:000000012201787

### CAUTION:

- Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-119, "Precautions for Removing Battery Terminal"](#).
- After installing the bulb, install the bulb socket securely for watertightness.
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.
- Never touch bulb by hand while it is lit or right after being turned off.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

### PARKING LAMP BULB

### CAUTION:

Replacement of a single part is not possible due to the adoption of LED. For replacement, replace front combination lamp as a set. Refer to [EXL-211, "Removal and Installation"](#).

### FRONT TURN SIGNAL LAMP BULB

1. Rotate the front turn signal lamp bulb socket counterclockwise and unlock it.
2. Remove front turn signal lamp bulb from the front turn signal lamp bulb socket.

### FRONT SIDE MARKER LAMP BULB

1. Rotate the front side marker lamp bulb socket counterclockwise and unlock it.
2. Remove front side marker lamp bulb from the front side marker lamp bulb socket.

## Disassembly and Assembly

INFOID:000000012201788

### DISASSEMBLY

1. Rotate the front turn signal lamp bulb socket counterclockwise and unlock it.
2. Remove front turn signal lamp bulb from the front turn signal lamp bulb socket.
3. Rotate the front side marker lamp bulb socket counterclockwise and unlock it.
4. Remove front side marker lamp bulb from the front side marker lamp bulb socket.

### ASSEMBLY

Note the following item, and then assemble in the reverse order of disassembly.

### CAUTION:

After installing the bulb, install the bulb socket securely for watertightness.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

# DAYTIME RUNNING LIGHT


< REMOVAL AND INSTALLATION >

[HALOGEN TYPE]


## DAYTIME RUNNING LIGHT

Exploded View

INFOID:000000012201789



1. Daytime running light      2. Front bumper fascia assembly      3. U nut  
4. Harness connector assembly

 5.5 (0.56, 49)  
N·m (kg-m, in-lb)

### Removal and Installation

INFOID:000000012201790

#### CAUTION:

Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-119, "Precautions for Removing Battery Terminal"](#).

#### REMOVAL

1. Remove front bumper fascia lower. Refer to [EXT-17, "Removal and Installation"](#).
2. Disconnect daytime running light harness connector.
3. Remove daytime running light mounting nuts.
4. Remove daytime running light from front bumper fascia lower.

#### INSTALLATION

Install in the reverse order of removal.

### Replacement

INFOID:000000012201791

#### CAUTION:

Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-119, "Precautions for Removing Battery Terminal"](#).

### DAYTIME RUNNING LIGHT

#### CAUTION:

Replacement of a single part is not possible due to the adoption of LED. For replacement, replace daytime running light as a set. Refer to [EXL-212, "Removal and Installation"](#).

# FRONT FOG LAMP


< REMOVAL AND INSTALLATION >

[HALOGEN TYPE]

## FRONT FOG LAMP


Exploded View

INFOID:000000012201792



- 1. Front bumper fascia assembly
- 2. Front fog lamp bracket
- 3. Front fog lamp bulb
- 4. Front fog lamp
- 5. U nut

← : Vehicle front

 : N·m (kg-m, in-lb)

### Removal and Installation

INFOID:000000012201793

#### CAUTION:

Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-119. "Precautions for Removing Battery Terminal"](#).

#### REMOVAL

1. Remove front fender protector to make work space. Refer to [EXT-31. "Removal and Installation"](#).
2. Disconnect front fog lamp harness connector.
3. Remove front fog lamp fixing screws, and then remove front fog lamp from front fog lamp bracket.
4. Remove front fog lamp bracket mounting bolt and fixing clips, and then remove front fog lamp bracket.

# FRONT FOG LAMP

< REMOVAL AND INSTALLATION >

[HALOGEN TYPE]

## INSTALLATION

Note the following item, and then install in the reverse order of removal.

### NOTE:

After installation, perform aiming adjustment. Refer to [EXL-204. "Description"](#).

## Replacement


INFOID:000000012201794

### CAUTION:

- Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-119. "Precautions for Removing Battery Terminal"](#).
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.
- Never touch bulb by hand while it is lit or right after being turned off.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

## FRONT FOG LAMP BULB

1. Remove fender protector to make work space. Refer to [EXT-31. "Removal and Installation"](#).
2. Remove front fog lamp bulb connector (1).
3. Rotate front fog lamp bulb (2) counterclockwise and unlock it.



# SIDE TURN SIGNAL LAMP

< REMOVAL AND INSTALLATION >

[HALOGEN TYPE]

## SIDE TURN SIGNAL LAMP

### Exploded View

INFOID:000000012201795

Refer to [MIR-17, "Exploded View"](#).

### Removal and Installation


INFOID:000000012201796

#### **CAUTION:**

Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-119, "Precautions for Removing Battery Terminal"](#).

#### REMOVAL

1. Remove door mirror cover. Refer to [MIR-20, "DOOR MIRROR COVER : Removal and Installation"](#).
2. Remove side turn signal lamp fixing screws (A), and then disconnect side turn signal lamp harness connector (B).



3. Remove side turn signal lamp.

#### INSTALLATION

Install in the reverse order of removal.

#### Replacement

INFOID:000000012201797

#### **CAUTION:**

Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-119, "Precautions for Removing Battery Terminal"](#).

#### SIDE TURN SIGNAL LAMP BULB

#### **CAUTION:**

Replacement of a single part is not possible due to the adoption of LED. For replacement, replace side turn signal lamp as a set. Refer to [EXL-215, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# OPTICAL SENSOR


< REMOVAL AND INSTALLATION >

[HALOGEN TYPE]

## OPTICAL SENSOR


### Exploded View

INFOID:000000012201798



1. Optical sensor

2. Switch panel

 : Pawl

### Removal and Installation

INFOID:000000012201799

#### REMOVAL

1. Insert an appropriate tool between the switch panel and the instrument upper panel. Pull out the optical sensor upward.
2. Disconnect the optical sensor connector.
3. Remove optical sensor from switch panel.

#### INSTALLATION

Install in the reverse order of removal.



# LIGHTING & TURN SIGNAL SWITCH

< REMOVAL AND INSTALLATION >

[HALOGEN TYPE]

## LIGHTING & TURN SIGNAL SWITCH

### Removal and Installation

INFOID:000000012201800

#### REMOVAL

Remove light & turn signal switch. Refer to [BCS-95. "Removal and Installation"](#).

#### INSTALLATION

Install in the reverse order of removal.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

# HAZARD SWITCH


< REMOVAL AND INSTALLATION >

[HALOGEN TYPE]


## HAZARD SWITCH

Exploded View

INFOID:000000012201801



1. Instrument panel assembly
2. Hazard switch

 : Pawl

### Removal and Installation

INFOID:000000012201802

#### **CAUTION:**

Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-119, "Precautions for Removing Battery Terminal"](#).

#### REMOVAL

1. Remove audio unit. Refer to [AV-50, "Removal and Installation"](#).
2. Disengage fixing pawls, and then remove hazard switch from instrument panel inside to outside.

#### INSTALLATION

Install in the reverse order of removal.

# REAR COMBINATION LAMP

< REMOVAL AND INSTALLATION >


[HALOGEN TYPE]

## REAR COMBINATION LAMP

Exploded View

INFOID:000000012201803

REMOVAL



1. Grommet

2. Grommet

3. Rear combination lamp

○ : Clip

⊙ : N·m (kg-m, in-lb)


DISASSEMBLY

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# REAR COMBINATION LAMP

< REMOVAL AND INSTALLATION >

[HALOGEN TYPE]



- |                               |   |                      |
|-------------------------------|---|----------------------|
| 1. Rear combination lamp      | 2. Back-up lamp bulb                              | 3. Harness connector |
| 4. Rear turn signal lamp bulb | 5. Stop/Tail lamp bulb<br>(Rear side marker lamp) |                      |

## Removal and Installation

INFOID:000000012201804

### CAUTION:

- Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-119, "Precautions for Removing Battery Terminal"](#).
- When removing, always use a remover tool that is made of plastic.

### REMOVAL

1. Full open back door.
2. Remove luggage side lower finisher. Refer to [INT-35, "LUGGAGE SIDE LOWER FINISHER : Removal and Installation"](#).
3. Remove rear combination lamp mounting bolts.
4. Insert a remover tool into the rear combination lamp and rear fender to disengage the clips.
5. Pull up rear combination lamp, and then remove rear combination lamp.
6. Disconnect rear combination lamp connector.

### INSTALLATION

Install in the reverse order of removal.

### Replacement

INFOID:000000012201805

### CAUTION:

- Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-119, "Precautions for Removing Battery Terminal"](#).
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.

# REAR COMBINATION LAMP

[HALOGEN TYPE]

< REMOVAL AND INSTALLATION >

- Never touch bulb by hand while it is lit or right after being turned off.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

TAIL LAMP (LED)

**CAUTION:**

Replacement of a single part is not possible due to the adoption of LED. For replacement, replace rear combination lamp as a set. Refer to [EXL-220, "Removal and Installation"](#).

STOP/TAIL LAMP BULB (REAR SIDE MARKER LAMP)

1. Remove rear combination lamp assembly. Refer to [EXL-220, "Removal and Installation"](#).
2. Rotate stop/tail lamp bulb socket counterclockwise, and then remove stop/tail lamp bulb socket.
3. Remove stop/tail lamp bulb from stop/tail lamp bulb socket.

REAR TURN SIGNAL LAMP BULB

1. Remove rear combination lamp assembly. Refer to [EXL-220, "Removal and Installation"](#).
2. Rotate rear turn signal lamp bulb socket counterclockwise, and then remove rear turn signal lamp bulb socket.
3. Remove rear turn signal lamp bulb from rear turn signal lamp bulb socket.

BACK-UP LAMP BULB

1. Remove rear combination lamp assembly. Refer to [EXL-220, "Removal and Installation"](#).
2. Rotate back-up lamp bulb socket counterclockwise, and then remove back-up lamp bulb socket.
3. Remove back-up lamp bulb from back-up lamp bulb socket.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# HIGH-MOUNTED STOP LAMP

< REMOVAL AND INSTALLATION >


[HALOGEN TYPE]

## HIGH-MOUNTED STOP LAMP


Exploded View

INFOID:000000012201806


EXCEPT FOR NISMO AND NISMO RS



1. High-mounted stop lamp                      2. Seal packing

 : N·m (kg·m, in·lb)

NISMO AND NISMO RS



1. Rear spoiler                      2. High-mounted stop lamp                      3. High-mounted stop lamp cover

## Removal and Installation

INFOID:000000012201807

### CAUTION:

Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-119, "Precautions for Removing Battery Terminal"](#).

### REMOVAL

Except for NISMO and NISMO RS

1. Remove blind seal from back door inside.

### CAUTION:

# HIGH-MOUNTED STOP LAMP

[HALOGEN TYPE]

## < REMOVAL AND INSTALLATION >

**Never damage the blind seal, so that it can be reused.**

2. Remove high-mounted stop lamp mounting nuts and connector. A
3. Pull high-mounted stop lamp toward vehicle upside, and then remove high-mounted stop lamp.

### NISMO and NISMO RS

1. Remove rear spoiler. Refer to [EXT-49. "Removal and Installation"](#). B
2. Remove high-mounted stop lamp cover mounting bolts, and then remove high-mounted stop lamp cover. C
3. Remove high-mounted stop lamp harness connector from rear spoiler. C
4. Pull out high-mounted stop lamp, and then remove high-mounted stop lamp. D

### INSTALLATION

Note the following item, and then install in the reverse order of removal. D

**CAUTION:**

**Seal packing cannot be reused.** E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

EXL

# LICENSE PLATE LAMP


< REMOVAL AND INSTALLATION >

[HALOGEN TYPE]


## LICENSE PLATE LAMP

Exploded View

INFOID:000000012201808



1. License plate lamp housing assembly      2. Bulb      3. License plate lamp bulb socket

 : Pawl

## Removal and Installation


INFOID:000000012201809

### CAUTION:

Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-119, "Precautions for Removing Battery Terminal"](#).

### REMOVAL

1. While pressing the license plate lamp to direction right side, pull it to direction outside and then remove it.
2. Disconnect license plate lamp connector.



### INSTALLATION

Install in the reverse order of removal.

## Replacement

INFOID:000000012201810

### CAUTION:

- Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-119, "Precautions for Removing Battery Terminal"](#).
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.
- Never touch bulb by hand while it is lit or right after being turned off.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

### LICENSE PLATE LAMP BULB

1. Remove license plate lamp. Refer to [EXL-224, "Removal and Installation"](#).
2. Rotate the bulb socket counterclockwise and unlock it.



# LICENSE PLATE LAMP

< REMOVAL AND INSTALLATION >

[HALOGEN TYPE]

3. Remove the bulb from the socket.

A

B

C

D

E

F

G

H

I

J

K

**EXL**

M

N

O

P

# REAR FOG LAMP

< REMOVAL AND INSTALLATION >


[HALOGEN TYPE]

## REAR FOG LAMP

Exploded View

INFOID:000000012201811

### REMOVAL



1. Rear fog lamp housing

2. Rear bumper fascia lower

3. Rear fog lamp housing bracket

N·m (kg-m, in-lb)

: Vehicle front

### Removal and Installation

INFOID:000000012201812

#### REMOVAL

1. Remove rear bumper fascia lower. Refer to [EXT-23, "Removal and Installation"](#).
2. Remove rear fog lamp housing mounting nuts.
3. Remove rear fog lamp housing from the rear bumper fascia lower.
4. Remove rear fog lamp housing bracket from rear bumper fascia lower.

#### INSTALLATION

Installation is the reverse order of removal.

# REAR REFLEX REFLECTOR

< REMOVAL AND INSTALLATION >


[HALOGEN TYPE]

## REAR REFLEX REFLECTOR

Exploded View

INFOID:000000012201813


EXCEPT FOR NISMO AND NISMO RS




1. Rear bumper fascia lower


2. Rear reflex reflector LH

3. Rear reflex reflector RH

 : Pawl

 : N·m (kg·m, in·lb)

NISMO AND NISMO RS



1. Rear bumper fascia lower

2. Rear reflex reflector RH

3. Rear reflex reflector LH

 : Metal clip

 : Vehicle front

## Removal and Installation

INFOID:000000012201814

### REMOVAL

Except for NISMO and NISMO RS

1. Remove rear bumper fascia lower. Refer to [EXT-23, "Removal and Installation"](#).

## REAR REFLEX REFLECTOR


[HALOGEN TYPE]

### < REMOVAL AND INSTALLATION >

2. Remove rear reflex reflector fixing screw.
3. Disengage rear reflex reflector fixing pawls, and then remove rear reflex reflector.

#### NISMO and NISMO RS

1. Remove rear bumper fascia lower. Refer to [EXT-23. "Removal and Installation"](#).
2. Disengage rear reflex reflector fixing metal clip, and then remove rear reflex reflector according to numerical order 1→3 indicated by arrows as shown in the figure.



### INSTALLATION

Install in the reverse order of removal.

# SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[HALOGEN TYPE]

## SERVICE DATA AND SPECIFICATIONS (SDS)

### SERVICE DATA AND SPECIFICATIONS (SDS)

#### Bulb Specifications

INFOID:0000000012201815

#### EXCEPT FOR NISMO AND NISMO RS

Item	Type	Wattage (W)	
Headlamp	High Beam	HB3	60
	Low Beam	H11	55
Front combination lamp	Front turn signal lamp	WY21W (Amber)	21
	Front side marker lamp	W5W	5
	Parking lamp	LED	—
Front fog lamp	H11	55	
Side turn signal lamp	LED	—	
Rear combination lamp	Tail lamp (LED)	LED	—
	Stop lamp/Tail lamp (Rear side marker)	W21/5W	21/5
	Rear turn signal lamp	WY21W (Amber)	21
	Back-up lamp	W16W	16
High-mounted stop lamp	LED	—	
License plate lamp	W5W	5	

#### NISMO AND NISMO RS

Item	Type	Wattage (W)	
Headlamp	High Beam	HB3	60
	Low Beam	H11	55
Front combination lamp	Front turn signal lamp	WY21W (Amber)	21
	Front side marker lamp	W5W	5
	Parking lamp	LED	—
Daytime running light	LED	—	
Side turn signal lamp	LED	—	
Rear combination lamp	Tail lamp (LED)	LED	—
	Stop lamp/Tail lamp (Rear side marker)	W21/5W	21/5
	Rear turn signal lamp	WY21W (Amber)	21
	Back-up lamp	W16W	16
High-mounted stop lamp	LED	—	
License plate lamp	W5W	5	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P