

SECTION RSU

REAR SUSPENSION

CONTENTS

A
B
C
D

RSU

2WD	Inspection	15	F
PRECAUTION	SERVICE DATA AND SPECIFICATIONS (SDS)	16	G
PRECAUTIONS	SERVICE DATA AND SPECIFICATIONS (SDS)	16	H
Precautions for Suspension	Wheel Alignment	16	
Precautions for Removing Battery Terminal	Wheelarch Height	16	
PREPARATION	AWD		
PREPARATION	PRECAUTION	18	I
Commercial Service Tools	PRECAUTIONS	18	J
SYMPTOM DIAGNOSIS	Precautions for Suspension	18	
NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING	Precautions for Removing Battery Terminal	18	
NVH Troubleshooting Chart	PREPARATION	19	K
PERIODIC MAINTENANCE	PREPARATION	19	L
REAR SUSPENSION ASSEMBLY	Commercial Service Tools	19	
Inspection	SYMPTOM DIAGNOSIS	20	
WHEEL ALIGNMENT	NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING	20	M
Inspection	NVH Troubleshooting Chart	20	
REMOVAL AND INSTALLATION	PERIODIC MAINTENANCE	21	N
REAR SHOCK ABSORBER	REAR SUSPENSION ASSEMBLY	21	O
Exploded View	Inspection	21	
Removal and Installation	WHEEL ALIGNMENT	22	P
Inspection	Inspection	22	
COIL SPRING	Adjustment	22	
Exploded View	REMOVAL AND INSTALLATION	24	
Removal and Installation	REAR SHOCK ABSORBER	24	
Inspection	Exploded View	24	
REAR SUSPENSION BEAM	Removal and Installation	24	
Exploded View	Inspection	25	
Removal and Installation			

Disposal	26	Inspection	34
COIL SPRING	27	REAR STABILIZER	35
Exploded View	27	Exploded View	35
Removal and Installation	27	Removal and Installation	35
Inspection	28	Inspection	35
SUSPENSION ARM	29	REAR SUSPENSION ASSEMBLY	36
Exploded View	29	Exploded View	36
Removal and Installation	29	Removal and Installation	36
Inspection	30	Inspection	37
LOWER LINK	31	SERVICE DATA AND SPECIFICATIONS	
Exploded View	31	(SDS)	38
Removal and Installation	31	SERVICE DATA AND SPECIFICATIONS	
Inspection	32	(SDS)	38
UPPER LINK	33	Wheel Alignment	38
Exploded View	33	Wheelarch Height	38
Removal and Installation	33		

PRECAUTION

PRECAUTIONS

Precautions for Suspension

INFOID:0000000012200387

- When installing rubber bushings, the final tightening must be carried out under unladen conditions with tires on ground. Spilled oil might shorten the life of rubber bushings. Be sure to wipe off any spilled oil.
- Unladen conditions mean that fuel, engine coolant and lubricant are full. Spare tire, jack, hand tools and mats are in designated positions.
- After servicing suspension parts, be sure to check wheel alignment.
- Self-lock nuts are not reusable. Always use new ones when installing. Since new self-lock nuts are pre-oiled, tighten as they are.
- The tightening surface must be kept free from oil/grease.
- When jacking up the vehicle with a floor jack, never hang the jack on the suspension beam.


Precautions for Removing Battery Terminal

INFOID:0000000012926513

When disconnecting the battery terminal, pay attention to the following.

- Always use a 12V battery as power source.
- Never disconnect battery terminal while engine is running.
- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.
- For vehicles with the engine listed below, remove the battery terminal after a lapse of the specified time:

D4D engine	: 20 minutes	YS23DDT	: 4 minutes
HRA2DDT	: 12 minutes	YS23DDTT	: 4 minutes
K9K engine	: 4 minutes	ZD30DDTi	: 60 seconds
M9R engine	: 4 minutes	ZD30DDTT	: 60 seconds
R9M engine	: 4 minutes		
V9X engine	: 4 minutes		
YD25DDTi	: 2 minutes		



NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- After high-load driving, if the vehicle is equipped with the V9X engine, turn the ignition switch OFF and wait for at least 15 minutes to remove the battery terminal.

NOTE:

- Turbocharger cooling pump may operate in a few minutes after the ignition switch is turned OFF.
- Example of high-load driving
 - Driving for 30 minutes or more at 140 km/h (86 MPH) or more.
 - Driving for 30 minutes or more on a steep slope.
- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.

NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.

PREPARATION

< PREPARATION >


[2WD]

PREPARATION

PREPARATION

Commercial Service Tools

INFOID:0000000012200389

Tool name	Description
Power tool	Loosening bolts and nuts
 PBIC0190E	

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

< SYMPTOM DIAGNOSIS >

[2WD]

SYMPTOM DIAGNOSIS

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

NVH Troubleshooting Chart

INFOID:0000000012200390

Use chart below to find the cause of the symptom. If necessary, repair or replace these parts.

Reference			RSU-8, RSU-12, RSU-14	RSU-8	—	—	RSU-13	RSU-8, RSU-12, RSU-14	RSU-7	NVH in RAX and RSU sections	NVH in WT section	NVH in WT section	NVH in BR section
Possible cause and SUSPECTED PARTS			Improper installation, looseness	Shock absorber deformation, damage or deflection	Bushing or mounting deterioration	Parts interference	Spring fatigue	Suspension looseness	Incorrect wheel alignment	REAR AXLE AND REAR SUSPENSION	TIRE	ROAD WHEEL	BRAKE
Symptom	REAR SUSPENSION	Noise	x	x	x	x	x	x		x	x	x	x
		Shake	x	x	x	x		x		x	x	x	x
		Vibration	x	x	x	x	x			x	x		
		Shimmy	x	x	x	x			x	x	x	x	x
		Judder	x	x	x					x	x	x	x
		Poor quality ride or handling	x	x	x	x	x		x	x	x	x	

x: Applicable

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

RSU

PERIODIC MAINTENANCE

REAR SUSPENSION ASSEMBLY

Inspection

INFOID:0000000012200391

COMPONENT PART

Check the mounting conditions (looseness, backlash) of each component and component conditions (wear, damage) are normal.

SHOCK ABSORBER ASSEMBLY

Check for oil leakage, damage, and replace if necessary.

WHEEL ALIGNMENT

Inspection

INFOID:000000012200392

DESCRIPTION

CAUTION:

- The adjustment mechanisms of camber and toe-in are not included.
- If camber and toe-in is outside the standard, check front suspension parts for wear and damage. Replace suspect parts if a malfunction is detected.

Measure wheel alignment under unladen conditions.

NOTE:

"Unladen conditions" means that fuel, engine coolant, and lubricant are full. Spare tire, jack, hand tools and mats are in designated positions.

PRELIMINARY CHECK

Check the following:

- Tires for improper air pressure and wear. Refer to [WT-47, "Tire Air Pressure"](#).
- Road wheels for runout.
- Wheel bearing axial end play. Refer to [RAX-6, "Inspection"](#).
- Shock absorber operation.
- Each mounting point of axle and suspension for looseness and deformation.
- Each of rear suspension beam and shock absorber for cracks, deformation, and other damage.
- Vehicle height (posture).

GENERAL INFORMATION AND RECOMMENDATIONS

- A four-wheel thrust alignment should be performed.
- This type of alignment is recommended for any NISSAN/INFINITI vehicle.
- The four-wheel "thrust" process helps ensure that the vehicle is properly aligned and the steering wheel is centered.
- The alignment rack itself should be capable of accepting any NISSAN/INFINITI vehicle.
- The rack should be checked to ensure that it is level.
- Check the machine is properly calibrated.
- Your alignment equipment should be regularly calibrated in order to give correct information.
- Check with the manufacturer of your specific equipment for their recommended Service/Calibration Schedule.

ALIGNMENT PROCESS

IMPORTANT:

Use only the alignment specifications listed in this Service Manual.

- When displaying the alignment settings, many alignment machines use "indicators": (Green/red, plus or minus, Go/No Go). **Never use these indicators.**
- The alignment specifications programmed into your machine that operate these indicators may not be correct.
- This may result in an ERROR.
- Most camera-type alignment machines are equipped with both "Rolling Compensation" method and optional "Jacking Compensation" method to "compensate" the alignment targets or head units. "Rolling Compensation" is the preferred method.
- If using the "Rolling Compensation" method, after installing the alignment targets or head units, push or pull on the rear wheel to move the vehicle. **Do not push or pull on the vehicle body.**
- If using the "Jacking Compensation" method, after installing the alignment targets or head units, raise the vehicle and rotate the wheels 1/2 turn both ways.

NOTE:

- Do not use the "Rolling Compensation" method if you are using sensor-type alignment equipment.
- Follow all instructions for the alignment machine you're using for more information.

REAR SHOCK ABSORBER

< REMOVAL AND INSTALLATION >

[2WD]


REMOVAL AND INSTALLATION

REAR SHOCK ABSORBER

Exploded View

INFOID:000000012200393

EXCEPT FOR 18 INCH TIRE




- | | | |
|-------------------------|------------------------|-----------------|
| 1. Rear suspension beam | 2. Shock absorber | 3. Bound bumper |
| 4. Bound bumper cover | 5. Washer | 6. Bushing |
| 7. Distance tube | 8. Piston rod lock nut | 9. Cap |

⊗: Always replace after every disassembly.

⊞: N·m (kg·m, ft·lb)

FOR 18 INCH TIRE



- | | | |
|-------------------------|------------------------|-----------------|
| 1. Rear suspension beam | 2. Shock absorber | 3. Bound bumper |
| 4. Bound bumper cover | 5. Washer | 6. Bushing |
| 7. Distance tube | 8. Piston rod lock nut | 9. Cap |

REAR SHOCK ABSORBER

< REMOVAL AND INSTALLATION >

[2WD]

⊗: Always replace after every disassembly.


Ⓐ: N·m (kg·m, ft·lb)

Removal and Installation


INFOID:0000000012200394

REMOVAL

1. Remove tires with power tool. Refer to [WT-39. "Removal and Installation"](#).
2. Set suitable jack under rear suspension beam.
CAUTION:
 - **Never damage the suspension beam with a jack.**
 - **Check the stable condition when using a jack.**
3. Remove shock absorber mounting bolt (lower side) (1).
4. Remove shock absorber mask. Refer to [INT-33. "Exploded View"](#).
5. Remove cap.




6. Remove piston rod lock nut (1), and then remove washer and bushing.
NOTE:
To loosen piston rod lock nut, fix the tip (A) of the piston rod.
7. Remove shock absorber assembly.
8. Remove bushing, distance tube, washer, bound bumper cover, and bound bumper from shock absorber.
9. Perform inspection after removal. Refer to [RSU-10. "Inspection"](#).



INSTALLATION

Note the following, and install in the reverse order of removal.


- To install bushings (1), securely insert protrusion (A) into the hole on the vehicle body side.



- Install washer (1) in the direction shown in the figure.

⇐ : Bushing side

- Perform final tightening of bolts and nuts at the shock absorber lower side (rubber bushing), under unladen conditions with tires on level ground.



REAR SHOCK ABSORBER


[2WD]

< REMOVAL AND INSTALLATION >


- Hold a head (A) of shock absorber piston rod nut to have it rotate, then tighten the piston rod lock nut (1) to the specified torque.

CAUTION:

Never reuse piston rod lock nut.



- When installing the cap, securely engage the cap groove (A) with the flange on the vehicle side.
- Perform inspection after installation. Refer to [RSU-10, "Inspection"](#).
- After replacing the shock absorber, always follow the disposal procedure to discard the shock absorber. Refer to [RSU-10, "Inspection"](#).



INFOID:0000000012200395

Inspection

INSPECTION AFTER REMOVAL

Shock Absorber

Check the following items, and replace the part if necessary.

- Shock absorber for deformation, cracks, and other damage.
- Piston rod for damage, uneven wear, and distortion.
- Oil leakage.

Bound Bumper, Bushing

Check for cracks and damage. Replace it if necessary.

Washer, Bound Bumper Cover, Distance Tube

- Check for cracks and damage. Replace it if necessary.

INSPECTION AFTER INSTALLATION

1. Check wheel alignment. Refer to [RSU-7, "Inspection"](#).
2. Adjust neutral position of steering angle sensor. Refer to [BRC-63, "Work Procedure"](#).

Disposal

INFOID:0000000012200396


1. Set shock absorber horizontally to the ground with the piston rod fully extracted.
2. Drill 2 – 3 mm (0.08 – 0.12 in) hole at the position (●) from top as shown in the figure to release gas gradually.

CAUTION:

- **Wear eye protection (safety glasses).**
- **Wear gloves.**
- **Be careful with metal chips or oil blown out by the compressed gas.**

NOTE:

- Drill vertically in this direction.
- Directly to the outer tube avoiding brackets.
- The gas is clear, colorless, odorless, and harmless.



A : 20 – 30 mm (0.79 – 1.18 in)

REAR SHOCK ABSORBER

< REMOVAL AND INSTALLATION >

[2WD]

3. Position the drilled hole downward and drain oil by moving the piston rod several times.

CAUTION:

Dispose of drained oil according to the law and local regulations.

A

B

C

D

RSU

F

G

H

I

J

K

L

M

N

O

P

COIL SPRING


< REMOVAL AND INSTALLATION >

[2WD]

COIL SPRING

Exploded View

INFOID:0000000012200397



Removal and Installation

INFOID:0000000012200398

REMOVAL

1. Remove tires with power tool. Refer to [WT-39, "Removal and Installation"](#).

2. Set jack under rear suspension beam.

CAUTION:

- Never damage the suspension beam with a jack.
- Check the stable condition when using a jack.


3. Remove rear shock absorber mounting bolts (lower side). Refer to [RSU-8, "Exploded View"](#).

4. Slowly lower jack, then remove upper rubber seat, coil spring and lower rubber seat from rear suspension beam.

CAUTION:

Operate while checking that jack supporting status is stable.

5. Perform inspection after removal. Refer to [RSU-13, "Inspection"](#).




INSTALLATION

Note the following, and install in the reverse order of removal.

- Install lower rubber seat with its protrusion (A) on the lower area aligned with the hole of rear suspension beam.

B : Coil spring lower end




COIL SPRING

< REMOVAL AND INSTALLATION >


[2WD]

- Match up lower rubber seat (1) indentions and rear suspension beam (2) grooves (A) and attach.




- Securely install coil spring (1) with the lower end of the major diameter aligned with the steps of lower rubber seat (2).

Dimension (A) : 5 mm (0.20 in) or less



- Install coil spring (1) by aligning upper end of coil spring with upper seat (2) in to the protrusion of body side as shown in the figure.
- Perform inspection after installation. Refer to [RSU-13, "Inspection"](#).



Inspection

INFOID:0000000012200399

INSPECTION AFTER REMOVAL

Check rubber seat and coil spring for deformation, crack, and damage. Replace it if necessary.

INSPECTION AFTER INSTALLATION

- Check wheel alignment. Refer to [RSU-7, "Inspection"](#).
- Adjust neutral position of steering angle sensor. Refer to [BRC-63, "Work Procedure"](#).

REAR SUSPENSION BEAM


< REMOVAL AND INSTALLATION >

[2WD]

REAR SUSPENSION BEAM

Exploded View

INFOID:0000000012200400



1. Rear suspension beam
2. Rear suspension arm bracket

⊗: Always replace after every disassembly.

⊞: N·m (kg-m, ft-lb)

Removal and Installation

INFOID:0000000012200401

REMOVAL

1. Remove tires with power tool. Refer to [WT-39, "Removal and Installation"](#).
2. Drain brake fluid. Refer to [BR-12, "Draining"](#).
3. Remove wheel sensor and sensor harness. Refer to [BRC-150, "REAR WHEEL SENSOR : Removal and Installation"](#).
4. Remove brake caliper assembly. Refer to [BR-64, "BRAKE CALIPER ASSEMBLY : Removal and Installation"](#).
5. Remove disc rotor. Refer to [RAX-7, "Removal and Installation"](#).
6. Remove parking brake shoe assembly. Refer to [PB-9, "Removal and Installation"](#).
7. Remove parking brake cable from back plate and rear suspension beam. Refer to [PB-7, "Removal and Installation"](#).
8. Separate brake hose and brake tube. Refer to [BR-32, "REAR : Removal and Installation"](#).
9. Set suitable jack under rear suspension beam.
CAUTION:
 - Never damage the suspension beam with a jack.
 - Check the stable condition when using a jack.
10. Remove shock absorber mounting bolts (lower side). Refer to [RSU-9, "Removal and Installation"](#).
11. Remove coil spring. Refer to [RSU-12, "Removal and Installation"](#).
12. Remove rear suspension arm bracket mounting bolts.
13. Remove rear suspension arm beam mounting bolts and nuts.
14. Slowly lower jack, remove rear suspension arm bracket and rear suspension beam from vehicle.
CAUTION:
 - Operate while checking that jack supporting status is stable.
15. Remove wheel hub assembly. Refer to [RAX-7, "Removal and Installation"](#).
16. Remove rear suspension arm bracket from rear suspension beam.

REAR SUSPENSION BEAM

< REMOVAL AND INSTALLATION >

[2WD]

17. Perform inspection after removal. Refer to [RSU-15, "Inspection"](#).

INSTALLATION

Note the following, and install in the reverse order of removal.


- Never reuse rear suspension beam mounting nut.
- To install rear suspension arm bracket to the vehicle, temporarily tighten the bolts before tightening to the specified torque, referring to the tightening method and the numerical order shown below:

Temporary tightening : 1 → 2 → 3 → 4

Final tightening (specified torque) : 5 → 6 → 3 → 4 → 1 → 2 → 7 → 8

← : Vehicle front

- Perform final tightening of rear suspension beam installation position (rubber bushing), under unladen conditions with tires on level ground.
- Perform inspection after installation. Refer to [RSU-15, "Inspection"](#).



INFOID:0000000012200402

Inspection

INSPECTION AFTER REMOVAL

Check rear suspension beam and rear suspension beam bracket for deformation, cracks or damage. Replace the part if necessary.

INSPECTION AFTER INSTALLATION

1. Check wheel sensor harness for proper connection. Refer to [BRC-148, "REAR WHEEL SENSOR : Exploded View"](#).
2. Adjust parking brake. Refer to [PB-4, "Inspection and Adjustment"](#).
3. Check wheel alignment. Refer to [RSU-7, "Inspection"](#).
4. Adjust neutral position of steering angle sensor. Refer to [BRC-63, "Work Procedure"](#).

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[2WD]

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

Wheel Alignment

INFOID:0000000012200403

FOR USA MODELS

Item		Standard
Camber Degree minute (Decimal degree)	Minimum	-2° 01' (-2.01°)
	Nominal	-1° 31' (-1.52°)
	Maximum	-1° 01' (-1.02°)
Toe-in	Total toe-in Distance	Minimum Out 1.1 mm (Out 0.043 in)
		Nominal In 2.9 mm (In 0.114 in)
		Maximum In 6.9 mm (In 0.272 in)
	Toe angle (left wheel and right wheel)*1 Degree minute (Decimal degree)	Minimum Out 0° 05' 00" (Out 0.08°)
		Nominal In 0° 15' 00" (In 0.25°)
		Maximum In 0° 35' 00" (In 0.58°)

Measure value under unladen*2 conditions.

*1: Since adjustment mechanism is not included, the value of the left and right wheels (both wheels) must be used as the standard value.

*2: Fuel, engine coolant and lubricant are full. Spare tire, jack, hand tools and mats are in designated positions.

FOR CANADA MODELS

Item		Standard
Camber Degree minute (Decimal degree)	Minimum	-2° 01' (-2.01°)
	Nominal	-1° 31' (-1.52°)
	Maximum	-1° 01' (-1.02°)
Toe-in	Total toe-in Distance	Minimum Out 1.2 mm (Out 0.047 in)
		Nominal In 2.8 mm (In 0.11 in)
		Maximum In 6.8 mm (In 0.268 in)
	Toe angle (left wheel and right wheel)*1 Degree minute (Decimal degree)	Minimum Out 0° 06' 00" (Out 0.10°)
		Nominal In 0° 14' 00" (In 0.23°)
		Maximum In 0° 34' 00" (In 0.56°)

Measure value under unladen*2 conditions.

*1: Since adjustment mechanism is not included, the value of the left and right wheels (both wheels) must be used as the standard value.

*2: Fuel, engine coolant and lubricant are full. Spare tire, jack, hand tools and mats are in designated positions.

Wheelarch Height

INFOID:0000000012200404

FOR USA MODELS


Item	Standard	NISMO	NISMO RS	Standard
Transmission	M/T			CVT
Tire Size	17 inch	18 inch		17 inch
Front (Hf)	734 mm (28.90 in)	724 mm (28.50 in)	725 mm (28.54 in)	735 mm (28.94 in)

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[2WD]

Item	Standard	NISMO	NISMO RS	Standard
Transmission	M/T			CVT
Tire Size	17 inch	18 inch		17 inch
Rear (Hr)	745 mm (29.33 in)	738 mm (29.06 in)	739 mm (29.09 in)	746 mm (29.37 in)




SFA746B

Measure value under unladen* conditions.

*: Fuel, engine coolant and lubricant are full. Spare tire, jack, hand tools and mats are in designated positions.

FOR CANADA MODELS

Item	Standard	NISMO	NISMO RS	Standard
Transmission	M/T			CVT
Tire Size	17 inch	18 inch		17 inch
Front (Hf)	735 mm (28.94 in)	727 mm (28.62 in)	725 mm (28.54 in)	735 mm (28.94 in)
Rear (Hr)	745 mm (29.33 in)	740 mm (29.13 in)	740 mm (29.13 in)	746 mm (29.37 in)



SFA746B

Measure value under unladen* conditions.

*: Fuel, engine coolant and lubricant are full. Spare tire, jack, hand tools and mats are in designated positions.

PRECAUTION

PRECAUTIONS

Precautions for Suspension

INFOID:0000000012200405

- When installing rubber bushings, the final tightening must be carried out under unladen conditions with tires on ground. Spilled oil might shorten the life of rubber bushings. Be sure to wipe off any spilled oil.
- Unladen conditions mean that fuel, engine coolant and lubricant are full. Spare tire, jack, hand tools and mats are in designated positions.
- After servicing suspension parts, be sure to check wheel alignment.
- Self-lock nuts are not reusable. Always use new ones when installing. Since new self-lock nuts are pre-oiled, tighten as they are.
- The tightening surface must be kept free from oil/grease.


Precautions for Removing Battery Terminal

INFOID:0000000012926560

When disconnecting the battery terminal, pay attention to the following.

- Always use a 12V battery as power source.
- Never disconnect battery terminal while engine is running.
- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.
- For vehicles with the engine listed below, remove the battery terminal after a lapse of the specified time:

D4D engine	: 20 minutes	YS23DDT	: 4 minutes
HRA2DDT	: 12 minutes	YS23DDTT	: 4 minutes
K9K engine	: 4 minutes	ZD30DDTi	: 60 seconds
M9R engine	: 4 minutes	ZD30DDTT	: 60 seconds
R9M engine	: 4 minutes		
V9X engine	: 4 minutes		
YD25DDTi	: 2 minutes		

**NOTE:**

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- After high-load driving, if the vehicle is equipped with the V9X engine, turn the ignition switch OFF and wait for at least 15 minutes to remove the battery terminal.

NOTE:

- Turbocharger cooling pump may operate in a few minutes after the ignition switch is turned OFF.
- Example of high-load driving
 - Driving for 30 minutes or more at 140 km/h (86 MPH) or more.
 - Driving for 30 minutes or more on a steep slope.
- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.

NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.

PREPARATION

< PREPARATION >


[AWD]

PREPARATION

PREPARATION

Commercial Service Tools

INFOID:0000000012200407

Tool name	Description
Power tool	Loosening bolts and nuts
 PBIC0190E	

A

B

C

D

RSU

F

G

H

I

J

K

L

M

N

O

P

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

< SYMPTOM DIAGNOSIS >

[AWD]

SYMPTOM DIAGNOSIS

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

NVH Troubleshooting Chart

INFOID:0000000012200408

Use chart below to find the cause of the symptom. If necessary, repair or replace these parts.

Symptom			Possible cause and SUSPECTED PARTS										Reference									
Symptom	REAR SUSPENSION	Noise	x	x	x	x	x	x														RSU-24, RSU-27, RSU-29, RSU-31, RSU-33, RSU-35, RSU-36
		Shake	x	x	x	x		x														RSU-25
		Vibration	x	x	x	x	x															—
		Shimmy	x	x	x	x																—
		Judder	x	x	x																	RSU-28
		Poor quality ride or handling	x	x	x	x				x	x											
																						RSU-22
																						RSU-35
																						NVH in DLN section.
																						NVH in DLN section.
																						NVH in RAX and RSU sections.
																						NVH in WT section.
																						NVH in WT section.
																						NVH in RAX section.
																						NVH in BR section.
																						NVH in ST section.

x: Applicable

PERIODIC MAINTENANCE

REAR SUSPENSION ASSEMBLY

Inspection

INFOID:0000000012200409

MOUNTING INSPECTION

Check the mounting conditions (looseness, backlash) of each component and component conditions (wear, damage) are normal.

SHOCK ABSORBER

Check for oil leakage and damage. Replace it if necessary.

A

B

C

D

RSU

F

G

H

I

J

K

L

M

N

O

P

WHEEL ALIGNMENT

Inspection

INFOID:0000000012200410

DESCRIPTION

Measure wheel alignment under unladen conditions.

NOTE:

"Unladen conditions" means that fuel, engine coolant, and lubricant are full. Spare tire, jack, hand tools and mats are in designated positions.

PRELIMINARY CHECK

Check the following:

- Tires for improper air pressure and wear. Refer to [WT-47, "Tire Air Pressure"](#).
- Road wheels for runout.
- Wheel bearing axial end play. Refer to [RAX-14, "Inspection"](#).
- Shock absorber operation.
- Each mounting point of axle and suspension for looseness and deformation.
- Each of lower link, upper link, rear suspension member, suspension arm, and shock absorber for cracks, deformation, and other damage.
- Vehicle height (posture).

GENERAL INFORMATION AND RECOMMENDATIONS

- A four-wheel thrust alignment should be performed.
- This type of alignment is recommended for any NISSAN/INFINITI vehicle.
- The four-wheel "thrust" process helps ensure that the vehicle is properly aligned and the steering wheel is centered.
- The alignment rack itself should be capable of accepting any NISSAN/INFINITI vehicle.
- The rack should be checked to ensure that it is level.
- Make sure the machine is properly calibrated.
- Your alignment equipment should be regularly calibrated in order to give correct information.
- Check with the manufacturer of your specific equipment for their recommended Service/Calibration Schedule.

ALIGNMENT PROCESS

IMPORTANT:

Use only the alignment specifications listed in this Service Manual.

- When displaying the alignment settings, many alignment machines use "indicators": (Green/red, plus or minus, Go/No Go). **Never use these indicators.**
- The alignment specifications programmed into your machine that operate these indicators may not be correct.
- This may result in an ERROR.
- Most camera-type alignment machines are equipped with both "Rolling Compensation" method and optional "Jacking Compensation" method to "compensate" the alignment targets or head units. "Rolling Compensation" is the preferred method.
- If using the "Rolling Compensation" method, after installing the alignment targets or head units, push or pull on the rear wheel to move the vehicle. **Do not push or pull on the vehicle body.**
- If using the "Jacking Compensation" method, after installing the alignment targets or head units, raise the vehicle and rotate the wheels 1/2 turn both ways.

NOTE:

- Do not use the "Rolling Compensation" method if you are using sensor-type alignment equipment.
- Follow all instructions for the alignment machine you're using for more information.

Adjustment

INFOID:0000000012200411

CAMBER, TOE-IN

CAUTION:

- **Adjust camber first, then adjust toe-in last. never change the order.**
 - **If camber angle needs to be adjusted, toe-in adjustment is necessary.**
 - **Minimize difference of left and right toe-in within tolerance.**
1. Loosen mounting nuts of upper link and lower link on the suspension member side.

WHEEL ALIGNMENT

< PERIODIC MAINTENANCE >

[AWD]

- Adjust camber and toe-in by turning upper link adjusting bolt (1) and lower link adjusting bolt (2) alternately.

A : Left side
B : Right side

NOTE:

Upper link adjusting bolt

Positive direction : Upper link slides into inner side of vehicle.


Negative direction : Upper link slides into outer side of vehicle.

Lower link adjusting bolt

Positive direction : Lower link slides into outer side of vehicle.

Negative direction : Lower link slides into inner side of vehicle.

- Refer to the table below for easier adjustment.



- Obtain the amount of camber and toe-in by calculating the difference between the measurement result and the standard value.
 - Obtain the needed adjustment amount from the graph and move adjusting bolts, respectively.
- After adjustment, tighten mounting nuts of upper link and lower link on the suspension member side.
CAUTION:
When tightening nut to the specified torque, the bolt must be fixed with a wrench.
 - Adjust neutral position of steering angle sensor. Refer to [BRC-63. "Work Procedure"](#).

REAR SHOCK ABSORBER

< REMOVAL AND INSTALLATION >


[AWD]

REMOVAL AND INSTALLATION

REAR SHOCK ABSORBER

Exploded View

INFOID:0000000012200412



- | | | |
|-----------------------|------------------------|-----------------|
| 1. Suspension arm | 2. Shock absorber | 3. Bound bumper |
| 4. Bound bumper cover | 5. Washer | 6. Bushing |
| 7. Distance tube | 8. Piston rod lock nut | 9. Cap |

↔: Vehicle front

⊗: Always replace after every disassembly.

Ⓔ: N·m (kg-m, ft-lb)

Removal and Installation

INFOID:0000000012200413

REMOVAL

1. Remove tires with power tool. Refer to [WT-39, "Removal and Installation"](#).
2. Set suitable jack under suspension arm.

CAUTION:


- Never damage the suspension arm with a jack.
- Check the stable condition when using a jack.

3. Remove shock absorber mounting bolt and nut (lower side).
4. Remove shock absorber mask. Refer to [INT-33, "Exploded View"](#).
5. Remove cap.
6. Remove piston rod lock nut (1), and then remove washer and bushing.

NOTE:

To loosen piston rod lock nut, fix the tip (A) of the piston rod.

7. Remove shock absorber assembly.
8. Remove bushing, distance tube, bound bumper cover, and bound bumper from shock absorber.
9. Perform inspection after removal. Refer to [RSU-25, "Inspection"](#).



INSTALLATION


REAR SHOCK ABSORBER

[AWD]

< REMOVAL AND INSTALLATION >

Note the following, and install in the reverse order of removal.


- To install bushings (1), securely insert protrusion (A) into the hole on the vehicle body side.



- Install washer (1) in the direction shown in the figure.

← : Bushing side


- Perform final tightening of bolts and nuts at the shock absorber lower side (rubber bushing), under unladen conditions with tires on level ground.




- Hold a head (A) of shock absorber piston rod nut to have it rotate, then tighten the piston rod lock nut (1) to the specified torque.

CAUTION:

Never reuse piston rod lock nut.



- When installing the cap, securely engage the cap groove (A) with the flange on the vehicle side.
- Perform inspection after installation. Refer to [RSU-25, "Inspection"](#).
- After replacing the shock absorber, always follow the disposal procedure to discard the shock absorber. Refer to [RSU-25, "Inspection"](#).



INFOID:000000012200414

Inspection

INSPECTION AFTER REMOVAL

Shock Absorber

Check the following items, and replace the part if necessary.

- Shock absorber for deformation, cracks, and other damage.
- Piston rod for damage, uneven wear, and distortion.
- Oil leakage.

REAR SHOCK ABSORBER

[AWD]

< REMOVAL AND INSTALLATION >

Bound Bumper, Bushing

Check for cracks and damage. Replace it if necessary.

Washer, Bound Bumper Cover, Distance Tube

- Check for cracks and damage. Replace it if necessary.

INSPECTION AFTER INSTALLATION

1. Check wheel alignment. Refer to [RSU-22. "Inspection"](#).
2. Adjust neutral position of steering angle sensor. Refer to [BRC-63. "Work Procedure"](#).

Disposal

INFOID:0000000012200415


1. Set shock absorber horizontally to the ground with the piston rod fully extracted.
2. Drill 2 – 3 mm (0.08 – 0.12 in) hole at the position (●) from top as shown in the figure to release gas gradually.

CAUTION:

- Wear eye protection (safety glasses).
- Wear gloves.
- Be careful with metal chips or oil blown out by the compressed gas.

NOTE:

- Drill vertically in this direction.
- Directly to the outer tube avoiding brackets.
- The gas is clear, colorless, odorless, and harmless.



A : 20 – 30 mm (0.79 – 1.18 in)

3. Position the drilled hole downward and drain oil by moving the piston rod several times.

CAUTION:

Dispose of drained oil according to the law and local regulations.

COIL SPRING


< REMOVAL AND INSTALLATION >

[AWD]

COIL SPRING

Exploded View

INFOID:0000000012200416



1. Upper rubber seat

2. Coil spring

3. Lower rubber seat

4. Suspension arm

⇐: Vehicle front

Removal and Installation

INFOID:0000000012200417

REMOVAL

1. Remove tires with power tool. Refer to [WT-39, "Removal and Installation"](#).
2. Remove wheel sensor and sensor harness. Refer to [BRC-150, "REAR WHEEL SENSOR : Removal and Installation"](#).
3. Set jack under suspension arm.
CAUTION:
 - Never damage the suspension arm with a jack.
 - Check the stable condition when using a jack.
4. Separate rear shock absorber lower side from suspension arm. Refer to [RSU-24, "Removal and Installation"](#).
5. Separate upper link from suspension arm.
6. Slowly lower jack, then remove upper rubber seat, coil spring and lower rubber seat from suspension arm.
CAUTION:
Operate while checking that jack supporting status is stable.
7. Perform inspection after removal. Refer to [RSU-28, "Inspection"](#).

INSTALLATION


Note the following, and install in the reverse order of removal.

COIL SPRING

< REMOVAL AND INSTALLATION >


[AWD]

- Install the lower rubber seat a projection (A) is attached as suspension arm mounting hole (B).
- Match up lower rubber seat indentions and suspension arm grooves and attach.




- Install coil spring (1) lower end with spring end holding section (B) of lower rubber seat (2).

Dimension (A) : 10 mm (0.20 in) or less



- Match up coil spring (1) upper end to the centre of upper rubber seat (2) projection (A) as shown in figure.
- Perform inspection after installation. Refer to [RSU-28. "Inspection"](#).



Inspection

INFOID:0000000012200418

INSPECTION AFTER REMOVAL

Check rubber seat and coil spring for deformation, crack, and damage. Replace it if necessary.

INSPECTION AFTER INSTALLATION

1. Check wheel sensor harness for proper connection. Refer to [BRC-148. "REAR WHEEL SENSOR : Exploded View"](#).
2. Check wheel alignment. Refer to [RSU-22. "Inspection"](#).
3. Adjust neutral position of steering angle sensor. Refer to [BRC-63. "Work Procedure"](#).

SUSPENSION ARM


< REMOVAL AND INSTALLATION >

[AWD]

SUSPENSION ARM

Exploded View

INFOID:0000000012200419



- | | | |
|---------------------------|-------------------|---------------------------|
| 1. Rear suspension member | 2. Adjusting bolt | 3. Upper link |
| 4. Eccentric disk | 5. Lower link | 6. Suspension arm bracket |
| 7. Suspension arm | | |

← Vehicle front

⊗: Always replace after every disassembly.

⊞: N·m (kg-m, ft-lb)

Removal and Installation

INFOID:0000000012200420

REMOVAL

1. Remove tires with power tool. Refer to [WT-39, "Removal and Installation"](#).
2. Drain brake fluid. Refer to [BR-12, "Draining"](#).
3. Remove wheel sensor and sensor harness. Refer to [BRC-150, "REAR WHEEL SENSOR : Removal and Installation"](#).
4. Remove caliper assembly. Hang caliper assembly in a place where it will not interfere with work. Refer to [BR-64, "BRAKE CALIPER ASSEMBLY : Removal and Installation"](#).
CAUTION:
Never depress brake pedal while brake caliper is removed.
5. Remove disc rotor. Refer to [RAX-16, "Removal and Installation"](#).
6. Remove parking brake cable mounting bolt. Refer to [PB-7, "Removal and Installation"](#).
7. Separate the brake tube from the brake hose, and remove lock plate. Refer to [BR-27, "REAR : Exploded View"](#).
8. Remove wheel hub and bearing assembly. Refer to [RAX-16, "Removal and Installation"](#).
9. Remove parking brake shoe and back plate. Refer to [PB-9, "Removal and Installation"](#).

SUSPENSION ARM

[AWD]

< REMOVAL AND INSTALLATION >

10. Set jack under suspension arm.

CAUTION:

- **Never damage the suspension arm with a jack.**
- **Check the stable condition when using a jack.**

11. Remove stabilizer link. Refer to [RSU-35, "Removal and Installation"](#).

12. Remove upper link from suspension arm. Refer to [RSU-33, "Removal and Installation"](#).

13. Remove lower link from suspension arm. Refer to [RSU-31, "Removal and Installation"](#).

14. Remove coil spring from suspension arm. Refer to [RSU-27, "Removal and Installation"](#).

15. Remove suspension arm bracket from vehicle.

16. Remove suspension arm from suspension arm bracket.

17. Perform inspection after removal. Refer to [RSU-30, "Inspection"](#).

INSTALLATION

Note the following, and install in the reverse order of removal.

- Perform final tightening of rear suspension member installation position (rubber bushing), under unladen conditions with tires on level ground.
- Never reuse suspension arm mounting nut.
- Perform inspection after installation. Refer to [RSU-30, "Inspection"](#).

Inspection

INFOID:0000000012200421

INSPECTION AFTER REMOVAL

Check suspension arm and bushing for deformation, cracks or damage. Replace it if necessary.

INSPECTION AFTER INSTALLATION

1. Check wheel sensor harness for proper connection. Refer to [BRC-148, "REAR WHEEL SENSOR : Exploded View"](#).
2. Adjust parking brake operation (stroke). Refer to [PB-4, "Inspection and Adjustment"](#).
3. Check wheel alignment. Refer to [RSU-22, "Inspection"](#).
4. Adjust neutral position of steering angle sensor. Refer to [BRC-63, "Work Procedure"](#).

LOWER LINK


< REMOVAL AND INSTALLATION >

[AWD]

LOWER LINK

Exploded View

INFOID:0000000012200422



- | | | |
|---------------------------|-------------------|---------------------------|
| 1. Rear suspension member | 2. Adjusting bolt | 3. Upper link |
| 4. Eccentric disk | 5. Lower link | 6. Suspension arm bracket |
| 7. Suspension arm | | |

← Vehicle front

⊗: Always replace after every disassembly.

⌘: N·m (kg-m, ft-lb)

Removal and Installation

INFOID:0000000012200423

REMOVAL

1. Remove tires with power tool. Refer to [WT-39, "Removal and Installation"](#).
2. Set jack under suspension arm.
CAUTION:
 - **Never damage the suspension arm with a jack.**
 - **Check the stable condition when using a jack.**
3. Remove stabilizer link. Refer to [RSU-35, "Removal and Installation"](#).
4. Remove eccentric disc, adjusting bolt, mounting bolt, and nut, then remove lower link.
5. Perform inspection after removal. Refer to [RSU-32, "Inspection"](#).

INSTALLATION

Note the following, and install in the reverse order of removal.

- Perform final tightening of rear suspension member and axle installation position (rubber bushing), under unladen conditions with tires on level ground.
- Never reuse lower link mounting nut.
- Perform inspection after installation. Refer to [RSU-32, "Inspection"](#).

Inspection

INFOID:0000000012200424

INSPECTION AFTER REMOVAL

Check lower link and bushing for any deformation, cracks, or damage. Replace it if necessary.

INSPECTION AFTER INSTALLATION

1. Check wheel alignment. Refer to [RSU-22, "Inspection"](#).
2. Adjust neutral position of steering angle sensor. Refer to [BRC-63, "Work Procedure"](#).

UPPER LINK


< REMOVAL AND INSTALLATION >

[AWD]

UPPER LINK

Exploded View

INFOID:0000000012200425



- | | | |
|---------------------------|-------------------|---------------------------|
| 1. Rear suspension member | 2. Adjusting bolt | 3. Upper link |
| 4. Eccentric disk | 5. Lower link | 6. Suspension arm bracket |
| 7. Suspension arm | | |

↔: Vehicle front

⊗: Always replace after every disassembly.

⊗: N·m (kg-m, ft-lb)

Removal and Installation

INFOID:0000000012200426

REMOVAL

1. Remove tires with power tool. Refer to [WT-39, "Removal and Installation"](#).
2. Remove wheel sensor and sensor harness. Refer to [BRC-150, "REAR WHEEL SENSOR : Removal and Installation"](#).
3. Set jack under suspension arm.
CAUTION:
 - Never damage the suspension arm with a jack.
 - Check the stable condition when using a jack.
4. Remove eccentric disc, adjusting bolt, mounting bolt, and nut, then remove upper link.
5. Perform inspection after removal. Refer to [RSU-34, "Inspection"](#).

INSTALLATION

Note the following, and install in the reverse order of removal.

- Perform final tightening of rear suspension member and axle installation position (rubber bushing), under unladen conditions with tires on level ground.
- Never reuse upper link mounting nut.
- Perform inspection after installation. Refer to [RSU-34, "Inspection"](#).

Inspection

INFOID:0000000012200427

INSPECTION AFTER REMOVAL

Check upper link and bushing for any deformation, cracks, or damage. Replace it if necessary.

INSPECTION AFTER INSTALLATION

1. Check wheel sensor harness for proper connection. Refer to [BRC-148, "REAR WHEEL SENSOR : Exploded View"](#).
2. Check wheel alignment. Refer to [RSU-22, "Inspection"](#).
3. Adjust neutral position of steering angle sensor. Refer to [BRC-63, "Work Procedure"](#).

REAR STABILIZER


< REMOVAL AND INSTALLATION >

[AWD]

REAR STABILIZER

Exploded View

INFOID:0000000012200428



- | | | |
|--------------------|---------------|---------------------------|
| 1. Stabilizer bar | 2. Bushing | 3. Stabilizer clamp |
| 4. Stabilizer link | 5. Lower link | 6. Rear suspension member |

←: Vehicle front

⊗: Always replace after every disassembly.

⊞: N·m (kg·m, ft·lb)

Removal and Installation

INFOID:0000000012200429

REMOVAL

1. Remove stabilizer link.
2. Remove center muffler. Refer to [EX-10. "Removal and Installation"](#).
3. Remove mounting nuts on stabilizer clamp, bushing, and stabilizer bar from suspension member.
4. Perform inspection after removal. Refer to [RSU-35. "Inspection"](#).

INSTALLATION

Note the following, and install in the reverse order of removal.

- Perform final tightening of rear suspension member and axle installation position (rubber bushing), under unladen conditions with tires on level ground.
- Never reuse stabilizer link mounting nut.

Inspection

INFOID:0000000012200430

INSPECTION AFTER REMOVAL

Check stabilizer bar, stabilizer link, stabilizer bushing and stabilizer clamp for deformation, cracks or damage. Replace it if necessary.

REAR SUSPENSION ASSEMBLY


< REMOVAL AND INSTALLATION >

[AWD]

REAR SUSPENSION ASSEMBLY

Exploded View

INFOID:0000000012200431



1. Rear suspension member 2. Rebound stopper 3. Washer

↔: Vehicle front

Ⓜ: N·m (kg-m, ft-lb)

Removal and Installation

INFOID:0000000012200432

REMOVAL

1. Remove tires with power tool. Refer to [WT-39, "Removal and Installation"](#).
2. Remove center muffler. Refer to [EX-10, "Removal and Installation"](#).
3. Remove propeller shaft. Refer to [DLN-124, "Removal and Installation"](#).
4. Remove stabilizer bar. Refer to [RSU-35, "Removal and Installation"](#).
5. Remove wheel sensor and sensor harness. Refer to [BRC-150, "REAR WHEEL SENSOR : Removal and Installation"](#).
6. Remove upper link from suspension arm. Refer to [RSU-33, "Removal and Installation"](#).
7. Remove lower link from suspension arm. Refer to [RSU-31, "Removal and Installation"](#).
8. Remove drive shaft from rear final drive. Refer to [RAX-19, "Removal and Installation"](#).
9. Remove rear final drive. Refer to [DLN-151, "Removal and Installation"](#).
10. Set jack under rear suspension member.

CAUTION:

- Never damage the suspension member with a jack.
- Check the stable condition when using a jack.

11. Remove rear suspension member mounting bolts, rebound stopper, and washer.
12. Slowly lower jack, then remove rear suspension member, lower link and upper link from vehicle as a unit.

CAUTION:

Operate while checking that jack supporting status is stable.

13. Remove lower link and upper link from rear suspension member.
14. Perform inspection after removal. Refer to [RSU-37, "Inspection"](#).

INSTALLATION

Note the following, and install in the reverse order of the removal.

REAR SUSPENSION ASSEMBLY


< REMOVAL AND INSTALLATION >

[AWD]

- To install mounting bolts of the suspension member, temporarily tighten them in numerical order shown in the figure and tighten them to the specified torque.

← : Vehicle front

- Perform the final tightening of each parts removed when removing rear suspension assembly under unladen conditions.
- Perform inspection after installation. Refer to [RSU-37, "Inspection"](#).



INFOID:0000000012200433

Inspection

INSPECTION AFTER REMOVAL

Check rear suspension member for deformation, cracks, or any other damage. Replace it if necessary.

INSPECTION AFTER INSTALLATION

1. Check wheel sensor harness for proper connection. Refer to [BRC-148, "REAR WHEEL SENSOR : Exploded View"](#).
2. Check wheel alignment. Refer to [RSU-22, "Inspection"](#).
3. Adjust neutral position of steering angle sensor. Refer to [BRC-63, "Work Procedure"](#).

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[AWD]

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

Wheel Alignment

INFOID:0000000012200434

FOR USA MODELS

Item			Standard	NISMO	NISMO RS
Tire Size			17 inch	18 inch	
Camber Degree minute (Decimal degree)		Minimum	−0° 45′ (−0.75°)	−0° 41′ (−0.68°)	
		Nominal	0° 00′ (0.00°)	0° 4′ (0.07°)	
		Maximum	0° 45′ (0.75°)	0° 49′ (0.81°)	
Toe-in	Total toe-in Distance	Minimum	In 1.0 mm (In 0.04 in)		
		Nominal	In 3.0 mm (In 0.12 in)		
		Maximum	In 5.0 mm (In 0.20 in)		
	Total toe-angle Degree minute (Decimal degree)	Minimum	In 0° 06′ 00″ (In 0.10°)	In 0° 11′ 00″ (In 0.18°)	
		Nominal	In 0° 16′ 00″ (In 0.27°)	In 0° 21′ 00″ (In 0.35°)	
		Maximum	In 0° 26′ 00″ (In 0.43°)	In 0° 31′ 00″ (In 0.52°)	

Measure value under unladen* conditions.

*: Fuel, engine coolant and lubricant are full. Spare tire, jack, hand tools and mats are in designated positions.

FOR CANADA MODELS

Item			Standard	NISMO	NISMO RS
Tire Size			17 inch	18 inch	
Camber Degree minute (Decimal degree)		Minimum	−0° 43′ (−0.71°)		
		Nominal	0° 02′ (0.03°)		
		Maximum	0° 47′ (0.78°)		
Toe-in	Total toe-in Distance	Minimum	In 1.0 mm (In 0.04 in)		
		Nominal	In 3.0 mm (In 0.12 in)		
		Maximum	In 5.0 mm (In 0.20 in)		
	Total toe-angle Degree minute (Decimal degree)	Minimum	In 0° 05′ 00″ (In 0.08°)	In 0° 07′ 00″ (In 0.12°)	
		Nominal	In 0° 15′ 00″ (In 0.25°)	In 0° 17′ 00″ (In 0.28°)	
		Maximum	In 0° 25′ 00″ (In 0.42°)	In 0° 27′ 00″ (In 0.45°)	

Measure value under unladen* conditions.

*: Fuel, engine coolant and lubricant are full. Spare tire, jack, hand tools and mats are in designated positions.

Wheelarch Height

INFOID:0000000012200435

FOR USA MODELS


Item	Standard	NISMO	NISMO RS
Tire Size	17 inch	18 inch	
Front (Hf)	734 mm (28.90 in)	724 mm (28.50 in)	

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[AWD]

Item	Standard	NISMO	NISMO RS
Tire Size	17 inch	18 inch	
Rear (Hr)	741 mm (29.17 in)	735 mm (28.94 in)	




SFA746B

Measure value under unladen* conditions.

*: Fuel, engine coolant and lubricant are full. Spare tire, jack, hand tools and mats are in designated positions.

FOR CANADA MODELS

Item	Standard	NISMO	NISMO RS
Tire Size	17 inch	18 inch	
Front (Hf)	735 mm (28.94 in)	726 mm (28.58 in)	724 mm (28.50 in)
Rear (Hr)	741 mm (29.17 in)	735 mm (28.94 in)	735 mm (28.94 in)



SFA746B

Measure value under unladen* conditions.

*: Fuel, engine coolant and lubricant are full. Spare tire, jack, hand tools and mats are in designated positions.