

A
B
C

EXL

SECTION EXL

EXTERIOR LIGHTING SYSTEM

D
E

CONTENTS

LED HEADLAMP		
PRECAUTION	6	
PRECAUTIONS	6	
Precaution for Technicians Using Medical Electric.....	6	
Point to Be Checked Before Starting Maintenance Work	6	
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	6	
Precaution for Removing 12V Battery	7	
PREPARATION	8	
PREPARATION	8	
Special Service Tool	8	
SYSTEM DESCRIPTION	9	
COMPONENT PARTS	9	
Component Parts Location	9	
LED Headlamp	10	
LED Headlamp Control Module	11	
Optical Sensor	11	
Hazard Switch	12	
SYSTEM	13	
HEADLAMP SYSTEM	13	
HEADLAMP SYSTEM : System Description	13	
HEADLAMP SYSTEM : Fail-Safe	14	
AUTO LIGHT SYSTEM (EXCEPT FOR CANADA)...	14	
AUTO LIGHT SYSTEM (EXCEPT FOR CANADA) : System Description	14	
AUTO LIGHT SYSTEM (EXCEPT FOR CANADA) : Circuit Diagram	16	
AUTO LIGHT SYSTEM (FOR CANADA)	16	
AUTO LIGHT SYSTEM (FOR CANADA) : System Description	17	
AUTO LIGHT SYSTEM (FOR CANADA) : Circuit Diagram	19	
DAYTIME RUNNING LIGHT SYSTEM	19	
DAYTIME RUNNING LIGHT SYSTEM : System Description	20	
TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM	20	
TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : System Description	21	
PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM	21	
PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM : System Description	21	
PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM : Fail-Safe	22	
FRONT FOG LAMP SYSTEM	22	
FRONT FOG LAMP SYSTEM : System Description	23	
FRONT FOG LAMP SYSTEM : Circuit Diagram	24	
FRONT FOG LAMP SYSTEM : Fail-Safe	24	
EXTERIOR LAMP BATTERY SAVER SYSTEM	25	
EXTERIOR LAMP BATTERY SAVER SYSTEM : System Description	25	
EXTERIOR LAMP BATTERY SAVER SYSTEM : Circuit Diagram	26	
DIAGNOSIS SYSTEM (BCM)	27	
COMMON ITEM	27	
COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)	27	
HEADLAMP	27	
HEADLAMP : CONSULT Function (BCM - HEAD LAMP)	28	
FLASHER	29	

EXL

FLASHER : CONSULT Function (BCM - FLASH-ER)	29	FRONT SIDE MARKER LAMP CIRCUIT	77
DIAGNOSIS SYSTEM (IPDM E/R)	30	Component Function Check	77
Diagnosis Description	30	Diagnosis Procedure	77
CONSULT Function (IPDM E/R)	31	TAIL LAMP CIRCUIT	78
ECU DIAGNOSIS INFORMATION	33	Component Function Check	78
BCM, IPDM E/R	33	Diagnosis Procedure	78
List of ECU Reference	33	LICENSE PLATE LAMP CIRCUIT	80
WIRING DIAGRAM	34	Component Function Check	80
EXTERIOR LIGHTING SYSTEM	34	Diagnosis Procedure	80
Wiring Diagram	34	FRONT FOG LAMP CIRCUIT	81
BASIC INSPECTION	60	Component Function Check	81
DIAGNOSIS AND REPAIR WORKFLOW	60	Diagnosis Procedure	81
Work Flow	60	TURN SIGNAL LAMP CIRCUIT	83
LED HEADLAMP OPERATION INSPECTION..	63	Component Function Check	83
Diagnosis Procedure	63	Diagnosis Procedure	83
DTC/CIRCUIT DIAGNOSIS	64	OPTICAL SENSOR	85
HEADLAMP (HI) CIRCUIT	64	Component Function Check	85
WITHOUT DAYTIME RUNNING LIGHT SYSTEM ...	64	Diagnosis Procedure	85
WITHOUT DAYTIME RUNNING LIGHT SYSTEM		HAZARD SWITCH	88
: Component Function Check	64	Component Function Check	88
WITHOUT DAYTIME RUNNING LIGHT SYSTEM		Diagnosis Procedure	88
: Diagnosis Procedure	64	SYMPTOM DIAGNOSIS	90
WITH DAYTIME RUNNING LIGHT SYSTEM	65	EXTERIOR LIGHTING SYSTEM SYMPTOMS..	90
WITH DAYTIME RUNNING LIGHT SYSTEM :		WITHOUT DAYTIME RUNNING LIGHT SYSTEM ...	90
Component Function Check	65	WITHOUT DAYTIME RUNNING LIGHT SYSTEM	
WITH DAYTIME RUNNING LIGHT SYSTEM : Di-		: Symptom Table	90
agnosis Procedure	66	WITH DAYTIME RUNNING LIGHT SYSTEM	92
HEADLAMP (LO) CIRCUIT	68	WITH DAYTIME RUNNING LIGHT SYSTEM :	
Component Function Check	68	Symptom Table	92
Diagnosis Procedure	68	NORMAL OPERATING CONDITION	95
DAYTIME RUNNING LIGHT RELAY CIRCUIT		Description	95
... 70		BOTH SIDE HEADLAMPS (HI) ARE NOT	
Component Function Check	70	TURNED ON	96
Diagnosis Procedure	70	WITHOUT DAYTIME RUNNING LIGHT SYSTEM ...	96
Component Inspection	71	WITHOUT DAYTIME RUNNING LIGHT SYSTEM	
LED HEADLAMP	72	: Description	96
Diagnosis Procedure	72	WITHOUT DAYTIME RUNNING LIGHT SYSTEM	
HEADLAMP WARNING LAMP	73	: Diagnosis Procedure	96
Component Function Check	73	WITH DAYTIME RUNNING LIGHT SYSTEM	96
Diagnosis Procedure	73	WITH DAYTIME RUNNING LIGHT SYSTEM : De-	
PARKING LAMP CIRCUIT	75	scription	96
Component Function Check	75	WITH DAYTIME RUNNING LIGHT SYSTEM : Di-	
Diagnosis Procedure	75	agnosis Procedure	96
		BOTH SIDE HEADLAMPS (LO) ARE NOT	
		TURNED ON	98
		Description	98
		Diagnosis Procedure	98

PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS ARE NOT TURNED ON99	Replacement 122	
Description99		A
Diagnosis Procedure99		
BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON 100	REAR REFLEX REFLECTOR 124	B
Description 100	Exploded View 124	
Diagnosis Procedure 100	Removal and Installation 124	
PERIODIC MAINTENANCE 101	SERVICE DATA AND SPECIFICATIONS (SDS) 125	C
HEADLAMP AIMING ADJUSTMENT 101	SERVICE DATA AND SPECIFICATIONS (SDS) 125	D
Description 101	Bulb Specifications 125	
Aiming Adjustment Procedure 102	HALOGEN HEADLAMP	
FRONT FOG LAMP AIMING ADJUSTMENT .. 103	PRECAUTION 126	E
Description 103	PRECAUTIONS 126	
Aiming Adjustment Procedure 103	Precaution for Technicians Using Medical Electric. 126	F
REMOVAL AND INSTALLATION 105	Point to Be Checked Before Starting Maintenance Work 126	
FRONT COMBINATION LAMP 105	Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" 126	G
Exploded View 105	Precaution for Removing 12V Battery 127	
Removal and Installation 106	PREPARATION 128	H
Bulb Replacement 106	PREPARATION 128	
Disassembly and Assembly 107	Special Service Tool 128	I
Installing service bracket 108	SYSTEM DESCRIPTION 129	
FRONT SIDE MARKER LAMP 109	COMPONENT PARTS 129	J
Exploded View 109	Component Parts Location 129	
Removal and Installation 109	Optical Sensor 130	K
Bulb Replacement 109	Hazard Switch 130	
FRONT FOG LAMP 111	SYSTEM 131	
Exploded View 111	HEADLAMP SYSTEM 131	EXL
Removal and Installation 111	HEADLAMP SYSTEM : System Description 131	
Replacement 111	HEADLAMP SYSTEM : Fail-Safe 131	
LIGHTING & TURN SIGNAL SWITCH 113	AUTO LIGHT SYSTEM (EXCEPT FOR CANADA) . 132	M
Exploded View 113	AUTO LIGHT SYSTEM (EXCEPT FOR CANADA) : System Description 132	
OPTICAL SENSOR 114	AUTO LIGHT SYSTEM (EXCEPT FOR CANADA) : Circuit Diagram 134	N
Exploded View 114	AUTO LIGHT SYSTEM (FOR CANADA) 134	
Removal and Installation 114	AUTO LIGHT SYSTEM (FOR CANADA) : System Description 135	O
HAZARD SWITCH 115	AUTO LIGHT SYSTEM (FOR CANADA) : Circuit Diagram 137	P
Exploded View 115	DAYTIME RUNNING LIGHT SYSTEM 137	
Removal and Installation 115	DAYTIME RUNNING LIGHT SYSTEM : System Description 138	
REAR COMBINATION LAMP 116	TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM 138	
Exploded View 116		
Removal and Installation 116		
Replacement 118		
HIGH-MOUNTED STOP LAMP 121		
Exploded View 121		
Removal and Installation 121		
LICENSE PLATE LAMP 122		
Exploded View 122		
Removal and Installation 122		

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : System Description	139	WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Component Function Check	182
PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM	139	WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure	182
PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM : System Description ..	139	WITH DAYTIME RUNNING LIGHT SYSTEM	183
PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM : Circuit Diagram	140	WITH DAYTIME RUNNING LIGHT SYSTEM :	
PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM : Fail-Safe	142	Component Function Check	183
FRONT FOG LAMP SYSTEM	143	WITH DAYTIME RUNNING LIGHT SYSTEM : Di-	
FRONT FOG LAMP SYSTEM : System Description	143	agnosis Procedure	184
FRONT FOG LAMP SYSTEM : Circuit Diagram ..	144	HEADLAMP (LO) CIRCUIT	186
FRONT FOG LAMP SYSTEM : Fail-Safe	144	Component Function Check	186
EXTERIOR LAMP BATTERY SAVER SYSTEM	145	Diagnosis Procedure	186
EXTERIOR LAMP BATTERY SAVER SYSTEM :			
System Description	145	DAYTIME RUNNING LIGHT RELAY CIRCUIT ..	188
EXTERIOR LAMP BATTERY SAVER SYSTEM :		Component Function Check	188
Circuit Diagram	146	Diagnosis Procedure	188
DIAGNOSIS SYSTEM (BCM)	147	Component Inspection	189
COMMON ITEM	147	PARKING LAMP CIRCUIT	190
COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)	147	Component Function Check	190
HEADLAMP	147	Diagnosis Procedure	190
HEADLAMP : CONSULT Function (BCM - HEAD LAMP)	148	FRONT SIDE MARKER LAMP CIRCUIT	192
FLASHER	149	Component Function Check	192
FLASHER : CONSULT Function (BCM - FLASHER)	149	Diagnosis Procedure	192
DIAGNOSIS SYSTEM (IPDM E/R)	150	TAIL LAMP CIRCUIT	193
Diagnosis Description	150	Component Function Check	193
CONSULT Function (IPDM E/R)	151	Diagnosis Procedure	193
ECU DIAGNOSIS INFORMATION	153	LICENSE PLATE LAMP CIRCUIT	195
BCM, IPDM E/R	153	Component Function Check	195
List of ECU Reference	153	Diagnosis Procedure	195
WIRING DIAGRAM	154	FRONT FOG LAMP CIRCUIT	196
EXTERIOR LIGHTING SYSTEM	154	Component Function Check	196
Wiring Diagram	154	Diagnosis Procedure	196
BASIC INSPECTION	179	TURN SIGNAL LAMP CIRCUIT	198
DIAGNOSIS AND REPAIR WORKFLOW	179	Component Function Check	198
Work Flow	179	Diagnosis Procedure	198
DTC/CIRCUIT DIAGNOSIS	182	OPTICAL SENSOR	200
HEADLAMP (HI) CIRCUIT	182	Component Function Check	200
WITHOUT DAYTIME RUNNING LIGHT SYSTEM ..	182	Diagnosis Procedure	200
		HAZARD SWITCH	203
		Component Function Check	203
		Diagnosis Procedure	203
		SYMPTOM DIAGNOSIS	205
		EXTERIOR LIGHTING SYSTEM SYMPTOMS.	205
		WITHOUT DAYTIME RUNNING LIGHT SYSTEM .	205
		WITHOUT DAYTIME RUNNING LIGHT SYSTEM	
		: Symptom Table	205
		WITH DAYTIME RUNNING LIGHT SYSTEM	206

WITH DAYTIME RUNNING LIGHT SYSTEM :	Bulb Replacement	221	
Symptom Table	Disassembly and Assembly	222	A
	Installing service bracket	222	
NORMAL OPERATING CONDITION	FRONT SIDE MARKER LAMP	224	B
Description	Exploded View	224	
	Removal and Installation	224	
BOTH SIDE HEADLAMPS (HI) ARE NOT	Bulb Replacement	224	C
TURNED ON	FRONT FOG LAMP	226	
	Exploded View	226	
WITHOUT DAYTIME RUNNING LIGHT SYSTEM..	Removal and Installation	226	D
WITHOUT DAYTIME RUNNING LIGHT SYSTEM	Replacement	226	
: Description			
WITHOUT DAYTIME RUNNING LIGHT SYSTEM	LIGHTING & TURN SIGNAL SWITCH	228	E
: Diagnosis Procedure	Exploded View	228	
	OPTICAL SENSOR	229	F
WITH DAYTIME RUNNING LIGHT SYSTEM	Exploded View	229	
WITH DAYTIME RUNNING LIGHT SYSTEM : De-	Removal and Installation	229	
scription	HAZARD SWITCH	230	G
WITH DAYTIME RUNNING LIGHT SYSTEM : Di-	Exploded View	230	
agnosis Procedure	Removal and Installation	230	
	REAR COMBINATION LAMP	231	H
BOTH SIDE HEADLAMPS (LO) ARE NOT	Exploded View	231	
TURNED ON	Removal and Installation	231	
Description	Replacement	233	I
Diagnosis Procedure	HIGH-MOUNTED STOP LAMP	236	
	Exploded View	236	
PARKING, LICENSE PLATE, SIDE MARKER	Removal and Installation	236	J
AND TAIL LAMPS ARE NOT TURNED ON ...	LICENSE PLATE LAMP	237	
... 214	Exploded View	237	
Description	Removal and Installation	237	K
Diagnosis Procedure	Replacement	237	
	REAR REFLEX REFLECTOR	238	EXL
BOTH SIDE FRONT FOG LAMPS ARE NOT	Exploded View	238	
TURNED ON	Removal and Installation	238	
Description	SERVICE DATA AND SPECIFICATIONS		M
Diagnosis Procedure	(SDS)	239	
	SERVICE DATA AND SPECIFICATIONS		N
PERIODIC MAINTENANCE	(SDS)	239	
216	Bulb Specifications	239	O
HEADLAMP AIMING ADJUSTMENT			P
216			
Description			
Aiming Adjustment Procedure			
217			
FRONT FOG LAMP AIMING ADJUSTMENT ..			
218			
Description			
Aiming Adjustment Procedure			
218			
REMOVAL AND INSTALLATION			
220			
FRONT COMBINATION LAMP			
220			
Exploded View			
220			
Removal and Installation			
220			

PRECAUTION

PRECAUTIONS

Precaution for Technicians Using Medical Electric

INFOID:000000009354876

OPERATION PROHIBITION

WARNING:

- Parts with strong magnet is used in this vehicle.
- Technicians using a medical electric device such as pacemaker must never perform operation on the vehicle, as magnetic field can affect the device function by approaching to such parts.

NORMAL CHARGE PRECAUTION

WARNING:

- If a technician uses a medical electric device such as an implantable cardiac pacemaker or an implantable cardioverter defibrillator, the possible effects on the devices must be checked with the device manufacturer before starting the charge operation.
- As radiated electromagnetic wave generated by PDM (Power Delivery Module) at normal charge operation may affect medical electric devices, a technician using a medical electric device such as implantable cardiac pacemaker or an implantable cardioverter defibrillator must not approach motor room [PDM (Power Delivery Module)] at the hood-opened condition during normal charge operation.

PRECAUTION AT TELEMATICS SYSTEM OPERATION

WARNING:

- If a technician uses implantable cardiac pacemaker or implantable cardioverter defibrillator (ICD), avoid the device implanted part from approaching within approximately 220 mm (8.66 in) from interior/exterior antenna.
- The electromagnetic wave of TCU might affect the function of the implantable cardiac pacemaker or the implantable cardioverter defibrillator (ICD), when using the service, etc.
- If a technician uses other medical electric devices than implantable cardiac pacemaker or implantable cardioverter defibrillator (ICD), the electromagnetic wave of TCU might affect the function of the device. The possible effects on the devices must be checked with the device manufacturer before TCU use.

PRECAUTION AT INTELLIGENT KEY SYSTEM OPERATION

WARNING:

- If a technician uses implantable cardiac pacemaker or implantable cardioverter defibrillator (ICD), avoid the device implanted part from approaching within approximately 220 mm (8.66 in) from interior/exterior antenna.
- The electromagnetic wave of Intelligent Key might affect the function of the implantable cardiac pacemaker or the implantable cardioverter defibrillator (ICD), at door operation, at each request switch operation, or at engine starting.
- If a technician uses other medical electric devices than implantable cardiac pacemaker or implantable cardioverter defibrillator (ICD), the electromagnetic wave of Intelligent Key might affect the function of the device. The possible effects on the devices must be checked with the device manufacturer before Intelligent Key use.

Point to Be Checked Before Starting Maintenance Work

INFOID:000000008746528

The high voltage system may starts automatically. It is required to check that the timer air conditioner and timer charge (during EVSE connection) are not set before starting maintenance work.

NOTE:

If the timer air conditioner or timer charge (during EVSE connection) is set, the high voltage system starts automatically even when the power switch is in OFF state.

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009316218

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS

PRECAUTIONS

[LED HEADLAMP]

< PRECAUTION >

system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

Precaution for Removing 12V Battery

INFOID:000000008746530

1. Check that EVSE is not connected.

NOTE:

If EVSE is connected, the air conditioning system may be automatically activated by the timer A/C function.

2. Turn the power switch OFF → ON → OFF. Get out of the vehicle. Close all doors (including back door).
3. Check that the charge status indicator lamp does not blink and wait for 5 minutes or more.

NOTE:

If the battery is removed within 5 minutes after the power switch is turned OFF, plural DTCs may be detected.

4. Remove 12V battery within 1 hour after turning the power switch OFF → ON → OFF.

NOTE:

- The 12V battery automatic charge control may start automatically even when the power switch is in OFF state.
- Once the power switch is turned ON → OFF, the 12V battery automatic charge control does not start for approximately 1 hour.

CAUTION:

- After all doors (including back door) are closed, if a door (including back door) is opened before battery terminals are disconnected, start over from Step 1.
- After turning the power switch OFF, if "Remote A/C" is activated by user operation, stop the air conditioner and start over from Step 1.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

PREPARATION

< PREPARATION >

[LED HEADLAMP]

PREPARATION


PREPARATION

Special Service Tool

INFOID:000000009347910

The actual shape of the tools may differ from those illustrated here.

Tool number (TechMate No.) Tool name	Description
— (J-46534) Trim Tool Set	Removing trim components



AWJIA0483ZZ

COMPONENT PARTS

< SYSTEM DESCRIPTION >



[LED HEADLAMP]

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000008746532



ALLIA1267ZZ

A. Front combination lamp (back)

No.	Part	Function
1.	IPDM E/R	<ul style="list-style-type: none"> Controls the integrated relay, and supplies voltage to the load according to the request from BCM (via CAN communication). Refer to PCS-6, "Component Parts Location" for detailed installation location.
2.	Combination switch (Lighting & turn signal switch)	Refer to BCS-8, "COMBINATION SWITCH READING SYSTEM : System Description" .
3.	Combination meter	<ul style="list-style-type: none"> Blinks the turn signal indicator lamp and outputs the turn signal operating sound with integrated buzzer according to the request from BCM (via CAN communication). Turns the tail lamp indicator lamp, high beam indicator lamp, front fog lamp indicator lamp and rear fog lamp indicator lamp ON according to the request from BCM (via CAN communication). Inputs headlamp warning lamp signal from LED headlamp control module and turns headlamp warning lamp ON.
4.	Hazard switch	Refer to EXL-12, "Hazard Switch" .

A
B
C
D
E
F
G
H
I
J
K

EXL

M
N
O
P

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[LED HEADLAMP]

No.	Part	Function
5.	BCM	<ul style="list-style-type: none"> • Detects each switch condition by the combination switch reading function • Judges that the exterior lamps are turned ON according to the vehicle condition • Requests the headlamp relay (HI/LO), tail lamp relay and front fog lamp relay ON to IPDM E/R (via CAN communication) • Requests the high beam indicator lamp, tail lamp indicator lamp and front fog lamp indicator lamp ON to the combination meter (via CAN communication) • Judges the outside brightness from the optical sensor signal. • Judges the ON/OFF timing according to the vehicle condition. • Judges the ON/OFF status of the exterior lamp according to the outside brightness and the vehicle condition. • Refer to BCS-5. "BODY CONTROL SYSTEM : Component Parts Location" for detailed installation location.
6.	Optical sensor	Refer to EXL-11. "Optical Sensor" .
7.	Front side marker lamp	Refer to EXL-125. "Bulb Specifications" .
8.	Front turn signal lamp	Refer to EXL-125. "Bulb Specifications" .
9.	Headlamp LO (LED headlamp)	Refer to EXL-13. "HEADLAMP SYSTEM : System Description" .
10.	Headlamp HI	Refer to EXL-125. "Bulb Specifications" .
11.	Parking Lamp	Refer to EXL-125. "Bulb Specifications" .
12.	Front fog lamp	Refer to EXL-125. "Bulb Specifications" .
13.	Daytime running light relay*	Headlamp HI ground circuit is switched according to request from IPDM E/R.
15.	Front door switch (driver side)	Refer to DLK-20. "Door Switch" .
16.	Rear side marker lamp	Refer to EXL-125. "Bulb Specifications" .
17.	Tail lamp	Refer to EXL-125. "Bulb Specifications" .
18.	Rear turn signal lamp	Refer to EXL-125. "Bulb Specifications" .
18.	License plate lamp	Refer to EXL-125. "Bulb Specifications" .
19.	LED headlamp control module	Refer to EXL-11. "LED Headlamp Control Module" .

*: With daytime running light system

LED Headlamp


INFOID:000000008746533

OUTLINE

- Semiconductor device (Light emitting diode: LED), which is illuminated when forward bias electric voltage is applied, is adopted as the source of light instead of halogen bulb or xenon bulb.
- Comparing to halogen headlamp or xenon headlamp, LED headlamp is electrically power saving, durable, and is illuminated in the similar color to the sunlight. Bright, natural, and eye-friendly visibility can be obtained.

ILLUMINATION PRINCIPLE

White LED emits the white light through fluorescent substance on luminescent surface of blue LED using semiconductor (joint construction of P type and N type).



COMPONENT PARTS

< SYSTEM DESCRIPTION >

[LED HEADLAMP]

1. When forward bias electric voltage is applied to LED, hole (positive characteristics) and electron (negative characteristics) move toward each electrode, and electric current flows.
2. Hole and electron move inside of semiconductor crystal and are connected (re-connection) again at connecting portion. A part of energies that is produced at this moment is emitted as the light.

PRECAUTIONS FOR TROUBLE DIAGNOSIS

Representative malfunction examples are; "Light does not turn ON", "Light blinks", and "Brightness is inadequate." Such malfunctions, however, occasionally occur by LED control module malfunction or lamp case malfunction. Specify the malfunctioning part with diagnosis procedure.

CAUTION:

- Never touch the harness, LED headlamp control module, the inside and metal part of lamp when turning the headlamp ON or operating the lighting switch, for preventing electrical shock.
- Never work with wet hands, for preventing electrical shock.
- Never perform LED headlamp control module circuit diagnosis with a circuit tester or an equivalent.
- Temporarily install the headlamps on the vehicle. Always connect power supply to the connector (vehicle side) when checking ON/OFF status.
- Disconnect the 12V battery negative terminal before disconnecting the lamp socket connector or the harness connector. Refer to [EXL-7, "Precaution for Removing 12V Battery"](#).
- Check for fusing of the fusible link(s), open around connector, short, disconnection if the symptom is caused by electric error.
- Always check for deformation or hole of headlamp housing and engagement of bulb cover. Otherwise, water may enter into headlamp because of damage of headlamp housing and contact to LED headlamp control module connector. The normal operation may be inhibited when short circuit to power supply is detected.


NOTE:

Turn the switch OFF once before turning ON, if the ON/OFF is inoperative.

LED Headlamp Control Module

INFOID:000000008746534


- Headlamp (LO) circuit is connected to LED headlamp control module integrated in the front combination lamp.
- Headlamp (LO) circuit turns LED headlamp ON.
- Outputs the headlamp warning lamp signal to the combination meter.



Optical Sensor

INFOID:000000008746535

Optical sensor converts the outside brightness (lux) to voltage and transmits the optical sensor signal to BCM.



COMPONENT PARTS


< SYSTEM DESCRIPTION >

[LED HEADLAMP]

Hazard Switch

INFOID:000000008746538

Inputs the hazard switch ON/OFF signal to BCM.




SYSTEM

HEADLAMP SYSTEM

HEADLAMP SYSTEM : System Description

INFOID:000000008746539

SYSTEM DIAGRAM



OUTLINE

Headlamp is controlled by combination switch reading function and headlamp control function of BCM, and relay control function of IPDM E/R.

HEADLAMP (LO) OPERATION

- BCM detects the combination switch condition with the combination switch reading function.
- BCM transmits the low beam request signal to IPDM E/R with CAN communication according to the headlamp (LO) ON condition.

Headlamp (LO) ON condition

- Lighting switch 2ND
- Lighting switch AUTO (auto light function ON judgment)
- Lighting switch AUTO, with the front fog lamp switch ON and the power switch ON
- Lighting switch PASS
- IPDM E/R turns integrated headlamp low relay ON according to low beam request signal and supplies power supply to LED headlamp control module.
- LED headlamp control module turns the headlamp (LO) ON according to the power supply from IPDM E/R.

HEADLAMP (HI) OPERATION

- BCM transmits the high beam request signal to IPDM E/R and the combination meter with CAN communication according to the headlamp (HI) ON condition.

Headlamp (HI) ON condition

- Lighting switch HI with the lighting switch 2ND or AUTO (auto light function ON judgment)
- Lighting switch PASS
- Lighting switch AUTO, with the front fog lamp switch ON, the power switch ON and lighting switch HI
- Combination meter turns the high beam indicator lamp ON according to the high beam request signal.
- IPDM E/R turns the integrated headlamp high relay ON, and turns the headlamp ON according to the high beam request signal.

HEADLAMP WARNING LAMP OPERATION

- LED headlamp control module outputs the headlamp warning lamp signal to combination meter when the following malfunction is detected.
 - LED
 - LED headlamp control module
 - Circuit between LED headlamp control module and LED.
 - Circuit between LED headlamp control module and combination meter.

SYSTEM

[LED HEADLAMP]

< SYSTEM DESCRIPTION >

- Combination meter turn the headlamp warning lamp ON according to the headlamp warning lamp signal inputs.

NOTE:

Headlamp LO may turn ON while headlamp warning lamp is turned ON, because 2 pieces of LED are used so that headlamp may continuously turn ON even if one of LED is not operative.

HEADLAMP SYSTEM : Fail-Safe

INFOID:000000008746541

CAN COMMUNICATION CONTROL

When CAN communication with BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If No CAN Communication Is Available With BCM


Control part	Fail-safe operation
Headlamp	<ul style="list-style-type: none">• Turns ON the headlamp low relay when the power switch is turned ON• Turns OFF the headlamp low relay when the power switch is turned OFF• Headlamp high relay OFF

AUTO LIGHT SYSTEM (EXCEPT FOR CANADA)

AUTO LIGHT SYSTEM (EXCEPT FOR CANADA) : System Description

INFOID:000000008746542

SYSTEM DIAGRAM



OUTLINE

- Auto light system is controlled by each function of BCM and IPDM E/R.

Control by BCM

- Combination switch reading function
- Headlamp control function
- Auto light function
- Delay timer function
- Wiper linked auto lighting function
- Auto light adjustment system

Control by IPDM E/R

- Relay control function
- Auto light system has the auto light function (with twilight lighting function), wiper linked auto lighting function and delay timer function.
- Auto light function automatically turns ON/OFF the exterior lamps* and each illumination automatically, depending on the outside brightness.
- Wiper linked auto lighting function automatically turns ON/OFF the exterior lamps* and each illumination when the light switch is in the AUTO position, according to a front wiper operation.

SYSTEM

< SYSTEM DESCRIPTION >

[LED HEADLAMP]

- When auto light system turns the exterior lamps ON with the power switch OFF, delay timer function turns the exterior lamps OFF, depending on the vehicle condition with the auto light function after a certain period of time.

*: Headlamp (LO/HI), parking lamp, tail lamp, front fog lamp and side marker lamp (Headlamp HI and front fog lamp depend on the combination switch condition.)

NOTE:

The settings of the twilight lighting function and the wiper linked auto lighting function can be changed with CONSULT. Refer to [EXL-28, "HEADLAMP : CONSULT Function \(BCM - HEAD LAMP\)"](#).

AUTO LIGHT FUNCTION (WITH TWILIGHT LIGHTING FUNCTION)

Description

- BCM detects the combination switch condition with the combination switch reading function.
- BCM supplies voltage to the optical sensor when the power switch is turned ON or ACC.
- Optical sensor converts outside brightness (lux) to voltage and transmits the optical sensor signal to BCM.
- BCM filters outside brightness based on the optical sensor signal and judges outside brightness.
- BCM detects change status of outside brightness according to outside brightness from the optical sensor signal and filtered outside brightness. Based on the change status, BCM judges ON/OFF condition of the exterior lamp.
- BCM transmits each request signal to IPDM E/R and combination meter via CAN communication, according to ON/OFF condition by the auto light function.

NOTE:

As to ON/OFF timing, the sensitivity depends on settings. The settings can be changed with CONSULT. Refer to [EXL-28, "HEADLAMP : CONSULT Function \(BCM - HEAD LAMP\)"](#).

WIPER LINKED AUTO LIGHTING FUNCTION

BCM turns the exterior lamps ON when detecting 4 operations of the front wiper work the light switch in AUTO position.

NOTE:

BCM turns OFF the headlamps 3 seconds after the front wiper switch is turned from ON⇒OFF.

AUTO LIGHT ADJUSTMENT SYSTEM

The auto light adjustment system automatically, dims/brightens the display and combination meter, according to brightness outside the vehicle, when lighting switch 1ST, lighting switch 2ND or lighting switch AUTO is operated. Refer to [INL-11, "AUTO LIGHT ADJUSTMENT SYSTEM : System Description"](#).

DELAY TIMER FUNCTION

BCM turns the exterior lamps OFF depending on the vehicle condition with the auto light function when the power switch is turned OFF.

- Turns the exterior lamps OFF 5 minutes after detecting that any door opens. (Door switch ON).
- Turns the exterior lamps OFF a certain period of time* after closing all doors. (Door switch ON→OFF).
- Turns the exterior lamps OFF with the power switch ACC or the light switch OFF.

*: The preset time is 45 seconds. The timer operating time can be set by CONSULT. Refer to [EXL-28, "HEAD-LAMP : CONSULT Function \(BCM - HEAD LAMP\)"](#).

NOTE:

When any position other than the light switch AUTO is set, the auto light system function switches to the exterior lamp battery saver function.


A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

EXL

AUTO LIGHT SYSTEM (FOR CANADA) : System Description

INFOID:000000008746544

SYSTEM DIAGRAM



OUTLINE

- Auto light system is controlled by each function of BCM and IPDM E/R.

Control by BCM

- Combination switch reading function
- Headlamp control function
- Auto light function
- Delay timer function
- Auto light adjustment system

Control by IPDM E/R

- Relay control function
- Auto light system has the auto light function and delay timer function.
- Auto light function automatically turns ON/OFF the exterior lamps* and each illumination automatically, depending on the outside brightness.
- When auto light system turns the exterior lamps ON with the power switch OFF, delay timer function turns the exterior lamps OFF, depending on the vehicle condition with the auto light function after a certain period of time.

*: Headlamp (LO/Hi), parking lamp, side marker lamp, tail lamp and front fog lamp (Headlamp HI and front fog lamp depend on the combination switch condition.)

AUTO LIGHT FUNCTION

- BCM detects the combination switch condition with the combination switch reading function.
- BCM supplies voltage to optical sensor when the power switch is turned ON or ACC.
- Optical sensor converts outside brightness (lux) to voltage and transmits the optical sensor signal to BCM.
- BCM judges outside brightness from the optical sensor signal and judges ON/OFF condition of the exterior lamp and each illumination according to the outside brightness.
- BCM transmits each request signal to IPDM E/R and combination meter via CAN communication according to ON/OFF condition by the auto light function.

NOTE:

ON/OFF timing differs based on the sensitivity from the setting. The setting can be set by CONSULT. Refer to [EXL-28. "HEADLAMP : CONSULT Function \(BCM - HEAD LAMP\)".](#)

AUTO LIGHT ADJUSTMENT SYSTEM

The auto light adjustment system automatically, dims/brightens the display, according to brightness outside the vehicle, when lighting switch 1ST, lighting switch 2ND or lighting switch AUTO is operated. Refer to [INL-11. "AUTO LIGHT ADJUSTMENT SYSTEM : System Description".](#)

DELAY TIMER FUNCTION

SYSTEM

< SYSTEM DESCRIPTION >

[LED HEADLAMP]

BCM turns the exterior lamp OFF depending on the vehicle condition with the auto light function when the power switch is turned OFF.

- Turns the exterior lamp OFF 5 minutes after detecting that any door opens. (Door switch ON).
- Turns the exterior lamp OFF a certain period of time* after closing all doors. (Door switch ON→OFF).
- Turns the exterior lamp OFF with the power switch ACC or the light switch OFF.

*: The preset time is 45 seconds. The timer operating time can be set by CONSULT. Refer to [EXL-28, "HEAD-LAMP : CONSULT Function \(BCM - HEAD LAMP\)"](#).

NOTE:

When any position other than the light switch AUTO is set, the auto light system function switches to the exterior lamp battery saver function.


SYSTEM

[LED HEADLAMP]

< SYSTEM DESCRIPTION >

AUTO LIGHT SYSTEM (FOR CANADA) : Circuit Diagram

INFOID:000000008746545




DAYTIME RUNNING LIGHT SYSTEM

DAYTIME RUNNING LIGHT SYSTEM : System Description

INFOID:000000008746546

SYSTEM DIAGRAM



OUTLINE

- Turns the headlamp high ON (high beam at approximately half illumination) as the daytime running light.
- Daytime running light is controlled by daytime running light control function and combination switch reading function of BCM, and relay control function of IPDM E/R.

DAYTIME RUNNING LIGHT OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM detects the vehicle condition according to power switch
- BCM detects the parking brake condition by the parking brake switch signal received from combination meter using CAN communication.
- BCM transmits the daytime running light request signal to IPDM E/R using CAN communication according to the daytime running light ON condition.

Daytime running light ON condition

- Vehicle condition READY
- Lighting switch OFF or 1ST
- Lighting switch AUTO, and the auto light function OFF judgment
- Parking brake switch OFF
- IPDM E/R controls the daytime running light relay (ground-side) to turn ON according to the daytime running light request signal.
- Power is supplied from the daytime running light relay through headlamp high RH and IPDM E/R to headlamp high LH. And high beam headlamps are illuminated (approximately half illumination) as the daytime running light.

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

SYSTEM


< SYSTEM DESCRIPTION >

[LED HEADLAMP]

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : System Description

INFOID:000000008746549

SYSTEM DIAGRAM



OUTLINE

Turn signal lamp and the hazard warning lamp is controlled by combination switch reading function and the flasher control function of BCM.

TURN SIGNAL LAMP OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM supplies voltage to the right (left) turn signal lamp circuit when the power switch is ON and the turn signal switch is in the right (left) position. BCM blinks the turn signal lamp.

HAZARD WARNING LAMP OPERATION

BCM supplies voltage to both turn signal lamp circuit when the hazard switch is ON. BCM blinks the hazard warning lamp.

TURN SIGNAL INDICATOR LAMP AND TURN SIGNAL OPERATION

- BCM transmits the turn signal indicator lamp signal to the combination meter using CAN communication while the turn signal lamp and the hazard warning lamp are operating.
- Combination meter outputs the turn signal sound with the integrated buzzer while blinking the turn signal indicator lamp according to the turn signal indicator lamp signal.

HIGH FLASHER OPERATION

- BCM detects the turn signal lamp circuit status from the current value.
- BCM increases the turn signal lamp blinking speed if the bulb or harness open is detected with the turn signal lamp operating.

NOTE:

The blinking speed is normal while operating the hazard warning lamp.

PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM

PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM : System De-

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

SYSTEM


< SYSTEM DESCRIPTION >

[LED HEADLAMP]

scription

INFOID:000000008746551

SYSTEM DIAGRAM



OUTLINE

Parking, license plate, side marker and tail lamps are controlled by combination switch reading function and headlamp control function of BCM, and relay control function of IPDM E/R.

PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits the position light request signal to IPDM E/R and the combination meter via CAN communication according to the ON/OFF condition of the parking, license plate, side marker and tail lamps.

Parking, license plate, side marker and tail lamps ON condition

- Lighting switch 1ST
- Lighting switch 2ND
- Lighting switch AUTO, and the auto light function ON judgment
- Lighting switch AUTO, with the front fog lamp switch ON and the power switch ON
- IPDM E/R turns the integrated tail lamp relay ON and turns the parking, license plate, side marker and tail lamps ON according to the position light request signal.
- Combination meter turns the tail lamp indicator lamp ON according to the position light request signal.

PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM : Fail-Safe

INFOID:000000008746553

CAN COMMUNICATION CONTROL

When CAN communication with BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If No CAN Communication Is Available With BCM


Control part	Fail-safe operation
<ul style="list-style-type: none"> • Parking lamp • License plate lamp • Illumination • Tail lamp • Side marker lamp 	<ul style="list-style-type: none"> • Turns ON the tail lamp relay when the power switch is turned ON • Turns OFF the tail lamp relay when the power switch is turned OFF

FRONT FOG LAMP SYSTEM

FRONT FOG LAMP SYSTEM : System Description

INFOID:000000008746554

SYSTEM DIAGRAM



OUTLINE

Front fog lamp is controlled by combination switch reading function, front fog lamp control function of BCM, and relay control function of IPDM E/R.

FRONT FOG LAMP OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits the front fog lights request signal to IPDM E/R and the combination meter via CAN communication according to the front fog lamp ON condition.

Front fog lamp ON condition

- Front fog lamp switch ON, and any of the following condition is satisfied.(except for the high beam ON)

- Lighting switch 2ND
- Lighting switch AUTO and the power switch ON

IPDM E/R turns the integrated front fog lamp relay ON, and turns the front fog lamp ON according to the front fog lights request signal.


Combination meter turns the front fog lamp indicator lamp ON according to the front fog lights request signal.

A
B
C
D
E
F
G
H
I
J
K

EXL

FRONT FOG LAMP SYSTEM : Circuit Diagram

INFOID:000000008746555



FRONT FOG LAMP SYSTEM : Fail-Safe

INFOID:000000008746556

CAN COMMUNICATION CONTROL

When CAN communication with BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If No CAN Communication Is Available With BCM

SYSTEM

< SYSTEM DESCRIPTION >

[LED HEADLAMP]


Control part	Fail-safe operation
Front fog lamp	Front fog lamp relay OFF

EXTERIOR LAMP BATTERY SAVER SYSTEM

EXTERIOR LAMP BATTERY SAVER SYSTEM : System Description

INFOID:000000008746557

SYSTEM DIAGRAM



OUTLINE

- Exterior lamp battery saver system is controlled by each function of BCM and IPDM E/R.

Control by BCM

- Combination switch reading function
- Headlamp control function
- Exterior lamp battery saver function

Control by IPDM E/R

- Relay control function
 - BCM turns the exterior lamps* OFF after a period of time to prevent the battery from over-discharge when the power switch is turned OFF with the exterior lamps ON.
- *: Headlamp (LO/Hi), parking lamp, tail lamp, side marker lamp, license plate lamp and front fog lamp

EXTERIOR LAMP BATTERY SAVER ACTIVATION

BCM activates the timer and turns the exterior lamp OFF 5 minutes after the power switch is turned from ON → OFF with the exterior lamps ON.

NOTE:

- Headlamp control function turns the exterior lamps ON normally when the power switch is turned ACC or set the vehicle to READY (both before and after the exterior lamp battery saver is turned OFF).
- The timer starts at the time that the lighting switch is turned from OFF → 1ST or 2ND with the exterior lamps OFF.


SYSTEM

< SYSTEM DESCRIPTION >

[LED HEADLAMP]

EXTERIOR LAMP BATTERY SAVER SYSTEM : Circuit Diagram

INFOID:00000008746558



DIAGNOSIS SYSTEM (BCM)

[LED HEADLAMP]

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000009344960

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Direct Diagnostic Mode	Description
Ecu Identification	The BCM part number is displayed.
Self Diagnostic Result	The BCM self diagnostic results are displayed.
Data Monitor	The BCM input/output data is displayed in real time.
Active Test	The BCM activates outputs to test components.
Work support	The settings for BCM functions can be changed.
Configuration	<ul style="list-style-type: none"> The vehicle specification can be read and saved. The vehicle specification can be written when replacing BCM.
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

SYSTEM APPLICATION

BCM can perform the following functions.

System	Sub System	Direct Diagnostic Mode						
		Ecu Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
Door lock	DOOR LOCK		x	x	x	x		
Rear window defogger	REAR DEFOGGER			x	x	x		
Warning chime	BUZZER			x	x			
Interior room lamp timer	INT LAMP			x	x	x		
Exterior lamp	HEADLAMP			x	x	x		
Wiper and washer	WIPER			x	x	x		
Turn signal and hazard warning lamps	FLASHER			x	x			
Air conditioner	AIR CONDITIONER			x				
Intelligent Key system	INTELLIGENT KEY		x	x	x	x		
Combination switch	COMB SW			x				
BCM	BCM	x	x			x	x	x
Immobilizer	IMMU		x	x	x			
Interior room lamp battery saver	BATTERY SAVER			x	x			
Trunk open	TRUNK			x				
Vehicle security system	THEFT ALM			x	x	x		
RAP system	RETAINED PWR			x				
Signal buffer system	SIGNAL BUFFER			x				
TPMS	AIR PRESSURE MONITOR		x	x	x	x		

HEADLAMP

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[LED HEADLAMP]

HEADLAMP : CONSULT Function (BCM - HEAD LAMP)

INFOID:000000009344961

DATA MONITOR

Monitor Item [Unit]	Description
PUSH SW [On/Off]	Indicates condition of power switch.
ENGINE STATE [Stop/Stall/Crank/Run]	Indicates engine status received from ECM on CAN communication line.
VEH SPEED 1 [km/h]	Indicates vehicle speed signal received from ABS on CAN communication line.
TURN SIGNAL R [On/Off]	Indicates condition of combination switch.
TURN SIGNAL L [On/Off]	
TAIL LAMP SW [On/Off]	
HI BEAM SW [On/Off]	
HEAD LAMP SW 1 [On/Off]	
HEAD LAMP SW 2 [On/Off]	
PASSING SW [On/Off]	
AUTO LIGHT SW [On/Off]	
FR FOG SW [On/Off]	
DOOR SW-DR [On/Off]	
DOOR SW-AS [On/Off]	Indicates condition of front door switch RH.
DOOR SW-RR [On/Off]	Indicates condition of rear door switch RH.
DOOR SW-RL [On/Off]	Indicates condition of rear door switch LH.
DOOR SW-BK [On/Off]	Indicates condition of trunk switch.
OPTI SEN (DTCT) [V]	Indicates outside brightness voltage signal from optical sensor.
OPTI SEN (FILT) [V]	Indicates outside brightness voltage signal from optical sensor filtered by BCM.

ACTIVE TEST

Test Item	Description
FR FOG LAMP	This test is able to check front fog lamp operation [On/Off].
DAYTIME RUNNING LIGHT	This test is able to check daytime running lamp operation [On/Off].
ILL DIM SIGNAL	This test is able to check head lamp illumination dimming operation [On/Off].

WORK SUPPORT

Support Item	Setting	Description
AUTO LIGHT LOGIC SET	MODE6	Autolamp function OFF.
	MODE5	
	MODE4	
	MODE3	Autolamp function ON at twilight.
	MODE2	Autolamp function ON at twilight or with wiper LO and HI operation.
	MODE1*	Autolamp function ON at twilight or with wiper INT, LO and HI operation.
BATTERY SAVER SET	Off	Exterior lamp battery saver function OFF.
	On*	Exterior lamp battery saver function ON.
CUSTOM A/LIGHT SETTING	MODE4	Less sensitive than normal setting (turns ON later).
	MODE3	More sensitive than MODE2.
	MODE2	More sensitive than normal setting (turns ON earlier).
	MODE1*	Normal setting.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[LED HEADLAMP]

Support Item	Setting		Description
ILL DELAY SET	MODE 8	180 sec.	Autolamp delay timer operation time.
	MODE 7	150 sec.	
	MODE 6	120 sec.	
	MODE 4	90 sec.	
	MODE 5	60 sec.	
	MODE 3	30 sec.	
	MODE 2	OFF	
	MODE 1*	45 sec.	

*: Initial setting

FLASHER

FLASHER : CONSULT Function (BCM - FLASHER)

INFOID:000000009344962

DATA MONITOR

Monitor Item [Unit]	Description
REQ SW -DR [On/Off]	Indicates condition of door request switch LH.
REQ SW -AS [On/Off]	Indicates condition of door request switch RH.
PUSH SW [On/Off]	Indicates condition of power switch.
TURN SIGNAL R [On/Off]	Indicates condition of turn signal function of combination switch.
TURN SIGNAL L [On/Off]	
HAZARD SW [On/Off]	Indicates condition of hazard switch.
RKE-LOCK [On/Off]	Indicates condition of lock signal from Intelligent Key.
RKE-UNLOCK [On/Off]	Indicates condition of unlock signal from Intelligent Key.
RKE-PANIC [On/Off]	Indicates condition of panic alarm signal from Intelligent Key.

ACTIVE TEST

Test Item	Description
FLASHER	This test is able to check turn signal lamp operation [Off/LH/RH].

WORK SUPPORT

Support Item	Setting	Description
HAZARD ANSWER BACK	Lock/Unlock	Hazard warning lamp answer back for LOCK and UNLOCK with request switch or Intelligent Key.
	Unlock Only	Hazard warning lamp answer back for UNLOCK only with request switch or Intelligent Key.
	Lock Only	Hazard warning lamp answer back for LOCK only with request switch or Intelligent Key.
	Off	Hazard warning lamp answer back OFF.

DIAGNOSIS SYSTEM (IPDM E/R)

Diagnosis Description

INFOID:000000009344963

AUTO ACTIVE TEST

Description

In auto active test mode, the IPDM E/R sends a drive signal to the following systems to check their operation.

- Rear window defogger
- Front wiper motor
- Parking lamp
- License plate lamp
- Tail lamp
- Front fog lamp
- Side marker lamp
- Headlamp (LO, HI)

Operation Procedure

NOTE:

Never perform auto active test in the following conditions.

- CONSULT is connected.
- Passenger door is open.

1. Turn the power switch OFF.
2. Turn the power switch ON, and within 20 seconds, press the driver door switch 10 times. Then turn the power switch OFF.
3. Turn the power switch ON within 10 seconds. After that the horn sounds once and the auto active test starts.

NOTE:

Never depress brake pedal while operating power switch so that auto active test is not activated.

4. After a series of the following operations is repeated 3 times, auto active test is completed.

NOTE:

- When auto active test mode has to be cancelled halfway through test, turn the power switch OFF.
- When auto active test is not activated, door switch may be the cause. Check door switch. Refer to [DLK-117, "Component Function Check"](#).

Inspection in Auto Active Test Mode

When auto active test mode is actuated, the following operation sequence is repeated 3 times.


Operation sequence	Inspection location	Operation
1	Rear window defogger	10 seconds
2	Front wiper motor	LO for 5 seconds → HI for 5 seconds
3	<ul style="list-style-type: none"> • Parking lamp • License plate lamp • Tail lamp • Front fog lamp • Side marker lamp 	10 seconds
4	Headlamp	LO for 10 seconds → HI ON ⇔ OFF 5 times

DIAGNOSIS SYSTEM (IPDM E/R)

[LED HEADLAMP]

< SYSTEM DESCRIPTION >

Concept of auto active test



- IPDM E/R starts the auto active test with the door switch signals transmitted by BCM via CAN communication. Therefore, the CAN communication line between IPDM E/R and BCM is considered normal if the auto active test starts successfully.
- The auto active test facilitates troubleshooting if any systems controlled by IPDM E/R cannot be operated.

Diagnosis chart in auto active test mode

Symptom	Inspection contents	Possible cause
Rear window defogger does not operate	Perform auto active test. Does the rear window defogger operate?	YES BCM signal input circuit
		NO <ul style="list-style-type: none"> • Rear window defogger • Rear window defogger ground circuit • Harness or connector between IPDM E/R and rear window defogger • IPDM E/R
Any of the following components do not operate • Parking lamp • License plate lamp • Tail lamp • Front fog lamp • Headlamp (HI, LO) • Side marker lamp • Front wiper motor	Perform auto active test. Does the applicable system operate?	YES BCM signal input circuit
		NO <ul style="list-style-type: none"> • Lamp or motor • Lamp or motor ground circuit • Harness or connector between IPDM E/R and applicable system • IPDM E/R

CONSULT Function (IPDM E/R)

INFOID:000000009344964

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with IPDM E/R.

Direct Diagnostic Mode	Description
Ecu Identification	The IPDM E/R part number is displayed.
Self Diagnostic Result	The IPDM E/R self diagnostic results are displayed.
Data Monitor	The IPDM E/R input/output data is displayed in real time.
Active Test	The IPDM E/R activates outputs to test components.
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

SELF DIAGNOSTIC RESULT

Refer to [PCS-18, "DTC Index"](#).

DATA MONITOR

DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

[LED HEADLAMP]

Monitor Item [Unit]	Main Signals	Description
TAIL&CLR REQ [On/Off]	×	Indicates position light request signal received from BCM on CAN communication line
HL LO REQ [On/Off]	×	Indicates low beam request signal received from BCM on CAN communication line
HL HI REQ [On/Off]	×	Indicates high beam request signal received from BCM on CAN communication line
FR FOG REQ [On/Off]	×	Indicates front fog light request signal received from BCM on CAN communication line
FR WIP REQ [Stop/1LOW/Low/Hi]	×	Indicates front wiper request signal received from BCM on CAN communication line
WIP AUTO STOP [STOP P/ACT P]	×	Indicates condition of front wiper auto stop signal
WIP PROT [Off/BLOCK]	×	Indicates condition of front wiper fail-safe operation
IGN RLY1 -REQ [On/Off]		Indicates power switch ON signal received from BCM on CAN communication line
IGN RLY [On/Off]	×	Indicates condition of ignition relay-1
PUSH SW [On/Off]		Indicates condition of power switch
DETENT SW [On/Off]		Indicates condition of shift position (park position switch)
DTRL REQ [Off]		Indicates daytime light request signal received from BCM on CAN communication line
HOOD SW [On/Off]		Indicates condition of hood switch
THFT HRN REQ [On/Off]		Indicates theft warning horn request signal received from BCM on CAN communication line
HORN CHIRP [On/Off]		Indicates horn reminder signal received from BCM on CAN communication line

ACTIVE TEST

Test item	Description
HORN	This test is able to check horn operation [On].
REAR DEFOGGER	This test is able to check rear window defogger operation [On/Off].
FRONT WIPER	This test is able to check wiper motor operation [Hi/Lo/Off].
EXTERNAL LAMPS	This test is able to check external lamp operation [Fog/Hi/Lo/TAIL/Off].

CAN DIAG SUPPORT MNTR

Refer to [LAN-13, "CAN Diagnostic Support Monitor"](#).

ECU DIAGNOSIS INFORMATION

BCM, IPDM E/R

List of ECU Reference

INFOID:000000008746564

ECU	Reference
BCM	BCS-28, "Reference Value"
	BCS-46, "Fail-safe"
	BCS-47, "DTC Inspection Priority Chart"
	BCS-48, "DTC Index"
IPDM E/R	PCS-14, "Reference Value"
	PCS-17, "Fail-Safe"
	PCS-18, "DTC Index"


A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

EXL

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]




AALWA0616GB

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]



AALWA0666GB


EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]

EXTERIOR LIGHTING SYSTEM LED - CONNECTORS


Connector No.	M4
Connector Name	DATA LINK CONNECTOR
Connector Color	WHITE



Connector No.	M16
Connector Name	OPTICAL SENSOR
Connector Color	WHITE



Connector No.	M18
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	-	-
2	-	-
3	LG	-
4	B	-
5	B	-
6	L	-
7	GR	-
8	G	-
9	-	-
10	-	-
11	SB	-
12	G	-
13	L	-
14	P	-
15	-	-
16	Y	-

Terminal No.	Color of Wire	Signal Name
1	Y	-
2	G	-
3	V	-

Terminal No.	Color of Wire	Signal Name
1	G	-
2	-	-
3	GR	-
4	L	-
5	G	-
6	V	-
7	P	-
8	P	-
9	B	-
10	R	-
11	LG	-
12	P	-
13	W	-
14	Y	-
15	LG	-
16	L	-

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P


EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]


Terminal No.	Color of Wire	Signal Name
23	-	-
24	W	-
25	B	-
26	W	-
27	Y	-
28	-	-
29	W	-
30	L	-
31	L	-
32	P	-

Connector No.	M21
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	-	-
2	-	-
3	-	-
4	-	-
5	-	-
6	-	-
7	B	-
8	SHIELD	-
9	R	-
10	SB	-
11	P	-
12	V	-
13	GR	-
14	P	-
15	L	-
16	G	-
17	-	-
18	-	-
19	-	-
20	-	-
21	-	-
22	-	-

Connector No.	M19
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	-	-
2	LG	-
3	P	-
4	GR	-
5	GR	-
6	W	-
7	-	-
8	-	-
9	-	-
10	V	-
11	V	-
12	LG	-
13	BR	-
14	SB	-
15	L	-
16	G	-

AALIA1750GB

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]

Terminal No.	Color of Wire	Signal Name
90	W	HIGH SIDE ENGINE START SW ILLUMINATION LED
91	V	POWER POSITION LED (LOCK POSITION LED)
92	B	LOW SIDE ENGINE START SW ILLUMINATION LED OUTPUT
93	GR	SMART KEYLESS BUZZER OUTPUT
94	-	SMART KEYLESS BUZZER OUTPUT
95	-	-
96	BR	ACC RELAY OUTPUT
97	LG	STARTER RELAY OUTPUT
98	L	IGN RELAY OUTPUT1 (USM)
99	GR	IGN RELAY OUTPUT2 (ELEC)
100	P	REQUEST SW (AS)
101	-	-
102	BG	SHIFT N, P
103	-	-
104	-	-
105	W	BRAKE SW2
106	-	-
107	-	-
108	-	-
109	-	-
110	-	-

Connector No.	M23
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90
----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name
71	-	-
72	-	-
73	V	PUSH SW SIGNAL OUTPUT
74	-	-
75	LG	REQUEST SW (DR)
76	SB	ENGINE START SW
77	-	-
78	P	DOOR ANTENNA (DR) +
79	V	DOOR ANTENNA (DR) -
80	LG	DOOR ANTENNA (AS) +
81	Y	DOOR ANTENNA (AS) -
82	W	BACK DOOR ANTENNA +
83	B	BACK DOOR ANTENNA -
84	BR	ROOM ANTENNA 1 +
85	Y	ROOM ANTENNA 1 -
86	G	ROOM ANTENNA 2 +
87	R	ROOM ANTENNA 2 -
88	G	ROOM ANTENNA 3 +
89	R	ROOM ANTENNA 3 -

AALIA1751GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]

Terminal No.	Color of Wire	Signal Name
36	P	COMBINATION SW OUTPUT 1
37	V	SHIFT P POSITION, PARKING POSITION SW
38	SB	INTELLIGENT TUNER
39	L	CAN-H
40	P	CAN-L

Terminal No.	Color of Wire	Signal Name
15	W	REAR DEFOGGER SW
16	R	MR OUTPUT
17	Y	AUTO LIGHT SENSOR POWER SUPPLY OUTPUT, KEYLESS TUNER, AUTO LIGHT SENSOR GND
18	L	AUTO LIGHT SENSOR GND
19	-	-
20	-	-
21	P	IMMOBILIZER ONE WAY COMMUNICATION (CLOCK)
22	-	-
23	R	SECURITY INDICATOR OUTPUT
24	SB	DONGLE LINK
25	LG	IMMOBILIZER TWO WAY COMMUNICATION
26	-	-
27	-	-
28	-	-
29	G	HAZARD SW
30	V	TRUNK/BACK DOOR OPENER SW
31	W	DOOR LOCK STATUS SW (DR)
32	GR	COMBINATION SW OUTPUT 5
33	Y	COMBINATION SW OUTPUT 4
34	W	COMBINATION SW OUTPUT 3
35	BG	COMBINATION SW OUTPUT 2

Connector No.	M24
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

Terminal No.	Color of Wire	Signal Name
1	-	-
2	L	COMBINATION SW INPUT 5
3	GR	COMBINATION SW INPUT 4
4	BR	COMBINATION SW INPUT 3
5	G	COMBINATION SW INPUT 2
6	V	COMBINATION SW INPUT 1
7	GR	KEY CYLINDER UNLOCK SW
8	R	KEY CYLINDER LOCK SW
9	BR	BRAKE SW1
10	-	-
11	-	-
12	Y	CENTRAL DOOR LOCK SW
13	BR	CENTRAL DOOR UNLOCK SW
14	G	AUTO LIGHT SENSOR INPUT

AALIA1752GB

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]

Connector No.	M29
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



104	103	102	101	100	99	98	97	96
110	109	108	107	106	105			

Connector No.	M27
Connector Name	COMBINATION SWITCH
Connector Color	WHITE



1	2	3	4	5	6
7	8	9	10	11	12
13	14				

Connector No.	M25
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



56	57	58	59	60	61	62	63	64
65	66	67	68	69	70			

Terminal No.	Color of Wire	Signal Name
41	-	-
42	-	-
43	Y	DOOR SW (BACK)
44	LG	REAR WIPER AUTO STOP SW
45	BR	DOOR SW (AS)
46	R	DOOR SW (RR)
47	SB	DOOR SW (DR)
48	W	DOOR SW (RL)
49	L	LUGGAGE LAMP OUTPUT
50	-	-
51	P	REQUEST SW (TRUNK/BACK DOOR)
52	-	-
53	GR	TRUNK/BACK DOOR OPEN OUTPUT
54	P	REAR WIPER MOTOR OUTPUT
55	G	DOOR UNLOCK OUTPUT (RR, RL)

Terminal No.	Color of Wire	Signal Name
1	LG	-
2	GR	-
3	R	-
4	SB	-
5	BR	-
6	B	-
7	W	-
8	L	-
9	BG	-
10	Y	-
11	P	-
12	V	-
13	GR	-
14	G	-
15	-	-
16	-	-

Terminal No.	Color of Wire	Signal Name
56	P	BATTERY SAVER OUTPUT
57	P	BATTERY (FUSE)
58	-	-
59	LG	DOOR UNLOCK OUTPUT (AS)
60	V	FLASHER OUTPUT (LEFT)
61	R	FLASHER OUTPUT (RIGHT)
62	-	-
63	BR	ROOM LAMP OUTPUT
64	-	-
65	V	DOOR LOCK OUTPUT
66	G	DOOR UNLOCK COMMON (DR)
67	B	GND
68	L	POWER WINDOW POWER SUPPLY (RAP)
69	R	POWER WINDOW POWER SUPPLY (BATTERY)
70	Y	BATTERY (F/L)

AALIA1753GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


EXL

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]


Connector No.	M40
Connector Name	JOINT CONNECTOR-M05
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-
3	BR	-
4	GR	-
5	L	-
6	L	-
7	L	-
8	L	-
9	L	-
10	L	-
11	LG	-
12	LG	-
13	L	-
14	R	-
15	P	-
16	P	-
17	P	-
18	P	-
19	P	-
20	P	-

Terminal No.	Color of Wire	Signal Name
21	-	-
22	GR	GND (FOR UPPER)
23	-	-
24	BG	PKB SW
25	SB	BRAKE OIL
26	B	ILL CONT OUT
27	R	A/BAG WARN
28	R	SECURITY
29	-	-
30	GR	8 P/R O/P
31	-	-
32	W	SDA (12C)
33	G	SCL (12C)
34	L	CHARGE LAMP
35	-	-
36	-	-
37	-	-
38	V	LED H LAMP R
39	LG	LED H LAMP L
40	W	BUCKLE SW FR DR

Connector No.	M34
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	LG	BAT
2	Y	BAT (FOR UPPER)
3	GR	IGN
4	BG	IGN (FOR UPPER)
5	B	GND1 (ILL)
6	B	GND2 (POWER)
7	-	-
8	Y	WASHER SW
9	BR	CHARGE CONNECT
10	-	-
11	-	-
12	V	SW GND
13	G	MODE B SW
14	Y	MODE A SW
15	BR	TRIP RESET SW
16	P	ILL CONT UP
17	G	UPPER ILL CONT
18	P	CAN-H
19	L	CAN-L
20	LG	AS SEATBELT W/L


AALIA1754GB

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >


[LED HEADLAMP]

Connector No.	M45
Connector Name	HAZARD SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	-
2	G	-
3	W	-
4	B	-

Connector No.	M44
Connector Name	JOINT CONNECTOR-M01
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	P	-
2	-	-
3	-	-
4	-	-
5	-	-
6	-	-
7	-	-
8	B	-
9	B	-
10	B	-
11	P	-
12	P	-
13	W	-
14	W	-
15	LG	-
16	R	-
17	R	-
18	W	-
19	W	-
20	W	-

Connector No.	M41
Connector Name	JOINT CONNECTOR-M06
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	SB	-
2	SB	-
3	SB	-
4	SB	-
5	L	-
6	L	-
7	L	-
8	L	-
9	L	-
10	L	-
11	LG	-
12	LG	-
13	LG	-
14	LG	-
15	P	-
16	P	-
17	P	-
18	P	-
19	P	-
20	P	-

AALIA1755GB


A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]

Connector No.	M50
Connector Name	JOINT CONNECTOR-M03
Connector Color	PINK



Terminal No.	Color of Wire	Signal Name
1	B	-
2	B	-
3	B	-
4	B	-
5	B	-
6	B	-
7	B	-
8	B	-
9	B	-
10	B	-
11	G	-
12	G	-
13	G	-
14	G	-
15	G	-
16	L	-
17	L	-
18	L	-
19	L	-
20	L	-

AALIA1756GB

EXTERIOR LIGHTING SYSTEM


< WIRING DIAGRAM >

[LED HEADLAMP]

Terminal No.	Color of Wire	Signal Name
60	Y	-
61	GR	-
62	W	-
63	BR	-
64	SHIELD	-
65	W	-
66	LG	-
67	R	-
68	G	-
69	BG	-
70	GR	-
71	R	-
72	R	-
73	B	-
74	W	-
76	L	-
80	W	-
81	LG	-
83	GR	-
84	L	-
85	Y	-
86	SB	-
88	R	-
89	G	-
90	SHIELD	-
91	Y	-
92	BR	-
93	W	-
94	P	-
95	L	-
96	P	-
97	G	-
98	V	-
99	LG	-
100	R	-

Terminal No.	Color of Wire	Signal Name
22	B	-
23	BG	-
24	B	-
26	G	-
27	B	-
28	B	-
25	W	-
29	R	-
31	R	-
32	W	-
33	GR	-
34	BR	-
35	BR	-
36	W	-
37	L	-
38	LG	-
39	SB	-
40	V	-
41	P	-
42	SB	-
43	G	-
44	LG	-
45	Y	-
46	R	-
47	W	-
48	L	-
49	G	-
50	L	-
51	SB	-
52	L	-
54	B	-
55	R	-
56	V	-
57	Y	-
58	L	-

Connector No.	M77
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R	-
2	L	-
3	V	-
4	LG	-
6	P	-
7	GR	-
9	G	-
10	L	-
11	L	-
12	Y	-
13	V	-
14	R	-
15	G	-
16	W	-
17	R	-
18	G	-
19	W	-
20	GR	-
21	P	-

AALIA1757GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

EXTERIOR LIGHTING SYSTEM


< WIRING DIAGRAM >

[LED HEADLAMP]

Terminal No.	Color of Wire	Signal Name
20	BR	-
21	V	-
22	SB	-
23	W	-
24	B	-
25	W	-
26	R	-
27	-	-
28	-	-
29	W	-
30	R	-
31	G	-
32	-	-

Terminal No.	Color of Wire	Signal Name
6	SHIELD	-
7	L	-
8	GR	-
9	R	-
10	BR	-
11	L	-
12	BR	-
13	B	-
14	-	-
15	R	-
16	G	-
17	R	-
18	G	-
19	SHIELD	-

Connector No.	M79
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	P	-
3	SHIELD	-
4	G	-
5	R	-


Connector No.	E10
Connector Name	FRONT SIDE MARKER LAMP LH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	O	-
2	BW	-

Terminal No.	Color of Wire	Signal Name
3	L	-
4	L	-
5	-	-
6	L	-
7	P	-
8	P	-
9	P	-
10	P	-
11	-	-
12	P	-

Connector No.	E6
Connector Name	JOINT CONNECTOR-E01
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

AALIA1758GB

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >


[LED HEADLAMP]

Connector No.	E11
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
9	B	GND (POWER)
10	-	-
11	-	-
12	-	-
13	-	-
14	R	RR DEF

Connector No.	E12
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
15	-	-
16	-	-
17	-	-
18	B/W	GND (SIGNAL)
19	W	FR FOG/L RH
20	V	FR FOG/L LH
21	-	-
22	-	-

Connector No.	E13
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
23	-	-
24	-	-
25	R	AUTO STOP SW
26	P	CAN-CL
27	L	CAN-CH
28	G	DTRL RLY
29	-	-
30	-	-
31	-	-
32	SB	HOOD SW
33	-	-
34	W	HORN RLY CONT

Connector No.	E14
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
35	R	VCM VB
36	-	-

Terminal No.	Color of Wire	Signal Name
37	-	-
38	LG	TAIL 1 (WITHOUT SOLAR CELL)
38	R	TAIL 1 (WITH SOLAR CELL)
39	L	FR WIPER HI
40	-	-
41	SB	VCM RLY CONT
42	BR	VCM BAT
43	O	CLEARANCE/L LH

Terminal No.	Color of Wire	Signal Name
44	B	TAIL 2
45	Y	FR WIPER LO
46	-	-

AALIA1759GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


EXL

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]

Connector No.	E15
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
47	-	-
48	-	-
49	Y	H/LAMP HI RH
50	G	H/LAMP HI LH

Terminal No.	Color of Wire	Signal Name
51	L	H/LAMP LO LH
52	P	H/LAMP LO RH
53	-	-
54	-	-
55	LG	FAST CHARGE
56	-	-
57	R	VCM IGN
58	O	REVERSE LAMP IGN
59	BR	ABS ECU IGN
60	GR	F/S RLY CONT
61	-	-
62	V	E-ACT/HAS IGN

Connector No.	E16
Connector Name	FRONT SIDE MARKER LAMP RH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	O	-
2	B/R	-

Connector No.	E27
Connector Name	REVERSE LAMP RELAY
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
1	O	-
2	SB	-
3	O	-
4	G	-

Connector No.	E30
Connector Name	FRONT FOG LAMP LH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	V	-
2	B/W	-

Connector No.	E44
Connector Name	JOINT CONNECTOR-E02
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	SB	-
2	SB	-
3	SB	-
4	SB	-
5	-	-
6	SB	-
7	O	-
8	O	-
9	O	-
10	O	-
11	O	-
12	-	-

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

Connector No.	E48
Connector Name	FRONT FOG LAMP RH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W	-
2	B/Y	-

AALIA1890GB

EXTERIOR LIGHTING SYSTEM


< WIRING DIAGRAM >

[LED HEADLAMP]

Terminal No.	Color of Wire	Signal Name
110	Y	COOLANT TEMPERATURE SENSOR
111	SB	ASCD STEERING SWITCH
112	B	P POSITION SW NO.2
113	O	BRAKE PEDAL POSITION SWITCH
115	V	CHARGING STATUS INDICATOR 1
116	SB	A/C RELAY
117	LG	CHARGE CONNECTOR LOCK ACTUATOR (+)
118	B	VCM GROUND
120	L	SENSOR GROUND (BATTERY CURRENT SENSOR)
121	W	SENSOR GROUND (COOLANT TEMPERATURE SENSOR)
122	B	SENSOR GROUND (ACCELERATOR PEDAL POSITION SENSOR 2)
123	BR	SENSOR GROUND (REFRIGERANT PRESSURE SENSOR)
124	W/L	ELECTRIC SHIFT SENSOR GND 2
125	BR	ASCD STEERING SWITCH GROUND
126	B/R	VCM GROUND
128	V	COOLING FAN CONTROL SIGNAL
129	Y	IMMEDIATE CHARGING SWITCH
130	W	CHARGE CONNECTOR LOCK ACTUATOR (-)

Terminal No.	Color of Wire	Signal Name
87	V	CHARGE CONNECTOR LOCK SWITCH INDICATOR (LOCK)
88	SB	M/C RELAY
89	BR	CHARGING STATUS INDICATOR 2
90	G	CHARGING STATUS INDICATOR 3
91	O	CHARGE CONNECTOR LOCK SWITCH INDICATOR (AUTO)
93	BR	CHARGE PORT ID OPENER SWITCH
94	O	CHARGE CONNECTOR LOCK SWITCH (LOCK)
95	Y	BATTERY CURRENT SENSOR
96	R	SENSOR POWER SUPPLY (BATTERY CURRENT SENSOR)
97	W	SENSOR POWER SUPPLY (ACCELERATOR PEDAL POSITION SENSOR 2)
98	L	SENSOR POWER SUPPLY (REFRIGERANT PRESSURE SENSOR)
99	R	P POSITION SW NO.1
101	P	STOP LAMP SWITCH
103	L	PLUG IN INDICATOR LAMP
104	R	CHARGE CONNECTOR LOCK RELAY POWER SUPPLY
107	L	BATTERY TEMPERATURE SENSOR
108	R	ACCELERATOR PEDAL POSITION SENSOR 2
109	B	REFRIGERANT PRESSURE SENSOR

Connector No.	E62
Connector Name	VCM
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
70	SB	REVERSE LAMP RELAY CONNECTION
72	P	DETECTING CIRCUIT SIGNAL
73	O	DETECTING CIRCUIT POWER SUPPLY
74	G	POWER ON POWER SUPPLY
75	L	CAN-H
76	P	CAN-L
78	SB	CHARGE CONNECTOR LOCK RELAY
79	R	12V BATTERY POWER SUPPLY
81	L	CHARGE CONNECTOR LOCK SWITCH (AUTO)
82	GR	CHARGE PORT LIGHT
83	W	ELECTRIC SHIFT SENSOR POWER SUPPLY 2
84	W	ELECTRIC SHIFT SENSOR NO.2
85	G	ELECTRIC SHIFT SENSOR NO.4
86	G	ELECTRIC SHIFT SENSOR NO.6

AALIA1891GB

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >


[LED HEADLAMP]

Connector No.	E84
Connector Name	DAYTIME RUNNING LIGHT RELAY
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	LG	-
2	G	-
3	L	-
4	B/Y	-
5	LG	-

Connector No.	E85
Connector Name	FRONT COMBINATION LAMP LH (WITH LED HEADLAMPS)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	LG	-
2	L	-
3	BR	-
4	O	-
5	G	-
6	B/W	-
7	B/W	-
8	Y	-
9	B	-(WITH DTRL)
9	B/W	-(WITHOUT DTRL)
10	-	-

Connector No.	E86
Connector Name	FRONT COMBINATION LAMP RH (WITH LED HEADLAMPS)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	R	-
2	P	-
3	BR	-
4	O	-
5	Y	-
6	L	-(WITH DTRL)
6	B/Y	-(WITHOUT DTRL)
7	B/Y	-
8	G	-
9	B	-(WITH DTRL)
9	B/Y	-(WITHOUT DTRL)
10	-	-

Connector No.	E102
Connector Name	STOP LAMP SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	-
2	SB	-
3	R	-
4	P	-

AALIA1892GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL


EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]

58	L	-
60	LG	-
61	GR	-
62	W	-
63	SB	-
64	SHIELD	-
65	W	-
66	G	-
67	V	-
68	R	-
69	B	-
70	BR	-
71	LG	-
72	R	-
73	B	-
74	O	-
76	L	-
77	Y	-
80	P	-
81	SB	-
83	GR	-
84	L	-
85	O	-
86	BR	-
88	B	-
89	W	-
90	SHIELD	-
91	Y	-
92	BR	-
93	O	-
94	R	-
95	V	-
96	P	-
97	G	-
98	W	-
99	O	-
100	SB	-

20	BR	-
21	R	-
22	B	-
23	LG	-
24	B	-
25	W	-
26	W	-
27	B	-
28	O/L	-
29	W	-
31	R	-
32	W	-
33	G	-
34	BR	-
35	V	-
36	O	-
37	L	-
38	SB	-
39	P	-
40	V	-
41	O	-
42	Y	-
43	BR	-
44	W	-
45	G	-
46	P	-
47	LG	-
47	R	-
48	B	-
49	L	-
50	G	-
51	W	-
52	O	-
54	B	-
55	R	-
56	Y	-
57	Y	-



Terminal No.	Color of Wire	Signal Name
1	R	-
2	L	-
3	BW	-(WITHOUT FRONT FOG LAMPS)
3	R	-(WITH LED HEADLAMPS)
4	LG	-(WITH LED HEADLAMPS)
4	B/W	-(WITHOUT FRONT FOG LAMPS)
6	B/R	-
7	W	-
9	G	-
10	R	-
11	L	-
12	Y	-
13	W	-
14	R	-
15	G	-
16	G	-
17	R	-
18	O	-
19	W/L	-


AALIA1893GB

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >


[LED HEADLAMP]

Connector No.	B2
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	-	-
2	LG	-
3	P	-
4	GR	-
5	GR	-
6	W	-
7	-	-
8	-	-
9	-	-
10	SB	-
11	V	-
12	LG	-
13	SB	-
14	Y	-
15	L	-
16	G	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	G	-
2	-	-
3	GR	-
4	L	-
5	G	-
6	R	-
7	BR	-
8	SB	-
9	GR	-
10	W	-
11	LG	-
12	P	-
13	V	-
14	Y	-
15	W	-
16	L	-

Connector No.	E107
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	P	-
3	SB	-
4	-	-
5	-	-
6	GR	-
7	-	-
8	P	-
9	BR	-
10	W	-
11	R	-
12	B	-
13	G	-
14	B	-
15	LG	-
16	BR	-
17	G	-
18	B	-
19	Y	-
20	R	-
21	O	-
22	W	-
23	SHIELD	-
24	-	-

AALIA1894GB

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]

Terminal No.	Color of Wire	Signal Name
19	-	-
20	-	-
21	-	-
22	-	-
23	-	-
24	R	-
25	W	-
26	LG	-
27	Y	-
28	-	-
29	R	-
30	GR	-
31	L	-
32	P	-

Terminal No.	Color of Wire	Signal Name
28	-	-
29	W	-
30	V	-
31	LG	-
32	SHIELD	-

Terminal No.	Color of Wire	Signal Name
5	-	-
6	-	-
7	B	-
8	SHIELD	-
9	B	-
10	SB	-
11	P	-
12	BR	-
13	GR	-
14	P	-
15	L	-
16	G	-
17	-	-
18	-	-

Terminal No.	Color of Wire	Signal Name
11	GR	-
12	BR	-
13	B	-
14	-	-
15	R	-
16	G	-
17	R	-
18	G	-
19	SHIELD	-
20	LG	-
21	V	-
22	GR	-
23	G	-
24	B	-
25	W	-
26	R	-
27	-	-

Connector No.	B3
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

Terminal No.	Color of Wire	Signal Name
1	-	-
2	-	-
3	-	-
4	-	-

Connector No.	B4
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

Terminal No.	Color of Wire	Signal Name
1	L	-
2	P	-
3	SHIELD	-
4	R	-
5	L	-
6	SHIELD	-
7	P	-
8	SB	-
9	R	-
10	BR	-

AALIA1895GB

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >


[LED HEADLAMP]

Connector No.	B53
Connector Name	REAR DOOR SWITCH RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	-	-
2	-	-
3	R	-
4	-	-

Connector No.	B18
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	-	-
2	-	-
3	-	-
4	P	-
5	P	-
6	BR	-
7	-	-
8	-	-
9	P	-
10	Y	-
11	B	-
12	W	-
13	R	-
14	L	-
15	LG	-
16	-	-
17	SHIELD	-
18	B	-
19	-	-
20	GR	-

Connector No.	B7
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	P	-
3	Y	-
4	-	-
5	-	-
6	SB	-
7	-	-
8	P	-
9	V	-
10	Y	-
11	L	-
12	G	-
13	G	-
14	B	-
15	LG	-
16	BR	-
17	G	-
18	B	-
19	Y	-
20	R	-
21	Y	-
22	W	-
23	SHIELD	-
24	-	-

AALIA1896GB


A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]

Connector No.	B57
Connector Name	LICENSE PLATE LAMP LH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	W	-
2	B	-


ABLIA5969GB

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >


[LED HEADLAMP]

Connector No.	B58
Connector Name	LICENSE PLATE LAMP RH
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
1	L	-
2	B	-

Connector No.	B59
Connector Name	REAR COMBINATION LAMP RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	G	-
2	Y	-
3	-	-
4	W	-
5	B	-
6	V	-

Connector No.	B71
Connector Name	REAR DOOR SWITCH LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	-	-
2	-	-
3	LG	-
4	-	-

Connector No.	B80
Connector Name	REAR COMBINATION LAMP LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	G	-
2	P	-
3	-	-
4	SB	-
5	B	-
6	GR	-

Connector No.	B85
Connector Name	JOINT CONNECTOR-B02
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	B	-
2	-	-
3	B	-
4	B	-
5	-	-
6	-	-
7	L	-

Terminal No.	Color of Wire	Signal Name
8	W	-
9	V	-
10	V	-
11	SHIELD	-
12	SHIELD	-
13	B	-
14	B	-
15	G	-
16	G	-
17	G	-
18	LG	-
19	R	-
20	R	-

AALIA1897GB

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

EXTERIOR LIGHTING SYSTEM


< WIRING DIAGRAM >

[LED HEADLAMP]

Terminal No.	Color of Wire	Signal Name
11	B	-
12	W	-
13	R	-
14	L	-
15	LG	-
16	-	-
17	SHIELD	-
18	Y	-
19	-	-
20	GR	-

Terminal No.	Color of Wire	Signal Name
2	-	-
3	-	-
4	P	-
5	W	-
6	R	-
7	-	-
8	-	-
9	P	-
10	SB	-

Connector No.	D504
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	-	-

Connector No.	D553
Connector Name	CONDENSER
Connector Color	BLACK




Connector No.	D551
Connector Name	CONDENSER
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
2	R	-

Terminal No.	Color of Wire	Signal Name
1	R	-

Connector No.	D505
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	-
2	R	-
3	P	-
4	W	-
5	R	-
6	SHIELD	-
7	Y	-
8	P	-
9	L	-
10	SB	-
11	LG	-
12	GR	-


AALIA1898GB

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]


Connector No.	D561
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	BR	-
2	B	-
3	R	-
4	B	-

Terminal No.	Color of Wire	Signal Name
7	Y	-(WITHOUT AROUND VIEW MONITOR)
7	R	-(WITH AROUND VIEW MONITOR)
8	P	-
9	L	-
10	SB	-
11	LG	-
12	GR	-

Connector No.	D555
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	W	-(WITHOUT AROUND VIEW MONITOR)
1	B	-(WITH AROUND VIEW MONITOR)
2	R	-(WITHOUT AROUND VIEW MONITOR)
2	W	-(WITH AROUND VIEW MONITOR)
3	P	-
4	W	-
5	R	-
6	SHIELD	-

Connector No.	D603
Connector Name	HIGH-MOUNTED STOP LAMP
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1	R	-
2	B	-

Connector No.	D602
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	BR	-
2	B	-
3	R	-
4	B	-

Connector No.	D562
Connector Name	BACK DOOR LOCK ASSEMBLY
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	GB	-
2	B	-
3	SB	-
4	B	-

AALIA1899GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000008746566

OVERALL SEQUENCE



JMKIA8652GB

DETAILED FLOW

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[LED HEADLAMP]

1.GET INFORMATION FOR SYMPTOM

1. Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurs).
2. Check operation condition of the function that is malfunctioning.

>> GO TO 2.

2.CHECK DTC

1. Check DTC.
2. Perform the following procedure if DTC is detected.
 - Record DTC and freeze frame data (Print them out using CONSULT.)
 - Erase DTC.
 - Study the relationship between the cause detected by DTC and the symptom described by the customer.
3. Check related service bulletins for information.

Are any symptoms described and any DTC detected?

Symptom is described, DTC is detected>>GO TO 3.

Symptom is described, DTC is not detected>>GO TO 4.

Symptom is not described, DTC is detected>>GO TO 5.

3.CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Also study the normal operation and fail-safe related to the symptom.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5.

4.CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6.

5.PERFORM DTC CONFIRMATION PROCEDURE

Perform DTC CONFIRMATION PROCEDURE for the detected DTC, and then check that DTC is detected again. At this time, always connect CONSULT to the vehicle, and check self diagnostic results in real time.

If two or more DTCs are detected, refer to [BCS-47. "DTC Inspection Priority Chart"](#) (BCM) or [PCS-18. "DTC Index"](#) (IPDM E/R), and determine trouble diagnosis order.

NOTE:

- Freeze frame data is useful if the DTC is not detected.
- Perform Component Function Check if DTC CONFIRMATION PROCEDURE is not included on Service Manual. This simplified check procedure is an effective alternative though DTC cannot be detected during this check.

If the result of Component Function Check is NG, it is the same as the detection of DTC by DTC CONFIRMATION PROCEDURE.

Is DTC detected?

YES >> GO TO 7.

NO >> Check according to [GI-53. "Intermittent Incident"](#).

6.DETECT MALFUNCTIONING SYSTEM BY SYMPTOM DIAGNOSIS

Detect malfunctioning system according to SYMPTOM DIAGNOSIS based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

Is the symptom described?

YES >> GO TO 7.

NO >> Monitor input data from related sensors or check voltage of related module terminals using CONSULT.

7.DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

DIAGNOSIS AND REPAIR WORKFLOW

[LED HEADLAMP]

< BASIC INSPECTION >

Inspect according to Diagnostic Procedure of the system.

Is malfunctioning part detected?

YES >> GO TO 8.

NO >> Check according to [GI-53. "Intermittent Incident"](#).

8. REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnostic Procedure again after repair and replacement.
3. Check DTC. If DTC is detected, erase it.

>> GO TO 9.

9. FINAL CHECK

When DTC is detected in step 2, perform DTC CONFIRMATION PROCEDURE again, and then check that the malfunction is repaired securely.

When symptom is described by the customer, refer to confirmed symptom in step 3 or 4, and check that the symptom is not detected.

Is DTC detected and does symptom remain?

YES-1 >> DTC is detected: GO TO 7.

YES-2 >> Symptom remains: GO TO 4.

NO >> Before returning the vehicle to the customer, always erase DTC.

LED HEADLAMP OPERATION INSPECTION

< BASIC INSPECTION >

[LED HEADLAMP]

LED HEADLAMP OPERATION INSPECTION

Diagnosis Procedure

INFOID:000000008746567

1. CHECK START

1. In the cool LED status (wait for more than 10 minutes after turning headlamp OFF), turn ON and turn OFF headlamp for the several times. Check that headlamp operates normally each time.
2. In the cool LED status, turn headlamp ON, wait until headlamp enters to the stable status (approximately 5 minutes after turning headlamp ON), and then check that headlamp operates normally without blinking or flickering.
3. In the warm LED status (turn headlamp ON for more than 15 minutes and wait for 1 minute after turning OFF), turn ON and turn OFF headlamp for the several times. Check that headlamp operates normally each time.
4. Turn headlamp ON for approximately 30 minutes, and then check that headlamp operates normally without difference in brightness between LH and RH, blinking or flickering.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Refer to [EXL-90, "WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Symptom Table"](#).

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

HEADLAMP (HI) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

DTC/CIRCUIT DIAGNOSIS

HEADLAMP (HI) CIRCUIT

WITHOUT DAYTIME RUNNING LIGHT SYSTEM

WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Component Function Check

INFOID:000000008746568

1. CHECK HEADLAMP (HI) OPERATION

CONSULT ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the test items, check that the headlamp (HI) is turned ON.

Hi : Headlamp (HI) ON
Off : Headlamp (HI) OFF

NOTE:

ON/OFF is repeated 1 second each.

Is the inspection result normal?

YES >> Headlamp (HI) circuit is normal.

NO >> Refer to [EXL-64, "WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure"](#).

WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure

INFOID:000000008746569

1. CHECK HEADLAMP (HI) OUTPUT VOLTAGE

CONSULT ACTIVE TEST

1. Turn power switch OFF.
2. Disconnect front combination lamp connector.
3. Turn power switch ON.
4. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
5. With operating the test items, check voltage between IPDM E/R harness connector and ground.

(+)			(-)	Test item	Voltage (Approx.)	
IPDM E/R						
Connector		Terminal				
RH	E15	49	Ground	EXTERNAL LAMPS	Hi	Battery voltage
					Off	0 V
LH		50			Hi	Battery voltage
					Off	0 V

Is the inspection result normal?

YES >> GO TO 2.

NO >> GO TO 3.

2. CHECK HEADLAMP (HI) OPEN CIRCUIT

1. Turn power switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and front combination lamp harness connector.

IPDM E/R			Front combination lamp		Continuity
Connector		Terminal	Connector	Terminal	
RH	E15	49	E86	5	Yes
LH		50	E85		

Is the inspection result normal?

YES >> GO TO 5.

HEADLAMP (HI) CIRCUIT

[LED HEADLAMP]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair or replace harness.

3.CHECK HEADLAMP (HI) FUSE

1. Turn power switch OFF.
2. Check that the following fuses are not blown.

Unit	Location	Fuse No.	Capacity
Headlamp HI (RH)	IPDM E/R	#51	10 A
Headlamp HI (LH)		#52	

Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-29, "Removal and Installation"](#).
NO >> GO TO 4.

4.CHECK HEADLAMP HIGH (HI) SHORT CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
RH	E15	49	No
LH		50	

Is the inspection result normal?

- YES >> Replace fuse. (Replace IPDM E/R if the fuse is blown again.)
NO >> Repair or replace harness. And then replace the fuse.

5.CHECK HEADLAMP (HI) GROUND OPEN CIRCUIT

1. Turn power switch OFF.
2. Disconnect front combination lamp connector.
3. Check continuity between front combination lamp harness connector and ground.

Front combination lamp		Ground	Continuity
Connector	Terminal		
RH	E86	6	Yes
LH			

Is the inspection result normal?

- YES >> Replace headlamp (HI) bulb.
NO >> Repair or replace harness.

WITH DAYTIME RUNNING LIGHT SYSTEM

WITH DAYTIME RUNNING LIGHT SYSTEM : Component Function Check INFOID:000000008746570

1.CHECK HEADLAMP (HI) OPERATION

ⓂCONSULT ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the test items, check that the headlamp (HI) is turned ON.

Hi : Headlamp (HI) ON
Off : Headlamp (HI) OFF

NOTE:

ON/OFF is repeated 1 second each.

Is the inspection result normal?

- YES >> Headlamp (HI) circuit is normal.
NO >> Refer to [EXL-66, "WITH DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure"](#).

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

HEADLAMP (HI) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

WITH DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure

INFOID:000000008746571

1. CHECK HEADLAMP (HI) OUTPUT VOLTAGE

CONSULT ACTIVE TEST

1. Turn power switch OFF.
2. Disconnect headlamp high connector.
3. Turn power switch ON.
4. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
5. With operating the test items, check voltage between IPDM E/R harness connector and ground.

(+)		Terminal	(-)	Test item	Voltage (Approx.)
IPDM E/R					
Connector					
RH	E15	49	Ground	Hi	Battery voltage
					Off
LH		50		Hi	Battery voltage
				Off	0 V

Is the inspection result normal?

- YES >> GO TO 2.
NO >> GO TO 3.

2. CHECK HEADLAMP (HI) OPEN CIRCUIT

1. Turn power switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and front combination lamp harness connector.

IPDM E/R		Front combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E15	E86	5	Yes
LH		49		
		E85		

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Repair or replace harness.

3. CHECK HEADLAMP (HI) FUSE

1. Turn power switch OFF.
2. Check that the following fuses are not blown

Unit	Location	Fuse No.	Capacity
Headlamp HI (RH)	IPDM E/R	#51	10 A
Headlamp HI (LH)		#52	

Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-29, "Removal and Installation"](#).
NO >> GO TO 4.

4. CHECK HEADLAMP (HI) SHORT CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Terminal	Ground	Continuity
Connector				
RH	E15	49		No
LH		50		

HEADLAMP (HI) CIRCUIT

[LED HEADLAMP]

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> Replace fuse. (Replace IPDM E/R if the fuse is blown again.)

NO >> Repair or replace harness. And then replace the fuse.

5.CHECK ILLUMINATION STATUS OF HEADLAMPS

Check illumination status of headlamps.

Which headlamp does not turn ON?

RH >> GO TO 6.

LH >> GO TO 8.

6.CHECK HEADLAMP HI (RH) GROUND OPEN CIRCUIT-1

1. Remove daytime running light relay.

2. Check continuity between daytime running light relay harness connector and front combination lamp RH harness connector.

Daytime running light relay		Front combination lamp RH		Continuity
Connector	Terminal	Connector	Terminal	
E84	3	E86	6	Yes

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace harness.

7.CHECK HEADLAMP HI (RH) GROUND OPEN CIRCUIT-2

Check continuity between daytime running light relay harness connector and ground.

Daytime running light relay		Ground	Continuity
Connector	Terminal		
E84	4		Yes

Is the inspection result normal?

YES >> Replace headlamp (HI) bulb. (Bulb socket is abnormal.)

NO >> Repair or replace harness.

8.CHECK HEADLAMP HI (LH) GROUND OPEN CIRCUIT

Check continuity between front combination lamp LH harness connector and ground.

Front combination lamp LH		Ground	Continuity
Connector	Terminal		
E85	6		Yes

Is the inspection result normal?

YES >> Replace headlamp (HI) bulb. (Bulb socket is abnormal.)

NO >> Repair or replace harness.

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

EXL

HEADLAMP (LO) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

HEADLAMP (LO) CIRCUIT

Component Function Check

INFOID:000000008746572

1.CHECK HEADLAMP (LO) OPERATION

CONSULT ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the test items, check that the headlamp (LO) is turned ON.

Lo : Headlamp (LO) ON

Off : Headlamp (LO) OFF

Is the inspection result normal?

- YES >> Headlamp (LO) circuit is normal.
NO >> Refer to [EXL-68, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008746573

1.CHECK HEADLAMP (LO) OUTPUT VOLTAGE

CONSULT ACTIVE TEST

1. Turn power switch OFF.
2. Disconnect front combination lamp connector.
3. Turn power switch ON.
4. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
5. With operating the test items, check voltage between IPDM E/R harness connector and ground.

(+)			(-)	Test item	Voltage (Approx.)		
IPDM E/R							
Connector		Terminal	Ground	EXTERNAL LAMPS			
RH	E15	52				Lo	Battery voltage
		Off				0 V	
LH	E15	51				Lo	Battery voltage
		Off	0 V				

Is the inspection result normal?

- YES >> GO TO 2.
NO >> GO TO 3.

2.CHECK HEADLAMP (LO) OPEN CIRCUIT

1. Turn power switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and front combination lamp harness connector.

IPDM E/R			Front combination lamp		Continuity
Connector		Terminal	Connector	Terminal	
RH	E15	52	E86	2	Yes
LH		51	E85		

Is the inspection result normal?

- YES >> Perform the LED headlamp diagnosis. Refer to [EXL-72, "Diagnosis Procedure"](#).
NO >> Repair or replace harness.

3.CHECK HEADLAMP (LO) FUSE

1. Turn power switch OFF.
2. Check that the following fuses are not blown.

HEADLAMP (LO) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

Unit	Location	Fuse No.	Capacity
Headlamp LO (RH)	IPDM E/R	#54	15 A
Headlamp LO (LH)		#53	

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-29, "Removal and Installation"](#).

NO >> GO TO 4.

4. CHECK HEADLAMP (LO) SHORT CIRCUIT-1

1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
RH	E15	52	No
LH		51	

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness. And then replace the fuse.

5. CHECK HEADLAMP (LO) SHORT CIRCUIT-2

Ⓜ CONSULT ACTIVE TEST

1. Replace fuse.
2. Connect IPDM E/R connector.
3. Turn power switch ON.
4. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
5. Check that fuse is not blown when Lo button is operated.

Is the inspection result normal?

YES >> GO TO 6.

NO >> Replace IPDM E/R. Refer to [PCS-29, "Removal and Installation"](#).

6. CHECK HEADLAMP (LO) SHORT CIRCUIT-3

1. Turn power switch OFF.
2. Connect front combination lamp connector.
3. Check that headlamp turns ON when lighting switch is in the 2ND position.

Is the inspection result normal?

YES >> Refer to [GI-53, "Intermittent Incident"](#).

NO >> Replace LED headlamp control module.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

DAYTIME RUNNING LIGHT RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

DAYTIME RUNNING LIGHT RELAY CIRCUIT

Component Function Check

INFOID:000000008746574

1. CHECK DAYTIME RUNNING LIGHT OPERATION

CONSULT ACTIVE TEST

1. Select "DAYTIME RUNNING LIGHT" of BCM (HEADLAMP) active test item.
2. With operating the test items, check that daytime running light operation.

On : Daytime running light ON

Off : Daytime running light OFF

Is the inspection result normal?

- YES >> Daytime running light relay circuit is normal.
NO >> Refer to [EXL-70, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008746575

1. CHECK DAYTIME RUNNING LIGHT RELAY FUSE

1. Turn power switch OFF.
2. Check that the following fuse is not blown.

Unit	Fuse No.	Capacity
Daytime running light relay	#37	10 A

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Replace the fuse after repairing the applicable circuit.

2. CHECK DAYTIME RUNNING LIGHT RELAY POWER SUPPLY

1. Remove daytime running light relay.
2. Check voltage between daytime running light relay harness connector and ground.

(+)		(-)	Voltage (Approx.)
Daytime running light relay			
Connector	Terminal	Ground	Battery voltage
E84	1		
	5		

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace harness.

3. CHECK DAYTIME RUNNING LIGHT RELAY

Check daytime running light relay. Refer to [EXL-71, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Replace daytime running light relay.

4. CHECK DAYTIME RUNNING LIGHT RELAY CONTROL SIGNAL OUTPUT

CONSULT ACTIVE TEST

1. Install daytime running light relay.
2. Turn power switch ON.
3. Select "DAYTIME RUNNING LIGHT" of BCM (HEADLAMP) active test item.
4. With operating the test item, check voltage between IPDM E/R harness connector and ground.

DAYTIME RUNNING LIGHT RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

(+)		(-)	Test item	Voltage (Approx.)	
IPDM E/R					
Connector	Terminal				
E13	28	Ground	DAYTIME RUNNING LIGHT	On	0 V
			Off	Battery voltage	

Is the inspection result normal?

YES >> Daytime running light relay circuit is OK.

NO-1 (Fixed at 0 V)>>GO TO 5.

NO-2 (Fixed at battery voltage) >>Replace IPDM E/R. Refer to [PCS-29, "Removal and Installation"](#).

5.CHECK DAYTIME RUNNING LIGHT RELAY CONTROL SIGNAL OPEN CIRCUIT

- Turn power switch OFF.
- Remove daytime running light relay.
- Disconnect IPDM E/R harness connector.
- Check continuity between IPDM E/R harness connector and daytime running light relay harness connector.

IPDM E/R		Daytime running light relay		Continuity
Connector	Terminal	Connector	Terminal	
E13	28	E84	2	Yes

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace harness.

6.CHECK DAYTIME RUNNING LIGHT RELAY CONTROL SIGNAL SHORT CIRCUIT

Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E13	28		No

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-29, "Removal and Installation"](#).

NO >> Repair or replace harness.

Component Inspection

INFOID:000000008746576

EXL

1.CHECK DAYTIME RUNNING LIGHT RELAY

- Turn the power switch OFF.
- Remove daytime running light relay.
- Apply battery voltage to daytime running light relay- between terminals 1 and 2.
- Check continuity between daytime running light relay terminals.

Daytime running light relay			Condition	Continuity
Terminal				
E84	5	3	Apply	Yes
			Not Apply	No
	4		Apply	No
			Not Apply	Yes

Is the inspection result normal?

YES >> Daytime running light relay is normal.

NO >> Replace daytime running light relay.

LED HEADLAMP

Diagnosis Procedure

INFOID:000000008746577

1. CHECK HEADLAMP (LO) GROUND OPEN CIRCUIT

1. Turn power switch OFF.
2. Disconnect front combination lamp connector.
3. Check continuity between front combination lamp harness connector and ground.

Front combination lamp		Terminal	Ground	Continuity
Connector				Continuity
RH	E86	9	Ground	Yes
LH	E85			

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair or replace harness.

2. CHECK LED HEAD LAMP CONTROL MODULE

Install the normal LED headlamp control module to the applicable headlamp. Check that the lighting switch is turned ON. Refer to [EXL-63, "Diagnosis Procedure"](#).

Is the headlamp turned ON?

- YES >> Replace LED headlamp control module.
 NO >> GO TO 3.

3. CHECK HEADLAMP

Install the normal headlamp to the applicable headlamp. Check that the headlamp is turned ON. Refer to [EXL-63, "Diagnosis Procedure"](#).

Is the headlamp turned ON?

- YES >> Replace headlamp.
 NO >> LED headlamp is normal. Check headlamp control system.

HEADLAMP WARNING LAMP

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

HEADLAMP WARNING LAMP

Component Function Check

INFOID:000000008746578

1. CHECK HEADLAMP WARNING LAMP OPERATION

1. Turn power switch OFF.
2. Disconnect front combination lamp connector.
3. Check that headlamp warning lamp on combination meter turns ON when power switch is turned ON.

Is the inspection result normal?

- YES >> Headlamp warning lamp is normal.
NO >> Refer to [EXL-73. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008746579

1. LED HEADLAMP CONTROL MODULE FUSE

1. Turn power switch OFF.
2. Check that the following fuse is not blown.

Unit	Fuse No.	Capacity
LED headlamp control module	#5	10 A

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the applicable circuit. And then replace the fuse.

2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect front combination lamp connector.
2. Turn power switch ON.
3. Check voltage between front combination lamp harness connector and ground.

(+)		Terminal	(-)	Voltage (Approx.)
Front combination lamp				
Connector		2	Ground	Battery voltage
RH	E86			
LH	E85			

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace harness.

3. CHECK HEADLAMP WARNING LAMP SIGNAL CIRCUIT

Check voltage between front combination lamp harness connector and ground.

(+)		Terminal	(-)	Voltage (Approx.)
Front combination lamp				
Connector		1	Ground	Less than 0.5 V
RH	E86			
LH	E85			

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Replace LED head lamp control module

4. CHECK HEADLAMP WARNING LAMP SIGNAL SHORT CIRCUIT

1. Turn power switch OFF.
2. Disconnect combination meter connector.
3. Check continuity between combination meter harness connector and ground.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

HEADLAMP WARNING LAMP

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

Combination meter		Ground	Continuity
Connector	Terminal		
RH	M34	38	No
LH		39	

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness.

5.CHECK COMBINATION METER

Check combination meter. Refer to [MWI-87, "Work flow"](#).

Is the inspection result normal?

YES >> Refer to [EXL-98, "Diagnosis Procedure"](#).

NO >> Repair or replace malfunctioning part.

PARKING LAMP CIRCUIT

[LED HEADLAMP]

< DTC/CIRCUIT DIAGNOSIS >

PARKING LAMP CIRCUIT

Component Function Check

INFOID:000000008746581

1.CHECK PARKING LAMP OPERATION

CONSULT ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the test items, check that the parking lamp is turned ON.

TAIL : Parking lamp ON
Off : Parking lamp OFF

Is the inspection result normal?

- YES >> Parking lamp circuit is normal.
NO >> Refer to [EXL-75, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008746582

1.CHECK PARKING LAMP FUSE

1. Turn power switch OFF.
2. Check that the following fuse is not blown.

Unit	Location	Fuse No.	Capacity
<ul style="list-style-type: none">• Parking lamp• Front side marker lamp• Tail lamp (RH)• License plate lamp	IPDM E/R	#47	10 A

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2.CHECK PARKING LAMP SHORT CIRCUIT

1. Disconnect the following connectors.
 - IPDM E/R
 - Front combination lamp
 - Front side marker lamp
 - Rear combination lamp (RH)
 - License plate lamp
2. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E14	43		No
	44		

Is the inspection result normal?

- YES >> Replace fuse. (Replace IPDM E/R if blown fuse is found again.)
NO >> Repair or replace harness. And then replace the fuse.

3.CHECK PARKING LAMP BULB

Check applicable lamp bulb.

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Replace bulb.

4.CHECK PARKING LAMP OUTPUT VOLTAGE

CONSULT ACTIVE TEST

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

EXL

PARKING LAMP CIRCUIT

[LED HEADLAMP]

< DTC/CIRCUIT DIAGNOSIS >

1. Disconnect front combination lamp connector.
2. Turn power switch ON.
3. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
4. With operating the test items, check voltage between IPDM E/R harness connector and ground.

(+)		(-)	Test item		Voltage (Approx.)
IPDM E/R					
Connector	Terminal				
E14	43	Ground	EXTERNAL LAMPS	TAIL	Battery voltage
				Off	0 V

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace IPDM E/R. Refer to [PCS-29. "Removal and Installation"](#).

5. CHECK PARKING LAMP OPEN CIRCUIT

1. Turn power switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and front combination lamp harness connector.

IPDM E/R		Front combination lamp		Continuity	
Connector	Terminal	Connector	Terminal		
RH	E14	43	E86	4	Yes
LH		E85			

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace harness.

6. CHECK PARKING LAMP GROUND OPEN CIRCUIT

Check continuity between front combination lamp harness connector and ground.

Front combination lamp		Ground	Continuity
Connector	Terminal		
RH	E86	7	Yes
LH	E85		

Is the inspection result normal?

YES >> Check corresponding bulb socket and harness. Repair or replace if necessary.

NO >> Repair or replace harness.

FRONT SIDE MARKER LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

FRONT SIDE MARKER LAMP CIRCUIT

Component Function Check

INFOID:000000008746583

1.CHECK PARKING LAMP OPERATION

Check that the parking lamp is turned ON.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check parking lamp circuit. Refer to [EXL-75, "Component Function Check"](#).

2.CHECK FRONT SIDE MARKER LAMP OPERATION

ⓂCONSULT ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.

2. With operating the test items, check that the front side marker lamp is turned ON.

TAIL : Front side marker lamp ON

Off : Front side marker lamp OFF

Is the inspection result normal?

YES >> Front side marker lamp circuit is normal.

NO >> Refer to [EXL-77, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008746584

1.CHECK FRONT SIDE MARKER LAMP BULB

Check applicable lamp bulb.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace bulb.

2.CHECK FRONT SIDE MARKER LAMP OPEN CIRCUIT

1. Turn power switch OFF.

2. Disconnect IPDM E/R connector and front side marker lamp connector.

3. Check continuity between IPDM E/R harness connector and front side marker lamp harness connector.

IPDM E/R		Front side marker lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E14	E16	1	Yes
LH		E10		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3.CHECK FRONT SIDE MARKER LAMP GROUND OPEN CIRCUIT

Check continuity between front side marker lamp harness connector and ground.

Front side marker lamp		Ground	Continuity
Connector	Terminal		
RH	E16	2	Yes
LH	E10		

Is the inspection result normal?

YES >> Check corresponding bulb socket and harness. Repair or replace if necessary.

NO >> Repair or replace harness.

TAIL LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

TAIL LAMP CIRCUIT

Component Function Check

INFOID:000000008746585

1. CHECK TAIL LAMP OPERATION

CONSULT ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the test items, check that the tail lamp is turned ON.

TAIL : Tail Lamp ON

Off : Tail lamp OFF

Is the inspection result normal?

- YES >> Tail lamp circuit is normal.
NO >> Refer to [EXL-78, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008746586

1. CHECK PARKING LAMP OPERATION

Check that the parking lamp is turned ON.

Is the inspection result normal?

- YES-1 [When tail lamp (RH) does not turn ON.]>>GO TO 5.
YES-2 [When tail lamp (LH) does not turn ON.]>>GO TO 2.
NO >> Check parking lamp circuit. Refer to [EXL-75, "Component Function Check"](#).

2. CHECK TAIL LAMP (LH) FUSE

1. Turn power switch OFF.
2. Check that the following fuse is not blown.

Unit	Location	Fuse No.	Capacity
Tail lamp (LH)	IPDM E/R	#46	10 A

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 4.

3. CHECK TAIL LAMP (LH) OUTPUT VOLTAGE

CONSULT ACTIVE TEST

1. Disconnect rear combination lamp (LH) connector.
2. Turn power switch ON.
3. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
4. With operating the test items, check voltage between IPDM E/R harness connector and ground.

(+)		(-)	Test item	Voltage (Approx.)	
IPDM E/R					
Connector	Terminal				
E14	38	Ground	EXTERNAL LAMPS	TAIL	Battery voltage
				Off	0 V

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Replace IPDM E/R. Refer to [PCS-29, "Removal and Installation"](#).

4. CHECK TAIL LAMP (LH) SHORT CIRCUIT

1. Disconnect IPDM E/R connector and rear combination lamp (LH) connector.
2. Check continuity between IPDM E/R harness connector and ground.

TAIL LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

IPDM E/R		Ground	Continuity
Connector	Terminal		
E14	38		No

Is the inspection result normal?

- YES >> Replace fuse. (Replace IPDM E/R if blown is found again.)
- NO >> Repair or replace harness. And then replace the fuse.

5. CHECK TAIL LAMP OPEN CIRCUIT

1. Turn power switch OFF.
2. Disconnect IPDM E/R connector and rear combination lamp connector.
3. Check continuity between IPDM E/R harness connector and rear combination lamp harness connector.

IPDM E/R		Rear combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E14	44	B59	Yes
LH		38	B80	

Is the inspection result normal?

- YES >> GO TO 6.
- NO >> Repair or replace harness.

6. CHECK TAIL LAMP GROUND OPEN CIRCUIT

Check continuity between rear combination lamp harness connector and ground.

Rear combination lamp		Ground	Continuity
Connector	Terminal		
RH	B59	6	Yes
LH	B80		

Is the inspection result normal?

- YES >> Replace rear combination lamp.
- NO >> Repair or replace harness.

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

EXL

LICENSE PLATE LAMP CIRCUIT

[LED HEADLAMP]

< DTC/CIRCUIT DIAGNOSIS >

LICENSE PLATE LAMP CIRCUIT

Component Function Check

INFOID:000000008746587

1. CHECK TAIL LAMP (RH) OPERATION

Check that the tail lamp (RH) is turned ON.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check tail lamp circuit. Refer to [EXL-78, "Component Function Check"](#).

2. CHECK LICENSE PLATE LAMP OPERATION

ⓐ CONSULT ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.

2. With operating the lighting switch, check that the license plate lamp is turned ON.

TAIL : License plate lamp ON

Off : License plate lamp OFF

Is the inspection result normal?

YES >> License plate lamp circuit is normal.

NO >> Refer to [EXL-80, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008746588

1. CHECK LICENSE PLATE LAMP BULB

Check the applicable lamp bulb.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace bulb.

2. CHECK LICENSE PLATE LAMP OPEN CIRCUIT

1. Turn power switch OFF.

2. Disconnect IPDM E/R connector and license plate lamp connector.

3. Check continuity between IPDM E/R harness connector and license plate lamp harness connector.

IPDM E/R		License plate lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E14	B58	1	Yes
LH		B57		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK LICENSE PLATE LAMP GROUND OPEN CIRCUIT

Check continuity between license plate lamp harness connector and ground.

License plate lamp		Ground	Continuity
Connector	Terminal		
RH	B58	2	Yes
LH	B57		

Is the inspection result normal?

YES >> Check corresponding bulb socket and harness. Repair or replace if necessary.

NO >> Repair or replace harness.

FRONT FOG LAMP CIRCUIT

[LED HEADLAMP]

< DTC/CIRCUIT DIAGNOSIS >

FRONT FOG LAMP CIRCUIT

Component Function Check

INFOID:000000008746589

1.CHECK FRONT FOG LAMP OPERATION

CONSULT ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the test items, check that the front fog lamp is turned ON.

Fog : Front fog lamp ON

Off : Front fog lamp OFF

Is the measurement normal?

- YES >> Front fog lamp circuit is normal.
NO >> Refer to [EXL-81, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008746590

1.CHECK FRONT FOG LAMP FUSE

1. Turn power switch OFF.
2. Check that the following blown is not fusing.

Unit	Location	Fuse No.	Capacity
Front fog lamp	IPDM E/R	#50	15 A

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2.CHECK FRONT FOG LAMP SHORT CIRCUIT

1. Disconnect front fog connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
RH	E12	19	No
LH		20	

Is the inspection result normal?

- YES >> Replace fuse. (Replace IPDM E/R if the fuse is blown again.)
NO >> Repair or replace harness. And then replace the fuse.

3.CHECK FRONT FOG LAMP BULB

Check the applicable lamp bulb.

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Replace bulb.

4.CHECK FRONT FOG LAMP OUTPUT VOLTAGE

CONSULT ACTIVE TEST

1. Disconnect front fog lamp connector.
2. Turn power switch ON.
3. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
4. With operating the test items, check the voltage between IPDM E/R harness connector and ground.

FRONT FOG LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

(+)		Terminal	(-)	Test item	Voltage (Approx.)		
IPDM E/R							
Connector							
RH	E12	19	Ground	EXTERNAL LAMPS	Fog	Battery voltage	
						Off	0 V
LH		20				Fog	Battery voltage
						Off	0 V

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace IPDM E/R. Refer to [PCS-29, "Removal and Installation"](#).

5. CHECK FRONT FOG LAMP OPEN CIRCUIT

1. Turn power switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and front fog lamp harness connector.

IPDM E/R		Front fog lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E12	19	E48	Yes
LH		20	E30	

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace harness.

6. CHECK FRONT FOG LAMP GROUND CIRCUIT OPEN CIRCUIT

Check continuity between front fog lamp harness connector and ground.

Front fog lamp		Terminal	Ground	Continuity
Connector				
RH	E48	2		Yes
LH	E30			

Is the inspection result normal?

YES >> Refer to [GI-53, "Intermittent Incident"](#).

NO >> Repair or replace harness.

TURN SIGNAL LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

TURN SIGNAL LAMP CIRCUIT

Component Function Check

INFOID:000000008746591

1. CHECK TURN SIGNAL LAMP

CONSULT ACTIVE TEST

1. Select "FLASHER" of BCM (FLASHER) active test item.
2. With operating the test items, check that the turn signal lamps is turned ON.

- LH** : Turn signal lamps (LH) ON
- RH** : Turn signal lamps (RH) ON
- Off** : Turn signal lamps OFF

Is the inspection result normal?

- YES >> Turn signal lamp circuit is normal.
- NO >> Refer to [EXL-83. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008746592

1. CHECK TURN SIGNAL LAMP BULB



Check the applicable lamp bulb.

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Replace bulb.

2. CHECK TURN SIGNAL LAMP OUTPUT VOLTAGE

1. Turn power switch OFF.
2. Disconnect front combination lamp connector and rear combination lamp connector.
3. Turn power switch ON.
4. With operating the turn signal switch, check voltage between BCM harness connector and ground.

(+)		(-)	Condition	Voltage (Approx.)	
BCM					
Connector	Terminal				
LH	M25	Ground	Turn signal switch	LH	
				OFF	0 V
RH	61			RH	
				OFF	0 V

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> GO TO 4.

TURN SIGNAL LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

3. CHECK TURN SIGNAL LAMP OPEN CIRCUIT

1. Turn power switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and front combination lamp, side turn signal lamp or rear combination lamp harness connector.

Front turn signal lamp

BCM		Front combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	M25	61	E86	8
LH		60	E85	

Rear turn signal lamp

BCM		Rear combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	M25	61	B59	4
LH		60	B80	

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> Repair or replace harness.

4. CHECK TURN SIGNAL LAMP SHORT CIRCUIT

Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
RH	M69	61	No
LH		60	

Is the inspection result normal?

- YES >> Check each bulb socket for internal short circuit, and if check result is normal, replace BCM. Refer to [BCS-86, "Removal and Installation"](#).
 NO >> Repair or replace harness.

5. CHECK TURN SIGNAL LAMP GROUND OPEN CIRCUIT

Check continuity between BCM harness connector and front combination lamp or rear combination lamp and ground.

Front turn signal lamp

Front combination lamp		Ground	Continuity
Connector	Terminal		
RH	E86	7	Yes
LH	E85		

Rear turn signal lamp

Rear combination lamp		Ground	Continuity
Connector	Terminal		
RH	B59	7	Yes
LH	B80		

Is the inspection result normal?

- YES >> Check corresponding bulb socket and harness. Repair or replace if necessary.
 NO >> Repair or replace harness.

OPTICAL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

OPTICAL SENSOR

Component Function Check

INFOID:000000008746593

1.CHECK OPTICAL SENSOR SIGNAL BY CONSULT

CONSULT DATA MONITOR

1. Turn power switch ON.
2. Select "OPTISEN (DTCT)" of BCM (HEADLAMP) data monitor item.
3. Turn lighting switch AUTO.
4. With the optical sensor illuminating, check the monitor status.

Monitor item	Condition		Voltage (Approx.)
OPTISEN (DTCT)	Optical sensor	When illuminating	3.1 V or more *
		When shutting off light	0.6 V or less

*: Illuminates the optical sensor. The value may be less than the standard value if brightness is weak.

Is the inspection result normal?

- YES >> Optical sensor is normal.
 NO >> Refer to [EXL-85, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008746594

1.CHECK OPTICAL SENSOR POWER SUPPLY INPUT

1. Turn power switch ON.
2. Turn lighting switch AUTO.
3. Check voltage between optical sensor harness connector and ground.

(+)		(-)	Voltage (Approx.)
Optical sensor			
Connector	Terminal		
M16	1	Ground	5 V

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> GO TO 4.

2.CHECK OPTICAL SENSOR GROUND INPUT

Check voltage between optical sensor harness connector and ground.

(+)		(-)	Voltage (Approx.)
Optical sensor			
Connector	Terminal		
M16	3	Ground	0 V

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 6.

3.CHECK OPTICAL SENSOR SIGNAL OUTPUT

With illuminating the optical sensor, check voltage between optical sensor harness connector and ground.

OPTICAL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

(+)		(-)	Condition	Voltage (Approx.)
Optical sensor				
Connector	Terminal			
M16	2	Ground	Optical sensor	When illuminating 3.1 V or more *
				When shutting off light 0.6 V or less

*: Illuminate the optical sensor. The value may be less than the standard if brightness is weak.

Is the inspection result normal?

YES >> GO TO 7.

NO >> Replace the optical sensor.

4. CHECK OPTICAL SENSOR OPEN CIRCUIT

1. Turn power switch OFF.
2. Disconnect optical sensor connector and BCM connector.
3. Check continuity between optical sensor harness connector and BCM harness connector.

Optical sensor		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M16	1	M24	17	Yes

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness.

5. CHECK OPTICAL SENSOR SHORT CIRCUIT

Check continuity between optical sensor harness connector and ground.

Optical sensor		Ground	Continuity
Connector	Terminal		
M16	1		No

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-86, "Removal and Installation"](#).

NO >> Repair or replace harness.

6. CHECK OPTICAL SENSOR GROUND OPEN CIRCUIT

1. Turn power switch OFF.
2. Disconnect optical sensor connector and BCM connector.
3. Check continuity between optical sensor harness connector and BCM harness connector.

Optical sensor		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M16	3	M24	18	Yes

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-86, "Removal and Installation"](#).

NO >> Repair or replace harness.

7. CHECK OPTICAL SENSOR SIGNAL OPEN CIRCUIT

1. Turn power switch OFF.
2. Disconnect optical sensor connector and BCM connector.
3. Check continuity between optical sensor harness connector and BCM harness connector.

OPTICAL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

Optical sensor		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M16	2	M24	14	Yes

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair or replace harness.

8. CHECK OPTICAL SENSOR SHORT CIRCUIT

Check continuity between optical sensor harness connector and ground.

Optical sensor		Ground	Continuity
Connector	Terminal		
M16	2		No

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-86, "Removal and Installation"](#).

NO >> Repair or replace harness.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

HAZARD SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

HAZARD SWITCH

Component Function Check

INFOID:000000008746595

1.CHECK HAZARD SWITCH SIGNAL BY CONSULT

ⓐCONSULT DATA MONITOR

1. Turn power switch ON.
2. Select "HAZARD SW" of BCM (FLASHER) data monitor item.
3. With operating the hazard switch, check the monitor status.

Monitor item	Condition		Monitor status
HAZARD SW	Hazard switch	ON	On
		OFF	Off

Is the inspection result normal?

- YES >> Hazard switch circuit is normal.
 NO >> Refer to [EXL-88, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000008746596

1.CHECK HAZARD SWITCH SIGNAL INPUT

1. Turn power switch OFF.
2. Disconnect hazard switch connector.
3. Check voltage between hazard switch connector and ground.

(+)		(-)	Voltage (Approx.)
Hazard switch			
Connector	Terminal	Ground	Battery voltage
M45	2		

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> GO TO 2.

2.CHECK HAZARD SWITCH SIGNAL OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between hazard switch harness connector and BCM harness connector.

Hazard switch		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M45	2	M24	29	Yes

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair or replace harness.

3.CHECK HAZARD SWITCH SIGNAL SHORT CIRCUIT

Check continuity between hazard switch harness connector and ground.

Hazard switch		Ground	Continuity
Connector	Terminal		
M45	2		No

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-86, "Removal and Installation"](#).
 NO >> Repair or replace harness.

HAZARD SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

4. CHECK HAZARD SWITCH GROUND OPEN CIRCUIT

Check continuity between hazard switch harness connector and ground.

Hazard switch		Ground	Continuity
Connector	Terminal		Yes
M45	1		

Is the inspection result normal?

- YES >> Replace hazard switch.
- NO >> Repair or replace harness.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[LED HEADLAMP]

SYMPTOM DIAGNOSIS

EXTERIOR LIGHTING SYSTEM SYMPTOMS WITHOUT DAYTIME RUNNING LIGHT SYSTEM

WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Symptom Table

INFOID:000000008746597

CAUTION:

Perform the self-diagnosis with CONSULT before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom		Possible cause	Inspection item
Headlamp (HI) is not turned ON.	One side	<ul style="list-style-type: none"> • Fuse • Halogen bulb (HI) • Harness between IPDM E/R and front combination lamp • Harness between front combination lamp and ground • IPDM E/R 	Headlamp (HI) circuit Refer to EXL-64, "WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Component Function Check" .
	Both sides	Symptom diagnosis "BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON" Refer to EXL-96, "WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure" .	
High beam indicator lamp is not turned ON. [Headlamp (HI) is turned ON.]		Combination meter	<ul style="list-style-type: none"> • Combination meter • Data monitor "HI-BEAM IND" • BCM (HEAD LAMP) Active test "HEADLAMP"
Headlamp (LO) is not turned ON. [Headlamp warning lamp is not turned ON.]	One side	<ul style="list-style-type: none"> • Fuse • Harness between IPDM E/R and front combination lamp • IPDM E/R • LED headlamp control module 	Headlamp (LO) circuit Refer to EXL-68, "Component Function Check" .
	Both sides	Symptom diagnosis "BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON" Refer to EXL-98, "Diagnosis Procedure" .	
Head lamp (LO) is not turned ON, or only 1 piece of LED is turned ON. [Headlamp warning lamp is turned ON.]		<ul style="list-style-type: none"> • Front combination lamp • LED headlamp control module • Harness between front combination lamp and ground 	LED headlamp Refer to EXL-72, "Diagnosis Procedure" .
Each lamp is not turned ON/OFF using lighting switch AUTO.		<ul style="list-style-type: none"> • Combination switch • Harness between combination switch and BCM • BCM 	Combination switch Refer to BCS-85, "Symptom Table" .
		<ul style="list-style-type: none"> • Optical sensor • Harness between optical sensor and BCM • BCM 	Optical sensor Refer to EXL-85, "Component Function Check" .
Parking lamp is not turned ON.		<ul style="list-style-type: none"> • Fuse • Parking lamp bulb • Parking lamp bulb socket • Harness between IPDM E/R and front combination lamp • Harness between front combination lamp and ground • IPDM E/R 	Parking lamp circuit Refer to EXL-75, "Component Function Check" .

EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[LED HEADLAMP]

Symptom	Possible cause	Inspection item	
Front side marker lamp is not turned ON.	<ul style="list-style-type: none"> • Fuse • Front side marker lamp bulb • Front side marker lamp bulb socket • Harness between IPDM E/R and front side marker lamp • Harness between front side marker lamp and ground 	Front side marker lamp circuit Refer to EXL-77. "Component Function Check" .	
Tail lamp and rear side marker lamp are not turned ON.	<ul style="list-style-type: none"> • Fuse • Harness between IPDM E/R and rear combination lamp • Harness between rear combination lamp and ground • Rear combination lamp 	Tail lamp circuit Refer to EXL-78. "Component Function Check" .	
License plate lamp is not turned ON.	<ul style="list-style-type: none"> • License plate lamp bulb • License plate lamp bulb socket • Harness between IPDM E/R and license plate lamp • Harness between license plate lamp and ground 	License plate lamp circuit Refer to EXL-80. "Component Function Check" .	
Parking lamp, side marker lamp, tail lamp and license plate lamp are not turned OFF.	Symptom diagnosis "PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS ARE NOT TURNED ON" Refer to EXL-99. "Diagnosis Procedure" .		
Tail lamp indicator lamp is not turned ON. (Parking lamp, side marker lamp, tail lamp and license plate lamp are turned ON.)	Combination meter	<ul style="list-style-type: none"> • Combination meter Data monitor "LIGHT IND" • BCM (HEAD LAMP) Active test "TAIL LAMP" 	
Turn signal lamp does not blink.	Indicator lamp is normal. (Applicable side performs high flasher activation.)	<ul style="list-style-type: none"> • Turn signal lamp bulb • Turn signal lamp bulb socket • Harness between BCM and each turn signal lamp 	Turn signal lamp circuit Refer to EXL-83. "Component Function Check" .
	Indicator lamp is included.	<ul style="list-style-type: none"> • Combination switch • Harness between combination switch and BCM • BCM 	Combination switch Refer to BCS-85. "Symptom Table" .
Turn signal indicator lamp does not blink. (Turn signal lamp is normal.)	One side	Combination meter	—
	Both sides (Always)	<ul style="list-style-type: none"> • Turn signal indicator lamp signal • BCM • Combination meter 	<ul style="list-style-type: none"> • Combination meter Data monitor "TURN IND" • BCM (FLASHER) Active test "FLASHER"
	Both sides (Only when activating hazard warning lamp with power switch OFF)	<ul style="list-style-type: none"> • Combination meter power supply and ground circuit • Combination meter 	Combination meter Power supply and ground circuit Refer to MWI-92. "COMBINATION METER : Diagnosis Procedure" .
<ul style="list-style-type: none"> • Hazard warning lamp does not activate. • Hazard warning lamp continues activating. (Turn signal is normal.) 	<ul style="list-style-type: none"> • Hazard switch • Harness between hazard switch and BCM • BCM 	Hazard switch Refer to EXL-88. "Component Function Check" .	

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

EXL

EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[LED HEADLAMP]

Symptom		Possible cause	Inspection item
Front fog lamp is not turned ON.	One side	<ul style="list-style-type: none"> • Front fog lamp bulb • Harness between IPDM E/R and front fog lamp • IPDM E/R 	Front fog lamp circuit Refer to EXL-81, "Component Function Check" .
	Both sides	Symptom diagnosis "BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON" Refer to EXL-100, "Diagnosis Procedure" .	
Front fog lamp indicator is not turned ON. (Front fog lamp is turned ON.)		Combination meter	<ul style="list-style-type: none"> • Combination meter • Data monitor "FR FOG IND" • BCM (HEAD LAMP) • Active test "FR FOG LAMP"

WITH DAYTIME RUNNING LIGHT SYSTEM

WITH DAYTIME RUNNING LIGHT SYSTEM : Symptom Table

INFOID:000000008746598

CAUTION:

Perform the self-diagnosis with CONSULT before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom		Possible cause	Inspection item
Headlamp (HI) is not turned ON.	One side	<ul style="list-style-type: none"> • Fuse • Halogen bulb (HI) • Harness between IPDM E/R and headlamp (HI) • Harness between headlamp (HI) and ground • IPDM E/R 	Headlamp (HI) circuit Refer to EXL-65, "WITH DAYTIME RUNNING LIGHT SYSTEM : Component Function Check" .
		<ul style="list-style-type: none"> • Harness between IPDM E/R and daytime running light relay • Daytime running light relay • IPDM E/R 	Daytime running light relay circuit Refer to EXL-70, "Component Function Check" .
	Both sides	Symptom diagnosis "BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON" Refer to EXL-96, "WITH DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure" .	
High beam indicator lamp is not turned ON. [Headlamp (HI) is turned ON.]		Combination meter	<ul style="list-style-type: none"> • Combination meter • Data monitor "HI-BEAM IND" • BCM (HEAD LAMP) • Active test "HEADLAMP"
Headlamp (LO) is not turned ON.	One side	<ul style="list-style-type: none"> • Fuse • Xenon bulb (LO) • Harness between IPDM E/R and headlamp lamp (LO) • Harness between headlamp (LO) and ground • IPDM E/R 	Headlamp (LO) circuit Refer to EXL-68, "Component Function Check" .
	Both sides	Symptom diagnosis "BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON" Refer to EXL-98, "Diagnosis Procedure" .	
Each lamp is not turned ON/OFF with lighting switch AUTO.		<ul style="list-style-type: none"> • Combination switch • Harness between combination switch and BCM • BCM 	Combination switch Refer to BCS-85, "Symptom Table" .
		<ul style="list-style-type: none"> • Optical sensor • Harness between optical sensor and BCM • BCM 	Optical sensor Refer to EXL-85, "Component Function Check" .

EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[LED HEADLAMP]

Symptom	Possible cause	Inspection item	
Daytime running light is not turned ON. [Headlamp (HI) is turned ON.]	<ul style="list-style-type: none"> • Fuse • Harness between IPDM E/R and daytime running light relay • Daytime running light relay • IPDM E/R • BCM • ECM • Combination meter 	<ul style="list-style-type: none"> • Daytime running light relay circuit Refer to EXL-70, "Component Function Check". • BCM (HEADLAMP) Data monitor "ENGINE STATE" • Combination meter Data monitor "PKB SW" • BCM (HEADLAMP) Active test "DAYTIME RUNNING LIGHT" 	
Parking lamp is not turned ON.	<ul style="list-style-type: none"> • Fuse • Parking lamp bulb • Harness between IPDM E/R and front combination lamp • IPDM E/R 	Parking lamp circuit Refer to EXL-75, "Component Function Check" .	
Front side marker lamp is not turned ON.	<ul style="list-style-type: none"> • Front side marker lamp bulb • Harness between IPDM E/R and front side marker lamp • Harness between front side marker lamp and ground • IPDM E/R 	Front side marker lamp circuit Refer to EXL-77, "Component Function Check" .	
Tail lamp (Rear side marker lamp) is not turned ON.	<ul style="list-style-type: none"> • Fuse • Tail lamp bulb • Harness between IPDM E/R and rear combination lamp • Harness between and rear combination lamp and ground 	Tail lamp circuit Refer to EXL-78, "Component Function Check" .	
License plate lamp is not turned ON.	<ul style="list-style-type: none"> • License plate lamp bulb • Harness between IPDM E/R and license plate lamp • Harness between license plate lamp and ground 	License plate lamp circuit Refer to EXL-80, "Component Function Check" .	
Parking lamp, side marker lamp, tail lamp and license plate lamp are not turned ON.	Symptom diagnosis "PARKING, SIDE MARKER, LICENSE PLATE AND TAIL LAMPS ARE NOT TURNED ON" Refer to EXL-99, "Diagnosis Procedure" .		
Tail lamp indicator is not turned ON. (Exterior lamps are turned ON.)	Combination meter	<ul style="list-style-type: none"> • Combination meter Data monitor "LIGHT IND" • BCM (HEADLAMP) Active test "TAIL LAMP" 	
Turn signal lamp does not blink.	Indicator lamp is normal. (Applicable side performs high flasher activation.)	<ul style="list-style-type: none"> • Turn signal lamp bulb • Door mirror • Harness between BCM and each turn signal lamp • Harness between each turn signal lamp and ground 	Turn signal lamp circuit Refer to EXL-83, "Component Function Check" .
	Indicator lamp is included.	<ul style="list-style-type: none"> • Combination switch • Harness between combination switch and BCM • BCM 	Combination switch Refer to BCS-85, "Symptom Table" .
Turn signal indicator lamp does not blink. (Turn signal lamp is normal.)	One side	Combination meter	—
	Both sides (Always)	<ul style="list-style-type: none"> • Turn signal indicator lamp signal • BCM • Combination meter 	<ul style="list-style-type: none"> • Combination meter Data monitor "TURN IND" • BCM (FLASHER) Active test "FLASHER"
	Both sides (Only when activating hazard warning lamp with ignition switch OFF)	<ul style="list-style-type: none"> • Combination meter power supply and ground circuit • Combination meter 	Combination meter Power supply and ground circuit Refer to MWI-92, "COMBINATION METER : Diagnosis Procedure" .

A
B
C
D
E
F
G
H
I
J
K

EXL

M
N
O
P

EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[LED HEADLAMP]

Symptom		Possible cause	Inspection item
<ul style="list-style-type: none"> • Hazard warning lamp does not activate. • Hazard warning lamp continues activating. (Turn signal is normal.) 		<ul style="list-style-type: none"> • Hazard switch • Harness between hazard switch and BCM • Harness between hazard switch and ground • BCM 	Hazard switch circuit Refer to EXL-88, "Component Function Check" .
Front fog lamp is not turned ON.	One side	<ul style="list-style-type: none"> • Front fog lamp bulb • Harness between IPDM E/R and front fog lamp • Harness between front fog lamp and ground • IPDM E/R 	Front fog lamp circuit Refer to EXL-81, "Component Function Check" .
	Both sides	Symptom diagnosis "BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON" Refer to EXL-100, "Diagnosis Procedure" .	

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[LED HEADLAMP]

NORMAL OPERATING CONDITION

Description

INFOID:000000008746599

LED HEADLAMP

- LED brightness and color may slightly change until the temperature becomes stable. This is not malfunction.
- Illumination time lag may occur between right and left. This is not malfunction.
- Brightness may be reduced due to aged deterioration of LED.
- Because of the dummy portion of connecting part of front combination lamp, water may be seemed as if it enters in headlamp after the vehicle is washed or after the rain. But, actually water is not entered in head lamp, and this is not malfunction.

AUTO LIGHT SYSTEM

The headlamp may not be turned ON/OFF immediately after passing dark area or bright area (short tunnel, sky bridge, shadowed area, etc.) while using the auto light system. This is caused by for the control difference. This is normal.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[LED HEADLAMP]

BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON WITHOUT DAYTIME RUNNING LIGHT SYSTEM

WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Description

INFOID:000000008746600

Both side headlamps (HI) are not turned ON when setting to the lighting switch HI or PASS.

WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure

INFOID:000000008746601

1.COMBINATION SWITCH INSPECTION

Check combination switch. Refer to [BCS-85. "Symptom Table"](#).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair or replace the malfunctioning part.

2.CHECK HEADLAMP (HI) REQUEST SIGNAL INPUT

ⓐCONSULT DATA MONITOR

1. Select "HL HI REQ" of IPDM E/R data monitor item.
2. With operating the lighting switch, check the monitor status.

Monitor item	Condition	Monitor status
HL HI REQ	Lighting switch (2ND) HI or PASS	On
	LO	Off

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Replace BCM. Refer to [BCS-86. "Removal and Installation"](#).

3.HEADLAMP (HI) CIRCUIT INSPECTION

Check headlamp (HI) circuit. Refer to [EXL-64. "WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Component Function Check"](#).

Is the inspection result normal?

- YES >> Refer to [GI-53. "Intermittent Incident"](#).
- NO >> Repair or replace the malfunctioning part.

WITH DAYTIME RUNNING LIGHT SYSTEM

WITH DAYTIME RUNNING LIGHT SYSTEM : Description

INFOID:000000008746602

Both side headlamps (HI) are not turned ON when setting to the lighting switch HI or PASS.

WITH DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure

INFOID:000000008746603

1.COMBINATION SWITCH INSPECTION

Check combination switch. Refer to [BCS-85. "Symptom Table"](#).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair or replace the malfunctioning part.

2.CHECK HEADLAMP (HI) REQUEST SIGNAL INPUT

ⓐCONSULT DATA MONITOR

1. Select "HL HI REQ" of IPDM E/R data monitor item.
2. With operating the lighting switch, check the monitor status.

Monitor item	Condition	Monitor status
HL HI REQ	Lighting switch (2ND) HI or PASS	On
	LO	Off

BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[LED HEADLAMP]

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace BCM. Refer to [BCS-86. "Removal and Installation"](#).

3. HEADLAMP (HI) CIRCUIT INSPECTION

Check headlamp (HI) circuit. Refer to [EXL-65. "WITH DAYTIME RUNNING LIGHT SYSTEM : Component Function Check"](#).

Is the inspection result normal?

YES >> Refer to [GI-53. "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning part.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[LED HEADLAMP]

BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON

Description

INFOID:000000008746604

Both side headlamps (LO) are not turned ON in any condition.

Diagnosis Procedure

INFOID:000000008746605

1. CHECK COMBINATION SWITCH

Check combination switch. Refer to [BCS-85. "Symptom Table"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

2. CHECK HEADLAMP (LO) REQUEST SIGNAL INPUT

Ⓟ CONSULT DATA MONITOR

1. Select "HL LO REQ" of IPDM E/R data monitor item.
2. With operating the lighting switch, check the monitor status.

Monitor item	Condition	Monitor status	
HL LO REQ	Lighting switch	2ND	On
		OFF	Off

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace BCM. Refer to [BCS-86. "Removal and Installation"](#).

3. HEADLAMP (LO) CIRCUIT INSPECTION

Check headlamp (LO) circuit. Refer to [EXL-68. "Component Function Check"](#).

Is the inspection result normal?

YES >> Refer to [GI-53. "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning part.

PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[LED HEADLAMP]

PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS ARE NOT TURNED ON

Description

INFOID:000000008746606

The parking, license plate, side marker, tail lamps and each illumination are not turned ON in any condition.

Diagnosis Procedure

INFOID:000000008746607

1.COMBINATION SWITCH INSPECTION

Check combination switch. Refer to [BCS-85. "Symptom Table"](#).

Is the combination switch normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

2.CHECK TAIL LAMP RELAY REQUEST SIGNAL INPUT

CONSULT DATA MONITOR

1. Select "TAIL & CLR REQ" of IPDM E/R data monitor item.
2. With operating the lighting switch, check the monitor status.

Monitor item	Condition		Monitor status
TAIL & CLR REQ	Lighting switch	1ST	On
		OFF	Off

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-29. "Removal and Installation"](#).

NO >> Replace BCM. Refer to [BCS-86. "Removal and Installation"](#).

BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[LED HEADLAMP]

BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON

Description

INFOID:000000008746608

The front fog lamps are not turned ON in any condition.

Diagnosis Procedure

INFOID:000000008746609

1.CHECK FUSE

Check that the following fuse is not blown.

Unit	Location	Fuse No.	Capacity
Front fog lamp	IPDM E/R	#50	15 A

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the applicable circuit. And then replace the fuse.

2.COMBINATION SWITCH INSPECTION

Check combination switch. Refer to [BCS-85, "Symptom Table"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning part.

3.CHECK FRONT FOG LAMP REQUEST SIGNAL INPUT

ⓅCONSULT DATA MONITOR

1. Select "FR FOG REQ" of IPDM E/R data monitor item.

2. With operating the front fog lamp switch, check the monitor status.

Monitor item	Condition	Monitor status
FR FOG REQ	Front fog lamp switch (With lighting switch 2ND)	ON
		OFF

Is the item status normal?

YES >> Replace IPDM E/R. Refer to [PCS-29, "Removal and Installation"](#).

NO >> Replace BCM. Refer to [BCS-86, "Removal and Installation"](#).

HEADLAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >

[LED HEADLAMP]

PERIODIC MAINTENANCE

HEADLAMP AIMING ADJUSTMENT

Description

INFOID:000000008746610

PREPARATION BEFORE ADJUSTING

NOTE:

- For details, refer to the regulations in your own country.
- Perform aiming if the vehicle front body has been repaired and/or the headlamp assembly has been replaced.

Before performing aiming adjustment, check the following.

- Adjust the tire pressure to the specification.
- Fill with coolant and each oil.
- Maintain the unloaded vehicle condition. (Remove luggage from the passenger compartment and the trunk room.)

NOTE:

Do not remove the on-vehicle tool.


- Wipe out dirt on the headlamp.

CAUTION:

Never use organic solvent (thinner, gasoline etc.)

- Ride alone on the driver seat.

AIMING ADJUSTMENT SCREW



A Headlamp RH (UP/DOWN) adjustment screw B. Headlamp LH (UP/DOWN) adjustment screw

← : Vehicle center

HEADLAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >

[LED HEADLAMP]

	Adjustment screw	Rotation	Facing direction
A	Headlamp RH (UP/DOWN)	Clockwise	DOWN
		Counterclockwise	UP
B	Headlamp LH (UP/DOWN)	Clockwise	DOWN
		Counterclockwise	UP


Aiming Adjustment Procedure

INFOID:000000008746611

1. Place the screen.
 - NOTE:**
 - Stop the vehicle facing the wall.
 - Place the board on a plain road vertically.
2. Face the vehicle with the screen. Maintain 10 m (32.8 ft) between the headlamp center and the screen.
3. Start the engine. Turn the headlamp (LO) ON.
 - NOTE:**
 - Shut off the headlamp light with the board to prevent from illuminating the adjustment screen.
 - CAUTION:**
 - Never cover the lens surface with a tape etc. The lens is made of resin.**
4. Measure the distance (X) between the horizontal center line of headlamp (H) and the cutoff line (A) within the light axis measurement range (R) from the vertical center line ahead of headlamp (V).

Light axis measurement range (R) : 350 ± 175 mm (13.78 ± 6.89 in)

Low beam distribution on the screen




5. Adjust the cutoff line height (X) with the aiming adjustment screw so as to enter in the adjustment range (M–N) according to the horizontal center line of headlamp (H).

unit: mm (in)

Horizontal center line of headlamp (H)	Highest cutoff line height (M)	Lowest cutoff line height (N)
700 (27.56) or less	4 (0.16)	30 (1.18)
701(27.60) – 800 (31.50)	4 (0.16)	30 (1.18)
801 (31.54) or more	17 (0.67)	44 (1.73)

Side view



Distance between the headlamp center and the screen (L) : 10 m (32.8 ft)

FRONT FOG LAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >

[LED HEADLAMP]

FRONT FOG LAMP AIMING ADJUSTMENT

Description

INFOID:000000008746612

PREPARATION BEFORE ADJUSTING

NOTE:

- For details, refer to the regulations in your own country.
- Perform aiming if the vehicle front body has been repaired and/or the fog lamp assembly has been replaced.

Before performing aiming adjustment, check the following.

- Adjust the tire pressure to the specification.
- Fill with coolant and each oil.
- Maintain the unloaded vehicle condition. (Remove luggage from the passenger compartment and the trunk room.)

NOTE:

Do not remove the temporary tire, jack and on-vehicle tool.

- Wipe out dirt on the fog lamp.

CAUTION:

Never use organic solvent (thinner, gasoline etc.)

- Ride alone on the driver seat.

AIMING ADJUSTMENT SCREW

- Turn the aiming adjusting screw for adjustment.


A: DOWN

B: UP

- For the position and direction of the adjusting screw, refer to the figure.

NOTE:

A screwdriver or hexagonal wrench [6 mm (0.24 in)] can be used for adjustment.



Aiming Adjustment Procedure

INFOID:000000008746613

1. Place the screen.

NOTE:

- Stop the vehicle facing the wall.
- Place the board on a plain road vertically.

2. Face the vehicle with the screen. Maintain 10 m (32.8 ft) between the front fog lamp center and the screen.

3. Start the motor. Turn the front fog lamp ON.

NOTE:

Shut off the headlamp light with the board to prevent from illuminating the adjustment screen.

CAUTION:

Never cover the lens surface with a tape etc. The lens is made of resin.

4. Adjust the cutoff line height (A) with the aiming adjustment screw so that the distance (X) between the horizontal center line of front fog lamp (H) and (A) becomes 150 mm (5.906 in).


A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

FRONT FOG LAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >

[LED HEADLAMP]

Front fog lamp light distribution on the screen



- A : Cutoff line
- B : High illuminance area
- H : Horizontal center line of front fog lamp
- V : Vertical center line of front fog lamp
- X : Cutoff line height

FRONT COMBINATION LAMP

< REMOVAL AND INSTALLATION >

[LED HEADLAMP]


REMOVAL AND INSTALLATION

FRONT COMBINATION LAMP

Exploded View

INFOID:000000008746614


REMOVAL



- 1. Front side marker lamp
- 2. Front combination lamp

: N·m (kg-m, in-lb)

DISASSEMBLY



- 1. Housing assembly
- 2. Front turn signal lamp bulb
- 3. Harness
- 4. Halogen bulb (HI)
- 5. Parking lamp bulb
- 6. Parking lamp bulb socket
- 7. Seal packing
- 8. LED headlamp control module
- 9. Bumper bracket

: Always replace after every disassembly.

: Vehicle front

CAUTION:

FRONT COMBINATION LAMP

< REMOVAL AND INSTALLATION >

[LED HEADLAMP]

- Disconnect the 12V battery negative terminal or remove the fuse to electric leakage. Refer to [EXL-7, "Precaution for Removing 12V Battery"](#).
- Never disassemble LED headlamp (LO) unit assembly.
- Replace front combination lamp, when malfunction LED headlamp unit.

Removal and Installation

INFOID:000000008746615

REMOVAL

1. Remove front bumper fascia. Refer to [EXT-13, "Removal and Installation"](#).
2. Remove front side marker lamp mounting bolts.
3. Pull up front side marker lamp, disconnect front side marker lamp harness connector and remove front side marker lamp.
4. Remove front combination lamp mounting bolts.
5. Pull out front combination lamp forward the vehicle, and then disconnect the connector before removing front combination lamp.

INSTALLATION

Note the following item, and then install in the reverse order of removal.

NOTE:

After installation, perform aiming adjustment. Refer to [EXL-101, "Description"](#).

Bulb Replacement


INFOID:000000008746616

CAUTION:


- Disconnect the 12V battery negative terminal or remove the fuse to electric leakage. Refer to [EXL-7, "Precaution for Removing 12V Battery"](#).
- After installing the bulb, install the resin cap and the bulb socket securely for watertightness.
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it to prevent damage to the bulb.
- Never touch bulb by hand while it is lit or right after being turned off to prevent a burns.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

PARKING LAMP BULB

1. Rotate resin cap (1) counterclockwise and unlock it.



2. Rotate parking lamp bulb socket (1) counterclockwise and unlock it.



3. Remove parking lamp bulb from bulb socket.

FRONT COMBINATION LAMP

< REMOVAL AND INSTALLATION >


[LED HEADLAMP]

HEADLAMP BULB (LO)


LED is used for headlamp bulb (LO). Always replace front combination lamp assembly as a unit, when bulb is to be replaced because of malfunction. Refer to [EXL-106, "Removal and Installation"](#).

HEADLAMP BULB (HI)

1. Rotate resin cap (1) counterclockwise and unlock it.



2. Remove parking lamp bulb and socket.
3. Rotate headlamp bulb (HI) (2) counterclockwise and unlock it.
4. Disconnect headlamp bulb (HI) harness connector (1).



5. Remove headlamp bulb (HI) from the headlamp housing assembly.

FRONT TURN SIGNAL LAMP BULB

1. Rotate bulb socket counterclockwise and unlock it.
2. Remove bulb from the bulb socket.

Disassembly and Assembly

INFOID:000000008746617

DISASSEMBLY

1. Rotate resin cap counterclockwise and unlock it.
2. Rotate parking lamp bulb socket counterclockwise and unlock it.
3. Disconnect parking lamp harness connector.
4. Rotate headlamp bulb (HI) counterclockwise and unlock it.
5. Disconnect headlamp bulb (HI) harness connector.
6. Rotate turn signal lamp bulb socket counterclockwise and unlock it.
7. Remove turn signal lamp bulb from bulb socket.
8. Remove LED headlamp control module mounting screws.
9. Disconnect LED headlamp control module harness connector, and then remove LED headlamp control module.
10. Remove combination lamp harness connector.

ASSEMBLY

Note the following items, and then assemble in the reverse order of disassembly.

CAUTION:

- Install LED headlamp control module securely.
- Always replace seal packing, when remove/replace LED headlamp control module.
- After installing the bulb, install the resin cap and the bulb socket securely for watertightness.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

FRONT COMBINATION LAMP


< REMOVAL AND INSTALLATION >

[LED HEADLAMP]

Installing service bracket


INFOID:000000008746618

If only installation part (A) as shown in the figure is damaged, and front combination lamp housing itself is not damaged, repair can be completed easily by installing service brackets.



Removal

1. Remove front combination lamp. Refer to [EXL-106, "Removal and Installation"](#).
2. Cut damaged section of installation part, then shape with sandpaper.




1. Front combination lamp RH
A. Cut line (R end)

2. Front combination lamp LH

Installation

1. Install service bracket (1) to headlamp housing (2) with screws.



2. Install front combination lamp to the vehicle.

NOTE:

After installation, perform aiming adjustment. Refer to [EXL-101, "Description"](#).

FRONT SIDE MARKER LAMP

< REMOVAL AND INSTALLATION >


[LED HEADLAMP]

FRONT SIDE MARKER LAMP

Exploded View


INFOID:000000009354883

REMOVAL



1. Front side marker lamp
2. Front combination lamp

DISASSEMBLY



1. Front side marker lamp housing
2. Front side marker lamp bulb socket
3. Front side marker lamp bulb

REMOVAL

1. Remove front side marker lamp mounting bolts.
2. Pull up front side marker lamp and disconnect the harness connector.
3. Remove front side marker lamp.

Removal and Installation

INFOID:000000009354882

Bulb Replacement

INFOID:000000009354884

CAUTION:

Revision: October 2013

EXL-109

2013 LEAF

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

FRONT SIDE MARKER LAMP

< REMOVAL AND INSTALLATION >

[LED HEADLAMP]

- **After installing the bulb, install the resin cap and the bulb socket securely for watertightness.**
- **Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it to prevent damage to the bulb.**
- **Never touch bulb by hand while it is lit or right after being turned off to prevent a burns.**
- **Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.**

FRONT SIDE MARKER LAMP BULB

1. Rotate bulb socket counterclockwise and unlock it.
2. Remove bulb from the bulb socket.

FRONT FOG LAMP


< REMOVAL AND INSTALLATION >

[LED HEADLAMP]

FRONT FOG LAMP

Exploded View

INFOID:000000008746619



- | | | |
|------------------------|---------------------------|-------------------|
| 1. Front bumper fascia | 2. Front fog lamp bracket | 3. Front fog lamp |
| 4. Front fog lamp bulb | 5. J nut | 6. Metal clip |

Removal and Installation

INFOID:000000008746620

REMOVAL

1. Remove the front under cover. Refer to [EXT-23, "FRONT UNDER COVER : Removal and Installation"](#).
2. Remove the fender protector (LH/RH). Refer to [EXT-21, "FENDER PROTECTOR : Removal and Installation"](#).
3. Disconnect the front fog lamp harness connector.
4. Remove the front fog lamp fixing screws and remove front fog lamp.

INSTALLATION

Note the following item, and then install in the reverse order of removal.

NOTE:

After installation, perform aiming adjustment. Refer to [EXL-103, "Description"](#)

Replacement

INFOID:000000008746621

CAUTION:

- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it to prevent damage to the bulb.
- Never touch bulb by hand while it is lit or right after being turned off to prevent a burns.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

FRONT FOG LAMP BULB


1. Remove front under cover. Refer to [EXT-23, "FRONT UNDER COVER : Removal and Installation"](#).

FRONT FOG LAMP

< REMOVAL AND INSTALLATION >

[LED HEADLAMP]

2. Remove front fender protector mounting bolts (A) and clip (B).



3. Remove front fog lamp bulb connector.
4. Rotate bulb counterclockwise and unlock it.

LIGHTING & TURN SIGNAL SWITCH

< REMOVAL AND INSTALLATION >

[LED HEADLAMP]

LIGHTING & TURN SIGNAL SWITCH

Exploded View

INFOID:000000008746624

The lighting & turn signal switch is integrated in the combination switch. Refer to [BCS-87. "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

OPTICAL SENSOR


< REMOVAL AND INSTALLATION >

[LED HEADLAMP]

OPTICAL SENSOR

Exploded View

INFOID:000000008746625



1. Optical sensor

2. Switch panel

△ : Pawl

Removal and Installation

INFOID:000000008746626

REMOVAL

1. Insert suitable tool between the switch panel and the instrument upper panel. Pull out the optical sensor upward.
2. Disconnect the optical sensor connector.
3. Remove optical sensor from switch panel.

INSTALLATION

Install in the reverse order of removal.

HAZARD SWITCH


< REMOVAL AND INSTALLATION >

[LED HEADLAMP]

HAZARD SWITCH

Exploded View

INFOID:000000008746629



1. Cluster lid C

2. Hazard switch

△ : Pawl

Removal and Installation

INFOID:000000008746630

REMOVAL

1. Remove cluster lid C. Refer to [IP-17, "Removal and Installation"](#).
2. Disengage hazard switch fixing pawls, and then remove hazard switch.

INSTALLATION

Install in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

REAR COMBINATION LAMP

< REMOVAL AND INSTALLATION >


[LED HEADLAMP]

REAR COMBINATION LAMP

Exploded View

INFOID:000000008746631


REMOVAL




1. Rear combination lamp

2. Grommet A

3. Grommet B

 : N·m (kg-m, in-lb)

DISASSEMBLY



1. Rear combination lamp harness

2. Rear turn signal bulb socket

3. Rear turn signal bulb

4. Buck-up lamp bulb socket

5. Buck-up lamp bulb

6. Rear combination lamp housing assembly

Removal and Installation

INFOID:000000008746632

CAUTION:

- Disconnect the 12V battery negative terminal or remove the fuse. Refer to [EXL-7, "Precaution for Removing 12V Battery"](#).

REAR COMBINATION LAMP

< REMOVAL AND INSTALLATION >

[LED HEADLAMP]


- Fogging of rear combination lamp inside is not a malfunction. Never replace parts. Fogging is a symptom in which inner surface of lens becomes whitely clouded, without there being visible water drops or water spots, as if lens is made of frosted-glass.

REMOVAL


1. Remove luggage side lower finisher. Refer to [INT-43. "LUGGAGE SIDE LOWER FINISHER : Removal and Installation"](#).
2. Disconnect rear combination lamp connector.
3. Remove rear combination lamp mounting bolts.
4. Insert a shop cloth (B) into clearance (A) between rear combination lamp (1) and rear fender panel (2), or apply protective tape.


CAUTION:

- To prevent rear fender panel paint surface from being damaged, always apply protection using a shop cloth or protective tape.
- When using protective tape, apply protective tape to both rear fender panel and rear combination lamp.



5. Pull rear combination lamp toward vehicle rear side, as shown by the arrow in the figure.

 : Clip



6. Remove rear combination lamp.

INSTALLATION

Note the following item, and then install in the reverse order of removal.


CAUTION:

REAR COMBINATION LAMP

< REMOVAL AND INSTALLATION >

[LED HEADLAMP]

When installing rear combination lamp, fix harness using harness fixing hook (A) on backside of rear combination lamp housing and place harness toward vehicle inside so that harness is not pinched by rear fender panel.



- 1. Harness
 - 2. Rear fender panel
 - 3. Rear fender extension
 - 4. Rear inner panel
- ← : Vehicle front

Replacement

INFOID:000000008746633

CAUTION:

- Disconnect the 12V battery negative terminal or remove the fuse. Refer to [EXL-7, "Precaution for Removing 12V Battery"](#).
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it. Never touch bulb by hand while it is lit or right after being turned off.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

STOP/TAIL LAMP BULB

LED is used for stop/tail lamp bulb. Always replace rear combination lamp assembly as a unit, when bulb is to be replaced because of malfunction.

REAR TURN SIGNAL LAMP BULB

1. Remove rear combination lamp mounting bolts.
2. Insert a shop cloth (B) into clearance (A) between rear combination lamp (1) and rear fender panel (2), or apply protective tape.

CAUTION:


- To prevent rear fender panel paint surface from being damaged, always apply protection using a shop cloth or protective tape.

REAR COMBINATION LAMP


< REMOVAL AND INSTALLATION >


[LED HEADLAMP]

- When using protective tape, apply protective tape to both rear fender panel and rear combination lamp.



3. Pull rear combination lamp toward vehicle rear side, as shown by the arrow in the figure.

 : Clip




4. Rotate bulb socket counterclockwise and unlock it.
5. Remove bulb from the socket.

BACK-UP LAMP BULB

1. Remove rear combination lamp mounting bolts.
2. Insert a shop cloth (B) into clearance (A) between rear combination lamp (1) and rear fender panel (2), and apply protective tape.

CAUTION:

- To prevent rear fender panel paint surface from being damaged, always apply protection using a shop cloth or protective tape.
- When using protective tape, apply protective tape to both rear fender panel and rear combination lamp.




A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P


REAR COMBINATION LAMP

< REMOVAL AND INSTALLATION >

[LED HEADLAMP]

3. Pull rear combination lamp toward vehicle rear side, as shown by the arrow in the figure.

 : Clip



4. Rotate bulb socket counterclockwise and unlock it.
5. Remove bulb from the socket.

HIGH-MOUNTED STOP LAMP


< REMOVAL AND INSTALLATION >

[LED HEADLAMP]


HIGH-MOUNTED STOP LAMP

Exploded View

INFOID:000000008746634



- 1. Rear spoiler
- 2. High-mounted stop lamp
- 3. High-mounted stop lamp cover
- 4. Rear washer nozzle

 : N·m (kg·m, in·lb)

●,▲: Indicates that the part is connected at points with same symbol in actual vehicle.

Removal and Installation

INFOID:000000008746635

REMOVAL

1. Remove rear spoiler. Refer to [EXT-36, "Removal and Installation"](#).
2. Remove high-mounted stop lamp cover mounting screws, and then remove high-mounted stop lamp cover.
3. Remove high-mounted stop lamp mounting screws.
4. Disconnect high-mounted stop lamp harness connector.
5. Remove high-mounted stop lamp.

INSTALLATION

Install in the reverse order of removal.

LICENSE PLATE LAMP


< REMOVAL AND INSTALLATION >

[LED HEADLAMP]


LICENSE PLATE LAMP

Exploded View

INFOID:000000008746636



1. License plate lamp bulb socket 2. License plate lamp bulb 3. License plate lamp housing

 : Pawl

Removal and Installation


INFOID:000000008746637

CAUTION:

Disconnect the 12V battery negative terminal or remove the fuse to electric leakage. Refer to [EXL-7](#), "[Precaution for Removing 12V Battery](#)".

REMOVAL

1. Remove license plate lamp in numerical order shown in the figure.



2. Disconnect license plate lamp connector, and then remove license plate lamp.

INSTALLATION

Install in the reverse order of removal.

Replacement

INFOID:000000008746638

CAUTION:

- Disconnect the 12V battery negative terminal or remove the fuse to electric leakage. Refer to [EXL-7](#), "[Precaution for Removing 12V Battery](#)".
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it to prevent damage to the bulb.
- Never touch bulb by hand while it is lit or right after being turned off to prevent a burns.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

LICENSE PLATE LAMP BULB

LICENSE PLATE LAMP

< REMOVAL AND INSTALLATION >

[LED HEADLAMP]

1. Remove license plate lamp.
2. Turn the bulb socket counterclockwise and unlock it.
3. Remove the bulb from the socket.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

REAR REFLEX REFLECTOR


< REMOVAL AND INSTALLATION >

[LED HEADLAMP]


REAR REFLEX REFLECTOR


Exploded View

INFOID:000000008746639



1. Reflex refractor

 : Pawl

 : N·m (kg-m, in-lb)

Removal and Installation

INFOID:000000008746640

REMOVAL

1. Remove rear bumper fascia. Refer to [EXT-17, "Removal and Installation"](#).
2. Remove rear reflex reflector fixing screws and disengage fixing pawls, and then remove rear reflex reflector.

INSTALLATION

Install in the reverse order of removal.

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[LED HEADLAMP]

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

Bulb Specifications

INFOID:000000008746641

Item	Type	Wattage (W)*
Front combination lamp	Headlamp (HI)	H9 (Halogen) 65
	Headlamp (LO)	LED —
	Front turn signal lamp	3457NAK (Amber) 21
	Parking lamp	W5W 5
Front side maker lamp	W5W 5	
Front fog lamp	H11 55	
Rear combination lamp	Stop lamp/Tail lamp	LED —
	Rear turn signal lamp	WY21W (Amber) 21
	Back-up lamp	W16W 16
	Rear side maker lamp	LED —
License plate lamp	W5W 5	
High-mounted stop lamp	LED —	

*: Always check with the Parts Department for the latest parts info.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

PRECAUTION

PRECAUTIONS

Precaution for Technicians Using Medical Electric

INFOID:000000009355110

OPERATION PROHIBITION

WARNING:

- Parts with strong magnet is used in this vehicle.
- Technicians using a medical electric device such as pacemaker must never perform operation on the vehicle, as magnetic field can affect the device function by approaching to such parts.

NORMAL CHARGE PRECAUTION

WARNING:

- If a technician uses a medical electric device such as an implantable cardiac pacemaker or an implantable cardioverter defibrillator, the possible effects on the devices must be checked with the device manufacturer before starting the charge operation.
- As radiated electromagnetic wave generated by PDM (Power Delivery Module) at normal charge operation may affect medical electric devices, a technician using a medical electric device such as implantable cardiac pacemaker or an implantable cardioverter defibrillator must not approach motor room [PDM (Power Delivery Module)] at the hood-opened condition during normal charge operation.

PRECAUTION AT TELEMATICS SYSTEM OPERATION

WARNING:

- If a technician uses implantable cardiac pacemaker or implantable cardioverter defibrillator (ICD), avoid the device implanted part from approaching within approximately 220 mm (8.66 in) from interior/exterior antenna.
- The electromagnetic wave of TCU might affect the function of the implantable cardiac pacemaker or the implantable cardioverter defibrillator (ICD), when using the service, etc.
- If a technician uses other medical electric devices than implantable cardiac pacemaker or implantable cardioverter defibrillator (ICD), the electromagnetic wave of TCU might affect the function of the device. The possible effects on the devices must be checked with the device manufacturer before TCU use.

PRECAUTION AT INTELLIGENT KEY SYSTEM OPERATION

WARNING:

- If a technician uses implantable cardiac pacemaker or implantable cardioverter defibrillator (ICD), avoid the device implanted part from approaching within approximately 220 mm (8.66 in) from interior/exterior antenna.
- The electromagnetic wave of Intelligent Key might affect the function of the implantable cardiac pacemaker or the implantable cardioverter defibrillator (ICD), at door operation, at each request switch operation, or at engine starting.
- If a technician uses other medical electric devices than implantable cardiac pacemaker or implantable cardioverter defibrillator (ICD), the electromagnetic wave of Intelligent Key might affect the function of the device. The possible effects on the devices must be checked with the device manufacturer before Intelligent Key use.

Point to Be Checked Before Starting Maintenance Work

INFOID:000000009346696

The high voltage system may starts automatically. It is required to check that the timer air conditioner and timer charge (during EVSE connection) are not set before starting maintenance work.

NOTE:

If the timer air conditioner or timer charge (during EVSE connection) is set, the high voltage system starts automatically even when the power switch is in OFF state.

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009346697

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS

PRECAUTIONS

[HALOGEN HEADLAMP]

< PRECAUTION >

system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

Precaution for Removing 12V Battery

INFOID:000000009346698

1. Check that EVSE is not connected.

NOTE:

If EVSE is connected, the air conditioning system may be automatically activated by the timer A/C function.

2. Turn the power switch OFF → ON → OFF. Get out of the vehicle. Close all doors (including back door).
3. Check that the charge status indicator lamp does not blink and wait for 5 minutes or more.

NOTE:

If the battery is removed within 5 minutes after the power switch is turned OFF, plural DTCs may be detected.

4. Remove 12V battery within 1 hour after turning the power switch OFF → ON → OFF.

NOTE:

- The 12V battery automatic charge control may start automatically even when the power switch is in OFF state.
- Once the power switch is turned ON → OFF, the 12V battery automatic charge control does not start for approximately 1 hour.

CAUTION:

- After all doors (including back door) are closed, if a door (including back door) is opened before battery terminals are disconnected, start over from Step 1.
- After turning the power switch OFF, if “Remote A/C” is activated by user operation, stop the air conditioner and start over from Step 1.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

< PREPARATION >

PREPARATION


PREPARATION

Special Service Tool

INFOID:000000009355109

The actual shape of the tools may differ from those illustrated here.

Tool number (TechMate No.) Tool name	Description
— (J-46534) Trim Tool Set	Removing trim components



AWJIA0483ZZ

COMPONENT PARTS

< SYSTEM DESCRIPTION >



[HALOGEN HEADLAMP]

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000009346699



ALLIA1269ZZ

A. Front combination lamp (back)

No.	Part	Function
1.	IPDM E/R	<ul style="list-style-type: none"> Controls the integrated relay, and supplies voltage to the load according to the request from BCM (via CAN communication). Refer to PCS-6, "Component Parts Location" for detailed installation location.
2.	Combination switch (Lighting & turn signal switch)	Refer to BCS-8, "COMBINATION SWITCH READING SYSTEM : System Description" .
3.	Combination meter	<ul style="list-style-type: none"> Blinks the turn signal indicator lamp and outputs the turn signal operating sound with integrated buzzer according to the request from BCM (via CAN communication). Turns the tail lamp indicator lamp, high beam indicator lamp, front fog lamp indicator lamp and rear fog lamp indicator lamp ON according to the request from BCM (via CAN communication).
4.	Hazard switch	Refer to EXL-130, "Hazard Switch" .
5.	BCM	<ul style="list-style-type: none"> Detects each switch condition by the combination switch reading function Judges that the exterior lamps are turned ON according to the vehicle condition Requests the headlamp relay (HI/LO), tail lamp relay and front fog lamp relay ON to IPDM E/R (via CAN communication) Requests the high beam indicator lamp, tail lamp indicator lamp and front fog lamp indicator lamp ON to the combination meter (via CAN communication) Judges the outside brightness from the optical sensor signal. Judges the ON/OFF timing according to the vehicle condition. Judges the ON/OFF status of the exterior lamp according to the outside brightness and the vehicle condition. Refer to BCS-5, "BODY CONTROL SYSTEM : Component Parts Location" for detailed installation location.
6.	Optical sensor	Refer to EXL-130, "Optical Sensor" .
7.	Front side marker lamp	Refer to EXL-239, "Bulb Specifications" .
8.	Front turn signal lamp	Refer to EXL-239, "Bulb Specifications" .
9.	Headlamp LO	Refer to EXL-239, "Bulb Specifications" .
10.	Headlamp HI	Refer to EXL-239, "Bulb Specifications" .

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[HALOGEN HEADLAMP]


No.	Part	Function
11.	Parking Lamp	Refer to EXL-239, "Bulb Specifications" .
12.	Front fog lamp	Refer to EXL-239, "Bulb Specifications" .
13.	Daytime running light relay*	Headlamp HI ground circuit is switched according to request from IPDM E/R.
14.	Front door switch (driver side)	Refer to DLK-20, "Door Switch" .
15.	Rear side marker lamp	Refer to EXL-239, "Bulb Specifications" .
16.	Tail lamp	Refer to EXL-239, "Bulb Specifications" .
17.	Rear turn signal lamp	Refer to EXL-239, "Bulb Specifications" .
18.	License plate lamp	Refer to EXL-239, "Bulb Specifications" .

*: With daytime running light system

Optical Sensor

INFOID:000000009346700


Optical sensor converts the outside brightness (lux) to voltage and transmits the optical sensor signal to BCM.



Hazard Switch

INFOID:000000009346701

Inputs the hazard switch ON/OFF signal to BCM.




SYSTEM

HEADLAMP SYSTEM

HEADLAMP SYSTEM : System Description

INFOID:000000009346702

SYSTEM DIAGRAM



OUTLINE

Headlamp is controlled by combination switch reading function and headlamp control function of BCM, and relay control function of IPDM E/R.

HEADLAMP (LO) OPERATION

- BCM detects the combination switch condition with the combination switch reading function.
- BCM transmits the low beam request signal to IPDM E/R with CAN communication according to the headlamp (LO) ON condition.

Headlamp (LO) ON condition

- Lighting switch 2ND
- Lighting switch AUTO (auto light function ON judgment)
- Lighting switch AUTO, with the front fog lamp switch ON and the power switch ON
- Lighting switch PASS

HEADLAMP (HI) OPERATION

- BCM transmits the high beam request signal to IPDM E/R and the combination meter with CAN communication according to the headlamp (HI) ON condition.

Headlamp (HI) ON condition

- Lighting switch HI with the lighting switch 2ND or AUTO (auto light function ON judgment)
- Lighting switch PASS
- Lighting switch AUTO, with the front fog lamp switch ON, the power switch ON and lighting switch HI
- Combination meter turns the high beam indicator lamp ON according to the high beam request signal.
- IPDM E/R turns the integrated headlamp high relay ON, and turns the headlamp ON according to the high beam request signal.

HEADLAMP SYSTEM : Fail-Safe

INFOID:000000009346703

CAN COMMUNICATION CONTROL

When CAN communication with BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If No CAN Communication Is Available With BCM

SYSTEM

< SYSTEM DESCRIPTION >

[HALOGEN HEADLAMP]


Control part	Fail-safe operation
Headlamp	<ul style="list-style-type: none"> • Turns ON the headlamp low relay when the power switch is turned ON • Turns OFF the headlamp low relay when the power switch is turned OFF • Headlamp high relay OFF

AUTO LIGHT SYSTEM (EXCEPT FOR CANADA)

AUTO LIGHT SYSTEM (EXCEPT FOR CANADA) : System Description

INFOID:000000009346704

SYSTEM DIAGRAM



OUTLINE

- Auto light system is controlled by each function of BCM and IPDM E/R.

Control by BCM

- Combination switch reading function
- Headlamp control function
- Auto light function
- Delay timer function
- Wiper linked auto lighting function
- Auto light adjustment system

Control by IPDM E/R

- Relay control function
- Auto light system has the auto light function (with twilight lighting function), wiper linked auto lighting function and delay timer function.
- Auto light function automatically turns ON/OFF the exterior lamps* and each illumination automatically, depending on the outside brightness.
- Wiper linked auto lighting function automatically turns ON/OFF the exterior lamps* and each illumination when the light switch is in the AUTO position, according to a front wiper operation.
- When auto light system turns the exterior lamps ON with the power switch OFF, delay timer function turns the exterior lamps OFF, depending on the vehicle condition with the auto light function after a certain period of time.

*: Headlamp (LO/HI), parking lamp, tail lamp, front fog lamp and side marker lamp (Headlamp HI and front fog lamp depend on the combination switch condition.)

NOTE:

The settings of the twilight lighting function and the wiper linked auto lighting function can be changed with CONSULT. Refer to [BCS-17, "HEADLAMP : CONSULT Function \(BCM - HEAD LAMP\)"](#).

AUTO LIGHT FUNCTION (WITH TWILIGHT LIGHTING FUNCTION)

Description

- BCM detects the combination switch condition with the combination switch reading function.
- BCM supplies voltage to the optical sensor when the power switch is turned ON or ACC.

SYSTEM

[HALOGEN HEADLAMP]

< SYSTEM DESCRIPTION >

- Optical sensor converts outside brightness (lux) to voltage and transmits the optical sensor signal to BCM.
- BCM filters outside brightness based on the optical sensor signal and judges outside brightness.
- BCM detects change status of outside brightness according to outside brightness from the optical sensor signal and filtered outside brightness. Based on the change status, BCM judges ON/OFF condition of the exterior lamp.
- BCM transmits each request signal to IPDM E/R and combination meter via CAN communication, according to ON/OFF condition by the auto light function.

NOTE:

As to ON/OFF timing, the sensitivity depends on settings. The settings can be changed with CONSULT. Refer to [BCS-17, "HEADLAMP : CONSULT Function \(BCM - HEAD LAMP\)"](#).

WIPER LINKED AUTO LIGHTING FUNCTION

BCM turns the exterior lamps ON when detecting 4 operations of the front wiper work the light switch in AUTO position.

NOTE:

BCM turns OFF the headlamps 3 seconds after the front wiper switch is turned from ON⇒OFF.

AUTO LIGHT ADJUSTMENT SYSTEM

The auto light adjustment system automatically, dims/brightens the display and combination meter, according to brightness outside the vehicle, when lighting switch 1ST, lighting switch 2ND or lighting switch AUTO is operated. Refer to [INL-11, "AUTO LIGHT ADJUSTMENT SYSTEM : System Description"](#).

DELAY TIMER FUNCTION

BCM turns the exterior lamps OFF depending on the vehicle condition with the auto light function when the power switch is turned OFF.

- Turns the exterior lamps OFF 5 minutes after detecting that any door opens. (Door switch ON).
- Turns the exterior lamps OFF a certain period of time* after closing all doors. (Door switch ON→OFF).
- Turns the exterior lamps OFF with the power switch ACC or the light switch OFF.

*: The preset time is 45 seconds. The timer operating time can be set by CONSULT. Refer to [BCS-17, "HEAD-LAMP : CONSULT Function \(BCM - HEAD LAMP\)"](#).

NOTE:

When any position other than the light switch AUTO is set, the auto light system function switches to the exterior lamp battery saver function.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P


SYSTEM

[HALOGEN HEADLAMP]

< SYSTEM DESCRIPTION >

AUTO LIGHT SYSTEM (EXCEPT FOR CANADA) : Circuit Diagram

INFOID:000000009346705




JMLIA1815GB

AUTO LIGHT SYSTEM (FOR CANADA)

AUTO LIGHT SYSTEM (FOR CANADA) : System Description

INFOID:00000009346706

SYSTEM DIAGRAM



OUTLINE

- Auto light system is controlled by each function of BCM and IPDM E/R.

Control by BCM

- Combination switch reading function
- Headlamp control function
- Auto light function
- Delay timer function
- Auto light adjustment system

Control by IPDM E/R

- Relay control function
- Auto light system has the auto light function and delay timer function.
- Auto light function automatically turns ON/OFF the exterior lamps* and each illumination automatically, depending on the outside brightness.
- When auto light system turns the exterior lamps ON with the power switch OFF, delay timer function turns the exterior lamps OFF, depending on the vehicle condition with the auto light function after a certain period of time.

*: Headlamp (LO/Hi), parking lamp, side marker lamp, tail lamp and front fog lamp (Headlamp HI and front fog lamp depend on the combination switch condition.)

AUTO LIGHT FUNCTION

- BCM detects the combination switch condition with the combination switch reading function.
- BCM supplies voltage to optical sensor when the power switch is turned ON or ACC.
- Optical sensor converts outside brightness (lux) to voltage and transmits the optical sensor signal to BCM.
- BCM judges outside brightness from the optical sensor signal and judges ON/OFF condition of the exterior lamp and each illumination according to the outside brightness.
- BCM transmits each request signal to IPDM E/R and combination meter via CAN communication according to ON/OFF condition by the auto light function.

NOTE:

ON/OFF timing differs based on the sensitivity from the setting. The setting can be set by CONSULT. Refer to [BCS-17, "HEADLAMP : CONSULT Function \(BCM - HEAD LAMP\)".](#)

AUTO LIGHT ADJUSTMENT SYSTEM

The auto light adjustment system automatically, dims/brightens the display, according to brightness outside the vehicle, when lighting switch 1ST, lighting switch 2ND or lighting switch AUTO is operated. Refer to [INL-11, "AUTO LIGHT ADJUSTMENT SYSTEM : System Description".](#)

DELAY TIMER FUNCTION

SYSTEM

< SYSTEM DESCRIPTION >

[HALOGEN HEADLAMP]

BCM turns the exterior lamp OFF depending on the vehicle condition with the auto light function when the power switch is turned OFF.

- Turns the exterior lamp OFF 5 minutes after detecting that any door opens. (Door switch ON).
- Turns the exterior lamp OFF a certain period of time* after closing all doors. (Door switch ON→OFF).
- Turns the exterior lamp OFF with the power switch ACC or the light switch OFF.

*: The preset time is 45 seconds. The timer operating time can be set by CONSULT. Refer to [BCS-17, "HEAD-LAMP : CONSULT Function \(BCM - HEAD LAMP\)"](#).


NOTE:

When any position other than the light switch AUTO is set, the auto light system function switches to the exterior lamp battery saver function.

DAYTIME RUNNING LIGHT SYSTEM : System Description

INFOID:000000009346708

SYSTEM DIAGRAM



OUTLINE

- Turns the headlamp high ON (high beam at approximately half illumination) as the daytime running light.
- Daytime running light is controlled by daytime running light control function and combination switch reading function of BCM, and relay control function of IPDM E/R.

DAYTIME RUNNING LIGHT OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM detects the vehicle condition according to power switch
- BCM detects the parking brake condition by the parking brake switch signal received from combination meter using CAN communication.
- BCM transmits the daytime running light request signal to IPDM E/R using CAN communication according to the daytime running light ON condition.

Daytime running light ON condition


- Vehicle condition READY
- Lighting switch OFF or 1ST
- Lighting switch AUTO, and the auto light function OFF judgment
- Parking brake switch OFF
- IPDM E/R controls the daytime running light relay 2 (ground-side) to turn ON according to the daytime running light request signal.
- Power is supplied from the daytime running light relay through headlamp high RH and IPDM E/R to headlamp high LH. And high beam headlamps are illuminated (approximately half illumination) as the daytime running light.

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : System Description

INFOID:000000009346710

SYSTEM DIAGRAM



OUTLINE

Turn signal lamp and the hazard warning lamp is controlled by combination switch reading function and the flasher control function of BCM.

TURN SIGNAL LAMP OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM supplies voltage to the right (left) turn signal lamp circuit when the power switch is ON and the turn signal switch is in the right (left) position. BCM blinks the turn signal lamp.

HAZARD WARNING LAMP OPERATION

BCM supplies voltage to both turn signal lamp circuit when the hazard switch is ON. BCM blinks the hazard warning lamp.

TURN SIGNAL INDICATOR LAMP AND TURN SIGNAL OPERATION

- BCM transmits the turn signal indicator lamp signal to the combination meter using CAN communication while the turn signal lamp and the hazard warning lamp are operating.
- Combination meter outputs the turn signal sound with the integrated buzzer while blinking the turn signal indicator lamp according to the turn signal indicator lamp signal.

HIGH FLASHER OPERATION

- BCM detects the turn signal lamp circuit status from the current value.
- BCM increases the turn signal lamp blinking speed if the bulb or harness open is detected with the turn signal lamp operating.

NOTE:

The blinking speed is normal while operating the hazard warning lamp.

PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM


PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM : System De-

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

scription

INFOID:000000009346712

SYSTEM DIAGRAM



OUTLINE

Parking, license plate, side marker and tail lamps are controlled by combination switch reading function and headlamp control function of BCM, and relay control function of IPDM E/R.

PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits the position light request signal to IPDM E/R and the combination meter via CAN communication according to the ON/OFF condition of the parking, license plate, side marker and tail lamps.

Parking, license plate, side marker and tail lamps ON condition

- Lighting switch 1ST
- Lighting switch 2ND
- Lighting switch AUTO, and the auto light function ON judgment
- Lighting switch AUTO, with the front fog lamp switch ON and the power switch ON
- IPDM E/R turns the integrated tail lamp relay ON and turns the parking, license plate, side marker and tail lamps ON according to the position light request signal.
- Combination meter turns the tail lamp indicator lamp ON according to the position light request signal.

PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM : Circuit Dia-

SYSTEM


[HALOGEN HEADLAMP]

< SYSTEM DESCRIPTION >

gram

INFOID:00000009346713

EXCEPT FOR CANADA




A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

SYSTEM

< SYSTEM DESCRIPTION >

[HALOGEN HEADLAMP]

FOR CANADA



PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM : Fail-Safe

INFOID:000000009346714

CAN COMMUNICATION CONTROL

When CAN communication with BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If No CAN Communication Is Available With BCM

SYSTEM

< SYSTEM DESCRIPTION >

[HALOGEN HEADLAMP]


Control part	Fail-safe operation
<ul style="list-style-type: none"> • Parking lamp • License plate lamp • Illumination • Tail lamp • Side marker lamp 	<ul style="list-style-type: none"> • Turns ON the tail lamp relay when the power switch is turned ON • Turns OFF the tail lamp relay when the power switch is turned OFF

FRONT FOG LAMP SYSTEM

FRONT FOG LAMP SYSTEM : System Description

INFOID:000000009346715

SYSTEM DIAGRAM



OUTLINE

Front fog lamp is controlled by combination switch reading function, front fog lamp control function of BCM, and relay control function of IPDM E/R.

FRONT FOG LAMP OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits the front fog lights request signal to IPDM E/R and the combination meter via CAN communication according to the front fog lamp ON condition.

Front fog lamp ON condition

- Front fog lamp switch ON, and any of the following condition is satisfied.(except for the high beam ON)

- Lighting switch 2ND
- Lighting switch AUTO and the power switch ON

IPDM E/R turns the integrated front fog lamp relay ON, and turns the front fog lamp ON according to the front fog lights request signal.

Combination meter turns the front fog lamp indicator lamp ON according to the front fog lights request signal.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

SYSTEM

< SYSTEM DESCRIPTION >

[HALOGEN HEADLAMP]


Control part	Fail-safe operation
Front fog lamp	Front fog lamp relay OFF

EXTERIOR LAMP BATTERY SAVER SYSTEM

EXTERIOR LAMP BATTERY SAVER SYSTEM : System Description

INFOID:000000009346718

SYSTEM DIAGRAM



OUTLINE

- Exterior lamp battery saver system is controlled by each function of BCM and IPDM E/R.

Control by BCM

- Combination switch reading function
- Headlamp control function
- Exterior lamp battery saver function

Control by IPDM E/R

- Relay control function
 - BCM turns the exterior lamps* OFF after a period of time to prevent the battery from over-discharge when the power switch is turned OFF with the exterior lamps ON.
- *: Headlamp (LO/Hi), parking lamp, tail lamp, side marker lamp, license plate lamp and front fog lamp

EXTERIOR LAMP BATTERY SAVER ACTIVATION

BCM activates the timer and turns the exterior lamp OFF 5 minutes after the power switch is turned from ON → OFF with the exterior lamps ON.

NOTE:

- Headlamp control function turns the exterior lamps ON normally when the power switch is turned ACC or set the vehicle to READY (both before and after the exterior lamp battery saver is turned OFF).
- The timer starts at the time that the lighting switch is turned from OFF → 1ST or 2ND with the exterior lamps OFF.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P


SYSTEM

< SYSTEM DESCRIPTION >

[HALOGEN HEADLAMP]

EXTERIOR LAMP BATTERY SAVER SYSTEM : Circuit Diagram

INFOID:00000009346719



DIAGNOSIS SYSTEM (BCM)

[HALOGEN HEADLAMP]

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000009346720

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Direct Diagnostic Mode	Description
Ecu Identification	The BCM part number is displayed.
Self Diagnostic Result	The BCM self diagnostic results are displayed.
Data Monitor	The BCM input/output data is displayed in real time.
Active Test	The BCM activates outputs to test components.
Work support	The settings for BCM functions can be changed.
Configuration	<ul style="list-style-type: none"> The vehicle specification can be read and saved. The vehicle specification can be written when replacing BCM.
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

SYSTEM APPLICATION

BCM can perform the following functions.

System	Sub System	Direct Diagnostic Mode						
		Ecu Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
Door lock	DOOR LOCK		x	x	x	x		
Rear window defogger	REAR DEFOGGER			x	x	x		
Warning chime	BUZZER			x	x			
Interior room lamp timer	INT LAMP			x	x	x		
Exterior lamp	HEADLAMP			x	x	x		
Wiper and washer	WIPER			x	x	x		
Turn signal and hazard warning lamps	FLASHER			x	x			
Air conditioner	AIR CONDITIONER			x				
Intelligent Key system	INTELLIGENT KEY		x	x	x	x		
Combination switch	COMB SW			x				
BCM	BCM	x	x			x	x	x
Immobilizer	IMMU		x	x	x			
Interior room lamp battery saver	BATTERY SAVER			x	x			
Trunk open	TRUNK			x				
Vehicle security system	THEFT ALM			x	x	x		
RAP system	RETAINED PWR			x				
Signal buffer system	SIGNAL BUFFER			x				
TPMS	AIR PRESSURE MONITOR		x	x	x	x		

HEADLAMP

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[HALOGEN HEADLAMP]

HEADLAMP : CONSULT Function (BCM - HEAD LAMP)

INFOID:000000009346721

DATA MONITOR

Monitor Item [Unit]	Description
PUSH SW [On/Off]	Indicates condition of power switch.
ENGINE STATE [Stop/Stall/Crank/Run]	Indicates engine status received from ECM on CAN communication line.
VEH SPEED 1 [km/h]	Indicates vehicle speed signal received from ABS on CAN communication line.
TURN SIGNAL R [On/Off]	Indicates condition of combination switch.
TURN SIGNAL L [On/Off]	
TAIL LAMP SW [On/Off]	
HI BEAM SW [On/Off]	
HEAD LAMP SW 1 [On/Off]	
HEAD LAMP SW 2 [On/Off]	
PASSING SW [On/Off]	
AUTO LIGHT SW [On/Off]	
FR FOG SW [On/Off]	
DOOR SW-DR [On/Off]	
DOOR SW-AS [On/Off]	Indicates condition of front door switch RH.
DOOR SW-RR [On/Off]	Indicates condition of rear door switch RH.
DOOR SW-RL [On/Off]	Indicates condition of rear door switch LH.
DOOR SW-BK [On/Off]	Indicates condition of trunk switch.
OPTI SEN (DTCT) [V]	Indicates outside brightness voltage signal from optical sensor.
OPTI SEN (FILT) [V]	Indicates outside brightness voltage signal from optical sensor filtered by BCM.

ACTIVE TEST

Test Item	Description
FR FOG LAMP	This test is able to check front fog lamp operation [On/Off].
DAYTIME RUNNING LIGHT	This test is able to check daytime running lamp operation [On/Off].
ILL DIM SIGNAL	This test is able to check head lamp illumination dimming operation [On/Off].

WORK SUPPORT

Support Item	Setting	Description
AUTO LIGHT LOGIC SET	MODE6	Autolamp function OFF.
	MODE5	
	MODE4	
	MODE3	Autolamp function ON at twilight.
	MODE2	Autolamp function ON at twilight or with wiper LO and HI operation.
	MODE1*	Autolamp function ON at twilight or with wiper INT, LO and HI operation.
BATTERY SAVER SET	Off	Exterior lamp battery saver function OFF.
	On*	Exterior lamp battery saver function ON.
CUSTOM A/LIGHT SETTING	MODE4	Less sensitive than normal setting (turns ON later).
	MODE3	More sensitive than MODE2.
	MODE2	More sensitive than normal setting (turns ON earlier).
	MODE1*	Normal setting.

DIAGNOSIS SYSTEM (BCM)

[HALOGEN HEADLAMP]

< SYSTEM DESCRIPTION >

Support Item	Setting		Description
ILL DELAY SET	MODE 8	180 sec.	Autolamp delay timer operation time.
	MODE 7	150 sec.	
	MODE 6	120 sec.	
	MODE 4	90 sec.	
	MODE 5	60 sec.	
	MODE 3	30 sec.	
	MODE 2	OFF	
	MODE 1*	45 sec.	

*: Initial setting

FLASHER

FLASHER : CONSULT Function (BCM - FLASHER)

INFOID:000000009346722

DATA MONITOR

Monitor Item [Unit]	Description
REQ SW -DR [On/Off]	Indicates condition of door request switch LH.
REQ SW -AS [On/Off]	Indicates condition of door request switch RH.
PUSH SW [On/Off]	Indicates condition of power switch.
TURN SIGNAL R [On/Off]	Indicates condition of turn signal function of combination switch.
TURN SIGNAL L [On/Off]	
HAZARD SW [On/Off]	Indicates condition of hazard switch.
RKE-LOCK [On/Off]	Indicates condition of lock signal from Intelligent Key.
RKE-UNLOCK [On/Off]	Indicates condition of unlock signal from Intelligent Key.
RKE-PANIC [On/Off]	Indicates condition of panic alarm signal from Intelligent Key.

ACTIVE TEST

Test Item	Description
FLASHER	This test is able to check turn signal lamp operation [Off/LH/RH].

WORK SUPPORT

Support Item	Setting	Description
HAZARD ANSWER BACK	Lock/Unlock	Hazard warning lamp answer back for LOCK and UNLOCK with request switch or Intelligent Key.
	Unlock Only	Hazard warning lamp answer back for UNLOCK only with request switch or Intelligent Key.
	Lock Only	Hazard warning lamp answer back for LOCK only with request switch or Intelligent Key.
	Off	Hazard warning lamp answer back OFF.

DIAGNOSIS SYSTEM (IPDM E/R)

Diagnosis Description

INFOID:000000009346723

AUTO ACTIVE TEST

Description

In auto active test mode, the IPDM E/R sends a drive signal to the following systems to check their operation.

- Rear window defogger
- Front wiper motor
- Parking lamp
- License plate lamp
- Tail lamp
- Front fog lamp
- Side marker lamp
- Headlamp (LO, HI)

Operation Procedure

NOTE:

Never perform auto active test in the following conditions.

- CONSULT is connected.
- Passenger door is open.

1. Turn the power switch OFF.
2. Turn the power switch ON, and within 20 seconds, press the driver door switch 10 times. Then turn the power switch OFF.
3. Turn the power switch ON within 10 seconds. After that the horn sounds once and the auto active test starts.

NOTE:

Never depress brake pedal while operating power switch so that auto active test is not activated.

4. After a series of the following operations is repeated 3 times, auto active test is completed.

NOTE:

- When auto active test mode has to be cancelled halfway through test, turn the power switch OFF.
- When auto active test is not activated, door switch may be the cause. Check door switch. Refer to [DLK-117](#), "[Component Function Check](#)".

Inspection in Auto Active Test Mode

When auto active test mode is actuated, the following operation sequence is repeated 3 times.


Operation sequence	Inspection location	Operation
1	Rear window defogger	10 seconds
2	Front wiper motor	LO for 5 seconds → HI for 5 seconds
3	<ul style="list-style-type: none"> • Parking lamp • License plate lamp • Tail lamp • Front fog lamp • Side marker lamp 	10 seconds
4	Headlamp	LO for 10 seconds → HI ON ⇔ OFF 5 times

DIAGNOSIS SYSTEM (IPDM E/R)

[HALOGEN HEADLAMP]

< SYSTEM DESCRIPTION >

Concept of auto active test



- IPDM E/R starts the auto active test with the door switch signals transmitted by BCM via CAN communication. Therefore, the CAN communication line between IPDM E/R and BCM is considered normal if the auto active test starts successfully.
- The auto active test facilitates troubleshooting if any systems controlled by IPDM E/R cannot be operated.

Diagnosis chart in auto active test mode

Symptom	Inspection contents	Possible cause
Rear window defogger does not operate	Perform auto active test. Does the rear window defogger operate?	YES BCM signal input circuit
		NO <ul style="list-style-type: none"> • Rear window defogger • Rear window defogger ground circuit • Harness or connector between IPDM E/R and rear window defogger • IPDM E/R
Any of the following components do not operate <ul style="list-style-type: none"> • Parking lamp • License plate lamp • Tail lamp • Front fog lamp • Headlamp (HI, LO) • Side marker lamp • Front wiper motor 	Perform auto active test. Does the applicable system operate?	YES BCM signal input circuit
		NO <ul style="list-style-type: none"> • Lamp or motor • Lamp or motor ground circuit • Harness or connector between IPDM E/R and applicable system • IPDM E/R

CONSULT Function (IPDM E/R)

INFOID:000000009346724

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with IPDM E/R.

Direct Diagnostic Mode	Description
Ecu Identification	The IPDM E/R part number is displayed.
Self Diagnostic Result	The IPDM E/R self diagnostic results are displayed.
Data Monitor	The IPDM E/R input/output data is displayed in real time.
Active Test	The IPDM E/R activates outputs to test components.
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

SELF DIAGNOSTIC RESULT

Refer to [PCS-18, "DTC Index"](#).

DATA MONITOR

DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

[HALOGEN HEADLAMP]

Monitor Item [Unit]	Main Signals	Description
TAIL&CLR REQ [On/Off]	×	Indicates position light request signal received from BCM on CAN communication line
HL LO REQ [On/Off]	×	Indicates low beam request signal received from BCM on CAN communication line
HL HI REQ [On/Off]	×	Indicates high beam request signal received from BCM on CAN communication line
FR FOG REQ [On/Off]	×	Indicates front fog light request signal received from BCM on CAN communication line
FR WIP REQ [Stop/1LOW/Low/Hi]	×	Indicates front wiper request signal received from BCM on CAN communication line
WIP AUTO STOP [STOP P/ACT P]	×	Indicates condition of front wiper auto stop signal
WIP PROT [Off/BLOCK]	×	Indicates condition of front wiper fail-safe operation
IGN RLY1 -REQ [On/Off]		Indicates power switch ON signal received from BCM on CAN communication line
IGN RLY [On/Off]	×	Indicates condition of ignition relay-1
PUSH SW [On/Off]		Indicates condition of power switch
DETENT SW [On/Off]		Indicates condition of shift position (park position switch)
DTRL REQ [Off]		Indicates daytime light request signal received from BCM on CAN communication line
HOOD SW [On/Off]		Indicates condition of hood switch
THFT HRN REQ [On/Off]		Indicates theft warning horn request signal received from BCM on CAN communication line
HORN CHIRP [On/Off]		Indicates horn reminder signal received from BCM on CAN communication line

ACTIVE TEST

Test item	Description
HORN	This test is able to check horn operation [On].
REAR DEFOGGER	This test is able to check rear window defogger operation [On/Off].
FRONT WIPER	This test is able to check wiper motor operation [Hi/Lo/Off].
EXTERNAL LAMPS	This test is able to check external lamp operation [Fog/Hi/Lo/TAIL/Off].

CAN DIAG SUPPORT MNTR

Refer to [LAN-13, "CAN Diagnostic Support Monitor"](#).

ECU DIAGNOSIS INFORMATION

BCM, IPDM E/R

List of ECU Reference

INFOID:000000009346725

ECU	Reference
BCM	BCS-28, "Reference Value"
	BCS-46, "Fail-safe"
	BCS-47, "DTC Inspection Priority Chart"
	BCS-48, "DTC Index"
IPDM E/R	PCS-14, "Reference Value"
	PCS-17, "Fail-Safe"
	PCS-18, "DTC Index"

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P


EXL

WIRING DIAGRAM

EXTERIOR LIGHTING SYSTEM

Wiring Diagram

INFOID:000000009346726



EXTERIOR LIGHTING SYSTEM HALOGEN

N : For Canada
U : USA


* : This connector is not shown in "Harness Layout".

AALWA0618GB

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[HALOGEN HEADLAMP]




AALWA0665GB

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[HALOGEN HEADLAMP]



AALWA0619GB


EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[HALOGEN HEADLAMP]

EXTERIOR LIGHTING SYSTEM HALOGEN - CONNECTORS


Connector No.	M4
Connector Name	DATA LINK CONNECTOR
Connector Color	WHITE



Connector No.	M16
Connector Name	OPTICAL SENSOR
Connector Color	WHITE



Connector No.	M18
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	-	-
2	-	-
3	LG	-
4	B	-
5	B	-
6	L	-
7	GR	-
8	G	-
9	-	-
10	-	-
11	SB	-
12	G	-
13	L	-
14	P	-
15	-	-
16	Y	-

Terminal No.	Color of Wire	Signal Name
1	Y	-
2	G	-
3	V	-

Terminal No.	Color of Wire	Signal Name
1	G	-
2	-	-
3	GR	-
4	L	-
5	G	-
6	V	-
7	P	-
8	P	-
9	B	-
10	R	-
11	LG	-
12	P	-
13	W	-
14	Y	-
15	LG	-
16	L	-


EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[HALOGEN HEADLAMP]


Terminal No.	Color of Wire	Signal Name
23	-	-
24	W	-
25	B	-
26	W	-
27	Y	-
28	-	-
29	W	-
30	L	-
31	L	-
32	P	-

Connector No.	M21
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	-	-
2	-	-
3	-	-
4	-	-
5	-	-
6	-	-
7	B	-
8	SHIELD	-
9	R	-
10	SB	-
11	P	-
12	V	-
13	GR	-
14	P	-
15	L	-
16	G	-
17	-	-
18	-	-
19	-	-
20	-	-
21	-	-
22	-	-

Connector No.	M19
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	-	-
2	LG	-
3	P	-
4	GR	-
5	GR	-
6	W	-
7	-	-
8	-	-
9	-	-
10	V	-
11	V	-
12	LG	-
13	BR	-
14	SB	-
15	L	-
16	G	-

AALIA1740GB

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[HALOGEN HEADLAMP]

Terminal No.	Color of Wire	Signal Name
90	W	HIGH SIDE ENGINE START SW ILLUMINATION LED
91	V	POWER POSITION LED (LOCK POSITION LED)
92	B	LOW SIDE ENGINE START SW ILLUMINATION LED OUTPUT
93	GR	SMART KEYLESS BUZZER OUTPUT
94	-	SMART KEYLESS BUZZER OUTPUT
95	-	-
96	BR	ACC RELAY OUTPUT
97	LG	STARTER RELAY OUTPUT
98	L	IGN RELAY OUTPUT1 (USM)
99	GR	IGN RELAY OUTPUT2 (ELEC)
100	P	REQUEST SW (AS)
101	-	-
102	BG	SHIFT N, P
103	-	-
104	-	-
105	W	BRAKE SW2
106	-	-
107	-	-
108	-	-
109	-	-
110	-	-

Connector No.	M23
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90
91	92	93	94	95	96	97	98	99	100	101	102	103	104	105	106	107	108	109	110

Terminal No.	Color of Wire	Signal Name
71	-	-
72	-	-
73	V	PUSH SW SIGNAL OUTPUT
74	-	-
75	LG	REQUEST SW (DR)
76	SB	ENGINE START SW
77	-	-
78	P	DOOR ANTENNA (DR) +
79	V	DOOR ANTENNA (DR) -
80	LG	DOOR ANTENNA (AS) +
81	Y	DOOR ANTENNA (AS) -
82	W	BACK DOOR ANTENNA +
83	B	BACK DOOR ANTENNA -
84	BR	ROOM ANTENNA 1 +
85	Y	ROOM ANTENNA 1 -
86	G	ROOM ANTENNA 2 +
87	R	ROOM ANTENNA 2 -
88	G	ROOM ANTENNA 3 +
89	R	ROOM ANTENNA 3 -

AALIA1741GB


EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[HALOGEN HEADLAMP]

Terminal No.	Color of Wire	Signal Name
36	P	COMBINATION SW OUTPUT 1
37	V	SHIFT P POSITION, PARKING POSITION SW
38	SB	INTELLIGENT TUNER
39	L	CAN-H
40	P	CAN-L

Terminal No.	Color of Wire	Signal Name
15	W	REAR DEFOGGER SW
16	R	MR OUTPUT
17	Y	AUTO LIGHT SENSOR POWER SUPPLY OUTPUT, KEYLESS TUNER, AUTO LIGHT SENSOR GND
18	L	
19	-	
20	-	
21	P	IMMOBILIZER ONE WAY COMMUNICATION (CLOCK)
22	-	
23	R	SECURITY INDICATOR OUTPUT
24	SB	DONGLE LINK
25	LG	IMMOBILIZER TWO WAY COMMUNICATION
26	-	
27	-	
28	-	
29	G	HAZARD SW
30	V	TRUNK/BACK DOOR OPENER SW
31	W	DOOR LOCK STATUS SW (DR)
32	GR	COMBINATION SW OUTPUT 5
33	Y	COMBINATION SW OUTPUT 4
34	W	COMBINATION SW OUTPUT 3
35	BG	COMBINATION SW OUTPUT 2



Terminal No.	Color of Wire	Signal Name
1	-	
2	L	COMBINATION SW INPUT 5
3	GR	COMBINATION SW INPUT 4
4	BR	COMBINATION SW INPUT 3
5	G	COMBINATION SW INPUT 2
6	V	COMBINATION SW INPUT 1
7	GR	KEY CYLINDER UNLOCK SW
8	R	KEY CYLINDER LOCK SW
9	BR	BRAKE SW1
10	-	
11	-	
12	Y	CENTRAL DOOR LOCK SW
13	BR	CENTRAL DOOR UNLOCK SW
14	G	AUTO LIGHT SENSOR INPUT

AALIA1742GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[HALOGEN HEADLAMP]

Connector No.	MZ9
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



104	103	102	101	100	99	98	97	96
110	109	108	107	106	105			

Terminal No.	Color of Wire	Signal Name
41	-	-
42	-	-
43	Y	DOOR SW (BACK)
44	LG	REAR WIPER AUTO STOP SW
45	BR	DOOR SW (AS)
46	R	DOOR SW (RR)
47	SB	DOOR SW (DR)
48	W	DOOR SW (RL)
49	L	LUGGAGE LAMP OUTPUT
50	-	-
51	P	REQUEST SW (TRUNK/BACK DOOR)
52	-	-
53	GR	TRUNK/BACK DOOR OPEN OUTPUT
54	P	REAR WIPER MOTOR OUTPUT
55	G	DOOR UNLOCK OUTPUT (RR, RL)

Connector No.	MZ7
Connector Name	COMBINATION SWITCH
Connector Color	WHITE



1	2	3	4	5	6
7	8	9	10	11	12
13	14				

Terminal No.	Color of Wire	Signal Name
1	LG	-
2	GR	-
3	R	-
4	SB	-
5	BR	-
6	B	-
7	W	-
8	L	-
9	BG	-
10	Y	-
11	P	-
12	V	-
13	GR	-
14	G	-
15	-	-
16	-	-

Connector No.	M25
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



56	57	58	59	60	61	62	63	64
65	66	67	68	69	70			

Terminal No.	Color of Wire	Signal Name
56	P	BATTERY SAVER OUTPUT
57	P	BATTERY (FUSE)
58	-	-
59	LG	DOOR UNLOCK OUTPUT (AS)
60	V	FLASHER OUTPUT (LEFT)
61	R	FLASHER OUTPUT (RIGHT)
62	-	-
63	BR	ROOM LAMP OUTPUT
64	-	-
65	V	DOOR LOCK OUTPUT
66	G	DOOR UNLOCK COMMON (DR)
67	B	GND
68	L	POWER WINDOW POWER SUPPLY (RAP)
69	R	POWER WINDOW POWER SUPPLY (BATTERY)
70	Y	BATTERY (F/L)


AALIA1743GB

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[HALOGEN HEADLAMP]


Connector No.	M40
Connector Name	JOINT CONNECTOR-M05
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-
3	BR	-
4	GR	-
5	L	-
6	L	-
7	L	-
8	L	-
9	L	-
10	L	-
11	LG	-
12	LG	-
13	L	-
14	R	-
15	P	-
16	P	-
17	P	-
18	P	-
19	P	-
20	P	-

Terminal No.	Color of Wire	Signal Name
21	-	-
22	GR	GND (FOR UPPER)
23	-	-
24	BG	PKB SW
25	SB	BRAKE OIL
26	B	ILL CONT OUT
27	R	A/BAG WARN
28	R	SECURITY
29	-	-
30	GR	8 P/R O/P
31	-	-
32	W	SDA (12C)
33	G	SCL (12C)
34	L	CHARGE LAMP
35	-	-
36	-	-
37	-	-
38	V	LED H LAMP R
39	LG	LED H LAMP L
40	W	BUCKLE SW FR DR

Connector No.	M34
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	LG	BAT
2	Y	BAT (FOR UPPER)
3	GR	IGN
4	BG	IGN (FOR UPPER)
5	B	GND1 (ILL)
6	B	GND2 (POWER)
7	-	-
8	Y	WASHER SW
9	BR	CHARGE CONNECT
10	-	-
11	-	-
12	V	SW GND
13	G	MODE B SW
14	Y	MODE A SW
15	BR	TRIP RESET SW
16	P	ILL CONT UP
17	G	UPPER ILL CONT
18	P	CAN-H
19	L	CAN-L
20	LG	AS SEATBELT W/L

AALIA1744GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


EXL

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >


[HALOGEN HEADLAMP]

Connector No.	M45
Connector Name	HAZARD SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	-
2	G	-
3	W	-
4	B	-

Connector No.	M44
Connector Name	JOINT CONNECTOR-M01
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	P	-
2	-	-
3	-	-
4	-	-
5	-	-
6	-	-
7	-	-
8	B	-
9	B	-
10	B	-
11	P	-
12	P	-
13	W	-
14	W	-
15	LG	-
16	R	-
17	R	-
18	W	-
19	W	-
20	W	-

Connector No.	M41
Connector Name	JOINT CONNECTOR-M06
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	SB	-
2	SB	-
3	SB	-
4	SB	-
5	L	-
6	L	-
7	L	-
8	L	-
9	L	-
10	L	-
11	LG	-
12	LG	-
13	LG	-
14	LG	-
15	P	-
16	P	-
17	P	-
18	P	-
19	P	-
20	P	-

AALIA1745GB


EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[HALOGEN HEADLAMP]

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

Connector No.	M50
Connector Name	JOINT CONNECTOR-M03
Connector Color	PINK



Terminal No.	Color of Wire	Signal Name
1	B	-
2	B	-
3	B	-
4	B	-
5	B	-
6	B	-
7	B	-
8	B	-
9	B	-
10	B	-
11	G	-
12	G	-
13	G	-
14	G	-
15	G	-
16	L	-
17	L	-
18	L	-
19	L	-
20	L	-

AALIA1746GB

EXTERIOR LIGHTING SYSTEM


< WIRING DIAGRAM >

[HALOGEN HEADLAMP]

Terminal No.	Color of Wire	Signal Name
60	Y	-
61	GR	-
62	W	-
63	BR	-
64	SHIELD	-
65	W	-
66	LG	-
67	R	-
68	G	-
69	BG	-
70	GR	-
71	R	-
72	R	-
73	B	-
74	W	-
76	L	-
80	W	-
81	LG	-
83	GR	-
84	L	-
85	Y	-
86	SB	-
88	R	-
89	G	-
90	SHIELD	-
91	Y	-
92	BR	-
93	W	-
94	P	-
95	L	-
96	P	-
97	G	-
98	V	-
99	LG	-
100	R	-

Terminal No.	Color of Wire	Signal Name
22	B	-
23	BG	-
24	B	-
26	G	-
27	B	-
28	B	-
25	W	-
29	R	-
31	R	-
32	W	-
33	GR	-
34	BR	-
35	BR	-
36	W	-
37	L	-
38	LG	-
39	SB	-
40	V	-
41	P	-
42	SB	-
43	G	-
44	LG	-
45	Y	-
46	R	-
47	W	-
48	L	-
49	G	-
50	L	-
51	SB	-
52	L	-
54	B	-
55	R	-
56	V	-
57	Y	-
58	L	-

Connector No.	M77
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R	-
2	L	-
3	V	-
4	LG	-
6	P	-
7	GR	-
9	G	-
10	L	-
11	L	-
12	Y	-
13	V	-
14	R	-
15	G	-
16	W	-
17	R	-
18	G	-
19	W	-
20	GR	-
21	P	-


AALIA1747GB

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[HALOGEN HEADLAMP]

Connector No.	E6
Connector Name	JOINT CONNECTOR-E01
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

Terminal No.	Color of Wire	Signal Name
3	L	-
4	L	-
5	-	-
6	L	-
7	P	-
8	P	-
9	P	-
10	P	-
11	-	-
12	P	-

Connector No.	E10
Connector Name	FRONT SIDE MARKER LAMP LH
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1	O	-
2	B/W	-

Connector No.	E11
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
9	B	GND (POWER)
10	-	-
11	-	-
12	-	-
13	-	-
14	R	RR DEF

Connector No.	E12
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
15	-	-
16	-	-
17	-	-
18	B/W	GND (SIGNAL)
19	W	FR FOG/L RH
20	V	FR FOG/L LH
21	-	-
22	-	-

Connector No.	E13
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
23	-	-
24	-	-
25	R	AUTO STOP SW
26	P	CAN-CL
27	L	CAN-CH
28	G	DTRL RLY
29	-	-
30	-	-
31	-	-
32	SB	HOOD SW
33	-	-
34	W	HORN RLY CONT

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >


[HALOGEN HEADLAMP]

Connector No.	E16
Connector Name	FRONT SIDE MARKER LAMP RH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	O	-
2	B/R	-

Connector No.	E15
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
47	-	-
48	-	-
49	Y	H/LAMP HI RH
50	G	H/LAMP HI LH
51	L	H/LAMP LO LH
52	P	H/LAMP LO RH
53	-	-
54	-	-
55	LG	FAST CHARGE
56	-	-
57	R	VCM IGN
58	O	REVERSE LAMP IGN
59	BR	ABS ECU IGN
60	GR	F/S RLY CONT
61	-	-
62	V	E-ACT/HAS IGN

Connector No.	E14
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
35	R	VCM VB
36	-	-
37	-	-
38	LG	TAIL 1 (WITHOUT SOLAR CELL)
38	R	TAIL 1 (WITH SOLAR CELL)
39	L	FR WIPER HI
40	-	-
41	SB	VCM RLY CONT
42	BR	VCM BAT
43	O	CLEARANCE/LH
44	B	TAIL 2
45	Y	FR WIPER LO
46	-	-

AALIA1880GB

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[HALOGEN HEADLAMP]

Connector No.	E26
Connector Name	FRONT COMBINATION LAMP LH (WITH HALOGEN HEADLAMPS)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	O	-
2	G	-
3	B/W	-
4	B/Y	-
5	Y	-
6	O	-

Connector No.	E27
Connector Name	REVERSE LAMP RELAY
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
1	O	-
2	SB	-
3	O	-
4	G	-

Connector No.	E30
Connector Name	FRONT FOG LAMP LH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	V	-
2	B/W	-

Connector No.	E44
Connector Name	JOINT CONNECTOR-E02
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	SB	-
2	SB	-
3	SB	-
4	SB	-
5	-	-
6	SB	-
7	O	-
8	O	-
9	O	-
10	O	-
11	O	-
12	-	-

Connector No.	E45
Connector Name	FRONT COMBINATION LAMP RH (WITH HALOGEN HEADLAMPS)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	O	-
2	Y	-
3	B/Y	-
4	B/W	-
5	G	-
6	P	-

Connector No.	E48
Connector Name	FRONT FOG LAMP RH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W	-
2	B/Y	-

AALIA1881GB

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

EXTERIOR LIGHTING SYSTEM


< WIRING DIAGRAM >

[HALOGEN HEADLAMP]

Terminal No.	Color of Wire	Signal Name
110	Y	COOLANT TEMPERATURE SENSOR
111	SB	ASCD STEERING SWITCH
112	B	P POSITION SW NO.2
113	O	BRAKE PEDAL POSITION SWITCH
115	V	CHARGING STATUS INDICATOR 1
116	SB	A/C RELAY
117	LG	CHARGE CONNECTOR LOCK ACTUATOR (+)
118	B	VCM GROUND
120	L	SENSOR GROUND (BATTERY CURRENT SENSOR)
121	W	SENSOR GROUND (COOLANT TEMPERATURE SENSOR)
122	B	SENSOR GROUND (ACCELERATOR PEDAL POSITION SENSOR 2)
123	BR	SENSOR GROUND (REFRIGERANT PRESSURE SENSOR)
124	W/L	ELECTRIC SHIFT SENSOR GND 2
125	BR	ASCD STEERING SWITCH GROUND
126	B/R	VCM GROUND
128	V	COOLING FAN CONTROL SIGNAL
129	Y	IMMEDIATE CHARGING SWITCH
130	W	CHARGE CONNECTOR LOCK ACTUATOR (-)

Terminal No.	Color of Wire	Signal Name
87	V	CHARGE CONNECTOR LOCK SWITCH INDICATOR (LOCK)
88	SB	M/C RELAY
89	BR	CHARGING STATUS INDICATOR 2
90	G	CHARGING STATUS INDICATOR 3
91	O	CHARGE CONNECTOR LOCK SWITCH INDICATOR (AUTO)
93	BR	CHARGE PORT ID OPENER SWITCH
94	O	CHARGE CONNECTOR LOCK SWITCH (LOCK)
95	Y	BATTERY CURRENT SENSOR
96	R	SENSOR POWER SUPPLY (BATTERY CURRENT SENSOR)
97	W	SENSOR POWER SUPPLY (ACCELERATOR PEDAL POSITION SENSOR 2)
98	L	SENSOR POWER SUPPLY (REFRIGERANT PRESSURE SENSOR)
99	R	P POSITION SW NO.1
101	P	STOP LAMP SWITCH
103	L	PLUG IN INDICATOR LAMP
104	R	CHARGE CONNECTOR LOCK RELAY POWER SUPPLY
107	L	BATTERY TEMPERATURE SENSOR
108	R	ACCELERATOR PEDAL POSITION SENSOR 2
109	B	REFRIGERANT PRESSURE SENSOR

Connector No.	E62
Connector Name	VCM
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
70	SB	REVERSE LAMP RELAY CONNECTION
72	P	DETECTING CIRCUIT SIGNAL
73	O	DETECTING CIRCUIT POWER SUPPLY
74	G	POWER ON POWER SUPPLY
75	L	CAN-H
76	P	CAN-L
78	SB	CHARGE CONNECTOR LOCK RELAY
79	R	12V BATTERY POWER SUPPLY
81	L	CHARGE CONNECTOR LOCK SWITCH (AUTO)
82	GR	CHARGE PORT LIGHT
83	W	ELECTRIC SHIFT SENSOR POWER SUPPLY 2
84	W	ELECTRIC SHIFT SENSOR NO.2
85	G	ELECTRIC SHIFT SENSOR NO.4
86	G	ELECTRIC SHIFT SENSOR NO.6

AALIA1882GB

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[HALOGEN HEADLAMP]

Connector No.	E102
Connector Name	STOP LAMP SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	-
2	SB	-
3	R	-
4	P	-

Connector No.	E77
Connector Name	DAYTIME LIGHT RELAY 1
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	B/R	-
2	P	-
3	L	-
5	P	-

Connector No.	E76
Connector Name	DAYTIME LIGHT RELAY 2
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	G	-
2	LG	-
3	B/Y	-
4	B/Y	-
5	LG	-

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

AALIA1883GB


EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[HALOGEN HEADLAMP]

58	L	-
60	LG	-
61	GR	-
62	W	-
63	SB	-
64	SHIELD	-
65	W	-
66	G	-
67	V	-
68	R	-
69	B	-
70	BR	-
71	LG	-
72	R	-
73	B	-
74	O	-
76	L	-
77	Y	-
80	P	-
81	SB	-
83	GR	-
84	L	-
85	O	-
86	BR	-
88	B	-
89	W	-
90	SHIELD	-
91	Y	-
92	BR	-
93	O	-
94	R	-
95	V	-
96	P	-
97	G	-
98	W	-
99	O	-
100	SB	-

20	BR	-
21	R	-
22	B	-
23	LG	-
24	B	-
25	W	-
26	W	-
27	B	-
28	O/L	-
29	W	-
31	R	-
32	W	-
33	G	-
34	BR	-
35	V	-
36	O	-
37	L	-
38	SB	-
39	P	-
40	V	-
41	O	-
42	Y	-
43	BR	-
44	W	-
45	G	-
46	P	-
47	LG	-
47	R	-
48	B	-
49	L	-
50	G	-
51	W	-
52	O	-
54	B	-
55	R	-
56	Y	-
57	Y	-



Terminal No.	Color of Wire	Signal Name
1	R	-
2	L	-
3	BW	-(WITHOUT FRONT FOG LAMPS)
3	R	-(WITH LED HEADLAMPS)
4	LG	-(WITH LED HEADLAMPS)
4	B/W	-(WITHOUT FRONT FOG LAMPS)
6	B/R	-
7	W	-
9	G	-
10	R	-
11	L	-
12	Y	-
13	W	-
14	R	-
15	G	-
16	G	-
17	R	-
18	O	-
19	W/L	-


AALIA1884GB

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[HALOGEN HEADLAMP]


Connector No.	B2
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3	4	5	6	7		
8	9	10	11	12	13	14	15	16

Terminal No.	Color of Wire	Signal Name
1	-	-
2	LG	-
3	P	-
4	GR	-
5	GR	-
6	W	-
7	-	-
8	-	-
9	-	-
10	SB	-
11	V	-
12	LG	-
13	SB	-
14	Y	-
15	L	-
16	G	-


Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3	4	5	6	7		
8	9	10	11	12	13	14	15	16

Terminal No.	Color of Wire	Signal Name
1	G	-
2	-	-
3	GR	-
4	L	-
5	G	-
6	R	-
7	BR	-
8	SB	-
9	GR	-
10	W	-
11	LG	-
12	P	-
13	V	-
14	Y	-
15	W	-
16	L	-

Connector No.	E107
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3	4	5	6	7	8	9	10	11	12
13	14	15	16	17	18	19	20	21	22	23	24

Terminal No.	Color of Wire	Signal Name
1	L	-
2	P	-
3	SB	-
4	-	-
5	-	-
6	GR	-
7	-	-
8	P	-
9	BR	-
10	W	-
11	R	-
12	B	-
13	G	-
14	B	-
15	LG	-
16	BR	-
17	G	-
18	B	-
19	Y	-
20	R	-
21	O	-
22	W	-
23	SHIELD	-
24	-	-

AALIA1885GB

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[HALOGEN HEADLAMP]


Terminal No.	Color of Wire	Signal Name
19	-	-
20	-	-
21	-	-
22	-	-
23	-	-
24	R	-
25	W	-
26	LG	-
27	Y	-
28	-	-
29	R	-
30	GR	-
31	L	-
32	P	-

Terminal No.	Color of Wire	Signal Name
5	-	-
6	-	-
7	B	-
8	SHIELD	-
9	B	-
10	SB	-
11	P	-
12	BR	-
13	GR	-
14	P	-
15	L	-
16	G	-
17	-	-
18	-	-

Terminal No.	Color of Wire	Signal Name
10	Y	-
11	L	-
12	G	-
13	G	-
14	B	-
15	LG	-
16	BR	-
17	G	-
18	B	-
19	Y	-
20	R	-
21	Y	-
22	W	-
23	SHIELD	-
24	-	-


Terminal No.	Color of Wire	Signal Name
1	L	-
2	P	-
3	Y	-
4	-	-
5	-	-
6	SB	-
7	-	-
8	P	-
9	V	-

Connector No.	B3
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	-	-
2	-	-
3	-	-
4	-	-

Connector No.	B7
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	P	-
3	Y	-
4	-	-
5	-	-
6	SB	-
7	-	-
8	P	-
9	V	-


AALIA1886GB

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[HALOGEN HEADLAMP]


Connector No.	B57
Connector Name	LICENSE PLATE LAMP LH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	W	-
2	B	-


Terminal No.	Color of Wire	Signal Name
6	BR	-
7	-	-
8	-	-
9	P	-
10	Y	-
11	B	-
12	W	-
13	R	-
14	L	-
15	LG	-
16	-	-
17	SHIELD	-
18	B	-
19	-	-
20	GR	-

Connector No.	B18
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	-	-
2	-	-
3	-	-
4	P	-
5	P	-

Connector No.	B80
Connector Name	REAR COMBINATION LAMP LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	G	-
2	P	-
3	-	-
4	SB	-
5	B	-
6	GR	-

Connector No.	B59
Connector Name	REAR COMBINATION LAMP RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	G	-
2	Y	-
3	-	-
4	W	-
5	B	-
6	V	-

Connector No.	B58
Connector Name	LICENSE PLATE LAMP RH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	L	-
2	B	-

AALIA1887GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


EXL

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >


[HALOGEN HEADLAMP]

Connector No.	D505
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	W	-
2	R	-
3	P	-
4	W	-
5	R	-
6	SHIELD	-
7	Y	-
8	P	-
9	L	-
10	SB	-
11	LG	-
12	GR	-

Connector No.	D504
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	-	-
2	-	-
3	-	-
4	P	-
5	W	-
6	R	-
7	-	-
8	-	-
9	P	-
10	SB	-
11	B	-
12	W	-
13	R	-
14	L	-
15	LG	-
16	-	-
17	SHIELD	-
18	Y	-
19	-	-
20	GR	-

Connector No.	B85
Connector Name	JOINT CONNECTOR-B02
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	B	-
2	-	-
3	B	-
4	B	-
5	-	-
6	-	-
7	L	-
8	W	-
9	V	-
10	V	-
11	SHIELD	-
12	SHIELD	-
13	B	-
14	B	-
15	G	-
16	G	-
17	G	-
18	LG	-
19	R	-
20	R	-

AALIA1888GB

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[HALOGEN HEADLAMP]

Connector No.	D553
Connector Name	CONDENSER
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
2	R	-

Connector No.	D551
Connector Name	CONDENSER
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	R	-


Connector No.	D561
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	BR	-
2	B	-
3	R	-
4	B	-

Terminal No.	Color of Wire	Signal Name
7	Y	-(WITHOUT AROUND VIEW MONITOR)
7	R	-(WITH AROUND VIEW MONITOR)
8	P	-
9	L	-
10	SB	-
11	LG	-
12	GR	-

Connector No.	D555
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	-(WITHOUT AROUND VIEW MONITOR)
1	B	-(WITH AROUND VIEW MONITOR)
2	R	-(WITHOUT AROUND VIEW MONITOR)
2	W	-(WITH AROUND VIEW MONITOR)
3	P	-
4	W	-
5	R	-
6	SHIELD	-

AALIA2047GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >


[HALOGEN HEADLAMP]

Connector No.	D603
Connector Name	HIGH-MOUNTED STOP LAMP
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	R	-
2	B	-

Connector No.	D602
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	BR	-
2	B	-
3	R	-
4	B	-

AALIA2048GB

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[HALOGEN HEADLAMP]


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000009346727

OVERALL SEQUENCE



DETAILED FLOW

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[HALOGEN HEADLAMP]

1. GET INFORMATION FOR SYMPTOM

1. Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurs).
2. Check operation condition of the function that is malfunctioning.

>> GO TO 2.

2. CHECK DTC

1. Check DTC.
2. Perform the following procedure if DTC is detected.
 - Record DTC and freeze frame data (Print them out using CONSULT.)
 - Erase DTC.
 - Study the relationship between the cause detected by DTC and the symptom described by the customer.
3. Check related service bulletins for information.

Are any symptoms described and any DTC detected?

Symptom is described, DTC is detected>>GO TO 3.

Symptom is described, DTC is not detected>>GO TO 4.

Symptom is not described, DTC is detected>>GO TO 5.

3. CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Also study the normal operation and fail-safe related to the symptom.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5.

4. CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6.

5. PERFORM DTC CONFIRMATION PROCEDURE

Perform DTC CONFIRMATION PROCEDURE for the detected DTC, and then check that DTC is detected again. At this time, always connect CONSULT to the vehicle, and check self diagnostic results in real time.

If two or more DTCs are detected, refer to [BCS-47. "DTC Inspection Priority Chart"](#) (BCM) or [PCS-18. "DTC Index"](#) (IPDM E/R), and determine trouble diagnosis order.

NOTE:

- Freeze frame data is useful if the DTC is not detected.
- Perform Component Function Check if DTC CONFIRMATION PROCEDURE is not included on Service Manual. This simplified check procedure is an effective alternative though DTC cannot be detected during this check.
If the result of Component Function Check is NG, it is the same as the detection of DTC by DTC CONFIRMATION PROCEDURE.

Is DTC detected?

YES >> GO TO 7.

NO >> Check according to [GI-53. "Intermittent Incident"](#).

6. DETECT MALFUNCTIONING SYSTEM BY SYMPTOM DIAGNOSIS

Detect malfunctioning system according to SYMPTOM DIAGNOSIS based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

Is the symptom described?

YES >> GO TO 7.

NO >> Monitor input data from related sensors or check voltage of related module terminals using CONSULT.

7. DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[HALOGEN HEADLAMP]

Inspect according to Diagnostic Procedure of the system.

Is malfunctioning part detected?

YES >> GO TO 8.

NO >> Check according to [GI-53. "Intermittent Incident"](#).

8. REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnostic Procedure again after repair and replacement.
3. Check DTC. If DTC is detected, erase it.

>> GO TO 9.

9. FINAL CHECK

When DTC is detected in step 2, perform DTC CONFIRMATION PROCEDURE again, and then check that the malfunction is repaired securely.

When symptom is described by the customer, refer to confirmed symptom in step 3 or 4, and check that the symptom is not detected.

Is DTC detected and does symptom remain?

YES-1 >> DTC is detected: GO TO 7.

YES-2 >> Symptom remains: GO TO 4.

NO >> Before returning the vehicle to the customer, always erase DTC.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

HEADLAMP (HI) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN HEADLAMP]

DTC/CIRCUIT DIAGNOSIS

HEADLAMP (HI) CIRCUIT

WITHOUT DAYTIME RUNNING LIGHT SYSTEM

WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Component Function Check

INFOID:000000009346728

1. CHECK HEADLAMP (HI) OPERATION

CONSULT ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the test items, check that the headlamp (HI) is turned ON.

Hi : Headlamp (HI) ON
Off : Headlamp (HI) OFF

NOTE:

ON/OFF is repeated 1 second each.

Is the inspection result normal?

YES >> Headlamp (HI) circuit is normal.

NO >> Refer to [EXL-182, "WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure"](#).

WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure

INFOID:000000009346729

1. CHECK HEADLAMP (HI) OUTPUT VOLTAGE

CONSULT ACTIVE TEST

1. Turn power switch OFF.
2. Disconnect front combination lamp connector.
3. Turn power switch ON.
4. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
5. With operating the test items, check voltage between IPDM E/R harness connector and ground.

(+)		Terminal	(-)	Test item	Voltage (Approx.)	
IPDM E/R						
Connector						
RH	E15	49	Ground	EXTERNAL LAMPS	Hi	Battery voltage
					Off	0 V
LH		50			Hi	Battery voltage
					Off	0 V

Is the inspection result normal?

YES >> GO TO 2.

NO >> GO TO 3.

2. CHECK HEADLAMP (HI) OPEN CIRCUIT

1. Turn power switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and front combination lamp harness connector.

IPDM E/R		Front combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E15	E45	2	Yes
LH		50		

Is the inspection result normal?

YES >> GO TO 5.

HEADLAMP (HI) CIRCUIT

[HALOGEN HEADLAMP]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair or replace harness.

3.CHECK HEADLAMP (HI) FUSE

1. Turn power switch OFF.
2. Check that the following fuses are not blown.

Unit	Location	Fuse No.	Capacity
Headlamp HI (RH)	IPDM E/R	#51	10 A
Headlamp HI (LH)		#52	

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-29, "Removal and Installation"](#).
NO >> GO TO 4.

4.CHECK HEADLAMP HIGH (HI) SHORT CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
RH	E15	49	No
LH		50	

Is the inspection result normal?

YES >> Replace fuse. (Replace IPDM E/R if the fuse is blown again.)
NO >> Repair or replace harness. And then replace the fuse.

5.CHECK HEADLAMP (HI) GROUND OPEN CIRCUIT

1. Turn power switch OFF.
2. Disconnect front combination lamp connector.
3. Check continuity between front combination lamp harness connector and ground.

Front combination lamp		Ground	Continuity
Connector	Terminal		
RH	E45	4	Yes
LH			

Is the inspection result normal?

YES >> Replace headlamp (HI) bulb.
NO >> Repair or replace harness.

WITH DAYTIME RUNNING LIGHT SYSTEM

WITH DAYTIME RUNNING LIGHT SYSTEM : Component Function Check INFOID:000000009346730

1.CHECK HEADLAMP (HI) OPERATION

ⓂCONSULT ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the test items, check that the headlamp (HI) is turned ON.

Hi : Headlamp (HI) ON
Off : Headlamp (HI) OFF

NOTE:

ON/OFF is repeated 1 second each.

Is the inspection result normal?

YES >> Headlamp (HI) circuit is normal.
NO >> Refer to [EXL-184, "WITH DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure"](#).

HEADLAMP (HI) CIRCUIT

[HALOGEN HEADLAMP]

< DTC/CIRCUIT DIAGNOSIS >

WITH DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure

INFOID:000000009346731

1. CHECK HEADLAMP (HI) OUTPUT VOLTAGE

CONSULT ACTIVE TEST

1. Turn power switch OFF.
2. Disconnect headlamp high connector.
3. Turn power switch ON.
4. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
5. With operating the test items, check voltage between IPDM E/R harness connector and ground.

(+)		Terminal	(-)	Test item	Voltage (Approx.)
IPDM E/R					
Connector					
RH	E15	49	Ground	Hi	Battery voltage
					Off
LH		50		Hi	Battery voltage
				Off	0 V

Is the inspection result normal?

- YES >> GO TO 2.
NO >> GO TO 3.

2. CHECK HEADLAMP (HI) OPEN CIRCUIT

1. Turn power switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and front combination lamp harness connector.

IPDM E/R		Front combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E15	E45	2	Yes
LH		50		

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Repair or replace harness.

3. CHECK HEADLAMP (HI) FUSE

1. Turn power switch OFF.
2. Check that the following fuses are not blown.

Unit	Location	Fuse No.	Capacity
Headlamp HI (RH)	IPDM E/R	#51	10 A
Headlamp HI (LH)		#52	

Is the inspection result normal?

- YES >> Replace IPDM E/R.
NO >> GO TO 4.

4. CHECK HEADLAMP (HI) SHORT CIRCUIT

1. Disconnect IPDM E/R connector. Refer to [PCS-29, "Removal and Installation"](#).
2. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Terminal	Ground	Continuity
Connector				
RH	E15	49		No
LH		50		

HEADLAMP (HI) CIRCUIT

[HALOGEN HEADLAMP]

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> Replace fuse. (Replace IPDM E/R if the fuse is blown again.)

NO >> Repair or replace harness. And then replace the fuse.

5.CHECK ILLUMINATION STATUS OF HEADLAMPS

Check illumination status of headlamps.

Which headlamp does not turn ON?

RH >> GO TO 6.

LH >> GO TO 8.

6.CHECK HEADLAMP HI (RH) GROUND OPEN CIRCUIT-1

1. Remove daytime running light relay.

2. Check continuity between daytime running light relay harness connector and front combination lamp RH harness connector.

Daytime running light relay		Front combination lamp RH		Continuity
Connector	Terminal	Connector	Terminal	
E76	3	E45	4	Yes

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace harness.

7.CHECK HEADLAMP HI (RH) GROUND OPEN CIRCUIT-2

Check continuity between daytime running light relay harness connector and ground.

Daytime running light relay		Ground	Continuity
Connector	Terminal		
E76	4		Yes

Is the inspection result normal?

YES >> Replace headlamp (HI) bulb. (Bulb socket is abnormal.)

NO >> Repair or replace harness.

8.CHECK HEADLAMP HI (LH) GROUND OPEN CIRCUIT

Check continuity between front combination lamp LH harness connector and ground.

Front combination lamp LH		Ground	Continuity
Connector	Terminal		
E26	4		Yes

Is the inspection result normal?

YES >> Replace headlamp (HI) bulb. (Bulb socket is abnormal.)

NO >> Repair or replace harness.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

HEADLAMP (LO) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN HEADLAMP]

HEADLAMP (LO) CIRCUIT

Component Function Check

INFOID:000000009346732

1.CHECK HEADLAMP (LO) OPERATION

CONSULT ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the test items, check that the headlamp (LO) is turned ON.

Lo : Headlamp (LO) ON
Off : Headlamp (LO) OFF

Is the inspection result normal?

- YES >> Headlamp (LO) circuit is normal.
NO >> Refer to [EXL-186, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009346733

1.CHECK HEADLAMP (LO) OUTPUT VOLTAGE

CONSULT ACTIVE TEST

1. Turn power switch OFF.
2. Disconnect front combination lamp connector.
3. Turn power switch ON.
4. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
5. With operating the test items, check voltage between IPDM E/R harness connector and ground.

(+)		Terminal	(-)	Test item	Voltage (Approx.)
IPDM E/R					
Connector					
RH	E15	52	Ground	Lo	Battery voltage
					Off
LH		51		Lo	Battery voltage
				Off	0 V

Is the inspection result normal?

- YES >> GO TO 2.
NO >> GO TO 3.

2.CHECK HEADLAMP (LO) OPEN CIRCUIT

1. Turn power switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and front combination lamp harness connector.

IPDM E/R		Front combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E15	E45	6	Yes
LH		51		

Is the inspection result normal?

- YES >> Replace headlamp bulb.
NO >> Repair or replace harness.

3.CHECK HEADLAMP (LO) FUSE

1. Turn power switch OFF.
2. Check that the following fuses are not blown.

HEADLAMP (LO) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN HEADLAMP]

Unit	Location	Fuse No.	Capacity
Headlamp LO (RH)	IPDM E/R	#54	15 A
Headlamp LO (LH)		#53	

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-29, "Removal and Installation"](#).

NO >> GO TO 4.

4. CHECK HEADLAMP (LO) SHORT CIRCUIT-1

1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
RH	E15	52	No
LH		51	

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness. And then replace the fuse.

5. CHECK HEADLAMP (LO) SHORT CIRCUIT-2

ⓐ CONSULT ACTIVE TEST

1. Replace fuse.
2. Connect IPDM E/R connector.
3. Turn power switch ON.
4. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
5. Check that fuse is not blown when Lo button is operated.

Is the inspection result normal?

YES >> GO TO 6.

NO >> Replace IPDM E/R. Refer to [PCS-29, "Removal and Installation"](#).

6. CHECK HEADLAMP (LO) SHORT CIRCUIT-3

1. Turn power switch OFF.
2. Connect front combination lamp connector.
3. Check that headlamp turns ON when lighting switch is in the 2ND position.

Is the inspection result normal?

YES >> Refer to [GI-53, "Intermittent Incident"](#).

NO >> Replace headlamp bulb.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

DAYTIME RUNNING LIGHT RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN HEADLAMP]

DAYTIME RUNNING LIGHT RELAY CIRCUIT

Component Function Check

INFOID:000000009346807

1. CHECK DAYTIME RUNNING LIGHT OPERATION

CONSULT ACTIVE TEST

1. Select "External Lamps" of BCM (HEADLAMP) active test item.
2. With operating the test items, check that daytime running light operation.

On : Headlamp (HI) ON

Off : Headlamp (HI) OFF

Is the inspection result normal?

- YES >> Daytime running light relay circuit is normal.
NO >> Refer to [EXL-188, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009346808

1. CHECK DAYTIME RUNNING LIGHT RELAY 2 FUSE

1. Turn ignition switch OFF.
2. Check that the following fuse is not blown.

Unit	Fuse No.	Capacity
Daytime running light relay 2	#37	10 A

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Replace the fuse after repairing the applicable circuit.

2. CHECK DAYTIME RUNNING LIGHT RELAY 2 POWER SUPPLY

1. Remove daytime running light relay.
2. Check voltage between daytime running light relay 2 harness connector and ground.

(+)		(-)	Voltage (Approx.)
Daytime running light relay 2			
Connector	Terminal	Ground	Battery voltage
E76	2		
	5		

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace harness.

3. CHECK DAYTIME RUNNING LIGHT RELAY 2

Check daytime running light relay 2. Refer to [EXL-189, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Replace daytime running light relay 2.

4. CHECK DAYTIME RUNNING LIGHT RELAY 2 CONTROL SIGNAL OUTPUT

CONSULT ACTIVE TEST

1. Install daytime running light relay 2.
2. Turn ignition switch ON.
3. Select "External Lamps" of BCM (HEADLAMP) active test item.
4. With operating the test item, check voltage between IPDM E/R harness connector and ground.

DAYTIME RUNNING LIGHT RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN HEADLAMP]

(+)		(-)	Test item	Voltage (Approx.)	
IPDM E/R					
Connector	Terminal				
E13	28	Ground	External Lamps	On	0 V
				Off	Battery voltage

Is the inspection result normal?

YES >> Daytime running light relay 2 circuit is OK.

NO-1 (Fixed at 0 V)>>GO TO 5.

NO-2 (Fixed at battery voltage) >>Replace IPDM E/R. Refer to [PCS-29, "Removal and Installation"](#).

5.CHECK DAYTIME RUNNING LIGHT RELAY 2 CONTROL SIGNAL OPEN CIRCUIT

- Turn ignition switch OFF.
- Remove daytime running light relay 2.
- Disconnect IPDM E/R harness connector.
- Check continuity between IPDM E/R harness connector and daytime running light relay 2 harness connector.

IPDM E/R		Daytime running light relay 2		Continuity
Connector	Terminal	Connector	Terminal	
E13	28	E65	2	Yes

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace harness.

6.CHECK DAYTIME RUNNING LIGHT RELAY 2 CONTROL SIGNAL SHORT CIRCUIT

Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E13	28		No

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-29, "Removal and Installation"](#).

NO >> Repair or replace harness.

Component Inspection

INFOID:000000009346809

EXL

1.CHECK DAYTIME RUNNING LIGHT RELAY 2

- Turn the ignition switch OFF.
- Remove daytime running light relay 2.
- Apply battery voltage to daytime running light relay- between terminals 1 and 2.
- Check continuity between daytime running light relay 2 terminals.

Daytime running light relay-2		Condition	Continuity
Terminal			
5	Voltage	Apply	Yes
		Not Apply	No
3	Voltage	Apply	No
		Not Apply	Yes

Is the inspection result normal?

YES >> Daytime running light relay 2 is normal.

NO >> Replace daytime running light relay 2.

PARKING LAMP CIRCUIT

[HALOGEN HEADLAMP]

< DTC/CIRCUIT DIAGNOSIS >

PARKING LAMP CIRCUIT

Component Function Check

INFOID:000000009346737

1.CHECK PARKING LAMP OPERATION

ⓅCONSULT ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the test items, check that the parking lamp is turned ON.

TAIL : Parking lamp ON
Off : Parking lamp OFF

Is the inspection result normal?

- YES >> Parking lamp circuit is normal.
NO >> Refer to [EXL-190, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009346738

1.CHECK PARKING LAMP FUSE

1. Turn power switch OFF.
2. Check that the following fuse is not blown.

Unit	Location	Fuse No.	Capacity
<ul style="list-style-type: none">• Parking lamp• Front side marker lamp• Tail lamp (RH)• License plate lamp	IPDM E/R	#47	10 A

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2.CHECK PARKING LAMP SHORT CIRCUIT

1. Disconnect the following connectors.
 - IPDM E/R
 - Front combination lamp
 - Front side marker lamp
 - Rear combination lamp (RH)
 - License plate lamp
2. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E14	43		No
	44		

Is the inspection result normal?

- YES >> Replace fuse. (Replace IPDM E/R if blown fuse is found again.)
NO >> Repair or replace harness. And then replace the fuse.

3.CHECK PARKING LAMP BULB

Check applicable lamp bulb.

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Replace bulb.

4.CHECK PARKING LAMP OUTPUT VOLTAGE

ⓅCONSULT ACTIVE TEST

PARKING LAMP CIRCUIT

[HALOGEN HEADLAMP]

< DTC/CIRCUIT DIAGNOSIS >

1. Disconnect front combination lamp connector.
2. Turn power switch ON.
3. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
4. With operating the test items, check voltage between IPDM E/R harness connector and ground.

(+)		(-)	Test item		Voltage (Approx.)
IPDM E/R					
Connector	Terminal				
E14	43	Ground	EXTERNAL LAMPS	TAIL	Battery voltage
				Off	0 V

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace IPDM E/R. Refer to [PCS-29. "Removal and Installation"](#).

5. CHECK PARKING LAMP OPEN CIRCUIT

1. Turn power switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and front combination lamp harness connector.

IPDM E/R		Front combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E14	43	E45	Yes
LH			E26	

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace harness.

6. CHECK PARKING LAMP GROUND OPEN CIRCUIT

Check continuity between front combination lamp harness connector and ground.

Front combination lamp		Ground	Continuity
Connector	Terminal		
RH	E45	3	Yes
LH	E26		

Is the inspection result normal?

YES >> Check corresponding bulb socket and harness. Repair or replace if necessary.

NO >> Repair or replace harness.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

FRONT SIDE MARKER LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN HEADLAMP]

FRONT SIDE MARKER LAMP CIRCUIT

Component Function Check

INFOID:000000009346739

1. CHECK PARKING LAMP OPERATION

Check that the parking lamp is turned ON.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check parking lamp circuit. Refer to [EXL-190, "Component Function Check"](#).

2. CHECK FRONT SIDE MARKER LAMP OPERATION

ⓐ CONSULT ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.

2. With operating the test items, check that the front side marker lamp is turned ON.

TAIL : Front side marker lamp ON

Off : Front side marker lamp OFF

Is the inspection result normal?

YES >> Front side marker lamp circuit is normal.

NO >> Refer to [EXL-192, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009346740

1. CHECK FRONT SIDE MARKER LAMP BULB

Check applicable lamp bulb.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace bulb.

2. CHECK FRONT SIDE MARKER LAMP OPEN CIRCUIT

1. Turn power switch OFF.

2. Disconnect IPDM E/R connector and front side marker lamp connector.

3. Check continuity between IPDM E/R harness connector and front side marker lamp harness connector.

IPDM E/R		Front side marker lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E14	E16	1	Yes
LH		E10		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK FRONT SIDE MARKER LAMP GROUND OPEN CIRCUIT

Check continuity between front side marker lamp harness connector and ground.

Front side marker lamp		Ground	Continuity
Connector	Terminal		
RH	E16	2	Yes
LH	E10		

Is the inspection result normal?

YES >> Check corresponding bulb socket and harness. Repair or replace if necessary.

NO >> Repair or replace harness.

TAIL LAMP CIRCUIT

Component Function Check

INFOID:000000009346741

1.CHECK TAIL LAMP OPERATION

CONSULT ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the test items, check that the tail lamp is turned ON.

TAIL : Tail Lamp ON
Off : Tail lamp OFF

Is the inspection result normal?

- YES >> Tail lamp circuit is normal.
 NO >> Refer to [EXL-193, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009346742

1.CHECK PARKING LAMP OPERATION

Check that the parking lamp is turned ON.

Is the inspection result normal?

- YES-1 [When tail lamp (RH) does not turn ON.]>>GO TO 5.
 YES-2 [When tail lamp (LH) does not turn ON.]>>GO TO 2.
 NO >> Check parking lamp circuit. Refer to [EXL-190, "Component Function Check"](#).

2.CHECK TAIL LAMP (LH) FUSE

1. Turn power switch OFF.
2. Check that the following fuse is not blown.

Unit	Location	Fuse No.	Capacity
Tail lamp (LH)	IPDM E/R	#46	10 A

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 4.

3.CHECK TAIL LAMP (LH) OUTPUT VOLTAGE

CONSULT ACTIVE TEST

1. Disconnect rear combination lamp (LH) connector.
2. Turn power switch ON.
3. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
4. With operating the test items, check voltage between IPDM E/R harness connector and ground.

(+)		(-)	Test item	Voltage (Approx.)
IPDM E/R				
Connector	Terminal			
E14	38	Ground	EXTERNAL LAMPS	Battery voltage
			TAIL Off	0 V

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> Replace IPDM E/R. Refer to [PCS-29, "Removal and Installation"](#).

4.CHECK TAIL LAMP (LH) SHORT CIRCUIT

1. Disconnect IPDM E/R connector and rear combination lamp (LH) connector.
2. Check continuity between IPDM E/R harness connector and ground.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

TAIL LAMP CIRCUIT

[HALOGEN HEADLAMP]

< DTC/CIRCUIT DIAGNOSIS >

IPDM E/R		Ground	Continuity
Connector	Terminal		
E14	38		

Is the inspection result normal?

- YES >> Replace fuse. (Replace IPDM E/R if blown fuse is found again.)
 NO >> Repair or replace harness. And then replace the fuse.

5. CHECK TAIL LAMP OPEN CIRCUIT

1. Turn power switch OFF.
2. Disconnect IPDM E/R connector and rear combination lamp connector.
3. Check continuity between IPDM E/R harness connector and rear combination lamp harness connector.

IPDM E/R		Rear combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E14	38	B59	Yes
LH		44	B80	

Is the inspection result normal?

- YES >> GO TO 6.
 NO >> Repair or replace harness.

6. CHECK TAIL LAMP GROUND OPEN CIRCUIT

Check continuity between rear combination lamp harness connector and ground.

Rear combination lamp		Ground	Continuity
Connector	Terminal		
RH	B59		5
LH	B80		

Is the inspection result normal?

- YES >> Replace rear combination lamp.
 NO >> Repair or replace harness.

LICENSE PLATE LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN HEADLAMP]

LICENSE PLATE LAMP CIRCUIT

Component Function Check

INFOID:000000009346743

1. CHECK TAIL LAMP (RH) OPERATION

Check that the tail lamp (RH) is turned ON.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check tail lamp circuit. Refer to [EXL-193, "Component Function Check"](#).

2. CHECK LICENSE PLATE LAMP OPERATION

Ⓜ CONSULT ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.

2. With operating the lighting switch, check that the license plate lamp is turned ON.

TAIL : License plate lamp ON

Off : License plate lamp OFF

Is the inspection result normal?

YES >> License plate lamp circuit is normal.

NO >> Refer to [EXL-195, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009346744

1. CHECK LICENSE PLATE LAMP BULB

Check the applicable lamp bulb.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace bulb.

2. CHECK LICENSE PLATE LAMP OPEN CIRCUIT

1. Turn power switch OFF.

2. Disconnect IPDM E/R connector and license plate lamp connector.

3. Check continuity between IPDM E/R harness connector and license plate lamp harness connector.

IPDM E/R		License plate lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E14	B58	1	Yes
LH		B57		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK LICENSE PLATE LAMP GROUND OPEN CIRCUIT

Check continuity between license plate lamp harness connector and ground.

License plate lamp		Ground	Continuity
Connector	Terminal		
RH	B58	2	Yes
LH	B57		

Is the inspection result normal?

YES >> Check corresponding bulb socket and harness. Repair or replace if necessary.

NO >> Repair or replace harness.

FRONT FOG LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN HEADLAMP]

FRONT FOG LAMP CIRCUIT

Component Function Check

INFOID:000000009346745

1.CHECK FRONT FOG LAMP OPERATION

ⓅCONSULT ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the test items, check that the front fog lamp is turned ON.

Fog : Front fog lamp ON
Off : Front fog lamp OFF

Is the measurement normal?

- YES >> Front fog lamp circuit is normal.
NO >> Refer to [EXL-196, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009346746

1.CHECK FRONT FOG LAMP FUSE

1. Turn power switch OFF.
2. Check that the following fuse is not blown.

Unit	Location	Fuse No.	Capacity
Front fog lamp	IPDM E/R	#50	15 A

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2.CHECK FRONT FOG LAMP SHORT CIRCUIT

1. Disconnect front fog connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
RH	E12	19	No
LH		20	

Is the inspection result normal?

- YES >> Replace fuse. (Replace IPDM E/R if the fuse is blown again.)
NO >> Repair or replace harness. And then replace the fuse.

3.CHECK FRONT FOG LAMP BULB

Check the applicable lamp bulb.

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Replace bulb.

4.CHECK FRONT FOG LAMP OUTPUT VOLTAGE

ⓅCONSULT ACTIVE TEST

1. Disconnect front fog lamp connector.
2. Turn power switch ON.
3. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
4. With operating the test items, check the voltage between IPDM E/R harness connector and ground.

FRONT FOG LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN HEADLAMP]

(+)		Terminal	(-)	Test item	Voltage (Approx.)	
IPDM E/R						
Connector	Terminal					
RH	E12	19	Ground	EXTERNAL LAMPS	Fog	Battery voltage
LH		20			Off	0 V
					Fog	Battery voltage
					Off	0 V

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace IPDM E/R. Refer to [PCS-29, "Removal and Installation"](#).

5. CHECK FRONT FOG LAMP OPEN CIRCUIT

1. Turn power switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and front fog lamp harness connector.

IPDM E/R		Front fog lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E12	19	E48	Yes
LH		20	E30	

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace harness.

6. CHECK FRONT FOG LAMP GROUND CIRCUIT OPEN CIRCUIT

Check continuity between front fog lamp harness connector and ground.

Front fog lamp		Ground	Continuity
Connector	Terminal		
RH	E48	2	Yes
LH	E30		

Is the inspection result normal?

YES >> Refer to [GI-53, "Intermittent Incident"](#).

NO >> Repair or replace harness.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

TURN SIGNAL LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN HEADLAMP]

TURN SIGNAL LAMP CIRCUIT

Component Function Check

INFOID:000000009346747

1. CHECK TURN SIGNAL LAMP

CONSULT ACTIVE TEST

1. Select "FLASHER" of BCM (FLASHER) active test item.
2. With operating the test items, check that the turn signal lamps is turned ON.

LH : Turn signal lamps (LH) ON
RH : Turn signal lamps (RH) ON
Off : Turn signal lamps OFF

Is the inspection result normal?

- YES >> Turn signal lamp circuit is normal.
 NO >> Refer to [EXL-198, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009346748

1. CHECK TURN SIGNAL LAMP BULB



Check the applicable lamp bulb.

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Replace bulb.

2. CHECK TURN SIGNAL LAMP OUTPUT VOLTAGE

1. Turn power switch OFF.
2. Disconnect front combination lamp connector and rear combination lamp connector.
3. Turn power switch ON.
4. With operating the turn signal switch, check voltage between BCM harness connector and ground.

(+)		(-)	Condition	Voltage (Approx.)		
BCM						
Connector	Terminal					
LH	M25	60	Ground	Turn signal switch	LH	 PKID0926E
					OFF	0 V
RH	M25	61	Ground	Turn signal switch	RH	 PKID0926E
					OFF	0 V

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 4.

TURN SIGNAL LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN HEADLAMP]

3. CHECK TURN SIGNAL LAMP OPEN CIRCUIT

1. Turn power switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and front combination lamp, side turn signal lamp or rear combination lamp harness connector.

Front turn signal lamp

BCM		Front combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	M25	61	E45	Yes
LH		60	E26	

Rear turn signal lamp

BCM		Rear combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	M25	61	B59	Yes
LH		60	B80	

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> Repair or replace harness.

4. CHECK TURN SIGNAL LAMP SHORT CIRCUIT

Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
RH	M25	61	No
LH		60	

Is the inspection result normal?

- YES >> Check each bulb socket for internal short circuit, and if check result is normal, replace BCM. Refer to [BCS-86, "Removal and Installation"](#).
 NO >> Repair or replace harness.

5. CHECK TURN SIGNAL LAMP GROUND OPEN CIRCUIT

Check continuity between BCM harness connector and front combination lamp or rear combination lamp and ground.

Front turn signal lamp

Front combination lamp		Ground	Continuity
Connector	Terminal		
RH	E45	3	Yes
LH	E26		

Rear turn signal lamp

Rear combination lamp		Ground	Continuity
Connector	Terminal		
RH	B59	5	Yes
LH	B80		

Is the inspection result normal?

- YES >> Check corresponding bulb socket and harness. Repair or replace if necessary.
 NO >> Repair or replace harness.

OPTICAL SENSOR

Component Function Check

INFOID:000000009346749

1. CHECK OPTICAL SENSOR SIGNAL BY CONSULT

CONSULT DATA MONITOR

1. Turn power switch ON.
2. Select "OPTISEN (DTCT)" of BCM (HEADLAMP) data monitor item.
3. Turn lighting switch AUTO.
4. With the optical sensor illuminating, check the monitor status.

Monitor item	Condition	Voltage (Approx.)
OPTISEN (DTCT)	Optical sensor	
	When illuminating	3.1 V or more *
	When shutting off light	0.6 V or less

*: Illuminates the optical sensor. The value may be less than the standard value if brightness is weak.

Is the inspection result normal?

- YES >> Optical sensor is normal.
 NO >> Refer to [EXL-200, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009346750

1. CHECK OPTICAL SENSOR POWER SUPPLY INPUT

1. Turn power switch ON.
2. Turn lighting switch AUTO.
3. Check voltage between optical sensor harness connector and ground.

(+)				Voltage (Approx.)
Optical sensor				
Connector	Terminal			
M16	1	Ground		5 V

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> GO TO 4.

2. CHECK OPTICAL SENSOR GROUND INPUT

Check voltage between optical sensor harness connector and ground.

(+)				Voltage (Approx.)
Optical sensor				
Connector	Terminal			
M16	3	Ground		0 V

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 6.

3. CHECK OPTICAL SENSOR SIGNAL OUTPUT

With illuminating the optical sensor, check voltage between optical sensor harness connector and ground.

OPTICAL SENSOR

[HALOGEN HEADLAMP]

< DTC/CIRCUIT DIAGNOSIS >

(+)		(-)	Condition	Voltage (Approx.)
Optical sensor				
Connector	Terminal			
M16	2	Ground	Optical sensor	When illuminating 3.1 V or more *
				When shutting off light 0.6 V or less

*: Illuminate the optical sensor. The value may be less than the standard if brightness is weak.

Is the inspection result normal?

YES >> GO TO 7.

NO >> Replace the optical sensor.

4. CHECK OPTICAL SENSOR OPEN CIRCUIT

1. Turn power switch OFF.
2. Disconnect optical sensor connector and BCM connector.
3. Check continuity between optical sensor harness connector and BCM harness connector.

Optical sensor		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M16	1	M24	17	Yes

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness.

5. CHECK OPTICAL SENSOR SHORT CIRCUIT

Check continuity between optical sensor harness connector and ground.

Optical sensor		Ground	Continuity
Connector	Terminal		
M16	1		No

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-86, "Removal and Installation"](#).

NO >> Repair or replace harness.

6. CHECK OPTICAL SENSOR GROUND OPEN CIRCUIT

1. Turn power switch OFF.
2. Disconnect optical sensor connector and BCM connector.
3. Check continuity between optical sensor harness connector and BCM harness connector.

Optical sensor		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M16	3	M24	18	Yes

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-86, "Removal and Installation"](#).

NO >> Repair or replace harness.

7. CHECK OPTICAL SENSOR SIGNAL OPEN CIRCUIT

1. Turn power switch OFF.
2. Disconnect optical sensor connector and BCM connector.
3. Check continuity between optical sensor harness connector and BCM harness connector.

OPTICAL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN HEADLAMP]

Optical sensor		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M16	2	M24	14	Yes

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair or replace harness.

8. CHECK OPTICAL SENSOR SHORT CIRCUIT

Check continuity between optical sensor harness connector and ground.

Optical sensor		Ground	Continuity
Connector	Terminal		
M16	2		No

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-86. "Removal and Installation"](#).

NO >> Repair or replace harness.

HAZARD SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN HEADLAMP]

HAZARD SWITCH

Component Function Check

INFOID:000000009346751

1.CHECK HAZARD SWITCH SIGNAL BY CONSULT

CONSULT DATA MONITOR

1. Turn power switch ON.
2. Select "HAZARD SW" of BCM (FLASHER) data monitor item.
3. With operating the hazard switch, check the monitor status.

Monitor item	Condition		Monitor status
HAZARD SW	Hazard switch	ON	On
		OFF	Off

Is the inspection result normal?

- YES >> Hazard switch circuit is normal.
 NO >> Refer to [EXL-203. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009346752

1.CHECK HAZARD SWITCH SIGNAL INPUT

1. Turn power switch OFF.
2. Disconnect hazard switch connector.
3. Check voltage between hazard switch connector and ground.

(+)		(-)	Voltage (Approx.)
Hazard switch			
Connector	Terminal	Ground	Battery voltage
M45	2		

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> GO TO 2.

2.CHECK HAZARD SWITCH SIGNAL OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between hazard switch harness connector and BCM harness connector.

Hazard switch		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M45	2	M24	29	Yes

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair or replace harness.

3.CHECK HAZARD SWITCH SIGNAL SHORT CIRCUIT

Check continuity between hazard switch harness connector and ground.

Hazard switch		Ground	Continuity
Connector	Terminal		
M45	2		No

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-86. "Removal and Installation"](#).
 NO >> Repair or replace harness.

HAZARD SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN HEADLAMP]

4. CHECK HAZARD SWITCH GROUND OPEN CIRCUIT

Check continuity between hazard switch harness connector and ground.

Hazard switch		Ground	Continuity
Connector	Terminal		
M45	1		Yes

Is the inspection result normal?

- YES >> Replace hazard switch.
- NO >> Repair or replace harness.

EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[HALOGEN HEADLAMP]

SYMPTOM DIAGNOSIS

EXTERIOR LIGHTING SYSTEM SYMPTOMS WITHOUT DAYTIME RUNNING LIGHT SYSTEM

WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Symptom Table

INFOID:000000009346753

CAUTION:

Perform the self-diagnosis with CONSULT before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom		Possible cause	Inspection item
Headlamp (HI) is not turned ON.	One side	<ul style="list-style-type: none"> • Fuse • Halogen bulb (HI) • Harness between IPDM E/R and front combination lamp • Harness between front combination lamp and ground • IPDM E/R 	Headlamp (HI) circuit Refer to EXL-182, "WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Component Function Check" .
	Both sides	Symptom diagnosis "BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON" Refer to EXL-211, "WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure" .	
High beam indicator lamp is not turned ON. [Headlamp (HI) is turned ON.]		Combination meter	<ul style="list-style-type: none"> • Combination meter • Data monitor "HI-BEAM IND" • BCM (HEAD LAMP) • Active test "HEADLAMP"
Headlamp (LO) is not turned ON. [Headlamp warning lamp is not turned ON.]	One side	<ul style="list-style-type: none"> • Fuse • Harness between IPDM E/R and front combination lamp • IPDM E/R 	Headlamp (LO) circuit Refer to EXL-186, "Component Function Check" .
	Both sides	Symptom diagnosis "BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON" Refer to EXL-213, "Diagnosis Procedure" .	
Each lamp is not turned ON/OFF using lighting switch AUTO.		<ul style="list-style-type: none"> • Combination switch • Harness between combination switch and BCM • BCM 	Combination switch Refer to BCS-85, "Symptom Table" .
		<ul style="list-style-type: none"> • Optical sensor • Harness between optical sensor and BCM • BCM 	Optical sensor Refer to EXL-200, "Component Function Check" .
Parking lamp is not turned ON.		<ul style="list-style-type: none"> • Fuse • Parking lamp bulb • Parking lamp bulb socket • Harness between IPDM E/R and front combination lamp • Harness between front combination lamp and ground • IPDM E/R 	Parking lamp circuit Refer to EXL-190, "Component Function Check" .
Front side marker lamp is not turned ON.		<ul style="list-style-type: none"> • Fuse • Front side marker lamp bulb • Front side marker lamp bulb socket • Harness between IPDM E/R and front side marker lamp • Harness between front side marker lamp and ground 	Front side marker lamp circuit Refer to EXL-192, "Component Function Check" .

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[HALOGEN HEADLAMP]

Symptom	Possible cause	Inspection item	
Tail lamp and rear side marker lamp are not turned ON.	<ul style="list-style-type: none"> • Fuse • Harness between IPDM E/R and rear combination lamp • Harness between rear combination lamp and ground • Rear combination lamp 	Tail lamp circuit Refer to EXL-193, "Component Function Check" .	
License plate lamp is not turned ON.	<ul style="list-style-type: none"> • License plate lamp bulb • License plate lamp bulb socket • Harness between IPDM E/R and license plate lamp • Harness between license plate lamp and ground 	License plate lamp circuit Refer to EXL-195, "Component Function Check" .	
Parking lamp, side marker lamp, tail lamp and license plate lamp are not turned OFF.	Symptom diagnosis "PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS ARE NOT TURNED ON" Refer to EXL-214, "Diagnosis Procedure" .		
Tail lamp indicator lamp is not turned ON. (Parking lamp, side marker lamp, tail lamp and license plate lamp are turned ON.)	Combination meter	<ul style="list-style-type: none"> • Combination meter Data monitor "LIGHT IND" • BCM (HEAD LAMP) Active test "TAIL LAMP" 	
Turn signal lamp does not blink.	Indicator lamp is normal. (Applicable side performs high flasher activation.)	<ul style="list-style-type: none"> • Turn signal lamp bulb • Turn signal lamp bulb socket • Harness between BCM and each turn signal lamp 	Turn signal lamp circuit Refer to EXL-198, "Component Function Check" .
	Indicator lamp is included.	<ul style="list-style-type: none"> • Combination switch • Harness between combination switch and BCM • BCM 	Combination switch Refer to BCS-85, "Symptom Table" .
Turn signal indicator lamp does not blink. (Turn signal lamp is normal.)	One side	Combination meter	—
	Both sides (Always)	<ul style="list-style-type: none"> • Turn signal indicator lamp signal • BCM • Combination meter 	<ul style="list-style-type: none"> • Combination meter Data monitor "TURN IND" • BCM (FLASHER) Active test "FLASHER"
	Both sides (Only when activating hazard warning lamp with power switch OFF)	<ul style="list-style-type: none"> • Combination meter power supply and ground circuit • Combination meter 	Combination meter Power supply and ground circuit Refer to MWI-92, "COMBINATION METER : Diagnosis Procedure" .
<ul style="list-style-type: none"> • Hazard warning lamp does not activate. • Hazard warning lamp continues activating. (Turn signal is normal.) 	<ul style="list-style-type: none"> • Hazard switch • Harness between hazard switch and BCM • BCM 	Hazard switch Refer to EXL-203, "Component Function Check" .	
Front fog lamp is not turned ON.	One side	<ul style="list-style-type: none"> • Front fog lamp bulb • Harness between IPDM E/R and front fog lamp • IPDM E/R 	Front fog lamp circuit Refer to EXL-196, "Component Function Check" .
	Both sides	Symptom diagnosis "BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON" Refer to EXL-215, "Diagnosis Procedure" .	
Front fog lamp indicator is not turned ON. (Front fog lamp is turned ON.)	Combination meter	<ul style="list-style-type: none"> • Combination meter Data monitor "FR FOG IND" • BCM (HEAD LAMP) Active test "FR FOG LAMP" 	

WITH DAYTIME RUNNING LIGHT SYSTEM

WITH DAYTIME RUNNING LIGHT SYSTEM : Symptom Table

INFOID:000000009346754

CAUTION:

EXTERIOR LIGHTING SYSTEM SYMPTOMS

[HALOGEN HEADLAMP]

< SYMPTOM DIAGNOSIS >

Perform the self-diagnosis with CONSULT before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom	Possible cause	Inspection item
Headlamp (HI) is not turned ON.	<ul style="list-style-type: none"> • Fuse • Halogen bulb (HI) • Harness between IPDM E/R and headlamp (HI) • Harness between headlamp (HI) and ground • IPDM E/R 	Headlamp (HI) circuit Refer to EXL-182 . " WITHOUT DAY-TIME RUNNING LIGHT SYSTEM : Component Function Check ".
	<ul style="list-style-type: none"> • Harness between IPDM E/R and daytime running light relay • Daytime running light relay • IPDM E/R 	Daytime running light relay circuit Refer to EXL-183 . " WITH DAYTIME RUNNING LIGHT SYSTEM : Component Function Check ".
	<p>Symptom diagnosis "BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON" Refer to EXL-211, "WITH DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure".</p>	
High beam indicator lamp is not turned ON. [Headlamp (HI) is turned ON.]	Combination meter	<ul style="list-style-type: none"> • Combination meter • Data monitor "HI-BEAM IND" • BCM (HEAD LAMP) • Active test "HEADLAMP"
Headlamp (LO) is not turned ON.	<ul style="list-style-type: none"> • Fuse • Xenon bulb (LO) • Harness between IPDM E/R and headlamp lamp (LO) • Harness between headlamp (LO) and ground • IPDM E/R 	Headlamp (LO) circuit Refer to EXL-186 . " Component Function Check ".
	<p>Symptom diagnosis "BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON" Refer to EXL-213. "Diagnosis Procedure".</p>	
Each lamp is not turned ON/OFF with lighting switch AUTO.	<ul style="list-style-type: none"> • Combination switch • Harness between combination switch and BCM • BCM 	Combination switch Refer to BCS-85 . " Symptom Table ".
	<ul style="list-style-type: none"> • Optical sensor • Harness between optical sensor and BCM • BCM 	Optical sensor Refer to EXL-200 . " Component Function Check ".
Daytime running light is not turned ON. [Headlamp (HI) is turned ON.]	<ul style="list-style-type: none"> • Fuse • Harness between IPDM E/R and daytime running light relay • Daytime running light relay • IPDM E/R • BCM • ECM • Combination meter 	<ul style="list-style-type: none"> • Daytime running light relay circuit Refer to EXL-183. "WITH DAY-TIME RUNNING LIGHT SYSTEM : Component Function Check". • BCM (HEADLAMP) • Data monitor "ENGINE STATE" • Combination meter • Data monitor "PKB SW" • BCM (HEADLAMP) • Active test "DAYTIME RUNNING LIGHT"
Parking lamp is not turned ON.	<ul style="list-style-type: none"> • Fuse • Parking lamp bulb • Harness between IPDM E/R and front combination lamp • IPDM E/R 	Parking lamp circuit Refer to EXL-190 . " Component Function Check ".

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[HALOGEN HEADLAMP]

Symptom	Possible cause	Inspection item	
Front side marker lamp is not turned ON.	<ul style="list-style-type: none"> • Front side marker lamp bulb • Harness between IPDM E/R and front side marker lamp • Harness between front side marker lamp and ground • IPDM E/R 	Front side marker lamp circuit Refer to EXL-192, "Component Function Check" .	
Tail lamp (Rear side marker lamp) is not turned ON.	<ul style="list-style-type: none"> • Fuse • Tail lamp bulb • Harness between IPDM E/R and rear combination lamp • Harness between and rear combination lamp and ground 	Tail lamp circuit Refer to EXL-193, "Component Function Check" .	
License plate lamp is not turned ON.	<ul style="list-style-type: none"> • License plate lamp bulb • Harness between IPDM E/R and license plate lamp • Harness between license plate lamp and ground 	License plate lamp circuit Refer to EXL-195, "Component Function Check" .	
Parking lamp, side marker lamp, tail lamp and license plate lamp are not turned ON.	<p>Symptom diagnosis "PARKING, SIDE MARKER, LICENSE PLATE AND TAIL LAMPS ARE NOT TURNED ON" Refer to EXL-214, "Diagnosis Procedure".</p>		
Tail lamp indicator is not turned ON. (Exterior lamps are turned ON.)	Combination meter	<ul style="list-style-type: none"> • Combination meter Data monitor "LIGHT IND" • BCM (HEADLAMP) Active test "TAIL LAMP" 	
Turn signal lamp does not blink.	Indicator lamp is normal. (Applicable side performs high flasher activation.)	<ul style="list-style-type: none"> • Turn signal lamp bulb • Door mirror • Harness between BCM and each turn signal lamp • Harness between each turn signal lamp and ground 	Turn signal lamp circuit Refer to EXL-198, "Component Function Check" .
	Indicator lamp is included.	<ul style="list-style-type: none"> • Combination switch • Harness between combination switch and BCM • BCM 	Combination switch Refer to BCS-85, "Symptom Table" .
Turn signal indicator lamp does not blink. (Turn signal lamp is normal.)	One side	Combination meter	—
	Both sides (Always)	<ul style="list-style-type: none"> • Turn signal indicator lamp signal • BCM • Combination meter 	<ul style="list-style-type: none"> • Combination meter Data monitor "TURN IND" • BCM (FLASHER) Active test "FLASHER"
	Both sides (Only when activating hazard warning lamp with ignition switch OFF)	<ul style="list-style-type: none"> • Combination meter power supply and ground circuit • Combination meter 	Combination meter Power supply and ground circuit Refer to MWI-92, "COMBINATION METER : Diagnosis Procedure" .
<ul style="list-style-type: none"> • Hazard warning lamp does not activate. • Hazard warning lamp continues activating. (Turn signal is normal.) 	<ul style="list-style-type: none"> • Hazard switch • Harness between hazard switch and BCM • Harness between hazard switch and ground • BCM 	Hazard switch circuit Refer to EXL-203, "Component Function Check" .	

EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[HALOGEN HEADLAMP]

Symptom		Possible cause	Inspection item
Front fog lamp is not turned ON.	One side	<ul style="list-style-type: none"> • Front fog lamp bulb • Harness between IPDM E/R and front fog lamp • Harness between front fog lamp and ground • IPDM E/R 	Front fog lamp circuit Refer to EXL-196 . " Component Function Check ".
	Both sides	Symptom diagnosis "BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON" Refer to EXL-215 . " Diagnosis Procedure ".	

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[HALOGEN HEADLAMP]

NORMAL OPERATING CONDITION

Description

INFOID:000000009346755

AUTO LIGHT SYSTEM

The headlamp may not be turned ON/OFF immediately after passing dark area or bright area (short tunnel, sky bridge, shadowed area, etc.) while using the auto light system. This is caused by for the control difference. This is normal.

BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[HALOGEN HEADLAMP]

BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON WITHOUT DAYTIME RUNNING LIGHT SYSTEM

WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Description

INFOID:000000009346756

Both side headlamps (HI) are not turned ON when setting to the lighting switch HI or PASS.

WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure

INFOID:000000009346757

1.COMBINATION SWITCH INSPECTION

Check combination switch. Refer to [BCS-85. "Symptom Table"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

2.CHECK HEADLAMP (HI) REQUEST SIGNAL INPUT

CONSULT DATA MONITOR

1. Select "HL HI REQ" of IPDM E/R data monitor item.
2. With operating the lighting switch, check the monitor status.

Monitor item	Condition		Monitor status
HL HI REQ	Lighting switch (2ND)	HI or PASS	On
		LO	Off

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace BCM. Refer to [BCS-86. "Removal and Installation"](#).

3.HEADLAMP (HI) CIRCUIT INSPECTION

Check headlamp (HI) circuit. Refer to [EXL-182. "WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Component Function Check"](#).

Is the inspection result normal?

YES >> Refer to [GI-53. "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning part.

WITH DAYTIME RUNNING LIGHT SYSTEM

WITH DAYTIME RUNNING LIGHT SYSTEM : Description

INFOID:000000009346758

Both side headlamps (HI) are not turned ON when setting to the lighting switch HI or PASS.

WITH DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure

INFOID:000000009346759

1.COMBINATION SWITCH INSPECTION

Check combination switch. Refer to [BCS-85. "Symptom Table"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

2.CHECK HEADLAMP (HI) REQUEST SIGNAL INPUT

CONSULT DATA MONITOR

1. Select "HL HI REQ" of IPDM E/R data monitor item.
2. With operating the lighting switch, check the monitor status.

Monitor item	Condition		Monitor status
HL HI REQ	Lighting switch (2ND)	HI or PASS	On
		LO	Off

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON

[HALOGEN HEADLAMP]

< SYMPTOM DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace BCM. Refer to [BCS-86. "Removal and Installation"](#).

3. HEADLAMP (HI) CIRCUIT INSPECTION

Check headlamp (HI) circuit. Refer to [EXL-183. "WITH DAYTIME RUNNING LIGHT SYSTEM : Component Function Check"](#).

Is the inspection result normal?

YES >> Refer to [GI-53. "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning part.

BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[HALOGEN HEADLAMP]

BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON

Description

INFOID:000000009346760

Both side headlamps (LO) are not turned ON in any condition.

Diagnosis Procedure

INFOID:000000009346761

1. CHECK COMBINATION SWITCH

Check combination switch. Refer to [BCS-85, "Symptom Table"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

2. CHECK HEADLAMP (LO) REQUEST SIGNAL INPUT

 CONSULT DATA MONITOR

1. Select "HL LO REQ" of IPDM E/R data monitor item.

2. With operating the lighting switch, check the monitor status.

Monitor item	Condition	Monitor status
HL LO REQ	Lighting switch	2ND
		OFF
		On
		Off

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace BCM. Refer to [BCS-86, "Removal and Installation"](#).

3. HEADLAMP (LO) CIRCUIT INSPECTION

Check headlamp (LO) circuit. Refer to [EXL-186, "Component Function Check"](#).

Is the inspection result normal?

YES >> Refer to [GI-53, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning part.

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

EXL

PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[HALOGEN HEADLAMP]

PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS ARE NOT TURNED ON

Description

INFOID:000000009346762

The parking, license plate, side marker, tail lamps and each illumination are not turned ON in any condition.

Diagnosis Procedure

INFOID:000000009346763

1.COMBINATION SWITCH INSPECTION

Check combination switch. Refer to [BCS-85. "Symptom Table"](#).

Is the combination switch normal?

- YES >> GO TO 2.
- NO >> Repair or replace the malfunctioning part.

2.CHECK TAIL LAMP RELAY REQUEST SIGNAL INPUT

ⓂCONSULT DATA MONITOR

1. Select "TAIL & CLR REQ" of IPDM E/R data monitor item.
2. With operating the lighting switch, check the monitor status.

Monitor item	Condition		Monitor status
TAIL & CLR REQ	Lighting switch	1ST	On
		OFF	Off

Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-29. "Removal and Installation"](#).
- NO >> Replace BCM. Refer to [BCS-86. "Removal and Installation"](#).

BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[HALOGEN HEADLAMP]

BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON

Description

INFOID:000000009346764

The front fog lamps are not turned ON in any condition.

Diagnosis Procedure

INFOID:000000009346765

1.CHECK FUSE

Check that the following fuse is not blown.

Unit	Location	Fuse No.	Capacity
Front fog lamp	IPDM E/R	#50	15 A

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the applicable circuit. And then replace the fuse.

2.COMBINATION SWITCH INSPECTION

Check combination switch. Refer to [BCS-85, "Symptom Table"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning part.

3.CHECK FRONT FOG LAMP REQUEST SIGNAL INPUT

CONSULT DATA MONITOR

1. Select "FR FOG REQ" of IPDM E/R data monitor item.

2. With operating the front fog lamp switch, check the monitor status.

Monitor item	Condition	Monitor status	
FR FOG REQ	Front fog lamp switch (With lighting switch 2ND)	ON	On
		OFF	Off

Is the item status normal?

YES >> Replace IPDM E/R. Refer to [PCS-29, "Removal and Installation"](#).

NO >> Replace BCM. Refer to [BCS-86, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

EXL

HEADLAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >

[HALOGEN HEADLAMP]

PERIODIC MAINTENANCE

HEADLAMP AIMING ADJUSTMENT

Description

INFOID:000000009346766

PREPARATION BEFORE ADJUSTING

NOTE:

- For details, refer to the regulations in your own country.
- Perform aiming if the vehicle front body has been repaired and/or the headlamp assembly has been replaced.

Before performing aiming adjustment, check the following.

- Adjust the tire pressure to the specification.
- Fill with coolant and each oil.
- Maintain the unloaded vehicle condition. (Remove luggage from the passenger compartment and the trunk room.)

NOTE:

Do not remove the on-vehicle tool.


- Wipe out dirt on the headlamp.

CAUTION:

Never use organic solvent (thinner, gasoline etc.)

- Ride alone on the driver seat.

AIMING ADJUSTMENT SCREW



A Headlamp RH (UP/DOWN) adjustment screw B. Headlamp LH (UP/DOWN) adjustment screw

↔ : Vehicle center

HEADLAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >

[HALOGEN HEADLAMP]

	Adjustment screw	Rotation	Facing direction
A	Headlamp RH (UP/DOWN)	Clockwise	DOWN
		Counterclockwise	UP
B	Headlamp LH (UP/DOWN)	Clockwise	DOWN
		Counterclockwise	UP


Aiming Adjustment Procedure

INFOID:000000009346767

1. Place the screen.
 - NOTE:**
 - Stop the vehicle facing the wall.
 - Place the board on a plain road vertically.
2. Face the vehicle with the screen. Maintain 10 m (32.8 ft) between the headlamp center and the screen.
3. Start the engine. Turn the headlamp (LO) ON.
 - NOTE:**
 - Shut off the headlamp light with the board to prevent from illuminating the adjustment screen.
 - CAUTION:**
 - Never cover the lens surface with a tape etc. The lens is made of resin.**
4. Measure the distance (X) between the horizontal center line of headlamp (H) and the cutoff line (A) within the light axis measurement range (R) from the vertical center line ahead of headlamp (V).

Light axis measurement range (R) : 350 ± 175 mm (13.78 ± 6.89 in)

Low beam distribution on the screen




5. Adjust the cutoff line height (X) with the aiming adjustment screw so as to enter in the adjustment range (M–N) according to the horizontal center line of headlamp (H).

unit: mm (in)

Horizontal center line of headlamp (H)	Highest cutoff line height (M)	Lowest cutoff line height (N)
700 (27.56) or less	4 (0.16)	30 (1.18)
701(27.60) – 800 (31.50)	4 (0.16)	30 (1.18)
801 (31.54) or more	17 (0.67)	44 (1.73)

Side view



Distance between the headlamp center and the screen (L) : 10 m (32.8 ft)

FRONT FOG LAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >

[HALOGEN HEADLAMP]

FRONT FOG LAMP AIMING ADJUSTMENT

Description

INFOID:000000009346768

PREPARATION BEFORE ADJUSTING

NOTE:

- For details, refer to the regulations in your own country.
- Perform aiming if the vehicle front body has been repaired and/or the fog lamp assembly has been replaced.

Before performing aiming adjustment, check the following.

- Adjust the tire pressure to the specification.
- Fill with coolant and each oil.
- Maintain the unloaded vehicle condition. (Remove luggage from the passenger compartment and the trunk room.)

NOTE:

Do not remove the temporary tire, jack and on-vehicle tool.

- Wipe out dirt on the fog lamp.

CAUTION:

Never use organic solvent (thinner, gasoline etc.)

- Ride alone on the driver seat.

AIMING ADJUSTMENT SCREW

- Turn the aiming adjusting screw for adjustment.


A: DOWN

B: UP

- For the position and direction of the adjusting screw, refer to the figure.

NOTE:

A screwdriver or hexagonal wrench [6 mm (0.24 in)] can be used for adjustment.



Aiming Adjustment Procedure

INFOID:000000009346769

1. Place the screen.

NOTE:

- Stop the vehicle facing the wall.
- Place the board on a plain road vertically.

2. Face the vehicle with the screen. Maintain 10 m (32.8 ft) between the front fog lamp center and the screen.

3. Start the motor. Turn the front fog lamp ON.

NOTE:

Shut off the headlamp light with the board to prevent from illuminating the adjustment screen.

CAUTION:

Never cover the lens surface with a tape etc. The lens is made of resin.


4. Adjust the cutoff line height (A) with the aiming adjustment screw so that the distance (X) between the horizontal center line of front fog lamp (H) and (A) becomes 150 mm (5.906 in).

FRONT FOG LAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >

[HALOGEN HEADLAMP]

Front fog lamp light distribution on the screen



- A : Cutoff line
- B : High illuminance area
- H : Horizontal center line of front fog lamp
- V : Vertical center line of front fog lamp
- X : Cutoff line height

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

FRONT COMBINATION LAMP

< REMOVAL AND INSTALLATION >

[HALOGEN HEADLAMP]


REMOVAL AND INSTALLATION

FRONT COMBINATION LAMP


Exploded View

INFOID:000000009346770

REMOVAL




1. Front side marker lamp 2. Front combination lamp

 : N·m (kg-m, in-lb)

DISASSEMBLY

Front combination lamp



1. Housing assembly 2. Front turn signal lamp bulb 3. Front turn signal lamp bulb socket
4. Harness 5. Halogen bulb

 : Vehicle front

Removal and Installation

INFOID:000000009346771

CAUTION:

FRONT COMBINATION LAMP

< REMOVAL AND INSTALLATION >

[HALOGEN HEADLAMP]

Disconnect the 12V battery negative terminal or remove the fuse to electric leakage. Refer to [EXL-7, "Precaution for Removing 12V Battery"](#).

REMOVAL

1. Remove front bumper fascia. Refer to [EXT-13, "Removal and Installation"](#).
2. Remove front side marker lamp mounting bolts.
3. Pull up front side marker lamp, disconnect the front side marker lamp harness connector and remove the front side marker lamp.
4. Remove front combination lamp mounting bolts.
5. Pull out front combination lamp forward the vehicle, and then disconnect the connector before removing front combination lamp.

INSTALLATION

Note the following item, and then install in the reverse order of removal.

NOTE:

After installation, perform aiming adjustment. Refer to [EXL-216, "Description"](#).

Bulb Replacement



INFOID:000000009346772

CAUTION:

- Disconnect the 12V battery negative terminal or remove the fuse to electric leakage. Refer to [EXL-127, "Precaution for Removing 12V Battery"](#).
- After installing the bulb, install the resin cap and the bulb socket securely for watertightness.
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it to prevent damage to the bulb.
- Never touch bulb by hand while it is lit or right after being turned off to prevent a burns.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

HEADLAMP BULB

1. Rotate resin cap (1) counterclockwise and unlock it.
2. Rotate headlamp bulb (2) counterclockwise and unlock it.
3. Disconnect headlamp bulb from the harness connector (1) and remove.



FRONT TURN SIGNAL LAMP BULB

1. Rotate bulb socket counterclockwise and unlock it.
2. Remove bulb from the bulb socket.

FRONT COMBINATION LAMP

< REMOVAL AND INSTALLATION >

[HALOGEN HEADLAMP]

Disassembly and Assembly

INFOID:000000009346773

DISASSEMBLY

1. Rotate resin cap counterclockwise and unlock it.
2. Rotate headlamp bulb counterclockwise and unlock it.
3. Disconnect headlamp bulb harness connector.
4. Rotate front turn signal lamp bulb socket counterclockwise and unlock it.
5. Remove front turn signal lamp bulb from bulb socket.
6. Remove combination lamp harness connector.


ASSEMBLY

Assembly is in the reverse order of disassembly.

Installing service bracket


INFOID:000000009346774

If only installation part (A) as shown in the figure is damaged, and front combination lamp housing itself is not damaged, repair can be completed easily by installing service brackets.



Removal

1. Remove front combination lamp. Refer to [EXL-220, "Removal and Installation"](#).
2. Cut damaged section of installation part, then shape with sandpaper.




1. Front combination lamp RH
- A. Cut line (R end)

2. Front combination lamp LH

Installation

1. Install service bracket (1) to headlamp housing (2) with screws.



2. Install front combination lamp to the vehicle.

FRONT COMBINATION LAMP

< REMOVAL AND INSTALLATION >

[HALOGEN HEADLAMP]

NOTE:

After installation, perform aiming adjustment. Refer to [EXL-216, "Description"](#).

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

FRONT SIDE MARKER LAMP

< REMOVAL AND INSTALLATION >


[HALOGEN HEADLAMP]

FRONT SIDE MARKER LAMP

Exploded View


INFOID:000000009355111

REMOVAL



1. Front side marker lamp
2. Front combination lamp

DISASSEMBLY



1. Front side marker lamp housing
2. Front side marker lamp bulb socket
3. Front side marker lamp bulb

REMOVAL

1. Remove front side marker lamp mounting bolts.
2. Pull up front side marker lamp and disconnect the harness connector.
3. Remove front side marker lamp.

Removal and Installation

INFOID:000000009355112

Bulb Replacement

INFOID:000000009355113

CAUTION:

Revision: October 2013

EXL-224

2013 LEAF

FRONT SIDE MARKER LAMP

[HALOGEN HEADLAMP]

< REMOVAL AND INSTALLATION >

- After installing the bulb, install the resin cap and the bulb socket securely for watertightness.
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it to prevent damage to the bulb.
- Never touch bulb by hand while it is lit or right after being turned off to prevent a burns.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

A

B

FRONT SIDE MARKER LAMP BULB

1. Rotate bulb socket counterclockwise and unlock it.
2. Remove bulb from the bulb socket.

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

FRONT FOG LAMP


< REMOVAL AND INSTALLATION >

[HALOGEN HEADLAMP]

FRONT FOG LAMP

Exploded View

INFOID:000000009346775



- | | | |
|------------------------|---------------------------|-------------------|
| 1. Front bumper fascia | 2. Front fog lamp bracket | 3. Front fog lamp |
| 4. Front fog lamp bulb | 5. J nut | 6. Metal clip |

Removal and Installation

INFOID:000000009346776

REMOVAL

1. Remove the front under cover. Refer to [EXT-23, "FRONT UNDER COVER : Removal and Installation"](#).
2. Remove the fender protector (LH/RH). Refer to [EXT-21, "FENDER PROTECTOR : Removal and Installation"](#).
3. Disconnect the front fog lamp harness connector.
4. Remove the front fog lamp fixing screws and remove front fog lamp.

INSTALLATION

Note the following item, and then install in the reverse order of removal.

NOTE:

After installation, perform aiming adjustment. Refer to [EXL-218, "Description"](#)

Replacement

INFOID:000000009346777

CAUTION:

- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it to prevent damage to the bulb.
- Never touch bulb by hand while it is lit or right after being turned off to prevent a burns.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

FRONT FOG LAMP BULB


1. Remove front under cover. Refer to [EXT-23, "FRONT UNDER COVER : Removal and Installation"](#).

FRONT FOG LAMP

< REMOVAL AND INSTALLATION >

[HALOGEN HEADLAMP]

2. Remove front fender protector mounting bolts (A) and clip (B).



3. Remove front fog lamp bulb connector.
4. Rotate bulb counterclockwise and unlock it.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

LIGHTING & TURN SIGNAL SWITCH

< REMOVAL AND INSTALLATION >

[HALOGEN HEADLAMP]

LIGHTING & TURN SIGNAL SWITCH

Exploded View


INFOID:000000009346778

The lighting & turn signal switch is integrated in the combination switch. Refer to [BCS-87, "Removal and Installation"](#).

OPTICAL SENSOR

Exploded View

INFOID:000000009346779



1. Optical sensor

2. Switch panel

: Pawl

Removal and Installation

INFOID:000000009346780

REMOVAL

1. Insert suitable tool between the switch panel and the instrument upper panel. Pull out the optical sensor upward.
2. Disconnect the optical sensor connector.
3. Remove optical sensor from switch panel.

INSTALLATION

Install in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

HAZARD SWITCH


< REMOVAL AND INSTALLATION >

[HALOGEN HEADLAMP]

HAZARD SWITCH


Exploded View

INFOID:000000009346781



1. Cluster lid C

2. Hazard switch

 : Pawl

Removal and Installation

INFOID:000000009346782

REMOVAL

1. Remove cluster lid C. Refer to [IP-17. "Removal and Installation"](#).
2. Disengage hazard switch fixing pawls, and then remove hazard switch.

INSTALLATION

Install in the reverse order of removal.

REAR COMBINATION LAMP

< REMOVAL AND INSTALLATION >


[HALOGEN HEADLAMP]

REAR COMBINATION LAMP

Exploded View

INFOID:000000009346783


REMOVAL




1. Rear combination lamp

2. Grommet A

3. Grommet B

 : N·m (kg-m, in-lb)

DISASSEMBLY



1. Rear combination lamp harness

2. Rear turn signal bulb socket

3. Rear turn signal bulb

4. Buck-up lamp bulb socket

5. Buck-up lamp bulb

6. Rear combination lamp housing assembly

Removal and Installation

INFOID:000000009346784

CAUTION:

- Fogging of rear combination lamp inside is not a malfunction. Never replace parts. Fogging is a symptom in which inner surface of lens becomes whitely clouded, without there being visible water drops or water spots, as if lens is made of frosted-glass.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

REAR COMBINATION LAMP

< REMOVAL AND INSTALLATION >


[HALOGEN HEADLAMP]

REMOVAL

1. Remove luggage side lower finisher. Refer to [INT-43. "LUGGAGE SIDE LOWER FINISHER : Removal and Installation"](#).
2. Disconnect rear combination lamp connector.
3. Remove rear combination lamp mounting bolts.
4. Insert a shop cloth (B) into clearance (A) between rear combination lamp (1) and rear fender panel (2), or apply protective tape.


CAUTION:

- To prevent rear fender panel paint surface from being damaged, always apply protection using a shop cloth or protective tape.
- When using protective tape, apply protective tape to both rear fender panel and rear combination lamp.



5. Pull rear combination lamp toward vehicle rear side, as shown by the arrow in the figure.

○ : Clip



6. Remove rear combination lamp.

INSTALLATION

Note the following item, and then install in the reverse order of removal.


CAUTION:

REAR COMBINATION LAMP

< REMOVAL AND INSTALLATION >

[HALOGEN HEADLAMP]

When installing rear combination lamp, fix harness using harness fixing hook (A) on backside of rear combination lamp housing and place harness toward vehicle inside so that harness is not pinched by rear fender panel.



- 1. Harness
 - 2. Rear fender panel
 - 3. Rear fender extension
 - 4. Rear inner panel
- ← : Vehicle front

Replacement

INFOID:000000009346785

CAUTION:

- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it. Never touch bulb by hand while it is lit or right after being turned off.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

STOP/TAIL LAMP BULB

LED is used for stop/tail lamp bulb. Always replace rear combination lamp assembly as a unit, when bulb is to be replaced because of malfunction.

REAR TURN SIGNAL LAMP BULB

1. Remove rear combination lamp mounting bolts.
2. Insert a shop cloth (B) into clearance (A) between rear combination lamp (1) and rear fender panel (2), or apply protective tape.

CAUTION:


- To prevent rear fender panel paint surface from being damaged, always apply protection using a shop cloth or protective tape.

REAR COMBINATION LAMP


< REMOVAL AND INSTALLATION >


[HALOGEN HEADLAMP]

- When using protective tape, apply protective tape to both rear fender panel and rear combination lamp.



3. Pull rear combination lamp toward vehicle rear side, as shown by the arrow in the figure.

 : Clip




4. Rotate bulb socket counterclockwise and unlock it.
5. Remove bulb from the socket.

BACK-UP LAMP BULB

1. Remove rear combination lamp mounting bolts.
2. Insert a shop cloth (B) into clearance (A) between rear combination lamp (1) and rear fender panel (2), or apply protective tape.

CAUTION:

- To prevent rear fender panel paint surface from being damaged, always apply protection using a shop cloth or protective tape.
- When using protective tape, apply protective tape to both rear fender panel and rear combination lamp.





REAR COMBINATION LAMP

[HALOGEN HEADLAMP]

< REMOVAL AND INSTALLATION >

3. Pull rear combination lamp toward vehicle rear side, as shown by the arrow in the figure.

 : Clip



4. Rotate bulb socket counterclockwise and unlock it.
5. Remove bulb from the socket.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

HIGH-MOUNTED STOP LAMP


< REMOVAL AND INSTALLATION >

[HALOGEN HEADLAMP]


HIGH-MOUNTED STOP LAMP

Exploded View

INFOID:000000009346786



1. Rear spoiler
2. High-mounted stop lamp
3. High-mounted stop lamp cover
4. Rear washer nozzle

 : N·m (kg·m, in·lb)

●,▲: Indicates that the part is connected at points with same symbol in actual vehicle.

Removal and Installation

INFOID:000000009346787

REMOVAL

1. Remove rear spoiler. Refer to [EXT-36, "Removal and Installation"](#).
2. Remove high-mounted stop lamp cover mounting screws, and then remove high-mounted stop lamp cover.
3. Remove high-mounted stop lamp mounting screws.
4. Disconnect high-mounted stop lamp harness connector.
5. Remove high-mounted stop lamp.

INSTALLATION

Install in the reverse order of removal.

LICENSE PLATE LAMP


< REMOVAL AND INSTALLATION >

[HALOGEN HEADLAMP]


LICENSE PLATE LAMP

Exploded View

INFOID:000000009346788



1. License plate lamp bulb socket
2. License plate lamp bulb
3. License plate lamp housing


 : Pawl

Removal and Installation

INFOID:000000009346789

REMOVAL

1. Remove license plate lamp in numerical order shown in the figure.



2. Disconnect license plate lamp connector, and then remove license plate lamp.

INSTALLATION

Install in the reverse order of removal.

Replacement

INFOID:000000009346790

CAUTION:

- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it to prevent damage to the bulb.
- Never touch bulb by hand while it is lit or right after being turned off to prevent a burns.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

LICENSE PLATE LAMP BULB

1. Remove license plate lamp.
2. Turn the bulb socket counterclockwise and unlock it.
3. Remove the bulb from the socket.

REAR REFLEX REFLECTOR


< REMOVAL AND INSTALLATION >

[HALOGEN HEADLAMP]


REAR REFLEX REFLECTOR


Exploded View

INFOID:000000009346791



1. Reflex refractor

 : Pawl

 : N·m (kg-m, in-lb)

Removal and Installation

INFOID:000000009346792

REMOVAL

1. Remove rear bumper fascia. Refer to [EXT-17, "Removal and Installation"](#).
2. Remove rear reflex reflector fixing screws and disengage fixing pawls, and then remove rear reflex reflector.

INSTALLATION

Install in the reverse order of removal.

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[HALOGEN HEADLAMP]

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

Bulb Specifications

INFOID:000000009346793

Item	Type	Wattage (W)*
Front combination lamp	Headlamp (HI/LOW)	H13 (Halogen) 60/55
	Turn signal/Park lamp	3457NAK (Amber) 27/7
Front side maker lamp	W5W	5
Front fog lamp	H11	55
Rear combination lamp	Stop lamp/Tail lamp	LED —
	Rear turn signal lamp	WY21W (Amber) 21
	Back-up lamp	W16W 16
	Rear side maker lamp	LED —
License plate lamp	W5W	5
High-mounted stop lamp	LED	—

*: Always check with the Parts Department for the latest parts info.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P