

PG

SECTION

POWER SUPPLY, GROUND & CIRCUIT ELEMENTS

CONTENTS

PRECAUTION	3	Wiring Diagram - BATTERY POWER SUPPLY	
PRECAUTIONS	3	FUSE No.74 -	26
Precaution for Technicians Using Medical Electric.....	3	Wiring Diagram - BATTERY POWER SUPPLY	
Point to Be Checked Before Starting Maintenance		FUSE No.77 -	27
Work	3	Wiring Diagram - ACCESSORY POWER SUP-	
High Voltage Precautions	3	PLY -	28
Precaution for Supplemental Restraint System		Wiring Diagram - ACCESSORY POWER SUP-	
(SRS) "AIR BAG" and "SEAT BELT PRE-TEN-		PLY FUSE No.19 -	29
SIONER"	5	Wiring Diagram - ON POWER SUPPLY -	30
Precaution for Removing 12V Battery	6	Wiring Diagram - ON POWER SUPPLY FUSE	
PREPARATION	7	No.1 -	33
PREPARATION	7	Wiring Diagram - ON POWER SUPPLY FUSE	
Special Service Tools	7	No.3 -	34
SYSTEM DESCRIPTION	8	Wiring Diagram - ON POWER SUPPLY FUSE	
COMPONENT PARTS	8	No.5 -	35
Circuit Breaker	8	Wiring Diagram - ON POWER SUPPLY FUSE	
12V Battery	8	No.55 -	36
Harness Connector	8	FUSE BLOCK - JUNCTION BOX (J/B)	37
Standardized Relay	12	Fuse, Connector and Terminal Arrangement	37
WIRING DIAGRAM	15	FUSE, FUSIBLE LINK AND RELAY BOX	38
POWER SUPPLY ROUTING CIRCUIT	15	Fuse and Fusible Link Arrangement	38
Wiring Diagram - BATTERY POWER SUPPLY -	15	IPDM E/R (INTELLIGENT POWER DISTRI-	
Wiring Diagram - BATTERY POWER SUPPLY		BUTION MODULE ENGINE ROOM)	39
FUSE No.11 -	20	Fuse, Connector and Terminal Arrangement	39
Wiring Diagram - BATTERY POWER SUPPLY		HARNESS	40
FUSE No.12 -	21	Harness Layout	40
Wiring Diagram - BATTERY POWER SUPPLY		BASIC INSPECTION	59
FUSE No.13 -	22	12V BATTERY INSPECTION	59
Wiring Diagram - BATTERY POWER SUPPLY		How to Handle 12V Battery	59
FUSE No.34 -	23	Work Flow	59
Wiring Diagram - BATTERY POWER SUPPLY		ADDITIONAL SERVICE WHEN REMOVING	
FUSE No.43 -	24	12V BATTERY NEGATIVE TERMINAL	62
Wiring Diagram - BATTERY POWER SUPPLY		Special Repair Requirement	62
FUSE No.46 -	25	FUSE INSPECTION	63

How To Check	63
FUSIBLE LINK INSPECTION	64
How To Check	64
REMOVAL AND INSTALLATION	65
12V BATTERY	65
Exploded View	65
Removal and Installation	65
BATTERY TRAY	67
Exploded View	67
Removal and Installation	67

BATTERY TERMINAL WITH FUSIBLE LINK...	68
Exploded View	68
Removal and Installation	68
BATTERY CURRENT SENSOR	69
Exploded View	69
Removal and Installation	69
SERVICE DATA AND SPECIFICATIONS	
(SDS)	70
SERVICE DATA AND SPECIFICATIONS	
(SDS)	70
12V Battery	70

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Technicians Using Medical Electric

INFOID:000000009349251

OPERATION PROHIBITION

WARNING:

- Parts with strong magnet is used in this vehicle.
- Technicians using a medical electric device such as pacemaker must never perform operation on the vehicle, as magnetic field can affect the device function by approaching to such parts.

NORMAL CHARGE PRECAUTION

WARNING:

- If a technician uses a medical electric device such as an implantable cardiac pacemaker or an implantable cardioverter defibrillator, the possible effects on the devices must be checked with the device manufacturer before starting the charge operation.
- As radiated electromagnetic wave generated by PDM (Power Delivery Module) at normal charge operation may affect medical electric devices, a technician using a medical electric device such as implantable cardiac pacemaker or an implantable cardioverter defibrillator must not approach motor room [PDM (Power Delivery Module)] at the hood-opened condition during normal charge operation.

PRECAUTION AT TELEMATICS SYSTEM OPERATION

WARNING:

- If a technician uses implantable cardiac pacemaker or implantable cardioverter defibrillator (ICD), avoid the device implanted part from approaching within approximately 220 mm (8.66 in) from interior/exterior antenna.
- The electromagnetic wave of TCU might affect the function of the implantable cardiac pacemaker or the implantable cardioverter defibrillator (ICD), when using the service, etc.
- If a technician uses other medical electric devices than implantable cardiac pacemaker or implantable cardioverter defibrillator (ICD), the electromagnetic wave of TCU might affect the function of the device. The possible effects on the devices must be checked with the device manufacturer before TCU use.

PRECAUTION AT INTELLIGENT KEY SYSTEM OPERATION

WARNING:

- If a technician uses implantable cardiac pacemaker or implantable cardioverter defibrillator (ICD), avoid the device implanted part from approaching within approximately 220 mm (8.66 in) from interior/exterior antenna.
- The electromagnetic wave of Intelligent Key might affect the function of the implantable cardiac pacemaker or the implantable cardioverter defibrillator (ICD), at door operation, at each request switch operation, or at engine starting.
- If a technician uses other medical electric devices than implantable cardiac pacemaker or implantable cardioverter defibrillator (ICD), the electromagnetic wave of Intelligent Key might affect the function of the device. The possible effects on the devices must be checked with the device manufacturer before Intelligent Key use.

Point to Be Checked Before Starting Maintenance Work

INFOID:000000008743979

The high voltage system may starts automatically. It is required to check that the timer air conditioner and timer charge (during EVSE connection) are not set before starting maintenance work.

NOTE:

If the timer air conditioner or timer charge (during EVSE connection) is set, the high voltage system starts automatically even when the power switch is in OFF state.

High Voltage Precautions

INFOID:000000008743980

WARNING:

- Because hybrid vehicles and electric vehicles contain a high voltage battery, there is the risk of electric shock, electric leakage, or similar accidents if the high voltage component and vehicle are han-

PRECAUTIONS

< PRECAUTION >

dled incorrectly. Be sure to follow the correct work procedures when performing inspection and maintenance.

- Be sure to remove the service plug in order to disconnect the high voltage circuits before performing inspection or maintenance of high voltage system harnesses and parts.
- To prevent the removed service plug from being connected by mistake during the procedure, always carry it in your pocket or put it in the tool box.
- Be sure to wear insulating protective equipment before beginning work on the high voltage system.
- Clearly identify the persons responsible for high voltage work and ensure that other persons do not touch the vehicle. When not working, cover high voltage parts with an insulating cover sheet or similar item to prevent other persons from contacting them.

CAUTION:

There is the possibility of a malfunction occurring if the vehicle is changed to READY status while the service plug is removed. Therefore do not change the vehicle to READY status unless instructed to do so in the Service Manual.

HIGH VOLTAGE HARNESS AND EQUIPMENT IDENTIFICATION

The colors of the high voltage harnesses and connectors are all orange. Orange "High Voltage" labels are applied to the Li-ion battery and other high voltage devices. Do not carelessly touch these harnesses and parts.

HANDLING OF HIGH VOLTAGE HARNESS AND TERMINALS

Immediately insulate disconnected high voltage connectors and terminals with insulating tape.

REGULATIONS ON WORKERS WITH MEDICAL ELECTRONICS

WARNING:

The vehicle contains parts that contain powerful magnets. If a person who is wearing a heart pacemaker or other medical device is close to these parts, the medical device may be affected by the magnets. Such persons must not perform work on the vehicle.

PROHIBITED ITEMS TO CARRY DURING THE WORK

Because this vehicle uses components that contain high voltage and powerful magnetism, do not carry any metal products which may cause short circuits, or any magnetic media (cash cards, prepaid cards, etc.) which may be damaged on your person when working.

POSTING A SIGN OF "DANGER! HIGH VOLTAGE AREA. KEEP OUT"

PRECAUTIONS

< PRECAUTION >

To call the attention of other workers, indicate "High voltage work in progress. Do not touch!" on vehicles where work is being performed on the high voltage systems.

**DANGER:
HIGH VOLTAGE
REPAIR IN PROGRESS.
DO NOT TOUCH!**

Person in charge:

**DANGER:
HIGH VOLTAGE
REPAIR IN PROGRESS.
DO NOT TOUCH!**

Person in charge:_____

Copy this page and put it after folding on the roof of the vehicle in service.

JSAIA1600GB

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000009329157

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS

A
B
C
D
E
F
G
H
I
J
K
L
G
N
O
P

PRECAUTIONS

< PRECAUTION >

system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

Precaution for Removing 12V Battery

INFOID:000000008743982

1. Check that EVSE is not connected.

NOTE:

If EVSE is connected, the air conditioning system may be automatically activated by the timer A/C function.

2. Turn the power switch OFF → ON → OFF. Get out of the vehicle. Close all doors (including back door).
3. Check that the charge status indicator lamp does not blink and wait for 5 minutes or more.

NOTE:

If the battery is removed within 5 minutes after the power switch is turned OFF, plural DTCs may be detected.

4. Remove 12V battery within 1 hour after turning the power switch OFF → ON → OFF.

NOTE:

- The 12V battery automatic charge control may start automatically even when the power switch is in OFF state.
- Once the power switch is turned ON → OFF, the 12V battery automatic charge control does not start for approximately 1 hour.

CAUTION:

- After all doors (including back door) are closed, if a door (including back door) is opened before battery terminals are disconnected, start over from Step 1.
- After turning the power switch OFF, if "Remote A/C" is activated by user operation, stop the air conditioner and start over from Step 1.

PREPARATION

< PREPARATION >



PREPARATION

PREPARATION

Special Service Tools

INFOID:000000008743983

The actual shape of the tools may differ from those illustrated here.

Tool number (TechMate No.) Tool name		Description
— (—) Model GR8-1200 NI Multitasking battery and electrical diagnostic station	 AWI1A1239ZZ	Tests batteries, starting and charging systems and charges batteries. For operating instructions, refer to diagnostic station instruction manual.
— (—) Model EXP-800 NI Battery and electrical diagnostic analyzer	 JSMIA0806ZZ	Tests batteries and charging systems. For operating instructions, refer to diagnostic analyzer instruction manual.

COMPONENT PARTS

< SYSTEM DESCRIPTION >


SYSTEM DESCRIPTION

COMPONENT PARTS

Circuit Breaker

INFOID:000000008743984

The PTC thermistor generates heat in response to current flow. The temperature (and resistance) of the thermistor element varies with current flow. Excessive current flow will cause the element's temperature to rise. When the temperature reaches a specified level, the electrical resistance will rise sharply to control the circuit current. Reduced current flow will cause the element to cool. Resistance falls accordingly and normal circuit current flow is allowed to resume.



12V Battery

INFOID:000000008743985

Type		55B24L(S)
20 hour rate capacity	[V – Ah]	12 – 45
Cold cranking current (For reference value)	[A]	433

NOTE:

VCM charges the 12V battery for 5 minutes when the vehicle power is not turned ON for a set period of time (120 h). Refer to [EVC-61, "AUTOMATIC 12V BATTERY CHARGE CONTROL : System Description"](#).

Harness Connector

INFOID:000000008743986

NOTE:

The color of the high voltage harnesses and connectors is orange. Do not carelessly touch these harnesses and connector.

HARNESS CONNECTOR (TAB-LOCKING TYPE)

- The tab-locking type connectors help prevent accidental looseness or disconnection.
- The tab-locking type connectors are disconnected by pushing or lifting the locking tab(s). Refer to the figure below.


CAUTION:

To prevent damage to the parts, never pull the harness or wires when disconnecting the connector.

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[Example]



SEL769DA

HARNESS CONNECTOR (SLIDE-LOCKING TYPE)

- A new style slide-locking type connector is used on certain systems and components, especially those related to OBD.
- The slide-locking type connectors help prevent incomplete locking and accidental looseness or disconnection.
- The slide-locking type connectors are disconnected by pushing or pulling the slider. Refer to the figure below.
- After connecting the connector, check that the slider is located in the correct position.


CAUTION:

- To prevent damage to the parts, never pull the harness or wires when disconnecting the connector.
- To prevent damage to the parts, be careful not to damage the connector support bracket when disconnecting the connector.

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[Example]



HARNESS CONNECTOR (LEVER LOCKING TYPE)


- Lever locking type harness connectors are used on certain control units and control modules such as ECM, ABS actuator and electric unit (control unit), etc.
- Lever locking type harness connectors are also used on super multiple junction (SMJ) connectors.
- Always confirm the lever is fully locked in place by moving the lever as far as it will go to ensure full connection.

CAUTION:

COMPONENT PARTS

< SYSTEM DESCRIPTION >

Always confirm the lever is fully released (loosened) before attempting to disconnect or connect these connectors to avoid damage to the connector housing or terminals.




- | | | |
|-----------------------------------|----------------------------------|------------------|
| 1. Control unit with single lever | 2. Control unit with dual levers | 3. SMJ connector |
| A. Fasten | A. Levers | A. Lever |
| B. Loosen | B. Fasten | B. Fasten |
| C. Lever | C. Loosen | C. Loosen |

HIGH VOLTAGE HARNESS CONNECTOR (2-STEP TYPE, 3-STEP TYPE)

- 2-step type and 3-step type connectors are used for specific high voltage parts.
- For secure connection, check that the slider is pressed all the way when connecting the high voltage connector.

2-Step Type


DISCONNECT



COMPONENT PARTS


< SYSTEM DESCRIPTION >

CONNECT




3-Step Type

DISCONNECT



CONNECT




Standardized Relay

INFOID:000000008743987

NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS

Relays can mainly be divided into three types: normal open, normal closed and mixed type relays.




BEL881H

COMPONENT PARTS

< SYSTEM DESCRIPTION >

TYPE OF STANDARDIZED RELAYS

1M 1 Make 2M 2 Make
 1T 1 Transfer 1M·1B 1 Make 1 Break

















SEL882H

A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

COMPONENT PARTS

< SYSTEM DESCRIPTION >

Type	Outer view	Circuit	Connector symbol and connection	Case color
1T				BLACK
2M				BROWN
1M•1B				GRAY
1M				BLUE
				

The arrangement of terminal numbers on the actual relays may differ from those shown above.

SEL188W

POWER SUPPLY ROUTING CIRCUIT


< WIRING DIAGRAM >


WIRING DIAGRAM

POWER SUPPLY ROUTING CIRCUIT

Wiring Diagram - BATTERY POWER SUPPLY -

INFOID:000000008743988


For connector terminal arrangements, harness layouts, and alphabets in a  (option abbreviation; if not described in wiring diagram), refer to [GI-12. "Connector Information"](#).



AAMWA0748GB


POWER SUPPLY ROUTING CIRCUIT

< WIRING DIAGRAM >



POWER SUPPLY ROUTING CIRCUIT

< WIRING DIAGRAM >




AAMWA0750GB

A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

POWER SUPPLY ROUTING CIRCUIT


< WIRING DIAGRAM >



AAMWA0751GB

POWER SUPPLY ROUTING CIRCUIT

< WIRING DIAGRAM >




ABMWA1986GB

POWER SUPPLY ROUTING CIRCUIT


< WIRING DIAGRAM >

Wiring Diagram - BATTERY POWER SUPPLY FUSE No.11 -

INFOID:000000008743989

For connector terminal arrangements, harness layouts, and alphabets in a  (option abbreviation; if not described in wiring diagram), refer to [GI-12, "Connector Information"](#).

BATTERY POWER SUPPLY FUSE No. 11




AAMIA1539GB

POWER SUPPLY ROUTING CIRCUIT


< WIRING DIAGRAM >

Wiring Diagram - BATTERY POWER SUPPLY FUSE No.12 -

INFOID:000000008743990

For connector terminal arrangements, harness layouts, and alphabets in a  (option abbreviation; if not described in wiring diagram), refer to [GI-12, "Connector Information"](#).

BATTERY POWER SUPPLY FUSE No. 12



A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

PG


AAMIA1540GB

POWER SUPPLY ROUTING CIRCUIT


< WIRING DIAGRAM >


Wiring Diagram - BATTERY POWER SUPPLY FUSE No.13 -

INFOID:000000008743991

For connector terminal arrangements, harness layouts, and alphabets in a  (option abbreviation; if not described in wiring diagram), refer to [GI-12, "Connector Information"](#).

BATTERY POWER SUPPLY FUSE No. 13

 : With homelink universal transmitter




AAMIA1541GB

POWER SUPPLY ROUTING CIRCUIT






< WIRING DIAGRAM >


Wiring Diagram - BATTERY POWER SUPPLY FUSE No.34 -

INFOID:000000009347911

For connector terminal arrangements, harness layouts, and alphabets in a  (option abbreviation; if not described in wiring diagram), refer to [GI-12, "Connector Information"](#).

BATTERY POWER SUPPLY FUSE No. 34

-  : Without NAVI
-  : With NAVI
-  : Without BOSE audio system
-  : With around view monitor
-  : With BOSE audio system




AAMIA1542GB

POWER SUPPLY ROUTING CIRCUIT


< WIRING DIAGRAM >

Wiring Diagram - BATTERY POWER SUPPLY FUSE No.43 -

INFOID:000000008743992

For connector terminal arrangements, harness layouts, and alphabets in a  (option abbreviation; if not described in wiring diagram), refer to [GI-12, "Connector Information"](#).




BATTERY POWER SUPPLY FUSE No.43



42

•

•

Connector No.	Terminal No.	Connect to
	1	CHARGING PORT LID ILLUMINATION
	11	VCM
	5	CHARGE PORT LID OPENER ACTUATOR RELAY


AAMIA1543GB

POWER SUPPLY ROUTING CIRCUIT





< WIRING DIAGRAM >


Wiring Diagram - BATTERY POWER SUPPLY FUSE No.46 -

INFOID:000000009347912

For connector terminal arrangements, harness layouts, and alphabets in a  (option abbreviation; if not described in wiring diagram), refer to [GI-12, "Connector Information"](#).

BATTERY POWER SUPPLY FUSE No.46

 : without NAVI
 : with NAVI
 : without BOSE audio system
 : with BOSE audio system




AAMIA2054GB

POWER SUPPLY ROUTING CIRCUIT


< WIRING DIAGRAM >

Wiring Diagram - BATTERY POWER SUPPLY FUSE No.74 -

INFOID:000000008743995

For connector terminal arrangements, harness layouts, and alphabets in a  (option abbreviation; if not described in wiring diagram), refer to [GI-12, "Connector Information"](#).

BATTERY POWER SUPPLY FUSE No.74




AAMIA1545GB

POWER SUPPLY ROUTING CIRCUIT


< WIRING DIAGRAM >

Wiring Diagram - BATTERY POWER SUPPLY FUSE No.77 -

INFOID:000000009347913

For connector terminal arrangements, harness layouts, and alphabets in a  (option abbreviation; if not described in wiring diagram), refer to [GI-12, "Connector Information"](#).

BATTERY POWER SUPPLY FUSE No.77



A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P


AAMIA1546GB

POWER SUPPLY ROUTING CIRCUIT


< WIRING DIAGRAM >

Wiring Diagram - ACCESSORY POWER SUPPLY -

INFOID:000000008743996

For connector terminal arrangements, harness layouts, and alphabets in a  (option abbreviation; if not described in wiring diagram), refer to [GI-12, "Connector Information"](#).

ACCESSORY POWER SUPPLY




AAMWA0753GB

POWER SUPPLY ROUTING CIRCUIT





< WIRING DIAGRAM >


Wiring Diagram - ACCESSORY POWER SUPPLY FUSE No.19 -

INFOID:000000008743997

For connector terminal arrangements, harness layouts, and alphabets in a  (option abbreviation; if not described in wiring diagram), refer to [GI-12, "Connector Information"](#).


ACCESSORY POWER SUPPLY FUSE No. 19

 : without NAVI
 : with NAVI
 : without BOSE audio system
 : with BOSE audio system



AAMIA2055GB


< WIRING DIAGRAM >



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

POWER SUPPLY ROUTING CIRCUIT

< WIRING DIAGRAM >




AAMWA0756GB

POWER SUPPLY ROUTING CIRCUIT


< WIRING DIAGRAM >

Wiring Diagram - ON POWER SUPPLY FUSE No.1 -

INFOID:000000008743999

For connector terminal arrangements, harness layouts, and alphabets in a  (option abbreviation; if not described in wiring diagram), refer to [GI-12, "Connector Information"](#).

ON POWER SUPPLY FUSE No. 1



A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P


AAMIA1548GB

POWER SUPPLY ROUTING CIRCUIT







< WIRING DIAGRAM >


Wiring Diagram - ON POWER SUPPLY FUSE No.3 -

INFOID:000000008744000

For connector terminal arrangements, harness layouts, and alphabets in a  (option abbreviation; if not described in wiring diagram), refer to [GI-12, "Connector Information"](#).

ON POWER SUPPLY FUSE No. 3

-  : without NAVI
-  : without BOSE audio system
-  : with around view monitor
-  : with BOSE audio system
-  : With homelink universal transmitter
-  : Without homelink universal transmitter




AAMIA1549GB

POWER SUPPLY ROUTING CIRCUIT

< WIRING DIAGRAM >


Wiring Diagram - ON POWER SUPPLY FUSE No.5 -

INFOID:000000008744001

For connector terminal arrangements, harness layouts, and alphabets in a  (option abbreviation; if not described in wiring diagram), refer to [GI-12, "Connector Information"](#).

ON POWER SUPPLY FUSE No. 5

 : with LED headlamps



A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P


AAMIA1550GB

POWER SUPPLY ROUTING CIRCUIT


< WIRING DIAGRAM >

Wiring Diagram - ON POWER SUPPLY FUSE No.55 -

INFOID:000000008744002

For connector terminal arrangements, harness layouts, and alphabets in a  (option abbreviation; if not described in wiring diagram), refer to [GI-12, "Connector Information"](#).

ON POWER SUPPLY FUSE No. 55



AAMIA1551GB


FUSE BLOCK - JUNCTION BOX (J/B)

< WIRING DIAGRAM >

FUSE BLOCK - JUNCTION BOX (J/B)

Fuse, Connector and Terminal Arrangement

INFOID:000000008744003



A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

AAMIA1552GB





FUSE, FUSIBLE LINK AND RELAY BOX

< WIRING DIAGRAM >

FUSE, FUSIBLE LINK AND RELAY BOX

Fuse and Fusible Link Arrangement

INFOID:000000008744004




AAMIA2056GB

< WIRING DIAGRAM >

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Fuse, Connector and Terminal Arrangement

INFOID:0000000008744005



AAMIA1554GB

HARNESS

< WIRING DIAGRAM >

HARNESS

Harness Layout

INFOID:000000010336172

HOW TO READ HARNESS LAYOUT


The following Harness Layouts use a map style grid to help locate connectors on the drawings:

- Main Harness and Main Sub Harness
- Motor Room Harness and Motor Room Sub Harness
- Motor Room Harness (Passenger Compartment)
- Motor Control Harness
- Body Harness and Rear Wheel Speed Sensor Sub Harness
- Room Lamp Harness
- High Voltage Harness

To use the grid reference


1. Find the desired connector number on the connector list.
2. Find the grid reference.
3. On the drawing, find the crossing of the grid reference letter column and number row.
4. Find the connector number in the crossing zone.
5. Follow the line (if used) to the connector.

Example:



SEL252V

OUTLINE




AAMIA2229GB

HARNESS

< WIRING DIAGRAM >

MAIN HARNESS



AAMIA0236ZZ

B3	M1	W/1	: Fuse block (J/B)	C2	M54	—	: Intake door motor
C2	M2	W/2	: Room lamp diode	D3	M55	W/40	: A/C auto amp.
B4	M4	W/16	: Data link connector	E4	M56	W/8	: Selector indicator
B3	M6	B/8	: Heated steering wheel switch	E4	M57	W/12	: Electric shift sensor

HARNESS

< WIRING DIAGRAM >


A2	M7	B/4	: Heated steering relay	D4	M60	B/3	: Power socket
E2	M8	B/2	: Front passenger air bag module	F5	M61	Y/21	: Air bag diagnosis sensor unit
E1	M9	O/2	: Front passenger air bag module	B2	M62	W/8	: Upper meter
G3	M10	W/55	: To D102	E3	M63	B/4	: Front passenger air bag off indicator
A4	M11	W/55	: To D22	B3	M65	GR/8	: Immediate charging switch
F4	M12	W/8	: To B40	F2	M67	W/40	: TCU
E2	M13	BR/2	: Warning buzzer	F3	M68	GR/17	: TCU
F2	M14	BR/2	: Tweeter RH	A2	M71	B/5	: Heated seat relay
A1	M15	BR/2	: Tweeter LH	B2	M72	—	: Body ground
E1	M16	W/3	: Optical sensor	A1	M73	W/16	: To R1
F3	M18	W/16	: To B1	F1	M74	W/2	: Sunload sensor
B4	M19	W/16	: To B2	E3	M75	W/4	: Remote keyless entry receiver
B4	M20	W/16	: To B26	B2	M76	—	: Body ground
A4	M21	W/32	: To B3	B4	M77	SMJ	: To E105
F4	M22	W/24	: To B7	A3	M78	B/2	: To E106
A3	M23	W/40	: BCM (Body control module)	F4	M79	W/32	: To B4
A2	M24	B/40	: BCM (Body control module)	B3	M80	W/2	: Combination switch
A3	M25	W/15	: BCM (Body control module)	D3	M82	W/4	: To M143
A2	M26	W/12	: Meter control switch	E3	M83	W/20	: Audio unit
B3	M27	W/16	: Combination switch	C1	M84	W/32	: Audio unit
B3	M28	B/8	: VDC off switch	D1	M85	B/5	: Audio unit
A3	M29	B/15	: BCM (Body control module)	D4	M86	B/2	: Inside key antenna (Instrument center)
C3	M30	W/8	: Steering angle sensor	C3	M87	W/24	: To M140
E3	M32	W/40	: Around view monitor control unit	C2	M88	W/2	: Diode-3
D3	M33	W/8	: Push-button ignition switch	A4	M89	W/2	: To B6
B2	M34	W/40	: Combination meter	A3	M90	B/5	: Rear heated seat relay
F2	M35	—	: Body ground	E2	M91	W/4	: Dongle unit
E2	M36	GR/20	: Joint connector-M02	C4	M92	GR/8	: Combination switch
B3	M37	W/8	: EPS control unit	B3	M93	G/8	: Charging port opener switch
B2	M38	B/2	: EPS control unit	A4	M94	GR/10	: Charge connector lock switch
E1	M39	GR/2	: Blower motor	E3	M95	W/20	: AV control unit (With navigation system without BOSE)
C2	M40	B/20	: Joint connector-M05	D1	M96	W/40	: AV control unit (With navigation system without BOSE)
E3	M41	B/20	: Joint connector-M06	D1	M97	GR/17	: AV control unit (With navigation system without BOSE)
C3	M42	W/2	: In-vehicle sensor	D1	M98	B/5	: AV control unit (With navigation system without BOSE)
C2	M43	GR/20	: Joint connector-M04	D3	M99	W/4	: To M200
E3	M44	GR/20	: Joint connector-M01	E3	M100	W/20	: AV control unit (With navigation system with BOSE)
D2	M45	W/4	: Hazard switch	E2	M102	W/16	: Heater pump control unit
E3	M46	O/20	: Joint connector-M07	D1	M103	W/40	: AV control unit (With navigation system with BOSE)
E3	M47	W/16	: Approaching vehicle sound for pedestrians (VSP) control unit	E1	M104	GR/17	: AV control unit (With navigation system with BOSE)
B4	M48	W/2	: Start up sound speaker	E1	M107	B/5	: AV control unit (With navigation system with BOSE)

HARNESS

< WIRING DIAGRAM >

D3	M49	W/4	: NATS antenna amp.	B4	M108	Y/6	: Combination switch (Spiral cable)
C2	M50	P/20	: Joint connector-M03	Main sub harness			
E2	M51	W/8	: Multifunction switch	C2	M200	W/4	: To M99
E4	M52	W/4	: Auxiliary input jack	D1	M201	W/4	: Charging status indicator
D4	M53	G/5	: USB connector				

MOTOR ROOM HARNESS



AAMIA0237ZZ

HARNESS

< WIRING DIAGRAM >


D2	E1	GR/2	: Fusible link box (Battery)	A3	E41	GR/2	: Washer pump
E3	E2	BR/2	: Fusible link box (Battery)	F4	E42	B/2	: Approaching vehicle sound for pedestrians (VSP) speaker
E2	E3	B/1	: Fusible link box (Battery)	B1	E43	B/4	: Power socket relay
E1	E5	W/3	: Anti theft horn relay	A2	E45	GR/6	: Front combination lamp RH (With halogen headlamps)
B4	E7	B/10	: Quick charge port	D4	E46	B/1	: Horn (Low)
E2	E8	B/52	: To F1	A4	E48	B/2	: Front fog lamp RH
F2	E9	B/2	: IPDM E/R (Intelligent power distribution module engine room)	E4	E49	B/3	: Refrigerant pressure sensor
F1	E10	GR/2	: Front side marker lamp LH	C5	E50	B/1	: Horn (Low)
F2	E11	B/6	: IPDM E/R (Intelligent power distribution module engine room)	C1	E52	BR/6	: A/C relay
F2	E12	BR/8	: IPDM E/R (Intelligent power distribution module engine room)	C5	E53	B/2	: Ambient sensor
E3	E13	BR/12	: IPDM E/R (Intelligent power distribution module engine room)	C2	E54	—	: Parking actuator relay
F3	E14	BR/12	: IPDM E/R (Intelligent power distribution module engine room)	B3	E57	B/1	: Vehicle security horn
F3	E15	W/16	: IPDM E/R (Intelligent power distribution module engine room)	D3	E58	B/24	: Joint connector-E03
B1	E16	GR/2	: Front side marker lamp RH	B4	E59	B/1	: Vehicle security horn
F3	E17	W/10	: IPDM E/R (Intelligent power distribution module engine room)	E2	E60	B/12	: To F2
A1	E18	—	: Cooling fan relay	C1	E64	B/4	: F/S chg relay
D4	E19	GR/3	: Cooling fan control module	F1	E65	B/4	: M/C relay
E3	E20	—	: Body ground	E3	E66	B/4	: Battery current sensor
D4	E21	B/4	: To E203	C2	E67	G/4	: Electric water pump
G2	E22	B/2	: Front wheel sensor LH	B3	E69	GR/2	: Coolant temperature sensor
B2	E23	—	: Body ground	D3	E74	GR/2	: Hood switch
C3	E24	GR/2	: Charging port lid illumination	F1	E76	B/5	: Daytime light relay 2
C4	E25	B/2	: Normal charge port	B1	E77	B/4	: Daytime light relay 1
F3	E26	GR/6	: Front combination lamp LH (With halogen headlamps)	B1	E84	B/5	: Daytime running light relay
E1	E27	B/4	: Reverse lamp relay	F3	E85	B/10	: Front combination lamp LH (With LED headlamps)
A2	E28	BR/3	: Intelligent Key warning buzzer	B2	E86	B/10	: Front combination lamp RH (With LED headlamps)
B3	E29	BR/2	: Washer level switch	D4	E87	GR/4	: Charging connector lock actuator
F5	E30	B/2	: Front fog lamp LH	B2	E88	B/4	: Charging port opener actuator relay
E2	E31	B/3	: Master cylinder pressure sensor	B3	E89	BR/2	: Compressor suction refrigerant temperature sensor
E1	E32	GR/5	: Front wiper motor	B2	E90	GR/2	: Refrigerant channel switching 2 way type valve
B4	E33	Y/2	: Crash zone sensor	A2	E91	B/2	: Refrigerant channel switching 3 way type valve
E2	E34	B/46	: Electrically-driven intelligent brake unit	Motor room sub harness			
C1	E35	B/32	: ABS actuator and electric unit (Control unit)	D5	E201	—	: PDM (Power delivery module)

HARNESS

< WIRING DIAGRAM >

C2	E37	GR/2	: Brake fluid level switch	E5	E202	B/4	: Front camera
C3	E38	B/4	: Charge port lid opener actuator	D4	E203	B/4	: To E21
B1	E39	B/2	: Front wheel sensor RH	D3	E204	—	: Fusible link box (Battery)

MOTOR ROOM HARNESS (PASSENGER COMPARTMENT)



AAMIA0238ZZ


A4	E4	B/1	: Parking brake switch	C3	E101	B/6	: Accelerator pedal position sensor
B2	E6	B/12	: Joint connector-E01	C3	E102	W/4	: Stop lamp switch

HARNESS

< WIRING DIAGRAM >


C2	E36	B/4	: Stroke sensor	B4	E105	SMJ	: To M77
B2	E44	B/12	: Joint connector-E02	B3	E106	B/2	: To M78
E2	E61	B/65	: VCM	B4	E107	W/24	: To B7
E2	E62	BR/65	: VCM	A4	E108	W/4	: To B8
A3	E72	—	: Body ground	B4	E112	BR/2	: Brake pedal position switch
A3	E75	—	: Body ground				

MOTOR CONTROL HARNESS



< WIRING DIAGRAM >

BODY HARNESS (LH SIDE)



HARNESS


< WIRING DIAGRAM >

B3	B2	W/16	: To M19	C2	B33	BR/6	: Front heated seat switch RH
B4	B3	W/32	: To M21	C2	B35	Y/2	: Front LH side air bag module
B3	B6	W/2	: To M89	C3	B36	Y/2	: Front LH seat belt pre-tensioner
B3	B7	W/24	: To E107	C4	B37	Y/2	: LH side air bag (Satellite) sensor
B3	B8	W/4	: To E108	B2	B38	B/6	: Yaw rate/side/decel G sensor
E4	B12	B/10	: To B201	D2	B39	—	: Body ground
D2	B13	Y/10	: Air bag diagnosis sensor unit	B2	B48	W/4	: Front door switch (Driver side)
D3	B14	Y/11	: Air bag diagnosis sensor unit	C3	B50	W/2	: Seat belt buckle switch (Driver side)
D3	B15	W/6	: Brake power supply backup unit	C4	B52	O/2	: Lap seat belt pre-tensioner (Driver side)
C2	B17	W/12	: To D201	D2	B71	W/4	: Rear door switch LH
E2	B18	W/20	: To D504	D2	B72	Y/2	: LH side front curtain air bag module
D2	B19	W/4	: To D501	E3	B80	W/6	: Rear combination lamp LH
C3	B21	W/4	: To B251	Rear wheel sensor sub harness			
B3	B24	G/36	: Li-ion battery	D4	B201	B/10	: Wire to wire
B2	B25	W/6	: Front heated seat switch LH	D4	B202	GR/2	: Rear wheel sensor LH
B3	B26	W/16	: To M20	F4	B203	GR/2	: Rear wheel sensor RH

HARNESS

< WIRING DIAGRAM >

BODY HARNESS (RH SIDE)



AAMIA0241ZZ

F3	B1	W/16	: To M18	E3	B34	W/2	: Seat belt buckle switch (Passenger side)
F3	B4	W/32	: To M79	F2	B40	W/8	: To M12
F2	B5	W/4	: To B350	D2	B41	W/2	: Trunk room lamp
C4	B9	W/32	: Bluetooth® control unit	F2	B42	W/24	: To M22
E3	B10	W/8	: Bluetooth® control unit	C2	B43	GR/2	: BOSE subwoofer

HARNESS


< WIRING DIAGRAM >

D2	B11	B/8	: BOSE speaker amp.	F3	B49	W/4	: Front door switch RH
F2	B16	W/12	: To D301	D2	B53	W/4	: Rear door switch RH
D2	B20	B/16	: BOSE speaker amp.	D2	B56	Y/2	: RH side front curtain air bag module
C3	B22	W/3	: To B401	A3	B57	BR/2	: License plate lamp LH
E3	B23	W/8	: To B301	B3	B58	BR/2	: License plate lamp RH
D3	B27	B/16	: BOSE speaker amp.	C3	B59	W/6	: Rear combination lamp RH
E2	B28	Y/2	: Front RH side air bag module	C3	B81	B/2	: Inside key antenna (Rear seat)
E3	B29	Y/2	: Front RH seat belt pre-tensioner	C3	B82	B/2	: Inside key antenna (Luggage room)
E4	B30	Y/2	: RH side air bag (Satellite) sensor	A4	B83	B/2	: Outside key antenna (Rear bumper)
C2	B31	B/20	: Joint connector-B03	E3	B85	B/20	: Joint connector-B02
D2	B32	—	: Body ground				

HARNESS

< WIRING DIAGRAM >

ROOM LAMP HARNESS




AAMIA0242ZZ

E3	R1	W/16	: To M73	E1	R5	W/3	: Room lamp
D2	R3	W/6	: Microphone	D3	R6	B/7	: Auto anti-dazzling inside mirror (Without universal homelink transceiver)
E1	R4	W/8	: Map lamp	D3	R7	B/10	: Auto anit-dazzling inside mirror (With homelink universal transceiver)

HARNESS

< WIRING DIAGRAM >

FRONT DOOR LH HARNESS




AAMIA0243ZZ

D1	W/4	: Side camera LH	D24	BR/2	: Front door speaker LH (With BOSE audio system)
D4	W/8	: Door mirror LH	D25	Y/2	: Front door satellite sensor LH
D5	W/16	: Door mirror remote control switch	D35	W/16	: Power window main switch
D6	GR/2	: Outside key antenna (Driver side)	D36	W/3	: Power window main switch
D15	B/2	: Front door request switch (Driver side)	D37	G/6	: Front power window motor LH
D22	W/55	: To M11	D38	GR/6	: Front door lock assembly (Driver side)
D23	W/2	: Front door speaker LH (Without BOSE audio system)			

HARNESS

< WIRING DIAGRAM >

FRONT DOOR RH HARNESS




AAMIA0244ZZ

D101	W/4	: Side camera RH	D107	GR/5	: Front door lock assembly (Passenger side)
D102	W/55	: To M10	D108	GR/2	: Outside key antenna (Passenger side)
D103	Y/2	: Front door satellite sensor RH	D115	B/2	: Front outside handle RH (Request switch)
D104	W/12	: Front power window switch (Passenger side)	D123	W/2	: Front door speaker RH (Without BOSE audio system)
D105	W/8	: Door mirror RH	D124	BR/2	: Front door speaker RH (With BOSE audio system)
D106	G/6	: Front power window motor (Passenger side)			

HARNESS

< WIRING DIAGRAM > REAR DOOR LH HARNESS




AAMIA0245ZZ

D201	W/12	: To B17	D204	GR/6	: Rear door lock assembly LH
D202	W/8	: Rear power window switch LH	D205	W/2	: Rear door speaker LH
D203	G/6	: Rear power window motor LH			

HARNESS

< WIRING DIAGRAM >
REAR DOOR RH HARNESS



AAMIA0246ZZ


D301	W/12	: To B16	D304	GR/6	: Rear door lock assembly RH
D302	W/8	: Rear power window switch RH	D305	W/2	: Rear door speaker RH
D303	G/6	: Rear power window motor RH			

PG

HARNESS

< WIRING DIAGRAM >

BACK DOOR HARNESS




AAMIA0247ZZ

D501	W/4	: To B19	D557	W/8	: Rear view camera (With around view monitor)
D502	W/2	: To D552	D558	—	: Body ground
D504	W/20	: To B18	D559	W/1	: Coil
D505	W/12	: To D555	D560	W/4	: Coil
D508	—	: Body ground	D561	W/4	: To D602
Back door sub harness			D562	W/4	: Back door lock assembly
D551	B/1	: Condenser	D563	GR/4	: Back door opener switch assembly
D552	W/2	: To D502	D564	B/1	: Condenser-1
D553	B/1	: Condenser	D565	B/1	: Rear window defogger
D554	W/4	: Rear wiper motor	D566	B/1	: Condenser-1
D555	W/12	: To D505	D567	B/1	: Rear window defogger
D556	W/4	: Rear view camera (Without around view monitor)			

HARNESS

< WIRING DIAGRAM >

HIGH VOLTAGE HARNESS



AAMIA0248ZZ

B4	H1	O/4	: Electric compressor (Without heat pump)	C4	H7	O/4	: PDM (Power delivery module)
B4	H2	O/3	: Electric compressor (With heat pump)	D4	H8	O/2	: PDM (Power delivery module)
E2	H3	O/3	: Li-ion battery	B3	H10	O/2	: Quick charge port
C3	H4	—	: Body ground	C4	H11	O/3	: Normal charge port

HARNESS

< WIRING DIAGRAM >

D3	H5	B/3	: PDM (Power delivery module)	F2	H19	O/6	: Li-ion battery
C2	H6	O/3	: PDM (Power delivery module)				

12V BATTERY INSPECTION

< BASIC INSPECTION >

BASIC INSPECTION

12V BATTERY INSPECTION

How to Handle 12V Battery

INFOID:000000008744022


CAUTION:

- If it becomes necessary to start the EV system with a booster battery and jumper cables, use a 12-volt booster battery.
- After connecting 12V battery cables, ensure that they are tightly clamped to 12V battery terminals for good contact.
- Never add distilled water through the hole used to check specific gravity.


METHODS OF PREVENTING OVER-DISCHARGE

The following precautions must be taken to prevent over-discharging a battery.

- The 12V battery surface (particularly its top) should always be kept clean and dry.
- The terminal connections should be clean and tight.
- At every routine maintenance, check the electrolyte level.
This also applies to batteries designated as "low maintenance" and "maintenance-free".



- When the vehicle is not going to be used over a long period of time, disconnect the 12V battery cable from the negative terminal. (If the vehicle has an extended storage switch, turn it off.) Refer to [PG-6, "Precaution for Removing 12V Battery"](#).



Work Flow

INFOID:000000008744023

12V BATTERY DIAGNOSIS WITH EXP-800 NI OR GR8-1200 NI

To diagnose and confirm the condition of the 12V battery, use the following special service tools:

- EXP-800 NI Battery and electrical diagnostic analyzer
- GR8-1200 NI Multitasking battery and electrical diagnostic station

NOTE:

Refer to the applicable instruction manual for proper battery diagnosis procedures.

12V BATTERY DIAGNOSIS WITHOUT EXP-800 NI OR GR8-1200 NI

Check Electrolyte Level

WARNING:


Never allow battery fluid to come in contact with skin, eyes, fabrics, or painted surfaces. After touching a 12V battery, never touch or rub your eyes until you have thoroughly washed your hands. If acid contacts eyes, skin or clothing, immediately flush with water for 15 minutes and seek medical attention.

Failure to do this may cause personal injury or damage to clothing or the painted surfaces.

12V BATTERY INSPECTION


< BASIC INSPECTION >

- Remove the cell plug using a suitable tool.
- Add distilled water up to the MAX level.



SULFATION

- A 12V battery will be completely discharged if it is left unattended for a long time and the specific gravity will become less than 1.100. This may result in sulfation on the cell plates.
- To determine if a 12V battery has been “sulfated”, note its voltage and current when charging it. As shown in the figure, less current and higher voltage are observed in the initial stage of charging sulfated batteries.
- A sulfated 12V battery may sometimes be brought back into service by means of a long, slow charge, 12 hours or more, followed by a battery capacity test.




Specific Gravity Check

NOTE:

Check the charge condition of the battery.

Periodically check the specific gravity of the electrolyte. Keep a close check on charge condition to prevent over-discharge.

1. Read hydrometer and thermometer indications at eye level.
2. Use the chart below to correct your hydrometer reading according to electrolyte temperature.



Hydrometer Temperature Correction

12V Battery electrolyte temperature [°C (°F)]	Add to specific gravity reading
71 (160)	0.032
66 (150)	0.028
60 (140)	0.024
54 (130)	0.020
49 (120)	0.016
43 (110)	0.012
38 (100)	0.008
32 (90)	0.004
27 (80)	0
21 (70)	-0.004
16 (60)	-0.008
10 (50)	-0.012

12V BATTERY INSPECTION

< BASIC INSPECTION >

12V Battery electrolyte temperature [°C (°F)]	Add to specific gravity reading
4 (40)	-0.016
-1 (30)	-0.020
-7 (20)	-0.024
-12 (10)	-0.028
-18 (0)	-0.032

Corrected specific gravity	Approximate charge condition
1.260 - 1.280	Fully charged
1.230 - 1.250	3/4 charged
1.200 - 1.220	1/2 charged
1.170 - 1.190	1/4 charged
1.140 - 1.160	Almost discharged
1.110 - 1.130	Completely discharged

Charging The 12V Battery

CAUTION:

- **Never “quick charge” a fully discharged 12V battery.**
- **Keep the 12V battery away from open flame while it is being charged.**
- **When connecting the charger, connect the leads first, then turn on the charger. Never turn on the charger first, as this may cause a spark.**
- **If 12V battery electrolyte temperature rises above 55 °C (131 °F), stop charging. Always charge battery at a temperature below 55 °C (131 °F).**

Charging Rates (Standard Charge)

Approximate charge condition	Charge current (A)	Charge time (h)
Fully charged	7	2
3/4 charged		2.5
1/2 charged		5
1/4 charged		7.5
Almost discharged		9
Completely discharged		10

Charging Rates (Quick Charge)

Approximate charge condition	Charge current (A)	Charge time (h)
Fully charged	—	—
3/4 charged	16	0.5
1/2 charged	33	
1/4 charged		
Almost discharged		
Completely discharged	—	—

NOTE:

The ammeter reading on your 12V battery charger will automatically decrease as the 12V battery charges. This indicates that the voltage of the 12V battery is increasing normally as the state of charge improves. The charging amps indicated above refer to initial charge rate.

- If, after charging, the specific gravity of any two cells varies more than 0.050, the 12V battery should be replaced.

ADDITIONAL SERVICE WHEN REMOVING 12V BATTERY NEGATIVE TERMINAL

< BASIC INSPECTION >

ADDITIONAL SERVICE WHEN REMOVING 12V BATTERY NEGATIVE TERMINAL

Special Repair Requirement

INFOID:000000009346800

System	Item	Reference
EV Control System	VCM Timer Adjustment	EVC-143, "Description"
Power Window Control System	Power Window System Initialization	PWC-36, "Description"
Heater & Air Conditioning Control System	Temperature Setting Trimmer	HAC-94, "Temperature Setting Trimmer" (with heat pump)
	Inlet Port Memory Function (REC)	HAC-94, "Inlet Port Memory Function (REC)" (with heat pump)
	Inlet Port Memory Function (FRE)	HAC-95, "Inlet Port Memory Function (FRE)" (with heat pump)
	Foot Position Setting Trimmer	HAC-95, "Foot Position Setting Trimmer" (with heat pump)
	Compressor Operation Setting at Defroster Mode (Timer/Remote Climate Control)	HAC-95, "Compressor Operation Setting at Defroster Mode (Timer/Remote Climate Control)" (with heat pump)
	Setting of Compressor Maximum Rotation Speed During Pre Air Conditioning	HAC-96, "Setting of Compressor Maximum Rotation Speed During Pre Air Conditioning" (with heat pump)
	Setting of Compressor Maximum Rotation Speed During Idling	HAC-96, "Setting of Compressor Maximum Rotation Speed During Idling" (with heat pump)
	Temperature Setting Trimmer	HAC-291, "Temperature Setting Trimmer" (without heat pump)
	Inlet Port Memory Function (REC)	HAC-291, "Inlet Port Memory Function (REC)" (without heat pump)
	Inlet Port Memory Function (FRE)	HAC-292, "Inlet Port Memory Function (FRE)" (without heat pump)
	Foot Position Setting Trimmer	HAC-292, "Foot Position Setting Trimmer" (without heat pump)
	Compressor Operation Setting at Defroster Mode (Timer/Remote Climate Control)	HAC-292, "Compressor Operation Setting at Defroster Mode (Timer/Remote Climate Control)" (without heat pump)
	Setting of Compressor Maximum Rotation Speed During Pre Air Conditioning	HAC-293, "Setting of Compressor Maximum Rotation Speed During Pre Air Conditioning" (without heat pump)
	Setting of Compressor Maximum Rotation Speed During Idling	HAC-293, "Setting of Compressor Maximum Rotation Speed During Idling" (without heat pump)
Audio, Visual & Navigation System	Audio (Radio Preset)	Refer to Owner's Manual
	Navigation System	Refer to Owner's Manual

FUSE INSPECTION


< BASIC INSPECTION >

FUSE INSPECTION

How To Check

INFOID:000000008744024

- If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.
- Use fuse of specified rating. Never use fuse of more than specified rating.
- Do not partially install fuse; always insert it into fuse holder properly.
- Remove fuse for "ELECTRICAL PARTS (BAT)" if vehicle is not used for a long period of time.



FUSIBLE LINK INSPECTION

< BASIC INSPECTION >

FUSIBLE LINK INSPECTION

How To Check


INFOID:000000008744025

A melted fusible link can be detected either by visual inspection or by feeling with finger tip. If its condition is questionable, use circuit tester or test lamp.

1 :Fusible link

CAUTION:

- If fusible link should melt, it is possible that critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check and eliminate cause of malfunction.
- Never wrap outside of fusible link with vinyl tape. Important: Never let fusible link touch any other wiring harness, vinyl or rubber parts.



JSMIA0532ZZ

12V BATTERY


< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION

12V BATTERY

Exploded View

INFOID:000000008744026



- | | | |
|-----------------------|-----------------|-------------------------|
| 1. Battery frame | 2. Battery rods | 3. Battery |
| 4. Battery tray liner | 5. Battery tray | 6. Battery tray bracket |

↩ Front

Removal and Installation

INFOID:000000008744027

REMOVAL

1. Disconnect the 12V battery cable from the negative terminal. Refer to [PG-6, "Precaution for Removing 12V Battery"](#).

CAUTION:

To prevent damage to the parts, disconnect the 12V battery cable from the negative terminal first.

2. Remove cover of 12V battery positive terminal.
3. Disconnect the 12V battery cable from the positive terminal.
4. Remove battery frame nuts and battery frame.
5. Remove 12V battery.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

To install the 12V battery, carefully read the following instructions.

- To prevent damage to the parts, connect the 12V battery cable to the positive terminal first.
- After connecting 12V battery cables, to securely supply 12V battery voltage, ensure that they are tightly clamped to 12V battery terminals for good contact.
- To securely supply 12V battery voltage, check 12V battery terminal for poor connection caused by corrosion.

12V BATTERY

< REMOVAL AND INSTALLATION >

Reset electronic systems as necessary. Refer to [PG-62. "Special Repair Requirement"](#).


BATTERY TRAY

< REMOVAL AND INSTALLATION >

BATTERY TRAY

Exploded View

INFOID:000000009328391



- | | | |
|-----------------------|-----------------|-------------------------|
| 1. Battery frame | 2. Battery rods | 3. Battery |
| 4. Battery tray liner | 5. Battery tray | 6. Battery tray bracket |

⇐ Front

Removal and Installation

INFOID:000000009328393

REMOVAL

1. Remove the 12 volt battery. Refer to [PG-65. "Removal and Installation"](#).
2. Remove the battery tray liner.
3. Remove the ground strap retainers from the battery tray and set the ground strap aside.
4. Remove the fuse, fusible link and relay box-1 from the battery tray and set the fuse, fusible link and relay box-1 aside.
5. Remove battery tray bolts and battery tray.

INSTALLATION

Installation is in the reverse order of removal.

BATTERY TERMINAL WITH FUSIBLE LINK

< REMOVAL AND INSTALLATION >


BATTERY TERMINAL WITH FUSIBLE LINK


Exploded View

INFOID:000000008744028

1 : Battery terminal with fusible link

2 : Harness connector

 : N·m (kg-m, ft-lb)



Removal and Installation

INFOID:000000008744029

REMOVAL

1. Disconnect the 12V battery cable from the negative terminal. Refer to [PG-6, "Precaution for Removing 12V Battery"](#).
CAUTION:
To prevent damage to the parts, disconnect the 12V battery cable from the negative terminal first.
2. Remove cover of 12V battery positive terminal.
3. Disconnect the 12V battery cable from the positive terminal.
4. Open cover of harness mounting nut.
5. Remove harness mounting nut and battery terminal with fusible link mounting nut.
6. Disconnect harness connector and remove battery terminal with fusible link.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

To install the 12V battery, carefully read the following instructions.

- **To prevent damage to the parts, connect the 12V battery cable to the positive terminal first.**
- **After connecting 12V battery cables, to securely supply 12V battery voltage, ensure that they are tightly clamped to 12V battery terminals for good contact.**
- **To securely supply 12V battery voltage, check 12V battery terminal for poor connection caused by corrosion.**

Reset electronic systems as necessary. Refer to [PG-62, "Special Repair Requirement"](#)


BATTERY CURRENT SENSOR


< REMOVAL AND INSTALLATION >

BATTERY CURRENT SENSOR

Exploded View

INFOID:000000008744030

- 1 : Battery current sensor
(With battery temperature sensor)
- 2 : Harness connector
-  : N·m (kg-m, ft-lb)



Removal and Installation

INFOID:000000008744031

REMOVAL

1. Disconnect the 12V battery cable from the negative terminal. Refer to [PG-6, "Precaution for Removing 12V Battery"](#).
2. Disconnect the battery current sensor connector.
3. Remove the battery current sensor mounting nut.
4. Remove the battery current sensor from 12V battery cable.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

To install the 12V battery, carefully read the following instructions.

- To prevent damage to the parts, connect the 12V battery cable to the positive terminal first.
- After connecting 12V battery cables, to securely supply 12V battery voltage, ensure that they are tightly clamped to 12V battery terminals for good contact.
- To securely supply 12V battery voltage, check 12V battery terminal for poor connection caused by corrosion.

Reset electronic systems as necessary. Refer to [PG-62, "Special Repair Requirement"](#).

PG

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

12V Battery

INFOID:0000000008744032

Type		51R
20 hour rate capacity	[V – Ah]	12 – 43
Cold cranking current (For reference value)	[A]	410