

SECTION DLK
DOOR & LOCK

A
B
C

CONTENTS

D
E

PRECAUTION	7	Charge Port Lid Opener Switch	21	F
PRECAUTIONS	7	SYSTEM (POWER DOOR LOCK SYSTEM)	22	G
Precaution for Technicians Using Medical Electric.....	7	System Description	22	
Point to Be Checked Before Starting Maintenance		SYSTEM (INTELLIGENT KEY SYSTEM)	24	
Work	7	INTELLIGENT KEY SYSTEM	24	H
Precaution for Supplemental Restraint System		INTELLIGENT KEY SYSTEM : System Descrip-		
(SRS) "AIR BAG" and "SEAT BELT PRE-TEN-		tion	24	
SIONER"	7	DOOR LOCK FUNCTION	25	I
Procedure without Cowl Top Cover	8	DOOR LOCK FUNCTION : System Description	25	
High Voltage Precautions	8	BACK DOOR OPEN FUNCTION	27	J
Precaution for Removing 12V Battery	10	BACK DOOR OPEN FUNCTION : System De-		
Precaution for Work	11	scription	27	
PREPARATION	12	REMOTE KEYLESS ENTRY FUNCTION	28	DLK
PREPARATION	12	REMOTE KEYLESS ENTRY FUNCTION : Sys-		
Special Service Tools	12	tem Description	29	
Commercial Service Tools	13	KEY REMINDER FUNCTION	31	L
SYSTEM DESCRIPTION	15	KEY REMINDER FUNCTION : System Descrip-		
COMPONENT PARTS	15	tion	31	M
Component Parts Location	15	WARNING FUNCTION	32	
Inside Key Antenna (Instrument Center)	17	WARNING FUNCTION : System Description	32	
Inside Key Antenna (Rear Seat)	17	SYSTEM (BACK DOOR OPENER SYSTEM) ...	35	N
Inside Key Antenna (Luggage Room)	17	System Description	35	
Outside Key Antenna (Rear Bumper)	17	SYSTEM (HOMELINK UNIVERSAL TRANS-		
Outside Key Antenna (LH)	18	CEIVER)	36	O
Outside Key Antenna (RH)	18	System Description	36	
Front Door Lock Assembly (LH)	18	SYSTEM (CHARGE PORT LID OPEN CON-		
Remote Keyless Entry Receiver	18	TROL)	37	P
Intelligent Key Warning Buzzer	19	System Description	37	
Back Door Lock Assembly	19	DIAGNOSIS SYSTEM (BCM)	38	
Door Lock and Unlock Switch	19	COMMON ITEM	38	
Front Door Request Switch (LH)	19			
Front Door Request Switch (RH)	20			
Door Switch	20			
Back Door Request Switch	20			
Back Door Opener Switch	20			
Charge Port Lid Opener Actuator	21			

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)	38	Component Function Check	82
		Diagnosis Procedure	82
		Component Inspection	83
DOOR LOCK	38	BACK DOOR REQUEST SWITCH	84
DOOR LOCK : CONSULT Function (BCM - DOOR LOCK)	39	Component Function Check	84
		Diagnosis Procedure	84
		Component Inspection	85
INTELLIGENT KEY	39	BUZZER (COMBINATION METER)	86
INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY)	39	Component Function Check	86
		Diagnosis Procedure	86
TRUNK	42	DOOR KEY CYLINDER SWITCH	87
TRUNK : CONSULT Function (BCM - TRUNK)	42	Component Function Check	87
		Diagnosis Procedure	87
		Component Inspection	88
ECU DIAGNOSIS INFORMATION	43	DOOR LOCK ACTUATOR	89
BCM	43	DRIVER SIDE	89
List of ECU Reference	43	DRIVER SIDE : Component Function Check	89
		DRIVER SIDE : Diagnosis Procedure	89
WIRING DIAGRAM	44	PASSENGER SIDE	90
DOOR & LOCK SYSTEM	44	PASSENGER SIDE :	
Wiring Diagram	44	Component Function Check	90
		PASSENGER SIDE : Diagnosis Procedure	90
HOMELINK UNIVERSAL TRANSCEIVER	63	REAR LH	91
Wiring Diagram	63	REAR LH : Component Function Check	91
		REAR LH : Diagnosis Procedure	91
BASIC INSPECTION	65	REAR RH	92
DIAGNOSIS AND REPAIR WORK FLOW	65	REAR RH : Component Function Check	92
Work Flow	65	REAR RH : Diagnosis Procedure	93
DTC/CIRCUIT DIAGNOSIS	68	DOOR LOCK AND UNLOCK SWITCH	95
B2621 INSIDE ANTENNA	68	DRIVER SIDE	95
DTC Logic	68	DRIVER SIDE : Component Function Check	95
Diagnosis Procedure	68	DRIVER SIDE : Diagnosis Procedure	95
		DRIVER SIDE : Component Inspection	96
B2622 INSIDE ANTENNA	70	PASSENGER SIDE	97
DTC Logic	70	PASSENGER SIDE :	
Diagnosis Procedure	70	Component Function Check	97
		PASSENGER SIDE : Diagnosis Procedure	97
B2623 INSIDE ANTENNA	72	PASSENGER SIDE : Component Inspection	98
DTC Logic	72	DOOR REQUEST SWITCH	100
Diagnosis Procedure	72	Component Function Check	100
		Diagnosis Procedure	100
B2626 OUTSIDE ANTENNA	74	Component Inspection	101
DTC Logic	74	DOOR SWITCH	102
Diagnosis Procedure	74	Component Function Check	102
		Diagnosis Procedure	102
B2627 OUTSIDE ANTENNA	76	Component Inspection	103
DTC Logic	76	HAZARD FUNCTION	105
Diagnosis Procedure	76	Component Function Check	105
		Diagnosis Procedure	105
B2628 OUTSIDE ANTENNA	78		
DTC Logic	78		
Diagnosis Procedure	78		
BACK DOOR OPENER ACTUATOR	80		
Component Function Check	80		
Diagnosis Procedure	80		
BACK DOOR OPENER SWITCH	82		

INTELLIGENT KEY	106	REAR RH	125	
Component Function Check	106	REAR RH : Description	125	A
Diagnosis Procedure	106	REAR RH : Diagnosis Procedure	125	
INTELLIGENT KEY WARNING BUZZER	107	DOOR DOES NOT LOCK/UNLOCK WITH		B
Component Function Check	107	DOOR REQUEST SWITCH	127	
Diagnosis Procedure	107	ALL DOOR REQUEST SWITCHES	127	C
Component Inspection	108	ALL DOOR REQUEST SWITCHES : Description ..	127	
REMOTE KEYLESS ENTRY RECEIVER	109	ALL DOOR REQUEST SWITCHES : Diagnosis	127	D
Component Function Check	109	Procedure	127	
Diagnosis Procedure	109	DRIVER SIDE DOOR REQUEST SWITCH	127	E
UNLOCK SENSOR	112	DRIVER SIDE DOOR REQUEST SWITCH : De-	127	
Component Function Check	112	scription	127	
Diagnosis Procedure	112	DRIVER SIDE DOOR REQUEST SWITCH : Diag-	127	F
Component Inspection	113	nosis Procedure	127	
INFORMATION DISPLAY	114	PASSENGER SIDE DOOR REQUEST SWITCH ...	128	G
Component Function Check	114	PASSENGER SIDE DOOR REQUEST SWITCH :		
Diagnosis Procedure	114	Description	128	
CHARGE PORT LID OPENER RELAY	115	PASSENGER SIDE DOOR REQUEST SWITCH :		H
Diagnosis Procedure	115	Diagnosis Procedure	128	
Component Inspection (Charge Port Lid Opener		BACK DOOR REQUEST SWITCH	128	I
Actuator Relay)	116	BACK DOOR REQUEST SWITCH : Description ..	129	
CHARGE PORT LID OPENER	118	BACK DOOR REQUEST SWITCH : Diagnosis	129	J
Component Function Check	118	Procedure	129	
Diagnosis Procedure	118	DOOR DOES NOT LOCK/UNLOCK WITH		L
Component Inspection (Charge Port Lid Opener		DOOR KEY CYLINDER OPERATION	130	
Actuator)	119	Diagnosis Procedure	130	
CHARGE PORT LID OPENER SWITCH	120	DOOR DOES NOT LOCK/UNLOCK WITH IN-		M
Diagnosis Procedure	120	TELLIGENT KEY	131	
Component Inspection (Charge Port Lid Opener		Diagnosis Procedure	131	
Switch)	120	POWER POSITION WARNING DOES NOT		N
HOMELINK UNIVERSAL TRANSCEIVER	122	OPERATE	132	
Component Function Check	122	Diagnosis Procedure	132	
Diagnosis Procedure	122	SELECTIVE UNLOCK FUNCTION DOES		O
SYMPTOM DIAGNOSIS	124	NOT OPERATE	133	
DOOR DOES NOT LOCK/UNLOCK WITH		Diagnosis Procedure	133	
DOOR LOCK AND UNLOCK SWITCH	124	BACK DOOR DOES NOT OPEN	134	P
ALL DOOR	124	Diagnosis Procedure	134	
ALL DOOR : Description	124	AUTO DOOR LOCK OPERATION DOES NOT		
ALL DOOR : Diagnosis Procedure	124	OPERATE	135	
DRIVER SIDE	124	Diagnosis Procedure	135	
DRIVER SIDE : Description	124	VEHICLE SPEED SENSING AUTO LOCK		
DRIVER SIDE : Diagnosis Procedure	124	OPERATION DOES NOT OPERATE	136	
PASSENGER SIDE	125	Diagnosis Procedure	136	
PASSENGER SIDE : Description	125	POWER SWITCH OFF INTERLOCK DOOR		
PASSENGER SIDE : Diagnosis Procedure	125	UNLOCK FUNCTION DOES NOT OPERATE.	137	
REAR LH	125	Diagnosis Procedure	137	
REAR LH : Description	125	P POSITION INTERLOCK DOOR LOCK/UN-		
REAR LH : Diagnosis Procedure	125	LOCK FUNCTION DOES NOT OPERATE	138	

Diagnosis Procedure	138	CHARGE PORT LID ASSEMBLY : Removal and Installation	158
HAZARD AND BUZZER REMINDER DOES NOT OPERATE	139	CHARGE PORT LID ASSEMBLY : Adjustment ...	159
Diagnosis Procedure	139	CHARGE PORT LID HINGE ASSEMBLY	160
KEY REMINDER FUNCTION DOES NOT OPERATE	141	CHARGE PORT LID HINGE ASSEMBLY : Removal and Installation	160
Diagnosis Procedure	141	CHARGE PORT COVER	160
OFF POSITION WARNING DOES NOT OPERATE	142	CHARGE PORT COVER : Removal and Installation	160
Diagnosis Procedure	142	RADIATOR CORE SUPPORT	161
TAKE AWAY WARNING DOES NOT OPERATE	143	Exploded View	161
Diagnosis Procedure	143	RADIATOR CORE SUPPORT UPPER	161
INTELLIGENT KEY LOW BATTERY WARNING DOES NOT OPERATE	144	RADIATOR CORE SUPPORT UPPER : Removal and Installation	161
Diagnosis Procedure	144	RADIATOR CORE SUPPORT LOWER	163
DOOR LOCK OPERATION WARNING DOES NOT OPERATE	145	RADIATOR CORE SUPPORT LOWER : Removal and Installation	163
Diagnosis Procedure	145	RADIATOR UPPER GRILLE	165
KEY ID WARNING DOES NOT OPERATE	146	RADIATOR UPPER GRILLE : Removal and Installation	165
Diagnosis Procedure	146	CHARGE PORT BRACKET	165
HOMELINK UNIVERSAL TRANSCEIVER DOES NOT OPERATE	147	CHARGE PORT BRACKET : Removal and Installation	165
Diagnosis Procedure	147	FRONT FENDER	168
SQUEAK AND RATTLE TROUBLE DIAGNOSES	148	Exploded View	168
Work Flow	148	Removal and Installation	168
Generic Squeak and Rattle Troubleshooting	149	FRONT DOOR	170
Diagnostic Worksheet	152	Exploded View	170
REMOVAL AND INSTALLATION	154	DOOR ASSEMBLY	170
HOOD	154	DOOR ASSEMBLY : Removal and Installation ...	170
Exploded View	154	DOOR ASSEMBLY : Adjustment	172
HOOD ASSEMBLY	154	DOOR STRIKER	173
HOOD ASSEMBLY : Removal and Installation ...	154	DOOR STRIKER : Removal and Installation	173
HOOD ASSEMBLY : Adjustment	155	DOOR HINGE	173
HOOD HINGE	156	DOOR HINGE : Removal and Installation	173
HOOD HINGE : Removal and Installation	156	DOOR CHECK LINK	174
HOOD SUPPORT ROD	157	DOOR CHECK LINK : Removal and Installation .	174
HOOD SUPPORT ROD : Removal and Installation	157	REAR DOOR	175
HOOD COVER	157	Exploded View	175
HOOD COVER : Removal and Installation	157	DOOR ASSEMBLY	175
CHARGE PORT LID	158	DOOR ASSEMBLY : Removal and Installation ...	175
Exploded View	158	DOOR ASSEMBLY : Adjustment	177
CHARGE PORT LID ASSEMBLY	158	DOOR STRIKER	178
		DOOR STRIKER : Removal and Installation	178
		DOOR HINGE	178
		DOOR HINGE : Removal and Installation	178

DOOR CHECK LINK	179	REAR DOOR LOCK	196	
DOOR CHECK LINK : Removal and Installation ..	179	Exploded View	196	A
BACK DOOR	180	DOOR LOCK	196	
Exploded View	180	DOOR LOCK : Removal and Installation	196	B
BACK DOOR ASSEMBLY	180	INSIDE HANDLE	197	
BACK DOOR ASSEMBLY : Removal and Installation	180	INSIDE HANDLE : Removal and Installation	197	C
BACK DOOR ASSEMBLY : Adjustment	182	OUTSIDE HANDLE	197	
BACK DOOR STRIKER	183	OUTSIDE HANDLE : Removal and Installation	197	
BACK DOOR STRIKER : Removal and Installation	183	BACK DOOR LOCK	200	D
BACK DOOR HINGE	183	Exploded View	200	
BACK DOOR HINGE : Removal and Installation ..	184	DOOR LOCK	200	E
BACK DOOR STAY	184	DOOR LOCK : Removal and Installation	200	
BACK DOOR STAY : Removal and Installation ...	184	OUTSIDE HANDLE	200	
BACK DOOR STAY : Disposal	185	OUTSIDE HANDLE : Removal and Installation	200	F
BACK DOOR WEATHER-STRIP	185	KEY CYLINDER	202	
BACK DOOR WEATHER-STRIP : Removal and Installation	185	GLOVE BOX LID KEY CYLINDER	202	G
HOOD LOCK	187	GLOVE BOX LID KEY CYLINDER : Removal and Installation	202	
Exploded View	187	DOOR SWITCH	203	H
HOOD LOCK	187	Removal and Installation	203	
HOOD LOCK : Removal and Installation	187	DOOR REQUEST SWITCH	204	I
HOOD LOCK SECONDARY CONTROL	188	DRIVER SIDE	204	
HOOD LOCK SECONDARY CONTROL : Removal and Installation	188	DRIVER SIDE : Removal and Installation	204	J
HOOD LOCK CONTROL CABLE	188	PASSENGER SIDE	204	
HOOD LOCK CONTROL CABLE : Removal and Installation	188	PASSENGER SIDE : Removal and Installation ...	204	
Inspection	188	BACK DOOR	204	DLK
CHARGE PORT LID LOCK	190	BACK DOOR : Removal and Installation	204	
Exploded View	190	INSIDE KEY ANTENNA	205	L
CHARGE PORT LID LOCK	190	INSTRUMENT CENTER	205	
CHARGE PORT LID LOCK : Removal and Installation	190	INSTRUMENT CENTER : Removal and Installation	205	M
CHARGE PORT LID OPENER ACTUATOR	191	CENTER CONSOLE	205	
CHARGE PORT LID OPENER ACTUATOR : Removal and Installation	191	CENTER CONSOLE : Removal and Installation ..	205	N
FRONT DOOR LOCK	192	REAR SEAT	205	
Exploded View	192	REAR SEAT : Removal and Installation	205	O
DOOR LOCK	192	LUGGAGE ROOM	205	
DOOR LOCK : Removal and Installation	192	LUGGAGE ROOM : Removal and Installation	205	P
INSIDE HANDLE	193	OUTSIDE KEY ANTENNA	207	
INSIDE HANDLE : Removal and Installation	193	DRIVER SIDE	207	
OUTSIDE HANDLE	193	DRIVER SIDE : Removal and Installation	207	
OUTSIDE HANDLE : Removal and Installation ...	193	PASSENGER SIDE	207	
		PASSENGER SIDE : Removal and Installation ...	207	
		REAR BUMPER	207	

REAR BUMPER : Removal and Installation	207	Removal and Installation	210
INTELLIGENT KEY WARNING BUZZER	208	CHARGE PORT LID OPENER SWITCH	211
Removal and Installation	208	Removal and Installation	211
REMOTE KEYLESS ENTRY RECEIVER	209	BACK DOOR OPENER SWITCH ASSEMBLY	
Removal and Installation	209		..212
INTELLIGENT KEY BATTERY	210	Removal and Installation	212

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Technicians Using Medical Electric

INFOID:0000000010119695

OPERATION PROHIBITION

WARNING:

- Parts with strong magnet is used in this vehicle.
- Technicians using a medical electric device such as pacemaker must never perform operation on the vehicle, as magnetic field can affect the device function by approaching to such parts.

NORMAL CHARGE PRECAUTION

WARNING:

- If a technician uses a medical electric device such as an implantable cardiac pacemaker or an implantable cardioverter defibrillator, the possible effects on the devices must be checked with the device manufacturer before starting the charge operation.
- As radiated electromagnetic wave generated by PDM (Power Delivery Module) at normal charge operation may affect medical electric devices, a technician using a medical electric device such as implantable cardiac pacemaker or an implantable cardioverter defibrillator must not approach motor room [PDM (Power Delivery Module)] at the hood-opened condition during normal charge operation.

PRECAUTION AT TELEMATICS SYSTEM OPERATION

WARNING:

- If a technician uses implantable cardiac pacemaker or implantable cardioverter defibrillator (ICD), avoid the device implanted part from approaching within approximately 220 mm (8.66 in) from interior/exterior antenna.
- The electromagnetic wave of TCU might affect the function of the implantable cardiac pacemaker or the implantable cardioverter defibrillator (ICD), when using the service, etc.
- If a technician uses other medical electric devices than implantable cardiac pacemaker or implantable cardioverter defibrillator (ICD), the electromagnetic wave of TCU might affect the function of the device. The possible effects on the devices must be checked with the device manufacturer before TCU use.

PRECAUTION AT INTELLIGENT KEY SYSTEM OPERATION

WARNING:

- If a technician uses implantable cardiac pacemaker or implantable cardioverter defibrillator (ICD), avoid the device implanted part from approaching within approximately 220 mm (8.66 in) from interior/exterior antenna.
- The electromagnetic wave of Intelligent Key might affect the function of the implantable cardiac pacemaker or the implantable cardioverter defibrillator (ICD), at door operation, at each request switch operation, or at engine starting.
- If a technician uses other medical electric devices than implantable cardiac pacemaker or implantable cardioverter defibrillator (ICD), the electromagnetic wave of Intelligent Key might affect the function of the device. The possible effects on the devices must be checked with the device manufacturer before Intelligent Key use.

Point to Be Checked Before Starting Maintenance Work

INFOID:0000000010119696

The high voltage system may starts automatically. It is required to check that the timer air conditioner and timer charge (during EVSE connection) are not set before starting maintenance work.

NOTE:

If the timer air conditioner or timer charge (during EVSE connection) is set, the high voltage system starts automatically even when the power switch is in OFF state.

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000010119697

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

PRECAUTIONS

< PRECAUTION >

system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS


WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

Procedure without Cowl Top Cover

INFOID:000000010119698


When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc. to prevent damage to the windshield.



High Voltage Precautions

INFOID:000000010119699

DANGER:

 Since hybrid vehicles and electric vehicles contain a high voltage battery, there is the risk of electric shock, electric leakage, or similar accidents if the high voltage component and vehicle are handled incorrectly. Be sure to follow the correct work procedures when performing inspection and maintenance.

WARNING:

- Be sure to remove the service plug in order to disconnect the high voltage circuits before performing inspection or maintenance of high voltage system harnesses and parts.
- The removed service plug must always be carried in a pocket of the responsible worker or placed in the tool box during the procedure to prevent the plug from being connected by mistake.
- Be sure to wear insulated protective equipment before beginning work on the high voltage system.
- Never allow workers other than the responsible person to touch the vehicle containing high voltage parts. To keep others from touching the high voltage parts, these parts must be covered with an insulating sheet except when using them.

CAUTION:

Never bring the vehicle into the READY status with the service plug removed unless otherwise instructed in the Service Manual. A malfunction may occur if this is not observed.

HIGH VOLTAGE HARNESS AND EQUIPMENT IDENTIFICATION

PRECAUTIONS

< PRECAUTION >

All the high voltage harnesses and connectors are orange. The Li-ion battery and other high voltage devices include an orange high voltage label. Never touch these harnesses and high voltage parts.

A

HANDLING OF HIGH VOLTAGE HARNESS AND TERMINALS

Immediately insulate disconnected high voltage connectors and terminals with insulating tape.

B

REGULATIONS ON WORKERS WITH MEDICAL ELECTRONICS

WARNING:

The vehicle contains parts that contain powerful magnets. If a person who is wearing a heart pacemaker or other medical device is close to these parts, the medical device may be affected by the magnets. Such persons must not perform work on the vehicle.

C

PROHIBITED ITEMS TO CARRY DURING THE WORK

Hybrid vehicles and electric vehicles contain parts with high voltage and intense magnetic force. Never carry metal products and magnetic recording media (e.g. cash card, prepaid card) to repair/inspect high voltage parts. If this is not observed, the metal products may create a risk of short circuit and the magnetic recording media may lose their magnetic recording.

D

E

POSTING A SIGN OF "DANGER! HIGH VOLTAGE AREA. KEEP OUT"

F

G

H

I

J

DLK

L

M

N

O

P

PRECAUTIONS

< PRECAUTION >

Indicate "HIGH VOLTAGE. DO NOT TOUCH" on the vehicle under repair/inspection to call attention to other workers.

Person in charge: _____
DO NOT TOUCH! REPAIR IN PROGRESS. HIGH VOLTAGE DANGER:
DANGER: HIGH VOLTAGE REPAIR IN PROGRESS. DO NOT TOUCH! Person in charge: _____
Copy this page and put it after folding on the roof of the vehicle in service.

JSA1A1600GB

Precaution for Removing 12V Battery

INFOID:000000010119700

1. Check that EVSE is not connected.

NOTE:

If EVSE is connected, the air conditioning system may be automatically activated by the timer A/C function.

2. Turn the power switch OFF → ON → OFF. Get out of the vehicle. Close all doors (including back door).

PRECAUTIONS

< PRECAUTION >

3. Check that the charge status indicator lamp does not blink and wait for 5 minutes or more.
- NOTE:**
If the battery is removed within 5 minutes after the power switch is turned OFF, plural DTCs may be detected.
4. Remove 12V battery within 1 hour after turning the power switch OFF → ON → OFF.
- NOTE:**
- The 12V battery automatic charge control may start automatically even when the power switch is in OFF state.
 - Once the power switch is turned ON → OFF, the 12V battery automatic charge control does not start for approximately 1 hour.
- CAUTION:**
- **After all doors (including back door) are closed, if a door (including back door) is opened before battery terminals are disconnected, start over from Step 1.**
 - **After turning the power switch OFF, if “Remote A/C” is activated by user operation, stop the air conditioner and start over from Step 1.**

Precaution for Work

INFOID:000000010119701

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
 - Water soluble dirt:
 - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
 - Then rub with a soft, dry cloth.
 - Oily dirt:
 - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
 - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
 - Then rub with a soft, dry cloth.
 - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
 - For genuine leather seats, use a genuine leather seat cleaner.

PREPARATION

< PREPARATION >





PREPARATION

PREPARATION

Special Service Tools



INFOID:000000010119702

The actual shape of the tools may differ from those illustrated here.

Tool number (TechMate No.) Tool name	Description
<p>— (J-39570) Chassis Ear</p>  <p style="text-align: center;">S1IA0993E</p>	Locating the noise
<p>— (J-50397) NISSAN Squeak and Rattle Kit</p>  <p style="text-align: center;">ALJIA1232Z</p>	Repairing the cause of noise
<p>— (J-46534) Trim Tool Set</p>  <p style="text-align: center;">AWJIA0483Z</p>	Removing trim components
<p>— (J-43241) Remote Keyless Entry Tester</p>  <p style="text-align: center;">LEL946A</p>	Used to test keyfobs





PREPARATION

< PREPARATION >

Tool number (TechMate No.) Tool name	Description	
<p>— (J-50190) Signal Tech II</p>  <p>ALEIA0131ZZ</p>	<ul style="list-style-type: none"> • Activate and display TPMS transmitter IDs • Display tire pressure reported by the TPMS transmitter • Read TPMS DTCs • Register TPMS transmitter IDs • Test remote keyless entry keyfob relative signal strength • Check Intelligent Key relative signal strength • Confirm vehicle Intelligent Key antenna signal strength • Compatible with future sensors • Equipped with a display 	<p>A</p> <p>B</p> <p>C</p> <p>D</p>
<p>KV48105501 (J-45295-A) Transmitter Activation Tool</p>  <p>ALEIA0183ZZ</p>	<ul style="list-style-type: none"> • Activate TPMS transmitter IDs • Compatible with future sensors • Equipped with a display (KV48105501 only) 	<p>E</p> <p>F</p> <p>G</p>




Commercial Service Tools

INFOID:000000010119703

Tool name	Description	
<p>Insulated gloves [Guaranteed insulation performance for 1000V/300A]</p>  <p>JMCIA0149ZZ</p>	<p>Removing and installing high voltage components</p>	<p>H</p> <p>I</p> <p>J</p>
<p>Leather gloves [Use leather gloves that can fasten the wrist tight]</p>  <p>JPCIA0066ZZ</p>	<ul style="list-style-type: none"> • Removing and installing high voltage components • Protect insulated gloves 	<p>DLK</p> <p>L</p> <p>M</p>
<p>Insulated safety shoes</p>  <p>JPCIA0011ZZ</p>	<p>Removing and installing high voltage components</p>	<p>N</p> <p>O</p>
<p>Safety glasses [ANSI Z87.1]</p>  <p>JPCIA0012ZZ</p>	<ul style="list-style-type: none"> • Removing and installing high voltage components • To protect eye from the spatter on the work to electric line 	<p>P</p>

PREPARATION

< PREPARATION >

Tool name	Description
<p data-bbox="164 201 280 222">Face shield</p>  <p data-bbox="776 420 865 434">JPCIA0167ZZ</p>	<ul data-bbox="1008 201 1463 306" style="list-style-type: none">• Removing and installing high voltage components• To protect eye from the spatter on the work to electric line
<p data-bbox="164 453 331 474">Insulated helmet</p>  <p data-bbox="776 667 865 682">JPCIA0013ZZ</p>	<p data-bbox="1008 453 1458 506">Removing and installing high voltage components</p>
<p data-bbox="164 705 272 726">Power tool</p>  <p data-bbox="776 919 849 934">PIIB1407E</p>	<p data-bbox="1008 705 1341 726">Loosening nuts, screws and bolts</p>

COMPONENT PARTS


< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000010119704



A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

COMPONENT PARTS

< SYSTEM DESCRIPTION >

- A. View with glove box lid removed B. View with front bumper removed C. View with cluster lid C removed
 D. View with rear bumper removed E. View with luggage floor upper finisher removed F. View with rear seat removed

No.	Component	Function
1.	VCM	Transmits P position signal to BCM Refer to TM-32, "Component Parts Location" for detailed installation location
2.	Remote keyless entry receiver	DLK-18, "Remote Keyless Entry Receiver"
3.	BCM	BCM detects the vehicle status according to signals from each door switch, each outside/inside key antenna, and unlock sensor. BCM transmits drive signal to door lock actuator when BCM receives operation signal from remote keyless entry receiver and each switch. Refer to BCS-5, "BODY CONTROL SYSTEM : Component Parts Location" for detailed installation location
4.	Intelligent Key warning buzzer	DLK-19, "Intelligent Key Warning Buzzer"
5.	Charge port lid opener actuator	DLK-21, "Charge Port Lid Opener Actuator"
6.	Inside key antenna (instrument center)	DLK-17, "Inside Key Antenna (Instrument Center)"
7.	Power switch	<ul style="list-style-type: none"> Changes power position Inputs power switch ON/OFF condition to BCM Refer to SEC-9, "Component Parts Location" for detailed installation location
8.	Combination meter	<ul style="list-style-type: none"> Displays each operation method guide and warning for system malfunction Performs operation method guide and warning with buzzer Transmits vehicle speed signal to CAN communication line Refer to MWI-6, "METER SYSTEM : Component Parts Location" for detailed installation location
9.	Charge port lid opener switch	DLK-21, "Charge Port Lid Opener Switch"
10.	Main power window and door lock and unlock switch (RH similar)	DLK-19, "Door Lock and Unlock Switch"
11.	Front outside handle LH (outside key antenna)	DLK-18, "Outside Key Antenna (LH)"
12.	Front outside handle LH (request switch)	DLK-19, "Front Door Request Switch (LH)"
13.	Front door lock assembly (LH)	DLK-18, "Front Door Lock Assembly (LH)"
14.	Front door switch LH	DLK-20, "Door Switch"
15.	Back door request switch	DLK-20, "Back Door Request Switch"
16.	Back door opener switch	DLK-20, "Back Door Opener Switch"
17.	Outside antenna (rear bumper)	DLK-17, "Outside Key Antenna (Rear Bumper)"
18.	Back door lock assembly (door opener actuator)	DLK-19, "Back Door Lock Assembly"
19.	Inside key antenna (luggage room)	DLK-17, "Inside Key Antenna (Luggage Room)"
20.	Inside key antenna (rear seat)	DLK-17, "Inside Key Antenna (Rear Seat)"
21.	Front outside handle RH (request switch)	DLK-20, "Front Door Request Switch (RH)"
22.	Front outside handle RH (outside key antenna)	DLK-18, "Outside Key Antenna (RH)"


COMPONENT PARTS

< SYSTEM DESCRIPTION >

Inside Key Antenna (Instrument Center)

INFOID:0000000010119705


- Inside key antenna (instrument center) detects that Intelligent Key is within the inside detection area, and then transmits detection status to BCM.
- Inside key antenna (instrument center) is installed in the rear of cluster lid C of instrument center.



Inside Key Antenna (Rear Seat)

INFOID:0000000010119706


- Inside key antenna (rear seat) detects that Intelligent Key is within the inside detection area, and then transmits detection status to BCM.
- Inside key antenna (rear seat) is installed underneath rear seat cushion.



Inside Key Antenna (Luggage Room)

INFOID:0000000010119707


- Inside key antenna (luggage room) detects that Intelligent Key is within the inside detection area, and then transmits detection status to BCM.
- Inside key antenna (luggage room) is installed in the rear of luggage floor upper finisher.



Outside Key Antenna (Rear Bumper)

INFOID:0000000010119708

- Outside key antenna (rear bumper) detects that Intelligent Key is within the outside detection area, and then transmits detection status to BCM. Request signal is transmitted simultaneously to Intelligent Key.
- Outside key antenna (rear bumper) is installed in the rear of rear bumper.



A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P


COMPONENT PARTS

< SYSTEM DESCRIPTION >

Outside Key Antenna (LH)

INFOID:000000010119709


- Outside key antenna (LH) detects that Intelligent Key is within the outside detection area, and then transmits detection status to BCM. Request signal is transmitted simultaneously to Intelligent Key.
- Outside key antenna (LH) is installed in the front outside handle (LH).



Outside Key Antenna (RH)

INFOID:000000010119710


- Outside key antenna (RH) detects that Intelligent Key is within the outside detection area, and then transmits detection status to BCM. Request signal is transmitted simultaneously to Intelligent Key.
- Outside key antenna (RH) is installed in front outside handle (RH).



Front Door Lock Assembly (LH)

INFOID:000000010119711


- Door lock actuator and unlock sensor are Integrated in front door lock assembly (LH).
- Door lock actuator receives lock/unlock signal from BCM, and then locks/unlocks LH door.
- Only front door lock assembly (LH) integrates unlock sensor. Unlock sensor transmits lock/unlock status of LH door to BCM.



Remote Keyless Entry Receiver

INFOID:000000010119712

- Remote keyless entry receiver receives button operation signal and key ID signal of Intelligent Key, and then transmits them to BCM.
- Remote keyless entry receiver is installed in the rear of glove box lid.




COMPONENT PARTS

< SYSTEM DESCRIPTION >

Intelligent Key Warning Buzzer

INFOID:0000000010119713


- Intelligent Key warning buzzer warns the user, who is outside vehicle, of operation confirmation according to Intelligent Key operation and door request switch operation, or of an inappropriate operation.
- Intelligent Key warning buzzer is installed in the rear of front bumper and underneath headlight RH.



Back Door Lock Assembly

INFOID:0000000010119714


- Back door lock assembly lock assembly integrates door opener actuator and back door switch.
- Door opener actuator opens the back door according to the door open signal from BCM.
- Back door switch detects open/close status of back door.



Door Lock and Unlock Switch

INFOID:0000000010119715


- Door lock and unlock switch transmits door lock/unlock signal operation to BCM.
- Door lock and unlock switch (1) is integrated in the main power window and door lock/unlock switch and power window and door lock/unlock switch RH.



Front Door Request Switch (LH)

INFOID:0000000010119716

- Front door request switch (LH) transmits door request switch signal to BCM.
- Front door request switch (LH) (1) is integrated in front outside handle (LH).



A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P


COMPONENT PARTS

< SYSTEM DESCRIPTION >

Front Door Request Switch (RH)

INFOID:000000010119717


- Front door request switch (RH) transmits door request switch signal to BCM.
- Front door request switch (RH) (1) is integrated in front outside handle (RH).



Door Switch

Door switch detects open/close status of door and transmits door switch signal to BCM.


INFOID:000000010119718



Back Door Request Switch

- Back door request switch transmits back door request switch signal to BCM.
- Back door request switch (1) is integrated in the back door opener switch assembly.


INFOID:000000010119719



Back Door Opener Switch

- Back door opener switch transmits back door opener switch signal to BCM.
- Back door opener switch (1) is integrated in the back door opener switch assembly.

INFOID:000000010119720




COMPONENT PARTS

< SYSTEM DESCRIPTION >

Charge Port Lid Opener Actuator

INFOID:000000010119721


Charge port lid opener actuator ① opens the charge port lid according to the charge port lid open signal from VCM.



Charge Port Lid Opener Switch

INFOID:000000010119722

- When charge port lid opener switch is pressed, charge port lid open operation is detected and charge port lid opener switch signal is transmitted to VCM.
- Charge port lid opener switch is installed on instrument lower panel LH



A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

SYSTEM (POWER DOOR LOCK SYSTEM)


< SYSTEM DESCRIPTION >

SYSTEM (POWER DOOR LOCK SYSTEM)

System Description

INFOID:000000010119723

SYSTEM DIAGRAM



DOOR LOCK FUNCTION

Door Lock and Unlock Switch

- The door lock and unlock switch (LH) is built into main power window and door lock/unlock switch.
- The door lock and unlock switch (RH) is built into power window and door lock/unlock switch RH.
- Interlocked with the locking operation of door lock and unlock switch, door lock actuators of all doors are locked.
- Interlocked with the unlocking operation of door lock and unlock switch, door lock actuators of all doors are unlocked.

Door Key Cylinder Switch

- With the mechanical key inserted in the door key cylinder on driver side, turning it to lock position, locks door lock actuator of all doors.
- With the mechanical key inserted in the door key cylinder on driver side, turning it to unlock position once unlocks the driver side door, turning it to unlock position again within 5 seconds after the first unlock operation unlocks all of the other doors actuator. (SELECTIVE UNLOCK OPERATION)

Selective unlock operation mode can be changed using CONSULT.

Refer to [BCS-20, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)"](#).

POWER POSITION WARNING FUNCTION

When door lock and unlock switch are operated while driver side door is open and power position is ACC or ON, door locks once but immediately unlocks.

INTERIOR ROOM LAMP CONTROL FUNCTION

Interior room lamp is controlled according to door lock /unlock state. Refer to [INL-8, "INTERIOR ROOM LAMP CONTROL SYSTEM : System Description"](#).

AUTOMATIC DOOR LOCK/UNLOCK FUNCTION (LOCK OPERATION)

The interlock door lock function is the function that locks all doors linked with the vehicle speed or shift position. It has 2 types as per the following items.

Vehicle Speed Sensing Auto Door Lock

All doors are locked when the vehicle speed reaches 24 km/h (15 MPH) or more.

BCM outputs the lock signal to all door lock actuators when it detects that the power switch is turned ON, all doors are closed and the vehicle speed received from the combination meter via CAN communication becomes 24 km/h (15 MPH) or more.

P Position Interlock Door Lock

All doors are locked when shifting the selector lever from the P position to any position other than P.

SYSTEM (POWER DOOR LOCK SYSTEM)

< SYSTEM DESCRIPTION >

BCM outputs the lock signal to all door lock actuators when it detects that the power switch is in the ON position and the shift signal received from the VCM is shifted from the P position to any position other than P.

Setting change of Automatic Door Lock/Unlock Function

The lock operation setting of the automatic door lock/unlock function can be changed.

With CONSULT

The ON/OFF switching of the automatic door lock function and the type selection of the automatic door lock/unlock function can be performed at the "Work support" setting of CONSULT.

Without CONSULT

The automatic door lock function ON/OFF can be switched by performing the following operation:

1. Close all doors (door switch OFF)
2. Power switch: OFF→ON
3. Press and hold the door lock and unlock switch for 5 seconds or more in the lock direction within 20 seconds after turning the power switch ON.
4. The switching complete when the hazard lamp blinks.

OFF → ON : 2 blinks

ON → OFF : 1 blink

AUTOMATIC DOOR LOCK/UNLOCK FUNCTION (UNLOCK OPERATION)

The automatic door lock/unlock function is the function that unlocks all doors linked with the power switch position or shift position. It has 2 types as per the following items:

POWER OFF Interlock Door Unlock

All doors are unlocked when the power switch position is changed from ON to OFF.

BCM outputs the unlock signal to all door lock actuators when it detects that the power switch position is changed from ON to OFF.

P Position Interlock Door Unlock

All doors are unlocked when shifting the selector lever from any position other than P to P position.

BCM outputs the unlock signal to all door lock actuators when it detects that the power switch is in the ON position and the shift signal received from VCM is shifted from any position other than P to P position.

Setting change of Automatic Door Lock/Unlock Function

The unlock operation setting of the automatic door lock/unlock function can be changed.

With CONSULT

The ON/OFF switching of the automatic door lock/unlock function and the type selection of the automatic door lock/unlock function can be performed at the "Work support" setting of CONSULT.

Without CONSULT

The automatic door lock/unlock function ON/OFF can be switched by performing the following operation:

1. Close all doors below (door switch OFF)
2. Power switch: OFF→ON
3. Press and hold the door lock and unlock switch for 5 seconds or more in the unlock direction within 20 seconds after turning the power switch position ON.
4. The switching is complete when the hazard lamp blinks.

OFF → ON : 2 blinks

ON → OFF : 1 blink

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

SYSTEM (INTELLIGENT KEY SYSTEM)


< SYSTEM DESCRIPTION >

SYSTEM (INTELLIGENT KEY SYSTEM) INTELLIGENT KEY SYSTEM

INTELLIGENT KEY SYSTEM : System Description

INFOID:000000010119724

SYSTEM DIAGRAM



- The Intelligent Key system is a system that makes it possible to lock and unlock the door locks (door lock/unlock function) by carrying the Intelligent Key, which operates based on the results of electronic ID verification using two-way communication between the Intelligent Key and the vehicle (BCM).

NOTE:

The driver should always carry the Intelligent Key.

- The settings for each function can be changed with CONSULT.
- If an Intelligent Key is lost, a new Intelligent Key can be registered. A maximum of 4 Intelligent Keys can be registered.
- It is possible to perform a diagnosis on the system and register an Intelligent Key with CONSULT.

Function	Description	Refer
Door lock	Lock/unlock can be performed by pressing the request switch	DLK-25
Back door opener	The back door can be opened by carrying the Intelligent Key and pressing the back door opener switch	DLK-27
Remote keyless entry	Lock/unlock can be performed by pressing the remote controller button of the Intelligent Key	DLK-29

SYSTEM (INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >


Function	Description	Refer
Key reminder	The key reminder buzzer sounds a warning if the door is locked with the key left inside the vehicle	DLK-31
Warning	If an action that does not meet the operating condition of the Intelligent Key system is taken, the buzzer sounds to inform the driver	DLK-32
READY set function	The vehicle can be set READY while carrying the Intelligent Key	SEC-12
Panic alarm	When Intelligent Key panic alarm button is pressed, horn sounds	SEC-18
Interior room lamp control	Interior room lamp is controlled according to door lock/unlock state	INL-8
Charge connector unlock	Charge connector unlock can be performed by a long press of the charge port lid opener button on the Intelligent Key	EVC-61
Charge port lid open	Charge port lid open can be performed by a long press of the charge port lid opener button on the Intelligent Key	EVC-61

DOOR LOCK FUNCTION

DOOR LOCK FUNCTION : System Description

INFOID:000000010119725

SYSTEM DIAGRAM



DOOR REQUEST SWITCH OPERATION

When pressing the door request switch, it is possible to lock and unlock the door by carrying the Intelligent Key.

OPERATION DESCRIPTION

- When the BCM detects that each door request switch is pressed, it activates the outside key antenna and inside key antenna corresponding to the pressed door request switch and transmits the request signal to the Intelligent Key. And then, check that the Intelligent Key is near the door.
- If the Intelligent Key is within the outside key antenna detection area, it receives the request signal and transmits the key ID signal to the BCM via remote keyless entry receiver.
- BCM receives the key ID signal and compares it with the registered key ID.
- BCM transmits door lock/unlock signal and operates each door lock actuator. At the same time, BCM blinks hazard warning lamp (lock: 2 times, unlock: 1 time) and sounds Intelligent Key buzzer (lock: 2 times, unlock: 1 time) as a reminder.

SYSTEM (INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

OPERATION CONDITION


If the following conditions are satisfied, door lock/unlock operation is performed if the door request switch is operated:

Each door request switch operation	Operation condition
Lock	<ul style="list-style-type: none"> • All doors are closed • Panic alarm is not activated • Power switch is in the OFF position • Intelligent Key is outside the vehicle • Intelligent Key is within outside key antenna detection area *
Unlock	<ul style="list-style-type: none"> • Power switch is in the OFF position • Intelligent Key is outside the vehicle • Intelligent Key is within outside key antenna detection area *

*: Even with a registered Intelligent Key remaining inside the vehicle, door locks can be locked and unlocked from outside of the vehicle with a spare Intelligent Key as long as key IDs are different.

OUTSIDE KEY ANTENNA DETECTION AREA

The outside key antenna detection area of door lock/unlock function is in the range of approximately 80 cm (31.50 in) surrounding the driver, passenger door handles (1) and back door handle (2). However, this operating range depends on the ambient conditions.



SELECTIVE UNLOCK FUNCTION

Lock Operation

When a LOCK signal is sent from door request switch (LH, RH or back door), all doors are locked.

Unlock Operation

- When an UNLOCK signal from front door request switch (LH) is transmitted, LH door unlocks. When another UNLOCK signal is transmitted within 60 seconds, all door unlocks.
- When an UNLOCK signal from front door request switch (RH) is transmitted, RH door unlocks. When another UNLOCK signal is transmitted within 60 seconds, all door unlocks.
- When an UNLOCK signal from back door request switch is transmitted, back door unlocks. When another UNLOCK signal is transmitted within 60 seconds, all door unlocks.

How to Change Selective Unlock Operation Mode

Selective unlock operation mode can be changed using CONSULT.

Refer to [BCS-20, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)"](#).

HAZARD AND BUZZER REMINDER FUNCTION

During lock, unlock, operation by each request switch, the hazard warning lamps and Intelligent Key warning buzzer will blink or honk as a reminder.

When doors are locked, unlocked by each request switch, BCM honks Intelligent Key warning buzzer as a reminder and blinks.

Operating Function of Hazard and Buzzer Reminder

Operation	Hazard warning lamp blinks	Intelligent Key warning buzzer honk
Unlock	Once	Once
Lock	Twice	Twice

Hazard and buzzer reminder does not operate if power switch ON position.

How to Change Hazard and Buzzer Reminder Operation Mode

Hazard and buzzer reminder operation mode can be changed using CONSULT.

Refer to [BCS-20, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)"](#).

SYSTEM (INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

AUTO DOOR LOCK FUNCTION

After door is unlocked by door request switch operation and if 60 seconds or more passes without performing the following operation, all doors are automatically locked. However, operation check function does not activate.

Operating condition	<ul style="list-style-type: none"> • Door switch is ON (door is open) • Door is locked • Power switch is pressed
---------------------	---

Auto door lock mode can be changed by the "AUTO LOCK SET" in "Work support". Refer to [BCS-20, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)"](#).

LIST OF OPERATION RELATED PARTS

Parts marked with × are the parts related to operation.


Door lock function	Intelligent Key	Remote keyless entry receiver	Door switch	Door request switch	Door lock actuator	Inside key antenna	Outside key antenna	CAN communication system	BCM	Hazard warning lamp	Power switch	Combination meter
Door lock/unlock function	×	×	×	×	×	×	×		×			
Hazard reminder function								×	×	×		×
Door lock status indicator operation									×			
Selective unlock function	×			×	×	×	×		×			
Auto door lock function	×				×				×		×	

BACK DOOR OPEN FUNCTION

BACK DOOR OPEN FUNCTION : System Description

INFOID:000000010119726

SYSTEM DIAGRAM



BACK DOOR OPEN OPERATION

This section describes the operation of the back door opener switch. The operation of the back door opener request switch is the same as the door lock function. Refer to [DLK-35, "System Description"](#).

SYSTEM (INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

- The back door open function can open the back door by pressing the back door opener switch while carrying the Intelligent Key and all doors are locked.
- The back door open function enables the back door to be opened by pressing back door opener switch after BCM transmits UNLOCK signal to each door.

BACK DOOR OPEN

- When the BCM detects that back door opener switch is pressed, it starts the outside key antenna (rear bumper) and inside key antenna and transmits the request signal to the Intelligent Key. Then, check that the Intelligent Key is near the back door.
- If the Intelligent Key is within the outside key antenna detection area, it receives the request signal and transmits the key ID signal to the BCM via remote keyless entry receiver.
- BCM receives the key ID signal and compares it with the registered key ID.
- BCM opens back door and simultaneously unlocks all doors.

NOTE:

In selective unlock mode, only back door opens. All doors do not unlock.


OPERATION CONDITION

If the following conditions are satisfied, the back door can be opened:

Back door open function	Operation condition
Back door open operation	<ul style="list-style-type: none"> • Vehicle speed is less than 5 km/h (3 MPH) • Panic alarm is not activated • Intelligent Key is outside of vehicle • Intelligent Key is within outside key antenna detection area • Back door is closed

OUTSIDE KEY ANTENNA DETECTION AREA

The outside key antenna detection area of back door open function is in the range of approximately 80 cm (31.50 in) surrounding the back door opener switch (1). However, this operating range depends on the ambient conditions.



LIST OF OPERATION RELATED PARTS

Parts marked with × are the parts related to operation.

Back door open function	Intelligent Key	Remote keyless entry receiver	Back door opener actuator	Door lock actuator	Inside key antenna	Outside key antenna (rear bumper)	CAN communication system	BCM	Back door opener switch	Combination meter
Back door open function	×	×	×	×	×	×	×	×	×	×

REMOTE KEYLESS ENTRY FUNCTION


SYSTEM (INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

REMOTE KEYLESS ENTRY FUNCTION : System Description

INFOID:000000010119727

SYSTEM DIAGRAM



BASIC OPERATION

The Intelligent Key has the same functions as the remote control entry system. Therefore, it can be used in the same manner as the remote controller by operating the door lock/unlock button.

OPERATION

Remote keyless entry system controls operation of the following items:

- Door lock/unlock
- Selective Unlock function
- Hazard reminder function
- Auto door lock

OPERATION AREA

To check that the Intelligent Key works normally, use within 1 m (3 ft) range of each doors, however the operable range may differ according to surroundings.

DOOR LOCK/UNLOCK FUNCTION

- When door lock/unlock button of the Intelligent Key is pressed, lock signal or unlock signal transmitted from Intelligent Key to BCM via remote keyless entry receiver.
- BCM receives the signal and compares it with the registered key ID to the vehicle.
- When BCM receives the door lock/unlock signal, it operates all door lock actuators and the hazard lamp (lock: 2 time, unlock: 1 times) and horn chirp signal to IPDM E/R at the same time as a reminder.
- IPDM E/R honks horn (lock: 1 times) as a reminder.

OPERATION CONDITION

If the following condition are satisfied, remote keyless entry operation is performed when the Intelligent Key is operated:

Remote controller operation	Operation condition
Lock / Unlock	Panic alarm is not activated

SELECTIVE UNLOCK FUNCTION

- When an LOCK signal is transmitted from Intelligent Key, all doors are locked.
- When an UNLOCK signal is transmitted from Intelligent Key once, driver side door is unlocked.
- Then, if an UNLOCK signal is transmitted from Intelligent Key again within 60 seconds, all other doors are unlocked.

How To Change Selective Unlock Operation Mode

Selective unlock operation mode can be changed using CONSULT.

Refer to [BCS-20. "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)".](#)

HAZARD AND HORN REMINDER FUNCTION

SYSTEM (INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

When doors are locked or unlocked by Intelligent Key, BCM blinks hazard warning lamps as a reminder and transmits horn chirp signal to IPDM E/R. IPDM E/R sounds horn as a reminder. The hazard and horn reminder has a horn chirp mode (C mode) and a non-horn chirp mode (S mode).

Operating Function of Hazard and Horn Reminder

	C mode			S mode		
	Lock	Unlock	Back door open	Lock	Unlock	Back door open
Intelligent Key operation	Lock	Unlock	Back door open	Lock	Unlock	Back door open
Hazard warning lamp blinks	Twice	Once	—	Twice	—	—
Horn sound	Once	—	—	—	—	—

Hazard and horn reminder does not operate if power switch ON position.


How to change hazard and horn reminder mode

Ⓟ With CONSULT

Refer to [BCS-20, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)"](#).

ⓧ Without CONSULT

When LOCK and UNLOCK signals are sent from the Intelligent Key for more than 2 seconds at the same time, the hazard and horn reminder mode is changed and hazard warning lamp blinks and horn sounds as per the following items:



AUTO DOOR LOCK FUNCTION

After door is unlocked by Intelligent Key button operation and if 60 seconds or more passes without performing the following operation, all doors are locked. However, operation check function does not activate.

Operating condition	<ul style="list-style-type: none"> • Door switch is ON (door is open) • Door is locked • Power switch is pressed
---------------------	---

How To Change Auto Door Lock Operation Mode

Auto door lock operation mode can be changed using CONSULT.

Refer to [BCS-20, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)"](#).

LIST OF OPERATION RELATED PARTS

Parts marked with × are the parts related to operation.

Remote keyless entry functions	Intelligent Key	Door switch	Door lock actuator	Power switch	Intelligent Key warning buzzer	CAN communication system	BCM	Combination meter	Hazard warning lamp	IPDM E/R
Door lock/unlock function by remote control button	×	×	×			×	×			
Hazard reminder function	×			×	×	×	×	×	×	×

SYSTEM (INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >


	Intelligent Key	Door switch	Door lock actuator	Power switch	Intelligent Key warning buzzer	CAN communication system	BCM	Combination meter	Hazard warning lamp	IPDM E/R
Remote keyless entry functions										
Selective Unlock function	x	x	x	x		x	x			
Auto door lock function	x					x	x			

KEY REMINDER FUNCTION

KEY REMINDER FUNCTION : System Description

INFOID:000000010119728

SYSTEM DIAGRAM



BASIC OPERATION

Key reminder is the function that prevents the key from being left in the vehicle. Key reminder has the following 3 functions:

Key remainder function	Operation condition	Operation
Driver side door closed*	Right after driver side door is closed under the following conditions <ul style="list-style-type: none"> Intelligent Key is inside the vehicle Driver side door is opened Driver side door is in unlock state 	All doors unlock
Door is open or closed	Right after all doors are closed under the following conditions <ul style="list-style-type: none"> Intelligent Key is inside the vehicle Any door is opened All doors are locked. 	<ul style="list-style-type: none"> All doors unlock Honk Intelligent Key warning buzzer
Back door is closed	Right after back door is closed under the following conditions <ul style="list-style-type: none"> Intelligent Key is inside the vehicle All doors (except back door) are closed All doors (except back door) are locked 	<ul style="list-style-type: none"> All doors unlock Back door can open with back door opener switch Honk Intelligent Key warning buzzer

*:If the door closing impact shocks the door lock knob, or contacts against baggage with the door lock knob might activate the door locks accidentally but unlock operation is perform in these cases.

NOTE:

- The above function operates when the Intelligent Key is inside the vehicle. However, there may be times when the Intelligent Key cannot be detected, and this function does not operate when the Intelligent Key is

A
B
C
D
E
F
G
H
I
J

DLK

L
M
N
O
P

SYSTEM (INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

on the instrument panel, rear parcel shelf, or in the glove box. Also, this system sometimes does not operate if the Intelligent Key is in the door pocket for the open door.

WARNING FUNCTION

WARNING FUNCTION : System Description

INFOID:000000010119729

OPERATION DESCRIPTION

The warning function are as per the following items and are given to the user as warning information and warnings using combinations of Intelligent Key warning buzzer, combination meter buzzer and information display in combination meter:

- Intelligent Key system malfunction
- OFF position warning
- Take away warning
- Door lock operation warning
- Key ID warning
- READY set information
- Plug in information
- Intelligent Key low battery warning
- Key ID verification information

OPERATION CONDITION

Once the following condition from below is established, alert or warning is executed:

Warning/Information functions		Operation procedure
Intelligent Key system malfunction		When a malfunction is detected on BCM
OFF position warning		When condition A, B or condition C is satisfied <ul style="list-style-type: none"> • Condition A <ul style="list-style-type: none"> - Power switch: ACC position - Door switch (driver side): ON (Door is open) • Condition B <ul style="list-style-type: none"> - Turn power switch from ON to OFF while door is open • Condition C <ul style="list-style-type: none"> - Intelligent Key backside is contacted to power switch while brake pedal is depressed and power switch is LOCK or OFF (When the Intelligent Key battery is discharged) - Door switch (driver side): ON (Door is open)
Take away warning	Door is open to close	<ul style="list-style-type: none"> • Power switch: Except LOCK position • Door switch: ON to OFF (Door is open to close) • Intelligent Key cannot be detected inside the vehicle
	Door is open	<ul style="list-style-type: none"> • Power switch: Except LOCK position • Door switch: ON (Door is open) • Key ID verification every 5 seconds when registered Intelligent Key cannot be detected inside the vehicle
	Power switch operation	<ul style="list-style-type: none"> • Power switch: Except LOCK position • Press power switch • Intelligent Key cannot be detected inside the vehicle
Door lock operation warning		When door lock operation is requested while door lock operating condition of door request switch or Intelligent Key are not satisfied
Key ID warning		When registered Intelligent Key cannot be detected inside the vehicle after Power switch is turned ON
READY set information *	Power switch is ON position	<ul style="list-style-type: none"> • Power switch: ON position • Electric shift selector position: P position • The vehicle is not READY • When charge port is not connected
	Power switch is except ON position	<ul style="list-style-type: none"> • Power switch: Except ON position • Electric shift selector position: P position • Intelligent Key is detected inside the vehicle after driver door is open and then closed • When charge port is not connected

SYSTEM (INTELLIGENT KEY SYSTEM)





< SYSTEM DESCRIPTION >

Warning/Information functions	Operation procedure
Plug in indicator*	When charge port is connected
Intelligent Key low battery warning	When Intelligent Key is low battery, BCM is detected after power switch is turned ON
Key ID verification information	<ul style="list-style-type: none"> • When registered Intelligent Key can not be detected inside the vehicle • Intelligent Key battery is discharged • When NATS antenna amp cannot be detected NATS ID

*:One of either item is displayed according to connection status of charge port connector.

WARNING METHOD

The following table shows the alarm or warning methods with chime:
Information display (combination meter) when the warning conditions are met.




Warning/Information functions		Information display (combination meter)	Warning chime	
			Combination meter buzzer	Intelligent Key warning buzzer
Intelligent Key system malfunction		 <small>JMKIA5196ZZ</small>	—	—
OFF position warning		—	Sounds (beeps continuously)	—
Take away warning	Door is open to close	 <small>JMKIA5192ZZ</small>	Sounds (beeps 3 times)	Sounds (beeps 1 time)
	Door is open		—	—
	Power switch operation		Sounds (beeps 3 times)	—
Door lock operation warning	Request switch operation	—	—	Sounds (for 2 seconds)
	Intelligent Key operation	—	—	Sounds (for 2 seconds)
Key ID warning		 <small>JMKIA5192ZZ</small>	—	—
READY set information		 <small>JMKIA6134GB</small>	—	—

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

SYSTEM (INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

Warning/Information functions	Information display (combination meter)	Warning chime	
		Combination meter buzzer	Intelligent Key warning buzzer
Plug in indicator	 <small>JMKIA6370GB</small>	—	—
Intelligent Key low battery warning	 <small>JMKIA3049ZZ</small>	—	—
Key ID verification information	 <small>JMKIA4907ZZ</small>	—	—

LIST OF OPERATION RELATED PARTS

Parts marked with × are the parts related to operation.

Warning function		Intelligent Key	Power switch	Door switch	Door request switch	Inside key antenna	Outside key antenna	Intelligent Key warning buzzer	Combination meter buzzer	CAN communication system	BCM	Information display
Intelligent Key system malfunction										×	×	×
OFF position warning				×					×	×	×	
Take away warning	Door is open or close	×		×		×		×	×	×	×	×
	Door is open	×		×		×				×	×	×
	Power switch operation	×	×			×			×	×	×	×
Door lock operation warning		×		×	×	×	×				×	
Key ID warning			×			×				×	×	×
READY set information	Power switch is ON position	×	×			×				×	×	×
	Power switch is except ON position	×	×			×				×	×	×
Plug in indicator												×
Intelligent Key low battery warning		×				×				×	×	×
Key ID verification information		×				×				×	×	×

SYSTEM (BACK DOOR OPENER SYSTEM)


< SYSTEM DESCRIPTION >

SYSTEM (BACK DOOR OPENER SYSTEM)

System Description

INFOID:000000010119730

SYSTEM DIAGRAM



BACK DOOR OPENER OPERATION

When back door opener switch is pressed, BCM operates back door opener actuator.

NOTE:

Back door opener actuator is not for locking the back door. The function is only to open the back door.

OPERATION CONDITION

If the following conditions are satisfied, back door opener operation is performed:

Back door opener switch operation	Operation condition
Back door open	<ul style="list-style-type: none"> When back door opener switch is pressed while all doors are in unlock status. Vehicle speed is less than 5 km/h (3 MPH)

NOTE:

- When 12V battery terminal is disconnected and reconnected during all doors unlock state, back door may not open.
- Regardless of door lock actuator state, BCM resets recognition of all doors unlock state approximately 30 seconds after 12V battery terminal is disconnected and BCM recognizes that all doors are in lock state.
- When 12V battery terminal is reconnected and back door does not open, have BCM recognize that all doors are in unlock state.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

SYSTEM (HOMELINK UNIVERSAL TRANSCEIVER)

< SYSTEM DESCRIPTION >

SYSTEM (HOMELINK UNIVERSAL TRANSCEIVER)

System Description

INFOID:000000010119731

Item	Function
HomeLink® Universal Transceiver	A maximum of 3 radio signals can be stored and transmitted to operate the garage door, etc.

SYSTEM (CHARGE PORT LID OPEN CONTROL)

< SYSTEM DESCRIPTION >

SYSTEM (CHARGE PORT LID OPEN CONTROL)

System Description

INFOID:000000010119732

OPERATION DESCRIPTION

Charge port lid open can be performed by pressing the charge port lid opener button or charge port lid opener switch. Refer to [EVC-61, "CHARGE PORT CONTROL : System Description"](#).

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (BCM) COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000010500887

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Direct Diagnostic Mode	Description
Ecu Identification	The BCM part number is displayed.
Self Diagnostic Result	The BCM self diagnostic results are displayed.
Data Monitor	The BCM input/output data is displayed in real time.
Active Test	The BCM activates outputs to test components.
Work support	The settings for BCM functions can be changed.
Configuration	<ul style="list-style-type: none"> The vehicle specification can be read and saved. The vehicle specification can be written when replacing BCM.
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

SYSTEM APPLICATION

BCM can perform the following functions.

System	Sub System	Direct Diagnostic Mode						
		Ecu Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
Door lock	DOOR LOCK		×	×	×	×		
Rear window defogger	REAR DEFOGGER			×	×			
Warning chime	BUZZER			×	×			
Interior room lamp timer	INT LAMP			×	×	×		
Exterior lamp	HEADLAMP			×	×	×		
Wiper and washer	WIPER			×	×	×		
Turn signal and hazard warning lamps	FLASHER			×	×	×		
Air conditioner	AIR CONDITIONER			×	×			
Intelligent Key system	INTELLIGENT KEY		×	×	×	×		
Combination switch	COMB SW			×				
BCM	BCM	×	×			×	×	×
Immobilizer	IMMU		×	×	×	×		
Interior room lamp battery saver	BATTERY SAVER			×	×	×		
Trunk open	TRUNK			×				
Vehicle security system	THEFT ALM			×	×	×		
RAP system	RETAINED PWR			×				
Signal buffer system	SIGNAL BUFFER			×				
TPMS	AIR PRESSURE MONITOR		×	×	×	×		

DOOR LOCK

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

DOOR LOCK : CONSULT Function (BCM - DOOR LOCK)

INFOID:000000010500888

SELF DIAGNOSTIC RESULT

Refer to [BCS-48, "DTC Index"](#).

DATA MONITOR

Monitor Item [Unit]	Description
REQ SW-DR [On/Off]	Indicates condition of door request switch LH.
REQ SW-AS [On/Off]	Indicates condition of door request switch RH.
REQ SW-BD/TR [On/Off]	Indicates condition of back door request switch.
DOOR SW-DR [On/Off]	Indicates condition of front door switch LH.
DOOR SW-AS [On/Off]	Indicates condition of front door switch RH.
DOOR SW-RR [On/Off]	Indicates condition of rear door switch RH.
DOOR SW-RL [On/Off]	Indicates condition of rear door switch LH.
DOOR SW-BK [On/Off]	Indicates condition of trunk switch.
CDL LOCK SW [On/Off]	Indicates condition of lock signal from door lock and unlock switch.
CDL UNLOCK SW [On/Off]	Indicates condition of unlock signal from door lock and unlock switch.
KEY CYL LK-SW [On/Off]	Indicates condition of lock signal from door key cylinder switch.
KEY CYL UN-SW [On/Off]	Indicates condition of unlock signal from door key cylinder switch.

ACTIVE TEST

Test Item	Description
DOOR LOCK	This test is able to check door lock operation [ALL LOCK/ALL UNLK/DR UNLK/AS UNLK/OTR ULK].

WORK SUPPORT

Support Item	Setting	Description
DOOR LOCK-UNLOCK SET	On*	Selective unlock function ON.
	Off	Selective unlock function OFF.
AUTOMATIC LOCK/UNLOCK SELECT	Lock/Unlock*	Automatic door lock and unlock functions ON.
	Lock Only	Automatic door lock only function ON.
	Unlock Only	Automatic door unlock only function ON.
	Off	Automatic door lock function OFF.
AUTOMATIC DOOR LOCK SELECT	P RANGE	Doors lock automatically when shifted out of P (park).
	VH SPD	Doors lock automatically when vehicle speed is greater than 24 km/h (15 mph).
AUTOMATIC DOOR UNLOCK SELECT	MODE6	This mode is not used.
	MODE5	This mode is not used.
	MODE4	Driver door is unlocked automatically when shifted into P (park).
	MODE3	Driver door is unlocked automatically when ignition is switched from ON to OFF.
	MODE2	All doors unlock automatically when shifted into P (park).
MODE1*	All doors unlock automatically when ignition is switched from ON to OFF.	

*: Initial setting

INTELLIGENT KEY

INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY)

INFOID:000000010500889

SELF DIAGNOSTIC RESULT

Refer to [BCS-48, "DTC Index"](#).

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

DATA MONITOR

Monitor Item [Unit]	Main	Description
REQ SW -DR [On/Off]	×	Indicates condition of door request switch LH.
REQ SW -AS [On/Off]	×	Indicates condition of door request switch RH.
REQ SW -BD/TR [On/Off]	×	Indicates condition of back door request switch.
PUSH SW [On/Off]		Indicates condition of power switch.
BRAKE SW 1 [On/Off]	×	Indicates condition of brake switch.
BRAKE SW 2 [On/Off]		Indicates condition of brake switch.
DETE/CANCL SW [On/Off]	×	Indicates condition of P (park) position.
SFT PN/N SW [On/Off]	×	Indicates condition of P (park) or N (neutral) position.
UNLK SEN -DR [On/Off]	×	Indicates condition of door unlock sensor.
PUSH SW -IPDM [On/Off]		Indicates condition of power switch received from IPDM E/R on CAN communication line.
IGN RLY1 -F/B [On/Off]		Indicates condition of ignition relay 1 received from IPDM E/R on CAN communication line.
DETE SW -IPDM [On/Off]		Indicates condition of detent switch received from TCM on CAN communication line.
SFT P -MET [On/Off]		Indicates condition of P (park) position from TCM on CAN communication line.
SFT N -MET [On/Off]		Indicates condition of N (neutral) position from IPDM E/R on CAN communication line.
ENGINE STATE [Stop/Start/Crank/Run]	×	Indicates condition of engine state from ECM on CAN communication line.
VEH SPEED 1 [mph/km/h]	×	Indicates condition of vehicle speed signal received from ABS on CAN communication line.
VEH SPEED 2 [mph/km/h]	×	Indicates condition of vehicle speed signal received from combination meter on CAN communication line.
DOOR STAT -DR [LOCK/READY/UNLK]	×	Indicates condition of driver side door status.
DOOR STAT -AS [LOCK/READY/UNLK]	×	Indicates condition of passenger side door status.
ID OK FLAG [Set/Reset]		Indicates condition of Intelligent Key ID.
PRMT ENG STRT [Set/Reset]		Indicates condition of engine start possibility.
RKE OPE COUN1 [0-19]	×	When remote keyless entry receiver receives the signal transmitted while operating the Intelligent Key, the numerical value starts changing.
RKE-LOCK [On/Off]		Indicates condition of lock signal from Intelligent Key.
RKE-UNLOCK [On/Off]		Indicates condition of unlock signal from Intelligent Key.
RKE-PANIC [On/Off]		Indicates condition of panic signal from Intelligent Key.
RKE-MODE CHG [On/Off]		Indicates condition of mode change signal from Intelligent Key.

ACTIVE TEST

Test Item	Description
INSIDE BUZZER	This test is able to check combination meter warning chime operation [Off/Take Out/Knob/Key].

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Test Item	Description		
LCD	B&P N	This test is able to check combination meter traction motor start information.	A
	B&P I		B
	ID NG	This test is able to check combination meter key ID warning information.	B
	ROTAT	This item is displayed, but is not used.	C
	SFT P		C
	INSRT		C
	BATT	This test is able to check combination meter Intelligent Key low battery warning information.	D
	NO KY	This item is displayed, but is not used.	D
	OUTKEY	This test is able to check combination meter take away warning information.	E
	LK WN	This test is able to check combination meter OFF position warning information.	E
	Off	—	E
BATTERY SAVER	This test is able to check interior room lamp battery saver operation [Off/On].		F
ENGINE SW ILLUMI	This test is able to check power switch illumination operation [Off/On].		F
PUSH SWITCH INDICATOR	This test is able to check power switch ACC/ON indicator operation [Off/On].		G
TRUNK/BACK DOOR	This test is able to check back door opener actuator operation [Open].		G
INT LAMP	This test is able to check interior room lamp operation [Off/On].		H
INDICATOR	This test is able to check combination meter warning lamp operation [Off/KEY ON/KEY IND].		H
FLASHER	This test is able to check security hazard lamp operation [RH/LH/Off].		H
OUTSIDE BUZZER	This test is able to check Intelligent Key warning buzzer operation [On/Off].		I
HORN	This test is able to check horn operation [On].		I

WORK SUPPORT

Support Item	Setting	Description	
LOCK/UNLOCK BY I-KEY	On*	Door lock/unlock function from request switch ON.	J
	Off	Door lock/unlock function from request switch OFF.	J
ANTI KEY LOCK IN-FUNCTI	On*	Key reminder function ON.	DLK
	Off	Key reminder function OFF.	DLK
ANS BACK I-KEY UNLOCK	On*	Buzzer reminder function when doors are unlocked with request switch ON.	L
	Off	Buzzer reminder function when doors are unlocked with request switch OFF.	L
ANS BACK I-KEY LOCK	Horn Chirp	Horn chirp reminder function when doors are locked with request switch.	M
	Buzzer*	Buzzer reminder function when doors are locked with request switch.	N
	Off	No reminder function when doors are locked with request switch.	N
HORN WITH KEYLESS LOCK	On*	Horn reminder function when doors are locked with Intelligent Key ON.	O
	Off	Horn reminder function when doors are locked with Intelligent Key OFF.	O
HAZARD ANSWER BACK	Lock/Unlock*	Horn reminder function when doors are locked or unlocked with request switch or Intelligent Key.	P
	Unlock Only	Horn reminder function when doors are unlocked with request switch or Intelligent Key.	P
	Lock Only	Horn reminder function when doors are locked with request switch or Intelligent Key.	P
	Off	Horn reminder function when doors are locked or unlocked with request switch or Intelligent Key OFF.	P

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Support Item	Setting	Description	
INSIDE ANT DIAGNOSIS	—	This function allows inside key antenna self-diagnosis.	
CONFIRM KEY FOB ID	MEMORY 1	Intelligent Key ID code can be checked.	
	MEMORY 2		
	MEMORY 3		
	MEMORY 4		
	NON REGIST		
PANIC ALARM SET	MODE 3	1.5 sec.	Panic alarm button set time on Intelligent Key can be set.
	MODE 2	OFF	
	MODE 1*	0.5 sec.	
AUTO LOCK SET	MODE7	5 min.	Auto door lock time can be set.
	MODE6	4 min.	
	MODE5	3 min.	
	MODE4	2 min.	
	MODE3*	1 min.	
	MODE2	30 sec.	
	MODE1	OFF	

*: Initial Setting

TRUNK

TRUNK : CONSULT Function (BCM - TRUNK)

INFOID:0000000010500890

DATA MONITOR

Monitor Item [Unit]	Description
PUSH SW [On/Off]	Indicates condition of power switch.
UNLK SEN -DR [On/Off]	Indicates condition of door unlock sensor.
VEH SPEED 1 [km/h]	Indicates vehicle speed signal received from ABS on CAN communication line.
TR/BD OPEN SW [On/Off]	Indicates condition of back door opener switch.

BCM

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION

BCM

List of ECU Reference

INFOID:0000000010119737

ECU	Reference
	BCS-28, "Reference Value"
BCM	BCS-46, "Fail-safe"
	BCS-47, "DTC Inspection Priority Chart"
	BCS-48, "DTC Index"

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DOOR & LOCK SYSTEM


< WIRING DIAGRAM >

WIRING DIAGRAM

DOOR & LOCK SYSTEM

Wiring Diagram


INFOID:000000010119738



AAKWA0827GB

DOOR & LOCK SYSTEM

< WIRING DIAGRAM >




AAKWA0828GB

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DOOR & LOCK SYSTEM


< WIRING DIAGRAM >



AAKWA0829GB

DOOR & LOCK SYSTEM

< WIRING DIAGRAM >



AAKWA0830GB


A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DOOR & LOCK SYSTEM

< WIRING DIAGRAM >


DOOR LOCK SYSTEM - CONNECTORS

Connector No.	M4
Connector Name	DATA LINK CONNECTOR
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6	L	-
14	P	-

Connector No.	M10
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4A	LG	-
5A	V	-
10A	BR	-
11A	Y	-
12A	B	-
36A	B	-
37A	P	-
38A	Y	-
39A	LG	-

Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4C	G	-
5C	V	-
13C	B	-
36C	LG	-
37C	R	-
38C	GR	-
39C	W	-
40C	P	-
41C	V	-
47C	Y	-
48C	BR	-

Connector No.	M18
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5	G	-
6	V	-

DOOR & LOCK SYSTEM

< WIRING DIAGRAM >


Terminal No.	Color of Wire	Signal Name
27	Y	-
31	L	-
32	P	-

Connector No.	M21
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
11	P	-
12	V	-
26	W	-

Connector No.	M19
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	GR	-
5	GR	-
6	W	-

Connector No.	M23
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
75	LG	REQUEST SW (DR)
76	SB	ENGINE START SW
78	P	DOOR ANTENNA (DR) +
79	V	DOOR ANTENNA (DR) -
80	LG	DOOR ANTENNA (AS) +
81	Y	DOOR ANTENNA (AS) -

Terminal No.	Color of Wire	Signal Name
82	W	BACK DOOR ANTENNA +
83	B	BACK DOOR ANTENNA -
84	BR	ROOM ANTENNA 1 +
85	Y	ROOM ANTENNA 1 -
86	G	ROOM ANTENNA 2 +
87	R	ROOM ANTENNA 2 -
88	G	ROOM ANTENNA 3 +
89	R	ROOM ANTENNA 3 -
93	GR	SMART KEYLESS BUZZER OUTPUT
97	LG	STARTER RELAY OUTPUT
100	P	REQUEST SW (AS)
102	BG	SHIFT N, P

AAKIA1980GB

A B C D E F G H I J L M N O P

DLK

DOOR & LOCK SYSTEM

< WIRING DIAGRAM >

Terminal No.	Color of Wire	Signal Name
30	V	TRUNK/BACK DOOR OPENER SW
31	W	DOOR LOCK STATUS SW (DR)
37	V	SHIFT P POSITION, PARKING POSITION SW
38	SB	INTELLIGENT TUNER
39	L	CAN-H
40	P	CAN-L

Terminal No.	Color of Wire	Signal Name
7	GR	KEY CYLINDER UNLOCK SW
8	R	KEY CYLINDER LOCK SW
12	Y	CENTRAL DOOR LOCK SW
13	BR	CENTRAL DOOR UNLOCK SW
18	L	KEYLESS TUNER, AUTO LIGHT SENSOR GND

Connector No.	M24
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

Connector No.	M33
Connector Name	POWER SWITCH
Connector Color	WHITE



4	5	6	7	8
3				

Terminal No.	Color of Wire	Signal Name
4	B	-
8	SB	-

Connector No.	M29
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



41	42	43	44	45	46	47	48	49
50	51	52	53	54	55			

Terminal No.	Color of Wire	Signal Name
43	Y	DOOR SW (BACK)
45	BR	DOOR SW (AS)
46	R	DOOR SW (RR)
47	SB	DOOR SW (DR)
48	W	DOOR SW (RL)
51	P	REQUEST SW (TRUNK/BACK DOOR)
53	GR	TRUNK/BACK DOOR OPEN OUTPUT
55	G	DOOR UNLOCK OUTPUT (RR, RL)

Connector No.	M25
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



56	57	58	59	60	61	62	63	64
65	66	67	68	69	70			


Terminal No.	Color of Wire	Signal Name
57	P	BATTERY (FUSE)
59	LG	DOOR UNLOCK OUTPUT (AS)
60	V	FLASHER OUTPUT (LEFT)
61	R	FLASHER OUTPUT (RIGHT)
63	BR	ROOM LAMP OUTPUT
65	V	DOOR LOCK OUTPUT
66	G	DOOR UNLOCK COMMON (DR)
67	B	GND
70	Y	BATTERY (F/L)

AAK1A1981GB

DOOR & LOCK SYSTEM


< WIRING DIAGRAM >

Connector No.	M41
Connector Name	JOINT CONNECTOR-M06
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
9	L	-
10	L	-
19	P	-
20	P	-

Connector No.	M40
Connector Name	JOINT CONNECTOR-M05
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
5	L	-
8	L	-
9	L	-
10	L	-
11	LG	-
12	LG	-
15	P	-
18	P	-
19	P	-
20	P	-

Connector No.	M34
Connector Name	COMBINATION METER
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	LG	BAT
3	GR	IGN
5	B	GND 1 (ILL)
6	B	GND 2 (POWER)
18	P	CAN-L
19	L	CAN-H

Connector No.	M46
Connector Name	JOINT CONNECTOR-CM07
Connector Color	ORANGE




Terminal No.	Color of Wire	Signal Name
19	SB	-
20	SB	-

Connector No.	M44
Connector Name	JOINT CONNECTOR-M01
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
11	P	-
12	P	-

Connector No.	M43
Connector Name	JOINT CONNECTOR-M04
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
2	Y	-
12	Y	-

AAKIA1982GB


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK

DOOR & LOCK SYSTEM


< WIRING DIAGRAM >

Connector No.	M50
Connector Name	JOINT CONNECTOR-CM03
Connector Color	PINK



Terminal No.	Color of Wire	Signal Name
1	B	-
3	B	-
4	B	-

Connector No.	M75
Connector Name	REMOTE KEYLESS ENTRY RECEIVER
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	G	-
2	SB	-
3	-	-
4	L	-

Connector No.	M77
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
13	V	-
20	GR	-
23	BG	-
44	LG	-
60	Y	-
61	GR	-
91	Y	-

Connector No.	M79
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
10	BR	-
13	B	-
15	R	-
16	G	-
26	R	-
29	W	-
30	R	-
31	G	-
32	-	-



AAK1A1983GB

DOOR & LOCK SYSTEM


< WIRING DIAGRAM >

Connector No.	E5
Connector Name	ANTI THEFT HORN RELAY
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R	-
2	O	-
3	G	-

Connector No.	M93
Connector Name	CHARGE PORT LID OPENER SWITCH
Connector Color	GREEN




Terminal No.	Color of Wire	Signal Name
1	P	-
6	-	-
8	B	-

Connector No.	M86
Connector Name	INSIDE KEY ANTENNA (INSTRUMENT CENTER)
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	BR	-
2	Y	-

Connector No.	E12
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
18	B/W	GND (SIGNAL)
20	V	FR FOG/LH

Connector No.	E11
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
9	B	GND (POWER)

Connector No.	E6
Connector Name	JOINT CONNECTOR-E01
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-
3	L	-
7	P	-
8	P	-
9	P	-

AAKIA1984GB

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DOOR & LOCK SYSTEM


< WIRING DIAGRAM >

Connector No.	E28
Connector Name	INTELLIGENT KEY WARNING BUZZER
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	LG	-
3	GR	-

Connector No.	E14
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
42	BR	VCM BAT

Connector No.	E13
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
25	R	AUTO STOP SW
26	P	CAN-CL
27	L	CAN-CH
34	W	HORN RLY CONT

Connector No.	E59
Connector Name	VEHICLE SECURITY HORN
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
2	BY	-

Connector No.	E57
Connector Name	VEHICLE SECURITY HORN
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	G	-

Connector No.	E38
Connector Name	CHARGE PORT LID OPENER ACTUATOR
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	BY	-
3	P	-

AAK1A1985GB

DOOR & LOCK SYSTEM


< WIRING DIAGRAM >

Connector No.	E61
Connector Name	VCM
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
23	R	CHARGE PORT LID OPENER ACTUATOR RELAY
30	W	READY SIGNAL
47	LG	P/N POSITION SIGNAL
48	W	P POSITION SIGNAL

Connector No.	E62
Connector Name	VCM
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
75	L	CAN-H
76	P	CAN-L
93	BR	CHARGE PORT ID OPENER SWITCH

Connector No.	E88
Connector Name	CHARGE PORT LID OPENER ACTUATOR RELAY
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
1	R	-
2	B/Y	-
3	P	-
5	BR	-

Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
13	W	-
20	BR	-
23	LG	-
44	W	-
60	LG	-
61	GR	-
91	Y	-

Connector No.	E107
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	P	-


AAKIA1986GB

A B C D E F G H I J K L M N O P

DLK

DOOR & LOCK SYSTEM

< WIRING DIAGRAM >




AAKIA1987GB

DOOR & LOCK SYSTEM


< WIRING DIAGRAM >

Connector No.	B48
Connector Name	FRONT DOOR SWITCH LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	SB	-

Connector No.	B18
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
9	P	-
10	Y	-
14	L	-
20	GR	-

Connector No.	B17
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	W	-
8	GR	-

Connector No.	B71
Connector Name	REAR DOOR SWITCH LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	LG	-

Connector No.	B53
Connector Name	REAR DOOR SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	R	-

Connector No.	B49
Connector Name	FRONT DOOR SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	BR	-

AAKIA1988GB

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DOOR & LOCK SYSTEM

< WIRING DIAGRAM >

Connector No.	B83
Connector Name	OUTSIDE KEY ANTENNA (REAR BUMPER)
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	W	-
2	B	-

Connector No.	B82
Connector Name	INSIDE KEY ANTENNA (LUGGAGE ROOM)
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	V	-
2	LG	-

Connector No.	B81
Connector Name	INSIDE KEY ANTENNA (REAR SEAT)
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	G	-
2	R	-

Connector No.	D15
Connector Name	FRONT OUTSIDE HANDLE LH (REQUEST SWITCH)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	LG	-
2	B	-

Connector No.	D6
Connector Name	FRONT OUTSIDE HANDLE LH (OUTSIDE KEY ANTENNA)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1	P	-
2	V	-

AAKIA1989GB

DOOR & LOCK SYSTEM

< WIRING DIAGRAM >


Connector No.	D35
Connector Name	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	GND
3	Y	LOCK SW
15	BR	UNLOCK SW


Terminal No.	Color of Wire	Signal Name
4C	SB	-
5C	V	-
13C	B	-
36C	LG	-
37C	R	-
38C	L	-
39C	G	-
40C	P	-
41C	V	-
47C	Y	-
48C	BR	-

Connector No.	D22
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5A	V	-
11A	Y	-
12A	B	-
36A	B	-
37A	P	-
38A	Y	-
39A	LG	-

Connector No.	D102
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	D38
Connector Name	FRONT DOOR LOCK ASSEMBLY LH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	V	-
2	SB	-
3	G	-
4	B	-
5	L	-
6	R	-

AAKIA1990GB

A B C D E F G H I J L M N O P

DLK

DOOR & LOCK SYSTEM

< WIRING DIAGRAM >

Connector No.	D108
Connector Name	FRONT OUTSIDE HANDLE RH (OUTSIDE KEY ANTENNA)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	LG	-
2	Y	-

Connector No.	D107
Connector Name	FRONT DOOR LOCK ACTUATOR RH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
5	V	-
6	Y	-

Connector No.	D104
Connector Name	POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	Y	-
2	BR	-
3	B	-

Connector No.	D204
Connector Name	REAR DOOR LOCK ACTUATOR LH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	V	-
2	G	-

Connector No.	D201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	V	-
8	G	-

Connector No.	D115
Connector Name	FRONT OUTSIDE HANDLE RH (REQUEST SWITCH)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	P	-
2	B	-

AAKIA1991GB

DOOR & LOCK SYSTEM


< WIRING DIAGRAM >

Connector No.	D504
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
9	P	-
10	SB	-
14	L	-
20	GR	-

Connector No.	D304
Connector Name	FRONT DOOR LOCK ACTUATOR RH
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
5	V	-
6	G	-

Connector No.	D301
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	V	-
8	G	-

Connector No.	D562
Connector Name	BACK DOOR LOCK ASSEMBLY
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	GR	-
2	B	-
3	SB	-
4	B	-

Connector No.	D555
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8	P	-
9	L	-
10	SB	-
12	GR	-

Connector No.	D505
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8	P	-
9	L	-
10	SB	-
12	GR	-

AAKIA1992GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK

DOOR & LOCK SYSTEM

< WIRING DIAGRAM >

Connector No.	D563
Connector Name	BACK DOOR OPENER SWITCH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	L	-
2	B	-
3	B	-
4	P	-

AAKIA1993GB

HOMELINK UNIVERSAL TRANSCEIVER


< WIRING DIAGRAM >

HOMELINK UNIVERSAL TRANSCEIVER

Wiring Diagram

INFOID:0000000010119739

HOMELINK UNIVERSAL TRANSCEIVER



A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P


AAKWA0831GB

HOMELINK UNIVERSAL TRANSCEIVER

< WIRING DIAGRAM >


HOMELINK UNIVERSAL TRANSCEIVER - CONNECTORS

Connector No.	M43
Connector Name	JOINT CONNECTOR-M04
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
2	Y	-
5	W	-
9	W	-
12	Y	-

Connector No.	R1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5	B	-
8	B/Y	-
11	B/R	-

Connector No.	M50
Connector Name	JOINT CONNECTOR-CM03
Connector Color	PINK




Terminal No.	Color of Wire	Signal Name
1	B	-
7	B	-

Connector No.	R7
Connector Name	AUTO ANTI-DAZZLING INSIDE MIRROR
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	-	-
2	-	-
3	-	-
4	-	-
5	-	-
6	B/R	IGN
7	-	-
8	B	GND
9	-	-
10	B/Y	IGN

Connector No.	M73
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	B	-
8	Y	-
11	W	-

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000010119740

OVERALL SEQUENCE



A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

DETAILED FLOW

Revision: May 2014

DLK-65

2014 LEAF

JMKIA8652GB

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

1. GET INFORMATION FOR SYMPTOM

1. Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurs).
2. Check operation condition of the function that is malfunctioning.

>> GO TO 2.

2. CHECK DTC

1. Check DTC.
2. Perform the following procedure if DTC is detected.
 - Record DTC and freeze frame data (Print them out using CONSULT.)
 - Erase DTC.
 - Study the relationship between the cause detected by DTC and the symptom described by the customer.
3. Check related service bulletins for information.

Are any symptoms described and any DTC detected?

Symptom is described, DTC is detected>>GO TO 3.

Symptom is described, DTC is not detected>>GO TO 4.

Symptom is not described, DTC is detected>>GO TO 5.

3. CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Also study the normal operation and fail-safe related to the symptom.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5.

4. CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6.

5. PERFORM DTC CONFIRMATION PROCEDURE

Perform DTC CONFIRMATION PROCEDURE for the detected DTC, and then check that DTC is detected again. At this time, always connect CONSULT to the vehicle, and check self diagnostic results in real time.

If two or more DTCs are detected, refer to [BCS-47. "DTC Inspection Priority Chart"](#) (BCM), and determine trouble diagnosis order.

NOTE:

- Freeze frame data is useful if the DTC is not detected.
- Perform Component Function Check if DTC CONFIRMATION PROCEDURE is not included on Service Manual. This simplified check procedure is an effective alternative though DTC cannot be detected during this check.
If the result of Component Function Check is NG, it is the same as the detection of DTC by DTC CONFIRMATION PROCEDURE.

Is DTC detected?

YES >> GO TO 7.

NO >> Check according to [GI-53. "Intermittent Incident"](#).

6. DETECT MALFUNCTIONING SYSTEM BY SYMPTOM DIAGNOSIS

Detect malfunctioning system according to SYMPTOM DIAGNOSIS based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

Is the symptom described?

YES >> GO TO 7.

NO >> Monitor input data from related sensors or check voltage of related module terminals using CONSULT.

7. DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

Inspect according to Diagnostic Procedure of the system.

Is malfunctioning part detected?

YES >> GO TO 8.

NO >> Check according to [GI-53. "Intermittent Incident"](#).

8. REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnostic Procedure again after repair and replacement.
3. Check DTC. If DTC is detected, erase it.

>> GO TO 9.

9. FINAL CHECK

When DTC is detected in step 2, perform DTC CONFIRMATION PROCEDURE again, and then check that the malfunction is repaired securely.

When symptom is described by the customer, refer to confirmed symptom in step 3 or 4, and check that the symptom is not detected.

Is DTC detected and does symptom remain?

YES-1 >> DTC is detected: GO TO 7.

YES-2 >> Symptom remains: GO TO 4.

NO >> Before returning the vehicle to the customer, always erase DTC.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

B2621 INSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

B2621 INSIDE ANTENNA

DTC Logic

INFOID:000000010119741

DTC DETECTION LOGIC

DTC	CONSULT display description	DTC detecting condition	Possible cause
B2621	INSIDE ANTENNA 1	An excessive high or low voltage from inside antenna (instrument center) is sent to BCM.	<ul style="list-style-type: none"> Inside key antenna (instrument center) Harness or connector [Inside key antenna (instrument center) circuit is open or shorted]

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "INSIDE ANT DIAGNOSIS" in "Work support".
3. Perform inside key antenna ("INSIDE ANT DIAGNOSIS") in "Work support" of "INTELLIGENT KEY".
4. Check BCM for DTC.

Is inside key antenna DTC detected?

- YES >> Refer to [DLK-68, "Diagnosis Procedure"](#).
- NO >> Inside key antenna (instrument center) is OK.

Diagnosis Procedure

INFOID:000000010119742

Regarding Wiring Diagram information, refer to [DLK-44, "Wiring Diagram"](#).

1. CHECK INSIDE KEY ANTENNA INPUT SIGNAL 1

1. Turn power switch ON.
2. Check signal between BCM harness connector and ground using oscilloscope.

(+)		(-)	Condition	Signal (Reference value)
BCM				
Connector	Terminal			
M23	84	Ground	When Intelligent Key is in the antenna detection area	<p style="text-align: right; font-size: small;">JMKIA3839GB</p>
	85		When Intelligent Key is not in the antenna detection area	<p style="text-align: right; font-size: small;">JMKIA5951GB</p>

Is the inspection result normal?

B2621 INSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

- YES >> Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).
 NO >> GO TO 2.

2. CHECK INSIDE KEY ANTENNA CIRCUIT

- Turn power switch OFF.
- Disconnect BCM connector and inside key antenna (instrument center) connector.
- Check continuity between BCM harness connector and inside key antenna (instrument center) harness connector.

BCM		Inside key antenna (instrument center)		Continuity
Connector	Terminal	Connector	Terminal	
M23	84	M86	1	Yes
	85		2	

- Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M23	84		No
	85		

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair or replace harness.

3. CHECK INSIDE KEY ANTENNA INPUT SIGNAL 2

- Replace inside key antenna (instrument center). (New antenna or other antenna)
- Connect BCM connector and inside key antenna (instrument center) connector.
- Turn power switch ON.
- Check signal between BCM harness connector and ground using oscilloscope.

(+)		(-)	Condition	Signal (Reference value)
BCM				
Connector	Terminal			
M23	84	Ground	When Intelligent Key is in the antenna detection area	<p style="text-align: right; font-size: small;">JMKIA3839GB</p>
	85		When Intelligent Key is not in the antenna detection area	<p style="text-align: right; font-size: small;">JMKIA5951GB</p>

Is the inspection result normal?

- YES >> Replace inside key antenna (instrument center). Refer to [DLK-205, "INSTRUMENT CENTER : Removal and Installation"](#).
 NO >> Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

B2622 INSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

B2622 INSIDE ANTENNA

DTC Logic

INFOID:000000010119743

DTC DETECTION LOGIC

DTC	CONSULT display description	DTC detecting condition	Possible cause
B2622	INSIDE ANTENNA 2	An excessive high or low voltage from inside antenna (rear seat) is sent to BCM.	<ul style="list-style-type: none"> Inside key antenna (rear seat) Harness or connector [Inside key antenna (rear seat) circuit is open or shorted]

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "INSIDE ANT DIAGNOSIS" in "Work support".
3. Perform inside key antenna ("INSIDE ANT DIAGNOSIS") in "Work support" of "INTELLIGENT KEY".
4. Check BCM for DTC.

Is inside key antenna DTC detected?

- YES >> Refer to [DLK-70, "Diagnosis Procedure"](#).
 NO >> Inside key antenna (rear seat) is OK.

Diagnosis Procedure

INFOID:000000010119744

Regarding Wiring Diagram information, refer to [DLK-44, "Wiring Diagram"](#).

1. CHECK INSIDE KEY ANTENNA INPUT SIGNAL 1

1. Turn power switch ON.
2. Check signal between BCM harness connector and ground using oscilloscope.

(+)		(-)	Condition	Signal (Reference value)
BCM				
Connector	Terminal			
M23	86	Ground	When Intelligent Key is in the antenna detection area	<p style="text-align: right;">JMKIA3839GB</p>
	87		When Intelligent Key is not in the antenna detection area	<p style="text-align: right;">JMKIA5951GB</p>

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).
 NO >> GO TO 2.

B2622 INSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

2. CHECK INSIDE KEY ANTENNA CIRCUIT

1. Turn power switch OFF.
2. Disconnect BCM connector and inside key antenna (rear seat) connector.
3. Check continuity between BCM harness connector and inside key antenna (rear seat) harness connector.

BCM		Inside key antenna (rear seat)		Continuity
Connector	Terminal	Connector	Terminal	
M23	86	B81	1	Yes
	87		2	

4. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M23	86		No
	87		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK INSIDE KEY ANTENNA INPUT SIGNAL 2

1. Replace inside key antenna (rear seat). (New antenna or other antenna)
2. Connect BCM connector and inside key antenna (rear seat) connector.
3. Turn power switch ON.
4. Check signal between BCM harness connector and ground using oscilloscope.

(+) BCM		(-)	Condition	Signal (Reference value)
Connector	Terminal			
M23	86	Ground	When Intelligent Key is in the antenna detection area	<p style="text-align: right; font-size: small;">JMKIA3839GB</p>
	87		When Intelligent Key is not in the antenna detection area	<p style="text-align: right; font-size: small;">JMKIA5951GB</p>

Is the inspection result normal?

YES >> Replace inside key antenna (rear seat). Refer to [DLK-205, "REAR SEAT : Removal and Installation"](#).

NO >> Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

B2623 INSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

B2623 INSIDE ANTENNA

DTC Logic

INFOID:000000010119745

DTC DETECTION LOGIC

DTC	CONSULT display description	DTC detecting condition	Possible cause
B2623	INSIDE ANTENNA 3	An excessive high or low voltage from inside antenna (luggage room) is sent to BCM.	<ul style="list-style-type: none"> Inside key antenna (luggage room) Harness or connector [Inside key antenna (luggage room) circuit is open or shorted]

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "INSIDE ANT DIAGNOSIS" in "Work support".
3. Perform inside key antenna ("INSIDE ANT DIAGNOSIS") in "Work support" of "INTELLIGENT KEY".
4. Check BCM for DTC.

Is inside key antenna DTC detected?

- YES >> Refer to [DLK-72, "Diagnosis Procedure"](#).
- NO >> Inside key antenna (luggage room) is OK.

Diagnosis Procedure

INFOID:000000010119746

Regarding Wiring Diagram information, refer to [DLK-44, "Wiring Diagram"](#).

1. CHECK INSIDE KEY ANTENNA INPUT SIGNAL 1

1. Turn power switch ON.
2. Check signal between BCM harness connector and ground using oscilloscope.

(+) BCM		(-)	Condition	Signal (Reference value)
Connector	Terminal			
M23	88	Ground	When Intelligent Key is in the antenna detection area	<p style="text-align: right; font-size: small;">JMKIA3839GB</p>
	89		When Intelligent Key is not in the antenna detection area	<p style="text-align: right; font-size: small;">JMKIA5951GB</p>

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).
- NO >> GO TO 2.

B2623 INSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

2. CHECK INSIDE KEY ANTENNA CIRCUIT

1. Turn power switch OFF.
2. Disconnect BCM connector and inside key antenna (luggage room) connector.
3. Check continuity between BCM harness connector and inside key antenna (luggage room) harness connector.

BCM		Inside key antenna (luggage room)		Continuity
Connector	Terminal	Connector	Terminal	
M23	88	B82	1	Yes
	89		2	

4. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M23	88		No
	89		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK INSIDE KEY ANTENNA INPUT SIGNAL 2

1. Replace inside key antenna (luggage room). (New antenna or other antenna)
2. Connect BCM connector and inside key antenna (luggage room) connector.
3. Turn power switch ON.
4. Check signal between BCM harness connector and ground using oscilloscope.

(+)		(-)	Condition	Signal (Reference value)
BCM				
Connector	Terminal			
M23	88	Ground	When Intelligent Key is in the antenna detection area	
	89		When Intelligent Key is not in the antenna detection area	

Is the inspection result normal?

YES >> Replace inside key antenna (luggage room). Refer to [DLK-205, "LUGGAGE ROOM : Removal and Installation"](#).

NO >> Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

B2626 OUTSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

B2626 OUTSIDE ANTENNA

DTC Logic

INFOID:000000010119747

DTC DETECTION LOGIC

DTC	CONSULT display description	DTC detecting condition	Possible cause
B2626	OUTSIDE 1 ANTENNA	An excessive high or low voltage from outside key antenna (RH) is sent to BCM.	<ul style="list-style-type: none"> • Outside key antenna (RH) • Harness or connector [Outside key antenna (RH) circuit is open or shorted]

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Disconnect outside key antenna (RH) connector.
2. Perform "Self Diagnostic Result" of "INTELLIGENT KEY" using CONSULT.

Is outside key antenna DTC detected?

- YES >> Refer to [DLK-74, "Diagnosis Procedure"](#).
- NO >> Outside key antenna (RH) is OK.

Diagnosis Procedure

INFOID:000000010119748

Regarding Wiring Diagram information, refer to [DLK-44, "Wiring Diagram"](#).

1. CHECK OUTSIDE KEY ANTENNA INPUT SIGNAL 1

1. Turn power switch OFF.
2. Check signal between BCM harness connector and ground using oscilloscope.

(+)		(-)	Condition	Signal (Reference value)
BCM				
Connector	Terminal			
M23	80 81	Ground	When Intelligent Key is in the antenna detection area (The distance between Intelligent Key and antenna: 80 cm or less)	<p style="text-align: right; font-size: small;">JMK1A5955GB</p>
			When the RH request switch is operated with power switch OFF	<p style="text-align: right; font-size: small;">JMK1A5954GB</p>

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).
- NO >> GO TO 2.

2. CHECK OUTSIDE KEY ANTENNA CIRCUIT

1. Disconnect BCM connector and outside key antenna (RH) connector.

B2626 OUTSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

2. Check continuity between BCM harness connector and outside key antenna (RH) harness connector.

BCM		Outside key antenna (RH)		Continuity
Connector	Terminal	Connector	Terminal	
M23	80	D108	1	Yes
	81		2	

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M23	80		No
	81		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK OUTSIDE KEY ANTENNA INPUT SIGNAL 2

1. Replace outside key antenna (RH). (New antenna or other antenna)
2. Connect BCM connector and outside key antenna (RH) connector.
3. Check signal between BCM harness connector and ground using oscilloscope.

(+)		(-)	Condition	Signal (Reference value)
BCM				
Connector	Terminal			
M23	80	Ground	When Intelligent Key is in the antenna detection area (The distance between Intelligent Key and antenna: 80 cm or less)	<p style="text-align: right; font-size: small;">JMKIA5955GB</p>
	81		When the RH request switch is operated with power switch OFF	<p style="text-align: right; font-size: small;">JMKIA5954GB</p>

Is the inspection result normal?

YES >> Replace front outside handle RH (outside key antenna). Refer to [DLK-207. "PASSENGER SIDE : Removal and Installation"](#).

NO >> Replace BCM. Refer to [BCS-72. "Removal and Installation"](#).

B2627 OUTSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

B2627 OUTSIDE ANTENNA

DTC Logic

INFOID:000000010119749

DTC DETECTION LOGIC

DTC	CONSULT display description	DTC detecting condition	Possible cause
B2627	OUTSIDE 2 ANTENNA	An excessive high or low voltage from outside key antenna (LH) is sent to BCM.	<ul style="list-style-type: none"> • Outside key antenna (LH) • Harness or connector [Outside key antenna (LH) circuit is open or shorted]

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Disconnect outside key antenna (LH) connector.
2. Perform "Self Diagnostic Result" of "INTELLIGENT KEY" using CONSULT.

Is outside key antenna DTC detected?

- YES >> Refer to [DLK-76, "Diagnosis Procedure"](#).
 NO >> Outside key antenna (LH) is OK.

Diagnosis Procedure

INFOID:000000010119750

Regarding Wiring Diagram information, refer to [DLK-44, "Wiring Diagram"](#).

1. CHECK OUTSIDE KEY ANTENNA INPUT SIGNAL 1

1. Turn power switch OFF.
2. Check signal between BCM harness connector and ground using oscilloscope.

(+)		(-)	Condition	Signal (Reference value)
BCM				
Connector	Terminal			
M23	78	Ground	When the LH request switch is operated with power switch OFF	<p style="text-align: right; font-size: small;">JMK1A5955GB</p>
	79		When Intelligent Key is in the antenna detection area (The distance between Intelligent Key and antenna: 80 cm or less)	<p style="text-align: right; font-size: small;">JMK1A5954GB</p>
			When Intelligent Key is not in the antenna detection area (The distance between Intelligent Key and antenna: Approx. 2 m)	<p style="text-align: right; font-size: small;">JMK1A5954GB</p>

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).
 NO >> GO TO 2.

2. CHECK OUTSIDE KEY ANTENNA CIRCUIT

1. Disconnect BCM connector and outside key antenna (LH) connector.

B2627 OUTSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

2. Check continuity between BCM harness connector and outside key antenna (LH) harness connector.

BCM		Outside key antenna (LH)		Continuity
Connector	Terminal	Connector	Terminal	
M23	78	D6	1	Yes
	79		2	

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M23	78		No
	79		



Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK OUTSIDE KEY ANTENNA INPUT SIGNAL 2

1. Replace outside key antenna (LH). (New antenna or other antenna)
2. Connect BCM connector and outside key antenna (LH) connector.
3. Check signal between BCM harness connector and ground using oscilloscope.

(+)		(-)	Condition	Signal (Reference value)
BCM				
Connector	Terminal			
M23	78	Ground	When Intelligent Key is in the antenna detection area (The distance between Intelligent Key and antenna: 80 cm or less)	 <p style="text-align: right; font-size: small;">JMKIA5955GB</p>
	79		When the LH request switch is operated with power switch OFF	 <p style="text-align: right; font-size: small;">JMKIA5954GB</p>

Is the inspection result normal?

YES >> Replace front outside handle LH (outside key antenna). Refer to [DLK-207. "DRIVER SIDE : Removal and Installation"](#).

NO >> Replace BCM. Refer to [BCS-72. "Removal and Installation"](#).

B2628 OUTSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

B2628 OUTSIDE ANTENNA

DTC Logic

INFOID:000000010119751

DTC DETECTION LOGIC

DTC	CONSULT display description	DTC detecting condition	Possible cause
B2628	OUTSIDE 3 ANTENNA	An excessive high or low voltage from outside key antenna (rear bumper) is sent to BCM.	<ul style="list-style-type: none"> • Outside key antenna (rear bumper) • Harness or connector [Outside key antenna (rear bumper) circuit is open or shorted]

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Disconnect outside key antenna (rear bumper) connector.
2. Perform "Self Diagnostic Result" of "INTELLIGENT KEY" using CONSULT.

Is outside key antenna DTC detected?

- YES >> Refer to [DLK-78. "Diagnosis Procedure"](#).
 NO >> Outside key antenna (rear bumper) is OK.



Diagnosis Procedure

INFOID:000000010119752

Regarding Wiring Diagram information, refer to [DLK-44. "Wiring Diagram"](#).

1. CHECK OUTSIDE KEY ANTENNA INPUT SIGNAL 1

1. Turn power switch OFF.
2. Check signal between BCM harness connector and ground using oscilloscope.

(+)		(-)	Condition	Signal (Reference value)
BCM				
Connector	Terminal			
M23	82 83	Ground	When Intelligent Key is in the antenna detection area (The distance between Intelligent Key and antenna: 80 cm or less)	 <p style="text-align: right; font-size: small;">JMK1A5955GB</p>
			When the back door request switch is operated with power switch OFF	 <p style="text-align: right; font-size: small;">JMK1A5954GB</p>

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-72. "Removal and Installation"](#).
 NO >> GO TO 2.

2. CHECK OUTSIDE KEY ANTENNA CIRCUIT

B2628 OUTSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

1. Disconnect BCM connector and outside key antenna (rear bumper) connector.
2. Check continuity between BCM harness connector and outside key antenna (rear bumper) harness connector.

BCM		Outside key antenna (rear bumper)		Continuity
Connector	Terminal	Connector	Terminal	
M23	82	B83	1	Yes
	83		2	

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M23	82		No
	83		



Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK OUTSIDE KEY ANTENNA INPUT SIGNAL 2

1. Replace outside key antenna (rear bumper). (New antenna or other antenna)
2. Connect BCM and outside key antenna (rear bumper) connector.
3. Check signal between BCM harness connector and ground using oscilloscope.

(+)		(-)	Condition	Signal (Reference value)
BCM				
Connector	Terminal			
M23	82	Ground	When the back door request switch is operated with power switch OFF	 <p style="text-align: right; font-size: small;">JMKIA5955GB</p>
	83			 <p style="text-align: right; font-size: small;">JMKIA5954GB</p>

Is the inspection result normal?

YES >> Replace outside key antenna (rear bumper). Refer to [DLK-207, "REAR BUMPER : Removal and Installation"](#).

NO >> Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

BACK DOOR OPENER ACTUATOR

< DTC/CIRCUIT DIAGNOSIS >

BACK DOOR OPENER ACTUATOR

Component Function Check

INFOID:000000010119753

1.CHECK FUNCTION

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "TRUNK/BACK DOOR" in "Active Test".
3. Touch "OPEN" to check that it works normally.

Is the inspection result normal?

- YES >> Back door opener actuator is OK.
NO >> Refer to [DLK-80, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000010119754

Regarding Wiring Diagram information, refer to [DLK-44, "Wiring Diagram"](#).

1.CHECK BACK DOOR OPENER ACTUATOR INPUT SIGNAL

1. Turn power switch OFF.
2. Disconnect back door lock assembly connector.
3. Check voltage between back door lock assembly harness connector and ground.

(+)		(-)	Condition		Voltage (Approx.)
Connector	Terminal				
D562	1	Ground	Back door opener switch	ON	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2.CHECK BACK DOOR OPENER ACTUATOR CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and back door lock assembly harness connector.

BCM		Back door lock assembly		Continuity
Connector	Terminal	Connector	Terminal	
M29	53	D562	1	Yes

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M29	53		No

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).
NO >> Repair or replace harness.

3.CHECK BACK DOOR OPENER ACTUATOR GROUND CIRCUIT

Check continuity between back door lock assembly harness connector and ground.

BACK DOOR OPENER ACTUATOR

< DTC/CIRCUIT DIAGNOSIS >

Back door lock assembly		Ground	Continuity
Connector	Terminal		Yes
D562	2		

Is the inspection normal?

- YES >> Replace back door lock assembly. Refer to [DLK-200, "DOOR LOCK : Removal and Installation"](#).
- NO >> Repair or replace harness.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

BACK DOOR OPENER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

BACK DOOR OPENER SWITCH

Component Function Check

INFOID:000000010119755

1. CHECK FUNCTION

1. Select "TRUNK" of "BCM" using CONSULT.
2. Select "TR/BD OPEN SW" in "Data Monitor".
3. Check that the function operates normally according to the following conditions:

Monitor item	Condition		Status
TR/BD OPEN SW	Back door opener switch	Pressed	ON
		Released	OFF

Is the inspection result normal?

- YES >> Back door opener switch is OK.
 NO >> Refer to [DLK-82, "Diagnosis Procedure"](#).


Diagnosis Procedure

INFOID:000000010119756

Regarding Wiring Diagram information, refer to [DLK-44, "Wiring Diagram"](#).

1. CHECK BACK DOOR OPENER SWITCH INPUT SIGNAL

1. Turn power switch OFF.
2. Disconnect back door opener switch assembly connector.
3. Check signal between back door opener switch assembly harness connector and ground using oscilloscope.

(+)		(-)	Signal (Reference value)
Connector	Terminal		
D563	1	Ground	 <p>JPMA0012GB</p>

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 2.

2. CHECK BACK DOOR OPENER SWITCH CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and back door opener switch assembly harness connector.

BCM		Back door opener switch assembly		Continuity
Connector	Terminal	Connector	Terminal	
M24	30	D563	1	Yes

3. Check continuity between BCM harness connector and ground.

BACK DOOR OPENER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

BCM		Ground	Continuity
Connector	Terminal		
M24	30		No

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).
 NO >> Repair or replace harness.

3.CHECK BACK DOOR OPENER SWITCH GROUND CIRCUIT

Check continuity between back door opener switch assembly harness connector and ground.

Back door opener switch assembly		Ground	Continuity
Connector	Terminal		
D563	2		Yes

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair or replace harness.

4.CHECK BACK DOOR OPENER SWITCH

Refer to [DLK-83, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> Replace back door opener switch assembly. Refer to [DLK-212, "Removal and Installation"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-53, "Intermittent Incident"](#).

>> Inspection End.

Component Inspection

INFOID:000000010119757

1.CHECK BACK DOOR OPENER SWITCH

1. Turn power switch OFF.
2. Disconnect back door opener switch assembly connector.
3. Check continuity between back door opener switch assembly terminals.

Back door opener switch assembly		Condition	Continuity
Terminal			
1	2	Back door opener switch	Pressed Yes
		Released No	

Is the inspection result normal?

- YES >> Inspection End.
 NO >> Replace back door opener switch assembly. Refer to [DLK-212, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

BACK DOOR REQUEST SWITCH

< DTC/CIRCUIT DIAGNOSIS >

BACK DOOR REQUEST SWITCH

Component Function Check

INFOID:000000010119758

1.CHECK FUNCTION

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "REQ SW-BD/TR" in "Data Monitor".
3. Check that the function operates normally according to the following conditions:

Monitor item	Condition		Status
REQ SW-BD/TR	Back door request switch	Pressed	ON
		Released	OFF

Is the inspection result normal?

- YES >> Back door request switch is OK.
NO >> Refer to [DLK-84, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000010119759

Regarding Wiring Diagram information, refer to [DLK-44, "Wiring Diagram"](#).

1.CHECK BACK DOOR REQUEST SWITCH INPUT SIGNAL

1. Turn power switch OFF.
2. Disconnect back door opener switch assembly connector.
3. Check voltage between back door opener switch assembly harness connector and ground.

(+)		(-)	Voltage (Approx.)
Back door opener switch assembly			
Connector	Terminal		
D563	4	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2.CHECK BACK DOOR REQUEST SWITCH CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and back door opener switch assembly harness connector.

BCM		Back door opener switch assembly		Continuity
Connector	Terminal	Connector	Terminal	
M29	51	D563	4	Yes

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M29	51		No

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).
NO >> Repair harness or connector.

3.CHECK BACK DOOR REQUEST SWITCH GROUND CIRCUIT

BACK DOOR REQUEST SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Check continuity between back door opener switch assembly harness connector and ground.

Back door opener switch assembly		Ground	Continuity
Connector	Terminal		
D563	3		Yes

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK BACK DOOR REQUEST SWITCH

Refer to [DLK-85. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace back door opener switch assembly. Refer to [DLK-212. "Removal and Installation"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-53. "Intermittent Incident"](#).

>> Inspection End.

Component Inspection

INFOID:000000010119760

1.CHECK BACK DOOR REQUEST SWITCH

1. Turn power switch OFF.
2. Disconnect back door opener switch assembly connector.
3. Check continuity between back door opener switch assembly terminals.

Back door opener switch assembly		Condition	Continuity
Terminal			
3	4	Back door request switch	Pressed Yes
			Released No

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace back door opener switch assembly. Refer to [DLK-212. "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

BUZZER (COMBINATION METER)

< DTC/CIRCUIT DIAGNOSIS >

BUZZER (COMBINATION METER)

Component Function Check

INFOID:000000010119761

1.CHECK FUNCTION

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "INSIDE BUZZER" in "Active Test".
3. Touch "Key", "Knob" or "Take Out" to check that it works normally.

Is the inspection result normal?

- YES >> Buzzer (combination meter) is OK.
NO >> Refer to [DLK-86. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000010119762

1.CHECK METER BUZZER CIRCUIT

Refer to [WCS-43. "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace the malfunctioning parts.

2.CHECK INTERMITTENT INCIDENT

Refer to [GI-53. "Intermittent Incident"](#).

>> Inspection End.

DOOR KEY CYLINDER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

DOOR KEY CYLINDER SWITCH

Component Function Check

INFOID:0000000010119763

1. CHECK FUNCTION

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "KEY CYL LK SW", "KEY CYL UN-SW" in "Data Monitor".
3. Check that the function operates normally according to the following conditions:

Monitor item	Condition	Status
KEY CYL LK-SW	Lock	ON
	Neutral / Unlock	OFF
KEY CYL UN-SW	Unlock	ON
	Neutral / Lock	OFF

Is the inspection result normal?

- YES >> Door key cylinder switch is OK.
 NO >> Refer to [DLK-87. "Diagnosis Procedure"](#).


Diagnosis Procedure

INFOID:0000000010119764

Regarding Wiring Diagram information, refer to [DLK-44. "Wiring Diagram"](#).

1. CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL

1. Turn power switch OFF.
2. Disconnect front door lock assembly (LH) connector.
3. Check voltage between front door lock assembly (LH) harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Connector	Terminal		
D38	5	Ground	
	6		

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 2.

2. CHECK DOOR KEY CYLINDER SWITCH SIGNAL CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and front door lock assembly (LH) harness connector.

BCM		Front door lock assembly (LH)		Continuity
Connector	Terminal	Connector	Terminal	
M24	7	D38	5	Yes
	8		6	

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

DOOR KEY CYLINDER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M24	7		No
	8		

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK DOOR KEY CYLINDER SWITCH GROUND CIRCUIT

Check continuity between front door lock assembly (LH) harness connector and ground.

Front door lock assembly (LH)		Ground	Continuity
Connector	Terminal		
D38	4		Yes

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK DOOR KEY CYLINDER SWITCH

Refer to [DLK-88, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace front door lock assembly (LH). Refer to [DLK-193, "OUTSIDE HANDLE : Removal and Installation"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-53, "Intermittent Incident"](#).

>> Inspection End.

Component Inspection

INFOID:0000000010119765

1.CHECK DOOR KEY CYLINDER SWITCH

1. Turn power switch OFF.
2. Disconnect front door lock assembly (LH) terminal.
3. Check continuity between front door lock assembly (LH) terminals.

Front door lock assembly (LH)		Condition	Continuity
Terminal			
5	4	LH door key cylinder	Unlock
			Neutral / Lock
6			Lock
			Neutral / Unlock

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace front door lock assembly (LH). Refer to [DLK-193, "OUTSIDE HANDLE : Removal and Installation"](#).

DOOR LOCK ACTUATOR

< DTC/CIRCUIT DIAGNOSIS >

DOOR LOCK ACTUATOR DRIVER SIDE

DRIVER SIDE : Component Function Check

INFOID:0000000010119766

1.CHECK FUNCTION

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "DOOR LOCK" in "Active Test".
3. Touch "ALL LOCK" or "ALL UNLK" to check that it works normally.

Is the inspection result normal?

YES >> Door lock actuator is OK.

NO >> Refer to [DLK-89, "DRIVER SIDE : Diagnosis Procedure"](#).

DRIVER SIDE : Diagnosis Procedure

INFOID:0000000010119767

Regarding Wiring Diagram information, refer to [DLK-44, "Wiring Diagram"](#).

1.CHECK DOOR LOCK ACTUATOR INPUT SIGNAL

1. Turn power switch OFF.
2. Disconnect front door lock assembly (LH) connector.
3. Check voltage between front door lock assembly (LH) harness connector and ground.

(+)		(-)	Condition	Voltage (Approx.)
Connector	Terminal			
D38	1	Ground	Door lock and unlock switch	Battery voltage
	2		Lock Unlock	

Is the inspection result normal?

YES >> Replace front door lock assembly (LH). Refer to [DLK-192, "DOOR LOCK : Removal and Installation"](#).

NO >> GO TO 2.

2.CHECK DOOR LOCK ACTUATOR CIRCUIT

1. Disconnect BCM connector and all door lock assembly connectors.
2. Check continuity between BCM harness connector and front door lock assembly (LH) harness connector.

BCM		Front door lock assembly (LH)		Continuity
Connector	Terminal	Connector	Terminal	
M25	65	D38	1	Yes
	66		2	

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M25	65		No
	66		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

DOOR LOCK ACTUATOR

< DTC/CIRCUIT DIAGNOSIS >

3. CHECK BCM OUTPUT SIGNAL

1. Connect BCM connector.
2. Check voltage between BCM harness connector and ground.

(+)		(-)	Condition	Voltage (Approx.)	
BCM					
Connector	Terminal				
M25	65	Ground	Door lock and unlock switch	Lock	Battery voltage
	66			Unlock	

Is the inspection result normal?

- YES >> Check for internal short of each door lock actuator.
 NO >> Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

PASSENGER SIDE

PASSENGER SIDE : Component Function Check

INFOID:000000010119768

1. CHECK FUNCTION

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "DOOR LOCK" in "Active Test".
3. Check that the function operates normally according to the following conditions:

Monitor item		Status	
DOOR LOCK	ALL LOCK	Door lock actuators	LOCK
	ALL UNLK		UNLOCK

Is the inspection result normal?

- YES >> Door lock actuator is OK.
 NO >> Refer to [DLK-89, "DRIVER SIDE : Diagnosis Procedure"](#).

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000010119769

Regarding Wiring Diagram information, refer to [DLK-44, "Wiring Diagram"](#).

1. CHECK DOOR LOCK ACTUATOR INPUT SIGNAL

1. Turn power switch OFF.
2. Disconnect front door lock actuator RH connector.
3. Check voltage between front door lock actuator RH harness connector and ground.

(+)		(-)	Condition	Voltage (Approx.)	
Front door lock actuator RH					
Connector	Terminal				
D107	5	Ground	Door lock and unlock switch	Lock	Battery voltage
	6			Unlock	

Is the inspection result normal?

- YES >> Replace front door lock actuator RH. Refer to [DLK-192, "DOOR LOCK : Removal and Installation"](#).
 NO >> GO TO 2.

2. CHECK DOOR LOCK ACTUATOR CIRCUIT

1. Disconnect BCM connector and all door lock assembly connectors.
2. Check continuity between BCM harness connector and front door lock actuator RH harness connector.

DOOR LOCK ACTUATOR

< DTC/CIRCUIT DIAGNOSIS >

BCM		Front door lock actuator RH		Continuity
Connector	Terminal	Connector	Terminal	
M25	59	D107	6	Yes
	65		5	

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M25	59		No
	65		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3.CHECK BCM OUTPUT SIGNAL

1. Connect BCM connector.
2. Check voltage between BCM harness connector and ground.

(+)		(-)	Condition	Voltage (Approx.)
BCM				
Connector	Terminal	Ground	Door lock and unlock switch	Battery voltage
M25	59			
	65	Lock		

Is the inspection result normal?

YES >> Check for internal short of each door lock actuator.

NO >> Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

REAR LH

REAR LH : Component Function Check

INFOID:000000010119770

DLK

1.CHECK FUNCTION

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "DOOR LOCK" in "Active Test".
3. Check that the function operates normally according to the following conditions:

Monitor item		Status	
DOOR LOCK	ALL LOCK	Door lock actuators	LOCK
	ALL UNLK		UNLOCK

Is the inspection result normal?

YES >> Door lock actuator is OK.

NO >> Refer to [DLK-89, "DRIVER SIDE : Diagnosis Procedure"](#).

REAR LH : Diagnosis Procedure

INFOID:000000010119771

Regarding Wiring Diagram information, refer to [DLK-44, "Wiring Diagram"](#).

1.CHECK DOOR LOCK ACTUATOR INPUT SIGNAL

1. Turn power switch OFF.
2. Disconnect rear door lock actuator LH connector.
3. Check voltage between rear door lock actuator LH harness connector and ground.

DOOR LOCK ACTUATOR

< DTC/CIRCUIT DIAGNOSIS >

(+)		(-)	Condition		Voltage (Approx.)
Rear door lock actuator LH					
Connector	Terminal				
D204	1	Ground	Door lock and unlock switch	Lock	Battery voltage
	2			Unlock	

Is the inspection result normal?

YES >> Replace rear door lock actuator LH. Refer to [DLK-196. "DOOR LOCK : Removal and Installation"](#).

NO >> GO TO 2.

2. CHECK DOOR LOCK ACTUATOR CIRCUIT

1. Disconnect BCM connector and all door lock actuator connectors.
2. Check continuity between BCM harness connector and rear door lock actuator LH harness connector.

BCM		Rear door lock actuator LH		Continuity
Connector	Terminal	Connector	Terminal	
M29	55	D204	2	Yes
M25	65		1	

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M29	55		No
M25	65		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK BCM OUTPUT SIGNAL

1. Connect BCM connector.
2. Check voltage between BCM harness connector and ground.

(+)		(-)	Condition		Voltage (Approx.)
BCM					
Connector	Terminal				
M29	55	Ground	Door lock and unlock switch	Unlock	Battery voltage
M25	65			Lock	

Is the inspection result normal?

YES >> Check for internal short of each door lock actuator.

NO >> Replace BCM. Refer to [BCS-72. "Removal and Installation"](#).

REAR RH

REAR RH : Component Function Check

INFOID:000000010119772

1. CHECK FUNCTION

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "DOOR LOCK" in "Active Test".
3. Check that the function operates normally according to the following conditions:

Monitor item		Status	
DOOR LOCK	ALL LOCK	Door lock actuators	LOCK
	ALL UNLK		UNLOCK

DOOR LOCK ACTUATOR

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES >> Door lock actuator is OK.
 NO >> Refer to [DLK-89, "DRIVER SIDE : Diagnosis Procedure"](#).

REAR RH : Diagnosis Procedure

INFOID:0000000010119773

Regarding Wiring Diagram information, refer to [DLK-44, "Wiring Diagram"](#).

1. CHECK DOOR LOCK ACTUATOR INPUT SIGNAL

- Turn power switch OFF.
- Disconnect rear door lock actuator RH connector.
- Check voltage between rear door lock actuator RH harness connector and ground.

(+)		(-)	Condition	Voltage (Approx.)
Connector	Terminal			
D304	5	Ground	Door lock and unlock switch	Lock
	6			Unlock
				Battery voltage

Is the inspection result normal?

- YES >> Replace rear door lock actuator RH. Refer to [DLK-196, "DOOR LOCK : Removal and Installation"](#).
 NO >> GO TO 2.

2. CHECK DOOR LOCK ACTUATOR CIRCUIT

- Disconnect BCM connector and all door lock actuator connectors.
- Check continuity between BCM harness connector and rear door lock actuator RH harness connector.

BCM		Rear door lock actuator RH		Continuity
Connector	Terminal	Connector	Terminal	
M29	55	D304	6	Yes
M25	65		5	

- Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M29	55		No
M25	65		

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair or replace harness.

3. CHECK BCM OUTPUT SIGNAL

- Connect BCM connector.
- Check voltage between BCM harness connector and ground.

(+)		(-)	Condition	Voltage (Approx.)
BCM				
Connector	Terminal	Ground	Door lock and unlock switch	Battery voltage
M29	55			
M25	65			
				Unlock
				Lock

Is the inspection result normal?

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK

DOOR LOCK ACTUATOR

< DTC/CIRCUIT DIAGNOSIS >

- YES >> Check for internal short of each door lock actuator.
- NO >> Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

DOOR LOCK AND UNLOCK SWITCH

< DTC/CIRCUIT DIAGNOSIS >

DOOR LOCK AND UNLOCK SWITCH DRIVER SIDE

DRIVER SIDE : Component Function Check

INFOID:0000000010119774

1. CHECK FUNCTION

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "CDL LOCK SW", "CDL UNLOCK SW" in "Data Monitor".
3. Check that the function operates normally according to the following conditions:

Monitor item	Condition	Status
CDL LOCK SW	Lock	ON
	Unlock	OFF
CDL UNLOCK SW	Lock	OFF
	Unlock	ON

Is the inspection result normal?

- YES >> Door lock and unlock switch is OK.
 NO >> Refer to [DLK-95, "DRIVER SIDE : Diagnosis Procedure"](#).


DRIVER SIDE : Diagnosis Procedure

INFOID:0000000010119775

Regarding Wiring Diagram information, refer to [DLK-44, "Wiring Diagram"](#).

1. CHECK DOOR LOCK AND UNLOCK SWITCH INPUT SIGNAL

1. Turn power switch OFF.
2. Disconnect main power window and door lock/unlock switch connector.
3. Check signal between main power window and door lock/unlock switch harness connector and ground using oscilloscope.

(+)		(-)	Signal (Reference value)
Connector	Terminal		
D35	3	Ground	 <p style="text-align: center;">1.0 - 1.5 V</p>
	15		

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 2.

2. CHECK DOOR LOCK AND UNLOCK SWITCH CIRCUIT

1. Disconnect BCM connector and power window and door lock/unlock switch RH connector.
2. Check continuity between BCM harness connector and main power window and door lock/unlock switch harness connector.

DOOR LOCK AND UNLOCK SWITCH

< DTC/CIRCUIT DIAGNOSIS >

BCM		Main power window and door lock/unlock switch		Continuity
Connector	Terminal	Connector	Terminal	
M24	12	D35	3	Yes
	13		15	

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M24	12		No
	13		

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-72. "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK DOOR LOCK AND UNLOCK SWITCH GROUND

Check continuity between main power window and door lock/unlock switch harness connector and ground.

Main power window and door lock/unlock switch		Ground	Continuity
Connector	Terminal		
D35	1		Yes

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK DOOR LOCK AND UNLOCK SWITCH

Refer to [DLK-96. "DRIVER SIDE : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-61. "Removal and Installation"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-53. "Intermittent Incident"](#).

>> Inspection End.

DRIVER SIDE : Component Inspection

INFOID:000000010119776

1.CHECK DOOR LOCK AND UNLOCK SWITCH

1. Turn power switch OFF.
2. Disconnect main power window and door lock/unlock switch connector.
3. Check continuity between main power window and door lock/unlock switch terminals.

Main power window and door lock/unlock switch		Condition	Continuity	
Terminal				
3	1	Door lock and unlock switch	LOCK	Yes
		UNLOCK	No	
15		LOCK	No	
		UNLOCK	Yes	

Is the inspection result normal?

YES >> Inspection End.

DOOR LOCK AND UNLOCK SWITCH

< DTC/CIRCUIT DIAGNOSIS >

NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-61, "Removal and Installation"](#).

PASSENGER SIDE

PASSENGER SIDE : Component Function Check

INFOID:0000000010119777

1. CHECK FUNCTION

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "CDL LOCK SW", "CDL UNLOCK SW" in "Data Monitor".
3. Check that the function operates normally according to the following conditions:

Monitor item	Condition	Status
CDL LOCK SW	Lock	ON
	Unlock	OFF
CDL UNLOCK SW	Lock	OFF
	Unlock	ON

Is the inspection result normal?

YES >> Door lock and unlock switch is OK.

NO >> Refer to [DLK-97, "PASSENGER SIDE : Diagnosis Procedure"](#).


PASSENGER SIDE : Diagnosis Procedure

INFOID:0000000010119778

Regarding Wiring Diagram information, refer to [DLK-44, "Wiring Diagram"](#).

1. CHECK DOOR LOCK AND UNLOCK SWITCH INPUT SIGNAL

1. Turn power switch OFF.
2. Disconnect power window and door lock/unlock switch RH connector.
3. Check signal between power window and door lock/unlock switch RH harness connector and ground using oscilloscope.

(+)		(-)	Signal (Reference value)
Connector	Terminal		
D104	1	Ground	 <p style="text-align: right; font-size: small;">JFMIA0012GB</p>
	2		

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK DOOR LOCK AND UNLOCK SWITCH CIRCUIT

1. Disconnect BCM connector and main power window and door lock/unlock switch connector.
2. Check continuity between BCM harness connector and power window and door lock/unlock switch RH harness connector.

DOOR LOCK AND UNLOCK SWITCH

< DTC/CIRCUIT DIAGNOSIS >

BCM		Power window and door lock/unlock switch RH		Continuity
Connector	Terminal	Connector	Terminal	
M24	12	D104	1	Yes
	13		2	

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M24	12		No
	13		

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-72. "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK DOOR LOCK AND UNLOCK SWITCH GROUND

Check continuity between power window and door lock/unlock switch RH harness connector and ground.

Power window and door lock/unlock switch RH		Ground	Continuity
Connector	Terminal		
D104	3		Yes

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK DOOR LOCK AND UNLOCK SWITCH

Refer to [DLK-98. "PASSENGER SIDE : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace power window and door lock/unlock switch RH. Refer to [PWC-61. "Removal and Installation"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-53. "Intermittent Incident"](#).

>> Inspection End.

PASSENGER SIDE : Component Inspection

INFOID:000000010119779

1.CHECK DOOR LOCK AND UNLOCK SWITCH

1. Turn power switch OFF.
2. Disconnect power window and door lock/unlock switch RH connector.
3. Check continuity between power window and door lock/unlock switch RH terminals.

Power window and door lock/unlock switch RH		Condition	Continuity	
Terminal				
1	3	Door lock and unlock switch	LOCK	Yes
			UNLOCK	No
2			LOCK	No
			UNLOCK	Yes

Is the inspection result normal?

YES >> Inspection End.

DOOR LOCK AND UNLOCK SWITCH

< DTC/CIRCUIT DIAGNOSIS >

NO >> Replace power window and door lock/unlock switch RH. Refer to [PWC-61. "Removal and Installation"](#).

- A
- B
- C
- D
- E
- F
- G
- H
- I
- J
- DLK**
- L
- M
- N
- O
- P

DOOR REQUEST SWITCH

< DTC/CIRCUIT DIAGNOSIS >

DOOR REQUEST SWITCH

Component Function Check

INFOID:000000010119780

1.CHECK FUNCTION

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "REQ SW-DR", "REQ SW-AS" in "Data Monitor".
3. Check that the function operates normally according to the following conditions:

Monitor item	Condition		Status
REQ SW -DR	LH door request switch	Pressed	ON
		Released	OFF
REQ SW -AS	RH door request switch	Pressed	ON
		Released	OFF

Is the inspection result normal?

- YES >> Door request switch is OK.
NO >> Refer to [DLK-100, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000010119781

Regarding Wiring Diagram information, refer to [DLK-44, "Wiring Diagram"](#).

1.CHECK DOOR REQUEST SWITCH INPUT SIGNAL

1. Turn power switch OFF.
2. Disconnect malfunctioning door request switch connector.
3. Check voltage between malfunctioning door request switch harness connector and ground.

(+)		Terminal	(-)	Voltage (Approx.)
Door request switch				
Connector				
LH	D15	1	Ground	Battery voltage
RH	D115			

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2.CHECK DOOR REQUEST SWITCH CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between malfunctioning door request switch harness connector and BCM harness connector.

Door request switch		Terminal	BCM		Continuity
Connector			Connector	Terminal	
LH	D15	1	M23	75	Yes
RH	D115			100	

3. Check continuity between malfunctioning door request switch harness connector and ground.

DOOR REQUEST SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Door request switch		Terminal	Ground	Continuity
Connector				Continuity
LH	D15	1		No
RH	D115			

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK DOOR REQUEST SWITCH GROUND CIRCUIT

Check continuity between malfunctioning door request switch harness connector and ground.

Door request switch		Terminal	Ground	Continuity
Connector				Continuity
LH	D15	2		Yes
RH	D115			

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK DOOR REQUEST SWITCH

Refer to [DLK-101, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace malfunctioning front outside handle (request switch). Refer to [DLK-193, "OUTSIDE HANDLE : Removal and Installation"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-53, "Intermittent Incident"](#).

>> Inspection End.

Component Inspection

INFOID:000000010119782

DLK

1.CHECK DOOR REQUEST SWITCH

1. Turn power switch OFF.
2. Disconnect malfunctioning door request switch connector.
3. Check continuity between malfunctioning door request switch terminals.

Door request switch		Condition	Continuity
Terminal			
1	2	Door request switch Pressed	Yes
		Released	No

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace malfunctioning Front outside handle (request switch). Refer to [DLK-193, "OUTSIDE HANDLE : Removal and Installation"](#).

DOOR SWITCH

< DTC/CIRCUIT DIAGNOSIS >

DOOR SWITCH

Component Function Check

INFOID:000000010119783

1.CHECK FUNCTION

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "DOOR SW-DR", "DOOR SW-AS", "DOOR SW-RL", "DOOR SW-RR", "DOOR SW-BK" in "Data Monitor".
3. Check that the function operates normally according to the following conditions:

Monitor item	Condition		Status
DOOR SW-DR	Front door LH	Open	ON
		Closed	OFF
DOOR SW-AS	Front door RH	Open	ON
		Closed	OFF
DOOR SW-RL	Rear door LH	Open	ON
		Closed	OFF
DOOR SW-RR	Rear door RH	Open	ON
		Closed	OFF
DOOR SW-BK	Back door	Open	ON
		Closed	OFF

Is the inspection result normal?

- YES >> Door switch is OK.
 NO >> Refer to [DLK-102, "Diagnosis Procedure"](#).


Diagnosis Procedure

INFOID:000000010119784

Regarding Wiring Diagram information, refer to [DLK-44, "Wiring Diagram"](#).

1.CHECK DOOR SWITCH INPUT SIGNAL

1. Turn power switch OFF.
2. Disconnect malfunctioning door switch connector.
3. Check signal between malfunctioning door switch harness connector and ground using oscilloscope.

(+)		Terminal	(-)	Signal (Reference value)
Door switch				
Connector				
Front LH	B48	3	Ground	 <p>PKIB4960J 7.0 - 8.0 V</p>
Front RH	B49			
Rear LH	B71			
Rear RH	B53			
Back door	D562			

Is the inspection result normal?

- YES-1 >> Back door: GO TO 3.
 YES-2 >> Other door: GO TO 4.
 NO >> GO TO 2.

2.CHECK DOOR SWITCH CIRCUIT

DOOR SWITCH

< DTC/CIRCUIT DIAGNOSIS >

1. Disconnect BCM connector.
2. Check continuity between door switch harness connector and BCM harness connector.

Door switch		BCM		Continuity
Connector	Terminal	Connector	Terminal	
Front LH	B48	M29	47	Yes
Front RH	B49		45	
Rear LH	B71		48	
Rear RH	B53		46	
Back door	D562		43	

3. Check continuity between door switch harness connector and ground.

Door switch		Terminal	Ground	Continuity
Connector	Terminal			
Front LH	B48	3	Ground	No
Front RH	B49			
Rear LH	B71			
Rear RH	B53			
Back door	D562			

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK BACK DOOR SWITCH GROUND CIRCUIT

Check continuity between back door lock assembly harness connector and ground.

Back door lock assembly		Ground	Continuity
Connector	Terminal		
D562	4		Yes

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK DOOR SWITCH

Refer to [DLK-103, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace malfunctioning door switch.

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-53, "Intermittent Incident"](#).

>> Inspection End.

Component Inspection

INFOID:000000010119785

1.CHECK DOOR SWITCH

1. Turn power switch OFF.
2. Disconnect malfunctioning door switch connector.
3. Check continuity between door switch terminals.

DOOR SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Door switch			Condition	Continuity	
Terminal					
<ul style="list-style-type: none"> • Front LH • Front RH • Rear LH • Rear RH 	3	Ground part of door switch	Door switch	Pressed	Yes
					Released
Back door		4	Back door lock	Lock	Yes
				Unlock	No

Is the inspection result normal?

- YES >> Inspection End.
 NO >> Replace malfunctioning door switch.

HAZARD FUNCTION

< DTC/CIRCUIT DIAGNOSIS >

HAZARD FUNCTION

Component Function Check

INFOID:000000010119786

1.CHECK FUNCTION

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "FLASHER" in "Active Test".
3. Touch "LH" or "RH" to check that it works normally.

Is the inspection result normal?

YES >> Hazard warning lamp circuit is OK.

NO >> Refer to [DLK-105. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000010119787

1.CHECK HAZARD SWITCH CIRCUIT

Refer to [EXL-112. "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK INTERMITTENT INCIDENT

Refer to [GI-53. "Intermittent Incident"](#).

>> Inspection End.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

INTELLIGENT KEY

< DTC/CIRCUIT DIAGNOSIS >

INTELLIGENT KEY

Component Function Check

INFOID:000000010119788

1.CHECK FUNCTION

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "RKE OPE COUN1" in "Data Monitor".
3. Check that the function operates normally according to the following conditions:

Monitor item	Condition
RKE OPE COUN1	Check that the numerical value is changing while operating on the Intelligent Key.

Is the inspection result normal?

- YES >> Intelligent Key is OK.
NO >> Refer to [DLK-106, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000010119789


1.CHECK INTELLIGENT KEY BATTERY

Check by connecting a resistance (approximately 300 Ω) so that the current value becomes about 10 mA. Refer to [DLK-210, "Removal and Installation"](#).

Standard : Approx. 2.5 - 3.0 V

Is the measurement value within the specification?

- YES >> Replace Intelligent Key.
NO >> Replace Intelligent Key battery.



INTELLIGENT KEY WARNING BUZZER

< DTC/CIRCUIT DIAGNOSIS >

INTELLIGENT KEY WARNING BUZZER

Component Function Check

INFOID:000000010119790

1.CHECK FUNCTION

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "OUTSIDE BUZZER" in "Active Test".
3. Touch "ON" to check that it works normally.

Is the inspection result normal?

- YES >> Intelligent Key warning buzzer is OK.
NO >> Refer to [DLK-107. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000010119791

Regarding Wiring Diagram information, refer to [DLK-44. "Wiring Diagram"](#).

1.CHECK FUSE

1. Turn power switch OFF.
2. Check 10 A fuse, [No. 13, located in fuse block (J/B)].

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Replace the blown fuse after repairing the affected circuit.

2.CHECK INTELLIGENT KEY WARNING BUZZER POWER SUPPLY CIRCUIT

1. Disconnect Intelligent Key warning buzzer connector.
2. Check voltage between Intelligent Key warning buzzer harness connector and ground.

(+)		(-)	Voltage (Approx.)
Intelligent Key warning buzzer			
Connector	Terminal	Ground	Battery voltage
E28	1		

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace harness.

3.CHECK INTELLIGENT KEY WARNING BUZZER CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and Intelligent Key warning buzzer harness connector.

BCM		Intelligent Key warning buzzer		Continuity
Connector	Terminal	Connector	Terminal	
M23	93	E28	3	Yes

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M23	93		No

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace harness.

4.CHECK INTELLIGENT KEY WARNING BUZZER

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK

INTELLIGENT KEY WARNING BUZZER

< DTC/CIRCUIT DIAGNOSIS >

Refer to [DLK-108. "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-72. "Removal and Installation"](#).

NO >> Replace Intelligent Key warning buzzer. Refer to [DLK-208. "Removal and Installation"](#).

Component Inspection

INFOID:000000010119792

1. CHECK INTELLIGENT KEY WARNING BUZZER

1. Turn power switch OFF.
2. Disconnect Intelligent Key warning buzzer connector.
3. Connect battery power supply directly to Intelligent Key warning buzzer terminals and check the operation.

Intelligent Key warning buzzer		Operation
Terminal		
(+)	(-)	
1	3	Buzzer sounds

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace Intelligent Key warning buzzer. Refer to [DLK-208. "Removal and Installation"](#).

REMOTE KEYLESS ENTRY RECEIVER

< DTC/CIRCUIT DIAGNOSIS >

REMOTE KEYLESS ENTRY RECEIVER

Component Function Check

INFOID:000000010119793

1.CHECK FUNCTION

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "RKE OPE COUN1" in "Data Monitor".
3. Check that the function operates normally according to the following conditions:

Monitor item	Condition
RKE OPE COUN1	Checks whether value changes when operating Intelligent Key

Is the inspection result normal?

- YES >> Remote keyless entry receiver is OK.
NO >> Refer to [DLK-109. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000010119794

Regarding Wiring Diagram information, refer to [DLK-44. "Wiring Diagram"](#).

1.CHECK REMOTE KEYLESS ENTRY RECEIVER POWER SUPPLY

1. Turn power switch OFF.
2. Disconnect remote keyless entry receiver connector.
3. Check voltage between remote keyless entry receiver harness connector and ground.

(+)		(-)	Voltage (Approx.)
Connector	Terminal		
M75	1	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2.DETECT MALFUNCTIONING PART

Check the following:

- 10 A fuse (No. 7)
- Harness for open or short between remote keyless entry receiver and battery.

Is the inspection result normal?

- YES >> GO TO 7.
NO >> Repair or replace the malfunctioning parts.

3.CHECK REMOTE KEYLESS ENTRY RECEIVER GROUND CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and remote keyless entry receiver harness connector.

BCM		Remote keyless entry receiver		Continuity
Connector	Terminal	Connector	Terminal	
M24	18	M75	4	Yes

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M24	18		No

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

REMOTE KEYLESS ENTRY RECEIVER

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair or replace harness.

4. CHECK BCM SIGNAL

1. Reconnect BCM connector.
2. Check voltage between remote keyless entry receiver harness connector and ground.

(+)		(-)	Voltage (Approx.)
Remote keyless entry receiver			
Connector	Terminal	Ground	Battery voltage
M75	2		

Is the inspection result normal?

- YES >> GO TO 6.
 NO >> GO TO 5.

5. CHECK REMOTE KEYLESS ENTRY RECEIVER CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and remote keyless entry receiver harness connector.

BCM		Remote keyless entry receiver		Continuity
Connector	Terminal	Connector	Terminal	
M24	38	M75	2	Yes

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M24	38		No

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).
 NO >> Repair or replace harness.

6. CHECK REMOTE KEYLESS ENTRY RECEIVER OUTPUT SIGNAL

1. Reconnect remote keyless entry receiver connector.
2. Check signal between remote keyless entry receiver harness connector and ground using oscilloscope.

(+)		(-)	Condition	Signal (Reference value)
Remote keyless entry receiver				
Connector	Terminal	Ground	Waiting	Battery voltage
M75	2			

JMMIA0572GB

Is the inspection result normal?

- YES >> GO TO 7.
 NO >> Replace remote keyless entry receiver. Refer to [DLK-209, "Removal and Installation"](#).

7. CHECK INTERMITTENT INCIDENT

Refer to [GI-53, "Intermittent Incident"](#).

REMOTE KEYLESS ENTRY RECEIVER

< DTC/CIRCUIT DIAGNOSIS >

>> Inspection End.

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

UNLOCK SENSOR

< DTC/CIRCUIT DIAGNOSIS >

UNLOCK SENSOR

Component Function Check

INFOID:000000010119795

1.CHECK FUNCTION

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "UNLK SEN -DR" in "Data Monitor".
3. Check that the function operates normally according to the following conditions:

Monitor item	Condition		Status
UNLK SEN -DR	Driver side door	Lock	OFF
		Unlock	ON

Is the inspection result normal?

- YES >> Unlock sensor is OK.
 NO >> Refer to [DLK-112. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000010119796

Regarding Wiring Diagram information, refer to [DLK-44. "Wiring Diagram"](#).

1.CHECK BCM OUTPUT SIGNAL

1. Turn power switch OFF.
2. Disconnect front door lock assembly (LH) connector.
3. Check signal between front door lock assembly (LH) harness connector and ground using oscilloscope.

(+)		(-)	Signal (Reference value)
Connector	Terminal		
D38	3	Ground	

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 2.

2.CHECK UNLOCK SENSOR CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and front door lock assembly (LH) harness connector.

BCM		Front door lock assembly (LH)		Continuity
Connector	Terminal	Connector	Terminal	
M24	31	D38	3	Yes

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M24	31		No

UNLOCK SENSOR

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK UNLOCK SENSOR GROUND CIRCUIT

Check continuity between front door lock assembly (LH) harness connector and ground.

Front door lock assembly (LH)		Ground	Continuity
Connector	Terminal		Yes
D38	4		

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK UNLOCK SENSOR

Refer to [DLK-113, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace front door lock assembly (LH). Refer to [DLK-192, "DOOR LOCK : Removal and Installation"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-53, "Intermittent Incident"](#).

>> Inspection End.

Component Inspection

INFOID:000000010119797

1.CHECK UNLOCK SENSOR

1. Turn power switch OFF.
2. Disconnect front door lock assembly (LH) connector.
3. Check continuity between front door lock assembly (LH) terminals.

Front door lock assembly (LH)		Condition	Continuity
Terminal			Yes
3	4	Driver side door	Unlock
			Lock

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace front door lock assembly (LH). Refer to [DLK-192, "DOOR LOCK : Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

INFORMATION DISPLAY

< DTC/CIRCUIT DIAGNOSIS >

INFORMATION DISPLAY

Component Function Check

INFOID:000000010119798

1.CHECK FUNCTION

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "LCD" in "Active Test".
3. Check each warning display on meter display.

Is the inspection result normal?

- YES >> Information display is OK.
NO >> Refer to [DLK-114, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000010119799

1.CHECK COMBINATION METER

Refer to [MWI-48, "Description"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace the malfunctioning parts.

2.CHECK INTERMITTENT INCIDENT

Refer to [GI-53, "Intermittent Incident"](#).

>> Inspection End.

CHARGE PORT LID OPENER RELAY

< DTC/CIRCUIT DIAGNOSIS >

CHARGE PORT LID OPENER RELAY

Diagnosis Procedure

INFOID:0000000010119800

Regarding Wiring Diagram information, refer to [DLK-44. "Wiring Diagram"](#).

1. CHECK CHARGE PORT LID OPENER ACTUATOR RELAY POWER SUPPLY-1

1. Turn power switch OFF.
2. Disconnect charge port lid opener actuator relay.
3. Check the voltage between charge port lid opener actuator relay harness connector and ground.

+		-	Voltage (Approx.)
Charge port lid opener actuator relay			
Connector	Terminal		
E88	5	Ground	12V battery voltage

Is the inspection result normal?

- YES >> GO TO 5.
NO >> GO TO 2.

2. CHECK CHARGE PORT LID OPENER ACTUATOR RELAY POWER SUPPLY-2

Check the voltage between IPDM E/R harness connector and ground.

+		-	Voltage (Approx.)
IPDM E/R			
Connector	Terminal		
E14	42	Ground	12V battery voltage

Is the inspection result normal?

- YES >> GO TO 4.
NO >> GO TO 3.

3. CHECK FUSE

1. Remove 20A fuse #43 from IPDM E/R.
2. Check that the fuse is not blown.

Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-29. "Removal and Installation"](#).
NO >> Replace the fuse after repairing the applicable circuit.

4. CHECK CHARGE PORT LID OPENER ACTUATOR RELAY POWER SUPPLY CIRCUIT

1. Disconnect IPDM E/R harness connector.
2. Check the continuity between IPDM E/R harness connector and charge port lid opener actuator relay harness connector.

+		-		Continuity
IPDM E/R		Charge port lid opener actuator relay		
Connector	Terminal	Connector	Terminal	
E14	42	E88	5	Yes

3. Also check harness for short to ground and short to voltage.

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-53. "Intermittent Incident"](#).
NO >> Repair or replace malfunctioning component.

CHARGE PORT LID OPENER RELAY

< DTC/CIRCUIT DIAGNOSIS >

5. CHARGE PORT LID OPENER ACTUATOR RELAY CONTROL SIGNAL VOLTAGE

Check the voltage between charge port lid opener actuator relay harness connector under the following condition:

+		-	Condition	Voltage (Approx.)
Charge port lid opener actuator relay				
Connector	Terminal			
E88	1	Ground	Immediately after the charge port lid opener switch is pressed.	12V battery voltage

Is the inspection result normal?

YES >> GO TO 8.

NO >> GO TO 6.

6. CHECK CHARGE PORT LID OPENER ACTUATOR RELAY DRIVE CIRCUIT

1. Disconnect VCM harness connector.
2. Check the continuity between VCM harness connector and charge port lid opener actuator relay harness connector.

+		-		Continuity
VCM		Charge port lid opener actuator relay		
Connector	Terminal	Connector	Terminal	
E61	23	E88	1	Yes

3. Also check harness for short to ground and short to voltage.

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace malfunctioning component.

7. CHECK CHARGE PORT LID OPENER SWITCH RELATED CIRCUIT

Check charge port lid opener switch related circuit. Refer to [DLK-120. "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-53. "Intermittent Incident"](#).

NO >> Repair or replace malfunctioning component.

8. CHECK CHARGE PORT LID OPENER ACTUATOR RELAY GROUND CIRCUIT

Check the continuity between charge port lid opener actuator relay harness connector and ground.

+		-	Continuity
Charge port lid opener actuator relay			
Connector	Terminal		
E88	2	Ground	Yes

Is the inspection result normal?

YES >> GO TO 9.

NO >> Repair or replace malfunctioning component.

Component Inspection (Charge Port Lid Opener Actuator Relay)

INFOID:000000010119801

1. CHECK CHARGE PORT LID OPENER ACTUATOR RELAY

1. Turn power switch OFF.
2. Disconnect charge port lid opener actuator relay.

CHARGE PORT LID OPENER RELAY


< DTC/CIRCUIT DIAGNOSIS >

3. Check the continuity between charge port lid opener actuator relay terminals under the following conditions:

Terminals	Conditions	Continuity
3 and 5	12 V direct current supply between terminals 1 and 2	Yes
	No current supply	No

Is the inspection result normal?

- YES >> Inspection End.
 NO >> Replace charge port lid opener actuator relay.



A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

CHARGE PORT LID OPENER

< DTC/CIRCUIT DIAGNOSIS >

CHARGE PORT LID OPENER

Component Function Check

INFOID:000000010119802

1. CHARGE PORT LID OPENER FUNCTION CHECK

1. Close charge port lid.
2. Press charge port lid opener switch.

Does the charge port lid open?

- YES >> Inspection End.
NO >> Proceed to [EVC-395, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000010119803

Regarding Wiring Diagram information, refer to [DLK-44, "Wiring Diagram"](#).

1. CHECK CHARGE PORT LID OPENER ACTUATOR RELAY RELATED CIRCUIT

Check charge port lid opener actuator relay related circuit. Refer to [DLK-115, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace malfunctioning component.

2. CHECK CHARGE PORT LID OPENER ACTUATOR

Check charge port lid opener actuator. Refer to [DLK-119, "Component Inspection \(Charge Port Lid Opener Actuator\)"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Replace charge port lid opener actuator. Refer to [DLK-191, "CHARGE PORT LID OPENER ACTUATOR: Removal and Installation"](#).

3. CHECK CHARGE PORT LID OPENER ACTUATOR CONTROL CIRCUIT

1. Check the continuity between charge port lid opener actuator relay harness connector and charge port lid opener actuator harness connector.

+		-		Continuity
Charge port lid opener actuator relay		Charge port lid opener actuator		
Connector	Terminal	Connector	Terminal	
E88	3	E38	3	Yes

2. Also check harness for short to ground and short to voltage.

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace malfunctioning component.

4. CHECK CHARGE PORT LID OPENER ACTUATOR GROUND CIRCUIT

Check the continuity between charge port lid opener actuator harness connector and ground.

+		-	Continuity
Charge port lid opener actuator relay			
Connector	Terminal		
E88	2	Ground	Yes

Is the inspection result normal?

- YES >> Inspection End.

CHARGE PORT LID OPENER

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair or replace malfunctioning component.

Component Inspection (Charge Port Lid Opener Actuator)

INFOID:0000000010119804

1. CHECK CHARGE PORT LID OPENER ACTUATOR

1. Turn power switch OFF.
2. Remove charge port lid opener actuator. Refer to [DLK-191, "CHARGE PORT LID OPENER ACTUATOR : Removal and Installation"](#).
3. Check the resistance between charge port lid opener actuator connector terminals.

Charge port lid opener actuator		Resistance
+	-	
Terminal		
1	3	1 – 4 Ω

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace charge port lid opener actuator. Refer to [DLK-191, "CHARGE PORT LID OPENER ACTUATOR : Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

CHARGE PORT LID OPENER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

CHARGE PORT LID OPENER SWITCH

Diagnosis Procedure

INFOID:000000010119805

Regarding Wiring Diagram information, refer to [DLK-44, "Wiring Diagram"](#).

1. CHECK CHARGE PORT LID OPENER SWITCH SIGNAL CIRCUIT

1. Disconnect VCM harness connector.
2. Check the continuity between charge port lid opener switch harness connector and VCM harness connector.

+		-		Continuity
Charge port lid opener switch		VCM		
Connector	Terminal	Connector	Terminal	
M93	6	E62	93	Yes

3. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace malfunctioning component.

2. CHECK CHARGE PORT LID OPENER SWITCH GROUND CIRCUIT

Check the continuity between charge port lid opener switch harness connector and ground.

+		-	Continuity
Charge port lid opener switch			
Connector	Terminal		
M93	8	Ground	Yes

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning component.

3. CHECK CHARGE PORT LID OPENER SWITCH

Check charge port lid opener switch. Refer to [DLK-120, "Component Inspection \(Charge Port Lid Opener Switch\)"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace charge port lid opener switch. Refer to [DLK-211, "Removal and Installation"](#).

Component Inspection (Charge Port Lid Opener Switch)

INFOID:000000010119806

1. CHECK CHARGE PORT LID OPENER SWITCH

1. Turn power switch OFF.
2. Disconnect charge port lid opener switch harness connector.
3. Check the continuity between charge port lid opener switch terminals under the following condition:

Terminal	Condition		Continuity
6 – 8	Charge port lid opener switch	Released	No
		Pressed	Yes

Is the inspection result normal?

YES >> Inspection End.

CHARGE PORT LID OPENER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

NO >> Replace charge port lid opener switch. Refer to [DLK-211. "Removal and Installation"](#).

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

HOMELINK UNIVERSAL TRANSCEIVER

< DTC/CIRCUIT DIAGNOSIS >

HOMELINK UNIVERSAL TRANSCEIVER

Component Function Check

INFOID:000000010119807

1.CHECK FUNCTION

Check that system receiver (garage door opener, etc.) operates with original hand-held transmitter.

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Receiver or hand-held transmitter is malfunctioning.

2.CHECK ILLUMINATE

1. Turn power switch OFF.
2. Does red light of transmitter illuminate when any transmitter button is pressed?

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Refer to [DLK-122, "Diagnosis Procedure"](#).

3.CHECK TRANSMITTER

Check transmitter with Tool*.

*:For details, refer to Technical Service Bulletin.

Is the inspection result normal?

- YES >> Receiver or hand-held transmitter malfunction, not vehicle related.
- NO >> Replace auto anti-dazzling inside mirror (HomeLink® Universal Transceiver).

Diagnosis Procedure

INFOID:000000010119808

Regarding Wiring Diagram information, refer to [DLK-44, "Wiring Diagram"](#).

1.CHECK POWER SUPPLY

1. Turn power switch OFF.
2. Disconnect auto anti-dazzling inside mirror (HomeLink® Universal Transceiver) connector.
3. Check voltage between auto anti-dazzling inside mirror (HomeLink® Universal Transceiver) harness connector and ground.

(+)		(-)	Voltage (Approx.)
Auto anti-dazzling inside mirror (HomeLink® Universal Transceiver)			
Connector	Terminal		
R7	6	Ground	Battery voltage
	10		

Is the inspection result normal?

- YES >> GO TO 2.
- NO-1 >> Check 10 A fuse [No. 3, No.13].
- NO-2 >> Harness for open or short between fuse and auto anti-dazzling inside mirror (HomeLink® Universal Transceiver).

2.CHECK GROUND CIRCUIT

Check continuity between auto anti-dazzling inside mirror (HomeLink® Universal Transceiver) harness connector and ground.

HOMELINK UNIVERSAL TRANSCEIVER

< DTC/CIRCUIT DIAGNOSIS >

Auto anti-dazzling inside mirror (HomeLink® Universal Transceiver)		Ground	Continuity
Connector	Terminal		
R7	8		Yes

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3.CHECK INTERMITTENT INCIDENT

Refer to [GI-53, "Intermittent Incident"](#).

>> Inspection End.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

DOOR DOES NOT LOCK/UNLOCK WITH DOOR LOCK AND UNLOCK SWITCH

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

DOOR DOES NOT LOCK/UNLOCK WITH DOOR LOCK AND UNLOCK SWITCH

ALL DOOR

ALL DOOR : Description

INFOID:000000010119809

All doors do not lock/unlock using door lock and unlock switch.

ALL DOOR : Diagnosis Procedure

INFOID:000000010119810

1. CHECK DOOR LOCK AND UNLOCK SWITCH

Check door lock and unlock switch.

Refer to [DLK-95, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK DOOR LOCK ACTUATOR

Check front door lock assembly (LH).

Refer to [DLK-89, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK DOOR SWITCH

Check door switch.

Refer to [DLK-102, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. REPLACE BCM

1. Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

DRIVER SIDE

DRIVER SIDE : Description

INFOID:000000010119811

Driver side door does not lock/unlock using door lock and unlock switch.

DRIVER SIDE : Diagnosis Procedure

INFOID:000000010119812

1. CHECK DOOR LOCK ACTUATOR

Check front door lock assembly (LH).

Refer to [DLK-89, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. REPLACE BCM

1. Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

DOOR DOES NOT LOCK/UNLOCK WITH DOOR LOCK AND UNLOCK SWITCH

< SYMPTOM DIAGNOSIS >

2. Confirm the operation after replacement.

Is the result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-53. "Intermittent Incident"](#).

PASSENGER SIDE

PASSENGER SIDE : Description

INFOID:0000000010119813

Passenger side door does not lock/unlock using door lock and unlock switch.

PASSENGER SIDE : Diagnosis Procedure

INFOID:0000000010119814

1.CHECK DOOR LOCK ACTUATOR

Check front door lock actuator RH.

Refer to [DLK-90. "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.REPLACE BCM

1. Replace BCM. Refer to [BCS-72. "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-53. "Intermittent Incident"](#).

REAR LH

REAR LH : Description

INFOID:0000000010119815

Rear LH side door does not lock/unlock using door lock and unlock switch.

REAR LH : Diagnosis Procedure

INFOID:0000000010119816

1.CHECK DOOR LOCK ACTUATOR

Check rear door lock actuator LH.

Refer to [DLK-91. "REAR LH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.REPLACE BCM

1. Replace BCM. Refer to [BCS-72. "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-53. "Intermittent Incident"](#).

REAR RH

REAR RH : Description

INFOID:0000000010119817

Rear RH side door does not lock/unlock using door lock and unlock switch.

REAR RH : Diagnosis Procedure

INFOID:0000000010119818

1.CHECK DOOR LOCK ACTUATOR

Check rear door lock actuator RH.

Refer to [DLK-92. "REAR RH : Component Function Check"](#).

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

DOOR DOES NOT LOCK/UNLOCK WITH DOOR LOCK AND UNLOCK SWITCH

< SYMPTOM DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.REPLACE BCM

1. Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

DOOR DOES NOT LOCK/UNLOCK WITH DOOR REQUEST SWITCH

< SYMPTOM DIAGNOSIS >

DOOR DOES NOT LOCK/UNLOCK WITH DOOR REQUEST SWITCH ALL DOOR REQUEST SWITCHES

ALL DOOR REQUEST SWITCHES : Description

INFOID:0000000010119819

All doors do not lock/unlock using all door request switches.

ALL DOOR REQUEST SWITCHES : Diagnosis Procedure

INFOID:0000000010119820

1. CHECK REMOTE KEYLESS ENTRY FUNCTION

Check remote keyless entry function.

Does door lock/unlock with Intelligent Key button?

YES >> GO TO 2.

NO >> Refer to [DLK-131, "Diagnosis Procedure"](#).

2. CHECK "LOCK/UNLOCK BY I-KEY" SETTING IN "WORK SUPPORT"

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.

2. Select "LOCK/UNLOCK BY I-KEY" in "Work support".

3. Check "LOCK/UNLOCK BY I-KEY" in "Work support".

Refer to [BCS-20, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Set "LOCK/UNLOCK BY I-KEY" in "Work support".

3. CHECK INSIDE KEY ANTENNA

Check inside key antenna.

• Instrument center: Refer to [DLK-68, "DTC Logic"](#).

• Rear seat: Refer to [DLK-70, "DTC Logic"](#).

• Luggage room: Refer to [DLK-72, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. CHECK OUTSIDE KEY ANTENNA

Check outside key antenna.

• LH: Refer to [DLK-76, "DTC Logic"](#).

• RH: Refer to [DLK-74, "DTC Logic"](#).

• Rear bumper: Refer to [DLK-78, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5. REPLACE BCM

1. Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

DRIVER SIDE DOOR REQUEST SWITCH

DRIVER SIDE DOOR REQUEST SWITCH : Description

INFOID:0000000010119821

All doors do not lock/unlock using LH door request switch.

DRIVER SIDE DOOR REQUEST SWITCH : Diagnosis Procedure

INFOID:0000000010119822

1. CHECK DTC WITH BCM

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

DOOR DOES NOT LOCK/UNLOCK WITH DOOR REQUEST SWITCH

< SYMPTOM DIAGNOSIS >

Check that DTC is not detected with BCM.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refer to [BCS-48, "DTC Index"](#).

2. CHECK LH DOOR REQUEST SWITCH

Check LH door request switch.

Refer to [DLK-84, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK OUTSIDE KEY ANTENNA

Check outside key antenna (LH).

Refer to [DLK-76, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. REPLACE BCM

1. Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

PASSENGER SIDE DOOR REQUEST SWITCH

PASSENGER SIDE DOOR REQUEST SWITCH : Description

INFOID:000000010119823

All doors do not lock/unlock using RH door request switch.

PASSENGER SIDE DOOR REQUEST SWITCH : Diagnosis Procedure

INFOID:000000010119824

1. CHECK RH DOOR REQUEST SWITCH

Check RH door request switch.

Refer to [DLK-84, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK OUTSIDE KEY ANTENNA

Check outside key antenna (RH).

Refer to [DLK-74, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. REPLACE BCM

1. Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

BACK DOOR REQUEST SWITCH

DOOR DOES NOT LOCK/UNLOCK WITH DOOR REQUEST SWITCH

< SYMPTOM DIAGNOSIS >

BACK DOOR REQUEST SWITCH : Description

INFOID:000000010119825

All doors do not lock/unlock using back door request switch.

BACK DOOR REQUEST SWITCH : Diagnosis Procedure

INFOID:000000010119826

1.CHECK BACK DOOR REQUEST SWITCH

Check back door request switch.

Refer to [DLK-84, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK OUTSIDE KEY ANTENNA

Check outside key antenna (rear bumper).

Refer to [BCS-48, "DTC Index"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.REPLACE BCM

1. Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

DOOR DOES NOT LOCK/UNLOCK WITH DOOR KEY CYLINDER OPERATION

< SYMPTOM DIAGNOSIS >

DOOR DOES NOT LOCK/UNLOCK WITH DOOR KEY CYLINDER OPERATION

Diagnosis Procedure

INFOID:000000010119827

1. CHECK POWER DOOR LOCK OPERATION

Check power door lock operation.

Does door lock/unlock with door lock and unlock switch?

YES >> GO TO 2.

NO >> Refer to [DLK-95, "DRIVER SIDE : Component Function Check"](#).

2. CHECK DOOR KEY CYLINDER SWITCH

Check door key cylinder switch.

Refer to [DLK-87, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. REPLACE BCM

1. Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

DOOR DOES NOT LOCK/UNLOCK WITH INTELLIGENT KEY

< SYMPTOM DIAGNOSIS >

DOOR DOES NOT LOCK/UNLOCK WITH INTELLIGENT KEY

Diagnosis Procedure

INFOID:000000010119828

1.CHECK DTC WITH BCM

Check that DTC is not detected with BCM.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refer to [BCS-48, "DTC Index"](#).

2.CHECK POWER DOOR LOCK OPERATION

Check door lock/unlock using door lock and unlock switch.

Does door lock/unlock using door lock and unlock switch?

YES >> GO TO 3.

NO >> Refer to [DLK-95, "DRIVER SIDE : Component Function Check"](#).

3.CHECK REMOTE KEYLESS ENTRY RECEIVER

Check remote keyless entry receiver.

Refer to [DLK-109, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4.CHECK INTELLIGENT KEY

Check Intelligent Key.

Refer to [DLK-106, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5.REPLACE BCM

1. Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

POWER POSITION WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

POWER POSITION WARNING DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000010119829

1. CHECK DTC WITH BCM

Check that DTC is not detected with BCM.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refer to [BCS-48, "DTC Index"](#).

2. CHECK POWER DOOR LOCK OPERATION

Check power door lock operation.

Does door lock/unlock with driver side door lock knob and door key cylinder?

YES >> GO TO 3.

NO >> Refer to [DLK-22, "System Description"](#).

3. CHECK DOOR SWITCH

Check door switch.

Refer to [DLK-102, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. CHECK COMBINATION METER BUZZER

Check combination meter buzzer.

Refer to [DLK-86, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5. REPLACE BCM

1. Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

SELECTIVE UNLOCK FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

SELECTIVE UNLOCK FUNCTION DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000010119830

1. CHECK "DOOR LOCK-UNLOCK SET" SETTING IN "WORK SUPPORT"

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "DOOR LOCK-UNLOCK SET" in "Work support".
3. Check "DOOR LOCK-UNLOCK SET" in "Work support"
Refer to [BCS-15, "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

Is the inspection result normal?

- YES >> GO TO 2
NO >> Set "DOOR LOCK-UNLOCK SET" in "Work support".

2. REPLACE BCM

1. Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).
2. Confirm the operation after replacement.

Is the result normal?

- YES >> Inspection End.
NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

BACK DOOR DOES NOT OPEN

< SYMPTOM DIAGNOSIS >

BACK DOOR DOES NOT OPEN

Diagnosis Procedure

INFOID:000000010119831

1. CHECK DTC WITH BCM

Check that DTC is not detected with BCM.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refer to [BCS-48, "DTC Index"](#).

2. CHECK BACK DOOR OPENER SWITCH

Check back door opener switch.

Refer to [DLK-82, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK BACK DOOR OPENER ACTUATOR

Check back door opener actuator.

Refer to [DLK-80, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. CHECK VEHICLE SPEED SIGNAL

Check vehicle speed signal.

Refer to [MWI-65, "DTC Index"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5. REPLACE BCM

1. Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

AUTO DOOR LOCK OPERATION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

AUTO DOOR LOCK OPERATION DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000010119832

1. CHECK "AUTO LOCK SET" SETTING IN "WORK SUPPORT"

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "AUTO LOCK SET" in "Work support".
3. Check "AUTO LOCK SET" in "Work support".
Refer to [BCS-20. "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)".](#)

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Set "AUTO LOCK SET" setting in "Work support".

2. REPLACE BCM

1. Replace BCM. Refer to [BCS-72. "Removal and Installation".](#)
2. Confirm the operation after replacement.

Is the result normal?

- YES >> Inspection End.
NO >> Check intermittent incident. Refer to [GI-53. "Intermittent Incident".](#)

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

VEHICLE SPEED SENSING AUTO LOCK OPERATION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

VEHICLE SPEED SENSING AUTO LOCK OPERATION DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000010119833

1. CHECK "AUTOMATIC LOCK/UNLOCK SELECT" SETTING IN "WORK SUPPORT"

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "AUTOMATIC LOCK/UNLOCK SELECT" in "Work support".
3. Check "AUTOMATIC LOCK/UNLOCK SELECT" in "Work support".
Refer to [BCS-15, "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Set "AUTOMATIC LOCK/UNLOCK SELECT" in "Work support".

2. CHECK "AUTOMATIC DOOR LOCK SELECT" SETTING IN "WORK SUPPORT"

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "AUTOMATIC DOOR LOCK SELECT" in "Work support".
3. Check "AUTOMATIC DOOR LOCK SELECT" in "Work support".
Refer to [BCS-15, "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Set "AUTOMATIC DOOR LOCK SELECT" in "Work support".

3. REPLACE BCM

1. Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).
2. Confirm the operation after replacement.

Is the result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

POWER SWITCH OFF INTERLOCK DOOR UNLOCK FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

POWER SWITCH OFF INTERLOCK DOOR UNLOCK FUNCTION DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000010119834

1. CHECK "AUTOMATIC LOCK/UNLOCK SELECT" SETTING IN "WORK SUPPORT"

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "AUTOMATIC LOCK/UNLOCK SELECT" in "Work support".
3. Check "AUTOMATIC LOCK/UNLOCK SELECT" in "Work support".
Refer to [BCS-15, "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Set "AUTOMATIC LOCK/UNLOCK SELECT" in "Work support".

2. CHECK "AUTOMATIC DOOR UNLOCK SELECT" SETTING IN "WORK SUPPORT"

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "AUTOMATIC DOOR UNLOCK SELECT" in "Work support".
3. Check "AUTOMATIC DOOR UNLOCK SELECT" in "Work support".
Refer to [BCS-15, "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Set "AUTOMATIC DOOR UNLOCK SELECT" in "Work support".

3. REPLACE BCM

1. Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).
2. Confirm the operation after replacement.

Is the result normal?

- YES >> Inspection End.
NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

P POSITION INTERLOCK DOOR LOCK/UNLOCK FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

P POSITION INTERLOCK DOOR LOCK/UNLOCK FUNCTION DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000010119835

1. CHECK "AUTOMATIC LOCK/UNLOCK SELECT" SETTING IN "WORK SUPPORT"

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "AUTOMATIC LOCK/UNLOCK SELECT" in "Work support".
3. Check "AUTOMATIC LOCK/UNLOCK SELECT" in "Work support".
Refer to [BCS-15. "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Set "AUTOMATIC LOCK/UNLOCK SELECT" in "Work support".

2. CHECK "AUTOMATIC DOOR LOCK SELECT" SETTING IN "WORK SUPPORT"

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "AUTOMATIC DOOR LOCK SELECT" in "Work support".
3. Check "AUTOMATIC DOOR LOCK SELECT" in "Work support".
Refer to [BCS-15. "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Set "AUTOMATIC DOOR LOCK SELECT" in "Work support".

3. CHECK "AUTOMATIC DOOR UNLOCK SELECT" SETTING IN "WORK SUPPORT"

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "AUTOMATIC DOOR UNLOCK SELECT" in "Work support".
3. Check "AUTOMATIC DOOR UNLOCK SELECT" in "Work support".
Refer to [BCS-15. "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Set "AUTOMATIC DOOR UNLOCK SELECT" in "Work support".

4. REPLACE BCM

1. Replace BCM. Refer to [BCS-72. "Removal and Installation"](#).
2. Confirm the operation after replacement.

Is the result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-53. "Intermittent Incident"](#).

HAZARD AND BUZZER REMINDER DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

HAZARD AND BUZZER REMINDER DOES NOT OPERATE

Diagnosis Procedure

INFOID:0000000010119836

1. CHECK DTC WITH BCM AND COMBINATION METER

Check that DTC is not detected with BCM and combination meter.

Is the inspection result normal?

YES >> GO TO 2.

NO-1 >> Refer to [BCS-48, "DTC Index"](#). (BCM)

NO-2 >> Refer to [MWI-65, "DTC Index"](#). (Combination meter)

2. CHECK "HAZARD ANSWER BACK" SETTING IN "WORK SUPPORT"

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.

2. Select "HAZARD ANSWER BACK" in "Work support".

3. Check the "HAZARD ANSWER BACK" in "Work support".

Refer to [BCS-20, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Set "HAZARD ANSWER BACK" in "Work support".

3. CHECK "ANS BACK I-KEY LOCK" SETTING IN "WORK SUPPORT"

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.

2. Select "ANS BACK I-KEY LOCK" in "Work support".

3. Check the "ANS BACK I-KEY LOCK" in "Work support".

Refer to [BCS-20, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Set "ANS BACK I-KEY LOCK" in "Work support".

4. CHECK "ANS BACK I-KEY UNLOCK" SETTING IN "WORK SUPPORT"

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.

2. Select "ANS BACK I-KEY UNLOCK" in "Work support".

3. Check the "ANS BACK I-KEY UNLOCK" in "Work support".

Refer to [BCS-20, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Set "ANS BACK I-KEY UNLOCK" in "Work support".

5. CHECK HAZARD FUNCTION

Check hazard function.

Refer to [DLK-105, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the malfunctioning parts.

6. CHECK INTELLIGENT KEY WARNING BUZZER

Check Intelligent Key warning buzzer.

Refer to [DLK-107, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace the malfunctioning parts.

7. REPLACE BCM

1. Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> Inspection End.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

HAZARD AND BUZZER REMINDER DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

KEY REMINDER FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

KEY REMINDER FUNCTION DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000010119837

1.CHECK DTC WITH BCM

Check that DTC is not detected with BCM.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refer to [BCS-48, "DTC Index"](#).

2.CHECK "ANTI KEY LOCK IN FUNCTI" SETTING IN "WORK SUPPORT"

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.

2. Select "ANTI KEY LOCK IN FUNCTI" in "Work support".

3. Check "ANTI KEY LOCK IN FUNCTI" in "Work support".

Refer to [BCS-20, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Set "ANTI KEY LOCK IN FUNCTI" in "Work support".

3.CHECK DOOR SWITCH

Check door switch.

Refer to [DLK-102, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4.CHECK INSIDE KEY ANTENNA

Check inside key antenna.

• Instrument center: Refer to [DLK-68, "DTC Logic"](#).

• Rear seat: Refer to [DLK-70, "DTC Logic"](#).

• Luggage room: Refer to [DLK-72, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5.CHECK UNLOCK SENSOR

Check unlock sensor.

Refer to [DLK-112, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the malfunctioning parts.

6.REPLACE BCM

1. Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

OFF POSITION WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

OFF POSITION WARNING DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000010119838

1. CHECK DTC WITH BCM AND COMBINATION METER

Check that DTC is not detected with BCM and combination meter.

Is the inspection result normal?

- YES >> GO TO 2.
- NO-1 >> Refer to [BCS-48, "DTC Index"](#). (BCM)
- NO-2 >> Refer to [MWI-65, "DTC Index"](#). (Combination meter)

2. CHECK COMBINATION METER BUZZER

Check combination meter buzzer.

Refer to [DLK-86, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace the malfunctioning parts.

3. CHECK INTELLIGENT KEY WARNING BUZZER

Check Intelligent Key warning buzzer.

Refer to [DLK-107, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair or replace the malfunctioning parts.

4. CHECK DOOR SWITCH

Check front door switch (LH).

Refer to [DLK-102, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Repair or replace the malfunctioning parts.

5. REPLACE BCM

1. Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).
2. Confirm the operation after replacement.

Is the result normal?

- YES >> Inspection End.
- NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

TAKE AWAY WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

TAKE AWAY WARNING DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000010119839

1. CHECK DTC WITH BCM AND COMBINATION METER

Check that DTC is not detected with BCM and combination meter.

Is the inspection result normal?

YES >> GO TO 2.

NO-1 >> Refer to [BCS-48, "DTC Index"](#). (BCM)

NO-2 >> Refer to [MWI-65, "DTC Index"](#). (Combination meter)

2. CHECK COMBINATION METER BUZZER

Check combination meter buzzer.

Refer to [DLK-107, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK INFORMATION DISPLAY

Check information display.

Refer to [DLK-114, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. CHECK INTELLIGENT KEY WARNING BUZZER

Check Intelligent Key warning buzzer.

Refer to [DLK-107, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5. CHECK DOOR SWITCH

Check door switch.

Refer to [DLK-102, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the malfunctioning parts.

6. CHECK INSIDE KEY ANTENNA

Check inside key antenna.

• Instrument center: Refer to [DLK-68, "DTC Logic"](#).

• Rear seat: Refer to [DLK-70, "DTC Logic"](#).

• Luggage room: Refer to [DLK-72, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace the malfunctioning parts.

7. REPLACE BCM

1. Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

INTELLIGENT KEY LOW BATTERY WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

INTELLIGENT KEY LOW BATTERY WARNING DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000010119840

1. CHECK DTC WITH BCM AND COMBINATION METER

Check that DTC is not detected with BCM and combination meter.

Is the inspection result normal?

- YES >> GO TO 2.
- NO-1 >> Refer to [BCS-48, "DTC Index"](#). (BCM)
- NO-2 >> Refer to [MWI-65, "DTC Index"](#). (Combination meter)

2. CHECK "LO- BATT OF KEY FOB WARN" SETTING IN "WORK SUPPORT"

1. Select "INTELLIGENT KEY" of "BCM".
2. Select "LO- BATT OF KEY FOB WARN" in "Work support".
3. Check "LO- BATT OF KEY FOB WARN" in "Work support".
Refer to [BCS-20, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)"](#).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Set "LO- BATT OF KEY FOB WARN" in "Work support".

3. CHECK INTELLIGENT KEY

Check Intelligent Key.
Refer to [DLK-106, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair or replace the malfunctioning parts.

4. CHECK INFORMATION DISPLAY

Check information display.
Refer to [DLK-114, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Repair or replace the malfunctioning parts.

5. CHECK INSIDE KEY ANTENNA

Check inside key antenna.

- Instrument center: Refer to [DLK-68, "DTC Logic"](#).
- Rear seat: Refer to [DLK-70, "DTC Logic"](#).
- Luggage room: Refer to [DLK-72, "DTC Logic"](#).

Is the inspection result normal?

- YES >> GO TO 6.
- NO >> Repair or replace the malfunctioning parts.

6. REPLACE BCM

1. Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).
2. Confirm the operation after replacement.

Is the result normal?

- YES >> Inspection End.
- NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

DOOR LOCK OPERATION WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

DOOR LOCK OPERATION WARNING DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000010119841

1.CHECK DOOR LOCK FUNCTION

Check door lock function.

Does door lock/unlock using door request switch?

YES >> GO TO 2.

NO >> Refer to [DLK-100, "Component Function Check"](#).

2.CHECK INTELLIGENT KEY WARNING BUZZER

Check Intelligent Key warning buzzer.

Refer to [DLK-107, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.REPLACE BCM

1. Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

KEY ID WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

KEY ID WARNING DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000010119842

1. CHECK DTC WITH BCM AND COMBINATION METER

Check that DTC is not detected with BCM and combination meter.

Is the inspection result normal?

- YES >> GO TO 2.
- NO-1 >> Refer to [BCS-48, "DTC Index"](#). (BCM)
- NO-2 >> Refer to [MWI-65, "DTC Index"](#). (Combination meter)

2. CHECK INTELLIGENT KEY

Check Intelligent Key.

Refer to [DLK-106, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace the malfunctioning parts.

3. CHECK INFORMATION DISPLAY

Check information display.

Refer to [DLK-114, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair or replace the malfunctioning parts.

4. CHECK INSIDE KEY ANTENNA

Check inside key antenna.

- Instrument center: Refer to [DLK-68, "DTC Logic"](#).
- Rear seat: Refer to [DLK-70, "DTC Logic"](#).
- Luggage room: Refer to [DLK-72, "DTC Logic"](#).

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Repair or replace the malfunctioning parts.

5. REPLACE BCM

1. Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).
2. Confirm the operation after replacement.

Is the result normal?

- YES >> Inspection End.
- NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

HOMELINK UNIVERSAL TRANSCEIVER DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

HOMELINK UNIVERSAL TRANSCEIVER DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000010119843

1. CHECK HOMELINK® UNIVERSAL TRANSCEIVER

Check HomeLink® Universal Transceiver.

Refer to [DLK-122, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. REPLACE AUTO ANTI-DAZZLING INSIDE MIRROR

Replace auto anti-dazzling inside mirror.

Refer to [MIR-19, "Removal and Installation"](#).

Is the result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK


SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

SQUEAK AND RATTLE TROUBLE DIAGNOSES

Work Flow

INFOID:000000010119844



SBT842

CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any customer's comments; refer to [DLK-152, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, be sure to diagnose and repair the noise that the customer is concerned about. This can be accomplished by test driving the vehicle with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak —(Like tennis shoes on a clean floor)
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces = higher pitch noise/softer surfaces = lower pitch noises/edge to surface = chirping.
- Creak—(Like walking on an old wooden floor)
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle—(Like shaking a baby rattle)
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock —(Like a knock on a door)
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick—(Like a clock second hand)
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump—(Heavy, muffled knock noise)
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz—(Like a bumble bee)
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending upon the person. A noise that you may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

DUPLICATE THE NOISE AND TEST DRIVE

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when you confirm the repair.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
 - 2) Tap or push/pull around the area where the noise appears to be coming from.
 - 3) Rev the engine.
 - 4) Use a floor jack to recreate vehicle "twist".
 - 5) At idle, apply engine load (electrical load, half-clutch on M/T model, drive position on CVT and A/T models).
 - 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.
- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
 - If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

CHECK RELATED SERVICE BULLETINS

After verifying the customer concern or symptom, check ASIST for Technical Service Bulletins (TSBs) related to that concern or symptom.

If a TSB relates to the symptom, follow the procedure to repair the noise.

LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Chassis Ear: J-39570, Engine Ear: J-39565 and mechanic's stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
 - removing the components in the area that you suspect the noise is coming from.
Do not use too much force when removing clips and fasteners, otherwise clips and fasteners can be broken or lost during the repair, resulting in the creation of new noise.
 - tapping or pushing/pulling the component that you suspect is causing the noise.
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
 - feeling for a vibration with your hand by touching the component(s) that you suspect is (are) causing the noise.
 - placing a piece of paper between components that you suspect are causing the noise.
 - looking for loose components and contact marks.Refer to [DLK-149, "Generic Squeak and Rattle Troubleshooting"](#).

REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
 - separate components by repositioning or loosening and retightening the component, if possible.
 - insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. A NISSAN Squeak and Rattle Kit (J-50397) is available through your authorized NISSAN Parts Department.

CAUTION:

Do not use excessive force as many components are constructed of plastic and may be damaged.

NOTE:

- Always check with the Parts Department for the latest parts information.
- The materials contained in the NISSAN Squeak and Rattle Kit (J-50397) are listed on the inside cover of the kit; and can each be ordered separately as needed.
- The following materials not found in the kit can also be used to repair squeaks and rattles.
 - SILICONE GREASE: Use instead of UHMW tape that will be visible or does not fit. The silicone grease will only last a few months.
 - SILICONE SPRAY: Use when grease cannot be applied.
 - DUCT TAPE: Use to eliminate movement.

CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

Generic Squeak and Rattle Troubleshooting

INFOID:000000010119845

Refer to Table of Contents for specific component removal and installation information.

INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

1. Cluster lid A and the instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar finisher
4. Instrument panel to windshield
5. Instrument panel pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicone spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

CAUTION:

Do not use silicone spray to isolate a squeak or rattle. If you saturate the area with silicone, you will not be able to recheck the repair.

CENTER CONSOLE

Components to pay attention to include:

1. Shift selector assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

DOORS

Pay attention to the:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. You can usually insulate the areas with felt cloth tape or insulator foam blocks from the NISSAN Squeak and Rattle Kit (J-50397) to repair the noise.

TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the owner.

In addition look for:

1. Trunk lid bumpers out of adjustment
2. Trunk lid striker out of adjustment
3. The trunk lid torsion bars knocking together
4. A loose license plate or bracket

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

SUNROOF/HEADLINING

Noises in the sunroof/headlining area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sun visor shaft shaking in the holder
3. Front or rear windshield touching headlining and squeaking

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

OVERHEAD CONSOLE (FRONT AND REAR)

Overhead console noises are often caused by the console panel clips not being engaged correctly. Most of these incidents are repaired by pushing up on the console at the clip locations until the clips engage.

In addition look for:

1. Loose harness or harness connectors.
2. Front console map/reading lamp lens loose.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

3. Loose screws at console attachment points.

SEATS

When isolating seat noise it's important to note the position the seat is in and the load placed on the seat when the noise is present. These conditions should be duplicated when verifying and isolating the cause of the noise.

Cause of seat noise include:

1. Headrest rods and holder
2. A squeak between the seat pad cushion and frame
3. The rear seatback lock and bracket

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

Causes of transmitted underhood noise include:

1. Any component installed to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator installation pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

These noises can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine rpm or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting, securing, or insulating the component causing the noise.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

Diagnostic Worksheet

INFOID:000000010119846





Dear Customer:

We are concerned about your satisfaction with your vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your vehicle right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service advisor or technician to ensure we confirm the noise you are hearing.

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to page 2 of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET - page 2

Briefly describe the location where the noise occurs:

II. WHEN DOES IT OCCUR? (please check the boxes that apply)

- | | |
|---|--|
| <input type="checkbox"/> Anytime | <input type="checkbox"/> After sitting out in the rain |
| <input type="checkbox"/> 1st time in the morning | <input type="checkbox"/> When it is raining or wet |
| <input type="checkbox"/> Only when it is cold outside | <input type="checkbox"/> Dry or dusty conditions |
| <input type="checkbox"/> Only when it is hot outside | <input type="checkbox"/> Other: |

III. WHEN DRIVING:

- Through driveways
- Over rough roads
- Over speed bumps
- Only about ____ mph
- On acceleration
- Coming to a stop
- On turns: left, right or either (circle)
- With passengers or cargo
- Other: _____
- After driving ____ miles or ____ minutes

IV. WHAT TYPE OF NOISE

- Squeak (like tennis shoes on a clean floor)
- Creak (like walking on an old wooden floor)
- Rattle (like shaking a baby rattle)
- Knock (like a knock at the door)
- Tick (like a clock second hand)
- Thump (heavy muffled knock noise)
- Buzz (like a bumble bee)

TO BE COMPLETED BY DEALERSHIP PERSONNEL

Test Drive Notes:

	YES	NO	Initials of person performing
Vehicle test driven with customer	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise verified on test drive	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise source located and repaired	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Follow up test drive performed to confirm repair	<input type="checkbox"/>	<input type="checkbox"/>	_____

VIN: _____ Customer Name _____
W.O.# _____ Date: _____

This form must be attached to Work Order

LATA0071E

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

HOOD


< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION

HOOD

Exploded View

INFOID:000000010119847



- | | | |
|------------------------|--------------------|--------------------------------|
| 1. Hood cover (LH) | 2. Hood cover (RH) | 3. Hood assembly |
| 4. Hood insulator | 5. Grommet | 6. Hood support rod |
| 7. Hood front seal | 8. Clamp | 9. Hood lock secondary control |
| 10. Hood bumper rubber | 11. Hood hinge | ○ Pawl |
- △ Clip ■ Grease ■ L Sealing point with locking sealant

HOOD ASSEMBLY

HOOD ASSEMBLY : Removal and Installation

INFOID:000000010119848

CAUTION:

- Operate with two workers, because of its heavy weight.
- Use protective tape or shop cloths to protect surrounding components from damage during removal and installation.

REMOVAL

1. Support the hood assembly using a suitable tool.

WARNING:

Bodily injury may occur if hood assembly is not supported properly when removing hood assembly.

2. Remove hood hinge nuts and hood assembly.

HOOD

< REMOVAL AND INSTALLATION >

INSTALLATION


Installation is in the reverse order of removal.

CAUTION:

- After installation, apply touch-up paint (body color) to the heads of the hood hinge nuts.
- After installation, perform hood assembly adjustment procedure. Refer to [DLK-155. "HOOD ASSEMBLY : Adjustment"](#).

HOOD ASSEMBLY : Adjustment

INFOID:000000010119849



1. Hood assembly
4. Hood lock assembly

2. Hood bumper rubber
5. Charge port lid

3. Hood hinge
6. Front bumper fascia

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

HOOD

< REMOVAL AND INSTALLATION >

7. Front combination lamp

8. Front side maker lamp

9. Front fender

 Grease

Check the clearance and surface height between the hood and each part by visual inspection and tactile feel. If the clearance and surface height are out of specification, adjust them according to the procedures shown below.

Unit: mm (in)

Portion	Section	Item	Measurement	Standard	Parallelism	Equality
Hood – Charge port lid	A – A	G	Clearance	5.0 ± 2.7 (0.20 ± 0.11)	1.9 (0.07)	2.0 (0.08)
		H	Surface height	1.0 ± 2.0 (0.04 ± 0.08)	1.9 (0.07)	2.0 (0.08)
Hood – Charge port lid	B – B	J	Clearance	5.0 ± 2.7 (0.20 ± 0.11)	—	2.9 (0.11)
Hood – Front bumper fascia	C – C	K	Clearance	5.0 ± 2.7 (0.20 ± 0.11)	2.0 (0.08)	2.0 (0.08)
		M	Surface height	1.0 ± 2.0 (0.04 ± 0.08)	—	1.0 (0.04)
Hood – Front combination lamp	D – D	N	Clearance	4.0 ± 2.5 (0.16 ± 0.10)	1.9 (0.07)	2.9 (0.11)
Hood – Front side marker lamp	E – E	O	Clearance	4.0 ± 2.5 (0.16 ± 0.10)	1.9 (0.07)	2.9 (0.11)
Hood – Front fender	F – F	P	Clearance	3.5 ± 1.0 (0.14 ± 0.04)	1.0 (0.04)	1.5 (0.06)

FITTING ADJUSTMENT

1. Remove the radiator upper grille. Refer to [DLK-165, "RADIATOR UPPER GRILLE : Removal and Installation"](#).
2. Remove the hood lock assembly. Refer to [DLK-187, "HOOD LOCK : Removal and Installation"](#).
3. Adjust the surface height of hood assembly, charge port lid assembly and front bumper fascia according to the specified value, by rotating the hood bumper rubber.
4. Position the hood lock assembly and engage hood striker. Check hood lock assembly and hood striker for looseness.
5. Move hood lock assembly laterally until the center of hood striker and hood lock assembly are vertical when viewed from the front.
6. After adjustment, tighten hood lock bolts to specified torque.
7. Open hood and rotate hood bumper rubber counterclockwise between half a turn and three-quarters of a turn.
8. Check that secondary latch is securely engaged with secondary striker (charge port bracket) from the dead load of the hood assembly.
9. Check the the primary latch is securely engaged with primary striker when hood assembly is closed free-fall from approximately 200 mm (7.874 in) height.
10. Install the radiator upper grille. Refer to [DLK-165, "RADIATOR UPPER GRILLE : Removal and Installation"](#).

HOOD HINGE

HOOD HINGE : Removal and Installation

INFOID:000000010119850

REMOVAL

1. Remove hood assembly. Refer to [DLK-154, "HOOD ASSEMBLY : Removal and Installation"](#).
2. Remove front fender. Refer to [DLK-168, "Removal and Installation"](#).
3. Remove hood hinge bolts, and then remove hood hinge.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:


- After installation, perform hood assembly adjustment procedure. Refer to [DLK-155, "HOOD ASSEMBLY : Adjustment"](#).
- After installation, apply touch-up paint (body color) to the head of the hood hinge bolts and nuts.

HOOD

< REMOVAL AND INSTALLATION >

- Check hood hinge rotating part for poor lubrication. If necessary, apply a suitable multi-purpose grease.

← : Grease point



HOOD SUPPORT ROD

HOOD SUPPORT ROD : Removal and Installation

INFOID:000000010119851

REMOVAL

1. Support the hood assembly using a suitable tool.

WARNING:

Bodily injury may occur if hood assembly is not properly supported when removing hood assembly.

2. Pull hood support rod from grommet and remove.

INSTALLATION

Installation is in the reverse order of removal.


HOOD COVER

HOOD COVER : Removal and Installation

INFOID:000000010119852


REMOVAL

1. Remove hood cover nuts.
2. Apply protective tape (A) on the hood assembly to protect the painted surface from damage.



3. Release the hood cover clips using a suitable tool (A) and remove.

△ : Clip



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P


CHARGE PORT LID

< REMOVAL AND INSTALLATION >

CHARGE PORT LID

Exploded View

INFOID:000000010119853



- | | | |
|-----------------------------------|--------------------------------------|-----------------------------|
| 1. Charge port lid cover assembly | 2. Charge port lid seal | 3. Charge port lid assembly |
| 4. Charge port lid lock cable | 5. Charge port lid actuator assembly | 6. Charge port lid |
| 7. Charge port lid lock | 8. Charge port lid rear cover | △ Clip |

CHARGE PORT LID ASSEMBLY

CHARGE PORT LID ASSEMBLY : Removal and Installation

INFOID:000000010119854

REMOVAL

1. Remove the charge port lid nuts and charge port lid.
2. Remove the front camera, if necessary. Refer to [AV-503. "Removal and Installation"](#).

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:


After installation, perform charge port lid assembly fitting adjustment. Refer to [DLK-159. "CHARGE PORT LID ASSEMBLY : Adjustment"](#).

CHARGE PORT LID

< REMOVAL AND INSTALLATION >

CHARGE PORT LID ASSEMBLY : Adjustment

INFOID:000000010119855



- 1. Hood assembly
- 2. Charge port lid assembly
- 3. Front bumper fascia
- 4. Charge port lid lock

Check the clearance and the surface height between charge port lid and each part by visual inspection and tactile feel. If the clearance and the surface height are out of specification, adjust them according to the adjustment procedure.

Unit: mm (in)

Portion	Section	Item	Measurement	Standard	Parallelism
Charge port lid – Hood	A – A	E	Clearance	5.0 ± 2.7 (0.20 ± 0.11)	1.9 (0.07)
		F	Surface height	1.0 ± 2.0 (0.04 ± 0.08)	1.9 (0.07)
Charge port lid – Hood	B – B	G	Clearance	5.0 ± 2.7 (0.20 ± 0.11)	2.9 (0.11)
Charge port lid – Front bumper fascia	C – C	H	Clearance	2.6 ± 1.2 (0.10 ± 0.05)	1.9 (0.07)
		J	Surface height	1.5 ± 1.5 (0.06 ± 0.06)	1.9 (0.07)
Charge port lid – Front bumper fascia	D – D	K	Clearance	3.3 ± 1.2 (0.13 ± 0.05)	1.9 (0.07)
		M	Surface height	3.5 ± 1.5 (0.14 ± 0.06)	1.9 (0.07)

FITTING ADJUSTMENT PROCEDURE

1. Remove charge port cover. Refer to [DLK-160. "CHARGE PORT COVER : Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

CHARGE PORT LID

< REMOVAL AND INSTALLATION >

2. Remove charge port lid lock.
3. Loosen charge port lid assembly nuts.
4. Adjust the clearance of charge port lid assembly, hood assembly and front bumper fascia according to the specified value, by moving charge port lid assembly.
5. Tighten charge port lid.
6. Temporarily tighten charge port lid lock.
7. Adjust the surface height of charge port lid assembly, hood assembly and front bumper fascia according to the specified value, by moving charge port lid lock.
8. After adjustment, tighten charge port lid lock bolts.
9. Install charge port cover. Refer to [DLK-160, "CHARGE PORT COVER : Removal and Installation"](#).

CHARGE PORT LID HINGE ASSEMBLY

CHARGE PORT LID HINGE ASSEMBLY : Removal and Installation

INFOID:000000010119856

REMOVAL

1. Remove front bumper fascia. Refer to [EXT-13, "Removal and Installation"](#).
2. Remove charge port lid lock assembly. Refer to [DLK-190, "CHARGE PORT LID LOCK : Removal and Installation"](#).
3. Release the charge port rear cover clips using a suitable tool and remove.
4. Remove charge port lid hinge bolts and charge port lid hinge assembly.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

After installation, perform charge port lid assembly fitting adjustment. Refer to [DLK-159, "CHARGE PORT LID ASSEMBLY : Adjustment"](#).

CHARGE PORT COVER

CHARGE PORT COVER : Removal and Installation

INFOID:000000010119857

REMOVAL

1. Remove the charge port lid. Refer to [DLK-158, "CHARGE PORT LID ASSEMBLY : Removal and Installation"](#).
2. Remove the radiator upper grille. Refer to [DLK-165, "RADIATOR UPPER GRILLE : Removal and Installation"](#).
3. Release the charge port cover clips using a suitable tool and remove.
4. Release the charge port lid seal clips using a suitable tool and remove from charge port cover, if necessary.

INSTALLATION

Installation is in the reverse order of removal.


RADIATOR CORE SUPPORT

< REMOVAL AND INSTALLATION >

RADIATOR CORE SUPPORT

Exploded View

INFOID:000000010119858



- | | | |
|-------------------------------------|--------------------------------|------------------------|
| 1. Radiator upper grille | 2. Radiator core support upper | 3. Charge port bracket |
| 4. Radiator core support lower stay | 5. Radiator core support lower | 6. Air guide (RH) |
| 7. Air guide (LH) | | |


●, ▲, ■: Indicates that the part is connected at points with same symbol in actual vehicle.

RADIATOR CORE SUPPORT UPPER

RADIATOR CORE SUPPORT UPPER : Removal and Installation

INFOID:000000010119859

DANGER:

 Since hybrid vehicles and electric vehicles contain a high voltage battery, there is the risk of electric shock, electric leakage, or similar accidents if the high voltage component and vehicle are handled incorrectly. Be sure to follow the correct work procedures when performing inspection and maintenance.

WARNING:

- Be sure to remove the service plug in order to disconnect the high voltage circuits before performing inspection or maintenance of high voltage system harnesses and parts.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK

RADIATOR CORE SUPPORT

< REMOVAL AND INSTALLATION >

- The removed service plug must always be carried in a pocket of the responsible worker or placed in the tool box during the procedure to prevent the plug from being connected by mistake.
- Be sure to wear insulating protective equipment consisting of glove, shoes, face shield and glasses before beginning work on the high voltage system.
- Never allow workers other than the responsible person to touch the vehicle containing high voltage parts. To keep others from touching the high voltage parts, these parts must be covered with an insulating sheet except when using them.
- Refer to [GI-34, "High Voltage Precautions"](#).

CAUTION:

Never bring the vehicle into the READY status with the service plug removed unless otherwise instructed in the Service Manual. A malfunction may occur if this is not observed.


REMOVAL

WARNING:

Disconnect the high voltage. Refer to [GI-33, "How to Disconnect High Voltage"](#).

1. Check voltage in high voltage circuit. (Check that condenser are discharged.)
 - a. Lift up the vehicle and remove the Li-ion battery under covers. Refer to [EVB-181, "Exploded View"](#).
 - b. Disconnect high voltage connector from front side of Li-ion battery. Refer to [EVB-181, "Removal and Installation"](#).
 - c. Measure voltage between high voltage harness terminals.

DANGER:

 Always use protective equipment as touching high voltage components without using them will cause electrocution. (where high voltage might remain/is present on terminals.)




Standard

: 5 V or less


CAUTION:

For voltage measurements, use a tester which can measure to 500V or higher.

2. Remove front bumper fascia, energy absorber and apron bracket. Refer to [EXT-13, "Removal and Installation"](#).
3. Remove hood lock assembly. Refer to [DLK-187, "HOOD LOCK : Removal and Installation"](#).
4. Remove air guide (RH) clips (A) and washer tank inlet clip (B).



JSA1A1362ZZ




JMK1A6499ZZ


RADIATOR CORE SUPPORT

< REMOVAL AND INSTALLATION >

5. Remove reservoir tank bolts (A), air guide (LH) clip (B) and degas tank bolt (C).



6. Remove harness fixing clips (A).



7. Disconnect quick charge port connector. Refer to [VC-128, "Removal and Installation"](#).
8. Disconnect normal charge port connector. Refer to [VC-135, "Removal and Installation"](#).
9. Remove upper mounting bolts of charge port bracket.
10. Remove lower mounting nuts and bolt of radiator core support lower stay.
11. Move charge port bracket and radiator core support lower stay.
12. Support hood assembly using a suitable tool.

WARNING:

Injury may occur if hood assembly is not supported with appropriate material when removing hood assembly.

13. Remove radiator core support upper bolts and radiator core support upper.

INSTALLATION


Installation is in the reverse order of removal.

RADIATOR CORE SUPPORT LOWER

RADIATOR CORE SUPPORT LOWER : Removal and Installation

INFOID:000000010119860

DANGER:

 Since hybrid vehicles and electric vehicles contain a high voltage battery, there is the risk of electric shock, electric leakage, or similar accidents if the high voltage component and vehicle are handled incorrectly. Be sure to follow the correct work procedures when performing inspection and maintenance.

WARNING:

- Be sure to remove the service plug in order to disconnect the high voltage circuits before performing inspection or maintenance of high voltage system harnesses and parts.
- The removed service plug must always be carried in a pocket of the responsible worker or placed in the tool box during the procedure to prevent the plug from being connected by mistake.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

RADIATOR CORE SUPPORT

< REMOVAL AND INSTALLATION >

- Be sure to wear insulating protective equipment consisting of glove, shoes, face shield and glasses before beginning work on the high voltage system.
- Never allow workers other than the responsible person to touch the vehicle containing high voltage parts. To keep others from touching the high voltage parts, these parts must be covered with an insulating sheet except when using them.
- Refer to [GI-34, "High Voltage Precautions"](#).

CAUTION:

Never bring the vehicle into the READY status with the service plug removed unless otherwise instructed in the Service Manual. A malfunction may occur if this is not observed.


REMOVAL

WARNING:

Disconnect the high voltage. Refer to [GI-33, "How to Disconnect High Voltage"](#).

1. Check voltage in high voltage circuit. (Check that condenser are discharged.)
 - a. Lift up the vehicle and remove the Li-ion battery under covers. refer to [EVB-181, "Exploded View"](#).
 - b. Disconnect high voltage connector from front side of Li-ion battery. Refer to [EVB-181, "Removal and Installation"](#).
 - c. Measure voltage between high voltage harness terminals.

DANGER:

 Always use protective equipment as touching high voltage components without using them will cause electrocution. (where high voltage might remain/is present on terminals.)





Standard

: 5 V or less

CAUTION:

For voltage measurements, use a tester which can measure to 500V or higher.


2. Remove front bumper fascia, energy absorber, and apron bracket. Refer to [EXT-13, "Removal and Installation"](#).
3. Remove reservoir tank bolts (A).



RADIATOR CORE SUPPORT

< REMOVAL AND INSTALLATION >


4. Remove harness fixing clips (A).



5. Disconnect quick charge port connector. Refer to [VC-128. "Removal and Installation"](#).
6. Disconnect normal charge port connector. Refer to [VC-135. "Removal and Installation"](#).
7. Remove lower mounting bolts of hood lock assembly.
8. Remove upper mounting bolts of charge port bracket.
9. Remove lower mounting nuts and bolt of radiator core support lower stay.
10. Move charge port bracket and radiator core support lower stay.
11. Remove air guides (LH/RH).
12. Use belts (A) to suspend radiator and condenser to prevent them from falling.

CAUTION:

Do not damage radiator and condenser.



13. Remove front fixing clip of fender protector (LH/RH) from radiator core support lower.
14. Remove radiator core support lower bolts and radiator core support lower.

INSTALLATION

Installation is in the reverse order of removal.

RADIATOR UPPER GRILLE

RADIATOR UPPER GRILLE : Removal and Installation

INFOID:000000010119861

REMOVAL

Remove radiator upper grille clips and radiator upper grille.

INSTALLATION


Installation in the reverse order of removal.

CHARGE PORT BRACKET

CHARGE PORT BRACKET : Removal and Installation

INFOID:000000010119862

DANGER:

 Since hybrid vehicles and electric vehicles contain a high voltage battery, there is the risk of electric shock, electric leakage, or similar accidents if the high voltage component and vehicle are

RADIATOR CORE SUPPORT

< REMOVAL AND INSTALLATION >

handled incorrectly. Be sure to follow the correct work procedures when performing inspection and maintenance.

WARNING:

- Be sure to remove the service plug in order to disconnect the high voltage circuits before performing inspection or maintenance of high voltage system harnesses and parts.
- The removed service plug must always be carried in a pocket of the responsible worker or placed in the tool box during the procedure to prevent the plug from being connected by mistake.
- Be sure to wear insulating protective equipment consisting of glove, shoes, face shield and glasses before beginning work on the high voltage system.
- Never allow workers other than the responsible person to touch the vehicle containing high voltage parts. To keep others from touching the high voltage parts, these parts must be covered with an insulating sheet except when using them.
- Refer to [GI-34, "High Voltage Precautions"](#).

CAUTION:

Never bring the vehicle into the READY status with the service plug removed unless otherwise instructed in the Service Manual. A malfunction may occur if this is not observed.


REMOVAL

WARNING:

Disconnect the high voltage. Refer to [GI-33, "How to Disconnect High Voltage"](#).

1. Check voltage in high voltage circuit. (Check that condenser are discharged.)
 - a. Lift up the vehicle and remove the Li-ion battery under covers. refer to [EVB-181, "Exploded View"](#).
 - b. Disconnect high voltage connector from front side of Li-ion battery. Refer to [EVB-181, "Removal and Installation"](#).
 - c. Measure voltage between high voltage harness terminals.


DANGER:

 Always use protective equipment as touching high voltage components without using them will cause electrocution. (where high voltage might remain/is present on terminals.)



Standard


: 5 V or less



CAUTION:

For voltage measurements, use a tester which can measure to 500V or higher.

2. Remove charge port hinge assembly. Refer to [DLK-160, "CHARGE PORT LID HINGE ASSEMBLY : Removal and Installation"](#).
3. Remove quick charge port. Refer to [VC-128, "Removal and Installation"](#).
4. Remove normal charge port. Refer to [VC-135, "Removal and Installation"](#).
5. Remove crash zone sensor. Refer to [SR-33, "Removal and Installation"](#).
6. Remove harness fixing clips (A).



7. Remove charge port bracket bolts and nuts and charge port bracket.

RADIATOR CORE SUPPORT

< REMOVAL AND INSTALLATION >

INSTALLATION

Installation is in the reverse order of removal.

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P


FRONT FENDER

< REMOVAL AND INSTALLATION >

FRONT FENDER

Exploded View

INFOID:000000010119863



- | | | |
|---------------------------------|--------------------------|----------------------|
| 1. Rivet | 2. Front fender cover | 3. Front fender seal |
| 4. Front fender upper insulator | 5. Front fender assembly | 6. Front fender seal |
| 7. Front fender stiffener | ⊙ Pawl | ⇐ Front |

Removal and Installation

INFOID:000000010119864


CAUTION:

Use shop cloths to protect the body from damage during removal and installation.

REMOVAL

1. Remove fender protector. Refer to [EXT-21, "FENDER PROTECTOR : Removal and Installation"](#).
2. Remove front fender cover. Refer to [DLK-168, "Exploded View"](#).
3. Remove front combination lamp. Refer to [EXL-130, "Removal and Installation"](#).
4. Remove the front fender bolts.
5. Apply protective tape (A) on the body side outer panel to protect the painted surface from damage.

⇐: Front




FRONT FENDER

< REMOVAL AND INSTALLATION >

6. Using a suitable tool (A), remove front fender stiffener (2) from the vehicle body while carefully pulling the portion of front fender (1) toward vehicle outside.

↔: Front



7. Remove the front fender assembly.

CAUTION:

Use care when removing the front fender. The front fender baffle foam adheres the front fender to the body side outer. Carefully release the baffle foam or damage to the front fender may occur.

INSTALLATION

Note the following items, and install in the reverse order of removal.

CAUTION:

- After installation, apply touch-up paint (body color) to the head of front fender bolts.
- After installation, adjust the following parts:
 - Hood assembly: Refer to [DLK-155, "HOOD ASSEMBLY : Adjustment"](#).
 - Front door: Refer to [DLK-172, "DOOR ASSEMBLY : Adjustment"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK


FRONT DOOR

< REMOVAL AND INSTALLATION >

FRONT DOOR

Exploded View

INFOID:000000010119865



- | | | |
|-----------------------|-----------------------|--------------------|
| 1. Front door panel | 2. Grommet | 3. Bolt |
| 4. Door striker | 5. Bumper rubber | 6. Door check link |
| 7. Door hinge (lower) | 8. Door hinge (upper) | ⊗ Do not reuse |

 Grease

DOOR ASSEMBLY

DOOR ASSEMBLY : Removal and Installation

INFOID:000000010119866

WARNING:

Before servicing, push power switch OFF, disconnect 12V battery negative terminal and wait five minutes or more. Refer to [DLK-10, "Precaution for Removing 12V Battery"](#).

CAUTION:

- Use two people when removing or installing the front door due to its heavy weight.
- When removing and installing front door assembly, support front door with a suitable tool.


REMOVAL

1. Disconnect the negative battery terminal and wait at least five minutes. Refer to [PG-89, "Removal and Installation"](#).

FRONT DOOR

< REMOVAL AND INSTALLATION >

2. Disconnect the front door harness connector.



3. Remove door check link bolt (body side).
4. Remove door hinge nuts (door side) and front door assembly.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Apply anticorrosive agent to the mounting surface of the front door.
- After installation, check the front door open/close and lock/unlock operation.
- After installation, perform the front door adjustment procedure. Refer to [DLK-172, "DOOR ASSEMBLY : Adjustment"](#).
- After installation, apply touch-up paint (body color) to the head of the door hinge nuts.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P


DLK



FRONT DOOR

< REMOVAL AND INSTALLATION >

DOOR ASSEMBLY : Adjustment

INFOID:000000010119867



- | | | |
|---------------------|----------------------------|----------------------------|
| 1. Front fender | 2. Front door | 3. Rear door |
| 4. Body side outer | 5. Door striker | 6. Bolt |
| 7. Front door hinge | 8. Rear door hinge (upper) | 9. Rear door hinge (lower) |
-  Do not reuse
  Grease

Check the clearance and surface height between front door and each part by visual inspection and tactile feel. If the clearance and the surface height are out of specification, adjust them according to the adjustment procedure.

Unit: mm (in)

Portion	Section	Measurement	Standard
Front fender – Front door	A – A	Clearance	4.0 ± 1.0 (0.16 ± 0.04)
		Surface height	0.0 ± 1.0 (0.00 ± 0.04)
Front door – Rear door	B – B	Clearance	4.2 ± 1.0 (0.17 ± 0.04)
		Surface height	0.0 ± 1.0 (0.00 ± 0.04)
Front door – Rear door	C – C	Clearance	4.0 ± 1.0 (0.16 ± 0.04)
		Surface height	0.0 ± 1.0 (0.00 ± 0.04)

FITTING ADJUSTMENT PROCEDURE

FRONT DOOR

< REMOVAL AND INSTALLATION >

1. Remove front fender. Refer to [DLK-168, "Removal and Installation"](#).
2. Loosen door hinge nuts (door side).
3. Adjust the surface height of front door according to the specifications provided.
4. Temporarily tighten door hinge nuts (door side).
5. Loosen door hinge bolts (body side).
6. Raise front door at rear end to adjust clearance of the front door according to the specifications provided.
7. Tighten bolts and nuts to the specified torque.
CAUTION:
 - After installation, apply touch-up paint (body color) to the head of door hinge bolts and nuts.
 - Check door hinge rotating part for poor lubrication. If necessary, apply a suitable multi-purpose grease.
8. Install front fender. Refer to refer to [DLK-168, "Removal and Installation"](#).

DOOR STRIKER ADJUSTMENT

Adjust door striker so that it becomes parallel with door lock insertion direction.

DOOR STRIKER

DOOR STRIKER : Removal and Installation

INFOID:000000010119868

REMOVAL

Remove the door striker bolts and door striker.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Do not reuse door striker bolts.
- After installation, perform the front door adjustment procedure. Refer to [DLK-172, "DOOR ASSEMBLY : Adjustment"](#).
- After installation, apply touch-up paint (body color) to the head of the door striker bolts.

DOOR HINGE

DOOR HINGE : Removal and Installation

INFOID:000000010119869

WARNING:

Before servicing, push power switch OFF, disconnect 12V battery negative terminal and wait 5 minutes or more. Refer to [DLK-10, "Precaution for Removing 12V Battery"](#).

CAUTION:

- Use two people when removing or installing the front door due to its heavy weight.
- When removing and installing front door assembly, support door using a suitable tool.

REMOVAL

1. Disconnect the negative and positive battery terminals and wait at least three minutes.
2. Remove front fender. Refer to [DLK-168, "Removal and Installation"](#).
3. Remove front door assembly. Refer to [DLK-170, "DOOR ASSEMBLY : Removal and Installation"](#).
4. Remove front door hinge mounting bolts (body side), and then remove front door hinge.

INSTALLATION

Note the following items, and install in the reverse order of removal.

CAUTION:

- Apply anticorrosive agent to the hinge mating surface.
- After installation, check front door open/close and lock/unlock operation. If necessary, perform the front door adjustment procedure. Refer to [DLK-172, "DOOR ASSEMBLY : Adjustment"](#).
- After installation, apply touch-up paint (body color) to the head of the door hinge nuts.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


DLK

FRONT DOOR

< REMOVAL AND INSTALLATION >

- Check door hinge rotating part for poor lubrication. If necessary, apply a suitable multi-purpose grease.

← : Grease point




DOOR CHECK LINK

DOOR CHECK LINK : Removal and Installation

INFOID:000000010119870

REMOVAL

1. Fully close the front door window.
2. Remove front door speaker. Refer to [AV-70, "Removal and Installation"](#) (DISPLAY AUDIO), [AV-320, "Removal and Installation"](#) (NAVIGATION WITHOUT BOSE) or [AV-490, "Removal and Installation"](#) (NAVIGATION WITH BOSE).
3. Remove sealing screen.
NOTE:
Cut the butyl-tape so that some parts of the butyl-tape do not remain on the sealing screen, if the sealing screen is reused.
4. Remove the door check link bolt (body side).
5. Remove the door check link bolts (door side).
6. Remove door check link (1) from door panel (2).




INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Check front door open/close operation after installation.
- Check door check link rotating part for poor lubrication. If necessary, apply a suitable multi-purpose grease.

← : Grease point




REAR DOOR

< REMOVAL AND INSTALLATION >

REAR DOOR

Exploded View

INFOID:000000010119871



- | | | |
|-----------------------|-----------------------|--------------------|
| 1. Rear door panel | 2. Grommet | 3. Bolt |
| 4. Door striker | 5. Bumper rubber | 6. Door check link |
| 7. Door hinge (lower) | 8. Door hinge (upper) | ⊗ Do not reuse |

Grease

DOOR ASSEMBLY

DOOR ASSEMBLY : Removal and Installation


INFOID:000000010119872

CAUTION:

- Use two people when removing or installing the rear door due to its heavy weight.
- When removing or installing the rear door assembly, support the rear door using a suitable tool.

REMOVAL


1. Remove rear door harness grommet (2) from body side outer (1) and pull out rear door harness.



REAR DOOR

< REMOVAL AND INSTALLATION >

2. Disconnect the harness connector from the rear door.



3. Remove the door check link bolt (body side).
4. Remove door hinge nuts (door side) and rear door assembly.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:


- Apply anticorrosive agent onto the mounting surface.
- After installation, check the rear door open/close and lock/unlock operation. If necessary, perform the rear door assembly adjustment procedure. Refer to [DLK-177, "DOOR ASSEMBLY : Adjustment"](#).
- Check door hinge rotating part for poor lubrication. If necessary, apply a suitable multi-purpose grease.
- After installation, apply touch-up paint (body color) to the head of door hinge nuts.

REAR DOOR

< REMOVAL AND INSTALLATION >

DOOR ASSEMBLY : Adjustment

INFOID:000000010119873



- | | | |
|---------------------|----------------------------|----------------------------|
| 1. Front fender | 2. Front door | 3. Rear door |
| 4. Body side outer | 5. Door striker | 6. Bolt |
| 7. Front door hinge | 8. Rear door hinge (upper) | 9. Rear door hinge (lower) |
- Do not reuse
 Grease

Check the clearance and surface height between rear door and each part by visual inspection and tactile feel. If the clearance and the surface height are out of specification, adjust them according to the adjustment procedure.

Unit: mm (in)

Portion	Section	Measurement	Standard
Front fender – Front door	A – A	Clearance	4.0 ± 1.0 (0.16 ± 0.04)
		Surface height	0.0 ± 1.0 (0.00 ± 0.04)
Front door – Rear door	B – B	Clearance	4.2 ± 1.0 (0.17 ± 0.04)
		Surface height	0.0 ± 1.0 (0.00 ± 0.04)
Front door – Rear door	C – C	Clearance	4.0 ± 1.0 (0.16 ± 0.04)
		Surface height	0.0 ± 1.0 (0.00 ± 0.04)

FITTING ADJUSTMENT PROCEDURE

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK

REAR DOOR

< REMOVAL AND INSTALLATION >

1. Remove center pillar lower garnish. Refer to [INT-30, "CENTER PILLAR LOWER GARNISH : Removal and Installation"](#).
2. Loosen door hinge nuts (door side).
3. Adjust the surface height of rear door according to the specifications provided.
4. Temporarily tighten door hinge nuts (door side).
5. Loosen door hinge nuts and bolts (body side).
6. Raise rear door at rear end to adjust clearance of rear door according to the specifications provided.
7. Tighten bolts and nuts to the specified torque.
CAUTION:
 - After installation, apply touch-up paint (body color) to the head of door hinge bolts and nuts.
 - Check door hinge rotating part for poor lubrication. If necessary, apply a suitable multi-purpose grease.
8. Install center pillar lower garnish. Refer to [INT-30, "CENTER PILLAR LOWER GARNISH : Removal and Installation"](#).

DOOR STRIKER ADJUSTMENT

Adjust door striker so that it becomes parallel with door lock insertion direction.

DOOR STRIKER

DOOR STRIKER : Removal and Installation

INFOID:000000010119874

REMOVAL

Remove the door striker bolts and door striker.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Do not reuse door striker bolts.
- After installation, perform the rear door adjustment procedure. Refer to [DLK-177, "DOOR ASSEMBLY : Adjustment"](#).
- After installation, apply touch-up paint (body color) to the head of the door striker bolts.

DOOR HINGE

DOOR HINGE : Removal and Installation

INFOID:000000010119875

CAUTION:

- Use two people when removing or installing the rear door due to its heavy weight.
- When removing and installing rear door assembly, support the rear door using a suitable tool.

REMOVAL

1. Remove rear door assembly. Refer to [DLK-175, "DOOR ASSEMBLY : Removal and Installation"](#).
2. Remove center pillar lower garnish. Refer to [INT-30, "CENTER PILLAR LOWER GARNISH : Removal and Installation"](#).
3. Remove the rear door hinge bolts and nuts (body side) and door hinge.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:


- Apply anticorrosive agent onto the mounting surface.
- After installation, check the rear door open/close and lock/unlock operation. If necessary, perform the rear door assembly adjustment procedure. Refer to [DLK-177, "DOOR ASSEMBLY : Adjustment"](#).
- After installation, apply touch-up paint (body color) to the head of door hinge nuts.

REAR DOOR

< REMOVAL AND INSTALLATION >

- Check door hinge rotating part for poor lubrication. If necessary, apply a suitable multi-purpose grease.

← : Grease point




DOOR CHECK LINK

DOOR CHECK LINK : Removal and Installation

INFOID:000000010119876

REMOVAL

1. Fully close the rear door window.
2. Remove rear door finisher. Refer to [INT-22, "Removal and Installation"](#).
3. Remove the rear door speaker. Refer to [AV-71, "Removal and Installation"](#) (DISPLAY AUDIO), [AV-322, "Removal and Installation"](#) (NAVIGATION WITHOUT BOSE) or [AV-492, "Removal and Installation"](#) (NAVIGATION WITH BOSE).
4. Remove the door check link bolt (body side).
5. Remove the door check link bolts (door side).
6. Remove door check link (1) from door panel (2).




INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- After installation, check the rear door open/close and lock/unlock operation.
- Check door check link rotating part for poor lubrication. If necessary, apply a suitable multi-purpose grease.

← : Grease point



A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P


BACK DOOR


< REMOVAL AND INSTALLATION >

BACK DOOR

Exploded View

INFOID:000000010119877



- | | | |
|----------------------------|--|---------------------------------|
| 1. Back door weather-strip | 2. Back door stay assembly | 3. Back door stay lower bracket |
| 4. Bumper rubber | 5. Bolt | 6. Back door striker |
| 7. Back door panel | 8. Back door hinge | A. Center mark |
| B. Seam |  Grease | |

BACK DOOR ASSEMBLY

BACK DOOR ASSEMBLY : Removal and Installation

INFOID:000000010119878

CAUTION:

- Use two people when removing or installing the back door due to its heavy weight.
- Use shop cloths to protect surrounding components from damage during removal or installation of the back door.


REMOVAL

1. Remove the rear pillar finishers (LH/RH). Refer to [INT-31. "REAR PILLAR FINISHER : Removal and Installation"](#).


BACK DOOR

< REMOVAL AND INSTALLATION >


2. Disconnect harness connector (A) and (B).
3. Remove harness clip (C).
4. Remove ground cable mounting bolt (D).
⇐: Front




5. Remove rear washer hose (1) from hose joint (2).
⇐: Front



6. Remove grommet (1), and then pull out harness from rear fender extension (LH) (2).



7. Remove grommet (1), and then pull out harness from rear fender extension (RH) (2).



8. Support back door with appropriate material to prevent it from falling.

WARNING:

Bodily injury may occur if no supporting rod is holding the back door open when removing the back door stay.

9. Remove back door stay assembly (back door side). Refer to [DLK-184. "BACK DOOR STAY : Removal and Installation"](#).
10. Remove back door hinge nuts on back door and remove.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P


BACK DOOR

< REMOVAL AND INSTALLATION >

- Check back door hinge rotating part for poor lubrication. If necessary, apply a suitable multi-purpose grease.
- After installation, check back door open/close and lock/unlock operation. If necessary, perform the back door assembly adjustment procedure. Refer to [DLK-182, "BACK DOOR ASSEMBLY : Adjustment"](#).

BACK DOOR ASSEMBLY : Adjustment

INFOID:000000010119879





1. Back door assembly
2. Bumper rubber

3. Back door hinge
5. Bolt

4. Back door striker
6. Roof panel

BACK DOOR

< REMOVAL AND INSTALLATION >

- | | | |
|--------------------------|--|--|
| 7. Rear spoiler assembly | 8. Rear combination lamp | 9. Back door glass |
| 10. Rear bumper fascia |  Do not reuse |  Grease |


Check the clearance and the surface height between the back door and each part by visual inspection and tactile feel. If the clearance and surface height is out of specification, adjust them according to the adjustment procedure.

Unit: mm (in)

Portion	Section	Item	Measurement	Standard	Parallelism	Equality
Roof panel – Rear spoiler	A – A	F	Clearance	7.0 ± 2.0 (0.28 ± 0.08)	0.0 (0.00)	2.0 (0.08)
		G	Surface height	0.8 ± 2.0 (0.03 ± 0.08)	—	—
Rear combination lamp – Back door glass	B – B	H	Clearance	5.0 ± 2.3 (0.20 ± 0.09)	1.9 (0.07)	2.9 (0.11)
Rear combination lamp – Back door	C – C	J	Clearance	5.0 ± 2.3 (0.20 ± 0.09)	1.9 (0.07)	2.9 (0.11)
Rear bumper fascia – Back door	D – D	K	Clearance	5.3 ± 2.0 (0.21 ± 0.08)	2.0 (0.08)	2.0 (0.08)
Rear bumper fascia – Back door	E – E	M	Clearance	8.0 ± 2.0 (0.31 ± 0.08)	2.0 (0.08)	—

FITTING ADJUSTMENT PROCEDURE

- Loosen back door striker bolts.
- Loosen back door hinge nuts (back door side).
- Adjust back door to specifications provided.
- After adjustment tighten back door striker bolts and back door hinge nuts (back door side) to the specified torque.
- Screw bumper rubber into the stopper position (A), and then loosen by a half turn.



CAUTION:

After installation, apply touch-up paint (body color) to the head of back door hinge nuts.

BACK DOOR STRIKER ADJUSTMENT

Adjust the back door striker so that it becomes parallel with back door lock insertion direction.

BACK DOOR STRIKER

BACK DOOR STRIKER : Removal and Installation

INFOID:000000010119880

REMOVAL

Remove the door striker bolts and door striker.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Do not reuse door striker bolts.
- After installation, perform the back door adjustment procedure. Refer to [DLK-182, "BACK DOOR ASSEMBLY : Adjustment"](#).
- After installation, apply touch-up paint (body color) to the head of the door striker bolts.

BACK DOOR HINGE

BACK DOOR


< REMOVAL AND INSTALLATION >

BACK DOOR HINGE : Removal and Installation

INFOID:000000010119881

REMOVAL

1. Remove the luggage floor upper finisher. Refer to [INT-42, "LUGGAGE FLOOR UPPER FINISHER : Removal and Installation"](#).
2. Remove back door assembly. Refer to [DLK-180, "BACK DOOR ASSEMBLY : Removal and Installation"](#).
3. Partially remove the back door weather-strip. Refer to [DLK-185, "BACK DOOR WEATHER-STRIP : Removal and Installation"](#).
4. Remove rear assist grips (LH/RH) and mounting clips for rear portion of headlining, and then remove rear portion of headlining. Refer to [INT-36, "Exploded View"](#).
5. Remove insulator (A).



6. Remove back door hinge nut (body side) and back door hinge.


INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- After installation, check back door open/close and lock/unlock operation. If necessary, perform the back door assembly adjustment procedure. Refer to [DLK-182, "BACK DOOR ASSEMBLY : Adjustment"](#).
- Check back door hinge rotating part for poor lubrication. If necessary, apply a suitable multi-purpose grease.

← : Grease point



BACK DOOR STAY

BACK DOOR STAY : Removal and Installation

INFOID:000000010119882

REMOVAL

1. Support the back door using a suitable tool.

WARNING:

Bodily injury may occur if no supporting rod is holding the back door open when removing the back door stay.

2. Remove back door stay bolts (body side).

BACK DOOR


< REMOVAL AND INSTALLATION >

- Remove the metal clip (3) located on the connection between the back door stay assembly (1) and the back door stay lower bracket (2) by using a suitable tool (A).

CAUTION:

Be careful not to damage painted surface.

- Remove back door stay assembly (back door side).



- Remove back door stay bolts and back door stay assembly.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Apply anticorrosive agent onto the mounting surface.
- After installation, check back door open/close and lock/unlock operation.


BACK DOOR STAY : Disposal

INFOID:000000010119883

- Fix back door stay (1) using a vise (C).
- Using hacksaw (A) slowly make 2 holes in the back door stay, in numerical order as shown in the figure.


CAUTION:

- When cutting a hole on back door stay, always cover the hacksaw using a shop cloth (B) to avoid scattering metal fragments or oil.
- Wear eye protection (safety glasses).
- Wear gloves.



A: 20.0 mm (0.787 in)

B: Cut at the groove.



BACK DOOR WEATHER-STRIP

BACK DOOR WEATHER-STRIP : Removal and Installation

INFOID:000000010119884

REMOVAL

Pull and remove engagement with body from weather-strip joint.

CAUTION:

Do not pull strongly on weather-strip.


INSTALLATION

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

BACK DOOR


< REMOVAL AND INSTALLATION >

1. Working from the upper section, align weather-strip center mark (A) with vehicle center mark (cutting position) and install weather-strip onto the vehicle.



⇐ Front

2. Align the connecting point (B) of weather-strip (2) to the center (A) of striker (1), and then install as shown in the figure.



3. Pull weather-strip gently to ensure that there is no loose section.

NOTE:

Check that weather-strip fits tightly in each corner.


HOOD LOCK

< REMOVAL AND INSTALLATION >

HOOD LOCK

Exploded View

INFOID:000000010119885



- | | | |
|--------------------------------|-----------------------|----------------------------|
| 1. Hood lock secondary control | 2. Hood lock assembly | 3. Hood lock control cable |
| A. To charge port lid lock | △ Clip | Grease |


HOOD LOCK

HOOD LOCK : Removal and Installation

INFOID:000000010119886

REMOVAL

1. Remove radiator upper grille. Refer to [DLK-165. "RADIATOR UPPER GRILLE : Removal and Installation"](#).
2. Remove hood lock assembly. Refer to [DLK-187. "HOOD LOCK : Removal and Installation"](#).
3. Disconnect hood lock control cable (2) from hood lock assembly (1).



4. Disconnect the harness connector from the hood lock assembly (if equipped).
5. Remove the hood lock assembly.

INSTALLATION

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

HOOD LOCK

< REMOVAL AND INSTALLATION >

Installation is in the reverse order of removal.

CAUTION:

- Check that hood lock control cable is properly engaged with hood lock.
- After installation, perform hood assembly adjustment procedure. Refer to [DLK-155, "HOOD ASSEMBLY : Adjustment"](#).
- After installation, perform hood lock control inspection. Refer to [DLK-188, "Inspection"](#).

HOOD LOCK SECONDARY CONTROL

HOOD LOCK SECONDARY CONTROL : Removal and Installation

INFOID:000000010119887

REMOVAL

Remove the hood lock secondary control nuts and hood lock secondary control.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

After installation, perform hood lock control inspection. Refer to [DLK-188, "Inspection"](#).

HOOD LOCK CONTROL CABLE

HOOD LOCK CONTROL CABLE : Removal and Installation

INFOID:000000010119888

REMOVAL

1. Disconnect the hood lock control cable from the hood lock assembly.
2. Disconnect the charge port lid control cable from the charge port lid lock.
3. Disconnect the hood lock control cable and charge port lid control cable from the hood lock release handle and charge port lid lock release handle.
4. Remove the fender protector (LH). Refer to [EXT-21, "FENDER PROTECTOR : Removal and Installation"](#).
5. Release hood lock control cable clips using a suitable tool.
6. Remove grommet on the lower dash, and pull the hood lock control cable toward the passenger compartment.

CAUTION:


While pulling, do not damage the outside of hood lock control cable.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Do not bend cable too much, keep the radius 100 mm (3.937 in) or more.
- Check that cable is not offset from the positioning grommet and apply sealant to the grommet (at * mark).



- Check that hood lock control cable is properly engaged with hood lock.
- After installation, perform hood assembly adjustment procedure. Refer to [DLK-155, "HOOD ASSEMBLY : Adjustment"](#).
- After installation, perform hood lock control inspection. Refer to [DLK-188, "Inspection"](#).

Inspection

INFOID:000000010119889

NOTE:

If the hood lock release cable is bent or deformed, replace it.

HOOD LOCK


< REMOVAL AND INSTALLATION >

1. Check that secondary latch is properly engaged with secondary striker with hoods own weight.
2. While operating hood lock release lever, carefully check that the front end of the hood is raised by approximately 20.0 mm (0.79 in). Also check that the hood lock release lever returns to the original position.
3. Check that the hood lock release lever operates at 49 N (5.0 kg-m, 11.0 ft-lb) or below.
4. Install so that the static closing force of the hood is 120 - 564 N (12.2 - 57.6 kg-m, 89 - 416 ft-lb).

NOTE:

- Do not exert vertical force on the right or left side of hood lock.
 - Do not press simultaneously on both sides.
5. Check the hood lock lubrication condition. If necessary, apply a suitable multi-purpose grease.

← : Grease point



A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK


CHARGE PORT LID LOCK

< REMOVAL AND INSTALLATION >

CHARGE PORT LID LOCK

Exploded View

INFOID:000000010119890



- | | | |
|-----------------------------------|--------------------------------------|-----------------------------|
| 1. Charge port lid cover assembly | 2. Charge port lid seal | 3. Charge port lid assembly |
| 4. Charge port lid lock cable | 5. Charge port lid actuator assembly | 6. Charge port lid |
| 7. Charge port lid lock | 8. Charge port lid rear cover | △ Clip |


CHARGE PORT LID LOCK

CHARGE PORT LID LOCK : Removal and Installation

INFOID:000000010119891

REMOVAL

1. Remove charge port lid rear cover. Refer to [DLK-158, "Exploded View"](#).
2. Disconnect charge port lid control cable (2) from charge port lid lock (1), as shown.



3. Remove charge port lid lock bolts and charge port lid lock.

CHARGE PORT LID LOCK

< REMOVAL AND INSTALLATION >

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Check that charge port lid lock control cable is properly engaged with charge port lid lock.
- After installation, perform charge port lid fitting adjustment. Refer to [DLK-159, "CHARGE PORT LID ASSEMBLY : Adjustment"](#).


CHARGE PORT LID OPENER ACTUATOR

CHARGE PORT LID OPENER ACTUATOR : Removal and Installation


INFOID:000000010119892

REMOVAL

1. Remove charge port lid rear cover. Refer to [DLK-158, "Exploded View"](#).
2. Remove actuator cover.
 - a. Remove actuator cover screws.
 - b. Pull up actuator cover (1) from harness grommet (2) side, and the disconnect harness connector (A) from charge port lid opener actuator (3).



- c. Remove charge port lid control cable (1) from charge port lid hinge assembly (2) and charge port lid opener actuator (3).



- d. Remove actuator cover, charge port lid control cable and harness at the same time.
3. Remove charge port lid opener actuator bolts and charge port lid opener actuator.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Check that charge port lid lock control cable is properly engaged with charge port lid opener actuator.
- When replace charge port lid control cable and charge port lid opener actuator, replace with actuator cover.
- After installation, perform charge port lid fitting adjustment. Refer to [DLK-159, "CHARGE PORT LID ASSEMBLY : Adjustment"](#).
- Check charge port lid assembly lock/unlock operation after installation.


FRONT DOOR LOCK

< REMOVAL AND INSTALLATION >

FRONT DOOR LOCK

Exploded View

INFOID:000000010119893



- | | | |
|---|--------------------------|---------------------------|
| 1. Door key cylinder assembly (driver side) | 2. Rear gasket | 3. Outside handle bracket |
| Outside handle escutcheon (passenger side) | | |
| 4. Bolt | 5. Key rod (driver side) | 6. Door lock assembly |
| 7. Inside handle escutcheon | 8. Inside handle | 9. Cable clip |
| 10. Front gasket | 11. Outside handle | ⇐ Front |
| Do not reuse | Grease | |

DOOR LOCK

DOOR LOCK : Removal and Installation

INFOID:000000010119894

REMOVAL

1. Remove outside handle bracket. Refer to [DLK-193. "OUTSIDE HANDLE : Removal and Installation"](#).
2. Remove front door lower sash. Refer to [GW-19. "Exploded View"](#).
3. Remove door lock assembly bolts.
4. Disconnect the harness connector from the door lock actuator and remove door lock assembly.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:


- Do not reuse door lock assembly bolts.
- After installation, check the door open/close and lock/unlock operation.
- After installation, check door lock cable is properly engaged with outside handle bracket.

FRONT DOOR LOCK

< REMOVAL AND INSTALLATION >

- Check door lock assembly for poor lubrication. If necessary, apply a suitable multi-purpose grease.

← : Grease point



INSIDE HANDLE

INSIDE HANDLE : Removal and Installation

INFOID:000000010119895

REMOVAL

1. Remove front door finisher. Refer to [INT-19. "Removal and Installation"](#).
2. Remove inside handle screws and inside handle.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

After installation, check the door open/close and lock/unlock operation.

OUTSIDE HANDLE

OUTSIDE HANDLE : Removal and Installation

INFOID:000000010119896


REMOVAL

1. Fully close the front door glass.
2. Remove front door finisher. Refer to [INT-19. "Removal and Installation"](#).
3. Remove sealing screen.

NOTE:

Cut the butyl-tape so that some parts of the butyl-tape do not remain on the sealing screen, if the sealing screen is reused.

4. Disengage rod holder (1), and then separate key rod (3) from door lock assembly (2) (driver side).




A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

FRONT DOOR LOCK


< REMOVAL AND INSTALLATION >

5. Disconnect harness connector from door antenna (1) and door request switch (2) and remove harness clamps (A).




⇐ Front


6. Remove grommet (1) (door side). Loosen bolt (2) that retains door lock cylinder. (For passenger side, bolt fixes outside handle escutcheon.)



7. While pulling outside handle, remove door key cylinder assembly (driver side) or outside handle escutcheon (passenger side).




8. While pulling outside handle (1), slide toward rear of vehicle to remove outside handle.





FRONT DOOR LOCK

< REMOVAL AND INSTALLATION >


9. Remove front gasket (1) and rear gasket (2).




-  Pawl
-  Front

10. Slide outside handle bracket toward rear of vehicle to remove.

-  Front



11. Disconnect outside handle cable (1) from outside handle bracket (2).



INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- When installing key rod, rotate key rod holder until a click is felt (driver side only).
- Check that door lock cables are properly engaged with inside handle and outside handle.
- After installation, check door open/close and lock/unlock operation.

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P


REAR DOOR LOCK

< REMOVAL AND INSTALLATION >

REAR DOOR LOCK

Exploded View

INFOID:000000010119897



- | | | |
|------------------------------|-----------------------|-----------------------------|
| 1. Outside handle escutcheon | 2. Rear gasket | 3. Outside handle bracket |
| 4. Bolt | 5. Door lock assembly | 6. Inside handle escutcheon |
| 7. Inside handle | 8. Cable clip | 9. Front gasket |
| 10. Outside handle | ↔ Front | ⊗ Do not reuse |

 Grease

DOOR LOCK

DOOR LOCK : Removal and Installation

INFOID:000000010119898


REMOVAL

1. Remove outside handle bracket. Refer to [DLK-197, "OUTSIDE HANDLE : Removal and Installation"](#).

REAR DOOR LOCK

< REMOVAL AND INSTALLATION >

2. Disengage inside handle cable (1) from cable clip (A).



3. Remove lower bolt (B) of partition sash.
4. Disconnect the harness connector from the door lock actuator.
5. Remove door lock assembly bolts.
6. Remove door lock assembly while locating Inside handle cable and door lock cable to the bottom side of rear partition sash.


INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Do not reuse door lock assembly bolts.
- After installation, check the door open/close and lock/unlock operation.
- After installation, check door lock cable is properly engaged with outside handle bracket.
- Check door lock assembly for poor lubrication. If necessary, apply a suitable multi-purpose grease.

← : Grease point



INSIDE HANDLE

INSIDE HANDLE : Removal and Installation

INFOID:000000010119899

REMOVAL

1. Remove rear door finisher. Refer to [INT-22. "Removal and Installation"](#).
2. Remove inside handle screws and inside handle.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

After installation, check door open/close and lock/unlock operation.

OUTSIDE HANDLE

OUTSIDE HANDLE : Removal and Installation

INFOID:000000010119900

REMOVAL

1. Fully close rear door glass.

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

REAR DOOR LOCK


< REMOVAL AND INSTALLATION >

2. Remove rear door finisher. Refer to [JNT-22. "Removal and Installation"](#).
3. Remove sealing screen.


NOTE:

Cut the butyl-tape so that some parts of the butyl-tape do not remain on the sealing screen, if the sealing screen is reused.


4. Remove door side grommet and loosen bolt from grommet hole.




5. While pulling outside handle, remove outside handle escutcheon.



6. While pulling outside handle (1), slide toward rear of vehicle to remove outside handle.



7. Remove front gasket (1) and rear gasket (2).




○ Pawl

← Front


REAR DOOR LOCK

< REMOVAL AND INSTALLATION >

8. Slide outside handle bracket toward rear of vehicle to remove.
⇐: Front



9. Disconnect outside handle cable (1) from outside handle bracket (2).



INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- After installation, check door open/close and lock/unlock operation.
- Check door lock cable is properly engaged with outside handle bracket.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK


BACK DOOR LOCK

< REMOVAL AND INSTALLATION >

BACK DOOR LOCK

Exploded View

INFOID:000000010119901



- | | | |
|----------------------------|--------------|----------------------|
| 1. Back door lock assembly | 2. Bolt | 3. Back door striker |
| 4. Outside handle | Do not reuse | Grease |


DOOR LOCK

DOOR LOCK : Removal and Installation

INFOID:000000010119902

REMOVAL

1. Remove the back door lower finisher. Refer to [INT-48. "BACK DOOR LOWER FINISHER : Removal and Installation"](#).
2. Remove back door lock harness (1) from back door lock assembly (2).
3. Disconnect the harness connector (A) from the back door lock assembly.



4. Remove back door lock assembly bolts and back door lock assembly.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

After installation, check back door open/close and lock/unlock operation.

OUTSIDE HANDLE

OUTSIDE HANDLE : Removal and Installation

INFOID:000000010119903


REMOVAL

1. Remove the back door lower finisher. Refer to [INT-48. "BACK DOOR LOWER FINISHER : Removal and Installation"](#).

BACK DOOR LOCK

< REMOVAL AND INSTALLATION >

2. Disconnect the harness connectors from the outside handle and rear view camera (if equipped).



3. Remove outside handle nuts.
4. Remove harness grommet from back door panel, then remove the outside handle.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

After installation, check back door open/close and lock/unlock operation.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

KEY CYLINDER

< REMOVAL AND INSTALLATION >

KEY CYLINDER


GLOVE BOX LID KEY CYLINDER

GLOVE BOX LID KEY CYLINDER : Removal and Installation

INFOID:000000010436591

REMOVAL


1. Insert key (1) into glove box lid lock cylinder (2).
2. Pull upward on glove box lid release handle (3).
3. Rotate key (1) and turn glove box lid key cylinder (2) to the lock position.



4. Press tumbler stopper (1) into glove box lid lock cylinder (2) using a suitable tool (A), and then remove key (3) and glove box lid lock cylinder together from glove box lid release handle (4).

NOTE:

When removing glove box lid lock cylinder (2) note the position of cylinder to glove box lid release handle (4).




5. Remove sleeve (3) from glove box lid release handle and then install sleeve to glove box lid lock cylinder.

NOTE:

When removing sleeve note the position of sleeve to glove box lid release handle.

CAUTION:

Do not pull out key (1) from glove box lid lock cylinder (2) while sleeve (3) is removed. Otherwise, tumblers (4) may be lost from glove box lid lock cylinder.



INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

After installation, check glove box assembly open/close, lock/unlock operation.

DOOR SWITCH

< REMOVAL AND INSTALLATION >


DOOR SWITCH

Removal and Installation

INFOID:000000010119904

REMOVAL

1. Remove the door switch bolt (A).
2. Disconnect the harness connector and remove the door switch (1).



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

DOOR REQUEST SWITCH

< REMOVAL AND INSTALLATION >

DOOR REQUEST SWITCH

DRIVER SIDE

DRIVER SIDE : Removal and Installation

INFOID:000000010119905

The door request switch (driver side) is serviced as an assembly with the outside handle. Refer to [DLK-193, "OUTSIDE HANDLE : Removal and Installation"](#).

PASSENGER SIDE

PASSENGER SIDE : Removal and Installation

INFOID:000000010119906

The door request switch (passenger side) is serviced as an assembly with the outside handle. Refer to [DLK-193, "OUTSIDE HANDLE : Removal and Installation"](#).

BACK DOOR

BACK DOOR : Removal and Installation

INFOID:000000010119907

The back door request switch is serviced as an assembly with the back door opener switch. Refer to [DLK-212, "Removal and Installation"](#).

INSIDE KEY ANTENNA

< REMOVAL AND INSTALLATION >


INSIDE KEY ANTENNA INSTRUMENT CENTER

INSTRUMENT CENTER : Removal and Installation

INFOID:000000010119908

REMOVAL

1. Remove the cluster lid C. Refer to [IP-17. "Removal and Installation"](#).
2. Remove the inside key antenna (instrument center) screw (A).
CAUTION:
Be careful not to drop mounting screw (A) into instrument panel.
3. Disconnect the harness connector and remove the inside key antenna (instrument center) (1).



INSTALLATION

Installation is in the reverse order of removal.

CENTER CONSOLE

CENTER CONSOLE : Removal and Installation

INFOID:000000010119909

REMOVAL

1. Remove the shift selector finisher. Refer to [IP-28. "Exploded View"](#).
2. Disconnect the harness connector from the inside key antenna (center console).
3. Remove the inside key antenna (center console) screws and inside key antenna.

INSTALLATION

Installation is in the reverse order of removal.


REAR SEAT

REAR SEAT : Removal and Installation

INFOID:000000010119910

REMOVAL

1. Remove the rear seat. Refer to [SE-40. "SEAT CUSHION : Removal and Installation"](#).
2. Release the inside key antenna (rear seat) clip (A) using a suitable tool.
3. Disconnect the harness connector and remove the inside key antenna (rear seat) (1).



INSTALLATION

Installation is in the reverse order of removal.

LUGGAGE ROOM

LUGGAGE ROOM : Removal and Installation

INFOID:000000010119911

REMOVAL

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK


INSIDE KEY ANTENNA

< REMOVAL AND INSTALLATION >

1. Remove the luggage floor upper finisher. Refer to [INT-42. "LUGGAGE FLOOR UPPER FINISHER : Removal and Installation"](#).
2. Disconnect the harness connector and remove the inside key antenna (luggage room) (1) using a suitable tool (A).

CAUTION:

- When removing and installing, use shop cloths to protect the inside key antenna (luggage room) from damage.
- Be aware that mounting clips (B) may pop put.



INSTALLATION

Installation is in the reverse order of removal.

OUTSIDE KEY ANTENNA

< REMOVAL AND INSTALLATION >

OUTSIDE KEY ANTENNA

DRIVER SIDE

DRIVER SIDE : Removal and Installation

INFOID:0000000010119912

The outside key antenna (driver side) is serviced as an assembly with the outside handle. Refer to [DLK-193](#), "[OUTSIDE HANDLE : Removal and Installation](#)".

PASSENGER SIDE

PASSENGER SIDE : Removal and Installation

INFOID:0000000010119913

The outside key antenna (passenger side) is serviced as an assembly with the outside handle. Refer to [DLK-193](#), "[OUTSIDE HANDLE : Removal and Installation](#)".


REAR BUMPER

REAR BUMPER : Removal and Installation

INFOID:0000000010119914

REMOVAL

1. Remove the rear bumper fascia. Refer to [EXT-17](#), "[Removal and Installation](#)".
2. Release the outside key antenna (rear bumper) clip (A) using a suitable tool.
3. Disconnect the harness connector and remove the outside key antenna (rear bumper) (1).



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

INTELLIGENT KEY WARNING BUZZER

< REMOVAL AND INSTALLATION >


INTELLIGENT KEY WARNING BUZZER

Removal and Installation

INFOID:000000010119915

REMOVAL

1. Remove the front bumper fascia. Refer to [EXT-13, "Removal and Installation"](#).
2. Disconnect the harness connector from the Intelligent Key warning buzzer.
3. Remove the Intelligent Key warning buzzer bolt (A) and Intelligent Key warning buzzer (1).



INSTALLATION

Installation is in the reverse order of removal.

REMOTE KEYLESS ENTRY RECEIVER

< REMOVAL AND INSTALLATION >


REMOTE KEYLESS ENTRY RECEIVER

Removal and Installation

INFOID:000000010119916

REMOVAL

1. Remove the glove box lid. Refer to [JP-17. "Removal and Installation"](#)
2. Disconnect the harness connector from the remote keyless entry receiver.
3. Remove the remote keyless entry receiver bolt (A) and remote keyless entry receiver (1).



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

INTELLIGENT KEY BATTERY

< REMOVAL AND INSTALLATION >

INTELLIGENT KEY BATTERY


Removal and Installation

INFOID:000000010119917

1. Release the lock knob at the back of the Intelligent Key and remove the mechanical key.
2. Insert a suitable tool (A) wrapped with a cloth into the slit of the corner and twist it to separate the upper part from the lower part.

CAUTION:

- Do not touch the circuit board or battery terminal.
- The key fob is water-resistant. However, if it does get wet, immediately wipe it dry.



3. Replace the battery with new one.


Battery replacement

:Coin-type lithium battery (CR2025)

4. Align the tips of the upper and lower parts, and then push them together until it is securely closed.

CAUTION:

- When replacing battery, keep dirt, grease, and other foreign materials off the electrode contact area.
- After replacing the battery, check that all Intelligent Key functions work normally.



CHARGE PORT LID OPENER SWITCH

< REMOVAL AND INSTALLATION >


CHARGE PORT LID OPENER SWITCH

Removal and Installation

INFOID:000000010119918


REMOVAL

1. Remove instrument lower panel LH. Refer to [IP-17, "Removal and Installation"](#).
2. Remove the switch finisher screws (A) and switch finisher (1).



3. Remove charge port lid opener switch (2) from switch finisher (1).

○: Pawl



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

BACK DOOR OPENER SWITCH ASSEMBLY

< REMOVAL AND INSTALLATION >


BACK DOOR OPENER SWITCH ASSEMBLY

Removal and Installation


INFOID:000000010119919

REMOVAL

1. Remove back door outside handle. Refer to [DLK-200. "OUTSIDE HANDLE : Removal and Installation"](#).
2. Remove the switch finisher screws (A) and switch finisher (1).



3. Pinch back door opener switch assembly (2) from both side (in the direction shown by arrow 1) and disengage tab. Press toward outside (in the direction shown by arrow 2) to remove from back door outside handle (1).



INSTALLATION

Installation is in the reverse order of removal.