

SECTION DLK
DOOR & LOCK

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

CONTENTS

PRECAUTION	7	Charge Port Lid Opener Actuator	22
PRECAUTIONS	7	Charge Port Lid Opener Switch	22
Precaution for Technicians Using Medical Electric.....	7	SYSTEM (POWER DOOR LOCK SYSTEM)	23
Point to Be Checked Before Starting Maintenance		System Description	23
Work	7	SYSTEM (INTELLIGENT KEY SYSTEM)	25
Precaution for Supplemental Restraint System		INTELLIGENT KEY SYSTEM	25
(SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	7	INTELLIGENT KEY SYSTEM : System Description	25
Procedure without Cowl Top Cover	8	DOOR LOCK FUNCTION	26
High Voltage Precautions	8	DOOR LOCK FUNCTION : System Description	26
Precaution for Removing 12V Battery	10	BACK DOOR OPEN FUNCTION	28
Precaution for Servicing Doors and Locks	11	BACK DOOR OPEN FUNCTION : System Description	28
Precaution for Work	11	REMOTE KEYLESS ENTRY FUNCTION	29
PREPARATION	13	REMOTE KEYLESS ENTRY FUNCTION : System Description	30
PREPARATION	13	KEY REMINDER FUNCTION	32
Special Service Tools	13	KEY REMINDER FUNCTION : System Description	32
Commercial Service Tools	14	WARNING FUNCTION	33
SYSTEM DESCRIPTION	16	WARNING FUNCTION : System Description	33
COMPONENT PARTS	16	SYSTEM (BACK DOOR OPENER SYSTEM) ...	36
Component Parts Location	16	System Description	36
Inside Key Antenna (Instrument Center)	18	SYSTEM (HOMELINK UNIVERSAL TRANSCEIVER)	37
Inside Key Antenna (Rear Seat)	18	System Description	37
Inside Key Antenna (Luggage Room)	18	SYSTEM (CHARGE PORT LID OPEN CONTROL)	38
Outside Key Antenna (Rear Bumper)	18	System Description	38
Outside Key Antenna (LH)	19	DIAGNOSIS SYSTEM (BCM)	39
Outside Key Antenna (RH)	19	COMMON ITEM	39
Front Door Lock Assembly (LH)	19		
Remote Keyless Entry Receiver	19		
Intelligent Key Warning Buzzer	20		
Back Door Lock Assembly	20		
Door Lock and Unlock Switch	20		
Front Door Request Switch (LH)	20		
Front Door Request Switch (RH)	21		
Door Switch	21		
Back Door Request Switch	21		
Back Door Opener Switch	21		

DLK

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)	39	Component Function Check	83
DOOR LOCK	39	Diagnosis Procedure	83
DOOR LOCK : CONSULT Function (BCM - DOOR LOCK)	40	Component Inspection	84
INTELLIGENT KEY	40	BACK DOOR REQUEST SWITCH	85
INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY)	40	Component Function Check	85
TRUNK	43	Diagnosis Procedure	85
TRUNK : CONSULT Function (BCM - TRUNK)	43	Component Inspection	86
ECU DIAGNOSIS INFORMATION	44	BUZZER (COMBINATION METER)	87
BCM	44	Component Function Check	87
List of ECU Reference	44	Diagnosis Procedure	87
WIRING DIAGRAM	45	DOOR KEY CYLINDER SWITCH	88
DOOR & LOCK SYSTEM	45	Component Function Check	88
Wiring Diagram	45	Diagnosis Procedure	88
HOMELINK UNIVERSAL TRANSCEIVER	64	Component Inspection	89
Wiring Diagram	64	DOOR LOCK ACTUATOR	90
BASIC INSPECTION	66	DRIVER SIDE	90
DIAGNOSIS AND REPAIR WORK FLOW	66	DRIVER SIDE : Component Function Check	90
Work Flow	66	DRIVER SIDE : Diagnosis Procedure	90
DTC/CIRCUIT DIAGNOSIS	69	PASSENGER SIDE	91
B2621 INSIDE ANTENNA	69	PASSENGER SIDE :	
DTC Logic	69	Component Function Check	91
Diagnosis Procedure	69	PASSENGER SIDE : Diagnosis Procedure	91
B2622 INSIDE ANTENNA	71	REAR LH	92
DTC Logic	71	REAR LH : Component Function Check	92
Diagnosis Procedure	71	REAR LH : Diagnosis Procedure	92
B2623 INSIDE ANTENNA	73	REAR RH	93
DTC Logic	73	REAR RH : Component Function Check	93
Diagnosis Procedure	73	REAR RH : Diagnosis Procedure	94
B2626 OUTSIDE ANTENNA	75	DOOR LOCK AND UNLOCK SWITCH	96
DTC Logic	75	DRIVER SIDE	96
Diagnosis Procedure	75	DRIVER SIDE : Component Function Check	96
B2627 OUTSIDE ANTENNA	77	DRIVER SIDE : Diagnosis Procedure	96
DTC Logic	77	DRIVER SIDE : Component Inspection	97
Diagnosis Procedure	77	PASSENGER SIDE	98
B2628 OUTSIDE ANTENNA	79	PASSENGER SIDE :	
DTC Logic	79	Component Function Check	98
Diagnosis Procedure	79	PASSENGER SIDE : Diagnosis Procedure	98
BACK DOOR OPENER ACTUATOR	81	PASSENGER SIDE : Component Inspection	99
Component Function Check	81	DOOR REQUEST SWITCH	101
Diagnosis Procedure	81	Component Function Check	101
BACK DOOR OPENER SWITCH	83	Diagnosis Procedure	101
		Component Inspection	102
		DOOR SWITCH	103
		Component Function Check	103
		Diagnosis Procedure	103
		Component Inspection	104
		HAZARD FUNCTION	106
		Component Function Check	106
		Diagnosis Procedure	106

INTELLIGENT KEY	107	REAR RH	126	
Component Function Check	107	REAR RH : Description	126	A
Diagnosis Procedure	107	REAR RH : Diagnosis Procedure	126	
INTELLIGENT KEY WARNING BUZZER	108	DOOR DOES NOT LOCK/UNLOCK WITH		B
Component Function Check	108	DOOR REQUEST SWITCH	128	
Diagnosis Procedure	108	ALL DOOR REQUEST SWITCHES	128	C
Component Inspection	109	ALL DOOR REQUEST SWITCHES : Description ..	128	
REMOTE KEYLESS ENTRY RECEIVER	110	ALL DOOR REQUEST SWITCHES : Diagnosis		D
Component Function Check	110	Procedure	128	
Diagnosis Procedure	110	DRIVER SIDE DOOR REQUEST SWITCH	128	E
UNLOCK SENSOR	113	DRIVER SIDE DOOR REQUEST SWITCH : De-		
Component Function Check	113	scription	128	
Diagnosis Procedure	113	DRIVER SIDE DOOR REQUEST SWITCH : Diag-		E
Component Inspection	114	nosis Procedure	128	
INFORMATION DISPLAY	115	PASSENGER SIDE DOOR REQUEST SWITCH ...	129	F
Component Function Check	115	PASSENGER SIDE DOOR REQUEST SWITCH :		
Diagnosis Procedure	115	Description	129	
CHARGE PORT LID OPENER RELAY	116	PASSENGER SIDE DOOR REQUEST SWITCH :		G
Diagnosis Procedure	116	Diagnosis Procedure	129	
Component Inspection (Charge Port Lid Opener		BACK DOOR REQUEST SWITCH	129	H
Actuator Relay)	117	BACK DOOR REQUEST SWITCH : Description ..	130	
CHARGE PORT LID OPENER	119	BACK DOOR REQUEST SWITCH : Diagnosis		H
Component Function Check	119	Procedure	130	
Diagnosis Procedure	119	DOOR DOES NOT LOCK/UNLOCK WITH		I
Component Inspection (Charge Port Lid Opener		DOOR KEY CYLINDER OPERATION	131	
Actuator)	120	Diagnosis Procedure	131	
CHARGE PORT LID OPENER SWITCH	121	DOOR DOES NOT LOCK/UNLOCK WITH IN-		J
Diagnosis Procedure	121	TELLIGENT KEY	132	
Component Inspection (Charge Port Lid Opener		Diagnosis Procedure	132	
Switch)	121	POWER POSITION WARNING DOES NOT		DLK
HOMELINK UNIVERSAL TRANSCEIVER	123	OPERATE	133	
Component Function Check	123	Diagnosis Procedure	133	L
Diagnosis Procedure	123	SELECTIVE UNLOCK FUNCTION DOES		
SYMPTOM DIAGNOSIS	125	NOT OPERATE	134	M
DOOR DOES NOT LOCK/UNLOCK WITH		Diagnosis Procedure	134	
DOOR LOCK AND UNLOCK SWITCH	125	BACK DOOR DOES NOT OPEN	135	N
ALL DOOR	125	Diagnosis Procedure	135	
ALL DOOR : Description	125	AUTO DOOR LOCK OPERATION DOES NOT		O
ALL DOOR : Diagnosis Procedure	125	OPERATE	136	
DRIVER SIDE	125	Diagnosis Procedure	136	
DRIVER SIDE : Description	125	VEHICLE SPEED SENSING AUTO LOCK		P
DRIVER SIDE : Diagnosis Procedure	125	OPERATION DOES NOT OPERATE	137	
PASSENGER SIDE	126	Diagnosis Procedure	137	
PASSENGER SIDE : Description	126	POWER SWITCH OFF INTERLOCK DOOR		
PASSENGER SIDE : Diagnosis Procedure	126	UNLOCK FUNCTION DOES NOT OPERATE.	138	
REAR LH	126	Diagnosis Procedure	138	
REAR LH : Description	126	P POSITION INTERLOCK DOOR LOCK/UN-		
REAR LH : Diagnosis Procedure	126	LOCK FUNCTION DOES NOT OPERATE	139	

Diagnosis Procedure	139	CHARGE PORT LID ASSEMBLY : Removal and Installation	159
HAZARD AND BUZZER REMINDER DOES NOT OPERATE	140	CHARGE PORT LID ASSEMBLY : Adjustment ...	160
Diagnosis Procedure	140	CHARGE PORT LID HINGE ASSEMBLY	161
KEY REMINDER FUNCTION DOES NOT OPERATE	142	CHARGE PORT LID HINGE ASSEMBLY : Removal and Installation	161
Diagnosis Procedure	142	CHARGE PORT COVER	161
OFF POSITION WARNING DOES NOT OPERATE	143	CHARGE PORT COVER : Removal and Installation	161
Diagnosis Procedure	143	RADIATOR CORE SUPPORT	162
TAKE AWAY WARNING DOES NOT OPERATE	144	Exploded View	162
Diagnosis Procedure	144	RADIATOR CORE SUPPORT UPPER	162
INTELLIGENT KEY LOW BATTERY WARNING DOES NOT OPERATE	145	RADIATOR CORE SUPPORT UPPER : Removal and Installation	162
Diagnosis Procedure	145	RADIATOR CORE SUPPORT LOWER	164
DOOR LOCK OPERATION WARNING DOES NOT OPERATE	146	RADIATOR CORE SUPPORT LOWER : Removal and Installation	164
Diagnosis Procedure	146	RADIATOR UPPER GRILLE	166
KEY ID WARNING DOES NOT OPERATE	147	RADIATOR UPPER GRILLE : Removal and Installation	166
Diagnosis Procedure	147	CHARGE PORT BRACKET	166
HOMELINK UNIVERSAL TRANSCEIVER DOES NOT OPERATE	148	CHARGE PORT BRACKET : Removal and Installation	166
Diagnosis Procedure	148	FRONT FENDER	169
SQUEAK AND RATTLE TROUBLE DIAGNOSES	149	Exploded View	169
Work Flow	149	Removal and Installation	169
Generic Squeak and Rattle Troubleshooting	150	FRONT DOOR	171
Diagnostic Worksheet	153	Exploded View	171
REMOVAL AND INSTALLATION	155	DOOR ASSEMBLY	171
HOOD	155	DOOR ASSEMBLY : Removal and Installation ...	171
Exploded View	155	DOOR ASSEMBLY : Adjustment	173
HOOD ASSEMBLY	155	DOOR STRIKER	174
HOOD ASSEMBLY : Removal and Installation ...	155	DOOR STRIKER : Removal and Installation	174
HOOD ASSEMBLY : Adjustment	156	DOOR HINGE	174
HOOD HINGE	157	DOOR HINGE : Removal and Installation	174
HOOD HINGE : Removal and Installation	157	DOOR CHECK LINK	175
HOOD SUPPORT ROD	158	DOOR CHECK LINK : Removal and Installation .	175
HOOD SUPPORT ROD : Removal and Installation	158	REAR DOOR	176
HOOD COVER	158	Exploded View	176
HOOD COVER : Removal and Installation	158	DOOR ASSEMBLY	176
CHARGE PORT LID	159	DOOR ASSEMBLY : Removal and Installation ...	176
Exploded View	159	DOOR ASSEMBLY : Adjustment	178
CHARGE PORT LID ASSEMBLY	159	DOOR STRIKER	179
		DOOR STRIKER : Removal and Installation	179
		DOOR HINGE	179
		DOOR HINGE : Removal and Installation	179

DOOR CHECK LINK	180	REAR DOOR LOCK	197	
DOOR CHECK LINK : Removal and Installation ..	180	Exploded View	197	A
BACK DOOR	181	DOOR LOCK	197	
Exploded View	181	DOOR LOCK : Removal and Installation	197	B
BACK DOOR ASSEMBLY	181	INSIDE HANDLE	198	
BACK DOOR ASSEMBLY : Removal and Installation	181	INSIDE HANDLE : Removal and Installation	198	C
BACK DOOR ASSEMBLY : Adjustment	183	OUTSIDE HANDLE	198	
BACK DOOR STRIKER	184	OUTSIDE HANDLE : Removal and Installation	198	
BACK DOOR STRIKER : Removal and Installation	184	BACK DOOR LOCK	201	D
BACK DOOR HINGE	184	Exploded View	201	
BACK DOOR HINGE : Removal and Installation ..	185	DOOR LOCK	201	E
BACK DOOR STAY	185	DOOR LOCK : Removal and Installation	201	
BACK DOOR STAY : Removal and Installation ...	185	OUTSIDE HANDLE	201	
BACK DOOR STAY : Disposal	186	OUTSIDE HANDLE : Removal and Installation	201	F
BACK DOOR WEATHER-STRIP	186	KEY CYLINDER	203	
BACK DOOR WEATHER-STRIP : Removal and Installation	186	GLOVE BOX LID KEY CYLINDER	203	G
HOOD LOCK	188	GLOVE BOX LID KEY CYLINDER : Removal and Installation	203	
Exploded View	188	DOOR SWITCH	204	H
HOOD LOCK	188	Removal and Installation	204	
HOOD LOCK : Removal and Installation	188	DOOR REQUEST SWITCH	205	I
HOOD LOCK SECONDARY CONTROL	189	DRIVER SIDE	205	
HOOD LOCK SECONDARY CONTROL : Removal and Installation	189	DRIVER SIDE : Removal and Installation	205	J
HOOD LOCK CONTROL CABLE	189	PASSENGER SIDE	205	
HOOD LOCK CONTROL CABLE : Removal and Installation	189	PASSENGER SIDE : Removal and Installation ...	205	
Inspection	189	BACK DOOR	205	DLK
CHARGE PORT LID LOCK	191	BACK DOOR : Removal and Installation	205	
Exploded View	191	INSIDE KEY ANTENNA	206	L
CHARGE PORT LID LOCK	191	INSTRUMENT CENTER	206	
CHARGE PORT LID LOCK : Removal and Installation	191	INSTRUMENT CENTER : Removal and Installation	206	M
CHARGE PORT LID OPENER ACTUATOR	192	CENTER CONSOLE	206	
CHARGE PORT LID OPENER ACTUATOR : Removal and Installation	192	CENTER CONSOLE : Removal and Installation ..	206	N
FRONT DOOR LOCK	193	REAR SEAT	206	
Exploded View	193	REAR SEAT : Removal and Installation	206	O
DOOR LOCK	193	LUGGAGE ROOM	206	
DOOR LOCK : Removal and Installation	193	LUGGAGE ROOM : Removal and Installation	206	P
INSIDE HANDLE	194	OUTSIDE KEY ANTENNA	208	
INSIDE HANDLE : Removal and Installation	194	DRIVER SIDE	208	
OUTSIDE HANDLE	194	DRIVER SIDE : Removal and Installation	208	
OUTSIDE HANDLE : Removal and Installation ...	194	PASSENGER SIDE	208	
		PASSENGER SIDE : Removal and Installation ...	208	
		REAR BUMPER	208	

REAR BUMPER : Removal and Installation	208	Removal and Installation	211
INTELLIGENT KEY WARNING BUZZER	209	CHARGE PORT LID OPENER SWITCH	212
Removal and Installation	209	Removal and Installation	212
REMOTE KEYLESS ENTRY RECEIVER	210	BACK DOOR OPENER SWITCH ASSEMBLY	
Removal and Installation	210		..213
INTELLIGENT KEY BATTERY	211	Removal and Installation	213

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Technicians Using Medical Electric

INFOID:000000010639677

OPERATION PROHIBITION

WARNING:

- Parts with strong magnet is used in this vehicle.
- Technicians using a medical electric device such as pacemaker must never perform operation on the vehicle, as magnetic field can affect the device function by approaching to such parts.

NORMAL CHARGE PRECAUTION

WARNING:

- If a technician uses a medical electric device such as an implantable cardiac pacemaker or an implantable cardioverter defibrillator, the possible effects on the devices must be checked with the device manufacturer before starting the charge operation.
- As radiated electromagnetic wave generated by PDM (Power Delivery Module) at normal charge operation may affect medical electric devices, a technician using a medical electric device such as implantable cardiac pacemaker or an implantable cardioverter defibrillator must not approach motor room [PDM (Power Delivery Module)] at the hood-opened condition during normal charge operation.

PRECAUTION AT TELEMATICS SYSTEM OPERATION

WARNING:

- If a technician uses implantable cardiac pacemaker or implantable cardioverter defibrillator (ICD), avoid the device implanted part from approaching within approximately 220 mm (8.66 in) from interior/exterior antenna.
- The electromagnetic wave of TCU might affect the function of the implantable cardiac pacemaker or the implantable cardioverter defibrillator (ICD), when using the service, etc.
- If a technician uses other medical electric devices than implantable cardiac pacemaker or implantable cardioverter defibrillator (ICD), the electromagnetic wave of TCU might affect the function of the device. The possible effects on the devices must be checked with the device manufacturer before TCU use.

PRECAUTION AT INTELLIGENT KEY SYSTEM OPERATION

WARNING:

- If a technician uses implantable cardiac pacemaker or implantable cardioverter defibrillator (ICD), avoid the device implanted part from approaching within approximately 220 mm (8.66 in) from interior/exterior antenna.
- The electromagnetic wave of Intelligent Key might affect the function of the implantable cardiac pacemaker or the implantable cardioverter defibrillator (ICD), at door operation, at each request switch operation, or at engine starting.
- If a technician uses other medical electric devices than implantable cardiac pacemaker or implantable cardioverter defibrillator (ICD), the electromagnetic wave of Intelligent Key might affect the function of the device. The possible effects on the devices must be checked with the device manufacturer before Intelligent Key use.

Point to Be Checked Before Starting Maintenance Work

INFOID:000000010639678

The high voltage system may starts automatically. It is required to check that the timer air conditioner and timer charge (during EVSE connection) are not set before starting maintenance work.

NOTE:

If the timer air conditioner or timer charge (during EVSE connection) is set, the high voltage system starts automatically even when the power switch is in OFF state.

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000010639679

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

PRECAUTIONS

< PRECAUTION >

system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS


WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

Procedure without Cowl Top Cover

INFOID:000000010639680


When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc. to prevent damage to the windshield.



High Voltage Precautions

INFOID:000000010639681

DANGER:

 Since hybrid vehicles and electric vehicles contain a high voltage battery, there is the risk of electric shock, electric leakage, or similar accidents if the high voltage component and vehicle are handled incorrectly. Be sure to follow the correct work procedures when performing inspection and maintenance.

WARNING:

- Be sure to remove the service plug in order to disconnect the high voltage circuits before performing inspection or maintenance of high voltage system harnesses and parts.
- The removed service plug must always be carried in a pocket of the responsible worker or placed in the tool box during the procedure to prevent the plug from being connected by mistake.
- Be sure to wear insulated protective equipment before beginning work on the high voltage system.
- Never allow workers other than the responsible person to touch the vehicle containing high voltage parts. To keep others from touching the high voltage parts, these parts must be covered with an insulating sheet except when using them.

CAUTION:

Never bring the vehicle into the READY status with the service plug removed unless otherwise instructed in the Service Manual. A malfunction may occur if this is not observed.

HIGH VOLTAGE HARNESS AND EQUIPMENT IDENTIFICATION

PRECAUTIONS

< PRECAUTION >

All the high voltage harnesses and connectors are orange. The Li-ion battery and other high voltage devices include an orange high voltage label. Never touch these harnesses and high voltage parts.

A

HANDLING OF HIGH VOLTAGE HARNESS AND TERMINALS

Immediately insulate disconnected high voltage connectors and terminals with insulating tape.

B

REGULATIONS ON WORKERS WITH MEDICAL ELECTRONICS

WARNING:

The vehicle contains parts that contain powerful magnets. If a person who is wearing a heart pacemaker or other medical device is close to these parts, the medical device may be affected by the magnets. Such persons must not perform work on the vehicle.

C

PROHIBITED ITEMS TO CARRY DURING THE WORK

Hybrid vehicles and electric vehicles contain parts with high voltage and intense magnetic force. Never carry metal products and magnetic recording media (e.g. cash card, prepaid card) to repair/inspect high voltage parts. If this is not observed, the metal products may create a risk of short circuit and the magnetic recording media may lose their magnetic recording.

D

E

POSTING A SIGN OF "DANGER! HIGH VOLTAGE AREA. KEEP OUT"

F

G

H

I

J

DLK

L

M

N

O

P

PRECAUTIONS

< PRECAUTION >

Indicate "HIGH VOLTAGE. DO NOT TOUCH" on the vehicle under repair/inspection to call attention to other workers.

Person in charge: _____
DO NOT TOUCH! REPAIR IN PROGRESS. HIGH VOLTAGE DANGER:
DANGER: HIGH VOLTAGE REPAIR IN PROGRESS. DO NOT TOUCH! Person in charge: _____
Copy this page and put it after folding on the roof of the vehicle in service.

JSAIA1600GB

Precaution for Removing 12V Battery

INFOID:0000000110639682

1. Check that EVSE is not connected.

NOTE:

If EVSE is connected, the air conditioning system may be automatically activated by the timer A/C function.

2. Turn the power switch OFF → ON → OFF. Get out of the vehicle. Close all doors (including back door).

PRECAUTIONS

< PRECAUTION >

3. Check that the charge status indicator lamp does not blink and wait for 5 minutes or more.
NOTE:
If the battery is removed within 5 minutes after the power switch is turned OFF, plural DTCs may be detected.
4. Remove 12V battery within 1 hour after turning the power switch OFF → ON → OFF.
NOTE:
 - The 12V battery automatic charge control may start automatically even when the power switch is in OFF state.
 - Once the power switch is turned ON → OFF, the 12V battery automatic charge control does not start for approximately 1 hour.**CAUTION:**
 - **After all doors (including back door) are closed, if a door (including back door) is opened before battery terminals are disconnected, start over from Step 1.**
 - **After turning the power switch OFF, if “Remote A/C” is activated by user operation, stop the air conditioner and start over from Step 1.**

Precaution for Servicing Doors and Locks

INFOID:000000011046223

WARNING:

Radio waves could adversely affect electric medical equipment. Those who use a pacemaker should contact the electric medical equipment manufacturer for the possible influences before use.

- After removing and installing the opening/closing parts, be sure to carry out fitting adjustments to check their operation.
- Check the lubrication level, damage, and wear of each part. If necessary, grease or replace it.
- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
 - Water soluble dirt:
 - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
 - Then rub with a soft, dry cloth.
 - Oily dirt:
 - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
 - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
 - Then rub with a soft, dry cloth.
 - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
 - For genuine leather seats, use a genuine leather seat cleaner.

Precaution for Work

INFOID:000000011107781

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
 - Water soluble dirt:
 - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
 - Then rub with a soft, dry cloth.
 - Oily dirt:

PRECAUTIONS

< PRECAUTION >

- Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
- Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
- Then rub with a soft, dry cloth.
- Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
- For genuine leather seats, use a genuine leather seat cleaner.

PREPARATION

< PREPARATION >

PREPARATION


PREPARATION

Special Service Tools

INFOID:000000010639684

The actual shape of the tools may differ from those illustrated here.


Tool number (TechMate No.) Tool name	Description
— (J-39570) Chassis Ear	Locating the noise
— (J-50397) NISSAN Squeak and Rattle Kit	Repairing the cause of noise
— (J-46534) Trim Tool Set	Removing trim components
— (J-43241) Remote Keyless Entry Tester	Used to test keyfobs




SIA0993E



ALJIA1232ZZ



AWJIA0483ZZ





LEL946A

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P





PREPARATION

< PREPARATION >

Tool number (TechMate No.) Tool name	Description
<p>— (J-50190) Signal Tech II</p>  <p>ALEIA0131ZZ</p>	<ul style="list-style-type: none"> • Activate and display TPMS transmitter IDs • Display tire pressure reported by the TPMS transmitter • Read TPMS DTCs • Register TPMS transmitter IDs • Test remote keyless entry keyfob relative signal strength • Check Intelligent Key relative signal strength • Confirm vehicle Intelligent Key antenna signal strength • Compatible with future sensors • Equipped with a display
<p>KV48105501 (J-45295-A) Transmitter Activation Tool</p>  <p>ALEIA0183ZZ</p>	<ul style="list-style-type: none"> • Activate TPMS transmitter IDs • Compatible with future sensors • Equipped with a display (KV48105501 only)




Commercial Service Tools

INFOID:0000000010639685

Tool name	Description
<p>Insulated gloves [Guaranteed insulation performance for 1000V/300A]</p>  <p>JMCIA0149ZZ</p>	<p>Removing and installing high voltage components</p>
<p>Leather gloves [Use leather gloves that can fasten the wrist tight]</p>  <p>JPCIA0066ZZ</p>	<ul style="list-style-type: none"> • Removing and installing high voltage components • Protect insulated gloves
<p>Insulated safety shoes</p>  <p>JPCIA0011ZZ</p>	<p>Removing and installing high voltage components</p>
<p>Safety glasses [ANSI Z87.1]</p>  <p>JPCIA0012ZZ</p>	<ul style="list-style-type: none"> • Removing and installing high voltage components • To protect eye from the spatter on the work to electric line

PREPARATION

< PREPARATION >

Tool name	Description	
<p data-bbox="162 197 284 222">Face shield</p>  <p data-bbox="771 415 860 432">JPCIA0167ZZ</p>	<ul data-bbox="1006 197 1461 304" style="list-style-type: none"> • Removing and installing high voltage components • To protect eye from the spatter on the work to electric line 	<p data-bbox="1518 178 1550 203">A</p> <p data-bbox="1518 283 1550 308">B</p> <p data-bbox="1518 388 1550 413">C</p>
<p data-bbox="162 449 332 474">Insulated helmet</p>  <p data-bbox="771 667 860 684">JPCIA0013ZZ</p>	<p data-bbox="1006 449 1453 504">Removing and installing high voltage components</p>	<p data-bbox="1518 493 1550 518">D</p> <p data-bbox="1518 598 1550 623">E</p>
<p data-bbox="162 701 267 726">Power tool</p>  <p data-bbox="771 919 844 936">PIIB1407E</p>	<p data-bbox="1006 701 1339 726">Loosening nuts, screws and bolts</p>	<p data-bbox="1518 703 1550 728">F</p> <p data-bbox="1518 808 1550 833">G</p> <p data-bbox="1518 913 1550 938">H</p>

DLK

COMPONENT PARTS


< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000010639686



COMPONENT PARTS

< SYSTEM DESCRIPTION >

- A. View with glove box lid removed B. View with front bumper removed C. View with cluster lid C removed
 D. View with rear bumper removed E. View with luggage floor upper finisher removed F. View with rear seat removed

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

No.	Component	Function
1.	VCM	Transmits P position signal to BCM Refer to TM-32, "Component Parts Location" for detailed installation location
2.	Remote keyless entry receiver	DLK-19, "Remote Keyless Entry Receiver"
3.	BCM	BCM detects the vehicle status according to signals from each door switch, each outside/inside key antenna, and unlock sensor. BCM transmits drive signal to door lock actuator when BCM receives operation signal from remote keyless entry receiver and each switch. Refer to BCS-5, "BODY CONTROL SYSTEM : Component Parts Location" for detailed installation location
4.	Intelligent Key warning buzzer	DLK-20, "Intelligent Key Warning Buzzer"
5.	Charge port lid opener actuator	DLK-22, "Charge Port Lid Opener Actuator"
6.	Inside key antenna (instrument center)	DLK-18, "Inside Key Antenna (Instrument Center)"
7.	Power switch	<ul style="list-style-type: none"> Changes power position Inputs power switch ON/OFF condition to BCM Refer to SEC-9, "Component Parts Location" for detailed installation location
8.	Combination meter	<ul style="list-style-type: none"> Displays each operation method guide and warning for system malfunction Performs operation method guide and warning with buzzer Transmits vehicle speed signal to CAN communication line Refer to MWI-6, "METER SYSTEM : Component Parts Location" for detailed installation location
9.	Charge port lid opener switch	DLK-22, "Charge Port Lid Opener Switch"
10.	Main power window and door lock and unlock switch (RH similar)	DLK-20, "Door Lock and Unlock Switch"
11.	Front outside handle LH (outside key antenna)	DLK-19, "Outside Key Antenna (LH)"
12.	Front outside handle LH (request switch)	DLK-20, "Front Door Request Switch (LH)"
13.	Front door lock assembly (LH)	DLK-19, "Front Door Lock Assembly (LH)"
14.	Front door switch LH	DLK-21, "Door Switch"
15.	Back door request switch	DLK-21, "Back Door Request Switch"
16.	Back door opener switch	DLK-21, "Back Door Opener Switch"
17.	Outside antenna (rear bumper)	DLK-18, "Outside Key Antenna (Rear Bumper)"
18.	Back door lock assembly (door opener actuator)	DLK-20, "Back Door Lock Assembly"
19.	Inside key antenna (luggage room)	DLK-18, "Inside Key Antenna (Luggage Room)"
20.	Inside key antenna (rear seat)	DLK-18, "Inside Key Antenna (Rear Seat)"
21.	Front outside handle RH (request switch)	DLK-21, "Front Door Request Switch (RH)"
22.	Front outside handle RH (outside key antenna)	DLK-19, "Outside Key Antenna (RH)"


COMPONENT PARTS

< SYSTEM DESCRIPTION >

Inside Key Antenna (Instrument Center)

INFOID:000000010639687


- Inside key antenna (instrument center) detects that Intelligent Key is within the inside detection area, and then transmits detection status to BCM.
- Inside key antenna (instrument center) is installed in the rear of cluster lid C of instrument center.



Inside Key Antenna (Rear Seat)

INFOID:000000010639688


- Inside key antenna (rear seat) detects that Intelligent Key is within the inside detection area, and then transmits detection status to BCM.
- Inside key antenna (rear seat) is installed underneath rear seat cushion.



Inside Key Antenna (Luggage Room)

INFOID:000000010639689


- Inside key antenna (luggage room) detects that Intelligent Key is within the inside detection area, and then transmits detection status to BCM.
- Inside key antenna (luggage room) is installed in the rear of luggage floor upper finisher.



Outside Key Antenna (Rear Bumper)

INFOID:000000010639690

- Outside key antenna (rear bumper) detects that Intelligent Key is within the outside detection area, and then transmits detection status to BCM. Request signal is transmitted simultaneously to Intelligent Key.
- Outside key antenna (rear bumper) is installed in the rear of rear bumper.




COMPONENT PARTS

< SYSTEM DESCRIPTION >

Outside Key Antenna (LH)

INFOID:0000000110639691


- Outside key antenna (LH) detects that Intelligent Key is within the outside detection area, and then transmits detection status to BCM. Request signal is transmitted simultaneously to Intelligent Key.
- Outside key antenna (LH) is installed in the front outside handle (LH).



Outside Key Antenna (RH)

INFOID:0000000110639692


- Outside key antenna (RH) detects that Intelligent Key is within the outside detection area, and then transmits detection status to BCM. Request signal is transmitted simultaneously to Intelligent Key.
- Outside key antenna (RH) is installed in front outside handle (RH).



Front Door Lock Assembly (LH)

INFOID:0000000110639693


- Door lock actuator and unlock sensor are Integrated in front door lock assembly (LH).
- Door lock actuator receives lock/unlock signal from BCM, and then locks/unlocks LH door.
- Only front door lock assembly (LH) integrates unlock sensor. Unlock sensor transmits lock/unlock status of LH door to BCM.



Remote Keyless Entry Receiver

INFOID:0000000110639694

- Remote keyless entry receiver receives button operation signal and key ID signal of Intelligent Key, and then transmits them to BCM.
- Remote keyless entry receiver is installed in the rear of glove box lid.



A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P


COMPONENT PARTS

< SYSTEM DESCRIPTION >

Intelligent Key Warning Buzzer

INFOID:000000010639695


- Intelligent Key warning buzzer warns the user, who is outside vehicle, of operation confirmation according to Intelligent Key operation and door request switch operation, or of an inappropriate operation.
- Intelligent Key warning buzzer is installed in the rear of front bumper and underneath headlight RH.



Back Door Lock Assembly

INFOID:000000010639696


- Back door lock assembly lock assembly integrates door opener actuator and back door switch.
- Door opener actuator opens the back door according to the door open signal from BCM.
- Back door switch detects open/close status of back door.



Door Lock and Unlock Switch

INFOID:000000010639697


- Door lock and unlock switch transmits door lock/unlock signal operation to BCM.
- Door lock and unlock switch (1) is integrated in the main power window and door lock/unlock switch and power window and door lock/unlock switch RH.



Front Door Request Switch (LH)

INFOID:000000010639698

- Front door request switch (LH) transmits door request switch signal to BCM.
- Front door request switch (LH) (1) is integrated in front outside handle (LH).




COMPONENT PARTS

< SYSTEM DESCRIPTION >

Front Door Request Switch (RH)

INFOID:0000000110639699


- Front door request switch (RH) transmits door request switch signal to BCM.
- Front door request switch (RH) (1) is integrated in front outside handle (RH).



Door Switch

Door switch detects open/close status of door and transmits door switch signal to BCM.


INFOID:0000000110639700



Back Door Request Switch

- Back door request switch transmits back door request switch signal to BCM.
- Back door request switch (1) is integrated in the back door opener switch assembly.


INFOID:0000000110639701



Back Door Opener Switch

- Back door opener switch transmits back door opener switch signal to BCM.
- Back door opener switch (1) is integrated in the back door opener switch assembly.

INFOID:0000000110639702



A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P


COMPONENT PARTS

< SYSTEM DESCRIPTION >

Charge Port Lid Opener Actuator

INFOID:000000010639703


Charge port lid opener actuator ① opens the charge port lid according to the charge port lid open signal from VCM.



Charge Port Lid Opener Switch

INFOID:000000010639704

- When charge port lid opener switch is pressed, charge port lid open operation is detected and charge port lid opener switch signal is transmitted to VCM.
- Charge port lid opener switch is installed on instrument lower panel LH



SYSTEM (POWER DOOR LOCK SYSTEM)


< SYSTEM DESCRIPTION >

SYSTEM (POWER DOOR LOCK SYSTEM)

System Description

INFOID:0000000110639705

SYSTEM DIAGRAM



DOOR LOCK FUNCTION

Door Lock and Unlock Switch

- The door lock and unlock switch (LH) is built into main power window and door lock/unlock switch.
- The door lock and unlock switch (RH) is built into power window and door lock/unlock switch RH.
- Interlocked with the locking operation of door lock and unlock switch, door lock actuators of all doors are locked.
- Interlocked with the unlocking operation of door lock and unlock switch, door lock actuators of all doors are unlocked.

Door Key Cylinder Switch

- With the mechanical key inserted in the door key cylinder on driver side, turning it to lock position, locks door lock actuator of all doors.
- With the mechanical key inserted in the door key cylinder on driver side, turning it to unlock position once unlocks the driver side door, turning it to unlock position again within 5 seconds after the first unlock operation unlocks all of the other doors actuator. (SELECTIVE UNLOCK OPERATION)

Selective unlock operation mode can be changed using CONSULT.

Refer to [BCS-20, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)"](#).

POWER POSITION WARNING FUNCTION

When door lock and unlock switch are operated while driver side door is open and power position is ACC or ON, door locks once but immediately unlocks.

INTERIOR ROOM LAMP CONTROL FUNCTION

Interior room lamp is controlled according to door lock /unlock state. Refer to [INL-9, "INTERIOR ROOM LAMP CONTROL SYSTEM : System Description"](#).

AUTOMATIC DOOR LOCK/UNLOCK FUNCTION (LOCK OPERATION)

The interlock door lock function is the function that locks all doors linked with the vehicle speed or shift position. It has 2 types as per the following items.

Vehicle Speed Sensing Auto Door Lock

All doors are locked when the vehicle speed reaches 24 km/h (15 MPH) or more.

BCM outputs the lock signal to all door lock actuators when it detects that the power switch is turned ON, all doors are closed and the vehicle speed received from the combination meter via CAN communication becomes 24 km/h (15 MPH) or more.

P Position Interlock Door Lock

All doors are locked when shifting the selector lever from the P position to any position other than P.

SYSTEM (POWER DOOR LOCK SYSTEM)

< SYSTEM DESCRIPTION >

BCM outputs the lock signal to all door lock actuators when it detects that the power switch is in the ON position and the shift signal received from the VCM is shifted from the P position to any position other than P.

Setting change of Automatic Door Lock/Unlock Function

The lock operation setting of the automatic door lock/unlock function can be changed.

With CONSULT

The ON/OFF switching of the automatic door lock function and the type selection of the automatic door lock/unlock function can be performed at the “Work support” setting of CONSULT.

Without CONSULT

The automatic door lock function ON/OFF can be switched by performing the following operation:

1. Close all doors (door switch OFF)
2. Power switch: OFF→ON
3. Press and hold the door lock and unlock switch for 5 seconds or more in the lock direction within 20 seconds after turning the power switch ON.
4. The switching complete when the hazard lamp blinks.

OFF → ON : 2 blinks

ON → OFF : 1 blink

AUTOMATIC DOOR LOCK/UNLOCK FUNCTION (UNLOCK OPERATION)

The automatic door lock/unlock function is the function that unlocks all doors linked with the power switch position or shift position. It has 2 types as per the following items:

POWER OFF Interlock Door Unlock

All doors are unlocked when the power switch position is changed from ON to OFF.

BCM outputs the unlock signal to all door lock actuators when it detects that the power switch position is changed from ON to OFF.

P Position Interlock Door Unlock

All doors are unlocked when shifting the selector lever from any position other than P to P position.

BCM outputs the unlock signal to all door lock actuators when it detects that the power switch is in the ON position and the shift signal received from VCM is shifted from any position other than P to P position.

Setting change of Automatic Door Lock/Unlock Function

The unlock operation setting of the automatic door lock/unlock function can be changed.

With CONSULT

The ON/OFF switching of the automatic door lock/unlock function and the type selection of the automatic door lock/unlock function can be performed at the “Work support” setting of CONSULT.

Without CONSULT

The automatic door lock/unlock function ON/OFF can be switched by performing the following operation:

1. Close all doors below (door switch OFF)
2. Power switch: OFF→ON
3. Press and hold the door lock and unlock switch for 5 seconds or more in the unlock direction within 20 seconds after turning the power switch position ON.
4. The switching is complete when the hazard lamp blinks.

OFF → ON : 2 blinks

ON → OFF : 1 blink

SYSTEM (INTELLIGENT KEY SYSTEM)


< SYSTEM DESCRIPTION >

SYSTEM (INTELLIGENT KEY SYSTEM) INTELLIGENT KEY SYSTEM

INTELLIGENT KEY SYSTEM : System Description

INFOID:000000010639706

SYSTEM DIAGRAM



- The Intelligent Key system is a system that makes it possible to lock and unlock the door locks (door lock/unlock function) by carrying the Intelligent Key, which operates based on the results of electronic ID verification using two-way communication between the Intelligent Key and the vehicle (BCM).

NOTE:

- The driver should always carry the Intelligent Key.
- The settings for each function can be changed with CONSULT.
- If an Intelligent Key is lost, a new Intelligent Key can be registered. A maximum of 4 Intelligent Keys can be registered.
- It is possible to perform a diagnosis on the system and register an Intelligent Key with CONSULT.

Function	Description	Refer
Door lock	Lock/unlock can be performed by pressing the request switch	DLK-26
Back door opener	The back door can be opened by carrying the Intelligent Key and pressing the back door opener switch	DLK-28
Remote keyless entry	Lock/unlock can be performed by pressing the remote controller button of the Intelligent Key	DLK-30

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

SYSTEM (INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >


Function	Description	Refer
Key reminder	The key reminder buzzer sounds a warning if the door is locked with the key left inside the vehicle	DLK-32
Warning	If an action that does not meet the operating condition of the Intelligent Key system is taken, the buzzer sounds to inform the driver	DLK-33
READY set function	The vehicle can be set READY while carrying the Intelligent Key	SEC-12
Panic alarm	When Intelligent Key panic alarm button is pressed, horn sounds	SEC-18
Interior room lamp control	Interior room lamp is controlled according to door lock/unlock state	INL-9
Charge connector unlock	Charge connector unlock can be performed by a long press of the charge port lid opener button on the Intelligent Key	EVC-62
Charge port lid open	Charge port lid open can be performed by a long press of the charge port lid opener button on the Intelligent Key	EVC-62

DOOR LOCK FUNCTION

DOOR LOCK FUNCTION : System Description

INFOID:0000000110639707

SYSTEM DIAGRAM



DOOR REQUEST SWITCH OPERATION

When pressing the door request switch, it is possible to lock and unlock the door by carrying the Intelligent Key.

OPERATION DESCRIPTION

- When the BCM detects that each door request switch is pressed, it activates the outside key antenna and inside key antenna corresponding to the pressed door request switch and transmits the request signal to the Intelligent Key. And then, check that the Intelligent Key is near the door.
- If the Intelligent Key is within the outside key antenna detection area, it receives the request signal and transmits the key ID signal to the BCM via remote keyless entry receiver.
- BCM receives the key ID signal and compares it with the registered key ID.
- BCM transmits door lock/unlock signal and operates each door lock actuator. At the same time, BCM blinks hazard warning lamp (lock: 2 times, unlock: 1 time) and sounds Intelligent Key buzzer (lock: 2 times, unlock: 1 time) as a reminder.

SYSTEM (INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

OPERATION CONDITION


If the following conditions are satisfied, door lock/unlock operation is performed if the door request switch is operated:

Each door request switch operation	Operation condition
Lock	<ul style="list-style-type: none"> • All doors are closed • Panic alarm is not activated • Power switch is in the OFF position • Intelligent Key is outside the vehicle • Intelligent Key is within outside key antenna detection area *
Unlock	<ul style="list-style-type: none"> • Power switch is in the OFF position • Intelligent Key is outside the vehicle • Intelligent Key is within outside key antenna detection area *

*: Even with a registered Intelligent Key remaining inside the vehicle, door locks can be locked and unlocked from outside of the vehicle with a spare Intelligent Key as long as key IDs are different.

OUTSIDE KEY ANTENNA DETECTION AREA

The outside key antenna detection area of door lock/unlock function is in the range of approximately 80 cm (31.50 in) surrounding the driver, passenger door handles (1) and back door handle (2). However, this operating range depends on the ambient conditions.



SELECTIVE UNLOCK FUNCTION

Lock Operation

When a LOCK signal is sent from door request switch (LH, RH or back door), all doors are locked.

Unlock Operation

- When an UNLOCK signal from front door request switch (LH) is transmitted, LH door unlocks. When another UNLOCK signal is transmitted within 60 seconds, all door unlocks.
- When an UNLOCK signal from front door request switch (RH) is transmitted, RH door unlocks. When another UNLOCK signal is transmitted within 60 seconds, all door unlocks.
- When an UNLOCK signal from back door request switch is transmitted, back door unlocks. When another UNLOCK signal is transmitted within 60 seconds, all door unlocks.

How to Change Selective Unlock Operation Mode

Selective unlock operation mode can be changed using CONSULT.

Refer to [BCS-20, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)"](#).

HAZARD AND BUZZER REMINDER FUNCTION

During lock, unlock, operation by each request switch, the hazard warning lamps and Intelligent Key warning buzzer will blink or honk as a reminder.

When doors are locked, unlocked by each request switch, BCM honks Intelligent Key warning buzzer as a reminder and blinks.

Operating Function of Hazard and Buzzer Reminder

Operation	Hazard warning lamp blinks	Intelligent Key warning buzzer honk
Unlock	Once	Once
Lock	Twice	Twice

Hazard and buzzer reminder does not operate if power switch ON position.

How to Change Hazard and Buzzer Reminder Operation Mode

Hazard and buzzer reminder operation mode can be changed using CONSULT.

Refer to [BCS-20, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)"](#).

SYSTEM (INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

AUTO DOOR LOCK FUNCTION

After door is unlocked by door request switch operation and if 60 seconds or more passes without performing the following operation, all doors are automatically locked. However, operation check function does not activate.

Operating condition	<ul style="list-style-type: none"> • Door switch is ON (door is open) • Door is locked • Power switch is pressed
---------------------	---

Auto door lock mode can be changed by the "AUTO LOCK SET" in "Work support". Refer to [BCS-20, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)"](#).

LIST OF OPERATION RELATED PARTS

Parts marked with × are the parts related to operation.


Door lock function	Intelligent Key	Remote keyless entry receiver	Door switch	Door request switch	Door lock actuator	Inside key antenna	Outside key antenna	CAN communication system	BCM	Hazard warning lamp	Power switch	Combination meter
Door lock/unlock function	×	×	×	×	×	×	×		×			
Hazard reminder function								×	×	×		×
Door lock status indicator operation									×			
Selective unlock function	×			×	×	×	×		×			
Auto door lock function	×				×				×		×	

BACK DOOR OPEN FUNCTION

BACK DOOR OPEN FUNCTION : System Description

INFOID:0000000110639708

SYSTEM DIAGRAM



BACK DOOR OPEN OPERATION

This section describes the operation of the back door opener switch. The operation of the back door opener request switch is the same as the door lock function. Refer to [DLK-36, "System Description"](#).

SYSTEM (INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

- The back door open function can open the back door by pressing the back door opener switch while carrying the Intelligent Key and all doors are locked.
- The back door open function enables the back door to be opened by pressing back door opener switch after BCM transmits UNLOCK signal to each door.

BACK DOOR OPEN

- When the BCM detects that back door opener switch is pressed, it starts the outside key antenna (rear bumper) and inside key antenna and transmits the request signal to the Intelligent Key. Then, check that the Intelligent Key is near the back door.
- If the Intelligent Key is within the outside key antenna detection area, it receives the request signal and transmits the key ID signal to the BCM via remote keyless entry receiver.
- BCM receives the key ID signal and compares it with the registered key ID.
- BCM opens back door and simultaneously unlocks all doors.

NOTE:

In selective unlock mode, only back door opens. All doors do not unlock.


OPERATION CONDITION

If the following conditions are satisfied, the back door can be opened:

Back door open function	Operation condition
Back door open operation	<ul style="list-style-type: none"> • Vehicle speed is less than 5 km/h (3 MPH) • Panic alarm is not activated • Intelligent Key is outside of vehicle • Intelligent Key is within outside key antenna detection area • Back door is closed

OUTSIDE KEY ANTENNA DETECTION AREA

The outside key antenna detection area of back door open function is in the range of approximately 80 cm (31.50 in) surrounding the back door opener switch (1). However, this operating range depends on the ambient conditions.



LIST OF OPERATION RELATED PARTS

Parts marked with × are the parts related to operation.

Back door open function	Intelligent Key	Remote keyless entry receiver	Back door opener actuator	Door lock actuator	Inside key antenna	Outside key antenna (rear bumper)	CAN communication system	BCM	Back door opener switch	Combination meter
Back door open function	×	×	×	×	×	×	×	×	×	×

REMOTE KEYLESS ENTRY FUNCTION


SYSTEM (INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

REMOTE KEYLESS ENTRY FUNCTION : System Description

INFOID:0000000110639709

SYSTEM DIAGRAM



BASIC OPERATION

The Intelligent Key has the same functions as the remote control entry system. Therefore, it can be used in the same manner as the remote controller by operating the door lock/unlock button.

OPERATION

Remote keyless entry system controls operation of the following items:

- Door lock/unlock
- Selective Unlock function
- Hazard reminder function
- Auto door lock

OPERATION AREA

To check that the Intelligent Key works normally, use within 1 m (3 ft) range of each doors, however the operable range may differ according to surroundings.

DOOR LOCK/UNLOCK FUNCTION

- When door lock/unlock button of the Intelligent Key is pressed, lock signal or unlock signal transmitted from Intelligent Key to BCM via remote keyless entry receiver.
- BCM receives the signal and compares it with the registered key ID to the vehicle.
- When BCM receives the door lock/unlock signal, it operates all door lock actuators and the hazard lamp (lock: 2 time, unlock: 1 times) and horn chirp signal to IPDM E/R at the same time as a reminder.
- IPDM E/R honks horn (lock: 1 times) as a reminder.

OPERATION CONDITION

If the following condition are satisfied, remote keyless entry operation is performed when the Intelligent Key is operated:

Remote controller operation	Operation condition
Lock / Unlock	Panic alarm is not activated

SELECTIVE UNLOCK FUNCTION

- When an LOCK signal is transmitted from Intelligent Key, all doors are locked.
- When an UNLOCK signal is transmitted from Intelligent Key once, driver side door is unlocked.
- Then, if an UNLOCK signal is transmitted from Intelligent Key again within 60 seconds, all other doors are unlocked.

How To Change Selective Unlock Operation Mode

Selective unlock operation mode can be changed using CONSULT.

Refer to [BCS-20. "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)".](#)

HAZARD AND HORN REMINDER FUNCTION

SYSTEM (INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

When doors are locked or unlocked by Intelligent Key, BCM blinks hazard warning lamps as a reminder and transmits horn chirp signal to IPDM E/R. IPDM E/R sounds horn as a reminder. The hazard and horn reminder has a horn chirp mode (C mode) and a non-horn chirp mode (S mode).

Operating Function of Hazard and Horn Reminder

	C mode			S mode		
	Lock	Unlock	Back door open	Lock	Unlock	Back door open
Intelligent Key operation	Lock	Unlock	Back door open	Lock	Unlock	Back door open
Hazard warning lamp blinks	Twice	Once	—	Twice	—	—
Horn sound	Once	—	—	—	—	—

Hazard and horn reminder does not operate if power switch ON position.


How to change hazard and horn reminder mode

📖 With CONSULT

Refer to [BCS-20, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)"](#).

⊗ Without CONSULT

When LOCK and UNLOCK signals are sent from the Intelligent Key for more than 2 seconds at the same time, the hazard and horn reminder mode is changed and hazard warning lamp blinks and horn sounds as per the following items:



AUTO DOOR LOCK FUNCTION

After door is unlocked by Intelligent Key button operation and if 60 seconds or more passes without performing the following operation, all doors are locked. However, operation check function does not activate.

Operating condition	<ul style="list-style-type: none"> • Door switch is ON (door is open) • Door is locked • Power switch is pressed
---------------------	---

How To Change Auto Door Lock Operation Mode

Auto door lock operation mode can be changed using CONSULT.

Refer to [BCS-20, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)"](#).

LIST OF OPERATION RELATED PARTS

Parts marked with × are the parts related to operation.

Remote keyless entry functions	Intelligent Key	Door switch	Door lock actuator	Power switch	Intelligent Key warning buzzer	CAN communication system	BCM	Combination meter	Hazard warning lamp	IPDM E/R
Door lock/unlock function by remote control button	×	×	×			×	×			
Hazard reminder function	×			×	×	×	×	×	×	×

SYSTEM (INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >


	Intelligent Key	Door switch	Door lock actuator	Power switch	Intelligent Key warning buzzer	CAN communication system	BCM	Combination meter	Hazard warning lamp	IPDM E/R
Remote keyless entry functions										
Selective Unlock function	×	×	×	×		×	×			
Auto door lock function	×					×	×			

KEY REMINDER FUNCTION

KEY REMINDER FUNCTION : System Description

INFOID:000000010639710

SYSTEM DIAGRAM



BASIC OPERATION

Key reminder is the function that prevents the key from being left in the vehicle.

Key reminder has the following 3 functions:

Key remainder function	Operation condition	Operation
Driver side door closed*	Right after driver side door is closed under the following conditions <ul style="list-style-type: none"> Intelligent Key is inside the vehicle Driver side door is opened Driver side door is in unlock state 	All doors unlock
Door is open or closed	Right after all doors are closed under the following conditions <ul style="list-style-type: none"> Intelligent Key is inside the vehicle Any door is opened All doors are locked. 	<ul style="list-style-type: none"> All doors unlock Honk Intelligent Key warning buzzer
Back door is closed	Right after back door is closed under the following conditions <ul style="list-style-type: none"> Intelligent Key is inside the vehicle All doors (except back door) are closed All doors (except back door) are locked 	<ul style="list-style-type: none"> All doors unlock Back door can open with back door opener switch Honk Intelligent Key warning buzzer

*:If the door closing impact shocks the door lock knob, or contacts against baggage with the door lock knob might activate the door locks accidentally but unlock operation is perform in these cases.

NOTE:

- The above function operates when the Intelligent Key is inside the vehicle. However, there may be times when the Intelligent Key cannot be detected, and this function does not operate when the Intelligent Key is

SYSTEM (INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

on the instrument panel, rear parcel shelf, or in the glove box. Also, this system sometimes does not operate if the Intelligent Key is in the door pocket for the open door.

WARNING FUNCTION

WARNING FUNCTION : System Description

INFOID:000000010639711

OPERATION DESCRIPTION

The warning function are as per the following items and are given to the user as warning information and warnings using combinations of Intelligent Key warning buzzer, combination meter buzzer and information display in combination meter:

- Intelligent Key system malfunction
- OFF position warning
- Take away warning
- Door lock operation warning
- Key ID warning
- READY set information
- Plug in information
- Intelligent Key low battery warning
- Key ID verification information

OPERATION CONDITION

Once the following condition from below is established, alert or warning is executed:

Warning/Information functions		Operation procedure
Intelligent Key system malfunction		When a malfunction is detected on BCM
OFF position warning		When condition A, B or condition C is satisfied <ul style="list-style-type: none"> • Condition A <ul style="list-style-type: none"> - Power switch: ACC position - Door switch (driver side): ON (Door is open) • Condition B <ul style="list-style-type: none"> - Turn power switch from ON to OFF while door is open • Condition C <ul style="list-style-type: none"> - Intelligent Key backside is contacted to power switch while brake pedal is depressed and power switch is LOCK or OFF (When the Intelligent Key battery is discharged) - Door switch (driver side): ON (Door is open)
Take away warning	Door is open to close	<ul style="list-style-type: none"> • Power switch: Except LOCK position • Door switch: ON to OFF (Door is open to close) • Intelligent Key cannot be detected inside the vehicle
	Door is open	<ul style="list-style-type: none"> • Power switch: Except LOCK position • Door switch: ON (Door is open) • Key ID verification every 5 seconds when registered Intelligent Key cannot be detected inside the vehicle
	Power switch operation	<ul style="list-style-type: none"> • Power switch: Except LOCK position • Press power switch • Intelligent Key cannot be detected inside the vehicle
Door lock operation warning		When door lock operation is requested while door lock operating condition of door request switch or Intelligent Key are not satisfied
Key ID warning		When registered Intelligent Key cannot be detected inside the vehicle after Power switch is turned ON
READY set information*	Power switch is ON position	<ul style="list-style-type: none"> • Power switch: ON position • Electric shift selector position: P position • The vehicle is not READY • When charge port is not connected
	Power switch is except ON position	<ul style="list-style-type: none"> • Power switch: Except ON position • Electric shift selector position: P position • Intelligent Key is detected inside the vehicle after driver door is open and then closed • When charge port is not connected

SYSTEM (INTELLIGENT KEY SYSTEM)





< SYSTEM DESCRIPTION >

Warning/Information functions	Operation procedure
Plug in indicator*	When charge port is connected
Intelligent Key low battery warning	When Intelligent Key is low battery, BCM is detected after power switch is turned ON
Key ID verification information	<ul style="list-style-type: none"> • When registered Intelligent Key can not be detected inside the vehicle • Intelligent Key battery is discharged • When NATS antenna amp cannot be detected NATS ID

*:One of either item is displayed according to connection status of charge port connector.




WARNING METHOD

The following table shows the alarm or warning methods with chime:
Information display (combination meter) when the warning conditions are met.

Warning/Information functions		Information display (combination meter)	Warning chime	
			Combination meter buzzer	Intelligent Key warning buzzer
Intelligent Key system malfunction		 I-Key system fault <small>JMKIA5196ZZ</small>	—	—
OFF position warning		—	Sounds (beeps continuously)	—
Take away warning	Door is open to close	 Key is not detected <small>JMKIA5192ZZ</small>	Sounds (beeps 3 times)	Sounds (beeps 1 time)
	Door is open		—	—
	Power switch operation		Sounds (beeps 3 times)	—
Door lock operation warning	Request switch operation	—	—	Sounds (for 2 seconds)
	Intelligent Key operation	—	—	Sounds (for 2 seconds)
Key ID warning		 Key is not detected <small>JMKIA5192ZZ</small>	—	—
READY set information		 Brake <small>JMKIA6134GB</small>	—	—

SYSTEM (INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

Warning/Information functions	Information display (combination meter)	Warning chime	
		Combination meter buzzer	Intelligent Key warning buzzer
Plug in indicator	 <small>JMKIA6370GB</small>	—	—
Intelligent Key low battery warning	 <small>JMKIA3049ZZ</small>	—	—
Key ID verification information	 <small>JMKIA4907ZZ</small>	—	—

LIST OF OPERATION RELATED PARTS

Parts marked with × are the parts related to operation.

Warning function		Intelligent Key	Power switch	Door switch	Door request switch	Inside key antenna	Outside key antenna	Intelligent Key warning buzzer	Combination meter buzzer	CAN communication system	BCM	Information display
Intelligent Key system malfunction										×	×	×
OFF position warning				×					×	×	×	
Take away warning	Door is open or close	×		×		×		×	×	×	×	×
	Door is open	×		×		×				×	×	×
	Power switch operation	×	×			×			×	×	×	×
Door lock operation warning		×		×	×	×	×	×			×	
Key ID warning			×			×				×	×	×
READY set information	Power switch is ON position	×	×			×				×	×	×
	Power switch is except ON position	×	×			×				×	×	×
Plug in indicator												×
Intelligent Key low battery warning		×				×				×	×	×
Key ID verification information		×				×				×	×	×

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

SYSTEM (BACK DOOR OPENER SYSTEM)


< SYSTEM DESCRIPTION >

SYSTEM (BACK DOOR OPENER SYSTEM)

System Description

INFOID:000000010639712

SYSTEM DIAGRAM



BACK DOOR OPENER OPERATION

When back door opener switch is pressed, BCM operates back door opener actuator.

NOTE:

Back door opener actuator is not for locking the back door. The function is only to open the back door.

OPERATION CONDITION

If the following conditions are satisfied, back door opener operation is performed:

Back door opener switch operation	Operation condition
Back door open	<ul style="list-style-type: none"> When back door opener switch is pressed while all doors are in unlock status. Vehicle speed is less than 5 km/h (3 MPH)

NOTE:

- When 12V battery terminal is disconnected and reconnected during all doors unlock state, back door may not open.
- Regardless of door lock actuator state, BCM resets recognition of all doors unlock state approximately 30 seconds after 12V battery terminal is disconnected and BCM recognizes that all doors are in lock state.
- When 12V battery terminal is reconnected and back door does not open, have BCM recognize that all doors are in unlock state.

SYSTEM (HOMELINK UNIVERSAL TRANSCEIVER)

< SYSTEM DESCRIPTION >

SYSTEM (HOMELINK UNIVERSAL TRANSCEIVER)

System Description

INFOID:000000010639713

Item	Function
HomeLink® Universal Transceiver	A maximum of 3 radio signals can be stored and transmitted to operate the garage door, etc.

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DLK

SYSTEM (CHARGE PORT LID OPEN CONTROL)

< SYSTEM DESCRIPTION >

SYSTEM (CHARGE PORT LID OPEN CONTROL)

System Description

INFOID:000000010639714

OPERATION DESCRIPTION

Charge port lid open can be performed by pressing the charge port lid opener button or charge port lid opener switch. Refer to [EVC-62, "CHARGE PORT CONTROL : System Description"](#).

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000010639715

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Direct Diagnostic Mode	Description
Ecu Identification	The BCM part number is displayed.
Self Diagnostic Result	The BCM self diagnostic results are displayed.
Data Monitor	The BCM input/output data is displayed in real time.
Active Test	The BCM activates outputs to test components.
Work support	The settings for BCM functions can be changed.
Configuration	<ul style="list-style-type: none"> The vehicle specification can be read and saved. The vehicle specification can be written when replacing BCM.
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

SYSTEM APPLICATION

BCM can perform the following functions.

System	Sub System	Direct Diagnostic Mode						
		Ecu Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
Door lock	DOOR LOCK		×	×	×	×		
Rear window defogger	REAR DEFOGGER			×	×			
Warning chime	BUZZER			×	×			
Interior room lamp timer	INT LAMP			×	×	×		
Exterior lamp	HEADLAMP			×	×	×		
Wiper and washer	WIPER			×	×	×		
Turn signal and hazard warning lamps	FLASHER			×	×	×		
Air conditioner	AIR CONDITIONER			×	×			
Intelligent Key system	INTELLIGENT KEY		×	×	×	×		
Combination switch	COMB SW			×				
BCM	BCM	×	×			×	×	×
Immobilizer	IMMU		×	×	×	×		
Interior room lamp battery saver	BATTERY SAVER			×	×	×		
Trunk open	TRUNK			×				
Vehicle security system	THEFT ALM			×	×	×		
RAP system	RETAINED PWR			×				
Signal buffer system	SIGNAL BUFFER			×				
TPMS	AIR PRESSURE MONITOR		×	×	×	×		

DOOR LOCK

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

DOOR LOCK : CONSULT Function (BCM - DOOR LOCK)

INFOID:000000010639716

SELF DIAGNOSTIC RESULT

Refer to [BCS-48, "DTC Index"](#).

DATA MONITOR

Monitor Item [Unit]	Description
REQ SW-DR [On/Off]	Indicates condition of door request switch LH.
REQ SW-AS [On/Off]	Indicates condition of door request switch RH.
REQ SW-BD/TR [On/Off]	Indicates condition of back door request switch.
DOOR SW-DR [On/Off]	Indicates condition of front door switch LH.
DOOR SW-AS [On/Off]	Indicates condition of front door switch RH.
DOOR SW-RR [On/Off]	Indicates condition of rear door switch RH.
DOOR SW-RL [On/Off]	Indicates condition of rear door switch LH.
DOOR SW-BK [On/Off]	Indicates condition of trunk switch.
CDL LOCK SW [On/Off]	Indicates condition of lock signal from door lock and unlock switch.
CDL UNLOCK SW [On/Off]	Indicates condition of unlock signal from door lock and unlock switch.
KEY CYL LK-SW [On/Off]	Indicates condition of lock signal from door key cylinder switch.
KEY CYL UN-SW [On/Off]	Indicates condition of unlock signal from door key cylinder switch.

ACTIVE TEST

Test Item	Description
DOOR LOCK	This test is able to check door lock operation [ALL LOCK/ALL UNLK/DR UNLK/AS UNLK/OTR ULK].

WORK SUPPORT

Support Item	Setting	Description
DOOR LOCK-UNLOCK SET	On*	Selective unlock function ON.
	Off	Selective unlock function OFF.
AUTOMATIC LOCK/UNLOCK SELECT	Lock/Unlock*	Automatic door lock and unlock functions ON.
	Lock Only	Automatic door lock only function ON.
	Unlock Only	Automatic door unlock only function ON.
	Off	Automatic door lock function OFF.
AUTOMATIC DOOR LOCK SELECT	P RANGE	Doors lock automatically when shifted out of P (park).
	VH SPD	Doors lock automatically when vehicle speed is greater than 24 km/h (15 mph).
AUTOMATIC DOOR UNLOCK SELECT	MODE6	This mode is not used.
	MODE5	This mode is not used.
	MODE4	Driver door is unlocked automatically when shifted into P (park).
	MODE3	Driver door is unlocked automatically when ignition is switched from ON to OFF.
	MODE2	All doors unlock automatically when shifted into P (park).
MODE1*	All doors unlock automatically when ignition is switched from ON to OFF.	

*: Initial setting

INTELLIGENT KEY

INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY)

INFOID:000000010639717

SELF DIAGNOSTIC RESULT

Refer to [BCS-48, "DTC Index"](#).

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

DATA MONITOR

Monitor Item [Unit]	Main	Description
REQ SW -DR [On/Off]	×	Indicates condition of door request switch LH.
REQ SW -AS [On/Off]	×	Indicates condition of door request switch RH.
REQ SW -BD/TR [On/Off]	×	Indicates condition of back door request switch.
PUSH SW [On/Off]		Indicates condition of power switch.
BRAKE SW 1 [On/Off]	×	Indicates condition of brake switch.
BRAKE SW 2 [On/Off]		Indicates condition of brake switch.
DETE/CANCL SW [On/Off]	×	Indicates condition of P (park) position.
SFT PN/N SW [On/Off]	×	Indicates condition of P (park) or N (neutral) position.
UNLK SEN -DR [On/Off]	×	Indicates condition of door unlock sensor.
PUSH SW -IPDM [On/Off]		Indicates condition of power switch received from IPDM E/R on CAN communication line.
IGN RLY1 -F/B [On/Off]		Indicates condition of ignition relay 1 received from IPDM E/R on CAN communication line.
DETE SW -IPDM [On/Off]		Indicates condition of detent switch received from TCM on CAN communication line.
SFT P -MET [On/Off]		Indicates condition of P (park) position from TCM on CAN communication line.
SFT N -MET [On/Off]		Indicates condition of N (neutral) position from IPDM E/R on CAN communication line.
ENGINE STATE [Stop/Start/Crank/Run]	×	Indicates condition of engine state from ECM on CAN communication line.
VEH SPEED 1 [mph/km/h]	×	Indicates condition of vehicle speed signal received from ABS on CAN communication line.
VEH SPEED 2 [mph/km/h]	×	Indicates condition of vehicle speed signal received from combination meter on CAN communication line.
DOOR STAT -DR [LOCK/READY/UNLK]	×	Indicates condition of driver side door status.
DOOR STAT -AS [LOCK/READY/UNLK]	×	Indicates condition of passenger side door status.
ID OK FLAG [Set/Reset]		Indicates condition of Intelligent Key ID.
PRMT ENG STRT [Set/Reset]		Indicates condition of engine start possibility.
RKE OPE COUN1 [0-19]	×	When remote keyless entry receiver receives the signal transmitted while operating the Intelligent Key, the numerical value starts changing.
RKE-LOCK [On/Off]		Indicates condition of lock signal from Intelligent Key.
RKE-UNLOCK [On/Off]		Indicates condition of unlock signal from Intelligent Key.
RKE-PANIC [On/Off]		Indicates condition of panic signal from Intelligent Key.
RKE-MODE CHG [On/Off]		Indicates condition of mode change signal from Intelligent Key.

ACTIVE TEST

Test Item	Description
INSIDE BUZZER	This test is able to check combination meter warning chime operation [Off/Take Out/Knob/Key].

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Test Item	Description	
LCD	B&P N	This test is able to check combination meter traction motor start information.
	B&P I	
	ID NG	This test is able to check combination meter key ID warning information.
	ROTAT	This item is displayed, but is not used.
	SFT P	
	INSRT	
	BATT	This test is able to check combination meter Intelligent Key low battery warning information.
	NO KY	This item is displayed, but is not used.
	OUTKEY	This test is able to check combination meter take away warning information.
	LK WN	This test is able to check combination meter OFF position warning information.
	Off	—
BATTERY SAVER	This test is able to check interior room lamp battery saver operation [Off/On].	
ENGINE SW ILLUMI	This test is able to check power switch illumination operation [Off/On].	
PUSH SWITCH INDICATOR	This test is able to check power switch ACC/ON indicator operation [Off/On].	
TRUNK/BACK DOOR	This test is able to check back door opener actuator operation [Open].	
INT LAMP	This test is able to check interior room lamp operation [Off/On].	
INDICATOR	This test is able to check combination meter warning lamp operation [Off/KEY ON/KEY IND].	
FLASHER	This test is able to check security hazard lamp operation [RH/LH/Off].	
OUTSIDE BUZZER	This test is able to check Intelligent Key warning buzzer operation [On/Off].	
HORN	This test is able to check horn operation [On].	

WORK SUPPORT

Support Item	Setting	Description
LOCK/UNLOCK BY I-KEY	On*	Door lock/unlock function from request switch ON.
	Off	Door lock/unlock function from request switch OFF.
ANTI KEY LOCK IN-FUNCTI	On*	Key reminder function ON.
	Off	Key reminder function OFF.
ANS BACK I-KEY UNLOCK	On*	Buzzer reminder function when doors are unlocked with request switch ON.
	Off	Buzzer reminder function when doors are unlocked with request switch OFF.
ANS BACK I-KEY LOCK	Horn Chirp	Horn chirp reminder function when doors are locked with request switch.
	Buzzer*	Buzzer reminder function when doors are locked with request switch.
	Off	No reminder function when doors are locked with request switch.
HORN WITH KEYLESS LOCK	On*	Horn reminder function when doors are locked with Intelligent Key ON.
	Off	Horn reminder function when doors are locked with Intelligent Key OFF.
HAZARD ANSWER BACK	Lock/Unlock*	Horn reminder function when doors are locked or unlocked with request switch or Intelligent Key.
	Unlock Only	Horn reminder function when doors are unlocked with request switch or Intelligent Key.
	Lock Only	Horn reminder function when doors are locked with request switch or Intelligent Key.
	Off	Horn reminder function when doors are locked or unlocked with request switch or Intelligent Key OFF.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Support Item	Setting	Description	
INSIDE ANT DIAGNOSIS	—	This function allows inside key antenna self-diagnosis.	A
CONFIRM KEY FOB ID	MEMORY 1	Intelligent Key ID code can be checked.	B
	MEMORY 2		
	MEMORY 3		
	MEMORY 4		
	NON REGIST		
PANIC ALARM SET	MODE 3	1.5 sec.	D
	MODE 2	OFF	
	MODE 1*	0.5 sec.	
AUTO LOCK SET	MODE7	5 min.	E
	MODE6	4 min.	
	MODE5	3 min.	
	MODE4	2 min.	
	MODE3*	1 min.	
	MODE2	30 sec.	
	MODE1	OFF	
		F	
		G	

*: Initial Setting

TRUNK

TRUNK : CONSULT Function (BCM - TRUNK)

INFOID:0000000010639718

DATA MONITOR

Monitor Item [Unit]	Description	
PUSH SW [On/Off]	Indicates condition of power switch.	J
UNLK SEN -DR [On/Off]	Indicates condition of door unlock sensor.	
VEH SPEED 1 [km/h]	Indicates vehicle speed signal received from ABS on CAN communication line.	
TR/BD OPEN SW [On/Off]	Indicates condition of back door opener switch.	DLK

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

BCM

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION

BCM

List of ECU Reference

INFOID:0000000010639719

ECU	Reference
BCM	BCS-28. "Reference Value"
	BCS-46. "Fail-safe"
	BCS-47. "DTC Inspection Priority Chart"
	BCS-48. "DTC Index"

DOOR & LOCK SYSTEM


< WIRING DIAGRAM >

WIRING DIAGRAM

DOOR & LOCK SYSTEM

Wiring Diagram

INFOID:000000010639720




A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK

DOOR & LOCK SYSTEM


< WIRING DIAGRAM >



AAKWA0828GB

DOOR & LOCK SYSTEM


< WIRING DIAGRAM >



A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DOOR & LOCK SYSTEM

< WIRING DIAGRAM >




AAKWA0830GB

DOOR & LOCK SYSTEM

< WIRING DIAGRAM >


DOOR LOCK SYSTEM - CONNECTORS

Connector No.	M4
Connector Name	DATA LINK CONNECTOR
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6	L	-
14	P	-

Connector No.	M10
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4A	LG	-
5A	V	-
10A	BR	-
11A	Y	-
12A	B	-
36A	B	-
37A	P	-
38A	Y	-
39A	LG	-

Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4C	G	-
5C	V	-
13C	B	-
36C	LG	-
37C	R	-
38C	GR	-
39C	W	-
40C	P	-
41C	V	-
47C	Y	-
48C	BR	-

Connector No.	M18
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	G	-
6	V	-

AAKIA1979GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK

DOOR & LOCK SYSTEM

< WIRING DIAGRAM >

Terminal No.	Color of Wire	Signal Name
27	Y	-
31	L	-
32	P	-

Connector No.	M21
Connector Name	WIRE TO WIRE
Connector Color	WHITE



16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
32	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17

Terminal No.	Color of Wire	Signal Name
11	P	-
12	V	-
26	W	-

Connector No.	M19
Connector Name	WIRE TO WIRE
Connector Color	WHITE



7	6	5	4	3	2	1		
16	15	14	13	12	11	10	9	8

Terminal No.	Color of Wire	Signal Name
4	GR	-
5	GR	-
6	W	-

Connector No.	M23
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90
91	92	93	94	95	96	97	98	99	100	101	102	103	104	105	106	107	108	109	110

Terminal No.	Color of Wire	Signal Name
75	LG	REQUEST SW (DR)
76	SB	ENGINE START SW
78	P	DOOR ANTENNA (DR) +
79	V	DOOR ANTENNA (DR) -
80	LG	DOOR ANTENNA (AS) +
81	Y	DOOR ANTENNA (AS) -

Terminal No.	Color of Wire	Signal Name
82	W	BACK DOOR ANTENNA +
83	B	BACK DOOR ANTENNA -
84	BR	ROOM ANTENNA 1 +
85	Y	ROOM ANTENNA 1 -
86	G	ROOM ANTENNA 2 +
87	R	ROOM ANTENNA 2 -
88	G	ROOM ANTENNA 3 +
89	R	ROOM ANTENNA 3 -
93	GR	SMART KEYLESS BUZZER OUTPUT
97	LG	STARTER RELAY OUTPUT
100	P	REQUEST SW (AS)
102	BG	SHIFT N, P

AAKIA1980GB


DOOR & LOCK SYSTEM

< WIRING DIAGRAM >


Terminal No.	Color of Wire	Signal Name
30	V	TRUNK/BACK DOOR OPENER SW
31	W	DOOR LOCK STATUS SW (DR)
37	V	SHIFT P POSITION, PARKING POSITION SW
38	SB	INTELLIGENT TUNER
39	L	CAN-H
40	P	CAN-L

Terminal No.	Color of Wire	Signal Name
7	GR	KEY CYLINDER UNLOCK SW
8	R	KEY CYLINDER LOCK SW
12	Y	CENTRAL DOOR LOCK SW
13	BR	CENTRAL DOOR UNLOCK SW
18	L	KEYLESS TUNER, AUTO LIGHT SENSOR GND


Connector No.	M24
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Connector No.	M33
Connector Name	POWER SWITCH
Connector Color	WHITE




Connector No.	M29
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
4	B	-
8	SB	-

Terminal No.	Color of Wire	Signal Name
43	Y	DOOR SW (BACK)
45	BR	DOOR SW (AS)
46	R	DOOR SW (RR)
47	SB	DOOR SW (DR)
48	W	DOOR SW (RL)
51	P	REQUEST SW (TRUNK/BACK DOOR)
53	GR	TRUNK/BACK DOOR OPEN OUTPUT
55	G	DOOR UNLOCK OUTPUT (RR, RL)

Connector No.	M25
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
57	P	BATTERY (FUSE)
59	LG	DOOR UNLOCK OUTPUT (AS)
60	V	FLASHER OUTPUT (LEFT)
61	R	FLASHER OUTPUT (RIGHT)
63	BR	ROOM LAMP OUTPUT
65	V	DOOR LOCK OUTPUT
66	G	DOOR UNLOCK COMMON (DR)
67	B	GND
70	Y	BATTERY (F/L)

AAKIA1981GB


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK

DOOR & LOCK SYSTEM


< WIRING DIAGRAM >

Connector No.	M41
Connector Name	JOINT CONNECTOR-M06
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
9	L	-
10	L	-
19	P	-
20	P	-

Connector No.	M40
Connector Name	JOINT CONNECTOR-M05
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
5	L	-
8	L	-
9	L	-
10	L	-
11	LG	-
12	LG	-
15	P	-
18	P	-
19	P	-
20	P	-

Connector No.	M34
Connector Name	COMBINATION METER
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	LG	BAT
3	GR	IGN
5	B	GND 1 (ILL)
6	B	GND 2 (POWER)
18	P	CAN-L
19	L	CAN-H

Connector No.	M46
Connector Name	JOINT CONNECTOR-CM07
Connector Color	ORANGE




Terminal No.	Color of Wire	Signal Name
19	SB	-
20	SB	-

Connector No.	M44
Connector Name	JOINT CONNECTOR-M01
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
11	P	-
12	P	-

Connector No.	M43
Connector Name	JOINT CONNECTOR-M04
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
2	Y	-
12	Y	-

AAKIA1982GB

DOOR & LOCK SYSTEM


< WIRING DIAGRAM >

Connector No.	M50
Connector Name	JOINT CONNECTOR-CM03
Connector Color	PINK




Terminal No.	Color of Wire	Signal Name
1	B	-
3	B	-
4	B	-

Connector No.	M75
Connector Name	REMOTE KEYLESS ENTRY RECEIVER
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	G	-
2	SB	-
3	-	-
4	L	-

Connector No.	M77
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
13	V	-
20	GR	-
23	BG	-
44	LG	-
60	Y	-
61	GR	-
91	Y	-

Connector No.	M79
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
10	BR	-
13	B	-
15	R	-
16	G	-
26	R	-
29	W	-
30	R	-
31	G	-
32	-	-

AAKIA1983GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK

DOOR & LOCK SYSTEM


< WIRING DIAGRAM >

Connector No.	E5
Connector Name	ANTI THEFT HORN RELAY
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R	-
2	O	-
3	G	-

Connector No.	M93
Connector Name	CHARGE PORT LID OPENER SWITCH
Connector Color	GREEN




Terminal No.	Color of Wire	Signal Name
1	P	-
6	-	-
8	B	-

Connector No.	M86
Connector Name	INSIDE KEY ANTENNA (INSTRUMENT CENTER)
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	BR	-
2	Y	-

Connector No.	E12
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
18	B/W	GND (SIGNAL)
20	V	FR FOG/L LH

Connector No.	E11
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
9	B	GND (POWER)

Connector No.	E6
Connector Name	JOINT CONNECTOR-E01
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-
3	L	-
7	P	-
8	P	-
9	P	-

AAKIA1984GB

DOOR & LOCK SYSTEM


< WIRING DIAGRAM >

Connector No.	E28
Connector Name	INTELLIGENT KEY WARNING BUZZER
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
1	LG	-
3	GR	-

Connector No.	E14
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
42	BR	VCM BAT

Connector No.	E13
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
25	R	AUTO STOP SW
26	P	CAN-CL
27	L	CAN-CH
34	W	HORN RLY CONT

Connector No.	E59
Connector Name	VEHICLE SECURITY HORN
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
2	BY	-

Connector No.	E57
Connector Name	VEHICLE SECURITY HORN
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	G	-

Connector No.	E38
Connector Name	CHARGE PORT LID OPENER ACTUATOR
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	BY	-
3	P	-


AAKIA1985GB

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DOOR & LOCK SYSTEM


< WIRING DIAGRAM >

Connector No.	E61
Connector Name	VCM
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
23	R	CHARGE PORT LID OPENER ACTUATOR RELAY
30	W	READY SIGNAL
47	LG	P/N POSITION SIGNAL
48	W	P POSITION SIGNAL

Connector No.	E62
Connector Name	VCM
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
75	L	CAN-H
76	P	CAN-L
93	BR	CHARGE PORT ID OPENER SWITCH

Connector No.	E88
Connector Name	CHARGE PORT LID OPENER ACTUATOR RELAY
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
1	R	-
2	B/Y	-
3	P	-
5	BR	-

Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
13	W	-
20	BR	-
23	LG	-
44	W	-
60	LG	-
61	GR	-
91	Y	-

Connector No.	E107
Connector Name	WIRE TO WIRE
Connector Color	WHITE





Terminal No.	Color of Wire	Signal Name
1	L	-
2	P	-

DOOR & LOCK SYSTEM



< WIRING DIAGRAM >

Connector No.	B3
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
11	P	-
12	BR	-
26	LG	-
27	Y	-
31	L	-
32	P	-

Connector No.	B2
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	GR	-
5	GR	-
6	W	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	G	-
6	R	-

Connector No.	B16
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	R	-
8	G	-

Connector No.	B7
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
1	L	-
2	P	-

Connector No.	B4
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
10	BR	-
13	B	-
15	R	-
16	G	-
26	R	-
29	W	-
30	V	-
31	LG	-
32	SHIELD	-

AAKIA1987GB


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK

DOOR & LOCK SYSTEM


< WIRING DIAGRAM >

Connector No.	B48
Connector Name	FRONT DOOR SWITCH LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	SB	-

Connector No.	B18
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
9	P	-
10	Y	-
14	L	-
20	GR	-

Connector No.	B17
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	W	-
8	GR	-

Connector No.	B71
Connector Name	REAR DOOR SWITCH LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	LG	-

Connector No.	B53
Connector Name	REAR DOOR SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	R	-

Connector No.	B49
Connector Name	FRONT DOOR SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	BR	-

AAKIA1988GB

DOOR & LOCK SYSTEM

< WIRING DIAGRAM >

Connector No.	B81
Connector Name	INSIDE KEY ANTENNA (REAR SEAT)
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	G	-
2	R	-

Connector No.	B82
Connector Name	INSIDE KEY ANTENNA (LUGGAGE ROOM)
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	V	-
2	LG	-

Connector No.	B83
Connector Name	OUTSIDE KEY ANTENNA (REAR BUMPER)
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	W	-
2	B	-

Connector No.	D6
Connector Name	FRONT OUTSIDE HANDLE LH (OUTSIDE KEY ANTENNA)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	P	-
2	V	-

Connector No.	D15
Connector Name	FRONT OUTSIDE HANDLE LH (REQUEST SWITCH)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	LG	-
2	B	-


AAKIA1989GB

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DOOR & LOCK SYSTEM

< WIRING DIAGRAM >


Connector No.	D35
Connector Name	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	GND
3	Y	LOCK SW
15	BR	UNLOCK SW


Terminal No.	Color of Wire	Signal Name
4C	SB	-
5C	V	-
13C	B	-
36C	LG	-
37C	R	-
38C	L	-
39C	G	-
40C	P	-
41C	V	-
47C	Y	-
48C	BR	-

Connector No.	D22
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5A	V	-
11A	Y	-
12A	B	-
36A	B	-
37A	P	-
38A	Y	-
39A	LG	-

Connector No.	D102
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	D38
Connector Name	FRONT DOOR LOCK ASSEMBLY LH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	V	-
2	SB	-
3	G	-
4	B	-
5	L	-
6	R	-

AAKIA1990GB

DOOR & LOCK SYSTEM


< WIRING DIAGRAM >

Connector No.	D108
Connector Name	FRONT OUTSIDE HANDLE RH (OUTSIDE KEY ANTENNA)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1	LG	-
2	Y	-

Connector No.	D107
Connector Name	FRONT DOOR LOCK ACTUATOR RH
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
5	V	-
6	Y	-

Connector No.	D104
Connector Name	POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	Y	-
2	BR	-
3	B	-

Connector No.	D204
Connector Name	REAR DOOR LOCK ACTUATOR LH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	V	-
2	G	-

Connector No.	D201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	V	-
8	G	-

Connector No.	D115
Connector Name	FRONT OUTSIDE HANDLE RH (REQUEST SWITCH)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	P	-
2	B	-


AAKIA1991GB

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DOOR & LOCK SYSTEM


< WIRING DIAGRAM >

Connector No.	D504
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
9	P	-
10	SB	-
14	L	-
20	GR	-

Connector No.	D304
Connector Name	FRONT DOOR LOCK ACTUATOR RH
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
5	V	-
6	G	-

Connector No.	D301
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	V	-
8	G	-

Connector No.	D562
Connector Name	BACK DOOR LOCK ASSEMBLY
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	GR	-
2	B	-
3	SB	-
4	B	-

Connector No.	D555
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8	P	-
9	L	-
10	SB	-
12	GR	-

Connector No.	D505
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8	P	-
9	L	-
10	SB	-
12	GR	-


AAKIA1992GB

DOOR & LOCK SYSTEM

< WIRING DIAGRAM >

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

Connector No.	D563
Connector Name	BACK DOOR OPENER SWITCH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	L	-
2	B	-
3	B	-
4	P	-

AAKIA1993GB

HOMELINK UNIVERSAL TRANSCEIVER


< WIRING DIAGRAM >

HOMELINK UNIVERSAL TRANSCEIVER

Wiring Diagram

INFOID:000000010639721

HOMELINK UNIVERSAL TRANSCEIVER




AAKWA0831GB

HOMELINK UNIVERSAL TRANSCEIVER

< WIRING DIAGRAM >


HOMELINK UNIVERSAL TRANSCEIVER - CONNECTORS

Connector No.	M43
Connector Name	JOINT CONNECTOR-M04
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
2	Y	-
5	W	-
9	W	-
12	Y	-

Connector No.	M50
Connector Name	JOINT CONNECTOR-CM03
Connector Color	PINK




Terminal No.	Color of Wire	Signal Name
1	B	-
7	B	-

Connector No.	M73
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5	B	-
8	Y	-
11	W	-

Connector No.	R1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	B	-
8	B/Y	-
11	B/R	-

Connector No.	R7
Connector Name	AUTO ANTI-DAZZLING INSIDE MIRROR
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	-	-
2	-	-
3	-	-
4	-	-
5	-	-
6	B/R	IGN
7	-	-
8	B	GND
9	-	-
10	B/Y	IGN

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:0000000110639722

OVERALL SEQUENCE



JMKIA8652GB

DETAILED FLOW

Revision: June 2014

DLK-66

2015 Leaf NAM

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

1.GET INFORMATION FOR SYMPTOM

1. Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurs).
2. Check operation condition of the function that is malfunctioning.

>> GO TO 2.

2.CHECK DTC

1. Check DTC.
2. Perform the following procedure if DTC is detected.
 - Record DTC and freeze frame data (Print them out using CONSULT.)
 - Erase DTC.
 - Study the relationship between the cause detected by DTC and the symptom described by the customer.
3. Check related service bulletins for information.

Are any symptoms described and any DTC detected?

Symptom is described, DTC is detected>>GO TO 3.

Symptom is described, DTC is not detected>>GO TO 4.

Symptom is not described, DTC is detected>>GO TO 5.

3.CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Also study the normal operation and fail-safe related to the symptom.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5.

4.CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6.

5.PERFORM DTC CONFIRMATION PROCEDURE

Perform DTC CONFIRMATION PROCEDURE for the detected DTC, and then check that DTC is detected again. At this time, always connect CONSULT to the vehicle, and check self diagnostic results in real time.

If two or more DTCs are detected, refer to [BCS-47. "DTC Inspection Priority Chart"](#) (BCM), and determine trouble diagnosis order.

NOTE:

- Freeze frame data is useful if the DTC is not detected.
- Perform Component Function Check if DTC CONFIRMATION PROCEDURE is not included on Service Manual. This simplified check procedure is an effective alternative though DTC cannot be detected during this check.

If the result of Component Function Check is NG, it is the same as the detection of DTC by DTC CONFIRMATION PROCEDURE.

Is DTC detected?

YES >> GO TO 7.

NO >> Check according to [GI-53. "Intermittent Incident"](#).

6.DETECT MALFUNCTIONING SYSTEM BY SYMPTOM DIAGNOSIS

Detect malfunctioning system according to SYMPTOM DIAGNOSIS based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

Is the symptom described?

YES >> GO TO 7.

NO >> Monitor input data from related sensors or check voltage of related module terminals using CONSULT.

7.DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

Inspect according to Diagnostic Procedure of the system.

Is malfunctioning part detected?

YES >> GO TO 8.

NO >> Check according to [GI-53. "Intermittent Incident"](#).

8. REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnostic Procedure again after repair and replacement.
3. Check DTC. If DTC is detected, erase it.

>> GO TO 9.

9. FINAL CHECK

When DTC is detected in step 2, perform DTC CONFIRMATION PROCEDURE again, and then check that the malfunction is repaired securely.

When symptom is described by the customer, refer to confirmed symptom in step 3 or 4, and check that the symptom is not detected.

Is DTC detected and does symptom remain?

YES-1 >> DTC is detected: GO TO 7.

YES-2 >> Symptom remains: GO TO 4.

NO >> Before returning the vehicle to the customer, always erase DTC.

B2621 INSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

B2621 INSIDE ANTENNA

DTC Logic

INFOID:000000010639723

DTC DETECTION LOGIC

DTC	CONSULT display description	DTC detecting condition	Possible cause
B2621	INSIDE ANTENNA 1	An excessive high or low voltage from inside antenna (instrument center) is sent to BCM.	<ul style="list-style-type: none"> Inside key antenna (instrument center) Harness or connector [Inside key antenna (instrument center) circuit is open or shorted]

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "INSIDE ANT DIAGNOSIS" in "Work support".
3. Perform inside key antenna ("INSIDE ANT DIAGNOSIS") in "Work support" of "INTELLIGENT KEY".
4. Check BCM for DTC.

Is inside key antenna DTC detected?

- YES >> Refer to [DLK-69, "Diagnosis Procedure"](#).
 NO >> Inside key antenna (instrument center) is OK.

Diagnosis Procedure

INFOID:000000010639724

Regarding Wiring Diagram information, refer to [DLK-45, "Wiring Diagram"](#).

1. CHECK INSIDE KEY ANTENNA INPUT SIGNAL 1

1. Turn power switch ON.
2. Check signal between BCM harness connector and ground using oscilloscope.

(+)		(-)	Condition	Signal (Reference value)
BCM				
Connector	Terminal			
M23	84	Ground	When Intelligent Key is in the antenna detection area	<p>JMKIA3839GB</p>
	85		When Intelligent Key is not in the antenna detection area	<p>JMKIA5951GB</p>

Is the inspection result normal?

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

B2621 INSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

- YES >> Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).
 NO >> GO TO 2.

2. CHECK INSIDE KEY ANTENNA CIRCUIT

1. Turn power switch OFF.
2. Disconnect BCM connector and inside key antenna (instrument center) connector.
3. Check continuity between BCM harness connector and inside key antenna (instrument center) harness connector.

BCM		Inside key antenna (instrument center)		Continuity
Connector	Terminal	Connector	Terminal	
M23	84	M86	1	Yes
	85		2	

4. Check continuity between BCM harness connector and ground.



BCM		Ground	Continuity
Connector	Terminal		
M23	84		No
	85		

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair or replace harness.

3. CHECK INSIDE KEY ANTENNA INPUT SIGNAL 2

1. Replace inside key antenna (instrument center). (New antenna or other antenna)
2. Connect BCM connector and inside key antenna (instrument center) connector.
3. Turn power switch ON.
4. Check signal between BCM harness connector and ground using oscilloscope.

(+)		(-)	Condition	Signal (Reference value)
BCM				
Connector	Terminal			
M23	84	Ground	When Intelligent Key is in the antenna detection area	 <small>JMKIA3839GB</small>
	85		When Intelligent Key is not in the antenna detection area	 <small>JMKIA5951GB</small>

Is the inspection result normal?

- YES >> Replace inside key antenna (instrument center). Refer to [DLK-206, "INSTRUMENT CENTER : Removal and Installation"](#).
 NO >> Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

B2622 INSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

B2622 INSIDE ANTENNA

DTC Logic

INFOID:0000000110639725

DTC DETECTION LOGIC

DTC	CONSULT display description	DTC detecting condition	Possible cause
B2622	INSIDE ANTENNA 2	An excessive high or low voltage from inside antenna (rear seat) is sent to BCM.	<ul style="list-style-type: none"> Inside key antenna (rear seat) Harness or connector [Inside key antenna (rear seat) circuit is open or shorted]

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "INSIDE ANT DIAGNOSIS" in "Work support".
3. Perform inside key antenna ("INSIDE ANT DIAGNOSIS") in "Work support" of "INTELLIGENT KEY".
4. Check BCM for DTC.

Is inside key antenna DTC detected?

- YES >> Refer to [DLK-71, "Diagnosis Procedure"](#).
- NO >> Inside key antenna (rear seat) is OK.

Diagnosis Procedure

INFOID:0000000110639726

Regarding Wiring Diagram information, refer to [DLK-45, "Wiring Diagram"](#).

1. CHECK INSIDE KEY ANTENNA INPUT SIGNAL 1

1. Turn power switch ON.
2. Check signal between BCM harness connector and ground using oscilloscope.

(+) BCM		(-)	Condition	Signal (Reference value)
Connector	Terminal			
M23	86 87	Ground	When Intelligent Key is in the antenna detection area	
			When Intelligent Key is not in the antenna detection area	

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).
- NO >> GO TO 2.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

B2622 INSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

2. CHECK INSIDE KEY ANTENNA CIRCUIT

1. Turn power switch OFF.
2. Disconnect BCM connector and inside key antenna (rear seat) connector.
3. Check continuity between BCM harness connector and inside key antenna (rear seat) harness connector.

BCM		Inside key antenna (rear seat)		Continuity
Connector	Terminal	Connector	Terminal	
M23	86	B81	1	Yes
	87		2	

4. Check continuity between BCM harness connector and ground.



BCM		Ground	Continuity
Connector	Terminal		
M23	86		No
	87		

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair or replace harness.

3. CHECK INSIDE KEY ANTENNA INPUT SIGNAL 2

1. Replace inside key antenna (rear seat). (New antenna or other antenna)
2. Connect BCM connector and inside key antenna (rear seat) connector.
3. Turn power switch ON.
4. Check signal between BCM harness connector and ground using oscilloscope.

(+) BCM		(-)	Condition	Signal (Reference value)
Connector	Terminal			
M23	86	Ground	When Intelligent Key is in the antenna detection area	 <p style="text-align: right; font-size: small;">JMKIA3839GB</p>
	87		When Intelligent Key is not in the antenna detection area	 <p style="text-align: right; font-size: small;">JMKIA5951GB</p>

Is the inspection result normal?

- YES >> Replace inside key antenna (rear seat). Refer to [DLK-206, "REAR SEAT : Removal and Installation"](#).
 NO >> Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

B2623 INSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

B2623 INSIDE ANTENNA

DTC Logic

INFOID:0000000110639727

DTC DETECTION LOGIC

DTC	CONSULT display description	DTC detecting condition	Possible cause
B2623	INSIDE ANTENNA 3	An excessive high or low voltage from inside antenna (luggage room) is sent to BCM.	<ul style="list-style-type: none"> Inside key antenna (luggage room) Harness or connector [Inside key antenna (luggage room) circuit is open or shorted]

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "INSIDE ANT DIAGNOSIS" in "Work support".
3. Perform inside key antenna ("INSIDE ANT DIAGNOSIS") in "Work support" of "INTELLIGENT KEY".
4. Check BCM for DTC.

Is inside key antenna DTC detected?

- YES >> Refer to [DLK-73. "Diagnosis Procedure"](#).
- NO >> Inside key antenna (luggage room) is OK.

Diagnosis Procedure

INFOID:0000000110639728

Regarding Wiring Diagram information, refer to [DLK-45. "Wiring Diagram"](#).

1. CHECK INSIDE KEY ANTENNA INPUT SIGNAL 1

1. Turn power switch ON.
2. Check signal between BCM harness connector and ground using oscilloscope.

(+)		(-)	Condition	Signal (Reference value)
BCM				
Connector	Terminal			
M23	88	Ground	When Intelligent Key is in the antenna detection area	
	89		When Intelligent Key is not in the antenna detection area	

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-72. "Removal and Installation"](#).
- NO >> GO TO 2.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

B2623 INSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

2. CHECK INSIDE KEY ANTENNA CIRCUIT

1. Turn power switch OFF.
2. Disconnect BCM connector and inside key antenna (luggage room) connector.
3. Check continuity between BCM harness connector and inside key antenna (luggage room) harness connector.

BCM		Inside key antenna (luggage room)		Continuity
Connector	Terminal	Connector	Terminal	
M23	88	B82	1	Yes
	89		2	

4. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M23	88		No
	89		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK INSIDE KEY ANTENNA INPUT SIGNAL 2

1. Replace inside key antenna (luggage room). (New antenna or other antenna)
2. Connect BCM connector and inside key antenna (luggage room) connector.
3. Turn power switch ON.
4. Check signal between BCM harness connector and ground using oscilloscope.

(+)		(-)	Condition	Signal (Reference value)
BCM				
Connector	Terminal			
M23	88	Ground	When Intelligent Key is in the antenna detection area	
	89		When Intelligent Key is not in the antenna detection area	

Is the inspection result normal?

YES >> Replace inside key antenna (luggage room). Refer to [DLK-206, "LUGGAGE ROOM : Removal and Installation"](#).

NO >> Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

B2626 OUTSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

B2626 OUTSIDE ANTENNA

DTC Logic

INFOID:0000000110639729

DTC DETECTION LOGIC

DTC	CONSULT display description	DTC detecting condition	Possible cause
B2626	OUTSIDE 1 ANTENNA	An excessive high or low voltage from outside key antenna (RH) is sent to BCM.	<ul style="list-style-type: none"> Outside key antenna (RH) Harness or connector [Outside key antenna (RH) circuit is open or shorted]

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Disconnect outside key antenna (RH) connector.
2. Perform "Self Diagnostic Result" of "INTELLIGENT KEY" using CONSULT.

Is outside key antenna DTC detected?

- YES >> Refer to [DLK-75, "Diagnosis Procedure"](#).
 NO >> Outside key antenna (RH) is OK.

Diagnosis Procedure

INFOID:0000000110639730

Regarding Wiring Diagram information, refer to [DLK-45, "Wiring Diagram"](#).

1. CHECK OUTSIDE KEY ANTENNA INPUT SIGNAL 1

1. Turn power switch OFF.
2. Check signal between BCM harness connector and ground using oscilloscope.

(+)		(-)	Condition	Signal (Reference value)
BCM				
Connector	Terminal			
M23	80 81	Ground	When the RH request switch is operated with power switch OFF	<p>JMKIA5955GB</p>
			When Intelligent Key is in the antenna detection area (The distance between Intelligent Key and antenna: 80 cm or less)	<p>JMKIA5954GB</p>

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).
 NO >> GO TO 2.

2. CHECK OUTSIDE KEY ANTENNA CIRCUIT

1. Disconnect BCM connector and outside key antenna (RH) connector.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

B2626 OUTSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

2. Check continuity between BCM harness connector and outside key antenna (RH) harness connector.

BCM		Outside key antenna (RH)		Continuity
Connector	Terminal	Connector	Terminal	
M23	80	D108	1	Yes
	81		2	

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M23	80		No
	81		



Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK OUTSIDE KEY ANTENNA INPUT SIGNAL 2

1. Replace outside key antenna (RH). (New antenna or other antenna)
2. Connect BCM connector and outside key antenna (RH) connector.
3. Check signal between BCM harness connector and ground using oscilloscope.

(+)		(-)	Condition	Signal (Reference value)
BCM				
Connector	Terminal			
M23	80	Ground	When the RH request switch is operated with power switch OFF	 <p style="text-align: right; font-size: small;">JMKIA5955GB</p>
	81			 <p style="text-align: right; font-size: small;">JMKIA5954GB</p>

Is the inspection result normal?

YES >> Replace front outside handle RH (outside key antenna). Refer to [DLK-208. "PASSENGER SIDE : Removal and Installation"](#).

NO >> Replace BCM. Refer to [BCS-72. "Removal and Installation"](#).

B2627 OUTSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

B2627 OUTSIDE ANTENNA

DTC Logic

INFOID:000000010639731

DTC DETECTION LOGIC

DTC	CONSULT display description	DTC detecting condition	Possible cause
B2627	OUTSIDE 2 ANTENNA	An excessive high or low voltage from outside key antenna (LH) is sent to BCM.	<ul style="list-style-type: none"> Outside key antenna (LH) Harness or connector [Outside key antenna (LH) circuit is open or shorted]

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Disconnect outside key antenna (LH) connector.
2. Perform "Self Diagnostic Result" of "INTELLIGENT KEY" using CONSULT.

Is outside key antenna DTC detected?

- YES >> Refer to [DLK-77, "Diagnosis Procedure"](#).
- NO >> Outside key antenna (LH) is OK.

Diagnosis Procedure

INFOID:000000010639732

Regarding Wiring Diagram information, refer to [DLK-45, "Wiring Diagram"](#).

1. CHECK OUTSIDE KEY ANTENNA INPUT SIGNAL 1

1. Turn power switch OFF.
2. Check signal between BCM harness connector and ground using oscilloscope.

(+)		(-)	Condition	Signal (Reference value)
BCM				
Connector	Terminal			
M23	78	Ground	When the LH request switch is operated with power switch OFF	<p style="text-align: right;">JMkia5955GB</p>
	79		When Intelligent Key is not in the antenna detection area (The distance between Intelligent Key and antenna: Approx. 2 m)	<p style="text-align: right;">JMkia5954GB</p>

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).
- NO >> GO TO 2.

2. CHECK OUTSIDE KEY ANTENNA CIRCUIT

1. Disconnect BCM connector and outside key antenna (LH) connector.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

B2627 OUTSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

2. Check continuity between BCM harness connector and outside key antenna (LH) harness connector.

BCM		Outside key antenna (LH)		Continuity
Connector	Terminal	Connector	Terminal	
M23	78	D6	1	Yes
	79		2	

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M23	78		No
	79		



Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK OUTSIDE KEY ANTENNA INPUT SIGNAL 2

1. Replace outside key antenna (LH). (New antenna or other antenna)
2. Connect BCM connector and outside key antenna (LH) connector.
3. Check signal between BCM harness connector and ground using oscilloscope.

(+)		(-)	Condition	Signal (Reference value)
BCM				
Connector	Terminal			
M23	78	Ground	When the LH request switch is operated with power switch OFF	 <p style="text-align: right; font-size: small;">JMKIA5955GB</p>
	79			 <p style="text-align: right; font-size: small;">JMKIA5954GB</p>

Is the inspection result normal?

YES >> Replace front outside handle LH (outside key antenna). Refer to [DLK-208. "DRIVER SIDE : Removal and Installation"](#).

NO >> Replace BCM. Refer to [BCS-72. "Removal and Installation"](#).

B2628 OUTSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

B2628 OUTSIDE ANTENNA

DTC Logic

INFOID:0000000110639733

DTC DETECTION LOGIC

DTC	CONSULT display description	DTC detecting condition	Possible cause
B2628	OUTSIDE 3 ANTENNA	An excessive high or low voltage from outside key antenna (rear bumper) is sent to BCM.	<ul style="list-style-type: none"> • Outside key antenna (rear bumper) • Harness or connector [Outside key antenna (rear bumper) circuit is open or shorted]

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Disconnect outside key antenna (rear bumper) connector.
2. Perform "Self Diagnostic Result" of "INTELLIGENT KEY" using CONSULT.

Is outside key antenna DTC detected?

- YES >> Refer to [DLK-79. "Diagnosis Procedure"](#).
- NO >> Outside key antenna (rear bumper) is OK.

Diagnosis Procedure

INFOID:0000000110639734

Regarding Wiring Diagram information, refer to [DLK-45. "Wiring Diagram"](#).

1. CHECK OUTSIDE KEY ANTENNA INPUT SIGNAL 1

1. Turn power switch OFF.
2. Check signal between BCM harness connector and ground using oscilloscope.

(+)		(-)	Condition	Signal (Reference value)
BCM				
Connector	Terminal			
M23	82	Ground	When the back door request switch is operated with power switch OFF	<p>JMKIA5955GB</p>
	83		When Intelligent Key is not in the antenna detection area (The distance between Intelligent Key and antenna: Approx. 2 m)	<p>JMKIA5954GB</p>

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-72. "Removal and Installation"](#).
- NO >> GO TO 2.

2. CHECK OUTSIDE KEY ANTENNA CIRCUIT

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

B2628 OUTSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

1. Disconnect BCM connector and outside key antenna (rear bumper) connector.
2. Check continuity between BCM harness connector and outside key antenna (rear bumper) harness connector.

BCM		Outside key antenna (rear bumper)		Continuity
Connector	Terminal	Connector	Terminal	
M23	82	B83	1	Yes
	83		2	

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M23	82		No
	83		



Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK OUTSIDE KEY ANTENNA INPUT SIGNAL 2

1. Replace outside key antenna (rear bumper). (New antenna or other antenna)
2. Connect BCM and outside key antenna (rear bumper) connector.
3. Check signal between BCM harness connector and ground using oscilloscope.

(+)		(-)	Condition	Signal (Reference value)
BCM				
Connector	Terminal			
M23	82	Ground	When the back door request switch is operated with power switch OFF	 <p style="text-align: right; font-size: small;">JMKIA5955GB</p>
	83			 <p style="text-align: right; font-size: small;">JMKIA5954GB</p>
			When Intelligent Key is in the antenna detection area (The distance between Intelligent Key and antenna: 80 cm or less)	
			When Intelligent Key is not in the antenna detection area (The distance between Intelligent Key and antenna: Approx. 2 m)	

Is the inspection result normal?

YES >> Replace outside key antenna (rear bumper). Refer to [DLK-208, "REAR BUMPER : Removal and Installation"](#).

NO >> Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

BACK DOOR OPENER ACTUATOR

< DTC/CIRCUIT DIAGNOSIS >

BACK DOOR OPENER ACTUATOR

Component Function Check

INFOID:0000000110639735

1.CHECK FUNCTION

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "TRUNK/BACK DOOR" in "Active Test".
3. Touch "OPEN" to check that it works normally.

Is the inspection result normal?

- YES >> Back door opener actuator is OK.
NO >> Refer to [DLK-81. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000110639736

Regarding Wiring Diagram information, refer to [DLK-45. "Wiring Diagram"](#).

1.CHECK BACK DOOR OPENER ACTUATOR INPUT SIGNAL

1. Turn power switch OFF.
2. Disconnect back door lock assembly connector.
3. Check voltage between back door lock assembly harness connector and ground.

(+)		(-)	Condition		Voltage (Approx.)
Back door lock assembly					
Connector	Terminal				
D562	1	Ground	Back door opener switch	ON	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2.CHECK BACK DOOR OPENER ACTUATOR CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and back door lock assembly harness connector.

BCM		Back door lock assembly		Continuity
Connector	Terminal	Connector	Terminal	
M29	53	D562	1	Yes

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M29	53		No

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-72. "Removal and Installation"](#).
NO >> Repair or replace harness.

3.CHECK BACK DOOR OPENER ACTUATOR GROUND CIRCUIT

Check continuity between back door lock assembly harness connector and ground.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

BACK DOOR OPENER ACTUATOR

< DTC/CIRCUIT DIAGNOSIS >

Back door lock assembly		Ground	Continuity
Connector	Terminal		
D562	2		Yes

Is the inspection normal?

- YES >> Replace back door lock assembly. Refer to [DLK-201, "DOOR LOCK : Removal and Installation"](#).
NO >> Repair or replace harness.

BACK DOOR OPENER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

BACK DOOR OPENER SWITCH

Component Function Check

INFOID:000000010639737

1.CHECK FUNCTION

1. Select "TRUNK" of "BCM" using CONSULT.
2. Select "TR/BD OPEN SW" in "Data Monitor".
3. Check that the function operates normally according to the following conditions:

Monitor item	Condition		Status
TR/BD OPEN SW	Back door opener switch	Pressed	ON
		Released	OFF

Is the inspection result normal?

- YES >> Back door opener switch is OK.
 NO >> Refer to [DLK-83, "Diagnosis Procedure"](#).


Diagnosis Procedure

INFOID:000000010639738

Regarding Wiring Diagram information, refer to [DLK-45, "Wiring Diagram"](#).

1.CHECK BACK DOOR OPENER SWITCH INPUT SIGNAL

1. Turn power switch OFF.
2. Disconnect back door opener switch assembly connector.
3. Check signal between back door opener switch assembly harness connector and ground using oscilloscope.

(+)		(-)	Signal (Reference value)
Connector	Terminal		
D563	1	Ground	 <p style="text-align: right;">JPMA0012GB</p>

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 2.

2.CHECK BACK DOOR OPENER SWITCH CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and back door opener switch assembly harness connector.

BCM		Back door opener switch assembly		Continuity
Connector	Terminal	Connector	Terminal	
M24	30	D563	1	Yes

3. Check continuity between BCM harness connector and ground.

BACK DOOR OPENER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

BCM		Ground	Continuity
Connector	Terminal		
M24	30		No

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK BACK DOOR OPENER SWITCH GROUND CIRCUIT

Check continuity between back door opener switch assembly harness connector and ground.

Back door opener switch assembly		Ground	Continuity
Connector	Terminal		
D563	2		Yes

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK BACK DOOR OPENER SWITCH

Refer to [DLK-84, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace back door opener switch assembly. Refer to [DLK-213, "Removal and Installation"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-53, "Intermittent Incident"](#).

>> Inspection End.

Component Inspection

INFOID:000000010639739

1.CHECK BACK DOOR OPENER SWITCH

1. Turn power switch OFF.
2. Disconnect back door opener switch assembly connector.
3. Check continuity between back door opener switch assembly terminals.

Back door opener switch assembly		Condition	Continuity	
Terminal				
1	2	Back door opener switch	Pressed	Yes
			Released	No

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace back door opener switch assembly. Refer to [DLK-213, "Removal and Installation"](#).

BACK DOOR REQUEST SWITCH

< DTC/CIRCUIT DIAGNOSIS >

BACK DOOR REQUEST SWITCH

Component Function Check

INFOID:000000010639740

1.CHECK FUNCTION

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "REQ SW-BD/TR" in "Data Monitor".
3. Check that the function operates normally according to the following conditions:

Monitor item	Condition		Status
REQ SW-BD/TR	Back door request switch	Pressed	ON
		Released	OFF

Is the inspection result normal?

- YES >> Back door request switch is OK.
NO >> Refer to [DLK-85, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000010639741

Regarding Wiring Diagram information, refer to [DLK-45, "Wiring Diagram"](#).

1.CHECK BACK DOOR REQUEST SWITCH INPUT SIGNAL

1. Turn power switch OFF.
2. Disconnect back door opener switch assembly connector.
3. Check voltage between back door opener switch assembly harness connector and ground.

(+)		(-)	Voltage (Approx.)
Connector	Terminal		
D563	4	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2.CHECK BACK DOOR REQUEST SWITCH CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and back door opener switch assembly harness connector.

BCM		Back door opener switch assembly		Continuity
Connector	Terminal	Connector	Terminal	
M29	51	D563	4	Yes

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M29	51		No

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).
NO >> Repair harness or connector.

3.CHECK BACK DOOR REQUEST SWITCH GROUND CIRCUIT

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

BACK DOOR REQUEST SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Check continuity between back door opener switch assembly harness connector and ground.

Back door opener switch assembly		Ground	Continuity
Connector	Terminal		
D563	3		Yes

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4. CHECK BACK DOOR REQUEST SWITCH

Refer to [DLK-86, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace back door opener switch assembly. Refer to [DLK-213, "Removal and Installation"](#).

5. CHECK INTERMITTENT INCIDENT

Refer to [GI-53, "Intermittent Incident"](#).

>> Inspection End.

Component Inspection

INFOID:000000010639742

1. CHECK BACK DOOR REQUEST SWITCH

1. Turn power switch OFF.
2. Disconnect back door opener switch assembly connector.
3. Check continuity between back door opener switch assembly terminals.

Back door opener switch assembly		Condition	Continuity
Terminal			
3	4	Back door request switch	Pressed Yes
			Released No

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace back door opener switch assembly. Refer to [DLK-213, "Removal and Installation"](#).

BUZZER (COMBINATION METER)

< DTC/CIRCUIT DIAGNOSIS >

BUZZER (COMBINATION METER)

Component Function Check

INFOID:000000010639743

1.CHECK FUNCTION

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "INSIDE BUZZER" in "Active Test".
3. Touch "Key", "Knob" or "Take Out" to check that it works normally.

Is the inspection result normal?

- YES >> Buzzer (combination meter) is OK.
NO >> Refer to [DLK-87. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000010639744

1.CHECK METER BUZZER CIRCUIT

Refer to [WCS-43. "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace the malfunctioning parts.

2.CHECK INTERMITTENT INCIDENT

Refer to [GI-53. "Intermittent Incident"](#).

>> Inspection End.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

DOOR KEY CYLINDER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

DOOR KEY CYLINDER SWITCH

Component Function Check

INFOID:000000010639745

1. CHECK FUNCTION

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "KEY CYL LK SW", "KEY CYL UN-SW" in "Data Monitor".
3. Check that the function operates normally according to the following conditions:

Monitor item	Condition	Status
KEY CYL LK-SW	Lock	ON
	Neutral / Unlock	OFF
KEY CYL UN-SW	Unlock	ON
	Neutral / Lock	OFF

Is the inspection result normal?

- YES >> Door key cylinder switch is OK.
 NO >> Refer to [DLK-88, "Diagnosis Procedure"](#).


Diagnosis Procedure

INFOID:000000010639746

Regarding Wiring Diagram information, refer to [DLK-45, "Wiring Diagram"](#).

1. CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL

1. Turn power switch OFF.
2. Disconnect front door lock assembly (LH) connector.
3. Check voltage between front door lock assembly (LH) harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Connector	Terminal		
D38	5	Ground	
	6		

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 2.

2. CHECK DOOR KEY CYLINDER SWITCH SIGNAL CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and front door lock assembly (LH) harness connector.

BCM		Front door lock assembly (LH)		Continuity
Connector	Terminal	Connector	Terminal	
M24	7	D38	5	Yes
	8		6	

DOOR KEY CYLINDER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M24	7		No
	8		

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK DOOR KEY CYLINDER SWITCH GROUND CIRCUIT

Check continuity between front door lock assembly (LH) harness connector and ground.

Front door lock assembly (LH)		Ground	Continuity
Connector	Terminal		
D38	4		Yes

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK DOOR KEY CYLINDER SWITCH

Refer to [DLK-89, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace front door lock assembly (LH). Refer to [DLK-194, "OUTSIDE HANDLE : Removal and Installation"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-53, "Intermittent Incident"](#).

>> Inspection End.

Component Inspection

INFOID:0000000010639747

DLK

1.CHECK DOOR KEY CYLINDER SWITCH

1. Turn power switch OFF.
2. Disconnect front door lock assembly (LH) terminal.
3. Check continuity between front door lock assembly (LH) terminals.

Front door lock assembly (LH)		Condition	Continuity
Terminal			
5	4	LH door key cylinder	Unlock
			Neutral / Lock
6			Lock
			Neutral / Unlock

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace front door lock assembly (LH). Refer to [DLK-194, "OUTSIDE HANDLE : Removal and Installation"](#).

DOOR LOCK ACTUATOR

< DTC/CIRCUIT DIAGNOSIS >

DOOR LOCK ACTUATOR DRIVER SIDE

DRIVER SIDE : Component Function Check

INFOID:0000000010639748

1. CHECK FUNCTION

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "DOOR LOCK" in "Active Test".
3. Touch "ALL LOCK" or "ALL UNLK" to check that it works normally.

Is the inspection result normal?

YES >> Door lock actuator is OK.

NO >> Refer to [DLK-90, "DRIVER SIDE : Diagnosis Procedure"](#).

DRIVER SIDE : Diagnosis Procedure

INFOID:0000000010639749

Regarding Wiring Diagram information, refer to [DLK-45, "Wiring Diagram"](#).

1. CHECK DOOR LOCK ACTUATOR INPUT SIGNAL

1. Turn power switch OFF.
2. Disconnect front door lock assembly (LH) connector.
3. Check voltage between front door lock assembly (LH) harness connector and ground.

(+)		(-)	Condition	Voltage (Approx.)
Connector	Terminal			
D38	1	Ground	Door lock and unlock switch	Battery voltage
	2		Lock Unlock	

Is the inspection result normal?

YES >> Replace front door lock assembly (LH). Refer to [DLK-193, "DOOR LOCK : Removal and Installation"](#).

NO >> GO TO 2.

2. CHECK DOOR LOCK ACTUATOR CIRCUIT

1. Disconnect BCM connector and all door lock assembly connectors.
2. Check continuity between BCM harness connector and front door lock assembly (LH) harness connector.

BCM		Front door lock assembly (LH)		Continuity
Connector	Terminal	Connector	Terminal	
M25	65	D38	1	Yes
	66		2	

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M25	65		No
	66		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

DOOR LOCK ACTUATOR

< DTC/CIRCUIT DIAGNOSIS >

3.CHECK BCM OUTPUT SIGNAL

1. Connect BCM connector.
2. Check voltage between BCM harness connector and ground.

(+)		(-)	Condition	Voltage (Approx.)
BCM				
Connector	Terminal			
M25	65	Ground	Door lock and unlock switch	Lock
	66			Unlock
				Battery voltage

Is the inspection result normal?

- YES >> Check for internal short of each door lock actuator.
 NO >> Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

PASSENGER SIDE

PASSENGER SIDE : Component Function Check

INFOID:000000010639750

1.CHECK FUNCTION

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "DOOR LOCK" in "Active Test".
3. Check that the function operates normally according to the following conditions:

Monitor item		Status	
DOOR LOCK	ALL LOCK	Door lock actuators	LOCK
	ALL UNLK		UNLOCK

Is the inspection result normal?

- YES >> Door lock actuator is OK.
 NO >> Refer to [DLK-90, "DRIVER SIDE : Diagnosis Procedure"](#).

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000010639751

Regarding Wiring Diagram information, refer to [DLK-45, "Wiring Diagram"](#).

1.CHECK DOOR LOCK ACTUATOR INPUT SIGNAL

1. Turn power switch OFF.
2. Disconnect front door lock actuator RH connector.
3. Check voltage between front door lock actuator RH harness connector and ground.

(+)		(-)	Condition	Voltage (Approx.)
Front door lock actuator RH				
Connector	Terminal			
D107	5	Ground	Door lock and unlock switch	Lock
	6			Unlock
				Battery voltage

Is the inspection result normal?

- YES >> Replace front door lock actuator RH. Refer to [DLK-193, "DOOR LOCK : Removal and Installation"](#).
 NO >> GO TO 2.

2.CHECK DOOR LOCK ACTUATOR CIRCUIT

1. Disconnect BCM connector and all door lock assembly connectors.
2. Check continuity between BCM harness connector and front door lock actuator RH harness connector.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

DOOR LOCK ACTUATOR

< DTC/CIRCUIT DIAGNOSIS >

BCM		Front door lock actuator RH		Continuity
Connector	Terminal	Connector	Terminal	
M25	59	D107	6	Yes
	65		5	

- Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M25	59		No
	65		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3.CHECK BCM OUTPUT SIGNAL

- Connect BCM connector.
- Check voltage between BCM harness connector and ground.

(+)		(-)	Condition	Voltage (Approx.)
BCM				
Connector	Terminal	Ground	Door lock and unlock switch	Battery voltage
M25	59			
	65	Lock		

Is the inspection result normal?

YES >> Check for internal short of each door lock actuator.

NO >> Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

REAR LH

REAR LH : Component Function Check

INFOID:000000010639752

1.CHECK FUNCTION

- Select "DOOR LOCK" of "BCM" using CONSULT.
- Select "DOOR LOCK" in "Active Test".
- Check that the function operates normally according to the following conditions:

Monitor item		Status	
DOOR LOCK	ALL LOCK	Door lock actuators	LOCK
	ALL UNLK		UNLOCK

Is the inspection result normal?

YES >> Door lock actuator is OK.

NO >> Refer to [DLK-90, "DRIVER SIDE : Diagnosis Procedure"](#).

REAR LH : Diagnosis Procedure

INFOID:000000010639753

Regarding Wiring Diagram information, refer to [DLK-45, "Wiring Diagram"](#).

1.CHECK DOOR LOCK ACTUATOR INPUT SIGNAL

- Turn power switch OFF.
- Disconnect rear door lock actuator LH connector.
- Check voltage between rear door lock actuator LH harness connector and ground.

DOOR LOCK ACTUATOR

< DTC/CIRCUIT DIAGNOSIS >

(+)		(-)	Condition		Voltage (Approx.)
Rear door lock actuator LH					
Connector	Terminal				
D204	1	Ground	Door lock and unlock switch	Lock	Battery voltage
	2			Unlock	

Is the inspection result normal?

YES >> Replace rear door lock actuator LH. Refer to [DLK-197, "DOOR LOCK : Removal and Installation"](#).

NO >> GO TO 2.

2. CHECK DOOR LOCK ACTUATOR CIRCUIT

1. Disconnect BCM connector and all door lock actuator connectors.
2. Check continuity between BCM harness connector and rear door lock actuator LH harness connector.

BCM		Rear door lock actuator LH		Continuity
Connector	Terminal	Connector	Terminal	
M29	55	D204	2	Yes
M25	65		1	

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M29	55		No
M25	65		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK BCM OUTPUT SIGNAL

1. Connect BCM connector.
2. Check voltage between BCM harness connector and ground.

(+)		(-)	Condition		Voltage (Approx.)
BCM					
Connector	Terminal				
M29	55	Ground	Door lock and unlock switch	Unlock	Battery voltage
M25	65			Lock	

Is the inspection result normal?

YES >> Check for internal short of each door lock actuator.

NO >> Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

REAR RH

REAR RH : Component Function Check

INFOID:0000000010639754

1. CHECK FUNCTION

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "DOOR LOCK" in "Active Test".
3. Check that the function operates normally according to the following conditions:

Monitor item		Status	
DOOR LOCK	ALL LOCK	Door lock actuators	LOCK
	ALL UNLK		UNLOCK

DOOR LOCK ACTUATOR

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES >> Door lock actuator is OK.
 NO >> Refer to [DLK-90. "DRIVER SIDE : Diagnosis Procedure"](#).

REAR RH : Diagnosis Procedure

INFOID:000000010639755

Regarding Wiring Diagram information, refer to [DLK-45. "Wiring Diagram"](#).

1. CHECK DOOR LOCK ACTUATOR INPUT SIGNAL

1. Turn power switch OFF.
2. Disconnect rear door lock actuator RH connector.
3. Check voltage between rear door lock actuator RH harness connector and ground.

(+)		(-)	Condition	Voltage (Approx.)
Connector	Terminal			
D304	5	Ground	Door lock and unlock switch	Battery voltage
	6		Lock Unlock	

Is the inspection result normal?

- YES >> Replace rear door lock actuator RH. Refer to [DLK-197. "DOOR LOCK : Removal and Installation"](#).
 NO >> GO TO 2.

2. CHECK DOOR LOCK ACTUATOR CIRCUIT

1. Disconnect BCM connector and all door lock actuator connectors.
2. Check continuity between BCM harness connector and rear door lock actuator RH harness connector.

BCM		Rear door lock actuator RH		Continuity
Connector	Terminal	Connector	Terminal	
M29	55	D304	6	Yes
M25	65		5	

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M29	55	Ground	No
M25	65		

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair or replace harness.

3. CHECK BCM OUTPUT SIGNAL

1. Connect BCM connector.
2. Check voltage between BCM harness connector and ground.

(+)		(-)	Condition	Voltage (Approx.)	
BCM					
Connector	Terminal	Ground	Door lock and unlock switch	Battery voltage	
M29	55				Unlock
M25	65				Lock

Is the inspection result normal?

DOOR LOCK ACTUATOR

< DTC/CIRCUIT DIAGNOSIS >

YES >> Check for internal short of each door lock actuator.

NO >> Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

DOOR LOCK AND UNLOCK SWITCH

< DTC/CIRCUIT DIAGNOSIS >

DOOR LOCK AND UNLOCK SWITCH DRIVER SIDE

DRIVER SIDE : Component Function Check

INFOID:000000010639756

1. CHECK FUNCTION

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "CDL LOCK SW", "CDL UNLOCK SW" in "Data Monitor".
3. Check that the function operates normally according to the following conditions:

Monitor item	Condition	Status
CDL LOCK SW	Lock	ON
	Unlock	OFF
CDL UNLOCK SW	Lock	OFF
	Unlock	ON

Is the inspection result normal?

- YES >> Door lock and unlock switch is OK.
 NO >> Refer to [DLK-96, "DRIVER SIDE : Diagnosis Procedure"](#).


DRIVER SIDE : Diagnosis Procedure

INFOID:000000010639757

Regarding Wiring Diagram information, refer to [DLK-45, "Wiring Diagram"](#).

1. CHECK DOOR LOCK AND UNLOCK SWITCH INPUT SIGNAL

1. Turn power switch OFF.
2. Disconnect main power window and door lock/unlock switch connector.
3. Check signal between main power window and door lock/unlock switch harness connector and ground using oscilloscope.

(+)		(-)	Signal (Reference value)
Connector	Terminal		
D35	3 15	Ground	 <p style="text-align: right; font-size: small;">JPMIA0012GB 1.0 - 1.5 V</p>

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 2.

2. CHECK DOOR LOCK AND UNLOCK SWITCH CIRCUIT

1. Disconnect BCM connector and power window and door lock/unlock switch RH connector.
2. Check continuity between BCM harness connector and main power window and door lock/unlock switch harness connector.

DOOR LOCK AND UNLOCK SWITCH

< DTC/CIRCUIT DIAGNOSIS >

BCM		Main power window and door lock/unlock switch		Continuity
Connector	Terminal	Connector	Terminal	
M24	12	D35	3	Yes
	13		15	

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M24	12		No
	13		

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK DOOR LOCK AND UNLOCK SWITCH GROUND

Check continuity between main power window and door lock/unlock switch harness connector and ground.

Main power window and door lock/unlock switch		Ground	Continuity
Connector	Terminal		
D35	1		Yes

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK DOOR LOCK AND UNLOCK SWITCH

Refer to [DLK-97, "DRIVER SIDE : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-63, "Removal and Installation"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-53, "Intermittent Incident"](#).

>> Inspection End.

DRIVER SIDE : Component Inspection

INFOID:000000010639758

1.CHECK DOOR LOCK AND UNLOCK SWITCH

1. Turn power switch OFF.
2. Disconnect main power window and door lock/unlock switch connector.
3. Check continuity between main power window and door lock/unlock switch terminals.

Main power window and door lock/unlock switch		Condition	Continuity
Terminal			
3	1	Door lock and unlock switch	LOCK Yes
		UNLOCK No	
15		LOCK No	
		UNLOCK Yes	

Is the inspection result normal?

YES >> Inspection End.

DOOR LOCK AND UNLOCK SWITCH

< DTC/CIRCUIT DIAGNOSIS >

NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-63. "Removal and Installation"](#).

PASSENGER SIDE

PASSENGER SIDE : Component Function Check

INFOID:000000010639759

1. CHECK FUNCTION

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "CDL LOCK SW", "CDL UNLOCK SW" in "Data Monitor".
3. Check that the function operates normally according to the following conditions:

Monitor item	Condition	Status
CDL LOCK SW	Lock	ON
	Unlock	OFF
CDL UNLOCK SW	Lock	OFF
	Unlock	ON

Is the inspection result normal?

YES >> Door lock and unlock switch is OK.

NO >> Refer to [DLK-98. "PASSENGER SIDE : Diagnosis Procedure"](#).


PASSENGER SIDE : Diagnosis Procedure

INFOID:000000010639760

Regarding Wiring Diagram information, refer to [DLK-45. "Wiring Diagram"](#).

1. CHECK DOOR LOCK AND UNLOCK SWITCH INPUT SIGNAL

1. Turn power switch OFF.
2. Disconnect power window and door lock/unlock switch RH connector.
3. Check signal between power window and door lock/unlock switch RH harness connector and ground using oscilloscope.

(+)		(-)	Signal (Reference value)
Connector	Terminal		
D104	1	Ground	 <p>1.0 - 1.5 V</p> <p>JPMIA0012GB</p>
	2		

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK DOOR LOCK AND UNLOCK SWITCH CIRCUIT

1. Disconnect BCM connector and main power window and door lock/unlock switch connector.
2. Check continuity between BCM harness connector and power window and door lock/unlock switch RH harness connector.

DOOR LOCK AND UNLOCK SWITCH

< DTC/CIRCUIT DIAGNOSIS >

BCM		Power window and door lock/unlock switch RH		Continuity
Connector	Terminal	Connector	Terminal	
M24	12	D104	1	Yes
	13		2	

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M24	12		No
	13		

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

NO >> Repair or replace harness.

3. CHECK DOOR LOCK AND UNLOCK SWITCH GROUND

Check continuity between power window and door lock/unlock switch RH harness connector and ground.

Power window and door lock/unlock switch RH		Ground	Continuity
Connector	Terminal		
D104	3		Yes

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4. CHECK DOOR LOCK AND UNLOCK SWITCH

Refer to [DLK-99, "PASSENGER SIDE : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace power window and door lock/unlock switch RH. Refer to [PWC-63, "Removal and Installation"](#).

5. CHECK INTERMITTENT INCIDENT

Refer to [GI-53, "Intermittent Incident"](#).

>> Inspection End.

PASSENGER SIDE : Component Inspection

INFOID:000000010639761

1. CHECK DOOR LOCK AND UNLOCK SWITCH

1. Turn power switch OFF.
2. Disconnect power window and door lock/unlock switch RH connector.
3. Check continuity between power window and door lock/unlock switch RH terminals.

Power window and door lock/unlock switch RH		Condition	Continuity
Terminal			
1	3	Door lock and unlock switch	LOCK Yes
2		UNLOCK No	
		LOCK No	
		UNLOCK Yes	

Is the inspection result normal?

YES >> Inspection End.

DOOR LOCK AND UNLOCK SWITCH

< DTC/CIRCUIT DIAGNOSIS >

NO >> Replace power window and door lock/unlock switch RH. Refer to [PWC-63. "Removal and Installation"](#).

DOOR REQUEST SWITCH

< DTC/CIRCUIT DIAGNOSIS >

DOOR REQUEST SWITCH

Component Function Check

INFOID:0000000110639762

1.CHECK FUNCTION

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "REQ SW-DR", "REQ SW-AS" in "Data Monitor".
3. Check that the function operates normally according to the following conditions:

Monitor item	Condition		Status
REQ SW -DR	LH door request switch	Pressed	ON
		Released	OFF
REQ SW -AS	RH door request switch	Pressed	ON
		Released	OFF

Is the inspection result normal?

- YES >> Door request switch is OK.
NO >> Refer to [DLK-101, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000110639763

Regarding Wiring Diagram information, refer to [DLK-45, "Wiring Diagram"](#).

1.CHECK DOOR REQUEST SWITCH INPUT SIGNAL

1. Turn power switch OFF.
2. Disconnect malfunctioning door request switch connector.
3. Check voltage between malfunctioning door request switch harness connector and ground.

(+)		Terminal	(-)	Voltage (Approx.)
Door request switch				
Connector				
LH	D15	1	Ground	Battery voltage
RH	D115			

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2.CHECK DOOR REQUEST SWITCH CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between malfunctioning door request switch harness connector and BCM harness connector.

Door request switch		BCM		Continuity
Connector	Terminal	Connector	Terminal	
LH	D15	M23	75	Yes
RH	D115		100	

3. Check continuity between malfunctioning door request switch harness connector and ground.

DOOR REQUEST SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Door request switch		Terminal	Ground	Continuity
Connector				Continuity
LH	D15	1		No
RH	D115			

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-72. "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK DOOR REQUEST SWITCH GROUND CIRCUIT

Check continuity between malfunctioning door request switch harness connector and ground.

Door request switch		Terminal	Ground	Continuity
Connector				Continuity
LH	D15	2		Yes
RH	D115			

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK DOOR REQUEST SWITCH

Refer to [DLK-102. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace malfunctioning front outside handle (request switch). Refer to [DLK-194. "OUTSIDE HANDLE : Removal and Installation"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-53. "Intermittent Incident"](#).

>> Inspection End.

Component Inspection

INFOID:000000010639764

1.CHECK DOOR REQUEST SWITCH

1. Turn power switch OFF.
2. Disconnect malfunctioning door request switch connector.
3. Check continuity between malfunctioning door request switch terminals.

Door request switch		Condition	Continuity
Terminal			
1	2	Door request switch Pressed	Yes
		Released	No

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace malfunctioning Front outside handle (request switch). Refer to [DLK-194. "OUTSIDE HANDLE : Removal and Installation"](#).

DOOR SWITCH

< DTC/CIRCUIT DIAGNOSIS >

DOOR SWITCH

Component Function Check

INFOID:0000000110639765

1.CHECK FUNCTION

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "DOOR SW-DR", "DOOR SW-AS", "DOOR SW-RL", "DOOR SW-RR", "DOOR SW-BK" in "Data Monitor".
3. Check that the function operates normally according to the following conditions:

Monitor item	Condition		Status
DOOR SW-DR	Front door LH	Open	ON
		Closed	OFF
DOOR SW-AS	Front door RH	Open	ON
		Closed	OFF
DOOR SW-RL	Rear door LH	Open	ON
		Closed	OFF
DOOR SW-RR	Rear door RH	Open	ON
		Closed	OFF
DOOR SW-BK	Back door	Open	ON
		Closed	OFF

Is the inspection result normal?

- YES >> Door switch is OK.
 NO >> Refer to [DLK-103. "Diagnosis Procedure"](#).


Diagnosis Procedure

INFOID:0000000110639766

Regarding Wiring Diagram information, refer to [DLK-45. "Wiring Diagram"](#).

1.CHECK DOOR SWITCH INPUT SIGNAL

1. Turn power switch OFF.
2. Disconnect malfunctioning door switch connector.
3. Check signal between malfunctioning door switch harness connector and ground using oscilloscope.

(+)		(-)	Signal (Reference value)
Door switch			
Connector	Terminal	Ground	
Front LH	B48		
Front RH	B49		
Rear LH	B71		
Rear RH	B53		
Back door	D562		

Is the inspection result normal?

- YES-1 >> Back door: GO TO 3.
 YES-2 >> Other door: GO TO 4.
 NO >> GO TO 2.

2.CHECK DOOR SWITCH CIRCUIT

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DOOR SWITCH

< DTC/CIRCUIT DIAGNOSIS >

1. Disconnect BCM connector.
2. Check continuity between door switch harness connector and BCM harness connector.

Door switch		BCM		Continuity
Connector	Terminal	Connector	Terminal	
Front LH	B48	3	M29	47
Front RH	B49			45
Rear LH	B71			48
Rear RH	B53			46
Back door	D562			43
				Yes

3. Check continuity between door switch harness connector and ground.

Door switch		Terminal	Ground	Continuity
Connector	Terminal			
Front LH	B48	3		No
Front RH	B49			
Rear LH	B71			
Rear RH	B53			
Back door	D562			

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK BACK DOOR SWITCH GROUND CIRCUIT

Check continuity between back door lock assembly harness connector and ground.

Back door lock assembly		Ground	Continuity
Connector	Terminal		
D562	4		Yes

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK DOOR SWITCH

Refer to [DLK-104, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace malfunctioning door switch.

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-53, "Intermittent Incident"](#).

>> Inspection End.

Component Inspection

INFOID:0000000010639767

1.CHECK DOOR SWITCH

1. Turn power switch OFF.
2. Disconnect malfunctioning door switch connector.
3. Check continuity between door switch terminals.

DOOR SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Door switch			Condition	Continuity	
Terminal					
<ul style="list-style-type: none"> • Front LH • Front RH • Rear LH • Rear RH 	3	Ground part of door switch	Door switch	Pressed Released	Yes No
		4	Back door lock	Lock Unlock	Yes No
Back door					

Is the inspection result normal?

- YES >> Inspection End.
- NO >> Replace malfunctioning door switch.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

HAZARD FUNCTION

< DTC/CIRCUIT DIAGNOSIS >

HAZARD FUNCTION

Component Function Check

INFOID:000000010639768

1.CHECK FUNCTION

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "FLASHER" in "Active Test".
3. Touch "LH" or "RH" to check that it works normally.

Is the inspection result normal?

- YES >> Hazard warning lamp circuit is OK.
NO >> Refer to [DLK-106. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000010639769

1.CHECK HAZARD SWITCH CIRCUIT

Refer to [EXL-113. "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace the malfunctioning parts.

2.CHECK INTERMITTENT INCIDENT

Refer to [GI-53. "Intermittent Incident"](#).

>> Inspection End.

INTELLIGENT KEY

< DTC/CIRCUIT DIAGNOSIS >

INTELLIGENT KEY

Component Function Check

INFOID:0000000110639770

1.CHECK FUNCTION

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "RKE OPE COUN1" in "Data Monitor".
3. Check that the function operates normally according to the following conditions:

Monitor item	Condition
RKE OPE COUN1	Check that the numerical value is changing while operating on the Intelligent Key.

Is the inspection result normal?

- YES >> Intelligent Key is OK.
NO >> Refer to [DLK-107. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000110639771


1.CHECK INTELLIGENT KEY BATTERY

Check by connecting a resistance (approximately 300 Ω) so that the current value becomes about 10 mA. Refer to [DLK-211. "Removal and Installation"](#).

Standard : Approx. 2.5 - 3.0 V

Is the measurement value within the specification?

- YES >> Replace Intelligent Key.
NO >> Replace Intelligent Key battery.



A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

INTELLIGENT KEY WARNING BUZZER

< DTC/CIRCUIT DIAGNOSIS >

INTELLIGENT KEY WARNING BUZZER

Component Function Check

INFOID:000000010639772

1.CHECK FUNCTION

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "OUTSIDE BUZZER" in "Active Test".
3. Touch "ON" to check that it works normally.

Is the inspection result normal?

- YES >> Intelligent Key warning buzzer is OK.
NO >> Refer to [DLK-108, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000010639773

Regarding Wiring Diagram information, refer to [DLK-45, "Wiring Diagram"](#).

1.CHECK FUSE

1. Turn power switch OFF.
2. Check 10 A fuse, [No. 13, located in fuse block (J/B)].

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Replace the blown fuse after repairing the affected circuit.

2.CHECK INTELLIGENT KEY WARNING BUZZER POWER SUPPLY CIRCUIT

1. Disconnect Intelligent Key warning buzzer connector.
2. Check voltage between Intelligent Key warning buzzer harness connector and ground.

(+)		(-)	Voltage (Approx.)
Connector	Terminal		
E28	1	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace harness.

3.CHECK INTELLIGENT KEY WARNING BUZZER CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and Intelligent Key warning buzzer harness connector.

BCM		Intelligent Key warning buzzer		Continuity
Connector	Terminal	Connector	Terminal	
M23	93	E28	3	Yes

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M23	93		No

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace harness.

4.CHECK INTELLIGENT KEY WARNING BUZZER

INTELLIGENT KEY WARNING BUZZER

< DTC/CIRCUIT DIAGNOSIS >

Refer to [DLK-109. "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-72. "Removal and Installation"](#).

NO >> Replace Intelligent Key warning buzzer. Refer to [DLK-209. "Removal and Installation"](#).

Component Inspection

INFOID:000000010639774

1. CHECK INTELLIGENT KEY WARNING BUZZER

1. Turn power switch OFF.
2. Disconnect Intelligent Key warning buzzer connector.
3. Connect battery power supply directly to Intelligent Key warning buzzer terminals and check the operation.

Intelligent Key warning buzzer		Operation
Terminal		
(+)	(-)	
1	3	Buzzer sounds

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace Intelligent Key warning buzzer. Refer to [DLK-209. "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

REMOTE KEYLESS ENTRY RECEIVER

< DTC/CIRCUIT DIAGNOSIS >

REMOTE KEYLESS ENTRY RECEIVER

Component Function Check

INFOID:000000010639775

1.CHECK FUNCTION

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "RKE OPE COUN1" in "Data Monitor".
3. Check that the function operates normally according to the following conditions:

Monitor item	Condition
RKE OPE COUN1	Checks whether value changes when operating Intelligent Key

Is the inspection result normal?

- YES >> Remote keyless entry receiver is OK.
NO >> Refer to [DLK-110, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000010639776

Regarding Wiring Diagram information, refer to [DLK-45, "Wiring Diagram"](#).

1.CHECK REMOTE KEYLESS ENTRY RECEIVER POWER SUPPLY

1. Turn power switch OFF.
2. Disconnect remote keyless entry receiver connector.
3. Check voltage between remote keyless entry receiver harness connector and ground.

(+)		(-)	Voltage (Approx.)
Connector	Terminal		
M75	1	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2.DETECT MALFUNCTIONING PART

Check the following:

- 10 A fuse (No. 7)
- Harness for open or short between remote keyless entry receiver and battery.

Is the inspection result normal?

- YES >> GO TO 7.
NO >> Repair or replace the malfunctioning parts.

3.CHECK REMOTE KEYLESS ENTRY RECEIVER GROUND CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and remote keyless entry receiver harness connector.

BCM		Remote keyless entry receiver		Continuity
Connector	Terminal	Connector	Terminal	
M24	18	M75	4	Yes

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M24	18		No

REMOTE KEYLESS ENTRY RECEIVER

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace harness.

4. CHECK BCM SIGNAL

1. Reconnect BCM connector.
2. Check voltage between remote keyless entry receiver harness connector and ground.

(+)		(-)	Voltage (Approx.)
Remote keyless entry receiver			
Connector	Terminal	Ground	Battery voltage
M75	2		

Is the inspection result normal?

- YES >> GO TO 6.
NO >> GO TO 5.

5. CHECK REMOTE KEYLESS ENTRY RECEIVER CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and remote keyless entry receiver harness connector.

BCM		Remote keyless entry receiver		Continuity
Connector	Terminal	Connector	Terminal	
M24	38	M75	2	Yes

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M24	38		No

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).
NO >> Repair or replace harness.

6. CHECK REMOTE KEYLESS ENTRY RECEIVER OUTPUT SIGNAL

1. Reconnect remote keyless entry receiver connector.
2. Check signal between remote keyless entry receiver harness connector and ground using oscilloscope.

(+)		(-)	Condition	Signal (Reference value)
Remote keyless entry receiver				
Connector	Terminal	Ground	Waiting	Battery voltage
M75	2			

JMMIA0572GB

Is the inspection result normal?

- YES >> GO TO 7.
NO >> Replace remote keyless entry receiver. Refer to [DLK-210, "Removal and Installation"](#).

7. CHECK INTERMITTENT INCIDENT

Refer to [GI-53, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

REMOTE KEYLESS ENTRY RECEIVER

< DTC/CIRCUIT DIAGNOSIS >

>> Inspection End.

UNLOCK SENSOR

< DTC/CIRCUIT DIAGNOSIS >

UNLOCK SENSOR

Component Function Check

INFOID:000000010639777

1.CHECK FUNCTION

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "UNLK SEN -DR" in "Data Monitor".
3. Check that the function operates normally according to the following conditions:

Monitor item	Condition		Status
UNLK SEN -DR	Driver side door	Lock	OFF
		Unlock	ON

Is the inspection result normal?

- YES >> Unlock sensor is OK.
 NO >> Refer to [DLK-113. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000010639778

Regarding Wiring Diagram information, refer to [DLK-45. "Wiring Diagram"](#).

1.CHECK BCM OUTPUT SIGNAL

1. Turn power switch OFF.
2. Disconnect front door lock assembly (LH) connector.
3. Check signal between front door lock assembly (LH) harness connector and ground using oscilloscope.

(+)		(-)	Signal (Reference value)
Connector	Terminal		
D38	3	Ground	

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 2.

2.CHECK UNLOCK SENSOR CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and front door lock assembly (LH) harness connector.

BCM		Front door lock assembly (LH)		Continuity
Connector	Terminal	Connector	Terminal	
M24	31	D38	3	Yes

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M24	31		No

UNLOCK SENSOR

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK UNLOCK SENSOR GROUND CIRCUIT

Check continuity between front door lock assembly (LH) harness connector and ground.

Front door lock assembly (LH)		Ground	Continuity
Connector	Terminal		
D38	4		Yes

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK UNLOCK SENSOR

Refer to [DLK-114, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace front door lock assembly (LH). Refer to [DLK-193, "DOOR LOCK : Removal and Installation"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-53, "Intermittent Incident"](#).

>> Inspection End.

Component Inspection

INFOID:000000010639779

1.CHECK UNLOCK SENSOR

1. Turn power switch OFF.
2. Disconnect front door lock assembly (LH) connector.
3. Check continuity between front door lock assembly (LH) terminals.

Front door lock assembly (LH)		Condition	Continuity
Terminal			
3	4	Driver side door	Unlock Yes
			Lock No

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace front door lock assembly (LH). Refer to [DLK-193, "DOOR LOCK : Removal and Installation"](#).

INFORMATION DISPLAY

< DTC/CIRCUIT DIAGNOSIS >

INFORMATION DISPLAY

Component Function Check

INFOID:000000010639780

1.CHECK FUNCTION

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "LCD" in "Active Test".
3. Check each warning display on meter display.

Is the inspection result normal?

- YES >> Information display is OK.
NO >> Refer to [DLK-115. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000010639781

1.CHECK COMBINATION METER

Refer to [MWI-48. "Description"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace the malfunctioning parts.

2.CHECK INTERMITTENT INCIDENT

Refer to [GI-53. "Intermittent Incident"](#).

>> Inspection End.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

CHARGE PORT LID OPENER RELAY

< DTC/CIRCUIT DIAGNOSIS >

CHARGE PORT LID OPENER RELAY

Diagnosis Procedure

INFOID:000000010639782

Regarding Wiring Diagram information, refer to [DLK-45, "Wiring Diagram"](#).

1. CHECK CHARGE PORT LID OPENER ACTUATOR RELAY POWER SUPPLY-1

1. Turn power switch OFF.
2. Disconnect charge port lid opener actuator relay.
3. Check the voltage between charge port lid opener actuator relay harness connector and ground.

+		-	Voltage (Approx.)
Charge port lid opener actuator relay			
Connector	Terminal		
E88	5	Ground	12V battery voltage

Is the inspection result normal?

- YES >> GO TO 5.
NO >> GO TO 2.

2. CHECK CHARGE PORT LID OPENER ACTUATOR RELAY POWER SUPPLY-2

Check the voltage between IPDM E/R harness connector and ground.

+		-	Voltage (Approx.)
IPDM E/R			
Connector	Terminal		
E14	42	Ground	12V battery voltage

Is the inspection result normal?

- YES >> GO TO 4.
NO >> GO TO 3.

3. CHECK FUSE

1. Remove 20A fuse #43 from IPDM E/R.
2. Check that the fuse is not blown.

Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-30, "Removal and Installation"](#).
NO >> Replace the fuse after repairing the applicable circuit.

4. CHECK CHARGE PORT LID OPENER ACTUATOR RELAY POWER SUPPLY CIRCUIT

1. Disconnect IPDM E/R harness connector.
2. Check the continuity between IPDM E/R harness connector and charge port lid opener actuator relay harness connector.

+		-		Continuity
IPDM E/R		Charge port lid opener actuator relay		
Connector	Terminal	Connector	Terminal	
E14	42	E88	5	Yes

3. Also check harness for short to ground and short to voltage.

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).
NO >> Repair or replace malfunctioning component.

CHARGE PORT LID OPENER RELAY

< DTC/CIRCUIT DIAGNOSIS >

5. CHARGE PORT LID OPENER ACTUATOR RELAY CONTROL SIGNAL VOLTAGE

Check the voltage between charge port lid opener actuator relay harness connector under the following condition:

+		-	Condition	Voltage (Approx.)
Charge port lid opener actuator relay				
Connector	Terminal			
E88	1	Ground	Immediately after the charge port lid opener switch is pressed.	12V battery voltage

Is the inspection result normal?

- YES >> GO TO 8.
- NO >> GO TO 6.

6. CHECK CHARGE PORT LID OPENER ACTUATOR RELAY DRIVE CIRCUIT

1. Disconnect VCM harness connector.
2. Check the continuity between VCM harness connector and charge port lid opener actuator relay harness connector.

+		-		Continuity
VCM		Charge port lid opener actuator relay		
Connector	Terminal	Connector	Terminal	
E61	23	E88	1	Yes

3. Also check harness for short to ground and short to voltage.

Is the inspection result normal?

- YES >> GO TO 7.
- NO >> Repair or replace malfunctioning component.

7. CHECK CHARGE PORT LID OPENER SWITCH RELATED CIRCUIT

Check charge port lid opener switch related circuit. Refer to [DLK-121, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).
- NO >> Repair or replace malfunctioning component.

8. CHECK CHARGE PORT LID OPENER ACTUATOR RELAY GROUND CIRCUIT

Check the continuity between charge port lid opener actuator relay harness connector and ground.

+		-	Continuity
Charge port lid opener actuator relay			
Connector	Terminal		
E88	2	Ground	Yes

Is the inspection result normal?

- YES >> GO TO 9.
- NO >> Repair or replace malfunctioning component.

Component Inspection (Charge Port Lid Opener Actuator Relay)

INFOID:000000010639783

1. CHECK CHARGE PORT LID OPENER ACTUATOR RELAY

1. Turn power switch OFF.
2. Disconnect charge port lid opener actuator relay.

CHARGE PORT LID OPENER RELAY

< DTC/CIRCUIT DIAGNOSIS >


3. Check the continuity between charge port lid opener actuator relay terminals under the following conditions:

Terminals	Conditions	Continuity
3 and 5	12 V direct current supply between terminals 1 and 2	Yes
	No current supply	No

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace charge port lid opener actuator relay.



CHARGE PORT LID OPENER

< DTC/CIRCUIT DIAGNOSIS >

CHARGE PORT LID OPENER

Component Function Check

INFOID:0000000110639784

1. CHARGE PORT LID OPENER FUNCTION CHECK

1. Close charge port lid.
2. Press charge port lid opener switch.

Does the charge port lid open?

- YES >> Inspection End.
NO >> Proceed to [EVC-397. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000110639785

Regarding Wiring Diagram information, refer to [DLK-45. "Wiring Diagram"](#).

1. CHECK CHARGE PORT LID OPENER ACTUATOR RELAY RELATED CIRCUIT

Check charge port lid opener actuator relay related circuit. Refer to [DLK-116. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace malfunctioning component.

2. CHECK CHARGE PORT LID OPENER ACTUATOR

Check charge port lid opener actuator. Refer to [DLK-120. "Component Inspection \(Charge Port Lid Opener Actuator\)"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Replace charge port lid opener actuator. Refer to [DLK-192. "CHARGE PORT LID OPENER ACTUATOR : Removal and Installation"](#).

3. CHECK CHARGE PORT LID OPENER ACTUATOR CONTROL CIRCUIT

1. Check the continuity between charge port lid opener actuator relay harness connector and charge port lid opener actuator harness connector.

+		-		Continuity
Charge port lid opener actuator relay		Charge port lid opener actuator		
Connector	Terminal	Connector	Terminal	
E88	3	E38	3	Yes

2. Also check harness for short to ground and short to voltage.

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace malfunctioning component.

4. CHECK CHARGE PORT LID OPENER ACTUATOR GROUND CIRCUIT

Check the continuity between charge port lid opener actuator harness connector and ground.

+		-	Continuity
Charge port lid opener actuator relay			
Connector	Terminal		
E88	2	Ground	Yes

Is the inspection result normal?

- YES >> Inspection End.

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

CHARGE PORT LID OPENER

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair or replace malfunctioning component.

Component Inspection (Charge Port Lid Opener Actuator)

INFOID:000000010639786

1. CHECK CHARGE PORT LID OPENER ACTUATOR

1. Turn power switch OFF.
2. Remove charge port lid opener actuator. Refer to [DLK-192. "CHARGE PORT LID OPENER ACTUATOR : Removal and Installation"](#).
3. Check the resistance between charge port lid opener actuator connector terminals.

Charge port lid opener actuator		Resistance
+	-	
Terminal		
1	3	1 – 4 Ω

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace charge port lid opener actuator. Refer to [DLK-192. "CHARGE PORT LID OPENER ACTUATOR : Removal and Installation"](#).

CHARGE PORT LID OPENER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

CHARGE PORT LID OPENER SWITCH

Diagnosis Procedure

INFOID:0000000110639787

Regarding Wiring Diagram information, refer to [DLK-45. "Wiring Diagram"](#).

1. CHECK CHARGE PORT LID OPENER SWITCH SIGNAL CIRCUIT

1. Disconnect VCM harness connector.
2. Check the continuity between charge port lid opener switch harness connector and VCM harness connector.

+		-		Continuity
Charge port lid opener switch		VCM		
Connector	Terminal	Connector	Terminal	
M93	6	E62	93	Yes

3. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace malfunctioning component.

2. CHECK CHARGE PORT LID OPENER SWITCH GROUND CIRCUIT

Check the continuity between charge port lid opener switch harness connector and ground.

+		-	Continuity
Charge port lid opener switch			
Connector	Terminal		
M93	8	Ground	Yes

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning component.

3. CHECK CHARGE PORT LID OPENER SWITCH

Check charge port lid opener switch. Refer to [DLK-121. "Component Inspection \(Charge Port Lid Opener Switch\)"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace charge port lid opener switch. Refer to [DLK-212. "Removal and Installation"](#).

Component Inspection (Charge Port Lid Opener Switch)

INFOID:0000000110639788

1. CHECK CHARGE PORT LID OPENER SWITCH

1. Turn power switch OFF.
2. Disconnect charge port lid opener switch harness connector.
3. Check the continuity between charge port lid opener switch terminals under the following condition:

Terminal	Condition		Continuity
6 – 8	Charge port lid opener switch	Released	No
		Pressed	Yes

Is the inspection result normal?

YES >> Inspection End.

CHARGE PORT LID OPENER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

NO >> Replace charge port lid opener switch. Refer to [DLK-212. "Removal and Installation"](#).

HOMELINK UNIVERSAL TRANSCEIVER

< DTC/CIRCUIT DIAGNOSIS >

HOMELINK UNIVERSAL TRANSCEIVER

Component Function Check

INFOID:0000000110639789

1.CHECK FUNCTION

Check that system receiver (garage door opener, etc.) operates with original hand-held transmitter.

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Receiver or hand-held transmitter is malfunctioning.

2.CHECK ILLUMINATE

1. Turn power switch OFF.
2. Does red light of transmitter illuminate when any transmitter button is pressed?

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Refer to [DLK-123, "Diagnosis Procedure"](#).

3.CHECK TRANSMITTER

Check transmitter with Tool*.

*:For details, refer to Technical Service Bulletin.

Is the inspection result normal?

- YES >> Receiver or hand-held transmitter malfunction, not vehicle related.
- NO >> Replace auto anti-dazzling inside mirror (HomeLink® Universal Transceiver).

Diagnosis Procedure

INFOID:0000000110639790

Regarding Wiring Diagram information, refer to [DLK-45, "Wiring Diagram"](#).

1.CHECK POWER SUPPLY

1. Turn power switch OFF.
2. Disconnect auto anti-dazzling inside mirror (HomeLink® Universal Transceiver) connector.
3. Check voltage between auto anti-dazzling inside mirror (HomeLink® Universal Transceiver) harness connector and ground.

DLK

(+)		(-)	Voltage (Approx.)
Auto anti-dazzling inside mirror (HomeLink® Universal Transceiver)			
Connector	Terminal		
R7	6	Ground	Battery voltage
	10		

Is the inspection result normal?

- YES >> GO TO 2.
- NO-1 >> Check 10 A fuse [No. 3, No.13].
- NO-2 >> Harness for open or short between fuse and auto anti-dazzling inside mirror (HomeLink® Universal Transceiver).

2.CHECK GROUND CIRCUIT

Check continuity between auto anti-dazzling inside mirror (HomeLink® Universal Transceiver) harness connector and ground.

HOMELINK UNIVERSAL TRANSCEIVER

< DTC/CIRCUIT DIAGNOSIS >

Auto anti-dazzling inside mirror (HomeLink® Universal Transceiver)		Ground	Continuity
Connector	Terminal		
R7	8		Yes

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3.CHECK INTERMITTENT INCIDENT

Refer to [GI-53, "Intermittent Incident"](#).

>> Inspection End.

DOOR DOES NOT LOCK/UNLOCK WITH DOOR LOCK AND UNLOCK SWITCH

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

DOOR DOES NOT LOCK/UNLOCK WITH DOOR LOCK AND UNLOCK SWITCH

ALL DOOR

ALL DOOR : Description

INFOID:0000000010639791

All doors do not lock/unlock using door lock and unlock switch.

ALL DOOR : Diagnosis Procedure

INFOID:0000000010639792

1.CHECK DOOR LOCK AND UNLOCK SWITCH

Check door lock and unlock switch.

Refer to [DLK-96. "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK DOOR LOCK ACTUATOR

Check front door lock assembly (LH).

Refer to [DLK-90. "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CHECK DOOR SWITCH

Check door switch.

Refer to [DLK-103. "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4.REPLACE BCM

1. Replace BCM. Refer to [BCS-72. "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-53. "Intermittent Incident"](#).

DRIVER SIDE

DRIVER SIDE : Description

INFOID:0000000010639793

Driver side door does not lock/unlock using door lock and unlock switch.

DRIVER SIDE : Diagnosis Procedure

INFOID:0000000010639794

1.CHECK DOOR LOCK ACTUATOR

Check front door lock assembly (LH).

Refer to [DLK-90. "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.REPLACE BCM

1. Replace BCM. Refer to [BCS-72. "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
DLK

DOOR DOES NOT LOCK/UNLOCK WITH DOOR LOCK AND UNLOCK SWITCH

< SYMPTOM DIAGNOSIS >

2. Confirm the operation after replacement.

Is the result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

PASSENGER SIDE

PASSENGER SIDE : Description

INFOID:0000000010639795

Passenger side door does not lock/unlock using door lock and unlock switch.

PASSENGER SIDE : Diagnosis Procedure

INFOID:0000000010639796

1.CHECK DOOR LOCK ACTUATOR

Check front door lock actuator RH.

Refer to [DLK-91, "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.REPLACE BCM

1. Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

REAR LH

REAR LH : Description

INFOID:0000000010639797

Rear LH side door does not lock/unlock using door lock and unlock switch.

REAR LH : Diagnosis Procedure

INFOID:0000000010639798

1.CHECK DOOR LOCK ACTUATOR

Check rear door lock actuator LH.

Refer to [DLK-92, "REAR LH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.REPLACE BCM

1. Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

REAR RH

REAR RH : Description

INFOID:0000000010639799

Rear RH side door does not lock/unlock using door lock and unlock switch.

REAR RH : Diagnosis Procedure

INFOID:0000000010639800

1.CHECK DOOR LOCK ACTUATOR

Check rear door lock actuator RH.

Refer to [DLK-93, "REAR RH : Component Function Check"](#).

DOOR DOES NOT LOCK/UNLOCK WITH DOOR LOCK AND UNLOCK SWITCH

< SYMPTOM DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.REPLACE BCM

1. Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

DOOR DOES NOT LOCK/UNLOCK WITH DOOR REQUEST SWITCH

< SYMPTOM DIAGNOSIS >

DOOR DOES NOT LOCK/UNLOCK WITH DOOR REQUEST SWITCH ALL DOOR REQUEST SWITCHES

ALL DOOR REQUEST SWITCHES : Description

INFOID:0000000010639801

All doors do not lock/unlock using all door request switches.

ALL DOOR REQUEST SWITCHES : Diagnosis Procedure

INFOID:0000000010639802

1. CHECK REMOTE KEYLESS ENTRY FUNCTION

Check remote keyless entry function.

Does door lock/unlock with Intelligent Key button?

YES >> GO TO 2.

NO >> Refer to [DLK-132, "Diagnosis Procedure"](#).

2. CHECK "LOCK/UNLOCK BY I-KEY" SETTING IN "WORK SUPPORT"

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.

2. Select "LOCK/UNLOCK BY I-KEY" in "Work support".

3. Check "LOCK/UNLOCK BY I-KEY" in "Work support".

Refer to [BCS-20, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Set "LOCK/UNLOCK BY I-KEY" in "Work support".

3. CHECK INSIDE KEY ANTENNA

Check inside key antenna.

• Instrument center: Refer to [DLK-69, "DTC Logic"](#).

• Rear seat: Refer to [DLK-71, "DTC Logic"](#).

• Luggage room: Refer to [DLK-73, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. CHECK OUTSIDE KEY ANTENNA

Check outside key antenna.

• LH: Refer to [DLK-77, "DTC Logic"](#).

• RH: Refer to [DLK-75, "DTC Logic"](#).

• Rear bumper: Refer to [DLK-79, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5. REPLACE BCM

1. Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

DRIVER SIDE DOOR REQUEST SWITCH

DRIVER SIDE DOOR REQUEST SWITCH : Description

INFOID:0000000010639803

All doors do not lock/unlock using LH door request switch.

DRIVER SIDE DOOR REQUEST SWITCH : Diagnosis Procedure

INFOID:0000000010639804

1. CHECK DTC WITH BCM

DOOR DOES NOT LOCK/UNLOCK WITH DOOR REQUEST SWITCH

< SYMPTOM DIAGNOSIS >

Check that DTC is not detected with BCM.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refer to [BCS-48. "DTC Index"](#).

2.CHECK LH DOOR REQUEST SWITCH

Check LH door request switch.

Refer to [DLK-85. "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CHECK OUTSIDE KEY ANTENNA

Check outside key antenna (LH).

Refer to [DLK-77. "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4.REPLACE BCM

1. Replace BCM. Refer to [BCS-72. "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-53. "Intermittent Incident"](#).

PASSENGER SIDE DOOR REQUEST SWITCH

PASSENGER SIDE DOOR REQUEST SWITCH : Description

INFOID:000000010639805

All doors do not lock/unlock using RH door request switch.

PASSENGER SIDE DOOR REQUEST SWITCH : Diagnosis Procedure

INFOID:000000010639806

1.CHECK RH DOOR REQUEST SWITCH

Check RH door request switch.

Refer to [DLK-85. "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK OUTSIDE KEY ANTENNA

Check outside key antenna (RH).

Refer to [DLK-75. "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.REPLACE BCM

1. Replace BCM. Refer to [BCS-72. "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-53. "Intermittent Incident"](#).

BACK DOOR REQUEST SWITCH

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

DOOR DOES NOT LOCK/UNLOCK WITH DOOR REQUEST SWITCH

< SYMPTOM DIAGNOSIS >

BACK DOOR REQUEST SWITCH : Description

INFOID:000000010639807

All doors do not lock/unlock using back door request switch.

BACK DOOR REQUEST SWITCH : Diagnosis Procedure

INFOID:000000010639808

1.CHECK BACK DOOR REQUEST SWITCH

Check back door request switch.

Refer to [DLK-85. "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK OUTSIDE KEY ANTENNA

Check outside key antenna (rear bumper).

Refer to [BCS-48. "DTC Index"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.REPLACE BCM

1. Replace BCM. Refer to [BCS-72. "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-53. "Intermittent Incident"](#).

DOOR DOES NOT LOCK/UNLOCK WITH DOOR KEY CYLINDER OPERATION

< SYMPTOM DIAGNOSIS >

DOOR DOES NOT LOCK/UNLOCK WITH DOOR KEY CYLINDER OPERATION

Diagnosis Procedure

INFOID:000000010639809

1. CHECK POWER DOOR LOCK OPERATION

Check power door lock operation.

Does door lock/unlock with door lock and unlock switch?

YES >> GO TO 2.

NO >> Refer to [DLK-96, "DRIVER SIDE : Component Function Check"](#).

2. CHECK DOOR KEY CYLINDER SWITCH

Check door key cylinder switch.

Refer to [DLK-88, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. REPLACE BCM

1. Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

DOOR DOES NOT LOCK/UNLOCK WITH INTELLIGENT KEY

< SYMPTOM DIAGNOSIS >

DOOR DOES NOT LOCK/UNLOCK WITH INTELLIGENT KEY

Diagnosis Procedure

INFOID:000000010639810

1. CHECK DTC WITH BCM

Check that DTC is not detected with BCM.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refer to [BCS-48, "DTC Index"](#).

2. CHECK POWER DOOR LOCK OPERATION

Check door lock/unlock using door lock and unlock switch.

Does door lock/unlock using door lock and unlock switch?

YES >> GO TO 3.

NO >> Refer to [DLK-96, "DRIVER SIDE : Component Function Check"](#).

3. CHECK REMOTE KEYLESS ENTRY RECEIVER

Check remote keyless entry receiver.

Refer to [DLK-110, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. CHECK INTELLIGENT KEY

Check Intelligent Key.

Refer to [DLK-107, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5. REPLACE BCM

1. Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

POWER POSITION WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

POWER POSITION WARNING DOES NOT OPERATE

Diagnosis Procedure

INFOID:0000000010639811

1. CHECK DTC WITH BCM

Check that DTC is not detected with BCM.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refer to [BCS-48, "DTC Index"](#).

2. CHECK POWER DOOR LOCK OPERATION

Check power door lock operation.

Does door lock/unlock with driver side door lock knob and door key cylinder?

YES >> GO TO 3.

NO >> Refer to [DLK-23, "System Description"](#).

3. CHECK DOOR SWITCH

Check door switch.

Refer to [DLK-103, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. CHECK COMBINATION METER BUZZER

Check combination meter buzzer.

Refer to [DLK-87, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5. REPLACE BCM

1. Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

SELECTIVE UNLOCK FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

SELECTIVE UNLOCK FUNCTION DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000010639812

1. CHECK "DOOR LOCK-UNLOCK SET" SETTING IN "WORK SUPPORT"

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "DOOR LOCK-UNLOCK SET" in "Work support".
3. Check "DOOR LOCK-UNLOCK SET" in "Work support"
Refer to [BCS-15, "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

Is the inspection result normal?

- YES >> GO TO 2
NO >> Set "DOOR LOCK-UNLOCK SET" in "Work support".

2. REPLACE BCM

1. Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).
2. Confirm the operation after replacement.

Is the result normal?

- YES >> Inspection End.
NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

BACK DOOR DOES NOT OPEN

< SYMPTOM DIAGNOSIS >

BACK DOOR DOES NOT OPEN

Diagnosis Procedure

INFOID:000000010639813

1. CHECK DTC WITH BCM

Check that DTC is not detected with BCM.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refer to [BCS-48, "DTC Index"](#).

2. CHECK BACK DOOR OPENER SWITCH

Check back door opener switch.

Refer to [DLK-83, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK BACK DOOR OPENER ACTUATOR

Check back door opener actuator.

Refer to [DLK-81, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. CHECK VEHICLE SPEED SIGNAL

Check vehicle speed signal.

Refer to [MWI-65, "DTC Index"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5. REPLACE BCM

1. Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

AUTO DOOR LOCK OPERATION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

AUTO DOOR LOCK OPERATION DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000010639814

1. CHECK "AUTO LOCK SET" SETTING IN "WORK SUPPORT"

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "AUTO LOCK SET" in "Work support".
3. Check "AUTO LOCK SET" in "Work support".
Refer to [BCS-20, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Set "AUTO LOCK SET" setting in "Work support".

2. REPLACE BCM

1. Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).
2. Confirm the operation after replacement.

Is the result normal?

- YES >> Inspection End.
NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

VEHICLE SPEED SENSING AUTO LOCK OPERATION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

VEHICLE SPEED SENSING AUTO LOCK OPERATION DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000010639815

1. CHECK "AUTOMATIC LOCK/UNLOCK SELECT" SETTING IN "WORK SUPPORT"

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "AUTOMATIC LOCK/UNLOCK SELECT" in "Work support".
3. Check "AUTOMATIC LOCK/UNLOCK SELECT" in "Work support".
Refer to [BCS-15, "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Set "AUTOMATIC LOCK/UNLOCK SELECT" in "Work support".

2. CHECK "AUTOMATIC DOOR LOCK SELECT" SETTING IN "WORK SUPPORT"

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "AUTOMATIC DOOR LOCK SELECT" in "Work support".
3. Check "AUTOMATIC DOOR LOCK SELECT" in "Work support".
Refer to [BCS-15, "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Set "AUTOMATIC DOOR LOCK SELECT" in "Work support".

3. REPLACE BCM

1. Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).
2. Confirm the operation after replacement.

Is the result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

POWER SWITCH OFF INTERLOCK DOOR UNLOCK FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

POWER SWITCH OFF INTERLOCK DOOR UNLOCK FUNCTION DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000010639816

1. CHECK "AUTOMATIC LOCK/UNLOCK SELECT" SETTING IN "WORK SUPPORT"

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "AUTOMATIC LOCK/UNLOCK SELECT" in "Work support".
3. Check "AUTOMATIC LOCK/UNLOCK SELECT" in "Work support".
Refer to [BCS-15, "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Set "AUTOMATIC LOCK/UNLOCK SELECT" in "Work support".

2. CHECK "AUTOMATIC DOOR UNLOCK SELECT" SETTING IN "WORK SUPPORT"

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "AUTOMATIC DOOR UNLOCK SELECT" in "Work support".
3. Check "AUTOMATIC DOOR UNLOCK SELECT" in "Work support".
Refer to [BCS-15, "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Set "AUTOMATIC DOOR UNLOCK SELECT" in "Work support".

3. REPLACE BCM

1. Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).
2. Confirm the operation after replacement.

Is the result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

P POSITION INTERLOCK DOOR LOCK/UNLOCK FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

P POSITION INTERLOCK DOOR LOCK/UNLOCK FUNCTION DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000010639817

1. CHECK "AUTOMATIC LOCK/UNLOCK SELECT" SETTING IN "WORK SUPPORT"

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "AUTOMATIC LOCK/UNLOCK SELECT" in "Work support".
3. Check "AUTOMATIC LOCK/UNLOCK SELECT" in "Work support".
Refer to [BCS-15, "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Set "AUTOMATIC LOCK/UNLOCK SELECT" in "Work support".

2. CHECK "AUTOMATIC DOOR LOCK SELECT" SETTING IN "WORK SUPPORT"

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "AUTOMATIC DOOR LOCK SELECT" in "Work support".
3. Check "AUTOMATIC DOOR LOCK SELECT" in "Work support".
Refer to [BCS-15, "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Set "AUTOMATIC DOOR LOCK SELECT" in "Work support".

3. CHECK "AUTOMATIC DOOR UNLOCK SELECT" SETTING IN "WORK SUPPORT"

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "AUTOMATIC DOOR UNLOCK SELECT" in "Work support".
3. Check "AUTOMATIC DOOR UNLOCK SELECT" in "Work support".
Refer to [BCS-15, "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Set "AUTOMATIC DOOR UNLOCK SELECT" in "Work support".

4. REPLACE BCM

1. Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).
2. Confirm the operation after replacement.

Is the result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

HAZARD AND BUZZER REMINDER DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

HAZARD AND BUZZER REMINDER DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000010639818

1. CHECK DTC WITH BCM AND COMBINATION METER

Check that DTC is not detected with BCM and combination meter.

Is the inspection result normal?

- YES >> GO TO 2.
- NO-1 >> Refer to [BCS-48, "DTC Index"](#). (BCM)
- NO-2 >> Refer to [MWI-65, "DTC Index"](#). (Combination meter)

2. CHECK "HAZARD ANSWER BACK" SETTING IN "WORK SUPPORT"

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "HAZARD ANSWER BACK" in "Work support".
3. Check the "HAZARD ANSWER BACK" in "Work support".
Refer to [BCS-20, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)"](#).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Set "HAZARD ANSWER BACK" in "Work support".

3. CHECK "ANS BACK I-KEY LOCK" SETTING IN "WORK SUPPORT"

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "ANS BACK I-KEY LOCK" in "Work support".
3. Check the "ANS BACK I-KEY LOCK" in "Work support".
Refer to [BCS-20, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)"](#).

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Set "ANS BACK I-KEY LOCK" in "Work support".

4. CHECK "ANS BACK I-KEY UNLOCK" SETTING IN "WORK SUPPORT"

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "ANS BACK I-KEY UNLOCK" in "Work support".
3. Check the "ANS BACK I-KEY UNLOCK" in "Work support".
Refer to [BCS-20, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)"](#).

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Set "ANS BACK I-KEY UNLOCK" in "Work support".

5. CHECK HAZARD FUNCTION

Check hazard function.

Refer to [DLK-106, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 6.
- NO >> Repair or replace the malfunctioning parts.

6. CHECK INTELLIGENT KEY WARNING BUZZER

Check Intelligent Key warning buzzer.

Refer to [DLK-108, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 7.
- NO >> Repair or replace the malfunctioning parts.

7. REPLACE BCM

1. Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).
2. Confirm the operation after replacement.

Is the result normal?

- YES >> Inspection End.

HAZARD AND BUZZER REMINDER DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

NO >> Check intermittent incident. Refer to [GI-53. "Intermittent Incident"](#).

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

KEY REMINDER FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

KEY REMINDER FUNCTION DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000010639819

1. CHECK DTC WITH BCM

Check that DTC is not detected with BCM.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refer to [BCS-48, "DTC Index"](#).

2. CHECK "ANTI KEY LOCK IN FUNCTI" SETTING IN "WORK SUPPORT"

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.

2. Select "ANTI KEY LOCK IN FUNCTI" in "Work support".

3. Check "ANTI KEY LOCK IN FUNCTI" in "Work support".

Refer to [BCS-20, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Set "ANTI KEY LOCK IN FUNCTI" in "Work support".

3. CHECK DOOR SWITCH

Check door switch.

Refer to [DLK-103, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. CHECK INSIDE KEY ANTENNA

Check inside key antenna.

• Instrument center: Refer to [DLK-69, "DTC Logic"](#).

• Rear seat: Refer to [DLK-71, "DTC Logic"](#).

• Luggage room: Refer to [DLK-73, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5. CHECK UNLOCK SENSOR

Check unlock sensor.

Refer to [DLK-113, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the malfunctioning parts.

6. REPLACE BCM

1. Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

OFF POSITION WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

OFF POSITION WARNING DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000010639820

1. CHECK DTC WITH BCM AND COMBINATION METER

Check that DTC is not detected with BCM and combination meter.

Is the inspection result normal?

YES >> GO TO 2.

NO-1 >> Refer to [BCS-48, "DTC Index"](#). (BCM)

NO-2 >> Refer to [MWI-65, "DTC Index"](#). (Combination meter)

2. CHECK COMBINATION METER BUZZER

Check combination meter buzzer.

Refer to [DLK-87, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK INTELLIGENT KEY WARNING BUZZER

Check Intelligent Key warning buzzer.

Refer to [DLK-108, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. CHECK DOOR SWITCH

Check front door switch (LH).

Refer to [DLK-103, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5. REPLACE BCM

1. Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

TAKE AWAY WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

TAKE AWAY WARNING DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000010639821

1. CHECK DTC WITH BCM AND COMBINATION METER

Check that DTC is not detected with BCM and combination meter.

Is the inspection result normal?

- YES >> GO TO 2.
- NO-1 >> Refer to [BCS-48, "DTC Index"](#). (BCM)
- NO-2 >> Refer to [MWI-65, "DTC Index"](#). (Combination meter)

2. CHECK COMBINATION METER BUZZER

Check combination meter buzzer.

Refer to [DLK-108, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace the malfunctioning parts.

3. CHECK INFORMATION DISPLAY

Check information display.

Refer to [DLK-115, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair or replace the malfunctioning parts.

4. CHECK INTELLIGENT KEY WARNING BUZZER

Check Intelligent Key warning buzzer.

Refer to [DLK-108, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Repair or replace the malfunctioning parts.

5. CHECK DOOR SWITCH

Check door switch.

Refer to [DLK-103, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 6.
- NO >> Repair or replace the malfunctioning parts.

6. CHECK INSIDE KEY ANTENNA

Check inside key antenna.

- Instrument center: Refer to [DLK-69, "DTC Logic"](#).
- Rear seat: Refer to [DLK-71, "DTC Logic"](#).
- Luggage room: Refer to [DLK-73, "DTC Logic"](#).

Is the inspection result normal?

- YES >> GO TO 7.
- NO >> Repair or replace the malfunctioning parts.

7. REPLACE BCM

1. Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

- YES >> Inspection End.
- NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

INTELLIGENT KEY LOW BATTERY WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

INTELLIGENT KEY LOW BATTERY WARNING DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000010639822

1. CHECK DTC WITH BCM AND COMBINATION METER

Check that DTC is not detected with BCM and combination meter.

Is the inspection result normal?

YES >> GO TO 2.

NO-1 >> Refer to [BCS-48, "DTC Index"](#). (BCM)

NO-2 >> Refer to [MWI-65, "DTC Index"](#). (Combination meter)

2. CHECK "LO- BATT OF KEY FOB WARN" SETTING IN "WORK SUPPORT"

1. Select "INTELLIGENT KEY" of "BCM".

2. Select "LO- BATT OF KEY FOB WARN" in "Work support".

3. Check "LO- BATT OF KEY FOB WARN" in "Work support".

Refer to [BCS-20, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Set "LO- BATT OF KEY FOB WARN" in "Work support".

3. CHECK INTELLIGENT KEY

Check Intelligent Key.

Refer to [DLK-107, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. CHECK INFORMATION DISPLAY

Check information display.

Refer to [DLK-115, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5. CHECK INSIDE KEY ANTENNA

Check inside key antenna.

• Instrument center: Refer to [DLK-69, "DTC Logic"](#).

• Rear seat: Refer to [DLK-71, "DTC Logic"](#).

• Luggage room: Refer to [DLK-73, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the malfunctioning parts.

6. REPLACE BCM

1. Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

DOOR LOCK OPERATION WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

DOOR LOCK OPERATION WARNING DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000010639823

1. CHECK DOOR LOCK FUNCTION

Check door lock function.

Does door lock/unlock using door request switch?

YES >> GO TO 2.

NO >> Refer to [DLK-101, "Component Function Check"](#).

2. CHECK INTELLIGENT KEY WARNING BUZZER

Check Intelligent Key warning buzzer.

Refer to [DLK-108, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. REPLACE BCM

1. Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

KEY ID WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

KEY ID WARNING DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000010639824

1. CHECK DTC WITH BCM AND COMBINATION METER

Check that DTC is not detected with BCM and combination meter.

Is the inspection result normal?

YES >> GO TO 2.

NO-1 >> Refer to [BCS-48, "DTC Index"](#). (BCM)

NO-2 >> Refer to [MWI-65, "DTC Index"](#). (Combination meter)

2. CHECK INTELLIGENT KEY

Check Intelligent Key.

Refer to [DLK-107, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK INFORMATION DISPLAY

Check information display.

Refer to [DLK-115, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. CHECK INSIDE KEY ANTENNA

Check inside key antenna.

• Instrument center: Refer to [DLK-69, "DTC Logic"](#).

• Rear seat: Refer to [DLK-71, "DTC Logic"](#).

• Luggage room: Refer to [DLK-73, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5. REPLACE BCM

1. Replace BCM. Refer to [BCS-72, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

HOMELINK UNIVERSAL TRANSCEIVER DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

HOMELINK UNIVERSAL TRANSCEIVER DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000010639825

1. CHECK HOMELINK® UNIVERSAL TRANSCEIVER

Check HomeLink® Universal Transceiver.

Refer to [DLK-123, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. REPLACE AUTO ANTI-DAZZLING INSIDE MIRROR

Replace auto anti-dazzling inside mirror.

Refer to [MIR-20, "Removal and Installation"](#).

Is the result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-53, "Intermittent Incident"](#).


SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

SQUEAK AND RATTLE TROUBLE DIAGNOSES

Work Flow

INFOID:0000000110639826



SBT842

CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any customer's comments; refer to [DLK-153, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, be sure to diagnose and repair the noise that the customer is concerned about. This can be accomplished by test driving the vehicle with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak —(Like tennis shoes on a clean floor)
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces = higher pitch noise/softer surfaces = lower pitch noises/edge to surface = chirping.
- Creak—(Like walking on an old wooden floor)
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle—(Like shaking a baby rattle)
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock —(Like a knock on a door)
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick—(Like a clock second hand)
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump—(Heavy, muffled knock noise)
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz—(Like a bumble bee)
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending upon the person. A noise that you may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

DUPLICATE THE NOISE AND TEST DRIVE

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when you confirm the repair.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
 - 2) Tap or push/pull around the area where the noise appears to be coming from.
 - 3) Rev the engine.
 - 4) Use a floor jack to recreate vehicle "twist".
 - 5) At idle, apply engine load (electrical load, half-clutch on M/T model, drive position on CVT and A/T models).
 - 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.
- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
 - If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

CHECK RELATED SERVICE BULLETINS

After verifying the customer concern or symptom, check ASIST for Technical Service Bulletins (TSBs) related to that concern or symptom.

If a TSB relates to the symptom, follow the procedure to repair the noise.

LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Chassis Ear: J-39570, Engine Ear: J-39565 and mechanic's stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
 - removing the components in the area that you suspect the noise is coming from.
Do not use too much force when removing clips and fasteners, otherwise clips and fasteners can be broken or lost during the repair, resulting in the creation of new noise.
 - tapping or pushing/pulling the component that you suspect is causing the noise.
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
 - feeling for a vibration with your hand by touching the component(s) that you suspect is (are) causing the noise.
 - placing a piece of paper between components that you suspect are causing the noise.
 - looking for loose components and contact marks.Refer to [DLK-150. "Generic Squeak and Rattle Troubleshooting"](#).

REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
 - separate components by repositioning or loosening and retightening the component, if possible.
 - insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. A NISSAN Squeak and Rattle Kit (J-50397) is available through your authorized NISSAN Parts Department.

CAUTION:

Do not use excessive force as many components are constructed of plastic and may be damaged.

NOTE:

- Always check with the Parts Department for the latest parts information.
- The materials contained in the NISSAN Squeak and Rattle Kit (J-50397) are listed on the inside cover of the kit; and can each be ordered separately as needed.
- The following materials not found in the kit can also be used to repair squeaks and rattles.
 - SILICONE GREASE: Use instead of UHMW tape that will be visible or does not fit. The silicone grease will only last a few months.
 - SILICONE SPRAY: Use when grease cannot be applied.
 - DUCT TAPE: Use to eliminate movement.

CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

Generic Squeak and Rattle Troubleshooting

INFOID:000000010639827

Refer to Table of Contents for specific component removal and installation information.

INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

1. Cluster lid A and the instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar finisher
4. Instrument panel to windshield
5. Instrument panel pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicone spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

CAUTION:

Do not use silicone spray to isolate a squeak or rattle. If you saturate the area with silicone, you will not be able to recheck the repair.

CENTER CONSOLE

Components to pay attention to include:

1. Shift selector assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

DOORS

Pay attention to the:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. You can usually insulate the areas with felt cloth tape or insulator foam blocks from the NISSAN Squeak and Rattle Kit (J-50397) to repair the noise.

TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the owner.

In addition look for:

1. Trunk lid bumpers out of adjustment
2. Trunk lid striker out of adjustment
3. The trunk lid torsion bars knocking together
4. A loose license plate or bracket

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

SUNROOF/HEADLINING

Noises in the sunroof/headlining area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sun visor shaft shaking in the holder
3. Front or rear windshield touching headlining and squeaking

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

OVERHEAD CONSOLE (FRONT AND REAR)

Overhead console noises are often caused by the console panel clips not being engaged correctly. Most of these incidents are repaired by pushing up on the console at the clip locations until the clips engage.

In addition look for:

1. Loose harness or harness connectors.
2. Front console map/reading lamp lens loose.

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

3. Loose screws at console attachment points.

SEATS

When isolating seat noise it's important to note the position the seat is in and the load placed on the seat when the noise is present. These conditions should be duplicated when verifying and isolating the cause of the noise.

Cause of seat noise include:

1. Headrest rods and holder
2. A squeak between the seat pad cushion and frame
3. The rear seatback lock and bracket

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

Causes of transmitted underhood noise include:

1. Any component installed to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator installation pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

These noises can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine rpm or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting, securing, or insulating the component causing the noise.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

Diagnostic Worksheet

INFOID:0000000110639828




Dear Customer:

We are concerned about your satisfaction with your vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your vehicle right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service advisor or technician to ensure we confirm the noise you are hearing.

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to page 2 of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET - page 2

Briefly describe the location where the noise occurs:

II. WHEN DOES IT OCCUR? (please check the boxes that apply)

- | | |
|---|--|
| <input type="checkbox"/> Anytime | <input type="checkbox"/> After sitting out in the rain |
| <input type="checkbox"/> 1st time in the morning | <input type="checkbox"/> When it is raining or wet |
| <input type="checkbox"/> Only when it is cold outside | <input type="checkbox"/> Dry or dusty conditions |
| <input type="checkbox"/> Only when it is hot outside | <input type="checkbox"/> Other: |

III. WHEN DRIVING:

- Through driveways
- Over rough roads
- Over speed bumps
- Only about ____ mph
- On acceleration
- Coming to a stop
- On turns: left, right or either (circle)
- With passengers or cargo
- Other: _____
- After driving ____ miles or ____ minutes

IV. WHAT TYPE OF NOISE

- Squeak (like tennis shoes on a clean floor)
- Creak (like walking on an old wooden floor)
- Rattle (like shaking a baby rattle)
- Knock (like a knock at the door)
- Tick (like a clock second hand)
- Thump (heavy muffled knock noise)
- Buzz (like a bumble bee)

TO BE COMPLETED BY DEALERSHIP PERSONNEL

Test Drive Notes:

	YES	NO	Initials of person performing
Vehicle test driven with customer	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise verified on test drive	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise source located and repaired	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Follow up test drive performed to confirm repair	<input type="checkbox"/>	<input type="checkbox"/>	_____

VIN: _____ Customer Name _____

W.O.# _____ Date: _____

This form must be attached to Work Order

LAI0071E

HOOD


< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION

HOOD

Exploded View

INFOID:0000000010639829



- | | | |
|------------------------|--------------------|------------------------------------|
| 1. Hood cover (LH) | 2. Hood cover (RH) | 3. Hood assembly |
| 4. Hood insulator | 5. Grommet | 6. Hood support rod |
| 7. Hood front seal | 8. Clamp | 9. Hood lock secondary control |
| 10. Hood bumper rubber | 11. Hood hinge | ○ Pawl |
| △ Clip | Grease | Sealing point with locking sealant |

HOOD ASSEMBLY

HOOD ASSEMBLY : Removal and Installation

INFOID:0000000010639830

CAUTION:

- Operate with two workers, because of its heavy weight.
- Use protective tape or shop cloths to protect surrounding components from damage during removal and installation.

REMOVAL

1. Support the hood assembly using a suitable tool.

WARNING:

Bodily injury may occur if hood assembly is not supported properly when removing hood assembly.

2. Remove hood hinge nuts and hood assembly.

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

HOOD

< REMOVAL AND INSTALLATION >

INSTALLATION


Installation is in the reverse order of removal.

CAUTION:

- After installation, apply touch-up paint (body color) to the heads of the hood hinge nuts.
- After installation, perform hood assembly adjustment procedure. Refer to [DLK-156, "HOOD ASSEMBLY : Adjustment"](#).

HOOD ASSEMBLY : Adjustment

INFOID:000000010639831



1. Hood assembly
4. Hood lock assembly

2. Hood bumper rubber
5. Charge port lid

3. Hood hinge
6. Front bumper fascia

HOOD

< REMOVAL AND INSTALLATION >

7. Front combination lamp 8. Front side maker lamp 9. Front fender

 Grease

Check the clearance and surface height between the hood and each part by visual inspection and tactile feel. If the clearance and surface height are out of specification, adjust them according to the procedures shown below.

Unit: mm (in)

Portion	Section	Item	Measurement	Standard	Parallelism	Equality
Hood – Charge port lid	A – A	G	Clearance	5.0 ± 2.7 (0.20 ± 0.11)	1.9 (0.07)	2.0 (0.08)
		H	Surface height	1.0 ± 2.0 (0.04 ± 0.08)	1.9 (0.07)	2.0 (0.08)
Hood – Charge port lid	B – B	J	Clearance	5.0 ± 2.7 (0.20 ± 0.11)	—	2.9 (0.11)
Hood – Front bumper fascia	C – C	K	Clearance	5.0 ± 2.7 (0.20 ± 0.11)	2.0 (0.08)	2.0 (0.08)
		M	Surface height	1.0 ± 2.0 (0.04 ± 0.08)	—	1.0 (0.04)
Hood – Front combination lamp	D – D	N	Clearance	4.0 ± 2.5 (0.16 ± 0.10)	1.9 (0.07)	2.9 (0.11)
Hood – Front side marker lamp	E – E	O	Clearance	4.0 ± 2.5 (0.16 ± 0.10)	1.9 (0.07)	2.9 (0.11)
Hood – Front fender	F – F	P	Clearance	3.5 ± 1.0 (0.14 ± 0.04)	1.0 (0.04)	1.5 (0.06)

FITTING ADJUSTMENT

- Remove the radiator upper grille. Refer to [DLK-166, "RADIATOR UPPER GRILLE : Removal and Installation"](#).
- Remove the hood lock assembly. Refer to [DLK-188, "HOOD LOCK : Removal and Installation"](#).
- Adjust the surface height of hood assembly, charge port lid assembly and front bumper fascia according to the specified value, by rotating the hood bumper rubber.
- Position the hood lock assembly and engage hood striker. Check hood lock assembly and hood striker for looseness.
- Move hood lock assembly laterally until the center of hood striker and hood lock assembly are vertical when viewed from the front.
- After adjustment, tighten hood lock bolts to specified torque.
- Open hood and rotate hood bumper rubber counterclockwise between half a turn and three-quarters of a turn.
- Check that secondary latch is securely engaged with secondary striker (charge port bracket) from the dead load of the hood assembly.
- Check the the primary latch is securely engaged with primary striker when hood assembly is closed free-fall from approximately 200 mm (7.874 in) height.
- Install the radiator upper grille. Refer to [DLK-166, "RADIATOR UPPER GRILLE : Removal and Installation"](#).

HOOD HINGE

HOOD HINGE : Removal and Installation

INFOID:000000010639832

REMOVAL

- Remove hood assembly. Refer to [DLK-155, "HOOD ASSEMBLY : Removal and Installation"](#).
- Remove front fender. Refer to [DLK-169, "Removal and Installation"](#).
- Remove hood hinge bolts, and then remove hood hinge.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:


- After installation, perform hood assembly adjustment procedure. Refer to [DLK-156, "HOOD ASSEMBLY : Adjustment"](#).
- After installation, apply touch-up paint (body color) to the head of the hood hinge bolts and nuts.

HOOD

< REMOVAL AND INSTALLATION >

- Check hood hinge rotating part for poor lubrication. If necessary, apply a suitable multi-purpose grease.

← : Grease point



HOOD SUPPORT ROD

HOOD SUPPORT ROD : Removal and Installation

INFOID:0000000010639833

REMOVAL

1. Support the hood assembly using a suitable tool.

WARNING:

Bodily injury may occur if hood assembly is not properly supported when removing hood assembly.

2. Pull hood support rod from grommet and remove.

INSTALLATION

Installation is in the reverse order of removal.


HOOD COVER

HOOD COVER : Removal and Installation

INFOID:0000000010639834


REMOVAL

1. Remove hood cover nuts.
2. Apply protective tape (A) on the hood assembly to protect the painted surface from damage.



3. Release the hood cover clips using a suitable tool (A) and remove.

△: Clip



INSTALLATION

Installation is in the reverse order of removal.


CHARGE PORT LID

< REMOVAL AND INSTALLATION >

CHARGE PORT LID

Exploded View

INFOID:0000000110639835



- | | | |
|-----------------------------------|--------------------------------------|-----------------------------|
| 1. Charge port lid cover assembly | 2. Charge port lid seal | 3. Charge port lid assembly |
| 4. Charge port lid lock cable | 5. Charge port lid actuator assembly | 6. Charge port lid |
| 7. Charge port lid lock | 8. Charge port lid rear cover | △ Clip |

CHARGE PORT LID ASSEMBLY

CHARGE PORT LID ASSEMBLY : Removal and Installation

INFOID:0000000110639836

REMOVAL

1. Remove the charge port lid nuts and charge port lid.
2. Remove the front camera, if necessary. Refer to [AV-503. "Removal and Installation"](#).

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:


After installation, perform charge port lid assembly fitting adjustment. Refer to [DLK-160. "CHARGE PORT LID ASSEMBLY : Adjustment"](#).

CHARGE PORT LID

< REMOVAL AND INSTALLATION >

CHARGE PORT LID ASSEMBLY : Adjustment

INFOID:000000010639837



- 1. Hood assembly
- 2. Charge port lid assembly
- 3. Front bumper fascia
- 4. Charge port lid lock

Check the clearance and the surface height between charge port lid and each part by visual inspection and tactile feel. If the clearance and the surface height are out of specification, adjust them according to the adjustment procedure.

Unit: mm (in)

Portion	Section	Item	Measurement	Standard	Parallelism
Charge port lid – Hood	A – A	E	Clearance	5.0 ± 2.7 (0.20 ± 0.11)	1.9 (0.07)
		F	Surface height	1.0 ± 2.0 (0.04 ± 0.08)	1.9 (0.07)
Charge port lid – Hood	B – B	G	Clearance	5.0 ± 2.7 (0.20 ± 0.11)	2.9 (0.11)
Charge port lid – Front bumper fascia	C – C	H	Clearance	2.6 ± 1.2 (0.10 ± 0.05)	1.9 (0.07)
		J	Surface height	1.5 ± 1.5 (0.06 ± 0.06)	1.9 (0.07)
Charge port lid – Front bumper fascia	D – D	K	Clearance	3.3 ± 1.2 (0.13 ± 0.05)	1.9 (0.07)
		M	Surface height	3.5 ± 1.5 (0.14 ± 0.06)	1.9 (0.07)

FITTING ADJUSTMENT PROCEDURE

1. Remove charge port cover. Refer to [DLK-161, "CHARGE PORT COVER : Removal and Installation"](#).

CHARGE PORT LID

< REMOVAL AND INSTALLATION >

2. Remove charge port lid lock.
3. Loosen charge port lid assembly nuts.
4. Adjust the clearance of charge port lid assembly, hood assembly and front bumper fascia according to the specified value, by moving charge port lid assembly.
5. Tighten charge port lid.
6. Temporarily tighten charge port lid lock.
7. Adjust the surface height of charge port lid assembly, hood assembly and front bumper fascia according to the specified value, by moving charge port lid lock.
8. After adjustment, tighten charge port lid lock bolts.
9. Install charge port cover. Refer to [DLK-161, "CHARGE PORT COVER : Removal and Installation"](#).

CHARGE PORT LID HINGE ASSEMBLY

CHARGE PORT LID HINGE ASSEMBLY : Removal and Installation

INFOID:000000010639838

REMOVAL

1. Remove front bumper fascia. Refer to [EXT-13, "Removal and Installation"](#).
2. Remove charge port lid lock assembly. Refer to [DLK-191, "CHARGE PORT LID LOCK : Removal and Installation"](#).
3. Release the charge port rear cover clips using a suitable tool and remove.
4. Remove charge port lid hinge bolts and charge port lid hinge assembly.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

After installation, perform charge port lid assembly fitting adjustment. Refer to [DLK-160, "CHARGE PORT LID ASSEMBLY : Adjustment"](#).

CHARGE PORT COVER

CHARGE PORT COVER : Removal and Installation

INFOID:000000010639839

REMOVAL

1. Remove the charge port lid. Refer to [DLK-159, "CHARGE PORT LID ASSEMBLY : Removal and Installation"](#).
2. Remove the radiator upper grille. Refer to [DLK-166, "RADIATOR UPPER GRILLE : Removal and Installation"](#).
3. Release the charge port cover clips using a suitable tool and remove.
4. Release the charge port lid seal clips using a suitable tool and remove from charge port cover, if necessary.

INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P


RADIATOR CORE SUPPORT

< REMOVAL AND INSTALLATION >

RADIATOR CORE SUPPORT

Exploded View

INFOID:000000010639840



- | | | |
|-------------------------------------|--------------------------------|------------------------|
| 1. Radiator upper grille | 2. Radiator core support upper | 3. Charge port bracket |
| 4. Radiator core support lower stay | 5. Radiator core support lower | 6. Air guide (RH) |
| 7. Air guide (LH) | | |


●, ▲, ■: Indicates that the part is connected at points with same symbol in actual vehicle.

RADIATOR CORE SUPPORT UPPER

RADIATOR CORE SUPPORT UPPER : Removal and Installation

INFOID:000000010639841

DANGER:

 Since hybrid vehicles and electric vehicles contain a high voltage battery, there is the risk of electric shock, electric leakage, or similar accidents if the high voltage component and vehicle are handled incorrectly. Be sure to follow the correct work procedures when performing inspection and maintenance.

WARNING:

- Be sure to remove the service plug in order to disconnect the high voltage circuits before performing inspection or maintenance of high voltage system harnesses and parts.

RADIATOR CORE SUPPORT

< REMOVAL AND INSTALLATION >

- The removed service plug must always be carried in a pocket of the responsible worker or placed in the tool box during the procedure to prevent the plug from being connected by mistake.
- Be sure to wear insulating protective equipment consisting of glove, shoes, face shield and glasses before beginning work on the high voltage system.
- Never allow workers other than the responsible person to touch the vehicle containing high voltage parts. To keep others from touching the high voltage parts, these parts must be covered with an insulating sheet except when using them.
- Refer to [GI-34, "High Voltage Precautions"](#).

CAUTION:

Never bring the vehicle into the READY status with the service plug removed unless otherwise instructed in the Service Manual. A malfunction may occur if this is not observed.

REMOVAL

WARNING:

Disconnect the high voltage. Refer to [GI-33, "How to Disconnect High Voltage"](#).

1. Check voltage in high voltage circuit. (Check that condenser are discharged.)
 - a. Lift up the vehicle and remove the Li-ion battery under covers. Refer to [EVB-181, "Exploded View"](#).
 - b. Disconnect high voltage connector from front side of Li-ion battery. Refer to [EVB-181, "Removal and Installation"](#).
 - c. Measure voltage between high voltage harness terminals.

DANGER:




Always use protective equipment as touching high voltage components without using them will cause electrocution. (where high voltage might remain/is present on terminals.)



Standard


: 5 V or less



CAUTION:

For voltage measurements, use a tester which can measure to 500V or higher.


2. Remove front bumper fascia, energy absorber and apron bracket. Refer to [EXT-13, "Removal and Installation"](#).
3. Remove hood lock assembly. Refer to [DLK-188, "HOOD LOCK : Removal and Installation"](#).
4. Remove air guide (RH) clips (A) and washer tank inlet clip (B).




RADIATOR CORE SUPPORT

< REMOVAL AND INSTALLATION >

5. Remove reservoir tank bolts (A), air guide (LH) clip (B) and degas tank bolt (C).



6. Remove harness fixing clips (A).



7. Disconnect quick charge port connector. Refer to [VC-128, "Removal and Installation"](#).
8. Disconnect normal charge port connector. Refer to [VC-135, "Removal and Installation"](#).
9. Remove upper mounting bolts of charge port bracket.
10. Remove lower mounting nuts and bolt of radiator core support lower stay.
11. Move charge port bracket and radiator core support lower stay.
12. Support hood assembly using a suitable tool.

WARNING:

Injury may occur if hood assembly is not supported with appropriate material when removing hood assembly.

13. Remove radiator core support upper bolts and radiator core support upper.

INSTALLATION


Installation is in the reverse order of removal.

RADIATOR CORE SUPPORT LOWER

RADIATOR CORE SUPPORT LOWER : Removal and Installation

INFOID:000000010639842

DANGER:

 Since hybrid vehicles and electric vehicles contain a high voltage battery, there is the risk of electric shock, electric leakage, or similar accidents if the high voltage component and vehicle are handled incorrectly. Be sure to follow the correct work procedures when performing inspection and maintenance.

WARNING:

- Be sure to remove the service plug in order to disconnect the high voltage circuits before performing inspection or maintenance of high voltage system harnesses and parts.
- The removed service plug must always be carried in a pocket of the responsible worker or placed in the tool box during the procedure to prevent the plug from being connected by mistake.

RADIATOR CORE SUPPORT

< REMOVAL AND INSTALLATION >

- Be sure to wear insulating protective equipment consisting of glove, shoes, face shield and glasses before beginning work on the high voltage system.
- Never allow workers other than the responsible person to touch the vehicle containing high voltage parts. To keep others from touching the high voltage parts, these parts must be covered with an insulating sheet except when using them.
- Refer to [GI-34, "High Voltage Precautions"](#).

CAUTION:

Never bring the vehicle into the READY status with the service plug removed unless otherwise instructed in the Service Manual. A malfunction may occur if this is not observed.

REMOVAL

WARNING:

Disconnect the high voltage. Refer to [GI-33, "How to Disconnect High Voltage"](#).

1. Check voltage in high voltage circuit. (Check that condenser are discharged.)
 - a. Lift up the vehicle and remove the Li-ion battery under covers. refer to [EVB-181, "Exploded View"](#).
 - b. Disconnect high voltage connector from front side of Li-ion battery. Refer to [EVB-181, "Removal and Installation"](#).
 - c. Measure voltage between high voltage harness terminals.

DANGER:



Always use protective equipment as touching high voltage components without using them will cause electrocution. (where high voltage might remain/is present on terminals.)





Standard

: 5 V or less

CAUTION:

For voltage measurements, use a tester which can measure to 500V or higher.


2. Remove front bumper fascia, energy absorber, and apron bracket. Refer to [EXT-13, "Removal and Installation"](#).
3. Remove reservoir tank bolts (A).



RADIATOR CORE SUPPORT

< REMOVAL AND INSTALLATION >


4. Remove harness fixing clips (A).



5. Disconnect quick charge port connector. Refer to [VC-128, "Removal and Installation"](#).
6. Disconnect normal charge port connector. Refer to [VC-135, "Removal and Installation"](#).
7. Remove lower mounting bolts of hood lock assembly.
8. Remove upper mounting bolts of charge port bracket.
9. Remove lower mounting nuts and bolt of radiator core support lower stay.
10. Move charge port bracket and radiator core support lower stay.
11. Remove air guides (LH/RH).
12. Use belts (A) to suspend radiator and condenser to prevent them from falling.

CAUTION:

Do not damage radiator and condenser.



13. Remove front fixing clip of fender protector (LH/RH) from radiator core support lower.
14. Remove radiator core support lower bolts and radiator core support lower.

INSTALLATION

Installation is in the reverse order of removal.

RADIATOR UPPER GRILLE

RADIATOR UPPER GRILLE : Removal and Installation

INFOID:000000010639843

REMOVAL

Remove radiator upper grille clips and radiator upper grille.

INSTALLATION


Installation in the reverse order of removal.

CHARGE PORT BRACKET

CHARGE PORT BRACKET : Removal and Installation

INFOID:000000010639844

DANGER:

 Since hybrid vehicles and electric vehicles contain a high voltage battery, there is the risk of electric shock, electric leakage, or similar accidents if the high voltage component and vehicle are

RADIATOR CORE SUPPORT

< REMOVAL AND INSTALLATION >

handled incorrectly. Be sure to follow the correct work procedures when performing inspection and maintenance.

WARNING:

- Be sure to remove the service plug in order to disconnect the high voltage circuits before performing inspection or maintenance of high voltage system harnesses and parts.
- The removed service plug must always be carried in a pocket of the responsible worker or placed in the tool box during the procedure to prevent the plug from being connected by mistake.
- Be sure to wear insulating protective equipment consisting of glove, shoes, face shield and glasses before beginning work on the high voltage system.
- Never allow workers other than the responsible person to touch the vehicle containing high voltage parts. To keep others from touching the high voltage parts, these parts must be covered with an insulating sheet except when using them.
- Refer to [GI-34, "High Voltage Precautions"](#).

CAUTION:

Never bring the vehicle into the READY status with the service plug removed unless otherwise instructed in the Service Manual. A malfunction may occur if this is not observed.

REMOVAL

WARNING:

Disconnect the high voltage. Refer to [GI-33, "How to Disconnect High Voltage"](#).

1. Check voltage in high voltage circuit. (Check that condenser are discharged.)
 - a. Lift up the vehicle and remove the Li-ion battery under covers. refer to [EVB-181, "Exploded View"](#).
 - b. Disconnect high voltage connector from front side of Li-ion battery. Refer to [EVB-181, "Removal and Installation"](#).
 - c. Measure voltage between high voltage harness terminals.

DANGER:




Always use protective equipment as touching high voltage components without using them will cause electrocution. (where high voltage might remain/is present on terminals.)



Standard


: 5 V or less



CAUTION:

For voltage measurements, use a tester which can measure to 500V or higher.

2. Remove charge port hinge assembly. Refer to [DLK-161, "CHARGE PORT LID HINGE ASSEMBLY : Removal and Installation"](#).
3. Remove quick charge port. Refer to [VC-128, "Removal and Installation"](#).
4. Remove normal charge port. Refer to [VC-135, "Removal and Installation"](#).
5. Remove crash zone sensor. Refer to [SR-33, "Removal and Installation"](#).
6. Remove harness fixing clips (A).



7. Remove charge port bracket bolts and nuts and charge port bracket.

RADIATOR CORE SUPPORT

< REMOVAL AND INSTALLATION >

INSTALLATION

Installation is in the reverse order of removal.


FRONT FENDER

< REMOVAL AND INSTALLATION >

FRONT FENDER

Exploded View

INFOID:0000000110639845



- | | | |
|---------------------------------|--------------------------|----------------------|
| 1. Rivet | 2. Front fender cover | 3. Front fender seal |
| 4. Front fender upper insulator | 5. Front fender assembly | 6. Front fender seal |
| 7. Front fender stiffener | ○● Pawl | ← Front |

Removal and Installation


INFOID:0000000110639846

CAUTION:

Use shop cloths to protect the body from damage during removal and installation.

REMOVAL

1. Remove fender protector. Refer to [EXT-21, "FENDER PROTECTOR : Removal and Installation"](#).
 2. Remove front fender cover. Refer to [DLK-169, "Exploded View"](#).
 3. Remove front combination lamp. Refer to [EXL-132, "Removal and Installation"](#).
 4. Remove the front fender bolts.
 5. Apply protective tape (A) on the body side outer panel to protect the painted surface from damage.
- ←: Front




FRONT FENDER

< REMOVAL AND INSTALLATION >

- Using a suitable tool (A), remove front fender stiffener (2) from the vehicle body while carefully pulling the portion of front fender (1) toward vehicle outside.

↔: Front



- Remove the front fender assembly.

CAUTION:

Use care when removing the front fender. The front fender baffle foam adheres the front fender to the body side outer. Carefully release the baffle foam or damage to the front fender may occur.

INSTALLATION

Note the following items, and install in the reverse order of removal.

CAUTION:

- After installation, apply touch-up paint (body color) to the head of front fender bolts.
- After installation, adjust the following parts:
 - Hood assembly: Refer to [DLK-156, "HOOD ASSEMBLY : Adjustment"](#).
 - Front door: Refer to [DLK-173, "DOOR ASSEMBLY : Adjustment"](#).


FRONT DOOR

< REMOVAL AND INSTALLATION >

FRONT DOOR

Exploded View

INFOID:000000010639847



- | | | |
|-----------------------|-----------------------|--------------------|
| 1. Front door panel | 2. Grommet | 3. Bolt |
| 4. Door striker | 5. Bumper rubber | 6. Door check link |
| 7. Door hinge (lower) | 8. Door hinge (upper) | ⊗ Do not reuse |

 Grease

DOOR ASSEMBLY

DOOR ASSEMBLY : Removal and Installation

INFOID:000000010639848

WARNING:

Before servicing, push power switch OFF, disconnect 12V battery negative terminal and wait five minutes or more. Refer to [DLK-10, "Precaution for Removing 12V Battery"](#).

CAUTION:

- Use two people when removing or installing the front door due to its heavy weight.
- When removing and installing front door assembly, support front door with a suitable tool.


REMOVAL

1. Disconnect the negative battery terminal and wait at least five minutes. Refer to [PG-82, "Removal and Installation"](#).

FRONT DOOR

< REMOVAL AND INSTALLATION >

2. Disconnect the front door harness connector.



3. Remove door check link bolt (body side).
4. Remove door hinge nuts (door side) and front door assembly.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:


- Apply anticorrosive agent to the mounting surface of the front door.
- After installation, check the front door open/close and lock/unlock operation.
- After installation, perform the front door adjustment procedure. Refer to [DLK-173, "DOOR ASSEMBLY : Adjustment"](#).
- After installation, apply touch-up paint (body color) to the head of the door hinge nuts.

FRONT DOOR

< REMOVAL AND INSTALLATION >

DOOR ASSEMBLY : Adjustment

INFOID:0000000110639849



- | | | |
|---------------------|----------------------------|----------------------------|
| 1. Front fender | 2. Front door | 3. Rear door |
| 4. Body side outer | 5. Door striker | 6. Bolt |
| 7. Front door hinge | 8. Rear door hinge (upper) | 9. Rear door hinge (lower) |
- Do not reuse
 Grease

Check the clearance and surface height between front door and each part by visual inspection and tactile feel. If the clearance and the surface height are out of specification, adjust them according to the adjustment procedure.

Unit: mm (in)

Portion	Section	Measurement	Standard
Front fender – Front door	A – A	Clearance	4.0 ± 1.0 (0.16 ± 0.04)
		Surface height	0.0 ± 1.0 (0.00 ± 0.04)
Front door – Rear door	B – B	Clearance	4.2 ± 1.0 (0.17 ± 0.04)
		Surface height	0.0 ± 1.0 (0.00 ± 0.04)
Front door – Rear door	C – C	Clearance	4.0 ± 1.0 (0.16 ± 0.04)
		Surface height	0.0 ± 1.0 (0.00 ± 0.04)

FITTING ADJUSTMENT PROCEDURE

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK

FRONT DOOR

< REMOVAL AND INSTALLATION >

1. Remove front fender. Refer to [DLK-169, "Removal and Installation"](#).
2. Loosen door hinge nuts (door side).
3. Adjust the surface height of front door according to the specifications provided.
4. Temporarily tighten door hinge nuts (door side).
5. Loosen door hinge bolts (body side).
6. Raise front door at rear end to adjust clearance of the front door according to the specifications provided.
7. Tighten bolts and nuts to the specified torque.

CAUTION:

- After installation, apply touch-up paint (body color) to the head of door hinge bolts and nuts.
- Check door hinge rotating part for poor lubrication. If necessary, apply a suitable multi-purpose grease.

8. Install front fender. Refer to refer to [DLK-169, "Removal and Installation"](#).

DOOR STRIKER ADJUSTMENT

Adjust door striker so that it becomes parallel with door lock insertion direction.

DOOR STRIKER

DOOR STRIKER : Removal and Installation

INFOID:000000010639850

REMOVAL

Remove the door striker bolts and door striker.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Do not reuse door striker bolts.
- After installation, perform the front door adjustment procedure. Refer to [DLK-173, "DOOR ASSEMBLY : Adjustment"](#).
- After installation, apply touch-up paint (body color) to the head of the door striker bolts.

DOOR HINGE

DOOR HINGE : Removal and Installation

INFOID:000000010639851

WARNING:

Before servicing, push power switch OFF, disconnect 12V battery negative terminal and wait 5 minutes or more. Refer to [DLK-10, "Precaution for Removing 12V Battery"](#).

CAUTION:

- Use two people when removing or installing the front door due to its heavy weight.
- When removing and installing front door assembly, support door using a suitable tool.

REMOVAL

1. Disconnect the negative and positive battery terminals and wait at least three minutes.
2. Remove front fender. Refer to [DLK-169, "Removal and Installation"](#).
3. Remove front door assembly. Refer to [DLK-171, "DOOR ASSEMBLY : Removal and Installation"](#).
4. Remove front door hinge mounting bolts (body side), and then remove front door hinge.

INSTALLATION

Note the following items, and install in the reverse order of removal.

CAUTION:


- Apply anticorrosive agent to the hinge mating surface.
- After installation, check front door open/close and lock/unlock operation. If necessary, perform the front door adjustment procedure. Refer to [DLK-173, "DOOR ASSEMBLY : Adjustment"](#).
- After installation, apply touch-up paint (body color) to the head of the door hinge nuts.

FRONT DOOR

< REMOVAL AND INSTALLATION >

- Check door hinge rotating part for poor lubrication. If necessary, apply a suitable multi-purpose grease.

← : Grease point




DOOR CHECK LINK

DOOR CHECK LINK : Removal and Installation

INFOID:000000010639852

REMOVAL

1. Fully close the front door window.
2. Remove front door speaker. Refer to [AV-70, "Removal and Installation"](#) (AUDIO WITHOUT NAVIGATION) (EXCEPT MEXICO), [AV-194, "Removal and Installation"](#) (AUDIO WITHOUT NAVIGATION (FOR MEXICO)), [AV-320, "Removal and Installation"](#) (NAVIGATION WITHOUT BOSE), [AV-490, "Removal and Installation"](#) (NAVIGATION WITH BOSE), [AV-593, "Removal and Installation"](#) (TELEMATICS SYSTEM).
3. Remove sealing screen.
NOTE:
Cut the butyl-tape so that some parts of the butyl-tape do not remain on the sealing screen, if the sealing screen is reused.
4. Remove the door check link bolt (body side).
5. Remove the door check link bolts (door side).
6. Remove door check link (1) from door panel (2).




INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Check front door open/close operation after installation.
- Check door check link rotating part for poor lubrication. If necessary, apply a suitable multi-purpose grease.

← : Grease point




REAR DOOR

< REMOVAL AND INSTALLATION >

REAR DOOR

Exploded View

INFOID:000000010639853



- | | | |
|-----------------------|-----------------------|--------------------|
| 1. Rear door panel | 2. Grommet | 3. Bolt |
| 4. Door striker | 5. Bumper rubber | 6. Door check link |
| 7. Door hinge (lower) | 8. Door hinge (upper) | ⊗ Do not reuse |

Grease

DOOR ASSEMBLY

DOOR ASSEMBLY : Removal and Installation


INFOID:000000010639854

CAUTION:

- Use two people when removing or installing the rear door due to its heavy weight.
- When removing or installing the rear door assembly, support the rear door using a suitable tool.

REMOVAL


1. Remove rear door harness grommet (2) from body side outer (1) and pull out rear door harness.



REAR DOOR

< REMOVAL AND INSTALLATION >

2. Disconnect the harness connector from the rear door.



3. Remove the door check link bolt (body side).
4. Remove door hinge nuts (door side) and rear door assembly.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Apply anticorrosive agent onto the mounting surface.
- After installation, check the rear door open/close and lock/unlock operation. If necessary, perform the rear door assembly adjustment procedure. Refer to [DLK-178, "DOOR ASSEMBLY : Adjustment"](#).
- Check door hinge rotating part for poor lubrication. If necessary, apply a suitable multi-purpose grease.
- After installation, apply touch-up paint (body color) to the head of door hinge nuts.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P


DLK

REAR DOOR

< REMOVAL AND INSTALLATION >

DOOR ASSEMBLY : Adjustment

INFOID:000000010639855



- | | | |
|---------------------|----------------------------|----------------------------|
| 1. Front fender | 2. Front door | 3. Rear door |
| 4. Body side outer | 5. Door striker | 6. Bolt |
| 7. Front door hinge | 8. Rear door hinge (upper) | 9. Rear door hinge (lower) |
- Do not reuse
 Grease

Check the clearance and surface height between rear door and each part by visual inspection and tactile feel. If the clearance and the surface height are out of specification, adjust them according to the adjustment procedure.

Unit: mm (in)

Portion	Section	Measurement	Standard
Front fender – Front door	A – A	Clearance	4.0 ± 1.0 (0.16 \pm 0.04)
		Surface height	0.0 ± 1.0 (0.00 \pm 0.04)
Front door – Rear door	B – B	Clearance	4.2 ± 1.0 (0.17 \pm 0.04)
		Surface height	0.0 ± 1.0 (0.00 \pm 0.04)
Front door – Rear door	C – C	Clearance	4.0 ± 1.0 (0.16 \pm 0.04)
		Surface height	0.0 ± 1.0 (0.00 \pm 0.04)

FITTING ADJUSTMENT PROCEDURE

REAR DOOR

< REMOVAL AND INSTALLATION >

1. Remove center pillar lower garnish. Refer to [INT-30, "CENTER PILLAR LOWER GARNISH : Removal and Installation"](#). A
2. Loosen door hinge nuts (door side).
3. Adjust the surface height of rear door according to the specifications provided.
4. Temporarily tighten door hinge nuts (door side). B
5. Loosen door hinge nuts and bolts (body side).
6. Raise rear door at rear end to adjust clearance of rear door according to the specifications provided. C
7. Tighten bolts and nuts to the specified torque.
CAUTION:
 - After installation, apply touch-up paint (body color) to the head of door hinge bolts and nuts.
 - Check door hinge rotating part for poor lubrication. If necessary, apply a suitable multi-purpose grease.
8. Install center pillar lower garnish. Refer to [INT-30, "CENTER PILLAR LOWER GARNISH : Removal and Installation"](#). E

DOOR STRIKER ADJUSTMENT

Adjust door striker so that it becomes parallel with door lock insertion direction.

DOOR STRIKER

DOOR STRIKER : Removal and Installation

INFOID:000000010639856

REMOVAL

Remove the door striker bolts and door striker.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Do not reuse door striker bolts.
- After installation, perform the rear door adjustment procedure. Refer to [DLK-178, "DOOR ASSEMBLY : Adjustment"](#).
- After installation, apply touch-up paint (body color) to the head of the door striker bolts.

DOOR HINGE

DOOR HINGE : Removal and Installation

INFOID:000000010639857

DLK

CAUTION:

- Use two people when removing or installing the rear door due to its heavy weight.
- When removing and installing rear door assembly, support the rear door using a suitable tool.

REMOVAL

1. Remove rear door assembly. Refer to [DLK-176, "DOOR ASSEMBLY : Removal and Installation"](#).
2. Remove center pillar lower garnish. Refer to [INT-30, "CENTER PILLAR LOWER GARNISH : Removal and Installation"](#).
3. Remove the rear door hinge bolts and nuts (body side) and door hinge.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:


- Apply anticorrosive agent onto the mounting surface.
- After installation, check the rear door open/close and lock/unlock operation. If necessary, perform the rear door assembly adjustment procedure. Refer to [DLK-178, "DOOR ASSEMBLY : Adjustment"](#).
- After installation, apply touch-up paint (body color) to the head of door hinge nuts.

REAR DOOR

< REMOVAL AND INSTALLATION >

- Check door hinge rotating part for poor lubrication. If necessary, apply a suitable multi-purpose grease.

← : Grease point




DOOR CHECK LINK

DOOR CHECK LINK : Removal and Installation

INFOID:0000000010639858

REMOVAL

1. Fully close the rear door window.
2. Remove rear door finisher. Refer to [JNT-22, "Removal and Installation"](#).
3. Remove front door speaker. Refer to [AV-70, "Removal and Installation"](#) (AUDIO WITHOUT NAVIGATION) (EXCEPT MEXICO), [AV-194, "Removal and Installation"](#) (AUDIO WITHOUT NAVIGATION (FOR MEXICO)), [AV-320, "Removal and Installation"](#) (NAVIGATION WITHOUT BOSE), [AV-490, "Removal and Installation"](#) (NAVIGATION WITH BOSE), [AV-593, "Removal and Installation"](#) (TELEMATICS SYSTEM).
4. Remove the door check link bolt (body side).
5. Remove the door check link bolts (door side).
6. Remove door check link (1) from door panel (2).




INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- After installation, check the rear door open/close and lock/unlock operation.
- Check door check link rotating part for poor lubrication. If necessary, apply a suitable multi-purpose grease.

← : Grease point




BACK DOOR

< REMOVAL AND INSTALLATION >

BACK DOOR

Exploded View

INFOID:000000010639859



- | | | |
|----------------------------|----------------------------|---------------------------------|
| 1. Back door weather-strip | 2. Back door stay assembly | 3. Back door stay lower bracket |
| 4. Bumper rubber | 5. Bolt | 6. Back door striker |
| 7. Back door panel | 8. Back door hinge | A. Center mark |
| B. Seam | Grease | |

BACK DOOR ASSEMBLY

BACK DOOR ASSEMBLY : Removal and Installation

INFOID:000000010639860

CAUTION:

- Use two people when removing or installing the back door due to its heavy weight.
- Use shop cloths to protect surrounding components from damage during removal or installation of the back door.


REMOVAL

1. Remove the rear pillar finishers (LH/RH). Refer to [INT-31, "REAR PILLAR FINISHER : Removal and Installation"](#).


BACK DOOR

< REMOVAL AND INSTALLATION >


2. Disconnect harness connector (A) and (B).
3. Remove harness clip (C).
4. Remove ground cable mounting bolt (D).
⇐: Front




5. Remove rear washer hose (1) from hose joint (2).
⇐: Front



6. Remove grommet (1), and then pull out harness from rear fender extension (LH) (2).



7. Remove grommet (1), and then pull out harness from rear fender extension (RH) (2).



8. Support back door with appropriate material to prevent it from falling.

WARNING:

Bodily injury may occur if no supporting rod is holding the back door open when removing the back door stay.

9. Remove back door stay assembly (back door side). Refer to [DLK-185, "BACK DOOR STAY : Removal and Installation"](#).
10. Remove back door hinge nuts on back door and remove.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:


BACK DOOR

< REMOVAL AND INSTALLATION >

- Check back door hinge rotating part for poor lubrication. If necessary, apply a suitable multi-purpose grease.
- After installation, check back door open/close and lock/unlock operation. If necessary, perform the back door assembly adjustment procedure. Refer to [DLK-183, "BACK DOOR ASSEMBLY : Adjustment"](#).

BACK DOOR ASSEMBLY : Adjustment

INFOID:000000010639861



1. Back door assembly
2. Bumper rubber
3. Back door hinge
4. Back door striker

5. Bolt
6. Roof panel



7. Back door hinge
8. Back door assembly
9. Back door assembly
10. Back door assembly

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK

BACK DOOR

< REMOVAL AND INSTALLATION >

- | | | |
|--------------------------|--|--|
| 7. Rear spoiler assembly | 8. Rear combination lamp | 9. Back door glass |
| 10. Rear bumper fascia |  Do not reuse |  Grease |


Check the clearance and the surface height between the back door and each part by visual inspection and tactile feel. If the clearance and surface height is out of specification, adjust them according to the adjustment procedure.

Unit: mm (in)

Portion	Section	Item	Measurement	Standard	Parallelism	Equality
Roof panel – Rear spoiler	A – A	F	Clearance	7.0 ± 2.0 (0.28 ± 0.08)	0.0 (0.00)	2.0 (0.08)
		G	Surface height	0.8 ± 2.0 (0.03 ± 0.08)	—	—
Rear combination lamp – Back door glass	B – B	H	Clearance	5.0 ± 2.3 (0.20 ± 0.09)	1.9 (0.07)	2.9 (0.11)
Rear combination lamp – Back door	C – C	J	Clearance	5.0 ± 2.3 (0.20 ± 0.09)	1.9 (0.07)	2.9 (0.11)
Rear bumper fascia – Back door	D – D	K	Clearance	5.3 ± 2.0 (0.21 ± 0.08)	2.0 (0.08)	2.0 (0.08)
Rear bumper fascia – Back door	E – E	M	Clearance	8.0 ± 2.0 (0.31 ± 0.08)	2.0 (0.08)	—

FITTING ADJUSTMENT PROCEDURE

- Loosen back door striker bolts.
- Loosen back door hinge nuts (back door side).
- Adjust back door to specifications provided.
- After adjustment tighten back door striker bolts and back door hinge nuts (back door side) to the specified torque.
- Screw bumper rubber into the stopper position (A), and then loosen by a half turn.



CAUTION:

After installation, apply touch-up paint (body color) to the head of back door hinge nuts.

BACK DOOR STRIKER ADJUSTMENT

Adjust the back door striker so that it becomes parallel with back door lock insertion direction.

BACK DOOR STRIKER

BACK DOOR STRIKER : Removal and Installation

INFOID:0000000010639862

REMOVAL

Remove the door striker bolts and door striker.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Do not reuse door striker bolts.
- After installation, perform the back door adjustment procedure. Refer to [DLK-183, "BACK DOOR ASSEMBLY : Adjustment"](#).
- After installation, apply touch-up paint (body color) to the head of the door striker bolts.

BACK DOOR HINGE

BACK DOOR


< REMOVAL AND INSTALLATION >

BACK DOOR HINGE : Removal and Installation

INFOID:0000000110639863

REMOVAL

1. Remove the luggage floor upper finisher. Refer to [INT-41, "LUGGAGE FLOOR BOARD : Removal and Installation"](#).
2. Remove back door assembly. Refer to [DLK-181, "BACK DOOR ASSEMBLY : Removal and Installation"](#).
3. Partially remove the back door weather-strip. Refer to [DLK-186, "BACK DOOR WEATHER-STRIP : Removal and Installation"](#).
4. Remove rear assist grips (LH/RH) and mounting clips for rear portion of headlining, and then remove rear portion of headlining. Refer to [INT-36, "Exploded View"](#).
5. Remove insulator (A).



6. Remove back door hinge nut (body side) and back door hinge.


INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- After installation, check back door open/close and lock/unlock operation. If necessary, perform the back door assembly adjustment procedure. Refer to [DLK-183, "BACK DOOR ASSEMBLY : Adjustment"](#).
- Check back door hinge rotating part for poor lubrication. If necessary, apply a suitable multi-purpose grease.

← : Grease point



BACK DOOR STAY

BACK DOOR STAY : Removal and Installation

INFOID:0000000110639864

REMOVAL

1. Support the back door using a suitable tool.

WARNING:

Bodily injury may occur if no supporting rod is holding the back door open when removing the back door stay.

2. Remove back door stay bolts (body side).

BACK DOOR


< REMOVAL AND INSTALLATION >

3. Remove the metal clip (3) located on the connection between the back door stay assembly (1) and the back door stay lower bracket (2) by using a suitable tool (A).

CAUTION:

Be careful not to damage painted surface.

4. Remove back door stay assembly (back door side).



5. Remove back door stay bolts and back door stay assembly.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Apply anticorrosive agent onto the mounting surface.
- After installation, check back door open/close and lock/unlock operation.


BACK DOOR STAY : Disposal

INFOID:000000010639865

1. Fix back door stay (1) using a vise (C).
2. Using hacksaw (A) slowly make 2 holes in the back door stay, in numerical order as shown in the figure.


CAUTION:

- When cutting a hole on back door stay, always cover the hacksaw using a shop cloth (B) to avoid scattering metal fragments or oil.
- Wear eye protection (safety glasses).
- Wear gloves.



A: 20.0 mm (0.787 in)

B: Cut at the groove.



BACK DOOR WEATHER-STRIP

BACK DOOR WEATHER-STRIP : Removal and Installation

INFOID:000000010639866

REMOVAL

Pull and remove engagement with body from weather-strip joint.

CAUTION:


Do not pull strongly on weather-strip.

INSTALLATION

BACK DOOR


< REMOVAL AND INSTALLATION >

1. Working from the upper section, align weather-strip center mark (A) with vehicle center mark (cutting position) and install weather-strip onto the vehicle.



⇐ Front

2. Align the connecting point (B) of weather-strip (2) to the center (A) of striker (1), and then install as shown in the figure.



3. Pull weather-strip gently to ensure that there is no loose section.
NOTE:
Check that weather-strip fits tightly in each corner.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK


HOOD LOCK



< REMOVAL AND INSTALLATION >

HOOD LOCK

Exploded View

INFOID:000000010639867



- | | | |
|--------------------------------|--|--|
| 1. Hood lock secondary control | 2. Hood lock assembly | 3. Hood lock control cable |
| A. To charge port lid lock |  Clip |  Grease |


HOOD LOCK

HOOD LOCK : Removal and Installation

INFOID:000000010639868

REMOVAL

1. Remove radiator upper grille. Refer to [DLK-166, "RADIATOR UPPER GRILLE : Removal and Installation"](#).
2. Remove hood lock assembly. Refer to [DLK-188, "HOOD LOCK : Removal and Installation"](#).
3. Disconnect hood lock control cable (2) from hood lock assembly (1).



4. Disconnect the harness connector from the hood lock assembly (if equipped).
5. Remove the hood lock assembly.

INSTALLATION

HOOD LOCK

< REMOVAL AND INSTALLATION >

Installation is in the reverse order of removal.

CAUTION:

- Check that hood lock control cable is properly engaged with hood lock.
- After installation, perform hood assembly adjustment procedure. Refer to [DLK-156, "HOOD ASSEMBLY : Adjustment"](#).
- After installation, perform hood lock control inspection. Refer to [DLK-189, "Inspection"](#).

HOOD LOCK SECONDARY CONTROL

HOOD LOCK SECONDARY CONTROL : Removal and Installation

INFOID:000000010639869

REMOVAL

Remove the hood lock secondary control nuts and hood lock secondary control.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

After installation, perform hood lock control inspection. Refer to [DLK-189, "Inspection"](#).

HOOD LOCK CONTROL CABLE

HOOD LOCK CONTROL CABLE : Removal and Installation

INFOID:000000010639870

REMOVAL

1. Disconnect the hood lock control cable from the hood lock assembly.
2. Disconnect the charge port lid control cable from the charge port lid lock.
3. Disconnect the hood lock control cable and charge port lid control cable from the hood lock release handle and charge port lid lock release handle.
4. Remove the fender protector (LH). Refer to [EXT-21, "FENDER PROTECTOR : Removal and Installation"](#).
5. Release hood lock control cable clips using a suitable tool.
6. Remove grommet on the lower dash, and pull the hood lock control cable toward the passenger compartment.

CAUTION:


While pulling, do not damage the outside of hood lock control cable.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Do not bend cable too much, keep the radius 100 mm (3.937 in) or more.
- Check that cable is not offset from the positioning grommet and apply sealant to the grommet (at * mark).



- Check that hood lock control cable is properly engaged with hood lock.
- After installation, perform hood assembly adjustment procedure. Refer to [DLK-156, "HOOD ASSEMBLY : Adjustment"](#).
- After installation, perform hood lock control inspection. Refer to [DLK-189, "Inspection"](#).

Inspection

INFOID:000000010639871

NOTE:

If the hood lock release cable is bent or deformed, replace it.

A
B
C
D
E
F
G
H
I
J
DLK

L
M
N
O
P

HOOD LOCK


< REMOVAL AND INSTALLATION >

1. Check that secondary latch is properly engaged with secondary striker with hoods own weight.
2. While operating hood lock release lever, carefully check that the front end of the hood is raised by approximately 20.0 mm (0.79 in). Also check that the hood lock release lever returns to the original position.
3. Check that the hood lock release lever operates at 49 N (5.0 kg-m, 11.0 ft-lb) or below.
4. Install so that the static closing force of the hood is 120 - 564 N (12.2 - 57.6 kg-m, 89 - 416 ft-lb).

NOTE:

- Do not exert vertical force on the right or left side of hood lock.
 - Do not press simultaneously on both sides.
5. Check the hood lock lubrication condition. If necessary, apply a suitable multi-purpose grease.

← : Grease point




CHARGE PORT LID LOCK

< REMOVAL AND INSTALLATION >

CHARGE PORT LID LOCK

Exploded View

INFOID:0000000110639872



- | | | |
|-----------------------------------|--------------------------------------|-----------------------------|
| 1. Charge port lid cover assembly | 2. Charge port lid seal | 3. Charge port lid assembly |
| 4. Charge port lid lock cable | 5. Charge port lid actuator assembly | 6. Charge port lid |
| 7. Charge port lid lock | 8. Charge port lid rear cover | △ Clip |


CHARGE PORT LID LOCK

CHARGE PORT LID LOCK : Removal and Installation

INFOID:0000000110639873

REMOVAL

1. Remove charge port lid rear cover. Refer to [DLK-159, "Exploded View"](#).
2. Disconnect charge port lid control cable (2) from charge port lid lock (1), as shown.



3. Remove charge port lid lock bolts and charge port lid lock.

CHARGE PORT LID LOCK

< REMOVAL AND INSTALLATION >

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Check that charge port lid lock control cable is properly engaged with charge port lid lock.
- After installation, perform charge port lid fitting adjustment. Refer to [DLK-160, "CHARGE PORT LID ASSEMBLY : Adjustment"](#).

CHARGE PORT LID OPENER ACTUATOR

CHARGE PORT LID OPENER ACTUATOR : Removal and Installation

INFOID:000000010639874


REMOVAL

1. Remove charge port lid rear cover. Refer to [DLK-159, "Exploded View"](#).


2. Remove actuator cover.

a. Remove actuator cover screws.

b. Pull up actuator cover (1) from harness grommet (2) side, and the disconnect harness connector (A) from charge port lid opener actuator (3).



c. Remove charge port lid control cable (1) from charge port lid hinge assembly (2) and charge port lid opener actuator (3).



d. Remove actuator cover, charge port lid control cable and harness at the same time.

3. Remove charge port lid opener actuator bolts and charge port lid opener actuator.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Check that charge port lid lock control cable is properly engaged with charge port lid opener actuator.
- When replace charge port lid control cable and charge port lid opener actuator, replace with actuator cover.
- After installation, perform charge port lid fitting adjustment. Refer to [DLK-160, "CHARGE PORT LID ASSEMBLY : Adjustment"](#).
- Check charge port lid assembly lock/unlock operation after installation.


FRONT DOOR LOCK

< REMOVAL AND INSTALLATION >

FRONT DOOR LOCK

Exploded View

INFOID:0000000110639875



- | | | |
|---|--------------------------|---------------------------|
| 1. Door key cylinder assembly (driver side) | 2. Rear gasket | 3. Outside handle bracket |
| Outside handle escutcheon (passenger side) | | |
| 4. Bolt | 5. Key rod (driver side) | 6. Door lock assembly |
| 7. Inside handle escutcheon | 8. Inside handle | 9. Cable clip |
| 10. Front gasket | 11. Outside handle | ⇐ Front |
| ⊗ Do not reuse | 🛢 Grease | |

DOOR LOCK

DOOR LOCK : Removal and Installation

INFOID:0000000110639876

REMOVAL

1. Remove outside handle bracket. Refer to [DLK-194, "OUTSIDE HANDLE : Removal and Installation"](#).
2. Remove front door lower sash. Refer to [GW-20, "Exploded View"](#).
3. Remove door lock assembly bolts.
4. Disconnect the harness connector from the door lock actuator and remove door lock assembly.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:


- Do not reuse door lock assembly bolts.
- After installation, check the door open/close and lock/unlock operation.
- After installation, check door lock cable is properly engaged with outside handle bracket.

FRONT DOOR LOCK

< REMOVAL AND INSTALLATION >

- Check door lock assembly for poor lubrication. If necessary, apply a suitable multi-purpose grease.

← : Grease point



INSIDE HANDLE

INSIDE HANDLE : Removal and Installation

INFOID:000000010639877

REMOVAL

1. Remove front door finisher. Refer to [INT-19. "Removal and Installation"](#).
2. Remove inside handle screws and inside handle.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

After installation, check the door open/close and lock/unlock operation.

OUTSIDE HANDLE

OUTSIDE HANDLE : Removal and Installation

INFOID:000000010639878


REMOVAL

1. Fully close the front door glass.
2. Remove front door finisher. Refer to [INT-19. "Removal and Installation"](#).
3. Remove sealing screen.

NOTE:

Cut the butyl-tape so that some parts of the butyl-tape do not remain on the sealing screen, if the sealing screen is reused.


4. Disengage rod holder (1), and then separate key rod (3) from door lock assembly (2) (driver side).



FRONT DOOR LOCK


< REMOVAL AND INSTALLATION >

5. Disconnect harness connector from door antenna (1) and door request switch (2) and remove harness clamps (A).




↔ Front


6. Remove grommet (1) (door side). Loosen bolt (2) that retains door lock cylinder. (For passenger side, bolt fixes outside handle escutcheon.)



7. While pulling outside handle, remove door key cylinder assembly (driver side) or outside handle escutcheon (passenger side).



8. While pulling outside handle (1), slide toward rear of vehicle to remove outside handle.




A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

FRONT DOOR LOCK

< REMOVAL AND INSTALLATION >

9. Remove front gasket (1) and rear gasket (2).




○ Pawl


⇐ Front

10. Slide outside handle bracket toward rear of vehicle to remove.

⇐ Front



11. Disconnect outside handle cable (1) from outside handle bracket (2).



INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- When installing key rod, rotate key rod holder until a click is felt (driver side only).
- Check that door lock cables are properly engaged with inside handle and outside handle.
- After installation, check door open/close and lock/unlock operation.


REAR DOOR LOCK

< REMOVAL AND INSTALLATION >

REAR DOOR LOCK

Exploded View

INFOID:0000000110639879



- | | | |
|------------------------------|-----------------------|-----------------------------|
| 1. Outside handle escutcheon | 2. Rear gasket | 3. Outside handle bracket |
| 4. Bolt | 5. Door lock assembly | 6. Inside handle escutcheon |
| 7. Inside handle | 8. Cable clip | 9. Front gasket |
| 10. Outside handle | ↶ Front | ⊗ Do not reuse |

Grease

DOOR LOCK

DOOR LOCK : Removal and Installation

INFOID:0000000110639880

REMOVAL

1. Remove outside handle bracket. Refer to [DLK-198, "OUTSIDE HANDLE : Removal and Installation"](#).


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK

REAR DOOR LOCK

< REMOVAL AND INSTALLATION >

2. Disengage inside handle cable (1) from cable clip (A).



3. Remove lower bolt (B) of partition sash.
4. Disconnect the harness connector from the door lock actuator.
5. Remove door lock assembly bolts.
6. Remove door lock assembly while locating Inside handle cable and door lock cable to the bottom side of rear partition sash.


INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Do not reuse door lock assembly bolts.
- After installation, check the door open/close and lock/unlock operation.
- After installation, check door lock cable is properly engaged with outside handle bracket.
- Check door lock assembly for poor lubrication. If necessary, apply a suitable multi-purpose grease.

← : Grease point



INSIDE HANDLE

INSIDE HANDLE : Removal and Installation

INFOID:0000000010639881

REMOVAL

1. Remove rear door finisher. Refer to [INT-22. "Removal and Installation"](#).
2. Remove inside handle screws and inside handle.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

After installation, check door open/close and lock/unlock operation.

OUTSIDE HANDLE

OUTSIDE HANDLE : Removal and Installation

INFOID:0000000010639882

REMOVAL

1. Fully close rear door glass.

REAR DOOR LOCK


< REMOVAL AND INSTALLATION >

2. Remove rear door finisher. Refer to [INT-22. "Removal and Installation"](#).
3. Remove sealing screen.


NOTE:

Cut the butyl-tape so that some parts of the butyl-tape do not remain on the sealing screen, if the sealing screen is reused.


4. Remove door side grommet and loosen bolt from grommet hole.




5. While pulling outside handle, remove outside handle escutcheon.



6. While pulling outside handle (1), slide toward rear of vehicle to remove outside handle.



7. Remove front gasket (1) and rear gasket (2).



- Pawl
- ← Front


A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

REAR DOOR LOCK


< REMOVAL AND INSTALLATION >

8. Slide outside handle bracket toward rear of vehicle to remove.

⇐: Front



9. Disconnect outside handle cable (1) from outside handle bracket (2).



INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- After installation, check door open/close and lock/unlock operation.
- Check door lock cable is properly engaged with outside handle bracket.


BACK DOOR LOCK

< REMOVAL AND INSTALLATION >

BACK DOOR LOCK

Exploded View

INFOID:000000010639883



- 1. Back door lock assembly
 - 2. Bolt
 - 3. Back door striker
 - 4. Outside handle
- ⊗ Do not reuse 🛢 Grease


DOOR LOCK

DOOR LOCK : Removal and Installation

INFOID:000000010639884

REMOVAL

1. Remove the back door lower finisher. Refer to [INT-46. "BACK DOOR LOWER FINISHER : Removal and Installation"](#).
2. Remove back door lock harness (1) from back door lock assembly (2).
3. Disconnect the harness connector (A) from the back door lock assembly.



4. Remove back door lock assembly bolts and back door lock assembly.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

After installation, check back door open/close and lock/unlock operation.

OUTSIDE HANDLE

OUTSIDE HANDLE : Removal and Installation

INFOID:000000010639885

REMOVAL


1. Remove the back door lower finisher. Refer to [INT-46. "BACK DOOR LOWER FINISHER : Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

BACK DOOR LOCK

< REMOVAL AND INSTALLATION >

2. Disconnect the harness connectors from the outside handle and rear view camera (if equipped).



3. Remove outside handle nuts.
4. Remove harness grommet from back door panel, then remove the outside handle.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

After installation, check back door open/close and lock/unlock operation.

KEY CYLINDER

< REMOVAL AND INSTALLATION >

KEY CYLINDER


GLOVE BOX LID KEY CYLINDER

GLOVE BOX LID KEY CYLINDER : Removal and Installation

INFOID:000000010639886

REMOVAL


1. Insert key (1) into glove box lid lock cylinder (2).
2. Pull upward on glove box lid release handle (3).
3. Rotate key (1) and turn glove box lid key cylinder (2) to the lock position.



4. Press tumbler stopper (1) into glove box lid lock cylinder (2) using a suitable tool (A), and then remove key (3) and glove box lid lock cylinder together from glove box lid release handle (4).

NOTE:

When removing glove box lid lock cylinder (2) note the position of cylinder to glove box lid release handle (4).




5. Remove sleeve (3) from glove box lid release handle and then install sleeve to glove box lid lock cylinder.

NOTE:

When removing sleeve note the position of sleeve to glove box lid release handle.

CAUTION:

Do not pull out key (1) from glove box lid lock cylinder (2) while sleeve (3) is removed. Otherwise, tumblers (4) may be lost from glove box lid lock cylinder.



INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

After installation, check glove box assembly open/close, lock/unlock operation.

DOOR SWITCH

< REMOVAL AND INSTALLATION >


DOOR SWITCH

Removal and Installation

INFOID:000000010639887

REMOVAL

1. Remove the door switch bolt (A).
2. Disconnect the harness connector and remove the door switch (1).



INSTALLATION

Installation is in the reverse order of removal.

DOOR REQUEST SWITCH

< REMOVAL AND INSTALLATION >

DOOR REQUEST SWITCH

DRIVER SIDE

DRIVER SIDE : Removal and Installation

INFOID:000000010639888

The door request switch (driver side) is serviced as an assembly with the outside handle. Refer to [DLK-194](#), "[OUTSIDE HANDLE : Removal and Installation](#)".

PASSENGER SIDE

PASSENGER SIDE : Removal and Installation

INFOID:000000010639889

The door request switch (passenger side) is serviced as an assembly with the outside handle. Refer to [DLK-194](#), "[OUTSIDE HANDLE : Removal and Installation](#)".

BACK DOOR

BACK DOOR : Removal and Installation

INFOID:000000010639890

The back door request switch is serviced as an assembly with the back door opener switch. Refer to [DLK-213](#), "[Removal and Installation](#)".

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

INSIDE KEY ANTENNA

< REMOVAL AND INSTALLATION >


INSIDE KEY ANTENNA INSTRUMENT CENTER

INSTRUMENT CENTER : Removal and Installation

INFOID:0000000010639891

REMOVAL

1. Remove the cluster lid C. Refer to [IP-17. "Removal and Installation"](#).
2. Remove the inside key antenna (instrument center) screw (A).
CAUTION:
Be careful not to drop mounting screw (A) into instrument panel.
3. Disconnect the harness connector and remove the inside key antenna (instrument center) (1).



INSTALLATION

Installation is in the reverse order of removal.

CENTER CONSOLE

CENTER CONSOLE : Removal and Installation

INFOID:0000000010639892

REMOVAL

1. Remove the shift selector finisher. Refer to [IP-28. "Exploded View"](#).
2. Disconnect the harness connector from the inside key antenna (center console).
3. Remove the inside key antenna (center console) screws and inside key antenna.

INSTALLATION

Installation is in the reverse order of removal.


REAR SEAT

REAR SEAT : Removal and Installation

INFOID:0000000010639893

REMOVAL

1. Remove the rear seat. Refer to [SE-40. "SEAT CUSHION : Removal and Installation"](#).
2. Release the inside key antenna (rear seat) clip (A) using a suitable tool.
3. Disconnect the harness connector and remove the inside key antenna (rear seat) (1).



INSTALLATION

Installation is in the reverse order of removal.

LUGGAGE ROOM

LUGGAGE ROOM : Removal and Installation

INFOID:0000000010639894

REMOVAL


INSIDE KEY ANTENNA

< REMOVAL AND INSTALLATION >

1. Remove the luggage floor board. Refer to [INT-41. "LUGGAGE REAR PLATE : Removal and Installation"](#).
2. Disconnect the harness connector and remove the inside key antenna (luggage room) (1) using a suitable tool (A).

CAUTION:

- When removing and installing, use shop cloths to protect the inside key antenna (luggage room) from damage.
- Be aware that mounting clips (B) may pop put.



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

OUTSIDE KEY ANTENNA

< REMOVAL AND INSTALLATION >

OUTSIDE KEY ANTENNA

DRIVER SIDE

DRIVER SIDE : Removal and Installation

INFOID:000000010639895

The outside key antenna (driver side) is serviced as an assembly with the outside handle. Refer to [DLK-194](#), "[OUTSIDE HANDLE : Removal and Installation](#)".

PASSENGER SIDE

PASSENGER SIDE : Removal and Installation

INFOID:000000010639896

The outside key antenna (passenger side) is serviced as an assembly with the outside handle. Refer to [DLK-194](#), "[OUTSIDE HANDLE : Removal and Installation](#)".


REAR BUMPER

REAR BUMPER : Removal and Installation

INFOID:000000010639897

REMOVAL

1. Remove the rear bumper fascia. Refer to [EXT-17](#), "[Removal and Installation](#)".
2. Release the outside key antenna (rear bumper) clip (A) using a suitable tool.
3. Disconnect the harness connector and remove the outside key antenna (rear bumper) (1).



INSTALLATION

Installation is in the reverse order of removal.

INTELLIGENT KEY WARNING BUZZER

< REMOVAL AND INSTALLATION >


INTELLIGENT KEY WARNING BUZZER

Removal and Installation

INFOID:000000010639898

REMOVAL

1. Remove the front bumper fascia. Refer to [EXT-13. "Removal and Installation"](#).
2. Disconnect the harness connector from the Intelligent Key warning buzzer.
3. Remove the Intelligent Key warning buzzer bolt (A) and Intelligent Key warning buzzer (1).



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

REMOTE KEYLESS ENTRY RECEIVER

< REMOVAL AND INSTALLATION >


REMOTE KEYLESS ENTRY RECEIVER

Removal and Installation

INFOID:000000010639899

REMOVAL

1. Remove the glove box assembly. Refer to [IP-17. "Removal and Installation"](#)
2. Disconnect the harness connector from the remote keyless entry receiver.
3. Remove the remote keyless entry receiver bolt (A) and remote keyless entry receiver (1).



INSTALLATION

Installation is in the reverse order of removal.

INTELLIGENT KEY BATTERY

< REMOVAL AND INSTALLATION >

INTELLIGENT KEY BATTERY


Removal and Installation

INFOID:0000000110639900

1. Release the lock knob at the back of the Intelligent Key and remove the mechanical key.
2. Insert a suitable tool (A) wrapped with a cloth into the slit of the corner and twist it to separate the upper part from the lower part.

CAUTION:

- Do not touch the circuit board or battery terminal.
- The key fob is water-resistant. However, if it does get wet, immediately wipe it dry.



3. Replace the battery with new one.


Battery replacement

:Coin-type lithium battery (CR2025)

4. Align the tips of the upper and lower parts, and then push them together until it is securely closed.

CAUTION:

- When replacing battery, keep dirt, grease, and other foreign materials off the electrode contact area.
- After replacing the battery, check that all Intelligent Key functions work normally.



A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

CHARGE PORT LID OPENER SWITCH

< REMOVAL AND INSTALLATION >


CHARGE PORT LID OPENER SWITCH

Removal and Installation

INFOID:000000010639901


REMOVAL

1. Remove instrument lower panel LH. Refer to [IP-17. "Removal and Installation"](#).
2. Remove the switch finisher screws (A) and switch finisher (1).



3. Remove charge port lid opener switch (2) from switch finisher (1).

○: Pawl



INSTALLATION

Installation is in the reverse order of removal.

BACK DOOR OPENER SWITCH ASSEMBLY

< REMOVAL AND INSTALLATION >


BACK DOOR OPENER SWITCH ASSEMBLY

Removal and Installation


INFOID:0000000110639902

REMOVAL

1. Remove back door outside handle. Refer to [DLK-201. "OUTSIDE HANDLE : Removal and Installation"](#).
2. Remove the switch finisher screws (A) and switch finisher (1).



3. Pinch back door opener switch assembly (2) from both side (in the direction shown by arrow 1) and disengage tab. Press toward outside (in the direction shown by arrow 2) to remove from back door outside handle (1).



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK