

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DI  
L  
M

# DI

## SECTION

# DRIVER INFORMATION SYSTEM

### CONTENTS

<b>PRECAUTIONS</b> .....	<b>4</b>	LOW-FUEL WARNING LAMP .....	<b>16</b>
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	4	Fuel Gauge Pointer Fluctuates-Indicator Wrong Value or Varies .....	18
Wiring Diagrams and Trouble Diagnosis .....	4	Fuel Gauge Does Not Move to FULL Position .....	18
<b>PREPARATION</b> .....	<b>5</b>	Electrical Components Inspection .....	19
Commercial Service Tools .....	5	CHECK FUEL LEVEL SENSOR UNIT .....	19
<b>COMBINATION METERS</b> .....	<b>6</b>	Removal and Installation of Combination Meter ....	19
System Description .....	6	REMOVAL .....	19
UNIFIED CONTROL METER .....	6	INSTALLATION .....	19
HOW TO CHANGE THE DISPLAY FOR ODO/TRIP METER .....	6	Disassembly and Assembly of Combination Meter..	20
POWER SUPPLY AND GROUND CIRCUIT .....	6	DISASSEMBLY .....	20
WATER TEMPERATURE GAUGE .....	7	ASSEMBLY .....	20
TACHOMETER .....	7	<b>COMPASS</b> .....	<b>21</b>
FUEL GAUGE .....	7	System Description .....	21
SPEEDOMETER .....	7	DIRECTION DISPLAY .....	21
CAN Communication System Description .....	7	Wiring Diagram – COMPAS – .....	23
CAN Communication Unit .....	7	Removal and Installation of Compass .....	24
Component Parts and Harness Connector Location...	7	<b>WARNING LAMPS</b> .....	<b>25</b>
Combination Meter .....	8	System Description .....	25
CHECK .....	8	OUTLINE .....	25
Schematic .....	9	AIR BAG WARNING LAMP .....	25
Wiring Diagram — METER — .....	10	DOOR WARNING LAMP .....	25
Terminals and Reference Value for Combination Meter .....	12	LOW OIL PRESSURE WARNING LAMP .....	25
Meter/Gauges Operation, Odo/Trip Meter, A/T Indicator and ICC System Display .....	12	CHARGE WARNING LAMP .....	25
SELF-DIAGNOSIS FUNCTION .....	12	LOW WASHER LEVEL WARNING LAMP .....	25
HOW TO ALTERNATE DIAGNOSIS MODE .....	12	A/T CHECK WARNING LAMP .....	26
How to Proceed with Trouble Diagnosis .....	13	LOW FUEL LEVEL WARNING LAMP .....	26
Diagnosis Flow .....	13	ABS WARNING LAMP .....	26
Power Supply and Ground Circuit Inspection .....	14	VDC OFF WARNING LAMP .....	26
Trouble Diagnosis Chart by Symptom .....	15	SLIP WARNING LAMP .....	26
DIAGNOSIS RESULTS .....	15	SEAT BELT WARNING LAMP .....	26
Engine Speed Signal Inspection .....	16	BRAKE WARNING LAMP .....	26
Water Temperature Signal Inspection .....	16	MALFUNCTION INDICATOR LAMP .....	27
Vehicle Speed Signal Inspection .....	16	LOW TIRE PRESSURE WARNING LAMP .....	27
Fuel Level Sensor Signal Inspection .....	16	ASCD WARNING LAMP .....	27
FUEL LEVEL SENSOR UNIT .....	16	ICC SYSTEM WARNING LAMP .....	27
		WARNING MESSAGE ON DISPLAY .....	27
		Schematic .....	28
		Wiring Diagram — WARN — .....	29
		Terminals and Reference Value for BCM .....	37

Work Flow .....	37	AV COMMUNICATION LINE .....	65
Preliminary Inspection .....	37	VEHICLE INFORMATION SYSTEM .....	66
CONSULT-II Function .....	37	SETTING OF VEHICLE STATUS .....	68
DIAGNOSTIC ITEMS DESCRIPTION .....	37	WARNING INDICATIONS .....	70
CONSULT-II BASIC OPERATION PROCEDURE .....	37	Precautions for AV and NAVI Control Unit Replacement .....	71
DATA MONITOR .....	38	Component Parts and Harness Connector Location .....	71
ACTIVE TEST .....	39	Schematic .....	72
On Board Diagnosis .....	39	Wiring Diagram — INF/D — .....	73
SWITCH MONITOR .....	39	Terminals and Reference Value for AV and NAVI Control Unit .....	78
DIAGNOSIS ITEM .....	40	Terminals and Reference Value for Display .....	78
Trouble Diagnosis for Door Warning Lamp .....	40	Terminals and Reference Value for Multifunction Switch .....	80
Inspection/Combination Meter Circuit .....	40	On Board Self-Diagnosis Function .....	80
Inspection/Front Door Switch .....	41	DESCRIPTION .....	80
Inspection/Rear Door Switch .....	42	DIAGNOSIS ITEM .....	81
Electrical Components Inspection .....	43	Self-Diagnosis Mode .....	81
OIL PRESSURE SWITCH .....	43	Confirmation/Adjustment Mode .....	81
<b>A/T INDICATOR .....</b>	<b>44</b>	CONSULT-II Function .....	81
Wiring Diagram — AT/IND — .....	44	Multifunction Switch Self-Diagnosis Function .....	81
A/T Indicator Does Not Illuminate .....	45	STARTING THE SELF-DIAGNOSIS MODE .....	81
<b>WARNING CHIME .....</b>	<b>46</b>	EXITING THE SELF-DIAGNOSIS MODE .....	82
System Description .....	46	DIAGNOSIS FUNCTION .....	82
FUNCTION .....	46	Power Supply and Ground Circuit Check for AV and NAVI Control Unit .....	82
IGNITION KEY WARNING CHIME .....	46	Power Supply and Ground Circuit Inspection for Display .....	82
LIGHT WARNING CHIME .....	46	Power Supply and Ground Circuit Inspection for Multifunction Switch .....	83
SEAT BELT WARNING CHIME .....	47	No Fuel Information is Displayed/No Warning Message is Displayed .....	84
Component Parts and Harness Connector Location .....	47	Vehicle Condition Setting is Not Possible .....	85
Major Component Parts and Function .....	47	Multifunction Switch Does Not Operate .....	86
Schematic .....	48	Multifunction Switch Indicator Does Not Illuminate .....	86
Wiring Diagram — CHIME — .....	49	Removal and Installation of AV and NAVI Control Unit .....	86
Terminals and Reference Value Chart for BCM .....	53	REMOVAL .....	86
Work Flow .....	53	INSTALLATION .....	86
Preliminary Inspection .....	54	Removal and Installation of Display .....	87
INSPECTION FOR POWER SUPPLY AND GROUND CIRCUIT .....	54	REMOVAL .....	87
CONSULT-II Function .....	55	INSTALLATION .....	87
DIAGNOSTIC ITEMS DESCRIPTION .....	55	Disassembly and Assembly for Multifunction Switch .....	88
CONSULT-II BASIC OPERATION PROCEDURE .....	55	DISASSEMBLY .....	88
DATA MONITOR .....	56	ASSEMBLY .....	88
ACTIVE TEST .....	57	<b>VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM .....</b>	<b>89</b>
On Board Diagnosis .....	57	System Description .....	89
DIAGNOSIS ITEM .....	57	INTEGRATED SWITCH SYSTEM .....	89
SWITCH MONITOR .....	57	PRECAUTION OF LCD MONITOR .....	89
Symptom Chart .....	58	POWER SUPPLY AND GROUND .....	89
Warning Chime Circuit Inspection .....	59	AV COMMUNICATION LINE .....	89
Front Door Switch (Driver Side) Inspection .....	60	VEHICLE INFORMATION SYSTEM .....	90
Key Switch Insert Signal Inspection .....	61	SETTING OF VEHICLE STATUS .....	92
Lighting Switch Input Signal Inspection .....	62	WARNING INDICATIONS .....	94
Seat Belt Buckle Switch Inspection .....	62	Precautions for AV Control Unit Replacement .....	95
Removal and Installation of Warning Chime .....	64	Component Parts and Harness Connector and Har-	
REMOVAL .....	64		
INSTALLATION .....	64		
<b>VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM WITH NAVIGATION SYSTEM... 65</b>			
System Description .....	65		
INTEGRATED SWITCH SYSTEM .....	65		
PRECAUTION OF LCD MONITOR .....	65		
POWER SUPPLY AND GROUND .....	65		

ness Connector Location .....	95	Multifunction Switch does Not Operate .....	132
Schematic .....	96	Multifunction Switch Indicator does not Illuminate	132
Wiring Diagram — INF/D — .....	97	Removal and Installation of AV Control Unit .....	133
Schematic .....	102	REMOVAL .....	133
Wiring Diagram — COMM — .....	103	INSTALLATION .....	133
Terminals and Reference Value for AV Control Unit	107	Removal and Installation of Display .....	133
Terminals and Reference Value for Display .....	110	REMOVAL .....	133
Terminals and Reference Value for Multifunction		INSTALLATION .....	133
Switch .....	111	Disassembly and Assembly of Multifunction Switch	134
On Board Self-Diagnosis Function (Without CON-		DISASSEMBLY .....	134
SULT-II) .....	112	ASSEMBLY .....	134
DESCRIPTION .....	112	<b>CLOCK</b> .....	<b>135</b>
DIAGNOSIS ITEM .....	112	Wiring Diagram — CLOCK — .....	135
Self-Diagnosis Mode .....	113	Removal and Installation .....	136
OPERATION PROCEDURE .....	113	REMOVAL .....	136
SELF-DIAGNOSIS RESULT .....	114	INSTALLATION .....	136
Confirmation/Adjustment Mode .....	115	<b>VOICE ACTIVATED CONTROL SYSTEM</b> .....	<b>137</b>
OPERATION PROCEDURE .....	115	System Description .....	137
DISPLAY DIAGNOSIS .....	116	OUTLINE .....	137
VEHICLE SIGNALS .....	116	VOICE ACTIVATED CONTROL FUNCTION ...	137
AUTO CLIMATE CONTROL .....	117	AV COMMUNICATION LINE .....	138
CONSULT-II Function .....	117	Schematic .....	139
CONSULT-IIBASICOPERATIONPROCEDURE		Wiring Diagram — VOICE — .....	140
..	117	Terminals and Reference Values for Voice Activated	
SELF-DIAG RESULTS .....	118	Control Module .....	145
DATA MONITOR .....	118	Component Parts and Harness Connector Location	146
VERSION .....	119	Trouble Diagnoses .....	147
Multifunction Switch Self-Diagnosis Function .....	119	THIS CONDITION IS NOT MALFUNCTION ....	147
STARTING THE SELF-DIAGNOSIS MODE .....	119	Self-Diagnosis Function .....	147
EXITING THE SELF-DIAGNOSIS MODE .....	119	DESCRIPTION .....	147
DIAGNOSIS FUNCTION .....	119	DIAGNOSIS ITEM .....	147
Power Supply and Ground Circuit Inspection for AV		Self-Diagnosis Mode .....	147
Control Unit .....	120	OPERATION PROCEDURE .....	147
Power Supply and Ground Circuit Inspection for Dis-		Confirmation/Adjustment Mode .....	148
play .....	121	OPERATION PROCEDURE .....	148
Inspection of Multifunction Switch for Power Supply		Power Supply and Ground Circuit Inspection .....	149
and Ground Circuit .....	122	Voice Command Not Identified (With Voice Acti-	
Vehicle Speed Signal Inspection .....	122	vated Control System in Operation) .....	150
Illumination Control Signal Inspection .....	123	No Guide Sound or Beeps .....	151
Ignition Signal Inspection .....	124	Voice Activated Control System Not Starting PTT	
RGB Screen is Not Shown .....	124	Switch Pushed ON .....	152
Color of RGB Image is Not Proper .....	125	Audio Not Muted with PTT Switch Pushed ON ...	154
RGB Screen is Rolling .....	127	Audio Mute Not Released .....	155
No A/C Display is Shown .....	128	Removal and Installation for Voice Activated Control	
A/C Operation is Not Possible .....	129	Module .....	156
No Fuel Information is Displayed/No Warning Mes-		REMOVAL .....	156
sage is Displayed .....	130	INSTALLATION .....	156
Vehicle Condition Setting is Not Possible .....	131		

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DI  
L  
M

# PRECAUTIONS

## PRECAUTIONS

PFP:00011

### Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

AKS004Z4

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

### Wiring Diagrams and Trouble Diagnosis

AKS004Z5

When you read wiring diagrams, refer to the following:

- Refer to [GI-14, "How to Read Wiring Diagrams"](#) in GI section
- Refer to [PG-2, "POWER SUPPLY ROUTING"](#) for power distribution circuit in PG section

When you perform trouble diagnosis, refer to the following:

- Refer to [GI-10, "HOW TO FOLLOW TEST GROUPS IN TROUBLE DIAGNOSES"](#) in GI section
- Refer to [GI-26, "How to Perform Efficient Diagnosis for an Electrical Incident"](#) in GI section


# PREPARATION

## PREPARATION

PFP:00002

### Commercial Service Tools

AKS003VD

Tool name	Description
<p>Power tool</p>  <p>PBIC0191E</p>	<p>Loosening bolts and nuts</p>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DI  
L  
M

DI

# COMBINATION METERS

## COMBINATION METERS

PFP:24814

### System Description


AKS002HM

#### UNIFIED CONTROL METER

- Speedometer, odo/trip meter, tachometer, fuel gauge and water temperature gauge are controlled totally by control unit built in combination meter.
- Digital meter is adopted for odo/trip meter.\*  
\*The record of the odo meter is kept even if the battery cable is disconnected. The record of the trip meter is erased when the battery cable is disconnected.
- Odo/trip meter, A/T indicator and ICC system display segments can be checked in self-diagnosis mode.
- Meter/gauge can be checked in self-diagnosis mode.

#### HOW TO CHANGE THE DISPLAY FOR ODO/TRIP METER

- The CAN communication signals (vehicle speed signal) from VDC/TCS/ABS control unit, and the memory signals from the meter memory circuit are processed by the combination meter, and the mileage is displayed.
- Operating the odo/trip meter switch allows switching the mode in the following order.



- The odometer/trip display switching and trip display resetting can be identified by the time from pressing the odometer/trip switch to releasing it.
- When resetting with trip A displayed, only trip A display is reset (same as trip B).

#### POWER SUPPLY AND GROUND CIRCUIT

Power is supplied at all times

- through 10A fuse [No. 6, located in the fuse block (J/B) No. 1]
- to combination meter terminal 39.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 9, located in the fuse block (J/B) No. 1]
- to combination meter terminals 40 and 42.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 21, located in the fuse block (J/B) No. 1]
- to combination meter terminal 28.

Ground is supplied

- to combination meter terminals 20 and 33
- through body grounds M24 and M114.

# COMBINATION METERS

## WATER TEMPERATURE GAUGE

The water temperature gauge indicates the engine coolant temperature. ECM provides an engine coolant temperature signal to combination meter for water temperature gauge with CAN communication line.

## TACHOMETER

The tachometer indicates engine speed in revolution per minutes (rpm). ECM provides a engine speed signal to combination meter for tachometer with CAN communication line.

## FUEL GAUGE

The fuel gauge indicates the approximate fuel level in the fuel tank. The fuel gauge is regulated by a variable resistor signal supplied

- to combination meter terminal 30 for the fuel level sensor
- from terminal 5 of the fuel level sensor unit
- through terminal 6 of the fuel level sensor unit and
- through combination meter terminal 31.

## SPEEDOMETER

VDC/TCS/ABS control unit provides a vehicle speed signal to the combination meter for the speedometer with CAN communication line.

## CAN Communication System Description

AKS002HN

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.


## CAN Communication Unit

AKS00A0J

Refer to [LAN-21, "CAN Communication Unit"](#) in "LAN SYSTEM".

## Component Parts and Harness Connector Location



AKS002HO



# COMBINATION METERS

AKS002HP

## Combination Meter CHECK



53	54	55	56	57	58	59	60	61	62	63	64
41	42	43	44	45	46	47	48	49	50	51	52

(M41)

(White)

21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20

(M42)

(White)

- (U) : For U.S.A
- (C) : For Canada
- (OI) : Without ICC
- (IC) : With ICC


SKIA9288E



# COMBINATION METERS

## Schematic

AKS002HR



IC : With ICC  
TW : With low tire pressure warning system

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DI  
L  
M









TKWA0578E

# COMBINATION METERS

AKS002HS

## Wiring Diagram — METER —


### DI-METER-01




REFER TO THE FOLLOWING.  
 (F105), (B211) -SUPER MULTIPLE JUNCTION (SMJ)  
 (M1) -FUSE BLOCK-JUNCTION BOX (J/B) NO.1  
 (E218), (F102) -ELECTRICAL UNITS

# COMBINATION METERS

## DI-METER-02



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DI  
L  
M





REFER TO THE FOLLOWING.  
**(B211)** -SUPER MULTIPLE JUNCTION (SMJ)

TKWA0580E

# COMBINATION METERS

## Terminals and Reference Value for Combination Meter

AKS002HU

Terminal No.	Wire color	Item	Measuring condition		Reference value (V)
			Ignition switch	Operation or condition	
20	B	Ground	ON	—	Approx. 0
28	L/OR	Ignition switch ACC or ON	ACC	—	Battery voltage
30	R/Y	Fuel level sensor signal	—	—	Refer to <a href="#">DI-19, "Electrical Components Inspection"</a> .
31	B/Y	Fuel level sensor ground	—	—	—
33	B	Ground	ON	—	Approx. 0
34	L	CAN H	—	—	—
35	R	CAN L	—	—	—
37	OR/L	Vehicle speed signal (8-pulse)	ON	Speedometer operated [When vehicle speed is approx. 40 km/h (25 MPH)]	 <p>ELF1084D</p>
38	PU/W	Vehicle speed signal (2-pulse)	ON	Speedometer operated [When vehicle speed is approx. 40 km/h (25 MPH)]	 <p>ELF1080D</p>
39	Y/G	Battery power source	OFF	—	Battery voltage
40	G	Ignition switch ON or START	ON	—	Battery voltage
42					

## Meter/Gauges Operation, Odo/Trip Meter, A/T Indicator and ICC System Display

AKS002HV

### SELF-DIAGNOSIS FUNCTION

- Odo/trip meter segment, A/T indicator segment and ICC system display can be checked in self-diagnosis mode.
- Meters/gauges can be checked in self-diagnoses mode.

### HOW TO ALTERNATE DIAGNOSIS MODE

1. Turn ignition switch ON, and switch the odo/ trip meter to "trip A" or "trip B".


#### NOTE:

If the diagnosis function is activated with the trip meter A displayed, the mileage on the trip meter A is reset to 0.0 km (same as the trip meter B display).

2. Turn ignition switch OFF.
3. While pushing the odo/trip meter switch, turn ignition switch ON again.
4. Check that the trip meter displays "0000.0".
5. Push the odo/trip meter switch at least 3 times. (Within 7 seconds after the ignition switch is turned ON.)

# COMBINATION METERS


6. All the segments on the odo/trip meter, A/T indicator and ICC system display illuminate, and simultaneously the low-fuel warning lamp indicator illuminate. At this time, the unified control meter is turned to diagnosis mode.



## NOTE:

If any of the segments is not displayed, replace combination meter.

7. Push the odo/trip meter switch. Indication of each meter/gauge should be as shown in the right during pushing odo/trip meter switch if there is no malfunctioning. (at this time, the low-fuel warning lamp goes off).



## How to Proceed with Trouble Diagnosis

1. Confirm the symptom or customer complaint.
2. Perform diagnosis according to diagnosis flow. Refer to [DI-13, "Diagnosis Flow"](#).
3. According to the trouble diagnosis chart, repair or replace the cause of the trouble symptom. Refer to [DI-15, "Trouble Diagnosis Chart by Symptom"](#).
4. Does the meter operate normally? If so, go to 5. If not, go to 2.
5. Inspection end.

## Diagnosis Flow

### 1. CHECK WARNING LAMP ILLUMINATION

Turn ignition switch ON.

Do warning lamps (such as malfunction indicator lamp and oil pressure warning lamp) illuminate?

YES >> GO TO 2.

NO >> Check ignition power supply system of combination meter. Refer to [DI-14, "Power Supply and Ground Circuit Inspection"](#).

### 2. CHECK SELF-DIAGNOSIS OPERATION

Perform combination meter self-diagnosis. Refer to [DI-12, "SELF-DIAGNOSIS FUNCTION"](#).

Does self-diagnosis function operate?

YES >> GO TO 3.

NO >> Check battery power supply of combination meter and ground system. Refer to [DI-14, "Power Supply and Ground Circuit Inspection"](#).


# COMBINATION METERS

## 3. CHECK ODO/TRIP METER OPERATION

Check segment display status of odo/trip meter. Refer to [DI-12](#), "[SELF-DIAGNOSIS FUNCTION](#)".

Is the display normal?

- YES >> GO TO 4.
- NO >> Replace combination meter.



## 4. CHECK FUEL WARNING LAMP ILLUMINATION CONFIRMATION

During fuel warning lamp check, confirm illumination of fuel warning lamp.

Condition of odo/trip meter switch	Fuel warning lamp
Pushed	Does not illuminate.
Released	Illuminates.

OK or NG


- OK >> GO TO 5.
- NG >> Replace combination meter.

## 5. CHECK COMBINATION METER CIRCUIT

Check indication of each meter/gauge in self-diagnosis mode. Refer to [DI-12](#), "[SELF-DIAGNOSIS FUNCTION](#)".

OK or NG

- OK >> Go to diagnosis results. Refer to [DI-15](#), "[DIAGNOSIS RESULTS](#)".
- NG >> Replace combination meter.



## Power Supply and Ground Circuit Inspection

### 1. CHECK FUSES

Check that any of the fuses in combination meter is blown.

Unit	Power source	Fuse No.
Combination meter	Battery	6
	Ignition switch ON or START	9
	Ignition switch ACC or ON	21

OK or NG


- OK >> GO TO 2.
- NG >> If fuse is blown, be sure to eliminate cause of problem before installing new fuse. Refer to [PG-2](#), "[POWER SUPPLY ROUTING](#)".

# COMBINATION METERS

## 2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect combination meter connector.
2. Check voltage between combination meter harness connector terminals and ground.

Terminals		(-)	Ignition switch position		
(+)	Connector		Terminal (Wire color)	OFF	ACC
M41	28 (L/OR)	Ground	0V	Battery voltage	Battery voltage
	39 (Y/G)		Battery voltage	Battery voltage	Battery voltage
	40 (G)		0V	0V	Battery voltage
M42	42 (G)				Battery voltage



OK or NG

OK >> GO TO 3.

NG >> Check harness for open or short between combination meter and fuse.

## 3. CHECK GROUND CIRCUIT


1. Turn ignition switch OFF.
2. Check continuity between combination meter harness connector M41 terminals 20 (B), 33 (B) and ground.

**Continuity should exist.**

OK or NG

OK >> Inspection end.

NG >> Repair harness or connector.



## Trouble Diagnosis Chart by Symptom

### DIAGNOSIS RESULTS

Trouble phenomenon	Possible cause
Tachometer indication is malfunction.	Refer to <a href="#">DI-16, "Engine Speed Signal Inspection"</a> .
Water temperature gauge indication is malfunction.	Refer to <a href="#">DI-16, "Water Temperature Signal Inspection"</a> .
Indication is irregular for the speedometer and odo/trip meter.	Refer to <a href="#">DI-16, "Vehicle Speed Signal Inspection"</a> .
Fuel gauge indication is malfunction.	Refer to <a href="#">DI-16, "Fuel Level Sensor Signal Inspection"</a> .
Fuel warning lamp indication is irregular.	
Indications are irregular for more than one gauge.	Replace combination meter.
A/T position indicator is malfunction.	Refer to <a href="#">DI-45, "A/T Indicator Does Not Illuminate"</a> .
ICC system display does not illuminate.	Refer to <a href="#">ACS-58, "TROUBLE DIAGNOSIS — GENERAL DESCRIPTION"</a> .

# COMBINATION METERS

---

## Engine Speed Signal Inspection

AKS002VI

### 1. CHECK ECM SELF-DIAGNOSIS

---

Perform ECM self-diagnosis. Refer to [EC-108, "CONSULT-II Function \(ENGINE\)"](#) .

OK or NG

- OK >> Replace combination meter.
- NG >> Perform "Diagnostic procedure" displayed DTC.

## Water Temperature Signal Inspection

AKS002VJ

### 1. CHECK ECM SELF-DIAGNOSIS

---

Perform the ECM self-diagnosis. Refer to [EC-108, "CONSULT-II Function \(ENGINE\)"](#) .

OK or NG

- OK >> Replace combination meter.
- NG >> Perform "Diagnostic procedure" displayed DTC.

## Vehicle Speed Signal Inspection

AKS002VK

### 1. CHECK VDC/TCS/ABS CONTROL UNIT SELF-DIAGNOSIS

---

Perform VDC/TCS/ABS control unit self-diagnosis. Refer to [AT-89, "CONSULT-II"](#) .

OK or NG

- OK >> Replace combination meter.
- NG >> Perform "Diagnostic procedure" displayed self-diagnosis results.

## Fuel Level Sensor Signal Inspection

AKS002I3

### FUEL LEVEL SENSOR UNIT

The following symptoms do not indicate a malfunction.

- Depending on vehicle posture or driving circumstance, the fuel level in the tank varies, and the pointer may fluctuate.
- If the vehicle is fueled with the ignition switch ON, the pointer will move slowly.
- If vehicle is tilted when the ignition switch is turned ON, fuel in the tank may flow to one direction resulting in a change in the reading.

### LOW-FUEL WARNING LAMP

Depending on vehicle posture or driving circumstance, the fuel level in the tank varies, and the warning lamp ON timing may be changed.

### 1. CHECK HARNESS CONNECTOR

---

Check combination meter, fuel level sensor unit and terminals (meter-side, module-side, lead-side, and harness-side) for poor connection and bend.

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.



# COMBINATION METERS


## 2. CHECK HARNESS CONNECTOR OUTPUT SIGNAL

1. Disconnect fuel level sensor connector.
2. Turn ignition switch ON.
3. Check voltage between combination meter harness connector M41 terminal 30 (R/Y) and ground.

**Approx. 5V**

OK or NG

- OK >> GO TO 3.  
NG >> Replace combination meter.



## 3. CHECK HARNESS FOR OPEN OR SHORT CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector.
3. Check continuity between combination meter harness connector M41 terminal 30 (R/Y) and fuel level sensor unit harness connector B51 terminal 5 (R/Y).


**Continuity should exist.**

4. Check continuity between combination meter harness connector M41 terminal 30 (R/Y) and ground.

**Continuity should not exist.**

OK or NG

- OK >> GO TO 4.  
NG >> Repair harness or connector.



## 4. CHECK FUEL LEVEL SENSOR GROUND CIRCUIT

1. Check continuity between combination meter harness connector M41 terminal 31 (B/Y) and fuel level sensor unit harness connector B51 terminal 6 (B).


**Continuity should exist.**

2. Check continuity between combination meter harness connector M41 terminal 31 (B/Y) and ground.

**Continuity should not exist.**

OK or NG

- OK >> GO TO 5.  
NG >> Repair harness or connector.



## 5. CHECK FUEL LEVEL SENSOR UNIT

Check components. Refer to [DI-19, "CHECK FUEL LEVEL SENSOR UNIT"](#).

OK or NG

- OK >> GO TO 6.  
NG >> Replace fuel level sensor unit.

# COMBINATION METERS

---

## 6. CHECK INSTALLATION CONDITION

---

Check fuel level sensor unit installation, and check whether the float arm interferes or binds with any components inside the arm.

OK or NG

- OK >> Replace combination meter.
- NG >> Install fuel level sensor unit properly.

### Fuel Gauge Pointer Fluctuates-Indicator Wrong Value or Varies

AKS00214

#### 1. CHECK FUEL GAUGE POINTER FOR FLUCTUATION

---

Does the indication value fluctuate during driving or before/after stop?

Does the indication value vary?

- YES >> The pointer fluctuation may be caused by fuel level change in the fuel tank.
- NO >> Ask the customer about the situation when the symptom occurs in detail, and Preform the trouble diagnosis.

### Fuel Gauge Does Not Move to FULL Position

AKS00215

#### 1. QUESTION 1

---

Does it take a long time for the pointer to move to FULL position?

YES or NO

- YES >> GO TO 2.
- NO >> GO TO 3.

#### 2. QUESTION 2

---

Was the vehicle fueled with the ignition switch ON?

YES or NO

- YES >> Be sure to fuel the vehicle with the ignition switch OFF. Otherwise it will take a long time to move to FULL position because of the characteristic of the fuel gauge.
- NO >> GO TO 3.

#### 3. QUESTION 3

---

Is the floor or the vehicle inclined?

YES or NO

- YES >> It may not be filled fully.
- NO >> GO TO 4.

#### 4. QUESTION 4

---

During driving, does the fuel gauge pointer move gradually toward EMPTY position?

YES or NO

- YES >> Check the components. Refer to [DI-16, "FUEL LEVEL SENSOR UNIT"](#).
- NO >> The float arm may interfere or bind with any of the components in the fuel tank.


# COMBINATION METERS

## Electrical Components Inspection CHECK FUEL LEVEL SENSOR UNIT

AKS002I9

- For removal, refer to [FL-3, "FUEL LEVEL SENSOR UNIT, FUEL FILTER AND FUEL PUMP ASSEMBLY"](#)
- Check the resistance between terminals 5 and 6.


Terminal		Float position mm (in)		Resistance value $\Omega$
5	6	Full (3)	Approx. 82.7 (3.3)	Approx. 4.5 - 5.5
		1/2 (2)	Approx. 200.3 (7.9)	Approx. 31.5 - 35.5
		Empty (1)	Approx. 325.0 (12.8)	Approx. 80.0 - 83.0




## Removal and Installation of Combination Meter REMOVAL

AKS002IA

1. Remove cluster lid A. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#).
2. Remove screws (3) with power tool, and disconnect connectors.



3. While pulling combination meter upper-side forward, pull it out.  
**CAUTION:**  
To prevent it from being damaged by interference with the meter bracket, protect the meter with cloth.




## INSTALLATION

Install in the reverse order of removal.

# COMBINATION METERS

## Disassembly and Assembly of Combination Meter

AKS002/B



1. Front cover
4. Meter cover

2. Upper housing

3. Unified meter control unit assembly

### DISASSEMBLY

1. Disengage tabs (8) to separate meter cover.
2. Disengage tabs (8) to separate upper housing.
3. Disengage tabs (8) to separate front cover.

### ASSEMBLY

Assemble in reverse order of disassembly.

# COMPASS


## COMPASS

PFP:24835

### System Description

AKS003ZP

This unit displays earth magnetism and heading direction of vehicle.



### DIRECTION DISPLAY

Push the switch when the ignition key is in the "ON" or "START" position. The direction will be displayed. Pushing the "COMP" switch a second time will turn off the display.

1. If the display reads "C" calibrate the compass by driving the vehicle in 3 complete circles at less than 8km/h (5MPH).
2. To adjust for Compass Variance:
  - a. Press the "COMP" switch for more than 3 seconds. The current zone number will appear in the display.
  - b. Find your current location and variance zone number on the zone map.
  - c. Press the "COMP" switch until the new zone number appears in the display. After you stop pressing the button in, the display will show a compass direction within a few seconds.


#### NOTE:

1. Do not install the ski rack, antenna, etc. which are attached to the vehicle by means of a magnet. They affect the operation of the compass.
  2. If the compass deviates from the correct indication soon after repeated adjustment, have the compass checked at an authorized dealer.
  3. The compass may not indicate the correct compass point in tunnels or while driving up or down a steep hill. (The compass returns to the correct compass point when the vehicle moves to an area where the geomagnetism is stabilized.)
3. **Cleaning the Mirror**  
When cleaning the mirror, use a paper towel or similar material dampened with glass cleaner. Do not spray glass cleaner directly on the mirror as that may cause the liquid cleaner to enter the mirror housing.

# COMPASS

## “C” is Displayed in the Compass Window

The compass needs to be calibrated. Drive the vehicle in 3 circles at 8km/h (5MPH) or less until the display reads a direction. You can also calibrate the compass by driving your vehicle on your everyday routine. The compass will be calibrated once it has tracked 3 complete circles.



## Inaccurate Compass Direction



1. With the display turned on, push the “COMP” switch for 3 seconds, until the Zone selection comes up (a number will be displayed in the mirror compass window).
2. Toggle until correct zone is found and release switch.
3. The display will show all segments, and return to the normal compass mode within 10 seconds of no switch activity.
4. If the vehicle changes zone, repeat steps 1 through 3. See map.

# COMPASS

## Wiring Diagram – COMPAS –

AKS003LW

DI-COMPAS-01



REFER TO THE FOLLOWING.  
 (E201), (R1) - FUSE BLOCK-  
 JUNCTION BOX (J/B) NO.1

TKWA0619E

---

## Removal and Installation of Compass

AKS0040J

Refer to [GW-59, "Removal and Installation"](#) .



## WARNING LAMPS

PFP:24814

### System Description OUTLINE

AKS002IC

Power is supplied at all times

- through 10A fuse [No. 6, located in the fuse block (J/B) No. 1]
- to combination meter terminal 39.

With ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 9, located in the fuse block (J/B) No. 1]
- to combination meter terminals 40 and 42.

Ground is supplied

- to combination meter terminals 20 and 33
- through body grounds M24 and M114
- to seat belt buckle switch terminal 15A (with automatic drive positioner) or 14 (without automatic drive positioner)
- through body grounds B17 and B57
- to brake fluid level switch terminal 2 and
- to washer level switch terminal 2
- through body grounds E42 and E62.

### AIR BAG WARNING LAMP

During probe out or when an air bag malfunction occurs, the ground path is interrupted

- from the air bag diagnosis sensor unit terminal 15
- to combination meter terminal 5.

Ground is supplied

- to combination meter terminal 45
- through body grounds M24 and M114.

When power and ground are supplied, the air bag warning lamp (LEDs) illuminates.

For further information, refer to [SRS-8, "TROUBLE DIAGNOSIS"](#).

### DOOR WARNING LAMP

Door warning lamp is controlled by BCM.

When one of the doors is opened, ground is supplied to the BCM terminals 33, 37, 142 and 143.

And then ground is supplied

- to combination meter terminal 3
- from BCM terminal 111.

When power and ground are supplied, the door warning lamp illuminates.

### LOW OIL PRESSURE WARNING LAMP

Low oil pressure causes oil pressure switch terminal 1 to provide ground to combination meter terminal 63.

When power and ground are supplied, the low oil pressure warning lamp illuminates.

### CHARGE WARNING LAMP

During prove out or when a alternator malfunction occurs, ground is supplied

- to combination meter terminal 64
- from alternator terminal 3.

When power and ground are supplied, the charge warning lamp and brake lamp illuminate.

### LOW WASHER LEVEL WARNING LAMP

When the washer fluid level is low, ground is supplied

- to combination meter terminal 16
- from washer level switch terminal 1.

When power and ground are supplied, the signal is sent

- from combination meter terminals 56 and 57

A

B

C

D

E

F

G

H

I

J

DI

L

M

# WARNING LAMPS

---

- through AV and NAVI control unit terminals 32 and 33 or AV control unit terminals 34 and 35
- to display.

Then warning lamp message appears display.

## **A/T CHECK WARNING LAMP**

When an A/T system malfunction occurs, signal sent

- to combination meter terminals 34 and 35
- from TCM (transmission control module) with CAN communication line.

When signal is received, the AT oil temp warning lamp blinks or illuminates.

For further information, refer to [AT-256, "A/T CHECK Indicator Lamp Does Not Come On"](#) .

## **LOW FUEL LEVEL WARNING LAMP**

The amount of fuel in the fuel tank is determined by the fuel level sensor in the fuel tank. Fuel level signal is sent

- from combination meter terminal 31
- through fuel level sensor unit terminals 6 and 5
- to combination meter terminal 30.

The fuel level sensor will illuminate the low fuel level warning lamp when the fuel level is low.

When power and ground are supplied, the low fuel level warning lamp illuminates.

## **ABS WARNING LAMP**

When an ABS malfunction occurs, ground is supplied

- to combination meter terminal 6
- from VDC/TCS/ABS control unit terminal 30.

When power and ground is supplied, the ABS warning lamp illuminates.

For further information, refer to [BRC-37, "BASIC INSPECTION 3 ABS WARNING LAMP, VDC OFF LAMP, SLIP LAMP INSPECTION"](#) .

## **VDC OFF WARNING LAMP**

When VDC OFF switch is in OFF position, or an VDC/TCS/ABS malfunction occurs, ground is supplied

- to combination meter terminal 51
- from VDC/TCS/ABS control unit terminal 31.

When power and ground are supplied, the VDC OFF warning lamp illuminates.

For further information, refer to [BRC-37, "BASIC INSPECTION 3 ABS WARNING LAMP, VDC OFF LAMP, SLIP LAMP INSPECTION"](#) .

## **SLIP WARNING LAMP**

When VDC is in operation, or a VDC malfunction occurs, ground is supplied

- to combination meter terminal 11
- from VDC/TCS/ABS control unit terminal 83.

When power and ground are supplied, the slip warning lamp illuminates.

For further information, refer to [BRC-37, "BASIC INSPECTION 3 ABS WARNING LAMP, VDC OFF LAMP, SLIP LAMP INSPECTION"](#) .

## **SEAT BELT WARNING LAMP**

When the driver's seat belt is unfastened, ground is supplied

- to combination meter terminal 8
- from seat belt buckle switch terminal 41.

When power and ground are supplied, the seat belt warning lamp illuminates.

## **BRAKE WARNING LAMP**

When the parking brake is applied, or the brake fluid level is low, ground is supplied

- to combination meter terminal 22
- from parking brake switch terminal 1, or
- to combination meter terminal 21
- brake fluid level switch terminal 1.

# WARNING LAMPS

When power and ground are supplied, the brake warning lamp illuminates.

## **MALFUNCTION INDICATOR LAMP**

During prove out or when an engine control malfunction occurs, ground is supplied

- to combination meter terminal 52
- from ECM terminal 35.

When power and ground are supplied, the malfunction indicator lamp illuminates.

For further information, refer to [EC-413, "DTC P0650 MIL"](#) .

## **LOW TIRE PRESSURE WARNING LAMP**

When a low tire pressure warning control malfunction occurs, ground is supplied

- to combination meter terminal 7
- from low tire pressure warning control unit terminal 3.

When power and ground are supplied, the tire pressure warning lamp illuminates.

For further information, refer to [WT-23, "TROUBLE DIAGNOSIS FOR SYMPTOMS"](#) .

## **ASCD WARNING LAMP**

When an ASCD malfunction occurs, ground is supplied

- to combination meter terminal 61
- from ASCD control unit terminal 18.

When power and ground are supplied, the ASCD warning lamp illuminates.

## **ICC SYSTEM WARNING LAMP**

When an ICC system malfunction occurs, ground is supplied

- to combination meter terminal 53
- from ICC unit terminal 25.

When power and ground are supplied, the ICC system warning lamp illuminates.

## **WARNING MESSAGE ON DISPLAY**

When a warning lamp illuminates or flushes, signal is sent

- from combination meter terminals 56 and 57
- through AV and NAVI control unit terminals 32 and 33 or AV control unit terminals 34 and 35
- to display.

Then warning message appears on display.

A

B

C

D

E

F

G

H

I

J

DI


L

M

# WARNING LAMPS

AKS0021D

## Schematic



TKWA0583E





# WARNING LAMPS

## Wiring Diagram — WARN —

AKS0021E

### DI-WARN-01

⊠IC⊠ : WITH ICC



REFER TO THE FOLLOWING.



(M1) - FUSE BLOCK-JUNCTION BOX (J/B) NO.1

(M4) - ELECTRICAL UNITS


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DI  
L  
M

# WARNING LAMPS


DI-WARN-02



(B20), (B220)  
W W



(B21), (B271)  
W W



(D62), (D82)  
B B

REFER TO THE FOLLOWING.




(M5), (B211) -SUPER MULTIPLE JUNCTION (SMJ)

(M4), (B4) -ELECTRICAL UNITS




TKWA0585E

# WARNING LAMPS

DI-WARN-03




\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.



REFER TO THE FOLLOWING.

(M5), (F105) -SUPER MULTIPLE JUNCTION (SMJ)  
(E218), (F101) -ELECTRICAL UNITS





TKWA0586E

# WARNING LAMPS

## DI-WARN-04

IC : WITH ICC  
TW : WITH LOW TIRE PRESSURE WARNING SYSTEM



REFER TO THE FOLLOWING.

E218 -ELECTRICAL UNITS

TKWA0587E








# WARNING LAMPS

## DI-WARN-05

IC : WITH ICC

OI : WITHOUT ICC



REFER TO THE FOLLOWING.


(E205), (B211) -SUPER MULTIPLE JUNCTION (SMJ)

TKWA0588E

# WARNING LAMPS



DI-WARN-06

IC : WITH ICC



1 M8  
B

REFER TO THE FOLLOWING.  
E205, F105 -SUPER MULTIPLE  
JUNCTION (SMJ)





TKWA0589E

# WARNING LAMPS

DI-WARN-07

▬ : DATA LINE  
 IC : WITH ICC




REFER TO THE FOLLOWING.  
 B211 -SUPER MULTIPLE JUNCTION (SMJ)

TKWA0590E

# WARNING LAMPS

DI-WARN-08



1	2	3	4	5	6	7	8	9	10	11		
12	13	14	15	16	17	18	19	20	21	22	23	24

(M7)  
W

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

(M41)  
W

41	42	43	44	45	46	47	48	49	50	51	52
53	54	55	56	57	58	59	60	61	62	63	64

(M42)  
W

1	1	2	2	3	3	3	3
4	4	4	4	4	5	5	5

(M46)  
B

48	45	42	39	37	35	33	30	27
47	44	41	38	36	34	32	29	26
46	43	40				31	28	25

(M77), (B29)  
GY GY

1	2
---	---

(E47)  
BR

REFER TO THE FOLLOWING.  
(E205) -SUPER MULTIPLE JUNCTION (SMJ)

TKWA0591E

# WARNING LAMPS

## Terminals and Reference Value for BCM

AKS002IF

Terminal No.	Wire color	Item	Measuring condition		Reference value (V)
			Ignition switch	Operation or condition	
33	W	Door lock assembly rear LH (door switch)	OFF	Door open (Door switch ON)	Approx. 0
				Door closed (Door switch OFF)	Approx. 12
37	LG	Front door switch (passenger side)	OFF	Door open (Door switch ON)	Approx. 0
				Door closed (Door switch OFF)	Approx. 12
111	P/B	Door warning lamp	OFF	Door open (Door switch ON)	Approx. 0
				Door closed (Door switch OFF)	Approx. 12
142	R/Y	Front door switch (driver side)	OFF	Door open (Door switch ON)	Approx. 0
				Door closed (Door switch OFF)	Approx. 12
143	W/L	Door lock assembly rear RH (door switch)	OFF	Door open (Door switch ON)	Approx. 0
				Door closed (Door switch OFF)	Approx. 12

## Work Flow

AKS002IG

1. Check the symptom and customer's requests.
2. Understand the outline of system. Refer to [DI-25, "System Description"](#).
3. Perform the preliminary inspection. Refer to [DI-54, "Preliminary Inspection"](#).
4. Referring to Trouble diagnosis chart, repair or replace the cause of the incident. Refer to [DI-40, "Trouble Diagnosis for Door Warning Lamp"](#).
5. Does warning chime system operate normally? If so, go to 5. If not, go to 2.
6. Inspection end.

## Preliminary Inspection

AKS002IH

Perform preliminary check, refer to [DI-54, "Preliminary Inspection"](#).

## CONSULT-II Function

AKS002II


CONSULT-II executes the following functions by combining data reception and command transmission via the communication line from BCM. IVMS communication inspection, work support (only function setting of seats and steering wheel), self-diagnosis, data monitor, and active test display.

## DIAGNOSTIC ITEMS DESCRIPTION

IVMS diagnosis position	Diagnosis mode	Description
DOOR OPEN WARNING	Data monitor	The input data to the BCM control unit is displayed in real time.
	Active test	Operation of electrical loads can be checked by sending driving signal to them.
BCM PART NUMBER		Displays BCM part No.


## CONSULT-II BASIC OPERATION PROCEDURE

1. With the ignition switch OFF, connect "CONSULT-II" and "CONSULT-II CONVERTER" to the data link connector, and turn the ignition switch ON.




# WARNING LAMPS


2. Touch "START (NISSAN BASED VHCL)".



3. Touch "IVMS" on "SELECT SYSTEM" screen.  
If "IVMS" is not indicated, go to [GI-38, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



4. Check the model specification, touch either "WITH SUNROOF" or "WITHOUT SUNROOF".  
5. Touch "OK". If the selection is wrong, touch "CANCEL".



6. Select the desired part to be diagnosed on the "SELECT TEST ITEM" screen.

## DATA MONITOR

### Operation Procedure

1. Touch "DOOR OPEN WARNING" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
3. Touch "MAIN SIGNALS" or "SELECTION FROM MENU" on "DATA MONITOR" screen.

MAIN SIGNALS	Monitors the main items.
SELECTION FROM MENU	Selects and monitors the items.

4. If "SELECTION FROM MENU" is selected, touch the desired monitor item. If "MAIN SIGNALS" is selected, the main item required to control is monitored.
5. Touch "START".
6. During monitoring, touching "COPY" can start recording the monitor item status.

### Data Monitor Item

Monitored item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch (driver side).
DOOR SW-AS	Indicates [ON/OFF] condition of front door switch (passenger side).

# WARNING LAMPS

Monitored item	Description
DOOR SW-RL	Indicates [ON/OFF] condition of door lock assembly rear LH (door switch).
DOOR SW-RR	Indicates [ON/OFF] condition of door lock assembly rear RH (door switch).

## ACTIVE TEST

### Operation Procedure

1. Touch "DOOR OPEN WARNING" on "SELECT TEST ITEM" screen.
2. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
3. Touch the item to be tested, and check the operation.
4. During the operation check, touching "OFF" deactivates the operation.

### Active Test Item

Test item.	Malfunction detecting condition
DR OPN WARN LAMP	This test is able to check door warning lamp operation. Door warning lamp indicate when touch "ON" on CONSULT-II screen.

## On Board Diagnosis

AKS002J


### ON BOARD DIAGNOSTIC RESULTS INDICATOR LAMP

- Map lamps and step lamps (all seats) act as the indicators for the on board diagnosis.

## SWITCH MONITOR

Perform the diagnosis on the switch system to each control unit.


### How to Perform Switch Monitor



# WARNING LAMPS

## Description

In this mode, when BCM detects the input signal from a switch in IVMS as shown below, the detection is indicated by the map lamp and front step lamps with buzzer.



## Switch Monitor Item

The status of the switch (except the ignition switch, interior lamp switch, and map lamp switch) as input to each control unit can be monitored.

BCM	Front door switch (driver side)
	Front door switch (passenger side)
	Door lock assembly rear LH (door switch)
	Door lock assembly rear RH (door switch)

## Cancel of Switch Monitor

- Turn ignition switch OFF.
- Drive the vehicle at more than 7km/h (4MPH).

## DIAGNOSIS ITEM

Diagnosis item	Description
Switch monitor	Monitoring conditions of switches connected to BCM.

## Trouble Diagnosis for Door Warning Lamp

AKS002IK

Symptom	Diagnostic procedure and repair order
Door warning lamp does not illuminate with any of doors are open.	<ul style="list-style-type: none"> <li>● Check combination meter circuit. Refer to <a href="#">DI-40, "Inspection/Combination Meter Circuit"</a>.</li> <li>● Check front door switch. Refer to <a href="#">DI-41, "Inspection/Front Door Switch"</a>.</li> <li>● Check door lock assembly rear (door switch). Refer to <a href="#">DI-42, "Inspection/Rear Door Switch"</a>.</li> </ul>
Door warning lamp illuminates constantly.	If the above systems work properly, replace the BCM.

## Inspection/Combination Meter Circuit

AKS002IL

### 1. CHECK DOOR WARNING LAMP INPUT SIGNAL

1. Disconnect BCM connector and combination meter connector.
2. Check continuity between BCM harness connector M4 terminal 111 (P/B) and combination meter harness connector M41 terminal 3 (P/B).


**Continuity should exist.**

3. Check continuity between BCM harness connector M4 terminal 111 (P/B) and ground.

**Continuity should not exist.**

OK or NG

- OK >> GO TO 2.
- NG >> Repair harness or connector.





# WARNING LAMPS


## 2. CHECK DOOR WARNING LAMP

1. Connect combination meter connector.
2. Turn ignition switch ON.
3. Check voltage between BCM harness connector M4 terminal 111 (P/B) and ground.

**Approx. 12V**

OK or NG

- OK >> Combination meter is OK.  
 NG >> Replace combination meter.



## Inspection/Front Door Switch

### 1. CHECK FRONT DOOR SWITCH OPERATION

**With CONSULT-II**

See "DOOR SW" in "DATA MONITOR" mode.

**When door is opened : ON**

**When door is closed : OFF**

**Without CONSULT-II**

Check front door switches in "SWITCH MONITOR" mode. Refer to [DI-39, "On Board Diagnosis"](#).

OK or NG

- OK >> Front door switch is OK.  
 NG >> GO TO 2.

DATA MONITOR	
MONITOR	
DOOR SW-DR	OFF
DOOR SW-AS	OFF
DOOR SW-RR	OFF
DOOR SW-RL	OFF
RECORD	

SEL498W

### 2. CHECK FRONT DOOR SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector and front door switches connector.
3. Check the following.

- Continuity between BCM harness connector B4 terminal 142 (R/Y) and front door switch (driver side) harness connector B20 terminal 1 (R/Y)

**Continuity should exist.**

- Continuity between BCM harness connector M4 terminals 37 (LG) and front door switch (passenger side) harness connector B220 terminal 1 (LG)


**Continuity should exist.**

4. Check continuity between BCM harness connector M4, B4 terminals 37 (LG), 142 (R/Y) and ground.

**Continuity should not exist.**

OK or NG

- OK >> GO TO 3.  
 NG >> Repair harness or connector.



# WARNING LAMPS

## 3. CHECK FRONT DOOR SWITCH (DRIVER SIDE OR PASSENGER SIDE)


Check front door switch.

**When front door switch is released : Continuity should exist.**

**When front door switch is pushed : Continuity should not exist.**

OK or NG

- OK >> Front door switch is OK.
- NG >> Replace front door switch.



## Inspection/Rear Door Switch

### 1. CHECK REAR DOOR SWITCH OPERATION

**With CONSULT-II**

See "DOOR SW" in "DATA MONITOR" mode.

**When door is opened : ON**

**When door is closed : OFF**

**Without CONSULT-II**

Check rear doors switches in "SWITCH MONITOR" mode. Refer to [DI-39. "On Board Diagnosis"](#).

OK or NG

- OK >> Door lock assembly rear (door switch) is OK.
- NG >> GO TO 2.

DATA MONITOR	
MONITOR	
DOOR SW-DR	OFF
DOOR SW-AS	OFF
DOOR SW-RR	OFF
DOOR SW-RL	OFF
RECORD	

### 2. CHECK REAR DOOR SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect BCM connector and door lock assembly rear (door switch) connector.
3. Check the following.

- Continuity between BCM harness connector B4 terminal 143 (W/L) and door lock assembly rear RH (door switch) harness connector D82 terminal 1 (W)

**Continuity should exist.**

- Continuity between BCM harness connector M4 terminal 33 (W) and door lock assembly rear LH (door switch) harness connector D62 terminal 1 (W)


**Continuity should exist.**

4. Check continuity between BCM harness connector M4, B4 terminal 33 (W), 143 (W/L) and ground.

**Continuity should not exist.**

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness or connector.



# WARNING LAMPS

## 3. CHECK REAR DOOR SWITCH

Check continuity between door lock assembly rear (door switch) harness connector D62(LH) or D82(RH) terminals 1 and 2.


**When rear door is opened : Continuity should exist.**

**When rear door is closed : Continuity should not exist.**

OK or NG

OK >> GO TO 4.

NG >> Replace door lock assembly rear (door switch) LH or RH.



## 4. CHECK REAR DOOR SWITCH GROUND CIRCUIT


Check continuity between door lock assembly rear (door switch) connector D62 (LH) or D82 (RH) terminal 2 (B) and ground.

**Continuity should exist.**

OK or NG

OK >> Door lock assembly rear (door switch) is OK.


NG >> Repair harness or connector.



## Electrical Components Inspection OIL PRESSURE SWITCH

Check continuity between the oil pressure switch and ground.

Condition	Oil pressure kPa (kg/cm <sup>2</sup> , psi)	Continuity
Engine stopped	Less than 29 (0.3, 4)	Yes
Engine running	More than 29 (0.3, 4)	No



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DI  
L  
M

# A/T INDICATOR



PFP:24814

## A/T INDICATOR

### Wiring Diagram — AT/IND —

AKS002IP

## DI-AT/IND-01



REFER TO THE FOLLOWING.

- (F105) -SUPER MULTIPLE JUNCTION (SMJ)
- (M1) -FUSE BLOCK-JUNCTION BOX (J/B) NO.1

TKWA1651E

# A/T INDICATOR

---

## A/T Indicator Does Not Illuminate

AKS002IR

### 1. CHECK COMBINATION METER SELF-DIAGNOSIS

---

Perform combination meter self-diagnosis mode. Refer to [DI-12, "Meter/Gauges Operation, Odo/Trip Meter, A/T Indicator and ICC System Display"](#).

**If it check from combination meter trouble diagnosis, go to next step.**

OK or NG

OK >> A/T indicator is OK.

NG >> Replace combination meter.

### 2. CHECK TCM CONTROL UNIT SYSTEM

---

Perform TCM self-diagnosis. Refer to [AT-89, "CONSULT-II"](#) in AT section.

OK or NG

OK >> Replace combination meter.

NG >> Perform "Diagnosis Procedure" displayed self-diagnosis results.

A

B

C

D

E

F

G

H

I

J

DI

L

M

# WARNING CHIME

## WARNING CHIME

PFP:24814

### System Description FUNCTION

AKS002IS

Item	Description
Ignition key warning chime	Sounds warning chime when driver's door is opened with key in ignition key cylinder and ignition switch "OFF" or "ACC" position.
Light warning chime	Sounds warning chime when driver's door is opened with lighting switch in the 1st or 2nd position and ignition switch "OFF" or "ACC" position.
Seat belt warning chime	Sounds warning chime for about 6 seconds if ignition switch is turned "ON" when driver's seat belt is unfastened.

Power is supplied at all times

- through 10A fuse [No. 3, located in the fuse block (J/B) No. 1]
- to BCM terminal 105
- through 10A fuse [No. 32, located in the fuse block (J/B) No. 2]
- to key switch and key lock solenoid (key switch) terminal 3
- through 10A fuse [No. 6, located in the fuse block (J/B) No. 1]
- to headlamp battery saver control unit terminal 7 and
- to warning chime terminal 1
- through 15A fuse [No. 54, located in the fuse, fusible link and relay block (J/B)]
- to tail lamp relay terminals 2 and 6 [located in fuse, fusible link and relay block (J/B)].

With ignition switch in ON or START position, power is supplied

- through 10A fuse [No. 1, located in the fuse block (J/B) NO. 1]
- to BCM terminal 68 and
- to headlamp battery saver control unit terminal 1.

Ground is supplied

- to BCM terminals 56 and 113
- through body grounds M24 and M114.

When a signal, or combination of signals, is received by the BCM, the warning chime will sound.

### IGNITION KEY WARNING CHIME

With the key in the ignition key cylinder, power is supplied

- through key switch and key lock solenoid (key switch) terminal 4
- to BCM terminal 69.

When front door switch (driver side) is open, ground is supplied

- to BCM terminal 142
- through front door (driver side) switch terminal 1.

Front door switch (driver side) is case ground.

With ignition switch in OFF or ACC position, and the driver's door open, ground is supplied

- to warning chime terminal 3
- from BCM terminal 12.

The warning chime will sound.

### LIGHT WARNING CHIME

When lighting switch is in the 1st or 2nd position, ground is supplied

- to tail lamp relay terminal 1
- through battery saver control unit terminals 6 and 14,
- to battery saver control unit terminals 5 and 13
- through combination switch terminal 11 and
- to combination switch terminal 5
- through body grounds M25 and M115.

# WARNING CHIME

When tail lamp relay is energied, power is supplied

- through tail lamp relay terminal 7 [located in fuse, fusible link and relay block (J/B)]
- to BCM terminal 3.

When front door switch (driver side) is open, ground is supplied

- to BCM terminal 142
- through front door switch (driver side) terminal 1.

Front door switch (driver side) is case ground.

With ignition switch OFF or ACC position, driver's door open, and lighting switch in 1ST or 2ND position, ground is supplied

- to warning chime terminal 3
- from BCM terminal 12.

The warning chime will sound. [Except when head lamp battery saver control operates (for 45 seconds after ignition switch is turned to OFF or ACC position) and head-lamps do not illuminate.]

## SEAT BELT WARNING CHIME

When seat belt buckle switch is unfastened, ground is supplied

- to BCM terminal 147
- through front power seat (seat belt buckle switch) terminals 41 and 15A [with automatic drive positioner] or
- through front power seat (seat belt buckle switch) terminals 41 and 14 [without automatic drive positioner], and
- through body grounds B17 and B57.


With ignition switch turned ON and seat belt unfastened (seat belt switch ON), ground is supplied

- to warning chime terminal 3
- from BCM terminal 12.

Warning chime will sound for approximately 6 seconds.

## Component Parts and Harness Connector Location

AKS002IT



## Major Component Parts and Function


AKS002IU

Components	Functions
BCM	It operates the warning chime intermittently by signals from the ignition switch, key detection switch, lighting switch, or front door switch (driver side) or seat belt buckle switch (driver side).
Warning chime	It generates intermittent sounds by signals from the BCM.

# WARNING CHIME

## Schematic

AKS002IV





TKWA0593E



# WARNING CHIME

## Wiring Diagram — CHIME —

AKS0021W







REFER TO THE FOLLOWING.

- (M1) - FUSE BLOCK-JUNCTION BOX (J/B) NO.1
- (M145) - FUSE BLOCK-JUNCTION BOX (J/B) NO.2
- (M4) - ELECTRICAL UNITS

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DI  
L  
M

# WARNING CHIME

DI-CHIME-02



REFER TO THE FOLLOWING.



- (E205) -SUPER MULTIPLE JUNCTION (SMJ)
- (M1, E201) -FUSE BLOCK-JUNCTION BOX (J/B) NO.1
- (E3) -FUSE, FUSIBLE LINK AND RELAY BLOCK (J/B)
- (M4) -ELECTRICAL UNITS

\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

TKWA0595E

# WARNING CHIME

## DI-CHIME-03









REFER TO THE FOLLOWING.  
M4, B4 -ELECTRICAL  
UNITS

\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DI  
L  
M

# WARNING CHIME

DI-CHIME-04





TKWA0597E

# WARNING CHIME

## Terminals and Reference Value Chart for BCM

AKS002IX

Terminal No.	Wire color	Item	Measuring condition		Reference value (V)
			Ignition switch	Operation or condition	
3	R/L	Tail lamp relay	ON	Lighting switch: 1ST or 2ND	ON Approx. 12
					OFF Approx. 0
12	BR	Warning chime input signal	OFF	[Ignition key warning chime] Front door (driver side): Open Lighting switch: OFF	Key is inserted.  ELN0529D
					Key is removed. Approx. 12
			OFF	[Light warning chime] Lighting switch: 1ST, 2ND	Front door (driver side): Open  ELN0530D
					Front door (driver side): Closed Approx. 12
56	B	Ground	ON	—	Approx. 0
68	W/B	Ignition switch ON or START	ON	Ignition switch is in "ON" position	Battery voltage
69	PU/W	Key switch	OFF	Key is removed.	Approx. 0
				Key is inserted.	Approx. 12
105	Y/L	Battery power source	OFF	—	Battery voltage
113	B	Ground	ON	—	Approx. 0
142	R/Y	Front door switch (driver side)	OFF	ON (Open)	Approx. 0
				OFF (Closed)	Approx. 12
147	G/W	Seat belt buckle switch (driver side)	ON	Ignition switch is "ON" position	Fasten Approx. 5
					Unfasten Approx. 0

### Work Flow

AKS002IY

1. Check the symptom and customer's requests.
2. Understand the outline of system. Refer to [DI-46, "System Description"](#) .
3. Perform the preliminary check. Refer to [DI-54, "Preliminary Inspection"](#) .
4. Referring to Trouble diagnosis chart, repair or replace the cause of the incident. Refer to [DI-58, "Symptom Chart"](#) .
5. Does warning chime system operate normally? If so, go to 5. If not, go to 2.
6. Inspection end.

# WARNING CHIME

AKS0040A

## Preliminary Inspection INSPECTION FOR POWER SUPPLY AND GROUND CIRCUIT

### 1. CHECK FUSES

Check that any of the following fuses for the BCM is blown.

Unit	Power source	Fuse No.
BCM	Battery	3
	Ignition switch ON or START	1
Warning chime	Battery	6

Refer to [DI-49, "Wiring Diagram — CHIME —"](#).

OK or NG


OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-2, "POWER SUPPLY ROUTING"](#).

### 2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect BCM connector.
2. Check voltage between BCM connector M4 terminals 68 (W/B), 105 (Y/L) and ground.

Terminals		Ignition switch position			
(+)		(-)	OFF	ACC	ON
Connector	Terminal (Wire color)				
M4	68 (W/B)	Ground	0V	0V	Battery voltage
	105 (Y/L)	Ground	Battery voltage	Battery voltage	Battery voltage



OK or NG

OK >> GO TO 3.

NG >> Check harness for open between BCM and fuse.

### 3. CHECK GROUND CIRCUIT


1. Turn ignition switch OFF.
2. Check continuity between BCM harness connector M4 terminals 56 (B), 113 (B) and ground.

**Continuity should exist.**

OK or NG

OK >> Inspection end.

NG >> Repair harness or connector.



# WARNING CHIME

AKS0040B

## CONSULT-II Function


- CONSULT-II executes the following functions by combining data reception and command transmission via the communication line from BCM. IVMS communication inspection, work support (only function setting of seats and steering wheel), self-diagnosis, data monitor, and active test display.

## DIAGNOSTIC ITEMS DESCRIPTION


IVMS diagnosis position	Diagnosis mode	Description
IGN KEY WARN ALM	Data monitor	The input data to the BCM control unit is displayed in real time.
	Active test	Operation of electrical loads can be checked by sending driving signal to them.
LIGHT WARN ALM	Data monitor	The input data to the BCM control unit is displayed in real time.
	Active test	Operation of electrical loads can be checked by sending driving signal to them.
SEAT BELT TIMER	Data monitor	The input data to the BCM control unit is displayed in real time.
	Active test	Operation of electrical loads can be checked by sending driving signal to them.
BCM PART NUMBER		Displays BCM part No.

## CONSULT-II BASIC OPERATION PROCEDURE


- With the ignition switch OFF, connect "CONSULT-II" and "CONSULT-II CONVERTER" to the data link connector, and turn the ignition switch ON.



- Touch "START (NISSAN BASED VHCL)".




- Touch "IVMS" on "SELECT SYSTEM" screen. If "IVMS" is not indicated, go to [GI-38, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



# WARNING CHIME

4. Check the model specification, touch either "WITH SUNROOF" or "WITHOUT SUNROOF".
5. Touch "OK". If the selection is wrong, touch "CANCEL".



6. Select the desired part to be diagnosed on the "SELECT TEST ITEM" screen.

## DATA MONITOR

### Operation Procedure

1. Touch "IGN WARN ALM", "LIGHT WARN ALM" or "SEAT BELT WARM" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
3. Touch "MAIN SIGNALS" or "SELECTION FROM MENU" on "DATA MONITOR" screen.

MAIN SIGNALS	Monitors the main items.
SELECTION FROM MENU	Selects and monitors the items.

4. If "SELECTION FROM MENU" is selected, touch the desired monitor item. If "MAIN SIGNALS" is selected, the main item required to control is monitored.
5. Touch "START".
6. During monitoring, touching "COPY" can start recording the monitor item status.

### Data Monitor Item (Key Warning Chime)

Monitored item	Description
IGN KEY SW	Indicates [ON/OFF] condition of electronic key switch.
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.

### Data Monitor Item (Light Warning Chime)

Monitored item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.
HD/LAMP 1ST SW	Indicates [ON/OFF] condition of lighting switch.

### Data Monitor Item (Seat Belt Warning Chime)

Monitored item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.
SEAT BELT SW	Indicates [ON/OFF] condition of fastening belt buckle switch.



# WARNING CHIME

## ACTIVE TEST

### Operation Procedure

1. Touch "IGN WARN ALM", "LIGHT WARN ALM" or "SEAT BELT WARN" on "SELECT TEST ITEM" screen.
2. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
3. Touch the item to be tested, and check the operation.
4. During the operation check, touching "OFF" deactivates the operation.

### Active Test Item (Key Warning Chime)

Test item	Malfunction detecting condition
CHIME	This test is able to check key warning chime operation. Key warning chime sounds for 2 seconds after touching "ON" on CONSULT-II screen.

### Active Test Item (Light Warning Chime)

Test item	Malfunction detecting condition
CHIME	This test is able to check light warning chime operation. Light warning chime sounds for 2 seconds after touching "ON" on CONSULT-II screen.

### Active Test Item (Seat Belt Warning Chime)

Test item	Malfunction detecting condition
CHIME	This test is able to check seat belt warning chime operation. Seat belt warning chime sounds for 2 seconds after touching "ON" on CONSULT-II screen.

## On Board Diagnosis

AKS002J1

### ON BOARD DIAGNOSTIC RESULTS INDICATOR LAMP

- Map lamps and step lamps (all seats) act as the indicators for the on board diagnosis.


### DIAGNOSIS ITEM

Diagnosis item	Description
Switch monitor	Monitoring conditions of switches connected to BCM.

### SWITCH MONITOR

- Perform the diagnosis on the switch system to each control unit.


### How to Perform Switch Monitor



# WARNING CHIME

## Description

- In this mode, when BCM detects the input signal from a switch in IVMS as shown below, the detection is indicated by the map lamps and front step lamps with buzzer.



## Switch Monitor Item

- The status of the switch (except the ignition switch, interior lamp ill switch, and map lamp switch) as input to each control unit can be monitored.

BCM	Driver door switch
	Lighting switch (1ST)
	Seat belt buckle switch

## Cancel of Switch Monitor

- Turn ignition switch OFF
- Drive the vehicle at more than 7km/h (4MPH).

## Symptom Chart

AKS002J2

Symptom	Possible cause and repair order
All warning chime does not activate.	<ul style="list-style-type: none"> <li>Warning chime circuit check. Refer to <a href="#">DI-59, "Warning Chime Circuit Inspection"</a> .</li> </ul> If the above systems are work properly, replace the BCM.
Light warning chime does not activate (head-lamp system is properly).	<ul style="list-style-type: none"> <li>Lighting switch input signal check. Refer to <a href="#">DI-62, "Lighting Switch Input Signal Inspection"</a> .</li> <li>Front door switch (driver side) check. Refer to <a href="#">DI-60, "Front Door Switch (Driver Side) Inspection"</a> .</li> </ul> If the above systems are work properly, replace the BCM.
Key warning chime does not activate.	<ul style="list-style-type: none"> <li>Key switch insert signal check. Refer to <a href="#">DI-61, "Key Switch Insert Signal Inspection"</a> .</li> <li>Front door switch (driver side) check. Refer to <a href="#">DI-60, "Front Door Switch (Driver Side) Inspection"</a> .</li> </ul> If the above systems are work properly, replace the BCM.
Seat belt warning chime does not activate.	<ul style="list-style-type: none"> <li>Check seat belt buckle switch input signal check. Refer to <a href="#">DI-62, "Seat Belt Buckle Switch Inspection"</a> .</li> </ul> If the above systems are work properly, replace the BCM.
With the ignition switch turned OFF and the door closed (driver side), turning the lighting switch ON (1st) activates the chime.	<ul style="list-style-type: none"> <li>Door switch (driver side) check. Refer to <a href="#">DI-60, "Front Door Switch (Driver Side) Inspection"</a> .</li> </ul> If the above systems are work properly, replace the BCM.

# WARNING CHIME

AKS0040C

## Warning Chime Circuit Inspection


### 1. CHECK POWER SUPPLY CIRCUIT

1. Disconnect warning chime connector.
2. Check voltage between warning chime harness connector M74 terminal 1 (Y/G) and ground.

**Battery voltage should exist.**

OK or NG

- OK >> GO TO 2.  
NG >> Check harness for open or short between fuse and warning chime.




### 2. CHECK WARNING CHIME SHORT CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between warning chime harness connector M74 terminal 3 (BR) and ground.

**Continuity should not exist.**

OK or NG

- OK >> GO TO 3.  
NO >> Repair harness or connector.




### 3. CHECK WARNING CHIME OPEN CIRCUIT

Check continuity between warning chime harness connector M74 terminal 3 (BR) and BCM harness connector M4 terminal 12 (BR).

**Continuity should exist.**

OK or NG

- OK >> GO TO 4.  
NG >> Repair harness or connector.




### 4. CHECK WARNING CHIME OPERATION

1. Connect warning chime connector.
2. Ground warning chime harness connector M74 terminal 3 (BR).

**Warning chime should operate.**

OK or NG

- OK >> Replace BCM.  
NG >> Replace warning chime.



# WARNING CHIME

AKS0040D

## Front Door Switch (Driver Side) Inspection

### 1. CHECK FRONT DOOR SWITCH (DRIVER SIDE) INPUT SIGNAL

#### With CONSULT-II

Check front door switch ("DOOR SW-DR") in "DATA MONITOR" mode.

When driver's door is open :DOOR SW-DR ON

When driver's door is closed :DOOR SW-DR OFF


#### Without CONSULT-II

Check front door switch (driver side) in "SWITCH MONITOR" mode. Refer to [DI-57, "On Board Diagnosis"](#).

OK or NG

OK >> Front door switch (driver side) is OK.

NG >> GO TO 2.



### 2. CHECK FRONT DOOR SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector and front door switch (driver side) connector.
3. Check continuity between BCM harness connector B4 terminal 142 (R/Y) and front door switch (driver side) harness connector B20 terminal 1 (R/Y).

Continuity should exist.


4. Check continuity between BCM harness connector B4 terminal 142 (R/Y) and ground.

Continuity should not exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.



### 3. CHECK DOOR SWITCH (DRIVER SIDE)

Check front door switch.


When front door switch is released : Continuity should exist.

When front door switch is pushed : Continuity should not exist.

OK or NG

OK >> Front door switch (driver side) is OK.

NG >> Replace front door switch (driver side).



# WARNING CHIME

## Key Switch Insert Signal Inspection

AKS0040E


### 1. CHECK KEY SWITCH INPUT SIGNAL

#### With CONSULT-II

Check key switch ("IGN KEY SW") in "DATA MONITOR" mode.

**When key is inserted to ignition key cylinder : IGN KEY SW ON**

**When key is removed to ignition key cylinder : IGN KEY SW OFF**




#### Without CONSULT-II

1. Disconnect the BCM connector.
2. Check voltage between BCM harness connector M4 terminal 69 (PU/W) and ground.

**When key is inserted to ignition key cylinder : Approx. 12V**

**When key is removed to ignition key cylinder : Approx. 0V**



#### OK or NG

- OK >> Key switch and key lock solenoid (key switch) is OK.  
NG >> GO TO 2.


### 2. CHECK KEY SWITCH CIRCUIT

1. Disconnect key switch and key lock solenoid (key switch) connector.
2. Check continuity between BCM harness connector M4 terminal 69 (PU/W) and key switch and key lock solenoid (key switch) harness connector M64 terminal 4 (PU/W).

**Continuity should exist.**

#### OK or NG

- OK >> GO TO 3.  
NG >> Repair harness or connector.



### 3. CHECK KEY SWITCH (INSERT)


Check continuity between terminals 3 and 4 of key switch and key lock solenoid (key switch) connector M64.

**When key is inserted to ignition key cylinder : Continuity should exist.**

**When key is removed to ignition key cylinder : Continuity should not exist.**

#### OK or NG

- OK >> Inspection end.  
NG >> Replace key switch and key lock solenoid (key switch).



# WARNING CHIME

## Lighting Switch Input Signal Inspection

AKS0040F

### 1. CHECK LIGHTING SWITCH INPUT SIGNAL

#### With CONSULT-II

Check Lighting switch ("HD/LMP 1ST SW") in "DATA MONITOR" mode.

**When lighting switch is 1ST : HD/LMP 1ST SW ON or 2ND**

**When lighting switch is OFF : HD/LMP 1ST SW OFF**

#### Without CONSULT-II

Check lighting switch in switch monitor mode, refer to [DI-57, "On Board Diagnosis"](#).

OK or NG

- OK >> Lighting switch is OK.
- NG >> GO TO 2.

DATA MONITOR	
MONITOR	
HD/LMP 1ST SW	ON
RECORD	

SEL500W

### 2. CHECK TAIL LAMP RELAY CONTROL SIGNAL


1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check voltage between BCM harness connector M4 terminal 3 (R/L) and ground.

**When lighting switch is 1ST or 2ND : Approx. 12V**

**When lighting switch is OFF : Approx. 0V**

OK or NG

- OK >> Inspection end.
- NG >> Check harness for open or short between BCM and tail lamp relay.



## Seat Belt Buckle Switch Inspection

AKS0040G

### 1. CHECK SEAT BELT BUCKLE SWITCH INPUT SIGNAL

#### With CONSULT-II

Check seat belt buckle switch ("SEAT BELT SW") in "DATA MONITOR" mode.

**When seat belt is fastened : SEAT BELT SW ON**

**When seat belt is unfastened : SEAT BELT SW OFF**

#### Without CONSULT-II

Check seat belt buckle switch in switch monitor mode. Refer to [DI-57, "On Board Diagnosis"](#).

OK or NG

- OK >> Seat belt buckle switch is OK.
- NG >> GO TO 2.

DATA MONITOR	
MONITOR	
SEAT BELT SW	ON
RECORD	

SEL501W

# WARNING CHIME

## 2. CHECK SEAT BELT BUCKLE SWITCH


1. Turn ignition switch OFF.
2. Disconnect seat belt buckle switch connector.
3. Check the following.

### With automatic drive positioner

- Continuity between seat belt buckle switch connector B150 terminals 41 (L/B) and 15A (B)

**When seat belt is fastened : Continuity should not exist.**

**When seat belt is unfastened : Continuity should exist.**




### Without automatic drive positioner

- Continuity between seat belt buckle switch connector B150 terminals 41 (L/B) and 14 (B)

**When seat belt is fastened : Continuity should not exist.**

**When seat belt is unfastened : Continuity should exist.**



### OK or NG

- OK >> GO TO 3.
- NG >> Replace seat belt buckle switch.

## 3. CHECK SEAT BELT BUCKLE SWITCH CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector B4 terminal 147 (G/W) and seat belt buckle switch harness connector B150 terminal 41 (L/B).


**Continuity should exist.**

3. Check continuity between BCM harness connector B4 terminal 147 (G/W) and ground.

**Continuity should not exist.**

### OK or NG

- OK >> GO TO 4.
- NG >> Repair harness or connector.



# WARNING CHIME


## 4. CHECK SEAT BELT BUCKLE SWITCH GROUND CIRCUIT

Check the following.

### With automatic drive positioner

- Continuity between seat belt buckle switch connector B150 terminal 15A (B) and ground

**Continuity should exist.**




### Without automatic drive positioner

- Continuity between seat belt buckle switch connector B150 terminal 14 (B) and ground

**Continuity should exist.**

### OK or NG


- OK >> Inspection end.
- NG >> Repair harness or connector.



## Removal and Installation of Warning Chime

### REMOVAL

- Remove cluster lid C. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#).
- Remove bolt (1), and remove warning chime.



### INSTALLATION

Install in the reverse order of removal.



## VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITH NAVIGATION SYSTEM

PFP:28395

A

### System Description INTEGRATED SWITCH SYSTEM

AKS004DL

B

Using the multifunction switch at the center of the instrument panel, the controls of the following systems are centralized:

- Auto A/C system
- Vehicle information system
- Audio system
- Navigation system
- Hazard switch

C

The multifunction switch can operate and check the vehicle condition and each setting (vehicle electrical system).

D

E

### PRECAUTION OF LCD MONITOR

- When passenger compartment temperature is low, the LCD monitor sometimes dims because of the brightness of the back light (small fluorescent light) integrated into the LCD monitor decrease. In this case, the refreshing rate of the picture also becomes low because of the low response of the LCD monitor. When passenger compartment becomes warm, however, the LCD recovers the normal display.
- Sometimes, black or bright dots peculiar to LCD monitor can be seen on the display.
- Back light sometimes flickers or darkens according to the total consumption hours and the number of ON and OFF switching. In this case, the back light should be replaced. (LCD monitor assembly)

F

G

H

### POWER SUPPLY AND GROUND

#### Power is Supplied at All Times

- through 15A fuse [No. 52, located in fuse, fusible link and relay block (J/B)]
- to AV and NAVI control unit terminals 2 and 3, and
- to display terminals 21 and 23.

I

#### When Ignition Switch is in ACC or ON Position, Power is Supplied

- through 10A fuse [No. 21, located in fuse block (J/B) No. 1]
- to AV and NAVI control unit terminal 6,
- to display terminal 19, and
- to multifunction switch terminal 1.

J

DI

#### When Ignition Switch is in ON or START Position, Power is Supplied

- through 10A fuse [No. 1, located in fuse block (J/B) No. 1]
- to AV and NAVI control unit terminal 26.

L

#### Ground is Supplied

- to AV and NAVI control unit terminal 1 and 4
- through body grounds B17 and B57
- to multifunction switch terminal 2, and
- to display terminals 22 and 24
- through body grounds M24 and M114.

M

### AV COMMUNICATION LINE

AV and NAVI control unit is connected to the following units by AV communication line. Each unit transmits/receives data with AV communication line.


- Display
- Multifunction switch
- Audio unit
- BOSE speaker amp.
- Rear view camera control unit

# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITH NAVIGATION SYSTEM


- Low tire pressure warning control unit
- Voice activated control module

## VEHICLE INFORMATION SYSTEM

- AV and NAVI control unit is received vehicle information system of signals from combination meter.
  - AV and NAVI control unit is communicating with BCM and combination meter.
1. Press “INFO” switch to display vehicle information display.



2. Select “Trip Computer”, “Fuel Economy”, “Maintenance” or “Tire pressure”.




Display items	Display/Setting contents
Trip Computer	Elapsed Time
	Driving Distance
	Average Speed
Fuel Economy	Average Fuel Economy (MPG)
	Distance to Empty (miles)
	Fuel Economy (MPG)
	Fuel Economy Record
Maintenance (with Maintenance information*)	Maintenance intervals of engine oil and setting of oil change cycle
	Maintenance intervals of oil filter and setting of filter replacement cycle
	Maintenance intervals of tire and setting of tire replacement cycle
Tire Pressure	Tire pressure information.

\*:Maintenance information displays the change cycle of engine oil, oil filter and tire on LCD monitor depending on the driving distance specified by a driver or a technician.

# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITH NAVIGATION SYSTEM


## Trip Computer Information

1. Select "Trip Computer".
2. Elapsed time, Driving distance and Average speed are displayed as Trip Computer information.




## Fuel Economy Information

1. Select "Fuel Economy".
2. Average Fuel Economy, Distance to Empty, Fuel Economy are displayed as Fuel Economy information.




3. Select "Fuel Economy Record". The average fuel consumption history will be displayed in graph along with the average for the previous Reset – to – Reset period.



## Maintenance Information

1. Select "Maintenance".
2. Engine Oil, Oil Filter and Tire Rotation are displayed as Maintenance information.




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DI  
L  
M

# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITH NAVIGATION SYSTEM


## Tire Pressure Information

1. Select "Tire Pressure".
2. Tire pressure displayed as Tire pressure information




### NOTE:

- When air pressure becomes 180kPa (1.8kg/cm<sup>2</sup> , 26psi) or less, "LOW PRESSURE" warning is indicated.
- When air pressure becomes 70kPa (0.7kg/cm<sup>2</sup> , 10psi) or less, "FLAT TIRE" warning is indicated.
- When pressure is not detected or tire pressure system has problem "\*\*\* psi" is indicated.
- Indication with yellow frame for the malfunctioning tire.




## SETTING OF VEHICLE STATUS

- Setting of electric status can be changed by multifunction switch. The signal is sent to BCM through AV and NAVI control unit to change vehicle electric system setting.
  - AV and NAVI control unit is communicating with BCM and combination meter.
1. Press "SETTING" switch to display vehicle information display.



2. Select "Vehicle Electronic System".




# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITH NAVIGATION SYSTEM

3. Select a vehicle status shown on the display.


Adjustable vehicle status

- Language/Unit
- Lift Steering Column When Exiting Vehicle.
- Adjust Driver Seat When Exiting Vehicle
- Illuminate Interior When Unlocking Vehicle




A  
B  
C  
D

- Interior Lights Off Delay
- Sensitivity of Automatic Headlights
- Automatic Headlights Off Delay
- Keyless Remote Response-Horn/Lights



E  
F  
G

- Remote Custom Setting
- Return All Setting to Default



H  
I  
J

DI

L  
M

# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITH NAVIGATION SYSTEM

## Adjustable Vehicle Status

Setting items	Setting variations	Initial setting	Operation
Language/Unit	Language: English/Français	English	Language and unit can be changed in this mode.
	Unit: US/Metric	US	
Lift Steering Column When Exiting Vehicle	ON/OFF	ON	<p>The steering column automatically tilts up when the driver gets out, and returns to the original position when the driver gets on.</p> <ul style="list-style-type: none"> <li>When driver door is closed and key removed from ignition key cylinder, the steering column tilts up.</li> <li>When driver door is open and key is turned to OFF, the steering column tilts up.</li> </ul>
Adjust Driver Seat When Exiting Vehicle	ON/OFF	ON	The driver's seat automatically slides backward when the driver gets out, and returns to the original position when the driver gets on.
Illuminate Interior When Unlocking Vehicle	ON/OFF	ON	The interior room lamps are illuminate automatically when the door unlocked with key or key fob.
Interior Lights Off Delay	OFF/15/30/45 sec.	30 sec.	Interior room lamp timer period can be changed in this mode. Selects interior room lamp timer.
Sensitivity of Automatic Headlights	1/2/3/4	3	Sensitivity of auto light sensor can be adjusted.
Automatic Headlights Off Delay	OFF/20/45/90/120/150/180 sec.	45 sec.	Auto light delay off timer period can be changed in this mode. Selects auto light delay off timer.
Keyless Remote Response - Horn/Lights	Hazard indicators only /Hazard indicators and horn	Hazard indicators only	<p>Hazard indicators Only:</p> <ul style="list-style-type: none"> <li>Lock operation: The hazard warning lamp flash twice when lock the doors with key fob.</li> <li>Unlock operation: No response.</li> </ul> <p>Hazard indicators and horn:</p> <ul style="list-style-type: none"> <li>Lock operation: The hazard warning lamp flash twice and horn sounds once when lock the doors with key fob.</li> <li>Unlock operation; The hazard warning lamp flash once when unlock the doors with key fob.</li> </ul>
Remote Custom Setting	ON/OFF	ON	<p>The driving position -seat and steering column- and the audio setting -current source and radio station presets- are set to the same condition you made last time by identifying the key fob ID.</p> <p>This function operates when unlock the doors by using the key fob.</p> <p><b>NOTE:</b> It is necessary to memorize the driving position before using this function.</p>
Return All Settings to Default	None	None	If this key is selected, all vehicle electronic systems setting are return to default.

## WARNING INDICATIONS

When combination meter receives warning signal from BCM, then combination meter warning lamp is illuminated.

Then combination meter sends warning signal to AV and NAVI control unit to display warning indications on the screen.

Warning indicators	Warning lamps in instrument panel	Warning detection and cancel conditions		Cases of malfunction
DOOR OPEN	Door	Detection condition	Vehicle is running [approx. 5 km/h (3 MPH) or faster] and door ajar of any of the doors is detected.	Door is open
		Cancel condition	Vehicle is stopped and all the doors lock.	

## Precautions for AV and NAVI Control Unit Replacement

AKS004DM

- When replacing the AV and NAVI control unit, eject the map DVD-ROM before disconnecting the battery.
- The AV and NAVI control unit has the following information stored in its memory. Record the memory contents before replacing the control unit, and input them in the new unit as necessary.


- |   |   |
|---|---|
| <p>&lt;FM-AM&gt;</p> <p>&lt;CD&gt;</p> <p>&lt;Sound quality&gt;</p> <p>&lt;Image quality&gt;</p> <p>&lt;Navigation mode&gt;</p> | <ul style="list-style-type: none"> <li>• Preset frequency</li> <li>• Area for indicating station, selection of overlapped stations</li> <li>• Program status</li> <li>• Volume balance memory set values</li> <li>• Equalizer memory set values</li> <li>• Brightness of light when ON/OFF</li> <li>• Dimming switching</li> <li>• Display color switching</li> <li>• Latest status (MAP screen/BIRD VIEW™, reduced scale, rotation angle of map screen, route guide ON/OFF, track ON/OFF, etc.)</li> <li>• Current position</li> <li>• Destination, passing point 1-5</li> <li>• Registered places, their names, etc.</li> </ul> |
|---|---|

**NOTE:**

Only removing the battery does not erase the memory.

## Component Parts and Harness Connector Location

AKS004DN




SKIA9345E

# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITH NAVIGATION SYSTEM

## Schematic

AKS004DO



TKWA0598E









# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITH NAVIGATION SYSTEM

## Wiring Diagram — INF/D —

AKS004DP

DI-INF/D-01



REFER TO THE FOLLOWING.


(E205) -SUPER MULTIPLE JUNCTION (SMJ)

(E3) -FUSE, FUSIBLE LINK AND RELAY BLOCK (J/B)

TKWA1230E

# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITH NAVIGATION SYSTEM

DI-INF/D-02




REFER TO THE FOLLOWING.  
 (M4) -ELECTRICAL UNITS

TKWA0600E

# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITH NAVIGATION SYSTEM

DI-INF/D-03



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DI  
L  
M

1	2	3	4	5	6	7	8	9	10	11		
12	13	14	15	16	17	18	19	20	21	22	23	24

(M7)  
W

1	1	1	1	1	1	1	1	2	2
3	3	3	3	3	3	3	3	2	2

(M21)  
GY

1	1	1	1	1	1	2	2	2	2
3	3	3	3	3	3	4	4	4	4

(M49)  
L

1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18	19	20

(M119)  
GY



48	45	42	39	37	35	33	30	27
47	44	41	38	36	34	32	29	26
46	43	40				31	28	25

(B29)  
GY

24	21	18	15	13	11	9	6	3
23	20	17	14	12	10	8	5	2
22	19	16				7	4	1

(B30)  
W


REFER TO THE FOLLOWING.

- (M5) -SUPER MULTIPLE JUNCTION (SMJ)
- (M1) -FUSE BLOCK-JUNCTION BOX (J/B) NO.1

TKWA1231E

# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITH NAVIGATION SYSTEM

DI-INF/D-04



1	2	3	4	5	6	7	8	9	10	11		
12	13	14	15	16	17	18	19	20	21	22	23	24

(M7)  
W

24	22	20	18	16	14	10	8	6	4	2		
23	21	19	17	15	13	12	11	9	7	5	3	1

(M82)  
GY


24	21	18	15	13	11	9	6	3
23	20	17	14	12	10	8	5	2
22	19	16				7	4	1

(B30)  
W

TKWA0602E

# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITH NAVIGATION SYSTEM

DI-INF/D-05



1	2	3	4	5	6	7	8	9	10	11		
12	13	14	15	16	17	18	19	20	21	22	23	24

(M7) W

24	22	20	18	16	14	10	8	6	4	2		
23	21	19	17	15	13	12	11	9	7	5	3	1

(M82) GY

20	18	16	14	12	8	6	4	2		
19	17	15	13	11	10	9	7	5	3	1

(M83) W

7	6	5	4	3	2	1		
16	15	14	13	12	11	10	9	8

(M84) W

48	45	42	39	37	35	33	30	27
47	44	41	38	36	34	32	29	26
46	43	40	31	28	25			

(B29) GY

TKWA0603E

# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITH NAVIGATION SYSTEM







## Terminals and Reference Value for AV and NAVI Control Unit

AKS004DQ






Refer to [AV-64, "Terminals and Reference Value for AV and NAVI Control Unit"](#) .

## Terminals and Reference Value for Display

AKS004DR

Terminals		Signal	Condition		Reference value
Terminal No.	Wire color		Ignition switch	Operation	
1	R/L	RGB signal (R: Red)	ON	Move to "Screen Adjustment" in the check/adjustment function.	 <p style="text-align: right;">SKIA0165E</p>
2	R/W	RGB signal (G: Green)	ON	Move to "Screen Adjustment" in the check/adjustment function.	 <p style="text-align: right;">SKIA0166E</p>
3	B	RGB signal (B: Blue)	ON	Move to "Screen Adjustment" in the check/adjustment function.	 <p style="text-align: right;">SKIA0167E</p>
4	—	RGB ground	ON	—	Approx. 0V
5	W	Horizontal synchronizing signal	ON	ON screen, the volume can be adjusted.	 <p style="text-align: right;">SKIA0163E</p>
6	R	Vertical synchronizing signal	ON	—	 <p style="text-align: right;">SKIA0161E</p>
7	G	RGB synchronizing signal	ON	Press the map switch.	 <p style="text-align: right;">SKIA0164E</p>

# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITH NAVIGATION SYSTEM





Terminals		Signal	Condition		Reference value
Terminal No.	Wire color		Ignition switch	Operation	
8	B	RGB area signal	ON	Press the vehicle information switch.	 <p style="text-align: right; font-size: small;">SKIA0162E</p>
12	B/R	Communication signal (-)	ON	—	 <p style="text-align: right; font-size: small;">SKIA0176E</p>
13	W/R	Communication signal (+)	ON	—	 <p style="text-align: right; font-size: small;">SKIA0175E</p>
14	—	Shield ground	—	—	—
15	L	Communication signal (-)	ON	—	 <p style="text-align: right; font-size: small;">SKIA0176E</p>
16	R	Communication signal (+)	ON	—	 <p style="text-align: right; font-size: small;">SKIA0175E</p>
17	—	Shield ground	—	—	—
19	L/B	Ignition switch (ACC)	ACC	—	Battery voltage
21	SB	Battery power supply	OFF	—	Battery voltage
23					
22	B	Ground	—	—	—
24					

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DI  
L  
M

# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITH NAVIGATION SYSTEM

## Terminals and Reference Value for Multifunction Switch

AKS004DS

Terminals		Signal	Condition		Reference value
Terminal No.	Wire color		Ignition switch	Operation	
1	L/B	Ignition switch (ACC)	ACC	—	Battery voltage
2	B	Ground	ON	—	Approx. 0V
9	R	Communication signal (+)	ON	—	 <p style="text-align: right; font-size: small;">SKIA0175E</p>
10	L	Communication signal (-)	ON	—	 <p style="text-align: right; font-size: small;">SKIA0176E</p>
11	—	Shield ground	ON	—	—
15	Y	Communication signal (+)	ON	—	 <p style="text-align: right; font-size: small;">SKIA0175E</p>
16	BR	Communication signal (-)	ON	—	 <p style="text-align: right; font-size: small;">SKIA0176E</p>
17	—	Shield ground	—	—	—

## On Board Self-Diagnosis Function DESCRIPTION

AKS004DT

- Diagnosis function consists of the self-diagnosis mode performed automatically and the CONFIRMATION/ADJUSTMENT mode operated manually.
- Self-diagnosis mode checks for connections between the units constituting this system, analyzes each individual unit at the same time, and displays the results on the LCD screen.
- CONFIRMATION/ADJUSTMENT mode is used to perform trouble diagnosis that require operation and judgment by an operator (trouble that cannot be automatically judged by the system), to check/change the set value, and to display the History of Errors of the navigation system.



# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITH NAVIGATION SYSTEM

## DIAGNOSIS ITEM

Mode		Description	
Self-diagnosis		<ul style="list-style-type: none"> <li>● AV and NAVI Control unit diagnosis (DVD-ROM drive will not be diagnosed when no map DVD-ROM is in it.)</li> <li>● Analyzes connection between the AV and NAVI control unit and the GPS antenna connection between the AV and NAVI control unit and each unit, and operation of each unit.</li> </ul>	
CONFIRMATION/ ADJUSTMENT	Display diagnosis	Color tone and shading of the screen can be checked by the display of a color bar and a gray scale.	
	Vehicle signals	Analyzes the following vehicle signals: Vehicle speed signal, parking brake signal, light signal, ignition switch signal, and reverse signal.	
	Speaker Test	Checks the connection of each speaker using a test tone.	
	Auto Climate Control	Turns all A/C screens on display and A/C switch indicator lamp on.	
	Navigation	Display Longitude & Latitude	Display the map. Use the joystick to adjust position. Longitude and latitude will be displayed.
		Speed Calibration	Under ordinary conditions, the navigation system distance measuring function will automatically compensate for minute decreases in wheel and tire diameter caused by tire wear or low pressure. Speed calibration immediately restores system accuracy in cases such as when distance calibration is needed because of the use of tire chains in inclement weather.
		Angle Adjustment	Corrects difference between actual turning angle of a vehicle and turning angle of the car mark on the display.
		Initialize Location	This mode is for initializing the current location. Use when the vehicle is transported a long distance on a trailer, etc.
History of Errors		Diagnosis results previously stored in the memory (before turning ignition switch ON) are displayed in this mode. Time and location when/where the errors occurred are also displayed.	
Rear View Camera		Changes position of the aiming line overlapped on the rear view image.	

### Self-Diagnosis Mode

AKS004DU

Refer to [AV-69, "Self-Diagnosis Mode"](#) .

### Confirmation/Adjustment Mode

AKS004DV

Refer to [AV-73, "Confirmation/Adjustment Mode"](#) .

### CONSULT-II Function

AKS004DW

Refer to [AV-79, "CONSULT-II Function"](#) .

### Multifunction Switch Self-Diagnosis Function


AKS004DX

It can check ON/OFF operation of each switch in the multifunction switch and diagnose the input signals to the rear control switch (audio) and steering switch (audio).

#### STARTING THE SELF-DIAGNOSIS MODE

1. Turn ignition switch from OFF to ACC.
2. Within 10 seconds press and hold the function switches "1" and "6" simultaneously for 5 seconds.

Then the self-diagnosis operates.



# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITH NAVIGATION SYSTEM

## EXITING THE SELF-DIAGNOSIS MODE

- Turn ignition switch OFF, or press and hold the function switches "1" and "6" simultaneously for 5 seconds. Then the self-diagnosis ends.

## DIAGNOSIS FUNCTION

- It can illuminate all the indicators (LED) in the multifunction switch.
- It can check for continuity of the switches by sounding the buzzer when the multifunction switch is pressed.
- It can check for continuity of harness between multifunction switch and rear control switch (audio), or steering switch (audio).

### NOTE:

When it check continuity of harness between multifunction switch and rear control switch (audio), rear control cancel switch is OFF position.

## Power Supply and Ground Circuit Check for AV and NAVI Control Unit

AKS004DY

Refer to [AV-83, "Power Supply and Ground Circuit Check"](#) .

## Power Supply and Ground Circuit Inspection for Display

AKS004DZ

### 1. CHECK FUSES

Check 15A fuse [No. 52, located in fuse, fusible link and relay block (J/B)] is blown.

#### OK or NG

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-2, "POWER SUPPLY ROUTING"](#) .

### 2. CHECK POWER SUPPLY CIRCUIT


1. Disconnect display connector.
2. Check voltage between display harness connector M82 terminals and ground.

Terminals		Ignition switch position			
(+)		(-)	OFF	ACC	ON
Connector	Terminal (Wire color)				
M82	19 (L/B)	Ground	0V	Battery voltage	Battery voltage
	21 (SB)	Ground	Battery voltage	Battery voltage	Battery voltage
	23 (SB)	Ground	Battery voltage	Battery voltage	Battery voltage

#### OK or NG

OK >> GO TO 3.

NG >> Check harness for open or short between display and fuse.




## 3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between display harness connector M82 terminals 22 (B), 24 (B) and ground.

**Continuity should exist.**

OK or NG

- OK >> Inspection end.  
 NG >> Repair harness or connector.



## Power Supply and Ground Circuit Inspection for Multifunction Switch

AKS004E0


### 1. CHECK POWER SUPPLY CIRCUIT

1. Disconnect multifunction switch connector.
2. Check voltage between multifunction switch and ground.

Terminals		Ignition switch position			
(+)		(-)	OFF	ACC	ON
Connector	Terminal (Wire color)				
M83	1 (L/B)	Ground	0V	Battery voltage	Battery voltage

OK or NG

- OK >> GO TO 2.  
 NG >> Check harness for open or short between multifunction switch and fuse.




### 2. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between multifunction switch harness connector M83 terminal 2 (B) and ground.

**Continuity should exist.**

OK or NG

- OK >> Inspection end.  
 NG >> Repair harness or connector.



## No Fuel Information is Displayed/No Warning Message is Displayed

AKS004E1

### 1. CHECK HARNESS

1. Disconnect connectors of combination meter, BCM, and AV and NAVI control unit.
2. Check continuity between AV and NAVI control unit and combination meter.

Terminals				Continuity
AV and NAVI control unit (+)		Combination meter (-)		
Connector	Terminal (Wire color)	Connector	Terminal (Wire color)	
B29	33 (LG)	M42	56 (LG)	Yes
	32 (PU)		57 (PU)	

3. Check continuity between AV and NAVI control unit and ground.

Terminals			Continuity
AV and NAVI control unit (+)		(-)	
Connector	Terminal (Wire color)		
B29	33 (LG)	Ground	No
	32 (PU)		

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair harness or connector.

### 2. CHECK COMMUNICATION SIGNAL (AV-ME)

1. Connect connectors of combination meter, BCM, and AV and NAVI control unit.
2. Turn ignition switch ON.
3. Check voltage signal between AV and NAVI control unit harness connector B29 terminal 33 (LG) and ground with CONSULT-II or oscilloscope.

**33 (LG) - Ground** : Refer to [AV-64, "Terminals and Reference Value for AV and NAVI Control Unit"](#) .

#### OK or NG

- OK >> GO TO 3.  
 NG >> Replace AV and NAVI control unit




### 3. CHECK COMMUNICATION SIGNAL (ME-AV)

1. Turn ignition switch ON and display "VEHICLE ELECTRONIC SYSTEMS" screen.
2. Check voltage signal between AV and NAVI control unit harness connector B29 terminal 32 (PU) and ground with CONSULT-II or oscilloscope.

**32 (PU) - Ground** : Refer to [AV-64, "Terminals and Reference Value for AV and NAVI Control Unit"](#) .

#### OK or NG

- OK >> Replace AV and NAVI control unit.  
 NG >> Replace combination meter.



## Vehicle Condition Setting is Not Possible

### 1. CHECK HARNESS

1. Disconnect connectors of combination meter, BCM, and AV and NAVI control unit.
2. Check continuity AV and NAVI control unit and BCM.


Terminals				Continuity
AV and NAVI control unit (+)		BCM (-)		
Connector	Terminal (Wire color)	Connector	Terminal (Wire color)	
B29	33 (LG)	M4	31 (LG)	Yes
	32 (PU)		30 (PU)	

3. Check continuity between AV and NAVI control unit and ground.

Terminals			Continuity
AV and NAVI control unit (+)		(-)	
Connector	Terminal (Wire color)		
B29	33 (LG)	Ground	No
	32 (PU)		

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair harness or connector.




### 2. CHECK COMMUNICATION SIGNAL (AV-ME)

1. Connect connectors of combination meter, BCM, and AV and NAVI control unit.
2. Turn ignition switch ON.
3. Check voltage signal between AV and NAVI control unit harness connector B29 terminal 33 (LG) and ground with CONSULT-II or oscilloscope.

**33 (LG) - Ground** : Refer to [AV-64, "Terminals and Reference Value for AV and NAVI Control Unit"](#) .

#### OK or NG

- OK >> GO TO 3.  
 NG >> Replace AV and NAVI control unit.




### 3. CHECK COMMUNICATION SIGNAL (ME-AV)

1. Turn ignition switch ON and display "VEHICLE ELECTRONIC SYSTEMS" screen.
2. Check voltage signal between AV and NAVI control unit harness connector B29 terminal 32 (PU) and ground with CONSULT-II or oscilloscope.

**32 (PU) - Ground** : Refer to [AV-64, "Terminals and Reference Value for AV and NAVI Control Unit"](#) .

#### OK or NG

- OK >> Replace AV and NAVI control unit.  
 NG >> Replace BCM.



## Multifunction Switch Does Not Operate

AKS004E3

### 1. MULTIFUNCTION SWITCH SELF-DIAGNOSIS

Perform multifunction switch self-diagnosis. Refer to [DI-81, "Multifunction Switch Self-Diagnosis Function"](#) .

Is self-diagnosis result OK?

- OK >> GO TO 2.
- NG >> Replace multifunction switch.

### 2. CHECK POWER AND GROUND CIRCUIT

Check power and ground circuit. Refer to [DI-80, "Terminals and Reference Value for Multifunction Switch"](#) .

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness or connector.

### 3. COMMUNICATION CIRCUIT SELF-DIAGNOSIS

Perform the self-diagnosis mode in the self-diagnosis function (If the self-diagnosis cannot be activated with the multifunction switch, check with CONSULT-II). Refer to [AV-69, "Self-Diagnosis Mode"](#) .

Is self-diagnosis result OK?

- OK >> Replace display.
- NG >> With the self-diagnostic results, check the malfunction part.

## Multifunction Switch Indicator Does Not Illuminate

AKS004E4

### 1. MULTIFUNCTION SWITCH SELF-DIAGNOSIS

Perform the multifunction switch self-diagnosis. Refer to [DI-81, "Multifunction Switch Self-Diagnosis Function"](#) .

Is the self-diagnosis result OK?


- OK >> Replace switch of the malfunctioning indicator.
- NG >> Replace multifunction switch.

## Removal and Installation of AV and NAVI Control Unit

AKS004E7

### REMOVAL

1. Remove the trunk front finisher. Refer to [EI-42, "TRUNK ROOM TRIM & TRUNK LID FINISHER"](#) .
2. Remove the screws (4) and remove the AV and NAVI control unit.



### INSTALLATION


Install in the reverse order of removal.

## Removal and Installation of Display


### REMOVAL

1. Remove the cluster lid C. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#)
2. Remove the screws (4), and remove the display.

AKS004E5



3. Remove screws (4), and remove bracket.




### INSTALLATION

Install in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DI  
L  
M

## Disassembly and Assembly for Multifunction Switch

AKS004E6



PKIA1671E

- |                                    |                         |                    |
|------------------------------------|-------------------------|--------------------|
| 1. Multifunction switch            | 2. Escutcheon           | 3. Hazard switch   |
| 4. Defroster, rear defogger switch | 5. Function switch      | 6. Function switch |
| 7. Function switch                 | 8. TAPE and DISC switch | 9. A/C switch      |
| 10. Escutcheon                     | 11. AM and FM switch    | 12. Escutcheon     |
| 13. Switch assembly                | 14. Escutcheon          | 15. Cluster lid C  |

### DISASSEMBLY

1. Remove the screw (8).
2. Remove the switches.

### ASSEMBLY

Assemble in the reverse order of disassembly.



## VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM

PFP:28395

A

### System Description INTEGRATED SWITCH SYSTEM

AKS0040H

B

Using the multifunction switch at the center of the instrument panel, the controls of the following systems are centralized:

- Auto A/C system
- Vehicle information system
- Audio system
- Hazard switch

C

The multifunction switch can operate and check the vehicle condition and each setting (vehicle electrical system).

D

### PRECAUTION OF LCD MONITOR

E

- When passenger compartment temperature is low, the LCD monitor sometimes dims because of the brightness of the back light (small fluorescent light) integrated into the LCD monitor decrease. In this case, the refreshing rate of the picture also becomes low because of the low response of the LCD monitor. When passenger compartment becomes warm, however, the LCD recovers the normal display.
- Sometimes, black or bright dots peculiar to LCD monitor can be seen on the display.
- Back light sometimes flickers or darkens according to the total consumption hours and the number of ON and OFF switching. In this case, the back light should be replaced. (LCD monitor assembly).

F

G

### POWER SUPPLY AND GROUND

#### Power Is Supplied At All Times

H

- through 15A fuse [No. 52, located in fuse, fusible link and relay block (J/B)]
- to AV control unit terminals 2 and 3, and
- to display terminals 21 and 23.

I

#### When Ignition Switch is in ACC or ON Position, Power is Supplied

J

- through 10A fuse [No. 21, located in fuse block (J/B) No. 1]
- to AV control unit terminal 6
- to display terminal 19, and
- to multifunction switch terminal 1.

DI

#### When Ignition Switch is in ON or START Position, Power is Supplied

- through 10A fuse [No. 1, located in fuse block (J/B) No. 1]
- to AV control unit terminal 27.

L

#### Ground is Supplied

M

- to AV control unit terminals 1 and 4
- through body grounds M25 and M115, and
- to multifunction switch terminal 2 and
- to display terminals 22 and 24
- through grounds M24 and M114.

### AV COMMUNICATION LINE

AV control unit is connected to the following units by AV communication line. Each unit transmits/receives data with AV communication line.

- Display
- Multifunction switch
- Audio unit
- BOSE speaker amp.(audio amp.)
- Rear view camera control unit
- Low tire pressure warning control unit


# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM

- Voice activated control module


## VEHICLE INFORMATION SYSTEM

- AV control unit is received vehicle information system of signals from combination meter.
- AV control unit is communicating with BCM and combination meter.

1. Press “INFO” switch to display vehicle information display.



2. Select “Trip Computer”, “Fuel Economy”, “Maintenance” or “Tire Pressure”.




Display items	Display/Setting contents
Trip Computer	Elapsed time
	Driving distance
	Average Speed
Fuel Economy	Average fuel economy (MPG)
	Distance to empty (miles)
	Fuel economy (MPG)
Maintenance (with Maintenance information*)	Fuel economy record
	Maintenance intervals of engine oil and setting of oil change cycle
	Maintenance intervals of oil filter and setting of filter replacement cycle
Tire Pressure	Maintenance intervals of tire and setting of tire replacement cycle
Tire Pressure	Tire pressure information

\*: Maintenance information displays the change cycle of engine oil, oil filter and tire on LCD monitor depending on the driving distance specified by a driver or a technician.

# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM


## Trip Computer Information

1. Select "Trip Computer".
2. Elapsed Time, Driving Distance and Average Speed are displayed as Trip Computer information.




## Fuel Economy Information

1. Select "Fuel Economy".
2. Average Fuel Economy, Distance to Empty, Fuel Economy are displayed as Fuel Economy information.




3. Select "Fuel Economy Record". The average fuel consumption history will be displayed in graph along with the average for the previous Reset – to – Reset period.



## Maintenance Information


1. Select "Maintenance".
2. Engine Oil, Oil Filter and Tire Rotation are displayed as Maintenance information.



# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM


## Tire Pressure Information

1. Select "Tire Pressure".
2. Tire pressure displayed as Tire Pressure information.




### NOTE:

- When air pressure becomes 180kPa (1.8kg/cm<sup>2</sup> , 26psi) or less, "LOW PRESSURE" warning is indicated.
- When air pressure becomes 70kPa (0.7kg/cm<sup>2</sup> , 10psi) or less, "FLAT TIRE" warning is indicated.
- When pressure is not detected or tire pressure system has malfunction "\*\*\* psi" is indicated.
- Indication with yellow frame for the malfunctioning tire.




## SETTING OF VEHICLE STATUS

- Setting of electric status can be changed by multifunction switch. The signal is sent to BCM through AV control unit to change vehicle electric system setting.
  - AV control unit is communicating with BCM and combination meter.
1. Press "SETTING" switch to display vehicle information display.



2. Select "Vehicle Electronic System".




# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM

## 3. Select a vehicle status shown on the display.


Adjustable vehicle status

- Language/Unit
- Lift Steering Column When Exiting Vehicle
- Adjust Driver Seat When Exiting Vehicle
- Illuminate Interior When Unlocking Vehicle




A  
B  
C

- Interior Lights Off Delay
- Sensitivity of Automatic Headlights
- Automatic Headlights Off Delay
- Keyless Remote Response - Horn/Lights



D  
E  
F  
G

- Remote Custom Setting
- Return All Settings to Default



H  
I  
J

DI

L  
M

# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM

## Adjustable Vehicle Status

Setting items	Setting variations	Initial setting	Operation
Language/Unit	Language: English/Français	English	Language and unit can be changed in this mode.
	Unit: US/Metric	US	
Lift Steering Column When Exiting Vehicle	ON/OFF	ON	<p>The steering column automatically tilts up when the driver gets out, and returns to the original position when the driver gets on.</p> <ul style="list-style-type: none"> <li>When driver door is closed and key removed from ignition key cylinder, the steering column tilts up.</li> <li>When driver door is open and key is turned to OFF, the steering column tilts up.</li> </ul>
Adjust Driver Seat When Exiting Vehicle	ON/OFF	ON	The driver's seat automatically slides backward when the driver gets out, and returns to the original position when the driver gets on.
Illuminate Interior When Unlocking Vehicle	ON/OFF	ON	The interior room lamps are illuminate automatically when the door unlocked with key or key fob.
Interior Lights Off Delay	OFF/15/30/45 sec.	30 sec.	Interior room lamp timer period can be changed in this mode. Selects interior room lamp timer.
Sensitivity of Automatic Headlights	1/2/3/4	3	Sensitivity of auto light sensor can be adjusted.
Automatic Headlights Off Delay	OFF/20/45/90/120/150/180 sec.	45 sec.	Auto light delay off timer period can be changed in this mode. Selects auto light delay off timer.
Keyless Remote Response - Horn/Lights	Hazard indicators only /Hazard indicators and horn	Hazard indicators only	<p>Hazard indicators Only:</p> <ul style="list-style-type: none"> <li>Lock operation: The hazard warning lamp flash twice when lock the doors with key fob.</li> <li>Unlock operation: No response.</li> </ul> <p>Hazard indicators and horn:</p> <ul style="list-style-type: none"> <li>Lock operation: The hazard warning lamp flash twice and horn sounds once when lock the doors with key fob.</li> <li>Unlock operation; The hazard warning lamp flash once when unlock the doors with key fob.</li> </ul>
Remote Custom Settings	ON/OFF	ON	<p>The driving position -seat and steering column- and the audio setting -current source and radio station presets- are set to the same condition you made last time by identifying the key fob ID.</p> <p>This function operates when unlock the doors by using the key fob.</p> <p><b>NOTE:</b> It is necessary to memorize the driving position before using this function.</p>
Return All Settings to Default	None	None	If this key is selected, all vehicle electronic systems setting are return to default.

## WARNING INDICATIONS

When combination meter receives warning signal from some control units or sensors, then combination meter warning lamp is illuminated.

Then combination meter sends warning signal to AV control unit to display warning indications on the screen.

Warning indicators	Warning lamps in instrument panel	Warning detection and cancel conditions		Cases of malfunction
DOOR OPEN	Door	Detection condition	Vehicle is running [approx. 5 km/h (3 MPH) or faster] and door ajar of any of the doors is detected.	Door is open
		Cancel condition	Vehicle is stopped and all the doors lock.	

# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM

## Precautions for AV Control Unit Replacement

AKS003ZR

The AV control unit has the following information stored in its memory. Record the memory contents before replacing the control unit, and input them in the new unit as necessary.


- |  |   |
|--|---|
| <p>&lt;FM-AM&gt;</p> <p>&lt;CD&gt;</p> <p>&lt;Sound quality&gt;</p> <p>&lt;Image quality&gt;</p> | <ul style="list-style-type: none"> <li>• Preset frequency</li> <li>• Area for indicating station, selection of overlapped stations</li> <li>• Program status</li> <li>• Volume balance memory set values</li> <li>• Equalizer memory set values</li> <li>• Brightness of light when ON/OFF</li> <li>• Dimming switching</li> <li>• Display color switching</li> </ul> |
|--|---|

### NOTE:

Only removing the battery does not erase the memory.

## Component Parts and Harness Connector and Harness Connector Location

AKS003ZS




SKIA9346E

# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM

## Schematic

AKS003ZT



TKWA0604E





# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM

## Wiring Diagram — INF/D —

AKS003ZU

DI-INF/D-06



REFER TO THE FOLLOWING.

(E205) -SUPER MULTIPLE JUNCTION (SMJ)

(E3) -FUSE, FUSIBLE LINK AND RELAY BLOCK (J/B)

A

B

C

D

E

F

G

H

I

J



DI

L

M

# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM

DI-INF/D-07








REFER TO THE FOLLOWING.  
 (M4) -ELECTRICAL UNITS

TKWA0606E

# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM

DI-INF/D-08




REFER TO THE FOLLOWING.  
 (M1) -FUSE BLOCK-JUNCTION BOX (J/B) NO.1

TKWA1233E

# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM

DI-INF/D-09



24	21	18	15	13	11	9	6	3
23	20	17	14	12	10	8	5	2
22	19	16		7	4	1		

(M78) W






24	22	20	18	16	14	10	8	6	4	2		
23	21	19	17	15	13	12	11	9	7	5	3	1

(M82) GY

TKWA0608E

# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM

DI-INF/D-10




TKWA0609E

# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM

## Schematic

AKS003ZV



(TP) : With low tire pressure warning system

(VC) : With voice activated control system

TKWA1234E


# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM

## Wiring Diagram — COMM —

AKS003ZW

### DI-COMM-01

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DI  
L  
M




REFER TO PG-POWER.

— : DATA LINE

TP : WITH LOW TIRE PRESSURE WARNING SYSTEM

VC : WITH VOICE ACTIVATED CONTROL SYSTEM



REFER TO THE FOLLOWING.



(M5), (E205) -SUPER MULTIPLE JUNCTION (SMJ)

(M1) -FUSE BLOCK-JUNCTION BOX (J/B) NO.1

(E3) -FUSE, FUSIBLE LINK AND RELAY BLOCK (J/B)

# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM

DI-COMM-02








TKWA1236E



# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM

DI-COMM-03









REFER TO THE FOLLOWING.





(M5) -SUPER MULTIPLE JUNCTION (SMJ)

# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM

DI-COMM-04



REFER TO THE FOLLOWING.  
 (B211) -SUPER MULTIPLE JUNCTION (SMJ)  
 (M1) -FUSE BLOCK-JUNCTION BOX (J/B) NO.1








TKWA1238E

# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM







## Terminals and Reference Value for AV Control Unit

AKS003ZX

Terminals			Signal	Signal input/output	Condition		Reference value
(+)		(-)			Ignition switch	Operation	
Terminal No.	Wire color						
1	B	Ground	Ground	—	ON	—	Approx. 0V
2	SB	Ground	Battery	Input	OFF	—	Battery voltage
3							
4	B	Ground	Ground	—	ON	—	Approx. 0V
6	L/B	Ground	Ignition switch (ACC)	Input	ACC	—	Battery voltage
10	—	—	Shield ground	—	—	—	—
11	R	10	Vertical synchronizing (VP) signal	Input	ON	—	 <p style="text-align: right; font-size: small;">SKIA0161E</p>
12	B	10	RGB area (YS) signal	Output	ON	Press the "info" switch.	 <p style="text-align: right; font-size: small;">SKIA0162E</p>
13	W	10	Horizontal synchronizing (HP) signal	Input	ON	Adjust sound volume while rear view screen is shown.	 <p style="text-align: right; font-size: small;">SKIA0163E</p>
14	—	Ground	RGB ground	—	—	—	—
15	G	10	RGB synchronizing signal	Output	ON	Press the "MAP" switch.	 <p style="text-align: right; font-size: small;">SKIA0164E</p>
18	R/L	14	RGB signal (R: red)	Output	ON	Select "SCREEN ADJUSTMENT" of CONFIRMATION/ADJUSTMENT function.	 <p style="text-align: right; font-size: small;">SKIA0165E</p>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DI  
L  
M

# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM

Terminals			Signal	Signal input/output	Condition		Reference value
(+)		(-)			Ignition switch	Operation	
Terminal No.	Wire color						
21	R/W	14	RGB signal (G: green)	Output	ON	Select "SCREEN ADJUSTMENT" of CONFIRMATION/ADJUSTMENT function.	 <small>SKIA0166E</small>
24	B	14	RGB signal (B: blue)	Output	ON	Select "SCREEN ADJUSTMENT" of CONFIRMATION/ADJUSTMENT function.	 <small>SKIA0167E</small>
25	R/L	Ground	Illumination control signal	Input	ON	Lighting switch ON (1st position)	Approx. 12V
						Lighting switch OFF	Approx. 0V
27	BR/W	Ground	Ignition switch (ON)	Input	ON	—	Battery voltage
31	—	—	Shield ground	—	—	—	—
33	OR/L	Ground	Vehicle speed signal (8-pulse)	Input	ON	When vehicle speed is approx. 40 km/h (25 MPH)	 <small>SKIA0168E</small>
34	LG	Ground	Communication signal (AV - ME)	Output	ON	Display the vehicle information screen.	 <small>SKIA0169E</small>
35	PU	Ground	Communication signal (ME - AV)	Input	ON	Perform various settings on the vehicle information screen.	 <small>SKIA0170E</small>
40	—	—	Shield ground	—	—	—	—
41	P	Ground	CONSULT-II communication signal (AV - CN)	Output	ON	Perform CONSULT-II.	 <small>SKIA0169E</small>

# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM








Terminals			Signal	Signal input/output	Condition		Reference value
(+)		(-)			Ignition switch	Operation	
Terminal No.	Wire color						
42	BR/Y	Ground	CONSULT-II communication signal (CN-AV)	Input	ON	Perform CONSULT-II.	<p style="text-align: right;">SKIA0170E</p>
43	L	Ground	A/C communication signal (AC-AV)	Input	ON	—	<p style="text-align: right;">SKIA0173E</p>
44	L/W	Ground	A/C communication signal (AV-AC)	Output	ON	—	<p style="text-align: right;">SKIA0172E</p>
45	L/R	Ground	A/C clock signal	Input	ON	—	<p style="text-align: right;">SKIA0174E</p>
46	—	—	Shield ground	—	—	—	—
47	W/R	Ground	Communication signal (+)	Input/output	ON	—	<p style="text-align: right;">SKIA0175E</p>
48	B/R	Ground	Communication signal (-)	Input/output	ON	—	<p style="text-align: right;">SKIA0176E</p>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DI  
L  
M





# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM

AKS003ZY

## Terminals and Reference Value for Display


Terminals		Signal	Condition		Reference value
Terminal No.	Wire color		Ignition switch	Operation	
1	R/L	RGB signal (R: Red)	ON	Move to "Screen Adjustment" in the check/adjustment function.	 <p style="text-align: right;">SKIA0165E</p>
2	R/W	RGB signal (G: Green)	ON	Move to "Screen Adjustment" in the check/adjustment function.	 <p style="text-align: right;">SKIA0166E</p>
3	B	RGB signal (B: Blue)	ON	Move to "Screen Adjustment" in the check/adjustment function.	 <p style="text-align: right;">SKIA0167E</p>
4	—	RGB ground	ON	—	Approx. 0V
5	W	Horizontal synchronizing signal	ON	ON screen, the volume can be adjusted.	 <p style="text-align: right;">SKIA0163E</p>
6	R	Vertical synchronizing signal	ON	—	 <p style="text-align: right;">SKIA0161E</p>
7	G	RGB synchronizing signal	ON	Press the map switch.	 <p style="text-align: right;">SKIA0164E</p>
8	B	RGB area signal	ON	Press the vehicle information switch.	 <p style="text-align: right;">SKIA0162E</p>

# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM




Terminals		Signal	Condition		Reference value
Terminal No.	Wire color		Ignition switch	Operation	
12	B/R	Communication signal (-)	ON	—	 SKIA0176E
13	W/R	Communication signal (+)	ON	—	 SKIA0175E
14	—	Shield ground	—	—	—
15	L	Communication signal (-)	ON	—	 SKIA0176E
16	R	Communication signal (+)	ON	—	 SKIA0175E
17	—	Shield ground	—	—	—
19	L/B	Ignition switch (ACC)	ACC	—	Battery voltage
21	SB	Battery power	OFF	—	Battery voltage
23					
22	B	Ground	—	—	—
24					

## Terminals and Reference Value for Multifunction Switch

AKS003ZZ

Terminals		Signal	Condition		Reference value
Terminal No.	Wire color		Ignition switch	Operation	
1	L/B	Ignition switch (ACC)	ACC	—	Battery voltage
2	B	Ground	ON	—	Approx. 0V
9	R	Communication signal (+)	ON	—	 SKIA0175E

# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM

Terminals		Signal	Condition		Reference value
Terminal No.	Wire color		Ignition switch	Operation	
10	L	Communication signal (-)	ON	—	 <p style="text-align: right; font-size: small;">SKIA0176E</p>
11	—	Shield ground	—	—	—
15	Y	Communication signal (+)	ON	—	 <p style="text-align: right; font-size: small;">SKIA0175E</p>
16	BR	Communication signal (-)	ON	—	 <p style="text-align: right; font-size: small;">SKIA0176E</p>
17	—	Shield ground	—	—	—

## On Board Self-Diagnosis Function (Without CONSULT-II) DESCRIPTION

AKS00400

- Diagnosis function consists of the self-diagnosis mode performed automatically and the CONFIRMATION/ADJUSTMENT mode operated manually.
- Self-diagnosis mode checks for connections between the units constituting this system, analyzes each individual unit at the same time, and displays the results on the LCD screen.
- CONFIRMATION/ADJUSTMENT mode is used to perform trouble diagnosis that require operation and judgment by an operator (trouble that cannot be automatically judged by the system), to check/change the set value, and to display the History of Errors of the navigation system.

## DIAGNOSIS ITEM

Mode	Description										
Self-Diagnosis	<ul style="list-style-type: none"> <li>● AV control unit diagnosis (DVD-ROM drive will not be diagnosed when no map DVD-ROM is in it.).</li> <li>● Analyzes connection between the AV control unit and the GPS antenna connection between the AV control unit and each unit, and operation of each unit.</li> </ul>										
CONFIRMATION/ ADJUSTMENT	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 30%;">Display Diagnosis</td> <td>Color tone and shading of the screen can be checked by the display of a color bar and a gray scale.</td> </tr> <tr> <td>Vehicle Signals</td> <td>Analyzes the following vehicle signals: Vehicle speed signal, parking brake signal, light signal, ignition switch signal, and reverse signal.</td> </tr> <tr> <td>Speaker Test</td> <td>Checks the connection of each speaker using a test tone.</td> </tr> <tr> <td>Auto Climate Control</td> <td>Turns all A/C screens on display and A/C switch indicator lamp on.</td> </tr> <tr> <td>Rear View Camera</td> <td>Changes position of the aiming line overlapped on the rear view image.</td> </tr> </table>	Display Diagnosis	Color tone and shading of the screen can be checked by the display of a color bar and a gray scale.	Vehicle Signals	Analyzes the following vehicle signals: Vehicle speed signal, parking brake signal, light signal, ignition switch signal, and reverse signal.	Speaker Test	Checks the connection of each speaker using a test tone.	Auto Climate Control	Turns all A/C screens on display and A/C switch indicator lamp on.	Rear View Camera	Changes position of the aiming line overlapped on the rear view image.
Display Diagnosis	Color tone and shading of the screen can be checked by the display of a color bar and a gray scale.										
Vehicle Signals	Analyzes the following vehicle signals: Vehicle speed signal, parking brake signal, light signal, ignition switch signal, and reverse signal.										
Speaker Test	Checks the connection of each speaker using a test tone.										
Auto Climate Control	Turns all A/C screens on display and A/C switch indicator lamp on.										
Rear View Camera	Changes position of the aiming line overlapped on the rear view image.										




# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM


AKS00401

## Self-Diagnosis Mode OPERATION PROCEDURE


1. Start the engine.
2. Turn the audio system off.
3. While pressing the "INFO" switch, turn the volume control dial clockwise or counterclockwise for 30 clicks or more. (When the self-diagnosis mode is started, a short beep will be heard.)
  - Shifting from current screen to previous screen is performed by pressing "PREV" switch.




4. The initial trouble diagnosis screen will be shown, and items "SELF DIAGNOSIS" and "Confirmation/Adjustment" will become selective.



5. Perform self-diagnosis by selecting the "SELF DIAGNOSIS".
  - Self-diagnosis subdivision screen will be shown and the operation enters the self-diagnosis mode.
  - A bar graph shown below the self-diagnosis subdivision screen indicates progress of the diagnosis.



6. When the self-diagnosis completes, optional part confirmation screen will be shown.
  - When connection of an optional part is judged faulty, a screen to check if the optional part is actually fitted on the vehicle or not will be shown. When fitted, select the switch of the part on the screen and press "END". Then the "SELF DIAGNOSIS" screen will be shown.
  - When the optional part is connected normally, the switch for the part will not appear on the screen.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DI  
L  
M

# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM


7. On the “SELF DIAGNOSIS” screen, each unit name will be colored according to the diagnosis result, as follows.

- Green** : No malfunctioning.
- Yellow** : Cannot be judged by self–diagnosis results.
- Red** : Unit is malfunctioning.

- If several malfunctions are present in a unit, color of its switch on the screen will be either red or yellow determined by the malfunction of the highest priority.


**CAUTION:**

“Tire Pressure Control Unit” on the screen will be illuminated in yellow when performing self-diagnosis with ignition switch in ACC position.



8. Select a switch on the “SELF DIAGNOSIS” screen and comments for the diagnosis results will be shown.

- When the switch is green, the following comment will be shown. “Self-diagnosis was successful. Further diagnosis and adjustments are recommended. Follow the “confirmation and adjustments” menu or refer to the service manual.”.
- When the switch is yellow, the following comment will be shown. “Connection to the following unit is abnormal. See the Service Manual for further details”.
- When the switch is red, the following comment will be shown. “Center Control Unit is abnormal”.



## SELF-DIAGNOSIS RESULT

### Quick Reference Table

1. Select an applicable diagnosis No. in the diagnosis result quick reference table.
2. Find estimated malfunctioning system in the diagnosis No. table and perform check by referring to [DI-103, "Wiring Diagram — COMM —"](#).
3. Turn the ignition switch to OFF and perform self-diagnosis again.

Switch color	Screen switch							Diagnosis No.
	Center control unit*1	Display	Tire pressure control unit	Audio unit	CD auto changer	Audio amp.*2	Voice activated control module	
Red	×							1
Yellow	×	×						2
	×		×					3
	×			×	×			4
	×				×			5
	×						×	6
	×					×		7
	×			×	×	×		8

- \*1: Center control unit = AV control unit
- \*2: Audio amp. = BOSE speaker amp.

**CAUTION:**

- When multifunction switch has a malfunction, you can not start.
- Check the following when the self–diagnosis mode you can not use.
  - AV communication line between AV control unit and Display, AV communication line between Display and multifunction switch.
  - multifunction switch power supply and ground circuit
- When an error is in the AV communication line, it cannot be detected on the screen because self–diagnosis is inoperative. However, the error can be detected with CONSULT-II.

# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM


## Self-Diagnosis Codes

Diagnosis No.	Possible cause
1	AV control unit malfunction
2	Display power supply and ground circuit
3	<ul style="list-style-type: none"> <li>● Low tire pressure warning control unit power supply and ground circuit,</li> <li>● AV communication line between low tire pressure warning control unit and multifunction switch.</li> </ul>
4	Audio unit power supply and ground circuit
5	<ul style="list-style-type: none"> <li>● CD auto changer power supply and ground circuit</li> <li>● AV communication line between CD auto changer and audio unit.</li> </ul>
6	Voice activated control module power supply and ground circuit.
7	<ul style="list-style-type: none"> <li>● BOSE speaker amp. power supply and ground circuit.</li> <li>● AV communication line between BOSE speaker amp. and audio unit.</li> <li>● BOSE speaker amp. internal communication circuit.</li> </ul>
8	<ul style="list-style-type: none"> <li>● AV communication line between audio unit and multifunction switch.</li> <li>● Audio control unit communication circuit.</li> </ul>


## Confirmation/Adjustment Mode OPERATION PROCEDURE

AKS00402


1. Start the engine.
2. Turn the audio system off.
3. While pressing the "INFO" switch, turn the volume control dial clockwise or counterclockwise for 30 clicks or more. (When the self-diagnosis mode is started, a short beep will be heard.)
  - Shifting from current screen to previous screen is performed by pressing "PREV" switch.



4. The initial trouble diagnosis screen will be shown, and items "SELF DIAGNOSIS" and "Confirmation/Adjustment" will become selective.




5. When "Confirmation/Adjustment" is selected on the initial trouble diagnosis screen, the operation will enter the CONFIRMATION/ADJUSTMENT mode. In this mode, check and adjustment of each item will become possible.
6. Select each switch on "Confirmation/Adjustment" screen to display the relevant diagnosis screen.



# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM

## DISPLAY DIAGNOSIS



### CAUTION:

When **DISPLAY COLOR SPECTRUM BAR** screen is completed after “PREV” switch is pressed, the screen color changes once. This is not abnormal.

- When RGB signal error occurred in the RGB system, tone of the color bar will change as follows.

**R (red) signal error** : Screen looks bluish


**G (green) signal error** : Screen looks yellowish

**B (blue) signal error** : Screen looks reddish

- When the color of the screen looks unusual, refer to [DI-125, "Color of RGB Image is Not Proper"](#) .

## VEHICLE SIGNALS

- A comparison check can be made of each actual vehicle signal and the signals recognized by the system.



Diagnosis item	Display	Condition	Remarks
Vehicle Speed	ON	Vehicle speed > 0 km/h (0 MPH)	Changes in indication may be delayed by approx. 1.5 seconds. This is normal.
	OFF	Vehicle speed = 0 km/h (0 MPH)	
	—	Ignition switch in ACC position	
Light	ON	Lighting switch ON	—
	OFF	Lighting switch OFF	
IGN	ON	Ignition switch ON	—
	OFF	Ignition switch ACC or OFF	

- If vehicle speed is NG, refer to [DI-122, "Vehicle Speed Signal Inspection"](#) .
- If light is NG, refer to [DI-123, "Illumination Control Signal Inspection"](#) .
- If IGN is NG, refer to [DI-124, "Ignition Signal Inspection"](#) .

# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM

## AUTO CLIMATE CONTROL


- Refer to ATC Automatic Air Conditioner [ATC-49, "Self-Diagnosis Function"](#) for the details.

## CONSULT-II Function


AKS00403

### CONSULT-II BASIC OPERATION PROCEDURE


1. With the ignition switch OFF, connect "CONSULT-II" and "CONSULT-II CONVERTER" to the data link connector, and turn the ignition switch ON.



2. Touch "START(NISSAN BASED VHCL)".



3. Touch "MULTIAV" on "SELECT SYSTEM" screen.  
If "MULTIAV" is not indicated, go to [GI-38, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).
4. Select "VIRSION", "SELF-DIAG RESULTS" or "SIGNAL MONITOR".



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DI  
L  
M

# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM

## SELF-DIAG RESULTS

- Checks for connection between each unit and analyzes each individual unit, then displays the results on the screen.

### Items Shown

Items shown	Malfunctioning part/reference page
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	-
HEAD UNIT ABNORMAL	AV control unit malfunction
PANEL SW ABNORMAL CONNECTION	Refer to <a href="#">DI-114, "Quick Reference Table"</a> .
AUDIO HEAD UNIT ABNORMAL CONNECTION	
AIR COMP RECEIVER ABNORMAL CONNECTION	
BOSE AMP ABNORMAL CONNECTION	
BOSE AMP ABNORMAL	BOSE speaker amp. malfunction
VOICE UNIT ABNORMAL CONNECTION	Refer to <a href="#">DI-114, "Quick Reference Table"</a> .
VOICE UNIT ABNORMAL	Voice activated control module malfunction.
REAR VIEW CAMERA ABNORMAL CONNECTION	See note.
PANEL SW ABNORMAL CONNECTION (MULTIFUNCTION SW)	Refer to <a href="#">DI-114, "Quick Reference Table"</a> .
IVCS ABNORMAL CONNECTION	See note.

### NOTE:

When “IVCS ABNORMAL CONNECTION” and “REAR VIEW CAMERA ABNORMAL CONDITION” are indicated, it does not malfunction.

### DATA MONITOR

- Displays status of the vehicle signal input to the AV control unit. (Refer to [DI-115, "Confirmation/Adjustment Mode"](#) for operation conditions for the connections to be indicated.)

DATA MONITOR			
MONITOR	NO DTC		
VHCL SPD SIG		OFF	
BRAKE		ON	
MTR ILL DIM		OFF	
IGN SW		ON	
NAVI ON SIG		OFF	
		RECORD	
MODE	BACK	LIGHT	COPY

SKIA4181E


- For each signal, a comparison of actual operating status and the status recognized by the system can be checked.

DATA MONITOR item	Display	Condition	Remarks
VHCL SPD SIG	ON	Vehicle speed > 0 km/h (0 MPH)	Changes in indication may be delayed by approx. 1.5 seconds. This is normal.
	OFF	Vehicle speed = 0 km/h (0 MPH)	
	—	Ignition switch in ACC position	
BRAKE	ON	—	This item cannot be monitored. (No change of display)
MTR ILL DIM	ON	Lighting switch ON	—
	OFF	Lighting switch OFF	
IGN SW	ON	Ignition switch ON	—
	OFF	Ignition switch ACC or OFF	
NAVI ON SIG	OFF	—	This item cannot be monitored. (No change of display)

# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM

## VERSION

Displays version of each unit connected to the AV control unit.



Version display	Remarks
"PANEL SW"	Multifunction switch
"HEAD UNIT"	AV control unit
"REAR VIEW CAMERA"	—
"FRONT SEAT DISPLAY"	Display
"AUDIO HEAD UNIT"	—
"AIR COMP RECEIVER"	Low Tire Pressure Warning Control Unit
"BOSE AMP"	—
"IVCS"	—
"VOICE UNIT"	Voice Activated Control Module

## Multifunction Switch Self-Diagnosis Function


AKS00404

It can check ON/OFF operation of each switch in the multifunction switch and diagnose the input signals to the rear control switch (audio) and steering switch (audio).

### STARTING THE SELF-DIAGNOSIS MODE

1. Turn ignition switch from OFF to ACC.
2. Within 10 seconds press and hold the function switches "1" and "6" simultaneously for 5 seconds.

Then the self-diagnosis operates.



### EXITING THE SELF-DIAGNOSIS MODE

- Turn ignition switch OFF, or press and hold the function switches "1" and "6" simultaneously for 5 seconds. Then the self-diagnosis ends.

### DIAGNOSIS FUNCTION

- It can illuminate all the indicators (LED) in the multifunction switch.
- It can check for continuity of the switches by sounding the buzzer when the multifunction switch is pressed.
- It can check for continuity of harness between multifunction switch and rear control switch (audio), or steering switch (audio).

# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM

## Power Supply and Ground Circuit Inspection for AV Control Unit

AKS00401

### 1. CHECK FUSE

Check AV control unit fuses are not blown.

Unit	Power source	Fuse No.
AV control unit	Battery power	52
	Ignition switch ACC or ON	21

OK or NG


OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-2, "POWER SUPPLY ROUTING"](#) .

### 2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect AV control unit connector.
2. Check voltage between AV control unit and ground.

Terminals		Ignition switch position			
Connector	(+)	(-)	OFF	ACC	ON
	Terminal (Wire color)				
M78	2 (SB)	Ground	Battery voltage	Battery voltage	Battery voltage
	3 (SB)	Ground	Battery voltage	Battery voltage	Battery voltage
	6 (L/B)	Ground	0V	Battery voltage	Battery voltage



OK or NG

OK >> GO TO 3.

NG >> Check harness for open or short between AV control unit and fuse.

### 3. CHECK GROUND CIRCUIT


1. Turn ignition switch OFF.
2. Check continuity between AV control unit harness connector M78 terminals 1 (B), 4 (B) and ground.

**Continuity should exist.**

OK or NG

OK >> Inspection end.

NG >> Repair harness or connector.





# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM

## Power Supply and Ground Circuit Inspection for Display

AKS0040J

### 1. CHECK FUSES

Check the followings.

- 15A fuse [No. 52, located in fuse, fusible link and relay block (J/B)] is blown
- 10A fuse [No. 21, located in fuse block (J/B) NO. 1] is blown

OK or NG


OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-2](#), "POWER SUPPLY ROUTING".

### 2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect display connector.
2. Check voltage between display harness connector M82 terminals and ground.

Terminals		Ignition switch position			
(+)		(-)	OFF	ACC	ON
Connector	Terminal (Wire color)				
M82	19 (L/B)	Ground	0V	Battery voltage	Battery voltage
	21 (SB)	Ground	Battery voltage	Battery voltage	Battery voltage
	23 (SB)	Ground	Battery voltage	Battery voltage	Battery voltage



OK or NG

OK >> GO TO 3.

NG >> Check harness for open or short between display and fuse.

### 3. CHECK GROUND CIRCUIT


1. Turn ignition switch OFF.
2. Check continuity between display harness connector M82 terminals 22 (B), 24 (B) and ground.

**Continuity should exist.**

OK or NG

OK >> Inspection end.

NG >> Repair harness or connector.



# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM

## Inspection of Multifunction Switch for Power Supply and Ground Circuit

AKS0040K

### 1. CHECK POWER SUPPLY CIRCUIT


1. Disconnect multifunction switch connector.
2. Check voltage between multifunction switch harness connector M83 terminal 1 (L/B) and ground.

Terminals		Ignition switch position			
Connector	(+)	(-)	OFF	ACC	ON
	Terminal (wire color)				
M83	1 (L/B)	Ground	0V	Battery voltage	Battery voltage

OK or NG

OK >> GO TO 2.

NG >> Check harness for open or short between multifunction switch and fuse.



### 2. CHECK GROUND CIRCUIT


1. Turn ignition switch OFF.
2. Check continuity between multifunction switch harness connector M83 terminal 2 (B) and ground.

**Continuity should exist.**

OK or NG

OK >> Inspection end.

NG >> Repair harness or connector.



## Vehicle Speed Signal Inspection

AKS0040L

### 1. CHECK HARNESS

1. Disconnect connectors of AV control unit and combination meter.
2. Check continuity between AV control unit harness connector M77 terminal 33 (OR/L) and combination meter harness connector M41 terminal 37 (OR/L).

**Continuity should exist.**

3. Check continuity between AV control unit harness connector M77 terminal 33 (OR/L) and ground.


**Continuity should not exist.**

OK or NG

OK >> GO TO 2.

NG >> ● Check connector housings for disconnected or loose terminals.

- Repair harness or connector.



# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM


## 2. VEHICLE SPEED SIGNAL CHECK 1

1. Connect AV control unit connector.
2. Turn ignition switch ON.
3. Check voltage between AV control unit harness connector M77 terminal 33 (OR/L) and ground.

**Approx. 5V**

OK or NG

- OK >> GO TO 3.  
 NG >> Replace AV control unit.




## 3. VEHICLE SPEED SIGNAL CHECK 2

1. Connect combination meter connector.
2. Start engine and drive vehicle at more than 40 km/h (25 MPH).
3. Check voltage signal between AV control unit harness connector M77 terminal 33 (OR/L) and ground.

**33 (OR/L) - Ground** : Refer to [DI-107, "Terminals and Reference Value for AV Control Unit"](#) .

OK or NG

- OK >> Replace AV control unit.  
 NG >> Check combination meter. Refer to [DI-16, "Vehicle Speed Signal Inspection"](#) .



## Illumination Control Signal Inspection

AKS0040M


### 1. CHECK ILLUMINATION CONTROL SIGNAL

1. Turn ignition switch ON.
2. Check voltage between AV control unit harness connector M77 terminal 25 (B/L) and ground.

Terminals		(-)	Lighting switch condition	Voltage (V)
(+) Connector				
Terminal (Wire color)				
M77	25 (R/L)	Ground	ON (1st position)	Approx. 12V
			OFF	Approx. 0V

OK or NG

- OK >> Replace AV control unit.  
 NG >> Check harness for open or short between AV control unit and BCM.



# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM


## Ignition Signal Inspection

AKS0040N

### 1. CHECK IGNITION SIGNAL

1. Disconnect AV control unit connector.
2. Check voltage between AV control unit harness connector M77 terminal 27 (BR/W) and ground.

Terminals		Ignition switch position			
(+)		(-)	OFF	ACC	ON
Connector	Terminal (Wire color)				
M77	27 (BR/W)	Ground	0V	0V	Battery voltage



OK or NG

OK >> Replace AV control unit.

NG >> Check harness for open or short between AV control unit and fuse.

## RGB Screen is Not Shown

AKS0040O

### 1. CHECK HARNESS

1. Disconnect connectors of AV control unit and display.
2. Check continuity between AV control unit harness connector M78 terminal 12 (B) and display harness connector M82 terminal 8 (B).


**Continuity should exist.**

3. Check continuity between AV control unit harness connector M78 terminal 13 (W) and display harness connector M82 terminal 5 (W).

**Continuity should exist.**

4. Check continuity between AV control unit harness connector M78 terminal 12 (B), 13 (W) and ground.

**Continuity should not exist.**



OK or NG

OK >> GO TO 2.


NG >> ● Check connector housings for disconnected or loose terminals.

- Repair harness or connector.

### 2. CHECK HORIZONTAL SYNCHRONIZATION SIGNAL

1. Connect connectors of AV control unit and display.
2. Turn ignition switch ON.
3. Check voltage signal between AV control unit harness connector M78 terminals 13 (W) and 10.

**13 (W) - 10 : Refer to [DI-107, "Terminals and Reference Value for AV Control Unit"](#) .**



OK or NG

OK >> GO TO 3.

NG >> Replace display.


## 3. CHECK RGB AREA SIGNAL

1. Press "INFO" switch.
2. Check voltage signal between AV control unit harness connector M78 terminals 12 (B) and 10.

**12 (B) - 10** : Refer to [DI-107, "Terminals and Reference Value for AV Control Unit"](#) .

OK or NG

- OK >> Replace display.
- NG >> Replace AV control unit.



AKS0040P

## Color of RGB Image is Not Proper

### 1. CHECK COLOR BAR DIAGNOSIS

Check color tone by "SCREEN ADJUSTMENT" of CONFIRMATION/ADJUSTMENT function.

OK or NG

- OK >> Inspection end.
- NG >> GO TO 2.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DI  
L  
M

# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM

## 2. CHECK HARNESS

1. Turn ignition switch OFF.
2. Disconnect connectors of AV control unit and display.
3. Check continuity as follows.

● **When the screen looks bluish**

Terminals				Continuity
AV control unit		Display		
Connector	Terminal (Wire color)	Connector	Terminal (Wire color)	
M78	18 (R/L)	M82	1 (R/L)	Yes
	14		4	Yes

Terminals			Continuity
(+)		(-)	
Connector	Terminal (Wire color)		
M78	14, 18 (R/L)	Ground	No

● **When the screen looks reddish**




Terminals				Continuity
AV control unit		Display		
Connector	Terminal (Wire color)	Connector	Terminal (Wire color)	
M78	21 (R/W)	M82	2 (R/W)	Yes
	14		4	Yes

Terminals			Continuity
(+)		(-)	
Connector	Terminal (Wire color)		
M78	14, 21 (R/W)	Ground	No

● **When the screen looks yellowish**

Terminals				Continuity
AV control unit		Display		
Connector	Terminal (Wire color)	Connector	Terminal (Wire color)	
M78	24 (B)	M82	3 (B)	Yes
	14		4	Yes

Terminals			Continuity
(+)		(-)	
Connector	Terminal (Wire color)		
M78	14, 24 (B)	Ground	No



OK or NG

OK >> GO TO 3.

NG >> ● Check connector housings for disconnected or loose terminals.

- Repair harness or connector.

# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM

## 3. CHECK RGB SIGNAL

1. Connect connectors of AV control unit and display.
2. Turn ignition switch ON.
3. Display "Color bar" by "CONFIRMATION/ADJUSTMENT" mode.
4. Check the following with CONSULT-II or oscilloscope.

- **When the screen looks bluish**

Voltage signal between AV control unit harness connector M78 terminals 18 (R/L) and 14

**18 (R/L) - 14** : Refer to [DI-107, "Terminals and Reference Value for AV Control Unit"](#) .

- **When the screen looks reddish**


Voltage signal between AV control unit harness connector M78 terminals 21 (R/W) and 14

**21 (R/W) - 14** : Refer to [DI-107, "Terminals and Reference Value for AV Control Unit"](#) .

- **When the screen looks yellowish**

Voltage signal between AV control unit harness connector M78 terminals 24 (B) and 14

**24 (B) - 14** : Refer to [DI-107, "Terminals and Reference Value for AV Control Unit"](#) .



OK or NG

- OK >> Replace display.
- NG >> Replace AV control unit.

## RGB Screen is Rolling

AKS0040Q


### 1. CHECK HARNESS

1. Disconnect connectors of AV control unit and display.
2. Check continuity between AV control unit harness connector and display harness connector.

Terminals				Continuity
AV control unit		Display		
Connector	Terminal (Wire color)	Connector	Terminal (Wire color)	
M78	15 (G)	M82	7 (G)	Yes
	10		4	

3. Check continuity between AV control unit harness connector and ground.

Terminals			Continuity
(+)		(-)	
Connector	Terminal (Wire color)		
M78	15 (G)	Ground	No
	10		



OK or NG

- OK >> GO TO 2.
- NG >>
  - Check connector housings for disconnected or loose terminals.
  - Repair harness or connector.

# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM

## 2. CHECK RGB SYNCHRONIZING SIGNAL

1. Connect connectors of AV control unit and display.
2. Turn ignition switch ON.
3. Check voltage signal between AV control unit harness connector M78 terminals 15 (G) and 10.

**15 (G) - 10** : Refer to [DI-107, "Terminals and Reference Value for AV Control Unit"](#) .

OK or NG

- OK >> Replace display.  
NG >> Replace AV control unit.

## No A/C Display is Shown

### 1. CHECK HARNESS

1. Disconnect connectors of A/C auto amp. and AV control unit.
2. Check continuity between A/C auto amp. harness connector M119 terminal 9 (W) and AV control unit harness connector M77 terminal 44 (W).

**Continuity should exist.**

3. Check continuity between A/C auto amp. harness connector M119 terminal 20 (B) and AV control unit harness connector M77 terminal 45 (B).

**Continuity should exist.**

4. Check continuity between AV control unit harness connector M77 terminals 44 (W), 45 (B) and ground.

**Continuity should not exist.**

Ok or NG

- OK >> GO TO 2.  
NG >> ● Check connector housings for disconnected or loose terminals.  
● Repair harness or connector.


## 2. CHECK A/C-AV, AC-CLK COMMUNICATION SIGNAL

1. Connect A/C auto amp. connector.
2. Turn ignition switch ON.
3. Check voltage between AV control unit harness connector M77 terminals 44 (W), 45 (B) and ground.



**Approx. 5V**

OK or NG

- OK >> GO TO 3.  
NG >> Replace A/C auto amp.



AKS0040R





# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM

## 3. CHECK A/C-AV, AC-CLK COMMUNICATION SIGNAL

1. Connect AV control unit connector.
2. Turn ignition switch ON.
3. Check voltage signal between AV control unit harness connector M77 terminals 44 (W), 45 (B) and ground.

**44 (W), 45 (B) - Ground** :Refer to [DI-107, "Terminals and Reference Value for AV Control Unit"](#)

OK or NG

- OK >> Replace A/C auto amp.  
NG >> Replace AV control unit.

## A/C Operation is Not Possible

### 1. CHECK HARNESS

1. Turn ignition switch OFF.
2. Disconnect connectors of A/C auto amp. and AV control unit.
3. Check continuity between A/C auto amp. harness connector M119 terminal 10 (R) and AV control unit harness connector M77 terminal 43 (R).

**Continuity should exist.**

4. Check continuity between A/C auto amp. harness connector M119 terminal 20 (B) and AV control unit harness connector M77 terminal 45 (B).

**Continuity should exist.**

5. Check continuity between AV control unit harness connector M77 terminals 43 (R), 45 (B) and ground.

**Continuity should not exist.**

OK or NG

- OK >> GO TO 2.  
NG >> ● Check connector housings for disconnected or loose terminals.  
● Repair harness or connector.


## 2. CHECK AV-A/C, AC-CLK COMMUNICATION SIGNAL

1. Connect A/C auto amp. connector.
2. Turn ignition switch ON.
3. Check voltage between AV control unit harness connector M77 terminal 43 (R) and ground.



**Approx. 5V**

OK or NG

- OK >> GO TO 3.  
NG >> Replace A/C auto amplifier.



AKS0040S



# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM


## 3. CHECK AV-A/C, AC-CLK COMMUNICATION SIGNAL

1. Connect AV control unit connector.
2. Turn ignition switch ON.
3. Check voltage between AV control unit harness connector M77 terminals 43 (R), 45 (B) and ground with CONSULT-II or oscilloscope.

**43 (R), 45 (B) - Ground** : Refer to [DI-107, "Terminals and Reference Value for AV Control Unit"](#)

OK or NG

- OK >> Replace A/C auto amp.  
NG >> Replace AV control unit.



## No Fuel Information is Displayed/No Warning Message is Displayed

AKS0040G

### 1. CHECK HARNESS

1. Disconnect connectors of AV control unit, combination meter and BCM.
2. Check continuity between AV control unit harness connector M77 terminal 34 (LG) and combination meter harness connector M42 terminal 56 (LG).

**Continuity should exist.**

3. Check continuity between AV control unit harness connector M77 terminal 35 (PU) and combination meter harness connector M42 terminal 57 (PU).


**Continuity should exist.**

4. Check continuity between AV control unit harness connector M77 terminals 34 (LG), 35 (PU) and ground.

**Continuity should not exist.**

OK or NG

- OK >> GO TO 2.  
NG >> ● Check connector housings for disconnected or loose terminals.  
● Repair harness or connector.




### 2. CHECK COMMUNICATION SIGNAL (AV-ME)

1. Connect combination meter connector, BCM connector and AV control unit connector.
2. Turn ignition switch ON.
3. Check voltage signal between AV control unit harness connector M77 terminal 34 (LG) and ground with CONSULT-II or oscilloscope.

**34 (LG) - Ground** : Refer to [DI-107, "Terminals and Reference Value for AV Control Unit"](#) .

OK or NG

- OK >> GO TO 3.  
NG >> Replace AV control unit.




# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM

## 3. CHECK COMMUNICATION SIGNAL (ME-AV)

1. Turn ignition switch to ON and display "VEHICLE ELECTRONIC SYSTEMS" screen.
2. Check voltage signal between AV control unit harness connector M77 terminal 35 (PU) and ground with CONSULT-II or oscilloscope.

**35 (PU) - Ground** : Refer to [DI-107, "Terminals and Reference Value for AV Control Unit"](#) .



### OK or NG

- OK >> Replace AV control unit.  
NG >> Replace combination meter.

## Vehicle Condition Setting is Not Possible

### 1. CHECK HARNESS

1. Disconnect connectors of AV control unit, combination meter and BCM.
2. Check continuity AV control unit harness connector M77 terminal 34 (LG) and BCM harness connector M4 terminal 31 (LG).


**Continuity should exist.**

3. Check continuity AV control unit harness connector M77 terminal 35 (PU) and BCM harness connector M4 terminal 30 (PU).

**Continuity should exist.**

4. Check continuity between AV control unit harness connector M77 terminals 34 (LG), 35 (PU) and ground.

**Continuity should not exist.**




### OK or NG

- OK >> GO TO 2.  
NG >> ● Check connector housings for disconnected or loose terminals.  
● Repair harness or connector.

## 2. CHECK COMMUNICATION SIGNAL (AV-ME)

1. Connect AV control unit connector, combination meter connector and BCM connector.
2. Turn ignition switch ON.
3. Check voltage signal between AV control unit harness connector M77 terminal 34 (LG) and ground with CONSULT-II or oscilloscope.

**34 (LG) - Ground** : Refer to [DI-107, "Terminals and Reference Value for AV Control Unit"](#) .



### OK or NG

- OK >> GO TO 3.  
NG >> Replace AV control unit.

# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM


## 3. CHECK COMMUNICATION SIGNAL (ME-AV)

1. Turn ignition switch to ON and display "VEHICLE ELECTRONIC SYSTEMS" screen.
2. Check voltage signal between AV control unit harness connector M77 terminal 35 (PU) and ground with CONSULT-II or oscilloscope.

**35 (PU) - Ground** : Refer to [DI-107, "Terminals and Reference Value for AV Control Unit"](#) .

OK or NG

- OK >> Replace AV control unit.  
NG >> Replace BCM.



## Multifunction Switch does Not Operate

AKS004DJ

### 1. MULTIFUNCTION SWITCH SELF-DIAGNOSIS

Perform multifunction switch self-diagnosis. Refer to [DI-119, "Multifunction Switch Self-Diagnosis Function"](#) .  
Is self-diagnosis result OK?

- OK >> GO TO 2.  
NG >> Replace multifunction switch.

### 2. CHECK POWER AND GROUND CIRCUIT

Check power and ground circuit. Refer to [DI-122, "Inspection of Multifunction Switch for Power Supply and Ground Circuit"](#) .

OK or NG

- OK >> GO TO 3.  
NG >> Repair harness or connector.

### 3. COMMUNICATION CIRCUIT SELF-DIAGNOSIS

Perform the self-diagnosis mode in the self-diagnosis function (If the self-diagnosis cannot be activated with the multifunction switch, check with CONSULT-II). Refer to [DI-113, "Self-Diagnosis Mode"](#) .

Is self-diagnosis result OK?

- OK >> Replace display.  
NG >> With the self-diagnosis results, check the malfunction part.

## Multifunction Switch Indicator does not Illuminate

AKS004DK

### 1. MULTIFUNCTION SWITCH SELF-DIAGNOSIS

Perform the multifunction switch self-diagnosis. Refer to [DI-119, "Multifunction Switch Self-Diagnosis Function"](#) .

Is the self-diagnosis result OK?


- OK >> Replace switch of the malfunctioning indicator.  
NG >> Replace multifunction switch.

# VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM


## Removal and Installation of AV Control Unit

### REMOVAL

1. Remove cluster lid C. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#) .
2. Remove warning chime. Refer to [DI-64, "Removal and Installation of Warning Chime"](#) .
3. Remove tire pressure warning control unit. Refer to [WT-8, "TIRE PRESSURE WARNING CONTROL UNIT"](#) .
4. Remove screws (2), and remove AV control unit with power tool.



5. Remove screws (4), and remove bracket.




### INSTALLATION

Install in the reverse order of removal.


## Removal and Installation of Display

### REMOVAL

1. Remove cluster lid C. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#) .
2. Remove screws (4), and remove display.



3. Remove screws (4), and remove bracket.




### INSTALLATION

Install in the reverse order of removal.

## Disassembly and Assembly of Multifunction Switch

AKS0040L



PKIA1671E

- |                                    |                         |                    |
|------------------------------------|-------------------------|--------------------|
| 1. Multifunction switch            | 2. Escutcheon           | 3. Hazard switch   |
| 4. Defroster, rear defogger switch | 5. Function switch      | 6. Function switch |
| 7. Function switch                 | 8. TAPE and DISC switch | 9. A/C switch      |
| 10. Escutcheon                     | 11. AM and FM switch    | 12. Escutcheon     |
| 13. Switch assembly                | 14. Escutcheon          | 15. Cluster lid C  |

### DISASSEMBLY

1. Remove screw (8).
2. Remove switches.

### ASSEMBLY

Assemble in the reverse order of disassembly.

# CLOCK




PF25820

## CLOCK

### Wiring Diagram — CLOCK —

AKS002K9

## DI-CLOCK-01



REFER TO THE FOLLOWING.

(M1) -FUSE BLOCK-JUNCTION BOX (J/B) NO.1

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DI  
L  
M


# CLOCK

AKS002KA

## Removal and Installation

### REMOVAL

1. Remove cluster lid C, refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#).
2. Remove screws (2), and remove clock.



### INSTALLATION

Install in the reverse order of removal.



# VOICE ACTIVATED CONTROL SYSTEM


## VOICE ACTIVATED CONTROL SYSTEM

PFP:28337

### System Description OUTLINE

AKS004E8

- The VACS (Voice-Activated Control System) provides a safe and convenient way of controlling vehicle systems such as the audio, auto A/C and navigation (if so equipped). The system is controlled by the PTT (Push to talk) switch. Voice commands are picked up by a microphone. When giving a command, voice feedback will be heard through the speaker, and messages will be shown on the display. Voice feedback can be turned off. Personal directories of nametags for radio station presets can be created, and spoken command help is provided.
- Refer to Owner's Manual for voice activated control system operating instructions.



Power is supplied at all times

- through 15A fuse [No. 52, located in fuse, fusible link and relay block (J/B)]
- to Voice Activated Control Module terminal 13.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 21, located in the fuse block (J/B) No. 1]
- to Voice Activated Control Module terminal 20.

Ground is also supplied

- to Voice Activated Control Module terminal 14
- through grounds B17 and B57.

### VOICE ACTIVATED CONTROL FUNCTION

When PTT switch pushed ON, signal is sent

- from steering switch terminal 2
- to multifunction switch terminal 7, then
- via multifunction switch, display and AV and NAVI control unit terminals 47 and 48 (with navigation system) or AV control unit terminals 49 and 50 (without navigation system) with AV communication line
- to voice activated control module terminals 35 and 36.

Voice activated control module displays "LISTENING" on screen when PTT switch is ON.

When any voice is input into microphone, voice signal is sent

- from microphone terminals 4 and 5
- to voice activated control module terminals 33 and 34.

When voice activated control module identifies voice signal as a command, it sends the signal

- from voice activated control module terminals 35 and 36
- to AV and NAVI control unit terminals 47 and 48 (with navigation system) or AV control unit (without navigation system) terminals 49 and 50 with AV communication line.

Then AV and NAVI control unit (with navigation system) or AV control unit (without navigation system) sends operational signal

- to display and audio unit and performs the voice command.

While voice activated control system is in operation, voice activated control module sends voice signal

- from voice activated control module terminals 25 and 26
- to BOSE speaker amp. terminals 26 and 42, and guides various operations.

Also at the same time voice activated control module sends mute signal

- from voice activated control module terminal 27
- to audio unit terminal 9.

in order to prevent any noise input into microphone.

# VOICE ACTIVATED CONTROL SYSTEM

---

## AV COMMUNICATION LINE

Voice Activated Control Module is connected to the following units through AV Communication Line. Each unit transmits/receives data with AV communication line.


- AV and NAVI control unit (with navigation system)
- AV control unit (without navigation system)
- Display
- Audio unit
- Multifunction switch

# VOICE ACTIVATED CONTROL SYSTEM

## Schematic

AKS004E9

- (NV) : With NAVI
- (ON) : Without NAVI
- \*1 48 : (NV) \*4 44 : (NV)
- 50 : (ON) 47 : (ON)
- \*2 47 : (NV) \*5 45 : (NV)
- 49 : (ON) 48 : (ON)
- \*3 46 : (NV) \*6 43 : (NV)
- 51 : (ON) 46 : (ON)



TKWA0620E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DI  
L  
M

# VOICE ACTIVATED CONTROL SYSTEM

AKS004EA

## Wiring Diagram — VOICE —

## DI-VOICE-01





REFER TO THE FOLLOWING.  
 (M5), (E205) -SUPER MULTIPLE JUNCTION (SMJ)  
 (M1) -FUSE BLOCK-JUNCTION BOX (J/B) NO.1  
 (E3) -FUSE,FUSIBLE LINK AND RELAY BLOCK (J/B)

TKWA0621E

# VOICE ACTIVATED CONTROL SYSTEM

## DI-VOICE-02

- ▬ : DATA LINE
- ⊡(NV) : WITH NAVI
- ⊡(ON) : WITHOUT NAVI
- \*1 48 : ⊡(NV)
- 50 : ⊡(ON)
- \*2 47 : ⊡(NV)
- 49 : ⊡(ON)
- \*3 46 : ⊡(NV)
- 51 : ⊡(ON)



REFER TO THE FOLLOWING.

⊡(M5) -SUPER MULTIPLE JUNCTION BOX (SMJ)

TKWA0622E

# VOICE ACTIVATED CONTROL SYSTEM

DI-VOICE-03

DATA LINE

(NV) : WITH NAVI









(ON) : WITHOUT NAVI

\*1 44: (NV)    \*3 43: (NV)

47: (ON)    46: (ON)

\*2 45: (NV)


48: (ON)



REFER TO THE FOLLOWING.

(E205) -SUPER MULTIPLE JUNCTION BOX (SMJ)

(E3) -FUSE, FUSIBLE LINK AND RELAY BLOCK (J/B)




\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

TKWA0623E




# VOICE ACTIVATED CONTROL SYSTEM

DI-VOICE-04

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M



DI




REFER TO THE FOLLOWING.  
 (M5) -SUPER MULTIPLE JUNCTION (SMJ)

TKWA0624E

# VOICE ACTIVATED CONTROL SYSTEM

DI-VOICE-05



1	2	3	4	○	6	7
8	9	10	11	12	13	14
15	16					

(B27)  
W

34	32	30	28	26	24	22	20	18	16	14
33	31	29	27	25	23	21	19	17	15	13

(B69)  
W

1	2
3	4

(B72)





TKWA0625E



# VOICE ACTIVATED CONTROL SYSTEM

## Terminals and Reference Values for Voice Activated Control Module

AKS0040U


Terminals				Item	Condition	Reference value
(+)		(-)				
Terminal No.	Wire color	Terminal No.	Wire color			
13	SB	Ground	-	Battery power supply	-	Battery voltage
14	B	Ground	-	Ground	-	Approx. 0V
20	L/OR	Ground	-	Ignition switch (ACC)	ACC	Battery voltage
23	-	-	-	Audio shield ground	-	-
25	L	23	-	Audio output (-)	Voice guide operates.	
26	R	23	-	Audio output (+)		
27	Y/R	Ground	-	Mute	PTT switch (not operate → operate)	Approx. 5V → Approx. 0V
34	R	33	L	Mic input	Voice mic test operates.	
35	R	37	-	Communication signal (-)	-	
36	G	37	-	Communication signal (+)	-	
37	-	-	-	Shield ground	-	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DI  
L  
M

# VOICE ACTIVATED CONTROL SYSTEM

## Component Parts and Harness Connector Location

AKS004EC



# VOICE ACTIVATED CONTROL SYSTEM

## Trouble Diagnoses THIS CONDITION IS NOT MALFUNCTION

AKS004ED

### Example of Basic Operational Errors

The system should respond correctly to all voice commands. Follow the solutions given in this guide for the appropriate error when any of the following symptom is encountered.

Where the solutions are listed by number, try each solution in turn, starting with number one, until the symptom is resolved.

Symptom	Remedy
Displays "COMMAND NOT RECOGNIZED" or the system does not interpret the command correctly.	<ol style="list-style-type: none"> <li>1. Ensure that the command is valid, see Command list (Refer to Owner's Manual).</li> <li>2. Ensure that the command is given after the tone while "LISTENING" is displayed.</li> <li>3. Speak clearly without pausing between words and at a level appropriate to the ambient noise level.</li> <li>4. Ensure that the ambient noise level is not excessive, for example, windows open or defrost on.</li> </ol> <p><b>NOTE:</b> If it is too noisy to use the microphone, it is likely that voice commands will not be recognized.</p> <ol style="list-style-type: none"> <li>5. If optional words of the command have been omitted, then the command should be tried with these in place.</li> <li>6. If a number of commands have been given in rapid succession resulting in the message "COMMAND NOT RECOGNIZED" to be displayed, then allow the system to recover (approximately one minute) before trying the command again.</li> <li>7. If the system consistently does not recognize commands, the voice training procedure should be carried out to improve the recognition response for the speaker.</li> </ol>
Displays "NO SPEECH DETECTED".	<ol style="list-style-type: none"> <li>1. Ensure that the command is given after the tone while "LISTENING" is displayed.</li> <li>2. Ensure that the command is given within a maximum of five seconds from the end of the tone.</li> </ol> <p><b>NOTE:</b> Be sure you know what to say before pressing the PTT switch.</p>
Displays "NAMETAG NOT UNIQUE".	<ol style="list-style-type: none"> <li>1. This response will be received when storing a nametag if the nametag being given has already been stored. This can be confirmed by giving the Radio Directory command.</li> <li>2. If this response is received and the nametag has not been used already, then it is too similar to an existing nametag or voice grammar and an alternative should be used.</li> </ol>
The system consistently selects the wrong nametag.	<ol style="list-style-type: none"> <li>1. Ensure that the nametag requested matches what was originally stored. This can be confirmed by giving the Radio Directory command.</li> <li>2. Delete one of the nametags being confused and replace it with a different nametag.</li> </ol>

## Self-Diagnosis Function DESCRIPTION

AKS004EE

- Diagnosis function consists of the self-diagnosis mode, and the "CONFIRMATION/ADJUSTMENT" mode.
- Self-diagnosis mode checks for connection between AV and NAVI control unit (with navigation system) or AV control unit (without navigation system) and voice activated control module and analyzes each unit, then displays the results.
- "CONFIRMATION/ADJUSTMENT" function analyzes each microphone.

### DIAGNOSIS ITEM

Mode	Description				
Self-diagnosis	<ul style="list-style-type: none"> <li>● Checks for the connections between AV and NAVI control unit or AV control unit and voice activated control module.</li> <li>● Performs the unit diagnosis of voice activated control module.</li> </ul>				
CONFIRMATION/ ADJUSTMENT	<table border="1"> <thead> <tr> <th>Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Voice Mic. Test</td> <td> <ul style="list-style-type: none"> <li>● Checks microphone.</li> </ul> </td> </tr> </tbody> </table>	Mode	Description	Voice Mic. Test	<ul style="list-style-type: none"> <li>● Checks microphone.</li> </ul>
Mode	Description				
Voice Mic. Test	<ul style="list-style-type: none"> <li>● Checks microphone.</li> </ul>				

## Self-Diagnosis Mode OPERATION PROCEDURE

AKS004EF


- To start the self-diagnosis mode and to check the diagnosis result, refer to [AV-69, "Self-Diagnosis Mode"](#) (with navigation system), or [DI-113, "Self-Diagnosis Mode"](#) (without navigation system).

# VOICE ACTIVATED CONTROL SYSTEM


AKS004EG

## Confirmation/Adjustment Mode OPERATION PROCEDURE

1. Start the engine.
2. Turn the audio system off.
3. While pressing the "INFO" switch, turn the volume control dial clockwise or counterclockwise for 30 clicks or more.




4. The initial trouble diagnosis screen will be shown, and items "SELF-DIAGNOSIS" and "CONFIRMATION/ADJUSTMENT" will become selective.
5. When "CONFIRMATION/ADJUSTMENT" is selected on the trouble diagnosis screen, the operation will enter the CONFIRMATION/ADJUSTMENT mode. In this mode, check and adjustment of each item will become possible.



6. When "Voice Mic. Test" is selected with joystick, icon indicator turns on (green) and voice input into microphone is sent out through speakers.

**NOTE:**

Voice from speakers may sound echoic.



# VOICE ACTIVATED CONTROL SYSTEM

AKS0040V

## Power Supply and Ground Circuit Inspection

### 1. CHECK FUSES

Check that any of the following fuses for voice activated control module is blown.

Unit	Power source	Fuse No.
Voice Activated Control Module	Battery	52
	Ignition switch ACC or ON	21

OK or NG


OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-2, "POWER SUPPLY ROUTING"](#).

### 2. CHECK POWER SUPPLY CIRCUIT

Check voltage between voice activated control module harness connector B69 terminals 13 (SB), 20 (L/OR) and ground.

Terminals		Ignition switch position			
(+)		(-)	OFF	ACC	ON
Connector	Terminal (Wire color)				
B69	13 (SB)	Ground	Battery voltage	Battery voltage	Battery voltage
	20 (L/OR)		0V	Battery voltage	Battery voltage



OK or NG

OK >> GO TO 3.

NG >> Check harness between voice activated control module and fuse.

### 3. CHECK GROUND CIRCUIT


- Turn ignition switch OFF.
- Check continuity between voice activated control module harness connector B69 terminal 14 (B) and ground.

**Continuity should exist.**

OK or NG

OK >> Inspection end.

NG >> Repair harness or connector.



# VOICE ACTIVATED CONTROL SYSTEM

AKS0040W

## Voice Command Not Identified (With Voice Activated Control System in Operation)

### 1. CHECK MICROPHONE OPERATION

- Select "Voice Mic. Test" of "CONFIRMATION/ADJUSTMENT" mode. Refer to [DI-148, "Confirmation/Adjustment Mode"](#).
- Speak to microphone, and check if the sound is heard from (right) instrument speaker.

OK or NG

- OK >> Replace voice activated control module.
- NG >> GO TO 2.

### 2. CHECK MICROPHONE CIRCUIT

1. Disconnect voice activated control module connector and microphone connector.
2. Check the following.
  - Continuity between voice activated control module harness connector B69 terminal 33 (L) and microphone connector R10 terminal 5 (L).

**Continuity should exist.**

- Continuity between voice activated control module harness connector B69 terminal 34 (R) and microphone harness connector R10 terminal 4 (R).

**Continuity should exist.**

- Continuity between voice activated control module harness connector B69 terminals 33 (L), 34 (R) and ground.

**Continuity should not exist.**

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness or connector.



### 3. CHECK MICROPHONE SIGNAL

1. Connect voice activated control module connector and microphone connector.
2. Turn ignition switch ON.
3. Speak to microphone and check signal between voice activated control module connector B69 terminals 34 (R) and 33 (L) with CONSULT-II or oscilloscope.

**34(R) - 33(L) : Refer to [DI-145, "Terminals and Reference Values for Voice Activated Control Module"](#).**

OK or NG

- OK >> Replace voice activated control module.
- NG >> Replace microphone.



# VOICE ACTIVATED CONTROL SYSTEM

AKS0040X

## No Guide Sound or Beeps

### 1. CHECK GUIDE SOUND SETTING

Check volume setting of voice activated control system if set as 0 (zero).

OK or NG

- OK >> GO TO 2.
- NG >> Adjust volume.

### 2. CHECK BOSE SPEAKER AMP. CIRCUIT

1. Disconnect voice activated control module connector and BOSE speaker amp. connector.
2. Check the following.
  - Continuity between voice activated control module harness connector B69 terminal 25 (L) and BOSE speaker amp. harness connector B234 terminal 42 (OR/L)

**Continuity should exist.**

- Continuity between voice activated control module harness connector B69 terminal 26 (R) and BOSE speaker amp. harness connector B234 terminal 26 (W/L)

**Continuity should exist.**

- Continuity between voice activated control module harness connector B69 terminals 25 (L), 26 (R) and ground

**Continuity should not exist.**

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness or connector.



### 3. CHECK VOICE SIGNAL

1. Connect voice activated control module connector and BOSE speaker amp.
2. Turn ignition switch ON.
3. The Speaker Adaptation (SA) mode ON and voice guide signal sent out, check signal between voice activated control module harness connector B69 terminals 25 (L), 26 (R) and 23.

**25 (L) - 23** :Refer to [DI-145, "Terminals and Reference Values for Voice Activated Control Module"](#) .  
**26 (R) - 23**

OK or NG

- OK >> Replace BOSE speaker amp.
- NG >> Replace voice activated control module.



# VOICE ACTIVATED CONTROL SYSTEM

---

## Voice Activated Control System Not Starting PTT Switch Pushed ON

AKS0040Y

### 1. CHECK PTT SWITCH OPERATION

---

Check PTT switch operation with self-diagnosis of multifunction switch. Refer to [DI-119, "Multifunction Switch Self-Diagnosis Function"](#) .

OK or NG

- OK >> GO TO 2.
- NG >> Replace steering switch.

### 2. CHECK MULTIFUNCTION SWITCH AND VOICE ACTIVATED CONTROL MODULE

---

Start self-diagnosis mode. Refer to [AV-69, "Self-Diagnosis Mode"](#) (with navigation system) or [DI-113, "Self-Diagnosis Mode"](#) (without navigation system).

Does self-diagnosis mode start?

- YES >> GO TO 3.
- NO >> Replace multifunction switch.

### 3. CHECK VOICE ACTIVATED CONTROL MODULE

---

Check voice activated control module with self-diagnosis mode started in previous step 2.

OK or NG

- OK >> ● Replace AV and NAVI control unit (with navigation system), or  
● Replace AV control unit (without navigation system).
- NG >> GO TO 4.

### 4. CHECK POWER SUPPLY AND GROUND CIRCUIT

---

Check power supply and ground circuit of voice activated control module. Refer to [DI-149, "Power Supply and Ground Circuit Inspection"](#) .

OK or NG

- OK >> GO TO 5.
- NG >> Repair harness or connector.



# VOICE ACTIVATED CONTROL SYSTEM

## 5. CHECK AV COMMUNICATION LINE



1. Disconnect voice activated control module and AV and NAVI control unit (with navigation system) or AV control unit (without navigation system) connector.
2. Check the following.

### - With navigation system

Terminals				Continuity
(+)		(-)		
Connector	Terminal (Wire color)	Connector	Terminal (Wire color)	
B71	35 (R)	B29	48 (R)	Yes
	36 (G)		47 (G)	Yes
	37		46	Yes
	35 (R)		46	No
	36 (G)		46	No

### - Without navigation system

Terminals				Continuity
(+)		(-)		
Connector	Terminal (Wire color)	Connector	Terminal (Wire color)	
B71	35 (R)	M50	50 (R)	Yes
	36 (G)		49 (G)	Yes
	37		51	Yes
	35 (R)		51	No
	36 (G)		51	No



### OK or NG

- OK >> Replace voice activated control module.
- NG >> Repair harness or connector.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

DI

# VOICE ACTIVATED CONTROL SYSTEM

AKS004OZ

## Audio Not Muted with PTT Switch Pushed ON


### 1. CHECK AUDIO UNIT CIRCUIT

1. Disconnect voice activated control module connector and Audio unit connector.
2. Check the following.
  - Continuity between voice activated control module harness connector B69 terminal 27 (Y/R) and Audio unit harness connector M87 terminal 9 (OR)

**Continuity should exist.**

- Continuity between voice activated control module harness connector B69 terminal 27 (Y/R) and ground

**Continuity should not exist.**




OK or NG

- OK >> GO TO 2.
- NG >> Repair harness or connector.

### 2. CHECK AUDIO UNIT MUTE SIGNAL

1. Connect voice activated control module connector and audio unit connector.
2. Turn ignition switch ON.
3. Check voltage between voice activated control module harness connector B69 terminal 27(Y/R) and ground.



Terminals		PTT switch condition	Voltage (V)
(+)	(-)		
Connector	Terminal (Wire color)		
B69	27 (Y/R)	ON	Approx. 0
		OFF	Approx. 5

OK or NG

- OK >> Replace audio unit.
- NG >> Replace voice activated control module.

# VOICE ACTIVATED CONTROL SYSTEM

AKS004P0

## Audio Mute Not Released


### 1. AUDIO UNIT MUTE SIGNAL CIRCUIT

1. Disconnect voice activated control module connector and audio unit connector.
2. Check continuity between audio unit harness connector M87 terminal 9 (OR) and ground.

**Continuity should not exist.**

OK or NG

- OK >> GO TO 2.  
 NG >> Repair and replace harness.




### 2. CHECK MUTE SIGNAL

1. Connect voice activated control module connector and audio unit connector.
2. Turn ignition switch ON.
3. Check the following.

Unit	Terminals		PTT switch condition	Voltage (V)	
	(+)				(-)
	Connector	Terminal (Wire color)			
Voice activated control module	B69	27 (Y/R)	ON	Approx. 0	
			OFF	Approx. 5	
Audio unit	M87	9 (OR)	ON	Approx. 0	
			OFF	Approx. 5	

OK or NG

- OK >> Replace audio unit.  
 NG >> Replace voice activated control module.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DI  
L  
M


# VOICE ACTIVATED CONTROL SYSTEM

## Removal and Installation for Voice Activated Control Module


AKS004EN

### REMOVAL

1. Remove trunk side trim. Refer to [EI-42. "TRUNK ROOM TRIM & TRUNK LID FINISHER"](#) .
2. Remove voice activated control module.



3. Remove bracket from voice activated control module.



### INSTALLATION

Install in the reverse order of removal.