

SECTION GW

GLASSES, WINDOW SYSTEM & MIRRORS

CONTENTS

PRECAUTIONS	3	POWER WINDOW LOCK	18
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	3	RETAINED POWER OPERATION	18
Handling for Adhesive and Primer	3	ANTI-PINCH SYSTEM	19
Wiring Diagrams and Trouble Diagnosis	3	POWER WINDOW CONTROL BY THE KEY CYLINDER SWITCH	19
PREPARATION	4	Schematic	20
Special Service Tools	4	Wiring Diagram — WINDOW —	21
Commercial Service Tools	4	Terminals and Reference Value for BCM	29
SQUEAK AND RATTLE TROUBLE DIAGNOSES	5	Terminals and Reference Value for Driver Door Control Unit	30
Work Flow	5	Terminals and Reference Value for Passenger, Rear LH, RH Door Control Unit	31
CUSTOMER INTERVIEW	5	Trouble Diagnosis Symptom Chart	32
DUPLICATE THE NOISE AND TEST DRIVE	6	Communication Signal Circuit Check	33
CHECK RELATED SERVICE BULLETINS	6	Front Power Window Regulator Circuit Check (Driver Side)	34
LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE	6	Front Power Window Regulator Circuit Check (Passenger Side)	35
REPAIR THE CAUSE	6	Rear Power Window Regulator LH or RH Circuit Check	36
CONFIRM THE REPAIR	7	Limit Switch Check (Driver Side)	37
Generic Squeak and Rattle Troubleshooting	7	Limit Switch Check (Passenger Side)	38
INSTRUMENT PANEL	7	Encoder Switch Check (Driver Side)	39
CENTER CONSOLE	7	Encoder Switch Check (Passenger Side)	41
DOORS	7	Driver Door Control Unit Circuit Check	43
TRUNK	8	Passenger Door Control Unit Circuit Check	43
SUNROOF/HEADLINING	8	Rear Door Control Unit (LH or RH) Circuit Check... ..	44
SEATS	8	Door Switch Check	45
UNDERHOOD	8	Door Key Cylinder Switch Check	45
Diagnostic Worksheet	9	FRONT DOOR GLASS AND REGULATOR	47
WINDSHIELD GLASS	11	Removal and Installation	47
Removal and Installation	11	REMOVAL	47
REMOVAL	11	INSTALLATION	48
INSTALLATION	12	INSPECTION AFTER REMOVAL	48
REAR WINDOW GLASS AND MOLDING	13	SETTING AFTER INSTALLATION	48
Removal and Installation	13	FITTING INSPECTION	49
REMOVAL	13	Door Glass Fitting Adjustment	50
INSTALLATION	14	ADJUSTMENT LOCATIONS	50
POWER WINDOW SYSTEM	15	ADJUSTMENT STANDARD CLEARANCE	50
Component Parts and Harness Connector Location. ..	15	[A] IN-OUT ADJUSTMENT (AT THE GLASS	
System Description	16		
MANUAL OPERATION	16		
AUTO OPERATION	18		

WAIST)	51	Component Parts and Harness Connector Location..	78
[B] FORE-AFT TILT ADJUSTMENT	51	System Description	78
[C] IN-OUT TILT ADJUSTMENT (AT GUIDE RAIL)	51	OUTLINE OF OPERATION	78
[D] UP-STOP ADJUSTMENT	51	MIRROR POSITION MEMORY FUNCTIONS	79
[E] FORE-AFT ADJUSTMENT	52	POWER SUPPLY	79
REAR DOOR GLASS AND REGULATOR	53	MIRROR CONTROL SWITCH TO OPERATION..	80
Removal and Installation	53	MEMORY MIRROR OPERATION	81
REMOVAL	53	DOOR MIRROR MOTOR TO OPERATION	81
INSTALLATION	54	SYSTEM DIAGRAM	82
INSPECTION AFTER REMOVAL	54	Schematic	83
FITTING INSPECTION	54	Wiring Diagram — MIRROR —	84
Door Glass Fitting Adjustment	55	Terminals and Reference Values for Driver Side	
ADJUSTMENT LOCATIONS	55	Door Mirror Control Unit & Terminals and Reference	
ADJUSTMENT STANDARD CLEARANCE	55	Value for Passenger Side Door Mirror Control Unit..	88
[A] IN-OUT ADJUSTMENT (AT THE GLASS		Terminals and Reference Values for BCM	88
WAIST)	56	Work Flow	89
[B] FORE-AFT TILT ADJUSTMENT	56	Preliminary Check	90
[C] IN-OUT TILT ADJUSTMENT (AT GUIDE RAIL)	56	POWER SUPPLY AND GROUND CIRCUIT	
[D] UP-STOP ADJUSTMENT	56	CHECK	90
[E] FORE-AFT ADJUSTMENT	57	CONSULT-II Function	92
INSIDE MIRROR	58	CONSULT-II BASIC OPERATION PROCEDURE	
Wiring Diagram — I/MIRR —	58	... 92	
Removal and Installation	59	IVMS COMMUNICATION INSPECTION	93
REMOVAL	59	COMMUNICATION SYSTEM A	95
INSTALLTION	59	COMMUNICATION SYSTEM B	95
REAR WINDOW DEFOGGER	60	COMMUNICATION SYSTEM C	95
Component Parts and Harness Connector Location..	60	SELF-DIAGNOSIS RESULTS	97
System Description	60	DATA MONITOR	97
Schematic	62	ACTIVE TEST	99
Wiring Diagram — DEF —	63	On Board Diagnosis	99
Terminals and Reference Value for BCM	66	DIAGNOSIS ITEM	99
Work Flow	66	COMMUNICATION DIAGNOSIS	100
Preliminary Check	66	COMMUNICATION SYSTEM A	102
POWER SUPPLY AND GROUND CIRCUIT		COMMUNICATION SYSTEM B	102
INSPECTION	66	COMMUNICATION SYSTEM C	102
CONSULT-II Function	68	SWITCH MONITOR	104
CONSULT-II BASIC OPERATION PROCEDURE		ON BOARD DIAGNOSIS FOR AUTOMATIC	
... 68		DRIVE POSITIONER	105
DATA MONITOR	68	Symptom Chart	107
ACTIVE TEST	69	Door Mirror Remote Control Switch (Changeover	
Trouble Diagnosis Symptom Chart	69	Switch) Circuit Inspection	107
Rear Window Defogger Switch Circuit Check	69	Back- Up Input Signal Circuit Inspection In R Posi-	
Rear Window Defogger and Door Mirror Defogger		tion	109
Circuit Check	70	Door Mirror Remote Control Switch (Mirror Switch)	
Rear Window Defogger Circuit Check	72	Circuit Inspection	110
Door Mirror Defogger Power Supply Circuit Check..	73	Mirror Motors Circuit Inspection	111
Driver Side Door Mirror Defogger Circuit Check	74	Mirror Sensors Circuit Inspection	113
Passenger Side Door Mirror Defogger Circuit Check		DOOR MIRROR	116
... 75		Wiring Diagram — MIRROR —	116
Filament Check	76	Removal and Installation	117
Filament Repair	76	REMOVAL	117
REPAIR EQUIPMENT	76	INSTALLATION	117
REPAIRING PROCEDURE	77	Disassembly and Assembly	118
REVERSE INTERLOCK DOOR MIRROR SYSTEM..	78	DISASSEMBLY	118
		ASSEMBLY	119

PRECAUTIONS

PRECAUTIONS

PF0:00001

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

AIS004W4

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Handling for Adhesive and Primer

AIS001G1

- Do not use an adhesive which is past its usable term. Shelf life of this product is limited to six months after the date of manufacture. Carefully adhere to the expiration or manufacture date printed on the box.
- Keep primers and adhesive in a cool, dry place. Ideally, they should be stored in a refrigerator.
- Open the seal of the primer and adhesive just before application. Do not use the remainder.
- Before application, be sure to shake the primer container to stir the content. If any floating materials are found, do not use it.
- If any primer or adhesive contacts the skin, wipe it off with white gasoline or equivalent and wash the skin with soap.
- When using primer and adhesive, always observe the precautions in the instruction manual.

Wiring Diagrams and Trouble Diagnosis

AIS001G2

- If each local control unit (LCU) connector is left disconnected for at least 1 minute, the BCM stores a communication inactive. After reconnecting the connector, any of the following steps shall be done. “Disconnect the BCM battery power supply”, Execute Erase memory with CONSULT-II.

When you read wiring diagrams, refer to the following:

- [GI-14, "How to Read Wiring Diagrams"](#) in GI section
- [PG-2, "POWER SUPPLY ROUTING"](#) in PG section

When you perform trouble diagnosis, refer to the following:

- [GI-10, "HOW TO FOLLOW TEST GROUPS IN TROUBLE DIAGNOSES"](#) in GI section
- [GI-26, "How to Perform Efficient Diagnosis for an Electrical Incident"](#) in GI section

Check for any service bulletins before servicing the vehicle.

A
B
C
D
E
F
G
H
J
K
L
M

GW

PREPARATION



PREPARATION

PFP:00002

Special Service Tools


AIS001G3

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
(J-39570) Chassis ear  <p style="text-align: right; margin-right: 50px;">SIIA0993E</p>	Locating the noise
(J-43980) NISSAN Squeak and Rattle Kit  <p style="text-align: right; margin-right: 50px;">SIIA0994E</p>	Repairing the cause of noise

Commercial Service Tools

AIS001G4

Tool name	Description
Engine ear  <p style="text-align: right; margin-right: 50px;">SIIA0995E</p>	Locating the noise


SQUEAK AND RATTLE TROUBLE DIAGNOSES

SQUEAK AND RATTLE TROUBLE DIAGNOSES

PFP:00000

Work Flow

AIS001G5



CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any customer's comments; refer to [GW-9, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, be sure to diagnose and repair the noise that the customer is concerned about. This can be accomplished by test driving the vehicle with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak—(Like tennis shoes on a clean floor)
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces=higher pitch noise/softer surfaces=lower pitch noises/edge to surface=chirping
- Creak—(Like walking on an old wooden floor)
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle—(Like shaking a baby rattle)
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock—(Like a knock on a door)
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick—(Like a clock second hand)
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump—(Heavy, muffled knock noise)
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz—(Like a bumble bee)
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending upon the person. A noise that you may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

DUPLICATE THE NOISE AND TEST DRIVE

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when you confirm the repair.

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
 - 2) Tap or push/pull around the area where the noise appears to be coming from.
 - 3) Rev the engine.
 - 4) Use a floor jack to recreate vehicle "twist".
 - 5) At idle, apply engine load (electrical load, half-clutch on M/T models, drive position on A/T models).
 - 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.
- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
 - If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

CHECK RELATED SERVICE BULLETINS

After verifying the customer concern or symptom, check ASIST for Technical Service Bulletins (TSBs) related to that concern or symptom.

If a TSB relates to the symptom, follow the procedure to repair the noise.

LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Chassis Ear: J-39570, Engine Ear and mechanics stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
 - removing the components in the area that you suspect the noise is coming from.
Do not use too much force when removing clips and fasteners, otherwise clips and fastener can be broken or lost during the repair, resulting in the creation of new noise.
 - tapping or pushing/pulling the component that you suspect is causing the noise.
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
 - feeling for a vibration with your hand by touching the component(s) that you suspect is (are) causing the noise.
 - placing a piece of paper between components that you suspect are causing the noise.
 - looking for loose components and contact marks.
Refer to [GW-7, "Generic Squeak and Rattle Troubleshooting"](#) .

REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
 - separate components by repositioning or loosening and retightening the component, if possible.
 - insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. A Nissan Squeak and Rattle Kit (J-43980) is available through your authorized Nissan Parts Department.

CAUTION:

Do not use excessive force as many components are constructed of plastic and may be damaged. Always check with the Parts Department for the latest parts information.

The following materials are contained in the Nissan Squeak and Rattle Kit (J-43980). Each item can be ordered separately as needed.

URETHANE PADS [1.5 mm (0.059 in) thick]

Insulates connectors, harness, etc.

76268-9E005: 100 × 135 mm (3.94 × 5.31 in)/76884-71L01: 60 × 85 mm (2.36 × 3.35 in)/76884-71L02: 15 × 25 mm (0.59 × 0.98 in)

INSULATOR (Foam blocks)

Insulates components from contact. Can be used to fill space behind a panel.

73982-9E000: 45 mm (1.77 in) thick, 50 × 50 mm (1.97 × 1.97 in)/73982-50Y00: 10 mm (0.39 in) thick, 50 × 50 mm (1.97 × 1.97 in)

SQUEAK AND RATTLE TROUBLE DIAGNOSES

INSULATOR (Light foam block)

80845-71L00: 30 mm (1.18 in) thick, 30 × 50 mm (1.18 × 1.97 in)

FELT CLOTH TAPE

Used to insulate where movement does not occur. Ideal for instrument panel applications.

68370-4B000: 15 × 25 mm (0.59 × 0.98 in) pad/68239-13E00: 5 mm (0.20 in) wide tape roll

The following materials, not found in the kit, can also be used to repair squeaks and rattles.

UHMW(TEFLON) TAPE

Insulates where slight movement is present. Ideal for instrument panel applications.

SILICONE GREASE

Used in of UHMW tape that will be visible or not fit.

Note: Will only last a few months.

SILICONE SPRAY

Use when grease cannot be applied.

DUCT TAPE

Use to eliminate movement.

A

B

C

D

E

CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

F

Generic Squeak and Rattle Troubleshooting

AIS001G6

Refer to Table of Contents for specific component removal and installation information.

G

INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

1. The cluster lid A and instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar garnish
4. Instrument panel to windshield
5. Instrument panel mounting pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

H

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicone spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

J

CAUTION:

Do not use silicone spray to isolate a squeak or rattle. If you saturate the area with silicone, you will not be able to recheck the repair.

K

L

CENTER CONSOLE

Components to pay attention to include:

1. Shifter assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

M

DOORS

Pay attention to the:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. You can usually insulate the areas with felt cloth tape or insulator foam blocks from the Nissan Squeak and Rattle Kit (J-43980) to repair the noise.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the owner. In addition look for:

1. Trunk lid dumpers out of adjustment
2. Trunk lid striker out of adjustment
3. The trunk lid torsion bars knocking together
4. A loose license plate or bracket

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

SUNROOF/HEADLINING

Noises in the sunroof/headlining area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sunvisor shaft shaking in the holder
3. Front or rear windshield touching headlining and squeaking

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

SEATS

When isolating seat noise it's important to note the position the seat is in and the load placed on the seat when the noise is present. These conditions should be duplicated when verifying and isolating the cause of the noise.

Cause of seat noise include:

1. Headrest rods and holder
2. A squeak between the seat pad cushion and frame
3. The rear seatback lock and bracket

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

Causes of transmitted underhood noise include:

1. Any component mounted to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator mounting pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

These noises can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine RPM or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting, securing, or insulating the component causing the noise.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

Diagnostic Worksheet

AIS001G7




SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

Dear Infiniti Customer:

We are concerned about your satisfaction with your Infiniti vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your Infiniti right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service advisor or technician to ensure we confirm the noise you are hearing.

I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to the back of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

SBT860

A
B
C
D
E
F
G
H
GW
J
K
L
M

SQUEAK AND RATTLE TROUBLE DIAGNOSES

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET- page 2

Briefly describe the location where the noise occurs:

II. WHEN DOES IT OCCUR? (check the boxes that apply)

- | | |
|--|---|
| <input type="checkbox"/> anytime | <input type="checkbox"/> after sitting out in the sun |
| <input type="checkbox"/> 1 st time in the morning | <input type="checkbox"/> when it is raining or wet |
| <input type="checkbox"/> only when it is cold outside | <input type="checkbox"/> dry or dusty conditions |
| <input type="checkbox"/> only when it is hot outside | <input type="checkbox"/> other: _____ |

III. WHEN DRIVING:

- through driveways
- over rough roads
- over speed bumps
- only at about ____ mph
- on acceleration
- coming to a stop
- on turns : left, right or either (circle)
- with passengers or cargo
- other: _____
- after driving ____ miles or ____ minutes

IV. WHAT TYPE OF NOISE?

- squeak (like tennis shoes on a clean floor)
- creak (like walking on an old wooden floor)
- rattle (like shaking a baby rattle)
- knock (like a knock on a door)
- tick (like a clock second hand)
- thump (heavy, muffled knock noise)
- buzz (like a bumble bee)

TO BE COMPLETED BY DEALERSHIP PERSONNEL

Test Drive Notes:

	YES	NO	Initials of person performing
Vehicle test driven with customer	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise verified on test drive	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise source located and repaired	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Follow up test drive performed to confirm repair	<input type="checkbox"/>	<input type="checkbox"/>	_____

VIN: _____ Customer Name: _____

W.O. #: _____ Date: _____

This form must be attached to Work Order

SBT844

WINDSHIELD GLASS


WINDSHIELD GLASS

PFP:72712

Removal and Installation

AIS001G8

A
B
C
D
E
F
G
H
GW
J
K
L
M



- | | | |
|---------------------|-----------------------|-------------|
| 1. Dam rubber | 2. Windshield molding | 3. Fastener |
| 4. Mirror base | 5. Insulator | 6. Spacer |
| 7. Windshield glass | 8. Panel | 9. Bond |
| 10. Roof panel | | |

REMOVAL

1. Remove front pillar garnish. Refer to [EI-34, "BODY SIDE TRIM"](#) .
2. Remove headlining. Refer to [EI-40, "HEADLINING"](#) .
3. Remove body side welt on the front pillar. Refer to [EI-34, "BODY SIDE TRIM"](#) .
4. Remove cowl top cover. Refer to [EI-20, "COWL TOP"](#) .
5. Remove windshield molding.
6. Apply a protective tape around the windshield glass to protect the painted surface from damage.
7. Remove glass using piano wire or power cutting tool and an inflatable pump bag.
 - If a windshield glass is to be reused, mark the body and the glass with mating marks.


WINDSHIELD GLASS

WARNING:

When cutting the glass from the vehicle, always wear safety glasses and heavy gloves to help prevent glass splinters from entering your eyes or cutting your hands.

CAUTION:

- When a windshield glass is to be reused, do not use a cutting knife or power cutting tool.
- Be careful not to scratch the glass when removing.
- Do not set or stand the glass on its edge. Small chips may develop into cracks.



INSTALLATION

- The dam rubber and the insulator should be installed in position.
- Use a genuine Nissan Urethane Adhesive Kit or equivalent and follow the instructions furnished with it.
- While the urethane adhesive is curing, open a door window. This will prevent the glass from being forced out by passenger compartment air pressure when a door is closed.
- The fastener and the molding must be installed securely so that it is in position and leaves no gap.
- Inform the customer that the vehicle should remain stationary until the urethane adhesive has completely cured (preferably 24 hours). Curing time varies with temperature and humidity.

WARNING:

- Keep heat and open flames away as primers and adhesive are flammable.
- The materials contained in the kit are harmful if swallowed, and may irritate skin and eyes. Avoid contact with the skin and eyes.
- Use in an open, well ventilated location. Avoid breathing the vapors. They can be harmful if inhaled. If affected by vapor inhalation, immediately move to an area with fresh air.
- Driving the vehicle before the urethane adhesive has completely cured may affect the performance of the windshield in case of an accident.

CAUTION:

- Do not use an adhesive which is past its usable term. Shelf life of this product is limited to six months after the date of manufacture. Carefully adhere to the expiration or manufacture date printed on the box.
- Keep primers and adhesive in a cool, dry place. Ideally, they should be stored in a refrigerator.
- Do not leave primers or adhesive cartridge unattended with their caps open or off.
- The vehicle should not be driven for at least 24 hours or until the urethane adhesive has completely cured. Curing time varies depending on temperature and humidity. The curing time will increase under lower temperature and lower humidity.

Repairing Water Leaks

Leaks can be repaired without removing and reinstalling glass.

If water is leaking between the urethane adhesive material and body or glass, determine the extent of leakage.

This can be done by applying water to the windshield area while pushing glass outward.

To stop the leak, apply primer (if necessary) and then urethane adhesive to the leak point.

REAR WINDOW GLASS AND MOLDING


REAR WINDOW GLASS AND MOLDING

PF9:79712

Removal and Installation


AIS001G9

SEC. 797



⊗ : Always replace after every disassembly.

Unit: mm (in)



- | | | |
|----------------------|------------------------|----------------------|
| 1. Rear window glass | 2. Rear window molding | 3. Dam rubber |
| 4. Bond | 5. Roof panel | 6. Trunk lid (outer) |
| 7. Body side (outer) | | |

REMOVAL

1. Remove rear pillar finisher upper. Refer to [EI-34, "BODY SIDE TRIM"](#).
2. Remove headlining. Refer to [EI-40, "HEADLINING"](#).
3. Remove the rear parcel shelf finisher. Refer to [EI-37, "REAR PARCEL SHELF FINISHER"](#).
4. Remove the connectors and grounds for the rear defogger and printed antenna.
5. Apply protective tape around the rear window glass to protect the painted surface from damage.
6. Cut the molding with cutting knife.
 - After removing moldings using pliers, remove glass using piano wire or power cutting tool and an inflatable pump bag.
 - If a rear window glass is reused, mark the body and the glass with mating marks.

A
B
C
D
E
F
G
H
GW
J
K
L
M


REAR WINDOW GLASS AND MOLDING

WARNING:

When cutting the glass from the vehicle, always wear safety glasses and heavy gloves to help prevent glass splinters from entering your eyes or cutting your hands.

CAUTION:

- When a rear window glass is reused, do not use a cutting knife or power cutting tool.
- Be careful not to scratch the glass when removing.
- Do not set or stand the glass on its edge. Small chips may develop into cracks.



INSTALLATION

- Use a genuine Nissan Urethane Adhesive Kit or equivalent and follow the instructions furnished with it.
- While the urethane adhesive is curing, open a door window. This will prevent the glass from being forced out by passenger compartment air pressure when a door is closed.
- The molding must be installed securely so that it is in position and leaves no gap.
- Inform the customer that the vehicle should remain stationary until the urethane adhesive has completely cured (preferably 24 hours). Curing time varies with temperature and humidity.

WARNING:

- Keep heat and open flames away as primers and adhesive are flammable.
- The materials contained in the kit are harmful if swallowed, and may irritate skin and eyes. Avoid contact with the skin and eyes.
- Use in an open, well ventilated location. Avoid breathing the vapors. They can be harmful if inhaled. If affected by vapor inhalation, immediately move to an area with fresh air.
- Driving the vehicle before the urethane adhesive has completely cured may affect the performance of the rear window in case of an accident.

CAUTION:

- Do not use an adhesive which is past its usable term. Shelf life of this product is limited to six months after the date of manufacture. Carefully adhere to the expiration or manufacture date printed on the box.
- Keep primers and adhesive in a cool, dry place. Ideally, they should be stored in a refrigerator.
- Do not leave primers or adhesive cartridge unattended with their caps open or off.
- The vehicle should not be driven for at least 24 hours or until the urethane adhesive has completely cured. Curing time varies depending on temperature and humidity. The curing time will increase under lower temperature and lower humidity.


POWER WINDOW SYSTEM

POWER WINDOW SYSTEM

PPF:25401

Component Parts and Harness Connector Location

AIS001GA



A
B
C
D
E
F
G
H
GW
J
K
L
M

GW

PIIA2872E

System Description

Power is supplied at all time

- through 10A fuse [No.3,located in the fuse block (J/B)]
- to BCM terminal 105
- through 40A fusible link (letter H, located in the fuse and fusible link box)
- to circuit breaker-1 and circuit breaker-2
- through circuit breaker-1
- to driver door control unit (LCU01) terminal 14
- to rear LH door control unit terminal 10.
- through circuit breaker-2
- to passenger door control unit terminal 10
- to rear RH door control unit terminal 10.

With ignition switch in ON or START position, power is supplied

- though 10A [No.1,located in the fuse block (J/B)]
- to BCM terminal 68

Ground supplied

- to BCM terminals 56 and 113
- through body grounds M24 and M114.
- to driver door control unit (LCU01) terminal 15
- through body grounds M24 and M114.
- to passenger door control unit terminal 11
- through body grounds M24 and M114.
- to rear LH door control unit terminal 11
- through body grounds B17 and B57.
- to rear RH door control unit terminal 11
- through body grounds B217 and B256.

MANUAL OPERATION

Front Driver Side Door

Ground is supplied

- to driver door control unit (LCU01) terminal 15
- through body grounds M24 and M114

WINDOW UP

When the driver side switch in the front power window main switch is pressed in the up position

Power is supplied

- to front power window regulator (driver side) terminal 1
- through driver door control unit (LCU01) terminal 18.

Ground is supplied

- to front power window regulator (driver side) terminal 2
- through driver door control unit (LCU01) terminal 11.

Then, the motor raises the window until the switch is released.

WINDOW DOWN

When the driver side switch in the front power window main switch is pressed in the down position

Power is supplied

- to front power window regulator (driver side) terminal 2
- through driver door control unit (LCU01) terminal 11.

Ground is supplied

- to front power window regulator (driver side) terminal 1
- through driver door control unit (LCU01) terminal 18.

Then, the motor lowers the window until the switch is released.

POWER WINDOW SYSTEM

Front Passenger Side Door

FRONT POWER WINDOW SUB-SWITCH OPERATION

Ground is supplied

- to passenger door control unit terminal 11
- through body grounds M24 and M114.

WINDOW UP

When the front power window sub-switch is pressed in the up position

Power is supplied

- to front power window regulator terminal 1
- through passenger door control unit terminal 14.

Ground is supplied

- to front power window regulator terminal 2
- through passenger door control unit terminal 3.

Then, the motor raises the window until the switch is released.

WINDOW DOWN

When the front power window sub-switch is pressed in the down position

Power is supplied

- to front power window regulator terminal 2
- through passenger door control unit terminal 3.

Ground is supplied

- to front power window regulator terminal 1
- through passenger door control unit terminal 14.

Then, the motor lowers the window until the switch is released.

FRONT POWER WINDOW MAIN SWITCH OPERATION

Signal is sent

- to passenger door control unit terminal 15
- through driver door control unit (LCU01) terminal 5.

The operation of power window after receive the signal is as same as operate the front power window sub-switch.

Rear Door LH

REAR POWER WINDOW SUB-SWITCH LH OPERATION

Ground is supplied

- to rear LH door control unit terminal 11
- through body grounds B17 and B57.

WINDOW UP

When the rear power window sub-switch LH is pressed in the up position

Power is supplied

- to rear power window regulator LH terminal 1
- through rear LH door control unit terminal 14.

Ground is supplied

- to rear power window regulator LH terminal 2
- through rear LH door control unit terminal 3.

Then, the motor raises the window until the switch is released.

WINDOW DOWN

When the rear power window sub-switch LH is pressed in the down position

Power is supplied

- to rear power window regulator LH terminal 2
- through rear LH door control unit terminal 3.

Ground is supplied

- to rear power window regulator LH terminal 1
- through rear LH door control unit terminal 14.

A

B

C

D

E

F

G

H

GW

J

K

L

M

POWER WINDOW SYSTEM

Then, the motor lowers the window until the switch is released.

POWER WINDOW MAIN SWITCH OPERATION

Signal is sent

- to rear LH door control unit terminal 15
- through driver door control unit (LCU01) terminal 5.

The operation of power window after receive the signal is as same as operate the rear power window sub-switch LH

Rear Door RH

REAR POWER WINDOW SUB-SWITCH RH OPERATION

Ground is supplied

- to rear RH door control unit terminal 11
- through body grounds B217 and B256.

WINDOW UP

When the rear power window sub-switch RH is pressed in the up position

Power is supplied

- to rear power window regulator RH terminal 1
- through rear RH door control unit terminal 14.

Ground is supplied

- to rear power window regulator RH terminal 2
- through rear RH door control unit terminal 3.

Then, the motor raises the window until the switch is released.

WINDOW DOWN

When the rear power window sub-switch RH is pressed in the down position

Power is supplied

- to rear power window regulator RH terminal 2
- through rear RH door control unit terminal 3.

Ground is supplied

- to rear power window regulator RH terminal 1
- through rear RH door control unit terminal 14.

Then, the motor lowers the window until the switch is released.

POWER WINDOW MAIN SWITCH OPERATION

Signal is sent

- to rear RH door control unit terminal 15
- through driver door control unit (LCU01) terminal 5.

The operation of power window after receive the signal is as same as operate the rear power window sub-switch RH.

AUTO OPERATION

The power window AUTO feature enables the driver to open or close the driver's and passenger's side window without holding the window switch in the down or up position.

The AUTO feature only operates on the driver's and passenger's side windows.

POWER WINDOW LOCK

The power window lock is designed to lock operation of all windows except for driver side door window.

When the lock position, power window lock signal is sent by using power window local data line from driver door control unit (LCU01) to each door control unit.

RETAINED POWER OPERATION

When the ignition switch is turned to the OFF position, power window switch for all doors in the way can be operated until approximately 45 seconds.

The retained power operation is canceled when the driver or passenger side door is opened.

POWER WINDOW SYSTEM

ANTI-PINCH SYSTEM

Driver door control unit (LCU01) and passenger door control unit monitor the power window regulator motor operation and the power window position (full closed or other) by the signals from encoder and limit switch in power window regulator motor.

When driver door control unit (LCU01) and passenger door control unit detect interruption during the following close operation in the each door.

- automatic close operation when ignition switch is in the ON position.
- automatic close operation during power window timer operation.

Driver door control unit (LCU01) and passenger door control unit power window regulator motor for open and the power window will be lowered about 150 mm(5.91 in).

POWER WINDOW CONTROL BY THE KEY CYLINDER SWITCH

When ignition key switch is OFF, front power window can be opened or closed by turning the front door key cylinder driver side UNLOCK / LOCK position more then 1.5 seconds over condition.

- Power window can be opened as the door key cylinder is kept fully turning to the UNLOCK position.
- Power window can be closed as the door key cylinder is kept fully turning to the LUCK position.

The power window opening stops when the following operations are carried out.

- While performing open / close the window, power window is stopped at the position as the door key cylinder is placed on NEUTRAL.
- When the ignition switch is turned ON while the power window opening is operated.

A

B

C

D

E

F

G

H

GW

J

K


L

M

POWER WINDOW SYSTEM

Schematic

AIS001MT





TIWA0213E

POWER WINDOW SYSTEM

Wiring Diagram — WINDOW —

AIS001MU

GW-WINDOW-01







REFER TO THE FOLLOWING.
 (M5), (B211) -SUPER MULTIPLE JUNCTION (SMJ)
 (M1) -FUSE BLOCK-JUNCTION BOX (J/B) NO.1
 (M4), (B4) -ELECTRICAL UNITS

TIWA0214E

POWER WINDOW SYSTEM

GW-WINDOW-02

▬ : DATA LINE





REFER TO THE FOLLOWING.

- (D1) -SUPER MULTIPLE JUNCTION (SMJ)
- (M145) -FUSE BLOCK-JUNCTION BOX (J/B) NO.2
- (M4) -ELECTRICAL UNITS

TIWA0215E

POWER WINDOW SYSTEM

GW-WINDOW-03







REFER TO THE FOLLOWING.
(D1) -SUPER MULTIPLE JUNCTION (SMJ)

A
B
C
D
E
F
G
H
J
K
L
M

GW

POWER WINDOW SYSTEM

GW-WINDOW-04



REFER TO THE FOLLOWING.



(D1) -SUPER MULTIPLE JUNCTION UNIT (SMJ)

(M1), (E203) -FUSE BLOCK-JUNCTION BOX (J/B) NO.1

TIWA0217E

POWER WINDOW SYSTEM

GW-WINDOW-06





REFER TO THE FOLLOWING.
 (M5) -SUPER MULTIPLE JUNCTION (SMJ)

TIWA0219E

POWER WINDOW SYSTEM

GW-WINDOW-07



REFER TO THE FOLLOWING.
 (B211) -SUPER MULTIPLE JUNCTION (SMJ)







TIWA0220E

POWER WINDOW SYSTEM

GW-WINDOW-08

: WITH NAVI

: WITHOUT NAVI



REFER TO THE FOLLOWING.





(M4) -ELECTRICAL UNITS

TIWA0221E

POWER WINDOW SYSTEM

Terminals and Reference Value for BCM

AIS001MV

TERMI-NAL	WIRE COLOR	ITEM	CONDITION	Voltage (V) (Approx.)
17	BR/Y	Date link connector RX	—	—
18	P	Date link connector TX	—	—
27	BR/W	Remote keyless entry receiver signal	Vehicle key is removed	State of reception waiting  OCC3879D
			Keyfob switch is pushed	 OCC3880D
			Vehicle key is inserted	0
28	L	Remote keyless entry receiver power supply	Vehicle key is removed	State of reception waiting  OCC3881D
			Keyfob switch is pushed	 OCC3882D
			Vehicle key is inserted	0
30	PU	Monitor 1	—	—
31	LG	Monitor 2	—	—
37	LG	Passenger side door switch	ON (Open) → OFF (Close)	0 → Battery voltage
44	Y	Remoter keyless entry receiver ground	—	0
56	B	Ground	—	0
67	G/W	Date line A-3	—	—
68	W/B	Ignition switch ON or START	Ignition switch (ON or START position)	Battery voltage
69	PU/W	Key-in detection	Vehicle key is inserted (ON)	Battery voltage
			Vehicle key is removed (OFF)	0
105	Y/L	BAT power supply	—	Battery voltage
113	B	Ground	—	0
142	R/Y	Driver side door switch	ON (Open) → OFF (Close)	0 → Battery voltage



A
B
C
D
E
F
G
H
J
K
L
M

GW

POWER WINDOW SYSTEM

Terminals and Reference Value for Driver Door Control Unit



AIS001MW

TERMI- NAL	WIRE COLOR	ITEM	CONDITION	Voltage (V) (Approx.)
1	G	Encoder pulse signal	When power window motor operates	 <p style="text-align: right;">OCC3383D</p>
4	W	Encoder power supply	When ignition switch ON or power window timer operates	10
5	L/Y	Local data line	When ignition switch ON or power window timer operates	 <p style="text-align: right;">SIIA0591J</p>
7	PU	Limit switch signal	Driver side door window is in a position between fully-open and just before fully-closed position (ON)	0
			Driver side door window is in a position between just before fully-closed position and fully-closed position (OFF)	5
8	G/W	Data line A-3	—	—
9	PU/W	Key cylinder switch unlock signal	Key position (Neutral → Unlock)	5 → 0
10	GY	Key cylinder switch lock signal	Key position (Neutral → Lock)	5 → 0
11	L/W	Driver side power window motor DOWN signal	When power window motor DOWN operates	Battery voltage
14	Y/G	BAT power supply	—	Battery voltage
15	B	Ground	—	0
18	L/R	Driver side power window motor UP signal	When power window motor UP operates	Battery voltage

POWER WINDOW SYSTEM

Terminals and Reference Value for Passenger, Rear LH, RH Door Control Unit

AIS001MX

TERMI- NAL	WIRE COLOR	ITEM	CONDITION	Voltage (V) (Approx.)
(1)	PU	Limit switch signal	Passenger side door window is in a position between fully-open and just before fully-closed position (ON)	0
			Passenger side door window is in a position between just before fully-closed position and fully-closed position (OFF)	5
3	LW	Power window motor DOWN signal	When power window motor DOWN operates	Battery voltage
(4)	W	Encoder power supply	When ignition switch ON or power window timer operates	10
10	(W/R) Y/B	BAT power supply	—	Battery voltage
11	B	Ground	—	0
(12)	G	Encoder pulse signal	When power window motor operates	 <p style="text-align: right; font-size: small;">OCC3383D</p>
14	L/R	Power window motor UP signal	When power window motor UP operates	Battery voltage
15	L/Y	Local data line	When ignition switch ON or power window timer operates	 <p style="text-align: right; font-size: small;">SIIA0591J</p>

(): Passenger door control unit

A
B
C
D
E
F
G
H
GW
J
K
L
M

POWER WINDOW SYSTEM

AIS001MY

Trouble Diagnosis Symptom Chart

- Check that other systems using the signal of the following systems operate normally.

Symptom	Diagnostic procedure.	Refer to page
None of the power windows can be operated using any switch	<p>Check the following.</p> <ul style="list-style-type: none"> ● 40A fusible link (letter H, located in fuse and fusible link box) ● Harness for open and short between fuse and driver control unit (LCU01). ● Harness for open and short between BCM and driver door control unit (LCU01). Refer to BL-76. "COMMUNICATION DIAGNOSIS". ● Driver door control unit (LCU01) ● Driver door control unit power and ground circuit check. ● BCM 	—
One or more power windows cannot be operated using front power window main switch	1. Driver door control unit circuit check	GW-43
	2. Communication signal circuit check	GW-33
Driver side power window cannot be operated but other windows can be operated	1. Driver door control unit circuit check	GW-43
	2. Front power window regulator (driver side) circuit check	GW-34
Passenger side power window cannot be operated	1. Passenger door control unit circuit check	GW-43
	2. Communication signal circuit check	GW-33
	3. Front power window regulator (passenger side) check	GW-35
Rear LH or RH power window cannot be operated	1. Rear door control unit (LH or RH) circuit check	GW-44
	2. Communication signal circuit check	GW-33
	3. Rear power window regulator LH or RH check	GW-36
Anti-pinch system does not operate normally. (driver side)	1. Limit switch is adjusted	GW-48
	2. Limit switch check (driver side)	GW-37
	3. Encoder switch check (driver side)	GW-39
	4. Door window sliding part malfunction. <ul style="list-style-type: none"> ● A foreign material adheres to window glass or glass run rubber. ● Glass run rubber wear or deformation. ● Sash is tilted too much, or not enough. 	—
	5. Replace driver door control unit	EI-31
Anti-pinch system does not operate normally. (passenger side)	1. Limit switch is adjusted	GW-48
	2. Limit switch check (passenger side)	GW-38
	3. Encoder switch check (passenger side)	GW-41
	4. Door window sliding part malfunction. <ul style="list-style-type: none"> ● A foreign material adheres to window glass or glass run rubber. ● Glass run rubber wear or deformation. ● Sash is tilted too much, or not enough. 	—
	5. Replace passenger door control unit	EI-31

POWER WINDOW SYSTEM


Symptom	Diagnostic procedure.	Refer to page
Power window timer function does not operate properly	1. Door switch check	GW-45
	2. Communication signal circuit check	GW-33
	Check the following <ul style="list-style-type: none"> ● harness for open and short between BCM and driver door control unit (LCU01). Refer to BL-76. "COMMUNICATION DIAGNOSIS" ● BCM ● Key switch check 	—
Does not operate by the key cylinder switch.	1. Door key cylinder switch circuit check.	GW-45
	2. Driver door control unit circuit check	GW-43
	3. Replace driver door control unit	EI-31


Communication Signal Circuit Check

AIS001MZ

1. CHECK COMMUNICATION SIGNAL

1. Turn ignition switch OFF.
2. Check the signal between malfunctioning door control unit connector and ground with oscilloscope.

Connector	Terminals (Wire color)		signal
	(+)	(-)	
D38 (passenger) D58 (rear LH) D78 (rear RH)	15 (L/Y)	Ground	 <p>SIIA0591J</p>



OK or NG

- OK >> Communication signal is OK.
 NG >> GO TO 2.

POWER WINDOW SYSTEM

2. CHECK COMMUNICATION CIRCUIT

1. Disconnect driver door control unit (LCU01) and malfunctioning door control unit connector.
2. Check continuity between driver door control unit (LCU01) and malfunctioning door control unit connector.
 - Driver door control unit (LCU01) connector D8 terminal 5 and passenger door control unit connector D38 terminal 15.

5 (L/Y) – 15 (L/Y) : Continuity should exist.

- Driver door control unit (LCU01) connector D8 terminal 5 and rear LH door control unit connector D58 terminal 15.

5 (L/Y) – 15 (L/Y) : Continuity should exist.

- Driver door control unit (LCU01) connector D8 terminal 5 and rear RH door control unit connector D78 terminal 15.

5 (L/Y) – 15 (L/Y) : Continuity should exist.


3. Check continuity between driver door control unit (LCU01) connector D8 terminal 5 and body ground.

5 (L/Y) – Ground : Continuity should not exist.

OK or NG

OK >> Replace driver door control unit (LCU01).

NG >> Repair or replace harness between driver door control unit (LCU01) and malfunctioning door control unit.



Front Power Window Regulator Circuit Check (Driver Side)

AIS001N0

1. CHECK DRIVER DOOR CONTROL UNIT OUTPUT SIGNAL


1. Turn ignition switch OFF.
2. Disconnect front power window regulator (driver side) connector.
3. Turn ignition switch ON.
4. Check voltage between front power window regulator (driver side) connector and ground.

Connector	Terminals (Wiring color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
D7	1 (L/R)	Ground	Closing	Battery voltage
			Opening	0
	2 (L/W)		Closing	0
			Opening	Battery voltage

OK or NG

OK >> Replace front power window regulator (driver side).

NG >> GO TO 2.



POWER WINDOW SYSTEM

2. CHECK DRIVER DOOR CONTROL UNIT CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver door control unit (LCU01) connector.
3. Check continuity between front power window regulator (driver side) connector D7 terminals 1, 2 and driver door control unit (LCU01) connector D8 terminals 11, 18.

18 (L/R) – 1 (L/R) : Continuity should exist.

11 (L/W) – 2 (L/W) : Continuity should exist.

4. Check continuity between driver door control unit (LCU01) connector D8 terminals 11,18 and ground.


11 (L/W) – Ground : Continuity should not exist.

18 (L/R) – Ground : Continuity should not exist.

OK or NG

OK >> Replace driver door control unit (LCU01).

NG >> Repair or replace harness between driver door control unit (LCU01) and front power window regulator (driver side).



Front Power Window Regulator Circuit Check (Passenger Side)

AIS001N1

1. CHECK PASSENGER DOOR CONTROL UNIT OUTPUT SIGNAL


1. Turn ignition switch OFF.
2. Disconnect front power window regulator (passenger side) connector.
3. Turn ignition switch ON.
4. Check voltage between front power window regulator (passenger side) connector and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
D37	1 (L/R)	Ground	Closing	Battery voltage
			Opening	0
	2 (L/W)		Closing	0
			Opening	Battery voltage

OK or NG

OK >> Replace power window regulator (passenger side).

NG >> GO TO 2.



A
B
C
D
E
F
G
H
J
K
L
M

GW

POWER WINDOW SYSTEM

2. CHECK FRONT POWER WINDOW REGULATOR (PASSENGER SIDE) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect passenger door control unit connector.
3. Check continuity between passenger door control unit connector D38 terminals 3, 14 and front power window regulator (passenger side) connector D37 terminals 1, 2.

3 (L/W) – 2 (L/W) : Continuity should exist.

14 (L/R) – 1 (L/R) : Continuity should exist.

4. Check continuity between passenger door control unit connector D38 terminals 3, 14 and ground.


3 (L/W) – Ground : Continuity should not exist.

14 (L/R) – Ground : Continuity should not exist.

OK or NG

OK >> Replace passenger door control unit.

NG >> Repair or replace harness between passenger door control unit and front power window regulator (passenger side).



Rear Power Window Regulator LH or RH Circuit Check

AIS001N2

1. CHECK REAR DOOR CONTROL UNIT LH OR RH OUTPUT SIGNAL


1. Turn ignition switch ON.
2. Check voltage between rear power window regulator LH or RH connector D57 (LH) or D77 (RH) terminals 1, 2 and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
D57 (LH) D77 (RH)	1 (L/R)	Ground	Closing	Battery voltage
			Opening	0
	2 (L/W)		Closing	0
			Opening	Battery voltage

OK or NG

OK >> Replace rear power window regulator LH or RH.

NG >> GO TO 2.



2. CHECK REAR POWER WINDOW REGULATOR LH OR RH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear door control unit LH or RH and rear power window regulator LH or RH connector.
3. Check continuity between rear door control unit LH or RH connector D58 (LH) or D78 (RH) terminals 3, 14 and rear power window regulator LH or RH connector D57 (LH) or D77 (RH) terminals 1, 2.

3 (L/W) – 2 (L/W) : Continuity should exist.

14 (L/R) – 1 (L/R) : Continuity should exist.

4. Check continuity between rear door control unit LH or RH connector D58 (LH) or D78 (RH) terminals 3, 14 and ground.


3 (L/W) – Ground : Continuity should not exist.

14 (L/R) – Ground : Continuity should not exist.

OK or NG

OK >> Replace rear door control unit LH or RH.

NG >> Repair or replace harness between rear door control unit LH or RH and rear power window regulator LH or RH.



POWER WINDOW SYSTEM


AIS001N3

Limit Switch Check (Driver Side)

1. CHECK DRIVER DOOR LIMIT SWITCH SIGNAL

1. Turn ignition switch ON.
2. Check voltage between driver door control unit (LCU01) connector and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
D8	7 (PU)	Ground	Driver side door window is in a position between fully-open and just before fully-closed position (ON).	0
			Driver side door window is in a position between just before fully-closed position and fully-closed position (OFF).	5



OK or NG

- OK >> Limit switch circuit is OK.
 NG >> GO TO 2.


2. CHECK LIMIT SWITCH GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect front power window regulator (driver side) connector.
3. Check continuity between front power window regulator (driver side) connector D7 terminal 3 and ground.

3 (B) – Ground : Continuity should exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair or replace harness.



3. CHECK HARNESS CONTINUITY

1. Disconnect driver door control unit (LCU01) connector.
2. Check continuity between driver door control unit (LCU01) connector D8 terminal 7 and front power window regulator (driver side) connector D7 terminal 4.


7 (PU) – 4 (PU) : Continuity should exist.

3. Check continuity between driver door control unit (LCU01) connector D8 terminal 7 and ground.

7 (PU) – Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair or replace harness between driver door control unit (LCU01) and front power window regulator (driver side).



POWER WINDOW SYSTEM


4. CHECK DRIVER DOOR CONTROL UNIT OUTPUT SIGNAL

1. Connect driver door control unit (LCU01) connector.
2. Turn ignition switch ON.
3. Check voltage between driver door control unit (LCU01) connector D8 terminal 7 and ground.

7(PU) – Ground : Approx. 5V

OK or NG

- OK >> Replace front power window regulator (driver side).
 NG >> Replace driver door control unit (LCU01).



PIIA2686E


AIS001N4

Limit Switch Check (Passenger Side)

1. CHECK PASSENGER DOOR LIMIT SWITCH SIGNAL

1. Turn ignition switch ON.
2. Check voltage between passenger door control unit connector and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
D38	1 (PU)	Ground	Passenger side door window is in a position between fully-open and just before fully-closed position (ON).	0
			Passenger side door window is in a position between just before fully-closed position and fully-closed position (OFF).	5



PIIA2689E

OK or NG

- OK >> Limit switch circuit is OK.
 NG >> GO TO 2.


2. CHECK LIMIT SWITCH GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect front power window regulator (passenger side) connector.
3. Check continuity between front power window regulator (passenger side) connector D37 terminal 3 and ground.

3 (B) – Ground : Continuity should exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair or replace harness.



PIIA2690E

POWER WINDOW SYSTEM

3. CHECK HARNESS CONTINUITY

1. Disconnect passenger door control unit connector.
2. Check continuity between passenger door control unit connector D38 terminal 1 and front power window regulator (passenger side) connector D37 terminal 4.

1 (PU) – 4 (PU) : Continuity should exist.


3. Check continuity between passenger door control unit connector D38 terminal 1 and ground.

1 (PU) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Repair or replace harness between passenger door control unit and front power window regulator (passenger side).



4. CHECK PASSENGER DOOR CONTROL UNIT OUTPUT SIGNAL


1. Connect passenger door control unit connector.
2. Turn ignition switch ON.
3. Check voltage between passenger door control unit connector D38 terminal 1 and ground.

1 (PU) – Ground : Approx. 5V

OK or NG

OK >> Replace front power window regulator (passenger side).

NG >> Replace passenger door control unit.



Encoder Switch Check (Driver Side)

1. CHECK FRONT POWER WINDOW REGULATOR (DRIVER SIDE) POWER SUPPLY


1. Turn ignition switch ON.
2. Check voltage between driver door control unit (LCU01) connector D8 terminal 4 and ground.

4 (W) – Ground : Approx. 10V

OK or NG

OK >> GO TO 2.

NG >> Replace driver door control unit (LCU01).



POWER WINDOW SYSTEM

2. CHECK HARNESS CONTINUITY


1. Turn ignition switch OFF.
2. Disconnect driver door control unit (LCU01) and front power window regulator (driver side) connector.
3. Check continuity between driver door control unit (LCU01) connector D8 terminal 4 and front power window regulator (driver side) connector D7 terminal 5.

4 (W) – 5 (W) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair or replace harness between driver door control unit (LCU01) and front power window regulator (driver side).



3. CHECK ENCODER GROUND


Check continuity between front power window regulator (driver side) connector D7 terminal 3 and ground.

3 (B) – Ground : Continuity should exist.

OK or NG

OK >> GO TO 4.


NG >> Repair or replace harness.



4. CHECK ENCODER SIGNAL

1. Connect driver door control unit (LCU01) and front power window regulator (driver side) connector.
2. Turn ignition switch ON.
3. Check the signal between driver door control unit (LCU01) connector and ground with oscilloscope.

Connector	Terminals (Wire color)		Condition	Signal
	(+)	(-)		
D8	1 (G)	Ground	Opening	<p>OCC3383D</p>



OK or NG

OK >> Encoder switch circuit is OK.

NG >> GO TO 5.

POWER WINDOW SYSTEM

5. CHECK ENCODER CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver door control unit (LCU01) and front power window regulator (driver side) connector.
3. Check continuity between driver door control unit (LCU01) connector D8 terminal 1 and front power window regulator (driver side) connector D7 terminal 6.


1 (G) – 6 (G) : Continuity should exist.

4. Check continuity between driver door control unit (LCU01) connector D8 terminal 1 and ground.

1 (G) – Ground : Continuity should not exist.

OK or NG

- OK >> Replace front power window regulator (driver side)
NG >> Repair or replace harness between driver door control unit (LCU01) and front power window regulator (driver side).



AIS001N6

Encoder Switch Check (Passenger Side)


1. CHECK FRONT POWER WINDOW REGULATOR (PASSENGER SIDE) POWER SUPPLY

1. Turn ignition switch ON.
2. Check voltage between passenger door control unit connector D38 terminal 4 and ground.

4 (W) – Ground : Approx. 10V

OK or NG

- OK >> GO TO 2.
NG >> Replace passenger door control unit.




2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect passenger door control unit and front power window regulator (passenger side) connector.
3. Check continuity between driver door control unit (LCU01) connector D38 terminal 4 and front power window regulator (passenger side) connector D37 terminal 5.

4 (W) – 5 (W) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
NG >> Repair or replace harness between passenger door control unit and front power window regulator (passenger side).



POWER WINDOW SYSTEM

3. CHECK ENCODER GROUND


Check continuity between front power window regulator (passenger side) connector D37 terminal 3 and ground.

3 (B) – Ground : Continuity should exist.

OK or NG

OK >> GO TO 4.


NG >> Repair or replace harness.



4. CHECK ENCODER SIGNAL

1. Connect passenger door control unit and front power window regulator (passenger side) connector.
2. Turn ignition switch ON.
3. Check the signal between passenger door control unit connector and ground with oscilloscope.

Connector	Terminals (Wire color)		Condition	Signal
	(+)	(-)		
D38	12 (G)	Ground	Opening	<p>OCC3383D</p>



OK or NG

OK >> Encoder switch circuit is OK.

NG >> GO TO 5.

5. CHECK ENCODER CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect passenger door control unit and front power window regulator (passenger side) connector.
3. Check continuity between passenger door control unit connector D38 terminal 12 and front power window regulator (passenger side) connector D37 terminal 6.

12 (G) – 6 (G) : Continuity should exist.


4. Check continuity between passenger door control unit connector D38 terminal 12 and ground.

12 (G) – Ground : Continuity should not exist.

OK or NG

OK >> Replace front power window regulator (passenger side)

NG >> Repair or replace harness between passenger door control unit and front power window regulator (passenger side).



POWER WINDOW SYSTEM

Driver Door Control Unit Circuit Check

AIS001NB

1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver door control unit (LCU01) connector.
3. Check voltage between driver door control unit (LCU01) connector D8 terminal 14 and ground.


14 (Y/G) – Ground : Battery voltage

OK or NG

OK >> GO TO 2.

NG >> Check the following.

- 40A fusible link (letter H, located in fuse and fusible link box).
- Harness for open or short between driver control unit (LCU01) and fuse.



2. CHECK GROUND CIRCUIT


Check continuity between driver door control unit (LCU01) connector D8 terminal 15 and ground.

15 (B) – Ground : Continuity should exist.

OK or NG

OK >> INSPECTION END

NG >> Repair or replace harness.



Passenger Door Control Unit Circuit Check

AIS001NR

1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect passenger door control unit connector.
3. Check voltage between passenger door control unit connector D38 terminal 10 and ground.


10 (W/R) – Ground : Battery voltage

OK or NG

OK >> GO TO 2.

NG >> Check the following.

- 40A fusible link (letter H, located in fuse and fusible link box).
- Harness for open or short between passenger control unit and fuse.



POWER WINDOW SYSTEM


2. CHECK GROUND CIRCUIT

Check continuity between passenger door control unit connector D38 terminal 11 and ground.

11 (B) – Ground : Continuity should exist.

OK or NG

- OK >> INSPECTION END
NG >> Repair or replace harness.



Rear Door Control Unit (LH or RH) Circuit Check


1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear door control unit connector.
3. Check voltage between rear door control unit LH or RH connector D58 or D78 terminal 10 and ground.

10 (Y/B) – Ground : Battery voltage

OK or NG

- OK >> GO TO 2.
NG >> Check the following.
- 40A fusible link (letter H, located in fuse and fusible link box).
 - Harness for open or short between rear control unit LH or RH and fuse.




2. CHECK GROUND CIRCUIT

Check continuity between rear door control unit LH or RH connector D58 or D78 terminal 11 and ground.

11 (B) – Ground : Continuity should exist.

OK or NG

- OK >> INSPECTION END
NG >> Repair or replace harness.



POWER WINDOW SYSTEM

Door Switch Check

AIS001NU


1. CHECK DOOR SWITCH INPUT SIGNAL

☑ With CONSULT-II

- Check door switch in "DATE MONITOR" mode with CONSULT-II.

When door is opened : DOOR SW ON

When door is closed : DOOR SW OFF



☒ Without CONSULT-II

- Check all door switches in switch monitor mode. Refer to Remote keyless entry system, [BL-79, "SWITCH MONITOR"](#).

OK or NG


OK >> Door switch is OK.

NG >> GO TO 2.

2. CHECK DOOR SWITCH

- Turn ignition switch OFF.
- Disconnect door switch connector.
- Check continuity between following terminals and ground.

Door switch connector		Terminals (Wire color)	Condition	Continuity
Front door switch (driver side)	B20	1 (R/Y) – Ground	Pressed	No
			Released	Yes
Front door switch (passenger side)	B220	1 (LG) – Ground	Pressed	No
			Released	Yes



OK or NG

OK >> Check harness for open and short between door switch and BCM.

NG >> Check door switch ground condition.


Door Key Cylinder Switch Check

AIS002MV

1. CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL

Check voltage between driver door control unit (LCU01) connector and ground.

Connector	Terminals (Wire color)		Key position	Voltage (V) (Approx.)
	(+)	(-)		
D8	9 (PU/W)	Ground	Neutral/Unlock	5
			Lock	0
	10 (GY)		Neutral/Lock	5
			Unlock	0



OK or NG

OK >> Further inspection is necessary. Refer to symptom chart.

NG >> GO TO 2.

POWER WINDOW SYSTEM


2. CHECK DOOR KEY CYLINDER SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver door control unit (LCU01) and front door key cylinder switch connector.
3. Check continuity between driver door control unit (LCU01) connector D8 terminal 9, 10 and front door key cylinder switch connector D12 terminals 1, 3.

9 (PU/W) – 1 (PU/W) : Continuity should exist.
10 (GY) – 3 (GY) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair or replace harness between driver door control unit (LCU01) and front door key cylinder switch.




3. CHECK DOOR KEY CYLINDER SWITCH GROUND

Check continuity between front door key cylinder switch connector D12 terminal 2 and ground.

2 (B) – Ground : Continuity should exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair or replace harness.




4. CHECK DOOR KEY CYLINDER SWITCH

Check continuity between front door key cylinder switch terminal 1, 3 and 2.

Terminals		Key position	Continuity
1	2	Neutral/Lock	No
		Unlock	Yes
3		Neutral/Unlock	No
		Lock	Yes

OK or NG

- OK >> Check the condition of the harness and the connector.
 NG >> Replace door key cylinder switch.




FRONT DOOR GLASS AND REGULATOR

FRONT DOOR GLASS AND REGULATOR

PPF:80300

Removal and Installation


AIS001GP



- | | | |
|-----------------------|------------------|---------------------|
| 1. Front door glass | 2. Glass stopper | 3. Guide channel |
| 4. Regulator assembly | 5. Glass guide | 6. Main channel |
| 7. Sub channel | 8. Guide rail | 9. Inner stabilizer |


REMOVAL

1. Remove front door finisher. Refer to [EI-31, "DOOR FINISHER"](#) .
2. Remove door speaker. Refer to [AV-30, "Removal and Installation of Door Speaker"](#) .
3. Remove front door outside molding. Refer to [EI-27, "DOOR OUTSIDE MOLDING"](#) .
4. Remove door sealing screen assembly.
5. Remove door inner cover. Refer to [GW-117, "Removal and Installation"](#) .
6. Remove glass stopper and inner stabilizer.




FRONT DOOR GLASS AND REGULATOR

- Operate power window main switch to raise/lower door window until glass mounting nuts can be seen.
- Remove glass mounting nuts.



- While holding door glass, raise it at the rear end to pull the guide roller out of guide rail.
- Remove glass guide from glass channel while lifting the whole and detach glass.
- Remove bolt and nut of guide rail then remove guide rail.
- Disconnect harness connector and clip harness.
- Remove bolt of regulator assembly then remove regulator assembly.
- Remove bolt and nut of guide channel then remove guide channel.



INSTALLATION

Install in the reverse order of removal.

INSPECTION AFTER REMOVAL

Check the regulator assembly for the following items. If a malfunction is detected, replace it or apply multi-purpose grease.

- Gear wear
- Spring damage
- Regulator deformation
- Grease condition for each sliding part

SETTING AFTER INSTALLATION

Setting of Limit Switch

If any of the following work has been done, set the limit switch (integrated in the motor).

- Removal and installation of the regulator.
- Removal and installation of the motor from the regulator.
- Operate the regulators as a unit.
- Removal and installation of the glass.
- Removal and installation of the glass stopper.

FRONT DOOR GLASS AND REGULATOR


Resetting

After installing each component to the vehicle and adjusting the glass fitting, follow the steps below.

1. Raise the glass to the top position.
2. While pressing and holding the reset switch, lower the glass to the bottom position.
3. Release the reset switch, and check that the reset switch returns to the original position, and then raise the glass to the top position.

CAUTION:

Do not operate the glass automatically to raise the glass to the top position.



FITTING INSPECTION

- Check that the glass is securely fit into the body side weatherstrip.
- Lower the glass slightly [approx. 10 to 20 mm (0.39 to 0.79 in)] and check that the clearance to the weatherstrip is parallel. If the clearance between the glass and weatherstrip is not parallel, adjust glass fitting.

A
B
C
D
E
F
G
H
J
K
L
M

GW

FRONT DOOR GLASS AND REGULATOR

AIS001G0


Door Glass Fitting Adjustment

The door glass is properly adjusted using the following five methods:


- [A] In-out adjustment (at the glass waist).
- [B] Fore-aft tilt adjustment.
- [C] In-out tilt adjustment.
- [D] Up-stop adjustment.
- [E] Fore-aft adjustment.

NOTE:


- When adjusting the door glass, it is not necessary to remove the outside door molding.
- After completing door glass adjustment, retighten all lock nuts.



ADJUSTMENT LOCATIONS



ADJUSTMENT STANDARD CLEARANCE




FRONT DOOR GLASS AND REGULATOR

[A] IN-OUT ADJUSTMENT (AT THE GLASS WAIST)

1. Raise door glass until glass stopper is in contact with inner stabilizer, just before the window stops.
2. Loosen adjusting bolts.
3. Lightly press door glass upper end outward so that glass outer surface contacts outer. With glass held in that position, press inner stabilizer to glass inner surface and tighten adjusting bolt.

CAUTION:

Make sure nap portions of stabilizers are clean and free from oil, grease, etc.




[B] FORE-AFT TILT ADJUSTMENT

- Adjust front glass sub-channel at the glass and retainer holder/body side weatherstrip location.
- For sub-channel adjustment procedures, refer to figure at right as a guide.

CAUTION:

- Make sure door glass sub-channel is horizontal.
- The fore-aft tilt adjustment must be made at the same time the fore-aft adjustment [E] is made.




[C] IN-OUT TILT ADJUSTMENT (AT GUIDE RAIL)

1. Adjust door glass-to-holder clearance to 0 to 3.5 mm (0 to 0.138 in) with the adjusting bolts.


CAUTION:

- Turn adjusting bolt clockwise to move door glass upper end outward.
- Turn adjusting bolt counterclockwise to move door glass upper end inward.



[D] UP-STOP ADJUSTMENT

1. Adjust panel side stopper location so that clearance at upper edge of door is standard measurement to 0 to 3.5 mm (0 to 0.138 in). Make sure front and rear glass side stoppers lightly contact front and rear panel side stoppers, then tighten adjusting nuts.
2. If stoppers do not contact each other, adjust sub-channel nut. Refer to "[B] Fore-aft tilt adjustment".
3. Open and close doors to make sure upper end of door glass does not contact holder.




FRONT DOOR GLASS AND REGULATOR

[E] FORE-AFT ADJUSTMENT

1. Lower the glass slightly until the glass side stopper comes off the panel side stopper.

CAUTION:

Do not lower the glass excessively.




2. Loosen lock nuts, and adjust guide rail in the fore-aft direction so that clearance between upper edge of door glass and holder is constant at the midpoint of holder specified dimension to 0 to 3.5 mm (0 to 0.138 in). Check that there is no interference between glass and holder when door is closed or opened.

CAUTION:

While loosening and tightening lock nuts, hold adjusting bolts using a standard screwdriver to prevent them from turning.

3. If outer perimeter of door glass interferes with holder when door is opened or closed, refer to "[B] Fore-aft tilt adjustment" for procedures.




REAR DOOR GLASS AND REGULATOR

REAR DOOR GLASS AND REGULATOR

PF82300

Removal and Installation


AIS001G0



- | | | |
|------------------|-------------------------------|-----------------------|
| 1. Glass stopper | 2. Guide channel | 3. Regulator assembly |
| 4. Sub-channel | 5. Glass guide | 6. Main channel |
| 7. Guide rail | 8. Door glass assembly (Rear) | 9. Inner stabilizer |


REMOVAL

1. Remove rear door finisher. Refer to [EI-31, "DOOR FINISHER"](#) .
2. Remove rear door speaker. Refer to [AV-30, "Removal and Installation of Door Speaker"](#) .
3. Remove sealing screen.
4. Remove rear door outside molding. Refer to [EI-27, "DOOR OUTSIDE MOLDING"](#) .
5. Remove glass stopper and inner stabilizer.
6. Operate power window sub-switch to raise/lower door window until glass mounting bolts can be seen.
7. Remove glass mounting nuts.




REAR DOOR GLASS AND REGULATOR

8. Remove glass guide from guide channel while lifting the whole.
9. Pull out back guide roller from guide rail and detach glass.



10. Remove bolt and nut of guide rail, then remove guide rail.
11. Remove the harness connector routed on the frame assembly, then remove the harness clip from the back.
12. Remove bolt of sub-channel and regulator then remove regulator assembly.
13. Remove bolt and nut of guide channel, then remove guide channel.



INSTALLATION

Install in the reverse order of removal.

INSPECTION AFTER REMOVAL

Check the regulator assembly for the following items. If a malfunction is detected, replace or grease it.

- Gear wear
- Regulator deformation
- Spring damage
- Grease condition for each sliding part

FITTING INSPECTION

- Check that the glass is securely fit into the body side weatherstrip.
- Lower the glass slightly [approx. 10 to 20 mm (0.39 to 0.79 in)], and check that the clearance to the weatherstrip is parallel. If the clearance between the glass and weatherstrip is not parallel, adjust glass fitting.

REAR DOOR GLASS AND REGULATOR

Door Glass Fitting Adjustment


AIS001Q1

The door glass is properly adjusted using the following five methods:


- [A] In-out adjustment (at the glass waist).
- [B] Fore-aft tilt adjustment.
- [C] In-out tilt adjustment.
- [D] Up-stop adjustment.
- [E] Fore-aft adjustment.

NOTE:


- When adjusting the door glass, it is not necessary to remove the outside door molding.
- After completing door glass adjustment, retighten all lock nuts.



ADJUSTMENT LOCATIONS



ADJUSTMENT STANDARD CLEARANCE



A
B
C
D
E
F
G
H
J
K
L
M

GW


REAR DOOR GLASS AND REGULATOR

[A] IN-OUT ADJUSTMENT (AT THE GLASS WAIST)

1. Raise door glass until glass stopper is in contact with inner stabilizer, just before the window stops.
2. Loosen adjusting bolts.
3. Lightly press door glass upper end outward so that glass outer surface contacts outer. With glass held in that position, press inner stabilizer to glass inner surface and tighten adjusting bolt.

CAUTION:

- Make sure nap portions of stabilizers are clean and free from oil, grease, etc.
- Make sure that stabilizers are parallel with glass surface.




[B] FORE-AFT TILT ADJUSTMENT

- Adjust front glass sub-channel at the glass and retainer holder/body side weatherstrip location.
- For sub-channel adjustment procedures, refer to figure at right as a guide.

CAUTION:

The fore-aft tilt adjustment must be made at the same time the fore-aft adjustment [E] is made.




[C] IN-OUT TILT ADJUSTMENT (AT GUIDE RAIL)

1. Adjust door glass-to-holder clearance to 0 to 3.5 mm (0 to 0.138 in) with the adjusting bolts.


CAUTION:

- Turn adjusting bolt clockwise to move door glass upper end outward.
- Turn adjusting bolt counterclockwise to move door glass upper end inward.



[D] UP-STOP ADJUSTMENT

1. Adjust panel stopper location so that clearance at upper edge of door is standard measurement to 0 to 3.5 mm (0 to 0.138 in). Make sure front and rear glass stoppers lightly contact front and rear panel stoppers, then tighten adjusting nuts.
2. If stoppers do not contact each other, adjust sub-channel nut. Refer to "[B] Fore-aft tilt adjustment".
3. Open and close doors to make sure upper end of door glass does not contact holder.




REAR DOOR GLASS AND REGULATOR

[E] FORE-AFT ADJUSTMENT

1. Lower the glass slightly until the glass side stopper comes off the panel side stopper.

CAUTION:

Do not lower the glass excessively.




2. Loosen lock nuts, and adjust guide rail in the fore-aft direction so that clearance between upper edge of door glass and holder is constant at the midpoint of holder specified dimension to 0 to 3.5 mm (0 to 0.138 in). Check that there is no interference between glass and holder when door is closed or opened.

CAUTION:

While loosening and tightening lock nuts, hold adjusting bolts using a standard screwdriver to prevent them from turning.

3. If outer perimeter of door glass interferes with holder when door is opened or closed, refer to "[B] Fore-aft tilt adjustment" for procedures.



A
B
C
D
E
F
G
H
J
K
L
M

GW

INSIDE MIRROR





PFP:96321

INSIDE MIRROR

Wiring Diagram — I/MIRR —

AIS001GR

GW-I/MIRR-01



REFER TO THE FOLLOWING.


(D1) -SUPER MULTIPLE JUNCTION (SMJ)

(E201), (R1) -FUSE BLOCK-JUNCTION BOX (J/B) NO.1

INSIDE MIRROR

Removal and Installation

AIS001GS



A
B
C
D
E
F
G
H
GW
J
K
L
M

1. Inside mirror

2. Inside mirror finisher

REMOVAL

1. Remove inside mirror finisher.
2. Remove screw of inside mirror base.
3. Slide inside mirror upward to remove, and disconnect the connector.

INSTALLTION

Install in the reverse order of removal.


REAR WINDOW DEFOGGER

PF25350

REAR WINDOW DEFOGGER

Component Parts and Harness Connector Location

AIS001GU



System Description

AIS001GT

The rear window defogger system is controlled by the BCM (Body Control Module). The rear window defogger is operated only for approximately 15 minutes.

Power is supplied at all times

- through 20A fuse [No.10, located in the fuse block (J/B)],
- to the rear window defogger and door mirror defogger relay terminal 6,
- through 20A fuse [No.11, located in the fuse block (J/B)],
- to the rear window defogger and door mirror defogger relay terminal 3,
- through 10A fuse [No.3, located in the fuse block (J/B)],
- to BCM terminal 105.

With the ignition switch in the ACC or ON position,
Power is supplied

- through 10A fuse [No.4, located in the fuse block (J/B)]
- to the door mirror defogger relay terminal 5.

With the ignition switch in the ON or START position,
Power is supplied

- through 10A fuse [No.1, located in the fuse block (J/B)],
- to BCM terminal 68, and
- to the rear window defogger and door mirror defogger relay terminal 1.

When the rear defogger switch in the multifunction switch is ON,
Ground is supplied

- to multifunction switch (rear window defogger switch) terminal 5,
- through BCM terminal 10,
- through BCM terminal 56,
- through body grounds M24 and M114.

Then BCM recognizes that rear window defogger switch is turned to ON,
Ground is supplied

- to the rear window defogger and door mirror defogger relay terminal 2,
- through BCM terminal 144,
- through BCM terminal 56,
- through body grounds M24 and M114.

With power and ground supplied rear window defogger and door mirror defogger relay is energized.
When rear window defogger and door mirror defogger relay is turned ON,

REAR WINDOW DEFOGGER

Power is supplied.

- through rear window defogger and door mirror defogger relay terminal 5 and 7,
- through condenser terminal 1,
- to rear window defogger terminal 2.

Ground is supplied

- to rear window defogger terminal 1,
- through body ground B422.

This power and ground supplied rear window defogger filaments heat and defog the rear window. When rear window defogger and door mirror defogger relay is turned ON, power is supplied.

- through rear window defogger and door mirror defogger relay terminal 5 and 7,
- to door mirror defogger relay terminal 2.

Ground is supplied

- to Door mirror defogger relay terminal 1,
- through body ground B17 and B57.

When door mirror defogger relay is energized.

When door mirror defogger relay is turned ON, power is supplied.

- through door mirror defogger relay terminal 3,
- to door mirror defogger terminal (Driver side and Passenger side) 6.

Ground is supplied

- to door mirror defogger (Driver side and Passenger side) terminal 5.
- through body grounds M24 and M114.

With power and grounds supplied, door mirror defogger filaments heat and defog the mirror.

When rear window defogger and door mirror defogger relay is turned ON, power is supplied.

- through rear window defogger and door mirror defogger relay terminal 5 and 7,
- to multifunction switch (rear window defogger switch) terminal 6.

Ground is supplied

- to multifunction switch (rear window defogger switch) terminal 2,
- through body ground M24 and M114.

Then rear window defogger switch indicator is illuminated.

A

B

C

D

E

F

G

H

GW

J

K


L

M

REAR WINDOW DEFOGGER

Schematic

AI5001GV




TIWM0036E

REAR WINDOW DEFOGGER

Wiring Diagram — DEF —

AIS001GW


GW-DEF-01



REFER TO PG-POWER.

NEXT PAGE

A
B
C
D
E
F
G
H
GW
J
K
L
M







*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

REFER TO THE FOLLOWING.
 (M1), (B1), (B2) - FUSE
 BLOCK-JUNCTION BOX (J/B) NO.1

TIWA0230E

REAR WINDOW DEFOGGER

GW-DEF-03



REFER TO THE FOLLOWING.

(M5), (D1), (D31) -SUPER MULTIPLE JUNCTION (SMJ)

(M1) -FUSE BLOCK-JUNCTION BOX (J/B) NO.1

TIWA0232E

REAR WINDOW DEFOGGER

Terminals and Reference Value for BCM

AIS001O1

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
10	G/R	Rear defogger switch signal	Rear defogger switch ON	0V
			Rear defogger switch OFF	Approx.5V
56	B	Ground	—	0V
68	W/B	IGN power supply	Ignition switch ON or START	Battery voltage
105	Y/L	BAT power supply	—	Battery voltage
113	B	Ground	—	0V
144	G/W	Rear window defogger and door mirror defogger relay control signal	Rear defogger switch ON	0V
			Rear defogger switch OFF	Battery voltage

Work Flow

AIS001GX

1. Check the symptom and customer's requests.
2. Understand the outline of system. Refer to [GW-60, "System Description"](#) .
3. The preliminary check. Refer to [GW-66, "Preliminary Check"](#) .
4. According to the trouble diagnosis chart, repair or replace the cause of the malfunction. Refer to [GW-69, "Trouble Diagnosis Symptom Chart"](#) .
5. Does rear defogger operate normally? OK: GO TO 6. NG: GO TO 4.
6. Inspection end.

Preliminary Check

AIS002MW

POWER SUPPLY AND GROUND CIRCUIT INSPECTION

1. FUSE INSPECTION

- Check that any of the following fuses in the BCM is blown.

Unit	Terminal NO.	Power source	Fuse NO.
BCM	105	BAT power supply	#3
	68	IGN power supply	#1

NOTE:

Refer to [GW-60, "Component Parts and Harness Connector Location"](#) .

OK or NG?

OK >> GO TO 2.


NG >> If fuse is blown, be sure to eliminate cause of problem before installing new fuse. Refer to [PG-2, "POWER SUPPLY ROUTING"](#) .

REAR WINDOW DEFOGGER

2. POWER SUPPLY CIRCUIT INSPECTION (BCM)

1. Turn ignition switch OFF.
2. Disconnect the BCM connector M4, check voltage between connector terminal (refer to the "Chart below") of the harness connector and ground.

Terminals		Power source	Condition	Voltage (V) (Approx.)
(+)	(-)			
Connector	Terminal (Wire color)			
M4	105(Y/L)	BAT power supply	Ignition switch OFF	Battery voltage
	68(W/B)	IGN power supply	Ignition switch ON	Battery voltage



OK or NG?

- OK >> GO TO 3.
 NG >> Check harness for open and short between BCM and fuse.


3. GROUND CIRCUIT INSPECTION (BCM)

Check continuity between BCM connector M4 terminals and ground.

- 56 (B) – Ground : Continuity should exist.**
113 (B) – Ground : Continuity should exist.

OK or NG?

- OK >> System is OK.
 NG >> Repair or replace harness.




REAR WINDOW DEFOGGER


AIS001Q5

CONSULT-II Function CONSULT-II BASIC OPERATION PROCEDURE


1. Turn ignition switch OFF.
2. Connect "CONSULT-II" and CONSULT-II CONVERTER to data link connector.




3. Turn ignition switch ON.
4. Touch "START (NISSAN BASED VHCL)".



5. Touch "IVMS" on the "SELECT SYSTEM" screen.



6. Check the model specification, and touch either "WITH SUNROOF" or "WITHOUT SUNROOF" on the "SELECT SYS COND" screen.
7. Touch "OK". If the selection is wrong, touch "CANCEL".
8. Select the desired part to be diagnosed on the "SELECT TEST ITEM" screen.



DATA MONITOR Display Item List

Monitor item "Operation"		Content
REAR DEF SW	"ON/OFF"	Displays "Press (ON)/others (OFF)" status determined with the rear window defogger switch.
IGN ON SW	"ON/OFF"	Displays "IGN (ON)/OFF" status determined with the ignition switch signal.

REAR WINDOW DEFOGGER

ACTIVE TEST

Display Item List

Test item	Content
REAR DEFOGGER	Gives a drive signal to the rear window defogger to activate it.

Trouble Diagnosis Symptom Chart

AIS00103

- Check that other systems using the signal of the following systems operate normally.

Symptom	Diagnoses / service procedure	Refer to page
Rear window defogger and door mirror defogger do not operate.	1, Rear window defogger switch circuit check.	GW-69
	2, Rear window defogger and door mirror defogger circuit check.	GW-70
	3, Replace BCM	-
Rear window defogger does not operate, but door mirror defogger operates.	1, Rear window defogger circuit check.	GW-72
	2, Filament check.	GW-76
Door mirror defogger does not operated, but rear window defogger operates.	1, Door mirror defogger power supply circuit check.	GW-73
Driver side door mirror defogger does not operated, but door mirror defogger operates	1, Driver side door mirror defogger circuit check.	GW-74
Passenger side door mirror defogger does not operated, buy door mirror defogger operates.	1, Passenger side door mirror defogger circuit check.	GW-75

Rear Window Defogger Switch Circuit Check

AIS00105


1. REAR WINDOW DEFOGGER (MULTIFUNCTION) SWITCH INSPECTION

④ With CONSULT-II

Check rear window switch "REAR DEF SW" in "DATA MONITOR" mode with CONSULT-II.

When rear window defogger switch ON


REAR DEF SW : ON



⊗ With out CONSULT-II

- Turn ignition switch ON.
- Check voltage between BCM connector M4 terminal 10(G/R) and ground.

Con- nector	Terminal (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
M4	10 (G/R)	Ground	When rear window defogger switch is pressed.	0
			When rear window defogger switch is OFF.	5



OK or NG

- OK >> Rear window defogger switch check is OK.
 NG >> GO TO 2.

REAR WINDOW DEFOGGER

2. REAR WINDOW DEFOGGER SWITCH SIGNAL CIRCUIT INSPECTION

1. Disconnect BCM connector and multifunction switch (rear window defogger with) connector.
2. Check continuity between BCM connector M4 terminal 10(G/R) and multifunction switch (rear defogger switch) connector M83 terminal 5(G/R).

10 (G/R) – 5(G/R) :Continuity should exist.


3. Check continuity between BCM harness connector M4 terminal 10(G/R) and ground

10 (G/R) – ground :Continuity should not exist.

OK or NG

OK >> GO TO 3.

NG >> Repair or replace harness between BCM and multifunction switch (rear window defogger switch).



3. MULTIFUNCTION (REAR WINDOW DEFOGGER) SWITCH GROUND HARNESS INSPECTION


Check continuity between multifunction (rear window defogger) switch connector M83 terminal 2 (B) and ground.

2(B) – ground : Continuity should exist.

OK or NG

OK >> Replace multifunction switch.

NG >> Repair or replace harness between multifunction (rear window defogger) switch and ground.



Rear Window Defogger and Door Mirror Defogger Circuit Check

AIS00106

1. CHECK FUSE

1. Turn ignition switch OFF.
2. Check if the following fuse for Fuse block (J/B) is blown.

COMPONENT PARTS	TERMINAL NO. (SIGNAL)	AMPERE	FUSE NO.
Fuse block (J/B)	2J (IGN power supply)	10A	#1

NOTE:

Refer to [GW-60. "Component Parts and Harness Connector Location"](#).

OK or NG

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse, refer to [PG-2. "POWER SUPPLY ROUTING"](#).

REAR WINDOW DEFOGGER

2. REAR WINDOW DEFOGGER AND DOOR MIRROR DEFOGGER RELAY POWER SUPPLY CIRCUIT INSPECTION


1. Disconnect rear window defogger and door mirror defogger relay.
2. Turn ignition switch ON.
3. Check voltage between rear window defogger and door mirror defogger relay harness connector B8 terminal 1 (W/G) and ground.

1 (W/G) – Ground : Battery voltage

OK or NG

OK >> GO TO 3.


NG >> Repair or replace harness between fuse block (J/B) and rear window defogger and door mirror defogger relay.



3. REAR WINDOW DEFOGGER AND DOOR MIRROR DEFOGGER RELAY INSPECTION

Check continuity between terminals 3 and 5, 6 and 7.

Terminal		Condition	Continuity
(+)	(-)		
3	5	12V direct current supply between terminals 1 to 2	Should exist
		No current supply	Should not exist
6	7	12V direct current supply between terminals 1 to 2	Should exist
		No current supply	Should not exist



OK or NG

OK >> GO TO 4.

NG >> Replace rear window defogger and door mirror defogger relay.

4. REAR WINDOW DEFOGGER AND DOOR MIRROR DEFOGGER RELAY GROUND HARNESS INSPECTION


1. Turn ignition switch OFF.
2. Installation rear window defogger and door mirror defogger relay.
3. Turn ignition switch ON.
4. Check voltage between BCM connector terminal 144 (G/W) and ground.

144 (G/W) – Ground : Battery voltage

OK or NG

OK >> Rear window defogger and door mirror defogger circuit is OK.

NG >> Repair or replace harness between rear window defogger and door mirror defogger relay and BCM.




REAR WINDOW DEFOGGER

AIS00107

Rear Window Defogger Circuit Check

1. REAR WINDOW DEFOGGER POWER SUPPLY CIRCUIT INSPECTION 1

1. Disconnect rear window defogger connector.
2. Turn ignition switch ON.
3. Push the rear window defogger switch.
4. Check voltage between rear window defogger connector and ground.



Con- nector	Terminal (Wire color)		Condition	Voltage V (Approx)
	(+)	(-)		
B181	2 (B)	Ground	Turn ignition switch ON. When rear window defogger switch is pressed.	Battery voltage
			Turn ignition switch OFF.	0

OK or NG

- OK >> GO TO 2.
NG >> GO TO 3.


2. REAR WINDOW DEFOGGER GROUND HARNESS INSPECTION

1. Turn ignition switch OFF.
2. Check continuity between rear window defogger connector B421 terminal 1 (B) and ground.

1(B) – ground : Continuity should exist.

OK or NG

- OK >> Rear window defogger circuit check is OK.
NG >> Repair or replace harness between rear window defogger and ground.




3. REAR WINDOW DEFOGGER GROUND HARNESS INSPECTION 2

1. Disconnect condenser connector.
2. Turn ignition switch ON.
3. Push the rear window defogger switch.
4. Check voltage between condenser connector and ground.

Con- nector	Terminal (Wire color)		Condition	Voltage V (Approx)
	(+)	(-)		
B25	1 (L/R)	Ground	When rear window defogger switch is pressed.	Battery voltage
			Turn ignition switch OFF.	0

OK or NG

- OK >> Check the condenser
- If condenser is OK, repair or replace harness between condenser and rear window defogger.
 - If condenser is NG, replace condenser.
- NG >> Repair or replace harness between rear window defogger and door mirror defogger relay and condenser.



REAR WINDOW DEFOGGER

Door Mirror Defogger Power Supply Circuit Check

AIS0010A

1. CHECK FUSE

1. Turn ignition switch OFF.
2. Check if the following fuse for Fuse block (J/B) is blown.

COMPONENT PARTS	TERMINAL NO. (SIGNAL)	AMPERE	FUSE NO.
Fuse block (J/B)	3A (BAT power supply)	10A	#4

NOTE:

Refer to [GW-60, "Component Parts and Harness Connector Location"](#).

OK or NG


OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse, refer to [PG-2, "POWER SUPPLY ROUTING"](#).

2. DOOR MIRROR DEFOGGER POWER SUPPLY CIRCUIT INSPECTION 1

1. Disconnect door mirror defogger relay connector.
2. Turn ignition switch ON.
3. push the rear window defogger switch.
4. Check voltage between door mirror defogger relay connector and ground.

Con- nector	Terminal (Wire color)		Condition	Voltage V (Approx)
	(+)	(-)		
B10	2 (L/R)	Ground	Turn ignition switch ON. When rear window defogger switch is pressed.	Battery voltage
			Turn ignition switch OFF.	0



OK or NG

OK >> GO TO 3.

NG >> Repair or replace between harness rear window defogger and door mirror defogger relay and door mirror defogger relay.

3. DOOR MIRROR DEFOGGER RELAY INSPECTION


1. Turn ignition switch OFF.
2. Remove door mirror defogger relay.
3. Check continuity between terminals 3 and 5.

Terminal	Condition	Continuity
3	12V direct current supply between terminals 1 to 2	Should exist
5	No current supply	Should not exist

OK or NG

OK >> GO TO 4.

NG >> Replace door mirror defogger relay.



REAR WINDOW DEFOGGER

4. DOOR MIRROR DEFOGGER RELAY GROUND HARNESS INSPECTION


Check continuity between door mirror defogger relay connector B10 terminal 1 (B) and ground.

1 (B) – ground : Continuity should exist.

OK or NG

OK >> GO TO 5.

NG >> Repair or replace harness between door mirror defogger relay and ground.



5. DOOR MIRROR DEFOGGER POWER SUPPLY CIRCUIT INSPECTION


Check voltage between door mirror defogger relay connector B10 terminal 5 (P/B) and ground.

5 (P/B) – Ground : Battery voltage

OK or NG

OK >> Check the harness for open or short between door mirror defogger relay and door mirror.

NG >> Repair or replace harness between fuse block (J/B) No.1 and door mirror defogger relay.



Driver Side Door Mirror Defogger Circuit Check

AIS0010B

1. DOOR MIRROR DEFOGGER POWER SUPPLY CIRCUIT INSPECTION


1. Turn ignition switch OFF.
2. Disconnect door mirror defogger connector.
3. Check voltage between driver side door mirror defogger connector and ground.

Con- nector	Terminal (Wire color)		Condition	Voltage V (Approx)
	(+)	(-)		
D2	6(L/R)	Ground	Turn ignition switch ON. When rear window defogger switch is pressed.	Battery voltage
			Turn ignition switch OFF.	0

OK or NG

OK >> GO TO 2.

NG >> Repair or replace harness between door mirror defogger relay and driver side door mirror (Door mirror defogger).



REAR WINDOW DEFOGGER


2. DOOR MIRROR DEFOGGER GROUND HARNESS INSPECTION

1. Turn ignition switch OFF.
2. Check continuity between driver side door mirror defogger connector D2 terminal 5 (B) and ground.

5 (B) – Ground : Continuity should exist.

OK or NG

- OK >> Check the following, if it is OK, replace driver side door mirror glass.
- Door mirror defogger firmament continuity check.
 - Check the harness for open or short between door mirror defogger relay and door mirror.
- NG >> Repair or replace harness between driver side door mirror (Door mirror defogger) and ground.




Passenger Side Door Mirror Defogger Circuit Check

AIS0010C

1. DOOR MIRROR DEFOGGER POWER SUPPLY CIRCUIT INSPECTION

1. Turn ignition switch OFF.
2. Disconnect passenger side door mirror defogger connector.
3. Check voltage between passenger side door mirror defogger connector and body ground.

Con- nector	Terminal (Wire color)		Condition	Voltage V (Approx)
	(+)	(-)		
D32	6 (L/R)	Ground	Turn ignition switch ON. When rear window defogger switch is pressed.	Battery voltage
			Turn ignition switch OFF.	0



OK or NG

- OK >> GO TO 2.
- NG >> Repair or replace harness between door mirror defogger relay and passenger side door mirror (door mirror defogger).


2. DOOR MIRROR DEFOGGER GROUND HARNESS INSPECTION

1. Turn ignition switch OFF.
2. Check continuity between passenger side door mirror defogger connector D32 terminal 5 (B) and body ground.

5 (B) – Ground : Continuity should exist.

OK or NG

- OK >> Check the following, if it is OK, replace passenger side door mirror glass.
- Door mirror defogger firmament continuity check.
 - Check the harness for open or short between door mirror defogger relay and door mirror.
- NG >> Repair or replace harness between passenger side door mirror defogger and ground.




REAR WINDOW DEFOGGER


Filament Check

AIS001H3


1. When measuring voltage, wrap tin foil around the top of the negative probe. Then press the foil against the wire with your finder.



2. Attach probe circuit tester (in Volt range) to middle portion of each filament.



3. If a filament is burned out, circuit tester registers 0 or battery voltage.
4. To locate burned out point, move probe to left and right along filament. Test needle will swing abruptly when probe passes the point.



Filament Repair REPAIR EQUIPMENT




AIS001H4

- Conductive silver composition (Dupont No. 4817 or equivalent)
- Ruler 30 cm (11.8 in) long
- Drawing pen
- Heat gun
- Alcohol
- Cloth

REAR WINDOW DEFOGGER

REPAIRING PROCEDURE

1. Wipe broken heat wire and its surrounding area clean with a cloth dampened alcohol.
2. Apply a small amount of conductive silver composition to tip of drawing pen. Shake silver composition container before use.
3. Place ruler on glass along broken line. Deposit conductive silver composition on break with drawing pen. Slightly overlap existing heat wire on both sides [preferably 5 mm (0.20 in)] of the break.
4. After repair has been completed, check repaired wire for continuity. This check should be conducted 10 minutes after silver composition is deposited. Do not touch repaired area while test is being conducted.
5. Apply a constant stream of hot air directly to the repaired area for approximately 20 minutes with a heat gun. A minimum distance of 3 cm (1.2 in) should be kept between repaired area and hot air outlet. If a heat gun is not available, let the repaired area dry for 24 hours.



A
B
C
D
E
F
G
H
GW
J
K
L
M


REVERSE INTERLOCK DOOR MIRROR SYSTEM

REVERSE INTERLOCK DOOR MIRROR SYSTEM

PFP:28548

Component Parts and Harness Connector Location

AIS0010H



PIIA2882E

System Description

AIS001H5

- When switching the door mirror remote control switch position (LH/RH), the system moves driver or passenger door mirror face downward, in relation to the A/T selector lever being shifted to Reverse Position.
- The mirror position with the reverse gear engaged can be adjusted and the adjusted mirror position can be stored in memory (2 positions).
- With reverse gear-linked operation signal, the driver side door mirror control unit (LCU 03) and passenger side door mirror control unit (LCU 04) installed on the door panel drives and controls the motors (UP/DOWN, LH/RH).
- Using the self-diagnostic function and CONSULT-II, system diagnosis can be performed.

OUTLINE OF OPERATION

Operation Conditions

If all of the following conditions are satisfied, starts operating after approximately 0.5 seconds.

- Ignition switch is in ON position.
- Set the door mirror remote control switch to the right position, or left position.
- A/T selector lever is in R position.

NOTE:

- If the conditions for reverse gear-linked operation are satisfied during manual operation, the manual operation is interrupted and switched to the reverse gear-linked operation.

REVERSE INTERLOCK DOOR MIRROR SYSTEM

Operation Angle

Fixed operation angle

	Facing downward	Facing unwearied
Driver-side	7°	1°
Passenger-side	7°	1°

End of Operation

If the following conditions is satisfied, the reverse gear-linked operation is stopped.

- When the set angle is reached.
- When no operation signal or no operation end signal can be received for approximately 2 seconds or more after BCM actually outputs the reverse gear-linked operation signal.
- After receiving the operation signal from the door mirror control unit, when BCM has stayed in the status for 60 seconds.

Return Operation

If one of the following conditions is satisfied, the mirror face returns upward.

- When the ignition switch is turned OFF.
- When the A/T selector lever is shifted to any position except R position.
- When the door mirror remote control switch is in the neutral position.

NOTE:

- After the above operation, if no operation conditions previously mentioned are satisfied, shifting the A/T selector lever to R position will not move the mirror face downward.

End of Return Operation

- Mirror face returns to the original position.
- When no operation signal or no operation end signal can be received for approximately 2 seconds or more after BCM actually outputs the reverse gear-linked operation signal.
- After receiving the operation signal from the door mirror control unit, when BCM has stayed in the status for 60 seconds.

MIRROR POSITION MEMORY FUNCTIONS

Equipped with a function which allows memorizing the desired mirror face positions (2 positions each for LH/RH door mirror).

Memory Operation Conditions

The seat and steering wheel positions are in accordance with memory 1 or memory 2 in the automatic drive position control. Refer to [SE-13. "AUTOMATIC DRIVE POSITIONER"](#).

Memory Operation Procedure

1. Turn ignition switch ON.
2. Shift the A/T selector lever to R position.
3. Switch the door mirror remote control switch to right or left, and set the mirror face to the desired angle.
4. Press the setting button, and within 5 seconds, press the memory switch which stores the current seat and steering wheel positions for 0.5 seconds or more.
5. If the memory switch with certain positions stored is used, it turns off for 0.5 seconds after the operation, and after that it illuminates continuously (for Pyrex. 5 seconds).
6. If a memory switch with no positions stored is used, it illuminates (for Pyrex. 5 seconds) after the memory switch operation.

POWER SUPPLY

Power is supplied at all times

- through 10A fuse [No.8, located in the fuse block (J/B)]
- to driver side door mirror control unit terminal No.8 and passenger side door mirror remote control unit terminal No.8.
- through 10A fuse [No.3, located in the fuse block (J/B)]
- to BCM terminal No.105.

A
B
C
D
E
F
G
H
J
K
L
M

GW

REVERSE INTERLOCK DOOR MIRROR SYSTEM

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No.9, located in the fuse block (J/B)]
- to back-up lamp relay terminal No. 2 and 5.

With the ignition switch in the ON or START position and selector lever is in R position, power is supplied

- through back-up lamp relay terminal No.3
- to TCM terminal No.141.

MIRROR CONTROL SWITCH TO OPERATION

If the changeover switch with RH positions,

Ground is supplied

- to BCM terminal No.21
- through the door mirror remote control switch terminal No.5,
- through door mirror remote control switch terminal No.7
- through grounds M25 and M115,

BCM recognizes that changeover switch is RH positions.

If the changeover switch with LH positions,

Ground is supplied

- to BCM terminal No.24
- through the door mirror remote control switch terminal No.6,
- through door mirror remote control switch terminal No.7
- through grounds M25 and M115

BCM recognizes that changeover switch is LH positions.

When mirror switch is selected to right,

Ground is supplied

- through BCM terminal No.29
- to the door mirror remote control switch terminal No.1,
- through door mirror remote control switch terminal No.7
- through grounds M25 and M115,

BCM recognizes that mirror switch is selected to right.

When mirror switch is selected to left,

Ground is supplied

- to BCM terminal No.25
- through the door mirror remote control switch terminal No.2,
- through door mirror remote control switch terminal No.7
- through grounds M25 and M115,

BCM recognizes that mirror switch is selected to left.

When mirror switch is selected to up,

Ground is supplied

- to BCM terminal No.32
- through the door mirror remote control switch terminal No.3,
- through door mirror remote control switch terminal No.7
- through grounds M25 and M115,

BCM recognizes that mirror switch is selected to up.

When mirror switch is selected to down,

Ground is supplied

- to BCM terminal No.34
- through the door mirror remote control switch terminal No.4,
- through door mirror remote control switch terminal No.7
- through grounds M25 and M115,

BCM recognizes that mirror switch is selected to down.

BCM is connected to driver side door mirror control unit (LCU03) and passenger side door mirror control unit (LCU04) as DATA LINE A-2 and DATA LINE A-3.

REVERSE INTERLOCK DOOR MIRROR SYSTEM

Then signal inputs to driver side door mirror control unit and passenger side door mirror control unit terminal No.7 from BCM terminal No.61 and No.67 by DATA LINE A-2 and DATA LINE A-3.
If the changeover switch with LH positions, signal is transmitted to LCU03.
If the changeover switch with RH positions, signal is transmitted to LCU04.

MEMORY MIRROR OPERATION

BCM transmits the memory switch (1 or 2) ON signal to the door mirror control unit.
BCM is connected to driver side door mirror control unit (LCU03) and passenger side door mirror control unit (LCU04) as DATA LINE A-2 and DATA LINE A-3.
Then signal input to driver side door mirror control unit and passenger side door mirror control unit terminal No.7 from BCM terminal No.61 and No.67 by DATA LINE A-2 and DATA LINE A-3.
When door mirror control unit receives the signal of memory switch from BCM, control unit operations the door mirror according to memory data.

Power is supplied

- through door mirror control unit terminal No. 1
- to the door mirror terminal No. 16, and then

signal is transmitted (upper and down)

- through door mirror terminal No. 14
- to door mirror control unit terminal No. 5,

LCU recognizes an upper and down position according to the voltage.
and also signal is transmitted (left and right)

- through door mirror terminal No. 12
 - to door mirror control unit terminal No. 6,
- an left and right position is recognized according to the voltage.

DOOR MIRROR MOTOR TO OPERATION

When mirror motor up signal is transmitted from BCM to door mirror control unit,
Power is supplied

- through door mirror control unit terminal No.3
- to door mirror terminal No.8.

Then ground is supplied,

- to door mirror terminal No.11
- through door mirror control unit terminal No.9
- through door mirror control unit terminal No.10
- through body ground M24 and M114.

with power and ground supplied, mirror motor is operated up side.

When mirror motor down signal is transmitted from BCM to door mirror control unit,
Power is supplied

- through door mirror control unit terminal No.9
- to door mirror terminal No.11.

Then ground is supplied

- to door mirror terminal No.8
- through door mirror control unit terminal No.3
- through door mirror control unit terminal No.10
- through body ground M24 and M114.

with power and ground supplied, mirror motor is operated down side.

When mirror motor left signal is transmitted from BCM to door mirror control unit,
Power is supplied

- through door mirror control unit terminal No.4
- to the door mirror terminal No.9.

Then ground is supplied

- to door mirror terminal No.11
- through door mirror control unit terminal No.9

A

B

C

D

E

F

G

H

GW

J

K

L

M

REVERSE INTERLOCK DOOR MIRROR SYSTEM

- through door mirror control unit terminal No.10
- through body ground M24 and M114.

with power and ground supplied, mirror motor is operated left side.

When mirror motor right signal is transmitted from BCM to door mirror control unit,
Power is supplied


- through door mirror control unit terminal No.9
- to the door mirror terminal No.11

Then ground is supplied

- to door mirror terminal No.9
- through door mirror control unit terminal No.4
- through door mirror control unit terminal No.10
- through body ground M24 and M114.

with power and ground supplied, mirror motor is operated right side.


SYSTEM DIAGRAM



REVERSE INTERLOCK DOOR MIRROR SYSTEM

Schematic

AIS001H7



A
B
C
D
E
F
G
H
I
J
K
L
M

GW





TIWA0222E

REVERSE INTERLOCK DOOR MIRROR SYSTEM

AIS001HB

Wiring Diagram — MIRROR —

GW-MIRROR-01



REFER TO THE FOLLOWING.

(D1), (D31) -SUPER MULTIPLE JUNCTION (SMJ)




(M1) -FUSE BLOCK-JUNCTION BOX (J/B) NO.1

TIWA0223E

REVERSE INTERLOCK DOOR MIRROR SYSTEM

GW-MIRROR-02

▬ : DATA LINE




REFER TO THE FOLLOWING.

(D31) -SUPER MULTIPLE JUNCTION (SMJ)

REVERSE INTERLOCK DOOR MIRROR SYSTEM

GW-MIRROR-03



11	6	8	9	12		
10	5	4	2	7	3	1

(M19)
W

1	1	1	1	1	2	2	2	2
3	3	3	3	3	3	3	3	3

(M38)
P



REFER TO THE FOLLOWING.

(M4) -ELECTRICAL UNITS

TIWA0225E

REVERSE INTERLOCK DOOR MIRROR SYSTEM

GW-MIRROR-04



REVERSE INTERLOCK DOOR MIRROR SYSTEM

Terminals and Reference Values for Driver Side Door Mirror Control Unit & Terminals and Reference Value for Passenger Side Door Mirror Control Unit

AIS001H9

TERMINAL		WIRE COLOR		ITEM	CONDITION	VOLTAGE (V) (Approx.)
+	-	+	-			
1	*	W/L	—	Mirror sensor power supply	—	5
2		Y	—	Ground (Mirror sensor)	—	0
3	9	GY/R (R)	PU/W (OR)	Mirror motor UP signal	When motor is activated (UP)	Battery voltage
					When motor is not activated	0
4	9	BR	PU/W (OR)	Mirror motor LH signal	When motor is activated (LH)	Battery voltage
					When motor is not activated	0
5	*	LY	—	Mirror sensor UP / DOWN signal	When motor is activated (UP or DOWN)	Changes between 4 (UP) – 0.5 (DOWN)
6	*	G	—	Mirror sensor LEFT / RIGHT signal	When motor is activated (LEFT or RIGHT)	Changes between 4 (RIGHT) – 0.5 (LEFT).
7		G/W (R/B)	—	Data line A-3	—	—
8		L	—	BAT power supply	—	Battery voltage
9	3	PU/W (OR)	GY/R (R)	Mirror motor DOWN signal	When motor is activated (DOWN)	Battery voltage
					When motor is not activated	0
9	4	PU/W (OR)	BR	Mirror motor RH signal	When motor is activated (RH)	Battery voltage
					When motor is not activated	0
10	*	B	—	Ground	—	0

*: Body ground

(): Passenger side

Terminals and Reference Values for BCM

AIS001HA

TERMINAL	WIRE COLOR	ITEM	CONDITION	Voltage (V) (Approx.)
21	SB	Door mirror change over switch RIGHT signal	Set the door mirror control switch to right position.	0
			Other than above	5
24	BR/Y	Door mirror change over switch LEFT signal	Set the door mirror remote control switch to left position.	0
			Other than above	5
25	G/R	Door mirror remote control switch signal–LH operation	Set the either LH/RH door mirror face to left.	0
			Other than above	5
29	LG/R	Door mirror remote control switch signal–RH operation	Set the either LH/RH door mirror face to right.	0
			Other than above	5
32	L/W	Door mirror remote control switch signal–Upward	Set the either LH/RH door mirror face upward.	0
			Other than above	5
34	P/L	Door mirror remote control switch signal–Downward	Set the either LH/RH door mirror face downward.	0
			Other than above	5
39	G	Memory switch1 signal	Memory switch1 (ON)	0
			Memory switch1 (OFF)	5
43	OR/L	Memory switch2 signal	Memory switch2 (ON)	0
			Memory switch2 (OFF)	5
50	P/B	Set switch signal	Set switch (ON)	0
			Set switch (OFF)	5

REVERSE INTERLOCK DOOR MIRROR SYSTEM

TERMINAL	WIRE COLOR	ITEM	CONDITION	Voltage (V) (Approx.)
56	B	Ground	—	0
61	R/B	Data line A-2	—	—
67	G/W	Data line A-3	—	—
105	Y/L	BAT power supply	—	Battery voltage
113	B	Ground	—	0
141	R/B	R position signal	When the selector lever is in R position	Battery voltage
			When the selector lever is not in R position	0

Work Flow

AIS001HB

1. Check the symptom and customer's requests.
2. Understand the system description. Refer to [GW-78, "System Description"](#).
3. Carry out the preliminary check. Refer to [GW-90, "Preliminary Check"](#).
4. Carry out the communication diagnosis.
If CONSULT-II is used, refer to [GW-93, "IVMS Communication Diagnosis"](#).
If CONSULT-II is not used, refer to [GW-100, "COMMUNICATION DIAGNOSIS"](#).
Is the communication diagnosis result OK?
If OK, GO TO 7.
If NG, GO TO 5.
5. Repair or replace depending on the diagnosis result.
6. Carry out the communication diagnosis again.
If CONSULT-II is used, refer to [GW-93, "IVMS Communication Diagnosis"](#).
If CONSULT-II is not used, refer to [GW-100, "COMMUNICATION DIAGNOSIS"](#).
Is communication diagnosis result OK?
If OK, GO TO 7.
If NG, GO TO 5.
7. Perform self-diagnosis. If CONSULT-II is used, refer to [GW-97, "SELF-DIAGNOSIS RESULTS"](#).
If CONSULT-II is not used, refer to [GW-105, "ON BOARD DIAGNOSIS FOR AUTOMATIC DRIVE POSITIONER"](#).
Is self-diagnosis result OK?
If OK, GO TO 11.
If NG, GO TO 8.
8. Repair or replace depending on the diagnosis result.
9. Carry out the self-diagnosis again. If CONSULT-II is used, refer to [GW-97, "SELF-DIAGNOSIS RESULTS"](#).
If CONSULT-II is not used, refer to [GW-105, "ON BOARD DIAGNOSIS FOR AUTOMATIC DRIVE POSITIONER"](#).
Is self-diagnosis result OK?
If OK, GO TO 11.
If NG, GO TO 8.
10. Refer to Trouble diagnosis chart, repair or replace the cause of the malfunction. Refer to [GW-107, "Symptom Chart"](#).
11. Does the Reverse Interlock Door Mirror System operate normally?
If it operates normally, GO TO 12.
If not, GO TO 10.
12. Inspection END.

REVERSE INTERLOCK DOOR MIRROR SYSTEM

AIS001HC

Preliminary Check POWER SUPPLY AND GROUND CIRCUIT CHECK

1. CHECK FUSE

Check that any of the following fuses in BCM and door mirror control unit are blown.

Unit	Terminal No.	Power source	Fuse No.
BCM	105	BAT power supply	#3
Door Mirror Control Unit (Driver side & Passenger side)	8	BAT power supply	#8

NOTE:

Refer to [GW-78, "Component Parts and Harness Connector Location"](#).

OK or NG?

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse. Refer to [GW-78, "Component Parts and Harness Connector Location"](#).

2. POWER SUPPLY CIRCUIT INSPECTION (BCM)


1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check voltage between BCM connector M4 terminal 105 and ground.

105 (Y/L) – Ground : Battery voltage

OK or NG?

OK >> GO TO 3.

NG >> Repair or replace the harnesses for BCM power supply circuit.



3. GROUND CIRCUIT INSPECTION(BCM)

1. Turn ignition switch OFF.
2. Check continuity between BCM connector M4 terminal 56, 113 and ground.


56 (B) – Ground : Continuity should exist.

113 (B) – Ground : Continuity should exist.

OK or NG?

OK >> GO TO 4.

NG >> Repair or replace harness.



REVERSE INTERLOCK DOOR MIRROR SYSTEM


4. CHECK POWER SUPPLY CIRCUIT (DOOR MIRROR CONTROL UNIT)

1. Turn ignition switch OFF.
2. Disconnect door mirror control unit connector.
3. Check voltage between door mirror control unit connector D5 (driver side), D35 (passenger side) terminal 8 and ground.

8 (L) – Ground : Battery voltage

OK or NG?

- OK >> GO TO 5.
NG >> Repair or replace harness.




5. CHECK GROUND CIRCUIT (DOOR MIRROR CONTROL UNIT)

Check continuity between door mirror control unit connector D5 (driver side), D35 (passenger side) terminal 10 and ground.

10 (B) – Ground : Continuity should exist.

OK or NG?

- OK >> Preliminary check is OK.
NG >> Repair or replace harness.



REVERSE INTERLOCK DOOR MIRROR SYSTEM

AIS001HD

CONSULT-II Function


CONSULT-II executes the following functions by combining data received and command transmitted via the communication line from BCM. IVMS communication inspection, work support (only function setting of seats and steering wheel), self-diagnosis, data monitor, and active test display.

IVMS diagnosis position	Inspection item and diagnosis mode	Description
IVMS-COMM CHECK	IVMS-COMM DIAGNOSIS	Diagnose a communication malfunction, inactive communication, and sleep malfunction in the communication line between BCM and each LCU.
	WAKE-UP DIAGNOSIS	Diagnose the wake-up signals output from each LCU.
AUTO DRIVE POSITIONER	WORK SUPPORT*	Changes the setting for each function. Refer to SE-36. "SETTING CHANGE FUNCTION" .
	SELF-DIAG RESULTS	Carries out the self-diagnosis.
	DATA MONITOR	Displays the input data of BCM and each LCU on real-time basis.
	ACTIVE TEST	Sends a drive signal to a load to check the operation.
BCM PART NUMBER		Displays BCM part No.


*: Only for function setting of seat and steering wheel

CONSULT-II BASIC OPERATION PROCEDURE


1. Turn ignition switch OFF.
2. Connect "CONSULT-II" and "CONSULT-II CONVERTER" to the data link connector.



3. Turn ignition switch ON.
4. Touch "START (NISSAN BASED VHCL)".




5. Touch "IVMS" on the "SELECT SYSTEM" screen. If "IVMS" is not indicated, go to [GI-39. "INSPECTION PROCEDURE"](#).



REVERSE INTERLOCK DOOR MIRROR SYSTEM

6. Check the model specification, touch either "WITH SUNROOF" or "WITHOUT SUNROOF" on the "SELECT SYS COND" screen.
7. Touch "OK". If the selection is wrong, touch "CANCEL".
8. Select the desired part to be diagnosed on the "SELECT TEST ITEM" screen.



A
B
C
D
E
F
G
H
J
K
L
M

IVMS COMMUNICATION INSPECTION

IVMS contains the IVMS communication diagnosis and wake-up diagnosis.

IVMS Communication Diagnosis

The IVMS communication diagnosis consists of the communication diagnosis, sleep diagnosis, and inactive communication diagnosis between BCM and each local unit (LCU), and display the results on the CONSULT-II screen.

NOTE:

Sleep is a power saving function when a vehicle is stationary (all BCM related electrical equipment: OFF, and the timer: OFF).

The function also stores the communication malfunction records and inactive communication records, and displays the data on the CONSULT-II screen (Malfunction record diagnosis)

Malfunction description	CONSULT-II display item	Description
Communication malfunction	COMM DATA	<ul style="list-style-type: none"> Communicating with each LCU is judged sound when the communication is normally completed and the transmitted data and received data are identically the same. In other cases, it is judged malfunctioning. If the communication is inactive, no diagnosis result is displayed.
Inactive communication	NO RESPONSE	<ul style="list-style-type: none"> Communicating with each LCU is judged sound when at least one time communication is normally completed within three trials. In other cases, it is judged malfunctioning.
Sleep malfunction	SLEEP	<ul style="list-style-type: none"> Check that each LCU enters sleep mode.
Communication malfunction *	PAST COMM DATA	<ul style="list-style-type: none"> The records when communication signal malfunctions were continuously detected while the communication was normal are displayed. Or the records when a malfunction is detected during the past sleep mode are displayed.
Inactive communication*	PAST NO RESPONSE	<ul style="list-style-type: none"> The records when inactive communications were continuously detected while the communication was normal are displayed.

*: malfunctioning item record

Operation Procedure

1. Touch "IVMS-COMM CHECK" on "SELECT TEST ITEM".
2. Touch "IVMS-COMM DIAGNOSIS" on "SELECT DIAG ITEM" screen.
3. Touch "START" on "IVMS-COMM DIAGNOSIS" screen to start the diagnosis.
4. After the diagnosis is completed, the malfunctioning system is displayed.
5. When the malfunctioning items are displayed, touch "PRINT" to record.
6. Touch "ERASE".
7. Carry out the communication inspection again to check that any malfunctioning item is displayed.
8. Check the displayed items.

Wake - Up Diagnosis

The wake-up diagnosis is carried out when BCM detects the wake-up signal from each local unit (LCU). When the switch shown on the screen is operated as instructed, each local control unit (LCU) outputs the wake-up signal. If BCM cannot detect a wake-up signal, it is judged malfunctioning. The malfunctioning local control unit (LCU) is displayed on the screen.

GW

REVERSE INTERLOCK DOOR MIRROR SYSTEM

Operation Procedure

1. Touch "IVMS-COMM CHECK" on "SELECT TEST ITEM" screen.
2. Touch "WAKE-UP DIAGNOSIS" on "SELECT DIAG ITEM" screen.
3. Touch "START" on "WAKE-UP DIAGNOSIS" screen to start the diagnosis.
4. Touch "NEXT" to select the local control unit (LCU) to be diagnosed.
5. Check that any malfunction is displayed. If necessary, touch "PRINT" to record.
6. Carry out the inspection to the malfunctioning item.

Trouble Diagnosis Chart

Malfunctioning item	Display unit	CONSULT-II IVMS communication diagnosis content	Self-diagnosis trouble code No.	Malfunctioning system and reference
COMM DATA	One LCU is displayed.	POWER WINDOW C/U-DR "COMM DATA"	24	Replace the displayed LCU.
		DOOR MIRROR C/U-RH "COMM DATA"	27	
		DOOR MIRROR C/U-LH "COMM DATA"	37	
		POWER SEAT C/U-DR "COMM DATA"	47	
	Multiple LCUs are displayed	BCM "COMM FAIL1" ,"COMM FAIL2"	Displays in order of 24→27→37→47→ and cycles from 24.	Communication system A: Refer to GW-95 .
NO RESPONSE	One LCU is displayed.	POWER WINDOW C/U-DR "NO RESPONSE"	25	Communication system B: Refer to GW-95 .
		DOOR MIRROR C/U-RH "NO RESPONSE"	28	
		DOOR MIRROR C/U-LH "NO RESPONSE"	38	
		POWER SEAT C/U-DR "NO RESPONSE"	48	
	Multiple LCUs are displayed	BCM/HARNESS	Displays in order of 25→28→38→48→ and cycles from 25.	Communication system C: Refer to GW-95 .
SLEEP malfunction	One LCU is displayed.	POWER WINDOW C/U-DR "SLEEP"	No self-diagnosis function	Replace the displayed LCU.
		DOOR MIRROR C/U-RH "SLEEP"		
		DOOR MIRROR C/U-LH "SLEEP"		
		POWER SEAT C/U-DR "SLEEP"		
	Multiple LCUs are displayed	All the above control units are displayed.	No self-diagnosis function	Communication system A: Refer to GW-95 .

NOTE:

- For a specific local control unit (LCU), either "PAST COMM DATA" or "PAST NO RESPONSE" may be displayed instead of the above results. The data record, causes this, so erase the records.
(The display only shows the incident records, they are not malfunctions caused during the diagnosis. One possible cause is that an intermittent incident occurred.)
- Follow the steps below to erase the memory.
Carry out either disconnect BCM battery power supply or erase memory with CONSULT-II.
- With the battery connected, if the local control unit (LCU) connector is disconnected and left for approximately 1 minute, the BCM stores "NO RESPONSE" record.

REVERSE INTERLOCK DOOR MIRROR SYSTEM

COMMUNICATION SYSTEM A

1. BCM INSPECTION

Replace BCM with a known-good one, and carry out the communication diagnosis. Refer to [GW-93, "IVMS Communication Diagnosis"](#) .

OK or NG?

- OK >> Replace BCM
- NG >> GO TO 2.

2. LCU INSPECTION

1. Replace with the previously installed BCM.
2. Replace LCU with a known-good one, and carry out the communication diagnosis. Refer to [GW-93, "IVMS Communication Diagnosis"](#) .

OK or NG?

- OK >> Replace LCU
- NG >> Perform the following.
 - Repair or replace communication harness between LCU and BCM.
 - Replace with the previously installed LCU.

COMMUNICATION SYSTEM B

1. HARNESS CONNECTOR INSPECTION

Check the terminals (at the control unit and harness) on the malfunctioning LCU for disconnection, bend, loose connection, and other malfunctions.

OK or NG?

- OK >> GO TO 2.
- NG >> Repair the terminals and connectors.

2. LCU INSPECTION

Replace the malfunctioning LCU with a known-good one, and carry out the communication diagnosis. Refer to [GW-93, "IVMS Communication Diagnosis"](#) .

OK or NG?

- OK >> Replace LCU
- NG >> Perform the following.
 - Repair or replace communication harness between LCU and BCM.
 - Replace with the previously installed LCU.

COMMUNICATION SYSTEM C

1. HARNESS CONNECTOR INSPECTION

Check the terminals (at the control unit and harness) on BCM and LCU for disconnection, bend, loose connection, and other malfunctions.

OK or NG?

- OK >> GO TO 2.
- NG >> Repair the terminals and connectors.

A
B
C
D
E
F
G
H
J
K
L
M

GW

REVERSE INTERLOCK DOOR MIRROR SYSTEM

2. BCM INSPECTION

Replace the malfunctioning BCM with a known-good one, and carry out the communication diagnosis. Refer to [GW-93, "IVMS Communication Diagnosis"](#) .

OK or NG?

OK >> Replace the BCM

NG >> Perform the following.

- Repair the communication harness between LCU and BCM control.
- Replace with the previously installed BCM.

REVERSE INTERLOCK DOOR MIRROR SYSTEM

SELF-DIAGNOSIS RESULTS

Operation Procedure

1. Touch "AUTO DRIVE POSITIONER" on "SELECT TEST ITEM" screen.
2. Touch "SELF-DIAG RESULTS" on "SELECT DIAG MODE" screen.
3. Touch "START" on "SELF-DIAG RESULTS" screen.
4. The seat and steering wheel automatically move, and the self-diagnosis for the seat, steering wheel and door mirror start (door mirror does not operate).
5. Within 15 seconds after the self-diagnosis for the seat, steering wheel and door mirror are completed, drive the vehicle at a speed of 7 km/h (4 MPH) or higher for the vehicle speed sensor self-diagnosis.
6. After the diagnosis is completed, the malfunctioning system is displayed.
7. When the malfunctioning items are displayed, touch "COPY" to record.
8. Touch "ERASE".
9. Perform self-diagnosis results again to check that any malfunctioning item is displayed.
10. Check the displayed items.

Display Item List

Malfunctioning system	Malfunction detecting condition
SEAT SLIDE	While the sliding motor moves the seat backward for 2.5 seconds, and then forward for 2.5 seconds, when the sliding sensor pulse change less than 2 times.
SEAT RECLINING	While the reclining motor moves the seat forward for 2.5 seconds, and then backward for 2.5 seconds, when the reclining sensor pulse change less than 2 times.
SEAT LIFTER-FR	While the lifter motor (front end) moves the seat downward for 2.5 seconds, and then upward for 2.5 seconds, when the lifter sensor (front end) pulse change less than 2 times.
SEAT LIFTER-RR	While the lifter motor (rear end) moves the seat downward for 2.5 seconds, and then upward for 2.5 seconds, when the lifter sensor (rear end) pulse change less than 2 times.
STEERING TILT	While the tilt motor moves the steering wheel upward for 1 second, and then downward for 1 second, when the tilt sensor output voltage is 0.2V or less.
STEERING TELESCO	While the telescoping motor moves the steering wheel forward for 1 second, and then backward for 1 second, when the telescoping sensor output voltage is 0.2V or less.
DOOR MIRROR-LH-UP-DOWN	When LH door mirror sensor detects 0.2V or lower, or 4.5V or higher, for 0.5 seconds or more.
DOOR MIRROR-LH-L-R	
DOOR MIRROR-RH-UP-DOWN	When RH door mirror sensor detects 0.2V or lower, or 4.5V or higher, for 0.5 seconds or more.
DOOR MIRROR-RH-L-R	
VEHICLE SPEED SENSOR	While the vehicle speed is less than 7 km/h (4 MPH) for 15 seconds after the diagnosis for the seat and steering wheel is completed.

DATA MONITOR

Display Item List

Monitor item [OPERATION or UNIT]	Contents
SLIDE SW-FR	"ON/OFF" ON / OFF status judged from the sliding switch (FR) signal is displayed.
SLIDE SW-RR	"ON/OFF" ON / OFF status judged from the sliding switch (RR) signal is displayed.
RECLN SW-FR	"ON/OFF" ON / OFF status judged from the reclining switch (FR) signal is displayed.
RECLIN SW-RR	"ON/OFF" ON / OFF status judged from the reclining switch (RR) signal is displayed.
LIFT FR SW-UP	"ON/OFF" ON / OFF status judged from the FR lifter switch (UP) signal is displayed.
LIFT FR SW-DN	"ON/OFF" ON / OFF status judged from the FR lifter switch (DOWN) signal is displayed.
LIFT RR SW-UP	"ON/OFF" ON / OFF status judged from the RR lifter switch (UP) signal is displayed.
LIFT RR SW-DN	"ON/OFF" ON / OFF status judged from the RR lifter switch (DOWN) signal is displayed.
MIR CON SW-UP	"ON/OFF" ON / OFF status judged from the door mirror remote control switch (UP) signal is displayed.
MIR CON SW-DN	"ON/OFF" ON / OFF status judged from the door mirror remote control switch (DOWN) signal is displayed.

REVERSE INTERLOCK DOOR MIRROR SYSTEM

Monitor item [OPERATION or UNIT]		Contents
MIR CON SW–RH	"ON/OFF"	ON / OFF status judged from the door mirror remote control switch (RIGHT) signal is displayed.
MIR CON SW–LH	"ON/OFF"	ON / OFF status judged from the door mirror remote control switch (LEFT) signal is displayed.
MIR CHNG SW–R	"ON/OFF"	ON / OFF status judged from the door mirror remote control switch (switching to RIGHT) signal is displayed.
MIR CHNG SW–L	"ON/OFF"	ON / OFF status judged from the door mirror remote control switch (switching to LEFT) signal is displayed.
SET SW	"ON/OFF"	ON / OFF status judged from the setting switch signal is displayed.
TELESCO SW–FR	"ON/OFF"	ON / OFF status judged from the telescoping switch (FR) signal is displayed.
TELESCO SW–RR	"ON/OFF"	ON / OFF status judged from the telescoping switch (RR) signal is displayed.
TILT SW–UP	"ON/OFF"	ON / OFF status judged from the tilt switch (UP) signal is displayed.
TILT SW–DOWN	"ON/OFF"	ON / OFF status judged from the tilt switch (DOWN) signal is displayed.
MEMORY SW1	"ON/OFF"	ON / OFF status judged from the seat memory switch 1 signal is displayed.
MEMORY SW2	"ON/OFF"	ON / OFF status judged from the seat memory switch 2 signal is displayed.
CANCEL SW	"ON/OFF"	Setting status is displayed with the display unit: "Active (ON) / inactive (OFF)"
DOOR SW DR	"ON/OFF"	Door open (ON) / door closed (OFF) status judged from the driver door switch is displayed.
VHCL SPEED SE	"<7km/>7km"	The present vehicle speed (less than 7 km/h (4 MPH), or 7 km/h (4MPH) or higher) is displayed.
DETENT SW	"ON/OFF"	The selector lever position "P position (ON) / other than P position (OFF)" judged from the detent switch signal is displayed.
IGN ON SW	"ON/OFF"	ON / START, ACC, or OFF status judged from the ignition switch signal is displayed.
IGN ACC SW	"ON/OFF"	ACC or ON / START, or OFF status judged from the ignition switch signal is displayed.
IGN START SW	"ON/OFF"	START, ON / ACC, or OFF status judged from the ignition switch signal is displayed.
IGN KEY SW	"ON/OFF"	Key inserted (ON) / key removed (OFF) status judged from the key detection switch is displayed.
R POSITION SW	"ON/OFF"	R position (ON) / Other than R position OFF of shift position signal from back-up lamp relay is displayed.
TILT SEN	"V"	The tilt position (voltage) judged from the tilt sensor signal is displayed.
TELESCO SEN	"V"	The telescoping position (voltage) judged from the telescoping sensor signal is displayed.
MIR/SE RH R–L	"ON/OFF"	ON (normal value)/OFF (abnormal value) *of voltage value judged from RH door mirror sensor output voltage (LH/RH) is displayed.
MIR/SE RH U–D	"ON/OFF"	ON (normal value) / OFF (abnormal value) *of voltage value judged from RH door mirror sensor output voltage (UP / DOWN) is displayed.
MIR/SE LH R–L	"ON/OFF"	ON (normal value) / OFF (abnormal value) *of voltage value judged from LH door mirror sensor output voltage (LH / RH) is displayed.
MIR/SE LH U–D	"ON/OFF"	ON (normal value) / OFF (abnormal value) *of voltage value judged from LH door mirror sensor output voltage (UP / DOWN) is displayed.
Voltage	"V"	Displays measured values by voltage probe.
Frequency	"ms,Hz,%"	Displays value measured with pulse probe.

*: Abnormal value indicates that the sensor output voltage is 0.2V or lower, or 4.5V or higher.

REVERSE INTERLOCK DOOR MIRROR SYSTEM

ACTIVE TEST

Display Item List

Test item	Description
TILT MOTOR	The tilt motor is activated by receiving the drive signal.
TELESCO MOTOR	The telescoping motor is activated by receiving the drive signal.
SEAT SLIDE	The sliding motor is activated by receiving the drive signal.
SEAT RECLINING	The reclining motor is activated by receiving the drive signal.
SEAT LIFTER FR	The front end lifter motor is activated by receiving the drive signal.
SEAT LIFTER RR	The rear end lifter motor is activated by receiving the drive signal.
MEMORY SW INDCTR	The memory switch indicator is lit by receiving the drive signal.
MIRROR MOTOR RH	The passenger side door mirror motor moves the mirror UP/DOWN and LEFT/RIGHT by receiving the drive signal.
MIRROR MOTOR LH	The driver side door mirror motor moves the mirror UP/DOWN and LEFT/RIGHT by receiving the drive signal.

On Board Diagnosis

AIS001HE

BCM can check each local unit (LCU), switches, loads, and malfunctions in communication with the self-diagnosis.

DIAGNOSIS ITEM




Diagnosis item	Description
Communication diagnosis	<ul style="list-style-type: none">● It can check the communication line between BCM and each LCU, and also each LCU, for a communication error and malfunction.
Switch monitor	<ul style="list-style-type: none">● It can check the switch systems which send data to BCM and each LCU for a malfunction.
Self-diagnosis for auto drive positioner	<ul style="list-style-type: none">● Diagnoses malfunctions in each motor and sensor in the electrical load parts of the driver power seat system (sliding, reclining, and lifter [front/rear]), of the steering wheel system (tilt, telescoping), and of door mirror.

REVERSE INTERLOCK DOOR MIRROR SYSTEM

COMMUNICATION DIAGNOSIS

Check the communication between BCM and each local control unit(LCU).

Operation Procedure




SIIA0409E

Diagnosis Result Display

- The indicator lamps (the map lamp and step lamp) turn ON (illuminate) for 2 seconds and OFF (go off) for 2 seconds to indicate that the diagnosis has started, then indicate the diagnosis trouble code.
- To indicate the self-diagnosis trouble code, the indicator lamps illuminate or flash.
- At first, the lamps indicate the second place by ON / OFF with 0.5 second-interval, then OFF for 1.5 seconds. Next, they indicate the first place by ON / OFF with 0.5 second interval.
- If there are multiple malfunctioning parts, the lamps indicate them in sequence from the smallest diagnosis trouble code.
- The diagnosis results repeat until the diagnosis is cancelled.
- If a malfunction is indicated, carry out the communication diagnosis again to check that the same diagnosis trouble code is indicated.

Diagnosis Trouble Code Indication Example



SIIA0410E

REVERSE INTERLOCK DOOR MIRROR SYSTEM

Trouble Diagnosis Chart

Malfunctioning item	Display unit	CONSULT-II IVMS communication diagnosis content	Self-diagnosis trouble code No.	Malfunctioning system and reference
COMM DATA	One LCU is displayed.	POWER WINDOW C/U-DR "COMM DATA"	24	Replace the displayed LCU.
		DOOR MIRROR C/U-RH "COMM DATA"	27	
		DOOR MIRROR C/U-LH "COMM DATA"	37	
		POWER SEAT C/U-DR "COMM DATA"	47	
	Multiple LCUs are displayed	BCM "COMM FAIL1" ,"COMM FAIL2"	Displays in order of 24→27→37→47→ and cycles from 24.	Communication system A: Refer to GW-102 .
NO RESPONSE	One LCU is displayed.	POWER WINDOW C/U-DR "NO RESPONSE"	25	Communication system B: Refer to GW-102 .
		DOOR MIRROR C/U-RH "NO RESPONSE"	28	
		DOOR MIRROR C/U-LH "NO RESPONSE"	38	
		POWER SEAT C/U-DR "NO RESPONSE"	48	
	Multiple LCUs are displayed	BCM/HARNESS	Displays in order of 25→28→38→48→ and cycles from 25.	Communication system C: Refer to GW-102 .
SLEEP malfunction	One LCU is displayed.	POWER WINDOW C/U-DR "SLEEP"	No self-diagnosis function	Replace the displayed LCU.
		DOOR MIRROR C/U-RH "SLEEP"		
		DOOR MIRROR C/U-LH "SLEEP"		
		POWER SEAT C/U-DR "SLEEP"		
	Multiple LCUs are displayed	All the above control units are displayed.	No self-diagnosis function	Communication system A: Refer to GW-102 .

NOTE:

- For a specific local control unit(LCU), either "PAST COMM DATA" or "PAST NO RESPONSE" may be displayed instead of the above results. This is caused by the data record, so erase the records.
(The display only shows the incident records, they are not malfunctions caused during the diagnosis. One possible cause is that an irreproducible incident occurred.)
- Follow the steps below to erase the memory.
Carry out either disconnect BCM battery power supply or erase memory with CONSULT-II.
- With the battery connected, if the local control unit(LCU) connector is disconnected and left for approximately 1 minute, the BCM stores "NO RESPONSE" record.

Cancel of Communication Diagnosis

If one of the following conditions is satisfied, the communication diagnosis is cancelled.

- When the ignition switch is turned OFF.
- The vehicle speed becomes 7 km/h (4 MPH) or higher.
- Ten minutes have passed since the diagnosis result indication start without no diagnosis cancel operation.

REVERSE INTERLOCK DOOR MIRROR SYSTEM

COMMUNICATION SYSTEM A

1. BCM INSPECTION

Replace BCM with a known-good one, and carry out the communication diagnosis. Refer to [GW-100, "COMMUNICATION DIAGNOSIS"](#) .

OK or NG?

- OK >> Replace BCM.
- NG >> GO TO 2.

2. LCU INSPECTION

1. Replace with the previously installed BCM.
2. Replace LCU with a known-good one, and carry out the communication diagnosis. Refer to [SE-46, "COMMUNICATION DIAGNOSIS"](#) .

OK or NG?

- OK >> Replace LCU.
- NG >> Perform the following.
 - Repair or replace communication harness between LCU and BCM.
 - Replace with the previously installed LCU.

COMMUNICATION SYSTEM B

1. HARNESS CONNECTOR INSPECTION

Check the terminals (at the control unit and harness) on the malfunctioning LCU for disconnection, bend, poor connection and other malfunctions.

OK or NG?

- OK >> GO TO 2.
- NG >> Repair the terminals and connectors.

2. LCU INSPECTION

Replace the malfunctioning LCU with a known-good one, and carry out the communication diagnosis. Refer to [GW-100, "COMMUNICATION DIAGNOSIS"](#) .

OK or NG?

- OK >> Replace LCU.
- NG >> Perform the following.
 - Repair or replace communication harness between LCU and BCM.
 - Replace with the previously installed LCU.

COMMUNICATION SYSTEM C

1. HARNESS CONNECTOR INSPECTION

Check the terminals (at the control unit and harness) on BCM and LCU for disconnection, bend, poor connection, and other malfunctions.

OK or NG?

- OK >> GO TO 2.
- NG >> Repair the terminals and connectors.

REVERSE INTERLOCK DOOR MIRROR SYSTEM

2. BCM INSPECTION

Replace the malfunctioning BCM with a known-good one, and carry out the communication diagnosis. Refer to [GW-100, "COMMUNICATION DIAGNOSIS"](#) .

OK or NG?

OK >> Replace BCM.

NG >> Perform the following.

- Repair the communication harness between LCU and BCM control.
- Replace with the previously installed BCM.

A

B

C

D

E

F

G

H

GW

J

K

L




M

REVERSE INTERLOCK DOOR MIRROR SYSTEM

SWITCH MONITOR

Carry out the diagnosis for the switch system input to each control unit.


Operation Procedure



S1IA0411E

Diagnosis Result Display

- Detects the status change (switch ON/OFF operation) of the switch to be checked, and turns on/off the indicator lamps (the map lamp and step lamp). Also sounds the buzzer (the key remainder and light remainder) for 0.5 seconds.
- If a malfunction is detected, no indicator lamp and buzzer react.



Diagnosis Item

- The status of the switch (except the ignition switch, interior lamp switch, and map lamp switch) input to each control unit can be monitored.

Control unit	Item
BCM	Detent switch
	Steering wheel position switch (telescoping switch and tilt switch)
	Seat memory switch (memory switch 1, memory switch 2, and setting switch).
	Driver door switch
	Door mirror remote control switch

Cancel of Switch Monitor


If one of the following conditions are satisfied, the switch monitor is cancelled.

- When the ignition switch is turned OFF.
- The vehicle speed becomes 7 km/h (4 MPH) or higher.

REVERSE INTERLOCK DOOR MIRROR SYSTEM

ON BOARD DIAGNOSIS FOR AUTOMATIC DRIVE POSITIONER

- Check the operations of the auto drive positioner system.













SEL596W
*1: If no malfunction is indicated, On board Diagnosis will end after the vehicle speed sensor diagnosis is performed.

*2: Diagnosis ends after self-diagnostic results have indicated for 10 minutes if left unattended.

REVERSE INTERLOCK DOOR MIRROR SYSTEM

Diagnosis Result Display

- The malfunctioning items are indicated by how many times LEDs on the seat memory switches 1 and 2 flash simultaneously.

Code No.	Detected items	Indication of seat memory switches 1 and 2	Explanation
1	Seat sliding	IND1, IND2 	While the seat motors are moving for 2.5 seconds, if the number of seat sliding/reclining/lifting sensor pulses changes 2 times or less, the seat device is determined to be malfunctioning.
2	Seat reclining	IND1, IND2 	
3	Seat lifting front	IND1, IND2 	
4	Seat lifting rear	IND1, IND2 	
5	Steering telescopic	IND1, IND2 	While the steering motors are moving, if the steering sensor output changes 0.2 volts or less, the steering device is determined to be malfunctioning.
6	Steering tilt	IND1, IND2 	
7	Door mirrors (upper and lower)	IND1, IND2 	When output voltage of either LH or RH door mirror sensor continues at less than 0.2V or more than 4.5V for 0.5 seconds or more, the door mirror is determined to be malfunctioning.
8	Door mirrors (LH and RH)	IND1, IND2 	When output voltage of either LH or RH door mirror sensor continues at less than 0.2V or more than 4.5V for 0.5 seconds or more, the door mirror is determined to be malfunctioning.
9	Vehicle speed sensor circuit	IND1, IND2 	If the vehicle speed sensor output of less than 7 km/h (4 MPH) is detected, the vehicle speed sensor is determined to be malfunctioning.
-	No malfunction in the above items		—

PIIA0190E

- If the vehicle speed is less than 7 km/h (4 MPH) for 15 seconds after the diagnosis for the seat and steering wheel systems were completed, the vehicle speed signal is judged malfunctioning.
- If LH door mirror is malfunctioning, only indicator lamp on the memory switch 1 flashes, and if RH door mirror is malfunctioning, only indicator lamp on the memory switch 2 flashes.
- When all the diagnosis are finished normally, the indicator lamps on the memory switches 1 and 2 go off after the vehicle speed signal diagnosis.
- If there are multiple malfunctioning parts, the lamps indicate them in sequence from the smallest diagnosis trouble code.
- The diagnosis results repeat until the diagnosis mode is cancelled.

REVERSE INTERLOCK DOOR MIRROR SYSTEM

Symptom Chart

AIS001XM

Symptom	Diagnoses / Service procedure	Refer to page
Reverse interlock door mirror system does not operate at all.	1. Door mirror remote control switch (changeover switch) circuit inspection.	GW-107
	2. Back-up input signal circuit inspection in R position.	GW-109
	3. Replace BCM.	—
<ul style="list-style-type: none"> During the reverse interlock door mirror system operation, either LH or RH door mirror face does not reproduce the stored angle. After the reverse interlock door mirror system operation, the door mirror face returns to wrong position (not to the original position). 	1. Mirror sensors circuit inspection .	GW-113
	2. Carry out the communication inspection again.	—
The mirror face position with the reverse gear engaged cannot be memorized.	1. Seat memory switch circuit inspection.	SE-76
	2. Door mirror remote control switch (changeover switch) system inspection.	GW-107
	3. Door mirror remote control switch (mirror switch) system inspection.	GW-110
	4. Back-up input signal control inspection R position inspection.	GW-109
	5. Mirror motors circuit inspection.	GW-111
	6. Mirror sensors circuit inspection.	GW-113
	7. Replace BCM.	—


Door Mirror Remote Control Switch (Changeover Switch) Circuit Inspection

AIS001XM

1. FUNCTION INSPECTION

With CONSULT-II

Check the operation on "MIR CHNG SW-R" or "MIR CHNG SW-L" in the DATA MONITOR. Refer to [GW-97, "DATA MONITOR"](#) .



Without CONSULT-II

Carry out the switch monitor in the self-diagnostic function. Refer to [GW-104, "SWITCH MONITOR"](#) .

OK or NG?

- OK >> Door mirror remote control switch (changeover switch) circuit is OK.
- NG >> GO TO 2.

REVERSE INTERLOCK DOOR MIRROR SYSTEM

2. DOOR MIRROR REMOTE CONTROL SWITCH (CHANGEOVER SWITCH) INSPECTION


1. Turn ignition switch OFF.
2. Disconnect door mirror remote control switch connector.
3. Check continuity between door mirror remote control switch terminal 5 (RH), 6 (LH) and 7.

Changeover switch RIGHT position

5 – 7 : Continuity should exist.

Changeover switch LEFT position

6 – 7 : Continuity should exist.



OK or NG ?

OK >> GO TO 3.

NG >> Replace malfunction door mirror remote control switch.

3. HARNESS CONTINUITY INSPECTION

1. Disconnect the BCM connector.
2. Check continuity between BCM connector M4 terminals 21, 24 and door mirror remote control switch connector M19 terminals 5, 6.

21 (SB) – 5 (SB) : Continuity should exist.

24 (BR/Y) – 6 (BR/Y) : Continuity should exist.

3. Check continuity between BCM connector M4 terminals 21, 24 and ground.


21 (SB) – Ground : Continuity should not exist.

24 (BR/Y) – Ground : Continuity should not exist.

OK or NG ?

OK >> GO TO 4.


NG >> Repair or replace harness.



4. GROUND CIRCUIT INSPECTION OF DOOR MIRROR REMOTE CONTROL SWITCH

Check continuity between the door mirror remote control switch connector M19 terminal 7 and ground.

7 (B) – Ground : Continuity should exist.



OK or NG ?

OK >> Check connector for damage or loose connection.

NG >> Repair or replace harness.

REVERSE INTERLOCK DOOR MIRROR SYSTEM

Back- Up Input Signal Circuit Inspection In R Position

AIS001XO

1. CHECK THE SYMPTOM

Check that other systems using the reverse signal are under normal operation.

Whether back-up lamp lights is checked.

OK or NG ?


OK >> GO TO 2.

NG >> Refer to [AT-265, "Vehicle Does Not Creep Backward in "R" Position"](#) .

2. FUNCTION INSPECTION

With CONSULT-II

Check the operation on "R POSITION SW" in the DATA MONITOR. Refer to [GW-97, "DATA MONITOR"](#) .



Without CONSULT-II

Carry out switch monitor in self-diagnostic function. Refer to [GW-104, "SWITCH MONITOR"](#) .

GO or NG ?

OK >> System is OK.

NG >> GO TO 3.


3. HARNESS CONTINUITY INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the BCM and back-up lamp relay connector.
3. Check continuity between BCM connector B4 terminal 141 and back-up lamp relay connector E2-2 terminal 3.

141 (R/B) – 3 (R/B) : Continuity should exist.

4. Check continuity between BCM connector B4 terminal 141 and ground.

141 (R/B) – Ground : Continuity should not exist.



OK or NG ?

OK >> Replace BCM.

NG >> Repair or replace harness.

REVERSE INTERLOCK DOOR MIRROR SYSTEM

AIS001XR

Door Mirror Remote Control Switch (Mirror Switch) Circuit Inspection

1. DOOR MIRROR REMOTE CONTROL SWITCH(MIRROR SWITCH) SIGNAL INSPECTION

With CONSULT-II

Check the operation on "MIR CON SW-UP/DN" and "MIR CON SW-RH/LH" in the DATA MONITOR. Refer to [GW-97, "DATA MONITOR"](#).

DATA MONITOR	
MONITOR	
MIR CON SW-UP	OFF
MIR CON SW-DN	OFF
MIR CON SW-RH	OFF
MIR CON SW-LH	OFF

PIIB0344E

Without CONSULT-II

Carry out the switch monitor in the self-diagnostic function. Refer to [GW-104, "SWITCH MONITOR"](#).


OK or NG ?

- OK >> Door mirror remote control switch (mirror switch) circuit is OK.
- NG >> GO TO 2.

2. DOOR MIRROR REMOTE CONTROL SWITCH (MIRROR SWITCH) INSPECTION

1. Turn ignition switch OFF.
2. Disconnect door mirror remote control switch connector.
3. Check continuity between door remote control switch (mirror switch) terminals 1, 2, 3, 4 and 7.

Terminals	Condition	Continuity
3	7	UP operation
4		DOWN operation
2		LEFT operation
1		RIGHT operation




OK or NG ?

- OK >> GO TO 3.
- NG >> Replace the door mirror remote control switch.

3. GROUND CIRCUIT INSPECTION OF DOOR MIRROR REMOTE CONTROL SWITCH

Check continuity between the door mirror remote control switch connector M19 terminal 7 and ground.

7 – Ground : Continuity should exist.



REVERSE INTERLOCK DOOR MIRROR SYSTEM

OK or NG ?

- OK >> GO TO 4.
- NG >> Repair or replace harness


4. HARNESS CONTINUITY INSPECTION

1. Disconnect BCM harness connector.
2. Check continuity between BCM connector M4 terminals 25, 29, 32, 34 and door mirror remote control switch connector M19 terminals 1, 2, 3, 4.

- 25 (G/R) – 2 (G/R) : Continuity should exist.**
- 29 (LG/R) – 1 (LG/R) : Continuity should exist.**
- 32 (L/W) – 3 (L/W) : Continuity should exist.**
- 34 (P/L) – 4 (P/L) : Continuity should exist.**

3. Check continuity between BCM connector M4 terminals 25, 29, 32, 34 and ground.

- 25 (G/R) – Ground : Continuity should not exist.**
- 29 (LG/R) – Ground : Continuity should not exist.**
- 32 (L/W) – Ground : Continuity should not exist.**
- 34 (P/L) – Ground : Continuity should not exist.**



OK or NG?

- OK >> Check connector for damage or loose connection.
- NG >> Repair or replace harness between BCM and door mirror remote control switch.

Mirror Motors Circuit Inspection

AIS001XS

1. DOOR MIRROR FUNCTION INSPECTION

Check the following items.
Operation malfunction caused by a foreign object caught in door mirror face edge.

OK or NG ?

- OK >> GO TO 2.
- NG >> Repair the malfunctioning parts, and check the symptom again.


2. MIRROR MOTOR INSPECTION

With CONSULT-II

Check the operation with "MIRROR MOTOR RH " or "MIRROR MOTOR LH " in the ACTIVE TEST. Refer to [GW-99, "ACTIVE TEST"](#) .

NOTE:

If CONSULT-II is not available, skip this procedure and go to the next step.



OK or NG ?

- OK >> System is OK.
- NG >> GO TO 3.

REVERSE INTERLOCK DOOR MIRROR SYSTEM


3. HARNESS CONTINUITY INSPECTION

1. Turn ignition switch OFF.
2. Disconnect door mirror control unit D5 (driver side), D35 (passenger side) and door mirror connector D2 (driver side), D32 (passenger side) connectors.
3. Check continuity between door mirror control unit connector D5 (driver side), D35 (passenger side) terminals 3, 4, 9 and door mirror connector D2 (driver side), D32 (passenger side) terminals 8, 9, 11.

- 3 (GY/R)(R)* – 8 (GY/R)(R)* : Continuity should exist.**
4 (BR) – 9 (BR) : Continuity should exist.
9 (PU/W)(OR)*–11 (PU/W)(OR)* : Continuity should exist.

4. Check continuity between door mirror control unit connector D5 (driver side), D35 (passenger side) terminals 3, 4, 9 and ground.

- 3 (GY/R)(R)* – Ground : Continuity should not exist.**
4 (BR) – Ground : Continuity should not exist.
9 (PU/W)(OR)* – Ground : Continuity should not exist.



*: Wire color for passenger side door mirror and passenger side door mirror control unit.

OK or NG ?


OK >> GO TO 4.

NG >> Repair or replace harness between door mirror control unit and door mirror.

4. MIRROR MOTOR SIGNAL INSPECTION

1. Connect door mirror control unit D5 (driver side), D35 (passenger side) and door mirror connector D2 (driver side), D32 (passenger side) connectors.
2. Turn ignition switch ON.
3. Check voltage between door mirror control unit connector D5 (driver side), D35 (passenger side) terminals 3, 4, 9 and ground.

Con- nector	Terminals (Wire color)		Condition	Voltage(V) (Approx.)
	(+)	(-)		
D5 D35	3 (GY/R) (R)*	Ground	When motor is actiated (UP)	Battery voltage
			When motor is not activated	0
	4 (BR)		When motor is actiaged (LEFT)	Battery voltage
			When motor is not activated	0
	9 (PU/W) (OR)*		When motor is activated (RIGHT) or (DOWN)	Battery voltage
			When motor is not activated	0



*: Wire color for passenger side door mirror control unit

OK or NG ?

OK >> Replace the door mirror motor (driver side) or (passenger side).

NG >> Replace the door mirror control unit (driver side) or (passenger side).

REVERSE INTERLOCK DOOR MIRROR SYSTEM

AIS002MX

Mirror Sensors Circuit Inspection

1. DOOR MIRROR FUNCTION INSPECTION

Check the following items.

- Operation malfunction caused by a foreign object caught in door mirror face edge.
- Operation malfunction in memory control.

NOTE:

If a door mirror face position is set to an implausible angle, the set position may not be reproduced.

OK or NG ?

OK >> GO TO 2.

NG >> Repair the malfunctioning parts, and check the symptom again.

2. MIRROR SENSOR INSPECTION

Ⓟ With CONSULT-II

Check that ON is displayed on "MIR/SE RH R-L", "MIR/SE RH U-D" or "MIR/SE LH R-L", "MIR/SE LH U-D" in the DATA MONITOR. Refer to [GW-97, "DATA MONITOR"](#).

DATA MONITOR	
MONITOR	
MIR/SE RH R-L	ON
MIR/SE RH U-D	ON
MIR/SE LH R-L	ON
MIR/SE LH U-D	ON

PIIB0342E

ⓧ Without CONSULT-II

GO TO 3.

Question

OK >> System is OK.

NG >> GO TO 3.

3. MIRROR SENSOR POWER SUPPLY INSPECTION


1. Turn ignition switch ON.
2. Check voltage between door mirror control unit connector D5 (driver side), D35 (passenger side) terminal 1 and ground.

1 (W/L) – Ground : Approx. 5V

OK or NG

OK >> GO TO 4.

NG >> Replace door mirror control unit.



REVERSE INTERLOCK DOOR MIRROR SYSTEM


4. MIRROR SENSOR GROUND CIRCUIT INSPECTION

1. Turn ignition switch OFF.
2. Check continuity between door mirror control unit connector D5 (driver side), D35 (passenger side) terminal 2 and ground.

2 (Y) – Ground : Continuity should exist.

OK or NG

- OK >> GO TO 5.
NG >> Replace door mirror control unit.



5. HARNESS CONTINUITY INSPECTION 1


1. Disconnect door mirror control unit connector D5 (driver side), D35 (passenger side) and door mirror connector D2 (driver side), D32 (passenger side).
2. Check continuity between door mirror control unit connector D5 (driver side), D35 (passenger side) terminal 1, 2 and door mirror connector D2 (driver side), D32 (passenger side) terminal 10, 16.

1 (W/L) – 16 (W/L) : Continuity should exist.

2 (Y) – 10 (Y) : Continuity should exist.

OK or NG

- OK >> GO TO 6.
NG >> Repair or replace harness.



6. HARNESS CONTINUITY INSPECTION 2

1. Disconnect door mirror control unit connector D5 (driver side), D35 (passenger side) and door mirror connector D2 (driver side), D32 (passenger side).
2. Check continuity between door mirror control unit connector D5 (driver side), D35 (passenger side) terminals 5, 6 and door mirror connector D2 (driver side), D32 (passenger side) terminals 12, 14.

5 (L/Y) – 14 (L/Y) : Continuity should exist.

6 (G) – 12 (G) : Continuity should exist.


3. Check continuity between door mirror control unit connector D5 (driver side), D35 (passenger side) terminals 5, 6 and ground.

5 (L/Y) – Ground : Continuity should not exist.

6 (G) – Ground : Continuity should not exist.

OK or NG?

- OK >> GO TO 7.
NG >> Repair or replace harness.



REVERSE INTERLOCK DOOR MIRROR SYSTEM


7. MIRROR SENSOR SIGNAL INSPECTION

1. Connect door mirror control unit D5 (driver side), D35 (passenger side) and door mirror D2 (driver side), D32 (passenger side) connectors.
2. Turn ignition switch ON.
3. Check voltage between door mirror control unit connector D5 (driver side), D35 (passenger side) terminals 5, 6 and ground.

Con- nector	Terminals (Wire color)		Condition	Voltage(V) (Approx.)
	(+)	(-)		
D5 D35	5(L/Y)	Ground	When motor is activated (UP/ DOWN)	Changes between 4 (close to peak) – 0.5 (close to valley)
	6(G)		When motor is activated (LEFT/ RIGHT)	Changes between 4 (close to right edge) – 0.5 (close to left edge)

OK or NG?

- OK >> Replace the door mirror control unit.
 NG >> Replace the door mirror.



A
B
C
D
E
F
G
H
J
K
L
M

GW

DOOR MIRROR


PDF:96301

DOOR MIRROR

Wiring Diagram — MIRROR —

AIS001HM

GW-MIRROR-05



10	2	9	8
6	1	4	3

1	1	1	1	1	2	2	2	2	2
3	3	3	3	3	3	3	3	3	3


16	14	12	10	6	4	2
15	13	11	9	8	7	5

REFER TO THE FOLLOWING.
 (D1), (D31) -SUPER MULTIPLE JUNCTION (SMJ)
 (M1) -FUSE BLOCK-JUNCTION BOX (J/B) NO.1

DOOR MIRROR

Removal and Installation

AIS001HN



1. Door mirror assembly

2. Inner cover

REMOVAL

1. Remove front door finisher and Inner cover. Refer to [EI-31, "DOOR FINISHER"](#).
2. Disconnect door mirror harness connector.
3. Loosen the door mirror mounting nuts, and remove door mirror assembly.

INSTALLATION

Install in the reverse order of removal.


A
B
C
D
E
F
G
H
J
K
L
M

GW

DOOR MIRROR

Disassembly and Assembly

AIS001HO



DISASSEMBLY

1. Place the mirror body with the mirror glass facing upward.
2. Put a strip of protective tape on the mirror body.
3. As shown in the figure, insert a small slotted screwdriver wrapped with tape into the recess between the mirror face (mirror holder) and mirror holder bracket, and push up the lower pawls to remove the mirror holder lower half.

NOTE:


When pushing up the pawls, do not attempt to use 1 recess only, be sure to push up with both recesses. Insert screwdriver into recesses, and push up while rotating (twist) to make work easier.

4. Lightly lift up lower side of the mirror face, and detach pawls of upper side as if pulling it out. Remove the mirror face from the mirror body.

NOTE:

Be certain not to allow grease on sealing agent in center of the mirror body assembly or back side of the mirror face (mirror holder).

5. Remove the terminals of mirror heater from the mirror face.




DOOR MIRROR

ASSEMBLY

1. Place the mirror holder bracket and mirror body assembly in a horizontal position.
2. Connect the terminals of mirror heater to the mirror face.
3. Fit the upper pawls on the mirror face onto the mirror holder bracket first, then press the lower side of the mirror face until a click sound is heard to engage the lower pawls.

NOTE:

After installation, visually check that the lower pawls are securely engaged from the bottom of the mirror face.



A
B
C
D

E

F

G

H

GW

J

K

L

M

DOOR MIRROR
