

SECTION **DLK**  
DOOR & LOCK

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

CONTENTS

<b>PRECAUTION</b> .....	6	TRUNK OPEN FUNCTION : System Diagram .....	18
<b>PRECAUTIONS</b> .....	6	TRUNK OPEN FUNCTION : System Description.....	18
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	6	<b>REMOTE KEYLESS ENTRY FUNCTION</b> .....	19
Precaution Necessary for Steering Wheel Rotation after Battery Disconnect .....	6	REMOTE KEYLESS ENTRY FUNCTION : System Diagram .....	19
Precaution for Procedure without Cowl Top Cover.....	7	REMOTE KEYLESS ENTRY FUNCTION : System Description .....	19
Precautions For Xenon Headlamp Service .....	7	<b>KEY REMINDER FUNCTION</b> .....	21
Work .....	7	KEY REMINDER FUNCTION : System Diagram ....	22
<b>PREPARATION</b> .....	8	KEY REMINDER FUNCTION : System Description .....	22
<b>PREPARATION</b> .....	8	<b>WELCOME LIGHT FUNCTION</b> .....	22
Special Service Tools .....	8	WELCOME LIGHT FUNCTION : System Diagram .....	23
Commercial Service Tools .....	8	WELCOME LIGHT FUNCTION : System Description .....	23
<b>SYSTEM DESCRIPTION</b> .....	9	<b>WARNING FUNCTION</b> .....	24
<b>COMPONENT PARTS</b> .....	9	WARNING FUNCTION : System Description .....	24
<b>DOOR LOCK SYSTEM</b> .....	9	<b>SYSTEM (TRUNK LID OPENER SYSTEM)</b> .....	28
DOOR LOCK SYSTEM :		System Diagram .....	28
Component Parts Location .....	9	System Description .....	28
DOOR LOCK SYSTEM : Component Description...	11	<b>DIAGNOSIS SYSTEM (BCM)</b> .....	29
<b>SYSTEM (POWER DOOR LOCK SYSTEM)</b> .....	12	<b>COMMON ITEM</b> .....	29
System Diagram .....	12	COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM) .....	29
System Description .....	12	<b>DOOR LOCK</b> .....	30
<b>SYSTEM (INTELLIGENT KEY SYSTEM)</b> .....	14	DOOR LOCK : CONSULT-III Function (BCM - DOOR LOCK) .....	30
<b>INTELLIGENT KEY SYSTEM</b> .....	14	<b>INTELLIGENT KEY</b> .....	31
INTELLIGENT KEY SYSTEM : System Diagram....	14	INTELLIGENT KEY : CONSULT-III Function (BCM - INTELLIGENT KEY) .....	32
INTELLIGENT KEY SYSTEM : System Description .....	14	<b>TRUNK</b> .....	35
<b>DOOR LOCK FUNCTION</b> .....	15	TRUNK : CONSULT-III Function (BCM - TRUNK)....	35
DOOR LOCK FUNCTION : System Diagram .....	15		
DOOR LOCK FUNCTION : System Description ....	15		
<b>TRUNK OPEN FUNCTION</b> .....	17		

DLK

<b>ECU DIAGNOSIS INFORMATION .....</b>	<b>37</b>	<b>DOOR REQUEST SWITCH .....</b>	<b>78</b>
<b>BCM .....</b>	<b>37</b>	Component Function Check .....	78
List of ECU Reference .....	37	Diagnosis Procedure .....	78
<b>WIRING DIAGRAM .....</b>	<b>38</b>	Component Inspection .....	79
<b>DOOR &amp; LOCK SYSTEM .....</b>	<b>38</b>	<b>TRUNK LID OPENER REQUEST SWITCH .....</b>	<b>80</b>
Wiring Diagram - DOOR & LOCK SYSTEM - .....	38	Component Function Check .....	80
<b>BASIC INSPECTION .....</b>	<b>56</b>	Diagnosis Procedure .....	80
<b>DIAGNOSIS AND REPAIR WORK FLOW .....</b>	<b>56</b>	Component Inspection .....	81
Work Flow .....	56	<b>TRUNK LID OPENER SWITCH .....</b>	<b>82</b>
<b>INSPECTION AND ADJUSTMENT .....</b>	<b>59</b>	Component Function Check .....	82
<b>ADDITIONAL SERVICE WHEN REPLACING</b>		Diagnosis Procedure .....	82
<b>CONTROL UNIT .....</b>	<b>59</b>	Component Inspection .....	83
ADDITIONAL SERVICE WHEN REPLACING		<b>TRUNK LID OPENER CANCEL SWITCH .....</b>	<b>84</b>
CONTROL UNIT : Description .....	59	Component Function Check .....	84
ADDITIONAL SERVICE WHEN REPLACING		Diagnosis Procedure .....	84
CONTROL UNIT : Special Repair Requirement ....	59	Component Inspection .....	85
<b>DTC/CIRCUIT DIAGNOSIS .....</b>	<b>60</b>	<b>TRUNK ROOM LAMP SWITCH .....</b>	<b>86</b>
<b>B2621 INSIDE ANTENNA .....</b>	<b>60</b>	Component Function Check .....	86
DTC Logic .....	60	Diagnosis Procedure .....	86
Diagnosis Procedure .....	60	Component Inspection .....	87
<b>B2622 INSIDE ANTENNA .....</b>	<b>62</b>	<b>DOOR LOCK ACTUATOR .....</b>	<b>88</b>
DTC Logic .....	62	<b>DRIVER SIDE .....</b>	<b>88</b>
Diagnosis Procedure .....	62	DRIVER SIDE : Component Function Check .....	88
<b>B2623 INSIDE ANTENNA .....</b>	<b>64</b>	DRIVER SIDE : Diagnosis Procedure .....	88
DTC Logic .....	64	<b>PASSENGER SIDE .....</b>	<b>89</b>
Diagnosis Procedure .....	64	PASSENGER SIDE :	
<b>B2626 OUTSIDE ANTENNA .....</b>	<b>66</b>	Component Function Check .....	89
DTC Logic .....	66	PASSENGER SIDE : Diagnosis Procedure .....	89
Diagnosis Procedure .....	66	<b>REAR LH .....</b>	<b>90</b>
<b>B2627 OUTSIDE ANTENNA .....</b>	<b>68</b>	REAR LH : Component Function Check .....	90
DTC Logic .....	68	REAR LH : Diagnosis Procedure .....	90
Diagnosis Procedure .....	68	<b>REAR RH .....</b>	<b>91</b>
<b>B2628 OUTSIDE ANTENNA .....</b>	<b>70</b>	REAR RH : Component Function Check .....	91
DTC Logic .....	70	REAR RH : Diagnosis Procedure .....	91
Diagnosis Procedure .....	70	<b>FUEL LID LOCK ACTUATOR .....</b>	<b>93</b>
<b>DOOR SWITCH .....</b>	<b>72</b>	Component Function Check .....	93
Component Function Check .....	72	Diagnosis Procedure .....	93
Diagnosis Procedure .....	72	<b>TRUNK LID OPENER ACTUATOR .....</b>	<b>95</b>
Component Inspection .....	74	Component Function Check .....	95
<b>DOOR LOCK AND UNLOCK SWITCH .....</b>	<b>75</b>	Diagnosis Procedure .....	95
Component Function Check .....	75	<b>REMOTE KEYLESS ENTRY RECEIVER .....</b>	<b>97</b>
Diagnosis Procedure .....	75	Component Function Check .....	97
<b>DOOR KEY CYLINDER SWITCH .....</b>	<b>76</b>	Diagnosis Procedure .....	97
Component Function Check .....	76	<b>UNLOCK SENSOR .....</b>	<b>100</b>
Diagnosis Procedure .....	76	Component Function Check .....	100
Component Inspection .....	77	Diagnosis Procedure .....	100
		Component Inspection .....	101
		<b>INTELLIGENT KEY WARNING BUZZER .....</b>	<b>102</b>

Component Function Check .....	102	PASSENGER SIDE : Diagnosis Procedure .....	113
Diagnosis Procedure .....	102	<b>DOOR DOES NOT LOCK/UNLOCK WITH INTELLIGENT KEY</b> .....	<b>114</b>
Component Inspection .....	103	Diagnosis Procedure .....	114
<b>INTELLIGENT KEY</b> .....	<b>104</b>	<b>TRUNK LID DOES NOT OPEN</b> .....	<b>115</b>
Component Function Check .....	104	<b>TRUNK LID OPENER SWITCH</b> .....	<b>115</b>
Diagnosis Procedure .....	104	TRUNK LID OPENER SWITCH : Description .....	115
Special Repair Requirement .....	104	TRUNK LID OPENER SWITCH : Diagnosis Procedure .....	115
<b>INFORMATION DISPLAY</b> .....	<b>105</b>	<b>INTELLIGENT KEY</b> .....	<b>115</b>
Component Function Check .....	105	INTELLIGENT KEY : Description .....	115
Diagnosis Procedure .....	105	INTELLIGENT KEY : Diagnosis Procedure .....	115
<b>COMBINATION METER BUZZER</b> .....	<b>106</b>	<b>TRUNK LID OPENER REQUEST SWITCH</b> .....	<b>116</b>
Component Function Check .....	106	TRUNK LID OPENER REQUEST SWITCH : Description .....	116
Diagnosis Procedure .....	106	TRUNK LID OPENER REQUEST SWITCH : Diagnosis Procedure .....	116
<b>HAZARD FUNCTION</b> .....	<b>107</b>	<b>FUEL LID LOCK ACTUATOR DOES NOT OPERATE</b> .....	<b>117</b>
Component Function Check .....	107	Diagnosis Procedure .....	117
Diagnosis Procedure .....	107	<b>IGNITION POSITION WARNING FUNCTION DOES NOT OPERATE</b> .....	<b>118</b>
<b>SYMPTOM DIAGNOSIS</b> .....	<b>108</b>	Diagnosis Procedure .....	118
<b>DOOR DOES NOT LOCK/UNLOCK WITH DOOR LOCK AND UNLOCK SWITCH</b> .....	<b>108</b>	<b>SELECTIVE UNLOCK FUNCTION DOES NOT OPERATE</b> .....	<b>119</b>
<b>ALL DOOR</b> .....	<b>108</b>	Diagnosis Procedure .....	119
ALL DOOR : Description .....	108	<b>VEHICLE SPEED SENSING AUTO LOCK OPERATION DOES NOT OPERATE</b> .....	<b>120</b>
ALL DOOR : Diagnosis Procedure .....	108	Diagnosis Procedure .....	120
<b>DRIVER SIDE</b> .....	<b>108</b>	<b>IGN OFF INTERLOCK DOOR UNLOCK FUNCTION DOES NOT OPERATE</b> .....	<b>121</b>
DRIVER SIDE : Description .....	108	Diagnosis Procedure .....	121
DRIVER SIDE : Diagnosis Procedure .....	108	<b>P RANGE INTERLOCK DOOR LOCK/UNLOCK FUNCTION DOES NOT OPERATE</b> .....	<b>122</b>
<b>PASSENGER SIDE</b> .....	<b>108</b>	Diagnosis Procedure .....	122
PASSENGER SIDE : Description .....	109	<b>AUTO DOOR LOCK OPERATION DOES NOT OPERATE</b> .....	<b>123</b>
PASSENGER SIDE : Diagnosis Procedure .....	109	Diagnosis Procedure .....	123
<b>REAR LH</b> .....	<b>109</b>	<b>HAZARD AND HORN REMINDER DOES NOT OPERATE</b> .....	<b>124</b>
REAR LH : Description .....	109	Diagnosis Procedure .....	124
REAR LH : Diagnosis Procedure .....	109	<b>HAZARD AND BUZZER REMINDER DOES NOT OPERATE</b> .....	<b>125</b>
<b>REAR RH</b> .....	<b>109</b>	Diagnosis Procedure .....	125
REAR RH : Description .....	109	<b>KEY REMINDER FUNCTION DOES NOT OPERATE</b> .....	<b>126</b>
REAR RH : Diagnosis Procedure .....	109	Diagnosis Procedure .....	126
<b>DOOR DOES NOT LOCK/UNLOCK WITH DOOR KEY CYLINDER OPERATION</b> .....	<b>111</b>		
Diagnosis Procedure .....	111		
<b>DOOR DOES NOT LOCK/UNLOCK WITH DOOR REQUEST SWITCH</b> .....	<b>112</b>		
<b>ALL DOOR</b> .....	<b>112</b>		
ALL DOOR : Description .....	112		
ALL DOOR : Diagnosis Procedure .....	112		
<b>DRIVER SIDE</b> .....	<b>112</b>		
DRIVER SIDE : Description .....	113		
DRIVER SIDE : Diagnosis Procedure .....	113		
<b>PASSENGER SIDE</b> .....	<b>113</b>		
PASSENGER SIDE : Description .....	113		

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DLK  
L  
M  
N  
O  
P

<b>WELCOME LIGHT FUNCTION DOES NOT OPERATE</b> .....	<b>127</b>	<b>DOOR ASSEMBLY</b> .....	<b>153</b>
Diagnosis Procedure .....	127	DOOR ASSEMBLY : Removal and Installation ...	153
<b>OFF POSITION WARNING DOES NOT OPERATE</b> .....	<b>129</b>	DOOR ASSEMBLY : Adjustment .....	154
Diagnosis Procedure .....	129	<b>DOOR STRIKER</b> .....	<b>155</b>
<b>P POSITION WARNING DOES NOT OPERATE</b> .....	<b>130</b>	DOOR STRIKER : Removal and Installation .....	155
Diagnosis Procedure .....	130	<b>DOOR HINGE</b> .....	<b>156</b>
<b>ACC WARNING DOES NOT OPERATE</b> .....	<b>131</b>	DOOR HINGE : Removal and Installation .....	156
Diagnosis Procedure .....	131	<b>DOOR CHECK LINK</b> .....	<b>156</b>
<b>TAKE AWAY WARNING DOES NOT OPERATE</b> .....	<b>132</b>	DOOR CHECK LINK : Removal and Installation .	156
Diagnosis Procedure .....	132	<b>REAR DOOR</b> .....	<b>157</b>
<b>INTELLIGENT KEY LOW BATTERY WARNING DOES NOT OPERATE</b> .....	<b>134</b>	Exploded View .....	157
Diagnosis Procedure .....	134	<b>DOOR ASSEMBLY</b> .....	<b>157</b>
<b>DOOR LOCK OPERATION WARNING DOES NOT OPERATE</b> .....	<b>135</b>	DOOR ASSEMBLY : Removal and Installation ...	157
Diagnosis Procedure .....	135	DOOR ASSEMBLY : Adjustment .....	159
<b>KEY ID WARNING DOES NOT OPERATE</b> ....	<b>136</b>	<b>DOOR STRIKER</b> .....	<b>160</b>
Diagnosis Procedure .....	136	DOOR STRIKER : Removal and Installation .....	160
<b>SQUEAK AND RATTLE TROUBLE DIAGNOSES</b> .....	<b>137</b>	<b>DOOR HINGE</b> .....	<b>160</b>
Work Flow .....	137	DOOR HINGE : Removal and Installation .....	160
Inspection Procedure .....	139	<b>DOOR CHECK LINK</b> .....	<b>160</b>
Diagnostic Worksheet .....	141	DOOR CHECK LINK : Removal and Installation .	160
<b>REMOVAL AND INSTALLATION</b> .....	<b>143</b>	<b>TRUNK LID</b> .....	<b>162</b>
<b>HOOD</b> .....	<b>143</b>	Exploded View .....	162
Exploded View .....	143	<b>TRUNK LID ASSEMBLY</b> .....	<b>162</b>
<b>HOOD ASSEMBLY</b> .....	<b>143</b>	TRUNK LID ASSEMBLY : Removal and Installation .....	162
HOOD ASSEMBLY : Removal and Installation ...	143	TRUNK LID ASSEMBLY : Adjustment .....	164
HOOD ASSEMBLY : Adjustment .....	145	<b>TRUNK LID STRIKER</b> .....	<b>166</b>
<b>HOOD HINGE</b> .....	<b>146</b>	TRUNK LID STRIKER : Removal and Installation.	166
HOOD HINGE : Removal and Installation .....	146	<b>TRUNK LID HINGE</b> .....	<b>166</b>
<b>HOOD STAY</b> .....	<b>146</b>	TRUNK LID HINGE : Removal and Installation ...	166
HOOD STAY : Removal and Installation .....	147	<b>TRUNK LID STAY</b> .....	<b>166</b>
HOOD STAY : Disposal .....	147	TRUNK LID STAY : Removal and Installation .....	166
<b>RADIATOR CORE SUPPORT</b> .....	<b>148</b>	TRUNK LID STAY : Disposal .....	167
Exploded View .....	148	<b>TRUNK LID WEATHER-STRIP</b> .....	<b>167</b>
Removal and Installation .....	148	TRUNK LID WEATHER-STRIP : Removal and Installation .....	167
<b>FRONT FENDER</b> .....	<b>151</b>	<b>HOOD LOCK</b> .....	<b>169</b>
Exploded View .....	151	Exploded View .....	169
Removal and Installation .....	151	<b>HOOD LOCK</b> .....	<b>169</b>
<b>FRONT DOOR</b> .....	<b>153</b>	HOOD LOCK : Removal and Installation .....	169
Exploded View .....	153	HOOD LOCK : Inspection .....	170
		<b>HOOD LOCK CONTROL CABLE</b> .....	<b>171</b>
		HOOD LOCK CONTROL CABLE : Removal and Installation .....	171
		HOOD LOCK CONTROL CABLE : Inspection .....	173
		<b>FRONT DOOR LOCK</b> .....	<b>174</b>

Exploded View .....	174	INSTRUMENT CENTER : Removal and Installation .....	186	A
<b>DOOR LOCK .....</b>	<b>174</b>	<b>CONSOLE .....</b>	<b>186</b>	B
DOOR LOCK : Removal and Installation .....	174	CONSOLE : Removal and Installation .....	186	
<b>INSIDE HANDLE .....</b>	<b>176</b>	<b>TRUNK ROOM .....</b>	<b>186</b>	C
INSIDE HANDLE : Removal and Installation .....	176	TRUNK ROOM : Removal and Installation .....	186	
<b>OUTSIDE HANDLE .....</b>	<b>176</b>	<b>OUTSIDE KEY ANTENNA .....</b>	<b>187</b>	D
OUTSIDE HANDLE : Removal and Installation ...	176	<b>DRIVER SIDE .....</b>	<b>187</b>	
<b>REAR DOOR LOCK .....</b>	<b>178</b>	DRIVER SIDE : Removal and Installation .....	187	E
Exploded View .....	178	<b>PASSENGER SIDE .....</b>	<b>187</b>	
<b>DOOR LOCK .....</b>	<b>178</b>	PASSENGER SIDE : Removal and Installation ...	187	F
DOOR LOCK : Removal and Installation .....	178	<b>REAR BUMPER .....</b>	<b>187</b>	
<b>INSIDE HANDLE .....</b>	<b>179</b>	REAR BUMPER : Removal and Installation .....	187	G
INSIDE HANDLE : Removal and Installation .....	179	<b>INTELLIGENT KEY WARNING BUZZER .....</b>	<b>188</b>	
<b>OUTSIDE HANDLE .....</b>	<b>179</b>	Removal and Installation .....	188	H
OUTSIDE HANDLE : Removal and Installation ...	180	<b>TRUNK OPENER REQUEST SWITCH .....</b>	<b>189</b>	
<b>TRUNK LID LOCK .....</b>	<b>182</b>	Removal and Installation .....	189	I
Exploded View .....	182	<b>TRUNK LID OPENER SWITCH .....</b>	<b>190</b>	
Removal and Installation .....	182	Removal and Installation .....	190	J
<b>FUEL FILLER LID OPENER .....</b>	<b>183</b>	<b>TRUNK LID OPENER CANCEL SWITCH .....</b>	<b>191</b>	
Exploded View .....	183	Removal and Installation .....	191	
Removal and Installation .....	183	<b>REMOTE KEYLESS ENTRY RECEIVER .....</b>	<b>192</b>	
<b>DOOR SWITCH .....</b>	<b>185</b>	Removal and Installation .....	192	
Removal and Installation .....	185	<b>INTELLIGENT KEY BATTERY .....</b>	<b>193</b>	
<b>INSIDE KEY ANTENNA .....</b>	<b>186</b>	Removal and Installation .....	193	
<b>INSTRUMENT CENTER .....</b>	<b>186</b>			

**DLK**

L  
M  
N  
O  
P

# PRECAUTIONS

< PRECAUTION >

## PRECAUTION

### PRECAUTIONS

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000006114040

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIR BAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

#### Precaution Necessary for Steering Wheel Rotation after Battery Disconnect

INFOID:000000006114041

#### **NOTE:**

- Before removing and installing any control units, first turn the push-button ignition switch to the LOCK position, then disconnect both battery cables.
- After finishing work, confirm that all control unit connectors are connected properly, then re-connect both battery cables.
- Always use CONSULT-III to perform self-diagnosis as a part of each function inspection after finishing work. If a DTC is detected, perform trouble diagnosis according to self-diagnosis results.

For vehicle with steering lock unit, if the battery is disconnected or discharged, the steering wheel will lock and cannot be turned.

If turning the steering wheel is required with the battery disconnected or discharged, follow the operation procedure below before starting the repair operation.

#### OPERATION PROCEDURE

1. Connect both battery cables.

#### **NOTE:**

Supply power using jumper cables if battery is discharged.

2. Turn the push-button ignition switch to ACC position.  
(At this time, the steering lock will be released.)
3. Disconnect both battery cables. The steering lock will remain released with both battery cables disconnected and the steering wheel can be turned.
4. Perform the necessary repair operation.

# PRECAUTIONS


## < PRECAUTION >

- When the repair work is completed, re-connect both battery cables. With the brake pedal released, turn the push-button ignition switch from ACC position to ON position, then to LOCK position. (The steering wheel will lock when the push-button ignition switch is turned to LOCK position.)
- Perform self-diagnosis check of all control units using CONSULT-III.

### Precaution for Procedure without Cowl Top Cover

INFOID:000000006114042

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc.



### Precautions For Xenon Headlamp Service

INFOID:000000006114043

#### **WARNING:**

Comply with the following warnings to prevent any serious accident.

- Disconnect the battery cable (negative terminal) or the power supply fuse before installing, removing, or touching the xenon headlamp (bulb included). The xenon headlamp contains high-voltage generated parts.
- Never work with wet hands.
- Check the xenon headlamp ON-OFF status after assembling it to the vehicle. Never turn the xenon headlamp ON in other conditions. Connect the power supply to the vehicle-side connector. (Turning it ON outside the lamp case may cause fire or visual impairments.)
- Never touch the bulb glass immediately after turning it OFF. It is extremely hot.

#### **CAUTION:**

Comply with the following cautions to prevent any error and malfunction.

- Install the xenon bulb securely. (Insufficient bulb socket installation may melt the bulb, the connector, the housing, etc. by high-voltage leakage or corona discharge.)
- Never perform HID circuit inspection with a tester.
- Never touch the xenon bulb glass with hands. Never put oil and grease on it.
- Dispose of the used xenon bulb after packing it in thick vinyl without breaking it.
- Never wipe out dirt and contamination with organic solvent (thinner, gasoline, etc.).

### Work

INFOID:000000006114039

- After removing and installing the opening/closing parts, be sure to carry out fitting adjustments to check their operational.
- Check the lubrication level, damage, and wear of each part. If necessary, grease or replace it.

# PREPARATION

< PREPARATION >



## PREPARATION

### PREPARATION

#### Special Service Tools




INFOID:000000006114044

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
<p>(J-39570) Chassis ear</p>  <p>SIIA0993E</p>	<p>Locates the noise</p>
<p>(J-43980) NISSAN Squeak and Rattle Kit</p>  <p>SIIA0994E</p>	<p>Repairs the cause of noise</p>

#### Commercial Service Tools

INFOID:000000006114045

Tool name	Description
<p>Engine ear</p>  <p>SIIA0995E</p>	<p>Locates the noise</p>
<p>Remover tool</p>  <p>PIIB7923J</p>	<p>Removes the clips, pawls, and metal clips</p>
<p>Power tool</p>  <p>PIIB1407E</p>	



# COMPONENT PARTS

< SYSTEM DESCRIPTION >


## SYSTEM DESCRIPTION

### COMPONENT PARTS

#### DOOR LOCK SYSTEM

#### DOOR LOCK SYSTEM : Component Parts Location

INFOID:000000005946859



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P


DLK

JMKIA5285ZZ

# COMPONENT PARTS

## < SYSTEM DESCRIPTION >

- |  |  |   |
|--|--|---|
| 1. Inside key antenna (trunk room)   | 2. Inside key antenna (console)              | 3. Inside key antenna (instrument center)                 |
| 4. Remote keyless entry receiver   | 5. Intelligent Key warning buzzer            | 6. Combination meter                                      |
| 7. BCM   | 8. TCM                                       | 9. Power window main switch (door lock and unlock switch) |
| Refer to <a href="#">BCS-4, "BODY CONTROL SYSTEM : Component Parts Location"</a> |  |   |
| Refer to <a href="#">TM-8, "A/T CONTROL SYSTEM : Component Parts Location"</a>   |  |   |
| 10. Outside key antenna (driver side)  | 11. Front door switch (driver side)          | 12. Front door lock assembly (driver side)                |
| 13. Front door request switch (driver side)                                      |  |   |
| A. View with trunk lid upper finisher removed                                    | B. View with center console assembly removed | C. View with cluster lid C removed                        |
| D. View with glove box assembly removed  | E. View with front bumper removed            |   |



- |   |  |                                    |
|---|--|------------------------------------|
| 1. Push-button ignition switch                | 2. Trunk lid opener switch               | 3. Trunk lid opener request switch |
| 4. Trunk lid opener actuator                  | 5. Outside key antenna (rear bumper)     | 6. Fuel lid lock actuator          |
| 7. Front door request switch (passenger side) | 8. Outside key antenna (passenger side)  | 9. Trunk lid opener cancel switch  |
| A. View with rear bumper removed              | B. View with trunk side finisher removed |                                    |

# COMPONENT PARTS

< SYSTEM DESCRIPTION >

## DOOR LOCK SYSTEM : Component Description

INFOID:000000005946860

Item	Function
BCM	Controls the door lock system.
IPDM E/R	Sounds horn and blinks head lamp via CAN communication between BCM
TCM	Transmits shift position signal to BCM via CAN communication line.
Combination meter	<ul style="list-style-type: none"> <li>• Displays each operation method guide and warning for system malfunction</li> <li>• Performs operation method guide and warning with buzzer</li> <li>• Transmits vehicle speed signal to CAN communication line</li> </ul>
Remote keyless entry receiver	Receives lock/unlock signal from the Intelligent Key, and then transmits to BCM
Inside key antenna	Detects if Intelligent Key is inside the vehicle
Outside key antenna	Detects if Intelligent Key is outside the vehicle
Push-button ignition switch	Inputs push-button ignition switch ON/OFF condition to BCM
Door switch	Inputs door open/close condition to BCM
Door lock and unlock switch	<ul style="list-style-type: none"> <li>• Detects if door lock and unlock switch is press/release</li> <li>• Integrated in the power window main switch and front power window switch (passenger side)</li> </ul>
Door request switch	<ul style="list-style-type: none"> <li>• Detects if each door request switch is press/release</li> <li>• Integrated in the outside handle (driver side, passenger side) and back door opener switch assembly</li> </ul>
Intelligent Key	<p>The following functions are available when having and carrying electronic ID</p> <ul style="list-style-type: none"> <li>• Door lock/unlock</li> <li>• Engine start</li> <li>• Remote control entry function is available when operating on button</li> </ul>
Hazard warning lamp	Warns the user of the lock/unlock condition and inappropriate operations with the lamps blink
Door lock actuator	Output lock/unlock signal from BCM and locks/unlocks each door
Fuel lid lock actuator	Output lock/unlock signal from BCM and locks/unlocks fuel filler lid
Intelligent Key warning buzzer	Warns the user of the lock/unlock condition and inappropriate operations with the buzzer sound
Unlock sensor	Detects lock condition of driver door
Trunk lid opener actuator	Performs trunk lid open with signal from BCM
Trunk lid opener request switch	Performs trunk lid open request when it is pressed
Trunk lid opener cancel switch	Cancel trunk open operation
Trunk room lamp switch	It detects engagement of trunk lid lock assembly and trunk lid striker

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P


DLK

# SYSTEM (POWER DOOR LOCK SYSTEM)

< SYSTEM DESCRIPTION >

## SYSTEM (POWER DOOR LOCK SYSTEM)

### System Diagram



### System Description

#### DOOR LOCK FUNCTION

##### Door Lock and Unlock Switch

- The door lock and unlock switch (driver side) is build into power window main switch.
- Interlocked with the locking operation of door lock and unlock switch, door lock actuators of all doors and fuel lid lock actuator are locked.
- Interlocked with the unlocking operation of door lock and unlock switch, door lock actuators of all doors actuator and fuel lid lock actuator are unlocked.

##### Door Key Cylinder Switch

- With the mechanical key inserted in the door key cylinder on driver side, turning it to lock position, locks door lock actuator of all doors and fuel lid lock actuator.
- With the mechanical key inserted in the door key cylinder on driver side, turning it to unlock position once unlocks the driver side door, turning it to unlock position again within 60 seconds after the first unlock operation unlocks all of the other doors actuator and fuel lid lock actuator. (SELECTIVE UNLOCK OPERATION)

Selective unlock operation mode can be changed using CONSULT-III.

Refer to [DLK-30, "DOOR LOCK : CONSULT-III Function \(BCM - DOOR LOCK\)"](#).

#### DOOR KEY CYLINDER SWITCH POWER WINDOW FUNCTION

Driver side door key cylinder LOCK/UNLOCK operation can activate power window operation. Refer to [PWC-7, "System Description"](#).

#### IGNITION POSITION WARNING FUNCTION

When door lock and unlock switch are operated while driver side door is open and ignition position is ACC or ON, door locks once but immediately unlocks.

#### INTERIOR ROOM LAMP CONTROL FUNCTION

Interior room lamp is controlled according to door lock/unlock state, refer to [INL-7, "INTERIOR ROOM LAMP CONTROL SYSTEM : System Description"](#).

#### AUTOMATIC DOOR LOCK/UNLOCK FUNCTION (LOCK OPERATION)

The interlock door lock function is the function that locks all doors linked with the vehicle speed or shift position. It has 2 types as per the following items.

##### Vehicle Speed Sensing Auto Door Lock\*

All doors are locked when the vehicle speed reaches 24 km/h (15 MPH) or more.

BCM outputs the lock signal to all door lock actuators when it detects that the ignition switch is turned ON, all doors are closed and the vehicle speed received from the combination meter. via CAN communication becomes 24 km/h (15 MPH) or more.

##### P Range Interlock Door Lock

# SYSTEM (POWER DOOR LOCK SYSTEM)

## < SYSTEM DESCRIPTION >

All doors are locked when shifting the selector lever from the P position to any position other than the P position.

BCM outputs the lock signal to all door lock actuators when it detects that the ignition switch is in the ON position and the shift signal received from the TCM via CAN communication is shifted from the P position to any position other than the P position.

Setting change of Automatic Door Lock/Unlock Function

The lock operation setting of the automatic door lock/unlock function can be changed.

### **With CONSULT-III**

Refer to [DLK-32, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).

### **Without CONSULT- III**

The automatic door lock function ON/OFF can be switched by performing the following operation.

1. Close all doors (door switch OFF)
2. Turn ignition switch ON
3. Press and hold the door lock and unlock switch for 5 seconds or more in the "LOCK" direction within 20 seconds after turning the ignition switch ON.
4. The switch is complete when the hazard lamp blinks.

**OFF → ON : 2 blinks**

**ON → OFF : 1 blink**

## AUTOMATIC DOOR LOCK/UNLOCK FUNCTION (UNLOCK OPERATION)

The automatic door lock/unlock function is the function that unlocks all doors linked with the key position or shift position. It has 2 types as per the following items.

### IGN OFF Interlock Door Unlock\*

All doors are unlocked when the power supply position is changed from ON to OFF.

BCM outputs the unlock signal to all door lock actuators when it detects that the power supply position is changed from ignition switch ON to OFF.

### P Range Interlock Door Unlock

All doors are unlocked when shifting the selector lever from any position other than the P to P positions.

BCM outputs the unlock signal to all door lock actuators when it detects that the ignition switch is in the ON position and the shift signal received from TCM via CAN communication is shifted from any position other than the P to P positions.

Setting change of Automatic Door Lock/Unlock Function

The unlock operation setting of the automatic door lock/unlock function can be changed.

### **With CONSULT- III**

Refer to [DLK-32, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).

### **Without CONSULT- III**

The automatic door lock/unlock function ON/OFF can be switched by performing the following operation.

1. Close all doors (door switch OFF)
2. Turn ignition switch ON
3. Press and hold the door lock and unlock switch for 5 seconds or more in the "UNLOCK" direction within 20 seconds after turning the power supply position ON.
4. The switch is complete when the hazard lamp blinks.

**OFF → ON : 2 blinks**

**ON → OFF : 1 blink**

\*: This function is set to ON before delivery.


# SYSTEM (INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

## SYSTEM (INTELLIGENT KEY SYSTEM) INTELLIGENT KEY SYSTEM

### INTELLIGENT KEY SYSTEM : System Diagram

INFOID:000000005946865



### INTELLIGENT KEY SYSTEM : System Description

INFOID:000000005946866

- The Intelligent Key system is a system that makes it possible to lock and unlock the door locks (door lock/unlock function) by carrying the Intelligent Key, which operates based on the results of electronic ID verification using two-way communication between the Intelligent Key and the vehicle (BCM).

**CAUTION:**

**The driver should always carry the Intelligent Key**

- The settings for each function can be changed with CONSULT-III.
- If an Intelligent Key is lost, a new Intelligent Key can be registered. A maximum of 4 Intelligent Keys can be registered.
- It is possible to perform a diagnosis on the system and register an Intelligent Key with CONSULT-III.

Function	Description	Refer
Door lock	Lock/unlock can be performed by pressing the request switch	<a href="#">DLK-15</a>
Trunk open	The trunk lid can be opened by carrying the Intelligent Key and pressing the trunk lid opener request switch	<a href="#">DLK-18</a>
Remote keyless entry	Lock/unlock can be performed by pressing the remote controller button of the Intelligent Key	<a href="#">DLK-19</a>


# SYSTEM (INTELLIGENT KEY SYSTEM)

## < SYSTEM DESCRIPTION >

Function	Description	Refer
Key reminder	The key reminder buzzer sounds a warning if the door is locked with the key left inside the vehicle	<a href="#">DLK-22</a>
Welcome light	When the Intelligent Key is carried, and vehicle doors are approached, the BCM illuminates interior room lamps and operates heart beat operation of the push-button ignition switch	<a href="#">DLK-23</a>
Warning	If an action that does not meet the operating condition of the Intelligent Key system is taken, the buzzer sounds to inform the driver	<a href="#">DLK-24</a>
Engine start	The engine can be turned on while carrying the Intelligent Key	<a href="#">SEC-12</a>
Interior room lamp control	Interior room lamp is controlled according to door lock/unlock state	<a href="#">INL-7</a>
Power window	Power window can be operated by Intelligent Key button operation	<a href="#">PWC-7</a>
Panic alarm	When Intelligent Key panic alarm button is pressed, horn sounds and head-lamp blinks	<a href="#">SEC-18</a>
Intelligent Key interlock	Setting of auto driving position can be automatically set, according to key ID of Intelligent Key, to the position that is registered in advance	Automatic drive positioner <a href="#">ADP-21</a>
	Setting of air conditioning system can be set, according to key ID of Intelligent Key, to the setting value that is set before turning ignition switch OFF	Air conditioning system <a href="#">HAC-25</a>
	Setting of multi AV system can be set, according to key ID of Intelligent Key, to the setting value that is set before turning ignition switch OFF	Multi AV system <a href="#">AV-150</a>

## DOOR LOCK FUNCTION

### DOOR LOCK FUNCTION : System Diagram



### DOOR LOCK FUNCTION : System Description

INFOID:000000005946868

Only when pressing the request switch, it is possible to lock and unlock the door by carrying the Intelligent Key.

### OPERATION DESCRIPTION

# SYSTEM (INTELLIGENT KEY SYSTEM)

## < SYSTEM DESCRIPTION >

- When the BCM detects that each door request switch is pressed, it starts the outside key antenna and inside key antenna corresponding to the pressed door request switch and transmits the request signal to the Intelligent Key. And then, check that the Intelligent Key is near the door.
- If the Intelligent Key is within the outside key antenna detection area, it receives the request signal and transmits the key ID signal to the BCM via remote keyless entry receiver.
- BCM receives the key ID signal and compares it with the registered key ID.
- BCM lock/unlock each door and fuel filler lid and sounds Intelligent Key buzzer warning (lock: 2 time, unlock: 1 times) at the same time as a reminder.

## OPERATION CONDITION


If the following conditions are satisfied, door lock/unlock operation is performed if the request switch is operated.

Each request switch operation	Operation condition
Lock operation	<ul style="list-style-type: none"> <li>• All doors are closed</li> <li>• P position warning is not activated</li> <li>• Panic alarm is not activated</li> <li>• Intelligent Key is outside the vehicle</li> <li>• Intelligent Key is within outside key antenna detection area *</li> </ul>
Unlock Operation	<ul style="list-style-type: none"> <li>• Panic alarm is not activated</li> <li>• Intelligent Key is outside the vehicle</li> <li>• Intelligent Key is within outside key antenna detection area *</li> </ul>

\*: Even with a registered Intelligent Key remaining inside the vehicle, door locks can be locked/unlocked from outside of the vehicle with a spare Intelligent Key as long as key IDs are different.

## OUTSIDE KEY ANTENNA DETECTION AREA

The outside key antenna detection area of door lock/unlock function is in the range of approximately 80 cm (31.50 in) surrounding the driver, passenger door handles (1). However, this operating range depends on the ambient conditions.



## SELECTIVE UNLOCK FUNCTION

### Lock Operation

When an LOCK signal is sent from door request switch (driver side or passenger side), all doors and fuel filler lid will be locked.

### Unlock Operation

- When an UNLOCK signal from driver side door request switch is transmitted, driver side door and fuel filler lid unlocks. When another UNLOCK signal is transmitted within 60 seconds, passenger side door unlock.
- When an UNLOCK signal from passenger side door request switch is transmitted, passenger side door unlock. When another UNLOCK signal is transmitted within 60 seconds, driver side door and fuel filler lid unlocks.

### How to Change Selective Unlock Operation Mode

Selective unlock operation mode can be changed using CONSULT-III.

Refer to [DLK-32. "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).

## HAZARD AND BUZZER REMINDER FUNCTION

During lock, unlock, operation by each request switch, the hazard warning lamps and Intelligent Key warning buzzer will blink or honk as a reminder.

When doors are locked, unlocked by each request switch, BCM honks Intelligent Key warning buzzer as a reminder and blinks.

Operating Function of Hazard and Buzzer Reminder



# SYSTEM (INTELLIGENT KEY SYSTEM)

## < SYSTEM DESCRIPTION >

Operation	Hazard warning lamp blinks	Intelligent Key warning buzzer honk
Unlock	Once	Once
Lock	Twice	Twice

Hazard and buzzer reminder does not operate if ignition switch ON position.

### How to Change Hazard and Buzzer Reminder Operation Mode

Hazard and buzzer reminder operation mode can be changed using CONSULT-III.

Refer to [DLK-32. "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).

### AUTO DOOR LOCK FUNCTION

After door is unlocked by door request switch operation and if 60 seconds or more passes without performing the following operation, all doors and fuel filler lid are automatically locked. However, operation check function does not activate.

Operating condition	
	<ul style="list-style-type: none"> <li>• Door switch is ON (door is open)</li> <li>• Door is locked</li> <li>• Push switch is pressed</li> </ul>

### How To Change Auto Door Lock Operation Mode

Auto door lock operation mode can be changed using CONSULT-III.

Refer to [DLK-32. "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).

### LIST OF OPERATION RELATED PARTS

Parts marked with × are the parts related to operation.

Door lock function	Intelligent Key	Remote keyless entry receiver	Door switch	Door request switch	Door lock actuator and fuel lid lock actuator	Inside key antenna	Outside key antenna	Intelligent Key warning buzzer	CAN communication system	BCM	Hazard warning lamp	Push-button ignition switch	Combination meter
Door lock/unlock function	×	×	×	×	×	×	×			×			
Hazard and buzzer reminder function								×	×	×	×		×
Selective unlock function	×			×	×	×	×			×			
Auto door lock function	×		×	×	×					×		×	

### TRUNK OPEN FUNCTION

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P


DLK

# SYSTEM (INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

## TRUNK OPEN FUNCTION : System Diagram

INFOID:000000005946869



## TRUNK OPEN FUNCTION : System Description

INFOID:000000005946870

### TRUNK LID OPENER

- When the BCM detects that trunk lid opener request switch is pressed, it activates the outside key antenna (rear bumper) and inside key antenna and transmits the request signal to the Intelligent Key. And then, checks that the Intelligent Key is near the trunk lid.
- If the Intelligent Key is within the outside key antenna detection area, it receives the request signal and transmits the key ID signal to the BCM via remote keyless entry receiver.
- BCM receives the key ID signal and compares it with the registered key ID.
- BCM transmits the trunk open request signal and sounds Intelligent Key warning buzzer 4 times at the same time (buzzer reminder). However, buzzer reminder does not operate when ignition switch is in the ON position.
- When BCM receives the trunk open request signal, it operates the trunk lid opener actuator and opens the trunk.

### OPERATION CONDITION

If the following conditions are not satisfied, trunk open operation is not performed even if the trunk lid opener request switch is operated.

Trunk lid opener request switch operation	Operation condition
Trunk open operation	<ul style="list-style-type: none"> <li>• Vehicle speed is less than 5 km/h (3 MPH)</li> <li>• Intelligent Key is within outside key antenna (rear bumper) detection area</li> <li>• Trunk lid opener cancel switch is ON</li> <li>• Trunk lid is closed</li> </ul>

### BUZZER REMINDER FUNCTION

When trunk is opened by trunk lid opener request switch, BCM honks Intelligent Key warning buzzer as a reminder.

#### Operating Function Of Buzzer Reminder

Operation	Intelligent Key warning buzzer honks
Trunk lid open	Four times

#### How to change buzzer reminder mode

🔧 With CONSULT-III


Refer to [DLK-32, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).

### OUTSIDE KEY ANTENNA DETECTION AREA

# SYSTEM (INTELLIGENT KEY SYSTEM)

## < SYSTEM DESCRIPTION >

The outside key antenna detection area of trunk open function is in the range of approximately 80 cm (31.50 in) surrounding trunk opener request switch (1). However, this operating range depends on the ambient conditions.



## LIST OF OPERATION RELATED PARTS


Parts marked with × are the parts related to operation.

Trunk open function	Intelligent Key	Remote keyless entry receiver	Trunk room lamp switch	Trunk opener request switch	Trunk lid opener actuator	Inside key antenna	Outside key antenna (rear bumper)	Intelligent Key warning buzzer	CAN communication system	BCM	Trunk lid opener cancel switch
Trunk open function	×	×	×	×	×	×	×		×	×	×
Buzzer reminder function								×	×	×	

## REMOTE KEYLESS ENTRY FUNCTION

### REMOTE KEYLESS ENTRY FUNCTION : System Diagram

INFOID:0000000005946871



### REMOTE KEYLESS ENTRY FUNCTION : System Description

INFOID:0000000005946872

The Intelligent Key has the same functions as the remote control entry system. Therefore, it can be used in the same manner as the remote controller by operating the door lock/unlock button.

#### OPERATION

Remote keyless entry system controls operation of the following items.

- Door lock/unlock function

# SYSTEM (INTELLIGENT KEY SYSTEM)

## < SYSTEM DESCRIPTION >

- Selective unlock function
- Trunk lid open function
- Hazard and horn reminder function
- Auto door lock function

### OPERATION AREA

To check that the Intelligent Key works normally, use within 1 m (3 ft) range of each doors, however the operable range may differ according to surroundings.

### DOOR LOCK/UNLOCK FUNCTION

- When door lock/unlock button of the Intelligent Key is pressed, lock signal or unlock signal transmitted from Intelligent Key to BCM via remote keyless entry receiver.
- When BCM receives the door lock/unlock signal, it operates all door lock actuators and fuel lid lock actuator the hazard lamp (lock: 2 times, unlock: 1 time) and horn chirp signal to IPDM E/R at the same time as a reminder.
- IPDM E/R honks horn (lock: 2 times) as a reminder

### OPERATION CONDITION

If the following condition are satisfied, remote keyless entry operation is performed when the Intelligent Key is operated.

Remote controller operation	Operation condition
Lock	<ul style="list-style-type: none"><li>• Panic alarm is not activated</li><li>• P position warning is not activated</li></ul>
Unlock	Panic alarm is not activated

### SELECTIVE UNLOCK FUNCTION

- When an LOCK signal is transmitted from Intelligent Key, all doors and fuel filler lid are locked.
- When an UNLOCK signal is transmitted from Intelligent Key once, driver side door and fuel filler lid are unlocked.
- Then, if an UNLOCK signal is transmitted from Intelligent Key again within 60 seconds, all other doors are unlocked.

#### How To Change Selective Unlock Operation Mode

Selective unlock operation mode can be changed using CONSULT-III.

Refer to [DLK-30. "DOOR LOCK : CONSULT-III Function \(BCM - DOOR LOCK\)".](#)

### TRUNK OPEN FUNCTION

- When trunk button of the Intelligent Key is pressed, the trunk open signal is transmitted from the Intelligent Key to the BCM via remote keyless entry receiver.
- When BCM receives the trunk open request signal, it operates the trunk lid opener actuator and opens the trunk.

### OPERATION CONDITION

Remote controller operation	Operation condition
Trunk open	<ul style="list-style-type: none"><li>• Press and hold the trunk open button for 0.4 second or more*</li><li>• Ignition switch is except the ON position</li><li>• Trunk lid opener cancel switch is ON</li><li>• Vehicle speed is less than 5 km/h (3 MPH)</li><li>• Panic alarm is not activated</li></ul>

\*: Pattern of trunk open button can be selected using CONSULT-III. Refer to [DLK-32. "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)".](#)

### HAZARD AND HORN REMINDER FUNCTION

When doors are locked or unlocked by Intelligent Key, BCM blinks hazard warning lamps as a reminder and transmits horn chirp signal to IPDM E/R. IPDM E/R sounds horn as a reminder.

The hazard and horn reminder has a horn chirp mode (C mode) and a non-horn chirp mode (S mode).

Operating Function of Hazard and Horn Reminder

# SYSTEM (INTELLIGENT KEY SYSTEM)

## < SYSTEM DESCRIPTION >

Intelligent Key operation	C mode			S mode		
	Lock	Unlock	Trunk open	Lock	Unlock	Trunk open
Hazard warning lamp blinks	Twice	Once	—	Twice	—	—
Horn sound	Once	—	—	—	—	—

Hazard and horn reminder does not operate if ignition switch ON position.


### How to change hazard and horn reminder mode

#### ☑ With CONSULT-III

Refer to [DLK-32, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).

#### ☒ Without CONSULT-III

When LOCK and UNLOCK signals are sent from the Intelligent Key for more than 2 seconds at the same time, the hazard and horn reminder mode is changed and hazard warning lamp blinks and horn sounds as per the following items:



## AUTO DOOR LOCK FUNCTION

After door is unlocked by Intelligent Key button operation and if 60 seconds or more passes without performing the following operation, all doors are locked. However, operation check function does not activate.

Operating condition	<ul style="list-style-type: none"> <li>• Door switch is ON (door is open)</li> <li>• Door is locked</li> <li>• Push switch is pressed</li> </ul>
---------------------	--

### How To Change Auto Door Lock Operation Mode

Auto door lock operation mode can be changed using CONSULT-III.

Refer to [DLK-32, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).

## LIST OF OPERATION RELATED PARTS

Parts marked with × are the parts related to operation.

Remote keyless entry functions	Intelligent Key	Door switch	Door lock actuator	Push-button ignition switch	Intelligent Key warning buzzer	CAN communication system	BCM	Combination meter	Hazard warning lamp	Horn	IPDM E/R	Trunk lid opener actuator	Trunk lid opener cancel switch	Trunk room lamp switch
Door lock/unlock function	×	×	×			×	×							
Trunk open function	×			×	×	×	×					×	×	×
Hazard and horn reminder function	×				×	×	×	×	×	×	×			
Selective unlock function	×	×	×			×	×							
Auto door lock function	×	×		×		×	×							


## KEY REMINDER FUNCTION

# SYSTEM (INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

## KEY REMINDER FUNCTION : System Diagram

INFOID:000000005946873



## KEY REMINDER FUNCTION : System Description

INFOID:000000005946874

Key reminder is the function that prevents the key from being left in the vehicle. Key reminder has the following 3 functions.

Key remainder function	Operation condition	Operation
Driver door closed*	Right after driver side door is closed under the following conditions <ul style="list-style-type: none"> <li>• Door lock operation is performed</li> <li>• Driver side door is open</li> <li>• Driver side door is in unlock state</li> </ul>	All doors and fuel filler lid unlock
Door is open or closed	Right after all doors are closed under the following conditions <ul style="list-style-type: none"> <li>• Intelligent Key is inside the vehicle</li> <li>• Any door is open</li> <li>• All doors are locked by door lock and unlock switch or door lock knob</li> </ul>	<ul style="list-style-type: none"> <li>• All doors and fuel filler lid unlock</li> <li>• Honk Intelligent Key warning buzzer</li> </ul>
Trunk is closed	Right after trunk is closed under the following conditions <ul style="list-style-type: none"> <li>• Intelligent Key is inside trunk room</li> <li>• All doors are closed</li> <li>• All doors are locked</li> </ul>	<ul style="list-style-type: none"> <li>• Trunk open</li> <li>• Honk Intelligent Key warning buzzer</li> </ul>

\*:If the door closing impact shocks the door lock knob, or contacts against baggage with the door lock knob might activate the door locks accidentally but unlock operation is perform in these cases.

### CAUTION:

- The above function operates when the Intelligent Key is inside the vehicle. However, there may be times when the Intelligent Key cannot be detected, and this function does not operate when the Intelligent Key is on the instrument panel, rear parcel shelf, or in the glove box. Also, this system sometimes does not operate if the Intelligent Key is in the door pocket for the open door.


## WELCOME LIGHT FUNCTION

# SYSTEM (INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

## WELCOME LIGHT FUNCTION : System Diagram

INFOID:000000005982471



## WELCOME LIGHT FUNCTION : System Description

INFOID:000000005982472

The welcome light function operates as per the following. When the Intelligent Key is carried, and vehicle doors are approached, the BCM illuminates interior room lamp\* and operates heart beat operation of the push-button ignition switch.

\*: Settings for map lamp, foot lamp, personal lamp, and outside handle lamp are available.

### OPERATION DESCRIPTION

- When the BCM detects that the Intelligent Key is within the outside key antenna detection area. BCM transmits the request signal to the Intelligent Key and check it is near the door.
- Intelligent Key receives the request signal and transmits the key ID signal to the BCM via remote keyless receiver.
- BCM receives the key ID signal and compares it with the registered key ID.
- BCM illuminates lamps that are set, when key ID verification is OK.

### TIMER FUNCTION

BCM can operate welcome light function, using the timer function, for 9 days, after key switch is turned OFF. The timer function resets when the engine is started\*. Operating period of timer function may differ depending on battery size.

\*: Timer function does not stop if another Intelligent Key that has a different key ID is detected within the interior antenna detection area, when starting the engine.

### OPERATION CONDITION

If the following condition are satisfied, welcome light function is operated.

Function	Operation condition
Welcome light function	<ul style="list-style-type: none"> <li>• All door are closed</li> <li>• All doors is locked</li> <li>• Ignition switch: OFF position</li> <li>• Shift position: P position</li> <li>• Intelligent Key is outside the vehicle</li> <li>• Timer function is activated</li> </ul>

## OUTSIDE KEY ANTENNA DETECTION AREA


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

DLK

# SYSTEM (INTELLIGENT KEY SYSTEM)

## < SYSTEM DESCRIPTION >

The outside key antenna detection area of door lock/unlock function is in the range of approximately 80 cm (31.50 in) surrounding the driver, passenger door handles (1) and back door handle (2). However, this operating range depends on the ambient conditions.



## WELCOME LIGHT FUNCTION SETTING

Welcome light function operation mode can be changed using CONSULT-III

Ⓟ With CONSULT-III

Refer to [DLK-32, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).

ⓧ Without CONSULT-III

The welcome light function ON/OFF can be switched by performing the following operation.

1. Turn ignition switch: OFF→ON
2. Press and hold the driver side door request switch for 5 seconds or more within 20 seconds after turning the ignition switch ON.
3. The switching is complete when combination meter buzzer sounds.

## WARNING FUNCTION

### WARNING FUNCTION : System Description

INFOID:000000005946875

### OPERATION DESCRIPTION

The warning function are as per the following items and are given to the user as warning information and warnings using combinations of Intelligent Key warning buzzer, combination meter buzzer and information display in combination meter.

- Intelligent Key system malfunction
- OFF position warning
- P position warning
- ACC warning
- Take away warning
- Door lock operation warning
- Engine start information
- Steering lock information
- Intelligent Key low battery warning
- Key ID warning
- Key ID verification information

### OPERATION CONDITION

Once the following condition from below is established, alert or warning is executed.

Warning/Information functions		Operation procedure
Intelligent Key system malfunction		When a malfunction is detected on BCM
OFF position warning	For internal	<ul style="list-style-type: none"> <li>• Ignition switch: ACC position</li> <li>• Door switch (driver side): ON (Door is open)</li> </ul>
	For external	OFF position warning (For internal) is in active mode, driver side door is closed <b>NOTE:</b> OFF position (For external) active only when each of the sequence occurs as below: P position warning → ACC warning → OFF position warning (For internal)
P position warning	For internal	<ul style="list-style-type: none"> <li>• Shift position: Except P position</li> <li>• Engine is running to stopped (Ignition switch is ON to OFF)</li> </ul>
	For external	Warning is activated when driver door is closed from the open position while the P position warning (for inside vehicle) is ON





# SYSTEM (INTELLIGENT KEY SYSTEM)

## < SYSTEM DESCRIPTION >

Warning/Information functions		Operation procedure
ACC warning		<ul style="list-style-type: none"> <li>When P position warning is in active mode, shift position changes P position.</li> <li>Ignition switch: ACC position</li> </ul>
Take away warning	Door is open to close	<ul style="list-style-type: none"> <li>Ignition switch: Except LOCK position</li> <li>Door switch: ON to OFF (Door is open to close)</li> <li>Intelligent Key cannot be detected inside the vehicle</li> </ul>
	Door is open	<ul style="list-style-type: none"> <li>Door switch: ON (Door is open)</li> <li>Key ID verification every 5 seconds when registered Intelligent Key cannot be detected inside the vehicle</li> </ul>
	Push button-ignition switch operation	<ul style="list-style-type: none"> <li>Ignition switch: Except LOCK position</li> <li>Press push-button ignition switch</li> <li>Intelligent Key cannot be detected inside the vehicle</li> </ul>
Door lock operation warning		When door lock operation is requested while door lock operating condition of door request switch or Intelligent Key are not satisfied
Engine start information	Ignition switch is ON position	<ul style="list-style-type: none"> <li>Ignition switch: ON position</li> <li>Shift position: P position</li> <li>Engine is stopped</li> </ul>
	Ignition switch is except ON position	<ul style="list-style-type: none"> <li>Ignition switch: Except ON position</li> <li>Shift position: P position</li> <li>Intelligent Key is inserted in key slot or Intelligent Key can be detected inside the vehicle</li> </ul>
Steering lock information		When steering lock cannot be released after ignition switch is turned ON
Intelligent Key low battery warning		When Intelligent Key is low battery, BCM is detected after ignition switch is turned ON
Key ID warning		When registered intelligent Key cannot be detected inside the vehicle after ignition switch is turned ON
Key ID verification information		<ul style="list-style-type: none"> <li>When registered Intelligent Key cannot be detected inside the vehicle</li> <li>Intelligent Key battery is discharged</li> <li>When NATS antenna amp cannot be detected NATS ID</li> </ul>






## WARNING METHOD

The following table shows the alarm or warning methods with chime.  
Information display (combination meter) when the warning conditions are met.

Warning/Information functions	Information display (combination meter)	Warning chime	
		Combination meter buzzer	Intelligent Key warning buzzer
Intelligent Key system malfunction	 <small>JMKIA5402ZZ</small>	—	—
OFF position warning	For internal	—	Activate
	For external	—	Activate
P position warning	For internal	Activate	—
	For external	 <small>JMKIA0037GB</small>	Active



# SYSTEM (INTELLIGENT KEY SYSTEM)

## < SYSTEM DESCRIPTION >

Warning/Information functions		Information display (combination meter)	Warning chime	
			Combination meter buzzer	Intelligent Key warning buzzer
ACC warning		 <small>JMKIA0047GB</small>	—	—
Take away warning	Door is open to close	 <small>JMKIA4906ZZ</small>	Activate	Activate
	Door is open		—	—
	Push-ignition switch operation		Activate	—
Door lock operation warning	Request switch operation	—	—	Activate
	Intelligent Key operation	—	—	Activate
Key ID warning		 <small>JMKIA4906ZZ</small>	—	—
Engine start information		 <small>JMKIA0032GB</small>	—	—
Steering lock information		 <small>JMKIA0033GB</small>	—	—

# SYSTEM (INTELLIGENT KEY SYSTEM)

## < SYSTEM DESCRIPTION >

Warning/Information functions	Information display (combination meter)	Warning chime	
		Combination meter buzzer	Intelligent Key warning buzzer
Intelligent Key low battery warning	 <small>JMKIA3049ZZ</small>	—	—
Key ID verification information	 <small>JMKIA4907ZZ</small>	—	—

## LIST OF OPERATION RELATED PARTS

Parts marked with × are the parts related to operation.

Warning function		Intelligent Key	Ignition switch	Door switch	Door request switch	Inside key antenna	Outside key antenna	Intelligent Key warning buzzer	Combination meter buzzer	CAN communication system	BCM	Information display
Intelligent Key system malfunction										×	×	×
OFF position warning	For internal			×					×	×	×	
	For external			×				×			×	
P position warning			×						×	×	×	×
ACC warning			×						×	×	×	×
Take away warning	Door is open or close	×		×		×		×	×	×	×	×
	Door is open	×		×		×				×	×	×
	Push-button ignition switch operation	×	×			×			×	×	×	×
Door lock operation warning		×		×	×	×	×	×			×	
Key ID warning			×			×				×	×	×
Engine start information	Ignition switch is ON position	×	×			×				×	×	×
	Ignition switch is except ON position	×	×			×				×	×	×
Steering lock information			×							×	×	×
Intelligent Key low battery warning		×				×				×	×	×
Key ID verification information		×				×				×	×	×

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

DLK


# SYSTEM (TRUNK LID OPENER SYSTEM)

< SYSTEM DESCRIPTION >

## SYSTEM (TRUNK LID OPENER SYSTEM)

### System Diagram

INFOID:000000005946876



### System Description

INFOID:000000005946877

#### TRUNK LID OPENER OPERATION

When trunk lid opener switch is ON, BCM operates trunk lid opener actuator.

#### OPERATION CONDITION

If the following conditions are satisfied, trunk open operation is performed.

Trunk lid opener switch operation	Operation condition
Trunk lid open	<ul style="list-style-type: none"> <li>• Trunk lid opener cancel switch is ON</li> <li>• Vehicle speed is less than 5 km/h (3 MPH)</li> </ul>

# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (BCM)

### COMMON ITEM

### COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM)

INFOID:000000005946878

### APPLICATION ITEM

CONSULT-III performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
Work Support	Changes the setting for each system function.
Self Diagnostic Result	Displays the diagnosis results judged by BCM.
CAN Diag Support Monitor	Monitors the reception status of CAN communication viewed from BCM. Refer to CONSULT-III operation manual.
Data Monitor	The BCM input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from BCM.
Ecu Identification	The BCM part number is displayed.
Configuration	This function is not used even though it is displayed.

### SYSTEM APPLICATION

BCM can perform the following functions for each system.

#### NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

×: Applicable item

System	Sub system selection item	Diagnosis mode		
		Work Support	Data Monitor	Active Test
Door lock	DOOR LOCK	×	×	×
Rear window defogger	REAR DEFOGGER		×	×
Warning chime	BUZZER		×	×
Interior room lamp timer	INT LAMP	×	×	×
Exterior lamp	HEAD LAMP	×	×	×
Wiper and washer	WIPER	×	×	×
Turn signal and hazard warning lamps	FLASHER	×	×	×
—	AIR CONDITONER*			
• Intelligent Key system • Engine start system	INTELLIGENT KEY	×	×	×
Combination switch	COMB SW		×	
Body control system	BCM	×		
IVIS - NATS	IMMU		×	×
Interior room lamp battery saver	BATTERY SAVER	×	×	×
Trunk lid open	TRUNK		×	×
Vehicle security system	THEFT ALM	×	×	×
RAP system	RETAINED PWR		×	
Signal buffer system	SIGNAL BUFFER		×	×
TPMS	TPMS (AIR PRESSURE MONITOR)	×	×	×

#### NOTE:

\*: This item is displayed, but is not used.

### FREEZE FRAME DATA (FFD)

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays on CONSULT-III.

# DIAGNOSIS SYSTEM (BCM)

## < SYSTEM DESCRIPTION >

CONSULT screen item	Indication/Unit	Description	
Vehicle Speed	km/h	Vehicle speed of the moment a particular DTC is detected	
Odo/Trip Meter	km	Total mileage (Odometer value) of the moment a particular DTC is detected	
Vehicle Condition	SLEEP>LOCK	Power position status of the moment a particular DTC is detected	While turning BCM status from low power consumption mode to normal mode (Power supply position is "LOCK")
	SLEEP>OFF		While turning BCM status from low power consumption mode to normal mode (Power supply position is "OFF".)
	LOCK>ACC		While turning power supply position from "LOCK" to "ACC"
	ACC>ON		While turning power supply position from "ACC" to "IGN"
	RUN>ACC		While turning power supply position from "RUN" to "ACC" (Vehicle is stopping and selector lever is except P position.)
	CRANK>RUN		While turning power supply position from "CRANKING" to "RUN" (From cranking up the engine to run it)
	RUN>URGENT		While turning power supply position from "RUN" to "ACC" (Emergency stop operation)
	ACC>OFF		While turning power supply position from "ACC" to "OFF"
	OFF>LOCK		While turning power supply position from "OFF" to "LOCK"
	OFF>ACC		While turning power supply position from "OFF" to "ACC"
	ON>CRANK		While turning power supply position from "IGN" to "CRANKING"
	OFF>SLEEP		While turning BCM status from normal mode (Power supply position is "OFF".) to low power consumption mode
	LOCK>SLEEP		While turning BCM status from normal mode (Power supply position is "LOCK".) to low power consumption mode
	LOCK		Power supply position is "LOCK" (Ignition switch OFF with steering is locked.)
	OFF		Power supply position is "OFF" (Ignition switch OFF with steering is unlocked.)
	ACC		Power supply position is "ACC" (Ignition switch ACC)
	ON		Power supply position is "IGN" (Ignition switch ON with engine stopped)
	ENGINE RUN		Power supply position is "RUN" (Ignition switch ON with engine running)
CRANKING	Power supply position is "CRANKING" (At engine cranking)		
IGN Counter	0 - 39	<p>The number of times that ignition switch is turned ON after DTC is detected</p> <ul style="list-style-type: none"> <li>• The number is 0 when a malfunction is detected now.</li> <li>• The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON.</li> <li>• The number is fixed to 39 until the self-diagnosis results are erased if it is over 39.</li> </ul>	

## DOOR LOCK

### DOOR LOCK : CONSULT-III Function (BCM - DOOR LOCK)

INFOID:000000006062137

#### BCM CONSULT-III FUNCTION

CONSULT-III performs the following functions via CAN communication with BCM.

#### WORK SUPPORT

# DIAGNOSIS SYSTEM (BCM)

## < SYSTEM DESCRIPTION >

Monitor item	Description
DOOR LOCK-UNLOCK SET	Selective unlock function mode can be changed to operation with this mode <ul style="list-style-type: none"> <li>• On: Operate</li> <li>• Off: Non-operation</li> </ul>
AUTOMATIC DOOR LOCK SELECT	Automatic door lock function mode can be selected from the following in this mode <ul style="list-style-type: none"> <li>• VH SPD: All doors are locked when vehicle speed more than 24 km/h (15MPH)</li> <li>• P RANGE: All doors are locked when shifting the selector lever from P position to other than the P position</li> </ul>
AUTOMATIC DOOR UNLOCK SELECT	Automatic door unlock function mode can be selected from the following in the mode <ul style="list-style-type: none"> <li>• MODE 1: All doors are unlocked when the power supply position is changed from ON to OFF</li> <li>• MODE 2: All doors are unlocked when shifting the selector lever from any position other than the P to P position</li> <li>• MODE 3: Driver side door is unlocked when the power supply position is changed from ON to OFF</li> <li>• MODE 4: Driver side door is unlocked when shifting the selector lever from any position other than the P to P position</li> <li>• MODE 5: This item is displayed, but cannot be used</li> <li>• MODE 6: This item is displayed, but cannot be used</li> </ul>
AUTOMATIC LOCK/UNLOCK SET	Automatic door lock/unlock function mode can be selected from the following in this mode <ul style="list-style-type: none"> <li>• Off: Non-operational</li> <li>• Unlock Only: Door unlock operation only</li> <li>• Lock Only: Door lock operation only</li> <li>• Lock/Unlock: Lock and unlock operation</li> </ul>

## DATA MONITOR

Monitor Item	Contents
REQ SW-DR	Indicated [On/Off] condition of door request switch (driver side)
REQ SW-AS	Indicated [On/Off] condition of door request switch (passenger side)
REQ SW-BD/TR	Indicated [On/Off] condition of trunk lid opener request switch
DOOR SW-DR	Indicated [On/Off] condition of front door switch (driver side)
DOOR SW-AS	Indicated [On/Off] condition of front door switch (passenger side)
DOOR SW-RR	Indicated [On/Off] condition of rear door switch RH
DOOR SW-RL	Indicated [On/Off] condition of rear door switch LH
DOOR SW-BK	<b>NOTE:</b> This item is displayed, but cannot be monitored
CDL LOCK SW	Indicated [On/Off] condition of lock signal from door lock unlock switch
CDL UNLOCK SW	Indicated [On/Off] condition of unlock signal from door lock unlock switch
KEY CYL LK-SW	Indicated [On/Off] condition of lock signal from door key cylinder switch
KEY CYL UN-SW	Indicated [On/Off] condition of unlock signal from door key cylinder switch

## ACTIVE TEST

Test item	Description
DOOR LOCK	This test is able to check door lock/unlock operation <ul style="list-style-type: none"> <li>• The all door lock actuators are locked when "ALL LOCK" on CONSULT-III screen is touched</li> <li>• The all door lock actuators are unlocked when "ALL UNLK" on CONSULT-III screen is touched</li> <li>• The front door lock actuator (driver side) is unlocked when "DR UNLK" on CONSULT-III screen is touched</li> <li>• The front door lock actuator (passenger side) is unlocked when "AS UNLK" on CONSULT- III screen is touched</li> <li>• The door lock actuator (other) is unlocked when "OTR ULK" on CONSULT-III screen is touched</li> </ul>

## INTELLIGENT KEY

## DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

**INTELLIGENT KEY : CONSULT-III Function (BCM - INTELLIGENT KEY)** INFOID:000000006062138

### WORK SUPPORT

Monitor item	Description
INSIDE ANT DIAGNOSIS	This function allows inside key antenna self-diagnosis
LOCK/UNLOCK BY I-KEY	Door lock/unlock function by door request switch mode can be changed to operation in this mode <ul style="list-style-type: none"> <li>• On: Operate</li> <li>• Off: Non-operation</li> </ul>
ENGINE START BY I-KEY	Engine start function mode can be changed to operation with this mode <ul style="list-style-type: none"> <li>• On: Operate</li> <li>• Off: Non-operation</li> </ul>
TRUNK/GLASS HATCH OPEN	Buzzer reminder function mode by trunk lid opener request switch and Intelligent Key can be changed to operation with this mode <ul style="list-style-type: none"> <li>• On: Operate</li> <li>• Off: Non-operation</li> </ul>
PANIC ALARM SET	Panic alarm button pressing time on Intelligent Key remote control button can be selected from the following with this mode <ul style="list-style-type: none"> <li>• MODE 1: 0.5 sec</li> <li>• MODE 2: Non-operation</li> <li>• MODE 3: 1.5 sec</li> </ul>
TRUNK OPEN DELAY	Trunk button pressing on Intelligent Key can be selected as per the following in this mode. <ul style="list-style-type: none"> <li>• MODE 1: Press and hold</li> <li>• MODE 2: Press twice</li> <li>• MODE 3: Press and hold, or press twice</li> </ul>
LO- BATT OF KEY FOB WARN	Intelligent Key low battery warning mode can be changed to operation with this mode <ul style="list-style-type: none"> <li>• On: Operate</li> <li>• Off: Non-operation</li> </ul>
ANTI KEY LOCK IN FUNCTI	Key reminder function mode can be changed to operation with this mode <ul style="list-style-type: none"> <li>• On: Operate</li> <li>• Off: Non-operation</li> </ul>
HAZARD ANSWER BACK	Hazard reminder function mode by door request switch and Intelligent Key button can be selected from the following with this mode <ul style="list-style-type: none"> <li>• Lock Only: Door lock operation only</li> <li>• Unlock Only: Door unlock operation only</li> <li>• Lock/Unlock: Lock and unlock operation</li> <li>• Off: Non-operation</li> </ul>
ANS BACK I-KEY LOCK	Buzzer reminder function (lock operation) mode by door request switch can be selected from the following with this mode <ul style="list-style-type: none"> <li>• Horn Chirp: Sound horn</li> <li>• Buzzer: Sound Intelligent Key warning buzzer</li> <li>• Off: Non-operation</li> </ul>
ANS BACK I-KEY UNLOCK	Buzzer reminder function (unlock operation) mode by door request switch can be changed to operation with this mode <ul style="list-style-type: none"> <li>• On: Operate</li> <li>• Off: Non-operation</li> </ul>
SHORT CRANKING OUTPUT	Starter motor can operate during the times below <ul style="list-style-type: none"> <li>• 70 msec</li> <li>• 100 msec</li> <li>• 200 msec</li> </ul>
CONFIRM KEY FOB ID	It can be checked whether Intelligent Key ID code is registered or not in this mode



# DIAGNOSIS SYSTEM (BCM)

## < SYSTEM DESCRIPTION >

Monitor item	Description
AUTO LOCK SET	Auto door lock operation time can be changed in this mode <ul style="list-style-type: none"> <li>• MODE 1: OFF</li> <li>• MODE 2: 30 sec</li> <li>• MODE 3: 1 minute</li> <li>• MODE 4: 2 minutes</li> <li>• MODE 5: 3 minutes</li> <li>• MODE 6: 4 minutes</li> <li>• MODE 7: 5 minutes</li> </ul>
HORN WITH KEYLESS LOCK	Horn reminder function mode by Intelligent Key button can be selected from the following with this mode <ul style="list-style-type: none"> <li>• On: Operate</li> <li>• Off: Non-operation</li> </ul>
PW DOWN SET	Unlock button pressing time on Intelligent Key button can be selected from the following with this mode <ul style="list-style-type: none"> <li>• MODE 1: 3 sec</li> <li>• MODE 2: Non-operation</li> <li>• MODE 3: 5 sec</li> </ul>
WELCOME LIGHT SELECT	Welcome light function mode can be selected from the following with this mode <ul style="list-style-type: none"> <li>• Puddle/Outside Handle</li> <li>• Room lamp</li> <li>• Head &amp; Tail Lamps (this item is displayed, but cannot be used)</li> <li>• Heart Beat</li> </ul>
WELCOME LIGHT OP SET	Welcome light function mode can be changed to operation with this mode <ul style="list-style-type: none"> <li>• On: Operate</li> <li>• Off: Non-operation</li> </ul>
INTELLIGENT KEY SETUP	Intelligent Key interlock function mode can be changed to operation with this mode <ul style="list-style-type: none"> <li>• On: Operate</li> <li>• Off: Non-operation</li> </ul>

## SELF-DIAG RESULT

Refer to [BCS-55, "DTC Index"](#).

## DATA MONITOR

Monitor Item	Condition
REQ SW -DR	Indicates [On/Off] condition of door request switch (driver side)
REQ SW -AS	Indicates [On/Off] condition of door request switch (passenger side)
REQ SW -BD/TR	Indicates [On/Off] condition of trunk lid opener request switch
PUSH SW	Indicates [On/Off] condition of push-button ignition switch
CLUTCH SW	<b>NOTE:</b> This item is displayed, but cannot be monitored
BRAKE SW 1	Indicates [On/Off]* condition of stop lamp switch power supply
BRAKE SW 2	Indicates [On/Off] condition of stop lamp switch
DETE/CANCL SW	Indicates [On/Off] condition of P position
SFT PN/N SW	Indicates [On/Off] condition of P or N position
S/L -LOCK	Indicates [On/Off] condition of steering lock unit (LOCK)
S/L -UNLOCK	Indicates [On/Off] condition of steering lock unit (UNLOCK)
S/L RELAY -F/B	Indicates [On/Off] condition of steering lock relay
UNLK SEN -DR	Indicates [On/Off] condition of driver door UNLOCK status
PUSH SW -IPDM	Indicates [On/Off] condition of push-button ignition switch
IGN RLY1 -F/B	Indicates [On/Off] condition of ignition relay 1
DETE SW -IPDM	Indicates [On/Off] condition of P position
SFT PN -IPDM	Indicates [On/Off] condition of P or N position
SFT P -MET	Indicates [On/Off] condition of P position

A  
B  
C  
D  
E  
F  
G  
H  
I  
J

DLK

L  
M  
N  
O  
P

## DIAGNOSIS SYSTEM (BCM)

### < SYSTEM DESCRIPTION >

Monitor Item	Condition
SFT N -MET	Indicates [On/Off] condition of N position
ENGINE STATE	Indicates [Stop/Stall/Crank/Run] condition of engine states
S/L LOCK-IPDM	Indicates [On/Off] condition of steering lock unit (LOCK)
S/L UNLK-IPDM	Indicates [On/Off] condition of steering lock unit (UNLOCK)
S/L RELAY-REQ	Indicates [On/Off] condition of steering lock relay
VEH SPEED 1	Display the vehicle speed signal received from combination meter by numerical value [Km/h]
VEH SPEED 2	Display the vehicle speed signal received from ABS or VDC or TCM by numerical value [Km/h]
DOOR STAT-DR	Indicates [LOCK/READY/UNLK] condition of driver side door status
DOOR STAT-AS	Indicates [LOCK/READY/UNLK] condition of passenger side door status
ID OK FLAG	Indicates [Set/Reset] condition of key ID
PRMT ENG STRT	Indicates [Set/Reset] condition of engine start possibility
PRMT RKE STRT	<b>NOTE:</b> This item is displayed, but cannot be monitored
TRNK/HAT MNTR	Indicates [On/Off] condition of trunk room lamp switch
RKE-LOCK	Indicates [On/Off] condition of LOCK signal from Intelligent Key
RKE-UNLOCK	Indicates [On/Off] condition of UNLOCK signal from Intelligent Key
RKE-TR/BD	Indicates [On/Off] condition of trunk open signal from Intelligent Key
RKE-PANIC	Indicates [On/Off] condition of panic alarm button of Intelligent Key
RKE-MODE CHG	Indicates [On/Off] condition of MODE CHANGE signal from Intelligent Key
RKE OPE COUN1	When remote keyless entry receiver receives the signal transmitted while operating on Intelligent Key, the numerical value start changing
RKE OPE COUN2	<b>NOTE:</b> This item is displayed, but cannot be monitored

\*: OFF is displayed when brake pedal is depressed while brake switch power supply is OFF.

### ACTIVE TEST

Test item	Description
BATTERY SAVER	This test is able to check interior room lamp operation <ul style="list-style-type: none"> <li>• On: Operate</li> <li>• Off: Non-operation</li> </ul>
OUTSIDE BUZZER	This test is able to check Intelligent Key warning buzzer operation <ul style="list-style-type: none"> <li>• On: Operate</li> <li>• Off: Non-operation</li> </ul>
INSIDE BUZZER	This test is able to check warning chime in combination meter operation <ul style="list-style-type: none"> <li>• Take Out: Take away warning chime sounds when CONSULT-III screen is touched</li> <li>• Key: Key warning chime sounds when CONSULT-III screen is touched</li> <li>• Knob: OFF position warning chime sounds when CONSULT-III screen is touched</li> <li>• Off: Non-operation</li> </ul>
INDICATOR	This test is able to check warning lamp operation <ul style="list-style-type: none"> <li>• KEY ON: "KEY" Warning lamp illuminates when CONSULT-III screen is touched</li> <li>• KEY IND: "KEY" Warning lamp blinks when CONSULT-III screen is touched</li> <li>• Off: Non-operation</li> </ul>
INT LAMP	This test is able to check interior room lamp operation <ul style="list-style-type: none"> <li>• On: Operate</li> <li>• Off: Non-operation</li> </ul>

# DIAGNOSIS SYSTEM (BCM)

## < SYSTEM DESCRIPTION >

Test item	Description	
LCD	This test is able to check meter display information <ul style="list-style-type: none"> <li>• Engine start information displays when "BP N" on CONSULT-III screen is touched</li> <li>• Engine start information displays when "BP I" on CONSULT-III screen is touched</li> <li>• Key ID warning displays when "ID NG" on CONSULT-III screen is touched</li> <li>• Steering lock information displays when "ROTAT" on CONSULT-III screen is touched</li> <li>• P position warning displays when "SFT P" on CONSULT-III screen is touched</li> <li>• INSRT: This item is displayed, but cannot be monitored</li> <li>• BATT: This item is displayed, but cannot be monitored</li> <li>• Take away through window warning displays when "NO KY" on CONSULT-III screen is touched</li> <li>• Take away warning display when "OUTKEY" on CONSULT-III screen is touched</li> <li>• OFF position warning display when "LK WN" on CONSULT-III screen is touched</li> </ul>	A B C D
FLASHER	This test is able to check hazard warning lamp operation The hazard warning lamps are activated after "LH/RH/Off" on CONSULT-III screen is touched	E
P RANGE	This test is able to check AT shift selector power supply <ul style="list-style-type: none"> <li>• On: Operate</li> <li>• Off: Non-operation</li> </ul>	F
ENGINE SW ILLUMI	This test is able to check push-ignition switch illumination operation Push-ignition switch illumination illuminates when "ON" on CONSULT-III screen is touched	G
LOCK INDICATOR	This test is able to check LOCK indicator (push-button ignition switch) operation <ul style="list-style-type: none"> <li>• On: Operate</li> <li>• Off: Non-operation</li> </ul>	H
ACC INDICATOR	This test is able to check ACC indicator (push-button ignition switch) operation <ul style="list-style-type: none"> <li>• On: Operate</li> <li>• Off: Non-operation</li> </ul>	I
IGNITION ON IND	This test is able to check ON indicator (push-button ignition switch) operation <ul style="list-style-type: none"> <li>• On: Operate</li> <li>• Off: Non-operation</li> </ul>	J
HORN	This test is able to check horn operation <ul style="list-style-type: none"> <li>• On: Operate</li> <li>• Off: Non-operation</li> </ul>	DLK
TRUNK/BACK DOOR	This test is able to check trunk lid open operation <ul style="list-style-type: none"> <li>• Open: Operate</li> </ul>	L
INTELLIGENT KEY LINK	This test is able to check Intelligent Key interlock function <ul style="list-style-type: none"> <li>• ID No1: BCM transmits Intelligent Key ID No1 to each control unit</li> <li>• ID No2: BCM transmits Intelligent Key ID No2 to each control unit</li> </ul>	M
INTELLIGENT KEY LINK (CAN)	This test is able to check Intelligent Key interlock function <ul style="list-style-type: none"> <li>• Off: Non-operation</li> <li>• ID No1: BCM transmits Intelligent Key ID No1 to each control unit via CAN communication line</li> <li>• ID No2: BCM transmits Intelligent Key ID No2 to each control unit via CAN communication line</li> <li>• ID No3: BCM transmits Intelligent Key ID No3 to each control unit via CAN communication line</li> <li>• ID No4: BCM transmits Intelligent Key ID No4 to each control unit via CAN communication line</li> <li>• ID No5: This item is displayed, but cannot be used</li> </ul>	N

## TRUNK

### TRUNK : CONSULT-III Function (BCM - TRUNK)

INFOID:0000000006062139

## DATA MONITOR

Monitor Item	Contents
PUSH SW	Indicates [On/Off] condition of push switch
UNLK SEN -DR	Indicates [On/Off] condition of unlock sensor
VEH SPEED 1	Indicates [Km/h] condition of vehicle speed signal from combination meter

## DIAGNOSIS SYSTEM (BCM)

### < SYSTEM DESCRIPTION >

Monitor Item	Contents
KEY CYL SW-TR	Indicates [On/Off] condition of trunk key cylinder switch
TR CANCEL SW	Indicates [On/Off] condition of trunk lid opener cancel switch
TR/BD OPEN SW	Indicates [Km/h] condition of trunk lid opener switch
TRNK/HAT MNTR	Indicates [On/Off] condition of trunk room lamp switch
RKE-TR/BD	Indicates [On/Off] condition of trunk open signal from Intelligent Key

# BCM

< ECU DIAGNOSIS INFORMATION >

## ECU DIAGNOSIS INFORMATION

BCM

List of ECU Reference

INFOID:000000005946882

ECU	Reference
BCM	<a href="#">BCS-32, "Reference Value"</a>
	<a href="#">BCS-52, "Fail-safe"</a>
	<a href="#">BCS-54, "DTC Inspection Priority Chart"</a>
	<a href="#">BCS-55, "DTC Index"</a>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DLK  
L  
M  
N  
O  
P

DLK

# DOOR & LOCK SYSTEM


< WIRING DIAGRAM >

## WIRING DIAGRAM

### DOOR & LOCK SYSTEM

#### Wiring Diagram - DOOR & LOCK SYSTEM -

INFOID:000000006136310



\*: This connector is not shown in "Harness Layout".


2010/02/03

JCKWA3221GB

# DOOR & LOCK SYSTEM

< WIRING DIAGRAM >

(NV) : With NAVI



\*: This connector is not shown in "Harness Layout".


JCKWA3222GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

DLK

# DOOR & LOCK SYSTEM


< WIRING DIAGRAM >





# DOOR & LOCK SYSTEM

< WIRING DIAGRAM >




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DLK  
L  
M  
N  
O  
P

# DOOR & LOCK SYSTEM

< WIRING DIAGRAM >

## DOOR LOCK SYSTEM


Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH03PW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	W	-
4	LG	-
5	P	-
6	V	-
7	GR	-
8	Y	-
9	LG	-
10	V	-
11	GR	- [With Climate controlled seat]
11	L	- [With heated seat]
12	P	- [With Climate controlled seat]
12	GR	- [With heated seat]
13	BR	-
14	R	-
15	O	-
16	V	-
17	B	-
18	R	-
19	W	-
20	R	-
21	B	-
22	LG	-
23	V	-
24	Y	-
25	G	-
26	GR	-
27	SB	-
28	P	- [With Pre-crash seat belt system]
28	L/O	- [Without Pre-crash seat belt system]
29	L	- [With Pre-crash seat belt system]
29	W/L	- [Without Pre-crash seat belt system]
30	SHIELD	-
32	L	-
33	R	-
34	L	-
35	R	-
36	G	-

37	SB	-
40	SHIELD	-
41	GR/V	-
42	W/L	-
45	W	-
47	O	-
48	V	-
49	BR	-
50	SB	-
51	V	-
52	LG	-
53	G	-
56	P	-
57	BR	-
58	LG	-
59	Y	-
60	W	-
61	B	-
62	LG	-
63	BR	- [With ICC and 4WAS system]
63	V	- [Without ICC and 4WAS system]
65	O	-
66	BR	-
67	V	-
68	LG	-
69	GR	-
70	R	-
72	L	-
73	P	-
74	L	-
75	P	-
76	Y	-
77	R	-
78	W	-
79	G	-
81	LG	-
82	BR	-
83	SB	-
84	Y	-
85	W	-
86	R	-
87	G	-
88	GR	-
91	SB	-
92	G	-
96	Y	-
97	O	-
98	SB	-
99	LG	-

Connector No.	B4
Connector Name	WIRE TO WIRE
Connector Type	TH40MM-CS15



Terminal No.	Color of Wire	Signal Name [Specification]
5	B/W	-
6	L	-
7	R	-
8	B	-
9	W	-
10	LG	-
11	P	-
12	GR	-
13	B/W	-
14	SB	-
15	O	-
16	G	-
17	Y	-
18	BR	-
19	GR	-
20	O	-
21	LG	-
22	L	-
23	SB	-
24	V	-
27	V	-
28	W	-
29	SB	-
30	L	-
31	LG	-
32	O	-
33	V	-
34	BR	-
35	B/R	-
36	P	-
37	BR	-
38	W	-
39	O	-
40	L	-
41	SHIELD	-
42	L	- [With Pre-crash seat belt system]
42	W/L	- [Without Pre-crash seat belt system]
43	P	- [With Pre-crash seat belt system]

43	L/O	- [Without Pre-crash seat belt system]
44	R	-
45	Y	-
46	V	-
47	SB	-
48	GR	-
49	LG	-
50	B	-
51	G	-
52	R	-
53	B	-
54	V	-
55	W	-

Connector No.	B16
Connector Name	FRONT DOOR SWITCH LH
Connector Type	A03FW



Terminal No.	Color of Wire	Signal Name [Specification]
2	LG	-


JCKWA3225GB

# DOOR & LOCK SYSTEM

< WIRING DIAGRAM >

## DOOR LOCK SYSTEM

Connector No.	B18
Connector Name	WIRE TO WIRE
Connector Type	INHUPW-CS10




Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	-
2	P	-
3	R	-
4	G	-
5	B/W	-
6	W	-
7	B/W	-
8	W	-
9	V	-
10	Y	-
11	L	-
12	Y	-
13	B	-

Connector No.	B23
Connector Name	REAR DOOR SWITCH LH
Connector Type	A05FW



Terminal No.	Color of Wire	Signal Name [Specification]
2	BR	-

Connector No.	B40
Connector Name	WIRE TO WIRE
Connector Type	RS18MW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	P	-
2	O	-
3	LG	-
4	L	-
5	B/W	-
6	SHIELD	-
7	W	-
8	R	-
9	G	-
10	Y	-
11	BR	-
12	SHIELD	-
13	LG	-
14	V	-
15	P	-
16	W	-

Connector No.	B49
Connector Name	INSIDE KEY ANTENNA (TRUNK ROOM)
Connector Type	RK02FL




Terminal No.	Color of Wire	Signal Name [Specification]
1	W/L	-
2	GR/V	-

Connector No.	B63
Connector Name	OUTSIDE KEY ANTENNA (REAR BUMPER)
Connector Type	RK02FL



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	GR	-

Connector No.	BZ01
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
3	R	-
17	GR	-
18	P	-
19	BR	-
20	GR	-
21	Y	-
22	GR	-
23	R	-
24	V	-
25	B	-
26	W	-
27	O	-
28	V	-
29	P	-
30	O	-
31	B/R	-
32	Y	-
40	SHIELD	-
41	W/R	-
42	V	-

44	P	-
45	SB	-
46	R	- [With Climate controlled seat]
48	Y	- [With heated seat]
47	G	- [With Climate controlled seat]
47	GR	- [With heated seat]
48	V	-
49	O	-
50	R	-
51	GR	-
52	LG	-
53	P	-
56	P	-
57	W	-
58	O	-
59	Y	-
61	SB	-
62	L	-
63	W	-
65	L	-
67	Y	-
68	SB	-
69	B	-
70	R	-
76	SHIELD	-
77	G	-
78	P	-
79	P	-
80	G	-
81	P	-
82	BR	-
83	GR	-
84	V	-
85	LG	-
86	W	-
87	O	-
88	Y	-
89	BR	-
90	L	-
91	BR	-
93	Y	- [With Climate controlled seat]
93	O	- [With heated seat]
94	GR	-
96	W	-
97	P	-
98	LG	-
99	LG	-
100	Y	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


DLK

# DOOR & LOCK SYSTEM

< WIRING DIAGRAM >

## DOOR LOCK SYSTEM

Connector No.	B204
Connector Name	WIRE TO WIRE
Connector Type	TH01PW-CS15



Connector No.	B216
Connector Name	FRONT DOOR SWITCH RH
Connector Type	A08PW



Connector No.	B223
Connector Name	REAR DOOR SWITCH RH
Connector Type	A08PW




Connector No.	B240
Connector Name	WIRE TO WIRE
Connector Type	NS10PW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
2	B/W	
3	B/W	
5	Y	
9	R	
10	P	
11	V	
12	Y	
13	BR	
14	LG	
15	GR	
16	G	
17	P	
18	BR	
18	GR	
20	V	
21	LG	
22	W	
23	O	
24	Y	
25	BR	
26	L	
32	G	
33	R	
34	SHIELD	
35	P	
36	B/R	
37	BR	
38	SB	
39	P	
44	SB	
45	R	
46	B	


Terminal No.	2	GR		Signal Name [Specification]
--------------	---	----	--	-----------------------------

Connector No.	B218
Connector Name	WIRE TO WIRE
Connector Type	NH10PW-CS10



Terminal No.	2	BR		Signal Name [Specification]
--------------	---	----	--	-----------------------------

Connector No.	B226
Connector Name	WIRE TO WIRE
Connector Type	NS12MW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	
2	V	
3	P	
4	Y	
5	BR	
6	SHIELD	
9	BR	
10	Y	
11	P	
12	O	
13	L	
14	B/W	
15	SHIELD	
16	LG	

Terminal No.	1	R		Signal Name [Specification]
2	GR			
3	O			
4	P			
7	B			
8	P			
9	O			
10	W			
11	O			
12	Y			
13	B			

Terminal No.	1	R		Signal Name [Specification]
2	GR			
3	V			
5	W			
6	B			
7	O			
8	B/R			
9	L			
10	L/W			
11	W			
11	L/R			
12	SHIELD			

Connector No.	B242
Connector Name	FUEL LID LOCK ACTUATOR
Connector Type	M04PW-LC



Terminal No.	1	LG		Signal Name [Specification]
2	GR			

JCKWA3227GB

# DOOR & LOCK SYSTEM

< WIRING DIAGRAM >

## DOOR LOCK SYSTEM

Connector No.	B514
Connector Name	DRIVER SEAT CONTROL UNIT
Connector Type	TH2ZFV-NH



23	24	25	26	27	28	29	30	31	32	33
20	21	22	19	18	17	16	15	14	13	12

Terminal No.	Color of Wire	Signal Name [Specification]
11	G/B	SLIDE SW (BACKWARD)
12	G/W	SLIDE SW (FORWARD)
13	R/G	RECLINER SW (BACKWARD)
14	R/W	RECLINER SW (FORWARD)
15	Y/B	REAR LIFTER SW (DOWNWARD)
16	Y/R	REAR LIFTER SW (UPWARD)
17	LG/B	RECLINER SW (BACKWARD)
18	LG/R	RECLINER SW (UPWARD)
19	G/Y	PULSE (SLIDE)
20	R/Y	PULSE (RECLINER)
21	Y	PULSE (REAR LIFTER)
22	B	PULSE (FRONT LIFTER)
23	P	CAN-H
24	P/L	CAN-L
25	G/O	IND 1
26	L/O	IND 2
27	V	ADDRESS 1
28	V/W	ADDRESS 2
29	L	SET SW
30	BR	PULSE(TILT)
31	BR/W	PULSE(TELESCOPIC)
32	W/L	UART (TX/RX)
33	W	POWER SUPPLY (ENCODER)

Connector No.	D1
Connector Name	WIRE TO WIRE
Connector Type	TH40FW-CS15



19	20	21	22	23	24	25	26	27	28	29	30	31	32	33
16	17	18	15	14	13	12	11	10	9	8	7	6	5	4
3	2	1												

Terminal No.	Color of Wire	Signal Name [Specification]
5	B	-
6	L	-
7	R	-
8	GR	-
9	G	-
10	LG	-
11	P	-
12	LG	-
13	B/W	-
14	Y	-
15	O	-
16	R	-
17	Y	-
18	BR	-
19	W	-
20	O	-
21	GR	-
22	G	-
23	LG	-
24	B	-
27	V	-
28	W	-
29	GR	-
30	G	-
31	Y	-
32	O	-
33	BR	-
34	L	-
35	P	-
36	V	-
37	GR	-
38	O	-
39	W	-
40	R	-
41	SHIELD	-
42	L	-
43	P	-
44	V	-
45	LG	-
46	BR	-
47	L	-
48	Y	-
49	P	-
50	B/W	-
51	G	-
52	Y	-
53	B/W	-
54	W	-
55	W	-

Connector No.	D8
Connector Name	WIRE TO WIRE
Connector Type	TH24FW-NH



11	12	13	14	15	16	17	18	19	20	21	22	23	24
10	9	8	7	6	5	4	3	2	1				

Terminal No.	Color of Wire	Signal Name [Specification]
4	P	-
7	Y	-
8	V	-
9	GR	-
10	G	-
11	W	-
12	O	-
13	O	-
14	W	-
15	R	-
16	G	-
19	BR	-
20	LG	-
21	R	-
23	B	-
24	V	-

Connector No.	D9
Connector Name	WIRE TO WIRE
Connector Type	NS08FW-CS



3	2	1			
8	7	6	5	4	

Terminal No.	Color of Wire	Signal Name [Specification]
2	LG	-
3	O	-
4	B/W	-
5	L	-
6	G	-
7	Y	-

8	B	-
---	---	---

Connector No.	D14
Connector Name	OUTSIDE KEY ANTENNA (DRIVER SIDE)
Connector Type	FK02MGY



2	1				
---	---	--	--	--	--

Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
2	L	-

Connector No.	D15
Connector Name	FRONT DOOR LOCK ASSEMBLY (DRIVER SIDE)
Connector Type	EG08GY-RS



1	2	3	4	5	6
---	---	---	---	---	---

Terminal No.	Color of Wire	Signal Name [Specification]
1	P	-
2	LG	-
3	W	-
4	B	-
5	G	-
6	R	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

DLK

JCKWA3228GB

# DOOR & LOCK SYSTEM

< WIRING DIAGRAM >

## DOOR LOCK SYSTEM

Connector No.	D17
Connector Name	FRONT OUTSIDE HANDLE ASSEMBLY LH
Connector Type	SAZ08FW




Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	B	-
3	V	-
4	B/W	-

Connector No.	D18
Connector Name	WIRE TO WIRE
Connector Type	TH24MW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
4	P	-
7	R/V	-
8	V	-
9	V/B	-
10	L/Y	-
11	V/W	-
12	O	-
13	LG	-
14	V	-
15	BR	-
16	GR	-
19	V	-
20	SB	-
21	R	-
23	LG	-
24	SB	-

Connector No.	D19
Connector Name	WIRE TO WIRE
Connector Type	NS08MW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
2	LG	-
3	O	-
4	B	-
5	L	-
6	G	-
7	Y	-
8	B	-

Connector No.	D22
Connector Name	POWER WINDOW MAIN SWITCH
Connector Type	NS16FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
3	B	ENCODER +
4	Y	+B
5	G	MOTOR DN DR
6	L	MOTOR UP DR
7	B	GND
9	O	IGN
10	LG	ENCODER GND
11	P	ENCODER SIG1
12	LG	ENCODER SIG2
13	V	COM
15	BR	LOCK SW
16	GR	UNLOCK SW

Connector No.	D31
Connector Name	WIRE TO WIRE
Connector Type	TH40FW-CS15



Terminal No.	Color of Wire	Signal Name [Specification]
2	B	-
3	B/W	-
5	GR	-
9	V	-
10	R	-
11	L	-
12	Y	-
13	BR	-
14	G	-
15	SB	-
16	G	-
17	O	-
18	BR	-
19	GR	-
20	V	-
21	LG	-
22	SB	-
23	G	-
24	Y	-
25	BR	-
26	L	-
32	L/O	-
33	W/L	-
34	SHIELD	-
35	W	-
36	L	-
37	P	-
38	S5	-
39	O	-
44	SB	-
45	R	-
46	B/W	-

Connector No.	D44
Connector Name	OUTSIDE KEY ANTENNA (PASSENGER SIDE)
Connector Type	RK02MGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	-
2	V	-

Connector No.	D45
Connector Name	FRONT DOOR LOCK ASSEMBLY (PASSENGER SIDE)
Connector Type	ED08FY-RS



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	SB	-

JCKWA3229GB

# DOOR & LOCK SYSTEM

< WIRING DIAGRAM >


## DOOR LOCK SYSTEM

Connector No.	D47
Connector Name	FRONT OUTSIDE HANDLE ASSEMBLY RH
Connector Type	SAZ08FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	SB	-
2	B	-
3	R	-
4	B/W	-

Connector No.	D51
Connector Name	WIRE TO WIRE
Connector Type	NH10MW-CS10




Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	V	-
3	R	-
4	L	-
7	B	-
8	P	-
9	W	-
10	V	-
11	L	-
12	LG	-
13	B	-

Connector No.	D55
Connector Name	REAR DOOR LOCK ASSEMBLY LH
Connector Type	EM8FGY-RS



Terminal No.	Color of Wire	Signal Name [Specification]
1	V	-
2	BR	-

Connector No.	D71
Connector Name	WIRE TO WIRE
Connector Type	NH10MW-CS10



Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	V	-
3	R	-
4	L	-
7	B	-
8	P	-
9	W	-
10	V	-
11	L	-
12	LG	-
13	B	-

Connector No.	D75
Connector Name	REAR DOOR LOCK ASSEMBLY RH
Connector Type	EM8FGY-RS



Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	V	-

Connector No.	E57
Connector Name	INTELLIGENT KEY WARNING BUZZER ENGINE ROOM
Connector Type	RK03FBR



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
3	V	-

Connector No.	E103
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS16FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1F	SS	-
2F	V	-

4F	G
6F	O
8F	W
9F	R
12F	Y

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

DLK

# DOOR & LOCK SYSTEM

< WIRING DIAGRAM >

## DOOR LOCK SYSTEM

Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	TH00FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
1	P	
2	W	
3	SB	
4	LG	
5	O	
7	GR	
8	G	
9	Y	
10	BR	
11	SB	
12	V	
13	GR	
14	GR	
15	V	
16	Y	
17	GR	
18	V	
20	BR	
21	P	
22	L	
23	P	
27	SHIELD	
28	L/O	
29	W/L	
31	BR	
32	G	
33	O	
34	Y	
40	BR	
41	BR	
42	L	
43	P	
44	W	
45	L	
46	GR	
47	V	
48	G	
48	O	

50	LG	-
60	W	-
61	G	-
62	Y	-
62	BR	-
64	V	-
66	Y	-
66	R	-
67	SB	-
77	O	-
78	SB	-
80	G	-
81	R	-
82	SB	-
83	GR	-
84	Y	-
85	Y	-
86	L	-
87	V	-
88	BR	-
89	LG	-
90	W	-
91	W	-
92	P	-
93	LG	-
94	BR	-
95	W	-
96	R	-
97	R	-
98	Y	-
99	V	-
100	V	-


Connector No.	F81
Connector Name	A/T ASSEMBLY
Connector Type	RK10FG-DGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	
2	R	
3	L	
4	V	

5	B	-
6	G	-
7	SB	-
8	P	-
9	LG	-
10	B	-

Connector No.	F501
Connector Name	TOM (TRANSMISSION CONTROL MODULE)
Connector Type	SP10FG



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	VIGN
2	B	BATT
3	R	CAN-H
4	O	K LINE
5	G	GND
6	GR	VIGN
7	LE	REV LAMP RLY
8	BR	CAN-L
9	Y	START RLY
10	W/B	GND

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS06FW-M2



Terminal No.	Color of Wire	Signal Name [Specification]
1A	R	
2A	W	
3A	Y	
4A	W	

5A	V	-
6A	Y	-
8A	Y	-

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS12PW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
6C	R	
7C	B	
9C	L	
10C	LG	
11C	LG	
12C	BG	

JCKWA3231GB




# DOOR & LOCK SYSTEM

< WIRING DIAGRAM >

## DOOR LOCK SYSTEM

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	TH8DMW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	W	-
3	SB	-
4	LG	-
5	W	-
6	BG	-
7	BG	-
8	G	-
9	Y	-
10	W	-
11	R	-
12	V	-
13	LG	-
14	L	-
15	B	-
16	W	-
17	GR	-
18	V	-
20	SB	-
21	BR	-
22	L	-
23	P	-
27	SHIELD	-
28	V	-
29	SB	-
31	BG	-
32	P	-
33	R	-
34	BG	-
40	BR	-
41	BR	-
42	L	-
43	P	-
44	BR	-
45	Y	-
46	BG	-
47	V	-
48	G	-
49	BG	-

50	W	-
60	GR	-
61	B	-
62	LG	-
63	BR	-
64	L	-
65	R	-
66	P	-
67	L	-
77	B	-
78	V	-
80	G	-
81	L	-
82	B	-
83	BG	-
84	SB	-
85	Y	-
86	L	-
87	V	-
88	V	-
89	LG	-
90	BG	-
91	W	-
92	BG	-
93	G	-
94	Y	-
95	W	-
96	R	-
97	SB	-
98	R	-
99	W	-
100	L	-

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	TH8DMW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	Y	-
4	BR	-
5	P	-

6	W	-
7	G	-
8	Y	-
9	G	-
10	V	-
11	V	- [With Climate controlled seat]
11	L	- [With heater seat]
12	P	- [With Climate controlled seat]
12	GR	- [With heater seat]
13	BR	-
14	GR	-
15	BG	-
16	V	-
17	BG	- [With ICC]
17	B	- [Without ICC]
18	L	-
19	W	-
20	R	-
21	B	-
22	LG	-
23	W	-
24	V	-
25	G	-
26	BR	-
27	SB	-
28	P	-
29	L	-
30	SHIELD	-
32	L	-
33	P	-
34	L	-
35	P	-
36	BG	-
37	SB	-
40	SHIELD	-
41	SB	-
42	V	-
45	W	-
47	L	-
48	LG	-
49	BR	-
50	V	-
51	V	-
52	P	-
53	BG	-
56	SB	-
57	P	-
58	LG	-
59	V	-
60	GR	-
61	B	-
62	LG	-

63	BR	-
65	W	-
66	R	-
67	V	-
68	LG	-
69	SB	-
70	V	-
72	L	-
73	P	-
74	L	-
75	P	-
76	G	-
77	Y	-
78	SB	-
79	W	-
81	LG	-
82	BR	-
83	BG	-
84	B	-
85	W	-
86	G	-
87	R	-
88	G	-
91	W	-
92	G	-
96	W	-
97	BG	-
98	V	-
99	LG	-

Connector No.	M18
Connector Name	TRUNK LID OPENER CANCEL SWITCH
Connector Type	IS02FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	V	-
2	B	-

JCKWA3232GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

DLK

# DOOR & LOCK SYSTEM

< WIRING DIAGRAM >

## DOOR LOCK SYSTEM

Connector No.	M20
Connector Name	PCB HARNESS
Connector Type	TH40FB-NH



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name [Specification]
1	B	
11	BR	
12	R	
14	L	
15	B	
17	R	
19	W	
20	R	
21	B	
22	R	
23	L	
24	L	
27	P	
30	SHIELD	
31	V	
33	V	
35	L	
36	P	
38	L	
40	Y	

Connector No.	M21
Connector Name	PCB HARNESS
Connector Type	TH40TW-NH



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name [Specification]
41	LG	
42	SHIELD	

43	Y	- [With BOSE system]
43	V	- [Without BOSE system]
44	BR	- [With BOSE system]
44	P	- [Without BOSE system]
45	SHIELD	
46	SB	- [With BOSE system]
46	G	- [Without BOSE system]
47	V	- [With BOSE system]
47	GR	- [Without BOSE system]
48	SHIELD	
49	R	
50	G	- [With BOSE system]
50	BR	- [Without BOSE system]
51	SHIELD	
52	P	- [With BOSE system]
52	L	- [Without BOSE system]
53	L	- [With BOSE system]
53	G	- [Without BOSE system]
54	Y	
55	BR	
56	G	
57	R	
61	SB	
62	SB	
63	LG	
64	B	
65	L	
66	R	
68	V	

Connector No.	M22
Connector Name	PCB HARNESS
Connector Type	TH40FB-NH



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name [Specification]
81	L	
82	P	
83	B	
84	B	
85	B	
86	B	
87	B	

88	B	
89	Y	
91	V	
92	V	
93	B	
94	B	
95	LG	
96	BR	
97	G	
98	G	
99	G	
100	G	
101	L	
102	P	
103	B	
104	BR	
105	R	
107	Y	
108	Y	
109	BR	
110	Y	
112	B	
113	P	
114	L	
116	B	
117	B	
117	BG	- [With V6 engine]
118	B	- [With V6 engine]
119	G	
120	V	

Connector No.	M23
Connector Name	PCB HARNESS
Connector Type	TH40FW-NH



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name [Specification]
121	R	
122	V	
123	BG	
124	BG	
126	BR	
130	B	

131	SB	
132	LG	
133	L	
135	P	
137	Y	
138	Y	
139	L	
140	L	
141	W	
142	W	
144	P	
145	R	
146	LG	
147	B	
148	L	
149	B	
150	P	
151	L	
152	B	
153	W	
154	W	
155	W	
157	W	
158	R	
159	R	

# DOOR & LOCK SYSTEM

< WIRING DIAGRAM >

## DOOR LOCK SYSTEM

Connector No.	M24
Connector Name	POB HARNESS
Connector Type	TH40FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
161	BG	-
162	BG	-
163	G	-
164	V	-
165	V	-
166	R	-
167	LG	-
168	R	-
169	R	-
170	B	-
172	B	-
174	W	-
175	B	-
176	L	-
177	P	-
178	Y	-
179	L	-
180	LG	-
182	BR	-
183	G	-
184	V	-
185	P	-
185	V	- [With BOSE system]
186	R	-
187	L	-
188	Y	-
189	B	-
190	V	-
191	G	-
192	B	-
193	SB	-
194	BR	-
194	BR	-
198	R	-
199	B	-
200	SB	-

Connector No.	M25
Connector Name	POB HARNESS
Connector Type	TH40FB-NH




Terminal No.	Color of Wire	Signal Name [Specification]
201	L	-
208	G	-
209	L	- [With BOSE system]
209	G	- [Without BOSE system]
210	P	-
210	P	- [With BOSE system]
210	L	- [Without BOSE system]
211	SHIELD	-
212	G	- [With BOSE system]
212	BR	- [Without BOSE system]
213	R	-
214	SHIELD	-
215	V	-
215	GR	- [With BOSE system]
216	LG	- [Without BOSE system]
216	G	- [Without BOSE system]
217	SHIELD	-
218	BR	-
218	P	- [With BOSE system]
219	GR	- [Without BOSE system]
219	V	- [With BOSE system]
220	SHIELD	-
221	P	-
222	LG	-
223	SB	-
224	SB	-
225	LG	-
226	R	-
230	BR	-
231	SB	-
232	V	-
233	L	-
234	P	-
235	B	-
239	V	-
240	W	-

Connector No.	M26
Connector Name	POB HARNESS
Connector Type	TH40FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
241	L	-
243	R	-
244	L	-
245	B	-
246	B	-
247	LG	-
247	B	- [With heated seat]
249	SHIELD	-
250	SHIELD	-
253	P	- [With Climate controlled seat]
253	B	- [Without Climate controlled seat]
254	W	-
254	B	- [With Climate controlled seat]
254	B	- [Without Climate controlled seat]
259	B	-
259	SHIELD	-
259	R	-
259	L	-
260	EG	-
261	P	-
269	GR	-
270	Y	-
271	BR	-
272	G	-
273	R	-
274	R	-
275	Y	-
276	B	-
277	G	-
278	R	-
279	SB	-
279	R	- [With Climate controlled seat]
280	Y	- [Without Climate controlled seat]

Connector No.	M30
Connector Name	POB HARNESS
Connector Type	TH40FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
402	R	-
403	R	-
407	V	-
408	B	-
409	B	-
410	B	-
411	B	-
413	Y	-
414	BR	-
416	LG	-
417	B	-
419	SE	-
420	SHIELD	-
422	V	-
427	P	-
428	V	-
429	P	-
430	LG	-
431	B	-
432	Y	-
435	V	-
438	BG	-
437	B	-
438	P	-
439	L	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

DLK

# DOOR & LOCK SYSTEM

< WIRING DIAGRAM >

## DOOR LOCK SYSTEM

Connector No.	M50
Connector Name	PUSH-BUTTON IGNITION SWITCH
Connector Type	TK08BR



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	B	-
3	R	-
4	BR	-
5	GR	-
6	Y	-
7	V	-
8	W	-

Connector No.	M53
Connector Name	COMBINATION METER
Connector Type	TH40FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	BATTERY POWER SUPPLY
2	BG	IGNITION SIGNAL
3	GR	VEHICLE SPEED SIGNAL (2-PULSE)
4	R	VEHICLE SPEED SIGNAL (3-PULSE)
5	B	ILLUMINATION CONTROL SIGNAL
6	B	METER CONTROL SWITCH GROUND
7	SB	ENTER SWITCH SIGNAL
8	LG	SELECT SWITCH SIGNAL
9	G	ILLUMINATION CONTROL SWITCH SIGNAL (+)
10	GR	ILLUMINATION CONTROL SWITCH SIGNAL (-)
11	L	TRIP RESET SWITCH SIGNAL
12	B	GROUND
14	L	CAN-H
15	P	CAN-L

Terminal No.	Color of Wire	Signal Name [Specification]
16	R	AIR BAG SIGNAL
23	B	GROUND
24	B	FUEL LEVEL SENSOR GROUND
25	W	ALTERNATOR SIGNAL
26	V	PARKING BRAKE SWITCH SIGNAL
27	V	BRAKE FLUID LEVEL SWITCH SIGNAL
28	G	SECURITY SIGNAL
29	L	WASHER LEVEL SWITCH SIGNAL
32	G	PADDLE SHIFTER SHIFT DOWN SIGNAL
33	BG	PADDLE SHIFTER SHIFT UP SIGNAL
34	G	FUEL LEVEL SENSOR SIGNAL
35	W	SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SIDE)
36	G	PASSENGER SEAT BELT WARNING SIGNAL
37	G	NON-MANUAL MODE SIGNAL
38	V	MANUAL MODE SHIFT DOWN SIGNAL
39	L	MANUAL MODE SHIFT UP SIGNAL
40	W	MANUAL MODE SIGNAL

Connector No.	M104
Connector Name	REMOTE KEYLESS ENTRY RECEIVER
Connector Type	TH40FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	GROUND
2	BR	SIGNAL OUTPUT
3	GR	RSSI
4	R	BATTERY

Connector No.	M105
Connector Name	WIRE TO WIRE
Connector Type	TH40FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
2	R	-
3	B	-
5	LG	-
6	P	-
7	L	-
8	P	-
9	B	-
10	W	-
11	W	-
12	SB	-
14	W	-
15	BR	-
16	V	-
18	G	-
19	B	-
20	V	-
22	BG	-
23	B	-
25	W	-
30	R	-
31	BR	-
32	L	-
33	P	-
34	LG	-
35	W	-
36	LG	-
37	L	-
38	R	-

# DOOR & LOCK SYSTEM

< WIRING DIAGRAM >

## DOOR LOCK SYSTEM

Connector No.	M117
Connector Name	WIRE TO WIRE
Connector Type	TH00FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
3	Y	-
17	GR	-
18	P	-
19	BR	-
20	GR	-
21	Y	-
22	LG	-
23	R	-
24	BG	-
25	LG	-
26	W	-
27	R	-
28	V	-
29	P	-
30	B	-
31	G	-
32	Y	-
40	SHIELD	-
41	R	-
42	V	-
44	W	-
45	SB	-
46	L	- [With Climate controlled seat]
47	G	- [With heated seat]
48	V	- [With Climate controlled seat]
49	BG	-
50	LG	-
51	SB	-
52	Y	-
53	W	-
56	B	-
57	G	-
58	R	-
59	W	-
61	LG	-
62	V	-

63	R	-
66	L	-
67	Y	-
68	SB	-
69	B	-
70	R	-
76	SHIELD	-
77	G	-
78	R	-
79	L	-
80	G	-
81	BG	-
82	BR	-
83	GR	-
84	V	-
85	LG	-
86	V	-
87	R	-
88	Y	-
89	BR	-
90	L	-
91	Y	-
93	W	- [With Climate controlled seat]
94	V	- [With heated seat]
96	W	-
97	Y	-
98	BR	-
99	G	-
100	Y	-


Connector No.	M120
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	RR WINDOW DEFG RLY CONT
2	BG	COMBI SW INPUT 5
3	SB	COMBI SW INPUT 4
4	L	COMBI SW INPUT 3
5	G	COMBI SW INPUT 2
6	P	COMBI SW INPUT 1

8	V	POWER WINDOW SW COMM
9	P	STOP LAMP SW L
11	R	RAIN SENSOR SERIAL LINK
14	W	OPTICAL SENSOR
16	SB	DIMMER SIGNAL
17	Y	SENSOR PWR SPLY
18	B	RECEIVER / SENSOR GND
19	R	RECEIVER PWR SPLY
20	BR	KYLS ENT RECEIVER COMM
21	P	NATS ANT AMP
22	GR	KYLS ENT RECEIVER RSSI
23	G	SECURITY IND CONT
24	L	DONGLE LINK
25	G	NATS ANT AMP
26	GR	I-KEY IDENTIFICATION
29	G	HAZARD SW
30	BG	TR LID OPNR SW
31	W	DR DOOR UNLK SW SENSOR
32	BR	COMBI SW OUTPUT 5
33	R	COMBI SW OUTPUT 4
34	V	COMBI SW OUTPUT 3
35	Y	COMBI SW OUTPUT 2
36	LG	COMBI SW OUTPUT 1
37	R	P POSITION
39	L	GAN-H
40	P	GAN-L

Connector No.	M121
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA09FB-FHA6-SA



Terminal No.	Color of Wire	Signal Name [Specification]
41	W	TR KEY CYLINDER SW
42	R	TR ROOM LAMP SW
44	V	TR LID OP CANCEL SW
45	GR	PASSENGER DOOR SW
46	BR	REAR RH DOOR SW
47	LG	DRIVER DOOR SW
48	P	REAR LH DOOR SW
49	SB	TR ROOM LAMP CONT
51	BG	TR LID OPEN REG SW
53	LG	TR LID OPEN OUTPUT

55	BR	RR DOOR UNLK OUTPUT
----	----	---------------------

Connector No.	M122
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA09FW-FHA6-SA



Terminal No.	Color of Wire	Signal Name [Specification]
56	R	INT ROOM LAMP PWR SPLY
57	R	BAT FUSE
58	L	AIR BAG
59	G	PASS DOOR UNLK OUTPUT
60	G	TURN SIG LH OUTPUT
61	V	TURN SIG RH OUTPUT
62	V	STEP LAMP CONT
63	L	ROOM LAMP TIMER CONT
65	V	ALL DOOR FL LID UNLK OUTPUT
66	LG	DR DOOR FL LID UNLK OUTPUT
67	B	GND
68	BG	PW PWR SPLY (GN)
69	Y	PW PWR SPLY (BAT)
70	W	BAT (F/L)

JCKWA3236GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

DLK

# DOOR & LOCK SYSTEM

< WIRING DIAGRAM >

## DOOR LOCK SYSTEM

Connector No.	M123
Connector Name	BOM BODY CONTROL MODULE
Connector Type	TH40PW-NH



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name [Specification]
72	B	OUTS HD LAMP OUTPUT
73	V	ON IND
75	G	DR DOOR REQ SW
76	SB	PASS DOOR REQ SW
78	BR	DRIVER DOOR ANT+
79	SB	DRIVER DOOR ANT-
80	LG	PASSENGER DOOR ANT+
81	V	PASSENGER DOOR ANT-
82	V	REAR BMR ANT+
83	SB	REAR BMR ANT-
84	BR	ROOM ANT1+
85	Y	ROOM ANT1-
86	R	ROOM ANT2+
87	G	ROOM ANT2-
88	V	TRUNK ROOM ANT+
89	SB	TRUNK ROOM ANT-
90	R	PUSH-BTN IGN SW ILL PWR
91	GR	LOCK IND
92	B	PUSH-BTN IGN SW ILL GND
93	V	↑-KEY WARN BUZZER
94	Y	S/L UNIT PWR SPLY
95	W	S/L UNIT COMM
96	SB	ACC RELAY CONT
97	SB	STARTER RELAY CONT
98	B	IGN RELAY (IPDM E/R) CONT
99	R	IGN RELAY (F/B) CONT
100	BR	PUSH SW
102	BR	P/N POSITION
104	GR	A/T SHIFT SELECT PWR SPLY
105	R	STOP LAMP SW 2
106	B	BLWR RELAY CONT
107	L	S/L CONDITION1
108	P	S/L CONDITION2
109	Y	ACC IND

Connector No.	M125
Connector Name	CAN GATEWAY
Connector Type	TH12PW-NH



1	2	3	4	5	6	7	8	9	10	11	12
---	---	---	---	---	---	---	---	---	----	----	----

Terminal No.	Color of Wire	Signal Name [Specification]
1	L	CAN-H
3	GR	BATTERY
4	L	CAN-H
5	B	GND
6	L	CAN-H
7	P	CAN-L
9	W	IGNITION
10	P	CAN-L
11	B	GND
12	P	CAN-L

Connector No.	M131
Connector Name	INSIDE KEY ANTENNA (INSTRUMENT CENTER)
Connector Type	RK02FL



1	2
---	---

Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	
2	Y	

Connector No.	M146
Connector Name	INSIDE KEY ANTENNA (CONSOLE)
Connector Type	RK02FL



1	2
---	---

Terminal No.	Color of Wire	Signal Name [Specification]
1	R	
2	G	

Connector No.	M147
Connector Name	AIR BAG DIAGNOSIS SENSOR UNIT
Connector Type	NH28FY-EX



8	9	7	6	2	5	4	3
19	52	54	23	24	22	21	
18	51	53	60	59	25	57	1

Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	IGN
2	B	GND
3	Y	DRI (+)
4	Y	DRI (-) DR2 (-)
5	Y	DR2 (+)
6	Y	ASI (+)
7	Y	ASI (-)
8	Y	AS2 (+)
9	Y	AS2 (-)
18	S9	EQ2S (+)
19	V	EQ2S (-)
22	SHIELD	GND
23	R	AIR BAG W/L
24	G	SEAT BELT
25	R	CUTOFF TELLTALE
51	G	SATELLITE RH2 (+)
52	R	SATELLITE RH2 (-)
53	P	SATELLITE RH2 (+)
54	L	SATELLITE RH2 (-)
57	L	IVCS

59	L	CAN-H
60	P	CAN-L

Connector No.	M181
Connector Name	WIRE TO WIRE
Connector Type	TH40MP-NH



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----


Terminal No.	Color of Wire	Signal Name [Specification]
2	R	
3	B	
5	R	
6	BR	
7	L	
8	P	
9	B	
10	W	
11	LG	
12	SB	
14	SB	
13	BR	
16	V	
18	G	
19	B	
20	V	
22	BG	
23	B	
25	W	
30	R	
31	BR	
32	L	
33	P	
34	LG	
35	W	
36	LG	
37	L	
38	R	

# DOOR & LOCK SYSTEM

< WIRING DIAGRAM >


## DOOR LOCK SYSTEM

Connector No.	M182
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FW




Terminal No.	Color of Wire	Signal Name [Specification]
3	LG	-
4	B	-
5	B	-
6	L	-
7	V	-
8	LG	-
11	SB	-
12	P	-
13	L	-
14	P	-
16	W	-

Connector No.	M187
Connector Name	TRUNK LID OPENER SWITCH
Connector Type	TH08FB-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	BG	-
2	B	-
3	R	-
4	B	-

Connector No.	M210
Connector Name	AV CONTROL UNIT
Connector Type	TH82FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
65	V	PARKING BRAKE SIGNAL
67	R	COMPOSITE IMAGE SIGNAL GND
68	W	COMPOSITE IMAGE SIGNAL
69	G	L-KEY LINK OUTPUT
71	SHIELD	MICROPHONE SHIELD
72	G	MICROPHONE VCC
73	BR	COMM (CONT->DISP)
74	P	CAN-L
75	LG	AV COMM (L)
76	LG	AV COMM (L)
79	SB	DIMMER SIGNAL
80	W	IGNITION SIGNAL
81	BG	REVERSE SIGNAL
82	R	VEHICLE SPEED SIGNAL (PULSE)
83	SHIELD	SHIELD
84	B	COMPOSITE IMAGE SYNC SIGNAL
87	R	MICROPHONE SIGNAL
88	SHIELD	SHIELD
89	Y	COMM (DISP->CONT)
90	L	CAN-H
91	SB	AV COMM (H)
92	SB	AV COMM (H)

Connector No.	T1
Connector Name	WIRE TO WIRE
Connector Type	NS12FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	P	-
2	L	-

1	R	-
2	LG	-
3	P	-
5	W	-
6	O	-
7	V	-
8	L	-
9	W	-
10	B	-
11	R	-
12	GR	-

Connector No.	T3
Connector Name	TRUNK LID LOCK ASSEMBLY
Connector Type	TE03FW-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	B	-
3	LG	-

Connector No.	T4
Connector Name	TRUNK LID OPENER REQUEST SWITCH
Connector Type	TK02MBR-P



Terminal No.	Color of Wire	Signal Name [Specification]
1	P	-
2	L	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

DLK

JCKWA3238GB

# DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000005946889

OVERALL SEQUENCE



DETAILED FLOW

JMKIA3620GB



# DIAGNOSIS AND REPAIR WORK FLOW

## < BASIC INSPECTION >

### 1.GET INFORMATION FOR SYMPTOM

Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred).

>> GO TO 2.

### 2.CHECK FOR DTC

1. Check BCM for DTC.
2. Perform the following procedure if DTC is displayed.
  - Record DTC and freeze frame data (print them out with CONSULT-III).
  - Erase DTC.
  - Study the relationship between the cause detected by DTC and the symptom described by the customer.
3. Check related service bulletins for information.

Are any symptoms described or any DTC detected?

- Symptom is described, DTC is displayed>>GO TO 3.
- Symptom is described, DTC is not displayed>>GO TO 4.
- Symptom is not described, DTC is displayed>>GO TO 5.

### 3.CONFIRM THE SYMPTOM

Confirm the symptom described by the customer.  
Connect CONSULT-III to the vehicle in the "DATA MONITOR" mode and check real time diagnosis results.  
Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5.

### 4.CONFIRM THE SYMPTOM

Confirm the symptom described by the customer.  
Connect CONSULT-III to the vehicle in the "DATA MONITOR" mode and check real time diagnosis results.  
Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6.

### 5.PERFORM DTC CONFIRMATION PROCEDURE

Perform DTC Confirmation Procedure for the displayed DTC, and then check that DTC is detected again.  
At this time, always connect CONSULT-III to the vehicle, and check diagnostic results in real time.  
If two or more DTCs are detected, refer to [BCS-54, "DTC Inspection Priority Chart"](#) (BCM) determine trouble diagnosis order.

#### **NOTE:**

Perform Component Function Check if DTC Confirmation Procedure is not included in Service Manual. This simplified check procedure is an effective alternative though DTC cannot be detected during this check.  
If the result of Component Function Check is NG, it is the same as the detection of DTC by DTC Confirmation Procedure.

Is DTC detected?

- YES >> GO TO 7.
- NO >> Refer to [GI-38, "Intermittent Incident"](#).

### 6.DETECT MALFUNCTIONING SYSTEM BY SYMPTOM DIAGNOSIS

Detect malfunctioning system according to SYMPTOM DIAGNOSIS based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptoms.

>> GO TO 7.

### 7.DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

Inspect according to Diagnostic Procedure of the system.

#### **NOTE:**

The Diagnostic Procedure described is based on open circuit inspection. A short circuit inspection is also required for the circuit check in the Diagnostic Procedure.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

DLK

## DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

---

Is malfunctioning part detected?

YES >> GO TO 8.

NO >> Check voltage of related BCM terminals using CONSULT-III.

### 8. REPAIR OR REPLACE THE MALFUNCTIONING PART

---

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnostic Procedure again after repair and replacement.
3. Check for DTC. If DTC is displayed, erase it.

>> GO TO 9.

### 9. FINAL CHECK

---

When DTC is detected in step 2, perform DTC Confirmation Procedure or Component Function Check again, and then check that the malfunction is completely repaired.

When symptom is described by the customer, refer to confirmed symptom in step 3 or 4, and check that the symptom is not detected.

Does the symptom reappear?

YES (DTC is detected)>>GO TO 7.

YES (Symptom remains)>>GO TO 6.

NO >> INSPECTION END

# INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

---

## INSPECTION AND ADJUSTMENT

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

A

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description

INFOID:000000005946890

B

Perform the system initialization when replacing BCM, replacing Intelligent Key or registering an additional Intelligent Key.

C

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement

INFOID:000000005946891

D

Refer to CONSULT-III operation manual for the NATS-IVIS/NVIS.

E

F

G

H

I

J

**DLK**

L

M

N

O

P

# B2621 INSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

## DTC/CIRCUIT DIAGNOSIS

### B2621 INSIDE ANTENNA

#### DTC Logic

INFOID:000000005946892

#### DTC DETECTION LOGIC

DTC	CONSULT-III display description	DTC detecting condition	Possible cause
B2621	INSIDE ANTENNA	An excessive high or low voltage from inside antenna (instrument center) is sent to BCM.	<ul style="list-style-type: none"> <li>Inside key antenna (instrument center)</li> <li>Between BCM and Inside key antenna (instrument center)</li> </ul>

#### DTC CONFIRMATION PROCEDURE

##### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT-III.
2. Select "INSIDE ANT DIAGNOSIS" in "WORK SUPPORT" mode.
3. Perform inside key antenna ("INSIDE ANT DIAGNOSIS") on "WORK SUPPORT" of "INTELLIGENT KEY".
4. Check BCM for DTC.

##### Is inside key antenna DTC detected?



- YES >> Refer to [DLK-60, "Diagnosis Procedure"](#).
- NO >> Inside key antenna (instrument center) is OK.

#### Diagnosis Procedure

INFOID:000000005946893

##### 1. CHECK INSIDE KEY ANTENNA INPUT SIGNAL 1

1. Turn ignition switch OFF.
2. Check signal between BCM harness connector and ground with oscilloscope.

(+)		(-)	Condition	Signal (Reference value)
BCM				
Connector	Terminal			
M123	84, 85	Ground	When Intelligent Key is in the antenna detection area	 <p>JMKIA3839GB</p>
			When Intelligent Key is not in antenna detection area	 <p>JMKIA3838GB</p>

##### Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).
- NO >> GO TO 2.

##### 2. CHECK INSIDE KEY ANTENNA CIRCUIT

1. Disconnect BCM connector and inside key antenna connector (instrument center).

# B2621 INSIDE ANTENNA

## < DTC/CIRCUIT DIAGNOSIS >

- Check continuity between BCM harness connector and inside key antenna (instrument center) harness connector.

BCM		Inside key antenna (instrument center)		Continuity
Connector	Terminal	Connector	Terminal	
M123	84	M131	1	Existed
	85		2	

- Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M123	84		Not existed
	85		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

### 3. CHECK INSIDE KEY ANTENNA INPUT SIGNAL 2

- Replace inside key antenna (instrument center). (New antenna or other antenna)
- Connect BCM connector and inside key antenna (instrument center) connector.
- Check signal between BCM harness connector and ground with oscilloscope.

(+)		(-)	Condition	Signal (Reference value)
BCM				
Connector	Terminal			
M123	84, 85	Ground	When Intelligent Key is in the antenna detection area	
			When Intelligent Key is not in antenna detection area	

Is the inspection result normal?

YES >> Replace inside key antenna (instrument center).

NO >> Replace BCM. Refer to [BCS-79. "Removal and Installation"](#).

# B2622 INSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

## B2622 INSIDE ANTENNA

### DTC Logic

INFOID:000000005946894

### DTC DETECTION LOGIC

DTC	CONSULT-III display description	DTC detecting condition	Possible cause
B2622	INSIDE ANTENNA	An excessive high or low voltage from inside antenna (console) is sent to BCM.	<ul style="list-style-type: none"> <li>Inside key antenna (console)</li> <li>Between BCM and Inside key antenna (console)</li> </ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT-III.
2. Select "INSIDE ANT DIAGNOSIS" in "WORK SUPPORT" mode.
3. Perform inside key antenna ("INSIDE ANT DIAGNOSIS") on "WORK SUPPORT" of "INTELLIGENT KEY".
4. Check BCM for DTC.

Is inside key antenna DTC detected?



- YES >> Refer to [DLK-62. "Diagnosis Procedure"](#).  
 NO >> Inside key antenna (console) is OK.

### Diagnosis Procedure

INFOID:000000005946895

#### 1. CHECK INSIDE KEY ANTENNA INPUT SIGNAL 1

1. Turn ignition switch OFF.
2. Check signal between BCM harness connector and ground with oscilloscope.

(+)		(-)	Condition	Signal (Reference value)
BCM				
Connector	Terminal			
M123	86, 87	Ground	When Intelligent Key is in the antenna detection area	 <p>JMKIA3839GB</p>
			When Intelligent Key is not in antenna detection area	 <p>JMKIA3838GB</p>

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-79. "Removal and Installation"](#).  
 NO >> GO TO 2.

#### 2. CHECK INSIDE KEY ANTENNA CIRCUIT

1. Disconnect BCM connector and inside key antenna (console) connector.
2. Check continuity between BCM harness connector and inside key antenna (console) harness connector.

# B2622 INSIDE ANTENNA

## < DTC/CIRCUIT DIAGNOSIS >

BCM		Inside key antenna (console)		Continuity
Connector	Terminal	Connector	Terminal	
M123	86	M146	1	Existed
	87		2	

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M123	86		Not existed
	87		



Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

### 3.CHECK INSIDE KEY ANTENNA INPUT SIGNAL 2

1. Replace inside key antenna (console). (New antenna or other antenna)
2. Connect BCM connector and inside key antenna (console) connector.
3. Check signal between BCM harness connector and ground with oscilloscope.

(+)		(-)	Condition	Signal (Reference value)
BCM				
Connector	Terminal			
M123	86, 87	Ground	When Intelligent Key is in the antenna detection area	 <p style="text-align: right; font-size: small;">JMKIA3839GB</p>
			When Intelligent Key is not in antenna detection area	 <p style="text-align: right; font-size: small;">JMKIA3838GB</p>

Is the inspection result normal?

YES >> Replace inside key antenna (console).

NO >> Replace BCM. Refer to [BCS-79. "Removal and Installation"](#).

# B2623 INSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

## B2623 INSIDE ANTENNA

### DTC Logic

INFOID:000000005946896

### DTC DETECTION LOGIC

DTC	CONSULT-III display description	DTC detecting condition	Possible cause
B2623	INSIDE ANTENNA	An excessive high or low voltage from inside antenna (trunk room) is sent to BCM.	<ul style="list-style-type: none"> <li>Inside key antenna (trunk room)</li> <li>Between BCM and Inside key antenna (trunk room)</li> </ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT-III.
2. Select "INSIDE ANT DIAGNOSIS" in "WORK SUPPORT" mode.
3. Perform inside key antenna ("INSIDE ANT DIAGNOSIS") on "WORK SUPPORT" of "INTELLIGENT KEY".
4. Check BCM for DTC.

#### Is inside key antenna DTC detected?



- YES >> Refer to [DLK-64, "Diagnosis Procedure"](#).  
 NO >> Inside key antenna (trunk room) is OK.

### Diagnosis Procedure

INFOID:000000005946897

#### 1. CHECK INSIDE KEY ANTENNA INPUT SIGNAL 1

1. Turn ignition switch OFF.
2. Check signal between BCM harness connector and ground with oscilloscope.

(+)		(-)	Condition	Signal (Reference value)
BCM				
Connector	Terminal			
M123	88, 89	Ground	When Intelligent Key is in the antenna detection area	 <p>JMKIA3839GB</p>
			When Intelligent Key is not in antenna detection area	 <p>JMKIA3838GB</p>

#### Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).  
 NO >> GO TO 2.

#### 2. CHECK INSIDE KEY ANTENNA CIRCUIT

1. Disconnect BCM connector and inside key antenna (trunk room) connector.
2. Check continuity between BCM harness connector and inside key antenna (trunk room) harness connector.



# B2623 INSIDE ANTENNA

## < DTC/CIRCUIT DIAGNOSIS >

BCM		Inside key antenna (trunk room)		Continuity
Connector	Terminal	Connector	Terminal	
M123	88	B49	1	Existed
	89		2	

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M123	88		Not existed
	89		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

### 3.CHECK INSIDE KEY ANTENNA INPUT SIGNAL 2

1. Replace inside key antenna (trunk room). (New antenna or other antenna)
2. Connect BCM connector and inside key antenna (trunk room) connector.
3. Check signal between BCM harness connector and ground with oscilloscope.

(+)		(-)	Condition	Signal (Reference value)
BCM				
Connector	Terminal			
M123	88, 89	Ground	When Intelligent Key is in the antenna detection area	
			When Intelligent Key is not in antenna detection area	

Is the inspection result normal?

YES >> Replace inside key antenna (trunk room).

NO >> Replace BCM. Refer to [BCS-79. "Removal and Installation"](#).

# B2626 OUTSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

## B2626 OUTSIDE ANTENNA

### DTC Logic

INFOID:000000006059407

### DTC DETECTION LOGIC

DTC	CONSULT-III display description	DTC detecting condition	Possible cause
B2626	OUTSIDE ANTENNA	An excessive high or low voltage from outside key antenna (driver side) is sent to BCM	<ul style="list-style-type: none"> <li>• Outside key antenna (driver side)</li> <li>• Between BCM ~ Outside key antenna (driver side)</li> </ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check "Self Diagnostic Result" mode of "BCM" using CONSULT-III.

#### Is DTC detected?



- YES >> Refer to [DLK-66. "Diagnosis Procedure"](#).  
 NO >> Inside key antenna (driver side) is OK.

### Diagnosis Procedure

INFOID:000000006059408

#### 1. CHECK OUTSIDE KEY ANTENNA INPUT SIGNAL 1

1. Turn ignition switch OFF.
2. Check signal between BCM harness connector and ground using oscilloscope.

(+)		(-)	Condition	Signal (Reference value)
BCM				
Connector	Terminal			
Driver side	M123	78, 79	Ground	When Intelligent Key is in the antenna detection area  <small>JMKIA3839GB</small>
				When Intelligent Key is not in the antenna detection area  <small>JMKIA3838GB</small>

#### Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-79. "Removal and Installation"](#).  
 NO >> GO TO 2.

#### 2. CHECK OUTSIDE KEY ANTENNA CIRCUIT

1. Disconnect BCM connector and outside key antenna (driver side) connector.
2. Check continuity between BCM harness connector and outside key antenna (driver side) harness connector.

# B2626 OUTSIDE ANTENNA

## < DTC/CIRCUIT DIAGNOSIS >

BCM		Outside key antenna (driver side)		Continuity
Connector	Terminal	Connector	Terminal	
M123	78	D14	1	Existed
	79		2	

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M123	78		Not existed
	79		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

### 3. CHECK OUTSIDE KEY ANTENNA INPUT SIGNAL 2

1. Replace outside key antenna (driver side). (New antenna or other antenna)
2. Connect BCM connector and outside key antenna (driver side) connector.
3. Check signal between BCM harness connector and ground using oscilloscope.

(+)			(-)	Condition	Signal (Reference value)
BCM		Terminal			
Connector	Terminal				
Driver side	M123	78, 79	Ground	When Intelligent Key is in the antenna detection area	<p>JMKIA3839GB</p>
				When Intelligent Key is not in the antenna detection area	<p>JMKIA3838GB</p>

Is the inspection result normal?

YES >> Replace outside key antenna (driver side).

NO >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

# B2627 OUTSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

## B2627 OUTSIDE ANTENNA

### DTC Logic

INFOID:000000006059409

### DTC DETECTION LOGIC

DTC	CONSULT-III display description	DTC detecting condition	Possible cause
B2627	OUTSIDE ANTENNA	An excessive high or low voltage from outside key antenna (passenger side) is sent to BCM	<ul style="list-style-type: none"> <li>• Outside key antenna (passenger side)</li> <li>• Between BCM ~ Outside key antenna (passenger side)</li> </ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check "Self Diagnostic Result" mode of "BCM" using CONSULT-III.

#### Is DTC detected?

- YES >> Refer to [DLK-68, "Diagnosis Procedure"](#).  
 NO >> Inside key antenna (passenger side) is OK.

### Diagnosis Procedure

INFOID:000000006059410

#### 1. CHECK OUTSIDE KEY ANTENNA INPUT SIGNAL 1

1. Turn ignition switch OFF.
2. Check signal between BCM harness connector and ground using oscilloscope.

(+) BCM		Terminal	(-)	Condition	Signal (Reference value)
Connector					
Passenger side	M123	80, 81	Ground	When Intelligent Key is in the antenna detection area	<p>JMKIA3839GB</p>
				When Intelligent Key is not in the antenna detection area	<p>JMKIA3838GB</p>

#### Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).  
 NO >> GO TO 2.

#### 2. CHECK OUTSIDE KEY ANTENNA CIRCUIT

1. Disconnect BCM connector and outside key antenna (passenger side) connector.
2. Check continuity between BCM harness connector and outside key antenna (passenger side) harness connector.

# B2627 OUTSIDE ANTENNA

## < DTC/CIRCUIT DIAGNOSIS >

BCM		Outside key antenna (passenger side)		Continuity
Connector	Terminal	Connector	Terminal	
M123	80	D44	1	Existed
	81		2	

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M123	80		Not existed
	81		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

### 3. CHECK OUTSIDE KEY ANTENNA INPUT SIGNAL 2

1. Replace outside key antenna (passenger side). (New antenna or other antenna)
2. Connect BCM connector and outside key antenna (passenger side) connector.
3. Check signal between BCM harness connector and ground using oscilloscope.

(+)			(-)	Condition	Signal (Reference value)
BCM		Terminal			
Connector	Terminal				
Passenger side	M123	80, 81	Ground	When Intelligent Key is in the antenna detection area	<p style="text-align: right; font-size: small;">JMkia3839GB</p>
				When Intelligent Key is not in the antenna detection area	<p style="text-align: right; font-size: small;">JMkia3838GB</p>

Is the inspection result normal?

YES >> Replace outside key antenna (passenger side).

NO >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

DLK

# B2628 OUTSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

## B2628 OUTSIDE ANTENNA

### DTC Logic

INFOID:000000006059411

### DTC DETECTION LOGIC

DTC	CONSULT-III display description	DTC detecting condition	Possible cause
B2628	OUTSIDE ANTENNA	An excessive high or low voltage from outside key antenna (rear bumper) is sent to BCM	<ul style="list-style-type: none"> <li>• Outside key antenna (rear bumper)</li> <li>• Between BCM – Outside key antenna (rear bumper)</li> </ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check "Self Diagnostic Result" mode of "BCM" using CONSULT-III.

#### Is DTC detected?

- YES >> Refer to [DLK-70. "Diagnosis Procedure"](#).  
 NO >> Inside key antenna (rear bumper) is OK.

### Diagnosis Procedure

INFOID:000000006059412

#### 1. CHECK OUTSIDE KEY ANTENNA INPUT SIGNAL 1

1. Turn ignition switch OFF.
2. Check signal between BCM harness connector and ground using oscilloscope.

(+)			(-)	Condition	Signal (Reference value)
BCM					
Connector	Terminal				
Rear bumper	M123	82, 83	Ground	When Intelligent Key is in the antenna detection area	<p style="text-align: right;">JMKIA3839GB</p>
				When Intelligent Key is not in the antenna detection area	<p style="text-align: right;">JMKIA3838GB</p>

#### Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-79. "Removal and Installation"](#).  
 NO >> GO TO 2.

#### 2. CHECK OUTSIDE KEY ANTENNA CIRCUIT

1. Disconnect BCM connector and outside key antenna (rear bumper) connector.
2. Check continuity between BCM harness connector and outside key antenna (rear bumper) harness connector.

# B2628 OUTSIDE ANTENNA

## < DTC/CIRCUIT DIAGNOSIS >

BCM		Outside key antenna (rear bumper)		Continuity
Connector	Terminal	Connector	Terminal	
M123	82	B63	1	Existed
	83		2	

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M123	82		Not existed
	83		



Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

### 3. CHECK OUTSIDE KEY ANTENNA INPUT SIGNAL 2

1. Replace outside key antenna (rear bumper). (New antenna or other antenna)
2. Connect BCM and outside key antenna (rear bumper) connector.
3. Check signal between BCM harness connector and ground using oscilloscope.

(+)			(-)	Condition	Signal (Reference value)
BCM		Terminal			
Connector	Terminal				
Rear bumper	M123	82, 83	Ground	When Intelligent Key is in the antenna detection area	 <p style="text-align: right; font-size: small;">JMKIA3839GB</p>
				When Intelligent Key is not in the antenna detection area	 <p style="text-align: right; font-size: small;">JMKIA3838GB</p>

Is the inspection result normal?

YES >> Replace outside key antenna (rear bumper).

NO >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

DLK

# DOOR SWITCH

< DTC/CIRCUIT DIAGNOSIS >

## DOOR SWITCH

### Component Function Check

INFOID:000000005946906

#### 1.CHECK FUNCTION

1. Select "DOOR LOCK" of "BCM" using CONSULT-III.
2. Select "DOOR SW-DR", "DOOR SW-AS", "DOOR SW-RL", "DOOR SW-RR" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

Monitor item	Condition		Status
DOOR SW-DR	Driver side door	Open	On
		Closed	Off
DOOR SW-AS	Passenger side door	Open	On
		Closed	Off
DOOR SW-RL	Rear side door LH	Open	On
		Closed	Off
DOOR SW-RR	Rear side door RH	Open	On
		Closed	Off

Is the inspection result normal?

- YES >> Door switch is OK.  
NO >> Refer to [DLK-72, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005946907





#### 1.CHECK DOOR SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect malfunctioning door switch connector.
3. Check signal between malfunctioning door switch harness connector and ground with oscilloscope.



# DOOR SWITCH

## < DTC/CIRCUIT DIAGNOSIS >

(+)		Terminal	(-)	Signal (Reference value)
Door switch				
Connector	Terminal			
Front LH	B16	2	Ground	 <p style="text-align: right; font-size: small;">JPMA0011GB</p>
Front RH	B216			 <p style="text-align: right; font-size: small;">JPMA0011GB</p>
Rear LH	B23			 <p style="text-align: right; font-size: small;">JPMA0011GB</p>
Rear RH	B223			 <p style="text-align: right; font-size: small;">JPMA0011GB</p>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

DLK

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> GO TO 2.

### 2. CHECK DOOR SWITCH CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and door switch harness connector.

BCM		Door switch		Continuity
Connector	Terminal	Connector	Terminal	
M121	47	B16 (Front LH)	2	Existed
	45	B216 (Front RH)		
	48	B23 (Rear LH)		
	46	B223 (Rear RH)		

3. Check continuity between BCM harness connector and ground.

# DOOR SWITCH

## < DTC/CIRCUIT DIAGNOSIS >

BCM		Ground	Continuity
Connector	Terminal		
M121	47		Not existed
	45		
	48		
	46		

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

NO >> Repair or replace harness.

### 3.CHECK DOOR SWITCH

Refer to [DLK-74, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace malfunctioning door switch.

### 4.CHECK INTERMITTENT INCIDENT

Refer to [GI-38, "Intermittent Incident"](#).

>> INSPECTION END

## Component Inspection

INFOID:000000005946908

### 1.CHECK DOOR SWITCH

1. Turn ignition switch OFF.
2. Disconnect malfunction door switch connector.
3. Check continuity between door switch terminals.

Door switch		Condition	Continuity	
Terminal				
2	Ground part of door switch	Door switch	Pressed	Not exists
			Released	Exists

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace malfunctioning door switch.

# DOOR LOCK AND UNLOCK SWITCH

< DTC/CIRCUIT DIAGNOSIS >

## DOOR LOCK AND UNLOCK SWITCH

### Component Function Check

INFOID:000000005946899

#### 1.CHECK FUNCTION

1. Select "DOOR LOCK" of "BCM" using CONSULT-III.
2. Select "CDL LOCK SW", "CDL UNLOCK SW" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

Monitor item	Condition	Status
CDL LOCK SW	Lock	ON
	Unlock	OFF
CDL UNLOCK SW	Lock	OFF
	Unlock	ON

Is the inspection result normal?

- YES >> Door lock and unlock switch is OK.  
NO >> Refer to [DLK-75, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005946900

#### 1.CHECK POWER WINDOW SWITCH

1. Turn ignition switch ON.
2. Check power window operation.

Does power window operate?

- YES >> Replace power window main switch.  
NO >> Refer to [PWC-59, "Diagnosis Procedure"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

DLK

# DOOR KEY CYLINDER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

## DOOR KEY CYLINDER SWITCH

### Component Function Check

INFOID:000000006059414

#### 1.CHECK FUNCTION

1. Select "DOOR LOCK" of "BCM" using CONSULT-III.
2. Select "KEY CYL LK-SW", "KEY CYL UN-SW" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

Monitor item	Condition	Status
KEY CYL LK-SW	Lock	ON
	Neutral / Unlock	OFF
KEY CYL UN-SW	Unlock	ON
	Neutral / Lock	OFF

Is the inspection result normal?

- YES >> Door key cylinder switch is OK.  
NO >> Refer to [DLK-76, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000006059415

#### 1.CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front door lock assembly (driver side) connector.
3. Check voltage between front door lock assembly (driver side) harness connector and ground.

(+) Front door lock assembly (driver side)		(-)	Voltage (Approx.)
Connector	Terminal		
D15	5	Ground	5 V
	6		

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> GO TO 2.

#### 2.CHECK DOOR KEY CYLINDER SWITCH SIGNAL CIRCUIT

1. Disconnect power window main switch connector.
2. Check continuity between power window main switch harness connector and front door lock assembly (driver side) harness connector.

Power window main switch		Front door lock assembly (driver side)		Continuity
Connector	Terminal	Connector	Terminal	
D22	15	D15	6	Existed
	16		5	

3. Check continuity between power window main switch harness connector and ground.

Power window main switch		Ground	Continuity
Connector	Terminal		
D22	15		Not existed
	16		

Is the inspection result normal?

- YES >> Replace power window main switch. Refer to [PWC-72, "Removal and Installation"](#).

# DOOR KEY CYLINDER SWITCH

## < DTC/CIRCUIT DIAGNOSIS >

NO >> Repair or replace harness.

### 3.CHECK DOOR KEY CYLINDER SWITCH GROUND CIRCUIT

Check continuity between front door lock assembly (driver side) harness connector and ground.

Front door lock assembly (driver side)		Ground	Continuity
Connector	Terminal		
D15	4		Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

### 4.CHECK DOOR KEY CYLINDER SWITCH

Refer to [DLK-77, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace front door lock assembly (driver side).

### 5.CHECK INTERMITTENT INCIDENT

Refer to [GI-38, "Intermittent Incident"](#).

>> INSPECTION END

## Component Inspection

INFOID:000000006059416

### 1.CHECK DOOR KEY CYLINDER SWITCH

1. Turn ignition switch OFF.
2. Disconnect front door lock assembly (driver side) connector.
3. Check continuity between front door lock assembly (driver side) terminals.

Front door lock assembly (driver side)		Condition	Continuity
Terminal			
5	4	Driver side door key cylinder	Unlock Existed
		Neutral / Lock Not existed	
6		Lock Existed	
		Neutral / Unlock Not existed	

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace front door lock assembly (driver side).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

**DLK**

# DOOR REQUEST SWITCH

< DTC/CIRCUIT DIAGNOSIS >

## DOOR REQUEST SWITCH

### Component Function Check

INFOID:000000005946929

#### 1.CHECK FUNCTION

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT-III.
2. Select "REQ SW -DR", "REQ SW -AS" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

Monitor item	Condition		Status
REQ SW -DR	Driver side door request switch	Pressed	On
		Released	Off
REQ SW -AS	Passenger side door request switch	Pressed	On
		Released	Off

Is the inspection result normal?

- YES >> Door request switch is OK.  
NO >> Refer to [DLK-78, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005946930

#### 1.CHECK DOOR REQUEST SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect malfunctioning front outside handle assembly connector.
3. Check voltage between malfunctioning front outside handle assembly harness connector and ground.

(+)		Terminal	(-)	Voltage (Approx.)
Front outside handle assembly (request switch)				
Connector	Terminal	1	Ground	12 V
LH	D17			
RH	D47			

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> GO TO 2.

#### 2.CHECK DOOR REQUEST SWITCH CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and malfunctioning front outside handle assembly harness connector.

BCM		Front outside handle assembly (request switch)		Continuity
Connector	Terminal	Connector	Terminal	
M123	75	LH	D17	Existed
	76	RH	D47	

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M123	75		Not existed
	76		

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).  
NO >> Repair or replace harness.

# DOOR REQUEST SWITCH

< DTC/CIRCUIT DIAGNOSIS >

## 3. CHECK DOOR REQUEST SWITCH GROUND CIRCUIT

Check continuity between malfunctioning front outside handle assembly harness connector and ground.

Front outside handle assembly (request switch)		Ground	Continuity
Connector	Terminal		
LH	D17	2	Existed
RH	D47		

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair or replace harness.

## 4. CHECK DOOR REQUEST SWITCH

Refer to [DLK-79. "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Replace malfunctioning front outside handle assembly.

## 5. CHECK INTERMITTENT INCIDENT

Refer to [GI-38. "Intermittent Incident"](#).

>> INSPECTION END

## Component Inspection

INFOID:000000005946931

## 1. CHECK DOOR REQUEST SWITCH

1. Turn ignition switch OFF.
2. Disconnect front outside handle assembly connector.
3. Check continuity between front outside handle assembly terminal.

Front outside handle assembly (request switch)		Condition	Continuity
Terminal			
1	2	Door request switch	Existed
			Not existed

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> Replace front outside handle.

DLK

# TRUNK LID OPENER REQUEST SWITCH

< DTC/CIRCUIT DIAGNOSIS >

## TRUNK LID OPENER REQUEST SWITCH

### Component Function Check

INFOID:000000005946932

#### 1.CHECK FUNCTION

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT-III.
2. Select "REQ SW -BD/TR" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

Monitor item	Condition		Status
REQ SW -BD/TR	Trunk lid opener request switch	Pressed	On
		Released	Off

Is the inspection result normal?

- YES >> Trunk lid opener request switch is OK.  
NO >> Refer to [DLK-80. "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005946933

#### 1.CHECK TRUNK LID OPENER REQUEST SWITCH OUTPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect trunk lid opener request switch connector.
3. Check voltage between trunk lid opener request switch harness connector and ground.

(+)		(-)	Voltage (Approx.)
Connector	Terminal		
T4	1	Ground	12 V

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> GO TO 2.

#### 2.CHECK TRUNK LID OPENER REQUEST SWITCH CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and trunk lid opener request switch harness connector.

BCM		Trunk lid opener request switch		Continuity
Connector	Terminal	Connector	Terminal	
M121	51	T4	1	Existed

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M121	51		Not existed

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-79. "Removal and Installation"](#).  
NO >> Repair or replace harness.

#### 3.CHECK TRUNK LID OPENER REQUEST SWITCH GROUND CIRCUIT

Check continuity between trunk lid opener request switch harness connector and ground.



# TRUNK LID OPENER REQUEST SWITCH

## < DTC/CIRCUIT DIAGNOSIS >

Trunk lid opener request switch		Ground	Continuity
Connector	Terminal		Existed
T4	2		

Is the inspection result normal?

- YES >> GO TO 4.  
 NO >> Repair or replace harness.

### 4.CHECK TRUNK LID OPENER REQUEST SWITCH

Refer to [DLK-81. "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.  
 NO >> Replace trunk lid opener request switch.

### 5.CHECK INTERMITTENT INCIDENT

Refer to [GI-38. "Intermittent Incident"](#).

>> INSPECTION END

## Component Inspection

INFOID:000000005946934

### 1.CHECK TRUNK LID OPENER REQUEST SWITCH

- Turn ignition switch OFF.
- Disconnect trunk lid opener request switch connector.
- Check continuing between trunk lid opener request switch terminal.

Trunk lid opener request switch		Condition	Continuity
Terminal			Existed
1	2	Trunk lid opener request switch	Existed
			Not existed

Is the inspection result normal?

- YES >> INSPECTION END  
 NO >> Replace trunk lid opener request switch.

DLK

# TRUNK LID OPENER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

## TRUNK LID OPENER SWITCH

### Component Function Check

INFOID:000000005946923

#### 1. CHECK FUNCTION

1. Select "TRUNK" of "BCM" using CONSULT-III.
2. Select "TR/BD OPEN SW" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

Monitor item	Condition		Status
TR/BD OPEN SW	Trunk lid opener switch	Pressed	On
		Released	Off

Is the inspection result normal?


- YES >> Trunk lid opener switch is OK.  
 NO >> Refer to [DLK-82, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005946924

#### 1. CHECK TRUNK LID OPENER INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect trunk lid opener switch connector.
3. Check signal between trunk lid opener switch harness connector and ground using oscilloscope.

(+)		(-)	Signal (Reference value)
Connector	Terminal		
M187	1	Ground	 <p style="text-align: right;">JPMIA0012GB</p>

Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> GO TO 2.

#### 2. CHECK TRUNK LID OPENER SWITCH CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and trunk lid opener switch harness connector.

BCM		Trunk lid opener switch		Continuity
Connector	Terminal	Connector	Terminal	
M120	30	M187	1	Existed

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M120	30		Not existed

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).  
 NO >> Repair or replace harness.

# TRUNK LID OPENER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

## 3.CHECK TRUNK LID OPENER SWITCH GROUND CIRCUIT

Check continuity between trunk lid opener switch harness connector and ground.

Trunk lid opener switch		Ground	Continuity
Connector	Terminal		
M187	2		Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

## 4.CHECK TRUNK LID OPENER SWITCH

Refer to [DLK-83, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace trunk lid opener switch.

## 5.CHECK INTERMITTENT INCIDENT

Refer to [GI-38, "Intermittent Incident"](#).

>> INSPECTION END

## Component Inspection

INFOID:000000005946925

## 1.CHECK TRUNK LID OPENER SWITCH

1. Turn ignition switch OFF.
2. Disconnect trunk lid opener switch connector.
3. Check continuity between trunk lid opener switch terminals.

Trunk lid opener switch		Condition	Continuity
Terminal			
1	2	Trunk lid opener switch	Existed
			Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace trunk lid opener switch.

DLK

# TRUNK LID OPENER CANCEL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

## TRUNK LID OPENER CANCEL SWITCH

### Component Function Check

INFOID:000000005946926

#### 1.CHECK FUNCTION

1. Select "TRUNK" of "BCM" using CONSULT-III.
2. Select "TR CANCEL SW" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

Monitor item	Condition		Status
TR CANCEL SW	Trunk lid opener cancel switch	Pressed	On
		Released	Off

Is the inspection result normal?


- YES >> Trunk lid opener cancel switch is OK.  
 NO >> Refer to [DLK-84, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005946927

#### 1.CHECK TRUNK LID OPENER CANCEL INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect trunk lid opener cancel switch connector.
3. Check signal between trunk lid opener cancel switch harness connector and ground using oscilloscope.

(+)		(-)	Signal (Reference value)
Connector	Terminal		
M18	1	Ground	 <p style="text-align: right;">JPMAI0012GB</p>

Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> GO TO 2.

#### 2.CHECK TRUNK LID OPENER SWITCH CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and trunk lid opener cancel switch harness connector.

BCM		Trunk lid opener cancel switch		Continuity
Connector	Terminal	Connector	Terminal	
M121	44	M18	1	Existed

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M121	44		Not existed

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).  
 NO >> Repair or replace harness.

# TRUNK LID OPENER CANCEL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

## 3.CHECK TRUNK LID OPENER CANCEL SWITCH GROUND CIRCUIT

Check continuity between trunk lid opener cancel switch harness connector and ground.

Trunk lid opener cancel switch		Ground	Continuity
Connector	Terminal		
M18	2		Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

## 4.CHECK TRUNK LID OPENER CANCEL SWITCH

Refer to [DLK-85, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace trunk lid opener cancel switch.

## 5.CHECK INTERMITTENT INCIDENT

Refer to [GI-38, "Intermittent Incident"](#).

>> INSPECTION END

## Component Inspection

INFOID:000000005946928

## 1.CHECK TRUNK LID OPENER CANCEL SWITCH

1. Turn ignition switch OFF.
2. Disconnect trunk lid opener cancel switch connector.
3. Check continuity between trunk lid opener cancel switch terminal.

Trunk lid opener cancel switch		Condition	Continuity
Terminal			
1	2	Trunk lid opener cancel switch	Existed
			Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace trunk lid opener cancel switch.

DLK

# TRUNK ROOM LAMP SWITCH

< DTC/CIRCUIT DIAGNOSIS >

## TRUNK ROOM LAMP SWITCH

### Component Function Check

INFOID:000000005946935

#### 1. CHECK FUNCTION

1. Select "TRUNK" of "BCM" using CONSULT-III.
2. Select "TRNK/HAT MNTR" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

Monitor item	Condition		Status
TRNK/HAT MNTR	Trunk lid	Open	On
		Closed	Off

Is the inspection result normal?

YES >> Trunk room lamp switch is OK.


NO >> Refer to [DLK-87. "Component Inspection"](#).

### Diagnosis Procedure

INFOID:000000005946936

#### 1. CHECK TRUNK ROOM LAMP SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect trunk lid lock assembly.
3. Check signal between trunk lid lock assembly harness connector and ground using oscilloscope.

(+)		(-)	Signal (Reference value)
Trunk lid lock assembly			
Connector	Terminal		
T3	1	Ground	

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

#### 2. CHECK TRUNK ROOM LAMP SWITCH CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM connector and trunk lid lock assembly connector.

BCM		Trunk lid lock assembly		Continuity
Connector	Terminal	Connector	Terminal	
M121	42	T3	1	Existed

3. Check continuity between BCM connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M121	42		Not existed

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-79. "Removal and Installation"](#).

NO >> Repair or replace harness.

# TRUNK ROOM LAMP SWITCH

< DTC/CIRCUIT DIAGNOSIS >

## 3.CHECK TRUNK ROOM LAMP SWITCH GROUND CIRCUIT

Check continuity between trunk lid lock assembly connector and ground.

Trunk lid lock assembly		Ground	Continuity
Connector	Terminal		
T3	2		Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

## 4.CHECK TRUNK ROOM LAMP SWITCH

Refer to [DLK-87, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace trunk lid lock assembly.

## 5.CHECK INTERMITTENT INCIDENT

Refer to [GI-38, "Intermittent Incident"](#).

>> INSPECTION END

## Component Inspection

INFOID:000000005946937

## 1.CHECK TRUNK ROOM LAMP SWITCH

1. Turn ignition switch OFF.
2. Disconnect trunk lid lock assembly connector.
3. Check continuing between trunk room lamp switch terminal.

Trunk lid lock assembly		Condition	Continuity
Terminal			
1	2	Trunk lid	Existed
			Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace trunk lid lock assembly.

DLK

# DOOR LOCK ACTUATOR

< DTC/CIRCUIT DIAGNOSIS >

## DOOR LOCK ACTUATOR DRIVER SIDE

### DRIVER SIDE : Component Function Check

INFOID:000000005946909

#### 1. CHECK FUNCTION

1. Select "DOOR LOCK" of "BCM" using CONSULT-III.
2. Select "DOOR LOCK" in "ACTIVE TEST" mode.
3. Touch "ALL LCK" or "ALL UNLK" to check that it works normally.

Is the inspection result normal?

YES >> Door lock actuator is OK.

NO >> Refer to [DLK-88. "DRIVER SIDE : Diagnosis Procedure"](#).

### DRIVER SIDE : Diagnosis Procedure

INFOID:000000005946910

#### 1. CHECK DOOR LOCK ACTUATOR OUTPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front door lock assembly (driver side) connector.
3. Check voltage between front door lock assembly (driver side) harness connector and ground.

(+)		(-)	Condition		Voltage (Approx.)
Front door lock assembly (driver side)					
Connector	Terminal				
D15	1	Ground	Door lock and un- lock switch	Lock	12 V
	2			Unlock	

Is the inspection result normal?

YES >> Replace front door lock assembly (driver side).

NO >> GO TO 2.

#### 2. CHECK DOOR LOCK ACTUATOR CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and front door lock assembly (driver side) harness connector.

BCM		Front door lock assembly (driver side)		Continuity
Connector	Terminal	Connector	Terminal	
M122	65	D15	1	Existed
	66		2	

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M122	65		Not existed
	66		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

#### 3. CHECK BCM OUTPUT SIGNAL

1. Connect BCM connector.
2. Check voltage between BCM harness connector and ground.



# DOOR LOCK ACTUATOR

## < DTC/CIRCUIT DIAGNOSIS >

(+)		(-)	Condition	Voltage (Approx.)
BCM				
Connector	Terminal			
M122	65	Ground	Door lock and unlock switch	Lock
	66			Unlock
12 V				

Is the inspection result normal?

YES >> Check for internal short of each door lock actuator and fuel lid lock actuator.

NO >> Replace BCM. Refer to [BCS-79. "Removal and Installation"](#).

## PASSENGER SIDE

### PASSENGER SIDE : Component Function Check

INFOID:000000005946911

#### 1.CHECK FUNCTION

1. Select "DOOR LOCK" of "BCM" using CONSULT-III.
2. Select "DOOR LOCK" in "ACTIVE TEST" mode.
3. Touch "ALL LCK" or "ALL UNLK" to check that it works normally.

Is the inspection result normal?

YES >> Door lock actuator is OK.

NO >> Refer to [DLK-89. "PASSENGER SIDE : Diagnosis Procedure"](#).

### PASSENGER SIDE : Diagnosis Procedure

INFOID:000000005946912

#### 1.CHECK DOOR LOCK ACTUATOR OUTPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front door lock assembly (passenger side) connector.
3. Check voltage between front door lock assembly (passenger side) harness connector and ground.

(+)		(-)	Condition	Voltage (Approx.)
Front door lock assembly (passenger side)				
Connector	Terminal			
D45	1	Ground	Door lock and unlock switch	Unlock
	2			Lock
12 V				

Is the inspection result normal?

YES >> Replace front door lock assembly (passenger side).

NO >> GO TO 2.

#### 2.CHECK DOOR LOCK ACTUATOR CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and front door lock assembly (passenger side) harness connector.

BCM		Front door lock assembly (passenger side)		Continuity
Connector	Terminal	Connector	Terminal	
M122	59	D45	1	Existed
	65		2	

3. Check continuity between BCM harness connector and ground.

# DOOR LOCK ACTUATOR

## < DTC/CIRCUIT DIAGNOSIS >

BCM		Ground	Continuity
Connector	Terminal		
M122	59		Not existed
	65		

### Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> Repair or replace harness.

## 3.CHECK BCM OUTPUT SIGNAL

1. Connect BCM connector.
2. Check voltage between BCM harness connector and ground.

(+)		(-)	Condition	Voltage (Approx.)	
BCM					
Connector	Terminal				
M122	59	Ground	Door lock and unlock switch	Unlock	12 V
	65			Lock	

### Is the inspection result normal?

- YES >> Check for internal short of each door lock actuator and fuel lid lock actuator.  
 NO >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

## REAR LH

### REAR LH : Component Function Check

INFOID:000000005946913

## 1.CHECK FUNCTION

1. Select "DOOR LOCK" of "BCM" using CONSULT-III.
2. Select "DOOR LOCK" in "ACTIVE TEST" mode.
3. Touch "ALL LCK" or "ALL UNLK" to check that it works normally.

### Is the inspection result normal?

- YES >> Door lock actuator is OK.  
 NO >> Refer to [DLK-90, "REAR LH : Diagnosis Procedure"](#).

### REAR LH : Diagnosis Procedure

INFOID:000000005946914

## 1.CHECK DOOR LOCK ACTUATOR OUTPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect rear door lock assembly LH.
3. Check voltage between rear door lock assembly LH harness connector and ground.

(+)		(-)	Condition	Voltage (Approx.)	
Rear door lock assembly LH					
Connector	Terminal				
D55	1	Ground	Door lock and unlock switch	Lock	12 V
	2			Unlock	

### Is the inspection result normal?

- YES >> Replace rear door lock assembly LH.  
 NO >> GO TO 2.

## 2.CHECK DOOR LOCK ACTUATOR CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and rear door lock assembly LH harness connector.

# DOOR LOCK ACTUATOR

## < DTC/CIRCUIT DIAGNOSIS >

BCM		Rear door lock assembly LH		Continuity
Connector	Terminal	Connector	Terminal	
M122	55	D55	2	Existed
	65		1	

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M122	55		Not existed
	65		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

### 3.CHECK BCM OUTPUT SIGNAL

1. Connect BCM connector.
2. Check voltage between BCM harness connector and ground.

(+)		(-)	Condition	Voltage (Approx.)
BCM				
Connector	Terminal			
M122	55	Ground	Door lock and unlock switch	Unlock
	65			Lock
				12 V

Is the inspection result normal?

YES >> Check for internal short of each door lock actuator and fuel lid lock actuator.

NO >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

## REAR RH

### REAR RH : Component Function Check

INFOID:000000005946915

DLK

#### 1.CHECK FUNCTION

1. Select "DOOR LOCK" of "BCM" using CONSULT-III.
2. Select "DOOR LOCK" in "ACTIVE TEST" mode.
3. Touch "ALL LCK" or "ALL UNLK" to check that it works normally.

Is the inspection result normal?

YES >> Door lock actuator is OK.

NO >> Refer to [DLK-91, "REAR RH : Diagnosis Procedure"](#).

### REAR RH : Diagnosis Procedure

INFOID:000000005946916

#### 1.CHECK DOOR LOCK ACTUATOR OUTPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect rear door lock assembly RH.
3. Check voltage between rear door lock assembly RH harness connector and ground.

(+)		(-)	Condition	Voltage (Approx.)
Rear door lock assembly RH				
Connector	Terminal			
D75	1	Ground	Door lock and unlock switch	Unlock
	2			Lock
				12 V

# DOOR LOCK ACTUATOR

## < DTC/CIRCUIT DIAGNOSIS >

### Is the inspection result normal?

- YES >> Replace rear door lock assembly RH.  
 NO >> GO TO 2.

## 2. CHECK DOOR LOCK ACTUATOR CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and rear door lock assembly RH harness connector.

BCM		Rear door lock assembly RH		Continuity
Connector	Terminal	Connector	Terminal	
M122	55	D75	1	Existed
	65		2	

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M122	55		Not Existed
	65		

### Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> Repair or replace harness.

## 3. CHECK BCM OUTPUT SIGNAL

1. Connect BCM connector.
2. Check voltage between BCM harness connector and ground.

(+)		(-)	Condition		Voltage (Approx.)
BCM					
Connector	Terminal				
M122	55	Ground	Door lock and unlock switch	Unlock	12 V
	65			Lock	

### Is the inspection result normal?

- YES >> Check for internal short of each door lock actuator and fuel lid lock actuator.  
 NO >> Replace BCM. Refer to [BCS-79. "Removal and Installation"](#).

# FUEL LID LOCK ACTUATOR

< DTC/CIRCUIT DIAGNOSIS >

## FUEL LID LOCK ACTUATOR

### Component Function Check

INFOID:000000005946917

#### 1.CHECK FUNCTION

1. Select "DOOR LOCK" of "BCM" using CONSULT-III.
2. Select "DOOR LOCK" in "ACTIVE TEST" mode.
3. Touch "ALL LCK" or "ALL UNLK" to check that it works normally.

Is the inspection result normal?

- YES >> Fuel lid lock actuator is OK.  
 NO >> Refer to [DLK-93. "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005946918

#### 1.CHECK FUEL LID LOCK ACTUATOR INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect fuel lid lock actuator.
3. Check voltage between fuel lid lock actuator harness connector and ground.

(+)		(-)	Condition		Voltage (Approx.)
Fuel lid lock actuator					
Connector	Terminal	Ground	Door lock and unlock switch	Unlock	12 V
B242	1				
	2				

Is the inspection result normal?

- YES >> Replace fuel lid lock actuator.  
 NO >> GO TO 2.

#### 2.CHECK FUEL LID LOCK ACTUATOR CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and all door lock actuator harness connector.

BCM		Fuel lid lock actuator		Continuity
Connector	Terminal	Connector	Terminal	
M122	65	B242	2	Existed
	66		1	

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M122	65		Not existed
	66		

Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> Repair or replace harness.

#### 3.CHECK BCM OUTPUT SIGNAL

1. Connect BCM connector.
2. Check voltage between BCM harness connector and ground.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

DLK

# FUEL LID LOCK ACTUATOR

## < DTC/CIRCUIT DIAGNOSIS >

(+)		(-)	Condition		Voltage (Approx.)
BCM					
Connector	Terminal				
M122	65	Ground	Door lock and unlock switch	Lock	12 V
	66			Unlock	

Is the inspection result normal?

YES >> Check for internal short of each door lock actuator.

NO >> Replace BCM. Refer to [BCS-79. "Removal and Installation"](#).

# TRUNK LID OPENER ACTUATOR

< DTC/CIRCUIT DIAGNOSIS >

## TRUNK LID OPENER ACTUATOR

### Component Function Check

INFOID:000000005946919

#### 1.CHECK FUNCTION

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT-III.
2. Select "TRUNK/GLASS HATCH" in "ACTIVE TEST" mode.
3. Touch "OPEN" to check that it works normally.

Is the inspection result normal?

- YES >> Trunk lid opener actuator is OK.  
NO >> Refer to [DLK-95. "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005946920

#### 1.CHECK TRUNK LID OPENER INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect trunk lid lock assembly (trunk lid opener actuator) connector.
3. Check voltage between trunk lid lock assembly (trunk lid opener actuator) harness connector and ground.

(+)		(-)	Condition	Voltage (Approx.)
Trunk lid lock assembly (trunk lid opener actuator)				
Connector	Terminal			
T3	3	Ground	Trunk lid opener switch is ON	12 V

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> GO TO 2.

#### 2.CHECK TRUNK LID OPENER ACTUATOR CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and trunk lid lock assembly (trunk lid opener actuator) harness connector.

BCM		Trunk lid lock assembly (trunk lid opener actuator)		Continuity
Connector	Terminal	Connector	Terminal	
M121	53	T3	3	Existed

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M121	53		Not existed

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-79. "Removal and Installation"](#).  
NO >> Repair or replace harness.

#### 3.CHECK TRUNK LID OPENER ACTUATOR GROUND CIRCUIT

Check continuity between trunk lid lock assembly (trunk lid opener actuator) harness connector and ground.

Trunk lid lock assembly (trunk lid opener actuator)		Ground	Continuity
Connector	Terminal		
T3	2		Existed

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

DLK

## TRUNK LID OPENER ACTUATOR

< DTC/CIRCUIT DIAGNOSIS >

---

Is the inspection normal?

- YES >> Replace trunk lid lock assembly (trunk lid opener actuator).
- NO >> Repair or replace harness.



# REMOTE KEYLESS ENTRY RECEIVER

< DTC/CIRCUIT DIAGNOSIS >

## REMOTE KEYLESS ENTRY RECEIVER

### Component Function Check

INFOID:000000006071734

#### 1.CHECK FUNCTION

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT-III.
2. Select "RKE OPE COUN1" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

Monitor item	Condition
RKE OPE COUN1	Check whether value changes when operating Intelligent Key

Is the inspection result normal?



- YES >> Remote keyless entry receiver is OK.  
 NO >> Refer to [DLK-97. "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000006071735

#### 1.CHECK REMOTE KEYLESS ENTRY RECEIVER OUTPUT SIGNAL

1. Turn ignition switch OFF.
2. Check signal between remote keyless entry receiver harness connector and ground using oscilloscope.

(+)		(-)	Condition	Signal (Reference value)
Remote keyless entry receiver Connector	Terminal			
M104	2	Ground	Waiting	 <p>JMKIA3838GB</p>
			Signal receiving	 <p>JMKIA3841GB</p>

Is the inspection result normal?

- YES >> GO TO 2.  
 NO >> GO TO 3.

#### 2.CHECK REMOTE KEYLESS ENTRY RECEIVER CIRCUIT 1

1. Disconnect BCM and remote keyless entry receiver connector
2. Check continuity between BCM harness connector and remote keyless entry receiver harness connector.

BCM		Remote keyless entry receiver		Continuity
Connector	Terminal	Connector	Terminal	
M120	20	M104	2	Existed

Is the inspection result normal?

- YES >> GO TO 8.  
 NO >> Repair or replace harness.

# REMOTE KEYLESS ENTRY RECEIVER

## < DTC/CIRCUIT DIAGNOSIS >

### 3. CHECK REMOTE KEYLESS ENTRY RECEIVER CIRCUIT 2

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and ground.


BCM		Ground	Continuity
Connector	Terminal		
M120	20		Not existed

Is the inspection result normal?

- YES >> GO TO 4.  
 NO >> Repair or replace harness.

### 4. CHECK REMOTE KEYLESS ENTRY RECEIVER POWER SUPPLY

1. Disconnect remote keyless entry receiver.
2. Check signal between remote keyless entry receiver harness connector and ground using oscilloscope.

(+)		(-)	Signal (Reference value)
Remote keyless entry receiver			
Connector	Terminal		
M104	4	Ground	 <p style="text-align: right; font-size: small;">JMKIA3838GB</p>

Is the inspection result normal?

- YES >> GO TO 6.  
 NO >> GO TO 5.

### 5. CHECK REMOTE KEYLESS ENTRY RECEIVER CIRCUIT 3

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and remote keyless entry receiver harness connector.

BCM		Remote keyless entry receiver		Continuity
Connector	Terminal	Connector	Terminal	
M120	19	M104	4	Existed

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M120	19		Not existed

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).  
 NO >> Repair or replace harness.

### 6. CHECK REMOTE KEYLESS ENTRY RECEIVER GROUND CIRCUIT 1

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and remote keyless entry receiver harness connector.

BCM		Remote keyless entry receiver		Continuity
Connector	Terminal	Connector	Terminal	
M120	18	M104	1	Existed

# REMOTE KEYLESS ENTRY RECEIVER

## < DTC/CIRCUIT DIAGNOSIS >

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M120	18		Not existed

Is the inspection result normal?

- YES >> GO TO 7.  
 NO >> Repair or replace harness.

## 7. CHECK REMOTE KEYLESS ENTRY RECEIVER GROUND CIRCUIT 2

1. Connect BCM connector.
2. Check continuity between BCM harness connector and ground.


BCM		Ground	Continuity
Connector	Terminal		
M120	18		Existed

Is the inspection result normal?

- YES >> Replace remote keyless entry receiver.  
 NO >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

## 8. CHECK REMOTE KEYLESS ENTRY RECEIVER RSSI OUTPUT SIGNAL

1. Connect BCM and remote keyless entry receiver connector.
2. Check signal between remote keyless entry receiver harness connector and ground using oscilloscope.

(+)		(-)	Condition	Signal (Reference value)
Remote keyless entry receiver Connector	Terminal			
M104	3	Ground	Waiting	0 V
			Signal receiving	

Is the inspection result normal?

- YES >> GO TO 9.  
 NO >> Replace remote keyless entry receiver.

## 9. CHECK REMOTE KEYLESS ENTRY RECEIVER RSSI CIRCUIT

1. Disconnect BCM and remote keyless entry receiver connector.
2. Check continuity between BCM harness connector and remote keyless entry receiver harness connector.

BCM		Remote keyless entry receiver		Continuity
Connector	Terminal	Connector	Terminal	
M120	22	M104	3	Existed

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).  
 NO >> Repair or replace harness.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

DLK

# UNLOCK SENSOR

< DTC/CIRCUIT DIAGNOSIS >

## UNLOCK SENSOR

### Component Function Check

INFOID:000000005946938

#### 1.CHECK FUNCTION

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT-III.
2. Select "UNLK SEN -DR" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

Monitor item	Condition		Status
UNLK SEN -DR	Driver side door	Lock	Off
		Unlock	On

Is the inspection result normal?

YES >> Unlock sensor is OK.


NO >> Refer to [DLK-100. "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005946939

#### 1.CHECK BCM OUTPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front door lock assembly (driver side) connector.
3. Check signal between front door lock assembly (driver side) harness connector and ground with oscilloscope.

(+)		(-)	Signal (Reference value)
Connector	Terminal		
D15	3	Ground	 <p>PKIB4960J</p>

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

#### 2.CHECK UNLOCK SENSOR CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and front door lock assembly (driver side) harness connector.

BCM		Front door lock assembly (driver side)		Continuity
Connector	Terminal	Connector	Terminal	
M120	31	D15	3	Existed

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M120	31		Not existed

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-79. "Removal and Installation"](#).

# UNLOCK SENSOR

## < DTC/CIRCUIT DIAGNOSIS >

NO >> Repair or replace harness.

### 3.CHECK UNLOCK SENSOR GROUND CIRCUIT

Check continuity between front door lock assembly (driver side) harness connector and ground.

Front door lock assembly (driver side)		Ground	Continuity
Connector	Terminal		
D15	4		Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

### 4.CHECK UNLOCK SENSOR

Refer to [DLK-101, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace front door lock assembly (driver side).

### 5.CHECK INTERMITTENT INCIDENT

Refer to [GI-38, "Intermittent Incident"](#).

>> INSPECTION END

## Component Inspection

INFOID:000000005946940

### 1.CHECK UNLOCK SENSOR

1. Turn ignition switch OFF.
2. Disconnect front door lock assembly (driver side).
3. Check front door lock assembly (driver side) terminals.

Front door lock assembly (driver side)		Condition	Continuity
Terminal			
3	4	Front door lock assembly (driver side)	Existed
			Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace front door lock assembly (driver side).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

DLK

# INTELLIGENT KEY WARNING BUZZER

< DTC/CIRCUIT DIAGNOSIS >

## INTELLIGENT KEY WARNING BUZZER

### Component Function Check

INFOID:000000005946943

#### 1.CHECK FUNCTION

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT-III.
2. Select "OUTSIDE BUZZER" in "ACTIVE TEST" mode.
3. Touch "ON" to check that it works normally.

Is the inspection result normal?

- YES >> Intelligent Key warning buzzer is OK.  
NO >> Refer to [DLK-102, "Diagnosis Procedure"](#).

#### Diagnosis Procedure

INFOID:000000005946944

#### 1.CHECK FUSE

1. Turn ignition switch OFF.
2. Check 10 A fuse, [No.11, located in fuse block (J/B)].

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.

#### 2.CHECK INTELLIGENT KEY WARNING BUZZER POWER SUPPLY CIRCUIT

1. Disconnect Intelligent Key warning buzzer connector.
2. Check voltage between Intelligent Key warning buzzer harness connector and ground.

(+)		(-)	Voltage (Approx.)
Connector	Terminal		
E57	1	Ground	12 V

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair or replace harness.

#### 3.CHECK INTELLIGENT KEY WARNING BUZZER CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and Intelligent Key warning buzzer harness connector.

BCM		Intelligent Key warning buzzer		Continuity
Connector	Terminal	Connector	Terminal	
M123	93	E57	3	Existed

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M123	93		Not existed

Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Repair or replace harness.

#### 4.CHECK INTELLIGENT KEY WARNING BUZZER

Check [DLK-103, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).  
NO >> Replace Intelligent Key warning buzzer.

# INTELLIGENT KEY WARNING BUZZER

< DTC/CIRCUIT DIAGNOSIS >

## Component Inspection

INFOID:000000005946945

### 1. CHECK INTELLIGENT KEY WARNING BUZZER

1. Turn ignition switch OFF.
2. Disconnect Intelligent Key warning buzzer connector.
3. Connect battery power supply directly to Intelligent Key warning buzzer terminals and check the operation.

Intelligent Key warning buzzer		Operation
Terminal		
(+)	(-)	
1	3	Buzzer sounds

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace Intelligent Key warning buzzer (engine room).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

DLK

# INTELLIGENT KEY

< DTC/CIRCUIT DIAGNOSIS >

## INTELLIGENT KEY

### Component Function Check

INFOID:000000005946946

#### 1.CHECK FUNCTION

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT-III.
2. Select "RKE OPE COUN1" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

Monitor item	Condition
RKE OPE COUN1	Check that the numerical value is changing while operating on the Intelligent Key

Is the inspection result normal?

- YES >> Intelligent Key is OK.  
NO >> Refer to [DLK-104, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005946947


#### 1.CHECK INTELLIGENT KEY BATTERY

Check by connecting a resistance (approximately 300 Ω) so that the current value becomes approximately 10 mA.

**Standard : Approx. 2.5 - 3.0 V**

Is the measurement value within the specification?

- YES >> Replace Intelligent Key.  
NO >> Replace Intelligent Key battery.



### Special Repair Requirement

INFOID:000000005946948

Refer to CONSULT-III Operation Manual NATS-IVIS/NVIS.



# INFORMATION DISPLAY

< DTC/CIRCUIT DIAGNOSIS >

## INFORMATION DISPLAY

### Component Function Check

INFOID:000000005946955

#### 1.CHECK FUNCTION

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT-III.
2. Select "LCD" in "ACTIVE TEST" mode.
3. Check each warning display on meter display.

Is the inspection result normal?

YES >> Information display is OK.

NO >> Refer to [DLK-105. "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005946956

#### 1.CHECK COMBINATION METER

Refer to [MWI-29. "On Board Diagnosis Function"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

#### 2.CHECK INTERMITTENT INCIDENT

Refer to [GI-38. "Intermittent Incident"](#).

>> INSPECTION END

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

DLK

# COMBINATION METER BUZZER

< DTC/CIRCUIT DIAGNOSIS >

---

## COMBINATION METER BUZZER

### Component Function Check

INFOID:000000005946957

#### 1.CHECK FUNCTION

---

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT-III.
2. Select "INSIDE BUZZER" in "ACTIVE TEST" mode.
3. Touch "Take out", "Knob" or "Key" to check that it works normally.

Is the inspection result normal?

- Yes >> Warning buzzer into combination meter is OK.  
No >> Refer to [DLK-106, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005946958

#### 1.CHECK METER BUZZER CIRCUIT

---

Refer to [WCS-41, "Component Function Check"](#).

Is the inspection result normal?

- Yes >> GO TO 2.  
No >> Repair or replace the malfunctioning parts.

#### 2.CHECK INTERMITTENT INCIDENT

---

Refer to [GI-38, "Intermittent Incident"](#).

>> INSPECTION END

# HAZARD FUNCTION

< DTC/CIRCUIT DIAGNOSIS >

## HAZARD FUNCTION

### Component Function Check

INFOID:000000005946961

#### 1.CHECK FUNCTION

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT-III.
2. Select "FLASHER" in "ACTIVE TEST" mode.
3. Touch "LH" or "RH" to check that it works normally.

Is the inspection result normal?

YES >> Hazard warning lamp circuit is OK.

NO >> Refer to [DLK-107. "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005946962

#### 1.CHECK HAZARD SWITCH CIRCUIT

Check hazard switch circuit.

Refer to [EXL-104. "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

#### 2.CHECK INTERMITTENT INCIDENT

Refer to [GI-38. "Intermittent Incident"](#).

>> INSPECTION END

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

DLK

# DOOR DOES NOT LOCK/UNLOCK WITH DOOR LOCK AND UNLOCK SWITCH

< SYMPTOM DIAGNOSIS >

## SYMPTOM DIAGNOSIS

### DOOR DOES NOT LOCK/UNLOCK WITH DOOR LOCK AND UNLOCK SWITCH

#### ALL DOOR

##### ALL DOOR : Description

INFOID:000000005946963

All doors do not lock/unlock using door lock and unlock switch.

##### ALL DOOR : Diagnosis Procedure

INFOID:000000005946964

#### 1.CHECK DOOR LOCK AND UNLOCK SWITCH

Check door lock and unlock switch.

Refer to [DLK-75, "Component Function Check"](#)

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

#### 2.CHECK DOOR LOCK ACTUATOR CIRCUIT

Check front door lock assembly (driver side).

Refer to [DLK-88, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

#### 3.REPLACE BCM

- Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).
- Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-38, "Intermittent Incident"](#).

#### DRIVER SIDE

##### DRIVER SIDE : Description

INFOID:000000005946965

Driver side door does not lock/unlock using door lock and unlock switch.

##### DRIVER SIDE : Diagnosis Procedure

INFOID:000000005946966

#### 1.CHECK DOOR LOCK ACTUATOR

Check front door lock assembly (driver side).

Refer to [DLK-88, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

#### 2.REPLACE BCM

- Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).
- Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-38, "Intermittent Incident"](#).

#### PASSENGER SIDE

# DOOR DOES NOT LOCK/UNLOCK WITH DOOR LOCK AND UNLOCK SWITCH

< SYMPTOM DIAGNOSIS >

## PASSENGER SIDE : Description

INFOID:000000005946967

Passenger side door does not lock/unlock using door lock and unlock switch.

## PASSENGER SIDE : Diagnosis Procedure

INFOID:000000005946968

### 1.CHECK DOOR LOCK ACTUATOR

Check front door lock assembly (passenger side).

Refer to [DLK-89, "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

### 2.REPLACE BCM

- Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).
- Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-38, "Intermittent Incident"](#).

## REAR LH

### REAR LH : Description

INFOID:000000005946969

Rear LH side door does not lock/unlock using door lock and unlock switch.

### REAR LH : Diagnosis Procedure

INFOID:000000005946970

### 1.CHECK DOOR LOCK ACTUATOR

Check rear door lock assembly LH.

Refer to [DLK-90, "REAR LH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

### 2.REPLACE BCM

- Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).
- Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-38, "Intermittent Incident"](#).

## REAR RH

### REAR RH : Description

INFOID:000000005946971

Rear RH side door does not lock/unlock using door lock and unlock switch.

### REAR RH : Diagnosis Procedure

INFOID:000000005946972

### 1.CHECK DOOR LOCK ACTUATOR

Check rear door lock assembly RH.

Refer to [DLK-91, "REAR RH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

### 2.REPLACE BCM

- Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

## DOOR DOES NOT LOCK/UNLOCK WITH DOOR LOCK AND UNLOCK SWITCH

< SYMPTOM DIAGNOSIS >

---

- Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-38, "Intermittent Incident"](#).

# DOOR DOES NOT LOCK/UNLOCK WITH DOOR KEY CYLINDER OPERATION

< SYMPTOM DIAGNOSIS >

## DOOR DOES NOT LOCK/UNLOCK WITH DOOR KEY CYLINDER OPERATION

### Diagnosis Procedure

INFOID:000000006059496

#### 1.CHECK POWER DOOR LOCK OPERATION

Check power door lock operation.

Does door lock/unlock with door lock and unlock switch?

YES >> GO TO 2.

NO >> Refer to [DLK-108, "ALL DOOR : Diagnosis Procedure"](#).

#### 2.CHECK DOOR KEY CYLINDER SWITCH

Check door key cylinder switch.

Refer to [DLK-76, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

#### 3.REPLACE BCM

• Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

• Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-38, "Intermittent Incident"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

DLK

# DOOR DOES NOT LOCK/UNLOCK WITH DOOR REQUEST SWITCH

< SYMPTOM DIAGNOSIS >

---

## DOOR DOES NOT LOCK/UNLOCK WITH DOOR REQUEST SWITCH ALL DOOR

ALL DOOR : Description

INFOID:000000005946973

All doors do not lock/unlock using all door request switches.

ALL DOOR : Diagnosis Procedure

INFOID:000000005946974

### 1. CHECK REMOTE KEYLESS ENTRY FUNCTION

---

Check remote keyless entry function.

Does door lock/unlock with Intelligent Key button?

YES >> GO TO 2.

NO >> Refer to [DLK-114, "Diagnosis Procedure"](#).

### 2. CHECK "LOCK/UNLOCK BY I-KEY" SETTING IN "WORK SUPPORT"

---

Check "LOCK/UNLOCK BY I-KEY" in "WORK SUPPORT".

Refer to [DLK-32, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Set "LOCK/UNLOCK BY I-KEY" in "WORK SUPPORT".

### 3. CHECK DOOR SWITCH

---

Check door switch.

Refer to [DLK-72, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

### 4. CHECK INSIDE KEY ANTENNA

---

Check inside key antenna.

• Instrument center: Refer to [DLK-60, "DTC Logic"](#).

• Console: Refer to [DLK-62, "DTC Logic"](#).

• Trunk room: Refer to [DLK-64, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

### 5. CHECK OUTSIDE KEY ANTENNA

---

Check outside key antenna.

• Driver side: Refer to [DLK-66, "DTC Logic"](#).

• Passenger side: Refer to [DLK-68, "DTC Logic"](#).

• Rear bumper: Refer to [DLK-70, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the malfunctioning parts.

### 6. REPLACE BCM

---

• Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

• Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-38, "Intermittent Incident"](#).

DRIVER SIDE



# DOOR DOES NOT LOCK/UNLOCK WITH DOOR REQUEST SWITCH

< SYMPTOM DIAGNOSIS >

## DRIVER SIDE : Description

INFOID:000000005946975

All doors do not lock/unlock using driver side door request switch.

## DRIVER SIDE : Diagnosis Procedure

INFOID:000000005946976

### 1.CHECK DRIVER SIDE DOOR REQUEST SWITCH

Check driver side door request switch.

Refer to [DLK-78, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

### 2.REPLACE BCM

- Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).
- Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-38, "Intermittent Incident"](#).

## PASSENGER SIDE

## PASSENGER SIDE : Description

INFOID:000000005946977

All doors do not lock/unlock using passenger side door request switch.

## PASSENGER SIDE : Diagnosis Procedure

INFOID:000000005946978

### 1.CHECK PASSENGER SIDE DOOR REQUEST SWITCH

Check passenger side door request switch.

Refer to [DLK-78, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

### 2.REPLACE BCM

- Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).
- Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-38, "Intermittent Incident"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

DLK

# DOOR DOES NOT LOCK/UNLOCK WITH INTELLIGENT KEY

< SYMPTOM DIAGNOSIS >

---

## DOOR DOES NOT LOCK/UNLOCK WITH INTELLIGENT KEY

### Diagnosis Procedure

INFOID:000000005946979

#### 1.CHECK POWER DOOR LOCK OPERATION

---

Check power door lock operation.

Does door lock/unlock with door lock and unlock switch?

YES >> GO TO 2.

NO >> Refer to [DLK-108, "ALL DOOR : Diagnosis Procedure"](#).

#### 2.CHECK REMOTE KEYLESS ENTRY RECEIVER

---

Check remote keyless entry receiver.

Refer to [DLK-97, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

#### 3.CHECK INTELLIGENT KEY

---

Check Intelligent Key.

Refer to [DLK-104, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

#### 4.REPLACE BCM

---

• Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

• Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-38, "Intermittent Incident"](#).

# TRUNK LID DOES NOT OPEN

< SYMPTOM DIAGNOSIS >

## TRUNK LID DOES NOT OPEN

### TRUNK LID OPENER SWITCH

#### TRUNK LID OPENER SWITCH : Description

INFOID:000000005946980

Trunk lid does not open by trunk lid opener switch operation.

#### TRUNK LID OPENER SWITCH : Diagnosis Procedure

INFOID:000000005946981

### 1.CHECK TRUNK LID OPENER SWITCH

Check trunk lid opener switch.

Refer to [DLK-82, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

### 2.CHECK TRUNK LID OPENER CANCEL SWITCH

Check trunk lid opener cancel switch.

Refer to [DLK-84, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

### 3.CHECK TRUNK LID OPENER ACTUATOR

Check trunk lid opener actuator.

Refer to [DLK-95, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

### 4.REPLACE BCM

• Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

• Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-38, "Intermittent Incident"](#).

## INTELLIGENT KEY

#### INTELLIGENT KEY : Description

INFOID:000000005946982

Trunk lid does not open by Intelligent Key remote operation.

#### INTELLIGENT KEY : Diagnosis Procedure

INFOID:000000005946983

### 1.CHECK TRUNK LID OPEN FUNCTION

Check trunk lid open function with trunk lid opener switch.

Does trunk lid open with trunk lid opener switch?

YES >> GO TO 2.

NO >> Refer to [DLK-115, "TRUNK LID OPENER SWITCH : Diagnosis Procedure"](#).

### 2.CHECK REMOTE KEYLESS ENTRY FUNCTION

Check remote keyless entry function.

Does door lock/unlock with Intelligent Key button?

YES >> GO TO 3.

NO >> Refer to [DLK-114, "Diagnosis Procedure"](#).

### 3.CHECK INTELLIGENT KEY

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

# TRUNK LID DOES NOT OPEN

## < SYMPTOM DIAGNOSIS >

---

Check Intelligent Key.

Refer to [DLK-104, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

### 4.REPLACE BCM

---

• Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

• Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-38, "Intermittent Incident"](#).

## TRUNK LID OPENER REQUEST SWITCH

### TRUNK LID OPENER REQUEST SWITCH : Description

INFOID:000000005946984

Trunk lid does not open by trunk lid opener request switch operation.

### TRUNK LID OPENER REQUEST SWITCH : Diagnosis Procedure

INFOID:000000005946985

#### 1.CHECK TRUNK LID OPEN FUNCTION

---

Check trunk lid open function with Intelligent Key.

Does trunk lid open with Intelligent Key?

YES >> GO TO 2.

NO >> Refer to [DLK-115, "INTELLIGENT KEY : Diagnosis Procedure"](#).

#### 2.CHECK TRUNK LID OPENER REQUEST SWITCH

---

Check trunk lid opener request switch.

Refer to [DLK-80, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

#### 3.CHECK OUTSIDE KEY ANTENNA (REAR BUMPER)

---

Check outside key antenna (rear bumper).

Refer to [DLK-70, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

#### 4.CHECK TRUNK ROOM LAMP SWITCH

---

Check trunk room lamp switch.

Refer to [DLK-86, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

#### 5.REPLACE BCM

---

• Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

• Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-38, "Intermittent Incident"](#).

# FUEL LID LOCK ACTUATOR DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

## FUEL LID LOCK ACTUATOR DOES NOT OPERATE

### Diagnosis Procedure

INFOID:000000005946986

#### 1.CHECK POWER DOOR LOCK OPERATION

Check power door lock operation.

Does door lock/unlock with door lock and unlock switch?

YES >> GO TO 2.

NO >> Refer to [DLK-108, "ALL DOOR : Diagnosis Procedure"](#).

#### 2.CHECK FUEL LID LOCK ACTUATOR

Check fuel lid lock actuator.

Refer to [DLK-93, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

#### 3.REPLACE BCM

• Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

• Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-38, "Intermittent Incident"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

DLK

# IGNITION POSITION WARNING FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

---

## IGNITION POSITION WARNING FUNCTION DOES NOT OPERATE

### Diagnosis Procedure

INFOID:000000006090447

#### 1. CHECK POWER DOOR LOCK OPERATION

---

Check power door lock operation.

Does door lock/unlock with door lock and unlock switch?

YES >> GO TO 2.

NO >> Refer to [DLK-108, "ALL DOOR : Diagnosis Procedure"](#).

#### 2. CHECK DOOR SWITCH

---

Check door switch.

Refer to [DLK-72, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

#### 3. CHECK TRUNK ROOM LAMP SWITCH

---

Check trunk room lamp switch.

Refer to [DLK-86, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

#### 4. REPLACE BCM

---

• Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

• Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-38, "Intermittent Incident"](#).

# SELECTIVE UNLOCK FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

## SELECTIVE UNLOCK FUNCTION DOES NOT OPERATE

### Diagnosis Procedure

INFOID:000000005946987

#### 1. CHECK "DOOR LOCK-UNLOCK SET" SETTING IN "WORK SUPPORT"

1. Select "DOOR LOCK" of "BCM" using CONSULT-III.
2. Select "DOOR LOCK-UNLOCK SET" in "WORK SUPPORT" mode.
3. Check "DOOR LOCK-UNLOCK SET" setting in "WORK SUPPORT".  
Refer to [DLK-30, "DOOR LOCK : CONSULT-III Function \(BCM - DOOR LOCK\)"](#).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Set "ON" in "DOOR LOCK-UNLOCK SET".

#### 2. REPLACE BCM

- Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).
- Confirm the operation after replacement.

Is the result normal?

- YES >> INSPECTION END  
NO >> Check intermittent incident. Refer to [GI-38, "Intermittent Incident"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

DLK

# VEHICLE SPEED SENSING AUTO LOCK OPERATION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

## VEHICLE SPEED SENSING AUTO LOCK OPERATION DOES NOT OPERATE

### Diagnosis Procedure

INFOID:000000005946988

#### 1. CHECK "AUTOMATIC LOCK/UNLOCK SELECT" SETTING IN "WORK SUPPORT"

---

1. Select "DOOR LOCK" of "BCM" using CONSULT-III.
2. Select "AUTOMATIC LOCK/UNLOCK SELECT" in "WORK SUPPORT" mode.
3. Check "AUTOMATIC LOCK/UNLOCK SELECT" setting in "WORK SUPPORT".  
Refer to [DLK-30, "DOOR LOCK : CONSULT-III Function \(BCM - DOOR LOCK\)"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Set "Lock Only" or "Lock/Unlock" in "AUTOMATIC LOCK/UNLOCK SELECT".

#### 2. CHECK "AUTOMATIC DOOR LOCK SELECT" SETTING IN "WORK SUPPORT"

---

1. Select "DOOR LOCK" of "BCM" using CONSULT-III.
2. Select "AUTOMATIC DOOR LOCK SELECT" in "WORK SUPPORT" mode.
3. Check "AUTOMATIC DOOR LOCK SELECT" setting in "WORK SUPPORT".  
Refer to [DLK-30, "DOOR LOCK : CONSULT-III Function \(BCM - DOOR LOCK\)"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Set "VH SPD" in "AUTOMATIC DOOR LOCK SELECT".

#### 3. REPLACE BCM

---

- Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).
- Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-38, "Intermittent Incident"](#).



# IGN OFF INTERLOCK DOOR UNLOCK FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

## IGN OFF INTERLOCK DOOR UNLOCK FUNCTION DOES NOT OPERATE

### Diagnosis Procedure

INFOID:000000005946989

#### 1. CHECK "AUTOMATIC LOCK/UNLOCK SELECT" SETTING IN "WORK SUPPORT"

1. Select "DOOR LOCK" of "BCM" using CONSULT-III.
2. Select "AUTOMATIC LOCK/UNLOCK SELECT" in "WORK SUPPORT" mode.
3. Check "AUTOMATIC LOCK/UNLOCK SELECT" setting in "WORK SUPPORT".  
Refer to [DLK-30, "DOOR LOCK : CONSULT-III Function \(BCM - DOOR LOCK\)"](#).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Set "Unlock Only" or "Lock/Unlock" in "AUTOMATIC LOCK/UNLOCK SELECT".

#### 2. CHECK "AUTOMATIC DOOR UNLOCK SELECT" SETTING IN "WORK SUPPORT"

1. Select "DOOR LOCK" of "BCM" using CONSULT-III.
2. Select "AUTOMATIC DOOR UNLOCK SELECT" in "WORK SUPPORT" mode.
3. Check "AUTOMATIC DOOR UNLOCK SELECT" setting in "WORK SUPPORT".  
Refer to [DLK-30, "DOOR LOCK : CONSULT-III Function \(BCM - DOOR LOCK\)"](#).

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Set "MODE 1" or "MODE 3" in "AUTOMATIC DOOR UNLOCK SELECT".

#### 3. REPLACE BCM

- Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).
- Confirm the operation after replacement.

Is the result normal?

- YES >> INSPECTION END  
NO >> Check intermittent incident. Refer to [GI-38, "Intermittent Incident"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

DLK

# P RANGE INTERLOCK DOOR LOCK/UNLOCK FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

## P RANGE INTERLOCK DOOR LOCK/UNLOCK FUNCTION DOES NOT OPERATE

### Diagnosis Procedure

INFOID:000000005946990

#### 1. CHECK "AUTOMATIC LOCK/UNLOCK SELECT" SETTING IN "WORK SUPPORT"

---

1. Select "DOOR LOCK" of "BCM" using CONSULT-III.
2. Select "AUTOMATIC LOCK/UNLOCK SELECT" in "WORK SUPPORT" mode.
3. Check "AUTOMATIC LOCK/UNLOCK SELECT" setting in "WORK SUPPORT".  
Refer to [DLK-30, "DOOR LOCK : CONSULT-III Function \(BCM - DOOR LOCK\)"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Set "Unlock Only", "Lock Only" or "Lock/Unlock" in "AUTOMATIC LOCK/UNLOCK SELECT".

#### 2. CHECK "AUTOMATIC DOOR LOCK SELECT" SETTING IN "WORK SUPPORT"

---

1. Select "DOOR LOCK" of "BCM" using CONSULT-III.
2. Select "AUTOMATIC DOOR LOCK SELECT" in "WORK SUPPORT" mode.
3. Check "AUTOMATIC DOOR LOCK SELECT" setting in "WORK SUPPORT".  
Refer to [DLK-30, "DOOR LOCK : CONSULT-III Function \(BCM - DOOR LOCK\)"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Set "P RANGE" in "AUTOMATIC DOOR LOCK SELECT".

#### 3. CHECK "AUTOMATIC DOOR UNLOCK SELECT" SETTING IN "WORK SUPPORT"

---

1. Select "DOOR LOCK" of "BCM" using CONSULT-III.
2. Select "AUTOMATIC DOOR UNLOCK SELECT" in "WORK SUPPORT" mode.
3. Check "AUTOMATIC DOOR UNLOCK SELECT" setting in "WORK SUPPORT".  
Refer to [DLK-30, "DOOR LOCK : CONSULT-III Function \(BCM - DOOR LOCK\)"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Set "MODE 2" or "MODE 4" in "AUTOMATIC DOOR UNLOCK SELECT".

#### 4. REPLACE BCM

---

- Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).
- Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-38, "Intermittent Incident"](#).

# AUTO DOOR LOCK OPERATION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

## AUTO DOOR LOCK OPERATION DOES NOT OPERATE

### Diagnosis Procedure

INFOID:000000005946991

#### 1. CHECK "AUTO LOCK SET" SETTING IN "WORK SUPPORT"

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT-III.
2. Select "AUTO LOCK SET" in "WORK SUPPORT" mode.
3. Check "AUTO LOCK SET" setting in "WORK SUPPORT".

Refer to [DLK-32, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Set "MODE 2", "MODE 3", "MODE 4", "MODE 5", "MODE 6" or "MODE 7" in "AUTO LOCK SET".

#### 2. REPLACE BCM

- Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).
- Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-38, "Intermittent Incident"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

DLK

# HAZARD AND HORN REMINDER DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

---

## HAZARD AND HORN REMINDER DOES NOT OPERATE

### Diagnosis Procedure

INFOID:000000005946992

---

#### 1. CHECK "HAZARD ANSWER BACK" SETTING IN "WORK SUPPORT"

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT-III.
2. Select "HAZARD ANSWER BACK" in "WORK SUPPORT" mode.
3. Check the "HAZARD ANSWER BACK" setting in "WORK SUPPORT".  
Refer to [DLK-32, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Set "Lock Only", "Unlock Only" or "Lock/Unlock" in "HAZARD ANSWER BACK".

---

#### 2. CHECK "HORN WITH KEYLESS LOCK" SETTING IN "WORK SUPPORT"

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT-III.
2. Select "HORN WITH KEYLESS LOCK" in "WORK SUPPORT" mode.
3. Check the "HORN WITH KEYLESS LOCK" setting in "WORK SUPPORT".  
Refer to [DLK-32, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Set "On" in "HORN WITH KEYLESS LOCK".

---

#### 3. CHECK HAZARD FUNCTION

Check hazard function.

Refer to [DLK-107, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Repair or replace the malfunctioning parts.

---

#### 4. CHECK HORN FUNCTION

Check horn function.

Refer to [SEC-138, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 5.  
NO >> Repair or replace the malfunctioning parts.

---

#### 5. REPLACE BCM

- Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).
- Confirm the operation after replacement.

Is the result normal?

- YES >> INSPECTION END  
NO >> Check intermittent incident. Refer to [GI-38, "Intermittent Incident"](#).

# HAZARD AND BUZZER REMINDER DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

## HAZARD AND BUZZER REMINDER DOES NOT OPERATE

### Diagnosis Procedure

INFOID:000000005946993

#### 1. CHECK "HAZARD ANSWER BACK" SETTING IN "WORK SUPPORT"

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT-III.
2. Select "HAZARD ANSWER BACK" in "WORK SUPPORT" mode.
3. Check the "HAZARD ANSWER BACK" setting in "WORK SUPPORT".  
Refer to [DLK-32, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)".](#)

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Set "Lock Only", "Unlock Only" or "Lock/Unlock" in "HAZARD ANSWER BACK".

#### 2. CHECK "ANS BACK I-KEY LOCK" SETTING IN "WORK SUPPORT"

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT-III.
2. Select "ANS BACK I-KEY LOCK" in "WORK SUPPORT" mode.
3. Check the "ANS BACK I-KEY LOCK" setting in "WORK SUPPORT".  
Refer to [DLK-32, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)".](#)

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Set "Horn Chirp" or "Buzzer" in "ANS BACK I-KEY LOCK".

#### 3. CHECK "ANS BACK I-KEY UNLOCK" SETTING IN "WORK SUPPORT"

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT-III.
2. Select "ANS BACK I-KEY UNLOCK" in "WORK SUPPORT" mode.
3. Check the "ANS BACK I-KEY UNLOCK" setting in "WORK SUPPORT".  
Refer to [DLK-32, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)".](#)

Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Set the "On" in "ANS BACK I-KEY UNLOCK".

#### 4. CHECK HAZARD FUNCTION

Check hazard function.  
Refer to [DLK-107, "Component Function Check".](#)

Is the inspection result normal?

- YES >> GO TO 5.  
NO >> Repair or replace the malfunctioning parts.

#### 5. CHECK INTELLIGENT KEY WARNING BUZZER

Check Intelligent Key warning buzzer.  
Refer to [DLK-102, "Component Function Check".](#)

Is the inspection result normal?

- YES >> GO TO 6.  
NO >> Repair or replace the malfunctioning parts.

#### 6. REPLACE BCM

- Replace BCM. Refer to [BCS-79, "Removal and Installation".](#)
- Confirm the operation after replacement.

Is the result normal?

- YES >> INSPECTION END  
NO >> Check intermittent incident. Refer to [GI-38, "Intermittent Incident".](#)

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

DLK

# KEY REMINDER FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

---

## KEY REMINDER FUNCTION DOES NOT OPERATE

### Diagnosis Procedure

INFOID:000000005946995

---

#### 1. CHECK "ANTI KEY LOCK IN FUNCTI" SETTING IN "WORK SUPPORT"

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT-III.
2. Select "ANTI KEY LOCK IN FUNCTI" in "WORK SUPPORT" mode.
3. Check "ANTI KEY LOCK IN FUNCTI" setting in "WORK SUPPORT".  
Refer to [DLK-32, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Set "On" in "ANTI KEY LOCK IN FUNCTI".

---

#### 2. CHECK INSIDE KEY ANTENNA

Check inside key antenna.

- Instrument center: Refer to [DLK-60, "DTC Logic"](#).
- Console: Refer to [DLK-62, "DTC Logic"](#).
- Trunk room: Refer to [DLK-64, "DTC Logic"](#).

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair or replace the malfunctioning parts.

---

#### 3. CHECK DOOR SWITCH

Check door switch.

Refer to [DLK-72, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Repair or replace the malfunctioning parts.

---

#### 4. CHECK TRUNK ROOM LAMP SWITCH

Check trunk room lamp switch.

Refer to [DLK-86, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 5.  
NO >> Repair or replace the malfunctioning parts.

---

#### 5. CHECK UNLOCK SENSOR

Check unlock sensor.

Refer to [DLK-100, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 6.  
NO >> Repair or replace the malfunctioning parts.

---

#### 6. REPLACE BCM

- Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).
- Confirm the operation after replacement.

Is the result normal?

- YES >> INSPECTION END  
NO >> Check intermittent incident. Refer to [GI-38, "Intermittent Incident"](#).

# WELCOME LIGHT FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

## WELCOME LIGHT FUNCTION DOES NOT OPERATE

### Diagnosis Procedure

INFOID:000000006059497

#### 1. CHECK "WELCOME LIGHT OP SET" SETTING IN "WORK SUPPORT"

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT-III.
2. Select "WELCOME LIGHT OP SET" in "WORK SUPPORT" mode.
3. Check "WELCOME LIGHT OP SET" setting in "WORK SUPPORT".  
Refer to [DLK-32, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Set "On" and "WELCOME LIGHT SELECT" in "WORK SUPPORT".

#### 2. CHECK "WELCOME LIGHT SELECT" SETTING IN "WORK SUPPORT"

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT-III.
2. Select "WELCOME LIGHT SELECT" in "WORK SUPPORT" mode.
3. Check "WELCOME LIGHT SELECT" setting in "WORK SUPPORT".  
Refer to [DLK-32, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Set "WELCOME LIGHT SELECT" setting in "WORK SUPPORT".

#### 3. CHECK INSIDE KEY ANTENNA

Check inside key antenna.

- Instrument center: Refer to [DLK-60, "DTC Logic"](#).
- Console: Refer to [DLK-62, "DTC Logic"](#).
- Trunk room: Refer to [DLK-64, "DTC Logic"](#).

Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Repair or replace the malfunctioning parts.

#### 4. CHECK OUTSIDE KEY ANTENNA

Check outside key antenna.

- Driver side: Refer to [DLK-66, "DTC Logic"](#).
- Passenger side: Refer to [DLK-68, "DTC Logic"](#).
- Rear bumper: Refer to [DLK-70, "DTC Logic"](#).

Is the inspection result normal?

- YES >> GO TO 5.  
NO >> Repair or replace the malfunctioning parts.

#### 5. CHECK REMOTE KEYLESS ENTRY FUNCTION

Check remote keyless entry function

Does door lock/unlock with Intelligent Key button?

- YES >> GO TO 6.  
NO >> Refer to [DLK-114, "Diagnosis Procedure"](#).

#### 6. CHECK INTERIOR ROOM LAMP CONTROL SYSTEM

Check interior room lamp control system. Refer to [INL-7, "INTERIOR ROOM LAMP CONTROL SYSTEM : System Description"](#).

Does the room lamp and puddle lamp turn ON?

- YES >> GO TO 7.  
NO >> Refer to [INL-66, "Symptom Table"](#).

#### 7. REPLACE BCM

- Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).
- Confirm the operation after replacement.

Is the result normal?

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

DLK

## WELCOME LIGHT FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

---

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-38, "Intermittent Incident"](#).



# OFF POSITION WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

## OFF POSITION WARNING DOES NOT OPERATE

### Diagnosis Procedure

INFOID:000000005946999

#### 1.CHECK DTC WITH BCM

Check that DTC is not detected with BCM.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Perform trouble diagnosis relevant to DTC indicated.

#### 2.CHECK DTC WITH COMBINATION METER

Check that DTC is not detected with combination meter.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Perform trouble diagnosis relevant to DTC indicated.

#### 3.CHECK COMBINATION METER BUZZER

Check combination meter buzzer.

Refer to [DLK-106. "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

#### 4.CHECK INTELLIGENT KEY WARNING BUZZER

Check Intelligent Key warning buzzer.

Refer to [DLK-102. "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

#### 5.CHECK DOOR SWITCH

Check door switch (driver side).

Refer to [DLK-72. "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the malfunctioning parts.

#### 6.REPLACE BCM

• Replace BCM. Refer to [BCS-79. "Removal and Installation"](#).

• Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-38. "Intermittent Incident"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

DLK

# P POSITION WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

---

## P POSITION WARNING DOES NOT OPERATE

### Diagnosis Procedure

INFOID:000000005947000

---

#### 1. CHECK DTC WITH BCM

Check that DTC is not detected with BCM.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Perform trouble diagnosis relevant to DTC indicated.

---

#### 2. CHECK DTC WITH COMBINATION METER

Check that DTC is not detected with combination meter.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Perform trouble diagnosis relevant to DTC indicated.

---

#### 3. CHECK INTELLIGENT KEY WARNING BUZZER

Check Intelligent Key warning buzzer.

Refer to [DLK-102, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

---

#### 4. CHECK COMBINATION METER BUZZER

Check combination meter buzzer.

Refer to [DLK-106, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

---

#### 5. CHECK DOOR SWITCH

Check door switch (driver side).

Refer to [DLK-72, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the malfunctioning parts.

---

#### 6. CHECK INFORMATION DISPLAY

Check information display.

Refer to [DLK-105, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace the malfunctioning parts.

---

#### 7. REPLACE BCM

• Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

• Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-38, "Intermittent Incident"](#).

# ACC WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

## ACC WARNING DOES NOT OPERATE

### Diagnosis Procedure

INFOID:000000005947001

#### 1.CHECK DTC WITH BCM

Check that DTC is not detected with BCM.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Perform trouble diagnosis relevant to DTC indicated.

#### 2.CHECK DTC WITH COMBINATION METER

Check that DTC is not detected with combination meter.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Perform trouble diagnosis relevant to DTC indicated.

#### 3.CHECK COMBINATION METER BUZZER

Check combination meter buzzer.

Refer to [DLK-106. "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

#### 4.CHECK INFORMATION DISPLAY

Check information display.

Refer to [DLK-105. "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

#### 5.REPLACE BCM

• Replace BCM. Refer to [BCS-79. "Removal and Installation"](#).

• Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-38. "Intermittent Incident"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

DLK

# TAKE AWAY WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

---

## TAKE AWAY WARNING DOES NOT OPERATE

### Diagnosis Procedure

INFOID:000000005947002

---

#### 1.CHECK DTC WITH BCM

Check that DTC is not detected with BCM.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Perform trouble diagnosis relevant to DTC indicated.

---

#### 2.CHECK DTC WITH COMBINATION METER

Check that DTC is not detected with combination meter.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Perform trouble diagnosis relevant to DTC indicated.

---

#### 3.CHECK DOOR SWITCH

Check door switch.

Refer to [DLK-72, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

---

#### 4.CHECK TRUNK ROOM LAMP SWITCH

Check trunk room lamp switch.

Refer to [DLK-86, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

---

#### 5.CHECK COMBINATION METER BUZZER

Check combination meter buzzer.

Refer to [DLK-106, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the malfunctioning parts.

---

#### 6.CHECK INFORMATION DISPLAY

Check information display.

Refer to [DLK-105, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace the malfunctioning parts.

---

#### 7.CHECK INTELLIGENT KEY WARNING BUZZER

Check Intelligent Key warning buzzer.

Refer to [DLK-102, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair or replace the malfunctioning parts.

---

#### 8.REPLACE BCM

- Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).
- Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

# TAKE AWAY WARNING DOES NOT OPERATE

## < SYMPTOM DIAGNOSIS >

---

NO >> Check intermittent incident. Refer to [GI-38. "Intermittent Incident"](#).

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

# INTELLIGENT KEY LOW BATTERY WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

---

## INTELLIGENT KEY LOW BATTERY WARNING DOES NOT OPERATE

### Diagnosis Procedure

INFOID:000000005947003

---

#### 1. CHECK DTC WITH BCM

Check that DTC is not detected with BCM.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Perform trouble diagnosis relevant to DTC indicated.

---

#### 2. CHECK DTC WITH COMBINATION METER

Check that DTC is not detected with combination meter.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Perform trouble diagnosis relevant to DTC indicated.

---

#### 3. CHECK "LO- BATT OF KEY FOB WARN" SETTING IN "WORK SUPPORT"

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT-III.

2. Select "LO- BATT OF KEY FOB WARN" in "WORK SUPPORT" mode.

3. Check "LO-BATT OF KEY FOB WARN" setting in "WORK SUPPORT".

Refer to [DLK-32, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Set "ON" setting in "WORK SUPPORT".

---

#### 4. CHECK INTELLIGENT KEY

Check Intelligent Key.

Refer to [DLK-104, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

---

#### 5. CHECK INFORMATION DISPLAY

Check information display.

Refer to [DLK-105, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the malfunctioning parts.

---

#### 6. REPLACE BCM

• Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

• Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-38, "Intermittent Incident"](#).

# DOOR LOCK OPERATION WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

## DOOR LOCK OPERATION WARNING DOES NOT OPERATE

### Diagnosis Procedure

INFOID:000000005947004

#### 1.CHECK DOOR LOCK FUNCTION

Check door lock function.

Does door lock/unlock using door request switch?

YES >> GO TO 2.

NO >> Refer to [DLK-112, "ALL DOOR : Diagnosis Procedure"](#).

#### 2.CHECK INTELLIGENT KEY WARNING BUZZER

Check Intelligent Key warning buzzer.

Refer to [DLK-102, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

#### 3.REPLACE BCM

• Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

• Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-38, "Intermittent Incident"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

DLK

# KEY ID WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

---

## KEY ID WARNING DOES NOT OPERATE

### Diagnosis Procedure

INFOID:000000005947005

---

#### 1.CHECK DTC WITH BCM

Check that DTC is not detected with BCM.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Perform trouble diagnosis relevant to DTC indicated.

---

#### 2.CHECK DTC WITH COMBINATION METER

Check that DTC is not detected with combination meter.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Perform trouble diagnosis relevant to DTC indicated.

---

#### 3.CHECK INTELLIGENT KEY

Check Intelligent Key.

Refer to [DLK-104, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

---

#### 4.CHECK INFORMATION DISPLAY

Check information display

Refer to [DLK-105, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

---

#### 5.CHECK INSIDE KEY ANTENNA

Check inside key antenna.

- Instrument center: Refer to [DLK-60, "DTC Logic"](#).
- Console: Refer to [DLK-62, "DTC Logic"](#).
- Trunk room: Refer to [DLK-64, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the malfunctioning parts.

---

#### 6.REPLACE BCM

- Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).
- Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-38, "Intermittent Incident"](#).




# SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

## SQUEAK AND RATTLE TROUBLE DIAGNOSES

### Work Flow

INFOID:000000006114049



### CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any of customer's comments; refer to [DLK-141, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, perform a diagnosis and repair the noise that the customer is concerned about. This can be accomplished by performing a cruise test on the vehicle with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak – (Like tennis shoes on a clean floor)  
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces = higher pitch noise/softer surfaces = lower pitch noises/edge to surface = chirping
- Creak – (Like walking on an old wooden floor)  
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle – (Like shaking a baby rattle)  
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock – (Like a knock on a door)  
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick – (Like a clock second hand)  
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump – (Heavy, muffled knock noise)  
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz – (Like a bumblebee)  
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending up on the person. A noise that a technician may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

### DUPLICATE THE NOISE AND TEST DRIVE

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when the repair is reconfirmed.

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

## < SYMPTOM DIAGNOSIS >

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
  - 2) Tap or push/pull around the area where the noise appears to be coming from.
  - 3) Rev the engine.
  - 4) Use a floor jack to recreate vehicle "twist".
  - 5) At idle, apply engine load (electrical load, half-clutch on M/T models, drive position on A/T models).
  - 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.
- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
  - If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

## CHECK RELATED SERVICE BULLETINS

After verifying the customer concern or symptom, check ASIST for Technical Service Bulletins (TSBs) related to that concern or symptom.

If a TSB relates to the symptom, follow the procedure to repair the noise.

## LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Chassis ear: J-39570, Engine ear and mechanics stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
  - Removing the components in the area that is are suspected to be the cause of the noise.  
Do not use too much force when removing clips and fasteners, otherwise clips and fastener can be broken or lost during the repair, resulting in the creation of new noise.
  - Tapping or pushing/pulling the component that is are suspected to be the cause of the noise.  
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
  - Feeling for a vibration by hand by touching the component(s) that is are suspected to be the cause of the noise.
  - Placing a piece of paper between components that are suspected to be the cause of the noise.
  - Looking for loose components and contact marks.  
Refer to [DLK-139, "Inspection Procedure"](#).

## REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
  - Separate components by repositioning or loosening and retightening the component, if possible.
  - Insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. A Nissan Squeak and Rattle Kit (J-43980) is available through the authorized Nissan Parts Department.

### **CAUTION:**

**Never use excessive force as many components are constructed of plastic and may be damaged.**

### **NOTE:**

Always check with the Parts Department for the latest parts information.

The following materials are contained in the Nissan Squeak and Rattle Kit (J-43980). Each item can be ordered separately as needed.

URETHANE PADS [1.5 mm (0.059 in) thick]

Insulates connectors, harness, etc.

76268-9E005: 100 × 135 mm (3.94 × 5.31 in)/76884-71L01: 60 × 85 mm (2.36 × 3.35 in)/76884-71L02: 15 × 25 mm (0.59 × 0.98 in)

INSULATOR (Foam blocks)

Insulates components from contact. Can be used to fill space behind a panel.

73982-9E000: 45 mm (1.77 in) thick, 50 × 50 mm (1.97 × 1.97 in)/73982-

50Y00: 10 mm (0.39 in) thick, 50 × 50 mm (1.97 × 1.97 in)

INSULATOR (Light foam block)

80845-71L00: 30 mm (1.18 in) thick, 30 × 50 mm (1.18 × 1.97in)

FELT CLOTHTAPE

Used to insulate where movement does not occur. Ideal for instrument panel applications.

68370-4B000: 15 × 25 mm (0.59 × 0.98 in) pad/68239-13E00: 5 mm (0.20 in) wide tape roll

The following materials, not found in the kit, can also be used to repair squeaks and rattles.

UHMW (TEFLON) TAPE

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

## < SYMPTOM DIAGNOSIS >

Insulates where slight movement is present. Ideal for instrument panel applications.

### SILICONE GREASE

Used in place of UHMW tape that is be visible or does not fit. Will only last a few months.

### SILICONE SPRAY

Used when grease cannot be applied.

### DUCT TAPE

Used to eliminate movement.

## CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

## Inspection Procedure

INFOID:000000006114050

Refer to Table of Contents for specific component removal and installation information.

## INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

1. The cluster lid A and instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar garnish
4. Instrument panel to windshield
5. Instrument panel mounting pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicon spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

### **CAUTION:**

**Never use silicone spray to isolate a squeak or rattle. If the area is saturated with silicone, the recheck of repair becomes impossible.**

## CENTER CONSOLE

Components to pay attention to include:

1. Shifter assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

## DOORS

Pay attention to the following:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. The areas can usually be insulated with felt cloth tape or insulator foam blocks from the Nissan Squeak and Rattle Kit (J-43980) to repair the noise.

## TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the customer.

In addition look for the following:

1. Trunk lid dumpers out of adjustment
2. Trunk lid striker out of adjustment
3. The trunk lid torsion bars knocking together
4. A loose license plate or bracket

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

## < SYMPTOM DIAGNOSIS >

---

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

### SUNROOF/HEADLINING

Noises in the sunroof/headlining area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sunvisor shaft shaking in the holder
3. Front or rear windshield touching headlining and squeaking

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

### SEATS

When isolating seat noise it's important to note the position the seats in and the load placed on the seat when the noise occurs. These conditions should be duplicated when verifying and isolating the cause of the noise.

Cause of seat noise include:

1. Headrest rods and holder
2. A squeak between the seat pad cushion and frame
3. The rear seatback lock and bracket

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

### UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

Causes of transmitted underhood noise include:

1. Any component mounted to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator mounting pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

These noises can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine RPM or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting, securing, or insulating the component causing the noise.

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

## Diagnostic Worksheet

INFOID:000000006114051







### SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

Dear Infiniti Customer:

We are concerned about your satisfaction with your Infiniti vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your Infiniti right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service consultant or technician to ensure we confirm the noise you are hearing.

#### I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to page 2 of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

PIIB8741E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DLK  
L  
M  
N  
O  
P

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

## SQUEAK & RATTLE DIAGNOSTIC WORKSHEET - page 2

Briefly describe the location where the noise occurs:

---

---

### II. WHEN DOES IT OCCUR? (please check the boxes that apply)

- |   |  |
|---|--|
| <input type="checkbox"/> anytime                      | <input type="checkbox"/> after sitting out in the rain |
| <input type="checkbox"/> 1st time in the morning      | <input type="checkbox"/> when it is raining or wet     |
| <input type="checkbox"/> only when it is cold outside | <input type="checkbox"/> dry or dusty conditions       |
| <input type="checkbox"/> only when it is hot outside  | <input type="checkbox"/> other:                        |

### III. WHEN DRIVING:

- through driveways
- over rough roads
- over speed bumps
- only about \_\_\_\_ mph
- on acceleration
- coming to a stop
- on turns: left, right or either (circle)
- with passengers or cargo
- other: \_\_\_\_\_
- after driving \_\_\_\_ miles or \_\_\_\_ minutes

### IV. WHAT TYPE OF NOISE

- squeak (like tennis shoes on a clean floor)
- creak (like walking on an old wooden floor)
- rattle (like shaking a baby rattle)
- knock (like a knock at the door)
- tick (like a clock second hand)
- thump (heavy, muffled knock noise)
- buzz (like a bumble bee)

## TO BE COMPLETED BY DEALERSHIP PERSONNEL

### Test Drive Notes:

---

---

---

	YES	NO	Initials of person performing
Vehicle test driven with customer	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise verified on test drive	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise source located and repaired	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Follow up test drive performed to confirm repair	<input type="checkbox"/>	<input type="checkbox"/>	_____

VIN: \_\_\_\_\_ Customer Name: \_\_\_\_\_  
W.O.# \_\_\_\_\_ Date: \_\_\_\_\_

This form must be attached to Work Order

PIIB8742E

# HOOD


< REMOVAL AND INSTALLATION >

## REMOVAL AND INSTALLATION


### HOOD

Exploded View

INFOID:000000006039531



- |                       |                   |                  |
|-----------------------|-------------------|------------------|
| 1. Hood assembly      | 2. Grommet        | 3. Bumper rubber |
| 4. Radiator core seal | 5. Hood insulator | 6. Stud ball     |
| 7. Hood stay          | 8. Hood hinge     |                  |

 : Clip

Refer to [Gl-4, "Components"](#) for symbols in the figure.

## HOOD ASSEMBLY

### HOOD ASSEMBLY : Removal and Installation

INFOID:000000006039532

#### CAUTION:

Operate with 2 workers, because of its heavy weight.

#### REMOVAL

1. Remove washer nozzle (LH and RH) and washer tube. Refer to [WW-51, "Removal and Installation"](#).
2. Support hood lock assembly with a proper material to prevent it from falling.


#### WARNING:

Body injury may occur if no supporting rod is holding the hood open when removing the hood stay.

# HOOD

## < REMOVAL AND INSTALLATION >

3. Remove the metal clip (3) located on the connection between the hood stay (1) and the stud ball (2) (hood side), by using a flatted-blade screwdriver (A).
4. Disengage the stud ball from the hood stay (hood side).



5. Remove hood hinge mounting nuts on the hood to remove the hood assembly.
6. Remove following parts after removing the hood assembly.
  - Radiator core seal
  - Hood insulator
  - Hood bumper rubber
  - Hood striker

## INSTALLATION

Note the following item, and install in the reverse order of removal.

### **CAUTION:**

- Before installing hood hinge, apply anticorrosive agent onto the mounting surface of the vehicle body.
- After installing, perform hood fitting adjustment. Refer to [DLK-145, "HOOD ASSEMBLY : Adjustment"](#).
- After installing, perform front washer nozzle and tube inspection and adjustment. Refer to [WW-52, "Inspection and Adjustment"](#).




# HOOD

< REMOVAL AND INSTALLATION >

## HOOD ASSEMBLY : Adjustment

INFOID:000000006039533



- 1. Hood assembly
- 2. Hood striker
- 3. Hood bumper rubber
- 4. Hood hinge
- 5. Front bumper fascia
- 6. Front fender

Refer to [GI-4, "Components"](#) for symbols in the figure.

Check the clearance and the surface height between hood and each part visually and by touching. (Fitting standard dimension in the table below should be satisfied.)

If the clearance and the surface height are out of specification, adjust them according to the procedures shown below.

Portion			Standard	Difference (LH/RH, MAX)
Hood – Bumper fascia	A – A	D	1.7 – 5.3 mm (0.067 – 0.209 in)	2.0 mm (0.079 in)
		E	(-2.5) – (+0.5) mm [(-0.098) – (+0.020) in]	2.0 mm (0.079 in)

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

DLK

# HOOD

## < REMOVAL AND INSTALLATION >

Portion			Standard	Difference (LH/RH, MAX)
Hood – Fender	B – B	F	Clearance 2.5 – 4.5 mm (0.098 – 0.177 in)	1.0 mm (0.039 in)
		G	Surface height (-1.5) – (+1.5) mm [(-0.059) – (+0.059) in]	—
	C – C	H	Clearance 2.5 – 4.5 mm (0.098 – 0.177 in)	1.0 mm (0.039 in)
		I	Surface height (-1.5) – (+1.5) mm [(-0.059) – (+0.059) in]	—
Hood striker – Bumper rubber	—	J	Clearance 32.5 – 33.5 mm (1.280 – 1.319 in)	—

1. Remove striker and adjust the surface height of hood, front bumper fascia and front fender according to the fitting standard dimension, by rotating hood bumper rubbers.
2. Adjust the height difference of striker, hood bumper rubber according to the fitting standard dimension.
3. Loosen hood hinge mounting nuts on the hood.
4. Adjust the clearance of hood, front bumper fascia, front grill and front fender according to the fitting standard dimension, for the hood.
5. Check that hood lock secondary latch is securely engaged with striker by dropping hood from approximately 200 mm (7.874 in) height or pressing lightly on the hood.  
**CAUTION:**  
**Never drop hood from a height of 300 mm (11.811 in) or more.**
6. Install as static closing face of hood is 94 – 490 N·m (9.6 – 50.0 kg·m).  
**NOTE:**
  - Exercise vertical force on right side and left side of hood lock.
  - Never press simultaneously both sides.
7. After adjustment tighten hood hinge mounting nuts to the specified torque.

## HOOD HINGE

### HOOD HINGE : Removal and Installation

INFOID:000000006039535

#### REMOVAL

1. Remove hood assembly. Refer to [DLK-143, "HOOD ASSEMBLY : Removal and Installation"](#).
2. Remove front fender cover. Refer to [EXT-21, "Exploded View"](#).
3. Remove brake master cylinder cover, battery cover, and hood ledge cover (LH and RH). Refer to [EXT-21, "Exploded View"](#).
4. Remove clips of hood seal, and then remove hood seal assembly (side). Refer to [DLK-151, "Exploded View"](#).
5. Remove front fender mounting bolt.
6. Remove hood hinge mounting bolts, and then remove hood hinge.

#### INSTALLATION

Note the following item, and install in the reverse order of removal.

#### **CAUTION:**

- Before installation of hood hinge, apply anticorrosive agent onto the surface of the vehicle body.
- Before installation of hood hinge, drop genuine high strength locking sealant or equivalent into bolt hole of hood hinge (body side).
- After installation, apply touch-up paint (the body color) onto the head of the hinge mounting bolts and nuts.
- After installation, perform hood fitting adjustment. Refer to [DLK-145, "HOOD ASSEMBLY : Adjustment"](#).

#### HOOD STAY

# HOOD

< REMOVAL AND INSTALLATION >

## HOOD STAY : Removal and Installation

INFOID:000000006039537


### REMOVAL

1. Support hood lock assembly with a proper material to prevent it from falling.

**WARNING:**

**Body injury may occur if no supporting rod is holding the hood open when removing the hood stay.**

2. Remove the metal clip (3) located on the connection between the hood stay (1) and the stud ball (2) (hood side), by using a flat-bladed screwdriver (A).
3. Disengage the stud ball from the hood stay (hood side).
4. Repeat the same operation to disengage the stud ball from the hood stay (body side), then remove the hood stay.



### INSTALLATION

Install in the reverse order of removal.


## HOOD STAY : Disposal

INFOID:000000006039538

1. Fix hood stay (1) using a vise (C).
2. Using hacksaw (A) slowly make 2 holes in the hood stay, in numerical order as shown in the figure.


**CAUTION:**

- When cutting a hole on hood stay, always cover a hacksaw using a shop cloth (B) to avoid scattering metal fragments or oil.
- Wear eye protection (safety glasses).
- Wear gloves.



**A: 20.0 mm (0.787 in)**

**B: Cut at the groove.**




# RADIATOR CORE SUPPORT

< REMOVAL AND INSTALLATION >

## RADIATOR CORE SUPPORT

Exploded View

INFOID:000000006039539



- |                                    |                                    |                                    |
|------------------------------------|------------------------------------|------------------------------------|
| 1. Hood lock bracket (RH)          | 2. Head lamp bracket (RH)          | 3. Front bumper upper retainer     |
| 4. Condenser side seal upper (RH)  | 5. Condenser side seal lower (RH)  | 6. Front bumper side retainer (RH) |
| 7. Hood lock support stay          | 8. Front bumper side retainer (LH) | 9. Condenser side seal upper (LH)  |
| 10. Condenser side seal lower (LH) | 11. Radiator core support assembly | 12. Head lamp bracket (LH)         |
| 13. Hood lock bracket (LH)         |                                    |                                    |

△ : Pawl

## Removal and Installation

INFOID:000000006039540

### REMOVAL


1. Remove brake master cylinder cover, battery cover, and hood ledge cover (LH and RH). Refer to [EXT-21, "Exploded View"](#).
2. Use a refrigerant collecting equipment to discharge the refrigerant. Refer to [HA-21, "Recycle Refrigerant"](#).
3. Remove engine under cover. Refer to [EXT-28, "ENGINE UNDER COVER : Removal and Installation"](#).
4. Drain engine coolant from radiator.
  - VQ engine models: Refer to [CO-8, "Draining"](#).
  - VK engine models: Refer to [CO-33, "Draining"](#).

# RADIATOR CORE SUPPORT

## < REMOVAL AND INSTALLATION >


5. Remove air duct (inlet) assembly.
  - VQ engine models: Refer to [EM-29, "Removal and Installation"](#).
  - VK engine models: Refer to [EM-184, "Removal and Installation"](#).
6. Remove front bumper fascia, energy absorber, and reinforcement. Refer to [EXT-14, "Removal and Installation"](#).
7. Remove front combination lamp (LH and RH). Refer to [EXL-119, "Removal and Installation"](#).
8. Remove head lamp bracket.
  1. Disconnect harness connector of Intelligent Key warning buzzer.
  2. Remove mounting bolts and remove head lamp bracket.
9. Remove washer tank. Refer to [WW-48, "Removal and Installation"](#).
10. Remove mounting bolts and remove hood lock bracket (LH and RH).
  1. Remove hood lock control cable (front) fixing clips from hood lock support stay and condenser upper bracket. Refer to [DLK-169, "Exploded View"](#).
  2. Remove hood lock control cable (front) from tube clip of front bumper upper retainer. Refer to [DLK-169, "Exploded View"](#).
  3. Remove hood lock bracket mounting bolts.
  4. Remove air cleaner assembly (VK engine models only). Refer to [EM-184, "Removal and Installation"](#).
  5. Disconnect harness connector (A), and then remove hood lock switch harness connector (B) from vehicle.

↶ : Vehicle front



6. Move hood lock bracket to a location where it does not inhibit work.
11. Remove horn (HIGH and LOW). Refer to [HRN-6, "Removal and Installation"](#).
12. Disconnect harness connector of refrigerant pressure sensor. Refer to [HA-41, "REFRIGERANT PRESSURE SENSOR : Removal and Installation"](#).
13. Disconnect harness connector of exhaust gas/outside odor sensor. Refer to [HAC-208, "Removal and Installation"](#).
14. Disconnect harness connector of ambient sensor. Refer to [HAC-202, "Removal and Installation"](#).
15. Remove ICC sensor integrated unit (with intelligent cruise control model). Refer to [CCS-180, "Removal and Installation"](#).
16. Move power steering oil cooler to a location where it does not inhibit work.
  1. Remove under side cover RH. Refer to [EXT-24, "FENDER PROTECTOR : Exploded View"](#).
  2. Remove mounting bolts (A) and remove power steering oil cooler (1).
  3. Remove power steering oil cooler as show in the figure.

↶ : Vehicle front



17. Remove condenser pipe assembly. Refer to [HA-41, "CONDENSER PIPE ASSEMBLY : Removal and Installation"](#).
18. Remove radiator reservoir tank.
  - VQ engine models: Refer to [CO-13, "Exploded View"](#).
  - VK engine models: Refer to [CO-39, "Exploded View"](#).
19. Remove radiator hose (upper) and radiator hose (lower) at radiator side.
  - VQ engine models: Refer to [CO-13, "Removal and Installation"](#).

# RADIATOR CORE SUPPORT

## < REMOVAL AND INSTALLATION >

---

- VK engine models: Refer to [CO-39, "Removal and Installation"](#).
20. Disconnect AT fluid cooler hose (A and B) from fan shroud and remove AT fluid cooler hose (A and B) from radiator.
- VQ engine (2WD) models: Refer to [TM-188, "VQ37VHR \(2WD\) : Removal and Installation"](#).
  - VQ engine (AWD) models: Refer to [TM-190, "VQ37VHR \(AWD\) : Removal and Installation"](#).
  - VK engine (2WD) models: Refer to [TM-192, "VK56VD \(2WD\) : Removal and Installation"](#).
  - VK engine (AWD) models: Refer to [TM-195, "VK56VD \(AWD\) : Removal and Installation"](#).
21. Disconnect harness connector of cooling fan control modules.
- VQ engine models: Refer to [CO-17, "Removal and Installation"](#).
  - VK engine models: Refer to [CO-43, "Removal and Installation"](#).
22. Disconnect harness connector of crash zone sensor. Refer to [SR-21, "Removal and Installation"](#).
23. Remove harness fixing clips from the following components.
- Front bumper upper retainer
  - Hood lock support stay
  - Cooling fan assembly
  - Radiator core support assembly
24. Remove mounting bolts, and then remove radiator core support assembly.
- CAUTION:**  
**Operate with two workers, because of its heavy weight.**
25. Remove the following parts after removing radiator core support assembly.
- Front bumper upper retainer
  - Front bumper side retainer (LH and RH)
  - Hood lock support stay
  - condenser assembly: Refer to [HA-40, "CONDENSER : Removal and Installation"](#).
  - Crash zone sensor: Refer to [SR-21, "Removal and Installation"](#).
  - Cooling fan assembly
  - VQ engine models: Refer to [CO-17, "Removal and Installation"](#).
  - VK engine models: Refer to [CO-43, "Removal and Installation"](#).
  - Remove radiator.
  - VQ engine models: Refer to [CO-13, "Removal and Installation"](#).
  - VK engine models: Refer to [CO-39, "Removal and Installation"](#).
  - Condenser side seal upper and lower

## INSTALLATION

Note the following item, and install in the reverse order of removal.

### **CAUTION:**

- Replenish the following parts.
- Refrigerant: Refer to [HA-21, "Charge Refrigerant"](#).
- Engine coolant (VQ engine models): Refer to [CO-9, "Refilling"](#).
- Engine coolant (VK engine models): Refer to [CO-34, "Refilling"](#).
- AT fluid: Refer to [TM-94, "Changing"](#).
- Power steering oil: Refer to [ST-31, "Inspection"](#).
- Adjust the following parts.
- Front combination lamp: Refer to [EXL-115, "Aiming Adjustment Procedure"](#).
- ICC sensor integrated unit (with intelligent cruise control model): Refer to [CCS-75, "Description"](#).


# FRONT FENDER

< REMOVAL AND INSTALLATION >

## FRONT FENDER

Exploded View

INFOID:000000006039541



1. Double-faced adhesive tape  
2.0 mm (0.079 in)
2. Hood seal assembly (side)
3. Front fender assembly
4. Front fender baffle

○ : Clip

Refer to [GI-4, "Components"](#) for symbols in the figure.

### CAUTION:

A viscous urethane foam (A) is installed on the back surface of front fender. When removing the front fender, peel of the urethane foam bit at a time, and carefully to remove it.

## Removal and Installation

INFOID:000000006039542

### CAUTION:

Use a shop cloth to protect the body from being damaged during removal and installation.

### REMOVAL

1. Remove front fender cover (RH and LH): Refer to [EXT-21, "Exploded View"](#).
2. Remove brake master cylinder cover, battery cover, hood ledge cover (LH and RH). Refer to [EXT-21, "Exploded View"](#).
3. Remove hood seal assembly (side).
4. Remove air duct (inlet).
  - VQ37: Refer to [EM-29, "Removal and Installation"](#).
  - VK56: Refer to [EM-184, "Removal and Installation"](#).
5. Remove front bumper fascia. Refer to [EXT-14, "Removal and Installation"](#).
6. Remove front combination lamp. Refer to [EXL-119, "Removal and Installation"](#).
7. Remove fender protector. Refer to [EXT-24, "FENDER PROTECTOR : Removal and Installation"](#).
8. Remove front door assembly. Refer to [DLK-153, "DOOR ASSEMBLY : Removal and Installation"](#).

## FRONT FENDER

### < REMOVAL AND INSTALLATION >

---

9. Remove front fender baffle.
10. Remove front fender mounting bolts, and then remove front fender.

### INSTALLATION

Note the following item, and install in the reverse order of removal.

#### **CAUTION:**

- After installation, check front fender adjustment.
- Hood side: Refer to [DLK-145, "HOOD ASSEMBLY : Adjustment"](#).
- Front door side: Refer to [DLK-154, "DOOR ASSEMBLY : Adjustment"](#).
- After installation, apply the touch-up paint (the body color) onto the head of front fender mounting bolts.
- Adjust the following part.
- Front combination lamp: Refer to [EXL-115, "Aiming Adjustment Procedure"](#).




# FRONT DOOR

< REMOVAL AND INSTALLATION >

## FRONT DOOR

Exploded View

INFOID:000000006039543



- |                       |                       |                       |
|-----------------------|-----------------------|-----------------------|
| 1. Front door panel   | 2. Door hinge (upper) | 3. Door hinge (lower) |
| 4. Door check link    | 5. Check link cover   | 6. Bumper rubber      |
| 7. Door striker cover | 8. Door striker       | 9. TORX bolt          |
| 10. Grommet           |                       |                       |

Refer to [GI-4. "Components"](#) for symbols in the figure.

## DOOR ASSEMBLY

### DOOR ASSEMBLY : Removal and Installation


INFOID:000000006039544


#### CAUTION:

- Perform work with 2 workers, because of its heavy weight.
- When removing and installing front door assembly, support door with a jack and cloth to protect door and body.

#### REMOVAL

1. Remove check link cover toward vehicle rear..

 : Pawl



2. Remove mounting bolts of door check link on the vehicle.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

DLK

# FRONT DOOR

## < REMOVAL AND INSTALLATION >

3. Disconnect front door harness connector.
4. Remove door hinge mounting nuts (door side), and then remove door assembly.

**NOTE:**

Adjustment of front door for installation is not necessary if front door assembly is removed by removing door hinge mounting nuts.

### INSTALLATION


Note the following item, and install in the reverse order of removal.

**CAUTION:**

- Check front door open/close, lock/unlock operation after installation.
- Check door hinge rotating part for poor lubrication. If necessary, apply body grease.
- After installation, perform the fitting adjustment. Refer to [DLK-154, "DOOR ASSEMBLY : Adjustment"](#).
- After installation, apply touch-up paint (the body color) onto the head of door hinge mounting nuts.

### DOOR ASSEMBLY : Adjustment

INFOID:000000006039545



- |                     |                            |                            |
|---------------------|----------------------------|----------------------------|
| 1. Front fender     | 2. Front door              | 3. Rear door               |
| 4. Body side outer  | 5. Door striker            | 6. TORX bolt               |
| 7. Front door hinge | 8. Rear door hinge (upper) | 9. Rear door hinge (lower) |

Refer to [GI-4, "Components"](#) for symbols in the figure.

Check the clearance and surface height between front door and each part by visually and touching.


# FRONT DOOR

## < REMOVAL AND INSTALLATION >


If the clearance and the surface height are out of specification, adjust them according to the procedures shown below.

Portion		Standard
Front fender – Front door	A – A	Clearance 2.7 – 4.7 mm (0.106 – 0.185 in)
		Surface height (-1.0) – (+1.0) mm [(-0.039) – (+0.039) in]
Front door – Rear door	B – B	Clearance 2.9 – 4.7 mm (0.114 – 0.185 in)
		Surface height (-1.0) – (+1.0) mm [(-0.039) – (+0.039) in]

1. Remove front fender. Refer to [DLK-151. "Removal and Installation"](#).
2. Loosen door hinge mounting nuts on door side.
3. Loosen bolts (A).



4. Adjust the surface height of front door according to the fitting standard dimension.
5. Tighten bolts (A).



6. Temporarily tighten door hinge mounting nuts on door side.
7. Loosen door hinge mounting bolts on body side.
8. Raise front door at rear end to adjust clearance of the front door according to the fitting standard dimension.
9. After adjustment tighten bolts and nuts to the specified torque.
10. Install front fender. Refer to [DLK-151. "Removal and Installation"](#).

## DOOR STRIKER ADJUSTMENT

Adjust door striker so that it becomes parallel with door lock insertion direction.

## DOOR STRIKER

### DOOR STRIKER : Removal and Installation

INFOID:000000006039547

## REMOVAL

Remove door striker cover and TORX bolts, and then remove door striker.

# FRONT DOOR

## < REMOVAL AND INSTALLATION >

### INSTALLATION

Note the following item, and install in the reverse order of removal.

#### **CAUTION:**

- Check front door open/close, lock/unlock operation after installation.
- After installation, check to perform the fitting adjustment. Refer to [DLK-154, "DOOR ASSEMBLY : Adjustment"](#).

### DOOR HINGE

#### DOOR HINGE : Removal and Installation

INFOID:000000006039549

### REMOVAL

1. Remove front fender. Refer to [DLK-151, "Removal and Installation"](#).
2. Remove front door assembly. Refer to [DLK-153, "DOOR ASSEMBLY : Removal and Installation"](#).
3. Remove front door hinge mounting bolts, and then remove front door hinge.

### INSTALLATION

Note the following item, and install in the reverse order of removal.

#### **CAUTION:**

- Check front door open/close, lock/unlock operation after installation.
- Check door hinge rotating part for poor lubrication. If necessary, apply body grease.
- After installation, perform the fitting adjustment. Refer to [DLK-154, "DOOR ASSEMBLY : Adjustment"](#).
- After installation, apply touch-up paint (the body color) onto the head of door hinge mounting nuts.


### DOOR CHECK LINK


#### DOOR CHECK LINK : Removal and Installation

INFOID:000000006039551

### REMOVAL

1. Fully close the front door window.
2. Remove front door finisher. Refer to [INT-31, "FRONT DOOR FINISHER : Removal and Installation"](#).
3. Remove front door speaker or front door woofer.
  - Front door speaker (base audio without navigation): Refer to [AV-121, "Removal and Installation"](#).
  - Front door woofer (BOSE audio without navigation): Refer to [AV-299, "Removal and Installation"](#).
4. Remove check link cover toward vehicle rear.

 : Pawl



5. Remove mounting bolts of door check link on the vehicle.
6. Remove mounting bolts of door check link on door panel.
7. Take door check link out from the hole of door panel.

### INSTALLATION

Note the following item, and install in the reverse order of removal.

#### **CAUTION:**

- Check front door open/close operation after installation.


# REAR DOOR

< REMOVAL AND INSTALLATION >

## REAR DOOR

### Exploded View

INFOID:000000006039552



- |                           |                          |                       |
|---------------------------|--------------------------|-----------------------|
| 1. Rear door panel        | 2. Door hinge (upper)    | 3. Door hinge (lower) |
| 4. Door check link        | 5. Door check link cover | 6. Bumper rubber      |
| 7. Child lock lever cover | 8. Door striker cover    | 9. Door striker       |
| 10. TORX bolt             | 11. Grommet              |                       |

Refer to [GI-4. "Components"](#) for symbols in the figure.

## DOOR ASSEMBLY

### DOOR ASSEMBLY : Removal and Installation


INFOID:000000006039553


#### CAUTION:

- Perform work with 2 workers, because of it's heavy weight.
- When removing and installing rear door assembly, support door with a jack and cloth to protect door and body.

#### REMOVAL

1. Remove check link cover toward vehicle rear.

 : Pawl



2. Remove mounting bolts of door check link on the vehicle.


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

DLK


## REAR DOOR

### < REMOVAL AND INSTALLATION >

3. Remove rear door harness grommet, and then pull out door harness from the vehicle.
4. Disconnect rear door harness connector.
5. Remove nut cup.




6. Remove door hinge mounting nuts (door side), and then remove rear door assembly.



7. Lift up rear door assembly (1). Disconnect door hinge [male-side (door side)] (2) from door hinge [female-side (body side)] (2) and remove toward outside of vehicle.

**NOTE:**

Adjustment of rear door assembly for installation is not necessary if rear door assembly is removed by disconnecting door hinge [male-side (door side)] from door hinge [female-side (body side)].



### INSTALLATION

Note the following item, and install in the reverse order of removal.

**CAUTION:**


- Check rear door open/close, lock/unlock operation after installation.
- Check door hinge rotating part for poor lubrication. If necessary, apply body grease.
- After installation, perform the fitting adjustment.
- After installation, apply touch-up paint (the body color) onto the head of door hinge mounting nuts.

# REAR DOOR

< REMOVAL AND INSTALLATION >

## DOOR ASSEMBLY : Adjustment

INFOID:000000006039554



- |                     |                            |                            |
|---------------------|----------------------------|----------------------------|
| 1. Front fender     | 2. Front door              | 3. Rear door               |
| 4. Body side outer  | 5. Door striker            | 6. TORX bolt               |
| 7. Front door hinge | 8. Rear door hinge (upper) | 9. Rear door hinge (lower) |

Refer to [GI-4. "Components"](#) for symbols in the figure.

Check the clearance and surface height between rear door and each part by visually and touching. If the clearance and the surface height are out of specification, adjust them according to the procedures shown below.

Portion		Standard	
Front door – Rear door	B – B	Clearance	2.9 – 4.7 mm (0.114 – 0.185 in)
		Surface height	(-1.0) – (+1.0) mm [(-0.039) – (+0.039) in]
Rear door – Body side outer	C – C	Clearance	2.7 – 4.7 mm (0.106 – 0.185 in)
		Surface height	(-1.0) – (+1.0) mm [(-0.039) – (+0.039) in]

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

DLK

# REAR DOOR

## < REMOVAL AND INSTALLATION >

### **CAUTION:**

When performing adjustment for installation, check that door hinge [male-side (door side)] is connected to door hinge [female-side (body side)].

1. Remove center pillar lower garnish. Refer to [INT-40, "CENTER PILLAR LOWER GARNISH : Removal and Installation"](#).
2. Loosen door hinge mounting nuts on door side.
3. Adjust the surface height of rear door according to the fitting standard dimension.
4. Temporarily tighten door hinge mounting nuts on door side.
5. Loosen door hinge mounting nuts and bolts on body side.
6. Raise rear door at rear end to adjust clearance of rear door according to the fitting standard dimension.
7. After adjustment tighten bolts and nuts to the specified torque.
8. Install center pillar lower garnish. Refer to [INT-40, "CENTER PILLAR LOWER GARNISH : Removal and Installation"](#).

### DOOR STRIKER ADJUSTMENT

Adjust door striker so that it becomes parallel with door lock insertion direction.

### DOOR STRIKER

#### DOOR STRIKER : Removal and Installation

INFOID:000000006039556

#### REMOVAL

1. Remove door striker cover with remover tool.
2. Remove door striker mounting TORX bolts, and then remove door striker.

#### INSTALLATION

Note the following item, and install in the reverse order of removal.

### **CAUTION:**

- Check rear door open/close, lock/unlock operation after installation.
- After installation, check to perform the fitting adjustment. Refer to [DLK-159, "DOOR ASSEMBLY : Adjustment"](#).

### DOOR HINGE

#### DOOR HINGE : Removal and Installation

INFOID:000000006039558

#### REMOVAL

1. Remove center pillar lower garnish. Refer to [INT-40, "CENTER PILLAR LOWER GARNISH : Removal and Installation"](#).
2. Remove rear door assembly. Refer to [DLK-157, "DOOR ASSEMBLY : Removal and Installation"](#).
3. Remove rear door hinge mounting bolts and nuts (body side), and then remove door hinge.

#### INSTALLATION

Note the following item, and install in the reverse order of removal.

### **CAUTION:**

- Check rear door open/close operation after installation.
- Check door hinge rotating part for poor lubrication. If necessary, apply body grease.
- When removing and installing rear door assembly, perform the fitting adjustment. Refer to [DLK-159, "DOOR ASSEMBLY : Adjustment"](#).
- After installing, apply the touch-up paint (the body color) onto the head of door hinge mounting nuts.

### DOOR CHECK LINK

#### DOOR CHECK LINK : Removal and Installation

INFOID:000000006039560

#### REMOVAL

1. Fully close the rear door window.
2. Remove rear door finisher. Refer to [INT-33, "REAR DOOR FINISHER : Removal and Installation"](#).
3. Remove rear door speaker.





# REAR DOOR

## < REMOVAL AND INSTALLATION >

- Base audio without navigation: Refer to [AV-123. "Removal and Installation"](#).
- BOSE audio without navigation: Refer to [AV-302. "Removal and Installation"](#).

4. Remove check link cover toward vehicle rear.

 : Pawl



5. Remove mounting bolts of the check link on the vehicle.
6. Remove mounting bolts of the check link on door panel.
7. Take door check link out from the hole of door panel.

### INSTALLATION

Note the following item, and install in the reverse order of removal.

**CAUTION:**

**Check rear door open/close operation after installation.**

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

DLK


# TRUNK LID

< REMOVAL AND INSTALLATION >

## TRUNK LID

Exploded View

INFOID:000000006039583



- |                              |                            |                            |
|------------------------------|----------------------------|----------------------------|
| 1. Trunk lid assembly        | 2. Trunk lid weather-strip | 3. Trunk lid hinge         |
| 4. Trunk lid stay            | 5. Trunk lid striker       | 6. Trunk lid lock assembly |
| 7. Trunk lid outer protector | 8. Trunk key cylinder      | 9. Bumper rubber           |
| 10. Emergency opener cable   |                            |                            |
- A : Center mark (upper)

## TRUNK LID ASSEMBLY

### TRUNK LID ASSEMBLY : Removal and Installation


INFOID:000000006039584

#### **CAUTION:**

**Operate with two workers, because of its heavy weight.**

#### REMOVAL


1. Remove the trunk lid finisher inner. Refer to [INT-56. "Removal and Installation"](#)
2. Disconnect harness connector (A) and harness clip (B) in trunk room.



# TRUNK LID

## < REMOVAL AND INSTALLATION >

3. Remove grommet (1), and then pull harness throughout body panel (2).



4. Remove the trunk lid hinge mounting bolts on trunk lid side and remove the trunk lid assembly.

## INSTALLATION

Note the following item, and install in the reverse order of removal.

### CAUTION:

- After installing, apply touch-up paint (the body color) onto the head of the hinge mounting bolts.
- Check trunk lid open/close, lock/unlock operation after installation.
- After installation, perform fitting adjustment. Refer to [DLK-164, "TRUNK LID ASSEMBLY : Adjustment"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P


DLK

# TRUNK LID

< REMOVAL AND INSTALLATION >

## TRUNK LID ASSEMBLY : Adjustment

INFOID:000000006039585



- |                       |                       |                          |
|-----------------------|-----------------------|--------------------------|
| 1. Trunk lid assembly | 2. Bumper rubber      | 3. Trunk lid hinge       |
| 4. Trunk lid striker  | 5. Body side outer    | 6. Rear combination lamp |
| 7. Reverse lamp       | 8. Trunk lid finisher | 9. Rear bumper fascia    |

Refer to [GI-4. "Components"](#) for symbols in the figure.


Check the clearance and surface height between trunk lid and each part by visually and touching. If the clearance and surface height are out of specification, adjust them according to the procedures shown below.

# TRUNK LID

## < REMOVAL AND INSTALLATION >

Portion			Standard	Difference (RH/LH, MAX)
Trunk lid – Body side outer	A – A	E	Clearance 2.5 – 4.5 mm (0.098 – 0.177 in)	1.4 mm (0.055 in)
		F	Surface height (-1.5) – (+0.5) mm [(-0.059) – (+0.020) in]	1.4 mm (0.055 in)
	B – B	G	Clearance 3.5 – 5.0 mm (0.118 – 0.197 in)	1.4 mm (0.055 in)
		H	Surface height (-1.5) – (+0.5) mm [(-0.059) – (+0.020) in]	1.4 mm (0.055 in)
Rear combination lamp – Reverse lamp	C – C	I	Clearance 2.1 – 5.9 mm (0.083 – 0.232 in)	2.5 mm (0.098 in)
		J	Surface height (-1.9) – (+1.9) mm [(-0.075) – (+0.075) in]	2.2 mm (0.087 in)
Trunk lid – Rear bumper fascia	D – D	K	Clearance 2.4 – 6.6 mm (0.094 – 0.260 in)	—

- Loosen trunk lid hinge mounting bolts (trunk lid side).
- Remove trunk rear plate. Refer to [INT-54, "TRUNK REAR PLATE : Removal and Installation"](#).
- Loosen trunk lid striker mounting bolts.
- Lift up trunk lid approximately 100 – 150 mm (3.937 – 5.906 in) height then close it lightly and check that it is engaged firmly with trunk lid closed.
- Check the clearance and surface height.
- Finally tighten trunk lid hinge and trunk lid striker.
- Install trunk rear plate. Refer to [INT-54, "TRUNK REAR PLATE : Removal and Installation"](#).
- Initialize the height of bumper rubber.



- Insert screwdriver (A) wrapped with the protective tape between the body (1) and the collar (2), and then pull out the bumper rubber (3) from the trunk lid (4).
  - Rotate the collar and contact it with the bumper rubber.
- Close the trunk lid by pushing with hands.

### NOTE:

The bumper rubber is pressed to the vehicle body side, and it is compressed in the trunk lid.

### CAUTION:


- Close the trunk lid gently because the bumper rubber is compressed excessively by slamming the trunk lid.
- If the bumper rubber is compressed excessively, initialize the height of bumper rubber, and then repeat the procedure again.

# TRUNK LID

## < REMOVAL AND INSTALLATION >

10. Open the trunk lid, and then engage it with the body by rotating the collar.

- (1) : Body
- (2) : Collar
- (3) : Bumper rubber
- (4) : Trunk lid



### CAUTION:

- Apply anticorrosive agent onto the mounting surface.
- After installation, check trunk lid open/close, lock/unlock operation.
- After installation, apply touch-up paint (the body color) onto the head of trunk lid hinge mounting bolts and nuts.

## TRUNK LID STRIKER ADJUSTMENT

Adjust trunk lid striker so that it becomes parallel with trunk lid lock insertion direction.

## TRUNK LID STRIKER

### TRUNK LID STRIKER : Removal and Installation

INFOID:000000006039587

#### REMOVAL

1. Remove trunk rear plate. Refer to [INT-54, "TRUNK REAR PLATE : Removal and Installation"](#).
2. Remove mounting bolts, and then remove trunk lid striker.

#### INSTALLATION

Note the following item, and install in the reverse order of removal.

### CAUTION:

- Check trunk lid open/close, lock/unlock operation after installation.
- When removing and installing trunk lid striker, perform the fitting adjustment. Refer to [DLK-164, "TRUNK LID ASSEMBLY : Adjustment"](#).

## TRUNK LID HINGE

### TRUNK LID HINGE : Removal and Installation

INFOID:000000006039589

#### REMOVAL

1. Remove trunk lid assembly. Refer to [DLK-162, "TRUNK LID ASSEMBLY : Removal and Installation"](#).
2. Remove trunk lid stay from trunk lid hinge. Refer to [DLK-166, "TRUNK LID STAY : Removal and Installation"](#).
3. Remove trunk lid hinge mounting nuts (body side), and then remove trunk lid hinge.

#### INSTALLATION

Note the following item, and install in the reverse order of removal.

### CAUTION:

- Check trunk lid open/close, lock/unlock operation after installation.
- Check trunk lid hinge rotating part for poor lubrication. If necessary, apply body grease.
- When removing and installing trunk lid assembly, perform the fitting adjustment. Refer to [DLK-164, "TRUNK LID ASSEMBLY : Adjustment"](#).
- After installation, apply touch-up paint (the body color) onto the head of trunk lid hinge mounting bolts.

## TRUNK LID STAY

### TRUNK LID STAY : Removal and Installation

INFOID:000000006039591

#### REMOVAL

# TRUNK LID


## < REMOVAL AND INSTALLATION >

1. Support trunk lid with the proper material to prevent it from falling.

### **WARNING:**

**Bodily injury may occur if no supporting rod is holding the trunk lid open when removing the trunk lid stay.**

2. Remove the metal clip (3) located on the connection between the trunk lid stay (1) and the stud ball (2) (trunk lid side) by using a flat-bladed screwdriver (A).
3. Remove trunk lid stay (trunk lid side).



4. In the same way, remove trunk lid stay (body side).

## INSTALLATION

Note the following item, and install in the reverse order of removal.

### **CAUTION:**

**Check trunk lid open/close operation after installation.**


## TRUNK LID STAY : Disposal

INFOID:000000006039592

1. Fix trunk lid stay (1) using a vise (C).
2. Using hacksaw (A) slowly make 2 holes in the trunk lid stay, in numerical order as shown in the figure.


### **CAUTION:**

- When cutting a hole on trunk lid stay, always cover a hacksaw using a shop cloth (B) to avoid scattering metal fragments or oil.
- Wear eye protection (safety glasses).
- Wear gloves.



A: 20.0 mm (0.787 in)

B: Cut at the groove.



## TRUNK LID WEATHER-STRIP

### TRUNK LID WEATHER-STRIP : Removal and Installation

INFOID:000000006039594

#### REMOVAL

Pull up and remove engagement with body from weather-strip joint.

### **CAUTION:**

**Never pull strongly on weather-strip.**

#### INSTALLATION

## TRUNK LID

### < REMOVAL AND INSTALLATION >

---

1. Working from the upper section, align weather-strip center mark (upper) with vehicle center position mark and install weather-strip onto the vehicle.
2. For the lower section, align weather-strip center mark (lower) with center of trunk lid striker.
3. Pull weather-strip gently to ensure that there is no loose section.

**NOTE:**

Check that weather-strip fits tightly in each corner.




# HOOD LOCK

< REMOVAL AND INSTALLATION >


## HOOD LOCK

### Exploded View

INFOID:000000006039565



- |  |                                    |                                      |
|--|------------------------------------|--------------------------------------|
| 1. Hood striker (LH/RH)                    | 2. Hood striker cover (LH/RH)      | 3. Hood lock (LH/RH)                 |
| 4. Secondary latch                         | 5. Hood lock control cable (front) | 6. Hood lock control cable protector |
| 7. Hood lock control cable protector cover | 8. Hood lock control cable (rear)  | 9. Hood lock opener lever            |

 : Clip

Refer to [GI-4, "Components"](#) for symbols in the figure.

## HOOD LOCK

### HOOD LOCK : Removal and Installation

INFOID:000000006039566

#### REMOVAL

#### **CAUTION:**


**Check wiring of hood lock control before removal.**

1. Remove air duct (inlet).
  - VQ engine models: Refer to [EM-29, "Exploded View"](#).
  - VK engine models: Refer to [EM-184, "Exploded View"](#).
2. Remove hood lock control cable (front) clips from hood lock stay and condenser upper bracket.
3. Remove hood lock control cable (front) from tube clip of front bumper upper retainer.
4. Remove air cleaner assembly (VK engine models only). Refer to [EM-184, "Removal and Installation"](#).


# HOOD LOCK

## < REMOVAL AND INSTALLATION >

5. Remove mounting bolts of hood lock then reward the arrow direction.




6. Disconnect hood lock control cable (front) from hood lock.



7. Disconnect harness connector (A), and then remove hood lock switch harness connector (B) from vehicle.

← : Vehicle front



8. Remove hood lock.

## INSTALLATION

Note the following item, and install in the reverse order of removal.

### CAUTION:

- Check that hood lock control cable is properly engaged with hood lock.
- After installation, perform hood fitting adjustment. Refer to [DLK-145, "HOOD ASSEMBLY : Adjustment"](#).
- After installation, perform hood lock control inspection. Refer to [DLK-170, "HOOD LOCK : Inspection"](#).

## HOOD LOCK : Inspection

INFOID:000000006039567

### NOTE:

If the hood lock cable is bent or deformed, replace it.

1. Check that the secondary and the hood lock stay are securely engaged by the weight of the hood when letting the hood free fall from a height of approximately 100 mm (3.937 in).
2. Check that the front end of the hood rises by approximately 20 mm (0.787 in) when pulling the hood opener lever gently. Also check that the hood opener lever returns to the original position.
3. Check that the tension of hood opener lever is less than 49.0 N (5.0 kg, 11.02 lb).
4. Check that the hood striker and the hood lock are securely engaged by the weight of the hood when letting the hood free fall from a height of approximately 300 mm (11.811 in).

### NOTE:

- Exert vertical force on right side and left side of hood lock.

# HOOD LOCK

## < REMOVAL AND INSTALLATION >

- Never press simultaneously both sides.

5. Check the hood lock lubrication condition. If necessary, apply body grease to hood lock.

## HOOD LOCK CONTROL CABLE

### HOOD LOCK CONTROL CABLE : Removal and Installation

INFOID:000000006052851


#### FRONT

##### Removal


##### **CAUTION:**

**Check wiring of hood lock control before removal.**


1. Remove clips of hood seal assembly (side).
2. Remove hood lock control cable protector (1) toward the arrow direction, then remove it from front combination lamp assembly (2).



3. Remove hood lock control cable cover from hood lock control cable protector.
4. Disconnect hood lock control cable (front) hood lock control cable protector.



5. Remove air duct (inlet).
  - VQ engine models: Refer to [EM-29. "Exploded View"](#).
  - VK engine models: Refer to [EM-184. "Exploded View"](#).
6. Remove hood lock control cable (front) fixing clips from hood lock stay and condenser upper bracket.
7. Remove hood lock control cable (front) from tube clip of front bumper upper retainer.
8. Remove air cleaner assembly (VK engine models only). Refer to [EM-184. "Removal and Installation"](#).
9. Remove mounting bolts of hood lock then reward the arrow direction.




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DLK  
L  
M  
N  
O  
P

# HOOD LOCK

## < REMOVAL AND INSTALLATION >

10. Disconnect hood lock control cable (front) from hood lock.



11. Remove hood lock control cable (front) from vehicle.

### Installation

Note the following item, and install in the reverse order of removal.

### **CAUTION:**

**Never to bend cable too much, keeping the radius 100 mm (3.937 in) or more.**


## REAR

### Removal


### **CAUTION:**

**Check wiring of hood lock control before removal.**

1. Remove clips of hood seal assembly (side).
2. Remove hood lock control cable protector (1) toward the arrow direction, then remove it from front combination lamp assembly (2).



3. Remove hood lock control cable cover from hood lock control cable protector.
4. Disconnect hood lock control cable (rear) from hood lock control cable protector.



5. Remove fender protector LH. Refer to [EXT-24, "FENDER PROTECTOR : Removal and Installation"](#).
6. Remove mounting bolts and remove hood lock opener lever.
7. Remove front kicking plate inner LH and dash side finisher LH. Refer to [INT-36, "Exploded View"](#).
8. Remove grommet on the lower dash, pull hood lock control cable (rear) toward the passenger compartment.

### **CAUTION:**

**While pulling, never to damage (peeling) the outside of the hood lock control cable.**

### Installation


# HOOD LOCK

## < REMOVAL AND INSTALLATION >

Note the following item, and install in the reverse order of removal.

### CAUTION:

- Never to bend cable too much, keeping the radius 100 mm (3.937 in) or more.
- Check that cable is not offset from the positioning grommet, and apply the sealant to the grommet (at\* mark) properly.



- Check that hood lock control cable is properly engaged with hood lock.
- After installation, perform hood fitting adjustment. Refer to [DLK-145, "HOOD ASSEMBLY : Adjustment"](#).
- After installation, perform hood lock control inspection. Refer to [DLK-170, "HOOD LOCK : Inspection"](#).

## HOOD LOCK CONTROL CABLE : Inspection

INFOID:000000006052853

### NOTE:

If the hood lock cable is bent or deformed, replace it.

1. Check that secondary latch is properly engaged with secondary striker [6.8 mm (0.268 in)] by hood weight.
2. While operating hood opener, carefully check that the front end of hood is raised by approximately 20.0 mm (0.787 in). Also check that hood opener returns to the original position.
3. Check that hood opener operating is condition 49 N (5.0 kg, 11.0 lb) or below.
4. Install so that static closing force of hood is 94 – 490 N·m (9.6 – 50.0 kg-m, 69 – 361 ft – lb).

### NOTE:

- Exert vertical force on right side and left side of hood lock.
  - Never press simultaneously both sides.
5. Check the hood lock lubrication condition. If necessary, apply body grease to hood lock.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

DLK


# FRONT DOOR LOCK

< REMOVAL AND INSTALLATION >

## FRONT DOOR LOCK

Exploded View

INFOID:000000006039568



- |   |                       |                             |
|---|-----------------------|-----------------------------|
| 1. Door key cylinder assembly (driver side) | 2. Rear gasket        | 3. TORX bolt                |
| Outside handle escutcheon (passenger side)  |                       |                             |
| 4. Key rod (driver side)                    | 5. Door lock assembly | 6. Inside handle escutcheon |
| 7. Inside handle                            | 8. Front gasket       | 9. Outside handle           |
| 10. Outside handle bracket                  |                       |                             |

← : Vehicle front

Refer to [GI-4, "Components"](#) for symbols in the figure.

## DOOR LOCK

### DOOR LOCK : Removal and Installation

INFOID:000000006039569

#### REMOVAL

1. Remove front door finisher. Refer to [INT-31, "FRONT DOOR FINISHER : Removal and Installation"](#).
2. Remove front door glass. Refer to [GW-18, "Removal and Installation"](#).
3. Remove front door module assembly. Refer to [GW-20, "Removal and Installation"](#).
4. Disconnect door antenna and door request switch connector and remove harness clamp (with Intelligent Key system model) on outside handle bracket.

# FRONT DOOR LOCK


## < REMOVAL AND INSTALLATION >

5. Remove door side grommet, and loosen TORX bolt from grommet hole.


**CAUTION:**

**Never remove TORX bolt forcibly.**


← : TORX bolt




6. Reach in to separate key rod (2) connection [on the door key cylinder assembly (1)] (driver side).



7. While pulling outside handle, remove door key cylinder assembly (driver side) or outside handle escutcheon (passenger side).



8. While pulling outside handle (1), slide toward rear of vehicle to remove outside handle.




9. Remove front gasket and rear gasket.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DLK  
L  
M  
N  
O  
P

# FRONT DOOR LOCK

## < REMOVAL AND INSTALLATION >

10. While pulling outside handle bracket, slide toward rear of vehicle to remove outside handle bracket.



11. Reach in to separate outside handle cable connection on outside handle bracket.
12. Remove door lock assembly mounting TORX bolts.
13. Disconnect door lock actuator connector, and then remove door lock assembly.
14. Remove key rod from door lock assembly.

## INSTALLATION

Note the following item, and install in the reverse order of removal.

### CAUTION:

- When installing each rod, rotate rod holder until a click is felt.
- Check door open/close, lock/unlock operation after installation.

## INSIDE HANDLE

### INSIDE HANDLE : Removal and Installation

INFOID:000000006039571

## REMOVAL

1. Remove front door finisher. Refer to [INT-31, "FRONT DOOR FINISHER : Removal and Installation"](#).
2. Remove inside handle mounting screws.

## INSTALLATION

Note the following item, and install in the reverse order of removal.

### CAUTION:

Check door open/close, lock/unlock operation after installation.

## OUTSIDE HANDLE

### OUTSIDE HANDLE : Removal and Installation

INFOID:000000006039573


## REMOVAL

1. Remove front door finisher. Refer to [INT-31, "FRONT DOOR FINISHER : Removal and Installation"](#).
2. Remove front door glass. Refer to [GW-18, "Removal and Installation"](#).
3. Remove front door module assembly. Refer to [GW-20, "Removal and Installation"](#).
4. Disconnect door antenna and door request switch connector and remove harness clamp (models with Intelligent Key system) on outside handle bracket.
5. Remove door side grommet, and loosen TORX bolt from grommet hole.

### CAUTION:

Never remove TORX bolt forcibly.

← : TORX bolt







# FRONT DOOR LOCK

## < REMOVAL AND INSTALLATION >


6. Reach in to separate key rod (2) connection [on the door key cylinder assembly (1)] (driver side).




7. While pulling outside handle, remove door key cylinder assembly (driver side) or outside handle escutcheon (passenger side).



8. While pulling outside handle (1), slide toward rear of vehicle to remove outside handle.



9. Remove front gasket and rear gasket.  
10. While pulling outside handle bracket, slide toward rear of vehicle to remove outside handle bracket.



11. Reach in to separate outside handle cable connection on outside handle bracket.

## INSTALLATION

Note the following item, and install in the reverse order of removal.

### CAUTION:

- When installing each rod, rotate rod holder until a click is felt.
- Check door open/close, lock/unlock operation after installation.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DLK  
L  
M  
N  
O  
P


# REAR DOOR LOCK

< REMOVAL AND INSTALLATION >

## REAR DOOR LOCK

Exploded View

INFOID:000000006039574



- |                              |                 |                             |
|------------------------------|-----------------|-----------------------------|
| 1. Outside handle escutcheon | 2. Rear gasket  | 3. TORX bolt                |
| 4. Door lock assembly        | 5. TORX bolt    | 6. Inside handle escutcheon |
| 7. Inside handle             | 8. Front gasket | 9. Outside handle           |
| 10. Outside handle bracket   |                 |                             |

← : Vehicle front

Refer to [GI-4. "Components"](#) for symbols in the figure.

## DOOR LOCK

### DOOR LOCK : Removal and Installation

INFOID:000000006039575


#### REMOVAL

1. Remove rear door finisher. Refer to [INT-33. "REAR DOOR FINISHER : Removal and Installation"](#).
2. Remove sealing screen. Refer to [GW-23. "Removal and Installation"](#).
3. Fully close the rear door glass.
4. Remove door side grommet, and loosen TORX bolt from grommet hole.

**CAUTION:**

**Never remove TORX bolt forcibly.**


← : TORX bolt




# REAR DOOR LOCK

## < REMOVAL AND INSTALLATION >


5. While pulling outside handle, remove outside handle escutcheon.



6. While pulling outside handle (1), slide toward rear of vehicle to remove outside handle.



7. Remove front gasket and rear gasket.
8. While pulling outside handle bracket, slide toward rear of vehicle to remove outside handle bracket.



9. Reach in to separate outside handle cable connection on outside handle bracket.
10. Remove door lock assembly mounting TORX bolts.
11. Disconnect door lock actuator connector, and then remove door lock assembly.

## INSTALLATION

Note the following item, and install in the reverse order of removal.

### **CAUTION:**

**Check door open/close, lock/unlock operation after installation.**

## INSIDE HANDLE

### INSIDE HANDLE : Removal and Installation

INFOID:000000006039577

## REMOVAL

1. Remove rear door finisher. Refer to [INT-33, "REAR DOOR FINISHER : Removal and Installation"](#).
2. Remove inside handle mounting screws, and then remove inside handle.

## INSTALLATION

Note the following item, and install in the reverse order of removal.

### **CAUTION:**

**Check door open/close, lock/unlock operation after installation.**

## OUTSIDE HANDLE

A  
B  
C  
D  
E  
F  
G  
H  
I  
J

DLK

L

M

N

O

P

# REAR DOOR LOCK

< REMOVAL AND INSTALLATION >

## OUTSIDE HANDLE : Removal and Installation

INFOID:00000006039579


### REMOVAL

1. Remove door side grommet, and loosen TORX bolt from grommet hole.


**CAUTION:**

**Never remove TORX bolt forcibly.**


← : TORX bolt




2. While pulling outside handle, remove outside handle escutcheon.



3. While pulling outside handle (1), slide toward rear of vehicle to remove outside handle.



4. Remove rear door finisher. Refer to [INT-33. "REAR DOOR FINISHER : Removal and Installation"](#).
5. Remove sealing screen. Refer to [GW-23. "Removal and Installation"](#).
6. Fully close rear door glass.
7. Remove front gasket and rear gasket.
8. While pulling outside handle bracket, slide toward rear of vehicle to remove outside handle bracket.



9. Reach in to separate outside handle cable connection on outside handle bracket.

### INSTALLATION

# REAR DOOR LOCK

## < REMOVAL AND INSTALLATION >

---

Note the following item, and install in the reverse order of removal.

**CAUTION:**

**Check door open/close, lock/unlock operation after installation.**

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P


# TRUNK LID LOCK

< REMOVAL AND INSTALLATION >

## TRUNK LID LOCK

Exploded View

INFOID:000000006039595



- |                              |                            |                            |
|------------------------------|----------------------------|----------------------------|
| 1. Trunk lid                 | 2. Trunk lid weather-strip | 3. Trunk lid hinge         |
| 4. Trunk lid stay            | 5. Trunk lid striker       | 6. Trunk lid lock assembly |
| 7. Trunk lid outer protector | 8. Trunk key cylinder      | 9. Bumper rubber           |
| 10. Emergency opener cable   |                            |                            |
| A. Center mark (upper)       |                            |                            |

Refer to [GI-4, "Components"](#) for symbols in the figure.

## Removal and Installation

INFOID:000000006039596

### REMOVAL

1. Remove trunk lid finisher inner. Refer to [INT-56, "Removal and Installation"](#).
2. Disconnect trunk lid emergency opener cable.
3. Disconnect cable of trunk lid lock assembly from trunk lid cylinder.
4. Disconnect trunk lid lock assembly connector.
5. Remove trunk lid lock assembly mounting bolts, and then remove trunk lid lock assembly.

### INSTALLATION

Note the following item, and install in the reverse order of removal.

#### **CAUTION:**

**Check trunk lid open/close, lock/unlock operation after installation.**


# FUEL FILLER LID OPENER

< REMOVAL AND INSTALLATION >


## FUEL FILLER LID OPENER

Exploded View

INFOID:000000006039581



- |                                    |                  |                          |
|------------------------------------|------------------|--------------------------|
| 1. Fuel filler lid opener actuator | 2. Lock nut      | 3. Bumper rubber         |
| 4. Fuel filler lid assembly        | 5. Bumper rubber | 6. Lock and rod assembly |


 : Pawl

### Removal and Installation

INFOID:000000006039582


#### NOTE:

When fuel filler lid opener actuator (1) is a defective operation, pull the rod to open fuel filler lid.



#### REMOVAL

1. Fully open fuel filler lid.
2. Remove fuel mounting pin (1).



3. Remove mounting screws and then remove fuel filler lid.
4. Rotate lock nut counterclockwise, and then remove lock nut.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

DLK

## FUEL FILLER LID OPENER

### < REMOVAL AND INSTALLATION >

---

5. Remove trunk side finisher RH. Refer to [INT-54, "TRUNK SIDE FINISHER : Removal and Installation"](#).
6. Push fuel filler lid opener actuator behind the vehicle, while pushing the pawl.
7. Disconnect harness connector and remove fuel filler lid opener actuator.
8. Pull and remove lock & rod assembly forward, while pushing the pawls.

### INSTALLATION

Note the following item, and install in the reverse order of removal.

#### **CAUTION:**

- **After installation, check fuel filler lid assembly open/close, lock/unlock operation.**
- **After installation, apply the touch-up paint (the body color) onto the head of the mounting screws.**



# DOOR SWITCH

< REMOVAL AND INSTALLATION >

---

## DOOR SWITCH

### Removal and Installation

INFOID:000000005947040

#### REMOVAL

Remove the door switch mounting bolt, and then remove door switch.

#### INSTALLATION

Install in the reverse order of removal.

A

B

C

D

E

F

G

H

I

J

**DLK**

L

M

N

O

P

# INSIDE KEY ANTENNA

< REMOVAL AND INSTALLATION >

---

## INSIDE KEY ANTENNA INSTRUMENT CENTER

### INSTRUMENT CENTER : Removal and Installation

INFOID:000000005947042

#### REMOVAL

1. Remove the cluster lid C. Refer to [IP-13. "Removal and Installation"](#).
2. Remove the inside key antenna (instrument center) mounting screw, and then remove inside key antenna (instrument center).

#### INSTALLATION

Install in the reverse order of removal.

## CONSOLE

### CONSOLE : Removal and Installation

INFOID:000000005947044

#### REMOVAL

1. Remove the console ashtray.
2. Remove the center console assembly. Refer to [IP-24. "Removal and Installation"](#).
3. Remove the inside key antenna mounting (console) screw, and then remove inside key antenna (console).

#### INSTALLATION

Install in the reverse order of removal.

## TRUNK ROOM

### TRUNK ROOM : Removal and Installation

INFOID:000000005947046

#### REMOVAL

1. Remove the trunk lid upper finisher. Refer to [INT-54. "TRUNK FINISHER FRONT : Removal and Installation"](#).
2. Remove the inside key antenna (trunk room) mounting nuts, and then remove inside key antenna (trunk room).

#### INSTALLATION

Install in the reverse order of removal.

# OUTSIDE KEY ANTENNA

< REMOVAL AND INSTALLATION >

## OUTSIDE KEY ANTENNA

### DRIVER SIDE

#### DRIVER SIDE : Removal and Installation

INFOID:000000005947048

#### REMOVAL

Remove the front outside handle LH. Refer to [DLK-176, "OUTSIDE HANDLE : Removal and Installation"](#).

#### INSTALLATION

Install in the reverse order of removal.

### PASSENGER SIDE

#### PASSENGER SIDE : Removal and Installation

INFOID:000000005947050

#### REMOVAL

Remove the front outside handle RH. Refer to [DLK-176, "OUTSIDE HANDLE : Removal and Installation"](#).

#### INSTALLATION

Install in the reverse order of removal.

### REAR BUMPER

#### REAR BUMPER : Removal and Installation

INFOID:000000005947052

#### REMOVAL

1. Remove the rear bumper. Refer to [EXT-18, "Removal and Installation"](#).
2. Remove the outside key antenna (rear bumper) mounting nuts, and then remove outside key antenna (rear bumper).

#### INSTALLATION

Install in the reverse order of removal.

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

# INTELLIGENT KEY WARNING BUZZER

< REMOVAL AND INSTALLATION >

---

## INTELLIGENT KEY WARNING BUZZER

### Removal and Installation

INFOID:000000005947054

#### REMOVAL

1. Remove the front bumper. Refer to [EXT-14. "Removal and Installation"](#).
2. Remove the Intelligent Key warning buzzer mounting bolt, and then remove the Intelligent Key warning buzzer.

#### INSTALLATION

Install in the reverse order of removal.

# TRUNK OPENER REQUEST SWITCH

< REMOVAL AND INSTALLATION >

---

## TRUNK OPENER REQUEST SWITCH

### Removal and Installation

INFOID:000000005947058

#### REMOVAL

1. Remove the trunk lid finisher. Refer to [EXT-41. "Removal and Installation"](#).
2. Remove trunk lid request switch from trunk lid finisher.

#### INSTALLATION

Install in the reverse order of removal.

A

B

C

D

E

F

G

H

I

J

**DLK**

L

M

N

O

P

# TRUNK LID OPENER SWITCH

< REMOVAL AND INSTALLATION >

---

## TRUNK LID OPENER SWITCH

### Removal and Installation

INFOID:000000005947060

#### REMOVAL

1. Remove the instrument driver lower panel. Refer to [IP-13. "Removal and Installation"](#).
2. Remove the trunk lid opener switch from instrument driver lower panel, and then remove pawl. Press trunk lid opener switch front side to disengage from instrument driver lower panel.

#### INSTALLATION

Install in the reverse order of removal.

# TRUNK LID OPENER CANCEL SWITCH

< REMOVAL AND INSTALLATION >

---

## TRUNK LID OPENER CANCEL SWITCH

### Removal and Installation

INFOID:000000005947062

#### REMOVAL

1. Remove the instrument assist lower panel. Refer to [IP-13, "Removal and Installation"](#).
2. Remove the trunk lid opener cancel switch instrument assist lower panel, and then remove pawl. Press trunk lid opener cancel switch backside to disengage from instrument assist lower panel.

#### INSTALLATION

Install in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DLK  
L  
M  
N  
O  
P

DLK

# REMOTE KEYLESS ENTRY RECEIVER

< REMOVAL AND INSTALLATION >

---

## REMOTE KEYLESS ENTRY RECEIVER

### Removal and Installation

INFOID:000000005947064

#### REMOVAL

1. Remove the glove box assembly. Refer to [IP-13. "Removal and Installation"](#).
2. Remove the remote keyless entry receiver mounting bolt, and then remove remote keyless entry receiver.

#### INSTALLATION

Install in the reverse order of removal.



# INTELLIGENT KEY BATTERY

< REMOVAL AND INSTALLATION >

## INTELLIGENT KEY BATTERY

### Removal and Installation


INFOID:000000006071741

1. Release the lock knob at the back of the Intelligent Key and remove the mechanical key.

2. Insert a flat-blade screwdriver (A) wrapped with a cloth into the slit of the corner and twist it to separate the upper part from the lower part.

**CAUTION:**

- Do not touch the circuit board or battery terminal.
- The key fob is water-resistant. However, if it does get wet, immediately wipe it dry.



3. Replace the battery with new one.


**Battery replacement**

**:Coin-type lithium battery (CR2025)**

4. Align the tips of the upper and lower parts, and then push them together until it is securely closed.

**CAUTION:**

- When replacing battery, keep dirt, grease, and other foreign materials off the electrode contact area.
- After replacing the battery, check that all Intelligent Key functions work normally.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DLK  
L  
M  
N  
O  
P