

A
B
C

SECTION **STC**

STEERING CONTROL SYSTEM

CONTENTS

EPS	TILT/TELESCOPIC	
ELECTRICALLY CONTROLLED POWER STEERING SYSTEM	TILT & TELESCOPIC SYSTEM	11
Precautions	System Description	11
BEFORE DIAGNOSING THE POWER STEERING SYSTEM, ENSURE THAT	OPERATION	11
Description	Component Parts and Harness Connector Location..	11
SYSTEM DESCRIPTION	Wiring Diagram	12
FAIL-SAFE FUNCTION	BCM Input/Output Signal Standard	13
HYDRAULIC CIRCUIT	Preliminary Check	14
Component Parts Location	POWER SUPPLY AND GROUND CIRCUIT INSPECTION	14
Wiring Diagram	Symptom 1: Telescopic System Does Not Operate..	15
Control Unit Input/Output Signal Standard	Symptom 2: Tilt System Does Not Operate	18
Trouble Diagnosis		
PRECAUTIONS FOR DIAGNOSIS		
INSPECTION BEFORE TROUBLE DIAGNOSIS...		
DIAGNOSIS PROCEDURE		

STC

ELECTRICALLY CONTROLLED POWER STEERING SYSTEM

PFP:28500

Precautions

AGS0003E

BEFORE DIAGNOSING THE POWER STEERING SYSTEM, ENSURE THAT

Vehicle Stopped

1. Power steering components (gears, oil pump, pipes, etc.) are free from leakage, and that oil level is correct.
2. Tires are inflated to specified pressure and are of specified size, and that steering wheel is a genuine Nissan part.
3. Suspension utilizes the original design, and is free of modifications which increase vehicle weight.
4. Wheel alignment is adjusted properly.

Vehicle In Operation

1. Understand the symptom.
2. Engine is operation properly

Description


AGS0003F

SYSTEM DESCRIPTION

The power steering system is a twin orifice type, which uses a vehicle-speed sensing, electronic control design. Solenoid valve sensitivity is controlled in response to vehicle speed to achieve optimum steering effort.

FAIL-SAFE FUNCTION

The fail-safe function operates to regulate solenoid valve operation in response to engine speed, thereby maintaining the required steering force.



Fail-Safe Input Conditions

Fail-safe input conditions	Release conditions
No vehicle speed signal entered for at least 10 seconds while driving at an engine speed of greater than 1,500 rpm.	<ul style="list-style-type: none"> ● A vehicle speed signal of greater than 1.4 km/h (0.9 MPH) is entered ● Ignition switch is turned from "OFF" to "ON".
A vehicle speed signal of greater than 30 km/h (19 MPH) or abruptly drops below 2 km/h (1 MPH).	


NOTE:

When the engine is revved up to 1,500 rpm or more for at least 10 seconds with vehicle at standstill, the fail-safe function operates; however, this is not a matter of concern. The fail-safe function can be released by driving vehicle of a speed of greater than 1.4 km/h (0.9 MPH) or by turning ignition switch from "OFF" to "ON".

ELECTRICALLY CONTROLLED POWER STEERING SYSTEM

[EPS]


HYDRAULIC CIRCUIT



Component Parts Location

AGS0003G

STC



A
B
C
D
E
F
H
I
J
K
L
M






ELECTRICALLY CONTROLLED POWER STEERING SYSTEM

[EPS]

Wiring Diagram

AGS0009N

STC-EPS-01



REFER TO THE FOLLOWING.

- (B211) -SUPER MULTIPLE JUNCTION (SMJ)
- (M1) -FUSE BLOCK-JUNCTION BOX (J/B) NO.1
- (E218) -ELECTRICAL UNITS




TGWA0008E

ELECTRICALLY CONTROLLED POWER STEERING SYSTEM

[EPS]

STC-EPS-02

A
B
C
D
E
F
STC
H
I
J
K
L
M






REFER TO THE FOLLOWING.

- (F105) -SUPER MULTIPLE JUNCTION (SMJ)
- (M1) -FUSE BLOCK-JUNCTION BOX (J/B) NO.1
- (F101) -ELECTRICAL UNITS

TGWA0009E

Control Unit Input/Output Signal Standard

The standard values (voltage), measured with an analog tester in contact with control unit terminal, are shown below:

Measuring terminal		Measuring point	Standard value	
+	-			
1		Ignition switch ON or START	Ignition switch ON	Battery voltage (approx. 12V)
2		Ground	—	0V
3		Vehicle speed signal	When the speed is very low, the voltage fluctuates between approximately 0V and approximately 5V or higher.	When vehicle speed is approx. 40 km/h (25 MPH)  ELF1080D
5	Ground	Engine revolution signal	Engine is running <ul style="list-style-type: none"> ● Warm-up condition ● Engine idle speed 	 PBIA3654J
			Engine is running <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	 PBIA3655J
7		Solenoid valve	Engine is running	Normal 0 km/h ((0 MPH) : Approx. 4.4 - 6.6V 100 km/h (62 MPH): Approx. 2.4 - 3.6V When the fail-safe function is activated: 0 - 1,500 rpm : Approx. 4.4 - 6.6V 1,500 - 3,000 rpm : Approx. 3.5V 3,000 rpm or more : Approx. 2.1V

Trouble Diagnosis

PRECAUTIONS FOR DIAGNOSIS

Intermittent incidents may be caused by malfunctioning harness, harness connector or terminal. Move harnesses, harness connectors or terminals by hand to make sure that there is no contact malfunction. If a circuit tester for measuring voltage is used for check, be careful not to forcibly spread any connector terminals.

INSPECTION BEFORE TROUBLE DIAGNOSIS

- Check power steering fluid level and check for any leak. Refer to [PS-6, "POWER STEERING FLUID"](#).

DIAGNOSIS PROCEDURE

Symptom:

- Heavy steering operation during stationary turns
- Light steering operation during high-speed driving

Inspection procedure

1. CHECK POWER STEERING CONTROL UNIT POWER CIRCUIT

1. Disconnect power steering control unit harness connector.
2. Check voltage between power steering control unit harness connector M108 terminal 1 (GY) and ground.


: Battery voltage should exist.

OK or NG

OK >> GO TO 2.

NG >> Check the following.

- 10A fuse [No.7, located in fuse block (J/B) No.1]
- Harness for open or short between power steering control unit and fuse.
- If there is any non-standard condition, repair or replace it.



2. CHECK POWER STEERING CONTROL UNIT GROUND CIRCUIT


Check continuity between power steering control unit harness connector M108 terminal 2 (B) and ground.

2 (B) - Ground : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair or replace power steering control unit ground harness.




3. CHECK SOLENOID VALVE SIGNAL 1

1. Connect power steering control unit harness connector.
2. Start engine and gradually increase the vehicle speed from 0 to 100 km/h (0 to 62 MPH).
3. Check voltage between power steering control unit harness connector M108 terminal 7 (LG) and ground.

: Make sure that voltage changes from approximately 5.5V to approximately 2.5V.

OK or NG

- OK >> GO TO 4.
 NG >> GO TO 9.




4. CHECK SOLENOID VALVE SIGNAL 2

1. When engine is running at idle, change the engine speed to approximately 1,600 rpm and then to approximately 3,000 rpm.
2. Check voltage between power steering control unit harness connector M108 terminal 7 (LG) and ground.

: Make that voltage changes from approximately 5.5V to approximately 2.1V in steps.

OK or NG

- OK >> GO TO 5.
 NG >> GO TO 10.




5. CHECK SOLENOID VALVE

- Disconnect power steering control unit and solenoid valve connectors.
- Check continuity between power steering control unit harness connector M108 terminal 7 (LG) and solenoid valve harness connector F3 terminal 1 (LG).

7 (LG) – 1 (LG) : Continuity should exist.

OK or NG

- OK >> GO TO 6.
 NG >> Check harness for open or short between power steering control unit and solenoid valve.




6. CHECK SOLENOID VALVE HARNESS

- Check continuity between solenoid valve harness connector F3 terminal 2 (B) and ground.

2 (B) – Ground : Continuity should exist.

OK or NG

- OK >> GO TO 7.
 NG >> Repair or replace solenoid valve ground harness.




7. CHECK SOLENOID VALVE

1. Check solenoid valve by listening for its operation sound while applying battery voltage to terminals 1 (LG) and 2 (B).
2. Check resistance value between following solenoid valve terminals.

1 (LG) - 2 (B) : Approx. 4 - 6Ω

OK or NG

- OK >> GO TO 8.
 NG >> Replace solenoid valve.



8. CHECK STEERING WHEEL TURNING FORCE

1. Connect power steering control unit harness connector.
2. Check steering wheel turning force. Refer to [PS-7, "CHECKING STEERING WHEEL TURNING TORQUE"](#)

OK or NG



- OK >> Inspection END.
 NG >> Adjust steering gear assembly adjusting screw ([PS-13](#)) and check pump discharge pressure ([PS-25](#)).

9. CHECK VEHICLE SPEED SIGNAL INPUT

- With rear wheels raised, rotate them by hand.
- Check voltage between power steering control unit harness connector M108 terminals 3 (PU/W) and ground.

When the wheels are rotated slowly by hand:

3 (PU/W) – Ground : Reading fluctuates between 0V and 5V.




OK or NG

- OK >> Replace power steering control unit.
 NG >> Check the following.
- Harness for open or short between power steering control unit and combination meter.
 - Combination meter operation. Refer to [DI-19, "Inspection/Vehicle Speed Signal"](#).
 - If there is non-standard condition, repair or replace it.

10. CHECK ENGINE REVOLUTION SIGNAL


1. When engine is running at idle, change the engine speed to approximately 2,000 rpm.
2. Check voltage between power steering control unit harness connector M108 terminal 5 (W/G) and ground.



5 (W/G) –
Ground


Engine is running

- Warm-up condition
- Idle speed



Engine is running

- Warm-up condition
- Engine speed is 2,000 rpm



OK or NG

OK >> Replace power steering control unit.

NG >> Check the following.

- Harness for open or short between power steering control unit and ECM
- ECM engine revolution signal inspection. Refer to [EC-113, "SELF-DIAG RESULTS MODE"](#) .
- If there is any non-standard condition, repair or replace it.

TILT & TELESCOPIC SYSTEM

PFP:48805

System Description
OPERATION

AGS000EY


Steering wheel position can be adjusted with the steering position switch.

NOTE:

- The steering wheel position can be manually operated with the ignition switch OFF.

Component Parts and Harness Connector Location

AGS000EZ




SGIA0428E

A
B
C
D
E
F
H
I
J
K
L
M

STC

STC-TILTEL-01





Wiring Diagram



REFER TO PG-POWER.

BCM (BODY CONTROL MODULE) (M4)

STEERING POSITION SWITCH (M51)



REFER TO THE FOLLOWING.
 (M1), (E203) - FUSE BLOCK-JUNCTION BOX (J/B) NO.1
 (M4) - ELECTRICAL UNITS

BCM Input/Output Signal Standard

AGS000F1

Terminal	Wire color	Measuring point	Standard value		
17	BR/Y	Data link (RX line)	—		
18	P	Data link (TX line)	—		
22	R/B	Telescopic switch FR signal	Telescopic switch	Forward operation (Motor operated)	Approx. 0V
				OFF	Approx. 5V
23	PU/R	Tilt switch DOWN signal	Tilt switch	DOWN operation (Motor operated)	Approx. 0V
				OFF	Approx. 5V
26	G/B	Telescopic switch RR signal	Telescopic switch	Backward operation (Motor operated)	Approx. 0V
				OFF	Approx. 5V
36	P/L	Tilt switch UP signal	Tilt switch	UP operation (Motor operated)	Approx. 0V
				OFF	Approx. 5V
56	B	Ground	Ignition switch ON		Approx. 0V
101	P/L	Telescopic motor FR signal	Telescopic switch forward operation.		Battery voltage (Approx. 12V)
102	P	Tilt motor DOWN signal	Tilt switch DOWN operation		Battery voltage (Approx. 12V)
103	R/B	Tilt motor UP signal	Tilt switch UP operation		Battery voltage (Approx. 12V)
104	Y/B	Power supply for tilt and telescopic device	Ignition switch OFF		Battery voltage (Approx. 12V)
105	Y/L	BAT power supply	Ignition switch OFF		Battery voltage (Approx. 12V)
107	P/B	Telescopic motor RR signal	Telescopic switch backward operation		Battery voltage (Approx. 12V)
113	B	Ground	Ignition switch ON		Approx. 0V
114	B	Ground for tilt and telescopic device	Ignition switch ON		Approx. 0V

A
B
C
D
E
F
STC
H
I
J
K
L
M

Preliminary Check
POWER SUPPLY AND GROUND CIRCUIT INSPECTION

1. CHECK FUSE

- Check if any of the following fuses in the BCM are blown.

Unit	Terminal No.	Power source	Fuse No.
BCM	105	Power source	#3

OK or NG?

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-2, "POWER SUPPLY ROUTING"](#).

2. CHECK POWER SUPPLY CIRCUIT (BCM)


1. Disconnect BCM connector.
2. Turn ignition switch ON.
3. Check voltage between BCM harness connector M4 terminal 104 (Y/B), 105 (Y/L) and ground.

Terminals		Power source	Condition	Voltage (V)
(+)				
Connector	Terminal			
M4	104 (Y/B), 105 (Y/L)	BAT power supply	Ignition switch OFF	Battery voltage

OK or NG?

OK >> GO TO 3.

NG >> Repair or replace harness. Check harness for open or short between BCM and fuse.



3. CHECK GROUND CIRCUIT (BCM)


1. Turn ignition switch OFF.
2. Check continuity between BCM harness connector M4 terminal 56 (B), 113 (B), 114 (B) and ground.

Terminals		Condition	Continuity
(+)			
Connector	Terminal		
M4	56 (B)	Ignition switch OFF	Yes
	113 (B)	Ignition switch OFF	Yes
	114 (B)	Ignition switch OFF	Yes

OK or NG?

OK >> Preliminary check is OK.

NG >> Repair or replace BCM ground harness.



Symptom 1: Telescopic System Does Not Operate

1. CHECK STEERING WHEEL TELESCOPIC MECHANISM

Check the following.

- Operation malfunction caused by steering wheel telescopic mechanism deformation or pinched harness or other foreign materials.
- Operation malfunction and interference with other parts by poor installation.

OK or NG

- OK >> GO TO 2.
- NG >> Repair the malfunctioning part and check again.


2. CHECK TELESCOPIC SWITCH INPUT/OUTPUT

1. Disconnect steering position switch connector.
2. Check voltage between steering position switch harness connector M51 terminals 4 (G/B), 5 (R/B) and ground.

Terminals		Voltage (V)	
(+)			
Connector	Terminal	(-)	
M51	4 (G/B)	Ground	Approx. 5V
	5 (R/B)	Ground	Approx. 5V

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 5.




3. CHECK STEERING POSITION SWITCH GROUND CIRCUIT

Check continuity between steering position switch harness connector M51 terminal 1 (B) and ground.

1 (B) – Ground : Continuity should exist.

OK or NG

- OK >> GO TO 4.
- NG >> Replace or replace harness.




4. CHECK TELESCOPIC SWITCH

Check continuity between steering position switch connector terminals 4, 5 and 1.

Terminals	Steering position switch operation	Continuity
4 – 1	Backward position	Yes
	Neutral or forward position	No
5 – 1	Forward position	Yes
	Neutral or backward position	No

OK or NG


- OK >> GO TO 6.
- NG >> Replace steering position switch.



5. CHECK HARNESS CONTINUITY

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector M4 terminals 22 (R/B), 26 (G/B) and steering position switch harness connector M51 terminals 4 (G/B), 5 (R/B).
3. Check continuity between BCM harness connector M4 terminals 22 (R/B), 26 (G/B) and ground.

Terminals				Continuity
(+)		(-)		
Connector	Terminal	Connector	Terminal	
M4	22 (R/B)	M51	5 (R/B)	Yes
	26 (G/B)		4 (G/B)	Yes
	22 (R/B)	Ground		No
	26 (G/B)	Ground		No




OK or NG?

- OK >> Replace BCM.
 NG >> Repair or replace harness.

6. CHECK BCM OUTPUT SIGNAL

1. Disconnect telescopic motor connector.
2. Check voltage between telescopic motor harness connector M60 terminals 1 (P/L), 2 (P/B) and ground.

Terminals			Condition	Voltage
(+)		(-)		
Connector	Terminal			
M60	1 (P/L)	Ground	Telescopic switch (FR operation)	Battery voltage
	2 (P/B)	Ground	Telescopic switch (RR operation)	Battery voltage
	1 (P/L), 2 (P/B)	Ground	Telescopic switch OFF	0V



OK or NG

- OK >> Replace telescopic motor.
 NG >> GO TO 7.


7. CHECK TELESCOPIC MOTOR CIRCUIT

1. Disconnect BCM and telescopic motor connectors.
2. Check continuity between BCM harness connector M4 terminals 101 (P/L), 107 (P/B) and telescopic motor harness connector M60 terminals 1 (P/L), 2 (P/B).
3. Check continuity between BCM harness connector M4 terminals 101 (P/L), 107 (P/B) and ground.

Terminals				Continuity
BCM (+)		Telescopic motor (-)		
Connector	Terminal	Connector	Terminal	
M4	101 (P/L)	M60	1 (P/L)	Yes
	107 (P/B)		2 (P/B)	Yes
	101 (P/L)	Ground		No
	107 (P/B)	Ground		No

OK or NG

- OK >> Replace BCM.
 NG >> Repair or replace harness.



A
B
C
D
E
F

STC

H
I
J
K
L
M

Symptom 2: Tilt System Does Not Operate

1. CHECK STEERING WHEEL TILT MECHANISM

Check the following.

- Operation malfunction caused by steering wheel tilt mechanism deformation or pinched harness or other foreign materials.
- Operation malfunction and interference with other parts by poor installation.

OK or NG

OK >> GO TO 2.

NG >> Repair the malfunctioning part and check again.

2. CHECK TILT SWITCH INPUT/OUTPUT


1. Disconnect steering position switch connector.
2. Turn ignition switch ON.
3. Check voltage between steering position switch harness connector M51 terminals 2 (P/L), 3 (PU/R) and body ground.

Terminals		(-)	Voltage (V)
(+)			
Connector	Terminal		
M4	2 (P/L)	Ground	5V
	3 (PU/R)	Ground	5V

OK or NG

OK >> GO TO 3.

NG >> GO TO 5.



3. CHECK STEERING POSITION SWITCH GROUND CIRCUIT


1. Turn ignition switch OFF.
2. Check continuity between steering position switch harness connector M51 terminal 1 (B) and body ground.

1 (B) – Ground : Continuity should exist.

OK or NG

OK >> GO TO 4.

NG >> Repair or replace harness.




4. CHECK TILT SWITCH

Check continuity between steering position switch connector terminals 2, 3 and 1.

Terminals	Steering position switch operation	Continuity
2 – 1	Tilt up position	Yes
	Neutral or tilt down position	No
3 – 1	Tilt down position	Yes
	Neutral or tilt up position	No

OK or NG

- OK >> GO TO 6.
- NG >> Replace steering position switch.




5. CHECK HARNESS CONTINUITY

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector M4 terminals 23 (PU/R), 36 (P/L) and steering position switch harness connector M51 terminals 2 (P/L), 3 (PU/R).
3. Check continuity between BCM harness connector M4 terminals 23 (PU/R), 36 (P/L) and ground.

Terminals				Continuity
(+)		(-)		
Connector	Terminal	Connector	Terminal	
M4	23 (PU/R)	M51	3 (PU/R)	Yes
	36 (P/L)		2 (P/L)	Yes
	23 (PU/R)	Ground		No
	36 (P/L)	Ground		No

OK or NG

- OK >> Replace BCM.
- NG >> Repair or replace harness.




6. CHECK BCM OUTPUT SIGNAL

1. Disconnect tilt motor connector.
2. Check voltage between tilt motor harness connector M58 terminals 1 (R/B), 2 (P) and ground.

Terminals			Condition	Voltage
(+)		(-)		
Connector	Terminal			
M58	1 (R/B)	Ground	Tilt switch (UP operation)	Battery voltage
	2 (P)	Ground	Tilt switch (DOWN operation)	Battery voltage
	1 (R/B), 2 (P)	Ground	Tilt switch OFF	0V

OK or NG

- OK >> Replace tilt motor.
- NG >> GO TO 7.




7. CHECK TILT MOTOR CIRCUIT

1. Disconnect BCM and telescopic motor connectors.
2. Check continuity between BCM harness connector M4 terminals 102 (P), 103 (R/B) and tilt motor harness connector M58 terminals 1 (R/B), 2 (P).
3. Check continuity between BCM harness connector M4 terminals 102 (P), 103 (R/B) and body ground.

Terminals				Continuity
BCM (+)		Tilt motor (-)		
Connector	Terminal	Connector	Terminal	
M4	102 (P)	M58	2 (P)	Yes
	103 (R/B)		1 (R/B)	Yes
	102 (P)	Ground		No
	103 (R/B)	Ground		No

OK or NG

- OK >> Replace BCM.
 NG >> Repair or replace harness.



SGIA0441E