

SECTION **PG**

POWER SUPPLY, GROUND & CIRCUIT ELEMENTS

CONTENTS

POWER SUPPLY ROUTING	2	REAR DOOR HARNESS	44
Schematic	2	Wiring Diagram Codes (Cell Codes)	45
Wiring Diagram — POWER —	3	ELECTRICAL UNITS LOCATION	49
BATTERY POWER SUPPLY—IGNITION SW. IN		Electrical Units Location	49
ANY POSITION	3	ENGINE COMPARTMENT	49
ACCESSORY POWER SUPPLY — IGNITION		PASSENGER COMPARTMENT	50
SW. IN “ACC” OR “ON”	7	LUGGAGE COMPARTMENT	52
IGNITION POWER SUPPLY — IGNITION SW.		HARNESS CONNECTOR	53
IN “ON” AND/OR “START”	9	Description	53
Fuse	13	HARNESS CONNECTOR (TAB-LOCKING	
Fusible Link	13	TYPE)	53
Circuit Breaker	13	HARNESS CONNECTOR (SLIDE-LOCKING	
GROUND	14	TYPE)	54
Ground Distribution	14	JOINT CONNECTOR (J/C)	55
MAIN HARNESS	14	Terminal Arrangement	55
ENGINE ROOM HARNESS	17	ELECTRICAL UNITS	56
ENGINE HARNESS	20	Terminal Arrangement	56
ENGINE CONTROL HARNESS	21	SMJ (SUPER MULTIPLE JUNCTION)	58
BODY HARNESS	23	Terminal Arrangement	58
BODY NO.2 HARNESS	25	STANDARDIZED RELAY	60
HARNESS	27	Description	60
Harness Layout	27	NORMAL OPEN, NORMAL CLOSED AND	
HOW TO READ HARNESS LAYOUT	27	MIXED TYPE RELAYS	60
OUTLINE	28	TYPE OF STANDARDIZED RELAYS	60
MAIN HARNESS	29	FUSE BLOCK - JUNCTION BOX (J/B) NO.1	62
ENGINE ROOM HARNESS	32	Terminal Arrangement	62
ENGINE HARNESS	35	FUSE BLOCK - JUNCTION BOX (J/B) NO.2	63
ENGINE CONTROL HARNESS	36	Terminal Arrangement	63
BODY HARNESS	38	FUSE, FUSIBLE LINK AND RELAY BLOCK (J/B).. 64	
BODY NO. 2 HARNESS	40	Terminal Arrangement	64
ROOM LAMP HARNESS	42	FUSE, FUSIBLE LINK AND RELAY BOX	65
FRONT DOOR HARNESS	43	Terminal Arrangement	65

A
B
C
D
E
F
G
H
I
J
L
M






PG

POWER SUPPLY ROUTING

Wiring Diagram — POWER — BATTERY POWER SUPPLY— IGNITION SW. IN ANY POSITION

AKS002RR

PG-POWER-01



*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT".




REFER TO THE FOLLOWING.
E3 - FUSE, FUSIBLE LINK AND RELAY BLOCK (J/B)

PG
L
M

POWER SUPPLY ROUTING


PG-POWER-02

CS : WITH CLIMATE CONTROLLED SEAT



REFER TO THE FOLLOWING.

(E3) - FUSE, FUSIBLE LINK AND RELAY BLOCK (J/B)




*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT".



TKWA0684E

POWER SUPPLY ROUTING

PG-POWER-03



A
B
C
D
E
F
G
H
I
J
PG
L
M





*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT".

TKWA0685E

POWER SUPPLY ROUTING

PG-POWER-04



*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT".

REFER TO THE FOLLOWING.

(M1, E203, B1, B2)
-FUSE BLOCK-JUNCTION BOX (J/B) NO.1

1	2	3	4	5	6	7	8	9	10	11
12	13	14	15	16	17	18	19	20	21	22

(M143, M145, E215) -FUSE BLOCK-JUNCTION BOX (J/B) NO.2




31	32	33	34	35	36	37	38
----	----	----	----	----	----	----	----

TKWA0686E

POWER SUPPLY ROUTING

ACCESSORY POWER SUPPLY — IGNITION SW. IN "ACC" OR "ON"

PG-POWER-05



*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT".

REFER TO THE FOLLOWING.

(E205) -SUPER MULTIPLE JUNCTION (SMJ)



(M1), (E201), (E202) -FUSE BLOCK-JUNCTION BOX (J/B) NO.1

1	2	3	4	5	6	7	8	9	10	11
12	13	14	15	16	17	18	19	20	21	22

TKWA1655E


POWER SUPPLY ROUTING

PG-POWER-06



*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT".

REFER TO THE FOLLOWING.





TKWA0688E

POWER SUPPLY ROUTING

IGNITION POWER SUPPLY — IGNITION SW. IN "ON" AND/OR "START"

PG-POWER-07

Ⓢ : FOR CANADA



★: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT".

REFER TO THE FOLLOWING.

(E205) -SUPER MULTIPLE JUNCTION (SMJ)

(M1), (E202), (B2), (R1) -FUSE BLOCK-JUNCTION BOX (J/B) NO.1

1	2	3	4	5	6	7	8	9	10	11
12	13	14	15	16	17	18	19	20	21	22

(E3) -FUSE, FUSIBLE LINK AND RELAY BLOCK (J/B)


B	51	52	53	54	55	56	57
---	----	----	----	----	----	----	----

58

TKWA0689E

POWER SUPPLY ROUTING

PG-POWER-08



REFER TO THE FOLLOWING.



(M1), (E201) - FUSE BLOCK-
JUNCTION BOX (J/B) NO.1

1	2	3	4	5	6	7	8	9	10	11
12	13	14	15	16	17	18	19	20	21	22

TKWA1656E


POWER SUPPLY ROUTING

PG-POWER-09



*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT".

REFER TO THE FOLLOWING.





A
B
C
D
E
F
G
H
I
J
PG
L
M

TKWA0691E


POWER SUPPLY ROUTING

PG-POWER-10

⬡ : FOR CANADA



REFER TO THE FOLLOWING.




TKWA0692E

POWER SUPPLY ROUTING

Fuse

- If fuse is blown, be sure to eliminate cause of incident before installing new fuse.
- Use fuse of specified rating. Never use fuse of more than specified rating.
- Do not partially install fuse; always insert it into fuse holder properly.
- Remove fuse for "ELECTRICAL PARTS (BAT)" if vehicle is not used for a long period of time.




Fusible Link

A melted fusible link can be detected either by visual inspection or by feeling with finger tip. If its condition is questionable, use circuit tester or test lamp.


CAUTION:

- If fusible link should melt, it is possible that critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check and eliminate cause of incident.
- Never wrap outside of fusible link with vinyl tape. Important: Never let fusible link touch any other wiring harness, vinyl or rubber parts.



Circuit Breaker

The PTC thermistor generates heat in response to current flow. The temperature (and resistance) of the thermistor element varies with current flow. Excessive current flow will cause the element's temperature to rise. When the temperature reaches a specified level, the electrical resistance will rise sharply to control the circuit current. Reduced current flow will cause the element to cool. Resistance falls accordingly and normal circuit current flow is allowed to resume.



A
B
C
D
E
F
G
H
I
J
PG
L
M


GROUND

PFP:00011

AKS002RS

GROUND


Ground Distribution MAIN HARNESS



A Next page

CKIA0232E

GROUND




A
B
C
D
E
F
G
H
I
J
PG
L
M

PG

CKIA0233E

GROUND





CON-NECTOR NUMBER	CONNECT TO
M13	VDC off switch
M18	Headlamp aiming switch
M19	Door mirror remote control switch
M31	Data link connector (Terminal No. 4)
M34	Headlamp battery saver control unit (Terminal No.11)
M78	AV control unit (Terminal No. 1) (Without NAVI)
M78	AV control unit (Terminal No. 4) (Without NAVI)
E36	Shield wire (A/T pv ign relay) (Terminal No. 5)
M17	Illumination control switch
M33	Headlamp battery saver control unit (Terminal No. 4)
M35	ASCD control unit (Terminal No. 17)
M84	Low tire pressure warning control unit
M51	Steering position switch (Without automatic drive positioner)
M51	ADP steering switch (With automatic drive positioner)
M52	Steering angle sensor
M56	Combination switch (Front wiper switch) (Terminal No. 17)
M56	Combination switch (Front wiper switch) (Terminal No. 20)
M69	Steering lock control unit
M112	Blower motor
M116	Glove box lamp
M118	Intake door motor
M120	A/C auto amp.
M471	Mode door motor (Driver side)
M472	Air mix door motor (Driver side)
M55	Combination switch (Lighting switch) (Terminal No. 5)
M55	Combination switch (Lighting switch) (Terminal No. 8)

J/C: Joint connector

CKIA0359E


GROUND

ENGINE ROOM HARNESS



CON-NECTOR NUMBER	CONNECT TO
E10	Headlamp LH
E40	Headlamp RH
E3	Fuse, fusible link and relay block (J/B) (Terminal No.29R) • Ignition relay • Park/Neutral position relay
E2-2	Front wiper relay
E36	A/T pv ign relay
E38	ICC brake hold relay
E52	ICC sensor
F103	Shield wire [TCM (Transmission control module)] (Terminal No.2,3)

J/C : Joint connector




CON-NECTOR NUMBER	CONNECT TO
E6	Front fog lamp LH
E12	Front combination LAMP LH • Parking • Turn

A
B
C
D
E
F
G
H
I
J
PG
L
M

GROUND


A Preceding Page



CON-NECTOR NUMBER	CONNECT TO
E11	Headlamp aiming motor LH
E26	Daytime light control unit
E41	Headlamp aiming motor RH
E46	Front side marker lamp RH
E47	Washer level switch
E54	Hood switch
E66	Front side marker lamp LH
E73	Brake fluid level switch
E75	Front wiper motor
E76	Climate controlled seat relay
E201	Fuse block (J/B) No.1 (Terminal No.1E) • Accessory relay • Trunk lid opener relay
R1	Fuse block (J/B) No.1 (Terminal No.5K)
R5	Vanity mirror lamp (Driver side)
R6	Front interior lamp • Map lamp LH • Map lamp RH • Interior lamp ill switch
R8	Sunroof motor assembly
R9	Auto anti-dazzling inside mirror
R12	Vanity mirror lamp (Passenger side)
R13	Rear interior lamp • Personal lamp LH • Personal lamp RH
F3	Power steering solenoid valve
E7	Front fog lamp RH
E50	Front combination lamp RH • Parking • Turn

Internal connect



Body ground



CKIA0236E

GROUND


A
B
C
D
E
F
G
H
I
J
PG
L
M



CKIA0237E

GROUND


ENGINE HARNESS



CKIA0238E

GROUND

ENGINE CONTROL HARNESS




A
B
C
D
E
F
G
H
I
J
PG
L
M

PG

CKIA0239E


GROUND



CKIA0240E

GROUND

BODY HARNESS





*: This sub-harness is not shown in "HARNES LAYOUT".

A Next page

CKIA0241E

GROUND




CKIA0242E

GROUND

BODY NO.2 HARNESS



A
B
C
D
E
F
G
H
I
J
PG
L
M



* : This sub-harness is not shown in "HARNESS LAYOUT"

CKIA0243E

GROUND



CKIA0244E

HARNESS

HARNESS

PF0:00011

Harness Layout

AKS002RT


HOW TO READ HARNESS LAYOUT

The following Harness Layouts use a map style grid to help locate connectors on the drawings:

- Main Harness
- Engine Room Harness (Engine Compartment)
- Engine Control Harness
- Body Harness
- Body No.2 Harness

To use the grid reference

1. Find the desired connector number on the connector list.
2. Find the grid reference.
3. On the drawing, find the crossing of the grid reference letter column and number row.
4. Find the connector number in the crossing zone.
5. Follow the line (if used) to the connector.



CONNECTOR SYMBOL

Main symbols of connector (in Harness Layout) are indicated in the below.

Connector type	Water proof type		Standard type	
	Male	Female	Male	Female
<ul style="list-style-type: none"> • Cavity: Less than 4 • Relay connector 				
<ul style="list-style-type: none"> • Cavity: From 5 to 8 				
<ul style="list-style-type: none"> • Cavity: More than 9 	—	—		
<ul style="list-style-type: none"> • Ground terminal etc. 	—			


SKIA0404E

A
B
C
D
E
F
G
H
I
J
L
M

PG


HARNESS

OUTLINE



HARNESS

MAIN HARNESS



For detail ground distribution information, refer to "GROUND DISTRIBUTION".

*: Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes. Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

TKIA0125E


F3	(M108)	W/8	: Power steering control unit
E3	(M109)	W/16	: CD auto changer
F1	(M110)	W/3	: Optical sensor
E1	(M111)	W/4	: To (M411)
F3	(M112)	W/6	: Blower motor
G1	(M114)	—	: Body ground
G1	(M115)	—	: Body ground
G2	(M116)	W/2	: Glove box lamp
G2	(M117)	W/2	: Trunk lid opener cancel switch
G2	(M118)	W/3	: Intake door motor
G2	(M119)	GY/20	: A/C auto amp.
G2	(M120)	GY/16	: A/C auto amp.
G3	(M121)	Y/4	: Front passenger air bag module
F1	(M123)	L/20	: Joint connector-14
G1	(M124)	OR/20	: Joint connector-15
G1	(M125)	B/20	: Joint connector-16
E1	(M128)	OR/20	: Joint connector-19
G2	(M129)	G/20	: Joint connector-20
D1	(M130)	W/6	: Joint connector-21
G3	(M132)	W/20	: To (E222)
F3	(M133)	W/12	: To (E223)
G3	(M135)	SMJ	: To (F105)
G3	(M141)	SMJ	: To (E211)
G3	(M142)	SMJ	: To (D31)
G3	(M143)	W/10	: Fuse block (J/B) No.2
F3	(M144)	W/8	: Fuse block (J/B) No.2
F3	(M145)	W/6	: Fuse block (J/B) No.2
B4	(M146)	BR/2	: To (E78) (Without NAVI)
C1	(M147)	W/2	: Diode
B4	(M148)	W/10	: To (E79)
E3	(M149)	BR/2	: Microphone

Main sub-harness-1

D3	(M401)	W/4	: To (M61)
D4	(M402)	B/2	: Stop lamp switch
C4	(M403)	BR/2	: ASCD brake switch (Without ICC)
C4	(M404)	BR/2	: ICC brake switch (With ICC)

Main sub-harness-2

E1	(M411)	W/4	: To (M11)
A1	(M412)	BR/2	: Instrument speaker LH
G1	(M414)	BR/2	: Instrument speaker RH




★ : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes. Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

A
B
C
D
E
F
G
H
I
J
PG
L
M

HARNESS

ENGINE ROOM HARNESS Engine Compartment



TKIA0005E

HARNESSES

C1	(E1)	—	: Engine room box
A1	(E2)	—	: Fuse, fusible link and relay box
C1	(E3)	SMJ	: Fuse, fusible link and relay block (J/B)
A1	(E5)	L/4	: Headlamp relay-2
D4	(E6)	L/2	: Front fog lamp LH
B3	(E7)	L/2	: Front fog lamp RH
D3	(E9)	B/2	: Headlamp LH
D4	(E10)	B/2	: Headlamp LH
D4	(E11)	B/3	: Headlamp aiming motor LH
D4	(E12)	GY/3	: Front combination lamp LH
C1	(E15)	SB/4	: ASCD pump (With ICC)
C1	(E16)	SB/4	: ASCD pump (Without ICC)
D2	(E20)	GY/2	: Front wheel sensor RH
D1	(E21)	DGY/8	: VDC actuator
E1	(E22)	SB/8	: VDC actuator
E1	(E23)	B/2	: VDC actuator
D2	(E24)	—	: Body ground
E3	(E26)	SB/8	: Daytime light control unit
E3	(E27)	SB/6	: Daytime light control unit
D3	(E28)	SB/4	: Daytime light control unit
C1	(E30)	B/1	: Security horn
D2	(E33)	GY/8	: To (F33)
D2	(E34)	B/10	: To (F34)
C2	(E35)	GY/9	: To (E305)
C2	(E36)	L/4	: A/T pv ign relay
F2	(E38)	GY/6	: ICC brake hold relay (With ICC)
B3	(E39)	B/2	: Headlamp RH
B2	(E40)	B/2	: Headlamp RH
B2	(E41)	B/3	: Headlamp aiming motor RH
B2	(E42)	—	: Body ground
C3	(E43)	B/1	: Horn low

(For Canada)


B3	(E46)	GY/2	: Front side marker lamp RH
B3	(E47)	BR/2	: Washer level switch
B3	(E48)	GY/2	: Front washer motor
C2	(E49)	B/3	: Refrigerant pressure sensor
B2	(E50)	GY/3	: Front combination lamp RH
C4	(E52)	-/6	: ICC sensor (With ICC)
C3	(E54)	GY/2	: Hood switch
F3	(E55)	W/2	: VDC relay box
F2	(E56)	DGY/8	: VDC relay box
F2	(E57)	B/2	: VDC relay box
C3	(E58)	B/2	: Ambient sensor
C3	(E60)	Y/2	: Crash zone sensor
E3	(E62)	—	: Body ground
C3	(E63)	B/1	: Horn high
C4	(E64)	GY/2	: Radiator coolant temperature sensor
E4	(E66)	GY/2	: Front side marker lamp LH
D2	(E67)	—	: Body ground
D2	(E69)	—	: Body ground
E2	(E70)	GY/2	: Front wheel sensor LH
E2	(E73)	GY/2	: Brake fluid level switch
F1	(E75)	SB/6	: Front wiper motor
C2	(E76)	BR/6	: Climate controlled seat relay
F2	(E77)	W/3	: Security horn relay
A1	(E78)	—	: Fuse block
E1	(E81)	GY/6	: Brake booster
E2	(E82)	-/3	: Brake pressure sensor } (With ICC)

★ : Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

A
B
C
D
E
F
G
H
I
J
L
M
PG

HARNESS

Passenger Compartment



- ★ E201 : W/8 : Fuse block (J/B) No.1
- E202 : W/4 : Fuse block (J/B) No.1
- E203 : W/4 : Fuse block (J/B) No.1
- E204 : BR/8 : BCM (Body control module)
- ★ E205 : SMJ : To M15
- E206 : Y/4 : To M16
- E212 : W/6 : To B12
- E215 : W/6 : Fuse block (J/B) No.2
- E216 : W/8 : Fuse block (J/B) No.1
- E217 : W/4 : Fuse block (J/B) No.1
- E218 : W/4 : Fuse block (J/B) No.1
- E222 : BR/8 : BCM (Body control module)
- ★ E223 : SMJ : To M132
- ★ E224 : W/12 : To M133
- E225 : BR/4 : To G204
- E229 : W/20 : To G205
- P/20 : Joint connector-25
- L/4 : Front fog lamp relay
- SMJ : VDC/TCS/ABS control unit
- W/20 : To M132
- W/12 : To M133
- BR/4 : To G204
- W/20 : To G205



★ : Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

TKIA0007E

HARNESS

ENGINE HARNESS

- (E301) : Battery (+)
- (E302) : Fuse, fusible link and relay box and fuse, fusible link and relay block (J/B)
- (E303) : Battery (+)
- ★ (E305) GY/9 : To (E35)
- (E307) : Body ground
- ★ (E308) B/3 : Power steering pressure sensor
- (E309) : Alternator
- (E310) GY/2 : Alternator
- (E311) : Alternator
- (E312) GY/1 : Starter motor
- (E313) : Starter motor
- ★ (E315) GY/10 : To (F5)
- ★ (E316) BR/3 : To (F6)
- ★ (E317) B/3 : Crankshaft position sensor (POS)
- ★ (E318) L/4 : Heated oxygen sensor 2 (Bank 2)
- ★ (E319) G/4 : Heated oxygen sensor 2 (Bank 1)



For detail ground distribution information, refer to "GROUND DISTRIBUTION".


- ★ : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes. Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

TKIA0008E

A
B
C
D
E
F
G
H
I
J
PG
L
M

HARNESS

ENGINE CONTROL HARNESS



TKIA0009E

Engine control harness

C4	F1	GY/1	: Oil pressure switch
D4	F2	B/1	: Compressor
E4	F3	BR/2	: Power steering solenoid valve
E5	F4	B/3	: Camshaft position sensor (PHASE)
D5	F5	GY/10	: To (E315)
D5	F6	B/3	: To (E316)
E4	F7	GY/5	: Mass air flow sensor
E4	F8	—	: Engine ground
E3	F9	—	: Engine ground
D4	F10	B/2	: Compressor
E4	F12	B/3	: Intake valve timing control position sensor (Bank 1)
D3	F13	G/2	: Intake valve timing control solenoid valve (Bank 1)
D3	F14	GY/2	: Cooling fan speed control solenoid valve
E4	F15	GY/3	: Ignition coil (With power transistor No.1)
F4	F16	GY/3	: Ignition coil (With power transistor No.3)
F3	F17	GY/3	: Ignition coil (With power transistor No.5)
G3	F18	GY/3	: Ignition coil (With power transistor No.7)
E2	F19	G/6	: Electric throttle control actuator
G3	F20	L/6	: Electric throttle control actuator
F2	F21	G/6	: To (F201)
F2	F22	G/4	: Heated oxygen sensor 1 (Bank 1)
E1	F23	GY/2	: Condenser
G2	F24	SB/2	: To (F261)
E2	F25	L/2	: EVAP canister purge volume control solenoid valve
F1	F26	G/10	: A/T assembly
F1	F27	G/8	: A/T assembly
F1	F28	B/8	: A/T assembly
D3	F29	B/2	: V/AS control solenoid valve
C3	F30	B/3	: Intake valve timing control position sensor (Bank 2)
C3	F31	G/2	: Intake valve timing control solenoid valve (Bank 2)
C2	F33	GY/8	: To (E33)
C2	F34	B/10	: To (E34)
C3	F35	GY/3	: Ignition coil (With power transistor No.2)
C2	F36	GY/3	: Ignition coil (With power transistor No.4)
C2	F37	GY/3	: Ignition coil (With power transistor No.6)
D2	F38	GY/3	: Ignition coil (With power transistor No.8)
D2	F40	DGY/4	: To (F241)
C2	F41	G/6	: To (F221)
D1	F42	G/4	: Heated oxygen sensor 1 (Bank 2)

A5	F101	SMJ	: ECM
A5	F102	SMJ	: ECM
B4	F103	W/24	: TCM (Transmission control module)
B5	F104	GY/24	: TCM (Transmission control module)
B4	F105	SMJ	: To (M135)
B4	F106	P/20	: Joint connector-28
A4	F107	P/20	: Joint connector-29
B4	F108	L/12	: Joint connector-30

Engine control sub-harness-1

G2	F201	G/6	: To (F21)
F4	F202	GY/2	: Injector No.1
F3	F203	GY/2	: Injector No.3
F3	F204	GY/2	: Injector No.5
F3	F205	GY/2	: Injector No.7

Engine control sub-harness-2

E3	F221	G/6	: To (F41)
D3	F222	GY/2	: Injector No.2
D3	F223	GY/2	: Injector No.4
D3	F224	GY/2	: Injector No.6
E2	F225	GY/2	: Injector No.8

Engine control sub-harness-3

E2	F241	B/4	: To (F40)
E2	F242	GY/2	: Knock sensor (Bank 1)
E2	F243	GY/2	: Knock sensor (Bank 2)


Engine control sub-harness-4

G2	F261	SB/2	: To (F24)
G2	F262	GY/2	: Engine coolant temperature sensor

★ : Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

HARNESS

BODY HARNESS



TKIA0076E


★ A1	(B1)	W/8	: Fuse block (J/B) No.1	D2	(B39)	GY/2	: Condenser
A1	(B2)	W/6	: Fuse block (J/B) No.1	D3	★ (B45)	W/2	: Dropping resistor
B1	(B4)	W/8	: BCM (Body control module)	E2	★ (B51)	W/6	: Fuel level sensor unit and fuel pump
B1	★ (B5)	SMJ	: To (M5)	F4	(B52)	GY/2	: Rear side marker lamp LH
A3	(B7)	W/24	: To (M7)	F3	(B53)	W/6	: Rear combination lamp LH
A3	(B8)	BR/6	: Rear window defogger and door mirror defogger relay	G3	(B55)	W/4	: Trunk closure control unit
A3	(B10)	L/4	: Door mirror defogger relay	G2	(B56)	GY/2	: Rear side marker lamp RH
A1	(B12)	W/6	: To (E212)	G3	(B57)	—	: Body ground
C1	(B13)	Y/12	: Air bag diagnosis sensor unit	G1	(B58)	W/6	: Rear combination lamp RH
C2	(B14)	Y/2	: Front LH side air bag module	G1	★ (B61)	GY/24	: To (B261)
C2	(B15)	W/10	: Front power seat (Driver side) (Via sub-harness)	G1	★ (B62)	W/10	: To (B262)
B3	(B16)	—	: Body ground	E3	(B69)	W/22	: Voice activated control module
B3	(B17)	—	: Body ground	E3	(B71)	GY/3	: Voice activated control module
C3	(B18)	Y/2	: LH side air bag (satellite) sensor	E3	(B72)	-/4	: Option connector-2 for voice activated system
C3	(B19)	Y/2	: Front LH seat belt pre-tensioner	A2	(B76)	L/4	: Back-up lamp relay
B3	(B20)	W/3	: Front door switch (Driver side)	C2	(B77)	W/2	: To (E273)
B2	(B21)	W/18	: To (D51)	B1	(B78)	BR/2	: To (M146)
D1	(B24)	Y/2	: LH side curtain air bag module	B2	(B79)	W/10	: To (M148)
D1	(B25)	W/1	: Condenser (Rear window defogger)	E3	(B80)	W/16	: Jumping connector (For Satellite radio receiver)
D1	(B26)	W/4	: Remote keyless entry receiver	E3	(B81)	W/16	: Jumping connector (For Satellite radio receiver)
C1	(B27)	W/16	: Option connector-1 for voice activated system				
E2	(B29)	GY/24	: AV and NAVI control unit } (With NAVI)				
E2	(B30)	W/24	: AV and NAVI control unit }				
E3	(B35)	SB/4	: Rear wheel sensor				
E4	(B36)	GY/2	: Dual mode muffler actuator				

★ : Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

A
B
C
D
E
F
G
H
I
J
L
M
PG

HARNESS

BODY NO. 2 HARNESS



For detail ground distribution information, refer to "GROUND DISTRIBUTION".

- ★ : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

Body No.2 harness

G1	(B201)	W/4	: Fuse block (J/B) No.2
G3★	(B204)	BR/4	: To (E224)
G3	(B205)	W/20	: To (E225)
F1★	(B211)	SMJ	: To (M141)
E2	(B213)	Y/12	: Air bag diagnosis sensor unit
F2	(B214)	Y/2	: Front RH side air bag module
E2	(B215)	W/8	: Front power seat (Passenger side) (Via sub-harness)
			(Without climate controlled seat)
F3	(B216)	—	: Body ground
F3★	(B217)	—	: Body ground
F3	(B218)	Y/2	: RH side air bag (satellite) sensor
E3	(B219)	Y/2	: Front RH seat belt pre-tensioner
F2	(B220)	W/3	: Front door switch (Passenger side)
D1	(B224)	Y/2	: RH side curtain air bag module
C2	(B231)	B/6	: BOSE speaker amp.
C2	(B232)	W/4	: BOSE speaker amp.
C2	(B233)	LG/Y/8	: BOSE speaker amp.
B2	(B234)	B/24	: BOSE speaker amp.
B2	(B235)	W/2	: Woofer
C1	(B237)	W/2	: High-mounted stop lamp
C2	(B238)	W/2	: Trunk room lamp
D2★	(B240)	W/4	: Fuel pump control module (FPCM)
D3	(B243)	W/24	: ICC unit
D3	(B244)	GY/24	: ICC unit
C3	(B245)	G/24	: ICC unit
C4★	(B251)	SB/8	: To (B401)
D2★	(B256)	—	: Body ground
D2	(B257)	—	: Body ground (With ICC)
D3	(B258)	W/6	: Dual mode muffler control unit
D2	(B259)	W/4	: Fuel lid opener actuator
A3	(B260)	W/3	: Trunk lid key cylinder switch (Unlock switch)
C3★	(B261)	GY/24	: To (B61)
C3★	(B262)	W/10	: To (B62)

A2	(B263)	BR/2	: License lamp RH
A2	(B264)	BR/2	: License lamp LH
A3	(B265)	B/2	: Trunk lid opener actuator
A3	(B266)	W/2	: Trunk room lamp switch
F2	(B271)	W/18	: To (D71)
E2	(B272)	W/10	: Front power seat (Passenger side) (Via sub-harness)
			(With climate controlled seat)
E2	(B273)	W/2	: To (B77)
C1	(B274)	W/2	: Diode


Body No.2 sub-harness-1

D4★	(B401)	SB/8	: To (B251)
D3★	(B402)	B/2	: EVAP canister vent control valve
E3★	(B403)	BR/3	: EVAP control system pressure sensor
E3★	(B404)	G/2	: Vacuum cut valve bypass valve

Body No.2 sub-harness-2

D1	(B421)	B/1	: Rear window defogger (-)
E1	(B422)	—	: Body ground

Diode (B274)




★ : Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

A
B
C
D
E
F
G
H
I
J
PG
L
M

HARNESS

ROOM LAMP HARNESS



(R1)	W/10	:	Fuse block (J/B) No.1
(R3)	W/12	:	To (M23)
(R4)	W/12	:	BCM (Body control module)
(R5)	W/2	:	Vanity mirror lamp (Driver side)
(R6)	W/8	:	Front interior lamp
(R7)	BR/6	:	Sunroof switch
(R8)	W/12	:	Sunroof motor assembly
(R9)	B/10	:	Auto anti-dazzling inside mirror
(R10)	W/12	:	Microphone
(R12)	W/2	:	Vanity mirror lamp (Passenger side)
(R13)	W/6	:	Rear interior lamp


TKIA0015E

HARNESS

FRONT DOOR HARNESS

LH Side


- | | |
|---|---|
| (D1) SMJ : To (M11) | (D7) GY/6 : Front power window regulator (Driver side) |
| (D2) BR/16 : Door mirror (Driver Side) | (D8) W/18 : Driver door control unit (LCU01) |
| (D3) GY/8 : Seat memory switch | (D9) W/3 : Trunk lid and fuel lid opener switch |
| (D5) W/10 : Driver side door mirror control unit (LCU03) (With memory mirror) | (D10) W/2 : Front step lamp (Driver side) |
| (D6) BR/2 : Front door speaker LH | (D11) SB/4 : Front door lock actuator (Driver side) |
| | (D12) BR/3 : Front door key cylinder switch (Driver side) |



TKIA0016E

RH Side

- | | |
|---|--|
| (D31) SMJ : To (M142) | (D37) GY/6 : Front power window regulator (Passenger side) |
| (D32) BR/16 : Door mirror (Passenger side) | (D38) W/16 : Passenger door control unit |
| (D35) W/10 : Passenger side door mirror control unit (LCU04) (With memory mirror) | (D40) W/2 : Front step lamp (Passenger side) |
| (D36) BR/2 : Front door speaker RH | (D41) SB/4 : Front door lock actuator (Passenger side) |



TKIA0017E


A
B
C
D
E
F
G
H
I
J
PG
L
M

HARNESS

REAR DOOR HARNESS

LH Side


- | | | | | | |
|------------|---|--------------------------------|------------|---|---|
| (D51) W/18 | : | To (B21) | (D60) W/2 | : | Rear step lamp LH |
| (D54) W/3 | : | Rear ashtray LH illumination | (D61) SB/4 | : | Rear door lock actuator LH |
| (D56) BR/2 | : | Rear door speaker LH | (D62) B/2 | : | Door lock assembly rear LH
(Door switch) |
| (D57) B/2 | : | Rear power window regulator LH | | | |
| (D58) W/16 | : | Rear LH door control unit | | | |



TKIA0018E

RH Side

- | | | | | | |
|------------|---|--------------------------------|------------|---|--|
| (D71) W/18 | : | To (B271) | (D80) W/2 | : | Rear step lamp RH |
| (D74) W/3 | : | Rear ashtray RH illumination | (D81) SB/4 | : | Rear door lock actuator RH |
| (D76) BR/2 | : | Rear door speaker RH | (D82) B/2 | : | Door lock assembly rear RH (Door switch) |
| (D77) B/2 | : | Rear power window regulator RH | | | |
| (D78) W/16 | : | Rear RH door control unit | | | |



TKIA0019E

HARNESS

Wiring Diagram Codes (Cell Codes)

AKS002RV

Use the chart below to find out what each wiring diagram code stands for. Refer to the wiring diagram code in the alphabetical index to find the location (page number) of each wiring diagram.

Code	Section	Wiring Diagram Name
A/C	ATC	Air Conditioner
APPS1	EC	Accelerator Pedal Position Sensor
APPS2	EC	Accelerator Pedal Position Sensor
APPS3	EC	Accelerator Pedal Position Sensor
ASCD	ACS	Automatic Speed Control Device
AT/IND	DI	A/T Indicator
AUDIO	AV	Audio
AUT/DP	SE	Automatic Drive Positioner - IVMS
BACK/L	LT	Back-up Lamp
BRK/SW	EC	Brake Switch
BYPS/V	EC	Vacuum Cut Valve Bypass Valve
CAN	AT	CAN Communication Line
CAN	EC	CAN Communication Line
CAN	LAN	CAN System
CD/CHG	AV	CD Auto Changer
CHARGE	SC	Charging System
CHIME	DI	Warning Chime
CIGAR	WW	Cigarette Lighter
CLOCK	DI	Clock
COMM	AV	Audio Visual Communication Line
COMM	DI	Audio Visual Communication Line
COMM	LAN	IVMS - Communication Check, Power Supply & Ground
COMPAS	DI	Auto Anti - Dazzling Inside Mirror (COMPASS)
COOL/V	EC	Cooling Fan Speed Control Solenoid Valve
C/SEAT	SE	Climate Controlled Seat
D/C	AT	Direct Clutch Solenoid Valve
D/CF	AT	Direct Clutch Solenoid Valve Function
D/LOCK	BL	Power Door Lock - IVMS
DEF	GW	Rear Window Defogger
DLC	EC	Data Link Connectors
DTRL	LT	Headlamp - With Daytime Light System
E/BRE	AT	A/T 1st Engine Braking
ECM/PW	EC	ECM Power Supply (Back - up)
ECTS	EC	Engine Coolant Temperature Sensor
EPS	STC	Electronic Controlled Power Steering System
ETC1	EC	Electrical Throttle Function
ETC2	EC	Electrical Throttle Control Motor Relay
ETC3	EC	Electrical Throttle Control Motor
F/FOG	LT	Front Fog Lamp
F/PUMP	EC	Fuel Pump
FR/B	AT	Front Brake Solenoid Valve

HARNESS

Code	Section	Wiring Diagram Name
FR/BF	AT	Front Brake Solenoid Valve Function
FLS1	EC	Fuel Level Sensor Function (SLOSH)
FLS2	EC	Fuel Level Sensor Circuit
FLS3	EC	Fuel Level Sensor Circuit (Ground Signal)
FPCM	EC	Fuel Pump Control Module
FPSW1	AT	Pressure Switch 1 (FR/B)
FPSW3	AT	Pressure Switch 3 (I/C)
FPSW5	AT	Pressure Switch 5 (D/C)
FPSW6	AT	Pressure Switch 6 (HLR/C)
FTS	AT	A/T Fluid Temperature Sensor
FTTS	EC	Fuel tank Temperature Sensor
FUELB1	EC	Fuel Injection System Function (Bank 1)
FUELB2	EC	Fuel Injection System Function (Bank 2)
H/AIM	LT	Headlamp Aiming Control System
H/LAMP	LT	Headlamp
HLR/C	AT	High and Low Reverse Clutch Solenoid Valve
HLR/CF	AT	High and Low Reverse Clutch Solenoid Valve Function
HORN	WW	Horn
I/C	AT	Input Clutch Solenoid Valve
I/CF	AT	Input Clutch Solenoid Valve Function
I/LOCK	AT	A/T Interlock
I/MIRR	GW	Inside Mirror (Auto-anti dazzling mirror)
IATS	EC	Intake Air Temperature Sensor
ICC	ACS	Intelligent Cruise Control System
IGN/SG	EC	Ignition Signal
ILL	LT	Illumination
INF/D	DI	Information Display
INJECT	EC	Injector
INT/L	LT	Vanity Mirror and Trunk Room Lamps
IVCB1	EC	Intake Valve Timing Control Solenoid Valve Bank 1
IVCB2	EC	Intake Valve Timing Control Solenoid Valve Bank 2
IVCSB1	EC	Intake Valve Timing Control Position Sensor Bank 1
IVCSB2	EC	Intake Valve Timing Control Position Sensor Bank 2
IVTB1	EC	Intake Valve Timing Control System (Bank 1)
IVTB2	EC	Intake Valve Timing Control System (Bank 2)
KEYLES	BL	Remote Keyless Entry System - IVMS
KS	EC	Knock Sensor
LC/B	AT	Low Coast Break Solenoid Valve
LC/BF	AT	Low Coast Break Solenoid Valve Function
LOAD	EC	Electrical Load Signal
LPSV	AT	Line Pressure Solenoid Valve
MAFS	EC	Mass Air Flow Sensor
MAIN	EC	Main Power Supply and Ground Circuit
METER	DI	Speedometer, Tachometer, Temp., Oil and Fuel Gauges

HARNESS

Code	Section	Wiring Diagram Name
MIL	EC	Malfunction Indicator Lamp
MIRROR	GW	Door Mirror
MMSW	AT	Manual Mode Switch
NATS	BL	IVIS (Infiniti Vehicle Immobilizer System - NATS)
NAVI	AV	Navigation System
NONDTC	AT	Non-detective Items
O2H1B1	EC	Heated Oxygen Sensor 1 Heater Bank 1
O2H1B2	EC	Heated Oxygen Sensor 1 Heater Bank 2
O2H2B1	EC	Rear Heated Oxygen Sensor 2 Heater Bank 1
O2H2B2	EC	Rear Heated Oxygen Sensor 2 Heater Bank 2
O2S1B1	EC	Heated Oxygen Sensor 1 Bank 1
O2S1B2	EC	Heated Oxygen Sensor 1 Bank 2
O2S2B1	EC	Rear Heated Oxygen Sensor 2 Bank 1
O2S2B2	EC	Rear Heated Oxygen Sensor 2 Bank 2
PGC/V	EC	EVAP Canister Purge Volume Control Solenoid Valve
PHASE	EC	Camshaft Position Sensor (PHASE)
PHONE	AV	Telephone
PNP/SW	AT	Park/Neutral Position Switch
PNP/SW	EC	Park/Neutral Position Switch
POS	EC	Crankshaft Position Sensor (CKPS) (POS)
POWER	AT	Transmission Control Module Power Supply
POWER	PG	Power Supply Routing
PRE/SE	EC	EVAP Control System Pressure Sensor
PS/SEN	EC	Power Steering Pressure Sensor
RCTS	EC	Radiator Coolant Temperature Sensor
REMOTE	AV	Audio (Remote Control Switch)
ROOM/L	LT	Interior Room Lamp - IVMS
RP/SEN	EC	Refrigerant Pressure Sensor
S/SIG	EC	Start Signal
SEAT	SE	Power Seat
SEN/PW	EC	Sensor Power Supply
SHIFT	AT	A/T Shift Lock System
SROOF	BL	Sunroof
SRS	SRS	Supplemental Restraint System
START	SC	Starting System
STEP/L	LT	Step Lamp - IVMS
STOP/L	LT	Stop Lamp
STSIG	AT	Start Signal
T&FLID	BL	Trunk Lid and Fuel Lid Opener
T/CLOS	BL	Trunk Closure System
T/WARN	WT	Low Tire Pressure Warning System
TAIL/L	LT	Parking, License and Tail Lamps
TCCSIG	AT	A/T TCC S/V Function (Lock Up)
TCV	AT	Torque Converter Clutch Solenoid Valve

A
B
C
D
E
F
G
H
I
J
PG
L
M

HARNESS

Code	Section	Wiring Diagram Name
TILTEL	STC	Electric Tilt, Telescopic Steering Position System
TPS1	EC	Throttle Position Sensor (Sensor 1)
TPS2	EC	Throttle Position Sensor (Sensor 2)
TPS3	EC	Throttle Position Sensor
TRNSCV	BL	Homelink Universal Transceiver
TRSA/T	AT	Turbine Revolution Sensor
TURN	LT	Turn Signal and Hazard Warning Lamps
VDC	BRC	Vehicle Dynamics Control System
VEHSEC	BL	Vehicle Security System - IVMS
VENT/V	EC	EVAP Canister Vent Control Valve
VEXH	EX	Variable Exhaust Muffler Control System
VIAS/V	EC	Variable Air Induction Control System
VOICE	DI	Voice Activated Control System
VSSAT	AT	Vehicle Speed Sensor A/T (Revolution Sensor)
W/ANT	AV	Audio Antenna
WARN	DI	Warning Lamps
WINDOW	GW	Power Window - IVMS
WIPER	WW	Wiper and Washer



ELECTRICAL UNITS LOCATION

ELECTRICAL UNITS LOCATION

PFP:25230

Electrical Units Location ENGINE COMPARTMENT

AKS002RW




A
B
C
D
E
F
G
H
I
J

PG


L
M

ELECTRICAL UNITS LOCATION


PASSENGER COMPARTMENT



A Dash side LH




In back of the fuse block (J/B) No. 1













CKIA0228E

ELECTRICAL UNITS LOCATION



In back of the fuse block (J/B) No. 2





CKIA0229E

A
B
C
D
E
F
G
H
I
J
K
L
M

PG

ELECTRICAL UNITS LOCATION

LUGGAGE COMPARTMENT



CKIA0230E

HARNESS CONNECTOR

HARNESS CONNECTOR

PFP:00011

Description

HARNESS CONNECTOR (TAB-LOCKING TYPE)

AKS002S0


- The tab-locking type connectors help prevent accidental looseness or disconnection.
- The tab-locking type connectors are disconnected by pushing or lifting the locking tab(s). Refer to the illustration below.

Refer to the next page for description of the slide-locking type connector.

CAUTION:

Do not pull the harness or wires when disconnecting the connector.

[Example]



A
B
C
D
E
F
G
H
I
J
PG
L
M

SEL769DA

HARNESS CONNECTOR


HARNESS CONNECTOR (SLIDE-LOCKING TYPE)

- A new style slide-locking type connector is used on certain systems and components, especially those related to OBD.
- The slide-locking type connectors help prevent incomplete locking and accidental looseness or disconnection.
- The slide-locking type connectors are disconnected by pushing or pulling the slider. Refer to the illustration below.

CAUTION:

- **Do not pull the harness or wires when disconnecting the connector.**
- **Be careful not to damage the connector support bracket when disconnecting the connector.**

[Example]




JOINT CONNECTOR (J/C)

PFP:B4341

AKS002S1

JOINT CONNECTOR (J/C)


Terminal Arrangement



J/C-1 **M9**

J/C-5 **M38**


J/C-13 **M81**



J/C-2 **M10**

J/C-7 **M46**

J/C-9 **M48**




(Pink)

J/C-25 **E216**


J/C-28 **F106**

J/C-29 **F107**



(Black)


J/C-16 **M125**



J/C-3 **M21**


J/C-8 **M47**

J/C-20 **M129**




J/C-10 **M49**

J/C-14 **M123**



(Gary)



(Blue)




J/C-11 **M79**


J/C-25 **E216**

J/C-15 **M124**


J/C-19 **M128**



(Green)




(Orange)




J/C-6 **M45**


J/C-21 **M130**



(White)



J/C-30 **F108**



(Blue)

A

B

C

D

E

F

G

H

I

J

PG





L

M




CKIA0264E

ELECTRICAL UNITS

BCM (BODY CONTROL MODULE)



ICC UNIT



A
B
C
D
E
F
G
H
I
J
L
M

PG


SMJ (SUPER MULTIPLE JUNCTION)

SMJ (SUPER MULTIPLE JUNCTION)

PFP:B4341

Terminal Arrangement

AKS002S3



CKIM0061E

SMJ (SUPER MULTIPLE JUNCTION)



MAIN HARNESS

M5 (White)

1U	2U	3U	4U	5U	11U 12U 13U 14U 15U 16U 17U 18U 19U 20U	30U 31U 32U 33U 34U 35U 36U 37U 38U
6U	7U	8U	9U	10U	21U 22U 23U 24U 25U 26U 27U 28U 29U	39U 40U 41U 42U 43U 44U 45U 46U

6U	7U	8U	9U	10U	21U 22U 23U 24U 25U 26U 27U 28U 29U	39U 40U 41U 42U 43U 44U 45U 46U
1U	2U	3U	4U	5U	11U 12U 13U 14U 15U 16U 17U 18U 19U 20U	30U 31U 32U 33U 34U 35U 36U 37U 38U

B5 (White)

BODY HARNESS



MAIN HARNESS

M135 (White)

6T	7T	8T	9T	10T	21T 22T 23T 24T 25T 26T 27T 28T 29T	39T 40T 41T 42T 43T 44T 45T 46T
1T	2T	3T	4T	5T	11T 12T 13T 14T 15T 16T 17T 18T 19T 20T	30T 31T 32T 33T 34T 35T 36T 37T 38T

1T	2T	3T	4T	5T	11T 12T 13T 14T 15T 16T 17T 18T 19T 20T	30T 31T 32T 33T 34T 35T 36T 37T 38T
6T	7T	8T	9T	10T	21T 22T 23T 24T 25T 26T 27T 28T 29T	39T 40T 41T 42T 43T 44T 45T 46T

F105 (White)

ENGINE CONTROL HARNESS



MAIN HARNESS

M11 (White)

20W 21W 22W 23W 24W 25W 26W 27W	36W	37W	38W	39W
11W 12W 13W 14W 15W 16W 17W 18W 19W	32W	33W	34W	35W
1W 2W 3W 4W 5W 6W 7W 8W 9W 10W	28W	29W	30W	31W

M142 (White)

20X 21X 22X 23X 24X 25X 26X 27X	36X	37X	38X	39X
11X 12X 13X 14X 15X 16X 17X 18X 19X	32X	33X	34X	35X
1X 2X 3X 4X 5X 6X 7X 8X 9X 10X	28X	29X	30X	31X

D1 (White)

1W 2W 3W 4W 5W 6W 7W 8W 9W 10W	28W	29W	30W	31W
11W 12W 13W 14W 15W 16W 17W 18W 19W	32W	33W	34W	35W
20W 21W 22W 23W 24W 25W 26W 27W	36W	37W	38W	39W

D31 (White)

1X 2X 3X 4X 5X 6X 7X 8X 9X 10X	28X	29X	30X	31X
11X 12X 13X 14X 15X 16X 17X 18X 19X	32X	33X	34X	35X
20X 21X 22X 23X 24X 25X 26X 27X	36X	37X	38X	39X

FRONT DOOR HARNESS (DRIVER SIDE)

FRONT DOOR HARNESS (PASSENGER SIDE)

A
B
C
D
E
F
G
H
I
J
PG
L
M

CKIM0062E

STANDARDIZED RELAY


PFP:00011

AKS002S4

STANDARDIZED RELAY

Description NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS


Relays can mainly be divided into three types: normal open, normal closed and mixed type relays.



SEL881H















TYPE OF STANDARDIZED RELAYS

- 1M 1 Make
- 2M 2 Make
- 1T 1 Transfer
- 1M-1B 1 Make 1 Break



SEL882H

STANDARDIZED RELAY

Type	Outer view	Circuit	Connector symbol and connection	Case color
1T				BLACK
2M				BROWN
1M•1B				GRAY
1M				BLUE
				

The arrangement of terminal numbers on the actual relays may differ from those shown above.

SEL188W

A
B
C
D
E
F
G
H
I
J
PG
L
M


FUSE BLOCK - JUNCTION BOX (J/B) NO.1

PF24350

AKS002S5

FUSE BLOCK - JUNCTION BOX (J/B) NO.1

Terminal Arrangement



CKIA0265E


FUSE BLOCK - JUNCTION BOX (J/B) NO.2

FUSE BLOCK - JUNCTION BOX (J/B) NO.2

PFP:24350

Terminal Arrangement

AKS002S6



A
B
C
D
E
F
G
H
I
J
PG
L
M



FUSE, FUSIBLE LINK AND RELAY BLOCK (J/B)

PFP:24382

AKS002S7

FUSE, FUSIBLE LINK AND RELAY BLOCK (J/B)

Terminal Arrangement



CKIM0066E



FUSE, FUSIBLE LINK AND RELAY BOX

FUSE, FUSIBLE LINK AND RELAY BOX


PFP:24382

Terminal Arrangement

AKS002S8



C to L FUSIBLE LINK
No. 71 to 78 FUSE



No. 82 FUSE

A
B
C
D
E
F
G
H
I
J
PG
L
M

FUSE, FUSIBLE LINK AND RELAY BOX
