

A
B
C
D
E

SECTION **BRC**

BRAKE CONTROL SYSTEM

CONTENTS

| | | |
|---|----|------------|
| VDC/TCS/ABS | | BRC |
| BASIC INSPECTION | 4 | |
| DIAGNOSIS AND REPAIR WORKFLOW | 4 | |
| Work Flow | 4 | |
| Diagnostic Work Sheet | 7 | |
| INSPECTION AND ADJUSTMENT | 8 | |
| ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT | 8 | |
| ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description | 8 | |
| ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement | 8 | |
| ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION | 8 | |
| ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description | 8 | |
| ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement | 8 | |
| FUNCTION DIAGNOSIS | 10 | |
| VDC | 10 | |
| System Diagram | 10 | |
| System Description | 10 | |
| Component Parts Location | 11 | |
| Component Description | 12 | |
| TCS | 13 | |
| System Diagram | 13 | |
| System Description | 13 | |
| Component Parts Location | 14 | |
| Component Description | 15 | |
| ABS | 16 | |
| System Diagram | 16 | |
| System Description | 16 | |
| Component Parts Location | 17 | |
| Component Description | 18 | |
| EBD | 19 | |
| System Diagram | 19 | |
| System Description | 19 | |
| Component Parts Location | 20 | |
| Component Description | 21 | |
| DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)] | 22 | |
| CONSULT-III Function (ABS) | 22 | |
| COMPONENT DIAGNOSIS | 27 | |
| C1101, C1102, C1103, C1104 WHEEL SENSOR-1 | 27 | |
| Description | 27 | |
| DTC Logic | 27 | |
| Diagnosis Procedure | 27 | |
| Component Inspection | 29 | |
| Special Repair Requirement | 29 | |
| C1105, C1106, C1107, C1108 WHEEL SENSOR-2 | 30 | |
| Description | 30 | |
| DTC Logic | 30 | |
| Diagnosis Procedure | 30 | |
| Component Inspection | 32 | |
| Special Repair Requirement | 32 | |
| C1109 BATTERY VOLTAGE [ABNORMAL] ... | 33 | |
| Description | 33 | |
| DTC Logic | 33 | |
| Diagnosis Procedure | 33 | |
| Special Repair Requirement | 34 | |
| C1110, C1153, C1170 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) | 35 | |
| DTC Logic | 35 | |
| Diagnosis Procedure | 35 | |
| Special Repair Requirement | 35 | |

| | | | |
|--|-----------|--|-----------|
| C1111 PUMP MOTOR | 36 | C1145, C1146 YAW RATE/SIDE G SENSOR... .. | 57 |
| Description | 36 | Description | 57 |
| DTC Logic | 36 | DTC Logic | 57 |
| Diagnosis Procedure | 36 | Diagnosis Procedure | 57 |
| Component Inspection | 37 | Component Inspection | 59 |
| Special Repair Requirement | 37 | Special Repair Requirement | 59 |
| C1114 MAIN RELAY | 38 | C1147, C1148, C1149, C1150 USV/HSV LINE.. | 60 |
| Description | 38 | Description | 60 |
| DTC Logic | 38 | DTC Logic | 60 |
| Diagnosis Procedure | 38 | Diagnosis Procedure | 60 |
| Component Inspection | 39 | Component Inspection | 61 |
| Special Repair Requirement | 39 | Special Repair Requirement | 62 |
| C1115 ABS SENSOR [ABNORMAL SIGNAL].. | 40 | C1154 TRANSMISSION RANGE SWITCH | 63 |
| Description | 40 | Description | 63 |
| DTC Logic | 40 | DTC Logic | 63 |
| Diagnosis Procedure | 40 | Diagnosis Procedure | 63 |
| Component Inspection | 41 | Special Repair Requirement | 63 |
| Special Repair Requirement | 42 | C1155 BR FLUID LEVEL LOW | 65 |
| C1116 STOP LAMP SW | 43 | Description | 65 |
| Description | 43 | DTC Logic | 65 |
| DTC Logic | 43 | Diagnosis Procedure | 65 |
| Diagnosis Procedure | 43 | Component Inspection | 66 |
| Special Repair Requirement | 44 | C1156 ST ANG SEN COM CIR | 67 |
| C1120, C1122, C1124, C1126 IN ABS SOL | 45 | Description | 67 |
| Description | 45 | DTC Logic | 67 |
| DTC Logic | 45 | Diagnosis Procedure | 67 |
| Diagnosis Procedure | 45 | U1000 CAN COMM CIRCUIT | 68 |
| Component Inspection | 46 | Description | 68 |
| Special Repair Requirement | 47 | DTC Logic | 68 |
| C1121, C1123, C1125, C1127 OUT ABS SOL.. | 48 | Diagnosis Procedure | 68 |
| Description | 48 | PARKING BRAKE SWITCH | 69 |
| DTC Logic | 48 | Description | 69 |
| Diagnosis Procedure | 48 | Component Function Check | 69 |
| Component Inspection | 49 | Diagnosis Procedure | 69 |
| Special Repair Requirement | 50 | Component Inspection | 69 |
| C1130, C1131, C1132, C1133, C1136 EN- GINE SIGNAL | 51 | VDC OFF SWITCH | 71 |
| Description | 51 | Description | 71 |
| DTC Logic | 51 | Component Function Check | 71 |
| Diagnosis Procedure | 51 | Diagnosis Procedure | 71 |
| C1142 PRESS SEN CIRCUIT | 52 | Component Inspection | 72 |
| Description | 52 | ABS WARNING LAMP | 73 |
| DTC Logic | 52 | Description | 73 |
| Diagnosis Procedure | 52 | Component Function Check | 73 |
| Component Inspection | 53 | Diagnosis Procedure | 73 |
| Special Repair Requirement | 53 | BRAKE WARNING LAMP | 74 |
| C1143, C1144 STEERING ANGLE SENSOR ... | 55 | Description | 74 |
| Description | 55 | Component Function Check | 74 |
| DTC Logic | 55 | Diagnosis Procedure | 74 |
| Diagnosis Procedure | 55 | VDC OFF INDICATOR LAMP | 75 |
| Component Inspection | 56 | Description | 75 |
| Special Repair Requirement | 56 | Component Function Check | 75 |

| | | | | |
|--|-----------|---|------------|-----|
| Diagnosis Procedure | 75 | Diagnosis Procedure | 97 | |
| SLIP INDICATOR LAMP | 76 | PRECAUTION | 98 | A |
| Description | 76 | PRECAUTIONS | 98 | B |
| Component Function Check | 76 | Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" | 98 | C |
| Diagnosis Procedure | 76 | Precautions Necessary for Steering Wheel Rotation after Battery Disconnect (Early Production, With Electronic Steering Column Lock) | 98 | D |
| ECU DIAGNOSIS | 77 | Precaution for Brake System | 99 | E |
| ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) | 77 | Precaution for Brake Control | 99 | |
| Reference Value | 77 | PREPARATION | 100 | |
| Wiring Diagram - BRAKE CONTROL SYSTEM - | 81 | Special Service Tool | 100 | |
| Fail-Safe | 88 | Commercial Service Tool | 100 | BRC |
| DTC No. Index | 89 | ON-VEHICLE REPAIR | 101 | |
| SYMPTOM DIAGNOSIS | 91 | PREPARATION | 100 | |
| VDC/TCS/ABS | 91 | Special Service Tool | 100 | |
| Symptom Table | 91 | Commercial Service Tool | 100 | |
| EXCESSIVE ABS FUNCTION OPERATION FREQUENCY | 92 | WHEEL SENSORS | 101 | G |
| Diagnosis Procedure | 92 | Removal and Installation | 101 | |
| UNEXPECTED PEDAL REACTION | 93 | SENSOR ROTOR | 103 | H |
| Diagnosis Procedure | 93 | Removal and Installation | 103 | |
| THE BRAKING DISTANCE IS LONG | 94 | ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) | 104 | I |
| Diagnosis Procedure | 94 | Exploded View | 104 | |
| ABS FUNCTION DOES NOT OPERATE | 95 | Removal and Installation | 104 | J |
| Diagnosis Procedure | 95 | G SENSOR | 106 | |
| PEDAL VIBRATION OR ABS OPERATION SOUND OCCURS | 96 | Removal and Installation | 106 | |
| Diagnosis Procedure | 96 | STEERING ANGLE SENSOR | 107 | K |
| VEHICLE JERKS DURING VDC/TCS/ABS CONTROL | 97 | Removal and Installation | 107 | L |

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000005462786


PRECAUTIONS FOR DIAGNOSIS

If steering angle sensor, steering system parts, suspension system parts, ABS actuator and electric unit (control unit) or tires have been replaced, or if wheel alignment has been adjusted, be sure to adjust neutral position of steering angle sensor before driving. Refer to [BRC-8, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >
OVERALL SEQUENCE

[VDC/TCS/ABS]



A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

JSFIA0010GB

DETAILED FLOW

1. COLLECT THE INFORMATION FROM THE CUSTOMER

Get the detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred) using the diagnosis worksheet. Refer to [BRC-7, "Diagnostic Work Sheet"](#).

>> GO TO 2.

DIAGNOSIS AND REPAIR WORKFLOW

[VDC/TCS/ABS]

< BASIC INSPECTION >

2. PERFORM THE SELF-DIAGNOSIS

Check the DTC display with the self-diagnosis function. Refer to [BRC-22, "CONSULT-III Function \(ABS\)"](#).

Is there any DTC displayed?

YES >> GO TO 3.

NO >> GO TO 4.

3. PERFORM THE SYSTEM DIAGNOSIS

Perform the diagnosis applicable to the displayed DTC. Refer to [BRC-89, "DTC No. Index"](#).

>> GO TO 7.

4. CHECK THE SYMPTOM THAT IS NOT CONSIDERED A SYSTEM MALFUNCTION

Check that the symptom is a normal operation that is not considered a system malfunction. Refer to [BRC-22, "CONSULT-III Function \(ABS\)"](#).

Is the symptom is a normal operation?

YES >> Inspection End

NO >> GO TO 5.

5. CHECK THE WARNING LAMP AND INDICATOR LAMP FOR ILLUMINATION

Check that the warning lamp and indicator lamp illuminate.

- ABS warning lamp: Refer to [BRC-73, "Description"](#).
- Brake warning lamp: Refer to [BRC-74, "Description"](#).
- VDC OFF indicator lamp: Refer to [BRC-75, "Description"](#).
- SLIP indicator lamp: Refer to [BRC-76, "Description"](#).

Is ON/OFF timing normal?

YES >> GO TO 6.

NO >> GO TO 2.

6. PERFORM THE DIAGNOSIS BY SYMPTOM

Perform the diagnosis applicable to the symptom.

>> GO TO 7.

7. REPAIR OR REPLACE THE MALFUNCTIONING PARTS

Repair or replace the specified malfunctioning parts.

>> GO TO 8.

8. FINAL CHECK

Perform the self-diagnosis again, and check that the malfunction is repaired completely. After checking, erase the self-diagnosis memory. Refer to [BRC-22, "CONSULT-III Function \(ABS\)"](#).

Is no other DTC present and the repair completed?

YES >> Inspection End

NO >> GO TO 3.

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[VDC/TCS/ABS]

Diagnostic Work Sheet

INFOID:000000005462787

| | | | |
|---------------------------|---|---|---|
| Customer name MR/MS | Model & Year | VIN | |
| Engine # | Trans. | Mileage | |
| Incident Date | Manuf. Date | In Service Date | |
| Symptoms | <input type="checkbox"/> Noise and vibration (from engine compartment) <input type="checkbox"/> Noise and vibration (from axle) | <input type="checkbox"/> Warning / Indicator activate | <input type="checkbox"/> Firm pedal operation Large stroke pedal operation |
| | <input type="checkbox"/> TCS does not work (Rear wheels slip when accelerating) | <input type="checkbox"/> ABS does not work (Wheels lock when braking) | <input type="checkbox"/> Lack of sense of acceleration |
| Engine conditions | <input type="checkbox"/> When starting <input type="checkbox"/> After starting | | |
| Road conditions | <input type="checkbox"/> Low friction road (<input type="checkbox"/> Snow <input type="checkbox"/> Gravel <input type="checkbox"/> Other) <input type="checkbox"/> Bumps / potholes | | |
| Driving conditions | <input type="checkbox"/> Full-acceleration <input type="checkbox"/> High speed cornering <input type="checkbox"/> Vehicle speed: Greater than 10 km/h (6 MPH) <input type="checkbox"/> Vehicle speed: 10 km/h (6 MPH) or less <input type="checkbox"/> Vehicle is stopped | | |
| Applying brake conditions | <input type="checkbox"/> Suddenly <input type="checkbox"/> Gradually | | |
| Other conditions | <input type="checkbox"/> Operation of electrical equipment <input type="checkbox"/> Shift change <input type="checkbox"/> Other descriptions | | |

SFIA3265E

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

INSPECTION AND ADJUSTMENT

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description

INFOID:000000005462788

After replacing the ABS actuator and electric unit (control unit), perform the neutral position adjustment for the steering angle sensor.

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement

INFOID:000000005462789

1. PERFORM THE NEUTRAL POSITION ADJUSTMENT FOR THE STEERING ANGLE SENSOR

Perform the neutral position adjustment for the steering angle sensor.

>> Refer to [BRC-8, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description

INFOID:000000005462790

When performing work that applies to the list below, make sure to adjust neutral position of steering angle sensor before operating vehicle.

x: Required –: Not required

| Situation | Adjustment of steering angle sensor neutral position |
|---|--|
| Removing/Installing ABS actuator and electric unit (control unit) | — |
| Replacing ABS actuator and electric unit (control unit) | x |
| Removing/Installing steering angle sensor | x |
| Replacing steering angle sensor | x |
| Removing/Installing steering components | x |
| Replacing steering components | x |
| Removing/Installing suspension components | x |
| Replacing suspension components | x |
| Change tires to new ones | — |
| Tire rotation | — |
| Adjusting wheel alignment | x |

ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement

INFOID:000000005462791

ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

CAUTION:

To adjust neutral position of steering angle sensor, make sure to use CONSULT-III (Adjustment cannot be done without CONSULT-III)

1. ALIGN THE VEHICLE STATUS

Stop vehicle with front wheels in straight-ahead position.

>> GO TO 2.

2. PERFORM THE NEUTRAL POSITION ADJUSTMENT FOR THE STEERING ANGLE SENSOR

1. On the CONSULT-III screen, touch "WORK SUPPORT", then "ST ANGLE SENSOR ADJUSTMENT".
2. Touch "START".

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[VDC/TCS/ABS]

CAUTION:

Do not touch steering wheel while adjusting steering angle sensor.

3. After approximately 10 seconds, touch "END".

NOTE:

After approximately 60 seconds, the adjustment ends automatically.

4. Turn ignition switch OFF, then turn it ON again.

CAUTION:

Be sure to perform above operation.

>> GO TO 3.

3. CHECK DATA MONITOR

1. Run vehicle with front wheels in straight-ahead position, then stop.
2. Select "DATA MONITOR". Then make sure "STR ANGLE SIG" is within $0 \pm 2.5^\circ$.

Is the steering angle within the specified range?

YES >> GO TO 4.

NO >> Perform the neutral position adjustment for the steering angle sensor again, GO TO 1.

4. ERASE THE SELF-DIAGNOSIS MEMORY

Erase the self-diagnosis memories of the ABS actuator and electric unit (control unit) and ECM.

- ABS actuator and electric unit (control unit): Refer to [BRC-22, "CONSULT-III Function \(ABS\)"](#).
- ECM: Refer to [EC-126, "CONSULT-III Function"](#).

Are the memories erased?

YES >> Inspection End


NO >> Check the items indicated by the self-diagnosis.

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

FUNCTION DIAGNOSIS

VDC










System Diagram



System Description

INFOID:000000005462793

- Vehicle dynamic control system detects driver's steering operation amount from the steering angle sensor. Using input information from the yaw rate/side/decel G sensor and wheel speed sensors, the VDC system judges driving conditions (conditions of understeer and oversteer) and controls engine output and brake application to improve vehicle driving stability.
- During VDC operation, it informs driver of system operation by flashing SLIP indicator lamp.
- Electrical system diagnosis by CONSULT-III is available.



AWFIA0442GB

1. Front wheel sensor LH E19
 Front wheel sensor RH E41

2. Stop lamp switch E38

3. VDC OFF switch M72

VDC

< FUNCTION DIAGNOSIS >

[VDC/TCS/ABS]

- | | | |
|---|---|-------------------------------------|
| 4. Combination meter M24 | 5. Rear wheel sensor LH C1 Rear wheel sensor RH C2 | 6. Yaw rate/side/decel G sensor M55 |
| 7. Steering angle sensor M53 (view with steering wheel removed) | 8. ABS actuator and electric unit (control unit) E26 | |


Component Description

INFOID:000000005462795

| Component parts | | Reference |
|---|--|---------------------------------------|
| ABS actuator and electric unit (control unit) | Pump | BRC-36. "Description" |
| | Motor | |
| | Actuator relay (Main relay) | BRC-38. "Description" |
| | Solenoid valve | BRC-45. "Description" |
| | Pressure sensor | BRC-52. "Description" |
| | VDC switch-over valve (HSV1, HSV2, USV1, USV2) | BRC-60. "Description" |
| Wheel sensor | | BRC-27. "Description" |
| Yaw rate/side/G sensor | | BRC-57. "Description" |
| Steering angle sensor | | BRC-55. "Description" |
| VDC OFF switch | | BRC-71. "Description" |
| ABS warning lamp | | BRC-73. "Description" |
| Brake warning lamp | | BRC-74. "Description" |
| Stop lamp switch | | BRC-43. "Description" |
| VDC OFF indicator lamp | | BRC-75. "Description" |
| Slip indicator lamp | | BRC-76. "Description" |

TCS










System Diagram



System Description

INFOID:000000005462797

- Traction Control System is a function that electronically controls engine torque and brake fluid pressure to ensure the optimum slippage ratio at drive wheels by computing wheel speed signals from 4 wheel sensors. When ABS actuator and electric unit (control unit) detects a spin at drive wheels, it compares wheel speed signals from all 4 wheels. At this time, LH and RH front brake fluid pressure are controlled, while fuel being cut to engine and throttle valve being closed to reduce engine torque by the control unit. Further more, throttle position is continuously controlled to ensure the optimum engine torque at all times.
- During TCS operation, it informs driver of system operation by flashing slip indicator lamp.
- Electrical system diagnosis by CONSULT-III is available.



AWFIA0442GB

1. Front wheel sensor LH E19
 Front wheel sensor RH E41

2. Stop lamp switch E38

3. VDC OFF switch M72

TCS

[VDC/TCS/ABS]

< FUNCTION DIAGNOSIS >

- | | | |
|---|---|-------------------------------------|
| 4. Combination meter M24 | 5. Rear wheel sensor LH C1 Rear wheel sensor RH C2 | 6. Yaw rate/side/decel G sensor M55 |
| 7. Steering angle sensor M53 (view with steering wheel removed) | 8. ABS actuator and electric unit (control unit) E26 | |

Component Description

INFOID:000000005462799


| Component parts | | Reference |
|---|--|---------------------------------------|
| ABS actuator and electric unit (control unit) | Pump | BRC-36. "Description" |
| | Motor | |
| | Actuator relay (Main relay) | BRC-38. "Description" |
| | Solenoid valve | BRC-45. "Description" |
| | Pressure sensor | BRC-52. "Description" |
| | VDC switch-over valve (HSV1, HSV2, USV1, USV2) | BRC-60. "Description" |
| Wheel sensor | BRC-27. "Description" | |
| Yaw rate/side/G sensor | BRC-57. "Description" | |
| Steering angle sensor | BRC-55. "Description" | |
| VDC OFF switch | BRC-71. "Description" | |
| ABS warning lamp | BRC-73. "Description" | |
| Brake warning lamp | BRC-74. "Description" | |
| Stop lamp switch | BRC-43. "Description" | |
| VDC OFF indicator lamp | BRC-75. "Description" | |
| Slip indicator lamp | BRC-76. "Description" | |

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

ABS

System Diagram

INFOID:000000005462800












AWFIA0440GE

System Description

INFOID:000000005462801

- Anti-Lock Braking System is a function that detects wheel revolution while braking, electronically controls braking force, and prevents wheel locking during sudden braking. It improves handling stability and maneuverability for avoiding obstacles.
- Electrical system diagnosis by CONSULT-III is available.



1. Front wheel sensor LH E19
Front wheel sensor RH E41

2. Stop lamp switch E38

3. VDC OFF switch M72

AWFIA0442GB

ABS

[VDC/TCS/ABS]

< FUNCTION DIAGNOSIS >

- | | | |
|--|---|-------------------------------------|
| 4. Combination meter M24 | 5. Rear wheel sensor LH C1 Rear wheel sensor RH C2 | 6. Yaw rate/side/decel G sensor M55 |
| 7. Steering angle sensor M53 (view with steering wheel removed) | 8. ABS actuator and electric unit (con- trol unit) E26 | |

Component Description


INFOID:000000005462803

| Component parts | | Reference |
|---|--|---------------------------------------|
| ABS actuator and electric unit (control unit) | Pump | BRC-36. "Description" |
| | Motor | |
| | Actuator relay (Main relay) | BRC-38. "Description" |
| | Solenoid valve | BRC-45. "Description" |
| | Pressure sensor | BRC-52. "Description" |
| | VDC switch-over valve (HSV1, HSV2, USV1, USV2) | BRC-60. "Description" |
| Wheel sensor | BRC-27. "Description" | |
| Yaw rate/side/G sensor | BRC-57. "Description" | |
| Steering angle sensor | BRC-55. "Description" | |
| VDC OFF switch | BRC-71. "Description" | |
| ABS warning lamp | BRC-73. "Description" | |
| Brake warning lamp | BRC-74. "Description" | |
| Stop lamp switch | BRC-43. "Description" | |
| VDC OFF indicator lamp | BRC-75. "Description" | |
| Slip indicator lamp | BRC-76. "Description" | |

EBD

System Diagram

INFOID:000000005462804












A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

System Description

INFOID:000000005462805

Electric Brake force Distribution functions as follows:

- ABS actuator and electric unit (control unit) detects subtle slippages between the front and rear wheels during braking. Then it electronically controls the rear braking force (brake fluid pressure) to reduce rear wheel slippage. Accordingly, it improves vehicle stability.
- Electrical system diagnosis by CONSULT-III is available.



AWFIA0442GB

1. Front wheel sensor LH E19
Front wheel sensor RH E41

2. Stop lamp switch E38

3. VDC OFF switch M72

EBD

< FUNCTION DIAGNOSIS >

[VDC/TCS/ABS]

- | | | |
|---|---|-------------------------------------|
| 4. Combination meter M24 | 5. Rear wheel sensor LH C1 Rear wheel sensor RH C2 | 6. Yaw rate/side/decel G sensor M55 |
| 7. Steering angle sensor M53 (view with steering wheel removed) | 8. ABS actuator and electric unit (control unit) E26 | |

Component Description

INFOID:000000005462807

| Component parts | Reference |
|---|---|
| ABS actuator and electric unit (control unit) | Pump BRC-36. "Description" |
| | Motor |
| | Actuator relay (Main relay) BRC-38. "Description" |
| | Solenoid valve BRC-45. "Description" |
| | Pressure sensor BRC-52. "Description" |
| | VDC switch-over valve (HSV1, HSV2, USV1, USV2) BRC-60. "Description" |
| Wheel sensor BRC-27. "Description" | BRC |
| Yaw rate/side/G sensor BRC-57. "Description" | |
| Steering angle sensor BRC-55. "Description" | |
| VDC OFF switch BRC-71. "Description" | G |
| ABS warning lamp BRC-73. "Description" | |
| Brake warning lamp BRC-74. "Description" | H |
| Stop lamp switch BRC-43. "Description" | |
| VDC OFF indicator lamp BRC-75. "Description" | I |
| Slip indicator lamp BRC-76. "Description" | |

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< FUNCTION DIAGNOSIS >

[VDC/TCS/ABS]

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

CONSULT-III Function (ABS)

INFOID:000000005462808

FUNCTION

CONSULT-III can display each diagnostic item using the following diagnostic test modes.

| Diagnostic test mode | Function |
|--------------------------|--|
| Work support | Supports inspections and adjustments. Commands are transmitted to the ABS actuator and electric unit (control unit) for setting the status suitable for required operation, input/output signals are received from the ABS actuator and electric unit (control unit) and received data is displayed. |
| Function Test | This mode is used to inform customers when the vehicle requires periodic maintenance. |
| Data Monitor | Displays ABS actuator and electric unit (control unit) input/output data in real time. |
| Active Test | Operation of electrical loads can be checked by sending drive signals to them. |
| Self Diagnostic Result | Displays ABS actuator and electric unit (control unit) self-diagnosis results. |
| CAN Diag Support Monitor | The result of transmit/receive diagnosis of CAN communication can be read. |
| ECU Identification | ABS actuator and electric unit (control unit) part number can be read. |

SELF DIAGNOSTIC RESULT MODE

Operation Procedure

Before performing the self-diagnosis, start engine and drive vehicle at 30 km/h (19 MPH) or more for approximately 1 minute.

How to Erase Self-Diagnosis Results

After erasing DTC memory, start engine and drive vehicle at 30 km/h (19 MPH) or more for approximately 1 minute as the final inspection, and make sure that the ABS warning lamp, VDC OFF indicator lamp, SLIP indicator lamp and brake warning lamp turn OFF.

CAUTION:

If memory cannot be erased, perform applicable diagnosis.

NOTE:

- When the wheel sensor malfunctions, after inspecting the wheel sensor system, the ABS warning lamp, VDC OFF indicator lamp, SLIP indicator lamp and brake warning lamp will not turn OFF even when the system is normal unless the vehicle is driving at approximately 30 km/h (19 MPH) or more for approximately 1 minute.
- Brake warning lamp will turn ON in case of parking brake operation (when switch is ON) or of brake fluid level switch operation (when brake fluid is insufficient).
- VDC OFF switch should not stay in "ON" position.

Display Item List

Refer to [BRC-89, "DTC No. Index"](#).

DATA MONITOR

Display Item List

| Item (Unit) | Data monitor item selection | | | Remarks |
|--------------------------|-----------------------------|--------------|---------------------|--|
| | ECU INPUT SIGNALS | MAIN SIGNALS | SELECTION FROM MENU | |
| FR LH SENSOR (km/h, mph) | × | × | × | Wheel speed (km/h, mph) calculated by front LH wheel sensor signal is displayed. |
| FR RH SENSOR (km/h, mph) | × | × | × | Wheel speed (km/h, mph) calculated by front RH wheel sensor signal is displayed. |
| RR LH SENSOR (km/h, mph) | × | × | × | Wheel speed (km/h, mph) calculated by rear LH wheel sensor signal is displayed. |

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< FUNCTION DIAGNOSIS >

[VDC/TCS/ABS]

| | | | | | |
|-----------------------------------|---|---|---|---|-----|
| RR RH SENSOR (km/h, mph) | × | × | × | Wheel speed (km/h, mph) calculated by rear RH wheel sensor signal is displayed. | A |
| FR RH IN SOL (On/Off) | — | × | × | Front RH IN ABS solenoid (On/Off) status is displayed. | B |
| FR RH OUT SOL (On/Off) | — | × | × | Front RH OUT ABS solenoid (On/Off) status is displayed. | C |
| FR LH IN SOL (On/Off) | — | × | × | Front LH IN ABS solenoid (On/Off) status is displayed. | D |
| FR LH OUT SOL (On/Off) | — | × | × | Front LH OUT ABS solenoid (On/Off) status is displayed. | E |
| RR RH IN SOL (On/Off) | — | × | × | Rear RH IN ABS solenoid (On/Off) status is displayed. | |
| RR RH OUT SOL (On/Off) | — | × | × | Rear RH OUT ABS solenoid (On/Off) status is displayed. | |
| RR LH IN SOL (On/Off) | — | × | × | Rear LH IN ABS solenoid (On/Off) status is displayed. | |
| RR LH OUT SOL (On/Off) | — | × | × | Rear LH OUT ABS solenoid (On/Off) status is displayed. | BRC |
| EBD WARN LAMP (On/Off) | — | — | × | EBD warning lamp (On/Off) status is displayed. | G |
| STOP LAMP SW (On/Off) | × | × | × | Stop lamp switch (On/Off) status is displayed. | H |
| MOTOR RELAY (On/Off) | — | × | × | ABS motor relay signal (On/Off) status is displayed. | I |
| ACTUATOR RLY (On/Off) | — | × | × | ABS actuator relay signal (On/Off) status is displayed. | J |
| ABS WARN LAMP (On/Off) | — | × | × | ABS warning lamp (On/Off) status is displayed. | K |
| OFF LAMP (On/Off) | — | × | × | VDC OFF lamp (On/Off) status is displayed. | L |
| SLIP LAMP (On/Off) | — | × | × | SLIP indicator lamp (On/Off) status is displayed. | M |
| BATTERY VOLT (V) | × | × | × | Voltage (V) supplied to ABS actuator and electric unit (control unit) is displayed. | N |
| GEAR (1, 2, 3, 4, 5, 6) | × | × | × | Gear position (1, 2, 3, 4, 5, 6) while in manual mode determined by TCM is displayed. | O |
| SLCT LVR POSI (N/P, R, N/P, D) | × | × | × | Selector lever position judged by PNP switch signal. | P |
| YAW RATE SEN (d/s) | × | × | × | Yaw rate (d/s) detected by yaw rate sensor is displayed. | |
| ACCEL POS SIG (%) | × | — | × | Throttle valve open/close (%) status judged by CAN communication signal is displayed. | |
| SIDE G-SENSOR (m/s ²) | × | — | × | Lateral acceleration (m/s ²) detected by side G sensor is displayed. | |
| STR ANGLE SIG (deg) | × | — | × | Steering angle (deg) detected by steering angle sensor is displayed. | |
| PRESS SENSOR (bar) | × | — | × | Brake fluid pressure detected by pressure sensor is displayed. | |
| EBD SIGNAL (On/Off) | — | — | × | EBD operation (On/Off) status is displayed. | |
| ABS SIGNAL (On/Off) | — | — | × | ABS operation (On/Off) status is displayed. | |
| TCS SIGNAL (On/Off) | — | — | × | TCS operation (On/Off) status is displayed. | |

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< FUNCTION DIAGNOSIS >

[VDC/TCS/ABS]

| | | | | |
|------------------------|---|---|---|---|
| VDC SIGNAL (On/Off) | — | — | × | VDC operation (On/Off) status is displayed. |
| EBD FAIL SIG (On/Off) | — | — | × | EBD fail signal (On/Off) status is displayed. |
| ABS FAIL SIG (On/Off) | — | — | × | ABS fail signal (On/Off) status is displayed. |
| TCS FAIL SIG (On/Off) | — | — | × | TCS fail signal (On/Off) status is displayed. |
| VDC FAIL SIG (On/Off) | — | — | × | VDC fail signal (On/Off) status is displayed. |
| CRANKING SIG (On/Off) | — | — | × | Cranking condition (On/Off) status is displayed. |
| FLUID LEV SW (On/Off) | × | — | × | Brake fluid level switch (On/Off) status is displayed. |
| PARK BRAKE SW (On/Off) | × | — | × | Parking brake switch (On/Off) status is displayed. |
| USV[FL-RR] (On/Off) | — | — | × | Primary side USV solenoid valve (On/Off) status is displayed. |
| USV[FR-RL] (On/Off) | — | — | × | Secondary side USV solenoid valve (On/Off) status is displayed. |
| HSV[FL-RR] (On/Off) | — | — | × | Primary side HSV solenoid valve (On/Off) status is displayed. |
| HSV[FR-RL] (On/Off) | — | — | × | Secondary side HSV solenoid valve (On/Off) status is displayed. |
| V/R OUTPUT (On/Off) | — | — | × | Valve relay operation signal (On/Off) status is displayed. |
| M/R OUTPUT (On/Off) | — | — | × | Motor relay operation signal (On/Off) status is displayed. |
| ENGINE RPM (rpm) | × | — | × | Engine speed judged by CAN communication signal is displayed. |

×: Applicable

—: Not applicable

ACTIVE TEST

CAUTION:

- Do not perform active test while driving vehicle.
- Make sure to completely bleed air from brake system.
- The active test cannot be performed with the ABS warning lamp, VDC indicator lamp, SLIP indicator lamp or brake warning lamp on.
- ABS warning lamp, VDC OFF indicator lamp, SLIP indicator lamp and brake warning lamp are on during active test.

NOTE:

- When active test is performed while depressing the pedal, the pedal depression amount will change. This is normal. (Only solenoid valve and ABS motor)
- “TEST IS STOPPED” is displayed 10 seconds after operation start.
- After “TEST IS STOPPED” is displayed, to perform test again, touch BACK.

Test Item

SOLENOID VALVE

- When performing an active test of the ABS function, select “MAIN SIGNALS” for each test item.
- For ABS solenoid valve, touch “Up”, “Keep”, and “Down” on the display screen. For ABS solenoid valve (ACT), touch “Up”, “ACT UP”, “ACT KEEP” and confirm that solenoid valves operate as shown in the table below.

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< FUNCTION DIAGNOSIS >

[VDC/TCS/ABS]

| Operation | | ABS solenoid valve | | | ABS solenoid valve (ACT) | | | |
|--------------------------|---------------|--------------------|------|------|--------------------------|--------|----------|---|
| | | Up | Keep | Down | Up | ACT UP | ACT KEEP | |
| FR RH SOL | FR RH IN SOL | Off | On | On | — | — | — | A |
| | FR RH OUT SOL | Off | Off | On* | — | — | — | B |
| | USV[FR-RR] | Off | Off | On* | — | — | — | C |
| | USV[FR-RL] | Off | Off | On* | — | — | — | |
| | HSV[FL-RR] | Off | Off | On* | — | — | — | |
| | HSV[FR-RL] | Off | Off | On* | — | — | — | |
| FR LH SOL | FR LH IN SOL | Off | On | On | — | — | — | D |
| | FR LH OUT SOL | Off | Off | On* | — | — | — | E |
| | USV[FR-RR] | Off | Off | On* | — | — | — | |
| | USV[FR-RL] | Off | Off | On* | — | — | — | |
| | HSV[FL-RR] | Off | Off | On* | — | — | — | |
| | HSV[FR-RL] | Off | Off | On* | — | — | — | |
| RR RH SOL | RR RH IN SOL | Off | On | On | — | — | — | |
| | RR RH OUT SOL | Off | Off | On* | — | — | — | |
| | USV[FR-RR] | Off | Off | On* | — | — | — | |
| | USV[FR-RL] | Off | Off | On* | — | — | — | |
| | HSV[FL-RR] | Off | Off | On* | — | — | — | |
| | HSV[FR-RL] | Off | Off | On* | — | — | — | |
| RR LH SOL | RR LH IN SOL | Off | On | On | — | — | — | I |
| | RR LH OUT SOL | Off | Off | On* | — | — | — | |
| | USV[FR-RR] | Off | Off | On* | — | — | — | |
| | USV[FR-RL] | Off | Off | On* | — | — | — | |
| | HSV[FL-RR] | Off | Off | On* | — | — | — | |
| | HSV[FR-RL] | Off | Off | On* | — | — | — | |
| FR RH ABS SOLENOID (ACT) | FR RH IN SOL | — | — | — | Off | Off | Off | K |
| | FR RH OUT SOL | — | — | — | Off | Off | Off | L |
| | USV[FR-RR] | — | — | — | Off | Off | Off | |
| | USV[FR-RL] | — | — | — | Off | On | On | |
| | HSV[FL-RR] | — | — | — | Off | Off | Off | |
| | HSV[FR-RL] | — | — | — | Off | On* | Off | |
| FR LH ABS SOLENOID (ACT) | FR LH IN SOL | — | — | — | Off | Off | Off | |
| | FR LH OUT SOL | — | — | — | Off | Off | Off | |
| | USV[FR-RR] | — | — | — | Off | Off | Off | |
| | USV[FR-RL] | — | — | — | Off | On | On | |
| | HSV[FL-RR] | — | — | — | Off | Off | Off | |
| | HSV[FR-RL] | — | — | — | Off | On* | Off | |
| RR RH ABS SOLENOID (ACT) | RR RH IN SOL | — | — | — | Off | Off | Off | P |
| | RR RH OUT SOL | — | — | — | Off | Off | Off | |
| | USV[FR-RR] | — | — | — | Off | Off | Off | |
| | USV[FR-RL] | — | — | — | Off | On | On | |
| | HSV[FL-RR] | — | — | — | Off | Off | Off | |
| | HSV[FR-RL] | — | — | — | Off | On* | Off | |

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< FUNCTION DIAGNOSIS >

[VDC/TCS/ABS]

| Operation | | ABS solenoid valve | | | ABS solenoid valve (ACT) | | |
|--------------------------|---------------|--------------------|------|------|--------------------------|--------|----------|
| | | Up | Keep | Down | Up | ACT UP | ACT KEEP |
| RR LH ABS SOLENOID (ACT) | RR LH IN SOL | — | — | — | Off | Off | Off |
| | RR LH OUT SOL | — | — | — | Off | Off | Off |
| | USV[FR-RR] | — | — | — | Off | Off | Off |
| | USV[FR-RL] | — | — | — | Off | On | On |
| | HSV[FL-RR] | — | — | — | Off | Off | Off |
| | HSV[FR-RL] | — | — | — | Off | On* | Off |

*: On for 1 to 2 seconds after the touch, and then Off

ABS MOTOR

- Touch “On” and “Off” on screen. Make sure motor relay, actuator relay, V/R output and M/R output operate as shown in table below.

| Operation | On | Off |
|--------------|----|-----|
| MOTOR RELAY | On | Off |
| ACTUATOR RLY | On | On |
| V/R OUTPUT | On | On |
| M/R OUTPUT | On | Off |

C1101, C1102, C1103, C1104 WHEEL SENSOR-1

< COMPONENT DIAGNOSIS >

[VDC/TCS/ABS]

COMPONENT DIAGNOSIS

C1101, C1102, C1103, C1104 WHEEL SENSOR-1

Description

INFOID:000000005462809

When the sensor rotor rotates, the magnetic field changes. It converts the magnetic field changes to current signals (rectangular wave) and transmits them to the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000005462810

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|----------------|---|---|
| C1101 | RR RH SENSOR-1 | Circuit of rear RH wheel sensor is open. Or when the sensor power voltage is outside the standard. | <ul style="list-style-type: none">• Harness or connector• Wheel sensor• ABS actuator and electric unit (control unit) |
| C1102 | RR LH SENSOR-1 | Circuit of rear LH wheel sensor is open. Or when the sensor power voltage is outside the standard. | |
| C1103 | FR RH SENSOR-1 | Circuit of front RH wheel sensor is open. Or when the sensor power voltage is outside the standard. | |
| C1104 | FR LH SENSOR-1 | Circuit of front LH wheel sensor is open. Or when the sensor power voltage is outside the standard. | |

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

| Self-diagnosis results |
|------------------------|
| RR RH SENSOR-1 |
| RR LH SENSOR-1 |
| FR RH SENSOR-1 |
| FR LH SENSOR-1 |

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-27, "Diagnosis Procedure"](#).
NO >> Inspection End

Diagnosis Procedure

INFOID:000000005462811

Regarding Wiring Diagram information, refer to [BRC-81, "Wiring Diagram - BRAKE CONTROL SYSTEM -"](#).

CAUTION:

Do not check between wheel sensor terminals.

1. CONNECTOR INSPECTION

1. Disconnect ABS actuator and electric unit (control unit) connector and wheel sensor of malfunctioning code.
2. Check terminals for deformation, disconnection, looseness or damage.

Is the inspection result normal?

- YES >> GO TO 2
NO >> Repair or replace as necessary.

2. CHECK WHEEL SENSOR OUTPUT SIGNAL

1. Connect ABS active wheel sensor tester (J-45741) to wheel sensor using appropriate adapter.
2. Turn on the ABS active wheel sensor tester power switch.

C1101, C1102, C1103, C1104 WHEEL SENSOR-1

< COMPONENT DIAGNOSIS >

[VDC/TCS/ABS]

NOTE:

The green POWER indicator should illuminate. If the POWER indicator does not illuminate, replace the battery in the ABS active wheel sensor tester before proceeding.

- Spin the wheel of the vehicle by hand and observe the red SENSOR indicator on the ABS active wheel sensor tester. The red SENSOR indicator should flash on and off to indicate an output signal.

NOTE:

If the red SENSOR indicator illuminates but does not flash, reverse the polarity of the tester leads and retest.

Does the ABS active wheel sensor tester detect a signal?

YES >> GO TO 3

NO >> Replace the wheel sensor. Refer to [BRC-101, "Removal and Installation"](#).

3.CHECK TIRES

Check the inflation pressure, wear and size of each tire.

Is the inspection result normal?

YES >> GO TO 4

NO >> Adjust tire pressure, or replace tire(s).

4.CHECK WHEEL BEARINGS

Check wheel bearing axial end play. Refer to [FAX-6, "Inspection"](#) (front) or [RAX-6, "On-vehicle Service"](#) (rear).

Is the inspection result normal?

YES >> GO TO 5

NO >> Repair or replace as necessary. Refer to [FAX-8, "Removal and Installation"](#) (front) or [RAX-9, "Wheel Bearing \(Rear\)"](#) (rear).

5.CHECK WIRING HARNESS FOR SHORT CIRCUIT


- Disconnect ABS actuator and electric unit (control unit) connector and wheel sensor of malfunctioning code.
- Check continuity between front wheel sensor connector terminals (A), rear wheel sensor connector terminals (B) and ground.

: Continuity should not exist.

Is the inspection result normal?

YES >> GO TO 6

NO >> Repair the circuit.



6.CHECK WIRING HARNESS FOR OPEN CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) connector and the malfunctioning wheel sensor connector.

| Wheel sensor | ABS actuator and electric unit (control unit) | | Wheel sensor | | Continuity |
|--------------|---|----------|--------------|----------|------------|
| | Connector | Terminal | Connector | Terminal | |
| Front LH | E26 | 16 | E19 | 1 | Yes |
| | | 5 | | 2 | |
| Front RH | | 9 | E41 | 1 | |
| | | 10 | | 2 | |
| Rear LH | | 6 | C1 | 1 | |
| | | 17 | | 2 | |
| Rear RH | | 8 | C2 | 1 | |
| | | 19 | | 2 | |

Is the inspection result normal?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-104, "Removal and Installation"](#).

C1101, C1102, C1103, C1104 WHEEL SENSOR-1

< COMPONENT DIAGNOSIS >

[VDC/TCS/ABS]

NO >> Repair the circuit.

Component Inspection

INFOID:000000005462812

1. CHECK DATA MONITOR

On "DATA MONITOR", select "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR", and "RR RH SENSOR", and check the vehicle speed.

| Wheel sensor | Vehicle speed (DATA MONITOR) |
|--------------|--|
| FR LH SENSOR | Nearly matches the speedometer display ($\pm 10\%$ or less) |
| FR RH SENSOR | |
| RR LH SENSOR | |
| RR RH SENSOR | |

Is the inspection result normal?

YES >> Inspection End

NO >> Go to diagnosis procedure. Refer to [BRC-27, "Diagnosis Procedure"](#).

Special Repair Requirement

INFOID:000000005462813

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-8, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

C1105, C1106, C1107, C1108 WHEEL SENSOR-2

< COMPONENT DIAGNOSIS >

[VDC/TCS/ABS]

C1105, C1106, C1107, C1108 WHEEL SENSOR-2

Description

INFOID:000000005462814

When the sensor rotor rotates, the magnetic field changes. It converts the magnetic field changes to current signals (rectangular wave) and transmits them to the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000005462815

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|----------------|---|---|
| C1105 | RR RH SENSOR-2 | Circuit of rear RH wheel sensor is open. Or when the sensor power voltage is outside the standard. | <ul style="list-style-type: none">• Harness or connector• Wheel sensor• ABS actuator and electric unit (control unit) |
| C1106 | RR LH SENSOR-2 | Circuit of rear LH wheel sensor is open. Or when the sensor power voltage is outside the standard. | |
| C1107 | FR RH SENSOR-2 | Circuit of front RH wheel sensor is open. Or when the sensor power voltage is outside the standard. | |
| C1108 | FR LH SENSOR-2 | Circuit of front LH wheel sensor is open. Or when the sensor power voltage is outside the standard. | |

DTC CONFIRMATION PROCEDURE

1.CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

| Self-diagnosis results |
|------------------------|
| RR RH SENSOR-2 |
| RR LH SENSOR-2 |
| FR RH SENSOR-2 |
| FR LH SENSOR-2 |

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-30. "Diagnosis Procedure"](#).
NO >> Inspection End

Diagnosis Procedure

INFOID:000000005518994

Regarding Wiring Diagram information, refer to [BRC-81. "Wiring Diagram - BRAKE CONTROL SYSTEM -"](#).

CAUTION:

Do not check between wheel sensor terminals.

1.CONNECTOR INSPECTION

1. Disconnect ABS actuator and electric unit (control unit) connector and wheel sensor of malfunctioning code.
2. Check terminals for deformation, disconnection, looseness or damage.

Is the inspection result normal?

- YES >> GO TO 2
NO >> Repair or replace as necessary.

2.CHECK WHEEL SENSOR OUTPUT SIGNAL

1. Connect ABS active wheel sensor tester (J-45741) to wheel sensor using appropriate adapter.
2. Turn on the ABS active wheel sensor tester power switch.

NOTE:

C1105, C1106, C1107, C1108 WHEEL SENSOR-2

[VDC/TCS/ABS]

< COMPONENT DIAGNOSIS >

The green POWER indicator should illuminate. If the POWER indicator does not illuminate, replace the battery in the ABS active wheel sensor tester before proceeding.

- Spin the wheel of the vehicle by hand and observe the red SENSOR indicator on the ABS active wheel sensor tester. The red SENSOR indicator should flash on and off to indicate an output signal.

NOTE:

If the red SENSOR indicator illuminates but does not flash, reverse the polarity of the tester leads and retest.

Does the ABS active wheel sensor tester detect a signal?

YES >> GO TO 3

NO >> Replace the wheel sensor. Refer to [BRC-101. "Removal and Installation"](#).

3.CHECK TIRES

Check the inflation pressure, wear and size of each tire.

Is the inspection result normal?

YES >> GO TO 4

NO >> Adjust tire pressure, or replace tire(s).

4.CHECK WHEEL BEARINGS

Check wheel bearing axial end play. Refer to [FAX-6. "Inspection"](#) (front) or [RAX-6. "On-vehicle Service"](#) (rear).

Is the inspection result normal?

YES >> GO TO 5

NO >> Repair or replace as necessary. Refer to [FAX-8. "Removal and Installation"](#) (front) or [RAX-9. "Wheel Bearing \(Rear\)"](#) (rear).

5.CHECK WIRING HARNESS FOR SHORT CIRCUIT


- Disconnect ABS actuator and electric unit (control unit) connector and wheel sensor of malfunctioning code.
- Check continuity between front wheel sensor connector terminals (A), rear wheel sensor connector terminals (B) and ground.

: Continuity should not exist.

Is the inspection result normal?

YES >> GO TO 6

NO >> Repair the circuit.



6.CHECK WIRING HARNESS FOR OPEN CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) connector and the malfunctioning wheel sensor connector.

| Wheel sensor | ABS actuator and electric unit (control unit) | | Wheel sensor | | Continuity |
|--------------|---|----------|--------------|----------|------------|
| | Connector | Terminal | Connector | Terminal | |
| Front LH | E26 | 16 | E19 | 1 | Yes |
| | | 5 | | 2 | |
| Front RH | | 9 | E41 | 1 | |
| | | 10 | | 2 | |
| Rear LH | | 6 | C1 | 1 | |
| | | 17 | | 2 | |
| Rear RH | | 8 | C2 | 1 | |
| | | 19 | | 2 | |

Is the inspection result normal?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-104. "Removal and Installation"](#).

NO >> Repair the circuit.

C1105, C1106, C1107, C1108 WHEEL SENSOR-2

< COMPONENT DIAGNOSIS >

[VDC/TCS/ABS]

Component Inspection

INFOID:000000005518995

1.CHECK DATA MONITOR

On "DATA MONITOR", select "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR", and "RR RH SENSOR", and check the vehicle speed.

| Wheel sensor | Vehicle speed (DATA MONITOR) |
|--------------|--|
| FR LH SENSOR | Nearly matches the speedometer display ($\pm 10\%$ or less) |
| FR RH SENSOR | |
| RR LH SENSOR | |
| RR RH SENSOR | |

Is the inspection result normal?

YES >> Inspection End

NO >> Go to diagnosis procedure. Refer to [BRC-30, "Diagnosis Procedure"](#).

Special Repair Requirement

INFOID:000000005518996

1.ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-8, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

C1109 BATTERY VOLTAGE [ABNORMAL]

< COMPONENT DIAGNOSIS >

[VDC/TCS/ABS]

C1109 BATTERY VOLTAGE [ABNORMAL]

Description

INFOID:000000005462819

Supplies electric power to the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000005462820

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|----------------------------|---|---|
| C1109 | BATTERY VOLTAGE [ABNORMAL] | When the ABS actuator and electric unit (control unit) power supply voltage is lower than normal. | <ul style="list-style-type: none"> • Harness or connector • ABS actuator and electric unit (control unit) |

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

| |
|----------------------------|
| Self-diagnosis results |
| BATTERY VOLTAGE [ABNORMAL] |

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-33, "Diagnosis Procedure"](#).
 NO >> Inspection End

Diagnosis Procedure

INFOID:000000005462821

Regarding Wiring Diagram information, refer to [BRC-81, "Wiring Diagram - BRAKE CONTROL SYSTEM -"](#).

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminals for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminals.
4. Reconnect connector and perform self-diagnosis. Refer to [BRC-22, "CONSULT-III Function \(ABS\)"](#).


Is any item displayed on the self-diagnosis display?

- YES >> GO TO 2
 NO >> Poor connection of connector terminals. Repair or replace connector.

2. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY CIRCUIT AND GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check voltage between ABS actuator and electric unit (control unit) connector E26 terminal 18 and ground.

| ABS actuator and electric unit (control unit) | | Ground | Condition | Voltage (Approx.) |
|---|----------|--------|----------------------|-------------------|
| Connector | Terminal | | | |
| E26 | 18 | — | Ignition switch: ON | Battery voltage |
| | | | Ignition switch: OFF | 0V |



ALFIA0006ZZ


C1109 BATTERY VOLTAGE [ABNORMAL]

[VDC/TCS/ABS]

< COMPONENT DIAGNOSIS >

4. Turn ignition switch OFF.
5. Check continuity between ABS actuator and electric unit (control unit) connector E26 terminals 1, 4 and ground.

| ABS actuator and electric unit (control unit) | | Ground | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| E26 | 1 | — | Yes |
| | 4 | | |



Is the inspection result normal?

YES >> Check battery for terminal looseness, low voltage, etc. If any malfunction is found, repair malfunctioning parts.

NO >> Repair or replace malfunctioning components.

Special Repair Requirement

INFOID:000000005519000

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-8, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

C1110, C1153, C1170 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)
 < COMPONENT DIAGNOSIS > [VDC/TCS/ABS]

C1110, C1153, C1170 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

DTC Logic

INFOID:000000005462823

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|--------------------|---|---|
| C1110 | CONTROLLER FAILURE | When there is an internal malfunction in the ABS actuator and electric unit (control unit). | • ABS actuator and electric unit (control unit) |
| C1153 | EMERGENCY BRAKE | When ABS actuator and electric unit (control unit) is malfunctioning. (Pressure increase is too much or too little) | |
| C1170 | VARIANT CODING | In a case where VARIANT CODING is different. | |

DTC CONFIRMATION PROCEDURE

1.CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

| |
|------------------------|
| Self-diagnosis results |
| CONTROLLER FAILURE |
| EMERGENCY BRAKE |
| VARIANT CODING |

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-35, "Diagnosis Procedure"](#).
- NO >> Inspection End

Diagnosis Procedure

INFOID:000000005462824

1.REPLACE ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

CAUTION:

Replace **ABS actuator and electric unit (control unit)** when self-diagnostic result shows items other than that applicable.

>> Replace ABS actuator and electric unit (control unit).

Special Repair Requirement

INFOID:00000000519001

1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-8, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

C1111 PUMP MOTOR

< COMPONENT DIAGNOSIS >

[VDC/TCS/ABS]

C1111 PUMP MOTOR

Description

INFOID:000000005462826

PUMP

The pump returns the brake fluid stored in the reservoir to the master cylinder by reducing the pressure.

MOTOR

The motor drives the pump according to the signals transmitted by the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000005462827

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|--------------|---|--|
| C1111 | PUMP MOTOR | During actuator motor ON, when the actuator motor turns OFF, or when the control line for actuator motor relay is open. | <ul style="list-style-type: none">• Harness or connector• ABS actuator and electric unit (control unit) |
| | | During actuator motor OFF, when the actuator motor turns ON, or when the control line for relay is shorted to ground. | |

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

| Self-diagnosis results |
|------------------------|
| PUMP MOTOR |

Is above displayed on the self-diagnosis display?

YES >> Proceed to diagnosis procedure. Refer to [BRC-36, "Diagnosis Procedure"](#).

NO >> Inspection End

Diagnosis Procedure

INFOID:000000005462828

Regarding Wiring Diagram information, refer to [BRC-81, "Wiring Diagram - BRAKE CONTROL SYSTEM -"](#).

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminals for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminals.
4. Reconnect connector and perform self-diagnosis. Refer to [BRC-22, "CONSULT-III Function \(ABS\)"](#).

Is any item indicated on the self-diagnosis display?

YES >> GO TO 2

NO >> Poor connection of connector terminals. Repair or replace connector.


2. CHECK ABS MOTOR AND MOTOR RELAY POWER SUPPLY CIRCUIT

C1111 PUMP MOTOR

[VDC/TCS/ABS]

< COMPONENT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check voltage between ABS actuator and electric unit (control unit) connector E26 terminal 2 and ground.




| ABS actuator and electric unit (control unit) | | Ground | Voltage (Approx.) |
|---|----------|--------|-------------------|
| Connector | Terminal | | |
| E26 | 2 | — | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 3
 NO >> Repair or replace malfunctioning components.

3. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) connector E26 terminals 1, 4 and ground.



| ABS actuator and electric unit (control unit) | | Ground | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| E26 | 1 | — | Yes |
| | 4 | | |

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit).
 Refer to [BRC-104, "Removal and Installation"](#).
 NO >> Repair or replace malfunctioning components.

Component Inspection

INFOID:000000005462829

1. CHECK ACTIVE TEST

1. On "ACTIVE TEST", select "ABS MOTOR".
2. Touch "On" and "Off" on screen. Make sure motor relay, actuator relay, V/R output and M/R output operate as shown in table below.

| Operation | On | Off |
|--------------|----|-----|
| MOTOR RELAY | On | Off |
| ACTUATOR RLY | On | On |
| V/R OUTPUT | On | On |
| M/R OUTPUT | On | Off |

Is the inspection result normal?

- YES >> Inspection End
 NO >> Go to diagnosis procedure. Refer to [BRC-36, "Diagnosis Procedure"](#).

Special Repair Requirement

INFOID:000000005519002

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-8, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

C1114 MAIN RELAY

< COMPONENT DIAGNOSIS >

[VDC/TCS/ABS]

C1114 MAIN RELAY

Description

INFOID:000000005462831

Activates or deactivates each solenoid valve according to the signals transmitted by the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000005462832

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|--------------|---|--|
| C1114 | MAIN RELAY | During actuator relay OFF, when the actuator relay turns ON, or when the control line for the relay is shorted to the ground. | <ul style="list-style-type: none">• Harness or connector• ABS actuator and electric unit (control unit) |
| | | During actuator relay ON, when the actuator relay turns ON, or when the control line for the relay is open. | |

DTC CONFIRMATION PROCEDURE

1.CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

| Self-diagnosis results |
|------------------------|
| MAIN RELAY |

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-38, "Diagnosis Procedure"](#).
- NO >> Inspection End

Diagnosis Procedure

INFOID:000000005462833

Regarding Wiring Diagram information, refer to [BRC-81, "Wiring Diagram - BRAKE CONTROL SYSTEM -"](#).

1.CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminals for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminals.
4. Reconnect connector and perform self-diagnosis. Refer to [BRC-22, "CONSULT-III Function \(ABS\)"](#).

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2
- NO >> Poor connection of connector terminals. Repair or replace connector.

2.CHECK SOLENOID AND ACTUATOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.

C1114 MAIN RELAY

[VDC/TCS/ABS]


< COMPONENT DIAGNOSIS >

- Check voltage between ABS actuator and electric unit (control unit) connector E26 terminal 3 and ground.

| ABS actuator and electric unit (control unit) | | Ground | Voltage (Approx.) |
|---|----------|--------|-------------------|
| Connector | Terminal | | |
| E26 | 3 | — | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 3
 NO >> Repair or replace malfunctioning components.




3. CHECK SOLENOID AND ACTUATOR RELAY GROUND CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) connector E26 terminals 1, 4 and ground.

| ABS actuator and electric unit (control unit) | | Ground | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| E26 | 1 | — | Yes |
| | 4 | | |

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit).
 Refer to [BRC-104, "Removal and Installation"](#).
 NO >> Repair or replace malfunctioning components.



Component Inspection

INFOID:000000005462834

1. CHECK ACTIVE TEST

- On "ACTIVE TEST", select "ABS MOTOR".
- Touch "On" and "Off" on screen. Make sure motor relay, actuator relay, V/R output and M/R output operate as shown in table below.

| Operation | On | Off |
|--------------|----|-----|
| MOTOR RELAY | On | Off |
| ACTUATOR RLY | On | On |
| V/R OUTPUT | On | On |
| M/R OUTPUT | On | Off |

Is the inspection result normal?

- YES >> Inspection End
 NO >> Go to diagnosis procedure. Refer to [BRC-36, "Diagnosis Procedure"](#).

Special Repair Requirement

INFOID:000000005519003

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-8, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

C1115 ABS SENSOR [ABNORMAL SIGNAL]

< COMPONENT DIAGNOSIS >

[VDC/TCS/ABS]

C1115 ABS SENSOR [ABNORMAL SIGNAL]

Description

INFOID:000000005462836

When the sensor rotor rotates, the magnetic field changes. It converts the magnetic field changes to current signals (rectangular wave) and transmits them to the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000005462837

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|------------------------------|---|---|
| C1115 | ABS SENSOR [ABNORMAL SIGNAL] | When wheel sensor input signal is malfunctioning. | <ul style="list-style-type: none">• Harness or connector• Wheel sensor• ABS actuator and electric unit (control unit) |

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

| |
|------------------------------|
| Self-diagnosis results |
| ABS SENSOR [ABNORMAL SIGNAL] |

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-40. "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000005518997

Regarding Wiring Diagram information, refer to [BRC-81. "Wiring Diagram - BRAKE CONTROL SYSTEM -"](#).

CAUTION:

Do not check between wheel sensor terminals.

1. CONNECTOR INSPECTION

1. Disconnect ABS actuator and electric unit (control unit) connector and wheel sensor of malfunctioning code.
2. Check terminals for deformation, disconnection, looseness or damage.

Is the inspection result normal?

- YES >> GO TO 2
NO >> Repair or replace as necessary.

2. CHECK WHEEL SENSOR OUTPUT SIGNAL

1. Connect ABS active wheel sensor tester (J-45741) to wheel sensor using appropriate adapter.
2. Turn on the ABS active wheel sensor tester power switch.

NOTE:

The green POWER indicator should illuminate. If the POWER indicator does not illuminate, replace the battery in the ABS active wheel sensor tester before proceeding.

3. Spin the wheel of the vehicle by hand and observe the red SENSOR indicator on the ABS active wheel sensor tester. The red SENSOR indicator should flash on and off to indicate an output signal.

NOTE:

If the red SENSOR indicator illuminates but does not flash, reverse the polarity of the tester leads and retest.

Does the ABS active wheel sensor tester detect a signal?

- YES >> GO TO 3
NO >> Replace the wheel sensor. Refer to [BRC-101. "Removal and Installation"](#).

C1115 ABS SENSOR [ABNORMAL SIGNAL]

[VDC/TCS/ABS]

< COMPONENT DIAGNOSIS >

3. CHECK TIRES

Check the inflation pressure, wear and size of each tire.

Is the inspection result normal?

YES >> GO TO 4

NO >> Adjust tire pressure, or replace tire(s).

4. CHECK WHEEL BEARINGS

Check wheel bearing axial end play. Refer to [FAX-6, "Inspection"](#) (front) or [RAX-6, "On-vehicle Service"](#) (rear).

Is the inspection result normal?

YES >> GO TO 5

NO >> Repair or replace as necessary. Refer to [FAX-8, "Removal and Installation"](#) (front) or [RAX-9, "Wheel Bearing \(Rear\)"](#) (rear).

5. CHECK WIRING HARNESS FOR SHORT CIRCUIT


1. Disconnect ABS actuator and electric unit (control unit) connector and wheel sensor of malfunctioning code.
2. Check continuity between front wheel sensor connector terminals (A), rear wheel sensor connector terminals (B) and ground.

: Continuity should not exist.

Is the inspection result normal?

YES >> GO TO 6

NO >> Repair the circuit.



6. CHECK WIRING HARNESS FOR OPEN CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) connector and the malfunctioning wheel sensor connector.

| Wheel sensor | ABS actuator and electric unit (control unit) | | Wheel sensor | | Continuity |
|--------------|---|----------|--------------|----------|------------|
| | Connector | Terminal | Connector | Terminal | |
| Front LH | E26 | 16 | E19 | 1 | Yes |
| | | 5 | | 2 | |
| Front RH | | 9 | E41 | 1 | |
| | | 10 | | 2 | |
| Rear LH | | 6 | C1 | 1 | |
| | | 17 | | 2 | |
| Rear RH | | 8 | C2 | 1 | |
| | | 19 | | 2 | |

Is the inspection result normal?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-104, "Removal and Installation"](#).

NO >> Repair the circuit.

Component Inspection

INFOID:000000005518998

1. CHECK DATA MONITOR

On "DATA MONITOR", select "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR", and "RR RH SENSOR", and check the vehicle speed.

| Wheel sensor | Vehicle speed (DATA MONITOR) |
|--------------|------------------------------|
| | |

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

C1115 ABS SENSOR [ABNORMAL SIGNAL]

[VDC/TCS/ABS]

< COMPONENT DIAGNOSIS >

| | |
|--------------|--|
| FR LH SENSOR | Nearly matches the speedometer display ($\pm 10\%$ or less) |
| FR RH SENSOR | |
| RR LH SENSOR | |
| RR RH SENSOR | |

Is the inspection result normal?

YES >> Inspection End

NO >> Go to diagnosis procedure. Refer to [BRC-40. "Diagnosis Procedure"](#).

Special Repair Requirement

INFOID:000000005518999

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-8. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

C1116 STOP LAMP SW

< COMPONENT DIAGNOSIS >

[VDC/TCS/ABS]

C1116 STOP LAMP SW

Description

INFOID:000000005462841

The stop lamp switch transmits the stop lamp switch signal (ON/OFF) to the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000005462842

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|--------------|--|---|
| C1116 | STOP LAMP SW | When stop lamp switch circuit is open. | <ul style="list-style-type: none"> • Harness or connector • Stop lamp switch • ABS actuator and electric unit (control unit) |

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

| |
|------------------------|
| Self-diagnosis results |
| STOP LAMP SWITCH |

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-43, "Diagnosis Procedure"](#).
 NO >> Inspection End

Diagnosis Procedure

INFOID:000000005462843

Regarding Wiring Diagram information, refer to [BRC-81, "Wiring Diagram - BRAKE CONTROL SYSTEM -"](#).

1. CONNECTOR INSPECTION

1. Disconnect stop lamp switch connector and ABS actuator and electric unit (control unit) connector.
2. Check terminals for deformation, disconnection, looseness or damage.


Is the inspection result normal?

- YES >> GO TO 2
 NO >> Repair or replace as necessary.

2. CHECK STOP LAMP SWITCH CIRCUIT

1. Connect stop lamp switch connector.
2. Check voltage between ABS actuator and electric unit (control unit) connector E26 terminal 20 and ground.

| ABS actuator and electric unit (control unit) | | Ground | Condition | Voltage (Approx.) |
|---|----------|--------|-----------------------|-------------------|
| Connector | Terminal | | | |
| E26 | 20 | — | Brake pedal depressed | Battery voltage |
| | | | Brake pedal released | 0V |



Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-104, "Removal and Installation"](#).
 NO >> GO TO 3

C1116 STOP LAMP SW

< COMPONENT DIAGNOSIS >

[VDC/TCS/ABS]


3. CHECK STOP LAMP SWITCH CIRCUIT FOR OPEN

1. Disconnect stop lamp switch connector.
2. Check continuity between ABS actuator and electric unit (control unit) connector E26 (A) terminal 20 and stop lamp switch connector E38 (B) terminal 4.

| ABS actuator and electric unit (control unit) | | stop lamp switch | | Continuity |
|---|----------|------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E26 (A) | 20 | E38 (B) | 4 | Yes |

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair or replace as necessary.




4. CHECK STOP LAMP SWITCH CIRCUIT FOR SHORT

Check continuity between ABS actuator and electric unit (control unit) connector E26 terminal 20 and ground.

| ABS actuator and electric unit (control unit) | | Ground | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| E26 | 20 | — | No |

Is the inspection result normal?

- YES >> Replace stop lamp switch.
 NO >> Repair harness or connectors.



Special Repair Requirement

INFOID:000000005519004

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-8. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

C1120, C1122, C1124, C1126 IN ABS SOL

< COMPONENT DIAGNOSIS >

[VDC/TCS/ABS]

C1120, C1122, C1124, C1126 IN ABS SOL

Description

INFOID:000000005462845

The solenoid valve increases, holds or decreases the fluid pressure of each brake caliper according to the signals transmitted by the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000005462846

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|------------------|---|---|
| C1120 | FR LH IN ABS SOL | When the control unit detects a malfunction in the front LH inlet solenoid circuit. | • ABS actuator and electric unit (control unit) |
| C1122 | FR RH IN ABS SOL | When the control unit detects a malfunction in the front RH inlet solenoid circuit. | |
| C1124 | RR LH IN ABS SOL | When the control unit detects a malfunction in the rear LH inlet solenoid circuit. | |
| C1126 | RR RH IN ABS SOL | When the control unit detects a malfunction in the rear RH inlet solenoid circuit. | |

DTC CONFIRMATION PROCEDURE

1.CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

| Self-diagnosis results |
|------------------------|
| FR LH IN ABS SOL |
| FR RH IN ABS SOL |
| RR LH IN ABS SOL |
| RR RH IN ABS SOL |

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-45. "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000005519005

Regarding Wiring Diagram information, refer to [BRC-81. "Wiring Diagram - BRAKE CONTROL SYSTEM -"](#).

1.CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminals for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminals.
4. Reconnect connector and perform self-diagnosis. Refer to [BRC-22. "CONSULT-III Function \(ABS\)"](#).

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2
NO >> Poor connection of connector terminals. Repair or replace connector.

2.CHECK SOLENOID AND ACTUATOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.

C1120, C1122, C1124, C1126 IN ABS SOL

[VDC/TCS/ABS]

< COMPONENT DIAGNOSIS >

- Check voltage between ABS actuator and electric unit (control unit) connector E26 terminal 3 and ground.

| ABS actuator and electric unit (control unit) | | Ground | Voltage (Approx.) |
|---|----------|--------|-------------------|
| Connector | Terminal | | |
| E26 | 3 | — | Battery voltage |

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace malfunctioning components.

3. CHECK SOLENOID AND ACTUATOR RELAY GROUND CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) connector E26 terminals 1, 4 and ground.



| ABS actuator and electric unit (control unit) | | Ground | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| E26 | 1 | — | Yes |
| | 4 | | |

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

Refer to [BRC-104. "Removal and Installation"](#).

NO >> Repair or replace malfunctioning components.



Component Inspection

INFOID:000000005462848

1. CHECK ACTIVE TEST

- Select each test menu item on "ACTIVE TEST".
- On the display, touch "Up", "Keep", and "Down", and check that the system operates as shown in the table below.

| Operation | | ABS solenoid valve | | |
|-----------|---------------|--------------------|------|------|
| | | Up | Keep | Down |
| FR RH SOL | FR RH IN SOL | Off | On | On |
| | FR RH OUT SOL | Off | Off | On* |
| | USV[FR-RR] | Off | Off | On* |
| | USV[FR-RL] | Off | Off | On* |
| | HSV[FL-RR] | Off | Off | On* |
| | HSV[FR-RL] | Off | Off | On* |
| FR LH SOL | FR LH IN SOL | Off | On | On |
| | FR LH OUT SOL | Off | Off | On* |
| | USV[FR-RR] | Off | Off | On* |
| | USV[FR-RL] | Off | Off | On* |
| | HSV[FL-RR] | Off | Off | On* |
| | HSV[FR-RL] | Off | Off | On* |

C1120, C1122, C1124, C1126 IN ABS SOL

< COMPONENT DIAGNOSIS >

[VDC/TCS/ABS]

| Operation | | ABS solenoid valve | | |
|-----------|---------------|--------------------|------|------|
| | | Up | Keep | Down |
| RR RH SOL | RR RH IN SOL | Off | On | On |
| | RR RH OUT SOL | Off | Off | On* |
| | USV[FR-RR] | Off | Off | On* |
| | USV[FR-RL] | Off | Off | On* |
| | HSV[FL-RR] | Off | Off | On* |
| | HSV[FR-RL] | Off | Off | On* |
| RR LH SOL | RR LH IN SOL | Off | On | On |
| | RR LH OUT SOL | Off | Off | On* |
| | USV[FR-RR] | Off | Off | On* |
| | USV[FR-RL] | Off | Off | On* |
| | HSV[FL-RR] | Off | Off | On* |
| | HSV[FR-RL] | Off | Off | On* |

*: On for 1 to 2 seconds after the touch, and then Off

Is the inspection result normal?

YES >> Inspection End.

NO >> Go to diagnosis procedure. Refer to [BRC-45, "Diagnosis Procedure"](#).

Special Repair Requirement

INFOID:000000005519008

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-8, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

C1121, C1123, C1125, C1127 OUT ABS SOL

< COMPONENT DIAGNOSIS >

[VDC/TCS/ABS]

C1121, C1123, C1125, C1127 OUT ABS SOL

Description

INFOID:000000005462850

The solenoid valve increases, holds or decreases the fluid pressure of each brake caliper according to the signals transmitted by the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000005462851

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|-------------------|--|---|
| C1121 | FR LH OUT ABS SOL | When the control unit detects a malfunction in the front LH outlet solenoid circuit. | • ABS actuator and electric unit (control unit) |
| C1123 | FR RH OUT ABS SOL | When the control unit detects a malfunction in the front RH outlet solenoid circuit. | |
| C1125 | RR LH OUT ABS SOL | When the control unit detects a malfunction in the rear LH outlet solenoid circuit. | |
| C1127 | RR RH OUT ABS SOL | When the control unit detects a malfunction in the rear RH outlet solenoid circuit. | |

DTC CONFIRMATION PROCEDURE

1.CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

| Self-diagnosis results |
|------------------------|
| FR LH OUT ABS SOL |
| FR RH OUT ABS SOL |
| RR LH OUT ABS SOL |
| RR RH OUT ABS SOL |

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-45. "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000005519006

Regarding Wiring Diagram information, refer to [BRC-81. "Wiring Diagram - BRAKE CONTROL SYSTEM -"](#).

1.CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminals for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminals.
4. Reconnect connector and perform self-diagnosis. Refer to [BRC-22. "CONSULT-III Function \(ABS\)"](#).

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2
NO >> Poor connection of connector terminals. Repair or replace connector.

2.CHECK SOLENOID AND ACTUATOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.

C1121, C1123, C1125, C1127 OUT ABS SOL

[VDC/TCS/ABS]

< COMPONENT DIAGNOSIS >


- Check voltage between ABS actuator and electric unit (control unit) connector E26 terminal 3 and ground.

| ABS actuator and electric unit (control unit) | | Ground | Voltage (Approx.) |
|---|----------|--------|-------------------|
| Connector | Terminal | | |
| E26 | 3 | — | Battery voltage |

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace malfunctioning components.



3. CHECK SOLENOID AND ACTUATOR RELAY GROUND CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) connector E26 terminals 1, 4 and ground.


| ABS actuator and electric unit (control unit) | | Ground | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| E26 | 1 | — | Yes |
| | 4 | | |

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

Refer to [BRC-104, "Removal and Installation"](#).

NO >> Repair or replace malfunctioning components.



Component Inspection

INFOID:000000005519007

1. CHECK ACTIVE TEST

- Select each test menu item on "ACTIVE TEST".
- On the display, touch "Up", "Keep", and "Down", and check that the system operates as shown in the table below.

| Operation | | ABS solenoid valve | | |
|-----------|---------------|--------------------|------|------|
| | | Up | Keep | Down |
| FR RH SOL | FR RH IN SOL | Off | On | On |
| | FR RH OUT SOL | Off | Off | On* |
| | USV[FR-RR] | Off | Off | On* |
| | USV[FR-RL] | Off | Off | On* |
| | HSV[FL-RR] | Off | Off | On* |
| | HSV[FR-RL] | Off | Off | On* |
| FR LH SOL | FR LH IN SOL | Off | On | On |
| | FR LH OUT SOL | Off | Off | On* |
| | USV[FR-RR] | Off | Off | On* |
| | USV[FR-RL] | Off | Off | On* |
| | HSV[FL-RR] | Off | Off | On* |
| | HSV[FR-RL] | Off | Off | On* |

C1121, C1123, C1125, C1127 OUT ABS SOL

< COMPONENT DIAGNOSIS >

[VDC/TCS/ABS]

| Operation | | ABS solenoid valve | | |
|-----------|---------------|--------------------|------|------|
| | | Up | Keep | Down |
| RR RH SOL | RR RH IN SOL | Off | On | On |
| | RR RH OUT SOL | Off | Off | On* |
| | USV[FR-RR] | Off | Off | On* |
| | USV[FR-RL] | Off | Off | On* |
| | HSV[FL-RR] | Off | Off | On* |
| | HSV[FR-RL] | Off | Off | On* |
| RR LH SOL | RR LH IN SOL | Off | On | On |
| | RR LH OUT SOL | Off | Off | On* |
| | USV[FR-RR] | Off | Off | On* |
| | USV[FR-RL] | Off | Off | On* |
| | HSV[FL-RR] | Off | Off | On* |
| | HSV[FR-RL] | Off | Off | On* |

*: On for 1 to 2 seconds after the touch, and then Off

Is the inspection result normal?

YES >> Inspection End.

NO >> Go to diagnosis procedure. Refer to [BRC-45, "Diagnosis Procedure"](#).

Special Repair Requirement

INFOID:000000005519009

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-8, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

C1130, C1131, C1132, C1133, C1136 ENGINE SIGNAL

< COMPONENT DIAGNOSIS >

[VDC/TCS/ABS]

C1130, C1131, C1132, C1133, C1136 ENGINE SIGNAL

Description

INFOID:000000005462855

ABS actuator and electric unit (control unit) and ECM exchange the engine signal with CAN communication line.

DTC Logic

INFOID:000000005462856

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|-----------------|---|---|
| C1130 | ENGINE SIGNAL 1 | Major engine components are malfunctioning. | <ul style="list-style-type: none">• Harness or connector• ABS actuator and electric unit (control unit)• ECM• CAN communication line |
| C1131 | ENGINE SIGNAL 2 | | |
| C1132 | ENGINE SIGNAL 3 | | |
| C1133 | ENGINE SIGNAL 4 | | |
| C1136 | ENGINE SIGNAL 6 | | |

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

| Self-diagnosis results |
|------------------------|
| ENGINE SIGNAL 1 |
| ENGINE SIGNAL 2 |
| ENGINE SIGNAL 3 |
| ENGINE SIGNAL 4 |
| ENGINE SIGNAL 6 |

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-51, "Diagnosis Procedure"](#).
NO >> Inspection End

Diagnosis Procedure

INFOID:000000005462857

INSPECTION PROCEDURE

1. CHECK ENGINE SYSTEM

1. Perform ECM self-diagnosis. Repair or replace items indicated, then perform ECM self-diagnosis again. Refer to [EC-126, "CONSULT-III Function"](#).
2. Perform ABS actuator and electric unit (control unit) self-diagnosis. Refer to [BRC-22, "CONSULT-III Function \(ABS\)"](#).

Is any item indicated on the self-diagnosis display?

- YES >> Repair or replace malfunctioning components.
NO >> Inspection End.

C1142 PRESS SEN CIRCUIT

< COMPONENT DIAGNOSIS >

[VDC/TCS/ABS]

C1142 PRESS SEN CIRCUIT

Description

INFOID:000000005462859

The pressure sensor converts the brake fluid pressure to an electric signal and transmits it to the ABS actuator and electric unit (control unit). (The pressure sensor is integrated in the ABS actuator and electric unit (control unit).)

DTC Logic

INFOID:000000005462860

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|-------------------|---|---|
| C1142 | PRESS SEN CIRCUIT | Pressure sensor signal line is open or shorted, or pressure sensor is malfunctioning. | <ul style="list-style-type: none">• Harness or connector• Stop lamp switch• ABS actuator and electric unit (control unit) |

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

| |
|------------------------|
| Self-diagnosis results |
| PRESS SEN CIRCUIT |

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-52. "Diagnosis Procedure"](#).
NO >> Inspection End

Diagnosis Procedure

INFOID:000000005462861

Regarding Wiring Diagram information, refer to [BRC-81. "Wiring Diagram - BRAKE CONTROL SYSTEM -"](#).

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector and stop lamp switch connector.
3. Check terminals for deformation, disconnection, looseness and damage. If any malfunction is found, repair or replace terminals.
4. Reconnect connectors securely.
5. Start engine.
6. Pump brake pedal carefully several times, and perform self-diagnosis.

Is the inspection result normal?

- YES >> GO TO 2
NO >> Poor connection of connector terminal. Repair or replace connector.

2. CHECK STOP LAMP SWITCH

C1142 PRESS SEN CIRCUIT

[VDC/TCS/ABS]

< COMPONENT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch connector.
3. Check continuity between stop lamp switch terminals 3 and 4.

| Stop lamp switch terminals | Condition | Continuity |
|----------------------------|-----------------------|------------|
| 3 – 4 | Brake pedal depressed | Yes |
| | Brake pedal released | No |

Is the inspection result normal?

- YES >> GO TO 3
 NO >> Replace stop lamp switch.

3.CHECK STOP LAMP SWITCH CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Connect stop lamp switch connector.
3. Check voltage between ABS actuator and electric unit (control unit) connector E26 terminal 20 and ground.

| ABS actuator and electric unit (control unit) | | Ground | Condition | Voltage (Approx.) |
|---|----------|--------|-----------------------|-------------------|
| Connector | Terminal | | | |
| E26 | 20 | — | Brake pedal depressed | Battery voltage |
| | | | Brake pedal released | 0V |

Is the inspection result normal?

- YES >> GO TO 4
 NO >> Repair or replace malfunctioning components.

4.CHECK SELF-DIAGNOSIS RESULTS

Check self-diagnosis results.

| |
|------------------------|
| Self-diagnosis results |
| PRESS SEN CIRCUIT |

Is above displayed on the self-diagnosis display?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-104. "Removal and Installation"](#).
 NO >> Inspection End.

Component Inspection

INFOID:000000005462862

1.CHECK DATA MONITOR

On "DATA MONITOR", select "PRESS SENSOR" and check the brake fluid pressure.

| Condition | PRESS SENSOR (DATA MONITOR) |
|---|-----------------------------|
| With ignition switch turned ON and brake pedal released. | Approx. 0 bar |
| With ignition switch turned ON and brake pedal depressed. | – 40 to 300 bar |



Is the inspection result normal?

- YES >> Inspection End
 NO >> Go to diagnosis procedure. Refer to [BRC-52. "Diagnosis Procedure"](#).

Special Repair Requirement

INFOID:000000005519011

1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION



C1142 PRESS SEN CIRCUIT

< COMPONENT DIAGNOSIS >

[VDC/TCS/ABS]

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-8, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

C1143, C1144 STEERING ANGLE SENSOR

< COMPONENT DIAGNOSIS >

[VDC/TCS/ABS]

C1143, C1144 STEERING ANGLE SENSOR

Description

INFOID:000000005462864

The steering angle sensor detects the rotation amount, angular velocity and direction of the steering wheel, and transmits the data to the ABS actuator and electric unit (control unit) via CAN communication.

DTC Logic

INFOID:000000005462865

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|--------------------|--|--|
| C1143 | ST ANG SEN CIRCUIT | Neutral position of steering angle sensor is dislocated, or the steering angle sensor is malfunctioning. | <ul style="list-style-type: none"> • Harness or connector • Steering angle sensor • ABS actuator and electric unit (control unit) |
| C1144 | ST ANG SEN SIGNAL | Neutral position of steering angle sensor is not finished. | |

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

| |
|------------------------|
| Self-diagnosis results |
| ST ANG SEN CIRCUIT |
| ST ANG SEN SIGNAL |

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-55, "Diagnosis Procedure"](#).
 NO >> Inspection End

Diagnosis Procedure

INFOID:000000005462866

Regarding Wiring Diagram information, refer to [BRC-81, "Wiring Diagram - BRAKE CONTROL SYSTEM -"](#).

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminals for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminals.
4. Reconnect connector and perform self-diagnosis. Refer to [BRC-22, "CONSULT-III Function \(ABS\)"](#).


Is any item displayed on the self-diagnosis display?

- YES >> GO TO 2
 NO >> Poor connection of connector terminals. Repair or replace connector.

2. CHECK STEERING ANGLE SENSOR HARNESS

1. Check CAN communication system. Refer to [LAN-16, "Trouble Diagnosis Flow Chart"](#).
2. Turn ignition switch OFF.
3. Disconnect steering angle sensor connector.
4. Check continuity between steering angle sensor harness connector M53 terminal 1 and ground.

| Steering angle sensor | | Ground | Continuity |
|-----------------------|----------|--------|------------|
| Connector | Terminal | | |
| M53 | 1 | — | Yes |



C1143, C1144 STEERING ANGLE SENSOR

[VDC/TCS/ABS]

< COMPONENT DIAGNOSIS >

5. Turn ignition switch ON.
6. Check voltage between steering angle sensor connector M53 terminal 4 and ground.

| Steering angle sensor | | Ground | Voltage (Approx.) |
|-----------------------|----------|--------|-------------------|
| Connector | Terminal | | |
| M53 | 4 | — | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 3
 NO >> Repair or replace malfunctioning components.

3.CHECK DATA MONITOR

1. Turn ignition switch OFF.
2. Connect steering angle sensor connector and ABS actuator and electric unit (control unit) connector.
3. Select "STR ANGLE SIG" in "Data Monitor" and check steering angle sensor signal.

| Steering condition | STR ANGLE SIG (Data monitor) |
|--------------------|------------------------------|
| Driving straight | - 2.5 ° to + 2.5 ° |
| Turn 90° to right | Approx.+ 90 ° |
| Turn 90° to left | Approx.- 90 ° |

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-104, "Removal and Installation"](#).
 NO >> Replace steering angle sensor and adjust neutral position of steering angle sensor. Refer to [BRC-107, "Removal and Installation"](#) and [BRC-56, "Special Repair Requirement"](#).

Component Inspection

INFOID:000000005462867

1.CHECK DATA MONITOR

Select "STR ANGLE SIG" in "DATA MONITOR" and check steering angle sensor signal.

| Steering condition | STR ANGLE SIG (DATA MONITOR) |
|--------------------|------------------------------|
| Driving straight | ±2.5 ° |
| Turn 90 ° to right | Approx. +90 ° |
| Turn 90 ° to left | Approx. -90 ° |

Is the inspection result normal?

- YES >> Inspection End
 NO >> Go to diagnosis procedure. Refer to [BRC-55, "Diagnosis Procedure"](#).


Special Repair Requirement

INFOID:000000005519012

1.ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-8, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END



C1145, C1146 YAW RATE/SIDE G SENSOR

< COMPONENT DIAGNOSIS >

[VDC/TCS/ABS]

C1145, C1146 YAW RATE/SIDE G SENSOR

Description

INFOID:000000005462869

The yaw rate/side/decel G sensor detects the yaw rate/side/decel G affecting the vehicle, and transmits the data to the ABS actuator and electric unit (control unit) as an analog voltage signal.

DTC Logic

INFOID:000000005462870

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|--------------------|---|---|
| C1145 | YAW RATE SENSOR | Yaw rate sensor is malfunctioning, or the yaw rate sensor signal line is open or shorted. | • Harness or connector • ABS actuator and electric unit (control unit) • Yaw rate/side G sensor |
| C1146 | SIDE G-SEN CIRCUIT | Side G sensor is malfunctioning, or circuit of side G sensor is open or shorted. | |

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

| |
|------------------------|
| Self-diagnosis results |
| YAW RATE SENSOR |
| SIDE G-SEN CIRCUIT |

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-57. "Diagnosis Procedure"](#).
NO >> Inspection End

Diagnosis Procedure

INFOID:000000005462871

Regarding Wiring Diagram information, refer to [BRC-81. "Wiring Diagram - BRAKE CONTROL SYSTEM -"](#).

CAUTION:

- Sudden turns (such as spin turns, acceleration turns), drifting, etc., when VDC function is off (VDC OFF switch "ON") may cause yaw rate/side/decel G sensor system to indicate a malfunction. However, this is not a malfunction if normal operation can be resumed after restarting engine. Then erase memory of self-diagnosis.
- If vehicle is on turn-table at entrance to parking garage, or on other moving surfaces, VDC OFF indicator lamp may illuminate and CONSULT-III self-diagnosis may indicate yaw rate sensor system malfunction. However, in this case there is no malfunction in yaw rate sensor system. Take vehicle off of turn-table or other moving surfaces, and start engine. Results will return to normal. Also, after doing spin turns or acceleration turns with VDC function off (VDC OFF switch "ON"), the results will return to a normal condition by re-starting vehicle.

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect yaw rate/side/decel G sensor connector and ABS actuator and electric unit (control unit) connector.
3. Check terminals for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminals.
4. Reconnect connectors and perform self-diagnosis. Refer to [BRC-22. "CONSULT-III Function \(ABS\)"](#).

Is any item displayed on the self-diagnosis display?

- YES >> GO TO 2
NO >> Poor connection of connector terminals. Repair or replace connectors.

C1145, C1146 YAW RATE/SIDE G SENSOR


< COMPONENT DIAGNOSIS >

[VDC/TCS/ABS]

2. CHECK YAW RATE/SIDE/DECEL G SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch ON, then OFF.
2. Check voltage between yaw rate/side/decel G sensor connector M55 terminal 4 and ground.

| Yaw rate/side/decel G sensor | | Ground | Condition | Voltage (Approx.) |
|------------------------------|----------|--------|----------------------|-------------------|
| Connector | Terminal | | | |
| M55 | 4 | — | Ignition switch: ON | Battery voltage |
| | | | Ignition switch: OFF | 0V |




Is the inspection result normal?

- YES >> GO TO 3
 NO >> Repair or replace malfunctioning components.

3. CHECK YAW RATE/SIDE/DECEL G SENSOR GROUND SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Check resistance between yaw rate/side/decel G sensor connector M55 terminal 1 and ground.

| Yaw rate/side/decel G sensor | | Ground | Continuity |
|------------------------------|----------|--------|------------|
| Connector | Terminal | | |
| M55 | 1 | — | Yes |




Is the inspection result normal?

- YES >> GO TO 4
 NO >> Repair or replace malfunctioning components.

4. CHECK YAW RATE/SIDE/DECEL G SENSOR HARNESS

1. Check continuity between ABS actuator and electric unit (control unit) connector E26 (A) terminals 14 and 25 and yaw rate/side/decel G sensor harness connector M55 (B) terminals 2 and 3.

| ABS actuator and electric unit (control unit) | | Yaw rate/side/decel G sensor | | Continuity |
|---|----------|------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E26 (A) | 14 | M55 (B) | 2 | Yes |
| | 25 | | 3 | |



2. Check continuity between ABS actuator and electric unit (control unit) connector E26 (A) terminals 14, 25 and ground.

| ABS actuator and electric unit (control unit) | | Ground | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| E26 (A) | 14 | — | No |
| | 25 | | |

Is the inspection result normal?

- YES >> GO TO 5
 NO >> Repair or replace malfunctioning components.

5. CHECK DATA MONITOR

1. Connect Yaw rate/side/decel G sensor and ABS actuator and electric unit (control unit) connectors.

C1145, C1146 YAW RATE/SIDE G SENSOR

< COMPONENT DIAGNOSIS >

[VDC/TCS/ABS]

2. Select "YAW RATE SEN", "SIDE G-SENSOR" in "Data Monitor" and check Yaw rate/side/decel G sensor signal.

| Vehicle condition | Yaw rate sensor (Data monitor) | Side G sensor (Data monitor) |
|-------------------|--------------------------------|------------------------------|
| Stopped | Approx. 0 d/s | Approx. 0 m/s ² |
| Turning right | Negative value | Negative value |
| Turning left | Positive value | Positive value |

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-104. "Removal and Installation"](#).

NO >> Replace Yaw rate/side/decel G sensor. Refer to [BRC-106. "Removal and Installation"](#).

Component Inspection

INFOID:000000005462872

1.CHECK DATA MONITOR

Select "YAW RATE SEN", "SIDE G-SENSOR" in "DATA MONITOR" and check yaw rate/side/decel G sensor signal.

| Vehicle condition | YAW RATE SEN (DATA MONITOR) | SIDE G-SENSOR (DATA MONITOR) |
|-------------------|-----------------------------|------------------------------|
| Stopped | Approx. 0 d/s | Approx. 0 m/s ² |
| Turning right | Negative value | Negative value |
| Turning left | Positive value | Positive value |

Is the inspection result normal?

YES >> Inspection End

NO >> Go to diagnosis procedure. Refer to [BRC-57. "Diagnosis Procedure"](#).

Special Repair Requirement

INFOID:000000005519013

1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-8. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

C1147, C1148, C1149, C1150 USV/HSV LINE

< COMPONENT DIAGNOSIS >

[VDC/TCS/ABS]

C1147, C1148, C1149, C1150 USV/HSV LINE

Description

INFOID:000000005462874

USV1, USV2 (CUT VALVE)

The cut valve shuts off the normal brake fluid path from the master cylinder, when VDC/TCS is activated.

HSV1, HSV2 (SUCTION VALVE)

The suction valve supplies the brake fluid from the master cylinder to the pump, when VDC/TCS is activated.

DTC Logic

INFOID:000000005462875

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|-----------------|---|---|
| C1147 | USV LINE[FL-RR] | VDC switch-over solenoid valve (USV1) on the primary side is open circuit or shorted, or the control line is open or shorted to the power supply or the ground. | • Harness or connector • ABS actuator and electric unit (control unit) |
| C1148 | USV LINE[FR-RL] | VDC switch-over solenoid valve (USV2) on the primary side is open circuit or shorted, or the control line is open or shorted to the power supply or the ground. | |
| C1149 | HSV LINE[FL-RR] | VDC switch-over solenoid valve (HSV1) on the primary side is open circuit or shorted, or the control line is open or shorted to the power supply or the ground. | |
| C1150 | HSV LINE[FR-RL] | VDC switch-over solenoid valve (HSV2) on the primary side is open circuit or shorted, or the control line is open or shorted to the power supply or the ground. | |

DTC CONFIRMATION PROCEDURE

1.CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

| Self-diagnosis results |
|------------------------|
| USV LINE[FL-RR] |
| USV LINE[FR-RL] |
| HSV LINE[FL-RR] |
| HSV LINE[FR-RL] |

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-60. "Diagnosis Procedure"](#).
NO >> Inspection End

Diagnosis Procedure

INFOID:000000005519014

Regarding Wiring Diagram information, refer to [BRC-81. "Wiring Diagram - BRAKE CONTROL SYSTEM -"](#).

1.CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminals for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminals.
4. Reconnect connector and perform self-diagnosis. Refer to [BRC-22. "CONSULT-III Function \(ABS\)"](#).

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2

C1147, C1148, C1149, C1150 USV/HSV LINE

< COMPONENT DIAGNOSIS >

[VDC/TCS/ABS]

NO >> Poor connection of connector terminals. Repair or replace connector.

2. CHECK SOLENOID AND ACTUATOR RELAY POWER SUPPLY CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check voltage between ABS actuator and electric unit (control unit) connector E26 terminal 3 and ground.

| ABS actuator and electric unit (control unit) | | Ground | Voltage (Approx.) |
|---|----------|--------|-------------------|
| Connector | Terminal | | |
| E26 | 3 | — | Battery voltage |

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace malfunctioning components.



3. CHECK SOLENOID AND ACTUATOR RELAY GROUND CIRCUIT


Check continuity between ABS actuator and electric unit (control unit) connector E26 terminals 1, 4 and ground.

| ABS actuator and electric unit (control unit) | | Ground | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| E26 | 1 | — | Yes |
| | 4 | | |

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).
Refer to [BRC-104, "Removal and Installation"](#).

NO >> Repair or replace malfunctioning components.



Component Inspection

INFOID:000000005462877

1. CHECK ACTIVE TEST

1. Select each test menu item on "ACTIVE TEST".
2. On the display, touch "Up", "ACT UP", and "ACT KEEP", and check that the system operates as shown in the table below.

| Operation | ABS solenoid valve (ACT) | | | |
|--------------------------|--------------------------|--------|----------|-----|
| | Up | ACT UP | ACT KEEP | |
| FR RH ABS SOLENOID (ACT) | FR RH IN SOL | Off | Off | Off |
| | FR RH OUT SOL | Off | Off | Off |
| | USV[FR-RR] | Off | Off | Off |
| | USV[FR-RL] | Off | On | On |
| | HSV[FL-RR] | Off | Off | Off |
| | HSV[FR-RL] | Off | On* | Off |
| FR LH ABS SOLENOID (ACT) | FR LH IN SOL | Off | Off | Off |
| | FR LH OUT SOL | Off | Off | Off |
| | USV[FR-RR] | Off | Off | Off |
| | USV[FR-RL] | Off | On | On |
| | HSV[FL-RR] | Off | Off | Off |
| | HSV[FR-RL] | Off | On* | Off |

C1147, C1148, C1149, C1150 USV/HSV LINE

< COMPONENT DIAGNOSIS >

[VDC/TCS/ABS]

| Operation | | ABS solenoid valve (ACT) | | |
|--------------------------|---------------|--------------------------|--------|----------|
| | | Up | ACT UP | ACT KEEP |
| RR RH ABS SOLENOID (ACT) | RR RH IN SOL | Off | Off | Off |
| | RR RH OUT SOL | Off | Off | Off |
| | USV[FR-RR] | Off | Off | Off |
| | USV[FR-RL] | Off | On | On |
| | HSV[FL-RR] | Off | Off | Off |
| | HSV[FR-RL] | Off | On* | Off |
| RR LH ABS SOLENOID (ACT) | RR LH IN SOL | Off | Off | Off |
| | RR LH OUT SOL | Off | Off | Off |
| | USV[FR-RR] | Off | Off | Off |
| | USV[FR-RL] | Off | On | On |
| | HSV[FL-RR] | Off | Off | Off |
| | HSV[FR-RL] | Off | On* | Off |

*: On for 1 to 2 seconds after the touch, and then Off

Is the inspection result normal?

YES >> Inspection End

NO >> Go to diagnosis procedure. Refer to [BRC-60, "Diagnosis Procedure"](#).

Special Repair Requirement

INFOID:000000005519015

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-8, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

C1154 TRANSMISSION RANGE SWITCH

< COMPONENT DIAGNOSIS >

[VDC/TCS/ABS]

C1154 TRANSMISSION RANGE SWITCH

Description

INFOID:000000005462879

The transmission range switch signal is transmitted to the ABS actuator and electric unit (control unit) using the CAN communication lines.

DTC Logic

INFOID:000000005462880

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|--------------|--|--|
| C1154 | PNP POS SIG | Transmission range switch signal or communication line between the ABS actuator and electric unit (control unit) and TCM is open or shorted. | <ul style="list-style-type: none">• Harness or connector• Transmission range switch |

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

| Self-diagnosis results |
|------------------------|
| PNP POS SIG |

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-63, "Diagnosis Procedure"](#).
NO >> Inspection End

Diagnosis Procedure

INFOID:000000005462881

INSPECTION PROCEDURE

1. CHECK DATA MONITOR

Select "SLCT LVR POSI" in "Data Monitor" and check transmission range switch signal.

| Selector lever position | SLCT LVR POSI (Data monitor) |
|-------------------------|------------------------------|
| P position | P |
| R position | R |
| N position | N |
| D position | D |

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-104, "Removal and Installation"](#).
NO >> GO TO 2

2. CHECK TRANSMISSION RANGE SWITCH

Perform transmission range switch inspection. Refer to [TM-47, "Component Inspection \(Transmission Range Switch\)"](#).

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-104, "Removal and Installation"](#).
NO >> Repair or replace malfunctioning components.

Special Repair Requirement

INFOID:000000005519016

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

C1154 TRANSMISSION RANGE SWITCH

< COMPONENT DIAGNOSIS >

[VDC/TCS/ABS]

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit). Refer to [BRC-8, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

C1155 BR FLUID LEVEL LOW

< COMPONENT DIAGNOSIS >

[VDC/TCS/ABS]

C1155 BR FLUID LEVEL LOW

Description

INFOID:000000005462883

The brake fluid level switch converts the brake fluid level to an electric signal and transmits it to the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000005462884

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|--------------------|---|---|
| C1155 | BR FLUID LEVEL LOW | Brake fluid level is low or communication line between the ABS actuator and electric unit (control unit) and brake fluid level switch is open or shorted. | <ul style="list-style-type: none">• Harness or connector• Brake fluid level switch |

DTC CONFIRMATION PROCEDURE

1.CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

| Self-diagnosis results |
|------------------------|
| BR FLUID LEVEL LOW |

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-65, "Diagnosis Procedure"](#).
NO >> Inspection End

Diagnosis Procedure

INFOID:000000005462885

Regarding Wiring Diagram information, refer to [BRC-81, "Wiring Diagram - BRAKE CONTROL SYSTEM -"](#).

CAUTION:

Check brake fluid level in brake reservoir tank before starting inspection.

1.CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect brake fluid level switch connector and combination meter connector.
3. Check terminals for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminals.
4. Reconnect connector and perform self-diagnosis. Refer to [BRC-22, "CONSULT-III Function \(ABS\)"](#).

Is any item displayed on the self-diagnosis display?

- YES >> GO TO 2
NO >> Poor connection of connector terminals. Repair or replace connectors.

2.CHECK BRAKE FLUID LEVEL SWITCH

Perform the brake fluid level switch component inspection. Refer to [BRC-66, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 3
NO >> Replace brake fluid level switch. Refer to [BR-38, "Disassembly and Assembly"](#).

3.CHECK BRAKE FLUID LEVEL SWITCH HARNESS

C1155 BR FLUID LEVEL LOW

[VDC/TCS/ABS]

< COMPONENT DIAGNOSIS >

1. Disconnect combination meter connector.
2. Check continuity between combination meter connector M24 (A) terminal 27 and brake fluid level switch connector E24 (B) terminal 1.

27 - 1 : Continuity should exist.

3. Check continuity between combination meter connector M24 (A) terminal 27 and ground.

27 - Ground : Continuity should not exist.

Is the inspection result normal?

- YES >> GO TO 4
- NO >> Repair or replace malfunctioning components.



4. CHECK BRAKE FLUID LEVEL SWITCH GROUND CIRCUIT

Check continuity between brake fluid level switch connector E24 (B) terminal 2 and ground.

2 - Ground : Continuity should exist.

Is the inspection result normal?

- YES >> Inspection End.
- NO >> • Repair or replace malfunctioning components.
• Perform the self-diagnosis, and make sure that the result shows "NO DTC IS DETECTED".



Component Inspection

INFOID:000000005462886


1. CHECK BRAKE FLUID LEVEL SWITCH

1. Turn ignition switch OFF.
2. Disconnect brake fluid level switch connector.
3. Check continuity between brake fluid level switch terminals 1 and 2.

| Brake fluid level switch terminals | Condition | Continuity |
|------------------------------------|-----------------------------|------------|
| 1—2 | Brake fluid reservoir full | No |
| | Brake fluid reservoir empty | Yes |

Is the inspection result normal?

- YES >> Inspection End.
- NO >> Replace brake fluid level switch. Refer to [BR-38, "Disassembly and Assembly"](#).



C1156 ST ANG SEN COM CIR

Description

INFOID:000000005462888

The steering angle sensor is connected to the ABS actuator and electric unit (control unit) in addition to CAN lines. CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

DTC Logic

INFOID:000000005462889

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|--------------------|---|--|
| C1156 | ST ANG SEN COM CIR | When steering angle sensor is not transmitting CAN communication signal to the ABS actuator and electric unit (control unit). | <ul style="list-style-type: none"> • Harness or connector • CAN communication line • Steering angle sensor • ABS actuator and electric unit (control unit) |

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

DTC CONFIRMATION PROCEDURE

1.CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

| |
|------------------------|
| Self-diagnosis results |
| ST ANG SEN COM CIR |

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-67. "Diagnosis Procedure"](#).
- NO >> Inspection End

Diagnosis Procedure

INFOID:000000005462890

1.CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminals for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminals.
4. Reconnect connector and perform self-diagnosis. Refer to [BRC-22. "CONSULT-III Function \(ABS\)"](#).

| |
|------------------------|
| Self-diagnosis results |
| CAN COMM CIRCUIT |
| ST ANG SEN COM CIR |

Is above displayed on the self-diagnosis display?

- YES >> Refer to [LAN-16. "Trouble Diagnosis Flow Chart"](#).
- NO >> Inspection End.

U1000 CAN COMM CIRCUIT

< COMPONENT DIAGNOSIS >

[VDC/TCS/ABS]

U1000 CAN COMM CIRCUIT

Description

INFOID:000000005462891

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

DTC Logic

INFOID:000000005462892

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|------------------|---|--|
| U1000 | CAN COMM CIRCUIT | When ABS actuator and electric unit (control unit) is not transmitting or receiving CAN communication signal for 2 seconds or more. | <ul style="list-style-type: none">• CAN communication line• ABS actuator and electric unit (control unit) |

Diagnosis Procedure

INFOID:000000005462893

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminals for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminals.
4. Reconnect connector and perform self-diagnosis. Refer to [BRC-22, "CONSULT-III Function \(ABS\)"](#).

Self-diagnosis results

CAN COMM CIRCUIT

Is above displayed on the self-diagnosis display?

- YES >> Refer to [LAN-16, "Trouble Diagnosis Flow Chart"](#).
NO >> Inspection End.

PARKING BRAKE SWITCH

< COMPONENT DIAGNOSIS >

[VDC/TCS/ABS]

PARKING BRAKE SWITCH

Description

INFOID:000000005462894

The parking brake switch converts the status of the parking brake pedal to an electric signal and transmits it to the combination meter. The combination meter, through CAN communication, transmits the signal to the ABS actuator and electric unit (control unit).

Component Function Check

INFOID:000000005462895

1. CHECK PARKING BRAKE SWITCH OPERATION

Operate the parking brake and check that the brake warning lamp in the combination meter turns on/off correctly.

| Condition | Brake warning lamp illumination |
|---------------------------|---------------------------------|
| Parking brake engaged | ON |
| Parking brake not engaged | OFF |

Is the inspection result normal?

YES >> Inspection End

NO >> Go to diagnosis procedure. Refer to [BRC-69, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000005462896

Regarding Wiring Diagram information, refer to [BRC-81, "Wiring Diagram - BRAKE CONTROL SYSTEM -"](#).


1. CHECK PARKING BRAKE SWITCH CIRCUIT

1. Disconnect combination meter connector and parking brake switch connector.
2. Check continuity between combination meter connector M24 (A) terminal 26 and parking brake switch connector E35 (B) terminal 1.

26 - 1 : Continuity should exist.

3. Check continuity between combination meter harness connector M24 (A) terminal 26 and ground.

26 - Ground : Continuity should not exist.



Is the inspection result normal?

YES >> GO TO 2

NO >> Repair harness or connector.

2. CHECK PARKING BRAKE SWITCH

Perform parking brake switch component inspection. Refer to [BRC-69, "Component Inspection"](#).

Is the inspection result normal?

YES >> Check parking brake switch case ground condition.

NO >> Replace parking brake switch.

Component Inspection

INFOID:000000005462897

INSPECTION PROCEDURE

1. CHECK PARKING BRAKE SWITCH

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

PARKING BRAKE SWITCH

[VDC/TCS/ABS]


< COMPONENT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect parking brake switch connector.
3. Check continuity between parking brake switch terminal 1 and ground.

| Component | Terminal | Condition | Continuity |
|----------------------|----------|-------------------------|------------|
| Parking brake switch | 1 | Parking brake depressed | Yes |
| | | Parking brake released | No |

Is the inspection result normal?

- YES >> Inspection End.
NO >> Replace parking brake switch.



VDC OFF SWITCH

< COMPONENT DIAGNOSIS >

[VDC/TCS/ABS]

VDC OFF SWITCH

Description

INFOID:000000005462898

VDC OFF switch deactivates (turn OFF) the VDC/TCS function when the VDC OFF switch is pressed.

Component Function Check

INFOID:000000005462899

1.CHECK VDC OFF SWITCH OPERATION

Operate the VDC OFF switch and check that the VDC OFF indicator lamp in the combination meter turns on/off correctly.

| Condition | VDC OFF indicator lamp illumination |
|--------------------|-------------------------------------|
| VDC OFF switch ON | ON |
| VDC OFF switch OFF | OFF |

Is the inspection result normal?

YES >> Inspection End

NO >> Go to diagnosis procedure. Refer to [BRC-71. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000005462900

Regarding Wiring Diagram information, refer to [BRC-81. "Wiring Diagram - BRAKE CONTROL SYSTEM -"](#).

INSPECTION PROCEDURE

1.CHECK VDC OFF SWITCH

Perform VDC OFF switch component inspection. Refer to [BRC-72. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 2

NO >> Replace VDC OFF switch.

2.CHECK VDC OFF SWITCH HARNESS

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between ABS actuator and electric unit (control unit) connector E26 (A) terminal 21 and VDC OFF switch connector M72 (B) terminal 1.

| ABS actuator and electric unit (control unit) | | VDC OFF switch | | Continuity |
|---|----------|----------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E26 (A) | 21 | M72 (B) | 1 | Yes |

3. Check continuity between ABS actuator and electric unit (control unit) connector E26 (A) terminal 21 and ground.


| ABS actuator and electric unit (control unit) | | Ground | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| E26 (A) | 21 | — | No |

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace malfunctioning components.

3.CHECK VDC OFF SWITCH GROUND



A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

VDC OFF SWITCH

[VDC/TCS/ABS]


< COMPONENT DIAGNOSIS >

Check continuity between VDC OFF switch connector M72 terminal 2 and ground.

| VDC OFF switch | | Ground | Continuity |
|----------------|----------|--------|------------|
| Connector | Terminal | | |
| M72 | 2 | — | No |

Is the inspection result normal?

- YES >> Inspection End.
 NO >> Repair or replace malfunctioning components.



INFOID:000000005462901

Component Inspection

INSPECTION PROCEDURE


1. CHECK VDC OFF SWITCH

1. Turn ignition switch OFF.
2. Disconnect VDC OFF switch connector.
3. Check continuity between VDC OFF switch terminals.

| VDC OFF switch terminals | Condition | Continuity |
|--------------------------|-------------------------------|------------|
| 1 - 2 | VDC OFF switch is pressed ON | Yes |
| | VDC OFF switch is pressed OFF | No |

Is the inspection result normal?

- YES >> Inspection End
 NO >> Replace VDC OFF switch.



ABS WARNING LAMP

< COMPONENT DIAGNOSIS >

[VDC/TCS/ABS]

ABS WARNING LAMP

Description

INFOID:000000005462902

x: ON –: OFF

| Condition | ABS warning lamp |
|--|------------------|
| Ignition switch OFF | – |
| For 2 seconds after turning ON ignition switch | x |
| 2 seconds later after turning ON ignition switch | – |
| ABS function is malfunctioning. | x |
| EBD function is malfunctioning. | x |

Component Function Check

INFOID:000000005462903

1.CHECK ABS WARNING LAMP OPERATION

Check that the lamp illuminates for approximately 2 seconds after the ignition switch is turned ON.

Is the inspection result normal?

YES >> Inspection End

NO >> Go to diagnosis procedure. Refer to [BRC-73, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000005462904

1.CHECK SELF-DIAGNOSIS

Perform ABS actuator and electric unit (control unit) self-diagnosis. Refer to [BRC-22, "CONSULT-III Function \(ABS\)"](#).

Is the inspection result normal?

YES >> GO TO 2

NO >> Check items displayed by self-diagnosis.

2.CHECK COMBINATION METER

Check if the indication and operation of combination meter are normal. Refer to [MWI-4, "Work Flow"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-104, "Removal and Installation"](#).

NO >> Repair or replace combination meter. Refer to [MWI-140, "Removal and Installation"](#).

BRAKE WARNING LAMP

< COMPONENT DIAGNOSIS >

[VDC/TCS/ABS]

BRAKE WARNING LAMP

Description

INFOID:000000005462905

×: ON –: OFF

| Condition | Brake warning lamp (Note 1) |
|---------------------------------|-----------------------------|
| Ignition switch OFF | – |
| Ignition switch ON | × (Note 2) |
| EBD function is malfunctioning. | × |

NOTE:

- 1: Brake warning lamp will turn on in case of parking brake operation (when switch is ON) or of brake fluid level switch operation (when brake fluid is insufficient).
- 2: After starting engine, brake warning lamp is turned off.

Component Function Check

INFOID:000000005462906

1. BRAKE WARNING LAMP OPERATION CHECK 1

Check that the lamp illuminates after the ignition switch is turned ON, and turns OFF after the engine is started.

Is the inspection result normal?

YES >> GO TO 2

NO >> Go to diagnosis procedure. Refer to [BRC-74, "Diagnosis Procedure"](#).

2. BRAKE WARNING LAMP OPERATION CHECK 2

Check that the brake warning lamp in the combination meter turns on/off correctly when operating the parking brake.

Is the inspection result normal?

YES >> Inspection End

NO >> Check parking brake switch. Refer to [MWI-43, "Description"](#).

Diagnosis Procedure

INFOID:000000005462907

1. CHECK PARKING BRAKE SWITCH

Check that the brake warning lamp in the combination meter turns on/off correctly when operating the parking brake.

Is the inspection result normal?

YES >> GO TO 2

NO >> Check parking brake switch. Refer to [MWI-43, "Description"](#).

2. CHECK SELF-DIAGNOSIS

Perform ABS actuator and electric unit (control unit) self-diagnosis. Refer to [BRC-22, "CONSULT-III Function \(ABS\)"](#).

Is the inspection result normal?

YES >> GO TO 3

NO >> Check items displayed by self-diagnosis.

3. CHECK COMBINATION METER

Check if the indication and operation of combination meter are normal. Refer to [MWI-4, "Work Flow"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-104, "Removal and Installation"](#).

NO >> Repair or replace combination meter. Refer to [MWI-140, "Removal and Installation"](#).

VDC OFF INDICATOR LAMP

< COMPONENT DIAGNOSIS >

[VDC/TCS/ABS]

VDC OFF INDICATOR LAMP

Description

INFOID:000000005462908

x: ON –: OFF

| Condition | VDC OFF indicator lamp |
|--|------------------------|
| Ignition switch OFF | – |
| For 2 seconds after turning ON ignition switch | x |
| 2 seconds later after turning ON ignition switch | – |
| VDC OFF switch turned ON. (VDC function is OFF.) | x |
| VDC/TCS function is malfunctioning. | x |
| ABS function is malfunctioning. | x |
| EBD function is malfunctioning. | x |

Component Function Check

INFOID:000000005462909

1.VDC OFF INDICATOR LAMP OPERATION CHECK 1

Check that the lamp illuminates for approximately 2 seconds after the ignition switch is turned ON.

Is the inspection result normal?

YES >> GO TO 2

NO >> Go to diagnosis procedure. Refer to [BRC-75. "Diagnosis Procedure"](#).

2.VDC OFF INDICATOR LAMP OPERATION CHECK 2

Check that the VDC OFF indicator lamp in the combination meter turns on/off correctly when operating the VDC OFF switch.

Is the inspection result normal?

YES >> Inspection End

NO >> Check VDC OFF switch. Refer to [BRC-71. "Description"](#).

Diagnosis Procedure

INFOID:000000005462910

1.CHECK VDC OFF SWITCH

Check that the VDC OFF indicator lamp in the combination meter turns on/off correctly when operating the VDC OFF switch.

Is the inspection result normal?

YES >> GO TO 2

NO >> Check VDC OFF switch. Refer to [BRC-71. "Diagnosis Procedure"](#).

2.CHECK SELF-DIAGNOSIS

Perform ABS actuator and electric unit (control unit) self-diagnosis. Refer to [BRC-22. "CONSULT-III Function \(ABS\)"](#).

Is the inspection result normal?

YES >> GO TO 3

NO >> Check items displayed by self-diagnosis.

3.CHECK COMBINATION METER

Check if the indication and operation of combination meter are normal. Refer to [MWI-4. "Work Flow"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-104. "Removal and Installation"](#).

NO >> Repair or replace combination meter. Refer to [MWI-140. "Removal and Installation"](#).

SLIP INDICATOR LAMP

< COMPONENT DIAGNOSIS >

[VDC/TCS/ABS]

SLIP INDICATOR LAMP

Description

INFOID:000000005462911

x: ON –: OFF

| Condition | SLIP indicator lamp |
|--|---------------------|
| Ignition switch OFF | – |
| For 2 seconds after turning ON ignition switch | x |
| 2 seconds later after turning ON ignition switch | – |
| VDC/TCS function is malfunctioning. | x |
| ABS function is malfunctioning. | x |
| EBD function is malfunctioning. | x |

Component Function Check

INFOID:000000005462912

1.CHECK SLIP INDICATOR LAMP OPERATION

Check that the lamp illuminates for approximately 2 seconds after the ignition switch is turned ON.

Is the inspection result normal?

YES >> Inspection End

NO >> Go to diagnosis procedure. Refer to [BRC-76. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000005462913

1.CHECK SELF-DIAGNOSIS

Perform ABS actuator and electric unit (control unit) self-diagnosis. Refer to [BRC-22. "CONSULT-III Function \(ABS\)"](#).

Is the inspection result normal?

YES >> GO TO 2

NO >> Check items displayed by self-diagnosis.

2.CHECK COMBINATION METER

Check if the indication and operation of combination meter are normal. Refer to [MWI-4. "Work Flow"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-104. "Removal and Installation"](#).

NO >> Repair or replace combination meter. Refer to [MWI-140. "Removal and Installation"](#).

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS >

[VDC/TCS/ABS]

ECU DIAGNOSIS

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Reference Value

INFOID:000000005462914

VALUES ON THE DIAGNOSIS TOOL

CAUTION:

The display shows the control unit calculation data, so a normal value might be displayed even in the event the output circuit (harness) is open or short-circuited.

| Monitor item | Display content | Data monitor | |
|---------------|---|--|-------------------------------------|
| | | Condition | Reference value in normal operation |
| FR LH SENSOR | Wheel speed | 0 [km/h, mph] | Vehicle stopped |
| | | Nearly matches the speed meter display ($\pm 10\%$ or less) | Vehicle running (Note 1) |
| FR RH SENSOR | Wheel speed | 0 [km/h, mph] | Vehicle stopped |
| | | Nearly matches the speed meter display ($\pm 10\%$ or less) | Vehicle running (Note 1) |
| RR LH SENSOR | Wheel speed | 0 [km/h, mph] | Vehicle stopped |
| | | Nearly matches the speed meter display ($\pm 10\%$ or less) | Vehicle running (Note 1) |
| RR RH SENSOR | Wheel speed | 0 [km/h, mph] | Vehicle stopped |
| | | Nearly matches the speed meter display ($\pm 10\%$ or less) | Vehicle running (Note 1) |
| FR LH IN SOL | Operation status of all solenoid valves | Actuator (solenoid valve) is active ("ACTIVE TEST" with CONSULT-III) or actuator relay is inactive (in fail-safe mode) | On |
| | | When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON) | Off |
| FR LH OUT SOL | Operation status of all solenoid valves | Actuator (solenoid valve) is active ("ACTIVE TEST" with CONSULT-III) or actuator relay is inactive (in fail-safe mode) | On |
| | | When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON) | Off |
| FR RH IN SOL | Operation status of all solenoid valves | Actuator (solenoid valve) is active ("ACTIVE TEST" with CONSULT-III) or actuator relay is inactive (in fail-safe mode) | On |
| | | When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON) | Off |
| FR RH OUT SOL | Operation status of all solenoid valves | Actuator (solenoid valve) is active ("ACTIVE TEST" with CONSULT-III) or actuator relay is inactive (in fail-safe mode) | On |
| | | When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON) | Off |
| RR LH IN SOL | Operation status of all solenoid valves | Actuator (solenoid valve) is active ("ACTIVE TEST" with CONSULT-III) or actuator relay is inactive (in fail-safe mode) | On |
| | | When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON) | Off |

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS >

[VDC/TCS/ABS]

| Monitor item | Display content | Data monitor | |
|---------------|---|--|-------------------------------------|
| | | Condition | Reference value in normal operation |
| RR LH OUT SOL | Operation status of all solenoid valves | Actuator (solenoid valve) is active ("ACTIVE TEST" with CONSULT-III) or actuator relay is inactive (in fail-safe mode) | On |
| | | When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON) | Off |
| RR RH IN SOL | Operation status of all solenoid valves | Actuator (solenoid valve) is active ("ACTIVE TEST" with CONSULT-III) or actuator relay is inactive (in fail-safe mode) | On |
| | | When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON) | Off |
| RR RH OUT SOL | Operation status of all solenoid valves | Actuator (solenoid valve) is active ("ACTIVE TEST" with CONSULT-III) or actuator relay is inactive (in fail-safe mode) | On |
| | | When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON) | Off |
| EBD WARN LAMP | EBD warning lamp (Note 2) | When EBD warning lamp is ON | On |
| | | When EBD warning lamp is OFF | Off |
| STOP LAMP SW | Brake pedal operation | When brake pedal is depressed | On |
| | | When brake pedal is not depressed | Off |
| MOTOR RELAY | Motor and motor relay operation | When the motor relay and motor are operating | On |
| | | When the motor relay and motor are not operating | Off |
| ACTUATOR RLY | Actuator relay operation | When the actuator relay is operating | On |
| | | When the actuator relay is not operating | Off |
| ABS WARN LAMP | ABS warning lamp (Note 2) | When ABS warning lamp is ON | On |
| | | When ABS warning lamp is OFF | Off |
| OFF LAMP | VDC OFF indicator lamp (Note 2) | When VDC OFF indicator lamp is ON | On |
| | | When VDC OFF indicator lamp is OFF | Off |
| SLIP LAMP | SLIP indicator lamp (Note 2) | When SLIP indicator lamp is ON | On |
| | | When SLIP indicator lamp is OFF | Off |
| BATTERY VOLT | Battery voltage supplied to the ABS actuator and electric unit (control unit) | Ignition switch ON | 10 – 16 V |
| GEAR | Manual mode gear position determined by TCM | 1st gear 2nd gear 3rd gear 4th gear 5th gear 6th gear | 1 2 3 4 5 6 |
| SLCT LVR POSI | A/T shift position | P position R position N position D position | N/P R N/P D |
| YAW RATE SEN | Yaw rate detected by yaw rate/side G sensor | When vehicle stop | Approx. 0 d/s |
| | | When vehicle turning | -75 to 75 d/s |

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS >

[VDC/TCS/ABS]

| Monitor item | Display content | Data monitor | |
|---------------|--|---|-------------------------------------|
| | | Condition | Reference value in normal operation |
| ACCEL POS SIG | Throttle actuator opening/closing is displayed (linked with accelerator pedal) | Accelerator pedal not depressed (ignition switch is ON) | 0 % |
| | | Depress accelerator pedal (ignition switch is ON) | 0 - 100 % |
| SIDE G-SENSOR | Transverse G detected by side G sensor | Vehicle stopped | Approx. 0 m/s ² |
| | | Vehicle turning right | Negative value (m/s ²) |
| | | Vehicle turning left | Positive value (m/s ²) |
| STR ANGLE SIG | Steering angle detected by steering angle sensor | Straight-ahead | Approx. 0° |
| | | Steering wheel turned | -720 to 720° |
| PRESS SENSOR | Brake fluid pressure detected by pressure sensor | With ignition switch turned ON and brake pedal released | Approx. 0 bar |
| | | With ignition switch turned ON and brake pedal depressed | -40 to 300 bar |
| EBD SIGNAL | EBD operation | EBD is active | On |
| | | EBD is inactive | Off |
| ABS SIGNAL | ABS operation | ABS is active | On |
| | | ABS is inactive | Off |
| TCS SIGNAL | TCS operation | TCS is active | On |
| | | TCS is inactive | Off |
| VDC SIGNAL | VDC operation | VDC is active | On |
| | | VDC is inactive | Off |
| EBD FAIL SIG | EBD fail-safe signal | In EBD fail-safe | On |
| | | EBD is normal | Off |
| ABS FAIL SIG | ABS fail-safe signal | In ABS fail-safe | On |
| | | ABS is normal | Off |
| TCS FAIL SIG | TCS fail-safe signal | In TCS fail-safe | On |
| | | TCS is normal | Off |
| VDC FAIL SIG | VDC fail-safe signal | In VDC fail-safe | On |
| | | VDC is normal | Off |
| CRANKING SIG | Crank operation | Crank is active | On |
| | | Crank is inactive | Off |
| FLUID LEV SW | Brake fluid level switch | When brake fluid level switch ON | On |
| | | When brake fluid level switch OFF | Off |
| PARK BRAKE SW | Parking brake switch | Parking brake switch is active | On |
| | | Parking brake switch is inactive | Off |
| USV[FL-RR] | VDC switch-over valve | When actuator (switch-over valve) is active ("ACTIVE TEST" with CONSULT-III) or actuator relay is inactive (when in fail-safe mode) | On |
| | | When actuator (switch-over valve) is not active and actuator relay is active (ignition switch ON) | Off |

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS >

[VDC/TCS/ABS]

| Monitor item | Display content | Data monitor | |
|--------------|--|---|--|
| | | Condition | Reference value in normal operation |
| USV[FR-RL] | VDC switch-over valve | When actuator (switch-over valve) is active ("ACTIVE TEST" with CONSULT-III) or actuator relay is inactive (when in fail-safe mode) | On |
| | | When actuator (switch-over valve) is not active and actuator relay is active (ignition switch ON) | Off |
| HSV[FL-RR] | VDC switch-over valve | When actuator (switch-over valve) is active ("ACTIVE TEST" with CONSULT-III) or actuator relay is inactive (when in fail-safe mode) | On |
| | | When actuator (switch-over valve) is not active and actuator relay is active (ignition switch ON) | Off |
| HSV[FR-RL] | VDC switch-over valve | When actuator (switch-over valve) is active ("ACTIVE TEST" with CONSULT-III) or actuator relay is inactive (when in fail-safe mode) | On |
| | | When actuator (switch-over valve) is not active and actuator relay is active (ignition switch ON) | Off |
| V/R OUTPUT | Solenoid valve relay activated | When the solenoid valve relay is active (when ignition switch OFF) | On |
| | | When the solenoid valve relay is not active (in the fail-safe mode) | Off |
| M/R OUTPUT | Actuator motor and motor relay activated | When the actuator motor and motor relay are active ("ACTIVE TEST" with CONSULT-III) | On |
| | | When the actuator motor and motor relay are inactive | Off |
| ENGINE RPM | With engine running | With engine stopped | 0 rpm |
| | | Engine running | Almost in accordance with tachometer display |

Note 1: Confirm tire pressure is normal.

Note 2: On and off timing for warning lamp and indicator lamp. Refer to [BRC-10. "System Description"](#).

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)


< ECU DIAGNOSIS >

[VDC/TCS/ABS]

Wiring Diagram - BRAKE CONTROL SYSTEM -

INFOID:000000005462915

BRAKE CONTROL SYSTEM




ABFWA0002GE

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS >

[VDC/TCS/ABS]



ABFWA0096GE


ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS >

[VDC/TCS/ABS]


BRAKE CONTROL SYSTEM CONNECTORS

| | |
|-----------------|--------------|
| Connector No. | M1 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 8G | P | - |
| 15G | L | - |
| 24G | G/R | - |
| 31G | V | - |
| 34G | O | - |
| 67G | GR | - |
| 70G | Y | - |
| 75G | SB | - |
| 77G | Y/B | - |

| | |
|-----------------|------------------|
| Connector No. | M5 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 12M | O | - |

| | |
|-----------------|---------------------|
| Connector No. | M22 |
| Connector Name | DATA LINK CONNECTOR |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 7 | O | - |

| | |
|-----------------|-------------------|
| Connector No. | M24 |
| Connector Name | COMBINATION METER |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---------------|
| 2 | O | IGN |
| 3 | B | GND (POWER) |
| 21 | L | CAN-H |
| 22 | P | CAN-L |
| 23 | B | GND (CIRCUIT) |
| 26 | G/R | PKB |
| 27 | V | BRAKE OIL IN |

| | |
|-----------------|-----------------------|
| Connector No. | M53 |
| Connector Name | STEERING ANGLE SENSOR |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---------------------------|
| 1 | B | STEERING ANGLE SENS GND |
| 2 | P | CAN-L |
| 4 | O | STEERING ANGLE SENS POWER |
| 5 | L | CAN-H |

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS >


[VDC/TCS/ABS]

| | |
|-----------------|------------------|
| Connector No. | E6 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1P | SB | - |
| 2P | LG | - |
| 8P | R | - |

| | |
|-----------------|----------------|
| Connector No. | M72 |
| Connector Name | VDC OFF SWITCH |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | SB | - |
| 2 | B | - |

| | |
|-----------------|------------------------------|
| Connector No. | M55 |
| Connector Name | YAW RATE/SIDE/DECEL G SENSOR |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | B | GND |
| 2 | Y/B | CAN-L |
| 3 | Y | CAN-H |
| 4 | GR | IG |


| | |
|-----------------|-----------------------|
| Connector No. | E19 |
| Connector Name | FRONT WHEEL SENSOR LH |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | W | POWER |
| 2 | V | SIG |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 25 | GR | ABS ECU |

| | |
|-----------------|--|
| Connector No. | E18 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | WHITE |



ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS >

[VDC/TCS/ABS]

| | |
|-----------------|---------------------|
| Connector No. | E21 |
| Connector Name | JOINT CONNECTOR-E03 |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | - |
| 4 | L | - |

| | |
|-----------------|---------------------|
| Connector No. | E22 |
| Connector Name | JOINT CONNECTOR-E04 |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | P | - |
| 4 | P | - |

| | |
|-----------------|--------------------------|
| Connector No. | E24 |
| Connector Name | BRAKE FLUID LEVEL SWITCH |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | V | - |
| 2 | BY | - |

| | |
|-----------------|---|
| Connector No. | E26 |
| Connector Name | ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | B | MGND |
| 2 | G | UB (MR) |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3 | R | UB (VR) |
| 4 | B | GND |
| 5 | V | DS FL |
| 6 | G | DP RL |
| 7 | - | - |
| 8 | L | DP RR |
| 9 | B | DP FR |
| 10 | LG | DS FR |
| 11 | GR | DIAG-K |
| 12 | - | - |
| 13 | - | - |
| 14 | O | CAN-M2 |
| 15 | P | CAN-L |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 16 | W | DP FL |
| 17 | O | DS RL |
| 18 | GR | UZ |
| 19 | BR | DS RR |
| 20 | SB | BLS |
| 21 | R | VDC OFF SW |
| 22 | - | - |
| 23 | - | - |
| 24 | - | - |
| 25 | B | CAN-P2 |
| 26 | L | CAN-H |

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P


ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS >


[VDC/TCS/ABS]

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 8G | P | - |
| 15G | L | - |
| 24G | P | - |
| 31G | V | - |
| 34G | O | - |
| 67G | W | - |
| 70G | B | - |
| 75G | R | - |
| 77G | SB | - |

| | |
|-----------------|--------------|
| Connector No. | E30 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| | |
|-----------------|--------------|
| Connector No. | E29 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 4 | O | - |
| 5 | BR | - |
| 13 | G | - |
| 14 | L | - |

| | |
|-----------------|-----------------------|
| Connector No. | E41 |
| Connector Name | FRONT WHEEL SENSOR RH |
| Connector Color | GRAY |



| | |
|-----------------|------------------|
| Connector No. | E38 |
| Connector Name | STOP LAMP SWITCH |
| Connector Color | WHITE |



| | |
|-----------------|----------------------|
| Connector No. | E35 |
| Connector Name | PARKING BRAKE SWITCH |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | B | POWER |
| 2 | LG | SIG |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3 | R | - |
| 4 | LG | - |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | P | - |


ABFIA0262GB

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS >

[VDC/TCS/ABS]

| | |
|-----------------|----------------|
| Connector No. | E47 |
| Connector Name | JUNCTION BLOCK |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 41 | GR | - |

| | |
|-----------------|----------------|
| Connector No. | E46 |
| Connector Name | JUNCTION BLOCK |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 26 | GR | - |
| 31 | O | - |
| 39 | SB | - |

| | |
|-----------------|----------------|
| Connector No. | E44 |
| Connector Name | JUNCTION BLOCK |
| Connector Color | BROWN |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 10 | SB | - |

| | |
|-----------------|----------------------|
| Connector No. | C2 |
| Connector Name | REAR WHEEL SENSOR RH |
| Connector Color | GRAY |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | LG | POWER RH |
| 2 | BR | SIG RH |

| | |
|-----------------|----------------------|
| Connector No. | C1 |
| Connector Name | REAR WHEEL SENSOR LH |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | G | POWER LH |
| 2 | O | SIG LH |

| | |
|-----------------|----------------|
| Connector No. | E49 |
| Connector Name | JUNCTION BLOCK |
| Connector Color | BROWN |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 53 | W | - |
| 54 | GR | - |

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

ABFIA0263GB

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS >


[VDC/TCS/ABS]

| | |
|-----------------|--------------|
| Connector No. | B31 |
| Connector Name | WIRE TO WIRE |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | O | - |
| 2 | G | - |
| 3 | BR | - |
| 4 | LG | - |

| | |
|-----------------|--------------|
| Connector No. | B10 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 4 | O | - |
| 5 | BR | - |
| 13 | G | - |
| 14 | LG | - |

| | |
|-----------------|--------------|
| Connector No. | C5 |
| Connector Name | WIRE TO WIRE |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | O | - |
| 2 | G | - |
| 3 | BR | - |
| 4 | LG | - |

ABFIA0264GB

INFOID:000000005462916

Fail-Safe

CAUTION:

If the Fail-Safe function is activated, perform self-diagnosis for VDC/TCS/ABS system.

ABS, EBD SYSTEM

In case of an electrical malfunction with the ABS, ABS warning lamp, VDC OFF indicator lamp, SLIP indicator lamp will turn on. In case of an electrical malfunction with the EBD system, brake warning lamp, ABS warning

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

[VDC/TCS/ABS]

< ECU DIAGNOSIS >

lamp, VDC OFF indicator lamp and SLIP indicator lamp will turn on. The system will revert to one of the following conditions of the fail-safe function.

- For ABS malfunction, only the EBD is operative and the condition of vehicle is the same condition of vehicles without VDC/TCS/ABS system.
- For EBD malfunction, the EBD and ABS become inoperative, and the condition of vehicle is the same as the condition of vehicles without VDC/TCS/ABS or EBD system.

VDC / TCS

In case of VDC/TCS system malfunction, VDC OFF indicator lamp, SLIP indicator lamp are turned on, and the condition of vehicle is the same as the condition of vehicles without VDC/TCS system. In case of an electrical malfunction with the VDC/TCS system, the ABS control continues to operate normally without VDC/TCS control.

DTC No. Index

INFOID:000000005462917

| DTC | Items (CONSULT-III screen terms) | Reference |
|-------|----------------------------------|---------------------------------------|
| C1101 | RR RH SENSOR-1 | BRC-27. "Description" |
| C1102 | RR LH SENSOR-1 | |
| C1103 | FR RH SENSOR-1 | |
| C1104 | FR LH SENSOR-1 | |
| C1105 | RR RH SENSOR-2 | BRC-30. "Description" |
| C1106 | RR LH SENSOR-2 | |
| C1107 | FR RH SENSOR-2 | |
| C1108 | FR LH SENSOR- 2 | |
| C1109 | BATTERY VOLTAGE [ABNORMAL] | BRC-33. "Description" |
| C1110 | CONTROLLER FAILURE | BRC-35. "DTC Logic" |
| C1111 | PUMP MOTOR | BRC-36. "Description" |
| C1114 | MAIN RELAY | BRC-38. "Description" |
| C1115 | ABS SENSOR [ABNORMAL SIGNAL] | BRC-40. "Description" |
| C1116 | STOP LAMP SW | BRC-43. "Description" |
| C1120 | FR LH IN ABS SOL | BRC-45. "Description" |
| C1122 | FR RH IN ABS SOL | |
| C1124 | RR LH IN ABS SOL | |
| C1126 | RR RH IN ABS SOL | |
| C1121 | FR LH OUT ABS SOL | BRC-48. "Description" |
| C1123 | FR RH OUT ABS SOL | |
| C1125 | RR LH OUT ABS SOL | |
| C1127 | RR RH OUT ABS SOL | |
| C1130 | ENGINE SIGNAL 1 | BRC-51. "Description" |
| C1131 | ENGINE SIGNAL 2 | |
| C1132 | ENGINE SIGNAL 3 | |
| C1133 | ENGINE SIGNAL 4 | |
| C1136 | ENGINE SIGNAL 6 | BRC-52. "Description" |
| C1142 | PRESS SEN CIRCUIT | |
| C1143 | ST ANG SEN CIRCUIT | BRC-55. "Description" |
| C1144 | ST ANG SEN SIGNAL | |
| C1145 | YAW RATE SENSOR | BRC-57. "Description" |
| C1146 | SIDE G-SEN CIRCUIT | |

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS >

[VDC/TCS/ABS]

| DTC | Items (CONSULT-III screen terms) | Reference |
|-------|----------------------------------|---------------------------------------|
| C1147 | USV LINE [FL-RR] | BRC-60. "Description" |
| C1148 | USV LINE [FR-RL] | |
| C1149 | HSV LINE [FL-RR] | |
| C1150 | HSV LINE [FR-RL] | |
| C1153 | EMERGENCY BRAKE | BRC-35. "DTC Logic" |
| C1154 | PNP POS SIG | BRC-63. "Description" |
| C1155 | BR FLUID LEVEL LOW | BRC-65. "Description" |
| C1156 | ST ANG SEN COM CIR | BRC-67. "Description" |
| C1170 | VARIANT CODING | BRC-35. "DTC Logic" |
| U1000 | CAN COMM CIRCUIT | BRC-68. "Description" |

SYMPTOM DIAGNOSIS

VDC/TCS/ABS

Symptom Table

INFOID:000000005462918

If ABS warning lamp, VDC OFF indicator lamp and SLIP indicator lamp turn ON, perform self-diagnosis.

| Symptom | Check item | Reference |
|--|--|---|
| Excessive ABS function operation frequency | Brake force distribution | BRC-92, "Diagnosis Procedure" |
| | Looseness of front and rear axle | |
| | Wheel sensor and rotor system | |
| Unexpected pedal reaction | Brake pedal stroke | BRC-93, "Diagnosis Procedure" |
| | Make sure the braking force is sufficient when the ABS is not operating. | |
| The braking distance is long | Check stopping distance when the ABS is not operating. | BRC-94, "Diagnosis Procedure" |
| ABS function does not operate (Note 1) | ABS actuator and electric unit (control unit) | BRC-95, "Diagnosis Procedure" |
| Pedal vibration or ABS operation sound occurs (Note 2) | Brake pedal | BRC-96, "Diagnosis Procedure" |
| | ABS actuator and electric unit (control unit) | |
| Vehicle jerks during VDC/TCS/ABS control | ABS actuator and electric unit (control unit) | BRC-97, "Diagnosis Procedure" |
| | TCM | |
| | ECM | |

NOTE:

- 1: The ABS does not operate when the speed is 10 km/h (6 MPH) or less.
- 2: Under the following conditions, ABS is activated and vibration is felt when brake pedal is lightly depressed (just place a foot on it). However, this is normal.
 - When shifting gears
 - When driving on slippery road
 - During cornering at high speed
 - When passing over bumps or grooves [at approximately 50 mm (1.97 in) or more]
 - When pulling away just after starting engine [at approximately 10 km/h (6 MPH) or higher]

EXCESSIVE ABS FUNCTION OPERATION FREQUENCY

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

EXCESSIVE ABS FUNCTION OPERATION FREQUENCY

Diagnosis Procedure

INFOID:000000005462919

1. CHECK START

Check front and rear brake force distribution using a brake tester.

Is the inspection result normal?

- YES >> GO TO 2
- NO >> Check brake system.

2. CHECK FRONT AND REAR AXLE

Make sure that there is no excessive play in the front and rear axles. Refer to front: [FAX-6. "Inspection"](#), rear: [RAX-6. "On-vehicle Service"](#).

Is the inspection result normal?

- YES >> GO TO 3
- NO >> Repair or replace malfunctioning components.

3. CHECK WHEEL SENSOR AND SENSOR ROTOR

Check the following.

- Wheel sensor installation for damage.
- Sensor rotor installation for damage.
- Wheel sensor connector connection.
- Wheel sensor harness inspection.

Is the inspection result normal?

- YES >> GO TO 4
- NO >> • Replace wheel sensor or sensor rotor. Refer to [BRC-101. "Removal and Installation"](#).
 - Repair harness.

4. CHECK ABS WARNING LAMP DISPLAY

Make sure that the ABS warning lamp is turned off after the ignition switch is turned ON or when driving.

Is the inspection result normal?

- YES >> Normal
- NO >> Perform self-diagnosis. Refer to [BRC-22. "CONSULT-III Function \(ABS\)"](#).

UNEXPECTED PEDAL REACTION

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

UNEXPECTED PEDAL REACTION

Diagnosis Procedure

INFOID:000000005462920

1.CHECK BRAKE PEDAL STROKE

Check brake pedal stroke. Refer to [BR-14, "Inspection and Adjustment"](#).

Is the stroke too big?

- YES >> • Bleed air from brake tube and hose. Refer to [BR-16, "Bleeding Brake System"](#).
• Check brake pedal, brake booster, and master cylinder for mount play, looseness, brake system fluid leakage, etc. Refer to brake pedal [BR-14, "Inspection and Adjustment"](#), brake booster [BR-9, "Inspection"](#) and master cylinder [BR-11, "Inspection"](#).

NO >> GO TO 2

2.CHECK FUNCTION

Disconnect ABS actuator and electric unit (control unit) connector to deactivate ABS. Check if braking force is normal in this condition. Connect connector after inspection.

Is the inspection result normal?

YES >> GO TO procedure 3 "CHECK WHEEL SENSOR AND SENSOR ROTOR" of symptom 1. Refer to [BRC-92, "Diagnosis Procedure"](#).

NO >> Check brake system.

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

THE BRAKING DISTANCE IS LONG

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

THE BRAKING DISTANCE IS LONG

Diagnosis Procedure

INFOID:000000005462921

CAUTION:

The stopping distance on slippery road surfaces might be longer with the ABS operating than when the ABS is not operating.

1. CHECK FUNCTION

Turn ignition switch OFF and disconnect ABS actuator and electric unit (control unit) connector to deactivate ABS. In this condition, check stopping distance. After inspection, connect connector.

Is the inspection result normal?

- YES >> GO TO procedure "CHECK WHEEL SENSOR AND SENSOR ROTOR" of symptom. Refer to [BRC-92. "Diagnosis Procedure"](#).
- NO >> Check brake system.

ABS FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

ABS FUNCTION DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000005462922

CAUTION:

ABS does not operate when speed is 10 km/h (6 MPH) or lower.

1.CHECK ABS WARNING LAMP DISPLAY

Make sure that the ABS warning lamp turns OFF after ignition switch is turned on or when driving.

Is the inspection result normal?

YES >> GO TO procedure "CHECK WHEEL SENSOR AND SENSOR ROTOR" of symptom. Refer to [BRC-92, "Diagnosis Procedure"](#).

NO >> Perform self-diagnosis. Refer to [BRC-22, "CONSULT-III Function \(ABS\)"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

BRC

PEDAL VIBRATION OR ABS OPERATION SOUND OCCURS

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

PEDAL VIBRATION OR ABS OPERATION SOUND OCCURS

Diagnosis Procedure

INFOID:000000005462923

CAUTION:

Under the following conditions, ABS is activated and vibration is felt when brake pedal is lightly depressed (just place a foot on it). However, this is normal.

- When shifting gears
- When driving on slippery road
- During cornering at high speed
- When passing over bumps or grooves [at approximately 50 mm (1.97 in) or more]
- When pulling away just after starting engine [at approximately 10 km/h (6 MPH) or higher]

1. SYMPTOM CHECK 1

Check if there is pedal vibration or operation sound when the engine is started.

Do symptoms occur?

YES >> GO TO 2

NO >> Perform self-diagnosis. Refer to [BRC-22, "CONSULT-III Function \(ABS\)"](#).

2. SYMPTOM CHECK 2

Check symptoms when electrical component (headlamps, etc.) switches are operated.

Do symptoms occur?

YES >> Check if there is a radio, antenna, antenna lead wire, or wiring close to the control unit. If there is, move it farther away.

NO >> GO TO procedure "CHECK WHEEL SENSOR AND SENSOR ROTOR" of symptom. Refer to [BRC-92, "Diagnosis Procedure"](#).

VEHICLE JERKS DURING VDC/TCS/ABS CONTROL

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

VEHICLE JERKS DURING VDC/TCS/ABS CONTROL

Diagnosis Procedure

INFOID:000000005462924

1.SYMPTOM CHECK

Check if the vehicle jerks during VDC/TCS/ABS control.

Is the inspection result normal?

- YES >> Normal.
- NO >> GO TO 2

2.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnostic of ABS actuator and electric unit (control unit).

Are self-diagnosis results indicated?

- YES >> Check corresponding items, make repairs, and perform ABS actuator and electric unit (control unit) self-diagnosis.
- NO >> GO TO 3

3.CHECK CONNECTOR

- Turn ignition switch OFF and disconnect ABS actuator and electric unit (control unit) connector and check terminal for deformation, disconnection, looseness, etc.
- Securely connect connector and perform ABS actuator and electric unit (control unit) self-diagnosis.

Are self-diagnosis results indicated?

- YES >> If poor contact, damage, open or short circuit of connector terminal is found, repair or replace.
- NO >> GO TO 4

4.CHECK ECM AND A/T SELF-DIAGNOSIS RESULTS

Perform ECM and CVT self-diagnosis.

Are self-diagnosis results indicated?

- YES >> Check the corresponding items.
 - ECM: Refer to [EC-126, "CONSULT-III Function"](#).
 - CVT: Refer to [TM-36, "CONSULT-III Function \(TRANSMISSION\)"](#).
- NO >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-104, "Removal and Installation"](#).

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000005462925

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precautions Necessary for Steering Wheel Rotation after Battery Disconnect (Early Production, With Electronic Steering Column Lock)

INFOID:000000005885915

NOTE:

- Before removing and installing any control units, first turn the push-button ignition switch to the LOCK position, then disconnect both battery cables.
- After finishing work, confirm that all control unit connectors are connected properly, then re-connect both battery cables.
- Always use CONSULT-III to perform self-diagnosis as a part of each function inspection after finishing work. If a DTC is detected, perform trouble diagnosis according to self-diagnosis results.

This vehicle is equipped with a push-button ignition switch and a steering lock unit.

If the battery is disconnected or discharged, the steering wheel will lock and cannot be turned.

If turning the steering wheel is required with the battery disconnected or discharged, follow the procedure below before starting the repair operation.

OPERATION PROCEDURE

1. Connect both battery cables.

NOTE:

Supply power using jumper cables if battery is discharged.

2. Carry the Intelligent Key or insert it to the key slot and turn the push-button ignition switch to ACC position. (At this time, the steering lock will be released.)
3. Disconnect both battery cables. The steering lock will remain released with both battery cables disconnected and the steering wheel can be turned.
4. Perform the necessary repair operation.

PRECAUTIONS

[VDC/TCS/ABS]

< PRECAUTION >

5. When the repair work is completed, re-connect both battery cables. With the brake pedal released, turn the push-button ignition switch from ACC position to ON position, then to LOCK position. (The steering wheel will lock when the push-button ignition switch is turned to LOCK position.)
6. Perform self-diagnosis check of all control units using CONSULT-III.


Precaution for Brake System

INFOID:000000005462927

- Always use recommended brake fluid. Refer to [MA-18. "FOR NORTH AMERICA : Fluids and Lubricants"](#) (for North America) or [MA-19. "FOR MEXICO : Fluids and Lubricants"](#) (for Mexico).
- Never reuse drained brake fluid.
- Be careful not to splash brake fluid on painted surface of body. If brake fluid is splashed on painted surfaces of body immediately wipe off with cloth and then wash it away with water.
- Never use mineral oils such as gasoline or kerosene. They will ruin rubber parts of the hydraulic system.
- Use a flare nut wrench when removing flare nuts, and use a flare nut torque wrench when tighten brake tube flare nuts.
- When installing brake tubes, be sure to check torque.
- Brake system is an important safety part. If a brake fluid leak is detected, always disassemble the affected part. If a malfunction is detected, replace part with a new one.
- Before working, turn ignition switch OFF and disconnect connectors of ABS actuator and electric unit (control unit) or the battery cable from the negative terminal.

WARNING:

Clean brake pads and shoes with a waste cloth, then wipe with a dust collector.



Precaution for Brake Control

INFOID:000000005462928

- Just after starting vehicle with ignition switch ON, brake pedal may vibrate or motor operating noise may be heard from engine compartment. This is normal condition.
- When an error is indicated by ABS or another warning lamp, collect all necessary information from customer (what symptoms are present under what conditions) and check for simple causes before starting diagnostic servicing. Besides electrical system inspection, check brake booster operation, brake fluid level, and oil leaks.
- If tire size and type are used in an improper combination, or brake pads are not Genuine NISSAN parts, stopping distance or steering stability may deteriorate.
- ABS might be out of order or malfunctions by putting a radio (wiring inclusive), an antenna and a lead-in wire near the control unit.
- If aftermarket parts (car stereo, CD player, etc.) have been installed, check for incidents such as harness pinches, open circuits, and improper wiring.
- VDC system may not operate normally or a VDC OFF indicator lamp or SLIP indicator lamp may light.
- When replacing the following parts with parts other than genuine parts or making modifications: Suspension-related parts (shock absorber, spring, bushing, etc.), tires, wheels (other than specified sizes), brake-related parts (pad, rotor, caliper, etc.), engine-related parts (muffler, ECM, etc.) and body reinforcement-related parts (roll bar, tower bar, etc.).
- When driving with worn or deteriorated suspension, tires and brake-related parts.

PREPARATION

< PREPARATION >

[VDC/TCS/ABS]


PREPARATION

PREPARATION

Special Service Tool


INFOID:000000005462929

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

| Tool number (Kent-Moore No.) Tool name | Description |
|--|--|
| <p>— (J-45741) ABS active wheel sensor tester</p>  <p style="text-align: right;">WFA0101E</p> | <p>Checking operation of ABS active wheel sensor</p> |

Commercial Service Tool

INFOID:000000005462930


| Tool name | Description |
|--|---|
| <p>1. Flare nut crowfoot 2. Torque wrench</p>  <p style="text-align: right;">S-NT360</p> | <p>Removing and installing brake piping a: 10mm (0.39 in)/12mm (0.47 in)</p> |

ON-VEHICLE REPAIR

WHEEL SENSORS

Removal and Installation

INFOID:000000005462931



1. Front wheel sensor 2. Rear wheel sensor ← Front

CAUTION:

- Be careful not to damage wheel sensor edge and sensor rotor teeth.
- When pulling out the wheel sensor, be careful to turn it as little as possible. Do not pull on the wheel sensor harness.
- Check if foreign objects such as iron fragments are adhered to the pick-up part of the sensor or to the inside of the hole for the wheel sensor, or if a foreign object is caught in the surface of the mating surface for the wheel sensor. Repair as necessary and then install the wheel sensor.

FRONT WHEEL SENSOR

Removal

1. Remove the front wheel and tire. Refer to [WT-63, "Adjustment"](#).
2. Partially remove front wheel fender protector and reposition out of the way. Refer to [EXT-20, "Removal and Installation"](#).
3. Disconnect the wheel sensor harness connector.
4. Remove the wheel sensor harness from the brackets.
5. Remove the wheel sensor bolt and wheel sensor from the front hub assembly.

Installation

Installation is in the reverse order of removal.

REAR WHEEL SENSOR

Removal

1. Remove the rear wheel and tire. Refer to [WT-63, "Adjustment"](#).


A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

WHEEL SENSORS

[VDC/TCS/ABS]

< ON-VEHICLE REPAIR >

2. Remove the stabilizer bar clamps and bushings using power tool, and reposition the stabilizer bar out of the way.



3. Disconnect the wheel sensor harness connector.
4. Remove the wheel sensor harness from the brackets.
5. Remove the wheel sensor bolt and wheel sensor from the rear hub assembly.

Installation

Installation is in the reverse order of removal.

SENSOR ROTOR

Removal and Installation

INFOID:000000005462932

The front and rear wheel sensor rotors are an integral part of the wheel hub assemblies and cannot be disassembled. To replace the sensor rotor, replace the wheel hub assembly. Refer to [FAX-8. "Removal and Installation"](#) (Front), [RAX-7. "Removal and Installation"](#) (Rear).

- A
- B
- C
- D
- E
- BRC**
- G
- H
- I
- J
- K
- L
- M
- N
- O
- P

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)


< ON-VEHICLE REPAIR >

[VDC/TCS/ABS]

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Exploded View

INFOID:000000005462933



- | | | |
|--|------------------------------|--|
| 1. From master cylinder secondary side | 2. Grommet | 3. ABS actuator and electric unit (control unit) bracket |
| 4. From master cylinder primary side | 5. To front LH brake caliper | 6. To rear RH brake caliper |
| 7. To rear LH brake caliper | 8. To front RH brake caliper | 9. ABS actuator and electric unit (control unit) |

⇐ Front

Removal and Installation

INFOID:000000005462934

CAUTION:

- Before removal, disconnect the battery negative terminal.
- To disconnect the brake tubes, use a flare nut wrench to prevent the flare nuts and brake tubes from being damaged. To connect the brake tubes, use a flare nut torque wrench to tighten to the specified torque.
- Do not drop the ABS actuator and electric unit (control unit).
- Do not remove and install the ABS actuator and electric unit (control unit) by holding it by the harness.
- After installation, bleed the air from the brake lines. Refer to [BR-16, "Bleeding Brake System"](#).

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ON-VEHICLE REPAIR >

[VDC/TCS/ABS]

REMOVAL

1. Disconnect the battery negative terminal. A
2. Drain the brake fluid. Refer to [BR-16, "Drain and Refill"](#).
CAUTION:
Do not reuse the brake fluid. B
3. Remove the front wiper arms. Refer to [WW-95, "FRONT WIPER ARMS : Removal and Installation"](#). C
4. Remove the cowl top and RH cowl top extension. Refer to [EXT-18, "Removal and Installation"](#). C
5. Disconnect the wiper washer hose. C
6. Remove the tower bar. Refer to [FSU-15, "Exploded View"](#). D
7. Disconnect the ABS actuator and electric unit (control unit) connector. D
8. Loosen the brake tube flare nuts, then disconnect the brake tubes from the ABS actuator and electric unit (control unit). E
9. Remove the ABS actuator and electric unit (control unit) nuts. E
10. Remove the ABS actuator and electric unit (control unit). E
11. Remove the ABS actuator and electric unit (control unit) bracket as necessary. E

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

Perform the neutral position adjustment for the steering angle sensor. Refer to [BRC-8, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#). G

BRC

H
I
J
K
L
M
N
O
P

G SENSOR

< ON-VEHICLE REPAIR >

[VDC/TCS/ABS]

G SENSOR

Removal and Installation


INFOID:000000005462935

CAUTION:

- Do not drop or strike the yaw rate/side G sensor to prevent damage.
- Do not use power tool to remove the yaw rate/side G sensor to prevent damage.

REMOVAL

1. Remove the center console. Refer to [IP-16, "Removal and Installation"](#).
2. Disconnect the yaw rate/side G sensor connector.
3. Remove the yaw rate/side G sensor nuts.
 - ⇐: Front
4. Remove the yaw rate/side G sensor.



INSTALLATION

Installation is in the reverse order of removal.

STEERING ANGLE SENSOR

< ON-VEHICLE REPAIR >

[VDC/TCS/ABS]


STEERING ANGLE SENSOR

Removal and Installation

INFOID:000000005462936

REMOVAL

1. Remove the spiral cable. Refer to [SR-8. "Removal and Installation"](#).
2. Remove the screws (A) and release the clips (B) to remove the steering angle sensor (1) from the spiral cable (2).



INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

Perform the neutral position adjustment for the steering angle sensor. Refer to [BRC-8. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P