

**SECTION** SN  
**SONAR SYSTEM**

A  
 B  
 C  
 D  
 E  
 F  
 G  
 H  
 I  
 J  
 K  
 L  
 M  
 SN  
 O  
 P

**CONTENTS**

<b>PRECAUTION</b> .....	3	<b>Work Flow</b> .....	22
<b>PRECAUTION</b> .....	3	<b>INSPECTION AND ADJUSTMENT</b> .....	24
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	3	<b>ADDITIONAL SERVICE WHEN REPLACING SONAR CONTROL UNIT</b> .....	24
Precaution for Work .....	3	ADDITIONAL SERVICE WHEN REPLACING SONAR CONTROL UNIT : Description .....	24
<b>PREPARATION</b> .....	4	ADDITIONAL SERVICE WHEN REPLACING SONAR CONTROL UNIT : Work Procedure .....	24
<b>PREPARATION</b> .....	4	<b>CONFIGURATION (SONAR CONTROL UNIT)</b> .....	24
Special Service Tool .....	4	CONFIGURATION (SONAR CONTROL UNIT) : Description .....	25
<b>SYSTEM DESCRIPTION</b> .....	5	CONFIGURATION (SONAR CONTROL UNIT) : Work Procedure .....	25
<b>COMPONENT PARTS</b> .....	5	CONFIGURATION (SONAR CONTROL UNIT) : Configuration List .....	26
Component Parts Location .....	5	<b>DTC/CIRCUIT DIAGNOSIS</b> .....	27
Component Description .....	5	<b>U1000 CAN COMM CIRCUIT</b> .....	27
Sonar Control Unit .....	5	DTC Description .....	27
Sonar Sensor .....	6	Diagnosis Procedure .....	27
<b>SYSTEM</b> .....	7	<b>U1010 CONTROL UNIT (CAN)</b> .....	28
System Diagram .....	7	DTC Description .....	28
System Description .....	7	Diagnosis Procedure .....	28
<b>DIAGNOSIS SYSTEM (SONAR CONTROL UNIT)</b> .....	10	<b>B2720 CORNER SENSOR [RL]</b> .....	29
CONSULT Function .....	10	DTC Logic .....	29
<b>ECU DIAGNOSIS INFORMATION</b> .....	13	Diagnosis Procedure .....	29
<b>SONAR CONTROL UNIT</b> .....	13	<b>B2723 CORNER SENSOR [RR]</b> .....	31
Reference Value .....	13	DTC Logic .....	31
DTC Index .....	16	Diagnosis Procedure .....	31
<b>WIRING DIAGRAM</b> .....	17	<b>B2724 SONAR CONTROL UNIT</b> .....	33
<b>SONAR SYSTEM</b> .....	17	DTC Description .....	33
Wiring Diagram .....	17	Diagnosis Procedure .....	33
<b>BASIC INSPECTION</b> .....	22	<b>B2729 CORNER SENSOR [FL]</b> .....	34
<b>DIAGNOSIS AND REPAIR WORKFLOW</b> .....	22	DTC Logic .....	34

Diagnosis Procedure .....	34	<b>REMOVAL AND INSTALLATION .....</b>	<b>40</b>
<b>B272C CORNER SENSOR [FR] .....</b>	<b>36</b>	<b>SONAR SENSOR .....</b>	<b>40</b>
DTC Logic .....	36	Removal and Installation - Front Sonar Sensors ...	40
Diagnosis Procedure .....	36	Removal and Installation - Rear Sonar Sensors ....	40
<b>POWER SUPPLY AND GROUND CIRCUIT ....</b>	<b>38</b>	<b>SONAR CONTROL UNIT .....</b>	<b>41</b>
Diagnosis Procedure .....	38	Removal and Installation .....	41
<b>SYMPTOM DIAGNOSIS .....</b>	<b>39</b>	<b>BUZZER .....</b>	<b>42</b>
<b>SONAR SYSTEM .....</b>	<b>39</b>	Removal and Installation .....	42
Symptom Table .....	39		

# PRECAUTION

< PRECAUTION >

## PRECAUTION

### PRECAUTION

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000011978493

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

#### Precaution for Work

INFOID:000000011978495

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
  - Water soluble dirt:
    - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
    - Then rub with a soft, dry cloth.
  - Oily dirt:
    - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
    - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
    - Then rub with a soft, dry cloth.
  - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
  - For genuine leather seats, use a genuine leather seat cleaner.

# PREPARATION

< PREPARATION >

## PREPARATION


### PREPARATION

#### Special Service Tool

INFOID:000000011978496

The actual shape of the tools may differ from those illustrated here.

Tool number (TechMate No.) Tool name	Description
— (J-46534) Trim Tool Set	Removing trim components



AWJIA0483ZZ

# COMPONENT PARTS


< SYSTEM DESCRIPTION >

## SYSTEM DESCRIPTION

### COMPONENT PARTS

#### Component Parts Location

INFOID:0000000011978497



#### Component Description

INFOID:0000000011978498

No.	Component	Function
1.	Rear sonar sensor RH outer	Senses objects in rear of vehicle
2.	Front sonar sensor RH outer	Senses objects in front of vehicle
3.	Front sonar sensor LH outer	Senses objects in front of vehicle
4.	Sonar control unit	Controls sonar system and provides self-diagnosis
5.	AV control unit	Receives buzzer signal, and transmits to speakers. Refer to <a href="#">AV-13. "AV Control Unit"</a>
6.	Rear sonar sensor LH outer	Senses objects in rear of vehicle


#### Sonar Control Unit

INFOID:0000000012282832


- The sonar control unit is installed at the lower dash.
- Necessary signals are transmitted/received to/from control unit via CAN communication.
- Sonar sensor signals received from each sensor are received in the sonar control unit and transmitted to the AV control unit.

# COMPONENT PARTS

< SYSTEM DESCRIPTION >



Shown without driver assistance system




Shown with driver assistance system

## Sonar Sensor

INFOID:000000012282496

- When a distance from an obstacle is detected, a buzzer signal is transmitted to the sonar control unit.




# SYSTEM

< SYSTEM DESCRIPTION >

## SYSTEM

### System Diagram



### System Description

INFOID:0000000011978500

#### SYSTEM OPERATION DESCRIPTION

- Sonar sensors transmit a sensor signal to sonar control unit when detecting an obstacle, sonar control unit converts signal into a detection distance signal and transmits it to AV control unit via CAN communication.
- Combination meter operates sonar display in vehicle information display.
- Sonar control unit is capable of self diagnosis. It can detect sensor malfunction or sensor harness open circuits.

#### OBSTACLE DETECTION DISTANCE

- Sonar control unit changes output of sonar display and warning buzzers in 3 stages according to obstacle detection distance from corner sensors.
- Sonar control unit changes setting of obstacle detection distance in 4 stages.


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

SN

# SYSTEM

## < SYSTEM DESCRIPTION >

### Obstacle detection image



A. Approx. 50 cm (19.6 in)

B. Approx. 15 cm (5.9 in)

#### Detection distance

Warning item	Sensitivity level 1 (Fastest warning)	Sensitivity level 2 (Faster warning)	Sensitivity level 3 (Default value)	Sensitivity level 4 (Slower warning)
First stage warning	70 – 80 cm (27.5 – 31.4 in)	60 – 70 cm (23.6 – 27.5 in)	50 – 60 cm (19.6 – 23.6 in)	40 – 50 cm (15.7 – 19.6 in)
Second stage warning	50 – 70 cm (19.6 – 27.5 in)	40 – 60 cm (15.7 – 23.6 in)	30 – 50 cm (11.8 – 19.6 in)	30 – 40 cm (11.8 – 15.7 in)
Third stage warning	Less than 50 cm (19.6 in)	Less than 40 cm (15.7 in)	Less than 30 cm (11.8 in)	Less than 30 cm (11.8 in)

#### SONAR DISPLAY


- Combination meter receives detection distance signal via CAN communication from sonar control unit.
- Combination meter operates the sonar display in vehicle information display.
- Combination meter changes color and blinking cycle of display according to detection distance.



# SYSTEM

## < SYSTEM DESCRIPTION >


### Color and blinking cycle of sonar indicator



### SONAR BUZZER OPERATION

- Sonar sensors transmit a sensor signal to sonar control unit when detecting an obstacle.
- Sonar control unit converts signal received from each sensor into distance and transmits detection distance signal to combination meter via CAN communication.
- Sonar control unit transmits a buzzer signal to AV control unit.
- Sonar control unit changes buzzer cycle in 3 stages according to detection distance.

### Sonar buzzer cycle



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
SN  
O  
P

# DIAGNOSIS SYSTEM (SONAR CONTROL UNIT)

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (SONAR CONTROL UNIT)

### CONSULT Function

INFOID:000000011978501

#### CAUTION:

After disconnecting the CONSULT VI (vehicle interface) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and no-start condition.

### APPLICATION ITEMS

CONSULT can display each diagnostic item using the diagnostic test modes shown as follows:

Direct Diagnostic Mode	Description
Ecu Identification	The sonar control unit part number is displayed.
Self Diagnostic Result	The sonar control unit self diagnostic results are displayed.
Data Monitor	The sonar control unit input/output data is displayed in real time.
Active Test	The sonar control unit activates outputs to test components.
Work support	The settings for sonar control unit functions can be changed.
Configuration	<ul style="list-style-type: none"><li>• The vehicle specification can be read and saved.</li><li>• The vehicle specification can be written when replacing sonar control unit.</li></ul>
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

### ECU IDENTIFICATION

Displays the part number of sonar control unit.

### SELF-DIAGNOSTIC RESULTS

For details, refer to [SN-16, "DTC Index"](#).

### DATA MONITOR

Monitor Item	Description
VEHICLE SPEED [mph/km/h]	Indicates vehicle speed signal received from combination meter on CAN communication line.
SONAR C/U POWER SUPPLY [V]	Indicates condition of supply voltage signal to sonar control unit.
SENSOR VOLTAGE [V]	Indicates condition of voltage signal to sonar sensors.
DETECTION MODE [Mode 1/Mode 2]	Indicates condition of display detection mode.
SONAR TEMPORARY OFF [Yes/No]	Indicates condition of sonar system.
SONAR PERMANENT OFF [Yes/No]	Indicates condition of sonar system.
P N RANGE [On/Off]	Indicates condition of CVT shift selector P (park) or N (neutral) position.
LED [Yes/No]	Indicates condition of LED indicator.
TRAILER CONNECT [CON/N CON]	Indicates if trailer is connected.
REVERSE RANGE [On/Off]	Indicates condition of transmission range switch R (reverse) position.

# DIAGNOSIS SYSTEM (SONAR CONTROL UNIT)

## < SYSTEM DESCRIPTION >

Monitor Item	Description	
SHRT DST FRM RR SENS [cm/in]	Indicates distance to obstacle.	A
SHRT DST FRM FR SENS [cm/in]		
COR[RL] [cm/in]		B
COR[RL]->CEN[RL]/CEN[R] [cm/in]		
CEN[RL]/CEN[R]->COR[RL] [cm/in]		C
CEN[RL]/CEN[R] [cm/in]		
CEN[RL]->CEN[RR] [cm/in]		D
CEN[RR]->CEN[RL] [cm/in]		
CEN[RR] [cm/in]		E
CEN[RR]/CEN[R]->COR[RR] [cm/in]		
COR[RR]->CEN[RR]/CEN[R] [cm/in]		F
COR[RR] [cm/in]		
COR[FL] [cm/in]		G
COR[FL]->CEN[FL]/CEN[F] [cm/in]		
CEN[FL]/CEN[F]->COR[FL] [cm/in]		H
CEN[FL]/CEN[F] [cm/in]		
CEN[FL]->CEN[FR] [cm/in]		I
CEN[FR]->CEN[FL] [cm/in]		
CEN[FR] [cm/in]		J
CEN[FR]/CEN[F]->COR[FR] [cm/in]		
COR[FR]->CEN[FR]/CEN[F] [cm/in]	K	
COR[FR] [cm/in]		
RVRB TIME COR[RL] [ms/sec]		
RVRB TIME COR[RR] [ms/sec]		
RVRB TIME COR[FL] [ms/sec]		
RVRB TIME COR[FR] [ms/sec]		

## ACTIVE TEST

Test Item	Description	
FRONT BUZZER	This test is able to check front buzzer operation [On/Off].	L
REAR BUZZER	This test is able to check rear buzzer operation [On/Off].	M

## WORK SUPPORT

Support Item	Setting	Description	
VOLUME SETTING	Vol.1	Allows you to set volume of warning tone.	SN
	Low		
	Vol.3		O
	Middle		
	Vol.5		P
	High		
	Off		

## DIAGNOSIS SYSTEM (SONAR CONTROL UNIT)

### < SYSTEM DESCRIPTION >

Support Item	Setting	Description
TRAILER HITCH DETECTION RANGE ADJUSTMENT	Qu	Allows you to adjust rear sonar sensors for trailer towing.
	UP	
	DOWN	
	Qd	

### CONFIGURATION

Refer to [SN-25. "CONFIGURATION \(SONAR CONTROL UNIT\) : Description"](#).

### CAN DIAG SUPPORT MNTR

Refer to [LAN-14. "CAN Diagnostic Support Monitor"](#).

# SONAR CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

## ECU DIAGNOSIS INFORMATION

### SONAR CONTROL UNIT

Reference Value

INFOID:0000000011978502

VALUES ON THE DIAGNOSIS TOOL


Monitor Item	Condition	Value/Status	
COR[FL]	Key ON, CVT shift selector in R (reverse) position.	cm/in	
COR[FR]			
COR[RL]			
COR[RR]			
COR[RL]->CEN[RL]/CEN[R] [cm/in]			
CEN[RL]/CEN[R]->COR[RL] [cm/in]			
CEN[RL]/CEN[R] [cm/in]			
CEN[RL]->CEN[RR] [cm/in]			
CEN[RR]->CEN[RL] [cm/in]			
CEN[RR] [cm/in]			
CEN[RR]/CEN[R]->COR[RR] [cm/in]			
COR[RR]->CEN[RR]/CEN[R] [cm/in]			
COR[FL]->CEN[FL]/CEN[F] [cm/in]			
CEN[FL]/CEN[F]->COR[FL] [cm/in]			
CEN[FL]/CEN[F] [cm/in]			
CEN[FL]->CEN[FR] [cm/in]			
CEN[FR]->CEN[FL] [cm/in]			
CEN[FR] [cm/in]			
CEN[FR]/CEN[F]->COR[FR] [cm/in]			
COR[FR]->CEN[FR]/CEN[F] [cm/in]			
DETECTION MODE	Key ON.	Mode 1 Mode 2	
P N RANGE	When CVT shift selector is in any position other than P (park) or N (neutral).	Off	
	When CVT shift selector in P (park) or N (neutral) position.	On	
LED	When LED is off.	No	
	When LED is on.	Yes	
TRAILER CONNECT	When no trailer is connected.	N CONN	
	When trailer is connected.	CONN	
REVERSE RANGE	When transmission range switch is in any position other than R (reverse).	Off	
	When transmission range switch is in R (reverse) position.	On	
RVRB TIME COR[FL]	Key ON, CVT shift selector in R (reverse) position.	ms/sec	
RVRB TIME COR[FR]			
RVRB TIME COR[RL]			
RVRB TIME COR[RR]			
SENSOR VOLTAGE			5.0 V
SHRT DST FRM FR SENS			cm/in
SHRT DST FRM RR SENS			

# SONAR CONTROL UNIT

## < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
SONAR C/U POWER SUPPLY	Key ON.	Battery voltage
SONAR PERMANENT OFF	Key ON, CVT shift selector in R (reverse) position.	No
	When selector lever is in any position other than R (reverse).	Yes
SONAR TEMPORARY OFF	Key ON, CVT shift selector in R (reverse) position.	No
	When CVT shift selector is in any position other than R (reverse).	Yes
VEHICLE SPEED	While driving, equivalent to speedometer reading	mph, km/h

## TERMINAL LAYOUT- WITHOUT DRIVER ASSISTANCE SYSTEM




## PHYSICAL VALUES


Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output	Ignition switch	Operation	
3 (BG)	13 (W)	Sensor signal front LH	Input	ON	Shift position is R (reverse). Obstacle within range of front sonar sensor LH.	 JSNIA0837GB
4 (P)	13 (W)	Sensor signal front RH	Input	ON	Shift position is R (reverse). Obstacle within range of front sonar sensor RH.	 JSNIA0837GB
5 (L)	—	CAN high	Input/ Output	—	—	—
6 (P)	—	CAN low	Input/ Output	—	—	—
10 (B)	14 (W)	Sensor signal rear RH	Input	ON	Shift position is R (reverse). Obstacle within range of rear sonar sensor RH.	 JSNIA0837GB
12 (BG)	Ground	IGN power supply	Input	ON	—	Battery voltage

# SONAR CONTROL UNIT



## < ECU DIAGNOSIS INFORMATION >

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output	Ignition switch	Operation	
13 (W)	—	Front sensor ground	—	—	—	—
14 (W)	—	Rear sensor ground	—	—	—	—
15 (B)	Ground	Ground	—	ON	—	0 V
22 (R)	14 (W)	Sensor signal rear LH	Input	ON	Shift position is R (reverse). Obstacle within range of rear sonar sensor LH.	 <small>JSNIA0837GB</small>

## TERMINAL LAYOUT- WITH DRIVER ASSISTANCE SYSTEM





## PHYSICAL VALUES

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output	Ignition switch	Operation	
1 (G)	—	Sensor ground	—	—	—	—
7 (L)	1 (G)	Sensor signal rear RH	Input	ON	Shift position is R (reverse). Obstacle within range of rear sonar sensor RH.	 <small>JSNIA0837GB</small>
8 (R)	1 (G)	Sensor signal rear LH	Input	ON	Shift position is R (reverse). Obstacle within range of rear sonar sensor LH.	 <small>JSNIA0837GB</small>

# SONAR CONTROL UNIT

## < ECU DIAGNOSIS INFORMATION >

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output	Ignition switch	Operation	
9 (W)	1 (G)	Sensor signal front RH	Input	ON	Shift position is R (reverse). Obstacle within range of front sonar sensor RH.	 <p style="text-align: right; font-size: small;">JSNIA0837GB</p>
10 (B)	1 (G)	Sensor signal front LH	Input	ON	Shift position is R (reverse). Obstacle within range of front sonar sensor LH.	 <p style="text-align: right; font-size: small;">JSNIA0837GB</p>
13 (GR)	Ground	Ground	—	ON	—	0 V
17 (BR)	—	ITS CAN low	Input/ Output	—	—	—
18 (LG)	—	ITS CAN high	Input/ Output	—	—	—
24 (Y)	Ground	IGN power supply	Input	ON	—	Battery voltage

## DTC Index

INFOID:000000011978503

CONSULT Display	Reference Page
U1000: CAN COMM CIRCUIT	<a href="#">SN-27. "DTC Description"</a>
U1010: CONTROL UNIT (CAN)	<a href="#">SN-28. "DTC Description"</a>
B2720: REAR LEFT SIDE EXTERNAL SENSOR	<a href="#">SN-29. "DTC Logic"</a>
B2723: REAR RIGHT SIDE EXTERNAL SENSOR	<a href="#">SN-31. "DTC Logic"</a>
B2724: ECU	<a href="#">SN-33. "DTC Description"</a>
B2729: FRONT LEFT SIDE EXTERNAL SENSOR	<a href="#">SN-34. "DTC Logic"</a>
B272C: FRONT RIGHT SIDE EXTERNAL SENSOR	<a href="#">SN-36. "DTC Logic"</a>



# SONAR SYSTEM

< WIRING DIAGRAM >

## WIRING DIAGRAM


### SONAR SYSTEM

#### Wiring Diagram

INFOID:000000011978504

: CAN COMMUNICATION LINE FOR DIAGNOSIS  
DO : WITH DRIVER ASSISTANCE SYSTEM  
DZ : WITHOUT DRIVER ASSISTANCE SYSTEM

#### SONAR SYSTEM




AANWA1373GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
SN  
O  
P


## SONAR SYSTEM CONNECTORS

Connector No.	M1
Connector Name	WIRED TO WIRE
Connector Type	TH80FW-CST16-TM4
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
38G	BG	-
39G	W	-
40G	P	-
41G	W	-

Connector No.	M5
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS16FW-CS
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
7P	BG	-

Connector No.	M6
Connector Name	WIRED TO WIRE
Connector Type	TH80FDGY-CST16-TM4
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
66J	W	-
67J	R	-
68J	W	-
69J	B	-


Connector No.	M122
Connector Name	SONAR CONTROL UNIT (WITHOUT DRIVER ASSISTANCE SYSTEM)
Connector Type	TH24FW-NH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	-	-
2	-	-
3	BG	FOL
4	P	FOR
5	L	CAN-H
6	P	CAN-L

7	-	-
8	-	-
9	-	-
10	B	ROR
11	-	-
12	BG	POWER SUPPLY (IGN)
13	W	FRONT SENSOR GND
14	W	REAR SENSOR GND
15	B	GND
16	-	-
17	-	-
18	-	-
19	-	-
20	-	-
21	-	-
22	R	ROL
23	-	-
24	-	-

Connector No.	M123
Connector Name	JOINT CONNECTOR-M09
Connector Type	TK04FW-J
Connector Color	WHITE





Terminal No.	Color of Wire	Signal Name
2	W	-
3	W	-
4	W	-



# SONAR SYSTEM

< WIRING DIAGRAM >

Connector No.	M350	WIRE TO WIRE
Connector Name	WIRE TO WIRE	
Connector Type	TH24MW-NH	
Connector Color	WHITE	






Connector No.	E2	WIRE TO WIRE
Connector Name	WIRE TO WIRE	
Connector Type	TH24MW-NH	
Connector Color	WHITE	

Terminal No.	Color of Wire	Signal Name
3	B	-
4	W	-
10	L	-
12	Y	-
13	G	-
14	G	-
15	GR	-
22	R	-


Connector No.	M351	SONAR CONTROL UNIT (WITH DRIVER ASSISTANCE SYSTEM)
Connector Name	SONAR CONTROL UNIT (WITH DRIVER ASSISTANCE SYSTEM)	
Connector Type	TH24FW-NH	
Connector Color	WHITE	

Terminal No.	Color of Wire	Signal Name
1	G	SENSOR GND
2	-	-
3	-	-
4	-	-
5	-	-
6	-	-
7	L	ROR
8	R	ROL
9	W	FOR
10	B	FOL
11	-	-
12	-	-
13	GR	GND
14	-	-




Connector No.	M124	JOINT CONNECTOR-M03
Connector Name	JOINT CONNECTOR-M03	
Connector Type	TK04FW-J	
Connector Color	WHITE	





Terminal No.	Color of Wire	Signal Name
2	W	-
3	W	-
4	W	-

Connector No.	M192	WIRE TO WIRE
Connector Name	WIRE TO WIRE	
Connector Type	TH24FW-NH	
Connector Color	WHITE	

Terminal No.	Color of Wire	Signal Name
3	BG	-
4	P	-
10	B	-
12	BG	-
13	W	-
14	W	-
15	B	-
22	R	-


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

SN

# SONAR SYSTEM


< WIRING DIAGRAM >

Connector No.	E302
Connector Name	FRONT SONAR SENSOR RH OUTER
Connector Type	RH03FB
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	G	-
2	P	-

Connector No.	E304
Connector Name	FRONT SONAR SENSOR LH OUTER
Connector Type	RH03FB
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	W	-
2	R	-

Connector No.	E236
Connector Name	WIRE TO WIRE
Connector Type	RH02FB
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W	-
2	R	-

Connector No.	E237
Connector Name	WIRE TO WIRE
Connector Type	RH06FB
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
5	G	-
6	P	-

Connector No.	E300
Connector Name	WIRE TO WIRE
Connector Type	RH02MB
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	W	-
2	R	-

Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS11G-TM4
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
38G	R	-
39G	W	-
40G	BG	-
41G	G	-

Connector No.	E202
Connector Name	WIRE TO WIRE
Connector Type	TH24FW-NH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	LG	-
5	P	-
6	W	-
7	R	-


AANIA3948GB

# SONAR SYSTEM

< WIRING DIAGRAM >


2	P	-
---	---	---

Connector No.	T2
Connector Name	WIRE TO WIRE
Connector Type	RH04FB
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	P	-
2	L	-
3	B	-
4	Y	-

Connector No.	T3
Connector Name	REAR SONAR SENSOR LH OUTER
Connector Type	RH03FB
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	Y	-
2	B	-

Connector No.	T4
Connector Name	REAR SONAR SENSOR RH OUTER
Connector Type	RH03FB
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	L	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH80MDGY-CS16-TM4
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
66J	G	-
67J	W	-
68J	R	-
69J	BG	-

Connector No.	B24
Connector Name	WIRE TO WIRE
Connector Type	RH04MB
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	BG	-
2	R	-
3	W	-
4	G	-

AANIA3949GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

SN

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000011978505

#### OVERALL SEQUENCE



Reference 1: Refer to [SN-10. "CONSULT Function"](#).

Reference 2: Refer to [SN-16. "DTC Index"](#).

Reference 3: Refer to [SN-39. "Symptom Table"](#).

#### DETAILED FLOW

##### 1. INTERVIEW AND SYMPTOM CONFIRMATION

Check the malfunction symptoms by performing the following items.

- Interview the customer to obtain the malfunction information (conditions and environment when the malfunction occurred).
- Check the symptom.

Is the occurred symptom malfunction?

YES >> GO TO 2.

NO >> Inspection End.

##### 2. DIAGNOSIS WITH CONSULT

1. Connect CONSULT and perform Self Diagnostic Result for SONAR. Refer to [SN-10. "CONSULT Function"](#).

# DIAGNOSIS AND REPAIR WORKFLOW

## < BASIC INSPECTION >

---

### NOTE:

Skip to step 4 of the diagnosis procedure if SONAR is not displayed.

- When DTC is detected, follow the instructions below:
  - Record DTC and Freeze Frame Data.

### Is DTC displayed?

- YES >> GO TO 3.  
NO >> GO TO 4.

## 3. TROUBLE DIAGNOSIS FOR DTC

---

- Check the DTC indicated in the self-diagnosis results.
- Perform the relevant diagnosis referring to the DTC Index. Refer to [SN-16. "DTC Index"](#).

>> GO TO 5.

## 4. TROUBLE DIAGNOSIS FOR SYMPTOMS

---

Perform the relevant diagnosis referring to the diagnosis chart by symptom. Refer to [SN-39. "Symptom Table"](#).

>> GO TO 5.

## 5. ERROR PART REPAIR

---

- Repair or replace the identified malfunctioning parts.
- Perform Self Diagnostic Result for SONAR with CONSULT.

### NOTE:

Erase the stored self-diagnosis results after repairing or replacing the relevant components if any DTC has been indicated in the self-diagnosis results.

- Check that the symptom does not occur.

### Does the symptom occur?

- YES >> GO TO 1.  
NO >> Inspection End.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

SN

# INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

---

## INSPECTION AND ADJUSTMENT

### ADDITIONAL SERVICE WHEN REPLACING SONAR CONTROL UNIT

#### ADDITIONAL SERVICE WHEN REPLACING SONAR CONTROL UNIT : Description

INFOID:000000011978506

#### BEFORE REPLACEMENT

When replacing sonar control unit, save or print current vehicle specification with CONSULT configuration before replacement.

**NOTE:**

If "Before Replace ECU" cannot be used, use the "After Replace ECU" or "Manual Configuration" after replacing sonar control unit.

#### AFTER REPLACEMENT

**CAUTION:**

When replacing sonar control unit, you must perform "After Replace ECU" with CONSULT.

- Complete the procedure of "After Replace ECU" in order.
- If you set incorrect "After Replace ECU", incidents might occur.
- Configuration is different for each vehicle model. Confirm configuration of each vehicle model.

#### ADDITIONAL SERVICE WHEN REPLACING SONAR CONTROL UNIT : Work Procedure

INFOID:000000011978507

### 1. SAVING VEHICLE SPECIFICATION

---

#### CONSULT

Enter "Re/Programming, Configuration" and perform "Before Replace ECU" to save or print current vehicle specification.

**NOTE:**

If "Before Replace ECU" cannot be used, use the "After Replace ECU" or "Manual Configuration" after replacing sonar control unit.

>> GO TO 2.

### 2. REPLACE SONAR CONTROL UNIT

---

Replace sonar control unit. Refer to [SN-41. "Removal and Installation"](#).

>> GO TO 3.

### 3. WRITING VEHICLE SPECIFICATION

---

#### CONSULT

1. Enter "Re/Programming, Configuration".
2. If "Before Replace ECU" operation was performed, an "Operation Log Selection" screen will automatically be displayed. Select the applicable file from the "Saved Data List" and press "Confirm" to write vehicle specification. Refer to [SN-25. "CONFIGURATION \(SONAR CONTROL UNIT\) : Work Procedure"](#).
3. If "Before Replace ECU" operation was not performed, select "After Replace ECU" or "Manual Configuration" to write vehicle specification. Refer to [SN-25. "CONFIGURATION \(SONAR CONTROL UNIT\) : Work Procedure"](#).

>> GO TO 4.

### 4. OPERATION CHECK

---

Check that the operation of the sonar control unit is normal.

>> Work End.

### CONFIGURATION (SONAR CONTROL UNIT)



# INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

## CONFIGURATION (SONAR CONTROL UNIT) : Description

INFOID:000000011978508

Vehicle specification needs to be written with CONSULT. Configuration has three functions as follows:

Function	Description
"Before Replace ECU"	<ul style="list-style-type: none"><li>• Reads the vehicle configuration of current sonar control unit.</li><li>• Saves the read vehicle configuration.</li></ul>
"After Replace ECU"	Writes the vehicle configuration with manual selection.
"Select Saved Data List"	Writes the vehicle configuration with saved data.

### CAUTION:

- When replacing sonar control unit, you must perform "Select Saved Data List" or "After Replace ECU" with CONSULT.
- Complete the procedure of "Select Saved Data List" or "After Replace ECU" in order.
- If you set incorrect "Select Saved Data List" or "After Replace ECU", incidents might occur.
- Configuration is different for each vehicle model. Confirm configuration of each vehicle model.
- Never perform "Select Saved Data List" or "After Replace ECU" except for new sonar control unit.

## CONFIGURATION (SONAR CONTROL UNIT) : Work Procedure

INFOID:000000011978509

### 1. WRITING MODE SELECTION

#### CONSULT

Select "Reprogramming, Configuration" of sonar control unit.

When writing saved data>>GO TO 2.

When writing manually>>GO TO 3.

### 2. PERFORM "SAVED DATA LIST"

#### CONSULT

Automatically "Operation Log Selection" window will display if "Before Replace ECU" was performed. Select applicable file from the "Save Data List" and press "Confirm".

>> Work End.

### 3. PERFORM "AFTER REPLACE ECU" OR "MANUAL CONFIGURATION"

#### CONSULT

1. Select "After Replace ECU" or "Manual Configuration".
2. Identify the correct model and configuration list. Refer to [SN-26. "CONFIGURATION \(SONAR CONTROL UNIT\) : Configuration List"](#).
3. Confirm and/or change setting value for each item.

#### CAUTION:

Thoroughly read and understand the vehicle specification. ECU control may not operate normally if the setting is not correct.

4. Select "Next".

#### CAUTION:

Make sure to select "Next", confirm each setting value and press "OK" even if the indicated configuration of brand new sonar control unit is same as the desirable configuration. If not, configuration which is set automatically by selecting vehicle model can not be memorized.

5. When "Completed", select "End".

>> GO TO 4.

### 4. OPERATION CHECK

Confirm that each function controlled by sonar control unit operates normally.

>> Work End.

# INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

## CONFIGURATION (SONAR CONTROL UNIT) : Configuration List

INFOID:000000011978510

**CAUTION:**

Thoroughly read and understand the vehicle specification. Incorrect settings may result in abnormal control of ECU.

MANUAL SETTING ITEM	
Items	Setting value
BCI FUNCTION	WITH ⇔ WITHOUT*

⇔: Items which confirm vehicle specifications

\*: BCI FUNCTION should always be set to WITHOUT.

# U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## DTC/CIRCUIT DIAGNOSIS

### U1000 CAN COMM CIRCUIT

#### DTC Description

INFOID:000000012248781

#### DESCRIPTION

CAN (Controller Area Network) is a serial communication line for real-time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independently). In CAN communication, control units are connected with 2 communication lines (CAN high, CAN low) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Signal Chart. Refer to [LAN-32. "CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart"](#).

#### DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	
U1000	CAN COMM CIRCUIT (CAN COMM CIRCUIT)	Diagnosis condition	When ignition switch is ON.
		Signal (terminal)	–
		Threshold	–
		Diagnosis delay time	2 seconds or more

#### POSSIBLE CAUSE

CAN communication system

#### FAIL-SAFE

The system using the CAN communication signal from control unit which cannot communicate does not function.

#### DTC CONFIRMATION PROCEDURE

##### 1. PERFORM DTC CONFIRMATION PROCEDURE

###### ⓂCONSULT

1. Turn ignition switch ON.
2. Turn ignition switch OFF and wait at least 30 seconds.
3. Turn ignition switch ON and wait at least 30 seconds or more.
4. Select "Self Diagnostic Result" mode of "SONAR".
5. Check DTC.

###### Is DTC U1000 detected?

YES >> Proceed to [SN-27. "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41. "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

#### Diagnosis Procedure

INFOID:000000012248782

##### 1. PERFORM DTC CONFIRMATION PROCEDURE AGAIN

###### ⓂCONSULT

1. Turn ignition switch ON.
2. Erase DTC.
3. Perform DTC confirmation procedure again. Refer to [SN-27. "DTC Description"](#).

###### Is DTC detected again?

YES >> Perform the trouble diagnosis for CAN communication system. Refer to [LAN-17. "Trouble Diagnosis Flow Chart"](#).

NO >> Inspection End.

# U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

## U1010 CONTROL UNIT (CAN)

### DTC Description

INFOID:000000012248783

#### DESCRIPTION

CAN (Controller Area Network) is a serial communication line for real-time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independently). In CAN communication, control units are connected with 2 communication lines (CAN high, CAN low) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only. CAN Communication Signal Chart. Refer to [LAN-32, "CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart"](#).

#### DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	
U1010	CONTROL UNIT (CAN) [Control unit (CAN)]	Diagnosis condition	When ignition switch is ON.
		Signal (terminal)	-
		Threshold	-
		Diagnosis delay time	30 seconds or more

#### POSSIBLE CAUSE

CAN communication system

#### FAIL-SAFE

The system using the CAN communication signal does not function.

#### DTC CONFIRMATION PROCEDURE

##### 1. PRECONDITIONING

1. Turn ignition switch OFF and wait at least 30 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 30 seconds.

>> GO TO 2.

##### 2. PERFORM DTC CONFIRMATION PROCEDURE

###### CONSULT

1. Turn ignition switch ON and wait at least 30 seconds or more.
2. Select "Self Diagnostic Result" mode of "SONAR".
3. Check DTC.

###### Is DTC U1010 detected?

- YES >> Proceed to [SN-28, "Diagnosis Procedure"](#).  
NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).  
NO-2 >> Confirmation after repair: Inspection End.

#### Diagnosis Procedure

INFOID:000000012248784

##### 1. PERFORM DTC CONFIRMATION PROCEDURE AGAIN

###### CONSULT

1. Turn ignition switch ON.
2. Erase DTC.
3. Perform DTC confirmation procedure again. Refer to [SN-28, "DTC Description"](#).

###### Is DTC U1010 detected again?

- YES >> Replace sonar control unit. Refer to [SN-41, "Removal and Installation"](#).  
NO >> Inspection End.

# B2720 CORNER SENSOR [RL]

< DTC/CIRCUIT DIAGNOSIS >

## B2720 CORNER SENSOR [RL]

### DTC Logic

INFOID:0000000011978514

### DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition		
B2720	REAR LEFT SIDE EXTERNAL SENSOR (Rear sonar sensor LH outer)	1	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Rear sonar sensor LH outer circuit is shorted to ground (terminal 22 (without driver assistance system, or 8 (with driver assistance system))
			Threshold	Rear sonar sensor LH outer circuit is shorted to ground
			Diagnosis delay time	30 seconds or more
		2	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Rear sonar sensor LH outer signal is open (terminal 22 (without driver assistance system, or 8 (with driver assistance system))
			Threshold	Rear sonar sensor LH outer circuit is open
			Diagnosis delay time	30 seconds or more

### POSSIBLE CAUSE

- Sensor configuration
- Harness or connectors
- Rear sonar sensor LH outer

### FAIL-SAFE

Rear sonar sensor LH outer signal is not received

### Diagnosis Procedure

INFOID:0000000011978515

Regarding Wiring Diagram information, refer to [SN-17. "Wiring Diagram"](#).

## 1. CHECK REAR SONAR SENSOR LH CIRCUIT CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect sonar control unit connector M122 (without driver assistance system), or M351 (with driver assistance system), and rear sonar sensor LH connector T3.
3. Check continuity between sonar control unit connector M122 (without driver assistance system), or M351 (with driver assistance system), and rear sonar sensor LH connector T3.

Without driver assistance system

Sonar control unit		Rear sonar sensor LH		Continuity
Connector	Terminal	Connector	Terminal	
M122	22	T3	2	Yes
	14		1	

With driver assistance system

Sonar control unit		Rear sonar sensor LH		Continuity
Connector	Terminal	Connector	Terminal	

## B2720 CORNER SENSOR [RL]

### < DTC/CIRCUIT DIAGNOSIS >

M351	8	T3	2	Yes
	1		1	

4. Check continuity between sonar control unit connector M122 (without driver assistance system), or M351 (with driver assistance system), and ground.

Without driver assistance system

Sonar control unit		Ground	Continuity
Connector	Terminal		
M122	22	—	No

With driver assistance system

Sonar control unit		Ground	Continuity
Connector	Terminal		
M351	8	—	No

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness or connectors.

### 2. CHECK REAR SONAR SENSOR LH SIGNAL CIRCUIT SHORT TO BATTERY

1. Turn ignition switch ON.
2. Check voltage between sonar control unit connector M122 (without driver assistance system), or M351 (with driver assistance system), and ground.

Without driver assistance system

Sonar control unit		Ground	Voltage (Approx.)
Connector	Terminal		
M122	22	—	0V

With driver assistance system

Sonar control unit		Ground	Voltage (Approx.)
Connector	Terminal		
M351	8	—	0V

Is the inspection result normal?

YES >> Replace rear sonar sensor LH. Refer to [SN-40. "Removal and Installation - Front Sonar Sensors"](#).

NO >> Repair or replace harness or connectors.

# B2723 CORNER SENSOR [RR]

< DTC/CIRCUIT DIAGNOSIS >

## B2723 CORNER SENSOR [RR]

### DTC Logic

INFOID:0000000011978516

### DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition		
B2723	REAR RIGHT SIDE EXTERNAL SENSOR (Rear sonar sensor RH outer)	1	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Rear sonar sensor RH outer circuit is shorted to ground (terminal 10 (without driver assistance system), or 7 (with driver assistance system))
			Threshold	Rear sonar sensor RH outer circuit is shorted to ground
			Diagnosis delay time	30 seconds or more
		2	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Rear sonar sensor RH outer signal is open (terminal 10 (without driver assistance system), or 7 (with driver assistance system))
			Threshold	Rear sonar sensor RH outer circuit is open
			Diagnosis delay time	30 seconds or more

### POSSIBLE CAUSE

- Sensor configuration
- Harness or connectors
- Rear sonar sensor RH outer

### FAIL-SAFE

Rear sonar sensor RH outer signal is not received

### Diagnosis Procedure

INFOID:0000000011978517

Regarding Wiring Diagram information, refer to [SN-17. "Wiring Diagram"](#).

## 1. CHECK REAR SONAR SENSOR RH SIGNAL CIRCUIT CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect sonar control unit connector M122 (without driver assistance system), or M351 (with driver assistance system), and rear sonar sensor RH connector T4.
3. Check continuity between sonar control unit connector M122 (without driver assistance system), or M351 (with driver assistance system), and rear sonar sensor RH connector T4.

Without driver assistance system

Sonar control unit		Rear sonar sensor RH		Continuity
Connector	Terminal	Connector	Terminal	
M122	10	T4	2	Yes
	14		1	

With driver assistance system

Sonar control unit		Rear sonar sensor RH		Continuity
Connector	Terminal	Connector	Terminal	

## B2723 CORNER SENSOR [RR]

### < DTC/CIRCUIT DIAGNOSIS >

M351	7	T4	2	Yes
	1		1	

4. Check continuity between sonar control unit connector M122 (without driver assistance system), or M351 (with driver assistance system), and ground.

Without driver assistance system

Sonar control unit		Ground	Continuity
Connector	Terminal		
M122	10	—	No

With driver assistance system

Sonar control unit		Ground	Continuity
Connector	Terminal		
M351	7	—	No

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness or connectors.

### 2. CHECK REAR SONAR SENSOR RH SIGNAL CIRCUIT SHORT TO BATTERY

1. Turn ignition switch ON.
2. Check voltage between sonar control unit connector M122 (without driver assistance system), or M351 (with driver assistance system), and ground.

Without driver assistance system

Sonar control unit		Ground	Voltage (Approx.)
Connector	Terminal		
M122	10	—	0V

With driver assistance system

Sonar control unit		Ground	Voltage (Approx.)
Connector	Terminal		
M351	7	—	0V

Is the inspection result normal?

YES >> Replace rear sonar sensor RH. Refer to [SN-40. "Removal and Installation - Front Sonar Sensors"](#).

NO >> Repair or replace harness or connectors.



# B2724 SONAR CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

## B2724 SONAR CONTROL UNIT

### DTC Description

INFOID:000000012248785

### DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	
		Diagnosis condition	When ignition switch is ON.
B2724	SONAR CONTROL UNIT (Sonar control unit)	Signal (terminal)	–
		Threshold	–
		Diagnosis delay time	30 seconds or more

### POSSIBLE CAUSE

Sonar control unit

### FAIL-SAFE

Sonar system not functioning

### Diagnosis Procedure

INFOID:000000012248786

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

##### ⓂCONSULT

1. Turn ignition switch ON.
2. Turn ignition switch OFF and wait at least 30 seconds.
3. Turn ignition switch ON and wait at least 30 seconds or more.
4. Select "Self Diagnostic Result" mode of "SONAR".
5. Check DTC.

##### Is DTC B2724 detected?

- YES >> Replace sonar control unit. Refer to [SN-41. "Removal and Installation"](#).  
NO >> Inspection End.

# B2729 CORNER SENSOR [FL]

< DTC/CIRCUIT DIAGNOSIS >

## B2729 CORNER SENSOR [FL]

### DTC Logic

INFOID:000000011978521

### DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition		
B2729	FRONT LEFT SIDE EXTERNAL SENSOR (Front sonar sensor LH outer)	1	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Front sonar sensor LH outer circuit is shorted to ground (terminal 3 (without driver assistance system), or 10 (with driver assistance system))
			Threshold	Front sonar sensor LH outer circuit is shorted to ground
			Diagnosis delay time	30 seconds or more
		2	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Front sonar sensor LH outer signal is open (terminal 3 (without driver assistance system), or 10 (with driver assistance system))
			Threshold	Front sonar sensor LH outer circuit is open
			Diagnosis delay time	30 seconds or more

### POSSIBLE CAUSE

- Sensor configuration
- Harness or connectors
- Front sonar sensor LH outer

### FAIL-SAFE

Front sonar sensor LH outer signal is not received

### Diagnosis Procedure

INFOID:000000011978522

Regarding Wiring Diagram information, refer to [SN-17, "Wiring Diagram"](#).

### 1. CHECK FRONT SONAR SENSOR LH CIRCUIT CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect sonar control unit connector M122 (without driver assistance system), or M351 (with driver assistance system), and front sonar sensor LH connector E304.
3. Check continuity between sonar control unit connector M122 (without driver assistance system), or M351 (with driver assistance system), and front sonar sensor LH connector E304.

Without driver assistance system

Sonar control unit		Front sonar sensor LH		Continuity
Connector	Terminal	Connector	Terminal	
M122	3	E304	2	Yes
	13		1	

With driver assistance system

Sonar control unit		Front sonar sensor LH		Continuity
Connector	Terminal	Connector	Terminal	

## B2729 CORNER SENSOR [FL]

### < DTC/CIRCUIT DIAGNOSIS >

M351	10	E304	2	Yes
	1		1	

4. Check continuity between sonar control unit connector M122 (without driver assistance system), or M351 (with driver assistance system), and ground.

Without driver assistance system

Sonar control unit		Ground	Continuity
Connector	Terminal		
M122	3	—	No

With driver assistance system

Sonar control unit		Ground	Continuity
Connector	Terminal		
M351	10	—	No

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness or connectors.

### 2. CHECK FRONT SONAR SENSOR LH SIGNAL CIRCUIT SHORT TO BATTERY

1. Turn ignition switch ON.
2. Check voltage between sonar control unit connector M122 (without driver assistance system), or M351 (with driver assistance system), and ground.

Without driver assistance system

Sonar control unit		Ground	Voltage (Approx.)
Connector	Terminal		
M122	3	—	0V

With driver assistance system

Sonar control unit		Ground	Voltage (Approx.)
Connector	Terminal		
M351	10	—	0V

Is the inspection result normal?

YES >> Replace front sonar sensor LH. Refer to [SN-40. "Removal and Installation - Front Sonar Sensors"](#).

NO >> Repair or replace harness or connectors.

SN

# B272C CORNER SENSOR [FR]

< DTC/CIRCUIT DIAGNOSIS >

## B272C CORNER SENSOR [FR]

### DTC Logic

INFOID:000000011978523

### DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition		
B2720	FRONT RIGHT SIDE EXTERNAL SENSOR (Front sonar sensor RH outer)	1	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Front sonar sensor RH outer circuit is shorted to ground (terminal 4 (without driver assistance system), or 9 (with driver assistance system))
			Threshold	Front sonar sensor RH outer circuit is shorted to ground
			Diagnosis delay time	30 seconds or more
		2	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Front sonar sensor RH outer signal is open (terminal 4 (without driver assistance system), or 9 (with driver assistance system))
			Threshold	Front sonar sensor RH outer circuit is open
			Diagnosis delay time	30 seconds or more

### POSSIBLE CAUSE

- Sensor configuration
- Harness or connectors
- Front sonar sensor RH outer

### FAIL-SAFE

Front sonar sensor RH outer signal is not received

### Diagnosis Procedure

INFOID:000000011978524

Regarding Wiring Diagram information, refer to [SN-17, "Wiring Diagram"](#).

## 1. CHECK FRONT SONAR SENSOR RH CIRCUIT CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect sonar control unit connector M122 (without driver assistance system), or M351 (with driver assistance system), and front sonar sensor RH connector E302.
3. Check continuity between sonar control unit connector M122 (without driver assistance system), or M351 (with driver assistance system), and front sonar sensor RH connector E302.

Without driver assistance system

Sonar control unit		Front sonar sensor RH		Continuity
Connector	Terminal	Connector	Terminal	
M122	4	E302	2	Yes
	13		1	

With driver assistance system

Sonar control unit		Front sonar sensor RH		Continuity
Connector	Terminal	Connector	Terminal	

## B272C CORNER SENSOR [FR]

### < DTC/CIRCUIT DIAGNOSIS >

M351	9	E302	2	Yes
	1		1	

4. Check continuity between sonar control unit connector M122 (without driver assistance system), or M351 (with driver assistance system), and ground.

Without driver assistance system

Sonar control unit		Ground	Continuity
Connector	Terminal		
M122	4	—	No

With driver assistance system

Sonar control unit		Ground	Continuity
Connector	Terminal		
M351	9	—	No

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness or connectors.

### 2. CHECK FRONT SONAR SENSOR RH SIGNAL CIRCUIT SHORT TO BATTERY

1. Turn ignition switch ON.
2. Check voltage between sonar control unit connector M122 (without driver assistance system), or M351 (with driver assistance system), and ground.

Without driver assistance system

Sonar control unit		Ground	Voltage (Approx.)
Connector	Terminal		
M122	4	—	0V

With driver assistance system

Sonar control unit		Ground	Voltage (Approx.)
Connector	Terminal		
M351	9	—	0V

Is the inspection result normal?

YES >> Replace front sonar sensor RH. Refer to [SN-40. "Removal and Installation - Front Sonar Sensors"](#).

NO >> Repair or replace harness or connectors.

SN

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## POWER SUPPLY AND GROUND CIRCUIT

### Diagnosis Procedure

INFOID:000000011978527

Regarding Wiring Diagram information, refer to [SN-17. "Wiring Diagram"](#).

### 1. CHECK FUSE

Check that the following fuse is not blown:

Terminal No.	Signal name	Fuse No.
12 (without driver assistance system)	IGN power supply	30 (10A)
24 (with driver assistance system)		

Is the fuse blown?

YES >> Replace the blown fuse after repairing the affected circuit.

NO >> GO TO 2.

### 2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect sonar control unit connector M122 (without driver assistance system), or M351 (with driver assistance system).
3. Check voltage between sonar control unit connector M122 (without driver assistance system), or M351 (with driver assistance system), and ground.

Without driver assistance system

Sonar control unit		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
M122	12	—	Ignition switch: ON	Battery voltage

With driver assistance system

Sonar control unit		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
M351	24	—	Ignition switch: ON	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

### 3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between sonar control unit connector M122 (without driver assistance system), or M351 (with driver assistance system), and ground.

Without driver assistance system

Sonar control unit		Ground	Continuity
Connector	Terminal		
M122	15	—	Yes

With driver assistance system

Sonar control unit		Ground	Continuity
Connector	Terminal		
M351	13	—	Yes

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair or replace harness or connectors.

# SONAR SYSTEM

< SYMPTOM DIAGNOSIS >

## SYMPTOM DIAGNOSIS

### SONAR SYSTEM

#### Symptom Table

INFOID:0000000011978528

Symptom	Possible cause	Reference page
Malfunction is detected in only 1 sensor of display (Always displayed in red).	<ul style="list-style-type: none"><li>• Sonar sensor circuit</li><li>• Sonar sensor</li></ul>	<ul style="list-style-type: none"><li>• <a href="#">SN-34</a> (front LH)</li><li>• <a href="#">SN-36</a> (front RH)</li><li>• <a href="#">SN-29</a> (rear LH)</li><li>• <a href="#">SN-31</a> (rear RH)</li><li>• <a href="#">SN-40</a> (removal and installation)</li></ul>
Malfunction is detected in all 4 sensors of display (Always displayed in red).	<ul style="list-style-type: none"><li>• Sonar control unit power supply and ground circuits</li><li>• CAN communication circuits</li></ul>	<ul style="list-style-type: none"><li>• <a href="#">SN-38</a></li><li>• <a href="#">LAN-17, "Trouble Diagnosis Flow Chart"</a></li></ul>

A

B

C

D

E

F

G

H

I

J

K

L

M

SN

O

P

# SONAR SENSOR

< REMOVAL AND INSTALLATION >

## REMOVAL AND INSTALLATION


### SONAR SENSOR

#### Removal and Installation - Front Sonar Sensors

INFOID:000000011978529

##### REMOVAL

1. Remove front bumper fascia. Refer to [EXT-17. "Removal and Installation"](#).
2. Disconnect harness connector from front sonar sensor.
3. Release front sonar sensor finisher (1) pawls using suitable tool and remove front sonar sensor (2) from front sonar sensor finisher.  
○: Pawl
4. Remove front sonar sensor finisher (1) from front bumper fascia (if necessary).



##### INSTALLATION

Installation is in the reverse order of removal.

##### **CAUTION:**


**If front sonar sensor finisher is replaced, clean area before installation.**

#### Removal and Installation - Rear Sonar Sensors

INFOID:000000011978530

##### REMOVAL

1. Disconnect harness connector from rear sonar sensor.
2. Release rear sonar sensor finisher (1) pawls using suitable tool and remove rear sonar sensor (2) from rear sonar sensor finisher.  
○: Pawl
3. Remove rear sonar sensor finisher (1) from rear bumper fascia (if necessary).



##### INSTALLATION

Installation is in the reverse order of removal.

##### **CAUTION:**

**If rear sonar sensor finisher is replaced, clean area before installation.**



# SONAR CONTROL UNIT

< REMOVAL AND INSTALLATION >

## SONAR CONTROL UNIT

### Removal and Installation


INFOID:0000000011978531

#### REMOVAL

##### **CAUTION:**

Before replacing the sonar control unit, perform "READ CONFIGURATION" to save or print current vehicle specification. Refer to [SN-24, "ADDITIONAL SERVICE WHEN REPLACING SONAR CONTROL UNIT : Description"](#).

1. Remove the instrument lower panel LH. Refer to [IP-23, "Removal and Installation"](#).
2. Disconnect the harness connector (B) from the sonar control unit (1).
3. Remove the screw (A) from the sonar control unit (1) and remove.



#### INSTALLATION

Installation is in the reverse order of removal.

##### **CAUTION:**

Be sure to perform "WRITE CONFIGURATION" when replacing sonar control unit. Refer to [SN-24, "ADDITIONAL SERVICE WHEN REPLACING SONAR CONTROL UNIT : Description"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

SN

# BUZZER

< REMOVAL AND INSTALLATION >

---

## BUZZER

### Removal and Installation

INFOID:000000011978532

**NOTE:**

Sonar Buzzer function is integrated with the AV control unit, for removal and installation Refer to [AV-183, "Removal and Installation"](#).