

SECTION **INL**

INTERIOR LIGHTING SYSTEM

CONTENTS

BASIC INSPECTION	3	POWER SUPPLY AND GROUND CIRCUIT	18
DIAGNOSIS AND REPAIR WORKFLOW	3	BCM	18
Work Flow	3	BCM : Diagnosis Procedure	18
SYSTEM DESCRIPTION	5	INTERIOR ROOM LAMP POWER SUPPLY CIRCUIT	19
INTERIOR ROOM LAMP CONTROL SYSTEM	Description	19
System Diagram	5	Component Function Check	19
System Description	5	Diagnosis Procedure	19
Component Parts Location	7	INTERIOR ROOM LAMP CONTROL CIRCUIT
Component Description	7	Description	21
INTERIOR ROOM LAMP BATTERY SAVER SYSTEM	8	Component Function Check	21
System Diagram	8	Diagnosis Procedure	21
System Description	8	STEP LAMP CIRCUIT	23
Component Parts Location	9	Description	23
Component Description	10	Component Function Check	23
ILLUMINATION CONTROL SYSTEM	11	Diagnosis Procedure	23
System Diagram	11	PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT	25
System Description	11	Description	25
Component Parts Location	12	Component Function Check	25
Component Description	12	Diagnosis Procedure	25
DIAGNOSIS SYSTEM (BCM)	13	INTERIOR ROOM LAMP CONTROL SYSTEM
COMMON ITEM	13	Wiring Diagram - INTERIOR ROOM LAMP -	27
COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM)	13	ILLUMINATION	38
INT LAMP	14	Wiring Diagram - ILLUMINATION -	38
INT LAMP : CONSULT-III Function (BCM - INT LAMP)	15	ECU DIAGNOSIS INFORMATION	54
BATTERY SAVER	16	BCM (BODY CONTROL MODULE)	54
BATTERY SAVER : CONSULT-III Function (BCM - BATTERY SAVER)	16	Reference Value	54
DTC/CIRCUIT DIAGNOSIS	18	Wiring Diagram - BCM -	77
		Fail-safe	83
		DTC Inspection Priority Chart	85

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

INL

DTC Index	85	ROOF CENTER	112
COMBINATION METER	88	ROOF CENTER : Replacement	112
Reference Value	88		
Wiring Diagram - METER -	94		
Fail-Safe	105		
DTC Index	106		
SYMPTOM DIAGNOSIS	108		
INTERIOR LIGHTING SYSTEM SYMPTOMS.	108		
Symptom Table	108		
PRECAUTION	109		
PRECAUTIONS	109		
FOR USA AND CANADA	109		
FOR USA AND CANADA : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	109		
FOR MEXICO	109		
FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	109		
REMOVAL AND INSTALLATION	111		
MAP LAMP	111		
Exploded View	111		
Removal and Installation	111		
Replacement	111		
MOOD LAMP	112		
MAP LAMP	112		
MAP LAMP : Replacement	112		
FRONT DOOR GRIP	112		
FRONT DOOR GRIP : Replacement	112		
ROOF CENTER	112		
Exploded View	113		
Replacement	113		
VANITY MIRROR LAMP	113		
Exploded View	113		
Replacement	113		
CONSOLE POCKET LAMP	114		
Exploded View	114		
Replacement	114		
ASHTRAY ILLUMINATION	115		
Exploded View	115		
Replacement	115		
GLOVE BOX LAMP	116		
Exploded View	116		
Replacement	116		
STEP LAMP	117		
Exploded View	117		
Removal and Installation	117		
Replacement	117		
PERSONAL LAMP	118		
Exploded View	118		
Removal and Installation	118		
Replacement	119		
LUGGAGE ROOM LAMP	120		
Exploded View	120		
Removal and Installation	120		
Replacement	120		
SERVICE DATA AND SPECIFICATIONS (SDS)	121		
SERVICE DATA AND SPECIFICATIONS (SDS)	121		
Bulb Specifications	121		

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000006262804

OVERALL SEQUENCE



JPLIA0313GB

DETAILED FLOW

1. INTERVIEW FOR MALFUNCTION

Interview the symptom to the customer.

A
B
C
D
E
F
G
H
I
J
K
INL
M
N
O
P

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

>> GO TO 2.

2. SYMPTOM CHECK

Check the symptom from the customer's information.

>> GO TO 3.

3. BASIC INSPECTION

Check the operation of each part. Check that any symptom occurs other than the interviewed symptom.

>> GO TO 4.

4. SELF-DIAGNOSIS WITH CONSULT-III

Perform the self-diagnosis with CONSULT-III. Check that any DTC is detected.

Is any DTC detected?

YES >> GO TO 5.

NO >> GO TO 6.

5. TROUBLE DIAGNOSIS BY DTC

Perform the trouble diagnosis for the detected DTC. Specify the malfunctioning part.

>> GO TO 9.

6. FAIL-SAFE ACTIVATION CHECK

Check that the symptom is applied to the fail-safe activation.

Does the fail-safe activate?

YES >> GO TO 7.

NO >> GO TO 8.

7. SYSTEM DIAGNOSIS

Perform the system diagnosis for the system that the fail-safe activates. Specify the malfunctioning part.

>> GO TO 9.

8. SYMPTOM DIAGNOSIS

Perform the symptom diagnosis. Specify the malfunctioning part.

>> GO TO 9.

9. MALFUNCTION PART REPAIR

Repair or replace the malfunctioning part.

>> GO TO 10.

10. REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT-III)

Perform the self-diagnosis with CONSULT-III. Check that any DTC is not detected. Erase DTC if DTC is detected before the repair. Check that DTC is not detected again.

Is any DTC detected?

YES >> GO TO 5.

NO >> GO TO 11.

11. REPAIR CHECK (OPERATION CHECK)

Check the operation of each part.

Does it operate normally?

YES >> INSPECTION END

NO >> GO TO 3.

INTERIOR ROOM LAMP CONTROL SYSTEM


< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

INTERIOR ROOM LAMP CONTROL SYSTEM

System Diagram

INFOID:0000000006262805



System Description

INFOID:0000000006262806

OUTLINE

- Interior room lamps* are controlled by interior room lamp timer control function of BCM.
*: Map lamp and personal lamp (when map lamp switch is in DOOR position).
- Step lamp is controlled by step lamp control function of BCM.
- Push-button ignition switch illumination is controlled by the push-button ignition switch illumination control function of BCM.

INTERIOR ROOM LAMP TIMER CONTROL


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

INL

INTERIOR ROOM LAMP CONTROL SYSTEM

< SYSTEM DESCRIPTION >

Interior Room Lamp Timer Basic Operation



- The interior room lamp turns ON and OFF (gradual brightening and dimming) by the interior room timer.
- BCM judges the vehicle condition with the following items. It activates the interior room timer.
 - Ignition switch status
 - Door switch signal (ALL)
 - Door lock/unlock signal (Remote keyless entry receiver, each request switch, key cylinder lock/unlock switch, door lock/unlock switch)

NOTE:

Each function of interior room lamp timer can be set by CONSULT-III. Refer to [INL-15, "INT LAMP : CONSULT-III Function \(BCM - INT LAMP\)"](#).

Interior Room Lamp ON Operation

- BCM always turns the interior room lamp ON when any door opens.
- BCM activates the interior room timer in any of the following conditions to turn the interior room lamp ON for a period of time.
 - Any door opens before all doors close.
 - Ignition switch is turned ON → OFF.
 - Any door unlock signal is detected when all doors close with ignition switch OFF.

NOTE:

Restart the timer if new condition is input during the timer operating time.

Interior Room Lamp OFF Operation

BCM stops the timer in any of the following conditions to turns the interior room lamp OFF.

- The timer operating time is expired.
- Ignition switch position is other than OFF with all doors close.
- Any door lock operation is detected with all doors close.

STEP LAMP CONTROL

BCM controls the step lamp (ground-side) to turn ON with any door switch ON.

PUSH-BUTTON IGNITION SWITCH ILLUMINATION CONTROL

Push-button Ignition Switch Illumination Basic Operation

- BCM provides the power supply and the ground to turn the push-button ignition switch illumination ON.
- BCM cuts the ground supply while the each illumination (tail lamp) ON. BCM switches to the ground control with the meter illumination control function.

Push-button Ignition Switch Illumination ON Operation

BCM turns the push-button ignition switch illumination ON in the following conditions.

- Ignition switch ON
- Each illumination (tail lamp) ON
- Any of the following conditions with ignition switch OFF
 - Engine start permission is entered.
 - Intelligent Key inserted into the key slot.
 - Driver door is LOCK → UNLOCK.
 - Driver door is open.

Push-button Ignition Switch Illumination OFF Operation

INTERIOR ROOM LAMP CONTROL SYSTEM


< SYSTEM DESCRIPTION >

BCM turns the push-button ignition switch illumination OFF in any of the following conditions.

- The push-button ignition switch illumination ON conditions do not satisfy.
- All of the following conditions with ignition switch OFF
- Each illumination (tail lamp) OFF
- The push-button ignition switch illumination ON conditions do not change (15 seconds after the ignition switch OFF) or the driver door is UNLOCK → LOCK.

Component Parts Location

INFOID:0000000006262807



JPLIA0889ZZ

- | | | |
|-----------------------|---------------------------------|---|
| 1. Personal lamp | 2. Request switch | 3. Step lamp |
| 4. Door switch | 5. Key cylinder switch | 6. Push-button ignition switch illumination |
| 7. Map lamp | 8. Door lock switch | 9. Remote keyless entry receiver |
| 10. BCM | | |
| A. Over the glove box | B. Behind the combination meter | |

Component Description

INFOID:0000000006262808

Part	Description
BCM	<ul style="list-style-type: none">• Activates the interior room lamp timer depending on the vehicle condition to turn the interior room lamp ON/OFF.• Turns the step lamp ON /OFF according to any door switch status.
Remote keyless entry receiver	<ul style="list-style-type: none">• Receives the lock/unlock signal from keyfob.• Transmits the lock/unlock signal to BCM.
• Request switch • Key cylinder lock/unlock switch • Door lock/unlock switch	Inputs the lock/unlock signal to BCM.
Door switch	Inputs the door switch signal to BCM.


INTERIOR ROOM LAMP BATTERY SAVER SYSTEM

< SYSTEM DESCRIPTION >

INTERIOR ROOM LAMP BATTERY SAVER SYSTEM

System Diagram

INFOID:0000000006262809



JPLIA0986GB

System Description

INFOID:0000000006262810

OUTLINE

- Interior room lamp battery saver is controlled by BCM.
- BCM turns applicable lamps OFF depending on the vehicle condition. This function prevents the battery from over-discharging if the driver neglect turning OFF the any lamps.

Applicable lamps

- Map lamp
- Personal lamp
- Step lamp
- Luggage room lamp
- Vanity mirror lamp

INTERIOR ROOM LAMP BATTERY SAVER FUNCTION

- When the ignition switch is turned OFF, BCM operates the timer for a period of time to cut the interior room lamp power supply.
- BCM restart the timer when any of the following signals changes while operating the timer.
 - Ignition switch status
 - Door switch signal (ALL)
 - Door lock/unlock signal (Remote keyless entry receiver, each request switch, key cylinder lock/unlock switch, door lock/unlock switch)
 - Back door switch signal
 - Key switch signal (Key slot)
- BCM provides the interior room lamp power supply continuously when the ignition switch position is other than OFF.

NOTE:


INTERIOR ROOM LAMP BATTERY SAVER SYSTEM

< SYSTEM DESCRIPTION >

Each function of interior room lamp battery saver can be set by CONSULT-III. Refer to [INL-16, "BATTERY SAVER : CONSULT-III Function \(BCM - BATTERY SAVER\)"](#).

Component Parts Location

INFOID:000000006262811



- | | | |
|-----------------------------------|---------------------------------|-----------------------|
| 1. Personal lamp | 2. Request switch | 3. Step lamp |
| 4. Door switch | 5. Key cylinder switch | 6. Key slot |
| 7. Map lamp | 8. Vanity mirror lamp | 9. Door lock switch |
| 10. Remote keyless entry receiver | 11. BCM | 12. Luggage room lamp |
| 13. Back door switch | | |
| A. Over the glove box | B. Behind the combination meter | C. Back door |
| D. Back door lock assembly | | |

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

INL

INTERIOR ROOM LAMP BATTERY SAVER SYSTEM

< SYSTEM DESCRIPTION >

Component Description

INFOID:000000006262812

Part	Description
BCM	Operates the interior room lamp battery saver depending on the vehicle condition to cut the interior room lamp power supply.
Remote keyless entry receiver	<ul style="list-style-type: none">• Receives the lock/unlock signal from keyfob.• Transmits the lock/unlock signal to BCM.
• Request switch • Key cylinder lock/unlock switch • Door lock/unlock switch	Inputs the lock/unlock signal to BCM.
• Door switch • Back door switch	Inputs a switch signal to BCM.
Key slot	Inputs the Intelligent Key in status to BCM.


ILLUMINATION CONTROL SYSTEM

< SYSTEM DESCRIPTION >

ILLUMINATION CONTROL SYSTEM

System Diagram

INFOID:0000000006262813



JPLIA0855GB

System Description

INFOID:0000000006262814

OUTLINE

Each illumination lamp is controlled by each function of BCM, IPDM E/R and combination meter.

Control by BCM

- Combination switch reading function
- Headlamp control function

Control by IPDM E/R

- Relay control function

Control by combination meter

- Meter illumination control function (Refer to [MWI-24, "METER ILLUMINATION CONTROL : System Description".](#))

ILLUMINATION CONTROL

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits position light request signal to IPDM E/R and combination meter according to tail lamp ON condition.

INL

Tail lamp ON condition

- Lighting switch 1ST
- Lighting switch 2ND
- Lighting switch AUTO, and the auto light function ON judgment (With auto light system)
- IPDM E/R turns the integrated tail lamp relay ON according to position light request signal. It provides the power supply to each illumination lamp.
- Combination meter enters in the nighttime mode according to position light request signal. Under the nighttime mode the combination meter controls the illuminance by controlling the each illumination lamp (ground side).

M

N

O


P

ILLUMINATION CONTROL SYSTEM

< SYSTEM DESCRIPTION >

Component Parts Location

INFOID:000000006262815



- | | | |
|----------------------|--------------------------------|-----------------------|
| 1. Combination meter | 2. Illumination control switch | 3. Combination switch |
| 4. IPDM E/R | 5. BCM | |
| A Engine room (LH) | B Behind the combination meter | |

Component Description

INFOID:000000006262816

Part	Description
BCM	<ul style="list-style-type: none">Detects each switch condition by the combination switch reading function.Judges the illumination lamp ON/OFF status depending on the vehicle condition. And then it transmits position light request signal to IPDM E/R and combination meter (with CAN communication).
IPDM E/R	Controls the integrated relay according to the request from BCM (with CAN communication).
Combination meter	<ul style="list-style-type: none">Enters in nighttime mode according to the request from BCM (with CAN communication).Controls the each illumination in the nighttime mode. Refer to MWI-24, "METER ILLUMINATION CONTROL : System Description".
Combination switch (Lighting & turn signal switch)	Refer to BCS-10, "System Description" .

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM)

INFOID:0000000006262817

APPLICATION ITEM

CONSULT-III performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
Work Support	Changes the setting for each system function.
Self Diagnostic Result	Displays the diagnosis results judged by BCM.
CAN Diag Support Monitor	Monitors the reception status of CAN communication viewed from BCM. Refer to CONSULT-III operation manual.
Data Monitor	The BCM input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from BCM.
Ecu Identification	The BCM part number is displayed.
Configuration	<ul style="list-style-type: none"> • Read and save the vehicle specification. • Write the vehicle specification when replacing BCM.

SYSTEM APPLICATION

BCM can perform the following functions for each system.

NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

x: Applicable item

System	Sub system selection item	Diagnosis mode		
		Work Support	Data Monitor	Active Test
Door lock	DOOR LOCK	x	x	x
Rear window defogger	REAR DEFOGGER		x	x
Warning chime	BUZZER		x	x
Interior room lamp timer	INT LAMP	x	x	x
Exterior lamp	HEAD LAMP	x	x	x
Wiper and washer	WIPER	x ^{*1}	x	x
Turn signal and hazard warning lamps	FLASHER	x	x	x
—	AIR CONDITIONER ^{*2}			
• Intelligent Key system • Engine start system	INTELLIGENT KEY	x	x	x
Combination switch	COMB SW		x	
Body control system	BCM	x		
NVIS - NATS	IMMU		x	x
Interior room lamp battery saver	BATTERY SAVER	x	x	x
Back door opener system	TRUNK		x	x
Vehicle security system	THEFT ALM	x	x	x
RAP system	RETAINED PWR		x	
Signal buffer system	SIGNAL BUFFER		x	x
TPMS	TPMS (AIR PRESSURE MONITOR)	x	x	x

NOTE:

- *1: For models with rain sensor this mode is displayed, but is not used.
- *2: This item is displayed, but is not used.

FREEZE FRAME DATA (FFD)

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays on CONSULT-III.

CONSULT screen item	Indication/Unit	Description	
Vehicle Speed	km/h	Vehicle speed of the moment a particular DTC is detected	
Odo/Trip Meter	km	Total mileage (Odometer value) of the moment a particular DTC is detected	
Vehicle Condition	SLEEP>LOCK	Power position status of the moment a particular DTC is detected	While turning BCM status from low power consumption mode to normal mode (Power supply position is "LOCK")
	SLEEP>OFF		While turning BCM status from low power consumption mode to normal mode (Power supply position is "OFF".)
	LOCK>ACC		While turning power supply position from "LOCK" to "ACC"
	ACC>ON		While turning power supply position from "ACC" to "IGN"
	RUN>ACC		While turning power supply position from "RUN" to "ACC" (Vehicle is stopping and selector lever is except P position.)
	CRANK>RUN		While turning power supply position from "CRANKING" to "RUN" (From cranking up the engine to run it)
	RUN>URGENT		While turning power supply position from "RUN" to "ACC" (Emergency stop operation)
	ACC>OFF		While turning power supply position from "ACC" to "OFF"
	OFF>LOCK		While turning power supply position from "OFF" to "LOCK"
	OFF>ACC		While turning power supply position from "OFF" to "ACC"
	ON>CRANK		While turning power supply position from "IGN" to "CRANKING"
	OFF>SLEEP		While turning BCM status from normal mode (Power supply position is "OFF".) to low power consumption mode
	LOCK>SLEEP		While turning BCM status from normal mode (Power supply position is "LOCK".) to low power consumption mode
	LOCK		Power supply position is "LOCK" (Ignition switch OFF with steering is locked.)
	OFF		Power supply position is "OFF" (Ignition switch OFF with steering is unlocked.)
	ACC		Power supply position is "ACC" (Ignition switch ACC)
	ON		Power supply position is "IGN" (Ignition switch ON with engine stopped)
	ENGINE RUN		Power supply position is "RUN" (Ignition switch ON with engine running)
	CRANKING		Power supply position is "CRANKING" (At engine cranking)
IGN Counter	0 - 39	<p>The number of times that ignition switch is turned ON after DTC is detected</p> <ul style="list-style-type: none"> • The number is 0 when a malfunction is detected now. • The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. • The number is fixed to 39 until the self-diagnosis results are erased if it is over 39. 	

INT LAMP


DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

INT LAMP : CONSULT-III Function (BCM - INT LAMP)

INFOID:0000000006262818

WORK SUPPORT



Service item	Setting item	Setting	
SET I/L D-UNLCK INTCON	ON*	With the interior room lamp timer function	
	OFF	Without the interior room lamp timer function	
ROOM LAMP TIMER SET	MODE 2	7.5 sec.	Sets the interior room lamp ON time. (Timer operating time)
	MODE 3*	15 sec.	
	MODE 4	30 sec.	
ROOM LAMP ON TIME SET	MODE 1	0.5 sec.	Sets the interior room lamp gradual brightening time.
	MODE 2*	1 sec.	
	MODE 3	2 sec.	
	MODE 4	3 sec.	
	MODE 5	0 sec.	
ROOM LAMP OFF TIME SET	MODE 1	0.5 sec.	Sets the interior room lamp gradual dimming time.
	MODE 2	1 sec.	
	MODE 3	2 sec.	
	MODE 4*	3 sec.	
	MODE 5	0 sec.	
R LAMP TIMER LOGIC SET	MODE 1*	Interior room lamp timer activates with synchronizing all doors.	
	MODE 2	Interior room lamp timer activates with synchronizing the driver door only.	

*: Factory setting

DATA MONITOR

Monitor item [Unit]	Description
REQ SW-DR [On/Off]	The switch status input from request switch (driver side)
REQ SW-AS [On/Off]	The switch status input from front request switch (passenger side)
PUSH SW [On/Off]	The switch status input from push-button ignition switch
KEY SW-SLOT [On/Off]	Key switch status input from key slot

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitor item [Unit]	Description
DOOR SW-DR [On/Off]	The switch status input from front door switch (driver side)
DOOR SW-AS [On/Off]	The switch status input from front door switch (passenger side)
DOOR SW-RR [On/Off]	The switch status input from rear door switch RH
DOOR SW-RL [On/Off]	The switch status input from rear door switch LH
DOOR SW-BK [On/Off]	NOTE: The item is indicated, but not monitored.
CDL LOCK SW [On/Off]	Lock switch status received from door lock/unlock switch by power window switch serial link
CDL UNLOCK SW [On/Off]	Unlock switch status received from door lock/unlock switch by power window switch serial link
KEY CYL LK-SW [On/Off]	Lock switch status received from key cylinder lock/unlock switch by power window switch serial link
KEY CYL UN-SW [On/Off]	Unlock switch status received from key cylinder lock/unlock switch by power window switch serial link
BACK DOOR SW [On/Off]	The switch status input from back door switch
RKE-LOCK [On/Off]	Lock signal status received from remote keyless entry receiver
RKE-UNLOCK [On/Off]	Unlock signal status received from remote keyless entry receiver

ACTIVE TEST

Test item	Operation	Description
INT LAMP	On	Outputs the interior room lamp control signal to turn map lamp and personal lamp ON (Map lamp switch is in DOOR position).
	Off	Stops the interior room lamp control signal to turn map lamp and personal lamp OFF.
STEP LAMP TEST	On	Outputs the step lamp control signal to turn step lamp ON.
	Off	Stops the step lamp control signal to turn step lamp OFF.
LUGGAGE LAMP TEST	On	NOTE: The item is displayed, but cannot be tested.
	Off	

BATTERY SAVER

BATTERY SAVER : CONSULT-III Function (BCM - BATTERY SAVER)

INFOID:0000000006262819

WORK SUPPORT

Service item	Setting item	Setting
BATTERY SAVER SET	On*	With the exterior lamp battery saver function
	Off	Without the exterior lamp battery saver function
ROOM LAMP BAT SAV SET	On*	With the interior room lamp battery saver function
	Off	Without the interior room lamp battery saver function
ROOM LAMP TIMER SET	MODE 1	30 min.
	MODE 2	60 min.
	MODE 3*	15 min.

*: Factory setting

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

DATA MONITOR

Monitor item [Unit]	Description
REQ SW-DR [On/Off]	The switch status input from request switch (driver side)
REQ SW-AS [On/Off]	The switch status input from front request switch (passenger side)
REQ SW-RR [On/Off]	NOTE: The item is indicated, but not monitored.
REQ SW-RL [On/Off]	
PUSH SW [On/Off]	The switch status input from push-button ignition switch
KEY SW-SLOT [On/Off]	Key switch status input from key slot
UNLK SEN-DR [On/Off]	Driver door unlock status input from unlock sensor
DOOR SW-DR [On/Off]	The switch status input from front door switch (driver side)
DOOR SW-AS [On/Off]	The switch status input from front door switch (passenger side)
DOOR SW-RR [On/Off]	The switch status input from rear door switch RH
DOOR SW-RL [On/Off]	The switch status input from rear door switch LH
DOOR SW-BK [On/Off]	NOTE: The item is indicated, but not monitored.
CDL LOCK SW [On/Off]	Lock switch status received from door lock/unlock switch by power window switch serial link
CDL UNLOCK SW [On/Off]	Unlock switch status received from door lock/unlock switch by power window switch serial link
KEY CYL LK-SW [On/Off]	Lock switch status received from key cylinder lock/unlock switch by power window switch serial link
KEY CYL UN-SW [On/Off]	Unlock switch status received from key cylinder lock/unlock switch by power window switch serial link
BACK DOOR SW [On/Off]	The switch status input from back door switch
RKE-LOCK [On/Off]	Lock signal status received from remote keyless entry receiver
RKE-UNLOCK [On/Off]	Unlock signal status received from remote keyless entry receiver

ACTIVE TEST

Test item	Operation	Description
BATTERY SAVER	Off	Cuts the interior room lamp power supply to turn interior room lamp OFF.
	On	Outputs the interior room lamp power supply to turn interior room lamp ON.*

*: Each lamp switch is in ON position.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT

BCM

BCM : Diagnosis Procedure

INFOID:0000000006262820

1. CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

Signal name	Fuse and fusible link No.
Battery power supply	L
	10

Is the fuse fusing?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit if a fuse or fusible link is blown.

NO >> GO TO 2.

2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connectors.
3. Check voltage between BCM harness connector and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
BCM		Ground
Connector	Terminal	
M118	1	Battery voltage
M119	11	

Is the measurement value normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3. CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

BCM		Continuity
Connector	Terminal	
M119	13	Existed

Does continuity exist?

YES >> INSPECTION END

NO >> Repair harness or connector.

INTERIOR ROOM LAMP POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

INTERIOR ROOM LAMP POWER SUPPLY CIRCUIT

Description

INFOID:0000000006262821

Provides the interior room lamp power supply. Also cuts the power supply when the interior room lamp battery saver activating.

Component Function Check

INFOID:0000000006262822

1. CHECK INTERIOR ROOM LAMP POWER SUPPLY FUNCTION

① CONSULT-III ACTIVE TEST

1. Turn the ignition switch ON.
2. Turn each interior room lamp ON.
 - Map lamp
 - Personal lamp
 - Step lamp
 - Vanity mirror lamp
 - Luggage room lamp
3. Select "BATTERY SAVER" of BCM (BATTERY SAVER) active test item.
4. With operating the test items, check that each interior room lamp turns ON/OFF.

Off : Interior room lamp OFF

On : Interior room lamp ON

Does the interior room lamp turn ON/OFF?

YES >> Interior room lamp power supply circuit is normal.

NO >> Refer to [INL-19, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000006262823

1. CHECK INTERIOR ROOM LAMP POWER SUPPLY OUTPUT

① CONSULT-III ACTIVE TEST

1. Turn the ignition switch ON.
2. Select "BATTERY SAVER" of BCM (BATTERY SAVER) active test item.
3. With operating the test item, check voltage between BCM harness connector and the ground.

Terminals		Test item	Voltage (Ap- prox.)
(+)	(-)		
BCM		BATTERY SAVER	
Connector	Terminal		
M119	4	Ground	
		Off	0 V
		On	Battery volt- age

Is the measurement value normal?

YES >> GO TO 2.

NO >> Replace BCM.

2. CHECK INTERIOR ROOM LAMP POWER SUPPLY OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the following connectors.
 - Map lamp
 - Personal lamp
 - Vanity mirror lamp (driver side)
 - Vanity mirror lamp (passenger side)
 - Luggage room lamp (RH)
 - Luggage room lamp (LH)
 - Step lamp (driver side)

INL

M

N

O

P

INTERIOR ROOM LAMP POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

- Step lamp (passenger side)
3. Check continuity between BCM harness connector and each interior room lamp harness connector.

BCM		Each interior room lamp		Continuity
Connector	Terminal	Connector	Terminal	
M119	4	Map lamp	R19	1
		Personal lamp	R21	1
		Vanity mirror lamp (driver side)	R24	2
		Vanity mirror lamp (passenger side)	R10	2
		Luggage room lamp (RH)	D156	2
		Luggage room lamp (LH)	D157	2
		Step lamp (driver side)	D17	1
		Step lamp (passenger side)	D51	1

Does continuity exist?

YES >> GO TO 3.

NO >> Repair the harnesses or connectors.

3.CHECK INTERIOR ROOM LAMP POWER SUPPLY SHORT CIRCUIT

Check continuity between BCM harness connector and the ground.

BCM		Ground	Continuity
Connector	Terminal		
M119	4		Not existed

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Check that each interior room lamp has no internal short circuit.

INTERIOR ROOM LAMP CONTROL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

INTERIOR ROOM LAMP CONTROL CIRCUIT

Description

INFOID:0000000006262824

Controls each interior room lamp (ground side) by PWM signal.

NOTE:

PWM signal control period is approximately 250 Hz (in the gradual brightening/dimming).

Component Function Check

INFOID:0000000006262825

CAUTION:

Before performing the diagnosis, check that the following is normal.

- Interior room lamp power supply
- Map lamp bulb
- Personal lamp bulb

1.CHECK INTERIOR ROOM LAMP CONTROL FUNCTION

(H)CONSULT-III ACTIVE TEST

1. Switch the map lamp switch to DOOR.
2. Turn the ignition switch ON.
3. Select "INT LAMP" of BCM (INT LAMP) active test item.
4. With operating the test items, check that each interior room lamp turns ON/OFF (gradual brightening/dimming).

On : Interior room lamp gradual brightening

Off : Interior room lamp gradual dimming

Does the interior room lamp turns ON/OFF (gradual brightening/dimming)?

YES >> Interior room lamp control circuit is normal.

NO >> Refer to [INL-21, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000006262826

1.CHECK INTERIOR ROOM LAMP CONTROL OUTPUT

(H)CONSULT-III ACTIVE TEST

1. Turn ignition switch OFF.
2. Remove all the bulbs of map lamp and personal lamp.
3. Select "INT LAMP" of BCM (INT LAMP) active test item.
4. With operating the test item, check continuity between BCM harness connector and ground.

BCM		Ground	Test item	Continuity	
Connector	Terminal		INT LAMP		
M119	19		On	Existed	
			Off	Not existed	

Is the measurement value normal?

YES >> GO TO 2.

Fixed ON>>GO TO 3.

Fixed OFF>>Replace BCM.

2.CHECK INTERIOR ROOM LAMP CONTROL OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector, map lamp connector and personal lamp connector.
3. Check continuity between BCM harness connector, map lamp harness connector and personal lamp harness connector.

INTERIOR ROOM LAMP CONTROL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

BCM		Map lamp/personal lamp			Continuity
Connector	Terminal	Connector		Terminal	
M119	19	Map lamp	R19	2	Existed
		Personal lamp	R21	3	

Does continuity exist?

YES >> Replace the map lamp or the personal lamp.

NO >> Repair the harnesses or connectors.

3.CHECK INTERIOR ROOM LAMP CONTROL SHORT CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector, map lamp connector and personal lamp connector.
3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M119	19		Not existed

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Replace BCM.

STEP LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

STEP LAMP CIRCUIT

Description

INFOID:0000000006262827

Controls the step lamp (ground side) to turn the step lamp ON and OFF.

Component Function Check

INFOID:0000000006262828

CAUTION:

Before performing the diagnosis, check that the following is normal.

- Interior room lamp power supply
- Step lamp bulb

1.CHECK STEP LAMP OPERATION

(B)CONSULT-III ACTIVE TEST

1. Turn the ignition switch ON.
2. Select "STEP LAMP TEST" of BCM (INT LAMP) active test item.
3. With operating the test items, check that step lamp turns ON/OFF.

On : Step lamp ON

Off : Step lamp OFF

Does the step lamp turn ON/OFF?

YES >> Step lamp circuit is normal.

NO >> Refer to [INL-23, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000006262829

1.CHECK STEP LAMP OUTPUT

(B)CONSULT-III ACTIVE TEST

1. Turn the ignition switch OFF.
2. Remove the step lamp bulbs (driver side and passenger side).
3. Turn the ignition switch ON.
4. Select "STEP LAMP TEST" of BCM (INT LAMP) active test item.
5. With operating the test item, check continuity between BCM harness connector and the ground.

BCM		Ground	Test item	Continuity
Connector	Terminal		STEP LAMP TEST	
M119	7		On	Existed
			Off	Not existed

Is the measurement value normal?

YES >> GO TO 2.

Fixed ON>>GO TO 3.

Fixed OFF>>Replace BCM.

2.CHECK STEP LAMP OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector, and step lamp connector.
3. Check continuity between BCM harness connector and step lamp harness connector.

BCM		Step lamp			Continuity
Connector	Terminal	Connector	Terminal		
M119	7	Driver side	D17	2	Existed
		Passen- ger side	D51	2	

STEP LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Does continuity exist?

YES >> Replace step lamp.

NO >> Repair harnesses or connectors.

3.CHECK STEP LAMP SHORT CIRCUIT

1. Turn the ignition switch OFF.
2. Check continuity between BCM harness connector and the ground.

BCM		Ground	Continuity
Connector	Terminal		
M119	7		Not existed

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Replace BCM.

PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT

Description

INFOID:0000000006262830

Provides the power supply and the ground to control the push-button ignition switch illumination.

Component Function Check

INFOID:0000000006262831

1.CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION OPERATION

(CONSULT-III ACTIVE TEST

1. Turn the ignition switch ON.
2. Select "ENGINE SW ILLUMI" of BCM (INTELLIGENT KEY) active test item.
3. With operating the test items, check that the push-button ignition switch illumination turns ON/OFF

On : Push-button ignition switch illumination ON

Off : Push-button ignition switch illumination OFF

Does the push-button ignition switch illumination turn ON/OFF?

YES >> Push-button ignition switch illumination circuit is normal.

NO >> Refer to [INL-25. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000006262832

1.CHECK ILLUMINATION CONTROL SWITCHING OPERATION

1. Turn the ignition switch ON.
2. With operating the lighting switch, check that the push-button ignition switch illumination turns ON/OFF

Condition	Push-button ignition switch illumination
• Ignition switch ON • Lighting switch 1ST	ON
• Ignition switch OFF • Lighting switch OFF • Driver door LOCK	OFF

Does the push-button ignition switch illumination turn ON/OFF?

YES >> GO TO 2.

NO >> GO TO 3.

2.CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector and the push-button ignition switch connector.
3. Check continuity between BCM harness connector and the push-button ignition switch harness connector.

BCM		Push-button ignition switch		Continuity
Connector	Terminal	Connector	Terminal	
M119	14	M101	2	Existed

Does the continuity exist?

YES >> Replace BCM.

NO >> Repair the harness or the connector.

3.CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION POWER SUPPLY OUTPUT

(CONSULT-III ACTIVE TEST

1. Turn the ignition switch ON.
2. Select "ENGINE SW ILLUMI" of BCM (INTELLIGENT KEY) active test item.
3. With operating the test item, check voltage between BCM harness connector and the ground.

PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Terminals		Test item	Voltage (Ap-prox.)
(+)	(-)		
BCM	Ground	ENGINE SW ILLUMI	
Connector		ON	5 V
M123		OFF	0 V

Is the measurement value normal?

YES >> GO TO 4.

NO >> GO TO 5.

4.CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION POWER SUPPLY OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector and the push-button ignition switch connector.
3. Check continuity between BCM harness connector and the push-button ignition switch harness connector.

BCM		Push-button ignition switch		Continuity
Connector	Terminal	Connector	Terminal	
M123	133	M101	3	Existed

Does the continuity exist?

YES >> Replace push-button ignition switch.

NO >> Repair the harness or the connector.

5.CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION POWER SUPPLY SHORT CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector and the push-button ignition switch connector.
3. Check continuity between BCM harness connector and the ground.

BCM		Ground	Continuity
Connector	Terminal		
M123	133		Not existed

Does the continuity exist?

YES >> Repair the harness or the connector.

NO >> Replace BCM.


INTERIOR ROOM LAMP CONTROL SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

INTERIOR ROOM LAMP CONTROL SYSTEM

Wiring Diagram - INTERIOR ROOM LAMP -

INFOID:0000000006262833




2010/09/06

JCLWM6139GB

INTERIOR ROOM LAMP CONTROL SYSTEM


< DTC/CIRCUIT DIAGNOSIS >



JCLWM6140GB

INTERIOR ROOM LAMP CONTROL SYSTEM

< DTC/CIRCUIT DIAGNOSIS >



JCLWM6141GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
INL
Z

INTERIOR ROOM LAMP CONTROL SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

INTERIOR ROOM LAMP		B11		B34		B71		B73	
Connector No.	Wire to Wire	Connector No.	Front Door Switch (Driver Side)	Connector No.	Wire to Wire	Connector No.	Signal Name [Specification]	Connector No.	Signal Name [Specification]
Connector Name	TH85MW-CS 9	Connector Type	A05FW	Connector Name	NS16MW-CS	Connector Type	-	Connector Name	-
47	SB	48	SHIELD	49	B	50	R/W	51	R/L
52	G	53	Y	54	LG	55	BR	56	P
57	L	58	R	59	SHIELD	60	B	61	R/L
62	R/W	63	LG	64	Y	65	BR	66	V
67	GR	68	R	69	SHIELD	70	WR	71	BR
72	W/L	73	LG	74	SB	75	L	76	G
77	V	78	SB	79	B	80	W	81	R
82	LG	83	W	84	O	85	G	86	SB
88	P	89	BR	90	Y	91	G	92	BR
94	Y	95	BR	96	GR	97	R	98	LG
99	O	99	LG	99	O	99	LG	99	O

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
1	SHIELD	-	2	SB	-
2	B	-	3	Y	-
3	R/L	-	4	SE	-
4	R/W	-	5	R	-
5	SB	-	6	V	-
6	P	-	7	BR	-
7	V	-	8	LG	-
8	SHIELD	-	9	L	-
9	BR/L	-	10	R	-
10	Y/G	-	11	P	-
11	Y/L	-	12	W	-
12	W/L	-	13	GR	-
13	L	-	14	G	-
14	BR	-	15	Y	-
15	SB	-	16	BR	-
16	BR	-			
17	V	-			
18	SB	-			
19	R	-			
20	P	-			
21	LG	-			
22	W	-			
23	Y	-			
24	GR	-			
25	Y	-			
26	W/L	-			
27	P	-			
28	LG	-			
29	BR	-			
30	O	-			
31	O	-			
32	BR	-			
33	SB	-			
34	SB	-			
35	SHIELD	-			
36	L/O	-			
37	LG	-			
38	P	-			
39	Y	-			
40	GR	-			
41	GR	-			
42	SB	-			
43	LG	-			

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-	2	L	-
2	LG	-			


JCLWM6142GB

INTERIOR ROOM LAMP CONTROL SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

INTERIOR ROOM LAMP

Connector No.	BZ19
Connector Name	WIRE TO WIRE
Connector Type	TH32MW-NH




Terminal No.	Color of Wire	Signal Name [Specification]
1	W/R	-
2	B/R	-
3	SHIELD	-
4	W/R	-
5	B/R	-
6	SHIELD	-
7	GR/V	-
8	W/L	-
9	SHIELD	-
10	GR/V	-
11	W/L	-
12	SHIELD	-
13	SB	-
14	Y	-
15	R	-
16	W	-
17	G	-
18	P	-
19	V	-
20	BR	-

Connector No.	BZ21
Connector Name	REAR DOOR SWITCH RH
Connector Type	A03FW



Terminal No.	Color of Wire	Signal Name [Specification]
2	W	-

Connector No.	D6
Connector Name	POWER WINDOW MAIN SWITCH
Connector Type	NS30IW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
17	LG	-

Connector No.	D5
Connector Name	POWER WINDOW MAIN SWITCH
Connector Type	NS16FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	-

Connector No.	D9
Connector Name	FRONT DOOR LOCK ASSEMBLY (DRIVER SIDE)
Connector Type	E00FGY-RS



Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	-

Connector No.	BZ20
Connector Name	FRONT DOOR SWITCH (PASSENGER SIDE)
Connector Type	A03FW



Terminal No.	Color of Wire	Signal Name [Specification]
2	R	-

Connector No.	D17
Connector Name	STEP LAMP (DRIVER SIDE)
Connector Type	G00FW



A B C D M T G I Z O P INL

JCLWM6143GB

INTERIOR ROOM LAMP CONTROL SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

INTERIOR ROOM LAMP			
Connector No.	D21	Signal Name [Specification]	
Connector Name	WIRE TO WIRE		
Connector Type	TH40FW-CS15		
Terminal No.	Color of Wire	Signal Name [Specification]	
1	V	-	
2	G	-	
3	P	-	
4	B	-	
5	W	-	
6	SB	-	
7	P	-	
8	BR	-	
9	GR	-	
10	V	-	
11	O	-	
12	Y	-	
13	G	-	
14	BR	-	
15	LG	-	
16	G	-	
17	Y	-	
18	GR	-	
19	BR	-	
20	LG	-	
21	P	-	
22	V	-	
23	W	-	
24	BR	-	
25	LG	-	
26	G	-	
27	Y	-	
28	GR	-	
29	BR	-	
30	LG	-	
31	Y	-	
32	GR	-	
33	G	-	
34	Y	-	
35	LG	-	
36	P	-	
37	V	-	
38	BR	-	
39	LG	-	
40	G	-	
41	Y	-	
42	GR	-	
43	LG	-	
44	W	-	
45	SB	-	
46	R	-	
47	V	-	
48	BR	-	
49	LG	-	
50	G	-	
51	Y	-	
52	GR	-	
53	L	- [With automatic drive positioner] - [Without automatic drive positioner]	
54	P	- [With automatic drive positioner] - [Without automatic drive positioner]	
55	SB	- [With automatic drive positioner] - [Without automatic drive positioner]	
Connector No.	D45	Signal Name [Specification]	
Connector Name	FRONT POWER WINDOW SWITCH (PASSENGER SIDE)		
Connector Type	NS16FW-CS		
Terminal No.	Color of Wire	Signal Name [Specification]	
1	LG	-	
2	W	-	
3	V	-	
4	R	-	
5	L	-	
6	LG	-	
7	P	-	
8	B	-	
9	Y	-	
10	GR	-	
11	O	-	
12	W	-	
13	GR	-	
14	G	-	
15	O	-	
16	BR	-	
Connector No.	D156	Signal Name [Specification]	
Connector Name	JUGGAGE ROOM LAMP RH		
Connector Type	CJ40FW		
Terminal No.	Color of Wire	Signal Name [Specification]	
1	LG	-	
2	R	-	
3	W	-	
4	LG	-	
Connector No.	D157	Signal Name [Specification]	
Connector Name	STEP LAMP (PASSENGER SIDE)		
Connector Type	CQDFW		
Terminal No.	Color of Wire	Signal Name [Specification]	
1	G	-	
2	R	-	
3	W	-	
4	LG	-	

JCLWM6144GB

INTERIOR ROOM LAMP CONTROL SYSTEM

< DTC/CIRCUIT DIAGNOSIS >


JCLWM6145GB

INTERIOR ROOM LAMP CONTROL SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

INTERIOR ROOM | AMP

Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Type	TH10FW-CS10-M3



72	BR
73	L
74	W
75	BR
76	R
77	G
78	Y
79	G
80	R
81	W
82	W
83	O



4	6	P	-
5	0	V	-
5	1	O	- [With automatic drive positioner]
5	2	GR	- [Without automatic drive positioner]
5	2	R	- [With automatic drive positioner]
5	3	L	- [Without automatic drive positioner]
5	3	V	- [With automatic drive positioner]
5	4	LG	- [Without automatic drive positioner]
5	4	G	- [Without automatic drive positioner]
5	5	SB	- [With automatic drive positioner]
5	5	O	- [Without automatic drive positioner]



JCLWM6146GB

INTERIOR ROOM LAMP CONTROL SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

INTERIOR ROOM LAMP

Connector No.	M44
Connector Name	WIRE TO WIRE
Connector Type	TH32FW-NH



Terminal No.	Signal Name [Specification]
1	G
2	R
3	SHIELD
4	B
5	W
6	SHIELD
7	L
8	R
9	SHIELD
10	V
11	LG
12	SHIELD
13	P
14	SB
15	SB
16	R
17	V
18	P
19	P
20	LG
21	Y
22	O
23	LG
24	SB
25	Y
26	Y
27	Y
28	R
29	LG
30	O
31	Y
32	BR
33	R
34	Y
35	SHIELD
36	G
37	Y
38	O
39	LG
40	O
41	LG
42	SB
43	G
44	LG
45	SB
46	G
47	SB
48	SHIELD
49	R
50	LG
51	V
52	B
53	BR
54	B
55	G
56	P
57	L
58	SB
59	SHIELD
60	B
61	R

Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	BAT
2	SE	CLOCK
3	O	DATA
5	GR	ILL BAT
6	R	ILL
7	B	GND
11	Y	KEY SWITCH SIGNAL



Terminal No.	Color of Wire	Signal Name [Specification]
1	1	
2	2	
3	3	
4	4	
5	5	
6	6	
7	7	
8	8	

[M10]

Connector No.

Connector Name

PUSH-BUTTON IGNITION SWITCH

Connector Type

TK09FBR

Terminal No.	Color of Wire	Signal Name [Specification]
1	1	
2	2	
3	3	
4	4	
5	5	
6	6	
7	7	
8	8	

[M10]


Connector No.

Connector Name

-

Connector Type

-



Terminal No.	Color of Wire	Signal Name [Specification]
1	1	
2	2	
3	3	
4	4	
5	5	
6	6	
7	7	
8	8	

[M10]

Connector No.

KEY SLOT

Connector Type

TH12FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	1	
2	2	
3	3	
4	4	
5	5	
6	6	
7	7	
8	8	
9	9	
10	10	
11	11	
12	12	
13	13	
14	14	
15	15	
16	16	
17	17	
18	18	
19	19	
20	20	
21	21	
22	22	
23	23	
24	24	
25	25	
26	26	
27	27	
28	28	
29	29	
30	30	
31	31	
32	32	
33	33	
34	34	
35	35	
36	36	
37	37	
38	38	
39	39	
40	40	
41	41	
42	42	
43	43	
44	44	
45	45	
46	46	
47	47	
48	48	
49	49	
50	50	
51	51	
52	52	
53	53	
54	54	
55	55	
56	56	
57	57	
58	58	
59	59	
60	60	
61	61	

JCLWM6147GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z
INL

INTERIOR ROOM LAMP CONTROL SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

INTERIOR ROOM LAMP			
Connector No.	M103	Signal Name [Specification]	
Connector Name	COMBINATION SWITCH	Terminal No.	Color of Wire
Connector Type	TH16FW-NH	1	G
		2	Y
		3	O
		4	W
		5	V
		6	B
		7	GR
		8	L
		9	SB
		10	P
		11	O
		12	W
		13	R
		14	P
Connector No.	M119	Signal Name [Specification]	
Connector Name	BCM (BODY CONTROL MODULE)	Terminal No.	Color of Wire
Connector Type	NS16FW-CS	4	P
		5	G
		7	Y
		8	V
		9	G
		10	P
		11	LG
		13	B
		14	O
		15	L
		17	G
		18	BR
		19	Y
Connector No.	M121	Signal Name [Specification]	
Connector Name	BCM (BODY CONTROL MODULE)	Terminal No.	Color of Wire
Connector Type	MS3FB-LC	1	W
		2	GR
		3	L
		4	LG
		5	B
		6	W
		7	GR
		8	P
		9	L
		91	GR
		92	R
		93	P
		96	L
		98	Y
		99	V
		101	P
		102	W
		103	Y
		107	O
		108	P
		109	SB
		110	G
Connector No.	M122	Signal Name [Specification]	
Connector Name	BCM (BODY CONTROL MODULE)	Terminal No.	Color of Wire
Connector Type	TH40FB-NH	1	W
		2	GR
		3	L
		4	LG
		5	B
		6	W
		7	GR
		8	P
		9	L
		10	Y
		11	GR
		12	LG
		13	B
		14	W
		15	GR
		16	LG
		17	Y
		18	GR
		19	LG
		20	Y
		21	GR
		22	LG
		23	B
		24	W
		25	GR
		26	LG
		27	Y
		28	GR
		29	LG
		30	B
		31	W
		32	GR
		33	LG
		34	Y
		35	GR
		36	LG
		37	B
		38	W
		39	GR
		40	LG
		41	Y
		42	GR
		43	LG
		44	B
		45	W
		46	GR
		47	LG
		48	Y
		49	GR
		50	LG
		51	B
		52	W
		53	GR
		54	LG
		55	Y
		56	GR
		57	LG
		58	B
		59	W
		60	GR
		61	LG
		62	Y
		63	GR
		64	LG
Connector No.	M123	Signal Name [Specification]	
Connector Name	BCM (BODY CONTROL MODULE)	Terminal No.	Color of Wire
Connector Type	MS3FB-LC	1	W
		2	GR
		3	L
		4	LG
		5	B
		6	W
		7	GR
		8	P
		9	L
		91	GR
		92	R
		93	P
		96	L
		98	Y
		99	V
		101	P
		102	W
		103	Y
		107	O
		108	P
		109	SB
		110	G

JCLWM6148GB

INTERIOR ROOM LAMP CONTROL SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

A

B

C

D

E

F

G

H

I

J

K

L

M

N

O

P

INL

INTERIOR ROOM LAMP

Connector No.	R1
Connector Name	WIRE TO WIRE
Connector Type	TH10FW-NH

HS.

Terminal No.	Color of Wire	Signal Name [Specification]
1	W	- [With navigation system] - [Without navigation system]
2	R/W	- [With navigation system] - [Without navigation system]
3	SHIELD	-
4	R/L	-
5	B	-
6	Y	-
7	R/L	-
8	Y/R	-
9	B/Y	-
10	B	-
11	Y	-
12	P/W	-
13	B	-
14	R/Y	-
15	B/R	-
16	R	-

Connector No.	R19
Connector Name	MAP LAMP
Connector Type	TK108FCY

HS.

Terminal No.	Color of Wire	Signal Name [Specification]
1	P/W	-
2	Y	-
3	B	-
4	SB	-
5	RY	-
6	R/L	-
7	Y	-
8	R/L	-
9	Y/R	-
10	B/Y	-
11	B	-
12	Y	-
13	P/W	-
14	B	-
15	R/Y	-
16	B/R	-
17	R	-

Connector No.	R24
Connector Name	VANITY MIRROR LAMP (DRIVER SIDE)
Connector Type	MCA02FW

HS.

Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	P/W	-

Connector No.	R21
Connector Name	PERSONAL LAMP
Connector Type	TH10FP-HH

HS.

Terminal No.	Color of Wire	Signal Name [Specification]
1	P/W	-
2	B	-
3	SB	-

Connector No.	R10
Connector Name	VANITY MIRROR LAMP (PASSENGER SIDE)
Connector Type	MCA02FW

HS.

Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	P/W	-

JCLWM6149GB


ILLUMINATION

< DTC/CIRCUIT DIAGNOSIS >

ILLUMINATION

Wiring Diagram - ILLUMINATION -


INFOID:0000000006262834



JCLWM6150GB

ILLUMINATION

< DTC/CIRCUIT DIAGNOSIS >




JCLWM6151GB

A
B
C
D
E
F
G
H
I
J
K
L
INL
M
N
O
P

ILLUMINATION

< DTC/CIRCUIT DIAGNOSIS >


<ST> : With heated steering
 <HS> : With heated seat
 <AB> : With automatic back door



JCLWM6152GB

ILLUMINATION

< DTC/CIRCUIT DIAGNOSIS >




JCLWM6153GB

A
B
C
D
E
F
G
H
I
J
K
L
INL
M
N
O
P

ILLUMINATION

< DTC/CIRCUIT DIAGNOSIS >



JCLWM6154GB

ILLUMINATION


< DTC/CIRCUIT DIAGNOSIS >

ILLUMINATION

Connector No. B3

Connector Name WIRE TO WIRE


Connector Type TK1DFW-NS8



Connector No. B11

Connector Name WIRE TO WIRE

Connector Type TH80MW-CS19



Connector No. B34

Connector Name FRONT DOOR SWITCH (DRIVER SIDE)

Connector Type A03FW



Connector No. B216

Connector Name WIRE TO WIRE

Connector Type NST6MBR-CS



Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
1	SHIELD	-	59	SHIELD	-
2	B	-	60	B	-
3	R/L	-	61	R/L	-
4	R/W	-	62	R/W	-
5	SB	-	63	LG	-
6	P	-	64	Y	-
7	V	-	65	BR	-
8	SHIELD	-	66	V	-
9	BR/L	-	67	GR	-
10	Y/G	-	68	R	-
11	Y/L	-	69	SHIELD	-
12	WL	-	70	W/R	-
13	L	-	71	B/R	-
14	BR	-	72	Y	-
15	SB	-	73	LG	-
16	BR	-	74	SB	-
17	Y	-	75	L	-
18	SB	-	76	G	-
19	R	-	77	R	-
20	P	-	78	B	-
21	LG	-	79	B	-
22	W	-	80	W	-
23	Y	-	81	R	-
24	BR	-	82	L	-
25	Y	-	83	BR	-
26	Y	-	84	O	-
27	V	-	85	G	-
28	WL	-	86	SB	-
30	P	-	87	R	-
31	O	-	88	G	-
32	BR	-	89	GR	-
33	SB	-	90	Y	-
35	SHIELD	-	91	G	-
36	L/O	-	92	BR	-
37	LG	-	93	G	-
40	Y	-	94	V	-
41	GR	-	95	BR	-
42	SB	-	96	GR	-
46	LG	-	97	R	-
48	SB	-	98	LG	-
49	Y	-	99	O	-

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
2G	GR	-	1	G	-
4G	L	-	2	B/P	-
5G	P	-	5	O	-
10G	Y	-	6	W	-
11G	Y	-	7	Y	-
			8	GR	-
			9	G	-
			10	O	-
			12	G	-
			13	V	-
			14	R	-
			15	P	-
			16	SB	-

JCLWM6155GB

A B C D E F G H I J K L M N O P Q R S T Z

ILLUMINATION

< DTC/CIRCUIT DIAGNOSIS >

ILLUMINATION

Connector No. BE158

Connector Name WIRE TO WIRE

Connector Type TK1DFW-NS8



10	9	8	7	6	5	4	3	2	1
18	17	16	15	14	13	12	11		

Connector No. D21

Connector Name WIRE TO WIRE

Connector Type TH40FW-CS15



15	O	-							
16	SB	-							

Connector No. D14

Connector Name DOOR MIRROR REMOTE CONTROL SWITCH

Connector Type TK16FBR



1	2	3	4	5	6	7			
8	9	10	11	12	13	14	15	16	

Connector No. D3

Connector Name DOOR MIRROR REMOTE CONTROL SWITCH

Connector Type TK16FW



Connector No. D16

Connector Name FRONT DOOR INSIDE HANDLE ILLUMINATION DRIVER SIDE

Connector Type TK02FGY



1	2	3	4	5	6	7			
8	9	10	11	12	13	14	15	16	

Connector No. D41

Connector Name WIRE TO WIRE

Connector Type TH40FW-CS15



53	L	- [With automatic drive positioner]
53	P	- [Without automatic drive positioner]
54	SB	- [With automatic drive positioner]
54	LG	- [Without automatic drive positioner]
55	LG	- [With automatic drive positioner]
55	O	- [Without automatic drive positioner]

Connector No. D4

Connector Name WIRE TO WIRE

Connector Type TH40FW-CS15

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
46	45	44	43	42	41	40	39	38	37	36	35	34	33	32
33	32	31	30	29	28	27	26	25	24	23	22	21	20	19
22	21	20	19	18	17	16	15	14	13	12	11	10	9	8

Connector No. D4

Connector Name WIRE TO WIRE

Connector Type TH40FW-CS15

1	2	3	4	5	6	7			
8	9	10	11	12	13	14	15	16	

Connector No. D4

Connector Name WIRE TO WIRE

Connector Type TH40FW-CS15

1	2	3	4	5	6	7			
8	9	10	11	12	13	14	15	16	

Connector No. D4

Connector Name WIRE TO WIRE

Connector Type TH40FW-CS15

1	2	3	4	5	6	7			
8	9	10	11	12	13	14	15	16	

Connector No. D4

Connector Name WIRE TO WIRE

Connector Type TH40FW-CS15

1	2	3	4	5	6	7			
8	9	10	11	12	13	14	15	16	

Connector No. D4

Connector Name WIRE TO WIRE

Connector Type TH40FW-CS15

1	2	3	4	5	6	7			
8	9	10	11	12	13	14	15	16	

Connector No. D4

Connector Name WIRE TO WIRE

Connector Type TH40FW-CS15

1	2	3	4	5	6	7			
8	9	10	11	12	13	14	15	16	

Connector No. D4

Connector Name WIRE TO WIRE

Connector Type TH40FW-CS15

1	2	3	4	5	6	7			
8	9	10	11	12	13	14	15	16	

Connector No. D4

Connector Name WIRE TO WIRE

Connector Type TH40FW-CS15

1	2	3	4	5	6	7			
8	9	10	11	12	13	14	15	16	

Connector No. D4

Connector Name WIRE TO WIRE

Connector Type TH40FW-CS15

1	2	3	4	5	6	7			
8	9	10	11	12	13	14	15	16	

Connector No. D4

Connector Name WIRE TO WIRE

Connector Type TH40FW-CS15

1	2	3	4	5	6	7			
8	9	10	11	12	13	14	15	16	

Connector No. D4

Connector Name WIRE TO WIRE

Connector Type TH40FW-CS15

1	2	3	4	5	6	7			
8	9	10	11	12	13	14	15	16	

Connector No. D4

Connector Name WIRE TO WIRE

Connector Type TH40FW-CS15

1	2	3	4	5	6	7			
8	9	10	11	12	13	14	15	16	

Connector No. D4

Connector Name WIRE TO WIRE

Connector Type TH40FW-CS15

1	2	3	4	5	6	7			
8	9	10	11	12	13	14	15	16	

Connector No. D4

Connector Name WIRE TO WIRE

Connector Type TH40FW-CS15

1	2	3	4	5	6	7			
8	9	10	11	12	13	14	15	16	

Connector No. D4

Connector Name WIRE TO WIRE

Connector Type TH40FW-CS15

1	2	3	4	5	6	7			
8	9	10	11	12	13	14	15	16	

Connector No. D4

Connector Name WIRE TO WIRE

Connector Type TH40FW-CS15

1	2	3
---	---	---

ILLUMINATION

< DTC/CIRCUIT DIAGNOSIS >

ILLUMINATION

Connector No.	D47	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
Connector Name	FRONT DOOR INSIDE HANDLE ILLUMINATION (PASSENGER SIDE)	1	Y	-	4	W	L	-	-	-
Connector Type	TK02FGY	2	LG	-	5	W	-	-	-	-
		3	GR	-	7	LG	-	-	-	-
		4	B	-	10	B	-	-	-	-
		5	W	-	11	Y	-	-	-	-
		6	B	-	12	G	-	-	-	-
Connector No.	DB1	7	-	-	13	V	-	-	-	-
Connector Name	WIRE TO WIRE	8	-	-	14	P	-	-	-	-
Connector Type	TK10MW-NS8	9	-	-	15	SB	-	-	-	-
		10	-	-	16	R	-	-	-	-
		11	-	-	17	R	GR	-	-	-
		12	-	-	18	-	-	-	-	-

Connector No.	E10	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
Connector Name	FRONT E & R INTELLIGENT POWER DISTRIBUTION MODULE (FRONT ROOM)	39	P	-	40	L	-	-	-	-
Connector Type	TH08FW-NH	41	B	-	42	SE	-	-	-	-
		43	Y	-	44	W	-	-	-	-
		45	O	-	46	BR	-	-	-	-

Connector No.	E103	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
Connector Name	FUSE BLOCK (J-B)	1	W	-	4	LG	-	-	-	-
Connector Type	NS16FW-CS	5	-	-	5	Y	-	-	-	-
		6	-	-	7	GR	-	-	-	-
		7	-	-	10	BR	-	-	-	-
		8	-	-	11	Y	-	-	-	-
		9	-	-	12	B	-	-	-	-
		10	-	-	13	SB	-	-	-	-
		11	-	-	15	W	-	-	-	-
		12	-	-	16	R	-	-	-	-
		13	-	-	19	Y	-	-	-	-
		14	-	-	20	L	-	-	-	-
		15	-	-	21	O	-	-	-	-
		16	-	-	22	SB	-	-	-	-
		17	-	-	23	GR	-	-	-	-
		18	-	-	24	G	-	-	-	-
		19	-	-	25	GR	-	-	-	-
		20	-	-	26	Y	-	-	-	-
		21	-	-	27	W	-	-	-	-
		22	-	-	28	SB	-	-	-	-
		23	-	-	30	BR	-	-	-	-
		24	-	-	34	P	-	-	-	-
		25	-	-	35	G	-	-	-	-
		26	-	-	36	GR	-	-	-	-
		27	-	-	38	-	-	-	-	-

Connector No.	D155	Terminal No.	Color of Wire	Signal Name [Specification]	Connector Name	D12	Terminal No.	Color of Wire	Signal Name [Specification]	Connector Name	D12	Terminal No.	Color of Wire	Signal Name [Specification]
Connector Name	WIRE TO WIRE	1	W	-	FRONT HEATED SEAT SWITCH RH	TK10MW-NS8	2	LG	-	REAR HEATED SEAT SWITCH LH	TK10MW-NS8	3	LG	-
Connector Type	NS05FBR-CS	3	GR	-		4	LG	-	-		5	GR	-	
		4	B	-		5	W	-	-		6	GR	-	
		5	W	-		6	Y	-	-		7	GR	-	
		6	B	-		7	GR	-	-		8	GR	-	
		8	-	-		9	Y	-	-		10	GR	-	
		10	-	-		11	W	-	-		12	Y	-	
		12	-	-		13	LG	-	-		14	LG	-	
		13	-	-		14	Y	-	-		15	W	-	
		14	-	-		15	GR	-	-		16	GR	-	
		15	-	-		16	Y	-	-		17	W	-	
		16	-	-		17	GR	-	-		18	Y	-	
		18	-	-		19	Y	-	-		20	LG	-	
		20	-	-		21	W	-	-		22	LG	-	
		21	-	-		22	GR	-	-		23	Y	-	
		22	-	-		24	G	-	-		25	R	-	
		23	-	-		25	GR	-	-		26	Y	-	
		24	-	-		26	W	-	-		27	W	-	
		25	-	-		27	BR	-	-		28	BR	-	
		26	-	-		28	SB	-	-		29	BR	-	
		27	-	-		29	SB	-	-		30	BR	-	
		28	-	-		30	BR	-	-		31	BR	-	
		31	-	-		31	BR	-	-		32	BR	-	
		32	-	-		32	BR	-	-		33	BR	-	
		33	-	-		33	BR	-	-		34	BR	-	
		34	-	-		34	BR	-	-		35	BR	-	
		35	-	-		35	BR	-	-		36	BR	-	
		36	-	-		36	BR	-	-		37	BR	-	
		37	-	-		37	BR	-	-		38	BR	-	

JCLWM6157GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z
INL

ILLUMINATION

< DTC/CIRCUIT DIAGNOSIS >

ILLUMINATION

Connector No.	Wire To Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
Connector Name	WIRE TO WIRE		72	Y	
Connector Type	TH70MW-CS10-M3		73	L	-
			74	W	-
			75	BR	-
			76	GR	-
			77	O	[With navigation system]
			78	Y	- [Without navigation system]
			78	G	- [With iPod and navigation system]
			78	V	- [Without iPod and navigation system]
			79	Y	-
			80	R	-
			81	W	-
			82	LG	-
			83	O	-
Connector No.	M1	FUSE BLOCK (J/B)	1	Y	
Connector Name	FUSE BLOCK (J/B)		2	SB	-
Connector Type	NS121PN-CS		3	B	-
			4	R	-
Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
3	Y	-	6C	BR	-
5	LG	-	7C	B	-
6	GR	-	8D	G	-
8	G	-	9C	GR	-
11	P	-	10C	SB	-
12	L	-	11C	R	-
13	Y	-	12C	O	-
14	O	-			
15	BR	-			
20	Y	-			
21	BR	-			
22	P	-			
24	L	-			
25	O	-			
28	SB	-			
29	W	-			
30	Y	-			
47	P	-			
48	L	-			
49	SB	-			
50	GR	-			
51	LG	-			
52	V	-			
53	GR	-			
54	BR	-			
55	Y	-			
56	W/L	-			
60	V	-			
61	BR	-			
62	O	-			
63	L/O	-			
64	SHIELD	-			
66	W	-			
67	BR	-			
68	Y	-			
69	SB	-			
70	GR	-			
71	SB	-			

JCLWM6158GB

ILLUMINATION

< DTC/CIRCUIT DIAGNOSIS >

ILLUMINATION

Terminal No.	Color of Wire	Signal Name [Specification]
72	BR	
73	L	
74	W	
75	BR	
76	R	
77	G	
78	Y	
79	G	
80	R	
81	W	
82	W	
83	O	
3	P	
5	O	
6	G	
8	R	
11	P	
12	L	
13	V	
14	Y	
15	R	
20	Y	
21	BR	
22	G	
24	Y	
25	L	
28	BR	
29	L	
30	R	
47	P	
48	L	
49	W	
50	GR	
51	LG	
52	Y	
53	V	
54	SR	
55	P	
56	SB	
60	V	
61	GR	
62	O	
63	V	
64	SHIELD	
66	W	
66	SB	
67	R	
68	W	
69	P	
70	G	
71	G	

Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	V	-
4	L	- (With iPod without BOSE system)
4	W	- (With BOSE system and base auto direct iPod)
5	B	- (With BOSE system)
5	W	- (Without iPod without BOSE system)
5	BR	- (Without iPod and BOSE system)
6	GR	-
7	G	-
8	B	-
16	W	-
17	Y	-
18	W	-
19	R	-
20	SB	-
24	LG	-
25	Y	-
26	P	-
29	O	-
30	G	-
31	V	-
32	Y	-
33	P	-
34	BR	-
35	R	-

Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	B	-

Terminal No.	Color of Wire	Signal Name [Specification]
1	2	1 2 3 4 5
2	3	6 7 8 9 10
6	7	11 12 13 14 15
9	8	16 17 18 19 20
10	L	RX (AMP/DISP)

Terminal No.	Color of Wire	Signal Name [Specification]
1	B	GND
6	G	IGN
8	R	ILL+
9	BR	ILL-
10	L	RX (AMP/DISP)

Terminal No.	Color of Wire	Signal Name [Specification]
1	WIRE TO WIRE	
2	WIRE TO CS15	
6	WIRE TO CS15	
10	WIRE TO CS15	

JCLWM6159GB

A

B

C

D

E

F

G

H

I

J

K

M

N

O

P

Q

R

S

T

U

V

W

X

Y

Z

ILLUMINATION

< DTC/CIRCUIT DIAGNOSIS >

ILLUMINATION

Connector No.	M20	Connector No.	M26	Connector No.	M32
Connector Name	WIRE TO WIRE	Connector Name	HEATED STEERING WHEEL SWITCH	Connector Name	COMBINATION SWITCH (SPRAL CABLE)
Connector Type	TH45MW-CS15	Connector Type	NS06FW-CS	Connector Type	TK08FGY-IV
1	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 [With automatic drive positioner] [Without automatic drive positioner]	52	GR R L V G G SB O	- (With automatic drive positioner) - (Without automatic drive positioner) - (With automatic drive positioner) - (Without automatic drive positioner) - (With automatic drive positioner) - (Without automatic drive positioner)	
2	G	52	R		
3	W	53	V		
4	R	54	LG		
5	B	54	G		
5	G	55	SB		
5	L	55	O		
6	V	55			
7	BR	56			
8	O	57			
9	SB	58			
10	L	59			
11	G	60			
14	B	61			
15	GR	62			
16	L	63			
17	Y	64			
18	W	65			
19	Y	66			
20	SB	67			
24	P	68			
25	V	69			
26	W	70			
29	R	71			
30	L	72			
31	SB	73			
32	W	74			
33	P	75			
34	BR	76			
35	R	77			
41	LG	78			
42	LG	79			
43	O	80			
44	Y	81			
45	P	82			
46	P	83			
50	V	84			
51	O	85			

JCLWM6160GB

ILLUMINATION

< DTC/CIRCUIT DIAGNOSIS >

A

B

C

D

E

F

G

H

I

K

L

M

N

O

P

ILLUMINATION

Connector No.	M54	Connector No.	M5
Connector Name	COMBINATION METER	Connector Name	HAZARD SWITCH
Connector Type	TH46FW-NH	Connector Type	TK04FW



Connector No.	M5	Connector No.	M6
Connector Name	AUDIO UNIT	Connector Name	ILLUMINATION CONTROL
Connector Type	TH18FW-CS2	Connector Type	TH18FW-CS2



Connector No.	M6	Connector No.	M70
Connector Name	ILLUMINATION CONTROL SWITCH (-)	Connector Name	WIRE TO WIRE
Connector Type	TH46FW-NH	Connector Type	NS16FBR-CS



Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	BAT	1	B	-
2	O	IGN	2	G	-
3	B	GROUND	3	R	-
4	B	GROUND	4	SB	-
5	SB	ILLUMINATION CONTROL	5	SB	-
9	SB	TRIP RESET SWITCH	6	W	-
9	W	SWILL POWER	6	V	-
10	O	METER CONTROL SW GND	9	L	-
11	L	ENTER SWITCH	10	GR	-
12	R	SELECT SWITCH	12	P	-
13	Y	ILLUMINATION CONTROL SWITCH (+) (With automatic drive position)	13	V	-
13	Y	ILLUMINATION CONTROL SWITCH (+) (Without a automatic drive position)	14	L	-
14	GR	ILLUMINATION CONTROL SWITCH (-)	14	BR	-
15	BR	AIR BAG	16	V	-
18	L	AMBIENT SENSOR			
19	P	AMBIENT SENSOR POWER			
20	Y	AMBIENT SENSOR GROUND			
21	L	CAN-H			
22	P	CAN-L			
23	B	GROUND			
24	W	FUEL LEVEL SENSOR GROUND			
25	BR	CHG			
26	G	PARKING BRAKE SWITCH			
27	V	BRAKE FLUID LEVEL SWITCH			
29	R	WASHER LEVEL SWITCH	7	R	ACC
30	P	VEHICLE SPEED (Z-PULSE)	3	SB	ILLUMINATION CONTROL SIGNAL (+)
31	V	VEHICLE SPEED (Z-PULSE)	9	R	ILLUMINATION CONTROL SIGNAL (-)
32	LG	OD OFF / SPORTS	11	BR	_SOUND SIGNAL FRONT LH (+)
34	G	FUEL LEVEL SENSOR	12	V	_SOUND SIGNAL FRONT LH (-)
35	SB	SEAT BELT BUCKLE SWITCH (DRIVER SIDE)	13	O	_SOUND SIGNAL REAR RH (+)
36	R	SEAT BELT BUCKLE SWITCH (PASSENGER SIDE)	14	P	_SOUND SIGNAL REAR RH (-)
			19	Y	BATTERY

Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	G	-
3	R	-
4	SB	-

Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	G	-
3	R	-
4	SB	-

JCLWM6161GB

ILLUMINATION

< DTC/CIRCUIT DIAGNOSIS >

ILLUMINATION

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
1	SHIELD		59	SHIELD	
2	B		60	B	
3	W		61	R	
4	R		62	W	
5	Y		63	O	
6	W		64	Y	
7	G		65	V	
8	SHIELD		66	V	
9	W		67	GR	
10	R		68	G	
11	G		69	SHIELD	
12	B		70	L	- [With automatic drive positioner]
13	O		71	R	- [Without automatic drive positioner]
14	R		72	LG	
15	SB		73	Y	
16	R		74	R	
17	V		75	P	
18	P		76	L	
19	LG		77	BR	
20	Y		78	B	
21	Y		79	B	
22	O		80	W	
23	LG		81	LG	
24	SB		82	L	- [With automatic drive positioner]
25	Y		83	W	- [Without automatic drive positioner]
26	Y		84	R	
27	Y		85	V	
28	R		86	Y	
29	Y		87	R	
30	Y		88	G	
31	W		89	B	
32	BR		90	O	
33	Y		91	G	
34	Y		92	BR	
35	SHIELD		93	P	
36	G		94	V	
37	Y		95	O	
38	O		96	SB	
39	LG		97	L	
40	SB		98	LG	

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
47	SB		99	Y	-
48	SHIELD				
49	R				
50	LG				
51	V				
52	B				
53	BR				
54	B				
55	G				
56	P				
57	L				
58	SB				
59	SHIELD				
60	B				
61	R				
62	W				
63	O				
64	Y				
65	V				
66	V				
67	GR				
68	G				
69	SHIELD				
70	L				
71	R				
72	LG				
73	Y				
74	R				
75	P				
76	L				
77	BR				
78	B				
79	B				
80	W				
81	LG				
82	L				
83	W	- [With automatic drive positioner]			
84	R	- [Without automatic drive positioner]			
85	V				
86	Y				
87	R				
88	G				
89	B				
90	O				
91	G				
92	BR				
93	P				
94	V				
95	O				
96	SB				
97	L				
98	LG				

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
47	SB		99	Y	-
48	SHIELD				
49	R				
50	LG				
51	V				
52	B				
53	BR				
54	B				
55	G				
56	P				
57	L				
58	SB				
59	SHIELD				
60	B				
61	R				
62	W				
63	O				
64	Y				
65	V				
66	V				
67	GR				
68	G				
69	SHIELD				
70	L	- [With automatic drive positioner]			
71	R	- [Without automatic drive positioner]			
72	LG				
73	Y				
74	R				
75	P				
76	L				
77	BR				
78	B				
79	B				
80	W				
81	LG				
82	L				
83	W	- [With automatic drive positioner]			
84	R	- [Without automatic drive positioner]			
85	V				
86	Y				
87	R				
88	G				
89	B				
90	O				
91	G				
92	BR				
93	P				
94	V				
95	O				
96	SB				
97	L				
98	LG				

JCLWM6162GB

ILLUMINATION

< DTC/CIRCUIT DIAGNOSIS >

ILLUMINATION

Connector No.	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
M101	PUSH-BUTTON IGNITION SWITCH	1	O	-
Connector Name		2	B	-
Connector Type	TK08FBR	3	R	-
		4	R	-
Connector No.	MI10	1	O	-
Connector Name	AUTOMATIC BACK DOOR MAN SWITCH	2	B	-
Connector Type	TK08FW	3	R	-
		4	R	-
Connector No.	MI11	1	O	-
Connector Name	AUTOMATIC BACK DOOR SW	2	B	-
Connector Type	TK08FBR	3	B	-
		4	R	-
Terminal Color No.	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
1	B	1	O	-
2	O	2	BR	-
3	W	3	B	-
4	BR	4	R	-
5	R	5	G	-
6	L	6	-	-
7	P	7	-	-
8	GR	8	-	-
Connector No.	MI11	1	O	-
Connector Name	AUTOMATIC BACK DOOR SWITCH	2	B	-
Connector Type	TK08FW	3	R	-
		4	SB	-
Connector No.	MI13	1	Y	-
Connector Name	COMBINATION SWITCH	2	B	-
Connector Type	TH1FW-NH	3	R	-
		4	SB	-
Terminal Color No.	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
1	2	1	2	FR
2	3	2	3	IGN
3	4	3	4	OUTPUT 4
4	5	4	5	FR
5	6	5	6	OUTPUT 3
6	7	6	B	GND
7	8	7	GR	INPUT 3
8	9	8	L	OUTPUT 5
9	10	9	SB	INPUT 2
10	11	10	P	INPUT 4
11	12	11	O	INPUT 1
12	13	12	W	OUTPUT 1
13	14	13	R	INPUT 5
		14	P	OUTPUT 2



JCLWM6163GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z
INL

ILLUMINATION

< DTC/CIRCUIT DIAGNOSIS >

ILLUMINATION



Connector No.		Terminal No.	Color of Wire	Signal Name [Specification]
Connector No.	M122	1	B	SOUND SIGNAL REAR DOOR SPEAKER RH (-)
Connector Name	BCM (BODY CONTROL MODULE)	2	W	STRG SW A
Connector Type	TH40FB-NH	3	ACC	ACC (With BOSE system)
		4	R	ACC (Without BOSE system)
		5	B	ILLUMINATION
		6	SB	SOUND SIGNAL FRONT DOOR SPEAKER AND FRONT SQUAWKER RH (-)
		7	L	SOUND SIGNAL FRONT DOOR SPEAKER AND FRONT SQUAWKER RH (+)
		8	LG	SOUND SIGNAL REAR DOOR SPEAKER RH (-)
		9	V	SOUND SIGNAL REAR DOOR SPEAKER RH (+)
		10	W	EJECT SIGNAL
		11	Y	STRG SW B
		12	G	BATTERY
		13	ACC	AV CONTROL UNIT
		14	W	SW GND
		15	L	STRG SW GND
		16	G	STRG SW B
		17	Y	STRG SW B
		18	G	BATTERY
		19	Y	STRG SW B
		20	B	GND

JCLWM6164GB

ILLUMINATION

< DTC/CIRCUIT DIAGNOSIS >

ILLUMINATION

Connector No.	M180
Connector Name	AV CONTROL UNIT
Connector Type	TH32FW-NH



Connector No.	M203
Connector Name	FRONT HEATED SEAT SWITCH (PASSENGER SIDE)
Connector Type	NS06FBR-CS



Terminal No.	Color of Wire	Signal Name [Specification]
65	LG	PARKING BRAKE
67	BR	COMPOSITE IMAGE SIGNAL GND
68	GR	COMPOSITE IMAGE SIGNAL
71	SHIELD	SHIELD
72	B	MICROPHONE VCC
73	R	COMM (COMM-DISP)
74	P	CAN-L
75	LG	AV COMM (L)
76	LG	AV COMM (L)
79	R	ILLUMINATION SIGNAL
80	G	IGNITION
81	SB	REVERSE
82	V	VEHICLE SPEED SIGNAL (8-PULSE)
83	SHIELD	SHIELD
87	W	MICROPHONE SIGNAL
88	SHIELD	SHIELD
89	G	COMM (DISP->CONT)
90	L	CAN-H
91	SB	AV COMM (H)
92	SB	AV COMM (H)



Terminal No.	Color of Wire	Signal Name [Specification]
13	-	-
14	-	-
15	-	-
16	-	-
17	-	-
18	-	-
19	-	-
20	-	-



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	V	-
3	Y	-
4	B	-
5	R	-
6	BR	-
7	L	-
8	V	-
9	B	-
10	Y	-
11	P/W	-
12	B	-
13	R/Y	-
14	B/R	-
15	R	-


Terminal No.	Color of Wire	Signal Name [Specification]
1	P/W	-
2	Y	-
3	B	-
4	R/Y	-
5	B/R	-
6	R	-

Terminal No.	Color of Wire	Signal Name [Specification]
13	-	-
14	-	-
15	-	-
16	-	-
17	-	-
18	-	-
19	-	-
20	-	-



Terminal No.	Color of Wire	Signal Name [Specification]
1	P/W	-
2	Y	-
3	B	-
4	R/Y	-
5	B/R	-
6	R	-

Terminal No.	Color of Wire	Signal Name [Specification]
1	P/W	-
2	Y	-
3	B	-
4	R/Y	-
5	B/R	-
6	R	-



Terminal No.	Color of Wire	Signal Name [Specification]
1	P/W	-
2	Y	-
3	B	-
4	R/Y	-
5	B/R	-
6	R	-

JCLWM6165GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION

BCM (BODY CONTROL MODULE)

Reference Value

INFOID:000000006856672

VALUES ON THE DIAGNOSIS TOOL

CONSULT-III MONITOR ITEM

Monitor Item	Condition	Value/Status
FR WIPER HI	Other than front wiper switch HI	Off
	Front wiper switch HI	On
FR WIPER LOW	Other than front wiper switch LO	Off
	Front wiper switch LO	On
FR WASHER SW	Front washer switch OFF	Off
	Front washer switch ON	On
FR WIPER INT	Other than front wiper switch INT/AUTO	Off
	Front wiper switch INT/AUTO	On
FR WIPER STOP	Front wiper is not in STOP position	Off
	Front wiper is in STOP position	On
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	Wiper intermittent dial position
RR WIPER ON	Other than rear wiper switch ON	Off
	Rear wiper switch ON	On
RR WIPER INT	Other than rear wiper switch INT	Off
	Rear wiper switch INT	On
RR WASHER SW	Rear washer switch OFF	Off
	Rear washer switch ON	On
RR WIPER STOP	Rear wiper is in STOP position	Off
	Rear wiper is not in STOP position	On
TURN SIGNAL R	Other than turn signal switch RH	Off
	Turn signal switch RH	On
TURN SIGNAL L	Other than turn signal switch LH	Off
	Turn signal switch LH	On
TAIL LAMP SW	Other than lighting switch 1ST and 2ND	Off
	Lighting switch 1ST or 2ND	On
HI BEAM SW	Other than lighting switch HI	Off
	Lighting switch HI	On
HEAD LAMP SW 1	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
HEAD LAMP SW 2	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
PASSING SW	Other than lighting switch PASS	Off
	Lighting switch PASS	On
AUTO LIGHT SW	Other than lighting switch AUTO	Off
	Lighting switch AUTO	On
FR FOG SW	Front fog lamp switch OFF	Off
	Front fog lamp switch ON	On

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
RR FOG SW	NOTE: The item is indicated, but not monitored.	Off
DOOR SW-DR	Driver door closed	Off
	Driver door opened	On
DOOR SW-AS	Passenger door closed	Off
	Passenger door opened	On
DOOR SW-RR	Rear RH door closed	Off
	Rear RH door opened	On
DOOR SW-RL	Rear LH door closed	Off
	Rear LH door opened	On
DOOR SW-BK	Back door closed	Off
	Back door opened	On
CDL LOCK SW	Other than power door lock switch LOCK	Off
	Power door lock switch LOCK	On
CDL UNLOCK SW	Other than power door lock switch UNLOCK	Off
	Power door lock switch UNLOCK	On
KEY CYL LK-SW	Other than driver door key cylinder LOCK position	Off
	Driver door key cylinder LOCK position	On
KEY CYL UN-SW	Other than driver door key cylinder UNLOCK position	Off
	Driver door key cylinder UNLOCK position	On
KEY CYL SW-TR	NOTE: The item is indicated, but not monitored.	Off
HAZARD SW	Hazard switch is OFF	Off
	Hazard switch is ON	On
REAR DEF SW NOTE: For models with BOSE audio system this item is not monitored.	Rear window defogger switch OFF	Off
	Rear window defogger switch ON	On
TR CANCEL SW	NOTE: The item is indicated, but not monitored.	Off
TR/BD OPEN SW	Back door opener switch OFF	Off
	While the back door opener switch is turned ON	On
TRNK/HAT MNTR	NOTE: The item is indicated, but not monitored.	Off
RKE-LOCK	LOCK button of Intelligent Key is not pressed	Off
	LOCK button of Intelligent Key is pressed	On
RKE-UNLOCK	UNLOCK button of Intelligent Key is not pressed	Off
	UNLOCK button of Intelligent Key is pressed	On
RKE-TR/BD	BACK DOOR OPEN button of Intelligent Key is not pressed	Off
	BACK DOOR OPEN button of Intelligent Key is pressed	On
RKE-PANIC	PANIC button of Intelligent Key is not pressed	Off
	PANIC button of Intelligent Key is pressed	On
RKE-P/W OPEN	UNLOCK button of Intelligent Key is not pressed	Off
	UNLOCK button of Intelligent Key is pressed and held	On

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
RKE-MODE CHG	LOCK/UNLOCK button of Intelligent Key is not pressed and held simultaneously	Off
	LOCK/UNLOCK button of Intelligent Key is pressed and held simultaneously	On
OPTICAL SENSOR	Bright outside of the vehicle	Close to 5 V
	Dark outside of the vehicle	Close to 0 V
REQ SW -DR	Driver door request switch is not pressed	Off
	Driver door request switch is pressed	On
REQ SW -AS	Passenger door request switch is not pressed	Off
	Passenger door request switch is pressed	On
REQ SW -RR	NOTE: The item is indicated, but not monitored.	Off
REQ SW -RR	NOTE: The item is indicated, but not monitored.	Off
REQ SW -BD/TR	Back door request switch is not pressed	Off
	Back door request switch is pressed	On
PUSH SW	Push-button ignition switch (push switch) is not pressed	Off
	Push-button ignition switch (push switch) is pressed	On
IGN RLY2 -F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
ACC RLY -F/B	NOTE: The item is indicated, but not monitored.	Off
CLUCH SW	NOTE: The item is indicated, but not monitored.	Off
BRAKE SW 1	The brake pedal is depressed when No. 7 fuse is blown	Off
	The brake pedal is not depressed when No. 7 fuse is blown, or No. 7 fuse is normal	On
BRAKE SW 2	The brake pedal is not depressed	Off
	Stop lamp switch 1 signal circuit is normal	On
DETE/CANCL SW	Selector lever in P position	Off
	Selector lever in any position other than P	On
SFT PN/N SW	Selector lever in any position other than P and N	Off
	Selector lever in P or N position	On
S/L -LOCK	NOTE: The item is indicated, but not monitored.	Off
S/L -UNLOCK	NOTE: The item is indicated, but not monitored.	Off
S/L RELAY-F/B	NOTE: The item is indicated, but not monitored.	Off
UNLK SEN -DR	Driver door is unlocked	Off
	Driver door is locked	On
PUSH SW -IPDM	Push-button ignition switch (push-switch) is not pressed	Off
	Push-button ignition switch (push-switch) is pressed	On
IGN RLY1 -F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
DETE SW -IPDM	Selector lever in any position other than P	Off
	Selector lever in P position	On

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
SFT PN -IPDM	Selector lever in any position other than P and N	Off
	Selector lever in P or N position	On
SFT P -MET	Selector lever in any position other than P	Off
	Selector lever in P position	On
SFT N -MET	Selector lever in any position other than N	Off
	Selector lever in N position	On
ENGINE STATE	Engine stopped	Stop
	While the engine stalls	Stall
	At engine cranking	Crank
	Engine running	Run
S/L LOCK-IPDM	NOTE: The item is indicated, but not monitored.	Off
S/L UNLK-IPDM	NOTE: The item is indicated, but not monitored.	Off
S/L RELAY-REQ	NOTE: The item is indicated, but not monitored.	Off
VEH SPEED 1	While driving	Equivalent to speedometer reading
VEH SPEED 2	While driving	Equivalent to speedometer reading
DOOR STAT-DR	Driver door is locked	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Driver door is unlocked	UNLOCK
DOOR STAT-AS	Passenger door is locked	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Passenger door is unlocked	UNLOCK
ID OK FLAG	Power supply position in LOCK position	Reset
	Power supply position in any position other than LOCK	Set
PRMT ENG STRT	The engine start is prohibited	Reset
	The engine start is permitted	Set
PRMT RKE STRT	NOTE: The item is indicated, but not monitored.	Reset
KEY SW -SLOT	Intelligent Key is not inserted into key slot	Off
	Intelligent Key is inserted into key slot	On
RKE OPE COUN1	During the operation of Intelligent Key	Operation frequency of Intelligent Key
RKE OPE COUN2	NOTE: The item is indicated, but not monitored.	—
CONFIRM ID ALL	The Intelligent Key ID that the key slot receives is not recognized by any Intelligent Key ID registered to BCM.	Yet
	The Intelligent Key ID that the key slot receives is recognized by any Intelligent Key ID registered to BCM.	Done
CONFIRM ID4	The Intelligent Key ID that the key slot receives is not recognized by the fourth Intelligent Key ID registered to BCM.	Yet
	The Intelligent Key ID that the key slot receives is recognized by the fourth Intelligent Key ID registered to BCM.	Done

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
CONFIRM ID3	The Intelligent Key ID that the key slot receives is not recognized by the third Intelligent Key ID registered to BCM.	Yet
	The Intelligent Key ID that the key slot receives is recognized by the third Intelligent Key ID registered to BCM.	Done
CONFIRM ID2	The Intelligent Key ID that the key slot receives is not recognized by the second Intelligent Key ID registered to BCM.	Yet
	The Intelligent Key ID that the key slot receives is recognized by the second Intelligent Key ID registered to BCM.	Done
CONFIRM ID1	The Intelligent Key ID that the key slot receives is not recognized by the first Intelligent Key ID registered to BCM.	Yet
	The Intelligent Key ID that the key slot receives is recognized by the first Intelligent Key ID registered to BCM.	Done
TP 4	The ID of fourth Intelligent Key is not registered to BCM	Yet
	The ID of fourth Intelligent Key is registered to BCM	Done
TP 3	The ID of third Intelligent Key is not registered to BCM	Yet
	The ID of third Intelligent Key is registered to BCM	Done
TP 2	The ID of second Intelligent Key is not registered to BCM	Yet
	The ID of second Intelligent Key is registered to BCM	Done
TP 1	The ID of first Intelligent Key is not registered to BCM	Yet
	The ID of first Intelligent Key is registered to BCM	Done
AIR PRESS FL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front LH tire
AIR PRESS FR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front RH tire
AIR PRESS RR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear RH tire
AIR PRESS RL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear LH tire
ID REGST FL1	ID of front LH tire transmitter is registered	Done
	ID of front LH tire transmitter is not registered	Yet
ID REGST FR1	ID of front RH tire transmitter is registered	Done
	ID of front RH tire transmitter is not registered	Yet
ID REGST RR1	ID of rear RH tire transmitter is registered	Done
	ID of rear RH tire transmitter is not registered	Yet
ID REGST RL1	ID of rear LH tire transmitter is registered	Done
	ID of rear LH tire transmitter is not registered	Yet
WARNING LAMP	Tire pressure indicator OFF	Off
	Tire pressure indicator ON	On
BUZZER	Tire pressure warning alarm is not sounding	Off
	Tire pressure warning alarm is sounding	On

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

TERMINAL LAYOUT




PHYSICAL VALUES

A
B
C
D
E
F
G
H
I
J
K
L
INL
M
N
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
1 (W)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
2 (GR)	Ground	P/W power supply (BAT)	Output	Ignition switch OFF	Battery voltage
3 (L)	Ground	P/W power supply (RAP)	Output	Ignition switch ON	Battery voltage
4 (P)	Ground	Interior room lamp power supply	Output	Interior room lamp battery saver is activated. (Cuts the interior room lamp power supply)	0 V
				Interior room lamp battery saver is not activated. (Outputs the interior room lamp power supply)	Battery voltage
5 (G)	Ground	Passenger door UN- LOCK	Output	Passenger door	UNLOCK (Actuator is activated)
					0 V
7 (Y)	Ground	Step lamp	Output	Step lamp	ON
					0 V
8 (V)	Ground	All doors LOCK	Output	All doors	LOCK (Actuator is activated)
					0 V
9 (G)	Ground	Driver door UNLOCK	Output	Driver door	UNLOCK (Actuator is activated)
					0 V
10 (P)	Ground	Rear RH door and rear LH door UN- LOCK	Output	Rear RH door and rear LH door	UNLOCK (Actuator is activated)
					0 V
11 (LG)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
13 (B)	Ground	Ground	—	Ignition switch ON	0 V
14 (O)	Ground	Push-button ignition switch illumination ground	Output	Tail lamp	OFF
					ON
15 (L)	Ground	ACC indicator lamp	Output	Ignition switch	OFF (LOCK and ON indicator lamps are not illuminated.)
					ACC




NOTE:
When the illumination brightening/dimming level is in the neutral position

JSNIA0010GB


BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


Terminal No. (Wire color)	Description		Condition	Value (Approx.)	
	+	-			
17 (G)	Ground	Turn signal RH	Output	Ignition switch ON	Turn signal switch OFF
					Turn signal switch RH
18 (BR)	Ground	Turn signal LH	Output	Ignition switch ON	Turn signal switch OFF
					Turn signal switch LH
19 (Y)	Ground	Room lamp timer control	Output	Interior room lamp	OFF
					ON
23 (BR)	Ground	Back door open	Output	Back door	OPEN (Back door opener actuator is activated)
					Other than OPEN (Back door opener actuator is not activated)
26 (G)	Ground	Rear wiper	Output	Rear wiper	OFF (Stopped)
					ON (Operated)
34 (B)	Ground	Luggage room antenna (-)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compartment
					When Intelligent Key is not in the passenger compartment




PKID0926E



PKID0926E







JMKIA0062GB



JMKIA0063GB





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
35 (W)	Ground	Luggage room antenna (+)	Output Ignition switch OFF	When Intelligent Key is in the passenger compartment
				 (V) 15 10 5 0 1 s JMKA0062GB
38 (L)	Ground	Rear bumper antenna (-)	Output When the back door request switch is operated with ignition switch OFF	When Intelligent Key is not in the passenger compartment
				 (V) 15 10 5 0 1 s JMKA0063GB
39 (BR)	Ground	Rear bumper antenna (+)	Output When the back door request switch is operated with ignition switch OFF	When Intelligent Key is in the antenna detection area
				 (V) 15 10 5 0 1 s JMKA0062GB
47 (L)	Ground	Ignition relay (IPDM E/R) control	Output Ignition switch	When Intelligent Key is not in the antenna detection area
				 (V) 15 10 5 0 1 s JMKA0063GB
47 (L)	Ground	Ignition relay (IPDM E/R) control	Output Ignition switch	OFF or ACC
				Battery voltage
				ON
				0 V





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
52 (R)	Ground	Starter relay control	Output	Ignition switch ON	When selector lever is in P or N position	Battery voltage
					When selector lever is not in P or N position	0.3 V
				Ignition switch OFF		0 V
60 (BR)	Ground	Push-button ignition switch (push switch)	Input	Push-button igni- tion switch (push switch)	Pressed	0 V
					Not pressed	Battery voltage
61 (R)	Ground	Back door request switch	Input	Back door re- quest switch	ON (Pressed)	0 V
					OFF (Not pressed)	 <small>JPMIA0016GB</small> 1.0 V
64 (GR)	Ground	Warning buzzer	Output	Warning buzzer	Sounding	0 V
					Not sounding	Battery voltage
65 (O)	Ground	Rear wiper stop posi- tion	Input	Rear wiper	In stop position	 <small>JPMIA0016GB</small> 1.0 V
					Not in stop position	0 V
66 (Y)	Ground	Back door switch	Input	Back door switch	OFF (When back door closes)	 <small>JPMIA0011GB</small> 11.8 V
					ON (When back door opens)	0 V
67 (LG)	Ground	Back door opener switch	Input	Back door opener switch	Pressed	0 V
					Not pressed	 <small>JPMIA0011GB</small> 11.8 V







BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
68 (W)	Ground	Rear RH door switch	Input	<p>Rear RH door switch</p> <p>OFF (When rear RH door closes)</p>  <p>JPMIA0011GB</p> <p>11.8 V</p>
69 (R)	Ground	Rear LH door switch	Input	<p>Rear LH door switch</p> <p>OFF (When rear LH door closes)</p>  <p>JPMIA0011GB</p> <p>11.8 V</p>
72 (B)	Ground	Room antenna (-) (Center console)	Output	<p>Ignition switch OFF</p> <p>When Intelligent Key is in the passenger compartment</p>  <p>JMKIA0062GB</p> <p>1 s</p>
				<p>When Intelligent Key is not in the passenger compartment</p>  <p>JMKIA0063GB</p> <p>1 s</p>

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)		
	+	-	Signal name	Input/ Output		
73 (W)	Ground	Room antenna (+) (Center console)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compart- ment	 (V) 15 10 5 0 1 s <small>JMKIA0062GB</small>
					When Intelligent Key is not in the passenger compart- ment	 (V) 15 10 5 0 1 s <small>JMKIA0063GB</small>
74 (Y)	Ground	Passenger door an- tenna (-)	Output	When the pas- senger door re- quest switch is operated with ig- nition switch OFF	When Intelligent Key is in the antenna detection area	 (V) 15 10 5 0 1 s <small>JMKIA0062GB</small>
					When Intelligent Key is not in the antenna detection area	 (V) 15 10 5 0 1 s <small>JMKIA0063GB</small>
75 (LG)	Ground	Passenger door an- tenna (+)	Output	When the pas- senger door re- quest switch is operated with ig- nition switch OFF	When Intelligent Key is in the antenna detection area	 (V) 15 10 5 0 1 s <small>JMKIA0062GB</small>
					When Intelligent Key is not in the antenna detection area	 (V) 15 10 5 0 1 s <small>JMKIA0063GB</small>

A

B

C

D

E

F

G

H

I

J

K

INL

M

N





O

P

BCM (BODY CONTROL MODULE)







< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)		
	Signal name	Input/ Output				
+	-					
76 (V)	Ground	Driver door antenna (-)	Output	When Intelligent Key is in the antenna detection area		
				When the driver door request switch is oper- ated with ignition switch OFF		
77 (P)	Ground	Driver door antenna (+)	Output	When Intelligent Key is not in the antenna detection area		
				When the driver door request switch is oper- ated with ignition switch OFF		
80 (SB)	Ground	NATS antenna amp.	Input/ Output	During waiting	Ignition switch is pressed while inserting Intelligent Key into the key slot.	Just after pressing ignition switch. Pointer of tester should move.
81 (O)	Ground	NATS antenna amp.	Input/ Output	During waiting	Ignition switch is pressed while inserting Intelligent Key into the key slot.	Just after pressing ignition switch. Pointer of tester should move.
82 (BR)	Ground	Ignition relay [fuse block (J/B)] control	Output	Ignition switch	OFF or ACC	0 V
					ON	Battery voltage








BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
83 (P)	Ground	Remote keyless entry receiver communication	Input/ Output	<p>During waiting</p>  <p>JMKIA0064GB</p>
				<p>When operating either button on Intelligent Key</p>  <p>JMKIA0065GB</p>
87 (R)	Ground	Combination switch INPUT 5	Input	<p>All switches OFF (Wiper intermittent dial 4)</p>  <p>JPMIA0041GB</p> <p>1.4 V</p>
				<p>Front fog lamp switch ON (Wiper intermittent dial 4)</p>  <p>JPMIA0037GB</p> <p>1.3 V</p>
				<p>Rear wiper switch ON (Wiper intermittent dial 4)</p>  <p>JPMIA0039GB</p> <p>1.3 V</p>
				<p>Any of the conditions below with all switches OFF</p> <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 6 • Wiper intermittent dial 7  <p>JPMIA0040GB</p> <p>1.3 V</p>




BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
88 (GR)	Ground	Combination switch INPUT 3	Input	 All switches OFF (Wiper intermittent dial 4)  Lighting switch HI (Wiper intermittent dial 4)  Lighting switch 2ND (Wiper intermittent dial 4)  Rear washer switch ON (Wiper intermittent dial 4)  Any of the conditions below with all switches OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 3
				JPMIA0041GB 1.4 V
				JPMIA0036GB 1.3 V
				JPMIA0037GB 1.3 V
				JPMIA0039GB 1.3 V
90 (P)	Ground	CAN - L	Input/ Output	—
91 (L)	Ground	CAN - H	Input/ Output	—






BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
92 (R)	Ground	Key slot illumination	Output	Key slot illumination	OFF	0 V
					Blinking	 (V) 15 10 5 0 1 s <small>JPMIA0015GB</small>
					ON	Battery voltage
93 (P)	Ground	ON indicator lamp	Output	Ignition switch	OFF (LOCK and ACC indicator lamps are not illuminated.)	Battery voltage
					ON	0 V
95 (L)	Ground	ACC relay control	Output	Ignition switch	OFF	0 V
					ACC or ON	Battery voltage
96 (Y)	Ground	CVT shift selector (detention switch) power supply	Output	—		Battery voltage
99 (V)	Ground	Selector lever P position switch	Input	Selector lever	P position	0 V
					Any position other than P	Battery voltage
100 (P)	Ground	Passenger door request switch	Input	Passenger door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	 (V) 15 10 5 0 10 ms <small>JPMIA0016GB</small>
					ON (Pressed)	1.0 V
101 (W)	Ground	Driver door request switch	Input	Driver door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	 (V) 15 10 5 0 10 ms <small>JPMIA0016GB</small>
					ON (Pressed)	1.0 V
102 (Y)	Ground	Blower fan motor relay control	Output	Ignition switch	OFF or ACC	0 V
					ON	Battery voltage
103 (L)	Ground	Remote keyless entry receiver power supply	Output	Ignition switch OFF		Battery voltage






BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
107 (O)	Ground	Combination switch INPUT 1	Combination switch (Wiper intermittent dial 4)	All switches OFF  1.4 V
				Turn signal switch LH  1.3 V
				Turn signal switch RH  1.3 V
				Front wiper switch LO  1.3 V
				Front washer switch ON  1.3 V







BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	
	Signal name	Input/ Output			
+	-				
108 (P)	Ground	Combination switch INPUT 4	Input	Combination switch	All switches OFF (Wiper intermittent dial 4)
					 1.4 V
					Lighting switch AUTO (Wiper intermittent dial 4)
					 1.3 V
					Lighting switch 1ST (Wiper intermittent dial 4)
					 1.3 V
					Rear wiper switch INT (Wiper intermittent dial 4)
					 1.3 V
					Any of the conditions below with all switches OFF • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6
					 1.3 V




BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
109 (SB)	Ground	Combination switch INPUT 2	Input Combination switch (Wiper intermittent dial 4)	All switches OFF  1.4 V
				Lighting switch PASS  1.3 V
				Lighting switch 2ND  1.3 V
				Front wiper switch INT/AUTO  1.3 V
				Front wiper switch HI  1.3 V
110 (G)	Ground	Hazard switch	Input Hazard switch	ON  0 V
				OFF  1.1 V




BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	
	+	-			
112 (R)	Ground	Rain sensor serial link	Input/ Output	Ignition switch ON	 <small>JPMIA0156GB</small> 8.7 V
113 (O)	Ground	Optical sensor	Input	Ignition switch ON	Close to 5 V
					Close to 0 V
116 (GR)	Ground	Stop lamp switch 1	Input	—	Battery voltage
118 (L)	Ground	Stop lamp switch 2	Input	Stop lamp switch	0 V
					Battery voltage
119 (W)	Ground	Front door lock assembly driver side (Unlock sensor)	Input	Driver door	 <small>JPMIA0012GB</small> 1.1 V
					0 V
121 (Y)	Ground	Key slot switch	Input	When Intelligent Key is inserted into key slot	
				When Intelligent Key is not inserted into key slot	
123 (G)	Ground	IGN feedback	Input	Ignition switch	0 V
					Battery voltage
124 (R)	Ground	Passenger door switch	Input	Passenger door switch	 <small>JPMIA0011GB</small> 11.8 V
					0 V






BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
130 (BR)	Ground	Rear window defogger switch	Input Ignition switch ON	Rear window defogger switch OFF
				(V) 15 10 5 0  10 ms JPMIA0012GB 1.1 V
132 (G)	Ground	Power window switch communication	Input/ Output Ignition switch ON	Rear window defogger switch ON
				(V) 15 10 5 0  10 ms JPMIA0013GB 10.2 V
				Ignition switch OFF or ACC Battery voltage
133 (W)	Ground	Push-button ignition switch illumination	Output Push-button ignition switch illumination	ON (When tail lamps OFF)
				NOTE: The pulse width of this wave is varied by the illumination brightening/dimming level.
				(V) 15 10 5 0  JPMIA0159GB
134 (R)	Ground	LOCK indicator lamp	Output LOCK indicator lamp	OFF (ACC and ON indicator lamps are not illuminated.)
				Battery voltage
				ON 0 V
137 (P)	Ground	Receiver and sensor ground	Input Ignition switch ON	0 V
138 (V)	Ground	Receiver and sensor power supply	Output Ignition switch	OFF 0 V
				ACC or ON 5.0 V

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
139 (O)	Ground	Tire pressure receiver communication	Input/ Output	Ignition switch ON	Standby state	 OCC3881D
					When receiving the signal from the transmitter	 OCC3880D
140 (GR)	Ground	Selector lever P/N position	Input	Selector lever	P or N position	Battery voltage
					Except P and N positions	0 V
141 (O)	Ground	Security indicator	Output	Security indicator	ON	0 V
					Blinking	 JPMIA0014GB 11.3 V
					OFF	Battery voltage
142 (L)	Ground	Combination switch OUTPUT 5	Output	Combination switch (Wiper intermittent dial 4)	All switches OFF	0 V
					Lighting switch 1ST	
					Lighting switch HI	
					Lighting switch 2ND	
					Turn signal switch RH	 JPMIA0031GB 10.7 V
143 (W)	Ground	Combination switch OUTPUT 1	Output	Combination switch	All switches OFF (Wiper intermittent dial 4)	0 V
					Front wiper switch HI (Wiper intermittent dial 4)	
					Rear wiper switch INT (Wiper intermittent dial 4)	
					Any of the conditions below with all switches OFF	
					<ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 3 • Wiper intermittent dial 6 • Wiper intermittent dial 7 	
						 JPMIA0032GB 10.7 V


BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
144 (P)	Ground	Combination switch OUTPUT 2	Output	All switches OFF (Wiper intermittent dial 4) Front washer switch ON (Wiper intermittent dial 4) Rear wiper switch ON (Wiper intermittent dial 4) Rear washer switch ON (Wiper intermittent dial 4) Any of the conditions below with all switches OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6
145 (V)	Ground	Combination switch OUTPUT 3	Output	All switches OFF Front wiper switch INT/AUTO Front wiper switch LO Lighting switch AUTO
146 (Y)	Ground	Combination switch OUTPUT 4	Output	All switches OFF Front fog lamp switch ON Lighting switch 2ND Lighting switch PASS Turn signal switch LH
150 (SB)	Ground	Driver door switch	Input	OFF (When driver door closes)
151 (G)	Ground	Rear window defogger relay control	Output	ON (When driver door opens)
		Rear window de-fogger		Active Not activated




JPMIA0033GB



JPMIA0034GB



JPMIA0035GB




JPMIA0011GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Wiring Diagram - BCM -

INFOID:000000006856673



2010/09/06


JCMWN0014GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

: Except for Mexico
 : With power seat without automatic drive positioner


* : This connector is not shown in "Harness Layout".





JCMWN0015GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >



* : This connector is not shown in "Harness Layout".




JCMWN0016GB

A B C D E F G H I J K L M N O P

INL

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >




JCMWN0017GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

: With automatic back door
 : Without automatic back door



JCMWN0018GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
INL

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)

Connector No.	Connector No.	Connector Name	Connector Type	Diagram
M103	M119	COMBINATION SWITCH	NS16FW-CS	
TH1BFW-NH		BCM (BODY CONTROL MODULE)		

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
1	G	RR	4	P	INTERIOR ROOM AMP POWER SUPPLY
2	Y	OUTPUT 4	5	G	PASSENGER DOOR UNLOCK OUTPUT
3	O	FR	7	Y	STEP LAMP OUTPUT
4	W	IGN	8	V	ALL DOOR FUEL LID UNLOCK OUTPUT
5	V	OUTPUT 3	9	G	DRIVER DOOR FUEL LID UNLOCK OUTPUT
6	B	GND	10	P	REAR DOOR UNLOCK OUTPUT
7	GR	INPUT 3	11	LG	BAT (FUSE)
8	L	OUTPUT 5	13	B	GND
9	SB	INPUT 2	14	O	PUSH-BUTTON IGNITION SW LHL RND
10	P	INPUT 4	15	L	ACC IND
11	O	INPUT 1	17	G	TURN SIGNAL RH
12	W	OUTPUT 1	18	BR	TURN SIGNAL LH
13	R	INPUT 5	19	Y	ROOM LAMP-TIMER CONTROL
14	P	OUTPUT 2			

Connector No.	Connector No.	Connector Name	Connector Type	Diagram
M113	M120	BCM (BODY CONTROL MODULE)	NS12FW-CS	
MD3FB-LC		BCM (BODY CONTROL MODULE)		

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
23	BR	BACK DOOR OPEN OUTPUT	26	G	REAR WIPER OUTPUT
24			25	26	
27			27	28	
28			29	29	
29			30	31	

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
1	W	BAT (F-L)	2	B	ROOM ANT 2+
2	GR	POWER WINDOW POWER SUPPLY (BAT)	3	W	PASSENGER DOOR ANT-
3	L	POWER WINDOW POWER SUPPLY (RAP)	4	Y	DRIVER DOOR ANT+
			5	V	DRIVER DOOR ANT-
			6	P	IMMOBILIZER ANTENNA CONTROL
			7	S3	IMMOBILIZER ANTENNA SIGNAL
			8	O	

JCMWN0019GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

A
B
C
D
E
F
G
H
I
J
K

INL
M
N
O
P

BCM (BODY CONTROL MODULE)		
Connector No.	M123	
Connector Name	BCM (BODY CONTROL MODULE)	
Connector Type	TH40FG-NH	
HS		
Terminal	Color No. of Wire	Signal Name [Specification]
112	R	RAIN SENSOR SERIAL LINK
113	O	OPTICAL SENSOR
116	GR	FUSE CHECK
118	L	STOP LAMP SW
119	W	DR DOOR UNLOCK SENSOR
121	Y	KEY SLOT SW
123	G	IGN F/B
124	R	PASSENGER DOOR SW
130	BR	REAR DEFOGGER SW
132	G	POWER WINDOW SW COMM
133	W	PUSH-BUTTON IGNITION SW/ILL POWER
134	R	LOCK RD
137	P	RECEIVER / SENSOR GND
138	V	RECEIVER / SENSOR POWER SUPPLY
139	O	TIRE PRESS RECEIVER SIGNAL
140	GR	SHIFT LIP
141	O	SECURITY INDICATOR OUTPUT
142	L	COMBI SW OUTPUT 5
143	W	COMBI SW OUTPUT 1
144	P	COMBI SW OUTPUT 2
145	V	COMBI SW OUTPUT 3
146	Y	COMBI SW OUTPUT 4
150	SB	DRIVER DOOR SW
151	G	REAR WINDOW DEFROGGER RELAY

JCMWN0020GB

INFOID:0000000006856674

Fail-safe

FAIL-SAFE CONTROL BY DTC

BCM performs fail-safe control when any DTC are detected.

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Display contents of CONSULT	Fail-safe	Cancellation
B2190: NATS ANTENNA AMP	Inhibit engine cranking	Erase DTC
B2191: DIFFERENCE OF KEY	Inhibit engine cranking	Erase DTC
B2192: ID DISCORD BCM-ECM	Inhibit engine cranking	Erase DTC
B2193: CHAIN OF BCM-ECM	Inhibit engine cranking	Erase DTC
B2195: ANTI SCANNING	Inhibit engine cranking	Ignition switch ON → OFF
B2560: STARTER CONT RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> • Starter control relay signal • Starter relay status signal
B2607: S/L RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> • Steering lock relay signal (Request signal) • Steering lock relay signal (Condition signal)
B2608: STARTER RELAY	Inhibit engine cranking	500 ms after the following signal communication status becomes consistent <ul style="list-style-type: none"> • Starter motor relay control signal • Starter relay status signal (CAN)
B260A: IGNITION RELAY	Inhibit engine cranking	500 ms after the following conditions are fulfilled <ul style="list-style-type: none"> • IGN relay (IPDM E/R) control signal: OFF (Battery voltage) • Ignition ON signal (CAN to IPDM E/R): OFF (Request signal) • Ignition ON signal (CAN from IPDM E/R): OFF (Condition signal)
B260F: ENG STATE SIG LOST	Maintains the power supply position attained at the time of DTC detection	When any of the following conditions are fulfilled <ul style="list-style-type: none"> • Power position changes to ACC • Receives engine status signal (CAN)
B2617: STARTER RELAY CIRC	Inhibit engine cranking	1 second after the starter motor relay control inside BCM becomes normal
B2618: BCM	Inhibit engine cranking	1 second after the ignition relay (IPDM E/R) control inside BCM becomes normal
B261E: VEHICLE TYPE	Inhibit engine cranking	BCM initialization

HIGH FLASHER OPERATION

BCM detects the turn signal lamp circuit status by the current value.

BCM increases the turn signal lamp blinking speed if the bulb or harness open is detected with the turn signal lamp operating.

NOTE:

The blinking speed is normal while activating the hazard warning lamp.

FAIL-SAFE CONTROL BY RAIN SENSOR MALFUNCTION

- BCM judges the rain sensor serial link error by the rain sensor serial link condition and detects the rain sensor malfunction by rain sensor malfunction signal.
- When BCM detects the rain sensor serial link error or the rain sensor malfunction while front wiper AUTO operation, BCM operates a fail-safe control.

NOTE:

If rain sensor malfunction is detected when ignition switch is turned OFF ⇒ ON and front wiper switch is INT/AUTO position, BCM operates a fail-safe control.

REAR WIPER MOTOR PROTECTION

BCM detects the rear wiper stopping position according to the rear wiper stop position signal.

When the rear wiper stop position signal does not change for more than 5 seconds while driving the rear wiper, BCM stops power supply to protect the rear wiper motor.

Condition of cancellation

1. More than 1 minute is passed after the rear wiper stop.
2. Turn rear wiper switch OFF.
3. Operate the rear wiper switch or rear washer switch.

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

DTC Inspection Priority Chart

INFOID:000000006856675

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	DTC	
1	B2562: LOW VOLTAGE	A
2	<ul style="list-style-type: none">• U1000: CAN COMM• U1010: CONTROL UNIT(CAN)	B
3	<ul style="list-style-type: none">• B2190: NATS ANTENNA AMP• B2191: DIFFERENCE OF KEY• B2192: ID DISCORD BCM-ECM• B2193: CHAIN OF BCM-ECM• B2195: ANTI SCANNING	C
	<ul style="list-style-type: none">• B2553: IGNITION RELAY• B2555: STOP LAMP• B2556: PUSH-BTN IGN SW• B2557: VEHICLE SPEED• B2560: STARTER CONT RELAY• B2601: SHIFT POSITION• B2602: SHIFT POSITION• B2603: SHIFT POSI STATUS• B2604: PNP SW• B2605: PNP SW• B2608: STARTER RELAY• B260A: IGNITION RELAY• B260F: ENG STATE SIG LOST• B2614: ACC RELAY CIRC• B2615: BLOWER RELAY CIRC• B2616: IGN RELAY CIRC• B2617: STARTER RELAY CIRC• B2618: BCM• B261A: PUSH-BTN IGN SW• B261E: VEHICLE TYPE• B26EA: KEY REGISTRATION• C1729: VHCL SPEED SIG ERR• U0415: VEHICLE SPEED SIG	D
4	<ul style="list-style-type: none">• C1704: LOW PRESSURE FL• C1705: LOW PRESSURE FR• C1706: LOW PRESSURE RR• C1707: LOW PRESSURE RL• C1708: [NO DATA] FL• C1709: [NO DATA] FR• C1710: [NO DATA] RR• C1711: [NO DATA] RL• C1716: [PRESSDATA ERR] FL• C1717: [PRESSDATA ERR] FR• C1718: [PRESSDATA ERR] RR• C1719: [PRESSDATA ERR] RL• C1734: CONTROL UNIT	E
5	<ul style="list-style-type: none">• B2622: INSIDE ANTENNA• B2623: INSIDE ANTENNA	F
6	<ul style="list-style-type: none">• B2622: INSIDE ANTENNA• B2623: INSIDE ANTENNA	G
		H
		I
		J
		K
		INL
		M
		N
		O
		P

DTC Index

INFOID:000000006856676

NOTE:

The details of time display are as follows.

- CRNT: A malfunction is detected now.
- PAST: A malfunction was detected in the past.

IGN counter is displayed on Freeze Frame Data. For details of Freeze Frame Data, refer to [BCS-18, "COMMON ITEM : CONSULT-III Function \(BCM - COMMON ITEM\)"](#).

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
No DTC is detected. further testing may be required.	—	—	—	—	—
U1000: CAN COMM	—	—	—	—	BCS-38
U1010: CONTROL UNIT(CAN)	—	—	—	—	BCS-39
U0415: VEHICLE SPEED SIG	—	—	—	—	BCS-40
B2190: NATS ANTENNA AMP	×	—	—	—	SEC-42
B2191: DIFFERENCE OF KEY	×	—	—	—	SEC-45
B2192: ID DISCORD BCM-ECM	×	—	—	—	SEC-46
B2193: CHAIN OF BCM-ECM	×	—	—	—	SEC-48
B2195: ANTI SCANNING	×	—	—	—	SEC-49
B2553: IGNITION RELAY	—	×	—	—	PCS-48
B2555: STOP LAMP	—	×	—	—	SEC-50
B2556: PUSH-BTN IGN SW	—	×	×	—	SEC-52
B2557: VEHICLE SPEED	×	×	×	—	SEC-54
B2560: STARTER CONT RELAY	×	×	×	—	SEC-55
B2562: LOW VOLTAGE	—	×	—	—	BCS-41
B2601: SHIFT POSITION	×	×	×	—	SEC-56
B2602: SHIFT POSITION	×	×	×	—	SEC-59
B2603: SHIFT POSI STATUS	×	×	×	—	SEC-61
B2604: PNP SW	×	×	×	—	SEC-64
B2605: PNP SW	×	×	×	—	SEC-66
B2608: STARTER RELAY	×	×	×	—	SEC-68
B260A: IGNITION RELAY	×	×	×	—	PCS-50
B260F: ENG STATE SIG LOST	×	×	×	—	SEC-70
B2614: ACC RELAY CIRC	—	×	×	—	PCS-52
B2615: BLOWER RELAY CIRC	—	×	×	—	PCS-55
B2616: IGN RELAY CIRC	—	×	×	—	PCS-58
B2617: STARTER RELAY CIRC	×	×	×	—	SEC-72
B2618: BCM	×	×	×	—	PCS-61
B261A: PUSH-BTN IGN SW	—	×	×	—	SEC-75
B261E: VEHICLE TYPE	×	×	×	(Turn ON for 15 seconds)	SEC-78
B2622: INSIDE ANTENNA	—	×	—	—	DLK-91
B2623: INSIDE ANTENNA	—	×	—	—	DLK-93
B26EA: KEY REGISTRATION	—	×	×	(Turn ON for 15 seconds)	SEC-71
C1704: LOW PRESSURE FL	—	—	—	—	WT-23
C1705: LOW PRESSURE FR	—	—	—	—	
C1706: LOW PRESSURE RR	—	—	—	—	
C1707: LOW PRESSURE RL	—	—	—	—	

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
C1708: [NO DATA] FL	—	—	—	×	WT-25
C1709: [NO DATA] FR	—	—	—	×	
C1710: [NO DATA] RR	—	—	—	×	
C1711: [NO DATA] RL	—	—	—	×	
C1716: [PRESSDATA ERR] FL	—	—	—	×	WT-28
C1717: [PRESSDATA ERR] FR	—	—	—	×	
C1718: [PRESSDATA ERR] RR	—	—	—	×	
C1719: [PRESSDATA ERR] RL	—	—	—	×	
C1729: VHCL SPEED SIG ERR	—	—	—	×	WT-29
C1734: CONTROL UNIT	—	—	—	×	WT-30

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

COMBINATION METER

Reference Value

INFOID:0000000006856683

VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Condition		Value/Status
SPEED METER [km/h]	Ignition switch ON	While driving	Equivalent to speedometer reading NOTE: 655.35 is displayed when the malfunction signal is received
SPEED OUTPUT [km/h]	Ignition switch ON	While driving	Equivalent to speedometer reading NOTE: 655.35 is displayed when the malfunction signal is received
ODO OUTPUT [km/h or mph]	Ignition switch ON	—	Equivalent to odometer reading in combination meter
TACHO METER [rpm]	Ignition switch ON	While driving	Equivalent to tachometer reading NOTE: 8191.875 is displayed when the malfunction signal is received
FUEL METER [L]	Ignition switch ON	—	Values according to fuel level
W TEMP METER [°C]	Ignition switch ON	—	Values according to engine coolant temperature NOTE: 215 is displayed when the malfunction signal is input
FUEL CAP W/L	Ignition switch ON	Fuel filler cap warning display ON	On
		Fuel filler cap warning display OFF	Off
ABS W/L	Ignition switch ON	ABS warning lamp ON	On
		ABS warning lamp OFF	Off
VDC/TCS IND	Ignition switch ON	VDC OFF indicator lamp ON	On
		VDC OFF indicator lamp OFF	Off
SLIP IND	Ignition switch ON	SLIP Indicator lamp ON	On
		SLIP indicator lamp OFF	Off
BRAKE W/L	Ignition switch ON	Brake warning lamp ON	On
		Brake warning lamp OFF	Off
DOOR W/L	Ignition switch ON	Door warning lamp ON	On
		Door warning lamp OFF	Off
HI-BEAM IND	Ignition switch ON	High-beam indicator lamp ON	On
		High-beam indicator lamp OFF	Off
TURN IND	Ignition switch ON	Turn signal indicator lamp ON	On
		Turn signal indicator lamp OFF	Off
LIGHT IND	Ignition switch ON	Light indicator lamp ON	On
		Light indicator lamp OFF	Off
OIL W/L	Ignition switch ON	Oil pressure warning lamp ON	On
		Oil pressure warning lamp OFF	Off
MIL	Ignition switch ON	Malfunction indicator lamp ON	On
		Malfunction indicator lamp OFF	Off

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition		Value/Status
CRUISE IND	Ignition switch ON	CRUISE indicator lamp ON	On
		CRUISE indicator lamp OFF	Off
O/D OFF IND	Ignition switch ON	O/D OFF indicator lamp ON	On
		O/D OFF indicator lamp OFF	Off
4WD W/L	Ignition switch ON	AWD warning lamp ON	On
		AWD warning lamp OFF	Off
4WD LOCK IND	Ignition switch ON	AWD LOCK indicator lamp ON	On
		AWD LOCK indicator lamp OFF	Off
FUEL W/L	Ignition switch ON	Low-fuel warning lamp ON	On
		Low-fuel warning lamp OFF	Off
WASHER W/L	Ignition switch ON	Washer warning displayed	On
		Washer warning not displayed	Off
AIR PRES W/L	Ignition switch ON	Low tire pressure lamp ON	On
		Low tire pressure lamp OFF	Off
KEY G/Y W/L	Ignition switch ON	Key warning lamp (green/yellow) ON	On
		Key warning lamp (green/yellow) OFF	Off
LCD	Ignition switch ON	Engine start information display	B&P I
	Ignition switch ACC	Engine start information display	B&P N
	Ignition switch LOCK	Key ID warning display	ID NG
	Ignition switch LOCK	Steering lock information display	ROTAT
	Ignition switch LOCK	P position warning display	SFT P
	Ignition switch LOCK	Intelligent Key insert information display	INSRT
	Ignition switch LOCK	Intelligent Key low battery warning display	BATT
	Ignition switch ON	Take away warning display	NO KY
	Ignition switch LOCK	Key warning display	OUTKY
SHIFT IND	Ignition switch ON	ACC warning display	LK WN
		Shift position indicator P display	P
		Shift position indicator R display	R
		Shift position indicator N display	N
		Shift position indicator D display	D
		Shift position indicator L display	L
	Ignition switch ON	Overdrive control switch ON	On
		Overdrive control switch OFF	Off
M RANGE SW	Ignition switch ON	NOTE: This item is displayed, but cannot be monitored.	Off
NM RANGE SW	Ignition switch ON	NOTE: This item is displayed, but cannot be monitored.	Off

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

COMBINATION METER


< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition		Value/Status
AT SFT UP SW	Ignition switch ON	NOTE: This item is displayed, but cannot be monitored.	Off
AT SFT DWN SW	Ignition switch ON	NOTE: This item is displayed, but cannot be monitored.	Off
ST SFT UP SW	Ignition switch ON	NOTE: This item is displayed, but cannot be monitored.	Off
ST SFT DWN SW	Ignition switch ON	NOTE: This item is displayed, but cannot be monitored.	Off
PKB SW	Ignition switch ON	Parking brake switch ON	On
		Parking brake switch OFF	Off
BUCKLE SW	Ignition switch ON	Seat belt (driver side) not fastened	On
		Seat belt (driver side) fastened	Off
BRAKE OIL SW	Ignition switch ON	Brake fluid level switch ON	On
		Brake fluid level switch OFF	Off
DISTANCE [km]	Ignition switch ON	—	Possible driving distance calculated by combination meter
A/C AMP CONN	Ignition switch ON	Other than the following	On
		Receives ambient sensor power signal	Off
ENTER SW	Ignition switch ON	When is pressed	On
		Other than the above	Off
SELECT SW	Ignition switch ON	When is pressed	On
		Other than the above	Off
OUTSIDE TEMP [°C] or [°F]	Ignition switch ON	—	Equivalent to ambient temperature NOTE: This may not match the indicated value on the information display.
FUEL LOW SIG	Ignition switch ON	Low fuel warning displayed	On
		Low fuel warning not displayed	Off
BUZZER	Ignition switch ON	Buzzer ON	On
		Buzzer OFF	Off

NOTE:

Some items are not available according to vehicle specification.



TERMINAL LAYOUT



PHYSICAL VALUES

COMBINATION METER



< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
1 (Y)	Ground	Battery power supply	Input	Ignition switch OFF	—	Battery voltage
2 (O)	Ground	IGN signal	Input	Ignition switch ON	—	Battery voltage
3 (B)	Ground	Ground	—	Ignition switch ON	—	0 V
5 (SB)	Ground	Illumination control signal	Output	Ignition switch ON	• Lighting switch 1ST • When meter illumination is maximum	 <small>JPNIA0828GB</small>
					• Lighting switch 1ST • When meter illumination is minimum	 <small>JPNIA0827GB</small>
8 (SB)	10 (O)	Trip reset signal	Input	Ignition switch ON	When trip reset switch is pressed.	0 V
					Other than the above	5 V
10 (O)	Ground	Meter control switch ground	—	Ignition switch ON	—	0 V
11 (L)	10 (O)	Enter switch signal	Input	Ignition switch ON	When  is pressed.	0 V
					Other than the above	5 V
12 (R)	10 (O)	Select switch signal	Input	Ignition switch ON	When  is pressed.	0 V
					Other than the above	5 V
13 (Y ^{*1} or V ^{*2})	10 (O)	Illumination control switch signal (+)	Input	Ignition switch ON	When  is pressed.	0 V
					Other than the above	5 V
14 (GR)	10 (O)	Illumination control switch signal (-)	Input	Ignition switch ON	When  is pressed.	0 V
					Other than the above	5 V
15 (BR)	Ground	Air bag signal	Input	Ignition switch ON	Air bag warning lamp ON	4 V
					Air bag warning lamp OFF	0 V

A
B
C
D
E
F
G
H
I
J
K
L
INL
M
N
O
P



COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
18 (L)	Ground	Ambient sensor signal	Input	Ignition switch ON	Changes depending to ambient temperature.	 JSNIA0014GB
19 (P)	Ground	Ambient sensor power	Input	Ignition switch ON	—	5 V
20 (Y)	Ground	Ambient sensor ground	Input	Ignition switch ON	—	0 V
21 (L)	—	CAN-H	—	—	—	—
22 (P)	—	CAN-L	—	—	—	—
23 (B)	Ground	Ground	—	Ignition switch ON	—	0 V
24 (W)	Ground	Fuel level sensor signal ground	—	Ignition switch ON	—	0 V
25 (BR)	Ground	Alternator signal	Input	Ignition switch ON	Charge warning lamp ON	2 V
					Charge warning lamp OFF	12 V
26 (G)	Ground	Parking brake switch signal	Input	Ignition switch ON	Parking brake ON	0 V
					Parking brake OFF	5 V
27 (V)	Ground	Brake fluid level switch signal	Input	Ignition switch ON	Brake fluid level is normal	12 V
					Brake fluid level is less than LOW level	0 V
29 (R)	Ground	Washer level switch signal	Input	Ignition switch ON	Washer level switch ON	0 V
					Washer level switch OFF	5 V
30 (P)	Ground	Vehicle speed signal output (2-pulse)	Output	Ignition switch ON	Speedometer operated [When vehicle speed is approx. 40 km/h (25 MPH)]	NOTE: The maximum voltage varies depending on the specification (destination unit).
 JSNIA0015GB						

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
31 (V)	Ground	Vehicle speed signal output (8-pulse)	Output	Ignition switch ON	Speedometer operated [When vehicle speed is approx. 40 km/h (25 MPH)]	NOTE: The maximum voltage varies de- pending on the specification (destination unit).  <small>JSNIA0012GB</small>
32 (LG)	Ground	Overdrive control switch signal	Input	Ignition switch ON	Overdrive control switch pressed.	0 V
					Overdrive control switch not pressed.	12 V
34 (G)	Ground	Fuel level sensor signal	Input	Ignition switch ON	—	 <small>JPNIA0740ZZ</small>
35 (SB)	Ground	Seat belt buckle switch sig- nal (driver side)	Input	Ignition switch ON	When driver seat belt is fas- tened.	12 V
					When driver seat belt is un- fastened.	0 V
36 (R)	Ground	Seat belt buckle switch sig- nal (passenger side)	Input	Ignition switch ON	<ul style="list-style-type: none"> • When getting in the pas- senger seat. • When passenger seat belt is fastened. 	12 V
					<ul style="list-style-type: none"> • When getting in the pas- senger seat. • When passenger seat belt is unfastened. 	0 V

*1: Without automatic drive positioner

*2: With automatic drive positioner

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O


P

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

Wiring Diagram - METER -

INFOID:0000000006856684




JCNWM5340GB

2010/09/06

COMBINATION METER


< ECU DIAGNOSIS INFORMATION >



JCNWM5341GE

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >



JCNWWM5342GB

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

METER		Signal Name [Specification]							
Terminal No.	Color of Wire	Terminal No.	Color of Wire	Terminal No.	Color of Wire	Terminal No.	Color of Wire	Terminal No.	Color of Wire
1	SB	20	P	21	LG	22	W	23	Y
2	W	-	-	24	GR	-	-	25	Y
3	W	-	-	26	V	27	V	28	WL
4	R	-	-	29	P	30	P	31	O
5	O	-	-	32	BR	33	BR	34	SB
6	P	-	-	35	SB	36	LO	37	LG
7	L	-	-	38	BR	39	Y	40	Y
8	B	-	-	41	GR	42	GR	43	GR
9	LG	-	-	44	SB	45	SB	46	LG
10	V	-	-	47	SB	48	SHIELD	49	B
11	L	-	-	50	RW	51	R/L	52	B
12	BR	-	-	53	Y	54	LG	55	BR
13	P	-	-	56	P	57	L	58	R
14	BR	-	-	59	SHIELD	60	B	61	R/L
15	O	-	-	62	RW	63	LG	64	Y
16	G	-	-	65	BR	66	V	67	GR
Connector No.	B4	Connector Name	WIRE TO WIRE	Connector No.	B19	Connector Name	WIRE TO WIRE	Connector No.	B16
Connector Type	NS16MW-CS			Connector Type	NS16FW-CS	Connector Type	NS16FW-CS	Connector Type	NS16FW-CS

JCNWM5343GB

A B C D E F G H I J K L M N O P

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

METER	Connector No.	B240	Connector Name	FUEL LEVEL SENSOR UNIT AND FUEL PUMP	Connector Type	EOSFY-RS		
	Connector No.	B214	Connector Name	WIRE TO WIRE	Connector Type	NSD6FW-CS		
	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]		
EGR	Connector No.	B209	Connector Name	WIRE TO WIRE	Connector Type	TK2NG-Y-BD		
	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]		
	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]		
SEAT BELT BUCKLE SWITCH (PASSENGER SIDE)	Connector No.	B437	Connector Name	SEAT BELT BUCKLE SWITCH (PASSENGER SIDE)	Connector Type	A03MW-P		
	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]		
	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]		
SEAT BELT BUCKLE SWITCH (DRIVER SIDE)	Connector No.	B449	Connector Name	SEAT BELT BUCKLE SWITCH (DRIVER SIDE)	Connector Type	A03MW-P		
	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]		
	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]		
FUEL LEVEL SENSOR UNIT AND FUEL PUMP	Connector No.	B301	Connector Name	FUEL LEVEL SENSOR UNIT AND FUEL PUMP	Connector Type	-		
	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]		
	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]		
WIRE TO WIRE	Connector No.	B431	Connector Name	WIRE TO WIRE	Connector Type	NSD6BW-CS		
	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]		
	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]		
WIRE TO WIRE	Connector No.	B409	Connector Name	SEAT BELT BUCKLE SWITCH (DRIVER SIDE)	Connector Type	A03MW-P		
	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]		
	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]		

JCNWM5344GB

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

METER			
Connector No.	B460	Terminal Color of Wire No.	Signal Name [Specification]
Connector Name	WIRE TO WIRE	10 W	-
Connector Type	NS16WW-CS	11 G	-
Connector No.	E8	12 BR	-
Connector Name	WIRE TO WIRE	13 SS	-
Connector Type	NS12WBR-CS	14 B	-
Connector No.	TH08FW-NH	1 2 3 4 5 6 7 8 9 10 11 12	Signal Name [Specification]
Connector Name	IGN & INTELLIGENT POWER DISTRIBUTION MODULE_E ENGINE ROOM		
Connector Type			
Connector No.	E11	42 41 40 39 46 45 44 43	Signal Name [Specification]
Connector Name	IGN & INTELLIGENT POWER DISTRIBUTION MODULE_E ENGINE ROOM		
Connector Type	TH08FW-NH		
Connector No.	E10	1 2 3 4 5 6 7 8 9 10 11 12 13 14 3 4 5 6 7 8 9 10 11 12 13 14 25 26 27 28 29 30 31 32 33 34 35 36	Signal Name [Specification]
Connector Name	IGN & INTELLIGENT POWER DISTRIBUTION MODULE_E ENGINE ROOM		
Connector Type	TH08FW-CS12-M4-I		
Connector No.	E6	1 2 3 4 5 6 7 8 9 10 11 12 13 14 3 4 5 6 7 8 9 10 11 12 13 14 25 26 27 28 29 30 31 32 33 34 35 36	Signal Name [Specification]
Connector Name	WIRE TO WIRE		
Connector Type	TK16MGTV		
Connector No.	E16		Color Name [Specification]
Connector Name	ECM		
Connector Type	RH24FB-RZ8-L-LH		
Terminal Color of Wire No.	Signal Name [Specification]	19 Y	-
		20 L	-
		21 O	-
		22 SS	-
		23 GR	-
		24 G	-
		25 GR	-
		26 Y	-
		27 W	-
		28 SB	-
		29 BR	-
		30 BR	-
		31 O	-
		32 P	-
		33 G	-
		34 GR	-
		35 P	-
		36 G	-
		37 GR	-
Terminal Color of Wire No.	Signal Name [Specification]	38 G	-
		39 P	-
		40 L	-
		41 B	-
		42 SE	-
		43 Y	-
		44 W	-
		45 O	-
		46 BR	-
Terminal Color of Wire No.	Signal Name [Specification]	47	-
		48	-
		49	-
		50	-
		51	-
		52	-
		53	-
		54	-
Terminal Color of Wire No.	Signal Name [Specification]	55	-
		56	-
		57	-
		58	-
		59	-
		60	-
		61	-
		62	-
		63	-
		64	-
Terminal Color of Wire No.	Signal Name [Specification]	65	-
		66	-
		67	-
		68	-
		69	-
		70	-
		71	-
		72	-
		73	-
		74	-
		75	-
		76	-
		77	-
		78	-
		79	-
		80	-
		81	-
		82	-
		83	-
		84	-
		85	-
		86	-
		87	-
		88	-
		89	-
		90	-
		91	-
		92	-
		93	-
		94	-
		95	-
		96	-
		97	-
		98	-
		99	-
		100	-
		101	-
		102	-
		103	-
		104	-
		105	-
		106	-
		107	-
		108	-
		109	-
		110	-
		111	-
		112	-
		113	-
		114	-
		115	-
		116	-
		117	-
		118	-
		119	-
		120	-
		121	-
		122	-
		123	-
		124	-
		125	-
		126	-
		127	-
		128	-
		129	-
		130	-
		131	-
		132	-
		133	-
		134	-
		135	-
		136	-
		137	-
		138	-
		139	-
		140	-
		141	-
		142	-
		143	-
		144	-
		145	-
		146	-
		147	-
		148	-
		149	-
		150	-
		151	-
		152	-
		153	-
		154	-
		155	-
		156	-
		157	-
		158	-
		159	-
		160	-
		161	-
		162	-
		163	-
		164	-
		165	-
		166	-
		167	-
		168	-
		169	-
		170	-
		171	-
		172	-
		173	-
		174	-
		175	-
		176	-
		177	-
		178	-
		179	-
		180	-
		181	-
		182	-
		183	-
		184	-
		185	-
		186	-
		187	-
		188	-
		189	-
		190	-
		191	-
		192	-
		193	-
		194	-
		195	-
		196	-
		197	-
		198	-
		199	-
		200	-
		201	-
		202	-
		203	-
		204	-
		205	-
		206	-
		207	-
		208	-
		209	-
		210	-
		211	-
		212	-
		213	-
		214	-
		215	-
		216	-
		217	-
		218	-
		219	-
		220	-
		221	-
		222	-
		223	-
		224	-
		225	-
		226	-
		227	-
		228	-
		229	-
		230	-
		231	-
		232	-
		233	-
		234	-
		235	-
		236	-
		237	-
		238	-
		239	-
		240	-
		241	-
		242	-
		243	-
		244	-
		245	-
		246	-
		247	-
		248	-
		249	-
		250	-
		251	-
		252	-
		253	-
		254	-
		255	-
		256	-
		257	-
		258	-
		259	-
		260	-
		261	-
		262	-
		263	-
		264	-
		265	-
		266	-
		267	-
		268	-
		269	-
		270	-
		271	-
		272	-
		273	-
		274	-
		275	-
		276	-
		277	-
		278	-
		279	-
		280	-
		281	-
		282	-
		283	-
		284	-
		285	-
		286	-
		287	-
		288	-
		289	-
		290	-
		291	-
		292	-
		293	-
		294	-
		295	-
		296	-
		297	-
		298	-
		299	-
		300	-
		301	-
		302	-
		303	-
		304	-
		305	-
		306	-
		307	-
		308	-
		309	-
		310	-
		311	-
		312	-
		313	-
		314	-
		315	-
		316	-
		317	-
		318	-
		319	-
		320	-
		321	-
		322	-
		323	-
		324	-
		325	-
		326	-
		327	-
		328	-
		329	-
		330	-
		331	-
		332	-
		333	-
		334	-
		335	-
		336	-
		337	-
		338	-
		339	-
		340	-
		341	-
		342	-
		343	-
		344	-
		345	-
		346	-
		347	-
		348	-
		349	-
		350	-
		351	-
		352	-
		353	-
		354	-
		355	-
		356	-
		357	-
		358	-
		359	-
		360	-
		361	-
		362	-
		363	-
		364	-
		365	-
		366	-
		367	-
		368	-
		369	-
		370	-
		371	-
		372	-
		373	-
		374	-
		375	-
		376	-
		377	-
		378	-
		379	-
		380	-
		381	-
		382	-
		383	-
		384	-
		385	-
		386	-
		387	-
		388	-
		389	-
		390	-
		391	-
		392	-
		393	-
		394	-
		395	-
		396	-
		397	-
		398	-
		399	-
		400	-
		401	-
		402	-
		403	-
		404	-
		405	-
		406	-
		407	-
		408	-
		409	-
		410	-
		411	-
		412	-
		413	-
		414	-
		415	-
		416	-
		417	-
		418	-
		419	-
		420	-
		421	-
		422	-
		423	-
		424	-
		425	-
		426	-
		427	-
		428	-
		429	-
		430	-
		431	-
		432	-
		433	-
		434	-
		435	-
		436	-
		437	-
		438	-
		439	-
		440	-
		441	-
		442	-
		443	-
		444	-
		445	-
		446	-
		447	-
		448	-
		449	-
		450	-
		451	-
		452	-
		453	-
		454	-
		455	-
		456	-
		457	-
		458	-
		459	-
		460	-
		461	-
		462	-
		463	-
		464	

JCNWM5345GB

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

JCNWM5346GB

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

METER		Connector No.	Connector Name	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
Connector No.		E338	POWER INTELLIGENT POWER DISTRIBUTION MODULE		7	GR		7	GR	
Connector Name		WASHER LEVEL SWITCH	ENGINE ROOM		80	B		80	B	
Connector Type		Z02FBR	TH16FY-NH							
Connector No.		E346	POWER INTELLIGENT POWER DISTRIBUTION MODULE		91	GR		91	GR	
Connector Name		TH16FY-NH	ENGINE ROOM		92	G		92	G	
Connector Type		TH16FY-NH	TH16FY-NH		93	R		93	R	
					94	Y		94	Y	
					95	W		95	W	
					96	W		96	W	
					97	W		97	W	
					98	W		98	W	
					99	W		99	W	
					100	W		100	W	
					101	L		101	L	
					102	B		102	B	
					103	P		103	P	
Connector No.		E339	POWER INTELLIGENT POWER DISTRIBUTION MODULE		104	W		104	W	
Connector Name		WIRE TO WIRE	ENGINE ROOM		105	W		105	W	
Connector Type		NS12FBR-CS	TH16FY-NH		106	W		106	W	
					107	W		107	W	
					108	W		108	W	
					109	W		109	W	
					110	W		110	W	
					111	W		111	W	
					112	W		112	W	
Connector No.		F12	POWER INTELLIGENT POWER DISTRIBUTION MODULE		113	W		113	W	
Connector Name		TH120FY-GSI2-M4	ENGINE ROOM		114	W		114	W	
Connector Type		TH120FY-GSI2-M4	TH120FY-GSI2-M4		115	W		115	W	
					116	W		116	W	
					117	W		117	W	
					118	W		118	W	
					119	W		119	W	
					120	W		120	W	
Connector No.		E347	POWER INTELLIGENT POWER DISTRIBUTION MODULE		121	W		121	W	
Connector Name		TH16FY-NH	ENGINE ROOM		122	W		122	W	
Connector Type		TH16FY-NH	TH16FY-NH		123	W		123	W	
					124	W		124	W	
					125	W		125	W	
					126	W		126	W	
					127	W		127	W	
					128	W		128	W	
					129	W		129	W	
					130	W		130	W	
					131	W		131	W	
					132	W		132	W	
					133	W		133	W	
					134	W		134	W	
					135	W		135	W	
					136	W		136	W	
					137	W		137	W	
					138	W		138	W	
					139	W		139	W	
					140	W		140	W	
					141	W		141	W	
					142	W		142	W	
					143	W		143	W	
					144	W		144	W	
					145	W		145	W	
					146	W		146	W	
					147	W		147	W	
					148	W		148	W	
					149	W		149	W	
					150	W		150	W	
					151	W		151	W	
					152	W		152	W	
					153	W		153	W	
					154	W		154	W	
					155	W		155	W	
					156	W		156	W	
					157	W		157	W	
					158	W		158	W	
					159	W		159	W	
					160	W		160	W	
					161	W		161	W	
					162	W		162	W	
					163	W		163	W	
					164	W		164	W	
					165	W		165	W	
					166	W		166	W	
					167	W		167	W	
					168	W		168	W	
					169	W		169	W	
					170	W		170	W	
					171	W		171	W	
					172	W		172	W	
					173	W		173	W	
					174	W		174	W	
					175	W		175	W	
					176	W		176	W	
					177	W		177	W	
					178	W		178	W	
					179	W		179	W	
					180	W		180	W	
					181	W		181	W	
					182	W		182	W	
					183	W		183	W	
					184	W		184	W	
					185	W		185	W	
					186	W		186	W	
					187	W		187	W	
					188	W		188	W	
					189	W		189	W	
					190	W		190	W	
					191	W		191	W	
					192	W		192	W	
					193	W		193	W	
					194	W		194	W	
					195					

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

METER				
Connector No.	F123	Connector No.	M3	
Connector Name	WIRE TO WIRE	Connector Name	WIRE TO WIRE	
Connector Type	TK16FGY-IV	Connector Type	NS12FW-CS	
				
Terminal No.	Color of Wire	Signal Name [Specification]		
1	L	-		
3	GR	6C BR	3	P
4	GB	7C B	5	O
5	R	8C G	6	G
6	L/R	9C GR	8	R
8	P	10C SB	11	P
10	Y/B	11C R	12	L
11	BR/W	12C O	13	V
12	BR	-	14	Y
13	G	-	15	R
14	B	-	20	Y
			21	BR
			22	G
			24	Y
			25	L
			28	BR
			29	L
			30	R
			47	P
			48	W
			49	GR
			50	LG
			52	Y
			53	V
			54	SB
			55	P
			56	SB
			60	V
			61	GR
			62	O
			63	V
			64	SHEILD
			66	W
			67	R
			68	W
			69	P
			70	G
			71	G

JCNWM5348GB

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

ICNWM5349GB

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

JCNWM5350GB

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

A

B

C

D

E

F

G

H

I

K

L

M

N

O

P

INL

METER		Connector No.	M172	AV COMM (H)
Terminal	Color No.	Connector Name	AV CONTROL UNIT	CAN-H
79	SB	Connector Type	TH24FW-NH	SW GND
80	P			SHIELD
81	L			V
82	V			TELEPHONE SIGNAL (-)
86	SHIELD			TELEPHONE SIGNAL (+)
87	R			VEHICLE SPEED SIGNAL (G-PULSE)
88	L			PARKING BRAKE [With BOSE system]
92	V			PARKING BRAKE [Without BOSE system]
93	G			REVERSE
94	SB			IGNITION
95	G			DISK EJECT SIGNAL
96	W			AUX SOUND SIGNAL GND
102	V	Connector No.	M180	AUX SOUND SIGNAL LH (-)
103	B	Connector Name	AV CONTROL UNIT	AUX SOUND SIGNAL RH (-)
104	R	Connector Type	TH32FW-NH	

Terminal	Color No.	Wire	Signal Name [Specification]	Signal Name [Specification]
36	O		SIGNAL VCC	SIGNAL VCC
37	SB		SIGNAL GND	SIGNAL GND
38	G		HP	HP
39	L		COMM (DISP->CONT)	COMM (DISP->CONT)
40	W		RGE AREA (Y-S)	RGE AREA (Y-S)
41	SHIELD		SHIELD	SHIELD
42	B		RGB SYNC	RGB (R-RED) SIGNAL
43	G		RGB (G-GREEN) SIGNAL	RGB (G-GREEN) SIGNAL
44	L		RGB (B-BLUE) SIGNAL	RGB (B-BLUE) SIGNAL
45	Y		COMPOSITE IMAGE SIGNAL	COMPOSITE IMAGE SIGNAL
46	V		INVERTER VCC	INVERTER VCC
47	LG		INVERTER GND	INVERTER GND
48	Y		VP	VP
49	BR		COMM (CONT->DISP)	COMM (CONT->DISP)
50	R		SHIELD	SHIELD
51	P		SHIELD	SHIELD
52	SB		SHIELD	SHIELD
57	SHIELD		SHIELD	SHIELD
58	SHIELD		SHIELD	SHIELD

Terminal	Color No.	Wire	Signal Name [Specification]	Signal Name [Specification]
61	SB		63	64
62	LG		65	66
63	BR		67	68
64	G		69	70
65	R		71	72
66	V		73	74
67	LG		75	76
68	BR		77	78
69	G		79	80
70	R		81	82
71	V		83	84
72	LG		85	86
73	BR		87	88
74	G		89	90
75	G		91	92

Terminal	Color No.	Wire	Signal Name [Specification]	Signal Name [Specification]
76	SB		80	81
77	LG		82	83
78	BR		84	85
79	G		86	87
80	R		88	89
81	V		90	91
82	LG		92	93
83	BR		94	95
84	G		96	97
85	R		98	99
86	V		100	101
87	LG		102	103
88	BR		104	105
89	G		106	107
90	R		108	109
91	V		110	111
92	LG		112	113
93	BR		114	115
94	G		116	117
95	R		118	119
96	V		120	121

JCNWMS351GB

INFOID:0000000006856685

Fail-Safe

FAIL-SAFE

The combination meter activates the fail-safe control if CAN communication with each unit is malfunctioning.

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

Function		Specifications
Speedometer		
Tachometer		Reset to zero by suspending communication.
Engine coolant temperature gauge		
Illumination control		When suspending communication, changes to nighttime mode.
Information display	Door open warning	The display turns off by suspending communication.
	Parking brake release warning	
	Low tire pressure warning	
	Fuel filler cap warning	
	Instantaneous fuel warning	• When reception time of an abnormal signal is 2 seconds or less, the last received datum is used for calculation to indicate the result.
	Average fuel consumption	• When reception time of an abnormal signal is more than two seconds, the last result calculated during normal condition is indicated.
	Average vehicle speed	
	Travel distance	
Buzzer		The buzzer turns off by suspending communication.
Warning lamp/indicator lamp	ABS warning lamp	The lamp turns on by suspending communication.
	SLIP indicator lamp	
	Brake warning lamp	
	AWD warning lamp	
	Malfunction indicator lamp	
	Low tire pressure warning lamp	The lamp turns ON after flashing for 1 minute.
	High beam indicator lamp	The lamp turns off by suspending communication.
	Turn signal indicator lamp	
	Light indicator lamp	
	Oil pressure warning lamp	
	CRUISE indicator lamp	
	O/D OFF indicator lamp	
	VDC OFF indicator lamp	
	AWD LOCK indicator lamp	
	Key warning lamp	

DTC Index

INFOID:000000006856686

Display contents of CONSULT-III	Diagnostic item is detected when ...	Refer to
CAN COMM CIRCUIT [U1000]	When combination meter is not transmitting or receiving CAN communication signal for 2 seconds or more.	MWI-39. "Diagnosis Procedure"
CONTROL UNIT (CAN) [U1010]	When detecting error during the initial diagnosis of the CAN controller of combination meter.	MWI-40. "Diagnosis Procedure"
VEHICLE SPEED [B2205]	The abnormal vehicle speed signal is input from the ABS actuator and electric unit (control unit) for 2 seconds or more.	MWI-41. "Diagnosis Procedure"

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

Display contents of CONSULT-III	Diagnostic item is detected when ...	Refer to
ENGINE SPEED [B2267]	If ECM continuously transmits abnormal engine speed signals for 2 seconds or more.	MWI-42 "Diagnosis Procedure"
WATER TEMP [B2268]	If ECM continuously transmits abnormal engine coolant temperature signals for 60 seconds or more.	MWI-43 "Diagnosis Procedure"

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

INTERIOR LIGHTING SYSTEM SYMPTOMS

<SYMPTOM DIAGNOSIS>

SYMPTOM DIAGNOSIS

INTERIOR LIGHTING SYSTEM SYMPTOMS

Symptom Table

INFOID:000000006262844

CAUTION:

Perform the self-diagnosis with CONSULT-III before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom	Possible cause	Inspection item
All the following lamps are not turned ON. <ul style="list-style-type: none">• Map lamp• Personal lamp• Luggage room lamp• Step lamp• Vanity mirror lamp	<ul style="list-style-type: none">• Harness between BCM and each interior room lamp• BCM	Interior room lamp power supply circuit Refer to INL-19 .
<ul style="list-style-type: none">• Interior room lamp is not turned ON even though the door is open. (It turns ON when turning the interior room lamp ON.)• Interior room lamp does not turn OFF even though the door is closed.	<ul style="list-style-type: none">• Harness between BCM and each door switch• Harness between BCM and each interior room lamp• BCM	Door switch circuit Refer to DLK-97 . Interior room lamp control circuit Refer to INL-21 .
Interior room lamp timer does not activate. (It turns ON/ OFF when the door opens/closes.)	—	Check the interior room lamp setting. Refer to INL-15 .
Step lamps (driver side and passenger side) are not turned ON. (Map lamp and personal lamp are turned ON.)	<ul style="list-style-type: none">• Harness between BCM and each step lamp• BCM	Step lamp circuit Refer to INL-23 .
Step lamps (driver side and passenger side) are not turned OFF. (Map lamp and personal lamp are turned OFF.)	<ul style="list-style-type: none">• Harness between BCM and push-button ignition switch• BCM	Push-button ignition switch illumination circuit Refer to INL-25 .
Interior room lamp battery saver does not activate.	—	Check the interior room lamp battery saver setting. Refer to INL-16 .

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

FOR USA AND CANADA

FOR USA AND CANADA : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000006262845

A
B
C
D
E
F
G
H
I
J
K

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted.

Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

FOR MEXICO

FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INL

INFOID:000000006262846

M
N

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

PRECAUTIONS

< PRECAUTION >

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

MAP LAMP


< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION

MAP LAMP

Exploded View

INFOID:000000006262847



1. Map lamp assembly

2. Bulb

3. Lens

Removal and Installation

INFOID:000000006262848

Refer to [INT-26. "NORMAL ROOF : Exploded View"](#) (Normal roof) or [INT-30. "SUNROOF : Exploded View"](#) (With sunroof) for the map lamp assembly installation/removal.

Replacement

INFOID:000000006262849

CAUTION:

- Disconnect the battery negative terminal or remove the fuse.
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.
- Never touch bulb by hand while it is lit or right after being turned off.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

MAP LAMP BULB

INL

1. Insert any appropriate tool into the gap between the lens. Remove the lens.
2. Remove the bulb.

M

N

O

P

MOOD LAMP

< REMOVAL AND INSTALLATION >

MOOD LAMP

MAP LAMP

MAP LAMP : Replacement

INFOID:000000006262850

MAP LAMP

Mood lamp (map lamp) is integrated into the map lamp assembly. Refer to [INL-111, "Exploded View"](#).

FRONT DOOR GRIP

FRONT DOOR GRIP : Replacement

INFOID:000000006262851

FRONT DOOR

Mood lamp (front door grip) is integrated into the front door trim. Refer to [INT-12, "FRONT DOOR FINISHER : Exploded View"](#).

ROOF CENTER

ROOF CENTER : Replacement

INFOID:000000006262852

ROOF CENTER

Mood lamp (roof center) is integrated into the headlining.

- Refer to [INT-26, "NORMAL ROOF : Exploded View"](#) (Normal roof).
- Refer to [INT-30, "SUNROOF : Exploded View"](#) (With sunroof).


VANITY MIRROR LAMP

< REMOVAL AND INSTALLATION >

VANITY MIRROR LAMP

Exploded View

INFOID:0000000006262853



1. Bulb
2. Lens

Replacement

INFOID:0000000006262854

CAUTION:

- Disconnect the battery negative terminal or remove the fuse.
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.
- Never touch bulb by hand while it is lit or right after being turned off.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

VANITY MIRROR LAMP BULB

1. Insert any appropriate tool into the gap between the lens. Remove the lens.
2. Remove the bulb.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P


CONSOLE POCKET LAMP

< REMOVAL AND INSTALLATION >

CONSOLE POCKET LAMP

Exploded View

INFOID:0000000006262855



1. Bulb
2. Bulb socket

Replacement

INFOID:0000000006262856

CAUTION:

- Disconnect the battery negative terminal or remove the fuse.
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.
- Never touch bulb by hand while it is lit or right after being turned off.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

CONSOLE POCKET LAMP BULB

1. Remove the cluster lid C (lower). Refer to [IP-12, "Exploded View"](#).
2. Rotate the bulb socket counterclockwise and unlock it.
3. Remove the bulb.


ASHTRAY ILLUMINATION

< REMOVAL AND INSTALLATION >

ASHTRAY ILLUMINATION

Exploded View

INFOID:0000000006262857



1. Bulb socket

2. Bulb

Replacement

INFOID:0000000006262858

CAUTION:

- Disconnect the battery negative terminal or remove the fuse.
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.
- Never touch bulb by hand while it is lit or right after being turned off.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

ASHTRAY ILLUMINATION BULB

1. Remove the console finisher assembly. Refer to [IP-20, "Exploded View"](#).
2. Rotate the bulb socket counterclockwise and unlock it.
3. Remove the bulb.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P


GLOVE BOX LAMP

< REMOVAL AND INSTALLATION >

GLOVE BOX LAMP

Exploded View

INFOID:0000000006262859



1. Bulb

2. Bulb socket

Replacement

INFOID:0000000006262860

CAUTION:

- Disconnect the battery negative terminal or remove the fuse.
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.
- Never touch bulb by hand while it is lit or right after being turned off.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

GLOVE BOX LAMP BULB

1. Remove the glove box assembly. Refer to [IP-12, "Exploded View"](#).
2. Rotate the bulb socket counterclockwise and unlock it.
3. Remove the bulb.


STEP LAMP

< REMOVAL AND INSTALLATION >

STEP LAMP

Exploded View

INFOID:0000000006262861



1. Step lamp case

2. Bulb

3. Lens

A Metal clip

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

Removal and Installation

INFOID:0000000006262862

CAUTION:

Disconnect the battery negative terminal or remove the fuse.

REMOVAL

1. Insert any appropriate tool into the gap between the step lamp and the door trim. Remove the step lamp.
2. Disconnect the connector.

INSTALLATION

Install in the reverse order of removal.

Replacement

INFOID:0000000006262863

CAUTION:

- **Disconnect the battery negative terminal or remove the fuse.**
- **Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.**
- **Never touch bulb by hand while it is lit or right after being turned off.**
- **Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.**

STEP LAMP BULB

1. Insert any appropriate tool into the gap between the lens. Remove the lens.
2. Remove the bulb.


PERSONAL LAMP

< REMOVAL AND INSTALLATION >

PERSONAL LAMP

Exploded View

INFOID:0000000006262864



1. Personal lamp case
2. Personal lamp finisher
3. Lens
4. Bulb

NOTE:

Replace the personal lamp case as a set (right and left). After removing the headlining assembly, remove the personal lamp case. Refer to [INT-26, "NORMAL ROOF : Exploded View"](#) (Normal roof) or [INT-30, "SUNROOF : Exploded View"](#) (With sunroof).

Removal and Installation

INFOID:0000000006262865

CAUTION:


Disconnect the battery negative terminal or remove the fuse.

REMOVAL

1. Remove the headlining assembly. Refer to [INT-26, "NORMAL ROOF : Exploded View"](#) (Normal roof) or [INT-30, "SUNROOF : Exploded View"](#) (With sunroof).
2. Insert any appropriate tool into the gap between the lens. Remove the lens.
3. Press the both side pawls (A) to the arrow direction (➡). Remove the personal lamp finisher.
4. Remove the personal lamp case from the headlining assembly.

NOTE:

Replace the personal lamp case as a set (right and left).



JPLIA0087ZZ

INSTALLATION

Install in the reverse order of removal.


NOTE:

The following is easier to install the personal lamp finisher.

PERSONAL LAMP

< REMOVAL AND INSTALLATION >

- Press the personal lamp finisher to the headlining. Pull the personal lamp case pawl to the arrow direction () with any appropriate tool.



INFOID:0000000006262866

Replacement

CAUTION:

- Disconnect the battery negative terminal or remove the fuse.
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.
- Never touch bulb by hand while it is lit or right after being turned off.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

PERSONAL LAMP BULB

1. Insert any appropriate tool into the gap between the lens. Remove the lens.
2. Remove the bulb.

A
B
C
D

E
F

G
H
I
J

K

INL

M
N
O
P


LUGGAGE ROOM LAMP

< REMOVAL AND INSTALLATION >

LUGGAGE ROOM LAMP

Exploded View

INFOID:0000000006262867



JPLIA0838ZZ

1. Bulb

2. Luggage room lamp assembly

Removal and Installation

INFOID:0000000006262868

CAUTION:

Disconnect the battery negative terminal or remove the fuse.

REMOVAL

1. Insert any appropriate tool into the gap between the luggage room lamp assembly and back door finisher inner. Remove the luggage room lamp assembly.
2. Disconnect the connector.

INSTALLATION

Install in the reverse order of removal.

Replacement

INFOID:0000000006262869

CAUTION:

- Disconnect the battery negative terminal or remove the fuse.
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.
- Never touch bulb by hand while it is lit or right after being turned off.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

LUGGAGE ROOM LAMP BULB

1. Remove the luggage room lamp assembly.
2. Remove the bulb.

SERVICE DATA AND SPECIFICATIONS (SDS)

<SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

Bulb Specifications

INFOID:000000006262870

Item	Type	Wattage (W)
Push-button ignition switch illumination	LED	—
Map lamp	Wedge	8
Mood lamp	Map lamp	LED
	Front door grip	LED
	Roof center	LED
Vanity mirror lamp	—	2
Console pocket lamp	Wedge	1.4
Ashtray illumination	Wedge	1.4
Glove box lamp	Wedge	1.4
Step lamp	Wedge	2.7
Personal lamp	Wedge	8
Luggage room lamp	—	8

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P