

SECTION STC

STEERING CONTROL SYSTEM

CONTENTS

BASIC INSPECTION	2	POWER STEERING CONTROL UNIT	13
DIAGNOSIS AND REPAIR WORK FLOW	2	Reference Value	13
Work Flow	2	Wiring Diagram - ELECTRONICALLY CON-	
		TROLLED POWER STEERING SYSTEM -	15
		Fail-Safe	17
SYSTEM DESCRIPTION	3	SYMPTOM DIAGNOSIS	19
EPS SYSTEM	3	UNBALANCE STEERING WHEEL TURNING	
System Diagram	3	FORCE (TORQUE VARIATION)	19
System Description	3	Description	19
Component Parts Location	5	Diagnosis Procedure	19
Component Description	5	PRECAUTION	20
DTC/CIRCUIT DIAGNOSIS	6	PRECAUTIONS	20
POWER SUPPLY AND GROUND CIRCUIT	6	FOR USA AND CANADA	20
Description	6	FOR USA AND CANADA : Precaution for Supple-	
Diagnosis Procedure	6	mental Restraint System (SRS) "AIR BAG" and	
POWER STEERING SOLENOID VALVE	7	"SEAT BELT PRE-TENSIONER"	20
Description	7	FOR MEXICO	20
Diagnosis Procedure	7	FOR MEXICO : Precaution for Supplemental Re-	
Component Inspection	8	straint System (SRS) "AIR BAG" and "SEAT BELT	
ENGINE SPEED SIGNAL CIRCUIT	9	PRE-TENSIONER"	20
Description	9	Precautions for Removing of Battery Terminal	21
Diagnosis Procedure	9	REMOVAL AND INSTALLATION	22
VEHICLE SPEED SIGNAL CIRCUIT	11	POWER STEERING CONTROL UNIT	22
Description	11	Removal and Installation	22
Diagnosis Procedure	11		
ECU DIAGNOSIS INFORMATION	13		

A
B
C
D
E

F
STC

H
I
J
K
L
M
N
O
P

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000009722588

DETAILED FLOW

1.COLLECT THE INFORMATION FROM THE CUSTOMER

It is also important to clarify customer complaints before inspection. First of all, reproduce symptoms and understand them fully. Ask customer about his/her complaints carefully. In some cases, it is necessary to check symptoms by driving vehicle with customer.

CAUTION:

Customers are not professional. It is dangerous to make an easy guess like “maybe the customer means that...,” or “maybe the customer mentions this symptom”.

>> GO TO 2.

2.CHECK THE STATUS

1. Power steering fluid leakage and check the power steering fluid level. Refer to [ST-33. "Inspection"](#) (With heated steering wheel) or [ST-78. "Inspection"](#) (Without heated steering wheel).
2. Check the drive belt tension. Refer to [EM-17. "Checking"](#).
3. Check the power steering gear for damages, cracks and fluid leakage. Refer to [ST-56. "Inspection"](#) (With heated steering wheel) or [ST-98. "Inspection"](#) (Without heated steering wheel).
4. Check the relief oil pressure. Refer to [ST-62. "Inspection"](#) (With heated steering wheel), [ST-104. "Inspection"](#) (Without heated steering wheel).

>> GO TO 3.

3.DIAGNOSIS CHART BY SYMPTOM

Perform the diagnosis by symptom. Refer to [STC-19. "Diagnosis Procedure"](#).

>> GO TO 4.

4.FINAL CHECK

Check the input/output standard values for the power steering control unit.

Are the power steering control unit input/output values within standard ranges respectively?

YES >> INSPECTION END

NO >> GO TO 2.

EPS SYSTEM

< SYSTEM DESCRIPTION >


SYSTEM DESCRIPTION

EPS SYSTEM

System Diagram


INFOID:0000000009722589

CONTROL DIAGRAM



JSGIA0119GB

CROSS-SECTIONAL VIEW



JSGIA0376ZZ

1. Combination meter
2. Power steering control unit
3. Power steering solenoid valve
4. Steering gear assembly
5. Gear housing assembly
6. Gear sub-assembly
7. Pinion
8. Power steering oil pump
9. Reservoir tank

System Description


INFOID:0000000009722590

- The EPS system controls the power steering solenoid valve through the power steering control unit.

EPS SYSTEM


< SYSTEM DESCRIPTION >

- The valve driving voltage to control the power steering solenoid valve varies according to the vehicle speed.




OPERATION PRINCIPLE

During Parking (When Turning The Steering Wheel To The Right.)



- Power steering solenoid valve is closed while a vehicle is stopped.
- Pinion "1R", "2R" and "3R" are closed depending on steering torque of steering wheel.
- Oil pressure "P" in the gear housing assembly is the sum of oil pressures occurred in "2R" and "3R". This results in a light steering force because of high pressure.

During High-speed Operation




- Power steering solenoid valve is opened during high-speed operation.
- Pinion "1R", "2R" and "3R" are closed depending on steering torque of steering wheel.
- Oil pressure "2R" does not occur because the power steering solenoid valve is on full throttle.
- Oil pressure "P" in the gear housing assembly includes only oil pressure occurred in "3R" and results in a heavy steering force.

EPS SYSTEM

< SYSTEM DESCRIPTION >

Component Parts Location

INFOID:000000009722591



1. Power steering solenoid valve 2. Power steering control unit
A. Steering gear assembly B. Glove box assembly removed

◀: Vehicle front

Component Description

INFOID:000000009722592

Component parts	Reference/Function
Power steering control unit	<ul style="list-style-type: none">Signals from various sensors control the driving voltage to the power steering solenoid valve.The power steering control unit controls the driving voltage to the power steering solenoid valve for maintaining the power steering assist force when the fail-safe function is activated. (The engine speed signals control EPS system if any vehicle speed signal error is detected.)
Combination meter	STC-11, "Description"
ECM	STC-9, "Description"
Power steering solenoid valve	STC-7, "Description"

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT

Description

INFOID:000000009722593

Power supply to EPS system

Diagnosis Procedure

INFOID:000000009722594

1.CHECK POWER SUPPLY

1. Turn the ignition switch OFF.
2. Disconnect power steering control unit harness connector.
3. Check voltage between power steering control unit harness connector and ground.

Power steering control unit		—	Voltage (Approx.)
Connector	Terminal		
M61	3	Ground	0 V

4. Turn the ignition switch ON.

CAUTION:

Never start the engine.

5. Check voltage between power steering control unit harness connector and ground.

Power steering control unit		—	Voltage (Approx.)
Connector	Terminal		
M61	3	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check the following. If any items are damaged, repair or replace damaged parts.

- 10A fuses (#3) open
- Harness for short or open between ignition switch and power steering control unit harness connector No. 3 terminal.
- Ignition switch. Refer to [PCS-68, "Component Inspection"](#).

2.CHECK GROUND CIRCUIT

1. Turn the ignition switch OFF.

2. Check continuity between power steering control unit harness connector and ground.

Power steering control unit		—	Continuity
Connector	Terminal		
M61	6	Ground	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair open circuit or short to power in harness or connectors.

3.CHECK TERMINALS AND HARNESS CONNECTORS

Check power steering control unit pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace damaged parts.

POWER STEERING SOLENOID VALVE

< DTC/CIRCUIT DIAGNOSIS >

POWER STEERING SOLENOID VALVE

Description

INFOID:0000000009722595

Power steering solenoid valve controls the power steering oil pressure in the gear housing assembly.

Diagnosis Procedure

INFOID:0000000009722596

1. CHECK POWER STEERING SOLENOID VALVE SIGNAL

Check voltage between power steering control unit harness connector and ground.

Power steering control unit		—	Condition	Voltage (Approx.)
Connector	Terminal			
M61	1	Ground	Vehicle speed: 0 km/h (0 MPH) (Engine is running)	4.4 – 6.6 V
			Vehicle speed: 100 km/h (62 MPH)	2.4 – 3.6 V

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 2.

2. CHECK HARNESS BETWEEN POWER STEERING SOLENOID VALVE AND POWER STEERING CONTROL UNIT

1. Turn the ignition switch OFF.
2. Disconnect power steering solenoid valve harness connector.
3. Disconnect power steering control unit harness connector.
4. Check the continuity between power steering solenoid valve harness connector and the power steering control unit harness connector.

Power steering solenoid valve		Power steering control unit		Continuity
Connector	Terminal	Connector	Terminal	
E52	1	M61	1	Existed
E52	2	M61	5	Existed

5. Check continuity between power steering control unit harness connector and ground.

Power steering control unit		—	Continuity
Connector	Terminal		
M61	1	Ground	Not existed
M61	5	Ground	Not existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace damaged parts.

3. CHECK POWER STEERING SOLENOID VALVE

Check power steering solenoid valve. Refer to [STC-8, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace gear-sub assembly. Refer to [ST-46, "Exploded View"](#) (With heated steering wheel), [ST-88, "Exploded View"](#) (Without heated steering wheel).

4. CHECK TERMINALS AND HARNESS CONNECTORS

- Check power steering control unit pin terminals for damage or loose connection with harness connector.
- Check power steering solenoid valve pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

POWER STEERING SOLENOID VALVE

< DTC/CIRCUIT DIAGNOSIS >

YES >> INSPECTION END

NO >> Repair or replace damaged parts.

Component Inspection

INFOID:000000009722597

1. CHECK POWER STEERING SOLENOID VALVE

1. Turn the ignition switch OFF.
2. Disconnect power steering solenoid valve harness connector.
3. Check resistance between power steering solenoid valve connector terminals.

Power steering solenoid valve		Resistance (Approx.)
Terminal		
1	2	4 – 6 Ω

4. Check power steering solenoid valve by listening for its operation sound while applying battery voltage to power steering solenoid valve connector E52 terminals 1 (positive) and 2 (negative).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace gear-sub assembly. Refer to [ST-46, "Exploded View"](#) (With heated steering wheel), [ST-88, "Exploded View"](#) (Without heated steering wheel).

ENGINE SPEED SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

ENGINE SPEED SIGNAL CIRCUIT

Description

INFOID:0000000009722598

ECM sends engine speed signal to power steering control unit.

Diagnosis Procedure

INFOID:0000000009722599

1. PERFORM ECM SELF-DIAGNOSIS

(B) With CONSULT

1. Turn the ignition switch ON.

CAUTION:

Never start the engine

2. Perform "ENGINE" self-diagnosis. Refer to [EC-129, "CONSULT Function"](#).

Is any DTC detected?

YES >> Check the DTC.

NO >> GO TO 2.

2. CHECK HARNESS BETWEEN ECM AND POWER STEERING CONTROL UNIT

1. Turn the ignition switch OFF.
2. Disconnect ECM harness connectors.
3. Disconnect power steering control unit harness connector.
4. Check continuity between ECM harness connector and power steering control unit harness connector.

ECM		Power steering control unit		Continuity
Connector	Terminal	Connector	Terminal	
E16	94	M61	10	Existed

5. Check continuity between power steering control unit harness connector and ground.

Power steering control unit		—	Continuity
Connector	Terminal		
M61	10	Ground	Not existed

Is the inspection result normal?

YES >> GO TO 3.



NO >> Repair or replace damaged parts.

3. CHECK ENGINE SPEED SIGNAL (1)

1. Connect ECM harness connectors.
2. Check signal between ECM harness connector and ground with oscilloscope.

ENGINE SPEED SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

ECM		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
E16	94	Ground	Engine is running • Warm-up condition • Idle speed	 2V/div 10mSec/div <small>JMBIA0076GB</small>
			Engine is running • Warm-up condition • Engine speed: Approx. 2,000 rpm	 2V/div 10mSec/div <small>JMBIA0077GB</small>



Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace ECM. Refer to [EC-16, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description"](#).

4. CHECK ENGINE SPEED SIGNAL (2)

1. Turn the ignition switch OFF.
2. Connect power steering control unit harness connector.
3. Check signal between power steering control unit harness connector and ground with oscilloscope.

Power steering control unit		—	Condition	Voltage (Approx.)
Connector	Terminal			
M61	10	Ground	Engine is running • Warm-up condition • Idle speed	 2V/div 10mSec/div <small>JMBIA0076GB</small>
			Engine is running • Warm-up condition • Engine speed: Approx. 2,000 rpm	 2V/div 10mSec/div <small>JMBIA0077GB</small>

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace power steering control unit. Refer to [STC-22, "Removal and Installation"](#).

5. CHECK TERMINALS AND HARNESS CONNECTORS

- Check power steering control unit pin terminals for damage or loose connection with harness connector.
- Check ECM pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace damaged parts.

VEHICLE SPEED SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

VEHICLE SPEED SIGNAL CIRCUIT

Description

INFOID:0000000009722600

Combination meter sends vehicle speed signal to power steering control unit.

Diagnosis Procedure

INFOID:0000000009722601

1. PERFORM COMBINATION METER SELF-DIAGNOSIS

With CONSULT

1. Turn the ignition switch ON.

CAUTION:

Never start the engine

2. Perform "METER/M&A" self-diagnosis. Refer to [MWI-35, "CONSULT Function \(METER/M&A\)".](#)

Is any DTC detected?

YES >> Check the DTC.

NO >> GO TO 2.

2. CHECK HARNESS BETWEEN COMBINATION METER AND POWER STEERING CONTROL UNIT

1. Turn the ignition switch OFF.
2. Disconnect combination meter harness connector.
3. Disconnect power steering control unit harness connector.
4. Check continuity between combination meter harness connector and power steering control unit harness connector.

Combination meter		Power steering control unit		Continuity
Connector	Terminal	Connector	Terminal	
M34	30	M61	8	Existed

5. Check continuity between power steering control unit harness connector and ground.

Power steering control unit		—	Continuity
Connector	Terminal		
M61	8	Ground	Not existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace damaged parts.

3. CHECK VEHICLE SPEED SIGNAL (1)

1. Turn the ignition switch OFF.
2. Connect combination meter harness connector.
3. Check combination meter input/output standard values. Refer to [MWI-59, "Reference Value".](#)

Is the inspection result normal?

YES >> GO TO 4.


NO >> Replace combination meter Refer to [MWI-105, "Exploded View".](#)

4. CHECK VEHICLE SPEED SIGNAL (2)

1. Turn the ignition switch OFF.
2. Connect power steering control unit harness connector.
3. Check signal between power steering control unit harness connector and ground with oscilloscope.

VEHICLE SPEED SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Power steering control unit		—	Condition	Voltage (Approx.)
Connector	Terminal			
M61	8	Ground	<p>Vehicle speed: 40 km/h (25 MPH)</p> <p>CAUTION: Check air pressure of tire under standard condition.</p>	<p>NOTE: The maximum voltage varies depending on the specification (destination unit).</p>  <p>JSNIA0015GB</p>

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace power steering control unit. Refer to [STC-22, "Removal and Installation"](#).

5.CHECK TERMINALS AND HARNESS CONNECTORS

- Check power steering control unit pin terminals for damage or loose connection with harness connector.
- Check combination meter pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace damaged parts.

POWER STEERING CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


ECU DIAGNOSIS INFORMATION

POWER STEERING CONTROL UNIT

Reference Value


INFOID:0000000009722602

TERMINAL LAYOUT



JSGIA0023ZZ



PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	STC
+	-	Signal name	Input/ Output			H
1 (Y)	Ground	Power steering solenoid valve voltage	Output	Vehicle speed: 0 km/h (0 MPH) (Engine is running)	4.4 – 6.6 V	I
				Vehicle speed: 100 km/h (62 MPH)	2.4 – 3.6 V	J
3 (G)	Ground	Ignition switch power supply	Input	Ignition switch: ON	Battery voltage	K
				Ignition switch: OFF	0 V	L
5 (LG)	Ground	Power steering solenoid valve ground	—	Always	0 V	M
6 (B)	Ground	Ground	—	Always	0 V	N
8 (P)	Ground	Vehicle speed signal	Input	Vehicle speed: 40 km/h (25 MPH) CAUTION: Check air pressure of tire under standard condition.	NOTE: The maximum voltage varies depending on the specification (destination unit). 	O

JSNIA0015GB

POWER STEERING CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
10 (V)	Ground	Engine speed signal	Input	Engine is running • Warm-up condition • Idle speed	 10mSec/div 2V/div JMBIA0076GB
				Engine is running • Warm-up condition • Engine speed: Approx. 2,000 rpm	 10mSec/div 2V/div JMBIA0077GB

CAUTION:

When using circuit tester or oscilloscope to measure voltage for inspection, be sure not to forcibly extend any connector terminals.


POWER STEERING CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Wiring Diagram - ELECTRONICALLY CONTROLLED POWER STEERING SYSTEM -

INFOID:000000009722603

ELECTRONICALLY CONTROLLED POWER STEERING SYSTEM



2008/09/23

JCGWM0180GB

POWER STEERING CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

ELECTRONICALLY CONTROLLED POWER STEERING SYSTEM

Connector No.	Connector No.	Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]
E16	E22	1 W	ACCELERATOR PEDAL POSITION SENSOR 1	61 V	BR
ECM		2 O	ACCELERATOR PEDAL POSITION SENSOR 2	62 LG	—
RH2FB-F2B-L-LH		32 BR	SENSE POWER SUPPLY	63 L/O	—
		33 B	SENSE GROUND	64 SHIELD	—
		84 Y	ASCO STEERING SWITCH	65 H	BR
		85 Y	EVAP CONTROL STEERING PRESSURE SENSOR	66 H	—
		26 SB	SENSOR POWER SUPPLY	67 BR	—
		87 GR	DATA LINK CONNECTOR	68 Y	—
		88 O	SENSOR POWER SUPPLY	69 SB	—
		91 L	SENSE GROUND	70 GR	—
		92 BR	IGNITION SWITCH	71 SB	—
		93 BR	ENGINE SPEED OUTPUT SIGNAL	72 Y	—
		94 GR	FUEL TANK TEMPERATURE SENSOR	73 L	W
		95 Y	SENSOR GROUND	74 W	—
		96 GR	CAN COMMUNICATION LINE(CAN-L)	75 BR	—
		97 P	CAN COMMUNICATION LINE(CAN-H)	76 GR	—
		98 L	SENSOR GROUND	77 O	—
		100 G	PHP SIGNAL	78 G	—
		102 R	SENSOR GROUND	78 V	—
		104 SB	POWER SUPPLY FOR ECM	79 Y	—
		105 V	STOP/LAMP SWITCH	80 R	—
		106 SB	ECM GROUND	81 W	—
		107 B	ECM GROUND	82 LG	—
		108 B	EVAP CANISTER VENT CONTROL VALVE	83 O	—
		109 W	ASCO BRAKE SWITCH	12 L	—
		110 G	ASCO BRAKE SWITCH	13 Y	—
		111 B	ECM GROUND	14 O	—
		112 B	ECM GROUND	15 BR	—
				20 Y	—
				21 W	—
				24 L	—
				25 O	—
				28 SB	—
				29 W	—
				30 Y	—
					—

JRGWC0751GB

POWER STEERING CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

A

B

C

D

E

F

STC

G

H

I

J

M

N

O

P

ELECTRONICALLY CONTROLLED POWER STEERING SYSTEM

Connector No.	M34
Connector Name	COMBINATION METER
Connector Type	TH40FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	BATTERY POWER SUPPLY	1	Y	EPS SOL+
2	LG	IGN SIGNAL	2	LG	IGN
3	SB	GROUND	3	G	EPS SOL-
4	P	GROUND	4	B	GROUND
5	LG	ILLUMINATION CONTROL SIGNAL	5	SB	VEHICLE SPEED (2-PULSE)
6	V	TRIP RESET SIGNAL	6	P	ENG TACHO
7	GR	SWILL POWER	7	W	
8	BR	METER CONTROL SWITCH GROUND	8	LG	
9	BR	ENTER CONTROL SWITCH GROUND	9	LG	
10	BR	SELECT SWITCH SIGNAL	10	L	
11	V	ILLUMINATION CONTROL SIGNAL (2-PULSE)	11	R	
12	W	ILLUMINATION CONTROL SIGNAL (2-PULSE)	12	R	
13	BR	ILLUMINATION CONTROL SIGNAL (2-PULSE)	13	V	
14	GR	ILLUMINATION CONTROL SWITCH SIGNAL (-)	14	GR	
15	BR	AIR BAG SIGNAL	15	BR	
16	W	AMBIENT SENSOR SIGNAL	16	L	
17	P	AMBIENT SENSOR POWER	17	P	
18	Q	AMBIENT SENSOR GROUND	18	Y	
19	Q	CAN-H	19	Y	
20	Q	CAN-L	20	Y	
21	BR	FUEL LEVEL SENSOR GROUND	21	Y	
22	BR	ALTERNATOR SIGNAL	22	P	
23	BR	PARKING BRAKE SWITCH SIGNAL	23	B	
24	W	VEHICLE SPEED SIGNAL (2-PULSE)	24	W	
25	BR	VEHICLE SPEED SIGNAL (2-PULSE)	25	BR	
26	G	OVERDRIVE CONTROL SWITCH SIGNAL	26	G	
27	V	SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SIDE)	27	V	
28	R	SEAT BELT BUCKLE SWITCH SIGNAL (PASSENGER SIDE)	28	R	
29	R	WASHER FLUID LEVEL SWITCH SIGNAL	29	R	
30	P	VEHICLE SPEED SIGNAL (2-PULSE)	30	P	
31	V	VEHICLE SPEED SIGNAL (2-PULSE)	31	V	
32	LG	OVERDRIVE CONTROL SWITCH SIGNAL	32	LG	
33	G	VEHICLE SPEED SIGNAL (2-PULSE)	33	G	
34	SB	SEAT BELT BUCKLE SWITCH SIGNAL (PASSENGER SIDE)	34	SB	
35	SB	SEAT BELT BUCKLE SWITCH SIGNAL (PASSENGER SIDE)	35	SB	
36	R	SEAT BELT BUCKLE SWITCH SIGNAL (PASSENGER SIDE)	36	R	

Diagram showing the pinout for the M34 connector, with 16 pins labeled 1 through 16.

POWER STEERING CONTROL UNIT


< ECU DIAGNOSIS INFORMATION >

- EPS system enters the fail-safe mode (that allows the steering force to be controlled without impairing the drivability) if any of the input/output values to/from EPS system (power steering control unit) deviate from the standard range.

NOTE:

The system enters the fail-safe mode if the engine speed remains at 1,500 rpm or more for over 10 seconds while the vehicle is stopped. This is normal.

- The fail-safe function is canceled when a vehicle speed signal of 2 km/h (1.2 MPH) or more is inputted or the ignition switch is turned OFF→ON. EPS system restores the normal operation at that time.



Mode	Warning lamp	DTC	Detection point (malfunction part)	Error area and root cause
Fail-safe function	—	—	Vehicle speed signal input	<ul style="list-style-type: none"> • Engine speed is 1,500 rpm or more and there is no vehicle speed signal input for over 10 seconds during vehicle travel. • Vehicle speed signal has abruptly dropped from 30 km/h (19 MPH) or more to 2 km/h (1.2 MPH) or less within 1.4 seconds.

UNBALANCE STEERING WHEEL TURNING FORCE (TORQUE VARIATION)

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

UNBALANCE STEERING WHEEL TURNING FORCE (TORQUE VARIATION)

Description

INFOID:0000000009722605

- Hard steering when fully turning the steering wheel.
- Light steering when driving at a high speed.

Diagnosis Procedure

INFOID:0000000009722606

1.CHECK SYSTEM FOR POWER SUPPLY AND GROUND

Perform trouble diagnosis for power supply and ground. Refer to [STC-6, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace damaged parts.

2.CHECK SYSTEM FOR VEHICLE SPEED SIGNAL

Perform trouble diagnosis for vehicle speed signal. Refer to [STC-11, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace damaged parts.

3.CHECK SYSTEM FOR ENGINE SPEED SIGNAL

Perform trouble diagnosis for engine speed signal. Refer to [STC-9, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace damaged parts.

4.CHECK SYSTEM FOR POWER STEERING SOLENOID VALVE

Perform trouble diagnosis for power steering solenoid valve. Refer to [STC-7, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> Perform the symptom diagnosis for the steering system. Refer to [ST-29, "NVH Troubleshooting Chart"](#) (With heated steering wheel), [ST-76, "NVH Troubleshooting Chart"](#) (Without heated steering wheel).

NO >> Repair or replace damaged parts.

A

B

C

D

E

F

STC

H

I

J

K

L

M

N

O

P

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS FOR USA AND CANADA

FOR USA AND CANADA : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009722607

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

FOR MEXICO

FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009722608

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

PRECAUTIONS

< PRECAUTION >

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precautions for Removing of Battery Terminal

INFOID:0000000010147413

- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.

NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.


NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.



SEF289H

STC

POWER STEERING CONTROL UNIT

< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION

POWER STEERING CONTROL UNIT

Removal and Installation

INFOID:000000009722609

REMOVAL

1. Remove instrument lower panel RH. Refer to [IP-14, "Exploded View"](#).
2. Disconnect power steering control unit connector.
3. Remove power steering control unit.

INSTALLATION

Install in the reverse order of removal.