

A
B
C

SECTION **WW**

WIPER & WASHER

CONTENTS

| | |
|--|---|
| <p>BASIC INSPECTION 4</p> <p>DIAGNOSIS AND REPAIR WORK FLOW 4</p> <p style="padding-left: 20px;">Work Flow4</p> <p>SYSTEM DESCRIPTION 7</p> <p>FRONT WIPER AND WASHER SYSTEM 7</p> <p>WITH RAIN SENSOR7</p> <p style="padding-left: 20px;">WITH RAIN SENSOR : System Diagram7</p> <p style="padding-left: 20px;">WITH RAIN SENSOR : System Description7</p> <p style="padding-left: 20px;">WITH RAIN SENSOR : Component Parts Location 10</p> <p style="padding-left: 20px;">WITH RAIN SENSOR : Component Description.... 10</p> <p>WITHOUT RAIN SENSOR 11</p> <p style="padding-left: 20px;">WITHOUT RAIN SENSOR : System Diagram 11</p> <p style="padding-left: 20px;">WITHOUT RAIN SENSOR : System Description.... 11</p> <p style="padding-left: 20px;">WITHOUT RAIN SENSOR : Component Parts Location 14</p> <p style="padding-left: 20px;">WITHOUT RAIN SENSOR : Component Description 14</p> <p>REAR WIPER AND WASHER SYSTEM16</p> <p style="padding-left: 20px;">System Diagram 16</p> <p style="padding-left: 20px;">System Description 16</p> <p style="padding-left: 20px;">Component Parts Location 18</p> <p style="padding-left: 20px;">Component Description 18</p> <p>DIAGNOSIS SYSTEM (BCM)19</p> <p>COMMON ITEM19</p> <p style="padding-left: 20px;">COMMON ITEM : CONSULT Function (BCM - COMMON ITEM) 19</p> <p>WIPER20</p> <p style="padding-left: 20px;">WIPER : CONSULT Function (BCM - WIPER) 20</p> <p>DIAGNOSIS SYSTEM (IPDM E/R)22</p> <p style="padding-left: 20px;">Diagnosis Description22</p> <p style="padding-left: 20px;">CONSULT Function (IPDM E/R)24</p> | <p style="text-align: right;">D E F G H I J K</p> <p>DTC/CIRCUIT DIAGNOSIS27</p> <p>WIPER AND WASHER FUSE, FUSIBLE LINK27</p> <p style="padding-left: 20px;">Description27</p> <p style="padding-left: 20px;">Diagnosis Procedure27</p> <p>POWER SUPPLY AND GROUND CIRCUIT28</p> <p>BCM (BODY CONTROL MODULE)28</p> <p style="padding-left: 20px;">BCM (BODY CONTROL MODULE) : Diagnosis Procedure28</p> <p>IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)28</p> <p style="padding-left: 20px;">IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) : Diagnosis Procedure28</p> <p>FRONT WIPER MOTOR LO CIRCUIT30</p> <p style="padding-left: 20px;">Component Function Check30</p> <p style="padding-left: 20px;">Diagnosis Procedure30</p> <p>FRONT WIPER MOTOR HI CIRCUIT32</p> <p style="padding-left: 20px;">Component Function Check32</p> <p style="padding-left: 20px;">Diagnosis Procedure32</p> <p>FRONT WIPER STOP POSITION SIGNAL CIRCUIT34</p> <p style="padding-left: 20px;">Component Function Check34</p> <p style="padding-left: 20px;">Diagnosis Procedure34</p> <p>FRONT WIPER MOTOR GROUND CIRCUIT ...36</p> <p style="padding-left: 20px;">Diagnosis Procedure36</p> <p>WASHER SWITCH37</p> <p style="padding-left: 20px;">Description37</p> <p style="padding-left: 20px;">Component Inspection37</p> <p>RAIN SENSOR38</p> <p style="padding-left: 20px;">Description38</p> <p style="padding-left: 20px;">Component Function Check38</p> <p style="padding-left: 20px;">Diagnosis Procedure38</p> |
|--|---|

WW

M
N
O
P

| | | | |
|--|------------|---|------------|
| REAR WIPER MOTOR CIRCUIT | 40 | FOR CALIFORNIA AND CANADA : Precautions for Removing of Battery Terminal | 126 |
| Component Function Check | 40 | | |
| Diagnosis Procedure | 40 | | |
| REAR WIPER STOP POSITION SIGNAL CIR- CUIT | 42 | FOR MEXICO | 126 |
| Component Function Check | 42 | FOR MEXICO : Precaution for Supplemental Re- straint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" | 126 |
| Diagnosis Procedure | 42 | FOR MEXICO : Precaution for Procedure without Cowl Top Cover | 127 |
| FRONT WIPER AND WASHER SYSTEM | 44 | FOR MEXICO : Precautions for Removing of Bat- tery Terminal | 127 |
| Wiring Diagram - FRONT WIPER AND WASHER SYSTEM - | 44 | | |
| REAR WIPER AND WASHER SYSTEM | 52 | REMOVAL AND INSTALLATION | 128 |
| Wiring Diagram - REAR WIPER AND WASHER SYSTEM - | 52 | WASHER TANK | 128 |
| ECU DIAGNOSIS INFORMATION | 60 | Exploded View | 128 |
| BCM (BODY CONTROL MODULE) | 60 | Removal and Installation | 128 |
| Reference Value | 60 | WASHER PUMP | 129 |
| Wiring Diagram - BCM - | 83 | Exploded View | 129 |
| Fail-safe | 98 | Removal and Installation | 129 |
| DTC Inspection Priority Chart | 99 | WASHER LEVEL SWITCH | 130 |
| DTC Index | 100 | Removal and Installation | 130 |
| IPDM E/R (INTELLIGENT POWER DISTRI- BUTION MODULE ENGINE ROOM) | 103 | FRONT WASHER NOZZLE AND TUBE | 131 |
| Reference Value | 103 | Exploded View | 131 |
| Wiring Diagram - IPDM E/R - | 111 | Hydraulic Layout | 131 |
| Fail-safe | 114 | Removal and Installation | 131 |
| DTC Index | 116 | Inspection and Adjustment | 132 |
| SYMPTOM DIAGNOSIS | 117 | FRONT WIPER ARM | 134 |
| WIPER AND WASHER SYSTEM SYMPTOMS . | 117 | Exploded View | 134 |
| WITH RAIN SENSOR | 117 | Removal and Installation | 134 |
| WITH RAIN SENSOR : Symptom Table | 117 | Adjustment | 134 |
| WITHOUT RAIN SENSOR | 119 | WIPER BLADE | 136 |
| WITHOUT RAIN SENSOR : Symptom Table | 119 | Exploded View | 136 |
| NORMAL OPERATING CONDITION | 122 | Removal and Installation | 136 |
| Description | 122 | Replacement | 136 |
| FRONT WIPER DOES NOT OPERATE | 123 | FRONT WIPER DRIVE ASSEMBLY | 138 |
| Description | 123 | Exploded View | 138 |
| Diagnosis Procedure | 123 | Removal and Installation | 138 |
| PRECAUTION | 125 | Disassembly and Assembly | 139 |
| PRECAUTIONS | 125 | RAIN SENSOR | 140 |
| FOR CALIFORNIA AND CANADA | 125 | Exploded View | 140 |
| FOR CALIFORNIA AND CANADA : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" | 125 | Removal and Installation | 140 |
| FOR CALIFORNIA AND CANADA : Precaution for Procedure without Cowl Top Cover | 125 | WIPER AND WASHER SWITCH | 141 |
| | | Exploded View | 141 |
| | | REAR WIPER ARM | 142 |
| | | Exploded View | 142 |
| | | Removal and Installation | 142 |
| | | Adjustment | 142 |
| | | REAR WIPER MOTOR | 144 |
| | | Exploded View | 144 |
| | | Removal and Installation | 144 |

| | | | |
|--|------------|---------------------------------|-----|
| REAR WASHER NOZZLE AND TUBE | 145 | Removal and Installation | 146 |
| Hydraulic Layout | 145 | Inspection and Adjustment | 147 |

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000009719709

OVERALL SEQUENCE



JMKIA8652GB

DETAILED FLOW

Revision: 2013 August

WW-4

2014 MURANO

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

1.GET INFORMATION FOR SYMPTOM

1. Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurs).
2. Check operation condition of the function that is malfunctioning.

>> GO TO 2.

2.CHECK DTC

1. Check DTC.
2. Perform the following procedure if DTC is detected.
 - Record DTC and freeze frame data (Print them out using CONSULT.)
 - Erase DTC.
 - Study the relationship between the cause detected by DTC and the symptom described by the customer.
3. Check related service bulletins for information.

Are any symptoms described and any DTC detected?

- Symptom is described, DTC is detected>>GO TO 3.
- Symptom is described, DTC is not detected>>GO TO 4.
- Symptom is not described, DTC is detected>>GO TO 5.

3.CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.
Also study the normal operation and fail-safe related to the symptom.
Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5.

4.CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.
Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6.

5.PERFORM DTC CONFIRMATION PROCEDURE

Perform DTC CONFIRMATION PROCEDURE for the detected DTC, and then check that DTC is detected again. At this time, always connect CONSULT to the vehicle, and check self diagnostic results in real time. If two or more DTCs are detected, refer to [BCS-90. "DTC Inspection Priority Chart"](#) (BCM) or [PCS-34. "DTC Index"](#) (IPDM E/R), and determine trouble diagnosis order.

NOTE:

- Freeze frame data is useful if the DTC is not detected.
- Perform Component Function Check if DTC CONFIRMATION PROCEDURE is not included on Service Manual. This simplified check procedure is an effective alternative though DTC cannot be detected during this check.
If the result of Component Function Check is NG, it is the same as the detection of DTC by DTC CONFIRMATION PROCEDURE.

Is DTC detected?

- YES >> GO TO 7.
- NO >> Check according to [GI-44. "Intermittent Incident"](#).

6.DETECT MALFUNCTIONING SYSTEM BY SYMPTOM DIAGNOSIS

Detect malfunctioning system according to SYMPTOM DIAGNOSIS based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

Is the symptom described?

- YES >> GO TO 7.
- NO >> Monitor input data from related sensors or check voltage of related module terminals using CONSULT.

7.DETECT MALFUNCTIONING PART BY DIAGNOSIS PROCEDURE

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

Inspect according to Diagnosis Procedure of the system.

Is malfunctioning part detected?

YES >> GO TO 8.

NO >> Check according to [GI-44. "Intermittent Incident"](#).

8. REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnosis Procedure again after repair and replacement.
3. Check DTC. If DTC is detected, erase it.

>> GO TO 9.

9. FINAL CHECK

When DTC is detected in step 2, perform DTC CONFIRMATION PROCEDURE again, and then check that the malfunction is repaired securely.

When symptom is described by the customer, refer to confirmed symptom in step 3 or 4, and check that the symptom is not detected.

Is DTC detected and does symptom remain?

YES-1 >> DTC is detected: GO TO 7.

YES-2 >> Symptom remains: GO TO 4.

NO >> Before returning the vehicle to the customer, always erase DTC.

FRONT WIPER AND WASHER SYSTEM


< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

FRONT WIPER AND WASHER SYSTEM WITH RAIN SENSOR

WITH RAIN SENSOR : System Diagram

INFOID:000000009719710



WITH RAIN SENSOR : System Description

INFOID:000000009719711

OUTLINE

The front wiper is controlled by each function of BCM and IPDM E/R.

Control by BCM

- Combination switch reading function
- Front wiper control function

Control by IPDM E/R

- Front wiper control function
- Relay control function

Combination meter indicates low washer fluid warning judged with the signal from the washer level switch. For details of low washer fluid warning, refer to [MWI-26. "INFORMATION DISPLAY : System Description"](#).

FRONT WIPER BASIC OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits the front wiper request signal to IPDM E/R with CAN communication depending on each operating condition of the front wiper.
- IPDM E/R turns ON/OFF the integrated front wiper relay and the front wiper high relay according to the front wiper request signal. IPDM E/R provides the power supply to operate the front wiper HI/LO operation.

FRONT WIPER LO OPERATION

- BCM transmits the front wiper request signal (LO) to IPDM E/R with CAN communication according to the front wiper LO operating condition.

Front wiper LO operating condition

- Ignition switch ON
- Front wiper switch LO or front wiper switch MIST (while pressing)
- IPDM E/R turns ON the integrated front wiper relay according to the front wiper request signal (LO).

FRONT WIPER HI OPERATION

- BCM transmits the front wiper request signal (HI) to IPDM E/R with CAN communication according to the front wiper HI operating condition.

Front wiper HI operating condition

- Ignition switch ON
- Front wiper switch HI

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

WW

FRONT WIPER AND WASHER SYSTEM

< SYSTEM DESCRIPTION >

- IPDM E/R turns ON the integrated front wiper relay and the front wiper high relay according to the front wiper request signal (HI).

FRONT WIPER AUTO OPERATION

Rain Sensing

Rain level and sensor conditions are detected by rain sensor.

- BCM transmits the vehicle conditions (vehicle speed, front wiper condition, rain sensor sensitivity setting, etc.) to the rain sensor via the rain sensor serial link.
- Rain sensor judges a wiping speed for front wiper by rain condition and the vehicle conditions. And it transmits the wiping speed request signal to the BCM via the rain sensor serial link.

Auto Wiping Operation

- BCM receives the wiping speed request signal from the rain sensor via the rain sensor serial link.
- BCM controls front wiper operation according to the wiping speed request signals. And it transmits the front wiper request signals (LO or HI) to the IPDM E/R via CAN communication line.

Front wiper AUTO operating condition

- Ignition switch ON
- Front wiper switch INT/AUTO

NOTE:

When the front wiper switch is turned to INT/AUTO position, front wiper operates once regardless of a rainy condition.

Rain Sensor Sensitivity Setting

BCM determines rain sensor sensitivity according to a wiper volume.


| Wiper volume dial position | Sensitivity |
|----------------------------|-------------------------|
| 1 | High sensitivity |
| 2 | |
| 3 | Medium-high sensitivity |
| 4 | |
| 5 | Low-medium sensitivity |
| 6 | |
| 7 | Low sensitivity |

NOTE:

When the wiper volume is turned up at 1 level with front wiper AUTO operating condition, front wiper operates once.

FRONT WIPER AUTO STOP OPERATION

- BCM stops transmitting the front wiper request signal when the front wiper switch is turned OFF.
- IPDM E/R detects the front wiper stop position signal from the front wiper motor and detects the front wiper motor position (stop position/except stop position).
- When the front wiper request signal is stopped, IPDM E/R turns ON the front wiper relay until the front wiper motor returns to the stop position.



FRONT WIPER AND WASHER SYSTEM

< SYSTEM DESCRIPTION >

NOTE:

- BCM stops the transmitting of the front wiper request signal when the ignition switch is OFF. A
- IPDM E/R turns the front wiper relay OFF when the ignition switch is OFF.

FRONT WIPER OPERATION LINKED WITH WASHER

- BCM transmits the front wiper request signal (LO) to IPDM E/R with CAN communication according to the washer linked operating condition of the front wiper. B
- BCM transmits the front wiper request signal (LO) so that the front wiper operates approximately 2 times when the front washer switch OFF is detected. C

Washer linked operating condition of front wiper

- Ignition switch ON
- Front washer switch ON (0.4 second or more) D
- IPDM E/R turns ON the integrated front wiper relay according to the front wiper request signal (LO).
- The washer pump is grounded through the combination switch with the front washer switch ON.

FAIL-SAFE FUNCTION

Front Wiper control

IPDM E/R performs the fail-safe function when the front wiper stop position circuit is malfunctioning. Refer to [PCS-32, "Fail-safe"](#). F

Rain Sensor Malfunction

- BCM judges the rain sensor serial link error by the rain sensor serial link condition and detects the rain sensor malfunction by rain sensor malfunction signal. G
- When BCM detects the rain sensor serial link error or the rain sensor malfunction while front wiper AUTO operation, BCM operates a fail-safe control.

NOTE:

If rain sensor malfunction is detected when ignition switch is turned OFF ⇒ ON and front wiper switch is INT/AUTO position, BCM operates front wiper LO. H

WW

M

N

O


P

FRONT WIPER AND WASHER SYSTEM

< SYSTEM DESCRIPTION >

WITH RAIN SENSOR : Component Parts Location

INFOID:000000009719712



- | | | |
|----------------------------|-------------------------------|---------------------------------------|
| 1. Combination switch | 2. Combination meter | 3. Rain sensor |
| 4. Washer pump | 5. Front wiper motor | 6. IPDM E/R |
| 7. BCM | | |
| A. Wind shield upper | B. Radiator core support (RH) | C. Cowl top, left side of engine room |
| D. Engine room (left side) | E. Behind combination meter | |

WITH RAIN SENSOR : Component Description

INFOID:000000009719713

| Part | Description |
|----------|---|
| BCM | <ul style="list-style-type: none"> Judges each switch status by the combination switch reading function. Requests (with CAN communication) the front wiper relay and the front wiper high relay ON to IPDM E/R. |
| IPDM E/R | <ul style="list-style-type: none"> Controls the integrated relay according to the request (with CAN communication) from BCM. Performs the auto stop control of the front wiper. |


FRONT WIPER AND WASHER SYSTEM

< SYSTEM DESCRIPTION >

| Part | Description |
|--|---|
| Combination switch (Wiper & washer switch) | Refer to BCS-10, "System Diagram" . |
| Combination meter | Transmits the vehicle speed signal to BCM with CAN communication. |
| Rain sensor | Detects water droplets on the windshield with infrared rays, and transmits the rain sensor signal to BCM through the rain sensor serial link. |

WITHOUT RAIN SENSOR

WITHOUT RAIN SENSOR : System Diagram



WITHOUT RAIN SENSOR : System Description

INFOID:000000009719715

OUTLINE

The front wiper is controlled by each function of BCM and IPDM E/R.

Control by BCM

- Combination switch reading function
- Front wiper control function

Control by IPDM E/R

- Front wiper control function
- Relay control function

Combination meter indicates low washer fluid warning judged with the signal from the washer level switch. For details of low washer fluid warning, refer to [MWI-26, "INFORMATION DISPLAY : System Description"](#).

FRONT WIPER BASIC OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits the front wiper request signal to IPDM E/R with CAN communication depending on each operating condition of the front wiper.
- IPDM E/R turns ON/OFF the integrated front wiper relay and the front wiper high relay according to the front wiper request signal. IPDM E/R provides the power supply to operate the front wiper HI/LO operation.

FRONT WIPER LO OPERATION

- BCM transmits the front wiper request signal (LO) to IPDM E/R with CAN communication according to the front wiper LO operating condition.

Front wiper LO operating condition

- Ignition switch ON
- Front wiper switch LO or front wiper switch MIST (while pressing)
- IPDM E/R turns ON the integrated front wiper relay according to the front wiper request signal (LO).

FRONT WIPER HI OPERATION

- BCM transmits the front wiper request signal (HI) to IPDM E/R with CAN communication according to the front wiper HI operating condition.

FRONT WIPER AND WASHER SYSTEM

< SYSTEM DESCRIPTION >

Front wiper HI operating condition


- Ignition switch ON
- Front wiper switch HI
- IPDM E/R turns ON the integrated front wiper relay and the front wiper high relay according to the front wiper request signal (HI).

FRONT WIPER INT OPERATION

- BCM transmits the front wiper request signal (INT) to IPDM E/R with CAN communication depending on the front wiper INT operating condition and intermittent operation delay interval according to the wiper intermittent dial position.

Front wiper INT operating condition

- Ignition switch ON
- Front wiper switch INT
- IPDM E/R turns ON the integrated front wiper relay so that the front wiper is operated only once according to the front wiper request signal (INT).
- BCM detects stop position/except stop position of the front wiper motor according to the front wiper stop position signal received from IPDM E/R with CAN communication.
- BCM transmits the front wiper request signal (INT) again after the intermittent operation delay interval.



NOTE:

Factory setting of the front wiper intermittent operation is the operation without vehicle speed. Front wiper intermittent operation can be set to the operation with vehicle speed by CONSULT. Refer to [WW-20. "WIPER : CONSULT Function \(BCM - WIPER\)"](#).

Front wiper intermittent operation with vehicle speed

- BCM calculates the intermittent operation delay interval from the following
 - Vehicle speed signal (received from the combination meter with CAN communication)
 - Wiper intermittent dial position

| Wiper intermittent dial position | Intermittent operation interval | Intermittent operation delay Interval (s) | | | |
|----------------------------------|---------------------------------|---|---------------------------------|------------------------------------|-------------------------------|
| | | Vehicle speed | | | |
| | | 0 – 5 km/h (0 – 3.1 MPH) | 5 – 35 km/h (3.1 – 21.7 MPH) | 35 – 65 km/h* (21.7 – 40.4 MPH) | 65 km/h (40.4 MPH) or more |
| 1 | Short ↑ | 0.8 | 0.6 | 0.4 | 0.24 |
| 2 | | 4 | 3 | 2 | 1.2 |
| 3 | | 10 | 7.5 | 5 | 3 |
| 4 | | 16 | 12 | 8 | 4.8 |
| 5 | Long ↓ | 24 | 18 | 12 | 7.2 |
| 6 | | 32 | 24 | 16 | 9.6 |
| 7 | | 42 | 31.5 | 21 | 12.6 |

*: When without vehicle speed setting


FRONT WIPER AUTO STOP OPERATION

- BCM stops transmitting the front wiper request signal when the front wiper switch is turned OFF.
- IPDM E/R detects the front wiper stop position signal from the front wiper motor and detects the front wiper motor position (stop position/except stop position).

FRONT WIPER AND WASHER SYSTEM

< SYSTEM DESCRIPTION >

- When the front wiper request signal is stopped, IPDM E/R turns ON the front wiper relay until the front wiper motor returns to the stop position.



NOTE:

- BCM stops the transmitting of the front wiper request signal when the ignition switch is OFF.
- IPDM E/R turns the front wiper relay OFF when the ignition switch is OFF.

FRONT WIPER OPERATION LINKED WITH WASHER

- BCM transmits the front wiper request signal (LO) to IPDM E/R with CAN communication according to the washer linked operating condition of the front wiper.
- BCM transmits the front wiper request signal (LO) so that the front wiper operates approximately 2 times when the front washer switch OFF is detected.

Washer linked operating condition of front wiper

- Ignition switch ON
- Front washer switch ON (0.4 second or more)
- IPDM E/R turns ON the integrated front wiper relay according to the front wiper request signal (LO).
- The washer pump is grounded through the combination switch with the front washer switch ON.

FRONT WIPER FAIL-SAFE OPERATION

IPDM E/R performs the fail-safe function when the front wiper stop position circuit is malfunctioning. Refer to [PCS-32. "Fail-safe"](#).

A
B
C
D
E
F
G
H
I
J
K

WW


M
N
O
P

FRONT WIPER AND WASHER SYSTEM

< SYSTEM DESCRIPTION >

WITHOUT RAIN SENSOR : Component Parts Location

INFOID:00000009719716



- | | | |
|-------------------------------|---------------------------------------|----------------------------|
| 1. Combination switch | 2. Combination meter | 3. Washer pump |
| 4. Front wiper motor | 5. IPDM E/R | 6. BCM |
| A. Radiator core support (RH) | B. Cowl top, left side of engine room | C. Engine room (left side) |
| D. Behind combination meter | | |

WITHOUT RAIN SENSOR : Component Description

INFOID:00000009719717

| Part | Description |
|----------|---|
| BCM | <ul style="list-style-type: none"> Judges each switch status by the combination switch reading function. Requests (with CAN communication) the front wiper relay and the front wiper high relay ON to IPDM E/R. |
| IPDM E/R | <ul style="list-style-type: none"> Controls the integrated relay according to the request (with CAN communication) from BCM. Performs the auto stop control of the front wiper. |

FRONT WIPER AND WASHER SYSTEM

< SYSTEM DESCRIPTION >

| Part | Description |
|---|---|
| Combination switch (Wiper & washer switch) | Refer to BCS-10, "System Diagram" . |
| Combination meter | Transmits the vehicle speed signal to BCM with CAN communication. |

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O


P

REAR WIPER AND WASHER SYSTEM

< SYSTEM DESCRIPTION >

REAR WIPER AND WASHER SYSTEM

System Diagram



System Description

INFOID:000000009719719

OUTLINE

The rear wiper is controlled by each function of BCM.

Control by BCM

- Combination switch reading function
- Rear wiper control function

REAR WIPER BASIC OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM controls the rear wiper to start or stop.

REAR WIPER ON OPERATION

- BCM supplies power to the rear wiper motor according to the rear wiper ON operating condition.

Rear wiper ON operating condition


- Ignition switch ON
- Rear wiper switch ON

REAR WIPER INT OPERATION

- BCM supplies power to the rear wiper motor according to the INT operating condition.

Rear wiper INT operating condition

- Ignition switch ON
- Rear wiper switch INT
- BCM controls the rear wiper to operate once.
- BCM detects the rear wiper motor stopping position.
- BCM supplies power to the rear wiper motor after an intermittent from the stop of the rear wiper motor.




REAR WIPER AUTO STOP OPERATION

- BCM stops supplying power to the rear wiper motor when the rear wiper switch is turned OFF.

REAR WIPER AND WASHER SYSTEM

< SYSTEM DESCRIPTION >

- BCM reads a rear wiper stop position signal from the rear wiper motor to detect a rear wiper motor position.
- When the rear wiper motor is at other than the stopping position, BCM continues to supply power to the rear wiper motor until it returns to the stopping position.



NOTE:

BCM stops supplying power to the rear wiper motor when the ignition switch is turned OFF.

REAR WIPER OPERATION LINKED WITH WASHER

- BCM supplies power to the rear wiper motor according to the washer linked operating condition of rear wiper. When the rear washer switch is turned OFF, BCM controls rear wiper to operate approximately 3 times.

Washer linked operating condition of rear wiper

- Ignition switch ON
- Rear washer switch ON (0.4 second or more)
- The washer pump is grounded through the combination switch with the rear washer switch ON.

WASHER PATH SWITCHING OPERATION

Rear washer and rear camera washer share the same washer pump.

Washer switching solenoid valve switches the washer path to rear washer side or to rear camera washer side. When rear washer is in the active condition, washer switching solenoid valve is activated and the washer path is switched to rear washer side.

For details refer to [DAS-11, "Washer Switching Solenoid Valve"](#).

REAR WIPER FAIL-SAFE OPERATION

BCM performs the fail-safe function when the rear wiper stop position circuit is malfunctioning. Refer to [BCS-89, "Fail-safe"](#).


A
B
C
D
E
F
G
H
I
J
K
WW
M
N
O
P

REAR WIPER AND WASHER SYSTEM

< SYSTEM DESCRIPTION >

Component Parts Location

INFOID:000000009719720



- | | | |
|-------------------------------|------------------------------------|---|
| 1. Combination switch | 2. Washer switching solenoid valve | 3. Washer pump |
| 4. BCM | 5. Rear wiper motor | |
| A. Radiator core support (RH) | B. Behind combination meter | C. Back door trim finisher lower inside |

Component Description

INFOID:000000009719721

| Part | Description |
|---|---|
| BCM | <ul style="list-style-type: none"> Judges each switch status by the combination switch reading function. Supplies power to the rear wiper motor. Performs the auto stop control of the rear wiper. |
| Combination switch (Wiper & washer switch) | Refer to BCS-10, "System Diagram" . |
| Washer switching solenoid valve | Refer to DAS-11, "Washer Switching Solenoid Valve" . |

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000010129275

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

| Diagnosis mode | Function Description |
|--------------------------|---|
| Work Support | Changes the setting for each system function. |
| Self Diagnostic Result | Displays the diagnosis results judged by BCM. |
| CAN Diag Support Monitor | Monitors the reception status of CAN communication viewed from BCM. |
| Data Monitor | The BCM input/output signals are displayed. |
| Active Test | The signals used to activate each device are forcibly supplied from BCM. |
| Ecu Identification | The BCM part number is displayed. |
| Configuration | <ul style="list-style-type: none"> Read and save the vehicle specification. Write the vehicle specification when replacing BCM. |

SYSTEM APPLICATION

BCM can perform the following functions for each system.

NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

×: Applicable item

| System | Sub system selection item | Diagnosis mode | | |
|---|-----------------------------|----------------|--------------|-------------|
| | | Work Support | Data Monitor | Active Test |
| Door lock | DOOR LOCK | × | × | × |
| Rear window defogger | REAR DEFOGGER | | × | × |
| Warning chime | BUZZER | | × | × |
| Interior room lamp timer | INT LAMP | × | × | × |
| Exterior lamp | HEAD LAMP | × | × | × |
| Wiper and washer | WIPER | ×*1 | × | × |
| Turn signal and hazard warning lamps | FLASHER | × | × | × |
| — | AIR CONDITONER*2 | | | |
| <ul style="list-style-type: none"> Intelligent Key system Engine start system | INTELLIGENT KEY | × | × | × |
| Combination switch | COMB SW | | × | |
| Body control system | BCM | × | | |
| NVIS - NATS | IMMU | | × | × |
| Interior room lamp battery saver | BATTERY SAVER | × | × | × |
| Back door opener system | TRUNK | | × | × |
| Vehicle security system | THEFT ALM | × | × | × |
| RAP system | RETAINED PWR | | × | |
| Signal buffer system | SIGNAL BUFFER | | × | × |
| TPMS | TPMS (AIR PRESSURE MONITOR) | × | × | × |

NOTE:

- *1: For models with rain sensor this mode is displayed, but is not used.
- *2: This item is displayed, but is not used.

FREEZE FRAME DATA (FFD)

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays on CONSULT.

| CONSULT screen item | Indication/Unit | Description | |
|---------------------|-----------------|--|--|
| Vehicle Speed | km/h | Vehicle speed of the moment a particular DTC is detected | |
| Odo/Trip Meter | km | Total mileage (Odometer value) of the moment a particular DTC is detected | |
| Vehicle Condition | SLEEP>LOCK | Power position status of the moment a particular DTC is detected | While turning BCM status from low power consumption mode to normal mode (Power supply position is "LOCK"*) |
| | SLEEP>OFF | | While turning BCM status from low power consumption mode to normal mode (Power supply position is "OFF".) |
| | LOCK>ACC | | While turning power supply position from "LOCK" to "ACC" |
| | ACC>ON | | While turning power supply position from "ACC" to "IGN" |
| | RUN>ACC | | While turning power supply position from "RUN" to "ACC" (Vehicle is stopping and selector lever is except P position.) |
| | CRANK>RUN | | While turning power supply position from "CRANKING" to "RUN" (From cranking up the engine to run it) |
| | RUN>URGENT | | While turning power supply position from "RUN" to "ACC" (Emergency stop operation) |
| | ACC>OFF | | While turning power supply position from "ACC" to "OFF" |
| | OFF>LOCK | | While turning power supply position from "OFF" to "LOCK"* |
| | OFF>ACC | | While turning power supply position from "OFF" to "ACC" |
| | ON>CRANK | | While turning power supply position from "IGN" to "CRANKING" |
| | OFF>SLEEP | | While turning BCM status from normal mode (Power supply position is "OFF".) to low power consumption mode |
| | LOCK>SLEEP | | While turning BCM status from normal mode (Power supply position is "LOCK"*) to low power consumption mode |
| | LOCK | | Power supply position is "LOCK"* |
| | OFF | | Power supply position is "OFF" (Ignition switch OFF) |
| | ACC | | Power supply position is "ACC" (Ignition switch ACC) |
| | ON | | Power supply position is "IGN" (Ignition switch ON with engine stopped) |
| | ENGINE RUN | | Power supply position is "RUN" (Ignition switch ON with engine running) |
| | CRANKING | | Power supply position is "CRANKING" (At engine cranking) |
| IGN Counter | 0 - 39 | The number of times that ignition switch is turned ON after DTC is detected <ul style="list-style-type: none"> • The number is 0 when a malfunction is detected now. • The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. • The number is fixed to 39 until the self-diagnosis results are erased if it is over 39. | |

NOTE:

*: Power supply position shifts to "LOCK" from "OFF", when ignition switch is in the OFF position, selector lever is in the P position, and any of the following conditions are met.

- Closing door
- Opening door
- Door is locked using door request switch
- Door is locked using Intelligent Key

The power supply position shifts to "ACC" when the push-button ignition switch (push switch) is pushed at "LOCK".

WIPER

WIPER : CONSULT Function (BCM - WIPER)

INFOID:000000009719723

WORK SUPPORT

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

| Service item | Setting item | Description |
|---------------------|--------------|--|
| WIPER SPEED SETTING | On | With vehicle speed (Front wiper intermittent time linked with the vehicle speed and wiper intermittent dial position) |
| | Off* | Without vehicle speed (Front wiper intermittent time linked with the wiper intermittent dial position) |

*:Factory setting

NOTE:

Work support item is not indicated when the vehicle with rain sensor.

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

| Monitor Item [Unit] | Description |
|---------------------------|---|
| PUSH SW [Off/On] | The switch status input from push-button ignition switch. |
| VEHICLE SPEED 1 [km/h] | The value of the vehicle speed signal received from combination meter with CAN communication. |
| FR WIPER HI [Off/On] | Each switch status that BCM judges from the combination switch reading function. |
| FR WIPER LOW [Off/On] | |
| FR WASHER SW [Off/On] | |
| FR WIPER INT [Off/On] | |
| FR WIPER STOP [Off/On] | Front wiper motor (stop position) status received from IPDM E/R with CAN communication. |
| INT VOLUME [1 – 7] | Each switch status that BCM judges from the combination switch reading function. |
| RR WIPER ON [Off/On] | Each switch status that BCM judges from the combination switch reading function. |
| RR WIPER INT [Off/On] | |
| RR WASHER SW [Off/On] | |
| RR WIPER STOP [Off/On] | Rear wiper motor (stop position) status input from the rear wiper motor. |

ACTIVE TEST

| Test item | Operation | Description |
|-----------|-----------|---|
| FR WIPER | Hi | Transmits the front wiper request signal (HI) to IPDM E/R with CAN communication to operate the front wiper HI operation. |
| | Lo | Transmits the front wiper request signal (LO) to IPDM E/R with CAN communication to operate the front wiper LO operation. |
| | INT | Transmits the front wiper request signal (INT) to IPDM E/R with CAN communication to operate the front wiper INT operation. |
| | Off | Stops transmitting the front wiper request signal to stop the front wiper operation. |
| RR WIPER | On | Outputs the voltage to operate the rear wiper motor. |
| | Off | Stops the voltage to stop. |

DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (IPDM E/R)

Diagnosis Description

INFOID:000000010129276

AUTO ACTIVE TEST

Description

In auto active test mode, the IPDM E/R sends a drive signal to the following systems to check their operation.

- Oil pressure warning lamp
- Front wiper (LO, HI)
- Parking lamps
- License plate lamps
- Side maker lamps
- Tail lamps
- Front fog lamps
- Headlamps (LO, HI)
- A/C compressor (magnet clutch)
- Cooling fan

Operation Procedure

1. Close the hood and lift the wiper arms from the windshield. (Prevent windshield damage due to wiper operation)

NOTE:

When auto active test is performed with hood opened, sprinkle water on windshield beforehand.

2. Turn the ignition switch OFF.
3. Turn the ignition switch ON, and within 20 seconds, press the front door switch (driver side) 10 times. Then turn the ignition switch OFF.

CAUTION:

Close passenger door.

4. Turn the ignition switch ON within 10 seconds. After that the horn sounds once and the auto active test starts.
5. The oil pressure warning lamp starts blinking when the auto active test starts.
6. After a series of the following operations is repeated 3 times, auto active test is completed.

NOTE:

When auto active test mode has to be cancelled halfway through test, turn the ignition switch OFF.

CAUTION:

- **If auto active test mode cannot be actuated, check door switch system. Refer to [DLK-97, "WITH AUTOMATIC BACK DOOR : Component Function Check"](#).**
- **Do not start the engine.**

Inspection in Auto Active Test Mode


When auto active test mode is actuated, the following 6 steps are repeated 3 times.

| Operation sequence | Inspection location | Operation |
|--------------------|---|--|
| 1 | Oil pressure warning lamp | Blinks continuously during operation of auto active test |
| 2 | Front wiper | LO for 5 seconds → HI for 5 seconds |
| 3 | <ul style="list-style-type: none">• Parking lamps• License plate lamps• Side maker lamps• Tail lamps• Front fog lamps | 10 seconds |
| 4 | Headlamps | LO ↔ HI 5 times |
| 5 | A/C compressor (magnet clutch) | ON ↔ OFF 5 times |
| 6 | Cooling fan | LO for 5 seconds → MID for 3 seconds → HI for 2 seconds |

DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

Concept of auto active test



- IPDM E/R starts the auto active test with the door switch signals transmitted by BCM via CAN communication. Therefore, the CAN communication line between IPDM E/R and BCM is considered normal if the auto active test starts successfully.
- The auto active test facilitates troubleshooting if any systems controlled by IPDM E/R cannot be operated.

Diagnosis chart in auto active test mode

| Symptom | Inspection contents | Possible cause |
|---|--|---|
| Any of the following components do not operate <ul style="list-style-type: none"> • Parking lamps • License plate lamps • Side maker lamps • Tail lamps • Front fog lamps • Headlamp (HI, LO) • Front wiper (HI, LO) | Perform auto active test. Does the applicable system operate? | YES BCM signal input circuit |
| | | NO <ul style="list-style-type: none"> • Lamp or motor • Lamp or motor ground circuit • Harness or connector between IPDM E/R and applicable system • IPDM E/R |
| A/C compressor does not operate | Perform auto active test. Does the magnet clutch operate? | YES <ul style="list-style-type: none"> • A/C amp. signal input circuit • CAN communication signal between A/C amp. and ECM • CAN communication signal between ECM and IPDM E/R |
| | | NO <ul style="list-style-type: none"> • Magnet clutch • Harness or connector between IPDM E/R and magnet clutch • IPDM E/R |
| Oil pressure warning lamp does not operate | Perform auto active test. Does the oil pressure warning lamp blink? | YES <ul style="list-style-type: none"> • Harness or connector between IPDM E/R and oil pressure switch • Oil pressure switch • IPDM E/R |
| | | NO <ul style="list-style-type: none"> • CAN communication signal between IPDM E/R and BCM • CAN communication signal between BCM and combination meter • Combination meter |

DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

| Symptom | Inspection contents | Possible cause | |
|------------------------------|--|----------------|--|
| Cooling fan does not operate | Perform auto active test. Does the cooling fan operate? | YES | <ul style="list-style-type: none"> • ECM signal input circuit • CAN communication signal between ECM and IPDM E/R |
| | | NO | <ul style="list-style-type: none"> • Harness or connector between IPDM E/R and cooling fan motor • Harness or connector between IPDM E/R and cooling fan relay • Cooling fan motor • Cooling fan relay • IPDM E/R |

CONSULT Function (IPDM E/R)

INFOID:000000010129277

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with IPDM E/R.

| Diagnosis mode | Description |
|--------------------------|---|
| Ecu Identification | Allows confirmation of IPDM E/R part number. |
| Self Diagnostic Result | Displays the diagnosis results judged by IPDM E/R. |
| Data Monitor | Displays the real-time input/output data from IPDM E/R input/output data. |
| Active Test | IPDM E/R can provide a drive signal to electronic components to check their operations. |
| CAN Diag Support Monitor | The results of transmit/receive diagnosis of CAN communication can be read. |

SELF DIAGNOSTIC RESULT

Refer to [PCS-34, "DTC Index"](#).

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

| Monitor Item [Unit] | MAIN SIG- NALS | Description |
|----------------------------------|-------------------|---|
| MOTOR FAN REQ [1/2/3/4] | × | Displays the value of the cooling fan speed request signal received from ECM via CAN communication. |
| AC COMP REQ [Off/On] | × | Displays the status of the A/C compressor request signal received from ECM via CAN communication. |
| TAIL&CLR REQ [Off/On] | × | Displays the status of the position light request signal received from BCM via CAN communication. |
| HL LO REQ [Off/On] | × | Displays the status of the low beam request signal received from BCM via CAN communication. |
| HL HI REQ [Off/On] | × | Displays the status of the high beam request signal received from BCM via CAN communication. |
| FR FOG REQ [Off/On] | × | Displays the status of the front fog light request signal received from BCM via CAN communication. |
| FR WIP REQ [Stop/1LOW/Low/Hi] | × | Displays the status of the front wiper request signal received from BCM via CAN communication. |
| WIP AUTO STOP [STOP P/ACT P] | × | Displays the status of the front wiper auto stop signal judged by IPDM E/R. |
| WIP PROT [Off/BLOCK] | × | Displays the status of the front wiper fail-safe operation judged by IPDM E/R. |
| IGN RLY1 -REQ [Off/On] | | Displays the status of the ignition switch ON signal received from BCM via CAN communication. |

DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

| Monitor Item [Unit] | MAIN SIG- NALS | Description |
|---|-------------------|---|
| IGN RLY [Off/On] | × | Displays the status of the ignition relay judged by IPDM E/R. |
| PUSH SW [Off/On] | | Displays the status of the push-button ignition switch judged by IPDM E/R. |
| INTER/NP SW [Off/On] | | Displays the status of the shift position judged by IPDM E/R. |
| ST RLY CONT [Off/On] | | Displays the status of the starter relay status signal received from BCM via CAN communication. |
| IHBT RLY -REQ [Off/On] | | Displays the status of the starter control relay signal received from BCM via CAN communication. |
| ST/INHI RLY [Off/ ST ON/INHI ON/UNKWN] | | Displays the status of the starter relay and starter control relay judged by IPDM E/R. |
| DETENT SW [Off/On] | | Displays the status of the CVT shift selector (detention switch) judged by IPDM E/R. |
| S/L RLY -REQ [Off/On] | | NOTE: The item is indicated, but not monitored. |
| S/L STATE [LOCK/UNLOCK/UNKWN] | | NOTE: The item is indicated, but not monitored. |
| DTRL REQ [Off/On] | | NOTE: The item is indicated, but not monitored. |
| OIL P SW [Open/Close] | | Displays the status of the oil pressure switch judged by IPDM E/R. |
| HOOD SW [Off/On] | | NOTE: The item is indicated, but not monitored. |
| HL WASHER REQ [Off/On] | | NOTE: The item is indicated, but not monitored. |
| THFT HRN REQ [Off/On] | | Displays the status of the theft warning horn request signal received from BCM via CAN communication. |
| HORN CHIRP [Off/On] | | Displays the status of the horn reminder signal received from BCM via CAN communication. |
| CRNRNG LMP REQ [Off/On] | | NOTE: The item is indicated, but not monitored. |

ACTIVE TEST

| Test item | Operation | Description |
|------------------|-----------|--|
| CORNERING LAMP | Off | NOTE: The item is indicated, but cannot be tested. |
| | LH | |
| | RH | |
| HORN | On | Operates horn relay for 20 ms. |
| FRONT WIPER | Off | OFF |
| | Lo | Operates the front wiper relay. |
| | Hi | Operates the front wiper relay and front wiper high relay. |
| MOTOR FAN | 1 | OFF |
| | 2 | Operates the cooling fan relay-1. |
| | 3 | Operates the cooling fan relay-2. |
| | 4 | Operates the cooling fan relay-2 and cooling fan relay-3. |
| HEAD LAMP WASHER | On | NOTE: The item is indicated, but cannot be tested. |

DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

| Test item | Operation | Description |
|----------------|-----------|---|
| EXTERNAL LAMPS | Off | OFF |
| | TAIL | Operates the tail lamp relay. |
| | Lo | Operates the headlamp low relay. |
| | Hi | Operates the headlamp low relay and ON/OFF the headlamp high relay at 1 second intervals. |
| | Fog | Operates the front fog lamp relay. |

WIPER AND WASHER FUSE, FUSIBLE LINK

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

WIPER AND WASHER FUSE, FUSIBLE LINK

Description

INFOID:000000009719726

Fuse, fusible link list

| Unit | Location | No. | Capacity |
|-------------------|------------|-----|----------|
| Front wiper motor | IPDM E/R | 60 | 30 A |
| Washer pump | IPDM E/R | 47 | 10 A |
| Rain sensor | Fuse block | 6 | 10 A |

Diagnosis Procedure

INFOID:000000009719727

1. CHECK FUSES AND FUSIBLE LINK

Check that the following fuses and fusible link are not fusing.

| Unit | Location | No. | Capacity |
|-------------------|------------|-----|----------|
| Front wiper motor | IPDM E/R | 60 | 30 A |
| Washer pump | IPDM E/R | 47 | 10 A |
| Rain sensor | Fuse block | 6 | 10 A |

Is the fuse or fusible link fusing?

- YES >> Replace the fuse or fusible link with a new one after repairing the applicable circuit.
- NO >> The fuse or fusible link is normal.

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

WW

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

POWER SUPPLY AND GROUND CIRCUIT

BCM (BODY CONTROL MODULE)

BCM (BODY CONTROL MODULE) : Diagnosis Procedure

INFOID:000000009719728

1. CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

| Signal name | Fuse and fusible link No. |
|----------------------|---------------------------|
| Battery power supply | L |
| | 10 |

Is the fuse fusing?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit if a fuse or fusible link is blown.

NO >> GO TO 2.

2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connectors.
3. Check voltage between BCM harness connector and ground.

| Terminals | | Voltage (Approx.) |
|-----------|----------|---------------------------|
| (+) | (-) | |
| BCM | | Ground Battery voltage |
| Connector | Terminal | |
| M118 | 1 | |
| M119 | 11 | |

Is the measurement value normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3. CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

| BCM | | Ground | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal | | Existed |
| M119 | 13 | | |

Does continuity exist?

YES >> INSPECTION END

NO >> Repair harness or connector.

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) : Diagnosis Procedure

INFOID:000000009719729

1. CHECK FUSES AND FUSIBLE LINK

Check that the following IPDM E/R fuses or fusible links are not blown.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

| Signal name | Fuses and fusible link No. |
|----------------------|----------------------------|
| Battery power supply | E |
| | 50 |
| | 51 |

Is the fuse fusing?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit if a fuse or fusible link is blown.

NO >> GO TO 2.

2.CHECK POWER SUPPLY CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check voltage between IPDM E/R harness connector and the ground.

| Terminals | | Voltage (Approx.) |
|-----------|----------|----------------------|
| (+) | (-) | |
| IPDM E/R | | Battery voltage |
| Connector | Terminal | |
| E9 | 1 | |

Is the measurement value normal?

YES >> GO TO 3.

NO >> Repair the harness or connector.

3.CHECK GROUND CIRCUIT

Check continuity between IPDM E/R harness connectors and the ground.

| IPDM E/R | | Ground | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal | | |
| E10 | 12 | | Existed |
| E11 | 41 | | |

Does continuity exist?

YES >> INSPECTION END

NO >> Repair the harness or connector.

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P



FRONT WIPER MOTOR LO CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

FRONT WIPER MOTOR LO CIRCUIT

Component Function Check

INFOID:000000009719730

1. CHECK FRONT WIPER LO OPERATION

⊗ IPDM E/R AUTO ACTIVE TEST

1. Start IPDM E/R auto active test. Refer to [PCS-10, "Diagnosis Description"](#).
2. Check that the front wiper operates at the LO operation.

Ⓟ CONSULT ACTIVE TEST

1. Select "FRONT WIPER" of IPDM E/R active test item.
2. With operating the test item, check front wiper operation.

Lo : Front wiper (LO) operation

Off : Stop the front wiper.

Is front wiper (LO) operation normally?

- YES >> Front wiper motor LO circuit is normal.
NO >> Refer to [WW-30, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009719731

1. CHECK FRONT WIPER MOTOR (LO) OUTPUT VOLTAGE

1. Turn the ignition switch OFF, and wait for 20 seconds or more.
2. Disconnect front wiper motor connector.
3. Turn the ignition switch ON, and wait for 10 seconds.
4. Check voltage between IPDM E/R harness connector and ground.

| Terminals | | | Voltage (Approx.) |
|-----------|----------|--------|----------------------------------|
| (+) | (-) | | |
| IPDM E/R | | Ground | Battery voltage (10 seconds)* |
| Connector | Terminal | | |
| E10 | 4 | | |

*: According to front wiper protection function, IPDM E/R supplies voltage for 10 seconds (battery voltage) and then stops for 20 seconds (0 V). This operations repeats 5 times, and then IPDM E/R stops voltage supply. To perform the check again, turn ignition switch OFF, wait for 20 seconds or more, and then perform the check.

Is the measurement value normal?

- YES >> GO TO 2.
NO >> Replace IPDM E/R.

2. CHECK FRONT WIPER MOTOR (LO) OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and front wiper motor harness connector.

| IPDM E/R | | Front wiper motor | | Continuity |
|-----------|----------|-------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E10 | 4 | E12 | 1 | Existed |

Does continuity exist?

- YES >> GO TO 3.
NO >> Repair the harness or connector.

3. CHECK FRONT WIPER MOTOR (LO) SHORT CIRCUIT

Check continuity between IPDM E/R harness connector and ground.

FRONT WIPER MOTOR LO CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

| IPDM E/R | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| E10 | 4 | | Not existed |

Does continuity exist?

YES >> Repair the harness or connector.

NO >> Replace front wiper motor.

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

FRONT WIPER MOTOR HI CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

FRONT WIPER MOTOR HI CIRCUIT

Component Function Check

INFOID:000000009719732

1. CHECK FRONT WIPER HI OPERATION

⊗ IPDM E/R AUTO ACTIVE TEST

1. Start IPDM E/R auto active test. Refer to [PCS-10, "Diagnosis Description"](#).
2. Check that the front wiper operates at the HI operation.

Ⓟ CONSULT ACTIVE TEST

1. Select "FRONT WIPER" of IPDM E/R active test item.
2. With operating the test item, check front wiper operation.

Hi : Front wiper (HI) operation

Off : Stop the front wiper.

Is front wiper (HI) operation normally?

YES >> Front wiper motor HI circuit is normal.

NO >> Refer to [WW-32, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009719733

1. CHECK FRONT WIPER MOTOR (HI) OUTPUT VOLTAGE

Ⓟ CONSULT ACTIVE TEST

1. Turn the ignition switch OFF, and wait for 20 seconds or more.
2. Disconnect front wiper motor connector.
3. Turn the ignition switch ON.
4. Select "FRONT WIPER" of IPDM E/R active test item.
5. With operating the test item, check voltage between IPDM E/R harness connector and ground.

| Terminals | | Test item | Voltage (Approx.) |
|-----------|----------|-------------|----------------------------------|
| (+) | (-) | | |
| IPDM E/R | | FRONT WIPER | Battery voltage (10 seconds)* |
| Connector | Terminal | | |
| E10 | 5 | Hi | |

*: According to front wiper protection function, IPDM E/R supplies voltage for 10 seconds (battery voltage) and then stops for 20 seconds (0 V). This operations repeats 5 times, and then IPDM E/R stops voltage supply. To perform the check again, turn ignition switch OFF, wait for 20 seconds or more, and then perform the check.

Is the measurement value normal?

YES >> GO TO 2.

NO >> Replace IPDM E/R.

2. CHECK FRONT WIPER MOTOR (HI) OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and front wiper motor harness connector.

| IPDM E/R | | Front wiper motor | | Continuity |
|-----------|----------|-------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E10 | 5 | E12 | 4 | Existed |

Does continuity exist?

YES >> GO TO 3.

NO >> Repair the harness or connector.

3. CHECK FRONT WIPER MOTOR (HI) SHORT CIRCUIT

FRONT WIPER MOTOR HI CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Check continuity between IPDM E/R harness connector and ground.

| IPDM E/R | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| E10 | 5 | | Not existed |

Does continuity exist?

- YES >> Repair the harness or connector.
- NO >> Replace front wiper motor.

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

FRONT WIPER STOP POSITION SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

FRONT WIPER STOP POSITION SIGNAL CIRCUIT

Component Function Check

INFOID:000000009719734

1.CHECK FRONT WIPER STOP POSITION SIGNAL

CONSULT DATA MONITOR

1. Select "FR WIPER STOP" of BCM data monitor item.
2. Operate the front wiper.
3. Check that "FR WIPER STOP" changes to "STOP P" and "ACT P" linked with the wiper operation.

| Monitor item | Condition | | Monitor status |
|---------------|-------------------|----------------------|----------------|
| FR WIPER STOP | Front wiper motor | Stop position | STOP P |
| | | Except stop position | ACT P |

Is the status of item normal?

- YES >> Front wiper stop position signal circuit is normal.
NO >> Refer to [WW-34, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009719735

1.CHECK FRONT WIPER MOTOR OUTPUT VOLTAGE

1. Turn the ignition switch OFF.
2. Disconnect front wiper motor connector.
3. Turn the ignition switch ON.
4. Check voltage between IPDM E/R harness connector and ground.

| Terminals | | Voltage (Approx.) |
|-----------|----------|-------------------|
| (+) | (-) | |
| IPDM E/R | | Battery voltage |
| Connector | Terminal | |
| E10 | 16 | |

Is the measurement value normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2.CHECK FRONT WIPER MOTOR SHORT CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and ground.

| IPDM E/R | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| E10 | 16 | | Not existed |

Does continuity exist?

- YES >> Repair the harness or connector.
NO >> Replace IPDM E/R.

3.CHECK FRONT WIPER MOTOR CIRCUIT CONTINUITY

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and front wiper motor harness connector.

FRONT WIPER STOP POSITION SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

| IPDM E/R | | Front wiper motor | | Continuity |
|-----------|----------|-------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E10 | 16 | E12 | 5 | Existed |

Does continuity exist?

- YES >> Replace front wiper motor.
- NO >> Repair the harness or connector.

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

WW

FRONT WIPER MOTOR GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

FRONT WIPER MOTOR GROUND CIRCUIT

Diagnosis Procedure

INFOID:000000009719736

1. CHECK FRONT WIPER MOTOR (GROUND) OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect front wiper motor connector.
3. Check continuity between front wiper motor harness connector and ground.

| Front wiper motor | | Ground | Continuity |
|-------------------|----------|--------|------------|
| Connector | Terminal | | Existed |
| E12 | 2 | | |

Does continuity exist?

- YES >> Front wiper motor ground circuit is normal.
NO >> Repair the harness or connector.

WASHER SWITCH


< DTC/CIRCUIT DIAGNOSIS >

WASHER SWITCH

Description

INFOID:000000009719737

- Washer switch is integrated with combination switch.
- Combination switch switches polarity between front washer operating and rear washer operating to supply power to the washer pump on ground.




Component Inspection

INFOID:000000009719738

1. CHECK WIPER SWITCH

1. Turn the ignition switch OFF.
2. Disconnect combination switch connector.
3. Check continuity between the combination switch terminals.

- A : Terminal 4
 B : Terminal 6
 C : Terminal 3
 D : Terminal 1



JPLIA0164GB

| Combination switch | | Condition | Continuity |
|--------------------|---|------------------------|------------|
| Terminal | | | |
| 1 | 6 | Front washer switch ON | Existed |
| 3 | 4 | | |
| 1 | 4 | Rear washer switch ON | |
| 3 | 6 | | |

Does continuity exist?

- YES >> Wiper and washer switch is normal.
 NO >> Replace combination switch (Wiper and washer switch).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

WW

RAIN SENSOR


< DTC/CIRCUIT DIAGNOSIS >

RAIN SENSOR

Description

INFOID:000000009719739

Rain sensor judges a wiping speed for front wiper by rain condition and the vehicle conditions. And it transmits the wiping speed request signal to the BCM via the rain sensor serial link.



Component Function Check

INFOID:000000009719740

1. CHECK FRONT WIPER AUTO OPERATION

1. Clean rain sensor detection area of windshield fully.
2. When the front wiper switch is turned to INT/AUTO position, front wiper operates once regardless of a rainy condition.

Is front wiper (AUTO) operation normally?

- YES >> Rain sensor circuit is normal.
NO >> Refer to [WW-38, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009719741

1. CHECK RAIN SENSOR FUSE

1. Turn the ignition switch OFF.
2. Check that the rain sensor 10 A fuse (#6) is not fusing.

Is the fuse fusing?

- YES >> Replace the fuse after repairing the applicable circuit.
NO >> GO TO 2.

2. CHECK RAIN SENSOR POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect rain sensor connector.
3. Turn ignition switch ON.
4. Check voltage between rain sensor harness connector and ground.

| Terminal | | Voltage (Approx.) |
|-----------------------|----------|-------------------|
| (+) | (-) | |
| Rain sensor connector | Terminal | |
| R23 | 1 | Battery voltage |

Is the measurement value normal?

- YES >> GO TO 3.
NO >> Repair or replace harness.

3. CHECK RAIN SENSOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between rain sensor harness connector and ground.

RAIN SENSOR

< DTC/CIRCUIT DIAGNOSIS >

| Rain sensor | | Ground | Continuity |
|-------------|----------|--------|------------|
| Connector | Terminal | | |
| R23 | 3 | | Existed |


Does continuity exist?

YES >> GO TO 4.

NO >> Repair or replace harness.

4. CHECK RAIN SENSOR SIGNAL

1. Connect rain sensor connector.
2. Turn ignition switch ON.
3. Check signal between BCM harness connector and ground with oscilloscope.

| Terminal (+) | | Terminal (-) | Condition | Signal (Reference value) |
|---------------|----------|--------------|--------------------|---|
| BCM connector | Terminal | | | |
| M123 | 112 | Ground | Ignition switch ON |  <p>Approx. 8.7V</p> |

Is the measurement value normal?

YES >> Replace rain sensor. Refer to [WW-140, "Exploded View"](#).

NO >> GO TO 5.

5. CHECK RAIN SENSOR SIGNAL CIRCUIT FOR OPEN

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and rain sensor harness connector.

| BCM | | Rain sensor | | Continuity |
|-----------|----------|-------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M123 | 112 | R23 | 2 | Existed |

Does continuity exist?

YES >> GO TO 6.

NO >> Repair or replace harness.

6. CHECK RAIN SENSOR SIGNAL CIRCUIT FOR SHORT

Check continuity between BCM harness connector and ground.

| BCM | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| M123 | 112 | | Not existed |

Does continuity exist?

YES >> Repair or replace harness.

NO >> Replace BCM. Refer to [BCS-98, "Exploded View"](#).

REAR WIPER MOTOR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

REAR WIPER MOTOR CIRCUIT

Component Function Check

INFOID:000000009719742

1. CHECK REAR WIPER ON OPERATION

CONSULT ACTIVE TEST

1. Select "RR WIPER" of BCM active test item.
2. With operating the test item, check rear wiper operation.

On : Rear wiper ON operation

Off : Stop the rear wiper.

Is rear wiper operation normally?

- YES >> Rear wiper motor circuit is normal.
NO >> Refer to [WW-40, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009719743

1. CHECK REAR WIPER MOTOR OUTPUT VOLTAGE

CONSULT ACTIVE TEST

1. Turn rear wiper switch OFF, and wait for 1 minute or more.
2. Turn the ignition switch OFF.
3. Disconnect rear wiper motor connector.
4. Turn the ignition switch ON.
5. Select "RR WIPER" of BCM active test item.
6. With operating the test item, check voltage between BCM harness connector and ground.

| Terminals | | Test item | Voltage (Approx.) |
|-----------|----------|------------|---------------------------------|
| (+) | (-) | | |
| BCM | | REAR WIPER | Battery voltage (5 seconds)* |
| Connector | Terminal | | |
| M120 | 26 | On | |

*: When "REAR WIPER" is "On" for 5 seconds or more during active test of CONSULT, BCM stops the power supply according to rear wiper motor protection function. To perform the check again, turn "REAR WIPER" to "Off", wait for 1 minute or more, and then perform the check.

Is the measurement value normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK REAR WIPER MOTOR SHORT CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and ground.

| BCM | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| M120 | 26 | | Not existed |

Does continuity exist?

- YES >> Repair the harness or connector.
NO >> Replace BCM. Refer to [BCS-98, "Exploded View"](#).

3. CHECK REAR WIPER MOTOR OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector.

REAR WIPER MOTOR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

3. Check continuity between BCM harness connector and rear wiper motor harness connector.

| BCM | | Rear wiper motor | | Continuity |
|-----------|----------|------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M120 | 26 | D193 | 1 | Existed |

Does continuity exist?

YES >> GO TO 4.

NO >> Repair the harness or connector.

4. CHECK REAR WIPER MOTOR GROUND OPEN CIRCUIT

Check continuity between rear wiper motor harness connector and ground.

| Rear wiper motor | | Ground | Continuity |
|------------------|----------|--------|------------|
| Connector | Terminal | | |
| D193 | 3 | | Existed |

Does continuity exist?

YES >> Replace rear wiper motor.

NO >> Repair the harness or connector.

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

WW

REAR WIPER STOP POSITION SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

REAR WIPER STOP POSITION SIGNAL CIRCUIT

Component Function Check

INFOID:000000009719744

1. CHECK REAR WIPER STOP POSITION SIGNAL

CONSULT DATA MONITOR

1. Select "WIPER" of BCM data monitor item.
2. Operate the rear wiper.
3. Check that "RR WIPER STOP" changes to "ON" and "OFF" linked with the wiper operation.

| Monitor item | Condition | | Monitor status |
|---------------|------------------|----------------------|----------------|
| RR WIPER STOP | Rear wiper motor | Stop position | On |
| | | Except stop position | Off |

Is the status of item normal?

- YES >> Rear wiper stop position signal circuit is normal.
NO >> Refer to [WW-42, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009719745

1. CHECK REAR WIPER MOTOR OUTPUT VOLTAGE

1. Turn the ignition switch OFF.
2. Disconnect rear wiper motor connector.
3. Turn the ignition switch ON.
4. Check voltage between BCM harness connector and ground.

| Terminals | | Ground | Voltage (Approx.) |
|-----------|----------|--------|-------------------|
| (+) | (-) | | |
| BCM | | Ground | Battery voltage |
| Connector | Terminal | | |
| M121 | 65 | | |

Is the measurement value normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK REAR WIPER MOTOR SHORT CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and ground.

| BCM | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| M121 | 65 | | Not existed |

Does continuity exist?

- YES >> Repair the harness or connector.
NO >> Replace BCM. Refer to [BCS-98, "Exploded View"](#).

3. CHECK REAR WIPER MOTOR OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and rear wiper motor harness connector.

REAR WIPER STOP POSITION SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

| BCM | | Rear wiper motor | | Continuity |
|-----------|----------|------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M121 | 65 | D193 | 4 | Existed |

Does continuity exist?

- YES >> Replace rear wiper motor.
- NO >> Repair the harness or connector.

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

WW


FRONT WIPER AND WASHER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

FRONT WIPER AND WASHER SYSTEM

Wiring Diagram - FRONT WIPER AND WASHER SYSTEM -


INFOID:00000009719746



FRONT WIPER AND WASHER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

◊WL◊ : With LDW
 ◊OL◊ : Without LDW




A
B
C
D
E
F
G
H
I
J
K
WW
M
N
O
P

FRONT WIPER AND WASHER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

FRONT WIPER AND WASHER SYSTEM


| | |
|----------------|--------------|
| Connector No. | B11 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH88MM-CSS19 |



| Terminal No. | Color Of Wires | Signal Name [Specification] |
|--------------|----------------|-----------------------------|
| 1 | SHIELD | |
| 2 | R/L | |
| 3 | R/L | |
| 4 | R/W | |
| 6 | P | |
| 7 | V | |
| 8 | SHIELD | |
| 9 | BR/L | |
| 10 | Y/G | |
| 11 | Y/L | |
| 12 | W/L | |
| 13 | L | |
| 14 | BR | |
| 15 | SB | |
| 16 | SP | |
| 17 | V | |
| 18 | SB | |
| 19 | R | |
| 20 | P | |
| 21 | LG | |
| 22 | W | |
| 23 | Y | |
| 24 | GR | |
| 25 | Y | |
| 27 | V | |
| 28 | R | |
| 30 | P | |
| 31 | BR | |
| 32 | SB | |
| 33 | SB | |
| 35 | SHIELD | |
| 36 | G | |
| 37 | LG | |
| 40 | Y | |
| 41 | GR | |

| | | |
|----|--------|--|
| 42 | G | |
| 43 | G | |
| 44 | LG | |
| 45 | G | |
| 46 | SB | |
| 47 | R | |
| 48 | GR | |
| 49 | SHIELD | |
| 50 | B | |
| 51 | BR | |
| 52 | G | |
| 53 | R/W | |
| 54 | R | |
| 55 | R/L | |
| 56 | B | |
| 57 | L | |
| 58 | R | |
| 59 | R | |
| 60 | SHIELD | |
| 61 | B | |
| 62 | Y | |
| 63 | R/L | |
| 64 | R/W | |
| 65 | LG | |
| 66 | R | |
| 67 | L | |
| 68 | V | |
| 69 | G | |
| 70 | GR | |
| 71 | BR | |
| 72 | R | |
| 73 | SHIELD | |
| 74 | W/R | |
| 75 | B/R | |
| 76 | Y | |
| 77 | LG | |
| 78 | SB | |
| 79 | L | |
| 80 | G | |
| 81 | R | |
| 82 | L | |

| | |
|----------------|--------------|
| Connector No. | E8 |
| Connector Name | WIRE TO WIRE |
| Connector Type | INS12MBRR-CS |



| Terminal No. | Color Of Wires | Signal Name [Specification] |
|--------------|----------------|-----------------------------|
| 3 | GR | |
| 4 | SB | |
| 5 | O | |
| 8 | G | |
| 9 | W | |
| 10 | Y | |
| 11 | G | |

| | |
|----------------|--|
| Connector No. | E10 |
| Connector Name | ENGINE INTELLIGENT POWER DISTRIBUTION MODULE FRAME |
| Connector Type | TH20FM-CSS12-M4-TV |



| Terminal No. | Color Of Wires | Signal Name [Specification] |
|--------------|----------------|-----------------------------|
| 4 | LG | |
| 5 | V | |
| 7 | GR | |
| 10 | GR | |
| 12 | B | |
| 13 | SB | |
| 15 | W | |
| 16 | R | |
| 19 | Y | |
| 20 | L | |
| 21 | O | |
| 22 | SB | |
| 23 | GR | |
| 24 | G | |
| 25 | GR | |
| 26 | V | |
| 27 | W | |
| 28 | SB | |
| 30 | BR | |
| 34 | O | |
| 35 | P | |
| 36 | G | |
| 38 | GR | |

FRONT WIPER AND WASHER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

FRONT WIPER AND WASHER SYSTEM

| | |
|----------------|------------------------------|
| Connector No. | E11 |
| Connector Name | REAR VIEW CAMERA WIPER MOTOR |
| Connector Type | INS32MW-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 38 | P | - |
| 40 | B | - |
| 41 | S | - |
| 42 | SB | - |
| 43 | Y | - |
| 44 | W | - |
| 45 | O | - |
| 46 | BR | - |

| | |
|----------------|-------------------|
| Connector No. | E12 |
| Connector Name | FRONT WIPER MOTOR |
| Connector Type | HS5FCY |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | LG | - |
| 2 | B/W | - |
| 4 | Y | - |
| 5 | R | - |

| | |
|----------------|--------------|
| Connector No. | E28 |
| Connector Name | WIRE TO WIRE |
| Connector Type | INS32MW-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | GR | - |
| 2 | Y | - |

| | |
|----------------|--------------------------------|
| Connector No. | E28 |
| Connector Name | REAR VIEW CAMERA WIPER RELAY 2 |
| Connector Type | MS30FEB-AM-LC |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W | - |
| 2 | L | - |
| 3 | GR | - |
| 4 | GR | - |
| 5 | W | - |

| | |
|----------------|--------------------------------|
| Connector No. | E29 |
| Connector Name | REAR VIEW CAMERA WIPER RELAY 1 |
| Connector Type | MS30FEB-M2-LC |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W | - |
| 2 | W | - |
| 3 | O | - |
| 4 | O | - |
| 5 | B | - |

| | |
|----------------|---------------|
| Connector No. | E105 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH10MM-CSD-M3 |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 3 | Y | - |
| 5 | LG | - |
| 6 | GR | - |
| 8 | G | - |
| 11 | P | - |
| 12 | L | - |
| 13 | Y | - |
| 14 | GR | - |
| 20 | Y | - |
| 21 | BR | - |
| 22 | P | - |
| 24 | L | - |
| 25 | O | - |
| 26 | SB | - |

| | | |
|----|--------|---|
| 29 | W | - |
| 30 | Y | - |
| 32 | R | - |
| 39 | L | - |
| 40 | B | - |
| 47 | P | - |
| 48 | L | - |
| 49 | SB | - |
| 50 | GR | - |
| 51 | LG | - |
| 52 | V | - |
| 53 | GR | - |
| 54 | BR | - |
| 55 | Y | - |
| 56 | W/L | - |
| 60 | BR | - |
| 62 | O | - |
| 63 | L/O | - |
| 64 | SHIELD | - |
| 66 | W | - |
| 67 | BR | - |
| 68 | Y | - |
| 69 | SB | - |
| 70 | GR | - |
| 71 | SB | - |
| 72 | Y | - |
| 73 | L | - |
| 74 | W | - |
| 75 | BR | - |
| 76 | GR | - |
| 77 | O | - |
| 78 | G | - [With iPod without navigation system] |
| 78 | V | - [Without iPod and navigation system] |
| 79 | Y | - [With navigation system] |
| 80 | R | - |
| 81 | W | - |
| 82 | LG | - |
| 83 | O | - |

JRLWC9472GB

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

WW

FRONT WIPER AND WASHER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >


FRONT WIPER AND WASHER SYSTEM

| | |
|----------------|-------------|
| Connector No. | E322 |
| Connector Name | WASHER PUMP |
| Connector Type | E02FGY-RS |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | O | - |
| 2 | O | - |

| | |
|----------------|--------------|
| Connector No. | E339 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS1ZFBR-CS |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 3 | O | - |
| 4 | G | - |
| 5 | O | - |
| 8 | G | - |
| 9 | W | - |
| 10 | Y | - |
| 11 | R | - |

| | |
|----------------|--|
| Connector No. | E345 |
| Connector Name | INTELLIGENT POWER DISTRIBUTION MOBILE ENGINE (P/ONE) |
| Connector Type | NS30RFW-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 82 | L | - |
| 83 | Y | - |
| 84 | L | - |
| 85 | SB | - |
| 86 | GR | - |
| 87 | GR | - |
| 88 | W | - |
| 89 | L | - |
| 90 | G | - |

| | |
|----------------|------------------|
| Connector No. | M1 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | NS36FPW-M2 |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1A | Y | - |
| 2A | G | - |
| 3A | Y | - |
| 4A | GR | - |
| 7A | LG | - |
| 8A | Y | - |

| | |
|----------------|------------------|
| Connector No. | M2 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | NS10FPW-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 35 | Y | - |
| 36 | G | - |
| 44 | L | - |
| 45 | L | - |
| 55 | Y | - |
| 75 | R | - |
| 85 | R | - |
| 85 | GR | - |

| | |
|----------------|---------------------|
| Connector No. | M4 |
| Connector Name | DATA LINK CONNECTOR |
| Connector Type | BD16FW |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 3 | LG | - |
| 4 | B | - |
| 5 | B | - |
| 6 | LG | - |
| 8 | LG | - |
| 11 | SP | - |
| 14 | P | - |
| 16 | Y | - |

| | |
|----------------|----------------|
| Connector No. | M11 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH10FM-CS10-M3 |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 3 | BR | - |
| 5 | BR | - |
| 5 | OD | - |
| 6 | G | - |
| 8 | R | - |
| 11 | P | - |
| 12 | L | - |
| 13 | V | - |
| 14 | Y | - |
| 15 | R | - |
| 20 | W | -(Without colour display) |
| 20 | Y | -(With colour display) |
| 21 | BR | - |
| 22 | LG | - |
| 24 | Y | - |
| 24 | BR | - |
| 28 | BR | - |
| 29 | B | - |
| 30 | R | - |
| 38 | R | - |
| 39 | L | - |
| 40 | B | - |
| 47 | P | - |
| 48 | L | - |
| 49 | W | - |
| 50 | GR | - |
| 51 | LG | - |
| 52 | Y | - |
| 53 | SB | - |
| 55 | P | - |
| 56 | LG | - |
| 60 | V | - |
| 61 | GR | - |
| 62 | BR | - |
| 63 | V | - |

FRONT WIPER AND WASHER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

FRONT WIPER AND WASHER SYSTEM

| | | | |
|-----|--------|---|---|
| 84 | SHIELD | - | - |
| 85 | W | - | - |
| 86 | W | - | - |
| 87 | W | - | - |
| 88 | W | - | - |
| 89 | P | - | - |
| 90 | G | - | - |
| 91 | G | - | - |
| 92 | BR | - | - |
| 93 | L | - | - |
| 94 | W | - | - |
| 95 | BR | - | - |
| 96 | R | - | - |
| 97 | G | - | - |
| 98 | Y | - | - |
| 99 | G | - | - |
| 100 | W | - | - |
| 101 | W | - | - |
| 102 | W | - | - |
| 103 | EG | - | - |

| | |
|----------------|--------------|
| Connector No. | M23 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH18MR-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-------------------------------|
| 1 | W | - |
| 2 | R | - [Without navigation system] |
| 3 | B | - [With navigation system] |
| 4 | SHIELD | - |
| 5 | SHIELD | - |
| 6 | Y | - |
| 7 | Y | - |
| 8 | B | - |
| 9 | Y | - |
| 10 | B | - |
| 11 | P | - |
| 12 | L | - |
| 13 | SB | - |
| 14 | G | - |
| 15 | G | - |
| 16 | R | - |

FRONT WIPER AND WASHER SYSTEM

| | | |
|----|----|---|
| 23 | B | GROUND |
| 24 | BR | FUEL LEVEL SIGNAL |
| 25 | BR | ALTERNATOR SIGNAL |
| 26 | G | PARKING BRAKE SWITCH SIGNAL |
| 27 | V | BRAKE FLUID LEVEL SWITCH SIGNAL |
| 28 | R | WASHER LEVEL SWITCH SIGNAL |
| 29 | P | VEHICLE SPEED SIGNAL (2-PULSE) |
| 30 | V | VEHICLE SPEED SIGNAL (8-PULSE) |
| 31 | LG | OVERDRIVE CONTROL SWITCH SIGNAL |
| 32 | G | FUEL LEVEL SENSOR SIGNAL |
| 33 | SB | SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SIDE) |
| 34 | R | SEAT BELT BUCKLE SWITCH SIGNAL (PASSENGER SIDE) |

| | |
|----------------|--------------|
| Connector No. | M26 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS32FW-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|--|
| 1 | Y | BATTERY POWER SUPPLY |
| 2 | LG | IGN SIGNAL |
| 3 | B | GROUND |
| 4 | B | GROUND |
| 5 | SB | ILLUMINATION CONTROL SIGNAL |
| 6 | SB | TRIP RESET SIGNAL |
| 7 | W | SW ILL POWER |
| 8 | W | METER CONTROL SWITCH GROUND |
| 9 | L | ENTER SWITCH SIGNAL |
| 10 | L | SELECT SWITCH SIGNAL |
| 11 | R | ILLUMINATION CONTROL SWITCH SIGNAL (1) |
| 12 | R | ILLUMINATION CONTROL SWITCH SIGNAL (2) |
| 13 | CR | MAP SAG SIGNAL |
| 14 | BR | AMBIENT SENSOR SIGNAL |
| 15 | L | AMBIENT SENSOR POWER |
| 16 | P | AMBIENT SENSOR GROUND |
| 17 | P | CAN-H |
| 18 | P | CAN-L |

FRONT WIPER AND WASHER SYSTEM

| | | |
|----|----|---|
| 35 | B | GROUND |
| 36 | BR | FUEL LEVEL SIGNAL |
| 37 | G | PARKING BRAKE SWITCH SIGNAL |
| 38 | V | BRAKE FLUID LEVEL SWITCH SIGNAL |
| 39 | R | WASHER LEVEL SWITCH SIGNAL |
| 40 | P | VEHICLE SPEED SIGNAL (2-PULSE) |
| 41 | V | VEHICLE SPEED SIGNAL (8-PULSE) |
| 42 | LG | OVERDRIVE CONTROL SWITCH SIGNAL |
| 43 | G | FUEL LEVEL SENSOR SIGNAL |
| 44 | SB | SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SIDE) |
| 45 | R | SEAT BELT BUCKLE SWITCH SIGNAL (PASSENGER SIDE) |

| | |
|----------------|--------------|
| Connector No. | M27 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80FW-CS19 |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | SHIELD | - |
| 2 | W | - |
| 3 | W | - |
| 4 | R | - |
| 5 | W | - |
| 6 | W | - |
| 7 | G | - |
| 8 | SHIELD | - |
| 9 | W | - |
| 10 | R | - |
| 11 | G | - |
| 12 | B | - |
| 13 | P | - |
| 14 | R | - |
| 15 | SB | - |
| 16 | R | - |
| 17 | R | - |
| 18 | P | - |
| 19 | P | - |
| 20 | LG | - |
| 21 | Y | - |
| 22 | BR | - |
| 23 | LG | - |

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

WW


FRONT WIPER AND WASHER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

FRONT WIPER AND WASHER SYSTEM

| | | | |
|----|----|--|---|
| 70 | B | - | - |
| 71 | P | - | - |
| 72 | LG | - | - |
| 73 | Y | - | - |
| 74 | R | - | - |
| 75 | P | - | - |
| 76 | L | - | - |
| 77 | BR | - | - |
| 79 | B | - | - |
| 80 | W | - | - |
| 81 | L | - | - |
| 82 | L | - | - |
| 83 | GR | - [Without automatic drive positioner] | - |
| 84 | W | - [With automatic drive positioner] | - |
| 85 | Y | - | - |
| 86 | W | - | - |
| 87 | R | - | - |
| 88 | G | - | - |
| 89 | B | - | - |
| 90 | V | - | - |
| 91 | G | - | - |
| 92 | BR | - | - |
| 93 | P | - | - |
| 94 | V | - | - |
| 95 | W | - | - |
| 96 | SB | - | - |
| 97 | L | - | - |
| 98 | LG | - | - |
| 99 | Y | - | - |

| | |
|----------------|--------------------|
| Connector No. | M103 |
| Connector Name | COMBINATION SWITCH |
| Connector Type | TH1BEW-NH |



H.S.

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | G | - |
| 2 | Y | OUTPUT 4 |
| 3 | BG | FR |
| 4 | W | IGN |

| | | |
|----|----|----------|
| 5 | V | OUTPUT 3 |
| 6 | B | GROUND |
| 7 | GR | INPUT 3 |
| 8 | L | OUTPUT 5 |
| 9 | SB | INPUT 2 |
| 10 | P | INPUT 4 |
| 11 | O | INPUT 1 |
| 12 | W | OUTPUT 1 |
| 13 | R | INPUT 5 |
| 14 | P | OUTPUT 2 |

| | |
|----------------|---------------------------|
| Connector No. | M118 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | M03FB-LC |



H.S.

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|---------------------------------|
| 1 | W | BAT (F/L) |
| 2 | GR | POWER WINDOW POWER SUPPLY (BAT) |
| 3 | L | POWER WINDOW POWER SUPPLY (IGN) |

| | |
|----------------|---------------------------|
| Connector No. | M119 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | NS1BFW-CS |



H.S.

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|------------------------------------|
| 4 | P/W | INTERIOR ROOM LAMP POWER SUPPLY |
| 5 | G | PASSENGER DOOR UNLOCK OUTPUT |
| 7 | W | STEP LAMP CONT |
| 8 | V | ALL DOOR FUEL LID LOCK OUTPUT |
| 9 | G | DRIVER DOOR FUEL LID UNLOCK OUTPUT |

| | | |
|----|----|-------------------------------------|
| 10 | P | REAR DOOR UNLOCK OUTPUT |
| 11 | LG | BAT (R/SE) |
| 13 | B | GROUND |
| 14 | O | PUSH-BUTTON ILLUMINATION SW ILL GND |
| 15 | L | ACC IND |
| 17 | G | TURN SIGNAL RH |
| 18 | BR | TURN SIGNAL LH |
| 19 | Y | INT ROOM LAMP CONT |

| | |
|----------------|---------------------------|
| Connector No. | M122 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | TH40FB-NH |



H.S.

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-------------------------------------|
| 72 | B | ROOM ANT- |
| 73 | W | ROOM ANT+ |
| 74 | Y | PASSENGER DOOR ANT- |
| 75 | LG | PASSENGER DOOR ANT+ |
| 76 | P | DRIVER DOOR ANT- |
| 77 | SB | DRIVER DOOR ANT+ |
| 80 | SB | NATS ANT AMP2 |
| 81 | O | NATS ANT AMP |
| 82 | BR | IGN RELAY (F/B) CONT |
| 83 | P | KEYLESS ENTRY RECEIVER COMM |
| 87 | R | COMBI SW INPUT 5 |
| 88 | GR | COMBI SW INPUT 3 |
| 90 | P | CAN-L |
| 91 | L | CAN-H |
| 92 | R | KEY SLOT ILL CONT |
| 93 | P | ON IND |
| 95 | L | ACC RELAY CONT |
| 96 | Y | CVT SHIFT SELECTOR POWER SUPPLY |
| 100 | P | PASSENGER DOOR REQUEST SW |
| 101 | W | DRIVER DOOR REQUEST SW |
| 102 | Y | BLOWER RELAY CONT |
| 103 | L | KEYLESS ENTRY RECEIVER POWER SUPPLY |
| 107 | O | COMBI SW INPUT 1 |
| 108 | P | COMBI SW INPUT 4 |
| 109 | SB | COMBI SW INPUT 2 |

| | | |
|-----|---|-----------|
| 110 | G | HAZARD SW |
|-----|---|-----------|



H.S.


| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|---------------------------------------|
| 112 | R | RAIN SENSOR SERIAL LINK |
| 113 | P/B | OPTICAL SENSOR |
| 116 | GR | STOP LAMP SW 1 |
| 118 | L | STOP LAMP SW 2 |
| 119 | W | DR DOOR UNLOCK SENSOR |
| 121 | Y | KEY SLOT SW |
| 123 | G | IGN F/B |
| 124 | R | PASSENGER DOOR SW |
| 130 | BR | REAR DEFOGGER SW |
| 132 | G | POWER WINDOW SW COMM |
| 133 | W | PUSH-BUTTON ILLUMINATION SW ILL POWER |
| 134 | P | REAR DEFOGGER SW |
| 137 | S | RECEIVER SENSOR GND |
| 138 | V | RECEIVER SENSOR POWER SUPPLY |
| 139 | O | THRE PRESS RECEIVER COMM |
| 140 | GR | SHIFT N/P |
| 141 | O | SECURITY IND LAMP CONT |
| 142 | L | COMBI SW OUTPUT 5 |
| 143 | W | COMBI SW OUTPUT 1 |
| 144 | P | COMBI SW OUTPUT 2 |
| 145 | V | COMBI SW OUTPUT 3 |
| 146 | Y | COMBI SW OUTPUT 4 |
| 150 | SB | DRIVER DOOR SW |
| 151 | G | REAR WINDOW DEFOGGER RELAY CONT |

FRONT WIPER AND WASHER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >


FRONT WIPER AND WASHER SYSTEM

| | |
|----------------|-----------------|
| Connector No. | M172 |
| Connector Name | AV CONTROL UNIT |
| Connector Type | TH24FW-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 36 | GR | SIGNAL VCC |
| 37 | GB | SIGNAL GND |
| 38 | G | UP |
| 39 | L | COMM (DISP- CONT) |
| 40 | W | RGB AREA(Y/S) SIGNAL |
| 41 | SHIELD | SHIELD |
| 42 | B | RGB SYNC |
| 43 | G | RGB (R/RED) SIGNAL |
| 44 | L | RGB (G/GREEN) SIGNAL |
| 45 | Y | RGB (B/BLUE) SIGNAL |
| 46 | W | -- |
| 47 | R | -- |
| 48 | Y | INVERTER VCC |
| 49 | BR | INVERTER GND |
| 50 | R | VP |
| 51 | G | -- |
| 52 | B | -- |
| 57 | SHIELD | SHIELD |
| 58 | B | -- |


| | |
|----------------|-----------------|
| Connector No. | M174 |
| Connector Name | AV CONTROL UNIT |
| Connector Type | TH33FW-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-------------------------------------|
| 76 | LG | AV COMM (L) |
| 77 | SB | AV COMM (H) |
| 78 | LG | AV COMM (L) |
| 79 | SB | AV COMM (H) |
| 80 | P | CAN-L |
| 81 | L | CAN-H |
| 82 | V | SW GND |
| 86 | SHIELD | SHIELD |
| 87 | R | TEL VOICE SIGNAL (+) |
| 88 | L | TEL VOICE SIGNAL (-) |
| 92 | V | VEHICLE SPEED SIGNAL (8-PULSE) |
| 93 | G | PARKING BRAKE (Without BOSE system) |
| 94 | SB | REVERSE |
| 95 | G | DISK SELECT SIGNAL |
| 96 | W | AUX SOUND SIGNAL GND |
| 102 | W | AUX SOUND SIGNAL LH (-) |
| 103 | B | AUX SOUND SIGNAL RH (+) |
| 104 | R | -- |




| | |
|----------------|-----------------|
| Connector No. | M180 |
| Connector Name | AV CONTROL UNIT |
| Connector Type | TH337FW-NH |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|--------------------------------|
| 65 | LG | PARKING BRAKE |
| 67 | L | -- |
| 68 | LG | SHIELD |
| 71 | SHIELD | SHIELD |
| 72 | B | MICROPHONE VCC |
| 73 | R | COMM (CONT- DISP) |
| 74 | L | CAN-L |
| 75 | LG | AV COMM (L) |
| 76 | LG | AV COMM (L) |
| 78 | R | ILLUMINATION SIGNAL |
| 80 | G | IGNITION |
| 81 | SB | REVERSE |
| 82 | V | VEHICLE SPEED SIGNAL (8-PULSE) |
| 83 | B | -- |

| | |
|----------------|-------------|
| Connector No. | R23 |
| Connector Name | RAIN SENSOR |
| Connector Type | A4B03FB |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | Y/R | -- |
| 2 | R | -- |
| 3 | B | -- |

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 87 | W | MICROPHONE SIGNAL |
| 88 | W | -- |
| 89 | L | CAN-H |
| 90 | L | CAN-H |
| 91 | SB | AV COMM (H) |
| 92 | SB | AV COMM (H) |



| | |
|----------------|--------------|
| Connector No. | R1 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH16FW-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|--------------------------------|
| 1 | R/W | -- [Without navigation system] |
| 2 | W | -- [With navigation system] |
| 2 | R/L | -- [Without navigation system] |
| 2 | SHIELD | -- [With navigation system] |
| 3 | B | -- |
| 4 | SHIELD | -- |
| 5 | Y/L | -- |
| 6 | B/L | -- |
| 8 | B/L | -- |
| 9 | B | -- |
| 10 | Y | -- |
| 11 | P/W | -- |
| 12 | B | -- |
| 13 | R/Y | -- |
| 15 | B/R | -- |
| 16 | R | -- |

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

WW


REAR WIPER AND WASHER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

REAR WIPER AND WASHER SYSTEM

Wiring Diagram - REAR WIPER AND WASHER SYSTEM -


INFOID:00000009719747



REAR WIPER AND WASHER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

◀WL▶ : With LDW
 ◀OL▶ : Without LDW



JRLWC2835GB

A
 B
 C
 D
 E
 F
 G
 H
 I
 J
 K
 L
 M
 N
 O
 P


WW

REAR WIPER AND WASHER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

REAR WIPER AND WASHER SYSTEM

| | |
|----------------|--------------|
| Connector No. | B11 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH8BMW-C519 |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | SHIELD | |
| 2 | R/L | |
| 3 | R/L | |
| 4 | R/W | |
| 6 | P | |
| 7 | V | |
| 8 | SHIELD | |
| 9 | BR/L | |
| 10 | Y/G | |
| 11 | Y/L | |
| 12 | W/L | |
| 13 | L | |
| 14 | BR | |
| 15 | SB | |
| 16 | SP | |
| 17 | V | |
| 18 | SB | |
| 19 | R | |
| 20 | P | |
| 21 | LG | |
| 22 | W | |
| 23 | Y | |
| 24 | GR | |
| 25 | Y | |
| 27 | V | |
| 28 | R | |
| 30 | P | |
| 31 | BR | |
| 32 | SB | |
| 35 | SHIELD | |
| 36 | LG | |
| 37 | LG | |
| 40 | Y | |
| 41 | GR | |

| | | |
|----|--------|--|
| 42 | G | |
| 46 | G | |
| 48 | LG | |
| 49 | SB | |
| 47 | R | |
| 48 | GR | |
| 48 | SHIELD | |
| 49 | B | |
| 49 | BR | |
| 50 | G | |
| 50 | R/W | |
| 51 | R | |
| 51 | R/L | |
| 52 | B | |
| 52 | LG | |
| 53 | BR | |
| 54 | BR | |
| 55 | P | |
| 56 | L | |
| 57 | L | |
| 58 | R | |
| 59 | R | |
| 59 | SHIELD | |
| 60 | B | |
| 60 | Y | |
| 61 | R/L | |
| 62 | R/W | |
| 63 | LG | |
| 64 | R | |
| 65 | GR | |
| 66 | L | |
| 66 | V | |
| 67 | G | |
| 67 | GR | |
| 68 | BR | |
| 68 | R | |
| 69 | SHIELD | |
| 70 | W/R | |
| 71 | B/R | |
| 72 | Y | |
| 73 | LG | |
| 74 | SB | |
| 75 | L | |
| 76 | G | |
| 77 | R | |
| 78 | B | |
| 80 | W | |
| 81 | R | |
| 82 | L | |

| | | |
|----|----|--|
| 83 | BR | |
| 84 | G | |
| 85 | G | |
| 86 | SB | |
| 87 | R | |
| 88 | G | |
| 89 | GR | |
| 90 | Y | |
| 91 | G | |
| 92 | BR | |
| 93 | G | |
| 94 | V | |
| 95 | BR | |
| 96 | GR | |
| 98 | LG | |
| 99 | O | |

| | |
|----------------|--------------|
| Connector No. | B78 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS1BMW-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | LG | |
| 2 | Y | |
| 3 | SB | |
| 5 | R | |
| 6 | V | |
| 8 | B | |
| 9 | L | |
| 10 | R | |
| 11 | W | |
| 12 | GR | |
| 13 | GR | |
| 14 | G | |
| 15 | Y | |
| 16 | BR | |

| | |
|----------------|--------------|
| Connector No. | B98 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH32BMW |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | G | |
| 2 | Y | |

| | |
|----------------|--------------|
| Connector No. | D153 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS1BMW-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | LG | |
| 2 | W | |
| 3 | V | |
| 5 | R | |
| 6 | V | |
| 8 | B | |
| 9 | L | |
| 10 | R | |
| 11 | O | |
| 12 | W | |
| 13 | GR | |
| 14 | G | |
| 15 | O | |
| 16 | BR | |

REAR WIPER AND WASHER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

REAR WIPER AND WASHER SYSTEM

| | |
|----------------|---------------------------------|
| Connector No. | D187 |
| Connector Name | WASHER SWITCHING SOLENOID VALVE |
| Connector Type | TR02FW-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 2 | Y | - |
| 3 | G | - |

| | |
|----------------|--------------|
| Connector No. | D171 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TR02FW |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | G | - |
| 2 | Y | - |

| | |
|----------------|------------------|
| Connector No. | D183 |
| Connector Name | REAR WIPER MOTOR |
| Connector Type | C-044FW-1V |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | G | - |
| 3 | GR | - |
| 4 | G | - |

| | |
|----------------|--------------|
| Connector No. | EB |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS12M8R-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 3 | GR | - |
| 4 | SB | - |
| 5 | O | - |
| 8 | G | - |
| 9 | W | - |
| 10 | Y | - |
| 11 | G | - |

| | |
|----------------|--------------|
| Connector No. | E26 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS32M4-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | GR | - |
| 2 | Y | - |

| | |
|----------------|---------------------------------|
| Connector No. | E28 |
| Connector Name | REAR VIEW CAMERA WASHER RELAY 2 |
| Connector Type | MS30FB-M2-LC |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W | - |
| 2 | L | - |
| 3 | GR | - |
| 4 | GR | - |
| 5 | W | - |

| | |
|----------------|---------------------------------|
| Connector No. | E28 |
| Connector Name | REAR VIEW CAMERA WASHER RELAY 1 |
| Connector Type | MS30FB-M2-LC |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W | - |
| 2 | W | - |
| 3 | R | - |
| 4 | O | - |
| 5 | B | - |

| | |
|----------------|----------------|
| Connector No. | E105 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH7DMV-C51D-M3 |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 3 | Y | - |
| 5 | LG | - |
| 6 | GR | - |
| 8 | G | - |
| 11 | P | - |
| 12 | L | - |
| 13 | Y | - |
| 14 | O | - |
| 15 | BN | - |
| 20 | Y | - |
| 21 | BR | - |
| 22 | P | - |
| 24 | L | - |
| 25 | O | - |
| 26 | SB | - |

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

WW

REAR WIPER AND WASHER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

REAR WIPER AND WASHER SYSTEM


| | | | | | |
|----|--------|--|--|--|--|
| 37 | W | | | | |
| 38 | R | | | | |
| 39 | L | | | | |
| 40 | B | | | | |
| 47 | P | | | | |
| 48 | L | | | | |
| 49 | SB | | | | |
| 50 | GR | | | | |
| 51 | LG | | | | |
| 52 | V | | | | |
| 53 | GR | | | | |
| 54 | BR | | | | |
| 55 | Y | | | | |
| 56 | W | | | | |
| 57 | L | | | | |
| 61 | BR | | | | |
| 62 | O | | | | |
| 63 | L/O | | | | |
| 64 | SHIELD | | | | |
| 66 | W | | | | |
| 67 | BR | | | | |
| 68 | Y | | | | |
| 69 | SB | | | | |
| 70 | GR | | | | |
| 71 | SB | | | | |
| 72 | Y | | | | |
| 73 | L | | | | |
| 74 | BR | | | | |
| 75 | BR | | | | |
| 76 | GR | | | | |
| 77 | O | | | | |
| 78 | G | | | | |
| 78 | V | | | | |
| 78 | Y | | | | |
| 79 | Y | | | | |
| 80 | R | | | | |
| 81 | W | | | | |
| 82 | LG | | | | |
| 83 | O | | | | |

| | |
|----------------|-------------|
| Connector No. | E522 |
| Connector Name | WASHER PUMP |
| Connector Type | EDGEY-RS |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | O | |
| 2 | G | |

| | |
|----------------|--------------|
| Connector No. | E339 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS1ZFBR-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 3 | O | |
| 4 | G | |
| 5 | O | |
| 8 | G | |
| 9 | W | |
| 10 | Y | |
| 11 | R | |

| | |
|----------------|--|
| Connector No. | E525 |
| Connector Name | INTELLIGENT POWER DISTRIBUTION MODULE FUSE |
| Connector Type | NSBFW-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 84 | L | |
| 86 | SB | |
| 87 | GR | |
| 88 | W | |
| 89 | L | |
| 90 | G | |

| | |
|----------------|------------------|
| Connector No. | M1 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | NSBFW-M2 |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1A | Y | |
| 2A | G | |
| 3A | Y | |
| 4A | GR | |
| 5A | LG | |
| 6A | Y | |

| | |
|----------------|---------------------|
| Connector No. | M4 |
| Connector Name | DATA LINK CONNECTOR |
| Connector Type | BDBFW |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 3 | LG | |
| 5 | B | |
| 6 | L | |
| 7 | BR | |
| 8 | G | |
| 11 | SB | |
| 14 | P | |
| 15 | Y | |

| | |
|----------------|----------------|
| Connector No. | M11 |
| Connector Name | WIRE TO WIRE |
| Connector Type | T17BFR-CS/B-M3 |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 3 | P | |
| 5 | BR | |
| 8 | O | |
| 9 | G | |
| 11 | P | |
| 12 | L | |
| 13 | V | |
| 14 | Y | |
| 15 | R | |
| 20 | W | [Without colour display] |

JRLWC9479GB

REAR WIPER AND WASHER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

REAR WIPER AND WASHER SYSTEM


| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 20 | Y | |
| 21 | BR | |
| 22 | LG | |
| 23 | LS | |
| 24 | Y | |
| 25 | Y | |
| 26 | BR | |
| 27 | L | |
| 28 | R | |
| 29 | L | |
| 30 | R | |
| 31 | W | |
| 32 | BR | |
| 33 | Y | |
| 34 | Y | |
| 35 | B | |
| 36 | G | |
| 37 | G | |
| 38 | LS | |
| 39 | Y | |
| 40 | LS | |
| 41 | LS | |
| 42 | LS | |
| 43 | LS | |
| 44 | LS | |
| 45 | LS | |
| 46 | LG | |
| 47 | Y | |
| 48 | GR | |
| 49 | BR | |
| 50 | LG | |
| 51 | Y | |
| 52 | B | |
| 53 | BR | |
| 54 | B | |
| 55 | G | |
| 56 | P | |
| 57 | L | |
| 58 | W | |
| 59 | BR | |
| 60 | R | |
| 61 | W | |
| 62 | GR | |
| 63 | Y | |
| 64 | SHIELD | |
| 65 | W | |
| 66 | W | |
| 67 | R | |
| 68 | W | |
| 69 | W | |
| 70 | C | |
| 71 | G | |
| 72 | BR | |
| 73 | L | |
| 74 | W | |
| 75 | BR | |
| 76 | R | |
| 77 | G | |
| 78 | Y | |
| 79 | G | |
| 80 | R | |
| 81 | W | |
| 82 | W | |
| 83 | BG | |

| | |
|----------------|--------------|
| Connector No. | M26 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS32FW-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | G | |
| 2 | Y | |

| | |
|----------------|--------------|
| Connector No. | M77 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80FW-CS19 |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | SHIELD | |
| 2 | B | |
| 3 | W | |
| 4 | R | |
| 5 | W | |
| 6 | W | |
| 7 | G | |
| 8 | SHIELD | |
| 9 | W | |
| 10 | R | |
| 11 | G | |
| 12 | B | |
| 13 | W | |
| 14 | R | |
| 15 | SB | |
| 16 | R | |
| 17 | V | |
| 18 | P | |
| 19 | P | |

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 67 | W | |
| 68 | CG | |
| 69 | SHIELD | |
| 70 | SHIELD | |
| 71 | P | |
| 72 | LG | |
| 73 | Y | |
| 74 | R | |
| 75 | P | |
| 76 | L | |
| 77 | BR | |
| 78 | W | |
| 79 | B | |
| 80 | W | |
| 81 | L | |
| 82 | GR | |
| 83 | WR | |
| 84 | R | |
| 85 | V | |
| 86 | W | |
| 87 | R | |
| 88 | G | |
| 89 | B | |
| 90 | V | |
| 91 | G | |
| 92 | BR | |
| 93 | P | |
| 94 | V | |
| 95 | V | |
| 96 | SB | |
| 97 | LG | |
| 98 | LG | |
| 99 | Y | |

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 20 | Y | |
| 21 | BR | |
| 22 | LG | |
| 23 | LS | |
| 24 | Y | |
| 25 | Y | |
| 26 | BR | |
| 27 | L | |
| 28 | R | |
| 29 | L | |
| 30 | R | |
| 31 | W | |
| 32 | BR | |
| 33 | Y | |
| 34 | Y | |
| 35 | B | |
| 36 | G | |
| 37 | G | |
| 38 | LS | |
| 39 | Y | |
| 40 | LS | |
| 41 | LS | |
| 42 | LS | |
| 43 | LS | |
| 44 | LS | |
| 45 | LS | |
| 46 | LG | |
| 47 | Y | |
| 48 | GR | |
| 49 | BR | |
| 50 | LG | |
| 51 | Y | |
| 52 | B | |
| 53 | BR | |
| 54 | B | |
| 55 | G | |
| 56 | P | |
| 57 | L | |
| 58 | W | |
| 59 | BR | |
| 60 | R | |
| 61 | W | |
| 62 | GR | |
| 63 | Y | |
| 64 | SHIELD | |
| 65 | W | |
| 66 | W | |
| 67 | R | |
| 68 | W | |
| 69 | W | |
| 70 | C | |
| 71 | G | |
| 72 | BR | |
| 73 | L | |
| 74 | W | |
| 75 | BR | |
| 76 | R | |
| 77 | G | |
| 78 | Y | |
| 79 | G | |
| 80 | R | |
| 81 | W | |
| 82 | W | |
| 83 | BG | |

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

WW


JRLWC9480GB

REAR WIPER AND WASHER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

REAR WIPER AND WASHER SYSTEM

| | |
|----------------|--------------------|
| Connector No. | M103 |
| Connector Name | COMBINATION SWITCH |
| Connector Type | TH18FW-NH |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | G | IGN |
| 2 | W | IGN |
| 3 | EG | OUTPUT 4 |
| 4 | W | IGN |
| 5 | V | OUTPUT 3 |
| 6 | B | GROUND |
| 7 | GR | INPUT 3 |
| 8 | L | OUTPUT 5 |
| 9 | SB | INPUT 2 |
| 10 | P | INPUT 4 |
| 11 | O | INPUT 1 |
| 12 | W | OUTPUT 1 |
| 13 | R | INPUT 5 |
| 14 | P | OUTPUT 2 |

| | |
|----------------|---------------------------|
| Connector No. | M118 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | M03FB-LC |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|---------------------------------|
| 1 | W | BAT (E/L) |
| 2 | GR | POWER WINDOW POWER SUPPLY (BAT) |
| 3 | L | POWER WINDOW POWER SUPPLY (IGN) |

| | |
|----------------|---------------------------|
| Connector No. | M119 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | NS18FW-CS |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|------------------------------------|
| 1 | W | INTERIOR ROOM LAMP POWER SUPPLY |
| 2 | O | PASSENGER DOOR UNLOCK OUTPUT |
| 3 | W | STEER LAMP CONT |
| 4 | V | ALL DOOR FUEL LID LOCK OUTPUT |
| 5 | G | DRIVER DOOR FUEL LID UNLOCK OUTPUT |
| 6 | P | REAR DOOR UNLOCK OUTPUT |
| 7 | LG | BAT (FUSE) |
| 8 | B | GROUND |
| 9 | L | ACC IND |
| 10 | O | PUSH-BUTTON IGNITION SW ILL GND |
| 11 | L | TURN SIGNAL RH |
| 12 | G | TURN SIGNAL LH |
| 13 | BR | INT ROOM LAMP CONT |
| 14 | Y | |
| 15 | L | |
| 16 | W | |
| 17 | G | |
| 18 | BR | |
| 19 | Y | |

| | |
|----------------|---------------------------|
| Connector No. | M120 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | NS12FW-CS |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 23 | BR | BACK DOOR GREEN OUTPUT |
| 26 | G | REAR WIPER OUTPUT |

| | |
|----------------|---------------------------|
| Connector No. | M121 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | TH46FY-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 34 | W | LUGGAGE ROOM ANT- |
| 35 | R | LUGGAGE ROOM ANT+ |
| 38 | L | REAR BUMPER ANT- |
| 39 | BR | REAR BUMPER ANT+ |
| 47 | L | IGN RELAY (F/DM) CONT |
| 52 | L | STARTER RELAY CONT |
| 60 | BR | PUSH SW |
| 61 | R | BACK DOOR OPENER REQUEST SW |
| 64 | GR | I-KEY WARN BLUZZER |
| 65 | O | REAR WIPER STOP POSITION |
| 66 | Y | BACK DOOR SW |
| 67 | LG | BACK DOOR OPENER SW |
| 68 | W | REAR RH DOOR SW |
| 69 | R | REAR LH DOOR SW |


| | |
|----------------|---------------------------|
| Connector No. | M122 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | TH40FB-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 72 | B | ROOM ANT- |
| 73 | W | ROOM ANT+ |
| 74 | Y | PASSENGER DOOR ANT- |
| 75 | LG | PASSENGER DOOR ANT+ |
| 76 | V | DRIVER DOOR ANT- |
| 77 | P | DRIVER DOOR ANT+ |

| | | |
|-----|----|-------------------------------------|
| 80 | SB | MATS ANT AMP |
| 81 | G | MATS ANT AMP |
| 82 | BR | IGN RELAY (E/B) CONT |
| 83 | P | KEYLESS ENTRY RECEIVER COMM |
| 87 | R | COMBI SW INPUT 5 |
| 88 | GR | COMBI SW INPUT 3 |
| 90 | P | CAN-L |
| 91 | L | CAN-H |
| 92 | R | KEY SLOT ILL CONT |
| 93 | P | ON IND |
| 95 | L | ACC RELAY CONT |
| 96 | Y | CVT SHIFT SELECTOR POWER SUPPLY |
| 99 | V | SHIFT P |
| 100 | P | PASSENGER DOOR REQUEST SW |
| 101 | W | DRIVER DOOR REQUEST SW |
| 102 | L | BLUZZER RELAY CONT |
| 103 | L | KEYLESS ENTRY RECEIVER POWER SUPPLY |
| 107 | O | COMBI SW INPUT 1 |
| 108 | P | COMBI SW INPUT 4 |
| 109 | SB | COMBI SW INPUT 2 |
| 110 | G | HAZARD SW |

| | |
|----------------|---------------------------|
| Connector No. | M123 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | TH46FC-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------------|
| 112 | R | RAIN SENSOR SERIAL LINK |
| 113 | P/B | OPTICAL SENSOR |
| 116 | GR | STOP LAMP SW 1 |
| 118 | L | STOP LAMP SW 2 |
| 119 | W | DR DOOR UNLOCK SENSOR |
| 120 | G | REAR SW |
| 121 | G | IGN F/EA |
| 124 | R | PASSENGER DOOR SW |
| 130 | BR | REAR DEFROGGER SW |
| 132 | G | POWER WINDOW SW GNDM |
| 133 | W | PUSH-BUTTON IGNITION SW ILL POWER |
| 134 | R | LOCK IND |
| 137 | P | RECEIVER/SENSOR GND |

REAR WIPER AND WASHER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

REAR WIPER AND WASHER SYSTEM

| | | |
|-----|----|----------------------------------|
| 138 | V | REAR WIPER POWER SUPPLY |
| 139 | GR | REAR WIPER COMB |
| 140 | GR | TIRE PRESS. DET. 2 |
| 141 | O | SECURITY IND. LAMP CONT. |
| 142 | O | COMB. SW. OUTPUT 5 |
| 143 | W | COMB. SW. OUTPUT 1 |
| 144 | P | COMB. SW. OUTPUT 2 |
| 145 | V | COMB. SW. OUTPUT 3 |
| 146 | Y | COMB. SW. OUTPUT 4 |
| 150 | SB | DRIVER DOOR SW. |
| 151 | G | REAR WINDOW DEFOGGER RELAY CONT. |

WW

JRLWC9482GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION

BCM (BODY CONTROL MODULE)

Reference Value

INFOID:000000010129278

VALUES ON THE DIAGNOSIS TOOL

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

CONSULT MONITOR ITEM

| Monitor Item | Condition | Value/Status |
|----------------|---|----------------------------------|
| FR WIPER HI | Other than front wiper switch HI | Off |
| | Front wiper switch HI | On |
| FR WIPER LOW | Other than front wiper switch LO | Off |
| | Front wiper switch LO | On |
| FR WASHER SW | Front washer switch OFF | Off |
| | Front washer switch ON | On |
| FR WIPER INT | Other than front wiper switch INT/AUTO | Off |
| | Front wiper switch INT/AUTO | On |
| FR WIPER STOP | Front wiper is not in STOP position | Off |
| | Front wiper is in STOP position | On |
| INT VOLUME | Wiper intermittent dial is in a dial position 1 - 7 | Wiper intermittent dial position |
| RR WIPER ON | Other than rear wiper switch ON | Off |
| | Rear wiper switch ON | On |
| RR WIPER INT | Other than rear wiper switch INT | Off |
| | Rear wiper switch INT | On |
| RR WASHER SW | Rear washer switch OFF | Off |
| | Rear washer switch ON | On |
| RR WIPER STOP | Rear wiper is in STOP position | Off |
| | Rear wiper is not in STOP position | On |
| TURN SIGNAL R | Other than turn signal switch RH | Off |
| | Turn signal switch RH | On |
| TURN SIGNAL L | Other than turn signal switch LH | Off |
| | Turn signal switch LH | On |
| TAIL LAMP SW | Other than lighting switch 1ST and 2ND | Off |
| | Lighting switch 1ST or 2ND | On |
| HI BEAM SW | Other than lighting switch HI | Off |
| | Lighting switch HI | On |
| HEAD LAMP SW 1 | Other than lighting switch 2ND | Off |
| | Lighting switch 2ND | On |
| HEAD LAMP SW 2 | Other than lighting switch 2ND | Off |
| | Lighting switch 2ND | On |
| PASSING SW | Other than lighting switch PASS | Off |
| | Lighting switch PASS | On |
| AUTO LIGHT SW | Other than lighting switch AUTO | Off |
| | Lighting switch AUTO | On |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Monitor Item | Condition | Value/Status | |
|---|---|--------------|----|
| FR FOG SW | Front fog lamp switch OFF | Off | A |
| | Front fog lamp switch ON | On | |
| RR FOG SW | NOTE: The item is indicated, but not monitored. | Off | B |
| DOOR SW-DR | Driver door closed | Off | C |
| | Driver door opened | On | |
| DOOR SW-AS | Passenger door closed | Off | D |
| | Passenger door opened | On | |
| DOOR SW-RR | Rear RH door closed | Off | E |
| | Rear RH door opened | On | |
| DOOR SW-RL | Rear LH door closed | Off | F |
| | Rear LH door opened | On | |
| DOOR SW-BK | Back door closed | Off | G |
| | Back door opened | On | |
| CDL LOCK SW | Other than power door lock switch LOCK | Off | H |
| | Power door lock switch LOCK | On | |
| CDL UNLOCK SW | Other than power door lock switch UNLOCK | Off | I |
| | Power door lock switch UNLOCK | On | |
| KEY CYL LK-SW | Other than driver door key cylinder LOCK position | Off | J |
| | Driver door key cylinder LOCK position | On | |
| KEY CYL UN-SW | Other than driver door key cylinder UNLOCK position | Off | K |
| | Driver door key cylinder UNLOCK position | On | |
| KEY CYL SW-TR | NOTE: The item is indicated, but not monitored. | Off | |
| HAZARD SW | Hazard switch is OFF | Off | WW |
| | Hazard switch is ON | On | |
| REAR DEF SW NOTE: For models with BOSE audio system this item is not monitored. | Rear window defogger switch OFF | Off | M |
| | Rear window defogger switch ON | On | |
| TR CANCEL SW | NOTE: The item is indicated, but not monitored. | Off | |
| TR/BD OPEN SW | Back door opener switch OFF | Off | N |
| | While the back door opener switch is turned ON | On | |
| TRNK/HAT MNTR | NOTE: The item is indicated, but not monitored. | Off | |
| RKE-LOCK | LOCK button of Intelligent Key is not pressed | Off | O |
| | LOCK button of Intelligent Key is pressed | On | |
| RKE-UNLOCK | UNLOCK button of Intelligent Key is not pressed | Off | P |
| | UNLOCK button of Intelligent Key is pressed | On | |
| RKE-TR/BD | BACK DOOR OPEN button of Intelligent Key is not pressed | Off | |
| | BACK DOOR OPEN button of Intelligent Key is pressed | On | |
| RKE-PANIC | PANIC button of Intelligent Key is not pressed | Off | |
| | PANIC button of Intelligent Key is pressed | On | |
| RKE-P/W OPEN | UNLOCK button of Intelligent Key is not pressed | Off | |
| | UNLOCK button of Intelligent Key is pressed and held | On | |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Monitor Item | Condition | Value/Status |
|----------------|--|--------------|
| RKE-MODE CHG | LOCK/UNLOCK button of Intelligent Key is not pressed and held simultaneously | Off |
| | LOCK/UNLOCK button of Intelligent Key is pressed and held simultaneously | On |
| OPTICAL SENSOR | Bright outside of the vehicle | Close to 5 V |
| | Dark outside of the vehicle | Close to 0 V |
| REQ SW -DR | Driver door request switch is not pressed | Off |
| | Driver door request switch is pressed | On |
| REQ SW -AS | Passenger door request switch is not pressed | Off |
| | Passenger door request switch is pressed | On |
| REQ SW -RR | NOTE: The item is indicated, but not monitored. | Off |
| REQ SW -RR | NOTE: The item is indicated, but not monitored. | Off |
| REQ SW -BD/TR | Back door request switch is not pressed | Off |
| | Back door request switch is pressed | On |
| PUSH SW | Push-button ignition switch (push switch) is not pressed | Off |
| | Push-button ignition switch (push switch) is pressed | On |
| IGN RLY2 -F/B | Ignition switch in OFF or ACC position | Off |
| | Ignition switch in ON position | On |
| ACC RLY -F/B | NOTE: The item is indicated, but not monitored. | Off |
| CLUCH SW | NOTE: The item is indicated, but not monitored. | Off |
| BRAKE SW 1 | The brake pedal is depressed when No. 7 fuse is blown | Off |
| | The brake pedal is not depressed when No. 7 fuse is blown, or No. 7 fuse is normal | On |
| BRAKE SW 2 | The brake pedal is not depressed | Off |
| | Stop lamp switch 1 signal circuit is normal | On |
| DETE/CANCL SW | Selector lever in P position | Off |
| | Selector lever in any position other than P | On |
| SFT PN/N SW | Selector lever in any position other than P and N | Off |
| | Selector lever in P or N position | On |
| S/L -LOCK | NOTE: The item is indicated, but not monitored. | Off |
| S/L -UNLOCK | NOTE: The item is indicated, but not monitored. | Off |
| S/L RELAY-F/B | NOTE: The item is indicated, but not monitored. | Off |
| UNLK SEN -DR | Driver door is unlocked | Off |
| | Driver door is locked | On |
| PUSH SW -IPDM | Push-button ignition switch (push-switch) is not pressed | Off |
| | Push-button ignition switch (push-switch) is pressed | On |
| IGN RLY1 -F/B | Ignition switch in OFF or ACC position | Off |
| | Ignition switch in ON position | On |
| DETE SW -IPDM | Selector lever in any position other than P | Off |
| | Selector lever in P position | On |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Monitor Item | Condition | Value/Status | |
|----------------|---|--|----|
| SFT PN -IPDM | Selector lever in any position other than P and N | Off | A |
| | Selector lever in P or N position | On | |
| SFT P -MET | Selector lever in any position other than P | Off | B |
| | Selector lever in P position | On | |
| SFT N -MET | Selector lever in any position other than N | Off | C |
| | Selector lever in N position | On | |
| ENGINE STATE | Engine stopped | Stop | |
| | While the engine stalls | Stall | D |
| | At engine cranking | Crank | |
| | Engine running | Run | |
| S/L LOCK-IPDM | NOTE: The item is indicated, but not monitored. | Off | E |
| S/L UNLK-IPDM | NOTE: The item is indicated, but not monitored. | Off | F |
| S/L RELAY-REQ | NOTE: The item is indicated, but not monitored. | Off | |
| VEH SPEED 1 | While driving | Equivalent to speedometer reading | G |
| VEH SPEED 2 | While driving | Equivalent to speedometer reading | H |
| DOOR STAT-DR | Driver door is locked | LOCK | |
| | Wait with selective UNLOCK operation (5 seconds) | READY | I |
| | Driver door is unlocked | UNLOCK | |
| DOOR STAT-AS | Passenger door is locked | LOCK | |
| | Wait with selective UNLOCK operation (5 seconds) | READY | J |
| | Passenger door is unlocked | UNLOCK | |
| ID OK FLAG | Power supply position in LOCK position | Reset | |
| | Power supply position in any position other than LOCK | Set | K |
| PRMT ENG STRT | The engine start is prohibited | Reset | |
| | The engine start is permitted | Set | WW |
| PRMT RKE STRT | NOTE: The item is indicated, but not monitored. | Reset | |
| KEY SW -SLOT | Intelligent Key is not inserted into key slot | Off | M |
| | Intelligent Key is inserted into key slot | On | |
| RKE OPE COUN1 | During the operation of Intelligent Key | Operation frequency of Intelligent Key | N |
| RKE OPE COUN2 | NOTE: The item is indicated, but not monitored. | — | |
| CONFIRM ID ALL | The Intelligent Key ID that the key slot receives is not recognized by any Intelligent Key ID registered to BCM. | Yet | O |
| | The Intelligent Key ID that the key slot receives is recognized by any Intelligent Key ID registered to BCM. | Done | P |
| CONFIRM ID4 | The Intelligent Key ID that the key slot receives is not recognized by the fourth Intelligent Key ID registered to BCM. | Yet | |
| | The Intelligent Key ID that the key slot receives is recognized by the fourth Intelligent Key ID registered to BCM. | Done | |

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >

| Monitor Item | Condition | Value/Status |
|--------------|---|-------------------------------|
| CONFIRM ID3 | The Intelligent Key ID that the key slot receives is not recognized by the third Intelligent Key ID registered to BCM. | Yet |
| | The Intelligent Key ID that the key slot receives is recognized by the third Intelligent Key ID registered to BCM. | Done |
| CONFIRM ID2 | The Intelligent Key ID that the key slot receives is not recognized by the second Intelligent Key ID registered to BCM. | Yet |
| | The Intelligent Key ID that the key slot receives is recognized by the second Intelligent Key ID registered to BCM. | Done |
| CONFIRM ID1 | The Intelligent Key ID that the key slot receives is not recognized by the first Intelligent Key ID registered to BCM. | Yet |
| | The Intelligent Key ID that the key slot receives is recognized by the first Intelligent Key ID registered to BCM. | Done |
| TP 4 | The ID of fourth Intelligent Key is not registered to BCM | Yet |
| | The ID of fourth Intelligent Key is registered to BCM | Done |
| TP 3 | The ID of third Intelligent Key is not registered to BCM | Yet |
| | The ID of third Intelligent Key is registered to BCM | Done |
| TP 2 | The ID of second Intelligent Key is not registered to BCM | Yet |
| | The ID of second Intelligent Key is registered to BCM | Done |
| TP 1 | The ID of first Intelligent Key is not registered to BCM | Yet |
| | The ID of first Intelligent Key is registered to BCM | Done |
| AIR PRESS FL | Ignition switch ON (Only when the signal from the transmitter is received) | Air pressure of front LH tire |
| AIR PRESS FR | Ignition switch ON (Only when the signal from the transmitter is received) | Air pressure of front RH tire |
| AIR PRESS RR | Ignition switch ON (Only when the signal from the transmitter is received) | Air pressure of rear RH tire |
| AIR PRESS RL | Ignition switch ON (Only when the signal from the transmitter is received) | Air pressure of rear LH tire |
| ID REGST FL1 | ID of front LH tire transmitter is registered | Done |
| | ID of front LH tire transmitter is not registered | Yet |
| ID REGST FR1 | ID of front RH tire transmitter is registered | Done |
| | ID of front RH tire transmitter is not registered | Yet |
| ID REGST RR1 | ID of rear RH tire transmitter is registered | Done |
| | ID of rear RH tire transmitter is not registered | Yet |
| ID REGST RL1 | ID of rear LH tire transmitter is registered | Done |
| | ID of rear LH tire transmitter is not registered | Yet |
| WARNING LAMP | Tire pressure indicator OFF | Off |
| | Tire pressure indicator ON | On |
| BUZZER | Tire pressure warning alarm is not sounding | Off |
| | Tire pressure warning alarm is sounding | On |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


TERMINAL LAYOUT



PHYSICAL VALUES





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|---|------------------|---|--|--|
| | | Signal name | Input/ Output | | | |
| + | - | | | | | |
| 1 (W) | Ground | Battery power supply | Input | Ignition switch OFF | | Battery voltage |
| 2 (GR) | Ground | P/W power supply (BAT) | Output | Ignition switch OFF | | Battery voltage |
| 3 (L) | Ground | P/W power supply (IGN) | Output | Ignition switch ON | | Battery voltage |
| 4 (P/W) | Ground | Interior room lamp power supply | Output | Interior room lamp battery saver is activated. (Cuts the interior room lamp power supply) | | 0 V |
| | | | | Interior room lamp battery saver is not activated. (Outputs the interior room lamp power supply) | | Battery voltage |
| 5 (G) | Ground | Passenger door UN- LOCK | Output | Passenger door | UNLOCK (Actuator is activated) | Battery voltage |
| | | | | | Other than UNLOCK (Actuator is not activated) | 0 V |
| 7 (W) | Ground | Step lamp control | Output | Step lamp | ON | 0 V |
| | | | | | OFF | Battery voltage |
| 8 (V) | Ground | All doors LOCK | Output | All doors | LOCK (Actuator is activated) | Battery voltage |
| | | | | | Other than LOCK (Actuator is not activated) | 0 V |
| 9 (G) | Ground | Driver door UNLOCK | Output | Driver door | UNLOCK (Actuator is activated) | Battery voltage |
| | | | | | Other than UNLOCK (Actuator is not activated) | 0 V |
| 10 (P) | Ground | Rear RH door and rear LH door UN- LOCK | Output | Rear RH door and rear LH door | UNLOCK (Actuator is activated) | Battery voltage |
| | | | | | Other than UNLOCK (Actuator is not activated) | 0 V |
| 11 (LG) | Ground | Battery power supply | Input | Ignition switch OFF | | Battery voltage |
| 13 (B) | Ground | Ground | — | Ignition switch ON | | 0 V |
| 14 (O) | Ground | Push-button ignition switch illumination ground | Output | Tail lamp | OFF | 0 V |
| | | | | | ON | <p>NOTE: When the illumination brightening/dimming level is in the neutral position</p>  <p style="text-align: right; font-size: small;">JSNIA0010GB</p> |
| 15 (L) | Ground | ACC indicator lamp | Output | Ignition switch | OFF (LOCK and ON indicator lamps are not illuminated.) | Battery voltage |
| | | | | | ACC | 0 V |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|----------------------------|------------------|--|--|-----------------|
| + | - | Signal name | Input/ Output | | | |
| 17 (G) | Ground | Turn signal RH | Output | Turn signal switch OFF | 0 V | |
| | | | | Turn signal switch ON |  6.5 V | |
| 18 (BR) | Ground | Turn signal LH | Output | Turn signal switch OFF | 0 V | |
| | | | | Turn signal switch ON |  6.5 V | |
| 19 (Y) | Ground | Interior room lamp control | Output | Interior room lamp | OFF | Battery voltage |
| | | | | ON | 0 V | |
| 23 (BR) | Ground | Back door open | Output | Back door | OPEN (Back door opener actuator is activated) | Battery voltage |
| | | | | Other than OPEN (Back door opener actuator is not activated) | 0 V | |
| 26 (G) | Ground | Rear wiper | Output | Rear wiper | OFF (Stopped) | 0 V |
| | | | | ON (Operated) | Battery voltage | |
| 34 (B) | Ground | Luggage room antenna (-) | Output | Ignition switch OFF |  | |
| | | | | When Intelligent Key is not in the passenger compartment |  | |

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

WW





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|-----------------------------------|------------------|--|--------------------|
| + | - | Signal name | Input/ Output | | |
| 35 (W) | Ground | Luggage room antenna (+) | Output | Ignition switch OFF | |
| | | | | When Intelligent Key is not in the passenger compartment | |
| 38 (L) | Ground | Rear bumper antenna (-) | Output | When the back door request switch is operated with ignition switch OFF | |
| | | | | When Intelligent Key is not in the antenna detection area | |
| 39 (BR) | Ground | Rear bumper antenna (+) | Output | When the back door request switch is operated with ignition switch OFF | |
| | | | | When Intelligent Key is not in the antenna detection area | |
| 47 (L) | Ground | Ignition relay (IPDM E/R) control | Output | Ignition switch | Battery voltage |
| | | | | OFF or ACC | 0 V |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >




| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|--|------------------|---|--|---|
| | | Signal name | Input/ Output | | | |
| + | - | | | | | |
| 52 (R) | Ground | Starter relay control | Output | Ignition switch ON | When selector lever is in P or N position | Battery voltage |
| | | | | | When selector lever is not in P or N position | 0.3 V |
| | | | | Ignition switch OFF | | 0 V |
| 60 (BR) | Ground | Push-button ignition switch (push switch) | Input | Push-button igni- tion switch (push switch) | Pressed | 0 V |
| | | | | | Not pressed | Battery voltage |
| 61 (R) | Ground | Back door request switch | Input | Back door re- quest switch | ON (Pressed) | 0 V |
| | | | | | OFF (Not pressed) |  1.0 V |
| 64 (GR) | Ground | Intelligent key warn- ing buzzer control | Output | Warning buzzer | Sounding | 0 V |
| | | | | | Not sounding | Battery voltage |
| 65 (O) | Ground | Rear wiper stop posi- tion | Input | Rear wiper | In stop position |  1.0 V |
| | | | | | Not in stop position | 0 V |
| 66 (Y) | Ground | Back door switch | Input | Back door switch | OFF (When back door closes) |  11.8 V |
| | | | | | ON (When back door opens) | 0 V |
| 67 (LG) | Ground | Back door opener switch | Input | Back door opener switch | Pressed | 0 V |
| | | | | | Not pressed |  11.8 V |

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

WW






BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|--------------------------------------|------------------|--|---|
| + | - | Signal name | Input/ Output | | |
| 68 (W) | Ground | Rear RH door switch | Input | Rear RH door switch |  <p style="text-align: right; font-size: small;">JPMIA0011GB</p> <p style="text-align: center;">11.8 V</p> |
| | | | | OFF (When rear RH door closes) | ON (When rear RH door opens) |
| 69 (R) | Ground | Rear LH door switch | Input | Rear LH door switch |  <p style="text-align: right; font-size: small;">JPMIA0011GB</p> <p style="text-align: center;">11.8 V</p> |
| | | | | OFF (When rear LH door closes) | ON (When rear LH door opens) |
| 72 (B) | Ground | Room antenna (-) (Center console) | Output | Ignition switch OFF |  <p style="text-align: right; font-size: small;">JMKIA0062GB</p> |
| | | | | When Intelligent Key is in the passenger compartment | When Intelligent Key is not in the passenger compartment |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|--------------------------------------|------------------|---|---|
| + | - | Signal name | Input/ Output | | |
| 73 (W) | Ground | Room antenna (+) (Center console) | Output | | |
| | | | | When Intelligent Key is not in the passenger compart- ment |  <p style="text-align: right; font-size: small;">JMKIA0063GB</p> |
| 74 (Y) | Ground | Passenger door an- tenna (-) | Output | When the pas- senger door re- quest switch is operated with ig- nition switch OFF |  <p style="text-align: right; font-size: small;">JMKIA0062GB</p> |
| | | | | When Intelligent Key is not in the antenna detection area |  <p style="text-align: right; font-size: small;">JMKIA0063GB</p> |
| 75 (LG) | Ground | Passenger door an- tenna (+) | Output | When the pas- senger door re- quest switch is operated with ig- nition switch OFF |  <p style="text-align: right; font-size: small;">JMKIA0062GB</p> |
| | | | | When Intelligent Key is not in the antenna detection area |  <p style="text-align: right; font-size: small;">JMKIA0063GB</p> |

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

WW







BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|---|------------------|--|---|---|
| + | - | Signal name | Input/ Output | | | |
| 76 (V) | Ground | Driver door antenna (-) | Output | When the driver door request switch is operated with ignition switch OFF | <p style="text-align: right; font-size: small;">JMKIA0062GB</p> | |
| | | | | When Intelligent Key is not in the antenna detection area | <p style="text-align: right; font-size: small;">JMKIA0063GB</p> | |
| 77 (P) | Ground | Driver door antenna (+) | Output | When the driver door request switch is operated with ignition switch OFF | <p style="text-align: right; font-size: small;">JMKIA0062GB</p> | |
| | | | | When Intelligent Key is not in the antenna detection area | <p style="text-align: right; font-size: small;">JMKIA0063GB</p> | |
| 80 (SB) | Ground | NATS antenna amp. | Input/ Output | During waiting | Ignition switch is pressed while inserting Intelligent Key into the key slot. | Just after pressing ignition switch. Pointer of tester should move. |
| 81 (O) | Ground | NATS antenna amp. | Input/ Output | During waiting | Ignition switch is pressed while inserting Intelligent Key into the key slot. | Just after pressing ignition switch. Pointer of tester should move. |
| 82 (BR) | Ground | Ignition relay [fuse block (J/B)] control | Output | Ignition switch | OFF or ACC | 0 V |
| | | | | | ON | Battery voltage |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >






| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|---|------------------|---|---|--|
| | | Signal name | Input/ Output | | | |
| + | - | | | | | |
| 83 (P) | Ground | Remote keyless entry receiver communication | Input/ Output | During waiting |  <p style="text-align: right; font-size: small;">JMKIA0064GB</p> | |
| | | | | When operating either button on Intelligent Key |  <p style="text-align: right; font-size: small;">JMKIA0065GB</p> | |
| 87 (R) | Ground | Combination switch INPUT 5 | Input | Combination switch | All switches OFF (Wiper intermittent dial 4) |  <p style="text-align: right; font-size: small;">JPMIA0041GB</p> <p style="text-align: center;">1.4 V</p> |
| | | | | | Front fog lamp switch ON (Wiper intermittent dial 4) |  <p style="text-align: right; font-size: small;">JPMIA0037GB</p> <p style="text-align: center;">1.3 V</p> |
| | | | | | Rear wiper switch ON (Wiper intermittent dial 4) |  <p style="text-align: right; font-size: small;">JPMIA0039GB</p> <p style="text-align: center;">1.3 V</p> |
| | | | | | Any of the conditions below with all switches OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 6 • Wiper intermittent dial 7 |  <p style="text-align: right; font-size: small;">JPMIA0040GB</p> <p style="text-align: center;">1.3 V</p> |

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

WW




BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|-------------------------------|------------------|-----------------------|--|--|
| + | - | Signal name | Input/ Output | | | |
| 88 (GR) | Ground | Combination switch INPUT 3 | Input | Combination switch | All switches OFF (Wiper intermittent dial 4) |  <p style="text-align: right; font-size: small;">JPMIA0041GB</p> <p style="text-align: center;">1.4 V</p> |
| | | | | | Lighting switch HI (Wiper intermittent dial 4) |  <p style="text-align: right; font-size: small;">JPMIA0036GB</p> <p style="text-align: center;">1.3 V</p> |
| | | | | | Lighting switch 2ND (Wiper intermittent dial 4) |  <p style="text-align: right; font-size: small;">JPMIA0037GB</p> <p style="text-align: center;">1.3 V</p> |
| | | | | | Rear washer switch ON (Wiper intermittent dial 4) |  <p style="text-align: right; font-size: small;">JPMIA0039GB</p> <p style="text-align: center;">1.3 V</p> |
| | | | | | Any of the conditions below with all switches OFF |  <p style="text-align: right; font-size: small;">JPMIA0040GB</p> <p style="text-align: center;">1.3 V</p> |
| 90 (P) | Ground | CAN-L | Input/ Output | — | — | |
| 91 (L) | Ground | CAN-H | Input/ Output | — | — | |

BCM (BODY CONTROL MODULE)






< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|--|------------------|-------------------------------|---|--|
| + | - | Signal name | Input/ Output | | | |
| 92 (R) | Ground | Key slot illumination | Output | Key slot illumination | OFF | 0 V |
| | | | | | Blinking |  6.5 V |
| | | | | | ON | Battery voltage |
| 93 (P) | Ground | ON indicator lamp | Output | Ignition switch | OFF (LOCK and ACC indicator lamps are not illuminated.) | Battery voltage |
| | | | | | ON | 0 V |
| 95 (L) | Ground | ACC relay control | Output | Ignition switch | OFF | 0 V |
| | | | | | ACC or ON | Battery voltage |
| 96 (Y) | Ground | CVT shift selector (detention switch) power supply | Output | — | Battery voltage | |
| 99 (V) | Ground | Selector lever P position switch | Input | Selector lever | P position | 0 V |
| | | | | | Any position other than P | Battery voltage |
| 100 (P) | Ground | Passenger door request switch | Input | Passenger door request switch | ON (Pressed) | 0 V |
| | | | | | OFF (Not pressed) |  1.0 V |
| 101 (W) | Ground | Driver door request switch | Input | Driver door request switch | ON (Pressed) | 0 V |
| | | | | | OFF (Not pressed) |  1.0 V |
| 102 (Y) | Ground | Blower fan motor relay control | Output | Ignition switch | OFF or ACC | 0 V |
| | | | | | ON | Battery voltage |
| 103 (L) | Ground | Remote keyless entry receiver power supply | Output | Ignition switch OFF | Battery voltage | |

A
B
C
D
E
F
G
H
I
J
K
WW
M
N
O
P






BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|-------------------------------|------------------|---|------------------------|--|
| + | - | Signal name | Input/ Output | | | |
| 107 (O) | Ground | Combination switch INPUT 1 | Input | Combination switch (Wiper intermit- tent dial 4) | All switches OFF |  <p>1.4 V</p> |
| | | | | | Turn signal switch LH |  <p>1.3 V</p> |
| | | | | | Turn signal switch RH |  <p>1.3 V</p> |
| | | | | | Front wiper switch LO |  <p>1.3 V</p> |
| | | | | | Front washer switch ON |  <p>1.3 V</p> |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >







| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|-------------------------------|------------------|-----------------------|---|--|
| | | Signal name | Input/ Output | | | |
| + | - | | | | | |
| 108 (P) | Ground | Combination switch INPUT 4 | Input | Combination switch | All switches OFF (Wiper intermittent dial 4) |  1.4 V |
| | | | | | Lighting switch AUTO (Wiper intermittent dial 4) |  1.3 V |
| | | | | | Lighting switch 1ST (Wiper intermittent dial 4) |  1.3 V |
| | | | | | Rear wiper switch INT (Wiper intermittent dial 4) |  1.3 V |
| | | | | | Any of the conditions below with all switches OFF |  1.3 V |
| | | | | | <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6 | |

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

WW




BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|-------------------------------|------------------|--|--|--|
| | | Signal name | Input/ Output | | | |
| + | - | | | | | |
| 109 (SB) | Ground | Combination switch INPUT 2 | Input | Combination switch (Wiper intermittent dial 4) | All switches OFF |  <p style="text-align: right;">JPMIA0041GB</p> <p style="text-align: center;">1.4 V</p> |
| | | | | | Lighting switch PASS |  <p style="text-align: right;">JPMIA0037GB</p> <p style="text-align: center;">1.3 V</p> |
| | | | | | Lighting switch 2ND |  <p style="text-align: right;">JPMIA0036GB</p> <p style="text-align: center;">1.3 V</p> |
| | | | | | Front wiper switch INT/ AUTO |  <p style="text-align: right;">JPMIA0038GB</p> <p style="text-align: center;">1.3 V</p> |
| | | | | | Front wiper switch HI |  <p style="text-align: right;">JPMIA0040GB</p> <p style="text-align: center;">1.3 V</p> |
| | | | | | ON | 0 V |
| 110 (G) | Ground | Hazard switch | Input | Hazard switch |  <p style="text-align: right;">JPMIA0012GB</p> <p style="text-align: center;">1.1 V</p> | |
| | | | | OFF | | |

BCM (BODY CONTROL MODULE)




< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|--|------------------|--|---|
| | | Signal name | Input/ Output | | |
| + | - | | | | |
| 112 (R) | Ground | Rain sensor serial link | Input/ Output | Ignition switch ON |  <p style="text-align: center;">8.7 V</p> |
| 113 (P/B) | Ground | Optical sensor | Input | Ignition switch ON | When bright outside of the vehicle Close to 5 V |
| | | | | Ignition switch ON | When dark outside of the vehicle Close to 0 V |
| 116 (GR) | Ground | Stop lamp switch 1 | Input | — | Battery voltage |
| 118 (L) | Ground | Stop lamp switch 2 | Input | Stop lamp switch | OFF (Brake pedal is not depressed) 0 V |
| | | | | Stop lamp switch | ON (Brake pedal is depressed) Battery voltage |
| 119 (W) | Ground | Front door lock assembly driver side (Unlock sensor) | Input | Driver door |  <p style="text-align: center;">1.1 V</p> |
| | | | | Driver door | UNLOCK status (unlock sensor switch ON) 0 V |
| 121 (Y) | Ground | Key slot switch | Input | When Intelligent Key is inserted into key slot | Battery voltage |
| | | | | When Intelligent Key is not inserted into key slot | 0 V |
| 123 (G) | Ground | IGN feedback | Input | Ignition switch | OFF or ACC 0 V |
| | | | | Ignition switch | ON Battery voltage |
| 124 (R) | Ground | Passenger door switch | Input | Passenger door switch |  <p style="text-align: center;">11.8 V</p> |
| | | | | Passenger door switch | ON (When passenger door opens) 0 V |

A
B
C
D
E
F
G
H
I
J
K
WW
M
N
O
P






BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|--|------------------|--|---|--|
| + | - | Signal name | Input/ Output | | | |
| 130 (BR) | Ground | Rear window defogger switch | Input | Ignition switch ON | Rear window defogger switch OFF |  1.1 V |
| | | | | Rear window defogger switch ON | | 0 V |
| 132 (G) | Ground | Power window switch communication | Input/ Output | Ignition switch ON | |  10.2 V |
| | | | | Ignition switch OFF or ACC | | Battery voltage |
| 133 (W) | Ground | Push-button ignition switch illumination | Output | Push-button ignition switch illumination | ON (When tail lamps OFF) | 9.5 V |
| | | | | | ON (When tail lamps ON) | <p style="text-align: center;">NOTE: The pulse width of this wave is varied by the illumination brightening/dimming level.</p>  9.5 V |
| 134 (R) | Ground | LOCK indicator lamp | Output | LOCK indicator lamp | OFF (ACC and ON indicator lamps are not illuminated.) | Battery voltage |
| | | | | | ON | 0 V |
| 137 (P) | Ground | Receiver and sensor ground | Input | Ignition switch ON | | 0 V |
| 138 (V) | Ground | Receiver and sensor power supply | Output | Ignition switch | OFF | 0 V |
| | | | | | ACC or ON | 5.0 V |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >





| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|--------------------------------------|------------------|---|--|
| | | Signal name | Input/ Output | | |
| + | - | | | | |
| 139 (O) | Ground | Tire pressure receiver communication | Input/ Output | Ignition switch ON | Standby state  OCC3881D |
| | | | | When receiving the signal from the transmitter  OCC3880D | |
| 140 (GR) | Ground | Selector lever P/N position | Input | Selector lever | P or N position Battery voltage |
| | | | | Except P and N positions 0 V | |
| 141 (O) | Ground | Security indicator | Output | Security indicator | ON 0 V |
| | | | | Blinking  JPMA0014GB 11.3 V | |
| | | | | OFF Battery voltage | |
| 142 (L) | Ground | Combination switch OUTPUT 5 | Output | Combination switch (Wiper intermittent dial 4) | All switches OFF 0 V |
| | | | | Lighting switch 1ST |  JPMA0031GB 10.7 V |
| | | | | Lighting switch HI | |
| | | | | Lighting switch 2ND | |
| Turn signal switch RH | | | | | |
| 143 (W) | Ground | Combination switch OUTPUT 1 | Output | Combination switch | All switches OFF (Wiper intermittent dial 4) 0 V |
| | | | | Front wiper switch HI (Wiper intermittent dial 4) |  JPMA0032GB 10.7 V |
| | | | | Rear wiper switch INT (Wiper intermittent dial 4) | |
| | | | | Any of the conditions below with all switches OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 3 • Wiper intermittent dial 6 • Wiper intermittent dial 7 | |

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

WW

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|---|------------------|---|--|---|
| + | - | Signal name | Input/ Output | | | |
| 144 (P) | Ground | Combination switch OUTPUT 2 | Output | Combination switch | All switches OFF (Wiper intermittent dial 4) | 0 V |
| | | | | | Front washer switch ON (Wiper intermittent dial 4) |  |
| | | | | | Rear wiper switch ON (Wiper intermittent dial 4) | |
| | | | | | Rear washer switch ON (Wiper intermittent dial 4) | |
| | | | | | Any of the conditions below with all switches OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6 | |
| 145 (V) | Ground | Combination switch OUTPUT 3 | Output | Combination switch (Wiper intermit- tent dial 4) | All switches OFF | 0 V |
| | | | | | Front wiper switch INT/ AUTO |  |
| | | | | | Front wiper switch LO | |
| | | | | | Lighting switch AUTO | |
| 146 (Y) | Ground | Combination switch OUTPUT 4 | Output | Combination switch (Wiper intermit- tent dial 4) | All switches OFF | 0 V |
| | | | | | Front fog lamp switch ON |  |
| | | | | | Lighting switch 2ND | |
| | | | | | Lighting switch PASS | |
| | | | | | Turn signal switch LH | |
| 150 (SB) | Ground | Driver door switch | Input | Driver door switch | OFF (When driver door closes) |  11.8 V |
| | | | | | ON (When driver door opens) | 0 V |
| 151 (G) | Ground | Rear window defog- ger relay control | Output | Rear window de- fogger | Active | 0 V |
| | | | | | Not activated | Battery voltage |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Wiring Diagram - BCM -

INFOID:000000010129279



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


WW

2011/07/28

JRMWC5024GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >





JRMWC5025GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

- : With navigation system
- : Without navigation system
- : With sunroof
- : With automatic drive positioner
- : With power seat without automatic drive positioner
- : With automatic back door
- : With color display

* : This connector is not shown in "Harness Layout".




A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

WW

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >




JRMWC5027GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

AB : With automatic back door
OA : Without automatic back door



JRMWC5028GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


WW

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)

| | |
|----------------|----------------------------------|
| Connector No. | B8 |
| Connector Name | AUTOMATIC BACK DOOR CONTROL UNIT |
| Connector Type | TH20FW-TB6 |



| | |
|----------------|---------------------|
| Connector No. | B51 |
| Connector Name | REAR DOOR SWITCH LH |
| Connector Type | TH44FW-RH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | B/W | [Without rear view camera] |
| 2 | LG | [With rear view camera] |
| 3 | BR | - |
| 4 | P | - |
| 4 | L | - |

| | |
|----------------|-------------|
| Connector No. | B72 |
| Connector Name | DICD |
| Connector Type | 24335-G5802 |



| | |
|----------------|-----------------------------------|
| Connector No. | B85 |
| Connector Name | OUTSIDE KEY ANTENNA (REAR BUMPER) |
| Connector Type | RK02FCY |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | BR | BUTZER |
| 2 | Y | ABS SW |
| 3 | Y | ABS CLOSE SW |
| 4 | Y | ABS SW |
| 5 | L | CAN-H |
| 6 | P | CAN-L |
| 7 | LG | HALF LATCH SW |
| 8 | GR | IGN |
| 9 | GR | IGN |
| 10 | SB | BAT |
| 11 | V | CLOSURE MTR (CLOSE) |
| 12 | R | CLOSURE MTR (OPEN) |
| 13 | V | TOUCH SENS LH |
| 14 | V | TOUCH SENS LH |
| 15 | O | TOUCH SENS GND |
| 16 | W | TOUCH SENS RH |
| 17 | W | TOUCH SENS RH |
| 18 | LG | MAIN SW |
| 19 | P | OPEN SW |
| 20 | L | OPEN SW |
| 21 | B | GROUND |
| 22 | B | GROUND |
| 23 | GR | GROUND |
| 24 | BR | ENCODER B |
| 25 | Y | ENCODER A |
| 26 | G | ENCODER PWR |

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 3 | BR | - |

| | |
|----------------|---------------------------------|
| Connector No. | B32 |
| Connector Name | FRONT DOOR SWITCH (DRIVER SIDE) |
| Connector Type | TH44FW-RH |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | R | - |
| 2 | G | - |

| | |
|----------------|-----------------------------------|
| Connector No. | B88 |
| Connector Name | INSIDE KEY ANTENNA (LUGGAGE ROOM) |
| Connector Type | RK02FCY |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 3 | SB | - |

| | |
|----------------|--------------------------|
| Connector No. | B59 |
| Connector Name | REAR COMBINATION LAMP RH |
| Connector Type | NS44MW-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W | - |
| 2 | L | - |

| | |
|----------------|--------------------------|
| Connector No. | B60 |
| Connector Name | REAR COMBINATION LAMP LH |
| Connector Type | NS44MW-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W | - |
| 2 | B | - |

| | |
|----------------|-----------------------------------|
| Connector No. | B88 |
| Connector Name | INSIDE KEY ANTENNA (LUGGAGE ROOM) |
| Connector Type | RK02FCY |



JRMWE5830GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)

| | |
|----------------|---------------------|
| Connector No. | B232 |
| Connector Name | REAR DOOR SWITCH RH |
| Connector Type | TH0FW-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 3 | W | - |

| | |
|----------------|------------------------------------|
| Connector No. | B233 |
| Connector Name | FRONT DOOR SWITCH (PASSENGER SIDE) |
| Connector Type | TH0FW-NH |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 3 | R | - |

| | |
|----------------|-----------------------|
| Connector No. | B407 |
| Connector Name | LUMBAR SUPPORT SWITCH |
| Connector Type | NS0MFBR-CS |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 11 | O | - |
| 12 | LG | - |
| 13 | Y/W | - |
| 14 | Y | - |

| | |
|----------------|---------------------------------|
| Connector No. | B414 |
| Connector Name | POWER SEAT SWITCH (DRIVER SIDE) |
| Connector Type | NS10FW-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | R | - |
| 2 | B | - |
| 3 | G | - |
| 4 | G/R | - |
| 5 | V | - |
| 6 | R/L | - |
| 8 | L/W | - |
| 8 | L/R | - |
| 10 | L/B | - |

| | |
|----------------|------------------------------------|
| Connector No. | B434 |
| Connector Name | POWER SEAT SWITCH (PASSENGER SIDE) |
| Connector Type | NS10FW-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 2 | B | - |
| 3 | G | - |
| 4 | G/R | - |
| 5 | V | - |
| 6 | R/L | - |

| | |
|----------------|--------------------------|
| Connector No. | B452 |
| Connector Name | DRIVER SEAT CONTROL UNIT |
| Connector Type | TH02FW |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 11 | O/B | - |
| 12 | G/W | - |
| 13 | R/G | - |
| 14 | R/W | - |
| 15 | V/B | - |
| 17 | L/G/B | - |
| 18 | L/S/R | - |
| 19 | G/Y | - |
| 20 | R/Y | - |
| 21 | L/Y | - |
| 22 | BR/Y | - |
| 23 | P | - |
| 24 | P/L | - |
| 25 | G/O | - |
| 26 | L/O | - |
| 27 | V | - |
| 28 | V/W | - |
| 29 | O/L | - |
| 31 | BR/W | - |
| 32 | W/L | - |
| 33 | W | - |

| | |
|----------------|--------------------------|
| Connector No. | D5 |
| Connector Name | POWER WINDOW MAIN SWITCH |
| Connector Type | NS10FW-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | GR | - |
| 2 | BR | - |
| 4 | BR | - |
| 5 | SR | - |
| 6 | R | - |
| 7 | P | - |
| 8 | L | - |
| 9 | G | - |
| 10 | V | - |
| 11 | LG | - |
| 13 | Y | - |
| 14 | O | - |
| 15 | R | - |

| | |
|----------------|--------------------------|
| Connector No. | D6 |
| Connector Name | POWER WINDOW MAIN SWITCH |
| Connector Type | NS10FW-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 17 | PS | - |
| 19 | LG | - |

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P


WW

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)

| | |
|----------------|--|
| Connector No. | D9 |
| Connector Name | FRONT DOOR LOCK ASSEMBLY (DRIVER SIDE) |
| Connector Type | ERBEFY-RS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | V | - |
| 2 | G | - |
| 3 | P | - |
| 4 | B | - |
| 5 | R | - |
| 6 | L | - |

| | |
|----------------|--|
| Connector No. | D11 |
| Connector Name | FRONT OUTSIDE HANDLE LH (REQUEST SWITCH) |
| Connector Type | RHOZFB |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W | - |
| 2 | B | - |

| | |
|----------------|---|
| Connector No. | D12 |
| Connector Name | FRONT OUTSIDE HANDLE LH (OUTSIDE KEY ANTENNA) |
| Connector Type | RHOZMGY |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | V | - |
| 2 | Y | - |

| | |
|----------------|-------------------------|
| Connector No. | D17 |
| Connector Name | STEP LAMP (DRIVER SIDE) |
| Connector Type | COZFW |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | G | - |
| 2 | R | - |

| | |
|----------------|--|
| Connector No. | D45 |
| Connector Name | FRONT POWER WINDOW SWITCH (PASSENGER SIDE) |
| Connector Type | NS18FW-GS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | R | - |
| 2 | L | - |
| 3 | B | - |
| 4 | LG | - |
| 5 | P | - |
| 6 | B | - |
| 7 | Y | - |
| 8 | G | - |
| 9 | O | - |
| 10 | P | - |
| 11 | B | - |
| 12 | Y | - |
| 13 | G | - |
| 14 | G | - |
| 15 | G | - |
| 16 | O | - |

| | |
|----------------|---|
| Connector No. | D48 |
| Connector Name | FRONT DOOR LOCK ASSEMBLY (PASSENGER SIDE) |
| Connector Type | ERBEFY-RS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | V | - |
| 2 | G | - |

| | |
|----------------|--|
| Connector No. | D59 |
| Connector Name | FRONT OUTSIDE HANDLE RH (REQUEST SWITCH) |
| Connector Type | RHOZFB |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | O | - |
| 2 | B | - |

| | |
|----------------|----------------------------|
| Connector No. | D51 |
| Connector Name | STEP LAMP (PASSENGER SIDE) |
| Connector Type | COZFW |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | G | - |
| 2 | R | - |

JRMWE5832GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


BCM (BODY CONTROL MODULE)

| | |
|----------------|---|
| Connector No. | D82 |
| Connector Name | FRONT OUTSIDE HANDLE RH (OUTSIDE KEY ANTENNA) |
| Connector Type | FR02M6Y |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | LG | - |
| 2 | W | - |

| | |
|----------------|-----------------------------|
| Connector No. | D83 |
| Connector Name | REAR POWER WINDOW SWITCH LH |
| Connector Type | NS08FW-CS |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | R | - |
| 2 | P | - |
| 3 | SB | - |
| 4 | LG | - |
| 5 | L | - |

| | |
|----------------|----------------------------|
| Connector No. | D85 |
| Connector Name | REAR DOOR LOCK ASSEMBLY LH |
| Connector Type | EB0F6Y-BS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | V | - |
| 2 | G | - |

| | |
|----------------|-----------------------------|
| Connector No. | D103 |
| Connector Name | REAR POWER WINDOW SWITCH RH |
| Connector Type | NS08FW-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | R | - |
| 2 | P | - |
| 3 | SB | - |
| 4 | LG | - |
| 5 | L | - |

| | |
|----------------|----------------------------|
| Connector No. | D105 |
| Connector Name | REAR DOOR LOCK ASSEMBLY RH |
| Connector Type | EB0F6Y-BS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 3 | V | - |
| 6 | G | - |

| | |
|----------------|----------------------|
| Connector No. | D156 |
| Connector Name | LUGGAGE ROOM LAMP RH |
| Connector Type | CJ04FW |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 2 | W | - |
| 4 | LG | - |

| | |
|----------------|----------------------|
| Connector No. | D157 |
| Connector Name | LUGGAGE ROOM LAMP LH |
| Connector Type | CJ04FW |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 2 | W | - |
| 4 | LG | - |

| | |
|----------------|----------------------------------|
| Connector No. | D178 |
| Connector Name | AUTOMATIC BACK DOOR CLOSE SWITCH |
| Connector Type | TK06FGY |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | O | - |
| 2 | B | - |
| 3 | W | - |
| 4 | LG | - |

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

WW

JRMWE5833GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)

| | |
|----------------|-------------------------|
| Connector No. | D179 |
| Connector Name | BACK DOOR LOCK ASSEMBLY |
| Connector Type | NSDBEW-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | R | - |
| 2 | Y | - |
| 4 | G | - |
| 5 | L | - |
| 6 | W | - |
| 7 | LG | - |
| 8 | B | - |

| | |
|----------------|-------------------------|
| Connector No. | D180 |
| Connector Name | BACK DOOR LOCK ASSEMBLY |
| Connector Type | NSDBEW-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | BR | - |
| 2 | B | - |
| 3 | LG | - |
| 4 | B | - |

| | |
|----------------|----------------------------------|
| Connector No. | D188 |
| Connector Name | BACK DOOR OPENER SWITCH ASSEMBLY |
| Connector Type | TH84MW-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | R | - |
| 2 | B | - |
| 3 | B | - |
| 4 | Y | - |

| | |
|----------------|------------------|
| Connector No. | D183 |
| Connector Name | REAR WIPER MOTOR |
| Connector Type | CU04FW-TV |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | G | - |
| 3 | GR | - |
| 4 | O | - |

| | |
|----------------|---|
| Connector No. | E16 |
| Connector Name | ECU INTELLIGENT POWER DISTRIBUTION MODULE FRAME |
| Connector Type | TH89FW-CS12-M4-TV |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 5 | Y | - |
| 7 | GR | - |
| 10 | BR | - |
| 12 | B | - |
| 13 | SB | - |
| 15 | W | - |
| 16 | R | - |
| 19 | Y | - |
| 20 | L | - |
| 21 | O | - |
| 22 | SB | - |
| 23 | GR | - |
| 24 | G | - |
| 26 | Y | - |
| 27 | W | - |
| 28 | SB | - |
| 30 | BR | - |
| 34 | O | - |
| 35 | P | - |
| 36 | G | - |
| 38 | GR | - |

| | |
|----------------|---|
| Connector No. | E11 |
| Connector Name | ECU INTELLIGENT POWER DISTRIBUTION MODULE FRAME |
| Connector Type | TH89FW-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 39 | P | - |
| 40 | B | - |
| 41 | B | - |
| 42 | SB | - |
| 43 | Y | - |
| 44 | W | - |
| 45 | O | - |
| 46 | BR | - |

| | |
|----------------|----------------|
| Connector No. | E16 |
| Connector Name | ECM |
| Connector Type | RP24FE-R28-L-H |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-------------------------------------|
| 81 | W | ACCELERATOR PEDAL POSITION SENSOR 1 |
| 82 | O | ACCELERATOR PEDAL POSITION SENSOR 2 |
| 83 | BR | SENSOR POWER SUPPLY |
| 84 | B | SENSOR GROUND |
| 85 | Y | SENSOR GROUND |
| 86 | SB | EVAP CONTROL SYSTEM PRESSURE SENSOR |
| 87 | GR | SENSOR POWER SUPPLY |
| 88 | O | DATA LINK CONNECTOR |
| 91 | L | SENSOR POWER SUPPLY |
| 92 | BR | SENSOR GROUND |
| 93 | BR | IGNITION SWITCH |
| 94 | GR | ENGINE SPEED OUTPUT SIGNAL |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)


| | | |
|-----|----|----------------------------------|
| 85 | Y | FUEL TANK TEMPERATURE SENSOR |
| 87 | GR | SENSOR GROUND |
| 88 | R | CAN COMMUNICATION LINE (CAN-L) |
| 88 | L | CAN COMMUNICATION LINE (CAN-H) |
| 100 | G | SENSOR GROUND |
| 102 | R | PNP SIGNAL |
| 104 | SB | SENSOR GROUND |
| 105 | V | POWER SUPPLY FOR ECM |
| 106 | SB | STOP LAMP SWITCH |
| 107 | B | ECM GROUND |
| 108 | B | ECM GROUND |
| 109 | W | EVAP CANISTER VENT CONTROL VALVE |
| 110 | G | ASD BRAKE SWITCH |
| 111 | B | ECM GROUND |
| 112 | B | ECM GROUND |

| | |
|----------------|--------------------------------|
| Connector No. | E25 |
| Connector Name | INTELLIGENT KEY WARNING BUZZER |
| Connector Type | PK03FBR |



| | | | | |
|-----------------------------|---|---|----|----|
| Terminal No. | 1 | 2 | 3 | GR |
| Color Of Wire | G | G | GR | |
| Signal Name [Specification] | | | | |

| | |
|----------------|---|
| Connector No. | E36 |
| Connector Name | ABS ACTIVATION AND ELECTRIC INET CONTROL UNIT |
| Connector Type | AE222FB-AJ24-LH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | R | VALVE / ECU SUPPLY |
| 2 | Y | WSS RL SIG (-) |
| 3 | L | WSS RL PWR (+) |
| 4 | GR | CLUSTER SUPPLY |
| 5 | B | WSS FR PWR (+) |
| 6 | W | WSS FR SIG (-) |
| 7 | LG | LIS |
| 8 | V | WSS FL SIG (-) |
| 9 | W | WSS FL PWR (+) |
| 10 | SB | CLUSTER GND |
| 11 | P | WSS RR PWR (+) |
| 12 | V | WSS RR SIG (-) |
| 13 | B/W | MOTOR GND |
| 14 | B | MOTOR SUPPLY |
| 15 | SB | ECM GND |
| 16 | BR | CAN 2 H |
| 17 | GR | IGN |
| 20 | GR | CAN 1 L |
| 21 | P | CAN 1 L |
| 22 | Y | VDC OFF SW |
| 23 | L | CAN 1 H |
| 25 | W | CAN 2 L |
| 26 | B/W | VALVE / ECU GND |

| | |
|----------------|------------------|
| Connector No. | E103 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | NS16PW-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 11F | G | |
| 12F | V | |
| 13 | L | |
| 14 | LG | |
| 15 | BR | |
| 16 | Y | |
| 17 | R | |
| 18 | GR | |
| 19 | GR | |

| | |
|----------------|------------------|
| Connector No. | E116 |
| Connector Name | STOP LAMP SWITCH |
| Connector Type | MD9FW-LC |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | R | |
| 2 | B | |
| 3 | G | |
| 4 | Y | |

| | |
|----------------|---------------------------|
| Connector No. | E318 |
| Connector Name | FRONT COMBINATION LAMP LH |
| Connector Type | Z05FBR |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | LG | |
| 2 | B | |
| 3 | Y | |

| | |
|----------------|---------------------------|
| Connector No. | E319 |
| Connector Name | FRONT COMBINATION LAMP RH |
| Connector Type | Z05FBR |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | R | |
| 2 | B | |
| 3 | G | |

| | |
|----------------|---------------------------|
| Connector No. | E327 |
| Connector Name | FRONT TURN SIGNAL LAMP LH |
| Connector Type | RS02FCY |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | Y | |
| 2 | B | |

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

WW

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)

| | |
|----------------|---------------------------|
| Connector No. | E32B |
| Connector Name | FRONT TURN SIGNAL LAMP RH |
| Connector Type | RS2ZEGY |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | G | - |
| 2 | B | - |

| | |
|----------------|---|
| Connector No. | F12 |
| Connector Name | FRONT INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM |
| Connector Type | TH2BFW-CS12-M4 |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 48 | W | - |
| 49 | R/B | - |
| 51 | LG | - |
| 52 | Y/G | - |
| 53 | R/W | - |
| 54 | G/W | - |
| 55 | W/L | - |
| 56 | R/Y | - |
| 57 | O | - |
| 58 | Y | - |
| 59 | WB | - |
| 60 | G | - |
| 72 | R/B | - |
| 75 | LG | - |
| 76 | SB | - |
| 77 | GR | - |
| 80 | B | - |

| | |
|----------------|-----------------------------------|
| Connector No. | F23 |
| Connector Name | TOM (TRANSMISSION CONTROL MODULE) |
| Connector Type | RH40FB-E2B-L-RH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|--|
| 1 | B | TRANSMISSION RANGE SWITCH 2 |
| 2 | P/O | TRANSMISSION RANGE SWITCH 2 |
| 3 | G/O | TRANSMISSION RANGE SWITCH 4 |
| 4 | GR | TRANSMISSION RANGE SWITCH 3 (MONITOR) |
| 5 | B | GROUND |
| 7 | W | SENSOR GROUND |
| 8 | G/W | CLOCK (SEL 2) |
| 9 | L/R | CHP SELECT (SEL 1) |
| 10 | BR/R | DATA I/O (SEL 3) |
| 11 | BR/W | TRANSMISSION RANGE SWITCH 1 |
| 13 | V | CVT FLUID TEMPERATURE SENSOR |
| 14 | R/W | PRIMARY PRESSURE SENSOR |
| 15 | V/W | SECONDARY PRESSURE SENSOR |
| 18 | G/B | REVERSE LAMP-RELAY |
| 19 | R/B | SENSOR GROUND |
| 25 | W/B | SENSOR GROUND |
| 26 | L/O | SENSOR POWER |
| 27 | R/G | STEP MOTOR C |
| 28 | R | STEP MOTOR B |
| 29 | O/B | STEP MOTOR C |
| 30 | G/R | STEP MOTOR A |
| 31 | P | CAN-L |
| 32 | L | CAN-H |
| 33 | LG | PRIMARY SPEED SENSOR |
| 34 | LG/R | SECONDARY SPEED SENSOR |
| 37 | V/R | LOCK-UP SELECT SOLENOID VALVE |
| 38 | L/W | TORQUE CONVERTER CLUTCH SOLENOID VALVE |
| 39 | W/B | SECONDARY PRESSURE SOLENOID VALVE |
| 40 | P/Y | LINE PRESSURE SOLENOID VALVE |
| 42 | B | GROUND |
| 43 | Y | POWER SUPPLY |
| 47 | L/R | POWER SUPPLY (MEMORY BACK-UP) |
| 48 | Y | POWER SUPPLY |

| | |
|----------------|------------------|
| Connector No. | M1 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | NSR6FW-M2 |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1A | - | - |
| 2A | G | - |
| 3A | Y | - |
| 4A | GR | - |
| 7A | LG | - |
| 8A | Y | - |

| | |
|----------------|------------------|
| Connector No. | M2 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | NS10FW-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1B | W | - |
| 3B | L | - |
| 4B | G | - |
| 5B | L | - |
| 6B | Y | - |
| 7B | R | - |
| 8B | SB | - |
| 9B | GR | - |

| | |
|----------------|------------------|
| Connector No. | M3 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | NS12FW-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 11C | SB | - |
| 12C | O | - |
| 8C | BR | - |
| 7C | B | - |
| 8C | G | - |
| 9C | GR | - |

| | |
|----------------|---------------------|
| Connector No. | M4 |
| Connector Name | DATA LINK CONNECTOR |
| Connector Type | BD18FW |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 3 | LG | - |
| 4 | B | - |
| 5 | B | - |
| 6 | L | - |
| 7 | BR | - |
| 8 | SB | - |
| 14 | P | - |
| 16 | Y | - |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)

| | |
|----------------|----------------|
| Connector No. | M17 |
| Connector Name | OPTICAL SENSOR |
| Connector Type | TK03FW |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | V | — |
| 2 | P | — |

| | |
|----------------|------------------------|
| Connector No. | M21 |
| Connector Name | TIRE PRESSURE RECEIVER |
| Connector Type | TK05FW |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | P | GROUND |
| 2 | O | SIGNAL |
| 4 | V | POWER |

| | |
|----------------|-------------------|
| Connector No. | M24 |
| Connector Name | COMBINATION METER |
| Connector Type | TH40FW-NH |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|---|
| 1 | G | BATTERY POWER SUPPLY |
| 2 | B | IGNITION |
| 3 | B | GROUND |
| 4 | B | GROUND |
| 5 | SB | ILLUMINATION CONTROL SIGNAL |
| 8 | SB | TRIP RESET SIGNAL |
| 9 | W | SW ILL POWER |
| 10 | LG | METER CONTROL SWITCH GROUND |
| 11 | L | ENTER SWITCH SIGNAL |
| 12 | R | SELECT SWITCH SIGNAL |
| 13 | V | ILLUMINATION CONTROL SWITCH SIGNAL (-) |
| 14 | GR | ILLUMINATION CONTROL SWITCH SIGNAL (+) |
| 15 | BR | AIR BAG SIGNAL |
| 16 | L | AMBIENT SENSOR SIGNAL |
| 17 | P | AMBIENT SENSOR POWER |
| 18 | Y | AMBIENT SENSOR GROUND |
| 20 | Y | CAN-L |
| 21 | P | CAN-H |
| 22 | B | GROUND |
| 23 | B | FUEL LEVEL SENSOR GROUND |
| 24 | W | ALTERNATOR SIGNAL |
| 25 | BR | PARKING BRAKE SWITCH SIGNAL |
| 26 | G | WASHER LEVEL SWITCH SIGNAL |
| 27 | V | WASHER LEVEL SWITCH SIGNAL |
| 29 | R | VEHICLE SPEED SIGNAL (2-PULSE) |
| 30 | P | VEHICLE SPEED SIGNAL (8-PULSE) |
| 31 | V | OVERDRIVE CONTROL SWITCH SIGNAL |
| 32 | LG | FUEL LEVEL SENSOR SIGNAL |
| 34 | G | FUEL LEVEL SENSOR SIGNAL |
| 35 | SB | SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SIDE) |
| 36 | R | SEAT BELT BUCKLE SWITCH SIGNAL (PASSENGER SIDE) |

| | |
|----------------|---------------|
| Connector No. | M45 |
| Connector Name | HAZARD SWITCH |
| Connector Type | TK04FW |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | B | — |
| 2 | B | — |
| 3 | B | — |
| 4 | R/Y | — |


| | |
|----------------|--------------|
| Connector No. | M50 |
| Connector Name | A/C AUTO AMP |
| Connector Type | SA040FW |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-------------------------------------|
| 1 | L | CAN-H |
| 2 | P | CAN-L |
| 6 | L | TX AMP SW & DISP |
| 7 | P | RX (SW AMP) |
| 10 | G | LAN SIG (Without colour display) |
| 10 | L | LAN SIG (With colour display) |
| 11 | R | NACTR |
| 15 | BR | SUN SENS |
| 16 | G | INTAKE SER (With colour display) |
| 16 | G | INTAKE SER (Without colour display) |
| 19 | G | IGN |
| 20 | G | IGN |
| 26 | GR | RR DEF F/B |
| 27 | BR | RR DEF ON |
| 32 | L | FAN PWM |
| 34 | P | AMB POWER (With colour display) |

| | | |
|----|----|------------------------------------|
| 34 | V | AMB POWER (Without colour display) |
| 35 | G | AMB SER (Without colour display) |
| 35 | L | AMB SER (With colour display) |
| 36 | LG | INCAR SENS |
| 37 | SB | SENS GND (Without colour display) |
| 37 | Y | SENS GND (With colour display) |
| 39 | B | GND (POWER) |
| 40 | Y | BAT |

| | |
|----------------|--------------------|
| Connector No. | M57 |
| Connector Name | CVT SHIFT SELECTOR |
| Connector Type | TK10FW |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | LG | — |
| 4 | B | — |
| 6 | P | — |
| 7 | B | — |
| 8 | Y | — |
| 8 | V | — |

| | |
|----------------|-------------------------------|
| Connector No. | M78 |
| Connector Name | REMOTE KEYLESS ENTRY RECEIVER |
| Connector Type | JAB04FB |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | P | GROUND |
| 2 | P | SIGNAL |
| 4 | L | +12V |

JRMWE5837GB

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P


WW

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)

| | |
|----------------|-----------|
| Connector No. | M189 |
| Connector Name | KEY SLOT |
| Connector Type | TH12FW-NH |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | GR | BAT |
| 2 | GR | LOCK |
| 3 | GR | DATA |
| 4 | GR | ILL.BAT |
| 5 | R | ILL |
| 6 | R | GROUND |
| 7 | B | KEY SWITCH SIGNAL |
| 11 | Y | |

| | |
|----------------|-------------------------|
| Connector No. | M100 |
| Connector Name | SECURITY INDICATOR LAMP |
| Connector Type | TR16ZFB |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | GR | |
| 2 | O | |

| | |
|----------------|-----------------------------|
| Connector No. | M101 |
| Connector Name | PUSH-BUTTON,IGNITION SWITCH |
| Connector Type | TK08FBR |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | G | |
| 2 | G | |
| 3 | W | |
| 4 | BR | |
| 5 | R | |
| 6 | L | |
| 7 | P | |
| 8 | GR | |


| | |
|----------------|--------------------|
| Connector No. | M103 |
| Connector Name | COMBINATION SWITCH |
| Connector Type | TH16FW-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | G | |
| 2 | Y | OUTPUT 4 |
| 3 | BG | FR |
| 4 | W | IGN |
| 5 | B | GROUND 3 |
| 6 | B | GROUND |
| 7 | GR | INPUT 3 |
| 8 | L | OUTPUT 5 |
| 9 | SB | INPUT 2 |
| 10 | P | INPUT 4 |
| 11 | O | INPUT 1 |
| 12 | W | OUTPUT 1 |


| | | | |
|--------------|----|---|----------|
| Terminal No. | 13 | R | INPUT 5 |
| Terminal No. | 14 | P | OUTPUT 2 |

| | |
|----------------|---------------------------|
| Connector No. | M118 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | M08FE-LC |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|---------------------------------|
| 1 | W | BAT (F/L) |
| 2 | GR | POWER WINDOW POWER SUPPLY (BAT) |
| 3 | L | POWER WINDOW POWER SUPPLY (IGN) |

| | |
|----------------|---------------------------|
| Connector No. | M119 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | HS16FW-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|------------------------------------|
| 4 | P/W | INTERIOR ROOM LAMP POWER SUPPLY |
| 5 | G | PASSENGER DOOR UNLOCK OUTPUT |
| 7 | W | STEP LAMP CONT |
| 8 | V | ALL DOOR FUEL LID LOCK OUTPUT |
| 9 | G | DRIVER DOOR FUEL LID UNLOCK OUTPUT |
| 10 | L | REAR DOOR UNLOCK OUTPUT |
| 11 | LG | BAT (L/SE) |
| 13 | B | GROUND |
| 14 | O | PUSH-BUTTON,IGNITION SW,ILL.GND |
| 15 | L | ACC.IND |
| 17 | G | TURN SIGNAL RH |
| 18 | BR | TURN SIGNAL LH |
| 19 | Y | INT. ROOM LAMP CONT |

| | |
|----------------|---------------------------|
| Connector No. | M120 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | NS12FW-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 23 | BR | BACK DOOR OPEN OUTPUT |
| 29 | G | REAR WIPER OUTPUT |

| | |
|----------------|---------------------------|
| Connector No. | M121 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | TH46FCY-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 34 | B | LUGGAGE ROOM ANT- |
| 35 | W | LUGGAGE ROOM ANT+ |
| 38 | L | REAR BUMPER ANT- |
| 39 | BR | REAR BUMPER ANT+ |
| 47 | L | IGN RELAY (PDM, E/R) CONT |
| 52 | R | STARTER RELAY CONT |
| 60 | BR | PUSH SW |
| 61 | R | BACK DOOR OPENER REQUEST SW |
| 65 | O | REAR WIPER STOP POSITION |
| 67 | Y | REAR WIPER STOP POSITION |
| 69 | LG | BACK DOOR OPENER SW |
| 68 | W | REAR RH DOOR SW |
| 69 | R | REAR LH DOOR SW |

JRMWE5838GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


BCM (BODY CONTROL MODULE)

| | |
|----------------|---------------------------|
| Connector No. | M122 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | TH46EB-NH |




| Terminal No. | Wire | Signal Name [Specification] |
|--------------|------|-------------------------------------|
| 72 | B | ROOM ANT- |
| 73 | W | ROOM ANT+ |
| 74 | Y | PASSENGER DOOR ANT- |
| 75 | LG | PASSENGER DOOR ANT+ |
| 76 | V | DRIVER DOOR ANT- |
| 77 | P | DRIVER DOOR ANT+ |
| 80 | SB | NATS ANT AMP |
| 81 | O | NATS ANT AMP |
| 82 | BR | IGN RELAY (F/B) CONT |
| 83 | P | KEYLESS ENTRY RECEIVER COMM |
| 87 | R | COMBI SW INPUT 5 |
| 88 | GR | COMBI SW INPUT 3 |
| 90 | P | CAN-L |
| 91 | L | CAN-H |
| 92 | R | KEY SLOT ILL CONT |
| 93 | P | ACC RELAY CONT |
| 95 | L | ACC RELAY CONT |
| 96 | Y | CVT SHIFT SELECTOR POWER SUPPLY |
| 99 | V | SHIF P |
| 100 | P | PASSENGER DOOR REQUEST SW |
| 101 | W | DRIVER DOOR REQUEST SW |
| 102 | Y | BLOWER RELAY CONT |
| 103 | L | KEYLESS ENTRY RECEIVER POWER SUPPLY |
| 107 | O | COMBI SW INPUT 1 |
| 108 | P | COMBI SW INPUT 4 |
| 109 | SB | COMBI SW INPUT 2 |
| 110 | G | HAZARD SW |

| | |
|----------------|---------------------------|
| Connector No. | M123 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | TH46FG-NH |



| Terminal No. | Wire | Signal Name [Specification] |
|--------------|------|-----------------------------------|
| 112 | R | RAIN SENSOR SERIAL LINK |
| 113 | CB | STOP LAMP SW 1 |
| 114 | CR | STOP LAMP SW 2 |
| 118 | L | DR DOOR UNLOCK SENSOR |
| 119 | W | KEY SLOT SW |
| 121 | Y | IGN F/B |
| 123 | G | PASSENGER DOOR SW |
| 124 | R | REAR DEFOGGER SW |
| 130 | BR | POWER WINDOW SW COMM |
| 132 | G | PUSH-BUTTON IGNITION SW ILL POWER |
| 133 | W | LOOK IND |
| 134 | R | RECEIVER/SENSOR GND |
| 137 | P | RECEIVER/SENSOR POWER SUPPLY |
| 138 | V | TIRE PRESS RECEIVER COMM |
| 139 | G | SECURITY AND ALARM CONT |
| 140 | GR | COMBI SW OUTPUT 1 |
| 141 | O | COMBI SW OUTPUT 5 |
| 142 | L | COMBI SW OUTPUT 1 |
| 143 | W | COMBI SW OUTPUT 2 |
| 144 | P | COMBI SW OUTPUT 3 |
| 145 | V | COMBI SW OUTPUT 4 |
| 146 | Y | DRIVER DOOR SW |
| 150 | SB | REAR WINDOW DEFOGGER RELAY CONT |
| 151 | G | REAR WINDOW DEFOGGER RELAY CONT |

| | |
|----------------|-----------------|
| Connector No. | M174 |
| Connector Name | AV CONTROL UNIT |
| Connector Type | TH32FW-NH |




| Terminal No. | Wire | Signal Name [Specification] |
|--------------|--------|------------------------------------|
| 75 | LG | AV COMM (L) |
| 76 | LG | AV COMM (L) |
| 78 | LG | AV COMM (L) |
| 79 | SR | AV COMM (H) |
| 80 | P | CAN-H |
| 81 | L | CAN-L |
| 82 | V | SW GND |
| 85 | SHIELD | SHIELD |
| 87 | R | TEL VOICE SIGNAL (-) |
| 88 | L | TEL VOICE SIGNAL (+) |
| 92 | V | VEHICLE SPEED SIGNAL (8-PULSE) |
| 93 | G | PARKING BRAKE (Without EBS system) |
| 94 | SB | REVERSE |
| 95 | G | IGNITION |
| 98 | W | DISK EJECT SIGNAL |
| 99 | W | AV COMM (L) |
| 102 | B | AV SOUND SIGNAL (L) |
| 103 | B | AV SOUND SIGNAL (R) |
| 104 | R | AUX SOUND SIGNAL PH (-) |



| | |
|----------------|------------------------------|
| Connector No. | M282 |
| Connector Name | INSIDE KEY ANTENNA (CONSOLE) |
| Connector Type | IK02PGY |

| | |
|----------------|-----------------|
| Connector No. | M180 |
| Connector Name | AV CONTROL UNIT |
| Connector Type | TH32FW-NH |



| Terminal No. | Wire | Signal Name [Specification] |
|--------------|------|-----------------------------|
| 1 | W | - |
| 2 | B | - |

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|--------------------------------|
| 65 | LC | PARKING BRAKE |
| 67 | LG | - |
| 68 | LG | - |
| 71 | SHIELD | - |
| 72 | B | MICROPHONE VCC |
| 73 | R | COMM (CONT-DISP) |
| 74 | P | CAN-L |
| 75 | LG | AV COMM (L) |
| 76 | LG | AV COMM (L) |
| 79 | R | ILLUMINATION SIGNAL |
| 80 | G | IGNITION |
| 81 | SB | REVERSE |
| 82 | V | VEHICLE SPEED SIGNAL (8-PULSE) |
| 83 | B | - |
| 84 | B | MICROPHONE SIGNAL |
| 88 | B | - |
| 89 | W | - |
| 90 | L | CAN-H |
| 91 | SB | AV COMM (H) |
| 92 | SB | AV COMM (H) |

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

WW

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)

| | |
|----------------|-------------------------------------|
| Connector No. | R10 |
| Connector Name | VANITY MIRROR LAMP (PASSENGER SIDE) |
| Connector Type | MICADZFV |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | B | - |
| 2 | P/W | - |

| | |
|----------------|----------|
| Connector No. | R19 |
| Connector Name | MAP LAMP |
| Connector Type | TKGDFCY |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | P/W | - |
| 2 | Y | - |
| 3 | B | - |
| 4 | SB | - |
| 5 | R/Y | - |
| 6 | R/L | - |

| | |
|----------------|---------------|
| Connector No. | R21 |
| Connector Name | PERSONAL LAMP |
| Connector Type | THGDFW-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | P/W | - |
| 2 | B | - |
| 3 | SB | - |

| | |
|----------------|-------------|
| Connector No. | R23 |
| Connector Name | RAIN SENSOR |
| Connector Type | JAABDQFB |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | Y/R | - |
| 2 | R | - |
| 3 | B | - |

| | |
|----------------|----------------------------------|
| Connector No. | R24 |
| Connector Name | VANITY MIRROR LAMP (DRIVER SIDE) |
| Connector Type | MICADZFV |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | P/W | - |
| 2 | P/W | - |

| | |
|----------------|------------------------|
| Connector No. | R101 |
| Connector Name | SUNROOF MOTOR ASSEMBLY |
| Connector Type | YEADDFCY |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | B | GROUND |
| 2 | O | GROUND |
| 3 | L | IGN |
| 4 | Y | PUSH SW |
| 5 | LG | OPEN SW |
| 6 | R | BAT |
| 7 | P | COMM |
| 8 | BR | VEHICLE SPEED (2-PULSE) |
| 9 | W | 2ND SW |
| 10 | V | CLOSE SW |

| | |
|----------------|-------------------------|
| Connector No. | R102 |
| Connector Name | SUNSHADE MOTOR ASSEMBLY |
| Connector Type | YEADDFCY |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 6 | B | GROUND |
| 7 | O | GROUND |
| 8 | P | COMM |
| 8 | BR | VEHICLE SPEED (2-PULSE) |

JRMWE5840GB

INFOID:000000010129280

Fail-safe

FAIL-SAFE CONTROL BY DTC

BCM performs fail-safe control when any DTC are detected.

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Display contents of CONSULT | Fail-safe | Cancellation |
|-----------------------------|---|--|
| B2190: NATS ANTENNA AMP | Inhibit engine cranking | Erase DTC |
| B2191: DIFFERENCE OF KEY | Inhibit engine cranking | Erase DTC |
| B2192: ID DISCORD BCM-ECM | Inhibit engine cranking | Erase DTC |
| B2193: CHAIN OF BCM-ECM | Inhibit engine cranking | Erase DTC |
| B2195: ANTI SCANNING | Inhibit engine cranking | Ignition switch ON → OFF |
| B2560: STARTER CONT RELAY | Inhibit engine cranking | 500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> • Starter control relay signal • Starter relay status signal |
| B2608: STARTER RELAY | Inhibit engine cranking | 500 ms after the following signal communication status becomes consistent <ul style="list-style-type: none"> • Starter motor relay control signal • Starter relay status signal (CAN) |
| B260A: IGNITION RELAY | Inhibit engine cranking | 500 ms after the following conditions are fulfilled <ul style="list-style-type: none"> • IGN relay (IPDM E/R) control signal: OFF (Battery voltage) • Ignition ON signal (CAN to IPDM E/R): OFF (Request signal) • Ignition ON signal (CAN from IPDM E/R): OFF (Condition signal) |
| B260F: ENG STATE SIG LOST | Maintains the power supply position attained at the time of DTC detection | When any of the following conditions are fulfilled <ul style="list-style-type: none"> • Power position changes to ACC • Receives engine status signal (CAN) |
| B2617: STARTER RELAY CIRC | Inhibit engine cranking | 1 second after the starter motor relay control inside BCM becomes normal |
| B2618: BCM | Inhibit engine cranking | 1 second after the ignition relay (IPDM E/R) control inside BCM becomes normal |
| B261E: VEHICLE TYPE | Inhibit engine cranking | BCM initialization |

HIGH FLASHER OPERATION

BCM detects the turn signal lamp circuit status by the current value.

BCM increases the turn signal lamp blinking speed if the bulb or harness open is detected with the turn signal lamp operating.

NOTE:

The blinking speed is normal while activating the hazard warning lamp.

FAIL-SAFE CONTROL BY RAIN SENSOR MALFUNCTION

- BCM judges the rain sensor serial link error by the rain sensor serial link condition and detects the rain sensor malfunction by rain sensor malfunction signal.
- When BCM detects the rain sensor serial link error or the rain sensor malfunction while front wiper AUTO operation, BCM operates a fail-safe control.

NOTE:

If rain sensor malfunction is detected when ignition switch is turned OFF ⇒ ON and front wiper switch is INT/AUTO position, BCM operates a fail-safe control.

REAR WIPER MOTOR PROTECTION

BCM detects the rear wiper stopping position according to the rear wiper stop position signal.

When the rear wiper stop position signal does not change for more than 5 seconds while driving the rear wiper, BCM stops power supply to protect the rear wiper motor.

Condition of cancellation

1. More than 1 minute is passed after the rear wiper stop.
2. Turn rear wiper switch OFF.
3. Operate the rear wiper switch or rear washer switch.

DTC Inspection Priority Chart

INFOID:000000010129281

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Priority | DTC |
|----------|--|
| 1 | B2562: LOW VOLTAGE |
| 2 | <ul style="list-style-type: none"> • U1000: CAN COMM • U1010: CONTROL UNIT(CAN) |
| 3 | <ul style="list-style-type: none"> • B2190: NATS ANTENNA AMP • B2191: DIFFERENCE OF KEY • B2192: ID DISCORD BCM-ECM • B2193: CHAIN OF BCM-ECM • B2195: ANTI SCANNING |
| 4 | <ul style="list-style-type: none"> • B2553: IGNITION RELAY • B2555: STOP LAMP • B2556: PUSH-BTN IGN SW • B2557: VEHICLE SPEED • B2560: STARTER CONT RELAY • B2601: SHIFT POSITION • B2602: SHIFT POSITION • B2603: SHIFT POSI STATUS • B2604: PNP SW • B2605: PNP SW • B2608: STARTER RELAY • B260A: IGNITION RELAY • B260F: ENG STATE SIG LOST • B2614: ACC RELAY CIRC • B2615: BLOWER RELAY CIRC • B2616: IGN RELAY CIRC • B2617: STARTER RELAY CIRC • B2618: BCM • B261A: PUSH-BTN IGN SW • B261E: VEHICLE TYPE • B26EA: KEY REGISTRATION • C1729: VHCL SPEED SIG ERR • U0415: VEHICLE SPEED SIG |
| 5 | <ul style="list-style-type: none"> • C1704: LOW PRESSURE FL • C1705: LOW PRESSURE FR • C1706: LOW PRESSURE RR • C1707: LOW PRESSURE RL • C1708: [NO DATA] FL • C1709: [NO DATA] FR • C1710: [NO DATA] RR • C1711: [NO DATA] RL • C1716: [PRESSDATA ERR] FL • C1717: [PRESSDATA ERR] FR • C1718: [PRESSDATA ERR] RR • C1719: [PRESSDATA ERR] RL • C1734: CONTROL UNIT |
| 6 | <ul style="list-style-type: none"> • B2622: INSIDE ANTENNA • B2623: INSIDE ANTENNA |

DTC Index

INFOID:000000010129282

NOTE:

The details of time display are as follows.

- CRNT: A malfunction is detected now.
- PAST: A malfunction was detected in the past.

IGN counter is displayed on Freeze Frame Data. For details of Freeze Frame Data, refer to [BCS-18. "COMMON ITEM : CONSULT Function \(BCM - COMMON ITEM\)".](#)

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| CONSULT display | Fail-safe | Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition | Intelligent Key warning lamp ON | Tire pressure monitor warning lamp ON | Reference |
|--|-----------|--|---------------------------------|---------------------------------------|------------------------|
| No DTC is detected. further testing may be required. | — | — | — | — | — |
| U1000: CAN COMM | — | — | — | — | BCS-42 |
| U1010: CONTROL UNIT(CAN) | — | — | — | — | BCS-43 |
| U0415: VEHICLE SPEED SIG | — | — | — | — | BCS-44 |
| B2190: NATS ANTENNA AMP | × | — | — | — | SEC-42 |
| B2191: DIFFERENCE OF KEY | × | — | — | — | SEC-45 |
| B2192: ID DISCORD BCM-ECM | × | — | — | — | SEC-46 |
| B2193: CHAIN OF BCM-ECM | × | — | — | — | SEC-48 |
| B2195: ANTI SCANNING | × | — | — | — | SEC-49 |
| B2553: IGNITION RELAY | — | × | — | — | PCS-50 |
| B2555: STOP LAMP | — | × | — | — | SEC-50 |
| B2556: PUSH-BTN IGN SW | — | × | × | — | SEC-52 |
| B2557: VEHICLE SPEED | × | × | × | — | SEC-54 |
| B2560: STARTER CONT RELAY | × | × | × | — | SEC-55 |
| B2562: LOW VOLTAGE | — | × | — | — | BCS-45 |
| B2601: SHIFT POSITION | × | × | × | — | SEC-56 |
| B2602: SHIFT POSITION | × | × | × | — | SEC-59 |
| B2603: SHIFT POSI STATUS | × | × | × | — | SEC-61 |
| B2604: PNP SW | × | × | × | — | SEC-64 |
| B2605: PNP SW | × | × | × | — | SEC-66 |
| B2608: STARTER RELAY | × | × | × | — | SEC-68 |
| B260A: IGNITION RELAY | × | × | × | — | PCS-52 |
| B260F: ENG STATE SIG LOST | × | × | × | — | SEC-70 |
| B2614: ACC RELAY CIRC | — | × | × | — | PCS-54 |
| B2615: BLOWER RELAY CIRC | — | × | × | — | PCS-57 |
| B2616: IGN RELAY CIRC | — | × | × | — | PCS-60 |
| B2617: STARTER RELAY CIRC | × | × | × | — | SEC-72 |
| B2618: BCM | × | × | × | — | PCS-63 |
| B261A: PUSH-BTN IGN SW | — | × | × | — | SEC-75 |
| B261E: VEHICLE TYPE | × | × | × (Turn ON for 15 seconds) | — | SEC-78 |
| B2622: INSIDE ANTENNA | — | × | — | — | DLK-91 |
| B2623: INSIDE ANTENNA | — | × | — | — | DLK-93 |
| B26EA: KEY REGISTRATION | — | × | × (Turn ON for 15 seconds) | — | SEC-71 |
| C1704: LOW PRESSURE FL | — | — | — | × | WT-23 |
| C1705: LOW PRESSURE FR | — | — | — | × | |
| C1706: LOW PRESSURE RR | — | — | — | × | |
| C1707: LOW PRESSURE RL | — | — | — | × | |

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| CONSULT display | Fail-safe | Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition | Intelligent Key warning lamp ON | Tire pressure monitor warning lamp ON | Reference |
|---------------------------|-----------|--|---------------------------------|---------------------------------------|-----------------------|
| C1708: [NO DATA] FL | — | — | — | × | WT-25 |
| C1709: [NO DATA] FR | — | — | — | × | |
| C1710: [NO DATA] RR | — | — | — | × | |
| C1711: [NO DATA] RL | — | — | — | × | |
| C1716: [PRESSDATA ERR] FL | — | — | — | × | WT-28 |
| C1717: [PRESSDATA ERR] FR | — | — | — | × | |
| C1718: [PRESSDATA ERR] RR | — | — | — | × | |
| C1719: [PRESSDATA ERR] RL | — | — | — | × | |
| C1729: VHCL SPEED SIG ERR | — | — | — | × | WT-29 |
| C1734: CONTROL UNIT | — | — | — | × | WT-30 |

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Reference Value

INFOID:000000010129283

VALUES ON THE DIAGNOSIS TOOL

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

| Monitor Item | Condition | | Value/Status |
|---------------|---|---|--------------|
| MOTOR FAN REQ | Engine idle speed | Changes depending on engine coolant temperature, air conditioner operation status, vehicle speed, etc. | 1/2/3/4 |
| AC COMP REQ | Engine running | A/C switch OFF | Off |
| | | A/C switch ON (Compressor is operating) | On |
| TAIL&CLR REQ | Lighting switch OFF | | Off |
| | Lighting switch 1ST, 2ND, HI or AUTO (Light is illuminated) | | On |
| HL LO REQ | Lighting switch OFF | | Off |
| | Lighting switch 2ND HI or AUTO (Light is illuminated) | | On |
| HL HI REQ | Lighting switch OFF | | Off |
| | Lighting switch HI | | On |
| FR FOG REQ | Lighting switch 2ND or AUTO (Light is illuminated) | Front fog lamp switch OFF | Off |
| | | <ul style="list-style-type: none"> • Front fog lamp switch ON • Daytime running light activated (Only for Canada) | On |
| FR WIP REQ | Ignition switch ON | Front wiper switch OFF | Stop |
| | | Front wiper switch INT | 1LOW |
| | | Front wiper switch LO | Low |
| | | Front wiper switch HI | Hi |
| WIP AUTO STOP | Ignition switch ON | Front wiper stop position | STOP P |
| | | Any position other than front wiper stop position | ACT P |
| WIP PROT | Ignition switch ON | Front wiper operates normally | Off |
| | | Front wiper stops at fail-safe operation | BLOCK |
| IGN RLY1 -REQ | Ignition switch OFF or ACC | | Off |
| | Ignition switch ON | | On |
| IGN RLY | Ignition switch OFF or ACC | | Off |
| | Ignition switch ON | | On |
| PUSH SW | Release the push-button ignition switch | | Off |
| | Press the push-button ignition switch | | On |
| INTER/NP SW | Ignition switch ON | Selector lever in any position other than P or N | Off |
| | | Selector lever in P or N position | On |
| ST RLY CONT | Ignition switch ON | | Off |
| | At engine cranking | | On |

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)


< ECU DIAGNOSIS INFORMATION >

| Monitor Item | Condition | Value/Status |
|----------------|--|--|
| IHBT RLY -REQ | Ignition switch ON | Off |
| | At engine cranking | On |
| ST/INHI RLY | Ignition switch ON | Off |
| | At engine cranking | INHI ON → ST ON |
| | The status of starter relay or starter control relay cannot be recognized by the battery voltage malfunction, etc. when the starter relay is ON and the starter control relay is OFF | UNKWN |
| DETENT SW | Ignition switch ON | <ul style="list-style-type: none"> • Press the selector button with selector lever in P position • Selector lever in any position other than P |
| | Release the selector button with selector lever in P position | On |
| S/L RLY -REQ | NOTE: The item is indicated, but not monitored. | Off |
| S/L STATE | NOTE: The item is indicated, but not monitored. | UNLOCK |
| DTRL REQ | NOTE: The item is indicated, but not monitored. | Off |
| OIL P SW | Ignition switch OFF, ACC or engine running | Open |
| | Ignition switch ON | Close |
| HOOD SW | NOTE: The item is indicated, but not monitored. | Off |
| HL WASHER REQ | NOTE: The item is indicated, but not monitored. | Off |
| THFT HRN REQ | Not operating | Off |
| | <ul style="list-style-type: none"> • Panic alarm is activated • Horn is activated with VEHICLE SECURITY (THEFT WARNING) SYSTEM | On |
| HORN CHIRP | Not operating | Off |
| | Door locking with Intelligent Key (horn chirp mode) | On |
| CRNRNG LMP REQ | NOTE: The item is indicated, but not monitored. | Off |

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

TERMINAL LAYOUT



PHYSICAL VALUES


| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|---|------------------|---|------------------------|--------------------|
| + | - | Signal name | Input/ Output | | | |
| 1 (R) | Ground | Battery power supply | Input | Ignition switch OFF | | Battery voltage |
| 2 (L) | Ground | Battery power supply | Input | Ignition switch OFF | | Battery voltage |
| 4 (LG) | Ground | Front wiper LO | Output | Ignition switch OFF | Front wiper switch OFF | 0 V |
| | | | | Ignition switch ON | Front wiper switch LO | Battery voltage |
| 5 (Y) | Ground | Front wiper HI | Output | Ignition switch OFF | Front wiper switch OFF | 0 V |
| | | | | Ignition switch ON | Front wiper switch HI | Battery voltage |
| 7 (GR) | Ground | Tail, license plate lamps & illuminations | Output | Ignition switch OFF | Lighting switch OFF | 0 V |
| | | | | Ignition switch ON | Lighting switch 1ST | Battery voltage |
| 10 (BR) | Ground | ECM relay power supply | Output | Ignition switch OFF (More than a few seconds after turning ignition switch OFF) | | 0 V |
| | | | | <ul style="list-style-type: none"> Ignition switch ON Ignition switch OFF (For a few seconds after turning ignition switch OFF) | | Battery voltage |
| 12 (B) | Ground | Ground | — | Ignition switch ON | | 0 V |

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

WW

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|--|------------------|---|---|--|
| + | - | Signal name | Input/ Output | | | |
| 13 (SB) | Ground | Fuel pump power supply | Output | Approximately 1 second or more after turning the ignition switch ON | | 0 V |
| | | | | <ul style="list-style-type: none"> • Approximately 1 second after turning the ignition switch ON • Engine running | | Battery voltage |
| 15 (W) | Ground | Ignition relay power supply | Output | Ignition switch OFF | | 0 V |
| | | | | Ignition switch ON | | Battery voltage |
| 16 (R) | Ground | Front wiper auto stop | Input | Ignition switch ON | Front wiper stop position | 0 V |
| | | | | | Any position other than front wiper stop position | Battery voltage |
| 19 (Y) | Ground | Ignition relay power supply | Output | Ignition switch OFF | | 0 V |
| | | | | Ignition switch ON | | Battery voltage |
| 20 (L) | Ground | Ambient sensor ground | Output | Ignition switch ON | | 0 V |
| 21 (O) | Ground | Ambient sensor | Input | Ignition switch ON NOTE: Changes depending to ambient temperature | |  <p style="text-align: right; font-size: small;">JSNIA0014GB</p> |
| 22 (SB) | Ground | Refrigerant pressure sensor ground | Output | Engine running | <ul style="list-style-type: none"> • Warm-up condition • Idle speed | 0 V |
| 23 (GR) | Ground | Refrigerant pressure sensor | Output | Engine running | <ul style="list-style-type: none"> • Warm-up condition • Both A/C switch and blower fan motor switch ON (Compressor operates) | 1.0 - 4.0 V |
| 24 (G) | Ground | Refrigerant pressure sensor power supply | Input | Ignition switch OFF | | 0 V |
| | | | | Ignition switch ON | | 5.0 V |
| 25 (GR) | Ground | Ignition relay power supply | Output | Ignition switch OFF | | 0 V |
| | | | | Ignition switch ON | | Battery voltage |
| 26*1 (Y) | Ground | Ignition relay power supply | Output | Ignition switch OFF | | 0 V |
| | | | | Ignition switch ON | | Battery voltage |
| 27 (W) | Ground | Ignition relay monitor | Input | Ignition switch OFF or ACC | | Battery voltage |
| | | | | Ignition switch ON | | 0 V |
| 28 (SB) | Ground | Push-button ignition switch | Input | Press the push-button ignition switch | | 0 V |
| | | | | Release the push-button ignition switch | | Battery voltage |
| 30 (BR) | Ground | Starter relay control | Input | Ignition switch ON | Selector lever in any position other than P or N | 0 V |
| | | | | | Selector lever P or N | Battery voltage |
| 34 (O) | Ground | Cooling fan relay-3 control | Input | Cooling fan stopped | | Battery voltage |
| | | | | Cooling fan at HI operation | | 0 V |
| 35 (P) | Ground | Cooling fan relay-1 power supply | Input | Cooling fan stopped | | Battery voltage |
| | | | | Cooling fan at LO operation | | 6.0 V |
| 36 (G) | Ground | Battery power supply | Input | Ignition switch OFF | | Battery voltage |

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | | |
|------------------------------|--------|---------------------------------------|------------------|---|---|-----------------|---|
| + | - | Signal name | Input/ Output | | | | |
| 38 (GR) | Ground | Cooling fan relay-1 power supply | Output | Cooling fan not operating | 0 V | A | |
| | | | | Cooling fan at LO operation | 6.0 V | B | |
| 39 (P) | — | CAN-L | Input/ Output | — | — | C | |
| 40 (L) | — | CAN-H | Input/ Output | — | — | | |
| 41 (B) | Ground | Ground | — | Ignition switch ON | 0 V | D | |
| 42 (SB) | Ground | Cooling fan relay-2 control | Input | Cooling fan stopped | Battery voltage | | |
| | | | | <ul style="list-style-type: none"> Cooling fan MID operating Cooling fan HI operating | 0 V | E | |
| 43 (Y) | Ground | CVT shift selector (Detention switch) | Input | Ignition switch ON | <ul style="list-style-type: none"> Press the selector button (selector lever P) Selector lever in any position other than P | Battery voltage | F |
| | | | | | Release the selector button (selector lever P) | 0 V | G |
| 44 (W) | Ground | Horn relay control | Input | The horn is deactivated | Battery voltage | | |
| | | | | The horn is activated | 0 V | H | |
| 45 (G) | Ground | Horn switch | Input | The horn is deactivated | Battery voltage | | |
| | | | | The horn is activated | 0 V | I | |
| 46 (BR) | Ground | Starter relay control | Input | Ignition switch ON | <ul style="list-style-type: none"> Selector lever in any position other than P or N | 0 V | J |
| | | | | | Selector lever P or N | Battery voltage | |
| 48 (W) | Ground | A/C relay power supply | Output | Engine running | A/C switch OFF | 0 V | |
| | | | | | A/C switch ON (A/C compressor is operating) | Battery voltage | K |
| 49 (R/B) | Ground | ECM relay power supply | Output | Ignition switch OFF (More than a few seconds after turning ignition switch OFF) | 0 V | | |
| | | | | <ul style="list-style-type: none"> Ignition switch ON Ignition switch OFF (For a few seconds after turning ignition switch OFF) | Battery voltage | WW | |
| 51 (LG) | Ground | Ignition relay power supply | Output | Ignition switch OFF | 0 V | | |
| | | | | Ignition switch ON | Battery voltage | M | |
| 52 (Y/G) | Ground | Ignition relay power supply | Output | Ignition switch OFF | 0 V | N | |
| | | | | Ignition switch ON | Battery voltage | | |
| 53 (R/W) | Ground | ECM relay power supply | Output | Ignition switch OFF (More than a few seconds after turning ignition switch OFF) | 0 V | O | |
| | | | | <ul style="list-style-type: none"> Ignition switch ON Ignition switch OFF (For a few seconds after turning ignition switch OFF) | Battery voltage | P | |

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|--|------------------|---|---|
| + | - | Signal name | Input/ Output | | |
| 54 (G/W) | Ground | Throttle control motor re- lay power supply | Output | Ignition switch OFF (More than a few seconds after turning ignition switch OFF) | 0 V |
| | | | | <ul style="list-style-type: none"> Ignition switch ON Ignition switch OFF (For a few seconds after turning igni- tion switch OFF) | Battery voltage |
| 55 (W/L) | Ground | ECM power supply | Output | Ignition switch OFF | Battery voltage |
| 56 (R/Y) | Ground | Ignition relay power supply | Output | Ignition switch OFF | 0 V |
| | | | | Ignition switch ON | Battery voltage |
| 57 (O) | Ground | Ignition relay power supply | Output | Ignition switch OFF | 0 V |
| | | | | Ignition switch ON | Battery voltage |
| 58 (Y) | Ground | Ignition relay power supply | Output | Ignition switch OFF | 0 V |
| | | | | Ignition switch ON | Battery voltage |
| 69 (W/B) | Ground | ECM relay control | Output | Ignition switch OFF (More than a few seconds after turning ignition switch OFF) | Battery voltage |
| | | | | <ul style="list-style-type: none"> Ignition switch ON Ignition switch OFF (For a few seconds after turning igni- tion switch OFF) | 0 - 1.5 V |
| 70 (O) | Ground | Throttle control motor re- lay control | Output | Ignition switch ON → OFF | 0 - 1.0 V ↓ Battery voltage ↓ 0 V |
| | | | | Ignition switch ON | 0 - 1.0 V |
| 72 (R/B) | Ground | Starter relay control | Input | Ignition switch ON | Selector lever in any posi- tion other than P or N |
| | | | | | Selector lever P or N |
| 75 (LG) | Ground | Oil pressure switch | Input | Ignition switch ON | Engine stopped |
| | | | | | Engine running |

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|---------------------------------|------------------|---|---|------------------------------|
| + | - | Signal name | Input/ Output | | | |
| 76 (SB) | Ground | Power generation command signal | Output | Ignition switch ON | | <p>JPMIA0001GB 6.3 V</p> |
| | | | | 40% is set on "ACTIVE TEST", "ALTERNATOR DUTY" of "ENGINE" | | <p>JPMIA0002GB 3.8 V</p> |
| | | | | 80% is set on "ACTIVE TEST", "ALTERNATOR DUTY" of "ENGINE" | | <p>JPMIA0003GB 1.4 V</p> |
| 77 (GR) | Ground | Fuel pump relay control | Output | <ul style="list-style-type: none"> Approximately 1 second after turning the ignition switch ON Engine running | | 0 - 1.5 V |
| | | | | Approximately 1 second or more after turning the ignition switch ON | | Battery voltage |
| 80 (B) | Ground | Starter motor | Output | At engine cranking | | Battery voltage |
| 83 (Y) | Ground | Headlamp LO (RH) | Output | Ignition switch ON | Lighting switch OFF | 0 V |
| | | | | | Lighting switch 2ND | Battery voltage |
| 84 (L) | Ground | Headlamp LO (LH) | Output | Ignition switch ON | Lighting switch OFF | 0 V |
| | | | | | Lighting switch 2ND | Battery voltage |
| 86 (SB) | Ground | Front fog lamp (RH) | Output | Lighting switch 2ND | Front fog lamp switch OFF | 0 V |
| | | | | | <ul style="list-style-type: none"> Front fog lamp switch ON Daytime running light activated (Only for Canada) | Battery voltage |
| 87 (GR) | Ground | Front fog lamp (LH) | Output | Lighting switch 2ND | Front fog lamp switch OFF | 0 V |
| | | | | | <ul style="list-style-type: none"> Front fog lamp switch ON Daytime running light activated (Only for Canada) | Battery voltage |
| 88 (W) | Ground | Washer pump power supply | Output | Ignition switch ON | | Battery voltage |

A

B

C

D

E

F

G

H

I

J

K

WW

M


N

O

P

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|--|------------------|--|---|--|
| + | - | Signal name | Input/ Output | | | |
| 89 (L) | Ground | Headlamp HI (RH) | Output | Ignition switch ON | Lighting switch OFF | 0 V |
| | | | | | <ul style="list-style-type: none"> • Lighting switch HI • Lighting switch PASS | Battery voltage |
| 90 (G) | Ground | Headlamp HI (LH) | Output | Ignition switch ON | Lighting switch OFF | 0 V |
| | | | | | <ul style="list-style-type: none"> • Lighting switch HI • Lighting switch PASS | Battery voltage |
| 91 (R) | Ground | Parking lamp (RH) | Output | Ignition switch ON | Lighting switch OFF | 0 V |
| | | | | | Lighting switch 1ST | Battery voltage |
| 92 (LG) | Ground | Parking lamp (LH) | Output | Ignition switch ON | Lighting switch OFF | 0 V |
| | | | | | Lighting switch 1ST | Battery voltage |
| 99 (BR) | Ground | Ambient sensor ground | Input | Ignition switch ON | | 0 V |
| 100 (SB) | Ground | Ambient sensor | Output | Ignition switch ON NOTE: Changes depending to ambient temperature | |  <p style="text-align: center;">JSNIA0014GB</p> |
| 101 (L) | Ground | Refrigerant pressure sensor ground | Input | Engine running | <ul style="list-style-type: none"> • Warm-up condition • Idle speed | 0 V |
| 102 (B) | Ground | Refrigerant pressure sensor | Input | Engine running | <ul style="list-style-type: none"> • Warm-up condition • Both A/C switch and blower fan motor switch ON (Compressor operates) | 1.0 - 4.0 V |
| 103 (P) | Ground | Refrigerant pressure sensor power supply | Output | Ignition switch OFF | | 0 V |
| | | | | Ignition switch ON | | 5.0 V |


*1: AWD models only

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

Wiring Diagram - IPDM E/R -

INFOID:000000010129284



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


WW

2011/07/28

JRMWC5029GB

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >




JRMWC5030GB

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

A
B
C
D
E
F
G
H
I
J
K
WW
M
N
O
P



IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

| IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) | | |
|--|-----|-----|
| Connector No. | E9 | ES |
| Color | BR | GR |
| Wire | 32 | 58 |
| Terminal No. | 34 | 58 |
| Color | O | L |
| Wire | 35 | G |
| Terminal No. | 36 | 69 |
| Color | G | W/B |
| Wire | 38 | 70 |
| Terminal No. | 38 | 72 |
| Color | GR | R/B |
| Wire | --- | --- |
| Terminal No. | --- | 75 |
| Color | --- | LG |
| Wire | --- | 76 |
| Terminal No. | --- | 77 |
| Color | --- | GR |
| Wire | --- | 80 |
| Terminal No. | --- | --- |
| Color | --- | B |
| Wire | --- | --- |

| IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) | | |
|--|-----|------|
| Connector No. | E10 | E346 |
| Color | BR | GR |
| Wire | 42 | 58 |
| Terminal No. | 41 | 58 |
| Color | B | L |
| Wire | 43 | G |
| Terminal No. | 44 | 69 |
| Color | Y | W/B |
| Wire | 45 | 70 |
| Terminal No. | 46 | 72 |
| Color | BR | R/B |
| Wire | --- | --- |
| Terminal No. | --- | 75 |
| Color | --- | LG |
| Wire | --- | 76 |
| Terminal No. | --- | 77 |
| Color | --- | GR |
| Wire | --- | 80 |
| Terminal No. | --- | --- |
| Color | --- | B |
| Wire | --- | --- |

| IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) | | |
|--|-----|------|
| Connector No. | E11 | E348 |
| Color | BR | GR |
| Wire | 42 | 58 |
| Terminal No. | 41 | 58 |
| Color | B | L |
| Wire | 43 | G |
| Terminal No. | 44 | 69 |
| Color | Y | W/B |
| Wire | 45 | 70 |
| Terminal No. | 46 | 72 |
| Color | BR | R/B |
| Wire | --- | --- |
| Terminal No. | --- | 75 |
| Color | --- | LG |
| Wire | --- | 76 |
| Terminal No. | --- | 77 |
| Color | --- | GR |
| Wire | --- | 80 |
| Terminal No. | --- | --- |
| Color | --- | B |
| Wire | --- | --- |

| IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) | | |
|--|-----|------|
| Connector No. | E12 | E345 |
| Color | BR | GR |
| Wire | 42 | 58 |
| Terminal No. | 41 | 58 |
| Color | B | L |
| Wire | 43 | G |
| Terminal No. | 44 | 69 |
| Color | Y | W/B |
| Wire | 45 | 70 |
| Terminal No. | 46 | 72 |
| Color | BR | R/B |
| Wire | --- | --- |
| Terminal No. | --- | 75 |
| Color | --- | LG |
| Wire | --- | 76 |
| Terminal No. | --- | 77 |
| Color | --- | GR |
| Wire | --- | 80 |
| Terminal No. | --- | --- |
| Color | --- | B |
| Wire | --- | --- |

| IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) | | |
|--|-----|------|
| Connector No. | E13 | E345 |
| Color | BR | GR |
| Wire | 42 | 58 |
| Terminal No. | 41 | 58 |
| Color | B | L |
| Wire | 43 | G |
| Terminal No. | 44 | 69 |
| Color | Y | W/B |
| Wire | 45 | 70 |
| Terminal No. | 46 | 72 |
| Color | BR | R/B |
| Wire | --- | --- |
| Terminal No. | --- | 75 |
| Color | --- | LG |
| Wire | --- | 76 |
| Terminal No. | --- | 77 |
| Color | --- | GR |
| Wire | --- | 80 |
| Terminal No. | --- | --- |
| Color | --- | B |
| Wire | --- | --- |

JRMWE5847GB

INFOID:000000010129285

Fail-safe

CAN COMMUNICATION CONTROL

When CAN communication with ECM and BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If No CAN Communication Is Available With ECM

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

| Control part | Fail-safe operation |
|----------------|---|
| Cooling fan | <ul style="list-style-type: none"> • Turns ON the cooling fan relay-2 and the cooling fan relay-3 when ignition switch is turned ON (Cooling fan operates at HI) • Turns OFF the cooling fan relay-1, the cooling fan relay-2 and the cooling fan relay-3 when the ignition switch is turned OFF (Cooling fan does not operate) |
| A/C compressor | A/C relay OFF |
| Alternator | Outputs the power generation command signal (PWM signal) 0% |

If No CAN Communication Is Available With BCM

| Control part | Fail-safe operation |
|---|---|
| Headlamp | <ul style="list-style-type: none"> • Turns ON the headlamp low relay when the ignition switch is turned ON • Turns OFF the headlamp low relay when the ignition switch is turned OFF • Headlamp high relay OFF |
| <ul style="list-style-type: none"> • Parking lamps • License plate lamps • Side maker lamps • Illuminations • Tail lamps | <ul style="list-style-type: none"> • Turns ON the tail lamp relay when the ignition switch is turned ON • Turns OFF the tail lamp relay when the ignition switch is turned OFF |
| Front wiper | <ul style="list-style-type: none"> • The status just before activation of fail-safe control is maintained until the ignition switch is turned OFF while the front wiper is operating at LO or HI speed. • The wiper is operated at LO speed until the ignition switch is turned OFF if the fail-safe control is activated while the front wiper is set in the INT/AUTO mode and the front wiper motor is operating. |
| Front fog lamps | Front fog lamp relay OFF |
| Horn | Horn OFF |
| Ignition relay | The status just before activation of fail-safe is maintained. |
| Starter motor | Starter control relay OFF |

IGNITION RELAY MALFUNCTION DETECTION FUNCTION

- IPDM E/R monitors the voltage at the contact circuit and excitation coil circuit of the ignition relay inside it.
- IPDM E/R judges the ignition relay error if the voltage differs between the contact circuit and the excitation coil circuit.
- If the ignition relay cannot turn OFF due to contact seizure, it activates the tail lamp relay for 10 minutes to alert the user to the ignition relay malfunction when the ignition switch is turned OFF.

| Voltage judgment | | IPDM E/R judgment | Operation |
|-----------------------------|-------------------------------------|---------------------------|--|
| Ignition relay contact side | Ignition relay excitation coil side | | |
| ON | ON | Ignition relay ON normal | — |
| OFF | OFF | Ignition relay OFF normal | — |
| ON | OFF | Ignition relay ON stuck | <ul style="list-style-type: none"> • Detects DTC "B2098: IGN RELAY ON" • Turns ON the tail lamp relay for 10 minutes |
| OFF | ON | Ignition relay OFF stuck | Detects DTC "B2099: IGN RELAY OFF" |

FRONT WIPER CONTROL

IPDM E/R detects front wiper stop position by a front wiper auto stop signal.

When a front wiper stop position signal is in the conditions listed below, IPDM E/R stops power supply to wiper after repeating a front wiper 10 seconds activation and 20 seconds stop five times.

| Ignition switch | Front wiper switch | Front wiper stop position signal |
|-----------------|--------------------|--|
| ON | OFF | The front wiper stop position signal (stop position) cannot be input for 10 seconds. |
| | ON | The front wiper auto stop signal does not change for 10 seconds. |

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

NOTE:

This operation status can be confirmed on the IPDM E/R “Data Monitor” that displays “BLOCK” for the item “WIP PROT” while the wiper is stopped.

STARTER MOTOR PROTECTION FUNCTION

IPDM E/R turns OFF the starter control relay to protect the starter motor when the starter control relay remains active for 90 seconds.

DTC Index

INFOID:000000010129286

NOTE:

- The details of time display are as follows.
 - CRNT: A malfunction is detected now.
 - PAST: A malfunction was detected in the past.
- IGN counter is displayed on FFD (Freeze Frame data).
 - The number is 0 when is detected now.
 - The number increases like 1 → 2 ... 38 → 39 after returning to the normal condition whenever IGN OFF → ON.
 - The number is fixed to 39 until the self-diagnosis results are erased if it is over 39.

×: Applicable

| CONSULT display | Fail-safe | Refer to |
|--|-----------|------------------------|
| No DTC is detected. further testing may be required. | — | — |
| U1000: CAN COMM CIRCUIT | × | PCS-15 |
| B2098: IGN RELAY ON CIRC | × | PCS-16 |
| B2099: IGN RELAY OFF CIRC | — | PCS-18 |
| B210B: STR CONT RLY ON CIRC | — | SEC-79 |
| B210C: STR CONT RLY OFF CIRC | — | SEC-80 |
| B210D: STARTER RLY ON CIRC | — | SEC-81 |
| B210E: STARTER RLY OFF CIRC | — | SEC-83 |
| B210F: INTRLCK/PNP SW ON | — | SEC-85 |
| B2110: INTRLCK/PNP SW OFF | — | SEC-87 |

WIPER AND WASHER SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

WIPER AND WASHER SYSTEM SYMPTOMS WITH RAIN SENSOR

WITH RAIN SENSOR : Symptom Table

INFOID:000000009719757

CAUTION:

Perform the self-diagnosis with CONSULT before performing the diagnosis by symptom. Perform the diagnosis by DTC if DTC is detected.

| Symptom | | Probable malfunction location | Inspection item |
|-------------------------------|-----------------------------------|---|--|
| Front wiper does not operate. | HI only | <ul style="list-style-type: none"> Combination switch Harness between combination switch and BCM BCM | Combination switch Refer to BCS-94, "Symptom Table" . |
| | | <ul style="list-style-type: none"> IPDM E/R Harness between IPDM E/R and front wiper motor Front wiper motor | Front wiper motor (HI) circuit Refer to WW-32, "Component Function Check" . |
| | | Front wiper request signal <ul style="list-style-type: none"> BCM IPDM E/R | IPDM E/R DATA MONITOR "FR WIP REQ" |
| | LO only | <ul style="list-style-type: none"> Combination switch Harness between combination switch and BCM BCM | Combination switch Refer to BCS-94, "Symptom Table" . |
| | | <ul style="list-style-type: none"> IPDM E/R Harness between IPDM E/R and front wiper motor Front wiper motor | Front wiper motor (LO) circuit Refer to WW-30, "Component Function Check" . |
| | | Front wiper request signal <ul style="list-style-type: none"> BCM IPDM E/R | IPDM E/R DATA MONITOR "FR WIP REQ" |
| | INT/AUTO only (Auto operation) | <ul style="list-style-type: none"> Combination switch Harness between combination switch and BCM BCM | Combination switch Refer to BCS-94, "Symptom Table" . |
| | | <ul style="list-style-type: none"> Rain sensor Harness between rain sensor and BCM BCM | Rain sensor Refer to WW-38, "Component Function Check" . |
| | HI, LO and INT/AUTO | SYMPTOM DIAGNOSIS "FRONT WIPER DOES NOT OPERATE" Refer to WW-123, "Diagnosis Procedure" . | |

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

WW

WIPER AND WASHER SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

| Symptom | Probable malfunction location | Inspection item | |
|---|--|--|---|
| Front wiper does not stop. | HI only | <ul style="list-style-type: none"> • Combination switch • BCM | Combination switch Refer to BCS-94, "Symptom Table" . |
| | | <ul style="list-style-type: none"> Front wiper request signal • BCM • IPDM E/R | IPDM E/R DATA MONITOR "FR WIP REQ" |
| | | IPDM E/R | — |
| | LO only | <ul style="list-style-type: none"> • Combination switch • BCM | Combination switch Refer to BCS-94, "Symptom Table" . |
| | | <ul style="list-style-type: none"> Front wiper request signal • BCM • IPDM E/R | IPDM E/R DATA MONITOR "FR WIP REQ" |
| | | IPDM E/R | — |
| | INT/AUTO only (Auto operation) | <ul style="list-style-type: none"> • Combination switch • BCM | Combination switch Refer to BCS-94, "Symptom Table" . |
| | | <ul style="list-style-type: none"> • Rain sensor • Harness between rain sensor and BCM • BCM | Rain sensor Refer to WW-38, "Component Function Check" . |
| | Front wiper does not operate normally. | Sensitivity setting cannot be performed. | <ul style="list-style-type: none"> • Combination switch • Harness between combination switch and BCM • BCM |
| BCM | | | — |
| Wiper is not linked to the washer operation. | | <ul style="list-style-type: none"> • Combination switch • Harness between combination switch and BCM • BCM | Combination switch Refer to BCS-94, "Symptom Table" . |
| | | BCM | — |
| Does not return to stop position. [Repeatedly operates for 10 seconds and then stops for 20 seconds. After that, it stops the operation. (Fail-safe)] | | <ul style="list-style-type: none"> • IPDM E/R • Harness between IPDM E/R and front wiper motor • Front wiper motor | Front wiper stop position signal circuit Refer to WW-34, "Component Function Check" . |
| Rear wiper does not operate. | | ON only | <ul style="list-style-type: none"> • Combination switch • Harness between combination switch and BCM • BCM |
| | INT only | <ul style="list-style-type: none"> • Combination switch • Harness between combination switch and BCM • BCM | Combination switch Refer to BCS-94, "Symptom Table" . |
| | ON and INT | <ul style="list-style-type: none"> • Combination switch • Harness between combination switch and BCM • BCM | Combination switch Refer to BCS-94, "Symptom Table" . |
| | | <ul style="list-style-type: none"> • BCM • Harness between rear wiper motor and BCM • Harness between rear wiper motor and ground • Rear wiper motor | Rear wiper motor circuit Refer to WW-40, "Component Function Check" . |
| Rear wiper does not stop. | ON only | <ul style="list-style-type: none"> • Combination switch • BCM | Combination switch Refer to BCS-94, "Symptom Table" . |
| | INT only | <ul style="list-style-type: none"> • Combination switch • BCM | Combination switch Refer to BCS-94, "Symptom Table" . |

WIPER AND WASHER SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

| Symptom | | Probable malfunction location | Inspection item |
|---|---|---|--|
| Rear wiper does not operate normally. | Wiper is not linked to the washer operation. | <ul style="list-style-type: none"> Combination switch Harness between rear wiper motor and BCM BCM | Combination switch Refer to BCS-94, "Symptom Table" . |
| | | BCM | — |
| | Rear wiper does not return to the stop position. [Stops after a five-second operation. (Fail-safe)] | <ul style="list-style-type: none"> BCM Harness between rear wiper motor and BCM Rear wiper motor | Rear wiper stop position signal circuit Refer to WW-42, "Component Function Check" . |
| Rear washer is in the active condition, but washer fluid is sprayed from rear view camera side. | | Washer switching solenoid valve | Washer switching solenoid valve circuit Refer to DAS-83, "Component Function Check" . |

WITHOUT RAIN SENSOR

WITHOUT RAIN SENSOR : Symptom Table

INFOID:000000009719758

CAUTION:

Perform the self-diagnosis with CONSULT before performing the diagnosis by symptom. Perform the diagnosis by DTC if DTC is detected.

| Symptom | | Probable malfunction location | Inspection item |
|-------------------------------|----------------|---|--|
| Front wiper does not operate. | HI only | <ul style="list-style-type: none"> Combination switch Harness between combination switch and BCM BCM | Combination switch Refer to BCS-94, "Symptom Table" . |
| | | <ul style="list-style-type: none"> IPDM E/R Harness between IPDM E/R and front wiper motor Front wiper motor | Front wiper motor (HI) circuit Refer to WW-32, "Component Function Check" . |
| | | Front wiper request signal <ul style="list-style-type: none"> BCM IPDM E/R | IPDM E/R DATA MONITOR "FR WIP REQ" |
| | LO and INT | <ul style="list-style-type: none"> Combination switch Harness between combination switch and BCM BCM | Combination switch Refer to BCS-94, "Symptom Table" . |
| | | <ul style="list-style-type: none"> IPDM E/R Harness between IPDM E/R and front wiper motor Front wiper motor | Front wiper motor (LO) circuit Refer to WW-30, "Component Function Check" . |
| | | Front wiper request signal <ul style="list-style-type: none"> BCM IPDM E/R | IPDM E/R DATA MONITOR "FR WIP REQ" |
| | INT only | <ul style="list-style-type: none"> Combination switch Harness between combination switch and BCM BCM | Combination switch Refer to BCS-94, "Symptom Table" . |
| | | Front wiper request signal <ul style="list-style-type: none"> BCM IPDM E/R | IPDM E/R DATA MONITOR "FR WIP REQ" |
| | HI, LO and INT | SYMPTOM DIAGNOSIS "FRONT WIPER DOES NOT OPERATE" Refer to WW-123, "Diagnosis Procedure" . | |

WIPER AND WASHER SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

| Symptom | Probable malfunction location | Inspection item | |
|---|---|--|---|
| Front wiper does not stop. | HI only | <ul style="list-style-type: none"> • Combination switch • BCM | Combination switch Refer to BCS-94, "Symptom Table" . |
| | | Front wiper request signal <ul style="list-style-type: none"> • BCM • IPDM E/R | IPDM E/R DATA MONITOR "FR WIP REQ" |
| | | IPDM E/R | — |
| | LO only | <ul style="list-style-type: none"> • Combination switch • BCM | Combination switch Refer to BCS-94, "Symptom Table" . |
| | | Front wiper request signal <ul style="list-style-type: none"> • BCM • IPDM E/R | IPDM E/R DATA MONITOR "FR WIP REQ" |
| | | IPDM E/R | — |
| | INT only | <ul style="list-style-type: none"> • Combination switch • BCM | Combination switch Refer to BCS-94, "Symptom Table" . |
| | | Front wiper request signal <ul style="list-style-type: none"> • BCM • IPDM E/R | IPDM E/R DATA MONITOR "FR WIP REQ" |
| | Front wiper does not operate normally. | Intermittent adjustment cannot be performed. | <ul style="list-style-type: none"> • Combination switch • Harness between combination switch and BCM • BCM |
| BCM | | | — |
| Intermittent control linked with vehicle speed cannot be performed. | | Check the vehicle speed detection wiper setting. Refer to WW-20, "WIPER : CONSULT Function (BCM - WIPER)" . NOTE: Factory setting of the front wiper intermitted operation is the operation without vehicle speed. | |
| Wiper is not linked to the washer operation. | | <ul style="list-style-type: none"> • Combination switch • Harness between combination switch and BCM • BCM | Combination switch Refer to BCS-94, "Symptom Table" . |
| | | BCM | — |
| Does not return to stop position. [Repeatedly operates for 10 seconds and then stops for 20 seconds. After that, it stops the operation. (Fail-safe)] | <ul style="list-style-type: none"> • IPDM E/R • Harness between IPDM E/R and front wiper motor • Front wiper motor | Front wiper stop position signal circuit Refer to WW-34, "Component Function Check" . | |
| Rear wiper does not operate. | ON only | <ul style="list-style-type: none"> • Combination switch • Harness between combination switch and BCM • BCM | Combination switch Refer to BCS-94, "Symptom Table" . |
| | INT only | <ul style="list-style-type: none"> • Combination switch • Harness between combination switch and BCM • BCM | Combination switch Refer to BCS-94, "Symptom Table" . |
| | ON and INT | <ul style="list-style-type: none"> • Combination switch • Harness between combination switch and BCM • BCM | Combination switch Refer to BCS-94, "Symptom Table" . |
| | | <ul style="list-style-type: none"> • BCM • Harness between rear wiper motor and BCM • Harness between rear wiper motor and ground • Rear wiper motor | Rear wiper motor circuit Refer to WW-40, "Component Function Check" . |

WIPER AND WASHER SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

| Symptom | | Probable malfunction location | Inspection item |
|---|----------|---|--|
| Rear wiper does not stop. | ON only | <ul style="list-style-type: none"> • Combination switch • BCM | Combination switch Refer to BCS-94, "Symptom Table" . |
| | INT only | <ul style="list-style-type: none"> • Combination switch • BCM | Combination switch Refer to BCS-94, "Symptom Table" . |
| Rear washer is in the active condition, but washer fluid is sprayed from rear view camera side. | | Washer switching solenoid valve | Washer switching solenoid valve circuit Refer to DAS-83, "Component Function Check" |

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

WW

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

NORMAL OPERATING CONDITION

Description

INFOID:000000009719759

FRONT WIPER MOTOR PROTECTION FUNCTION

- IPDM E/R may stop the front wiper to protect the front wiper motor if any obstruction (operation resistance) such as a large amount of snow is detected during the front wiper operation.
- At that time turn OFF the front wiper and remove the foreign object. Then wait for approximately 20 seconds or more and reactivate the front wiper. The wiper will operate normally.

REAR WIPER MOTOR PROTECTION FUNCTION

- BCM may stop rear wiper to protect the rear wiper motor when the rear wiper is stopped for 5 seconds or more due to a snowfall.
- Rear wiper operates normally one minute after the obstacles are removed with rear wiper OFF.

FRONT WIPER DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

FRONT WIPER DOES NOT OPERATE

Description

INFOID:000000009719760

The front wiper does not operate under any operation conditions.

Diagnosis Procedure

INFOID:000000009719761

1. CHECK WIPER RELAY OPERATION

IPDM E/R AUTO ACTIVE TEST

1. Start IPDM E/R auto active test. Refer to [PCS-10, "Diagnosis Description"](#).
2. Check that the front wiper operates at the LO/Hi operation.

CONSULT ACTIVE TEST

1. Select "FRONT WIPER" of IPDM E/R active test item.
2. With operating the test item, check front wiper operation.

Lo : Front wiper LO operation

Hi : Front wiper HI operation

Off : Stop the front wiper.

Is front wiper operation normally?

YES >> GO TO 5.

NO >> GO TO 2.

2. CHECK FRONT WIPER MOTOR FUSE

1. Turn the ignition switch OFF.
2. Check that the front wiper motor 30 A fuse (#60) is not fusing.

Is the fuse fusing?

YES >> Replace the fuse after repairing the applicable circuit.

NO >> GO TO 3.

3. CHECK FRONT WIPER MOTOR GROUND OPEN CIRCUIT

1. Disconnect front wiper motor connector.
2. Check continuity between front wiper motor harness connector and ground.

| Front wiper motor | | Ground | Continuity |
|-------------------|----------|--------|------------|
| Connector | Terminal | | Existed |
| E12 | 2 | | Existed |

Does continuity exist?

YES >> GO TO 4.

NO >> Repair the harness or connector.

4. CHECK FRONT WIPER MOTOR OUTPUT VOLTAGE

CONSULT ACTIVE TEST

1. Turn the ignition switch ON.
2. Select "FRONT WIPER" of IPDM E/R active test item.
3. With operating the test item, check voltage between IPDM E/R harness connector and ground.

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

WW

FRONT WIPER DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

| Terminals | | Test item | Voltage (Approx.) | | |
|-----------|----------|-------------|-------------------|-----|-----------------|
| (+) | (-) | | | | |
| IPDM E/R | | FRONT WIPER | | | |
| Connector | Terminal | | | | |
| E10 | 4 | | | Lo | Battery voltage |
| | 5 | | | Off | 0 V |
| Ground | | Hi | Battery voltage | | |
| | | Off | 0 V | | |

Is the measurement value normal?

- YES >> Replace front wiper motor.
 NO >> Replace IPDM E/R.

5.CHECK FRONT WIPER REQUEST SIGNAL INPUT

ⓐCONSULT DATA MONITOR

1. Select "FR WIP REQ" of IPDM E/R data monitor item.
2. Switch the front wiper switch to HI and LO.
3. With operating the front wiper switch, check the status of "FR WIP REQ".

| Monitor item | Condition | | Monitor status |
|--------------|-----------------------|-----|----------------|
| FR WIP REQ | Front wiper switch HI | On | Hi |
| | | Off | Stop |
| | Front wiper switch LO | On | Low |
| | | Off | Stop |

Is the status of item normal?

- YES >> Replace IPDM E/R.
 NO >> GO TO 6.

6.CHECK COMBINATION SWITCH

Perform the inspection of the combination switch. Refer to [BCS-94. "Symptom Table"](#).

Is combination switch normal?

- YES >> Replace BCM. Refer to [BCS-98. "Exploded View"](#).
 NO >> Repair or replace the applicable parts.

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS FOR CALIFORNIA AND CANADA

FOR CALIFORNIA AND CANADA : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009719762

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:


Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

FOR CALIFORNIA AND CANADA : Precaution for Procedure without Cowl Top Cover

INFOID:000000009719763

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc to prevent damage to windshield.



A
B
C
D
E
F
G
H
I
J
K
WW
M
N
O
P

PRECAUTIONS

< PRECAUTION >

FOR CALIFORNIA AND CANADA : Precautions for Removing of Battery Terminal

INFOID:000000010101863

- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.

NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.

NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.

FOR MEXICO

FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009719764

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.


- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.




PRECAUTIONS

< PRECAUTION >

FOR MEXICO : Precaution for Procedure without Cowl Top Cover

INFOID:000000009719765

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc to prevent damage to windshield.



FOR MEXICO : Precautions for Removing of Battery Terminal

INFOID:000000010101862

- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.

NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.


NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.



A
B
C
D
E
F
G
H
I
J
K

WW

M
N
O
P

WASHER TANK


< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION

WASHER TANK

Exploded View

INFOID:000000009719766



1. Washer tank inlet

2. Washer tank

Removal and Installation


INFOID:000000009719767

REMOVAL

1. Remove the clip (A).

← : Vehicle front

2. Pull out the washer tank inlet (1) from the washer tank.
3. Remove the front bumper fascia. Refer to [EXT-14, "Exploded View"](#).
4. Disconnect washer pump connector.
5. Disconnect washer level switch connector.
6. Remove front washer tube and rear washer tube.
7. Remove washer tank mounting bolts.
8. Remove the washer tank from the vehicle.



INSTALLATION

Install in the reverse order of removal.

CAUTION:

Add water up to the top of the washer tank inlet after installing. Check that there is no leakage.


WASHER PUMP

< REMOVAL AND INSTALLATION >

WASHER PUMP

Exploded View

INFOID:000000009719768



- | | | |
|----------------|----------------------|--------------------------|
| 1. Washer tank | 2. Rear washer tube | 3. Packing |
| 4. Washer pump | 5. Front washer tube | 6. Washer pump connector |

↔ : Vehicle front

Removal and Installation

INFOID:000000009719769

REMOVAL

1. Remove the fender protector RH (front). Refer to [EXT-26, "FENDER PROTECTOR : Exploded View"](#).
2. Disconnect washer pump connector.
3. Remove front washer tube and rear washer tube.
4. Remove washer pump from the washer tank.
5. Remove the packing from the washer tank.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

Never twist the packing when installing the washer pump.

A
B
C
D
E
F
G
H
I
J
K
WW
M
N
O
P

WASHER LEVEL SWITCH

< REMOVAL AND INSTALLATION >

WASHER LEVEL SWITCH

Removal and Installation

INFOID:000000009719770

The washer level switch must be replaced together with the washer tank as an assembly. Refer to [WW-128](#), "[Removal and Installation](#)".


FRONT WASHER NOZZLE AND TUBE

< REMOVAL AND INSTALLATION >

FRONT WASHER NOZZLE AND TUBE

Exploded View

INFOID:000000009719771




1. Front washer nozzle

2. Check valve

3. Front washer tube

Hydraulic Layout

INFOID:000000009719772




1. Front washer nozzle

2. Check valve

3. Front washer tube

4. Washer tank

 : Clip

Removal and Installation

INFOID:000000009719773

REMOVAL

1. Remove cowl top cover. Refer to [EXT-23, "Exploded View"](#).
2. Disconnect front washer tube from front washer nozzle.


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

WW

FRONT WASHER NOZZLE AND TUBE

< REMOVAL AND INSTALLATION >

- While pressing pawl (A) on the cowl top cover front side of front washer nozzle (1), remove front washer nozzle from cowl top cover.



INSTALLATION

Install in the reverse order of removal.

CAUTION:

The spray positions differ, check that left and right nozzles are installed correctly.


Inspection and Adjustment

INFOID:000000009719774

INSPECTION

Check valve Inspection


Check that air can pass through the hose by blowing forward (toward the nozzle), and check that air cannot pass through by sucking.



ADJUSTMENT

Washer Nozzle Spray Position Adjustment

Adjust spray positions to match the positions shown in the figure.



1. Black printed frame line

▨ : Spray area

● : Target spray position

FRONT WASHER NOZZLE AND TUBE

< REMOVAL AND INSTALLATION >


Unit: mm (in)

| Spray position | H | L | X | Y | S |
|----------------|-------------|-------------|-----------|------------|-----------|
| A | 285 (11.22) | 429 (16.89) | 80 (3.15) | 130 (5.12) | 65 (2.56) |
| B | 398 (15.67) | 232 (9.13) | 80 (3.15) | 130 (5.12) | 65 (2.56) |
| C | 185 (7.28) | 69 (2.72) | 80 (3.15) | 130 (5.12) | 65 (2.56) |
| D | 381 (15.00) | 37 (1.46) | 80 (3.15) | 130 (5.12) | 65 (2.56) |
| E | 398 (15.67) | 232 (9.13) | 80 (3.15) | 130 (5.12) | 65 (2.56) |
| F | 296 (11.65) | 421 (16.57) | 80 (3.15) | 130 (5.12) | 65 (2.56) |

Insert a needle or similar object (A) into the spray opening (1) and move up/down and left/right to adjust the spray position.

NOTE:

If wax or dust gets into the nozzle, remove wax or dust with a needle or small pin.



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

WW


FRONT WIPER ARM

< REMOVAL AND INSTALLATION >

FRONT WIPER ARM

Exploded View

INFOID:000000009719775



- | | | |
|---------------------------|---------------------------|------------------------|
| 1. Front wiper blade (RH) | 2. Front wiper arm (RH) | 3. Front wiper arm cap |
| 4. Front wiper arm (LH) | 5. Front wiper blade (LH) | |

Refer to [GI-4, "Components"](#) for symbols in the figure.

Removal and Installation


INFOID:000000009719776

REMOVAL

1. Operate the front wiper to move it to the auto stop position.
2. Open the hood.
3. Remove front wiper arm caps.
4. Remove the front wiper arm mounting nuts.
5. Raise front wiper arm, and remove front wiper arm from the vehicle.

INSTALLATION

1. Clean wiper arm mount as shown in the figure to prevent nuts from being loosened.
2. Operate the front wiper motor to move the front wiper to the auto stop position.
3. Adjust the front wiper blade position. Refer to [WW-134, "Adjustment"](#).
4. Install the front wiper arms by tightening the mounting nuts.
5. Inject the washer fluid.
6. Operate the front wiper to move it to the auto stop position.
7. Check that the front wiper blades stop at the specified position.
8. Install front wiper arm caps.



Adjustment

INFOID:000000009719777

WIPER BLADE POSITION ADJUSTMENT

Clearance between the end of cowl top cover and the top of front wiper blade center


FRONT WIPER ARM

< REMOVAL AND INSTALLATION >

Standard clearance

R : 51.0 ± 7.5 mm (2.008 ± 0.295 in)

L : 48.0 ± 7.5 mm (1.890 ± 0.295 in)



A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P


WIPER BLADE

< REMOVAL AND INSTALLATION >

WIPER BLADE

Exploded View

INFOID:000000009719778



- | | | |
|--------------------|--------------------|--------------|
| 1. Wiper refill | 2. Wiper blade | 3. Wiper arm |
| A. Wiper blade end | B. Wiper blade tip | |

Removal and Installation

INFOID:000000009719779

REMOVAL

Remove the wiper blade from the wiper arm.


INSTALLATION

Install the front wiper blade to the wiper arm.

Replacement

INFOID:000000009719780

1. Hold the rip of old wiper refill (1) at the rear end of the wiper blade with long-nose pliers, and pull out the wiper refill to the direction (A).




2. Insert the tip of new wiper refill (1) into the rear end of wiper blade. Slide the wiper refill to the direction (A) while pressing the wiper refill onto the wiper blade rear end.

NOTE:

- Insert the wiper refill to be held securely by tab (B) of wiper blade.
- After the wiper refill is fully inserted, remove the holder* (2).

*: Attached to service parts.



WIPER BLADE



< REMOVAL AND INSTALLATION >

3. Inert the wiper refill until the stopper at the rear end of wiper refill fits in the tab. Check that "LOCK" mark on wiper refill is aligned with "▼" mark on wiper blade.
4. Untwist the twisted wiper refill (▨) at the rear end of wiper blade, if any.
5. Check the following items after replacing wiper refill.
 - Wiper refill is not twisted at all.
 - Wiper refill thoroughly fits in the tab on wiper blade.
 - Wiper refill is inserted from the proper direction.

NOTE:

When the vertebra is detached.

- Insert the vertebra (1) into the wiper blade to the same bending direction.
- If a vertebra has a notch, fit it to a protrusion inside the wiper refill.



A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

WW

FRONT WIPER DRIVE ASSEMBLY


< REMOVAL AND INSTALLATION >

FRONT WIPER DRIVE ASSEMBLY

Exploded View


INFOID:000000009719781

REMOVAL VIEW




1. Front wiper drive assembly

DISASSEMBLY VIEW



- | | | |
|----------------------|---------------|--------------------------|
| 1. Front wiper motor | 2. Shaft seal | 3. Front wiper linkage 2 |
| 4. Front wiper frame | 5. Bracket | 6. Front wiper linkage 1 |

: Multi-purpose grease or an equivalent

Removal and Installation

INFOID:000000009719782

REMOVAL

1. Remove front wiper arm. Refer to [WW-134, "Exploded View"](#).
2. Remove cowl top cover. Refer to [EXT-23, "Exploded View"](#).
3. Remove bolts from the front wiper drive assembly.

FRONT WIPER DRIVE ASSEMBLY

< REMOVAL AND INSTALLATION >

4. Disconnect the front wiper motor connector.
5. Remove front wiper drive assembly from the vehicle.

A

INSTALLATION

1. Install the front wiper drive assembly to the vehicle.
2. Connect the front wiper motor connector.
3. Operate the front wiper to move it to the auto stop position.
4. Install the cowl top cover. Refer to [EXT-23, "Exploded View"](#).
5. Install front wiper arms. Refer to [WW-134, "Exploded View"](#).

B

C

Disassembly and Assembly

INFOID:000000009719783

D

DISASSEMBLY

1. Remove the front wiper linkage 1 and 2 from the front wiper drive assembly.
CAUTION:
Never bend the linkage or damage the plastic part of the ball joint when removing the front wiper linkage.
2. Remove the front wiper motor mounting screws, and then remove the front wiper motor from the front wiper frame.

E

F

ASSEMBLY

1. Connect the front wiper motor connector.
2. Operate the front wiper to move it to the auto stop position.
3. Disconnect the front wiper motor connector.
4. Install front wiper motor to front wiper frame.
5. Install the front wiper linkage 2 to the front wiper motor and the front wiper frame.
6. Install the front wiper linkage 1 to the front wiper frame.
CAUTION:
 - **Never drop front wiper motor or cause it to come into contact with other parts.**
 - **Be careful for the grease condition at the front wiper motor and front wiper linkage joint (retainer). Apply multi-purpose grease or an equivalent if necessary.**

G

H

I

J

K

WW

M

N

O

P

RAIN SENSOR

< REMOVAL AND INSTALLATION >

RAIN SENSOR


Exploded View

INFOID:000000009719784

CAUTION:

When the rain sensor is removed from windshield, the rain sensor cannot be re-used.

REMOVAL



1. Rain sensor connector 2. Inside mirror cover (upper) 3. Inside mirror cover (lower)
4. Rain sensor
A. Metal spring clip

Refer to [GI-4, "Components"](#) for symbols in the figure.

Removal and Installation

INFOID:000000009719785

REMOVAL

1. Remove the inside mirror cover (upper and lower).
2. Disengage the both sides of metal spring clips, and remove the rain sensor from the windshield.
3. Disconnect rain sensor connector.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

- **Surface of windshield should be cleaned.**
- **Never touch gel/adhesive of new part.**
- **Lock the metal spring clips and install the rain sensor securely.**

WIPER AND WASHER SWITCH

< REMOVAL AND INSTALLATION >

WIPER AND WASHER SWITCH

Exploded View

INFOID:000000009719786

Refer to [BCS-99. "Exploded View"](#).

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P


REAR WIPER ARM

< REMOVAL AND INSTALLATION >

REAR WIPER ARM

Exploded View

INFOID:000000009719787



- | | | |
|---------------------|-------------------------|---------------|
| 1. Rear wiper blade | 2. Rear wiper motor | 3. Pivot seal |
| 4. Rear wiper arm | 5. Rear wiper arm cover | |

Refer to [GI-4, "Components"](#) for symbols in the figure.

Removal and Installation


INFOID:000000009719788

REMOVAL

1. Operate the rear wiper to the auto stop position.
2. Remove rear wiper arm cover.
3. Remove the rear wiper arm mounting nut.
4. Raise rear wiper arm, and remove wiper arm from the vehicle.

INSTALLATION

1. Clean wiper arm mount as shown in the figure to prevent nut from being loosened.
2. Operate the rear wiper motor to the auto stop position.
3. Adjust the rear wiper blade position. Refer to [WW-142, "Adjustment"](#).
4. Install the rear wiper arm by tightening the mounting nut.
5. Inject the washer fluid.
6. Operate the rear wiper to the auto stop position.
7. Check that the rear wiper blades stop at the specified position.
8. Install rear wiper arm cover.



Adjustment

INFOID:000000009719789

REAR WIPER BLADE POSITION ADJUSTMENT


Clearance between the end of back door glass and top of wiper blade center.

REAR WIPER ARM

< REMOVAL AND INSTALLATION >

Standard clearance

L : 48.8 ± 7.5 mm (1.92 ± 0.295 in)



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

WW


REAR WIPER MOTOR

< REMOVAL AND INSTALLATION >

REAR WIPER MOTOR

Exploded View

INFOID:000000009719790



- | | | |
|---------------------|-------------------------|---------------|
| 1. Rear wiper blade | 2. Rear wiper motor | 3. Pivot seal |
| 4. Rear wiper arm | 5. Rear wiper arm cover | |

Refer to [GI-4, "Components"](#) for symbols in the figure.

Removal and Installation

INFOID:000000009719791

REMOVAL

1. Remove rear wiper arm cover and rear wiper arm. Refer to [WW-142, "Exploded View"](#).
2. Remove the back door finisher inner. Refer to [INT-38, "Removal and Installation"](#).
3. Disconnect the rear wiper motor connector.
4. Remove the rear wiper motor mounting bolts.
5. Remove the rear wiper motor from the vehicle.
6. Remove the pivot seal.

INSTALLATION

1. Install the pivot seal.
2. Install the rear wiper motor to the vehicle.
3. Connect the rear wiper motor connector.
4. Operate the rear wiper to the auto stop position.
5. Install the back door finisher inner. Refer to [INT-38, "Removal and Installation"](#).
6. Install rear wiper arm cover and rear wiper arm. Refer to [WW-142, "Exploded View"](#).

REAR WASHER NOZZLE AND TUBE


< REMOVAL AND INSTALLATION >

REAR WASHER NOZZLE AND TUBE

Hydraulic Layout

INFOID:000000009719792

With LDW/BSW



- | | | |
|---|----------------|------------------------------------|
| 1. Rear washer tube (From washer tank to washer switching solenoid valve) | 2. Washer tank | 3. Check valve |
| 4. Rear washer nozzle | 5. Nozzle | 6. Washer switching solenoid valve |
| 7. Rear washer tube (From washer switching solenoid valve to rear washer nozzle) | | |

- △ : Clip
○ : Grommet


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

WW

REAR WASHER NOZZLE AND TUBE

< REMOVAL AND INSTALLATION >

Without LDW/BSW



1. Rear washer nozzle

2. Check valve

3. Rear washer tube

4. Washer tank

△ : Clip

○ : Grommet

Removal and Installation

INFOID:000000009719793


REMOVAL

1. Remove the high-mounted stop lamp. Refer to [EXL-189. "Exploded View"](#).
2. Remove the rear washer tube from the rear washer nozzle.

REAR WASHER NOZZLE AND TUBE

< REMOVAL AND INSTALLATION >

- Remove the rear washer nozzle (1) from the high-mounted stop lamp (2).



INSTALLATION

Install in the reverse order of removal.


Inspection and Adjustment

INFOID:000000009719794

INSPECTION

Check valve Inspection

Check that air can pass through the hose by blowing forward (toward the nozzle), and check that air cannot pass through by sucking.



ADJUSTMENT


Washer Nozzle Spray Position adjustment

Adjust spray positions to match the positions shown in the figure.

1 : Black printed frame line

Unit: mm (in)


| Spray position | H (Height) | ϕ (Spray position area) |
|----------------|------------|------------------------------|
| A | 30 (1.18) | 30 (1.18) |



Insert a needle or similar object (A) into the spray opening (1) and move up/down and left/right to adjust the spray position.

NOTE:

If wax or dust gets into the nozzle, remove wax or dust with a needle or small pin.



A
B
C
D
E
F
G
H
I
J
K
WW
M
N
O
P