

# SECTION **BRC**

## BRAKE CONTROL SYSTEM

A  
B  
C  
D  
E  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

### CONTENTS

<b>VDC/TCS/ABS</b>	Component Description .....	19
<b>BASIC INSPECTION</b> .....	<b>ABS</b> .....	<b>20</b>
<b>DIAGNOSIS AND REPAIR WORK FLOW</b> .....	System Diagram .....	20
Work Flow .....	System Description .....	20
Diagnostic Work Sheet .....	Component Parts Location .....	20
<b>INSPECTION AND ADJUSTMENT</b> .....	Component Description .....	23
<b>ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT</b> .....	<b>EBD</b> .....	<b>24</b>
ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description .....	System Diagram .....	24
ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement .....	System Description .....	24
<b>ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION</b> .....	Component Parts Location .....	24
ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description .....	Component Description .....	27
ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement .....	<b>DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]</b> .....	<b>28</b>
<b>CALIBRATION OF DECEL G SENSOR</b> .....	CONSULT-III Function .....	28
CALIBRATION OF DECEL G SENSOR : Description .....	<b>DTC/CIRCUIT DIAGNOSIS</b> .....	<b>33</b>
CALIBRATION OF DECEL G SENSOR : Special Repair Requirement .....	<b>C1101, C1102, C1103, C1104 WHEEL SENSOR</b> .....	<b>33</b>
<b>SYSTEM DESCRIPTION</b> .....	Description .....	33
<b>VDC</b> .....	DTC Logic .....	33
System Diagram .....	Diagnosis Procedure .....	33
System Description .....	Component Inspection .....	34
Component Parts Location .....	Special Repair Requirement .....	35
Component Description .....	<b>C1105, C1106, C1107, C1108 WHEEL SENSOR</b> .....	<b>36</b>
<b>TCS</b> .....	Description .....	36
System Diagram .....	DTC Logic .....	36
System Description .....	Diagnosis Procedure .....	36
Component Parts Location .....	Component Inspection .....	37
	Special Repair Requirement .....	38
	<b>C1109 POWER AND GROUND SYSTEM</b> .....	<b>39</b>
	Description .....	39
	DTC Logic .....	39
	Diagnosis Procedure .....	39
	Component Inspection .....	40
	Special Repair Requirement .....	40

BRC

<b>C1110 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)</b> .....	<b>41</b>	Diagnosis Procedure .....	58
Description .....	41	Component Inspection .....	59
DTC Logic .....	41	Special Repair Requirement .....	59
Diagnosis Procedure .....	41	<b>C1142 PRESS SENSOR</b> .....	<b>60</b>
Special Repair Requirement .....	41	Description .....	60
<b>C1111 ABS MOTOR, MOTOR RELAY SYSTEM</b> .....	<b>42</b>	DTC Logic .....	60
Description .....	42	Diagnosis Procedure .....	60
DTC Logic .....	42	Component Inspection .....	60
Diagnosis Procedure .....	42	Special Repair Requirement .....	61
Component Inspection .....	43	<b>C1143 STEERING ANGLE SENSOR</b> .....	<b>62</b>
Special Repair Requirement .....	43	Description .....	62
<b>C1113, C1145, C1146 YAW RATE/SIDE/DECEL G SENSOR</b> .....	<b>44</b>	DTC Logic .....	62
Description .....	44	Diagnosis Procedure .....	62
DTC Logic .....	44	Component Inspection .....	63
Diagnosis Procedure .....	44	Special Repair Requirement .....	63
Component Inspection .....	45	<b>C1144 INCOMPLETE STEERING ANGLE SENSOR ADJUSTMENT</b> .....	<b>64</b>
Special Repair Requirement .....	46	Description .....	64
<b>C1115 WHEEL SENSOR</b> .....	<b>47</b>	DTC Logic .....	64
Description .....	47	Diagnosis Procedure .....	64
DTC Logic .....	47	Component Inspection .....	64
Diagnosis Procedure .....	47	Special Repair Requirement .....	64
Component Inspection .....	48	<b>C1155 BRAKE FLUID LEVEL SWITCH</b> .....	<b>66</b>
Special Repair Requirement .....	49	Description .....	66
<b>C1116 STOP LAMP SWITCH</b> .....	<b>50</b>	DTC Logic .....	66
Description .....	50	Diagnosis Procedure .....	66
DTC Logic .....	50	Component Inspection .....	67
Diagnosis Procedure .....	50	Special Repair Requirement .....	67
Component Inspection .....	51	<b>C1160 INCOMPLETE DECEL G SENSOR CALIBRATION</b> .....	<b>68</b>
Special Repair Requirement .....	51	Description .....	68
<b>C1120, C1122, C1124, C1126 IN ABS SOL</b> ....	<b>52</b>	DTC Logic .....	68
Description .....	52	Diagnosis Procedure .....	68
DTC Logic .....	52	Special Repair Requirement .....	68
Diagnosis Procedure .....	52	<b>C1161 INCOMPLETE SIDE G SENSOR CALIBRATION</b> .....	<b>69</b>
Component Inspection .....	53	Description .....	69
Special Repair Requirement .....	53	DTC Logic .....	69
<b>C1121, C1123, C1125, C1127 OUT ABS SOL</b> ..	<b>54</b>	Diagnosis Procedure .....	69
Description .....	54	Special Repair Requirement .....	69
DTC Logic .....	54	<b>C1162 INCOMPLETE PRESSURE SENSOR CALIBRATION</b> .....	<b>70</b>
Diagnosis Procedure .....	54	Description .....	70
Component Inspection .....	55	DTC Logic .....	70
Special Repair Requirement .....	55	Diagnosis Procedure .....	70
<b>C1130 ENGINE SIGNAL</b> .....	<b>56</b>	Special Repair Requirement .....	70
Description .....	56	<b>C1164, C1165 CV SYSTEM</b> .....	<b>71</b>
DTC Logic .....	56	Description .....	71
Diagnosis Procedure .....	56	DTC Logic .....	71
Special Repair Requirement .....	56	Diagnosis Procedure .....	71
<b>C1140 ACTUATOR RELAY SYSTEM</b> .....	<b>58</b>	Component Inspection .....	72
Description .....	58	Special Repair Requirement .....	72
DTC Logic .....	58		

<b>C1166, C1167 SV SYSTEM</b> .....	<b>73</b>	<b>EXCESSIVE ABS FUNCTION OPERATION</b>	
Description .....	73	<b>FREQUENCY</b> .....	<b>98</b>
DTC Logic .....	73	Diagnosis Procedure .....	98
Diagnosis Procedure .....	73	<b>UNEXPECTED PEDAL REACTION</b> .....	<b>99</b>
Component Inspection .....	74	Diagnosis Procedure .....	99
Special Repair Requirement .....	74	<b>THE BRAKING DISTANCE IS LONG</b> .....	<b>100</b>
<b>U1000, U1002 CAN COMM CIRCUIT</b> .....	<b>75</b>	Diagnosis Procedure .....	100
Description .....	75	<b>ABS FUNCTION DOES NOT OPERATE</b> .....	<b>101</b>
DTC Logic .....	75	Diagnosis Procedure .....	101
Diagnosis Procedure .....	75	<b>PEDAL VIBRATION OR ABS OPERATION</b>	
Special Repair Requirement .....	75	<b>SOUND OCCURS</b> .....	<b>102</b>
<b>POWER SUPPLY AND GROUND CIRCUIT</b> .....	<b>76</b>	Diagnosis Procedure .....	102
Description .....	76	<b>VEHICLE JERKS DURING VDC/TCS/ABS</b>	
Diagnosis Procedure .....	76	<b>CONTROL</b> .....	<b>103</b>
Special Repair Requirement .....	77	Diagnosis Procedure .....	103
<b>PARKING BRAKE SWITCH</b> .....	<b>78</b>	<b>NORMAL OPERATING CONDITION</b> .....	<b>104</b>
Component Function Check .....	78	Description .....	104
Diagnosis Procedure .....	78	<b>PRECAUTION</b> .....	<b>105</b>
Component Inspection .....	78	<b>PRECAUTIONS</b> .....	<b>105</b>
<b>VDC OFF SWITCH</b> .....	<b>80</b>	<b>FOR USA AND CANADA</b> .....	<b>105</b>
Description .....	80	FOR USA AND CANADA : Precaution for Supple-	
Component Function Check .....	80	mental Restraint System (SRS) "AIR BAG" and	
Diagnosis Procedure .....	80	"SEAT BELT PRE-TENSIONER" .....	105
Component Inspection .....	81	FOR USA AND CANADA : Precaution Necessary	
<b>ABS WARNING LAMP</b> .....	<b>82</b>	for Steering Wheel Rotation after Battery Discon-	
Description .....	82	nect .....	105
Component Function Check .....	82	FOR USA AND CANADA : Precaution for Proce-	
Diagnosis Procedure .....	82	dure without Cowl Top Cover .....	106
Special Repair Requirement .....	82	FOR USA AND CANADA : Precaution for Brake	
<b>BRAKE WARNING LAMP</b> .....	<b>83</b>	System .....	106
Description .....	83	FOR USA AND CANADA : Precaution for Brake	
Component Function Check .....	83	Control .....	106
Diagnosis Procedure .....	83	<b>FOR MEXICO</b> .....	<b>107</b>
Special Repair Requirement .....	83	FOR MEXICO : Precaution for Supplemental Re-	
<b>VDC OFF INDICATOR LAMP</b> .....	<b>85</b>	straint System (SRS) "AIR BAG" and "SEAT BELT	
Description .....	85	PRE-TENSIONER" .....	107
Component Function Check .....	85	FOR MEXICO : Precaution Necessary for Steer-	
Diagnosis Procedure .....	85	ing Wheel Rotation after Battery Disconnect .....	107
<b>SLIP INDICATOR LAMP</b> .....	<b>86</b>	FOR MEXICO : Precaution for Procedure without	
Description .....	86	Cowl Top Cover .....	108
Component Function Check .....	86	FOR MEXICO : Precaution for Procedure without	
Diagnosis Procedure .....	86	Cowl Top Cover .....	108
<b>ECU DIAGNOSIS INFORMATION</b> .....	<b>87</b>	FOR MEXICO : Precaution for Brake System .....	108
<b>ABS ACTUATOR AND ELECTRIC UNIT</b>		FOR MEXICO : Precaution for Brake Control .....	109
<b>(CONTROL UNIT)</b> .....	<b>87</b>	<b>REMOVAL AND INSTALLATION</b> .....	<b>110</b>
Reference Value .....	87	<b>WHEEL SENSOR</b> .....	<b>110</b>
Wiring Diagram -BRAKE CONTROL SYSTEM- .....	91	<b>FRONT WHEEL SENSOR</b> .....	<b>110</b>
Fail-Safe .....	95	FRONT WHEEL SENSOR : Exploded View .....	110
DTC No. Index .....	96		
<b>SYMPTOM DIAGNOSIS</b> .....	<b>98</b>		

FRONT WHEEL SENSOR : Removal and Installation .....	110	REAR SENSOR ROTOR : Removal and Installation .....	112
<b>REAR WHEEL SENSOR .....</b>	<b>111</b>	<b>ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) .....</b>	<b>113</b>
REAR WHEEL SENSOR : Exploded View .....	111	Exploded View .....	113
REAR WHEEL SENSOR : Removal and Installation .....	111	Removal and Installation .....	113
<b>SENSOR ROTOR .....</b>	<b>112</b>	<b>YAW RATE/SIDE/DECEL G SENSOR .....</b>	<b>115</b>
<b>FRONT SENSOR ROTOR .....</b>	<b>112</b>	Exploded View .....	115
FRONT SENSOR ROTOR : Exploded View .....	112	Removal and Installation .....	115
FRONT SENSOR ROTOR : Removal and Installation .....	112	<b>STEERING ANGLE SENSOR .....</b>	<b>116</b>
<b>REAR SENSOR ROTOR .....</b>	<b>112</b>	Exploded View .....	116
REAR SENSOR ROTOR : Exploded View .....	112	Removal and Installation .....	116

# BASIC INSPECTION

## DIAGNOSIS AND REPAIR WORK FLOW

### Work Flow

INFOID:000000005517248

### PRECAUTIONS FOR DIAGNOSIS

#### Adjustment of Steering Angle Sensor

If steering angle sensor, steering system parts, suspension system parts, ABS actuator and electric unit (control unit) or tires have been replaced, or if wheel alignment has been adjusted, be sure to adjust neutral position of steering angle sensor before driving. Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

#### Calibration of Decel G Sensor

If yaw rate/side/decel G sensor or ABS actuator and electric unit (control unit) have been replaced, be sure to calibrate decel G sensor before driving. Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).

A  
B  
C  
D  
E  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


**BRC**

# DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[VDC/TCS/ABS]

## OVERALL SEQUENCE



## DETAILED FLOW

### 1. COLLECT THE INFORMATION FROM THE CUSTOMER

Get the detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred) using the diagnosis worksheet. Refer to [BRC-8, "Diagnostic Work Sheet"](#).

>> GO TO 2.

# DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[VDC/TCS/ABS]

## 2. PERFORM THE SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT-III.

Is there any DTC displayed?

YES >> GO TO 3.

NO >> GO TO 4.

## 3. PERFORM THE SYSTEM DIAGNOSIS

Perform the diagnosis applicable to the displayed DTC of "ABS" with CONSULT-III. Refer to [BRC-96, "DTC No. Index"](#).

>> GO TO 7.

## 4. CHECK THE SYMPTOM THAT IS NOT CONSIDERED A SYSTEM MALFUNCTION

Check that the symptom is a normal operation that is not considered a system malfunction. Refer to [BRC-104, "Description"](#).

Is the symptom a normal operation?

YES >> GO TO 8.

NO >> GO TO 5.

## 5. CHECK THE WARNING LAMP AND INDICATOR LAMP FOR ILLUMINATION

Check that the warning lamp and indicator lamp illuminate.

- ABS warning lamp: Refer to [BRC-82, "Description"](#).
- Brake warning lamp: Refer to [BRC-83, "Description"](#).
- VDC OFF indicator lamp: Refer to [BRC-85, "Description"](#).
- SLIP indicator lamp: Refer to [BRC-86, "Description"](#).

Is ON/OFF timing normal?

YES >> GO TO 6.

NO >> GO TO 2.

## 6. PERFORM THE DIAGNOSIS BY SYMPTOM

Perform the diagnosis applicable to the symptom for "ABS" with CONSULT-III.

>> GO TO 7.

## 7. REPAIR OR REPLACE THE MALFUNCTIONING PARTS

Repair or replace the specified malfunctioning parts.

>> GO TO 8.

## 8. MEMORY CLEAR

Perform self-diagnosis memory clear for "ABS" with CONSULT-III.

>> GO TO 9.

## 9. FINAL CHECK

Perform the self-diagnosis again, and check that the malfunction is repaired completely.

Is no other DTC present and the repair completed?

YES >> INSPECTION END

NO >> GO TO 3.

A  
B  
C  
D  
E  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

BRC

# DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[VDC/TCS/ABS]

## Diagnostic Work Sheet

INFOID:000000005517249

Customer name MR/MS	Model & Year	VIN	
Engine #	Trans.	Mileage	
Incident Date	Manuf. Date	In Service Date	
Symptoms	<input type="checkbox"/> Noise and vibration (from engine compartment) <input type="checkbox"/> Noise and vibration (from axle)	<input type="checkbox"/> Warning / Indicator activate	<input type="checkbox"/> Firm pedal operation <input type="checkbox"/> Large stroke pedal operation
	<input type="checkbox"/> TCS does not work (Rear wheels slip when accelerating)	<input type="checkbox"/> ABS does not work (Wheels lock when braking)	<input type="checkbox"/> Lack of sense of acceleration
Engine conditions	<input type="checkbox"/> When starting <input type="checkbox"/> After starting		
Road conditions	<input type="checkbox"/> Low friction road ( <input type="checkbox"/> Snow <input type="checkbox"/> Gravel <input type="checkbox"/> Other ) <input type="checkbox"/> Bumps / potholes		
Driving conditions	<input type="checkbox"/> Full-acceleration <input type="checkbox"/> High speed cornering <input type="checkbox"/> Vehicle speed: Greater than 10 km/h (6 MPH) <input type="checkbox"/> Vehicle speed: 10 km/h (6 MPH) or less <input type="checkbox"/> Vehicle is stopped		
Applying brake conditions	<input type="checkbox"/> Suddenly <input type="checkbox"/> Gradually		
Other conditions	<input type="checkbox"/> Operation of electrical equipment <input type="checkbox"/> Shift change <input type="checkbox"/> Other descriptions		

SFIA3265E



# INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[VDC/TCS/ABS]

## INSPECTION AND ADJUSTMENT

### ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

#### ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description

INFOID:000000005532111

Perform the steering angle sensor adjustment and decel G sensor calibration after replacing the ABS actuator and electric unit (control unit).

#### ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement

INFOID:000000005532112

#### 1. PERFORM ADJUSTMENT OF STEERING ANGLE SENSOR AND CALIBRATION OF DECEL G SENSOR

Perform steering angle sensor adjustment and decel G sensor calibration.

- Adjustment of steering angle sensor: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> INSPECTION END

### ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

#### ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description

INFOID:000000005517250

When doing work that applies to the list below, make sure to adjust neutral position of steering angle sensor before running vehicle.

x: Required –: Not required

Situation	Adjustment of steering angle sensor neutral position
Removing/Installing ABS actuator and electric unit (control unit)	—
Replacing ABS actuator and electric unit (control unit)	x
Removing/Installing steering angle sensor	x
Replacing steering angle sensor	x
Removing/Installing steering components	x
Replacing steering components	x
Removing/Installing suspension components	x
Replacing suspension components	x
Change tires to new ones	—
Tire rotation	—
Adjusting wheel alignment	x

#### ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement

INFOID:000000005517251

#### ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

##### **CAUTION:**

**To adjust neutral position of steering angle sensor, make sure to use CONSULT-III (Adjustment cannot be done without CONSULT-III)**

#### 1. ALIGN THE VEHICLE STATUS

Stop the vehicle with front wheels in straight-ahead position.

>> GO TO 2.

#### 2. PERFORM THE NEUTRAL POSITION ADJUSTMENT FOR THE STEERING ANGLE SENSOR

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# INSPECTION AND ADJUSTMENT

[VDC/TCS/ABS]

## < BASIC INSPECTION >

1. Select "ABS", "WORK SUPPORT" and "ST ANGLE SENSOR ADJUSTMENT" in order with CONSULT-III.
2. Select "START".

### **CAUTION:**

**Never touch steering wheel while adjusting steering angle sensor.**

3. After approximately 10 seconds, select "END".

### **NOTE:**

After approximately 60 seconds, it ends automatically.

4. Turn the ignition switch OFF, then turn it ON again.

### **CAUTION:**

**Be sure to perform above operation.**

>> GO TO 3.

## 3. CHECK DATA MONITOR

1. Run the vehicle with front wheels in straight-ahead position, then stop.
2. Select "ABS", "DATA MONITOR" and "STR ANGLE SIG" in order with CONSULT-III, and check steering angle sensor signal.

**STR ANGLE SIG :  $0 \pm 3.5^\circ$**

Is the steering angle within the specified range?

YES >> GO TO 4.

NO >> Perform the neutral position adjustment for the steering angle sensor again, GO TO 1.

## 4. ERASE THE SELF-DIAGNOSIS MEMORY

Erase the self-diagnosis memories for "ABS" with CONSULT-III. Refer to [BRC-28, "CONSULT-III Function"](#).

Are the memories erased?

YES >> INSPECTION END

NO >> Check the items indicated by the self-diagnosis.

## CALIBRATION OF DECEL G SENSOR

### CALIBRATION OF DECEL G SENSOR : Description

INFOID:000000005517252

When doing work that applies to the list below, make sure to calibration of decel G sensor before running vehicle.

×: Required –: Not required

Situation	Calibration of decel G sensor
Removing/Installing ABS actuator and electric unit (control unit)	×
Replacing ABS actuator and electric unit (control unit)	×
Removing/Installing steering components	–
Removing/Installing suspension components	–
Change tires to new ones	–
Tire rotation	–
Adjusting wheel alignment	–
Removing/Installing yaw rate/side/decel G sensor	×
Replacing yaw rate/side/decel G sensor	×

### CALIBRATION OF DECEL G SENSOR : Special Repair Requirement

INFOID:000000005517253

#### CALIBRATION OF DECEL G SENSOR

### **CAUTION:**

- To calibrate decel G sensor, make sure to use CONSULT-III.  
(Calibration cannot be done without CONSULT-III.)
- Perform the G sensor calibration only with the vehicle parked on level surface.

## 1. ALIGN THE VEHICLE STATUS

# INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[VDC/TCS/ABS]

Stop the vehicle with front wheels in straight-ahead position.

**CAUTION:**

- Keep all tires inflated to correct pressures. Adjust the tire pressure to the specified pressure value.
- Check that there is specified-load in vehicle other than the driver (or equivalent weight placed in driver's position).

>> GO TO 2.

## 2.PERFORM THE CALIBRATION OF DECEL G SENSOR

1. Select "ABS", "WORK SUPPORT" and "DECEL G SEN CALIBRATION" in order with CONSULT-III.
2. Select "START".
3. After approximately 10 seconds, select "END".

**NOTE:**

After approximately 60 seconds, it ends automatically.

4. Turn the ignition switch OFF, then turn it ON again.

**CAUTION:**

Be sure to perform above operation.

>> GO TO 3.

## 3.CHECK DATA MONITOR

1. Run the vehicle with front wheels in straight-ahead position, then stop.
2. Select "ABS", "DATA MONITOR" and "DECEL G-SEN" in order with CONSULT-III, and check decel G sensor signal.

**DECEL G-SEN : ±0.08 G**

Is the yaw rate/side/decel G within the specified range?

YES >> GO TO 4.

NO >> Perform the calibration of decel G sensor again, GO TO 1.

## 4.ERASE THE SELF-DIAGNOSIS MEMORY

Erase the self-diagnosis memories for "ABS" with CONSULT-III. Refer to [BRC-28, "CONSULT-III Function"](#).

Are the memories erased?

YES >> INSPECTION END

NO >> Check the items indicated by the self-diagnosis.


A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# SYSTEM DESCRIPTION

## VDC

### System Diagram

INFOID:000000005517254



### System Description


INFOID:000000005517255

- In addition to the TCS/ABS function, the driver steering amount and brake operation amount are detected by the steering angle sensor and pressure sensor, and the vehicle's driving status (amount of under steering/over steering) is determined by the information from the yaw rate/side/decel G sensor, wheel sensor, etc., and this information is used to improve vehicle stability by controlling the braking and engine power to all four wheels.
- During VDC operation, it informs driver of system operation by blinking the SLIP indicator lamp.
- Electrical system diagnosis by CONSULT-III is available.

### Component Parts Location

INFOID:000000005517256

FOR USA



- |                           |                                 |  |
|---------------------------|---------------------------------|--|
| 1. Steering angle sensor  | 2. ABS warning lamp             | 3. Brake warning lamp                            |
| 4. VDC OFF indicator lamp | 5. SLIP indicator lamp          | 6. ABS actuator and electric unit (control unit) |
| 7. Front wheel sensor     | 8. Yaw rate/side/decel G sensor | 9. VDC OFF switch                                |
| 10. Rear wheel sensor     |                                 |  |

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


# VDC

[VDC/TCS/ABS]

## < SYSTEM DESCRIPTION >

- A. Back of spiral cable assembly
- B. Combination meter
- C. Engine room (right side)
- D. Steering knuckle
- E. Under center console
- F. Instrument driver lower panel
- G. Rear axle

EXCEPT FOR USA



# VDC

## < SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

- |                                  |                                 |  |   |
|----------------------------------|---------------------------------|--|---|
| 1. Steering angle sensor         | 2. ABS warning lamp             | 3. Brake warning lamp                            | A |
| 4. VDC OFF indicator lamp        | 5. SLIP indicator lamp          | 6. ABS actuator and electric unit (control unit) |   |
| 7. Front wheel sensor            | 8. Yaw rate/side/decel G sensor | 9. VDC OFF switch                                | B |
| 10. Rear wheel sensor            |                                 |  |   |
| A. Back of spiral cable assembly | B. Combination meter            | C. Engine room (right side)                      | C |
| D. Steering knuckle              | E. Under center console         | F. Instrument driver lower panel                 |   |
| G. Rear axle                     |                                 |  |   |

## Component Description

INFOID:000000005517257


Component parts		Reference
ABS actuator and electric unit (control unit)	Pump	<a href="#">BRC-42, "Description"</a>
	Motor	
	Actuator relay (Main relay)	<a href="#">BRC-58, "Description"</a>
	Solenoid valve	<a href="#">BRC-52, "Description"</a>
	VDC switch-over valve (CV1, CV2)	<a href="#">BRC-71, "Description"</a>
	VDC switch-over valve (SV1, SV2)	<a href="#">BRC-73, "Description"</a>
Wheel sensor	<a href="#">BRC-33, "Description"</a>	
Yaw rate/side/decel G sensor	<a href="#">BRC-44, "Description"</a>	
Steering angle sensor	<a href="#">BRC-62, "Description"</a>	
VDC OFF switch	<a href="#">BRC-80, "Description"</a>	
ABS warning lamp	<a href="#">BRC-82, "Description"</a>	
Brake warning lamp	<a href="#">BRC-83, "Description"</a>	
VDC OFF indicator lamp	<a href="#">BRC-85, "Description"</a>	
SLIP indicator lamp	<a href="#">BRC-86, "Description"</a>	

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

TCS

System Diagram

INFOID:000000005517258



System Description

INFOID:000000005517259


- The wheel spin of the drive wheels is detected by the ABS actuator and electric unit (control unit) using the wheel speed signals from the four wheels, so if wheel spin occurs, the drive wheel right and left brake fluid pressure control and engine fuel cut are conducted while the throttle valve opening is restricted to reduce the engine torque and decrease the amount of wheel spin. In addition, the throttle opening is controlled to achieve the optimum engine torque.
- During TCS operation, TCS informs driver of system operation by blinking the SLIP indicator lamp.
- Electrical system diagnosis by CONSULT-III is available.

Component Parts Location

INFOID:000000005517260

FOR USA





- |                           |                                 |  |
|---------------------------|---------------------------------|--|
| 1. Steering angle sensor  | 2. ABS warning lamp             | 3. Brake warning lamp                            |
| 4. VDC OFF indicator lamp | 5. SLIP indicator lamp          | 6. ABS actuator and electric unit (control unit) |
| 7. Front wheel sensor     | 8. Yaw rate/side/decel G sensor | 9. VDC OFF switch                                |
| 10. Rear wheel sensor     |                                 |  |

JSFIA0208ZZ

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


# TCS

[VDC/TCS/ABS]

## < SYSTEM DESCRIPTION >

- A. Back of spiral cable assembly
- B. Combination meter
- C. Engine room (right side)
- D. Steering knuckle
- E. Under center console
- F. Instrument driver lower panel
- G. Rear axle

EXCEPT FOR USA



JSFIA0209ZZ

# TCS

[VDC/TCS/ABS]

## < SYSTEM DESCRIPTION >

- |                                  |                                 |  |   |
|----------------------------------|---------------------------------|--|---|
| 1. Steering angle sensor         | 2. ABS warning lamp             | 3. Brake warning lamp                            | A |
| 4. VDC OFF indicator lamp        | 5. SLIP indicator lamp          | 6. ABS actuator and electric unit (control unit) |   |
| 7. Front wheel sensor            | 8. Yaw rate/side/decel G sensor | 9. VDC OFF switch                                | B |
| 10. Rear wheel sensor            |                                 |  |   |
| A. Back of spiral cable assembly | B. Combination meter            | C. Engine room (right side)                      | C |
| D. Steering knuckle              | E. Under center console         | F. Instrument driver lower panel                 |   |
| G. Rear axle                     |                                 |  |   |

## Component Description

INFOID:000000005517261


Component parts		Reference
ABS actuator and electric unit (control unit)	Pump	<a href="#">BRC-42, "Description"</a>
	Motor	
	Actuator relay (Main relay)	<a href="#">BRC-58, "Description"</a>
	Solenoid valve	<a href="#">BRC-52, "Description"</a>
	VDC switch-over valve (CV1, CV2)	<a href="#">BRC-71, "Description"</a>
	VDC switch-over valve (SV1, SV2)	<a href="#">BRC-73, "Description"</a>
Wheel sensor		<a href="#">BRC-33, "Description"</a>
Yaw rate/side/decel G sensor		<a href="#">BRC-44, "Description"</a>
Steering angle sensor		<a href="#">BRC-62, "Description"</a>
VDC OFF switch		<a href="#">BRC-80, "Description"</a>
ABS warning lamp		<a href="#">BRC-82, "Description"</a>
Brake warning lamp		<a href="#">BRC-83, "Description"</a>
VDC OFF indicator lamp		<a href="#">BRC-85, "Description"</a>
SLIP indicator lamp		<a href="#">BRC-86, "Description"</a>

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

ABS

System Diagram

INFOID:000000005517262



System Description

INFOID:000000005517263

- The Anti-Lock Braking System detects wheel revolution while braking, and it improves handling stability during sudden braking by electrically preventing 4 wheel lock. Maneuverability is also improved for avoiding obstacles.
- Electrical system diagnosis by CONSULT-III is available.

Component Parts Location


INFOID:000000005517264

FOR USA

# ABS

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]



- |                           |                                 |  |
|---------------------------|---------------------------------|--|
| 1. Steering angle sensor  | 2. ABS warning lamp             | 3. Brake warning lamp                            |
| 4. VDC OFF indicator lamp | 5. SLIP indicator lamp          | 6. ABS actuator and electric unit (control unit) |
| 7. Front wheel sensor     | 8. Yaw rate/side/decel G sensor | 9. VDC OFF switch                                |
| 10. Rear wheel sensor     |                                 |  |

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


# ABS

[VDC/TCS/ABS]

## < SYSTEM DESCRIPTION >

- A. Back of spiral cable assembly
- B. Combination meter
- C. Engine room (right side)
- D. Steering knuckle
- E. Under center console
- F. Instrument driver lower panel
- G. Rear axle

EXCEPT FOR USA



JSFIA0209ZZ

# ABS

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

- |                                  |                                 |  |   |
|----------------------------------|---------------------------------|--|---|
| 1. Steering angle sensor         | 2. ABS warning lamp             | 3. Brake warning lamp                            | A |
| 4. VDC OFF indicator lamp        | 5. SLIP indicator lamp          | 6. ABS actuator and electric unit (control unit) |   |
| 7. Front wheel sensor            | 8. Yaw rate/side/decel G sensor | 9. VDC OFF switch                                | B |
| 10. Rear wheel sensor            |                                 |  |   |
| A. Back of spiral cable assembly | B. Combination meter            | C. Engine room (right side)                      | C |
| D. Steering knuckle              | E. Under center console         | F. Instrument driver lower panel                 |   |
| G. Rear axle                     |                                 |  |   |

## Component Description

INFOID:000000005517265


Component parts	Reference	
ABS actuator and electric unit (control unit)	Pump	<a href="#">BRC-42, "Description"</a>
	Motor	
	Actuator relay (Main relay)	<a href="#">BRC-58, "Description"</a>
	Solenoid valve	<a href="#">BRC-52, "Description"</a>
	VDC switch-over valve (CV1, CV2)	<a href="#">BRC-71, "Description"</a>
	VDC switch-over valve (SV1, SV2)	<a href="#">BRC-73, "Description"</a>
Wheel sensor	<a href="#">BRC-33, "Description"</a>	
Yaw rate/side/decel G sensor	<a href="#">BRC-44, "Description"</a>	
Steering angle sensor	<a href="#">BRC-62, "Description"</a>	
VDC OFF switch	<a href="#">BRC-80, "Description"</a>	
ABS warning lamp	<a href="#">BRC-82, "Description"</a>	
Brake warning lamp	<a href="#">BRC-83, "Description"</a>	
VDC OFF indicator lamp	<a href="#">BRC-85, "Description"</a>	
SLIP indicator lamp	<a href="#">BRC-86, "Description"</a>	

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EBD

System Diagram

INFOID:000000005517266



System Description

INFOID:000000005517267


- Electronic Brake force Distribution detects subtle slippages between front and rear wheels during braking, and it improves handling stability by electronically controlling brake fluid pressure which results in reduced rear wheel slippage.
- Electrical system diagnosis by CONSULT-III is available.

Component Parts Location

INFOID:000000005517268

FOR USA





- |                           |                                 |  |
|---------------------------|---------------------------------|--|
| 1. Steering angle sensor  | 2. ABS warning lamp             | 3. Brake warning lamp                            |
| 4. VDC OFF indicator lamp | 5. SLIP indicator lamp          | 6. ABS actuator and electric unit (control unit) |
| 7. Front wheel sensor     | 8. Yaw rate/side/decel G sensor | 9. VDC OFF switch                                |
| 10. Rear wheel sensor     |                                 |  |

JSFIA0208ZZ

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


# EBD

[VDC/TCS/ABS]

## < SYSTEM DESCRIPTION >

- A. Back of spiral cable assembly
- B. Combination meter
- C. Engine room (right side)
- D. Steering knuckle
- E. Under center console
- F. Instrument driver lower panel
- G. Rear axle

EXCEPT FOR USA



< SYSTEM DESCRIPTION >

- |                                  |                                 |  |   |
|----------------------------------|---------------------------------|--|---|
| 1. Steering angle sensor         | 2. ABS warning lamp             | 3. Brake warning lamp                            | A |
| 4. VDC OFF indicator lamp        | 5. SLIP indicator lamp          | 6. ABS actuator and electric unit (control unit) |   |
| 7. Front wheel sensor            | 8. Yaw rate/side/decel G sensor | 9. VDC OFF switch                                | B |
| 10. Rear wheel sensor            |                                 |  |   |
| A. Back of spiral cable assembly | B. Combination meter            | C. Engine room (right side)                      | C |
| D. Steering knuckle              | E. Under center console         | F. Instrument driver lower panel                 |   |
| G. Rear axle                     |                                 |  |   |

Component Description

INFOID:000000005517269

Component parts		Reference
ABS actuator and electric unit (control unit)	Pump	<a href="#">BRC-42, "Description"</a>
	Motor	
	Actuator relay (Main relay)	<a href="#">BRC-58, "Description"</a>
	Solenoid valve	<a href="#">BRC-52, "Description"</a>
	VDC switch-over valve (CV1, CV2)	<a href="#">BRC-71, "Description"</a>
	VDC switch-over valve (SV1, SV2)	<a href="#">BRC-73, "Description"</a>
Wheel sensor	<a href="#">BRC-33, "Description"</a>	
Yaw rate/side/decel G sensor	<a href="#">BRC-44, "Description"</a>	
Steering angle sensor	<a href="#">BRC-62, "Description"</a>	
VDC OFF switch	<a href="#">BRC-80, "Description"</a>	
ABS warning lamp	<a href="#">BRC-82, "Description"</a>	
Brake warning lamp	<a href="#">BRC-83, "Description"</a>	
VDC OFF indicator lamp	<a href="#">BRC-85, "Description"</a>	
SLIP indicator lamp	<a href="#">BRC-86, "Description"</a>	

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

## DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

### CONSULT-III Function

INFOID:00000000517270

#### FUNCTION

CONSULT-III can display each diagnostic item using the diagnostic test modes as following.

Diagnostic test mode	Function
Work support	This mode enables a technician to adjust some devices faster and more accurately by following the indications on CONSULT-III.
Self diagnostic result	Self-diagnostic results can be read and erased quickly.
Data monitor	Input/Output data in the ABS actuator and electric unit (control unit) can be read.
Active test	CONSULT-III drives some actuators apart from the ABS actuator and electric unit (control unit) and also shifts some parameters in a specified range.
ECU identification	ABS actuator and electric unit (control unit) part number can be read.

#### WORK SUPPORT

Item	Description
ST ANGLE SENSOR ADJUSTMENT	Adjusts the neutral position of the steering angle sensor.
DECEL G SEN CALIBRATION	Calibrates decel G sensor.

#### SELF DIAGNOSTIC RESULT

##### Operation Procedure

Before performing the self-diagnosis for "ABS" with CONSULT-III, start the engine and drive the vehicle at 30 km/h (19 MPH) or more for approximately 1 minute.

##### Display Item List

Refer to [BRC-96, "DTC No. Index"](#).

##### How to Erase Self-diagnosis Results

After erasing DTC memory for "ABS" with CONSULT-III, start the engine and drive the vehicle at 30 km/h (19 MPH) or more for approximately 1 minute as the final inspection, and make sure that the ABS warning lamp, VDC OFF indicator lamp, SLIP indicator lamp and brake warning lamp turn OFF.

##### **CAUTION:**

**If memory cannot be erased, perform applicable diagnosis.**

##### **NOTE:**

- When the wheel sensor malfunctions, after inspecting the wheel sensor system, the ABS warning lamp, VDC OFF indicator lamp, SLIP indicator lamp and brake warning lamp will not turn OFF even when the system is normal unless the vehicle is driving at approximately 30 km/h (19 MPH) or more for approximately 1 minute.
- Brake warning lamp will turn ON in case of parking brake operation (when switch is ON) or of brake fluid level switch operation (when brake fluid is insufficient).
- VDC OFF switch should not stay "ON" position.

#### DATA MONITOR

Display Item List

# DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

×: Applicable ▼: Optional item

Monitor item (Unit)	SELECT MONITOR ITEM		Remarks	
	ECU INPUT SIGNALS	MAIN SIGNALS		
FR LH SENSOR [km/h (MPH)]	×	×	Wheel speed	A
FR RH SENSOR [km/h (MPH)]	×	×		B
RR LH SENSOR [km/h (MPH)]	×	×		C
RR RH SENSOR [km/h (MPH)]	×	×		D
STOP LAMP SW (On/Off)	×	×	Stop lamp switch signal status	E
BATTERY VOLT (V)	×	×	Battery voltage supplied to the ABS actuator and electric unit (control unit)	
GEAR	×	×	Gear position determined by TCM	<b>BRC</b>
R POSI SIG (On/Off)	▼	▼	Shift position judged by shift position (R) signal	
N POSI SIG (On/Off)	▼	▼	Shift position judged by shift position (N) signal	G
P POSI SIG (On/Off)	▼	▼	Shift position judged by shift position (P) signal	H
SLCT LVR POSI	×	×	Shift position judged by shift position signal	
OFF SW (On/Off)	×	×	VDC OFF switch	I
YAW RATE SEN (d/s)	×	×	Yaw rate detected by yaw rate/side/decel G sensor	
DECEL G-SEN (G)	×	×	Decel G detected by yaw rate/side/decel G sensor	J
ACCEL POS SIG (%)	×	▼	Throttle actuator opening/closing is displayed (Linked with accelerator pedal)	K
SIDE G-SENSOR (m/s <sup>2</sup> )	×	▼	Transverse G detected by yaw rate/side/decel G sensor	
STR ANGLE SIG (°)	×	▼	Steering angle detected by steering angle sensor	L
ENGINE RPM [tr/min (rpm)]	×	▼	Engine speed	M
FLUID LEV SW (On/Off)	×	▼	Brake fluid level switch	
PRESS SENSOR (bar)	×	▼	Brake fluid pressure detected by pressure sensor	N

A  
B  
C  
D  
E  
**BRC**  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

Monitor item (Unit)	SELECT MONITOR ITEM		Remarks
	ECU INPUT SIGNALS	MAIN SIGNALS	
FR RH IN SOL (On/Off)	▼	×	Operation status of each solenoid valve
FR RH OUT SOL (On/Off)	▼	×	
FR LH IN SOL (On/Off)	▼	×	
FR LH OUT SOL (On/Off)	▼	×	
RR RH IN SOL (On/Off)	▼	×	
RR RH OUT SOL (On/Off)	▼	×	
RR LH IN SOL (On/Off)	▼	×	
RR LH OUT SOL (On/Off)	▼	×	
MOTOR RELAY (On/Off)	▼	×	Motor and motor relay operation
ACTUATOR RLY (On/Off)	▼	×	Actuator relay operation
ABS WARN LAMP (On/Off)	▼	×	ABS warning lamp
OFF LAMP (On/Off)	▼	×	VDC OFF indicator lamp
SLIP LAMP (On/Off)	▼	×	SLIP indicator lamp
CV1 (On/Off)	▼	▼	Cut valve 1 monitor
CV2 (On/Off)	▼	▼	Cut valve 2 monitor
SV1 (On/Off)	▼	▼	Suction valve 1 monitor
SV2 (On/Off)	▼	▼	Suction valve 2 monitor
EBD SIGNAL (On/Off)	▼	▼	EBD operation
ABS SIGNAL (On/Off)	▼	▼	ABS operation
TCS SIGNAL (On/Off)	▼	▼	TCS operation
VDC SIGNAL (On/Off)	▼	▼	VDC operation
EBD FAIL SIG (On/Off)	▼	▼	EBD fail-safe status
ABS FAIL SIG (On/Off)	▼	▼	ABS fail-safe status
TCS FAIL SIG (On/Off)	▼	▼	TCS fail-safe status
VDC FAIL SIG (On/Off)	▼	▼	VDC fail-safe status

# DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

Monitor item (Unit)	SELECT MONITOR ITEM		Remarks
	ECU INPUT SIGNALS	MAIN SIGNALS	
EBD WARN LAMP (On/Off)	▼	▼	Brake warning lamp
CRANKING SIG (On/Off)	▼	▼	Crank operation
4WD FAIL REQ (On/Off)	▼	▼	AWD fail-safe signal status
2WD/4WD (2WD/4WD)	▼	▼	Distinguish 2WD and AWD

**NOTE:**

A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is a operation for checking.

**ACTIVE TEST MODE**

**CAUTION:**

- **Never perform active test while driving vehicle.**
- **Make sure to completely bleed air from brake system.**
- **The active test cannot be started when ABS warning lamp, VDC OFF indicator lamp, SLIP indicator lamp and brake warning lamp is ON.**
- **ABS warning lamp, VDC OFF indicator lamp, SLIP indicator lamp and brake warning lamp are ON during active test.**

**NOTE:**

- When active test is performed while depressing the pedal, the pedal depression amount will change. This is normal. (Only solenoid valve and ABS motor.)
- "TEST IS STOPPED" in "ABS" with CONSULT-III is displayed 10 seconds after operation start.
- After "TEST IS STOPPED" in "ABS" with CONSULT-III is displayed, to perform test again.

Test Item

**ABS SOLENOID VALVE**

- Select "Up", "Keep" and "Down" of "ACTIVE TEST" in "ABS" with CONSULT-III. Then use screen monitor to check that solenoid valve operates as shown in the table below.

Test item	Display item	Display		
		Up	Keep	Down
FR RH SOL	FR RH IN SOL	Off	On	On
	FR RH OUT SOL	Off	Off	On*
FR LH SOL	FR LH IN SOL	Off	On	On
	FR LH OUT SOL	Off	Off	On*
RR RH SOL	RR RH IN SOL	Off	On	On
	RR RH OUT SOL	Off	Off	On*
RR LH SOL	RR LH IN SOL	Off	On	On
	RR LH OUT SOL	Off	Off	On*

\*: On for 1 to 2 seconds after the select, and then Off.

**NOTE:**

A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is a operation for checking.

**ABS SOLENOID VALVE (ACT)**

- Select "Up", "ACT UP" and "ACT KEEP" of "ACTIVE TEST" in "ABS" with CONSULT-III. Then use screen monitor to check that solenoid valve operates as shown in the table below.

# DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

Test item	Display item	Display		
		Up	ACT UP	ACT KEEP
FR RH ABS SOLENOID (ACT)	FR RH IN SOL	Off	Off	Off
	FR RH OUT SOL	Off	Off	Off
	CV1	Off	On	On
	SV1	Off	On*	Off
FR LH ABS SOLENOID (ACT)	FR LH IN SOL	Off	Off	Off
	FR LH OUT SOL	Off	Off	Off
	CV2	Off	On	On
	SV2	Off	On*	Off
RR RH ABS SOLENOID (ACT)	RR RH IN SOL	Off	Off	Off
	RR RH OUT SOL	Off	Off	Off
	CV2	Off	On	On
	SV2	Off	On*	Off
RR LH ABS SOLENOID (ACT)	RR LH IN SOL	Off	Off	Off
	RR LH OUT SOL	Off	Off	Off
	CV1	Off	On	On
	SV1	Off	On*	Off

\*: On for 1 to 2 seconds after the select, and then Off.

**NOTE:**

A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is a operation for checking.

**ABS MOTOR**

- Select “On” and “Off” of “ACTIVE TEST” in “ABS” with CONSULT-III. Make sure motor relay and actuator relay operates as shown in table below.

Test item	Display item	Display	
		On	Off
ABS MOTOR	MOTOR RELAY	On	Off
	ACTUATOR RLY	On	On

**NOTE:**

A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is a operation for checking.

**ECU IDENTIFICATION**

ABS actuator and electric unit (control unit) part number can be read.



# C1101, C1102, C1103, C1104 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## DTC/CIRCUIT DIAGNOSIS

### C1101, C1102, C1103, C1104 WHEEL SENSOR

#### Description

INFOID:000000005517271

When the sensor rotor rotates, the magnetic field changes. It converts the magnetic field changes to current signals (rectangular wave) and transmits them to the ABS actuator and electric unit (control unit).

#### DTC Logic

INFOID:000000005517272

#### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1101	RR RH SENSOR-1	Circuit of rear RH wheel sensor is open or short circuit. Current signal from sensor is outside limits.	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• Wheel sensor</li><li>• ABS actuator and electric unit (control unit)</li><li>• Sensor rotor</li></ul>
C1102	RR LH SENSOR-1	Circuit of rear LH wheel sensor is open or short circuit. Current signal from sensor is outside limits.	
C1103	FR RH SENSOR-1	Circuit of front RH wheel sensor is open or short circuit. Current signal from sensor is outside limits.	
C1104	FR LH SENSOR-1	Circuit of front LH wheel sensor is open or short circuit. Current signal from sensor is outside limits.	

#### DTC CONFIRMATION PROCEDURE

##### 1. DTC REPRODUCTION PROCEDURE

1. Start the engine and drive the vehicle at 30 km/h (19 MPH) or more for approximately 1 minute.
2. Perform self-diagnosis for "ABS" with CONSULT-III.

Is DTC "C1101", "C1102", "C1103" or "C1104" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-33, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

#### Diagnosis Procedure

INFOID:000000005517273

#### **CAUTION:**

**Never check between wheel sensor harness connector terminals.**

##### 1. CHECK TIRE

Check air pressure, wear, and size. Refer to [WT-60, "Tire Air Pressure"](#).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace error-detected parts.

##### 2. CHECK WHEEL SENSOR AND SENSOR ROTOR

- Check wheel sensor for damage, disconnection or looseness.
- Check sensor rotor for damage.

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair wheel sensor mount or replace wheel sensor or replace sensor rotor.
- Front wheel sensor: Refer to [BRC-110, "FRONT WHEEL SENSOR : Exploded View"](#).
  - Rear wheel sensor: Refer to [BRC-111, "REAR WHEEL SENSOR : Exploded View"](#).
  - Front sensor rotor: Refer to [BRC-112, "FRONT SENSOR ROTOR : Exploded View"](#).
  - Rear sensor rotor: Refer to [BRC-112, "REAR SENSOR ROTOR : Exploded View"](#).

##### 3. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check terminal to see if it is deformed, disconnected, loose, etc.

# C1101, C1102, C1103, C1104 WHEEL SENSOR

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair or replace error-detected parts.

## 4. CHECK WHEEL SENSOR HARNESS

1. Check the continuity between ABS actuator and electric unit (control unit) harness connector and wheel sensor harness connector. (Also check continuity when steering wheel is turned right and left and when sensor harness inside the wheel house is moved.)

Measurement terminal for signal circuit

ABS actuator and electric unit (control unit)		Wheel sensor			Continuity
Connector	Terminal	Connector	Terminal		
E36	6	E39 (Front RH)		4	Existed
	8	E22 (Front LH)		2	
	12	C4 (2WD models) C6 (AWD models)	(Rear RH)	8	
	2	C3 (2WD models) C5 (AWD models)	(Rear LH)	6	

Measurement terminal for power supply circuit

ABS actuator and electric unit (control unit)		Wheel sensor			Continuity
Connector	Terminal	Connector	Terminal		
E36	5	E39 (Front RH)		3	Existed
	9	E22 (Front LH)		1	
	11	C4 (2WD models) C6 (AWD models)	(Rear RH)	7	
	3	C3 (2WD models) C5 (AWD models)	(Rear LH)	5	

2. Check the continuity between ABS actuator and electric unit (control unit) harness connector.

ABS actuator and electric unit (control unit)				Continuity
Connector	Terminal	Connector	Terminal	
E36	6, 5	E36	13, 26	Not existed
	8, 9			
	12, 11			
	2, 3			

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Repair or replace error-detected parts.

## 5. REPLACE WHEEL SENSOR

1. Replace wheel sensor.
2. Erase self-diagnosis results for "ABS" with CONSULT-III.
3. Start the engine and drive the vehicle at 30 km/h (19 MPH) or more for approximately 1 minute.
4. Perform self-diagnosis for "ABS" with CONSULT-III.

Is DTC "C1101", "C1102", "C1103" or "C1104" detected?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-113, "Exploded View"](#).
- NO >> INSPECTION END

## Component Inspection

INFOID:000000005517274

### 1. CHECK DATA MONITOR

Select "ABS", "DATA MONITOR" in order with CONSULT-III, select "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR", and "RR RH SENSOR", and check the vehicle speed.

# C1101, C1102, C1103, C1104 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

Wheel sensor	Condition	Vehicle speed (DATA MONITOR)
FR LH SENSOR	Vehicle stopped	0 [km/h (MPH)]
	Vehicle running (Note)	Nearly matches the speedometer display ( $\pm 10\%$ or less)
FR RH SENSOR	Vehicle stopped	0 [km/h (MPH)]
	Vehicle running (Note)	Nearly matches the speedometer display ( $\pm 10\%$ or less)
RR LH SENSOR	Vehicle stopped	0 [km/h (MPH)]
	Vehicle running (Note)	Nearly matches the speedometer display ( $\pm 10\%$ or less)
RR RH SENSOR	Vehicle stopped	0 [km/h (MPH)]
	Vehicle running (Note)	Nearly matches the speedometer display ( $\pm 10\%$ or less)

Is the inspection result normal?

YES >> INSPECTION END

NO >> Proceed to diagnosis procedure. Refer to [BRC-33, "Diagnosis Procedure"](#).

## Special Repair Requirement

INFOID:000000005517275

### 1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

After removing/replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.

- Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

A  
B  
C  
D  
E  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

BRC

# C1105, C1106, C1107, C1108 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## C1105, C1106, C1107, C1108 WHEEL SENSOR

### Description

INFOID:000000005517276

When the sensor rotor rotates, the magnetic field changes. It converts the magnetic field changes to current signals (rectangular wave) and transmits them to the ABS actuator and electric unit (control unit).

### DTC Logic

INFOID:000000005517277

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1105	RR RH SENSOR-2	Signal from rear RH wheel sensor does not match other 3 wheel speed signal.	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• Wheel sensor</li><li>• Sensor rotor</li><li>• ABS actuator and electric unit (control unit)</li><li>• Sensor rotor</li></ul>
C1106	RR LH SENSOR-2	Signal from rear LH wheel sensor does not match other 3 wheel speed signal.	
C1107	FR RH SENSOR-2	Signal from front RH wheel sensor does not match other 3 wheel speed signal.	
C1108	FR LH SENSOR-2	Signal from front LH wheel sensor does not match other 3 wheel speed signal.	

### DTC CONFIRMATION PROCEDURE

#### 1. DTC REPRODUCTION PROCEDURE

1. Start the engine and drive the vehicle at 30 km/h (19 MPH) or more for approximately 1 minute.
2. Perform self-diagnosis for "ABS" with CONSULT-III.

Is DTC "C1105", "C1106", "C1107" or "C1108" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-36, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000005517278

#### **CAUTION:**

**Never check between wheel sensor harness connector terminals.**

#### 1. CHECK TIRE

Check air pressure, wear, and size. Refer to [WT-60, "Tire Air Pressure"](#).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace error-detected parts.

#### 2. CHECK WHEEL SENSOR AND SENSOR ROTOR

- Check wheel sensor for damage, disconnection or looseness.
- Check sensor rotor for damage.

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair wheel sensor mount or replace wheel sensor or replace sensor rotor.
- Front wheel sensor: Refer to [BRC-110, "FRONT WHEEL SENSOR : Exploded View"](#).
  - Rear wheel sensor: Refer to [BRC-111, "REAR WHEEL SENSOR : Exploded View"](#).
  - Front sensor rotor: Refer to [BRC-112, "FRONT SENSOR ROTOR : Exploded View"](#).
  - Rear sensor rotor: Refer to [BRC-112, "REAR SENSOR ROTOR : Exploded View"](#).

#### 3. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check terminal to see if it is deformed, disconnected, loose, etc.

Is the inspection result normal?

# C1105, C1106, C1107, C1108 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

- YES >> GO TO 4.  
 NO >> Repair or replace error-detected parts.

## 4.CHECK WHEEL SENSOR HARNESS

1. Check the continuity between ABS actuator and electric unit (control unit) harness connector and wheel sensor harness connector. (Also check continuity when steering wheel is turned right and left and when sensor harness inside the wheel house is moved.)

Measurement terminal for signal circuit

ABS actuator and electric unit (control unit)		Wheel sensor			Continuity
Connector	Terminal	Connector	Terminal		
E36	6	E39 (Front RH)		4	Existed
	8	E22 (Front LH)		2	
	12	C4 (2WD models) C6 (AWD models)	(Rear RH)	8	
	2	C3 (2WD models) C5 (AWD models)	(Rear LH)	6	

Measurement terminal for power supply circuit

ABS actuator and electric unit (control unit)		Wheel sensor			Continuity
Connector	Terminal	Connector	Terminal		
E36	5	E39 (Front RH)		3	Existed
	9	E22 (Front LH)		1	
	11	C4 (2WD models) C6 (AWD models)	(Rear RH)	7	
	3	C3 (2WD models) C5 (AWD models)	(Rear LH)	5	

2. Check the continuity between ABS actuator and electric unit (control unit) harness connector.

ABS actuator and electric unit (control unit)				Continuity
Connector	Terminal	Connector	Terminal	
E36	6, 5	E36	13, 26	Not existed
	8, 9			
	12, 11			
	2, 3			

Is the inspection result normal?

- YES >> GO TO 5.  
 NO >> Repair or replace error-detected parts.

## 5.REPLACE WHEEL SENSOR

1. Replace wheel sensor.
2. Erase self-diagnosis results for "ABS" with CONSULT-III.
3. Start the engine and drive the vehicle at 30 km/h (19 MPH) or more for approximately 1 minute.
4. Perform self-diagnosis for "ABS" with CONSULT-III.

Is DTC "C1105", "C1106", "C1107" or "C1108" detected?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-113, "Exploded View"](#).  
 NO >> INSPECTION END

## Component Inspection

INFOID:000000005517279

### 1.CHECK DATA MONITOR

Select "ABS", "DATA MONITOR" in order with CONSULT-III, select "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR", and "RR RH SENSOR", and check the vehicle speed.

# C1105, C1106, C1107, C1108 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

Wheel sensor	Condition	Vehicle speed (DATA MONITOR)
FR LH SENSOR	Vehicle stopped	0 [km/h (MPH)]
	Vehicle running (Note)	Nearly matches the speedometer display ( $\pm 10\%$ or less)
FR RH SENSOR	Vehicle stopped	0 [km/h (MPH)]
	Vehicle running (Note)	Nearly matches the speedometer display ( $\pm 10\%$ or less)
RR LH SENSOR	Vehicle stopped	0 [km/h (MPH)]
	Vehicle running (Note)	Nearly matches the speedometer display ( $\pm 10\%$ or less)
RR RH SENSOR	Vehicle stopped	0 [km/h (MPH)]
	Vehicle running (Note)	Nearly matches the speedometer display ( $\pm 10\%$ or less)

Is the inspection result normal?

YES >> INSPECTION END

NO >> Proceed to diagnosis procedure. Refer to [BRC-36, "Diagnosis Procedure"](#).

## Special Repair Requirement

INFOID:000000005532210

### 1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

After removing/replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.

- Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

# C1109 POWER AND GROUND SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## C1109 POWER AND GROUND SYSTEM

### Description

INFOID:000000005517281

Supplies electric power to the ABS actuator and electric unit (control unit).

### DTC Logic

INFOID:000000005517282

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1109	BATTERY VOLTAGE [ABNORMAL]	When the ABS actuator and electric unit (control unit) power supply is lower than normal.	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• ABS actuator and electric unit (control unit)</li><li>• Fuse</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch OFF to ON.
2. Perform self-diagnosis for "ABS" with CONSULT-III.

#### Is DTC "C1109" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-39, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000005517283

#### 1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, etc.

#### Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace error-detected parts.

#### 2. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY CIRCUIT AND GROUND CIRCUIT

1. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Condition	Voltage
Connector	Terminal			
E36	20	Ground	Ignition switch: OFF	Approx. 0 V

2. Turn the ignition switch ON.  
**CAUTION:**  
**Never start the engine.**
3. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Condition	Voltage
Connector	Terminal			
E36	20	Ground	Ignition switch: ON	Battery voltage

4. Check 10A fusible link (45).
5. Check the continuity between ABS actuator and electric unit (control unit) harness connector and IPDM E/R.

# C1109 POWER AND GROUND SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

ABS actuator and electric unit (control unit)		IPDM E/R		Continuity
Connector	Terminal	Connector	Terminal	
E36	20	E10	25	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace error-detected parts.

## 3.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT

Check the continuity between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	13	Ground	Existed
	26		

Is the inspection result normal?

YES >> Check battery for terminal looseness, low voltage, etc. if any malfunction is found, repair error-detected parts.

NO >> Repair or replace error-detected parts.

## Component Inspection

INFOID:000000005532203

### 1.CHECK DATA MONITOR

Select "ABS", "DATA MONITOR" and "BATTERY VOLT" in order with CONSULT-III, and check the voltage.

Display item	Display
BATTERY VOLT	10 – 16 v

Is the inspection result normal?

YES >> INSPECTION END

NO >> Proceed to diagnosis procedure. Refer to [BRC-39. "Diagnosis Procedure"](#).

## Special Repair Requirement

INFOID:000000005532211

### 1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

After removing/replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.

- Adjustment of steering angle sensor neutral position: Refer to [BRC-9. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END



# C1110 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## C1110 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

### Description

INFOID:000000005517285

ABS actuator and electric unit (control unit) is continuously monitoring ECU hardware and software for correct operation.

### DTC Logic

INFOID:000000005517286

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1110	CONTROLLER FAILURE	When there is an internal malfunction in the ABS actuator and electric unit (control unit).	ABS actuator and electric unit (control unit)

### DTC CONFIRMATION PROCEDURE

#### 1. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT-III.

#### Is DTC "C1110" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-41. "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000005517287

#### 1. REPLACE ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Replace ABS actuator and electric unit (control unit) when self-diagnostic result shows items other than those applicable.

- >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-113. "Exploded View"](#).

### Special Repair Requirement

INFOID:000000005532212

#### 1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

After removing/replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.

- Adjustment of steering angle sensor neutral position: Refer to [BRC-9. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

# C1111 ABS MOTOR, MOTOR RELAY SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## C1111 ABS MOTOR, MOTOR RELAY SYSTEM

### Description

INFOID:000000005517289

#### PUMP

The pump returns the brake fluid stored in the reservoir to the master cylinder by reducing the pressure.

#### MOTOR

The motor drives the pump according to the signals transmitted by the ABS actuator and electric unit (control unit).

#### MOTOR RELAY

Activates or deactivates motor according to the signals transmitted by the ABS actuator and electric unit (control unit).

### DTC Logic

INFOID:000000005517290

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1111	PUMP MOTOR	During the actuator motor operating with ON, when the actuator motor turns OFF, or when the control line for actuator motor relay is open.	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• ABS actuator and electric unit (control unit)</li></ul>
		During the actuator motor operating with OFF, when the actuator motor turns ON, or when the control line for relay is shorted to ground.	

### DTC CONFIRMATION PROCEDURE

#### 1. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT-III.

#### Is DTC "C1111" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-42, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000005517291

#### 1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnect, looseness, etc.

#### Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Replace or repair error-detected parts.

#### 2. CHECK ABS MOTOR AND MOTOR RELAY POWER SUPPLY CIRCUIT

Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Voltage
Connector	Terminal		
E36	14	Ground	Battery voltage

#### Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair or replace error-detected parts.

#### 3. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT

Check the continuity between ABS actuator and electric unit (control unit) harness connector and ground.

# C1111 ABS MOTOR, MOTOR RELAY SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	13	Ground	Existed
	26		

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-113, "Exploded View"](#).  
NO >> Repair or replace error-detected parts.

## Component Inspection

INFOID:000000005517292

### 1. CHECK ACTIVE TEST

1. Select "ABS", "ACTIVE TEST" and "ABS MOTOR" in order with CONSULT-III.
2. Select "On" and "Off" on screen. Make sure motor relay and actuator relay operates as shown in table below.

Test item	Display item	Display	
		On	Off
ABS MOTOR	MOTOR RELAY	On	Off
	ACTUATOR RLY	On	On

**NOTE:**

A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is a operation for checking.

Is the inspection result normal?

- YES >> INSPECTION END  
NO >> Proceed to diagnosis procedure. Refer to [BRC-42, "Diagnosis Procedure"](#).

## Special Repair Requirement

INFOID:000000005532213

### 1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

After removing/replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.

- Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

# C1113, C1145, C1146 YAW RATE/SIDE/DECEL G SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## C1113, C1145, C1146 YAW RATE/SIDE/DECEL G SENSOR

### Description

INFOID:000000005517294

Yaw rate/side/decel G sensor detects yaw rate/side/decel G affecting the vehicle, and transmits the data to the ABS actuator and electric unit (control unit) as an analog voltage signal.

### DTC Logic

INFOID:000000005517295

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1113	G SENSOR	Decel G sensor is malfunctioning.	• Harness or connector • ABS actuator and electric unit (control unit) • Yaw rate/side/decel G sensor
C1145	YAW RATE SENSOR	<ul style="list-style-type: none"><li>• Yaw rate sensor is malfunctioning.</li><li>• Yaw rate/side/decel G sensor power voltage is outside the standard.</li><li>• Yaw rate/side/decel G sensor signal line is open or shorted.</li></ul>	
C1146	SIDE G-SEN CIRCUIT	Side G sensor is malfunctioning.	

### DTC CONFIRMATION PROCEDURE

#### 1. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT-III.

Is DTC "C1113", "C1145" or "C1146" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-44, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000005517296

#### CAUTION:

- Sudden turns (such as spin turns, acceleration turns), drifting, etc. may cause yaw rate/side/decel G sensor circuit indicate a malfunction. However this is not a malfunction if normal operation can be resumed after restarting engine.
- When on a turntable, such as at a parking structure entrance, or when on a moving object with engine running, the VDC OFF indicator lamp might turn on and self-diagnosis using the CONSULT-III yaw rate sensor system malfunction might be displayed, but in this case there is no malfunction with yaw rate/side/decel G sensor circuit. As soon as the vehicle leaves the turntable or moving object, restart the engine to return the system to normal.

#### 1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect yaw rate/side/decel G sensor connector.
4. Check terminal for deformation, disconnection, looseness, etc.

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Replace or repair error-detected parts.

#### 2. CHECK YAW RATE/SIDE/DECEL G SENSOR POWER SUPPLY CIRCUIT

1. Turn the ignition switch ON.  
**CAUTION:**  
**Never start the engine.**
2. Check the voltage between yaw rate/side/decel G sensor harness connector and ground.

# C1113, C1145, C1146 YAW RATE/SIDE/DECCEL G SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

Yaw rate/side/deccl G sensor		—	Voltage
Connector	Terminal		
M52	4	Ground	Battery voltage

3. Turn the ignition switch OFF.
4. Check the voltage between yaw rate/side/deccl G sensor harness connector and ground.

Yaw rate/side/deccl G sensor		—	Voltage
Connector	Terminal		
M52	4	Ground	Approx. 0 V

Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> Repair or replace error-detected parts.

## 3.CHECK YAW RATE/SIDE/DECCEL G SENSOR GROUND CIRCUIT

Check the continuity between yaw rate/side/deccl G sensor harness connector and ground.

Yaw rate/side/deccl G sensor		—	Continuity
Connector	Terminal		
M52	1	Ground	Existed

Is the inspection result normal?

- YES >> GO TO 4.  
 NO >> Repair or replace error-detected parts.

## 4.CHECK YAW RATE/SIDE/DECCEL G SENSOR HARNESS

Check the continuity between yaw rate/side/deccl G sensor harness connector and ABS actuator and electric unit (control unit) harness connector.

ABS actuator and electric unit (control unit)		Yaw rate/side/deccl G sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	25	M52	2	Existed
	19		3	
	4		4	
	10		1	

Is the inspection result normal?

- YES >> GO TO 5.  
 NO >> Repair or replace error-detected parts.

## 5.CHECK DATA MONITOR

1. Connect yaw rate/side/deccl G sensor harness connector.
2. Connect ABS actuator and electric unit (control unit) harness connector.
3. Select "ABS" and "DATA MONITOR" in order with CONSULT-III, select "YAW RATE SEN", "SIDE G-SEN" and "DECCEL G-SEN", and check yaw rate/side/deccl G sensor signal.

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-113, "Exploded View"](#).  
 NO >> Replace yaw rate/side/deccl G sensor. Refer to [BRC-115, "Exploded View"](#).

## Component Inspection

INFOID:000000005517297

## 1.CHECK DATA MONITOR

Select "ABS" and "DATA MONITOR" in order with CONSULT-III, select "YAW RATE SEN", "SIDE G-SEN" and "DECCEL G-SEN", and check yaw rate/side/deccl G sensor signal.

# C1113, C1145, C1146 YAW RATE/SIDE/DECEL G SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## DECEL G SENSOR

Vehicle condition	DATA MONITOR
Vehicle stopped	Approx. 0 G
Vehicle acceleration	Positive value
Vehicle deceleration	Negative value

## YAW RATE SENSOR

Vehicle condition	DATA MONITOR
Vehicle stopped	Approx. 0 d/s
Vehicle turning right	Negative value
Vehicle turning left	Positive value

## SIDE G SENSOR

Vehicle condition	DATA MONITOR
Vehicle stopped	Approx. 0 m/s <sup>2</sup>
Vehicle turning right	Negative value
Vehicle turning left	Positive value

Is the inspection result normal?

YES >> INSPECTION END

NO >> Proceed to diagnosis procedure. Refer to [BRC-44, "Diagnosis Procedure"](#).

## Special Repair Requirement

INFOID:000000005517298

### 1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

- After removing/replacing a yaw rate/side/decels G sensor, be sure to perform the following procedure.
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing/replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
- Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

# C1115 WHEEL SENSOR

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

## C1115 WHEEL SENSOR

### Description

INFOID:000000005517299

When the sensor rotor rotates, the magnetic field changes. It converts the magnetic field changes to current signals (rectangular wave) and transmits them to the ABS actuator and electric unit (control unit).

### DTC Logic

INFOID:000000005517300

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1115	ABS SENSOR [ABNORMAL SIGNAL]	When wheel sensor input signal is malfunctioning.	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• Wheel sensor</li><li>• ABS actuator and electric unit (control unit)</li><li>• Sensor rotor</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. DTC REPRODUCTION PROCEDURE

1. Start the engine and drive the vehicle at 30 km/h (19 MPH) or more for approximately 1 minute.
2. Perform self-diagnosis for "ABS" with CONSULT-III.

Is DTC "C1115" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-47, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000005517301

#### **CAUTION:**

**Never check between wheel sensor harness connector terminals.**

#### 1. CHECK TIRE

Check air pressure, wear, and size. Refer to [WT-60, "Tire Air Pressure"](#).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace error-detected parts.

#### 2. CHECK WHEEL SENSOR AND SENSOR ROTOR

- Check wheel sensor for damage, disconnection or looseness.
- Check sensor rotor for damage.

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair wheel sensor mount or replace wheel sensor or replace sensor rotor.
- Front wheel sensor: Refer to [BRC-110, "FRONT WHEEL SENSOR : Exploded View"](#).
  - Rear wheel sensor: Refer to [BRC-111, "REAR WHEEL SENSOR : Exploded View"](#).
  - Front sensor rotor: Refer to [BRC-112, "FRONT SENSOR ROTOR : Exploded View"](#).
  - Rear sensor rotor: Refer to [BRC-112, "REAR SENSOR ROTOR : Exploded View"](#).

#### 3. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect wheel sensor connector.
4. Check terminal to see if it is deformed, disconnected, loose, etc.

Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Repair or replace error-detected parts.

#### 4. CHECK WHEEL SENSOR HARNESS

# C1115 WHEEL SENSOR

[VDC/TCS/ABS]

## < DTC/CIRCUIT DIAGNOSIS >

1. Check the continuity between ABS actuator and electric unit (control unit) harness connector and wheel sensor harness connector. (Also check continuity when steering wheel is turned right and left and when sensor harness inside the wheel house is moved.)

Measurement terminal for signal circuit

ABS actuator and electric unit (control unit)		Wheel sensor			Continuity
Connector	Terminal	Connector	Terminal		
E36	6	E39 (Front RH)		4	Existed
	8	E22 (Front LH)		2	
	12	C4 (2WD models) C6 (AWD models)	(Rear RH)	8	
	2	C3 (2WD models) C5 (AWD models)	(Rear LH)	6	

Measurement terminal for power supply circuit

ABS actuator and electric unit (control unit)		Wheel sensor			Continuity
Connector	Terminal	Connector	Terminal		
E36	5	E39 (Front RH)		3	Existed
	9	E22 (Front LH)		1	
	11	C4 (2WD models) C6 (AWD models)	(Rear RH)	7	
	3	C3 (2WD models) C5 (AWD models)	(Rear LH)	5	

2. Check the continuity between ABS actuator and electric unit (control unit) harness connector.

ABS actuator and electric unit (control unit)				Continuity
Connector	Terminal	Connector	Terminal	
E36	6, 5	E36	13, 26	Not existed
	8, 9			
	12, 11			
	2, 3			

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace error-detected parts.

## 5. REPLACE WHEEL SENSOR

1. Replace wheel sensor.
2. Erase self-diagnosis results for "ABS" with CONSULT-III.
3. Start the engine and drive the vehicle at 30 km/h (19 MPH) or more for approximately 1 minute.
4. Perform self-diagnosis for "ABS" with CONSULT-III.

Is DTC "C1115" detected?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-113, "Exploded View"](#).

NO >> INSPECTION END

## Component Inspection

INFOID:000000005517302

### 1. CHECK DATA MONITOR

Select "ABS", "DATA MONITOR" in order with CONSULT-III, select "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR", and "RR RH SENSOR", and check the vehicle speed.

Wheel sensor	Condition	Vehicle speed (DATA MONITOR)
FR LH SENSOR	Vehicle stopped	0 [km/h (MPH)]
	Vehicle running (Note)	Nearly matches the speedometer display ( $\pm 10\%$ or less)



# C1115 WHEEL SENSOR

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

Wheel sensor	Condition	Vehicle speed (DATA MONITOR)
FR RH SENSOR	Vehicle stopped	0 [km/h (MPH)]
	Vehicle running (Note)	Nearly matches the speedometer display ( $\pm 10\%$ or less)
RR LH SENSOR	Vehicle stopped	0 [km/h (MPH)]
	Vehicle running (Note)	Nearly matches the speedometer display ( $\pm 10\%$ or less)
RR RH SENSOR	Vehicle stopped	0 [km/h (MPH)]
	Vehicle running (Note)	Nearly matches the speedometer display ( $\pm 10\%$ or less)

Is the inspection result normal?

YES >> INSPECTION END

NO >> Proceed to diagnosis procedure. Refer to [BRC-47. "Diagnosis Procedure"](#).

## Special Repair Requirement

INFOID:000000005532214

### 1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

BRC

After removing/replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.

- Adjustment of steering angle sensor neutral position: Refer to [BRC-9. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

# C1116 STOP LAMP SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## C1116 STOP LAMP SWITCH

### Description

INFOID:000000005517304

The stop lamp switch transmits the stop lamp switch signal (ON/OFF) to the ABS actuator and electric unit (control unit).

### DTC Logic

INFOID:000000005517305

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1116	STOP LAMP SW	When a stop lamp switch signal is not input where the brake pedal is depressed.	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• Stop lamp switch</li><li>• ABS actuator and electric unit (control unit)</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT-III.

#### Is DTC "C1116" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-50, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000005517306

#### 1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Disconnect stop lamp switch harness connector.
4. Check terminal for deformation, disconnection, looseness, etc.
5. Reconnect ABS actuator and electric unit (control unit) and stop lamp switch connectors securely.
6. Start the engine.
7. Repeat pumping brake pedal carefully several times, and perform self-diagnosis for "ABS" with CONSULT-III.

#### Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Poor connection of connector terminal. Replace or repair error-detected parts.

#### 2. CHECK STOP LAMP SWITCH CLEARANCE

Check stop lamp switch clearance. Refer to [BR-9, "Inspection and Adjustment"](#).

#### Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Adjust stop lamp switch clearance. Refer to [BR-9, "Inspection and Adjustment"](#).

#### 3. CHECK STOP LAMP SWITCH

Check stop lamp switch. Refer to [BRC-51, "Component Inspection"](#).

#### Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Repair or replace stop lamp switch.

#### 4. CHECK STOP LAMP SWITCH CIRCUIT

1. Turn the ignition switch OFF.
2. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

# C1116 STOP LAMP SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

ABS actuator and electric unit (control unit)		—	Condition	Voltage
Connector	Terminal			
E36	16	Ground	Brake pedal is depressed	Battery voltage
			Brake pedal is released	Approx. 0 V

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-113. "Exploded View"](#).  
NO >> Repair or replace error-detected parts.

## Component Inspection

INFOID:000000005517307

### 1. CHECK STOP LAMP SWITCH

1. Turn the ignition switch OFF.
2. Disconnect stop lamp switch connector.
3. Check the continuity between stop lamp switch connector terminals.

Stop lamp switch	Condition	Continuity
Terminal		
1 - 2	Release stop lamp switch (When brake pedal is depressed.)	Existed
	Push stop lamp switch (When brake pedal is released.)	Not existed

Is the inspection result normal?

- YES >> INSPECTION END  
NO >> Replace stop lamp switch. Refer to [BR-20. "Exploded View"](#).

## Special Repair Requirement

INFOID:000000005532215

### 1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

After removing/replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.

- Adjustment of steering angle sensor neutral position: Refer to [BRC-9. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

# C1120, C1122, C1124, C1126 IN ABS SOL

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## C1120, C1122, C1124, C1126 IN ABS SOL

### Description

INFOID:000000005517309

The solenoid valve increases, holds or decreases the fluid pressure of each brake caliper according to the signals transmitted by the ABS actuator and electric unit (control unit).

### DTC Logic

INFOID:000000005517310

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1120	FR LH IN ABS SOL	When the control unit detects a malfunction in the front LH inlet solenoid circuit.	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• ABS actuator and electric unit (control unit)</li></ul>
C1122	FR RH IN ABS SOL	When the control unit detects a malfunction in the front RH inlet solenoid circuit.	
C1124	RR LH IN ABS SOL	When the control unit detects a malfunction in the rear LH inlet solenoid circuit.	
C1126	RR RH IN ABS SOL	When the control unit detects a malfunction in the rear RH inlet solenoid circuit.	

### DTC CONFIRMATION PROCEDURE

#### 1. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT-III.

Is DTC "C1120", "C1122", "C1124" or "C1126" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-52, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000005517311

#### 1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, etc.

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Replace or repair error-detected parts.

#### 2. CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY POWER SUPPLY CIRCUIT

Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Voltage
Connector	Terminal		
E36	1	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair or replace error-detected parts.

#### 3. CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY GROUND CIRCUIT

Check the continuity between ABS actuator and electric unit (control unit) harness connector and ground.

# C1120, C1122, C1124, C1126 IN ABS SOL

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	13	Ground	Existed
	26		

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-113, "Exploded View"](#).  
 NO >> Repair or replace error-detected parts.

## Component Inspection

INFOID:000000005517312

### 1. CHECK ACTIVE TEST

1. Select "ABS", "ACTIVE TEST" and each test menu item in order with CONSULT-III.
2. Select "Up", "Keep", and "Down", and check that the system operates as shown in the table below.

Test item	Display item	Display		
		Up	Keep	Down
FR RH SOL	FR RH IN SOL	Off	On	On
	FR RH OUT SOL	Off	Off	On*
FR LH SOL	FR LH IN SOL	Off	On	On
	FR LH OUT SOL	Off	Off	On*
RR RH SOL	RR RH IN SOL	Off	On	On
	RR RH OUT SOL	Off	Off	On*
RR LH SOL	RR LH IN SOL	Off	On	On
	RR LH OUT SOL	Off	Off	On*

\*: On for 1 to 2 seconds after the select, and then Off.

**NOTE:**

A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is a operation for checking.

Is the inspection result normal?

- YES >> INSPECTION END  
 NO >> Proceed to diagnosis procedure. Refer to [BRC-52, "Diagnosis Procedure"](#).

## Special Repair Requirement

INFOID:000000005532216

### 1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

After removing/replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.

- Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

# C1121, C1123, C1125, C1127 OUT ABS SOL

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## C1121, C1123, C1125, C1127 OUT ABS SOL

### Description

INFOID:000000005517314

The solenoid valve increases, holds or decreases the fluid pressure of each brake caliper according to the signals transmitted by the ABS actuator and electric unit (control unit).

### DTC Logic

INFOID:000000005517315

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1121	FR LH OUT ABS SOL	When the control unit detects a malfunction in the front LH outlet solenoid circuit.	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• ABS actuator and electric unit (control unit)</li></ul>
C1123	FR RH OUT ABS SOL	When the control unit detects a malfunction in the front RH outlet solenoid circuit.	
C1125	RR LH OUT ABS SOL	When the control unit detects a malfunction in the rear LH outlet solenoid circuit.	
C1127	RR RH OUT ABS SOL	When the control unit detects a malfunction in the rear RH outlet solenoid circuit.	

### DTC CONFIRMATION PROCEDURE

#### 1. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT-III.

Is DTC "C1121", "C1123", "C1125" or "C1127" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-54, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000005517316

#### 1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, etc.

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Replace or repair error-detected parts.

#### 2. CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY POWER SUPPLY CIRCUIT

Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Voltage
Connector	Terminal		
E36	1	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair or replace error-detected parts.

#### 3. CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY GROUND CIRCUIT

Check the continuity between ABS actuator and electric unit (control unit) harness connector and ground.

# C1121, C1123, C1125, C1127 OUT ABS SOL

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	13	Ground	Existed
	26		

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-113, "Exploded View"](#).  
 NO >> Repair or replace error-detected parts.

## Component Inspection

INFOID:000000005517317

### 1. CHECK ACTIVE TEST

- Select "ABS", "ACTIVE TEST" and each test menu item in order with CONSULT-III.
- Select "Up", "Keep", and "Down", and check that the system operates as shown in the table below.

Test item	Display item	Display		
		Up	Keep	Down
FR RH SOL	FR RH IN SOL	Off	On	On
	FR RH OUT SOL	Off	Off	On*
FR LH SOL	FR LH IN SOL	Off	On	On
	FR LH OUT SOL	Off	Off	On*
RR RH SOL	RR RH IN SOL	Off	On	On
	RR RH OUT SOL	Off	Off	On*
RR LH SOL	RR LH IN SOL	Off	On	On
	RR LH OUT SOL	Off	Off	On*

\*: On for 1 to 2 seconds after the select, and then Off.

**NOTE:**

A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is a operation for checking.

Is the inspection result normal?

- YES >> INSPECTION END  
 NO >> Proceed to diagnosis procedure. Refer to [BRC-54, "Diagnosis Procedure"](#).

## Special Repair Requirement

INFOID:000000005532217

### 1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

After removing/replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.

- Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

## C1130 ENGINE SIGNAL

### Description

INFOID:000000005517319

ABS actuator and electric unit (control unit) and ECM exchange the engine signal via CAN communication line.

### DTC Logic

INFOID:000000005517320

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1130	ENGINE SIGNAL 1	Major engine components are malfunctioning.	<ul style="list-style-type: none"> <li>• ECM</li> <li>• ABS actuator and electric unit (control unit)</li> <li>• CAN communication line</li> </ul>

### DTC CONFIRMATION PROCEDURE

#### 1. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT-III.

Is DTC "C1130" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-56, "Diagnosis Procedure"](#).  
 NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000005517321

#### 1. PERFORM ECM SELF-DIAGNOSIS

Perform self-diagnosis for "ENGINE" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

- YES >> Check the malfunctioning system. Refer to [EC-116, "CONSULT-III Function"](#).  
 NO >> GO TO 2.

#### 2. PERFORM ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS (1)

1. Erase self-diagnosis results for "ABS" with CONSULT-III.
2. Turn the ignition switch OFF.
3. Start the engine. Drive the vehicle for a while.
4. Make sure that malfunction indicator lamp (MIL) turns OFF.

Is indicator lamp (MIL) turns OFF?

- YES >> GO TO 3.  
 NO >> Refer to [EC-116, "CONSULT-III Function"](#).

#### 3. PERFORM ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS (2)

Stop the vehicle. Perform self-diagnosis for "ENGINE" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-113, "Exploded View"](#).  
 NO >> Repair or replace error-detected parts.

### Special Repair Requirement

INFOID:000000005532218

#### 1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

After removing/replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.

- Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).



# C1130 ENGINE SIGNAL

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

>> END

A

B

C

D

E

**BRC**

G

H

I

J

K

L

M

N

O

P

# C1140 ACTUATOR RELAY SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## C1140 ACTUATOR RELAY SYSTEM

### Description

INFOID:000000005517323

Activates or deactivates each solenoid valve according to the signals transmitted by the ABS actuator and electric unit (control unit).

### DTC Logic

INFOID:000000005517324

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1140	ACTUATOR RLY	When the control unit detects a malfunction in the actuator relay system.	<ul style="list-style-type: none"> <li>• Harness or connector</li> <li>• ABS actuator and electric unit (control unit)</li> </ul>

### DTC CONFIRMATION PROCEDURE

#### 1. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT-III.

#### Is DTC "C1140" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-58, "Diagnosis Procedure"](#).  
 NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000005517325

#### 1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, etc.

#### Is the inspection result normal?

- YES >> GO TO 2.  
 NO >> Replace or repair error-detected parts.

#### 2. CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY POWER SUPPLY CIRCUIT

Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Voltage
Connector	Terminal		
E36	1	Ground	Battery voltage

#### Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> Repair or replace error-detected parts.

#### 3. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT

Check the continuity between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	13	Ground	Existed
	26		

#### Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-113, "Exploded View"](#).  
 NO >> Repair or replace error-detected parts.

## Component Inspection

INFOID:00000000517326

### 1. CHECK ACTIVE TEST

1. Select "ABS", "ACTIVE TEST" and "ABS MOTOR" in order with CONSULT-III.
2. Select "On" and "Off" on screen. Make sure motor relay and actuator relay operates as shown in table below.

Test item	Display item	Display	
		On	Off
ABS MOTOR	MOTOR RELAY	On	Off
	ACTUATOR RLY	On	On

**NOTE:**

A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is a operation for checking.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Proceed to diagnosis procedure. Refer to [BRC-58, "Diagnosis Procedure"](#).



## Special Repair Requirement

INFOID:000000005532219

### 1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

After removing/replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.

- Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

A  
B  
C  
D  
E  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# C1142 PRESS SENSOR

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

## C1142 PRESS SENSOR

### Description

INFOID:000000005517328

The pressure sensor converts the brake fluid pressure to an electric signal and transmits it to the ABS actuator and electric unit (control unit). [The pressure sensor is integrated in the ABS actuator and electric unit (control unit).]

### DTC Logic

INFOID:000000005517329

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1142	PRESS SEN CIRCUIT	Pressure sensor signal line is open or shorted, or pressure sensor is malfunctioning.	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• Stop lamp switch</li><li>• ABS actuator and electric unit (control unit)</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT-III.

#### Is DTC "C1142" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-60. "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000005517330

#### 1. CHECK STOP LAMP SWITCH

Check stop lamp switch system. Refer to [BRC-50. "Diagnosis Procedure"](#).

#### Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace error-detected parts.

#### 2. CHECK DATA MONITOR

Check pressure sensor signal. Refer to [BRC-60. "Component Inspection"](#).

#### Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Check brake pedal, brake booster and master cylinder for mount play, looseness, brake system fluid leakage, etc.
- Brake fluid leakage: Refer to [BR-12. "Inspection"](#).
  - Brake pedal: Refer to [BR-21. "Inspection and Adjustment"](#).
  - Master cylinder: Refer to [BR-29. "Inspection"](#).
  - Brake booster: Refer to [BR-31. "Inspection and Adjustment"](#).

#### 3. PERFORM ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT-III.

#### Is any item indicated on the self-diagnosis display?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-113. "Exploded View"](#).  
NO >> Repair or replace error-detected parts.

### Component Inspection

INFOID:000000005517331

#### 1. CHECK DATA MONITOR

Select "ABS", "DATA MONITOR" and "PRESS SENSOR" in order with CONSULT-III, and check the brake fluid pressure.

# C1142 PRESS SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

Condition	PRESS SENSOR (DATA MONITOR)
With ignition switch turned ON and brake pedal released.	Approx. 0 bar
With ignition switch turned ON and brake pedal depressed.	0 to 170 bar

Is the inspection result normal?

YES >> INSPECTION END

NO >> Proceed to diagnosis procedure. Refer to [BRC-60. "Diagnosis Procedure"](#).

## Special Repair Requirement

INFOID:000000005532220

### 1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

After removing/replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.

- Adjustment of steering angle sensor neutral position: Refer to [BRC-9. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# C1143 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## C1143 STEERING ANGLE SENSOR

### Description

INFOID:000000005517333

The steering angle sensor detects the rotation amount, angular velocity and direction of the steering wheel, and transmits the data to the ABS actuator and electric unit (control unit) via CAN communication.

### DTC Logic

INFOID:000000005517334

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1143	ST ANG SEN CIRCUIT	Neutral position of steering angle sensor is dislocated, steering angle sensor is malfunctioning, or wheel alignment is outside specified range.	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• Steering angle sensor</li><li>• ABS actuator and electric unit (control unit)</li><li>• Wheel alignment</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT-III.

#### Is DTC "C1143" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-62. "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000005517335

#### 1. CHECK WHEEL ALIGNMENT

Check wheel alignment. Refer to [FSU-8. "Inspection"](#) (front), [RSU-6. "Inspection"](#) (rear).

#### Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Adjust wheel alignment. Refer to [FSU-8. "Inspection"](#) (front), [RSU-6. "Adjustment"](#) (rear).

#### 2. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect steering angle sensor connector.
4. Check terminal for deformation, disconnection, looseness, etc.

#### Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Replace or repair error-detected parts.

#### 3. CHECK STEERING ANGLE SENSOR HARNESS

1. Turn the ignition switch ON.  
**CAUTION:**  
**Never start the engine.**
2. Check the voltage between steering angle sensor harness connector and ground.

Steering angle sensor		—	Voltage
Connector	Terminal		
M30	4	Ground	Battery voltage

3. Turn ignition switch OFF.
4. Check the continuity between steering angle sensor harness connector and ground.

# C1143 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

Steering angle sensor		—	Continuity
Connector	Terminal		
M30	1	Ground	Existed

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair or replace error-detected parts.

## 4.CHECK STEERING WHEEL PLAY

Check steering wheel play. Refer to [ST-14, "Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Repair or replace error-detected parts.

## 5.CHECK DATA MONITOR

1. Connect the ABS actuator and electric unit (control unit) harness connector.
2. Connect the steering angle sensor harness connector.
3. Check steering angle sensor signal. Refer to [BRC-63, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-113, "Exploded View"](#).
- NO >> Replace steering angle sensor. Refer to [BRC-116, "Exploded View"](#).

## Component Inspection

INFOID:000000005517336

### 1.CHECK DATA MONITOR

Select "ABS", "DATA MONITOR" and "STR ANGLE SIG" in order with CONSULT-III, and check steering angle sensor signal.

Steering condition	STR ANGLE SIG (DATA MONITOR)
Driving straight	-3.5 – +3.5°
Turn 90 ° to right	Approx. -90 °
Turn 90 ° to left	Approx. +90 °

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> Proceed to diagnosis procedure. Refer to [BRC-62, "Diagnosis Procedure"](#).

## Special Repair Requirement

INFOID:000000005517337

### 1.ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

- After removing/replacing a steering angle sensor, be sure to perform the following procedure.
  - Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- After removing/replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
  - Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
  - Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

# C1144 INCOMPLETE STEERING ANGLE SENSOR ADJUSTMENT

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## C1144 INCOMPLETE STEERING ANGLE SENSOR ADJUSTMENT

### Description

INFOID:000000005532204

The steering angle sensor detects the rotation amount, angular velocity and direction of the steering wheel, and transmits the data to the ABS actuator and electric unit (control unit) via CAN communication.

### DTC Logic

INFOID:000000005517338

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1144	ST ANG SEN SIGNAL	Adjustment of steering angle sensor neutral position is not finished.	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• Steering angle sensor</li><li>• ABS actuator and electric unit (control unit)</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Select "ABS", "WORK SUPPORT" and "ST ANGLE SENSOR ADJUSTMENT" in order with CONSULT-III, and perform adjust the neutral position of steering angle sensor.
3. Perform self-diagnosis for "ABS" with CONSULT-III.

#### Is DTC "C1144" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-64, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000005517339

#### 1. CHECK STEERING ANGLE SENSOR

Check steering angle sensor. Refer to [BRC-62, "Diagnosis Procedure"](#).

#### Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-113, "Exploded View"](#).  
NO >> Repair or replace error-detected parts.

### Component Inspection

INFOID:000000005532205

#### 1. CHECK DATA MONITOR

Select "ABS", "DATA MONITOR" and "STR ANGLE SIG" in order with CONSULT-III, and check steering angle sensor signal.

Steering condition	STR ANGLE SIG (DATA MONITOR)
Driving straight	-3.5 - +3.5°
Turn 90 ° to right	Approx. -90 °
Turn 90 ° to left	Approx. +90 °

#### Is the inspection result normal?

- YES >> INSPECTION END  
NO >> Proceed to diagnosis procedure. Refer to [BRC-62, "Diagnosis Procedure"](#).

### Special Repair Requirement

INFOID:000000005532221

#### 1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

- After removing/replacing a steering angle sensor, be sure to perform the following procedure.



# C1144 INCOMPLETE STEERING ANGLE SENSOR ADJUSTMENT

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

- Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- After removing/replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
- Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

A  
B  
C  
D  
E  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

**BRC**

# C1155 BRAKE FLUID LEVEL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## C1155 BRAKE FLUID LEVEL SWITCH

### Description

INFOID:000000005517341

The brake fluid level switch converts the brake fluid level to an electric signal and transmits it to the ABS actuator and electric unit (control unit).

### DTC Logic

INFOID:000000005517342

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1155	BR FLUID LEVEL LOW	Brake fluid level is low or communication line between the ABS actuator and electric unit (control unit) and brake fluid level switch is open or shorted.	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• ABS actuator and electric unit (control unit)</li><li>• Brake fluid level low</li><li>• Brake fluid level switch</li><li>• Combination meter</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT-III.

#### Is DTC "C1155" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-66, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000005517343

#### 1. CHECK BRAKE FLUID LEVEL

Check the brake fluid level.

#### Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Refill the brake fluid.

#### 2. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect brake fluid level switch harness connector.
3. Disconnect combination meter harness connector.
4. Check terminal for deformation, disconnection, looseness, etc.

#### Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Replace or repair error-detected parts.

#### 3. CHECK BRAKE FLUID LEVEL SWITCH

Check brake fluid level switch. Refer to [BRC-67, "Component Inspection"](#).

#### Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Brake fluid level switch is malfunction. Replace reservoir tank. Refer to [BR-27, "Exploded View"](#).

#### 4. CHECK BRAKE FLUID LEVEL SWITCH CIRCUIT

1. Check the continuity between brake fluid level switch harness connector and ABS actuator and electric unit (control unit) harness connector.

# C1155 BRAKE FLUID LEVEL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

Brake fluid level switch		ABS actuator and electric unit (control unit)		Continuity
Connector	Terminal	Connector	Terminal	
M37	1	E36	7	Existed

2. Check the continuity between brake fluid level switch harness connector and combination meter harness connector.

Brake fluid level switch		Combination meter		Continuity
Connector	Terminal	Connector	Terminal	
M37	1	E34	27	Existed

3. Check the continuity between brake fluid level switch harness connector and ground.

Brake fluid level switch		—	Continuity
Connector	Terminal		
E37	2	Ground	Existed

4. Check the continuity between combination meter harness connector and ground.

Combination meter		—	Continuity
Connector	Terminal		
E34	27	Ground	Existed

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-113, "Exploded View"](#).  
 NO >> Repair or replace error-detected parts.

## Component Inspection

INFOID:000000005517344

### 1. CHECK BRAKE FLUID LEVEL SWITCH

- Turn the ignition switch OFF.
- Disconnect brake fluid level switch connector.
- Check the continuity between brake fluid level switch connector terminals.

Brake fluid level switch	Condition	Continuity
Terminal		
1 - 2	When brake fluid is full in the reservoir tank.	Not existed
	When brake fluid is empty in the reservoir tank.	Existed

Is the inspection result normal?

- YES >> INSPECTION END  
 NO >> Replace reservoir tank. Refer to [BR-27, "Exploded View"](#).

## Special Repair Requirement

INFOID:000000005532222

### 1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

After removing/replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.

- Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

# C1160 INCOMPLETE DECEL G SENSOR CALIBRATION

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## C1160 INCOMPLETE DECEL G SENSOR CALIBRATION

### Description

INFOID:000000005517346

Yaw rate/side/decel G sensor detects decel G affecting the vehicle, and transmits the data to the ABS actuator and electric unit (control unit) as an analog voltage signal.

### DTC Logic

INFOID:000000005517347

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1160	DECEL G SEN SET	Calibration of decel G sensor is not finished.	<ul style="list-style-type: none"><li>• yaw rate/side/decel G sensor</li><li>• Harness or connector</li><li>• ABS actuator and electric unit (control unit)</li><li>• Incomplete decel G sensor calibration</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Select "ABS", "WORK SUPPORT" and "DECEL G SEN CALIBRATION" in order with CONSULT-III, and perform calibration of decel G sensor. Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Special Repair Requirement"](#).
3. Perform self-diagnosis for "ABS" with CONSULT-III.

#### Is DTC "C1160" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-68, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000005517348

#### 1. CHECK YAW RATE/SIDE/DECEL G SENSOR

Check yaw rate/side/decel G sensor. Refer to [BRC-45, "Component Inspection"](#).

#### Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-113, "Exploded View"](#).  
NO >> Repair or replace error-detected parts.

### Special Repair Requirement

INFOID:000000005532223

#### 1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

- After removing/replacing a yaw rate/side/decel G sensor, be sure to perform the following procedure.
  - Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing/replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
  - Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
  - Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

# C1161 INCOMPLETE SIDE G SENSOR CALIBRATION

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## C1161 INCOMPLETE SIDE G SENSOR CALIBRATION

### Description

INFOID:000000005517350

Yaw rate/side/decel G sensor detects side G affecting the vehicle, and transmits the data to the ABS actuator and electric unit (control unit) as an analog voltage signal.

### DTC Logic

INFOID:000000005517351

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1161	SIDE G SEN SET	When there is an internal malfunction in the ABS actuator and electric unit (control unit).	ABS actuator and electric unit (control unit)

### DTC CONFIRMATION PROCEDURE

#### 1. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT-III.

#### Is DTC "C1161" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-69. "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000005517352

#### 1. CHECK YAW RATE/SIDE/DECEL G SENSOR

Replace ABS actuator and electric unit (control unit) when self-diagnostic result shows items other than those applicable.

- >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-113. "Exploded View"](#).

### Special Repair Requirement

INFOID:000000005683362

#### 1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

After removing/replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.

- Adjustment of steering angle sensor neutral position: Refer to [BRC-9. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

# C1162 INCOMPLETE PRESSURE SENSOR CALIBRATION

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## C1162 INCOMPLETE PRESSURE SENSOR CALIBRATION

### Description

INFOID:000000005517354

The pressure sensor converts the brake fluid pressure to an electric signal and transmits it to the ABS actuator and electric unit (control unit). [The pressure sensor is integrated in the ABS actuator and electric unit (control unit).]

### DTC Logic

INFOID:000000005517355

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1162	PRESS SEN SET	When there is an internal malfunction in the ABS actuator and electric unit (control unit).	ABS actuator and electric unit (control unit)

### DTC CONFIRMATION PROCEDURE

#### 1. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT-III.

#### Is DTC "C1162" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-70. "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000005517356

#### 1. REPLACE ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Replace ABS actuator and electric unit (control unit) when self-diagnostic result shows items other than those applicable.

- >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-113. "Exploded View"](#).

### Special Repair Requirement

INFOID:000000005532225

#### 1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

After removing/replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.

- Adjustment of steering angle sensor neutral position: Refer to [BRC-9. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

# C1164, C1165 CV SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## C1164, C1165 CV SYSTEM

### Description

INFOID:00000000517358

The cut valve shuts off the normal brake fluid path from the master cylinder, when VDC/TCS is activated.

### DTC Logic

INFOID:00000000517359

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1164	CV1	VDC switch-over solenoid valve (CV1) on the primary side is open circuit or shorted, or the control line is open or shorted to the power supply or the ground.	<ul style="list-style-type: none"> <li>• Harness or connector</li> <li>• ABS actuator and electric unit (control unit)</li> </ul>
C1165	CV2	VDC switch-over solenoid valve (CV2) on the secondary side is open circuit or shorted, or the control line is open or shorted to the power supply or the ground.	

### DTC CONFIRMATION PROCEDURE

#### 1. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT-III.

Is DTC "C1164" or "C1165" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-71, "Diagnosis Procedure"](#).  
 NO >> INSPECTION END

### Diagnosis Procedure

INFOID:00000000517360

#### 1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, etc.

Is the inspection result normal?

- YES >> GO TO 2.  
 NO >> Replace or repair error-detected parts.

#### 2. CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY POWER SUPPLY CIRCUIT

Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Voltage
Connector	Terminal		
E36	1	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> Repair or replace error-detected parts.

#### 3. CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY GROUND CIRCUIT

Check the continuity between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	13	Ground	Existed
	26		

Is the inspection result normal?

# C1164, C1165 CV SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-113. "Exploded View"](#).  
 NO >> Repair or replace error-detected parts.

## Component Inspection

INFOID:000000005517361

### 1. CHECK ACTIVE TEST

1. Select "ABS", "ACTIVE TEST" and each test menu item in order with CONSULT-III.
2. Select "Up", "ACT UP", and "ACT KEEP", and check that the system operates as shown in the table below.

Test item	Display item	Display		
		Up	ACT UP	ACT KEEP
FR RH ABS SOLENOID (ACT)	FR RH IN SOL	Off	Off	Off
	FR RH OUT SOL	Off	Off	Off
	CV1	Off	On	On
	SV1	Off	On*	Off
FR LH ABS SOLENOID (ACT)	FR LH IN SOL	Off	Off	Off
	FR LH OUT SOL	Off	Off	Off
	CV2	Off	On	On
	SV2	Off	On*	Off
RR RH ABS SOLENOID (ACT)	RR RH IN SOL	Off	Off	Off
	RR RH OUT SOL	Off	Off	Off
	CV2	Off	On	On
	SV2	Off	On*	Off
RR LH ABS SOLENOID (ACT)	RR LH IN SOL	Off	Off	Off
	RR LH OUT SOL	Off	Off	Off
	CV1	Off	On	On
	SV1	Off	On*	Off

\*: On for 1 to 2 seconds after the select, and then Off.

**NOTE:**

A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is a operation for checking.

Is the inspection result normal?

- YES >> INSPECTION END  
 NO >> Proceed to diagnosis procedure. Refer to [BRC-71. "Diagnosis Procedure"](#).

## Special Repair Requirement

INFOID:000000005532226

### 1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

After removing/replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.

- Adjustment of steering angle sensor neutral position: Refer to [BRC-9. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END



C1166, C1167 SV SYSTEM

Description

INFOID:00000000517363

The suction valve supplies the brake fluid from the master cylinder to the pump, when VDC/TCS is activated.

DTC Logic

INFOID:00000000517364

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1166	SV1	VDC switch-over solenoid valve (SV1) on the primary side is open circuit or shorted, or the control line is open or shorted to the power supply or the ground.	<ul style="list-style-type: none"> <li>• Harness or connector</li> <li>• ABS actuator and electric unit (control unit)</li> </ul>
C1167	SV2	VDC switch-over solenoid valve (SV2) on the secondary side is open circuit or shorted, or the control line is open or shorted to the power supply or the ground.	

DTC CONFIRMATION PROCEDURE

1. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT-III.

Is DTC "C1166" or "C1167" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-73, "Diagnosis Procedure"](#).
- NO >> INSPECTION END

Diagnosis Procedure

INFOID:00000000517365

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, etc.

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Replace or repair error-detected parts.

2. CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY POWER SUPPLY CIRCUIT

Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Voltage
Connector	Terminal		
E36	1	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace error-detected parts.

3. CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY GROUND CIRCUIT

Check the continuity between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	13	Ground	Existed
	26		

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-113. "Exploded View"](#).  
 NO >> Repair or replace error-detected parts.

## Component Inspection

INFOID:000000005517366

### 1. CHECK ACTIVE TEST

1. Select "ABS", "ACTIVE TEST" and each test menu item in order with CONSULT-III.
2. Select "Up", "ACT UP", and "ACT KEEP", and check that the system operates as shown in the table below.

Test item	Display item	Display		
		Up	ACT UP	ACT KEEP
FR RH ABS SOLENOID (ACT)	FR RH IN SOL	Off	Off	Off
	FR RH OUT SOL	Off	Off	Off
	CV1	Off	On	On
	SV1	Off	On*	Off
FR LH ABS SOLENOID (ACT)	FR LH IN SOL	Off	Off	Off
	FR LH OUT SOL	Off	Off	Off
	CV2	Off	On	On
	SV2	Off	On*	Off
RR RH ABS SOLENOID (ACT)	RR RH IN SOL	Off	Off	Off
	RR RH OUT SOL	Off	Off	Off
	CV2	Off	On	On
	SV2	Off	On*	Off
RR LH ABS SOLENOID (ACT)	RR LH IN SOL	Off	Off	Off
	RR LH OUT SOL	Off	Off	Off
	CV1	Off	On	On
	SV1	Off	On*	Off

\*: On for 1 to 2 seconds after the select, and then Off.

**NOTE:**

A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is a operation for checking.

Is the inspection result normal?

- YES >> INSPECTION END  
 NO >> Proceed to diagnosis procedure. Refer to [BRC-73. "Diagnosis Procedure"](#).

## Special Repair Requirement

INFOID:000000005532352

### 1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

After removing/replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.

- Adjustment of steering angle sensor neutral position: Refer to [BRC-9. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

# U1000, U1002 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## U1000, U1002 CAN COMM CIRCUIT

### Description

INFOID:000000005517368

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### DTC Logic

INFOID:000000005517369

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
U1000	CAN COMM CIRCUIT	When ABS actuator and electric unit (control unit) is not transmitting or receiving CAN communication signal for 2 seconds or more.	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• CAN communication line</li><li>• ABS actuator and electric unit (control unit)</li></ul>
U1002	SYSTEM COOM	When ABS actuator and electric unit (control unit) is not transmitting or receiving CAN communication signal of steering angle sensor for 2 seconds or less.	

A

B

C

D

E

BRC

G

### DTC CONFIRMATION PROCEDURE

#### 1. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT-III.

Is DTC "U1000" or "U1002" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-75, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

H

I

J

### Diagnosis Procedure

INFOID:000000005517370

#### 1. PERFORM ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT-III.

Is the inspection result normal?

- YES >> Refer to [LAN-17, "Trouble Diagnosis Flow Chart"](#).  
NO >> INSPECTION END

K

L

### Special Repair Requirement

INFOID:000000005533017

#### 1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

- After removing/replacing a steering angle sensor, be sure to perform the following procedure.
  - Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- After removing/replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
  - Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
  - Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).

N

O

P

>> END

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## POWER SUPPLY AND GROUND CIRCUIT

### Description

INFOID:00000000517372

Supplies power to ABS actuator and electric unit (control unit).

### Diagnosis Procedure

INFOID:00000000517373

#### 1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) IGNITION POWER SUPPLY

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Voltage (Approx.)
Connector	Terminal		
E36	20	Ground	0 V

4. Turn the ignition switch ON.  
**CAUTION:**  
**Never start the engine.**
5. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Voltage
Connector	Terminal		
E36	20	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace error-detected parts.

#### 2. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY

1. Turn the ignition switch OFF.
2. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Voltage
Connector	Terminal		
E36	1	Ground	Battery voltage

3. Turn the ignition switch ON.  
**CAUTION:**  
**Never start the engine.**
4. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Voltage
Connector	Terminal		
E36	1	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace error-detected parts.

#### 3. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND

1. Turn the ignition switch OFF.
2. Check the continuity between ABS actuator and electric unit (control unit) harness connector and ground.

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	13	Ground	Existed
	26		

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace error-detected parts.

## Special Repair Requirement

INFOID:000000005532206

### 1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

After removing/replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.

- Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# PARKING BRAKE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## PARKING BRAKE SWITCH

### Component Function Check

INFOID:000000005517374

#### 1. CHECK PARKING BRAKE SWITCH OPERATION

Operate the parking brake pedal. Then check that the brake warning lamp in the combination meter turns ON/OFF correctly.

Condition	Brake warning lamp illumination status
When the parking brake pedal is operation	ON
When the parking brake pedal is not operation.	OFF

Is the inspection result normal?

YES >> INSPECTION END

NO >> Proceed to diagnosis procedure. Refer to [BRC-78, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005517375

#### 1. CHECK PARKING BRAKE SWITCH

Check parking brake switch. Refer to [BRC-78, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace parking brake switch. Refer to [PB-6, "Exploded View"](#).

#### 2. CHECK COMBINATION METER

Check the indication and operation of combination meter are normal. Refer to [MWI-33, "Diagnosis Description"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check combination meter. Refer to [MWI-34, "CONSULT-III Function \(METER/M&A\)"](#).

#### 3. CHECK PARKING BRAKE SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect parking brake switch harness connector.
3. Disconnect combination meter harness connector.
4. Check the continuity between parking brake switch harness connector and combination meter harness connector.

Parking brake switch		Combination meter		Continuity
Connector	Terminal	Connector	Terminal	
E27	1	M34	26	Existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace error-detected parts.

### Component Inspection

INFOID:000000005517376

#### 1. CHECK PARKING BRAKE SWITCH

1. Turn the ignition switch OFF.
2. Disconnect parking brake switch harness connector.
3. Check the continuity between parking brake switch harness connector and ground.

# PARKING BRAKE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

Parking brake switch		—	Condition	Continuity
Connector	Terminal			
E27	1	Ground	When the parking brake switch is operated.	Existed
			When the parking brake switch is not operated.	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace parking brake switch. Refer to [PB-6. "Exploded View"](#).

A  
B  
C  
D  
E  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

BRC

# VDC OFF SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## VDC OFF SWITCH

### Description

INFOID:000000005517377

VDC OFF switch can deactivate (turn OFF) the VDC/TCS function by pressing the VDC OFF switch.

### Component Function Check

INFOID:000000005517378

#### 1. CHECK VDC OFF SWITCH OPERATION

Turn ON/OFF the VDC OFF switch and check that the VDC OFF indicator lamp in the combination meter turns ON/OFF correctly.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Proceed to diagnosis procedure. Refer to [BRC-80, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005517379

#### 1. CHECK VDC OFF SWITCH

Check VDC OFF switch. Refer to [BRC-81, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace VDC OFF switch.

#### 2. CHECK VDC OFF SWITCH HARNESS

1. Disconnect ABS actuator and electric unit (control unit) harness connector.
2. Disconnect VDC OFF switch harness connector.
3. Check the continuity between VDC OFF switch harness connector and ABS actuator and electric unit (control unit) harness connector.

ABS actuator and electric unit (control unit)		VDC OFF switch		Continuity
Connector	Terminal	Connector	Terminal	
E36	22	M5	1	Existed

4. Check the continuity between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	22	Ground	Not existed

5. Check the continuity between VDC OFF switch harness connector and ground.

VDC OFF switch		—	Continuity
Connector	Terminal		
M5	2	Ground	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace error-detected parts.

#### 3. CHECK COMBINATION METER

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Connect VDC OFF switch harness connector.
3. Check the indication and operation of combination meter are normal. Refer to [MWI-33, "Diagnosis Description"](#).

Is the inspection result normal?

YES >> INSPECTION END



# VDC OFF SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

NO >> Repair or replace combination meter.

## Component Inspection

INFOID:00000000517380

### 1. CHECK VDC OFF SWITCH

1. Turn the ignition switch OFF.
2. Disconnect VDC OFF switch harness connector.
3. Check the continuity between VDC OFF switch harness connector terminals.

VDC OFF switch Terminal	Condition	Condition
1 - 2	When VDC OFF switch is hold pressed.	Existed
	When releasing VDC OFF switch.	Not existed

Is the inspection result normal?

- YES >> INSPECTION END  
NO >> Replace VDC OFF switch.

A  
B  
C  
D  
E  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

**BRC**

# ABS WARNING LAMP

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## ABS WARNING LAMP

### Description

INFOID:000000005517381

×: ON –: OFF

Condition	ABS warning lamp
Ignition switch OFF	–
For 2 seconds after turning ignition switch ON	×
2 seconds later after turning ignition switch ON	–
ABS function is malfunctioning.	×
EBD function is malfunctioning.	×

### Component Function Check

INFOID:000000005517382

#### 1.CHECK ABS WARNING LAMP OPERATION

Check that the lamp illuminates for approximately 2 seconds after the ignition switch is turned ON.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Proceed to diagnosis procedure. Refer to [BRC-82, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005517383

#### 1.CHECK SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT-III.

Is the inspection result normal?

YES >> Check combination meter. Refer to [MWI-34, "CONSULT-III Function \(METER/M&A\)"](#).

NO >> Check items displayed by self-diagnosis for "ABS" with CONSULT-III.

### Special Repair Requirement

INFOID:000000005532354

#### 1.ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

After removing/replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.

- Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

# BRAKE WARNING LAMP

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## BRAKE WARNING LAMP

### Description

INFOID:000000005517385

×: ON –: OFF

Condition	Brake warning lamp (Note 1)
Ignition switch OFF	–
For 2 seconds after turning ignition switch ON	× (Note 2)
2 seconds later after turning ignition switch ON	× (Note 2)
EBD function is malfunctioning.	×

#### NOTE:

- 1: Brake warning lamp will turn on in case of parking brake operation (when switch is ON) or of brake fluid level switch operation (when brake fluid is insufficient).
- 2: After starting the engine, brake warning lamp is turned off.

### Component Function Check

INFOID:000000005517386

BRC

#### 1. BRAKE WARNING LAMP OPERATION CHECK 1

Check that the lamp illuminates for approximately 2 seconds after the ignition switch is turned ON.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Proceed to diagnosis procedure. Refer to [BRC-83, "Diagnosis Procedure"](#).

#### 2. BRAKE WARNING LAMP OPERATION CHECK 2

Check that the brake warning lamp in the combination meter turns ON/OFF correctly when operating the parking brake pedal.

#### NOTE:

Brake warning lamp will turn on in case of parking brake operation (when switch is ON) or of brake fluid level switch operation (when brake fluid is insufficient).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Check parking brake switch. Refer to [BRC-78, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005517387

#### 1. CHECK PARKING BRAKE SWITCH

Check that the brake warning lamp in the combination meter turns ON/OFF correctly when operating the parking brake pedal.

#### NOTE:

Brake warning lamp will turn on in case of parking brake operation (when switch is ON) or of brake fluid level switch operation (when brake fluid is insufficient).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check parking brake switch. Refer to [BRC-78, "Diagnosis Procedure"](#).

#### 2. CHECK SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT-III.

Is the inspection result normal?

YES >> Check combination meter. Refer to [MWI-34, "CONSULT-III Function \(METER/M&A\)"](#).

NO >> Check items displayed by self-diagnosis for "ABS" with CONSULT-III.

### Special Repair Requirement

INFOID:000000005532355

#### 1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

## BRAKE WARNING LAMP

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

After removing/replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.

- Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

# VDC OFF INDICATOR LAMP

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## VDC OFF INDICATOR LAMP

### Description

INFOID:000000005517389

x: ON –: OFF

Condition	VDC OFF indicator lamp
Ignition switch OFF	–
For 2 seconds after turning ignition switch ON	x
2 seconds later after turning ignition switch ON	–
VDC OFF switch turned ON. (VDC function is OFF.)	x
VDC/TCS function is malfunctioning.	x
ABS function is malfunctioning.	x
EBD function is malfunctioning.	x

### Component Function Check

INFOID:000000005517390

#### 1.VDC OFF INDICATOR LAMP OPERATION CHECK 1

Check that the lamp illuminates for approximately 2 seconds after the ignition switch is turned ON.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Proceed to diagnosis procedure. Refer to [BRC-85, "Diagnosis Procedure"](#).

#### 2.VDC OFF INDICATOR LAMP OPERATION CHECK 2

Check that the VDC OFF indicator lamp in the combination meter turns ON/OFF correctly when operating the VDC OFF switch.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Check VDC OFF switch. Refer to [BRC-80, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005517391

#### 1.CHECK VDC OFF SWITCH

Check that the VDC OFF indicator lamp in the combination meter turns ON/OFF correctly when operating the VDC OFF switch.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check VDC OFF switch. Refer to [BRC-80, "Diagnosis Procedure"](#).

#### 2.CHECK SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT-III.

Is the inspection result normal?

YES >> Check combination meter. Refer to [MWI-34, "CONSULT-III Function \(METER/M&A\)"](#).

NO >> Check items displayed by self-diagnosis for "ABS" with CONSULT-III.

# SLIP INDICATOR LAMP

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## SLIP INDICATOR LAMP

### Description

INFOID:000000005517393

×: ON Δ: Blink –: OFF

Condition	SLIP indicator lamp
Ignition switch OFF	–
For 2 seconds after turning ignition switch ON	×
2 seconds later after turning ignition switch ON	–
VDC/TCS is activated while driving.	Δ
VDC/TCS function is malfunctioning.	×
ABS function is malfunctioning.	×
EBD function is malfunctioning.	×

### Component Function Check

INFOID:000000005517394

#### 1. CHECK SLIP INDICATOR LAMP OPERATION

Check that the lamp illuminates for approximately 2 seconds after the ignition switch is turned ON.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Proceed to diagnosis procedure. Refer to [BRC-86, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005517395

#### 1. CHECK SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT-III.

Is the inspection result normal?

YES >> Check combination meter. Refer to [MWI-34, "CONSULT-III Function \(METER/M&A\)"](#).

NO >> Check items displayed by self-diagnosis for "ABS" with CONSULT-III.

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

## ECU DIAGNOSIS INFORMATION

### ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

#### Reference Value

INFOID:000000005517397

#### VALUES ON THE DIAGNOSIS TOOL

#### CAUTION:

The display shows the control unit calculation data, so a normal value might be displayed even in the event the output circuit (harness) is open or short-circuited.

Monitor item	Display content	Data monitor	
		Condition	Reference value in normal operation
FR LH SENSOR	Wheel speed	Vehicle stopped	0 [km/h (MPH)]
		Vehicle running (Note 1)	Nearly matches the speedometer display ( $\pm 10\%$ or less)
FR RH SENSOR	Wheel speed	Vehicle stopped	0 [km/h (MPH)]
		Vehicle running (Note 1)	Nearly matches the speedometer display ( $\pm 10\%$ or less)
RR LH SENSOR	Wheel speed	Vehicle stopped	0 [km/h (MPH)]
		Vehicle running (Note 1)	Nearly matches the speedometer display ( $\pm 10\%$ or less)
RR RH SENSOR	Wheel speed	Vehicle stopped	0 [km/h (MPH)]
		Vehicle running (Note 1)	Nearly matches the speedometer display ( $\pm 10\%$ or less)
STOP LAMP SW	Brake pedal operation	When brake pedal is depressed	On
		When brake pedal is not depressed	Off
BATTERY VOLT	Battery voltage supplied to the ABS actuator and electric unit (control unit)	Ignition switch ON	10 – 16 V
GEAR	Gear position	Vehicle running	1 – 6
R POSI SIG	Select shift position	CVT shift position (R)	On
		CVT shift position (other R)	Off
N POSI SIG	Select shift position	CVT shift position (N)	On
		CVT shift position (other N)	Off
P POSI SIG	Select shift position	CVT shift position (P)	On
		CVT shift position (other P)	Off
SLCT LVR POSI	Select shift position	CVT shift position (P, R, N, D, L)	P R N D L
		Manual mode	##
OFF SW	VDC OFF switch ON/OFF status	VDC OFF switch ON (When VDC OFF indicator lamp is ON)	On
		VDC OFF switch OFF (When VDC OFF indicator lamp is OFF)	Off
YAW RATE SEN	Yaw rate detected by yaw rate/side/decel sensor	Vehicle stopped	Approx. 0 d/s
		Vehicle running	-100 to 100 d/s

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

Monitor item	Display content	Data monitor	
		Condition	Reference value in normal operation
DECEL G-SEN	Decel G detected by yaw rate/side/decel G sensor	Vehicle stopped	Approx. 0 G
		Vehicle running	-1.7 – +1.7 G
ACCEL POS SIG	Open/Close condition of throttle valve (Linked with accelerator pedal)	Accelerator pedal not depressed (Engine stopped)	0 %
		Depress accelerator pedal (Engine stopped)	0 - 100 %
SIDE G-SENSOR	Transverse G detected by yaw rate/side/decel G sensor	Vehicle stopped	Approx. 0 m/s <sup>2</sup>
		Vehicle running	- 16.7 – 16.7 m/s <sup>2</sup>
STR ANGLE SIG	Steering angle detected by steering angle sensor	Driving straight	-3.5 – +3.5°
		Turn 90 ° to right	Approx. -90 °
		Turn 90 ° to left	Approx. +90 °
ENGINE RPM	With engine running	With engine stopped	0 [tr/min (rpm)]
		Engine running	Almost in accordance with tachometer display
FLUID LEV SW	Brake fluid level switch signal status	When brake fluid level switch ON	On
		When brake fluid level switch OFF	Off
PRESS SENSOR	Brake fluid pressure detected by pressure sensor	With ignition switch ON and brake pedal released	Approx. 0 bar
		With ignition switch ON and brake pedal depressed	0 – 170 bar
FR RH IN SOL (Note 2)	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
FR RH OUT SOL (Note 2)	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
FR LH IN SOL (Note 2)	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
FR LH OUT SOL (Note 2)	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
RR RH IN SOL (Note 2)	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off



# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

Monitor item	Display content	Data monitor		
		Condition	Reference value in normal operation	
RR RH OUT SOL (Note 2)	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On	A
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off	B
RR LH IN SOL (Note 2)	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On	C
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off	D
RR LH OUT SOL (Note 2)	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On	E
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off	BRC
MOTOR RELAY	Motor and motor relay operation	Ignition switch ON or engine running (ABS operated)	On	G
		Ignition switch ON or engine running (ABS not operated)	Off	H
ACTUATOR RLY (Note 2)	Actuator relay operation	Vehicle stopped (Engine running)	On	I
		Vehicle stopped (Ignition switch ON)	Off	J
ABS WARN LAMP	ABS warning lamp (Note 3)	When ABS warning lamp is ON	On	K
		When ABS warning lamp is OFF	Off	L
OFF LAMP	VDC OFF indicator lamp (Note 3)	When VDC OFF indicator lamp is ON	On	M
		When VDC OFF indicator lamp is OFF	Off	N
SLIP LAMP	SLIP indicator lamp (Note 3)	When SLIP indicator lamp is ON	On	O
		When SLIP indicator lamp is blinking	On	P
		When SLIP indicator lamp is OFF	Off	
CV1	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On	
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off	
CV2	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On	
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off	
SV1	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On	
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off	

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

Monitor item	Display content	Data monitor	
		Condition	Reference value in normal operation
SV2	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
EBD SIGNAL	EBD operation	EBD is active	On
		EBD is inactive	Off
ABS SIGNAL	ABS operation	ABS is active	On
		ABS is inactive	Off
TCS SIGNAL	TCS operation	TCS is active	On
		TCS is inactive	Off
VDC SIGNAL	VDC operation	VDC is active	On
		VDC is inactive	Off
EBD FAIL SIG	EBD fail-safe signal	In EBD fail-safe	On
		EBD is normal	Off
ABS FAIL SIG	ABS fail-safe signal	In ABS fail-safe	On
		ABS is normal	Off
TCS FAIL SIG	TCS fail-safe signal	In TCS fail-safe	On
		TCS is normal	Off
VDC FAIL SIG	VDC fail-safe signal	In VDC fail-safe	On
		VDC is normal	Off
EBD WARN LAMP	Brake warning lamp ( Note 3)	When brake warning lamp is ON	On
		When brake warning lamp is OFF	Off
CRANKING SIG	Crank operation	Crank is active	On
		Crank is inactive	Off
4WD FAIL REQ	ETS fail status	ETS fail	On
		ETS normal	Off
2WD/4WD	Drive axle	2WD model	2WD
		4WD model	4WD

**NOTE:**

- 1: Confirm tire pressure is normal.
- 2: A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is a operation for checking.
- 3: On and off timing for warning lamp and indicator lamp.
  - ABS warning lamp: Refer to [BRC-82, "Description"](#).
  - Brake warning lamp: Refer to [BRC-83, "Description"](#).
  - VDC OFF indicator lamp: Refer to [BRC-85, "Description"](#).
  - SLIP indicator lamp: Refer to [BRC-86, "Description"](#).


# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

## Wiring Diagram -BRAKE CONTROL SYSTEM-

INFOID:00000000517398



### BRAKE CONTROL SYSTEM

AW: AWD models  
2W: 2WD models

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

## BRAKE CONTROL SYSTEM

Connector No.	B4
Connector Name	WIRE TO WIRE
Connector Type	NS16FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	SB	-
2	W	-
3	W	-
4	R	-
5	O	-
6	P	-
7	L	-
8	B	-
9	LG	-
10	V	-
11	L	-
12	BR	-
13	P	-
14	BR	-
15	O	-
16	G	-


Connector No.	B12
Connector Name	WIRE TO WIRE
Connector Type	NS16FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	SB	-
3	GR	-
4	V	-
5	LG	-
7	SHIELD	-

8	O	-
9	G	-
10	BR	-
11	P	-
12	LG	-
13	O	-
14	W/R	-
15	B/R	-

Connector No.	B205
Connector Name	WIRE TO WIRE
Connector Type	RH12FB



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	SB	-
3	V	-
7	B	-
8	Y	-
9	P	-


Connector No.	B205
Connector Name	WIRE TO WIRE
Connector Type	NS16MW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	GR	-
3	BR	-
4	Y	-
5	BR	-
7	SHIELD	-

8	B	-
9	W	-
10	V	-
11	P	-
12	G	-
13	R	-
14	W/R	-
15	B/R	-

Connector No.	C2
Connector Name	WIRE TO WIRE
Connector Type	RH12MB



Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	SB	-
3	V	-
7	R	-
8	L	-
9	P	-

Connector No.	C3
Connector Name	REAR WHEEL SENSOR LH (2WD MODELS)
Connector Type	RH02FGY



Terminal No.	Color of Wire	Signal Name [Specification]
5	L	-
6	R	-

Connector No.	C4
Connector Name	REAR WHEEL SENSOR RH (2WD MODELS)
Connector Type	RH02FGY



Terminal No.	Color of Wire	Signal Name [Specification]
7	P	-
8	V	-

Connector No.	C5
Connector Name	REAR WHEEL SENSOR LH (4WD MODELS)
Connector Type	RH02ML



Terminal No.	Color of Wire	Signal Name [Specification]
5	L	-
6	R	-

Connector No.	C5
Connector Name	REAR WHEEL SENSOR RH (4WD MODELS)
Connector Type	RH02FGY



Terminal No.	Color of Wire	Signal Name [Specification]
7	P	-
8	V	-

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

## BRAKE CONTROL SYSTEM

Connector No.	E10
Connector Name	ABS INFLUENT POWER DISTRIBUTION MODULE FUSE BLOCK
Connector Type	1F20FW-GS72-M4-IV



Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	
2	Y	
3	GR	
4	BR	
5	P	
6	B	
7	SB	
8	W	
9	L/Y	
10	L	
11	O	
12	SB	
13	GR	
14	G	
15	GR	
16	Y	
17	W	
18	SB	
19	GR	
20	G	
21	Y	
22	SB	
23	GR	
24	G	
25	GR	
26	Y	
27	W	
28	SB	
29	GR	
30	BR	
31	V	
32	G	
33	O	
34	P	
35	G	
36	GR	

Connector No.	E22
Connector Name	FRONT WHEEL SENSOR LH
Connector Type	RH02MB




Terminal No.	Color of Wire	Signal Name [Specification]
1	W	
2	V	

Connector No.	E27
Connector Name	PARKING BRAKE SWITCH
Connector Type	P01FE-A



Terminal No.	Color of Wire	Signal Name [Specification]
1	P	

Connector No.	E36
Connector Name	ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)
Connector Type	AE22FB-AJ24-LH



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	VALVE/ECU SUPPLY
2	Y	WSS RL SIG(-)
3	L	WSS RL PWRC(-)

Terminal No.	Color of Wire	Signal Name [Specification]
4	GR	CLUSTER SUPPLY
5	B	WSS FR PWRC(+)
6	W	WSS FR SIG(-)
7	LG	LIS
8	V	WSS FL SIG(-)
9	W	WSS FL PWRC(+)
10	SB	CLUSTER GND
11	P	WSS RR PWRC(+)
12	V	WSS RR SIG(-)
13	B/W	MOTOR GND
14	G	MOTOR SUPPLY
16	SB	BLS
19	BR	CAN2 H
20	GR	IGN
21	P	CAN1 L
22	Y	VDC OFF SW
23	L	CAN1 H
25	W	CAN2 L
28	B/W	VALVE/ECU GND

Connector No.	E37
Connector Name	BRAKE FLUID LEVEL SWITCH
Connector Type	YV02FGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	P	
2	B	

Connector No.	E39
Connector Name	FRONT WHEEL SENSOR RH
Connector Type	RH02MB



Terminal No.	Color of Wire	Signal Name [Specification]
3	B	
4	W	

Connector No.	E103
Connector Name	FUSE BLOCK (U/B)
Connector Type	NS18FW-GS



Terminal No.	Color of Wire	Signal Name [Specification]
1F	L	
2F	LG	
4F	BR	
6F	Y	
8F	R	
9F	GR	
11F	G	
12F	V	

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]


## BRAKE CONTROL SYSTEM

Connector No.	E104
Connector Name	WIRE TO WIRE
Connector Type	NS06FW-GS



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	
2	SB	
3	L	
4	R	
5	L	
6	P	
7	L	
8	B/W	
9	SB	
10	GR	
11	R	
12	W	
13	P	
14	V	
15	Y	
16	L	

Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	TH70MW-GS10-M3



Terminal No.	Color of Wire	Signal Name [Specification]
2	BR	
3	Y	
4	W	
5	LG	
6	GR	
8	G	

11	P	
12	L	
13	Y	
14	O	
15	BR	
20	Y	
21	BR	
22	P	
23	P	
24	L	
25	O	
26	G	
27	V	
28	SB	
29	W	
30	Y	
47	P	
48	L	
48	SB	
50	GR	
51	LG	
52	V	
53	GR	
54	BR	
55	Y	
56	W/L	
60	V	
61	BR	
62	O	
63	L/O	
64	SHIELD	
66	W	
67	BR	
68	Y	
69	SB	
70	GR	
71	SB	
72	Y	
72	U	
74	W	
75	BR	
76	GR	
77	O	
78	V	
79	Y	
80	R	
81	W	
82	LG	
83	O	

Connector No.	E116
Connector Name	STOP LAMP SWITCH
Connector Type	MM04FW-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	
2	LG	
3	G	
4	Y	

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS06FW-M2



Terminal No.	Color of Wire	Signal Name [Specification]
1A	Y	
2A	G	
3A	Y	
4A	GR	
5A	R	
6A	W	
7A	LG	
8A	Y	

Connector No.	M5
Connector Name	VDC OFF SWITCH
Connector Type	TK08FGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	
2	B	
3	R	
4	SB	


# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

## BRAKE CONTROL SYSTEM


Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Type	TH07PW-CSD-U-M3



Terminal No.	Color of Wire	Signal Name [Specification]
1	L	
2	L	
3	P	
4	O	
5	O	
6	G	
8	R	
11	P	
12	L	
13	V	
14	Y	
15	R	
20	Y	
21	BR	
22	G	
23	P	
24	Y	
25	L	
26	L	
27	O	
28	BR	
29	L	
30	R	
47	P	
48	L	
49	W	
50	GR	
51	LG	
52	Y	
53	V	
54	SB	
55	P	
56	SB	
60	V	
61	GR	
62	O	
63	V	
64	SHIELD	
86	W	


67	R	
68	W	
69	P	
70	G	
71	G	
72	BR	
73	L	
74	W	
75	BR	
76	R	
77	G	
78	Y	
79	G	
80	R	
81	W	
82	W	
83	O	

Connector No.	M30
Connector Name	STEERING ANGLE SENSOR
Connector Type	TH08FW-RH




Terminal No.	Color of Wire	Signal Name [Specification]
1	R	
2	P	
3	L	
4	G	
5	L	
6	SB	
8	O	

Connector No.	M34
Connector Name	COMBINATION METER
Connector Type	TH40FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	BAT
2	O	IGN
3	B	GROUND
4	B	GROUND
5	SB	ILLUMINATION CONTROL
8	SB	TRIP RESET SWITCH
9	W	SW ILL POWER
10	O	METER CONTROL SW GND
11	L	ENTER SWITCH
12	R	SELECT SWITCH
13	V	ILLUMINATION CONTROL SWITCH (+) (With automatic drive position)
13	Y	ILLUMINATION CONTROL SWITCH (-) (Without automatic drive position)
14	GR	ILLUMINATION CONTROL SWITCH (-)
15	BR	AIR BAG
18	L	AMBIENT SENSOR
19	P	AMBIENT SENSOR POWER
20	Y	AMBIENT SENSOR GROUND
21	L	CAN-H
22	P	CAN-L
23	B	GROUND
24	W	FUEL LEVEL SENSOR GROUND
25	BR	CHG
26	G	PARKING BRAKE SWITCH
27	V	BRAKE FLUID LEVEL SWITCH
29	R	WASHER LEVEL SWITCH
30	P	VEHICLE SPEED (2-PULSE)
31	V	VEHICLE SPEED (8-PULSE)
32	LG	OD OFF/SPORTS
34	G	FUEL LEVEL SENSOR
35	SB	SEAT BELT BUCKLE SWITCH (DRIVER SIDE)
36	R	SEAT BELT BUCKLE SWITCH (PASSENGER SIDE)

Connector No.	M52
Connector Name	YAW RATE / SIDE / DECEL G SENSOR
Connector Type	AAZ04FB-S



Terminal No.	Color of Wire	Signal Name [Specification]
1	P	
2	W	
3	R	
4	G	

## Fail-Safe

### ABS, EBD SYSTEM

If ABS malfunction electrically, ABS warning lamp, VDC OFF indicator lamp, SLIP indicator lamp will turn on. If EBD malfunction electrically, brake warning lamp, ABS warning lamp, VDC OFF indicator lamp and SLIP indicator lamp will turn on. Simultaneously, the VDC/TCS/ABS become one of the following conditions of the fail-safe function.

JCFWM0413GB

INFOID:000000005517399

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

[VDC/TCS/ABS]

## < ECU DIAGNOSIS INFORMATION >

- For malfunction of ABS, only the EBD is activated and the condition of vehicle is the same condition of vehicles without TCS/ABS system.

### NOTE:

ABS self-diagnosis sound may be heard. That is a normal condition because a self-diagnosis for "Ignition switch ON" and "The first starting" are being performed.

- For malfunction of EBD, EBD and ABS become inoperative, and the condition of vehicle is the same as the condition of vehicles without TCS/ABS, EBD system.

### VDC/TCS

If VDC/TCS/ABS system malfunction electrically, VDC OFF indicator lamp, SLIP indicator lamp are turned on, and the condition of vehicle is the same as the condition of vehicles without VDC/TCS control.

### CAUTION:

If the Fail-Safe function is activated, then perform self-diagnosis for "ABS" with CONSULT-III.

### DTC No. Index

INFOID:000000005517400

DTC	Items (CONSULT screen terms)	Reference
C1101	RR RH SENSOR-1	<a href="#">BRC-33, "DTC Logic"</a>
C1102	RR LH SENSOR-1	
C1103	FR RH SENSOR-1	
C1104	FR LH SENSOR-1	
C1105	RR RH SENSOR-2	<a href="#">BRC-36, "DTC Logic"</a>
C1106	RR LH SENSOR-2	
C1107	FR RH SENSOR-2	
C1108	FR LH SENSOR-2	
C1109	BATTERY VOLTAGE [ABNORMAL]	<a href="#">BRC-39, "DTC Logic"</a>
C1110	CONTROLLER FAILURE	<a href="#">BRC-41, "DTC Logic"</a>
C1111	PUMP MOTOR	<a href="#">BRC-42, "DTC Logic"</a>
C1113	G SENSOR	<a href="#">BRC-44, "DTC Logic"</a>
C1115	ABS SENSOR [ABNORMAL SIGNAL]	<a href="#">BRC-47, "DTC Logic"</a>
C1116	STOP LAMP SW	<a href="#">BRC-50, "DTC Logic"</a>
C1120	FR LH IN ABS SOL	<a href="#">BRC-52, "DTC Logic"</a>
C1121	FR LH OUT ABS SOL	<a href="#">BRC-54, "DTC Logic"</a>
C1122	FR RH IN ABS SOL	<a href="#">BRC-52, "DTC Logic"</a>
C1123	FR RH OUT ABS SOL	<a href="#">BRC-54, "DTC Logic"</a>
C1124	RR LH IN ABS SOL	<a href="#">BRC-52, "DTC Logic"</a>
C1125	RR LH OUT ABS SOL	<a href="#">BRC-54, "DTC Logic"</a>
C1126	RR RH IN ABS SOL	<a href="#">BRC-52, "DTC Logic"</a>
C1127	RR RH OUT ABS SOL	<a href="#">BRC-54, "DTC Logic"</a>
C1130	ENGINE SIGNAL 1	<a href="#">BRC-56, "DTC Logic"</a>
C1140	ACTUATOR RLY	<a href="#">BRC-58, "DTC Logic"</a>
C1142	PRESS SEN CIRCUIT	<a href="#">BRC-60, "DTC Logic"</a>
C1143	ST ANG SEN CIRCUIT	<a href="#">BRC-62, "DTC Logic"</a>
C1144	ST ANG SEN SIGNAL	<a href="#">BRC-64, "DTC Logic"</a>
C1145	YAW RATE SENSOR	<a href="#">BRC-44, "DTC Logic"</a>
C1146	SIDE G-SEN CIRCUIT	
C1155	BR FLUID LEVEL LOW	<a href="#">BRC-66, "DTC Logic"</a>
C1160	DECEL G SEN SET	<a href="#">BRC-68, "DTC Logic"</a>
C1161	SIDE G SEN SET	<a href="#">BRC-69, "DTC Logic"</a>



# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

DTC	Items (CONSULT screen terms)	Reference
C1162	PRESS SEN SET	<a href="#">BRC-70, "DTC Logic"</a>
C1164	CV1	<a href="#">BRC-71, "DTC Logic"</a>
C1165	CV2	
C1166	SV1	<a href="#">BRC-73, "DTC Logic"</a>
C1167	SV2	
U1000	CAN COMM CIRCUIT	<a href="#">BRC-75, "DTC Logic"</a>
U1002	SYSTEM COMM (CAN)	

A

B

C

D

E

**BRC**

G

H

I

J

K

L

M

N

O

P

## SYMPTOM DIAGNOSIS

### EXCESSIVE ABS FUNCTION OPERATION FREQUENCY

#### Diagnosis Procedure

INFOID:000000005517401

#### 1. CHECK START

Check front and rear brake force distribution using a brake tester. Refer to [BR-47, "General Specifications"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check brake system.

#### 2. CHECK FRONT AND REAR AXLE

Make sure that there is no excessive play in the front and rear axles.

- Front
  - 2WD models: Refer to [FAX-8, "Inspection"](#).
  - AWD models: Refer to [FAX-35, "Inspection"](#).
- Rear
  - 2WD models: Refer to [RAX-4, "Inspection"](#).
  - AWD models: Refer to [RAX-11, "Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace error-detected parts.

#### 3. CHECK WHEEL SENSOR AND SENSOR ROTOR

Check the following.

- Wheel sensor installation for damage.
  - Front wheel sensor: Refer to [BRC-110, "FRONT WHEEL SENSOR : Exploded View"](#).
  - Rear wheel sensor: Refer to [BRC-111, "REAR WHEEL SENSOR : Exploded View"](#).
- Wheel sensor connector connection.
- Wheel sensor harness inspection.
- Sensor rotor installation for damage.
  - Front sensor rotor: Refer to [BRC-112, "FRONT SENSOR ROTOR : Exploded View"](#).
  - Rear sensor rotor: Refer to [BRC-112, "REAR SENSOR ROTOR : Exploded View"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace wheel sensor or sensor rotor.

- Front wheel sensor: Refer to [BRC-110, "FRONT WHEEL SENSOR : Exploded View"](#).
- Rear wheel sensor: Refer to [BRC-111, "REAR WHEEL SENSOR : Exploded View"](#).
- Front sensor rotor: Refer to [BRC-112, "FRONT SENSOR ROTOR : Exploded View"](#).
- Rear sensor rotor: Refer to [BRC-112, "REAR SENSOR ROTOR : Exploded View"](#).

#### 4. CHECK ABS WARNING LAMP DISPLAY

Make sure that the ABS warning lamp is turned off after the ignition switch is turned ON or when driving.

Is the inspection result normal?

YES >> Normal

NO >> Perform self-diagnosis for "ABS" with CONSULT-III.

# UNEXPECTED PEDAL REACTION

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

## UNEXPECTED PEDAL REACTION

### Diagnosis Procedure

INFOID:00000000517402

#### 1.CHECK BRAKE PEDAL, BRAKE BOOSTER, BRAKE MASTER CYLINDER

Check brake pedal, brake booster, brake master cylinder mounting condition.

- Brake pedal: Refer to [BR-20, "Exploded View"](#).
- Brake booster: Refer to [BR-30, "Exploded View"](#).
- Brake master cylinder: Refer to [BR-27, "Exploded View"](#).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair or replace error-detected parts.

#### 2.CHECK BRAKE PEDAL STROKE

Check brake pedal stroke. Refer to [BR-9, "Inspection and Adjustment"](#).

Is the stroke too large?

- YES >> Bleed air from brake tube and hose. Refer to [BR-13, "Bleeding Brake System"](#).
- NO >> GO TO 3.

#### 3.CHECK FUNCTION

Disconnect ABS actuator and electric unit (control unit) connector to deactivate ABS. Check if braking force is normal in this condition. Connect connector after inspection.

Is the inspection result normal?

- YES >> Normal
- NO >> Check brake system.

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

## THE BRAKING DISTANCE IS LONG

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

---

### THE BRAKING DISTANCE IS LONG

#### Diagnosis Procedure

INFOID:00000000517403

**CAUTION:**

The stopping distance on slippery road surfaces might be longer with the ABS operating than when the ABS is not operating.

**1**.CHECK FUNCTION

---

Turn the ignition switch OFF and disconnect ABS actuator and electric unit (control unit) harness connector to deactivate ABS. In this condition, check stopping distance. After inspection, connect connector.

Is the inspection result normal?

YES >> Normal

NO >> Check brake system.

# ABS FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

## ABS FUNCTION DOES NOT OPERATE

### Diagnosis Procedure

INFOID:000000005517404

**CAUTION:**

**ABS does not operate when speed is 10 km/h (6 MPH) or lower.**

**1**.CHECK ABS WARNING LAMP DISPLAY

Make sure that the ABS warning lamp turns OFF after ignition switch is turned ON or when driving.

Is the inspection result normal?

YES >> Normal

NO >> Perform self-diagnosis.

A  
B  
C  
D  
E  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

**BRC**

# PEDAL VIBRATION OR ABS OPERATION SOUND OCCURS

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

## PEDAL VIBRATION OR ABS OPERATION SOUND OCCURS

### Diagnosis Procedure

INFOID:000000005517405

#### **CAUTION:**

Under the following conditions, ABS is activated and vibration is felt when brake pedal is lightly depressed (just place a foot on it). However, this is normal.

- When shifting gears
- When driving on slippery road
- During cornering at high speed
- When passing over bumps or grooves [at approximately 50 mm (1.97 in) or more]
- When pulling away just after starting engine [at approximately 10 km/h (6 MPH) or higher]

#### 1. SYMPTOM CHECK 1

---

Check that there are pedal vibrations when the engine is started.

Do vibrations occur?

YES >> GO TO 2.

NO >> Inspect the brake pedal. Refer to [BR-21, "Inspection and Adjustment"](#).

#### 2. SYMPTOM CHECK 2

---

Check that there are ABS operation noises when the engine is started.

Do the operation noises occur?

YES >> GO TO 3.

NO >> Perform self-diagnosis for "ABS" with CONSULT-III.

#### 3. SYMPTOM CHECK 3

---

Check symptoms when electrical component (headlamps, etc.) switches are operated.

Do symptoms occur?

YES >> Check if there is a radio, antenna, antenna lead wire, or wiring close to the control unit. If there is, move it farther away.

NO >> Normal

# VEHICLE JERKS DURING VDC/TCS/ABS CONTROL

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

## VEHICLE JERKS DURING VDC/TCS/ABS CONTROL

### Diagnosis Procedure

INFOID:000000005517406

#### 1.SYMPTOM CHECK

Check if the vehicle jerks during VDC/TCS/ABS control.

Is the inspection result normal?

- YES >> Normal.
- NO >> GO TO 2.

#### 2.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Are self-diagnosis results indicated?

- YES >> Check corresponding items, make repairs, and perform self-diagnosis for "ABS" with CONSULT-III.
- NO >> GO TO 3.

#### 3.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Check terminal for deformation, disconnection, looseness, etc.
4. Securely connect connectors and perform self-diagnosis for "ABS" with CONSULT-III.

Are self-diagnosis results indicated?

- YES >> If poor contact, damage, open or short circuit of connector terminal is found, repair or replace.
- NO >> GO TO 4.

#### 4.CHECK ECM AND TCM SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ENGINE" and "TRANSMISSION" with CONSULT-III.

Are self-diagnosis results indicated?

- YES >> Check the corresponding items.
- NO >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-113. "Exploded View"](#).

A  
B  
C  
D  
E  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

**BRC**

# NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

## NORMAL OPERATING CONDITION

### Description

INFOID:000000005517407

Symptom	Result
Slight vibrations are felt on the brake pedal and the operation noises occur, when VDC, TCS or ABS is activated.	This is a normal condition due to the VDC, TCS or ABS activation.
Stopping distance is longer than that of vehicles without ABS when the vehicle drives on rough, gravel, or snow-covered (fresh, deep snow) roads.	
The brake pedal moves and generates noises, when TCS or VDC is activated due to rapid acceleration or sharp turn.	
The brake pedal vibrates and motor operation noises occur from the engine room, after the engine starts and just after the vehicle starts.	This is a normal, and it is caused by the ABS operation check.
Depending on the road conditions, the driver may experience a sluggish feel.	This is normal, because TCS places the highest priority on the optimum traction (stability).
TCS may activate momentarily if wheel speed changes when driving over location where friction coefficient varies, when downshifting, or when fully depressing accelerator pedal.	
The ABS warning lamp, VDC OFF indicator lamp and SLIP indicator lamp may turn ON when the vehicle is subject to strong shaking or large vibration, such as when the vehicle is rotating on a turntable or located on a ship while the engine is running.	In this case, restart the engine on a normal road. If the normal condition is restored, there is no malfunction. At that time, erase the self-diagnosis memory.
VDC may not operate normally or the ABS warning lamp, VDC OFF indicator lamp, and SLIP indicator lamp may illuminate, when running on a special road that is extremely slanted (e.g. bank in a circuit course).	
A malfunction may occur in the yaw rate/side G sensor system, when the vehicle turns sharply, such as during a spin turn, axle turn, or drift driving, while the VDC function is off (VDC OFF indicator lamp illuminated).	
The vehicle speed will not increase even though the accelerator pedal is depressed, when inspecting the speedometer on a 2-wheel chassis dynamometer.	Normal (Deactivate the VDC/TCS function before performing an inspection on a chassis dynamometer.)



PRECAUTION

PRECAUTIONS  
FOR USA AND CANADA

FOR USA AND CANADA : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000005688780

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIR BAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

**WARNING:**

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

FOR USA AND CANADA : Precaution Necessary for Steering Wheel Rotation after Battery Disconnect

INFOID:000000005688783

**NOTE:**

- Before removing and installing any control units, first turn the push-button ignition switch to the LOCK position, then disconnect both battery cables.
- After finishing work, confirm that all control unit connectors are connected properly, then re-connect both battery cables.
- Always use CONSULT-III to perform self-diagnosis as a part of each function inspection after finishing work. If a DTC is detected, perform trouble diagnosis according to self-diagnosis results.

For vehicle with steering lock unit, if the battery is disconnected or discharged, the steering wheel will lock and cannot be turned.

If turning the steering wheel is required with the battery disconnected or discharged, follow the operation procedure below before starting the repair operation.

OPERATION PROCEDURE

1. Connect both battery cables.
  - NOTE:**  
Supply power using jumper cables if battery is discharged.
2. Turn the push-button ignition switch to ACC position.  
(At this time, the steering lock will be released.)
3. Disconnect both battery cables. The steering lock will remain released with both battery cables disconnected and the steering wheel can be turned.
4. Perform the necessary repair operation.

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

## PRECAUTIONS

[VDC/TCS/ABS]


### < PRECAUTION >

- When the repair work is completed, re-connect both battery cables. With the brake pedal released, turn the push-button ignition switch from ACC position to ON position, then to LOCK position. (The steering wheel will lock when the push-button ignition switch is turned to LOCK position.)
- Perform self-diagnosis check of all control units using CONSULT-III.

### FOR USA AND CANADA : Precaution for Procedure without Cowl Top Cover

INFOID:000000005688785

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc.



### FOR USA AND CANADA : Precaution for Brake System


INFOID:000000005517410

#### **WARNING:**

Clean any dust from the front brake and rear brake with a vacuum dust collector. Never blow with compressed air.

#### **CAUTION:**

- Brake fluid use refer to [MA-15, "FOR NORTH AMERICA : Fluids and Lubricants"](#).
- Never reuse drained brake fluid.
- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface.
- Never use mineral oils such as gasoline or light oil to clean. They may damage rubber parts and cause improper operation.
- Always loosen the brake tube flare nut with a flare nut wrench.
- Tighten the brake tube flare nut to the specified torque with crowfoot (A) and torque wrench (B).
- Always confirm the specified tightening torque when installing the brake pipes.
- Turn the ignition switch OFF and disconnect the ABS actuator and electric unit (control unit) connector or the battery negative terminal before performing the work.
- Check that no brake fluid leakage is present after replacing the parts.



### FOR USA AND CANADA : Precaution for Brake Control

INFOID:000000005517411

- When starting engine or when starting vehicle just after starting engine, brake pedal may vibrate or motor operating noise may be heard from engine compartment. This is normal condition.
- When an error is indicated by ABS or another warning lamp, collect all necessary information from customer (what symptoms are present under what conditions) and check for estimate causes before starting diagnostic servicing. Besides electrical system inspection, check brake booster operation, brake fluid level, and oil leaks.
- If tire size and type are used in an improper combination, or brake pads are not Genuine NISSAN parts, stopping distance or steering stability may deteriorate.
- ABS might be out of order or malfunctions by putting a radio (wiring inclusive), an antenna and a lead-in wire near the control unit.
- If aftermarket parts (car stereo, CD player, etc.) have been installed, check for incidents such as harness pinches, open circuits, and improper wiring.
- VDC system may not operate normally or a VDC OFF indicator lamp or SLIP indicator lamp may light.

# PRECAUTIONS

[VDC/TCS/ABS]

< PRECAUTION >

- When replacing the following parts with parts other than genuine parts or making modifications: Suspension-related parts (shock absorber, spring, bushing, etc.), tires, wheels (other than specified sizes), brake-related parts (pad, rotor, caliper, etc.), engine-related parts (muffler, ECM, etc.) and body reinforcement-related parts (roll bar, tower bar, etc.).
- When driving with worn or deteriorated suspension, tires and brake-related parts.

## FOR MEXICO

### FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000005688782

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

#### **WARNING:**

- **To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.**
- **Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIR BAG".**
- **Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.**

## PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

- **When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.**
- **When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.**

### FOR MEXICO : Precaution Necessary for Steering Wheel Rotation after Battery Disconnect

INFOID:000000005688784

#### **NOTE:**

- Before removing and installing any control units, first turn the push-button ignition switch to the LOCK position, then disconnect both battery cables.
- After finishing work, confirm that all control unit connectors are connected properly, then re-connect both battery cables.
- Always use CONSULT-III to perform self-diagnosis as a part of each function inspection after finishing work. If a DTC is detected, perform trouble diagnosis according to self-diagnosis results.

For vehicle with steering lock unit, if the battery is disconnected or discharged, the steering wheel will lock and cannot be turned.

If turning the steering wheel is required with the battery disconnected or discharged, follow the operation procedure below before starting the repair operation.

## OPERATION PROCEDURE

1. Connect both battery cables.

#### **NOTE:**

Supply power using jumper cables if battery is discharged.

2. Turn the push-button ignition switch to ACC position.  
(At this time, the steering lock will be released.)
3. Disconnect both battery cables. The steering lock will remain released with both battery cables disconnected and the steering wheel can be turned.
4. Perform the necessary repair operation.

## PRECAUTIONS

< PRECAUTION >


[VDC/TCS/ABS]

- When the repair work is completed, re-connect both battery cables. With the brake pedal released, turn the push-button ignition switch from ACC position to ON position, then to LOCK position. (The steering wheel will lock when the push-button ignition switch is turned to LOCK position.)
- Perform self-diagnosis check of all control units using CONSULT-III.

### FOR MEXICO : Precaution for Procedure without Cowl Top Cover

INFOID:000000005688786


When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc.



### FOR MEXICO : Precaution for Procedure without Cowl Top Cover

INFOID:000000005517413

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc.



### FOR MEXICO : Precaution for Brake System


INFOID:000000005517414

#### **WARNING:**

Clean any dust from the front brake and rear brake with a vacuum dust collector. Never blow with compressed air.

#### **CAUTION:**

- Brake fluid use refer to [MA-16, "FOR MEXICO : Fluids and Lubricants"](#).
- Never reuse drained brake fluid.
- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface.
- Never use mineral oils such as gasoline or light oil to clean. They may damage rubber parts and cause improper operation.
- Always loosen the brake tube flare nut with a flare nut wrench.
- Tighten the brake tube flare nut to the specified torque with crowfoot (A) and torque wrench (B).
- Always confirm the specified tightening torque when installing the brake pipes.
- Turn the ignition switch OFF and disconnect the ABS actuator and electric unit (control unit) connector or the battery negative terminal before performing the work.
- Check that no brake fluid leakage is present after replacing the parts.



# PRECAUTIONS

< PRECAUTION >

[VDC/TCS/ABS]

## FOR MEXICO : Precaution for Brake Control

INFOID:00000000517415

- When starting engine or when starting vehicle just after starting engine, brake pedal may vibrate or motor operating noise may be heard from engine compartment. This is normal condition.
- When an error is indicated by ABS or another warning lamp, collect all necessary information from customer (what symptoms are present under what conditions) and check for estimate causes before starting diagnostic servicing. Besides electrical system inspection, check brake booster operation, brake fluid level, and oil leaks.
- If tire size and type are used in an improper combination, or brake pads are not Genuine NISSAN parts, stopping distance or steering stability may deteriorate.
- ABS might be out of order or malfunctions by putting a radio (wiring inclusive), an antenna and a lead-in wire near the control unit.
- If aftermarket parts (car stereo, CD player, etc.) have been installed, check for incidents such as harness pinches, open circuits, and improper wiring.
- VDC system may not operate normally or a VDC OFF indicator lamp or SLIP indicator lamp may light.
- When replacing the following parts with parts other than genuine parts or making modifications: Suspension-related parts (shock absorber, spring, bushing, etc.), tires, wheels (other than specified sizes), brake-related parts (pad, rotor, caliper, etc.), engine-related parts (muffler, ECM, etc.) and body reinforcement-related parts (roll bar, tower bar, etc.).
- When driving with worn or deteriorated suspension, tires and brake-related parts.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

**BRC**


## REMOVAL AND INSTALLATION

### WHEEL SENSOR

#### FRONT WHEEL SENSOR

#### FRONT WHEEL SENSOR : Exploded View

INFOID:000000005517416



1. Front LH wheel sensor connector      2. Front LH wheel sensor

B. White line (slant line)

↶ : Vehicle front

Refer to [GI-4, "Components"](#) for symbol in the figure.

#### NOTE:

The above figure (front side) shows left side. Right side is the mirror image.

#### FRONT WHEEL SENSOR : Removal and Installation

INFOID:000000005517417

#### REMOVAL

Be careful with the following when removing sensor.

#### CAUTION:

- Never twist sensor harness as much as possible, when removing it. Pull sensors out without pulling sensor harness.
- Be careful to avoid damaging sensor edges or rotor teeth. Remove wheel sensor first before removing front or rear wheel hub. This is to avoid damage to sensor wiring and loss of sensor function.
- When you see the harness of the wheel sensor from the front side of the vehicle ensure that the white lines (B) are not twisted.

#### INSTALLATION

Be careful with the following when installing wheel sensor. Tighten installation bolts to the specified torques.

- When installing, make sure there is no foreign material such as iron chips on and in the mounting hole of the wheel sensor. Make sure no foreign material has been caught in the sensor rotor. Remove any foreign material and clean the mount.



# WHEEL SENSOR

[VDC/TCS/ABS]


## < REMOVAL AND INSTALLATION >

- When installing wheel sensor, be sure to press rubber grommets in until they lock at locations shown above in the figure. When installed, harness must not be twisted.

### REAR WHEEL SENSOR

#### REAR WHEEL SENSOR : Exploded View

INFOID:000000005517418



1. Rear RH wheel sensor
2. Rear RH wheel sensor connector
3. Rear LH wheel sensor connector
4. Rear LH wheel sensor

- B. AWD models only                      C. White line (slant line)

↶ : Vehicle front

Refer to [GI-4, "Components"](#) for symbol in the figure.

#### REAR WHEEL SENSOR : Removal and Installation

INFOID:000000005517419

##### REMOVAL

Be careful with the following when removing sensor.

##### **CAUTION:**

- **Never twist sensor harness as much as possible, when removing it. Pull sensors out without pulling sensor harness.**
- **Be careful to avoid damaging sensor edges or rotor teeth. Remove wheel sensor first before removing front or rear wheel hub. This is to avoid damage to sensor wiring and loss of sensor function.**

##### INSTALLATION

Be careful with the following when installing wheel sensor. Tighten installation bolts to the specified torques.

- When installing, make sure there is no foreign material such as iron chips on and in the mounting hole of the wheel sensor. Make sure no foreign material has been caught in the sensor rotor. Remove any foreign material and clean the mount.
- When installing wheel sensor, be sure to press rubber grommets in until they lock at locations shown above in the figure. When installed, harness must not be twisted.

# SENSOR ROTOR

< REMOVAL AND INSTALLATION >

[VDC/TCS/ABS]

## SENSOR ROTOR

### FRONT SENSOR ROTOR

#### FRONT SENSOR ROTOR : Exploded View

INFOID:000000005517420

Refer to [FAX-10, "Exploded View"](#) (2WD models), [FAX-37, "Exploded View"](#) (AWD models).

#### FRONT SENSOR ROTOR : Removal and Installation

INFOID:000000005517421

#### REMOVAL

Sensor rotor cannot be disassembled. Remove the sensor rotor together with hub bearing assembly. Refer to [FAX-10, "Removal and Installation"](#) (2WD models), [FAX-37, "Removal and Installation"](#) (AWD models).

#### INSTALLATION

Sensor rotor cannot be disassembled. Install the sensor rotor together with hub bearing assembly. Refer to [FAX-10, "Removal and Installation"](#) (2WD models), [FAX-37, "Removal and Installation"](#) (AWD models).

### REAR SENSOR ROTOR

#### REAR SENSOR ROTOR : Exploded View

INFOID:000000005517422

Refer to [RAX-5, "Exploded View"](#) (2WD models), [RAX-13, "Exploded View"](#) (AWD models).

#### REAR SENSOR ROTOR : Removal and Installation

INFOID:000000005517423

#### REMOVAL

Sensor rotor cannot be disassembled. Remove the sensor rotor together with hub bearing assembly. Refer to [RAX-5, "Removal and Installation"](#) (2WD models), [RAX-15, "Removal and Installation"](#) (AWD models).

#### INSTALLATION

Sensor rotor cannot be disassembled. Install the sensor rotor together with hub bearing assembly. Refer to [RAX-5, "Removal and Installation"](#) (2WD models), [RAX-15, "Removal and Installation"](#) (AWD models).



# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)


< REMOVAL AND INSTALLATION >

[VDC/TCS/ABS]

## ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Exploded View

INFOID:000000005517424



A  
B  
C  
D  
E  
G  
H  
I

BRC

J  
K  
L  
M  
N  
O  
P

1. ABS actuator and electric unit (control unit)      2. Bracket

- A. To rear RH brake caliper      B. To rear LH brake caliper      C. From master cylinder primary side  
D. To front RH brake caliper      E. To front LH brake caliper      F. From master cylinder secondary side

⇐: Vehicle front

Refer to [GI-4, "Components"](#) for symbol in the figure.

## Removal and Installation

INFOID:000000005517425

### REMOVAL

#### CAUTION:

- Before servicing, disconnect the battery cable from negative terminal.
- To remove brake tube, use a flare nut wrench to prevent flare nuts and brake tube from being damaged. To install, use flare nut crowfoot and torque wrench.
- Never apply excessive impact to ABS actuator and electric unit (control unit), such as dropping it.
- Never remove and install actuator by holding harness.

1. Remove cowl top. Refer to [EXT-21, "Exploded View"](#).
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Loosen brake tube flare nuts, then remove brake tubes from ABS actuator and electric unit (control unit).
4. Remove ABS actuator and electric unit (control unit) bracket mounting nut.
5. Remove ABS actuator and electric unit (control unit) from vehicle.

### INSTALLATION

Note the following, and install in the reverse order of removal.

#### CAUTION:

- Before servicing, disconnect the battery cable from negative terminal.

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)


< REMOVAL AND INSTALLATION >

[VDC/TCS/ABS]

- To remove brake tube, use a flare nut wrench to prevent flare nuts and brake tube from being damaged. To install, use flare nut crowfoot and torque wrench.
- Never apply excessive impact to ABS actuator and electric unit (control unit), such as dropping it.
- Never remove and install actuator by holding harness.
- After work is completed, bleed air from brake tube. Refer to [BR-13, "Bleeding Brake System"](#).
- After installing harness connector in the ABS actuator and electric unit (control unit), make sure connector is securely locked.
- After removing/replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
  - Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
  - Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).

Install ABS actuator and electric unit (control unit) as per the following steps.

1. Temporarily tighten mounting bolt (1) because the bracket (2) is temporarily being hold.
2. Tighten mounting bolt (3) while holding the bracket.
3. Tighten mounting bolts to the specified torque in the order of (4), (1).



# YAW RATE/SIDE/DECEL G SENSOR


< REMOVAL AND INSTALLATION >

[VDC/TCS/ABS]

## YAW RATE/SIDE/DECEL G SENSOR

Exploded View

INFOID:000000005517426



1. Yaw rate/side/decel G sensor
2. Connector

←: Vehicle front

Refer to [GI-4, "Components"](#) for symbol in the figure.

## Removal and Installation

INFOID:000000005517427

### REMOVAL

#### **CAUTION:**

**Never drop or strike yaw rate/side/decel G sensor, or never use power tool etc., because yaw rate/side/decel G sensor is sensitive to the impact.**

1. Remove center console assembly. Refer to [IP-20, "Exploded View"](#).
2. Disconnect yaw rate/side/decel G sensor harness connector.
3. Remove mounting nuts.
4. Remove yaw rate/side/decel G sensor.

### INSTALLATION

Note the following, and install in the reverse order of removal.

#### **CAUTION:**

- **Never drop or strike yaw rate/side/decel G sensor, or never use power tool etc., because yaw rate/side/decel G sensor is sensitive to the impact.**
- **After work, make sure to calibration of decel G sensor. Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).**

# STEERING ANGLE SENSOR


< REMOVAL AND INSTALLATION >

[VDC/TCS/ABS]

## STEERING ANGLE SENSOR

Exploded View

INFOID:000000005517428



1. Steering angle sensor

↔: Vehicle front

## Removal and Installation

INFOID:000000005517429

### REMOVAL

1. Remove spiral cable assembly. Refer to [SR-14, "Exploded View"](#).
2. Remove steering angle sensor from spiral cable assembly.

### INSTALLATION

Note the following, and install in the reverse order of removal.

#### **CAUTION:**

- **Never reuse steering angle sensor.**
- **After work, make sure to adjust neutral position of steering angle sensor. Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).**