

## SECTION **WW** WIPER & WASHER

### CONTENTS

<b>BASIC INSPECTION</b> .....	3	<b>DTC/CIRCUIT DIAGNOSIS</b> .....	25
<b>DIAGNOSIS AND REPAIR WORKFLOW</b> .....	3	<b>WIPER AND WASHER FUSE, FUSIBLE LINK</b> .....	25
Work Flow .....	3	Description .....	25
<b>SYSTEM DESCRIPTION</b> .....	5	Diagnosis Procedure .....	25
<b>FRONT WIPER AND WASHER SYSTEM</b> .....	5	<b>POWER SUPPLY AND GROUND CIRCUIT</b> ....	26
<b>WITH RAIN SENSOR</b> .....	5	<b>BCM (BODY CONTROL MODULE)</b> .....	26
WITH RAIN SENSOR : System Diagram .....	5	BCM (BODY CONTROL MODULE) : Diagnosis Procedure .....	26
WITH RAIN SENSOR : System Description .....	5	<b>IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)</b> .....	26
WITH RAIN SENSOR : Component Parts Location .....	8	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) : Diagnosis Procedure .....	26
WITH RAIN SENSOR : Component Description .....	8	<b>FRONT WIPER MOTOR LO CIRCUIT</b> .....	28
<b>WITHOUT RAIN SENSOR</b> .....	9	Component Function Check .....	28
WITHOUT RAIN SENSOR : System Diagram .....	9	Diagnosis Procedure .....	28
WITHOUT RAIN SENSOR : System Description .....	9	<b>FRONT WIPER MOTOR HI CIRCUIT</b> .....	30
WITHOUT RAIN SENSOR : Component Parts Location .....	12	Component Function Check .....	30
WITHOUT RAIN SENSOR : Component Description .....	12	Diagnosis Procedure .....	30
<b>REAR WIPER AND WASHER SYSTEM</b> .....	14	<b>FRONT WIPER AUTO STOP SIGNAL CIRCUIT</b> .....	32
System Diagram .....	14	Component Function Check .....	32
System Description .....	14	Diagnosis Procedure .....	32
Component Parts Location .....	16	<b>FRONT WIPER MOTOR GROUND CIRCUIT</b> ...	34
Component Description .....	16	Diagnosis Procedure .....	34
<b>DIAGNOSIS SYSTEM (BCM)</b> .....	17	<b>WASHER SWITCH</b> .....	35
<b>COMMON ITEM</b> .....	17	Description .....	35
COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM) .....	17	Component Inspection .....	35
<b>WIPER</b> .....	18	<b>RAIN SENSOR</b> .....	36
WIPER : CONSULT-III Function (BCM - WIPER) ...	18	Description .....	36
<b>DIAGNOSIS SYSTEM (IPDM E/R)</b> .....	20	Component Function Check .....	36
Diagnosis Description .....	20	Diagnosis Procedure .....	36
CONSULT-III Function (IPDM E/R) .....	22		

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
WW

<b>REAR WIPER MOTOR CIRCUIT .....</b>	<b>38</b>	<b>FOR MEXICO .....</b>	<b>122</b>
Component Function Check .....	38	FOR MEXICO : Precaution for Supplemental Re-	
Diagnosis Procedure .....	38	straint System (SRS) "AIR BAG" and "SEAT BELT	
<b>REAR WIPER AUTO STOP SIGNAL CIRCUIT .....</b>	<b>40</b>	PRE-TENSIONER" .....	122
Component Function Check .....	40	Precaution for Procedure without Cowl Top Cover. 123	
Diagnosis Procedure .....	40	<b>REMOVAL AND INSTALLATION .....</b>	<b>124</b>
<b>FRONT WIPER AND WASHER SYSTEM .....</b>	<b>42</b>	<b>WASHER TANK .....</b>	<b>124</b>
Wiring Diagram - FRONT WIPER AND WASHER		Exploded View .....	124
SYSTEM - .....	42	Removal and Installation .....	124
<b>REAR WIPER AND WASHER SYSTEM .....</b>	<b>49</b>	<b>WASHER PUMP .....</b>	<b>125</b>
Wiring Diagram - REAR WIPER AND WASHER		Exploded View .....	125
SYSTEM - .....	49	Removal and Installation .....	125
<b>ECU DIAGNOSIS INFORMATION .....</b>	<b>55</b>	<b>WASHER LEVEL SWITCH .....</b>	<b>126</b>
<b>BCM (BODY CONTROL MODULE) .....</b>	<b>55</b>	Removal and Installation .....	126
Reference Value .....	55	<b>FRONT WASHER NOZZLE AND TUBE .....</b>	<b>127</b>
Wiring Diagram - BCM - .....	79	Exploded View .....	127
Fail-safe .....	94	Hydraulic Layout .....	127
DTC Inspection Priority Chart .....	97	Removal and Installation .....	127
DTC Index .....	98	Inspection and Adjustment .....	128
<b>IPDM E/R (INTELLIGENT POWER DISTRI-</b>		<b>FRONT WIPER ARM .....</b>	<b>130</b>
<b>BUTION MODULE ENGINE ROOM) .....</b>	<b>100</b>	Exploded View .....	130
Reference Value .....	100	Removal and Installation .....	130
Wiring Diagram - IPDM E/R - .....	108	Adjustment .....	130
Fail-safe .....	111	<b>WIPER BLADE .....</b>	<b>132</b>
DTC Index .....	113	Exploded View .....	132
<b>SYMPTOM DIAGNOSIS .....</b>	<b>114</b>	Removal and Installation .....	132
<b>WIPER AND WASHER SYSTEM SYMPTOMS .....</b>	<b>114</b>	Replacement .....	132
<b>WITH RAIN SENSOR .....</b>	<b>114</b>	<b>FRONT WIPER DRIVE ASSEMBLY .....</b>	<b>134</b>
WITH RAIN SENSOR : Symptom Table .....	114	Exploded View .....	134
<b>WITHOUT RAIN SENSOR .....</b>	<b>116</b>	Removal and Installation .....	134
WITHOUT RAIN SENSOR : Symptom Table .....	116	Disassembly and Assembly .....	135
<b>NORMAL OPERATING CONDITION .....</b>	<b>119</b>	<b>RAIN SENSOR .....</b>	<b>136</b>
Description .....	119	Exploded View .....	136
<b>FRONT WIPER DOES NOT OPERATE .....</b>	<b>120</b>	Removal and Installation .....	136
Description .....	120	<b>WIPER AND WASHER SWITCH .....</b>	<b>137</b>
Diagnosis Procedure .....	120	Exploded View .....	137
<b>PRECAUTION .....</b>	<b>122</b>	<b>REAR WIPER ARM .....</b>	<b>138</b>
<b>PRECAUTIONS .....</b>	<b>122</b>	Exploded View .....	138
<b>FOR USA AND CANADA .....</b>	<b>122</b>	Removal and Installation .....	138
FOR USA AND CANADA : Precaution for Supple-		Adjustment .....	138
mental Restraint System (SRS) "AIR BAG" and		<b>REAR WIPER MOTOR .....</b>	<b>140</b>
"SEAT BELT PRE-TENSIONER" .....	122	Exploded View .....	140
		Removal and Installation .....	140
		<b>REAR WASHER NOZZLE AND TUBE .....</b>	<b>141</b>
		Hydraulic Layout .....	141
		Removal and Installation .....	141
		Inspection and Adjustment .....	142

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000005515992

#### OVERALL SEQUENCE



#### DETAILED FLOW

##### 1. INTERVIEW FOR MALFUNCTION

Interview the symptom to the customer.

# DIAGNOSIS AND REPAIR WORKFLOW

## < BASIC INSPECTION >

---

>> GO TO 2.

## 2. SYMPTOM CHECK

---

Check the symptom from the customer's information.

>> GO TO 3.

## 3. BASIC INSPECTION

---

Check the operation of each part. Check that any symptom occurs other than the interviewed symptom.

>> GO TO 4.

## 4. SELF-DIAGNOSIS WITH CONSULT-III

---

Perform the self-diagnosis with CONSULT-III. Check that any DTC is detected.

Is any DTC detected?

YES >> GO TO 5.

NO >> GO TO 6.

## 5. TROUBLE DIAGNOSIS BY DTC

---

Perform the trouble diagnosis for the detected DTC. Specify the malfunctioning part.

>> GO TO 9.

## 6. FAIL-SAFE ACTIVATION CHECK

---

Check that the symptom is applied to the fail-safe activation.

Does the fail-safe activate?

YES >> GO TO 7.

NO >> GO TO 8.

## 7. SYSTEM DIAGNOSIS

---

Perform the system diagnosis for the system that the fail-safe activates. Specify the malfunctioning part.

>> GO TO 9.

## 8. SYMPTOM DIAGNOSIS

---

Perform the symptom diagnosis. Specify the malfunctioning part.

>> GO TO 9.

## 9. MALFUNCTION PART REPAIR

---

Repair or replace the malfunctioning part.

>> GO TO 10.

## 10. REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT-III)

---

Perform the self-diagnosis with CONSULT-III. Check that any DTC is not detected. Erase DTC if DTC is detected before the repair. Check that DTC is not detected again.

Is any DTC detected?

YES >> GO TO 5.

NO >> GO TO 11.

## 11. REPAIR CHECK (OPERATION CHECK)

---

Check the operation of each part.

Does it operate normally?

YES >> INSPECTION END

NO >> GO TO 3.

# FRONT WIPER AND WASHER SYSTEM


< SYSTEM DESCRIPTION >

## SYSTEM DESCRIPTION

### FRONT WIPER AND WASHER SYSTEM WITH RAIN SENSOR

#### WITH RAIN SENSOR : System Diagram

INFOID:000000005515993



#### WITH RAIN SENSOR : System Description

INFOID:000000005515994

##### OUTLINE

The front wiper is controlled by each function of BCM and IPDM E/R.

Control by BCM

- Combination switch reading function
- Front wiper control function

Control by IPDM E/R

- Front wiper control function
- Relay control function

Combination meter indicates low washer fluid warning judged with the signal from the washer level switch. For details of low washer fluid warning, refer to [MWI-26, "INFORMATION DISPLAY : System Description"](#).

##### FRONT WIPER BASIC OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits the front wiper request signal to IPDM E/R with CAN communication depending on each operating condition of the front wiper.
- IPDM E/R turns ON/OFF the integrated front wiper relay and the front wiper high relay according to the front wiper request signal. IPDM E/R provides the power supply to operate the front wiper HI/LO operation.

##### FRONT WIPER LO OPERATION

- BCM transmits the front wiper request signal (LO) to IPDM E/R with CAN communication according to the front wiper LO operating condition.

Front wiper LO operating condition

- Ignition switch ON
- Front wiper switch LO or front wiper switch MIST (while pressing)
- IPDM E/R turns ON the integrated front wiper relay according to the front wiper request signal (LO).

##### FRONT WIPER HI OPERATION

- BCM transmits the front wiper request signal (HI) to IPDM E/R with CAN communication according to the front wiper HI operating condition.

Front wiper HI operating condition

- Ignition switch ON
- Front wiper switch HI

# FRONT WIPER AND WASHER SYSTEM

## < SYSTEM DESCRIPTION >

- IPDM E/R turns ON the integrated front wiper relay and the front wiper high relay according to the front wiper request signal (HI).

## FRONT WIPER AUTO OPERATION

### Rain Sensing

Rain level and sensor conditions are detected by rain sensor.

- BCM transmits the vehicle conditions (vehicle speed, front wiper condition, rain sensor sensitivity setting, etc.) to the rain sensor via the rain sensor serial link.
- Rain sensor judges a wiping speed for front wiper by rain condition and the vehicle conditions. And it transmits the wiping speed request signal to the BCM via the rain sensor serial link.

### Auto Wiping Operation

- BCM receives the wiping speed request signal from the rain sensor via the rain sensor serial link.
- BCM controls front wiper operation according to the wiping speed request signals. And it transmits the front wiper request signals (LO or HI) to the IPDM E/R via CAN communication line.

Front wiper AUTO operating condition

- Ignition switch ON
- Front wiper switch INT/AUTO

### NOTE:

When the front wiper switch is turned to INT/AUTO position, front wiper operates once regardless of a rainy condition.

### Rain Sensor Sensitivity Setting

BCM determines rain sensor sensitivity according to a wiper volume.


Wiper volume dial position	Sensitivity
1	High sensitivity
2	
3	Medium-high sensitivity
4	
5	Low-medium sensitivity
6	
7	Low sensitivity

### NOTE:

When the wiper volume is turned up at 1 level with front wiper AUTO operating condition, front wiper operates once.

## FRONT WIPER AUTO STOP OPERATION

- BCM stops transmitting the front wiper request signal when the front wiper switch is turned OFF.
- IPDM E/R detects the front wiper stop position signal from the front wiper motor and detects the front wiper motor position (stop position/except stop position).
- When the front wiper request signal is stopped, IPDM E/R turns ON the front wiper relay until the front wiper motor returns to the stop position.



# FRONT WIPER AND WASHER SYSTEM

## < SYSTEM DESCRIPTION >

### NOTE:

- BCM stops the transmitting of the front wiper request signal when the ignition switch is OFF.
- IPDM E/R turns the front wiper relay OFF when the ignition switch is OFF.

### FRONT WIPER OPERATION LINKED WITH WASHER

- BCM transmits the front wiper request signal (LO) to IPDM E/R with CAN communication according to the washer linked operating condition of the front wiper.
- BCM transmits the front wiper request signal (LO) so that the front wiper operates approximately 2 times when the front washer switch OFF is detected.

Washer linked operating condition of front wiper

- Ignition switch ON
- Front washer switch ON (0.4 second or more)
- IPDM E/R turns ON the integrated front wiper relay according to the front wiper request signal (LO).
- The washer pump is grounded through the combination switch with the front washer switch ON.

### FAIL-SAFE FUNCTION

Front Wiper control

IPDM E/R performs the fail-safe function when the front wiper auto stop circuit is malfunctioning. Refer to [PCS-30, "Fail-safe"](#).

Rain Sensor Malfunction

- BCM judges the rain sensor serial link error by the rain sensor serial link condition and detects the rain sensor malfunction by rain sensor malfunction signal.
- When BCM detects the rain sensor serial link error or the rain sensor malfunction while front wiper AUTO operation, BCM operates a fail-safe control.

### NOTE:

If rain sensor malfunction is detected when ignition switch is turned OFF ⇒ ON and front wiper switch is INT/ AUTO position, BCM operates front wiper LO.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P


WW

# FRONT WIPER AND WASHER SYSTEM

< SYSTEM DESCRIPTION >

## WITH RAIN SENSOR : Component Parts Location

INFOID:000000005515995



- |                            |                               |                                       |
|----------------------------|-------------------------------|---------------------------------------|
| 1. Combination switch      | 2. Combination meter          | 3. Rain sensor                        |
| 4. Washer pump             | 5. Front wiper motor          | 6. IPDM E/R                           |
| 7. BCM                     |                               |                                       |
| A. Wind shield upper       | B. Radiator core support (RH) | C. Cowl top, left side of engine room |
| D. Engine room (left side) | E. Behind combination meter   |                                       |

## WITH RAIN SENSOR : Component Description

INFOID:000000005515996

Part	Description
BCM	<ul style="list-style-type: none"> <li>Judges each switch status by the combination switch reading function.</li> <li>Requests (with CAN communication) the front wiper relay and the front wiper high relay ON to IPDM E/R.</li> </ul>
IPDM E/R	<ul style="list-style-type: none"> <li>Controls the integrated relay according to the request (with CAN communication) from BCM.</li> <li>Performs the auto stop control of the front wiper.</li> </ul>




# FRONT WIPER AND WASHER SYSTEM

## < SYSTEM DESCRIPTION >

Part	Description
Combination switch (Wiper & washer switch)	Refer to <a href="#">BCS-9, "System Diagram"</a> .
Combination meter	Transmits the vehicle speed signal to BCM with CAN communication.
Rain sensor	Detects water droplets on the windshield with infrared rays, and transmits the rain sensor signal to BCM through the rain sensor serial link.

## WITHOUT RAIN SENSOR

## WITHOUT RAIN SENSOR : System Diagram



## WITHOUT RAIN SENSOR : System Description

INFOID:000000005515998

### OUTLINE

The front wiper is controlled by each function of BCM and IPDM E/R.

#### Control by BCM

- Combination switch reading function
- Front wiper control function

#### Control by IPDM E/R

- Front wiper control function
- Relay control function

Combination meter indicates low washer fluid warning judged with the signal from the washer level switch. For details of low washer fluid warning, refer to [MWI-26, "INFORMATION DISPLAY : System Description"](#).

### FRONT WIPER BASIC OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits the front wiper request signal to IPDM E/R with CAN communication depending on each operating condition of the front wiper.
- IPDM E/R turns ON/OFF the integrated front wiper relay and the front wiper high relay according to the front wiper request signal. IPDM E/R provides the power supply to operate the front wiper HI/LO operation.

### FRONT WIPER LO OPERATION

- BCM transmits the front wiper request signal (LO) to IPDM E/R with CAN communication according to the front wiper LO operating condition.

#### Front wiper LO operating condition

- Ignition switch ON
- Front wiper switch LO or front wiper switch MIST (while pressing)
- IPDM E/R turns ON the integrated front wiper relay according to the front wiper request signal (LO).

### FRONT WIPER HI OPERATION

- BCM transmits the front wiper request signal (HI) to IPDM E/R with CAN communication according to the front wiper HI operating condition.

# FRONT WIPER AND WASHER SYSTEM

## < SYSTEM DESCRIPTION >

Front wiper HI operating condition


- Ignition switch ON
- Front wiper switch HI
- IPDM E/R turns ON the integrated front wiper relay and the front wiper high relay according to the front wiper request signal (HI).

## FRONT WIPER INT OPERATION

- BCM transmits the front wiper request signal (INT) to IPDM E/R with CAN communication depending on the front wiper INT operating condition and intermittent operation delay interval according to the wiper intermittent dial position.

Front wiper INT operating condition

- Ignition switch ON
- Front wiper switch INT
- IPDM E/R turns ON the integrated front wiper relay so that the front wiper is operated only once according to the front wiper request signal (INT).
- BCM detects stop position/except stop position of the front wiper motor according to the front wiper stop position signal received from IPDM E/R with CAN communication.
- BCM transmits the front wiper request signal (INT) again after the intermittent operation delay interval.



### NOTE:

Factory setting of the front wiper intermittent operation is the operation without vehicle speed. Front wiper intermittent operation can be set to the operation with vehicle speed by CONSULT-III. Refer to [WW-18, "WIPER : CONSULT-III Function \(BCM - WIPER\)"](#).

Front wiper intermittent operation with vehicle speed

- BCM calculates the intermittent operation delay interval from the following
- Vehicle speed signal (received from the combination meter with CAN communication)
- Wiper intermittent dial position

Wiper intermittent dial position	Intermittent operation interval	Intermittent operation delay Interval (s)			
		Vehicle speed			
		0 – 5 km/h (0 – 3.1 MPH)	5 – 35 km/h (3.1 – 21.7 MPH)	35 – 65 km/h* (21.7 – 40.4 MPH)	65 km/h (40.4 MPH) or more
1	Short ↑	0.8	0.6	0.4	0.24
2		4	3	2	1.2
3		10	7.5	5	3
4		16	12	8	4.8
5	↓ Long	24	18	12	7.2
6		32	24	16	9.6
7		42	31.5	21	12.6

\*: When without vehicle speed setting


## FRONT WIPER AUTO STOP OPERATION

- BCM stops transmitting the front wiper request signal when the front wiper switch is turned OFF.
- IPDM E/R detects the front wiper stop position signal from the front wiper motor and detects the front wiper motor position (stop position/except stop position).

# FRONT WIPER AND WASHER SYSTEM

## < SYSTEM DESCRIPTION >

- When the front wiper request signal is stopped, IPDM E/R turns ON the front wiper relay until the front wiper motor returns to the stop position.



### NOTE:

- BCM stops the transmitting of the front wiper request signal when the ignition switch is OFF.
- IPDM E/R turns the front wiper relay OFF when the ignition switch is OFF.

### FRONT WIPER OPERATION LINKED WITH WASHER

- BCM transmits the front wiper request signal (LO) to IPDM E/R with CAN communication according to the washer linked operating condition of the front wiper.
- BCM transmits the front wiper request signal (LO) so that the front wiper operates approximately 2 times when the front washer switch OFF is detected.

Washer linked operating condition of front wiper

- Ignition switch ON
- Front washer switch ON (0.4 second or more)
- IPDM E/R turns ON the integrated front wiper relay according to the front wiper request signal (LO).
- The washer pump is grounded through the combination switch with the front washer switch ON.

### FRONT WIPER FAIL-SAFE OPERATION

IPDM E/R performs the fail-safe function when the front wiper auto stop circuit is malfunctioning. Refer to [PCS-30. "Fail-safe"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K

WW

M

N

O


P

# FRONT WIPER AND WASHER SYSTEM

< SYSTEM DESCRIPTION >

## WITHOUT RAIN SENSOR : Component Parts Location

INFOID:000000005515999



- |                               |                                       |                            |
|-------------------------------|---------------------------------------|----------------------------|
| 1. Combination switch         | 2. Combination meter                  | 3. Washer pump             |
| 4. Front wiper motor          | 5. IPDM E/R                           | 6. BCM                     |
| A. Radiator core support (RH) | B. Cowl top, left side of engine room | C. Engine room (left side) |
| D. Behind combination meter   |                                       |                            |

## WITHOUT RAIN SENSOR : Component Description

INFOID:000000005516000

Part	Description
BCM	<ul style="list-style-type: none"> <li>Judges each switch status by the combination switch reading function.</li> <li>Requests (with CAN communication) the front wiper relay and the front wiper high relay ON to IPDM E/R.</li> </ul>
IPDM E/R	<ul style="list-style-type: none"> <li>Controls the integrated relay according to the request (with CAN communication) from BCM.</li> <li>Performs the auto stop control of the front wiper.</li> </ul>

## FRONT WIPER AND WASHER SYSTEM

### < SYSTEM DESCRIPTION >

Part	Description
Combination switch (Wiper & washer switch)	Refer to <a href="#">BCS-9, "System Diagram"</a> .
Combination meter	Transmits the vehicle speed signal to BCM with CAN communication.

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P


# REAR WIPER AND WASHER SYSTEM

< SYSTEM DESCRIPTION >

## REAR WIPER AND WASHER SYSTEM

### System Diagram

INFOID:000000005516001



### System Description

INFOID:000000005516002

#### OUTLINE

The rear wiper is controlled by each function of BCM.

Control by BCM

- Combination switch reading function
- Rear wiper control function

#### REAR WIPER BASIC OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM controls the rear wiper to start or stop.

#### REAR WIPER ON OPERATION

- BCM supplies power to the rear wiper motor according to the rear wiper ON operating condition.

Rear wiper ON operating condition


- Ignition switch ON
- Rear wiper switch ON

#### REAR WIPER INT OPERATION

- BCM supplies power to the rear wiper motor according to the INT operating condition.

Rear wiper INT operating condition

- Ignition switch ON
- Rear wiper switch INT
- BCM controls the rear wiper to operate once.
- BCM detects the rear wiper motor stopping position.
- BCM supplies power to the rear wiper motor after an intermittent from the stop of the rear wiper motor.




#### REAR WIPER AUTO STOP OPERATION

- BCM stops supplying power to the rear wiper motor when the rear wiper switch is turned OFF.

## REAR WIPER AND WASHER SYSTEM

### < SYSTEM DESCRIPTION >

- BCM reads a rear wiper stop position signal from the rear wiper motor to detect a rear wiper motor position.
- When the rear wiper motor is at other than the stopping position, BCM continues to supply power to the rear wiper motor until it returns to the stopping position.



#### NOTE:

BCM stops supplying power to the rear wiper motor when the ignition switch is turned OFF.

#### REAR WIPER OPERATION LINKED WITH WASHER

- BCM supplies power to the rear wiper motor according to the washer linked operating condition of rear wiper. When the rear washer switch is turned OFF, BCM controls rear wiper to operate approximately 3 times.

Washer linked operating condition of rear wiper

- Ignition switch ON
- Rear washer switch ON (0.4 second or more)
- The washer pump is grounded through the combination switch with the rear washer switch ON.

#### REAR WIPER FAIL-SAFE OPERATION

BCM performs the fail-safe function when the rear wiper auto stop circuit is malfunctioning. Refer to [BCS-86](#), "[Fail-safe](#)".


WW

# REAR WIPER AND WASHER SYSTEM

< SYSTEM DESCRIPTION >

## Component Parts Location

INFOID:000000005516003



1. Combination switch

2. Washer pump

3. BCM

4. Rear wiper motor

A. Radiator core support (RH)

B. Behind combination meter

C. Back door trim finisher lower inside

## Component Description

INFOID:000000005516004

Part	Description
BCM	<ul style="list-style-type: none"> <li>Judges each switch status by the combination switch reading function.</li> <li>Supplies power to the rear wiper motor.</li> <li>Performs the auto stop control of the rear wiper.</li> </ul>
Combination switch (Wiper & washer switch)	Refer to <a href="#">BCS-9, "System Diagram"</a> .



## DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

### DIAGNOSIS SYSTEM (BCM)

#### COMMON ITEM

#### COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM)

INFOID:000000005683164

#### APPLICATION ITEM

CONSULT-III performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
Work Support	Changes the setting for each system function.
Self Diagnostic Result	Displays the diagnosis results judged by BCM.
CAN Diag Support Monitor	Monitors the reception status of CAN communication viewed from BCM. Refer to CONSULT-III operation manual.
Data Monitor	The BCM input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from BCM.
Ecu Identification	The BCM part number is displayed.
Configuration	<ul style="list-style-type: none"> <li>Read and save the vehicle specification.</li> <li>Write the vehicle specification when replacing BCM.</li> </ul>

#### SYSTEM APPLICATION

BCM can perform the following functions for each system.

#### NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

x: Applicable item

System	Sub system selection item	Diagnosis mode		
		Work Support	Data Monitor	Active Test
Door lock	DOOR LOCK	x	x	x
Rear window defogger	REAR DEFOGGER		x	x
Warning chime	BUZZER		x	x
Interior room lamp timer	INT LAMP	x	x	x
Exterior lamp	HEAD LAMP	x	x	x
Wiper and washer	WIPER	x*1	x	x
Turn signal and hazard warning lamps	FLASHER	x	x	x
—	AIR CONDITONER*2			
<ul style="list-style-type: none"> <li>Intelligent Key system</li> <li>Engine start system</li> </ul>	INTELLIGENT KEY	x	x	x
Combination switch	COMB SW		x	
Body control system	BCM	x		
NVIS - NATS	IMMU		x	x
Interior room lamp battery saver	BATTERY SAVER	x	x	x
Back door opener system	TRUNK		x	x
Vehicle security system	THEFT ALM	x	x	x
RAP system	RETAINED PWR		x	
Signal buffer system	SIGNAL BUFFER		x	x
TPMS	TPMS (AIR PRESSURE MONITOR)	x	x	x

#### NOTE:

- \*1: For models with rain sensor this mode is displayed, but is not used.
- \*2: This item is displayed, but is not used.

#### FREEZE FRAME DATA (FFD)

## DIAGNOSIS SYSTEM (BCM)

### < SYSTEM DESCRIPTION >

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays on CONSULT-III.

CONSULT screen item	Indication/Unit	Description	
Vehicle Speed	km/h	Vehicle speed of the moment a particular DTC is detected	
Odo/Trip Meter	km	Total mileage (Odometer value) of the moment a particular DTC is detected	
Vehicle Condition	SLEEP>LOCK	Power position status of the moment a particular DTC is detected	While turning BCM status from low power consumption mode to normal mode (Power supply position is "LOCK")
	SLEEP>OFF		While turning BCM status from low power consumption mode to normal mode (Power supply position is "OFF".)
	LOCK>ACC		While turning power supply position from "LOCK" to "ACC"
	ACC>ON		While turning power supply position from "ACC" to "IGN"
	RUN>ACC		While turning power supply position from "RUN" to "ACC" (Vehicle is stopping and selector lever is except P position.)
	CRANK>RUN		While turning power supply position from "CRANKING" to "RUN" (From cranking up the engine to run it)
	RUN>URGENT		While turning power supply position from "RUN" to "ACC" (Emergency stop operation)
	ACC>OFF		While turning power supply position from "ACC" to "OFF"
	OFF>LOCK		While turning power supply position from "OFF" to "LOCK"
	OFF>ACC		While turning power supply position from "OFF" to "ACC"
	ON>CRANK		While turning power supply position from "IGN" to "CRANKING"
	OFF>SLEEP		While turning BCM status from normal mode (Power supply position is "OFF".) to low power consumption mode
	LOCK>SLEEP		While turning BCM status from normal mode (Power supply position is "LOCK".) to low power consumption mode
	LOCK		Power supply position is "LOCK" (Ignition switch OFF with steering is locked.)
	OFF		Power supply position is "OFF" (Ignition switch OFF with steering is unlocked.)
	ACC		Power supply position is "ACC" (Ignition switch ACC)
	ON		Power supply position is "IGN" (Ignition switch ON with engine stopped)
	ENGINE RUN		Power supply position is "RUN" (Ignition switch ON with engine running)
	CRANKING		Power supply position is "CRANKING" (At engine cranking)
IGN Counter	0 - 39	The number of times that ignition switch is turned ON after DTC is detected <ul style="list-style-type: none"> <li>• The number is 0 when a malfunction is detected now.</li> <li>• The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON.</li> <li>• The number is fixed to 39 until the self-diagnosis results are erased if it is over 39.</li> </ul>	

## WIPER

### WIPER : CONSULT-III Function (BCM - WIPER)

INFOID:000000005516006

### WORK SUPPORT

Service item	Setting item	Description
WIPER SPEED SETTING	On	With vehicle speed (Front wiper intermittent time linked with the vehicle speed and wiper intermittent dial position)
	Off*	Without vehicle speed (Front wiper intermittent time linked with the wiper intermittent dial position)

\*:Factory setting

# DIAGNOSIS SYSTEM (BCM)

## < SYSTEM DESCRIPTION >

### NOTE:

Work support item is not indicated when the vehicle with rain sensor.

### DATA MONITOR

Monitor Item [Unit]	Description
PUSH SW [Off/On]	The switch status input from push-button ignition switch.
VEHICLE SPEED 1 [km/h]	The value of the vehicle speed signal received from combination meter with CAN communication.
FR WIPER HI [Off/On]	Each switch status that BCM judges from the combination switch reading function.
FR WIPER LOW [Off/On]	
FR WASHER SW [Off/On]	
FR WIPER INT [Off/On]	
FR WIPER STOP [Off/On]	Front wiper motor (stop position) status received from IPDM E/R with CAN communication.
INT VOLUME [1 – 7]	Each switch status that BCM judges from the combination switch reading function.
RR WIPER ON [Off/On]	Each switch status that BCM judges from the combination switch reading function.
RR WIPER INT [Off/On]	
RR WASHER SW [Off/On]	
RR WIPER STOP [Off/On]	Rear wiper motor (stop position) status input from the rear wiper motor.

### ACTIVE TEST

Test item	Operation	Description
FR WIPER	Hi	Transmits the front wiper request signal (HI) to IPDM E/R with CAN communication to operate the front wiper HI operation.
	Lo	Transmits the front wiper request signal (LO) to IPDM E/R with CAN communication to operate the front wiper LO operation.
	INT	Transmits the front wiper request signal (INT) to IPDM E/R with CAN communication to operate the front wiper INT operation.
	Off	Stops transmitting the front wiper request signal to stop the front wiper operation.
RR WIPER	On	Outputs the voltage to operate the rear wiper motor.
	Off	Stops the voltage to stop.

# DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (IPDM E/R)

### Diagnosis Description

INFOID:000000005683165

#### AUTO ACTIVE TEST

##### Description

In auto active test mode, the IPDM E/R sends a drive signal to the following systems to check their operation.

- Oil pressure warning lamp
- Front wiper (LO, HI)
- Parking lamps
- License plate lamps
- Side marker lamps
- Tail lamps
- Front fog lamps
- Headlamps (LO, HI)
- A/C compressor (magnet clutch)
- Cooling fan

##### Operation Procedure

1. Close the hood and lift the wiper arms from the windshield. (Prevent windshield damage due to wiper operation)

##### NOTE:

When auto active test is performed with hood opened, sprinkle water on windshield beforehand.

2. Turn the ignition switch OFF.
3. Turn the ignition switch ON, and within 20 seconds, press the front door switch (driver side) 10 times. Then turn the ignition switch OFF.

##### CAUTION:

**Close passenger door.**

4. Turn the ignition switch ON within 10 seconds. After that the horn sounds once and the auto active test starts.
5. The oil pressure warning lamp starts blinking when the auto active test starts.
6. After a series of the following operations is repeated 3 times, auto active test is completed.

##### NOTE:

When auto active test mode has to be cancelled halfway through test, turn the ignition switch OFF.

##### CAUTION:

- If auto active test mode cannot be actuated, check door switch system. Refer to [DLK-97, "WITH AUTOMATIC BACK DOOR : Component Function Check"](#).
- Do not start the engine.

##### Inspection in Auto Active Test Mode


When auto active test mode is actuated, the following 6 steps are repeated 3 times.

Operation sequence	Inspection location	Operation
1	Oil pressure warning lamp	Blinks continuously during operation of auto active test
2	Front wiper	LO for 5 seconds → HI for 5 seconds
3	<ul style="list-style-type: none"><li>• Parking lamps</li><li>• License plate lamps</li><li>• Side marker lamps</li><li>• Tail lamps</li><li>• Front fog lamps</li></ul>	10 seconds
4	Headlamps	LO ⇔ HI 5 times
5	A/C compressor (magnet clutch)	ON ⇔ OFF 5 times
6	Cooling fan	LO for 5 seconds → MID for 3 seconds → HI for 2 seconds

# DIAGNOSIS SYSTEM (IPDM E/R)

## < SYSTEM DESCRIPTION >

### Concept of auto active test



- IPDM E/R starts the auto active test with the door switch signals transmitted by BCM via CAN communication. Therefore, the CAN communication line between IPDM E/R and BCM is considered normal if the auto active test starts successfully.
- The auto active test facilitates troubleshooting if any systems controlled by IPDM E/R cannot be operated.

### Diagnosis chart in auto active test mode

Symptom	Inspection contents	Possible cause
Any of the following components do not operate <ul style="list-style-type: none"> <li>Parking lamps</li> <li>License plate lamps</li> <li>Side maker lamps</li> <li>Tail lamps</li> <li>Front fog lamps</li> <li>Headlamp (HI, LO)</li> <li>Front wiper (HI, LO)</li> </ul>	Perform auto active test. Does the applicable system operate?	YES BCM signal input circuit
		NO <ul style="list-style-type: none"> <li>Lamp or motor</li> <li>Lamp or motor ground circuit</li> <li>Harness or connector between IPDM E/R and applicable system</li> <li>IPDM E/R</li> </ul>
A/C compressor does not operate	Perform auto active test. Does the magnet clutch operate?	YES <ul style="list-style-type: none"> <li>A/C amp. signal input circuit</li> <li>CAN communication signal between A/C amp. and ECM</li> <li>CAN communication signal between ECM and IPDM E/R</li> </ul>
		NO <ul style="list-style-type: none"> <li>Magnet clutch</li> <li>Harness or connector between IPDM E/R and magnet clutch</li> <li>IPDM E/R</li> </ul>
Oil pressure warning lamp does not operate	Perform auto active test. Does the oil pressure warning lamp blink?	YES <ul style="list-style-type: none"> <li>Harness or connector between IPDM E/R and oil pressure switch</li> <li>Oil pressure switch</li> <li>IPDM E/R</li> </ul>
		NO <ul style="list-style-type: none"> <li>CAN communication signal between IPDM E/R and BCM</li> <li>CAN communication signal between BCM and combination meter</li> <li>Combination meter</li> </ul>

# DIAGNOSIS SYSTEM (IPDM E/R)

## < SYSTEM DESCRIPTION >

Symptom	Inspection contents		Possible cause
Cooling fan does not operate	Perform auto active test. Does the cooling fan operate?	YES	<ul style="list-style-type: none"> <li>ECM signal input circuit</li> <li>CAN communication signal between ECM and IPDM E/R</li> </ul>
		NO	<ul style="list-style-type: none"> <li>Harness or connector between IPDM E/R and cooling fan motor</li> <li>Harness or connector between IPDM E/R and cooling fan relay</li> <li>Cooling fan motor</li> <li>Cooling fan relay</li> <li>IPDM E/R</li> </ul>

## CONSULT-III Function (IPDM E/R)

INFOID:000000005683166

### APPLICATION ITEM

CONSULT-III performs the following functions via CAN communication with IPDM E/R.

Diagnosis mode	Description
Ecu Identification	Allows confirmation of IPDM E/R part number.
Self Diagnostic Result	Displays the diagnosis results judged by IPDM E/R.
Data Monitor	Displays the real-time input/output data from IPDM E/R input/output data.
Active Test	IPDM E/R can provide a drive signal to electronic components to check their operations.
CAN Diag Support Monitor	The results of transmit/receive diagnosis of CAN communication can be read.

### SELF DIAGNOSTIC RESULT

Refer to [WW-113. "DTC Index"](#).

### DATA MONITOR

Monitor item

Monitor Item [Unit]	MAIN SIGNALS	Description
MOTOR FAN REQ [1/2/3/4]	×	Displays the value of the cooling fan speed request signal received from ECM via CAN communication.
AC COMP REQ [Off/On]	×	Displays the status of the A/C compressor request signal received from ECM via CAN communication.
TAIL&CLR REQ [Off/On]	×	Displays the status of the position light request signal received from BCM via CAN communication.
HL LO REQ [Off/On]	×	Displays the status of the low beam request signal received from BCM via CAN communication.
HL HI REQ [Off/On]	×	Displays the status of the high beam request signal received from BCM via CAN communication.
FR FOG REQ [Off/On]	×	Displays the status of the front fog light request signal received from BCM via CAN communication.
FR WIP REQ [Stop/1LOW/Low/Hi]	×	Displays the status of the front wiper request signal received from BCM via CAN communication.
WIP AUTO STOP [STOP P/ACT P]	×	Displays the status of the front wiper auto stop signal judged by IPDM E/R.
WIP PROT [Off/BLOCK]	×	Displays the status of the front wiper fail-safe operation judged by IPDM E/R.
IGN RLY1 -REQ [Off/On]		Displays the status of the ignition switch ON signal received from BCM via CAN communication.

# DIAGNOSIS SYSTEM (IPDM E/R)

## < SYSTEM DESCRIPTION >

Monitor Item [Unit]	MAIN SIG- NALS	Description
IGN RLY [Off/On]	×	Displays the status of the ignition relay judged by IPDM E/R.
PUSH SW [Off/On]		Displays the status of the push-button ignition switch judged by IPDM E/R.
INTER/NP SW [Off/On]		Displays the status of the shift position judged by IPDM E/R.
ST RLY CONT [Off/On]		Displays the status of the starter relay status signal received from BCM via CAN communication.
IHBT RLY -REQ [Off/On]		Displays the status of the starter control relay signal received from BCM via CAN communication.
ST/INHI RLY [Off/ ST ON/INHI ON/UNKWN]		Displays the status of the starter relay and starter control relay judged by IPDM E/R.
DETENT SW [Off/On]		Displays the status of the CVT shift selector (detention switch) judged by IPDM E/R.
S/L RLY -REQ [Off/On]		Displays the status of the steering lock relay signal received from BCM via CAN communication. <b>NOTE:</b> For models without steering lock unit this item is not monitored.
S/L STATE [LOCK/UNLOCK/UNKWN]		Displays the status of the steering lock judged by IPDM E/R. <b>NOTE:</b> For models without steering lock unit this item is not monitored.
DTRL REQ [Off/On]		<b>NOTE:</b> The item is indicated, but not monitored.
OIL P SW [Open/Close]		Displays the status of the oil pressure switch judged by IPDM E/R.
HOOD SW [Off/On]		<b>NOTE:</b> The item is indicated, but not monitored.
HL WASHER REQ [Off/On]		<b>NOTE:</b> The item is indicated, but not monitored.
THFT HRN REQ [Off/On]		Displays the status of the theft warning horn request signal received from BCM via CAN communication.
HORN CHIRP [Off/On]		Displays the status of the horn reminder signal received from BCM via CAN communication.
CRNRNG LMP REQ [Off/On]		<b>NOTE:</b> The item is indicated, but not monitored.

## ACTIVE TEST

### Test item

Test item	Operation	Description
CORNERING LAMP	Off	<b>NOTE:</b> The item is indicated, but cannot be tested.
	LH	
	RH	
HORN	On	Operates horn relay for 20 ms.
FRONT WIPER	Off	OFF
	Lo	Operates the front wiper relay.
	Hi	Operates the front wiper relay and front wiper high relay.
MOTOR FAN	1	OFF
	2	Operates the cooling fan relay-1.
	3	Operates the cooling fan relay-2.
	4	Operates the cooling fan relay-2 and cooling fan relay-3.

## DIAGNOSIS SYSTEM (IPDM E/R)

### < SYSTEM DESCRIPTION >

Test item	Operation	Description
HEAD LAMP WASHER	On	<b>NOTE:</b> The item is indicated, but cannot be tested.
EXTERNAL LAMPS	Off	OFF
	TAIL	Operates the tail lamp relay.
	Lo	Operates the headlamp low relay.
	Hi	Operates the headlamp low relay and ON/OFF the headlamp high relay at 1 second intervals.
	Fog	Operates the front fog lamp relay.



# WIPER AND WASHER FUSE, FUSIBLE LINK

< DTC/CIRCUIT DIAGNOSIS >

## DTC/CIRCUIT DIAGNOSIS

### WIPER AND WASHER FUSE, FUSIBLE LINK

#### Description

INFOID:0000000005516009

Fuse, fusible link list

Unit	Location	No.	Capacity
Front wiper motor	IPDM E/R	60	30 A
Washer pump	IPDM E/R	47	10 A
Rain sensor	Fuse block	6	10 A

#### Diagnosis Procedure

INFOID:0000000005516010

#### 1.CHECK FUSES AND FUSIBLE LINK

Check that the following fuses and fusible link are not fusing.

Unit	Location	No.	Capacity
Front wiper motor	IPDM E/R	60	30 A
Washer pump	IPDM E/R	47	10 A
Rain sensor	Fuse block	6	10 A

Is the fuse or fusible link fusing?

- YES >> Replace the fuse or fusible link with a new one after repairing the applicable circuit.  
NO >> The fuse or fusible link is normal.

WW

## POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

### POWER SUPPLY AND GROUND CIRCUIT

#### BCM (BODY CONTROL MODULE)

#### BCM (BODY CONTROL MODULE) : Diagnosis Procedure

INFOID:000000005516011

##### 1.CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

Signal name	Fuse and fusible link No.
Battery power supply	L
	10

Is the fuse fusing?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit if a fuse or fusible link is blown.

NO >> GO TO 2.

##### 2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connectors.
3. Check voltage between BCM harness connector and ground.

Terminals			Voltage (Approx.)
(+)		(-)	
BCM		Ground	
Connector	Terminal		
M118	1		
M119	11		
			Battery voltage

Is the measurement value normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

##### 3.CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		Existed
M119	13		

Does continuity exist?

YES >> INSPECTION END

NO >> Repair harness or connector.

#### IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

#### IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) : Diagnosis Procedure

INFOID:000000005516012

##### 1.CHECK FUSES AND FUSIBLE LINK

Check that the following IPDM E/R fuses or fusible links are not blown.

# POWER SUPPLY AND GROUND CIRCUIT

## < DTC/CIRCUIT DIAGNOSIS >

Signal name	Fuses and fusible link No.
Battery power supply	E
	50
	51

### Is the fuse fusing?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit if a fuse or fusible link is blown.

NO >> GO TO 2.

## 2.CHECK POWER SUPPLY CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check voltage between IPDM E/R harness connector and the ground.

Terminals			Voltage (Approx.)
(+)		(-)	
IPDM E/R			
Connector	Terminal	Ground	Battery voltage
E9	1		

### Is the measurement value normal?

YES >> GO TO 3.

NO >> Repair the harness or connector.

## 3.CHECK GROUND CIRCUIT

Check continuity between IPDM E/R harness connectors and the ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E10	12		Existed
E11	41		

### Does continuity exist?

YES >> INSPECTION END

NO >> Repair the harness or connector.

# FRONT WIPER MOTOR LO CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## FRONT WIPER MOTOR LO CIRCUIT

### Component Function Check

INFOID:000000005516013

#### 1.CHECK FRONT WIPER LO OPERATION

##### ⊗ IPDM E/R AUTO ACTIVE TEST

1. Start IPDM E/R auto active test. Refer to [PCS-10, "Diagnosis Description"](#).
2. Check that the front wiper operates at the LO operation.

##### Ⓜ CONSULT-III ACTIVE TEST

1. Select "FRONT WIPER" of IPDM E/R active test item.
2. With operating the test item, check front wiper operation.

**Lo : Front wiper (LO) operation**

**Off : Stop the front wiper.**

Is front wiper (LO) operation normally?

YES >> Front wiper motor LO circuit is normal.

NO >> Refer to [WW-28, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005516014

#### 1.CHECK FRONT WIPER MOTOR (LO) OUTPUT VOLTAGE

##### Ⓜ CONSULT-III ACTIVE TEST

1. Turn the ignition switch OFF.
2. Disconnect front wiper motor connector.
3. Turn the ignition switch ON.
4. Select "FRONT WIPER" of IPDM E/R active test item.
5. With operating the test item, check voltage between IPDM E/R harness connector and ground.

Terminals		Test item	Voltage (Approx.)
(+)	(-)		
IPDM E/R		FRONT WIPER	Battery voltage
Connector	Terminal		
E10	4	Lo	Battery voltage
		Off	0 V

Is the measurement value normal?

YES >> GO TO 2.

NO >> Replace IPDM E/R.

#### 2.CHECK FRONT WIPER MOTOR (LO) OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and front wiper motor harness connector.

IPDM E/R		Front wiper motor		Continuity
Connector	Terminal	Connector	Terminal	
E10	4	E12	1	Existed

Does continuity exist?

YES >> GO TO 3.

NO >> Repair the harness or connector.

#### 3.CHECK FRONT WIPER MOTOR (LO) SHORT CIRCUIT

Check continuity between IPDM E/R harness connector and ground.

FRONT WIPER MOTOR LO CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

IPDM E/R		Ground	Continuity
Connector	Terminal		
E10	4		Not existed

Does continuity exist?

- YES >> Repair the harness or connector.
- NO >> Replace front wiper motor.

A

B

C

D

E

F

G

H

I

J

K

M

N

O

P

WW

# FRONT WIPER MOTOR HI CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## FRONT WIPER MOTOR HI CIRCUIT

### Component Function Check

INFOID:000000005516015

#### 1.CHECK FRONT WIPER HI OPERATION

##### ⊗ IPDM E/R AUTO ACTIVE TEST

1. Start IPDM E/R auto active test. Refer to [PCS-10, "Diagnosis Description"](#).
2. Check that the front wiper operates at the HI operation.

##### Ⓜ CONSULT-III ACTIVE TEST

1. Select "FRONT WIPER" of IPDM E/R active test item.
2. With operating the test item, check front wiper operation.

**Hi** : Front wiper (HI) operation

**Off** : Stop the front wiper.

Is front wiper (HI) operation normally?

YES >> Front wiper motor HI circuit is normal.

NO >> Refer to [WW-30, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005516016

#### 1.CHECK FRONT WIPER MOTOR (HI) OUTPUT VOLTAGE

##### Ⓜ CONSULT-III ACTIVE TEST

1. Turn the ignition switch OFF.
2. Disconnect front wiper motor connector.
3. Turn the ignition switch ON.
4. Select "FRONT WIPER" of IPDM E/R active test item.
5. With operating the test item, check voltage between IPDM E/R harness connector and ground.

Terminals		Test item	Voltage (Approx.)
(+)	(-)		
IPDM E/R		FRONT WIPER	Battery voltage
Connector	Terminal		
E10	5	Hi	Battery voltage
		Off	0 V

Is the measurement value normal?

YES >> GO TO 2.

NO >> Replace IPDM E/R.

#### 2.CHECK FRONT WIPER MOTOR (HI) OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and front wiper motor harness connector.

IPDM E/R		Front wiper motor		Continuity
Connector	Terminal	Connector	Terminal	
E10	5	E12	4	Existed

Does continuity exist?

YES >> GO TO 3.

NO >> Repair the harness or connector.

#### 3.CHECK FRONT WIPER MOTOR (HI) SHORT CIRCUIT

Check continuity between IPDM E/R harness connector and ground.

## FRONT WIPER MOTOR HI CIRCUIT

### < DTC/CIRCUIT DIAGNOSIS >

IPDM E/R		Ground	Continuity
Connector	Terminal		
E10	5		Not existed

#### Does continuity exist?

YES >> Repair the harness or connector.

NO >> Replace front wiper motor.

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

# FRONT WIPER AUTO STOP SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## FRONT WIPER AUTO STOP SIGNAL CIRCUIT

### Component Function Check

INFOID:000000005516017

#### 1.CHECK FRONT WIPER (AUTO STOP) SIGNAL CHECK

##### CONSULT-III DATA MONITOR

1. Select "FR WIPER STOP" of BCM data monitor item.
2. Operate the front wiper.
3. Check that "FR WIPER STOP" changes to "STOP P" and "ACT P" linked with the wiper operation.

Monitor item	Condition		Monitor status
FR WIPER STOP	Front wiper motor	Stop position	STOP P
		Except stop position	ACT P

Is the status of item normal?

- YES >> Front wiper auto stop signal circuit is normal.  
NO >> Refer to [WW-32, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005516018

#### 1.CHECK FRONT WIPER MOTOR (AUTO STOP) OUTPUT VOLTAGE

1. Turn the ignition switch OFF.
2. Disconnect front wiper motor connector.
3. Turn the ignition switch ON.
4. Check voltage between IPDM E/R harness connector and ground.

Terminals			Voltage (Approx.)
(+)		(-)	
IPDM E/R		Ground	
Connector	Terminal		
E10	16		
			Battery voltage

Is the measurement value normal?

- YES >> GO TO 3.  
NO >> GO TO 2.

#### 2.CHECK FRONT WIPER MOTOR (AUTO STOP) SHORT CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		Not existed
E10	16		

Does continuity exist?

- YES >> Repair the harness or connector.  
NO >> Replace IPDM E/R.

#### 3.CHECK FRONT WIPER MOTOR (AUTO STOP) CIRCUIT CONTINUITY

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and front wiper motor harness connector.



# FRONT WIPER AUTO STOP SIGNAL CIRCUIT

## < DTC/CIRCUIT DIAGNOSIS >

IPDM E/R		Front wiper motor		Continuity
Connector	Terminal	Connector	Terminal	
E10	16	E12	5	Existed

### Does continuity exist?

- YES >> Replace front wiper motor.
- NO >> Repair the harness or connector.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW

## FRONT WIPER MOTOR GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

### FRONT WIPER MOTOR GROUND CIRCUIT

#### Diagnosis Procedure

INFOID:000000005516019

#### 1. CHECK FRONT WIPER MOTOR (GROUND) OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect front wiper motor connector.
3. Check continuity between front wiper motor harness connector and ground.

Front wiper motor		Ground	Continuity
Connector	Terminal		
E12	2		Existed

#### Does continuity exist?

- YES    >> Front wiper motor ground circuit is normal.  
NO     >> Repair the harness or connector.

# WASHER SWITCH


< DTC/CIRCUIT DIAGNOSIS >

## WASHER SWITCH

### Description

INFOID:000000005516020

- Washer switch is integrated with combination switch.
- Combination switch switches polarity between front washer operating and rear washer operating to supply power to the washer pump on ground.



### Component Inspection

INFOID:000000005516021

#### 1. CHECK WIPER SWITCH

1. Turn the ignition switch OFF.
2. Disconnect combination switch connector.
3. Check continuity between the combination switch terminals.

- A : Terminal 4  
B : Terminal 6  
C : Terminal 3  
D : Terminal 1

	OFF	FR	RR
A			
B			
C			
D			

JPLIA0164GB

Combination switch		Condition	Continuity
Terminal			
1	6	Front washer switch ON	Existed
3	4		
1	4	Rear washer switch ON	
3	6		

#### Does continuity exist?

- YES >> Wiper and washer switch is normal.  
NO >> Replace combination switch (Wiper and washer switch).

# RAIN SENSOR


< DTC/CIRCUIT DIAGNOSIS >

## RAIN SENSOR

### Description

INFOID:000000005516022

Rain sensor judges a wiping speed for front wiper by rain condition and the vehicle conditions. And it transmits the wiping speed request signal to the BCM via the rain sensor serial link.



### Component Function Check

INFOID:000000005516023

#### 1.CHECK FRONT WIPER AUTO OPERATION

1. Clean rain sensor detection area of windshield fully.
2. When the front wiper switch is turned to INT/AUTO position, front wiper operates once regardless of a rainy condition.

Is front wiper (AUTO) operation normally?

- YES >> Rain sensor circuit is normal.  
NO >> Refer to [WW-36, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005516024

#### 1.CHECK RAIN SENSOR FUSE

1. Turn the ignition switch OFF.
2. Check that the rain sensor 10 A fuse (#6) is not fusing.

Is the fuse fusing?

- YES >> Replace the fuse after repairing the applicable circuit.  
NO >> GO TO 2.

#### 2.CHECK RAIN SENSOR POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect rain sensor connector.
3. Turn ignition switch ON.
4. Check voltage between rain sensor harness connector and ground.

Terminal			Voltage (Approx.)
(+) Terminal		(-)	
Rain sensor connector	Terminal		
R23	1	Ground	Battery voltage

Is the measurement value normal?

- YES >> GO TO 3.  
NO >> Repair or replace harness.

#### 3.CHECK RAIN SENSOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between rain sensor harness connector and ground.

# RAIN SENSOR

## < DTC/CIRCUIT DIAGNOSIS >

Rain sensor		Ground	Continuity
Connector	Terminal		
R23	3		Existed


### Does continuity exist?

YES >> GO TO 4.

NO >> Repair or replace harness.

## 4.CHECK RAIN SENSOR SIGNAL

1. Connect rain sensor connector.
2. Turn ignition switch ON.
3. Check signal between BCM harness connector and ground with oscilloscope.

Terminal		Condition	Signal (Reference value)
(+)	(-)		
BCM connector	Terminal		
M123	112	Ground  Ignition switch ON	 <p>JPMIA0156GB Approx. 8.7V</p>

### Is the measurement value normal?

YES >> Replace rain sensor. Refer to [WW-136, "Exploded View"](#).

NO >> GO TO 5.

## 5.CHECK RAIN SENSOR SIGNAL CIRCUIT FOR OPEN

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and rain sensor harness connector.

BCM		Rain sensor		Continuity
Connector	Terminal	Connector	Terminal	
M123	112	R23	2	Existed

### Does continuity exist?

YES >> GO TO 6.

NO >> Repair or replace harness.

## 6.CHECK RAIN SENSOR SIGNAL CIRCUIT FOR SHORT

Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M123	112		Not existed

### Does continuity exist?

YES >> Repair or replace harness.

NO >> Replace BCM. Refer to [BCS-95, "Exploded View"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW

# REAR WIPER MOTOR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## REAR WIPER MOTOR CIRCUIT

### Component Function Check

INFOID:000000005516025

#### 1.CHECK REAR WIPER ON OPERATION

##### CONSULT-III ACTIVE TEST

1. Select "RR WIPER" of BCM active test item.
2. With operating the test item, check rear wiper operation.

**On** : Rear wiper ON operation

**Off** : Stop the rear wiper.

Is rear wiper operation normally?

- YES >> Rear wiper motor circuit is normal.  
NO >> Refer to [WW-38, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005516026

#### 1.CHECK REAR WIPER MOTOR OUTPUT VOLTAGE

##### CONSULT-III ACTIVE TEST

1. Turn the ignition switch OFF.
2. Disconnect rear wiper motor connector.
3. Turn the ignition switch ON.
4. Select "RR WIPER" of BCM active test item.
5. With operating the test item, check voltage between BCM harness connector and ground.

Terminals		Test item	Voltage (Approx.)
(+)	(-)		
BCM		REAR WIPER	
Connector	Terminal		
M120	26	On	Battery voltage
		Off	0 V

Is the measurement value normal?

- YES >> GO TO 3.  
NO >> GO TO 2.

#### 2.CHECK REAR WIPER MOTOR SHORT CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M120	26		Not existed

Does continuity exist?

- YES >> Repair the harness or connector.  
NO >> Replace BCM. Refer to [BCS-95, "Exploded View"](#).

#### 3.CHECK REAR WIPER MOTOR OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and rear wiper motor harness connector.

## REAR WIPER MOTOR CIRCUIT

### < DTC/CIRCUIT DIAGNOSIS >

BCM		Rear wiper motor		Continuity
Connector	Terminal	Connector	Terminal	
M120	26	D193	1	Existed

#### Does continuity exist?

YES >> GO TO 4.

NO >> Repair the harness or connector.

### 4.CHECK REAR WIPER MOTOR GROUND OPEN CIRCUIT

Check continuity between rear wiper motor harness connector and ground.

Rear wiper motor		Ground	Continuity
Connector	Terminal		
D193	3		Existed

#### Does continuity exist?

YES >> Replace rear wiper motor.

NO >> Repair the harness or connector.

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

# REAR WIPER AUTO STOP SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## REAR WIPER AUTO STOP SIGNAL CIRCUIT

### Component Function Check

INFOID:000000005516027

#### 1.CHECK REAR WIPER (AUTO STOP) OPERATION

##### CONSULT-III DATA MONITOR

1. Select "WIPER" of BCM data monitor item.
2. Operate the rear wiper.
3. Check that "RR WIPER STOP" changes to "ON" and "OFF" linked with the wiper operation.

Monitor item	Condition		Monitor status
RR WIPER STOP	Rear wiper motor	Stop position	On
		Except stop position	Off

Is the status of item normal?

YES >> Rear wiper auto stop signal circuit is normal.

NO >> Refer to [WW-40, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005516028

#### 1.CHECK REAR WIPER MOTOR (AUTO STOP) OUTPUT VOLTAGE

1. Turn the ignition switch OFF.
2. Disconnect rear wiper motor connector.
3. Turn the ignition switch ON.
4. Check voltage between BCM harness connector and ground.

Terminals			Voltage (Approx.)
(+)		(-)	
BCM		Ground	
Connector	Terminal		
M121	65		
			Battery voltage

Is the measurement value normal?

YES >> GO TO 3.

NO >> GO TO 2.

#### 2.CHECK REAR WIPER MOTOR (AUTO STOP) SHORT CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M121	65		Not existed

Does continuity exist?

YES >> Repair the harness or connector.

NO >> Replace BCM. Refer to [BCS-95, "Exploded View"](#).

#### 3.CHECK REAR WIPER MOTOR (AUTO STOP) OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and rear wiper motor harness connector.



## REAR WIPER AUTO STOP SIGNAL CIRCUIT

### < DTC/CIRCUIT DIAGNOSIS >

BCM		Rear wiper motor		Continuity
Connector	Terminal	Connector	Terminal	
M121	65	D193	4	Existed

#### Does continuity exist?

YES >> Replace rear wiper motor.

NO >> Repair the harness or connector.

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P


# FRONT WIPER AND WASHER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

## FRONT WIPER AND WASHER SYSTEM


### Wiring Diagram - FRONT WIPER AND WASHER SYSTEM -

INFOID:000000005516029



# FRONT WIPER AND WASHER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
WW  
M  
N  
O  
P

# FRONT WIPER AND WASHER SYSTEM

## < DTC/CIRCUIT DIAGNOSIS >

### FRONT WIPER AND WASHER SYSTEM

Connector No.	E8
Connector Name	WIRE TO WIRE
Connector Type	HS12MBR-CS



1	2	3	4	5
6	7	8	9	10
11	12			

Terminal No.	Color of Wire	Signal Name [Specification]
3	GR	-
4	SB	-
5	O	-
8	G	-
9	W	-
10	Y	-
11	G	-

Connector No.	E10
Connector Name	FROM E/R INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	TH20FW-CS12-M4-1V



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name [Specification]
4	LG	-
5	Y	-
7	GR	-
10	BR	-
11	P	-
12	B	-
13	SB	-
15	W	-
16	L/Y	-
19	Y	-
20	L	-
21	O	-
22	SB	-
23	GR	-
24	G	-

25	GR	-
26	Y	-
27	W	-
28	SB	-
30	BR	-
32	V	-
33	G	-
34	O	-
35	P	-
36	G	-
38	GR	-

Connector No.	E11
Connector Name	FROM E/R INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	TH40FW-NH



42	41	40	39
48	45	44	43

Terminal No.	Color of Wire	Signal Name [Specification]
39	P	-
40	L	-
41	B	-
42	SB	-
43	Y	-
44	W	-
45	O	-
46	BR	-

Connector No.	E12
Connector Name	FRONT WIPER MOTOR
Connector Type	HS10FGY



3	2	1
5	4	

Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	-

2	B/W	-
4	Y	-
5	L/Y	-

Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	TH10MW-CS10-M3



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name [Specification]
2	BR	-
3	Y	-
4	W	-
5	LG	-
6	GR	-
8	G	-
11	P	-
12	L	-
13	Y	-
14	O	-
15	BR	-
20	Y	-
21	BR	-
22	P	-
23	P	-
24	L	-
25	O	-
26	G	-
27	V	-
28	SB	-
29	W	-
30	Y	-
47	P	-
48	L	-
49	SB	-
50	GR	-
51	LG	-
52	V	-
53	GR	-
54	BR	-
55	Y	-
56	W/L	-
60	V	-

61	BR	-
62	O	-
63	L/O	-
64	SHIELD	-
66	W	-
67	BR	-
68	Y	-
69	SB	-
70	GR	-
71	SB	-
72	Y	-
73	L	-
74	W	-
75	BR	-
76	GR	-
77	O	-
78	V	-
79	Y	-
80	R	-
81	W	-
82	LG	-
83	O	-

Connector No.	E322
Connector Name	WASHER PUMP
Connector Type	EO2FGY-RS



1	2
---	---

Terminal No.	Color of Wire	Signal Name [Specification]
1	O	-
2	O	-

JCLWM4208GB

# FRONT WIPER AND WASHER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

## FRONT WIPER AND WASHER SYSTEM

Connector No.	E339
Connector Name	WIRE TO WIRE
Connector Type	NS12FW-CS



5	4	3	2	1
12	11	10	9	8
7	6			

Terminal No.	Color of Wire	Signal Name [Specification]
3	O	-
4	G	-
5	O	-
8	G	-
9	W	-
10	Y	-
11	R	-

Connector No.	E345
Connector Name	BROWN INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	NS08FW-CS



85	84	83
90	89	88
87	86	

Terminal No.	Color of Wire	Signal Name [Specification]
83	Y	-
84	L	-
86	SB	-
87	GR	-
88	W	-
89	L	-
90	G	-

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS06FW-M2



3A	2A	1A
8A	7A	6A
5A	4A	

Terminal No.	Color of Wire	Signal Name [Specification]
1A	Y	-
2A	G	-
3A	Y	-
4A	GR	-
5A	R	-
6A	W	-
7A	LG	-
8A	Y	-

Connector No.	M2
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS10FW-CS



4B	3B	2B	1B
10B	9B	8B	7B
6B	5B		

Terminal No.	Color of Wire	Signal Name [Specification]
1B	W	-
2B	L	-
3B	L	-
4B	G	-
5B	L	-
6B	Y	-
7B	R	-
8B	R	-
9B	GR	-


Connector No.	M4
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FW



9	10	11	12	13	14	15	16
1	2	3	4	5	6	7	8

Terminal No.	Color of Wire	Signal Name [Specification]
4	B	-
5	B	-
6	L	-
7	O	-
8	G	-
14	P	-
16	Y	-

Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Type	TH10FW-CS10-M3



Terminal No.	Color of Wire	Signal Name [Specification]
2	L	-
3	P	-
4	O	-
5	O	-
6	G	-
8	R	-
11	P	-
12	L	-
13	V	-
14	Y	-
15	R	-
20	Y	-
21	BR	-
22	G	-
23	P	-

24	Y	-
25	L	-
26	L	-
27	O	-
28	BR	-
29	L	-
30	R	-
47	P	-
48	L	-
49	W	-
50	GR	-
51	LG	-
52	Y	-
53	V	-
54	SB	-
55	P	-
56	SB	-
60	V	-
61	GR	-
62	O	-
63	V	-
64	SHIELD	-
66	W	-
67	R	-
68	W	-
69	P	-
70	G	-
71	G	-
72	BR	-
73	L	-
74	W	-
75	BR	-
76	R	-
77	G	-
78	Y	-
79	G	-
80	R	-
81	W	-
82	W	-
83	O	-

JCLWM4209GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
WW  
M  
N  
O  
P

## < DTC/CIRCUIT DIAGNOSIS >

Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	BAT
2	0	IGN
3	B	GROUND
4	B	GROUND
5	SB	ILLUMINATION CONTROL
8	SB	TRIP RESET SWITCH
9	SB	IGN. SWITCH

Terminal No.	Color of Wire	Signal Name (Specification)
1	G	RR
2	Y	OUTPUT 4
3	O	FR
4	W	IGN
5	V	OUTPUT 3
6	B	GND
7	GR	INPUT 3
8	L	OUTPUT 5
9	SB	INPUT 2
10	P	INPUT 4
11	O	INPUT 1

Terminal No.	Color of Wire	Signal Name [Specification]
4	P	INTERIOR ROOM LAMP POWER SUPPLY
5	G	PASSENGER DOOR UNLOCK OUTPUT
7	W	STEP LAMP OUTPUT
8	V	ALL DOOR FUEL LID LOCK OUTPUT
9	G	DRIVER DOOR FUEL ID UNLOCK OUTPUT
10	P	REAR DOOR UNLOCK OUTPUT
11	LG	BAT. (FUSE)
13	B	GND
14	O	PUSH-BUTTON (IGNITION SW) ILL. GND
15	L	ACC. IND.
17	G	TURN SIGNAL RH
18	BR	TURN SIGNAL LH

Terminal No.	Color of Wire	Signal Name [Specification]
72	B	ROOM ANT2-
73	W	ROOM ANT2+
74	Y	PASSENGER DOOR ANT+
75	LG	PASSENGER DOOR ANT-
76	V	DRIVER DOOR ANT+
77	P	DRIVER DOOR ANT-
80	SB	IMMOBI ANTENNA CONTROL
81	O	IMMOBI ANTENNA SIGNAL
82	BR	IGN RELAY (F/B) CONT
83	P	KEY/LESS ENTRY RECEIVER SIGNAL
87	R	COMBI SW INPUT 5
88	GR	COMBI SW INPUT 3
89	BR	PUSH SW
90	P	CAN L
91	R	CAN-H
92	L	KEY SLOT ILL
93	P	ON IND
95	L	ACC RELAY CONT
96	Y	CVT SHIFT SELECTOR POWER SUPPLY
97	O	S/L CONDITION 1
98	L	S/L CONDITION 2
99	V	SHIFT P
100	P	PASSENGER DOOR REQUEST SW
101	W	DRIVER DOOR REQUEST SW
102	Y	BLOWER FAN MOTOR RELAY CONT
103	L	KEY/LESS ENTRY RECEIVER POWER SUPPLY
106	Y	S/L POWER SUPPLY
107	O	COMBI SW INPUT 1
108	P	COMBI SW INPUT 4
109	SB	COMBI SW INPUT 2
110	G	HAZARD SW

# FRONT WIPER AND WASHER SYSTEM

## < DTC/CIRCUIT DIAGNOSIS >

### FRONT WIPER AND WASHER SYSTEM

Connector No.	M123
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FG-NH



123	124	125	126	127	128	129	130	131	132	133	134	135	136	137	138	139	140	141	142	143	144	145	146	147	148	149	150	151
-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----

Terminal No.	Color of Wire	Signal Name [Specification]
112	R	RAIN SENSOR SERIAL LINK
113	O	OPTICAL SENSOR
116	GR	FUSE CHECK
118	L	STOP LAMP SW
119	W	DR DOOR UNLOCK SENSOR
121	Y	KEY SLOT SW
123	G	IGN P/B
124	R	PASSENGER DOOR SW
130	BR	REAR DEFOGGER SW
132	G	POWER WINDOW SW COMM
133	W	PUSH-BUTTON IGNITION SW ILL POWER
134	R	LOCK IND
137	P	RECEIVER/SENSOR GND
138	V	RECEIVER/SENSOR POWER SUPPLY
139	O	TIRE PRESS RECEIVER SIGNAL
140	GR	SHIFT N/P
141	O	SECURITY INDICATOR OUTPUT
142	L	COMBI SW OUTPUT 5
143	W	COMBI SW OUTPUT 1
144	P	COMBI SW OUTPUT 2
145	V	COMBI SW OUTPUT 3
146	Y	COMBI SW OUTPUT 4
149	W	TIRE PRESS WARNING CHECK SW
150	SB	DRIVER DOOR SW
151	G	REAR WINDOW DEFOGGER RELAY

Connector No.	M129
Connector Name	AV CONTROL UNIT (WITH BOSE SYSTEM WITHOUT NAVIGATION SYSTEM)
Connector Type	TH42FW-NH



47	46	45	44	43	42	41	40	39	38	37	36
59	58	57	56	55	54	53	52	51	50	49	48

Terminal No.	Color of Wire	Signal Name [Specification]
36	L	COMPOSITE IMAGE SIGNAL
37	P	COMPOSITE IMAGE GND
38	Y	RGB (BLUE) SIGNAL
39	L	RGB (GREEN) SIGNAL
40	G	RGB (RED) SIGNAL
41	B	RGB SYNC
42	SHIELD	SHIELD
43	W	RGB AREA (YS) SIGNAL
44	G	COMM (DISP->CONT)
45	G	HP
46	LG	SIGNAL GND
47	O	SIGNAL VCC
49	SHIELD	SHIELD
50	SHIELD	SHIELD
55	SHIELD	SHIELD
56	R	COMM (CONT->DISP)
57	R	VP
58	BR	INVERTER GND
59	Y	INVERTER VCC

Connector No.	M131
Connector Name	AV CONTROL UNIT (WITH BOSE SYSTEM WITHOUT NAVIGATION SYSTEM)
Connector Type	TH42FW-NH



91	90	89	88	87	86	85	84	83	82	81	80	79	78	77	76
107	106	105	104	103	102	101	100	99	98	97	96	95	94	93	92

# FRONT WIPER AND WASHER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

## FRONT WIPER AND WASHER SYSTEM

Connector No.	R1
Connector Name	WIRE TO WIRE
Connector Type	TH16FW-NH



8	7	6	5	4	3	2	1
16	15	14	13	12	11	10	9

Terminal No.	Color of Wire	Signal Name [Specification]
1	R/W	-
2	SHIELD	-[With telephone and navigation system]
2	R/L	-[With telephone without navigation system]
3	B	-
4	SHIELD	-
6	R/L	-
7	Y/R	-
8	B/Y	-
9	B	-
10	Y	-
11	P/W	-
12	B	-
13	R/Y	-
15	B/R	-
16	R	-

Connector No.	R23
Connector Name	RAIN SENSOR
Connector Type	AAE03FB



1	2	3
---	---	---

Terminal No.	Color of Wire	Signal Name [Specification]
1	Y/R	-
2	R	-
3	B	-

JCLWM4212GB




# REAR WIPER AND WASHER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

## REAR WIPER AND WASHER SYSTEM

### Wiring Diagram - REAR WIPER AND WASHER SYSTEM -

INFOID:000000005516030



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


WW

# REAR WIPER AND WASHER SYSTEM

## < DTC/CIRCUIT DIAGNOSIS >

### REAR WIPER AND WASHER SYSTEM

Connector No.	B11
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS19



Terminal No.	Color of Wire	Signal Name [Specification]
1	SHIELD	-
2	B	-
3	R/L	-
4	R/W	-
5	SB	-
6	P	-
7	V	-
8	SHIELD	-
9	BR/L	-
10	Y/G	-
11	Y/L	-
12	W/L	-
13	L	-
14	BR	-
15	SB	-
16	BR	-
17	V	-
18	SB	-
19	R	-
20	P	-
21	LG	-
22	W	-
23	Y	-
24	GR	-
25	Y	-
27	V	-
28	W/L	-
30	P	-
31	O	-
32	BR	-
34	SB	-
35	SHIELD	-
36	L/O	-
37	LG	-
40	Y	-
41	O	-
42	SB	-
43	G	-

44	BR	-
45	L	-
46	GR	-
47	V	-
48	GR	- [With rear view camera and telephone]
49	Y	- [With rear view camera without telephone]
50	SHIELD	-
51	B	-
52	B	-
53	Y	-
54	LG	-
55	BR	-
56	P	-
57	L	-
58	R	-
59	SHIELD	-
60	B	-
61	R/L	-
62	P/W	-
63	LG	-
64	Y	-
66	GR	-
67	G	-
68	R	-
69	SHIELD	-
70	W/R	-
71	B/R	-
72	Y	-
73	LG	-
74	SB	-
75	L	-
76	G	-
77	R	-
78	SHIELD	-
79	B	-
80	W	-
81	R	-
82	L	-
83	BR	-
84	O	-
85	G	-
86	SB	-
87	R	-
88	G	-
89	GR	-
90	Y	-
91	G	-
92	BR	-
93	G	-
94	V	-
95	BR	-

96	GR	-
97	R	-
98	LG	-
99	O	-

Connector No.	B7/8
Connector Name	WIRE TO WIRE
Connector Type	NS16MW-CS



1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

1	2	3	4	5	6	7
8	9	10	11	12	13	14

# REAR WIPER AND WASHER SYSTEM

## < DTC/CIRCUIT DIAGNOSIS >

### REAR WIPER AND WASHER SYSTEM

Connector No.	E8
Connector Name	WIRE TO WIRE
Connector Type	NS12MBR-CS



1	2	3	4	5
6	7	8	9	10
11	12			

Terminal No.	Color of Wire	Signal Name [Specification]
3	GR	-
4	SB	-
5	O	-
8	G	-
9	W	-
10	Y	-
11	G	-

Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	TH70MW-CS10-M3



Terminal No.	Color of Wire	Signal Name [Specification]
2	BR	-
3	Y	-
4	W	-
5	LG	-
6	GR	-
8	G	-
11	P	-
12	L	-
13	Y	-
14	O	-
15	BR	-
20	Y	-
21	BR	-
22	P	-
23	P	-

24	L	-
25	O	-
26	G	-
27	Y	-
28	SB	-
29	W	-
30	Y	-
47	P	-
48	L	-
49	SB	-
50	GR	-
51	LG	-
52	V	-
53	GR	-
54	BR	-
55	Y	-
56	W/L	-
60	V	-
61	BR	-
62	O	-
63	L/O	-
64	SHIELD	-
66	W	-
67	BR	-
68	Y	-
69	SB	-
70	GR	-
71	SB	-
72	Y	-
73	L	-
74	W	-
75	BR	-
76	GR	-
77	O	-
78	V	-
79	Y	-
80	R	-
81	W	-
82	LG	-
83	O	-

Connector No.	E322
Connector Name	WASHER PUMP
Connector Type	E20FGY-RS



1	2
---	---

Terminal No.	Color of Wire	Signal Name [Specification]
1	O	-
2	O	-

Connector No.	E339
Connector Name	WIRE TO WIRE
Connector Type	NS12FBR-CS



5	4	3	2	1
12	11	10	9	8
7	6			

Terminal No.	Color of Wire	Signal Name [Specification]
3	O	-
4	G	-
5	O	-
8	G	-
9	W	-
10	Y	-
11	R	-

Connector No.	E345
Connector Name	ENGINE & INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	NS30FW-CS



85	84	83
90	89	88
87	86	

Terminal No.	Color of Wire	Signal Name [Specification]
83	Y	-
84	L	-
86	SB	-
87	GR	-
88	W	-
89	L	-
90	G	-

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS30FW-M2



3A	2A	1A
8A	7A	6A
5A	4A	

Terminal No.	Color of Wire	Signal Name [Specification]
1A	Y	-
2A	G	-
3A	Y	-
4A	GR	-
5A	R	-
6A	W	-
7A	LG	-
8A	Y	-

JCLWM4214GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

WW

# REAR WIPER AND WASHER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

## REAR WIPER AND WASHER SYSTEM


Connector No.	M4
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FW



9	10	11	12	13	14	15	16
1	2	3	4	5	6	7	8

Terminal No.	Color of Wire	Signal Name [Specification]
4	B	-
5	B	-
6	L	-
7	O	-
8	G	-
14	P	-
16	Y	-

Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Type	TH70FW-CS10-M3



Terminal No.	Color of Wire	Signal Name [Specification]
2	L	-
3	P	-
4	O	-
5	O	-
6	G	-
8	R	-
11	P	-
12	L	-
13	V	-
14	Y	-
15	R	-
20	Y	-
21	BR	-
22	G	-
23	P	-

24	Y	-
25	L	-
26	L	-
27	O	-
28	BR	-
29	L	-
30	R	-
47	P	-
48	L	-
49	W	-
50	GR	-
51	LG	-
52	Y	-
53	V	-
54	SB	-
55	P	-
56	SB	-
60	V	-
61	GR	-
62	O	-
63	V	-
64	SHIELD	-
66	W	-
67	R	-
68	W	-
69	P	-
70	G	-
71	G	-
72	BR	-
73	L	-
74	W	-
75	BR	-
76	R	-
77	G	-
78	Y	-
79	G	-
80	R	-
81	W	-
82	W	-
83	O	-


JCLWM4215GB

# REAR WIPER AND WASHER SYSTEM

## < DTC/CIRCUIT DIAGNOSIS >

### REAR WIPER AND WASHER SYSTEM

Connector No.	MT7
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS19




Terminal No.	Color of Wire	Signal Name [Specification]
1	SHIELD	-
2	B	-
3	W	-
4	R	-
5	Y	-
6	W	-
7	G	-
8	SHIELD	-
9	W	-
10	R	-
11	G	-
12	B	-
13	O	-
14	R	-
15	SB	-
16	R	-
17	V	-
18	P	-
19	P	-
20	LG	-
21	Y	-
22	O	-
23	LG	-
24	SB	-
25	Y	-
27	R	-
28	R	-
30	Y	-
31	W	-
32	BR	-
34	Y	-
35	SHIELD	-
36	G	-
37	Y	-
40	O	-
41	O	-
42	SB	-
43	L	-

44	V	-
45	P	-
46	R	-
47	Y	-
48	L	-
49	G	-
50	SHIELD	-
51	W	-
52	B	-
53	BR	-
54	B	-
55	G	-
56	P	-
57	L	-
58	SB	-
59	SHIELD	-
60	B	-
61	R	-
62	W	-
63	O	-
64	Y	-
66	L	-
67	R	-
68	G	-
69	SHIELD	-
70	L	-
71	R	-
72	LG	-
73	Y	-
74	R	-
75	P	-
76	L	-
77	BR	-
78	SHIELD	-
79	B	-
80	W	-
81	LG	-
82	L	-
83	W	-
84	GR	-
85	V	-
86	W	-
87	R	-
88	G	-
89	B	-
90	G	-
91	G	-
92	BR	-
93	P	-
94	V	-

95	O	-
96	SB	-
97	L	-
98	LG	-
99	Y	-

Connector No.	MI03
Connector Name	COMBINATION SWITCH
Connector Type	TH18FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	RR
2	Y	OUTPUT 4
3	O	FR
4	W	IGN
5	V	OUTPUT 3
6	B	GND
7	GR	INPUT 3
8	L	OUTPUT 5
9	SB	INPUT 2
10	P	INPUT 4
11	O	INPUT 1
12	W	OUTPUT 1
13	R	INPUT 5
14	P	OUTPUT 2

Connector No.	MI18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	MO3FB-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	BAT (F/L)

2	GR	POWER WINDOW POWER SUPPLY (BAT)
3	L	POWER WINDOW POWER SUPPLY (R4P)

Connector No.	MI19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS18FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
4	P	INTERIOR ROOM LAMP POWER SUPPLY
5	G	PASSENGER DOOR UNLOCK OUTPUT
7	W	STEP LAMP OUTPUT
8	V	ALL DOOR FUEL LID LOCK OUTPUT
9	G	DRIVER DOOR FUEL LID UNLOCK OUTPUT
10	P	REAR DOOR UNLOCK OUTPUT
11	LG	BAT (FUSE)
13	B	GND
14	O	PUSH-BUTTON IGNITION SW ILL GND
15	L	ACC IND
17	G	TURN SIGNAL RH
18	BR	TURN SIGNAL LH
19	Y	ROOM LAMP TIMER CONTROL

Connector No.	MI20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS12FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
23	BR	BACK DOOR OPEN OUTPUT
26	G	REAR WIPER OUTPUT

JCLWM4216GB

# REAR WIPER AND WASHER SYSTEM

## < DTC/CIRCUIT DIAGNOSIS >

### REAR WIPER AND WASHER SYSTEM

Connector No.	M121
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FG-NH



51	50	49	48	47	46	45	44	43	42	41	40	39	38	37	36	35	34	33	32
71	70	69	68	67	66	65	64	63	62	61	60	59	58	57	56	55	54	53	52

## BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

### ECU DIAGNOSIS INFORMATION

#### BCM (BODY CONTROL MODULE)

##### Reference Value

INFOID:0000000005683167

##### VALUES ON THE DIAGNOSIS TOOL

###### CONSULT-III MONITOR ITEM

Monitor Item	Condition	Value/Status
FR WIPER HI	Other than front wiper switch HI	Off
	Front wiper switch HI	On
FR WIPER LOW	Other than front wiper switch LO	Off
	Front wiper switch LO	On
FR WASHER SW	Front washer switch OFF	Off
	Front washer switch ON	On
FR WIPER INT	Other than front wiper switch INT/AUTO	Off
	Front wiper switch INT/AUTO	On
FR WIPER STOP	Front wiper is not in STOP position	Off
	Front wiper is in STOP position	On
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	Wiper intermittent dial position
RR WIPER ON	Other than rear wiper switch ON	Off
	Rear wiper switch ON	On
RR WIPER INT	Other than rear wiper switch INT	Off
	Rear wiper switch INT	On
RR WASHER SW	Rear washer switch OFF	Off
	Rear washer switch ON	On
RR WIPER STOP	Rear wiper is in STOP position	Off
	Rear wiper is not in STOP position	On
TURN SIGNAL R	Other than turn signal switch RH	Off
	Turn signal switch RH	On
TURN SIGNAL L	Other than turn signal switch LH	Off
	Turn signal switch LH	On
TAIL LAMP SW	Other than lighting switch 1ST and 2ND	Off
	Lighting switch 1ST or 2ND	On
HI BEAM SW	Other than lighting switch HI	Off
	Lighting switch HI	On
HEAD LAMP SW 1	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
HEAD LAMP SW 2	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
PASSING SW	Other than lighting switch PASS	Off
	Lighting switch PASS	On
AUTO LIGHT SW	Other than lighting switch AUTO	Off
	Lighting switch AUTO	On
FR FOG SW	Front fog lamp switch OFF	Off
	Front fog lamp switch ON	On

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
RR FOG SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off
DOOR SW-DR	Driver door closed	Off
	Driver door opened	On
DOOR SW-AS	Passenger door closed	Off
	Passenger door opened	On
DOOR SW-RR	Rear RH door closed	Off
	Rear RH door opened	On
DOOR SW-RL	Rear LH door closed	Off
	Rear LH door opened	On
DOOR SW-BK	Back door closed	Off
	Back door opened	On
CDL LOCK SW	Other than power door lock switch LOCK	Off
	Power door lock switch LOCK	On
CDL UNLOCK SW	Other than power door lock switch UNLOCK	Off
	Power door lock switch UNLOCK	On
KEY CYL LK-SW	Other than driver door key cylinder LOCK position	Off
	Driver door key cylinder LOCK position	On
KEY CYL UN-SW	Other than driver door key cylinder UNLOCK position	Off
	Driver door key cylinder UNLOCK position	On
KEY CYL SW-TR	<b>NOTE:</b> The item is indicated, but not monitored.	Off
HAZARD SW	Hazard switch is OFF	Off
	Hazard switch is ON	On
REAR DEF SW <b>NOTE:</b> For models with BOSE audio system this item is not monitored.	Rear window defogger switch OFF	Off
	Rear window defogger switch ON	On
TR CANCEL SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off
TR/BD OPEN SW	Back door opener switch OFF	Off
	While the back door opener switch is turned ON	On
TRNK/HAT MNTR	<b>NOTE:</b> The item is indicated, but not monitored.	Off
RKE-LOCK	LOCK button of Intelligent Key is not pressed	Off
	LOCK button of Intelligent Key is pressed	On
RKE-UNLOCK	UNLOCK button of Intelligent Key is not pressed	Off
	UNLOCK button of Intelligent Key is pressed	On
RKE-TR/BD	BACK DOOR OPEN button of Intelligent Key is not pressed	Off
	BACK DOOR OPEN button of Intelligent Key is pressed	On
RKE-PANIC	PANIC button of Intelligent Key is not pressed	Off
	PANIC button of Intelligent Key is pressed	On
RKE-P/W OPEN	UNLOCK button of Intelligent Key is not pressed	Off
	UNLOCK button of Intelligent Key is pressed and held	On



# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
RKE-MODE CHG	LOCK/UNLOCK button of Intelligent Key is not pressed and held simultaneously	Off
	LOCK/UNLOCK button of Intelligent Key is pressed and held simultaneously	On
OPTICAL SENSOR	Bright outside of the vehicle	Close to 5 V
	Dark outside of the vehicle	Close to 0 V
REQ SW -DR	Driver door request switch is not pressed	Off
	Driver door request switch is pressed	On
REQ SW -AS	Passenger door request switch is not pressed	Off
	Passenger door request switch is pressed	On
REQ SW -RR	<b>NOTE:</b> The item is indicated, but not monitored.	Off
REQ SW -RR	<b>NOTE:</b> The item is indicated, but not monitored.	Off
REQ SW -BD/TR	Back door request switch is not pressed	Off
	Back door request switch is pressed	On
PUSH SW	Push-button ignition switch (push switch) is not pressed	Off
	Push-button ignition switch (push switch) is pressed	On
IGN RLY2 -F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
ACC RLY -F/B	<b>NOTE:</b> The item is indicated, but not monitored.	Off
CLUCH SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off
BRAKE SW 1	The brake pedal is depressed when No. 7 fuse is blown	Off
	The brake pedal is not depressed when No. 7 fuse is blown, or No. 7 fuse is normal	On
BRAKE SW 2	The brake pedal is not depressed	Off
	Stop lamp switch 1 signal circuit is normal	On
DETE/CANCL SW	Selector lever in P position	Off
	Selector lever in any position other than P	On
SFT PN/N SW	Selector lever in any position other than P and N	Off
	Selector lever in P or N position	On
S/L -LOCK <b>NOTE:</b> For models without steering lock unit this item is not displayed.	Steering is unlocked	Off
	Steering is locked	On
S/L -UNLOCK <b>NOTE:</b> For models without steering lock unit this item is not displayed.	Steering is locked	Off
	Steering is unlocked	On
S/L RELAY-F/B <b>NOTE:</b> For models without steering lock unit this item is not displayed.	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
UNLK SEN -DR	Driver door is unlocked	Off
	Driver door is locked	On
PUSH SW -IPDM	Push-button ignition switch (push-switch) is not pressed	Off
	Push-button ignition switch (push-switch) is pressed	On

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
IGN RLY1 -F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
DETE SW -IPDM	Selector lever in any position other than P	Off
	Selector lever in P position	On
SFT PN -IPDM	Selector lever in any position other than P and N	Off
	Selector lever in P or N position	On
SFT P -MET	Selector lever in any position other than P	Off
	Selector lever in P position	On
SFT N -MET	Selector lever in any position other than N	Off
	Selector lever in N position	On
ENGINE STATE	Engine stopped	Stop
	While the engine stalls	Stall
	At engine cranking	Crank
	Engine running	Run
S/L LOCK-IPDM <b>NOTE:</b> For models without steering lock unit this item is not displayed.	Steering is unlocked	Off
	Steering is locked	On
S/L UNLK-IPDM <b>NOTE:</b> For models without steering lock unit this item is not displayed.	Steering is locked	Off
	Steering is unlocked	On
S/L RELAY-REQ <b>NOTE:</b> For models without steering lock unit this item is not displayed.	Steering lock system is not the LOCK condition and the changing condition from LOCK to UNLOCK.	Off
	Steering lock system is the LOCK condition or the changing condition from LOCK to UNLOCK.	On
VEH SPEED 1	While driving	Equivalent to speedometer reading
VEH SPEED 2	While driving	Equivalent to speedometer reading
DOOR STAT-DR	Driver door is locked	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Driver door is unlocked	UNLOCK
DOOR STAT-AS	Passenger door is locked	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Passenger door is unlocked	UNLOCK
ID OK FLAG	Power supply position in LOCK position	Reset
	Power supply position in any position other than LOCK	Set
PRMT ENG STRT	The engine start is prohibited	Reset
	The engine start is permitted	Set
PRMT RKE STRT	<b>NOTE:</b> The item is indicated, but not monitored.	Reset
KEY SW -SLOT	Intelligent Key is not inserted into key slot	Off
	Intelligent Key is inserted into key slot	On
RKE OPE COUN1	During the operation of Intelligent Key	Operation frequency of Intelligent Key
RKE OPE COUN2	<b>NOTE:</b> The item is indicated, but not monitored.	—

# BCM (BODY CONTROL MODULE)


## < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status	
CONFIRM ID ALL	The Intelligent Key ID that the key slot receives is not recognized by any Intelligent Key ID registered to BCM.	Yet	A
	The Intelligent Key ID that the key slot receives is recognized by any Intelligent Key ID registered to BCM.	Done	B
CONFIRM ID4	The Intelligent Key ID that the key slot receives is not recognized by the fourth Intelligent Key ID registered to BCM.	Yet	C
	The Intelligent Key ID that the key slot receives is recognized by the fourth Intelligent Key ID registered to BCM.	Done	
CONFIRM ID3	The Intelligent Key ID that the key slot receives is not recognized by the third Intelligent Key ID registered to BCM.	Yet	D
	The Intelligent Key ID that the key slot receives is recognized by the third Intelligent Key ID registered to BCM.	Done	
CONFIRM ID2	The Intelligent Key ID that the key slot receives is not recognized by the second Intelligent Key ID registered to BCM.	Yet	E
	The Intelligent Key ID that the key slot receives is recognized by the second Intelligent Key ID registered to BCM.	Done	F
CONFIRM ID1	The Intelligent Key ID that the key slot receives is not recognized by the first Intelligent Key ID registered to BCM.	Yet	G
	The Intelligent Key ID that the key slot receives is recognized by the first Intelligent Key ID registered to BCM.	Done	
TP 4	The ID of fourth Intelligent Key is not registered to BCM	Yet	H
	The ID of fourth Intelligent Key is registered to BCM	Done	
TP 3	The ID of third Intelligent Key is not registered to BCM	Yet	I
	The ID of third Intelligent Key is registered to BCM	Done	
TP 2	The ID of second Intelligent Key is not registered to BCM	Yet	J
	The ID of second Intelligent Key is registered to BCM	Done	
TP 1	The ID of first Intelligent Key is not registered to BCM	Yet	K
	The ID of first Intelligent Key is registered to BCM	Done	
AIR PRESS FL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front LH tire	
AIR PRESS FR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front RH tire	WW
AIR PRESS RR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear RH tire	
AIR PRESS RL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear LH tire	M
ID REGST FL1	ID of front LH tire transmitter is registered	Done	
	ID of front LH tire transmitter is not registered	Yet	N
ID REGST FR1	ID of front RH tire transmitter is registered	Done	
	ID of front RH tire transmitter is not registered	Yet	
ID REGST RR1	ID of rear RH tire transmitter is registered	Done	O
	ID of rear RH tire transmitter is not registered	Yet	
ID REGST RL1	ID of rear LH tire transmitter is registered	Done	P
	ID of rear LH tire transmitter is not registered	Yet	
WARNING LAMP	Tire pressure indicator OFF	Off	
	Tire pressure indicator ON	On	
BUZZER	Tire pressure warning alarm is not sounding	Off	
	Tire pressure warning alarm is sounding	On	

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


## TERMINAL LAYOUT



## PHYSICAL VALUES

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
1 (W)	Ground	Battery power supply	Input	Ignition switch OFF		Battery voltage
2 (GR)	Ground	P/W power supply (BAT)	Output	Ignition switch OFF		Battery voltage
3 (L)	Ground	P/W power supply (RAP)	Output	Ignition switch ON		Battery voltage
4 (P)	Ground	Interior room lamp power supply	Output	Interior room lamp battery saver is activated. (Cuts the interior room lamp power supply)		0 V
				Interior room lamp battery saver is not activated. (Outputs the interior room lamp power supply)		Battery voltage
5 (G)	Ground	Passenger door UN- LOCK	Output	Passenger door	UNLOCK (Actuator is activated)	Battery voltage
					Other than UNLOCK (Actuator is not activated)	0 V
7 (W)	Ground	Step lamp	Output	Step lamp	ON	0 V
					OFF	Battery voltage
8 (V)	Ground	All doors LOCK	Output	All doors	LOCK (Actuator is activated)	Battery voltage
					Other than LOCK (Actuator is not activated)	0 V
9 (G)	Ground	Driver door UNLOCK	Output	Driver door	UNLOCK (Actuator is activated)	Battery voltage
					Other than UNLOCK (Actuator is not activated)	0 V
10 (P)	Ground	Rear RH door and rear LH door UN- LOCK	Output	Rear RH door and rear LH door	UNLOCK (Actuator is activated)	Battery voltage
					Other than UNLOCK (Actuator is not activated)	0 V
11 (LG)	Ground	Battery power supply	Input	Ignition switch OFF		Battery voltage
13 (B)	Ground	Ground	—	Ignition switch ON		0 V
14 (O)	Ground	Push-button ignition switch illumination ground	Output	Tail lamp	OFF	0 V
					ON	<b>NOTE:</b> When the illumination brightening/dimming level is in the neutral position 
15 (L)	Ground	ACC indicator lamp	Output	Ignition switch	OFF (LOCK and ON indicator lamps are not illuminated.)	Battery voltage
					ACC	0 V

A

B

C

D

E

F

G

H

I

J

K

WW

M

N





O

P

JSNIA0010GB







# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
17 (G)	Ground	Turn signal RH	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch RH	 PKID0926E 6.5 V
18 (BR)	Ground	Turn signal LH	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch LH	 PKID0926E 6.5 V
19 (Y)	Ground	Room lamp timer control	Output	Interior room lamp	OFF	Battery voltage
					ON	0 V
23 (BR)	Ground	Back door open	Output	Back door	OPEN (Back door opener actuator is activated)	Battery voltage
					Other than OPEN (Back door opener actuator is not activated)	0 V
26 (G)	Ground	Rear wiper	Output	Rear wiper	OFF (Stopped)	0 V
					ON (Operated)	Battery voltage
34 (B)	Ground	Luggage room antenna (-)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compartment	 JMKIA0062GB
					When Intelligent Key is not in the passenger compartment	 JMKIA0063GB

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
35 (W)	Ground	Luggage room antenna (+)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compartment	
					When Intelligent Key is not in the passenger compartment	
38 (L)	Ground	Rear bumper antenna (-)	Output	When the back door request switch is operated with ignition switch OFF	When Intelligent Key is in the antenna detection area	
					When Intelligent Key is not in the antenna detection area	
39 (BR)	Ground	Rear bumper antenna (+)	Output	When the back door request switch is operated with ignition switch OFF	When Intelligent Key is in the antenna detection area	
					When Intelligent Key is not in the antenna detection area	
47 (L)	Ground	Ignition relay (IPDM E/R) control	Output	Ignition switch	OFF or ACC	Battery voltage
					ON	0 V

A

B

C

D

E

F

G

H

I

J

K

WW

M





N

O

P

# BCM (BODY CONTROL MODULE)





## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
52 (R)	Ground	Starter relay control	Output	Ignition switch ON	When selector lever is in P or N position	Battery voltage
					When selector lever is not in P or N position	0.3 V
				Ignition switch OFF		0 V
61 (R)	Ground	Back door request switch	Input	Back door re- quest switch	ON (Pressed)	0 V
					OFF (Not pressed)	 1.0 V
64 (GR)	Ground	Warning buzzer	Output	Warning buzzer	Sounding	0 V
					Not sounding	Battery voltage
65 (O)	Ground	Rear wiper stop posi- tion	Input	Rear wiper	In stop position	 1.0 V
					Not in stop position	0 V
66 (Y)	Ground	Back door switch	Input	Back door switch	OFF (When back door closes)	 11.8 V
					ON (When back door opens)	0 V
67 (LG)	Ground	Back door opener switch	Input	Back door opener switch	Pressed	0 V
					Not pressed	 11.8 V



# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >







Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
68 (W)	Ground	Rear RH door switch	Input	Rear RH door switch	OFF (When rear RH door closes)	 <p>JPMIA0011GB</p> <p>11.8 V</p>
				Rear RH door switch	ON (When rear RH door opens)	0 V
69 (R)	Ground	Rear LH door switch	Input	Rear LH door switch	OFF (When rear LH door closes)	 <p>JPMIA0011GB</p> <p>11.8 V</p>
				Rear LH door switch	ON (When rear LH door opens)	0 V
72 (B)	Ground	Room antenna (-) (Center console)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compart- ment	 <p>JMKIA0062GB</p>
				Ignition switch OFF	When Intelligent Key is not in the passenger compart- ment	 <p>JMKIA0063GB</p>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW





# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
73 (W)	Ground	Room antenna (+) (Center console)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compart- ment	 JMKIA0062GB
					When Intelligent Key is not in the passenger compart- ment	 JMKIA0063GB
74 (Y)	Ground	Passenger door an- tenna (-)	Output	When the pas- senger door re- quest switch is operated with ig- nition switch OFF	When Intelligent Key is in the antenna detection area	 JMKIA0062GB
					When Intelligent Key is not in the antenna detection area	 JMKIA0063GB
75 (LG)	Ground	Passenger door an- tenna (+)	Output	When the pas- senger door re- quest switch is operated with ig- nition switch OFF	When Intelligent Key is in the antenna detection area	 JMKIA0062GB
					When Intelligent Key is not in the antenna detection area	 JMKIA0063GB

# BCM (BODY CONTROL MODULE)







## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
76 (V)	Ground	Driver door antenna (-)	Output	When the driver door request switch is operat- ed with ignition switch OFF	When Intelligent Key is in the antenna detection area	 JMKIA0062GB
				When Intelligent Key is not in the antenna detection area	When Intelligent Key is not in the antenna detection area	 JMKIA0063GB
77 (P)	Ground	Driver door antenna (+)	Output	When the driver door request switch is operat- ed with ignition switch OFF	When Intelligent Key is in the antenna detection area	 JMKIA0062GB
				When Intelligent Key is not in the antenna detection area	When Intelligent Key is not in the antenna detection area	 JMKIA0063GB
80 (SB)	Ground	NATS antenna amp.	Input/ Output	During waiting	Ignition switch is pressed while inserting Intelligent Key into the key slot.	Just after pressing ignition switch. Pointer of tester should move.
81 (O)	Ground	NATS antenna amp.	Input/ Output	During waiting	Ignition switch is pressed while inserting Intelligent Key into the key slot.	Just after pressing ignition switch. Pointer of tester should move.
82 (BR)	Ground	Ignition relay [fuse block (J/B)] control	Output	Ignition switch	OFF or ACC	0 V
					ON	Battery voltage

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
WW  
M  
N  
O  
P






# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
83 (P)	Ground	Remote keyless entry receiver communica- tion	Input/ Output	During waiting	 JMKIA0064GB
				When operating either button on Intelligent Key	 JMKIA0065GB
87 (R)	Ground	Combination switch INPUT 5	Input	Combination switch	
				All switches OFF (Wiper intermittent dial 4)	 JPMIA0041GB 1.4 V
				Front fog lamp switch ON (Wiper intermittent dial 4)	 JPMIA0037GB 1.3 V
				Rear wiper switch ON (Wiper intermittent dial 4)	 JPMIA0039GB 1.3 V
				Any of the conditions below with all switches OFF <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 2</li> <li>• Wiper intermittent dial 6</li> <li>• Wiper intermittent dial 7</li> </ul>	 JPMIA0040GB 1.3 V

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
88 (GR)	Ground	Combination switch INPUT 3	Input	Combination switch	All switches OFF (Wiper intermittent dial 4)	 1.4 V
					Lighting switch HI (Wiper intermittent dial 4)	 1.3 V
					Lighting switch 2ND (Wiper intermittent dial 4)	 1.3 V
					Rear washer switch ON (Wiper intermittent dial 4)	 1.3 V
					Any of the conditions below with all switches OFF <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 2</li> <li>• Wiper intermittent dial 3</li> </ul>	 1.3 V
89 (BR)	Ground	Push-button ignition switch (push switch)	Input	Push-button igni- tion switch (push switch)	Pressed	0 V
					Not pressed	Battery voltage
90 (P)	Ground	CAN - L	Input/ Output	—	—	—
91 (L)	Ground	CAN - H	Input/ Output	—	—	—

A

B

C

D

E

F

G

H

I

J

K

WW

M




N

O

P






# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
92 (R)	Ground	Key slot illumination	Output	Key slot illumination	OFF	0 V
					Blinking	 <p>JPMA0015GB</p>
					ON	Battery voltage
93 (P)	Ground	ON indicator lamp	Output	Ignition switch	OFF (LOCK and ACC indicator lamps are not illuminated.)	Battery voltage
					ON	0 V
95 (L)	Ground	ACC relay control	Output	Ignition switch	OFF	0 V
					ACC or ON	Battery voltage
96 (Y)	Ground	CVT shift selector (detention switch) power supply	Output	—	—	Battery voltage
97*1 (O)	Ground	Steering lock condition No. 1	Input	Steering lock	LOCK status	0 V
					UNLOCK status	Battery voltage
98*1 (L)	Ground	Steering lock condition No. 2	Input	Steering lock	LOCK status	Battery voltage
					UNLOCK status	0 V
99 (V)	Ground	Selector lever P position switch	Input	Selector lever	P position	0 V
					Any position other than P	Battery voltage
100 (P)	Ground	Passenger door request switch	Input	Passenger door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	 <p>JPMA0016GB</p>
101 (W)	Ground	Driver door request switch	Input	Driver door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	 <p>JPMA0016GB</p>
102 (Y)	Ground	Blower fan motor relay control	Output	Ignition switch	OFF or ACC	0 V
					ON	Battery voltage
103 (L)	Ground	Remote keyless entry receiver power supply	Output	Ignition switch OFF		Battery voltage

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >






Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
106*1 (Y)	Ground	Steering lock unit power supply	Output	Ignition switch	OFF or ACC	Battery voltage
					ON	0 V
107 (O)	Ground	Combination switch INPUT 1	Input	Combination switch (Wiper intermittent dial 4)	All switches OFF	 1.4 V
					Turn signal switch LH	 1.3 V
					Turn signal switch RH	 1.3 V
					Front wiper switch LO	 1.3 V
					Front washer switch ON	 1.3 V

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW

# BCM (BODY CONTROL MODULE)







## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
108 (P)	Ground	Combination switch INPUT 4	Input	Combination switch	<p>All switches OFF (Wiper intermittent dial 4)</p>  <p>1.4 V</p>
					<p>Lighting switch AUTO (Wiper intermittent dial 4)</p>  <p>1.3 V</p>
					<p>Lighting switch 1ST (Wiper intermittent dial 4)</p>  <p>1.3 V</p>
					<p>Rear wiper switch INT (Wiper intermittent dial 4)</p>  <p>1.3 V</p>
					<p>Any of the conditions below with all switches OFF</p> <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 5</li> <li>• Wiper intermittent dial 6</li> </ul>  <p>1.3 V</p>



# BCM (BODY CONTROL MODULE)




## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)	
+	-	Signal name	Input/ Output				
109 (SB)	Ground	Combination switch INPUT 2	Input	Combination switch (Wiper intermit- tent dial 4)	All switches OFF	 JPMIA0041GB 1.4 V	A
					Lighting switch PASS	 JPMIA0037GB 1.3 V	B
					Lighting switch 2ND	 JPMIA0036GB 1.3 V	C
					Front wiper switch INT/ AUTO	 JPMIA0038GB 1.3 V	D
					Front wiper switch HI	 JPMIA0040GB 1.3 V	E
110 (G)	Ground	Hazard switch	Input	Hazard switch	ON	0 V	F
					OFF	 JPMIA0012GB 1.1 V	G

WW





# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
111*1 (LG)	Ground	Steering lock unit communication	Input/ Output	Steering lock	LOCK status	Battery voltage
					LOCK or UNLOCK	
					For 15 seconds after UN- LOCK	Battery voltage
					15 seconds or later after UNLOCK	0 V
112 (R)	Ground	Rain sensor serial link	Input/ Output	Ignition switch ON		
113 (O)	Ground	Optical sensor	Input	Ignition switch ON	When bright outside of the vehicle	Close to 5 V
					When dark outside of the vehicle	Close to 0 V
116 (GR)	Ground	Stop lamp switch 1	Input	—		Battery voltage
118 (L)	Ground	Stop lamp switch 2	Input	Stop lamp switch	OFF (Brake pedal is not depressed)	0 V
					ON (Brake pedal is de- pressed)	Battery voltage
119 (W)	Ground	Front door lock as- sembly driver side (Unlock sensor)	Input	Driver door	LOCK status (unlock sen- sor switch OFF)	
					UNLOCK status (unlock sensor switch ON)	0 V
121 (Y)	Ground	Key slot switch	Input	When Intelligent Key is inserted into key slot		Battery voltage
				When Intelligent Key is not inserted into key slot		0 V
123 (G)	Ground	IGN feedback	Input	Ignition switch	OFF or ACC	0 V
					ON	Battery voltage

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
124 (R)	Ground	Passenger door switch	Input	Passenger door switch	OFF (When passenger door closes)	 11.8 V
					ON (When passenger door opens)	0 V
130*2 (BR)	Ground	Rear window defog- ger switch	Input	Ignition switch ON	Rear window defogger switch OFF	 1.1 V
					Rear window defogger switch ON	0 V
132 (G)	Ground	Power window switch communication	Input/ Output	Ignition switch ON		 10.2 V
				Ignition switch OFF or ACC		Battery voltage
133 (W)	Ground	Push-button ignition switch illumination	Output	Push-button igni- tion switch illumina- tion	ON (When tail lamps OFF)	9.5 V
					ON (When tail lamps ON)	<b>NOTE:</b> The pulse width of this wave is varied by the illumination bright- ening/dimming level.  
					OFF	0 V
134 (R)	Ground	LOCK indicator lamp	Output	LOCK indicator lamp	OFF (ACC and ON indica- tor lamps are not illuminat- ed.)	Battery voltage
					ON	0 V
137 (P)	Ground	Receiver and sensor ground	Input	Ignition switch ON		0 V
138 (V)	Ground	Receiver and sensor power supply	Output	Ignition switch	OFF	0 V
					ACC or ON	5.0 V

A

B

C

D

E

F

G

H

I

J

K

WW

M






N

O

P






# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
139 (O)	Ground	Tire pressure receiver communication	Input/ Output	Ignition switch ON	Standby state	 OCC3881D
					When receiving the signal from the transmitter	 OCC3880D
140 (GR)	Ground	Selector lever P/N position	Input	Selector lever	P or N position	Battery voltage
					Except P and N positions	0 V
141 (O)	Ground	Security indicator	Output	Security indicator	ON	0 V
					Blinking	 JPMIA0014GB 11.3 V
					OFF	Battery voltage
142 (L)	Ground	Combination switch OUTPUT 5	Output	Combination switch (Wiper intermittent dial 4)	All switches OFF	0 V
					Lighting switch 1ST	 JPMIA0031GB 10.7 V
					Lighting switch HI	
					Lighting switch 2ND	
					Turn signal switch RH	
143 (W)	Ground	Combination switch OUTPUT 1	Output	Combination switch	All switches OFF (Wiper intermittent dial 4)	0 V
					Front wiper switch HI (Wiper intermittent dial 4)	 JPMIA0032GB 10.7 V
					Rear wiper switch INT (Wiper intermittent dial 4)	
					Any of the conditions below with all switches OFF <ul style="list-style-type: none"> <li>Wiper intermittent dial 1</li> <li>Wiper intermittent dial 2</li> <li>Wiper intermittent dial 3</li> <li>Wiper intermittent dial 6</li> <li>Wiper intermittent dial 7</li> </ul>	

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
144 (P)	Ground	Combination switch OUTPUT 2	Output	Combination switch	All switches OFF (Wiper intermittent dial 4)	0 V
					Front washer switch ON (Wiper intermittent dial 4)	
					Rear wiper switch ON (Wiper intermittent dial 4)	
					Rear washer switch ON (Wiper intermittent dial 4)	
					Any of the conditions below with all switches OFF <ul style="list-style-type: none"><li>• Wiper intermittent dial 1</li><li>• Wiper intermittent dial 5</li><li>• Wiper intermittent dial 6</li></ul>	
145 (V)	Ground	Combination switch OUTPUT 3	Output	Combination switch (Wiper intermit- tent dial 4)	All switches OFF	0 V
					Front wiper switch INT/ AUTO	
					Front wiper switch LO	
					Lighting switch AUTO	
146 (Y)	Ground	Combination switch OUTPUT 4	Output	Combination switch (Wiper intermit- tent dial 4)	All switches OFF	0 V
					Front fog lamp switch ON	
					Lighting switch 2ND	
					Lighting switch PASS	
					Turn signal switch LH	
149 (W)	Ground	Tire pressure warn- ing check switch	Input	Ignition switch ON		
						11.8 V
150 (SB)	Ground	Driver door switch	Input	Driver door switch	OFF (When driver door closes)	
					ON (When driver door opens)	0 V

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

## BCM (BODY CONTROL MODULE)

### < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
		Signal name	Input/ Output			
+	–					
151 (G)	Ground	Rear window defog- ger relay control	Output	Rear window de- fogger	Active	0 V
					Not activated	Battery voltage

**NOTE:**


- \*1: With steering lock unit
- \*2: Without BOSE audio system

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Wiring Diagram - BCM -

INFOID:000000005683168




2009/08/07

JCMWM4865GB

# BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >



JCMWM4866GB



< ECU DIAGNOSIS INFORMATION >




JCMWM4867GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
**WW**  
M  
N  
O  
P

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


<XM> : Except for Mexico  
 <RS> : With rain sensor  
 <WX> : With xenon headlamp  
 <OX> : Without xenon headlamp



JCMWM4868GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
WW  
M  
N  
O  
P

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

## BCM (BODY CONTROL MODULE)

Connector No.	B8
Connector Name	AUTOMATIC BACK DOOR CONTROL UNIT
Connector Type	TH20FW-T56



12	11	10	9	8	7	6	5	4	3	2	1		
26	25	24	23	22	21	20	19	18	17	16	15	14	13

Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	Buzzer
2	Y	ABD SW
4	Y	ABD CLOSE SW
6	L	CAN HI
7	P	CAN LOW
8	LG	HALF LATCH SW
9	GR	IGN
10	SB	BAT
11	V	CLOSURE MTR (CLOSE)
12	R	CLOSURE MTR (OPEN)
14	V	TOUCH SENS LH
15	O	TOUCH SENS GND
16	W	TOUCH SENS RH
17	LG	MAIN SW
19	P	CLOSE SW
20	L	OPEN SW
21	B	GND
22	B	GND
23	GR	GND
24	BR	ENCODER B
25	Y	ENCODER A
26	G	ENCODER PWR

Connector No.	B34
Connector Name	FRONT DOOR SWITCH (DRIVER SIDE)
Connector Type	A03FW



1	2	3
---	---	---

Terminal No.	Color of Wire	Signal Name [Specification]
--------------	---------------	-----------------------------

2	SB	-
---	----	---

Connector No.	B59
Connector Name	REAR COMBINATION LAMP RH
Connector Type	NS4MMW-CS



4	3	2	1
---	---	---	---

Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	-[With rear view camera]
1	B/W	-[Without rear view camera]
2	BR	-
3	P	-
4	L	-

Connector No.	B71
Connector Name	REAR DOOR SWITCH LH
Connector Type	A03FW



1	2	3
---	---	---

Terminal No.	Color of Wire	Signal Name [Specification]
2	BR	-

Connector No.	B73
Connector Name	DIODE
Connector Type	24335 CS902



1	2
---	---

Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	L	-

Connector No.	B80
Connector Name	REAR COMBINATION LAMP LH
Connector Type	NS4MMW-CS



4	3	2	1
---	---	---	---

Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	Y	-
3	P	-
4	L	-

Connector No.	B85
Connector Name	OUTSIDE KEY ANTENNA (REAR BUMPER)
Connector Type	RK02FGY



1	2
---	---

Terminal No.	Color of Wire	Signal Name [Specification]
--------------	---------------	-----------------------------

1	R	-
2	G	-

Connector No.	B86
Connector Name	INSIDE KEY ANTENNA (LUGGAGE ROOM)
Connector Type	RK02FGY



1	2
---	---

Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	B	-

Connector No.	B220
Connector Name	FRONT DOOR SWITCH (PASSENGER SIDE)
Connector Type	A03FW



1	2	3
---	---	---

Terminal No.	Color of Wire	Signal Name [Specification]
2	R	-


JCMWM4870GB

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

## BCM (BODY CONTROL MODULE)

Connector No.	B221
Connector Name	REAR DOOR SWITCH RH
Connector Type	AG3FW



Terminal No.	2
Color of Wire	W
Signal Name [Specification]	-

Connector No.	B407
Connector Name	LUMBAR SUPPORT SWITCH
Connector Type	NS4FBR-CS



Terminal No.	11
Color of Wire	O
Signal Name [Specification]	-
12	LG
13	Y/W
14	Y

Connector No.	B414
Connector Name	POWER SEAT SWITCH (DRIVER SIDE)
Connector Type	NS10FW-CS



Terminal No.	1
Color of Wire	R
Signal Name [Specification]	-

2	B	-
3	G	-
4	G/R	-
5	V	-
6	R/L	-
7	L	-
8	L/W	-
9	L/R	-
10	L/B	-

Connector No.	B434
Connector Name	POWER SEAT SWITCH (PASSENGER SIDE)
Connector Type	NS10FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	B	-
3	G	-
4	G/R	-
5	V	-
6	B/W	-

Connector No.	B432
Connector Name	DRIVER SEAT CONTROL UNIT
Connector Type	TH43FW



Terminal No.	Color of Wire	Signal Name [Specification]
11	G/B	-
12	G/W	-
13	R/G	-
14	R/W	-
15	V/B	-

16	Y/R	-
17	LG/B	-
18	LG/R	-
19	G/Y	-
20	R/Y	-
21	L/Y	-
22	BR/Y	-
23	P	-
24	P/L	-
25	G/O	-
26	L/O	-
27	V	-
28	V/W	-
29	O/L	-
30	BR	-
31	BR/W	-
32	W/L	-
33	W	-

Connector No.	D5
Connector Name	POWER WINDOW MAIN SWITCH
Connector Type	NS16FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	-
2	W	-
3	BR	-
4	L	-
5	SB	-
6	R	-
7	P	-
8	L	-
9	G	-
10	V	-
11	LG	-
13	Y	-
14	O	-
15	R	-

Connector No.	D6
Connector Name	POWER WINDOW MAIN SWITCH
Connector Type	NS33FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
17	B	-
19	LG	-

Connector No.	D8
Connector Name	FRONT DOOR LOOK ASSEMBLY (DRIVER SIDE)
Connector Type	ES6FGY-RS



Terminal No.	Color of Wire	Signal Name [Specification]
1	V	-
2	G	-
3	P	-
4	B	-
5	R	-
6	L	-

JCMWMM4871GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
WW  
M  
N  
O  
P

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

## BCM (BODY CONTROL MODULE)

Connector No.	D11
Connector Name	FRONT OUTSIDE HANDLE LH (REQUEST SWITCH)
Connector Type	RK02FB



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	B	-

Connector No.	D12
Connector Name	FRONT OUTSIDE HANDLE LH (OUTSIDE KEY ANTENNA)
Connector Type	RK02MGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	P	-
2	V	-

Connector No.	D17
Connector Name	STEP LAMP (DRIVER SIDE)
Connector Type	G02FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	R	-

Connector No.	D45
Connector Name	FRONT POWER WINDOW SWITCH (PASSENGER SIDE)
Connector Type	NS30FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
3	W	-
4	R	-
8	L	-
9	LG	-
10	P	-
11	B	-
12	Y	-
13	G	-
16	O	-

Connector No.	D48
Connector Name	FRONT DOOR LOCK ASSEMBLY (PASSENGER SIDE)
Connector Type	E06FGY-RS



Terminal No.	Color of Wire	Signal Name [Specification]
5	V	-
6	G	-

Connector No.	D50
Connector Name	FRONT OUTSIDE HANDLE RH (REQUEST SWITCH)
Connector Type	RK02FB



Terminal No.	Color of Wire	Signal Name [Specification]
1	O	-
2	B	-

Connector No.	D51
Connector Name	STEP LAMP (PASSENGER SIDE)
Connector Type	G02FW




Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	R	-

Connector No.	D52
Connector Name	FRONT OUTSIDE HANDLE RH (OUTSIDE KEY ANTENNA)
Connector Type	RK02MGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	-
2	W	-

Connector No.	D63
Connector Name	REAR POWER WINDOW SWITCH LH
Connector Type	NS30FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	P	-
3	SB	-
4	LG	-
5	L	-

Connector No.	D65
Connector Name	REAR DOOR LOCK ASSEMBLY LH
Connector Type	E06FGY-RS



Terminal No.	Color of Wire	Signal Name [Specification]
1	V	-
2	G	-


JCMWM4872GB

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

## BCM (BODY CONTROL MODULE)

Connector No.	D103
Connector Name	REAR POWER WINDOW SWITCH RH
Connector Type	NS08FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	P	-
3	SB	-
4	LG	-
5	L	-

Connector No.	D105
Connector Name	REAR DOOR LOCK ASSEMBLY RH
Connector Type	ED08FY-RS



Terminal No.	Color of Wire	Signal Name [Specification]
5	V	-
6	G	-

Connector No.	D156
Connector Name	LUGGAGE ROOM LAMP RH
Connector Type	CJ04FW



Terminal No.	Color of Wire	Signal Name [Specification]
2	W	-
4	LG	-

Connector No.	D157
Connector Name	LUGGAGE ROOM LAMP LH
Connector Type	CJ04FW



Terminal No.	Color of Wire	Signal Name [Specification]
2	W	-
4	LG	-

Connector No.	D178
Connector Name	AUTOMATIC BACK DOOR CLOSE SWITCH
Connector Type	TK08FGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	O	-
2	B	-
3	W	-
4	LG	-

Connector No.	D179
Connector Name	BACK DOOR LOCK ASSEMBLY (WITH AUTOMATE BACK DOOR)
Connector Type	NS08FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	V	-
4	G	-
5	L	-
6	W	-
7	LG	-
8	B	-

Connector No.	D180
Connector Name	BACK DOOR LOCK ASSEMBLY (WITHOUT AUTOMATE BACK DOOR)
Connector Type	NS04FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	B	-
3	LG	-
4	B	-

Connector No.	D186
Connector Name	BACK DOOR OPENER SWITCH ASSEMBLY
Connector Type	TR04MF-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	B	-
3	B	-
4	V	-

Connector No.	D193
Connector Name	REAR WIPER MOTOR
Connector Type	CJ04FW-1V



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
3	GR	-
4	O	-

JCMWM4873GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


WW

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

### BCM (BODY CONTROL MODULE)

Connector No.	E10
Connector Name	ENGINE INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	TH20FW-CS12-M4-1V




Terminal No.	Color of Wire	Signal Name [Specification]
4	LG	-
5	Y	-
7	GR	-
10	BR	-
11	P	-
12	B	-
13	SB	-
13	W	-
16	L/Y	-
19	Y	-
20	L	-
21	O	-
22	SB	-
23	GR	-
24	G	-
25	GR	-
26	Y	-
27	W	-
28	SB	-
30	BR	-
32	V	-
33	G	-
34	O	-
35	P	-
36	G	-
38	GR	-

Connector No.	E11
Connector Name	ENGINE INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	TH20FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
39	P	-
40	L	-
41	B	-
42	SB	-
43	Y	-
44	W	-
45	O	-
46	BR	-

Connector No.	E16
Connector Name	ECM
Connector Type	RH24FB-RZ8-L-LH



Terminal No.	Color of Wire	Signal Name [Specification]
81	W	APSI
82	O	APS2
83	BR	AVCC1-APSI1
84	B	GND-APSI1
85	Y	ASCD SW
86	SB	FTPRES
87	GR	AVCC2-APS2
88	O	KLINE
91	L	AVCC2-FTPRES
92	BR	GND-ASCD SW
93	BR	IGN SW
94	GR	TACHO(GABIN)
95	Y	TF
96	GR	GND-FTPRES


97	P	VEH CAN-L
98	L	VEH CAN-H
100	G	GND-APS2
102	B	NEUT-H
104	SB	GND-IF
105	V	VER
106	SB	BRAKE
107	B	GND
108	B	GND
109	W	ODCV
110	G	ENCSW
111	B	GND
112	B	GND

Connector No.	E25
Connector Name	INTELLIGENT KEY WARNING BUZZER
Connector Type	RK03BR



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
3	GR	-


Connector No.	E36
Connector Name	ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)
Connector Type	AE22FB-AJZ4-LH



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	VALVE/ECU SUPPLY
2	Y	WSS RL SIG(-)
3	L	WSS RL PWRC(-)
4	GR	CLUSTER SUPPLY
5	B	WSS FR PWRC(-)

6	W	WSS FR SIG(-)
7	LG	LIS
8	V	WSS FL SIG(-)
9	W	WSS FL PWRC(-)
10	SB	CLUSTER GND
11	P	WSS RR PWRC(-)
12	V	WSS RR SIG(-)
13	B/W	MOTOR GND
14	G	MOTOR SUPPLY
16	SB	BLS
18	O	DIAG K
19	BR	CAN2 H
20	GR	IGN
21	P	CAN1 L
22	Y	VDC OFF SW
23	L	CAN1 H
25	W	CAN2 L
26	B/W	VALVE/ECU GND

Connector No.	E03
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS16FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1F	L	-
2F	LG	-
4F	BR	-
6F	Y	-
8F	R	-
9F	GR	-
11F	G	-
12F	V	-

JCMWM4874GB



# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

## BCM (BODY CONTROL MODULE)

Connector No.	E116
Connector Name	STOP LAMP SWITCH
Connector Type	M04FW-LC



3	4
1	2

Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	LG	-
3	G	-
4	Y	-

Connector No.	E318
Connector Name	FRONT COMBINATION LAMP LH
Connector Type	Z03FER



3	2	1
---	---	---

Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	-
2	B	-
3	Y	-

Connector No.	E319
Connector Name	FRONT COMBINATION LAMP RH
Connector Type	Z03FER



3	2	1
---	---	---

Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	G	-
3	-	-

Connector No.	E327
Connector Name	FRONT TURN SIGNAL LAMP LH
Connector Type	RS02FGY



2	1
---	---

Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
2	B	-

Connector No.	E328
Connector Name	FRONT TURN SIGNAL LAMP RH
Connector Type	RS02FGY



2	1
---	---

Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	B	-

Connector No.	F12
Connector Name	ENGINE FUEL INJECTION POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	T423FW-CS12-M4



55	54	53	52	51	50	49	48	47	46	45	44	43	42	41	40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	---	---	---	---	---	---	---	---	---	---

Terminal No.	Color of Wire	Signal Name [Specification]
48	W	-
49	R/B	-
51	LG	-
52	Y/G	-
53	R/W	-
54	G/W	-
55	W/L	-
56	R/Y	-
57	O	-
58	Y	-
69	W/B	-
70	O	-
72	R/B	-
75	LG	-
76	SB	-
77	GR	-
80	B	-

Connector No.	F23
Connector Name	TCM (TRANSMISSION CONTROL MODULE)
Connector Type	RH40FB-R2B-L-RH



31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48
----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name [Specification]
1	P/B	INH SW 2
2	P/L	INH SW 3
3	G/O	INH SW 4
4	GR	INH SW 3 MON
5	B	GND

Terminal No.	Color of Wire	Signal Name [Specification]
6	O	K-LINE
7	W	SENSOR GND
8	G/W	CLOCK (SEL2)
9	L/R	CHP SELECT (SEL1)
10	BR/R	DATA I/O (SEL3)
11	BR/W	INH SW 1
13	V	ATF TEMP SENSOR
14	R/W	PRI PRESS SENSOR
15	V/W	SEC PRESS SENSOR
19	G/B	REV LAMP RELAY
20	R/B	STARTER RELAY
25	W/R	SENSOR GND
26	L/O	SENSOR POWER SOURCE(V)
27	R/G	S/M-D
28	R	S/M-C
29	O/B	S/M-B
30	G/R	S/M-A
31	P	CAN-H
32	L	CAN-L
33	LG	PRI SPEED SENSOR
34	LG/R	SEC SPEED SENSOR
37	V/R	L/OASEL-ON/OFF SOL
38	L/W	L/OASEL LINEAR SOL
39	W/B	SEC LINEAR SOL
40	R/Y	PL LINEAR SOL
42	B	GND
46	Y	VIGN
47	L/R	BATT
48	Y	VIGN

JCMWM4875GB

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

### BCM (BODY CONTROL MODULE)

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS06FW-M2



3A	2A1A
8A	7A6A5A4A

Terminal No.	Color of Wire	Signal Name [Specification]
1A	Y	-
2A	G	-
3A	Y	-
4A	GR	-
5A	R	-
6A	W	-
7A	LG	-
8A	Y	-

Connector No.	M2
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS10FW-CS



4B	3B	2B1B
10B	9B	8B7B6B5B

Terminal No.	Color of Wire	Signal Name [Specification]
1B	W	-
3B	L	-
4B	G	-
5B	L	-
6B	Y	-
7B	R	-
8B	R	-
9B	GR	-

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS12FW-CS



5C	4C	3C2C1C
12C	11C	10C9C8C7C6C

Terminal No.	Color of Wire	Signal Name [Specification]
6C	BR	-
7C	B	-
8C	G	-
9C	GR	-
10C	SB	-
11C	R	-
12C	O	-

Connector No.	M4
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FW



9	10	11	12	13	14	15	16
1	2	3	4	5	6	7	8

Terminal No.	Color of Wire	Signal Name [Specification]
4	B	-
5	B	-
6	L	-
7	O	-
8	G	-
14	P	-
16	Y	-

Connector No.	M12
Connector Name	STEERING LOCK UNIT
Connector Type	TH06FW-MH



4	3	2	1
8	7	6	5

Terminal No.	Color of Wire	Signal Name [Specification]
1	P	S/L 12V MECHANICAL(V1)
2	LG	S/L COM
3	O	S/L CONDITION 1
5	B	GND 1
6	B	GND 2
7	Y	S/L 12V CP(V2)
8	L	S/L CONDITION 2

Connector No.	M17
Connector Name	OPTICAL SENSOR
Connector Type	TK03FW



1	2	3
---	---	---

Terminal No.	Color of Wire	Signal Name [Specification]
1	V	-
2	O	-
3	P	-

Connector No.	M19
Connector Name	TIRE PRESSURE WARNING CHECK SWITCH
Connector Type	TK02FW



1	2
---	---

Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-

Connector No.	M21
Connector Name	TIRE PRESSURE RECEIVER
Connector Type	TK04FW



1	2	3	4
---	---	---	---

Terminal No.	Color of Wire	Signal Name [Specification]
1	P	GND
2	O	SIGNAL
4	V	POWER

JCMWM4876GB

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

## BCM (BODY CONTROL MODULE)

Connector No.	M34
Connector Name	COMBINATION METER
Connector Type	TH40PW-NH



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	BAT
2	O	IGN
3	B	GROUND
4	B	GROUND
5	SB	ILLUMINATION CONTROL
8	SB	TRIP RESET SWITCH
9	W	SW ILL POWER
10	O	METER CONTROL SW GND
11	L	ENTER SWITCH
12	R	SELECT SWITCH
13	V	ILLUMINATION CONTROL SWITCH (OFF/On automatic drive position)
13	Y	ILLUMINATION CONTROL SWITCH (OFF/On automatic drive position)
14	GR	ILLUMINATION CONTROL SWITCH (-)
15	BR	AIR BAG
18	L	AMBIENT SENSOR
19	P	AMBIENT SENSOR POWER
20	Y	AMBIENT SENSOR GROUND
21	L	CAN-H
22	P	CAN-L
23	B	GROUND
24	W	FUEL LEVEL SENSOR GROUND
25	BR	CHG
26	G	PARKING BRAKE SWITCH
27	V	BRAKE FLUID LEVEL SWITCH
29	R	WASHER LEVEL SWITCH
30	P	VEHICLE SPEED (2-PULSE)
31	V	VEHICLE SPEED (8-PULSE)
32	LG	OD OFF/SPORTS
34	G	FUEL LEVEL SENSOR
35	SB	SEAT BELT BUCKLE SWITCH (DRIVER SIDE)
36	R	SEAT BELT BUCKLE SWITCH (PASSENGER SIDE)

Connector No.	M45
Connector Name	HAZARD SWITCH
Connector Type	TK30FW



3	1	2	4
---	---	---	---

Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	G	-
3	R	-
4	SB	-

Connector No.	M50
Connector Name	A/C AUTO AMP
Connector Type	ISAB0FW



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name [Specification]
1	L	CAN-H
2	P	CAN-L
6	L	TX(AMP)/SW(IG/SP)
7	P	RX(SW/AMP)
10	L	LAN SIG
11	R	VACTR
15	O	SUN SENS
16	G	INTAKE SENS
17	R	ACC
19	B	IGN
20	G	RR DEF F/B
26	GR	RR DEF F/B
27	BR	RR DEF ON
32	L	FAN PWM
34	P	AMB POWER
35	L	AMB SENS
36	LG	INCAR SENS
37	Y	SENS GND

39	B	GND(POWER)
40	Y	BAT

Connector No.	M57
Connector Name	CVT SHIFT SELECTOR
Connector Type	TK10FW



1	3	7	9
2	4	5	6
		8	

Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	-
4	B	-
6	P	-
7	B	-
8	Y	-
9	V	-

Connector No.	M78
Connector Name	REMOTE KEYLESS ENTRY RECEIVER
Connector Type	JAB04FB



1	2	3	4
---	---	---	---

Terminal No.	Color of Wire	Signal Name [Specification]
1	P	GND
2	P	SIGNAL
4	L	+12V

Connector No.	M89
Connector Name	KEY SLOT
Connector Type	TH12FW-NH



1	2	3	4	5	6
7	8	9	10	11	12

Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	BAT
2	SB	GLOCK
3	O	DATA
5	GR	ILL BAT
6	B	ILL
7	B	GND
11	Y	KEY SWITCH SIGNAL

Connector No.	MT00
Connector Name	SECURITY INDICATOR LAMP
Connector Type	TK02FBR



1	2
---	---

Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	-
2	O	-

JCMWM4877GB

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

### BCM (BODY CONTROL MODULE)

Connector No.	M101
Connector Name	PUSH-BUTTON IGNITION SWITCH
Connector Type	TK08BR



1	2	3		
4	5	6	7	8

Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	O	-
3	W	-
4	BR	-
5	R	-
6	L	-
7	P	-
8	GR	-

Connector No.	M103
Connector Name	COMBINATION SWITCH
Connector Type	TH16FW-NH



1	2	3	4	5	6		
7	8	9	10	11	12	13	14

Terminal No.	Color of Wire	Signal Name [Specification]
1	G	RR
2	Y	OUTPUT 4
3	O	FR
4	W	IGN
5	V	OUTPUT 3
6	B	GND
7	GR	INPUT 3
8	L	OUTPUT 5
9	SB	INPUT 2
10	P	INPUT 4
11	O	INPUT 1
12	W	OUTPUT 1
13	R	INPUT 5
14	P	OUTPUT 2

Connector No.	M118
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	M03FB-LC



1	2	3
---	---	---

Terminal No.	Color of Wire	Signal Name [Specification]
1	W	BAT (F/L)
2	GR	POWER WINDOW POWER SUPPLY (BAT)
3	L	POWER WINDOW POWER SUPPLY (RAP)

Connector No.	M119
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS16FW-CS



4	5	6	7	8	9	10		
11	12	13	14	15	16	17	18	19

Terminal No.	Color of Wire	Signal Name [Specification]
4	P	INTERIOR ROOM LAMP POWER SUPPLY
5	G	PASSENGER DOOR UNLOCK OUTPUT
7	W	STEP LAMP OUTPUT
8	V	ALL DOOR FUEL LID LOCK OUTPUT
9	G	DRIVER DOOR FUEL LID UNLOCK OUTPUT
10	P	REAR DOOR UNLOCK OUTPUT
11	LG	BAT FUSE
13	B	GND
14	O	PUSH-BUTTON IGNITION SW ILL GND
15	L	ACC IND
17	G	TURN SIGNAL RH
18	BR	TURN SIGNAL LH
19	Y	ROOM LAMP TIMER CONTROL

Connector No.	M120
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS12FW-CS



20	21		22	23	24	
25	26	27	28	29	30	31

Terminal No.	Color of Wire	Signal Name [Specification]
23	BR	BACK DOOR OPEN OUTPUT
28	G	REAR WIPER OUTPUT

Connector No.	M121
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH04GY-NH



31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52
----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name [Specification]
34	B	LUGGAGE ROOM ANT1-
35	W	LUGGAGE ROOM ANT1+
38	L	REAR BUMPER ANT-
39	BR	REAR BUMPER ANT+
47	L	IGN RELAY FDM L/R CONT
52	R	STARTER RELAY CONT
61	R	BACK DOOR OPENER REQUEST SW
64	GR	REQUEST SW BUZZER
65	O	REAR WIPER STOP POSITION
66	Y	BACK DOOR SW
67	LG	BACK DOOR OPENER SW
69	W	REAR RH DOOR SW
69	R	REAR LH DOOR SW

Connector No.	M122
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH



53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100	101	102	103	104	105	106	107	108	109	110	111
----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----

Terminal No.	Color of Wire	Signal Name [Specification]
72	B	ROOM ANT2-
73	W	ROOM ANT2+
74	Y	PASSENGER DOOR ANT-
75	LG	PASSENGER DOOR ANT+
76	V	DRIVER DOOR ANT-
77	P	DRIVER DOOR ANT+
80	SB	IMMOBILIZER ANTENNA CONTROL
81	O	IMMOBILIZER ANTENNA SIGNAL
82	BR	IGN RELAY (F/B) CONT
83	P	KEYLESS ENTRY RECEIVER SIGNAL
87	R	COMBI SW INPUT 5
88	GR	COMBI SW INPUT 3
89	BR	PUSH SW
90	P	CAN-L
91	L	CAN-H
92	R	KEY SLOT ILL
93	P	ON IND
95	L	ACC RELAY CONT
96	Y	CVT SHIFT SELECTOR POWER SUPPLY
97	O	S/L CONDITION 1
98	L	S/L CONDITION 2
99	V	SHIFT P
100	P	PASSENGER DOOR REQUEST SW
101	W	DRIVER DOOR REQUEST SW
102	Y	BLOWER FAN MOTOR RELAY CONT
103	L	KEYLESS ENTRY RECEIVER POWER SUPPLY
106	Y	S/L POWER SUPPLY
107	O	COMBI SW INPUT 1
108	P	COMBI SW INPUT 4
109	SB	COMBI SW INPUT 2
110	G	HAZARD SW
111	LG	S/L COMM


JCMWM4878GB

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


## BCM (BODY CONTROL MODULE)

Connector No.	M123
Connector Name	BCM BODY CONTROL MODULE
Connector Type	TH40FG-NH




Terminal No.	Color of Wire	Signal Name [Specification]
112	R	RAIN SENSOR SERIAL LINK
113	O	OPTICAL SENSOR
116	GR	FUSE CHECK
118	L	STOP LAMP SW
119	W	DR DOOR UNLOCK SENSOR
121	Y	KEY SLOT SW
123	G	IGN P/B
124	R	PASSENGER DOOR SW
130	BR	REAR DEFOGGER SW
132	G	POWER WINDOW SW COMM
133	W	PUSH-BUTTON IGNITION SW ILL POWER
134	R	LOCK IND
137	P	RECEIVER/SENSOR GND
138	V	RECEIVER/SENSOR POWER SUPPLY
139	O	TIRE PRESS RECEIVER SIGNAL
140	GR	SHIFT N/P
141	O	SECURITY INDICATOR OUTPUT
142	L	COMBI SW OUTPUT 5
143	W	COMBI SW OUTPUT 1
144	P	COMBI SW OUTPUT 2
145	V	COMBI SW OUTPUT 3
146	Y	COMBI SW OUTPUT 4
148	W	TIRE PRESS WARNING CHECK SW
150	SB	DRIVER DOOR SW
151	G	REAR WINDOW DEFOGGER RELAY

Connector No.	M131
Connector Name	AV CONTROL UNIT (WITH NAVIGATION SYSTEM)
Connector Type	TH432FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
79	L	TEL VOICE SIGNAL (-)
80	R	TEL VOICE SIGNAL (+)
81	SHIELD	SHIELD
82	W	SOUND SIGNAL RH (-) [With DVD player]
82	W	IPod SOUND SIGNAL RH (-) [Without DVD player]
83	R	SOUND SIGNAL RH (+) [With DVD player]
83	R	IPod SOUND SIGNAL RH (+) [Without DVD player]
85	B	GND
86	L	CAN-H
87	P	CAN-L
88	R	AV COMM (H)
89	L	AV COMM (L)
90	G	AV COMM (H)
91	L	AV COMM (L)
95	R	AUX SOUND SIGNAL RH (+)
96	B	AUX SOUND SIGNAL LH (+)
97	W	AUX SOUND SIGNAL GND
98	G	SOUND SIGNAL LH (-) [With DVD player]
98	L	IPod SOUND SIGNAL LH (-) [Without DVD player]
99	B	SOUND SIGNAL LH (+) [With DVD player]
99	BR	IPod SOUND SIGNAL LH (+) [Without DVD player]
100	SHIELD	SHIELD [With DVD player]
100	SHIELD	SHIELD [Without DVD player]
101	V	SW GND
103	W	EJECT SIGNAL
104	G	IGNITION
105	SB	REVERSE
106	G	PARKING BRAKE
107	V	VEHICLE SPEED (8-PULSE)

Connector No.	M145
Connector Name	AV CONTROL UNIT (WITH NAVIGATION SYSTEM)
Connector Type	TH40FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
21	B	GND
22	Y	BATTERY
23	B	GND
24	Y	BATTERY
25	R	ACC
26	B	MICROPHONE VCC
27	SHIELD	MICROPHONE GND
28	W	MICROPHONE SIGNAL
35	G	IGNITION
36	G	PARKING BRAKE
37	SB	REVERSE
38	V	VEHICLE SPEED (8-PULSE)
40	P	CONNECTION RECOGNITION
42	B	CONTROL SIGNAL
43	B	CONTROL SIGNAL
48	G	AV COMM (H)
49	L	AV COMM (L)
50	R	AV COMM (H)
51	L	AV COMM (L)
52	L	CAN-H
53	P	CAN-L

Connector No.	M202
Connector Name	INSIDE KEY ANTENNA (CONSOLE)
Connector Type	RK02FG



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-

2	B	-
---	---	---

Connector No.	R10
Connector Name	VANITY MIRROR LAMP (PASSENGER SIDE)
Connector Type	MC402FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	P/W	-

Connector No.	R19
Connector Name	MAP LAMP
Connector Type	TK08FG



Terminal No.	Color of Wire	Signal Name [Specification]
1	P/W	-
2	Y	-
3	B	-
4	SB	-
5	R/Y	-
6	R/L	-

JCMWM4879GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
Q  
R  
S  
T  
U  
V  
W  
X  
Y  
Z


WW

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

## BCM (BODY CONTROL MODULE)

Connector No.	R21
Connector Name	PERSONAL LAMP
Connector Type	TH04FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	P/W	-
2	B	-
3	SB	-

Connector No.	R23
Connector Name	RAIN SENSOR
Connector Type	AA030FB



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y/R	-
2	B	-
3	B	-


Connector No.	R24
Connector Name	VANITY MIRROR LAMP (DRIVER SIDE)
Connector Type	MC020FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	-	-
2	-	-


1	B	-
2	P/W	-

Connector No.	R101
Connector Name	SUNROOF MOTOR ASSEMBLY
Connector Type	YEA10FGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	GND
2	O	GND
3	L	IGN
4	Y	PUSH SW
5	LG	OPEN SW
6	R	BAT
7	P	COMM
8	BR	SPEED(P)
9	W	2ND SW
10	V	CLOSE SW

Connector No.	R102
Connector Name	SUNSHADE MOTOR ASSEMBLY
Connector Type	YEA10FGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	GND
6	G	BAT
7	P	COMM
8	BR	SPEED(P)

## Fail-safe

### FAIL-SAFE CONTROL BY DTC

BCM performs fail-safe control when any DTC are detected.

JCMWM4880GB

INFOID:0000000005683169

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Display contents of CONSULT	Fail-safe	Cancellation
B2013: ID DISCORD BCM-S/L	Inhibit engine cranking	Erase DTC
B2014: CHAIN OF S/L-BCM	Inhibit engine cranking	Erase DTC
B2190: NATS ANTENNA AMP	Inhibit engine cranking	Erase DTC
B2191: DIFFERENCE OF KEY	Inhibit engine cranking	Erase DTC
B2192: ID DISCORD BCM-ECM	Inhibit engine cranking	Erase DTC
B2193: CHAIN OF BCM-ECM	Inhibit engine cranking	Erase DTC
B2195: ANTI SCANNING	Inhibit engine cranking	Ignition switch ON → OFF
B2557: VEHICLE SPEED	Inhibit steering lock	When normal vehicle speed signals are received from ABS actuator and electric unit (control unit) for 500 ms
B2560: STARTER CONT RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> <li>• Starter control relay signal</li> <li>• Starter relay status signal</li> </ul>
B2601: SHIFT POSITION	Inhibit steering lock	500 ms after the following signal reception status becomes consistent <ul style="list-style-type: none"> <li>• Selector lever P position switch signal</li> <li>• P range signal (CAN)</li> </ul>
B2602: SHIFT POSITION	Inhibit steering lock	5 seconds after the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> <li>• Ignition switch is in the ON position</li> <li>• Selector lever P position switch signal: Except P position (battery voltage)</li> <li>• Vehicle speed: 4 km/h (2.5 MPH) or more</li> </ul>
B2603: SHIFT POSI STATUS	Inhibit steering lock	500 ms after the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> <li>• Ignition switch is in the ON position</li> <li>• Selector lever P position switch signal: Except P position (battery voltage)</li> <li>• Selector lever P/N position signal: Except P and N positions (0 V)</li> </ul>
B2604: PNP SW	Inhibit steering lock	500 ms after any of the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> <li>• Status 1 <ul style="list-style-type: none"> <li>- Ignition switch is in the ON position</li> <li>- Selector lever P/N position signal: P and N position (battery voltage)</li> <li>- P range signal or N range signal (CAN): ON</li> </ul> </li> <li>• Status 2 <ul style="list-style-type: none"> <li>- Ignition switch is in the ON position</li> <li>- Selector lever P/N position signal: Except P and N positions (0 V)</li> <li>- P range signal and N range signal (CAN): OFF</li> </ul> </li> </ul>
B2605: PNP SW	Inhibit steering lock	500 ms after any of the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> <li>• Ignition switch is in the ON position</li> <li>- Power position: IGN</li> <li>- Selector lever P/N position signal: Except P and N positions (0 V)</li> <li>- Interlock/PNP switch signal (CAN): OFF</li> <li>• Status 2 <ul style="list-style-type: none"> <li>- Ignition switch is in the ON position</li> <li>- Selector lever P/N position signal: P or N position (battery voltage)</li> <li>- PNP switch signal (CAN): ON</li> </ul> </li> </ul>
B2606: S/L RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> <li>• Steering lock relay signal (Request signal)</li> <li>• Steering lock relay signal (Condition signal)</li> </ul>

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

## BCM (BODY CONTROL MODULE)

### < ECU DIAGNOSIS INFORMATION >

Display contents of CONSULT	Fail-safe	Cancellation
B2607: S/L RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> <li>Steering lock relay signal (Request signal)</li> <li>Steering lock relay signal (Condition signal)</li> </ul>
B2608: STARTER RELAY	Inhibit engine cranking	500 ms after the following signal communication status becomes consistent <ul style="list-style-type: none"> <li>Starter motor relay control signal</li> <li>Starter relay status signal (CAN)</li> </ul>
B2609: S/L STATUS	<ul style="list-style-type: none"> <li>Inhibit engine cranking</li> <li>Inhibit steering lock</li> </ul>	When the following steering lock conditions agree <ul style="list-style-type: none"> <li>BCM steering lock control status</li> <li>Steering lock condition No. 1 signal status</li> <li>Steering lock condition No. 2 signal status</li> </ul>
B260A: IGNITION RELAY	Inhibit engine cranking	500 ms after the following conditions are fulfilled <ul style="list-style-type: none"> <li>IGN relay (IPDM E/R) control signal: OFF (Battery voltage)</li> <li>Ignition ON signal (CAN to IPDM E/R): OFF (Request signal)</li> <li>Ignition ON signal (CAN from IPDM E/R): OFF (Condition signal)</li> </ul>
B260F: ENG STATE SIG LOST	Maintains the power supply position attained at the time of DTC detection	When any of the following conditions are fulfilled <ul style="list-style-type: none"> <li>Power position changes to ACC</li> <li>Receives engine status signal (CAN)</li> </ul>
B2612: S/L STATUS	<ul style="list-style-type: none"> <li>Inhibit engine cranking</li> <li>Inhibit steering lock</li> </ul>	When any of the following conditions are fulfilled <ul style="list-style-type: none"> <li>Steering lock unit status signal (CAN) is received normally</li> <li>The BCM steering lock control status matches the steering lock status recognized by the steering lock unit status signal (CAN from IPDM E/R)</li> </ul>
B2617: STARTER RELAY CIRC	Inhibit engine cranking	1 second after the starter motor relay control inside BCM becomes normal
B2618: BCM	Inhibit engine cranking	1 second after the ignition relay (IPDM E/R) control inside BCM becomes normal
B2619: BCM	Inhibit engine cranking	1 second after the steering lock unit power supply output control inside BCM becomes normal
B261E: VEHICLE TYPE	Inhibit engine cranking	BCM initialization
B26E9: S/L STATUS	<ul style="list-style-type: none"> <li>Inhibit engine cranking</li> <li>Inhibit steering lock</li> </ul>	When BCM transmits the LOCK request signal to steering lock unit, and receives LOCK response signal from steering lock unit, the following conditions are fulfilled <ul style="list-style-type: none"> <li>Steering condition No. 1 signal: LOCK (0V)</li> <li>Steering condition No. 2 signal: LOCK (Battery voltage)</li> </ul>

### HIGH FLASHER OPERATION

BCM detects the turn signal lamp circuit status by the current value.

BCM increases the turn signal lamp blinking speed if the bulb or harness open is detected with the turn signal lamp operating.

#### NOTE:

The blinking speed is normal while activating the hazard warning lamp.

### FAIL-SAFE CONTROL BY RAIN SENSOR MALFUNCTION

- BCM judges the rain sensor serial link error by the rain sensor serial link condition and detects the rain sensor malfunction by rain sensor malfunction signal.
- When BCM detects the rain sensor serial link error or the rain sensor malfunction while front wiper AUTO operation, BCM operates a fail-safe control.

#### NOTE:

If rain sensor malfunction is detected when ignition switch is turned OFF ⇒ ON and front wiper switch is INT/AUTO position, BCM operates a fail-safe control.

### REAR WIPER MOTOR PROTECTION

BCM detects the rear wiper stopping position according to the rear wiper stop position signal.

When the rear wiper stop position signal does not change for more than 5 seconds while driving the rear wiper, BCM stops power supply to protect the rear wiper motor.

Condition of cancellation

- More than 1 minute is passed after the rear wiper stop.



## BCM (BODY CONTROL MODULE)

### < ECU DIAGNOSIS INFORMATION >

2. Turn rear wiper switch OFF.
3. Operate the rear wiper switch or rear washer switch.

### DTC Inspection Priority Chart

INFOID:000000005683170

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	DTC
1	B2562: LOW VOLTAGE
2	<ul style="list-style-type: none"><li>• U1000: CAN COMM</li><li>• U1010: CONTROL UNIT(CAN)</li></ul>
3	<ul style="list-style-type: none"><li>• B2190: NATS ANTENNA AMP</li><li>• B2191: DIFFERENCE OF KEY</li><li>• B2192: ID DISCORD BCM-ECM</li><li>• B2193: CHAIN OF BCM-ECM</li><li>• B2195: ANTI SCANNING</li></ul>
4	<ul style="list-style-type: none"><li>• B2013: ID DISCORD BCM-S/L</li><li>• B2014: CHAIN OF S/L-BCM</li><li>• B2553: IGNITION RELAY</li><li>• B2555: STOP LAMP</li><li>• B2556: PUSH-BTN IGN SW</li><li>• B2557: VEHICLE SPEED</li><li>• B2560: STARTER CONT RELAY</li><li>• B2601: SHIFT POSITION</li><li>• B2602: SHIFT POSITION</li><li>• B2603: SHIFT POSI STATUS</li><li>• B2604: PNP SW</li><li>• B2605: PNP SW</li><li>• B2606: S/L RELAY</li><li>• B2607: S/L RELAY</li><li>• B2608: STARTER RELAY</li><li>• B2609: S/L STATUS</li><li>• B260A: IGNITION RELAY</li><li>• B260B: STEERING LOCK UNIT</li><li>• B260C: STEERING LOCK UNIT</li><li>• B260D: STEERING LOCK UNIT</li><li>• B260F: ENG STATE SIG LOST</li><li>• B2612: S/L STATUS</li><li>• B2614: ACC RELAY CIRC</li><li>• B2615: BLOWER RELAY CIRC</li><li>• B2616: IGN RELAY CIRC</li><li>• B2617: STARTER RELAY CIRC</li><li>• B2618: BCM</li><li>• B2619: BCM</li><li>• B261A: PUSH-BTN IGN SW</li><li>• B261E: VEHICLE TYPE</li><li>• B26E9: S/L STATUS</li><li>• B26EA: KEY REGISTRATION</li><li>• C1729: VHCL SPEED SIG ERR</li><li>• U0415: VEHICLE SPEED SIG</li></ul>

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Priority	DTC
5	<ul style="list-style-type: none"> <li>• C1704: LOW PRESSURE FL</li> <li>• C1705: LOW PRESSURE FR</li> <li>• C1706: LOW PRESSURE RR</li> <li>• C1707: LOW PRESSURE RL</li> <li>• C1708: [NO DATA] FL</li> <li>• C1709: [NO DATA] FR</li> <li>• C1710: [NO DATA] RR</li> <li>• C1711: [NO DATA] RL</li> <li>• C1716: [PRESSDATA ERR] FL</li> <li>• C1717: [PRESSDATA ERR] FR</li> <li>• C1718: [PRESSDATA ERR] RR</li> <li>• C1719: [PRESSDATA ERR] RL</li> <li>• C1734: CONTROL UNIT</li> </ul>
6	<ul style="list-style-type: none"> <li>• B2622: INSIDE ANTENNA</li> <li>• B2623: INSIDE ANTENNA</li> </ul>

## DTC Index

INFOID:000000005683171

### NOTE:

The details of time display are as follows.

- CRNT: A malfunction is detected now.
- PAST: A malfunction was detected in the past.

IGN counter is displayed on Freeze Frame Data. For details of Freeze Frame Data, refer to [WW-17. "COMMON ITEM : CONSULT-III Function \(BCM - COMMON ITEM\)".](#)

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
No DTC is detected. further testing may be required.	—	—	—	—	—
U1000: CAN COMM	—	—	—	—	<a href="#">BCS-38</a>
U1010: CONTROL UNIT(CAN)	—	—	—	—	<a href="#">BCS-39</a>
U0415: VEHICLE SPEED SIG	—	—	—	—	<a href="#">BCS-40</a>
B2013: ID DISCORD BCM-S/L*	×	×	—	—	<a href="#">SEC-51</a>
B2014: CHAIN OF S/L-BCM*	×	×	—	—	<a href="#">SEC-52</a>
B2190: NATS ANTENNA AMP	×	—	—	—	<a href="#">SEC-43</a>
B2191: DIFFERENCE OF KEY	×	—	—	—	<a href="#">SEC-46</a>
B2192: ID DISCORD BCM-ECM	×	—	—	—	<a href="#">SEC-47</a>
B2193: CHAIN OF BCM-ECM	×	—	—	—	<a href="#">SEC-49</a>
B2195: ANTI SCANNING	×	—	—	—	<a href="#">SEC-50</a>
B2553: IGNITION RELAY	—	×	—	—	<a href="#">PCS-48</a>
B2555: STOP LAMP	—	×	—	—	<a href="#">SEC-55</a>
B2556: PUSH-BTN IGN SW	—	×	×	—	<a href="#">SEC-57</a>
B2557: VEHICLE SPEED	×	×	×	—	<a href="#">SEC-59</a>
B2560: STARTER CONT RELAY	×	×	×	—	<a href="#">SEC-60</a>
B2562: LOW VOLTAGE	—	×	—	—	<a href="#">BCS-41</a>
B2601: SHIFT POSITION	×	×	×	—	<a href="#">SEC-61</a>
B2602: SHIFT POSITION	×	×	×	—	<a href="#">SEC-64</a>
B2603: SHIFT POSI STATUS	×	×	×	—	<a href="#">SEC-66</a>
B2604: PNP SW	×	×	×	—	<a href="#">SEC-69</a>

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
B2605: PNP SW	×	×	×	—	<a href="#">SEC-71</a>
B2606: S/L RELAY*	×	×	×	—	<a href="#">SEC-73</a>
B2607: S/L RELAY*	×	×	×	—	<a href="#">SEC-74</a>
B2608: STARTER RELAY	×	×	×	—	<a href="#">SEC-76</a>
B2609: S/L STATUS*	×	×	×	—	<a href="#">SEC-78</a>
B260A: IGNITION RELAY	×	×	×	—	<a href="#">PCS-50</a>
B260B: STEERING LOCK UNIT*	—	×	×	—	<a href="#">SEC-82</a>
B260C: STEERING LOCK UNIT*	—	×	×	—	<a href="#">SEC-83</a>
B260D: STEERING LOCK UNIT*	—	×	×	—	<a href="#">SEC-84</a>
B260F: ENG STATE SIG LOST	×	×	×	—	<a href="#">SEC-85</a>
B2612: S/L STATUS*	×	×	×	—	<a href="#">SEC-88</a>
B2614: ACC RELAY CIRC	—	×	×	—	<a href="#">PCS-52</a>
B2615: BLOWER RELAY CIRC	—	×	×	—	<a href="#">PCS-55</a>
B2616: IGN RELAY CIRC	—	×	×	—	<a href="#">PCS-58</a>
B2617: STARTER RELAY CIRC	×	×	×	—	<a href="#">SEC-92</a>
B2618: BCM	×	×	×	—	<a href="#">PCS-61</a>
B2619: BCM*	×	×	×	—	<a href="#">SEC-94</a>
B261A: PUSH-BTN IGN SW	—	×	×	—	<a href="#">SEC-95</a>
B261E: VEHICLE TYPE	×	×	× (Turn ON for 15 seconds)	—	<a href="#">SEC-98</a>
B2622: INSIDE ANTENNA	—	×	—	—	<a href="#">DLK-91</a>
B2623: INSIDE ANTENNA	—	×	—	—	<a href="#">DLK-93</a>
B26E9: S/L STATUS*	×	×	× (Turn ON for 15 seconds)	—	<a href="#">SEC-86</a>
B26EA: KEY REGISTRATION	—	×	× (Turn ON for 15 seconds)	—	<a href="#">SEC-87</a>
C1704: LOW PRESSURE FL	—	—	—	×	<a href="#">WT-25</a>
C1705: LOW PRESSURE FR	—	—	—	×	
C1706: LOW PRESSURE RR	—	—	—	×	
C1707: LOW PRESSURE RL	—	—	—	×	
C1708: [NO DATA] FL	—	—	—	×	<a href="#">WT-27</a>
C1709: [NO DATA] FR	—	—	—	×	
C1710: [NO DATA] RR	—	—	—	×	
C1711: [NO DATA] RL	—	—	—	×	
C1716: [PRESSDATA ERR] FL	—	—	—	×	<a href="#">WT-30</a>
C1717: [PRESSDATA ERR] FR	—	—	—	×	
C1718: [PRESSDATA ERR] RR	—	—	—	×	
C1719: [PRESSDATA ERR] RL	—	—	—	×	
C1729: VHCL SPEED SIG ERR	—	—	—	×	<a href="#">WT-32</a>
C1734: CONTROL UNIT	—	—	—	×	<a href="#">WT-34</a>

### NOTE:

\*: For models without steering lock unit this DTC is not applied.

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

## IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Reference Value

INFOID:000000005683172

VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Condition		Value/Status
MOTOR FAN REQ	Engine idle speed	Changes depending on engine coolant temperature, air conditioner operation status, vehicle speed, etc.	1/2/3/4
AC COMP REQ	Engine running	A/C switch OFF	Off
		A/C switch ON (Compressor is operating)	On
TAIL&CLR REQ	Lighting switch OFF		Off
	Lighting switch 1ST, 2ND, HI or AUTO (Light is illuminated)		On
HL LO REQ	Lighting switch OFF		Off
	Lighting switch 2ND HI or AUTO (Light is illuminated)		On
HL HI REQ	Lighting switch OFF		Off
	Lighting switch HI		On
FR FOG REQ	Lighting switch 2ND or AUTO (Light is illuminated)	Front fog lamp switch OFF	Off
		<ul style="list-style-type: none"> <li>Front fog lamp switch ON</li> <li>Daytime running light activated (Only for Canada)</li> </ul>	On
FR WIP REQ	Ignition switch ON	Front wiper switch OFF	Stop
		Front wiper switch INT	1LOW
		Front wiper switch LO	Low
		Front wiper switch HI	Hi
WIP AUTO STOP	Ignition switch ON	Front wiper stop position	STOP P
		Any position other than front wiper stop position	ACT P
WIP PROT	Ignition switch ON	Front wiper operates normally	Off
		Front wiper stops at fail-safe operation	BLOCK
IGN RLY1 -REQ	Ignition switch OFF or ACC		Off
	Ignition switch ON		On
IGN RLY	Ignition switch OFF or ACC		Off
	Ignition switch ON		On
PUSH SW	Release the push-button ignition switch		Off
	Press the push-button ignition switch		On
INTER/NP SW	Ignition switch ON	Selector lever in any position other than P or N	Off
		Selector lever in P or N position	On
ST RLY CONT	Ignition switch ON		Off
	At engine cranking		On
IHBT RLY -REQ	Ignition switch ON		Off
	At engine cranking		On

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition		Value/Status
ST/INHI RLY	Ignition switch ON		Off
	At engine cranking		INHI ON → ST ON
	The status of starter relay or starter control relay cannot be recognized by the battery voltage malfunction, etc. when the starter relay is ON and the starter control relay is OFF		UNKWN
DETENT SW	Ignition switch ON	<ul style="list-style-type: none"> <li>Press the selector button with selector lever in P position</li> <li>Selector lever in any position other than P</li> </ul>	Off
	Release the selector button with selector lever in P position		On
S/L RLY -REQ <b>NOTE:</b> For models without steering lock unit this item is not monitored.	None of the conditions below are present		Off
	<ul style="list-style-type: none"> <li>Open the driver door after the ignition switch is turned OFF (for a few seconds)</li> <li>Press the push-button ignition switch when the steering lock is activated</li> </ul>		On
S/L STATE <b>NOTE:</b> For models without steering lock unit this item is not monitored.	Steering lock is activated		LOCK
	Steering lock is deactivated		UNLOCK
	[DTC: B210A] is detected		UNKWN
DTRL REQ	<b>NOTE:</b> The item is indicated, but not monitored.		Off
OIL P SW	Ignition switch OFF, ACC or engine running		Open
	Ignition switch ON		Close
HOOD SW	<b>NOTE:</b> The item is indicated, but not monitored.		Off
HL WASHER REQ	<b>NOTE:</b> The item is indicated, but not monitored.		Off
THFT HRN REQ	Not operating		Off
	<ul style="list-style-type: none"> <li>Panic alarm is activated</li> <li>Horn is activated with VEHICLE SECURITY (THEFT WARNING) SYSTEM</li> </ul>		On
HORN CHIRP	Not operating		Off
	Door locking with Intelligent Key (horn chirp mode)		On
CRNRNG LMP REQ	<b>NOTE:</b> The item is indicated, but not monitored.		Off

A

B

C

D

E

F

G

H

I

J

K

WW

M

N


O

P

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

## TERMINAL LAYOUT




## PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
1 (R)	Ground	Battery power supply	Input	Ignition switch OFF		Battery voltage
2 (L)	Ground	Battery power supply	Input	Ignition switch OFF		Battery voltage
4 (LG)	Ground	Front wiper LO	Output	Ignition switch OFF	Front wiper switch OFF	0 V
				Ignition switch ON	Front wiper switch LO	Battery voltage
5 (Y)	Ground	Front wiper HI	Output	Ignition switch OFF	Front wiper switch OFF	0 V
				Ignition switch ON	Front wiper switch HI	Battery voltage
7 (GR)	Ground	Tail, license plate lamps & illuminations	Output	Ignition switch OFF	Lighting switch OFF	0 V
				Ignition switch ON	Lighting switch 1ST	Battery voltage
10 (BR)	Ground	ECM relay power supply	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)		0 V
				<ul style="list-style-type: none"> <li>Ignition switch ON</li> <li>Ignition switch OFF (For a few seconds after turning ignition switch OFF)</li> </ul>		Battery voltage

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
11*2 (P)	Ground	Steering lock unit power supply	Output	Ignition switch OFF	A few seconds after opening the driver door	Battery voltage
				Ignition switch LOCK	Press the push-button ignition switch	Battery voltage
				Ignition switch ACC or ON		0 V
12 (B)	Ground	Ground	—	Ignition switch ON		0 V
13 (SB)	Ground	Fuel pump power supply	Output	Approximately 1 second or more after turning the ignition switch ON		0 V
				<ul style="list-style-type: none"> <li>Approximately 1 second after turning the ignition switch ON</li> <li>Engine running</li> </ul>		Battery voltage
15 (W)	Ground	Ignition relay power supply	Output	Ignition switch OFF		0 V
				Ignition switch ON		Battery voltage
16 (L/Y)	Ground	Front wiper auto stop	Input	Ignition switch ON	Front wiper stop position	0 V
					Any position other than front wiper stop position	Battery voltage
19 (Y)	Ground	Ignition relay power supply	Output	Ignition switch OFF		0 V
				Ignition switch ON		Battery voltage
20 (L)	Ground	Ambient sensor ground	Output	Ignition switch ON		0 V
21 (O)	Ground	Ambient sensor	Input	Ignition switch ON <b>NOTE:</b> Changes depending to ambient temperature		
22 (SB)	Ground	Refrigerant pressure sensor ground	Output	Engine running	<ul style="list-style-type: none"> <li>Warm-up condition</li> <li>Idle speed</li> </ul>	0 V
23 (GR)	Ground	Refrigerant pressure sensor	Output	Engine running	<ul style="list-style-type: none"> <li>Warm-up condition</li> <li>Both A/C switch and blower fan motor switch ON (Compressor operates)</li> </ul>	1.0 - 4.0 V
24 (G)	Ground	Refrigerant pressure sensor power supply	Input	Ignition switch OFF		0 V
				Ignition switch ON		5.0 V
25 (GR)	Ground	Ignition relay power supply	Output	Ignition switch OFF		0 V
				Ignition switch ON		Battery voltage
26*1 (Y)	Ground	Ignition relay power supply	Output	Ignition switch OFF		0 V
				Ignition switch ON		Battery voltage
27 (W)	Ground	Ignition relay monitor	Input	Ignition switch OFF or ACC		Battery voltage
				Ignition switch ON		0 V
28 (SB)	Ground	Push-button ignition switch	Input	Press the push-button ignition switch		0 V
				Release the push-button ignition switch		Battery voltage

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
30 (BR)	Ground	Starter relay control	Input	Ignition switch ON	Selector lever in any position other than P or N	0 V
					Selector lever P or N	Battery voltage
32*2 (V)	Ground	Steering lock unit condition-1	Input	Steering lock is activated		0 V
				Steering lock is deactivated		Battery voltage
33*2 (G)	Ground	Steering lock unit condition-2	Input	Steering lock is activated		Battery voltage
				Steering lock is deactivated		0 V
34 (O)	Ground	Cooling fan relay-3 control	Input	Cooling fan stopped		Battery voltage
				Cooling fan at HI operation		0 V
35 (P)	Ground	Cooling fan relay-1 power supply	Input	Cooling fan stopped		Battery voltage
				Cooling fan at LO operation		6.0 V
36 (G)	Ground	Battery power supply	Input	Ignition switch OFF		Battery voltage
38 (GR)	Ground	Cooling fan relay-1 power supply	Output	Cooling fan not operating		0 V
				Cooling fan at LO operation		6.0 V
39 (P)	—	CAN-L	Input/ Output	—		—
40 (L)	—	CAN-H	Input/ Output	—		—
41 (B)	Ground	Ground	—	Ignition switch ON		0 V
42 (SB)	Ground	Cooling fan relay-2 control	Input	Cooling fan stopped		Battery voltage
				<ul style="list-style-type: none"> <li>Cooling fan MID operating</li> <li>Cooling fan HI operating</li> </ul>		0 V
43 (Y)	Ground	CVT shift selector (Detention switch)	Input	Ignition switch ON	Press the selector button (selector lever P)	Battery voltage
					<ul style="list-style-type: none"> <li>Selector lever in any position other than P</li> <li>Release the selector button (selector lever P)</li> </ul>	0 V
44 (W)	Ground	Horn relay control	Input	The horn is deactivated		Battery voltage
				The horn is activated		0 V
45 (O)	Ground	Horn switch	Input	The horn is deactivated		Battery voltage
				The horn is activated		0 V
46 (BR)	Ground	Starter relay control	Input	Ignition switch ON	Selector lever in any position other than P or N	0 V
					Selector lever P or N	Battery voltage
48 (W)	Ground	A/C relay power supply	Output	Engine running	A/C switch OFF	0 V
					A/C switch ON (A/C compressor is operating)	Battery voltage
49 (R/B)	Ground	ECM relay power supply	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)		0 V
				<ul style="list-style-type: none"> <li>Ignition switch ON</li> <li>Ignition switch OFF (For a few seconds after turning ignition switch OFF)</li> </ul>		Battery voltage



# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
51 (LG)	Ground	Ignition relay power supply	Output	Ignition switch OFF		0 V
				Ignition switch ON		Battery voltage
52 (Y/G)	Ground	Ignition relay power supply	Output	Ignition switch OFF		0 V
				Ignition switch ON		Battery voltage
53 (R/W)	Ground	ECM relay power supply	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)		0 V
				• Ignition switch ON • Ignition switch OFF (For a few seconds after turning igni- tion switch OFF)		Battery voltage
54 (G/W)	Ground	Throttle control motor re- lay power supply	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)		0 V
				• Ignition switch ON • Ignition switch OFF (For a few seconds after turning igni- tion switch OFF)		Battery voltage
55 (W/L)	Ground	ECM power supply	Output	Ignition switch OFF		Battery voltage
56 (R/Y)	Ground	Ignition relay power supply	Output	Ignition switch OFF		0 V
				Ignition switch ON		Battery voltage
57 (O)	Ground	Ignition relay power supply	Output	Ignition switch OFF		0 V
				Ignition switch ON		Battery voltage
58 (Y)	Ground	Ignition relay power supply	Output	Ignition switch OFF		0 V
				Ignition switch ON		Battery voltage
69 (W/B)	Ground	ECM relay control	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)		Battery voltage
				• Ignition switch ON • Ignition switch OFF (For a few seconds after turning igni- tion switch OFF)		0 - 1.5 V
70 (O)	Ground	Throttle control motor re- lay control	Output	Ignition switch ON → OFF		0 - 1.0 V ↓ Battery voltage ↓ 0 V
				Ignition switch ON		0 - 1.0 V
72 (R/B)	Ground	Starter relay control	Input	Ignition switch ON	Selector lever in any posi- tion other than P or N	0 V
					Selector lever P or N	Battery voltage
75 (LG)	Ground	Oil pressure switch	Input	Ignition switch ON	Engine stopped	0 V
					Engine running	Battery voltage

A

B

C

D

E

F

G

H

I

J

K

WW

M




N

O

P


# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
76 (SB)	Ground	Power generation command signal	Output	Ignition switch ON		 JPMIA0001GB 6.3 V
				40% is set on "ACTIVE TEST", "ALTERNATOR DUTY" of "ENGINE"		 JPMIA0002GB 3.8 V
				80% is set on "ACTIVE TEST", "ALTERNATOR DUTY" of "ENGINE"		 JPMIA0003GB 1.4 V
77 (GR)	Ground	Fuel pump relay control	Output	<ul style="list-style-type: none"> <li>Approximately 1 second after turning the ignition switch ON</li> <li>Engine running</li> </ul>		0 - 1.5 V
				Approximately 1 second or more after turning the ignition switch ON		Battery voltage
80 (B)	Ground	Starter motor	Output	At engine cranking		Battery voltage
83 (Y)	Ground	Headlamp LO (RH)	Output	Ignition switch ON	Lighting switch OFF	0 V
					Lighting switch 2ND	Battery voltage
84 (L)	Ground	Headlamp LO (LH)	Output	Ignition switch ON	Lighting switch OFF	0 V
					Lighting switch 2ND	Battery voltage
86 (SB)	Ground	Front fog lamp (RH)	Output	Lighting switch 2ND	Front fog lamp switch OFF	0 V
					<ul style="list-style-type: none"> <li>Front fog lamp switch ON</li> <li>Daytime running light activated (Only for Canada)</li> </ul>	Battery voltage
87 (GR)	Ground	Front fog lamp (LH)	Output	Lighting switch 2ND	Front fog lamp switch OFF	0 V
					<ul style="list-style-type: none"> <li>Front fog lamp switch ON</li> <li>Daytime running light activated (Only for Canada)</li> </ul>	Battery voltage
88 (W)	Ground	Washer pump power supply	Output	Ignition switch ON		Battery voltage

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
89 (L)	Ground	Headlamp HI (RH)	Output	Ignition switch ON	Lighting switch OFF	0 V
					<ul style="list-style-type: none"> <li>Lighting switch HI</li> <li>Lighting switch PASS</li> </ul>	Battery voltage
90 (G)	Ground	Headlamp HI (LH)	Output	Ignition switch ON	Lighting switch OFF	0 V
					<ul style="list-style-type: none"> <li>Lighting switch HI</li> <li>Lighting switch PASS</li> </ul>	Battery voltage
91 (R)	Ground	Parking lamp (RH)	Output	Ignition switch ON	Lighting switch OFF	0 V
					Lighting switch 1ST	Battery voltage
92 (LG)	Ground	Parking lamp (LH)	Output	Ignition switch ON	Lighting switch OFF	0 V
					Lighting switch 1ST	Battery voltage
99 (BR)	Ground	Ambient sensor ground	Input	Ignition switch ON		0 V
100 (SB)	Ground	Ambient sensor	Output	Ignition switch ON <b>NOTE:</b> Changes depending to ambient temperature		 <p>JSNIA0014GB</p>
101 (L)	Ground	Refrigerant pressure sensor ground	Input	Engine running	<ul style="list-style-type: none"> <li>Warm-up condition</li> <li>Idle speed</li> </ul>	0 V
102 (B)	Ground	Refrigerant pressure sensor	Input	Engine running	<ul style="list-style-type: none"> <li>Warm-up condition</li> <li>Both A/C switch and blower fan motor switch ON (Compressor operates)</li> </ul>	1.0 - 4.0 V
103 (P)	Ground	Refrigerant pressure sensor power supply	Output	Ignition switch OFF		0 V
				Ignition switch ON		5.0 V

\*1: AWD models only


\*2: Only for models with steering lock unit

WW

## < ECU DIAGNOSIS INFORMATION >

## Wiring Diagram - IPDM E/R -

INFOID:0000000005683173




JCMWM4888GB


2009/08/07

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >



WW



## < ECU DIAGNOSIS INFORMATION >

72	R/B	-
75	LG	-
76	SB	-
77	GR	-
80	B	-

90	G	-
----	---	---



98	97	96	95	94	93	92	91
106	105	104	103	102	101	100	99

Terminal No.	Color of Wire	Signal Name [Specification]
91	R	+
92	LG	+
99	BR	+
100	SB	+
101	L	+
102	B	+
103	P	+

Connector No.	F12
Connector Name	FROM E/R INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	TH20FW-CS12-M4

53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82				
47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80

Temporal Index	Color of Wire	Signal Name (Specification)
46	W	-
47	R/B	-
48	LG	-
49	LG	-
50	Y/G	-
51	R/W	-
52	R/W	-
53	R/W	-
54	G/W	-
55	W/L	-
56	R/G	-
57	O	-
58	-	-
59	-	-
60	W/B	-

PDM E/R (INTEL IIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

32	V	-
33	G	-
34	O	-
35	P	-
36	G	-
38	GR	-

Connector No.	E11
Connector Name	SPDM E/P (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	TH08FW-NH

42	41	40	39
46	45	44	43

	IT1007-PT-INT1
---	----------------

Terminal No.	Color of Wire	Signal Name (Specification)
39	P	-
40	L	-
41	B	-
42	SB	-
43	Y	-
44	W	-
45	O	-
46	BR	-

Connector No.	E345
Connector Name	SPDM E/P (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	NS08FW-CS

85	<input type="text"/>	84	83
90	89	88	87
		86	

Terminal No.	Color of Wire	Signal Name [Specification]
83	Y	-
84	L	-
86	SB	-
87	GR	-
88	W	-
89		

Connector No.	E9
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	L02FB-MC

CT-2

Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	L	-

Connector No.	E10
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	TH20FW-CS12-M4-1V

9	10	11	12	13	14	25	26	27	28	29	30	31	32	33	34	37	38
3	4	5	6	7	8	15	16	17	18	19	20	21	22	23	24	35	36

Terminal No.	Color of Wire	Signal Name (Specification)
4	LG	-
5	Y	-
7	GR	-
10	BR	-
11	P	-
12	B	-
13	SB	-
15	W	-
16	L/Y	-
19	Y	-
20	L	-
21	O	-
22	SB	-
23	GR	-
24	G	-
25	GR	-
26	Y	-
27	W	-
28	SB	-

INFOID:0000000005683174

## CAN COMMUNICATION CONTROL

### If No CAN Communication Is Available With ECM

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
WW  
M  
N  
O  
P

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

Control part	Fail-safe operation
Cooling fan	<ul style="list-style-type: none"> <li>• Turns ON the cooling fan relay-2 and the cooling fan relay-3 when ignition switch is turned ON (Cooling fan operates at HI)</li> <li>• Turns OFF the cooling fan relay-1, the cooling fan relay-2 and the cooling fan relay-3 when the ignition switch is turned OFF (Cooling fan does not operate)</li> </ul>
A/C compressor	A/C relay OFF
Alternator	Outputs the power generation command signal (PWM signal) 0%

If No CAN Communication Is Available With BCM

Control part	Fail-safe operation
Headlamp	<ul style="list-style-type: none"> <li>• Turns ON the headlamp low relay when the ignition switch is turned ON</li> <li>• Turns OFF the headlamp low relay when the ignition switch is turned OFF</li> <li>• Headlamp high relay OFF</li> </ul>
<ul style="list-style-type: none"> <li>• Parking lamps</li> <li>• License plate lamps</li> <li>• Side marker lamps</li> <li>• Illuminations</li> <li>• Tail lamps</li> </ul>	<ul style="list-style-type: none"> <li>• Turns ON the tail lamp relay when the ignition switch is turned ON</li> <li>• Turns OFF the tail lamp relay when the ignition switch is turned OFF</li> </ul>
Front wiper	<ul style="list-style-type: none"> <li>• The status just before activation of fail-safe control is maintained until the ignition switch is turned OFF while the front wiper is operating at LO or HI speed.</li> <li>• The wiper is operated at LO speed until the ignition switch is turned OFF if the fail-safe control is activated while the front wiper is set in the INT/AUTO mode and the front wiper motor is operating.</li> </ul>
Front fog lamps	Front fog lamp relay OFF
Horn	Horn OFF
Ignition relay	The status just before activation of fail-safe is maintained.
Starter motor	Starter control relay OFF
Steering lock unit*	Steering lock relay OFF

\*: Only for models with steering lock unit.

## IGNITION RELAY MALFUNCTION DETECTION FUNCTION

- IPDM E/R monitors the voltage at the contact circuit and excitation coil circuit of the ignition relay inside it.
- IPDM E/R judges the ignition relay error if the voltage differs between the contact circuit and the excitation coil circuit.
- If the ignition relay cannot turn OFF due to contact seizure, it activates the tail lamp relay for 10 minutes to alert the user to the ignition relay malfunction when the ignition switch is turned OFF.

Voltage judgment		IPDM E/R judgment	Operation
Ignition relay contact side	Ignition relay excitation coil side		
ON	ON	Ignition relay ON normal	—
OFF	OFF	Ignition relay OFF normal	—
ON	OFF	Ignition relay ON stuck	<ul style="list-style-type: none"> <li>• Detects DTC "B2098: IGN RELAY ON"</li> <li>• Turns ON the tail lamp relay for 10 minutes</li> </ul>
OFF	ON	Ignition relay OFF stuck	Detects DTC "B2099: IGN RELAY OFF"

## FRONT WIPER CONTROL

IPDM E/R detects front wiper stop position by a front wiper auto stop signal.

When a front wiper stop position signal is in the conditions listed below, IPDM E/R stops power supply to wiper after repeating a front wiper 10 seconds activation and 20 seconds stop five times.



# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

Ignition switch	Front wiper switch	Front wiper stop position signal
ON	OFF	The front wiper stop position signal (stop position) cannot be input for 10 seconds.
	ON	The front wiper auto stop signal does not change for 10 seconds.

### NOTE:

This operation status can be confirmed on the IPDM E/R “Data Monitor” that displays “BLOCK” for the item “WIP PROT” while the wiper is stopped.

### STARTER MOTOR PROTECTION FUNCTION

IPDM E/R turns OFF the starter control relay to protect the starter motor when the starter control relay remains active for 90 seconds.

### DTC Index

INFOID:0000000005683175

### NOTE:

- The details of time display are as follows.
  - CRNT: A malfunction is detected now.
  - PAST: A malfunction was detected in the past.
- IGN counter is displayed on FFD (Freeze Frame data).
  - The number is 0 when is detected now.
  - The number increases like 1 → 2 ... 38 → 39 after returning to the normal condition whenever IGN OFF → ON.
  - The number is fixed to 39 until the self-diagnosis results are erased if it is over 39.

×: Applicable

CONSULT display	Fail-safe	Refer to
No DTC is detected. further testing may be required.	—	—
U1000: CAN COMM CIRCUIT	×	<a href="#">PCS-15</a>
B2098: IGN RELAY ON	×	<a href="#">PCS-16</a>
B2099: IGN RELAY OFF	—	<a href="#">PCS-17</a>
B2108: STRG LCK RELAY ON *	—	<a href="#">SEC-99</a>
B2109: STRG LCK RELAY OFF *	—	<a href="#">SEC-100</a>
B210A: STRG LCK STATE SW *	—	<a href="#">SEC-101</a>
B210B: START CONT RLY ON	—	<a href="#">SEC-105</a>
B210C: START CONT RLY OFF	—	<a href="#">SEC-106</a>
B210D: STARTER RELAY ON	—	<a href="#">SEC-107</a>
B210E: STARTER RELAY OFF	—	<a href="#">SEC-108</a>
B210F: INTRLCK/PNP SW ON	—	<a href="#">SEC-110</a>
B2110: INTRLCK/PNP SW OFF	—	<a href="#">SEC-112</a>

\*: For models without steering lock unit this DTC is not applied.

# WIPER AND WASHER SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

## SYMPTOM DIAGNOSIS

### WIPER AND WASHER SYSTEM SYMPTOMS WITH RAIN SENSOR

#### WITH RAIN SENSOR : Symptom Table

INFOID:000000005516040

#### CAUTION:

Perform the self-diagnosis with CONSULT-III before performing the diagnosis by symptom. Perform the diagnosis by DTC if DTC is detected.

Symptom	Probable malfunction location	Inspection item
Front wiper does not operate.	HI only	<ul style="list-style-type: none"> <li>Combination switch</li> <li>Harness between combination switch and BCM</li> <li>BCM</li> </ul> Combination switch Refer to <a href="#">BCS-92, "Symptom Table"</a> .
		<ul style="list-style-type: none"> <li>IPDM E/R</li> <li>Harness between IPDM E/R and front wiper motor</li> <li>Front wiper motor</li> </ul> Front wiper motor (HI) circuit Refer to <a href="#">WW-30, "Component Function Check"</a> .
		Front wiper request signal <ul style="list-style-type: none"> <li>BCM</li> <li>IPDM E/R</li> </ul> IPDM E/R DATA MONITOR "FR WIP REQ"
	LO and INT/AUTO	<ul style="list-style-type: none"> <li>Combination switch</li> <li>Harness between combination switch and BCM</li> <li>BCM</li> </ul> Combination switch Refer to <a href="#">BCS-92, "Symptom Table"</a> .
		<ul style="list-style-type: none"> <li>IPDM E/R</li> <li>Harness between IPDM E/R and front wiper motor</li> <li>Front wiper motor</li> </ul> Front wiper motor (LO) circuit Refer to <a href="#">WW-28, "Component Function Check"</a> .
		Front wiper request signal <ul style="list-style-type: none"> <li>BCM</li> <li>IPDM E/R</li> </ul> IPDM E/R DATA MONITOR "FR WIP REQ"
	INT/AUTO only (Auto operation)	<ul style="list-style-type: none"> <li>Combination switch</li> <li>Harness between combination switch and BCM</li> <li>BCM</li> </ul> Combination switch Refer to <a href="#">BCS-92, "Symptom Table"</a> .
		<ul style="list-style-type: none"> <li>Rain sensor</li> <li>Harness between rain sensor and BCM</li> <li>BCM</li> </ul> Rain sensor Refer to <a href="#">WW-36, "Component Function Check"</a> .
	HI, LO and INT/AUTO	SYMPTOM DIAGNOSIS "FRONT WIPER DOES NOT OPERATE" Refer to <a href="#">WW-120, "Diagnosis Procedure"</a> .

# WIPER AND WASHER SYSTEM SYMPTOMS

## < SYMPTOM DIAGNOSIS >

Symptom		Probable malfunction location	Inspection item
Front wiper does not stop.	HI only	<ul style="list-style-type: none"> <li>Combination switch</li> <li>BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-92, "Symptom Table"</a> .
		Front wiper request signal <ul style="list-style-type: none"> <li>BCM</li> <li>IPDM E/R</li> </ul>	IPDM E/R DATA MONITOR "FR WIP REQ"
		IPDM E/R	—
	LO only	<ul style="list-style-type: none"> <li>Combination switch</li> <li>BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-92, "Symptom Table"</a> .
		Front wiper request signal <ul style="list-style-type: none"> <li>BCM</li> <li>IPDM E/R</li> </ul>	IPDM E/R DATA MONITOR "FR WIP REQ"
		IPDM E/R	—
	INT/AUTO only (Auto operation)	<ul style="list-style-type: none"> <li>Combination switch</li> <li>BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-92, "Symptom Table"</a> .
		<ul style="list-style-type: none"> <li>Rain sensor</li> <li>Harness between rain sensor and BCM</li> <li>BCM</li> </ul>	Rain sensor Refer to <a href="#">WW-36, "Component Function Check"</a> .
Front wiper does not operate normally.	Sensitivity adjustment cannot be performed.	<ul style="list-style-type: none"> <li>Combination switch</li> <li>Harness between combination switch and BCM</li> <li>BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-92, "Symptom Table"</a> .
		BCM	—
	Wiper is not linked to the washer operation.	<ul style="list-style-type: none"> <li>Combination switch</li> <li>Harness between combination switch and BCM</li> <li>BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-92, "Symptom Table"</a> .
		BCM	—
	Does not return to stop position. [Repeatedly operates for 10 seconds and then stops for 20 seconds. After that, it stops the operation. (Fail-safe)]	<ul style="list-style-type: none"> <li>IPDM E/R</li> <li>Harness between IPDM E/R and front wiper motor</li> <li>Front wiper motor</li> </ul>	Front wiper auto stop signal circuit Refer to <a href="#">WW-32, "Component Function Check"</a> .
Rear wiper does not operate.	ON only	<ul style="list-style-type: none"> <li>Combination switch</li> <li>Harness between combination switch and BCM</li> <li>BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-92, "Symptom Table"</a> .
	INT only	<ul style="list-style-type: none"> <li>Combination switch</li> <li>Harness between combination switch and BCM</li> <li>BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-92, "Symptom Table"</a> .
	ON and INT	<ul style="list-style-type: none"> <li>Combination switch</li> <li>Harness between combination switch and BCM</li> <li>BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-92, "Symptom Table"</a> .
		<ul style="list-style-type: none"> <li>BCM</li> <li>Harness between rear wiper motor and BCM</li> <li>Harness between rear wiper motor and ground</li> <li>Rear wiper motor</li> </ul>	Combination switch Refer to <a href="#">BCS-92, "Symptom Table"</a> .
Rear wiper does not stop.	ON only	<ul style="list-style-type: none"> <li>Combination switch</li> <li>BCM</li> </ul>	Rear wiper motor circuit Refer to <a href="#">WW-38, "Component Function Check"</a> .
	INT only	<ul style="list-style-type: none"> <li>Combination switch</li> <li>BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-92, "Symptom Table"</a> .

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

# WIPER AND WASHER SYSTEM SYMPTOMS

## < SYMPTOM DIAGNOSIS >

Symptom		Probable malfunction location	Inspection item
Rear wiper does not operate normally.	Wiper is not linked to the washer operation.	<ul style="list-style-type: none"> <li>Combination switch</li> <li>Harness between rear wiper motor and BCM</li> <li>BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-92, "Symptom Table"</a> .
		BCM	—
	Rear wiper does not return to the stop position. [Stops after a five-second operation. (Fail-safe)]	<ul style="list-style-type: none"> <li>BCM</li> <li>Harness between rear wiper motor and BCM</li> <li>Rear wiper motor</li> </ul>	Rear wiper auto stop signal circuit Refer to <a href="#">WW-40, "Component Function Check"</a> .

## WITHOUT RAIN SENSOR

### WITHOUT RAIN SENSOR : Symptom Table

INFOID:000000005516041

#### CAUTION:

Perform the self-diagnosis with CONSULT-III before performing the diagnosis by symptom. Perform the diagnosis by DTC if DTC is detected.

Symptom		Probable malfunction location	Inspection item
Front wiper does not operate.	HI only	<ul style="list-style-type: none"> <li>Combination switch</li> <li>Harness between combination switch and BCM</li> <li>BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-92, "Symptom Table"</a> .
		<ul style="list-style-type: none"> <li>IPDM E/R</li> <li>Harness between IPDM E/R and front wiper motor</li> <li>Front wiper motor</li> </ul>	Front wiper motor (HI) circuit Refer to <a href="#">WW-30, "Component Function Check"</a> .
		Front wiper request signal <ul style="list-style-type: none"> <li>BCM</li> <li>IPDM E/R</li> </ul>	IPDM E/R DATA MONITOR "FR WIP REQ"
	LO and INT	<ul style="list-style-type: none"> <li>Combination switch</li> <li>Harness between combination switch and BCM</li> <li>BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-92, "Symptom Table"</a> .
		<ul style="list-style-type: none"> <li>IPDM E/R</li> <li>Harness between IPDM E/R and front wiper motor</li> <li>Front wiper motor</li> </ul>	Front wiper motor (LO) circuit Refer to <a href="#">WW-28, "Component Function Check"</a> .
		Front wiper request signal <ul style="list-style-type: none"> <li>BCM</li> <li>IPDM E/R</li> </ul>	IPDM E/R DATA MONITOR "FR WIP REQ"
	INT only	<ul style="list-style-type: none"> <li>Combination switch</li> <li>Harness between combination switch and BCM</li> <li>BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-92, "Symptom Table"</a> .
		Front wiper request signal <ul style="list-style-type: none"> <li>BCM</li> <li>IPDM E/R</li> </ul>	IPDM E/R DATA MONITOR "FR WIP REQ"
	HI, LO and INT	SYMPTOM DIAGNOSIS "FRONT WIPER DOES NOT OPERATE" Refer to <a href="#">WW-120, "Diagnosis Procedure"</a> .	

# WIPER AND WASHER SYSTEM SYMPTOMS

## < SYMPTOM DIAGNOSIS >

Symptom		Probable malfunction location	Inspection item
Front wiper does not stop.	HI only	<ul style="list-style-type: none"> <li>Combination switch</li> <li>BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-92, "Symptom Table"</a> .
		Front wiper request signal <ul style="list-style-type: none"> <li>BCM</li> <li>IPDM E/R</li> </ul>	IPDM E/R DATA MONITOR "FR WIP REQ"
		IPDM E/R	—
	LO only	<ul style="list-style-type: none"> <li>Combination switch</li> <li>BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-92, "Symptom Table"</a> .
		Front wiper request signal <ul style="list-style-type: none"> <li>BCM</li> <li>IPDM E/R</li> </ul>	IPDM E/R DATA MONITOR "FR WIP REQ"
		IPDM E/R	—
	INT only	<ul style="list-style-type: none"> <li>Combination switch</li> <li>BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-92, "Symptom Table"</a> .
		Front wiper request signal <ul style="list-style-type: none"> <li>BCM</li> <li>IPDM E/R</li> </ul>	IPDM E/R DATA MONITOR "FR WIP REQ"
Front wiper does not operate normally.	Intermittent adjustment cannot be performed.	<ul style="list-style-type: none"> <li>Combination switch</li> <li>Harness between combination switch and BCM</li> <li>BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-92, "Symptom Table"</a> .
		BCM	—
	Intermittent control linked with vehicle speed cannot be performed.	Check the vehicle speed detection wiper setting. Refer to <a href="#">WW-18, "WIPER : CONSULT-III Function (BCM - WIPER)"</a> . <b>NOTE:</b> Factory setting of the front wiper intermitted operation is the operation without vehicle speed.	
	Wiper is not linked to the washer operation.	<ul style="list-style-type: none"> <li>Combination switch</li> <li>Harness between combination switch and BCM</li> <li>BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-92, "Symptom Table"</a> .
		BCM	—
Rear wiper does not operate.	Does not return to stop position. [Repeatedly operates for 10 seconds and then stops for 20 seconds. After that, it stops the operation. (Fail-safe)]	<ul style="list-style-type: none"> <li>IPDM E/R</li> <li>Harness between IPDM E/R and front wiper motor</li> <li>Front wiper motor</li> </ul>	Front wiper auto stop signal circuit Refer to <a href="#">WW-32, "Component Function Check"</a> .
	ON only	<ul style="list-style-type: none"> <li>Combination switch</li> <li>Harness between combination switch and BCM</li> <li>BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-92, "Symptom Table"</a> .
	INT only	<ul style="list-style-type: none"> <li>Combination switch</li> <li>Harness between combination switch and BCM</li> <li>BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-92, "Symptom Table"</a> .
	ON and INT	<ul style="list-style-type: none"> <li>Combination switch</li> <li>Harness between combination switch and BCM</li> <li>BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-92, "Symptom Table"</a> .
		<ul style="list-style-type: none"> <li>BCM</li> <li>Harness between rear wiper motor and BCM</li> <li>Harness between rear wiper motor and ground</li> <li>Rear wiper motor</li> </ul>	Combination switch Refer to <a href="#">BCS-92, "Symptom Table"</a> .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW

# WIPER AND WASHER SYSTEM SYMPTOMS

## < SYMPTOM DIAGNOSIS >

Symptom		Probable malfunction location	Inspection item
Rear wiper does not stop.	ON only	<ul style="list-style-type: none"> <li>Combination switch</li> <li>BCM</li> </ul>	Rear wiper motor circuit Refer to <a href="#">WW-38, "Component Function Check"</a> .
	INT only	<ul style="list-style-type: none"> <li>Combination switch</li> <li>BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-92, "Symptom Table"</a> .
Rear wiper does not operate normally.	Wiper is not linked to the washer operation.	<ul style="list-style-type: none"> <li>Combination switch</li> <li>Harness between rear wiper motor and BCM</li> <li>BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-92, "Symptom Table"</a> .
		BCM	—
	Rear wiper does not return to the stop position. [Stops after a five-second operation. (Fail-safe)]	<ul style="list-style-type: none"> <li>BCM</li> <li>Harness between rear wiper motor and BCM</li> <li>Rear wiper motor</li> </ul>	Rear wiper auto stop signal circuit Refer to <a href="#">WW-40, "Component Function Check"</a> .

## NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

### NORMAL OPERATING CONDITION

#### Description

INFOID:0000000005516042

#### FRONT WIPER MOTOR PROTECTION FUNCTION

- IPDM E/R may stop the front wiper to protect the front wiper motor if any obstruction (operation resistance) such as a large amount of snow is detected during the front wiper operation.
- At that time turn OFF the front wiper and remove the foreign object. Then wait for approximately 20 seconds or more and reactivate the front wiper. The wiper will operate normally.

#### REAR WIPER MOTOR PROTECTION FUNCTION

- BCM may stop rear wiper to protect the rear wiper motor when the rear wiper is stopped for 5 seconds or more due to a snowfall.
- Rear wiper operates normally one minute after the obstacles are removed with rear wiper OFF.

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

# FRONT WIPER DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

## FRONT WIPER DOES NOT OPERATE

### Description

INFOID:000000005516043

The front wiper does not operate under any operation conditions.

### Diagnosis Procedure

INFOID:000000005516044

#### 1.CHECK WIPER RELAY OPERATION

##### ⊗IPDM E/R AUTO ACTIVE TEST

1. Start IPDM E/R auto active test. Refer to [PCS-10, "Diagnosis Description"](#).
2. Check that the front wiper operates at the LO/HI operation.

##### ⓂCONSULT-III ACTIVE TEST

1. Select "FRONT WIPER" of IPDM E/R active test item.
2. With operating the test item, check front wiper operation.

**Lo** : Front wiper LO operation

**Hi** : Front wiper HI operation

**Off** : Stop the front wiper.

Is front wiper operation normally?

YES >> GO TO 5.

NO >> GO TO 2.

#### 2.CHECK FRONT WIPER MOTOR FUSE

1. Turn the ignition switch OFF.
2. Check that the front wiper motor 30 A fuse (#60) is not fusing.

Is the fuse fusing?

YES >> Replace the fuse after repairing the applicable circuit.

NO >> GO TO 3.

#### 3.CHECK FRONT WIPER MOTOR GROUND OPEN CIRCUIT

1. Disconnect front wiper motor connector.
2. Check continuity between front wiper motor harness connector and ground.

Front wiper motor		Ground	Continuity
Connector	Terminal		
E12	2		Existed

Does continuity exist?

YES >> GO TO 4.

NO >> Repair the harness or connector.

#### 4.CHECK FRONT WIPER MOTOR OUTPUT VOLTAGE

##### ⓂCONSULT-III ACTIVE TEST

1. Turn the ignition switch ON.
2. Select "FRONT WIPER" of IPDM E/R active test item.
3. With operating the test item, check voltage between IPDM E/R harness connector and ground.



# FRONT WIPER DOES NOT OPERATE

## < SYMPTOM DIAGNOSIS >

Terminals		Test item	Voltage (Approx.)
(+)	(-)		
IPDM E/R		FRONT WIPER	
Connector	Terminal		
E10	4	Lo	Battery voltage
		Off	0 V
	5	Hi	Battery voltage
		Off	0 V

Is the measurement value normal?

- YES >> Replace front wiper motor.  
NO >> Replace IPDM E/R.

## 5.CHECK FRONT WIPER REQUEST SIGNAL INPUT

### CONSULT-III DATA MONITOR

1. Select "FR WIP REQ" of IPDM E/R data monitor item.
2. Switch the front wiper switch to HI and LO.
3. With operating the front wiper switch, check the status of "FR WIP REQ".

Monitor item	Condition		Monitor status
FR WIP REQ	Front wiper switch HI	On	Hi
		Off	Stop
	Front wiper switch LO	On	Low
		Off	Stop

Is the status of item normal?

- YES >> Replace IPDM E/R.  
NO >> GO TO 6.

## 6.CHECK COMBINATION SWITCH

Perform the inspection of the combination switch. Refer to [BCS-92. "Symptom Table"](#).

Is combination switch normal?

- YES >> Replace BCM. Refer to [BCS-95. "Exploded View"](#).  
NO >> Repair or replace the applicable parts.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW

## PRECAUTIONS

< PRECAUTION >

### PRECAUTION

#### PRECAUTIONS

##### FOR USA AND CANADA

##### FOR USA AND CANADA : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000005674739

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted.

Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIR BAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

##### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

##### FOR MEXICO

##### FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000005674740

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIR BAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

##### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s)

## PRECAUTIONS


### < PRECAUTION >

- with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

### Precaution for Procedure without Cowl Top Cover

INFOID:000000005676461

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
WW  
M  
N  
O  
P

# WASHER TANK


< REMOVAL AND INSTALLATION >

## REMOVAL AND INSTALLATION

### WASHER TANK

#### Exploded View

INFOID:000000005516047



1. Washer tank inlet

2. Washer tank

### Removal and Installation


INFOID:000000005516048

#### REMOVAL

1. Remove the clip (A).

← : Vehicle front

2. Pull out the washer tank inlet (1) from the washer tank.
3. Remove the front bumper fascia. Refer to [EXT-13, "Exploded View"](#).
4. Disconnect washer pump connector.
5. Disconnect washer level switch connector.
6. Remove front washer tube and rear washer tube.
7. Remove washer tank mounting bolts.
8. Remove the washer tank from the vehicle.



#### INSTALLATION

Install in the reverse order of removal.

#### CAUTION:

Add water up to the top of the washer tank inlet after installing. Check that there is no leakage.


# WASHER PUMP

< REMOVAL AND INSTALLATION >

## WASHER PUMP

### Exploded View

INFOID:000000005516049



- |                |                      |                          |
|----------------|----------------------|--------------------------|
| 1. Washer tank | 2. Rear washer tube  | 3. Packing               |
| 4. Washer pump | 5. Front washer tube | 6. Washer pump connector |

⇨ : Vehicle front

### Removal and Installation

INFOID:000000005516050

#### REMOVAL

1. Remove the fender protector RH (front). Refer to [EXT-24, "FENDER PROTECTOR : Exploded View"](#).
2. Disconnect washer pump connector.
3. Remove front washer tube and rear washer tube.
4. Remove washer pump from the washer tank.
5. Remove the packing from the washer tank.

#### INSTALLATION

Install in the reverse order of removal.

#### **CAUTION:**

**Never twist the packing when installing the washer pump.**

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
WW  
M  
N  
O  
P

## WASHER LEVEL SWITCH

< REMOVAL AND INSTALLATION >

---

### WASHER LEVEL SWITCH

#### Removal and Installation

INFOID:000000005516051

The washer level switch must be replaced together with the washer tank as an assembly. Refer to [WW-124](#), "[Removal and Installation](#)".


## FRONT WASHER NOZZLE AND TUBE

< REMOVAL AND INSTALLATION >

### FRONT WASHER NOZZLE AND TUBE

Exploded View

INFOID:000000005516052




1. Front washer nozzle

2. Check valve

3. Front washer tube

Hydraulic Layout

INFOID:000000005516053



1. Front washer nozzle

2. Check valve

3. Front washer tube

4. Washer tank

△ : Clip

Removal and Installation

INFOID:000000005516054


#### REMOVAL

1. Remove cowl top cover. Refer to [EXT-21, "Exploded View"](#).
2. Disconnect front washer tube from front washer nozzle.

# FRONT WASHER NOZZLE AND TUBE

## < REMOVAL AND INSTALLATION >

- While pressing pawl (A) on the cowl top cover front side of front washer nozzle (1), remove front washer nozzle from cowl top cover.



## INSTALLATION

Install in the reverse order of removal.

### CAUTION:

The spray positions differ, check that left and right nozzles are installed correctly.


## Inspection and Adjustment

INFOID:000000005516055

## INSPECTION

Check valve Inspection


Check that air can pass through the hose by blowing forward (toward the nozzle), and check that air cannot pass through by sucking.



## ADJUSTMENT

Washer Nozzle Spray Position Adjustment

Adjust spray positions to match the positions shown in the figure.



1. Black printed frame line

▨ : Spray area

● : Target spray position



# FRONT WASHER NOZZLE AND TUBE

## < REMOVAL AND INSTALLATION >


Unit: mm (in)

Spray position	H	L	X	Y	S
A	285 (11.22)	429 (16.89)	80 (3.15)	130 (5.12)	65 (2.56)
B	398 (15.67)	232 (9.13)	80 (3.15)	130 (5.12)	65 (2.56)
C	185 (7.28)	69 (2.72)	80 (3.15)	130 (5.12)	65 (2.56)
D	381 (15.00)	37 (1.46)	80 (3.15)	130 (5.12)	65 (2.56)
E	398 (15.67)	232 (9.13)	80 (3.15)	130 (5.12)	65 (2.56)
F	296 (11.65)	421 (16.57)	80 (3.15)	130 (5.12)	65 (2.56)

Insert a needle or similar object (A) into the spray opening (1) and move up/down and left/right to adjust the spray position.

### NOTE:

If wax or dust gets into the nozzle, remove wax or dust with a needle or small pin.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K

WW

M  
N  
O  
P


## FRONT WIPER ARM

< REMOVAL AND INSTALLATION >

### FRONT WIPER ARM

#### Exploded View

INFOID:000000005516056



- |                           |                           |                        |
|---------------------------|---------------------------|------------------------|
| 1. Front wiper blade (RH) | 2. Front wiper arm (RH)   | 3. Front wiper arm cap |
| 4. Front wiper arm (LH)   | 5. Front wiper blade (LH) |                        |

Refer to [GI-4, "Components"](#) for symbols in the figure.

#### Removal and Installation


INFOID:000000005516057

##### REMOVAL

1. Operate the front wiper to move it to the auto stop position.
2. Open the hood.
3. Remove front wiper arm caps.
4. Remove the front wiper arm mounting nuts.
5. Raise front wiper arm, and remove front wiper arm from the vehicle.

##### INSTALLATION

1. Clean wiper arm mount as shown in the figure to prevent nuts from being loosened.
2. Operate the front wiper motor to move the front wiper to the auto stop position.
3. Adjust the front wiper blade position. Refer to [WW-130, "Adjustment"](#).
4. Install the front wiper arms by tightening the mounting nuts.
5. Inject the washer fluid.
6. Operate the front wiper to move it to the auto stop position.
7. Check that the front wiper blades stop at the specified position.
8. Install front wiper arm caps.



INFOID:000000005516058

#### Adjustment

##### WIPER BLADE POSITION ADJUSTMENT

Clearance between the end of cowl top cover and the top of front wiper blade center


## FRONT WIPER ARM

### < REMOVAL AND INSTALLATION >

Standard clearance

**R** :  $51.0 \pm 7.5 \text{ mm}$  ( $2.008 \pm 0.295 \text{ in}$ )

**L** :  $48.0 \pm 7.5 \text{ mm}$  ( $1.890 \pm 0.295 \text{ in}$ )



A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P


# WIPER BLADE

< REMOVAL AND INSTALLATION >

## WIPER BLADE

### Exploded View

INFOID:000000005516059



1. Wiper refill  
A. Wiper blade end

2. Wiper blade  
B. Wiper blade tip

3. Wiper arm

### Removal and Installation

INFOID:000000005516060

#### REMOVAL

Remove the wiper blade from the wiper arm.


#### INSTALLATION

Install the front wiper blade to the wiper arm.

### Replacement

INFOID:000000005516061

1. Hold the rip of old wiper refill (1) at the rear end of the wiper blade with long-nose pliers, and pull out the wiper refill to the direction (A).




2. Insert the tip of new wiper refill (1) into the rear end of wiper blade. Slide the wiper refill to the direction (A) while pressing the wiper refill onto the wiper blade rear end.

#### NOTE:

- Insert the wiper refill to be held securely by tab (B) of wiper blade.
- After the wiper refill is fully inserted, remove the holder\* (2).

\*: Attached to service parts.



## WIPER BLADE



### < REMOVAL AND INSTALLATION >

3. Insert the wiper refill until the stopper at the rear end of wiper refill fits in the tab. Check that "LOCK" mark on wiper refill is aligned with "▼" mark on wiper blade.
4. Untwist the twisted wiper refill (▨) at the rear end of wiper blade, if any.
5. Check the following items after replacing wiper refill.
  - Wiper refill is not twisted at all.
  - Wiper refill thoroughly fits in the tab on wiper blade.
  - Wiper refill is inserted from the proper direction.

#### NOTE:

When the vertebra is detached.

- Insert the vertebra (1) into the wiper blade to the same bending direction.
- If a vertebra has a notch, fit it to a protrusion inside the wiper refill.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
WW  
M  
N  
O  
P

# FRONT WIPER DRIVE ASSEMBLY


< REMOVAL AND INSTALLATION >

## FRONT WIPER DRIVE ASSEMBLY

Exploded View


INFOID:000000005516062

REMOVAL VIEW




1. Front wiper drive assembly

DISASSEMBLY VIEW



- |                      |               |                          |
|----------------------|---------------|--------------------------|
| 1. Front wiper motor | 2. Shaft seal | 3. Front wiper linkage 2 |
| 4. Front wiper frame | 5. Bracket    | 6. Front wiper linkage 1 |

: Multi-purpose grease or an equivalent

## Removal and Installation

INFOID:000000005516063

### REMOVAL

1. Remove front wiper arm. Refer to [WW-130, "Exploded View"](#).
2. Remove cowl top cover. Refer to [EXT-21, "Exploded View"](#).
3. Remove bolts from the front wiper drive assembly.

# FRONT WIPER DRIVE ASSEMBLY

## < REMOVAL AND INSTALLATION >

4. Disconnect the front wiper motor connector.
5. Remove front wiper drive assembly from the vehicle.

## INSTALLATION

1. Install the front wiper drive assembly to the vehicle.
2. Connect the front wiper motor connector.
3. Operate the front wiper to move it to the auto stop position.
4. Install the cowl top cover. Refer to [EXT-21, "Exploded View"](#).
5. Install front wiper arms. Refer to [WW-130, "Exploded View"](#).

## Disassembly and Assembly

INFOID:000000005516064

## DISASSEMBLY

1. Remove the front wiper linkage 1 and 2 from the front wiper drive assembly.  
**CAUTION:**  
**Never bend the linkage or damage the plastic part of the ball joint when removing the front wiper linkage.**
2. Remove the front wiper motor mounting screws, and then remove the front wiper motor from the front wiper frame.

## ASSEMBLY

1. Connect the front wiper motor connector.
2. Operate the front wiper to move it to the auto stop position.
3. Disconnect the front wiper motor connector.
4. Install front wiper motor to front wiper frame.
5. Install the front wiper linkage 2 to the front wiper motor and the front wiper frame.
6. Install the front wiper linkage 1 to the front wiper frame.  
**CAUTION:**
  - **Never drop front wiper motor or cause it to come into contact with other parts.**
  - **Be careful for the grease condition at the front wiper motor and front wiper linkage joint (retainer). Apply multi-purpose grease or an equivalent if necessary.**

WW

# RAIN SENSOR

< REMOVAL AND INSTALLATION >

## RAIN SENSOR


### Exploded View

INFOID:000000005516065

#### CAUTION:

When the rain sensor is removed from windshield, the rain sensor cannot be re-used.

### REMOVAL



1. Rain sensor connector
2. Inside mirror cover (upper)
3. Inside mirror cover (lower)
4. Rain sensor
- A. Metal spring clip

Refer to [GI-4, "Components"](#) for symbols in the figure.

### Removal and Installation

INFOID:000000005516066

#### REMOVAL

1. Remove the inside mirror cover (upper and lower).
2. Disengage the both sides of metal spring clips, and remove the rain sensor from the windshield.
3. Disconnect rain sensor connector.

#### INSTALLATION

Install in the reverse order of removal.

#### CAUTION:

- Surface of windshield should be cleaned.
- Never touch gel/adhesive of new part.
- Lock the metal spring clips and install the rain sensor securely.



# WIPER AND WASHER SWITCH

< REMOVAL AND INSTALLATION >

## WIPER AND WASHER SWITCH

### Exploded View

INFOID:000000005516067

Refer to [BCS-96, "Exploded View"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
WW  
M  
N  
O  
P


# REAR WIPER ARM

< REMOVAL AND INSTALLATION >

## REAR WIPER ARM

### Exploded View

INFOID:000000005516068



- |                     |                         |               |
|---------------------|-------------------------|---------------|
| 1. Rear wiper blade | 2. Rear wiper motor     | 3. Pivot seal |
| 4. Rear wiper arm   | 5. Rear wiper arm cover |               |

Refer to [GI-4, "Components"](#) for symbols in the figure.

### Removal and Installation


INFOID:000000005516069

#### REMOVAL

1. Operate the rear wiper to the auto stop position.
2. Remove rear wiper arm cover.
3. Remove the rear wiper arm mounting nut.
4. Raise rear wiper arm, and remove wiper arm from the vehicle.

#### INSTALLATION

1. Clean wiper arm mount as shown in the figure to prevent nut from being loosened.
2. Operate the rear wiper motor to the auto stop position.
3. Adjust the rear wiper blade position. Refer to [WW-138, "Adjustment"](#).
4. Install the rear wiper arm by tightening the mounting nut.
5. Inject the washer fluid.
6. Operate the rear wiper to the auto stop position.
7. Check that the rear wiper blades stop at the specified position.
8. Install rear wiper arm cover.



### Adjustment

INFOID:000000005516070

#### REAR WIPER BLADE POSITION ADJUSTMENT


Clearance between the end of back door glass and top of wiper blade center.

## REAR WIPER ARM

### < REMOVAL AND INSTALLATION >

Standard clearance

**L :  $48.8 \pm 7.5$  mm ( $1.92 \pm 0.295$  in)**



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
WW  
M  
N  
O  
P


## REAR WIPER MOTOR

< REMOVAL AND INSTALLATION >

### REAR WIPER MOTOR

#### Exploded View

INFOID:000000005516071



- |                     |                         |               |
|---------------------|-------------------------|---------------|
| 1. Rear wiper blade | 2. Rear wiper motor     | 3. Pivot seal |
| 4. Rear wiper arm   | 5. Rear wiper arm cover |               |

Refer to [GI-4, "Components"](#) for symbols in the figure.

#### Removal and Installation

INFOID:000000005516072

##### REMOVAL

1. Remove rear wiper arm cover and rear wiper arm. Refer to [WW-138, "Exploded View"](#).
2. Remove the back door finisher inner. Refer to [INT-38, "Exploded View"](#).
3. Disconnect the rear wiper motor connector.
4. Remove the rear wiper motor mounting bolts.
5. Remove the rear wiper motor from the vehicle.
6. Remove the pivot seal.

##### INSTALLATION

1. Install the pivot seal.
2. Install the rear wiper motor to the vehicle.
3. Connect the rear wiper motor connector.
4. Operate the rear wiper to the auto stop position.
5. Install the back door finisher inner. Refer to [INT-38, "Exploded View"](#).
6. Install rear wiper arm cover and rear wiper arm. Refer to [WW-138, "Exploded View"](#).


# REAR WASHER NOZZLE AND TUBE

< REMOVAL AND INSTALLATION >

## REAR WASHER NOZZLE AND TUBE

### Hydraulic Layout

INFOID:000000005516073



1. Rear washer nozzle

2. Check valve

3. Rear washer tube

4. Washer tank

△ : Clip

○ : Grommet

### Removal and Installation

INFOID:000000005516074


#### REMOVAL

1. Remove the high-mounted stop lamp. Refer to [EXL-190, "Exploded View"](#).
2. Remove the rear washer tube from the rear washer nozzle.

# 

### 

- Remove the rear washer nozzle (1) from the high-mounted stop lamp (2).



### 

Install in the reverse order of removal.


### 

INFOID:000000005516075

### 

#### 

Check that air can pass through the hose by blowing forward (toward the nozzle), and check that air cannot pass through by sucking.



### 


#### 

Adjust spray positions to match the positions shown in the figure.

1 : Black printed frame line

Unit: mm (in)

Spray position	H (Height)	$\phi$ (Spray position area)
A	30 (1.18)	30 (1.18)



Insert a needle or similar object (A) into the spray opening (1) and move up/down and left/right to adjust the spray position.

#### 

If wax or dust gets into the nozzle, remove wax or dust with a needle or small pin.

