

DEF

SECTION DEFROGGER

CONTENTS

BASIC INSPECTION	3	REAR WINDOW DEFOGGER RELAY	12																																																		
DIAGNOSIS AND REPAIR WORKFLOW	3	Description	12																																																		
Work Flow	3	Component Function Check	12																																																		
SYSTEM DESCRIPTION	4	Diagnosis Procedure	12																																																		
REAR WINDOW DEFOGGER SYSTEM	4	Component Inspection	13																																																		
WITH BOSE SYSTEM	4	REAR WINDOW DEFOGGER	14																																																		
WITH BOSE SYSTEM : System Diagram	4	Description	14																																																		
WITH BOSE SYSTEM : System Description	4	Component Function Check	14																																																		
WITH BOSE SYSTEM : Component Parts Location	5	Diagnosis Procedure	14																																																		
WITH BOSE SYSTEM : Component Description.....	5	Component Inspection	16																																																		
WITHOUT BOSE SYSTEM	6	DOOR MIRROR DEFOGGER	17																																																		
WITHOUT BOSE SYSTEM : System Diagram	6	Description	17																																																		
WITHOUT BOSE SYSTEM : System Description.....	6	Component Function Check	17																																																		
WITHOUT BOSE SYSTEM : Component Parts Location	7	Diagnosis Procedure	17																																																		
WITHOUT BOSE SYSTEM : Component Description.....	7	DRIVER SIDE DOOR MIRROR DEFOGGER ...	18																																																		
DIAGNOSIS SYSTEM (BCM)	8	COMMON ITEM	8	Description	18	COMMON ITEM : CONSULT-III Function (BCM -		Component Function Check	18	COMMON ITEM)	8	Diagnosis Procedure	18	REAR WINDOW DEFOGGER	9	Component Inspection	19	REAR WINDOW DEFOGGER : CONSULT-III		PASSENGER SIDE DOOR MIRROR DEFOG-		Function (BCM - REAR DEFOGGER)	9	GER	20	DTC/CIRCUIT DIAGNOSIS	10	Description	20	POWER SUPPLY AND GROUND CIRCUIT	10	Component Function Check	20	Diagnosis Procedure	10	Diagnosis Procedure	20	REAR WINDOW DEFOGGER SWITCH	11	Component Inspection	21	Description	11	REAR WINDOW DEFOGGER SYSTEM	22	Component Function Check	11	Wiring Diagram - DEFOGGER SYSTEM -	22	Diagnosis Procedure	11	ECU DIAGNOSIS INFORMATION	29
COMMON ITEM	8	Description	18																																																		
COMMON ITEM : CONSULT-III Function (BCM -		Component Function Check	18																																																		
COMMON ITEM)	8	Diagnosis Procedure	18																																																		
REAR WINDOW DEFOGGER	9	Component Inspection	19																																																		
REAR WINDOW DEFOGGER : CONSULT-III		PASSENGER SIDE DOOR MIRROR DEFOG-																																																			
Function (BCM - REAR DEFOGGER)	9	GER	20																																																		
DTC/CIRCUIT DIAGNOSIS	10	Description	20	POWER SUPPLY AND GROUND CIRCUIT	10	Component Function Check	20	Diagnosis Procedure	10	Diagnosis Procedure	20	REAR WINDOW DEFOGGER SWITCH	11	Component Inspection	21	Description	11	REAR WINDOW DEFOGGER SYSTEM	22	Component Function Check	11	Wiring Diagram - DEFOGGER SYSTEM -	22	Diagnosis Procedure	11	ECU DIAGNOSIS INFORMATION	29																										
Description	20																																																				
POWER SUPPLY AND GROUND CIRCUIT	10	Component Function Check	20	Diagnosis Procedure	10	Diagnosis Procedure	20	REAR WINDOW DEFOGGER SWITCH	11	Component Inspection	21	Description	11	REAR WINDOW DEFOGGER SYSTEM	22	Component Function Check	11	Wiring Diagram - DEFOGGER SYSTEM -	22	Diagnosis Procedure	11	ECU DIAGNOSIS INFORMATION	29																														
Component Function Check	20																																																				
Diagnosis Procedure	10	Diagnosis Procedure	20	REAR WINDOW DEFOGGER SWITCH	11	Component Inspection	21	Description	11	REAR WINDOW DEFOGGER SYSTEM	22	Component Function Check	11	Wiring Diagram - DEFOGGER SYSTEM -	22	Diagnosis Procedure	11	ECU DIAGNOSIS INFORMATION	29																																		
Diagnosis Procedure	20																																																				
REAR WINDOW DEFOGGER SWITCH	11	Component Inspection	21	Description	11	REAR WINDOW DEFOGGER SYSTEM	22	Component Function Check	11	Wiring Diagram - DEFOGGER SYSTEM -	22	Diagnosis Procedure	11	ECU DIAGNOSIS INFORMATION	29																																						
Component Inspection	21																																																				
Description	11	REAR WINDOW DEFOGGER SYSTEM	22																																																		
Component Function Check	11	Wiring Diagram - DEFOGGER SYSTEM -	22	Diagnosis Procedure	11	ECU DIAGNOSIS INFORMATION	29																																														
Wiring Diagram - DEFOGGER SYSTEM -	22																																																				
Diagnosis Procedure	11	ECU DIAGNOSIS INFORMATION	29																																																		

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
DEF

SYMPTOM DIAGNOSIS	63	ON IS NOT DISPLAYED WHEN PRESSING REAR WINDOW DEFOGGER SWITCH BUT IT IS OPERATED	67
REAR WINDOW DEFOGGER DOES NOT OPERATE	63	Diagnosis Procedure	67
Diagnosis Procedure	63		
REAR WINDOW DEFOGGER AND DOOR MIRROR DEFOGGER DO NOT OPERATE.	64	REAR WINDOW DEFOGGER INDICATOR DOES NOT ILLUMINATE	68
Diagnosis Procedure	64	Diagnosis Procedure	68
REAR WINDOW DEFOGGER DOES NOT OPERATE BUT BOTH DOOR MIRROR DEFOGGERS OPERATE.	65	PRECAUTION	69
Diagnosis Procedure	65	PRECAUTIONS	69
DOOR MIRROR DEFOGGER DOES NOT OPERATE	66	FOR USA AND CANADA	69
BOTH SIDES	66	FOR USA AND CANADA : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	69
BOTH SIDES : Diagnosis Procedure	66		
DRIVER SIDE	66	FOR MEXICO	69
DRIVER SIDE : Diagnosis Procedure	66	FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	69
PASSENGER SIDE	66	REMOVAL AND INSTALLATION	71
PASSENGER SIDE : Diagnosis Procedure	66	FILAMENT	71
		Inspection and Repair	71

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000006260838

DETAILED FLOW

1. OBTAIN INFORMATION ABOUT SYMPTOM

Interview the customer to obtain the malfunction information (conditions and environment when the malfunction occurred) as much as possible when the customer brings the vehicle in.

>> GO TO 2.

2. CHECK DTC

Perform self diagnosis with CONSULT-III

Is any DTC detected?

YES >> Refer to [DEF-60, "DTC Index"](#).

NO >> GO TO 3.

3. REPRODUCE THE MALFUNCTION INFORMATION

Check the malfunction on the vehicle that the customer describes.

Inspect the relation of the symptoms and the condition when the symptoms occur.

>> GO TO 4.

4. IDENTIFY THE MALFUNCTIONING SYSTEM WITH "SYMPTOM DIAGNOSIS"

Use "Symptom diagnosis" from the symptom inspection result in step 3. Then identify where to start performing the diagnosis based on possible causes and symptoms.

>> GO TO 5.

5. IDENTIFY MALFUNCTIONING PARTS WITH "COMPONENT DIAGNOSIS"

Perform the diagnosis with "Component diagnosis" of the applicable system.

>> GO TO 6.

6. REPAIR OR REPLACE THE MALFUNCTIONING PARTS

Repair or replace the specified malfunctioning parts.

>> GO TO 7.

7. FINAL CHECK

Check that malfunctions are not reproduced when obtaining the malfunction information from the customer, referring to the symptom inspection result in step 3.

Are all malfunctions corrected?

YES >> INSPECTION END

NO >> GO TO 4.

A

B

C

D

E

F

G

H

I

J

K

DEF

M

N

O

P

REAR WINDOW DEFOGGER SYSTEM


< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

REAR WINDOW DEFOGGER SYSTEM WITH BOSE SYSTEM

WITH BOSE SYSTEM : System Diagram

INFOID:0000000006260839



JMLIA0005GB

WITH BOSE SYSTEM : System Description

INFOID:0000000006260840

Operation Description

- Turn rear window defogger switch ON when the ignition switch is turned ON. Then multifunction switch (rear window defogger switch) transmits rear window defogger switch signal to AV control unit via AV communication. AV control unit transmits rear window defogger switch signal to BCM via CAN communication.
- BCM turns rear window defogger relay ON and transmits rear window defogger control signal to IPDM E/R via CAN communication when rear window defogger switch signal is received.
- Rear window defogger and door mirror defogger (with door mirror defogger) are supplied with power and operate when rear window defogger relay turns ON.
- IPDM E/R transmits rear window defogger control signal to AV control unit via CAN communication.
- AV control unit transmit rear defogger indicator signal to multifunction switch (rear window defogger switch) via AV communication. then rear window defogger indicator is illuminated.

Timer function

- BCM turns rear window defogger relay ON for approximately 15 minutes when rear window defogger switch is turned ON. It makes rear window defogger and door mirror defogger (with door mirror defogger) operate.
- Timer is canceled after pressing rear window defogger switch again during timer operation. Then BCM turns rear window defogger relay OFF. The same reaction also occurs during timer operation, if the ignition switch is turned OFF.

INPUT/OUTPUT SIGNAL CHART

Switch	Input signal to BCM	BCM function	Actuator
Rear window defogger switch	Defogger switch signal	Rear window defogger & Door mirror defogger * control	Rear window defogger
Push button ignition switch	Ignition signal		Door mirror defogger *


*: With door mirror defogger

REAR WINDOW DEFOGGER SYSTEM

< SYSTEM DESCRIPTION >

WITH BOSE SYSTEM : Component Parts Location

INFOID:000000006260841



JMLIA0119ZZ

- | | | |
|---|---|--|
| 1. BCM M118, M119, M122, M123 | 2. IPDM E/R E6, E11 | 3. Rear window defogger switch
(built-in multifunction switch M125) |
| 4. Rear window defogger connector
D184 | 5. AV control unit
With NAVI M145, M146
Without NAVI M129, M131 | |
| A. Dash side lower (passenger side) | B. Engine room dash panel (LH) | C. Behind rear pillar finisher (LH) |
| D. Behind cluster lid C | | |

K

DEF

WITH BOSE SYSTEM : Component Description

INFOID:000000006260842

M

N

O

P

BCM	<ul style="list-style-type: none"> Operates the rear window defogger with the operation of rear window defogger switch. Performs the timer control of rear window defogger.
Rear window defogger relay	<ul style="list-style-type: none"> Operates the rear window defogger and the door mirror defogger with the control signal from BCM.
IPDM E/R	<ul style="list-style-type: none"> Transmit rear window defogger control signal to AV control unit via CAN communication.
Multifunction switch (Rear window defogger switch)	<ul style="list-style-type: none"> The rear window defogger switch is installed. Turns the indicator lamp ON when detecting the operation of rear window defogger.
AV control unit	<ul style="list-style-type: none"> Displays the rear window defogger ON to the display when detecting the operation of rear window defogger.
Rear window defogger	<ul style="list-style-type: none"> Heats the heating wire with the power supply from the rear window defogger relay to prevent the rear window from fogging up.
Door mirror defogger*	<ul style="list-style-type: none"> Heats the heating wire with the power supply from the rear window defogger relay to prevent the door mirror from fogging up.

REAR WINDOW DEFOGGER SYSTEM


< SYSTEM DESCRIPTION >

*: With mirror defogger

WITHOUT BOSE SYSTEM

WITHOUT BOSE SYSTEM : System Diagram

INFOID:0000000006260843



WITHOUT BOSE SYSTEM : System Description

INFOID:0000000006260844

Operation Description

- Turn rear window defogger switch ON when the ignition switch is turned ON. Then A/C control unit (rear window defogger switch) transmits rear window defogger switch signal to A/C auto amp.. transmits rear window defogger switch signal to BCM.
- BCM turns rear window defogger relay ON and transmits rear window defogger control signal to IPDM E/R via CAN communication when rear window defogger switch signal is received.
- Rear window defogger and door mirror defogger (with door mirror defogger) are supplied with power and operate when rear window defogger relay turns ON.
- Rear window defogger relay transmits rear window defogger control signal to A/C auto amp. when rear window defogger operates.
- A/C auto amp. transmit rear window defogger indicator signal to A/C control unit (rear window defogger switch). Then rear window defogger indicator is illuminated.

Timer function

- BCM turns rear window defogger relay ON for approximately 15 minutes when rear window defogger switch is turned ON. It makes rear window defogger and door mirror defogger (with door mirror defogger) operate.
- Timer is canceled after pressing rear window defogger switch again during timer operation. Then BCM turns rear window defogger relay OFF. The same reaction also occurs during timer operation, if the ignition switch is turned OFF.

INPUT/OUTPUT SIGNAL CHART

Switch	Input signal to BCM	BCM function	Actuator
Rear window defogger switch	Defogger switch signal	Rear window defogger & Door mirror defogger * control	Rear window defogger
Push button ignition switch	Ignition signal		Door mirror defogger *


*: With door mirror defogger

REAR WINDOW DEFOGGER SYSTEM

< SYSTEM DESCRIPTION >

WITHOUT BOSE SYSTEM : Component Parts Location

INFOID:0000000006260845



JMLIA0128ZZ

- | | | |
|--|--------------------------------|--|
| 1. BCM M118, M119, M122, M123 | 2. IPDM E/R E6, E11 | 3. Rear window defogger switch (built-in A/C control unit M95) |
| 4. Rear window defogger connector D184 | 5. A/C auto amp. M50 | |
| A. Dash side lower (passenger side) | B. Engine room dash panel (LH) | C. Behind rear pillar finisher (LH) |
| D. Behind cluster lid C | | |

WITHOUT BOSE SYSTEM : Component Description

INFOID:0000000006260846

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DEF

BCM	<ul style="list-style-type: none"> Operates the rear window defogger with the operation of rear window defogger switch. Performs the timer control of rear window defogger.
Rear window defogger relay	<ul style="list-style-type: none"> Operates the rear window defogger and the door mirror defogger with the control signal from BCM.
IPDM E/R	<ul style="list-style-type: none"> Transmit rear window defogger control signal to ECM via CAN communication.
A/C control unit (Rear window defogger switch)	<ul style="list-style-type: none"> The rear window defogger switch is installed. Turns the indicator lamp ON when detecting the operation of rear window defogger.
A/C auto amp.	<ul style="list-style-type: none"> Displays the rear window defogger ON to the display when detecting the operation of rear window defogger.
Rear window defogger	<ul style="list-style-type: none"> Heats the heating wire with the power supply from the rear window defogger relay to prevent the rear window from fogging up.
Door mirror defogger*	<ul style="list-style-type: none"> Heats the heating wire with the power supply from the rear window defogger relay to prevent the door mirror from fogging up.

*: With door mirror defogger

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM)

INFOID:000000006260847

APPLICATION ITEM

CONSULT-III performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
Work Support	Changes the setting for each system function.
Self Diagnostic Result	Displays the diagnosis results judged by BCM.
CAN Diag Support Monitor	Monitors the reception status of CAN communication viewed from BCM. Refer to CONSULT-III operation manual.
Data Monitor	The BCM input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from BCM.
Ecu Identification	The BCM part number is displayed.
Configuration	This function is not used even though it is displayed.

SYSTEM APPLICATION

BCM can perform the following functions for each system.

NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

x: Applicable item

System	Sub system selection item	Diagnosis mode		
		Work Support	Data Monitor	Active Test
Door lock	DOOR LOCK	x	x	x
Rear window defogger	REAR DEFOGGER		x	x
Warning chime	BUZZER		x	x
Interior room lamp timer	INT LAMP	x	x	x
Exterior lamp	HEAD LAMP	x	x	x
Wiper and washer	WIPER	x	x	x
Turn signal and hazard warning lamps	FLASHER	x	x	x
—	AIR CONDITIONER*		x	
Intelligent Key system	INTELLIGENT KEY	x	x	x
Combination switch	COMB SW		x	
Body control system	BCM	x		
IVIS - NATS	IMMU		x	x
Interior room lamp battery saver	BATTERY SAVER	x	x	x
Trunk open	TRUNK		x	
Vehicle security system	THEFT ALM	x	x	x
RAP system	RETAINED PWR		x	
Signal buffer system	SIGNAL BUFFER		x	x
TPMS	TPMS (AIR PRESSURE MONITOR)	x	x	x

*: This item is displayed, but is not used.

FREEZE FRAME DATA (FFD) AND IGN COUNTER

Freeze Frame Data

The BCM records the following condition at the moment a particular DTC is detected.

- Vehicle Speed
- Odo/Trip Meter

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

- Vehicle Condition (BCM detected condition)

CONSULT screen terms	Description
SLEEP>LOCK	While turning BCM status from low power consumption mode to normal mode (Power supply position is "LOCK")
SLEEP>OFF	While turning BCM status from low power consumption mode to normal mode (Power supply position is "OFF".)
LOCK>ACC	While turning power supply position from "LOCK" to "ACC"
ACC>ON	While turning power supply position from "ACC" to "IGN"
RUN>ACC	While turning power supply position from "RUN" to "ACC" (Vehicle is stopping and selector lever is except P position.)
CRANK>RUN	While turning power supply position from "CRANKING" to "RUN" (From cranking up the engine to run it)
RUN>URGENT	While turning power supply position from "RUN" to "ACC" (Emergency stop operation)
ACC>OFF	While turning power supply position from "ACC" to "OFF"
OFF>LOCK	While turning power supply position from "OFF" to "LOCK"
OFF>ACC	While turning power supply position from "OFF" to "ACC"
ON>CRANK	While turning power supply position from "IGN" to "CRANKING"
OFF>SLEEP	While turning BCM status from normal mode (Power supply position is "OFF".) to low power consumption mode
LOCK>SLEEP	While turning BCM status from normal mode (Power supply position is "LOCK".) to low power consumption mode
LOCK	Power supply position is "LOCK" (Ignition switch OFF with steering is locked.)
OFF	Power supply position is "OFF" (Ignition switch OFF with steering is unlocked.)
ACC	Power supply position is "ACC" (Ignition switch ACC)
ON	Power supply position is "IGN" (Ignition switch ON with engine stopped)
ENGINE RUN	Power supply position is "RUN" (Ignition switch ON with engine running)
CRANKING	Power supply position is "CRANKING" (At engine cranking)

IGN Counter

IGN counter indicates the number of times that ignition switch is turned ON after DTC is detected.

- The number is 0 when a malfunction is detected now.
- The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON.
- The number is fixed to 39 until the self-diagnosis results are erased if it is over 39.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DEF

REAR WINDOW DEFOGGER

REAR WINDOW DEFOGGER : CONSULT-III Function (BCM - REAR DEFOGGER)

INFOID:0000000006260848

Data monitor

Monitor Item	Description
REAR DEF SW	This is displayed even when it is not equipped.
PUSH SW	Indicates [ON/OFF] condition of push switch.

ACTIVE TEST

Test Item	Description
REAR DEFOGGER	This test is able to check rear window defogger operation. Rear window defogger operates when "ON" on CONSULT-III screen is touched.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT

Diagnosis Procedure

INFOID:0000000006260849

1.CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

Terminal No.	Signal name	Fuse and fusible link No.
1		L
11	Battery power supply	10

Is the fuse blown?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit if a fuse or fusible link is blown.

NO >> GO TO 2.

2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connectors.
3. Check voltage between BCM harness connector and ground.

Terminals		Ground	Voltage (Approx.)		
(+) (-)					
BCM					
Connector	Terminal				
M118	1				
M119	11				
			Battery voltage		

Is the measurement value normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connector.

3.CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M119	13		Existed

Does continuity exist?

YES >> INSPECTION END

NO >> Repair or replace harness or connector.

REAR WINDOW DEFOGGER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

REAR WINDOW DEFOGGER SWITCH

Description

INFOID:0000000006260850

- The rear window defogger is operated by turning the rear window defogger switch ON.
- The indicator lamp in the rear window defogger illuminates when the rear window defogger is operating.

Component Function Check

INFOID:0000000006260851

1.CHECK REAR WINDOW DEFOGGER SWITCH FUNCTION

Check that the indicator lamp of rear window defogger illuminates when rear window defogger switch ON.

Is the inspection result normal?

YES >> Rear window defogger switch function is OK.

NO >> Refer to [DEF-11, "Diagnosis Procedure"](#)

Diagnosis Procedure

INFOID:0000000006260852

WITH BOSE AUDIO SYSTEM

1.CHECK PRESET SWITCH (REAR WINDOW DEFOGGER SWITCH)

Does preset switch operate normally?

- Without navigation system. Refer to [AV-175, "Description"](#).
- With navigation system. Refer to [AV-308, "Description"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace preset switch (rear window defogger switch). Refer to [AV-282, "Removal and Installation"](#).
(without navigation system) or [AV-427, "Removal and Installation"](#) (with navigation system).

WITHOUT BOSE AUDIO SYSTEM

1.CHECK A/C CONTROL (REAR WINDOW DEFOGGER SWITCH)

Check A/C control. Refer to [HAC-75, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace A/C control. Refer to [VTL-22, "Removal and Installation"](#).

DEF

REAR WINDOW DEFOGGER RELAY

< DTC/CIRCUIT DIAGNOSIS >

REAR WINDOW DEFOGGER RELAY

Description

INFOID:0000000006260853

Power is supplied to the rear window defogger with BCM control.

Component Function Check

INFOID:0000000006260854

1.CHECK REAR WINDOW DEFOGGER RELAY POWER SUPPLY CIRCUIT

1. Perform Active Test ("REAR DEFOGGER") with CONSULT-III.
2. Touch "ON".
3. Check that the rear window heating wire is getting warmer.

Is the inspection result normal?

YES >> Rear window defogger relay power supply circuit is OK.

NO >> Refer to [DEF-12, "Diagnosis Procedure"](#)

Diagnosis Procedure

INFOID:0000000006260855

1.CHECK FUSE

1. Turn ignition switch OFF.
2. Check 10A fuse (No.3, located in fuse block (J/B)).

-

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.

2.CHECK REAR WINDOW DEFOGGER RELAY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between BCM harness connector and ground.

(+) BCM		(-)	Condition of rear window defogger switch	Voltage (V) (Approx.)
Connector	Terminal			
M123	151	Ground	ON	0
			OFF	Battery voltage

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 3.

3.CHECK FUSE BLOCK (J/B)

Check voltage between fuse block (J/B) connector and ground.

Fuse block (J/B)		Ground	Voltage (V) (Approx.)
Connector	Terminal		
M2	4B		Battery voltage

Is the inspection result normal?

YES >> Repair or replace harness or connector between BCM and fuse block (J/B).

NO >> GO TO 4.

4.CHECK REAR WINDOW DEFOGGER RELAY

Check rear window defogger relay.

Refer to [DEF-13, "Component Inspection"](#)

Is the inspection result normal?

YES >> Replace fuse block (J/B).

NO >> Replace rear window defogger relay.

REAR WINDOW DEFOGGER RELAY

< DTC/CIRCUIT DIAGNOSIS >

5.CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [GI-44, "Intermittent Incident"](#)

>> INSPECTION END

Component Inspection

INFOID:000000006260856

1.CHECK REAR WINDOW DEFOGGER RELAY


1. Turn ignition switch OFF.
2. Disconnect rear window defogger relay.
3. Check rear window defogger relay.

Terminal	Condition		Continuity
Rear window defogger relay			
3	5	12 V direct current supply between terminals 1 and 2.	Existed
		No current supply	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace rear window defogger relay.



REAR WINDOW DEFOGGER

< DTC/CIRCUIT DIAGNOSIS >

REAR WINDOW DEFOGGER

Description

INFOID:0000000006260857

Heats the heating wire with the power supply from the rear window defogger relay to prevent the rear window from fogging up.

Component Function Check

INFOID:0000000006260858

1.CHECK REAR WINDOW DEFOGGER

1. Perform Active Test ("REAR DEFOGGER") with CONSULT-III.
2. Touch "ON".
3. Check that the rear window heating wire is getting warmer.

Is the inspection result normal?

- YES >> Rear window defogger is OK.
NO >> Refer to [DEF-14. "Diagnosis Procedure"](#)

Diagnosis Procedure

INFOID:0000000006260859

1.CHECK FUSE

1. Turn ignition switch OFF.
2. Check the following.
 - 20A fuse (No.14, located in fuse block (J/B)
 - 20A fuse (No.15, located in fuse block (J/B)

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.

2.CHECK POWER SUPPLY CIRCUIT

1. Disconnect rear window defogger harness connector.
2. Turn ignition switch ON.
3. Check voltage between rear window defogger connector and ground.

(+)		(-)	Condition of rear window defogger switch	Voltage (V) (Approx.)
Rear window defogger				
Connector	Terminal			
D184	1	Ground	ON	Battery voltage
			OFF	0

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 4.

3.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between rear window defogger harness connector and ground.

Rear window defogger		Ground	Continuity
Connector	Terminal		
D185	2		Existed

Is the inspection result normal?

- YES >> GO TO 9.
NO >> Repair or replace harness or connector between rear window defogger and ground.

4.CHECK REAR WINDOW DEFOGGER CIRCUIT 1

REAR WINDOW DEFOGGER

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect condenser connector.
3. Check continuity between condenser harness connector and rear window defogger harness connector.

Condenser		Rear window defogger		Continuity
Connector	Terminal	Connector	Terminal	
B75	2	B184	1	Existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness or connector.

5.CHECK REAR WINDOW DEFOGGER CIRCUIT 2

1. Check continuity between fuse block (J/B) harness connector and condenser harness connector.

Fuse block (J/B)		Condenser		Continuity
Connector	Terminal	Connector	Terminal	
B6	10G	B74	1	Existed
	11G			

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace harness or connector between fuse block (J/B) and condenser.

6.CHECK FUSE BLOCK (J/B)

1. Turn ignition switch ON.
2. Check voltage between fuse block (J/B) connector (fuse block side) and ground.

(+) Fuse block (J/B)		(-)	Condition of rear window defogger switch	Voltage (V) (Approx.)	
Connector	Terminal				
B6	10G	Ground	ON	Battery voltage	
			OFF	0	
	11G		ON	Battery voltage	
			OFF	0	

Is the inspection result normal?

YES >> GO TO 7.

NO >> GO TO 8.

7.CHECK CONDENSER

Check condenser. Refer to [DEF-16, "Component Inspection"](#)

Is the inspection result normal?

YES >> GO TO 10.

NO >> Replace condenser.

8.CHECK REAR WINDOW DEFOGGER RELAY

Check rear window defogger relay. Refer to [DEF-13, "Component Inspection"](#)

Is the inspection result normal?

YES >> Replace fuse block (J/B).

NO >> Replace rear window defogger relay.

9.CHECK FILAMENT

Check the filament for damage or blown.

Refer to [DEF-71, "Inspection and Repair"](#)

Is the inspection result normal?

A

B

C

D

E

F

G

H

I

J

DEF

M

N

O

P

REAR WINDOW DEFOGGER

< DTC/CIRCUIT DIAGNOSIS >

YES >> GO TO 10.

NO >> Repair filament.

10. CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [GI-44, "Intermittent Incident"](#)

>> INSPECTION END

Component Inspection

INFOID:000000006260860

1. CHECK CONDENSER

1. Check continuity between condenser connector and ground part of condenser.

Condensor		Ground part of condenser	Continuity
Connector	Terminal		
B74	1		
B75	2		

2. Check condenser.

Condensor				Continuity
Connector	Terminal	Connector	Terminal	
B74	1	B75	2	Existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair condenser.

DOOR MIRROR DEFOGGER

< DTC/CIRCUIT DIAGNOSIS >

DOOR MIRROR DEFOGGER

Description

INFOID:0000000006260861

Power is supplied to the door mirror defogger with BCM control.

Component Function Check

INFOID:0000000006260862

1.CHECK DOOR MIRROR DEFOGGER

1. Perform Active Test ("REAR DEFOGGER") with CONSULT-III.
2. Touch "ON".
3. Check that both side door mirror glass is getting warmer.

Is the inspection result normal?

- YES >> Door mirror defogger is OK.
NO >> Refer to [DEF-17, "Diagnosis Procedure"](#)

Diagnosis Procedure

INFOID:0000000006260863

1.CHECK FUSE

1. Turn ignition switch OFF.
2. Check 10A fuse (No.13, located in fuse block (J/B)).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.

2.CHECK FUSE BLOCK (J/B)

1. Turn ignition switch ON.
2. Check voltage between fuse block (J/B) connector (fuse block side) and ground.

(+) Fuse block (J/B)		(-) Connector	Condition of rear window defogger switch	Voltage (V) (Approx.)
Connector	Terminal			
M3	10C	Ground	ON	Battery voltage
			OFF	0

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Replace fuse block (J/B).

3.CHECK DOOR MIRROR DEFOGGER CIRCUIT

Check voltage between door mirror defogger (driver side) connector and ground.

Door mirror defogger (driver side)		Ground	Condition of rear window defogger switch	Voltage (V) (Approx.)
Connector	Terminal			
D3	7		ON	Battery voltage
			OFF	0

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace the harness or connector.

4.CHECK INTERMITTENT INCIDENT

Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#)

Is the inspection result normal?

>> INSPECTION END

DRIVER SIDE DOOR MIRROR DEFOGGER

< DTC/CIRCUIT DIAGNOSIS >

DRIVER SIDE DOOR MIRROR DEFOGGER

Description

INFOID:0000000006260864

Heats the heating wire with the power supply from the rear window defogger relay to prevent the door mirror from fogging up.

Component Function Check

INFOID:0000000006260865

1. CHECK DRIVER SIDE DOOR MIRROR DEFOGGER

1. Perform Active Test ("REAR DEFOGGER") with CONSULT-III.
2. Touch "ON".
3. Check that the driver side door mirror glass is getting warmer.

Is the inspection result normal?

- YES >> Driver side door mirror defogger is OK.
NO >> Refer to [DEF-18, "Diagnosis Procedure"](#)

Diagnosis Procedure

INFOID:0000000006260866

1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect door mirror (driver side) connector.
3. Turn ignition switch ON.
4. Check voltage between door mirror (driver side) harness connector and ground.

(+) Door mirror (driver side)		(-) Connector	Condition of rear window defogger switch	Voltage (V) (Approx.)
Connector	Terminal			
D3	7	Ground	ON	Battery voltage
			OFF	0

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace harness or connector between fuse block (J/B) and door mirror (driver side).

2. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between door mirror (driver side) harness connector and ground.

Door mirror (driver side)		Ground	Continuity
Connector	Terminal		
D3	19		Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace harness or connector between door mirror (driver side) and ground.

3. CHECK DRIVER SIDE DOOR MIRROR DEFOGGER

Check driver side door mirror defogger.

Refer to [DEF-19, "Component Inspection"](#)

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Replace door mirror (driver side). Refer to [MIR-71, "DOOR MIRROR ASSEMBLY : Removal and Installation"](#)

4. CHECK INTERMITTENT INCIDENT

Check intermittent incident.

DRIVER SIDE DOOR MIRROR DEFOGGER

< DTC/CIRCUIT DIAGNOSIS >

Refer to [GI-44, "Intermittent Incident"](#)

Is the inspection result normal?

>> INSPECTION END

Component Inspection

INFOID:000000006260867

1.CHECK DRIVER SIDE DOOR MIRROR DEFOGGER

1. Turn ignition switch OFF.
2. Disconnect door mirror (driver side) connector.
3. Check continuity between door mirror terminals.

Door mirror (driver side)			Continuity
Connector	Terminal		
D3	7	19	Existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace door mirror glass (driver side). Refer to [MIR-71, "DOOR MIRROR ASSEMBLY : Removal and Installation"](#)

A

B

C

D

E

G

H

I

J

K

DEF

M

N

O

P

PASSENGER SIDE DOOR MIRROR DEFOGGER

< DTC/CIRCUIT DIAGNOSIS >

PASSENGER SIDE DOOR MIRROR DEFOGGER

Description

INFOID:0000000006260868

Heats the heating wire with the power supply from the rear window defogger relay to prevent the door mirror from fogging up.

Component Function Check

INFOID:0000000006260869

1.CHECK PASSENGER SIDE DOOR MIRROR DEFOGGER

1. Perform Active Test ("REAR DEFOGGER") with CONSULT-III.
2. Touch "ON".
3. Check that the passenger side door mirror glass is getting warmer.

Is the inspection result normal?

- YES >> Passenger side door mirror defogger is OK.
NO >> Refer to [DEF-20, "Diagnosis Procedure"](#)

Diagnosis Procedure

INFOID:0000000006260870

1.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect door mirror (passenger side) connector.
3. Turn ignition switch ON.
4. Check voltage between door mirror (passenger side) harness connector and ground.

(+) Door mirror (Passenger side)		(-)	Condition of rear window defogger switch	Voltage (V) (Approx.)
Connector	Terminal			
D43	7	Ground	ON	Battery voltage
			OFF	0

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace harness or connector between fuse block (J/B) and door mirror (passenger side).

2.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between door mirror (passenger side) harness connector and ground.

Door mirror (passenger side)		Ground	Continuity
Connector	Terminal		
D43	19		Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace harness or connector between door mirror (passenger side) and ground.

3.CHECK PASSENGER SIDE DOOR MIRROR DEFOGGER

Check passenger side door mirror defogger.

Refer to [DEF-21, "Component Inspection"](#)

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Replace door mirror (passenger side).Refer to [MIR-71, "DOOR MIRROR ASSEMBLY : Removal and Installation"](#)

4.CHECK INTERMITTENT INCIDENT

PASSENGER SIDE DOOR MIRROR DEFOGGER

< DTC/CIRCUIT DIAGNOSIS >

Check intermittent incident.

Refer to [GI-44, "Intermittent Incident"](#)

>> INSPECTION END

Component Inspection

INFOID:000000006260871

1.CHECK PASSENGER DOOR MIRROR DEFOGGER

1. Turn ignition switch OFF.
2. Disconnect door mirror (passenger side) connector.
3. Check continuity between door mirror terminals.

Door mirror (passenger side)			Continuity
Connector	Terminal		
D43	7	19	Existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace door mirror glass (passenger side). Refer to [MIR-71, "DOOR MIRROR ASSEMBLY : Removal and Installation"](#)

A

B

C

D

E

F

G

H

I

J

K

DEF

M

N

O

P


REAR WINDOW DEFOGGER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

REAR WINDOW DEFOGGER SYSTEM

Wiring Diagram - DEFOGGER SYSTEM -

INFOID:0000000006260872




2010/09/06

JCLWM6176GB

REAR WINDOW DEFOGGER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >



ICL WM6177GB

REAR WINDOW DEFOGGER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

ICLWM6178GB


REAR WINDOW DEFOGGER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

ICL WM6179GB

REAR WINDOW DEFOGGER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >



ICLWM6180GB

REAR WINDOW DEFOGGER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

DEFROGGER		Connector No.	M122	Connector Name	BCM (BODY CONTROL MODULE)	Terminal Color of Wire No.	Signal Name [Specification]	Terminal Color of Wire No.	Signal Name [Specification]
Connector Name				Connector Type	TH4DFB-NH				
Connector No.				Connector Type	TH4DFC-NH				
									
									
									
DEFOGGER		Connector No.	M123	Connector Name	BCM (BODY CONTROL MODULE)	Terminal Color of Wire No.	Signal Name [Specification]	Terminal Color of Wire No.	Signal Name [Specification]
Connector Name				Connector Type	TH4DFB-NH				
									
									
									
									
DEFOGGER		Connector No.	M174	Connector Name	AV CONTROL UNIT	Terminal Color of Wire No.	Signal Name [Specification]	Terminal Color of Wire No.	Signal Name [Specification]
Connector Name				Connector Type	TH32FW-NH				
									
									
									
									
DEFOGGER		Connector No.	M172	Connector Name	AV CONTROL UNIT	Terminal Color of Wire No.	Signal Name [Specification]	Terminal Color of Wire No.	Signal Name [Specification]
Connector Name				Connector Type	TH24FW-NH				
									
									
									
									
DEFOGGER		Connector No.	M125	Connector Name	MULTIFUNCTION SWITCH	Terminal Color of Wire No.	Signal Name [Specification]	Terminal Color of Wire No.	Signal Name [Specification]
Connector Name				Connector Type	TH16FW-NH				
									
									
									
									

JCLWM6181GB

DEF

M

Z

O

P

A

B

C

D

T

G

I

K

M


Z

O

P

REAR WINDOW DEFOGGER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

DEFROGGER		
Connector No.	M180	
Connector Name	AV CONTROL UNIT	
Connector Type	TH32FW-NH	
HS		
Terminal No.	Color of Wire	Signal Name [Specification]
65	LG	PARKING BRAKE
67	BR	COMPOSITE IMAGE SIGNAL GND
68	GR	COMPOSITE IMAGE SIGNAL
71	SHIELD	SHIELD
72	B	MICROPHONE,VSCC
73	R	COMM (CONT-DISP)
74	P	CAN_L
75	LG	AV COMM (L)
76	LG	AV COMM (L)
79	R	ILLUMINATION SIGNAL
80	G	IGNITION
81	SB	REVERSE
82	V	VEHICLE SPEED SIGNAL (B PULSE)
83	SHIELD	SHIELD
87	W	MICROPHONE SIGNAL
88	SHIELD	SHIELD
89	G	COMM (DISP->CONT)
90	L	CAN_H
91	SB	AV COMM (H)
92	SB	AV COMM (H)

JCLWM6182GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION

BCM (BODY CONTROL MODULE)

Reference Value

INFOID:000000006859375

VALUES ON THE DIAGNOSIS TOOL

CONSULT-III MONITOR ITEM

Monitor Item	Condition	Value/Status
FR WIPER HI	Other than front wiper switch HI	Off
	Front wiper switch HI	On
FR WIPER LOW	Other than front wiper switch LO	Off
	Front wiper switch LO	On
FR WASHER SW	Front washer switch OFF	Off
	Front washer switch ON	On
FR WIPER INT	Other than front wiper switch INT/AUTO	Off
	Front wiper switch INT/AUTO	On
FR WIPER STOP	Front wiper is not in STOP position	Off
	Front wiper is in STOP position	On
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	Wiper intermittent dial position
RR WIPER ON	Other than rear wiper switch ON	Off
	Rear wiper switch ON	On
RR WIPER INT	Other than rear wiper switch INT	Off
	Rear wiper switch INT	On
RR WASHER SW	Rear washer switch OFF	Off
	Rear washer switch ON	On
RR WIPER STOP	Rear wiper is in STOP position	Off
	Rear wiper is not in STOP position	On
TURN SIGNAL R	Other than turn signal switch RH	Off
	Turn signal switch RH	On
TURN SIGNAL L	Other than turn signal switch LH	Off
	Turn signal switch LH	On
TAIL LAMP SW	Other than lighting switch 1ST and 2ND	Off
	Lighting switch 1ST or 2ND	On
HI BEAM SW	Other than lighting switch HI	Off
	Lighting switch HI	On
HEAD LAMP SW 1	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
HEAD LAMP SW 2	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
PASSING SW	Other than lighting switch PASS	Off
	Lighting switch PASS	On
AUTO LIGHT SW	Other than lighting switch AUTO	Off
	Lighting switch AUTO	On
FR FOG SW	Front fog lamp switch OFF	Off
	Front fog lamp switch ON	On

A

B

C

D

E

F

G

H

I

J

K

DEF

M

N

O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
RR FOG SW	NOTE: The item is indicated, but not monitored.	Off
DOOR SW-DR	Driver door closed	Off
	Driver door opened	On
DOOR SW-AS	Passenger door closed	Off
	Passenger door opened	On
DOOR SW-RR	Rear RH door closed	Off
	Rear RH door opened	On
DOOR SW-RL	Rear LH door closed	Off
	Rear LH door opened	On
DOOR SW-BK	Back door closed	Off
	Back door opened	On
CDL LOCK SW	Other than power door lock switch LOCK	Off
	Power door lock switch LOCK	On
CDL UNLOCK SW	Other than power door lock switch UNLOCK	Off
	Power door lock switch UNLOCK	On
KEY CYL LK-SW	Other than driver door key cylinder LOCK position	Off
	Driver door key cylinder LOCK position	On
KEY CYL UN-SW	Other than driver door key cylinder UNLOCK position	Off
	Driver door key cylinder UNLOCK position	On
KEY CYL SW-TR	NOTE: The item is indicated, but not monitored.	Off
HAZARD SW	Hazard switch is OFF	Off
	Hazard switch is ON	On
REAR DEF SW NOTE: For models with BOSE audio system this item is not monitored.	Rear window defogger switch OFF	Off
	Rear window defogger switch ON	On
TR CANCEL SW	NOTE: The item is indicated, but not monitored.	Off
TR/BD OPEN SW	Back door opener switch OFF	Off
	While the back door opener switch is turned ON	On
TRNK/HAT MNTR	NOTE: The item is indicated, but not monitored.	Off
RKE-LOCK	LOCK button of Intelligent Key is not pressed	Off
	LOCK button of Intelligent Key is pressed	On
RKE-UNLOCK	UNLOCK button of Intelligent Key is not pressed	Off
	UNLOCK button of Intelligent Key is pressed	On
RKE-TR/BD	BACK DOOR OPEN button of Intelligent Key is not pressed	Off
	BACK DOOR OPEN button of Intelligent Key is pressed	On
RKE-PANIC	PANIC button of Intelligent Key is not pressed	Off
	PANIC button of Intelligent Key is pressed	On
RKE-P/W OPEN	UNLOCK button of Intelligent Key is not pressed	Off
	UNLOCK button of Intelligent Key is pressed and held	On

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
RKE-MODE CHG	LOCK/UNLOCK button of Intelligent Key is not pressed and held simultaneously	Off
	LOCK/UNLOCK button of Intelligent Key is pressed and held simultaneously	On
OPTICAL SENSOR	Bright outside of the vehicle	Close to 5 V
	Dark outside of the vehicle	Close to 0 V
REQ SW -DR	Driver door request switch is not pressed	Off
	Driver door request switch is pressed	On
REQ SW -AS	Passenger door request switch is not pressed	Off
	Passenger door request switch is pressed	On
REQ SW -RR	NOTE: The item is indicated, but not monitored.	Off
REQ SW -RR	NOTE: The item is indicated, but not monitored.	Off
REQ SW -BD/TR	Back door request switch is not pressed	Off
	Back door request switch is pressed	On
PUSH SW	Push-button ignition switch (push switch) is not pressed	Off
	Push-button ignition switch (push switch) is pressed	On
IGN RLY2 -F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
ACC RLY -F/B	NOTE: The item is indicated, but not monitored.	Off
CLUCH SW	NOTE: The item is indicated, but not monitored.	Off
BRAKE SW 1	The brake pedal is depressed when No. 7 fuse is blown	Off
	The brake pedal is not depressed when No. 7 fuse is blown, or No. 7 fuse is normal	On
BRAKE SW 2	The brake pedal is not depressed	Off
	Stop lamp switch 1 signal circuit is normal	On
DETE/CANCL SW	Selector lever in P position	Off
	Selector lever in any position other than P	On
SFT PN/N SW	Selector lever in any position other than P and N	Off
	Selector lever in P or N position	On
S/L -LOCK	NOTE: The item is indicated, but not monitored.	Off
S/L -UNLOCK	NOTE: The item is indicated, but not monitored.	Off
S/L RELAY-F/B	NOTE: The item is indicated, but not monitored.	Off
UNLK SEN -DR	Driver door is unlocked	Off
	Driver door is locked	On
PUSH SW -IPDM	Push-button ignition switch (push-switch) is not pressed	Off
	Push-button ignition switch (push-switch) is pressed	On
IGN RLY1 -F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
DETE SW -IPDM	Selector lever in any position other than P	Off
	Selector lever in P position	On

A

B

C

D

E

F

G

H

I

J

K

DEF

M

N

O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
SFT PN -IPDM	Selector lever in any position other than P and N	Off
	Selector lever in P or N position	On
SFT P -MET	Selector lever in any position other than P	Off
	Selector lever in P position	On
SFT N -MET	Selector lever in any position other than N	Off
	Selector lever in N position	On
ENGINE STATE	Engine stopped	Stop
	While the engine stalls	Stall
	At engine cranking	Crank
	Engine running	Run
S/L LOCK-IPDM	NOTE: The item is indicated, but not monitored.	Off
S/L UNLK-IPDM	NOTE: The item is indicated, but not monitored.	Off
S/L RELAY-REQ	NOTE: The item is indicated, but not monitored.	Off
VEH SPEED 1	While driving	Equivalent to speedometer reading
VEH SPEED 2	While driving	Equivalent to speedometer reading
DOOR STAT-DR	Driver door is locked	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Driver door is unlocked	UNLOCK
DOOR STAT-AS	Passenger door is locked	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Passenger door is unlocked	UNLOCK
ID OK FLAG	Power supply position in LOCK position	Reset
	Power supply position in any position other than LOCK	Set
PRMT ENG STRT	The engine start is prohibited	Reset
	The engine start is permitted	Set
PRMT RKE STRT	NOTE: The item is indicated, but not monitored.	Reset
KEY SW -SLOT	Intelligent Key is not inserted into key slot	Off
	Intelligent Key is inserted into key slot	On
RKE OPE COUN1	During the operation of Intelligent Key	Operation frequency of Intelligent Key
RKE OPE COUN2	NOTE: The item is indicated, but not monitored.	—
CONFIRM ID ALL	The Intelligent Key ID that the key slot receives is not recognized by any Intelligent Key ID registered to BCM.	Yet
	The Intelligent Key ID that the key slot receives is recognized by any Intelligent Key ID registered to BCM.	Done
CONFIRM ID4	The Intelligent Key ID that the key slot receives is not recognized by the fourth Intelligent Key ID registered to BCM.	Yet
	The Intelligent Key ID that the key slot receives is recognized by the fourth Intelligent Key ID registered to BCM.	Done

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
CONFIRM ID3	The Intelligent Key ID that the key slot receives is not recognized by the third Intelligent Key ID registered to BCM.	Yet
	The Intelligent Key ID that the key slot receives is recognized by the third Intelligent Key ID registered to BCM.	Done
CONFIRM ID2	The Intelligent Key ID that the key slot receives is not recognized by the second Intelligent Key ID registered to BCM.	Yet
	The Intelligent Key ID that the key slot receives is recognized by the second Intelligent Key ID registered to BCM.	Done
CONFIRM ID1	The Intelligent Key ID that the key slot receives is not recognized by the first Intelligent Key ID registered to BCM.	Yet
	The Intelligent Key ID that the key slot receives is recognized by the first Intelligent Key ID registered to BCM.	Done
TP 4	The ID of fourth Intelligent Key is not registered to BCM	Yet
	The ID of fourth Intelligent Key is registered to BCM	Done
TP 3	The ID of third Intelligent Key is not registered to BCM	Yet
	The ID of third Intelligent Key is registered to BCM	Done
TP 2	The ID of second Intelligent Key is not registered to BCM	Yet
	The ID of second Intelligent Key is registered to BCM	Done
TP 1	The ID of first Intelligent Key is not registered to BCM	Yet
	The ID of first Intelligent Key is registered to BCM	Done
AIR PRESS FL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front LH tire
AIR PRESS FR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front RH tire
AIR PRESS RR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear RH tire
AIR PRESS RL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear LH tire
ID REGST FL1	ID of front LH tire transmitter is registered	Done
	ID of front LH tire transmitter is not registered	Yet
ID REGST FR1	ID of front RH tire transmitter is registered	Done
	ID of front RH tire transmitter is not registered	Yet
ID REGST RR1	ID of rear RH tire transmitter is registered	Done
	ID of rear RH tire transmitter is not registered	Yet
ID REGST RL1	ID of rear LH tire transmitter is registered	Done
	ID of rear LH tire transmitter is not registered	Yet
WARNING LAMP	Tire pressure indicator OFF	Off
	Tire pressure indicator ON	On
BUZZER	Tire pressure warning alarm is not sounding	Off
	Tire pressure warning alarm is sounding	On

A

B

C

D

E

F

G

H

I

J

K

DEF

M

N


O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

TERMINAL LAYOUT



PHYSICAL VALUES

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
1 (W)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
2 (GR)	Ground	P/W power supply (BAT)	Output	Ignition switch OFF	Battery voltage
3 (L)	Ground	P/W power supply (RAP)	Output	Ignition switch ON	Battery voltage
4 (P)	Ground	Interior room lamp power supply	Output	Interior room lamp battery saver is activated. (Cuts the interior room lamp power supply)	0 V
				Interior room lamp battery saver is not activated. (Outputs the interior room lamp power supply)	Battery voltage
5 (G)	Ground	Passenger door UN- LOCK	Output	Passenger door	UNLOCK (Actuator is activated)
					Other than UNLOCK (Actuator is not activated)
7 (Y)	Ground	Step lamp	Output	Step lamp	ON
					OFF
8 (V)	Ground	All doors LOCK	Output	All doors	LOCK (Actuator is activated)
					Other than LOCK (Actuator is not activated)
9 (G)	Ground	Driver door UNLOCK	Output	Driver door	UNLOCK (Actuator is activated)
					Other than UNLOCK (Actuator is not activated)
10 (P)	Ground	Rear RH door and rear LH door UN- LOCK	Output	Rear RH door and rear LH door	UNLOCK (Actuator is activated)
					Other than UNLOCK (Actuator is not activated)
11 (LG)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
13 (B)	Ground	Ground	—	Ignition switch ON	0 V
14 (O)	Ground	Push-button ignition switch illumination ground	Output	Tail lamp	OFF
					ON
15 (L)	Ground	ACC indicator lamp	Output	Ignition switch	OFF (LOCK and ON indicator lamps are not illuminated.)
					ACC

A

B

C

D

E

F

G

H

I

J

K


DEF

M

N





O

P









BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
17 (G)	Ground	Turn signal RH	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch RH	 PKID0926E 6.5 V
18 (BR)	Ground	Turn signal LH	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch LH	 PKID0926E 6.5 V
19 (Y)	Ground	Room lamp timer control	Output	Interior room lamp	OFF	Battery voltage
					ON	0 V
23 (BR)	Ground	Back door open	Output	Back door	OPEN (Back door opener actuator is activated)	Battery voltage
					Other than OPEN (Back door opener actuator is not activated)	0 V
26 (G)	Ground	Rear wiper	Output	Rear wiper	OFF (Stopped)	0 V
					ON (Operated)	Battery voltage
34 (B)	Ground	Luggage room anten- na (-)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compart- ment	 JMKIA0062GB
					When Intelligent Key is not in the passenger compart- ment	 JMKIA0063GB

BCM (BODY CONTROL MODULE)





< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)		
	+	-	Signal name	Input/ Output		
35 (W)	Ground	Luggage room antenna (+)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compartment	 (V) 15 10 5 0 1 s <small>JMKIA0062GB</small>
					When Intelligent Key is not in the passenger compartment	 (V) 15 10 5 0 1 s <small>JMKIA0063GB</small>
38 (L)	Ground	Rear bumper antenna (-)	Output	When the back door request switch is operated with ignition switch OFF	When Intelligent Key is in the antenna detection area	 (V) 15 10 5 0 1 s <small>JMKIA0062GB</small>
					When Intelligent Key is not in the antenna detection area	 (V) 15 10 5 0 1 s <small>JMKIA0063GB</small>
39 (BR)	Ground	Rear bumper antenna (+)	Output	When the back door request switch is operated with ignition switch OFF	When Intelligent Key is in the antenna detection area	 (V) 15 10 5 0 1 s <small>JMKIA0062GB</small>
					When Intelligent Key is not in the antenna detection area	 (V) 15 10 5 0 1 s <small>JMKIA0063GB</small>
47 (L)	Ground	Ignition relay (IPDM E/R) control	Output	Ignition switch	OFF or ACC	Battery voltage
					ON	0 V

A
B
C
D
E
F
G
H
I
J
K
DEF
M
N
O
P





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
52 (R)	Ground	Starter relay control	Output	Ignition switch ON	When selector lever is in P or N position	Battery voltage
					When selector lever is not in P or N position	0.3 V
				Ignition switch OFF		0 V
60 (BR)	Ground	Push-button ignition switch (push switch)	Input	Push-button igni- tion switch (push switch)	Pressed	0 V
					Not pressed	Battery voltage
61 (R)	Ground	Back door request switch	Input	Back door re- quest switch	ON (Pressed)	0 V
					OFF (Not pressed)	 <small>JPMIA0016GB</small> 1.0 V
64 (GR)	Ground	Warning buzzer	Output	Warning buzzer	Sounding	0 V
					Not sounding	Battery voltage
65 (O)	Ground	Rear wiper stop posi- tion	Input	Rear wiper	In stop position	 <small>JPMIA0016GB</small> 1.0 V
					Not in stop position	0 V
66 (Y)	Ground	Back door switch	Input	Back door switch	OFF (When back door closes)	 <small>JPMIA0011GB</small> 11.8 V
					ON (When back door opens)	0 V
67 (LG)	Ground	Back door opener switch	Input	Back door opener switch	Pressed	0 V
					Not pressed	 <small>JPMIA0011GB</small> 11.8 V

BCM (BODY CONTROL MODULE)





< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	+	-		
68 (W)	Ground	Rear RH door switch	Input	<p>Rear RH door switch</p> <p>OFF (When rear RH door closes)</p> 
				<p>ON (When rear RH door opens)</p> <p>0 V</p>
69 (R)	Ground	Rear LH door switch	Input	<p>Rear LH door switch</p> <p>OFF (When rear LH door closes)</p> 
				<p>ON (When rear LH door opens)</p> <p>0 V</p>
72 (B)	Ground	Room antenna (-) (Center console)	Output	<p>Ignition switch OFF</p> <p>When Intelligent Key is in the passenger compartment</p> 
				<p>When Intelligent Key is not in the passenger compartment</p> 

A
B
C
D
E
F
G
H
I
J
K
DEF
M
N
O
P





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)			
	Signal name	Input/ Output					
+	-						
73 (W)	Ground	Room antenna (+) (Center console)	Output Ignition switch OFF	When Intelligent Key is in the passenger compart- ment			
				 JMKA0062GB			
74 (Y)	Ground	Passenger door anten- na (-)	Output When the pas- senger door re- quest switch is operated with ig- nition switch OFF	When Intelligent Key is not in the passenger compart- ment			
				 JMKA0063GB			
75 (LG)	Ground	Passenger door anten- na (+)	Output When the pas- senger door re- quest switch is operated with ig- nition switch OFF	When Intelligent Key is in the antenna detection area			
				 JMKA0062GB			
				When Intelligent Key is not in the antenna detection area			
				 JMKA0063GB			







BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	A B C D E F G H I J K DEF M N O P	
	+	-	Signal name	Input/ Output		
76 (V)	Ground	Driver door antenna (-)	Output	When Intelligent Key is in the antenna detection area	(V) 15 10 5 0  JMKA0062GB	A B C D E F G H I J K DEF M N O P
				When the driver door request switch is oper- ated with ignition switch OFF	(V) 15 10 5 0  JMKA0063GB	
77 (P)	Ground	Driver door antenna (+)	Output	When Intelligent Key is in the antenna detection area	(V) 15 10 5 0  JMKA0062GB	A B C D E F G H I J K DEF M N O P
				When the driver door request switch is oper- ated with ignition switch OFF	(V) 15 10 5 0  JMKA0063GB	
80 (SB)	Ground	NATS antenna amp.	Input/ Output	During waiting	Ignition switch is pressed while inserting Intelligent Key into the key slot.	Just after pressing ignition switch. Pointer of tester should move.
81 (O)	Ground	NATS antenna amp.	Input/ Output	During waiting	Ignition switch is pressed while inserting Intelligent Key into the key slot.	Just after pressing ignition switch. Pointer of tester should move.
82 (BR)	Ground	Ignition relay [fuse block (J/B)] control	Output	Ignition switch	OFF or ACC	0 V
					ON	Battery voltage






BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
83 (P)	Ground	Remote keyless entry receiver communication	Input/ Output	<p>During waiting</p>  <p>JMKIA0064GB</p>
				<p>When operating either button on Intelligent Key</p>  <p>JMKIA0065GB</p>
87 (R)	Ground	Combination switch INPUT 5	Input	<p>All switches OFF (Wiper intermittent dial 4)</p>  <p>JPMIA0041GB</p> <p>1.4 V</p>
				<p>Front fog lamp switch ON (Wiper intermittent dial 4)</p>  <p>JPMIA0037GB</p> <p>1.3 V</p>
				<p>Rear wiper switch ON (Wiper intermittent dial 4)</p>  <p>JPMIA0039GB</p> <p>1.3 V</p>
				<p>Any of the conditions below with all switches OFF</p> <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 6 • Wiper intermittent dial 7  <p>JPMIA0040GB</p> <p>1.3 V</p>

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


Terminal No. (Wire color)	Description		Condition	Value (Approx.)	
	Signal name	Input/ Output			
88 (GR)	Ground	Combination switch INPUT 3	Input	All switches OFF (Wiper intermittent dial 4)	 JPMIA0041GB 1.4 V
				Lighting switch HI (Wiper intermittent dial 4)	 JPMIA0036GB 1.3 V
				Lighting switch 2ND (Wiper intermittent dial 4)	 JPMIA0037GB 1.3 V
				Rear washer switch ON (Wiper intermittent dial 4)	 JPMIA0039GB 1.3 V
				Any of the conditions below with all switches OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 3 	 JPMIA0040GB 1.3 V
90 (P)	Ground	CAN - L	Input/ Output	—	—
91 (L)	Ground	CAN - H	Input/ Output	—	—

A
B
C
D
E
F
G
H
I
J
K
DEF
M
N
O
P


BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
92 (R)	Ground	Key slot illumination	Output	OFF Key slot illumination Blinking ON
93 (P)	Ground	ON indicator lamp	Output	OFF (LOCK and ACC indicator lamps are not illuminated.) ON
95 (L)	Ground	ACC relay control	Output	OFF ACC or ON
96 (Y)	Ground	CVT shift selector (detention switch) power supply	Output	—
99 (V)	Ground	Selector lever P position switch	Input	Selector lever P position Any position other than P
100 (P)	Ground	Passenger door request switch	Input	ON (Pressed) Passenger door request switch OFF (Not pressed)
101 (W)	Ground	Driver door request switch	Input	ON (Pressed) Driver door request switch OFF (Not pressed)
102 (Y)	Ground	Blower fan motor relay control	Output	Ignition switch OFF or ACC ON
103 (L)	Ground	Remote keyless entry receiver power supply	Output	Ignition switch OFF



JPMIA0015GB








JPMIA0016GB



JPMIA0016GB






BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	A B C D E F G H I J K DEF M N O P
	Signal name	Input/ Output			
107 (O)	Ground	Combination switch INPUT 1	Combination switch (Wiper intermit- tent dial 4)	All switches OFF	 JPMIA0041GB 1.4 V
				Turn signal switch LH	 JPMIA0037GB 1.3 V
				Turn signal switch RH	 JPMIA0036GB 1.3 V
				Front wiper switch LO	 JPMIA0038GB 1.3 V
				Front washer switch ON	 JPMIA0039GB 1.3 V








BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
108 (P)	Ground	Combination switch INPUT 4	Input Combination switch	All switches OFF (Wiper intermittent dial 4)
				 1.4 V JPMIA0041GB
				Lighting switch AUTO (Wiper intermittent dial 4)
				 1.3 V JPMIA0038GB
				Lighting switch 1ST (Wiper intermittent dial 4)
				 1.3 V JPMIA0036GB
				Rear wiper switch INT (Wiper intermittent dial 4)
				 1.3 V JPMIA0040GB
				Any of the conditions below with all switches OFF • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6
				 1.3 V JPMIA0039GB




BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
109 (SB)	Ground	Combination switch INPUT 2	Input Combination switch (Wiper intermit- tent dial 4)	All switches OFF  1.4 V JPMIA0041GB
				Lighting switch PASS  1.3 V JPMIA0037GB
				Lighting switch 2ND  1.3 V JPMIA0036GB
				Front wiper switch INT/ AUTO  1.3 V JPMIA0038GB
				Front wiper switch HI  1.3 V JPMIA0040GB
110 (G)	Ground	Hazard switch	Input Hazard switch	ON  0 V
				OFF  1.1 V JPMIA0012GB




BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
112 (R)	Ground	Rain sensor serial link	Input/ Output	Ignition switch ON
				 <small>JPMIA0156GB</small> 8.7 V
113 (O)	Ground	Optical sensor	Input	Ignition switch ON
				When bright outside of the vehicle
116 (GR)	Ground	Stop lamp switch 1	Input	When dark outside of the vehicle
				Battery voltage
118 (L)	Ground	Stop lamp switch 2	Input	OFF (Brake pedal is not depressed)
				ON (Brake pedal is depressed)
119 (W)	Ground	Front door lock assembly driver side (Unlock sensor)	Input	Driver door
				 <small>JPMIA0012GB</small> 1.1 V
121 (Y)	Ground	Key slot switch	Input	LOCK status (unlock sensor switch OFF)
				UNLOCK status (unlock sensor switch ON)
123 (G)	Ground	IGN feedback	Input	When Intelligent Key is inserted into key slot
				0 V
124 (R)	Ground	Passenger door switch	Input	Ignition switch
				 <small>JPMIA0011GB</small> 11.8 V
				OFF (When passenger door closes)
				ON (When passenger door opens)
				0 V

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	+	-		
130 (BR)	Ground	Rear window defogger switch	Input	 JPMIA0012GB 1.1 V
				Rear window defogger switch ON 0 V
132 (G)	Ground	Power window switch communication	Input/ Output	 JPMIA0013GB 10.2 V
				Ignition switch OFF or ACC Battery voltage
133 (W)	Ground	Push-button ignition switch illumination	Output	ON (When tail lamps OFF)
				NOTE: The pulse width of this wave is varied by the illumination brightening/dimming level.  JPMIA0159GB
				OFF 0 V
134 (R)	Ground	LOCK indicator lamp	Output	OFF (ACC and ON indicator lamps are not illuminated.) ON
				Battery voltage 0 V
137 (P)	Ground	Receiver and sensor ground	Input	Ignition switch ON 0 V
138 (V)	Ground	Receiver and sensor power supply	Output	OFF ACC or ON 5.0 V

A

B

C

D

E

F

G

H

I

J

K

DEF

M

N

O

P





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
139 (O)	Ground	Tire pressure receiver communication	Input/ Output	Ignition switch ON
140 (GR)	Ground	Selector lever P/N position	Input	Selector lever
141 (O)	Ground	Security indicator	Output	Security indicator
142 (L)	Ground	Combination switch OUTPUT 5	Output	Combination switch (Wiper intermittent dial 4)
143 (W)	Ground	Combination switch OUTPUT 1	Output	Combination switch

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


Terminal No. (Wire color)	Description		Condition	Value (Approx.)	A B C D E F G H I J K DEF M N O P	
	+	-	Signal name	Input/ Output		
144 (P)	Ground	Combination switch OUTPUT 2	Output	Combination switch	All switches OFF (Wiper intermittent dial 4)	0 V
					Front washer switch ON (Wiper intermittent dial 4)	
					Rear wiper switch ON (Wiper intermittent dial 4)	
					Rear washer switch ON (Wiper intermittent dial 4)	
					Any of the conditions below with all switches OFF • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6	 <small>JPMIA0033GB</small> 10.7 V
145 (V)	Ground	Combination switch OUTPUT 3	Output	Combination switch (Wiper intermittent dial 4)	All switches OFF	0 V
					Front wiper switch INT/AUTO	
					Front wiper switch LO	
					Lighting switch AUTO	 <small>JPMIA0034GB</small> 10.7 V
146 (Y)	Ground	Combination switch OUTPUT 4	Output	Combination switch (Wiper intermittent dial 4)	All switches OFF	0 V
					Front fog lamp switch ON	
					Lighting switch 2ND	
					Lighting switch PASS	
					Turn signal switch LH	 <small>JPMIA0035GB</small> 10.7 V
150 (SB)	Ground	Driver door switch	Input	Driver door switch	OFF (When driver door closes)	 <small>JPMIA0011GB</small> 11.8 V
					ON (When driver door opens)	0 V
151 (G)	Ground	Rear window defogger relay control	Output	Rear window de-fogger	Active	0 V
					Not activated	Battery voltage

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Wiring Diagram - BCM -

INFOID:000000006859376




JCMWN0014GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

: Except for Mexico
 : With power seat without automatic drive positioner

* This connector is not shown in "Harness Layout".




JCMWN0015GB

A B C D E F G H I J K L M O P



DEF

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >



* : This connector is not shown in "Harness Layout".




JCMWN0016GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

: With rain sensor
 : With xenon headlamp
 : Without xenon headlamp




JCMWN0017GB

A B C D E F G H I J K L M O P

DEF

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >




JCMWN0018GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)



Connector No.	MI19	BCM (BODY CONTROL MODULE)
Connector Name	COMBINATION SWITCH	BCM (BODY CONTROL MODULE)
Connector Type	TH40FV-CS	TH40FV-NH

Connector No.	M119	BCM (BODY CONTROL MODULE)
Connector Name	COMBINATION SWITCH	BCM (BODY CONTROL MODULE)
Connector Type	TH40FV-CS	TH40FV-NH

Terminal No.	BR	IGN RELAY (F/B) CONT
82	P	KEYLESS ENTRY RECEIVER SIGNAL
83	R	COMBI SW INPUT 5
87	GR	COMBI SW INPUT 3
88	P	CAN-L
90	P	CAN-H
91	L	KEY SLOT ILL
92	R	ON IND
93	P	ACC RELAY CONT
95	L	CVT SHIFT SELECTOR POWER SUPPLY
96	V	SHIFT P
99	P	PASSENGER DOOR REQUEST SW
100	W	DRIVER DOOR REQUEST SW
101	Y	BLOWER FAN MOTOR RELAY CONT
102	B	KEYLESS ENTRY RECEIVER POWER SUPPLY
103	L	COMBI SW INPUT 1
107	O	COMBI SW INPUT 1+
108	P	COMBI SW INPUT 4
109	SE	COMBI SW INPUT 2
110	G	HAZARD SW

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
4	P	INTERIOR ROOM AMP POWER SUPPLY	34	B	LUGGAGE ROOM ANT -
5	G	PASSENGER DOOR UNLOCK OUTPUT	35	W	LUGGAGE ROOM ANT +
7	Y	STEP LAMP OUTPUT	38	L	REAR BUMPER ANT -
8	V	ALL DOOR FUEL LID LOCK OUTPUT	39	BR	REAR BUMPER ANT +
9	G	DRIVER DOOR FUEL LID UNLOCK OUTPUT	47	L	IGN RELAY PDME/R CONT
10	P	REAR DOOR UNLOCK OUTPUT	52	R	STARTER RELAY CONT
11	LG	BAT (FUSE)	60	BR	EXTRA IN 2
13	B	GRID	61	R	BACK DOOR OPENER REQUEST SW
14	O	PUSH-BUTTON GAUTON SW ILL GND	64	GR	REQUEST SW BUZZER
15	L	ACC IND	65	O	REAR WIPER STOP POSITION
17	G	TURN SIGNAL RH	66	Y	BLACK DOOR SW
18	BR	TURN SIGNAL LH	67	LG	BACK DOOR UNLOCK SW
19	Y	ROOM LAMP-TIMER CONTROL	68	W	REAR RH DOOR SW
20	P	OUTPUT 2	69	R	REAR LH DOOR SW

Connector No.	MI19	BCM (BODY CONTROL MODULE)
Connector Name	COMBINATION SWITCH	BCM (BODY CONTROL MODULE)
Connector Type	TH40FV-CS	TH40FV-NH

Connector No.	M119	BCM (BODY CONTROL MODULE)
Connector Name	COMBINATION SWITCH	BCM (BODY CONTROL MODULE)
Connector Type	TH40FV-CS	TH40FV-NH

Terminal No.	BR	IGN RELAY (F/B) CONT
82	P	KEYLESS ENTRY RECEIVER SIGNAL
83	R	COMBI SW INPUT 5
87	GR	COMBI SW INPUT 3
88	P	CAN-L
90	P	CAN-H
91	L	KEY SLOT ILL
92	R	ON IND
93	P	ACC RELAY CONT
95	L	CVT SHIFT SELECTOR POWER SUPPLY
96	V	SHIFT P
99	P	PASSENGER DOOR REQUEST SW
100	W	DRIVER DOOR REQUEST SW
101	Y	BLOWER FAN MOTOR RELAY CONT
102	B	KEYLESS ENTRY RECEIVER POWER SUPPLY
103	L	COMBI SW INPUT 1
107	O	COMBI SW INPUT 1+
108	P	COMBI SW INPUT 4
109	SE	COMBI SW INPUT 2
110	G	HAZARD SW

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
4	P	INTERIOR ROOM AMP POWER SUPPLY	34	B	LUGGAGE ROOM ANT -
5	G	PASSENGER DOOR UNLOCK OUTPUT	35	W	LUGGAGE ROOM ANT +
7	Y	STEP LAMP OUTPUT	38	L	REAR BUMPER ANT -
8	V	ALL DOOR FUEL LID LOCK OUTPUT	39	BR	REAR BUMPER ANT +
9	G	DRIVER DOOR FUEL LID UNLOCK OUTPUT	47	L	IGN RELAY PDME/R CONT
10	P	REAR DOOR UNLOCK OUTPUT	52	R	STARTER RELAY CONT
11	LG	BAT (FUSE)	60	BR	EXTRA IN 2
13	B	GRID	61	R	BACK DOOR OPENER REQUEST SW
14	O	PUSH-BUTTON GAUTON SW ILL GND	64	GR	REQUEST SW BUZZER
15	L	ACC IND	65	O	REAR WIPER STOP POSITION
17	G	TURN SIGNAL RH	66	Y	BLACK DOOR SW
18	BR	TURN SIGNAL LH	67	LG	BACK DOOR UNLOCK SW
19	Y	ROOM LAMP-TIMER CONTROL	68	W	REAR RH DOOR SW
20	P	OUTPUT 2	69	R	REAR LH DOOR SW

Connector No.	MI19	BCM (BODY CONTROL MODULE)
Connector Name	COMBINATION SWITCH	BCM (BODY CONTROL MODULE)
Connector Type	TH40FV-CS	TH40FV-NH

Terminal No.	BR	IGN RELAY (F/B) CONT
82	P	KEYLESS ENTRY RECEIVER SIGNAL
83	R	COMBI SW INPUT 5
87	GR	COMBI SW INPUT 3
88	P	CAN-L
90	P	CAN-H
91	L	KEY SLOT ILL
92	R	ON IND
93	P	ACC RELAY CONT
95	L	CVT SHIFT SELECTOR POWER SUPPLY
96	V	SHIFT P
99	P	PASSENGER DOOR REQUEST SW
100	W	DRIVER DOOR REQUEST SW
101	Y	BLOWER FAN MOTOR RELAY CONT
102	B	KEYLESS ENTRY RECEIVER POWER SUPPLY
103	L	COMBI SW INPUT 1
107	O	COMBI SW INPUT 1+
108	P	COMBI SW INPUT 4
109	SE	COMBI SW INPUT 2
110	G	HAZARD SW

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
4	P	INTERIOR ROOM AMP POWER SUPPLY	34	B	LUGGAGE ROOM ANT -
5	G	PASSENGER DOOR UNLOCK OUTPUT	35	W	LUGGAGE ROOM ANT +
7	Y	STEP LAMP OUTPUT	38	L	REAR BUMPER ANT -
8	V	ALL DOOR FUEL LID LOCK OUTPUT	39	BR	REAR BUMPER ANT +
9	G	DRIVER DOOR FUEL LID UNLOCK OUTPUT	47	L	IGN RELAY PDME/R CONT
10	P	REAR DOOR UNLOCK OUTPUT	52	R	STARTER RELAY CONT
11	LG	BAT (FUSE)	60	BR	EXTRA IN 2
13	B	GRID	61	R	BACK DOOR OPENER REQUEST SW
14	O	PUSH-BUTTON GAUTON SW ILL GND	64	GR	REQUEST SW BUZZER
15	L	ACC IND	65	O	REAR WIPER STOP POSITION
17	G	TURN SIGNAL RH	66	Y	BLACK DOOR SW
18	BR	TURN SIGNAL LH	67	LG	BACK DOOR UNLOCK SW
19	Y	ROOM LAMP-TIMER CONTROL	68	W	REAR RH DOOR SW
20	P	OUTPUT 2	69	R	REAR LH DOOR SW

Connector No.	M119	BCM (BODY CONTROL MODULE)
Connector Name	COMBINATION SWITCH	BCM (BODY CONTROL MODULE)
Connector Type	TH40FV-CS	TH40FV-NH

Terminal No.	BR	IGN RELAY (F/B) CONT
82	P	KEYLESS ENTRY RECEIVER SIGNAL
83	R	COMBI SW INPUT 5
87	GR	COMBI SW INPUT 3
88	P	CAN-L
90	P	CAN-H
91	L	KEY SLOT ILL
92	R	ON IND
93	P	ACC RELAY CONT
95	L	CVT SHIFT SELECTOR POWER SUPPLY
96	V	SHIFT P
99	P	PASSENGER DOOR REQUEST SW
100	W	DRIVER DOOR REQUEST SW
101	Y	BLOWER FAN MOTOR RELAY CONT
102	B	KEYLESS ENTRY RECEIVER POWER SUPPLY
103	L	COMBI SW INPUT 1
107	O	COMBI SW INPUT 1+
108	P	COMBI SW INPUT 4
109	SE	COMBI SW INPUT 2
110	G	HAZARD SW

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
4	P	INTERIOR ROOM AMP POWER SUPPLY	34	B	LUGGAGE ROOM ANT -
5	G	PASSENGER DOOR UNLOCK OUTPUT	35	W	LUGGAGE ROOM ANT +
7	Y	STEP LAMP OUTPUT	38	L	REAR BUMPER ANT -
8	V	ALL DOOR FUEL LID LOCK OUTPUT	39	BR	REAR BUMPER ANT +
9	G	DRIVER DOOR FUEL LID UNLOCK OUTPUT	47	L	IGN RELAY PDME/R CONT
10	P	REAR DOOR UNLOCK OUTPUT	52	R	STARTER RELAY CONT
11	LG	BAT (FUSE)	60	BR	EXTRA IN 2
13	B	GRID	61	R	BACK DOOR OPENER REQUEST SW
14	O	PUSH-BUTTON GAUTON SW ILL GND	64	GR	REQUEST SW BUZZER
15	L	ACC IND	65	O	REAR WIPER STOP POSITION
17	G	TURN SIGNAL RH	66	Y	BLACK DOOR SW
18	BR	TURN SIGNAL LH	67	LG	BACK DOOR UNLOCK SW
19	Y	ROOM LAMP-TIMER CONTROL	68	W	REAR RH DOOR SW
20	P	OUTPUT 2	69	R	REAR LH DOOR SW

Connector No.	M119	BCM (BODY CONTROL MODULE)
Connector Name	COMBINATION SWITCH	BCM (BODY CONTROL MODULE)
Connector Type	TH40FV-CS	TH40FV-NH

Terminal No.	BR	IGN RELAY (F/B) CONT
82	P	KEYLESS ENTRY RECEIVER SIGNAL
83	R	COMBI SW INPUT 5
87	GR	COMBI SW INPUT 3
88	P	CAN-L
90	P	CAN-H
91	L	KEY SLOT ILL
92	R	ON IND
93	P	ACC RELAY CONT
95	L	CVT SHIFT SELECTOR POWER SUPPLY
96	V	SHIFT P
99	P	PASSENGER DOOR REQUEST SW
100	W	DRIVER DOOR REQUEST SW
101	Y	BLOWER FAN MOTOR RELAY CONT
102	B	KEYLESS ENTRY RECEIVER POWER SUPPLY
103	L	COMBI SW INPUT 1
107	O	COMBI SW INPUT 1+
108	P	COMBI SW INPUT 4
109	SE	COMBI SW INPUT 2
110	G	HAZARD SW

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]

<tbl_r cells="6" ix="4" maxcspan="1" maxrspan="1

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)	
Connector No.	M12/3
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FG-NH

Terminal No.	Color of Wire	Signal Name [Specification]
112	R	RAIN SENSOR SERIAL LINK
113	O	OPTICAL SENSOR
116	GR	FUSE CHECK
118	L	STOP LAMP SW
119	W	DR DOOR UNLOCK SENSOR
121	Y	KEY SLOT SW
123	G	IGN FB
124	R	PASSENGER DOOR SW
130	BR	REAR DEFOGGER SW
132	G	POWER WINDOW SW COMM
133	W	PUSH-BUTTON IGNITION SW/ILL POWER
134	R	LOCK RD
137	P	RECEIVER / SENSOR GND
138	V	RECEIVER / SENSOR POWER SUPPLY
139	O	TIRE PRESS RECEIVER SIGNAL
140	GR	SHIFT M.V.P
141	O	SECURITY INDICATOR OUTPUT
142	L	COMBI SW OUTPUT 5
143	W	COMBI SW OUTPUT 1
144	P	COMBI SW OUTPUT 2
145	V	COMBI SW OUTPUT 3
146	Y	COMBI SW OUTPUT 4
150	SB	DRIVER DOOR SW
151	G	REAR WINDOW DEFROGGER RELAY

JCMWN0020GB

INFOID:000000006859377

Fail-safe

FAIL-SAFE CONTROL BY DTC

BCM performs fail-safe control when any DTC are detected.

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Display contents of CONSULT	Fail-safe	Cancellation
B2190: NATS ANTENNA AMP	Inhibit engine cranking	Erase DTC
B2191: DIFFERENCE OF KEY	Inhibit engine cranking	Erase DTC
B2192: ID DISCORD BCM-ECM	Inhibit engine cranking	Erase DTC
B2193: CHAIN OF BCM-ECM	Inhibit engine cranking	Erase DTC
B2195: ANTI SCANNING	Inhibit engine cranking	Ignition switch ON → OFF
B2560: STARTER CONT RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent • Starter control relay signal • Starter relay status signal
B2607: S/L RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent • Steering lock relay signal (Request signal) • Steering lock relay signal (Condition signal)
B2608: STARTER RELAY	Inhibit engine cranking	500 ms after the following signal communication status becomes consistent • Starter motor relay control signal • Starter relay status signal (CAN)
B260A: IGNITION RELAY	Inhibit engine cranking	500 ms after the following conditions are fulfilled • IGN relay (IPDM E/R) control signal: OFF (Battery voltage) • Ignition ON signal (CAN to IPDM E/R): OFF (Request signal) • Ignition ON signal (CAN from IPDM E/R): OFF (Condition signal)
B260F: ENG STATE SIG LOST	Maintains the power supply position attained at the time of DTC detection	When any of the following conditions are fulfilled • Power position changes to ACC • Receives engine status signal (CAN)
B2617: STARTER RELAY CIRC	Inhibit engine cranking	1 second after the starter motor relay control inside BCM becomes normal
B2618: BCM	Inhibit engine cranking	1 second after the ignition relay (IPDM E/R) control inside BCM becomes normal
B261E: VEHICLE TYPE	Inhibit engine cranking	BCM initialization

HIGH FLASHER OPERATION

BCM detects the turn signal lamp circuit status by the current value.

BCM increases the turn signal lamp blinking speed if the bulb or harness open is detected with the turn signal lamp operating.

NOTE:

The blinking speed is normal while activating the hazard warning lamp.

DEF

FAIL-SAFE CONTROL BY RAIN SENSOR MALFUNCTION

- BCM judges the rain sensor serial link error by the rain sensor serial link condition and detects the rain sensor malfunction by rain sensor malfunction signal.
- When BCM detects the rain sensor serial link error or the rain sensor malfunction while front wiper AUTO operation, BCM operates a fail-safe control.

NOTE:

If rain sensor malfunction is detected when ignition switch is turned OFF ⇒ ON and front wiper switch is INT/AUTO position, BCM operates a fail-safe control.

M

N

O

P

REAR WIPER MOTOR PROTECTION

BCM detects the rear wiper stopping position according to the rear wiper stop position signal.

When the rear wiper stop position signal does not change for more than 5 seconds while driving the rear wiper, BCM stops power supply to protect the rear wiper motor.

Condition of cancellation

- More than 1 minute is passed after the rear wiper stop.
- Turn rear wiper switch OFF.
- Operate the rear wiper switch or rear washer switch.

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

DTC Inspection Priority Chart

INFOID:000000006859378

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	DTC
1	B2562: LOW VOLTAGE
2	<ul style="list-style-type: none">• U1000: CAN COMM• U1010: CONTROL UNIT(CAN)
3	<ul style="list-style-type: none">• B2190: NATS ANTENNA AMP• B2191: DIFFERENCE OF KEY• B2192: ID DISCORD BCM-ECM• B2193: CHAIN OF BCM-ECM• B2195: ANTI SCANNING
4	<ul style="list-style-type: none">• B2553: IGNITION RELAY• B2555: STOP LAMP• B2556: PUSH-BTN IGN SW• B2557: VEHICLE SPEED• B2560: STARTER CONT RELAY• B2601: SHIFT POSITION• B2602: SHIFT POSITION• B2603: SHIFT POSI STATUS• B2604: PNP SW• B2605: PNP SW• B2608: STARTER RELAY• B260A: IGNITION RELAY• B260F: ENG STATE SIG LOST• B2614: ACC RELAY CIRC• B2615: BLOWER RELAY CIRC• B2616: IGN RELAY CIRC• B2617: STARTER RELAY CIRC• B2618: BCM• B261A: PUSH-BTN IGN SW• B261E: VEHICLE TYPE• B26EA: KEY REGISTRATION• C1729: VHCL SPEED SIG ERR• U0415: VEHICLE SPEED SIG
5	<ul style="list-style-type: none">• C1704: LOW PRESSURE FL• C1705: LOW PRESSURE FR• C1706: LOW PRESSURE RR• C1707: LOW PRESSURE RL• C1708: [NO DATA] FL• C1709: [NO DATA] FR• C1710: [NO DATA] RR• C1711: [NO DATA] RL• C1716: [PRESSDATA ERR] FL• C1717: [PRESSDATA ERR] FR• C1718: [PRESSDATA ERR] RR• C1719: [PRESSDATA ERR] RL• C1734: CONTROL UNIT
6	<ul style="list-style-type: none">• B2622: INSIDE ANTENNA• B2623: INSIDE ANTENNA

DTC Index

INFOID:000000006859379

NOTE:

The details of time display are as follows.

- CRNT: A malfunction is detected now.
- PAST: A malfunction was detected in the past.

IGN counter is displayed on Freeze Frame Data. For details of Freeze Frame Data, refer to [BCS-18, "COMMON ITEM : CONSULT-III Function \(BCM - COMMON ITEM\)"](#).

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
No DTC is detected. further testing may be required.	—	—	—	—	—
U1000: CAN COMM	—	—	—	—	BCS-38
U1010: CONTROL UNIT(CAN)	—	—	—	—	BCS-39
U0415: VEHICLE SPEED SIG	—	—	—	—	BCS-40
B2190: NATS ANTENNA AMP	×	—	—	—	SEC-42
B2191: DIFFERENCE OF KEY	×	—	—	—	SEC-45
B2192: ID DISCORD BCM-ECM	×	—	—	—	SEC-46
B2193: CHAIN OF BCM-ECM	×	—	—	—	SEC-48
B2195: ANTI SCANNING	×	—	—	—	SEC-49
B2553: IGNITION RELAY	—	×	—	—	PCS-48
B2555: STOP LAMP	—	×	—	—	SEC-50
B2556: PUSH-BTN IGN SW	—	×	×	—	SEC-52
B2557: VEHICLE SPEED	×	×	×	—	SEC-54
B2560: STARTER CONT RELAY	×	×	×	—	SEC-55
B2562: LOW VOLTAGE	—	×	—	—	BCS-41
B2601: SHIFT POSITION	×	×	×	—	SEC-56
B2602: SHIFT POSITION	×	×	×	—	SEC-59
B2603: SHIFT POSI STATUS	×	×	×	—	SEC-61
B2604: PNP SW	×	×	×	—	SEC-64
B2605: PNP SW	×	×	×	—	SEC-66
B2608: STARTER RELAY	×	×	×	—	SEC-68
B260A: IGNITION RELAY	×	×	×	—	PCS-50
B260F: ENG STATE SIG LOST	×	×	×	—	SEC-70
B2614: ACC RELAY CIRC	—	×	×	—	PCS-52
B2615: BLOWER RELAY CIRC	—	×	×	—	PCS-55
B2616: IGN RELAY CIRC	—	×	×	—	PCS-58
B2617: STARTER RELAY CIRC	×	×	×	—	SEC-72
B2618: BCM	×	×	×	—	PCS-61
B261A: PUSH-BTN IGN SW	—	×	×	—	SEC-75
B261E: VEHICLE TYPE	×	×	×	(Turn ON for 15 seconds)	SEC-78
B2622: INSIDE ANTENNA	—	×	—	—	DLK-91
B2623: INSIDE ANTENNA	—	×	—	—	DLK-93
B26EA: KEY REGISTRATION	—	×	×	(Turn ON for 15 seconds)	SEC-71
C1704: LOW PRESSURE FL	—	—	—	—	WT-23
C1705: LOW PRESSURE FR	—	—	—	—	
C1706: LOW PRESSURE RR	—	—	—	—	
C1707: LOW PRESSURE RL	—	—	—	—	

A
B
C
D
E
F
G
H
I
J
K
DEF
M
N
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
C1708: [NO DATA] FL	—	—	—	×	WT-25
C1709: [NO DATA] FR	—	—	—	×	
C1710: [NO DATA] RR	—	—	—	×	
C1711: [NO DATA] RL	—	—	—	×	
C1716: [PRESSDATA ERR] FL	—	—	—	×	WT-28
C1717: [PRESSDATA ERR] FR	—	—	—	×	
C1718: [PRESSDATA ERR] RR	—	—	—	×	
C1719: [PRESSDATA ERR] RL	—	—	—	×	
C1729: VHCL SPEED SIG ERR	—	—	—	×	WT-29
C1734: CONTROL UNIT	—	—	—	×	WT-30

REAR WINDOW DEFOGGER DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

REAR WINDOW DEFOGGER DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000006260878

1.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check power supply and ground circuit.

Refer to [DEF-10, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK REAR WINDOW DEFOGGER SWITCH

Check rear window defogger switch.

Refer to [DEF-11, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CHECK REAR WINDOW DEFOGGER RELAY

Check rear window defogger relay.

Refer to [DEF-12, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4.CHECK REAR WINDOW DEFOGGER

Check rear window defogger.

Refer to [DEF-14, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5.CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

NO >> GO TO 1.

A

B

C

D

E

F

G

H

I

J

K

DEF

M

N

O

P

REAR WINDOW DEFOGGER AND DOOR MIRROR DEFOGGER DO NOT OPERATE.

< SYMPTOM DIAGNOSIS >

REAR WINDOW DEFOGGER AND DOOR MIRROR DEFOGGER DO NOT OPERATE.

Diagnosis Procedure

INFOID:0000000006260879

1.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check power supply and ground circuit.

Refer to [DEF-10, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK REAR WINDOW DEFOGGER SWITCH

Check rear window defogger switch.

Refer to [DEF-11, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CHECK REAR WINDOW DEFOGGER RELAY

Check rear window defogger relay.

Refer to [DEF-12, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4.CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

NO >> GO TO 1.

REAR WINDOW DEFOGGER DOES NOT OPERATE BUT BOTH DOOR MIRROR DEFOGGERS OPERATE.

< SYMPTOM DIAGNOSIS >

REAR WINDOW DEFOGGER DOES NOT OPERATE BUT BOTH DOOR MIRROR DEFOGGERS OPERATE.

A

Diagnosis Procedure

INFOID:0000000006260880

1.CHECK REAR WINDOW DEFOGGER

Check rear window defogger.

Refer to [DEF-14, "Component Function Check".](#)

B

Is the inspection result normal?

C

YES >> GO TO 2.

D

NO >> Repair or replace the malfunctioning parts.

2.CONFIRM THE OPERATION

E

Confirm the operation again

F

Is the inspection result normal?

G

YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident".](#)

H

NO >> GO TO 1.

I

J

K

DEF

M

N

O

P

DOOR MIRROR DEFOGGER DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

DOOR MIRROR DEFOGGER DOES NOT OPERATE BOTH SIDES

BOTH SIDES : Diagnosis Procedure

INFOID:000000006260881

1. CHECK DOOR MIRROR DEFOGGER

Check door mirror defogger.

Refer to [DEF-17, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

NO >> GO TO 1.

DRIVER SIDE

DRIVER SIDE : Diagnosis Procedure

INFOID:000000006260882

1. CHECK DRIVER SIDE DOOR MIRROR DEFOGGER

Check driver side door mirror defogger.

Refer to [DEF-18, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

NO >> GO TO 1.

PASSENGER SIDE

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000006260883

1. CHECK PASSENGER SIDE DOOR MIRROR DEFOGGER.

Check passenger side door mirror defogger.

Refer to [DEF-20, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

NO >> GO TO 1.

ON IS NOT DISPLAYED WHEN PRESSING REAR WINDOW DEFOGGER SWITCH BUT IT IS OPERATED

< SYMPTOM DIAGNOSIS >

ON IS NOT DISPLAYED WHEN PRESSING REAR WINDOW DEFOGGER SWITCH BUT IT IS OPERATED

Diagnosis Procedure

INFOID:0000000006260884

WITH BOSE AUDIO SYSTEM

1. CHECK AV CONTROL UNIT FUNCTION

Check that the AV control unit is operating normally.

- Without navigation refer to [AV-225, "Work Flow"](#).
- With navigation refer to [AV-353, "Work Flow"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

NO >> GO TO 1.

WITHOUT BOSE AUDIO SYSTEM

1. CHECK A/C CONTROL UNIT FUNCTION

Check that A/C the control unit is operating normally. Refer to [HAC-5, "Work Flow"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

NO >> GO TO 1.

A

B

C

D

E

F

G

H

I

J

K

DEF

M

N

O

P

REAR WINDOW DEFOGGER INDICATOR DOES NOT ILLUMINATE

< SYMPTOM DIAGNOSIS >

REAR WINDOW DEFOGGER INDICATOR DOES NOT ILLUMINATE

Diagnosis Procedure

INFOID:0000000006260885

WITH BOSE AUDIO SYSTEM

1. CHECK PRESET SWITCH (REAR WINDOW DEFOGGER SWITCH)

Check rear window defogger operate.

YES >> Replace preset switch (rear window defogger switch). Refer to [AV-282, "Removal and Installation"](#) (without navigation system) or [AV-427, "Removal and Installation"](#) (with navigation system).

NO >> Check rear window defogger system. Refer to [DEF-3, "Work Flow"](#).

WITHOUT BOSE AUDIO SYSTEM

1. CHECK A/C CONTROL (REAR WINDOW DEFOGGER SWITCH)

Check rear window defogger operate.

YES >> Replace A/C control (rear window defogger switch). Refer to [VTL-22, "Removal and Installation"](#).

NO >> Check rear window defogger system. Refer to [DEF-3, "Work Flow"](#).

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

FOR USA AND CANADA

FOR USA AND CANADA : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000006260886

A
B
C
D
E
F
G
H
I
J
K

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted.

Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

FOR MEXICO

FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000006260887

DEF

M
N

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

PRECAUTIONS

< PRECAUTION >

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

FILAMENT

< REMOVAL AND INSTALLATION >


REMOVAL AND INSTALLATION FILAMENT

Inspection and Repair


INFOID:000000006260888

INSPECTION


- When measuring voltage, wrap tin foil around the top of the negative probe. Then press the foil against the wire with your finger.



- Attach probe circuit tester (in Volt range) to middle portion of each filament.



- If a filament is burned out, circuit tester registers 0 or battery voltage.
- To locate burned out point, move probe to left and right along filament. Test needle will swing abruptly when probe passes the point.



REPAIR

REPAIR EQUIPMENT

- Conductive silver composition (Dupont No. 4817 or equivalent)

A

B

C

D

E

F

G

H

I

J

K

DEF

M

N

O

P


FILAMENT

< REMOVAL AND INSTALLATION >


- Ruler 30 cm (11.8 in) long
- Drawing pen
- Heat gun
- Alcohol
- Cloth

REPAIRING PROCEDURE

1. Wipe broken heat wire and its surrounding area clean with a cloth dampened in alcohol.
2. Apply a small amount of conductive silver composition to tip of drawing pen.
Shake silver composition container before use.
3. Place ruler on glass along broken line. Deposit conductive silver composition on break with drawing pen. Slightly overlap existing heat wire on both sides [preferably 5 mm (0.20 in)] of the break.



4. After repair has been completed, check repaired wire for continuity. This check should be conducted 10 minutes after silver composition is deposited.
Do not touch repaired area while test is being conducted.



5. Apply a constant stream of hot air directly to the repaired area for approximately 20 minutes with a heat gun. A minimum distance of 3 cm (1.2 in) should be kept between repaired area and hot air outlet.
If a heat gun is not available, let the repaired area dry for 24 hours.

