

WCS

SECTION

WARNING CHIME SYSTEM

CONTENTS

BASIC INSPECTION	3	PARKING BRAKE RELEASE WARNING CHIME	F
DIAGNOSIS AND REPAIR WORKFLOW	3	: System Description	11
Work Flow	3	PARKING BRAKE RELEASE WARNING CHIME	G
SYSTEM DESCRIPTION	5	: Component Parts Location	12
WARNING CHIME SYSTEM	5	PARKING BRAKE RELEASE WARNING CHIME	H
WARNING CHIME SYSTEM	5	: Component Description	12
WARNING CHIME SYSTEM : System Diagram	5	KEY WARNING CHIME	I
WARNING CHIME SYSTEM : System Description	5	KEY WARNING CHIME : System Diagram	13
WARNING CHIME SYSTEM : Component Parts Location	6	KEY WARNING CHIME : System Description	13
WARNING CHIME SYSTEM : Component Description	7	KEY WARNING CHIME : Component Parts Location	14
LIGHT REMINDER WARNING CHIME	7	KEY WARNING CHIME : Component Description...	14
LIGHT REMINDER WARNING CHIME : System Diagram	7	DIAGNOSIS SYSTEM (METER)	J
LIGHT REMINDER WARNING CHIME : System Description	7	CONSULT-III Function (METER/M&A)	15
LIGHT REMINDER WARNING CHIME : Component Parts Location	8	DIAGNOSIS SYSTEM (BCM)	K
LIGHT REMINDER WARNING CHIME : Component Description	8	COMMON ITEM	19
SEAT BELT WARNING CHIME	8	COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM)	L
SEAT BELT WARNING CHIME : System Diagram	9	BUZZER	M
SEAT BELT WARNING CHIME : System Description	9	BUZZER : CONSULT-III Function (BCM - BUZZER)	20
SEAT BELT WARNING CHIME : Component Parts Location	10	DTC/CIRCUIT DIAGNOSIS	22
SEAT BELT WARNING CHIME : Component Description	10	POWER SUPPLY AND GROUND CIRCUIT	22
PARKING BRAKE RELEASE WARNING CHIME	10	COMBINATION METER	O
PARKING BRAKE RELEASE WARNING CHIME : System Diagram	11	COMBINATION METER : Diagnosis Procedure	22
		BCM (BODY CONTROL MODULE)	P
		BCM (BODY CONTROL MODULE) : Diagnosis Procedure	22
		METER BUZZER CIRCUIT	24
		Description	24
		Component Function Check	24
		Diagnosis Procedure	24

SEAT BELT BUCKLE SWITCH SIGNAL CIRCUIT	25	Description	88
Description	25	Diagnosis Procedure	88	
Component Function Check	25			
Diagnosis Procedure	25			
Component Inspection	26			
WARNING CHIME SYSTEM	27		
Wiring Diagram - WARNING CHIME -	27			
ECU DIAGNOSIS INFORMATION	34		
COMBINATION METER	34		
Reference Value	34			
Wiring Diagram - METER -	40			
Fail-Safe	51			
DTC Index	52			
BCM (BODY CONTROL MODULE)	54		
Reference Value	54			
Wiring Diagram - BCM -	77			
Fail-safe	83			
DTC Inspection Priority Chart	85			
DTC Index	85			
SYMPTOM DIAGNOSIS	88		
THE PARKING BRAKE RELEASE WARNING CONTINUES SOUNDING, OR DOES NOT SOUND	88		
Description	89	THE LIGHT REMINDER WARNING DOES NOT SOUND	89	
Diagnosis Procedure	89			
		THE SEAT BELT WARNING CONTINUES SOUNDING, OR DOES NOT SOUND	90	
		Description	90	
		Diagnosis Procedure	90	
		THE KEY WARNING DOES NOT SOUND	91	
		Description	91	
		Diagnosis Procedure	91	
		PRECAUTION	92	
		PRECAUTIONS	92	
		FOR USA AND CANADA	92	
		FOR USA AND CANADA : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	92	
		FOR MEXICO	92	
		FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	92	

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000006262222

OVERALL SEQUENCE



JSNIA0456GB

DETAILED FLOW

1. OBTAIN INFORMATION ABOUT SYMPTOM

WCS

Interview the customer to obtain as much information as possible about the conditions and environment under which the malfunction occurred.

>> GO TO 2.

2. CHECK SYMPTOM

- Check the symptom based on the information obtained from the customer.
- Check if any other malfunctions are present.

>> GO TO 3.

3. CHECK CONSULT-III SELF-DIAGNOSIS RESULTS

Connect CONSULT-III and perform self-diagnosis. Refer to [MWI-35, "CONSULT-III Function \(METER/M&A\)"](#).

A

B

C

D

E

F

G

H

I

J

K

L

M

O

P

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

Are self-diagnosis results normal?

YES >> GO TO 4.

NO >> GO TO 5.

4. NARROW DOWN MALFUNCTIONING PARTS BY SYMPTOM DIAGNOSIS

Perform symptom diagnosis and narrow down the malfunctioning parts.

>> GO TO 5.

5. REPAIR OR REPLACE MALFUNCTIONING PARTS

Repair or replace malfunctioning parts.

NOTE:

If DTC is displayed, erase DTC after repairing or replacing malfunctioning parts.

>> GO TO 6.

6. FINAL CHECK

Check that the warning buzzer in the combination meter operates normally.

Does it operate normally?

YES >> INSPECTION END

NO >> GO TO 1.

WARNING CHIME SYSTEM

< SYSTEM DESCRIPTION >


SYSTEM DESCRIPTION

WARNING CHIME SYSTEM

WARNING CHIME SYSTEM

WARNING CHIME SYSTEM : System Diagram

INFOID:0000000006262223




JPNIA1556GB

WARNING CHIME SYSTEM : System Description

INFOID:0000000006262224

COMBINATION METER

- The buzzer (1) for the warning chime system is integrated in the combination meter.
- The combination meter sounds the alarm buzzer installed in the combination meter when receiving the buzzer output signal transmitted from each unit.



JPNIA0741ZZ

BCM

BCM receives signals from various units and transmits a buzzer output signal to the combination meter via CAN communication if it judges that the warning buzzer should be activated.

BCM Warning Function List

A

B

C

D

E

F

G

H

I

J

K

L

M

WCS

O

P

WARNING CHIME SYSTEM

< SYSTEM DESCRIPTION >


Warning functions	Signal name
Light reminder warning chime	<ul style="list-style-type: none"> • Ignition switch signal • Lighting switch position signal • Door switch signal (driver side)
Seat belt warning chime	<ul style="list-style-type: none"> • Ignition switch signal • Seat belt buckle switch signal (driver side)
Key warning chime	<ul style="list-style-type: none"> • Ignition signal • Key slot switch signal • Door switch signal (driver side)

NOTE:

Parking brake release warning chime is detected by combination meter.

WARNING CHIME SYSTEM : Component Parts Location

INFOID:0000000006262225



JPNIA0814ZZ

- | | | |
|--|--|------------------|
| 1. Front door switch (driver side) | 2. Combination switch
(Lighting switch) | 3. Parking brake |
| 4. Seat belt buckle switch (driver side) | 5. Key slot | 6. BCM |
| 7. Combination meter | | |
| A. Behind the combination meter | | |

WARNING CHIME SYSTEM

< SYSTEM DESCRIPTION >

WARNING CHIME SYSTEM : Component Description

INFOID:0000000006262226

A

B

C

D

E

F

G

H

I

J

K

L

M

WCS

O


P

Unit	Description
Combination meter	<ul style="list-style-type: none"> Receives a buzzer output signal from the BCM with CAN communication line and sounds the buzzer. Judges whether the parking brake is released from the vehicle speed signal received from the ABS actuator and electric unit (control unit) with CAN communication line and the parking brake switch signal from the parking brake switch, and sounds the buzzer if necessary. Receives the seat belt buckle switch signal (driver side) from the seat belt buckle switch (driver side) and transmits it to BCM with CAN communication line.
BCM	Transmits signals provided by various units to the combination meter with CAN communication line.
ABS actuator and electric unit (control unit)	Transmits the vehicle speed signal to combination meter with CAN communication line.
Seat belt buckle switch (driver side)	Transmits a seat belt buckle switch signal (driver side) to the combination meter.
Combination switch (Lighting switch)	Transmits the lighting switch position signal to BCM.
Front door switch (driver side)	Transmits the door switch signal (driver side) to BCM.
Parking brake switch	Refer to MWI-54, "Description" .
Key slot	Transmits the key slot switch signal to BCM.

LIGHT REMINDER WARNING CHIME

LIGHT REMINDER WARNING CHIME : System Diagram

INFOID:0000000006262227



LIGHT REMINDER WARNING CHIME : System Description

INFOID:0000000006262228

DESCRIPTION

With ignition switch in the OFF or ACC position, when the driver door is open and the lighting switch is the 1st or 2nd position, the light warning chime will sound.

- BCM detects ignition switch in the OFF or ACC position, front door switch (driver side) ON, and lighting switch in 1st or 2nd position. Then the BCM transmits the buzzer output signal (light reminder warning chime) to combination meter with CAN communication line.
- When combination meter receives buzzer output signal (light reminder warning chime), it sounds the buzzer.

WARNING OPERATION CONDITIONS

If all of the following conditions are fulfilled.

- Ignition switch is in the OFF or ACC
- Lighting switch is in the 1st or 2nd position
- Front door switch (driver side) is ON

WARNING CANCEL CONDITIONS

Warning is canceled if any of the following conditions is fulfilled.


- Lighting switch OFF
- Ignition switch ON
- Front door switch (driver side) is OFF

WARNING CHIME SYSTEM

< SYSTEM DESCRIPTION >

LIGHT REMINDER WARNING CHIME : Component Parts Location

INFOID:0000000006262229



1. Front door switch (driver side)
2. Combination switch (Lighting switch)
3. Parking brake
4. Seat belt buckle switch (driver side)
5. Key slot
6. BCM
7. Combination meter
- A. Behind the combination meter

LIGHT REMINDER WARNING CHIME : Component Description

INFOID:0000000006262230

Unit	Description
Combination meter	Receives a buzzer output signal from the BCM and sounds the buzzer.
BCM	Judges the light warning conditions from the signals provided by various switches and transmits a buzzer output signal to the combination meter via CAN communication line if necessary.
Combination switch (Lighting switch)	Transmits the lighting switch position signal to BCM.
Front door switch (driver side)	Transmits the door switch signal (driver side) to BCM.


SEAT BELT WARNING CHIME

WARNING CHIME SYSTEM

< SYSTEM DESCRIPTION >

SEAT BELT WARNING CHIME : System Diagram

INFOID:000000006262231



JPNIA0750GB

SEAT BELT WARNING CHIME : System Description

INFOID:000000006262232

DESCRIPTION

With ignition switch turned ON and driver seat belt unfastened, seat belt warning chime will sound for approximately 6 seconds.

- The combination meter receives the seat belt buckle switch signal (driver side) from seat belt buckle switch (driver side) and transmits it to the BCM via CAN communication.
- The BCM receives seat belt buckle switch signal (driver side) from combination meter via CAN communication.
- The BCM detects seat belt reminder warning based on the received signal and transmits the buzzer output signal to combination meter via CAN communication.
- The combination meter receives the buzzer output signal from BCM via CAN communication and sounds the warning buzzer.

WARNING OPERATION CONDITIONS

If all of the following conditions are fulfilled, the warning buzzer will sound.

- Ignition switch ON
- Seat belt buckle switch (driver side) is ON (driver seat belt not fastened)

WARNING CANCEL CONDITIONS

Warning is canceled if any of the following conditions are fulfilled.

- Ignition switch OFF
- Seat belt buckle switch (driver side) is OFF (driver seat belt fastened)


WCS

WARNING CHIME SYSTEM

< SYSTEM DESCRIPTION >

SEAT BELT WARNING CHIME : Component Parts Location

INFOID:000000006262233



JPNIA0814ZZ

- | | | |
|--|--|------------------|
| 1. Front door switch (driver side) | 2. Combination switch
(Lighting switch) | 3. Parking brake |
| 4. Seat belt buckle switch (driver side) | 5. Key slot | 6. BCM |
| 7. Combination meter | | |
| A. Behind the combination meter | | |

SEAT BELT WARNING CHIME : Component Description

INFOID:000000006262234

Unit	Description
Combination meter	<ul style="list-style-type: none">• Receives the seat belt buckle switch signal (driver side) from the seat belt buckle switch (driver side) and transmits it to BCM via CAN communication line.• Receives a buzzer output signal from the BCM and sounds the buzzer.
BCM	Judges the seat belt warning condition according to the seat belt buckle switch signal (driver side) received from the combination meter via CAN communication and transmits a buzzer output signal to the combination meter via CAN communication line if necessary.
Seat belt buckle switch (driver side)	Transmits the seat belt buckle switch signal (driver side) to the combination meter.


PARKING BRAKE RELEASE WARNING CHIME

WARNING CHIME SYSTEM

< SYSTEM DESCRIPTION >

PARKING BRAKE RELEASE WARNING CHIME : System Diagram

INFOID:0000000006262235



JPNIA0751GB

PARKING BRAKE RELEASE WARNING CHIME : System Description

INFOID:0000000006262236

DESCRIPTION

Parking brake release warning chime judges the remaining parking brake according to the vehicle speed signal received from the ABS actuator and electric unit (control unit) via CAN communication and the parking brake switch signal from parking brake switch to sound the warning buzzer.

WARNING OPERATION CONDITIONS

If all of the following conditions are fulfilled.

- Vehicle speed is 7 km/h (4.3 MPH) or higher
- Parking brake switch ON

WARNING CANCEL CONDITIONS

Warning is canceled if any of the following conditions are fulfilled.

- Vehicle speed is approximately 3 km/h (1.9 MPH) or less
- Parking brake switch OFF

A
B
C
D
E
F
G
H
I
J
K
L
M

WCS


O
P

WARNING CHIME SYSTEM

< SYSTEM DESCRIPTION >

PARKING BRAKE RELEASE WARNING CHIME : Component Parts Location

INFOID:0000000006262237



JPNIA0814ZZ

- | | | |
|--|--|------------------|
| 1. Front door switch (driver side) | 2. Combination switch
(Lighting switch) | 3. Parking brake |
| 4. Seat belt buckle switch (driver side) | 5. Key slot | 6. BCM |
| 7. Combination meter | | |
| A. Behind the combination meter | | |

PARKING BRAKE RELEASE WARNING CHIME : Component Description

INFOID:0000000006262238

Unit	Description
Combination meter	Judges the remaining parking brake according to the vehicle speed signal received from the ABS actuator and electric unit (control unit) via CAN communication and the parking brake switch signal from parking brake switch and sounds the warning buzzer.
ABS actuator and electric unit (control unit)	Transmits the vehicle speed signal to the combination meter via CAN communication.
Parking brake switch	Transmits the parking brake switch signal to the combination meter.


KEY WARNING CHIME

WARNING CHIME SYSTEM

< SYSTEM DESCRIPTION >

KEY WARNING CHIME : System Diagram

INFOID:0000000006262239



KEY WARNING CHIME : System Description

INFOID:0000000006262240

DESCRIPTION

- BCM detects key warning according to the input of ignition switch, key slot switch signal and door switch (driver side) signal and transmits the buzzer output signal via CAN communication.
- The combination meter receives the buzzer output signal from BCM and sounds the warning buzzer.

WARNING OPERATION CONDITIONS

If all of the following conditions are fulfilled, the chime will sound.

- Other than ignition switch ON
- Key switch ON (keyfob is inserted in key slot)
- Front door switch (driver side) ON

WARNING CANCEL CONDITIONS

Warning canceled if any of the following conditions are fulfilled.

- Ignition switch ON
- Key switch OFF (keyfob is not inserted in key slot)
- Front door switch (driver side) OFF

A
B
C
D

E
F

G
H

I
J

K
L

M

WCS


O
P

WARNING CHIME SYSTEM

< SYSTEM DESCRIPTION >

KEY WARNING CHIME : Component Parts Location

INFOID:000000006262241



- | | | |
|--|--|------------------|
| 1. Front door switch (driver side) | 2. Combination switch
(Lighting switch) | 3. Parking brake |
| 4. Seat belt buckle switch (driver side) | 5. Key slot | 6. BCM |
| 7. Combination meter | | |
| A. Behind the combination meter | | |

KEY WARNING CHIME : Component Description

INFOID:000000006262242

Unit	Description
Combination meter	Sounds the warning buzzer according to the buzzer output signal received from BCM via CAN communication.
BCM	Judges key warning according to the door switch signal (driver side) from the front door switch (driver side) and the key slot switch signal from the key slot and transmits the buzzer output signal to the combination meter via CAN communication.
Front door switch (driver side)	Transmits the door switch signal (driver side) to BCM.
Key slot	Transmits the key slot switch signal to BCM.

DIAGNOSIS SYSTEM (METER)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (METER)

CONSULT-III Function (METER/M&A)

INFOID:0000000006845209

A

B

C

D

E

F

G

H

I

J

K

L

M

WCS

O

P

CONSULT-III APPLICATION ITEMS

CONSULT-III can perform the following diagnosis modes via CAN communication and the combination meter.

System	Diagnosis mode	Description
METER/M&A	Self Diagnostic Result	The combination meter checks the conditions and displays memorized errors.
	Data Monitor	Displays the combination meter input/output data in real time.
	Special function	Lighting history of the warning lamp and indicator lamp can be checked.

SELF DIAG RESULT

Refer to [MWI-77, "DTC Index"](#).

DATA MONITOR

Display Item List

X: Applicable

Display item [Unit]	MAIN SIGNALS	Description
SPEED METER [km/h]	X	<p>Value of vehicle speed signal received from ABS actuator and electric unit (control unit) via CAN communication.</p> <p>NOTE: 655.35 is displayed when the malfunction signal is received.</p>
SPEED OUTPUT [km/h]	X	<p>Vehicle speed signal value transmitted to other units via CAN communication.</p> <p>NOTE: 655.35 is displayed when the malfunction signal is received.</p>
ODO OUTPUT [km/h or mph]		<p>Odometer signal value transmitted to other units via CAN communication.</p>
TACHO METER [rpm]	X	<p>Value of the engine speed signal received from ECM via CAN communication.</p> <p>NOTE: 8191.875 is displayed when the malfunction signal is received.</p>
FUEL METER [L]	X	<p>Fuel level indicated on combination meter.</p>
W TEMP METER [°C]	X	<p>Value of engine coolant temperature signal is received from ECM via CAN communication.</p> <p>NOTE: 215 is displayed when the malfunction signal is input.</p>
FUEL CAP W/L [On/Off]		<p>Status of fuel filler cap warning display detected from fuel filler cap warning display signal received from ECM via CAN communication.</p>
ABS W/L [On/Off]		<p>Status of ABS warning lamp detected from ABS warning lamp signal is received from ABS actuator and electric unit (control unit) via CAN communication.</p>
VDC/TCS IND [On/Off]		<p>Status of VDC OFF indicator lamp detected from VDC OFF indicator lamp signal is received from ABS actuator and electric unit (control unit) via CAN communication.</p>
SLIP IND [On/Off]		<p>Status of SLIP indicator lamp detected from slip indicator lamp signal received from ABS actuator and electric unit (control unit) via CAN communication.</p>
BRAKE W/L [On/Off]		<p>Status of brake warning lamp detected from brake warning lamp signal is received from ABS actuator and electric unit (control unit) via CAN communication.</p> <p>NOTE: Displays "Off" if the brake warning lamp is illuminated when the valve check starts, the parking brake switch is turned ON or the brake fluid level switch is turned ON.</p>
DOOR W/L [On/Off]		<p>Status of door warning detected from door switch signal received from BCM via CAN communication.</p>
HI-BEAM IND [On/Off]		<p>Status of high beam indicator lamp detected from high beam request signal is received from BCM via CAN communication.</p>

DIAGNOSIS SYSTEM (METER)

< SYSTEM DESCRIPTION >

Display item [Unit]	MAIN SIGNALS	Description
TURN IND [On/Off]		Status of turn indicator lamp detected from turn indicator signal is received from BCM via CAN communication.
LIGHT IND [On/Off]		Status of light indicator lamp detected from position light request signal is received from BCM via CAN communication.
OIL W/L [On/Off]		Status of oil pressure warning lamp detected from oil pressure switch signal is received from BCM via CAN communication.
MIL [On/Off]		Status of malfunction indicator lamp detected from malfunctioning indicator lamp signal is received from ECM via CAN communication.
CRUISE IND [On/Off]		Status of CRUISE indicator detected from ASCD status signal is received from ECM via CAN communication.
O/D OFF IND [On/Off]		Status of O/D OFF indicator detected from O/D OFF indicator signal is received from CVT shift selector.
4WD W/L [On/Off]		Status of AWD warning lamp detected from AWD warning lamp signal is received from AWD control unit via CAN communication.
4WD LOCK IND [On/Off]		Status of AWD LOCK warning lamp detected from AWD LOCK warning lamp signal is received from AWD control unit via CAN communication.
FUEL W/L [On/Off]		Low-fuel warning lamp status detected by the identified fuel level.
WASHER W/L [On/Off]		Status of washer warning lamp judged from washer level switch input to combination meter.
AIR PRES W/L [On/Off]		Status of low tire pressure warning lamp detected from tire pressure signal is received from BCM via CAN communication.
KEY G/W W/L [On/Off]		Status of key warning lamp (G/Y) detected from key warning signal is received from BCM via CAN communication.
LCD [B&P N, B&P I, ID NG, ROTAT, SFT P, INSRT, BATT, NO KY, OUTKY, LK WN]		Displays status of Intelligent Key system warning detected from meter display signal is received from BCM via CAN communication.
SHIFT IND [P, R, N, D, L]		Status of shift position indicator detected from shift position signal is received from TCM via CAN communication.
O/D OFF SW [On/Off]		Status of O/D OFF switch.
M RANGE SW [Off]		This item is displayed, but cannot be monitored.
NM RANGE SW [Off]		This item is displayed, but cannot be monitored.
AT SFT UP SW [Off]		This item is displayed, but cannot be monitored.
AT SFT DWN SW [Off]		This item is displayed, but cannot be monitored.
ST SFT UP SW [Off]		This item is displayed, but cannot be monitored.
ST SFT DWN SW [Off]		This item is displayed, but cannot be monitored.
PKB SW [On/Off]		Status of parking brake switch.
BUCKLE SW [On/Off]		Status of seat belt buckle switch (driver side).
BRAKE OIL SW [On/Off]		Status of brake fluid level switch.
DISTANCE [km]		Value of possible driving distance calculated by combination meter.

DIAGNOSIS SYSTEM (METER)

< SYSTEM DESCRIPTION >

Display item [Unit]	MAIN SIGNALS	Description
A/C AMP CONN [On/Off]		Status of A/C auto amp. connection recognition signal.
ENTER SW [On/Off]		Status of (ENTER) switch.
SELECT SW [On/Off]		Status of (SELECT) switch.
OUTSIDE TEMP [°C or °F]		<p>Ambient air temperature value converted from ambient sensor signal received from ambient sensor.</p> <p>NOTE: This may not match with the temperature value indicated on the information display. (Because the information display value is a corrected value from the ambient sensor input value.)</p>
FUEL LOW SIG [On/Off]		Status of fuel level low warning signal to output to AV control unit via CAN communication.
BUZZER [On/Off]	X	Buzzer status (in the combination meter) is detected from the buzzer output signal received from each unit via CAN communication and the warning output condition of the combination meter.

NOTE:

Some items are not available according to vehicle specification.

SPECIAL FUNCTION

Special menu

Display item	Description
W/L ON HISTORY	Lighting history of warning lamp and indicator lamp can be checked.

W/L ON HISTORY

- Stores histories when warning/indicator lamp is turned on.
- “W/L ON HISTORY” indicates the “TIME” when the warning/indicator lamp is turned on.
- The “TIME” above is :
 - 0 : The condition that the warning/indicator lamp has been turned on 1 or more times after starting the engine and waiting for 30 seconds.
 - 1 - 39 : The number of times the engine was restarted after the 0 condition.
 - NO W/L ON HISTORY : Stores NO (0) turning on history of warning/indicator lamp.

NOTE:

- W/L ON HISTORY is not stored for approximately 30 seconds after the engine starts.
- Brake warning lamp does not store any history when the parking the brake is applied or the brake fluid level gets low.

Display Item

Display item	Description
ABS W/L	Lighting history of ABS warning lamp.
VDC/TCS IND	Lighting history of VDC OFF indicator lamp.
SLIP IND	Lighting history of SLIP indicator lamp.
BRAKE W/L	Lighting history of brake warning lamp.
DOOR W/L	Lighting history of door warning.
OIL W/L	Lighting history of oil pressure warning lamp.
C-ENG W/L	Lighting history of malfunction indicator lamp.
CRUISE IND	Lighting history of CRUISE indicator lamp.
SET IND	Lighting history of SET indicator.
O/D OFF IND	Lighting history of O/D OFF indicator lamp.
4WD W/L	Lighting history of AWD warning lamp.

A

B

C

D

E

F

G

H

I

J

K

L

M

WCS

O

P

DIAGNOSIS SYSTEM (METER)

< SYSTEM DESCRIPTION >

Display item	Description
FUEL W/L	Lighting history of low fuel level warning.
WASHER W/L	Lighting history of low washer fluid warning
AIR PRES W/L	Lighting history of low tire pressure warning lamp.
KEY G/Y W/L	Lighting history of key warning lamp (green/yellow).
KEY R W/L	Lighting history of key warning lamp (red).
CHAGE W/L	Lighting history of charge warning lamp.

NOTE:

In items displayed on the CONSULT screen, only those listed in the above table are used.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM)

INFOID:000000006845210

APPLICATION ITEM

CONSULT-III performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
Work Support	Changes the setting for each system function.
Self Diagnostic Result	Displays the diagnosis results judged by BCM.
CAN Diag Support Monitor	Monitors the reception status of CAN communication viewed from BCM. Refer to CONSULT-III operation manual.
Data Monitor	The BCM input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from BCM.
Ecu Identification	The BCM part number is displayed.
Configuration	<ul style="list-style-type: none">• Read and save the vehicle specification.• Write the vehicle specification when replacing BCM.

SYSTEM APPLICATION

BCM can perform the following functions for each system.

NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

x: Applicable item

System	Sub system selection item	Diagnosis mode		
		Work Support	Data Monitor	Active Test
Door lock	DOOR LOCK	x	x	x
Rear window defogger	REAR DEFOGGER		x	x
Warning chime	BUZZER		x	x
Interior room lamp timer	INT LAMP	x	x	x
Exterior lamp	HEAD LAMP	x	x	x
Wiper and washer	WIPER	x ^{*1}	x	x
Turn signal and hazard warning lamps	FLASHER	x	x	x
—	AIR CONDITIONER ^{*2}			
• Intelligent Key system • Engine start system	INTELLIGENT KEY	x	x	x
Combination switch	COMB SW		x	
Body control system	BCM	x		
NVIS - NATS	IMMU		x	x
Interior room lamp battery saver	BATTERY SAVER	x	x	x
Back door opener system	TRUNK		x	x
Vehicle security system	THEFT ALM	x	x	x
RAP system	RETAINED PWR		x	
Signal buffer system	SIGNAL BUFFER		x	x
TPMS	TPMS (AIR PRESSURE MONITOR)	x	x	x

NOTE:

- *1: For models with rain sensor this mode is displayed, but is not used.
- *2: This item is displayed, but is not used.

FREEZE FRAME DATA (FFD)

A

B

C

D

E

F

G

H

I

J

K

L

M

WCS

O

P

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays on CONSULT-III.

CONSULT screen item	Indication/Unit	Description
Vehicle Speed	km/h	Vehicle speed of the moment a particular DTC is detected
Odo/Trip Meter	km	Total mileage (Odometer value) of the moment a particular DTC is detected
Vehicle Condition	SLEEP>LOCK SLEEP>OFF LOCK>ACC ACC>ON RUN>ACC CRANK>RUN RUN>URGENT ACC>OFF OFF>LOCK OFF>ACC ON>CRANK OFF>SLEEP LOCK>SLEEP LOCK OFF ACC ON ENGINE RUN CRANKING	Power position status of the moment a particular DTC is detected While turning BCM status from low power consumption mode to normal mode (Power supply position is "LOCK") While turning BCM status from low power consumption mode to normal mode (Power supply position is "OFF".) While turning power supply position from "LOCK" to "ACC" While turning power supply position from "ACC" to "IGN" While turning power supply position from "RUN" to "ACC" (Vehicle is stopping and selector lever is except P position.) While turning power supply position from "CRANKING" to "RUN" (From cranking up the engine to run it) While turning power supply position from "RUN" to "ACC" (Emergency stop operation) While turning power supply position from "ACC" to "OFF" While turning power supply position from "OFF" to "LOCK" While turning power supply position from "OFF" to "ACC" While turning power supply position from "IGN" to "CRANKING" While turning BCM status from normal mode (Power supply position is "OFF".) to low power consumption mode While turning BCM status from normal mode (Power supply position is "LOCK".) to low power consumption mode Power supply position is "LOCK" (Ignition switch OFF with steering is locked.) Power supply position is "OFF" (Ignition switch OFF with steering is unlocked.) Power supply position is "ACC" (Ignition switch ACC) Power supply position is "IGN" (Ignition switch ON with engine stopped) Power supply position is "RUN" (Ignition switch ON with engine running) Power supply position is "CRANKING" (At engine cranking)
IGN Counter	0 - 39	The number of times that ignition switch is turned ON after DTC is detected <ul style="list-style-type: none"> • The number is 0 when a malfunction is detected now. • The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. • The number is fixed to 39 until the self-diagnosis results are erased if it is over 39.

BUZZER

BUZZER : CONSULT-III Function (BCM - BUZZER)

INFOID:0000000006845211

CONSULT-III APPLICATION ITEMS

Test item	Diagnosis mode	Description
BUZZER	Data Monitor	Displays BCM input data in real time.
	Active Test	Operation of electrical loads can be checked by sending driving signal to them.

DATA MONITOR

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Display item [Unit]	Description	A
PUSH SW [On/Off]	Status of push button ignition switch judged by BCM.	B
UNLK SEN-DR [On/Off]	Status of unlock sensor judged by BCM.	C
VEH SPEED 1 [Km/h]	Value of vehicle speed signal received from ABS actuator and electric unit (control unit) with CAN communication line.	D
KEY SW-SLOT [On/Off]	Status of key slot judged by BCM.	E
TAIL LAMP SW [On/Off]	Status of each switch judged by BCM using the combination switch readout function.	F
FR FOG SW [On/Off]	Status of front fog lamp switch judged by BCM.	G
DOOR SW-DR [On/Off]	Status of driver side door switch judged by BCM.	H

ACTIVE TEST

Display item [Unit]	Description	G
IGN KEY WARN ALM	The key warning chime operation can be checked by operating the relevant function (On/Off).	H
SEAT BELT WARN TEST	The seat belt warning chime operation can be checked by operating the relevant function (On/Off).	I
ID REGIST WARNING	The ID regist warning chime operation can be checked by operating the relevant function (On/Off).	J
LIGHT WARN ALM	The light warning chime operation can be checked by operating the relevant function (On/Off).	K

A

B

C

D

E

F

G

H

I

J

K

L

M

WCS

O

P

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT COMBINATION METER

COMBINATION METER : Diagnosis Procedure

INFOID:0000000006262246

1. CHECK FUSE

Check for blown fuses.

Power source	Fuse No.
Battery	11
Ignition switch ON or START	4

Is the inspection result normal?

YES >> GO TO 2.

NO >> Be sure to eliminate cause of malfunction before installing new fuse.

2. CHECK POWER SUPPLY CIRCUIT

Check voltage between combination meter harness connector terminals and ground.

Terminals		Ignition switch position	Voltage (Approx.)
(+)	(-)		
Combination meter			
Connector	Terminal	Ground	OFF
	1		Battery voltage
	2		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check harness between combination meter and fuse.

3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector.
3. Check continuity between combination meter harness connector terminals and ground.

Terminals		Continuity	Existed	
(+)	(-)			
Combination meter				
Connector	Terminal	Ground		
	3			
	23			

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair harness or connector.

BCM (BODY CONTROL MODULE)

BCM (BODY CONTROL MODULE) : Diagnosis Procedure

INFOID:0000000006856189

1. CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Signal name	Fuse and fusible link No.
Battery power supply	L
	10

Is the fuse fusing?

- YES >> Replace the blown fuse or fusible link after repairing the affected circuit if a fuse or fusible link is blown.
NO >> GO TO 2.

2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connectors.
3. Check voltage between BCM harness connector and ground.

Terminals		Voltage (Approx.)	
BCM			
Connector	Terminal		
M118	1	Ground	
M119	11	Battery voltage	

Is the measurement value normal?

- YES >> GO TO 3.
NO >> Repair harness or connector.

3.CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

BCM		Continuity
Connector	Terminal	
M119	13	

Does continuity exist?

- YES >> INSPECTION END
NO >> Repair harness or connector.

A

B

C

D

E

F

G

H

I

J

K

L

M

WCS

O

P

METER BUZZER CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

METER BUZZER CIRCUIT

Description

INFOID:0000000006262248

- The buzzer for warning chime system is installed in the combination meter.
- The combination meter sounds the alarm buzzer based on the signals transmitted from various units.

Component Function Check

INFOID:0000000006262249

1.CHECK OPERATION OF METER BUZZER

1. Select "BUZZER" of "BCM" on CONSULT-III.
2. Perform "LIGHT WARN ALM" of "Active Test".

Does meter buzzer beep?

YES >> INSPECTION END

NO >> GO TO 2.

2.CHECK COMBINATION METER INPUT SIGNAL

Select the "Data Monitor" for the "METER/M&A" and check the "BUZZER" monitor value.

BUZZER

Under the condition of buzzer input : On

Except above : Off

Is the inspection result normal?

YES >> Replace combination meter.

NO >> Replace BCM. Refer to [BCS-85, "Removal and Installation"](#).

Diagnosis Procedure

INFOID:0000000006262250

1.CHECK POWER SUPPLY OF COMBINATION METER

Check power supply of combination meter. Refer to [MWI-44, "COMBINATION METER : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair power supply circuit of combination meter. Refer to [MWI-44, "COMBINATION METER : Diagnosis Procedure"](#).

SEAT BELT BUCKLE SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

SEAT BELT BUCKLE SWITCH SIGNAL CIRCUIT

Description

INFOID:0000000006262251

Transmits a seat belt buckle switch signal (driver side) to the combination meter.

Component Function Check

INFOID:0000000006262252

1.CHECK COMBINATION METER INPUT SIGNAL

Select the "Data Monitor" for the "METER/M&A" and check the "BUCKLE SW" monitor value.

BUCKLE SW

- | | |
|------------------------------|-------|
| When seat belt is fastened | : Off |
| When seat belt is unfastened | : On |

>> INSPECTION END

Diagnosis Procedure

INFOID:0000000006262253

1.CHECK COMBINATION METER INPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between combination meter harness connector terminal and ground.

Terminals		Condition	Voltage (Approx.)
(+)	(-)		
Combination meter	Ground		
Connector	Terminal	When seat belt is fastened	12 V
		When seat belt is unfastened	0 V

Is the inspection result normal?

- YES >> Replace combination meter
NO >> GO TO 2.

2.CHECK SEAT BELT BUCKLE SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector and seat belt buckle switch (driver side) connector.
3. Check continuity between combination meter harness connector terminal and seat belt buckle switch (driver side) harness connector terminal.

Terminals		Continuity	WCS
(+)	(-)		
Combination meter	Seat belt buckle switch(driver side)	Exist	WCS
Connector	Terminal	Connector	Terminal
		B409 ^{*1}	15 ^{*1}
M34	35	B449 ^{*2}	40 ^{*2}

• *1 : Without automatic drive positioner

• *2 : With automatic drive positioner

4. Check harness continuity between combination meter harness connector terminal and ground.

SEAT BELT BUCKLE SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Terminals		Continuity	
(+)	(-)		
Combination meter			
Connector	Terminal		
M34	35	Not existed	

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3.CHECK SEAT BELT BUCKLE SWITCH GROUND CIRCUIT

Check harness continuity between seat belt buckle switch (driver side) harness connector terminal and ground.

Terminals		Continuity	
(+)	(-)		
Combination meter			
Connector	Terminal		
B409 ^{*1}	16 ^{*1}	Exist	
B449 ^{*2}	41 ^{*2}		

- *1 : Without automatic drive positioner

- *2 : With automatic drive positioner

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair harness or connector.

Component Inspection

INFOID:0000000006262254

1.CHECK SEAT BELT BUCKLE SWITCH (DRIVER SIDE)

- Turn ignition switch OFF.
- Disconnect the seat belt buckle switch (driver side) connector.
- Check continuity between terminals.

Terminals				Condition	Continuity
(+)	(-)	Connector	Terminal		
Seat belt buckle switch (driver side)					
Connector	Terminal	Connector	Terminal		
B409 ^{*1}	15 ^{*1}	B409 ^{*1}	16 ^{*1}	When seat belt is fastened	Not existed
B449 ^{*2}	40 ^{*2}	B449 ^{*2}	41 ^{*2}		
B409 ^{*1}	15 ^{*1}	B409 ^{*1}	16 ^{*1}	When seat belt is unfastened	Exist
B449 ^{*2}	40 ^{*2}	B449 ^{*2}	41 ^{*2}		

*1: Without automatic drive positioner

*2: With automatic drive positioner

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace the seat belt buckle. Refer to [SB-9, "SEAT BELT BUCKLE : Removal and Installation".](#)


WARNING CHIME SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

WARNING CHIME SYSTEM

Wiring Diagram - WARNING CHIME -

INFOID:0000000006262255




WARNING CHIME SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

WARNING CHIME

Connector No.	B11
Connector Name	WIRE TO WIRE
Connector Type	TH85MW-CS 9






Signal Name [Specification]

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
1	SHIELD	-	60	B	-
2	B	-	61	BL	-
3	R/L	-	62	RW	-
4	R/W	-	63	LG	-
5	SB	-	64	Y	-
6	P	-	65	BR	-
7	V	-	66	V	-
8	SHIELD	-	67	GR	-
9	BR/L	-	68	R	-
10	Y/G	-	69	SHIELD	-
11	Y/L	-	70	WR	-
12	W/L	-	71	BR	-
13	L	-	72	I	-
14	BR	-	73	LG	-
15	SB	-	74	SB	-
16	BR	-	75	L	-
17	V	-	76	G	-
18	SB	-	77	R	-
19	R	-	79	B	-
20	P	-	80	W	-
21	LG	-	81	R	-
22	W	-	82	L	-
23	Y	-	83	BR	-
24	GR	-	84	O	-
25	Y	-	85	G	-
26	SB	-	86	SB	-
27	V	-	87	R	-
28	W/L	-	88	G	-
29	P	-	89	GR	-
30	O	-	90	Y	-
31	BR	-	91	G	-
32	SB	-	92	BR	-
33	SB	-	93	G	-
34	SHIELD	-	94	V	-
35	L/O	-	95	BR	-
36	LG	-	96	GR	-
37	Y	-	97	R	-
38	GR	-	98	LG	-
39	BR	-	99	O	-
40	BR	-			
41	GR	-			
42	SB	-			
43	LG	-			

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
50	R/W	-	51	R/L	-
52	B	-	53	Y	-
54	LG	-	55	BR	-
56	P	-	57	L	-
58	R	-	59	SHIELD	-
60	B	-	61	BL	-
62	RW	-	63	LG	-
64	Y	-	65	BR	-
66	V	-	67	GR	-
68	R	-	69	SHIELD	-
70	WR	-	71	BR	-
72	I	-	73	LG	-
74	SB	-	75	L	-
76	G	-	77	R	-
78	B	-	79	BR	-
80	W	-	81	R	-
82	L	-	83	BR	-
84	O	-	85	G	-
86	SB	-	87	R	-
88	G	-	89	GR	-
90	Y	-	91	G	-
92	BR	-	93	G	-
94	V	-	95	BR	-
96	GR	-	97	R	-
98	LG	-	99	O	-

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
47	SB	-	48	SHIELD	-
49	B	-	50	R/W	-
51	R/L	-	52	B	-
53	Y	-	54	LG	-
55	BR	-	56	P	-
57	L	-	58	R	-
59	SHIELD	-	60	B	-
61	BL	-	62	RW	-
63	LG	-	64	Y	-
65	BR	-	66	V	-
67	GR	-	68	R	-
69	SHIELD	-	70	WR	-
71	BR	-	72	I	-
73	LG	-	74	SB	-
75	L	-	76	G	-
77	R	-	78	B	-
79	BR	-	80	W	-
81	R	-	82	L	-
83	BR	-	84	O	-
85	G	-	86	SB	-
87	R	-	88	G	-
89	GR	-	90	Y	-
91	G	-	92	BR	-
93	G	-	94	V	-
95	BR	-	96	GR	-
97	R	-	98	LG	-
99	O	-			

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
47	SB	-	48	SHIELD	-
49	B	-	50	R/W	-
51	R/L	-	52	B	-
53	Y	-	54	LG	-
55	BR	-	56	P	-
57	L	-	58	R	-
59	SHIELD	-	60	B	-
61	BL	-	62	RW	-
63	LG	-	64	Y	-
65	BR	-	66	V	-
67	GR	-	68	R	-
69	SHIELD	-	70	WR	-
71	BR	-	72	I	-
73	LG	-	74	SB	-
75	L	-	76	G	-
77	R	-	78	B	-
79	BR	-	80	W	-
81	R	-	82	L	-
83	BR	-	84	O	-
85	G	-	86	SB	-
87	R	-	88	G	-
89	GR	-	90	Y	-
91	G	-	92	BR	-
93	G	-	94	V	-
95	BR	-	96	GR	-
97	R	-	98	LG	-
99	O	-			



Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-	2	L	-
3	GR	-	4	O	-
5	G	-	6	B/W	-
7	BR	-	8	9	10
8	LG	-	9	11	12
9	SB	-	10	13	14
10	W/G	-	11	15	16
11	GR	-	12		
12			13		
13			14		
14			15		
15			16		

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-	2	L	-
3	GR	-	4	O	-
5	G	-	6	B/W	-
7	BR	-	8	9	10
8	LG	-	9	11	12
9	SB	-	10	13	14
10	W/G	-	11	15	16
11	GR	-	12		
12			13		
13			14		
14			15		
15			16		

JCNWM5355GB

WARNING CHIME SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

WARNING CHIME

Connector No. B411

Connector Name WIRE TO WIRE

Connector Type NS30BMW-CS



Terminal Color No. Signal Name [Specification]

1 R

2 P

3 G/O

4 O/L

5 BR

6 WG

7 B

8 WL

9 PLL

10 LO

11 V

12 V/W

13 W/R

14 GR/N

15 B/R

16 GR

17 B/R

18 GR

19

20

21

22

23

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

Terminal Color No. Signal Name [Specification]

1 R

2 G

3 WG

4 GR

5 B/R

6 GR

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

Terminal Color No. Signal Name [Specification]

1 P

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

Terminal Color No. Signal Name [Specification]

1 P

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

Terminal Color No. Signal Name [Specification]

1 P

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

Terminal Color No. Signal Name [Specification]

1 P

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

Terminal Color No. Signal Name [Specification]

1 P

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

Terminal Color No. Signal Name [Specification]

1 P

2

3

4

5

6

7

8

9

10

11

12

WARNING CHIME SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

WARNING CHIME

Connector No.	M4
Connector Name	DATA LINK CONNECTOR
Connector Type	BDI-FW



Terminal No.	Color of Wire	Signal Name [Specification]
3	LG	-
4	B	-
5	B	-
6	L	-
7	O	-
8	G	-
11	S5	-
14	P	-
16	Y	-




Terminal No.	Color of Wire	Signal Name [Specification]
56	P	-
57	V	-
60	Y	-
61	GR	-
62	O	-
63	V	-
64	SHIELD	-
66	W	-
67	R	-
68	V	-
69	P	-
70	G	-
71	G	-
72	BR	-
73	L	-
74	W	-
75	BR	-
76	R	-
77	G	-
78	Y	-
79	G	-
80	R	-
81	V	-
82	W	-
83	O	-



Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	Y	-
3	LG	-
4	GR	-
5	W	-
6	SB	-
7	SB	-
8	SB	-
9	W	-
10	O	-
11	L	-
12	R	-
13	V	-
14	Y	-
15	R	-
16	Y	-
17	Y	-
18	Y	-
19	Y	-
20	Y	-
21	BR	-
22	G	-
23	Y	-
24	Y	-



Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Type	TH7DFW-CS10-M3



Terminal No.	Color of Wire	Signal Name [Specification]
3	P	-
5	O	-
6	G	-
8	R	-
11	P	-
12	L	-
13	V	-
14	Y	-
15	R	-
20	Y	-
21	BR	-
22	G	-
24	Y	-



Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	Y	-
3	LG	-
4	GR	-
5	W	-
6	SB	-
7	SB	-
8	SB	-
9	W	-
10	O	-
11	L	-
12	R	-
13	V	-
14	Y	-
15	R	-
16	Y	-
17	Y	-
18	Y	-
19	Y	-
20	Y	-
21	BR	-
22	G	-
24	Y	-

Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	Y	-
3	LG	-
4	GR	-
5	W	-
6	SB	-
7	SB	-
8	SB	-
9	W	-
10	O	-
11	L	-
12	R	-
13	V	-
14	Y	-
15	R	-
16	Y	-
17	Y	-
18	Y	-
19	Y	-
20	Y	-
21	BR	-
22	G	-
24	Y	-

Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	Y	-
3	LG	-
4	GR	-
5	W	-
6	SB	-
7	SB	-
8	SB	-
9	W	-
10	O	-
11	L	-
12	R	-
13	V	-
14	Y	-
15	R	-
16	Y	-
17	Y	-
18	Y	-
19	Y	-
20	Y	-
21	BR	-
22	G	-
24	Y	-

Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	Y	-
3	LG	-
4	GR	-
5	W	-
6	SB	-
7	SB	-
8	SB	-
9	W	-
10	O	-
11	L	-
12	R	-
13	V	-
14	Y	-
15	R	-
16	Y	-
17	Y	-
18	Y	-
19	Y	-
20	Y	-
21	BR	-
22	G	-
24	Y	-

Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	Y	-
3	LG	-
4	GR	-
5	W	-
6	SB	-
7	SB	-
8	SB	-
9	W	-
10	O	-
11	L	-
12	R	-
13	V	-
14	Y	-
15	R	-
16	Y	-
17	Y	-
18	Y	-
19	Y	-
20	Y	-
21	BR	-
22	G	-
24	Y	-

Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	Y	-
3	LG	-
4	GR	-
5	W	-
6	SB	-
7	SB	-
8	SB	-
9	W	-
10	O	-
11	L	-
12	R	-
13	V	-
14	Y	-
15	R	-
16	Y	-
17	Y	-
18	Y	-
19	Y	-
20	Y	-
21	BR	-
22	G	-
24	Y	-

Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	Y	-
3	LG	-
4	GR	-
5	W	-
6	SB	-
7	SB	-
8	SB	-
9	W	-
10	O	-
11	L	-
12	R	-
13	V	-
14	Y	-
15	R	-
16	Y	-
17	Y	-
18	Y	-
19	Y	-
20	Y	-
21	BR	-
22	G	-
24	Y	-

Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	Y	-
3	LG	-
4	GR	-
5	W	-
6	SB	-
7	SB	-
8	SB	-
9	W	-
10	O	-
11	L	-
12	R	-
13	V	-
14	Y	-
15	R	-
16	Y	-
17	Y	-
18	Y	-
19	Y	-
20	Y	-
21	BR	-
22	G	-
24	Y	-

Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	Y	-
3	LG	-
4	GR	-
5	W	-
6	SB	-
7	SB	-
8	SB	-
9	W	-
10	O	-
11	L	-
12	R	-
13	V	-
14	Y	-
15	R	-
16	Y	-
17	Y	-
18	Y	-
19	Y	-
20	Y	-
21	BR	-
22	G	-
24	Y	-

Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	Y	-
3	LG	-
4	GR	-
5	W	-
6	SB	-
7	SB	-
8	SB	-
9	W	-
10	O	-
11	L	-
12	R	-
13	V	-
14	Y	-
15	R	-
16	Y	-
17	Y	-
18	Y	-
19	Y	-
20	Y	-
21	BR	-
22	G	-
24	Y	-


| Terminal No. |
<th
| --- |

WARNING CHIME SYSTEM


< DTC/CIRCUIT DIAGNOSIS >

WARNING CHIME


Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
1	SHIELD	-	60	B	-
2	B	-	61	R	-
3	W	-	62	W	-
4	R	-	63	O	-
5	Y	-	64	Y	-
6	W	-	65	Y	-
7	G	-	66	V	-
8	SHIELD	-	67	GR	-
9	W	-	68	G	-
10	R	-	69	SHIELD	-
11	G	-	70	L	-
12	B	-	71	R	-
13	O	-	72	LG	-
14	R	-	73	Y	-
15	SB	-	74	R	-
16	R	-	75	P	-
17	V	-	76	L	-
18	P	-	77	BR	-
19	P	-	78	B	-
20	LG	-	80	V	-
21	Y	-	81	LG	-
22	O	-	82	L	-
23	LG	-	83	GR	-
24	SB	-	84	R	-
25	Y	-	85	V	-
27	Y	-	86	W	-
28	R	-	87	R	-
30	Y	-	88	G	-
31	W	-	89	B	-
32	BR	-	90	O	-
34	Y	-	91	G	-
35	SHIELD	-	92	BR	-
36	G	-	93	P	-
37	Y	-	94	V	-
40	O	-	95	O	-
41	LG	-	96	SB	-
42	SB	-	97	L	-
46	LG	-	98	LG	-




Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
1	SHIELD	-	60	B	-
2	B	-	61	R	-
3	W	-	62	W	-
4	R	-	63	O	-
5	Y	-	64	Y	-
6	W	-	65	Y	-
7	G	-	66	V	-
8	SHIELD	-	67	GR	-
9	W	-	68	G	-
10	R	-	69	SHIELD	-
11	G	-	70	L	-
12	B	-	71	R	-
13	O	-	72	LG	-
14	R	-	73	Y	-
15	SB	-	74	R	-
16	R	-	75	P	-
17	V	-	76	L	-
18	P	-	77	BR	-
19	P	-	78	B	-
20	LG	-	80	V	-
21	Y	-	81	LG	-
22	O	-	82	L	-
23	LG	-	83	GR	-
24	SB	-	84	R	-
25	Y	-	85	V	-
27	Y	-	86	W	-
28	R	-	87	R	-
30	Y	-	88	G	-
31	W	-	89	B	-
32	BR	-	90	O	-
34	Y	-	91	G	-
35	SHIELD	-	92	BR	-
36	G	-	93	P	-
37	Y	-	94	V	-
40	O	-	95	O	-
41	LG	-	96	SB	-
42	SB	-	97	L	-
46	LG	-	98	LG	-




Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
47	SB	-	99	Y	-
48	SHIELD	-			
49	R	-			
50	LG	-			
51	V	-			
52	B	-			
53	BR	-			
54	B	-			
55	G	-			
56	P	-			
57	L	-			
58	SB	-			
59	SHIELD	-			
60	B	-			
61	R	-			
62	W	-			
63	O	-			
64	Y	-			
65	Y	-			
66	V	-			
67	GR	-			
68	G	-			
69	SHIELD	-			
70	L	-			
71	R	-			
72	LG	-			
73	Y	-			
74	R	-			
75	P	-			
76	L	-			
77	BR	-			
78	B	-			
80	V	-			
81	LG	-			
82	L	-			
83	GR	-			
84	R	-			
85	V	-			
87	R	-			
88	G	-			
89	B	-			
90	O	-			
91	G	-			
92	BR	-			
93	P	-			
94	V	-			
95	O	-			
96	SB	-			
97	L	-			
98	LG	-			




Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
1	G	RR	2	Y	OUTPUT 4
3	O	FR	4	W	IGN
5	V	OUTPUT 3	6	B	GND
7	GR	INPUT 3	8	L	OUTPUT 5
5	O	-	9	SE	INPUT 2
6	V	-	10	P	INPUT 4
11	O	INPUT 1	12	W	OUTPUT 1
13	R	INPUT 5	14	P	OUTPUT 2




Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
1	G	RR	2	Y	OUTPUT 4
3	O	FR	4	W	IGN
5	V	OUTPUT 3	6	B	GND
7	GR	INPUT 3	8	L	OUTPUT 5
5	O	-	9	SE	INPUT 2
6	V	-	10	P	INPUT 4
11	O	INPUT 1	12	W	OUTPUT 1
13	R	INPUT 5	14	P	OUTPUT 2



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	BAT (F/L)
2	GR	DATA
3	O	CLOCK
5	GR	BAT (ILL)
6	R	ILL
7	B	GND
11	Y	KEY SWITCH SIGNAL



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	BAT (F/L)
2	GR	DATA
3	O	CLOCK
5	GR	BAT (ILL)
6	R	ILL
7	B	GND
11	Y	KEY SWITCH SIGNAL



JCNWMS5358GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
WCS

WARNING CHIME SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

WARNING CHIME								
Connector No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
MI19	P	KEYLESS ENTRY RECEIVER SIGNAL	83	P	KEYLESS ENTRY RECEIVER SIGNAL	143	W	COMBI SW OUTPUT 1
BCM(BODY CONTROL MODULE)	R	COMBI SW INPUT 5	87	R	COMBI SW INPUT 5	144	P	COMBI SW OUTPUT 2
NS1DFW-CS	GR	COMBI SW INPUT 3	88	P	COMBI SW INPUT 3	145	Y	COMBI SW OUTPUT 3
Connector Type	CAN-L	CAN-L	90	P	CAN-L	146	Y	COMBI SW OUTPUT 4
	CAN-H	CAN-H	91	L	CAN-H	150	S8	DRIVER DOOR SW
			92	R		151	G	REAR WINDOW DEFOGGER RELAY
			93	P		94		
			95	L		96		
			96	Y	CVT SHIFT SELECTOR POWER SUPPLY	97		
			99	V	SHIFT P	98		
			100	P	PASSENGER DOOR REQUEST SW	99		
			101	W	DRIVER DOOR REQUEST SW	100		
			102	Y	BLOWER FAN MOTOR RELAY CONT	101		
			103	L	KEYLESS ENTRY RECEIVER POWER SUPPLY	102		
	P	INTERIOR ROOM LAMP POWER SUPPLY	107	O	COMBI SW INPUT 1	103		
	G	PASSENGER DOOR UNLOCK OUTPUT	108	P	COMBI SW INPUT 4	104		
	L	STEEL LAMP OUTPUT	109	SB	COMBI SW INPUT 2	105		
	V	ALL DOOR FUEL LID UNLOCK OUTPUT	110	G	HAZARD SW	106		
	G	DRIVER DOOR FUEL LID UNLOCK OUTPUT	110	P	REAR DOOR UNLOCK OUTPUT	107		
	LG	BAT FUSE	111	LG	INT FUSE	108		
	B	GND	113	B	FUSION BUTTON IGNITION SW/L GND	109		
	O	FUSION BUTTON IGNITION SW/L GND	114	O	ACC IND	110		
	L	TURN SIGNAL RH	115	L	TURN SIGNAL LH	111		
	G	TURN SIGNAL LH	117	G	TURN SIGNAL RH	112		
	BR	ROOM LAMP-TIMER CONTROL	118	BR	ROOM LAMP-TIMER CONTROL	113		
	Y	ROOM LAMP-TIMER CONTROL	119	Y		114		
			120			115		
			121	Y	KEY SLOT SW	116		
			122	Y	IGN F/B	117		
			124	R	PASSENGER DOOR SW	118		
			124	R	PASSENGER DOOR SW	119		
			125	R	POWER WINDOW SW COMM	120		
			125	G	POWER WINDOW SW COMM	121		
			126	W	PUSH-BUTTON IGNITION SW/L POWER	122		
			126	R	LOCK/RD	123		
			127	P	RECEIVER / SENSOR GND	124		
			127	V	RECEIVER / SENSOR POWER SUPPLY	125		
			128	V	TIRE PRESS RECEIVER SIGNAL	126		
			129	O	SHIFT NP	127		
			140	GR	SECURITY INDICATOR OUTPUT	128		
			141	O	IMMOBILIZER ANTENNA SIGNAL	129		
			142	L	IGN RELAY (F/B) CONT	130		
					COMBI SW OUTPUT 5	131		

JCNWM5359GB

WARNING CHIME SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

A

B

C

D

E

F

G

H

I

J

K

L

M

WCS

O

P

WARNING CHIME		
Connector No.	Mi80	
Connector Name	AV CONTROL UNIT	
Connector Type	TH32FW-NH	
		
Terminal	Color No.	Signal Name [Specification]
65	LG	PARKING BRAKE
67	BR	COMPOSITE IMAGE SIGNAL GND
68	GR	COMPOSITE IMAGE SIGNAL
71	SHIELD	SHIELD SIGNAL
72	B	MICROPHONE VCC
73	R	COMM (CONT-DISP)
74	P	CAN-L
75	LG	AV COMM (L)
76	LG	AV COMM (L)
79	R	ILLUMINATION SIGNAL
80	G	IGNITION
81	SB	REVERSE
82	V	VEHICLE SPEED SIGNAL (8 PULSE)
83	SHIELD	SHIELD
87	W	MICROPHONE SIGNAL
88	SHIELD	SHIELD
89	G	COMM (DISP->CONT)
90	L	CAN-H
91	SB	AV COMM (H)
92	SB	AV COMM (H)

JCNWM5360GB

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION COMBINATION METER

Reference Value

INFOID:0000000006845215

VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Condition		Value/Status
SPEED METER [km/h]	Ignition switch ON	While driving	Equivalent to speedometer reading NOTE: 655.35 is displayed when the malfunction signal is received
SPEED OUTPUT [km/h]	Ignition switch ON	While driving	Equivalent to speedometer reading NOTE: 655.35 is displayed when the malfunction signal is received
ODO OUTPUT [km/h or mph]	Ignition switch ON	—	Equivalent to odometer reading in combination meter
TACHO METER [rpm]	Ignition switch ON	While driving	Equivalent to tachometer reading NOTE: 8191.875 is displayed when the malfunction signal is received
FUEL METER [L]	Ignition switch ON	—	Values according to fuel level
W TEMP METER [°C]	Ignition switch ON	—	Values according to engine coolant temperature NOTE: 215 is displayed when the malfunction signal is input
FUEL CAP W/L	Ignition switch ON	Fuel filler cap warning display ON	On
		Fuel filler cap warning display OFF	Off
ABS W/L	Ignition switch ON	ABS warning lamp ON	On
		ABS warning lamp OFF	Off
VDC/TCS IND	Ignition switch ON	VDC OFF indicator lamp ON	On
		VDC OFF indicator lamp OFF	Off
SLIP IND	Ignition switch ON	SLIP Indicator lamp ON	On
		SLIP indicator lamp OFF	Off
BRAKE W/L	Ignition switch ON	Brake warning lamp ON	On
		Brake warning lamp OFF	Off
DOOR W/L	Ignition switch ON	Door warning lamp ON	On
		Door warning lamp OFF	Off
HI-BEAM IND	Ignition switch ON	High-beam indicator lamp ON	On
		High-beam indicator lamp OFF	Off
TURN IND	Ignition switch ON	Turn signal indicator lamp ON	On
		Turn signal indicator lamp OFF	Off
LIGHT IND	Ignition switch ON	Light indicator lamp ON	On
		Light indicator lamp OFF	Off
OIL W/L	Ignition switch ON	Oil pressure warning lamp ON	On
		Oil pressure warning lamp OFF	Off
MIL	Ignition switch ON	Malfunction indicator lamp ON	On
		Malfunction indicator lamp OFF	Off

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition		Value/Status
CRUISE IND	Ignition switch ON	CRUISE indicator lamp ON	On
		CRUISE indicator lamp OFF	Off
O/D OFF IND	Ignition switch ON	O/D OFF indicator lamp ON	On
		O/D OFF indicator lamp OFF	Off
4WD W/L	Ignition switch ON	AWD warning lamp ON	On
		AWD warning lamp OFF	Off
4WD LOCK IND	Ignition switch ON	AWD LOCK indicator lamp ON	On
		AWD LOCK indicator lamp OFF	Off
FUEL W/L	Ignition switch ON	Low-fuel warning lamp ON	On
		Low-fuel warning lamp OFF	Off
WASHER W/L	Ignition switch ON	Washer warning displayed	On
		Washer warning not displayed	Off
AIR PRES W/L	Ignition switch ON	Low tire pressure lamp ON	On
		Low tire pressure lamp OFF	Off
KEY G/Y W/L	Ignition switch ON	Key warning lamp (green/yellow) ON	On
		Key warning lamp (green/yellow) OFF	Off
LCD	Ignition switch ON	Engine start information display	B&P I
	Ignition switch ACC	Engine start information display	B&P N
	Ignition switch LOCK	Key ID warning display	ID NG
	Ignition switch LOCK	Steering lock information display	ROTAT
	Ignition switch LOCK	P position warning display	SFT P
	Ignition switch LOCK	Intelligent Key insert information display	INSRT
	Ignition switch LOCK	Intelligent Key low battery warning display	BATT
	Ignition switch ON	Take away warning display	NO KY
	Ignition switch LOCK	Key warning display	OUTKY
SHIFT IND	Ignition switch ON	ACC warning display	LK WN
		Shift position indicator P display	P
		Shift position indicator R display	R
		Shift position indicator N display	N
		Shift position indicator D display	D
	Ignition switch ON	Shift position indicator L display	L
		Overdrive control switch ON	On
		Overdrive control switch OFF	Off
M RANGE SW	Ignition switch ON	NOTE: This item is displayed, but cannot be monitored.	Off
NM RANGE SW	Ignition switch ON	NOTE: This item is displayed, but cannot be monitored.	Off

A

B

C

D

E

F

G

H

I

J

K

L

M

WCS

O

P

COMBINATION METER


< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition		Value/Status
AT SFT UP SW	Ignition switch ON	NOTE: This item is displayed, but cannot be monitored.	Off
AT SFT DWN SW	Ignition switch ON	NOTE: This item is displayed, but cannot be monitored.	Off
ST SFT UP SW	Ignition switch ON	NOTE: This item is displayed, but cannot be monitored.	Off
ST SFT DWN SW	Ignition switch ON	NOTE: This item is displayed, but cannot be monitored.	Off
PKB SW	Ignition switch ON	Parking brake switch ON	On
		Parking brake switch OFF	Off
BUCKLE SW	Ignition switch ON	Seat belt (driver side) not fastened	On
		Seat belt (driver side) fastened	Off
BRAKE OIL SW	Ignition switch ON	Brake fluid level switch ON	On
		Brake fluid level switch OFF	Off
DISTANCE [km]	Ignition switch ON	—	Possible driving distance calculated by combination meter
A/C AMP CONN	Ignition switch ON	Other than the following	On
		Receives ambient sensor power signal	Off
ENTER SW	Ignition switch ON	When is pressed	On
		Other than the above	Off
SELECT SW	Ignition switch ON	When is pressed	On
		Other than the above	Off
OUTSIDE TEMP [°C] or [°F]	Ignition switch ON	—	Equivalent to ambient temperature NOTE: This may not match the indicated value on the information display.
FUEL LOW SIG	Ignition switch ON	Low fuel warning displayed	On
		Low fuel warning not displayed	Off
BUZZER	Ignition switch ON	Buzzer ON	On
		Buzzer OFF	Off

NOTE:

Some items are not available according to vehicle specification.



TERMINAL LAYOUT



PHYSICAL VALUES

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			Value (Approx.)
1 (Y)	Ground	Battery power supply	Input	Ignition switch OFF	—	Battery voltage
2 (O)	Ground	IGN signal	Input	Ignition switch ON	—	Battery voltage
3 (B)	Ground	Ground	—	Ignition switch ON	—	0 V
5 (SB)	Ground	Illumination control signal	Output	Ignition switch ON	• Lighting switch 1ST • When meter illumination is maximum	 JPNIA0828GB
					• Lighting switch 1ST • When meter illumination is minimum	 JPNIA0827GB
8 (SB)	10 (O)	Trip reset signal	Input	Ignition switch ON	When trip reset switch is pressed.	0 V
					Other than the above	5 V
10 (O)	Ground	Meter control switch ground	—	Ignition switch ON	—	0 V
11 (L)	10 (O)	Enter switch signal	Input	Ignition switch ON	When  is pressed.	0 V
					Other than the above	5 V
12 (R)	10 (O)	Select switch signal	Input	Ignition switch ON	When  is pressed.	0 V
					Other than the above	5 V
13 (Y ^{*1} or V ^{*2})	10 (O)	Illumination control switch signal (+)	Input	Ignition switch ON	When  + is pressed.	0 V
					Other than the above	5 V
14 (GR)	10 (O)	Illumination control switch signal (-)	Input	Ignition switch ON	When  - is pressed.	0 V
					Other than the above	5 V
15 (BR)	Ground	Air bag signal	Input	Ignition switch ON	Air bag warning lamp ON	4 V
					Air bag warning lamp OFF	0 V

A

B

C

D

E

F

G

H

I

J

K

L

M



WCS

O

P



COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
18 (L)	Ground	Ambient sensor signal	Input	Ignition switch ON	Changes depending to ambient temperature.	 JSNIA0014GB
19 (P)	Ground	Ambient sensor power	Input	Ignition switch ON	—	5 V
20 (Y)	Ground	Ambient sensor ground	Input	Ignition switch ON	—	0 V
21 (L)	—	CAN-H	—	—	—	—
22 (P)	—	CAN-L	—	—	—	—
23 (B)	Ground	Ground	—	Ignition switch ON	—	0 V
24 (W)	Ground	Fuel level sensor signal ground	—	Ignition switch ON	—	0 V
25 (BR)	Ground	Alternator signal	Input	Ignition switch ON	Charge warning lamp ON	2 V
					Charge warning lamp OFF	12 V
26 (G)	Ground	Parking brake switch signal	Input	Ignition switch ON	Parking brake ON	0 V
					Parking brake OFF	5 V
27 (V)	Ground	Brake fluid level switch signal	Input	Ignition switch ON	Brake fluid level is normal	12 V
					Brake fluid level is less than LOW level	0 V
29 (R)	Ground	Washer level switch signal	Input	Ignition switch ON	Washer level switch ON	0 V
					Washer level switch OFF	5 V
30 (P)	Ground	Vehicle speed signal output (2-pulse)	Output	Ignition switch ON	Speedometer operated [When vehicle speed is approx. 40 km/h (25 MPH)]	NOTE: The maximum voltage varies depending on the specification (destination unit).
 JSNIA0015GB						

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
31 (V)	Ground	Vehicle speed signal output (8-pulse)	Output	Ignition switch ON	Speedometer operated [When vehicle speed is approx. 40 km/h (25 MPH)]	NOTE: The maximum voltage varies de- pending on the specification (destination unit).  JSNIA0012GB
32 (LG)	Ground	Overdrive control switch signal	Input	Ignition switch ON	Overdrive control switch pressed.	0 V
					Overdrive control switch not pressed.	12 V
34 (G)	Ground	Fuel level sensor signal	Input	Ignition switch ON	—	 JPNIA0740ZZ
35 (SB)	Ground	Seat belt buckle switch sig- nal (driver side)	Input	Ignition switch ON	When driver seat belt is fas- tened.	12 V
					When driver seat belt is un- fastened.	0 V
36 (R)	Ground	Seat belt buckle switch sig- nal (passenger side)	Input	Ignition switch ON	• When getting in the pas- senger seat. • When passenger seat belt is fastened.	12 V
					• When getting in the pas- senger seat. • When passenger seat belt is unfastened.	0 V

*1: Without automatic drive positioner

*2: With automatic drive positioner

A

B

C

D

E

F

G

H

I

J

K

L

M

WCS

O


P

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

Wiring Diagram - METER -

INFOID:0000000006847518




JCNWM5340GB

2010/09/06

COMBINATION METER


< ECU DIAGNOSIS INFORMATION >



JCNWM5341GB

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >



JCNWM5342GB

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

METER		Signal Name [Specification]							
Terminal No.	Color of Wire	Terminal No.	Color of Wire	Terminal No.	Color of Wire	Terminal No.	Color of Wire	Terminal No.	Color of Wire
1	SB	20	P	21	LG	22	W	23	Y
2	W	-	-	24	GR	-	-	25	Y
3	W	-	-	26	V	27	V	28	WL
4	R	-	-	29	P	30	P	31	O
5	O	-	-	32	BR	33	BR	34	SB
6	P	-	-	35	SB	36	LO	37	LG
7	L	-	-	38	BR	39	Y	40	Y
8	B	-	-	41	GR	42	SB	43	GR
9	LG	-	-	44	BR	45	BR	46	LG
10	V	-	-	47	SB	48	SHIELD	49	B
11	L	-	-	50	RW	51	R/L	52	B
12	BR	-	-	53	Y	54	LG	55	BR
13	P	-	-	56	P	57	L	58	R
14	BR	-	-	59	SHIELD	60	B	61	R/L
15	O	-	-	62	RW	63	LG	64	Y
16	G	-	-	65	BR	66	V	-	-
Connector No.		B4		NS16FW-CS		B19		NS16FW-CS	
Connector Name		WIRE TO WIRE							
Connector Type		NS16MW-CS		NS16FW-CS		NS16FW-CS		NS16FW-CS	

JCNWM5343GB

WCS

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

METER	Connector No.	B240	Connector Name	FUEL LEVEL SENSOR UNIT AND FUEL PUMP	Connector Type	EOSFY-RS			
	Connector No.	B214	Connector Name	WIRE TO WIRE	Connector Type	NSD6FW-CS			
	Connector No.	B209	Connector Name	WIRE TO WIRE	Connector Type	TK2NG-Y-BD			
SEAT BELT BUCKLE SWITCH (PASSENGER SIDE)	Connector No.	B437	Connector Name	SEAT BELT BUCKLE SWITCH (PASSENGER SIDE)	Connector Type	A03MW-P			
	Connector No.	B449	Connector Name	SEAT BELT BUCKLE SWITCH (DRIVER SIDE)	Connector Type	A03MW-P			
	Connector No.	B431	Connector Name	WIRE TO WIRE	Connector Type	NSD6BW-CS			
SEAT BELT BUCKLE SWITCH (DRIVER SIDE)	Connector No.	B437	Connector Name	SEAT BELT BUCKLE SWITCH (PASSENGER SIDE)	Connector Type	A03MW-P			
	Connector No.	B449	Connector Name	SEAT BELT BUCKLE SWITCH (DRIVER SIDE)	Connector Type	A03MW-P			
	Connector No.	B431	Connector Name	WIRE TO WIRE	Connector Type	NSD6BW-CS			
SEAT BELT BUCKLE SWITCH (PASSENGER SIDE)	Connector No.	B437	Connector Name	SEAT BELT BUCKLE SWITCH (PASSENGER SIDE)	Connector Type	A03MW-P			
	Connector No.	B449	Connector Name	SEAT BELT BUCKLE SWITCH (DRIVER SIDE)	Connector Type	A03MW-P			
	Connector No.	B431	Connector Name	WIRE TO WIRE	Connector Type	NSD6BW-CS			

JCNWM5344GB

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

ICNWM5345GB

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

METER		VALVE / ECU GND			
Connector No.	E27	26	B/W	WIRE TO WIRE	-
Connector Name	PARKING BRAKE SWITCH	72	Y	-	-
Connector Type	PO1FB-A	73	L	-	-
		74	W	-	-
		75	BR	-	-
		76	GR	-	-
		77	O	-	-
		78	Y	-	[With navigation system]
		78	G	-	[With iPod without navigation system]
		78	V	-	[Without iPod and navigation system]
		79	Y	-	-
		80	R	-	-
		81	W	-	-
		82	LG	-	-
		83	O	-	-
VALVE		VALVE / ECU GND			
Connector No.	E37	26	B/W	WIRE TO WIRE	-
Connector Name	BRAKE FLUID LEVEL SWITCH	72	Y	-	-
Connector Type	YY02FGY	73	L	-	-
		74	W	-	-
		75	BR	-	-
		76	GR	-	-
		77	O	-	-
		78	Y	-	-
		78	G	-	-
		78	V	-	-
		79	Y	-	-
		80	R	-	-
		81	W	-	-
		82	LG	-	-
		83	O	-	-
VALVE / ECU GND		VALVE / ECU GND			
Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
1	P	-	3	Y	-
			5	LG	-
			6	GR	-
			8	G	-
			11	P	-
			12	L	-
			13	Y	-
			14	O	-
			15	BR	-
			20	Y	-
			21	BR	-
			22	P	-
			24	L	-
			25	O	-
			28	SB	-
			29	W	-
			30	Y	-
			47	P	-
VALVE / ECU SUPPLY		VALVE / ECU SUPPLY			
Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
1	R	WSS RL SIG (-)	1	Y	-
2	Y	WSS RL SIG (-)	2	SB	-
3	L	WSS RL PWR (+)	3	SB	-
4	GR	CLUSTER SUPPLY	4	R	-
5	B	WSS FR PWR (+)	5	Y	-
6	W	WSS FR SIG (-)	6	SB	-
7	LG	LIS	7	L	-
8	V	WSS EL SIG (-)	8	SB	-
9	W	WSS EL PWR (+)	9	LG	-
10	SB	CLUSTER GND	10	GR	-
11	P	WSS RR PWR (+)	11	LG	-
12	V	WSS RR SIG (-)	12	V	-
13	B/W	MOTOR GND	13	BR	-
14	G	MOTOR SUPPLY	14	O	-
15	SB	BL5	15	LG	-
16	BR	CAN 2 H	16	SHIELD	-
17	GR	IGN	17	W	-
18		P	18	BR	-
19		CAN 1 L	19	Y	-
20		VDC OFF SW	20	SB	-
21		CAN 1 H	21	GR	-
22		CAN 2 L	22	SB	-
23		CAN 1 L	23	BR	-
24		CAN 2 H	24	Y	-
25		CAN 1 H	25	LG	-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-
		CAN 2 L			-
		CAN 1 L			-
		CAN 2 H			-
		CAN 1 H			-

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

METER		Connector No.	Connector Name	Terminal Color of Wire	Signal Name [Specification]	Terminal Color of Wire	Signal Name [Specification]	Terminal Color of Wire	Signal Name [Specification]	Terminal Color of Wire	Signal Name [Specification]
Connector No.	E338	Connector No.	E246								
Connector Name	WASHER LEVEL SWITCH	Connector Name	POWER INTELLIGENT POWER DISTRIBUTION MODULE								
Connector Type	Z012FBR	Connector Type	TH16FY-NH								
F12		Connector No.	Connector Name	Terminal Color of Wire	Signal Name [Specification]	Terminal Color of Wire	Signal Name [Specification]	Terminal Color of Wire	Signal Name [Specification]	Terminal Color of Wire	Signal Name [Specification]
Connector No.	E339	Connector No.	POWER INTELLIGENT POWER DISTRIBUTION MODULE								
Connector Name	WIRE TO WIRE	Connector Name	POWER INTELLIGENT POWER DISTRIBUTION MODULE								
Connector Type	NS12FBR-CS	Connector Type	TH120FY-GSI2-M4								
F23		Connector No.	Connector Name	Terminal Color of Wire	Signal Name [Specification]	Terminal Color of Wire	Signal Name [Specification]	Terminal Color of Wire	Signal Name [Specification]	Terminal Color of Wire	Signal Name [Specification]
Connector No.	E60	Connector No.	ALTERNATOR								
Connector Name		Connector Name									
Connector Type	HS33FB	Connector Type									
RHA40FB+RZ8-L-RH		Connector No.	Connector Name	Terminal Color of Wire	Signal Name [Specification]	Terminal Color of Wire	Signal Name [Specification]	Terminal Color of Wire	Signal Name [Specification]	Terminal Color of Wire	Signal Name [Specification]
Connector No.	F23	Connector No.	TCA (TRANSMISSION CONTROL MODULE)								
Connector Name		Connector Name									
Connector Type	RHA40FB+RZ8-L-RH	Connector Type									

JCNWM5347GB



WCS

A
B
C
D
E
F
G
H
I
J
K
L
M
N
P



COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

METER			
Connector No.	F123	Connector No.	M3
Connector Name	WIRE TO WIRE	Connector Name	WIRE TO WIRE
Connector Type	TK16FGY-IV	Connector Type	NS12FW-CS
			
Terminal No.	Color of Wire	Signal Name [Specification]	
1	L	-	
3	GR	6C BR	-
4	GB	7C B	-
5	R	8C G	-
6	L/R	9C GR	-
8	P	10C SB	-
10	Y/B	11C R	-
11	BR/W	12C O	-
12	BR	-	
13	G	-	
14	B	-	

FUSE BLOCK (J/B)			
Connector No.	M1	Connector No.	M11
Connector Name	FUSE BLOCK (J/B)	Connector Name	WIRE TO WIRE
Connector Type	NS12FW-M2	Connector Type	TH10FW-CS10-M3
			
Terminal No.	Color of Wire	Signal Name [Specification]	
9	10	11	12
10	11	12	13
11	12	13	14
12	13	14	15
13	14	15	16
14	15	16	-
15	16	-	-
16	-	-	-


DATA LINK CONNECTOR			
Connector No.	M4	Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FW	Connector Type	BD16FW
			
Terminal No.	Color of Wire	Signal Name [Specification]	
1	LG	-	
2	Y	-	
3	LG	-	
4	B	-	
5	B	-	
6	L	-	
7	O	-	
8	G	-	
9	S	-	
10	S	-	
11	S	-	
12	S	-	
13	P	-	
14	P	-	
15	Y	-	
16	Y	-	

FUSE BLOCK (J/B)			
Connector No.	M1	Connector No.	M11
Connector Name	FUSE BLOCK (J/B)	Connector Name	WIRE TO WIRE
Connector Type	NS12FW-M2	Connector Type	TH10FW-CS10-M3
			
Terminal No.	Color of Wire	Signal Name [Specification]	
1	2A 1A	-	
2	8A 7A 6A 5A 4A	-	
3	LG	-	
4	B	-	
5	B	-	
6	L	-	
7	O	-	
8	G	-	
9	S	-	
10	S	-	
11	S	-	
12	S	-	
13	P	-	
14	P	-	
15	Y	-	
16	Y	-	

JCNWM5348GB

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >



JCNWM5349GB

WCS

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

JCNWM5350GB

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

A
B
C
D
E
F
G

H
I
J
K
L
M

WCS

O
P

METER			
Connector No.	M172	AV COMM (H)	CAN-H
Connector Name	AV CONTROL UNIT	P	CAN-L
Connector Type	TH24FW-NH	L	CAN-H
		V	SW GND
		SHIELD	SHIELD
Terminal No.			
Color of Wire			
36	O	37	38
	SIGNAL VCC	39	40
37	SB	41	42
	SIGNAL GND	42	43
38	G	43	44
	HP	44	45
39	L	45	46
	COMM (DISP->CONT)	46	47
40	W	47	48
	RGE AREA (Y-S) SIGNAL	48	49
41	SHIELD	49	50
	SHIELD	50	R
42	B	51	P
	RGB SYNC	51	COMM (CONT->DISP)
43	G	52	SHIELD
	RGB (R-RED) SIGNAL	52	SHIELD
44	L	53	SHIELD
	RGB (G-GREEN) SIGNAL	53	SHIELD
45	Y	54	SHIELD
	RGB (B-BLUE) SIGNAL	54	SHIELD
46	V	55	SHIELD
	COMPOSITE IMAGE SIGNAL	55	SHIELD
47	LG	56	SHIELD
	COMPOSITE IMAGE SIGNAL	56	SHIELD
48	Y	57	SHIELD
	INVERTER VCC	57	SHIELD
49	BR	58	SHIELD
	INVERTER GND	58	SHIELD
50	R	59	SHIELD
	VP	59	SHIELD
51	P	60	SHIELD
	COMM (CONT->DISP)	60	SHIELD
52	SHIELD	61	SHIELD
53	SHIELD	62	SHIELD
54	SHIELD	63	SHIELD
55	SHIELD	64	SHIELD
56	SHIELD	65	SHIELD
57	SHIELD	66	SHIELD
58	SHIELD	67	SHIELD
59	SHIELD	68	SHIELD
60	SHIELD	69	SHIELD
61	SHIELD	70	SHIELD
62	SHIELD	71	SHIELD
63	SHIELD	72	SHIELD
64	SHIELD	73	SHIELD
65	SHIELD	74	SHIELD
66	SHIELD	75	SHIELD
67	SHIELD	76	SHIELD
68	SHIELD	77	SHIELD
69	SHIELD	78	SHIELD
70	SHIELD	79	SHIELD
71	SHIELD	80	SHIELD
72	SHIELD	81	SHIELD
73	SHIELD	82	SHIELD
74	SHIELD	83	SHIELD
75	SHIELD	84	SHIELD
76	SHIELD	85	SHIELD
77	SHIELD	86	SHIELD
78	SHIELD	87	SHIELD
79	SHIELD	88	SHIELD
80	SHIELD	89	SHIELD
81	SHIELD	90	SHIELD
82	SHIELD	91	SHIELD
83	SHIELD	92	SHIELD
84	SHIELD	93	SHIELD
85	SHIELD	94	SHIELD
86	SHIELD	95	SHIELD
87	SHIELD	96	SHIELD
88	SHIELD	97	SHIELD
89	SHIELD	98	SHIELD
90	SHIELD	99	SHIELD
91	SHIELD	100	SHIELD
92	SHIELD	101	SHIELD
93	SHIELD	102	SHIELD
94	SHIELD	103	SHIELD
95	SHIELD	104	SHIELD
96	SHIELD	105	SHIELD
97	SHIELD	106	SHIELD
98	SHIELD	107	SHIELD
99	SHIELD	108	SHIELD
100	SHIELD	109	SHIELD
101	SHIELD	110	SHIELD
102	SHIELD	111	SHIELD
103	SHIELD	112	SHIELD
104	SHIELD	113	SHIELD
105	SHIELD	114	SHIELD
106	SHIELD	115	SHIELD
107	SHIELD	116	SHIELD
108	SHIELD	117	SHIELD
109	SHIELD	118	SHIELD
110	SHIELD	119	SHIELD
111	SHIELD	120	SHIELD
112	SHIELD	121	SHIELD
113	SHIELD	122	SHIELD
114	SHIELD	123	SHIELD
115	SHIELD	124	SHIELD
116	SHIELD	125	SHIELD
117	SHIELD	126	SHIELD
118	SHIELD	127	SHIELD
119	SHIELD	128	SHIELD
120	SHIELD	129	SHIELD
121	SHIELD	130	SHIELD
122	SHIELD	131	SHIELD
123	SHIELD	132	SHIELD
124	SHIELD	133	SHIELD
125	SHIELD	134	SHIELD
126	SHIELD	135	SHIELD
127	SHIELD	136	SHIELD
128	SHIELD	137	SHIELD
129	SHIELD	138	SHIELD
130	SHIELD	139	SHIELD
131	SHIELD	140	SHIELD
132	SHIELD	141	SHIELD
133	SHIELD	142	SHIELD
134	SHIELD	143	SHIELD
135	SHIELD	144	SHIELD
136	SHIELD	145	SHIELD
137	SHIELD	146	SHIELD
138	SHIELD	147	SHIELD
139	SHIELD	148	SHIELD
140	SHIELD	149	SHIELD
141	SHIELD	150	SHIELD
142	SHIELD	151	SHIELD
143	SHIELD	152	SHIELD
144	SHIELD	153	SHIELD
145	SHIELD	154	SHIELD
146	SHIELD	155	SHIELD
147	SHIELD	156	SHIELD
148	SHIELD	157	SHIELD
149	SHIELD	158	SHIELD
150	SHIELD	159	SHIELD
151	SHIELD	160	SHIELD
152	SHIELD	161	SHIELD
153	SHIELD	162	SHIELD
154	SHIELD	163	SHIELD
155	SHIELD	164	SHIELD
156	SHIELD	165	SHIELD
157	SHIELD	166	SHIELD
158	SHIELD	167	SHIELD
159	SHIELD	168	SHIELD
160	SHIELD	169	SHIELD
161	SHIELD	170	SHIELD
162	SHIELD	171	SHIELD
163	SHIELD	172	SHIELD
164	SHIELD	173	SHIELD
165	SHIELD	174	SHIELD
166	SHIELD	175	SHIELD
167	SHIELD	176	SHIELD
168	SHIELD	177	SHIELD
169	SHIELD	178	SHIELD
170	SHIELD	179	SHIELD
171	SHIELD	180	SHIELD
172	SHIELD	181	SHIELD
173	SHIELD	182	SHIELD
174	SHIELD	183	SHIELD
175	SHIELD	184	SHIELD
176	SHIELD	185	SHIELD
177	SHIELD	186	SHIELD
178	SHIELD	187	SHIELD
179	SHIELD	188	SHIELD
180	SHIELD	189	SHIELD
181	SHIELD	190	SHIELD
182	SHIELD	191	SHIELD
183	SHIELD	192	SHIELD
184	SHIELD	193	SHIELD
185	SHIELD	194	SHIELD
186	SHIELD	195	SHIELD
187	SHIELD	196	SHIELD
188	SHIELD	197	SHIELD
189	SHIELD	198	SHIELD
190	SHIELD	199	SHIELD
191	SHIELD	200	SHIELD
192	SHIELD	201	SHIELD
193	SHIELD	202	SHIELD
194	SHIELD	203	SHIELD
195	SHIELD	204	SHIELD
196	SHIELD	205	SHIELD
197	SHIELD	206	SHIELD
198	SHIELD	207	SHIELD
199	SHIELD	208	SHIELD
200	SHIELD	209	SHIELD
201	SHIELD	210	SHIELD
202	SHIELD	211	SHIELD
203	SHIELD	212	SHIELD
204	SHIELD	213	SHIELD
205	SHIELD	214	SHIELD
206	SHIELD	215	SHIELD
207	SHIELD	216	SHIELD
208	SHIELD	217	SHIELD
209	SHIELD	218	SHIELD
210	SHIELD	219	SHIELD
211	SHIELD	220	SHIELD
212	SHIELD	221	SHIELD
213	SHIELD	222	SHIELD
214	SHIELD	223	SHIELD
215	SHIELD	224	SHIELD
216	SHIELD	225	SHIELD
217	SHIELD	226	SHIELD
218	SHIELD	227	SHIELD
219	SHIELD	228	SHIELD
220	SHIELD	229	SHIELD
221	SHIELD	230	SHIELD
222	SHIELD	231	SHIELD
223	SHIELD	232	SHIELD
224	SHIELD	233	SHIELD
225	SHIELD	234	SHIELD
226	SHIELD	235	SHIELD
227	SHIELD	236	SHIELD
228	SHIELD	237	SHIELD
229	SHIELD	238	SHIELD
230	SHIELD	239	SHIELD
231	SHIELD	240	SHIELD
232	SHIELD	241	SHIELD
233	SHIELD	242	SHIELD
234	SHIELD	243	SHIELD
235	SHIELD	244	SHIELD
236	SHIELD	245	SHIELD
237	SHIELD	246	SHIELD
238	SHIELD	247	SHIELD
239	SHIELD	248	SHIELD
240	SHIELD	249	SHIELD
241	SHIELD	250	SHIELD
242	SHIELD	251	SHIELD
243	SHIELD	252	SHIELD
244	SHIELD	253	SHIELD
245	SHIELD	254	SHIELD
246	SHIELD	255	SHIELD
247	SHIELD	256	SHIELD
248	SHIELD	257	SHIELD
249	SHIELD	258	SHIELD
250	SHIELD	259	SHIELD
251	SHIELD	260	SHIELD
252	SHIELD	261	SHIELD
253	SHIELD	262	SHIELD
254	SHIELD	263	SHIELD
255	SHIELD	264	SHIELD
256	SHIELD	265	SHIELD
257	SHIELD	266	SHIELD
258	SHIELD	267	SHIELD
259	SHIELD	268	SHIELD
260	SHIELD	269	SHIELD
261	SHIELD	270	SHIELD
262	SHIELD	271	SHIELD
263	SHIELD	272	SHIELD
264	SHIELD	273	SHIELD
265	SHIELD	274	SHIELD
266	SHIELD	275	SHIELD
267	SHIELD	276	SHIELD
268	SHIELD	277	SHIELD
269	SHIELD	278	SHIELD
270	SHIELD	279	SHIELD
271	SHIELD	280	SHIELD
272	SHIELD	281	SHIELD
273	SHIELD	282	SHIELD
274	SHIELD	283	SHIELD
275	SHIELD	284	SHIELD
276	SHIELD	285	SHIELD
277	SHIELD	286	SHIELD
278	SHIELD	287	SHIELD
279	SHIELD	288	SHIELD
280	SHIELD	289	SHIELD
281	SHIELD	290	SHIELD
282	SHIELD	291	SHIELD
283	SHIELD	292	SHIELD
284	SHIELD	293	SHIELD
285	SHIELD	294	SHIELD
286	SHIELD	295	SHIELD
287	SHIELD	296	SHIELD
288	SHIELD	297	SHIELD
289	SHIELD	298	SHIELD
290	SHIELD	299	SHIELD
291	SHIELD	300	SHIELD
292	SHIELD	301	SHIELD
293	SHIELD	302	SHIELD
294	SHIELD	303	SHIELD
295	SHIELD	304	SHIELD
296	SHIELD	305	SHIELD
297	SHIELD	306	SHIELD
298	SHIELD	307	SHIELD
299	SHIELD	308	SHIELD
300	SHIELD	309	SHIELD
301	SHIELD	310	SHIELD
302	SHIELD	311	SHIELD
303	SHIELD	312	SHIELD
304	SHIELD	313	SHIELD
305	SHIELD	314	SHIELD
306	SHIELD	315	SHIELD
307	SHIELD	316	SHIELD
308	SHIELD	317	SHIELD
309	SHIELD	318	SHIELD
310	SHIELD	319	SHIELD
311	SHIELD	320	SHIELD
312	SHIELD	321	SHIELD
313	SHIELD	322	SHIELD
314	SHIELD	323	SHIELD
315	SHIELD	324	SHIELD
316	SHIELD	325	SHIELD
317	SHIELD	326	SHIELD
318	SHIELD	327	SHIELD
319	SHIELD	328	SHIELD
320	SHIELD	329	SHIELD
321	SHIELD	330	SHIELD
322	SHIELD	331	SHIELD
323	SHIELD	332	SHIELD
324	SHIELD	333	SHIELD
325	SHIELD	334	SHIELD
326	SHIELD	335	SHIELD
327	SHIELD	336	SHIELD
328	SHIELD	337	SHIELD
329	SHIELD	338	SHIELD
330	SHIELD	339	SHIELD
331	SHIELD	340	SHIELD
332	SHIELD	341	SHIELD
333	SHIELD	342	SHIELD
334	SHIELD	343	SHIELD
335	SHIELD	344	SHIELD
336	SHIELD	345	SH

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

Function		Specifications
Speedometer		
Tachometer		Reset to zero by suspending communication.
Engine coolant temperature gauge		
Illumination control		When suspending communication, changes to nighttime mode.
Information display	Door open warning	The display turns off by suspending communication.
	Parking brake release warning	
	Low tire pressure warning	
	Fuel filler cap warning	
	Instantaneous fuel warning	• When reception time of an abnormal signal is 2 seconds or less, the last received datum is used for calculation to indicate the result.
	Average fuel consumption	• When reception time of an abnormal signal is more than two seconds, the last result calculated during normal condition is indicated.
	Average vehicle speed	
	Travel distance	
Buzzer		The buzzer turns off by suspending communication.
Warning lamp/indicator lamp	ABS warning lamp	The lamp turns on by suspending communication.
	SLIP indicator lamp	
	Brake warning lamp	
	AWD warning lamp	
	Malfunction indicator lamp	
	Low tire pressure warning lamp	The lamp turns ON after flashing for 1 minute.
	High beam indicator lamp	The lamp turns off by suspending communication.
	Turn signal indicator lamp	
	Light indicator lamp	
	Oil pressure warning lamp	
	CRUISE indicator lamp	
	O/D OFF indicator lamp	
	VDC OFF indicator lamp	
	AWD LOCK indicator lamp	
	Key warning lamp	

DTC Index

INFOID:0000000006262259

Display contents of CONSULT-III	Diagnostic item is detected when ...	Refer to
CAN COMM CIRCUIT [U1000]	When combination meter is not transmitting or receiving CAN communication signal for 2 seconds or more.	MWI-39. "Diagnosis Procedure"
CONTROL UNIT (CAN) [U1010]	When detecting error during the initial diagnosis of the CAN controller of combination meter.	MWI-40. "Diagnosis Procedure"
VEHICLE SPEED [B2205]	The abnormal vehicle speed signal is input from the ABS actuator and electric unit (control unit) for 2 seconds or more.	MWI-41. "Diagnosis Procedure"

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

Display contents of CONSULT-III	Diagnostic item is detected when ...	Refer to
ENGINE SPEED [B2267]	If ECM continuously transmits abnormal engine speed signals for 2 seconds or more.	MWI-42 "Diagnosis Procedure"
WATER TEMP [B2268]	If ECM continuously transmits abnormal engine coolant temperature signals for 60 seconds or more.	MWI-43 "Diagnosis Procedure"

A

B

C

D

E

F

G

H

I

J

K

L

M

WCS

O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)

Reference Value

INFOID:0000000006856177

VALUES ON THE DIAGNOSIS TOOL

CONSULT-III MONITOR ITEM

Monitor Item	Condition	Value/Status
FR WIPER HI	Other than front wiper switch HI	Off
	Front wiper switch HI	On
FR WIPER LOW	Other than front wiper switch LO	Off
	Front wiper switch LO	On
FR WASHER SW	Front washer switch OFF	Off
	Front washer switch ON	On
FR WIPER INT	Other than front wiper switch INT/AUTO	Off
	Front wiper switch INT/AUTO	On
FR WIPER STOP	Front wiper is not in STOP position	Off
	Front wiper is in STOP position	On
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	Wiper intermittent dial position
RR WIPER ON	Other than rear wiper switch ON	Off
	Rear wiper switch ON	On
RR WIPER INT	Other than rear wiper switch INT	Off
	Rear wiper switch INT	On
RR WASHER SW	Rear washer switch OFF	Off
	Rear washer switch ON	On
RR WIPER STOP	Rear wiper is in STOP position	Off
	Rear wiper is not in STOP position	On
TURN SIGNAL R	Other than turn signal switch RH	Off
	Turn signal switch RH	On
TURN SIGNAL L	Other than turn signal switch LH	Off
	Turn signal switch LH	On
TAIL LAMP SW	Other than lighting switch 1ST and 2ND	Off
	Lighting switch 1ST or 2ND	On
HI BEAM SW	Other than lighting switch HI	Off
	Lighting switch HI	On
HEAD LAMP SW 1	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
HEAD LAMP SW 2	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
PASSING SW	Other than lighting switch PASS	Off
	Lighting switch PASS	On
AUTO LIGHT SW	Other than lighting switch AUTO	Off
	Lighting switch AUTO	On
FR FOG SW	Front fog lamp switch OFF	Off
	Front fog lamp switch ON	On
RR FOG SW	NOTE: The item is indicated, but not monitored.	Off

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
DOOR SW-DR	Driver door closed	Off
	Driver door opened	On
DOOR SW-AS	Passenger door closed	Off
	Passenger door opened	On
DOOR SW-RR	Rear RH door closed	Off
	Rear RH door opened	On
DOOR SW-RL	Rear LH door closed	Off
	Rear LH door opened	On
DOOR SW-BK	Back door closed	Off
	Back door opened	On
CDL LOCK SW	Other than power door lock switch LOCK	Off
	Power door lock switch LOCK	On
CDL UNLOCK SW	Other than power door lock switch UNLOCK	Off
	Power door lock switch UNLOCK	On
KEY CYL LK-SW	Other than driver door key cylinder LOCK position	Off
	Driver door key cylinder LOCK position	On
KEY CYL UN-SW	Other than driver door key cylinder UNLOCK position	Off
	Driver door key cylinder UNLOCK position	On
KEY CYL SW-TR	NOTE: The item is indicated, but not monitored.	Off
HAZARD SW	Hazard switch is OFF	Off
	Hazard switch is ON	On
REAR DEF SW	Rear window defogger switch OFF	Off
NOTE: For models with BOSE audio system this item is not monitored.	Rear window defogger switch ON	On
TR CANCEL SW	NOTE: The item is indicated, but not monitored.	Off
TR/BD OPEN SW	Back door opener switch OFF	Off
	While the back door opener switch is turned ON	On
TRNK/HAT MNTR	NOTE: The item is indicated, but not monitored.	Off
RKE-LOCK	LOCK button of Intelligent Key is not pressed	Off
	LOCK button of Intelligent Key is pressed	On
RKE-UNLOCK	UNLOCK button of Intelligent Key is not pressed	Off
	UNLOCK button of Intelligent Key is pressed	On
RKE-TR/BD	BACK DOOR OPEN button of Intelligent Key is not pressed	Off
	BACK DOOR OPEN button of Intelligent Key is pressed	On
RKE-PANIC	PANIC button of Intelligent Key is not pressed	Off
	PANIC button of Intelligent Key is pressed	On
RKE-P/W OPEN	UNLOCK button of Intelligent Key is not pressed	Off
	UNLOCK button of Intelligent Key is pressed and held	On
RKE-MODE CHG	LOCK/UNLOCK button of Intelligent Key is not pressed and held simultaneously	Off
	LOCK/UNLOCK button of Intelligent Key is pressed and held simultaneously	On

A
 B
 C
 D
 E
 F
 G
 H
 I
 J
 K
 L
 M
 O
 P
 WCS

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
OPTICAL SENSOR	Bright outside of the vehicle	Close to 5 V
	Dark outside of the vehicle	Close to 0 V
REQ SW -DR	Driver door request switch is not pressed	Off
	Driver door request switch is pressed	On
REQ SW -AS	Passenger door request switch is not pressed	Off
	Passenger door request switch is pressed	On
REQ SW -RR	NOTE: The item is indicated, but not monitored.	Off
REQ SW -RR	NOTE: The item is indicated, but not monitored.	Off
REQ SW -BD/TR	Back door request switch is not pressed	Off
	Back door request switch is pressed	On
PUSH SW	Push-button ignition switch (push switch) is not pressed	Off
	Push-button ignition switch (push switch) is pressed	On
IGN RLY2 -F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
ACC RLY -F/B	NOTE: The item is indicated, but not monitored.	Off
CLUCH SW	NOTE: The item is indicated, but not monitored.	Off
BRAKE SW 1	The brake pedal is depressed when No. 7 fuse is blown	Off
	The brake pedal is not depressed when No. 7 fuse is blown, or No. 7 fuse is normal	On
BRAKE SW 2	The brake pedal is not depressed	Off
	Stop lamp switch 1 signal circuit is normal	On
DETE/CANCL SW	Selector lever in P position	Off
	Selector lever in any position other than P	On
SFT PN/N SW	Selector lever in any position other than P and N	Off
	Selector lever in P or N position	On
S/L -LOCK	NOTE: The item is indicated, but not monitored.	Off
S/L -UNLOCK	NOTE: The item is indicated, but not monitored.	Off
S/L RELAY-F/B	NOTE: The item is indicated, but not monitored.	Off
UNLK SEN -DR	Driver door is unlocked	Off
	Driver door is locked	On
PUSH SW -IPDM	Push-button ignition switch (push-switch) is not pressed	Off
	Push-button ignition switch (push-switch) is pressed	On
IGN RLY1 -F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
DETE SW -IPDM	Selector lever in any position other than P	Off
	Selector lever in P position	On
SFT PN -IPDM	Selector lever in any position other than P and N	Off
	Selector lever in P or N position	On
SFT P -MET	Selector lever in any position other than P	Off
	Selector lever in P position	On

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
SFT N -MET	Selector lever in any position other than N	Off
	Selector lever in N position	On
ENGINE STATE	Engine stopped	Stop
	While the engine stalls	Stall
	At engine cranking	Crank
	Engine running	Run
S/L LOCK-IPDM	NOTE: The item is indicated, but not monitored.	Off
S/L UNLK-IPDM	NOTE: The item is indicated, but not monitored.	Off
S/L RELAY-REQ	NOTE: The item is indicated, but not monitored.	Off
VEH SPEED 1	While driving	Equivalent to speedometer reading
VEH SPEED 2	While driving	Equivalent to speedometer reading
DOOR STAT-DR	Driver door is locked	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Driver door is unlocked	UNLOCK
DOOR STAT-AS	Passenger door is locked	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Passenger door is unlocked	UNLOCK
ID OK FLAG	Power supply position in LOCK position	Reset
	Power supply position in any position other than LOCK	Set
PRMT ENG STRT	The engine start is prohibited	Reset
	The engine start is permitted	Set
PRMT RKE STRT	NOTE: The item is indicated, but not monitored.	Reset
KEY SW -SLOT	Intelligent Key is not inserted into key slot	Off
	Intelligent Key is inserted into key slot	On
RKE OPE COUN1	During the operation of Intelligent Key	Operation frequency of Intelligent Key
RKE OPE COUN2	NOTE: The item is indicated, but not monitored.	—
CONFIRM ID ALL	The Intelligent Key ID that the key slot receives is not recognized by any Intelligent Key ID registered to BCM.	Yet
	The Intelligent Key ID that the key slot receives is recognized by any Intelligent Key ID registered to BCM.	Done
CONFIRM ID4	The Intelligent Key ID that the key slot receives is not recognized by the fourth Intelligent Key ID registered to BCM.	Yet
	The Intelligent Key ID that the key slot receives is recognized by the fourth Intelligent Key ID registered to BCM.	Done
CONFIRM ID3	The Intelligent Key ID that the key slot receives is not recognized by the third Intelligent Key ID registered to BCM.	Yet
	The Intelligent Key ID that the key slot receives is recognized by the third Intelligent Key ID registered to BCM.	Done

A

B

C

D

E

F

G

H

I

J

K

L

M

WCS

O

P

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
CONFIRM ID2	The Intelligent Key ID that the key slot receives is not recognized by the second Intelligent Key ID registered to BCM.	Yet
	The Intelligent Key ID that the key slot receives is recognized by the second Intelligent Key ID registered to BCM.	Done
CONFIRM ID1	The Intelligent Key ID that the key slot receives is not recognized by the first Intelligent Key ID registered to BCM.	Yet
	The Intelligent Key ID that the key slot receives is recognized by the first Intelligent Key ID registered to BCM.	Done
TP 4	The ID of fourth Intelligent Key is not registered to BCM	Yet
	The ID of fourth Intelligent Key is registered to BCM	Done
TP 3	The ID of third Intelligent Key is not registered to BCM	Yet
	The ID of third Intelligent Key is registered to BCM	Done
TP 2	The ID of second Intelligent Key is not registered to BCM	Yet
	The ID of second Intelligent Key is registered to BCM	Done
TP 1	The ID of first Intelligent Key is not registered to BCM	Yet
	The ID of first Intelligent Key is registered to BCM	Done
AIR PRESS FL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front LH tire
AIR PRESS FR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front RH tire
AIR PRESS RR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear RH tire
AIR PRESS RL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear LH tire
ID REGST FL1	ID of front LH tire transmitter is registered	Done
	ID of front LH tire transmitter is not registered	Yet
ID REGST FR1	ID of front RH tire transmitter is registered	Done
	ID of front RH tire transmitter is not registered	Yet
ID REGST RR1	ID of rear RH tire transmitter is registered	Done
	ID of rear RH tire transmitter is not registered	Yet
ID REGST RL1	ID of rear LH tire transmitter is registered	Done
	ID of rear LH tire transmitter is not registered	Yet
WARNING LAMP	Tire pressure indicator OFF	Off
	Tire pressure indicator ON	On
BUZZER	Tire pressure warning alarm is not sounding	Off
	Tire pressure warning alarm is sounding	On

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

TERMINAL LAYOUT



PHYSICAL VALUES

A
B
C
D
E
F
G
H
I
J
K
L
M


WCS

O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
1 (W)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
2 (GR)	Ground	P/W power supply (BAT)	Output	Ignition switch OFF	Battery voltage
3 (L)	Ground	P/W power supply (RAP)	Output	Ignition switch ON	Battery voltage
4 (P)	Ground	Interior room lamp power supply	Output	Interior room lamp battery saver is activated. (Cuts the interior room lamp power supply)	0 V
				Interior room lamp battery saver is not activated. (Outputs the interior room lamp power supply)	Battery voltage
5 (G)	Ground	Passenger door UN- LOCK	Output	Passenger door	UNLOCK (Actuator is activated)
					0 V
7 (Y)	Ground	Step lamp	Output	Step lamp	ON
					0 V
8 (V)	Ground	All doors LOCK	Output	All doors	LOCK (Actuator is activated)
					0 V
9 (G)	Ground	Driver door UNLOCK	Output	Driver door	UNLOCK (Actuator is activated)
					0 V
10 (P)	Ground	Rear RH door and rear LH door UN- LOCK	Output	Rear RH door and rear LH door	UNLOCK (Actuator is activated)
					0 V
11 (LG)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
13 (B)	Ground	Ground	—	Ignition switch ON	0 V
14 (O)	Ground	Push-button ignition switch illumination ground	Output	Tail lamp	OFF
					ON
15 (L)	Ground	ACC indicator lamp	Output	Ignition switch	OFF (LOCK and ON indicator lamps are not illuminated.)
					ACC







NOTE:
When the illumination brightening/dimming level is in the neutral position

JSNIA0010GB




BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
17 (G)	Ground	Turn signal RH	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch RH	 PKID0926E 6.5 V
18 (BR)	Ground	Turn signal LH	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch LH	 PKID0926E 6.5 V
19 (Y)	Ground	Room lamp timer control	Output	Interior room lamp	OFF	Battery voltage
					ON	0 V
23 (BR)	Ground	Back door open	Output	Back door	OPEN (Back door opener actuator is activated)	Battery voltage
					Other than OPEN (Back door opener actuator is not activated)	0 V
26 (G)	Ground	Rear wiper	Output	Rear wiper	OFF (Stopped)	0 V
					ON (Operated)	Battery voltage
34 (B)	Ground	Luggage room anten- na (-)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compart- ment	 JMKIA0062GB
					When Intelligent Key is not in the passenger compart- ment	 JMKIA0063GB





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
35 (W)	Ground	Luggage room antenna (+)	Output Ignition switch OFF	When Intelligent Key is in the passenger compartment
				 JMKA0062GB
38 (L)	Ground	Rear bumper antenna (-)	Output When the back door request switch is operat- ed with ignition switch OFF	When Intelligent Key is not in the passenger compartment
				 JMKA0063GB
39 (BR)	Ground	Rear bumper anten- na (+)	Output When the back door request switch is operat- ed with ignition switch OFF	When Intelligent Key is in the antenna detection area
				 JMKA0062GB
47 (L)	Ground	Ignition relay (IPDM E/R) control	Output Ignition switch	OFF or ACC
				Battery voltage
				ON 0 V





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
52 (R)	Ground	Starter relay control	Output	Ignition switch ON	When selector lever is in P or N position	Battery voltage
					When selector lever is not in P or N position	0.3 V
				Ignition switch OFF		0 V
60 (BR)	Ground	Push-button ignition switch (push switch)	Input	Push-button igni- tion switch (push switch)	Pressed	0 V
					Not pressed	Battery voltage
61 (R)	Ground	Back door request switch	Input	Back door re- quest switch	ON (Pressed)	0 V
					OFF (Not pressed)	 <small>JPMIA0016GB</small> 1.0 V
64 (GR)	Ground	Warning buzzer	Output	Warning buzzer	Sounding	0 V
					Not sounding	Battery voltage
65 (O)	Ground	Rear wiper stop posi- tion	Input	Rear wiper	In stop position	 <small>JPMIA0016GB</small> 1.0 V
					Not in stop position	0 V
66 (Y)	Ground	Back door switch	Input	Back door switch	OFF (When back door closes)	 <small>JPMIA0011GB</small> 11.8 V
					ON (When back door opens)	0 V
67 (LG)	Ground	Back door opener switch	Input	Back door opener switch	Pressed	0 V
					Not pressed	 <small>JPMIA0011GB</small> 11.8 V







BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
68 (W)	Ground	Rear RH door switch	Input	<p>Rear RH door switch</p> <p>OFF (When rear RH door closes)</p>  <p>JPMIA0011GB</p> <p>11.8 V</p>
69 (R)	Ground	Rear LH door switch	Input	<p>Rear LH door switch</p> <p>OFF (When rear LH door closes)</p>  <p>JPMIA0011GB</p> <p>11.8 V</p>
72 (B)	Ground	Room antenna (-) (Center console)	Output	<p>Ignition switch OFF</p> <p>When Intelligent Key is in the passenger compartment</p>  <p>JMKIA0062GB</p> <p>1 s</p>
				<p>When Intelligent Key is not in the passenger compartment</p>  <p>JMKIA0063GB</p> <p>1 s</p>

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	
	+	-			
73 (W)	Ground	Room antenna (+) (Center console)	Output	When Intelligent Key is in the passenger compart- ment	 <small>JMKIA0062GB</small>
				Ignition switch OFF	
74 (Y)	Ground	Passenger door an- tenna (-)	Output	When the pas- senger door re- quest switch is operated with ig- nition switch OFF	 <small>JMKIA0063GB</small>
				When Intelligent Key is not in the passenger compart- ment	
75 (LG)	Ground	Passenger door an- tenna (+)	Output	When the pas- senger door re- quest switch is operated with ig- nition switch OFF	 <small>JMKIA0062GB</small>
				When Intelligent Key is in the antenna detection area	
				When Intelligent Key is not in the antenna detection area	 <small>JMKIA0063GB</small>
				When Intelligent Key is in the antenna detection area	
				When Intelligent Key is not in the antenna detection area	 <small>JMKIA0062GB</small>
				When Intelligent Key is in the antenna detection area	
				When Intelligent Key is not in the antenna detection area	 <small>JMKIA0063GB</small>
				When Intelligent Key is in the antenna detection area	

A

B

C

D

E

F

G

H

I

J

K

L

M

WCS

O

P







BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)		
	Signal name	Input/ Output				
+	-					
76 (V)	Ground	Driver door antenna (-)	Output	When Intelligent Key is in the antenna detection area		
				When the driver door request switch is oper- ated with ignition switch OFF		
77 (P)	Ground	Driver door antenna (+)	Output	When Intelligent Key is not in the antenna detection area		
				When the driver door request switch is oper- ated with ignition switch OFF		
80 (SB)	Ground	NATS antenna amp.	Input/ Output	During waiting	Ignition switch is pressed while inserting Intelligent Key into the key slot.	Just after pressing ignition switch. Pointer of tester should move.
81 (O)	Ground	NATS antenna amp.	Input/ Output	During waiting	Ignition switch is pressed while inserting Intelligent Key into the key slot.	Just after pressing ignition switch. Pointer of tester should move.
82 (BR)	Ground	Ignition relay [fuse block (J/B)] control	Output	Ignition switch	OFF or ACC	0 V
					ON	Battery voltage

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	
	+	-			
83 (P)	Ground	Remote keyless entry receiver communication	Input/ Output	During waiting	 JMKIA0064GB
				When operating either button on Intelligent Key	 JMKIA0065GB
87 (R)	Ground	Combination switch INPUT 5	Input	All switches OFF (Wiper intermittent dial 4)	 JPMIA0041GB 1.4 V
				Front fog lamp switch ON (Wiper intermittent dial 4)	 JPMIA0037GB 1.3 V
				Rear wiper switch ON (Wiper intermittent dial 4)	 JPMIA0039GB 1.3 V
				Any of the conditions below with all switches OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 6 • Wiper intermittent dial 7 	 JPMIA0040GB 1.3 V

A

B

C

D

E

F

G

H

I

J

K

L

M





WCS

O

P

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	
	Signal name	Input/ Output			
+	-				
88 (GR)	Ground	Combination switch INPUT 3	Input	 All switches OFF (Wiper intermittent dial 4)  Lighting switch HI (Wiper intermittent dial 4)  Lighting switch 2ND (Wiper intermittent dial 4)  Rear washer switch ON (Wiper intermittent dial 4)  Any of the conditions below with all switches OFF • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 3	1.4 V 1.3 V 1.3 V 1.3 V 1.3 V
90 (P)	Ground	CAN - L	Input/ Output	—	
91 (L)	Ground	CAN - H	Input/ Output	—	


BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
92 (R)	Ground	Key slot illumination	Output	OFF Key slot illumination Blinking ON
93 (P)	Ground	ON indicator lamp	Output	OFF (LOCK and ACC indicator lamps are not illuminated.) ON
95 (L)	Ground	ACC relay control	Output	Ignition switch OFF ACC or ON
96 (Y)	Ground	CVT shift selector (detention switch) power supply	Output	—
99 (V)	Ground	Selector lever P position switch	Input	Selector lever P position Any position other than P
100 (P)	Ground	Passenger door request switch	Input	Passenger door request switch ON (Pressed) OFF (Not pressed)
101 (W)	Ground	Driver door request switch	Input	Driver door request switch ON (Pressed) OFF (Not pressed)
102 (Y)	Ground	Blower fan motor relay control	Output	Ignition switch OFF or ACC ON
103 (L)	Ground	Remote keyless entry receiver power supply	Output	Ignition switch OFF



JPMIA0015GB



JPMIA0016GB



JPMIA0016GB

A

B

C

D

E

F

G

H

I

J

K

L

M






WCS

O

P






BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
107 (O)	Ground	Combination switch INPUT 1	Combination switch (Wiper intermit- tent dial 4)	All switches OFF  1.4 V
				Turn signal switch LH  1.3 V
				Turn signal switch RH  1.3 V
				Front wiper switch LO  1.3 V
				Front washer switch ON  1.3 V







BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	
	Signal name	Input/ Output			
108 (P)	Ground	Combination switch INPUT 4	Input	All switches OFF (Wiper intermittent dial 4)	 <p>JPMIA0041GB 1.4 V</p>
				Lighting switch AUTO (Wiper intermittent dial 4)	 <p>JPMIA0038GB 1.3 V</p>
				Lighting switch 1ST (Wiper intermittent dial 4)	 <p>JPMIA0036GB 1.3 V</p>
				Rear wiper switch INT (Wiper intermittent dial 4)	 <p>JPMIA0040GB 1.3 V</p>
				Any of the conditions below with all switches OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6 	 <p>JPMIA0039GB 1.3 V</p>



BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
109 (SB)	Ground	Combination switch INPUT 2	Combination switch (Wiper intermittent dial 4)	All switches OFF
				 JPMIA0041GB 1.4 V
				 JPMIA0037GB 1.3 V
				 JPMIA0036GB 1.3 V
				 JPMIA0038GB 1.3 V
110 (G)	Ground	Hazard switch	Hazard switch	ON
				 JPMIA0040GB 0 V
			OFF	 JPMIA0012GB 1.1 V




BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	A B C D E F G H I J K L M WCS O P
	+	-	Signal name	Input/ Output	
112 (R)	Ground	Rain sensor serial link	Input/ Output	Ignition switch ON	 JPMIA0156GB 8.7 V
113 (O)	Ground	Optical sensor	Input	Ignition switch ON	When bright outside of the vehicle
					Close to 5 V
116 (GR)	Ground	Stop lamp switch 1	Input	—	When dark outside of the vehicle
					Close to 0 V
118 (L)	Ground	Stop lamp switch 2	Input	Stop lamp switch	OFF (Brake pedal is not depressed)
					0 V
119 (W)	Ground	Front door lock assembly driver side (Unlock sensor)	Input	Driver door	ON (Brake pedal is depressed)
					Battery voltage
121 (Y)	Ground	Key slot switch	Input	LOCK status (unlock sensor switch OFF)	
				UNLOCK status (unlock sensor switch ON)	
123 (G)	Ground	IGN feedback	Input	Ignition switch	0 V
					Battery voltage
124 (R)	Ground	Passenger door switch	Input	Passenger door switch	OFF (When passenger door closes)
					 JPMIA0011GB 11.8 V
					ON (When passenger door opens)
					0 V





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
130 (BR)	Ground	Rear window defogger switch	Input Ignition switch ON	Rear window defogger switch OFF
				(V) 15 10 5 0  10 ms JPMIA0012GB 1.1 V
132 (G)	Ground	Power window switch communication	Input/ Output Ignition switch ON	Rear window defogger switch ON
				(V) 15 10 5 0  10 ms JPMIA0013GB 10.2 V
				Ignition switch OFF or ACC Battery voltage
133 (W)	Ground	Push-button ignition switch illumination	Output Push-button ignition switch illumination	ON (When tail lamps OFF)
				NOTE: The pulse width of this wave is varied by the illumination brightening/dimming level.
				(V) 15 10 5 0  10 ms JPMIA0159GB
134 (R)	Ground	LOCK indicator lamp	Output LOCK indicator lamp	OFF (ACC and ON indicator lamps are not illuminated.)
				Battery voltage
				ON 0 V
137 (P)	Ground	Receiver and sensor ground	Input Ignition switch ON	0 V
138 (V)	Ground	Receiver and sensor power supply	Output Ignition switch	OFF 0 V
				ACC or ON 5.0 V

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)		
	+	-				
139 (O)	Ground	Tire pressure receiver communication	Input/ Output	Ignition switch ON	Standby state	 OCC3881D
					When receiving the signal from the transmitter	 OCC3880D
140 (GR)	Ground	Selector lever P/N position	Input	Selector lever	P or N position	Battery voltage
					Except P and N positions	0 V
141 (O)	Ground	Security indicator	Output	Security indicator	ON	0 V
					Blinking	 JPMIA0014GB 11.3 V
					OFF	Battery voltage
142 (L)	Ground	Combination switch OUTPUT 5	Output	Combination switch (Wiper intermittent dial 4)	All switches OFF	0 V
					Lighting switch 1ST	
					Lighting switch HI	
					Lighting switch 2ND	
					Turn signal switch RH	 JPMIA0031GB 10.7 V
143 (W)	Ground	Combination switch OUTPUT 1	Output	Combination switch	All switches OFF (Wiper intermittent dial 4)	0 V
					Front wiper switch HI (Wiper intermittent dial 4)	
					Rear wiper switch INT (Wiper intermittent dial 4)	
					Any of the conditions below with all switches OFF	
					<ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 3 • Wiper intermittent dial 6 • Wiper intermittent dial 7 	
						 JPMIA0032GB 10.7 V

A

B

C

D

E

F

G

H

I

J

K

L

M




WCS

O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)		
	+	-	Signal name	Input/ Output		
144 (P)	Ground	Combination switch OUTPUT 2	Output	Combination switch	All switches OFF (Wiper intermittent dial 4)	0 V
					Front washer switch ON (Wiper intermittent dial 4)	 <small>JPMIA0033GB</small>
					Rear wiper switch ON (Wiper intermittent dial 4)	
					Rear washer switch ON (Wiper intermittent dial 4)	
					Any of the conditions below with all switches OFF	<ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6 <small>10.7 V</small>
145 (V)	Ground	Combination switch OUTPUT 3	Output	Combination switch (Wiper intermittent dial 4)	All switches OFF	0 V
					Front wiper switch INT/AUTO	 <small>JPMIA0034GB</small>
					Front wiper switch LO	
					Lighting switch AUTO	
146 (Y)	Ground	Combination switch OUTPUT 4	Output	Combination switch (Wiper intermittent dial 4)	All switches OFF	0 V
					Front fog lamp switch ON	 <small>JPMIA0035GB</small>
					Lighting switch 2ND	
					Lighting switch PASS	
					Turn signal switch LH	
150 (SB)	Ground	Driver door switch	Input	Driver door switch	OFF (When driver door closes)	 <small>JPMIA0011GB</small>
					ON (When driver door opens)	
151 (G)	Ground	Rear window defogger relay control	Output	Rear window defogger	Active	0 V
					Not activated	Battery voltage


BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Wiring Diagram - BCM -

INFOID:000000006856178

BCM (BODY CONTROL MODULE)



2010/09/06


JCMWN0014GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

: Except for Mexico
 : With power seat without automatic drive positioner


* : This connector is not shown in "Harness Layout".





JCMWN0015GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >



* : This connector is not shown in "Harness Layout".




JCMWN0016GB

A B C D E F G H I J K L M N O P

WCS

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >




JCMWN0017GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

: With automatic back door
 : Without automatic back door



JCMWN0018GB

WCS

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)

Connector No.	Connector No.	Connector Name	Connector Type	Diagram
M103	M119	COMBINATION SWITCH	NS16FW-CS	
TH1BFW-NH				

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
1	G	RR	4	P	INTERIOR ROOM AMP POWER SUPPLY
2	Y	OUTPUT 4	5	G	PASSENGER DOOR UNLOCK OUTPUT
3	O	FR	7	Y	STEP LAMP OUTPUT
4	W	IGN	8	V	ALL DOOR FUEL LID UNLOCK OUTPUT
5	V	OUTPUT 3	9	G	DRIVER DOOR FUEL LID UNLOCK OUTPUT
6	B	GND	10	P	REAR DOOR UNLOCK OUTPUT
7	GR	INPUT 3	11	LG	BAT (FUSE)
8	L	OUTPUT 5	13	B	GND
9	SB	INPUT 2	14	O	PUSH-BUTTON IGNITION SW LHL ND
10	P	INPUT 4	15	L	ACC IND
11	O	INPUT 1	17	G	TURN SIGNAL RH
12	W	OUTPUT 1	18	BR	TURN SIGNAL LH
13	R	INPUT 5	19	Y	ROOM LAMP TIMER CONTROL
14	P	OUTPUT 2	20		

Connector No.	Connector No.	Connector Name	Connector Type	Diagram
M113	M120	BCM (BODY CONTROL MODULE)	NS12FW-CS	
MD3FB-LC				

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
1	W	BAT (F-L)	23	BR	BACK DOOR OPEN OUTPUT
2	GR	POWER WINDOW POWER SUPPLY (BAT)	26	G	REAR WIPER OUTPUT
3	L	POWER WINDOW POWER SUPPLY (RAP)			

Connector No.	Connector No.	Connector Name	Connector Type	Diagram
M122	M122	BCM (BODY CONTROL MODULE)	TH40FB-NH	

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
1	W	BAT (F-L)	2	BR	ROOM ANT 2+
2	GR	POWER WINDOW POWER SUPPLY (BAT)	3	W	PASSENGER DOOR ANT+
3	L	POWER WINDOW POWER SUPPLY (RAP)	4	Y	DRIVER DOOR ANT-

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
1	W	CAN-H	2	BR	IGN RELAY (F/B) CONT
2	GR	KEYLESS ENTRY RECEIVER SIGNAL	3	P	KEYLESS ENTRY RECEIVER SIGNAL
3	L	COMBI SW INPUT 3	7	R	COMBI SW INPUT 5
4	Y	CAN-L	8	GR	COMBI SW INPUT 3
5	GR	IGN RELAY (F/B) ON	9	P	IGN RELAY (F/B) ON
6	Y	KEY SLOT ILL	9	L	KEY SLOT ILL
7	GR	ON IND	9	R	ON IND
8	Y	ACU RELAY CONT	9	Y	CVT SHIFT SELECTOR POWER SUPPLY
9	GR	SHIFT P	9	Y	PASSENGER DOOR REQUEST SW
10	P	DRIVER DOOR REQUEST SW	10	W	DRIVER DOOR REQUEST SW
11	Y	BLOWER FAN MOTOR RELAY CONT	102	Y	BLOWER FAN MOTOR RELAY CONT
12	GR	KEYLESS ENTRY RECEIVER POWER SUPPLY	103	L	KEYLESS ENTRY RECEIVER POWER SUPPLY
13	Y	COMBI SW INPUT 1	107	O	COMBI SW INPUT 1
14	GR	COMBI SW INPUT 4	108	P	COMBI SW INPUT 4
15	Y	COMBI SW INPUT 2	109	SB	COMBI SW INPUT 2
16	GR	HAZARD SW	110	G	HAZARD SW
17	Y	IGN RELAY PDME/R CONT	47	L	IGN RELAY PDME/R CONT
18	GR	STARTER RELAY CONT	52	R	STARTER RELAY CONT
19	Y	EXTRA IN 2	60	BR	EXTRA IN 2
20	GR	BACK DOOR OPENER REQUEST SW	61	R	BACK DOOR OPENER REQUEST SW
21	Y	REQUEST SW BUZZER	64	GR	REQUEST SW BUZZER
22	GR	REAR WIPER STOP POSITION	65	O	REAR WIPER STOP POSITION
23	Y	BACK DOOR SW	66	Y	BACK DOOR SW
24	GR	BACK DOOR OPENER SW	67	LG	BACK DOOR OPENER SW
25	Y	REAR RH DOOR SW	68	W	REAR RH DOOR SW
26	GR	REAR LH DOOR SW	69	R	REAR LH DOOR SW

JCMWN0019GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

A

B

C

D

E

F

G

H

I

J

K

L

M

WCS

O

P

BCM (BODY CONTROL MODULE)		
Connector No.	M123	
Connector Name	BCM (BODY CONTROL MODULE)	
Connector Type	TH40FG-NH	
HS		
Terminal No.	Color of Wire	Signal Name [Specification]
112	R	RAIN SENSOR SERIAL LINK
113	O	OPTICAL SENSOR
116	GR	FUSE CHECK
118	L	STOP LAMP SW
119	W	DR DOOR UNLOCK SENSOR
121	Y	KEY SLOT SW
123	G	IGN F/B
124	R	PASSENGER DOOR SW
130	BR	REAR DEFOGGER SW
132	G	POWER WINDOW SW COMM
133	W	PUSH-BUTTON IGNITION SW/ILL POWER
134	R	LOCK RD
137	P	RECEIVER / SENSOR GND
138	V	RECEIVER / SENSOR POWER SUPPLY
139	O	TIRE PRESS RECEIVER SIGNAL
140	CR	SHIFT LIP
141	O	SECURITY INDICATOR OUTPUT
142	L	COMBI SW OUTPUT 5
143	W	COMBI SW OUTPUT 1
144	P	COMBI SW OUTPUT 2
145	V	COMBI SW OUTPUT 3
146	Y	COMBI SW OUTPUT 4
150	SB	DRIVER DOOR SW
151	G	REAR WINDOW DEFROGGER RELAY

JCMWN0020GB

INFOID:0000000006856179

Fail-safe

FAIL-SAFE CONTROL BY DTC

BCM performs fail-safe control when any DTC are detected.

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Display contents of CONSULT	Fail-safe	Cancellation
B2190: NATS ANTENNA AMP	Inhibit engine cranking	Erase DTC
B2191: DIFFERENCE OF KEY	Inhibit engine cranking	Erase DTC
B2192: ID DISCORD BCM-ECM	Inhibit engine cranking	Erase DTC
B2193: CHAIN OF BCM-ECM	Inhibit engine cranking	Erase DTC
B2195: ANTI SCANNING	Inhibit engine cranking	Ignition switch ON → OFF
B2560: STARTER CONT RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> • Starter control relay signal • Starter relay status signal
B2607: S/L RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> • Steering lock relay signal (Request signal) • Steering lock relay signal (Condition signal)
B2608: STARTER RELAY	Inhibit engine cranking	500 ms after the following signal communication status becomes consistent <ul style="list-style-type: none"> • Starter motor relay control signal • Starter relay status signal (CAN)
B260A: IGNITION RELAY	Inhibit engine cranking	500 ms after the following conditions are fulfilled <ul style="list-style-type: none"> • IGN relay (IPDM E/R) control signal: OFF (Battery voltage) • Ignition ON signal (CAN to IPDM E/R): OFF (Request signal) • Ignition ON signal (CAN from IPDM E/R): OFF (Condition signal)
B260F: ENG STATE SIG LOST	Maintains the power supply position attained at the time of DTC detection	When any of the following conditions are fulfilled <ul style="list-style-type: none"> • Power position changes to ACC • Receives engine status signal (CAN)
B2617: STARTER RELAY CIRC	Inhibit engine cranking	1 second after the starter motor relay control inside BCM becomes normal
B2618: BCM	Inhibit engine cranking	1 second after the ignition relay (IPDM E/R) control inside BCM becomes normal
B261E: VEHICLE TYPE	Inhibit engine cranking	BCM initialization

HIGH FLASHER OPERATION

BCM detects the turn signal lamp circuit status by the current value.

BCM increases the turn signal lamp blinking speed if the bulb or harness open is detected with the turn signal lamp operating.

NOTE:

The blinking speed is normal while activating the hazard warning lamp.

FAIL-SAFE CONTROL BY RAIN SENSOR MALFUNCTION

- BCM judges the rain sensor serial link error by the rain sensor serial link condition and detects the rain sensor malfunction by rain sensor malfunction signal.
- When BCM detects the rain sensor serial link error or the rain sensor malfunction while front wiper AUTO operation, BCM operates a fail-safe control.

NOTE:

If rain sensor malfunction is detected when ignition switch is turned OFF ⇒ ON and front wiper switch is INT/AUTO position, BCM operates a fail-safe control.

REAR WIPER MOTOR PROTECTION

BCM detects the rear wiper stopping position according to the rear wiper stop position signal.

When the rear wiper stop position signal does not change for more than 5 seconds while driving the rear wiper, BCM stops power supply to protect the rear wiper motor.

Condition of cancellation

1. More than 1 minute is passed after the rear wiper stop.
2. Turn rear wiper switch OFF.
3. Operate the rear wiper switch or rear washer switch.

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

DTC Inspection Priority Chart

INFOID:000000006856180

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	DTC	
1	B2562: LOW VOLTAGE	
2	<ul style="list-style-type: none">• U1000: CAN COMM• U1010: CONTROL UNIT(CAN)	
3	<ul style="list-style-type: none">• B2190: NATS ANTENNA AMP• B2191: DIFFERENCE OF KEY• B2192: ID DISCORD BCM-ECM• B2193: CHAIN OF BCM-ECM• B2195: ANTI SCANNING	
	<ul style="list-style-type: none">• B2553: IGNITION RELAY• B2555: STOP LAMP• B2556: PUSH-BTN IGN SW• B2557: VEHICLE SPEED• B2560: STARTER CONT RELAY• B2601: SHIFT POSITION• B2602: SHIFT POSITION• B2603: SHIFT POSI STATUS• B2604: PNP SW• B2605: PNP SW• B2608: STARTER RELAY• B260A: IGNITION RELAY• B260F: ENG STATE SIG LOST• B2614: ACC RELAY CIRC• B2615: BLOWER RELAY CIRC• B2616: IGN RELAY CIRC• B2617: STARTER RELAY CIRC• B2618: BCM• B261A: PUSH-BTN IGN SW• B261E: VEHICLE TYPE• B26EA: KEY REGISTRATION• C1729: VHCL SPEED SIG ERR• U0415: VEHICLE SPEED SIG	
	<ul style="list-style-type: none">• C1704: LOW PRESSURE FL• C1705: LOW PRESSURE FR• C1706: LOW PRESSURE RR• C1707: LOW PRESSURE RL• C1708: [NO DATA] FL• C1709: [NO DATA] FR• C1710: [NO DATA] RR• C1711: [NO DATA] RL• C1716: [PRESSDATA ERR] FL• C1717: [PRESSDATA ERR] FR• C1718: [PRESSDATA ERR] RR• C1719: [PRESSDATA ERR] RL• C1734: CONTROL UNIT	
5	<ul style="list-style-type: none">• B2622: INSIDE ANTENNA• B2623: INSIDE ANTENNA	

DTC Index

INFOID:000000006856181

NOTE:

The details of time display are as follows.

- CRNT: A malfunction is detected now.
- PAST: A malfunction was detected in the past.

IGN counter is displayed on Freeze Frame Data. For details of Freeze Frame Data, refer to [BCS-18, "COMMON ITEM : CONSULT-III Function \(BCM - COMMON ITEM\)"](#).

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
No DTC is detected. further testing may be required.	—	—	—	—	—
U1000: CAN COMM	—	—	—	—	BCS-38
U1010: CONTROL UNIT(CAN)	—	—	—	—	BCS-39
U0415: VEHICLE SPEED SIG	—	—	—	—	BCS-40
B2190: NATS ANTENNA AMP	×	—	—	—	SEC-42
B2191: DIFFERENCE OF KEY	×	—	—	—	SEC-45
B2192: ID DISCORD BCM-ECM	×	—	—	—	SEC-46
B2193: CHAIN OF BCM-ECM	×	—	—	—	SEC-48
B2195: ANTI SCANNING	×	—	—	—	SEC-49
B2553: IGNITION RELAY	—	×	—	—	PCS-48
B2555: STOP LAMP	—	×	—	—	SEC-50
B2556: PUSH-BTN IGN SW	—	×	×	—	SEC-52
B2557: VEHICLE SPEED	×	×	×	—	SEC-54
B2560: STARTER CONT RELAY	×	×	×	—	SEC-55
B2562: LOW VOLTAGE	—	×	—	—	BCS-41
B2601: SHIFT POSITION	×	×	×	—	SEC-56
B2602: SHIFT POSITION	×	×	×	—	SEC-59
B2603: SHIFT POSI STATUS	×	×	×	—	SEC-61
B2604: PNP SW	×	×	×	—	SEC-64
B2605: PNP SW	×	×	×	—	SEC-66
B2608: STARTER RELAY	×	×	×	—	SEC-68
B260A: IGNITION RELAY	×	×	×	—	PCS-50
B260F: ENG STATE SIG LOST	×	×	×	—	SEC-70
B2614: ACC RELAY CIRC	—	×	×	—	PCS-52
B2615: BLOWER RELAY CIRC	—	×	×	—	PCS-55
B2616: IGN RELAY CIRC	—	×	×	—	PCS-58
B2617: STARTER RELAY CIRC	×	×	×	—	SEC-72
B2618: BCM	×	×	×	—	PCS-61
B261A: PUSH-BTN IGN SW	—	×	×	—	SEC-75
B261E: VEHICLE TYPE	×	×	×	(Turn ON for 15 seconds)	SEC-78
B2622: INSIDE ANTENNA	—	×	—	—	DLK-91
B2623: INSIDE ANTENNA	—	×	—	—	DLK-93
B26EA: KEY REGISTRATION	—	×	×	(Turn ON for 15 seconds)	SEC-71
C1704: LOW PRESSURE FL	—	—	—	—	WT-23
C1705: LOW PRESSURE FR	—	—	—	—	
C1706: LOW PRESSURE RR	—	—	—	—	
C1707: LOW PRESSURE RL	—	—	—	—	

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
C1708: [NO DATA] FL	—	—	—	×	WT-25
C1709: [NO DATA] FR	—	—	—	×	
C1710: [NO DATA] RR	—	—	—	×	
C1711: [NO DATA] RL	—	—	—	×	
C1716: [PRESSDATA ERR] FL	—	—	—	×	WT-28
C1717: [PRESSDATA ERR] FR	—	—	—	×	
C1718: [PRESSDATA ERR] RR	—	—	—	×	
C1719: [PRESSDATA ERR] RL	—	—	—	×	
C1729: VHCL SPEED SIG ERR	—	—	—	×	WT-29
C1734: CONTROL UNIT	—	—	—	×	WT-30

A

B

C

D

E

F

G

H

I

J

K

L

M

WCS

O

P

THE PARKING BRAKE RELEASE WARNING CONTINUES SOUNDING, OR DOES NOT SOUND

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

THE PARKING BRAKE RELEASE WARNING CONTINUES SOUNDING, OR DOES NOT SOUND

Description

INFOID:0000000006262265

- The parking brake warning buzzer sounds continuously during vehicle travel though the parking brake is released.
- The parking brake warning buzzer does not sound at all even though driving the vehicle with the parking brake applied.

Diagnosis Procedure

INFOID:0000000006262266

1. CHECK PARKING BRAKE WARNING LAMP

1. Start the engine.
2. Check the operation of the brake warning lamp by operating the parking brake.

When parking brake is applied : ON

When parking brake is released : OFF

Is the inspection result normal?

- YES >> Replace the combination meter.
NO >> GO TO 2.

2. CHECK PARKING BRAKE SWITCH SIGNAL CIRCUIT

Perform a check for the parking brake switch signal circuit. Refer to [MWI-54, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair harness or connector.

3. CHECK PARKING BRAKE SWITCH

Perform a unit check for the parking brake switch. Refer to [MWI-54, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace the combination meter.
NO >> Replace the parking brake switch. Refer to [PB-6, "Exploded View"](#).

THE LIGHT REMINDER WARNING DOES NOT SOUND

< SYMPTOM DIAGNOSIS >

THE LIGHT REMINDER WARNING DOES NOT SOUND

Description

INFOID:0000000006262267

Light reminder warning chime does not sound even though headlamp is illuminated.

Diagnosis Procedure

INFOID:0000000006262268

1.CHECK COMBINATION SWITCH (LIGHT SWITCH) OPERATION

Check that the headlamps operate normally by operating the combination switch (light switch).

Do they operate normally?

YES >> GO TO 2.

NO >> Refer to [EXL-152, "Symptom Table"](#) (xenon type) or [EXL-325, "Symptom Table"](#) (halogen type).

2.CHECK FRONT DOOR SWITCH (DRIVER SIDE) SIGNAL CIRCUIT

Perform the check for the front door switch (driver side) signal circuit. Refer to [DLK-97, "WITH AUTOMATIC BACK DOOR : Diagnosis Procedure"](#) (with automatic back door) or [DLK-100, "WITHOUT AUTOMATIC BACK DOOR : Diagnosis Procedure"](#) (without automatic back door).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3.CHECK FRONT DOOR SWITCH (DRIVER SIDE)

Perform a unit check for the front door switch (driver side). Refer to [DLK-99, "WITH AUTOMATIC BACK DOOR : Component Inspection"](#) (with automatic back door) or [DLK-102, "WITHOUT AUTOMATIC BACK DOOR : Component Inspection"](#) (without automatic back door).

Is the inspection result normal?

YES >> Replace the BCM. Refer to [BCS-85, "Removal and Installation"](#).

NO >> Replace the front door switch (driver side). Refer to [DLK-348, "Removal and Installation"](#).

A

B

C

D

E

F

G

H

I

J

K

L

M

WCS

O

P

THE SEAT BELT WARNING CONTINUES SOUNDING, OR DOES NOT SOUND

< SYMPTOM DIAGNOSIS >

THE SEAT BELT WARNING CONTINUES SOUNDING, OR DOES NOT SOUND

Description

INFOID:0000000006262269

- Seat belt reminder warning does not sound.
- Seat belt reminder warning sounds continuously.

Diagnosis Procedure

INFOID:0000000006262270

1. CHECK SEAT BELT WARNING LAMP

1. Turn ignition switch ON.
2. Check the operation of the seat belt warning lamp in the combination meter.

Seat belt fastened	: OFF
Seat belt not fastened	: ON

Is the inspection result normal?

- YES >> GO TO 2.
NO >> GO TO 4.

2. CHECK BCM OUTPUT SIGNAL

Check if the light reminder warning chime is activated by performing BCM active test. Refer to [WCS-20, "BUZZER : CONSULT-III Function \(BCM - BUZZER\)".](#)

Is the inspection result normal?

- YES >> INSPECTION END
NO >> GO TO 3.

3. CHECK COMBINATION METER INPUT SIGNAL

Check if buzzer switches to proper condition (On/Off) on data monitor of combination meter. Refer to [MWI-35, "CONSULT-III Function \(METER/M&A\)".](#)

Buzzer active condition	: On
Buzzer non-active condition	: Off

Is the inspection result normal?

- YES >> Replace the combination meter.
NO >> Replace the BCM. Refer to [BCS-85, "Removal and Installation".](#)

4. CHECK SEAT BELT BUCKLE SWITCH CIRCUIT

Perform the check for the seat belt buckle switch circuit. Refer to [WCS-25, "Diagnosis Procedure".](#)

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Repair harness or connector.

5. CHECK SEAT BELT BUCKLE SWITCH (DRIVER SIDE)

Perform a unit check for the seat belt buckle switch (driver side). Refer to [WCS-26, "Component Inspection".](#)

Is the inspection result normal?

- YES >> Replace the combination meter.
NO >> Replace the seat belt buckle. Refer to [SB-9, "SEAT BELT BUCKLE : Removal and Installation".](#)

THE KEY WARNING DOES NOT SOUND

< SYMPTOM DIAGNOSIS >

THE KEY WARNING DOES NOT SOUND

Description

INFOID:0000000006262271

The key warning chime does not sound under the following conditions.

- Key inserted into the key slot. (Key slot switch ON)
- Ignition switch is not in ON or START. (Ignition switch signal OFF)
- Front door switch (driver side) is open. [Door switch signal (driver side) ON]

Diagnosis Procedure

INFOID:0000000006262272

1. CHECK BCM INPUT SIGNAL

1. Connect CONSULT-III.
2. Select the "Data Monitor" of "BCM (BUZZER)" and check the "KEY SW-SLOT" monitor value. Refer to [BCS-47, "Reference Value"](#).

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-85, "Removal and Installation"](#).
NO >> GO TO 2.

2. CHECK KEY SLOT SWITCH SIGNAL CIRCUIT

Check the key slot switch signal circuit. Refer to [DLK-131, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check applicable parts, and repair or replace corresponding parts.

3. CHECK DOOR SWITCH SIGNAL (DRIVER SIDE) CIRCUIT

Check the door switch signal (driver side) circuit. Refer to [DLK-97, "WITH AUTOMATIC BACK DOOR : Diagnosis Procedure"](#) (with automatic back door) or [DLK-100, "WITHOUT AUTOMATIC BACK DOOR : Diagnosis Procedure"](#) (without automatic back door).

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair harness or connector.

4. CHECK FRONT DOOR SWITCH (DRIVER SIDE)

Check the front door switch (driver side). Refer to [DLK-99, "WITH AUTOMATIC BACK DOOR : Component Inspection"](#) (with automatic back door) or [DLK-102, "WITHOUT AUTOMATIC BACK DOOR : Component Inspection"](#) (without automatic back door).

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-85, "Removal and Installation"](#).
NO >> Replace front door switch (driver side). Refer to [DLK-348, "Removal and Installation"](#).

A

B

C

D

E

F

G

H

I

J

K

L

M

WCS

O

P

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS FOR USA AND CANADA

FOR USA AND CANADA : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000006262273

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

FOR MEXICO

FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000006262274

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

PRECAUTIONS

< PRECAUTION >

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

A

B

C

D

E

F

G

H

I

J

K

L

M

WCS

O

P