

A
B
C
D
E

SECTION **BRC**

BRAKE CONTROL SYSTEM

CONTENTS

| | | |
|--|---|-----|
| | | BRC |
| VDC/TCS/ABS | Component Description19 | |
| BASIC INSPECTION 5 | ABS20 | |
| DIAGNOSIS AND REPAIR WORK FLOW 5 | System Diagram20 | G |
| Work Flow5 | System Description20 | |
| Diagnostic Work Sheet8 | Component Parts Location20 | |
| INSPECTION AND ADJUSTMENT 9 | Component Description23 | H |
| ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT9 | EBD24 | |
| ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description9 | System Diagram24 | I |
| ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement9 | System Description24 | |
| ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION9 | Component Parts Location24 | J |
| ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description9 | Component Description27 | |
| ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement9 | DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]28 | K |
| CALIBRATION OF DECEL G SENSOR 10 | CONSULT Function28 | |
| CALIBRATION OF DECEL G SENSOR : Description 10 | DTC/CIRCUIT DIAGNOSIS33 | L |
| CALIBRATION OF DECEL G SENSOR : Special Repair Requirement 10 | C1101, C1102, C1103, C1104 WHEEL SENSOR33 | |
| SYSTEM DESCRIPTION12 | Description33 | M |
| VDC12 | DTC Logic33 | |
| System Diagram12 | Diagnosis Procedure33 | N |
| System Description12 | Special Repair Requirement36 | |
| Component Parts Location12 | C1105, C1106, C1107, C1108 WHEEL SENSOR37 | O |
| Component Description15 | Description37 | |
| TCS16 | DTC Logic37 | P |
| System Diagram16 | Diagnosis Procedure37 | |
| System Description16 | Special Repair Requirement41 | |
| Component Parts Location16 | C1109 POWER AND GROUND SYSTEM42 | |
| | Description42 | |
| | DTC Logic42 | |
| | Diagnosis Procedure42 | |
| | Special Repair Requirement43 | |
| | C1110 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)44 | |

| | | | |
|---|-----------|--|-----------|
| Description | 44 | C1143 STEERING ANGLE SENSOR | 68 |
| DTC Logic | 44 | Description | 68 |
| Diagnosis Procedure | 44 | DTC Logic | 68 |
| Special Repair Requirement | 44 | Diagnosis Procedure | 68 |
| | | Special Repair Requirement | 70 |
| C1111 ABS MOTOR, MOTOR RELAY SYSTEM | 45 | C1144 INCOMPLETE STEERING ANGLE SENSOR ADJUSTMENT | 71 |
| Description | 45 | Description | 71 |
| DTC Logic | 45 | DTC Logic | 71 |
| Diagnosis Procedure | 45 | Diagnosis Procedure | 71 |
| Special Repair Requirement | 46 | Special Repair Requirement | 71 |
| C1113, C1145, C1146 YAW RATE/SIDE/DECEL G SENSOR | 47 | C1155 BRAKE FLUID LEVEL SWITCH | 73 |
| Description | 47 | Description | 73 |
| DTC Logic | 47 | DTC Logic | 73 |
| Diagnosis Procedure | 47 | Diagnosis Procedure | 73 |
| Special Repair Requirement | 48 | Component Inspection | 75 |
| | | Special Repair Requirement | 75 |
| C1115 WHEEL SENSOR | 50 | C1160 INCOMPLETE DECEL G SENSOR CALIBRATION | 77 |
| Description | 50 | Description | 77 |
| DTC Logic | 50 | DTC Logic | 77 |
| Diagnosis Procedure | 50 | Diagnosis Procedure | 77 |
| Special Repair Requirement | 55 | Special Repair Requirement | 77 |
| C1116 STOP LAMP SWITCH | 56 | C1161 INCOMPLETE SIDE G SENSOR CALIBRATION | 79 |
| Description | 56 | Description | 79 |
| DTC Logic | 56 | DTC Logic | 79 |
| Diagnosis Procedure | 56 | Diagnosis Procedure | 79 |
| Component Inspection | 57 | Special Repair Requirement | 79 |
| Special Repair Requirement | 57 | | |
| C1120, C1122, C1124, C1126 IN ABS SOL | 58 | C1162 INCOMPLETE PRESSURE SENSOR CALIBRATION | 80 |
| Description | 58 | Description | 80 |
| DTC Logic | 58 | DTC Logic | 80 |
| Diagnosis Procedure | 58 | Diagnosis Procedure | 80 |
| Special Repair Requirement | 59 | Special Repair Requirement | 80 |
| C1121, C1123, C1125, C1127 OUT ABS SOL.. | 60 | C1164, C1165 CV SYSTEM | 81 |
| Description | 60 | Description | 81 |
| DTC Logic | 60 | DTC Logic | 81 |
| Diagnosis Procedure | 60 | Diagnosis Procedure | 81 |
| Special Repair Requirement | 61 | Special Repair Requirement | 82 |
| C1130 ENGINE SIGNAL | 62 | C1166, C1167 SV SYSTEM | 83 |
| Description | 62 | Description | 83 |
| DTC Logic | 62 | DTC Logic | 83 |
| Diagnosis Procedure | 62 | Diagnosis Procedure | 83 |
| Special Repair Requirement | 62 | Special Repair Requirement | 84 |
| C1140 ACTUATOR RELAY SYSTEM | 64 | U1000 CAN COMM CIRCUIT | 85 |
| Description | 64 | Description | 85 |
| DTC Logic | 64 | DTC Logic | 85 |
| Diagnosis Procedure | 64 | Diagnosis Procedure | 85 |
| Special Repair Requirement | 65 | Special Repair Requirement | 85 |
| C1142 PRESS SENSOR | 66 | U1002 SYSTEM COMM (CAN) | 87 |
| Description | 66 | Description | 87 |
| DTC Logic | 66 | | |
| Diagnosis Procedure | 66 | | |
| Special Repair Requirement | 67 | | |

| | | | | |
|--|------------|---|------------|-----|
| DTC Logic | 87 | Diagnosis Procedure | 110 | |
| Diagnosis Procedure | 87 | THE BRAKING DISTANCE IS LONG | 111 | A |
| Special Repair Requirement | 88 | Diagnosis Procedure | 111 | |
| POWER SUPPLY AND GROUND CIRCUIT | 89 | ABS FUNCTION DOES NOT OPERATE | 112 | B |
| Description | 89 | Diagnosis Procedure | 112 | |
| Diagnosis Procedure | 89 | PEDAL VIBRATION OR ABS OPERATION | | C |
| Special Repair Requirement | 90 | SOUND OCCURS | 113 | |
| PARKING BRAKE SWITCH | 92 | Diagnosis Procedure | 113 | |
| Component Function Check | 92 | VEHICLE JERKS DURING VDC/TCS/ABS | | D |
| Diagnosis Procedure | 92 | CONTROL | 114 | |
| Component Inspection | 92 | Diagnosis Procedure | 114 | |
| VDC OFF SWITCH | 94 | NORMAL OPERATING CONDITION | 115 | E |
| Description | 94 | Description | 115 | |
| Component Function Check | 94 | PRECAUTION | 116 | BRC |
| Diagnosis Procedure | 94 | PRECAUTIONS | 116 | |
| Component Inspection | 95 | FOR USA AND CANADA | 116 | G |
| Special Repair Requirement | 95 | FOR USA AND CANADA : Precaution for Supple- | | |
| ABS WARNING LAMP | 96 | mental Restraint System (SRS) "AIR BAG" and | | H |
| Description | 96 | "SEAT BELT PRE-TENSIONER" | 116 | |
| Component Function Check | 96 | FOR USA AND CANADA : Precaution for Proce- | | I |
| Diagnosis Procedure | 96 | dure without Cowl Top Cover | 116 | |
| Special Repair Requirement | 96 | FOR USA AND CANADA : Precaution for Brake | | J |
| BRAKE WARNING LAMP | 97 | System | 116 | |
| Description | 97 | FOR USA AND CANADA : Precaution for Brake | | K |
| Component Function Check | 97 | Control | 117 | |
| Diagnosis Procedure | 97 | FOR USA AND CANADA : Precaution for Harness | | L |
| Special Repair Requirement | 97 | Repair | 117 | |
| VDC WARNING LAMP | 99 | FOR MEXICO | 118 | |
| Description | 99 | FOR MEXICO : Precaution for Supplemental Re- | | M |
| Component Function Check | 99 | straint System (SRS) "AIR BAG" and "SEAT BELT | | |
| Diagnosis Procedure | 99 | PRE-TENSIONER" | 118 | |
| Special Repair Requirement | 99 | FOR MEXICO : Precaution for Procedure without | | N |
| VDC OFF INDICATOR LAMP | 100 | Cowl Top Cover | 118 | |
| Description | 100 | FOR MEXICO : Precaution for Brake System | 118 | |
| Component Function Check | 100 | FOR MEXICO : Precaution for Brake Control | 119 | |
| Diagnosis Procedure | 100 | FOR MEXICO : Precaution for Harness Repair ... | 119 | |
| Special Repair Requirement | 101 | REMOVAL AND INSTALLATION | 121 | |
| ECU DIAGNOSIS INFORMATION | 102 | WHEEL SENSOR | 121 | |
| ABS ACTUATOR AND ELECTRIC UNIT | | FRONT WHEEL SENSOR | 121 | |
| (CONTROL UNIT) | 102 | FRONT WHEEL SENSOR : Exploded View | 121 | O |
| Reference Value | 102 | FRONT WHEEL SENSOR : Removal and Instal- | | P |
| Wiring Diagram -BRAKE CONTROL SYSTEM- | 105 | lation | 121 | |
| Fail-Safe | 106 | REAR WHEEL SENSOR | 122 | |
| DTC No. Index | 107 | REAR WHEEL SENSOR : Exploded View | 122 | |
| SYMPTOM DIAGNOSIS | 109 | REAR WHEEL SENSOR : Removal and Installa- | | |
| EXCESSIVE ABS FUNCTION OPERATION | | tion | 122 | |
| FREQUENCY | 109 | SENSOR ROTOR | 124 | |
| Diagnosis Procedure | 109 | FRONT SENSOR ROTOR | 124 | |
| UNEXPECTED PEDAL REACTION | 110 | | | |

| | | | |
|--|------------|---|------------|
| FRONT SENSOR ROTOR : Exploded View | 124 | Removal and Installation | 125 |
| FRONT SENSOR ROTOR : Removal and Installation | 124 | YAW RATE/SIDE/DECEL G SENSOR | 127 |
| REAR SENSOR ROTOR | 124 | Exploded View | 127 |
| REAR SENSOR ROTOR : Exploded View | 124 | Removal and Installation | 127 |
| REAR SENSOR ROTOR : Removal and Installation | 124 | STEERING ANGLE SENSOR | 128 |
| ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) | 125 | Exploded View | 128 |
| Exploded View | 125 | Removal and Installation | 128 |
| | | VDC OFF SWITCH | 129 |
| | | Removal and Installation | 129 |

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000007544616

PRECAUTIONS FOR DIAGNOSIS

Adjustment of Steering Angle Sensor

If steering angle sensor, steering system parts, suspension system parts, ABS actuator and electric unit (control unit) or tires have been replaced, or if wheel alignment has been adjusted, be sure to adjust neutral position of steering angle sensor before driving. Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

Calibration of Decel G Sensor

If yaw rate/side/decel G sensor or ABS actuator and electric unit (control unit) have been replaced, be sure to calibrate decel G sensor before driving. Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P


BRC

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[VDC/TCS/ABS]

OVERALL SEQUENCE



JPFIC0059GB

DETAILED FLOW

1. COLLECT THE INFORMATION FROM THE CUSTOMER

Get the detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred) using the diagnosis worksheet. Refer to [BRC-8, "Diagnostic Work Sheet"](#).

>> GO TO 2.

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[VDC/TCS/ABS]

2. PERFORM SELF-DIAGNOSIS

Perform self-diagnosis with CONSULT.

Is there any DTC displayed?

- YES >> Record or print self-diagnosis results and freeze frame data (FFD). GO TO 3.
NO >> GO TO 4.

3. PERFORM THE SYSTEM DIAGNOSIS

Perform the diagnosis applicable to the displayed DTC of "ABS" with CONSULT. Refer to [BRC-107, "DTC No. Index"](#).

>> GO TO 7.

4. CHECK THE SYMPTOM THAT IS NOT CONSIDERED A SYSTEM MALFUNCTION

Check that the symptom is a normal operation that is not considered a system malfunction. Refer to [BRC-115, "Description"](#).

Is the symptom a normal operation?

- YES >> GO TO 8.
NO >> GO TO 5.

5. CHECK THE WARNING LAMP AND INDICATOR LAMP FOR ILLUMINATION

Check that the warning lamp and indicator lamp illuminate.

- ABS warning lamp: Refer to [BRC-96, "Description"](#).
- Brake warning lamp: Refer to [BRC-97, "Description"](#).
- VDC warning lamp: Refer to [BRC-99, "Description"](#).
- VDC OFF indicator lamp: Refer to [BRC-100, "Description"](#).

Is ON/OFF timing normal?

- YES >> GO TO 6.
NO >> GO TO 2.

6. PERFORM SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT.

>> GO TO 7.

7. REPAIR OR REPLACE THE MALFUNCTIONING PARTS

Repair or replace the specified malfunctioning parts.

>> GO TO 8.

8. MEMORY CLEAR

Perform self-diagnosis memory clear for "ABS" with CONSULT.

>> GO TO 9.

9. FINAL CHECK

Perform the self-diagnosis again, and check that the malfunction is repaired completely.

Is no other DTC present and the repair completed?

- YES >> INSPECTION END
NO >> GO TO 3.

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[VDC/TCS/ABS]

Diagnostic Work Sheet

INFOID:000000007544617

| | | | |
|---------------------------|---|---|--|
| Customer name MR/MS | Model & Year | VIN | |
| Engine # | Trans. | Mileage | |
| Incident Date | Manuf. Date | In Service Date | |
| Symptoms | <input type="checkbox"/> Noise and vibration (from engine compartment) <input type="checkbox"/> Noise and vibration (from axle) | <input type="checkbox"/> Warning / Indicator activate | <input type="checkbox"/> Firm pedal operation <input type="checkbox"/> Large stroke pedal operation |
| | <input type="checkbox"/> TCS does not work (Rear wheels slip when accelerating) | <input type="checkbox"/> ABS does not work (Wheels lock when braking) | <input type="checkbox"/> Lack of sense of acceleration |
| Engine conditions | <input type="checkbox"/> When starting <input type="checkbox"/> After starting | | |
| Road conditions | <input type="checkbox"/> Low friction road (<input type="checkbox"/> Snow <input type="checkbox"/> Gravel <input type="checkbox"/> Other) <input type="checkbox"/> Bumps / potholes | | |
| Driving conditions | <input type="checkbox"/> Full-acceleration <input type="checkbox"/> High speed cornering <input type="checkbox"/> Vehicle speed: Greater than 10 km/h (6 MPH) <input type="checkbox"/> Vehicle speed: 10 km/h (6 MPH) or less <input type="checkbox"/> Vehicle is stopped | | |
| Applying brake conditions | <input type="checkbox"/> Suddenly <input type="checkbox"/> Gradually | | |
| Other conditions | <input type="checkbox"/> Operation of electrical equipment <input type="checkbox"/> Shift change <input type="checkbox"/> Other descriptions | | |

SFIA3265E

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[VDC/TCS/ABS]

INSPECTION AND ADJUSTMENT

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description

INFOID:000000007544618

Perform the steering angle sensor adjustment and decel G sensor calibration after replacing the ABS actuator and electric unit (control unit).

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement

INFOID:000000007544619

1. PERFORM ADJUSTMENT OF STEERING ANGLE SENSOR AND CALIBRATION OF DECEL G SENSOR

Perform steering angle sensor adjustment and decel G sensor calibration.

- Adjustment of steering angle sensor: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> INSPECTION END

ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description

INFOID:000000007544620

When doing work that applies to the list below, make sure to adjust neutral position of steering angle sensor before running vehicle.

x: Required –: Not required

| Situation | Adjustment of steering angle sensor neutral position |
|---|--|
| Removing/Installing ABS actuator and electric unit (control unit) | — |
| Replacing ABS actuator and electric unit (control unit) | x |
| Removing/Installing steering angle sensor | x |
| Replacing steering angle sensor | x |
| Removing/Installing steering components | x |
| Replacing steering components | x |
| Removing/Installing suspension components | x |
| Replacing suspension components | x |
| Change tires to new ones | — |
| Tire rotation | — |
| Adjusting wheel alignment | x |

ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement

INFOID:000000007544621

ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

CAUTION:

**To adjust neutral position of steering angle sensor, make sure to use CONSULT.
(Adjustment cannot be done without CONSULT.)**

1. ALIGN THE VEHICLE STATUS

Stop the vehicle with front wheels in straight-ahead position.

>> GO TO 2.

2. PERFORM THE NEUTRAL POSITION ADJUSTMENT FOR THE STEERING ANGLE SENSOR

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

INSPECTION AND ADJUSTMENT

[VDC/TCS/ABS]

< BASIC INSPECTION >

1. Select "ABS", "WORK SUPPORT" and "ST ANGLE SENSOR ADJUSTMENT" in order with CONSULT.
2. Select "START".

CAUTION:

Never touch steering wheel while adjusting steering angle sensor.

3. After approximately 10 seconds, select "END".

NOTE:

After approximately 60 seconds, it ends automatically.

4. Turn the ignition switch OFF, then turn it ON again.

CAUTION:

Be sure to perform above operation.

>> GO TO 3.

3. CHECK DATA MONITOR

1. Run the vehicle with front wheels in straight-ahead position, then stop.
2. Select "ABS", "DATA MONITOR" and "STR ANGLE SIG" in order with CONSULT, and check the steering angle sensor signal.

STR ANGLE SIG : 0±3.5°

Is the steering angle within the specified range?

YES >> GO TO 4.

NO >> Perform the neutral position adjustment for the steering angle sensor again, GO TO 1.

4. ERASE THE SELF-DIAGNOSIS MEMORY

Erase the self-diagnosis memories for "ABS" with CONSULT. Refer to [BRC-28. "CONSULT Function"](#).

Are the memories erased?

YES >> INSPECTION END

NO >> Check the items indicated by the self-diagnosis.

CALIBRATION OF DECEL G SENSOR

CALIBRATION OF DECEL G SENSOR : Description

INFOID:000000007544622

When doing work that applies to the list below, make sure to calibration of decel G sensor before running vehicle.

×: Required –: Not required

| Situation | Calibration of decel G sensor |
|---|-------------------------------|
| Removing/Installing ABS actuator and electric unit (control unit) | × |
| Replacing ABS actuator and electric unit (control unit) | × |
| Removing/Installing steering components | — |
| Removing/Installing suspension components | — |
| Change tires to new ones | — |
| Tire rotation | — |
| Adjusting wheel alignment | — |
| Removing/Installing yaw rate/side/decel G sensor | × |
| Replacing yaw rate/side/decel G sensor | × |

CALIBRATION OF DECEL G SENSOR : Special Repair Requirement

INFOID:000000007544623

CALIBRATION OF DECEL G SENSOR

CAUTION:

- To calibrate decel G sensor, make sure to use CONSULT.
(Calibration cannot be done without CONSULT.)
- Perform the G sensor calibration only with the vehicle parked on level surface.

1. ALIGN THE VEHICLE STATUS

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[VDC/TCS/ABS]

Stop the vehicle with front wheels in straight-ahead position.

CAUTION:

- Keep all tires inflated to correct pressures. Adjust the tire pressure to the specified pressure value.
- Check that there is specified-load in vehicle other than the driver (or equivalent weight placed in driver's position).

>> GO TO 2.

2.PERFORM THE CALIBRATION OF DECEL G SENSOR

1. Select "ABS", "WORK SUPPORT" and "DECEL G SEN CALIBRATION" in order with CONSULT.
2. Select "START".
3. After approximately 10 seconds, select "END".

NOTE:

After approximately 60 seconds, it ends automatically.

4. Turn the ignition switch OFF, then turn it ON again.

CAUTION:

Be sure to perform above operation.

>> GO TO 3.

3.CHECK DATA MONITOR

1. Run the vehicle with front wheels in straight-ahead position, then stop.
2. Select "ABS", "DATA MONITOR" and "DECEL G-SEN" in order with CONSULT, and check the decel G sensor signal.

DECEL G-SEN : ±0.08 G

Is the yaw rate/side/decel G sensor within the specified range?

YES >> GO TO 4.

NO >> Perform the calibration of decel G sensor again, GO TO 1.

4.ERASE THE SELF-DIAGNOSIS MEMORY

Erase the self-diagnosis memories for "ABS" with CONSULT. Refer to [BRC-28. "CONSULT Function"](#).

Are the memories erased?

YES >> INSPECTION END

NO >> Check the items indicated by the self-diagnosis.


A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

SYSTEM DESCRIPTION

VDC

System Diagram

INFOID:000000007544624



System Description


INFOID:000000007544625

- In addition to the TCS/ABS function, the driver steering amount and brake operation amount are detected by the steering angle sensor and pressure sensor, and the vehicle's driving status (amount of under steering/over steering) is determined by the information from the yaw rate/side/decel G sensor, wheel sensor, etc., and this information is used to improve vehicle stability by controlling the braking and engine power to all four wheels.
- During VDC operation, it informs driver of system operation by blinking the VDC warning lamp.
- Electrical system diagnosis by CONSULT is available.

Component Parts Location

INFOID:000000007544626

FOR USA



- | | | |
|---------------------------|---------------------------------|--|
| 1. Steering angle sensor | 2. ABS warning lamp | 3. Brake warning lamp |
| 4. VDC OFF indicator lamp | 5. VDC warning lamp | 6. ABS actuator and electric unit (control unit) |
| 7. Front wheel sensor | 8. Yaw rate/side/decel G sensor | 9. VDC OFF switch |
| 10. Rear wheel sensor | | |


JSFIA0529ZZ

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

< SYSTEM DESCRIPTION >

- A. Back of spiral cable assembly
- B. Combination meter
- C. Engine room (right side)
- D. Steering knuckle
- E. Under center console
- F. Instrument driver lower panel
- G. Rear axle

EXCEPT FOR USA



JSFIA0530ZZ

VDC

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

- | | | | |
|----------------------------------|---------------------------------|--|---|
| 1. Steering angle sensor | 2. ABS warning lamp | 3. Brake warning lamp | A |
| 4. VDC OFF indicator lamp | 5. VDC warning lamp | 6. ABS actuator and electric unit (control unit) | |
| 7. Front wheel sensor | 8. Yaw rate/side/decel G sensor | 9. VDC OFF switch | B |
| 10. Rear wheel sensor | | | |
| A. Back of spiral cable assembly | B. Combination meter | C. Engine room (right side) | C |
| D. Steering knuckle | E. Under center console | F. Instrument driver lower panel | |
| G. Rear axle | | | |

Component Description

INFOID:000000007544627


| Component parts | | Reference |
|---|--|---------------------------------------|
| ABS actuator and electric unit (control unit) | Pump | BRC-45, "Description" |
| | Motor | |
| | Actuator relay (Main relay) | BRC-64, "Description" |
| | ABS IN valve | BRC-58, "Description" |
| | ABS OUT valve | BRC-60, "Description" |
| | Cut valve 1 (CV1), cut valve 2 (CV2) | BRC-81, "Description" |
| | Suction valve 1 (SV1), suction valve 2 (SV2) | BRC-83, "Description" |
| Wheel sensor | BRC-33, "Description" | |
| Yaw rate/side/decel G sensor | BRC-47, "Description" | |
| Steering angle sensor | BRC-68, "Description" | |
| VDC OFF switch | BRC-94, "Description" | |
| ABS warning lamp | BRC-96, "Description" | |
| Brake warning lamp | BRC-97, "Description" | |
| VDC warning lamp | BRC-99, "Description" | |
| VDC OFF indicator lamp | BRC-100, "Description" | |

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

TCS

System Diagram

INFOID:000000007544628



System Description


INFOID:000000007544629

- The wheel spin of the drive wheels is detected by the ABS actuator and electric unit (control unit) using the wheel speed signals from the four wheels, so if wheel spin occurs, the drive wheel right and left brake fluid pressure control and engine fuel cut are conducted while the throttle valve opening is restricted to reduce the engine torque and decrease the amount of wheel spin. In addition, the throttle opening is controlled to achieve the optimum engine torque.
- During TCS operation, TCS informs driver of system operation by blinking the VDC warning lamp.
- Electrical system diagnosis by CONSULT is available.

Component Parts Location

INFOID:000000007544630

FOR USA



- | | | |
|---------------------------|---------------------------------|--|
| 1. Steering angle sensor | 2. ABS warning lamp | 3. Brake warning lamp |
| 4. VDC OFF indicator lamp | 5. VDC warning lamp | 6. ABS actuator and electric unit (control unit) |
| 7. Front wheel sensor | 8. Yaw rate/side/decel G sensor | 9. VDC OFF switch |
| 10. Rear wheel sensor | | |

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P


TCS

[VDC/TCS/ABS]

< SYSTEM DESCRIPTION >

- A. Back of spiral cable assembly
- B. Combination meter
- C. Engine room (right side)
- D. Steering knuckle
- E. Under center console
- F. Instrument driver lower panel
- G. Rear axle

EXCEPT FOR USA



< SYSTEM DESCRIPTION >

- | | | | |
|----------------------------------|---------------------------------|--|---|
| 1. Steering angle sensor | 2. ABS warning lamp | 3. Brake warning lamp | A |
| 4. VDC OFF indicator lamp | 5. VDC warning lamp | 6. ABS actuator and electric unit (control unit) | |
| 7. Front wheel sensor | 8. Yaw rate/side/decel G sensor | 9. VDC OFF switch | B |
| 10. Rear wheel sensor | | | |
| A. Back of spiral cable assembly | B. Combination meter | C. Engine room (right side) | C |
| D. Steering knuckle | E. Under center console | F. Instrument driver lower panel | |
| G. Rear axle | | | |

Component Description

INFOID:000000007544631


| Component parts | | Reference |
|---|--|---------------------------------------|
| ABS actuator and electric unit (control unit) | Pump | BRC-45, "Description" |
| | Motor | |
| | Actuator relay (Main relay) | BRC-64, "Description" |
| | ABS IN valve | BRC-58, "Description" |
| | ABS OUT valve | BRC-60, "Description" |
| | Cut valve 1 (CV1), cut valve 2 (CV2) | BRC-81, "Description" |
| | Suction valve 1 (SV1), suction valve 2 (SV2) | BRC-83, "Description" |
| Wheel sensor | BRC-33, "Description" | |
| Yaw rate/side/decel G sensor | BRC-47, "Description" | |
| Steering angle sensor | BRC-68, "Description" | |
| VDC OFF switch | BRC-94, "Description" | |
| ABS warning lamp | BRC-96, "Description" | |
| Brake warning lamp | BRC-97, "Description" | |
| VDC warning lamp | BRC-99, "Description" | |
| VDC OFF indicator lamp | BRC-100, "Description" | |

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

ABS

System Diagram

INFOID:000000007544632



System Description

INFOID:000000007544633

- The Anti-Lock Braking System detects wheel revolution while braking, and it improves handling stability during sudden braking by electrically preventing 4 wheel lock. Maneuverability is also improved for avoiding obstacles.
- Electrical system diagnosis by CONSULT is available.

Component Parts Location


INFOID:000000007544634

FOR USA

ABS

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]



- | | | |
|---------------------------|---------------------------------|--|
| 1. Steering angle sensor | 2. ABS warning lamp | 3. Brake warning lamp |
| 4. VDC OFF indicator lamp | 5. VDC warning lamp | 6. ABS actuator and electric unit (control unit) |
| 7. Front wheel sensor | 8. Yaw rate/side/decel G sensor | 9. VDC OFF switch |
| 10. Rear wheel sensor | | |

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P


ABS

[VDC/TCS/ABS]

< SYSTEM DESCRIPTION >

- A. Back of spiral cable assembly
- B. Combination meter
- C. Engine room (right side)
- D. Steering knuckle
- E. Under center console
- F. Instrument driver lower panel
- G. Rear axle

EXCEPT FOR USA



ABS

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

- | | | | |
|----------------------------------|---------------------------------|--|---|
| 1. Steering angle sensor | 2. ABS warning lamp | 3. Brake warning lamp | A |
| 4. VDC OFF indicator lamp | 5. VDC warning lamp | 6. ABS actuator and electric unit (control unit) | |
| 7. Front wheel sensor | 8. Yaw rate/side/decel G sensor | 9. VDC OFF switch | B |
| 10. Rear wheel sensor | | | |
| A. Back of spiral cable assembly | B. Combination meter | C. Engine room (right side) | C |
| D. Steering knuckle | E. Under center console | F. Instrument driver lower panel | |
| G. Rear axle | | | |

Component Description

INFOID:000000007544635


| Component parts | Reference | |
|---|--|---------------------------------------|
| ABS actuator and electric unit (control unit) | Pump | BRC-45, "Description" |
| | Motor | |
| | Actuator relay (Main relay) | BRC-64, "Description" |
| | ABS IN valve | BRC-58, "Description" |
| | ABS OUT valve | BRC-60, "Description" |
| | Cut valve 1 (CV1), cut valve 2 (CV2) | BRC-81, "Description" |
| | Suction valve 1 (SV1), suction valve 2 (SV2) | BRC-83, "Description" |
| Wheel sensor | BRC-33, "Description" | |
| Yaw rate/side/decel G sensor | BRC-47, "Description" | |
| Steering angle sensor | BRC-68, "Description" | |
| VDC OFF switch | BRC-94, "Description" | |
| ABS warning lamp | BRC-96, "Description" | |
| Brake warning lamp | BRC-97, "Description" | |
| VDC warning lamp | BRC-99, "Description" | |
| VDC OFF indicator lamp | BRC-100, "Description" | |

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

EBD

System Diagram

INFOID:000000007544636



System Description


INFOID:000000007544637

- Electronic Brake force Distribution detects subtle slippages between front and rear wheels during braking, and it improves handling stability by electronically controlling brake fluid pressure which results in reduced rear wheel slippage.
- Electrical system diagnosis by CONSULT is available.

Component Parts Location

INFOID:000000007544638

FOR USA



- | | | |
|---------------------------|---------------------------------|--|
| 1. Steering angle sensor | 2. ABS warning lamp | 3. Brake warning lamp |
| 4. VDC OFF indicator lamp | 5. VDC warning lamp | 6. ABS actuator and electric unit (control unit) |
| 7. Front wheel sensor | 8. Yaw rate/side/decel G sensor | 9. VDC OFF switch |
| 10. Rear wheel sensor | | |

JSFIA0529ZZ

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P


EBD

[VDC/TCS/ABS]

< SYSTEM DESCRIPTION >

- A. Back of spiral cable assembly
- B. Combination meter
- C. Engine room (right side)
- D. Steering knuckle
- E. Under center console
- F. Instrument driver lower panel
- G. Rear axle

EXCEPT FOR USA



JSFIA0530ZZ

< SYSTEM DESCRIPTION >

- | | | | |
|----------------------------------|---------------------------------|--|---|
| 1. Steering angle sensor | 2. ABS warning lamp | 3. Brake warning lamp | A |
| 4. VDC OFF indicator lamp | 5. VDC warning lamp | 6. ABS actuator and electric unit (control unit) | |
| 7. Front wheel sensor | 8. Yaw rate/side/decel G sensor | 9. VDC OFF switch | B |
| 10. Rear wheel sensor | | | |
| A. Back of spiral cable assembly | B. Combination meter | C. Engine room (right side) | C |
| D. Steering knuckle | E. Under center console | F. Instrument driver lower panel | |
| G. Rear axle | | | |

Component Description

INFOID:000000007544639

| Component parts | | Reference |
|---|--|---------------------------------------|
| ABS actuator and electric unit (control unit) | Pump | BRC-45, "Description" |
| | Motor | |
| | Actuator relay (Main relay) | BRC-64, "Description" |
| | ABS IN valve | BRC-58, "Description" |
| | ABS OUT valve | BRC-60, "Description" |
| | Cut valve 1 (CV1), cut valve 2 (CV2) | BRC-81, "Description" |
| | Suction valve 1 (SV1), suction valve 2 (SV2) | BRC-83, "Description" |
| Wheel sensor | BRC-33, "Description" | |
| Yaw rate/side/decel G sensor | BRC-47, "Description" | |
| Steering angle sensor | BRC-68, "Description" | |
| VDC OFF switch | BRC-94, "Description" | |
| ABS warning lamp | BRC-96, "Description" | |
| Brake warning lamp | BRC-97, "Description" | |
| VDC warning lamp | BRC-99, "Description" | |
| VDC OFF indicator lamp | BRC-100, "Description" | |

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

CONSULT Function

INFOID:000000007544640

FUNCTION

CONSULT can display each diagnostic item using the diagnostic test modes as following.

| Diagnostic test mode | Function |
|------------------------|--|
| Work support | This mode enables a technician to adjust some devices faster and more accurately by following the indications on CONSULT. |
| Self diagnostic result | Self-diagnostic results can be read and erased quickly. |
| Data monitor | Input/Output data in the ABS actuator and electric unit (control unit) can be read. |
| Active test | CONSULT drives some actuators apart from the ABS actuator and electric unit (control unit) and also shifts some parameters in a specified range. |
| ECU identification | ABS actuator and electric unit (control unit) part number can be read. |

WORK SUPPORT

| Item | Description |
|---|--|
| ST ANGLE SENSOR ADJUSTMENT | Adjusts the neutral position of the steering angle sensor. |
| DECEL G SEN CALIBRATION (only AWD models) | Calibrates decel G sensor. |

SELF DIAGNOSTIC RESULT

Operation Procedure

Before performing the self-diagnosis for "ABS" with CONSULT, start the engine and drive the vehicle at 30 km/h (19 MPH) or more for approximately 1 minute.

Display Item List

Refer to [BRC-107, "DTC No. Index"](#).

How to Erase Self-diagnosis Results

After erasing DTC memory for "ABS" with CONSULT, start the engine and drive the vehicle at 30 km/h (19 MPH) or more for approximately 1 minute as the final inspection, and make sure that the ABS warning lamp, VDC warning lamp and brake warning lamp turn OFF.

CAUTION:

If memory cannot be erased, perform applicable diagnosis.

NOTE:

- When the wheel sensor malfunctions, after inspecting the wheel sensor system, the ABS warning lamp, VDC warning lamp and brake warning lamp will not turn OFF even when the system is normal unless the vehicle is driving at approximately 30 km/h (19 MPH) or more for approximately 1 minute.
- Brake warning lamp will turn ON in case of parking brake operation (when switch is ON) or of brake fluid level switch operation (when brake fluid is insufficient).
- VDC OFF switch should not stay "ON" position.

DATA MONITOR

Display Item List

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

×: Applicable ▼: Optional item

| Monitor item (Unit) | SELECT MONITOR ITEM | | Remarks | |
|-----------------------------------|---------------------|--------------|--|------------|
| | ECU INPUT SIGNALS | MAIN SIGNALS | | |
| FR LH SENSOR [km/h (MPH)] | × | × | Wheel speed | A |
| FR RH SENSOR [km/h (MPH)] | × | × | | B |
| RR LH SENSOR [km/h (MPH)] | × | × | | C |
| RR RH SENSOR [km/h (MPH)] | × | × | | D |
| STOP LAMP SW (On/Off) | × | × | Stop lamp switch signal status | E |
| BATTERY VOLT (V) | × | × | Battery voltage supplied to the ABS actuator and electric unit (control unit) | |
| GEAR | × | × | Gear position determined by TCM | BRC |
| R POSI SIG (On/Off) | ▼ | ▼ | Shift position judged by shift position (R) signal | |
| N POSI SIG (On/Off) | ▼ | ▼ | Shift position judged by shift position (N) signal | G |
| P POSI SIG (On/Off) | ▼ | ▼ | Shift position judged by shift position (P) signal | H |
| SLCT LVR POSI | × | × | Shift position judged by shift position signal | |
| OFF SW (On/Off) | × | × | VDC OFF switch | I |
| YAW RATE SEN (d/s) | × | × | Yaw rate detected by yaw rate/side/decel G sensor | |
| DECEL G-SEN (G) | × | × | Decel G detected by yaw rate/side/decel G sensor | J |
| ACCEL POS SIG (%) | × | ▼ | Throttle actuator opening/closing is displayed (Linked with accelerator pedal) | K |
| SIDE G-SENSOR (m/s ²) | × | ▼ | Transverse G detected by yaw rate/side/decel G sensor | |
| STR ANGLE SIG (°) | × | ▼ | Steering angle detected by steering angle sensor | L |
| ENGINE RPM [tr/min (rpm)] | × | ▼ | Engine speed | M |
| FLUID LEV SW (On/Off) | × | ▼ | Brake fluid level switch | |
| PRESS SENSOR (bar) | × | ▼ | Brake fluid pressure detected by pressure sensor | N |
| FR RH IN SOL (On/Off) | ▼ | × | Operation status of front RH ABS IN valve | O |
| FR RH OUT SOL (On/Off) | ▼ | × | Operation status of front RH ABS OUT valve | |
| FR LH IN SOL (On/Off) | ▼ | × | Operation status of front LH ABS IN valve | P |
| FR LH OUT SOL (On/Off) | ▼ | × | Operation status of front LH ABS OUT valve | |
| RR RH IN SOL (On/Off) | ▼ | × | Operation status of rear RH ABS IN valve | |
| RR RH OUT SOL (On/Off) | ▼ | × | Operation status of rear RH ABS OUT valve | |

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

| Monitor item (Unit) | SELECT MONITOR ITEM | | Remarks |
|---------------------------|---------------------|--------------|---|
| | ECU INPUT SIGNALS | MAIN SIGNALS | |
| RR LH IN SOL (On/Off) | ▼ | × | Operation status of rear LH ABS IN valve |
| RR LH OUT SOL (On/Off) | ▼ | × | Operation status of rear LH ABS OUT valve |
| MOTOR RELAY (On/Off) | ▼ | × | Motor and motor relay operation |
| ACTUATOR RLY (On/Off) | ▼ | × | Actuator relay operation |
| ABS WARN LAMP (On/Off) | ▼ | × | ABS warning lamp |
| OFF LAMP (On/Off) | ▼ | × | VDC OFF indicator lamp |
| SLIP/VDC LAMP (On/Off) | ▼ | × | VDC warning lamp |
| CV1 (On/Off) | ▼ | ▼ | Cut valve 1 (CV1) monitor |
| CV2 (On/Off) | ▼ | ▼ | Cut valve 2 (CV2) monitor |
| SV1 (On/Off) | ▼ | ▼ | Suction valve 1 (SV1) monitor |
| SV2 (On/Off) | ▼ | ▼ | Suction valve 2 (SV2) monitor |
| EBD SIGNAL (On/Off) | ▼ | ▼ | EBD operation |
| ABS SIGNAL (On/Off) | ▼ | ▼ | ABS operation |
| TCS SIGNAL (On/Off) | ▼ | ▼ | TCS operation |
| VDC SIGNAL (On/Off) | ▼ | ▼ | VDC operation |
| EBD FAIL SIG (On/Off) | ▼ | ▼ | EBD fail-safe status |
| ABS FAIL SIG (On/Off) | ▼ | ▼ | ABS fail-safe status |
| TCS FAIL SIG (On/Off) | ▼ | ▼ | TCS fail-safe status |
| VDC FAIL SIG (On/Off) | ▼ | ▼ | VDC fail-safe status |
| EBD WARN LAMP (On/Off) | ▼ | ▼ | Brake warning lamp |
| CRANKING SIG (On/Off) | ▼ | ▼ | Crank operation |
| 4WD FAIL REQ (On/Off) | ▼ | ▼ | AWD fail-safe signal status |
| 2WD/4WD (2WD/4WD) | ▼ | ▼ | Distinguish 2WD and AWD |

NOTE:

A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is a operation for checking.

ACTIVE TEST MODE

CAUTION:

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

- **Never perform active test while driving vehicle.**
- **Make sure to completely bleed air from brake system.**
- **The active test cannot be started when ABS warning lamp, VDC warning lamp and brake warning lamp is ON.**
- **ABS warning lamp, VDC warning lamp and brake warning lamp are ON during active test.**

NOTE:

- When active test is performed while depressing the pedal, the pedal depression amount will change. This is normal.
- "TEST IS STOPPED" in "ABS" with CONSULT is displayed 10 seconds after operation start.
- After "TEST IS STOPPED" in "ABS" with CONSULT is displayed, to perform test again.

Test Item

ABS IN Valve and ABS OUT valve

- Select "Up", "Keep" and "Down" of "ACTIVE TEST" in "ABS" with CONSULT. Then use screen monitor to check that each valve operates as shown in the table below.

| Test item | Display item | Display | | |
|-----------|---------------|---------|------|------|
| | | Up | Keep | Down |
| FR RH SOL | FR RH IN SOL | Off | On | On |
| | FR RH OUT SOL | Off | Off | On* |
| FR LH SOL | FR LH IN SOL | Off | On | On |
| | FR LH OUT SOL | Off | Off | On* |
| RR RH SOL | RR RH IN SOL | Off | On | On |
| | RR RH OUT SOL | Off | Off | On* |
| RR LH SOL | RR LH IN SOL | Off | On | On |
| | RR LH OUT SOL | Off | Off | On* |

BRC

G
H
I

J

K

L

M

N

O

P

Q

R

S

*: On for 1 to 2 seconds after the select, and then Off.

NOTE:

A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is a operation for checking.

ABS IN Valve (ACT) and ABS OUT valve (ACT)

- Select "Up", "ACT UP" and "ACT KEEP" of "ACTIVE TEST" in "ABS" with CONSULT. Then use screen monitor to check that each valve operates as shown in the table below.

| Test item | Display item | Display | | |
|--------------------------|---------------|---------|--------|----------|
| | | Up | ACT UP | ACT KEEP |
| FR RH ABS SOLENOID (ACT) | FR RH IN SOL | Off | Off | Off |
| | FR RH OUT SOL | Off | Off | Off |
| | CV1 | Off | On | On |
| | SV1 | Off | On* | Off |
| FR LH ABS SOLENOID (ACT) | FR LH IN SOL | Off | Off | Off |
| | FR LH OUT SOL | Off | Off | Off |
| | CV2 | Off | On | On |
| | SV2 | Off | On* | Off |
| RR RH ABS SOLENOID (ACT) | RR RH IN SOL | Off | Off | Off |
| | RR RH OUT SOL | Off | Off | Off |
| | CV2 | Off | On | On |
| | SV2 | Off | On* | Off |

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

| Test item | Display item | Display | | |
|--------------------------|---------------|---------|--------|----------|
| | | Up | ACT UP | ACT KEEP |
| RR LH ABS SOLENOID (ACT) | RR LH IN SOL | Off | Off | Off |
| | RR LH OUT SOL | Off | Off | Off |
| | CV1 | Off | On | On |
| | SV1 | Off | On* | Off |

*: On for 1 to 2 seconds after the select, and then Off.

NOTE:

A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is a operation for checking.

ABS MOTOR

- Select "On" and "Off" of "ACTIVE TEST" in "ABS" with CONSULT. Make sure motor relay and actuator relay operates as shown in table below.

| Test item | Display item | Display | |
|-----------|--------------|---------|-----|
| | | On | Off |
| ABS MOTOR | MOTOR RELAY | On | Off |
| | ACTUATOR RLY | On | On |

NOTE:

A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is a operation for checking.

ECU IDENTIFICATION

ABS actuator and electric unit (control unit) part number can be read.

C1101, C1102, C1103, C1104 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

DTC/CIRCUIT DIAGNOSIS

C1101, C1102, C1103, C1104 WHEEL SENSOR

Description

INFOID:000000007544641

When the sensor rotor rotates, the magnetic field changes. It converts the magnetic field changes to current signals (rectangular wave) and transmits them to the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000007544642

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|----------------|---|---|
| C1101 | RR RH SENSOR-1 | Circuit of rear RH wheel sensor is open or short circuit. Current signal from sensor is outside limits. | <ul style="list-style-type: none">• Harness or connector• Wheel sensor• ABS actuator and electric unit (control unit) |
| C1102 | RR LH SENSOR-1 | Circuit of rear LH wheel sensor is open or short circuit. Current signal from sensor is outside limits. | |
| C1103 | FR RH SENSOR-1 | Circuit of front RH wheel sensor is open or short circuit. Current signal from sensor is outside limits. | |
| C1104 | FR LH SENSOR-1 | Circuit of front LH wheel sensor is open or short circuit. Current signal from sensor is outside limits. | |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Start the engine and drive the vehicle at 30 km/h (19 MPH) or more for approximately 1 minute.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1101", "C1102", "C1103" or "C1104" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-33, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000007544643

CAUTION:

Never check the between wheel sensor harness connector terminals.

1. CHECK WHEEL SENSOR

1. Turn the ignition switch OFF.
2. Check the wheel sensor for damage.

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2. REPLACE WHEEL SENSOR (1)

1. Replace wheel sensor.
 - Front: Refer to [BRC-121, "FRONT WHEEL SENSOR : Exploded View"](#).
 - Rear: Refer to [BRC-122, "REAR WHEEL SENSOR : Exploded View"](#).
2. Erase self-diagnosis result for "ABS".
3. Turn the ignition switch OFF, and wait 10 seconds or more.
4. Start the engine.
5. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
6. Stop the vehicle.

C1101, C1102, C1103, C1104 WHEEL SENSOR

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

7. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1101", "C1102", "C1103" or "C1104" detected?

YES >> GO TO 3.

NO >> INSPECTION END

3.CHECK CONNECTOR

1. Turn the ignition switch OFF.

2. Check the ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.

3. Check the wheel sensor harness connector for disconnection or looseness.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace error-detected parts, securely lock the harness connector, and GO TO 4.

4.PERFORM SELF-DIAGNOSIS (1)

1. Erase self-diagnosis result for "ABS" with CONSULT.

2. Turn the ignition switch OFF, and wait 10 seconds or more.

3. Start the engine.

4. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.

5. Stop the vehicle.

6. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1101", "C1102", "C1103" or "C1104" detected?

YES >> GO TO 5.

NO >> INSPECTION END

5.CHECK TERMINAL

1. Turn the ignition switch OFF.

2. Disconnect ABS actuator and electric unit (control unit) harness connector and then check the ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.

3. Disconnect wheel sensor harness connector and check the each wheel sensor pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace error-detected parts and GO TO 6.

6.PERFORM SELF-DIAGNOSIS (2)

1. Connect ABS actuator and electric unit (control unit) harness connector.

2. Connect wheel sensor harness connector.

3. Erase self-diagnosis result for "ABS".

4. Turn the ignition switch OFF, and wait 10 seconds or more.

5. Start the engine.

6. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.

7. Stop the vehicle.

8. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1101", "C1102", "C1103" or "C1104" detected?

YES >> GO TO 7.

NO >> INSPECTION END

7.CHECK WHEEL SENSOR HARNESS

1. Turn the ignition switch OFF.

2. Disconnect ABS actuator and electric unit (control unit) harness connector.

3. Disconnect wheel sensor harness connector.

4. Check the continuity between ABS actuator and electric unit (control unit) harness connector and wheel sensor harness connector. (Check the continuity when steering wheel is steered to RH and LH, or center harness in wheel housing is moved.)

C1101, C1102, C1103, C1104 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

Measurement connector and terminal for power supply circuit

| ABS actuator and electric unit (control unit) | | Wheel sensor | | Continuity |
|---|----------|--|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E36 | 9 | E22 (Front LH wheel) | 1 | Existed |
| | 5 | E39 (Front RH wheel) | 3 | |
| | 3 | C3 ^{*1} (Rear LH wheel) C5 ^{*2} (Rear LH wheel) | 5 | |
| | 11 | C4 ^{*1} (Rear RH wheel) C6 ^{*2} (Rear RH wheel) | 7 | |

*1: 2WD

*2: AWD

Measurement connector and terminal for signal circuit

| ABS actuator and electric unit (control unit) | | Wheel sensor | | Continuity |
|---|----------|--|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E36 | 8 | E22 (Front LH wheel) | 2 | Existed |
| | 6 | E39 (Front RH wheel) | 4 | |
| | 2 | C3 ^{*1} (Rear LH wheel) C5 ^{*2} (Rear LH wheel) | 6 | |
| | 12 | C4 ^{*1} (Rear RH wheel) C6 ^{*2} (Rear RH wheel) | 8 | |

*1: 2WD

*2: AWD

Is the inspection result normal?

YES >> GO TO 9.

NO >> Repair or replace error-detected parts and GO TO 8.

8. PERFORM SELF-DIAGNOSIS (3)

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Connect wheel sensor harness connector.
3. Erase self-diagnosis result for "ABS".
4. Turn the ignition switch OFF, and wait 10 seconds or more.
5. Start the engine.
6. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
7. Stop the vehicle.
8. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1101", "C1102", "C1103" or "C1104" detected?

YES >> GO TO 9.

NO >> INSPECTION END

9. REPLACE WHEEL SENSOR (2)

1. Replace wheel sensor.
 - Front: Refer to [BRC-121, "FRONT WHEEL SENSOR : Exploded View"](#).
 - Rear: Refer to [BRC-122, "REAR WHEEL SENSOR : Exploded View"](#).
2. Erase self-diagnosis result for "ABS" with CONSULT.
3. Turn the ignition switch OFF, and wait 10 seconds or more.
4. Start the engine.
5. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
6. Stop the vehicle.
7. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1101", "C1102", "C1103" or "C1104" detected?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-125, "Exploded View"](#).

NO >> INSPECTION END

C1101, C1102, C1103, C1104 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

Special Repair Requirement

INFOID:000000007544645

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

- After replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
- Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing/replacing a steering angle sensor, be sure to perform the following procedure.
- Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- After removing/replacing a yaw rate/side/decel G sensor, be sure to perform the following procedure.
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

C1105, C1106, C1107, C1108 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1105, C1106, C1107, C1108 WHEEL SENSOR

Description

INFOID:000000007544646

When the sensor rotor rotates, the magnetic field changes. It converts the magnetic field changes to current signals (rectangular wave) and transmits them to the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000007544647

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|----------------|--|---|
| C1105 | RR RH SENSOR-2 | Signal from rear RH wheel sensor does not match other 3 wheel speed signal. | <ul style="list-style-type: none">• Harness or connector• Wheel sensor• Sensor rotor• ABS actuator and electric unit (control unit)• Sensor rotor |
| C1106 | RR LH SENSOR-2 | Signal from rear LH wheel sensor does not match other 3 wheel speed signal. | |
| C1107 | FR RH SENSOR-2 | Signal from front RH wheel sensor does not match other 3 wheel speed signal. | |
| C1108 | FR LH SENSOR-2 | Signal from front LH wheel sensor does not match other 3 wheel speed signal. | |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Start the engine and drive the vehicle at 30 km/h (19 MPH) or more for approximately 1 minute.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1105", "C1106", "C1107" or "C1108" detected?

YES >> Proceed to diagnosis procedure. Refer to [BRC-37, "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000007544648

CAUTION:

Never check the between wheel sensor harness connector terminals.

1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY SYSTEM

Check the ABS actuator and electric unit (control unit) power supply system. Refer to [BRC-89, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace error-detected parts.

2. CHECK TIRE

1. Turn the ignition switch OFF.
2. Check the tire air pressure, wear and size. Refer to [WT-48, "Tire Air Pressure"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Adjust air pressure or replace tire and GO TO 3.

3. CHECK DATA MONITOR (1)

1. Erase self-diagnosis result for "ABS" with CONSULT.
2. Turn the ignition switch OFF, and wait 10 seconds or more.

C1105, C1106, C1107, C1108 WHEEL SENSOR

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

3. Start the engine.
4. Select "ABS" and "DATA MONITOR", check the "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR" with CONSULT.

NOTE:

Set the "DATA MONITOR" recording speed to "10 msec".

5. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

Regarding the deference at 30 km/h (19 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%, respectively?

- YES >> GO TO 4.
NO >> GO TO 5.

4.PERFORM SELF-DIAGNOSIS (1)

1. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
2. Stop the vehicle.
3. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1105", "C1106", "C1107" or "C1108" detected?

- YES >> GO TO 5.
NO >> INSPECTION END

5.CHECK WHEEL SENSOR

1. Turn the ignition switch OFF.
2. Check the wheel sensor for damage.
3. Remove dust and foreign matter adhered to the sensor rotor with a vacuum dust collector through the wheel sensor mounting hole.

CAUTION:

Install wheel sensor with no backlash and float, and tighten the mounting bolt to the specified torque.

- Front: Refer to [BRC-121, "FRONT WHEEL SENSOR : Exploded View"](#).
- Rear: Refer to [BRC-122, "REAR WHEEL SENSOR : Exploded View"](#).

Is the inspection result normal?

- YES >> GO TO 8.
NO >> GO TO 6.

6.REPLACE WHEEL SENSOR (1)

1. Replace wheel sensor.
 - Front: Refer to [BRC-121, "FRONT WHEEL SENSOR : Exploded View"](#).
 - Rear: Refer to [BRC-122, "REAR WHEEL SENSOR : Exploded View"](#).
2. Erase self-diagnosis result for "ABS" with CONSULT.
3. Turn the ignition switch OFF, and wait 10 seconds or more.
4. Start the engine.
5. Select "ABS" and "DATA MONITOR", check the "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR" with CONSULT.

NOTE:

Set the "DATA MONITOR" recording speed to "10 msec".

6. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

Regarding the deference at 30 km/h (19 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%, respectively?

- YES >> GO TO 7.
NO >> GO TO 19.

7.PERFORM SELF-DIAGNOSIS (2)

Ⓟ With CONSULT.

1. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
2. Stop the vehicle.
3. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1105", "C1106", "C1107" or "C1108" detected?

- YES >> GO TO 19.

C1105, C1106, C1107, C1108 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

NO >> INSPECTION END

8. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Check the ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.
3. Check the wheel sensor harness connector for disconnection or looseness.

Is the inspection result normal?

YES >> GO TO 11.

NO >> Repair or replace error-detected parts, securely lock the harness connector, and GO TO 9.

9. CHECK DATA MONITOR (2)

1. Erase self-diagnosis result for "ABS" with CONSULT.
2. Turn the ignition switch OFF, and wait 10 seconds or more.
3. Start the engine.
4. Select "ABS" and "DATA MONITOR", check the "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR" with CONSULT.

NOTE:

Set the "DATA MONITOR" recording speed to "10 msec".

5. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

Regarding the deference at 30 km/h (19 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%. respectively?

YES >> GO TO 10.

NO >> GO TO 11.

10. PERFORM SELF-DIAGNOSIS (3)

1. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
2. Stop the vehicle.
3. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1105", "C1106", "C1107" or "C1108" detected?

YES >> GO TO 11.

NO >> INSPECTION END

11. CHECK TERMINAL

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector and then check the ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.
3. Disconnect wheel sensor harness connector and check the each wheel sensor pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> GO TO 14.

NO >> Repair or replace error-detected parts and GO TO 12.

12. CHECK DATA MONITOR (3)

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Connect wheel sensor harness connector.
3. Erase self-diagnosis result for "ABS" with CONSULT.
4. Turn the ignition switch OFF, and wait 10 seconds or more.
5. Start the engine.
6. Select "ABS" and "DATA MONITOR", check the "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR" with CONSULT.

NOTE:

Set the "DATA MONITOR" recording speed to "10 msec".

7. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

Regarding the deference at 30 km/h (19 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%. respectively?

YES >> GO TO 13.

NO >> GO TO 14.

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P

C1105, C1106, C1107, C1108 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

13. PERFORM SELF-DIAGNOSIS (4)

1. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
2. Stop the vehicle.
3. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1105", "C1106", "C1107" or "C1108" detected?

YES >> GO TO 14.

NO >> INSPECTION END

14. CHECK WHEEL SENSOR HARNESS

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Disconnect wheel sensor harness connector.
4. Check the continuity between ABS actuator and electric unit (control unit) harness connector and the ground.

| ABS actuator and electric unit (control unit) | | — | Continuity |
|---|----------|--------|-------------|
| Connector | Terminal | | |
| E36 | 9, 8 | Ground | Not existed |
| | 5, 6 | | |
| | 3, 2 | | |
| | 11, 12 | | |

Is the inspection result normal?

YES >> GO TO 15.

NO >> Repair or replace error-detected parts and GO TO 15.

15. CHECK DATA MONITOR (4)

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Connect wheel sensor harness connector.
3. Erase self-diagnosis result for "ABS" with CONSULT.
4. Turn the ignition switch OFF, and wait 10 seconds or more.
5. Start the engine.
6. Select "ABS" and "DATA MONITOR", check the "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR" with CONSULT.

NOTE:

Set the "DATA MONITOR" recording speed to "10 msec".

7. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

Regarding the deference at 30 km/h (19 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%, respectively?

YES >> GO TO 16.

NO >> GO TO 17.

16. PERFORM SELF-DIAGNOSIS (5)

1. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
2. Stop the vehicle.
3. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1105", "C1106", "C1107" or "C1108" detected?

YES >> GO TO 17.

NO >> INSPECTION END

17. REPLACE WHEEL SENSOR (2)

1. Replace wheel sensor.
 - Front: Refer to [BRC-121. "FRONT WHEEL SENSOR : Exploded View"](#).
 - Rear: Refer to [BRC-122. "REAR WHEEL SENSOR : Exploded View"](#).
2. Erase self-diagnosis result for "ABS" with CONSULT.
3. Turn the ignition switch OFF, and wait 10 seconds or more.

C1105, C1106, C1107, C1108 WHEEL SENSOR

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

4. Start the engine.
5. Select "ABS" and "DATA MONITOR", check the "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR" with CONSULT.

NOTE:

Set the "DATA MONITOR" recording speed to "10 msec".

6. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

Regarding the deference at 30 km/h (19 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%, respectively?

YES >> GO TO 18.

NO >> GO TO 19.

18.PERFORM SELF-DIAGNOSIS (6)

1. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
2. Stop the vehicle.
3. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1105", "C1106", "C1107" or "C1108" detected?

YES >> GO TO 19.

NO >> INSPECTION END

19.REPLACE SENSOR ROTOR

1. Replace sensor rotor.
 - Front: Refer to [BRC-124, "FRONT SENSOR ROTOR : Exploded View"](#).
 - Rear: Refer to [BRC-124, "REAR SENSOR ROTOR : Exploded View"](#).
2. Erase self-diagnosis result for "ABS" with CONSULT.
3. Turn the ignition switch OFF, and wait 10 seconds or more.
4. Start the engine.
5. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
6. Stop the vehicle.
7. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1105", "C1106", "C1107" or "C1108" detected?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-125, "Exploded View"](#).

NO >> INSPECTION END

Special Repair Requirement

INFOID:000000007804877

1.ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

- After replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
 - Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
 - Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
 - Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing/replacing a steering angle sensor, be sure to perform the following procedure.
 - Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- After removing/replacing a yaw rate/side/decel G sensor, be sure to perform the following procedure.
 - Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

C1109 POWER AND GROUND SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1109 POWER AND GROUND SYSTEM

Description

INFOID:000000007544651

Supplies electric power to the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000007544652

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|-------------------------------|---|---|
| C1109 | BATTERY VOLTAGE [ABNORMAL] | When the ABS actuator and electric unit (control unit) power supply is lower than normal. | <ul style="list-style-type: none">• Harness or connector• ABS actuator and electric unit (control unit)• Fuse |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch OFF to ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1109" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-42, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000007544653

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Check the terminal for deformation, disconnection, looseness, etc.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace error-detected parts.

2. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY

1. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Voltage (Approx.) |
|---|----------|--------|----------------------|
| Connector | Terminal | | |
| E36 | 1 | Ground | Battery voltage |

2. Turn the ignition switch ON.

CAUTION:

Never start the engine.

3. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Voltage (Approx.) |
|---|----------|--------|----------------------|
| Connector | Terminal | | |
| E36 | 1 | Ground | Battery voltage |

Is the inspection result normal?

C1109 POWER AND GROUND SYSTEM

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

- YES >> GO TO 4.
- NO >> GO TO 3.

3. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY CIRCUIT

1. Turn the ignition switch OFF.
2. Check the 20A fusible link (#G).
3. Check the continuity and short circuit between ABS actuator and electric unit (control unit) harness connector terminal (1) and 20A fusible link (#G).

Is the inspection result normal?

- YES >> Perform trouble diagnosis for battery power supply. Refer to [PG-6, "Wiring Diagram - BATTERY POWER SUPPLY -"](#).
- NO >> Repair or replace error-detected parts.

4. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Check the continuity between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| E36 | 13 | Ground | Existed |
| | 26 | | |

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-125, "Exploded View"](#).
- NO >> Repair or replace error-detected parts.

Special Repair Requirement

INFOID:000000007804878

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

- After replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
 - Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
 - Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
 - Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing/replacing a steering angle sensor, be sure to perform the following procedure.
 - Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- After removing/replacing a yaw rate/side/decel G sensor, be sure to perform the following procedure.
 - Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

C1110 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1110 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Description

INFOID:000000007544656

ABS actuator and electric unit (control unit) is continuously monitoring ECU hardware and software for correct operation.

DTC Logic

INFOID:000000007544657

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|--------------------|---|---|
| C1110 | CONTROLLER FAILURE | When there is an internal malfunction in the ABS actuator and electric unit (control unit). | ABS actuator and electric unit (control unit) |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch OFF to ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1110" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-44. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000007544658

1. REPLACE ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Replace ABS actuator and electric unit (control unit) when self-diagnostic result shows items other than those applicable.

>> Replace ABS actuator and electric unit (control unit). Refer to [BRC-125. "Exploded View"](#).

Special Repair Requirement

INFOID:000000007804879

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

- After replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
- Adjustment of steering angle sensor neutral position: Refer to [BRC-9. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
- Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing/replacing a steering angle sensor, be sure to perform the following procedure.
- Adjustment of steering angle sensor neutral position: Refer to [BRC-9. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- After removing/replacing a yaw rate/side/decel G sensor, be sure to perform the following procedure.
- Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

C1111 ABS MOTOR, MOTOR RELAY SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1111 ABS MOTOR, MOTOR RELAY SYSTEM

Description

INFOID:000000007544660

PUMP

The pump returns the brake fluid stored in the reservoir to the master cylinder by reducing the pressure.

MOTOR

The motor drives the pump according to the signals transmitted by the ABS actuator and electric unit (control unit).

MOTOR RELAY

Activates or deactivates motor according to the signals transmitted by the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000007544661

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|--------------|--|---|
| C1111 | PUMP MOTOR | During the actuator motor operating with ON, when the actuator motor turns OFF, or when the control line for actuator motor relay is open. | <ul style="list-style-type: none"> • Harness or connector • ABS actuator and electric unit (control unit) |
| | | During the actuator motor operating with OFF, when the actuator motor turns ON, or when the control line for relay is shorted to ground. | |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch OFF to ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1111" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-45, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000007544662

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Check the terminal for deformation, disconnect, looseness, etc.

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair or replace error-detected parts.

2. CHECK ABS MOTOR AND MOTOR RELAY POWER SUPPLY

1. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Voltage (Approx.) |
|---|----------|--------|-------------------|
| Connector | Terminal | | |
| E36 | 14 | Ground | Battery voltage |

C1111 ABS MOTOR, MOTOR RELAY SYSTEM

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

2. Turn the ignition switch ON.

CAUTION:

Never start the engine.

3. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Voltage (Approx.) |
|---|----------|--------|-------------------|
| Connector | Terminal | | |
| E36 | 14 | Ground | Battery voltage |

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 3.

3. CHECK ABS MOTOR AND MOTOR RELAY POWER SUPPLY CIRCUIT

1. Turn the ignition switch OFF.

2. Check the 30A fusible link (#F).

3. Check the continuity and short circuit between ABS actuator and electric unit (control unit) harness connector terminal (14) and 30A fusible link (#F).

Is the inspection result normal?

YES >> Perform trouble diagnosis for battery power supply. Refer to [PG-6. "Wiring Diagram - BATTERY POWER SUPPLY -"](#).

NO >> Repair or replace error-detected parts.

4. CHECK ABS MOTOR AND MOTOR RELAY GROUND CIRCUIT

Check the continuity between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| E36 | 13 | Ground | Existed |
| | 26 | | |

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-125. "Exploded View"](#).

NO >> Repair or replace error-detected parts.

Special Repair Requirement

INFOID:000000007804880

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

- After replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
 - Adjustment of steering angle sensor neutral position: Refer to [BRC-9. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
 - Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
 - Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing/replacing a steering angle sensor, be sure to perform the following procedure.
 - Adjustment of steering angle sensor neutral position: Refer to [BRC-9. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- After removing/replacing a yaw rate/side/decel G sensor, be sure to perform the following procedure.
 - Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

C1113, C1145, C1146 YAW RATE/SIDE/DECCEL G SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1113, C1145, C1146 YAW RATE/SIDE/DECCEL G SENSOR

Description

INFOID:000000007544665

Yaw rate/side/deccl G sensor detects yaw rate/side/deccl G affecting the vehicle, and transmits the data to the ABS actuator and electric unit (control unit) as an analog voltage signal.

DTC Logic

INFOID:000000007544666

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|--------------------|---|---|
| C1113 | G SENSOR | Decel G sensor is malfunctioning. | • Harness or connector • ABS actuator and electric unit (control unit) • Yaw rate/side/deccl G sensor |
| C1145 | YAW RATE SENSOR | <ul style="list-style-type: none">• Yaw rate sensor is malfunctioning.• Yaw rate/side/deccl G sensor power voltage is outside the standard.• Yaw rate/side/deccl G sensor signal line is open or shorted. | |
| C1146 | SIDE G-SEN CIRCUIT | Side G sensor is malfunctioning. | |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch OFF to ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1113", "C1145" or "C1146" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-47, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000007544667

CAUTION:

- Sudden turns (such as spin turns, acceleration turns), drifting, etc. may cause yaw rate/side/deccl G sensor circuit indicate a malfunction. However this is not a malfunction if normal operation can be resumed after restarting engine.
- When on a turntable, such as at a parking structure entrance, or when on a moving object with engine running, the VDC warning lamp might turn ON and self-diagnosis using the CONSULT yaw rate sensor system malfunction might be displayed, but in this case there is no malfunction with yaw rate/side/deccl G sensor circuit. As soon as the vehicle leaves the turntable or moving object, restart the engine to return the system to normal.

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Disconnect yaw rate/side/deccl G sensor harness connector.
4. Check the terminal for deformation, disconnection, looseness, etc.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace error-detected parts.

2. CHECK YAW RATE/SIDE/DECCEL G SENSOR POWER SUPPLY CIRCUIT

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Turn the ignition switch ON.

C1113, C1145, C1146 YAW RATE/SIDE/DECEL G SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

CAUTION:

Never start the engine.

3. Check the voltage between yaw rate/side/decel G sensor harness connector and ground.

| Yaw rate/side/decel G sensor | | — | Voltage (Approx.) |
|------------------------------|----------|--------|-------------------|
| Connector | Terminal | | |
| M52 | 4 | Ground | Battery voltage |

4. Turn the ignition switch OFF.
5. Check the voltage between yaw rate/side/decel G sensor harness connector and ground.

| Yaw rate/side/decel G sensor | | — | Voltage (Approx.) |
|------------------------------|----------|--------|-------------------|
| Connector | Terminal | | |
| M52 | 4 | Ground | 0 V |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace error-detected parts.

3.CHECK YAW RATE/SIDE/DECEL G SENSOR GROUND CIRCUIT

Check the continuity between yaw rate/side/decel G sensor harness connector and ground.

| Yaw rate/side/decel G sensor | | — | Continuity |
|------------------------------|----------|--------|------------|
| Connector | Terminal | | |
| M52 | 1 | Ground | Existed |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace error-detected parts.

4.CHECK YAW RATE/SIDE/DECEL G SENSOR HARNESS

1. Disconnect ABS actuator and electric unit (control unit) harness connector.
2. Check the continuity between yaw rate/side/decel G sensor harness connector and ABS actuator and electric unit (control unit) harness connector.

| ABS actuator and electric unit (control unit) | | Yaw rate/side/decel G sensor | | Continuity |
|---|----------|------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E36 | 25 | M52 | 2 | Existed |
| | 19 | | 3 | |

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Repair or replace error-detected parts.

5.CHECK DATA MONITOR

1. Connect yaw rate/side/decel G sensor harness connector.
2. Connect ABS actuator and electric unit (control unit) harness connector.
3. Select "ABS" and "DATA MONITOR" in order with CONSULT, select "YAW RATE SEN", "SIDE G-SEN" and "DECEL G-SEN", and check the yaw rate/side/decel G sensor signal.

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-125. "Exploded View"](#).
NO >> Replace yaw rate/side/decel G sensor. Refer to [BRC-127. "Exploded View"](#).

Special Repair Requirement

INFOID:000000007804881

1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

C1113, C1145, C1146 YAW RATE/SIDE/DECEL G SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

- After replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
- Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing/replacing a steering angle sensor, be sure to perform the following procedure.
- Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- After removing/replacing a yaw rate/side/decel G sensor, be sure to perform the following procedure.
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

C1115 WHEEL SENSOR

Description

INFOID:000000007544670

When the sensor rotor rotates, the magnetic field changes. It converts the magnetic field changes to current signals (rectangular wave) and transmits them to the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000007544671

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|---------------------------------|---|---|
| C1115 | ABS SENSOR [ABNORMAL SIGNAL] | When wheel sensor input signal is malfunctioning. | <ul style="list-style-type: none"> Harness or connector Wheel sensor ABS actuator and electric unit (control unit) Sensor rotor |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Start the engine and drive the vehicle at 30 km/h (19 MPH) or more for approximately 1 minute.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1115" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-50, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000007544672

CAUTION:

Never check the between wheel sensor harness connector terminals.

1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY SYSTEM

Check the ABS actuator and electric unit (control unit) power supply system. Refer to [BRC-89, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair or replace error-detected parts.

2. CHECK TIRE

1. Turn the ignition switch OFF.
2. Check the tire air pressure, wear and size. Refer to [WT-48, "Tire Air Pressure"](#).

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> Adjust air pressure or replace tire and GO TO 3.

3. CHECK DATA MONITOR (1)

1. Erase self-diagnosis result for "ABS" with CONSULT.
2. Turn the ignition switch OFF, and wait 10 seconds or more.
3. Start the engine.
4. Select "ABS" and "DATA MONITOR", check the "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR" with CONSULT.

NOTE:

C1115 WHEEL SENSOR

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

Set the "DATA MONITOR" recording speed to "10 msec".

5. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

Regarding the deference at 30 km/h (19 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%, respectively?

YES >> GO TO 4.

NO >> GO TO 5.

4.PERFORM SELF-DIAGNOSIS (1)

1. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
2. Stop the vehicle.
3. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1115" detected?

YES >> GO TO 5.

NO >> INSPECTION END

5.CHECK WHEEL SENSOR

1. Turn the ignition switch OFF.
2. Check the wheel sensor for damage.
3. Remove dust and foreign matter adhered to the sensor rotor with a vacuum dust collector through the wheel sensor mounting hole.

CAUTION:

Install wheel sensor with no backlash and float, and tighten the mounting bolt to the specified torque.

• **Front:** Refer to [BRC-121, "FRONT WHEEL SENSOR : Exploded View"](#).

• **Rear:** Refer to [BRC-122, "REAR WHEEL SENSOR : Exploded View"](#).

Is the inspection result normal?

YES >> GO TO 8.

NO >> GO TO 6.

6.REPLACE WHEEL SENSOR (1)

1. Replace wheel sensor.
 - Front: Refer to [BRC-121, "FRONT WHEEL SENSOR : Exploded View"](#).
 - Rear: Refer to [BRC-122, "REAR WHEEL SENSOR : Exploded View"](#).
2. Erase self-diagnosis result for "ABS" with CONSULT.
3. Turn the ignition switch OFF, and wait 10 seconds or more.
4. Start the engine.
5. Select "ABS" and "DATA MONITOR", check the "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR" with CONSULT.

NOTE:

Set the "DATA MONITOR" recording speed to "10 msec".

6. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

Regarding the deference at 30 km/h (19 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%, respectively?

YES >> GO TO 7.

NO >> GO TO 19.

7.PERFORM SELF-DIAGNOSIS (2)

1. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
2. Stop the vehicle.
3. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1115" detected?

YES >> GO TO 19.

NO >> INSPECTION END

8.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Check the ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.

C1115 WHEEL SENSOR

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

3. Check the wheel sensor harness connector for disconnection or looseness.

Is the inspection result normal?

YES >> GO TO 11.

NO >> Repair or replace error-detected parts, securely lock the harness connector, and GO TO 9.

9.CHECK DATA MONITOR (2)

1. Erase self-diagnosis result for "ABS" with CONSULT.
2. Turn the ignition switch OFF, and wait 10 seconds or more.
3. Start the engine.
4. Select "ABS" and "DATA MONITOR", check the "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR" with CONSULT.

NOTE:

Set the "DATA MONITOR" recording speed to "10 msec".

5. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

Regarding the deference at 30 km/h (19 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%. respectively?

YES >> GO TO 10.

NO >> GO TO 11.

10.PERFORM SELF-DIAGNOSIS (3)

1. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
2. Stop the vehicle.
3. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1115" detected?

YES >> GO TO 11.

NO >> INSPECTION END

11.CHECK TERMINAL

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector and then check the ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.
3. Disconnect wheel sensor harness connector and check the each wheel sensor pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> GO TO 14.

NO >> Repair or replace error-detected parts and GO TO 12.

12.CHECK DATA MONITOR (3)

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Connect wheel sensor harness connector.
3. Erase self-diagnosis result for "ABS" with CONSULT.
4. Turn the ignition switch OFF, and wait 10 seconds or more.
5. Start the engine.
6. Select "ABS" and "DATA MONITOR", check the "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR" with CONSULT.

NOTE:

Set the "DATA MONITOR" recording speed to "10 msec".

7. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

Regarding the deference at 30 km/h (19 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%. respectively?

YES >> GO TO 13.

NO >> GO TO 14.

13.PERFORM SELF-DIAGNOSIS (4)

1. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
2. Stop the vehicle.
3. Perform self-diagnosis for "ABS" with CONSULT.

C1115 WHEEL SENSOR

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

Is DTC "C1115" detected?

YES >> GO TO 14.

NO >> INSPECTION END

14. CHECK WHEEL SENSOR HARNESS

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Disconnect wheel sensor harness connector.
4. Check the continuity between ABS actuator and electric unit (control unit) harness connector and wheel sensor harness connector. (Check the continuity when steering wheel is steered to RH and LH, or center harness in wheel housing is moved.)

Measurement connector and terminal for power supply circuit

| ABS actuator and electric unit (control unit) | | Wheel sensor | | Continuity |
|---|----------|--|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E36 | 9 | E22 (Front LH wheel) | 1 | Existed |
| | 5 | E39 (Front RH wheel) | 3 | |
| | 3 | C3* ¹ (Rear LH wheel) C5* ² (Rear LH wheel) | 5 | |
| | 11 | C4* ¹ (Rear RH wheel) C6* ² (Rear RH wheel) | 7 | |

*1: 2WD

*2: AWD

Measurement connector and terminal for signal circuit

| ABS actuator and electric unit (control unit) | | Wheel sensor | | Continuity |
|---|----------|--|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E36 | 8 | E22 (Front LH wheel) | 2 | Existed |
| | 6 | E39 (Front RH wheel) | 4 | |
| | 2 | C3* ¹ (Rear LH wheel) C5* ² (Rear LH wheel) | 6 | |
| | 12 | C4* ¹ (Rear RH wheel) C6* ² (Rear RH wheel) | 8 | |

*1: 2WD

*2: AWD

5. Check the continuity between ABS actuator and electric unit (control unit) harness connector and the ground.

| ABS actuator and electric unit (control unit) | | — | Continuity |
|---|----------|--------|-------------|
| Connector | Terminal | | |
| E36 | 9, 8 | Ground | Not existed |
| | 5, 6 | | |
| | 3, 2 | | |
| | 11, 12 | | |

Is the inspection result normal?

YES >> GO TO 15.

NO >> Repair or replace error-detected parts and GO TO 15.

15. CHECK DATA MONITOR (4)

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Connect wheel sensor harness connector.
3. Erase self-diagnosis result for "ABS" with CONSULT.
4. Turn the ignition switch OFF, and wait 10 seconds or more.

C1115 WHEEL SENSOR

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

5. Start the engine.
6. Select "ABS" and "DATA MONITOR", check the "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR" with CONSULT.

NOTE:

Set the "DATA MONITOR" recording speed to "10 msec".

7. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

Regarding the deference at 30 km/h (19 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%, respectively?

YES >> GO TO 16.

NO >> GO TO 17.

16.PERFORM SELF-DIAGNOSIS (5)

1. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
2. Stop the vehicle.
3. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1115" detected?

YES >> GO TO 17.

NO >> INSPECTION END

17.REPLACE WHEEL SENSOR (2)

1. Replace wheel sensor.
 - Front: Refer to [BRC-121, "FRONT WHEEL SENSOR : Exploded View"](#).
 - Rear: Refer to [BRC-122, "REAR WHEEL SENSOR : Exploded View"](#).
2. Erase self-diagnosis result for "ABS" with CONSULT.
3. Turn the ignition switch OFF, and wait 10 seconds or more.
4. Start the engine.
5. Select "ABS" and "DATA MONITOR", check the "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR" with CONSULT.

NOTE:

Set the "DATA MONITOR" recording speed to "10 msec".

6. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

Regarding the deference at 30 km/h (19 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%, respectively?

YES >> GO TO 18.

NO >> GO TO 19.

18.PERFORM SELF-DIAGNOSIS (6)

1. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
2. Stop the vehicle.
3. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1115" detected?

YES >> GO TO 19.

NO >> INSPECTION END

19.REPLACE SENSOR ROTOR

1. Replace sensor rotor.
 - Front: Refer to [BRC-124, "FRONT SENSOR ROTOR : Exploded View"](#).
 - Rear: Refer to [BRC-124, "REAR SENSOR ROTOR : Exploded View"](#).
2. Erase self-diagnosis result for "ABS".
3. Turn the ignition switch OFF, and wait 10 seconds or more.
4. Start the engine.
5. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
6. Stop the vehicle.
7. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1115" detected?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-125, "Exploded View"](#).

NO >> INSPECTION END

Special Repair Requirement

INFOID:000000007804882

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

- After replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
- Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing/replacing a steering angle sensor, be sure to perform the following procedure.
- Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- After removing/replacing a yaw rate/side/decel G sensor, be sure to perform the following procedure.
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

C1116 STOP LAMP SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1116 STOP LAMP SWITCH

Description

INFOID:000000007544675

The stop lamp switch transmits the stop lamp switch signal (ON/OFF) to the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000007544676

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|--------------|---|---|
| C1116 | STOP LAMP SW | When a stop lamp switch signal is not input where the brake pedal is depressed. | <ul style="list-style-type: none">• Harness or connector• Stop lamp switch• ABS actuator and electric unit (control unit) |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch OFF to ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1116" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-56, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000007544677

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Disconnect stop lamp switch harness connector.
4. Check the terminal for deformation, disconnection, looseness, etc.
5. Reconnect ABS actuator and electric unit (control unit) and stop lamp switch harness connectors securely.
6. Start the engine.
7. Repeat pumping brake pedal carefully several times, and perform self-diagnosis for "ABS" with CONSULT.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Poor connection of connector terminal. Repair or replace error-detected parts.

2. CHECK STOP LAMP SWITCH CLEARANCE

Check the stop lamp switch clearance. Refer to [BR-8, "Inspection and Adjustment"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Adjust stop lamp switch clearance. Refer to [BR-8, "Inspection and Adjustment"](#).

3. CHECK STOP LAMP SWITCH

Check the stop lamp switch. Refer to [BRC-57, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 4.

C1116 STOP LAMP SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

NO >> Repair or replace stop lamp switch.

4.CHECK STOP LAMP SWITCH CIRCUIT

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Condition | Voltage (Approx.) |
|---|----------|--------|--------------------------|-------------------|
| Connector | Terminal | | | |
| E36 | 16 | Ground | Brake pedal is depressed | Battery voltage |
| | | | Brake pedal is released | 0 V |

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-125, "Exploded View"](#).
NO >> Repair or replace error-detected parts.

Component Inspection

INFOID:000000007544678

1.CHECK STOP LAMP SWITCH

1. Turn the ignition switch OFF.
2. Disconnect stop lamp switch harness connector.
3. Check the continuity between stop lamp switch connector terminals.

| Stop lamp switch Terminal | Condition | Continuity |
|---------------------------|---|-------------|
| 1 – 2 | Release stop lamp switch (When brake pedal is depressed.) | Existed |
| | Push stop lamp switch (When brake pedal is released.) | Not existed |

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Replace stop lamp switch. Refer to [BR-19, "Exploded View"](#).

Special Repair Requirement

INFOID:000000007804883

1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

- After replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
- Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing/replacing a steering angle sensor, be sure to perform the following procedure.
- Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- After removing/replacing a yaw rate/side/decel G sensor, be sure to perform the following procedure.
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

C1120, C1122, C1124, C1126 IN ABS SOL

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1120, C1122, C1124, C1126 IN ABS SOL

Description

INFOID:000000007544680

The ABS IN valve increases, holds or decreases the fluid pressure of each brake caliper according to the signals transmitted by the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000007544681

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|------------------|---|--|
| C1120 | FR LH IN ABS SOL | When the control unit detects a malfunction in the front LH ABS IN valve circuit. | <ul style="list-style-type: none">• Harness or connector• ABS actuator and electric unit (control unit) |
| C1122 | FR RH IN ABS SOL | When the control unit detects a malfunction in the front RH ABS IN valve circuit. | |
| C1124 | RR LH IN ABS SOL | When the control unit detects a malfunction in the rear LH ABS IN valve circuit. | |
| C1126 | RR RH IN ABS SOL | When the control unit detects a malfunction in the rear RH ABS IN valve circuit. | |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch OFF to ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1120", "C1122", "C1124" or "C1126" detected?

YES >> Proceed to diagnosis procedure. Refer to [BRC-58, "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000007544682

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Check the terminal for deformation, disconnection, looseness, etc.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace error-detected parts.

2. CHECK ABS IN VALVE POWER SUPPLY

1. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Voltage (Approx.) |
|---|----------|--------|-------------------|
| Connector | Terminal | | |
| E36 | 1 | Ground | Battery voltage |

2. Turn the ignition switch ON.

CAUTION:

Never start the engine.

3. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Voltage (Approx.) |
|---|----------|--------|-------------------|
| Connector | Terminal | | |
| E36 | 1 | Ground | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> GO TO 3.

3.CHECK ABS IN VALVE POWER SUPPLY CIRCUIT

1. Turn the ignition switch OFF.
2. Check the 20A fusible link (#G).
3. Check the continuity and short circuit between ABS actuator and electric unit (control unit) harness connector terminal (1) and 20A fusible link (#G).

Is the inspection result normal?

- YES >> Perform trouble diagnosis for battery power supply. Refer to [PG-6. "Wiring Diagram - BATTERY POWER SUPPLY -"](#).
- NO >> Repair or replace error-detected parts.

4.CHECK ABS IN VALVE GROUND CIRCUIT

Check the continuity between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| E36 | 13 | Ground | Existed |
| | 26 | | |

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-125. "Exploded View"](#).
- NO >> Repair or replace error-detected parts.

Special Repair Requirement

INFOID:000000007804884

1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

- After replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
 - Adjustment of steering angle sensor neutral position: Refer to [BRC-9. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
 - Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
 - Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing/replacing a steering angle sensor, be sure to perform the following procedure.
 - Adjustment of steering angle sensor neutral position: Refer to [BRC-9. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- After removing/replacing a yaw rate/side/decel G sensor, be sure to perform the following procedure.
 - Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

C1121, C1123, C1125, C1127 OUT ABS SOL

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1121, C1123, C1125, C1127 OUT ABS SOL

Description

INFOID:000000007544685

The ABS OUT valve increases, holds or decreases the fluid pressure of each brake caliper according to the signals transmitted by the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000007544686

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|-------------------|--|--|
| C1121 | FR LH OUT ABS SOL | When the control unit detects a malfunction in the front LH ABS OUT valve circuit. | <ul style="list-style-type: none">• Harness or connector• ABS actuator and electric unit (control unit) |
| C1123 | FR RH OUT ABS SOL | When the control unit detects a malfunction in the front RH ABS OUT valve circuit. | |
| C1125 | RR LH OUT ABS SOL | When the control unit detects a malfunction in the rear LH ABS OUT valve circuit. | |
| C1127 | RR RH OUT ABS SOL | When the control unit detects a malfunction in the rear RH ABS OUT valve circuit. | |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch OFF to ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1121", "C1123", "C1125" or "C1127" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-60, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000007544687

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Check the terminal for deformation, disconnection, looseness, etc.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace error-detected parts.

2. CHECK ABS OUT VALVE POWER SUPPLY

1. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Voltage (Approx.) |
|---|----------|--------|-------------------|
| Connector | Terminal | | |
| E36 | 1 | Ground | Battery voltage |

2. Turn the ignition switch ON.

CAUTION:

Never start the engine.

3. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

C1121, C1123, C1125, C1127 OUT ABS SOL

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

| ABS actuator and electric unit (control unit) | | — | Voltage (Approx.) |
|---|----------|--------|-------------------|
| Connector | Terminal | | |
| E36 | 1 | Ground | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> GO TO 3.

3.CHECK ABS OUT VALVE POWER SUPPLY CIRCUIT

1. Turn the ignition switch OFF.
2. Check the 20A fusible link (#G).
3. Check the continuity and short circuit between ABS actuator and electric unit (control unit) harness connector terminal (1) and 20A fusible link (#G).

Is the inspection result normal?

- YES >> Perform trouble diagnosis for battery power supply. Refer to [PG-6. "Wiring Diagram - BATTERY POWER SUPPLY -"](#).
- NO >> Repair or replace error-detected parts.

4.CHECK ABS OUT VALVE GROUND CIRCUIT

Check the continuity between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| E36 | 13 | Ground | Existed |
| | 26 | | |

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-125. "Exploded View"](#).
- NO >> Repair or replace error-detected parts.

Special Repair Requirement

INFOID:000000007804885

1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

- After replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
 - Adjustment of steering angle sensor neutral position: Refer to [BRC-9. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
 - Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
 - Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing/replacing a steering angle sensor, be sure to perform the following procedure.
 - Adjustment of steering angle sensor neutral position: Refer to [BRC-9. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- After removing/replacing a yaw rate/side/decel G sensor, be sure to perform the following procedure.
 - Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

C1130 ENGINE SIGNAL

Description

INFOID:000000007544690

ABS actuator and electric unit (control unit) and ECM exchange the engine signal via CAN communication line.

DTC Logic

INFOID:000000007544691

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|-----------------|---|--|
| C1130 | ENGINE SIGNAL 1 | Major engine components are malfunctioning. | <ul style="list-style-type: none"> ECM ABS actuator and electric unit (control unit) CAN communication line |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch OFF to ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1130" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-62, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000007544692

1. PERFORM SELF-DIAGNOSIS (1)

Perform self-diagnosis for "ENGINE" with CONSULT.

Is any item indicated on the self-diagnosis display?

- YES >> Check the malfunctioning system. Refer to [EC-129, "CONSULT Function"](#).
 NO >> GO TO 2.

2. PERFORM SELF-DIAGNOSIS (2)

1. Erase self-diagnosis results for "ABS" with CONSULT.
2. Turn the ignition switch OFF.
3. Start the engine. Drive the vehicle for a while.
4. Make sure that malfunction indicator lamp (MIL) turns OFF.

Is indicator lamp (MIL) turns OFF?

- YES >> GO TO 3.
 NO >> Refer to [EC-129, "CONSULT Function"](#).

3. PERFORM SELF-DIAGNOSIS (3)

Stop the vehicle. Perform self-diagnosis for "ENGINE" with CONSULT.

Is any item indicated on the self-diagnosis display?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-125, "Exploded View"](#).
 NO >> Repair or replace error-detected parts.

Special Repair Requirement

INFOID:000000007804886

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G

C1130 ENGINE SIGNAL

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

SENSOR

- After replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure. A
- Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#). B
- After removing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing/replacing a steering angle sensor, be sure to perform the following procedure.
- Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#). C
- After removing/replacing a yaw rate/side/decel G sensor, be sure to perform the following procedure.
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#). D

>> END

E

BRC

G

H

I

J

K

L

M

N

O

P

C1140 ACTUATOR RELAY SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1140 ACTUATOR RELAY SYSTEM

Description

INFOID:000000007544694

Activates or deactivates each valve according to the signals transmitted by the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000007544695

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|--------------|---|---|
| C1140 | ACTUATOR RLY | When the control unit detects a malfunction in the actuator relay system. | <ul style="list-style-type: none"> • Harness or connector • ABS actuator and electric unit (control unit) |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch OFF to ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1140" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-64, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000007544696

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Check the terminal for deformation, disconnection, looseness, etc.

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair or replace error-detected parts.

2. CHECK ACTUATOR RELAY POWER SUPPLY

1. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Voltage (Approx.) |
|---|----------|--------|-------------------|
| Connector | Terminal | | |
| E36 | 1 | Ground | Battery voltage |

2. Turn the ignition switch ON.

CAUTION:

Never start the engine.

3. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Voltage (Approx.) |
|---|----------|--------|-------------------|
| Connector | Terminal | | |
| E36 | 1 | Ground | Battery voltage |

Is the inspection result normal?

C1140 ACTUATOR RELAY SYSTEM

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

- YES >> GO TO 4.
- NO >> GO TO 3.

3. CHECK ACTUATOR RELAY POWER SUPPLY CIRCUIT

1. Turn the ignition switch OFF.
2. Check the 20A fusible link (#G).
3. Check the continuity and short circuit between ABS actuator and electric unit (control unit) harness connector terminal (1) and 20A fusible link (#G).

Is the inspection result normal?

- YES >> Perform trouble diagnosis for battery power supply. Refer to [PG-6, "Wiring Diagram - BATTERY POWER SUPPLY -"](#).
- NO >> Repair or replace error-detected parts.

4. CHECK ACTUATOR RELAY GROUND CIRCUIT

Check the continuity between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| E36 | 13 | Ground | Existed |
| | 26 | | |

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-125, "Exploded View"](#).
- NO >> Repair or replace error-detected parts.

Special Repair Requirement

INFOID:000000007804887

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

- After replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
- Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing/replacing a steering angle sensor, be sure to perform the following procedure.
- Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- After removing/replacing a yaw rate/side/decel G sensor, be sure to perform the following procedure.
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

C1142 PRESS SENSOR

Description

INFOID:000000007544699

The pressure sensor converts the brake fluid pressure to an electric signal and transmits it to the ABS actuator and electric unit (control unit). [The pressure sensor is integrated in the ABS actuator and electric unit (control unit).]

DTC Logic

INFOID:000000007544700

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|-------------------|---|---|
| C1142 | PRESS SEN CIRCUIT | Pressure sensor signal line is open or shorted, or pressure sensor is malfunctioning. | <ul style="list-style-type: none"> • Harness or connector • Stop lamp switch • ABS actuator and electric unit (control unit) |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch OFF to ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1142" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-66, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000007544701

1. CHECK STOP LAMP SWITCH SYSTEM

Check the stop lamp switch system. Refer to [BRC-56, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair or replace error-detected parts.

2. CHECK DATA MONITOR

1. Check the brake fluid leakage. Refer to [BR-11, "Inspection"](#).
2. Check the front brake piping. Refer to [BR-23, "FRONT : Inspection"](#).
3. Check the rear brake piping. Refer to [BR-25, "REAR : Inspection"](#).
4. Check the brake pedal. Refer to [BR-20, "Inspection and Adjustment"](#).
5. Check the master cylinder. Refer to [BR-28, "Inspection"](#).
6. Check the brake booster. Refer to [BR-30, "Inspection and Adjustment"](#).
7. Check the front disc brake. Refer to [BR-41, "BRAKE CALIPER ASSEMBLY \(1 PISTON TYPE\) : Inspection"](#).
8. Check the rear disc brake. Refer to [BR-51, "BRAKE CALIPER ASSEMBLY : Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair or replace error-detected parts.

3. PERFORM SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT.

Is any item indicated on the self-diagnosis display?

C1142 PRESS SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-125. "Exploded View"](#).
- NO >> Repair or replace error-detected parts.

A

Special Repair Requirement

INFOID:000000007804888

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

B

- After replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
- Adjustment of steering angle sensor neutral position: Refer to [BRC-9. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
- Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing/replacing a steering angle sensor, be sure to perform the following procedure.
- Adjustment of steering angle sensor neutral position: Refer to [BRC-9. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- After removing/replacing a yaw rate/side/decel G sensor, be sure to perform the following procedure.
- Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).

C

D

E

BRC

>> END

G

H

I

J

K

L

M

N

O

P

C1143 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1143 STEERING ANGLE SENSOR

Description

INFOID:000000007544704

The steering angle sensor detects the rotation amount, angular velocity and direction of the steering wheel, and transmits the data to the ABS actuator and electric unit (control unit) via CAN communication.

DTC Logic

INFOID:000000007544705

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|--------------------|--|--|
| C1143 | ST ANG SEN CIRCUIT | Neutral position of steering angle sensor is dislocated, steering angle sensor is malfunctioning, or wheel alignment is outside specified range. | <ul style="list-style-type: none">• Harness or connector• Steering angle sensor• ABS actuator and electric unit (control unit)• Wheel alignment |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch OFF to ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1143" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-68, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000007544706

1. CHECK WHEEL ALIGNMENT

Check the wheel alignment. Refer to [FSU-7, "Inspection"](#) (front), [RSU-6, "Inspection"](#) (rear).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Adjust wheel alignment. Refer to [FSU-7, "Inspection"](#) (front), [RSU-6, "Adjustment"](#) (rear).

2. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Disconnect steering angle sensor harness connector.
4. Check the terminal for deformation, disconnection, looseness, etc.

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace error-detected parts.

3. CHECK STEERING ANGLE SENSOR POWER SUPPLY

1. Check the voltage between steering angle sensor harness connector and ground.

| Steering angle sensor | | — | Voltage (Approx.) |
|-----------------------|----------|--------|-------------------|
| Connector | Terminal | | |
| M30 | 4 | Ground | 0 V |

2. Turn the ignition switch ON.

C1143 STEERING ANGLE SENSOR

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

CAUTION:

Never start the engine.

3. Check the voltage between steering angle sensor harness connector and ground.

| Steering angle sensor | | — | Voltage (Approx.) |
|-----------------------|----------|--------|-------------------|
| Connector | Terminal | | |
| M30 | 4 | Ground | Battery voltage |

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

4.CHECK STEERING ANGLE SENSOR POWER SUPPLY CIRCUIT

1. Turn the ignition switch OFF.
2. Check the 10A fuse (#3).
3. Disconnect fuse block (J/B) harness connector.
4. Check the continuity between steering angle sensor harness connector and fuse block (J/B) harness connector.

| Steering angle sensor | | Fuse block (J/B) | | Continuity |
|-----------------------|----------|------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M30 | 4 | M1 | 2A | Existed |

Is the inspection result normal?

YES >> Perform trouble diagnosis for ignition power supply. Refer to [PG-21, "Wiring Diagram - IGNITION POWER SUPPLY -"](#).

NO >> Repair or replace error-detected parts.

5.CHECK STEERING ANGLE SENSOR GROUND CIRCUIT

Check the continuity between steering angle sensor harness connector and ground.

| Steering angle sensor | | — | Continuity |
|-----------------------|----------|--------|------------|
| Connector | Terminal | | |
| M30 | 1 | Ground | Existed |

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace error-detected parts.

6.CHECK STEERING WHEEL PLAY

Check the steering wheel play. Refer to [ST-33, "Inspection"](#).

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace error-detected parts.

7.CHECK CAN COMMUNICATION LINE

Check the "STRG BRANCH LINE CIRCUIT". Refer to [LAN-47, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair or replace error-detected parts. Refer to [LAN-21, "FOR USA AND CANADA : Precautions for Harness Repair"](#) (for USA and Canada), [LAN-23, "FOR MEXICO : Precautions for Harness Repair"](#) (for Mexico).

8.CHECK DATA MONITOR

1. Connect the ABS actuator and electric unit (control unit) harness connector.
2. Connect the steering angle sensor harness connector.
3. Check the steering angle sensor signal. Refer to [BRC-102, "Reference Value"](#).

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

C1143 STEERING ANGLE SENSOR

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-125, "Exploded View"](#).
- NO >> Replace steering angle sensor. Refer to [BRC-128, "Exploded View"](#).

Special Repair Requirement

INFOID:000000007804889

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

- After replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
- Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing/replacing a steering angle sensor, be sure to perform the following procedure.
- Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- After removing/replacing a yaw rate/side/decel G sensor, be sure to perform the following procedure.
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

C1144 INCOMPLETE STEERING ANGLE SENSOR ADJUSTMENT

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1144 INCOMPLETE STEERING ANGLE SENSOR ADJUSTMENT

Description

INFOID:000000007544709

The steering angle sensor detects the rotation amount, angular velocity and direction of the steering wheel, and transmits the data to the ABS actuator and electric unit (control unit) via CAN communication.

DTC Logic

INFOID:000000007544710

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|-------------------|---|--|
| C1144 | ST ANG SEN SIGNAL | Adjustment of steering angle sensor neutral position is not finished. | <ul style="list-style-type: none">• Harness or connector• Steering angle sensor• ABS actuator and electric unit (control unit) |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch OFF to ON.
2. Select "ABS", "WORK SUPPORT" and "ST ANGLE SENSOR ADJUSTMENT" in order with CONSULT, and perform adjust the neutral position of steering angle sensor.
3. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1144" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-71, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000007544711

1. CHECK STEERING ANGLE SENSOR

Check the steering angle sensor. Refer to [BRC-68, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-125, "Exploded View"](#).
NO >> Repair or replace error-detected parts.

Special Repair Requirement

INFOID:000000007804890

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

- After replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
 - Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
 - Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
 - Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing/replacing a steering angle sensor, be sure to perform the following procedure.
 - Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- After removing/replacing a yaw rate/side/decel G sensor, be sure to perform the following procedure.
 - Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).

C1144 INCOMPLETE STEERING ANGLE SENSOR ADJUSTMENT

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

>> END

C1155 BRAKE FLUID LEVEL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1155 BRAKE FLUID LEVEL SWITCH

Description

INFOID:000000007544714

The brake fluid level switch converts the brake fluid level to an electric signal and transmits it to the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000007544715

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|--------------------|---|---|
| C1155 | BR FLUID LEVEL LOW | Brake fluid level is low or communication line between the ABS actuator and electric unit (control unit) and brake fluid level switch is open or shorted. | <ul style="list-style-type: none">• Harness or connector• ABS actuator and electric unit (control unit)• Brake fluid level low• Brake fluid level switch• Combination meter |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch OFF to ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1155" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-73, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000007544716

1. CHECK BRAKE FLUID LEVEL

1. Turn the ignition switch OFF.
2. Check the brake fluid level. Refer to [BR-11, "Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Refill brake fluid. Refer to [BR-11, "Refilling"](#).

2. PERFORM SELF-DIAGNOSIS (1)

1. Erase self-diagnosis result for "ABS" with CONSULT.
2. Turn the ignition switch OFF, and wait 10 seconds or more.
3. Turn the ignition switch ON.

CAUTION:

Never start the engine.

4. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1155" detected?

- YES >> INSPECTION END
NO >> GO TO 3.

3. CHECK BRAKE FLUID LEVEL SWITCH

Check the brake fluids level switch. Refer to [BRC-75, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.

C1155 BRAKE FLUID LEVEL SWITCH

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Replace sub tank. Refer to [BR-26. "Exploded View"](#). GO TO 4.

4.PERFORM SELF-DIAGNOSIS (2)

1. Erase self-diagnosis result for "ABS" with CONSULT.
2. Turn the ignition switch OFF, and wait 10 seconds or more.
3. Turn the ignition switch ON.

CAUTION:

Never start the engine.

4. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1155" detected?

YES >> INSPECTION END

NO >> GO TO 5.

5.CHECK CONNECTOR AND TERMINAL

1. Turn the ignition switch OFF.
2. Disconnect brake fluid level switch harness connector.
3. Check the brake fluid level switch harness connector for disconnection or looseness.
4. Check the brake fluid level switch pin terminals for damage or loose connection with harness connector.
5. Disconnect combination meter harness connector.
6. Check the combination meter harness connector for disconnection or looseness.
7. Check the combination meter pin terminals for damage or loose connection with harness connector.
8. Disconnect ABS actuator and electric unit (control unit) harness connector.
9. Check the ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.
10. Check the ABS actuator and electric unit (control unit) harness connector pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace error-detected parts. GO TO 6.

6.PERFORM SELF-DIAGNOSIS (3)

1. Connect brake fluid level switch harness connector.
2. Connect combination meter harness connector.
3. Connect ABS actuator and electric unit (control unit) harness connector.
4. Erase self-diagnosis result for "ABS" with CONSULT.
5. Turn the ignition switch OFF, and wait 10 seconds or more.
6. Turn the ignition switch ON.

CAUTION:

Never start the engine.

7. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1155" detected?

YES >> INSPECTION END

NO >> GO TO 7.

7.CHECK BRAKE FLUID LEVEL SWITCH CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect brake fluid level switch harness connector.
3. Disconnect ABS actuator and electric unit (control unit) harness connector.
4. Disconnect combination meter harness connector.
5. Check the continuity between brake fluid level switch harness connector and ABS actuator and electric unit (control unit) harness connector.

| Brake fluid level switch | | ABS actuator and electric unit (control unit) | | Continuity |
|--------------------------|----------|---|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E37 | 1 | E36 | 7 | Existed |

6. Check the continuity between brake fluid level switch harness connector and combination meter harness connector.

C1155 BRAKE FLUID LEVEL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

| Brake fluid level switch | | Combination meter | | Continuity |
|--------------------------|----------|-------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E37 | 1 | M34 | 27 | Existed |

7. Check the continuity between brake fluid level switch harness connector and ground.

| Brake fluid level switch | | — | Continuity |
|--------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| E37 | 1 | Ground | Not existed |

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair or replace error-detected parts.

8. CHECK BRAKE FLUID LEVEL SWITCH GROUND

Check the continuity between brake fluid level switch harness connector and ground.

| Brake fluid level switch | | — | Continuity |
|--------------------------|----------|--------|------------|
| Connector | Terminal | | |
| E37 | 2 | Ground | Existed |

Is the inspection result normal?

YES >> GO TO 9.

NO >> Repair or replace error-detected parts.

9. CHECK COMBINATION METER

Check the combination meter. Refer to [MWI-35, "CONSULT Function \(METER/M&A\)"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-125, "Exploded View"](#).

NO >> Repair or replace combination meter. Refer to [MWI-94, "Exploded View"](#).

Component Inspection

INFOID:000000007544717

1. CHECK BRAKE FLUID LEVEL SWITCH

1. Turn the ignition switch OFF.
2. Disconnect brake fluid level switch harness connector.
3. Check the continuity between brake fluid level switch connector terminals.

| Brake fluid level switch | | Condition | Continuity |
|--------------------------|--|--|-------------|
| Terminal | | | |
| 1 – 2 | | When brake fluid is full in the sub tank. | Not existed |
| | | When brake fluid is empty in the sub tank. | Existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace sub tank. Refer to [BR-26, "Exploded View"](#).

Special Repair Requirement

INFOID:000000007804891

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

- After replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
 - Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
 - Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).

C1155 BRAKE FLUID LEVEL SWITCH

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

- After removing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing/replacing a steering angle sensor, be sure to perform the following procedure.
- Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- After removing/replacing a yaw rate/side/decel G sensor, be sure to perform the following procedure.
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

C1160 INCOMPLETE DECEL G SENSOR CALIBRATION

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1160 INCOMPLETE DECEL G SENSOR CALIBRATION

Description

INFOID:000000007544719

Yaw rate/side/decel G sensor detects decel G affecting the vehicle, and transmits the data to the ABS actuator and electric unit (control unit) as an analog voltage signal.

DTC Logic

INFOID:000000007544720

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|-----------------|--|---|
| C1160 | DECEL G SEN SET | Calibration of decel G sensor is not finished. | <ul style="list-style-type: none">• yaw rate/side/decel G sensor• Harness or connector• ABS actuator and electric unit (control unit)• Incomplete decel G sensor calibration |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch OFF to ON.
2. Select "ABS", "WORK SUPPORT" and "DECEL G SEN CALIBRATION" in order with CONSULT, and perform calibration of decel G sensor. Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Special Repair Requirement"](#).
3. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1160" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-77. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000007544721

1. CHECK YAW RATE/SIDE/DECEL G SENSOR

Check the yaw rate/side/decel G sensor. Refer to [BRC-102. "Reference Value"](#).

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-125. "Exploded View"](#).
NO >> Repair or replace error-detected parts.

Special Repair Requirement

INFOID:000000007804892

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

- After replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
 - Adjustment of steering angle sensor neutral position: Refer to [BRC-9. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
 - Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
 - Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing/replacing a steering angle sensor, be sure to perform the following procedure.
 - Adjustment of steering angle sensor neutral position: Refer to [BRC-9. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- After removing/replacing a yaw rate/side/decel G sensor, be sure to perform the following procedure.

C1160 INCOMPLETE DECEL G SENSOR CALIBRATION

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

C1161 INCOMPLETE SIDE G SENSOR CALIBRATION

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1161 INCOMPLETE SIDE G SENSOR CALIBRATION

Description

INFOID:000000007544723

Yaw rate/side/decel G sensor detects side G affecting the vehicle, and transmits the data to the ABS actuator and electric unit (control unit) as an analog voltage signal.

DTC Logic

INFOID:000000007544724

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|----------------|---|---|
| C1161 | SIDE G SEN SET | When there is an internal malfunction in the ABS actuator and electric unit (control unit). | ABS actuator and electric unit (control unit) |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch OFF to ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1161" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-79. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000007544725

1. REPLACE ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Replace ABS actuator and electric unit (control unit) when self-diagnostic result shows items other than those applicable.

>> Replace ABS actuator and electric unit (control unit). Refer to [BRC-125. "Exploded View"](#).

Special Repair Requirement

INFOID:000000007804893

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

- After replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
- Adjustment of steering angle sensor neutral position: Refer to [BRC-9. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
- Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing/replacing a steering angle sensor, be sure to perform the following procedure.
- Adjustment of steering angle sensor neutral position: Refer to [BRC-9. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- After removing/replacing a yaw rate/side/decel G sensor, be sure to perform the following procedure.
- Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

C1162 INCOMPLETE PRESSURE SENSOR CALIBRATION

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1162 INCOMPLETE PRESSURE SENSOR CALIBRATION

Description

INFOID:000000007544727

The pressure sensor converts the brake fluid pressure to an electric signal and transmits it to the ABS actuator and electric unit (control unit). [The pressure sensor is integrated in the ABS actuator and electric unit (control unit).]

DTC Logic

INFOID:000000007544728

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|---------------|---|---|
| C1162 | PRESS SEN SET | When there is an internal malfunction in the ABS actuator and electric unit (control unit). | ABS actuator and electric unit (control unit) |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch OFF to ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1162" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-80, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000007544729

1. REPLACE ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Replace ABS actuator and electric unit (control unit) when self-diagnostic result shows items other than those applicable.

>> Replace ABS actuator and electric unit (control unit). Refer to [BRC-125, "Exploded View"](#).

Special Repair Requirement

INFOID:000000007804894

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

- After replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
- Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing/replacing a steering angle sensor, be sure to perform the following procedure.
- Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- After removing/replacing a yaw rate/side/decel G sensor, be sure to perform the following procedure.
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

C1164, C1165 CV SYSTEM

Description

INFOID:000000007544731

The cut valve shuts off the normal brake fluid path from the master cylinder, when VDC/TCS is activated.

DTC Logic

INFOID:000000007544732

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|--------------|---|---|
| C1164 | CV1 | Cut valve 1 (CV1) on the primary side is open circuit or shorted, or the control line is open or shorted to the power supply or the ground. | <ul style="list-style-type: none"> Harness or connector ABS actuator and electric unit (control unit) |
| C1165 | CV2 | Cut valve 2 (CV2) on the secondary side is open circuit or shorted, or the control line is open or shorted to the power supply or the ground. | |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch OFF to ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1164" or "C1165" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-81, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000007544733

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Check the terminal for deformation, disconnection, looseness, etc.

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair or replace error-detected parts.

2. CHECK CUT VALVE (CV) POWER SUPPLY

1. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Voltage (Approx.) |
|---|----------|--------|-------------------|
| Connector | Terminal | | |
| E36 | 1 | Ground | Battery voltage |

2. Turn the ignition switch ON.
 - CAUTION:**
 - Never start the engine.**
3. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Voltage (Approx.) |
|---|----------|--------|-------------------|
| Connector | Terminal | | |
| E36 | 1 | Ground | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> GO TO 3.

3.CHECK CUT VALVE (CV) POWER SUPPLY CIRCUIT

1. Turn the ignition switch OFF.
2. Check the 20A fusible link (#G).
3. Check the continuity and short circuit between ABS actuator and electric unit (control unit) harness connector terminal (1) and 20A fusible link (#G).

Is the inspection result normal?

- YES >> Perform trouble diagnosis for battery power supply. Refer to [PG-6. "Wiring Diagram - BATTERY POWER SUPPLY -"](#).
- NO >> Repair or replace error-detected parts.

4.CHECK CUT VALVE (CV) GROUND CIRCUIT

Check the continuity between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| E36 | 13 | Ground | Existed |
| | 26 | | |

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-125. "Exploded View"](#).
- NO >> Repair or replace error-detected parts.

Special Repair Requirement

INFOID:000000007804895

1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

- After replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
 - Adjustment of steering angle sensor neutral position: Refer to [BRC-9. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
 - Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
 - Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing/replacing a steering angle sensor, be sure to perform the following procedure.
 - Adjustment of steering angle sensor neutral position: Refer to [BRC-9. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- After removing/replacing a yaw rate/side/decel G sensor, be sure to perform the following procedure.
 - Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

C1166, C1167 SV SYSTEM

Description

INFOID:000000007544736

The suction valve supplies the brake fluid from the master cylinder to the pump, when VDC/TCS is activated.

DTC Logic

INFOID:000000007544737

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|--------------|---|---|
| C1166 | SV1 | Suction valve 1 (SV1) on the primary side is open circuit or shorted, or the control line is open or shorted to the power supply or the ground. | <ul style="list-style-type: none"> • Harness or connector • ABS actuator and electric unit (control unit) |
| C1167 | SV2 | Suction valve 2 (SV2) on the secondary side is open circuit or shorted, or the control line is open or shorted to the power supply or the ground. | |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch OFF to ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1166" or "C1167" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-83, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000007544738

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Check the terminal for deformation, disconnection, looseness, etc.

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair or replace error-detected parts.

2. CHECK SUCTION VALVE (SV) POWER SUPPLY

1. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Voltage (Approx.) |
|---|----------|--------|-------------------|
| Connector | Terminal | | |
| E36 | 1 | Ground | Battery voltage |

2. Turn the ignition switch ON.
CAUTION:
Never start the engine.
3. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

< DTC/CIRCUIT DIAGNOSIS >

| ABS actuator and electric unit (control unit) | | — | Voltage (Approx.) |
|---|----------|--------|-------------------|
| Connector | Terminal | | |
| E36 | 1 | Ground | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> GO TO 3.

3.CHECK SUCTION VALVE (SV) POWER SUPPLY CIRCUIT

1. Turn the ignition switch OFF.
2. Check the 20A fusible link (#G).
3. Check the continuity and short circuit between ABS actuator and electric unit (control unit) harness connector terminal (1) and 20A fusible link (#G).

Is the inspection result normal?

- YES >> Perform trouble diagnosis for battery power supply. Refer to [PG-6. "Wiring Diagram - BATTERY POWER SUPPLY -"](#).
- NO >> Repair or replace error-detected parts.

4.CHECK SUCTION VALVE (SV) GROUND CIRCUIT

Check the continuity between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| E36 | 13 | Ground | Existed |
| | 26 | | |

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-125. "Exploded View"](#).
- NO >> Repair or replace error-detected parts.

Special Repair Requirement

INFOID:000000007804897

1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

- After replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
 - Adjustment of steering angle sensor neutral position: Refer to [BRC-9. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
 - Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
 - Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing/replacing a steering angle sensor, be sure to perform the following procedure.
 - Adjustment of steering angle sensor neutral position: Refer to [BRC-9. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- After removing/replacing a yaw rate/side/decel G sensor, be sure to perform the following procedure.
 - Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

U1000 CAN COMM CIRCUIT

Description

INFOID:000000007544741

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

DTC Logic

INFOID:000000007544742

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|------------------|---|---|
| U1000 | CAN COMM CIRCUIT | When ABS actuator and electric unit (control unit) is not transmitting or receiving CAN communication signal for 2 seconds or more. | <ul style="list-style-type: none">• Harness or connector• CAN communication line• ABS actuator and electric unit (control unit) |

A

B

C

D

E

BRC

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

G

H

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch OFF to ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

I

J

Is DTC "U1000" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-85, "Diagnosis Procedure"](#).
NO >> INSPECTION END

K

Diagnosis Procedure

INFOID:000000007544743

1. PERFORM SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT.

L

Is DTC "U1000" detected?

- YES >> Proceed to [LAN-15, "Trouble Diagnosis Flow Chart"](#).
NO >> INSPECTION END

M

Special Repair Requirement

INFOID:000000007804898

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

- After replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
 - Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
 - Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
 - Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing/replacing a steering angle sensor, be sure to perform the following procedure.
 - Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- After removing/replacing a yaw rate/side/decel G sensor, be sure to perform the following procedure.
 - Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).

N

O

P

U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

>> END

U1002 SYSTEM COMM (CAN)

Description

INFOID:000000007544745

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

DTC Logic

INFOID:000000007544746

DTC DETECTION LOGIC

| DTC | Display item | Malfunction detected condition | Possible cause |
|-------|-------------------|--|---|
| U1002 | SYSTEM COMM (CAN) | When ABS actuator and electric unit (control unit) is not transmitting or receiving CAN communication signal of steering angle sensor for 2 seconds or less. | <ul style="list-style-type: none"> • Harness or connector • CAN communication line • ABS actuator and electric unit (control unit) |

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch OFF to ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "U1002" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-87, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000007544747

CAUTION:

- **Never apply 7.0 V or more to the measurement terminal.**
- **Use a tester with open terminal voltage of 7.0 V or less.**
- **Turn the ignition switch OFF and disconnect the battery cable from the negative terminal when checking the harness.**

1. CHECK CAN DIAGNOSIS SUPPORT MONITOR

1. Select "ABS" and "CAN Diagnosis Support Monitor" in order with CONSULT.
2. Check the malfunction history between each control unit connected to ABS actuator and electric unit (control unit).

Check the result of "PAST"

All items are "OK">>Refer to [GI-44, "Intermittent Incident"](#).
 "TRANSMIT DIAG" is other than "OK">>GO TO 2.

A control unit other than ABS actuator and electric unit (control unit) is anything other than "OK">>GO TO 3.

2. CHECK TRANSMITTING SIDE UNIT

Check the ABS actuator and electric unit (control unit) harness connector terminals No. 21 and 23 for damage or loose connection.

Is the inspection result normal?

- YES >> Erase self-diagnosis results. Then perform self-diagnosis for "ABS" with CONSULT.

U1002 SYSTEM COMM (CAN)

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Recheck the terminals for damage or loose connection. Refer to [LAN-5. "Precautions for Harness Repair"](#).

3.CHECK APPLICABLE CONTROL UNIT

Check the damage or loose connection of each CAN communication line harness connector terminals.

Is the inspection result normal?

YES >> Erase self-diagnosis results. Then perform self-diagnosis for applicable control unit with CONSULT.

NO >> Recheck the terminals for damage or loose connection. Refer to [LAN-5. "Precautions for Harness Repair"](#).

Special Repair Requirement

INFOID:000000007804899

1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

- After replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
- Adjustment of steering angle sensor neutral position: Refer to [BRC-9. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
- Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing/replacing a steering angle sensor, be sure to perform the following procedure.
- Adjustment of steering angle sensor neutral position: Refer to [BRC-9. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- After removing/replacing a yaw rate/side/decel G sensor, be sure to perform the following procedure.
- Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

POWER SUPPLY AND GROUND CIRCUIT

Description

INFOID:000000007544749

Supplies power to ABS actuator and electric unit (control unit).

Diagnosis Procedure

INFOID:000000007544750

1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) IGNITION POWER SUPPLY

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Voltage (Approx.) |
|---|----------|--------|-------------------|
| Connector | Terminal | | |
| E36 | 20 | Ground | 0 V |

4. Turn the ignition switch ON.
CAUTION:
Never start the engine.
5. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Voltage (Approx.) |
|---|----------|--------|-------------------|
| Connector | Terminal | | |
| E36 | 20 | Ground | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) IGNITION POWER SUPPLY CIRCUIT

1. Turn the ignition switch OFF.
2. Check the 10A fuse (#45).
3. Disconnect IPDM E/R harness connector.
4. Check the continuity between ABS actuator and electric unit (control unit) harness connector and IPDM E/R harness connector.

| ABS actuator and electric unit (control unit) | | IPDM E/R | | Continuity |
|---|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E36 | 20 | E10 | 25 | Existed |

Is the inspection result normal?

- YES >> Perform trouble diagnosis for ignition power supply. Refer to [PG-21, "Wiring Diagram - IGNITION POWER SUPPLY -"](#).
- NO >> Repair or replace error-detected parts.

3. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) BATTERY POWER SUPPLY

1. Turn the ignition switch OFF.
2. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

| ABS actuator and electric unit (control unit) | | — | Voltage (Approx.) |
|---|----------|--------|-------------------|
| Connector | Terminal | | |
| E36 | 1 | Ground | Battery voltage |
| | 14 | | |

3. Turn the ignition switch ON.

CAUTION:

Never start the engine.

4. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Voltage (Approx.) |
|---|----------|--------|-------------------|
| Connector | Terminal | | |
| E36 | 1 | Ground | Battery voltage |
| | 14 | | |

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

4. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) BATTERY POWER SUPPLY CIRCUIT

1. Turn the ignition switch OFF.
2. Check the 20A fusible link (#G) and 30A fusible link (#F).
3. Check the continuity and short circuit between ABS actuator and electric unit (control unit) harness connector terminal (1) and 20A fusible link (#G).
4. Check the continuity and short circuit between ABS actuator and electric unit (control unit) harness connector terminal (14) and 30A fusible link (#F).

Is the inspection result normal?

YES >> Perform trouble diagnosis for battery power supply. Refer to [PG-6. "Wiring Diagram - BATTERY POWER SUPPLY -"](#).

NO >> Repair or replace error-detected parts.

5. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Check the continuity between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| E36 | 13 | Ground | Existed |
| | 26 | | |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace error-detected parts.

Special Repair Requirement

INFOID:000000007804901

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

- After replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
 - Adjustment of steering angle sensor neutral position: Refer to [BRC-9. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
 - Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

- Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing/replacing a steering angle sensor, be sure to perform the following procedure.
- Adjustment of steering angle sensor neutral position: Refer to [BRC-9. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- After removing/replacing a yaw rate/side/decel G sensor, be sure to perform the following procedure.
- Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

PARKING BRAKE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

PARKING BRAKE SWITCH

Component Function Check

INFOID:000000007544752

1. CHECK PARKING BRAKE SWITCH OPERATION

Operate the parking brake pedal. Then check that the brake warning lamp in the combination meter turns ON/OFF correctly.

| Condition | Brake warning lamp illumination status |
|--|--|
| When the parking brake pedal is operation | ON |
| When the parking brake pedal is not operation. | OFF |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Proceed to diagnosis procedure. Refer to [BRC-92, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000007544753

1. CHECK PARKING BRAKE SWITCH

Check the parking brake switch. Refer to [BRC-92, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace parking brake switch. Refer to [PB-6, "Exploded View"](#).

2. CHECK COMBINATION METER

Check the indication and operation of combination meter are normal. Refer to [MWI-34, "Diagnosis Description"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the combination meter. Refer to [MWI-35, "CONSULT Function \(METER/M&A\)"](#).

3. CHECK PARKING BRAKE SWITCH CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect parking brake switch harness connector.
3. Disconnect combination meter harness connector.
4. Check the continuity between parking brake switch harness connector and combination meter harness connector.

| Parking brake switch | | Combination meter | | Continuity |
|----------------------|----------|-------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E27 | 1 | M34 | 26 | Existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace error-detected parts.

Component Inspection

INFOID:000000007544754

1. CHECK PARKING BRAKE SWITCH

1. Turn the ignition switch OFF.
2. Disconnect parking brake switch harness connector.
3. Check the continuity between parking brake switch connector terminal and ground.

PARKING BRAKE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

| Parking brake switch | | — | Condition | Continuity |
|----------------------|----------|--------|--|-------------|
| Connector | Terminal | | | |
| E27 | 1 | Ground | When the parking brake switch is operated. | Existed |
| | | | When the parking brake switch is not operated. | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace parking brake switch. Refer to [PB-6. "Exploded View"](#).

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

VDC OFF SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

VDC OFF SWITCH

Description

INFOID:000000007544755

VDC OFF switch can deactivate (turn OFF) the VDC/TCS function by pressing the VDC OFF switch.

Component Function Check

INFOID:000000007544756

1.CHECK VDC OFF SWITCH OPERATION

Turn ON/OFF the VDC OFF switch and check that the VDC OFF indicator lamp in the combination meter turns ON/OFF correctly.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Proceed to diagnosis procedure. Refer to [BRC-94, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000007544757

1.CHECK VDC OFF SWITCH

Check the VDC OFF switch. Refer to [BRC-95, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace VDC OFF switch. Refer to [BRC-129, "Removal and Installation"](#).

2.CHECK VDC OFF SWITCH HARNESS

1. Disconnect ABS actuator and electric unit (control unit) harness connector.
2. Disconnect VDC OFF switch harness connector.
3. Check the continuity between VDC OFF switch harness connector and ABS actuator and electric unit (control unit) harness connector.

| ABS actuator and electric unit (control unit) | | VDC OFF switch | | Continuity |
|---|----------|----------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E36 | 22 | M5 | 1 | Existed |

4. Check the continuity between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Continuity |
|---|----------|--------|-------------|
| Connector | Terminal | | |
| E36 | 22 | Ground | Not existed |

5. Check the continuity between VDC OFF switch harness connector and ground.

| VDC OFF switch | | — | Continuity |
|----------------|----------|--------|------------|
| Connector | Terminal | | |
| M5 | 2 | Ground | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace error-detected parts.

3.CHECK COMBINATION METER

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Connect VDC OFF switch harness connector.
3. Check the indication and operation of combination meter are normal. Refer to [MWI-34, "Diagnosis Description"](#).

Is the inspection result normal?

YES >> INSPECTION END

VDC OFF SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

NO >> Repair or replace combination meter.

Component Inspection

INFOID:000000007544758

1. CHECK VDC OFF SWITCH

1. Turn the ignition switch OFF.
2. Disconnect VDC OFF switch harness connector.
3. Check the continuity between VDC OFF switch connector terminals.

| VDC OFF switch | Condition | Condition |
|----------------|--------------------------------------|-------------|
| Terminal | | |
| 1 - 2 | When VDC OFF switch is hold pressed. | Existed |
| | When releasing VDC OFF switch. | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace VDC OFF switch. Refer to [BRC-129. "Removal and Installation"](#).

Special Repair Requirement

INFOID:000000007804902

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

- After replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
- Adjustment of steering angle sensor neutral position: Refer to [BRC-9. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
- Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing/replacing a steering angle sensor, be sure to perform the following procedure.
- Adjustment of steering angle sensor neutral position: Refer to [BRC-9. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- After removing/replacing a yaw rate/side/decel G sensor, be sure to perform the following procedure.
- Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

ABS WARNING LAMP

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

ABS WARNING LAMP

Description

INFOID:000000007544759

×: ON –: OFF

| Condition | ABS warning lamp |
|---|------------------|
| Ignition switch OFF | – |
| For 2 seconds after turning ignition switch ON | × |
| 2 seconds later after turning ignition switch ON (system is normal) | – |
| ABS function is malfunctioning. | × |
| EBD function is malfunctioning. | × |

Component Function Check

INFOID:000000007544760

1. CHECK ABS WARNING LAMP OPERATION

Check that the lamp illuminates for approximately 2 seconds after the ignition switch is turned ON.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Proceed to diagnosis procedure. Refer to [BRC-96, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000007544761

1. PERFORM SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT.

Is the inspection result normal?

YES >> Check the combination meter. Refer to [MWI-35, "CONSULT Function \(METER/M&A\)"](#).

NO >> Check items displayed by self-diagnosis for "ABS" with CONSULT.

Special Repair Requirement

INFOID:000000007804903

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

- After replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
 - Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
 - Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
 - Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing/replacing a steering angle sensor, be sure to perform the following procedure.
 - Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- After removing/replacing a yaw rate/side/decel G sensor, be sure to perform the following procedure.
 - Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

BRAKE WARNING LAMP

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

BRAKE WARNING LAMP

Description

INFOID:000000007544763

×: ON –: OFF

| Condition | Brake warning lamp (Note 1) |
|---|-----------------------------|
| Ignition switch OFF | – |
| For 2 seconds after turning ignition switch ON | × (Note 2) |
| 2 seconds later after turning ignition switch ON (system is normal) | × (Note 2) |
| ABS function is malfunctioning. | – |
| EBD function is malfunctioning. | × |

NOTE:

- 1: Brake warning lamp will turn ON in case of parking brake operation (when switch is ON) or of brake fluid level switch operation (when brake fluid is insufficient).
- 2: After starting the engine, brake warning lamp is turned off.

Component Function Check

INFOID:000000007544764

BRC

1. BRAKE WARNING LAMP OPERATION CHECK 1

Check that the lamp illuminates for approximately 2 seconds after the ignition switch is turned ON.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Proceed to diagnosis procedure. Refer to [BRC-97. "Diagnosis Procedure"](#).

2. BRAKE WARNING LAMP OPERATION CHECK 2

Check that the brake warning lamp in the combination meter turns ON/OFF correctly when operating the parking brake pedal.

NOTE:

Brake warning lamp will turn ON in case of parking brake operation (when switch is ON) or of brake fluid level switch operation (when brake fluid is insufficient).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Check the parking brake switch. Refer to [BRC-92. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000007544765

1. CHECK PARKING BRAKE SWITCH

Check that the brake warning lamp in the combination meter turns ON/OFF correctly when operating the parking brake pedal.

NOTE:

Brake warning lamp will turn ON in case of parking brake operation (when switch is ON) or of brake fluid level switch operation (when brake fluid is insufficient).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check the parking brake switch. Refer to [BRC-92. "Diagnosis Procedure"](#).

2. PERFORM SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT.

Is the inspection result normal?

YES >> Check the combination meter. Refer to [MWI-35. "CONSULT Function \(METER/M&A\)"](#).

NO >> Check items displayed by self-diagnosis for "ABS" with CONSULT.

Special Repair Requirement

INFOID:000000007804905

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G

BRAKE WARNING LAMP

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

SENSOR

- After replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
- Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing/replacing a steering angle sensor, be sure to perform the following procedure.
- Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- After removing/replacing a yaw rate/side/decel G sensor, be sure to perform the following procedure.
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

VDC WARNING LAMP

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

VDC WARNING LAMP

Description

INFOID:000000007544770

×: ON Δ: Blink -: OFF

| Condition | VDC warning lamp |
|--|------------------|
| Ignition switch OFF | - |
| For 2 seconds after turning ignition switch ON | × |
| 2 seconds later after turning ignition switch ON | - |
| VDC/TCS is activated while driving. | Δ |
| VDC/TCS function is malfunctioning. | × |
| ABS function is malfunctioning. | × |
| EBD function is malfunctioning. | × |

Component Function Check

INFOID:000000007544771

1. CHECK VDC WARNING LAMP OPERATION

Check that the lamp illuminates for approximately 2 seconds after the ignition switch is turned ON.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Proceed to diagnosis procedure. Refer to [BRC-99, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000007544772

1. PERFORM SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT.

Is the inspection result normal?

YES >> Check the combination meter. Refer to [MWI-35, "CONSULT Function \(METER/M&A\)"](#).

NO >> Check items displayed by self-diagnosis for "ABS" with CONSULT.

Special Repair Requirement

INFOID:000000007804906

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

- After replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
- Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing/replacing a steering angle sensor, be sure to perform the following procedure.
- Adjustment of steering angle sensor neutral position: Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- After removing/replacing a yaw rate/side/decel G sensor, be sure to perform the following procedure.
- Calibration of decel G sensor: Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

VDC OFF INDICATOR LAMP

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

VDC OFF INDICATOR LAMP

Description

INFOID:000000007544767

×: ON –: OFF

| Condition | VDC OFF indicator lamp |
|--|------------------------|
| Ignition switch OFF | – |
| For 2 seconds after turning ignition switch ON | × |
| 2 seconds later after turning ignition switch ON | – |
| VDC OFF switch turned ON. (VDC function is OFF.) | × |
| VDC/TCS function is malfunctioning. | – |
| ABS function is malfunctioning. | – |
| EBD function is malfunctioning. | – |

Component Function Check

INFOID:000000007544768

1.VDC OFF INDICATOR LAMP OPERATION CHECK 1

Check that the lamp illuminates for approximately 2 seconds after the ignition switch is turned ON.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Proceed to diagnosis procedure. Refer to [BRC-100, "Diagnosis Procedure"](#).

2.VDC OFF INDICATOR LAMP OPERATION CHECK 2

Check that the VDC OFF indicator lamp in the combination meter turns ON/OFF correctly when operating the VDC OFF switch.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Check the VDC OFF switch. Refer to [BRC-94, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000007544769

1.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT

Perform diagnosis of ABS actuator and electric unit (control unit) power supply and ground circuit. Refer to [BRC-89, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace error-detected parts.

2.CHECK VDC OFF INDICATOR LAMP SIGNAL (1)

1. Select "ABS", "DATA MONITOR" and "OFF LAMP" according to this order with CONSULT.
2. Turn the ignition switch OFF.
3. Check that data monitor displays "On" for approx. 1 second after ignition switch is turned ON, and then changes to "Off".

CAUTION:

Never start engine.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-125, "Exploded View"](#).

3.CHECK VDC OFF INDICATOR LAMP SIGNAL (2)

1. Select "ABS", "DATA MONITOR" and "OFF LAMP" according to this order with CONSULT.
2. Check that data monitor displays "On" or "Off" each time when VDC OFF switch is operated.

Is the inspection result normal?

YES >> Check the combination meter. Refer to [MWI-34, "Diagnosis Description"](#).

VDC OFF INDICATOR LAMP

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

NO >> Check the VDC OFF switch system. Refer to [BRC-94. "Diagnosis Procedure"](#).

Special Repair Requirement

INFOID:000000007804907

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION AND CALIBRATION OF DECEL G SENSOR

- After replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
- Adjustment of steering angle sensor neutral position: Refer to [BRC-9. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
- Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).
- After removing/replacing a steering angle sensor, be sure to perform the following procedure.
- Adjustment of steering angle sensor neutral position: Refer to [BRC-9. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
- After removing/replacing a yaw rate/side/decel G sensor, be sure to perform the following procedure.
- Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).

>> END

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

ECU DIAGNOSIS INFORMATION

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Reference Value

INFOID:000000007544773

VALUES ON THE DIAGNOSIS TOOL

CAUTION:

The display shows the control unit calculation data, so a normal value might be displayed even in the event the output circuit (harness) is open or short-circuited.

| Monitor item | Display content | Data monitor | |
|---------------|---|---|--|
| | | Condition | Reference value in normal operation |
| FR LH SENSOR | Wheel speed | Vehicle stopped | 0 [km/h (MPH)] |
| | | Vehicle running (Note 1) | Nearly matches the speedometer display ($\pm 10\%$ or less) |
| FR RH SENSOR | Wheel speed | Vehicle stopped | 0 [km/h (MPH)] |
| | | Vehicle running (Note 1) | Nearly matches the speedometer display ($\pm 10\%$ or less) |
| RR LH SENSOR | Wheel speed | Vehicle stopped | 0 [km/h (MPH)] |
| | | Vehicle running (Note 1) | Nearly matches the speedometer display ($\pm 10\%$ or less) |
| RR RH SENSOR | Wheel speed | Vehicle stopped | 0 [km/h (MPH)] |
| | | Vehicle running (Note 1) | Nearly matches the speedometer display ($\pm 10\%$ or less) |
| STOP LAMP SW | Brake pedal operation | When brake pedal is depressed | On |
| | | When brake pedal is not depressed | Off |
| BATTERY VOLT | Battery voltage supplied to the ABS actuator and electric unit (control unit) | Ignition switch ON | 10 – 16 V |
| GEAR | Gear position | Vehicle running | 1 – 6 |
| R POSI SIG | Select shift position | CVT shift position (R) | On |
| | | CVT shift position (other R) | Off |
| N POSI SIG | Select shift position | CVT shift position (N) | On |
| | | CVT shift position (other N) | Off |
| P POSI SIG | Select shift position | CVT shift position (P) | On |
| | | CVT shift position (other P) | Off |
| SLCT LVR POSI | Select shift position | CVT shift position (P, R, N, D, L) | P R N D L |
| | | Manual mode | ## |
| OFF SW | VDC OFF switch ON/OFF status | VDC OFF switch ON (When VDC OFF indicator lamp is ON) | On |
| | | VDC OFF switch OFF (When VDC OFF indicator lamp is OFF) | Off |
| YAW RATE SEN | Yaw rate detected by yaw rate/side/decel sensor | Vehicle stopped | Approx. 0 d/s |
| | | Vehicle running | -100 to 100 d/s |

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

| Monitor item | Display content | Data monitor | |
|------------------------|--|---|--|
| | | Condition | Reference value in normal operation |
| DECEL G-SEN | Decel G detected by yaw rate/side/decel G sensor | Vehicle stopped | Approx. 0 G |
| | | Vehicle running | -1.7 – +1.7 G |
| ACCEL POS SIG | Open/Close condition of throttle valve (Linked with accelerator pedal) | Accelerator pedal not depressed (Engine stopped) | 0 % |
| | | Depress accelerator pedal (Engine stopped) | 0 - 100 % |
| SIDE G-SENSOR | Transverse G detected by yaw rate/side/decel G sensor | Vehicle stopped | Approx. 0 m/s ² |
| | | Vehicle running | - 16.7 – 16.7 m/s ² |
| STR ANGLE SIG | Steering angle detected by steering angle sensor | Driving straight | -3.5 – +3.5° |
| | | Turn 90 ° to right | Approx. +90 ° |
| | | Turn 90 ° to left | Approx. -90 ° |
| ENGINE RPM | With engine running | With engine stopped | 0 [tr/min (rpm)] |
| | | Engine running | Almost in accordance with tachometer display |
| FLUID LEV SW | Brake fluid level switch signal status | When brake fluid level switch ON | On |
| | | When brake fluid level switch OFF | Off |
| PRESS SENSOR | Brake fluid pressure detected by pressure sensor | With ignition switch ON and brake pedal released | Approx. 0 bar |
| | | With ignition switch ON and brake pedal depressed | 0 – 170 bar |
| FR RH IN SOL (Note 2) | Operation status of front RH ABS IN valve | Actuator (ABS IN valve) is active ("ACTIVE TEST" in "ABS" with CONSULT) | On |
| | | When the actuator (ABS IN valve) is not active and actuator relay is active (ignition switch ON) | Off |
| FR RH OUT SOL (Note 2) | Operation status of front RH ABS OUT valve | Actuator (ABS OUT valve) is active ("ACTIVE TEST" in "ABS" with CONSULT) | On |
| | | When the actuator (ABS OUT valve) is not active and actuator relay is active (ignition switch ON) | Off |
| FR LH IN SOL (Note 2) | Operation status of front LH ABS IN valve | Actuator (ABS IN valve) is active ("ACTIVE TEST" in "ABS" with CONSULT) | On |
| | | When the actuator (ABS IN valve) is not active and actuator relay is active (ignition switch ON) | Off |
| FR LH OUT SOL (Note 2) | Operation status of front LH ABS OUT valve | Actuator (ABS OUT valve) is active ("ACTIVE TEST" in "ABS" with CONSULT) | On |
| | | When the actuator (ABS OUT valve) is not active and actuator relay is active (ignition switch ON) | Off |
| RR RH IN SOL (Note 2) | Operation status of rear RH ABS IN valve | Actuator (ABS IN valve) is active ("ACTIVE TEST" in "ABS" with CONSULT) | On |
| | | When the actuator (ABS IN valve) is not active and actuator relay is active (ignition switch ON) | Off |

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

| Monitor item | Display content | Data monitor | |
|---------------------------|---|---|-------------------------------------|
| | | Condition | Reference value in normal operation |
| RR RH OUT SOL (Note 2) | Operation status of rear RH ABS OUT valve | Actuator (ABS OUT valve) is active ("ACTIVE TEST" in "ABS" with CONSULT) | On |
| | | When the actuator (ABS OUT valve) is not active and actuator relay is active (ignition switch ON) | Off |
| RR LH IN SOL (Note 2) | Operation status of rear LH ABS IN valve | Actuator (ABS IN valve) is active ("ACTIVE TEST" in "ABS" with CONSULT) | On |
| | | When the actuator (ABS IN valve) is not active and actuator relay is active (ignition switch ON) | Off |
| RR LH OUT SOL (Note 2) | Operation status of rear LH ABS OUT valve | Actuator (ABS OUT valve) is active ("ACTIVE TEST" in "ABS" with CONSULT) | On |
| | | When the actuator (ABS OUT valve) is not active and actuator relay is active (ignition switch ON) | Off |
| MOTOR RELAY | Motor and motor relay operation | Ignition switch ON or engine running (ABS operated) | On |
| | | Ignition switch ON or engine running (ABS not operated) | Off |
| ACTUATOR RLY (Note 2) | Actuator relay operation | Vehicle stopped (Engine running) | On |
| | | Vehicle stopped (Ignition switch ON) | Off |
| ABS WARN LAMP | ABS warning lamp (Note 3) | When ABS warning lamp is ON | On |
| | | When ABS warning lamp is OFF | Off |
| OFF LAMP | VDC OFF indicator lamp (Note 3) | When VDC OFF indicator lamp is ON | On |
| | | When VDC OFF indicator lamp is OFF | Off |
| SLIP/VDC LAMP | VDC warning lamp (Note 3) | When VDC warning lamp is ON | On |
| | | When VDC warning lamp is blinking | |
| | | When VDC warning lamp is OFF | Off |
| CV1 | Operation status of cut valve 1 (CV1) | Actuator (cut valve 1) is active ("ACTIVE TEST" in "ABS" with CONSULT) | On |
| | | When the actuator (cut valve 1) is not active and actuator relay is active (ignition switch ON) | Off |
| CV2 | Operation status of cut valve 2 (CV2) | Actuator (cut valve 2) is active ("ACTIVE TEST" in "ABS" with CONSULT) | On |
| | | When the actuator (cut valve 2) is not active and actuator relay is active (ignition switch ON) | Off |
| SV1 | Operation status of suction valve 1 (SV1) | Actuator (suction valve 1) is active ("ACTIVE TEST" in "ABS" with CONSULT) | On |
| | | When the actuator (suction valve 1) is not active and actuator relay is active (ignition switch ON) | Off |

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

| Monitor item | Display content | Data monitor | |
|---------------|---|---|-------------------------------------|
| | | Condition | Reference value in normal operation |
| SV2 | Operation status of suction valve 2 (SV2) | Actuator (suction valve 2) is active ("ACTIVE TEST" in "ABS" with CONSULT) | On |
| | | When the actuator (suction valve 2) is not active and actuator relay is active (ignition switch ON) | Off |
| EBD SIGNAL | EBD operation | EBD is active | On |
| | | EBD is inactive | Off |
| ABS SIGNAL | ABS operation | ABS is active | On |
| | | ABS is inactive | Off |
| TCS SIGNAL | TCS operation | TCS is active | On |
| | | TCS is inactive | Off |
| VDC SIGNAL | VDC operation | VDC is active | On |
| | | VDC is inactive | Off |
| EBD FAIL SIG | EBD fail-safe signal | In EBD fail-safe | On |
| | | EBD is normal | Off |
| ABS FAIL SIG | ABS fail-safe signal | In ABS fail-safe | On |
| | | ABS is normal | Off |
| TCS FAIL SIG | TCS fail-safe signal | In TCS fail-safe | On |
| | | TCS is normal | Off |
| VDC FAIL SIG | VDC fail-safe signal | In VDC fail-safe | On |
| | | VDC is normal | Off |
| EBD WARN LAMP | Brake warning lamp (Note 3) | When brake warning lamp is ON | On |
| | | When brake warning lamp is OFF | Off |
| CRANKING SIG | Crank operation | Crank is active | On |
| | | Crank is inactive | Off |
| 4WD FAIL REQ | ETS fail status | ETS fail | On |
| | | ETS normal | Off |
| 2WD/4WD | Drive axle | 2WD model | 2WD |
| | | AWD model | 4WD |

NOTE:

- 1: Confirm tire pressure is normal.
- 2: A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is a operation for checking.
- 3: On and off timing for warning lamp and indicator lamp.
 - ABS warning lamp: Refer to [BRC-96, "Description"](#).
 - Brake warning lamp: Refer to [BRC-97, "Description"](#).
 - VDC warning lamp: Refer to [BRC-99, "Description"](#).
 - VDC OFF indicator lamp: Refer to [BRC-100, "Description"](#).

Wiring Diagram -BRAKE CONTROL SYSTEM-


INFOID:000000007544774

For connector terminal arrangements, harness layouts, and alphabets in a (option abbreviation; if not described in wiring diagram), refer to [GI-12, "Connector Information"](#).

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]



2011/07/28

JRFWC0089GB

Fail-Safe

INFOID:000000007544775

ABS, EBD SYSTEM

If ABS malfunction electrically, ABS warning lamp and VDC warning lamp will turn ON. If EBD malfunction electrically, brake warning lamp, ABS warning lamp and VDC warning lamp will turn ON. Simultaneously, the VDC/TCS/ABS become one of the following conditions of the fail-safe function.

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

- For malfunction of ABS, only the EBD is activated and the condition of vehicle is the same condition of vehicles without TCS/ABS system.

NOTE:

ABS self-diagnosis sound may be heard. That is a normal condition because a self-diagnosis for "Ignition switch ON" and "The first starting" are being performed.

- For malfunction of EBD, EBD and ABS become inoperative, and the condition of vehicle is the same as the condition of vehicles without TCS/ABS, EBD system.

VDC/TCS

If VDC/TCS/ABS system malfunction electrically, VDC warning lamp are turned on, and the condition of vehicle is the same as the condition of vehicles without VDC/TCS control.

CAUTION:

If the Fail-Safe function is activated, then perform self-diagnosis for "ABS" with CONSULT.

DTC No. Index

INFOID:000000007544776

| DTC | Items (CONSULT screen terms) | Reference |
|-------|------------------------------|-------------------------------------|
| C1101 | RR RH SENSOR-1 | BRC-33, "DTC Logic" |
| C1102 | RR LH SENSOR-1 | |
| C1103 | FR RH SENSOR-1 | |
| C1104 | FR LH SENSOR-1 | |
| C1105 | RR RH SENSOR-2 | BRC-37, "DTC Logic" |
| C1106 | RR LH SENSOR-2 | |
| C1107 | FR RH SENSOR-2 | |
| C1108 | FR LH SENSOR-2 | BRC-42, "DTC Logic" |
| C1109 | BATTERY VOLTAGE [ABNORMAL] | |
| C1110 | CONTROLLER FAILURE | BRC-44, "DTC Logic" |
| C1111 | PUMP MOTOR | BRC-45, "DTC Logic" |
| C1113 | G SENSOR | BRC-47, "DTC Logic" |
| C1115 | ABS SENSOR [ABNORMAL SIGNAL] | BRC-50, "DTC Logic" |
| C1116 | STOP LAMP SW | BRC-56, "DTC Logic" |
| C1120 | FR LH IN ABS SOL | BRC-58, "DTC Logic" |
| C1121 | FR LH OUT ABS SOL | BRC-60, "DTC Logic" |
| C1122 | FR RH IN ABS SOL | BRC-58, "DTC Logic" |
| C1123 | FR RH OUT ABS SOL | BRC-60, "DTC Logic" |
| C1124 | RR LH IN ABS SOL | BRC-58, "DTC Logic" |
| C1125 | RR LH OUT ABS SOL | BRC-60, "DTC Logic" |
| C1126 | RR RH IN ABS SOL | BRC-58, "DTC Logic" |
| C1127 | RR RH OUT ABS SOL | BRC-60, "DTC Logic" |
| C1130 | ENGINE SIGNAL 1 | BRC-62, "DTC Logic" |
| C1140 | ACTUATOR RLY | BRC-64, "DTC Logic" |
| C1142 | PRESS SEN CIRCUIT | BRC-66, "DTC Logic" |
| C1143 | ST ANG SEN CIRCUIT | BRC-68, "DTC Logic" |
| C1144 | ST ANG SEN SIGNAL | BRC-71, "DTC Logic" |
| C1145 | YAW RATE SENSOR | BRC-47, "DTC Logic" |
| C1146 | SIDE G-SEN CIRCUIT | |
| C1155 | BR FLUID LEVEL LOW | BRC-73, "DTC Logic" |
| C1160 | DECEL G SEN SET | BRC-77, "DTC Logic" |
| C1161 | SIDE G SEN SET | BRC-79, "DTC Logic" |

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

| DTC | Items (CONSULT screen terms) | Reference |
|-------|------------------------------|-------------------------------------|
| C1162 | PRESS SEN SET | BRC-80, "DTC Logic" |
| C1164 | CV1 | BRC-81, "DTC Logic" |
| C1165 | CV2 | |
| C1166 | SV1 | BRC-83, "DTC Logic" |
| C1167 | SV2 | |
| U1000 | CAN COMM CIRCUIT | BRC-85, "DTC Logic" |
| U1002 | SYSTEM COMM (CAN) | BRC-87, "DTC Logic" |

EXCESSIVE ABS FUNCTION OPERATION FREQUENCY

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

SYMPTOM DIAGNOSIS

EXCESSIVE ABS FUNCTION OPERATION FREQUENCY

Diagnosis Procedure

INFOID:000000007544777

1. CHECK START

Check the front and rear brake force distribution using a brake tester. Refer to [BR-52, "General Specifications"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check the brake system.

2. CHECK FRONT AND REAR AXLE

Make sure that there is no excessive play in the front and rear axles.

• Front

- 2WD: Refer to [FAX-8, "Inspection"](#).

- AWD: Refer to [FAX-34, "Inspection"](#).

• Rear

- 2WD: Refer to [RAX-4, "Inspection"](#).

- AWD: Refer to [RAX-11, "Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace error-detected parts.

3. CHECK WHEEL SENSOR AND SENSOR ROTOR

Check the following.

• Wheel sensor installation for damage.

- Front wheel sensor: Refer to [BRC-121, "FRONT WHEEL SENSOR : Exploded View"](#).

- Rear wheel sensor: Refer to [BRC-122, "REAR WHEEL SENSOR : Exploded View"](#).

• Wheel sensor connector connection.

• Wheel sensor harness inspection.

• Sensor rotor installation for damage.

- Front sensor rotor: Refer to [BRC-124, "FRONT SENSOR ROTOR : Exploded View"](#).

- Rear sensor rotor: Refer to [BRC-124, "REAR SENSOR ROTOR : Exploded View"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace wheel sensor or sensor rotor.

• Front wheel sensor: Refer to [BRC-121, "FRONT WHEEL SENSOR : Exploded View"](#).

• Rear wheel sensor: Refer to [BRC-122, "REAR WHEEL SENSOR : Exploded View"](#).

• Front sensor rotor: Refer to [BRC-124, "FRONT SENSOR ROTOR : Exploded View"](#).

• Rear sensor rotor: Refer to [BRC-124, "REAR SENSOR ROTOR : Exploded View"](#).

4. CHECK ABS WARNING LAMP DISPLAY

Make sure that the ABS warning lamp is turned off after the ignition switch is turned ON or when driving.

Is the inspection result normal?

YES >> Normal

NO >> Perform self-diagnosis for "ABS" with CONSULT.

UNEXPECTED PEDAL REACTION

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

UNEXPECTED PEDAL REACTION

Diagnosis Procedure

INFOID:000000007544778

1.CHECK BRAKE PEDAL, BRAKE BOOSTER, BRAKE MASTER CYLINDER

Check the brake pedal, brake booster, brake master cylinder mounting condition.

- Brake pedal: Refer to [BR-19, "Exploded View"](#).
- Brake booster: Refer to [BR-29, "Exploded View"](#).
- Brake master cylinder: Refer to [BR-26, "Exploded View"](#).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair or replace error-detected parts.

2.CHECK BRAKE PEDAL STROKE

Check the brake pedal stroke. Refer to [BR-8, "Inspection and Adjustment"](#).

Is the stroke too large?

- YES >> Bleed air from brake tube and hose. Refer to [BR-12, "Bleeding Brake System"](#).
- NO >> GO TO 3.

3.CHECK FUNCTION

Disconnect ABS actuator and electric unit (control unit) harness connector to deactivate ABS. Check if braking force is normal in this condition. Connect harness connector after inspection.

Is the inspection result normal?

- YES >> Normal
- NO >> Check brake system.

THE BRAKING DISTANCE IS LONG

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

THE BRAKING DISTANCE IS LONG

Diagnosis Procedure

INFOID:000000007544779

CAUTION:

The stopping distance on slippery road surfaces might be longer with the ABS operating than when the ABS is not operating.

1.CHECK FUNCTION

Turn the ignition switch OFF and disconnect ABS actuator and electric unit (control unit) harness connector to deactivate ABS. In this condition, check the stopping distance. After inspection, connect connector.

Is the inspection result normal?

YES >> Normal

NO >> Check brake system.

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P

ABS FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

ABS FUNCTION DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000007544780

CAUTION:

ABS does not operate when speed is 10 km/h (6 MPH) or lower.

1.CHECK ABS WARNING LAMP DISPLAY

Make sure that the ABS warning lamp turns OFF after ignition switch is turned ON or when driving.

Is the inspection result normal?

YES >> Normal

NO >> Perform self-diagnosis for "ABS" with CONSULT.

PEDAL VIBRATION OR ABS OPERATION SOUND OCCURS

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

PEDAL VIBRATION OR ABS OPERATION SOUND OCCURS

Diagnosis Procedure

INFOID:000000007544781

CAUTION:

Under the following conditions, ABS is activated and vibration is felt when brake pedal is lightly depressed (just place a foot on it). However, this is normal.

- When shifting gears
- When driving on slippery road
- During cornering at high speed
- When passing over bumps or grooves [at approximately 50 mm (1.97 in) or more]
- When pulling away just after starting engine [at approximately 10 km/h (6 MPH) or higher]

1. SYMPTOM CHECK 1

Check that there are pedal vibrations when the engine is started.

Do vibrations occur?

YES >> GO TO 2.

NO >> Inspect the brake pedal. Refer to [BR-20, "Inspection and Adjustment"](#).

2. SYMPTOM CHECK 2

Check that there are ABS operation noises when the engine is started.

Do the operation noises occur?

YES >> GO TO 3.

NO >> Perform self-diagnosis for "ABS" with CONSULT.

3. SYMPTOM CHECK 3

Check symptoms when electrical component (headlamps, etc.) switches are operated.

Do symptoms occur?

YES >> Check if there is a radio, antenna, antenna lead wire, or wiring close to the control unit. If there is, move it farther away.

NO >> Normal

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

BRC

VEHICLE JERKS DURING VDC/TCS/ABS CONTROL

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

VEHICLE JERKS DURING VDC/TCS/ABS CONTROL

Diagnosis Procedure

INFOID:000000007544782

1. SYMPTOM CHECK

Check if the vehicle jerks during VDC/TCS/ABS control.

Is the inspection result normal?

- YES >> Normal.
- NO >> GO TO 2.

2. PERFORM SELF-DIAGNOSIS (1)

Perform self-diagnosis for "ABS" with CONSULT.

Are self-diagnosis results indicated?

- YES >> Check the corresponding items, make repairs, and perform self-diagnosis for "ABS" with CONSULT.
- NO >> GO TO 3.

3. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Check the terminal for deformation, disconnection, looseness, etc.
4. Securely connect harness connectors and perform self-diagnosis for "ABS" with CONSULT.

Are self-diagnosis results indicated?

- YES >> If poor contact, damage, open or short circuit of connector terminal is found, repair or replace.
- NO >> GO TO 4.

4. PERFORM SELF-DIAGNOSIS (2)

Perform self-diagnosis for "ENGINE" and "TRANSMISSION" with CONSULT.

Are self-diagnosis results indicated?

- YES >> Check the corresponding items.
- NO >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-125. "Exploded View"](#).

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

NORMAL OPERATING CONDITION

Description

INFOID:000000007544783

| Symptom | Result |
|---|---|
| Slight vibrations are felt on the brake pedal and the operation noises occur, when VDC, TCS or ABS is activated. | This is a normal condition due to the VDC, TCS or ABS activation. |
| Stopping distance is longer than that of vehicles without ABS when the vehicle drives on rough, gravel, or snow-covered (fresh, deep snow) roads. | |
| The brake pedal moves and generates noises, when TCS or VDC is activated due to rapid acceleration or sharp turn. | |
| The brake pedal vibrates and motor operation noises occur from the engine room, after the engine starts and just after the vehicle starts. | This is a normal, and it is caused by the ABS operation check. |
| Depending on the road conditions, the driver may experience a sluggish feel. | This is normal, because TCS places the highest priority on the optimum traction (stability). |
| TCS may activate momentarily if wheel speed changes when driving over location where friction coefficient varies, when downshifting, or when fully depressing accelerator pedal. | |
| The ABS warning lamp and VDC warning lamp may turn ON when the vehicle is subject to strong shaking or large vibration, such as when the vehicle is rotating on a turntable or located on a ship while the engine is running. | In this case, restart the engine on a normal road. If the normal condition is restored, there is no malfunction. At that time, erase the self-diagnosis memory. |
| VDC may not operate normally or the ABS warning lamp and VDC warning lamp may illuminate, when running on a special road that is extremely slanted (e.g. bank in a circuit course). | |
| A malfunction may occur in the yaw rate/side G sensor system, when the vehicle turns sharply, such as during a spin turn, axle turn, or drift driving, while the VDC function is off (VDC warning lamp illuminated). | |
| The vehicle speed will not increase even though the accelerator pedal is depressed, when inspecting the speedometer on a 2-wheel chassis dynamometer. | Normal (Deactivate the VDC/TCS function before performing an inspection on a chassis dynamometer.) |

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

PRECAUTION

PRECAUTIONS
FOR USA AND CANADA

FOR USA AND CANADA : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000007804772

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:


Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

FOR USA AND CANADA : Precaution for Procedure without Cowl Top Cover

INFOID:000000007804774

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc to prevent damage to windshield.



FOR USA AND CANADA : Precaution for Brake System

INFOID:000000007544786

WARNING:

Since dust covering the front and rear brakes has an affect on human body, the dust must be removed with a dust collector. Never splatter the dust with an air blow gun.

CAUTION:


- Brake fluid use refer to [MA-16, "FOR NORTH AMERICA : Fluids and Lubricants"](#).
- Never reuse drained brake fluid.

PRECAUTIONS

< PRECAUTION >

[VDC/TCS/ABS]

- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface.
- Never use mineral oils such as gasoline or light oil to clean. They may damage rubber parts and cause improper operation.
- Always loosen the brake tube flare nut with a flare nut wrench.
- Tighten the brake tube flare nut to the specified torque with crowfoot (A) and torque wrench (B).
- Always confirm the specified tightening torque when installing the brake pipes.
- Turn the ignition switch OFF and disconnect the ABS actuator and electric unit (control unit) harness connector or the battery negative terminal before performing the work.
- Check that no brake fluid leakage is present after replacing the parts.



FOR USA AND CANADA : Precaution for Brake Control


INFOID:000000007544787

- When starting engine or when starting vehicle just after starting engine, brake pedal may vibrate or motor operating noise may be heard from engine compartment. This is normal condition.
- When an error is indicated by ABS or another warning lamp, collect all necessary information from customer (what symptoms are present under what conditions) and check for estimate causes before starting diagnostic servicing. Besides electrical system inspection, check the brake booster operation, brake fluid level, and oil leaks.
- If tire size and type are used in an improper combination, or brake pads are not Genuine NISSAN parts, stopping distance or steering stability may deteriorate.
- ABS might be out of order or malfunctions by putting a radio (wiring inclusive), an antenna and a lead-in wire near the control unit.
- VDC system may not operate normally or a VDC warning lamp may light.
- When replacing the following parts with parts other than genuine parts or making modifications: Suspension-related parts (shock absorber, spring, bushing, etc.), tires, wheels (other than specified sizes), brake-related parts (pad, rotor, caliper, etc.), engine-related parts (muffler, ECM, etc.) and body reinforcement-related parts (roll bar, tower bar, etc.).
- When driving with worn or deteriorated suspension, tires and brake-related parts.

FOR USA AND CANADA : Precaution for Harness Repair

INFOID:000000007805041

- Solder the repair part, and wrap it with tape. [Twisted wire fray must be 110 mm (4.33 in) or less.]




PRECAUTIONS

[VDC/TCS/ABS]

< PRECAUTION >

- Never bypass the repair point with wire. (If it is bypassed, the turn-out point cannot be separated and the twisted wire characteristics are lost.)



FOR MEXICO

FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000007804773

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:


Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

FOR MEXICO : Precaution for Procedure without Cowl Top Cover

INFOID:000000007804775

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc to prevent damage to windshield.



FOR MEXICO : Precaution for Brake System

INFOID:000000007544790

WARNING:

PRECAUTIONS


< PRECAUTION >

[VDC/TCS/ABS]

Since dust covering the front and rear brakes has an affect on human body, the dust must be removed with a dust collector. Never splatter the dust with an air blow gun.

CAUTION:

- Brake fluid use refer to [MA-17, "FOR MEXICO : Fluids and Lubricants"](#).
- Never reuse drained brake fluid.
- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface.
- Never use mineral oils such as gasoline or light oil to clean. They may damage rubber parts and cause improper operation.
- Always loosen the brake tube flare nut with a flare nut wrench.
- Tighten the brake tube flare nut to the specified torque with crowfoot (A) and torque wrench (B).
- Always confirm the specified tightening torque when installing the brake pipes.
- Turn the ignition switch OFF and disconnect the ABS actuator and electric unit (control unit) harness connector or the battery negative terminal before performing the work.
- Check that no brake fluid leakage is present after replacing the parts.



FOR MEXICO : Precaution for Brake Control


INFOID:000000007544791

- When starting engine or when starting vehicle just after starting engine, brake pedal may vibrate or motor operating noise may be heard from engine compartment. This is normal condition.
- When an error is indicated by ABS or another warning lamp, collect all necessary information from customer (what symptoms are present under what conditions) and check for estimate causes before starting diagnostic servicing. Besides electrical system inspection, Check the brake booster operation, brake fluid level, and oil leaks.
- If tire size and type are used in an improper combination, or brake pads are not Genuine NISSAN parts, stopping distance or steering stability may deteriorate.
- ABS might be out of order or malfunctions by putting a radio (wiring inclusive), an antenna and a lead-in wire near the control unit.
- VDC system may not operate normally or a VDC warning lamp may light.
- When replacing the following parts with parts other than genuine parts or making modifications: Suspension-related parts (shock absorber, spring, bushing, etc.), tires, wheels (other than specified sizes), brake-related parts (pad, rotor, caliper, etc.), engine-related parts (muffler, ECM, etc.) and body reinforcement-related parts (roll bar, tower bar, etc.).
- When driving with worn or deteriorated suspension, tires and brake-related parts.

FOR MEXICO : Precaution for Harness Repair

INFOID:000000007805042

- Solder the repair part, and wrap it with tape. [Twisted wire fray must be 110 mm (4.33 in) or less.]




PRECAUTIONS

[VDC/TCS/ABS]

< PRECAUTION >

- Never bypass the repair point with wire. (If it is bypassed, the turn-out point cannot be separated and the twisted wire characteristics are lost.)




REMOVAL AND INSTALLATION

WHEEL SENSOR

FRONT WHEEL SENSOR

FRONT WHEEL SENSOR : Exploded View

INFOID:000000007544792



1. Front LH wheel sensor harness connector 2. Front LH wheel sensor

B. Color line (slant line)

← : Vehicle front

Refer to [GI-4, "Components"](#) for symbol in the figure.

NOTE:

The above figure (front side) shows left side. Right side is the mirror image.

FRONT WHEEL SENSOR : Removal and Installation

INFOID:000000007544793

REMOVAL

Be careful with the following when removing sensor.

CAUTION:

- **Never twist sensor harness as much as possible, when removing it. Pull sensors out without pulling sensor harness.**
- **Be careful to avoid damaging sensor edges or rotor teeth. Remove wheel sensor first before removing front or rear wheel hub. This is to avoid damage to sensor wiring and loss of sensor function.**
- **When you see the harness of the wheel sensor from the front side of the vehicle ensure that the color lines (B) are not twisted.**

INSTALLATION

Be careful with the following when installing wheel sensor. Tighten installation bolts to the specified torques.

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

WHEEL SENSOR

[VDC/TCS/ABS]


< REMOVAL AND INSTALLATION >

- When installing, make sure there is no foreign material such as iron chips on and in the mounting hole of the wheel sensor. Make sure no foreign material has been caught in the sensor rotor. Remove any foreign material and clean the mount.
- When installing wheel sensor, be sure to press rubber grommets in until they lock at locations shown above in the figure. When installed, harness must not be twisted.

REAR WHEEL SENSOR

REAR WHEEL SENSOR : Exploded View

INFOID:000000007544794



1. Rear RH wheel sensor
2. Rear RH wheel sensor harness connector
3. Rear LH wheel sensor connector
4. Rear LH wheel sensor

B. AWD models only

C. Color line (slant line)

↔ : Vehicle front

Refer to [GI-4, "Components"](#) for symbol in the figure.

REAR WHEEL SENSOR : Removal and Installation

INFOID:000000007544795

REMOVAL

Be careful with the following when removing sensor.

CAUTION:

- **Never twist sensor harness as much as possible, when removing it. Pull sensors out without pulling sensor harness.**
- **Be careful to avoid damaging sensor edges or rotor teeth. Remove wheel sensor first before removing front or rear wheel hub. This is to avoid damage to sensor wiring and loss of sensor function.**

INSTALLATION

Be careful with the following when installing wheel sensor. Tighten installation bolts to the specified torques.

- When installing, make sure there is no foreign material such as iron chips on and in the mounting hole of the wheel sensor. Make sure no foreign material has been caught in the sensor rotor. Remove any foreign material and clean the mount.

WHEEL SENSOR

< REMOVAL AND INSTALLATION >

[VDC/TCS/ABS]

- When installing wheel sensor, be sure to press rubber grommets in until they lock at locations shown above in the figure. When installed, harness must not be twisted.

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P

SENSOR ROTOR

[VDC/TCS/ABS]

< REMOVAL AND INSTALLATION >

SENSOR ROTOR

FRONT SENSOR ROTOR

FRONT SENSOR ROTOR : Exploded View

INFOID:000000007544796

Refer to [FAX-10, "Exploded View"](#) (2WD), [FAX-36, "Exploded View"](#) (AWD).

FRONT SENSOR ROTOR : Removal and Installation

INFOID:000000007544797

REMOVAL

Sensor rotor cannot be disassembled. Remove the sensor rotor together with hub bearing assembly. Refer to [FAX-10, "Removal and Installation"](#) (2WD), [FAX-36, "Removal and Installation"](#) (AWD).

INSTALLATION

Sensor rotor cannot be disassembled. Install the sensor rotor together with hub bearing assembly. Refer to [FAX-10, "Removal and Installation"](#) (2WD), [FAX-36, "Removal and Installation"](#) (AWD).

REAR SENSOR ROTOR

REAR SENSOR ROTOR : Exploded View

INFOID:000000007544798

Refer to [RAX-5, "Exploded View"](#) (2WD), [RAX-13, "Exploded View"](#) (AWD).

REAR SENSOR ROTOR : Removal and Installation

INFOID:000000007544799

REMOVAL

Sensor rotor cannot be disassembled. Remove the sensor rotor together with hub bearing assembly. Refer to [RAX-5, "Removal and Installation"](#) (2WD), [RAX-13, "Removal and Installation"](#) (AWD).

INSTALLATION

Sensor rotor cannot be disassembled. Install the sensor rotor together with hub bearing assembly. Refer to [RAX-5, "Removal and Installation"](#) (2WD), [RAX-13, "Removal and Installation"](#) (AWD).

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)


< REMOVAL AND INSTALLATION >

[VDC/TCS/ABS]

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Exploded View

INFOID:000000007544800



A
B
C
D
E
G
H
I

BRC

J
K
L
M
N
O
P

1. ABS actuator and electric unit (control unit)
2. Bracket

- | | | |
|------------------------------|------------------------------|--|
| A. To rear RH brake caliper | B. To rear LH brake caliper | C. From master cylinder primary side |
| D. To front RH brake caliper | E. To front LH brake caliper | F. From master cylinder secondary side |

← Vehicle front

Refer to [GI-4, "Components"](#) for symbol in the figure.

Removal and Installation

INFOID:000000007544801

REMOVAL

CAUTION:

- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface.
- Before servicing, disconnect the battery cable from negative terminal.
- To remove brake tube, use a flare nut wrench to prevent flare nuts and brake tube from being damaged. To install, use flare nut crowfoot and torque wrench.
- Never apply excessive impact to ABS actuator and electric unit (control unit), such as dropping it.
- Never remove and install actuator by holding harness.

1. Remove cowl top. Refer to [EXT-20, "Exploded View"](#).
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Loosen brake tube flare nuts, then remove brake tubes from ABS actuator and electric unit (control unit).
4. Remove ABS actuator and electric unit (control unit) bracket mounting bolts.
5. Remove ABS actuator and electric unit (control unit) from vehicle.

INSTALLATION

Note the following, and install in the reverse order of removal.

- Before servicing, disconnect the battery cable from negative terminal.


ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

[VDC/TCS/ABS]

< REMOVAL AND INSTALLATION >

- To remove brake tube, use a flare nut wrench to prevent flare nuts and brake tube from being damaged. To install, use flare nut crowfoot and torque wrench.
 - Never apply excessive impact to ABS actuator and electric unit (control unit), such as dropping it.
 - Never remove and install actuator by holding harness.
 - After work is completed, bleed air from brake tube. Refer to [BR-12. "Bleeding Brake System"](#).
 - After installing harness connector in the ABS actuator and electric unit (control unit), make sure harness connector is securely locked.
 - After removing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
 - Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).
 - After replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
 - Adjustment of steering angle sensor neutral position: Refer to [BRC-9. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).
 - Calibration of decel G sensor: Refer to [BRC-10. "CALIBRATION OF DECEL G SENSOR : Description"](#).
- Install ABS actuator and electric unit (control unit) as per the following steps.

1. Temporarily tighten mounting bolt (1) because the bracket (2) is temporarily being hold.
2. Tighten mounting bolt (3) while holding the bracket.
3. Tighten mounting bolts to the specified torque in the order of (4), (1).



YAW RATE/SIDE/DECEL G SENSOR


< REMOVAL AND INSTALLATION >

[VDC/TCS/ABS]

YAW RATE/SIDE/DECEL G SENSOR

Exploded View

INFOID:000000007544802



1. Yaw rate/side/decel G sensor
2. Connector

←: Vehicle front

Refer to [GI-4, "Components"](#) for symbol in the figure.

Removal and Installation

INFOID:000000007544803

REMOVAL

CAUTION:

Never drop or strike yaw rate/side/decel G sensor, or never use power tool etc., because yaw rate/side/decel G sensor is sensitive to the impact.

1. Remove center console assembly. Refer to [IP-20, "Exploded View"](#).
2. Remove rear ventilator duct. Refer to [VTL-58, "REAR VENTILATOR DUCT 2 : Exploded View"](#) (without 7 inch display), [VTL-121, "REAR VENTILATOR DUCT 2 : Exploded View"](#) (with 7 inch display).
3. Disconnect yaw rate/side/decel G sensor harness connector.
4. Remove mounting nuts.
5. Remove yaw rate/side/decel G sensor.

INSTALLATION

Note the following, and install in the reverse order of removal.

- Never drop or strike yaw rate/side/decel G sensor, or never use power tool etc., because yaw rate/side/decel G sensor is sensitive to the impact.
- After removing/replacing a yaw rate/side/decel G sensor, be sure to perform the calibration of decel G sensor. Refer to [BRC-10, "CALIBRATION OF DECEL G SENSOR : Description"](#).

STEERING ANGLE SENSOR


< REMOVAL AND INSTALLATION >

[VDC/TCS/ABS]

STEERING ANGLE SENSOR

Exploded View

INFOID:000000007544804



1. Steering angle sensor

↔: Vehicle front

Removal and Installation

INFOID:000000007544805

REMOVAL

1. Remove spiral cable assembly. Refer to [SR-14, "Exploded View"](#).
2. Remove steering angle sensor from spiral cable assembly.

INSTALLATION

Note the following, and install in the reverse order of removal.

- Never reuse steering angle sensor.
- After removing/replacing a steering angle sensor, be sure to perform the adjustment of steering angle sensor neutral position. Refer to [BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

VDC OFF SWITCH

< REMOVAL AND INSTALLATION >

[VDC/TCS/ABS]

VDC OFF SWITCH

Removal and Installation

INFOID:000000007804824

REMOVAL

1. Remove lower instrument panel LH. Refer to [IP-12, "Exploded View"](#).
2. Remove VDC OFF switch.

INSTALLATION

Installation is the reverse order of removal.

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P