SECTION DAS B DRIVER ASSISTANCE SYSTEM C

CONTENTS

LDW

PRECAUTION6
PRECAUTIONS6
FOR USA AND CANADA
FOR MEXICO 7 FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" 7 FOR MEXICO : Precautions for Removing of Battery Terminal 7 FOR MEXICO : Precaution for LDW System Service 7
SYSTEM DESCRIPTION8
COMPONENT PARTS8Component Parts Location8Camera Control Unit9Combination Meter9Rear View Camera9Pump Control Unit10Air Pump11Washer Switching Solenoid Valve11Rear View Camera Washer Relay11Warning Systems Switch/Warning Systems ON11

OPERATION18Switch Name and Function18System Display and Warning18	F
HANDLING PRECAUTION 20 Precautions for Lane Departure Warning 20	G
DIAGNOSIS SYSTEM (CAMERA CONTROL UNIT)21	Н
CONSULT Function21	
ECU DIAGNOSIS INFORMATION25	I
CAMERA CONTROL UNIT	J
DTC Index	Κ
PUMP CONTROL UNIT	1
WIRING DIAGRAM34	L
DRIVER ASSISTANCE SYSTEMS	M
BASIC INSPECTION45	
DIAGNOSIS AND REPAIR WORK FLOW45 Work Flow45	N
PRE-INSPECTION FOR DIAGNOSIS47 Inspection Procedure47	DA
REAR VIEW CAMERA WASHER/AIR BLOW- ER FUNCTION INSPECTION48 Inspection Procedure48	Ρ
ACTION TEST	

D

Ε

ADDITIONAL SERVICE WHEN REPLACING CAMERA CONTROL UNIT		
Description		
CONFIGURATION (CAMERA CONTROL		
UNIT)		
Description		
work Procedure		
CALIBRATING CAMERA IMAGE (REAR VIEW CAMERA)53	5	
Description	6	
Work Procedure (Preparation)	;	
Work Procedure (Pager View Camera Calibration) 55		
Work Procedure (Target Mark Sample)	,	
DTC/CIRCUIT DIAGNOSIS 58	;	
C1A03 VEHICLE SPEED SENSOR 58	2	
DTC Logic	5	
Diagnosis Procedure	;	
C1A04 ABS/TCS/VDC SYSTEM 59)	
DTC Logic 59)	
Diagnosis Procedure 59	I	
C1A39 STEERING ANGLE SENSOR 60)	
DTC Logic 60)	
Diagnosis Procedure 60	1	
U0122 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)		
DTC Logic		
Diagnosis Procedure61		
U0416 ABS ACTUATOR AND ELECTRIC		
UNII (CONTROL UNII)		
DTC Logic	,	
	•	
UU428 STEERING ANGLE SENSOR	; ,	
Dic Logic 63 Diagnosis Procedure	5	
Description 64	, L	
DTC Logic	Ļ	
Diagnosis Procedure 64	Ļ	
U1010 CONTROL UNIT (CAN)	;	
Description 65	;	
DTC Logic 65	í	
Diagnosis Procedure65	j	
U111A REAR CAMERA IMAGE SIGNAL CIR-		
CUII	i	
Dio Logic	,	
Diagnosis i 10000016 00	'	

U1232 STEERING ANGLE SENSOR
U1305 CONFIG UNFINISH
U1308 REAR CAMERA
U1309 AIR PUMP
U130B REAR CAMERA
U1310 PUMP CONTROL UNIT
POWER SUPPLY AND GROUND CIRCUIT 74
CAMERA CONTROL UNIT
PUMP CONTROL UNIT
WARNING SYSTEMS SWITCH CIRCUIT 76 Component Function Check
WARNING SYSTEMS ON INDICATOR CIR- CUIT
REAR VIEW CAMERA WASHER RELAYCIRCUIT80Component Function Check80Diagnosis Procedure80Component Inspection81
WASHER SWITCHING SOLENOID VALVE CIRCUIT
REAR WASHER SWITCH INPUT SIGNAL CIRCUIT
WASHER LEVEL SWITCH SIGNAL CIRCUIT 86 Diagnosis Procedure

SYMPTOM DIAGNOSIS87
LDW SYSTEM SYMPTOMS
LANE DEPARTURE WARNING LAMP DOES NOT TURNED ON
LDW ON INDICATOR LAMP DOES NOT TURNED ON
THE SYSTEM OPERATES EVEN WHEN US- ING TURN SIGNAL 91 Description 91 Diagnosis Procedure 91
SYSTEM SETTINGS CANNOT BE TURNED ON/OFF ON THE NAVIGATION SCREEN92 Description
NORMAL OPERATING CONDITION93 Description93
REMOVAL AND INSTALLATION94
CAMERA CONTROL UNIT
REAR VIEW CAMERA
PUMP CONTROL UNIT
AIR PUMP
WASHER SWITCHING SOLENOID VALVE98 Exploded View
REAR VIEW CAMERA WASHER/AIR NOZ- ZLE & TUBE
WARNING SYSTEMS SWITCH101 Removal and Installation101 BSW
PRECAUTION102
PRECAUTIONS102

FOR USA AND CANADA10 FOR USA AND CANADA : Precaution for Supple- mental Restraint System (SRS) "AIR BAG" and	02 A
"SEAT BELT PRE-TENSIONER"	02 02 02
FOR USA AND CANADA : Precaution for BSW System Service	02 C
FOR MEXICO10	03
FOR MEXICO : Precaution for Supplemental Re- straint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	D 03
FOR MEXICO : Precautions for Removing of Bat- tery Terminal	03 E
SYSTEM DESCRIPTION	04 ⊨
Component Parts Location	0 4 D4
Camera Control Unit	05 G
BSW Indicator LH/RH10	05
Combination Meter10	05
Rear View Camera	06 ⊟ DZ
Air Pump	07
Washer Switching Solenoid Valve	07
Rear View Camera Washer Relay10 Warning Systems Switch/Warning Systems ON Indicator	08 [']
CVCTEM 4	J
System Description	09 na
Fail-Safe1	13 K
OPERATION1	16
Switch Name and Function1	16
System Display and Warning1	16
HANDLING PRECAUTION	18
CONSULT Function1	19 19 N
ECU DIAGNOSIS INFORMATION12	23
CAMERA CONTROL UNIT1	23 DAS
Reference Value	23
Fail-Sate	26 29 P
DTC Index	28 28
PUMP CONTROL UNIT1	30
Reference Value1	30
WIRING DIAGRAM1	32

DRIVER ASSISTANCE SYSTEMS 132 Wiring Diagram
BASIC INSPECTION143
DIAGNOSIS AND REPAIR WORK FLOW 143 Work Flow143
PRE-INSPECTION FOR DIAGNOSIS
ADDITIONAL SERVICE WHEN REPLACING
CAMERA CONTROL UNIT
Description
DTC/CIRCUIT DIAGNOSIS149
C1A03 VEHICLE SPEED SENSOR 149
DTC Logic
DTC Logic
Diagnosis Procedure150
C1A39 STEERING ANGLE SENSOR 151
DTC Logic151 Diagnosis Procedure151
U0122 ABS ACTUATOR AND ELECTRIC
UNIT (CONTROL UNIT)
DIC Logic
U0416 ABS ACTUATOR AND ELECTRIC
UNIT (CONTROL UNIT)
Diagnosis Procedure
U0428 STEERING ANGLE SENSOR 154
DTC Logic154
Diagnosis Procedure
U1000 CAN COMM CIRCUIT 155
Description
Diagnosis Procedure155
U1010 CONTROL UNIT (CAN) 156
Description
Diagnosis Procedure
U111A REAR CAMERA IMAGE SIGNAL CIR-
CUIT
DICLOGIC157 Diagnosis Procedure157

U1232 STEERING ANGLE SENSOR	159
DIC Logic Diagnosis Procedure	159 159
U1305 CONFIG UNFINISH	160
DTC Logic	160
Diagnosis Procedure	160
U1308 REAR CAMERA	161
DTC Logic	161
Diagnosis Procedure	161
U1309 AIR PUMP	162
DTC Logic	162
Diagnosis Procedure	162
U130B REAR CAMERA	163
DTC Logic	163
	105
U1310 PUMP CONTROL UNIT	164
DIC Logic	164 164
	104
POWER SUPPLY AND GROUND CIRCUIT	165
	165
CAMERA CONTROL UNIT : Diagnosis Procedure	165
PUMP CONTROL UNIT : Diagnosis Procedure	165 165
WARNING SYSTEMS SWITCH CIRCUIT	167
Component Function Check	167
Diagnosis Procedure	167
Component Inspection	168
WARNING SYSTEMS ON INDICATOR CIR-	
CUIT	169
Component Function Check	169
Component Inspection	169
	171
Component Function Check	171
Diagnosis Procedure	171
Component Inspection	172
WASHER SWITCHING SOLENOID VALVE	
Component Function Check	174 174
Diagnosis Procedure	174
REAR WASHER SWITCH INPUT SIGNAL	
CIRCUIT	176
Diagnosis Procedure	176
WASHER LEVEL SWITCH SIGNAL CIRCUIT.	177
Diagnosis Procedure	177

BLIND SPOT WARNING INDICATOR CIR-	
CUIT	5
Diagnosis Procedure178	
SYMPTOM DIAGNOSIS 180)
BSW SYSTEM SYMPTOMS180)
Symptom Table 180)
BSW WARNING LAMP DOES NOT TURNED	
ON	
Description182	
Diagnosis Procedure182	:
BSW ON INDICATOR DOES NOT TURNED	
ON	5
Description183	;
Diagnosis Procedure183	,
SYSTEM SETTINGS CANNOT BE TURNED	
ON/OFF ON THE NAVIGATION SCREEN 184	,
Description184	
Diagnosis Procedure184	
NORMAL OPERATING CONDITION	,
Description	,
REMOVAL AND INSTALLATION 186	;

BSW INDICATOR	
CAMERA CONTROL UNIT	
REAR VIEW CAMERA188Exploded View188Removal and Installation188	
PUMP CONTROL UNIT189Exploded View189Removal and Installation189	
AIR PUMP	
WASHER SWITCHING SOLENOID VALVE 191 Exploded View	
REAR VIEW CAMERA WASHER/AIR NOZ- ZLE & TUBE	
WARNING SYSTEMS SWITCH	

J

Κ

L

Μ

DAS

< PRECAUTION > PRECAUTION PRECAUTIONS FOR USA AND CANADA

FOR USA AND CANADA : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

FOR USA AND CANADA : Precautions for Removing of Battery Terminal INFOLD:00000010089128

 When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.
 NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

• For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch. **NOTE:**

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

• After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC. **NOTE:**

The removal of 12V battery may cause a DTC detection error.

FOR USA AND CANADA : Precaution for LDW System Service

INFOID:000000009723199

WARNING:

Be careful of traffic conditions and safety around the vehicle when performing road test.



DAS-6



PRECAUTIONS

CAUTION:

Never perform the active test while driving.

Never change LDW initial state ON ⇒ OFF without the consent of the customer.

FOR MEXICO

< PRECAUTION >

FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" INFOID:000000009723200

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

FOR MEXICO : Precautions for Removing of Battery Terminal

• When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds. NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may

occur. For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch. NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

 After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC. NOTE:

The removal of 12V battery may cause a DTC detection error.

FOR MEXICO : Precaution for LDW System Service

WARNING:

Be careful of traffic conditions and safety around the vehicle when performing road test. **CAUTION:**

- Never perform the active test while driving.
- Never change LDW initial state ON ⇒ OFF without the consent of the customer.



INFOID:000000009723201

INFOID:000000010089127

А

D

E

F

Н

L

M

Ν

DAS

< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION **COMPONENT PARTS**

Component Parts Location

INFOID:000000009723202

[LDW]



(A)

Luggage room LH B

Luggage room RH \bigcirc

Instrument lower panel LH E)

No.	Component	Function
1	ABS actuator and electric unit (con- trol unit)	Transmits the vehicle speed signal (wheel speed) to camera control unit via CAN commu- nication Refer to <u>BRC-12, "Component Parts Location"</u> for detailed installation location
2	Washer pump	Pumps washer fluid from washer tank Refer to <u>WW-18, "Component Parts Location"</u> for detailed installation location
3	Washer level switch	Transmits the washer level switch signal to camera control unit

Revision: 2013 August



COMPONENT PARTS

< SYSTEM DESCRIPTION >

No.	Component	Function
4	ECM	Transmits the engine status signal and engine coolant temperature signal to camera con- trol unit via CAN communication Refer to <u>EC-36</u> , " <u>Component Parts Location</u> " for detailed installation location
5	ВСМ	Transmits the turn indicator signal to camera control unit via CAN communication Refer to <u>BCS-9</u> , "Component Parts Location" for detailed installation location
6	Rear view camera washer relay	Refer to DAS-11, "Rear View Camera Washer Relay"
$\overline{\mathcal{O}}$	Pump control unit	Refer to DAS-10, "Pump Control Unit"
8	Air pump	Refer to DAS-11, "Air Pump"
9	Rear view camera	Refer to DAS-9, "Rear View Camera"
10	Washer switching solenoid valve	Refer to DAS-11, "Washer Switching Solenoid Valve"
(11)	Camera control unit	Refer to DAS-9, "Camera Control Unit"
(12)	Combination meter	 Description: <u>DAS-9</u>, "Combination Meter" System display and warning: <u>DAS-18</u>, "System Display and Warning"
13	Steering angle sensor	Transmits the steering angle sensor signal to camera control unit via CAN communication
14)	Warning systems switch	Refer to DAS-11, "Warning Systems Switch/Warning Systems ON Indicator"
(15)	Warning systems ON indicator (On the warning systems switch)	Refer to DAS-11, "Warning Systems Switch/Warning Systems ON Indicator"
16	A/C auto amp.	Transmits the ambient sensor signal to camera control unit via CAN communication Refer to <u>HAC-150</u> , "Component Part Location" for detailed installation location
17	AV control unit	Transmits the system selection signal to camera control unit via CAN communication Refer to <u>AV-303, "Component Parts Location"</u> for detailed installation location

Camera Control Unit

- Camera control unit is installed in the luggage room RH.
- The adoption of CAN communication allows the signal transmission/reception between the camera control unit and each control unit.
- When the ignition switch is turned ON, electric power is supplied to the rear view camera.
- The camera control unit receives a camera image signal from the rear view camera and recognizes the lane that the own vehicle is currently traveling.
- When the own vehicle is almost deviated from the lane, the lane departure warning lamp on the combination meter blinks to warn the driver.
- The camera control unit communicates with the rear view camera via serial communication and receives the specific information of the camera. When the information matches the specific information of the camera written in the camera control unit, camera is activated normally.

Combination Meter

- Receives lane departure warning lamp signal, LDW ON indicator lamp signal, meter display signal and buzzer output signal from camera control unit via CAN communication.
- Turns the lane departure warning lamp and LDW ON indicator lamp ON/OFF according to the signals from camera control unit.
- Displays the clean camera display according to the signal from the camera control unit.
- Operates the buzzer according to the signal from the camera control unit.

Rear View Camera

- The rear view camera is installed to the back door finisher.
- Super-small CMOS camera (color) using CMOS^{*} for the image pickup element is adopted.
- With the mirror processing function, a mirror image is sent as if it is viewed by a rear view mirror.



INFOID:000000009723203

INFOID:000000009723204

Μ

Ν

DAS

Ρ

DAS-9

INFOID:000000009723205

COMPONENT PARTS

< SYSTEM DESCRIPTION >

- Power for the camera is supplied from the camera control unit, and the image at the rear of the vehicle is sent to the camera control unit.
- The rear view camera is equipped with a washer nozzle and air nozzle for cleaning camera. A check valve is installed to the tube connected to the washer nozzle.



NOTE:

*: "CMOS" is abbreviation of Complementary Metal Oxide Semiconductor, and features low power consumption and high speed reading rate of electric charge.

Camera Specification

Manufacturer name	SONY Corp.	
Image pickup element	1/4-inch CMOS image sensor	
Effective number of pixels	Approx. 300,000 pixels (632 × 480)	
Minimum brightness	2 lx	
Angle of view	H: 190.4° V: 141.8°	
Image	With mirror processing function	

Pump Control Unit

• Pump control unit is installed in under the luggage floor front finisher.



- Communicates with camera control unit via communication line.
- Activates air pump and washer pump according to the signal from camera control unit.
- Receives rear washer signal from washer switching solenoid valve.

INFOID:000000009723206

COMPONENT PARTS

< SYSTEM DESCRIPTION >

Air Pump

• Air pump is installed in the luggage floor spacer LH in the luggage room.

- Air pump is activated and generates compressed air when power is supplied from the pump control unit.
- Compressed air jets out from the air nozzle of rear view camera via air tube.

Washer Switching Solenoid Valve

- Washer switching solenoid valve is installed in the back door.
- When rear washer is in the inactive condition, the solenoid valve is inactive and rear view camera washer path is activated.
- When rear washer is in the active condition, the solenoid valve is active and the washer path is switched to rear washer side.
- When solenoid valve is active, a rear washer signal is transmitted to the pump control unit.

Rear View Camera Washer Relay

- Rear view camera washer relay 1 and 2 are installed in the engine room LH
- When the relay is in the inactive state, the circuit of window washer is energized.
- Rear view camera washer relay 1and 2 are activated according to a signal from the pump control unit and activate the washer pump regardless of window washer activation.

Warning Systems Switch/Warning Systems ON Indicator

- Installed to the instrument lower panel, the warning systems switch is used to activate/deactivate the LDW and BSW systems.
- Transmits a warning systems switch signal to the camera control unit.



2 kΩ

 \sim

[LDW]

А

Е





3

5

241

DAS

Ρ

Κ

< SYSTEM DESCRIPTION >

SYSTEM

System Description

SYSTEM DIAGRAM



CAMERA CONTROL UNIT INPUT/OUTPUT SIGNAL ITEM

Input Signal Item

INFOID:000000009723211

SYSTEM

< SYSTEM DESCRIPTION >

Transmit unit		Signal name	Description
ABS actuator	CAN com-	Vehicle speed signal (ABS)	Receives wheel speeds of four wheels
and electric unit (control unit)	munica- tion	VDC malfunction signal	Receives a malfunction state of VDC
BCM	CAN com- munica- tion	Turn indicator signal	Receives an operational state of the turn signal lamp and the hazard lamp
AV control unit	CAN com- munica- tion	System selection signal	Receives a selection state of each item in "Driver as- sist" selected with the navigation system
Steering angle sensor	CAN com- munica- tion	Steering angle sensor signal	Receives the number of revolutions, turning direction of the steering wheel
	CAN com-	Engine status signal	Receives the engine status
ECM	munica- tion	Engine coolant temperature signal	Receives the engine coolant temperature
A/C auto amp.	CAN com- munica- tion	Ambient sensor signal	Receives the ambient temperature
Rear view cam- era	Communi- cation line	Camera image signal	Receives the camera image signal
Washer level switch	Washer level switch signal		Receives a status of washer fluid level
Warning sys- tems switch	Warning sy	stems switch signal	Receives an ON/OFF state of the warning systems switch

Output Signal Item

Reception unit		Signal name		Description
		Lane departure warning lamp signal		Transmits a lane departure warning lamp signal to turn ON the lane departure warning lamp
Combination C	CAN commu-	LDW ON indicator lamp signal		Transmits a LDW ON indicator lamp signal to turn ON the LDW ON indicator lamp
meter	nication	Meter display signal	Clean camera display signal	Transmits a meter display signal to turn ON the clean camera indication on the information display.
		Buzzer output signal		Transmits a buzzer output signal to activates the warning buzzer
Pump control	Communica-	Rear view came	era washer signal	Transmits a rear view camera washer signal to activates the washer pump
unit tion line		Rear view camera air blow signal		Transmits a rear view camera air blow signal to activates the air pump
Warning sys- tems ON indi- cator	Warning syste	ns ON indicator signal		Turns ON the warning systems ON indicator

FUNCTION DESCRIPTION

- Lane Departure Warning (LDW) system provides a lane departure warning function when the vehicle is driven at speeds of approximately 70 km/h (45 MPH) or more.
- When the vehicle approaches either the left or the right side of the traveling lane, a warning will sound and the lane departure warning lamp (yellow) on the combination meter will blink to alert the driver.
- The warning does not occur during turn signal operation (Lane change side).
- The warning function will stop when the vehicle returns inside of the lane markers.

[LDW]

DAS

Ρ

< SYSTEM DESCRIPTION >

EXAMPLE



When the vehicle approaches the right lane marker, the driver is alerted by the buzzer and the blinking of lane departure warning lamp (yellow).

OPERATION DESCRIPTION

- When the system is turned ON by operating the warning systems switch, camera control unit turns ON the LDW ON indicator lamp and the warning systems ON indicator.
- Rear view camera monitors the traveling lane. It transmits the camera image signal to camera control unit.
- When judging from a camera image signal that the vehicle is approaching the lane marker, the camera control unit controls the following item to alert the driver.
- Activates warning buzzer in the combination meter.
- Camera control unit transmits a lane departure warning lamp signal to combination meter via CAN communication and turns ON/OFF the lane departure warning lamp (yellow).

Operating Condition

- LDW ON indicator lamp: ON
- Warning systems ON indicator: ON
- Vehicle speed: approximately 70 km/h (45 MPH) or more
- Turn indicator signal: After 2 seconds or more from turned OFF
- Back door: Close
- Low washer fluid warning: OFF

NOTE:

- When the LDW system setting on the navigation screen is ON.
- After the operating conditions of warning are satisfied, the warning continues until the vehicle speed reaches approximately 60 km/h (40 MPH)
- The LDW system may not function properly, depending on the situation. Refer to <u>DAS-20</u>, "<u>Precautions for</u> <u>Lane Departure Warning</u>"

Bulb Check Action and Fail-safe Indication

Vehicle condition/ Driver's operation	Warning sys- tems ON indi- cator	Indication on the combination meter
Ignition switch OFF ⇒ ON (Bulb check)	Approx. 5 sec. ON	OFF - (Yellow) (Yellow) ON SOIA0667GB

SYSTEM

Warning sys-

< SYSTEM DESCRIPTION >

Vehicle condition/ Driver's operation	tems ON indi- cator	Indication on the combination meter	A
When DTC is detected (Except "U1308")	ON		В
Camera calibration is not completed ("U1308" is detected) NOTE: This is detected while driving the vehicle and the indication remains ON until the ignition switch is turned OFF	ON	(Yellow) ON JSOIA0668GB	С
When lane markers cannot be detected due to dirt on the camera.	ON	In the information display UNAVAILABLE Clean Rear Camera	D F G
When the washer fluid level is low (Low washer fluid warning ON)	ON	Blinks at intervals of two seconds.	– I
When the back door is open (Back door open warning ON)	ON	Blinks at intervals of two seconds.	L

REAR VIEW CAMERA WASHER OPERATION

- When judging that the rear view camera has water droplets, the camera control unit transmits a rear view camera washer activation signal or rear view camera air blow signal to the pump control unit via serial communication.
- When receiving a rear view camera washer activation signal, the pump control unit simultaneously activates the washer pump to clean the rear view camera by spraying washer fluid from the nozzle installed to the rear view camera bracket.
- The washer switching solenoid valve switches the washer path from rear window to rear view camera.
- When receiving a rear view camera air blow signal, the pump control unit activates the air pump to clean the rear view camera by blowing air from the nozzle installed to the rear view camera bracket.

OPERATION CONDITION

- Approximately 30 km/h (20 MPH) or more
- When the camera control unit judges that the rear view camera has water droplets.
- When the front washer and the rear washer are not activated.
- · When the low washer fluid warning is OFF.

Ρ

< SYSTEM DESCRIPTION >

NOTE:

The camera is cleaned intermittently by spraying washer fluid and blowing air. When the camera control unit judges that dirt on the camera cannot be removed even after approximately 5 minutes from the first detection of dirt, the activation of LDW is canceled.

Fail-Safe

INFOID:000000009723212

DTC Display contents of CONSULT	Malfunction detection condition	Fail-safe condition
C1A03 VHCL SPEED SE CIRC	If the vehicle speed signal (wheel speed) from ABS actuator and electric unit (control unit) re- ceived by the camera control unit via CAN com- munication, are inconsistent	LDW system is cancelBSW system is cancel
C1A04 ABS/TCS/VDC CIRC	If a malfunction occurs in the VDC/TCS/ABS system	 LDW system is cancel BSW system is cancel
C1A39 STRG SEN CIR	If the steering angle sensor is malfunction	LDW system is cancelBSW system is cancel
U0122 VDC P-RUN DIAGNOSIS	If camera control unit detects an error signal that is received from ABS actuator and electric unit (control unit) via CAN communication	LDW system is cancelBSW system is cancel
U0416 VDC CHECKSUM DIAGNOSIS	If camera control unit detects an error signal that is received from ABS actuator and electric unit (control unit) via CAN communication	LDW system is cancelBSW system is cancel
U0428 ST ANGLE SENSOR CALIBRA- TION	Neutral position adjustment of steering angle sensor is not complete.	 Predicted course line is not displayed. MOD (Moving Object Detection) function is stopped. LDW system is stopped. BSW system is stopped.
U1000 CAN COMM CIRCUIT	When camera control unit cannot transmit/re- ceive CAN communication signal continuously for 2 seconds or more.	 The following functions are stopped When communication of steering angle sensor signal is not normal Predicted course line is not displayed. MOD (Moving Object Detection) function is stopped. LDW system is stopped. Front tire angle display is stopped. Using "SETTING" menu display, switch each indicator of predicted course line display and MOD switch to "OFF" (turn OFF) so that switch operation cannot be performed. When communication of vehicle signal, wheel speed sensor signal, and shift signal is not normal Predicted course line is not displayed. MOD (Moving Object Detection) function is stopped. LDW system is stopped. MOD (Moving Object Detection) function is stopped. LDW system is stopped. BSW system is stopped. Worm of the stopped. When communication of vehicle signal, wheel speed sensor signal, and shift signal is not normal Predicted course line is not displayed. MOD (Moving Object Detection) function is stopped. LDW system is stopped. BSW system is stopped. Using "SETTING" menu display, switch each indicator of predicted course line display and MOD switch to "OFF" (turn OFF) so that switch operation cannot be performed When communication of sonar signal is not normal Predicted course line is not displayed.
U1010 CONTROL UNIT (CAN)	CAN initial diagnosis malfunction is detected.	 MOD (Moving Object Detection) function is stopped. LDW system is stopped. BSW system is stopped.

SYSTEM

< SYSTEM DESCRIPTION >

		۱.	
		v	v
	~		•

DTC Display contents of CONSULT	Malfunction detection condition	Fail-safe condition
U111A REAR CAMERA IMAGE SIGNAL	No-signal status of rear camera image signal is continued for 500 ms or more while ignition switch is ON. NOTE: Current malfunction is displayed only and is not saved.	 Camera image is not displayed (Gray screen display). LDW system is stopped. BSW system is stopped.
U1232 ST ANGLE SEN CALIB	Neutral position adjustment of steering angle sensor is performed. NG signal from steering angle sensor is received.	 Predicted course line is not displayed. MOD (Moving Object Detection) function is stopped. LDW system is stopped. BSW system is stopped. Tire icon is stopped. Using "SETTING" menu display, switch each indicator of predicted course line display and MOD switch to "OFF" (turn OFF) so that switch operation cannot be performed.
U1305 CONFIG UNFINISH	The vehicle setting of camera control unit is in- complete. NOTE: Current malfunction is displayed only and is not saved.	Operation is according to the vehicle setting value as default value.
U1308 R-CAMERA (R&L) CALIB JDG- MNT	Camera image calibration is incomplete	 MOD (Moving Object Detection) function is stopped. LDW system is stopped. BSW system is stopped.
U1309 PUMP INPUT CURRENT JUDGE	Camera control unit detects the value of current from pump control unit is incorrect	 MOD (Moving Object Detection) function is stopped. LDW system is stopped. BSW system is stopped.
U130B RR CAMERA COMM ERROR	Camera control unit receives the incorrect com- munication signal from rear view camera	 MOD (Moving Object Detection) function is stopped. LDW system is stopped. BSW system is stopped.
U1310 PUMP ECU JUDGE	If the pump control unit is malfunction	LDW system is stopped.BSW system is stopped.
	When camera control unit is not normal.	Switch to camera screen is not allowed.
Other	When communication between camera control unit and each camera is not normal.	On applicable camera screen <u>A</u> marking (Red) is displayed.
	When communication line between camera control unit and each camera image line are af- fected by electromagnetic noises.	On applicable camera image screen, 🔀 dis- play (Blue) is displayed.

Ν

DAS

< SYSTEM DESCRIPTION >

Switch Name and Function



No.	Switch name	Description
1	Warning systems switch	Turns LDW system ON/OFF (When the setting of LDW system on the navigation system screen is ON)
2	LDW system setting screen (Navigation system setting screen)	Turns setting of LDW system can be switched between ON and OFF

System Display and Warning

INFOID:000000009723214

INDICATOR LAMP AND WARNING LAMP



No.	Display item	Description
1	Warning systems ON indicator	Indicates that the LDW and/or BSW system is ON
	Lane departure warning lamp (Yellow)	Blinks when LDW system is warning to driverTurns ON when LDW system has a malfunction
2	LDW ON indicator lamp (Green)	 Turns ON when LDW system is activated Blinks when the back door is open Blinks when the washer fluid level is low

DISPLAY AND WARNING

OPERATION

< SYSTEM DESCRIPTION >

Vehicle co	ondition/ Driver's operation	Action	Warning sys- tems ON indi- cator	Indication on the combination meter	Buzzer	А
Less than Ap- prox. 60 km/h (40 MPH)	Close to lane marker	No action	ON	(Green) ON JPOIA0021GB	_	B C D
Approx. 70 km/h (45	Close to lane marker	Warning • Buzzer sounds • Warning lamp blinks	ON	(Green) ON Blink ON JPOIA0022GB	Short con- tinuous beeps	E
MPH) or more	 Close to lane marker Turn signal ON (Deviate side) 	No action	ON	(Green) ON	_	G
		1		JPOIA0021GB	1	

NOTE:

After the operating conditions of warning are satisfied, the warning continues until the vehicle speed reaches approximately 60 km/h (40 MPH). Refer to <u>DAS-12. "System Description"</u>.

J

[LDW]

Κ

L

M

Ν

HANDLING PRECAUTION

Precautions for Lane Departure Warning

INFOID:000000009723215

[LDW]

REAR VIEW CAMERA HANDLING

The rear view camera for the LDW/BSW systems is located above the rear licence plate. To keep the proper operation of the LDW/BSW systems and prevent a system malfunction, be sure to observe the following:

- Always keep the rear view camera clean. Be careful not to damage the nozzle of automatic washer and blower.
- Do not attach "licence plate accessory" that reflect light.
- Do not strike or damage the areas around the rear view camera.

LANE DEPARTURE WARNING (LDW)

- The LDW system is only a warning device to inform the driver of a potential unintended lane departure. It will not steer the vehicle or prevent loss of control. It is the driver's responsibility to stay alert, drive safely, keep the vehicle in the traveling lane, and be in control of the vehicle at all times.
- The rear view camera may not detect properly under the following conditions:
- When towing a trailer.
- When strong light enters the rear view camera. (For example, direct sunlight or headlight from the rear)
- When ambient brightness changes instantly. (For example, when the vehicle enters or exits a tunnel or passes under a bridge.)
- Automatic washer and blower may not be able to secure detection capability when excessive dirt adheres on the camera lens.
- LDW system may not function properly under the following conditions:
- Excessive noise (e.g. audio system volume, open vehicle window) will interfere with the chime sound, and it may not be heard.
- The rear view camera may not be able to detect properly under the following conditions:
- On roads where there are multiple parallel lane markers; lane markers that are faded or not painted clearly; yellow painted lane markers; non-standard lane markers; or lane markers covered with water, dirt, snow, etc.
- On roads where the discontinued lane markers are still detectable.
- On roads where there are sharply contrasting objects, such as shadows, snow, water, wheel ruts, seams or lines remaining after road repairs. (The LDW system could detect these items as lane markers.)
- On roads where the traveling lane merges or separates.
- When the vehicle's traveling direction does not align with the lane marker.
- When the road surface is very dark due to scarce ambient light or impaired tail lamp.
- When driving on curved road, warning will be late on the outside of the curve due to the nature of the system.

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (CAMERA CONTROL UNIT)

CONSULT Function

INFOID:000000009723216

А

В

Н

J

Κ

Ρ

[LDW]

CONSULT FUNCTIONS

CONSULT performs the following functions via the CAN communication with the camera control unit.

Diagnosis mode	Description
ECU Identification	Camera control unit part number can be identified.
Self Diagnostic Results	Camera control unit diagnosis is performed. Current and previous malfunctions are displayed collectively.
Data Monitor	Diagnosis of vehicle signal that is received by camera control unit can be performed.
Work Support	 Target line calibration of rear wide view can be performed. Display of predicted course line can be switched to ON/OFF. Calibration and initialization of rear view camera can be performed. Neutral position adjustment of steering angle sensor can be performed. Calibration for LDW and BSW can be performed. Displays causes of system cancellation occurred during system control.
Active Test	Enables an operational check of a load by transmitting a driving signal from the camera control unit to the load.
Configuration	 The vehicle specification that is written in camera control unit can be displayed or stored. The vehicle specification can be written when camera control unit is replaced.

ECU IDENTIFICATION

Camera control unit part number can be identified.

SELF DIAGNOSIS RESULT

Refer to DAS-30, "DTC Index".

- In CONSULT self-diagnosis, self-diagnosis results and error history are displayed collectively.
- The current malfunction indicates "CRNT". The past malfunction indicates "PAST".
- The timing is displayed as "0" if any of the error codes [U1000] and [U1010] is detected. The counter increases by 1 if the condition is normal at the next ignition switch ON cycle.

Freeze Frame Data (FFD)

The following vehicle status is recorded when DTC is detected and is displayed on CONSULT.

Item name	Display content	
IGN counter (0 to 39)	Numerical value is displayed indicating the number of times that ignition switch is turned ON after the DTC is detected.	
	When "0" is displayed, it indicates that the system is presently malfunctioning.	
	• When any numerical number other than "0" is displayed, it indicates that system malfunction in the past is	
	detected, but the system is presently normal.	
,		
	Each time when ignition switch turns $OFF \rightarrow ON$, numerical number increases from $1 \rightarrow 2 \rightarrow 338 \rightarrow 39$.	
	When number of times exceeds 39, numeric display does not increase and 39 is displayed until self-diag-	
	nosis is eraseo.	

DATA MONITOR **NOTE**:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

• Displays the status of the following vehicle signals inputted into the camera control unit.

• For each signal, actual signal can be compared with the condition recognized on the system.

Display Item	Remarks
ST ANGLE SENSOR SIGNAL [ON/OFF]	Receiving status of steering angle signal received from steering angle sensor is switched to ON/OFF.
REVERSE SIGNAL [ON/OFF]	Receiving status of reverse signal received from AV control unit is displayed by ON/OFF.

< SYSTEM DESCRIPTION >

Display Item	Remarks			
VEHICLE SPEED SIGNAL [ON/OFF]	Receiving status of vehicle speed signal received from ABS actuator control unit is displayed by ON/OFF.			
ILL [ON/OFF]	Receiving status of dimmer signal received from BCM is displayed by ON/OFF.			
CAMERA SWITCH SIGNAL [ON/OFF]	Receiving status of camera switch signal received from AV control unit is displayed by ON/ OFF.			
CAMERA OFF SIGNAL [ON/OFF]	Receiving status of camera OFF signal received from AV control unit is displayed by ON/OFF.			
ITS SW 1 [ON/OFF]	Indicates the state of the warning system switch as seen by the camera control unit.			
ITS SW 1 IND [ON/OFF]	Indicates the state of the warning system switch indicator output.			
ST ANGLE SENSOR TYPE [ABSOLUTE]	Input type of steering angle sensor is displayed. NOTE: For this vehicle, "Absolute" is displayed.			
STEERING GEAR RATIO TYPE [TYPE1]	Type of steering gear ratio is displayed. NOTE: For this vehicle, "TYPE 1" is displayed.			
STEERING POSITION [LHD]	Steering position is displayed. NOTE: For this vehicle, "LHD" is displayed.			
WASH SW [ON/OFF]	Indicates [On/Off] status of the washer switch signal input			
REAR CAMERA IMAGE SIGNAL [OK/NG]	Input status of rear view camera image signal is displayed by OK/NG in real time.			
R-CAMERA COMM STATUS [OK/NG]	Communication status with rear camera is displayed by OK/NG in real time.			
R-CAMERA COMM LINE [OK/NG]	Status of communication line with rear camera is displayed by OK/NG in real time.			
TURN SIGNAL [ON/OFF]	Indicates [On/Off] status of the turn signal input			
ITS SW 2 [No setting]	Indicates the status of warning systems switch as seen by the camera control unit. NOTE: For this vehicle, "No setting" is displayed.			
PUMP COMM STATUS [OK/NG]	Communication status with pump control unit is displayed by OK/NG in real time.			
ITS SW 2 IND [No setting]	Indicates the status of warning systems switch indicator output. NOTE: For this vehicle, "No setting" is displayed.			

WORK SUPPORT

Display Item	Remarks
REAR WIDE-VIEW FIXED GUIDE LINE CORRECTION	The position of rear wide view guiding line can be changed.
PREDICTIVE COURSE LINE DIS- PLAY	ON/OFF setting of predictive course line can be performed.
INITIALIZE CAMERA IMAGE CALI- BRATION	The calibration can be initialized to factory shipment condition. NOTE: Calibration of camera image caused by misalignment of the camera installation position is per- formed.

< SYSTEM DESCRIPTION >

Display Item	Remarks	
STEERING ANGLE SENSOR AD- JUSTMENT	Steering angle sensor neutral position can be adjusted and registered. CAUTION: For vehicles with VDC, adjust the steering angle sensor neutral position on the ABS ac- tuator control unit side. Refer to <u>BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR</u> NEUTRAL POSITION : Special Repair Requirement".	
REAR CAMERA ITS	Calibration for LDW/BSW can be performed.	
CAUSE OF LDW CANCEL	Displays causes of automatic system cancellation occurred during control of the LDW system.	С
CAUSE OF BSW CANCEL	Displays causes of automatic system cancellation occurred during control of the BSW system.	

NOTE:

• Causes of the maximum five cancellations (system cancel) are displayed.

• The displayed cancellation causes display the number of the ignition switch ON/OFF up to 254. It is fixed to 254 if it is over 254. It returns to 0 when the same cancellation cause is detected again.

Display Items for The Cause of LDW/BSW Cancel

Cause of cancellation	Description	
REAR CAMERA DIRTY	Rear view camera lens is dirty.	F
TRUNK OPEN	Back door is open.	
TRAILER HITCH ON	Towing (by attaching a trailer).	G
R CAMERA COMM ERR	Communication error between camera control unit and rear view camera.	
LOW WASH FLUID	Washer fluid level is low.	
LO TMP(AIR WIPING)	Ambient temperature drops to -20 °C (-4 °F) or less.	-
LO TMP(WSH WIPING)	Ambient temperature drops to -20 °C (-4 °F) or less.	
NO RECORD	-	

ACTIVE TEST

CAUTION:

- Never perform "Active Test" while driving the vehicle.
- The "Active Test" cannot be performed when the following systems warning indicator is illuminated.
- Lane departure warning lamp
- BSW warning lamp
- Shift the selector lever to "P" position, and then perform the test.

Test items	Description	
LED LH INDICATOR	BSW indicator LH can be illuminated by ON/OFF operations as necessary.	_ L
LED RH INDICATOR	BSW indicator RH can be illuminated by ON/OFF operations as necessary.	_
WASH ACTIVE	Camera washer can be operated by ON/OFF operations as necessary.	M
AIR ACTIVE	Camera blower can be operated by ON/OFF operations as necessary.	_
AIR & WASH ACTIVE	Camera blower and washer can be operated by ON/OFF operations as necessary.	

LED LH INDICATOR

Test item	Operation	Description	BSW indicator LH	DA
LED LH INDICATOR	Off	Stops transmitting the BSW indicator LH signal below to end the test	OFF	
	On	Transmits the BSW indicator LH signal to the BSW indicator	ON	Ρ

LED RH INDICATOR

[LDW]

D

Е

J

Κ

< SYSTEM DESCRIPTION >

[LDW]

Test item	Operation	Description	BSW indicator RH
	Off	Stops transmitting the BSW indicator RH signal below to end the test	OFF
	On	Transmits the BSW indicator RH signal to the BSW indicator	ON

WASH ACTIVE

Test item	Operation	Description	Rear view camera washer
	Off	Stops transmitting the rear view camera washer signal below to end the test	OFF
WASHACHVE	On	Transmits the rear view camera washer signal to the pump control unit via communication line	ON

AIR ACTIVE

Test item	Operation	Description	Rear view camera air blower
	Off	Stops transmitting the rear view camera air blow signal below to end the test	OFF
	On	Transmits the rear view camera air blow signal to the pump control unit via communication line	ON

AIR & WASHER ACTIVE

Test item	Operation	Description	Rear view camera air blower and washer
AIR & WASHER AC-	Off	Stops transmitting the rear view camera air blow / washer signal below to end the test	OFF
TIVE	On	Transmits the rear view camera air blow / washer signal to the pump control unit via communication line	ON

CONFIGURATION

Configuration includes functions as follows.

Function		Description	
	Before Replace ECU	Allows the reading of vehicle specification written in camera con- trol unit to store the specification in CONSULT.	
Read/White Conliguration	After Replace ECU	Allows the writing of the vehicle information stored in CONSULT into the camera control unit.	
Manual Configuration		Allows the writing of the vehicle specification into the camera control unit by hand.	

ECU DIAGNOSIS INFORMATION CAMERA CONTROL UNIT

Reference Value

VALUES ON THE DIAGNOSIS TOOL

NOTE:

С The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

CONSULT	MONITOR	ITEM
00001		

Monitor Item		Condition	Value/Status
ST ANGLE SENSOR SIGNAL	Ignition switch	When steering angle sensor signal is input	ON
[ON/OFF]	ON	Other than the above	OFF
REVERSE SIGNAL	Ignition switch	R position	ON
[ON/OFF]	ON	Other than R position	OFF
VEHICLE SPEED SIGNAL	Ignition switch	When vehicle speed is input	ON
[ON/OFF]	ON	Other than the above	OFF
ILL	Ignition switch	When lighting switch is ON	ON
[ON/OFF]	ON	When lighting switch is OFF	OFF
CAMERA SWITCH SIGNAL	Ignition switch	When camera switch signal is input	ON
[ON/OFF]	ŎN	Other than the above	OFF
CAMERA OFF SIGNAL	Ignition switch	When camera OFF signal is input	ON
[ON/OFF]	ON	Other than the above	OFF
ITS SW 1	Ignition switch ON	Warning systems switch is ON. (Warning systems ON indicator illuminates.)	ON
[ON/OFF]		Warning systems switch is OFF. (Warning systems ON indicator OFF.)	OFF
ITS SW 1 IND	Ignition switch	Warning systems ON indicator illuminates.	ON
[ON/OFF]	ON	Warning systems ON indicator OFF	OFF
ST ANGLE SENSOR TYPE [Absolute]	Ignition switch ON	_	Absolute
STEERING GEAR RATIO TYPE [TYPE1]	Ignition switch ON	_	TYPE1
STEERING POSITION [LHD]	Ignition switch ON	_	LHD
WASH SW	Ignition switch	When washer switch signal is input	ON
[ON/OFF]	ON	Other than the above	OFF
		When rear camera image signal input status is normal	OK
REAR CAMERA IMAGE SIGNAL [OK/NG]	Ignition switch	When rear view camera image signal input status is not normal	NG
R-CAMERA COMM STATUS	Ignition switch	When communication status with rear camera is nor- mal	ОК
[OK/NG]	ON	When communication status with rear camera is not normal	NG
TURN SIGNAL	Ignition switch	Turn signal is ON	ON
[ON/OFF]	ŌN	Turn signal is OFF	OFF
ITS SW 2 [No setting]	Ignition switch ON	—	No setting

А

INFOID:000000009723217 В

< ECU DIAGNOSIS INFORMATION >

[LDW]

Monitor Item		Value/Status	
PUMP COMM STATUS Ignition swi		When communication signal is input	OK
[OK/NG]	ON	Other than the above	NG
ITS SW 2 IND [No setting]	Ignition switch ON	_	No setting

TERMINAL LAYOUT



PHYSICAL VALUES

Terr (Wire	minal color)	Description		Condition		Standard value	Reference value	
+	_	Signal name	Input/ Output			Standard value	(Approx.)	
1 (B)	Ground	Ground		lgnition switch ON	_	0 - 0.1 V	0 V	
2 (V)	1 (B)	Battery power supply	Input	lgnition switch OFF	_	9.5 - 16 V	Battery voltage	
3 (G)	1 (B)	Ignition signal	Input	Ignition switch ON	_	9.5 - 16 V	Battery voltage	
7 (R)	Ground	BSW indicator LH	Output	lgnition switch ON	Approx. 2 sec. after ignition switch OFF \Rightarrow ON (bulb check).	5.5 - 16 V	6.0 V	
8 (G)	Ground	BSW indicator RH	Output	Ignition switch ON	Approx. 2 sec. after ignition switch OFF \Rightarrow ON (bulb check)	5.5 - 16 V	6.0 V	
15	Ground	Warning systems ON	Output	Ignition switch	Warning systems ON indi- cator ON	0 - 0.1 V	0 V	
(BR)	Ground	indicator	Output	Output ON	ON	Warning systems ON indi- cator OFF	9.5 - 16 V	12.0 V
17	Ground	Warning systems	loout	Ignition	When warning systems switch is not pressed	9.5 - 16 V	12.0 V	
(GR)	Ground	switch	input	ON	INPUT SWITCH ON	When warning systems switch is pressed	0 - 0.1 V	0 V
25	1			Ignition	R position	9.5 - 16 V	12.0 V	
(R)	(B)	Reverse signal	Input	switch ON	Other than R position	0 - 0.1 V	0 V	
27 (L)	_	CAN-H	Input/ Output	_	_	_	_	
28 (P)		CAN-L	Input/ Output	_	_	_	_	

< ECU DIAGNOSIS INFORMATION >

Terr (Wire	minal e color)	Description	Description Condition Standard value Reference		Condition		Condition		Reference value	А
+	-	Signal name	Input/ Output		Condition	Standard Value	(Approx.)			
36 (W)	Ground	Communication signal (CAMERA \rightarrow PUMP)	Output	lgnition switch ON		Input the wavefor with the commu (V) 6 4 2 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	prm synchronized unication status.	B C D		
37 (SB)	Ground	COMM GND	_	Ignition switch ON		0 - 0.1 V	рків5039J 0 V	Е		
38 (V)	Ground	Communication signal (PUMP \rightarrow CAMERA)	Input	lgnition switch ON		Input the wavefor with the commu (V) 6 4 9 0 4 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Print	F G H		
40 (D)	Ground	Washer level switch	Input	Ignition switch	Washer is empty	0 - 0.1 V	0 V			
47 (B)	48	Camera image signal	Output	ON Ignition switch ON	Washer is not empty	9.5 - 16 V Input the wavefor with the camer (V) 1 0 -1 -1 +40 µ	12 V prm synchronized ra image signal.	K		
48	Ground	Camera image signal ground	_	Ignition switch ON	_	0 - 0.1 V	0 V	L		
49 (W)	52 (R/W)	Rear camera commu- nication signal	Input/ Output	Ignition switch ON		Input the wavefor with the comm (V) 5 4 3 2 1 0	JSNIA0836GB	M N DAS		
50 (R/L)	52 (R/W)	Rear camera power supply	Output	Ignition switch ON		5.0 - 9.0 V	6.0 V	Р		
52 (R/W)	Ground	Rear camera ground	_	Ignition switch ON	_	0 - 0.1 V	0 V			

[LDW]

< ECU DIAGNOSIS INFORMATION >

Terr (Wire	Terminal Description Nire color)		Standard value	Reference value			
+	_	Signal name	Input/ Output	Condition		Standard Value	(Approx.)
						Input the wavefo with the came	orm synchronized a image signal.
53 (B)	54	Rear camera image signal (+)	Input	Ignition switch — ON			
E A	Cround	Rear camera image		Ignition		0.011/	0.1/
54	Ground	signal (-)		ON		0-0.1 V	υv

Fail-Safe

INFOID:000000009723218

DTC Display contents of CONSULT	Malfunction detection condition	Fail-safe condition
C1A03 VHCL SPEED SE CIRC	If the vehicle speed signal (wheel speed) from ABS actuator and electric unit (control unit) re- ceived by the camera control unit via CAN com- munication, are inconsistent	LDW system is cancelBSW system is cancel
C1A04 ABS/TCS/VDC CIRC	If a malfunction occurs in the VDC/TCS/ABS system	 LDW system is cancel BSW system is cancel
C1A39 STRG SEN CIR	If the steering angle sensor is malfunction	 LDW system is cancel BSW system is cancel
U0122 VDC P-RUN DIAGNOSIS	If camera control unit detects an error signal that is received from ABS actuator and electric unit (control unit) via CAN communication	LDW system is cancelBSW system is cancel
U0416 VDC CHECKSUM DIAGNOSIS	If camera control unit detects an error signal that is received from ABS actuator and electric unit (control unit) via CAN communication	LDW system is cancelBSW system is cancel
U0428 ST ANGLE SENSOR CALIBRA- TION	Neutral position adjustment of steering angle sensor is not complete.	 Predicted course line is not displayed. MOD (Moving Object Detection) function is stopped. LDW system is stopped. BSW system is stopped.

< ECU DIAGNOSIS INFORMATION >

[LDW]

DTC Display contents of CONSULT	Malfunction detection condition	Fail-safe condition
U1000 CAN COMM CIRCUIT	When camera control unit cannot transmit/re- ceive CAN communication signal continuously for 2 seconds or more.	 The following functions are stopped When communication of steering angle sensor signal is not normal Predicted course line is not displayed. MOD (Moving Object Detection) function is stopped. LDW system is stopped. BSW system is stopped. Front tire angle display is stopped. Using "SETTING" menu display, switch each indicator of predicted course line dis- play and MOD switch to "OFF" (turn OFF) so that switch operation cannot be per- formed. When communication of vehicle signal, wheel speed sensor signal, and shift signal is not normal Predicted course line is not displayed. MOD (Moving Object Detection) function is stopped. LDW system is stopped. BSW system is stopped. Using "SETTING" menu display, switch each indicator of predicted course line dis- play and MOD switch to "OFF" (turn OFF) so that switch operation cannot be per- formed. When communication of vehicle signal, wheel speed sensor signal, and shift signal is not normal Predicted course line is not displayed. MOD (Moving Object Detection) function is stopped. LDW system is stopped. Using "SETTING" menu display, switch each indicator of predicted course line dis- play and MOD switch to "OFF" (turn OFF) so that switch operation cannot be per- formed When communication of sonar signal is not normal Predicted course line is not displayed.
U1010 CONTROL UNIT (CAN)	CAN initial diagnosis malfunction is detected.	 MOD (Moving Object Detection) function is stopped. LDW system is stopped. BSW system is stopped.
U111A REAR CAMERA IMAGE SIGNAL	No-signal status of rear camera image signal is continued for 500 ms or more while ignition switch is ON. NOTE: Current malfunction is displayed only and is not saved.	 Camera image is not displayed (Gray screen display). LDW system is stopped. BSW system is stopped.
U1232 ST ANGLE SEN CALIB	Neutral position adjustment of steering angle sensor is performed. NG signal from steering angle sensor is received.	 Predicted course line is not displayed. MOD (Moving Object Detection) function is stopped. LDW system is stopped. BSW system is stopped. Tire icon is stopped. Using "SETTING" menu display, switch each indicator of predicted course line display and MOD switch to "OFF" (turn OFF) so that switch operation cannot be performed.
U1305 CONFIG UNFINISH	The vehicle setting of camera control unit is in- complete. NOTE: Current malfunction is displayed only and is not saved.	Operation is according to the vehicle setting value as default value.
U1308 R-CAMERA (R&L) CALIB JDG- MNT	Camera image calibration is incomplete	 MOD (Moving Object Detection) function is stopped. LDW system is stopped. BSW system is stopped.

< ECU DIAGNOSIS INFORMATION >

DTC Display contents of CONSULT	Malfunction detection condition	Fail-safe condition
U1309 PUMP INPUT CURRENT JUDGE	Camera control unit detects the value of current from pump control unit is incorrect	 MOD (Moving Object Detection) function is stopped. LDW system is stopped. BSW system is stopped.
U130B RR CAMERA COMM ERROR	Camera control unit receives the incorrect com- munication signal from rear view camera	 MOD (Moving Object Detection) function is stopped. LDW system is stopped. BSW system is stopped.
U1310 PUMP ECU JUDGE	If the pump control unit is malfunction	LDW system is stopped.BSW system is stopped.
	When camera control unit is not normal.	Switch to camera screen is not allowed.
Other	When communication between camera control unit and each camera is not normal.	On applicable camera screen <u>A</u> marking (Red) is displayed.
	When communication line between camera control unit and each camera image line are af- fected by electromagnetic noises.	On applicable camera image screen, X display (Blue) is displayed.

DTC Inspection Priority Chart

INFOID:000000009723219

If multiple DTCs are detected simultaneously, check them one by one depending on the following DTC inspection priority chart.

Priority	Detected items (DTC)
1	U1000: CAN COMM CIRCUIT U1010: CONTROL UNIT (CAN)
2	U1232: ST ANGLE SEN CALIB U1305: CONFIG UNFINISH
3	U0428: ST ANGLE SENSOR CALIBRATION
4	U130B: RR CAMERA COMM ERROR
5	U1308: R-CAMERA (R&L) CALIB JDGMNT
6	 C1A04: ABS/TCS/VDC CIRC C1A39: STRG SEN CIR U0122: VDC P-RUN DIAGNOSIS U0416: VDC CHECKSUM DIAGNOSIS U111A: REAR CAMERA IMAGE SIGNAL U1309: PUMP INPUT CURRENT JUDGE U1310: PUMP ECU JUDGE
7	C1A03: VHCL SPEED SE CIRC

DTC Index

INFOID:000000009723220

		Warnir	ng lamp		Reference	
DTC	CONSULT display	Lane depar- ture warning lamp	BSW warning lamp	ing Object De- tection) icon		
C1A03	VHCL SPEED SE CIRC	ON	ON	Orange	DAS-58, "DTC Logic"	
C1A04	ABS/TCS/VDC CIRC	ON	ON	Orange	DAS-59, "DTC Logic"	
C1A39	STRG SEN CIR	ON	ON	Orange	DAS-60, "DTC Logic"	
U0122	VDC P-RUN DIAGNOSIS	ON	ON	Orange	DAS-61, "DTC Logic"	
U0416	VDC CHECKSUM DIAGNOSIS	ON	ON	Orange	DAS-62, "DTC Logic"	
U0428	ST ANGLE SENSOR CALIBRATION	ON	ON	Orange	AV-378, "DTC Logic"	

< ECU DIAGNOSIS INFORMATION >

[LDW]

		Warnir	ng lamp	"MOD" (Mov-		Δ
DTC	CONSULT display	Lane depar- ture warning lamp	BSW warning lamp	ing Object De- tection) icon	Reference	
U1000	CAN COMM CIRCUIT	ON	ON	Orange	AV-379, "CAMERA CONTROL UNIT : DTC Logic"	B
U1010	CONTROL UNIT (CAN)	ON	ON	Orange	AV-381, "CAMERA CONTROL UNIT : DTC Logic"	С
U111A	REAR CAMERA IMAGE SIGNAL	ON	ON	Orange	AV-382, "DTC Logic"	D
U1232	ST ANGLE SEN CALIB	ON	ON	Orange	AV-406. "CAMERA CONTROL UNIT : DTC Logic"	F
U1305	CONFIG UNFINISH	ON	ON	Orange	AV-415, "DTC Logic"	
U1308	R-CAMERA (R&L) CALIB JDGMNT	ON	ON	Orange	DAS-70, "DTC Logic"	
U1309	PUMP INPUT CURRENT JUDGE	ON	ON	Blue	DAS-71, "DTC Logic"	F
U130B	RR CAMERA COMM ERROR	ON	ON	Orange	AV-417, "DTC Logic"	
U1310	PUMP ECU JUDGE	ON	ON	Blue	DAS-73, "DTC Logic"	G

Н

J

Κ

L

Μ

Ν

DAS

Ρ

< ECU DIAGNOSIS INFORMATION >

PUMP CONTROL UNIT

Reference Value



PHYSICAL VALUES

Terminal (Wire color)		Description		Condition		Chanderd value	Reference value	
+	-	Signal name	Input/ Output	Condition		Standard value	(Approx.)	
1	2	Air pump power sup-		Ignition	Air pump operated	9.5 - 16 V	12 V	
(W)	(B)	ply	Output	switch ON	Other than above	0 - 0.1 V	0 V	
2 (B)	Ground	Air pump ground	_	Ignition switch ON	_	0 - 0.1 V	0 V	
3 (L)	5 (B)	Rear view camera washer relay 2	Output	Ignition switch ON	Rear view camera washer operated	0 - 0.1 V	0 V	
					Other than above	9.5 - 16 V	12 V	
4 (P)	5 (P)	Rear view camera	Output	Output Ignition Switch ON	Rear view camera washer operated	0 - 0.1 V	0 V	
(R)	(В)	washer relay i			Other than above	9.5 - 16 V	0 V	
5 (B)	Ground	Ground		Ignition switch ON	_	0 - 0.1 V	0 V	
6 (SB)	_	Communication line ground	_	Ignition switch ON	_	0 - 0.1 V	0 V	
7 (V)	_	Communication line (PUMP \rightarrow CAMERA)	Output	Ignition switch ON		Input the waveform synchronized with the communication status.		

JSOIA0648ZZ

PUMP CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Terminal (Wire color)		Description		Condition		Standard value	Reference value	А
+	-	Signal name	Input/ Output	Condition		Standard Value	(Approx.)	
8 (W)	_	Communication line (CAMERA \rightarrow PUMP)			gnition switch — ON	Input the waveform synchronized with the communication status.		В
			Input	Ignition switch ON				С
						<u>→</u> 1ms	PKIB5039J	D
9 (G)	5 (B)	5 (B) Rear washer status input Ignition Switco ON		Ignition	Rear washer switch is ON.	0 - 0.1 V	0 V	_
			switch ON	Rear washer switch is OFF.	9.5 - 16 V	12 V	E	
10 (BR)	5	5 Rear washer switch	Input	Ignition switch ON	Rear washer switch is ON.	9.5 - 16 V	12 V	
	(B)	input			Rear washer switch is OFF.	0 - 0.1 V	0 V	F
12 (Y)	5 (B)	Ignition power supply	Input	Ignition switch ON	_	9.5 - 16 V	12 V	G

Н

[LDW]

J

Κ

L

Μ

Ν

DAS

Ρ

Revision: 2013 August

[LDW]

WIRING DIAGRAM DRIVER ASSISTANCE SYSTEMS

Wiring Diagram



DRIVER ASSISTANCE SYSTEMS

DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >



Ρ


Connector Nu. B78 Connector Nume WIE TO WIE: Connector Type NS16MW-CS Mail 1 2 6 7 Mail 9 10 11 2 16 7	Territinal Online Open-of Nume Supran Name Specification 2 V V Supran Name Specification 3 Sup V V V 3 Sup V V V 11 P V V V 12 V V V V 13 V N V V 13 V N V V 13 V N V V Connector Nume Connector Nume Connector Nume V Connector Nume Connector Nume Connector Num V Connector Num Connector Num Connector Num V 1 P V V V 1 P V V V 1 P V V V 1 P N N V 1 P N N	
	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 <td></td>	
88 83 84 0 0 88 85 0 0 88 88 88 88 88 88 88 88 88 88 88 88 88	94 94 96 66 61 98 98 98 98 98 98 10 0 0 99 99 10 10 10 10 99 10 10 10 10 10 10 1 1 1 10 11 11 10 11 12 12 10 11 10 11 10 11 10 11 10 11 10 11 10 11 10 11 10 11 10 11 10 11 10 11 10 11 10 11 10 11 10 11 10 11 10 10 10 11 10	
42 C 44 C 45 L 47 S 47 S 47 S 47 S 48 S 49 S 49 S 49 S 49 S 49 S 41 S 42 S 43 S 44 B 50 C 50 R	51 R,R 25 R,L 25 R,L 26 P,R 27 L,L 28 R,R 29 R,R 26 P,R 26 R,R 26 R,R 27 L,L 28 R,R 29 L,L 20 L,R 21 R,R 22 L,L 23 L,L 24 L,L 25 R,R 26 R,R 27 L,C 28 L,G 29 L,G 21 L,G 22 L,G 23 L,G 24 L 25 L,G 26 R,R 27 L,G 28 L,G 29 L 21 L 22 L <tr tr=""></tr>	
ER ASSISTANCE SYSTEMS	Object Of Wree Signal Name [Specification] Wite Signal Name [Specification] Wite Signal Name [Specification] Wite Signal Name [Specification] P - P - Vic - Vic - Vic - Vic - Nuc - Nic - Nuc	
DRIV Connecto Connecto Connecto	$ \begin{array}{c c} T_{0001} \\ T$	

JROWC1662GB

Ρ

DAS

< WIRING DIAGRAM >

А

В

С

D

Е

F

G

Н

J

Κ

L

Μ

Ν

24 P		29 × 1	26 W	27 R			3 BK	- H 20	33 C	37 ~ ~	35 L = -	41 P -	42 GR –	43 L =	44 W = -	45 SB	46 R		52 L - [Without automatic drive positioner]	52 P - [With automatic drive positioner]	53 L - [With automatic drive positioner]	53 P - [Without automatic drive positioner]	54 LG = [Without automatic drive positioner]	54 SB – [With automatic drive positioner]	55 LG – [With automatic drive positioner]	55 0 - [Without automatic drive positioner]		Connector No De41		Connector Name WIRE TO WIRE	Connector Type TH40FW-CS15	ó	E	+ S =						Terminal Color Of Simol Name [Samification]	No. Wire Signal Name (Specification)	- 6	2 V -	4 B -	5 W -	9	7 0 -	8 8
Gonnector No. D18		Connector Name BSW INDICATOR LH		Connector Lype TH04MW-NH	Æ	ANALY .	H.S.		4 1				Terminal Color Of Signal Name [Specification]	No. Wire		4 B GROUND		Connector No. D21		Connector Name WIRE TO WIRE	Connector Type TH40FW-CS15								Terminal Color Of	No. Wire Signal Name [Specification]	1 V –	2 G -	3 P -	4 B -	5 W	- SB -	7 P -	8 BR	9 GR -	10 V –		14 B -	15 LG -	16 G -	17 Y –	18 GR -	19 BR –	20 LG -
Treminal Color Of	No. Mo. Signal Name [Specification]	NO. WIFE	- ·	2 B -		A	CONTRECTOR INO. B93	Connector Name PUMP CONTROL UNIT		Connector Type NS12FW-CS	4	(AMA)	HS.		26			Terminal Color Of	No. Wire Signal Name [Specification]	1 W AIR PUMP POWER SUPPLY	2 B AIR PUMP GROUND	3 L REAR VIEW CAMERA WASHER RELAY 2 DRIVE SIGNAL	4 REAR VIEW CAMERA WASHER RELAY 1 DRIVE SIGNAL	5 B	6 SB -	7 V -		4 G REAR WINDOW WASHER STATUS SIGNAL 10 DD DEAD WINDOW WASHER SWITCH STONAL	10 DR REAR WINDOW WASHER SWITCH SIGNAL			Connector No. B96	Connector Name WIRE TO WIRE		Connector Type TK02MW	đ	(MHA)		1 0	<u> </u>				Terminal Color Of Control Color Of Colo	No. Wire Signal Name (Specification)		2 Y –	
RIVER ASSISTANCE SYSTEMS		/ GR WAHNING SYSTEMS SWITCH	R REVERSE	CAN-H	CAN-L	W COMMUNICATION SIGNAL (CAMERA- PUMP)			P R WASHER LEVEL SWITCH SIGNAL		-	actor No. B93	sctor Name CAMERA CONTROL UNIT		sctor type IH32FW-NH				65 67 68 71 72 73 74 75 75	73 80 81 82 83 87 88 89 90 91 92			nal Color Of Simul Name [Securitantica]	Wire Dignal Name Copecification	B CAMERA IMAGE SIGNAL	SHIELD CAMERA IMAGE SIGNAL GROUND	W CAMERA COMMUNICATION SIGNAL		R CAMERA IMAGE SIGNAL (+)	SHIELD CAMERA IMAGE SIGNAL (-)			ctor No. B94	ctor Name AIR PUMP		ctor type IKU2MW				I]	112							

JROWC1663GB



DRIVER ASSISTANCE SYSTEMS

[LDW]

JROWC1664GB

	Г	Π	Т	Τ	Π		Т	Т	Т	Т	Π				Π				Π			Т	Т	Т	Γ	Γ	Π	Т	Т	Т	Τ	Τ	Τ			Π	Π	
	-	1				1	1	'		1	-	-	-	1		1	1	1	-	1		1	,		-	T	1		1	h iPod without navigation system	hout iPod and navigation system]	 [With navigation system] 		-	-	1		
	*	:≻ (× -		a d.	_	B	GR	- <u>1</u> 6	GR	BR	Y	W/L	>	BR	0	L/0	HIELD	w	BR	×	SB	B S	ac >		w	BR	GR	0	G - [With	V – [Wit	~	~	æ	w	LG	0	
	29	30 2	8 g	66 97	47	48	49	93 i	5	53	54	55	56	60	61	62	63	64 S	99	67	89	69	02 F	62	73	74	75	76	1/	78	78	78	79	80	81	82	83	
MURT ASSISTANCE SYSTEMS worker File Connector Num Connector Num Connector Num Connector Num working File Connector Num WIE TO MIE Connector Num Connector Num Connector Num working File Connector Num WIE TO MIE Connector Num Connector Num working Signal Num Signal Num Signal Num Connector Num Connector Num mid Connector Num Signal Num Signal Num Connector Num Connector Num mid Connector Num Signal Num Connector Num Connector Num Connector Num mid Connector Num Connector Num Connector Num Connector Num Connector Num mid Connector Num Connector Num Connector Num Connector Num Connector Num mid Connector Num Connector Num Connector Num Connector Num Connector Num mid Connector Num Connector Num Connector Num Connector Num Connector Num mid Connector Num Connector Num Connector Num Connector Num <td< td=""><td>E29</td><td>REAR VIEW CAMERA WASHER RELAY 1</td><td>MS03ER-M2-I C</td><td>M0001D-M2-FC</td><td>Ę</td><td>-]</td><td></td><td>4 3 2</td><td></td><td></td><td>Cinnel Name [Constitued]</td><td></td><td>-</td><td>-</td><td>1</td><td>1</td><td>1</td><td></td><td></td><td>E105</td><td>WIRE TO WIRE</td><td></td><td>TH70MW-CS10-M3</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td>Signal Name [Specification]</td><td></td><td>-</td><td>-</td><td>-</td><td>1</td><td>1</td><td></td></td<>	E29	REAR VIEW CAMERA WASHER RELAY 1	MS03ER-M2-I C	M0001D-M2-FC	Ę	-]		4 3 2			Cinnel Name [Constitued]		-	-	1	1	1			E105	WIRE TO WIRE		TH70MW-CS10-M3								Signal Name [Specification]		-	-	-	1	1	
INTERASSISTANCE SYSTEMS Recention Ein control home Eine control home	Connector No.	Connector Name	Connector Type	comercial type	ß	S i					Terminal Color Of	No. Wire	1 W	2 R	3 0	4 0	5 B			Connector No.	Connector Name		Connector Type	Æ	0	21					Ferminal Color Of	No. Wire	3 ×	5 LG	6 GR	8	11 P	¢.
INTER ASSISTANCE SYSTEMS exervive. Eis evention. Eis evention. Eis evention. Eis evention. Eise evention. Eise Eise Frahlen Spacification] wer Assoss Fittemen Supervi of Restrict Posters Space of Restrict Posters Pressons environment of Restrict Posters	Connector No. E26	Connector Name WIRE TO WIRE	Connector Type NS02MW-CS		- E		1 2				Terminal Color Of Simal Name [Seedification]	No. Wire Organization	1 GR –	2 Y -			Connector No. E28	CN DEAD VIEW CAMEDA WASHED DEI AV 3		Connector Type MS03FB-M2-LC	1		H.S.		4 3 2		-	Terminal Color Of Signal Name [Specification]	No. Wire	- M	2 L –	3 GR -	4 GR –	5 W -				
	ANCE SYSTEMS]		5 ST 105 109	1 98 112 108 110	6 107 111	96 100 104 108 112		Mama [Constituation]		3R PEDAL POSITION SENSOR 1	DR PEDAL POSITION SENSOR 2	4SOR POWER SUPPLY	SENSOR GROUND	CD STEERING SWITCH	ROL SYSTEM PRESSURE SENSOR	ENSOR POWER SUPPLY	ATA LINK CONNECTOR	ENSOR POWER SUPPLY	SENSOR GROUND	IGNITION SWITCH	ANK TEMPERATURE SENSOR	SENSOR GROUND	MMUNICATION LINE(CAN-L)	MMUNICATION LINE(CAN-H)	SENSOR GROUND	PNP SIGNAL	SENSOR GROUND	WER SUPPLY FOR ECM	STOP LAMP SWITCH	ECM GROUND	ECM GROUND	ISTER VENT CONTROL VALVE	SCD BRAKE SWITCH	ECM GROUND	ECM GROUND
	SSIST	ECM	RH24FR-R78-I -I H			81 85 95	82 86 9	82 87 91 9		ļ	Simol	Billio	ACCELERATC	ACCELERATO	SEP		AS	EVAP CONT	SE	0	03			FIFLT		CAN CC	CAN CC				PO				EVAP CAN	×		-

Connector No. M1 Connector Name FUSE BLOCK (J/B) Connector Type In State BLOCK (J/B)	Terminal Color Of Nor. Signal Mame [Saedification] 2h 7 1 2 2h 1 2 2 2 2h 1 1 1 2 2h 1 2 2 2 2h 2 2 2 2 2h 2 2 2 2 <th></th>	
Connector No. F23 Connector Name Connector Type Connector Connecto	Terminal Mono Description Mono Signal Mannel Specification1 1 P. L Franksmitssion Randee Smitch - 3 2 P.L Franksmitssion Randee Smitch - 3 3 CO Tranksmitssion Randee Smitch - 3 4 GR Franksmitssion Randee Smitch - 3 9 L/G Tranksmitssion Randee Smitch - 3 9 L/G Constraintssion Randee Smitch - 3 10 BR/R Constraints-3 11 V/M Polomic - 0 12 V/M Polomic - 0 13 V/M Polomic - 0 14 V/M Polomic - 0 15 V/M Polomic - 0 16 V/M Polomic - 0 17 V/M Polomic - 0 18 V/M Polomic - 0 19 V/M Polomic - 0 10 RELIO Stratten RELIV 11 V/M Polomic - 0 12 P/G Stratten RELIV 13 L/G Strapoloro	
Connector No. E39 Connector Name WRE TO WRE Connector Type NISTER CS	Terminal No. Oxfor No. Signal Name (Specification) 4 0 0 1 2 0 1 2 0 1 2 0 1 2 0 1 2 0 1 2 0 1 2 0 1 2 0 1 2 0 1 2 0 1 2 0 1 2 0 1 2 0 1 2 0 1 2 0 1 2 0 1 2 0	
DRIVER ASSISTANCE SYSTEMS Connector Name Connector Name Monocontent Type Connector Type C	Terminal Color: Of Non- Signal Name (Specification) 2 0 0 2 0 0 Connector Na. E38 Connector Name MS-REI (LF/EL SWITCH Connector Name MS-REI (LF/EL SWITCH Connector Name 2025BR Taminal Color: Of No. 1 R 2 R	

DAS

Ρ

DRIVER ASSISTANCE SYSTEMS

А

В

С

D

Е

F

G

Н

J

Κ

L

Μ

Ν

JROWC1666GB



JROWC1667GB

	Π	T	Τ				T					T]			T]				T							T	T	T]				T								T							T			T	T	T	Ţ		
					1	1	1			-				1	1			T	,		I		1	-	Т	-			I	T	T	1			I		I	-	I	1					I	I	-	-	1		,			n.	L	T	T	
	16 R	> 0	° €	20 LG	21 Y	27 BR	2 I I	22 22	54 SB	25 Y	27 Y	- 0	28 H	30 ≺	31 W		32 BK	34 Y	а В		p ;	3/ Y	40 BK	41 LG	42 SB	46 G	4 1	2 G		4/ Y	48 GR	48 SHIELD	49 BR	ç	E 0	20 LG	ы 20	51 R	51 <	57 B		3 1 2 0	5 1	9	ъ 26	57 L	58 SB	59 R	59 SHIELD	8	, ≻		× 3	× :	22	64 Y	65 R	
	139	ARNING SYSTEMS SWITCH	KOBFGY						2 3 4 5 6 7						Signal Name [Specification]		1	1					'			1/1		(IRE TO WIRE		HBUFW-CS19											Signal Name [Specification]				1		-	-			,					1	1	
	Connector No. M	Connector Name W	Connector Type T		B		1.6							Terminal Color Of	No. Wire	;	2 BK	3 7	4 SB	; ;	-	20 0	7 GR			Connector No. M		Connector Name W		Connector Lype	ą	1		2.1						Terminal Color Of	No Wire	C HIEI D	0 1100	8 7	м е	4 R	6 W	7 G	8 SHIELD	л о	: a	2 :		8 G	1 I	14 R	15 SB	
	Connector No. M34	Connector Name COMBINATION METER	Connector Type TH40FW-NH		E		13.							Terminal Color Of	No. Wire Signal Name [Specification]		1 Y BALIERY POWER SUPPLY	2 LG IGN SIGNAL	3 B GROIND			2 2B ILLUMINATION CONTROL SIGNAL	8 SB TKIP RESET SIGNAL	9 W SWILL POWER	10 LG METER CONTROL SWITCH GROUND	11 L ENTER SWITCH SIGNAL	10 D CELECT PARTOL CTONIAL		Charge and a set of the set of th	14 GR ILLUMINATION CONTROL SWITCH SIGNAL (-)	15 BR AIR BAG SIGNAL	18 L AMBIENT SENSOR SIGNAL	19 P AMBIENT SENSOR POWER			ZI L CAN-H	22 P CAN-L	23 B GROUND	24 W FUEL LEVEL SENSOR GROUND	25 BR ALTERNATOR SIGNAL				29 R WASHER LEVEL SWITCH SIGNAL	30 P VEHICLE SPEED SIGNAL (2-PULSE)	31 V VEHICLE SPEED SIGNAL (8-PULSE)	32 LG OVERDRIVE CONTROL SWITCH SIGNAL	34 G FUEL LEVEL SENSOR SIGNAL	35 SB SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SIDE)	36 R SEAT RELEARING E SWITCH SIGNAL (PASSENGER SIDE)								
IVER ASSISTANCE SYSTEMS	- -	> 4	GR - [With automatic drive positioner]	R = [Without automatic drive positioner]	L - [With automatic drive positioner]	V = [Without automatic drive nositioner]	 Contract automatic drive posterior C = [Without automatic drive notitionar] 		Lu – [With automatic drive positioner]	GR – [Without automatic drive positioner]	SB = [With automatic drive positioner]				cor No. M26		or Name VIRE TO WIRE		ar Type NSD2EW-CS]	1 2]			Color OT Signal Name [Specification]	Wire C	- 5	-				r No. M30	C Name CTEEDING ANGLE SENSOD		r Tvpe TH08FW-NH		[K		4 2		c]		Color Of	Wire Signal Name [Specification]		-		י פ			

DRIVER ASSISTANCE SYSTEMS

А

В

С

D

Е

F

G

Н

J

Κ

L

Μ

Ν

DAS

Ρ

JROWC1668GB

	ASSISTANCE SYSTEMS	Connec:	tor No.	M103	8	8	NATS ANT AMP.	83	п	
- I	-	Connect	tor Name	COMBINATION SWITCH	81	0	NATS ANT AMP.	87 W	MICROPHONE SIGNAL	
>					82	æ	IGN RELAY (F/B) CONT	88 88		
9	1	Connec	tor Type	TH16FW-NH	83	۵	KEYLESS ENTRY RECEIVER COMM	89 W	I.	
>	-	ģ			87	æ	COMBI SW INPUT 5	90 F	CAN-H	
ă	-	And A		ľ	88	Я	COMBI SW INPUT 3	91 SB	AV COMM (H)	
J	1	Ĕ	7		6	٩	CAN-L	92 SB	AV COMM (H)	
SHIE	LD –		9	1 2 3 4 5 6	91	_	CAN-H			
-	-			7 8 9 10 11 12 13 14	92	æ	KEY SLOT ILL CONT			
٩	-				93	۵.	ON IND			
ΓC					95	L	ACC RELAY CONT			
>	-				96	>	CVT SHIFT SELECTOR POWER SUPPLY			
۳	-	Termin	al Color C	f Signal Name [Snecification]	66	>	SHIFT P			
٩		Ň	Wire		10	٩	PASSENGER DOOR REQUEST SW			
-		-	G	-	101	>	DRIVER DOOR REQUEST SW			
ä	-	2	>	OUTPUT 4	102	>	BLOWER RELAY CONT			
8	-		BG	FR	103		KEYLESS ENTRY RECEIVER POWER SUPPLY			
5	-	4	M	IGN	107	0	COMBI SW INPUT 1			
	-	5	>	OUTPUT 3	108	٩	COMBI SW INPUT 4			
	-	9	8	GROUND	109	SB	COMBI SW INPUT 2			
ß	 - [Without automatic drive positioner] 	2	GR	INPUT 3	110	0	HAZARD SW			
*	 [With automatic drive positioner] 	8	-	OUTPUT 5						
œ	1	6	SB	INPUT 2						
>	-	10	٩	INPUT 4	Conne	ctor No.	M180			
>		Ξ	0	INPUT 1	Conne	ctor Name	AV CONTROL LINIT			
æ	-	12	W	OUTPUT 1						
9	-	13	æ	INPUT 5	Conne	ctor Type	TH32FW-NH			
8	-	14	٩	OUTPUT 2	Į					
>	-				E					
U	-				Ę	v				
BF	- 2	Connec	tor No.	M122		5	65 67 68 71 72 73 74 75 78			
٩	I	Connect	tor Name	BCM (BODY CONTROL MODULE)			79 80 81 82 83 89 89 90 91 92			
>	-	20100								
W	-	Connec	tor Type	TH40FB-NH						
SE		ģ								
-	1	B			Termi	nal Color C	F Cinnel Manue [Canaification]			
F	-	Ĕ			.oN	Wire	OBUSI MAILIC CONCULICATION			
^		Ĩ	9		65	ΓC	PARKING BRAKE			
		1		21 20 20 20 20 21 21 20 21 21 22 22 22 22 22 22 22 22 22 22 22	67	-				
					68	91				
					12	SHIELD	SHIELD			
					- 12	6	MICROPHONE VCC			
		Tarmine	o voloci le	-	1	0	COMM (CONT-DISD)			
		No	Wire	Signal Name [Specification]	2 2	- 0	CANEL			
		52	•	DOOM ANT-	35					
		21	3	BOOM ANT+	JR.	3 9	AV COMM (1)			
		74	: >	PASSENGER DOOR ANT-	62	α.	TI LIMINATION SIGNAL			
		75	-	PASSENGER DOOR ANT+	8		IGNITION			
		92	} >	DRIVER DOOR ANT-	8 8	, 6	BEVERSE			
		1	-	DBIVED DOOD ANT+	6	: 	VEUTOLE SPEED SIGNAL (9-DHILSE)			

JROWC1669GB

BASIC INSPECTION DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000009723223

OVERALL SEQUENCE



DETAILED FLOW

1.INTERVIEW FOR MALFUNCTION

It is also important to clarify the customer concerns before starting the inspection. Interview the customer about the concerns carefully and understand the symptoms fully. **NOTE:**

А

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

The customers are not professionals. Never assume that "maybe the customer means..." or "maybe the customer mentioned this symptom".

>> GO TO 2.

2.SELF-DIAGNOSIS WITH CONSULT

- 1. Perform "All DTC Reading" with CONSULT.
- 2. Check if the DTC is detected on the self-diagnosis results of "AVM".
- 3. When DTC is detected, follow the instructions below:
- Record DTC and Freeze Frame Data.

Is any DTC detected?

YES >> GO TO 5.

NO >> GO TO 3.

3. PRE-INSPECTION FOR DIAGNOSIS

Perform pre-inspection for diagnosis. Refer to DAS-47, "Inspection Procedure".

>> GO TO 4.

4.ACTION TEST

Perform LDW system action test to check the operation status. Refer to DAS-49, "Description".

>> GO TO 6.

5.TROUBLE DIAGNOSIS BY DTC

- 1. Check the DTC in the self-diagnosis results.
- Perform trouble diagnosis for the detected DTC. Specify a malfunctioning part. Refer to <u>DAS-30, "DTC</u> <u>Index"</u> (AVM).

>> GO TO 8.

6.SYMPTOM DIAGNOSIS

Perform symptom diagnosis. Specify malfunctioning part. Refer to <u>DAS-87, "Symptom Table"</u>.

>> GO TO 7.

7.MALFUNCTION PART REPAIR

Repair or replace the identified malfunctioning parts.

>> GO TO 8.

8.REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT)

Perform self-diagnosis with CONSULT. Check that any DTC is not detected. Erase DTC if DTC is detected before the repair. Check that DTC is not detected again.

Is any DTC detected?

YES \Rightarrow GO TO 5. NO \Rightarrow GO TO 9. **9.** REPAIR CHECK (ACTION TEST)

Perform LDW system action test. Also check the system operation.

Does it operate normally?

YES >> INSPECTION END NO >> GO TO 4.

PRE-INSPECTION FOR DIAGNOSIS

[LDW]

< BASIC INSPECTION > [LDW]	
PRE-INSPECTION FOR DIAGNOSIS	Λ
Inspection Procedure	A
1. CHECK REAR VIEW CAMERA LENS	В
1.check REAR VIEW CAMERA LENS Are rear view camera lens contaminated with foreign materials? YES >> Clean rear view camera lens. NO >> GOTO. 2.check REAR VIEW CAMERA INSTALLATION CONDITION Check rear view camera installation condition (e.g. position, looseness, bent in back door). Isi property installed? YES >> INSPECTION END NO >> Install rear view camera property, and perform rear view camera calibration. Refer to <u>DAS-53</u> . "Description".	B C D E F G H I J K L M N
	Ρ

REAR VIEW CAMERA WASHER/AIR BLOWER FUNCTION INSPECTION

< BASIC INSPECTION >

REAR VIEW CAMERA WASHER/AIR BLOWER FUNCTION INSPECTION

Inspection Procedure

INFOID:000000009723225

[LDW]

1.CHECK REAR VIEW CAMERA WASHER/AIR BLOWER FUNCTION

- 1. Start the engine.
- Select the ACTIVE TEST item "AIR&WASH ACTIVE" of "AVM" with CONSULT. NOTE:
 - Before function check, perform the following items:
 - Fill with washer fluid.
 - Perform ACTIVE TEST item "WASH ACTIVE" of "AVM" with CONSULT for 4 seconds.
- 3. With operating the test item, check the operation.

Is it properly operated?

Washer fluid ejects 2 or 3 times. (Normal function)>>INSPECTION END.

Washer fluid ejects 4 times or more.>>Properly install or replace air tube.

Washer fluid ejects only once>> Properly install or replace air tube.

Washer fluid does not eject>>Properly install washer tube or replace washer tube and check valve.

ACTION TEST

< BASIC IN	SPECTION >		_		[LDW]
ACTION	TEST				
Descriptio	n			INFC	/ DID:000000009723226
 Perform ac Perform ac WARNING: Be careful of 	ction test to verify the custo ction test and check the sys	mer's concern. tem operation a afety around th	fter system dia	ignosis. en performing road test.	E
CAUTION: Fully under • Precautio • System de • Handling	stand the following items ns: Refer to <u>DAS-6, "FOR</u> escription for LDW: Refer precaution: Refer to <u>DAS</u>	well before the USA AND CAN to DAS-12, "Sy -20, "Precaution	e road test; IADA : Precau /stem Descrip ns for Lane D	ition for LDW System Servi otion". eparture Warning".	(ice".
Inspectior	n Procedure			INFC	ND:000000009723227
WARNING: Be careful of CAUTION: Fully under • Precautio • System do • Handling 1.CHECK I	of traffic conditions and s stand the following items ns: Refer to <u>DAS-6, "FOR</u> escription for LDW: Refer precaution: Refer to <u>DAS</u> LDW SYSTEM SETTING	afety around th well before the <u>USA AND CAN</u> to <u>DAS-12, "Sy</u> -20, "Precaution	e vehicle whe road test; IADA : Precau (stem Descrip ns for Lane D	en performing road test. I <u>tion for LDW System Servi</u> I <u>tion"</u> . Ieparture Warning".	i <mark>ce"</mark> .
 Start the Check t Turn OF Check t 	e engine. hat the LDW system setting F the ignition switch and w hat the previous setting is s	can be enabled ait for 30 second aved when the e	l/disabled on tl ds or more. engine starts a	ne navigation screen. gain.	ŀ
>> 2.action	GO TO 2. TEST FOR LDW				
 Enable Turn wa Check t 	the setting of the LDW systerning systems switch ON (Non- ne LDW operation accordin	em on the navig varning systems g to the followin	ation screen. ON indicator i g table.	s ON).	ł
Vehicle	condition/ Driver's operation	Action	Warning sys- tems ON indi- cator	Indication on the combination meter	Buzzer
					Γ

DAS

Ν

Less than Approx. 60 km/h (40 MPH)

Close to lane marker

ON

(Green) ON

JPOIA0021GB

No action

ACTION TEST

< BASIC INSPECTION >

[LDW]

Vehicle co	ondition/ Driver's operation	Action	Warning sys- tems ON indi- cator	Indication on the combination meter	Buzzer
Approx. 70 km/h (45	Close to lane marker	Warning • Buzzer sounds • Warning lamp blinks	ON	(Green) ON Blink ON JPOIA0022GB	Short con- tinuous beeps
MPH) or more	 Close to lane marker Turn signal ON (Deviate side) 	No action	ON	(Green) ON JPOIA0021GB	_

NOTE:

After the operating conditions of warning are satisfied, the warning continues until the vehicle speed reaches approximately 60 km/h (40 MPH). Refer to <u>DAS-12</u>, "System Description".

>> INSPECTION END

ADDITIONAL SERVICE WHEN REPLACING CAMERA CONTROL UNIT	
< BASIC INSPECTION > [LDW]	
ADDITIONAL SERVICE WHEN REPLACING CAMERA CONTROL UNIT	Δ
Description	7.1
 Always perform the camera control unit configuration after replacing the camera control unit. Always perform the rear view camera calibration after removing and installing or replacing the rear view camera 	В
 Always perform the rear view camera calibration after replacing the camera control unit. 	C
The system does not operate normally unless the rear view camera calibration is performed. Always perform it.	C
Work Procedure	D
1.CAMERA CONTROL UNIT CONFIGURATION	F
Perform the camera control unit configuration with CONSULT. Refer to <u>DAS-52, "Description"</u> .	
>> GO TO 2. 2.REAR VIEW CAMERA CALIBRATION	F
Perform the rear view camera calibration with CONSULT. Refer to <u>DAS-53, "Work Procedure (Preparation)"</u> .	G
>> GO TO 3.	
3. PERFORM SELF-DIAGNOSIS	Н
Perform the self-diagnosis of camera control unit with CONSULT (AVM). Check if any DTC is detected. Is any DTC detected?	
 YES >> Perform the trouble diagnosis for the detected DTC. Refer to <u>DAS-30, "DTC Index"</u>. NO >> GO TO 4. 	
4.LDW SYSTEM ACTION TEST	J
 Perform the LDW system action test. Refer to <u>DAS-49</u>. "<u>Description</u>". Check that the LDW system operates normally. 	
>> WORK END	K
	L
	M
	Ν

DAS

CONFIGURATION (CAMERA CONTROL UNIT)

< BASIC INSPECTION >

CONFIGURATION (CAMERA CONTROL UNIT)

Description

INFOID:000000009723230

[LDW]

- Since vehicle specifications are not included in the camera control unit after replacement, it is required to write vehicle specifications with CONSULT.
- Configuration has three functions as follows.

Fu	nction	Description
Road/Write Configuration	Before Replace ECU	Allows the reading of vehicle specification written in camera con- trol unit to store the specification in CONSULT.
Read/write Conliguration	After Replace ECU	Allows the writing of the vehicle information stored in CONSULT into the camera control unit.
Manual Configuration		Allows the writing of the vehicle specification into the camera con- trol unit by hand.

Work Procedure

INFOID:000000009723231

1.SAVING VEHICLE SPECIFICATION

CONSULT Configuration

Perform "Before Replace ECU", and save the current vehicle specification in CONSULT.

>> GO TO 2.

2.REPLACE CAMERA CONTROL UNIT

Replace camera control unit. Refer to DAS-94, "Removal and Installation".

>> GO TO 3.

3.write vehicle specification

CONSULT Configuration

Write vehicle specification into camera control unit.

To write vehicle specification stored in CONSULT into the camera control unit>>GO TO 4. To write vehicle specification into the camera control unit by hand>>GO TO 5.

4.WRITE STORED DATA

CONSULT Configuration

Select "After Replace ECU" in "Read/Write Configuration." Write data stored in CONSULT with the "Before Replace ECU" function into the camera control unit.

>> GO TO 6.

5.MANUALLY WRITE VEHICLE SPECIFICATION

CONSULT Configuration

Perform "Manual Configuration." to write vehicle specification into the camera control unit.

NOTE:

If selection items are not displayed on the CONSULT screen, touch "NEXT".

>> GO TO 6.

6. OPERATION CHECK

Check that the operation of the camera control unit and camera images (fixed guide lines and predictive course lines) are normal.

>> WORK END

< BASIC INSPECTION > [LDW]
CALIBRATING CAMERA IMAGE (REAR VIEW CAMERA)
Description INFOID:00000009723232
 Always perform the rear view camera calibration after removing and installing or replacing the rear view camera. Always perform the rear view camera calibration after replacing the camera control unit. CAUTION:
 Place the vehicle on level ground when the calibration is operated. Follow the CONSULT when performing the calibration. (Rear view camera calibration cannot be operated without CONSULT.)
Work Procedure (Preparation)
1.PERFORM SELF-DIAGNOSIS
Perform self-diagnosis of the camera control unit with CONSULT (AVM). <u>Is any DTC detected?</u>
Except "U1308">>Perform diagnosis on the detected DTC and repair or replace the applicable item. Refer to <u>DAS-30, "DTC Index"</u> . "U1308" or no DTC>>GO TO 2.
2. PREPARATION BEFORE REAR VIEW CAMERA CALIBRATION
 Perform pre-inspection for diagnosis. Refer to <u>DAS-47, "Inspection Procedure"</u>. Adjust the tire pressure to the specified pressure value. Maintain no-load in vehicle. Check if coolapt and engine oil are filled up to correct level and fuel tank is full.
 Shift the selector lever to "P" position and release the parking brake. Clean the rear view camera.

>> GO TO 3.

3. PREPARATION OF CALIBRATION TARGET MARK

Prepare six sheets of white paper and black paper, respectively, with dimensions of 200 mm (7.87 in) × 200 mm (7.87 in) to create a left target, right target, and center target.
 NOTE:

Correct the magnification of print and print the target mark sample in the service manual on the black paper. Refer to <u>DAS-57, "Work Procedure (Target Mark Sample)"</u>.

- 2. Tape two sheets of black paper and two sheets of white paper together to make a target of 400 mm (15.75 in) \times 400 mm (15.75 in).
 - W : 200 mm (7.87 in)
 - L : 200 mm (7.87 in)

NOTE:

Use a transparent tape.



3. Create two more targets according to step 2.

Ρ

J

Κ

< BASIC INSPECTION >



(A) Left target and right target Side of the square target: 400 mm (15.75 in) Side of the black or white area: 200 mm (7.87 in)

>> Go to DAS-54, "Work Procedure (Target Setting)".

Work Procedure (Target Setting)

INFOID:000000009723234

CAUTION:

- Perform this operation in a horizontal position where there is a clear view for 3 m (9.84 ft) backward and 4 m (13.12 ft) wide.
- Place the target in a well-lighted location. (Poor lighting may make it hard to adjust.)

(B) Center target

- The target may not be detected when it shines by the reflected light of the sun or lighting.
- The target may not be detected when there is the same pattern of black and white as the target when the pattern is within 0.5 m (1.64 ft) from either side and upward/downward position from the target. (It is desirable that the target is positioned on the single-color floor.)

1.TARGET SETTING



< BASIC INSPECTION >

А

F

Н

Distance between B and E (D and F): 1775 mm (69.88 in)Distance between Ct and Lt (Ct and Rt): 1470 mm (57.87 in)

1. 1. Mark points "A", "B", "C" and "D" at the center of the lateral surface of each wheel.

NOTE:

Hang a string with a cone from the fender so as to pass through the center of wheel, and then mark a point at the center of the lateral surface of the wheel.

2. Draw line "LH" passing through points "A" and "B" on the left side of vehicle.

NOTE:

Approximately 2.2 m (7.22 ft) or more at the rear from the rear axle.

- Mark point "E" on the line "LH" at the positions 1775 mm (69.88 in) from point "B".
- 4. Draw line "RH" passing through points "C" and "D" on the right side of vehicle in the same way as step 2.
- 5. Mark point "F" on the line "RH" at the positions 1775 mm (69.88 in) from point "D".
- Draw line "RW" passing through the points "E" and "F" on the rear of vehicle. NOTE:

Approximately 1.8 m (5.91 ft) or more at both left and right sides from vehicle center.

7. Mark point "Ct" at the center of point "E" and "F" on the line "RW". CAUTION:

Make sure that "E" to "Ct" is equal to "F" to "Ct".

- 8. Mark point "Lt" and "Rt" on the line "RW" at the positions 1470 mm (57.87 in) from point "Ct".
- 9. Position the center of the target mark to point of "Ct", "Lt" and "Rt". CAUTION:

To perform an accurate calibration, check that the black-and-white pattern is as shown in the figure. The pattern of the center target differs from that of right/left target.



>> Go to DAS-55, "Work Procedure (Rear View Camera Calibration)".

Work Procedure (Rear View Camera Calibration)

CAUTION:

For accuracy, perform the calibration under the specified vehicle condition (Fuel full, no-load, specified tire pressure, etc.). Refer to <u>DAS-53, "Work Procedure (Preparation)"</u>.

1.CHECK REAR VIEW CAMERA HEIGHT



INFOID:000000009723235

Ρ

< BASIC INSPECTION >

Measure the rear view camera height.



H: Rear view camera height.

>> GO TO 2.

2.REAR VIEW CAMERA CALIBRATION

- 1. Select "Work Support" on "AVM" with CONSULT.
- 2. Select "REAR CAMERA ITS" and then touch "Start"
- 3. Touch "OK".
- 4. Input the rear view camera height "H", and then touch "APPLY".
- 5. Confirm that the same value is displayed on the center display.
- 6. Confirm the following items;
- The target should be accurately placed.
- The vehicle should be stopped.
- The vehicle should be under the specified vehicle condition.
- 7. Select "Start" to perform camera aiming.
- CAUTION:

To properly maintain vehicle attitude, operate CONSULT outside the vehicle with all the doors closed.

- 8. Confirm the displayed item.
- "Completed": Select "Completion".
- "Not completed": Perform the following services.

Displayed item	Possible causes	Service procedure
	Target mark position is incorrect.	Set target mark as specified. Refer to <u>DAS-54, "Work Procedure (Target</u> <u>Setting)"</u> .
Check the error contents using the screen of navigation system.	Target mark direction is incorrect.	Set target mark direction as shown in the fig- ure. Refer to <u>DAS-54, "Work Procedure (Target</u> <u>Setting)"</u> .
	Target mark reflects the light.	Shut out the light reflecting on target mark.

>> GO TO 3.

3.PERFORM SELF-DIAGNOSIS

Perform self-diagnosis of camera control unit with CONSULT (AVM).

Is any DTC detected?

YES >> Perform diagnosis on the detected DTC and repair or replace the applicable item. Refer to <u>DAS-</u> <u>30, "DTC Index"</u>.

- NO >> GO TO 4.
- **4.**ACTION TEST

CALIBRATING CAMERA IMAGE (REAR VIEW CAMERA) [LDW] < BASIC INSPECTION > Test the system operation by action test. Refer to DAS-49. "Description". А >> WORK END Work Procedure (Target Mark Sample) INFOID:000000009723236 В NOTE: Change the magnification of print to 200 mm (7.87 in) \times 200 mm (7.87 in) and print the target mark sample. С D Е F G Н J Κ L

Μ

Ν

Revision: 2013 August

[LDW]

DTC/CIRCUIT DIAGNOSIS C1A03 VEHICLE SPEED SENSOR

DTC Logic

INFOID:000000009723237

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
C1A03	VHCL SPEED SE CIRC	If the vehicle speed signal (wheel speed) from ABS actuator and electric unit (control unit) re- ceived by the camera control unit via CAN com- munication, are inconsistent	 Wheel speed sensor ABS actuator and electric unit (control unit) Camera control unit

NOTE:

If DTC "C1A03" is detected along with DTC "U1000" or "C1A04", first diagnose the DTC "U1000" or "C1A04".

Refer to <u>DAS-64, "DTC Logic"</u> for DTC "U1000".
Refer to <u>DAS-59, "DTC Logic"</u> for DTC "C1A04".

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Start the engine.

- Turn the LDW system ON. 2.
- 3. Drive the vehicle at 30 km/h (19 MPH) or more. **CAUTION:**

Always drive safety.

- 4. Stop the vehicle.
- 5. Perform "All DTC Reading" with CONSULT.
- Check if the "C1A03" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "C1A03" detected as the current malfunction?

- YES >> Refer to DAS-58, "Diagnosis Procedure".
- >> Refer to GI-44, "Intermittent Incident". NO

Diagnosis Procedure

INFOID:000000009723238

1.CHECK SELF-DIAGNOSIS RESULTS

Check if "C1A04" or "U1000" is detected other than "C1A03" in "Self Diagnostic Result" of "AVM".

Is any DTC detected?

YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to DAS-30. "DTC Index".

NO >> GO TO 2.

2.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to BRC-111, "DTC No. Index".
- NO >> Replace the camera control unit. Refer to DAS-94, "Removal and Installation".

C1A04 ABS/TCS/VDC SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

C1A04 ABS/TCS/VDC SYSTEM

DTC Logic

А

INFOID:000000009723239

DIC	Trouble diagnosis name	DTC detecting condition	Possible causes
C1A04	C1A04 ABS/TCS/VDC CIRC If a malfunction occurs in the VDC/TCS/ABS ABS actuator and electric unit (control unit)		ABS actuator and electric unit (control unit)
I OTE: DTC "C1A ogic".	.04" is detected along w	vith DTC "U1000", first diagnose the DT	C "U1000". Refer to <u>DAS-64, "DTC</u>
TC CONF	IRMATION PROCED	DURE	
.PERFOF	M DTC CONFIRMATIC	N PROCEDURE	
. Start the	engine.		
2. Wait for	approximately 10 minu	tes after turning the LDW system ON.	
. Check i	f the "C1A04" is detected	ed as the current malfunction in "Self Dia	agnostic Result" of "AVM".
s "C1A04" (detected as the current	malfunction?	-
YES >>	Refer to DAS-59, "Diag	Inosis Procedure".	
NO >>	Refer to <u>GI-44, "Interm</u>	lttent Incident".	
Diagnosis	Procedure		
agnoon			INFOID:00000000972324
	SELF-DIAGNOSIS RES	SULTS	INFOID:00000000972324
CHECK	SELF-DIAGNOSIS RES	SULTS	INFOID:00000000972324
CHECK	SELF-DIAGNOSIS RES "All DTC Reading" with f the "U1000" is detected	SULTS n CONSULT. d other than "C1A04" in "Self Diagnosti	INFOID:00000000972324 c Result" of "AVM".
CHECK Perform Check i <u>s "U1000" o</u> YES >>	SELF-DIAGNOSIS RES "All DTC Reading" with f the "U1000" is detecte letected? Perform the CAN com	SULTS n CONSULT. d other than "C1A04" in "Self Diagnosti munication system inspection. Repair o	INFOID:0000000972324
CHECK : Perform Check i <u>s "U1000" c</u> YES >>	SELF-DIAGNOSIS RES "All DTC Reading" with f the "U1000" is detected letected? Perform the CAN comp Refer to <u>DAS-64, "DTC</u>	SULTS n CONSULT. d other than "C1A04" in "Self Diagnosti munication system inspection. Repair of <u>5 Logic"</u> .	INFOID:0000000972324 c Result" of "AVM". or replace the malfunctioning parts
L.CHECK Perform C. Check i <u>s "U1000" c</u> YES >> NO >>	SELF-DIAGNOSIS RES "All DTC Reading" with f the "U1000" is detected letected? Perform the CAN comp Refer to <u>DAS-64, "DTC</u> GO TO 2.	SULTS n CONSULT. d other than "C1A04" in "Self Diagnosti munication system inspection. Repair o <u>Clogic"</u> .	INFOID:0000000972324 c Result" of "AVM". or replace the malfunctioning parts
CHECK Perform Check i <u>s "U1000" c</u> YES >> NO >> 2.CHECK	SELF-DIAGNOSIS RES "All DTC Reading" with f the "U1000" is detected letected? Perform the CAN comi Refer to <u>DAS-64, "DTC</u> GO TO 2. ABS ACTUATOR AND	SULTS n CONSULT. d other than "C1A04" in "Self Diagnosti munication system inspection. Repair of <u>Logic</u> ". ELECTRIC UNIT (CONTROL UNIT) SE	INFOID:0000000972324 c Result" of "AVM". or replace the malfunctioning parts ELF-DIAGNOSIS RESULTS
LCHECK : Perform Check i S <u>"U1000" (</u> YES >> NO >> CHECK / Check if any	SELF-DIAGNOSIS RES "All DTC Reading" with f the "U1000" is detected letected? Perform the CAN comp Refer to <u>DAS-64, "DTC</u> GO TO 2. ABS ACTUATOR AND r DTC is detected in "Se	SULTS n CONSULT. d other than "C1A04" in "Self Diagnosti munication system inspection. Repair of <u>Logic</u> ". ELECTRIC UNIT (CONTROL UNIT) SE elf Diagnostic Result" of "ABS".	INFOID:0000000972324 c Result" of "AVM". or replace the malfunctioning parts ELF-DIAGNOSIS RESULTS
L.CHECK : Perform C. Check i S <u>"U1000" of</u> YES >> NO >> CHECK i Check if any S any DTC	SELF-DIAGNOSIS RES "All DTC Reading" with f the "U1000" is detected letected? Perform the CAN comp Refer to <u>DAS-64, "DTC</u> GO TO 2. ABS ACTUATOR AND DTC is detected in "Se detected?	SULTS n CONSULT. d other than "C1A04" in "Self Diagnosti munication system inspection. Repair of <u>Logic</u> ". ELECTRIC UNIT (CONTROL UNIT) SE elf Diagnostic Result" of "ABS".	INFOID:0000000972324 c Result" of "AVM". or replace the malfunctioning parts ELF-DIAGNOSIS RESULTS
LCHECK : Perform Check i S <u>"U1000" c</u> YES >> NO >> CHECK : Check if any S any DTC YES >>	SELF-DIAGNOSIS RES "All DTC Reading" with f the "U1000" is detected letected? Perform the CAN comp Refer to <u>DAS-64, "DTC</u> GO TO 2. ABS ACTUATOR AND DTC is detected in "Se detected? Perform diagnosis on t BRC-111, "DTC No. Inc	SULTS The CONSULT. d other than "C1A04" in "Self Diagnosti munication system inspection. Repair of <u>Logic</u> ". ELECTRIC UNIT (CONTROL UNIT) SE elf Diagnostic Result" of "ABS". the detected DTC and repair or replaced dex"	INFOID:0000000972324 c Result" of "AVM". or replace the malfunctioning parts ELF-DIAGNOSIS RESULTS

DAS

Ν

C1A39 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

C1A39 STEERING ANGLE SENSOR

DTC Logic

INFOID:000000009723241

INFOID-00000009723242

[LDW]

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
C1A39	STRG SEN CIR	If the steering angle sensor is malfunction	Steering angle sensor

NOTE:

If DTC "C1A39" is detected along with DTC "U1000", first diagnose the DTC "U1000". Refer to <u>DAS-64, "DTC</u> <u>Logic</u>".

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

- 1. Turn the ignition switch ON.
- 2. Perform "All DTC Reading" with CONSULT.
- 3. Check if the "C1A39" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "C1A39" detected as the current malfunction?

- YES >> Refer to DAS-60, "Diagnosis Procedure".
- NO >> Refer to GI-44, "Intermittent Incident".

Diagnosis Procedure

1.CHECK SELF-DIAGNOSIS RESULTS

Check if "U1000" is detected other than "C1A39" in "Self Diagnostic Result" of "AVM".

Is "U1000" detected?

YES >> Perform the CAN communication system inspection. Repair or replace the malfunctioning parts. Refer to <u>DAS-64. "DTC Logic"</u>.

NO >> GO TO 2.

2.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to <u>BRC-111, "DTC No. Index"</u>.
- NO >> Replace the camera control unit. Refer to <u>DAS-94, "Removal and Installation"</u>.

U0122 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< DTC/CIRCUIT DIAGNOSIS >

U0122 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

DTC Logic

INFOID:000000009723243

[LDW]

А

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U0122	VDC P-RUN DIAGNO- SIS	If camera control unit detects an error signal that is received from ABS actuator and electric unit (control unit) via CAN communication	ABS actuator and electric unit (control unit)
NOTE: f DTC "U012 <u>₋ogic"</u> .	2" is detected along wi	th DTC "U1000", first diagnose the DTC	C "U1000". Refer to <u>DAS-64, "DTC</u>
DTC CONFI	RMATION PROCED	JRE	
1.PERFORM	I DTC CONFIRMATIO	N PROCEDURE	
 Start the Turn the Perform Check if 	engine. LDW system ON. 'All DTC Reading" with the "U0122" is detected	CONSULT. I as the current malfunction in "Self Dia	gnostic Result" of "AVM".
<u>s "U0122" de</u>	etected as the current m	nalfunction?	
YES >> F	Refer to <u>DAS-61, "Diagr</u>	nosis Procedure". topt Incident"	
No 221	Procoduro	tent incident.	
Jiagnosis	FIOCEDUIE		INFOID:0000000972324
1. CHECK S	ELF-DIAGNOSIS RES	JLTS	
Check if "U10	000" is detected other th	nan "U0122" in "Self Diagnostic Result"	of "AVM".
<u>s "U1000" de</u>	etected?		
YES >> F	Perform the CAN comm Refer to <u>DAS-64, "DTC</u>	nunication system inspection. Repair o Logic".	r replace the malfunctioning parts
	BS ACTUATOR AND E	LECTRIC UNIT (CONTROL UNIT) SE	LF-DIAGNOSIS RESULTS
Check if any	DTC is detected in "Sel	f Diagnostic Result" of "ABS".	
s any DTC d	<u>etecteu :</u> Perform diagnosis on th	e detected DTC and repair or replace	the malfunctioning parts. Pofor to
<u>s any DTC d</u> YES >> F	<u>erected ?</u> Perform diagnosis on th <u>BRC-111, "DTC No. Inde</u>	e detected DTC and repair or replace	the malfunctioning parts. Refer to

DAS

Ν

U0416 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< DTC/CIRCUIT DIAGNOSIS >

U0416 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

DTC Logic

INFOID:000000009723245

[LDW]

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U0416	VDC CHECKSUM DI- AGNOSIS	If camera control unit detects an error signal that is received from ABS actuator and electric unit (control unit) via CAN communication	ABS actuator and electric unit (control unit)

NOTE:

If DTC "U0416" is detected along with DTC "U1000", first diagnose the DTC "U1000". Refer to <u>DAS-64, "DTC</u> <u>Logic</u>".

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Start the engine.

- 2. Turn the LDW system ON.
- 3. Perform "All DTC Reading" with CONSULT.
- 4. Check if the "U0416" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U0416" detected as the current malfunction?

YES >> Refer to DAS-62, "Diagnosis Procedure".

NO >> Refer to GI-44, "Intermittent Incident".

Diagnosis Procedure

INFOID:000000009723246

1.CHECK SELF-DIAGNOSIS RESULTS

Check if "U1000" is detected other than "U0416" in "Self Diagnostic Result" of "AVM".

Is "U1000" detected?

YES >> Perform the CAN communication system inspection. Repair or replace the malfunctioning parts. Refer to <u>DAS-64, "DTC Logic"</u>.

NO >> GO TO 2.

2.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to <u>BRC-111, "DTC No. Index"</u>.
- NO >> Replace the camera control unit. Refer to <u>DAS-94, "Removal and Installation"</u>.

U0428 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

U0428 STEERING ANGLE SENSOR

DTC Logic

А

INFOID:000000009723247

[LDW]

DIC	Trouble diagnosis name	DTC detecting condition	Possible causes
U0428	ST ANGLE SENSOR CALIBRATION	The neutral position adjustment of the steering angle sensor is incomplete.	 Neutral position of steering angle sensor is not yet adjusted Steering angle sensor
I OTE: DTC " <u>ogic"</u> .	U0428" is detected al	long with DTC "U1232", first diagnose the DTC "	U1232". Refer to <u>DAS-68, "DTC</u>
Diagno	osis Procedure		INF01D:000000009723248
.ADJI	JST THE NEUTRAL I	POSITION OF THE STEERING ANGLE SENSC	R
Vhen U	0428 is detected, adj	ust the neutral position of the steering angle sen	sor.
	>> Perform adjustm <u>"ADJUSTMENT</u>	ent of the neutral position of the steering a OF STEERING ANGLE SENSOR NEUTRA	ngle sensor. Refer to <u>BRC-9.</u> _ POSITION : Special Repair
AUTIC	<u>Requirement"</u> .		
or veh nit sid	iicles with VDC, adju e.	ust the steering angle sensor neutral position	n on the ABS actuator control

U1000 CAN COMM CIRCUIT

Description

CAN (Controller Area Network) is a serial communication line for real-time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independently). In CAN communication, control units are connected with 2 communication lines (CAN-H, CAN-L) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Signal Chart. Refer to LAN-29, "CAN Communication Signal Chart".

DTC Logic

INFOID:000000009723250

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1000	CAN COMM CIRCUIT	Camera control unit is not transmitting or re- ceiving CAN communication signal for 2 sec- onds or more.	CAN communication system

NOTE:

If "U1000" is detected, first diagnose the CAN communication system.

Diagnosis Procedure

INFOID:000000009723251

1.PERFORM THE SELF-DIAGNOSIS

- 1. Start the engine.
- 2. Turn the LDW system ON, and then wait for 30 seconds or more.
- 3. Perform "All DTC Reading" with CONSULT.
- 4. Check if the "U1000" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U1000" detected as the current malfunction?

- YES >> Refer to LAN-18, "Trouble Diagnosis Flow Chart".
- NO >> Refer to GI-44, "Intermittent Incident".

INFOID:000000009723249

U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

U1010 CONTROL UNIT (CAN)

Description

CAN controller controls the communication of CAN communication signal and the error detection.

DTC Logic

INFOID:000000009723253

INFOID:000000009723252

[LDW]

А

В

С

Е

F

Н

Κ

L

Μ

Ν

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes		
U1010	CONTROL UNIT (CAN)	CAN initial diagnosis malfunction is detected.	Camera control unit	D	
Diagno	Diagnosis Procedure				

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Start the engine.

2. Turn the LDW system ON.

3. Perform "All DTC Reading" with CONSULT.

4. Check if the "U1010" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U1010" detected as the current malfunction?

YES >> Replace the camera control unit. Refer to <u>DAS-94, "Removal and Installation"</u>.

NO >> INSPECTION END

DAS

Р

U111A REAR CAMERA IMAGE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

U111A REAR CAMERA IMAGE SIGNAL CIRCUIT

DTC Logic

INFOID:000000009723255

[LDW]

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U111A	REAR CAMERA IMAGE SIGNAL	Camera image signal circuit is open or shorted.	 Camera image signal circuit be- tween rear view camera and cam- era control unit Camera control unit Rear view camera

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

- 1. Turn the ignition switch ON.
- 2. Shift the selector lever to "R" position.
- 3. Perform "All DTC Reading" with CONSULT.
- 4. Check if the "U111A" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U111A" detected as the current malfunction?

- YES >> Refer to DAS-66, "Diagnosis Procedure".
- NO >> Refer to <u>GI-44, "Intermittent Incident"</u>.

Diagnosis Procedure

INFOID:000000009723256

1. CHECK CONTINUITY REAR VIEW CAMERA POWER SUPPLY AND GROUND CIRCUIT

- 1. Turn ignition switch OFF.
- 2. Disconnect camera control unit connector and rear view camera connector.
- Check continuity between camera control unit harness connector and rear view camera harness connector.

Camera control unit		Rear view camera		Continuity
Connector	Terminals	Connector Terminals		Continuity
B03	50	D168	8	Existed
D93	52	0100	7	Existed

4. Check continuity between camera control unit harness connector and ground.

Camera control unit			Continuity
Connector	Terminal	Ground	Continuity
B93	50		Not existed

Is inspection result normal?

YES >> GO TO 2.

NO >> Repair harness or connector.

2. CHECK VOLTAGE REAR VIEW CAMERA POWER SUPPLY

- 1. Connect camera control unit connector and rear view camera connector.
- 2. Turn ignition switch ON.
- 3. Check voltage between camera control unit harness connector and ground.

U111A REAR CAMERA IMAGE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LDW]

	Terr	ninal				•	А
(-	+)	(-	·)	Standard voltage	Reference voltage		
	Camera c	control unit		Standard Voltage	(Approx.)		В
Connector	Terminal	Connector	Terminal				
B93	50	B93	52	5.0 - 9.0 V	6.0 V	-	
Is inspection YES >>> NO >>> 3 CHECK	on result no GO TO 3 Replace	o <u>rmal?</u> camera con	trol unit. R	efer to <u>DAS-94, "</u>	Removal and Inst	allation".	C
1. Turn ig 2. Discor 3. Check tor.	nition swite nect came continuity	ch OFF. ra control u between ca	nit connec imera cont	ctor and rear view	camera connecto connector and real	r. r view camera harness connec-	E
Camera	control unit	Rea	r view came	ra	uity (F
Connector	Terminal	ls Connec	tor Term	ninals	шу		
B03	53	D168		5 Existe	d		G
	54	Dioc		1	u		
4. Check	continuity	between ca	imera cont	trol unit harness c	onnector and grou	ind.	Н
Camera	control unit			Continu	litv		
Connector	Termina	ls	Ground				
B93	53 54			Not exis	ted		
Is inspection YES >> NO >> 4. CHECK	on result no GO TO 4 Repair ha	ormal? arness or co JMAGE SIC	onnector.				J
1. Conne 2. Turn ig 3. Check	ct camera Inition swite signal betv	control unit ch ON. ween came	connector	and rear view ca unit harness conn	mera connector. ector.		L
		Terminal					M
	(+)		(-)	Pof	erence value		
	Came	era control unit		Kei			
Connector	Termina	al Connec	tor Terr	ninal			Ν
B93	53	B93	5	(V) 1 1 −1	40 μ s		DAS P
Is inspection	n result no	ormal?	I				
YES >>	> Replace	camera con	trol unit. R	efer to DAS-94, "	Removal and Insta	allation".	

NO >> Replace camera control unit. Refer to <u>DAS-94, "Removal and Installation</u>".

U1232 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

U1232 STEERING ANGLE SENSOR

DTC Logic

INFOID:000000009723257

[LDW]

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1232	ST ANGLE SEN CALIB	The neutral position registration of the steering angle sensor can not finish.	Steering angle sensorCamera control unit

Diagnosis Procedure

INFOID:000000009723258

1.REGISTER THE NEUTRAL POSITION OF THE STEERING ANGLE SENSOR

- 1. Turn the ignition switch ON.
- 2. Perform registration of the neutral position of the steering angle sensor. Refer to <u>BRC-9</u>, "ADJUSTMENT <u>OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"</u>.
- 3. Check "Self Diagnostic Result" of "AVM" with CONSULT.
- Is "U1232" detected as the current malfunction?
- YES >> GO TO 2.
- NO >> INSPECTION END
- 2. CHECK STEERING ANGLE SENSOR

Check steering angle sensor.

Is the inspection result normal?

- YES >> Replace the camera control unit. Refer to <u>DAS-94, "Removal and Installation"</u>.
- NO >> Repair or replace malfunctioning parts.

U1305 CONFIG UNFINISH

< DTC/CIRCUIT DIAGNOSIS >

U1305 CONFIG UNFINISH

DTC Logic

A

INFOID:000000009723259

[LDW]

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1305	CONFIG UNFINISH	The vehicle specifications of camera control unit is incomplete.	Vehicle specifications for camera control unit is incomplete
NOTE: Current	malfunction is display	red only and is not saved	
Diagno	osis Procedure		INFOID:000000009723260
1. PERI	FORM CONFIGURAT	ION OF CAMERA CONTROL UNIT	
Perform	configuration of came	era control unit when DTC U1305 is detected.	
	>> Perform configura	ation of camera control unit. Refer to <u>DAS-52, "V</u>	/ork Procedure".

U1308 REAR CAMERA

< DTC/CIRCUIT DIAGNOSIS >

U1308 REAR CAMERA

DTC Logic

INFOID:000000009723261

[LDW]

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1308	R-CAMERA (R&L) CAL- IB JDGMNT	Camera image calibration is incomplete	 Calibration for camera image is in- complete Camera communication line is open

NOTE:

If DTC U1308 is detected along with DTC U130B, first diagnose the DTC U130B. Refer to <u>DAS-72, "DTC Logic"</u>.

Diagnosis Procedure

INFOID:000000009723262

1.PERFORM CALIBRATION OF CAMERA IMAGE

Perform calibration of camera image when DTC U1308 is detected.

>> Perform calibration of camera image. Refer to <u>DAS-53. "Work Procedure (Preparation)"</u>.

U1309 AIR PUMP

< DTC/CIRCUIT DIAGNOSIS >

U1309 AIR PUMP

DTC Logic

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1309	PUMP INPUT CUR- RENT JUDGE	Camera control unit detects the value of current from air pump is incorrect	Air pump
Diagno	osis Procedure		INFOID:000000009723264
1.PER	FORM DTC CONFIRI	MATION PROCEDURE	
1. Star 2 Turi	rt the engine. n the LDW system ON	J	
3. Peri 4. Che	form "All DTC Readin	 g" with CONSULT. etected as the current malfunction in "Self Diago	nostic Result" of "AVM".
<u>ls "U130</u>	09" detected as the cu	irrent malfunction?	
YES NO	>> Replace the air p >> Refer to <u>GI-44, "I</u>	ump. Refer to <u>DAS-97, "Removal and Installatio</u> ntermittent Incident".	<u>n"</u> .

Μ

Κ

L

Ν

INFOID:000000009723263

A

В

U130B REAR CAMERA

< DTC/CIRCUIT DIAGNOSIS >

U130B REAR CAMERA

DTC Logic

INFOID:000000009723265

INFOID:000000009723266

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U130B	REAR CAMERA COMM ERROR	Camera control unit receives the incorrect communication signal from rear camera unit	 Rear view camera Camera control unit

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

- 1. Turn the ignition switch ON.
- 2. Shift the selector lever to "R" position.
- 3. Perform "All DTC Reading" with CONSULT.
- 4. Check if the "U130B" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U130B" detected as the current malfunction?

- YES >> Refer to DAS-72, "Diagnosis Procedure".
- NO >> Refer to <u>GI-44</u>, "Intermittent Incident".

Diagnosis Procedure

1.REPLACE REAR VIEW CAMERA

- 1. Turn ignition switch OFF.
- 2. Replace the rear view camera. Refer to DAS-95. "Removal and Installation".
- 3. Turn ignition switch ON.
- 4. Erases All self-diagnosis results.
- 5. Shift selector lever to "R" position.
- 6. Perform "All DTC Reading" again.
- 7. Check if the "U130B" is detected in self-diagnosis results of "AVM".

Is inspection result normal?

- YES >> Refer to INSPECTION END.
- NO >> Replace camera control unit. Refer to DAS-94, "Removal and Installation".
U1310 PUMP CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

U1310 PUMP CONTROL UNIT

DTC Logic

А

INFOID:000000009723267

DTC DETECTION LOGIC В DTC Trouble diagnosis name DTC detecting condition Possible causes U1310 PUMP ECU JUDGE If the pump control unit is malfunction Pump control unit DTC CONFIRMATION PROCEDURE 1.PERFORM DTC CONFIRMATION PROCEDURE D 1. Start the engine. Turn the LDW system ON. 2. Perform "All DTC Reading" with CONSULT. Е 3. Check if the "U1310" is detected as the current malfunction in "Self Diagnostic Result" of "AVM". 4. Is "U1310" detected as the current malfunction? YES >> Refer to DAS-73, "Diagnosis Procedure". F >> INSPECTION END NO **Diagnosis** Procedure INFOID:000000009723268 1.CHECK VOLTAGE PUMP CONTROL UNIT POWER SUPPLY Check pump control unit power supply and ground circuit. Refer to DAS-74. "PUMP CONTROL UNIT : Diag-Н nosis Procedure". Is inspection result normal? YES >> Replace the pump control unit. Refer to DAS-96, "Removal and Installation". NO >> Repair the pump control unit power supply and ground circuit. Κ

Ρ

DAS

L

Μ

Ν

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

POWER SUPPLY AND GROUND CIRCUIT CAMERA CONTROL UNIT

CAMERA CONTROL UNIT : Diagnosis Procedure

1.CHECK FUSE

Check for blown fuses.

Power source	Fuse No.
Battery power supply	6
Ignition signal	3

Is the inspection result normal?

YES >> GO TO 2.

NO >> Be sure to eliminate cause of malfunction before installing new fuse.

2.CHECK CAMERA CONTROL UNIT POWER SUPPLY CIRCUIT

Check voltage between camera control unit harness connector and ground.

Terminal			Condition			
(·	+)	(-)		Condition	Standard	Reference
	Camera o	ontrol unit		Ignition	Ignition voltage	
Connector	Terminal	Connector	Terminal	switch		
	2			OFF	9.5 - 16 V	Battery volt- age
B92		B92	1	OFF	0 - 0.1 V	0 V
3				ON	9.5 - 16 V	Battery volt- age

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the camera control unit power supply circuit.

 ${f 3.}$ CHECK CAMERA CONTROL UNIT GROUND CIRCUIT

1. Turn the ignition switch OFF.

2. Disconnect the camera control unit connector.

3. Check for continuity between camera control unit harness connector and ground.

Camera d	control unit		Continuity
Connector	Terminal	Ground	Continuity
B92	1		Existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair the camera control unit ground circuit.

PUMP CONTROL UNIT

PUMP CONTROL UNIT : Diagnosis Procedure

1.CHECK FUSE

Check for blown fuses.

Power source	Fuse No.
Ignition power supply	47

Is the inspection result normal?

INFOID-000000009723269

INFOID:000000009723270

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

YES >> GO TO 2. NO >> Be sure to eliminate cause of malfunction before installing new fuse. А 2.CHECK PUMP CONTROL UNIT POWER SUPPLY CIRCUIT Check voltage between pump control unit harness connector and ground. В Terminal Condition (+)(-) Standard Reference voltage voltage Pump control unit Ignition switch Terminal Connector Terminal Connector D OFF 0-0.1 V 0 V D170 12 D170 5 Battery volt-ON 9.5 - 16 V age Е Is the inspection result normal? YES >> GO TO 3. NO >> Repair the pump control unit power supply circuit. F **3.**CHECK PUMP CONTROL UNIT GROUND CIRCUIT 1. Turn the ignition switch OFF. 2. Disconnect the pump control unit connector. 3. Check for continuity between pump control unit harness connector and ground. Н Pump control unit Continuity Connector Terminal Ground D170 5 Existed Is the inspection result normal? YES >> INSPECTION END NO >> Repair the pump control unit ground circuit. Κ L Μ

Ν

DAS

Ρ

< DTC/CIRCUIT DIAGNOSIS >

WARNING SYSTEMS SWITCH CIRCUIT

Component Function Check

1. CHECK WARNING SYSTEMS SWITCH INPUT SIGNAL

1. Turn the ignition switch ON.

2. Select the DATA MONITOR item "ITS SW 1" of "AVM" with CONSULT.

3. With operating the warning systems switch, check the monitor status.

Monitor item	Condition	Monitor status
	Warning systems switch is pressed	On
113 300 1	Warning systems switch is not pressed	OFF

Is the inspection result normal?

YES >> Warning systems switch circuit is normal.

NO >> Refer to DAS-76, "Diagnosis Procedure".

Diagnosis Procedure

1.CHECK WARNING SYSTEMS SWITCH SIGNAL INPUT

1. Turn the ignition switch ON.

2. Check voltage between camera control unit harness connector and ground.

Terminals		Condition		Reference	
(+) (-)		Condition	Standard		
Camera d	control unit		Warning	voltage	voltage
Connector	Terminal	Ground	systems switch		
B02	17		Pressed	0 - 0.1 V	0 V
			Released	9.5 - 16 V	12 V

Is the inspection result normal?

YES >> Replace the camera control unit. Refer to <u>DAS-94, "Removal and Installation"</u>.

NO >> GO TO 2.

2. CHECK WARNING SYSTEMS SWITCH

1. Turn ignition switch OFF.

2. Remove warning systems switch.

3. Check warning systems switch. Refer to <u>DAS-101, "Removal and Installation"</u>.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the warning systems switch. Refer to <u>DAS-101</u>, "<u>Removal and Installation</u>".

 ${f 3.}$ CHECK WARNING SYSTEMS SWITCH GROUND CIRCUIT

Check continuity between warning systems switch harness connector and the ground.

Warning systems switch			Continuity
Connector	Terminal	Ground	Continuity
M39	6	Ť	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair harness or connector.

4.CHECK WARNING SYSTEMS SWITCH SIGNAL INPUT CIRCUIT FOR OPEN

1. Disconnect the camera control unit connector.

DAS-76

INFOID:000000009723271

INFOID:000000009723272

WARNING SYSTEMS SWITCH CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

2. Check continuity between the camera control unit harness connector and warning systems switch harness connector.

Camera control unit Warning systems switch Continuity	
Connector Terminal Connector Terminal	
B92 17 M39 7 Existed	
Is the inspection result normal?	
YES >> GO TO 5.	
NO >> Repair the harnesses or connectors.	
D. CHECK WARNING SYSTEMS SWITCH SIGNAL INPUT CIRCUIT FOR SHORT	
Check continuity between the camera control unit harness connector and ground.	
Camera control unit Continuity	
Connector Terminal Ground	
B92 17 Not existed	
Is the inspection result normal?	
YES >> Replace the camera control unit. Refer to <u>DAS-94, "Removal and Installation"</u> .	
NO >> Repair the harnesses or connectors.	
Component Inspection	INFOID:000000009723273
Check continuity of warning systems switch.	
Terminal Condition Continuity	
7 9 When warning systems switch is pressed Existed	
When warning systems switch is released Not existed	
Is the inspection result normal?	
YES >> INSPECTION END	
NO >> Replace warning systems switch.	

Ν

[LDW]

А

DAS

Ρ

WARNING SYSTEMS ON INDICATOR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

WARNING SYSTEMS ON INDICATOR CIRCUIT

Component Function Check

1. CHECK WARNING SYSTEMS ON INDICATOR

- 1. Turn the ignition switch ON.
- 2. Select the ACTIVE TEST item "ITS SW 1 IND" of "AVM" with CONSULT.
- 3. With operating the test item, check the operation.

On : Warning systems ON indicator illuminates

Off : Warning systems ON indicator is turned OFF

Is the inspection result normal?

- YES >> Warning systems switch indicator circuit is normal.
- NO >> Refer to DAS-78, "Diagnosis Procedure".

Diagnosis Procedure

INFOID:000000009723275

[LDW]

INFOID:000000009723274

1. CHECK WARNING ON INDICATOR POWER SUPPLY CIRCUIT

- 1. Turn ignition switch OFF.
- 2. Disconnect warning systems switch connector.
- 3. Check voltage between warning systems switch harness connector and ground.

(·	+)	(-)	Voltage
Warning systems switch			(Approx.)
Connector Terminal		Ground	
M39 3		Ţ	Battery voltage

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the warning systems ON indicator power supply circuit.

2. CHECK WARNING SYSTEMS ON INDICATOR SIGNAL FOR OPEN

- 1. Disconnect the camera control unit harness connector.
- 2. Check continuity between the camera control unit harness connector and warning systems switch harness connector.

Camera control unit		Warning systems switch		Continuity
Connector	Terminal	Connector Terminal		Continuity
B92	15	M39	2	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the harnesses or connectors.

 ${
m 3.}$ CHECK WARNING SYSTEMS ON INDICATOR SIGNAL CIRCUIT FOR SHORT

Check continuity between the camera control unit harness connector and ground.

Camera control unit			Continuity	
Connector Terminal		Ground	Continuity	
B92	15	† 	Not existed	

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair the harnesses or connectors.

WARNING SYSTEMS ON INDICATOR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >	[LDW]
4. CHECK WARNING SYSTEMS ON INDICATOR	
Check the warning systems ON indicator. Refer to <u>DAS-79</u> , " <u>Component Inspection</u> ". <u>Is the inspection result normal?</u> YES >> Replace the camera control unit. Refer to <u>DAS-94</u> , " <u>Removal and Installation</u> ".	
NO >> Replace warning systems switch. <u>DAS-101. "Removal and Installation"</u> . Component Inspection	INFOID:000000009723276
1. CHECK WARNING SYSTEMS ON INDICATOR	
Apply battery voltage to warning systems switch terminals 1 and 2, and then check if the war indicator illuminates.	rning systems ON

Terminals		Warning sys-	
(+)	(-)	Condition	tems ON indica- tor
з	2	When the battery voltage is applied	On
5 Z	2	When the battery voltage is not applied	Off

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace the warning systems switch. Refer to DAS-101, "Removal and Installation".

J

Κ

L

Μ

Ν

[LDW]

А

В

С

D

Ε

F

G

DAS

Ρ

REAR VIEW CAMERA WASHER RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

REAR VIEW CAMERA WASHER RELAY CIRCUIT

Component Function Check

1.CHECK REAR VIEW CAMERA WASHER RELAY CIRCUIT

- 1. Turn the ignition switch ON.
- 2. Select the ACTIVE TEST item "WASH ACTIVE" of "AVM" with CONSULT.
- 3. With operating the test item, check the operation.

On : Rear view camera washer is activated.

Off : Rear view camera washer is not activated.

Is the inspection result normal?

- YES >> Washer rear view camera washer relay circuit is normal.
- NO >> Refer to <u>DAS-83</u>, "Diagnosis Procedure".

Diagnosis Procedure

INFOID:000000009723278

1.CHECK REAR VIEW CAMERA WASHER RELAY 1 POWER SUPPLY CIRCUIT

1. Turn the ignition switch ON.

2. Check voltage between rear view camera washer relay 1 harness connector and ground.

(+)	(-)	Voltage
Rear view came	ra washer relay 1		(Approx.)
Connector Terminal		Ground	
E29	1		Battery voltage

Is the inspection result normal?

YES >> GO TO 2.

١O	>> Repair rear	view camera	washer relay 1	power supply circuit.
----	----------------	-------------	----------------	-----------------------

2. CHECK REAR VIEW CAMERA WASHER RELAY 1 GROUND CIRCUIT

- 1. Turn ignition switch OFF.
- 2. Disconnect rear view camera washer relay 1.
- 3. Disconnect pump control unit connector.
- 4. Check continuity between rear view camera washer relay 1 harness connector and the pump control unit harness connector.

Rear view ca rela	imera washer ay 1	Pump co	Continuity	
Connector	Terminal	Connector	Terminal	
E29	2	D170	4	Existed

5. Check continuity between rear view camera washer relay 1 harness connector and the ground.

Rear view came	ra washer relay 1		Continuity	
Connector Terminal		Ground	Continuity	
E29	2	Ť	Not existed	

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3.CHECK REAR VIEW CAMERA WASHER RELAY 2 POWER SUPPLY CIRCUIT

1. Turn the ignition switch ON.

2. Check voltage between rear view camera washer relay 2 harness connector and ground.

DAS-80

INFOID:000000009723277

REAR VIEW CAMERA WASHER RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

		Tormin						А
			lais		()			
		(+)	-10		(-)	Voltage		
Rear	view ca	amera wasner re	elay 2		Success of	(/ ())		В
00	nnector	Iermir	nai	G	fround	D <i>u u</i>		
	E28	1				Battery voltage		0
Is the	inspec	ction result no	ormal	<u>?</u>				С
YES NO	>>	GO 10 4. Repair rear v	view c	amera	washer re	alay 2 nower si	ipply circuit	
4 c⊧								D
1. T	isconn	lect rear view	orr. v cam	era wa	sher relav	2.		_
3. C	heck c	continuity bet	ween	rear v	iew camer	a washer relay	2 harness connector and the pump control unit	E
h	arness	connector.						
Deer								F
Rear	rela	amera washer ay 2	F	Pump co	ontrol unit	Continuity		
Con	nector	Terminal	Con	nector	Terminal			
E	28	2	D	170	3	Existed		G
4. C	heck c	ontinuity bet	ween	rear v	iew camer	a washer relay	2 harness connector and the ground.	
		,				,	5	Н
Rear	view ca	amera washer re	elay 2			Continuity		
Co	nnector	Termir	nal	G	Fround	Continuity		
	E28	2				Not existed		
Is the	inspec	ction result n	ormal	?				
YES	>>	GO TO 5.						J
	>>	Repair harne	ess or	conne	ector.			
⊃. C⊦	IECK F	REAR VIEW	CAM	ERA W	ASHER R	ELAY 1 AND 2	2	
Check	k rear v	view camera	wash	er rela	y 1 and 2.	Refer to DAS-	81, "Component Inspection".	Κ
Is the	inspec	ction result n	ormal	?				
YES	>>	Replace pun	np cor	ntrol ur	nit. Notor			L
	>>			CONNE				_
Com	pone	nt Inspect	tion				INFOID:00000009723279	
1. c⊦	IECK F	REAR VIEW	CAM	ERA W	/ASHER R	ELAY 1		Μ
Apply	batter	y voltage to r	rear vi	iew ca	mera wasł	ner relay termin	nals 1 and 2, and then check for continuity under	
the fo	llowing	conditions.						Ν
Tor	minal		Con	dition		Continuity		
Tell	minal	When the het			annlied	Evietod		
5	3	When the het				Not ovieted		
		When the het		tage is f		Not existed		
4	3			toge is a				Ρ
		when the batt		lage is r	iot applied	EXISTED		

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace rear view camera washer relay 1.

2.CHECK REAR VIEW CAMERA WASHER RELAY 2

[LDW]

REAR VIEW CAMERA WASHER RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Apply battery voltage to rear view camera washer relay terminals 1 and 2, and then check for continuity under the following conditions.

Terminal		Condition	Continuity
5	3	When the battery voltage is applied	Existed
5 5	When the battery voltage is not applied	Not existed	
4	3	When the battery voltage is applied	Not existed
4 3	When the battery voltage is not applied	Existed	

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace rear view camera washer relay 2.

WAS	HER SWITCH	ING SOLEN	OID VALVE CIRCUIT
< DTC/CIRCUIT DIAGNO	SIS >		[LDW]
WASHER SWITCH	HING SOLEN	oid valve	CIRCUIT
Component Function	Check		INFOID:00000009723280
1.CHECK WASHER SWIT	TCHING SOLENC	ID VALVE CIRC	UIT
 Turn the ignition switch Select the ACTIVE TE With operating the test 	n ON. ST item "WASH A t item, check the o	CTIVE" of "AVM" peration.	' with CONSULT.
On : Rear view	camera washer is	activated.	
Off : Rear view	camera washer is	s not activated.	
Is the inspection result nor	mal?		
YES >> Washer switch	ing solenoid valve	circuit is normal cedure".	
Diagnosis Procedure			INEC/ID-00000009723281
1			
I.CHECK WASHER SWI	TCHING SOLENC	ID VALVE POW	ER SUPPLY CIRCUIT
 Turn the ignition switch Check voltage between 	n ON. n washer switching	g solenoid valve	harness connector and ground.
Tarminal			
(+)	5 (_)		
(+) Washer switching solenoid val	(-)	Voltage (Approx.)	
Connector Terminal	Ground		
D167 2		Battery voltage	-
Is the inspection result nor	mal?		
YES >> GO TO 2.			
NO >> Repair washer	switching solenoi	d valve power su	ipply circuit.
Z.CHECK WASHER SWI	TCHING SOLENC	ID VALVE SIGN	
 Turn ignition switch OF Disconnect washer sw 	F. vitching solenoid va	alve connector a	nd nump control unit connector
 Check continuity betwee harness connector. 	een washer switch	ing solenoid val	ve harness connector and the pump control unit
Washer switching solenoid	Pump control unit		
Connector Terminal	Connector Termir	Continuity	
D167 3	D170 9	Existed	
4. Check continuity betwe	een washer switch	ing solenoid valv	ve harness connector and the ground.
Washer switching solenoid val	lve		
Connector Terminal	Ground	Continuity	
D167 3		Not existed	-
Is the inspection result nor	mal?		
YES >> GO TO 3.			
NO >> Repair harness	s or connector.		
	ICHING SOLENO	ID VALVE GRO	
 Disconnect combination Check continuity between 	on switch. een washer switch	ing solenoid valv	e harness connector and the combination switch

DAS-83

Washer swite va	ching solenoid Ive	Combinat	Continuity	
Connector	Terminal	Connector	Terminal	
D167	3	M103	3	Existed

Is the inspection result normal?

YES >> Replace washer switching solenoid valve.

NO >> Repair harness or connector.

	RE	AR W	/ASI	HER SW	/ITCH INP		
< DTC/CIRC							
KEAK W	ASHER	20011	ICL		SIGNAL		А
Diagnosis	Procedu	re				INFOID:000000009723282	
1.снеск с	OMBINATI	ON SW	ІТСН	INPUT SI	GNAL CIRCL	ЛТ	В
 Turn ign Disconn Check c tor. 	ition switch ect pump co ontinuity be	OFF. ontrol ur tween c	nit cor combi	nnector an nation swi	d combination tch harness c	n switch connector. onnector and pump control unit harness connec-	С
	Tern	ninals				-	D
Pump co	ntrol unit	Cor	mbinat	ion switch	Continuity		
Connector	Terminal	Conne	ector	Terminal		_	Е
D170	10	M10)3	1	Existed		
4. Check C		ween p	oump		it narness cor	-	F
Connector	Termi	nal	G	round	Continuity		
D170	10				Not existed	-	G
Is the inspec YES >> I NO >> I	tion result n Replace pur Repair harn	ormal? np cont ess or c	rol ur	nit. Refer to ctor.	DAS-96, "R	emoval and Installation".	Н
							l J

Ν

Κ

L

Μ

DAS

WASHER LEVEL SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

WASHER LEVEL SWITCH SIGNAL CIRCUIT

Diagnosis Procedure

INFOID:000000009723283

[LDW]

1. CHECK WASHER LEVEL SWITCH INPUT SIGNAL CIRCUIT

- 1. Turn ignition switch OFF.
- 2. Disconnect combination meter connector and camera control unit.
- 3. Check continuity between combination meter harness connector and camera control unit harness connector.

Combina	tion meter	Camera o	Continuity	
Connector	Connector Terminal		Terminal	Continuity
M34	29	B93	40	Existed

4. Disconnect washer level switch harness connector.

5. Check continuity between camera control unit harness connector and the ground.

Camera o	control unit		Continuity
Connector	Terminal	Ground	Continuity
B93	40	*	Not existed

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair harness or connector.

2.CHECK WASHER LEVEL SWITCH SIGNAL CIRCUIT

Check washer level switch signal circuit. Refer to MWI-49, "Diagnosis Procedure".

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3.CHECK WASHER LEVEL SWITCH

Perform a unit check for the washer level switch. Refer to <u>MWI-50, "Component Inspection"</u>. <u>Is the inspection result normal?</u>

- YES >> Replace camera control unit. Refer to <u>DAS-94, "Removal and Installation"</u>.
- NO >> Replace washer tank. Refer to <u>WW-128</u>, "Removal and Installation".

SYMPTOM DIAGNOSIS LDW SYSTEM SYMPTOMS

Symptom Table

NOTE:

For the operational conditions of Lane Departure Warning (LDW), refer to DAS-12, "System Description".

Symptom		Possible cause	Inspection item/Reference page
	Lane departure warning lamp (Yellow) does not illu- minate.	Combination meterCamera control unit	Lane departure warning lamp does not turned ON Refer to <u>DAS-89, "Description"</u>
	LDW ON indicator lamp (Green) does not illuminate.	Combination meterCamera control unit	LDW ON indicator lamp does not turned ON Refer to <u>DAS-90, "Description"</u>
	Warning systems ON indica- tor does not illuminate.	 Harness between camera control unit and warning sys- tems switch Warning systems switch Camera control unit 	Warning systems ON indicator circuit Refer to <u>DAS-78, "Component</u> <u>Function Check"</u>
Indicator/warning lamps do not illuminate when ignition switch OFF \Rightarrow ON	Lane departure warning lamp (Yellow) or LDW ON in- dicator lamp (Green) does not illuminate.	 Combination meter Camera control unit 	 Lane departure warning lamp does not turned ON Refer to <u>DAS-89</u>, "<u>Descrip-</u> <u>tion</u>" LDW ON indicator lamp does not turned ON Refer to <u>DAS-90</u>, "<u>Descrip-</u> <u>tion</u>"
	 All of indicator/warning lamps does not illuminate; Lane departure warning lamp (Yellow) LDW ON indicator lamp (Green) Warning systems ON indi- cator 	 Power supply and ground circuit of camera control unit Camera control unit 	Power supply and ground circuit of camera control unit Refer to <u>DAS-74, "CAMERA</u> <u>CONTROL UNIT : Diagnosis</u> <u>Procedure"</u>
LDW system is not activated. (Indicator/warning lamps illumi- nate when ignition switch OFF \Rightarrow ON)	LDW ON indicator lamp is not turned ON ⇔ OFF when operating warning systems switch	 Harness between camera control unit and warning sys- tems switch Harness between warning systems switch and ground Warning systems switch Camera control unit 	 Warning systems switch circuit Refer to <u>DAS-76, "Component</u> <u>Function Check"</u> LDW system setting can not be turned ON/OFF on the nav- igation screen Refer to <u>DAS-92, "Diagnosis</u> <u>Procedure"</u>
	Warning buzzer is not sounding. (Lane departure warning lamp is activated.)	Combination meterCamera control unit	Meter buzzer circuit Refer to <u>WCS-24, "Component</u> <u>Function Check"</u>
 Warning functions are not timely (Example) Does not function when driving on lane markers Functions when driving in a lane Functions in a different position from the actual position. 		 Rear view camera calibration Rear view camera Camera control unit 	Rear view camera calibration DAS-53, "Description"
Functions when changing the course in direction of the turn sig- nal		Turn indicator signal (CAN) BCM Camera control unit 	System operates even when us- ing turn signal Refer to <u>DAS-91, "Description"</u>

INFOID:000000009723284

В

С

LDW SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

Symptom	Possible cause	Inspection item/Reference page
Rear view camera washer is not activated (Rear window washer is functioning normally)	 Rear view camera washer relay circuit Washer switching solenoid valve circuit Pump control unit Camera control unit 	 Rear view camera washer relay circuit Refer to <u>DAS-80, "Component</u> <u>Function Check"</u> Washer switching solenoid valve circuit Refer to <u>DAS-83, "Component</u> <u>Function Check"</u>
Rear view camera wash is insufficient	 Washer tube (include check valve) Air tube Washer/Air nozzle (Rear view camera) 	Rear view camera washer/air blower function Refer to <u>DAS-48, "Inspection</u> <u>Procedure"</u>

LANE DEPARTURE WARNING LAMP DOES NOT TURNED ON [LDW] < SYMPTOM DIAGNOSIS > LANE DEPARTURE WARNING LAMP DOES NOT TURNED ON А Description INFOID:000000009723285 The lane departure warning lamp in the combination meter does not turn ON when turning on the ignition В switch **Diagnosis** Procedure INEOID:000000009723286 **1.**CHECK COMBINATION METER Turn the ignition switch from OFF to ON to check that "LDW IND" included in "DATA MONITOR" in "METER/ D M&A" operates normally. Is the inspection result normal? YFS >> Replace the combination meter. Refer to MWI-105, "Removal and Installation". Е NO >> GO TO 2. **2.**CHECK SELF-DIAGNOSIS RESULTS OF COMBINATION METER 1. Perform "All DTC Reading" with CONSULT. F Check if the DTC is detected in self-diagnosis results of "METER/M&A". Refer to MWI-77, "DTC Index". Is any DTC detected? YES >> Repair or replace malfunctioning parts.

Check if the DTC is detected in self-diagnosis results of "AVM" Refer to DAS-30, "DTC Index".

>> GO TO 3.

Is any DTC detected?

NO

YES >> Repair or replace malfunctioning parts.

NO >> Replace the camera control unit. Refer to <u>DAS-94, "Removal and Installation"</u>.

3.CHECK SELF-DIAGNOSIS RESULTS OF CAMERA CONTROL UNIT

DAS

Н

Κ

L

M

Ν

Р

LDW ON INDICATOR LAMP DOES NOT TURNED ON

< SYMPTOM DIAGNOSIS >

LDW ON INDICATOR LAMP DOES NOT TURNED ON

Description

The LDW ON indicator lamp in the combination meter does not turn ON when turning on the ignition switch

Diagnosis Procedure

INFOID:000000009723288

INFOID:000000009723287

[LDW]

1.CHECK COMBINATION METER

Turn the ignition switch from OFF to ON to check that "LDW IND" included in "DATA MONITOR" in "METER/ M&A" operates normally.

Is the inspection result normal?

YES >> Replace the combination meter. Refer to <u>MWI-105, "Removal and Installation"</u>.

NO >> GO TO 2.

2. CHECK SELF-DIAGNOSIS RESULTS OF COMBINATION METER

- 1. Perform "All DTC Reading" with CONSULT.
- 2. Check if the DTC is detected in self-diagnosis results of "METER/M&A" Refer to MWI-77, "DTC Index".

Is any DTC detected?

YES >> Repair or replace malfunctioning parts.

NO >> GO TO 3.

3.CHECK SELF-DIAGNOSIS RESULTS OF CAMERA CONTROL UNIT

Check if the DTC is detected in self-diagnosis results of "AVM" Refer to DAS-30, "DTC Index".

Is any DTC detected?

- YES >> Repair or replace malfunctioning parts.
- NO >> Replace the camera control unit. Refer to <u>DAS-94, "Removal and Installation"</u>.

THE SYSTEM OPERATES EVEN WHEN USING TURN SIGNAL

< SYMPTOM DIAGNOSIS >	_ [LDW]
THE SYSTEM OPERATES EVEN WHEN USING TURN SIGNAL	
Description	F
The warning of Lane Departure Warning (LDW) is activated during the use of a turn signal.	E
For the operational conditions of Lane Departure Warning (LDW), refer to <u>DAS-12, "System Des</u>	scription".
Diagnosis Procedure	INFOID:000000009723290
1. CHECK TURN SIGNAL OPERATION	
Check that both right and left turn signals are normal. <u>Is the inspection result normal?</u> YES >> GO TO 2	E
NO >> Repair or replace malfunctioning parts. Refer to <u>EXL-162. "Symptom Table"</u> . 2.CHECK SELF-DIAGNOSIS RESULTS	E
 Perform "All DTC Reading" with CONSULT. Check if the DTC is detected in self-diagnosis results of "AVM" Refer to <u>DAS-30, "DTC Inde</u> 	F
<u>Is any DTC detected?</u> YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning pa NO >> Replace camera control unit. Refer to <u>DAS-94, "Removal and Installation"</u> .	irts.

J

Κ

L

Μ

Ν

DAS

Р

SYSTEM SETTINGS CANNOT BE TURNED ON/OFF ON THE NAVIGATION SCREEN

< SYMPTOM DIAGNOSIS >

SYSTEM SETTINGS CANNOT BE TURNED ON/OFF ON THE NAVIGATION SCREEN

Description

INFOID:000000009723291

[LDW]

• LDW system setting is not selectable on the navigation screen. **NOTE:**

When the ignition switch is in ACC position, LDW system settings cannot be changed.

- "Lane Departure Warning" is not indicated on the navigation screen.
- The switching between ON and OFF cannot be performed by operating the navigation system.
- The item of "Lane Departure Warning" on the navigation screen is not active.
- After turning ON the ignition switch or starting the engine, LDW settings of the navigation system cannot be selected for several tens of seconds under the following conditions:
- After replacing AV control unit.
- After erasing connection history of the navigation system.
- After erasing self-diagnosis results of AV control unit.
- The LDW system setting differs from the one set at the previous driving. **NOTE:**

Turn OFF the ignition switch and wait for 5 seconds or more.

Diagnosis Procedure

INFOID:000000009723292

1.CHECK LDW SYSTEM SETTING

- 1. Start the engine.
- 2. Check that the LDW system settings is selectable on the navigation screen.

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. PERFORM THE SELF-DIAGNOSIS

1. Perform self-diagnosis with CONSULT.

- 2. Check if the DTC is detected in self-diagnosis results of "AVM" and "MULTI AV". Refer to the following.
- AVM: <u>DAS-30, "DTC Index"</u>
- MULTI AV: <u>AV-340, "DTC Index"</u>

Is any DTC detected?

- YES >> Repair or replace malfunctioning parts.
- NO >> INSPECTION END

3.CHECK MULTIFUNCTION SWITCH

Operate the multifunction switch to check that the audio, navigation system, and air conditioner operate properly.

Is the inspection result normal?

YES >> Replace the camera control unit. Refer to <u>DAS-94, "Removal and Installation"</u>.

NO >> Repair or replace malfunctioning parts.

NORMAL OPERATING CONDITION

NORMAL OPERATING CONDITION

Description

Description	INFOID:000000009723293	
 PRECAUTIONS FOR LANE DEPARTURE WARNING (LDW) The LDW system is only a warning device to inform the driver of a potential unintended lane 	departure. It will	В
 not steer the vehicle or prevent loss of control. It is the driver's responsibility to stay alert, d the vehicle in the traveling lane, and be in control of the vehicle at all times. The rear view camera may not detect properly under the following conditions: When towing a trailer 	rive safely, keep	С
 When strong light enters the rear view camera. (For example, direct sunlight or headlight from the vehicle enters or example, when the vehicle enters or example, under a bridge.) 	om the rear) exits a tunnel or	D
 Automatic washer and blower may not be able to secure detection capability when excessive the camera lens. LDW system may not function properly under the following conditions: 	e dirt adheres on	E
 Excessive noise (e.g. audio system volume, open vehicle window) will interfere with the chimay not be heard. 	ne sound, and it	_
 The rear view camera may not be able to detect properly under the following conditions: On roads where there are multiple parallel lane markers; lane markers that are faded or no vellow painted lane markers: non-standard lane markers; or lane markers covered with wate 	t painted clearly; r. dirt. snow. etc.	Г
 On roads where the discontinued lane markers are still detectable. On roads where there are sharply contrasting objects, such as shadows, snow, water, when lines remaining after road repairs. (The LDW system could detect these items as lane mark 	el ruts, seams or	G
 On roads where the traveling lane merges or separates. When the vehicle's traveling direction does not align with the lane marker. 	513.7	Н
 When driving on curved road, warning will be late on the outside of the curve due to the n tem. 	ature of the sys-	
		J
		K
		L

M

[LDW]

А

Ν

DAS

Ρ

< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION CAMERA CONTROL UNIT

Exploded View

(1) Camera control unit

SEC. 280

Removal and Installation

REMOVAL

CAUTION:

Before replacing camera control unit, perform "Read/Write Configuration" to save or print current vehicle specification. For details, refer to <u>DAS-52, "Description"</u>.

- 1. Remove luggage side finisher lower (RH). Refer to INT-35, "Removal and Installation".
- 2. Disengage air tube clip from camera control unit bracket.
- 3. Remove camera control unit screws, disconnect camera control unit connector and remove the camera control unit.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

Must be perform additional service when replacing camera control unit. Refer to <u>DAS-51, "Work Proce-</u> <u>dure"</u>.

INFOID:000000009723294



REAR VIEW CAMERA

< REMOVAL AND INSTALLATION >

REAR VIEW CAMERA

Exploded View

1.

4.

INFOID:000000009723296

[LDW]

А



Μ

Ν

DAS

Ρ

PUMP CONTROL UNIT

< REMOVAL AND INSTALLATION >

PUMP CONTROL UNIT

Exploded View

INFOID:000000009723298



- (1) Luggage trim bracket
- (2) Pomp control unit

 \triangleleft : Vehicle front

Removal and Installation

INFOID:000000009723299

REMOVAL

- 1. Remove luggage floor front finisher. Refer to INT-35, "Removal and Installation".
- 2. Remove luggage mask. Refer to INT-34, "Exploded View".
- 3. Remove pump control unit mounting screws, disconnect pump control unit harness connector and remove pump control unit.

INSTALLATION

Install in the reverse order of removal.

< REMOVAL AND INSTALLATION > AIR PUMP

Exploded View

INFOID:000000009723300



А

WASHER SWITCHING SOLENOID VALVE

< REMOVAL AND INSTALLATION >

WASHER SWITCHING SOLENOID VALVE

Exploded View

INFOID:000000009723302



(1) Washer switching solenoid valve

Removal and Installation

REMOVAL

- 1. Remove back door finisher inner. Refer to INT-38, "Removal and Installation".
- 2. Remove the nuts.
- 3. Remove washer switching solenoid valve.

INSTALLATION

Install in the reverse order of removal.

INFOID:000000009723303

REAR VIEW CAMERA WASHER/AIR NOZZLE & TUBE

< REMOVAL AND INSTALLATION >

REAR VIEW CAMERA WASHER/AIR NOZZLE & TUBE

Exploded View

REAR VIEW CAMERA WASHER / AIR NOZZLE & TUBE



(A) Details

NOTE:

For washer pump and rear washer path, refer to <u>WW-145, "Hydraulic Layout"</u>. HYDRAULIC LAYOUT

M

L

Κ

[LDW]

INFOID:000000009723304

А

В

С

D

Е

F

Н

Ν

DAS

Ρ

REAR VIEW CAMERA WASHER/AIR NOZZLE & TUBE

< REMOVAL AND INSTALLATION >

SEC. 280•289 3 1 6 4 \bigcirc 8 5 2 - : A = : ® JSOIA0669ZZ Washer pump Air pump Back door 2 3 Washer switching solenoid valve Check valve Rear washer nozzle (5) 6

- (7) Air/washer nozzle
- (A) Washer tube

1

(4)

8 Rear view camera8 Air tube

WARNING SYSTEMS SWITCH

< REMOVAL AND INSTALLATION >

[LDW]

WARNING SYSTEMS SWITCH		Λ
Removal and Installation	INFOID:000000009723305	A
 REMOVAL Remove the instrument lower panel LH. Refer to <u>IP-15, "Removal and Installation"</u>. Remove warning systems switch from instrument lower panel LH. 		В
INSTALLATION Install in the reverse order of removal.		С
		E
		F
		G
		Н
		I
		J
		K
		L
		M
		DAS
		Ρ

< PRECAUTION > PRECAUTION PRECAUTIONS FOR USA AND CANADA

FOR USA AND CANADA : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

FOR USA AND CANADA : Precautions for Removing of Battery Terminal INFOLD:00000010089129

 When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.
 NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

• For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch. **NOTE:**

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

• After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC. **NOTE:**

The removal of 12V battery may cause a DTC detection error.

FOR USA AND CANADA : Precaution for BSW System Service

INFOID:000000009723307

WARNING:

Be careful of traffic conditions and safety around the vehicle when performing road test.



DAS-102



PRECAUTIONS

< PRECAUTION > **CAUTION:**

Never perform the active test while driving.

Never change BSW initial state ON ⇒ OFF without the consent of the customer.

FOR MEXICO

FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" INFOID:000000009723308

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

FOR MEXICO : Precautions for Removing of Battery Terminal

• When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds. NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may

occur. For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch. NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

 After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC. NOTE:

The removal of 12V battery may cause a DTC detection error.

FOR MEXICO : Precaution for BSW System Service

WARNING:

Be careful of traffic conditions and safety around the vehicle when performing road test. **CAUTION:**

- Never perform the active test while driving.
- Never change BSW initial state ON ⇒ OFF without the consent of the customer.





DAS



INFOID:000000010089130

А

D

E

F

Н

L

< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION COMPONENT PARTS

Component Parts Location

INFOID:000000009723310

[BSW]



A Front side of spare tire

B Luggage room LH

D Luggage room RH

E) Instrument lower panel LH

O Inside back door

No.	Component	Function
1	ABS actuator and electric unit (con- trol unit)	Transmits the vehicle speed signal (wheel speed) to camera control unit via CAN commu- nication Refer to <u>BRC-12, "Component Parts Location"</u> for detailed installation location
2	Washer pump	Washer fluid is sprayed according to rear view camera washer relay status Refer to <u>WW-18</u> , "Component Parts Location" for detailed installation location
3	Washer level switch	Transmits the washer level switch signal to camera control unit

Revision: 2013 August

DAS-104

2014 MURANO

COMPONENT PARTS

< SYSTEM DESCRIPTION >

No.	Component	Function
4	ECM	Transmits the engine status signal and engine coolant temperature signal to camera con- trol unit via CAN communication Refer to <u>EC-36, "Component Parts Location"</u> for detailed installation location
5	ВСМ	Transmits the turn indicator signal to camera control unit via CAN communication Refer to <u>BCS-9</u> , "Component Parts Location" for detailed installation location
6	Rear view camera washer relay	Refer to DAS-108, "Rear View Camera Washer Relay"
7	Pump control unit	Refer to DAS-107, "Pump Control Unit"
8	Air pump	Refer to DAS-107, "Air Pump"
9	Rear view camera	Refer to DAS-106, "Rear View Camera"
10	Washer switching solenoid valve	Refer to DAS-107, "Washer Switching Solenoid Valve"
11	Camera control unit	Refer to DAS-105, "Camera Control Unit"
(12)	BSW indicator RH	Refer to DAS-105, "BSW Indicator LH/RH"
13	Combination meter	 Description: <u>DAS-105, "Combination Meter"</u> System display and warning: <u>DAS-116, "System Display and Warning"</u>
14	Steering angle sensor	Transmits the steering angle sensor signal to camera control unit via CAN communication Refer to <u>BRC-12</u> , " <u>Component Parts Location</u> " for detailed installation location
(15)	Warning systems switch	Refer to DAS-108, "Warning Systems Switch/Warning Systems ON Indicator"
16	Warning systems ON indicator (On the warning systems switch)	Refer to DAS-108, "Warning Systems Switch/Warning Systems ON Indicator"
17	BSW indicator LH	Refer to DAS-105, "BSW Indicator LH/RH"
18	A/C auto amp.	Transmits the ambient sensor signal to camera control unit via CAN communication Refer to <u>HAC-150</u> , "Component Part Location" for detailed installation location
(19)	AV control unit	Transmits the system selection signal to camera control unit via CAN communication Refer to <u>AV-303</u> , "Component Parts Location" for detailed installation location

Camera Control Unit

- Camera control unit is installed in the luggage room RH.
- The adoption of CAN communication allows the signal transmission/reception between the camera control unit and each control unit.
- When the ignition switch is turned ON, electric power is supplied to the rear view camera.
- Camera control unit receives a camera image signal from rear view camera and recognizes a vehicle traveling in the adjacent lane.
- When a vehicle traveling in the adjacent lane approaches, camera control unit sounds the buzzer and blinks the BSW indicator to warn the driver.
- The camera control unit communicates with the rear view camera via serial communication and receives the specific information of the camera. When the information matches the specific information of the camera written in the camera control unit, camera is activated normally.

BSW Indicator LH/RH

- BSW indicator is installed in the door mirror corner cover.
- Receives a BSW indicator operation signal from the camera control unit and blinks or turns ON/OFF the BSW indicator.

Combination Meter

• Receives BSW warning lamp signal, BSW ON indicator lamp signal and buzzer output signal from camera control unit via CAN communication.



INFOID:000000009723311

DAS

INFOID:000000009723313

[BSW

INFOID:000000009723312

COMPONENT PARTS

< SYSTEM DESCRIPTION >

- Turns the BSW warning lamp, BSW ON indicator lamp ON/OFF according to the signals from camera control unit.
- Displays the clean camera display according to the signal from the camera control unit.
- Operates the buzzer according to the signal from the camera control unit.

Rear View Camera

INFOID:000000009723314

[BSW]

- The rear view camera is installed to the back door finisher.
- Super-small CMOS camera (color) using CMOS^{*} for the image pickup element is adopted.
- With the mirror processing function, a mirror image is sent as if it is viewed by a rear view mirror.
- Power for the camera is supplied from the camera control unit, and the image at the rear of the vehicle is sent to the camera control unit.
- The rear view camera is equipped with a washer nozzle and air nozzle for cleaning camera. A check valve is installed to the tube connected to the washer nozzle.



NOTE:

*: "CMOS" is abbreviation of Complementary Metal Oxide Semiconductor, and features low power consumption and high speed reading rate of electric charge.

Camera Specification

Manufacturer name	SONY Corp.
Image pickup element	1/4-inch CMOS image sensor
Effective number of pixels	Approx. 300,000 pixels (632 × 480)
Minimum brightness	2 lx
Angle of view	H: 190.4° V: 141.8°
Image	With mirror processing function

- Communicates with camera control unit via communication line.
- · Activates air pump and washer pump according to the signal from camera control unit.
- Receives rear washer signal from washer switching solenoid valve.

Air Pump

< SYSTEM DESCRIPTION >

Pump Control Unit

isher.

 Air pump is installed in the luggage floor spacer LH in the luggage room.

- Air pump is activated and generates compressed air when power is supplied from the pump control unit.
- Compressed air jets out from the air nozzle of rear view camera via air tube.

Washer Switching Solenoid Valve

- Washer switching solenoid valve is installed in the back door.
- When rear washer is in the inactive condition, the solenoid valve is inactive and rear view camera washer path is activated.
- When rear washer is in the active condition, the solenoid valve is active and the washer path is switched to rear washer side.
- · When solenoid valve is active, a rear washer signal is transmitted to the pump control unit.



Κ INFOID:000000009723317 L Μ Ν JSOIA0659ZZ DAS



F



INFOID:000000009723315

INFOID:000000009723316

COMPONENT PARTS

< SYSTEM DESCRIPTION >

Rear View Camera Washer Relay

- · Rear view camera washer relay 1 and 2 are installed in the engine room LH
- · When the relay is in the inactive state, the circuit of window washer is energized.
- Rear view camera washer relay 1and 2 are activated according to a signal from the pump control unit and activate the washer pump regardless of window washer activation.

Warning Systems Switch/Warning Systems ON Indicator

- · Installed to the instrument lower panel, the warning systems switch is used to activate/deactivate the LDW and BSW systems.
- Transmits a warning systems switch signal to the camera control unit.

3 5 241 2 kΩ \sim **125**Ω 000 5



INFOID:000000009723318

JSOIA065577 INFOID:000000009723319
< SYSTEM DESCRIPTION >

SYSTEM

System Description

SYSTEM DIAGRAM



CAMERA CONTROL UNIT INPUT/OUTPUT SIGNAL ITEM

Camera control unit receives signals via CAN communication. It also detects vehicle conditions that are necessary for BSW control.

DAS-109

INFOID:000000009723320

В

С

D

Ε

F

Н

J

Κ

L

Μ

Ν

DAS

Ρ

< SYSTEM DESCRIPTION >

Input Signal Item

Transmit unit		Signal name	Description
ABS actuator and electric unit (control unit)	CAN com- munica- tion	Vehicle speed signal (ABS)	Receives wheel speeds of four wheels
BCM	CAN com- munica-	Turn indicator signal	Receives an operational state of the turn signal lamp and the hazard lamp
	tion	Dimmer signal	Receives an ON/OFF state of dimmer signal
AV control unit	CAN com- munica- tion	System selection signal	Receives a selection state of each item in "Driver as- sist" selected with the navigation system
Steering angle sensor	CAN com- munica- tion	Steering angle sensor signal	Receives the number of revolutions, turning direction of the steering wheel
	CAN com-	Engine status signal	Receives the engine status
ECM	munica- tion	Engine coolant temperature signal	Receives the engine coolant temperature
A/C auto amp.	CAN com- munica- tion	Ambient sensor signal	Receives the ambient temperature
Rear view cam- era	Communi- cation line	Camera image signal	Receives the camera image signal
Washer level switch	Washer level switch signal		Receives a status of washer fluid level
Warning sys- tems switch	Warning systems switch signal		Receives an ON/OFF state of the warning systems switch

Output Signal Item

Reception unit		Signal name		Description
		BSW warning lamp signal		Transmits a BSW warning lamp signal to turn ON the Blind Spot Warning/Blind Spot Intervention warning lamp
Combination	CAN communication	BSW ON indictor signal		Transmits a BSW ON indictor lamp signal to turn ON the BSW ON indictor lamp
meter		Meter dis- play signal	Clean camera dis- play signal	Transmits a meter display signal to turn ON the clean camera indication on the information display.
		Buzzer output signal		Transmits a buzzer output signal to activates the warn- ing buzzer
Pump control		Rear view camera washer signal		Transmits a rear view camera washer signal to activates the washer pump
unit	Communication line	Rear view camera air blow signal		Transmits a rear view camera air blow signal to activates the air pump
Warning sys- tems ON indi- cator	Warning systems ON ir	DN indicator signal		Turns ON the warning systems ON indicator
Warning buzz- er	Warning buzzer operati	peration signal		Activates the warning buzzer
BSW indicator LH, RH	Indicator operation sign	al		Turns ON the BSW indicator LH, RH

FUNCTION DESCRIPTION

- The BSW system can help alert the driver of other vehicles in adjacent lanes when changing lanes.
- The BSW system uses rear view camera installed near the rear bumper to detect vehicles in an adjacent lane.

< SYSTEM DESCRIPTION >

- The rear view camera can detect vehicles on either side of vehicle within the detection zone shown as illustrated.
- This detection zone starts from the outside mirror of vehicle and extends approximately 10 ft (3.0 m) behind the rear bumper, and approximately 10 ft (3.0 m) sideways.
- The BSW system operates above approximately 32 km/h (20 MPH).
- If the rear view camera detects vehicles in the detection zone, the BSW indicator illuminates.



NOTE:

A buzzer sounds if the rear view camera have already detected vehicles when the driver activates the turn signal. If a vehicle comes into the detection zone after the driver activates the turn signal, then only the BSW indicator blinks and no buzzer sounds.



BSW SYSTEM OPERATION DESCRIPTION

- Camera control unit enables BSW system.
- The camera control unit turns on the BSW system when the warning systems switch is turned ON.
- Rear view camera transmits the camera image signal to camera control unit via communication line.
- Camera control unit starts the control as follows, based on a camera image signal, turn signal and dimmer signal transmitted from BCM via CAN communication:
- Buzzer output signal transmission to combination meter via CAN communication.
- Camera control unit transmits an indicator operation signal to the BSW indicator according to BSW indicator signal and BSW dimmer signal.

Operation Condition of BSW System

Camera control unit performs the control when the following conditions are satisfied.

- When the warning systems switch in turned ON*.
- When the vehicle drives at 32 km/h (20 MPH) or more to the forward direction.

NOTE:

- *: When the BSW system setting on the navigation screen is ON.
- After the operating conditions of warning are satisfied, the warning continues until the vehicle speed reaches approximately 29 km/h (18 MPH)

DAS-111

2014 MURANO

А

В

Ε

F

Н

Κ

M

Ν

Ρ

DAS

< SYSTEM DESCRIPTION >

• The BSW system may not function properly, depending on the situation. Refer to <u>DAS-118</u>, "<u>Precautions for</u> <u>Blind Spot Warning</u>".

BULB CHECK ACTION AND FAIL-SAFE INDICATION

Vehicle condition/Driver's operation	BSW indicator	Warning systems ON indicator	Indication on the combination meter
Ignition switch: OFF \Rightarrow ON	Approx. 2 sec. ON	Approx. 5 sec. ON	OFF - Contraction (Green) ON ON JSOIA0670GB
When DTC is detected	OFF	ON	(Yellow) ON JSOIA0671GB
When vehicles cannot be detected due to dirt on the rear view camera	OFF	ON	(Green) Blink JSOIA0261GB In the information display
When the washer fluid level is low (Low washer warning ON)	OFF	ON	Blinks at intervals of two seconds.
When the back door is open (Back door open warning ON)	OFF	ON	Blinks at intervals of two seconds.

REAR VIEW CAMERA WASHER OPERATION

• When judging that the rear view camera has water droplets, the camera control unit transmits a rear view camera washer activation signal or rear view camera air blow signal to the pump control unit via serial communication.

< SYSTEM DESCRIPTION >

- When receiving a rear view camera washer activation signal, the pump control unit simultaneously activates the washer pump to clean the rear view camera by spraying washer fluid from the nozzle installed to the rear view camera bracket.
- The washer switching solenoid valve switches the washer path from rear window to rear view camera.
- When receiving a rear view camera air blow signal, the pump control unit activates the air pump to clean the rear view camera by blowing air from the nozzle installed to the rear view camera bracket.

OPERATION CONDITION

- Approximately 30 km/h (20 MPH) or more
- When the camera control unit judges that the rear view camera has water droplets.
- When the front washer and the rear washer are not activated.
- When the low washer fluid warning is OFF.

NOTE:

The camera is cleaned intermittently by spraying washer fluid and blowing air. When the camera control unit judges that dirt on the camera cannot be removed even after approximately 5 minutes from the first detection of dirt, the activation of BSW is canceled.

Fail-Safe

INFOID:000000009723321

[BSW]

А

В

С

D

Е

DTC Display contents of CONSULT	Malfunction detection condition	Fail-safe condition
C1A03 VHCL SPEED SE CIRC	If the vehicle speed signal (wheel speed) from ABS actuator and electric unit (control unit) re- ceived by the camera control unit via CAN com- munication, are inconsistent	LDW system is cancelBSW system is cancel
C1A04 ABS/TCS/VDC CIRC	If a malfunction occurs in the VDC/TCS/ABS system	LDW system is cancelBSW system is cancel
C1A39 STRG SEN CIR	If the steering angle sensor is malfunction	LDW system is cancelBSW system is cancel
U0122 VDC P-RUN DIAGNOSIS	If camera control unit detects an error signal that is received from ABS actuator and electric unit (control unit) via CAN communication	LDW system is cancelBSW system is cancel
U0416 VDC CHECKSUM DIAGNOSIS	If camera control unit detects an error signal that is received from ABS actuator and electric unit (control unit) via CAN communication	LDW system is cancelBSW system is cancel
U0428 ST ANGLE SENSOR CALIBRA- TION	Neutral position adjustment of steering angle sensor is not complete.	 Predicted course line is not displayed. MOD (Moving Object Detection) function is stopped. LDW system is stopped. BSW system is stopped.

Ν

DAS

Ρ

< SYSTEM DESCRIPTION >

DTC Display contents of CONSULT	Malfunction detection condition	Fail-safe condition
U1000 CAN COMM CIRCUIT	When camera control unit cannot transmit/re- ceive CAN communication signal continuously for 2 seconds or more.	 The following functions are stopped When communication of steering angle sensor signal is not normal Predicted course line is not displayed. MOD (Moving Object Detection) function is stopped. LDW system is stopped. Front tire angle display is stopped. Using "SETTING" menu display, switch each indicator of predicted course line display and MOD switch to "OFF" (turn OFF) so that switch operation cannot be performed. When communication of vehicle signal, wheel speed sensor signal, and shift signal is not normal Predicted course line is not displayed. MOD (Moving Object Detection) function is stopped. USING "SETTING" menu display, switch each indicator of predicted course line display and MOD switch to "OFF" (turn OFF) so that switch operation cannot be performed. When communication of vehicle signal, wheel speed sensor signal, and shift signal is not normal Predicted course line is not displayed. MOD (Moving Object Detection) function is stopped. LDW system is stopped. Using "SETTING" menu display, switch each indicator of predicted course line display and MOD switch to "OFF" (turn OFF) so that switch operation cannot be performed When communication of sonar signal is not normal Predicted course line is not displayed.
U1010 CONTROL UNIT (CAN)	CAN initial diagnosis malfunction is detected.	 MOD (Moving Object Detection) function is stopped. LDW system is stopped. BSW system is stopped.
U111A REAR CAMERA IMAGE SIGNAL	No-signal status of rear camera image signal is continued for 500 ms or more while ignition switch is ON. NOTE: Current malfunction is displayed only and is not saved.	 Camera image is not displayed (Gray screen display). LDW system is stopped. BSW system is stopped.
U1232 ST ANGLE SEN CALIB	Neutral position adjustment of steering angle sensor is performed. NG signal from steering angle sensor is received.	 Predicted course line is not displayed. MOD (Moving Object Detection) function is stopped. LDW system is stopped. BSW system is stopped. Tire icon is stopped. Using "SETTING" menu display, switch each indicator of predicted course line display and MOD switch to "OFF" (turn OFF) so that switch operation cannot be performed.
U1305 CONFIG UNFINISH	The vehicle setting of camera control unit is in- complete. NOTE: Current malfunction is displayed only and is not saved.	Operation is according to the vehicle setting value as default value.
U1308 R-CAMERA (R&L) CALIB JDG- MNT	Camera image calibration is incomplete	 MOD (Moving Object Detection) function is stopped. LDW system is stopped. BSW system is stopped.

< SYSTEM DESCRIPTION >

DTC Display contents of CONSULT	Malfunction detection condition	Fail-safe condition
U1309 PUMP INPUT CURRENT JUDGE	Camera control unit detects the value of current from pump control unit is incorrect	 MOD (Moving Object Detection) function is stopped. LDW system is stopped. BSW system is stopped.
U130B RR CAMERA COMM ERROR	Camera control unit receives the incorrect com- munication signal from rear view camera	 MOD (Moving Object Detection) function is stopped. LDW system is stopped. BSW system is stopped.
U1310 PUMP ECU JUDGE	If the pump control unit is malfunction	LDW system is stopped.BSW system is stopped.
	When camera control unit is not normal.	Switch to camera screen is not allowed.
Other	When communication between camera control unit and each camera is not normal.	On applicable camera screen <u>A</u> marking (Red) is displayed.
	When communication line between camera	On applicable camera image screen, 🔀 dis-

play (Blue) is displayed.

control unit and each camera image line are af-

fected by electromagnetic noises.

G

Н

J

Κ

L

F

[BSW]

Μ

Ν

< SYSTEM DESCRIPTION >

Switch Name and Function



No.	Name	Function
1	Warning systems switch	Turns BSW system ON/OFF (When the setting of BSW system on the navigation system setting screen is ON)
2	BSW setting screen (Navigation setting screen)	Turns setting of BSW system can be switched between ON and OFF

System Display and Warning

INFOID:000000009723323

[BSW]

INDICATOR AND WARNING LAMP



No.	Name	Description
1	Warning systems ON indicator	Indicates that the LDW system and/or BSW system is ON
	BSW warning lamp (yellow)	Turns ON when BSW system has a malfunction
2	BSW ON indicator lamp (Green)	 Turns ON when BSW system is activated Blinks when the back door is open Blinks when the washer fluid level is low
c3	BSW indicator	Blinks when BSW system is warning to driver

DISPLAY AND WARNING OPERATION

Vehicle condition/ Driver's operation			on	Ac	tion
Warning systems ON indicator	Vehicle speed (Approx.) [km/h (MPH)]	Turn signal condition	Status of ve- hicle detec- tion within detection area	Indication on the BSW indicator	Buzzer
OFF	—	—	—	OFF	OFF

OPERATION

< SYSTEM DESCRIPTION >

Vehicle condition/ Driver's operation				Ac	tion	
Warning systems ON indicator	Vehicle speed (Approx.) [km/h (MPH)]	Turn signal condition	Status of ve- hicle detec- tion within detection area	Indication on the BSW indicator	Buzzer	B
	Less than ap- prox. 29 (18)	_	_	ON	OFF	С
		_	Vehicle is absent	ON	OFF	
		OFF	Vehicle is detected	ON	OFF	D
ON	Approx. 32 (20) or more	ON (vehicle de- tected direc- tion)	Before turn signal oper- ates Vehicle is detected Vehicle is detected af-	Blink 200 ms Indicator OFF 200 ms JSOIA0251GB Blink 200 ms Indicator OFF	Short continuous beep Buzzer ON Buzzer OFF 550 ms JSOIA0252GB	F
			ter turn sig- nal operates	Indicator	UFF	

NOTE:

• If vehicle speed exceeds approximately 32 km/h (20MPH), BSW function operates until the vehicle speed becomes lower than approximately 29km/h (18MPH).

• Time shown in the figure is approximate time.

Κ

Μ

Ν

DAS

Ρ

HANDLING PRECAUTION

Precautions for Blind Spot Warning

INFOID:000000009723324

[BSW]

REAR VIEW CAMERA HANDLING

The rear view camera for the LDW/BSW systems is located above the rear licence plate. To keep the proper operation of the LDW/BSW systems and prevent a system malfunction, be sure to observe the following:

- Always keep the rear view camera clean. Be careful not to damage the nozzle of automatic washer and blower.
- Do not attach "licence plate accessory" that reflect light.
- Do not strike or damage the areas around the rear view camera.

BLIND SPOT WARNING (BSW)

- The BSW system is not a replacement for proper driving procedure and is not designed to prevent contact with vehicles or objects. When changing lanes, always use the side and rear mirrors and turn and look in the direction you will move to ensure it is safe to change lanes. Never rely solely on the BSW system.
- The rear view camera may not detect properly under the following conditions:
- When towing a trailer.
- When strong light enters the rear view camera. (For example, direct sunlight or headlight from the rear)
- When ambient brightness changes instantly. (For example, when the vehicle enters or exits a tunnel or passes under a bridge.)
- Automatic washer and blower may not be able to secure detection capability when excessive dirt adheres on the camera lens.
- The camera unit may not be able to detect when certain objects are present such as:
- Pedestrians, bicycles, animals
- Several types of vehicles such as motorcycles
- Oncoming vehicles
- A vehicle approaching rapidly from behind.
- A vehicle which your vehicle overtakes rapidly.
- The rear view camera may not be able to detect property when your vehicle travels beside the middle section of a vehicle with long wheelbase(e.g. trailer truck, semi-trailer, tractor).
- The rear view camera detection zone is designed based on a standard lane width. When driving in a wider lane, the camera unit may not detect vehicles in an adjacent lane. When driving in a narrow lane, the camera unit may detect vehicles driving two lanes away.
- The rear view camera is designed to ignore most stationary objects, however objects such as guardrails, walls, foliage and parked vehicles may occasionally be detected. This is a normal operating condition.
- The rear view camera may detect reflection image of vehicles or roadside objects that are not actually in the detection zone, especially when the road is wet.

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (CAMERA CONTROL UNIT)

CONSULT Function

INFOID:000000009723325

[BSW]

А

В

Н

J

Κ

Ρ

CONSULT FUNCTIONS

CONSULT performs the following functions via the CAN communication with the camera control unit.

Diagnosis mode	Description
ECU Identification	Camera control unit part number can be identified.
Self Diagnostic Results	Camera control unit diagnosis is performed. Current and previous malfunctions are displayed collectively.
Data Monitor	Diagnosis of vehicle signal that is received by camera control unit can be performed.
Work Support	 Target line calibration of rear wide view can be performed. Display of predicted course line can be switched to ON/OFF. Calibration and initialization of rear view camera can be performed. Neutral position adjustment of steering angle sensor can be performed. Calibration for LDW and BSW can be performed. Displays causes of system cancellation occurred during system control.
Active Test	Enables an operational check of a load by transmitting a driving signal from the camera control unit to the load.
Configuration	 The vehicle specification that is written in camera control unit can be displayed or stored. The vehicle specification can be written when camera control unit is replaced.

ECU IDENTIFICATION

Camera control unit part number can be identified.

SELF DIAGNOSIS RESULT

Refer to DAS-128, "DTC Index".

- In CONSULT self-diagnosis, self-diagnosis results and error history are displayed collectively.
- The current malfunction indicates "CRNT". The past malfunction indicates "PAST".
- The timing is displayed as "0" if any of the error codes [U1000] and [U1010] is detected. The counter increases by 1 if the condition is normal at the next ignition switch ON cycle.

Freeze Frame Data (FFD)

The following vehicle status is recorded when DTC is detected and is displayed on CONSULT.

Item name	Display content
	Numerical value is displayed indicating the number of times that ignition switch is turned ON after the DTC is detected.
	• When "0" is displayed, it indicates that the system is presently malfunctioning.
IGN counter (0 to 39)	 When any numerical number other than "0" is displayed, it indicates that system malfunction in the past is detected, but the system is presently normal. NOTE:
	Each time when ignition switch turns OFF \rightarrow ON, numerical number increases from $1\rightarrow 2\rightarrow 338\rightarrow 39$.
	When number of times exceeds 39, numeric display does not increase and 39 is displayed until self-diag- nosis is erased.

DATA MONITOR **NOTE**:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

• Displays the status of the following vehicle signals inputted into the camera control unit.

• For each signal, actual signal can be compared with the condition recognized on the system.

Display Item	Remarks	
ST ANGLE SENSOR SIGNAL [ON/OFF]	Receiving status of steering angle signal received from steering angle sensor is switched to ON/OFF.	
REVERSE SIGNAL [ON/OFF]	Receiving status of reverse signal received from AV control unit is displayed by ON/OFF.	

< SYSTEM DESCRIPTION >

Display Item	Remarks		
VEHICLE SPEED SIGNAL [ON/OFF]	Receiving status of vehicle speed signal received from ABS actuator control unit is displayed by ON/OFF.		
ILL [ON/OFF]	Receiving status of dimmer signal received from BCM is displayed by ON/OFF.		
CAMERA SWITCH SIGNAL [ON/OFF]	Receiving status of camera switch signal received from AV control unit is displayed by ON/ OFF.		
CAMERA OFF SIGNAL [ON/OFF]	Receiving status of camera OFF signal received from AV control unit is displayed by ON/OFF.		
ITS SW 1 [ON/OFF]	Indicates the state of the warning system switch as seen by the camera control unit.		
ITS SW 1 IND [ON/OFF]	Indicates the state of the warning system switch indicator output.		
ST ANGLE SENSOR TYPE [ABSOLUTE]	Input type of steering angle sensor is displayed. NOTE: For this vehicle, "Absolute" is displayed.		
STEERING GEAR RATIO TYPE [TYPE1]	Type of steering gear ratio is displayed. NOTE: For this vehicle, "TYPE 1" is displayed.		
STEERING POSITION [LHD]	Steering position is displayed. NOTE: For this vehicle, "LHD" is displayed.		
WASH SW [ON/OFF]	Indicates [On/Off] status of the washer switch signal input		
REAR CAMERA IMAGE SIGNAL [OK/NG]	Input status of rear view camera image signal is displayed by OK/NG in real time.		
R-CAMERA COMM STATUS [OK/NG]	Communication status with rear camera is displayed by OK/NG in real time.		
R-CAMERA COMM LINE [OK/NG]	Status of communication line with rear camera is displayed by OK/NG in real time.		
TURN SIGNAL [ON/OFF]	Indicates [On/Off] status of the turn signal input		
ITS SW 2 [No setting]	Indicates the status of warning systems switch as seen by the camera control unit. NOTE: For this vehicle, "No setting" is displayed.		
PUMP COMM STATUS [OK/NG]	Communication status with pump control unit is displayed by OK/NG in real time.		
ITS SW 2 IND [No setting]	Indicates the status of warning systems switch indicator output. NOTE: For this vehicle, "No setting" is displayed.		

WORK SUPPORT

Display Item	Remarks	
REAR WIDE-VIEW FIXED GUIDE LINE CORRECTION	The position of rear wide view guiding line can be changed.	
PREDICTIVE COURSE LINE DIS- PLAY	ON/OFF setting of predictive course line can be performed.	
INITIALIZE CAMERA IMAGE CALI- BRATION	The calibration can be initialized to factory shipment condition. NOTE: Calibration of camera image caused by misalignment of the camera installation position is per- formed.	

< SYSTEM DESCRIPTION >

Display Item	Remarks	
STEERING ANGLE SENSOR AD- JUSTMENT	Steering angle sensor neutral position can be adjusted and registered. CAUTION: For vehicles with VDC, adjust the steering angle sensor neutral position on the ABS ac- tuator control unit side. Refer to <u>BRC-9, "ADJUSTMENT OF STEERING ANGLE SENSOR</u> <u>NEUTRAL POSITION : Special Repair Requirement"</u> .	B
REAR CAMERA ITS	Calibration for LDW/BSW can be performed.	
CAUSE OF LDW CANCEL	Displays causes of automatic system cancellation occurred during control of the LDW system.	С
CAUSE OF BSW CANCEL	Displays causes of automatic system cancellation occurred during control of the BSW system.	

NOTE:

• Causes of the maximum five cancellations (system cancel) are displayed.

• The displayed cancellation causes display the number of the ignition switch ON/OFF up to 254. It is fixed to 254 if it is over 254. It returns to 0 when the same cancellation cause is detected again.

Display Items for The Cause of LDW/BSW Cancel

Cause of cancellation	Description	
REAR CAMERA DIRTY	Rear view camera lens is dirty.	
TRUNK OPEN	Back door is open.	
TRAILER HITCH ON	Towing (by attaching a trailer).	G
R CAMERA COMM ERR	Communication error between camera control unit and rear view camera.	
LOW WASH FLUID	Washer fluid level is low.	
LO TMP(AIR WIPING)	Ambient temperature drops to -20 °C (-4 °F) or less.	H
LO TMP(WSH WIPING)	Ambient temperature drops to -20 °C (-4 °F) or less.	
NO RECORD	-	

ACTIVE TEST

CAUTION:

- Never perform "Active Test" while driving the vehicle.
- The "Active Test" cannot be performed when the following systems warning indicator is illuminated.
- Lane departure warning lamp
- BSW warning lamp
- Shift the selector lever to "P" position, and then perform the test.

Test items	Description	
LED LH INDICATOR	BSW indicator LH can be illuminated by ON/OFF operations as necessary.	
LED RH INDICATOR	BSW indicator RH can be illuminated by ON/OFF operations as necessary.	
WASH ACTIVE	Camera washer can be operated by ON/OFF operations as necessary.	
AIR ACTIVE	Camera blower can be operated by ON/OFF operations as necessary.	
AIR & WASH ACTIVE	Camera blower and washer can be operated by ON/OFF operations as necessary.	

LED LH INDICATOR

Test item	Operation	Description	BSW indicator LH	DAS
LED LH INDICATOR	Off	Stops transmitting the BSW indicator LH signal below to end the test	OFF	
	On	Transmits the BSW indicator LH signal to the BSW indicator	ON	Ρ

LED RH INDICATOR

[BSW]

D

Е

J

Κ

< SYSTEM DESCRIPTION >

[BSW]

Test item	Operation	Description BSW indicator RH	
LED RH INDICATOR	Off	Stops transmitting the BSW indicator RH signal below to end the test	OFF
	On	Transmits the BSW indicator RH signal to the BSW indicator	ON

WASH ACTIVE

Test item	Operation	Description Rear view camera was	
WASH ACTIVE -	Off	Stops transmitting the rear view camera washer signal below to end the test	OFF
	On	Transmits the rear view camera washer signal to the pump control unit via communication line	ON

AIR ACTIVE

Test item	Operation	Description Rear view camera air blov	
AIR ACTIVE	Off	Stops transmitting the rear view camera air blow signal below to end the test	OFF
	On	Transmits the rear view camera air blow signal to the pump control unit via communication line	ON

AIR & WASHER ACTIVE

Test item	Operation	Description	Rear view camera air blower and washer
AIR & WASHER AC- TIVE	Off	Stops transmitting the rear view camera air blow / washer signal below to end the test	OFF
	On	Transmits the rear view camera air blow / washer signal to the pump control unit via communication line	ON

CONFIGURATION

Configuration includes functions as follows.

Function		Description
Read/Write Configuration	Before Replace ECU	Allows the reading of vehicle specification written in camera con- trol unit to store the specification in CONSULT.
	After Replace ECU	Allows the writing of the vehicle information stored in CONSULT into the camera control unit.
Manual Configuration		Allows the writing of the vehicle specification into the camera con- trol unit by hand.

ECU DIAGNOSIS INFORMATION CAMERA CONTROL UNIT

Reference Value

VALUES ON THE DIAGNOSIS TOOL

NOTE:

С The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

CONSULT	MONITOR	ITEM
00110021		

Monitor Item		Condition	Value/Status
ST ANGLE SENSOR SIGNAL	Ignition switch	When steering angle sensor signal is input	ON
[ON/OFF]	ON	Other than the above	OFF
REVERSE SIGNAL	Ignition switch	R position	ON
[ON/OFF]	ON	Other than R position	OFF
VEHICLE SPEED SIGNAL	Ignition switch	When vehicle speed is input	ON
[ON/OFF]	ON	Other than the above	OFF
ILL	Ignition switch	When lighting switch is ON	ON
[ON/OFF]	ON	When lighting switch is OFF	OFF
CAMERA SWITCH SIGNAL	Ignition switch	When camera switch signal is input	ON
[ON/OFF]	ŎN	Other than the above	OFF
CAMERA OFF SIGNAL	Ignition switch	When camera OFF signal is input	ON
[ON/OFF]	ON	Other than the above	OFF
ITS SW 1	Ignition switch	Warning systems switch is ON. (Warning systems ON indicator illuminates.)	ON
[ON/OFF]	ON	Warning systems switch is OFF. (Warning systems ON indicator OFF.)	OFF
ITS SW 1 IND	Ignition switch	Warning systems ON indicator illuminates.	ON
[ON/OFF]	ON	Warning systems ON indicator OFF	OFF
ST ANGLE SENSOR TYPE [Absolute]	Ignition switch ON	_	Absolute
STEERING GEAR RATIO TYPE [TYPE1]	Ignition switch ON	_	TYPE1
STEERING POSITION [LHD]	Ignition switch ON	_	LHD
WASH SW	Ignition switch	When washer switch signal is input	ON
[ON/OFF]	ON	Other than the above	OFF
		When rear camera image signal input status is normal	OK
REAR CAMERA IMAGE SIGNAL [OK/NG]	ON	When rear view camera image signal input status is not normal	NG
R-CAMERA COMM STATUS	Ignition switch	When communication status with rear camera is nor- mal	ОК
[OK/NG]	ON	When communication status with rear camera is not normal	OFF ON OFF Absolute TYPE1 LHD ON OFF NG OF ON OF NG OF ON OF NG OFF NS ON OFF NS ON OFF NS ON OFF No se
TURN SIGNAL	Ignition switch	Turn signal is ON	ON
[ON/OFF]	ŌN	Turn signal is OFF	OFF
ITS SW 2 [No setting]	Ignition switch ON	—	No setting

INFOID:000000009723326

А

В

< ECU DIAGNOSIS INFORMATION >

[BSW]

Monitor Item	Condition		Value/Status
PUMP COMM STATUS	Ignition switch	When communication signal is input	OK
[OK/NG]	ON	Other than the above	NG
ITS SW 2 IND [No setting]	Ignition switch ON	_	No setting

TERMINAL LAYOUT



PHYSICAL VALUES

Terr (Wire	minal color)	Description			Condition	Standard value	Reference value
+	_	Signal name	Input/ Output		Condition	Standard value	(Approx.)
1 (B)	Ground	Ground	_	Ignition switch ON	_	0 - 0.1 V	0 V
2 (V)	1 (B)	Battery power supply	Input	Ignition switch OFF	_	9.5 - 16 V	Battery voltage
3 (G)	1 (B)	Ignition signal	Input	Ignition switch ON	_	9.5 - 16 V	Battery voltage
7 (R)	Ground	BSW indicator LH	Output	Ignition switch ON	Approx. 2 sec. after ignition switch OFF \Rightarrow ON (bulb check).	5.5 - 16 V	6.0 V
8 (G)	Ground	BSW indicator RH	Output	Ignition switch ON	Approx. 2 sec. after ignition switch OFF \Rightarrow ON (bulb check)	5.5 - 16 V	6.0 V
15	Ground	Warning systems ON	Output	Ignition switch	Warning systems ON indi- cator ON	0 - 0.1 V	0 V
(BR)	Ground	indicator	Output	ON	Warning systems ON indi- cator OFF	9.5 - 16 V	12.0 V
17	Cround	Warning systems	lagut	Ignition	When warning systems switch is not pressed	9.5 - 16 V	12.0 V
(GR)	Ground	switch	input	ON	When warning systems switch is pressed	0 - 0.1 V	0 V
25	1	5	-	Ignition	R position	9.5 - 16 V	12.0 V
(R)	(B)	Reverse signal	Input	switch ON	Other than R position	0 - 0.1 V	0 V
27 (L)	_	CAN-H	Input/ Output	_	_	_	_
28 (P)		CAN-L	Input/ Output	_	_		_

< ECU DIAGNOSIS INFORMATION >

Terr (Wire	minal e color)	Description				Chan do rel volvo	Reference value	А
+	-	Signal name	Input/ Output		Condition	Standard Value	(Approx.)	
36 (W)	Ground	Communication sig- nal (CAMERA → PUMP)	Output	lgnition switch ON		Input the wavefor with the comm (V) 6 4 2 0 •••••1ms	PKIB5039J	B C D
37 (SB)	Ground	COMM GND	_	Ignition switch ON		0 - 0.1 V	0 V	E
38 (V)	Ground	Communication signal (PUMP \rightarrow CAMERA)	Input	Ignition switch ON		Input the wavefor with the comm (V) 6 4 2 0 •••••1ms	PKIB5039J	F G
40	Ground	Washer level switch	Input	Ignition switch	Washer is empty	0 - 0.1 V	0 V	_
(R)	Cround		mpar	ON	Washer is not empty	9.5 - 16 V	12 V	.
47 (B)	48	Camera image signal	Output	lgnition switch ON		(V) 1 -1 -1	JSNIA0834GB	J
48	Ground	Camera image signal ground		Ignition switch ON	_	0 - 0.1 V	0 V	L
49 (W)	52 (R/W)	Rear camera commu- nication signal	Input/ Output	Ignition switch ON	_	Input the wavefor with the comm (V) 5 4 3 2 4 1 0	JSNIA0836GB	M N DA
50 (R/L)	52 (R/W)	Rear camera power supply	Output	Ignition switch ON		5.0 - 9.0 V	6.0 V	Р
52 (R/W)	Ground	Rear camera ground	_	Ignition switch ON	_	0 - 0.1 V	0 V	

[BSW]

< ECU DIAGNOSIS INFORMATION >

Terr (Wire	ninal color)	Description			Condition	Standard value	Reference value
+	_	Signal name	Input/ Output		Condition	(Approx	
53 (B)	54	Rear camera image signal (+)	Input	lgnition switch ON	_	Input the wavefor with the camer	orm synchronized ra image signal.
						40 μ	JSNIA0834GB
54	Ground	Rear camera image signal (–)	—	Ignition switch ON	_	0 - 0.1 V	0 V

Fail-Safe

INFOID:000000009723327

DTC Display contents of CONSULT	Malfunction detection condition	Fail-safe condition
C1A03 VHCL SPEED SE CIRC	If the vehicle speed signal (wheel speed) from ABS actuator and electric unit (control unit) re- ceived by the camera control unit via CAN com- munication, are inconsistent	LDW system is cancelBSW system is cancel
C1A04 ABS/TCS/VDC CIRC	If a malfunction occurs in the VDC/TCS/ABS system	 LDW system is cancel BSW system is cancel
C1A39 STRG SEN CIR	If the steering angle sensor is malfunction	 LDW system is cancel BSW system is cancel
U0122 VDC P-RUN DIAGNOSIS	If camera control unit detects an error signal that is received from ABS actuator and electric unit (control unit) via CAN communication	LDW system is cancelBSW system is cancel
U0416 VDC CHECKSUM DIAGNOSIS	If camera control unit detects an error signal that is received from ABS actuator and electric unit (control unit) via CAN communication	LDW system is cancelBSW system is cancel
U0428 ST ANGLE SENSOR CALIBRA- TION	Neutral position adjustment of steering angle sensor is not complete.	 Predicted course line is not displayed. MOD (Moving Object Detection) function is stopped. LDW system is stopped. BSW system is stopped.

< ECU DIAGNOSIS INFORMATION >

[BSW]

DTC Display contents of CONSULT	Malfunction detection condition	Fail-safe condition
U1000 CAN COMM CIRCUIT	When camera control unit cannot transmit/re- ceive CAN communication signal continuously for 2 seconds or more.	 The following functions are stopped When communication of steering angle sensor signal is not normal Predicted course line is not displayed. MOD (Moving Object Detection) function is stopped. LDW system is stopped. Front tire angle display is stopped. Using "SETTING" menu display, switch each indicator of predicted course line display and MOD switch to "OFF" (turn OFF) so that switch operation cannot be performed. When communication of vehicle signal, wheel speed sensor signal, and shift signal is not normal Predicted course line is not displayed. MOD (Moving Object Detection) function is stopped. USING "SETTING" menu display, switch each indicator of predicted course line display and MOD switch to "OFF" (turn OFF) so that switch operation cannot be performed. When communication of vehicle signal, wheel speed sensor signal, and shift signal is not normal Predicted course line is not displayed. MOD (Moving Object Detection) function is stopped. LDW system is stopped. BSW system is stopped. Using "SETTING" menu display, switch each indicator of predicted course line display and MOD switch to "OFF" (turn OFF) so that switch operation cannot be performed When communication of sonar signal is not normal
U1010 CONTROL UNIT (CAN)	CAN initial diagnosis malfunction is detected.	 Predicted course line is not displayed. MOD (Moving Object Detection) function is stopped. LDW system is stopped. BSW system is stopped.
U111A REAR CAMERA IMAGE SIGNAL	No-signal status of rear camera image signal is continued for 500 ms or more while ignition switch is ON. NOTE: Current malfunction is displayed only and is not saved.	 Camera image is not displayed (Gray screen display). LDW system is stopped. BSW system is stopped.
U1232 ST ANGLE SEN CALIB	Neutral position adjustment of steering angle sensor is performed. NG signal from steering angle sensor is received.	 Predicted course line is not displayed. MOD (Moving Object Detection) function is stopped. LDW system is stopped. BSW system is stopped. Tire icon is stopped. Using "SETTING" menu display, switch each indicator of predicted course line display and MOD switch to "OFF" (turn OFF) so that switch operation cannot be performed.
U1305 CONFIG UNFINISH	The vehicle setting of camera control unit is in- complete. NOTE: Current malfunction is displayed only and is not saved.	Operation is according to the vehicle setting value as default value.
U1308 R-CAMERA (R&L) CALIB JDG- MNT	Camera image calibration is incomplete	 MOD (Moving Object Detection) function is stopped. LDW system is stopped. BSW system is stopped.

< ECU DIAGNOSIS INFORMATION >

DTC Display contents of CONSULT	Malfunction detection condition	Fail-safe condition
U1309 PUMP INPUT CURRENT JUDGE	Camera control unit detects the value of current from pump control unit is incorrect	 MOD (Moving Object Detection) function is stopped. LDW system is stopped. BSW system is stopped.
U130B RR CAMERA COMM ERROR	Camera control unit receives the incorrect com- munication signal from rear view camera	 MOD (Moving Object Detection) function is stopped. LDW system is stopped. BSW system is stopped.
U1310 PUMP ECU JUDGE	If the pump control unit is malfunction	LDW system is stopped.BSW system is stopped.
	When camera control unit is not normal.	Switch to camera screen is not allowed.
Other	When communication between camera control unit and each camera is not normal.	On applicable camera screen <u>A</u> marking (Red) is displayed.
	When communication line between camera control unit and each camera image line are af- fected by electromagnetic noises.	On applicable camera image screen, X display (Blue) is displayed.

DTC Inspection Priority Chart

INFOID:000000009723328

[BSW]

If multiple DTCs are detected simultaneously, check them one by one depending on the following DTC inspection priority chart.

Priority	Detected items (DTC)
1	U1000: CAN COMM CIRCUIT U1010: CONTROL UNIT (CAN)
2	U1232: ST ANGLE SEN CALIB U1305: CONFIG UNFINISH
3	U0428: ST ANGLE SENSOR CALIBRATION
4	U130B: RR CAMERA COMM ERROR
5	U1308: R-CAMERA (R&L) CALIB JDGMNT
6	 C1A04: ABS/TCS/VDC CIRC C1A39: STRG SEN CIR U0122: VDC P-RUN DIAGNOSIS U0416: VDC CHECKSUM DIAGNOSIS U111A: REAR CAMERA IMAGE SIGNAL U1309: PUMP INPUT CURRENT JUDGE U1310: PUMP ECU JUDGE
7	C1A03: VHCL SPEED SE CIRC

DTC Index

INFOID:000000009723329

		Warnir	ng lamp	"MOD" (Move	
DTC	CONSULT display	Lane depar- ture warning lamp	BSW warning Iamp	ing Object De- tection) icon	Reference
C1A03	VHCL SPEED SE CIRC	ON	ON	Orange	DAS-149, "DTC Log- ic"
C1A04	ABS/TCS/VDC CIRC	ON	ON	Orange	DAS-150, "DTC Log- ic"
C1A39	STRG SEN CIR	ON	ON	Orange	DAS-151, "DTC Log- ic"
U0122	VDC P-RUN DIAGNOSIS	ON	ON	Orange	DAS-152, "DTC Log- ic"

< ECU DIAGNOSIS INFORMATION >

[BSW]

		Warnir	ng lamp	"MOD" (Mov-		٨
DTC	CONSULT display	Lane depar- ture warning lamp	BSW warning lamp	ing Object De- tection) icon	Reference	A
U0416	VDC CHECKSUM DIAGNOSIS	ON	ON	Orange	DAS-153, "DTC Log- ic"	В
U0428	ST ANGLE SENSOR CALIBRATION	ON	ON	Orange	DAS-154, "DTC Log- ic"	С
U1000	CAN COMM CIRCUIT	ON	ON	Orange	DAS-155. "DTC Log- ic"	
U1010	CONTROL UNIT (CAN)	ON	ON	Orange	DAS-156, "DTC Log- ic"	D
U111A	REAR CAMERA IMAGE SIGNAL	ON	ON	Orange	DAS-157, "DTC Log- ic"	Е
U1232	ST ANGLE SEN CALIB	ON	ON	Orange	DAS-159, "DTC Log- ic"	
U1305	CONFIG UNFINISH	ON	ON	Orange	DAS-160, "DTC Log- ic"	F
U1308	R-CAMERA (R&L) CALIB JDGMNT	ON	ON	Orange	DAS-161, "DTC Log- ic"	G
U1309	PUMP INPUT CURRENT JUDGE	ON	ON	Blue	DAS-162, "DTC Log- ic"	
U130B	RR CAMERA COMM ERROR	ON	ON	Orange	DAS-163, "DTC Log- ic"	Н
U1310	PUMP ECU JUDGE	ON	ON	Blue	DAS-164. "DTC Log- ic"	I

J

Κ

L

M

Ν

DAS

Ρ

< ECU DIAGNOSIS INFORMATION >

PUMP CONTROL UNIT

Reference Value



PHYSICAL VALUES

Terr (Wire	minal color)	Description			Condition	Standard value	Reference value
+	-	Signal name	Input/ Output		Condition	Standard value	(Approx.)
1	2	Air pump power sup-		Ignition	Air pump operated	9.5 - 16 V	12 V
(W)	(B)	ply	Output	Switch	Other than above	0 - 0.1 V	0 V
2 (B)	Ground	Air pump ground		Ignition switch ON	_	0 - 0.1 V	0 V
3	5 (P)	Rear view camera	Output	Ignition switch	Rear view camera washer operated	0 - 0.1 V	0 V
(L)	(В)	washer relay 2		ON	Other than above	9.5 - 16 V	12 V
4 (P)	5 (P)	Rear view camera	Output	Ignition switch	Rear view camera washer operated	0 - 0.1 V	0 V
(K)	(D)	washer relay i		ON	Other than above	9.5 - 16 V	0 V
5 (B)	Ground	Ground		Ignition switch ON	_	0 - 0.1 V	0 V
6 (SB)	_	Communication line ground	_	Ignition switch ON	_	0 - 0.1 V	0 V
7 (V)	_	Communication line (PUMP \rightarrow CAMERA)	Output	lgnition switch ON		Input the waveform the commun (V) 6 4 7 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	n synchronized with ication status.

INFOID:000000009723330

JSOIA0648ZZ

PUMP CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Terr (Wire	ninal color)	Description			Condition	Standard value	Reference value	А
+	_	Signal name	Input/ Output		Condition	Standard Value	(Approx.)	
						Input the waveform the commun	n synchronized with ication status.	В
8 (W)	_	Communication line (CAMERA \rightarrow PUMP)	Input	Ignition switch ON	_			С
						<u>→</u> 1ms	PKIB5039J	D
9	5		_	Ignition	Rear washer switch is ON.	0 - 0.1 V	0 V	_
(G)	(B)	Rear washer status	input	switch ON	Rear washer switch is OFF.	9.5 - 16 V	12 V	E
10	5	Rear washer switch		Ignition	Rear washer switch is ON.	9.5 - 16 V	12 V	
(BR)	(B)	input	Input	switch ON	Rear washer switch is OFF.	0 - 0.1 V	0 V	F
12 (Y)	5 (B)	Ignition power supply	Input	Ignition switch ON	_	9.5 - 16 V	12 V	G

Н

[BSW]

J

Κ

L

Μ

Ν

DAS

Ρ

[BSW]

WIRING DIAGRAM DRIVER ASSISTANCE SYSTEMS

Wiring Diagram



DRIVER ASSISTANCE SYSTEMS

DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >

[BSW] DATA LINK CONNECTOR M4 4 BCM (BODY CONTROL M122) M122) 8 COMBINATION METER (M34) ĝ WASHER LEVEL SWITCH E338 E339 E105 EB (FFM) ÷ 59 B11 40 CAMERA CONTROL UNIT (B92), (B93) œ BSW INDICATOR RH D54 D41 M18 L B11 50 28 4 D18 D18 D18 M20 B11 M77 DAS (\mathbf{b}) 27 51 JROWC0299GB

Ρ

А

В

С

D

Ε

F

G

Н

J

Κ

L

Μ

Ν



	_
Connector Nu. B18 Connector Nume WIZE TO WIRE Connector Nume Signal Name [Specification] Under Log Signal Name [Specification] Distribution BS Distribution Ornector Nume MIZE TO WIRE End V Distribution End Nume Distribution End Number Specification Distribution End RSWNIDATION HI Distribution	
88 88 9 89 6 9 89 6 0 89 6 0 89 7 0 80 7 0 81 7 0 82 8 0 80 7 0 81 7 0 82 8 0 83 10 0 84 10 11 10 10 11 10 10 11 10 10 11 11 10 11 11 10 11 11 10 11	
	1
48 0 0 48 1 0 53 1 1 1 1 53 1 1 1 1 54 1 1 1 1 1 54 1 1 1 1 1 54 1 1 1 1 1 1 54 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	
ASSISTANCE SYSTEMS	
)

Ρ

DAS

DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >

[BSW]

А

В

С

D

Е

F

G

Н

J

Κ

L

Μ

Ν

JROWC1662GB

		25 V = -	27 R -	29 V –	31 BR	32 R -	33 G	35 L	41 P -	42 GR	44 W -	45 SB -	46 R	51 0	52 L – [Without automatic drive positioner] 52 P – [With automatic drive positioner]	53 L - [With automatic drive positioner]	53 P – [Without automatic drive positioner]	54 LG - [Without automatic drive positioner] 54 SB - [With automatic drive positioner]	55 LG - [With automatic drive positioner]	55 0 - [Without automatic drive positioner]		ionnector No. D41	connector Name WIRE TO WIRE	connector Type TH40FW-CS15		HS 833 4 2 1			-	Ferminal Color Of Signal Name [Specification]	No. Wire 1 G –	4 B	5 W -	- C	
Connector No. D10	Confidector INO. U18	Connector Name BSW INDICATOR LH	Connector Type TH04MW-NH				4 1			Terminal Color Of Signal Name [Specification]	1 R INDICATOR_L	4 B GROUND	_ L _	Connector No. D21	Connector Name WIRE TO WIRE	Connector Type TH40FW-CS15	4				Ľ	Terminal Color Of	No. Wire Signal Name [Specification] C	2 4	3 b	4 α 8 α 9 4 α		8 BR	9 GR				17 Y -		
	or Of Signal Name [Specification]	1	1		B95	BLIMP CONTROL LINIT						26		Signal Name [Specification]	AIR PLIMP POWER SUPPLY	AIR PUMP GROUND	? VIEW CAMERA WASHER RELAY 2 DRIVE SIGNAL	R VIEW CAMERA WASHER RELAY 1 DRIVE SIGNAL -	1	Т	- R WINDOW WASHER STATUS SIGNAL	AR WINDOW WASHER SWITCH SIGNAL	MOLIMOT		TO WIRE	W			1 2	التعنا		Cimal Name [Snanification]	Ognet Matthe Lopechication	1	
Taminal Color C		- NO.	- 2 -		Connector No.	Connector Name	Connector Name		ß	H.S.				Terminal Color Of	No. Wire	2 B	3 L REA	4 R REAF	6 SB	> 3	9 G REA	10 BR RE/		Connector No. B96	Connector Name WIRE	Connector Type TK02	Ð	0 -	1911 1			Terminal Color Of	No. Wire	- ·	- 7

JROWC1663GB

Onderter Na. D 182 onnetor Name more tor Name more tor Name more tor Name more tor Name more tor Name p MRE TO WRE more tor Name p D 182 onnetor Name more tor Name p MRE TO WRE p MRE TO WRE p D 182 onnetor Name p Samu Name p Manue p Manue p Manue p onnetor Name p Samu Name p Manue p Manue p Manue p Manue p onnetor Name nonetor Name p Manue p Manue p
Connector Name Connector Name ERAN VIEW CAMERA Diffe Connector Name REAR VIEW CAMERA Eventor Type Image: Specification on the specification Name REAR VIEW CAMERA Image: Specification

DRIVER ASSISTANCE SYSTEMS

DAS

Ρ

F

G

Н

J

Κ

L

Μ

Ν

D

А

В

С

[BSW]

DRIVER ASSISTANCE

H.S.

	1	T			-	1	I	I	т	т	I	1	1	-		1	1		1	I	1	I	1	-	-	1	1	Т	1	-	-	1	- [With iPod without navigation syste	- [Without iPod and navigation syster	 [With navigation system] 	I	т	I	1	I			
	w	Y	а	L	В	٩	L	SB	GR	ΓC	>	GR	BR	Y	W/L	^	BR	0	٢/٥	SHIELD	w	BR	Y	SB	GR	SB	Y	_	w	BR	GR	0	G	^	Y	Y	œ	w	ΓC	0			
	29	30	38	39	40	47	48	49	50	51	52	53	54	55	56	60	61	62	63	64	99	67	68	69	70	1/	72	73	74	75	76	11	78	78	78	79	80	81	82	83			
	E29	REAR VIEW CAMERA WASHER RELAY 1		MS03FB-M2-LC		[-]	5		4 3 2			Simul Name [Saadification]		-	1	1	1	1			E105			TH70MW-CS10-M3									Simul Name [Condification]		1	1		1	1	-	-	1
	or No.	or Name		or Type	_								Color Of	Wire	W	я	0	0	в			or No.	w Nome		or Type				_					Color Of	Wire	Y	ΓC	GR	9	٩	-	Y	0
	Connecto	Connects		Connecto	ģ	B		2					Terminal	No.		2	3	4	2			Connecto	Connecto		Connecto	ζ	ß		2					Terminal	No.	е	ŝ	9	80	F	12	13	4
	E26	WIRE TO WIRE		NS02MW-CS				4	21				Simul Name [Searification]		1	-			E28	DEAD VIEW CAMERA WASHER BELAV 3		MS03FB-M2-LC			-] 5		4 3 2			[oignal ivame Lopecification	-	-	1	1	T						
	tor No.	for Name		tor Type				9					al Color Of	Wire	В	Y			tor No.	N		tor Type				9					al Color Of	Wire	w	-	GR	GR	*						
	Connec	Connec		Connec	ģ	ß	Ĕ						Termin	No.		2			Connec			Connec	ć	B	Ě						Termin	No.	-	2	e	4	ŝ						
SSISTANCE SYSTEMS	E16	ECM		RH24FB-RZ8-L-LH			81 85 83 97 105 109	82 86 94 96 12 106 110	20 20 20 20 101	22 BE 100 BE 100 100			Simul Name [Snarification]		ACCELERATOR PEDAL POSITION SENSOR 1	ACCELERATOR PEDAL POSITION SENSOR 2	SENSOR POWER SUPPLY	SENSOR GROUND	ASCD STEERING SWITCH	EVAP CONTROL SYSTEM PRESSURE SENSOR	SENSOR POWER SUPPLY	DATA LINK CONNECTOR	SENSOR POWER SUPPLY	SENSOR GROUND	IGNITION SWITCH	ENGINE SPEED OUTPUT SIGNAL	FUEL TANK TEMPERATURE SENSOR	SENSOR GROUND	CAN COMMUNICATION LINE(CAN-L)	CAN COMMUNICATION LINE(CAN-H)	SENSOR GROUND	PNP SIGNAL	SENSOR GROUND	POWER SUPPLY FOR ECM	STOP LAMP SWITCH	ECM GROUND	ECM GROUND	EVAP CANISTER VENT CONTROL VALVE	ASCD BRAKE SWITCH	ECM GROUND	ECM GROUND		
VER A:	tor No.	for Name		tor Type				9					al Color Of	Wire	w	0	BR	8	7	SB	GR	0	-	BR	BR	GR	~	GR	٩.	-	σ	æ	SB	>	SB	8	•	w	9	•	8		
DRIV	Connect	Connect		Connect	4	F	Ę						Terminé	No.	81	82	83	84	85	86	87	88	91	92	93	94	95	96	97	98	100	102	104	105	106	107	108	109	110	Ħ	112		

JROWC1665GB

Connector No. MI Connector Name FUSE BLOCK (J/ B) Connector Type INSIGFW-M2 Connector Type INSIGFW-M2 ALS BAT 60 50 44	Taminal Nue Color Nue Signal Name (Saecification] 1A V V -<	
Connector No. F23 Connector Name Connector Type Connector Con	Terminal New Canadian New Sanad Name (Specification) 1 P.B. Transbassission Ravice Sufficit 3 2 P.L. Transbassission Ravice Sufficit 4 3 C/O Transbassission Ravice Sufficit 4 4 B Ressamssion Ravice Sufficit 4 1 D.M. Wise 2 C/O Transbassion Ravice Sufficit 4 3 C/O Transbassion Ravice Sufficit 4 1 BF.M. Cold Rest 2 C/O Station Cold Rest 2 M.M. Station Cold Rest 2 M.M. Station Rest 2 M.M. Station Rest 2 M.M. Station Rest 2 M.M. Station Rest 2 </td <td></td>	
Connector No. E339 Connector Name Connector Name Connector Type Connector Type Co	Terminal New Calibration New Samal Name (Specification) 3 0 0 4 0 0 9 0 0 9 0 0 11 R - 12 0 - 11 R - 12 R - 13 R - 14 R - 15 - - 16 - - 17 - - 18 - - 19 - - 10 - -	
DRIVER ASSISTANCE SYSTEMS Connector Name MASTER PUMP Connector Type EQETOR AS	Terminal Number Wire Wire Wire Number Colory Of Number Signal Name [Specification] 1 0 - 1 0 - 1 0 - 1 0 -	

JROWC1666GB

Р

DAS

[BSW]

А

В

С

D

Е

F

G

Н

J

Κ

L

Μ

Ν

	П		Π				_			I		Т	Т	Т	Τ-	Л	Г	-	П			Т	Т	Г	П		Т	Т	Π	П	Т	Т	Т	Т	Т	Т	Т	Т	Т	Т	Г	Г	ſ
	M20	WIRE TO WIRE	TH40MW-CS15		1 2 2 4 8 4 7 8 4 R	2014 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	REAR REAR REAR				f Signal Name [Specification]				- With BOSF system and base audio without iPodi	- [With iPod without BOSF evetem]	- [With iPod without BOSE system]	- [With BOSE system and base audio without iPod)	-		-	1	T 1			1	1	1		-	-	I			'	-		,	1	-	-	-	
	r No.	r Name	r Type								Color Of		> c	3		ο α	σ		>	BR	M	SB	_ 0		GR		> 3	: >	BB	٩	>	> (x (r -	- 6	79 3	<u>ء</u> ء	. 88	; œ	ΓC	P	BR	
	Connecto	Connecto	Connecto	đ		2					Terminal	į,	- ^	4 ~	4		2	۵	9	7	80	6	2:	4	15	16	11	6	20	24	25	26	17	62	8	5	7 8	3 5	35	41	42	43	
	M18	WIRE TO WIRE	TH40MW-CS15				28 25 12 25 25 25				Signal Name [Specification]			- [With Bod without BOSE curatom]	- [With BOSE system and base audio without iPod]	- [With ROSF events	- [Without iPod and BOSE system]	- [With iPod without BOSE system]	-	-	1	1	1	-	1	1	1	,	1	1	-	1		1 1	•								
	No.	Name	Type								Color Of		>	-	M	. α	BR	w	GR	G	в	w	× 3	. 2	SB	ΓC	× 0	. «	GR	9	>	× ،	1	Η a	Ľ								
	Connector	Connector	Connector	đ		2					Terminal	<u>;</u> ,	- ^	-	4		2	ŝ	9	7	8	16	1 :	19	20	24	25	28	29	30	31	32	33	5 %	55								
	П		Π				П	Т		–	Т	Т	Т	Т	T	T	T					Т	Т	T			Т	Т		П		Т	Т	Т	Т	Т	Т	Т	1				
	-[With colour display]		-	-		1	-	T			1	I					-	1	1		-	1	1 1	1	1	1		1	T	T		I			I	I							
	>	BR 6	Y	8	L L	œ	œ.	_	в	٩		- 5	5 0	3 >	. >	- ex	۵.	ГG	>	GR	BR	>	SHIELD	: œ	w	٩	5	, H	_	M	BR	œ (: 5	> c	5 (r 3	* *	: 98	3				
	20	21	24	25	29	30	38	39	40	47	48	67 G	8 5	5 5	3	2	55	56	60	61	62	63	64 86	67	68	69	2 F	72	73	74	75	76	//	8/	2 0	8 8	- 	3 22	3				
										_		T	T	T	T	T	T						T	_										T	T	T	т Т	T	т Т	т	т	<u>г</u>	
YSTEMS						14 16	5678				e [Specification]					,	,	1	-						-M3							1	Name [Specification]						,		1		
SSISTANCE S	M4	DATA LINK CONNECTOR	BD16FW			11	/ 3 4				Signal Nam												IIW	WIRE TO WIRE	TH70FW-CS10-	l	Ē	<	9)		Signal										
'ER ASSISTANCE S	or No. M4	3r Name DATA LINK CONNECTOF	or Type BD16FW								Color Of Signal Nam	· ·	3 a			, aa	IJ	ß	٩	Y		:	or No. M11	or Name WIRE TO WIRE	or Type TH70FW-CS10-				•)	0.00	Color UT Signal	a)/4		HR C) c	· ~	: 4		- >	~	

JROWC1667GB

IS SWTCH IS SWTCH IS P IS P	27 Y	With Specification 20 V V 1 W V V V 1 W V V V V 1 V V V V V V 1 V V V V V V V 1 V <t< th=""></t<>
M34 Connector No. M39 Connector No. M39 Oconnector Nom WARNING SYSTEM TH4DFW-H4 Connector Type TrX08FGY		Bit Officient Standing Control in Specification V Entrifer Power Suppry V Entrifer Power Suppry V Entrifer Power Suppry Sign Unitary Entrifer Entrifer Suppry Sign Unitary Entrifer Entrifer Entrifer Suppry Sign Unitary Entrifer Ent
DRIVER ASSISTANCE SYSTEMS Connector Na 46 P Connector Na 51 BG - (With automatic drive positioner) 52 R - (With automatic drive positioner)	S L - (With automatic environment) 53 V - (With automatic environment) 54 V - (Without automatic environment) 55 G - (Without automatic environment) 55 G - (Without automatic environment) 55 S - (With automatic environment)	Terminal Col Terminal Colspan="2">Terminal Colspan="2">Terminal Colspan="2">Terminal Colspan="2" Terminal Colspan="2"

А

В

С

D

Е

F

G

Н

J

Κ

L

Μ

Ν

DAS

Ρ

JROWC1668GB

	IVER AS		Connect	or No.	M103	8 5	B c	NATS ANT AMP. NATS ANT AMP	83 B 87 W	- MICROPHONE SIC	IAI
	_ >		Connect	or Name	COMBINATION SWITCH	8 8	6	IGN RELAV (E/R) CONT	88 88	MICROPHONE SIC	AAL
		1	Connect	or Type	TH16FW-NH	8	<u>΄</u> α	KEYLESS ENTRY RECEIVER COMM	68 0	1	
	M					87	α.	COMBLSW INPUT 5	06	CAN-H	
	BG	-	ſ			88	GR	COMBI SW INPUT 3	91 SB	AV COMM (H)	
	0	1				6	٩	CAN-L	92 SB	AV COMM (H)	
	SHIELD	1	2		1 2 3 4 5 6	91	_	CAN-H			
		1			7 8 0 10 11 12 13 14	92	α	KEY SLOT ILL CONT			
	•					93	۵.	ON IND			
	ΓC	,				95	_	ACC RELAY CONT			
	Y	1				96	Y	CVT SHIFT SELECTOR POWER SUPPLY			
	ч	1	Termina	I Color Of	C: [66	>	SHIFT P			
	Ь	1	Ň	Wire	olgriei ivairre Lopecification	100	٩	PASSENGER DOOR REQUEST SW			
	-	1	÷	0	1	101	W	DRIVER DOOR REQUEST SW			
	BR	1	2	Y	OUTPUT 4	102	Y	BLOWER RELAY CONT			
N N	в	1	8	BG	FR	103	٦	KEYLESS ENTRY RECEIVER POWER SUPPLY			
	W		4	W	IGN	107	0	COMBI SW INPUT 1			
I I	L	-	5	>	OUTPUT 3	108	Ч	COMBI SW INPUT 4			
(B) - (Main automatic diverse lestioner) 8 - (Main automatic diverse lestioner) 8 - (Main automatic diverse lestioner) 9 - (Main automatic diverse lestioner) 10 - (Main automatic diverse lestioner) 11 - (Main automatic diverse lestioner) <tr< td=""><td>L</td><td>-</td><td>9</td><td>8</td><td>GROUND</td><td>109</td><td>SB</td><td>COMBI SW INPUT 2</td><td></td><td></td><td></td></tr<>	L	-	9	8	GROUND	109	SB	COMBI SW INPUT 2			
W - Urth attoantic drive positional W C - Urth attoantic drive positional V -	GR	 [Without automatic drive positioner] 	7	ВR	INPUT 3	110	U	HAZARD SW			
	w	- [With automatic drive positioner]	8		OUTPUT 5						
	н	-	6	BS	INPUT 2						
W Control Notice	>		10	٩	INPUT 4	Connect	or No.	M180			
	N		Ξ	0	INPUT 1	Connect	or Name	AV CONTROL LINIT			
0 1 0 Durl 1, 5 Dometer Type Durl 1, 5 0	٣	-	12	×	OUTPUT 1	5					
	0	1	13	۳	INPUT 5	Connect	or Type	TH32FW-NH			
		T	14	٩	OUTPUT 2	ą					
Bit Dimeter Nine MIZ MIZ <t< td=""><td>></td><td>T</td><td></td><td></td><td></td><td>A PART</td><td></td><td></td><td></td><td></td><td></td></t<>	>	T				A PART					
	0					S H					
P	BR		Connect	or No.	M122			65 67 68 71 72 73 74 75 76			
V Image: constraint of the	٩	-	Connect	or Name	BCM (BODY CONTROL MODULE)			79 80 81 82 83 85 89 90 91 92			
N	>	1									
SE - 1 - - 10 - - 10 - - 11 - - 12 - - 13 - - 14 - - 15 - - 16 - - 17 - - 18 - - 19 - - 10 - - 11 - - 12 - - 13 - - 14 - - 15 - - 16 - - 17 - - 18 - - 19 - - 11 - - 12 - - 13 - - 14 -	×	г	Connect	or Type	TH40FB-NH						
Li	B	г	ą								
Id Id Ministry Ministry Ministry Ministry Y Image:	_	T	EF-			Termina	I Color Of	Signal Name [Specification]			
γ	LG	-				No.	Wire				
Image: Constraint of the problem of the pro	>		2			65	9	PARKING BRAKF			
Terminal Control Contro Control Control <t< td=""><td></td><td></td><td></td><td></td><td>N 80 86 87 10 10 10 10 10 10 10 10 10 10 10 10 10</td><td>67</td><td>-</td><td></td><td></td><td></td><td></td></t<>					N 80 86 87 10 10 10 10 10 10 10 10 10 10 10 10 10	67	-				
Terminal No. Gale Of Were Signal Name [Specification] Terminal To Table Gale Of Signal Signal Name (Specification) 70. Were Were Signal Name [Specification] 73 B MICROFFICE MIC					23 03 93 96 96 96 96 90 20 20 00 90 90 90 90 100	89		,			
Termin Calor Of No. Signal Name [Speedfication] Press MICROPHONE VCC 72 E Root MAIT- 73 R COMM (CONT-DIPP) 73 K COMM (CONT-DIPP) COMM (CONT-DIPP) COMM (CONT-DIPP) 74 V ROOM MAIT- 75 LG AN COMM (CONT-DIPP) 74 V PASSENDERE DOOR MAIT- 75 LG AV COMM (CONT-DIPP) 76 V PORT 76 LG AV COMM (CONT-DIPP) 76 V PORT 76 LG AV COMM (CONT-DIPP) 76 V DORT 79 R LG LG 77 V DORT 79 R LLUMM/CONT SIGNAL 77 V DORT R SIGNAL R 77 D DORT R V MORT RESIDENT R						8 5		CHIELD			
Terminal No. Color Of Wrre Signal Name [Specification] ZZ R Commonscience voc. 72 W ROOM ANT- 73 P Commonscience voc. 73 W ROOM ANT- 76 LG AVCOMILID 74 P COMM CONT-DEPED OOM (LD) AVCOMILID 74 P AVCOMILID 76 LG AVCOMILID 74 V PASSENEER DOOR ANT- 76 LG AVCOMILID 75 V PASSENEER DOOR ANT- 20 G LUMMALIDIN SIGNAL. 75 V Demors DOOR ANT- 21 G G LOMMALIDIN SIGNAL. 77 P Demors DOOR ANT- 29 G LOMMALIDIN SIGNAL.						Ę F	STIELU	MICDODUCIN			
Terminal Location Logical (Laboratication) Zi R Continuity (Laboratication) 72 B Reconstructure 73 L Constructure 73 Y Reconstructure 75 LG AVX COMM (Libbra) 74 Y PrASSENDER DOID ANTI- 75 LG AVX COMM (Libbra) 76 V DORD ANTI- 79 R LLLUMM/CLIBBA 76 V DORD ANTI- 76 LG AVX COMM (Libbra) 76 V DORD ANTI- 79 R LLLUMM/CLIBBA LLUMM/CLIBBA 76 V DORD ANTI- 81 S1 S1 LLLUMM/CLIBBA 77 V DORD ANTI- 81 S1 S1 LLUMM/CLIBBA			}	101		77		MICKUPHONE VCC			
No. Wire			lermina	I Color Of	Signal Name [Specification]	73	2	COMM (CONT-DISP)			
72 B FOOM MNT- 75 LG AX OOM (L) 73 Y FROOM MAT- 76 LG AX OOM (L) 74 Y PASSENDER DOOR MAT- 79 R LLUMINON SIGNAL. 76 V DEREMERT DOOR MAT- 80 C LLUMINON SIGNAL. 76 V DEREMERT DOOR MAT- 80 C LIQUITON SIGNAL. 74 V DEREMERT DOOR MAT- 80 C LIQUITON SIGNAL. 76 V DEREMERT DOOR MAT- 81 S0 National SIGNAL. 77 D DEREMERT DOOR MAT- 81 S0 National SIGNAL.			No.	Wire		74	٩	CAN-L			
73 W MOMANT- 76 LG AV COMMAL 74 Y PASSENGE DOOR ANT- 39 R LLLAMINON SIGNAL 75 V PASSENGE DOOR ANT- 80 G LLLAMINON SIGNAL 76 V Denvise DOOR ANT- 80 G DUITON 77 P Denvise DOOR ANT- 81 S S Valuation			72	8	ROOM ANT-	75	P	AV COMM (L)			
74 Y PASSENGER DOOR ANT 79 R 1LLUMINATION SIGNAL 75 LI.3 PASSENGER DOOR ANT 80 G ILLUMINATION SIGNAL 76 V DRIVER DOOR ANT 81 SB G ISMITION 77 P DRIVER DOOR ANT 87 V VEHICLE SEED NO. 27			73	×	ROOM ANT+	76	ΓC	AV COMM (L)			
75 LG PASSENGER DOGR ANT- 80 G IONTTON 76 V DRIVER DOOR ANT- 81 S8			74	>	PASSENGER DOOR ANT-	79	2	ILLUMINATION SIGNAL			
76 V Definition 81 SB			75	9	PASSENGER DOOR ANT+	8	0	IGNITION			
77 P DRVERDOODANT+ 82 V VEHICLE SPEED SIGNAL (8-DILI SE)			76	>	DRIVER DOOR ANT-	81	e,	REVERSE			
			12	•	DBIVED DOOD ANT+	60	ļ	VEHICLE SPEED STONAL (9-DIILSE)			

JROWC1669GB

OVERALL SEQUENCE

BASIC INSPECTION DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000009723332

		С
↓ 	1	D
1. INTERVIEW FOR MALFUNCTION Interview the customer to obtain information for symptoms using "Diagnostic Work Sheet".		E
2. SELF-DIAGNOSIS WITH CONSULT Perform self-diagnosis with CONSULT. Check that any DTC is detected. Print out (or write down) DTC and freeze frame data.	DIC Is 5. TROUBLE DIAGNOSIS BY DTC detected Perform the trouble diagnosisfor the detected DTC. Specify the malfunctioning part.	F
3. PRE-INSPECTION FOR DIAGNOSIS Perform pre-inspection for diagnosis.		G
4. VERIFY CUSTOMER CONCERN (ACTION TEST)]	Н
Perform action test and verify the customer's concern.		
6. SYMPTOM DIAGNOSIS Perform symptom diagnosis. Specify malfunctioning part.		
SPECIFY MALFUNCTIONING PART)	J
		n.
7. MALFUNCTIONING PART REPAIR Repair or replace the identified malfunctioning parts.		L
	_	
8. REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT) Perform self-diagnosis with CONSULT. Check that any DTC	DTC is detected	M
Is not detected. Erase DTC if DTC is detected before the repair. Check that DTC is not detected again.		
DTC is not detected	_	Ν
9. REPAIR CHECK (ACTION TEST) Perform action test. And check the system operation.	Symptom remains	
Normal operation		DAS
	JSOIA0654GB	Р

DETAILED FLOW

1.INTERVIEW FOR MALFUNCTION

It is also important to clarify the customer concerns before starting the inspection. Interview the customer about the concerns carefully and understand the symptoms fully. **NOTE:**

DAS-143

А

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

The customers are not professionals. Never assume that "maybe the customer means..." or "maybe the customer mentioned this symptom".

>> GO TO 2.

2.SELF-DIAGNOSIS WITH CONSULT

- 1. Perform "All DTC Reading" with CONSULT.
- 2. Check if the DTC is detected on the self-diagnosis results of "AVM".
- 3. When DTC is detected, follow the instructions below:
- Record DTC and Freeze Frame Data.

Is any DTC detected?

YES >> GO TO 5.

NO >> GO TO 3.

3. PRE-INSPECTION FOR DIAGNOSIS

Perform pre-inspection for diagnosis. Refer to DAS-145. "Inspection Procedure".

>> GO TO 4.

4.ACTION TEST

Perform BSW system action test to check the operation status. Refer to <u>DAS-147, "Work Procedure"</u>. Check if any other malfunctions occur.

>> GO TO 6.

5. TROUBLE DIAGNOSIS BY DTC

- 1. Check the DTC in the self-diagnosis results.
- Perform trouble diagnosis for the detected DTC. Specify a malfunctioning part. Refer to <u>DAS-128</u>, "<u>DTC</u> <u>Index</u>" (AVM).

>> GO TO 8.

6.SYMPTOM DIAGNOSIS

Perform the applicable diagnosis according to the diagnosis chart by symptom. Refer to <u>DAS-180, "Symptom</u> <u>Table"</u>.

>> GO TO 7.

7.MALFUNCTIONING PART REPAIR

Repair or replace the identified malfunctioning parts.

>> GO TO 8.

8.REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT)

- 1. Erases self-diagnosis results.
- 2. Perform "All DTC Reading" again after repairing or replacing the specific items.
- 3. Check if any DTC is detected in self-diagnosis results of "AVM".

Is any DTC detected?

YES >> GO TO 5. NO >> GO TO 9.

9.REPAIR CHECK (ACTION TEST)

Perform the BSW system action test. Check that the malfunction symptom is solved or no other symptoms occur.

Is there a malfunction symptom?

YES >> GO TO 4. NO >> INSPECTION END
PRE-INSPECTION FOR DIAGNOSIS

[0011]

< BASIC INSPECTION > [BSW]	
PRE-INSPECTION FOR DIAGNOSIS	
Inspection Procedure	A
1.CHECK REAR VIEW CAMERA LENS	В
<u>Are rear view camera lens contaminated with foreign materials?</u> YES >> Clean rear view camera lens	С
NO $>>$ GO TO 2.	
CHECK REAR VIEW CAMERA INSTALLATION CONDITION	D
Is it properly installed?	
YES >> INSPECTION END NO >> Install rear view camera properly and perform rear view camera calibration. Refer to DAS-53	E
<u>"Description"</u> .	
	F
	0
	G
	Н
	J
	K
	L
	M
	N
	DA
	Ρ

ADDITIONAL SERVICE WHEN REPLACING CAMERA CONTROL UNIT < BASIC INSPECTION > [BSW]

ADDITIONAL SERVICE WHEN REPLACING CAMERA CONTROL UNIT

Description

INFOID:000000009723334

- Always perform the camera control unit configuration after replacing the camera control unit.
- Always perform the rear view camera calibration after removing and installing or replacing the rear view camera.
- Always perform the rear view camera calibration after replacing the camera control unit.
- CAUTION:

The system does not operate normally unless the rear view camera calibration is performed. Always perform it.

Work Procedure

INFOID:000000009723335

1.CAMERA CONTROL UNIT CONFIGURATION

Perform the camera control unit configuration with CONSULT. Refer to DAS-52, "Description".

>> GO TO 2.

2.REAR VIEW CAMERA CALIBRATION

Perform the rear view camera calibration with CONSULT. Refer to DAS-53, "Work Procedure (Preparation)".

>> GO TO 3.

3.PERFORM SELF-DIAGNOSIS

Perform the self-diagnosis of camera control unit with CONSULT (AVM). Check if any DTC is detected. <u>Is any DTC detected?</u>

YES >> Perform the trouble diagnosis for the detected DTC. Refer to <u>DAS-128, "DTC Index"</u>.

NO >> GO TO 4.

4.LDW SYSTEM ACTION TEST

1. Perform the BSW system action test. Refer to DAS-147. "Description".

2. Check that the BSW system operates normally.

>> WORK END

ACTION TEST

< BASIC INSPECTION >	[BSW]
ACTION TEST	
Description	INFOID:000000009723336
 Perform action test to verify the customer's concern. Perform action test and check the system operation after system diagnosis. 	
Be careful of traffic conditions and safety around the vehicle when performing road test. CAUTION: Fully understand the following items well before the road test:	
 Precautions: Refer to <u>DAS-102</u>, "FOR USA AND CANADA : Precaution for BSW System System description for Blind Spot Warning: Refer to <u>DAS-109</u>, "System Description". Normal operating condition: Refer to <u>DAS-185</u>, "Description". 	<u>Service"</u> .
Work Procedure	INFOID:000000009723337
WARNING: Be careful of traffic conditions and safety around the vehicle when performing road test. CAUTION: Fully understand the following items well before the road test; • Precautions: Refer to DAS-102, "FOR USA AND CANADA : Precaution for BSW System	Service".
 System description for Blind Spot Warning: Refer to <u>DAS-109, "System Description"</u>. Normal operating condition: Refer to <u>DAS-185, "Description"</u>. CHECK BSW SYSTEM SETTING 	
 Start the engine. Check that the BSW system setting can be enabled/disabled on the navigation screen. Turn OFF the ignition switch and wait for 5 seconds or more. 	
4. Check that the previous setting is saved when the engine starts again.	
2.BSW SYSTEM ACTION TEST	
1. Enable the patting of the DOW evotors on the povinction person	

- Enable the setting of the BSW system on the navigation screen.
 Turn warning systems switch ON (warning systems ON indicator is ON).
- 3. Check BSW operation according to the following table.

	Vehicle condition/	Driver's operatio	on	Act	ion	
Warning systems ON indicator	Vehicle speed (Approx.) [km/h (MPH)]	Turn signal condition	Status of ve- hicle detec- tion within detection area	Indication on the BSW indicator	Buzzer	M
OFF		—	—	OFF	OFF	

Κ

DAS

Ρ

ACTION TEST

< BASIC INSPECTION >

	Vehicle condition/	Driver's operatio	n	Ac	tion
Warning systems ON indicator	Vehicle speed (Approx.) [km/h (MPH)]	Turn signal condition	Status of ve- hicle detec- tion within detection area	Indication on the BSW indicator	Buzzer
	Less than ap- prox. 29 (18)	_	_	OFF	OFF
		-	Vehicle is absent	OFF	OFF
		OFF	Vehicle is detected	ON	OFF
				Blink	Short continuous beep
ON	Approx. 32 (20) or more	ON (vehicle de-	Before turn signal oper- ates Vehicle is detected	200 ms Indicator ON Indicator OFF 200 ms JSOIA0251GB	80 ms Buzzer ON Buzzer OFF 550 ms JSOIA0252GB
		tected direc- tion)	Vehicle is detected af- ter turn sig- nal operates	Blink 200 ms Indicator OFF 200 ms JSOIA0251GB	OFF

NOTE:

 If vehicle speed exceeds approximately 32 km/h (20MPH), BSW function operates until the vehicle speed becomes lower than approximately 29km/h (18MPH).

• Time shown in the figure is approximate time.

>> INSPECTION END

DTC/CIRCUIT DIAGNOSIS C1A03 VEHICLE SPEED SENSOR

DTC Logic

DTC DETECTION LOGIC

А

INFOID:000000009723338

	Trouble diagnosis name	DIC detecting condition	Possible causes
C1A03	VHCL SPEED SE CIRC	If the vehicle speed signal (wheel speed) from ABS actuator and electric unit (control unit) re- ceived by the camera control unit via CAN com- munication, are inconsistent	 Wheel speed sensor ABS actuator and electric unit (control unit) Camera control unit
NOTE: If DTC "C1. • Refer to <u>I</u> • Refer to <u>I</u>	A03" is detected along DAS-155, "DTC Logic" DAS-150, "DTC Logic"	with DTC "U1000" or "C1A04", first diag for DTC "U1000". for DTC "C1A04".	nose the DTC "U1000" or "C1A04".
DTC CON	FIRMATION PROCE	DURE	
1.PERFO	RM DTC CONFIRMAT	ION PROCEDURE	
1. Start th	e engine.		
2. Turn th 3 Drive t	ie BSW system ON. he vehicle at 30 km/h (19 MPH) or more	
CAUTI	ON:		
4 Stop th	s drive safety. Je vehicle		
5. Perform	n "All DTC Reading" w	ith CONSULT.	
6. Check	if the "C1A03" is detec	ted as the current malfunction in "Self D	agnostic Result" of "AVM".
VES	Refer to DAS-149 "D	iagnosis Procedure"	
NO >>	 Refer to <u>GI-44, "Interr</u> 	nittent Incident"	
Diagnosi	s Procedure		
		indent indent.	INFOID:000000009723339
1 <u></u> -0/			INFOID:000000009723339
1.снеск	SELF-DIAGNOSIS RE	SULTS	INFOID:000000009723339
1.CHECK Check if "C	SELF-DIAGNOSIS RE 1A04" or "U1000" is de	ESULTS etected other than "C1A03" in "Self Diagr	INFOID:000000009723339
1.CHECK Check if "C Is any DTC YES	SELF-DIAGNOSIS RE 1A04" or "U1000" is de detected?	ESULTS etected other than "C1A03" in "Self Diagr	INFOID:00000009723339
1. CHECK Check if "C Is any DTC YES >>	SELF-DIAGNOSIS RE 1A04" or "U1000" is de detected? Perform diagnosis on DAS-155, "DTC Logic	ESULTS etected other than "C1A03" in "Self Diagr the detected DTC and repair or replac	INFOID:00000009723339 nostic Result" of "AVM". e the malfunctioning parts. Refer to
1.CHECK Check if "C Is any DTC YES >> NO >>	SELF-DIAGNOSIS RE 1A04" or "U1000" is de detected? Perform diagnosis on <u>DAS-155, "DTC Logic</u> GO TO 2.	ESULTS etected other than "C1A03" in "Self Diagr the detected DTC and repair or replac	INFOID:00000009723339 mostic Result" of "AVM". e the malfunctioning parts. Refer to
1.CHECK Check if "C Is any DTC YES >> NO >> 2.CHECK	SELF-DIAGNOSIS RE 1A04" or "U1000" is de detected? Perform diagnosis on <u>DAS-155, "DTC Logic</u> GO TO 2. ABS ACTUATOR AND	ESULTS etected other than "C1A03" in "Self Diagr the detected DTC and repair or replac <u>2</u> .	INFOID:00000009723339 nostic Result" of "AVM". e the malfunctioning parts. Refer to ELF-DIAGNOSIS RESULTS
1.CHECK Check if "C Is any DTC YES >> NO >> 2.CHECK Check if an	SELF-DIAGNOSIS RE 1A04" or "U1000" is de detected? Perform diagnosis on DAS-155, "DTC Logic GO TO 2. ABS ACTUATOR ANE y DTC is detected in "S	ESULTS etected other than "C1A03" in "Self Diagr the detected DTC and repair or replac <u>2</u> . D ELECTRIC UNIT (CONTROL UNIT) S Self Diagnostic Result" of "ABS".	INFOID:00000009723339 nostic Result" of "AVM". e the malfunctioning parts. Refer to ELF-DIAGNOSIS RESULTS
1.CHECK Check if "C Is any DTC YES >> NO >> 2.CHECK Check if an Is any DTC	SELF-DIAGNOSIS RE 1A04" or "U1000" is de detected? Perform diagnosis on <u>DAS-155, "DTC Logic</u> GO TO 2. ABS ACTUATOR AND y DTC is detected in "S detected?	ESULTS etected other than "C1A03" in "Self Diagr the detected DTC and repair or replac <u>2</u> . DELECTRIC UNIT (CONTROL UNIT) Si Self Diagnostic Result" of "ABS".	INFOID:00000009723339 nostic Result" of "AVM". e the malfunctioning parts. Refer to ELF-DIAGNOSIS RESULTS
1.CHECK Check if "C Is any DTC YES >> NO >> 2.CHECK Check if an Is any DTC YES >>	SELF-DIAGNOSIS RE 1A04" or "U1000" is de detected? Perform diagnosis on DAS-155, "DTC Logic GO TO 2. ABS ACTUATOR AND y DTC is detected in "S detected? Perform diagnosis on BRC-111, "DTC No. 10	ESULTS etected other than "C1A03" in "Self Diagr the detected DTC and repair or replac <u>2</u> . DELECTRIC UNIT (CONTROL UNIT) S Self Diagnostic Result" of "ABS".	nostic Result" of "AVM". e the malfunctioning parts. Refer to ELF-DIAGNOSIS RESULTS e the malfunctioning parts. Refer to

Ρ

C1A04 ABS/TCS/VDC SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

C1A04 ABS/TCS/VDC SYSTEM

DTC Logic

[BSW]

INFOID:000000009723340

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
C1A04	ABS/TCS/VDC CIRC	If a malfunction occurs in the VDC/TCS/ABS system	ABS actuator and electric unit (control unit)

NOTE:

If DTC "C1A04" is detected along with DTC "U1000", first diagnose the DTC "U1000". Refer to <u>DAS-155, "DTC</u> <u>Logic</u>".

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

- 1. Start the engine.
- 2. Wait for approximately 10 minutes after turning the BSW system ON.
- 3. Perform "All DTC Reading" with CONSULT.
- 4. Check if the "C1A04" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "C1A04" detected as the current malfunction?

- YES >> Refer to <u>DAS-150</u>, "Diagnosis Procedure".
- NO >> Refer to <u>GI-44, "Intermittent Incident"</u>.

Diagnosis Procedure

INFOID:000000009723341

1.CHECK SELF-DIAGNOSIS RESULTS

- 1. Perform "All DTC Reading" with CONSULT.
- 2. Check if the "U1000" is detected other than "C1A04" in "Self Diagnostic Result" of "AVM".

Is "U1000" detected?

- YES >> Perform the CAN communication system inspection. Repair or replace the malfunctioning parts. Refer to <u>DAS-155, "DTC Logic"</u>.
- NO >> GO TO 2.

2. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to <u>BRC-111, "DTC No. Index"</u>.
- NO >> Replace the camera control unit. Refer to DAS-187, "Removal and Installation".

C1A39 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

C1A39 STEERING ANGLE SENSOR

DTC Logic

А

INFOID:000000009723342

DIC	Trouble diagnosis name	DTC detecting condition	Possible causes
C1A39	STRG SEN CIR	If the steering angle sensor is malfunction	Steering angle sensor
NOTE: If DTC "C1. Logic".	A39" is detected along with	DTC "U1000", first diagnose the DTC	C "U1000". Refer to <u>DAS-155, "DTC</u>
DTC CON	FIRMATION PROCEDU	IRE	
1.PERFO	RM DTC CONFIRMATION	PROCEDURE	
1. Turn th 2. Perforr 3. Check Is "C1A39"	e ignition switch ON. n "All DTC Reading" with (if the "C1A39" is detected detected as the current m	CONSULT. as the current malfunction in "Self Dia alfunction?	agnostic Result" of "AVM".
YES >> NO >>	 Refer to <u>DAS-151, "Diag</u> Refer to <u>GI-44, "Intermitted</u> 	nosis Procedure". ent Incident".	
Diagnosi	s Procedure		INFOID:0000000972334
1. снеск	SELF-DIAGNOSIS RESU	LTS	
Check if "U	1000" is detected other that	an "C1A39" in "Self Diagnostic Result	" of "AVM".
<u>ls "U1000"</u>	detected?		
YES >> NO >>	 Perform the CAN communication Refer to <u>DAS-155, "DTC</u> GO TO 2. 	unication system inspection. Repair o <u>Logic"</u> .	or replace the malfunctioning parts
2. снеск	ABS ACTUATOR AND EL	ECTRIC UNIT (CONTROL UNIT) SE	ELF-DIAGNOSIS RESULTS
Check if ar	y DTC is detected in "Self	Diagnostic Result" of "ABS".	
<u>ls any DTC</u>	detected?		
	Perform diagnosis on the	e detected DTC and repair or replace	e the malfunctioning parts. Refer to
YES >>	BRC-111, "DTC No. Inde	<u>x"</u> .	

M

Ν

DAS

Ρ

U0122 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< DTC/CIRCUIT DIAGNOSIS >

U0122 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

DTC Logic

INFOID:000000009723344

[BSW]

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U0122	VDC P-RUN DIAGNO- SIS	If camera control unit detects an error signal that is received from ABS actuator and electric unit (control unit) via CAN communication	ABS actuator and electric unit (control unit)

NOTE:

If DTC "U0122" is detected along with DTC "U1000", first diagnose the DTC "U1000". Refer to <u>DAS-155, "DTC</u> <u>Logic"</u>.

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Start the engine.

- 2. Turn the BSW system ON.
- 3. Perform "All DTC Reading" with CONSULT.
- 4. Check if the "U0122" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U0122" detected as the current malfunction?

YES >> Refer to DAS-152, "Diagnosis Procedure".

NO >> Refer to GI-44, "Intermittent Incident".

Diagnosis Procedure

INFOID:000000009723345

1.CHECK SELF-DIAGNOSIS RESULTS

Check if "U1000" is detected other than "U0122" in "Self Diagnostic Result" of "AVM".

Is "U1000" detected?

YES >> Perform the CAN communication system inspection. Repair or replace the malfunctioning parts. Refer to <u>DAS-155, "DTC Logic"</u>.

NO >> GO TO 2.

2.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ABS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to <u>BRC-111, "DTC No. Index"</u>.
- NO >> Replace the camera control unit. Refer to DAS-187, "Removal and Installation".

U0416 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< DTC/CIRCUIT DIAGNOSIS >

U0416 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

DTC Logic

INFOID:000000009723346

[BSW]

А

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U0416	VDC CHECKSUM DI- AGNOSIS	If camera control unit detects an error signal that is received from ABS actuator and electric unit (control unit) via CAN communication	ABS actuator and electric unit (control unit)
NOTE: f DTC "U041 <u>₋ogic"</u> .	6" is detected along wit	h DTC "U1000", first diagnose the DTC	"U1000". Refer to <u>DAS-155, "DTC</u>
DTC CONF	RMATION PROCED	URE	
1.PERFOR	M DTC CONFIRMATIO	N PROCEDURE	
 Start the Turn the Perform 	engine. BSW system ON. "All DTC Reading" with	CONSULT.	
1. Check if	the "U0416" is detected	as the current malfunction in "Self Dia	gnostic Result" of "AVM".
<u>s "U0416" de</u>	etected as the current n	nalfunction?	
NO >>F	Refer to <u>GI-44, "Intermit</u>	tent Incident".	
Diagnosis	Procedure		INFOID:0000000972334
1.CHECK S	ELF-DIAGNOSIS RES	ULTS	
Check if "U1(000" is detected other the	nan "U0416" in "Self Diagnostic Result"	of "AVM".
s "U1000" de	etected?		
	Perform the CAN comn	nunication system inspection. Repair o	r replace the malfunctioning parts
YES >> F	Refer to DAS-155 "DT(
YES >> F F NO >> 0	Refer to <u>DAS-155, "DT(</u> GO TO 2.	<u>- Logio</u> .	
YES >> F F NO >> C 2.CHECK A	Refer to <u>DAS-155, "DTC</u> GO TO 2. BS ACTUATOR AND E	ELECTRIC UNIT (CONTROL UNIT) SE	LF-DIAGNOSIS RESULTS
YES >> F F NO >> C 2.CHECK A Check if any	Refer to <u>DAS-155, "DTC</u> GO TO 2. BS ACTUATOR AND E DTC is detected in "Se	LECTRIC UNIT (CONTROL UNIT) SE	LF-DIAGNOSIS RESULTS
YES >> F F NO >> C CHECK A Check if any s any DTC d	Refer to <u>DAS-155, "DTC</u> GO TO 2. BS ACTUATOR AND E DTC is detected in "Se letected?	ELECTRIC UNIT (CONTROL UNIT) SE	LF-DIAGNOSIS RESULTS
YES >> F F NO >> C CHECK A Check if any <u>s any DTC d</u> YES >> F	Refer to <u>DAS-155, "DTC</u> GO TO 2. BS ACTUATOR AND E DTC is detected in "Se <u>letected?</u> Perform diagnosis on the	ELECTRIC UNIT (CONTROL UNIT) SE If Diagnostic Result" of "ABS". The detected DTC and repair or replace	LF-DIAGNOSIS RESULTS the malfunctioning parts. Refer to

DAS

Ρ

Ν

U0428 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

U0428 STEERING ANGLE SENSOR

DTC Logic

INFOID:000000009723348

[BSW]

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U0428	ST ANGLE SENSOR CALIBRATION	The neutral position adjustment of the steering angle sensor is incomplete.	 Neutral position of steering angle sensor is not yet adjusted Steering angle sensor

NOTE:

If DTC "U0428" is detected along with DTC "U1232", first diagnose the DTC "U1232". Refer to <u>DAS-159</u>, "<u>DTC</u> <u>Logic</u>".

Diagnosis Procedure

INFOID:000000009723349

1.ADJUST THE NEUTRAL POSITION OF THE STEERING ANGLE SENSOR

When U0428 is detected, adjust the neutral position of the steering angle sensor.

>> Perform adjustment of the neutral position of the steering angle sensor. Refer to <u>BRC-9.</u> <u>"ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair</u> <u>Requirement"</u>.

CAUTION:

For vehicles with VDC, adjust the steering angle sensor neutral position on the ABS actuator control unit side.

< DTC/CIRCUIT DIAGNOSIS >

U1000 CAN COMM CIRCUIT

Description

CAN (Controller Area Network) is a serial communication line for real-time application. It is an on-vehicle mul-В tiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independently). In CAN communication, control units are connected with 2 communication lines (CAN-H, CAN-L) allowing a high rate of information transmission with less wiring. Each С control unit transmits/receives data but selectively reads required data only.

CAN Communication Signal Chart. Refer to LAN-29, "CAN Communication Signal Chart".

DTC Logic

INFOID:000000009723351

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1000	CAN COMM CIRCUIT	Camera control unit is not transmitting or re- ceiving CAN communication signal for 2 sec- onds or more.	CAN communication system
NOTE: If "U100	0" is detected, first dia	gnose the CAN communication system.	<u> </u>
Diagno	osis Procedure		INF0ID:00000009723352
1.PER	FORM THE SELF-DIA	GNOSIS	
 Star Turr Turr Perr Che 	rt the engine. n the BSW system ON, form "All DTC Reading eck if the "U1000" is de	, and then wait for 30 seconds or more. " with CONSULT. tected as the current malfunction in "Se	If Diagnostic Result" of "AVM".
<u>ls "U100</u> YES	00" detected as the cur >> Refer to <u>LAN-18, "</u>	rent malfunction? Trouble Diagnosis Flow Chart".	
NO	>> Refer to <u>GI-44, "In</u>	termittent Incident".	

Ρ

DAS

Μ

Ν

INFOID:000000009723350

А

D

Е

U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

U1010 CONTROL UNIT (CAN)

Description

CAN controller controls the communication of CAN communication signal and the error detection.

DTC Logic

INFOID:000000009723354

INFOID:000000009723355

INFOID:000000009723353

DTC DETECTION LOGIC

DTC Trouble diagnosis name		DTC detecting condition	Possible causes
U1010	CONTROL UNIT (CAN)	CAN initial diagnosis malfunction is detected.	Camera control unit

Diagnosis Procedure

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Start the engine.

- 2. Turn the BSW system ON.
- 3. Perform "All DTC Reading" with CONSULT.
- 4. Check if the "U1010" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U1010" detected as the current malfunction?

- YES >> Replace the camera control unit. Refer to <u>DAS-187</u>, "Removal and Installation".
- NO >> INSPECTION END

U111A REAR CAMERA IMAGE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

U111A REAR CAMERA IMAGE SIGNAL CIRCUIT

DTC Logic

INFOID:000000009723356

[BSW]

А

DTC DETECTION LOGIC В DTC DTC detecting condition Possible causes Trouble diagnosis name · Camera image signal circuit between rear view camera and cam-REAR CAMERA IMAGE U111A Camera image signal circuit is open or shorted. era control unit SIGNAL Camera control unit D Rear view camera DTC CONFIRMATION PROCEDURE **1.**PERFORM DTC CONFIRMATION PROCEDURE Ε 1. Turn the ignition switch ON. 2. Shift the selector lever to "R" position. F 3. Perform "All DTC Reading" with CONSULT. Check if the "U111A" is detected as the current malfunction in "Self Diagnostic Result" of "AVM". 4 Is "U111A" detected as the current malfunction? YES >> Refer to DAS-157, "Diagnosis Procedure". NO >> Refer to GI-44, "Intermittent Incident". Diagnosis Procedure INFOID:000000009723357 Н 1. CHECK CONTINUITY REAR VIEW CAMERA POWER SUPPLY AND GROUND CIRCUIT 1. Turn ignition switch OFF. Disconnect camera control unit connector and rear view camera connector. 2. Check continuity between camera control unit harness connector and rear view camera harness connec-3. tor. Camera control unit Rear view camera Continuity Connector Terminals Connector Terminals Κ 50 8 B93 D168 Existed 52 7 Check continuity between camera control unit harness connector and ground. 4. Camera control unit M Continuity Connector Terminal Ground B93 50 Not existed Is inspection result normal? Ν YES >> GO TO 2. NO >> Repair harness or connector. DAS 2.CHECK VOLTAGE REAR VIEW CAMERA POWER SUPPLY 1. Connect camera control unit connector and rear view camera connector. 2. Turn ignition switch ON. Check voltage between camera control unit harness connector and ground. 3.

U111A REAR CAMERA IMAGE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

	Terminal					
Standard voltage	(+) (-)					
Standard Voltage	Camera control unit					
	Terminal	Connector	Terminal	Connector		
5.0 - 9.0 V	52	B93	50	B93		

Is inspection result normal?

YES >> GO TO 3.

NO >> Replace camera control unit. Refer to <u>DAS-187</u>, "Removal and Installation".

 ${\it 3.}$ CHECK CONTINUITY CAMERA IMAGE SIGNAL CIRCUIT

- 1. Turn ignition switch OFF.
- 2. Disconnect camera control unit connector and rear view camera connector.
- 3. Check continuity between camera control unit harness connector and rear view camera harness connector.

Camera o	control unit	Rear vie	w camera	Continuity
Connector	Terminals	Connector	Terminals	Continuity
B03	53	D168	5	Existed
D95	54	0100	1	LAIStea

4. Check continuity between camera control unit harness connector and ground.

Camera o	control unit		Continuity	
Connector	Terminals	Ground	Continuity	
P02	53		Not existed	
D93	54		NOT EXISTED	

Is inspection result normal?

YES >> GO TO 4.

NO >> Repair harness or connector.

4.CHECK CAMERA IMAGE SIGNAL

1. Connect camera control unit connector and rear view camera connector.

2. Turn ignition switch ON.

3. Check signal between camera control unit harness connector.

	Terr			
(·	+)	Deference value		
	Camera d			
Connector Terminal Connector Terminal				
B93	53	B93	54	(V) 1 0 -1 -1 -1 -1 -1 -1 -1 -1 -1 -1

Is inspection result normal?

YES >> Replace camera control unit. Refer to <u>DAS-187, "Removal and Installation"</u>.

NO >> Replace rear view camera. Refer to DAS-188. "Removal and Installation".

U1232 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

U1232 STEERING ANGLE SENSOR

DTC Logic

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1232	ST ANGLE SEN CALIB	The neutral position registration of the steering angle sensor can not finish.	Steering angle sensorCamera control unit
Diagn	osis Procedure		INFOID:00000009723359

Diagnosis Procedure

1. REGISTER THE NEUTRAL POSITION OF THE STEERING ANGLE SENSOR

1. Tu 2. Pe <u>OF</u>	rn the ignition switch ON. rform registration of the neutral position of the steering angle sensor. Refer to <u>BRC-9, "ADJUSTMENT</u> STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement".	E
3. Ch	eck "Self Diagnostic Result" of "AVM" with CONSULT.	
<u>ls "U12</u>	232" detected as the current malfunction?	
YES NO	>> GO TO 2. >> INSPECTION END	F
2.сн	ECK STEERING ANGLE SENSOR	G
Check	steering angle sensor.	G
Is the i	nspection result normal?	
YES NO	>> Replace the camera control unit. Refer to <u>DAS-187, "Removal and Installation"</u> . >> Repair or replace malfunctioning parts.	Н
		J

DAS

Κ

L

Μ

Ν

[BSW]

INFOID:000000009723358

А

В

С

D

U1305 CONFIG UNFINISH

< DTC/CIRCUIT DIAGNOSIS >

U1305 CONFIG UNFINISH

DTC Logic

INFOID:000000009723360

[BSW]

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1305	CONFIG UNFINISH	The vehicle specifications of camera control unit is incomplete.	Vehicle specifications for camera control unit is incomplete

NOTE:

Current malfunction is displayed only and is not saved.

Diagnosis Procedure

INFOID:000000009723361

$1. {\tt perform\ configuration\ of\ camera\ control\ unit}$

Perform configuration of camera control unit when DTC U1305 is detected.

>> Perform configuration of camera control unit. Refer to <u>DAS-52, "Work Procedure"</u>.

U1308 REAR CAMERA

< DTC/CIRCUIT DIAGNOSIS >

U1308 REAR CAMERA

DTC Logic

А

INFOID:000000009723362

[BSW]

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1308	R-CAMERA (R&L) CAL- IB JDGMNT	Camera image calibration is incomplete	 Calibration for camera image is in- complete Camera communication line is open
NOTE: f DTC _ogic".	U1308 is detected ald	ong with DTC U130B, first diagnose the E	DTC U130B. Refer to <u>DAS-163, "DTC</u>
Diagno	osis Procedure		INFOID:000000009723363
1. per	FORM CALIBRATION	I OF CAMERA IMAGE	
Perform	calibration of camera	image when DTC U1308 is detected.	
	>> Perform calibration	on of camera image. Refer to <u>DAS-53, "Wo</u>	ork Procedure (Preparation)".

DAS

Ν

Ρ

U1309 AIR PUMP

< DTC/CIRCUIT DIAGNOSIS >

U1309 AIR PUMP

DTC Logic

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1309	PUMP INPUT CUR- RENT JUDGE	Camera control unit detects the value of current from air pump is incorrect	Air pump

Diagnosis Procedure

INFOID:000000009723365

INFOID:000000009723364

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Start the engine.

2. Turn the BSW system ON.

3. Perform "All DTC Reading" with CONSULT.

4. Check if the "U1309" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U1309" detected as the current malfunction?

YES >> Replace the air pump. Refer to DAS-187, "Removal and Installation".

NO >> Refer to <u>GI-44</u>, "Intermittent Incident".

U130B REAR CAMERA

< DTC/CIRCUIT DIAGNOSIS >

U130B REAR CAMERA

DTC Logic

А

INFOID:000000009723366

DTC DETECTION LOGIC В DTC Trouble diagnosis name DTC detecting condition Possible causes REAR CAMERA COMM Camera control unit receives the incorrect · Rear view camera U130B ERROR communication signal from rear camera unit · Camera control unit DTC CONFIRMATION PROCEDURE D **1.**PERFORM DTC CONFIRMATION PROCEDURE 1. Turn the ignition switch ON. Е 2. Shift the selector lever to "R" position. 3. Perform "All DTC Reading" with CONSULT. Check if the "U130B" is detected as the current malfunction in "Self Diagnostic Result" of "AVM". 4. Is "U130B" detected as the current malfunction? F >> Refer to DAS-163, "Diagnosis Procedure". YES NO >> Refer to GI-44, "Intermittent Incident". **Diagnosis** Procedure INFOID:000000009723367 **1.**REPLACE REAR VIEW CAMERA Н 1. Turn ignition switch OFF. Replace the rear view camera. Refer to DAS-188. "Removal and Installation". 2. Turn ignition switch ON. 3. 4. Erases All self-diagnosis results. Shift selector lever to "R" position. 5. Perform "All DTC Reading" again. 6. Check if the "U130B" is detected in self-diagnosis results of "AVM". 7. Is inspection result normal? YES >> Refer to INSPECTION END.

NO >> Replace camera control unit. Refer to <u>DAS-187, "Removal and Installation"</u>.

DAS

Κ

L

M

Ν

Ρ

U1310 PUMP CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

U1310 PUMP CONTROL UNIT

DTC Logic

INFOID:000000009723368

[BSW]

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible causes
U1310	PUMP ECU JUDGE	If the pump control unit is malfunction	Pump control unit

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Start the engine.

2. Turn the BSW system ON.

3. Perform "All DTC Reading" with CONSULT.

4. Check if the "U1310" is detected as the current malfunction in "Self Diagnostic Result" of "AVM".

Is "U1310" detected as the current malfunction?

- YES >> Refer to <u>DAS-164</u>, "Diagnosis Procedure".
- NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009723369

1.CHECK VOLTAGE PUMP CONTROL UNIT POWER SUPPLY

Check pump control unit power supply and ground circuit. Refer to <u>DAS-165. "PUMP CONTROL UNIT : Diagnosis Procedure"</u>.

Is inspection result normal?

- YES >> Replace the pump control unit. Refer to <u>DAS-189</u>, "Removal and Installation".
- NO >> Repair the pump control unit power supply and ground circuit.

< DTC/CIR(POWER	R SUPPLY	AND GF	ROUND C	IRCUIT	[BSW]
	SUPPL		ROUND	CIRCUI	Т		
			Diagnosi	e Procodu	Iro		
		JE UNIT .	Diagnosi	S FIUCEUL			INFOID:000000009723370
Chock for bl							
	own iuses.			1			
	Po	ower source				Fuse No.	
	Batter	y power supply				<u> </u>	
Is the inspec	ction result n	ormal?				5	
YES >> NO >> 2.CHECK (Check voltage	GO TO 2. Be sure to e CAMERA CO ge between o	liminate cau DNTROL UN camera cont	se of malfun IIT POWER rol unit harne	ction before SUPPLY CIF ess connecto	installing ne RCUIT or and groun	w fuse. d.	
	Terr	ninal					
(+) (-)			Condition	Standard	Reference voltage		
Connector	Camera o Terminal	control unit	Ignition Voltage (App		(Approx.)		
	2			OFF	9.5 - 16 V	Battery volt- age	
B92		B92	1	OFF	0 - 0.1 V	0 V	
	3			ON	9.5 - 16 V	Battery volt- age	
Is the inspect YES >> NO >> 3. CHECK (<u>ction result n</u> GO TO 3. Repair the c CAMERA CO	ormal? amera contr DNTROL UN	ol unit power	r supply circ	uit.	<u>.</u>	
 Turn the Disconn Check fe 	e ignition swi lect the cam or continuity	tch OFF. era control u between ca	nit connecto mera control	r. I unit harnes	s connector	and ground.	
Cam	era control unit	:		Continuity	-		
Connecto	r Tern	ninal G	Ground	Evisted	-		
Is the inspect YES >> NO >> PUMP CO	tion result n INSPECTIO Repair the c	<u>ormal?</u> N END amera contr UNIT	ol unit groun	d circuit.			
PUMP CO	ONTROL	UNIT : Dia	agnosis P	rocedure			INFOID:000000009723371
1.снески	USE						
Check for bl	own fuses.						
	Po	ower source				Fuse No.	
	Ignitio	n power supply	,			47	

Is the inspection result normal?

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

YES >> GO TO 2.

NO >> Be sure to eliminate cause of malfunction before installing new fuse.

2.CHECK PUMP CONTROL UNIT POWER SUPPLY CIRCUIT

Check voltage between pump control unit harness connector and ground.

Terminal				Condition			
(·	+)	(-)		Condition	Standard	Reference	
Pump control unit				Ignition	voltage	voltage	
Connector	Terminal	Connector	Terminal	switch			
				OFF	0 - 0.1 V	0 V	
D170	12	12 D170	5	ON	9.5 - 16 V	Battery volt- age	

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the pump control unit power supply circuit.

3.CHECK PUMP CONTROL UNIT GROUND CIRCUIT

1. Turn the ignition switch OFF.

2. Disconnect the pump control unit connector.

3. Check for continuity between pump control unit harness connector and ground.

Pump co	ontrol unit		Continuity
Connector	Terminal	Ground	Continuity
D170	5		Existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair the pump control unit ground circuit.

		WARN	ING SY	STEMS SW		Γ
< DTC/CIRC	UIT DIAGN	NOSIS >				[BSW]
NARNIN	G SYST	EMS SV	VITCH	CIRCUIT		
Componer	nt Functio	on Check				INFOID:000000009723372
1 .снеск w	/ARNING S	YSTEMS S	WITCH INI	PUT SIGNAI		
Turn the	ignition swi	tch ON				
2. Select th	e DATA MC	NITOR item	"ITS SW	1" of "AVM" wit	h CONSULT.	
3. With ope	rating the w	varning syste	ems switch	, check the mo	nitor status.	
Monitor item		Condition		Monitor status		
	Warning sys	tems switch is	oressed	On		
ITS SW 1	Warning sys	tems switch is i	not pressed	OFF		
s the inspect	tion result n	ormal?	•			
YES >> V	Varning sys	tems switch	circuit is r	ormal.		
NO >> F	Refer to DAS	<u>S-167, "Diag</u>	nosis Prod	<u>cedure"</u> .		
Diagnosis	Procedu	re				INFOID:00000009723373
	ARNING S	YSTEMS S		JNAL INPUT		
. Turn the	ignition swi	tch ON.				
. Check vo	oltage betwe	een camera	control un	it harness conr	ector and ground.	
	Torminala					
()		()	Condition	1		
(+) potrol unit	(-)	Warning	Standard	Reference	
		_	systems	voltage	vollage	
Connector	Terminal	Ground	switch			
B92	17		Pressed	0 - 0.1 V	0 V	
			Released	9.5 - 16 V	12 V	
<u>s the inspect</u>	tion result n	ormal?				2 11 21 11
YES >>F NO >>(Replace the	camera con	troi unit. R	eter to DAS-18	37, "Removal and I	<u>nstallation"</u> .
	/ARNING S	YSTEMS SI	MITCH			
	tion owitch					
. Remove	warning sv	OFF. stems switch	۱.			
. Check w	arning syste	ems switch.	Refer to <u>D</u>	AS-194, "Remo	oval and Installation	<u>-"</u> .
s the inspect	tion result n	ormal?				
YES >> C	GO TO 3.					
NO >> F D	Replace the	warning sys	stems swite	ch. Refer to <u>DA</u>	<u>S-194, "Removal a</u>	and Installation".
CHECK W	ARNING S	YSTEMS S	WITCH GF		11	
Check contin	uity betwee	n warning sy	/stems sw	itch harness co	onnector and the gr	ound.
			1			
Warning	systems switc	n -		Continuity		
Connector	Termi	nal G	iround			
M39	6			Existed		
s the inspect	tion result n	ormal?				
YES >> (30 TO 4.					

NO >> Repair harness or connector.

4. CHECK WARNING SYSTEMS SWITCH SIGNAL INPUT CIRCUIT FOR OPEN

1. Disconnect the camera control unit connector.

WARNING SYSTEMS SWITCH CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

2. Check continuity between the camera control unit harness connector and warning systems switch harness connector.

Camera o	control unit	Warning sys	Continuity	
Connector	Terminal	Connector	Terminal	Continuity
B92	17	M39	7	Existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair the harnesses or connectors.

${f 5.}$ CHECK WARNING SYSTEMS SWITCH SIGNAL INPUT CIRCUIT FOR SHORT

Check continuity between the camera control unit harness connector and ground.

Camera d	control unit		Continuity
Connector	Terminal	Ground	Continuity
B92	B92 17		Not existed

Is the inspection result normal?

YES >> Replace the camera control unit. Refer to <u>DAS-187</u>, "Removal and Installation".

NO >> Repair the harnesses or connectors.

Component Inspection

INFOID:000000009723374

[BSW]

1.CHECK WARNING SYSTEMS SWITCH

Check continuity of warning systems switch.

Terminal		Condition	Continuity
7	٩	When warning systems switch is pressed	Existed
7 9	When warning systems switch is released	Not existed	

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace warning systems switch.

	V	VARNIN	G SYST	EMS O	N INC	DICATOR CIRCUIT	
< DTC/CIRC	UIT DIAGN	NOSIS >				[BSW]	
WARNIN	G SYST	EMS O	N INDIO	CATOF	R CIR	CUIT	Λ
Componer	nt Functio	on Check	K			INF0/D:00000009723375	
1. CHECK W	ARNING S	YSTEMS (ON INDICA	TOR			В
1. Turn the	ignition swi	tch ON.					
 Select the With open 	e ACTIVE T rating the te	FEST item est item, ch	"ITS SW 1 eck the op	IND" of ". eration.	AVM" v	vith CONSULT.	С
On	: Warning	systems C	N indicat	or illumir	nates		
Off	: Warning	systems C	ON indicate	or is turn	ed OF	F	D
Is the inspect	<u>ion result n</u>	ormal?					
YES >> V NO >> R	Varning sys Refer to DAS	tems switc S-169, "Dia	h indicator	circuit is cedure".	normal		Е
Diagnosis	Procedu	re				INFOID:000000009723376	
4							F
I.CHECK W	ARNING C	N INDICA		ER SUPP	LY CIF	CUIT	
 Turn ignit Disconne Check vo 	tion switch ect warning oltage betwe	OFF. systems sv een warnin	vitch conne g systems	ector. switch ha	irness	connector and ground.	G
	Termir	nals					Н
	(+)		(-)	Volta	ge		
Warning	systems switc	h		(Appro	эх.)		
Connector	Termi	nal	Ground				1
M39	3			Battery v	oltage		
YES >> G NO >> R 2.CHECK W	ion result n GO TO 2. Repair the w ARNING S	<u>ormal?</u> /arning sys /YSTEMS (tems ON ir DN INDICA	ndicator p TOR SIG	ower s	upply circuit. OR OPEN	J
1. Disconne	ect the came	era control	unit harnes	ss conne	ctor.		
2. Check conness con	ontinuity be nector.	tween the	camera co	ontrol unit	harne	ss connector and warning systems switch har-	L
Camera co	ontrol unit	Warning s	ystems switc	h Cont	tiouity		5.4
Connector	Terminal	Connector	Termina	d Con	linuity		IVI
B92	15	M39	2	Exi	sted		
Is the inspect	<u>ion result n</u>	ormal?					Ν
YES >> G NO >> R	50 TO 3. Repair the h	arnesses o	r connecto	ors		_	
3.CHECK W	ARNING S	YSTEMS (TOR SIG	NAL C	IRCUIT FOR SHORT	DAS
Check continu	uity betwee	n the came	era control	unit harne	ess cor	nector and ground.	
	- 					-	D
Camera	a control unit			Contin	uitv		Г
Connector	Termi	nal	Ground				
B92	. 15			Not exi	sted		

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair the harnesses or connectors.

WARNING SYSTEMS ON INDICATOR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BSW]

4. CHECK WARNING SYSTEMS ON INDICATOR

Check the warning systems ON indicator. Refer to DAS-170, "Component Inspection".

Is the inspection result normal?

YES >> Replace the camera control unit. Refer to <u>DAS-187, "Removal and Installation"</u>.

NO >> Replace warning systems switch. <u>DAS-194, "Removal and Installation"</u>.

Component Inspection

INFOID:000000009723377

1. CHECK WARNING SYSTEMS ON INDICATOR

Apply battery voltage to warning systems switch terminals 1 and 2, and then check if the warning systems ON indicator illuminates.

Terminals			Warning sys-	
(+)	(-)	Condition	tems ON indica- tor	
3	2	When the battery voltage is applied	On	
5	2	When the battery voltage is not applied	Off	

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace the warning systems switch. Refer to DAS-194, "Removal and Installation".

Control Diversion (Section 2) Purport (Section 2) REAR VIEW CAMERA WASHER RELAY CIRCUIT Component Function Check 1. CHECK REAR VIEW CAMERA WASHER RELAY CIRCUIT				V CAME	ERA WASH	
Component Function Check Processment Function Check 1. CHECK REAR VIEW CAMERA WASHER RELAY CIRCUIT 1. Turn the ignition switch ON. 2. Select the ACTIVE TEST item "WASH ACTIVE" of "AVM" with CONSULT. 3. With operating the test item, check the operation. Of : Rear view camera washer is activated. Off : Rear view camera washer is not activated. Is the inspection result normal? Vertex camera washer relay circuit is normal. NO >> Refer to DAS-117. Diagnosis Procedure? Diagnosis Procedure Vertex camera washer relay 1 is normal. NO >> Refer to DAS-117. Diagnosis Procedure? 1. CHECK REAR VIEW CAMERA WASHER RELAY 1 POWER SUPPLY CIRCUIT 1. Turn the ignition switch ON. Check voltage between rear view camera washer relay 1 harness connector and ground. Terminals (hproc.) Connector Terminal (*) Voltage [Sthe inspection result normal? YES YES >> GO TO 2. NO >> Repair rear view camera washer relay 1 power supply circuit. 2. Check REAR VIEW CAMERA WASHER RELAY 1 GROUND CIRCUIT 1. Turn ignition switch OFF. Solonnect rear view camera washer relay 1 harness connector and the pump control unit harness connector a	REAR VIE		/ERA W	/ASHEI	R RELAY (
1. CHECK REAR VIEW CAMERA WASHER RELAY CIRCUIT 1. Turn the ignition switch ON. 2. Select the ACTIVE TEST item "WASH ACTIVE" of "AVM" with CONSULT. 3. With operating the test item, check the operation. On : Rear view camera washer is not activated. Off : Rear view camera washer is not activated. Off : Rear view camera washer relay circuit is normal. NO >> Refer to DAS-11. "Diagnosis Procedure". Diagnosis Procedure Area view camera washer relay include the colspan="2">Area view camera washer relay 1 power supply circuit. 2. CHECK REAR VIEW CAMERA WASHER RELAY 1 GROUND CIRCUIT 1. Turn the ignition switch ON. 2. Check voltage between rear view camera washer relay 1 harness connector and ground. Terminal (Aprox.) Connector Terminal Battery voltage Is the inspection result normal? YES >> CO TO 2. NO >> Repair rear view camera washer relay 1 2. CHECK REAR VIEW CAMERA WASHER RELAY 1 GROUND CIRCUIT 1. Turn ignition switch OFF. 2. Disconnect rear view camera washer relay 1. 2. Disconnect rear	Component	Functio	n Check			
1. CHECK REAR VIEW CAMERA WASHER RELAY CIRCUIT 1. Turn the ignition switch ON. 2. Select the ACTIVE TEST item "WASH ACTIVE" of "AVM" with CONSULT. 3. With operating the test item, check the operation. On : Rear view camera washer is activated. Off : Rear view camera washer is not activated. Is the inspection result normal? YES >> Washer rear view camera washer relay circuit is normal. N0 >> Refer to DAS-171. "Diagnosis Procedure". Diagnosis Procedure 2. ChECK REAR VIEW CAMERA WASHER RELAY 1 POWER SUPPLY CIRCUIT 1. Turn the ignition switch ON. 2. Check voltage between rear view camera washer relay 1 harness connector and ground. Terminals						INF-01D-000000009723378
1. Turn the ignition switch ON. 2. Select the ACTIVE TEST item "WASH ACTIVE" of "AVM" with CONSULT. 3. With operating the test item, check the operation. On : Rear view camera washer is not activated. Is the inspection result normal? YES >> Washer rear view camera washer relay circuit is normal. NO >> Refer to DAS-171, "Diagnosis Procedure". Diagnosis Procedure 1. CHECK REAR VIEW CAMERA WASHER RELAY 1 POWER SUPPLY CIRCUIT 1. Turn the ignition switch ON. 2. Check voltage between rear view camera washer relay 1 harness connector and ground. Terminale (+) (-) (Approx.) Connector Terminale (+) (-) Voltage (Approx.) Connector Terminal (+) (-) Voltage (Approx.) Connector Terminal (+) (-) Voltage (Approx.) Connector Terminal Ground Exist 1. Turn ignition switch OFF. 1. Turn ignition switch OFF.	1.CHECK RE	AR VIEW	CAMERA V	VASHER	RELAY CIRCU	
On : Rear view camera washer is activated. Off : Rear view camera washer is not activated. Is the inspection result normal? Yes >> Refer to DAS-171, "Diagnosis Procedure". Diagnosis Procedure	 Turn the ig Select the With operation 	nition swit ACTIVE T ating the te	tch ON. EST item " est item, che	WASH AC eck the op	CTIVE" of "AVM eration.	" with CONSULT.
Off : Rear view camera washer is not activated. Is the inspection result normal? YES >> Refer to DAS-171_Diagnosis Procedure!. Diagnosis Procedure	On :	Rear vie	w camera v	vasher is	activated.	
Is the inspection result normal? YES >> Washer rear view camera washer relay circuit is normal. NO >> Refer to DAS-171, "Diagnosis Procedure". Diagnosis Procedure	Off :	Rear vie	w camera v	vasher is	not activated.	
YES >> Washer rear view camera washer relay circuit is normal. NO >> Refer to DAS-171. "Diagnosis Procedure". Diagnosis Procedure ************************************	Is the inspection	on result n	ormal?			
Diagnosis Procedure 1.CHECK REAR VIEW CAMERA WASHER RELAY 1 POWER SUPPLY CIRCUIT 1. Turn the ignition switch ON. 2. Check voltage between rear view camera washer relay 1 harness connector and ground. Image: Terminals (+) (-) Voltage (Approx.) Connector Terminal Ground Battery voltage Is the inspection result normal? YES >> GO TO 2. NO > Repair rear view camera washer relay 1 power supply circuit. 2.CHECK REAR VIEW CAMERA WASHER RELAY 1 GROUND CIRCUIT 1. Turn ignition switch OFF. 2. Disconnect pump control unit connector. 3. Check continuity between rear view camera washer relay 1. 3. Disconnect pump control unit connector. 4. Check continuity between rear view camera washer relay 1 harness connector and the pump control unit harness connector. Terminal Connector Connector Terminal Easi view camera washer relay 1 Existed 5. Check continuity between rear view camera washer relay 1 harness connector and the ground. Rear view camera washer relay 1 Ground Easisted S. Check continuity between rear view camera washer relay 1	YES >> Wa NO >> Re	asher rear	view came S-171, "Dia	ra washer phosis Pro	relay circuit is cedure".	normal.
1. CHECK REAR VIEW CAMERA WASHER RELAY 1 POWER SUPPLY CIRCUIT 1. Turn the ignition switch ON. 2. Check voltage between rear view camera washer relay 1 harness connector and ground. Image: the image of the image	Diagnosis P	Procedu	re			INFOID:000000009723379
1. CHECK REAR VIEW CAMERA WASHER RELAY 1 POWER SUPPLY CIRCUIT 1. Turn the ignition switch ON. 2. Check voltage between rear view camera washer relay 1 harness connector and ground. Image: the ignition switch OX. Rear view camera washer relay 1 Gonnector Terminal Ground Battery voltage Is the inspection result normal? YES >> GO TO 2. NO >> Repair rear view camera washer relay 1 power supply circuit. 2.CHECK REAR VIEW CAMERA WASHER RELAY 1 GROUND CIRCUIT 1. Turn ignition switch OFF. 2. Disconnect rear view camera washer relay 1. 3. Disconnect pump control unit connector. 4. Check continuity between rear view camera washer relay 1 harness connector and the pump control unit harness connector. Rear view camera washer relay 1 2. Check continuity between rear view camera washer relay 1 harness connector and the ground. Rear view camera washer relay 1 2. Check continuity between rear view camera washer relay 1 harness connector and the ground. Rear view camera washer relay 1 2. Check continuity between rear view camera washer relay 1 harness connector and the ground. Rear view camera washer relay 1 Gonnector Terminal Connector Groun	1					
1. Turn the ignition switch ON. 2. Check voltage between rear view camera washer relay 1 harness connector and ground. Image: terminals (+) (-) Rear view camera washer relay 1 Connector Terminal Ground (Approx.) E39 1 Battery voltage Is the inspection result normal? YES >> GO TO 2. NO >> Repair rear view camera washer relay 1 power supply circuit. 2.CHECK REAR VIEW CAMERA WASHER RELAY 1 GROUND CIRCUIT 1. Turn ignition switch OFF. 2. Disconnect rear view camera washer relay 1. 3. Disconnect rear view camera washer relay 1. Connector Terminal Connector Rear view camera washer Pump control unit Continuity Connector Terminal Connector Rear view camera washer relay 1 Connector Terminal Ground Continuity				VASHER	RELAY 1 POW	
Terminals (+) Voltage (Approx.) Rear view camera washer relay 1 Ground Voltage (Approx.) Connector Terminal E29 Voltage (Approx.) Battery voltage Is the inspection result normal? YES >> GO TO 2. NO >> Repair rear view camera washer relay 1 power supply circuit. 2. CHECK REAR VIEW CAMERA WASHER RELAY 1 GROUND CIRCUIT 1. Turn ignition switch OFF. 2. 2. Disconnect pump control unit connector. 3. Disconnect pump control unit connector. 4. 3. Disconnect pump control unit connector. Continuity Context continuity between rear view camera washer relay 1 harness connector and the pump control unit harness connector. Continuity Connector Terminal Connector Terminal Continuity Connector Terminal Ground Continuity Existed 5. Check continuity between rear view camera washer relay 1 harness connector and the ground. Image: Connector Terminal Ground Continuity Connector Terminal Ground Continuity Not existed Image: Connector.	 Turn the ig Check volt 	nition swit age betwe	tch ON. een rear vie	w camera	washer relay 1	harness connector and ground.
(+) (-) Voltage (Approx.) Rear view camera washer relay 1 Ground (Approx.) E29 1 Battery voltage Is the inspection result normal? YES > GO TO 2. NO >> Repair rear view camera washer relay 1 power supply circuit. 2.CHECK REAR VIEW CAMERA WASHER RELAY 1 GROUND CIRCUIT 1. Turn ignition switch OFF. 2. Disconnect rear view camera washer relay 1. 3. Disconnect pump control unit connector. 4. Check continuity between rear view camera washer relay 1 harness connector and the pump control unit harness connector. Rear view camera washer relay 1 Connector Terminal Connector Terminal E29 2 D170 4 Existed 5. Check continuity between rear view camera washer relay 1 harness connector and the ground. Rear view camera washer relay 1 <u>Connector Terminal Connector Terminal E29 2 D170 4 Existed 5. Check continuity between rear view camera washer relay 1 harness connector and the ground. Rear view camera washer relay 1 Ground Continuity <u>Connector Terminal E29 2 2 2 St the inspection result normal?<</u></u>		Termin	als			-
(Approx.) Connector Terminal Ground (Approx.) E29 1 Battery voltage Is the inspection result normal? YES >> GO TO 2. NO >> Repair rear view camera washer relay 1 power supply circuit. 2.CHECK REAR VIEW CAMERA WASHER RELAY 1 GROUND CIRCUIT 1. Turn ignition switch OFF. 2. Disconnect rear view camera washer relay 1. 3. Disconnect pump control unit connector. 4. Check continuity between rear view camera washer relay 1 harness connector and the pump control unit harness connector. Rear view camera washer Pump control unit Continuity Continuity Connector Terminal E29 2 Di70 4 Existed 5. Check continuity between rear view camera washer relay 1 harness connector and the ground. Rear view camera washer relay 1 Ground Continuity Connector Terminal E29 2 Di70 4 Existed 5. Check continuity between rear view camera washer relay 1 More sized Is the inspection result normal?	((+)		(-)	Voltage	
Connector Terminal Ground E29 1 Battery voltage Is the inspection result normal? YES >> GO TO 2. NO >> Repair rear view camera washer relay 1 power supply circuit. 2.CHECK REAR VIEW CAMERA WASHER RELAY 1 GROUND CIRCUIT 1. Turn ignition switch OFF. 2. Disconnect rear view camera washer relay 1. 3. Disconnect pump control unit connector. 4. Check continuity between rear view camera washer relay 1 harness connector and the pump control unit harness connector. 7. Check continuity between rear view camera washer relay 1 harness connector and the pump control unit harness connector. 7. Check continuity between rear view camera washer relay 1 harness connector and the ground. 7. Check continuity between rear view camera washer relay 1 harness connector and the ground. 7. Connector Terminal 6. Check continuity between rear view camera washer relay 1 harness connector and the ground. 7. Check continuity between rear view camera washer relay 1 harness connector and the ground. 7. Rear view camera washer relay 1 6. Check continuity between rear view camera washer relay 1 harness connector and the ground. 7. Exercise 3 = 2 2 8. the inspection result normal? YES >> GO TO 3. NO <td>Rear view came</td> <td>era washer re</td> <td>elay 1</td> <td></td> <td>(Approx.)</td> <td></td>	Rear view came	era washer re	elay 1		(Approx.)	
Image: Inspection result normal? YES >> GO TO 2. NO >> Repair rear view camera washer relay 1 power supply circuit. 2.CHECK REAR VIEW CAMERA WASHER RELAY 1 GROUND CIRCUIT 1. Turn ignition switch OFF. 2. Disconnect rear view camera washer relay 1. 3. Disconnect pump control unit connector. 4. Check continuity between rear view camera washer relay 1 harness connector and the pump control unit harness connector. 7. Check continuity between rear view camera washer relay 1 harness connector and the pump control unit harness connector. 7. Check continuity between rear view camera washer relay 1 harness connector and the ground. 7. Check continuity between rear view camera washer relay 1 harness connector and the ground. 7. Check continuity between rear view camera washer relay 1 harness connector and the ground. 7. Check continuity between rear view camera washer relay 1 harness connector and the ground. 7. Check continuity between rear view camera washer relay 1 harness connector and the ground. 7. Check continuity between rear view camera washer relay 1 harness connector and the ground. 7. Rear view camera washer relay 1 Ground 7. Connector Terminal 6. Continuity Ker view camera washer relay 1 8. the inspection result normal? Not existed 9. So GO TO 3.	E 29	Termii	nal (Ground	Battery voltage	-
Test and the product of	Is the inspectio	n result n	ormal?		Buttery voltage	-
NO >> Repair rear view camera washer relay 1 power supply circuit. 2.CHECK REAR VIEW CAMERA WASHER RELAY 1 GROUND CIRCUIT 1. Turn ignition switch OFF. 2. Disconnect rear view camera washer relay 1. 3. Disconnect pump control unit connector. 4. Check continuity between rear view camera washer relay 1 harness connector and the pump control unit harness connector. <u>Rear view camera washer relay 1 <u>Pump control unit relay 1 <u>Continuity <u>Connector Terminal Connector Terminal <u>E29 2 D170 4 <u>Existed 5 Check continuity between rear view camera washer relay 1 harness connector and the ground. <u>Rear view camera washer relay 1 <u>Connector Terminal <u>Ground <u>Continuity Not existed <u>Not existed </u> <u>Is the inspection result normal? YES > GO TO 3. NO >> Repair harness or connector. 3.CHECK REAR VIEW CAMERA WASHER RELAY 2 POWER SUPPLY CIRCUIT </u></u></u></u></u></u></u></u></u></u></u></u></u></u></u></u></u></u></u></u></u></u>	YES >> G0) TO 2.	onnan			
2.CHECK REAR VIEW CAMERA WASHER RELAY 1 GROUND CIRCUIT 1. Turn ignition switch OFF. 2. Disconnect rear view camera washer relay 1. 3. Disconnect pump control unit connector. 4. Check continuity between rear view camera washer relay 1 harness connector and the pump control unit harness connector. Rear view camera washer Pump control unit Continuity <u>relay 1 relay 1 <u>Pump control unit Continuity <u>Connector Terminal Connector <u>Terminal Continuity Continuity <u>Connector Terminal <u>Ground Continuity Continuity <u>Connector Terminal <u>Ground Continuity Terminal <u>Ground Continuity Terminal <u>Ground Terminal Ground <u>Continuity Not existed Is the inspection result normal? YES > GO TO 3. NO >> Repair harness or connector. 3.CHECK REAR VIEW CAMERA WASHER RELAY 2 POWER SUPPLY CIRCUIT </u></u></u></u></u></u></u></u></u></u></u>	NO >> Re	epair rear v	view camera	a washer r	elay 1 power s	upply circuit.
1. Turn ignition switch OFF. 2. Disconnect rear view camera washer relay 1. 3. Disconnect pump control unit connector. 4. Check continuity between rear view camera washer relay 1 harness connector and the pump control unit harness connector. Rear view camera washer relay 1 Rear view camera washer relay 1 Connector Terminal Connector Terminal E29 2 Check continuity between rear view camera washer relay 1 harness connector and the ground. Rear view camera washer relay 1 Continuity between rear view camera washer relay 1 harness connector and the ground. Rear view camera washer relay 1 Connector Terminal Ground Ground Continuity Connector Terminal Ground Continuity Connector Terminal Ground Not existed Is the inspection result normal? YES >> GO TO 3. NO >> Repair harness or connector. 3. CHECK REAR VIEW CAMERA WASHER RELAY 2 POWER SUPPLY CIRCUIT	2.CHECK RE	AR VIEW	CAMERA V	VASHER	RELAY 1 GRO	UND CIRCUIT
Rear view camera washer relay 1 Pump control unit Continuity Connector Terminal Connector Terminal E29 2 D170 4 Existed 5. Check continuity between rear view camera washer relay 1 harness connector and the ground. Image: Continuity Rear view camera washer relay 1 Ground Continuity Continuity Image: Connector Terminal Ground Continuity Image: Connector Terminal Continuity Not existed <td> Turn ignitic Disconnec Disconnec Check con harness con </td> <td>on switch (t rear view t pump co atinuity bet onnector.</td> <td>OFF. v camera wa ntrol unit co ween rear v</td> <td>asher rela onnector. view came</td> <td>y 1. era washer rela</td> <td>y 1 harness connector and the pump control unit</td>	 Turn ignitic Disconnec Disconnec Check con harness con 	on switch (t rear view t pump co atinuity bet onnector.	OFF. v camera wa ntrol unit co ween rear v	asher rela onnector. view came	y 1. era washer rela	y 1 harness connector and the pump control unit
Connector Terminal Connector Terminal E29 2 D170 4 Existed 5. Check continuity between rear view camera washer relay 1 harness connector and the ground. Rear view camera washer relay 1 Ground Continuity E29 2 Continuity Continuity Is the inspection result normal? YES >> GO TO 3. NO >> Repair harness or connector. Scheck REAR VIEW CAMERA WASHER RELAY 2 POWER SUPPLY CIRCUIT	Rear view came relay 1	era washer 1	Pump c	ontrol unit	Continuity	-
E29 2 D170 4 Existed 5. Check continuity between rear view camera washer relay 1 harness connector and the ground. Rear view camera washer relay 1 Ground Continuity Connector Terminal Ground Continuity E29 2 Not existed Not existed Is the inspection result normal? YES >> GO TO 3. NO >> Repair harness or connector. 3. CHECK REAR VIEW CAMERA WASHER RELAY 2 POWER SUPPLY CIRCUIT	Connector	Terminal	Connector	Termina		-
Check continuity between real view camera washer relay 1 namess connector and the ground. Rear view camera washer relay 1 Ground Continuity Connector Terminal Ground Continuity E29 2 Not existed Not existed Is the inspection result normal? YES >> GO TO 3. NO >> Repair harness or connector. 3.CHECK REAR VIEW CAMERA WASHER RELAY 2 POWER SUPPLY CIRCUIT	E29	2 tipuitu bat		4	Existed	1 harness connector and the ground
Rear view camera washer relay 1 Connector Terminal Ground Continuity E29 2 Not existed Not existed Is the inspection result normal? YES >> GO TO 3. NO >> Repair harness or connector. 3.CHECK REAR VIEW CAMERA WASHER RELAY 2 POWER SUPPLY CIRCUIT	5. Uneck con	innuity bet	ween rear \	new came	ra washer relay	y i namess connector and the ground.
Connector Terminal Ground Continuity E29 2 Not existed Is the inspection result normal? YES >> GO TO 3. NO >> Repair harness or connector. 3.CHECK REAR VIEW CAMERA WASHER RELAY 2 POWER SUPPLY CIRCUIT	Rear view came	era washer re	elay 1			
E29 2 Not existed Is the inspection result normal?	Connector	Termiı	nal (Ground	Continuity	
Is the inspection result normal? YES >> GO TO 3. NO >> Repair harness or connector. 3.CHECK REAR VIEW CAMERA WASHER RELAY 2 POWER SUPPLY CIRCUIT	E29	2			Not existed	-
YES >> GO TO 3. NO >> Repair harness or connector. 3. CHECK REAR VIEW CAMERA WASHER RELAY 2 POWER SUPPLY CIRCUIT	Is the inspection	on result n	ormal?		1	-
3. CHECK REAR VIEW CAMERA WASHER RELAY 2 POWER SUPPLY CIRCUIT	YES >> GO	O TO 3. epair harne	ess or conn	ector.		
	3.CHECK RE	AR VIEW	CAMERA V	VASHER	RELAY 2 POW	ER SUPPLY CIRCUIT

^{1.} Turn the ignition switch ON.

DAS-171

^{2.} Check voltage between rear view camera washer relay 2 harness connector and ground.

REAR VIEW CAMERA WASHER RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

(·	+)	(-)	Voltage
Rear view came	ra washer relay 2		(Approx.)
Connector Terminal		Ground	
E28	1		Battery voltage

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair rear view camera washer relay 2 power supply circuit.

4.CHECK REAR VIEW CAMERA WASHER RELAY 2 GROUND CIRCUIT

- 1. Turn ignition switch OFF.
- 2. Disconnect rear view camera washer relay 2.
- 3. Check continuity between rear view camera washer relay 2 harness connector and the pump control unit harness connector.

Rear view ca rela	amera washer ay 2	Pump co	Continuity	
Connector	Terminal	Connector	Terminal	
E28	2	D170	3	Existed

4. Check continuity between rear view camera washer relay 2 harness connector and the ground.

Rear view came	ra washer relay 2		Continuity	
Connector	Terminal	Ground	Continuity	
E28	2		Not existed	

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair harness or connector.

5.CHECK REAR VIEW CAMERA WASHER RELAY 1 AND 2

Check rear view camera washer relay 1 and 2. Refer to DAS-172, "Component Inspection".

Is the inspection result normal?

YES >> Replace pump control unit.

NO >> Repair harness or connector.

Component Inspection

1.CHECK REAR VIEW CAMERA WASHER RELAY 1

Apply battery voltage to rear view camera washer relay terminals 1 and 2, and then check for continuity under the following conditions.

Terminal		Condition	Continuity
5	3	When the battery voltage is applied	Existed
5 5	When the battery voltage is not applied	Not existed	
4 3		When the battery voltage is applied	Not existed
		When the battery voltage is not applied	Existed

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace rear view camera washer relay 1.

2.CHECK REAR VIEW CAMERA WASHER RELAY 2

INFOID:000000009723380

REAR VIEW CAMERA WASHER RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Apply battery voltage to rear view camera washer relay terminals 1 and 2, and then check for continuity under the following conditions.

Tern	ninal	Condition	Continuity		
5 3	When the battery voltage is applied	Existed			
	When the battery voltage is not applied	Not existed			
4	4 3	When the battery voltage is applied	Not existed		
4		When the battery voltage is not applied	Existed		
Is the	inspe	ction result normal?			
YES	YES >> INSPECTION END				
NO	>>	 >> Replace rear view camera washer relay 2. 			

DAS

[BSW]

А

В

С

D

Ε

F

G

Н

J

Κ

Μ

Ν

Р

WASHER SWITCHING SOLENOID VALVE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

WASHER SWITCHING SOLENOID VALVE CIRCUIT

Component Function Check

- 1. Turn the ignition switch ON.
- 2. Select the ACTIVE TEST item "WASH ACTIVE" of "AVM" with CONSULT.
- 3. With operating the test item, check the operation.

On : Rear view camera washer is activated.

Off : Rear view camera washer is not activated.

Is the inspection result normal?

- YES >> Washer switching solenoid valve circuit is normal.
- NO >> Refer to <u>DAS-174</u>, "Diagnosis Procedure".

Diagnosis Procedure

INFOID:000000009723382

[BSW]

INFOID:000000009723381

1. CHECK WASHER SWITCHING SOLENOID VALVE POWER SUPPLY CIRCUIT

- 1. Turn the ignition switch ON.
- 2. Check voltage between washer switching solenoid valve harness connector and ground.

(+)	(-)	Voltage
Washer switchir	ng solenoid valve		(Approx.)
Connector Terminal		Ground	
D167	2		Battery voltage

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair washer switching solenoid valve power supply circuit.

2. CHECK WASHER SWITCHING SOLENOID VALVE SIGNAL CIRCUIT

- 1. Turn ignition switch OFF.
- 2. Disconnect washer switching solenoid valve connector and pump control unit connector.
- Check continuity between washer switching solenoid valve harness connector and the pump control unit harness connector.

Washer switching solenoid valve		Pump co	Continuity	
Connector	Terminal	Connector Terminal		
D167	3	D170	9	Existed

4. Check continuity between washer switching solenoid valve harness connector and the ground.

Washer switchir	ng solenoid valve		Continuity
Connector	Terminal	Ground	Continuity
D167	3	Ť	Not existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

$\mathbf{3.}$ CHECK WASHER SWITCHING SOLENOID VALVE GROUND CIRCUIT

1. Disconnect combination switch.

2. Check continuity between washer switching solenoid valve harness connector and the combination switch harness connector.

DAS-174

WASHER SWITCHING SOLENOID VALVE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BSW]

Washer switc va	ching solenoid Ive	Combinati	on switch	Continuity	-
Connector	Terminal	Connector	Terminal	Continuity	
D167	3	M103	3	Existed	-
s the inspec	ction result n	ormal?			-
YES >> NO >>	Replace was Repair harne	sher switchin ess or conne	g solenoid v ctor.	/alve.	

Ρ

REAR WASHER SWITCH INPUT SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

REAR WASHER SWITCH INPUT SIGNAL CIRCUIT

Diagnosis Procedure

INFOID:000000009723383

[BSW]

1.CHECK COMBINATION SWITCH INPUT SIGNAL CIRCUIT

- 1. Turn ignition switch OFF.
- 2. Disconnect pump control unit connector and combination switch connector.
- 3. Check continuity between combination switch harness connector and pump control unit harness connector.

Pump control unit		Combination switch		Continuity
Connector	Terminal	Connector	Terminal	
D170	10	M103	1	Existed

4. Check continuity between pump control unit harness connector and the ground.

Pump co	ontrol unit		Continuity
Connector Terminal		Ground	Continuity
D170	10		Not existed

Is the inspection result normal?

YES >> Replace pump control unit. Refer to <u>DAS-189</u>, "Removal and Installation".

NO >> Repair harness or connector.

		WASHE	R LEVEL	SWITCH	SIGNAL CIRCUIT
< DTC/CIRC		NOSIS >			[BSW]
WASHEF	R LEVEL	SWITC	H SIGN	AL CIRC	JIT
Diagnosis	Procedu	re			INFOID:000000009723384
1		-			
I.CHECK V	WASHER LE	EVEL SWITC	CH INPUT S	SIGNAL CIRC	UIT
 Turn ign Disconn Check c tor. 	ition switch lect combina continuity bel	OFF. ation meter c tween comb	onnector a	nd camera co er harness co	ntrol unit. nnector and camera control unit harness connec-
Combinat	tion meter	Camera	control unit	Oractionsites	-
Connector	Terminal	Connector	Terminal	- Continuity	
M34	29	B93	40	Existed	-
4. Disconn 5. Check c	ect washer	level switch tween came	harness co ra control u	nnector. Init harness c	onnector and the ground.
Connector	Termi	nal (Fround	Continuity	
B93	40			Not existed	-
Is the inspec	tion result n	ormal?			-
YES >> NO >>	GO TO 2. Repair harn	ess or conne	ector.		
Z. CHECK V	WASHER LE	EVEL SWITC	CH SIGNAL	. CIRCUIT	
Check wash	er level swit	ch signal cir	cuit. Refer t	to <u>MWI-49, "C</u>	liagnosis Procedure".
Is the inspec	co result n	ormal?			
NO >>	Repair harn	ess or conne	ector.		
3. снеск v	WASHER LE	EVEL SWITC	ж		
Perform a ur	nit check for	the washer	level switch	. Refer to M	VI-50. "Component Inspection".
Is the inspec	tion result n	ormal?			
YES >>	Replace car	nera control	unit. Refer	to <u>DAS-187,</u>	"Removal and Installation".
NU >>	Replace was	sner tank. R	eier to <u>VVVV</u>	-128, "Remov	<u>ai and installation"</u> .

Ν

DAS

Ρ

BLIND SPOT WARNING INDICATOR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

BLIND SPOT WARNING INDICATOR CIRCUIT

Diagnosis Procedure

INFOID:000000009723385

[BSW]

1. CHECK BSW INDICATOR CIRCUIT FOR OPEN 1

- 1. Turn ignition switch OFF.
- 2. Disconnect camera control unit harness connector and BSW indicator harness connector.
- 3. Check continuity between camera control unit harness connector and BSW indicator harness connector.

Camera control unit		BSW ir	ndicator	Continuity	
Connector	Terminal	Connector Terminal			
P02	7 (LH)	D18 (LH)	1	Evictod	
D92	8 (RH)	D54 (RH)	I	Existed	

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the harnesses or connectors.

2. CHECK BSW INDICATOR CIRCUIT FOR OPEN 2

Check continuity between BSW indicator harness connector and ground.

BSW ir	ndicator		Continuity
Connector	Terminal	Ground	
D18 (LH)	2		Existed
D54 (RH)	2		Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the harnesses or connectors.

 $\mathbf{3}.$ check bsw indicator circuit for short

- 1. Turn ignition switch OFF.
- 2. Disconnect camera control unit harness connector and BSW indicator harness connector.
- 3. Check continuity between camera control unit harness connector and ground.

Camera o	control unit		Continuity
Connector	Terminal	Ground	Continuity
P02	7	Ground	Not existed
D92	8		NOI EXISIED

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair the harnesses or connectors.

4.CHECK CAMERA CONTROL UNIT VOLTAGE OUTPUT

1. Connect camera control unit harness connector.

2. Check voltage between BSW indicator harness connector and ground.

BLIND SPOT WARNING INDICATOR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BSW]

	Terminal					A
(+)		(-)	Condition	Voltage (Approx.)		
BSW indicator						В
	Ierminal	Ground	Ignition switch OFF \Rightarrow ON (Approx. 2 sec.)	6 V	_	
	1					C
D54 (RH)					-	0
Is the inspectio YES >> Re NO >> Re	<u>n result normal</u> place BSW indi place camera c	<u>?</u> cator. ontrol unit. Refe	er to <u>DAS-187, '</u>	"Removal and I	nstallation".	D
						E
						F
						G
						0
						Н
						I
						J
						К
						L
						Μ
						Ν
						DAS
						Ρ

INFOID:000000009723386

SYMPTOM DIAGNOSIS BSW SYSTEM SYMPTOMS

Symptom Table

CAUTION:

Perform the self-diagnosis with CONSULT before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

NOTE:

The operational conditions of BSW, refer to DAS-109, "System Description".

Sympt	om	Possible cause	Inspection item/Reference page
	BSW warning lamp (Yellow) does not illuminate	Combination meterCamera control unit	BSW warning lamp does not turned ON. Refer to <u>DAS-182,</u> <u>"Diagnosis Procedure"</u>
	BSW ON indicator lamp (Green) does not illuminate	Combination meterCamera control unit	BSW ON indicator lamp does not turned ON. Refer to <u>DAS-183.</u> <u>"Diagnosis Procedure"</u>
	Warning systems ON indica- tor (on the warning systems switch) does not illuminate	 Harness between camera control unit and warning sys- tems switch Warning systems switch Camera control unit 	Warning systems ON indicator circuit. Refer to <u>DAS-169. "Diag-</u> nosis Procedure"
Indicator/warning lamps do not il- luminate when ignition switch OFF \Rightarrow ON.	BSW ON indicator lamp (Green) or BSW warning lamp (Yellow) do not illumi- nate	Combination meterCamera control unit	 BSW warning lamp does not turned ON. Refer to <u>DAS-182</u>, <u>"Diagnosis Procedure"</u> BSW ON indicator lamp. Refer to <u>DAS-183</u>, "<u>Diagnosis Proce- dure"</u>
	 All of indicator/warning lamps do not illuminate; BSW warning lamp BSW ON indicator lamp Warning systems ON indicator 	 Power supply and ground circuit of camera control unit Camera control unit Combination meter 	Power supply and ground circuit of camera control unit. Refer to <u>DAS-165, "CAMERA CONTROL</u> <u>UNIT : Diagnosis Procedure"</u>
	BSW indicator does not turn ON	 Harness between camera control unit and BSW indica- tor Camera control unit BSW indicator 	BSW indicator circuit. Refer to DAS-178, "Diagnosis Procedure"
BSW system is not activated. (Indicator/warning lamps illuminate when ignition switch OFF \Rightarrow ON.)	Warning systems ON indica- tor is not turned ON ⇔ OFF when operating warning sys- tems switch	 Harness between camera control unit and waning sys- tems switch Harness between warning systems switch and ground Camera control unit Warning systems switch 	 Warning systems switch circuit. Refer to <u>DAS-167, "Diagnosis</u> <u>Procedure"</u>. BSW system setting cannot be turned ON/OFF on the naviga- tion screen. Refer to <u>DAS-184, "Diagnosis</u> <u>Procedure"</u>
	Buzzer is not sounding	Combination meterCamera control unit	Meter buzzer circuit. Refer to WCS-24, "Component Function Check"
BSW functions are not are not tim (Example)Does not function when approar BSW ON indicator lamp is illum	ely ching a adjacent vehicle while inated	 Rear view camera calibration Rear view camera Camera control unit 	Rear view camera calibration DAS-53, "Description"
BSW SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[BSW]

Symptom	Possible cause	Inspection item/Reference page	٨
Rear view camera washer is not activated (Rear window washer is functioning normally)	 Rear view camera washer relay circuit Washer switching solenoid valve circuit Pump control unit Camera control unit 	 Rear view camera washer relay circuit Refer to <u>DAS-171, "Compo-</u><u>nent Function Check"</u> Washer switching solenoid valve circuit Refer to <u>DAS-174, "Compo-</u><u>nent Function Check"</u> 	B
Rear view camera wash is insufficient	 Washer tube (include check valve) Air tube Washer/Air nozzle (Rear view camera) 	Rear view camera washer/air blower function Refer to <u>DAS-48, "Inspection</u> <u>Procedure"</u>	D

Е

F

G

Н

J

Κ

L

Μ

Ν

BSW WARNING LAMP DOES NOT TURNED ON

< SYMPTOM DIAGNOSIS >

BSW WARNING LAMP DOES NOT TURNED ON

Description

The BSW warning lamp in the combination meter does not turn ON when turning on the ignition switch

Diagnosis Procedure

INFOID:000000009723388

INFOID:000000009723387

[BSW]

1.CHECK COMBINATION METER

Turn the ignition switch from OFF to ON to check that "BSW W/L" included in "DATA MONITOR" in "METER/ M&A" operates normally.

Is the inspection result normal?

YES >> Replace the combination meter. Refer to <u>MWI-105, "Removal and Installation"</u>.

NO >> GO TO 2.

2. CHECK SELF-DIAGNOSIS RESULTS OF COMBINATION METER

- 1. Perform "All DTC Reading" with CONSULT.
- 2. Check if the DTC is detected in self-diagnosis results of "METER/M&A". Refer to MWI-77, "DTC Index".

Is any DTC detected?

YES >> Repair or replace malfunctioning parts.

NO >> GO TO 3.

3.CHECK SELF-DIAGNOSIS RESULTS OF CAMERA CONTROL UNIT

Check if the DTC is detected in self-diagnosis results of "AVM" Refer to DAS-128. "DTC Index".

Is any DTC detected?

- YES >> Repair or replace malfunctioning parts.
- NO >> Replace the camera control unit. Refer to <u>DAS-187, "Removal and Installation"</u>.

BSW ON INDICATOR DOES NOT TURNED ON	
< SYMPTOM DIAGNOSIS > [BSW]	
BSW ON INDICATOR DOES NOT TURNED ON	٨
Description	A
The BSW ON indicator lamp in the combination meter does not turn ON when turning on the ignition switch	В
Diagnosis Procedure	
1.CHECK COMBINATION METER	С
Turn the ignition switch from OFF to ON to check that "BSW IND" included in "DATA MONITOR" in "METER/ M&A" operates normally.	
Is the inspection result normal?	D
YES >> Replace the combination meter. Refer to <u>MWI-105, "Removal and Installation"</u> . NO >> GO TO 2.	_
2. CHECK SELF-DIAGNOSIS RESULTS OF COMBINATION METER	E
 Perform "All DTC Reading" with CONSULT. Check if the DTC is detected in self-diagnosis results of "METER/M&A" Refer to <u>MWI-77, "DTC Index"</u>. 	F
Is any DTC detected?	
YES >> Repair or replace malfunctioning parts. NO >> GO TO 3.	G
3. CHECK SELF-DIAGNOSIS RESULTS OF CAMERA CONTROL UNIT	
Check if the DTC is detected in self-diagnosis results of "AVM" Refer to DAS-128, "DTC Index".	Н
Is any DTC detected?	
 YES >> Repair or replace malfunctioning parts. NO >> Replace the camera control unit. Refer to <u>DAS-187. "Removal and Installation"</u>. 	Ι

J

Κ

L

Μ

Ν

SYSTEM SETTINGS CANNOT BE TURNED ON/OFF ON THE NAVIGATION SCREEN

< SYMPTOM DIAGNOSIS >

SYSTEM SETTINGS CANNOT BE TURNED ON/OFF ON THE NAVIGATION SCREEN

Description

INFOID:000000009723391

[BSW]

• BSW system setting is not selectable on the navigation screen. **NOTE:**

When the ignition switch is in ACC position, Blind Spot Warning system settings cannot be changed.

- "Blind Spot Warning" is not indicated on the navigation screen.
- The switching between ON and OFF cannot be performed by operating the navigation system.
- The item "Blind Spot Warning" on the navigation screen is not active.
- The Blind Spot Warning or system setting differs from the one set at the previous driving. **NOTE:**

Turn OFF the ignition switch and wait for 5 seconds or more.

Diagnosis Procedure

INFOID:000000009723392

1.CHECK BSW SYSTEM SETTING

1. Start the engine.

2. Check that the Blind Spot Warning system settings is selectable on the navigation screen.

Is the inspection result normal?

YES >> GO TO 3. NO >> GO TO 2.

2. PERFORM THE SELF-DIAGNOSIS

1. Perform self-diagnosis with CONSULT.

- 2. Check if the DTC is detected in self-diagnosis results of "AVM" and "MULTI AV". Refer to the following.
- AVM: <u>DAS-128</u>, "DTC Index"
- MULTI AV: <u>AV-340, "DTC Index"</u>

Is any DTC detected?

- YES >> Repair or replace malfunctioning parts.
- NO >> INSPECTION END

3.CHECK MULTIFUNCTION SWITCH

Operate the multifunction switch to check that the audio, navigation system, and air conditioner operate properly.

Is the inspection result normal?

- YES >> Replace the camera control unit. Refer to DAS-187, "Removal and Installation".
- NO >> Repair or replace malfunctioning parts.

NORMAL OPERATING CONDITION

NORMAL OPERATING CONDITION

Description

Description INFOID:000000009723393	
PRECAUTIONS FOR BLIND SPOT WARNING (BSW)	В
 The BSW system is not a replacement for proper driving procedure and is not designed to prevent contact with vehicles or objects. When changing lanes, always use the side and rear mirrors and turn and look in the direction you will move to ensure it is safe to change lanes. Never rely solely on the BSW system. The rear view camera may not detect properly under the following conditions: When towing a trailer 	С
 When strong light enters the rear view camera. (For example, direct sunlight or headlight from the rear) When ambient brightness changes instantly. (For example, when the vehicle enters or exits a tunnel or passes under a bridge.) 	D
 Automatic washer and blower may not be able to secure detection capability when excessive dirt adheres on the camera lens. The camera unit may not be able to detect when certain objects are present such as: Pedestrians, bicycles, animals 	E
 Several types of vehicles such as motorcycles Oncoming vehicles A vehicle approaching rapidly from behind. A vehicle which your vehicle overtakes rapidly 	F
 The rear view camera may not be able to detect property when your vehicle travels beside the middle section of a vehicle with long wheelbase(e.g. trailer truck, semi-trailer, tractor). 	G
• The rear view camera detection zone is designed based on a standard lane width. When driving in a wider lane, the camera unit may not detect vehicles in an adjacent lane. When driving in a narrow lane, the camera unit may detect vehicles driving two lanes away.	Н
 The rear view camera is designed to ignore most stationary objects, however objects such as guardrails, walls, foliage and parked vehicles may occasionally be detected. This is a normal operating condition. The rear view camera may detect reflection image of vehicles or roadside objects that are not actually in the detection zone, especially when the road is wet. 	I

Κ

[BSW]

А

L

Μ

Ν

DAS

REMOVAL AND INSTALLATION BSW INDICATOR

Removal and Installation

REMOVAL AND INSTALLATION

Removal

- 1. Remove the door mirror corner cover. Refer to <u>MIR-72, "DOOR MIRROR ASSEMBLY : Removal and</u> <u>Installation"</u>.
- 2. Remove the BSW indicator mounting screw.
- 3. Remove the BSW indicator from door mirror corner cover.

Installation

Install in the reverse order of removal.

INFOID:000000009723394

< REMOVAL AND INSTALLATION >

CAMERA CONTROL UNIT

Exploded View

① Camera control unit



Removal and Installation

REMOVAL

CAUTION:

Before replacing camera control unit, perform "Read/Write Configuration" to save or print current vehicle specification. For details, refer to <u>DAS-52, "Description"</u>.

- 1. Remove luggage side finisher lower (RH). Refer to INT-35, "Removal and Installation".
- 2. Disengage air tube clip from camera control unit bracket.
- Remove camera control unit screws, disconnect camera control unit connector and remove the camera control unit.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

Must be perform additional service when replacing camera control unit. Refer to <u>DAS-146, "Work Pro-</u> cedure".

K

J

L

Μ

Ν

DAS

Ρ

INFOID:000000009723395

А

F

REAR VIEW CAMERA

< REMOVAL AND INSTALLATION >

REAR VIEW CAMERA

Exploded View

INFOID:000000009723397

[BSW]



(1) Rear view camera

(2) Finisher

Removal and Installation

INFOID:000000009723398

REMOVAL

- 1. Remove back door finisher inner. Refer to <u>INT-38, "Removal and Installation"</u>.
- 2. Remove finisher.
- 3. Disconnect air tube and washer tube from rear view camera.
- Remove rear view camera mounting screws, disconnect rear view camera connector and remove rear view camera from back door assembly.
 CAUTION:

To prevent a malfunction resulting from a short circuit, never allow washer fluid to drip from tube to rear view camera and connector.

INSTALLATION

Install in the reverse order of removal.

PUMP CONTROL UNIT

< REMOVAL AND INSTALLATION >

PUMP CONTROL UNIT

Exploded View

1. 2.

3.

INFOID:000000009723399

[BSW]

А



Ν

< REMOVAL AND INSTALLATION > AIR PUMP

Exploded View

INFOID:000000009723401

[BSW]



Removal and Installation

INFOID:000000009723402

REMOVAL

- 1. Remove luggage floor spacer LH. Refer to INT-35, "Removal and Installation".
- 2. Disconnect air tube and air pump harness connector.
- 3. Remove air pump cover bolts and nut and remove air pump cover.
- 4. Remove air pump from luggage floor spacer LH.

INSTALLATION

Note the following items, and then install in the reverse order of removal.

CAUTION:

Remove double-sided tape remaining on luggage floor spacer LH with a double-sided tape remover, after removing air pump.

WASHER SWITCHING SOLENOID VALVE

< REMOVAL AND INSTALLATION >

WASHER SWITCHING SOLENOID VALVE

Exploded View

INFOID:000000009723403

[BSW]

А

В SEC. 280 8 С নি D 0 $(\circ$ Е B \sim 0 0 F 0 66 4 ÍO, JSOIA0663ZZ (1) Washer switching solenoid valve Н **Removal and Installation** INFOID:000000009723404 REMOVAL Remove back door finisher inner. Refer to INT-38, "Removal and Installation". 1. Remove the nuts. 2. J 3. Remove washer switching solenoid valve. **INSTALLATION** Install in the reverse order of removal. Κ

DAS

L

Μ

Ν

REAR VIEW CAMERA WASHER/AIR NOZZLE & TUBE

< REMOVAL AND INSTALLATION >

REAR VIEW CAMERA WASHER/AIR NOZZLE & TUBE

Exploded View

INFOID:000000009723405

REAR VIEW CAMERA WASHER / AIR NOZZLE & TUBE



(A) Details

NOTE:

For washer pump and rear washer path, refer to <u>WW-145, "Hydraulic Layout"</u>. HYDRAULIC LAYOUT

REAR VIEW CAMERA WASHER/AIR NOZZLE & TUBE

< REMOVAL AND INSTALLATION >

[BSW]



DAS

J

Κ

Μ

Ν

< REMOVAL AND INSTALLATION >

WARNING SYSTEMS SWITCH

Removal and Installation

REMOVAL

- 1. Remove the instrument lower panel LH. Refer to IP-15. "Removal and Installation".
- 2. Remove warning systems switch from instrument lower panel LH.

INSTALLATION

Install in the reverse order of removal.

[BSW]

INFOID:000000009723406