

A
B

SECTION HAC

HEATER & AIR CONDITIONING CONTROL SYSTEM C

CONTENTS D

WITHOUT 7 INCH DISPLAY		
BASIC INSPECTION	5	
DIAGNOSIS AND REPAIR WORKFLOW	5	
Work Flow	5	
INSPECTION AND ADJUSTMENT	8	
Description & Inspection	8	
Temperature Setting Trimmer	10	
Foot Position Setting Trimmer	10	
Inlet Port Memory Function (FRE)	11	
Inlet Port Memory Function (REC)	11	
SYSTEM DESCRIPTION	12	
COMPRESSOR CONTROL FUNCTION	12	
Description	12	
Component Part Location	13	
Component's Role	15	
AUTOMATIC AIR CONDITIONER SYSTEM	16	
System Diagram	16	
System Description	16	
Component Part Location	24	
Component Description	27	
MODE DOOR CONTROL SYSTEM	28	
System Diagram	28	
System Description	28	
UPPER VENTILATOR DOOR CONTROL SYSTEM	30	
System Diagram	30	
System Description	30	
AIR MIX DOOR CONTROL SYSTEM	32	
System Diagram	32	
System Description	32	
INTAKE DOOR CONTROL SYSTEM	34	
System Diagram	34	
System Description	34	
System Description	34	
BLOWER MOTOR CONTROL SYSTEM	36	
System Diagram	36	
System Description	36	
MAGNET CLUTCH CONTROL SYSTEM	38	
System Diagram	38	
System Description	38	
CAN COMMUNICATION SYSTEM	39	
System Description	39	
DIAGNOSIS SYSTEM (HVAC)	40	
CONSULT Function	40	
DTC/CIRCUIT DIAGNOSIS	44	
U1000 CAN COMM CIRCUIT	44	
Description	44	
DTC Logic	44	
Diagnosis Procedure	44	
U1010 CONTROL UNIT (CAN)	45	
Description	45	
DTC Logic	45	
Diagnosis Procedure	45	
B257B, B257C AMBIENT SENSOR	46	
Description	46	
DTC Logic	46	
Diagnosis Procedure	47	
Component Inspection	48	
B2578, B2579 IN-VEHICLE SENSOR	49	
Description	49	
DTC Logic	49	
Diagnosis Procedure	50	
Component Inspection	51	
B2581, B2582 INTAKE SENSOR	52	
Description	52	
DTC Logic	52	

HAC

Diagnosis Procedure	52	A/C CONTROL : Diagnosis Procedure	78
Component Inspection	53	A/C DISPLAY	79
B2630, B2631 SUNLOAD SENSOR	55	A/C DISPLAY : Diagnosis Procedure	79
Description	55	ECU DIAGNOSIS INFORMATION	80
DTC Logic	55	ECM	80
Diagnosis Procedure	56	Reference Value	80
Component Inspection	57	A/C AUTO AMP.	95
B2632, B2633 AIR MIX DOOR MOTOR		Reference Value	95
(DRIVER SIDE)	58	Wiring Diagram - AIR CONDITIONER CONTROL	
Description	58	SYSTEM -	97
DTC Logic	58	Fail-Safe	105
Diagnosis Procedure	59	DTC Inspection Priority Chart	106
B2634, B2635 AIR MIX DOOR MOTOR (PAS-		DTC Index	106
SENGER SIDE)	60	SYMPTOM DIAGNOSIS	108
Description	60	AIR CONDITIONER CONTROL	108
DTC Logic	60	Diagnosis Chart By Symptom	108
Diagnosis Procedure	61	INSUFFICIENT COOLING	109
B2636, B2637, B2638, B2639, B2654, B2655		Description	109
MODE DOOR MOTOR	62	Inspection procedure	109
Description	62	INSUFFICIENT HEATING	112
DTC Logic	62	Description	112
Diagnosis Procedure	63	Inspection procedure	112
B263D, B263E, B263F INTAKE DOOR MO-		NOISE	115
TOR	65	Description	115
Description	65	Inspection procedure	115
DTC Logic	65	MEMORY FUNCTION DOES NOT OPERATE.	117
Diagnosis Procedure	66	Description	117
B2661, B2662, B2663 UPPER VENTILATOR		Inspection procedure	117
DOOR MOTOR	67	PRECAUTION	118
Description	67	PRECAUTIONS	118
DTC Logic	67	FOR USA AND CANADA	118
Diagnosis Procedure	68	FOR USA AND CANADA : Precaution for Supple-	
BLOWER MOTOR	70	mental Restraint System (SRS) "AIR BAG" and	
Description	70	"SEAT BELT PRE-TENSIONER"	118
Component Function Check	70	FOR USA AND CANADA : Precautions for Re-	
Diagnosis Procedure	70	moving of Battery Terminal	118
Component Inspection	73	FOR USA AND CANADA : Working with HFC-	
MAGNET CLUTCH	74	134a (R-134a)	118
Description	74	FOR USA AND CANADA : General Refrigerant	
Component Function Check	74	Precaution	119
Diagnosis Procedure	74	FOR USA AND CANADA : Refrigerant Connec-	
A/C CONTROL SIGNAL CIRCUIT	76	tion	119
Diagnosis Procedure	76	FOR USA AND CANADA : Service Equipment ...	121
POWER SUPPLY AND GROUND CIRCUIT	77	FOR MEXICO	123
A/C AUTO AMP.	77	FOR MEXICO : Precaution for Supplemental Re-	
A/C AUTO AMP. : Description	77	straint System (SRS) "AIR BAG" and "SEAT BELT	
A/C AUTO AMP. : Component Function Check	77	PRE-TENSIONER"	123
A/C AUTO AMP. : Diagnosis Procedure	77		
A/C CONTROL	78		

FOR MEXICO : Precautions for Removing of Battery Terminal	124	System Diagram	164	
FOR MEXICO : Working with HFC-134a (R-134a)	124	System Description	164	A
FOR MEXICO : General Refrigerant Precaution ..	124	CAN COMMUNICATION SYSTEM	165	
FOR MEXICO : Refrigerant Connection	125	System Description	165	B
FOR MEXICO : Service Equipment	127	DIAGNOSIS SYSTEM (HVAC)	166	
COMPRESSOR	129	CONSULT Function	166	C
General Precautions	129	DTC/CIRCUIT DIAGNOSIS	170	
FLUORESCENT LEAK DETECTOR	130	U1000 CAN COMM CIRCUIT	170	D
General Precautions	130	Description	170	
WITH 7 INCH DISPLAY		DTC Logic	170	E
BASIC INSPECTION	131	Diagnosis Procedure	170	
DIAGNOSIS AND REPAIR WORKFLOW	131	U1010 CONTROL UNIT (CAN)	171	F
Work Flow	131	Description	171	
INSPECTION AND ADJUSTMENT	134	DTC Logic	171	G
Description & Inspection	134	Diagnosis Procedure	171	
Temperature Setting Trimmer	136	B257B, B257C AMBIENT SENSOR	172	H
Foot Position Setting Trimmer	136	Description	172	
Inlet Port Memory Function (FRE)	137	DTC Logic	172	
Inlet Port Memory Function (REC)	137	Diagnosis Procedure	173	
SYSTEM DESCRIPTION	138	Component Inspection	174	
COMPRESSOR CONTROL FUNCTION	138	B2578, B2579 IN-VEHICLE SENSOR	175	
Description	138	Description	175	
Fail-Safe	139	DTC Logic	175	
Component Part Location	139	Diagnosis Procedure	176	
Component's Role	142	Component Inspection	177	HAC
AUTOMATIC AIR CONDITIONER SYSTEM ..	143	B2581, B2582 INTAKE SENSOR	178	J
System Diagram	143	Description	178	
System Description	143	DTC Logic	178	
Component Part Location	150	Diagnosis Procedure	178	K
Component Description	153	Component Inspection	179	
MODE DOOR CONTROL SYSTEM	154	B2630, B2631 SUNLOAD SENSOR	181	L
System Diagram	154	Description	181	
System Description	154	DTC Logic	181	
UPPER VENTILATOR DOOR CONTROL SYSTEM	156	Diagnosis Procedure	182	
System Diagram	156	Component Inspection	183	M
System Description	156	B2632, B2633 AIR MIX DOOR MOTOR (DRIVER SIDE)	184	N
AIR MIX DOOR CONTROL SYSTEM	158	Description	184	
System Diagram	158	DTC Logic	184	
System Description	158	Diagnosis Procedure	185	O
INTAKE DOOR CONTROL SYSTEM	160	B2634, B2635 AIR MIX DOOR MOTOR (PASSENGER SIDE)	186	P
System Diagram	160	Description	186	
System Description	160	DTC Logic	186	
BLOWER MOTOR CONTROL SYSTEM	162	Diagnosis Procedure	187	
System Diagram	162	B2636, B2637, B2638, B2639, B2654, B2655 MODE DOOR MOTOR	188	
System Description	162	Description	188	
MAGNET CLUTCH CONTROL SYSTEM	164	DTC Logic	188	

Diagnosis Procedure	189	INSUFFICIENT COOLING	233
B263D, B263E, B263F INTAKE DOOR MOTOR	191	Description	233
Description	191	Inspection procedure	233
DTC Logic	191	INSUFFICIENT HEATING	236
Diagnosis Procedure	192	Description	236
B2661, B2662, B2663 UPPER VENTILATOR DOOR MOTOR	193	Inspection procedure	236
Description	193	NOISE	239
DTC Logic	193	Description	239
Diagnosis Procedure	194	Inspection procedure	239
BLOWER MOTOR	196	MEMORY FUNCTION DOES NOT OPERATE.	241
Description	196	Description	241
Component Function Check	196	Inspection procedure	241
Diagnosis Procedure	196	PRECAUTION	242
Component Inspection	199	PRECAUTIONS	242
MAGNET CLUTCH	200	FOR USA AND CANADA	242
Description	200	FOR USA AND CANADA : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	242
Component Function Check	200	FOR USA AND CANADA : Precautions for Removing of Battery Terminal	242
Diagnosis Procedure	200	FOR USA AND CANADA : Working with HFC-134a (R-134a)	242
POWER SUPPLY AND GROUND CIRCUIT ..	202	FOR USA AND CANADA : General Refrigerant Precaution	243
A/C AUTO AMP.	202	FOR USA AND CANADA : Refrigerant Connection	243
A/C AUTO AMP. : Description	202	FOR USA AND CANADA : Service Equipment ...	245
A/C AUTO AMP. : Component Function Check ...	202	FOR MEXICO	247
A/C AUTO AMP. : Diagnosis Procedure	202	FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	247
ECU DIAGNOSIS INFORMATION	204	FOR MEXICO : Precautions for Removing of Battery Terminal	248
ECM	204	FOR MEXICO : Working with HFC-134a (R-134a).	248
Reference Value	204	FOR MEXICO : General Refrigerant Precaution .	248
A/C AUTO AMP.	219	FOR MEXICO : Refrigerant Connection	249
Reference Value	219	FOR MEXICO : Service Equipment	251
Wiring Diagram - AIR CONDITIONER CONTROL SYSTEM -	221	COMPRESSOR	253
Fail-Safe	229	General Precautions	253
DTC Inspection Priority Chart	230	FLUORESCENT LEAK DETECTOR	254
DTC Index	230	General Precautions	254
SYMPTOM DIAGNOSIS	232		
AIR CONDITIONER CONTROL	232		
Diagnosis Chart By Symptom	232		

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[WITHOUT 7 INCH DISPLAY]


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000009722024

OVERALL SEQUENCE



DETAILED FLOW

JMKIA8652GB

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[WITHOUT 7 INCH DISPLAY]

1.GET INFORMATION FOR SYMPTOM

1. Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurs).
2. Check operation condition of the function that is malfunctioning.

>> GO TO 2.

2.CHECK DTC

1. Check DTC.
2. Perform the following procedure if DTC is detected.
 - Record DTC and freeze frame data (Print them out using CONSULT.)
 - Erase DTC.
 - Study the relationship between the cause detected by DTC and the symptom described by the customer.
3. Check related service bulletins for information.

Are any symptoms described and any DTC detected?

Symptom is described, DTC is detected>>GO TO 3.

Symptom is described, DTC is not detected>>GO TO 4.

Symptom is not described, DTC is detected>>GO TO 5.

3.CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Also study the normal operation and fail-safe related to the symptom.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5.

4.CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6.

5.PERFORM DTC CONFIRMATION PROCEDURE

Perform DTC CONFIRMATION PROCEDURE for the detected DTC, and then check that DTC is detected again. At this time, always connect CONSULT to the vehicle, and check self diagnostic results in real time. If two or more DTCs are detected, refer to DTC INSPECTION PRIORITY CHART, and determine trouble diagnosis order.

NOTE:

- Freeze frame data is useful if the DTC is not detected.
- Perform Component Function Check if DTC CONFIRMATION PROCEDURE is not included on Service Manual. This simplified check procedure is an effective alternative though DTC cannot be detected during this check.
If the result of Component Function Check is NG, it is the same as the detection of DTC by DTC CONFIRMATION PROCEDURE.

Is DTC detected?

YES >> GO TO 7.

NO >> Check according to [GI-44. "Intermittent Incident"](#).

6.DETECT MALFUNCTIONING SYSTEM BY SYMPTOM DIAGNOSIS

Detect malfunctioning system according to SYMPTOM DIAGNOSIS based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

Is the symptom described?

YES >> GO TO 7.

NO >> Monitor input data from related sensors or check voltage of related module terminals using CONSULT.

7.DETECT MALFUNCTIONING PART BY DIAGNOSIS PROCEDURE

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[WITHOUT 7 INCH DISPLAY]

Inspect according to Diagnosis Procedure of the system.

Is malfunctioning part detected?

YES >> GO TO 8.

NO >> Check according to [GI-44. "Intermittent Incident"](#).

8. REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnosis Procedure again after repair and replacement.
3. Check DTC. If DTC is detected, erase it.

>> GO TO 9.

9. FINAL CHECK

When DTC is detected in step 2, perform DTC CONFIRMATION PROCEDURE again, and then check that the malfunction is repaired securely.

When symptom is described by the customer, refer to confirmed symptom in step 3 or 4, and check that the symptom is not detected.

Is DTC detected and does symptom remain?

YES-1 >> DTC is detected: GO TO 7.

YES-2 >> Symptom remains: GO TO 4.

NO >> Before returning the vehicle to the customer, always erase DTC.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

INSPECTION AND ADJUSTMENT

Description & Inspection

INFOID:000000009722025

DESCRIPTION

The purpose of the operational check is to check that the individual system operates normally.

Conditions : Engine running at normal operating temperature

INSPECTION PROCEDURE

1.CHECK MEMORY FUNCTION

1. Start the engine.
2. Operate the temperature control switch (driver side) and raise the temperature setting to 32°C (90°F).
3. Press the ON/OFF switch.
4. Turn the ignition switch OFF.
5. Turn the ignition switch ON.
6. Press the AUTO switch.
7. Check that the temperature setting before turning the ignition switch OFF is stored.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Memory function malfunction: [HAC-117, "Inspection procedure"](#).

2.CHECK BLOWER MOTOR SPEED

1. Start the engine.
2. Operate the fan control dial. Check that the fan speed changes. Check the operation for all fan speeds.
3. Set the fan speed to speed 7.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Blower motor system malfunction: [HAC-70, "Diagnosis Procedure"](#).

3.CHECK DISCHARGE AIR (MODE SWITCH AND DEF SWITCH)

1. Press the MODE switch and the DEF switch.
2. Check that the air outlets change according to each indicated air outlet by placing a hand in front of the outlets. Refer to [HAC-16, "System Description"](#).

NOTE:

Confirm that the compressor clutch is engaged (sound or visual inspection) and the intake door position is at the FRE when the D/F or DEF is selected.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Mode door system malfunction: [HAC-63, "Diagnosis Procedure"](#).

4.CHECK DISCHARGE AIR (UPPER VENT SWITCH)

1. Press the UPPER VENT switch.
2. The UPPER VENT switch indicator is turned ON.

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[WITHOUT 7 INCH DISPLAY]

3. Check that the air blown from the UPPER VENT does not greatly deviate from the air mix ratio.

Discharge air flow							
Mode position indication	Condition	Air outlet/distribution					
		VENT			FOOT		DEF
		Front	Upper	Rear	Front	Rear	
	DUAL switch: OFF UPPER VENT switch : ON	81%	8%	11%	—	—	—
		41%	10%	17%	24%	8%	—
		12%	12%	16%	27%	10%	23%
		11%	11%	14%	25%	10%	29%
		11%	11%	12%	—	—	66%

JPIIA0509GB

4. Press the UPPER VENT switch again.
 5. The UPPER VENT switch indicator is turned OFF.
 6. The air blown from the UPPER VENT stops.

Does it operate normally?

YES >> GO TO 5.

NO >> Upper ventilator door system malfunction: [HAC-68, "Diagnosis Procedure"](#).

5. CHECK INTAKE AIR

1. Press the intake switch. Indicator is turned ON (REC).
 2. Press the intake switch again. Indicator is turned OFF (FRE).
 3. Listen for the intake door position change. (Slight change of blower sound can be heard.)

NOTE:

Confirm that the compressor clutch is engaged (sound or visual inspection) and the intake door position is at the FRE when the D/F or DEF is selected.

Is the inspection result normal?

YES >> GO TO 6.

NO >> Intake door system malfunction: [HAC-66, "Diagnosis Procedure"](#).

6. CHECK A/C SWITCH

1. Press the A/C switch.
 2. The A/C switch indicator is turned ON.
 Confirm that the compressor clutch engages (sound or visual inspection).

Is the inspection result normal?

YES >> GO TO 7.

NO >> Magnet clutch system malfunction: [HAC-74, "Diagnosis Procedure"](#).

7. CHECK WITH TEMPERATURE SETTING LOWERED

1. Operate the compressor.
 2. Operate the temperature control switch (driver side) and lower the temperature setting to 18°C (60°F).
 3. Check that the cool air blows from the outlets.

Is the inspection result normal?

YES >> GO TO 8.

NO >> Insufficient cooling: [HAC-109, "Inspection procedure"](#).

8. CHECK WITH TEMPERATURE SETTING RAISED

1. Operate the temperature control switch (driver side) and raise the temperature setting to 32°C (90°F) after warming up the engine.
 2. Check that the warm air blows from the outlets.

Is the inspection result normal?

YES >> GO TO 9.

NO >> Insufficient heating: [HAC-112, "Inspection procedure"](#).

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[WITHOUT 7 INCH DISPLAY]

9. CHECK LH/RH INDEPENDENT TEMPERATURE ADJUSTMENT FUNCTION

1. Press the DUAL switch, and then check that "DUAL" is shown on the display.
2. Operate the temperature control switch (driver side). Check that the discharge air temperature (driver side) changes.
3. Operate the temperature control switch (passenger side). Check that the discharge air temperature (passenger side) changes.
4. Press the DUAL switch, and then check that the temperature setting (LH/RH) is unified to the driver side temperature setting.

Is the inspection result normal?

YES >> GO TO 10.

NO >> Refer to [HAC-108. "Diagnosis Chart By Symptom"](#) and perform the appropriate diagnosis.

10. CHECK AUTO MODE

1. Press the AUTO switch, and then check that "AUTO" is shown on the display.
2. Operate the temperature control switch (driver side). Check that the fan speed or outlet changes (the discharge air temperature or fan speed varies depending on the ambient temperature, in-vehicle temperature, and temperature setting).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Refer to [HAC-108. "Diagnosis Chart By Symptom"](#) and perform the appropriate diagnosis.

Temperature Setting Trimmer

INFOID:000000009722026

Description

If the temperature felt by the customer is different than the air flow temperature controlled by the temperature setting, the auto amplifier control temperature can be adjusted to compensate for the temperature setting.

How to set

Using CONSULT, perform "TEMP SET CORRECT" on "WORK SUPPORT" of HVAC.

Work support items	Display (°F)	Display (°C)
TEMP SET CORRECT	6	3.0
	5	2.5
	4	2.0
	3	1.5
	2	1.0
	1	0.5
	0 (initial status)	0 (initial status)
	-1	-0.5
	-2	-1.0
	-3	-1.5
	-4	-2.0
	-5	-2.5
	-6	-3.0

NOTE:

- When the temperature setting is set to 25.0°C (77°F) and -3.0°C (-6°F), the temperature controlled by auto amp is 25.0°C (77°F) - 3.0°C (6°F) = 22.0°C (71°F) and the temperature becomes lower than the temperature setting.
- When the battery cable is disconnected from the negative terminal or when the battery voltage becomes 10V or less, the setting of the difference between the temperature setting and control temperature may be cancelled.

Foot Position Setting Trimmer

INFOID:000000009722027

Description

In the FOOT mode, the air blowing to the DEF can be turned ON/OFF.

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[WITHOUT 7 INCH DISPLAY]

How to set

Using CONSULT, perform "BLOW SET" on "WORK SUPPORT" of HVAC.

Work support items	Display	DEF door position	
		Auto control	Manual control
BLOW SET	Mode 1	OPEN	CLOSE
	Mode 2 (initial status)	OPEN	OPEN
	Mode 3	CLOSE	OPEN
	Mode 4	CLOSE	CLOSE

NOTE:

When the battery cable is disconnected from the negative terminal or when the battery voltage becomes 10V or less, the setting of the discharge air mix ratio in FOOT mode may be cancelled.

Inlet Port Memory Function (FRE)

INFOID:000000009722028

Description

- If the ignition switch is turned to the OFF position while the FRE switch is set to ON (fresh air intake), "Perform the memory" or "Do not perform the memory" of the FRE switch ON (fresh air intake) condition can be selected.
- If "Perform the memory" was set, the FRE switch will be ON (fresh air intake) when turning the ignition switch to the ON position again.
- If "Do not perform the memory" was set, the air inlets will be controlled automatically when turning the ignition switch to the ON position again.

How to set

Using CONSULT, perform "FRE MEMORY SET" on "WORK SUPPORT" of HVAC.

HAC

Work support items	Display	Setting
FRE MEMORY SET	WITHOUT	Perform the memory of manual FRE
	WITH (initial status)	Do not perform the memory of manual FRE (auto control)

NOTE:

When the battery cable is disconnected from the negative terminal or when the battery voltage becomes 10 V or less, the setting of the FRE switch memory function may be cancelled.

Inlet Port Memory Function (REC)

INFOID:000000009722029

Description

- If the ignition switch is turned to the OFF position while the REC switch is set to ON (recirculation), "Perform the memory" or "Do not perform the memory" of the REC switch ON (recirculation) condition can be selected.
- If "Perform the memory" was set, the REC switch will be ON (recirculation) when turning the ignition switch to the ON position again.
- If "Do not perform the memory" was set, the air inlets will be controlled automatically when turning the ignition switch to the ON position again.

How to set

Using CONSULT, perform "REC MEMORY SET" on "WORK SUPPORT" of HVAC.

Work support items	Display	Setting
REC MEMORY SET	WITHOUT (initial status)	Perform the memory of manual REC
	WITH	Do not perform the memory of manual REC (auto control)

NOTE:

When the battery cable is disconnected from the negative terminal or when the battery voltage becomes 10 or less, the setting of the REC switch memory function may be cancelled.

COMPRESSOR CONTROL FUNCTION

< SYSTEM DESCRIPTION >

[WITHOUT 7 INCH DISPLAY]

SYSTEM DESCRIPTION

COMPRESSOR CONTROL FUNCTION


Description

INFOID:000000009722030

PRINCIPLE OF OPERATION

Compressor is not activated.

Functional circuit diagram



- CAN (1) : A/C switch signal
- : Blower fan motor switch signal
- RX, TX : A/C switch signal
- : Fan ON signal
- : Defroster signal

CAN (2) : A/C Compressor request signal

Functional initial inspection chart

×: Applicable

Control unit	Diagnosis item	Location			
		A	B	C	D
A/C auto amp.	Self-diagnosis	×	—	—	—
	④ "HVAC" Data monitor	×	—	—	—
	Active test	×	—	—	×
ECM	Self-diagnosis function (CAN system diagnosis)	—	—	×	—
	Data monitor	—	×	×	—
IPDM E/R	Self-diagnosis function (CAN system diagnosis)	—	—	—	×
	Data monitor	—	—	×	—
	Auto active test	—	—	—	×

COMPRESSOR CONTROL FUNCTION


< SYSTEM DESCRIPTION >

[WITHOUT 7 INCH DISPLAY]

Component Part Location

INFOID:000000009722031

ENGINE COMPARTMENT



A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

1. Refrigerant pressure sensor

2. Compressor (magnet clutch)

3. Ambient sensor


PASSENGER COMPARTMENT

JPIIA0607ZZ

COMPRESSOR CONTROL FUNCTION

< SYSTEM DESCRIPTION >

[WITHOUT 7 INCH DISPLAY]



JPIIA0608ZZ

- | | | |
|-------------------------------------|--------------------------------|--|
| 1. Intake door motor | 2. Upper ventilator door motor | 3. Air mix door motor (passenger side) |
| 4. Air mix door motor (driver side) | 5. Mode door motor | 6. Sunload sensor |
| 7. In-vehicle sensor | 8. A/C auto amp. | 9. Intake sensor |
| 10. Blower motor | | |

COMPRESSOR CONTROL FUNCTION

< SYSTEM DESCRIPTION >

[WITHOUT 7 INCH DISPLAY]

Component's Role

INFOID:000000009722032

Component	Reference
Refrigerant pressure sensor	EC-465. "Description"
Compressor	HAC-74. "Description"
Ambient sensor	HAC-46. "Description"
Intake door motor	HAC-65. "Description"
Upper ventilator door motor	HAC-67. "Description"
Air mix door motor (driver side)	HAC-58. "Description"
Air mix door motor (passenger side)	HAC-60. "Description"
Mode door motor	HAC-62. "Description"
Sunload sensor	HAC-55. "Description"
In-vehicle sensor	HAC-49. "Description"
A/C auto amp.	HAC-77. "A/C AUTO AMP. : Description"
Intake sensor	HAC-52. "Description"
Blower motor	HAC-70. "Description"

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

AUTOMATIC AIR CONDITIONER SYSTEM

< SYSTEM DESCRIPTION >

[WITHOUT 7 INCH DISPLAY]


AUTOMATIC AIR CONDITIONER SYSTEM

System Diagram

INFOID:000000009722033

CONTROL SYSTEM

The control system consists of input sensors, switches, the A/C auto amp. (microcomputer) and outputs. The relationship of these components is as shown in the figure below:




System Description

INFOID:000000009722034

CONTROL OPERATION

Display

The operation status of the system is displayed on the screen.




AUTOMATIC AIR CONDITIONER SYSTEM

< SYSTEM DESCRIPTION >

[WITHOUT 7 INCH DISPLAY]

A/C Control



MODE Switch

The air discharge outlets are controlled with this switch.

Temperature Control Switch (Driver Side)

The set temperature is increased or decreased with this switch.

Temperature Control Switch (Passenger Side)

- The set temperature is increased or decreased with this switch.
- When this switch is pressed, DUAL switch indicator is turned ON.

AUTO Switch

- The compressor, intake doors, air mix doors, mode doors and blower speed are automatically controlled so that the in-vehicle temperature will reach, and be maintained at the set temperature selected by the operator.
- When pressing the AUTO switch, air inlet, air outlet, fan speed, and discharge air temperature are automatically controlled.

Defroster (DEF) Switch

Mode doors are set to the defrost position with this switch. Also, intake doors are set to the outside air position, and compressor turns ON.

UPPER VENT Switch

- When the UPPER VENT switch is pressed, the UPPER VENT switch indicator is turned ON.
- When the UPPER VENT switch indicator is turned ON, the UPPER VENT switch indicator is turned OFF by pressing the defroster (DEF) switch (after the above operation, the UPPER VENT switch indicator is turned ON by pressing the UPPER VENT switch).

A/C Switch

Compressor turns ON or OFF with this switch.

(Pressing the A/C switch when the A/C switch is ON turns OFF the A/C switch and compressor.)

Fan Control Dial

The blower speed is manually controlled with this dial. Seven speeds are available for manual control (as shown on the display screen).

ON/OFF Switch

Compressor and blower turn OFF, air inlet sets to FRE, and mode the position is set to foot position.

Rear Window Defogger Switch

When indicator is ON, rear window is defogged.

Intake Switch

- When the intake switch is ON, the intake switch indicator is turned ON, and air inlet is set to REC.
- When the intake switch is pressed again, the intake switch indicator is turned OFF, and air inlet is set to FRE.
- When the intake switch is pressed for approximately 1.5 seconds or longer, the intake switch indicator blink twice. Then, automatic control mode is entered. Inlet status is displayed by indicator even when automatically controlled.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

HAC

AUTOMATIC AIR CONDITIONER SYSTEM

< SYSTEM DESCRIPTION >

[WITHOUT 7 INCH DISPLAY]

- When the intake switch indicator is turned OFF, shifting mode position to D/F or DEF, or when compressor is turned from ON to OFF, intake switch is automatically turned OFF (set to FRE mode). REC mode can be re-entered by pressing intake switch again, and then compressor is turned ON. (Except D/F or DEF position)

DUAL Switch


- When the DUAL switch indicator is ON, the driver side and passenger side, temperature can each be set independently.
- When the DUAL switch indicator is OFF, the driver side outlet and setting temperature are applied to both sides.

AUTOMATIC AIR CONDITIONER SYSTEM

< SYSTEM DESCRIPTION >

[WITHOUT 7 INCH DISPLAY]

DISCHARGE AIR FLOW



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P






HAC

AUTOMATIC AIR CONDITIONER SYSTEM






< SYSTEM DESCRIPTION >

[WITHOUT 7 INCH DISPLAY]

AIR DISTRIBUTION

Discharge air flow							
Mode position indication	Condition	Air outlet/distribution					
		VENT			FOOT		DEF
		Front	Upper	Rear	Front	Rear	
	DUAL switch: OFF UPPER VENT switch : ON	81%	8%	11%	—	—	—
		41%	10%	17%	24%	8%	—
		12%	12%	16%	27%	10%	23%
		11%	11%	14%	25%	10%	29%
		11%	11%	12%	—	—	66%

JP1IA0509GB

Discharge air flow							
Mode position indication	Condition	Air outlet/distribution					
		VENT			FOOT		DEF
		Front	Upper	Rear	Front	Rear	
	DUAL switch: OFF UPPER VENT switch : OFF	88%	—	12%	—	—	—
		47%	—	18%	26%	9%	—
		13%	—	17%	33%	12%	25%
		12%	—	16%	28%	12%	32%
		11%	—	15%	—	—	74%


JP1IA0510GB

SWITCHES AND THEIR CONTROL FUNCTION

AUTOMATIC AIR CONDITIONER SYSTEM

< SYSTEM DESCRIPTION >

[WITHOUT 7 INCH DISPLAY]



* : Models for Mexico.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

AUTOMATIC AIR CONDITIONER SYSTEM

< SYSTEM DESCRIPTION >

[WITHOUT 7 INCH DISPLAY]


Switch position			Door position						Air mix door (Driver side)	Air mix door (Passenger side)
			Ventilator door	Max. cool door	Defroster door	Foot door	Upper ventilator door	Intake door		
AUTO switch	☀		AUTO						AUTO	
MODE switch	VENT	☀	A	A	A	A	—	—	—	
	B/L	☀	B	B	A	B				
	FOOT	☀	C	B	B	C				
	D/F	☀	C	B	B	B				
DEF switch	☀	☀	C	C	C	A	B	—	—	
UPPER VENT switch	ON	☀	—				A-B	—	—	—
	OFF	☀	—				C	—		
Intake switch	ON	☀	—	—	—	—	—	A*	—	
	OFF	☀						B*		
Temperature control switch (Driver side)	DUAL switch: OFF	18.0°C (60°F)	—	—	—	—	—	A	—	
		18.5°C ⇔ 31.5°C (61°F ⇔ 89°F)						AUTO		
		32.0°C (90°F)						B		
Temperature control switch (Driver side)	DUAL switch: ON	18.0°C (60°F)	—	—	—	—	—	A	—	
		18.5°C ⇔ 31.5°C (61°F ⇔ 89°F)						AUTO		
		32.0°C (90°F)						B		
Temperature control switch (Passenger side)	DUAL switch: ON	18.0°C (60°F)	—	—	—	—	—	A	—	
		18.5°C ⇔ 31.5°C (61°F ⇔ 89°F)						AUTO		
		32.0°C (90°F)						B		
ON/OFF switch			C	C	B	C	—	B	—	—

*: Inlet status is displayed by indicator when activating automatic control.

AIR CONDITIONER LAN CONTROL SYSTEM

The LAN (Local Area Network) system consists of the A/C auto amp., the mode door motor, the air mix door motors, the upper ventilator door motor and the intake door motor.

A configuration of these components is as shown in the figure below.



AUTOMATIC AIR CONDITIONER SYSTEM

[WITHOUT 7 INCH DISPLAY]

< SYSTEM DESCRIPTION >


SYSTEM CONSTRUCTION

A small network exists between the A/C auto amp., the mode door motor, the air mix door motors, the upper ventilator door motor and the intake door motor. The A/C auto amp. and motors are connected by data transmission lines and motor power supply lines. The LAN network is built through the ground circuits of each door motor.

Addresses, motor opening angle signals, motor stop signals and error checking messages are all transmitted through the data transmission lines connecting the A/C auto amp. and each door motor.

The following functions are contained in LCUs built into the mode door motor, the air mix door motors, the upper ventilator door motor and the intake door motor.


- Address
- Motor opening angle signals
- Data transmission
- Motor stop and drive decision
- Opening angle sensor (PBR function)
- Comparison
- Decision (A/C auto amp. indicated value and motor opening angle comparison)



Operation

The A/C auto amp. receives data from each of the sensors. The A/C auto amp. sends mode door, the air mix door and the intake door opening angle data to the mode door motor LCU, the air mix door motor LCUs, the upper ventilator door motor LCU and the intake door motor LCU.

The mode door motor, the air mix door motors, the upper ventilator door motor and the intake door motor read their respective signals according to the address signal. Opening angle indication signals received from the A/C auto amp. and each of the motor position sensors is compared by the LCUs in each door motor with the existing decision and opening angles. Next, HOT/COLD, DEF/VENT, OPEN/SHUT or FRE/REC operation is selected. The new selection data is returned to the A/C auto amp.



Transmission Data and Transmission Order

A/C auto amp. data is transmitted consecutively to each of the door motors following the form as shown in the figure below.

START:

- Initial compulsory signal is sent to each of the door motors.

ADDRESS:

- Data sent from the A/C auto amp. is selected according to data-based decisions made by the mode door motor, the air mix door motors, the upper ventilator door motor and the intake door motor.
- If the addresses are identical, the opening angle data and error check signals are received by the door motor LCUs. The LCUs then make the appropriate error decision. If the opening angle data has no error, door control begins.
- If an error exists, the received data is rejected and the corrected data received. Finally, door control is based upon the corrected opening angle data.

AUTOMATIC AIR CONDITIONER SYSTEM

[WITHOUT 7 INCH DISPLAY]

< SYSTEM DESCRIPTION >

OPENING ANGLE:


- Data that shows the indicated door opening angle of each door motor.

ERROR CHECK:

- In this procedure, transmitted and received data is checked for errors. Error data is then compiled. The error check prevents corrupted data from being used by the mode door motor, the air mix door motors, the upper ventilator door motor and the intake door motor. Error data can be related to the following symptoms.
 - Malfunction of electrical frequency
 - Poor electrical connections
 - Signal leakage from transmission lines
 - Signal level fluctuation

STOP SIGNAL:

- At the end of each transmission, a stop operation, in-operation, or internal malfunction message is delivered to the A/C auto amp. This completes one data transmission and control cycle.



Component Part Location


INFOID:000000009722035

ENGINE COMPARTMENT

AUTOMATIC AIR CONDITIONER SYSTEM

< SYSTEM DESCRIPTION >

[WITHOUT 7 INCH DISPLAY]



1. Refrigerant pressure sensor

2. Compressor (magnet clutch)

3. Ambient sensor

PASSENGER COMPARTMENT


A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

JPIIA0607ZZ

AUTOMATIC AIR CONDITIONER SYSTEM

< SYSTEM DESCRIPTION >

[WITHOUT 7 INCH DISPLAY]



JPIIA0608ZZ

- | | | |
|-------------------------------------|--------------------------------|--|
| 1. Intake door motor | 2. Upper ventilator door motor | 3. Air mix door motor (passenger side) |
| 4. Air mix door motor (driver side) | 5. Mode door motor | 6. Sunload sensor |
| 7. In-vehicle sensor | 8. A/C auto amp. | 9. Intake sensor |
| 10. Blower motor | | |

AUTOMATIC AIR CONDITIONER SYSTEM

< SYSTEM DESCRIPTION >

[WITHOUT 7 INCH DISPLAY]

Component Description

INFOID:000000009722036

Component	Reference
Refrigerant pressure sensor	EC-465. "Description"
Compressor	HAC-74. "Description"
Ambient sensor	HAC-46. "Description"
Intake door motor	HAC-65. "Description"
Upper ventilator door motor	HAC-67. "Description"
Air mix door motor (driver side)	HAC-58. "Description"
Air mix door motor (passenger side)	HAC-60. "Description"
Mode door motor	HAC-62. "Description"
Sunload sensor	HAC-55. "Description"
In-vehicle sensor	HAC-49. "Description"
A/C auto amp.	HAC-77. "A/C AUTO AMP. : Description"
Intake sensor	HAC-52. "Description"
Blower motor	HAC-70. "Description"

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

MODE DOOR CONTROL SYSTEM


< SYSTEM DESCRIPTION >

[WITHOUT 7 INCH DISPLAY]

MODE DOOR CONTROL SYSTEM

System Diagram

INFOID:000000009722037



System Description


INFOID:000000009722038

The mode door is automatically controlled by the temperature setting, ambient temperature, in-vehicle temperature, intake temperature and amount of sunload.

SYSTEM OPERATION

- The A/C auto amp. receives data from each of the sensors.
- The A/C auto amp. sends the air mix door, the mode door, the upper ventilator door and the intake door opening angle data to the air mix door motor LCU(s), the mode door motor LCU, the upper ventilator door motor LCU and the intake door motor LCU.
- The air mix door motor(s), the mode door motor, the upper ventilator door motor and the intake door motor read their respective signals according to the address signal. Opening angle indication signals received from the A/C auto amp. and each of the motor position sensors are compared by the LCUs in each door motor with the existing decision and opening angles.
- Next, HOT/COLD, DEF/VENT, OPEN/SHUT or FRE/REC operations is selected. The newly selected data is returned to the A/C auto amp.

Door Motor Circuit




Mode Door Control Specification

MODE DOOR CONTROL SYSTEM

< SYSTEM DESCRIPTION >

[WITHOUT 7 INCH DISPLAY]

Mode position can be selected manually by pressing the MODE switch or the DEF switch on the A/C control. This enables to fix a mode position. Pressing the AUTO switch allows automatic control by the A/C auto amp. During the automatic control of a mode position, a mode door position (VENT, B/L, FOOT, or D/F) is selected based on a target the air mix door opening angle and sunload depending on the temperature calculated by the A/C auto amp. In addition, the D/F is selected to prevent windshield fogging only when ambient temperature is extremely low with mode position the FOOT.



A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

UPPER VENTILATOR DOOR CONTROL SYSTEM


< SYSTEM DESCRIPTION >

[WITHOUT 7 INCH DISPLAY]

UPPER VENTILATOR DOOR CONTROL SYSTEM

System Diagram

INFOID:000000009722039



System Description


INFOID:000000009722040

The upper ventilator door motor is attached to the heater & cooling unit assembly. The upper ventilator door motor operates by the UPPER VENT switch ON/OFF. Motor rotation is conveyed to a rod which activates the upper ventilator door.

SYSTEM OPERATION

- The A/C auto amp. receives data from each of the sensors.
- The A/C auto amp. sends air mix door, the mode door, the upper ventilator door and the intake door opening angle data to the air mix door motor LCU(s), the mode door motor LCU, the upper ventilator door motor LCU and the intake door motor LCU.
- The air mix door motor(s), the mode door motor, the upper ventilator door motor and the intake door motor read their respective signals according to the address signal. Opening angle indication signals received from the A/C auto amp. and each of the motor position sensors are compared by the LCUs in each door motor with the existing decision and opening angles.
- Next, HOT/COLD, DEF/VENT, OPEN/SHUT or FRE/REC operations is selected. The newly selected data is returned to the A/C auto amp.

Door Motor Circuit



Upper Ventilator Specification

UPPER VENTILATOR DOOR CONTROL SYSTEM

< SYSTEM DESCRIPTION >

[WITHOUT 7 INCH DISPLAY]

UPPER VENT switch	MODE position	Upper ventilator door position
OFF	—	Close
ON	VENT or B/L	Open (Fully-open)
ON	FOOT or D/F	Open (Intermediate)
ON	DEF	Close

A

B

C

D

E

F

G

H

HAC

J

K

L

M

N

O

P


AIR MIX DOOR CONTROL SYSTEM

< SYSTEM DESCRIPTION >

[WITHOUT 7 INCH DISPLAY]

AIR MIX DOOR CONTROL SYSTEM

System Diagram



System Description


INFOID:00000009722042

The air mix doors are automatically controlled so that in-vehicle temperature is maintained at a predetermined value by the temperature setting, ambient temperature, intake temperature and amount of sunload.

SYSTEM OPERATION

- The A/C auto amp. receives data from each of the sensors.
- The A/C auto amp. sends air mix door, the mode door, the upper ventilator door and the intake door opening angle data to the air mix door motor LCU(s), the mode door motor LCU, the upper ventilator door motor LCU and the intake door motor LCU.
- The air mix door motor(s), the mode door motor, the upper ventilator door motor and the intake door motor read their respective signals according to the address signal. Opening angle indication signals received from the A/C auto amp. and each of the motor position sensors are compared by the LCUs in each door motor with the existing decision and opening angles.
- Next, HOT/COLD, DEF/VENT, OPEN/SHUT or FRE/REC operation is selected. The newly selected data is returned to the A/C auto amp.

Door Motor Circuit




Air Mix Door Control Specification

AIR MIX DOOR CONTROL SYSTEM

< SYSTEM DESCRIPTION >

[WITHOUT 7 INCH DISPLAY]

When ignition switch is ON, the A/C auto amp. continuously and automatically controls temperatures regardless of air conditioner operational condition. When setting a target temperature with the temperature control switch, the A/C auto amp. corrects the set temperature and decides a target air mix door opening angle. The A/C auto amp. controls air mix door according to the target air mix door opening angle and current air mix door opening angle, keeping an optimum air mix door opening angle. When the temperature is set at 18°C (60°F), air mix door is set on full cold, and when the temperature is set at 32°C (90°F), it is set to full hot.



A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

INTAKE DOOR CONTROL SYSTEM


< SYSTEM DESCRIPTION >

[WITHOUT 7 INCH DISPLAY]

INTAKE DOOR CONTROL SYSTEM

System Diagram

INFOID:000000009722043



System Description


INFOID:000000009722044

The intake doors are automatically controlled by the temperature setting, ambient temperature, in-vehicle temperature, intake temperature, amount of sunload and ON/OFF operation of the compressor.

SYSTEM OPERATION

The intake door control judges intake door position based on the ambient temperature, the intake air temperature and the in-vehicle temperature. When in shifting mode position D/F, if the DEF or ON/OFF switches are pressed, or when the A/C switch is OFF, the A/C auto amp. sets the intake door to the FRE position.

Door Motor Circuit



Intake Door Control Specification


INTAKE DOOR CONTROL SYSTEM

[WITHOUT 7 INCH DISPLAY]

< SYSTEM DESCRIPTION >

Intake door position is basically set to the FRE when the FRE indicator of the DEF switch and the intake switch turn ON, and set on the REC when the REC indicator of intake switch turns ON.

The intake door automatic control selects the FRE, the 20%FRE, or the REC depending on the target air mix door opening angle, based on in-vehicle temperature, ambient temperature, and sunload.



A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC


BLOWER MOTOR CONTROL SYSTEM

< SYSTEM DESCRIPTION >

[WITHOUT 7 INCH DISPLAY]

BLOWER MOTOR CONTROL SYSTEM

System Diagram



System Description

INFOID:000000009722046

Blower speed is automatically controlled by the temperature setting, ambient temperature, in-vehicle temperature, intake temperature, amount of sunload and air mix door position.


By pressing the AUTO switch, the blower motor starts to gradually increase air flow volume.

When engine coolant temperature is low, the blower motor operation is delayed to prevent cool air from flowing.

SYSTEM OPERATION

System operation

- For air flow, the manual selection (1-7) with the fan control dial has priority.
- If the AUTO switch is pressed or if the DEF switch is pressed while in the OFF condition, it changes to the automatic control by A/C auto amp.
- When increasing the air flow, it changes the duty ratio of the blower motor drive signal to prevent the air flow from suddenly increasing.
- There are the following types of air flow control: starting air flow control, starting air flow control at low coolant temperature, starting air flow control at high in-vehicle temperature, and air flow control at actuator operation in addition to manual control, normal automatic air flow control.



Normal automatic air flow control


- When the target temperature is set by the temperature control switch of A/C control, the A/C auto amp. performs the calculation and decides the target according to the signal from each sensor.
- The A/C auto amp. changes the duty ratio of blower motor drive signal and controls the air flow continuously so that the air flow becomes the target air flow.
- The minimum air flow will change according to the sunload when the air discharge outlet is VENT or B/L.

BLOWER MOTOR CONTROL SYSTEM

< SYSTEM DESCRIPTION >

[WITHOUT 7 INCH DISPLAY]

Fan Speed Control Specification



Starting air flow control

- When starting the automatic control of air flow, the system gradually increases the duty ratio of the blower motor drive signal to prevent too much air from blowing.
- The time period from when the air flow changes from LO to HI is approximately 8 seconds.
- It becomes the starting air flow control at low coolant temperature according to the calculation result of the A/C auto amp. and engine coolant temperature [approximately 58°C (136°F) or less] during the automatic air flow control.
- Do not perform the starting air flow control when the air discharge outlet is set to DEF.

Starting Fan Speed Control

Start up from COLD SOAK Condition (Automatic mode)

In cold start up condition where the engine coolant temperature is below 58°C (136°F), the blower does not operate for a short period of time (up to 150 seconds). The exact start delay time varies depending on the ambient temperature and engine coolant temperature.

In the most extreme case (very low ambient temperature) the blower start delay is 150 seconds as described above. After this delay, the blower will operate at low speed until the engine coolant temperature rises above 58°C (136°F), and then the blower speed increases to the objective speed.

Start up from usual or HOT SOAK Condition (Automatic mode)

The blower will begin operation momentarily after the AUTO switch is pressed. The blower speed rises gradually to the objective speed over a time period of 3 seconds or less (actual time depends on the objective blower speed).

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P


MAGNET CLUTCH CONTROL SYSTEM

< SYSTEM DESCRIPTION >

[WITHOUT 7 INCH DISPLAY]

MAGNET CLUTCH CONTROL SYSTEM

System Diagram



System Description

INFOID:000000009722048

The A/C auto amp. controls compressor operation by ambient temperature, intake air temperature and signal from ECM.

SYSTEM OPERATION

When the A/C switch, the AUTO switch, or the DEF switch is pressed, or when shifting mode position D/F, A/C auto amp. transmit the A/C switch signal and blower fan motor switch signal to the ECM, via CAN communication.

ECM judges whether compressor can be turned ON, based on each sensor status (refrigerant-pressure sensor signal, throttle angle, etc.). If the ECM judges that the compressor can be turned ON, it sends A/C compressor request signal to the IPDM E/R, via CAN communication.

Upon receipt of A/C compressor request signal from the ECM, the IPDM E/R turns the A/C relay ON to operate the compressor.

When sending A/C compressor request signal to the IPDM E/R via CAN communication line, the ECM simultaneously sends A/C compressor feedback signal to A/C auto amp. via CAN communication line.

The ECM sends A/C compressor feedback signal to A/C auto amp., then, uses input A/C compressor feedback signal to control air inlet.

Compressor Protection Control

The ECM makes the A/C relay turn OFF and stops the compressor when pressure on the high-pressure side detected by the refrigerant pressure sensor is over approximately 3,119 kPa (31.8 kg/cm², 452 psi), or below approximately 118 kPa (1.2 kg/cm², 17 psi).

Low Temperature Protection Control

Turn the A/C relay to OFF and stop the compressor by the signal from the A/C auto amp according to the evaporator passing air temperature detected by the intake sensor and the ambient temperature detected by the ambient sensor.

CAN COMMUNICATION SYSTEM

System Description

INFOID:000000009722049

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto each vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only. For details, refer to [LAN-28. "CAN System Specification Chart"](#).

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

DIAGNOSIS SYSTEM (HVAC)

< SYSTEM DESCRIPTION >

[WITHOUT 7 INCH DISPLAY]

DIAGNOSIS SYSTEM (HVAC)

CONSULT Function

INFOID:000000009722050

CONSULT can display each diagnosis item using the diagnosis test modes shown as per the following.

CONSULT application items

Diagnosis mode	Description
ECU Identification	Displays the A/C auto amp. number.
Self Diagnostic Result	Displays the diagnosis results judged by A/C auto amp.
Data Monitor	Displays A/C auto amp. input/output data in real time.
Active Test	The signals used to activate each device are forcibly supplied from A/C auto amp.
Work Support	Changes the setting for each system function. <ul style="list-style-type: none"> • Temperature setting trimmer • Inlet port memory function (FRE) • Inlet port memory function (REC) • Foot position setting trimmer

SELF DIAGNOSTIC RESULT

Refer to [HAC-106, "DTC Index"](#).

Display Item List

DTC	Items (CONSULT screen terms)	Diagnostic item is detected when...	Possible cause
U1000	CAN COMM CIRCUIT	When A/C auto amp. is not transmitting or receiving CAN communication signal for 2 or more seconds.	CAN communication system
U1010	CONTROL UNIT (CAN)	When detecting error during the initial diagnosis of CAN controller of A/C auto amp.	A/C auto amp.
B257B	AMB TEMP SEN SHORT	Detected temperature at ambient sensor -44°C (-47°F) or less	<ul style="list-style-type: none"> • Ambient sensor • A/C auto amp. • Harness and connector (Ambient sensor circuit is open, or there is a short in the circuit)
B257C	AMB TEMP SEN OPEN	Detected temperature at ambient sensor 100°C (212°F) or more	
B2578	IN CAR SEN SHORT	Detected temperature at in-vehicle sensor -44°C (-47°F) or less	<ul style="list-style-type: none"> • In-vehicle sensor • A/C auto amp. • Harness and connector (In-vehicle sensor circuit is open, or there is a short in the circuit)
B2579	IN CAR SEN OPEN	Detected temperature at in-vehicle sensor 100°C (212°F) or more	
B2581	EVAP TEMP SEN SHORT	Detected temperature at intake sensor -33°C (-27°F) or less	<ul style="list-style-type: none"> • Intake sensor • A/C auto amp. • Harness and connector (Intake sensor circuit is open, or there is a short in the circuit)
B2582	EVAP TEMP SEN OPEN	Detected temperature at intake sensor 69°C (156°F) or more	
B2630*	SUNLOAD SEN SHORT	Detected calorie at sunload sensor 64.7 w/m^2 ($56 \text{ kcal/m}^2\cdot\text{h}$) or less	<ul style="list-style-type: none"> • Sunload sensor • A/C auto amp. • Harness and connector (Sunload sensor circuit is open, or there is a short in the circuit)
B2631*	SUNLOAD SEN OPEN	Detected calorie at sunload sensor 2832 w/m^2 ($2436 \text{ kcal/m}^2\cdot\text{h}$) or more	
B2632	DR AIRMIX ACTR SHORT	Air mix door PBR (driver side) position 5% or less	<ul style="list-style-type: none"> • Air mix door motor (driver side) • A/C auto amp. • Harness and connector (CAN communication line is open or shorted)
B2633	DR AIRMIX ACTR OPEN	Air mix door PBR (driver side) position 95% or more	<ul style="list-style-type: none"> • Air mix door motor (driver side) • A/C auto amp. • Harness and connector (CAN communication line is open or shorted)

DIAGNOSIS SYSTEM (HVAC)

< SYSTEM DESCRIPTION >

[WITHOUT 7 INCH DISPLAY]

DTC	Items (CONSULT screen terms)	Diagnostic item is detected when...	Possible cause
B2634	PASS AIRMIX ACTR SHORT	Air mix door PBR (passenger side) position 5% or less	<ul style="list-style-type: none"> Air mix door motor (passenger side) A/C auto amp. Harness and connector (CAN communication line is open or shorted)
B2635	PASS AIRMIX ACTR OPEN	Air mix door PBR (passenger side) position 95% or more	<ul style="list-style-type: none"> Air mix door motor (passenger side) A/C auto amp. Harness and connector (CAN communication line is open or shorted)
B2636	DR VENT DOOR FAIL	When the malfunctioning door position is detected at VENT position	<ul style="list-style-type: none"> Mode door motor A/C auto amp. Harness and connector (CAN communication line is open or shorted) (Mode door motor is open or shorted)
B2637	DR B/L DOOR FAIL	When the malfunctioning door position is detected at B/L position	
B2638	DR D/F1 DOOR FAIL	When the malfunctioning door position is detected at FOOT position	
B2639	DR DEF DOOR FAIL	When the malfunctioning door position is detected at DEF position	
B263D	FRE DOOR FAIL	When the malfunctioning intake door position is detected at FRE position	<ul style="list-style-type: none"> Intake door motor A/C auto amp. Harness and connector (CAN communication line is open or shorted) (Intake door motor is open or shorted)
B263E	20P FRE DOOR FAIL	When the malfunctioning intake door position is detected at 20%FRE position	
B263F	REC DOOR FAIL	When the malfunctioning intake door position is detected at REC position	
B2654	D/F2 DOOR FAIL	When the malfunctioning door position is detected at D/F position	<ul style="list-style-type: none"> Mode door motor A/C auto amp. Harness and connector (CAN communication line is open or shorted) (Mode door motor is open or shorted)
B2655	B/L2 DOOR FAIL	When the malfunctioning door position is detected at B/L2 position	
B2661	UPPER VENT DOOR OPEN POSI FAIL	When the malfunctioning upper ventilator door position is detected at open position.	<ul style="list-style-type: none"> Upper ventilator door motor A/C auto amp. Harness and connector (CAN communication line is open or shorted) (Upper ventilator door motor is open or shorted)
B2662	UPPER VENT DOOR MID POSI FAIL	When the malfunctioning upper ventilator door position is detected at middle position.	
B2663	UPPER VENT DOOR SHUT POSI FAIL	When the malfunctioning upper ventilator door position is detected at shut position.	

*: Perform self-diagnosis under sunshine. When performing indoors, aim a light (more than 60 W) at sunload sensor, otherwise self-diagnosis indicates even though the sunload sensor is functioning normally.

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Display item list

Monitor item [Unit]	Description
COMP REQ SIG [On/Off]	Displays A/C switch ON/OFF status transmitted to other units via CAN communication
FAN REQ SIG [On/Off]	Displays blower switch ON/OFF status transmitted to other units via CAN communication
AMB TEMP SEN [°C]	Ambient sensor value converted from ambient sensor signal received from ambient sensor
IN-VEH TEMP [°C]	In-vehicle sensor value converted from in-vehicle sensor signal received from in-vehicle sensor

DIAGNOSIS SYSTEM (HVAC)

< SYSTEM DESCRIPTION >

[WITHOUT 7 INCH DISPLAY]

Monitor item [Unit]	Description
INT TEMP SEN [°C]	Intake sensor value converted from intake sensor signal received from intake sensor
SUNLOAD SEN [w/m ²]	Sunload sensor value converted from sunload sensor signal received from sunload sensor
AMB SEN CAL [°C]	Ambient sensor value calculated by A/C auto amp.
IN-VEH CAL [°C]	In-vehicle sensor value calculated by A/C auto amp.
INT TEMP CAL [°C]	Intake sensor value calculated by A/C auto amp.
SUNL SEN CAL [w/m ²]	Sunload sensor value calculated by A/C auto amp.
FAN DUTY	Duty ratio of blower motor judged by A/C auto amp.
XM	Target discharge air temperature judged by A/C auto amp. according to the temperature setting and the value from each sensor
ENG COOL TEMP [°C]	Water temperature signal value received from ECM via CAN communication
VEHICLE SPEED [Mph (km/h)]	Vehicle speed signal value received from meter via CAN communication

ACTIVE TEST

Test item	Description
ALL SEG	NOTE: <ul style="list-style-type: none"> Item can be displayed but cannot be tested. When choosing to turn "ALL SEG" on, error message is displayed but it is not malfunction.
HVAC TEST	The operation check of A/C system can be performed by selecting the mode. Refer to the following table for the conditions of each mode.

HVAC TEST

	Test item						
	MODE 1	MODE 2	MODE 3	MODE 4	MODE 5	MODE 6	MODE 7
Mode door position	VENT1	VENT2	B/L1	B/L2	FOOT	D/F	DEF
Intake door position	REC	REC	20%FRE	20%FRE	FRE	FRE	FRE
Air mix door position (driver & passenger side)	FULL COLD	FULL HOT	FULL COLD	FULL HOT	FULL HOT	FULL HOT	FULL HOT
Blower motor duty ratio	35%	35%	61%	61%	81%	81%	35%
Compressor (Magnet clutch)	ON	ON	ON	ON	OFF	OFF	ON
Upper ventilator door	OPEN	SHUT	OPEN	SHUT	SHUT	SHUT	SHUT

NOTE:

Perform the inspection of each output device after starting the engine because the compressor is operated.

WORK SUPPORT

Work item	Description	Reference
TEMP SET CORRECT (Setting of difference between temperature setting and control temperature)	If the temperature felt by the customer is different than the air flow temperature controlled by the temperature setting, the auto amplifier control temperature can be adjusted to compensate for the temperature setting.	HAC-10, "Temperature Setting Trimmer"
BLOW SET (Blow setting to DEF in FOOT mode)	In the FOOT mode, the air blowing to the DEF can change ON/OFF.	HAC-10, "Foot Position Setting Trimmer"

DIAGNOSIS SYSTEM (HVAC)

< SYSTEM DESCRIPTION >

[WITHOUT 7 INCH DISPLAY]

Work item	Description	Reference
<p>FRE MEMORY SET (FRE memory function setting)</p>	<ul style="list-style-type: none"> • If the ignition switch is turned to the OFF position while the FRE switch is set to ON (fresh air intake), "Perform the memory" or "Do not perform the memory" of the FRE switch ON (fresh air intake) condition can be selected. • If "Perform the memory" was set, the FRE switch will be ON (fresh air intake) when turning the ignition switch to the ON position again. • If "Do not perform the memory" was set, the air inlets will be controlled automatically when turning the ignition switch to the ON position again. 	<p>HAC-11. "Inlet Port Memory Function (FRE)"</p>
<p>REC MEMORY SET (REC memory function setting)</p>	<ul style="list-style-type: none"> • If the ignition switch is turned to the OFF position while the REC switch is set to ON (recirculation), "Perform the memory" or "Do not perform the memory" of the REC switch ON (recirculation) condition can be selected. • If "Perform the memory" was set, the REC switch will be ON (recirculation) when turning the ignition switch to the ON position again. • If "Do not perform the memory" was set, the air inlets will be controlled automatically when turning the ignition switch to the ON position again. 	<p>HAC-11. "Inlet Port Memory Function (REC)"</p>

NOTE:

When the battery cable is disconnected from the negative terminal or when the battery voltage becomes 10 V or less, the setting of WORK SUPPORT may be cancelled.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

DTC/CIRCUIT DIAGNOSIS

U1000 CAN COMM CIRCUIT

Description

INFOID:000000009722051

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with two communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Signal Chart. Refer to [LAN-17, "How to Use CAN Communication Signal Chart"](#).

DTC Logic

INFOID:000000009722052

DTC DETECTION LOGIC

DTC	Items (CONSULT screen terms)	Diagnostic item is detected when...	Possible cause
U1000	CAN COMM CIRCUIT	When A/C auto amp. is not transmitting or receiving CAN communication signal for 2 or more seconds.	CAN communication system

Diagnosis Procedure

INFOID:000000009722053

1. CHECK WITH SELF-DIAGNOSIS FUNCTION OF CONSULT

1. Turn ignition switch ON and wait for 2 or more seconds.
2. Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.

Is "CAN COMM CIRCUIT" displayed?

- YES >> Perform trouble diagnosis for the CAN communication system. Refer to [LAN-18, "Trouble Diagnosis Flow Chart"](#).
- NO >> Perform the intermittent malfunction diagnosis. Refer to [GI-44, "Intermittent Incident"](#).

U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT 7 INCH DISPLAY]

U1010 CONTROL UNIT (CAN)

Description

INFOID:000000009722054

Initial diagnosis of A/C auto amp.

DTC Logic

INFOID:000000009722055

DTC DETECTION LOGIC

DTC	Items (CONSULT screen terms)	Diagnostic item is detected when...	Possible cause
U1010	CONTROL UNIT (CAN)	When detecting error during the initial diagnosis of CAN controller of A/C auto amp.	A/C auto amp.

Diagnosis Procedure

INFOID:000000009722056

1. CHECK WITH SELF-DIAGNOSIS FUNCTION OF CONSULT

Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.

Is DTC No. "U1010" displayed?

YES >> Replace A/C auto amp.

NO >> INSPECTION END

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

B257B, B257C AMBIENT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT 7 INCH DISPLAY]

B257B, B257C AMBIENT SENSOR


Description

INFOID:000000009722057


COMPONENT DESCRIPTION

Ambient Sensor

- The ambient sensor (1) is installed to the front bumper (left back).
- It detects ambient temperature and converts it into a resistance value which is then input into the A/C auto amp.



Ambient Sensor Circuit



AMBIENT TEMPERATURE INPUT PROCESS

The A/C auto amp. equips a processing circuit for the ambient sensor input. However, when the temperature detected by the ambient sensor increases quickly, the processing circuit retards the A/C auto amp. function. It only allows the A/C auto amp. to recognize an ambient temperature increase of 0.33°C (0.6°F) per 100 seconds.

As an example, consider stopping for a few minutes after high speed driving. Although the actual ambient temperature has not changed, the temperature detected by the ambient sensor increases. This is because the heat from the engine compartment can radiate to the front bumper area, the location of the ambient sensor.

DTC Logic

INFOID:000000009722058

DTC DETECTION LOGIC

NOTE:

- If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-44, "DTC Logic"](#) or [HAC-45, "DTC Logic"](#).
- If there is an open circuit in the ambient sensor, A/C auto amp. registers extreme cold [-44°C (-47°F)] and adjusts the temperature control warmer.

DTC	Items (CONSULT screen terms)	Diagnostic item is detected when...	Possible cause
B257B	AMBIENT SENSOR	Detected temperature at ambient sensor -44°C (-47°F) or less	<ul style="list-style-type: none"> • Ambient sensor • A/C auto amp. • Harness and connector (Ambient sensor circuit is open, or there is a short in the circuit)
B257C		Detected temperature at ambient sensor 100°C (212°F) or more	

DTC CONFIRMATION PROCEDURE

1. CHECK WITH SELF-DIAGNOSIS FUNCTION OF CONSULT

B257B, B257C AMBIENT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT 7 INCH DISPLAY]

1. Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
2. Check if any DTC No. is displayed in the self-diagnosis results.

NOTE:

- If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-44, "DTC Logic"](#) or [HAC-45, "DTC Logic"](#).
- If there is an open circuit in the ambient sensor, A/C auto amp. registers extreme cold [-44°C (-47°F)] and adjusts the temperature control warmer.

Is DTC No. "B257B" or "B257C" displayed?

- YES >> Perform trouble diagnosis for the ambient sensor. Refer to [HAC-47, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009722059

1. CHECK VOLTAGE BETWEEN AMBIENT SENSOR AND GROUND

1. Disconnect ambient sensor connector.
2. Turn ignition switch ON.
3. Check voltage between ambient sensor harness connector and ground.

(+)		(-)	Voltage
Ambient sensor		—	
Connector	Terminal		
E337	1	Ground	Approx. 5 V

Is the inspection result normal?

- YES >> GO TO 2.
NO >> GO TO 4.

2. CHECK CIRCUIT CONTINUITY BETWEEN AMBIENT SENSOR AND A/C AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect A/C auto amp. connector.
3. Check continuity between ambient sensor harness connector and A/C auto amp. harness connector.

Ambient sensor		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
E337	2	M50	37	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair harness or connector.

3. CHECK AMBIENT SENSOR

Check ambient sensor. Refer to [HAC-48, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace A/C auto amp.
NO >> Replace ambient sensor.

4. CHECK CIRCUIT CONTINUITY BETWEEN AMBIENT SENSOR AND A/C AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect A/C auto amp. connector.
3. Check continuity between ambient sensor harness connector and A/C auto amp. harness connector.

Ambient sensor		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
E337	1	M50	35	Existed

4. Check continuity between ambient sensor harness connector and ground.

B257B, B257C AMBIENT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT 7 INCH DISPLAY]

Ambient sensor		—	Continuity
Connector	Terminal		
E337	1	Ground	Not existed

Is the inspection result normal?

YES >> Replace A/C auto amp.

NO >> Repair harness or connector.

Component Inspection

INFOID:000000009722060

1. CHECK AMBIENT SENSOR

1. Turn ignition switch OFF.
2. Disconnect ambient sensor connector. Refer to [VTL-26. "Exploded View"](#).
3. Check resistance between ambient sensor terminals.

Terminal		Condition	Resistance kΩ
		Temperature °C (°F)	
1	2	-15 (5)	12.73
		-10 (14)	9.92
		-5 (23)	7.80
		0 (32)	6.19
		5 (41)	4.95
		10 (50)	3.99
		15 (59)	3.24
		20 (68)	2.65
		25 (77)	2.19
		30 (86)	1.81
		35 (95)	1.51
		40 (104)	1.27
45 (113)	1.07		

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace ambient sensor.

B2578, B2579 IN-VEHICLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT 7 INCH DISPLAY]


B2578, B2579 IN-VEHICLE SENSOR

Description


INFOID:000000009722061

In-vehicle Sensor

- The in-vehicle sensor (1) is located on instrument driver lower panel (2).
- It converts variations in compartment air temperature drawn from the aspirator into a resistance value. It is then input into the A/C auto amp.





In-vehicle Sensor Circuit



Aspirator

The aspirator (1) is located on driver side of heater & cooling unit assembly. It produces vacuum pressure due to air discharged from the heater & cooling unit assembly, continuously taking compartment air in the aspirator.



DTC Logic

INFOID:000000009722062

DTC DETECTION LOGIC

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

B2578, B2579 IN-VEHICLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT 7 INCH DISPLAY]

NOTE:

If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-44, "DTC Logic"](#) or [HAC-45, "DTC Logic"](#).

DTC	Items (CONSULT screen terms)	Diagnostic item is detected when...	Possible cause
B2578	IN-VEHICLE SENSOR	Detected temperature at in-vehicle sensor -44°C (-47°F) or less	<ul style="list-style-type: none">• In-vehicle sensor• A/C auto amp.• Harness and connector (In-vehicle sensor circuit is open, or there is a short in the circuit)
B2579		Detected temperature at in-vehicle sensor 100°C (212°F) or more	

DTC CONFIRMATION PROCEDURE

1. CHECK WITH SELF-DIAGNOSIS FUNCTION OF CONSULT

1. Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
2. Check if any DTC No. is displayed in the self-diagnosis results.

NOTE:

If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-44, "DTC Logic"](#) or [HAC-45, "DTC Logic"](#).

Is DTC No. "B2578" or "B2579" displayed?

- YES >> Perform trouble diagnosis for the in-vehicle sensor. Refer to [HAC-50, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009722063

1. CHECK VOLTAGE BETWEEN IN-VEHICLE SENSOR AND GROUND

1. Disconnect in-vehicle sensor connector.
2. Turn ignition switch ON.
3. Check voltage between in-vehicle sensor harness connector and ground.

(+)		(-)	Voltage
Connector	Terminal		
M41	1	Ground	Approx. 5 V

Is the inspection result normal?

- YES >> GO TO 2.
NO >> GO TO 4.

2. CHECK CIRCUIT CONTINUITY BETWEEN IN-VEHICLE SENSOR AND A/C AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect A/C auto amp. connector.
3. Check continuity between in-vehicle sensor harness connector and A/C auto amp. harness connector.

In-vehicle sensor		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M41	2	M50	37	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair harness or connector.

3. CHECK IN-VEHICLE SENSOR

Check in-vehicle sensor. Refer to [HAC-51, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace A/C auto amp.

B2578, B2579 IN-VEHICLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT 7 INCH DISPLAY]

NO >> Replace in-vehicle sensor.

4.CHECK CIRCUIT CONTINUITY BETWEEN IN-VEHICLE SENSOR AND A/C AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect A/C auto amp. connector.
3. Check continuity between in-vehicle sensor harness connector and A/C auto amp. harness connector.

In-vehicle sensor		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M41	1	M50	36	Existed

4. Check continuity between in-vehicle sensor harness connector and ground.

In-vehicle sensor		—	Continuity
Connector	Terminal		
M41	1	Ground	Not existed

Is the inspection result normal?

YES >> Replace A/C auto amp.

NO >> Repair harness or connector.

Component Inspection

INFOID:000000009722064

1.CHECK IN-VEHICLE SENSOR

1. Turn ignition switch OFF.
2. Disconnect in-vehicle sensor connector. Refer to [VTL-27. "Exploded View"](#).
3. Check resistance between in-vehicle sensor terminals.

Terminal		Condition	Resistance kΩ
		Temperature °C (°F)	
1	2	-15 (5)	12.73
		-10 (14)	9.92
		-5 (23)	7.80
		0 (32)	6.19
		5 (41)	4.95
		10 (50)	3.99
		15 (59)	3.24
		20 (68)	2.65
		25 (77)	2.19
		30 (86)	1.81
		35 (95)	1.51
		40 (104)	1.27
45 (113)	1.07		

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace in-vehicle sensor.

B2581, B2582 INTAKE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT 7 INCH DISPLAY]


B2581, B2582 INTAKE SENSOR

Description


INFOID:000000009722065

Intake Sensor

- The intake sensor (1) is located on the evaporator (2).
- It converts air temperature after it passes through the evaporator into a resistance value which is then input to the A/C auto amp.



Intake Sensor Circuit



DTC Logic

INFOID:000000009722066

DTC DETECTION LOGIC

NOTE:

If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-44, "DTC Logic"](#) or [HAC-45, "DTC Logic"](#).

DTC	Items (CONSULT screen terms)	Diagnostic item is detected when...	Possible cause
B2581	INTAKE SENSOR	Detected temperature at intake sensor -33°C (-27°F) or less	<ul style="list-style-type: none"> • Intake sensor • A/C auto amp. • Harness and connector (Intake sensor circuit is open, or there is a short in the circuit)
B2582		Detected temperature at intake sensor 69°C (156°F) or more	

DTC CONFIRMATION PROCEDURE

1. CHECK WITH SELF-DIAGNOSIS FUNCTION OF CONSULT

1. Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
2. Check if any DTC No. is displayed in the self-diagnosis results.

NOTE:

If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-44, "DTC Logic"](#) or [HAC-45, "DTC Logic"](#).

Is DTC No. "B2581" or "B2582" displayed?

YES >> Perform trouble diagnosis for the intake sensor. Refer to [HAC-52, "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009722067

1. CHECK VOLTAGE BETWEEN INTAKE SENSOR AND GROUND

B2581, B2582 INTAKE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT 7 INCH DISPLAY]

1. Disconnect intake sensor connector.
2. Turn ignition switch ON.
3. Check voltage between intake sensor harness connector and ground.

(+)		(-)	Voltage
Intake sensor		—	
Connector	Terminal		
M42	1	Ground	Approx. 5 V

Is the inspection result normal?

- YES >> GO TO 2.
NO >> GO TO 4.

2.CHECK CIRCUIT CONTINUITY BETWEEN INTAKE SENSOR AND A/C AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect A/C auto amp. connector.
3. Check continuity between intake sensor harness connector and A/C auto amp. harness connector.

Intake sensor		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M42	2	M50	37	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair harness or connector.

3.CHECK INTAKE SENSOR

Check intake sensor. Refer to [HAC-53, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace A/C auto amp.
NO >> Replace intake sensor.

4.CHECK CIRCUIT CONTINUITY BETWEEN INTAKE SENSOR AND A/C AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect A/C auto amp. connector.
3. Check continuity between intake sensor harness connector and A/C auto amp. harness connector.

Intake sensor		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M42	1	M50	16	Existed

4. Check continuity between intake sensor harness connector and ground.

Intake sensor		(-)	Continuity
Connector	Terminal		
M42	1	Ground	Not existed

Is the inspection result normal?

- YES >> Replace A/C auto amp.
NO >> Repair harness or connector.

Component Inspection

INFOID:000000009722068

1.CHECK INTAKE SENSOR

1. Turn ignition switch OFF.
2. Disconnect intake sensor connector.
3. Check resistance between intake sensor terminals.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

B2581, B2582 INTAKE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT 7 INCH DISPLAY]

Terminal		Condition	Resistance kΩ
		Temperature °C (°F)	
1	2	-15 (5)	18.63
		-10 (14)	14.15
		-5 (23)	10.86
		0 (32)	8.41
		5 (41)	6.58
		10 (50)	5.19
		15 (59)	4.12
		20 (68)	3.30
		25 (77)	2.67
		30 (86)	2.17
		35 (95)	1.78
		40 (104)	1.46
		45 (113)	1.21

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace intake sensor.

B2630, B2631 SUNLOAD SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT 7 INCH DISPLAY]

B2630, B2631 SUNLOAD SENSOR


Description

INFOID:000000009722069


COMPONENT DESCRIPTION

Sunload Sensor

- The sunload sensor (1) is located on the driver's side instrument panel & pad.
- It detects sunload entering through windshield by means of a photo diode. The sensor converts the sunload into a current value which is then input into the A/C auto amp.



Sunload Sensor Circuit



SUNLOAD INPUT PROCESS

The A/C auto amp. also equips a processing circuit which averages the variations in detected sunload over a period of time. This prevents drastic swings in the air temperature control system operation due to small or quick variations in detected sunload.

For example, consider driving along a road bordered by an occasional group of large trees. The sunload detected by the sunload sensor varies whenever the trees obstruct the sunlight. The processing circuit averages the detected sunload over a period of time, so that the (insignificant) effect of the trees momentarily obstructing the sunlight does not cause any change in the air temperature control system operation. On the other hand, shortly after entering a long tunnel, the system recognizes the change in sunload, and the system reacts accordingly.

DTC Logic

INFOID:000000009722070

DTC DETECTION LOGIC

NOTE:

- If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-44. "DTC Logic"](#) or [HAC-45. "DTC Logic"](#).
- Sunload sensor may register a malfunction when indoors, at dusk, or at other times when light is insufficient. When performing the diagnosis indoors, light the sunload sensor with a lamp (60W or more).

DTC	Items (CONSULT screen terms)	Diagnostic item is detected when...	Possible cause
B2630	SUNLOAD SENSOR	Detected calorie at sunload sensor 64.7 w/m ² (56 kcal/m ² ·h) or less	<ul style="list-style-type: none"> • Sunload sensor • A/C auto amp. • Harness and connector (Sunload sensor circuit is open, or there is a short in the circuit)
B2631		Detected calorie at sunload sensor 2832 w/m ² (2436 kcal/m ² ·h) or more	

B2630, B2631 SUNLOAD SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT 7 INCH DISPLAY]

DTC CONFIRMATION PROCEDURE

1. CHECK WITH SELF-DIAGNOSIS FUNCTION OF CONSULT

1. Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
2. Check if any DTC No. is displayed in the self-diagnosis results.

NOTE:

- If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-44, "DTC Logic"](#) or [HAC-45, "DTC Logic"](#).
- Sunload sensor may register a malfunction when indoors, at dusk, or at other times when light is insufficient. When performing the diagnosis indoors, light the sunload sensor with a lamp (60W or more).

Is DTC No. "B2630" or "B2631" displayed?

- YES >> Perform trouble diagnosis for the sunload sensor. Refer to [HAC-56, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009722071

1. CHECK VOLTAGE BETWEEN SUNLOAD SENSOR AND GROUND

1. Disconnect sunload sensor connector.
2. Turn ignition switch ON.
3. Check voltage between sunload sensor harness connector and ground.

(+)		(-)	Voltage
Sunload sensor		—	
Connector	Terminal		
M74	1	Ground	Approx. 5 V

Is the inspection result normal?

- YES >> GO TO 2.
NO >> GO TO 4.

2. CHECK CIRCUIT CONTINUITY BETWEEN SUNLOAD SENSOR AND A/C AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect A/C auto amp. connector.
3. Check continuity between sunload sensor harness connector and A/C auto amp. harness connector.

Sunload sensor		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M74	2	M50	37	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair harness or connector.

3. CHECK SUNLOAD SENSOR

1. Reconnect sunload sensor connector and A/C auto amp. connector.
2. Check sunload sensor. Refer to [HAC-57, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace A/C auto amp.
NO >> Replace sunload sensor.

4. CHECK CIRCUIT CONTINUITY BETWEEN SUNLOAD SENSOR AND A/C AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect A/C auto amp. connector.
3. Check continuity between sunload sensor harness connector and A/C auto amp. harness connector.

B2630, B2631 SUNLOAD SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT 7 INCH DISPLAY]

Sunload sensor		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M74	1	M50	15	Existed

4. Check continuity between sunload sensor harness connector and ground.

Sunload sensor		—	Continuity
Connector	Terminal		
M74	1	Ground	Not existed

Is the inspection result normal?

YES >> Replace A/C auto amp.

NO >> Repair harness or connector.


Component Inspection

INFOID:000000009722072

1. CHECK SUNLOAD SENSOR

1. Turn ignition switch ON.
2. Check voltage between A/C auto amp. harness connector and ground.

(+) A/C auto amp.		(-)
Connector	Terminal	—
M50	15	Ground



NOTE:

Select a place where sunshine directly on it when checking sunload sensor.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace sunload sensor.

B2632, B2633 AIR MIX DOOR MOTOR (DRIVER SIDE)

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT 7 INCH DISPLAY]

B2632, B2633 AIR MIX DOOR MOTOR (DRIVER SIDE)

Description

INFOID:000000009722073


COMPONENT DESCRIPTION

Air Mix Door Motor (Driver Side)

- The air mix door motor (driver side) (1) are attached to the heater & cooling unit assembly.

←: Vehicle front

- It rotates so that the air mix door is opened or closed to a position set by the A/C auto amp.
- Motor rotation is then conveyed through a shaft and the air mix door position feedback is then sent to the A/C auto amp. by PBR built-in air mix door motor.



DTC Logic

INFOID:000000009722074

DTC DETECTION LOGIC

NOTE:

If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-44. "DTC Logic"](#) or [HAC-45. "DTC Logic"](#).

DTC	Items (CONSULT screen terms)	Diagnostic item is detected when...	Possible cause
B2632	DR AIR MIX DOOR MOT	Air mix door PBR (driver side) position 95% or less	<ul style="list-style-type: none">• Air mix door motor (PBR internal circuit is open or shorted)• A/C auto amp.• Harness and connector (LAN communication line is open or shorted)
B2633		Air mix door PBR (driver side) position 5% or more	

DTC CONFIRMATION PROCEDURE

1. CHECK WITH SELF-DIAGNOSIS FUNCTION OF CONSULT

1. Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
2. Check if any DTC No. is displayed in the self-diagnosis results.

NOTE:

If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-44. "DTC Logic"](#) or [HAC-45. "DTC Logic"](#).

Is DTC No. "B2632" or "B2633" displayed?

YES >> Perform trouble diagnosis for the air mix door motor (driver side). Refer to [HAC-59. "Diagnosis Procedure"](#).

NO >> GO TO 2.

2. FUNCTION INSPECTION

1. Press temperature control "UP" switch (driver side) until 32°C (90°F) is displayed.
2. Check for warm air at discharge air outlets.
3. Operate the compressor.
4. Press temperature control "DOWN" switch (driver side) until 18°C (60°F) is displayed.
5. Check for cool air at air discharge outlets.

Does it operate normally?

YES >> INSPECTION END

NO >> Check air mix door motor (driver side) installation, and repair or replace the malfunctioning parts.

B2632, B2633 AIR MIX DOOR MOTOR (DRIVER SIDE)

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT 7 INCH DISPLAY]

Diagnosis Procedure

INFOID:000000009722075

1. CHECK POWER SUPPLY FOR AIR MIX DOOR MOTOR (DRIVER SIDE)

Check voltage between air mix door motor (driver side) harness connector and ground.

(+)		(-)	Voltage
Air mix door motor (driver side)		—	
Connector	Terminal		
M306	1	Ground	Battery voltage


Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the harnesses or connectors.

2. CHECK SIGNAL FOR AIR MIX DOOR MOTOR (DRIVER SIDE)

Check the output waveform (LAN signal) between air mix door motor (driver side) harness connector and ground using an oscilloscope.

(+)		(-)	Voltage
Air mix door motor (driver side)		—	
Connector	Terminal		
M306	3	Ground	 SJIA1453J

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the harnesses or connectors.

3. CHECK AIR MIX DOOR MOTOR (DRIVER SIDE) GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect air mix door motor (driver side) connector.
3. Check continuity between air mix door motor (driver side) harness connector and ground.

Air mix door motor (driver side)		(-)	Continuity
Connector	Terminal	—	
M306	2	Ground	Existed

Is the inspection result normal?

YES >> Replace air mix door motor (driver side).

NO >> Repair harness or connector.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

B2634, B2635 AIR MIX DOOR MOTOR (PASSENGER SIDE)

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT 7 INCH DISPLAY]

B2634, B2635 AIR MIX DOOR MOTOR (PASSENGER SIDE)

Description

INFOID:000000009722076


COMPONENT DESCRIPTION

Air Mix Door Motor (Passenger Side)

- The air mix door motor (passenger side) (1) are attached to the heater & cooling unit assembly.

←: Vehicle front

- It rotates so that the air mix door is opened or closed to a position set by the A/C auto amp.
- Motor rotation is then conveyed through a shaft and the air mix door position feedback is then sent to the A/C auto amp. by PBR built-in air mix door motor.



DTC Logic

INFOID:000000009722077

DTC DETECTION LOGIC

NOTE:

If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-44. "DTC Logic"](#) or [HAC-45. "DTC Logic"](#).

DTC	Items (CONSULT screen terms)	Diagnostic item is detected when...	Possible cause
B2634	PASS AIR MIX DOOR MOT	Air mix door PBR (passenger side) position 95% or less	<ul style="list-style-type: none">• Air mix door motor (PBR internal circuit is open or shorted)• A/C auto amp.• Harness and connector (LAN communication line is open or shorted)
B2635		Air mix door PBR (passenger side) position 5% or more	

DTC CONFIRMATION PROCEDURE

1. CHECK WITH SELF-DIAGNOSIS FUNCTION OF CONSULT

1. Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
2. Check if any DTC No. is displayed in the self-diagnosis results.

NOTE:

If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-44. "DTC Logic"](#) or [HAC-45. "DTC Logic"](#).

Is DTC No. "B2634" or "B2635" displayed?

YES >> Perform trouble diagnosis for the air mix door motor (passenger side). Refer to [HAC-61. "Diagnosis Procedure"](#).

NO >> GO TO 2.

2. FUNCTION INSPECTION

1. Press temperature control "UP" switch (passenger side) until 32°C (90°F) is displayed.
2. Check for warm air at discharge air outlets.
3. Operate the compressor.
4. Press temperature control "DOWN" switch (passenger side) until 18°C (60°F) is displayed.
5. Check for cool air at air discharge outlets.

Does it operate normally?

YES >> INSPECTION END

NO >> Check air mix door motor (passenger side) installation, and repair or replace the malfunctioning parts.

B2634, B2635 AIR MIX DOOR MOTOR (PASSENGER SIDE)

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT 7 INCH DISPLAY]

Diagnosis Procedure

INFOID:000000009722078

1. CHECK POWER SUPPLY FOR AIR MIX DOOR MOTOR (PASSENGER SIDE)

Check voltage between air mix door motor (passenger side) harness connector and ground.

(+)		(-)	Voltage
Air mix door motor (passenger side)		—	
Connector	Terminal	Ground	Battery voltage
M307	1		


Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the harnesses or connectors.

2. CHECK SIGNAL FOR AIR MIX DOOR MOTOR (PASSENGER SIDE)

Check the output waveform (LAN signal) between air mix door motor (passenger side) harness connector and ground using an oscilloscope.

(+)		(-)	Voltage
Air mix door motor (passenger side)		—	
Connector	Terminal	Ground	 SJIA1453J
M307	3		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the harnesses or connectors.

3. CHECK AIR MIX DOOR MOTOR (PASSENGER SIDE) GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect air mix door motor (passenger side) connector.
3. Check continuity between air mix door motor (passenger side) harness connector and ground.

Air mix door motor (passenger side)		(-)	Continuity
Connector	Terminal	—	
M307	2	Ground	Existed

Is the inspection result normal?

YES >> Replace air mix door motor (passenger side).

NO >> Repair harness or connector.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

B2636, B2637, B2638, B2639, B2654, B2655 MODE DOOR MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT 7 INCH DISPLAY]

B2636, B2637, B2638, B2639, B2654, B2655 MODE DOOR MOTOR

Description


INFOID:000000009722079

COMPONENT DESCRIPTION

Mode Door Motor

- The mode door motor (1) are attached to the heater & cooling unit assembly.
- It rotates so that air is discharged from the outlet set by the A/C auto amp. Motor rotation is conveyed to a link which activates the mode door.

←: Vehicle front



DTC Logic

INFOID:000000009722080

DTC DETECTION LOGIC

NOTE:

If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-44, "DTC Logic"](#) or [HAC-45, "DTC Logic"](#).

DTC	Items (CONSULT screen terms)	Diagnostic item is detected when...	Possible cause
B2636	DR VENT DOOR FAIL	When the malfunctioning door position is detected at VENT position	<ul style="list-style-type: none">• Mode door motor (PBR internal circuit is open or shorted)• A/C auto amp.• Harness and connector (LAN communication line is open or shorted)
B2637	DR B/L DOOR FAIL	When the malfunctioning door position is detected at B/L position	
B2638	DR D/F1 DOOR FAIL	When the malfunctioning door position is detected at FOOT position	
B2639	DR DEF DOOR FAIL	When the malfunctioning door position is detected at DEF position	
B2654	D/F2 DOOR FAIL	When the malfunctioning door position is detected at D/F position	
B2655	B/L2 DOOR FAIL	When the malfunctioning door position is detected at B/L2 position	

DTC CONFIRMATION PROCEDURE

1. CHECK WITH SELF-DIAGNOSIS FUNCTION OF CONSULT

1. Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
2. Check if any DTC No. is displayed in the self-diagnosis results.

NOTE:

If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-44, "DTC Logic"](#) or [HAC-45, "DTC Logic"](#).

Is DTC No. "B2636", "B2637", "B2638", "B2639", "B2654" or "B2655" displayed?

- YES >> Perform trouble diagnosis for the mode door motor. Refer to [HAC-63, "Diagnosis Procedure"](#).
NO >> GO TO 2.

2. FUNCTION INSPECTION

1. Press MODE switch and DEF switch.
2. Each position indicator should change shape.

B2636, B2637, B2638, B2639, B2654, B2655 MODE DOOR MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT 7 INCH DISPLAY]

3. Confirm that air discharge comes out according to the air distribution table at below. Refer to [HAC-16](#). "[System Description](#)".

Discharge air flow							
Mode position indication	Condition	Air outlet/distribution					
		VENT			FOOT		DEF
		Front	Upper	Rear	Front	Rear	
	DUAL switch: OFF UPPER VENT switch : ON	81%	8%	11%	—	—	—
		41%	10%	17%	24%	8%	—
		12%	12%	16%	27%	10%	23%
		11%	11%	14%	25%	10%	29%
		11%	11%	12%	—	—	66%

JPIIA0509GB

Discharge air flow							
Mode position indication	Condition	Air outlet/distribution					
		VENT			FOOT		DEF
		Front	Upper	Rear	Front	Rear	
	DUAL switch: OFF UPPER VENT switch : OFF	88%	—	12%	—	—	—
		47%	—	18%	26%	9%	—
		13%	—	17%	33%	12%	25%
		12%	—	16%	28%	12%	32%
		11%	—	15%	—	—	74%

JPIIA0510GB

NOTE:

Confirm that the compressor clutch is engaged (Sound or visual inspection) and intake door position is at FRE when DEF () or D/F () is selected.

Does it operate normally?

YES >> INSPECTION END

NO >> Check mode door motor installation, and repair or replace the malfunctioning parts.

Diagnosis Procedure

INFOID:000000009722081

1. CHECK POWER SUPPLY FOR MODE DOOR MOTOR

Check voltage between mode door motor harness connector and ground.

(+)		(-)	Voltage
Mode door motor		—	
Connector	Terminal		
M310	1	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair harness or connector.


2. CHECK SIGNAL FOR MODE DOOR MOTOR

Confirm A/C LAN signal between mode door motor harness connector and ground using an oscilloscope.

B2636, B2637, B2638, B2639, B2654, B2655 MODE DOOR MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT 7 INCH DISPLAY]

(+)		(-)	Voltage
Mode door motor		—	
Connector	Terminal		
M310	3	Ground	

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3. CHECK MODE DOOR MOTOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect mode door motor connector.
3. Check continuity between mode door motor harness connector and ground.

Mode door motor		—	Continuity
Connector	Terminal		
M310	2	Ground	Existed

Is the inspection result normal?

YES >> Replace mode door motor.

NO >> Repair harness or connector.

B263D, B263E, B263F INTAKE DOOR MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT 7 INCH DISPLAY]

B263D, B263E, B263F INTAKE DOOR MOTOR

Description

INFOID:000000009722082


COMPONENT DESCRIPTION

Intake Door Motor

- The intake door motor (1) is attached to the blower unit.

←: Vehicle front

- It rotates so that air is drawn from inlets set by the A/C auto amp. Motor rotation is conveyed to a lever which activates the intake door.



JPIA0516ZZ

DTC Logic

INFOID:000000009722083

DTC DETECTION LOGIC

NOTE:

If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-44. "DTC Logic"](#) or [HAC-45. "DTC Logic"](#).

DTC	Items (CONSULT screen terms)	Diagnostic item is detected when...	Possible cause
B263D	FRE DOOR FAIL	When the malfunctioning intake door position is detected at FRE position	<ul style="list-style-type: none"> Intake door motor (PBR internal circuit is open or shorted) A/C auto amp. Harness and connector (LAN communication line is open or shorted)
B263E	20P FRE DOOR FAIL	When the malfunctioning intake door position is detected at 20%FRE position	
B263F	REC DOOR FAIL	When the malfunctioning intake door position is detected at REC position	

DTC CONFIRMATION PROCEDURE

1. CHECK WITH SELF-DIAGNOSIS FUNCTION OF CONSULT

- Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
- Check if any DTC No. is displayed in the self-diagnosis results.

NOTE:

If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-44. "DTC Logic"](#) or [HAC-45. "DTC Logic"](#).

Is DTC No. "B263D", "B263E" or "B263F" displayed?

- YES >> Perform trouble diagnosis for the intake door motor. Refer to [HAC-66. "Diagnosis Procedure"](#).
 NO >> GO TO 2.

2. FUNCTION INSPECTION

- Press intake switch.
- The intake switch indicator is turned ON. (REC position)
- Listen for intake door position change (Slight change of blower sound can be heard.).
- Press intake switch again.
- The intake switch indicator is turned OFF. (FRE position)
- Listen for intake door position change (Slight change of blower sound can be heard.).

Does it operate normally?

- YES >> INSPECTION END
 NO >> Check intake door motor installation, and repair or replace the malfunctioning parts.

B263D, B263E, B263F INTAKE DOOR MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT 7 INCH DISPLAY]

Diagnosis Procedure

INFOID:00000009722084

1. CHECK POWER SUPPLY FOR INTAKE DOOR MOTOR

Check voltage between intake door motor harness connector and ground.

(+)		(-)	Voltage
Intake door motor		—	
Connector	Terminal	Ground	Battery voltage
M304	1		


Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair harness or connector.

2. CHECK SIGNAL FOR INTAKE DOOR MOTOR

Confirm A/C LAN signal between intake door motor harness connector and ground using an oscilloscope.

(+)		(-)	Voltage
Intake door motor		—	
Connector	Terminal	Ground	
M304	3		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3. CHECK INTAKE DOOR MOTOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect intake door motor connector.
3. Check continuity between intake door motor harness connector and ground.

Intake door motor		(-)	Continuity
Intake door motor		—	
Connector	Terminal	Ground	Existed
M304	2		

Is the inspection result normal?

YES >> Replace intake door motor.

NO >> Repair harness or connector.

B2661, B2662, B2663 UPPER VENTILATOR DOOR MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT 7 INCH DISPLAY]

B2661, B2662, B2663 UPPER VENTILATOR DOOR MOTOR

Description

INFOID:000000009722085


COMPONENT DESCRIPTION

Upper Ventilator Door Motor

- The upper ventilator door motor (1) are attached to the heater & cooling unit assembly.

←: Vehicle front

- Upper ventilator door motor operates by UPPER VENT switch ON/OFF when the DEF switch is OFF.
- Motor rotation is conveyed to a link which activates the upper ventilator door.



JPIA0514ZZ

DTC Logic

INFOID:000000009722086

DTC DETECTION LOGIC

NOTE:

If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-44, "DTC Logic"](#) or [HAC-45, "DTC Logic"](#).

DTC	Items (CONSULT screen terms)	Diagnostic item is detected when...	Possible cause
B2661	UPPER VENT DOOR MOT	When the malfunctioning upper ventilator door position is detected at open position.	<ul style="list-style-type: none"> Upper ventilator door motor (PBR internal circuit is open or shorted) A/C auto amp. Harness and connector (LAN communication line is open or shorted)
B2662		When the malfunctioning upper ventilator door position is detected at middle position.	
B2663		When the malfunctioning upper ventilator door position is detected at shut position.	

DTC CONFIRMATION PROCEDURE

1. CHECK WITH SELF-DIAGNOSIS FUNCTION OF CONSULT

- Using CONSULT perform "SELF-DIAGNOSIS RESULTS" of HVAC.
- Check if any DTC No. is displayed in the self-diagnosis results.

NOTE:

If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-44, "DTC Logic"](#) or [HAC-45, "DTC Logic"](#).

Is DTC No. "B2661", "B2662" or "B2663" displayed?

YES >> Perform trouble diagnosis for the upper ventilator door motor. Refer to [HAC-68, "Diagnosis Procedure"](#).

NO >> GO TO 2.

2. FUNCTION INSPECTION

- Press the UPPER VENT switch.
- The UPPER VENT switch indicator is turned ON.

B2661, B2662, B2663 UPPER VENTILATOR DOOR MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT 7 INCH DISPLAY]

3. Check that the air blown from UPPER VENT does not greatly deviate from the air mix ratio.

Discharge air flow							
Mode position indication	Condition	Air outlet/distribution					
		VENT			FOOT		DEF
		Front	Upper	Rear	Front	Rear	
	DUAL switch: OFF UPPER VENT switch : ON	81%	8%	11%	—	—	—
		41%	10%	17%	24%	8%	—
		12%	12%	16%	27%	10%	23%
		11%	11%	14%	25%	10%	29%
		11%	11%	12%	—	—	66%

JPIIA0509GB

4. Press the UPPER VENT switch again.
5. The UPPER VENT switch indicator is turned OFF.
6. The air blown from UPPER VENT stops.

Does it operate normally?

YES >> INSPECTION END

NO >> Check upper ventilator door motor installation, and repair or replace the malfunctioning parts.

Diagnosis Procedure

INFOID:000000009722087

1. CHECK POWER SUPPLY FOR UPPER VENTILATOR DOOR MOTOR

Check voltage between upper ventilator door motor harness connector and ground.

(+)		(-)	Voltage
Upper ventilator door motor		—	
Connector	Terminal		
M308	1	Ground	Battery voltage


Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair harness or connector.

2. CHECK SIGNAL FOR UPPER VENTILATOR DOOR MOTOR

Confirm A/C LAN signal between upper ventilator door motor harness connector and ground using an oscilloscope.

(+)		(-)	Voltage
Upper ventilator door motor		—	
Connector	Terminal		
M308	3	Ground	

SJIA1453J

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

B2661, B2662, B2663 UPPER VENTILATOR DOOR MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT 7 INCH DISPLAY]

3. CHECK UPPER VENTILATOR DOOR MOTOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect upper ventilator door motor connector.
3. Check continuity between upper ventilator door motor harness connector and ground.

Upper ventilator door motor		—	Continuity
Connector	Terminal		
M308	2	Ground	Existed

Is the inspection result normal?

- YES >> Replace upper ventilator door motor.
NO >> Repair harness or connector.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

BLOWER MOTOR


Description

INFOID:000000009722088


COMPONENT DESCRIPTION

Brush-less Motor

The blower motor utilizes a brush-less motor with a rotating magnet. Quietness is improved over previous motors where the brush was the point of contact and the coil rotated.



Blower Motor Circuit



Component Function Check

INFOID:000000009722089

1. CHECK OPERATION

1. Warm up the engine.
2. Operate the fan control dial. Check that the fan speed and indicator are switched for all fan speeds.

Does it operate normally?

YES >> INSPECTION END

NO >> Perform trouble diagnosis for the blower motor. Refer to [HAC-70, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009722090

1. CHECK WITH SELF-DIAGNOSIS FUNCTION OF CONSULT

1. Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
2. Check if any DTC No. is displayed in the self-diagnosis results.

NOTE:

If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-44, "DTC Logic"](#) or [HAC-45, "DTC Logic"](#).

Is any DTC No. displayed?

YES >> Perform the diagnosis that is applicable to the sensor and actuator. Refer to [HAC-106, "DTC Index"](#).

NO >> GO TO 2.

2. CHECK WITH ACTIVE TEST OF CONSULT

1. Using CONSULT, perform "HVAC TEST" "ACTIVE TEST" of HVAC to check each output device. Refer to [HAC-40, "CONSULT Function"](#).

NOTE:

Perform the ACTIVE TEST after starting the engine because the compressor is operated.

BLOWER MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT 7 INCH DISPLAY]

- Check that the blower motor control signal changes according to each indicator signal.

	Test item						
	MODE 1	MODE 2	MODE 3	MODE 4	MODE 5	MODE 6	MODE 7
Mode door position	VENT1	VENT2	B/L1	B/L2	FOOT	D/F	DEF
Intake door position	REC	REC	20%FRE	20%FRE	FRE	FRE	FRE
Air mix door position (driver & passenger side)	FULL COLD	FULL HOT	FULL COLD	FULL HOT	FULL HOT	FULL HOT	FULL HOT
Blower motor duty ratio	35%	35%	61%	61%	81%	81%	35%
Compressor (Magnet clutch)	ON	ON	ON	ON	OFF	OFF	ON
Upper ventilator door	OPEN	SHUT	OPEN	SHUT	SHUT	SHUT	SHUT

NOTE:

Perform the inspection of each output device after starting the engine because the compressor is operated.

Does it operate normally?

YES >> INSPECTION END

NO >> GO TO 3.

3.CHECK POWER SUPPLY FOR BLOWER MOTOR

- Disconnect blower motor connector.
- Turn ignition switch ON.
- Check voltage between blower motor harness connector and ground.

(+)		(-)	Voltage
Blower motor		—	
Connector	Terminal		
M98	1	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 7.

4.CHECK BLOWER MOTOR GROUND CIRCUIT

- Turn ignition switch OFF.
- Check continuity between blower motor harness connector and ground.

Blower motor		—	Continuity
Connector	Terminal		
M98	3	Ground	Existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair harness or connector.

5.CHECK BLOWER MOTOR CIRCUIT CONTINUITY

- Disconnect A/C auto amp. connector.
- Check continuity between blower motor harness connector and A/C auto amp. harness connector.

Blower motor		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M98	2	M50	32	Existed

Is the inspection result normal?

YES >> GO TO 6.

BLOWER MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT 7 INCH DISPLAY]

NO >> Repair harness or connector.

6. CHECK A/C AUTO AMP. OUTPUT SIGNAL

1. Reconnect blower motor connector and A/C auto amp. connector.
2. Turn ignition switch ON.
3. Set MODE switch to the VENT position.
4. Check the output waveform between blower motor harness connector and ground using an oscilloscope, while varying the fan speed from 1 to 7.

Blower fan speed (Manual) VENT mode	1st	2nd	3rd	4th	5th	6th	7th
Blower motor connector M 98 terminal No. 2 (Oscilloscope)							
	Approx. 1.6 ms	Approx. 1.6 ms	Approx. 1.6 ms	Approx. 1.6 ms	Approx. 1.6 ms	Approx. 1.6 ms	Approx. 1.6 ms
Duty ratio	Approx. 25%	Approx. 33%	Approx. 41%	Approx. 51%	Approx. 61%	Approx. 71%	Approx. 81%

NOTE: Duty ratio = $\frac{T_x}{\text{Approx. } 1.6 \text{ ms}} \times 100 (\%)$

JPIIA0616GB

Is the inspection result normal?

- YES >> Replace the blower motor.
 NO >> Replace the A/C auto amp.

7. CHECK POWER VOLTAGE OF BLOWER RELAY

1. Turn the ignition switch OFF.
2. Remove the blower relay. Refer to [PG-91, "Fuse, Connector and Terminal Arrangement"](#).
3. Turn the ignition switch ON.
4. Check the voltage between blower relay fuse block side terminal and ground. Refer to [PG-91, "Fuse, Connector and Terminal Arrangement"](#) for relay terminal assignment.

(+)	(-)	Voltage
Blower relay	—	
1	Ground	Battery voltage
3		

Is the inspection result normal?

- YES >> GO TO 8.
 NO >> Inspection the power supply circuit. Refer to [PG-47, "Wiring Diagram - IGNITION POWER SUPPLY -"](#).

8. CHECK BLOWER RELAY

1. Turn the ignition switch OFF.
2. Install the blower relay. Refer to [PG-91, "Fuse, Connector and Terminal Arrangement"](#).
3. Turn the ignition switch ON.
4. Check the operating sound of blower relay.

Is the inspection result normal?

- YES >> GO TO 9.
 NO >> Replace the blower relay.

9. CHECK FUSE

Check 15A fuses (Nos. 21 and 22).

NOTE:

BLOWER MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT 7 INCH DISPLAY]

Refer to [PG-91, "Fuse, Connector and Terminal Arrangement"](#) for fuse location.

Is the inspection result normal?

YES >> Repair the harnesses or connectors.

NO >> Replace the fuse after repairing the applicable circuit.

Component Inspection

INFOID:000000009722091

1. CHECK BLOWER MOTOR

1. Remove the blower motor. Refer to [VTL-33, "Exploded View"](#).

2. Check that the blower motor rotates smoothly.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace blower motor.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

MAGNET CLUTCH

Description

INFOID:000000009722092

The magnet clutch drives the compressor, by an IPDM E/R signal.

Component Function Check

INFOID:000000009722093

1. FUNCTION INSPECTION

1. Press AUTO switch.
2. "AUTO" is indicated on the display.
3. Press the A/C switch.
4. Check that the indicator of the A/C switch turns on. Check visually and by sound that the compressor is operating (the discharge air temperature or fan speed varies depending on the ambient temperature, in-vehicle temperature, and temperature setting).
5. Press the A/C switch again.
6. Check that the indicator of the A/C switch turns OFF. Check visually and by sound that the compressor stops.

Does it operate normally?

YES >> INSPECTION END

NO >> Perform trouble diagnosis for the compressor. Refer to [HAC-74. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009722094

1. INSPECTION IN AUTO ACTIVE TEST MODE

Perform "AUTO ACTIVE TEST". Refer to [PCS-10. "Diagnosis Description"](#).

Does it operate normally?

YES >> GO TO 6.

NO >> GO TO 2.

2. CHECK MAGNET CLUTCH POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect compressor connector.
3. Perform auto active test of IPDM E/R. Refer to [PCS-10. "Diagnosis Description"](#).
4. When auto active test operation sequence is compressor (magnet clutch) operation, check voltage between compressor harness connector and ground.

+		-	Voltage
Compressor			
Connector	Terminal		
F18	1	Ground	0 V ⇔ Battery voltage

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 3.

3. CHECK FUSE

Check 10 A fuse (No. 49, located in IPDM E/R).

NOTE:

Refer to [PG-93. "Fuse, Connector and Terminal Arrangement"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.

4. CHECK MAGNET CLUTCH POWER SUPPLY CIRCUIT FOR OPEN

1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector and compressor harness connector.

MAGNET CLUTCH

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT 7 INCH DISPLAY]

IPDM E/R		Compressor		Continuity
Connector	Terminal	Connector	Terminal	
F12	48	F18	1	Existed

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-37, "Removal and Installation"](#).

NO >> Repair harness or connector.

5. CHECK MAGNET CLUTCH GROUND CIRCUIT FOR OPEN

Check continuity between compressor harness connector and ground.

Compressor		—	Continuity
Connector	Terminal		
F18	2	Ground	Existed

Is the inspection result normal?

YES >> Replace magnet clutch. Refer to [HA-38, "MAGNET CLUTCH : Removal and Installation"](#).

NO >> Repair harness or connector.

6. CHECK WITH SELF-DIAGNOSIS FUNCTION OF CONSULT

- Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
- Check if any DTC No. is displayed in the self-diagnosis results.

NOTE:

If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-44, "DTC Logic"](#) or [HAC-45, "DTC Logic"](#).

Is any DTC No. displayed?

YES >> Perform the diagnosis that is applicable to the sensor and actuator. Refer to [HAC-106, "DTC Index"](#).

NO >> GO TO 7.

7. CHECK A/C AUTO AMP. INPUT SIGNAL

Using CONSULT, check "On/Off" of "COMP REQ SIG" and "FAN REQ SIG" in "DATA MONITOR" of HVAC. Refer to [HAC-40, "CONSULT Function"](#).

A/C SWITCH ON : COMP REQ SIG On

A/C SWITCH OFF : COMP REQ SIG Off

FAN CONTROL DIAL ON : FAN REQ SIG On

FAN CONTROL DIAL OFF : FAN REQ SIG Off

Is the inspection result normal?

YES >> GO TO 8.

NO >> Replace A/C auto amp.

8. CHECK REFRIGERANT PRESSURE SENSOR

Check refrigerant pressure sensor. Refer to [EC-465, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace malfunctioning parts.

A/C CONTROL SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT 7 INCH DISPLAY]

A/C CONTROL SIGNAL CIRCUIT

Diagnosis Procedure

INFOID:00000009722095

1. CHECK WITH SELF-DIAGNOSIS FUNCTION OF CONSULT

1. Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
2. Check if any DTC No. is displayed in the self-diagnosis results.

NOTE:

If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-44, "DTC Logic"](#) or [HAC-45, "DTC Logic"](#).

Is any DTC No. displayed?

YES >> Perform the diagnosis that is applicable to the sensor and actuator. Refer to [HAC-106, "DTC Index"](#).

NO >> GO TO 2.

2. CHECK TX (A/C CONTROL → A/C AUTO AMP.) CIRCUIT CONTINUITY

1. Disconnect the A/C control and the A/C auto amp. connector.
2. Check continuity between A/C control harness connector and A/C auto amp. harness connector.

A/C control		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M95	4	M50	7	Existed

3. Check continuity between A/C control harness connector and ground.

A/C control		—	Continuity
Connector	Terminal		
M95	4	Ground	Not existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3. CHECK RX (A/C AUTO AMP. → A/C CONTROL) CIRCUIT CONTINUITY

1. Disconnect the A/C control and the A/C auto amp. connector.
2. Check continuity between A/C control harness connector and A/C auto amp. harness connector.

A/C control		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M95	3	M50	6	Existed

3. Check continuity between A/C control harness connector and ground.

A/C control		—	Continuity
Connector	Terminal		
M95	3	Ground	Not existed

Is the inspection result normal?

YES >> Perform trouble diagnosis for the A/C control. Refer to [HAC-78, "A/C CONTROL : Diagnosis Procedure"](#).

NO >> Repair harness or connector.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT 7 INCH DISPLAY]

POWER SUPPLY AND GROUND CIRCUIT

A/C AUTO AMP.

A/C AUTO AMP. : Description


INFOID:000000009722096

COMPONENT DESCRIPTION


A/C Auto Amp. (Air Conditioner Automatic Amplifier)

The A/C auto amp. (1) has a built-in microcomputer that processes information sent from various sensors needed for air conditioner operation. The air mix door motor(s), the mode door motor, the intake door motor, the upper ventilator door motor, the blower motor and the compressor are then controlled.

When the various switches and temperature control switch are operated, data is input to the A/C auto amp. from the A/C control.



Power Supply and Ground Circuit for A/C Auto Amp.



A/C AUTO AMP. : Component Function Check

INFOID:000000009722097

1. CHECK OPERATION

1. Press the AUTO switch, and then check that "AUTO" is shown on the display.
2. Operate the temperature control switch (driver side). Check that the fan speed or outlet changes. (The discharge air temperature or fan speed varies depending on the ambient temperature, in-vehicle temperature, and temperature setting.)

Does it operate normally?

YES >> INSPECTION END

NO >> Perform trouble diagnosis for the A/C system. Refer to [HAC-77. "A/C AUTO AMP. : Diagnosis Procedure"](#).

A/C AUTO AMP. : Diagnosis Procedure

INFOID:000000009722098

1. CHECK A/C AUTO AMP. POWER SUPPLY CIRCUIT

1. Disconnect the A/C auto amp. connector.
2. Check voltage between A/C auto amp. harness connector and ground.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT 7 INCH DISPLAY]

(+)		(-)	Voltage		
A/C auto amp.		—	Ignition switch position		
Connector	Terminal		OFF	ACC	ON
M50	17	Ground	Approx. 0 V	Battery voltage	Battery voltage
	20		Approx. 0 V	Approx. 0 V	Battery voltage
	40		Battery voltage	Battery voltage	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2.CHECK FUSE

Check 10A fuses [Nos. 3, 6 and 19, located in the fuse block (J/B)].

NOTE:

Refer to [PG-91, "Fuse, Connector and Terminal Arrangement"](#).

Is the inspection result normal?

- YES >> Repair the harnesses or connectors.
NO >> Replace the fuse after repairing the applicable circuit.

3.CHECK A/C AUTO AMP. CIRCUIT CONTINUITY

1. Turn ignition switch OFF.
2. Check continuity between A/C auto amp. harness connector and ground.

A/C auto amp.		(-)	Continuity
Connector	Terminal	—	Existed
M50	19		
	39		

Is the inspection result normal?

- YES >> Replace the A/C auto amp.
NO >> Repair the harnesses or connectors.

A/C CONTROL

A/C CONTROL : Diagnosis Procedure

INFOID:000000009722099

1.CHECK A/C CONTROL POWER SUPPLY CIRCUIT

1. Disconnect the A/C control connector.
2. Turn ignition switch ON.
3. Check voltage between A/C control harness connector and ground.

(+)		(-)	Voltage
A/C control		—	Battery voltage
Connector	Terminal		
M95	1	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the harnesses or connectors.

2.CHECK A/C CONTROL CIRCUIT CONTINUITY

1. Turn ignition switch OFF.
2. Check continuity between A/C control harness connector and ground.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT 7 INCH DISPLAY]

A/C control		—	Continuity
Connector	Terminal		
M95	2	Ground	Existed

Is the inspection result normal?

YES >> Replace the A/C control.

NO >> Repair the harnesses or connectors.

A/C DISPLAY

A/C DISPLAY : Diagnosis Procedure

INFOID:000000009722100

1. CHECK A/C DISPLAY POWER SUPPLY CIRCUIT

1. Disconnect the A/C display connector.
2. Turn ignition switch ON.
3. Check voltage between A/C display harness connector and ground.

(+)		(-)	Voltage
A/C display		—	
Connector	Terminal		
M16	6	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the harnesses or connectors.

2. CHECK A/C DISPLAY CIRCUIT CONTINUITY

1. Turn ignition switch OFF.
2. Check continuity between A/C display harness connector and ground.

A/C display		—	Continuity
Connector	Terminal		
M16	1	Ground	Existed

Is the inspection result normal?

YES >> Replace the A/C display.

NO >> Repair the harnesses or connectors.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

ECU DIAGNOSIS INFORMATION

ECM

Reference Value

INFOID:000000009722101

VALUES ON THE DIAGNOSIS TOOL

NOTE:

- The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.
- Numerical values in the following table are reference values.
- These values are input/output values that ECM receives/transmits and may differ from actual operations.

Example:

The ignition timing shown by the timing light may differ from the ignition timing displayed on the data monitor.

This occurs because the timing light shows a value calculated by ECM according to signals received from the cam shaft position sensor and other sensors related to ignition timing.

For outlines of following items, refer to [EC-129, "CONSULT Function"](#).

Monitor Item	Condition		Values/Status
ENG SPEED	Run engine and compare CONSULT value with the tachometer indication.		Almost the same speed as the tachometer indication.
MAS A/F SE-B1	See EC-140, "Description" .		
B/FUEL SCHDL	See EC-140, "Description" .		
A/F ALPHA-B1	See EC-140, "Description" .		
A/F ALPHA-B2	See EC-140, "Description" .		
COOLANT TEMP/S	• Engine: After warming up		More than 70°C (158°F)
A/F SEN1 (B1)	• Engine: After warming up	Maintaining engine speed at 2,000 rpm	Fluctuates around 2.2 V
A/F SEN1 (B2)	• Engine: After warming up	Maintaining engine speed at 2,000 rpm	Fluctuates around 2.2 V
HO2S2 (B1)	<ul style="list-style-type: none"> • Revving engine from idle to 3,000 rpm quickly after the following conditions are met. - Engine: After warming up - After keeping engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load 		0 - 0.3 V ↔ Approx. 0.6 - 1.0 V
HO2S2 (B2)	<ul style="list-style-type: none"> • Revving engine from idle to 3,000 rpm quickly after the following conditions are met. - Engine: After warming up - After keeping engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load 		0 - 0.3 V ↔ Approx. 0.6 - 1.0 V
HO2S2 MNTR (B1)	<ul style="list-style-type: none"> • Revving engine from idle to 3,000 rpm quickly after the following conditions are met. - Engine: After warming up - After keeping engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load 		LEAN ↔ RICH
HO2S2 MNTR (B2)	<ul style="list-style-type: none"> • Revving engine from idle to 3,000 rpm quickly after the following conditions are met. - Engine: After warming up - After keeping engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load 		LEAN ↔ RICH
VHCL SPEED SE	• Turn drive wheels and compare CONSULT value with the speedometer indication.		Almost the same speed as speedometer indication
BATTERY VOLT	• Ignition switch: ON (Engine stopped)		11 - 14 V
ACCEL SEN 1	• Ignition switch: ON (Engine stopped)	Accelerator pedal: Fully released	0.5 - 1.0 V
		Accelerator pedal: Fully depressed	4.2 - 4.8 V
ACCEL SEN 2*1	• Ignition switch: ON (Engine stopped)	Accelerator pedal: Fully released	0.5 - 1.0 V
		Accelerator pedal: Fully depressed	4.2 - 4.8 V

ECM

< ECU DIAGNOSIS INFORMATION >

[WITHOUT 7 INCH DISPLAY]

Monitor Item	Condition	Values/Status
TP SEN 1-B1	• Ignition switch: ON (Engine stopped) • Selector lever: D position	Accelerator pedal: Fully released More than 0.36 V
		Accelerator pedal: Fully depressed Less than 4.75 V
TP SEN 2-B1*1	• Ignition switch: ON (Engine stopped) • Selector lever: D position	Accelerator pedal: Fully released More than 0.36 V
		Accelerator pedal: Fully depressed Less than 4.75 V
FUEL T/TMP SE	• Ignition switch: ON	Indicates fuel tank temperature
INT/A TEMP SE	• Ignition switch: ON	Indicates intake air temperature
EVAP SYS PRES	• Ignition switch: ON	Approx. 1.8 - 4.8 V
FUEL LEVEL SE	• Ignition switch: ON	Depending on fuel level of fuel tank
START SIGNAL	• Ignition switch: ON → START → ON	OFF → ON → OFF
CLSD THL POS	• Ignition switch: ON (Engine stopped)	Accelerator pedal: Fully released ON
		Accelerator pedal: Slightly depressed OFF
AIR COND SIG	• Engine: After warming up, idle the engine	Air conditioner switch: OFF OFF
		Air conditioner switch: ON (Compressor operates.) ON
P/N POSI SW	• Ignition switch: ON	Selector lever: P or N position ON
		Selector lever: Except above position OFF
PW/ST SIGNAL	• Engine: After warming up, idle the engine	Steering wheel: Not being turned OFF
		Steering wheel: Being turned ON
LOAD SIGNAL	• Ignition switch: ON	Rear window defogger switch: ON and/or Lighting switch: 2nd position ON
		Rear window defogger switch and lighting switch: OFF OFF
IGNITION SW	• Ignition switch: ON → OFF → ON	ON → OFF → ON
HEATER FAN SW	• Engine: After warming up, idle the engine	Heater fan switch: ON ON
		Heater fan switch: OFF OFF
BRAKE SW	• Ignition switch: ON	Brake pedal: Fully released OFF
		Brake pedal: Slightly depressed ON
INJ PULSE-B1	• Engine: After warming up • Selector lever: P or N position • Air conditioner switch: OFF • No load	Idle 2.0 - 3.0 msec
		2,000 rpm 1.9 - 2.9 msec
INJ PULSE-B2	• Engine: After warming up • Selector lever: P or N position • Air conditioner switch: OFF • No load	Idle 2.0 - 3.0 msec
		2,000 rpm 1.9 - 2.9 msec
IGN TIMING	• Engine: After warming up • Selector lever: P or N position • Air conditioner switch: OFF • No load	Idle 7 - 17°BTDC
		2,000 rpm 25 - 45°BTDC
CAL/LD VALUE	• Engine: After warming up • Selector lever: P or N position • Air conditioner switch: OFF • No load	Idle 5 - 35%
		2,500 rpm 5 - 35%
MASS AIRFLOW	• Engine: After warming up • Selector lever: P or N position • Air conditioner switch: OFF • No load	Idle 2.0 - 6.0 g/s
		2,500 rpm 7.0 - 20.0 g/s

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

ECM

< ECU DIAGNOSIS INFORMATION >

[WITHOUT 7 INCH DISPLAY]

Monitor Item	Condition	Values/Status	
PURG VOL C/V	<ul style="list-style-type: none"> Engine: After warming up Selector lever: P or N position Air conditioner switch: OFF No load Idle (Accelerator pedal: Not depressed even slightly, after engine starting.)	0%	
	2,000 rpm	—	
INT/V TIM (B1)	<ul style="list-style-type: none"> Engine: After warming up Selector lever: P or N position Air conditioner switch: OFF No load Idle	-5 - 5°C	
	2,000 rpm	Approx. 0 - 30°C	
INT/V TIM (B2)	<ul style="list-style-type: none"> Engine: After warming up Selector lever: P or N position Air conditioner switch: OFF No load Idle	-5 - 5°C	
	2,000 rpm	Approx. 0 - 30°C	
INT/V SOL (B1)	<ul style="list-style-type: none"> Engine: After warming up Selector lever: P or N position Air conditioner switch: OFF No load Idle	0 - 2%	
	2,000 rpm	Approx. 0 - 50%	
INT/V SOL (B2)	<ul style="list-style-type: none"> Engine: After warming up Selector lever: P or N position Air conditioner switch: OFF No load Idle	0 - 2%	
	2,000 rpm	Approx. 0 - 50%	
VIAS S/V-1	<ul style="list-style-type: none"> Engine: After warming up Selector lever: P or N position Air conditioner switch: OFF No load When revving engine up to 5,000 rpm quickly	OFF → ON → OFF	
VIAS S/V-2	<ul style="list-style-type: none"> Engine: After warming up Selector lever: P or N position Air conditioner switch: OFF No load When revving engine up to 5,000 rpm quickly	OFF → ON → OFF	
AIR COND RLY	<ul style="list-style-type: none"> Engine: After warming up, idle the engine Air conditioner switch: OFF	OFF	
		Air conditioner switch: ON (Compressor operates)	ON
ENGINE MOUNT	<ul style="list-style-type: none"> Engine: After warming up Idle (With vehicle stopped)	IDLE	
		Except above conditions	TRVL
FUEL PUMP RLY	<ul style="list-style-type: none"> For 1 second after turning ignition switch: ON Engine running or cranking 	ON	
	<ul style="list-style-type: none"> Except above 	OFF	
VENT CONT/V	<ul style="list-style-type: none"> Ignition switch: ON 	OFF	
THRTL RELAY	<ul style="list-style-type: none"> Ignition switch: ON 	ON	
COOLING FAN	<ul style="list-style-type: none"> Engine: After warming up, idle the engine Air conditioner switch: OFF Engine coolant temperature: 97°C (206°F) or less	OFF	
		Engine coolant temperature: Between 98°C (208°F) and 99°C (210°F)	LOW
		Engine coolant temperature: Between 100°C (212°F) and 104°C (219°F)	MID
		Engine coolant temperature: 105°C (221°F) or more	HI
HO2S2 HTR (B1)	<ul style="list-style-type: none"> Engine speed: Below 3,600 rpm after the following conditions are met. <ul style="list-style-type: none"> Engine: After warming up Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load 	ON	
	<ul style="list-style-type: none"> Engine speed: Above 3,600 rpm 	OFF	

ECM

< ECU DIAGNOSIS INFORMATION >

[WITHOUT 7 INCH DISPLAY]

Monitor Item	Condition		Values/Status
HO2S2 HTR (B2)	<ul style="list-style-type: none"> Engine speed: Below 3,600 rpm after the following conditions are met. <ul style="list-style-type: none"> Engine: After warming up Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load 		ON
	<ul style="list-style-type: none"> Engine speed: Above 3,600 rpm 		OFF
I/P PULLY SPD	<ul style="list-style-type: none"> Vehicle speed: More than 20 km/h (12 MPH) 		Almost the same speed as the tachometer indication
VEHICLE SPEED	<ul style="list-style-type: none"> Turn drive wheels and compare CONSULT value with the speedometer indication. 		Almost the same speed as the speedometer indication
IDL A/V LEARN	<ul style="list-style-type: none"> Engine: Running 	Idle air volume learning has not been performed yet.	YET
		Idle air volume learning has already been performed successfully.	CMPLT
ENG OIL TEMP	<ul style="list-style-type: none"> Engine: After warming up 		More than 70°C (158°F)
TRVL AFTER MIL	<ul style="list-style-type: none"> Ignition switch: ON 	Vehicle has traveled after MIL has illuminated.	0 - 65,535 km (0 - 40,723 miles)
A/F S1 HTR (B1)	<ul style="list-style-type: none"> Engine: After warming up, idle the engine (More than 140 seconds after starting engine) 		4 - 100%
A/F S1 HTR (B2)	<ul style="list-style-type: none"> Engine: After warming up, idle the engine (More than 140 seconds after starting engine) 		4 - 100%
AC PRESS SEN	<ul style="list-style-type: none"> Engine: Idle Both A/C switch and blower fan switch: ON (Compressor operates) 		1.0 - 4.0 V
VHCL SPEED SE	<ul style="list-style-type: none"> Turn drive wheels and compare CONSULT value with the speedometer indication. 		Almost the same speed as the speedometer indication
SET VHCL SPD	<ul style="list-style-type: none"> Engine: Running 	ASCD: Operating	The preset vehicle speed is displayed
MAIN SW	<ul style="list-style-type: none"> Ignition switch: ON 	MAIN switch: Pressed	ON
		MAIN switch: Released	OFF
CANCEL SW	<ul style="list-style-type: none"> Ignition switch: ON 	CANCEL switch: Pressed	ON
		CANCEL switch: Released	OFF
RESUME/ACC SW	<ul style="list-style-type: none"> Ignition switch: ON 	RESUME/ACCELERATE switch: Pressed	ON
		RESUME/ACCELERATE switch: Released	OFF
SET SW	<ul style="list-style-type: none"> Ignition switch: ON 	SET/COAST switch: Pressed	ON
		SET/COAST switch: Released	OFF
BRAKE SW1 (ASCD brake switch)	<ul style="list-style-type: none"> Ignition switch: ON 	Brake pedal: Fully released	ON
		Brake pedal: Slightly depressed	OFF
BRAKE SW2 (Stop lamp switch)	<ul style="list-style-type: none"> Ignition switch: ON 	Brake pedal: Fully released	OFF
		Brake pedal: Slightly depressed	ON
VHCL SPD CUT	<ul style="list-style-type: none"> Ignition switch: ON 		NON
LO SPEED CUT	<ul style="list-style-type: none"> Ignition switch: ON 		NON
AT OD MONITOR	<ul style="list-style-type: none"> Ignition switch: ON 		OFF
AT OD CANCEL	<ul style="list-style-type: none"> Ignition switch: ON 		OFF
CRUISE LAMP	<ul style="list-style-type: none"> Ignition switch: ON 	MAIN switch: Pressed at the 1st time → at the 2nd time	ON → OFF
SET LAMP	<ul style="list-style-type: none"> MAIN switch: ON When vehicle speed is between 40 km/h (25 MPH) and 144 km/h (89 MPH) 	ASCD: Operating	ON
		ASCD: Not operating	OFF

A

B

C

D

E

F

G

H

HAC

J

K

L

M

N

O

P

ECM

< ECU DIAGNOSIS INFORMATION >

[WITHOUT 7 INCH DISPLAY]


Monitor Item	Condition	Values/Status
ALT DUTY	• Engine: Idle	0 - 80%
A/F ADJ-B1	• Engine: Running	-0.330 - 0.330
A/F ADJ-B2	• Engine: Running	-0.330 - 0.330
BAT CUR SEN	<ul style="list-style-type: none"> • Engine speed: Idle • Battery: Fully charged*2 • Selector lever: P or N position • Air conditioner switch: OFF • No load 	Approx. 2,600 - 3,500 mV
ALT DUTY SIG	• Power generation voltage variable control: Operating	ON
	• Power generation voltage variable control: Not operating	OFF
HO2 S2 DIAG1 (B1)	DTC P0139 self-diagnosis (delayed response) is incomplete.	INCMPL
	DTC P0139 self-diagnosis (delayed response) is complete.	CMPLT
HO2 S2 DIAG1 (B2)	DTC P0159 self-diagnosis (delayed response) is incomplete.	INCMPL
	DTC P0159 self-diagnosis (delayed response) is complete.	CMPLT
HO2 S2 DIAG2 (B1)	DTC P0139 self-diagnosis (slow response) is incomplete.	INCMPL
	DTC P0139 self-diagnosis (slow response) is complete.	CMPLT
HO2 S2 DIAG2 (B2)	DTC P0159 self-diagnosis (slow response) is incomplete.	INCMPL
	DTC P0159 self-diagnosis (slow response) is complete.	CMPLT
A/F SEN1 DIAG1 (B1)	DTC P015A and P015B self-diagnosis is incomplete.	INCMPL
	DTC P015A and P015B self-diagnosis is complete.	CMPLT
A/F SEN1 DIAG1 (B2)	DTC P015C and P015D self-diagnosis is incomplete.	INCMPL
	DTC P015C and P015D self-diagnosis is complete.	CMPLT
A/F SEN1 DIAG2 (B1)	DTC P014C and P014D self-diagnosis is incomplete.	INCMPL
	DTC P014C and P014D self-diagnosis is complete.	CMPLT
A/F SEN1 DIAG2 (B2)	DTC P014E and P014F self-diagnosis is incomplete.	INCMPL
	DTC P014E and P014F self-diagnosis is complete.	CMPLT
A/F SEN1 DIAG3 (B1)	The vehicle condition is not within the diagnosis range of DTC P014C, P014D, P015A or P015B.	ABSNT
	The vehicle condition is within the diagnosis range of DTC P014C, P014D, P015A or P015B.	PRSNT
A/F SEN1 DIAG3 (B2)	The vehicle condition is not within the diagnosis range of DTC P014E, P014F, P015C or P015D.	ABSNT
	The vehicle condition is within the diagnosis range of DTC P014E, P014F, P015C or P015D.	PRSNT
THRTL STK CNT B1*3	—	—
EVAP LEAK DIAG	Ignition switch: ON	Indicates the condition of EVAP leak diagnosis.
EVAP DIAG READY	Ignition switch: ON	Indicates the ready condition of EVAP leak diagnosis.

*1: Accelerator pedal position sensor 2 signal and throttle position sensor 2 signal are converted by ECM internally. Thus, they differ from ECM terminals voltage signal.

*2: Before measuring the terminal voltage, confirm that the battery is fully charged. Refer to [PG-3, "How to Handle Battery"](#).

*3: The item is indicated, but not used.

TERMINAL LAYOUT



PHYSICAL VALUES

NOTE:







- ECM is located in the engine room left side near battery.
- Specification data are reference values.
- Pulse signal is measured by CONSULT.

Terminal No.		Description		Condition	Value (Approx.)
+	--	Signal name	Input/Output		
1 (P/B)	112 (B)	Fuel injector No. 6	Output	[Engine is running] • Warm-up condition • Idle speed NOTE: The pulse cycle changes depending on rpm at idle	BATTERY VOLTAGE (11 - 14 V)★ 50mSec/div 10V/div JMBIA0047GB
3 (L/W)		Fuel injector No. 5			
29 (LG/R)		Fuel injector No. 4			
30 (R/Y)		Fuel injector No. 3			
31 (R/W)		Fuel injector No. 2			
32 (R/B)		Fuel injector No. 1		[Engine is running] • Warm-up condition • Engine speed: 2,000 rpm	BATTERY VOLTAGE (11 - 14 V)★ 50mSec/div 10V/div JMBIA0048GB
2 (G/W)	112 (B)	Throttle control motor power supply	Input	[Ignition switch: ON]	BATTERY VOLTAGE (11 - 14 V)
4 (BR/Y)	112 (B)	A/F sensor 1 heater (bank 1)	Output	[Engine is running] • Warm-up condition • Idle speed (More than 140 seconds after starting engine)	2.9 - 8.8 V★ 50mSec/div 5V/div JMBIA0092GB

ECM

< ECU DIAGNOSIS INFORMATION >



[WITHOUT 7 INCH DISPLAY]

Terminal No.		Description		Condition	Value (Approx.)
+	-	Signal name	Input/Output		
5 (L)	112 (B)	Throttle control motor (Open)	Output	[Ignition switch: ON] • Engine stopped • Selector lever: D position • Accelerator pedal: Fully depressed	0 - 14 V★ 
				[Ignition switch: ON] • Engine stopped • Selector lever: D position • Accelerator pedal: Fully released	0 - 14 V★ 
6 (P)	112 (B)	Throttle control motor (Close)	Output	[Ignition switch: ON] • Engine stopped • Selector lever: D position • Accelerator pedal: Fully released	0 - 14 V★ 
8 (SB)	112 (B)	A/F sensor 1 heater (bank 2)	Output	[Engine is running] • Warm-up condition • Idle speed (More than 140 seconds after starting engine)	2.9 - 8.8 V★ 
9 (L/B)	112 (B)	Ignition signal No. 3	Output	[Engine is running] • Warm-up condition • Idle speed NOTE: The pulse cycle changes depending on rpm at idle	0 - 0.2 V★ 
10 (G/R)		Ignition signal No. 2			
11 (Y/R)		Ignition signal No. 1			
18 (GR/R)		Ignition signal No. 6			
19 (P)		Ignition signal No. 5			
21 (W)	Ignition signal No. 4	[Engine is running] • Warm-up condition • Engine speed: 2,000 rpm	0.1 - 0.4 V★ 		
12 (B)	—	ECM ground	—	—	—

ECM

< ECU DIAGNOSIS INFORMATION >

[WITHOUT 7 INCH DISPLAY]

Terminal No.		Description		Condition	Value (Approx.)
+	—	Signal name	Input/Output		
13 (P/B)	112 (B)	Heated oxygen sensor 2 heater (bank 1)	Output	[Engine is running] • Engine speed: Below 3,600 rpm after the following conditions are met - Engine: after warming up - Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load	10 V★ 
				[Ignition switch: ON] • Engine stopped [Engine is running] • Engine speed: Above 3,600 rpm	BATTERY VOLTAGE (11 - 14 V)
14 (GR)	112 (B)	Fuel pump relay	Output	[Ignition switch: ON] • For 1 second after turning ignition switch ON [Engine is running]	0 - 1.5 V
				[Ignition switch: ON] • More than 1 second after turning ignition switch ON	BATTERY VOLTAGE (11 - 14 V)
15 (O)	112 (B)	Throttle control motor relay	Output	[Ignition switch: ON → OFF]	0 - 1.0 V → BATTERY VOLTAGE (11 - 14 V) → 0 V
				[Ignition switch: ON]	0 - 1.0 V
16 (B/Y)	—	ECM ground	—	—	—
17 (R)	112 (B)	Heated oxygen sensor 2 heater (bank 2)	Output	[Engine is running] • Engine speed: Below 3,600 rpm after the following conditions are met - Engine: after warming up - Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load	10 V★ 
				[Ignition switch: ON] • Engine stopped [Engine is running] • Engine speed: Above 3,600 rpm	BATTERY VOLTAGE (11 - 14 V)
24 (W/B)	112 (B)	ECM relay (Self shut-off)	Output	[Engine is running] [Ignition switch: OFF] • A few seconds after turning ignition switch OFF	0 - 1.5 V
				[Ignition switch: OFF] • More than a few seconds after turning ignition switch OFF	BATTERY VOLTAGE (11 - 14 V)

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

ECM

< ECU DIAGNOSIS INFORMATION >

[WITHOUT 7 INCH DISPLAY]

Terminal No.		Description		Condition	Value (Approx.)
+	-	Signal name	Input/Output		
25 (P/L)	112 (B)	EVAP canister purge volume control solenoid valve	Output	[Engine is running] • Idle speed • Accelerator pedal: Not depressed even slightly, after engine starting	BATTERY VOLTAGE (11 - 14 V)★
				[Engine is running] • Engine speed: approximately 2,000 rpm (More than 100 seconds after starting engine)	BATTERY VOLTAGE (11 - 14 V)★
26 (GR/B)	112 (B)	VIAS control solenoid valve 2	Output	[Engine is running] • Warm-up condition • Idle speed	BATTERY VOLTAGE (11 - 14 V)
				[Engine is running] • Warm-up condition • When revving engine up to 5,000 rpm quickly	BATTERY VOLTAGE (11 - 14 V) ↓ 0 - 1.0 V ↓ BATTERY VOLTAGE (11 - 14 V)
27 (V)	112 (B)	VIAS control solenoid valve 1	Output	[Engine is running] • Warm-up condition • Idle speed	BATTERY VOLTAGE (11 - 14 V)
				[Engine is running] • Warm-up condition • When revving engine up to 5,000 rpm quickly	BATTERY VOLTAGE (11 - 14 V) ↓ 0 - 1.0 V ↓ BATTERY VOLTAGE (11 - 14 V)
28 (BR/W)	112 (B)	Electronic controlled engine mount control solenoid valve	Output	[Engine is running] • Engine speed: For 2 seconds after reaching 950 rpm or less	0 - 1.0 V
				[Engine is running] • Engine speed: After a lapse of 2 seconds after reaching 950 rpm or less	2.0 - 3.0 V
				[Engine is running] • Engine speed: 950 rpm or more	BATTERY VOLTAGE (11 - 14 V)
33 (W)	112 (B)	Heated oxygen sensor 2 (bank 1)	Input	[Engine is running] • Revving engine from idle to 3,000 rpm quickly after the following conditions are met - Engine: after warming up - Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load	0 - 1.0 V

ECM

< ECU DIAGNOSIS INFORMATION >

[WITHOUT 7 INCH DISPLAY]

Terminal No.		Description		Condition	Value (Approx.)	
+	—	Signal name	Input/ Output			
34 (W/L)	112 (B)	Heated oxygen sensor 2 (bank 2)	Input	[Engine is running] • Revving engine from idle to 3,000 rpm quickly after the following conditions are met - Engine: after warming up - Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load	0 - 1.0 V	A B C D
35 (B)	—	Sensor ground (Heated oxygen sensor 2)	—	—	—	E
36 (B)	—	Sensor ground (Throttle position sensor)	—	—	—	F
37 (W)	112 (B)	Throttle position sensor 1	Input	[Ignition switch: ON] • Engine stopped • Selector lever: D position • Accelerator pedal: Fully released	More than 0.36 V	G
				[Ignition switch: ON] • Engine stopped • Selector lever: D position • Accelerator pedal: Fully depressed	Less than 4.75 V	H
38 (R)	112 (B)	Throttle position sensor 2	Input	[Ignition switch: ON] • Engine stopped • Selector lever: D position • Accelerator pedal: Fully released	Less than 4.75 V	HAC
				[Ignition switch: ON] • Engine stopped • Selector lever: D position • Accelerator pedal: Fully depressed	More than 0.36 V	J K
39 (R)	40 (G)	Refrigerant pressure sensor	Input	[Engine is running] • Warm-up condition • Both A/C switch and blower fan motor switch: ON (Compressor operates)	1.0 - 4.0 V	L
40 (G)	—	Sensor ground (Refrigerant pressure sensor)	—	—	—	M
41 (O/B)	48 (B/P)	Power steering pressure sensor	Output	[Engine is running] • Steering wheel: Being turned	0.5 - 4.5 V	N
				[Engine is running] • Steering wheel: Not being turned	0.4 - 0.8 V	O
42 (BR)	44 (G/B)	Battery current sensor	Input	[Engine is running] • Battery: Fully charged*2 • Idle speed	2.6 - 3.5 V	P
44 (G/B)	—	Sensor ground (Battery current sensor)	—	—	—	
45 (P)	49 (L)	A/F sensor 1 (bank 1)	Input	[Ignition switch: ON]	2.2 V	
46 (Y)	52 (B/R)	Engine coolant temperature sensor	Input	[Engine is running]	0 - 4.8 V Output voltage varies with engine coolant temperature.	

ECM

< ECU DIAGNOSIS INFORMATION >







[WITHOUT 7 INCH DISPLAY]

Terminal No.		Description		Condition	Value (Approx.)
+	—	Signal name	Input/ Output		
47 (G)	36 (B)	Sensor power supply (Throttle position sensor)	—	[Ignition switch: ON]	5 V
48 (B/P)	—	Sensor ground (Power steering pressure sensor)	—	—	—
49 (L)	112 (B)	A/F sensor 1 (bank 1)	Input	[Engine is running] • Warm-up condition • Engine speed: 2,000 rpm	1.8 V Output voltage varies with air fuel ratio.
50 (L/Y)	56 (G/B)	Intake air temperature sensor	Input	[Engine is running]	0 - 4.8 V Output voltage varies with intake air temperature.
51 (R/Y)	44 (G/B)	Sensor power supply (Battery current sensor)	—	[Ignition switch: ON]	5 V
52 (B/R)	—	Sensor ground (Engine coolant temperature sensor/Engine oil temperature sensor)	—	—	—
53 (V)	57 (LG)	A/F sensor 1 (bank 2)	Input	[Ignition switch: ON]	2.2 V
54 (G)	52 (B/R)	Engine oil temperature sensor	Input	[Engine is running]	0 - 4.8 V Output voltage varies with engine oil temperature.
55 (SB)	48 (Y)	Sensor power supply (Power steering pressure sensor)	—	[Ignition switch: ON]	5 V
56 (G/B)	—	Sensor ground (Mass air flow sensor/Intake air temperature sensor)	—	—	—
57 (LG)	112 (B)	A/F sensor 1 (bank 2)	Input	[Engine is running] • Warm-up condition • Engine speed: 2,000 rpm	1.8 V Output voltage varies with air fuel ratio.
58 (O)	56 (G/B)	Mass air flow sensor	Input	[Engine is running] • Warm-up condition • Idle speed	0.9 - 1.2 V
				[Engine is running] • Warm-up condition • Engine speed: 2,500 rpm	1.6 - 1.9 V
59 (G/W)	64 (B/R)	Sensor power supply [Camshaft position sensor (PHASE) (bank 1)]	—	[Ignition switch: ON]	5 V
60 (Y/B)	—	Sensor ground [Crankshaft position sensor (POS)]	—	—	—
61 (B)	67 (—)	Knock sensor (bank 1)	Input	[Engine is running] • Idle speed	2.5 V*1
62 (W)	67 (—)	Knock sensor (bank 2)	Input	[Engine is running] • Idle speed	2.5 V*1
63 (R/W)	68 (Y/G)	Sensor power supply [Camshaft position sensor (PHASE) (bank 2)]	—	[Ignition switch: ON]	5 V
64 (B/R)	—	Sensor ground [Camshaft position sensor (PHASE) (bank 1)]	—	—	—

ECM

< ECU DIAGNOSIS INFORMATION >

[WITHOUT 7 INCH DISPLAY]

Terminal No.		Description		Condition	Value (Approx.)
+	-	Signal name	Input/Output		
65 (W/B)	60 (Y/B)	Crankshaft position sensor (POS)	Input	[Engine is running] • Warm-up condition • Idle speed NOTE: The pulse cycle changes depending on rpm at idle	4.0 - 5.0 V★ 
				[Engine is running] • Engine speed: 2,000 rpm	4.0 - 5.0 V★ 
67 (-)	-	Sensor ground (Knock sensor)	-	-	-
68 (Y/G)	-	Sensor ground [Camshaft position sensor (PHASE) (bank 2)]	-	-	-
69 (BR/W)	68 (Y/G)	Camshaft position sensor (PHASE) (bank 2)	Input	[Engine is running] • Warm-up condition • Idle speed NOTE: The pulse cycle changes depending on rpm at idle	3.0 - 5.0 V★ 
				[Engine is running] • Engine speed is 2,000 rpm	3.0 - 5.0 V★ 
70 (W/R)	64 (B/R)	Camshaft position sensor (PHASE) (bank 1)	Input	[Engine is running] • Warm-up condition • Idle speed NOTE: The pulse cycle changes depending on rpm at idle	3.0 - 5.0 V★ 
				[Engine is running] • Engine speed is 2,000 rpm	3.0 - 5.0 V★ 



A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

ECM

< ECU DIAGNOSIS INFORMATION >



[WITHOUT 7 INCH DISPLAY]

Terminal No.		Description		Condition	Value (Approx.)
+	—	Signal name	Input/Output		
72 (BR/W)	40 (G)	Sensor power supply (Refrigerant pressure sensor)	—	[Ignition switch: ON]	5 V
75 (Y)	112 (B)	Intake valve timing control solenoid valve (bank 2)	Output	[Engine is running] • Warm-up condition • Idle speed	BATTERY VOLTAGE (11 - 14 V)
				[Engine is running] • Warm-up condition • Engine speed: 2,000 rpm	7 - 12 V★ 
76 (R/G)	60 (Y/B)	Sensor power supply [Crankshaft position sensor (POS)]	—	[Ignition switch: ON]	5 V
77 (W/L)	112 (B)	Power supply for ECM (Back-up)	Input	[Ignition switch: OFF]	BATTERY VOLTAGE (11 - 14 V)
78 (R/L)	112 (B)	Intake valve timing control solenoid valve (bank 1)	Output	[Engine is running] • Warm-up condition • Idle speed	BATTERY VOLTAGE (11 - 14 V)
				[Engine is running] • Warm-up condition • Engine speed: 2,000 rpm	7 - 12 V★ 
81 (W)	84 (B)	Accelerator pedal position sensor 1	Input	[Ignition switch: ON] • Engine stopped • Accelerator pedal: Fully released	0.5 - 1.0 V
				[Ignition switch: ON] • Engine stopped • Accelerator pedal: Fully depressed	4.2 - 4.8 V
82 (O)	100 (G)	Accelerator pedal position sensor 2	Input	[Ignition switch: ON] • Engine stopped • Accelerator pedal: Fully released	0.25 - 0.50 V
				[Ignition switch: ON] • Engine stopped • Accelerator pedal: Fully depressed	2.0 - 2.5 V
83 (BR)	84 (B)	Sensor power supply (Accelerator pedal position sensor 1)	—	[Ignition switch: ON]	5 V
84 (B)	—	Sensor ground (Accelerator pedal position sensor 1)	—	—	—

ECM

< ECU DIAGNOSIS INFORMATION >

[WITHOUT 7 INCH DISPLAY]

Terminal No.		Description		Condition	Value (Approx.)
+	-	Signal name	Input/Output		
85 (Y)	92 (BR)	ASCDC steering switch	Input	[Ignition switch: ON] • ASCDC steering switch: OFF	4 V
				[Ignition switch: ON] • MAIN switch: Pressed	0 V
				[Ignition switch: ON] • CANCEL switch: Pressed	1 V
				[Ignition switch: ON] • RESUME/ACCELERATE switch: Pressed	3 V
				[Ignition switch: ON] • SET/COAST switch: Pressed	2 V
86 (SB)	96 (GR)	EVAP control system pressure sensor	Input	[Ignition switch: ON]	1.8 - 4.8 V
87 (GR)	100 (G)	Sensor power supply (Accelerator pedal position sensor 2)	—	[Ignition switch: ON]	5 V
88 (O)	—	Data link connector	Input/Output	—	—
91 (L)	96 (GR)	Sensor power supply (EVAP control system pressure sensor)	—	[Ignition switch: ON]	5 V
92 (BR)	—	Sensor ground (ASCDC steering switch)	—	—	—
93 (BR)	112 (B)	Ignition switch	Input	[Ignition switch: OFF]	0 V
				[Ignition switch: ON]	BATTERY VOLTAGE (11 - 14 V)
94 (GR)	112 (B)	Engine speed output signal	Output	[Engine is running] • Warm-up condition • Idle speed NOTE: The pulse cycle changes depending on rpm at idle	1 V★ 
				[Engine is running] • Engine speed: 2,000 rpm	1 V★ 
95 (Y)	104 (SB)	Fuel tank temperature sensor	Input	[Engine is running]	0 - 4.8 V Output voltage varies with fuel tank temperature.
96 (GR)	—	Sensor ground (EVAP control system pressure sensor)	—	—	—
97 (P)	—	CAN communication line (CAN-L)	Input/Output	—	—
98 (L)	—	CAN communication line (CAN-H)	Input/Output	—	—

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

ECM

< ECU DIAGNOSIS INFORMATION >

[WITHOUT 7 INCH DISPLAY]

Terminal No.		Description		Condition	Value (Approx.)
+	—	Signal name	Input/ Output		
100 (G)	—	Sensor ground (Accelerator pedal position sensor 2)	—	—	—
102 (R)	112 (B)	PNP signal	Input	[Ignition switch: ON] • Selector lever: P or N position	BATTERY VOLTAGE (11 - 14 V)
				[Ignition switch: ON] • Selector lever: Except above position	0 V
104 (SB)	—	Sensor ground (Fuel tank temperature sensor)	—	—	—
105 (V)	112 (B)	Power supply for ECM	Input	[Ignition switch: ON]	BATTERY VOLTAGE (11 - 14 V)
106 (SB)	112 (B)	Stop lamp switch	Input	[Ignition switch: OFF] • Brake pedal: Fully released	0 V
				[Ignition switch: OFF] • Brake pedal: Slightly depressed	BATTERY VOLTAGE (11 - 14 V)
107 (B) 108 (B)	—	ECM ground	—	—	—
109 (W)	112 (B)	EVAP canister vent control valve	Output	[Ignition switch: ON]	BATTERY VOLTAGE (11 - 14 V)
110 (G)	112 (B)	ASCD brake switch	Input	[Ignition switch: ON] • Brake pedal: Slightly depressed	0 V
				[Ignition switch: ON] • Brake pedal: Fully released	BATTERY VOLTAGE (11 - 14 V)
111 (B) 112 (B)	—	ECM ground	—	—	—

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

*1: This may vary depending on internal resistance of the tester.

*2: Before measuring the terminal voltage, confirm that the battery is fully charged. Refer to [PG-3. "How to Handle Battery"](#).

A/C AUTO AMP.

< ECU DIAGNOSIS INFORMATION >

[WITHOUT 7 INCH DISPLAY]

A/C AUTO AMP.

Reference Value

INFOID:000000009722102

VALUES ON THE DIAGNOSIS TOOL


NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

CONSULT MONITOR ITEM

Monitor item	Condition		Value/Status
COMP REQ SIG	Engine: Run at idle after warming up	A/C switch: ON (Compressor operation status)	On
		A/C switch: OFF	Off
FAN REQ SIG	Engine: Run at idle after warming up	Blower fan: ON	On
		Blower fan: OFF	Off
AMB TEMP SEN	Ignition switch ON	—	22 - 131°F (-30 - 55°C)
IN-VEH TEMP	Ignition switch ON	—	22 - 131°F (-30 - 55°C)
INT TEMP SEN	Ignition switch ON	—	22 - 131°F (-30 - 55°C)
SUNLOAD SEN	Ignition switch ON	—	0 - 1045 w/m ² (0 - 900 kcal/m ² ·h)
AMB SEN CAL	Ignition switch ON	—	22 - 131°F (-30 - 55°C)
IN-VEH CAL	Ignition switch ON	—	22 - 131°F (-30 - 55°C)
INT TEMP CAL	Ignition switch ON	—	22 - 131°F (-30 - 55°C)
SUNL SEN CAL	Ignition switch ON	—	0 - 1045 w/m ² (0 - 900 kcal/m ² ·h)
FAN DUTY	Engine: Run at idle after warming up	Blower fan: ON	25 - 81
		Blower fan: OFF	0
XM	Ignition switch ON	—	-100 - 155
ENG COOL TEMP	Ignition switch ON	—	Values according to coolant temperature
VEHICLE SPEED	Driving	—	Equivalent to speedometer reading

TERMINAL LAYOUT





PHYSICAL VALUES

A/C AUTO AMP.

< ECU DIAGNOSIS INFORMATION >

[WITHOUT 7 INCH DISPLAY]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
1 (L)	—	CAN-H	Input/ Output	—	—
2 (P)	—	CAN-L	Input/ Output	—	—
6 (L)	Ground	TX (AMP > SW-DISP)	Input	—	—
7 (P)	Ground	RX (SW > AMP)	Output	—	—
10 (G)	Ground	LAN signal	Input/ Output	—	 <p style="text-align: right; font-size: small;">SJIA1453J</p>
11 (R)	Ground	Power supply for each door motor	Input	Ignition switch ON	Battery voltage
15 (BR)	Ground	Sunload sensor	Input	—	—
16 (R)	Ground	Intake sensor	Input	—	—
17 (W)	Ground	Power supply from ACC	—	Ignition switch ACC	Battery voltage
19 (B)	Ground	Ground	—	Ignition switch ON	0 V
20 (G)	Ground	Power supply from IGN	—	Ignition switch ON	Battery voltage
32 (L)	Ground	Blower motor control signal	Output	<ul style="list-style-type: none"> • Ignition switch ON • Blower speed: 1st speed (manual) 	 <p style="text-align: right; font-size: small;">JSIIA0096ZZ</p>
34 (V)	Ground	Power supply for ambient meter	Output	Ignition switch ON	5V
35 (G)	Ground	Ambient sensor	Input	—	—
36 (LG)	Ground	In-vehicle sensor	Input	—	—
37 (SB)	Ground	Sensor ground	—	Ignition switch ON	0 V
39 (B)	Ground	Ground	—	Ignition switch ON	0 V
40 (Y)	Ground	Power supply from BATT	—	Ignition switch OFF	Battery voltage


A/C AUTO AMP.

< ECU DIAGNOSIS INFORMATION >

[WITHOUT 7 INCH DISPLAY]

Wiring Diagram - AIR CONDITIONER CONTROL SYSTEM -

INFOID:000000009722103



2012/08/24

JRIWC0486GB


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

HAC

A/C AUTO AMP.

< ECU DIAGNOSIS INFORMATION >

[WITHOUT 7 INCH DISPLAY]




JRIWC0487GB

*: This connector is not shown in "Harness Layout".

A/C AUTO AMP.

< ECU DIAGNOSIS INFORMATION >

[WITHOUT 7 INCH DISPLAY]



*: This connector is not shown in "Harness Layout".

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P


AUTOMATIC AIR CONDITIONING SYSTEM

Connector No.	E6
Connector Name	WIRE TO WIRE
Connector Type	TK18MGZ-1V



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
2	Y	-
3	GR	-
4	R	-
5	GR	-
6	V	-
8	P	-
10	W	-
11	G	-
12	BR	-
13	SB	-
14	B	-

Connector No.	E7
Connector Name	WIRE TO WIRE
Connector Type	NS18MW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
2	B	-
5	B	-
6	B	-
7	O	-
10	B	-

Connector No.	E10
Connector Name	ECM INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	TH20EW-CS12-M4-1V




Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	Y	-
3	GR	-
4	B	-
5	GR	-
6	BR	-
7	B	-
8	SB	-
9	Y	-
10	BR	-
11	W	-
12	R	-
13	Y	-
14	W	-
15	W	-
16	R	-
19	Y	-
20	L	-
21	O	-
22	SB	-
23	GR	-
24	G	-
25	GR	-
26	Y	-
27	W	-
28	SB	-
29	BR	-
30	BR	-
34	O	-
35	P	-
36	G	-
38	GR	-

Connector No.	E11
Connector Name	ECM INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	TH8BEW-BH



Terminal No.	Color Of Wire	Signal Name [Specification]
38	P	-
41	B	-
42	SB	-
43	Y	-
44	W	-
45	O	-
46	BR	-

Connector No.	E16
Connector Name	ECM
Connector Type	RH24FB-F28-L-LH



Terminal No.	Color Of Wire	Signal Name [Specification]
81	W	ACCELERATOR PEDAL POSITION SENSOR 1
82	O	ACCELERATOR PEDAL POSITION SENSOR 2
83	BR	SENSOR POWER SUPPLY
84	B	SENSOR GROUND
85	B	ASD
86	SB	EVAP CONTROL SYSTEM PRESSURE SENSOR
87	GR	SENSOR POWER SUPPLY
88	O	DATA LINK CONNECTOR
91	L	SENSOR POWER SUPPLY
92	BR	SENSOR GROUND
93	BR	IGNITION SWITCH

84	GR	ENGINE SPEED OUTPUT SIGNAL
85	Y	FUEL TANK LEVEL SENSOR
86	GR	SENSOR GROUND
87	P	CAN COMMUNICATION LINE(CAN-L)
88	L	CAN COMMUNICATION LINE(CAN-H)
100	G	SENSOR GROUND
102	R	PNP SIGNAL
104	SB	SENSOR GROUND
105	V	POWER SUPPLY FOR ECM
106	SB	STOP LAMP SWITCH
107	B	ECM GROUND
108	B	ECM GROUND
109	W	EVAP CANISTER VENT CONTROL VALVE
110	G	ASD BRAKE SWITCH
111	B	ECM GROUND
112	B	ECM GROUND

Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	TH70MM-CS1D-M3



Terminal No.	Color Of Wire	Signal Name [Specification]
3	Y	-
5	LG	-
6	GR	-
8	G	-
11	P	-
12	L	-
13	Y	-
14	O	-
15	BR	-
20	Y	-
21	BR	-
22	L	-
24	L	-
25	O	-
28	SB	-
29	W	-
30	Y	-

AUTOMATIC AIR CONDITIONING SYSTEM

38	R	-	-	-	-
39	L	-	-	-	-
40	B	-	-	-	-
47	P	-	-	-	-
48	L	-	-	-	-
49	SB	-	-	-	-
50	GR	-	-	-	-
51	LG	-	-	-	-
52	V	-	-	-	-
53	GR	-	-	-	-
54	BR	-	-	-	-
55	Y	-	-	-	-
56	W/L	-	-	-	-
60	V	-	-	-	-
61	BR	-	-	-	-
62	L/O	-	-	-	-
64	SHIELD	-	-	-	-
66	W	-	-	-	-
67	BR	-	-	-	-
68	Y	-	-	-	-
69	SB	-	-	-	-
70	GR	-	-	-	-
71	SB	-	-	-	-
72	Y	-	-	-	-
73	L	-	-	-	-
74	W	-	-	-	-
75	BR	-	-	-	-
76	BR	-	-	-	-
78	O	-	-	-	-
78	G	-	-	-	-
78	V	-	-	-	-
78	Y	-	-	-	-
79	Y	-	-	-	-
80	R	-	-	-	-
81	W	-	-	-	-
82	LG	-	-	-	-
83	O	-	-	-	-

Connector No.	E500
Connector Name	REFRIGERANT PRESSURE SENSOR
Connector Type	RS3ZFB



Terminal No.	Color	Wire	Signal Name [Specification]
1	P	-	-
2	B	-	-
3	L	-	-

Connector No.	E537
Connector Name	AMBIENT SENSOR
Connector Type	RS3ZFB




Terminal No.	Color	Wire	Signal Name [Specification]
1	SB	-	-
2	BR	-	-

Connector No.	E546
Connector Name	INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	TH2BFW-BH



Terminal No.	Color	Wire	Signal Name [Specification]
31	R	-	-
32	BL	-	-
36	BR	-	-
38	R/W	-	-
100	SB	-	-
101	L	-	-
102	B	-	-
103	P	-	-

Connector No.	F8
Connector Name	ECM
Connector Type	RH4BFR-R2B-L-LH



Terminal No.	Color	Wire	Signal Name [Specification]
33	W	-	HEATED OXYGEN SENSOR 2 (BANK 1)
34	W/L	-	HEATED OXYGEN SENSOR 2 (BANK 2)
35	B	-	SENSOR GROUND
36	B	-	SENSOR GROUND
37	W	-	THROTTLE POSITION SENSOR 1
38	R	-	THROTTLE POSITION SENSOR 2
39	R	-	REFRIGERANT PRESSURE SENSOR
40	C	-	SENSOR GROUND
41	O/B	-	POWER STEERING PRESSURE SENSOR
42	BR	-	BATTERY CURRENT SENSOR
44	G/B	-	SENSOR GROUND
45	P	-	A/F SENSOR 1 (BANK 1)
46	Y	-	ENGINE COOLANT TEMPERATURE SENSOR

47	G	-	SENSOR POWER SUPPLY
48	B/P	-	SENSOR GROUND
49	B	-	A/F SENSOR 1 (BANK 1)
50	L/Y	-	INTAKE AIR TEMPERATURE SENSOR
51	R/Y	-	SENSOR POWER SUPPLY
52	B/R	-	SENSOR GROUND
53	V	-	A/F SENSOR 1 (BANK 2)
54	G	-	ENGINE OIL TEMPERATURE SENSOR
55	SB	-	SENSOR POWER SUPPLY
56	G/B	-	SENSOR GROUND
57	LG	-	A/F SENSOR 1 (BANK 2)
58	O	-	MASS AIR FLOW SENSOR
59	G/W	-	SENSOR POWER SUPPLY
60	Y/B	-	SENSOR GROUND
61	B	-	KNOCK SENSOR (BANK 1)
62	W	-	SENSOR POWER SUPPLY
64	R/W	-	SENSOR GROUND
64	R/R	-	SENSOR GROUND
65	W/B	-	CRANKSHAFT POSITION SENSOR(POS)
67	SHIELD	-	SENSOR GROUND
68	Y/G	-	SENSOR GROUND
69	BR/W	-	CRANKSHAFT POSITION SENSOR(PHASE) (BANK 1)
70	W/R	-	CRANKSHAFT POSITION SENSOR(PHASE) (BANK 1)
72	BR/W	-	SENSOR POWER SUPPLY
73	Y	-	INTAKE VALVE TIMING CONTROL SOLENOID VALVE (BANK 2)
76	R/G	-	SENSOR POWER SUPPLY
77	W/L	-	POWER SUPPLY FOR ECM (BACK-UP)
78	R/L	-	INTAKE VALVE TIMING CONTROL SOLENOID VALVE (BANK 1)

Connector No.	F12
Connector Name	ENGINE INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	TH2BFW-C5Z-M4



Terminal No.	Color	Wire	Signal Name [Specification]
48	W	-	-
49	R/B	-	-
51	LG	-	-
52	Y/G	-	-
53	R/W	-	-
54	G/W	-	-

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

AUTOMATIC AIR CONDITIONING SYSTEM

56	W/L	-
57	R/L	-
58	O	-
59	Y	-
60	W/B	-
70	O	-
72	R/B	-
75	LG	-
76	SB	-
77	GR	-
80	B	-

Connector No.	F18
Connector Name	COMPRESSOR
Connector Type	HS02EB



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	B	-

Connector No.	F12I
Connector Name	WIRE TO WIRE
Connector Type	NS10FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B/Y	-
2	R/Y	-
5	R/W	-
6	B	-
7	R/G	-


10	B	-
----	---	---

Connector No.	F123
Connector Name	WIRE TO WIRE
Connector Type	TK10FGY-1V



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
3	G/R	-
4	G/B	-
5	R	-
6	L/R	-
8	P	-
10	Y/B	-
11	BR/W	-
12	BR	-
13	G	-
14	B	-

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS30FW-AM




Terminal No.	Color Of Wire	Signal Name [Specification]
1A	Y	-
2A	G	-
3A	Y	-
4A	GR	-
7A	LG	-
8A	Y	-

Connector No.	M2
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS10FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
10	Y	-
11	G	-
12	L	-
13	Y	-
14	GR	-

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS12FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
10C	SB	-
11C	R	-
12C	O	-
13C	BR	-
14C	G	-
15C	GR	-

Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Type	TH10FW-CS10-M3



Terminal No.	Color Of Wire	Signal Name [Specification]
3	BR	-
5	BR	-
6	OD	-
8	G	-
11	P	-
12	L	-
13	V	-
14	Y	-
15	R	-
20	W	-
21	BR	-
22	LG	-
24	Y	-
28	BR	-
29	R	-
38	R	-
39	L	-
40	B	-
47	P	-
48	L	-
49	W	-
50	GR	-
51	LG	-
52	Y	-
53	SB	-
55	P	-
56	LG	-
60	V	-
61	GR	-
62	BR	-
63	V	-

AUTOMATIC AIR CONDITIONING SYSTEM


84	SHIELD	-
85	W	-
86	B	-
87	W	-
88	W	-
89	P	-
90	W	-
91	G	-
92	G	-
93	L	-
94	W	-
95	BR	-
96	R	-
97	G	-
98	Y	-
99	G	-
100	W	-
101	W	-
102	W	-
103	W	-
104	BG	-

Connector No.	M24
Connector Name	COMBINATION METER
Connector Type	TH40FW-NH



Terminal No.	Color	Wire	Signal Name [Specification]
1	G	LG	BATTERY POWER SUPPLY
2	G	SP	IGNITION
3	B	Y	GROUND
4	B	Y	GROUND
5	SB	BR	ILLUMINATION CONTROL SIGNAL
8	SB	BR	TRIP RESET SIGNAL
9	W	BR	SW ILL POWER
10	LG	BR	METER CONTROL SWITCH GROUND
11	L	BR	ENTER SWITCH SIGNAL
12	R	BR	SELECT SWITCH SIGNAL
13	V	GR	ILLUMINATION CONTROL SWITCH SIGNAL (-)
14	GR	GR	ILLUMINATION CONTROL SWITCH SIGNAL (+)
15	BR	GR	AIR BAG SIGNAL
16	L	GR	AMBIENT SENSOR SIGNAL
18	L	GR	AMBIENT SENSOR POWER
19	Y	GR	AMBIENT SENSOR GROUND
20	Y	GR	AMBIENT SENSOR GROUND
21	L	GR	CAN-T
22	P	GR	CAN-T
23	B	GR	GROUND
24	W	GR	FUEL LEVEL SENSOR GROUND
25	BR	GR	ALTERNATOR SIGNAL
26	G	GR	PARKING BRAKE SWITCH SIGNAL
27	V	GR	WASHER FLUID LEVEL SWITCH SIGNAL
29	R	GR	WASHER LEVEL SWITCH SIGNAL
30	P	GR	VEHICLE SPEED SIGNAL (2-PULSE)
31	V	GR	VEHICLE SPEED SIGNAL (8-PULSE)
32	LG	GR	OVERDRIVE CONTROL SWITCH SIGNAL
34	G	GR	FUEL LEVEL SENSOR SIGNAL
35	SB	GR	SEAT BELT BUOGE SWITCH SIGNAL (DRIVER SIDE)
36	R	GR	SEAT BELT BUOGE SWITCH SIGNAL (PASSENGER SIDE)

Connector No.	M16
Connector Name	A/C DISPLAY
Connector Type	TH16FB-NH



Terminal No.	Color	Wire	Signal Name [Specification]
1	B	GR	GROUND
6	G	IGN	IGN
8	R	ILL+	ILL+
9	BR	ILL-	ILL-
10	L	RX (AMP DISP)	RX (AMP DISP)

Connector No.	M41
Connector Name	IN-VEHICLE SENSOR
Connector Type	AB2FW



Terminal No.	Color	Wire	Signal Name [Specification]
1	LG	-	-
2	SP	-	-[Without colour display]
3	Y	-	-[With colour display]

Connector No.	M42
Connector Name	INTAKE SENSOR
Connector Type	CD2FW



Terminal No.	Color	Wire	Signal Name [Specification]
1	G	LG	-[With colour display]
2	SB	SB	-[Without colour display]
3	Y	Y	-[With colour display]

Connector No.	M50
Connector Name	A/C AUTO AMP.
Connector Type	SAB46FW



Terminal No.	Color	Wire	Signal Name [Specification]
1	L	GR	CAN-H
2	P	GR	CAN-L
3	Y	GR	RX (AMP SW & DISP)
7	P	GR	RX (SW AMP)
10	G	LAN SIG	LAN SIG [Without colour display]
11	R	LAN SIG	LAN SIG [With colour display]
11	R	GR	VACTR
15	BR	GR	SUN SENS
16	G	GR	INTAKE SENS [With colour display]
16	R	GR	INTAKE SENS [Without colour display]
19	B	GR	GROUND
20	G	IGN	IGN
26	GR	RR DEF F/B	RR DEF F/B
27	BR	RR DEF ON	RR DEF ON
27	L	AMB POWER	AMB POWER [Without colour display]
34	V	AMB POWER	AMB POWER [With colour display]
35	L	AMB SENS	AMB SENS [Without colour display]
35	L	AMB SENS	AMB SENS [With colour display]
36	LG	INCAR SENS	INCAR SENS
37	SB	SENS GND	SENS GND [Without colour display]
37	Y	SENS GND	SENS GND [With colour display]
39	B	GND (POWER)	GND (POWER)
40	Y	BAT	BAT

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


HAC

AUTOMATIC AIR CONDITIONING SYSTEM

Connector No.	M74
Connector Name	SUNLOAD SENSOR
Connector Type	K02FB




Connector No.	M95
Connector Name	A/C CONTROL
Connector Type	TH12FW-NH




Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	-
2	Y	- [Without colour display] - [With colour display]

Connector No.	M84
Connector Name	WIRE TO WIRE
Connector Type	A03MW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	B	-
3	G	- [Without colour display] - [With colour display]

Connector No.	M75
Connector Name	MULTIFUNCTION SWITCH
Connector Type	TH18FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	GROUND
2	R	ACC
3	R	ACC
4	R	ILL
5	B	ILL CONT
6	SB	AV COMM (H)
8	LG	AV COMM (L)
9	V	SW GND
14	W	EJECT SIGNAL

Connector No.	M77
Connector Name	AV CONTROL UNIT
Connector Type	TH24FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
36	GR	SIGNAL VCG
37	SB	SIGNAL GND
38	G	HP
39	L	COMM (DISC CONT)
41	L	RGB PARENT SIGNAL
42	SHIELD	SHIELD
43	B	RGB SYNC
44	G	RGB (RED) SIGNAL
45	L	RGB (G.GREEN) SIGNAL
46	W	RGB (B.BLUE) SIGNAL
47	R	-

48	Y	INVERTER VCG
49	BR	INVERTER GND
50	R	VP
51	LG	-
52	B	-
57	SHIELD	SHIELD
58	B	-


Connector No.	M174
Connector Name	AV CONTROL UNIT
Connector Type	TH32FW-NH




Terminal No.	Color Of Wire	Signal Name [Specification]
76	LG	AV COMM (L)
77	SB	AV COMM (H)
78	LG	AV COMM (L)
79	SB	AV COMM (H)
80	P	CAN-L
81	P	CAN-H
82	V	SW GND
86	SHIELD	SHIELD
87	R	TEL VOICE SIGNAL (+)
88	L	TEL VOICE SIGNAL (-)
92	V	VEHICLE SPEED SIGNAL (8-PULSE)
93	G	PARKING BRAKE [Without BOSE system]
94	SB	REVERSE
95	G	IGNITION
96	W	DISK EJECT SIGNAL
102	W	AUX SOUND SIGNAL GND
103	B	AUX SOUND SIGNAL LH (+)
104	R	AUX SOUND SIGNAL RH (+)

AUTOMATIC AIR CONDITIONING SYSTEM


Connector No.	M180
Connector Name	AV CONTROL UNIT
Connector Type	TH3FEW-NH




Connector No.	M322
Connector Name	WIRE TO WIRE
Connector Type	A03FW



Connector No.	M326
Connector Name	AIR MIX DOOR MOTOR LH
Connector Type	A03FW




Connector No.	M328
Connector Name	UPPER VENT DOOR MOTOR
Connector Type	A03FW



Terminal No.	Color Of Wire	Signal Name [Specification]
65	LG	PARKING BRAKE
66	LG	—
67	LG	—
71	SHIELD	SHIELD
72	B	MICROPHONE VCC
73	R	COMM CONT- (DISP)
74	P	CAN-L
75	LG	AV COMM (L)
76	LG	AV COMM (L)
79	R	ILLUMINATION SIGNAL
80	G	IGNITION
81	SB	REVERSE
82	V	VEHICLE SPEED SIGNAL (P-PULSE)
83	B	—
87	W	—
88	W	MICROPHONE SIGNAL
89	W	—
80	L	CAN-H
81	SB	AV COMM (H)
82	SB	AV COMM (H)


Terminal No.	Color Of Wire	Signal Name [Specification]
1	—	—
2	—	—
3	—	—

Connector No.	M304
Connector Name	INTAKE DOOR MOTOR
Connector Type	A03FW




Terminal No.	Color Of Wire	Signal Name [Specification]
1	—	—
2	—	—
3	—	—

Connector No.	M307
Connector Name	AIR MIX DOOR MOTOR RH
Connector Type	A03FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	—
2	B	—
3	L	—

Connector No.	M310
Connector Name	MODE DOOR MOTOR
Connector Type	A03FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	—	—
2	—	—
3	—	—

Terminal No.	Color Of Wire	Signal Name [Specification]
1	—	—
2	—	—
3	—	—

Terminal No.	Color Of Wire	Signal Name [Specification]
1	—	—
2	—	—
3	—	—

Fail-Safe

FAIL-SAFE FUNCTION

If a communication error exists between the A/C auto amp. and A/C control for 30 seconds or longer, air conditioner is controlled under the following conditions:

JRIWC1467GB

INFOID:000000009722104

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

A/C AUTO AMP.

< ECU DIAGNOSIS INFORMATION >

[WITHOUT 7 INCH DISPLAY]

Compressor : ON
Air outlet : AUTO
Air inlet : FRE (Fresh air intake)
Fan speed : AUTO
Set temperature : Setting before communication error occurs

DTC Inspection Priority Chart

INFOID:000000009722105

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	Detected items (DTC)
1	<ul style="list-style-type: none"> • U1000: CAN COMM CIRCUIT • U1010: CONTROL UNIT (CAN)
2	<ul style="list-style-type: none"> • B2578: IN-VEHICLE SENSOR • B2579: IN-VEHICLE SENSOR • B257B: AMBIENT SENSOR • B257C: AMBIENT SENSOR • B2581: INTAKE SENSOR • B2582: INTAKE SENSOR • B2630: SUNLOAD SENSOR • B2631: SUNLOAD SENSOR • B2632: DR AIR MIX DOOR MOT • B2633: DR AIR MIX DOOR MOT • B2634: PASS AIR MIX DOOR MOT • B2635: PASS AIR MIX DOOR MOT • B2636: DR VENT DOOR FAIL • B2637: DR B/L DOOR FAIL • B2638: DR D/F1 DOOR FAIL • B2639: DR DEF DOOR FAIL • B263D: FRE DOOR FAIL • B263E: 20P FRE DOOR FAIL • B263F: REC DOOR FAIL • B2654: D/F2 DOOR FAIL • B2655: B/L2 DOOR FAIL • B2661: UPPER VENT DOOR MOT • B2662: UPPER VENT DOOR MOT • B2663: UPPER VENT DOOR MOT

DTC Index

INFOID:000000009722106

DTC	Items (CONSULT screen terms)	Reference
U1000	CAN COMM CIRCUIT	HAC-44, "DTC Logic"
U1010	CONTROL UNIT (CAN)	HAC-45, "DTC Logic"
B2578	IN-VEHICLE SENSOR	HAC-49, "DTC Logic"
B2579	IN-VEHICLE SENSOR	HAC-49, "DTC Logic"
B257B	AMBIENT SENSOR	HAC-46, "DTC Logic"
B257C	AMBIENT SENSOR	HAC-46, "DTC Logic"
B2581	INTAKE SENSOR	HAC-52, "DTC Logic"
B2582	INTAKE SENSOR	HAC-52, "DTC Logic"
B2630*	SUNLOAD SENSOR	HAC-55, "DTC Logic"
B2631*	SUNLOAD SENSOR	HAC-55, "DTC Logic"
B2632	DR AIR MIX DOOR MOT	HAC-58, "DTC Logic"
B2633	DR AIR MIX DOOR MOT	HAC-58, "DTC Logic"

A/C AUTO AMP.

< ECU DIAGNOSIS INFORMATION >

[WITHOUT 7 INCH DISPLAY]

DTC	Items (CONSULT screen terms)	Reference
B2634	PASS AIR MIX DOOR MOT	HAC-60, "DTC Logic"
B2635	PASS AIR MIX DOOR MOT	HAC-60, "DTC Logic"
B2636	DR VENT DOOR FAIL	HAC-62, "DTC Logic"
B2637	DR B/L DOOR FAIL	HAC-62, "DTC Logic"
B2638	DR D/F1 DOOR FAIL	HAC-62, "DTC Logic"
B2639	DR DEF DOOR FAIL	HAC-62, "DTC Logic"
B263D	FRE DOOR FAIL	HAC-65, "DTC Logic"
B263E	20P FRE DOOR FAIL	HAC-65, "DTC Logic"
B263F	REC DOOR FAIL	HAC-65, "DTC Logic"
B2654	D/F2 DOOR FAIL	HAC-62, "DTC Logic"
B2655	B/L2 DOOR FAIL	HAC-62, "DTC Logic"
B2661	UPPER VENT DOOR MOT	HAC-67, "DTC Logic"
B2662	UPPER VENT DOOR MOT	HAC-67, "DTC Logic"
B2663	UPPER VENT DOOR MOT	HAC-67, "DTC Logic"

*: Perform self-diagnosis under sunshine. When performing indoors, aim a light (more than 60 W) at sunload sensor, otherwise self-diagnosis indicates even though the sunload sensor is functioning normally.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

AIR CONDITIONER CONTROL

< SYMPTOM DIAGNOSIS >

[WITHOUT 7 INCH DISPLAY]

SYMPTOM DIAGNOSIS

AIR CONDITIONER CONTROL

Diagnosis Chart By Symptom

INFOID:000000009722107

Symptom	Reference	
A/C system does not activate.	Go to Trouble Diagnosis Procedure for A/C Control Signal Circuit.	HAC-76. "Diagnosis Procedure"
A/C display dose not work.	Go to Trouble Diagnosis Procedure for A/C Display.	HAC-79. "A/C DISPLAY : Diagnosis Procedure"
Air outlet does not change.	Go to Trouble Diagnosis Procedure for Mode Door Motor. (LAN)	HAC-63. "Diagnosis Procedure"
Mode door motor does not operate normally.		
Discharge air temperature does not change.	Go to Trouble Diagnosis Procedure for Air Mix Door Motor. (LAN)	HAC-59. "Diagnosis Procedure" (driver side) or HAC-61. "Diagnosis Procedure" (passenger side)
Air mix door motor does not operate normally.		
Intake door does not change.	Go to Trouble Diagnosis Procedure for Intake Door Motor. (LAN)	HAC-66. "Diagnosis Procedure"
Intake door motor does not operate normally.		
Blower motor operation is malfunctioning.	Go to Trouble Diagnosis Procedure for Blower Motor.	HAC-70. "Diagnosis Procedure"
Magnet clutch does not engage.	Go to Trouble Diagnosis Procedure for Magnet Clutch.	HAC-74. "Diagnosis Procedure"
Insufficient cooling	Go to Trouble Diagnosis Procedure for Insufficient Cooling.	HAC-109. "Inspection procedure"
No cool air comes out. (Air flow volume is normal.)		
Insufficient heating	Go to Trouble Diagnosis Procedure for Insufficient Heating.	HAC-112. "Inspection procedure"
No warm air comes out. (Air flow volume is normal.)		
Noise	Go to Trouble Diagnosis Procedure for Noise.	HAC-115. "Inspection procedure"
Memory function does not operate.	Go to Trouble Diagnosis Procedure for Memory Function.	HAC-117. "Inspection procedure"

INSUFFICIENT COOLING

[WITHOUT 7 INCH DISPLAY]

< SYMPTOM DIAGNOSIS >

INSUFFICIENT COOLING

Description

INFOID:000000009722108

Symptom

- Insufficient cooling
- No cool air comes out. (Air flow volume is normal.)

Inspection procedure

INFOID:000000009722109

1.CHECK WITH A GAUGE OF RECOVERY/RECYCLING RECHARGING EQUIPMENT

Connect the recovery/recycling recharging equipment to the vehicle and perform the pressure inspection with the gauge.

Is there refrigerant?

YES >> GO TO 2.

NO-1 >> Check for refrigerant leakages with the refrigerant leakage detecting fluorescent leak detector. Refer to [HA-30, "Inspection"](#).

NO-2 >> GO TO 2 after repairing or replacing the parts according to the inspection results.

2.CHECK CHARGED REFRIGERANT AMOUNT

1. Connect recovery/recycling recharging equipment to the vehicle and discharge the refrigerant.
2. Recharge with the proper amount of refrigerant and perform the inspection with the refrigerant leakage detecting fluorescent leak detector. Refer to [HA-30, "Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Refill the refrigerant and repair or replace the parts according to the inspection results.

3.CHECK REFRIGERANT CYCLE PRESSURE

Connect recovery/recycling recharging equipment to the vehicle and perform the performance test. Refer to [HA-28, "Performance Chart"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Perform the diagnosis with the gauge pressure. Refer to [HA-8, "Trouble Diagnosis For Unusual Pressure"](#).

4.CHECK SETTING OF TEMPERATURE SETTING TRIMMER

Using CONSULT, check the setting of "TEMP SET CORRECT" on "WORK SUPPORT" of HVAC. Refer to [HAC-10, "Temperature Setting Trimmer"](#).

1. Check that the temperature setting trimmer is set to "+ direction".

NOTE:

The control temperature can be set with the setting of the temperature setting trimmer.

2. Set temperature control dial to "0".

Are the malfunction solved?

YES >> Perform the setting separately if necessary. END.

NO >> GO TO 5.

5.CHECK WITH SELF-DIAGNOSIS FUNCTION OF CONSULT

1. Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
2. Check if any DTC No. is displayed in the trouble diagnosis results.

NOTE:

If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-44, "DTC Logic"](#) or [HAC-45, "DTC Logic"](#).

Is any DTC No. displayed?

YES >> Perform the diagnosis that is applicable to the sensor and the door motor. Refer to [HAC-106, "DTC Index"](#).

NO >> GO TO 6.

6.CHECK WITH ACTIVE TEST OF CONSULT

A

B

C

D

E

F

G

H

HAC

J

K

L

M

N

O

P

INSUFFICIENT COOLING

< SYMPTOM DIAGNOSIS >

[WITHOUT 7 INCH DISPLAY]

- Using CONSULT, perform "HVAC TEST" "ACTIVE TEST" of HVAC to check each output device. Refer to [HAC-40, "CONSULT Function"](#).

NOTE:

Perform the ACTIVE TEST after starting the engine because the compressor is operated.

- Refer to the table and check the outlet, inlet, air flow temperature, blower motor control signal, magnet clutch operation, and air mix ratio. Visually check each operating condition, by listening for noise, touching air outlets with a hand, etc.

	Test item						
	MODE 1	MODE 2	MODE 3	MODE 4	MODE 5	MODE 6	MODE 7
Mode door position	VENT1	VENT2	B/L1	B/L2	FOOT	D/F	DEF
Intake door position	REC	REC	20%FRE	20%FRE	FRE	FRE	FRE
Air mix door position (driver & passenger side)	FULL COLD	FULL HOT	FULL COLD	FULL HOT	FULL HOT	FULL HOT	FULL HOT
Blower motor duty ratio	35%	35%	61%	61%	81%	81%	35%
Compressor (Magnet clutch)	ON	ON	ON	ON	OFF	OFF	ON
Upper ventilator door	OPEN	SHUT	OPEN	SHUT	SHUT	SHUT	SHUT

NOTE:

Perform the inspection of each output device after starting the engine because the compressor is operated.

Discharge air flow							
Mode position indication	Condition	Air outlet/distribution					
		VENT			FOOT		DEF
		Front	Upper	Rear	Front	Rear	
	DUAL switch: OFF UPPER VENT switch : ON	81%	8%	11%	—	—	—
		41%	10%	17%	24%	8%	—
		12%	12%	16%	27%	10%	23%
		11%	11%	14%	25%	10%	29%
		11%	11%	12%	—	—	66%

JPIIA0509GB

Discharge air flow							
Mode position indication	Condition	Air outlet/distribution					
		VENT			FOOT		DEF
		Front	Upper	Rear	Front	Rear	
	DUAL switch: OFF UPPER VENT switch : OFF	88%	—	12%	—	—	—
		47%	—	18%	26%	9%	—
		13%	—	17%	33%	12%	25%
		12%	—	16%	28%	12%	32%
		11%	—	15%	—	—	74%

JPIIA0510GB

Does it operate normally?

YES >> GO TO 7.

INSUFFICIENT COOLING

< SYMPTOM DIAGNOSIS >

[WITHOUT 7 INCH DISPLAY]

- NO-1 >> Air outlet does not change. Refer to [HAC-63, "Diagnosis Procedure"](#).
- NO-2 >> Air inlet does not change. Refer to [HAC-66, "Diagnosis Procedure"](#).
- NO-3 >> Discharge air temperature does not change. Refer to [HAC-59, "Diagnosis Procedure"](#) and [HAC-61, "Diagnosis Procedure"](#).
- NO-4 >> Blower motor does not operate normally. Refer to [HAC-70, "Diagnosis Procedure"](#).
- NO-5 >> Magnet clutch does not operate. Refer to [HAC-74, "Diagnosis Procedure"](#).

A
B

7. CHECK AMBIENT TEMPERATURE DISPLAY

Check that there is not much difference between actual ambient temperature and indicated temperature on information display in combination meter.

Is the inspection result normal?

- YES >> GO TO 8.
- NO >> Perform the diagnosis for the A/C auto amp. connection recognition signal. Refer to [MWI-56, "Diagnosis Procedure"](#).

C
D

8. CHECK DRIVE BELT

Check tension of the drive belt. Refer to [EM-17, "Checking"](#).

Is the inspection result normal?

- YES >> GO TO 9.
- NO >> Adjust or replace drive belt.

E
F

9. CHECK AIR LEAKAGE FROM DUCT

Check duct and nozzle, etc, of the A/C system for air leakage.

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> Repair or replace parts according to the inspection results.

G
H

HAC

J
K
L
M
N
O
P

INSUFFICIENT HEATING

Description

INFOID:000000009722110

Symptom

- Insufficient heating
- No warm air comes out. (Air flow volume is normal.)

Inspection procedure

INFOID:000000009722111

1. CHECK COOLING SYSTEM

1. Check engine coolant level and check for leakage. Refer to [CO-11, "Inspection"](#).
2. Check radiator cap. Refer to [CO-15, "RADIATOR CAP : Inspection"](#).
3. Check water flow sounds of engine coolant. Refer to [CO-12, "Refilling"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Refill the engine coolant and repair or replace the parts according to the inspection results.

2. CHECK OPERATION

1. Press temperature switch (driver side) and raise temperature setting to 32°C (90°F) after warming up the engine.
2. Check that warm air blows from the outlets.

Is the inspection result normal?

- YES >> INSPECTION END
NO >> GO TO 3.

3. CHECK SETTING OF TEMPERATURE SETTING TRIMMER

Using CONSULT, check the setting of "TEMP SET CORRECT" on "WORK SUPPORT" of HVAC. Refer to [HAC-10, "Temperature Setting Trimmer"](#).

1. Check that the temperature setting trimmer is set to "– direction".
NOTE:
The control temperature can be set by the temperature setting trimmer.
2. Set temperature control dial to "0".

Are the malfunction solved?

- YES >> Perform the setting separately if necessary. END.
NO >> GO TO 4.

4. CHECK WITH SELF-DIAGNOSIS FUNCTION OF CONSULT

1. Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
2. Check if any DTC No. is displayed in the trouble diagnosis results.

NOTE:

If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-44, "DTC Logic"](#) or [HAC-45, "DTC Logic"](#).

Is any DTC No. displayed?

- YES >> Perform the diagnosis that is applicable to the sensor and the door motor. Refer to [HAC-106, "DTC Index"](#).
NO >> GO TO 5.

5. CHECK WITH ACTIVE TEST OF CONSULT

1. Using CONSULT, perform "HVAC TEST" in "ACTIVE TEST" of HVAC to check each output device. Refer to [HAC-40, "CONSULT Function"](#).

NOTE:

Perform the ACTIVE TEST after starting the engine because the compressor is operated.

2. Refer to the table and check the outlet, inlet, air flow temperature, blower motor control signal, magnet clutch operation, and air mix ratio. Visually check each operating condition, by listening for noise, touching air outlets with a hand, etc.

INSUFFICIENT HEATING

< SYMPTOM DIAGNOSIS >

[WITHOUT 7 INCH DISPLAY]

	Test item						
	MODE 1	MODE 2	MODE 3	MODE 4	MODE 5	MODE 6	MODE 7
Mode door position	VENT1	VENT2	B/L1	B/L2	FOOT	D/F	DEF
Intake door position	REC	REC	20%FRE	20%FRE	FRE	FRE	FRE
Air mix door position (driver & passenger side)	FULL COLD	FULL HOT	FULL COLD	FULL HOT	FULL HOT	FULL HOT	FULL HOT
Blower motor duty ratio	35%	35%	61%	61%	81%	81%	35%
Compressor (Magnet clutch)	ON	ON	ON	ON	OFF	OFF	ON
Upper ventilator door	OPEN	SHUT	OPEN	SHUT	SHUT	SHUT	SHUT

NOTE:

Perform the inspection of each output device after starting the engine because the compressor is operated.

Discharge air flow							
Mode position indication	Condition	Air outlet/distribution					
		VENT			FOOT		DEF
		Front	Upper	Rear	Front	Rear	
	DUAL switch: OFF UPPER VENT switch : ON	81%	8%	11%	—	—	—
		41%	10%	17%	24%	8%	—
		12%	12%	16%	27%	10%	23%
		11%	11%	14%	25%	10%	29%
		11%	11%	12%	—	—	66%

JPIIA0509GB

Discharge air flow							
Mode position indication	Condition	Air outlet/distribution					
		VENT			FOOT		DEF
		Front	Upper	Rear	Front	Rear	
	DUAL switch: OFF UPPER VENT switch : OFF	88%	—	12%	—	—	—
		47%	—	18%	26%	9%	—
		13%	—	17%	33%	12%	25%
		12%	—	16%	28%	12%	32%
		11%	—	15%	—	—	74%

JPIIA0510GB

Does it operate normally?

- YES >> GO TO 6.
- NO-1 >> Air outlet does not change. Refer to [HAC-63. "Diagnosis Procedure"](#).
- NO-2 >> Air inlet does not change. Refer to [HAC-66. "Diagnosis Procedure"](#).
- NO-3 >> Discharge air temperature does not change. Refer to [HAC-59. "Diagnosis Procedure"](#) and [HAC-61. "Diagnosis Procedure"](#).
- NO-4 >> Blower motor does not operate normally. Refer to [HAC-70. "Diagnosis Procedure"](#).
- NO-5 >> Magnet clutch does not operate. Refer to [HAC-74. "Diagnosis Procedure"](#).

INSUFFICIENT HEATING

< SYMPTOM DIAGNOSIS >

[WITHOUT 7 INCH DISPLAY]

6.CHECK AIR LEAKAGE FROM DUCT

Check duct and nozzle, etc, of the A/C system for air leakage.

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace parts according to the inspection results.

7.CHECK HEATER HOSE INSTALLATION CONDITION

Check the heater hose installation condition visually (for twists, crushes, etc.).

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair or replace parts according to the inspection results.

8.CHECK TEMPERATURE OF HEATER HOSE

1. Check the temperature of inlet hose and outlet hose of heater core.
2. Check that the inlet side of heater core is hot and the outlet side is slightly lower than/almost equal to the inlet side.

CAUTION:

Always perform the temperature inspection in a short period of time because the engine coolant temperature is very hot.

Is the inspection result normal?

YES >> GO TO 9.

NO >> Replace the heater core after performing the procedures after the cooling system inspection. GO TO 1.

9.REPLACE HEATER CORE

Replace the heater core. Refer to heater core. Refer to [VTL-47, "Exploded View"](#).

Are the malfunction solved?

YES >> INSPECTION END

NO >> Perform the procedures again after the cooling system inspection. GO TO 1.

NOISE**Description**

INFOID:000000009722112

Symptom

- Noise
- Noise is heard when the A/C system operates.

Inspection procedure

INFOID:000000009722113

1.CHECK OPERATION

1. Operate the A/C system and check the operation. Refer to [HAC-8. "Description & Inspection"](#).
2. Check the parts where noise is occurring.

Can the parts where noise is occurring be checked?

- YES-1 >> Noise from blower motor: GO TO 2.
 YES-2 >> Noise from compressor: GO TO 3.
 YES-3 >> Noise from expansion valve: GO TO 4.
 YES-4 >> Noise from A/C piping (pipe, flexible hose): GO TO 6.
 YES-5 >> Noise from drive belt: GO TO 7.
 NO >> INSPECTION END

2.CHECK BLOWER MOTOR

1. Remove blower motor.
2. Remove foreign materials that are in the blower unit.
3. Check the noise from blower motor again.

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> Replace blower motor.

3.CHECK COMPRESSOR

Perform trouble diagnosis for the compressor and check the compressor. Refer to [HA-11. "Symptom Table"](#).

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> Refill the refrigerant or replace the compressor according to the inspection results.

4.CHECK WITH GAUGE PRESSURE

Perform the diagnosis with the gauge pressure. Refer to [HA-8. "Trouble Diagnosis For Unusual Pressure"](#).

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> Repair or replace parts according to the inspection results.

5.CHECK EXPANSION VALVE

1. Correct the refrigerant with recovery/recycling recharging equipment.
2. Recharge with the proper amount of the collected refrigerant after recycling or new refrigerant.
3. Check for the noise from expansion valve again.

Are the malfunction solved?

- YES >> INSPECTION END
 NO >> Replace expansion valve.

6.CHECK A/C PIPING (PIPE, FLEXIBLE HOSE)

1. Check the A/C piping (pipes, flexible hoses) (for deformation and damage, etc.).
2. Check the installation condition of clips and brackets, etc, of the A/C piping (pipes, flexible hoses).

Is the inspection result normal?

- YES >> Fix the line with rubber or come vibration absorbing material.
 NO >> Repair or replace parts according to the inspection results.

7.CHECK DRIVE BELTA
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

NOISE

[WITHOUT 7 INCH DISPLAY]

< SYMPTOM DIAGNOSIS >

Check tension of the drive belt. Refer to [EM-17. "Checking"](#).

Is the inspection result normal?

YES >> Check the noise from compressor: GO TO 3.

NO >> Adjust or replace drive belt according to the inspection results.

MEMORY FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[WITHOUT 7 INCH DISPLAY]

MEMORY FUNCTION DOES NOT OPERATE

Description

INFOID:000000009722114

Symptom

- Memory function does not operate normally.
- The setting is not maintained. (It returns to the initial condition.)

Inspection procedure

INFOID:000000009722115

1. CHECK OPERATION

1. Set temperature control switch to 32°C (90°F).
2. Press the ON/OFF switch.
3. Turn the ignition switch OFF.
4. Turn the ignition switch ON.
5. Press the AUTO switch.
6. Check that the set temperature is maintained.

Is the inspection result normal?

- YES >> INSPECTION END
NO >> GO TO 2.

2. CHECK POWER SUPPLY AND GROUND CIRCUIT OF A/C AUTO AMP.

Check power supply and ground circuit of the A/C auto amp. Refer to [HAC-77. "A/C AUTO AMP. : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> Replace the A/C auto amp.
NO >> Repair or replace malfunctioning parts.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

PRECAUTIONS

< PRECAUTION >

[WITHOUT 7 INCH DISPLAY]

PRECAUTION

PRECAUTIONS

FOR USA AND CANADA

FOR USA AND CANADA : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009722116

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

FOR USA AND CANADA : Precautions for Removing of Battery Terminal

INFOID:000000010092838

- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.

NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.


NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.



FOR USA AND CANADA : Working with HFC-134a (R-134a)

INFOID:000000009722117

CAUTION:

- CFC-12 (R-12) refrigerant and HFC-134a (R-134a) refrigerant are not compatible. Compressor malfunction is likely to occur if the refrigerants are mixed, refer to "CONTAMINATED REFRIGERANT"

PRECAUTIONS

< PRECAUTION >

[WITHOUT 7 INCH DISPLAY]

- below. To determine the purity of HFC-134a (R-134a) in the vehicle and recovery tank, use Refrigerant Recovery/Recycling Recharging equipment and Refrigerant Identifier.
- Use only specified lubricant for the HFC-134a (R-134a) A/C system and HFC-134a (R-134a) components. Compressor malfunction is likely to occur if lubricant other than that specified is used.
 - The specified HFC-134a (R-134a) lubricant rapidly absorbs moisture from the atmosphere. The following handling precautions must be observed:
 - Immediately cap (seal) the component to minimize the entry of moisture from the atmosphere when removing refrigerant components from a vehicle.
 - Never remove the caps (unseal) until just before connecting the components when installing refrigerant components to a vehicle. Connect all refrigerant loop components as quickly as possible to minimize the entry of moisture into system.
 - Use only the specified lubricant from a sealed container. Immediately reseal containers of lubricant. Lubricant becomes moisture saturated and should not be used without proper sealing.
 - Never allow lubricant (NISSAN A/C System Oil Type S) to come in to contact with styrene foam parts. Damage may result.

CONTAMINATED REFRIGERANT

Take the appropriate steps shown below if a refrigerant other than pure HFC-134a (R-134a) is identified in a vehicle:

- Explain to the customer that environmental regulations prohibit the release of contaminated refrigerant into the atmosphere.
- Explain that recovery of the contaminated refrigerant could damage service equipment and refrigerant supply.
- Suggest the customer return the vehicle to the location of previous service where the contamination may have occurred.
- If repairing, recover the refrigerant using only **dedicated equipment and containers. Never reintroduce contaminated refrigerant into the existing service equipment.** Contact a local refrigerant product retailer for available service if the facility does not have dedicated recovery equipment. This refrigerant must be disposed of in accordance with all federal and local regulations. In addition, replacement of all refrigerant system components on the vehicle is recommended.
- The air conditioner warranty is void if the vehicle is within the warranty period. Please contact Nissan Customer Affairs for further assistance.

FOR USA AND CANADA : General Refrigerant Precaution

INFOID:000000009722118

WARNING:

- **Never breath A/C refrigerant, lubricant vapor or mist. Exposure may irritate eyes, nose and throat. Remove HFC-134a (R-134a) from the A/C system, using certified service equipment meeting requirements of SAE J-2210 [HFC-134a (R-134a) recycling equipment], or J-2209 [HFC-134a (R-134a) recovery equipment]. Ventilate work area before resuming service if accidental system discharge occurs. Additional health and safety information may be obtained from refrigerant and lubricant manufacturers.**
- **Never release refrigerant into the air. Use approved recovery/recycling equipment to capture the refrigerant each time an air conditioning system is discharged.**
- **Always wear eye and hand protection (goggles and gloves) when working with any refrigerant or air conditioning system.**
- **Never store or heat refrigerant containers above 52°C (126°F).**
- **Never heat a refrigerant container with an open flame. Place the bottom of the container in a warm pail of water if container warming is required.**
- **Never intentionally drop, puncture, or incinerate refrigerant containers.**
- **Keep refrigerant away from open flames. Poisonous gas is produced if refrigerant burns.**
- **Refrigerant displaces oxygen, therefore be certain to work in well ventilated areas to prevent suffocation.**
- **Never pressure test or leakage test HFC-134a (R-134a) service equipment and/or vehicle air conditioning systems with compressed air during repair. Some mixtures of air and HFC-134a (R-134a) have been shown to be combustible at elevated pressures. These mixtures, if ignited, may cause injury or property damage. Additional health and safety information may be obtained from refrigerant manufacturers.**

FOR USA AND CANADA : Refrigerant Connection

INFOID:000000009722119

A new type refrigerant connection has been introduced to all refrigerant lines except the following location.


PRECAUTIONS

[WITHOUT 7 INCH DISPLAY]

< PRECAUTION >

- Expansion valve to evaporator
- Refrigerant pressure sensor to liquid tank

O-RING AND REFRIGERANT CONNECTION



F: Former type refrigerant connection N: New type refrigerant connection

○: O-ring size

CAUTION:

The new and former refrigerant connections use different O-ring configurations. Never confuse O-rings since they are not interchangeable. Refrigerant may leak at the connection if a wrong O-ring is installed.

O-Ring Part Numbers and Specifications

Connection type	Piping connection point	Part number	QTY	O-ring size	
New	Low-pressure flexible hose to low-pressure pipe	92474 N8210	1	φ19	
	High-pressure pipe to condenser pipe assembly (Outlet)	92471 N8210	1	φ8	
	Condenser pipe assembly (Inlet) to high-pressure flexible hose (One-touch joint)	92472 N8210	1	φ12	
	Condenser assembly to condenser pipe assembly	Inlet	92472 N8210	1	φ12
		Outlet	92471 N8210	1	φ8
	Low-pressure pipe to expansion valve	92473 N8210	1	φ16	
	High-pressure pipe to expansion valve	92471 N8210	1	φ8	
	Compressor to low-pressure flexible hose	92474 N8210	1	φ19	
	Compressor to high-pressure flexible hose	92472 N8210	1	φ12	
Liquid tank to condenser assembly	Inlet	92471 N8210	1	φ8	
	Outlet		1		

PRECAUTIONS

< PRECAUTION >

[WITHOUT 7 INCH DISPLAY]

Connection type	Piping connection point		Part number	QTY	O-ring size
Former	Refrigerant pressure sensor to liquid tank		J2476 89956	1	φ10
	Expansion valve to evaporator pipe assembly	Inlet	92475 71L00	1	φ12
		Outlet	92475 72L00	1	φ16
	Evaporator to evaporator pipe assembly	Inlet	92475 71L00	1	φ12
		Outlet	92475 72L00	1	φ16

WARNING:

Check that all refrigerant is discharged into the recycling equipment and the pressure in the system is less than atmospheric pressure. Then gradually loosen the discharge side hose fitting and remove it.


CAUTION:

Observe the following when replacing or cleaning refrigerant cycle components.

- Store it in the same way as it is when mounted on the car when the compressor is removed. Failure to do so will cause lubricant to enter the low-pressure chamber.
- Always use a torque wrench and a back-up wrench when connecting tubes.
- Immediately plug all openings to prevent entry of dust and moisture after disconnecting tubes.
- Connect the pipes at the final stage of the operation when installing an air conditioner in the vehicle. Never remove the seal caps of pipes and other components until just before required for connection.
- Allow components stored in cool areas to warm to working area temperature before removing seal caps. This prevents condensation from forming inside A/C components.
- Thoroughly remove moisture from the refrigeration system before charging the refrigerant.
- Replace always used O-rings.
- Apply lubricant to circle of the O-rings shown in illustration when connecting tube. Be careful not to apply lubricant to threaded portion.

Name : NISSAN A/C System Oil Type S

- O-ring must be closely attached to the groove portion of tube.
- Be careful not to damage O-ring and tube when replacing the O-ring.
- Connect tube until a click can be heard. Then tighten the nut or bolt by hand. Check that the O-ring is installed to tube correctly.
- Perform leakage test and make sure that there is no leakage from connections after connecting line. Disconnect the line and replace the O-ring when the refrigerant leaking point is found. Then tighten the connections of seal seat to the specified torque.



FOR USA AND CANADA : Service Equipment

INFOID:000000009722120

RECOVERY/RECYCLING EQUIPMENT

Be certain to follow the manufacturer instructions for machine operation and machine maintenance. Never introduce any refrigerant other than that specified into the machine.

ELECTRICAL LEAK DETECTOR

PRECAUTIONS

[WITHOUT 7 INCH DISPLAY]

< PRECAUTION >


Be certain to follow the manufacturer instructions for tester operation and tester maintenance.

VACUUM PUMP

The lubricant contained inside the vacuum pump is not compatible with the specified lubricant for HFC-134a (R-134a) A/C systems. The vent side of the vacuum pump is exposed to atmospheric pressure. So the vacuum pump lubricant may migrate out of the pump into the service hose. This is possible when the pump is switched OFF after evacuation (vacuuming) and hose is connected to it. To prevent this migration, use a manual valve placed near the hose-to-pump connection, as per the following.


- Vacuum pumps usually have a manual isolator valve as part of the pump. Close this valve to isolate the service hose from the pump.
- Use a hose equipped with a manual shut-off valve near the pump end for pumps without an isolator. Close the valve to isolate the hose from the pump.
- Disconnect the hose from the pump if the hose has an automatic shut-off valve. As long as the hose is connected, the valve is open and lubricating oil may migrate.

Some one-way valves open when vacuum is applied and close under no vacuum condition. Such valves may restrict the ability of the pump to create a deep vacuum and are not recommended.




MANIFOLD GAUGE SET

Be certain that the gauge face indicates HFC-134a or R-134a. Be sure the gauge set has 1/2"-16 ACME threaded connections for service hoses. Confirm the set has been used only with refrigerant HFC-134a (R-134a) and specified lubricants.



SERVICE HOSES

Be certain that the service hoses display the markings described (colored hose with a black stripe). All hoses must equip positive shut-off devices (either manual or automatic) near the end of the hoses opposite to the manifold gauge.



SERVICE COUPLERS


PRECAUTIONS

< PRECAUTION >

Never attempt to connect HFC-134a (R-134a) service couplers to a CFC-12 (R-12) A/C system. The HFC-134a (R-134a) couplers do not properly connect to the CFC-12 (R-12) system. However, if an improper connection is attempted, discharge and contamination may occur.


Shut-off valve rotation	A/C service valve
Clockwise	Open
Counterclockwise	Close

[WITHOUT 7 INCH DISPLAY]



REFRIGERANT WEIGHT SCALE

Verify that no refrigerant other than HFC-134a (R-134a) and specified lubricants have been used with the scale. The hose fitting must be 1/2"-16 ACME if the scale controls refrigerant flow electronically.



CHARGING CYLINDER

Use of a charging cylinder is not recommended. Refrigerant may be vented into the air from the top valve of the cylinder when filling the cylinder with refrigerant. Also, the accuracy of the cylinder is generally less than that of an electronic scale or of quality recycle/recharge equipment.

FOR MEXICO

FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009722121

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

PRECAUTIONS

< PRECAUTION >

[WITHOUT 7 INCH DISPLAY]

FOR MEXICO : Precautions for Removing of Battery Terminal

INFOID:000000010092839

- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.

NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.


NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.



FOR MEXICO : Working with HFC-134a (R-134a)

INFOID:000000009722122

CAUTION:

- **CFC-12 (R-12) refrigerant and HFC-134a (R-134a) refrigerant are not compatible. Compressor malfunction is likely to occur if the refrigerants are mixed, refer to "CONTAMINATED REFRIGERANT" below. To determine the purity of HFC-134a (R-134a) in the vehicle and recovery tank, use Refrigerant Recovery/Recycling Recharging equipment and Refrigerant Identifier.**
- **Use only specified lubricant for the HFC-134a (R-134a) A/C system and HFC-134a (R-134a) components. Compressor malfunction is likely to occur if lubricant other than that specified is used.**
- **The specified HFC-134a (R-134a) lubricant rapidly absorbs moisture from the atmosphere. The following handling precautions must be observed:**
 - **Immediately cap (seal) the component to minimize the entry of moisture from the atmosphere when removing refrigerant components from a vehicle.**
 - **Never remove the caps (unseal) until just before connecting the components when installing refrigerant components to a vehicle. Connect all refrigerant loop components as quickly as possible to minimize the entry of moisture into system.**
 - **Use only the specified lubricant from a sealed container. Immediately reseal containers of lubricant. Lubricant becomes moisture saturated and should not be used without proper sealing.**
 - **Never allow lubricant (NISSAN A/C System Oil Type S) to come in to contact with styrene foam parts. Damage may result.**

CONTAMINATED REFRIGERANT

Take the appropriate steps shown below if a refrigerant other than pure HFC-134a (R-134a) is identified in a vehicle:

- Explain to the customer that environmental regulations prohibit the release of contaminated refrigerant into the atmosphere.
- Explain that recovery of the contaminated refrigerant could damage service equipment and refrigerant supply.
- Suggest the customer return the vehicle to the location of previous service where the contamination may have occurred.
- If repairing, recover the refrigerant using only **dedicated equipment and containers. Never reintroduce contaminated refrigerant into the existing service equipment.** Contact a local refrigerant product retailer for available service if the facility does not have dedicated recovery equipment. This refrigerant must be disposed of in accordance with all federal and local regulations. In addition, replacement of all refrigerant system components on the vehicle is recommended.
- The air conditioner warranty is void if the vehicle is within the warranty period. Please contact Nissan Customer Affairs for further assistance.

FOR MEXICO : General Refrigerant Precaution

INFOID:000000009722123

WARNING:

- **Never breath A/C refrigerant, lubricant vapor or mist. Exposure may irritate eyes, nose and throat. Remove HFC-134a (R-134a) from the A/C system, using certified service equipment meeting require-**

PRECAUTIONS

[WITHOUT 7 INCH DISPLAY]

< PRECAUTION >

- ments of SAE J-2210 [HFC-134a (R-134a) recycling equipment], or J-2209 [HFC-134a (R-134a) recovery equipment]. Ventilate work area before resuming service if accidental system discharge occurs. Additional health and safety information may be obtained from refrigerant and lubricant manufacturers.
- Never release refrigerant into the air. Use approved recovery/recycling equipment to capture the refrigerant each time an air conditioning system is discharged.
 - Always wear eye and hand protection (goggles and gloves) when working with any refrigerant or air conditioning system.
 - Never store or heat refrigerant containers above 52°C (126°F).
 - Never heat a refrigerant container with an open flame. Place the bottom of the container in a warm pail of water if container warming is required.
 - Never intentionally drop, puncture, or incinerate refrigerant containers.
 - Keep refrigerant away from open flames. Poisonous gas is produced if refrigerant burns.
 - Refrigerant displaces oxygen, therefore be certain to work in well ventilated areas to prevent suffocation.
 - Never pressure test or leakage test HFC-134a (R-134a) service equipment and/or vehicle air conditioning systems with compressed air during repair. Some mixtures of air and HFC-134a (R-134a) have been shown to be combustible at elevated pressures. These mixtures, if ignited, may cause injury or property damage. Additional health and safety information may be obtained from refrigerant manufacturers.


FOR MEXICO : Refrigerant Connection

INFOID:000000009722124

A new type refrigerant connection has been introduced to all refrigerant lines except the following location.

- Expansion valve to evaporator
- Refrigerant pressure sensor to liquid tank

O-RING AND REFRIGERANT CONNECTION



F. Former type refrigerant connection N. New type refrigerant connection

O: O-ring size

CAUTION:

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

PRECAUTIONS

< PRECAUTION >

[WITHOUT 7 INCH DISPLAY]

The new and former refrigerant connections use different O-ring configurations. Never confuse O-rings since they are not interchangeable. Refrigerant may leak at the connection if a wrong O-ring is installed.

O-Ring Part Numbers and Specifications

Connection type	Piping connection point		Part number	QTY	O-ring size
New	Low-pressure flexible hose to low-pressure pipe		92474 N8210	1	φ19
	High-pressure pipe to condenser pipe assembly (Outlet)		92471 N8210	1	φ8
	Condenser pipe assembly (Inlet) to high-pressure flexible hose (One-touch joint)		92472 N8210	1	φ12
	Condenser assembly to condenser pipe assembly	Inlet	92472 N8210	1	φ12
		Outlet	92471 N8210	1	φ8
	Low-pressure pipe to expansion valve		92473 N8210	1	φ16
	High-pressure pipe to expansion valve		92471 N8210	1	φ8
	Compressor to low-pressure flexible hose		92474 N8210	1	φ19
	Compressor to high-pressure flexible hose		92472 N8210	1	φ12
	Liquid tank to condenser assembly	Inlet	92471 N8210	1	φ8
Outlet		1			
Former	Refrigerant pressure sensor to liquid tank		J2476 89956	1	φ10
	Expansion valve to evaporator pipe assembly	Inlet	92475 71L00	1	φ12
		Outlet	92475 72L00	1	φ16
	Evaporator to evaporator pipe assembly	Inlet	92475 71L00	1	φ12
		Outlet	92475 72L00	1	φ16

WARNING:

Check that all refrigerant is discharged into the recycling equipment and the pressure in the system is less than atmospheric pressure. Then gradually loosen the discharge side hose fitting and remove it.

CAUTION:

Observe the following when replacing or cleaning refrigerant cycle components.

- Store it in the same way as it is when mounted on the car when the compressor is removed. Failure to do so will cause lubricant to enter the low-pressure chamber.
- Always use a torque wrench and a back-up wrench when connecting tubes.
- Immediately plug all openings to prevent entry of dust and moisture after disconnecting tubes.
- Connect the pipes at the final stage of the operation when installing an air conditioner in the vehicle. Never remove the seal caps of pipes and other components until just before required for connection.
- Allow components stored in cool areas to warm to working area temperature before removing seal caps. This prevents condensation from forming inside A/C components.
- Thoroughly remove moisture from the refrigeration system before charging the refrigerant.
- Replace always used O-rings.
- Apply lubricant to circle of the O-rings shown in illustration when connecting tube. Be careful not to apply lubricant to threaded portion.

Name : NISSAN A/C System Oil Type S


- O-ring must be closely attached to the groove portion of tube.
- Be careful not to damage O-ring and tube when replacing the O-ring.
- Connect tube until a click can be heard. Then tighten the nut or bolt by hand. Check that the O-ring is installed to tube correctly.

PRECAUTIONS

< PRECAUTION >

[WITHOUT 7 INCH DISPLAY]

- Perform leakage test and make sure that there is no leakage from connections after connecting line. Disconnect the line and replace the O-ring when the refrigerant leaking point is found. Then tighten the connections of seal seat to the specified torque.



FOR MEXICO : Service Equipment

INFOID:000000009722125

RECOVERY/RECYCLING EQUIPMENT

Be certain to follow the manufacturer instructions for machine operation and machine maintenance. Never introduce any refrigerant other than that specified into the machine.

ELECTRICAL LEAK DETECTOR


Be certain to follow the manufacturer instructions for tester operation and tester maintenance.

VACUUM PUMP

The lubricant contained inside the vacuum pump is not compatible with the specified lubricant for HFC-134a (R-134a) A/C systems. The vent side of the vacuum pump is exposed to atmospheric pressure. So the vacuum pump lubricant may migrate out of the pump into the service hose. This is possible when the pump is switched OFF after evacuation (vacuuming) and hose is connected to it. To prevent this migration, use a manual valve placed near the hose-to-pump connection, as per the following.

- Vacuum pumps usually have a manual isolator valve as part of the pump. Close this valve to isolate the service hose from the pump.
- Use a hose equipped with a manual shut-off valve near the pump end for pumps without an isolator. Close the valve to isolate the hose from the pump.
- Disconnect the hose from the pump if the hose has an automatic shut-off valve. As long as the hose is connected, the valve is open and lubricating oil may migrate.

Some one-way valves open when vacuum is applied and close under no vacuum condition. Such valves may restrict the ability of the pump to create a deep vacuum and are not recommended.




MANIFOLD GAUGE SET

PRECAUTIONS

< PRECAUTION >


Be certain that the gauge face indicates HFC-134a or R-134a. Be sure the gauge set has 1/2"-16 ACME threaded connections for service hoses. Confirm the set has been used only with refrigerant HFC-134a (R-134a) and specified lubricants.

[WITHOUT 7 INCH DISPLAY]



SERVICE HOSES


Be certain that the service hoses display the markings described (colored hose with a black stripe). All hoses must equip positive shut-off devices (either manual or automatic) near the end of the hoses opposite to the manifold gauge.



SERVICE COUPLERS


Never attempt to connect HFC-134a (R-134a) service couplers to a CFC-12 (R-12) A/C system. The HFC-134a (R-134a) couplers do not properly connect to the CFC-12 (R-12) system. However, if an improper connection is attempted, discharge and contamination may occur.

Shut-off valve rotation	A/C service valve
Clockwise	Open
Counterclockwise	Close



REFRIGERANT WEIGHT SCALE

Verify that no refrigerant other than HFC-134a (R-134a) and specified lubricants have been used with the scale. The hose fitting must be 1/2"-16 ACME if the scale controls refrigerant flow electronically.



CHARGING CYLINDER

Use of a charging cylinder is not recommended. Refrigerant may be vented into the air from the top valve of the cylinder when filling the cylinder with refrigerant. Also, the accuracy of the cylinder is generally less than that of an electronic scale or of quality recycle/recharge equipment.

COMPRESSOR

General Precautions

INFOID:000000009722126

CAUTION:

- Plug all openings to prevent moisture and foreign matter from entering.
- Store it in the same way as it is when mounted on the car when the compressor is removed.
- Follow “Maintenance of Lubricant Quantity in Compressor” exactly when replacing or repairing the compressor. Refer to [HA-25, "Maintenance of Lubricant Quantity"](#).
- Keep friction surfaces between clutch and pulley clean. Wipe it off by using a clean waste cloth moistened with thinner if the surface is contaminated with lubricant.
- Turn the compressor shaft by hand more than five turns in both directions after compressor service operation. This equally distributes lubricant inside the compressor. Let the engine idle and operate the compressor for one hour after the compressor is installed.
- Apply voltage to the new compressor and check for normal operation after replacing the compressor magnet clutch.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

FLUORESCENT LEAK DETECTOR

< PRECAUTION >

[WITHOUT 7 INCH DISPLAY]

FLUORESCENT LEAK DETECTOR

General Precautions

INFOID:000000009722127

CAUTION:

- The A/C system contains a fluorescent leak detection dye used for locating refrigerant leakages. An ultraviolet (UV) lamp is required to illuminate the dye when inspecting for leakages.
- Always wear fluorescence enhancing UV safety goggles to protect eyes and enhance the visibility of the fluorescent dye.
- The fluorescent dye leak detector is not a replacement for an electrical leak detector (SST: J-41995). The fluorescent dye leak detector should be used in conjunction with an electrical leak detector (SST: J-41995) to pin-point refrigerant leakages.
- Read and follow all manufacture operating instructions and precautions prior to performing the work for the purpose of safety and customer satisfaction.
- A compressor shaft seal should not necessarily be repaired because of dye seepage. The compressor shaft seal should only be repaired after confirming the leakage with an electrical leak detector (SST: J-41995).
- Always remove any remaining dye from the leakage area after repairs are completed to avoid a misdiagnosis during future service.
- Never allow dye to come into contact with painted body panels or interior components. Clean immediately with the approved dye cleaner if dye is spilled. Fluorescent dye left on a surface for an extended period of time cannot be removed.
- Never spray the fluorescent dye cleaning agent on hot surfaces (engine exhaust manifold, etc.).
- Never use more than one refrigerant dye bottle (1/4 ounce /7.4 cc) per A/C system.
- Leak detection dyes for HFC-134a (R-134a) and CFC-12 (R-12) A/C systems are different. Never use HFC-134a (R-134a) leak detection dye in CFC-12 (R-12) A/C system, or CFC-12 (R-12) leak detection dye in HFC-134a (R-134a) A/C system, or A/C system damage may result.
- The fluorescent properties of the dye remains for three or more years unless a compressor malfunction occurs.

IDENTIFICATION

NOTE:

Vehicles with factory installed fluorescent dye have a green label.

Vehicles without factory installed fluorescent dye have a blue label.

IDENTIFICATION LABEL FOR VEHICLE

Vehicles with factory installed fluorescent dye have an identification label on the front side of hood.

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[WITH 7 INCH DISPLAY]


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000009722128

OVERALL SEQUENCE



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

HAC

DETAILED FLOW

JMKIA8652GB

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[WITH 7 INCH DISPLAY]

1. GET INFORMATION FOR SYMPTOM

1. Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurs).
2. Check operation condition of the function that is malfunctioning.

>> GO TO 2.

2. CHECK DTC

1. Check DTC.
2. Perform the following procedure if DTC is detected.
 - Record DTC and freeze frame data (Print them out using CONSULT.)
 - Erase DTC.
 - Study the relationship between the cause detected by DTC and the symptom described by the customer.
3. Check related service bulletins for information.

Are any symptoms described and any DTC detected?

Symptom is described, DTC is detected>>GO TO 3.

Symptom is described, DTC is not detected>>GO TO 4.

Symptom is not described, DTC is detected>>GO TO 5.

3. CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Also study the normal operation and fail-safe related to the symptom.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5.

4. CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6.

5. PERFORM DTC CONFIRMATION PROCEDURE

Perform DTC CONFIRMATION PROCEDURE for the detected DTC, and then check that DTC is detected again. At this time, always connect CONSULT to the vehicle, and check self diagnostic results in real time. If two or more DTCs are detected, refer to DTC INSPECTION PRIORITY CHART, and determine trouble diagnosis order.

NOTE:

- Freeze frame data is useful if the DTC is not detected.
- Perform Component Function Check if DTC CONFIRMATION PROCEDURE is not included on Service Manual. This simplified check procedure is an effective alternative though DTC cannot be detected during this check.
If the result of Component Function Check is NG, it is the same as the detection of DTC by DTC CONFIRMATION PROCEDURE.

Is DTC detected?

YES >> GO TO 7.

NO >> Check according to [GI-44. "Intermittent Incident"](#).

6. DETECT MALFUNCTIONING SYSTEM BY SYMPTOM DIAGNOSIS

Detect malfunctioning system according to SYMPTOM DIAGNOSIS based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

Is the symptom described?

YES >> GO TO 7.

NO >> Monitor input data from related sensors or check voltage of related module terminals using CONSULT.

7. DETECT MALFUNCTIONING PART BY DIAGNOSIS PROCEDURE

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[WITH 7 INCH DISPLAY]

Inspect according to Diagnosis Procedure of the system.

Is malfunctioning part detected?

YES >> GO TO 8.

NO >> Check according to [GI-44. "Intermittent Incident"](#).

8. REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnosis Procedure again after repair and replacement.
3. Check DTC. If DTC is detected, erase it.

>> GO TO 9.

9. FINAL CHECK

When DTC is detected in step 2, perform DTC CONFIRMATION PROCEDURE again, and then check that the malfunction is repaired securely.

When symptom is described by the customer, refer to confirmed symptom in step 3 or 4, and check that the symptom is not detected.

Is DTC detected and does symptom remain?

YES-1 >> DTC is detected: GO TO 7.

YES-2 >> Symptom remains: GO TO 4.

NO >> Before returning the vehicle to the customer, always erase DTC.

A

B

C

D

E

F

G

H

HAC

J

K

L

M

N

O

P

INSPECTION AND ADJUSTMENT

Description & Inspection

INFOID:000000009722129

DESCRIPTION

The purpose of the operational check is to check that the individual system operates normally.

Conditions : Engine running at normal operating temperature

INSPECTION PROCEDURE

1.CHECK MEMORY FUNCTION

1. Start the engine.
2. Operate the temperature control dial (driver side) and raise the temperature setting to 32°C (90°F).
3. Press the ON/OFF switch.
4. Turn the ignition switch OFF.
5. Turn the ignition switch ON.
6. Press the AUTO switch.
7. Check that the temperature setting before turning the ignition switch OFF is stored.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Memory function malfunction: [HAC-241, "Inspection procedure"](#).

2.CHECK BLOWER MOTOR SPEED

1. Start the engine.
2. Operate the fan control dial. Check that the fan speed changes. Check the operation for all fan speeds.
3. Set the fan speed to speed 7.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Blower motor system malfunction: [HAC-196, "Diagnosis Procedure"](#).

3.CHECK DISCHARGE AIR(MODE SWITCH AND DEF SWITCH)

1. Press the MODE switch and the DEF switch.
2. Check that the air outlets change according to each indicated air outlet by placing a hand in front of the outlets. Refer to [HAC-143, "System Description"](#).

NOTE:

Confirm that the compressor clutch is engaged (sound or visual inspection) and intake door position is at FRE when the D/F or DEF is selected.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Mode door system malfunction: [HAC-189, "Diagnosis Procedure"](#).

4.CHECK DISCHARGE AIR (UPPER VENT SWITCH)

1. Press the UPPER VENT switch.
2. The UPPER VENT switch indicator is turned ON.

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[WITH 7 INCH DISPLAY]

3. Check that the air blown from UPPER VENT does not greatly deviate from the air mix ratio.

Discharge air flow							
Mode position indication	Condition	Air outlet/distribution					
		VENT			FOOT		DEF
		Front	Upper	Rear	Front	Rear	
	DUAL switch: OFF UPPER VENT switch : ON	81%	8%	11%	—	—	—
		41%	10%	17%	24%	8%	—
		12%	12%	16%	27%	10%	23%
		11%	11%	14%	25%	10%	29%
		11%	11%	12%	—	—	66%

JPIIA0509GB

4. Press the UPPER VENT switch again.
 5. The UPPER VENT switch indicator is turned OFF.
 6. The air blown from the UPPER VENT stops.

Does it operate normally?

YES >> GO TO 5.

NO >> Upper ventilator door system malfunction: [HAC-194, "Diagnosis Procedure"](#).

5. CHECK INTAKE AIR

1. Press the intake switch. Indicator is turned ON (REC).
 2. Press the intake switch again. Indicator is turned OFF (FRE).
 3. Listen for the intake door position change. (Slight change of blower sound can be heard.)

NOTE:

Confirm that the compressor clutch is engaged (sound or visual inspection) and intake door position is at FRE when the D/F or DEF is selected.

Is the inspection result normal?

YES >> GO TO 6.

NO >> Intake door system malfunction: [HAC-192, "Diagnosis Procedure"](#).

6. CHECK A/C SWITCH

1. Press the A/C switch.
 2. The A/C switch indicator is turned ON.
 Confirm that the compressor clutch engages (sound or visual inspection).

Is the inspection result normal?

YES >> GO TO 7.

NO >> Magnet clutch system malfunction: [HAC-200, "Diagnosis Procedure"](#).

7. CHECK WITH TEMPERATURE SETTING LOWERED

1. Operate the compressor.
 2. Operate the temperature control switch (driver side) and lower the temperature setting to 18°C (60°F).
 3. Check that the cool air blows from the outlets.

Is the inspection result normal?

YES >> GO TO 8.

NO >> Insufficient cooling: [HAC-233, "Inspection procedure"](#).

8. CHECK WITH TEMPERATURE SETTING RAISED

1. Operate the temperature control dial (driver side) and raise the temperature setting to 32°C (90°F) after warming up the engine.
 2. Check that the warm air blows from the outlets.

Is the inspection result normal?

YES >> GO TO 9.

NO >> Insufficient heating: [HAC-236, "Inspection procedure"](#).

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[WITH 7 INCH DISPLAY]

9. CHECK LH/RH INDEPENDENT TEMPERATURE ADJUSTMENT FUNCTION

1. Press the DUAL switch, and then check that "DUAL" is shown on the display.
2. Operate the temperature control dial (driver side). Check that the discharge air temperature (driver side) changes.
3. Operate the temperature control dial (passenger side). Check that the discharge air temperature (passenger side) changes.
4. Press the DUAL switch, and then check that the temperature setting (LH/RH) is unified to the driver side temperature setting.

Is the inspection result normal?

YES >> GO TO 10.

NO >> Refer to [HAC-232. "Diagnosis Chart By Symptom"](#) and perform the appropriate diagnosis.

10. CHECK AUTO MODE

1. Press the AUTO switch, and then check that "AUTO" is shown on the display.
2. Operate the temperature control dial (driver side). Check that the fan speed or outlet changes (the discharge air temperature or fan speed varies depending on the ambient temperature, in-vehicle temperature, and temperature setting).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Refer to [HAC-232. "Diagnosis Chart By Symptom"](#) and perform the appropriate diagnosis.

Temperature Setting Trimmer

INFOID:000000009722130

Description

If the temperature felt by the customer is different than the air flow temperature controlled by the temperature setting, the auto amplifier control temperature can be adjusted to compensate for the temperature setting.

How to set

Using CONSULT, perform "TEMP SET CORRECT" on "WORK SUPPORT" of HVAC.

Work support items	Display (°F)	Display (°C)
TEMP SET CORRECT	6	3.0
	5	2.5
	4	2.0
	3	1.5
	2	1.0
	1	0.5
	0 (initial status)	0 (initial status)
	-1	-0.5
	-2	-1.0
	-3	-1.5
	-4	-2.0
	-5	-2.5
	-6	-3.0

NOTE:

- When the temperature setting is set to 25.0°C (77°F) and -3.0°C (-6°F), the temperature controlled by auto amp is 25.0°C (77°F) - 3.0°C (6°F) = 22.0°C (71°F) and the temperature becomes lower than the temperature setting.
- When the battery cable is disconnected from the negative terminal or when the battery voltage becomes 10 V or less, the setting of the difference between the temperature setting and control temperature may be cancelled.

Foot Position Setting Trimmer

INFOID:000000009722131

Description

In the FOOT mode, the air blowing to the DEF can be turned ON/OFF.

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[WITH 7 INCH DISPLAY]

How to set

Using CONSULT, perform "BLOW SET" on "WORK SUPPORT" of HVAC.

Work support items	Display	DEF door position	
		Auto control	Manual control
BLOW SET	Mode 1	OPEN	CLOSE
	Mode 2 (initial status)	OPEN	OPEN
	Mode 3	CLOSE	OPEN
	Mode 4	CLOSE	CLOSE

NOTE:

When the battery cable is disconnected from the negative terminal or when the battery voltage becomes 10 V or less, the setting of the discharge air mix ratio in FOOT mode may be cancelled.

Inlet Port Memory Function (FRE)

INFOID:000000009722132

Description

- If the ignition switch is turned to the OFF position while the FRE switch is set to ON (fresh air intake), "Perform the memory" or "Do not perform the memory" of the FRE switch ON (fresh air intake) condition can be selected.
- If "Perform the memory" was set, the FRE switch will be ON (fresh air intake) when turning the ignition switch to the ON position again.
- If "Do not perform the memory" was set, the air inlets will be controlled automatically when turning the ignition switch to the ON position again.

How to set

Using CONSULT, perform "FRE MEMORY SET" on "WORK SUPPORT" of HVAC.

Work support items	Display	Setting
FRE MEMORY SET	WITHOUT	Perform the memory of manual FRE
	WITH (initial status)	Do not perform the memory of manual FRE (auto control)

NOTE:

When the battery cable is disconnected from the negative terminal or when the battery voltage becomes 10 V or less, the setting of the FRE switch memory function may be cancelled.

Inlet Port Memory Function (REC)

INFOID:000000009722133

Description

- If the ignition switch is turned to the OFF position while the REC switch is set to ON (recirculation), "Perform the memory" or "Do not perform the memory" of the REC switch ON (recirculation) condition can be selected.
- If "Perform the memory" was set, the REC switch will be ON (recirculation) when turning the ignition switch to the ON position again.
- If "Do not perform the memory" was set, the air inlets will be controlled automatically when turning the ignition switch to the ON position again.

How to set

Using CONSULT, perform "REC MEMORY SET" on "WORK SUPPORT" of HVAC.

Work support items	Display	Setting
REC MEMORY SET	WITHOUT (initial status)	Perform the memory of manual REC
	WITH	Do not perform the memory of manual REC (auto control)

NOTE:

When the battery cable is disconnected from the negative terminal or when the battery voltage becomes 10 V or less, the setting of the REC switch memory function may be cancelled.

COMPRESSOR CONTROL FUNCTION

< SYSTEM DESCRIPTION >

[WITH 7 INCH DISPLAY]

SYSTEM DESCRIPTION

COMPRESSOR CONTROL FUNCTION


Description

INFOID:000000009722134

PRINCIPLE OF OPERATION

Compressor is not activated.

Functional circuit diagram



CAN (1) : A/C switch signal
: Blower fan motor switch signal

CAN (2) : A/C compressor request signal

Functional initial inspection chart

×: Applicable

Control unit	Diagnosis item	Location				
		A	B	C	D	
A/C auto amp.	④ "HVAC"	Self-diagnosis	×	—	—	—
		Data monitor	×	—	—	—
		Active test	×	—	—	×
ECM	④ "ENGINE"	Self-diagnosis function (CAN system diagnosis)	—	—	×	—
		Data monitor	—	×	×	—
IPDM E/R	④ "IPDM E/R"	Self-diagnosis function (CAN system diagnosis)	—	—	—	×
		Data monitor	—	—	×	—
	Auto active test	—	—	—	×	

COMPRESSOR CONTROL FUNCTION

< SYSTEM DESCRIPTION >

[WITH 7 INCH DISPLAY]

Fail-Safe

INFOID:000000009722135

FAIL-SAFE FUNCTION

- If a communication error exists between the A/C auto amp., and the AV control unit and preset switch for 30 seconds or longer, air conditioner is controlled under the following conditions:

Compressor	: ON	A
Air outlet	: AUTO	B
Air inlet	: FRE (Fresh)	C
Blower fan speed	: AUTO	D
Set temperature	: Setting before communication error occurs	E

Component Part Location

INFOID:000000009722136

ENGINE COMPARTMENT


A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

COMPRESSOR CONTROL FUNCTION

< SYSTEM DESCRIPTION >

[WITH 7 INCH DISPLAY]



JPIIA0607ZZ

1. Refrigerant pressure sensor

2. Compressor (magnet clutch)


3. Ambient sensor

PASSENGER COMPARTMENT

COMPRESSOR CONTROL FUNCTION

< SYSTEM DESCRIPTION >

[WITH 7 INCH DISPLAY]



- | | | |
|-------------------------------------|--------------------------------|--|
| 1. Intake door motor | 2. Upper ventilator door motor | 3. Air mix door motor (passenger side) |
| 4. Air mix door motor (driver side) | 5. Mode door motor | 6. Sunload sensor |
| 7. In-vehicle sensor | 8. A/C auto amp. | 9. Intake sensor |
| 10. Blower motor | | |

JPIIA0608ZZ

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

COMPRESSOR CONTROL FUNCTION

< SYSTEM DESCRIPTION >

[WITH 7 INCH DISPLAY]

Component's Role

INFOID:000000009722137

Component	Reference
Refrigerant pressure sensor	EC-465. "Description"
Compressor	HAC-200. "Description"
Ambient sensor	HAC-172. "Description"
Intake door motor	HAC-191. "Description"
Upper ventilator door motor	HAC-193. "Description"
Air mix door motor (driver side)	HAC-184. "Description"
Air mix door motor (passenger side)	HAC-186. "Description"
Mode door motor	HAC-188. "Description"
Sunload sensor	HAC-181. "Description"
In-vehicle sensor	HAC-175. "Description"
A/C auto amp.	HAC-202. "A/C AUTO AMP. : Description"
Intake sensor	HAC-178. "Description"
Blower motor	HAC-196. "Description"

AUTOMATIC AIR CONDITIONER SYSTEM

< SYSTEM DESCRIPTION >

[WITH 7 INCH DISPLAY]


AUTOMATIC AIR CONDITIONER SYSTEM

System Diagram

INFOID:000000009722138

CONTROL SYSTEM

The control system consists of input sensors, switches, the A/C auto amp. (microcomputer) and outputs. The relationship of these components is as shown in the figure below:



System Description


INFOID:000000009722139

CONTROL OPERATION

Display

The operation status of the system is displayed on the screen.

Models with navigation system




AUTOMATIC AIR CONDITIONER SYSTEM


< SYSTEM DESCRIPTION >

[WITH 7 INCH DISPLAY]

Models without navigation system



Preset Switch



MODE Switch

The air discharge outlets are controlled with this switch.

Temperature Control Dial (Driver Side)

The set temperature is increased or decreased with this dial.

Temperature Control Dial (Passenger Side)

- The set temperature is increased or decreased with this dial.
- When the temperature control dial is turned, DUAL switch indicator is turned ON.

AUTO Switch

- The compressor, intake doors, air mix doors, mode doors and blower speed are automatically controlled so that the in-vehicle temperature will reach, and be maintained at the set temperature selected by the operator.
- When pressing the AUTO switch, air inlet, air outlet, fan speed, and discharge air temperature are automatically controlled.

Defroster (DEF) Switch

Mode doors are set to the defrost position with this switch. Also, intake doors are set to the outside air position, and compressor turns ON.

UPPER VENT Switch

- When the UPPER VENT switch is pressed, the UPPER VENT switch indicator is turned ON.
- When the UPPER VENT switch indicator is turned ON, the UPPER VENT switch indicator is turned OFF by pressing the defroster (DEF) switch (after the above operation, the UPPER VENT switch indicator is turned ON by pressing the UPPER VENT switch).

A/C Switch

Compressor turns ON or OFF with this switch.

(Pressing the A/C switch when the A/C switch is ON turns OFF the A/C switch and compressor.)

Fan Control Dial

The blower speed is manually controlled with this dial. Seven speeds are available for manual control (as shown on the display screen).

AUTOMATIC AIR CONDITIONER SYSTEM

< SYSTEM DESCRIPTION >

[WITH 7 INCH DISPLAY]

ON/OFF Switch

Compressor and blower turn OFF, intake doors and the mode doors are automatically controlled.

A

Rear Window Defogger Switch

When indicator is ON, rear window is defogged.

B

Intake Switch

- When the intake switch is ON, the intake switch indicator is turned ON, and air inlet is set to REC.
- When the intake switch is pressed again, the intake switch indicator is turned OFF, and air inlet is set to FRE.
- When the intake switch is pressed for approximately 1.5 seconds or longer, the intake switch indicator lamps blink twice. Then, automatic control mode is entered. Inlet status is displayed by indicator even when automatically controlled.
- When the intake switch indicator is turned OFF, shifting mode position to D/F or DEF, or when compressor is turned from ON to OFF, intake switch is automatically turned OFF (set to FRE mode). REC mode can be re-entered by pressing intake switch again, and then compressor is turned ON. (Except D/F or DEF position)

D

DUAL Switch

- When the DUAL switch indicator is ON, the driver side and passenger side, temperature can each be set independently.
- When the DUAL switch indicator is OFF, the driver side outlet and setting temperature are applied to both sides.

E

F

G

H

HAC

J

K

L

M

N

O


P

AUTOMATIC AIR CONDITIONER SYSTEM

< SYSTEM DESCRIPTION >

[WITH 7 INCH DISPLAY]

DISCHARGE AIR FLOW




AUTOMATIC AIR CONDITIONER SYSTEM

< SYSTEM DESCRIPTION >

[WITH 7 INCH DISPLAY]

SWITCHES AND THEIR CONTROL FUNCTION



* : Models for Mexico.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

AUTOMATIC AIR CONDITIONER SYSTEM

< SYSTEM DESCRIPTION >


[WITH 7 INCH DISPLAY]

Switch position			Door position								
			Ventilator door	Max. cool door	Defroster door	Foot door	Upper ventilator door	Intake door	Air mix door (Driver side)	Air mix door (Passenger side)	
AUTO switch	☀		AUTO						AUTO		
MODE switch	VENT	☀	A	A	A	A	—	—			
	B/L	☀	B	B	A	B					
	FOOT	☀	C	B	B	B					
	D/F	☀	C	B	B	B					
DEF switch	☀	☀	C	C	C	A		B	—	—	
UPPER VENT switch	ON	☀	—				A-B	—			
	OFF	☀	—				C				
Intake switch	ON	☀	—	—	—	—	—	—	A*		
	OFF	☀							B*		
Temperature control dial (Driver side)	DUAL switch: OFF	18.0°C (60°F)	—	—	—	—	—	—	—	A	
		18.5°C ⇔ 31.5°C (61°F ⇔ 89°F)								AUTO	
		32.0°C (90°F)								B	
Temperature control dial (Driver side)	DUAL switch: ON	18.0°C (60°F)	—	—	—	—	—	—	—	A	
		18.5°C ⇔ 31.5°C (61°F ⇔ 89°F)								AUTO	
		32.0°C (90°F)								B	
Temperature control dial (Passenger side)	ON	18.0°C (60°F)	—	—	—	—	—	—	—	A	
		18.5°C ⇔ 31.5°C (61°F ⇔ 89°F)								—	
		32.0°C (90°F)								B	
ON/OFF switch			C	C	B	C	—	B	—	—	

*: Inlet status is displayed by indicator when activating automatic control.

AIR CONDITIONER LAN CONTROL SYSTEM

The LAN (Local Area Network) system consists of the A/C auto amp., the mode door motor, the air mix door motors, the upper ventilator door motor and the intake door motor. A configuration of these components is as shown in the figure below.



JP1IA0489GB

AUTOMATIC AIR CONDITIONER SYSTEM

< SYSTEM DESCRIPTION >

[WITH 7 INCH DISPLAY]


SYSTEM CONSTRUCTION

A small network exists between the A/C auto amp., the mode door motor, the air mix door motors, the upper ventilator door motor and the intake door motor. The A/C auto amp. and motors are connected by data transmission lines and motor power supply lines. The LAN network is built through the ground circuits of each door motor.

Addresses, motor opening angle signals, motor stop signals and error checking messages are all transmitted through the data transmission lines connecting the A/C auto amp. and each door motor.

The following functions are contained in LCUs built into the mode door motor, the air mix door motors, the upper ventilator door motor and the intake door motor.


- Address
- Motor opening angle signals
- Data transmission
- Motor stop and drive decision
- Opening angle sensor (PBR function)
- Comparison
- Decision (A/C auto amp. indicated value and motor opening angle comparison)



Operation

The A/C auto amp. receives data from each of the sensors. The A/C auto amp. sends mode door, the air mix door and the intake door opening angle data to the mode door motor LCU, the air mix door motor LCUs, the upper ventilator door motor LCU and the intake door motor LCU.

The mode door motor, the air mix door motors, the upper ventilator door motor and the intake door motor read their respective signals according to the address signal. Opening angle indication signals received from the A/C auto amp. and each of the motor position sensors is compared by the LCUs in each door motor with the existing decision and opening angles. Next, HOT/COLD, DEF/VENT, OPEN/SHUT or FRE/REC operation is selected. The new selection data is returned to the A/C auto amp.



Transmission Data and Transmission Order

A/C auto amp. data is transmitted consecutively to each of the door motors following the form as shown in the figure below.

START:

- Initial compulsory signal is sent to each of the door motors.

ADDRESS:

- Data sent from the A/C auto amp. is selected according to data-based decisions made by the mode door motor, the air mix door motors, the upper ventilator door motor and the intake door motor.
- If the addresses are identical, the opening angle data and error check signals are received by the door motor LCUs. The LCUs then make the appropriate error decision. If the opening angle data has no error, door control begins.
- If an error exists, the received data is rejected and corrected the data received. Finally, door control is based upon the corrected opening angle data.

AUTOMATIC AIR CONDITIONER SYSTEM

< SYSTEM DESCRIPTION >

[WITH 7 INCH DISPLAY]

OPENING ANGLE:


- Data that shows the indicated door opening angle of each door motor.

ERROR CHECK:

- In this procedure, transmitted and received data is checked for errors. Error data is then compiled. The error check prevents corrupted data from being used by the mode door motor, the air mix door motors, the upper ventilator door motor and the intake door motor. Error data can be related to the following symptoms.
 - Malfunction of electrical frequency
 - Poor electrical connections
 - Signal leakage from transmission lines
 - Signal level fluctuation

STOP SIGNAL:

- At the end of each transmission, a stop operation, in-operation, or internal malfunction message is delivered to the A/C auto amp. This completes one data transmission and control cycle.



Component Part Location

INFOID:000000009722140


ENGINE COMPARTMENT

AUTOMATIC AIR CONDITIONER SYSTEM

< SYSTEM DESCRIPTION >

[WITH 7 INCH DISPLAY]

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P



1. Refrigerant pressure sensor

2. Compressor (magnet clutch)

3. Ambient sensor


PASSENGER COMPARTMENT

JPIHA0607ZZ

AUTOMATIC AIR CONDITIONER SYSTEM

< SYSTEM DESCRIPTION >

[WITH 7 INCH DISPLAY]



JPIIA0608ZZ

- | | | |
|-------------------------------------|--------------------------------|--|
| 1. Intake door motor | 2. Upper ventilator door motor | 3. Air mix door motor (passenger side) |
| 4. Air mix door motor (driver side) | 5. Mode door motor | 6. Sunload sensor |
| 7. In-vehicle sensor | 8. A/C auto amp. | 9. Intake sensor |
| 10. Blower motor | | |

AUTOMATIC AIR CONDITIONER SYSTEM

< SYSTEM DESCRIPTION >

[WITH 7 INCH DISPLAY]

Component Description

INFOID:000000009722141

Component	Reference
Refrigerant pressure sensor	EC-465. "Description"
Compressor	HAC-200. "Description"
Ambient sensor	HAC-172. "Description"
Intake door motor	HAC-191. "Description"
Upper ventilator door motor	HAC-193. "Description"
Air mix door motor (driver side)	HAC-184. "Description"
Air mix door motor (passenger side)	HAC-186. "Description"
Mode door motor	HAC-188. "Description"
Sunload sensor	HAC-181. "Description"
In-vehicle sensor	HAC-175. "Description"
A/C auto amp.	HAC-202. "A/C AUTO AMP. : Description"
Intake sensor	HAC-178. "Description"
Blower motor	HAC-196. "Description"

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC


MODE DOOR CONTROL SYSTEM

< SYSTEM DESCRIPTION >

[WITH 7 INCH DISPLAY]

MODE DOOR CONTROL SYSTEM

System Diagram



System Description


INFOID:000000009722143

The mode door is automatically controlled by the temperature setting, ambient temperature, in-vehicle temperature, intake temperature and amount of sunload.

SYSTEM OPERATION

- The A/C auto amp. receives data from each of the sensors.
- The A/C auto amp. sends the air mix door, the mode door, the upper ventilator door and the intake door opening angle data to the air mix door motor LCU(s), the mode door motor LCU, the upper ventilator door motor LCU and the intake door motor LCU.
- The air mix door motor(s), the mode door motor, the upper ventilator door motor and the intake door motor read their respective signals according to the address signal. Opening angle indication signals received from the A/C auto amp. and each of the motor position sensors are compared by the LCUs in each door motor with the existing decision and opening angles.
- Next, HOT/COLD, DEF/VENT, OPEN/SHUT or FRE/REC operations is selected. The newly selected data is returned to the A/C auto amp.

Door Motor Circuit




Mode Door Control Specification

MODE DOOR CONTROL SYSTEM

[WITH 7 INCH DISPLAY]

< SYSTEM DESCRIPTION >

Mode position can be selected manually by pressing the MODE switch or the DEF switch on the A/C control. This enables to fix a mode position. Pressing the AUTO switch allows automatic control by the A/C auto amp. During the automatic control of a mode position, a mode door position (VENT, B/L, FOOT, or D/F) is selected based on a target the air mix door opening angle and sunload depending on the temperature calculated by the A/C auto amp. In addition, the D/F is selected to prevent windshield fogging only when ambient temperature is extremely low with mode position the FOOT.



A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

UPPER VENTILATOR DOOR CONTROL SYSTEM


< SYSTEM DESCRIPTION >

[WITH 7 INCH DISPLAY]

UPPER VENTILATOR DOOR CONTROL SYSTEM

System Diagram

INFOID:000000009722144



System Description


INFOID:000000009722145

The upper ventilator door motor is attached to the heater & cooling unit assembly. The upper ventilator door motor operates by the UPPER VENT switch ON/OFF. Motor rotation is conveyed to a rod which activates the upper ventilator door.

SYSTEM OPERATION

- The A/C auto amp. receives data from each of the sensors.
- The A/C auto amp. sends air mix door, the mode door, the upper ventilator door and the intake door opening angle data to the air mix door motor LCU(s), the mode door motor LCU, the upper ventilator door motor LCU and the intake door motor LCU.
- The air mix door motor(s), the mode door motor, the upper ventilator door motor and the intake door motor read their respective signals according to the address signal. Opening angle indication signals received from the A/C auto amp. and each of the motor position sensors are compared by the LCUs in each door motor with the existing decision and opening angles.
- Next, HOT/COLD, DEF/VENT, OPEN/SHUT or FRE/REC operations is selected. The newly selected data is returned to the A/C auto amp.

Door Motor Circuit



JPIIA0495GB

Upper Ventilator Specification

UPPER VENTILATOR DOOR CONTROL SYSTEM

< SYSTEM DESCRIPTION >

[WITH 7 INCH DISPLAY]

UPPER VENT switch	MODE position	Upper ventilator door position
OFF	—	Close
ON	VENT or B/L	Open (Fully-open)
ON	FOOT or D/F	Open (Intermediate)
ON	DEF	Close

A

B

C

D

E

F

G

H

HAC

J

K

L

M

N

O

P


AIR MIX DOOR CONTROL SYSTEM

< SYSTEM DESCRIPTION >

[WITH 7 INCH DISPLAY]

AIR MIX DOOR CONTROL SYSTEM

System Diagram



System Description


INFOID:000000009722147

The air mix doors are automatically controlled so that in-vehicle temperature is maintained at a predetermined value by the temperature setting, ambient temperature, intake temperature and amount of sunload.

SYSTEM OPERATION

- The A/C auto amp. receives data from each of the sensors.
- The A/C auto amp. sends air mix door, the mode door, the upper ventilator door and the intake door opening angle data to the air mix door motor LCU(s), the mode door motor LCU, the upper ventilator door motor LCU and the intake door motor LCU.
- The air mix door motor(s), the mode door motor, the upper ventilator door motor and the intake door motor read their respective signals according to the address signal. Opening angle indication signals received from the A/C auto amp. and each of the motor position sensors are compared by the LCUs in each door motor with the existing decision and opening angles.
- Next, HOT/COLD, DEF/VENT, OPEN/SHUT or FRE/REC operation is selected. The newly selected data is returned to the A/C auto amp.

Door Motor Circuit




Air Mix Door Control Specification

AIR MIX DOOR CONTROL SYSTEM

[WITH 7 INCH DISPLAY]

< SYSTEM DESCRIPTION >

When ignition switch is ON, the A/C auto amp. continuously and automatically controls temperatures regardless of air conditioner operational condition. When setting a target temperature with the temperature control switch, the A/C auto amp. corrects the set temperature and decides a target air mix door opening angle. The A/C auto amp. controls air mix door according to the target air mix door opening angle and current air mix door opening angle, keeping an optimum air mix door opening angle. When the temperature is set at 18°C (60°F), air mix door is set on full cold, and when the temperature is set at 32°C (90°F), it is set to full hot.



A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

INTAKE DOOR CONTROL SYSTEM


< SYSTEM DESCRIPTION >

[WITH 7 INCH DISPLAY]

INTAKE DOOR CONTROL SYSTEM

System Diagram

INFOID:000000009722148



System Description


INFOID:000000009722149

The intake doors are automatically controlled by the temperature setting, ambient temperature, in-vehicle temperature, intake temperature, amount of sunload and ON/OFF operation of the compressor.

SYSTEM OPERATION

The intake door control judges intake door position based on the ambient temperature, the intake air temperature and the in-vehicle temperature. When in shifting mode position D/F, if the DEF or ON/OFF switches are pressed, or when the A/C switch is OFF, the A/C auto amp. sets the intake door to the FRE position.

Door Motor Circuit



Intake Door Control Specification


INTAKE DOOR CONTROL SYSTEM

[WITH 7 INCH DISPLAY]

< SYSTEM DESCRIPTION >

Intake door position is basically set to the FRE when the FRE indicator of the DEF switch and the intake switch turn ON, and set on the REC when the REC indicator of intake switch turns ON.

The intake door automatic control selects the FRE, the 20%FRE, or the REC depending on the target air mix door opening angle, based on in-vehicle temperature, ambient temperature, and sunload.



A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

BLOWER MOTOR CONTROL SYSTEM


< SYSTEM DESCRIPTION >

[WITH 7 INCH DISPLAY]

BLOWER MOTOR CONTROL SYSTEM

System Diagram

INFOID:000000009722150



System Description

INFOID:000000009722151

Blower speed is automatically controlled by the temperature setting, ambient temperature, in-vehicle temperature, intake temperature, amount of sunload and air mix door position.


By pressing the AUTO switch, the blower motor starts to gradually increase air flow volume.

When engine coolant temperature is low, the blower motor operation is delayed to prevent cool air from flowing.

SYSTEM OPERATION

System operation

- For air flow, the manual selection (1-7) with the fan control dial has priority.
- If the AUTO switch is pressed or if the DEF switch is pressed while in the OFF condition, it changes to the automatic control by A/C auto amp.
- When increasing the air flow, it changes the duty ratio of the blower motor drive signal to prevent the air flow from suddenly increasing.
- There are the following types of air flow control: starting air flow control, starting air flow control at low coolant temperature, starting air flow control at high in-vehicle temperature, and air flow control at actuator operation in addition to manual control, normal automatic air flow control.



Normal automatic air flow control


- When the target temperature is set by the temperature control dial of preset switch, the A/C auto amp. performs the calculation and decides the target according to the signal from each sensor.
- The A/C auto amp. changes the duty ratio of blower motor drive signal and controls the air flow continuously so that the air flow becomes the target air flow.
- The minimum air flow will change according to the sunload when the air discharge outlet is VENT or B/L.

BLOWER MOTOR CONTROL SYSTEM

[WITH 7 INCH DISPLAY]

< SYSTEM DESCRIPTION >

Fan Speed Control Specification



Starting air flow control

- When starting the automatic control of air flow, the system gradually increases the duty ratio of the blower motor drive signal to prevent too much air from blowing.
- The time period from when the air flow changes from LO to HI is approximately 8 seconds.
- It becomes the starting air flow control at low coolant temperature according to the calculation result of the A/C auto amp. and engine coolant temperature [approximately 58°C (136°F) or less] during the automatic air flow control.
- Do not perform the starting air flow control when the air discharge outlet is set to DEF.

Starting Fan Speed Control

Start up from COLD SOAK Condition (Automatic mode)

In cold start up condition where the engine coolant temperature is below 58°C (136°F), the blower does not operate for a short period of time (up to 150 seconds). The exact start delay time varies depending on the ambient temperature and engine coolant temperature.

In the most extreme case (very low ambient temperature) the blower start delay is 150 seconds as described above. After this delay, the blower will operate at low speed until the engine coolant temperature rises above 58°C (136°F), and then the blower speed increases to the objective speed.

Start up from usual or HOT SOAK Condition (Automatic mode)

The blower will begin operation momentarily after the AUTO switch is pressed. The blower speed rises gradually to the objective speed over a time period of 3 seconds or less (actual time depends on the objective blower speed).

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P


MAGNET CLUTCH CONTROL SYSTEM

< SYSTEM DESCRIPTION >

[WITH 7 INCH DISPLAY]

MAGNET CLUTCH CONTROL SYSTEM

System Diagram



System Description

INFOID:000000009722153

The A/C auto amp. controls compressor operation by ambient temperature, intake air temperature and signal from ECM.

SYSTEM OPERATION

When the A/C switch, the AUTO switch, or the DEF switch is pressed, or when shifting mode position D/F, A/C auto amp. transmit the A/C switch signal and blower fan motor switch signal to the ECM, via CAN communication.

ECM judges whether compressor can be turned ON, based on each sensor status (refrigerant-pressure sensor signal, throttle angle, etc.). If the ECM judges that the compressor can be turned ON, it sends A/C compressor request signal to the IPDM E/R, via CAN communication.

Upon receipt of A/C compressor request signal from the ECM, the IPDM E/R turns the A/C relay ON to operate the compressor.

When sending A/C compressor request signal to the IPDM E/R via CAN communication line, the ECM simultaneously sends A/C compressor feedback signal to A/C auto amp. via CAN communication line.

The ECM sends A/C compressor feedback signal to A/C auto amp., then, uses input A/C compressor feedback signal to control air inlet.

Compressor Protection Control

The ECM makes the A/C relay turn OFF and stops the compressor when pressure on the high-pressure side detected by the refrigerant pressure sensor is over approximately 3,119 kPa (31.8 kg/cm², 452 psi), or below approximately 118 kPa (1.2 kg/cm², 17 psi).

Low Temperature Protection Control

Turn the A/C relay to OFF and stop the compressor by the signal from the A/C auto amp according to the evaporator passing air temperature detected by the intake sensor and the ambient temperature detected by the ambient sensor.

CAN COMMUNICATION SYSTEM

System Description

INFOID:000000009722154

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto each vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only. For details, refer to [LAN-28. "CAN System Specification Chart"](#).

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

DIAGNOSIS SYSTEM (HVAC)

< SYSTEM DESCRIPTION >

[WITH 7 INCH DISPLAY]

DIAGNOSIS SYSTEM (HVAC)

CONSULT Function

INFOID:00000009722155

CONSULT can display each diagnosis item using the diagnosis test modes shown as per the following.

CONSULT application items

Diagnosis mode	Description
ECU Identification	Displays the A/C auto amp. number.
Self Diagnostic Result	Displays the diagnosis results judged by A/C auto amp.
Data Monitor	Displays A/C auto amp. input/output data in real time.
Active Test	The signals used to activate each device are forcibly supplied from A/C auto amp.
Work Support	Changes the setting for each system function. <ul style="list-style-type: none"> • Temperature setting trimmer • Inlet port memory function (FRE) • Inlet port memory function (REC) • Foot position setting trimmer

SELF DIAGNOSTIC RESULT

Refer to [HAC-230, "DTC Index"](#).

Display Item List

DTC	Items (CONSULT screen terms)	Diagnostic item is detected when...	Possible cause
U1000	CAN COMM CIRCUIT	When A/C auto amp. is not transmitting or receiving CAN communication signal for 2 or more seconds.	CAN communication system
U1010	CONTROL UNIT (CAN)	When detecting error during the initial diagnosis of CAN controller of A/C auto amp.	A/C auto amp.
B257B	AMB TEMP SEN SHORT	Detected temperature at ambient sensor -44°C (-47°F) or less	<ul style="list-style-type: none"> • Ambient sensor • A/C auto amp.
B257C	AMB TEMP SEN OPEN	Detected temperature at ambient sensor 100°C (212°F) or more	<ul style="list-style-type: none"> • Harness and connector (Ambient sensor circuit is open, or there is a short in the circuit)
B2578	IN CAR SEN SHORT	Detected temperature at in-vehicle sensor -44°C (-47°F) or less	<ul style="list-style-type: none"> • In-vehicle sensor • A/C auto amp.
B2579	IN CAR SEN OPEN	Detected temperature at in-vehicle sensor 100°C (212°F) or more	<ul style="list-style-type: none"> • Harness and connector (In-vehicle sensor circuit is open, or there is a short in the circuit)
B2581	EVAP TEMP SEN SHORT	Detected temperature at intake sensor -33°C (-27°F) or less	<ul style="list-style-type: none"> • Intake sensor • A/C auto amp.
B2582	EVAP TEMP SEN OPEN	Detected temperature at intake sensor 69°C (156°F) or more	<ul style="list-style-type: none"> • Harness and connector (Intake sensor circuit is open, or there is a short in the circuit)
B2630*	SUNLOAD SEN SHORT	Detected calorie at sunload sensor 64.7 w/m^2 ($56 \text{ kcal/m}^2\cdot\text{h}$) or less	<ul style="list-style-type: none"> • Sunload sensor • A/C auto amp.
B2631*	SUNLOAD SEN OPEN	Detected calorie at sunload sensor 2832 w/m^2 ($2436 \text{ kcal/m}^2\cdot\text{h}$) or more	<ul style="list-style-type: none"> • Harness and connector (Sunload sensor circuit is open, or there is a short in the circuit)
B2632	DR AIRMIX ACTR SHORT	Air mix door PBR (driver side) position 5% or less	<ul style="list-style-type: none"> • Air mix door motor (driver side) • A/C auto amp.
B2633	DR AIRMIX ACTR OPEN	Air mix door PBR (driver side) position 95% or more	<ul style="list-style-type: none"> • Harness and connector (CAN communication line is open or shorted) • (Air mix door motor is open or shorted)

DIAGNOSIS SYSTEM (HVAC)

< SYSTEM DESCRIPTION >

[WITH 7 INCH DISPLAY]

DTC	Items (CONSULT screen terms)	Diagnostic item is detected when...	Possible cause
B2634	PASS AIRMIX ACTR SHORT	Air mix door PBR (passenger side) position 5% or less	<ul style="list-style-type: none"> Air mix door motor (passenger side) A/C auto amp. Harness and connector (CAN communication line is open or shorted) (Air mix door motor is open or shorted)
B2635	PASS AIRMIX ACTR OPEN	Air mix door PBR (passenger side) position 95% or more	
B2636	DR VENT DOOR FAIL	When the malfunctioning door position is detected at VENT position	<ul style="list-style-type: none"> Mode door motor A/C auto amp. Harness and connector (CAN communication line is open or shorted) (Mode door motor is open or shorted)
B2637	DR B/L DOOR FAIL	When the malfunctioning door position is detected at B/L position	
B2638	DR D/F1 DOOR FAIL	When the malfunctioning door position is detected at FOOT position	
B2639	DR DEF DOOR FAIL	When the malfunctioning door position is detected at DEF position	
B263D	FRE DOOR FAIL	When the malfunctioning intake door position is detected at FRE position	<ul style="list-style-type: none"> Intake door motor A/C auto amp. Harness and connector (CAN communication line is open or shorted) (Intake door motor is open or shorted)
B263E	20P FRE DOOR FAIL	When the malfunctioning intake door position is detected at 20%FRE position	
B263F	REC DOOR FAIL	When the malfunctioning intake door position is detected at REC position	
B2654	D/F2 DOOR FAIL	When the malfunctioning door position is detected at D/F position	<ul style="list-style-type: none"> Mode door motor A/C auto amp. Harness and connector (CAN communication line is open or shorted) (Mode door motor is open or shorted)
B2655	B/L2 DOOR FAIL	When the malfunctioning door position is detected at B/L2 position	
B2661	UPPER VENT DOOR OPEN POSI FAIL	When the malfunctioning upper ventilator door position is detected at open position.	<ul style="list-style-type: none"> Upper ventilator door motor A/C auto amp. Harness and connector (CAN communication line is open or shorted) (Upper ventilator door motor is open or shorted)
B2662	UPPER VENT DOOR MID POSI FAIL	When the malfunctioning upper ventilator door position is detected at middle position.	
B2663	UPPER VENT DOOR SHUT POSI FAIL	When the malfunctioning upper ventilator door position is detected at shut position.	

*: Perform self-diagnosis under sunshine. When performing indoors, aim a light (more than 60 W) at sunload sensor, otherwise self-diagnosis indicates even though the sunload sensor is functioning normally.

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Display item list

Monitor item [Unit]	Description
COMP REQ SIG [On/Off]	Displays A/C switch ON/OFF status transmitted to other units via CAN communication
FAN REQ SIG [On/Off]	Displays blower switch ON/OFF status transmitted to other units via CAN communication
AMB TEMP SEN [°C]	Ambient sensor value converted from ambient sensor signal received from ambient sensor
IN-VEH TEMP [°C]	In-vehicle sensor value converted from in-vehicle sensor signal received from in-vehicle sensor

DIAGNOSIS SYSTEM (HVAC)

< SYSTEM DESCRIPTION >

[WITH 7 INCH DISPLAY]

Monitor item [Unit]	Description
INT TEMP SEN [°C]	Intake sensor value converted from intake sensor signal received from intake sensor
SUNLOAD SEN [w/m ²]	Sunload sensor value converted from sunload sensor signal received from sunload sensor
AMB SEN CAL [°C]	Ambient sensor value calculated by A/C auto amp.
IN-VEH CAL [°C]	In-vehicle sensor value calculated by A/C auto amp.
INT TEMP CAL [°C]	Intake sensor value calculated by A/C auto amp.
SUNL SEN CAL [w/m ²]	Sunload sensor value calculated by A/C auto amp.
FAN DUTY	Duty ratio of blower motor judged by A/C auto amp.
XM	Target discharge air temperature judged by A/C auto amp. according to the temperature setting and the value from each sensor
ENG COOL TEMP [°C]	Water temperature signal value received from ECM via CAN communication
VEHICLE SPEED [Mph (km/h)]	Vehicle speed signal value received from meter via CAN communication

ACTIVE TEST

Test item	Description
ALL SEG	NOTE: <ul style="list-style-type: none"> Item can be displayed but cannot be tested. When choosing to turn "ALL SEG" on, error message is displayed but it is not malfunction.
HVAC TEST	The operation check of A/C system can be performed by selecting the mode. Refer to the following table for the conditions of each mode.

HVAC TEST

	Test item						
	MODE 1	MODE 2	MODE 3	MODE 4	MODE 5	MODE 6	MODE 7
Mode door position	VENT1	VENT2	B/L1	B/L2	FOOT	D/F	DEF
Intake door position	REC	REC	20%FRE	20%FRE	FRE	FRE	FRE
Air mix door position (driver & passenger side)	FULL COLD	FULL HOT	FULL COLD	FULL HOT	FULL HOT	FULL HOT	FULL HOT
Blower motor duty ratio	35%	35%	61%	61%	81%	81%	35%
Compressor (Magnet clutch)	ON	ON	ON	ON	OFF	OFF	ON
Upper ventilator door	OPEN	SHUT	OPEN	SHUT	SHUT	SHUT	SHUT

NOTE:

Perform the inspection of each output device after starting the engine because the compressor is operated.

WORK SUPPORT

Work item	Description	Reference
TEMP SET CORRECT (Setting of difference between temperature setting and control temperature)	If the temperature felt by the customer is different than the air flow temperature controlled by the temperature setting, the auto amplifier control temperature can be adjusted to compensate for the temperature setting.	HAC-136, "Temperature Setting Trimmer"
BLOW SET (Blow setting to DEF in FOOT mode)	In the FOOT mode, the air blowing to the DEF can change ON/OFF.	HAC-136, "Foot Position Setting Trimmer"

DIAGNOSIS SYSTEM (HVAC)

< SYSTEM DESCRIPTION >

[WITH 7 INCH DISPLAY]

Work item	Description	Reference
<p>FRE MEMORY SET (FRE memory function setting)</p>	<ul style="list-style-type: none"> • If the ignition switch is turned to the OFF position while the FRE switch is set to ON (fresh air intake), "Perform the memory" or "Do not perform the memory" of the FRE switch ON (fresh air intake) condition can be selected. • If "Perform the memory" was set, the FRE switch will be ON (fresh air intake) when turning the ignition switch to the ON position again. • If "Do not perform the memory" was set, the air inlets will be controlled automatically when turning the ignition switch to the ON position again. 	<p>HAC-137. "Inlet Port Memory Function (FRE)"</p>
<p>REC MEMORY SET (REC memory function setting)</p>	<ul style="list-style-type: none"> • If the ignition switch is turned to the OFF position while the REC switch is set to ON (recirculation), "Perform the memory" or "Do not perform the memory" of the REC switch ON (recirculation) condition can be selected. • If "Perform the memory" was set, the REC switch will be ON (recirculation) when turning the ignition switch to the ON position again. • If "Do not perform the memory" was set, the air inlets will be controlled automatically when turning the ignition switch to the ON position again. 	<p>HAC-137. "Inlet Port Memory Function (REC)"</p>

NOTE:

When the battery cable is disconnected from the negative terminal or when the battery voltage becomes 10 V or less, the setting of WORK SUPPORT may be cancelled.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

DTC/CIRCUIT DIAGNOSIS

U1000 CAN COMM CIRCUIT

Description

INFOID:000000009722156

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with two communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Signal Chart. Refer to [LAN-17, "How to Use CAN Communication Signal Chart"](#).

DTC Logic

INFOID:000000009722157

DTC DETECTION LOGIC

DTC	Items (CONSULT screen terms)	Diagnostic item is detected when...	Possible cause
U1000	CAN COMM CIRCUIT	When A/C auto amp. is not transmitting or receiving CAN communication signal for 2 or more seconds.	CAN communication system

Diagnosis Procedure

INFOID:000000009722158

1. CHECK WITH SELF-DIAGNOSIS FUNCTION OF CONSULT

1. Turn ignition switch ON and wait for 2 or more seconds.
2. Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.

Is "CAN COMM CIRCUIT" displayed?

- YES >> Perform trouble diagnosis for the CAN communication system. Refer to [LAN-18, "Trouble Diagnosis Flow Chart"](#).
- NO >> Perform the intermittent malfunction diagnosis. Refer to [GI-44, "Intermittent Incident"](#).

U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

[WITH 7 INCH DISPLAY]

U1010 CONTROL UNIT (CAN)

Description

INFOID:000000009722159

Initial diagnosis of A/C auto amp.

DTC Logic

INFOID:000000009722160

DTC DETECTION LOGIC

DTC	Items (CONSULT screen terms)	Diagnostic item is detected when...	Possible cause
U1010	CONTROL UNIT (CAN)	When detecting error during the initial diagnosis of CAN controller of A/C auto amp.	A/C auto amp.

Diagnosis Procedure

INFOID:000000009722161

1. CHECK WITH SELF-DIAGNOSIS FUNCTION OF CONSULT

Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.

Is DTC No. "U1010" displayed?

YES >> Replace A/C auto amp.

NO >> INSPECTION END

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

B257B, B257C AMBIENT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH 7 INCH DISPLAY]

B257B, B257C AMBIENT SENSOR


Description

INFOID:000000009722162


COMPONENT DESCRIPTION

Ambient Sensor

- The ambient sensor (1) is installed to the front bumper (left back).
- It detects ambient temperature and converts it into a resistance value which is then input into the A/C auto amp.



Ambient Sensor Circuit



AMBIENT TEMPERATURE INPUT PROCESS

The A/C auto amp. equips a processing circuit for the ambient sensor input. However, when the temperature detected by the ambient sensor increases quickly, the processing circuit retards the A/C auto amp. function. It only allows the A/C auto amp. to recognize an ambient temperature increase of 0.33°C (0.6°F) per 100 seconds.

As an example, consider stopping for a few minutes after high speed driving. Although the actual ambient temperature has not changed, the temperature detected by the ambient sensor increases. This is because the heat from the engine compartment can radiate to the front bumper area, the location of the ambient sensor.

DTC Logic

INFOID:000000009722163

DTC DETECTION LOGIC

NOTE:

- If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-170, "DTC Logic"](#) or [HAC-171, "DTC Logic"](#).
- If there is an open circuit in the ambient sensor, A/C auto amp. registers extreme cold [-44°C (-47°F)] and adjusts the temperature control warmer.

DTC	Items (CONSULT screen terms)	Diagnostic item is detected when...	Possible cause
B257B	AMBIENT SENSOR	Detected temperature at ambient sensor -44°C (-47°F) or less	<ul style="list-style-type: none"> • Ambient sensor • A/C auto amp. • Harness and connector (Ambient sensor circuit is open, or there is a short in the circuit)
B257C		Detected temperature at ambient sensor 100°C (212°F) or more	

DTC CONFIRMATION PROCEDURE

1. CHECK WITH SELF-DIAGNOSIS FUNCTION OF CONSULT

B257B, B257C AMBIENT SENSOR

[WITH 7 INCH DISPLAY]

< DTC/CIRCUIT DIAGNOSIS >

- Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
- Check if any DTC No. is displayed in the self-diagnosis results.

NOTE:

- If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-170, "DTC Logic"](#) or [HAC-171, "DTC Logic"](#).
- If there is an open circuit in the ambient sensor, A/C auto amp. registers extreme cold [-44°C (-47°F)] and adjusts the temperature control warmer.

Is DTC No. "B257B" or "B257C" displayed?

- YES >> Perform trouble diagnosis for the ambient sensor. Refer to [HAC-173, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009722164

1. CHECK VOLTAGE BETWEEN AMBIENT SENSOR AND GROUND

- Disconnect ambient sensor connector.
- Turn ignition switch ON.
- Check voltage between ambient sensor harness connector and ground.

(+)		(-)	Voltage
Ambient sensor		—	
Connector	Terminal		
E337	1	Ground	Approx. 5 V

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> GO TO 4.

2. CHECK CIRCUIT CONTINUITY BETWEEN AMBIENT SENSOR AND A/C AUTO AMP.

- Turn ignition switch OFF.
- Disconnect A/C auto amp. connector.
- Check continuity between ambient sensor harness connector and A/C auto amp. harness connector.

Ambient sensor		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
E337	2	M50	37	Existed

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair harness or connector.

3. CHECK AMBIENT SENSOR

Check ambient sensor. Refer to [HAC-174, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace A/C auto amp.
 NO >> Replace ambient sensor.

4. CHECK CIRCUIT CONTINUITY BETWEEN AMBIENT SENSOR AND A/C AUTO AMP.

- Turn ignition switch OFF.
- Disconnect A/C auto amp. connector.
- Check continuity between ambient sensor harness connector and A/C auto amp. harness connector.

Ambient sensor		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
E337	1	M50	35	Existed

- Check continuity between ambient sensor harness connector and ground.

B257B, B257C AMBIENT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH 7 INCH DISPLAY]

Ambient sensor		—	Continuity
Connector	Terminal		
E337	1	Ground	Not existed

Is the inspection result normal?

YES >> Replace A/C auto amp.

NO >> Repair harness or connector.

Component Inspection

INFOID:000000009722165

1. CHECK AMBIENT SENSOR

1. Turn ignition switch OFF.
2. Disconnect ambient sensor connector. Refer to [VTL-90. "Exploded View"](#).
3. Check resistance between ambient sensor terminals.

Terminal		Condition	Resistance kΩ
		Temperature °C (°F)	
1	2	-15 (5)	12.73
		-10 (14)	9.92
		-5 (23)	7.80
		0 (32)	6.19
		5 (41)	4.95
		10 (50)	3.99
		15 (59)	3.24
		20 (68)	2.65
		25 (77)	2.19
		30 (86)	1.81
		35 (95)	1.51
		40 (104)	1.27
45 (113)	1.07		

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace ambient sensor.

B2578, B2579 IN-VEHICLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH 7 INCH DISPLAY]


B2578, B2579 IN-VEHICLE SENSOR

Description


INFOID:000000009722166

In-vehicle Sensor

- The in-vehicle sensor (1) is located on instrument driver lower panel (2).
- It converts variations in compartment air temperature drawn from the aspirator into a resistance value. It is then input into the A/C auto amp.





In-vehicle Sensor Circuit



Aspirator

The aspirator (1) is located on driver side of heater & cooling unit assembly. It produces vacuum pressure due to air discharged from the heater & cooling unit assembly, continuously taking compartment air in the aspirator.



DTC Logic

INFOID:000000009722167

DTC DETECTION LOGIC

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

B2578, B2579 IN-VEHICLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH 7 INCH DISPLAY]

NOTE:

If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-170, "DTC Logic"](#) or [HAC-171, "DTC Logic"](#).

DTC	Items (CONSULT screen terms)	Diagnostic item is detected when...	Possible cause
B2578	IN-VEHICLE SENSOR	Detected temperature at in-vehicle sensor -44°C (-47°F) or less	<ul style="list-style-type: none"> In-vehicle sensor A/C auto amp. Harness and connector (In-vehicle sensor circuit is open, or there is a short in the circuit)
B2579		Detected temperature at in-vehicle sensor 100°C (212°F) or more	

DTC CONFIRMATION PROCEDURE

1. CHECK WITH SELF-DIAGNOSIS FUNCTION OF CONSULT

- Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
- Check if any DTC No. is displayed in the self-diagnosis results.

NOTE:

If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-170, "DTC Logic"](#) or [HAC-171, "DTC Logic"](#).

Is DTC No. "B2578" or "B2579" displayed?

- YES >> Perform trouble diagnosis for the in-vehicle sensor. Refer to [HAC-176, "Diagnosis Procedure"](#).
- NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009722168

1. CHECK VOLTAGE BETWEEN IN-VEHICLE SENSOR AND GROUND

- Disconnect in-vehicle sensor connector.
- Turn ignition switch ON.
- Check voltage between in-vehicle sensor harness connector and ground.

(+)		(-)	Voltage
In-vehicle sensor		—	
Connector	Terminal		
M41	1	Ground	

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> GO TO 4.

2. CHECK CIRCUIT CONTINUITY BETWEEN IN-VEHICLE SENSOR AND A/C AUTO AMP.

- Turn ignition switch OFF.
- Disconnect A/C auto amp. connector.
- Check continuity between in-vehicle sensor harness connector and A/C auto amp. harness connector.

In-vehicle sensor		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M41	2	M50	37	Existed

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair harness or connector.

3. CHECK IN-VEHICLE SENSOR

Check in-vehicle sensor. Refer to [HAC-177, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace A/C auto amp.

B2578, B2579 IN-VEHICLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH 7 INCH DISPLAY]

NO >> Replace in-vehicle sensor.

4.CHECK CIRCUIT CONTINUITY BETWEEN IN-VEHICLE SENSOR AND A/C AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect A/C auto amp. connector.
3. Check continuity between in-vehicle sensor harness connector and A/C auto amp. harness connector.

In-vehicle sensor		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M41	1	M50	36	Existed

4. Check continuity between in-vehicle sensor harness connector and ground.

In-vehicle sensor		—	Continuity
Connector	Terminal		
M41	1	Ground	Not existed

Is the inspection result normal?

YES >> Replace A/C auto amp.

NO >> Repair harness or connector.

Component Inspection

INFOID:000000009722169

1.CHECK IN-VEHICLE SENSOR

1. Turn ignition switch OFF.
2. Disconnect in-vehicle sensor connector. Refer to [VTL-91. "Exploded View"](#).
3. Check resistance between in-vehicle sensor terminals.

Terminal		Condition	Resistance kΩ
		Temperature °C (°F)	
1	2	-15 (5)	12.73
		-10 (14)	9.92
		-5 (23)	7.80
		0 (32)	6.19
		5 (41)	4.95
		10 (50)	3.99
		15 (59)	3.24
		20 (68)	2.65
		25 (77)	2.19
		30 (86)	1.81
		35 (95)	1.51
		40 (104)	1.27
45 (113)	1.07		

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace in-vehicle sensor.

B2581, B2582 INTAKE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH 7 INCH DISPLAY]


B2581, B2582 INTAKE SENSOR

Description


INFOID:000000009722170

Intake Sensor

- The intake sensor (1) is located on the evaporator (2).
- It converts air temperature after it passes through the evaporator into a resistance value which is then input to the A/C auto amp.



Intake Sensor Circuit



DTC Logic

INFOID:000000009722171

DTC DETECTION LOGIC

NOTE:

If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-170, "DTC Logic"](#) or [HAC-171, "DTC Logic"](#).

DTC	Items (CONSULT screen terms)	Diagnostic item is detected when...	Possible cause
B2581	INTAKE SENSOR	Detected temperature at intake sensor -33°C (-27°F) or less	<ul style="list-style-type: none"> • Intake sensor • A/C auto amp. • Harness and connector (Intake sensor circuit is open, or there is a short in the circuit)
B2582		Detected temperature at intake sensor 69°C (156°F) or more	

DTC CONFIRMATION PROCEDURE

1. CHECK WITH SELF-DIAGNOSIS FUNCTION OF CONSULT

1. Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
2. Check if any DTC No. is displayed in the self-diagnosis results.

NOTE:

If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-170, "DTC Logic"](#) or [HAC-171, "DTC Logic"](#).

Is DTC No. "B2581" or "B2582" displayed?

- YES >> Perform trouble diagnosis for the intake sensor. Refer to [HAC-178, "Diagnosis Procedure"](#).
- NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009722172

1. CHECK VOLTAGE BETWEEN INTAKE SENSOR AND GROUND

B2581, B2582 INTAKE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH 7 INCH DISPLAY]

1. Disconnect intake sensor connector.
2. Turn ignition switch ON.
3. Check voltage between intake sensor harness connector and ground.

(+)		(-)	Voltage
Intake sensor		—	
Connector	Terminal		
M42	1	Ground	Approx. 5 V

Is the inspection result normal?

YES >> GO TO 2.

NO >> GO TO 4.

2.CHECK CIRCUIT CONTINUITY BETWEEN INTAKE SENSOR AND A/C AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect A/C auto amp. connector.
3. Check continuity between intake sensor harness connector and A/C auto amp. harness connector.

Intake sensor		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M42	2	M50	37	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3.CHECK INTAKE SENSOR

Check intake sensor. Refer to [HAC-179, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace A/C auto amp.

NO >> Replace intake sensor.

4.CHECK CIRCUIT CONTINUITY BETWEEN INTAKE SENSOR AND A/C AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect A/C auto amp. connector.
3. Check continuity between intake sensor harness connector and A/C auto amp. harness connector.

Intake sensor		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M42	1	M50	16	Existed

4. Check continuity between intake sensor harness connector and ground.

Intake sensor		—	Continuity
Connector	Terminal		
M42	1	Ground	Not existed

Is the inspection result normal?

YES >> Replace A/C auto amp.

NO >> Repair harness or connector.

Component Inspection

INFOID:000000009722173

1.CHECK INTAKE SENSOR

1. Turn ignition switch OFF.
2. Disconnect intake sensor connector.
3. Check resistance between intake sensor terminals.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

B2581, B2582 INTAKE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH 7 INCH DISPLAY]

Terminal		Condition	Resistance kΩ
		Temperature °C (°F)	
1	2	-15 (5)	18.63
		-10 (14)	14.15
		-5 (23)	10.86
		0 (32)	8.41
		5 (41)	6.58
		10 (50)	5.19
		15 (59)	4.12
		20 (68)	3.30
		25 (77)	2.67
		30 (86)	2.17
		35 (95)	1.78
		40 (104)	1.46
		45 (113)	1.21

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace intake sensor.

B2630, B2631 SUNLOAD SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH 7 INCH DISPLAY]

B2630, B2631 SUNLOAD SENSOR


Description

INFOID:000000009722174


COMPONENT DESCRIPTION

Sunload Sensor

- The sunload sensor (1) is located on the driver's side instrument panel & pad.
- It detects sunload entering through windshield by means of a photo diode. The sensor converts the sunload into a current value which is then input into the A/C auto amp.



Sunload Sensor Circuit



SUNLOAD INPUT PROCESS

The A/C auto amp. also equips a processing circuit which averages the variations in detected sunload over a period of time. This prevents drastic swings in the air temperature control system operation due to small or quick variations in detected sunload.

For example, consider driving along a road bordered by an occasional group of large trees. The sunload detected by the sunload sensor varies whenever the trees obstruct the sunlight. The processing circuit averages the detected sunload over a period of time, so that the (insignificant) effect of the trees momentarily obstructing the sunlight does not cause any change in the air temperature control system operation. On the other hand, shortly after entering a long tunnel, the system recognizes the change in sunload, and the system reacts accordingly.

DTC Logic

INFOID:000000009722175

DTC DETECTION LOGIC

NOTE:

- If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-170. "DTC Logic"](#) or [HAC-171. "DTC Logic"](#).
- Sunload sensor may register a malfunction when indoors, at dusk, or at other times when light is insufficient. When performing the diagnosis indoors, light the sunload sensor with a lamp (60W or more).

DTC	Items (CONSULT screen terms)	Diagnostic item is detected when...	Possible cause
B2630	SUNLOAD SENSOR	Detected calorie at sunload sensor 64.7 w/m ² (56 kcal/m ² ·h) or less	<ul style="list-style-type: none"> • Sunload sensor • A/C auto amp. • Harness and connector (Sunload sensor circuit is open, or there is a short in the circuit)
B2631		Detected calorie at sunload sensor 2832 w/m ² (2436 kcal/m ² ·h) or more	

B2630, B2631 SUNLOAD SENSOR

[WITH 7 INCH DISPLAY]

< DTC/CIRCUIT DIAGNOSIS >

DTC CONFIRMATION PROCEDURE

1. CHECK WITH SELF-DIAGNOSIS FUNCTION OF CONSULT

1. Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
2. Check if any DTC No. is displayed in the self-diagnosis results.

NOTE:

- If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-170, "DTC Logic"](#) or [HAC-171, "DTC Logic"](#).
- Sunload sensor may register a malfunction when indoors, at dusk, or at other times when light is insufficient. When performing the diagnosis indoors, light the sunload sensor with a lamp (60W or more).

Is DTC No. "B2630" or "B2631" displayed?

- YES >> Perform trouble diagnosis for the sunload sensor. Refer to [HAC-182, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009722176

1. CHECK VOLTAGE BETWEEN SUNLOAD SENSOR AND GROUND

1. Disconnect sunload sensor connector.
2. Turn ignition switch ON.
3. Check voltage between sunload sensor harness connector and ground.

(+)		(-)	Voltage
Sunload sensor		—	
Connector	Terminal		
M74	1	Ground	Approx. 5 V

Is the inspection result normal?

- YES >> GO TO 2.
NO >> GO TO 4.

2. CHECK CIRCUIT CONTINUITY BETWEEN SUNLOAD SENSOR AND A/C AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect A/C auto amp. connector.
3. Check continuity between sunload sensor harness connector and A/C auto amp. harness connector.

Sunload sensor		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M74	2	M50	37	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair harness or connector.

3. CHECK SUNLOAD SENSOR

1. Reconnect sunload sensor connector and A/C auto amp. connector.
2. Check sunload sensor. Refer to [HAC-183, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace A/C auto amp.
NO >> Replace sunload sensor.

4. CHECK CIRCUIT CONTINUITY BETWEEN SUNLOAD SENSOR AND A/C AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect A/C auto amp. connector.
3. Check continuity between sunload sensor harness connector and A/C auto amp. harness connector.

B2630, B2631 SUNLOAD SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH 7 INCH DISPLAY]

Sunload sensor		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M74	1	M50	15	Existed

4. Check continuity between sunload sensor harness connector and ground.

Sunload sensor		—	Continuity
Connector	Terminal		
M74	1	Ground	Not existed

Is the inspection result normal?

YES >> Replace A/C auto amp.

NO >> Repair harness or connector.


Component Inspection

INFOID:000000009722177

1. CHECK SUNLOAD SENSOR

1. Turn ignition switch ON.
2. Check voltage between A/C auto amp. harness connector and ground.

(+) A/C auto amp.		(-)
Connector	Terminal	—
M50	15	Ground



NOTE:

Select a place where sunshine directly on it when checking sunload sensor.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace sunload sensor.

B2632, B2633 AIR MIX DOOR MOTOR (DRIVER SIDE)

< DTC/CIRCUIT DIAGNOSIS >

[WITH 7 INCH DISPLAY]

B2632, B2633 AIR MIX DOOR MOTOR (DRIVER SIDE)

Description

INFOID:000000009722178


COMPONENT DESCRIPTION

Air Mix Door Motor (Driver Side)

- The air mix door motor (driver side) (1) are attached to the heater & cooling unit assembly.

←: Vehicle front

- It rotates so that the air mix door is opened or closed to a position set by the A/C auto amp.
- Motor rotation is then conveyed through a shaft and the air mix door position feedback is then sent to the A/C auto amp. by PBR built-in air mix door motor.



DTC Logic

INFOID:000000009722179

DTC DETECTION LOGIC

NOTE:

If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-170. "DTC Logic"](#) or [HAC-171. "DTC Logic"](#).

DTC	Items (CONSULT screen terms)	Diagnostic item is detected when...	Possible cause
B2632	DR AIR MIX DOOR MOT	Air mix door PBR (driver side) position 95% or less	<ul style="list-style-type: none">• Air mix door motor (PBR internal circuit is open or shorted)• A/C auto amp.• Harness and connector (LAN communication line is open or shorted)
B2633		Air mix door PBR (driver side) position 5% or more	

DTC CONFIRMATION PROCEDURE

1. CHECK WITH SELF-DIAGNOSIS FUNCTION OF CONSULT

1. Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
2. Check if any DTC No. is displayed in the self-diagnosis results.

NOTE:

If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-170. "DTC Logic"](#) or [HAC-171. "DTC Logic"](#).

Is DTC No. "B2632" or "B2633" displayed?

YES >> Perform trouble diagnosis for the air mix door motor (driver side). Refer to [HAC-185. "Diagnosis Procedure"](#).

NO >> GO TO 2.

2. FUNCTION INSPECTION

1. Press temperature control "UP" dial (driver side) until 32°C (90°F) is displayed.
2. Check for warm air at discharge air outlets.
3. Operate the compressor.
4. Press temperature control "DOWN" dial (driver side) until 18°C (60°F) is displayed.
5. Check for cool air at air discharge outlets.

Does it operate normally?

YES >> END.

NO >> Check air mix door motor (driver side) installation, and repair or replace the malfunctioning parts.

B2632, B2633 AIR MIX DOOR MOTOR (DRIVER SIDE)

< DTC/CIRCUIT DIAGNOSIS >

[WITH 7 INCH DISPLAY]

Diagnosis Procedure

INFOID:000000009722180

1. CHECK POWER SUPPLY FOR AIR MIX DOOR MOTOR (DRIVER SIDE)

Check voltage between air mix door motor (driver side) harness connector and ground.

(+)		(-)	Voltage
Air mix door motor (driver side)		—	
Connector	Terminal		
M306	1	Ground	Battery voltage


Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the harnesses or connectors.

2. CHECK SIGNAL FOR AIR MIX DOOR MOTOR (DRIVER SIDE)

Check the output waveform (LAN signal) between air mix door motor (driver side) harness connector and ground using an oscilloscope.

(+)		(-)	Voltage
Air mix door motor (driver side)		—	
Connector	Terminal		
M306	3	Ground	

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the harnesses or connectors.

3. CHECK AIR MIX DOOR MOTOR (DRIVER SIDE) GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect air mix door motor (driver side) connector.
3. Check continuity between air mix door motor (driver side) harness connector and ground.

Air mix door motor (driver side)		(-)	Continuity
Connector	Terminal		
M306	2	Ground	Existed

Is the inspection result normal?

YES >> Replace air mix door motor (driver side).

NO >> Repair harness or connector.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

B2634, B2635 AIR MIX DOOR MOTOR (PASSENGER SIDE)

< DTC/CIRCUIT DIAGNOSIS >

[WITH 7 INCH DISPLAY]

B2634, B2635 AIR MIX DOOR MOTOR (PASSENGER SIDE)

Description

INFOID:000000009722181


COMPONENT DESCRIPTION

Air Mix Door Motor (Passenger Side)

- The air mix door motor (passenger side) (1) are attached to the heater & cooling unit assembly.

←: Vehicle front

- It rotates so that the air mix door is opened or closed to a position set by the A/C auto amp.
- Motor rotation is then conveyed through a shaft and the air mix door position feedback is then sent to the A/C auto amp. by PBR built-in air mix door motor.



DTC Logic

INFOID:000000009722182

DTC DETECTION LOGIC

NOTE:

If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-170. "DTC Logic"](#) or [HAC-171. "DTC Logic"](#).

DTC	Items (CONSULT screen terms)	Diagnostic item is detected when...	Possible cause
B2634	PASS AIR MIX DOOR MOT	Air mix door PBR (passenger side) position 95% or less	<ul style="list-style-type: none">• Air mix door motor (PBR internal circuit is open or shorted)• A/C auto amp.• Harness and connector (LAN communication line is open or shorted)
B2635		Air mix door PBR (passenger side) position 5% or more	

DTC CONFIRMATION PROCEDURE

1. CHECK WITH SELF-DIAGNOSIS FUNCTION OF CONSULT

1. Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
2. Check if any DTC No. is displayed in the self-diagnosis results.

NOTE:

If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-170. "DTC Logic"](#) or [HAC-171. "DTC Logic"](#).

Is DTC No. "B2634" or "B2635" displayed?

YES >> Perform trouble diagnosis for the air mix door motor (passenger side). Refer to [HAC-187. "Diagnosis Procedure"](#).

NO >> GO TO 2.

2. FUNCTION INSPECTION

1. Press temperature control "UP" dial (passenger side) until 32°C (90°F) is displayed.
2. Check for warm air at discharge air outlets.
3. Operate the compressor.
4. Press temperature control "DOWN" dial (passenger side) until 18°C (60°F) is displayed.
5. Check for cool air at air discharge outlets.

Does it operate normally?

YES >> END.

NO >> Check air mix door motor (passenger side) installation, and repair or replace the malfunctioning parts.

B2634, B2635 AIR MIX DOOR MOTOR (PASSENGER SIDE)

< DTC/CIRCUIT DIAGNOSIS >

[WITH 7 INCH DISPLAY]

Diagnosis Procedure

INFOID:000000009722183

1. CHECK POWER SUPPLY FOR AIR MIX DOOR MOTOR (PASSENGER SIDE)

Check voltage between air mix door motor (passenger side) harness connector and ground.

(+)		(-)	Voltage
Air mix door motor (passenger side)		—	
Connector	Terminal	Ground	Battery voltage
M307	1		


Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the harnesses or connectors.

2. CHECK SIGNAL FOR AIR MIX DOOR MOTOR (PASSENGER SIDE)

Check the output waveform (LAN signal) between air mix door motor (passenger side) harness connector and ground using an oscilloscope.

(+)		(-)	Voltage
Air mix door motor (passenger side)		—	
Connector	Terminal	Ground	 SJIA1453J
M307	3		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the harnesses or connectors.

3. CHECK AIR MIX DOOR MOTOR (PASSENGER SIDE) GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect air mix door motor (passenger side) connector.
3. Check continuity between air mix door motor (passenger side) harness connector and ground.

Air mix door motor (passenger side)		(-)	Continuity
Connector	Terminal	—	
M307	2	Ground	Existed

Is the inspection result normal?

YES >> Replace air mix door motor (passenger side).

NO >> Repair harness or connector.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

B2636, B2637, B2638, B2639, B2654, B2655 MODE DOOR MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH 7 INCH DISPLAY]

B2636, B2637, B2638, B2639, B2654, B2655 MODE DOOR MOTOR

Description


INFOID:000000009722184

COMPONENT DESCRIPTION

Mode Door Motor

- The mode door motor (1) are attached to the heater & cooling unit assembly.
- It rotates so that air is discharged from the outlet set by the A/C auto amp. Motor rotation is conveyed to a link which activates the mode door.

←: Vehicle front



DTC Logic

INFOID:000000009722185

DTC DETECTION LOGIC

NOTE:

If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-170, "DTC Logic"](#) or [HAC-171, "DTC Logic"](#).

DTC	Items (CONSULT screen terms)	Diagnostic item is detected when...	Possible cause
B2636	DR VENT DOOR FAIL	When the malfunctioning door position is detected at VENT position	<ul style="list-style-type: none">• Mode door motor (PBR internal circuit is open or shorted)• A/C auto amp.• Harness and connector (LAN communication line is open or shorted)
B2637	DR B/L DOOR FAIL	When the malfunctioning door position is detected at B/L position	
B2638	DR D/F1 DOOR FAIL	When the malfunctioning door position is detected at FOOT position	
B2639	DR DEF DOOR FAIL	When the malfunctioning door position is detected at DEF position	
B2654	D/F2 DOOR FAIL	When the malfunctioning door position is detected at D/F position	
B2655	B/L2 DOOR FAIL	When the malfunctioning door position is detected at B/L2 position	

DTC CONFIRMATION PROCEDURE

1. CHECK WITH SELF-DIAGNOSIS FUNCTION OF CONSULT

1. Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
2. Check if any DTC No. is displayed in the self-diagnosis results.

NOTE:

If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-170, "DTC Logic"](#) or [HAC-171, "DTC Logic"](#).

Is DTC No. "B2636", "B2637", "B2638", "B2639", "B2654" or "B2655" displayed?

- YES >> Perform trouble diagnosis for the mode door motor. Refer to [HAC-189, "Diagnosis Procedure"](#).
- NO >> GO TO 2.

2. FUNCTION INSPECTION

1. Press MODE switch and DEF switch.
2. Each position indicator should change shape.

B2636, B2637, B2638, B2639, B2654, B2655 MODE DOOR MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH 7 INCH DISPLAY]

3. Confirm that air discharge comes out according to the air distribution table at below. Refer to [HAC-143](#). "[System Description](#)".



Discharge air flow							
Mode position indication	Condition	Air outlet/distribution					
		VENT			FOOT		DEF
		Front	Upper	Rear	Front	Rear	
	DUAL switch: OFF UPPER VENT switch : ON	81%	8%	11%	—	—	—
		41%	10%	17%	24%	8%	—
		12%	12%	16%	27%	10%	23%
		11%	11%	14%	25%	10%	29%
		11%	11%	12%	—	—	66%

JPIIA0509GB

Discharge air flow							
Mode position indication	Condition	Air outlet/distribution					
		VENT			FOOT		DEF
		Front	Upper	Rear	Front	Rear	
	DUAL switch: OFF UPPER VENT switch : OFF	88%	—	12%	—	—	—
		47%	—	18%	26%	9%	—
		13%	—	17%	33%	12%	25%
		12%	—	16%	28%	12%	32%
		11%	—	15%	—	—	74%

JPIIA0510GB

NOTE:

Confirm that the compressor clutch is engaged (Sound or visual inspection) and intake door position is at FRE when DEF () or D/F () is selected.

Does it operate normally?

YES >> INSPECTION END

NO >> Check mode door motor installation, and repair or replace the malfunctioning parts.

Diagnosis Procedure

INFOID:000000009722186

1. CHECK POWER SUPPLY FOR MODE DOOR MOTOR

Check voltage between mode door motor harness connector and ground.

(+)		(-)	Voltage
Mode door motor		—	
Connector	Terminal	Ground	Battery voltage
M310	1		

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair harness or connector.

2. CHECK SIGNAL FOR MODE DOOR MOTOR

Confirm A/C LAN signal between mode door motor harness connector and ground using an oscilloscope.


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

HAC

B2636, B2637, B2638, B2639, B2654, B2655 MODE DOOR MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH 7 INCH DISPLAY]

(+)		(-)	Voltage
Mode door motor		—	
Connector	Terminal		
M310	3	Ground	 <p style="text-align: right; font-size: small;">SJIA1453J</p>

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3. CHECK MODE DOOR MOTOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect mode door motor connector.
3. Check continuity between mode door motor harness connector and ground.

Mode door motor		—	Continuity
Connector	Terminal		
M310	2	Ground	Existed

Is the inspection result normal?

YES >> Replace mode door motor.

NO >> Repair harness or connector.

B263D, B263E, B263F INTAKE DOOR MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH 7 INCH DISPLAY]

B263D, B263E, B263F INTAKE DOOR MOTOR

Description

INFOID:000000009722187


COMPONENT DESCRIPTION

Intake Door Motor

- The intake door motor (1) is attached to the blower unit.

←: Vehicle front

- It rotates so that air is drawn from inlets set by the A/C auto amp. Motor rotation is conveyed to a lever which activates the intake door.



JPIA0516ZZ

DTC Logic

INFOID:000000009722188

DTC DETECTION LOGIC

NOTE:

If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-170, "DTC Logic"](#) or [HAC-171, "DTC Logic"](#).

DTC	Items (CONSULT screen terms)	Diagnostic item is detected when...	Possible cause
B263D	FRE DOOR FAIL	When the malfunctioning intake door position is detected at FRE position	<ul style="list-style-type: none"> Intake door motor (PBR internal circuit is open or shorted) A/C auto amp. Harness and connector (LAN communication line is open or shorted)
B263E	20P FRE DOOR FAIL	When the malfunctioning intake door position is detected at 20%FRE position	
B263F	REC DOOR FAIL	When the malfunctioning intake door position is detected at REC position	

DTC CONFIRMATION PROCEDURE

1. CHECK WITH SELF-DIAGNOSIS FUNCTION OF CONSULT

- Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
- Check if any DTC No. is displayed in the self-diagnosis results.

NOTE:

If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-170, "DTC Logic"](#) or [HAC-171, "DTC Logic"](#).

Is DTC No. "B263D", "B263E" or "B263F" displayed?

- YES >> Perform trouble diagnosis for the intake door motor. Refer to [HAC-192, "Diagnosis Procedure"](#).
 NO >> GO TO 2.

2. FUNCTION INSPECTION

- Press intake switch.
- The intake switch indicator is turned ON. (REC position)
- Listen for intake door position change (Slight change of blower sound can be heard.).
- Press intake switch again.
- The intake switch indicator is turned OFF. (FRE position)
- Listen for intake door position change (Slight change of blower sound can be heard.).

Does it operate normally?

- YES >> INSPECTION END
 NO >> Check intake door motor installation, and repair or replace the malfunctioning parts.

B263D, B263E, B263F INTAKE DOOR MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH 7 INCH DISPLAY]

INFOID:00000009722189

Diagnosis Procedure

1. CHECK POWER SUPPLY FOR INTAKE DOOR MOTOR

Check voltage between intake door motor harness connector and ground.

(+)		(-)	Voltage
Intake door motor		—	
Connector	Terminal	Ground	Battery voltage
M304	1		


Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair harness or connector.

2. CHECK SIGNAL FOR INTAKE DOOR MOTOR

Confirm A/C LAN signal between intake door motor harness connector and ground using an oscilloscope.

(+)		(-)	Voltage
Intake door motor		—	
Connector	Terminal	Ground	
M304	3		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3. CHECK INTAKE DOOR MOTOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect intake door motor connector.
3. Check continuity between intake door motor harness connector and ground.

Intake door motor		(-)	Continuity
Intake door motor		—	
Connector	Terminal	Ground	Existed
M304	2		

Is the inspection result normal?

YES >> Replace intake door motor.

NO >> Repair harness or connector.

B2661, B2662, B2663 UPPER VENTILATOR DOOR MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH 7 INCH DISPLAY]

B2661, B2662, B2663 UPPER VENTILATOR DOOR MOTOR

Description

INFOID:000000009722190


COMPONENT DESCRIPTION

Upper Ventilator Door Motor

- The upper ventilator door motor (1) are attached to the heater & cooling unit assembly.

←: Vehicle front

- Upper ventilator door motor operates by UPPER VENT switch ON/OFF when the DEF switch is OFF.
- Motor rotation is conveyed to a link which activates the upper ventilator door.



DTC Logic

INFOID:000000009722191

DTC DETECTION LOGIC

NOTE:

If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-170, "DTC Logic"](#) or [HAC-171, "DTC Logic"](#).

DTC	Items (CONSULT screen terms)	Diagnostic item is detected when...	Possible cause
B2661	UPPER VENT DOOR MOT	When the malfunctioning upper ventilator door position is detected at open position.	<ul style="list-style-type: none"> Upper ventilator door motor (PBR internal circuit is open or shorted) A/C auto amp. Harness and connector (LAN communication line is open or shorted)
B2662		When the malfunctioning upper ventilator door position is detected at middle position.	
B2663		When the malfunctioning upper ventilator door position is detected at shut position.	

DTC CONFIRMATION PROCEDURE

1. CHECK WITH SELF-DIAGNOSIS FUNCTION OF CONSULT

- Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
- Check if any DTC No. is displayed in the self-diagnosis results.

NOTE:

If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-170, "DTC Logic"](#) or [HAC-171, "DTC Logic"](#).

Is DTC No. "B2661", "B2662" or "B2663" displayed?

YES >> Perform trouble diagnosis for the upper ventilator door motor. Refer to [HAC-194, "Diagnosis Procedure"](#).

NO >> GO TO 2.

2. FUNCTION INSPECTION

- Press the UPPER VENT switch.
- The UPPER VENT switch indicator is turned ON.

B2661, B2662, B2663 UPPER VENTILATOR DOOR MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH 7 INCH DISPLAY]

3. Check that the air blown from UPPER VENT does not greatly deviate from the air mix ratio.

Discharge air flow							
Mode position indication	Condition	Air outlet/distribution					
		VENT			FOOT		DEF
		Front	Upper	Rear	Front	Rear	
	DUAL switch: OFF UPPER VENT switch : ON	81%	8%	11%	—	—	—
		41%	10%	17%	24%	8%	—
		12%	12%	16%	27%	10%	23%
		11%	11%	14%	25%	10%	29%
		11%	11%	12%	—	—	66%

JPIIA0509GB

4. Press the UPPER VENT switch again.
5. The UPPER VENT switch indicator is turned OFF.
6. The air blown from UPPER VENT stops.

Does it operate normally?

YES >> INSPECTION END

NO >> Check upper ventilator door motor installation, and repair or replace the malfunctioning parts.

Diagnosis Procedure

INFOID:000000009722192

1.CHECK POWER SUPPLY FOR UPPER VENTILATOR DOOR MOTOR

Check voltage between upper ventilator door motor harness connector and ground.

(+)		(-)	Voltage
Upper ventilator door motor		—	
Connector	Terminal		
M308	1	Ground	Battery voltage


Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair harness or connector.

2.CHECK SIGNAL FOR UPPER VENTILATOR DOOR MOTOR

Confirm A/C LAN signal between upper ventilator door motor harness connector and ground using an oscilloscope.

(+)		(-)	Voltage
Upper ventilator door motor		—	
Connector	Terminal		
M308	3	Ground	

SJIA1453J

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

B2661, B2662, B2663 UPPER VENTILATOR DOOR MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH 7 INCH DISPLAY]

3. CHECK UPPER VENTILATOR DOOR MOTOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect upper ventilator door motor connector.
3. Check continuity between upper ventilator door motor harness connector and ground.

Upper ventilator door motor		—	Continuity
Connector	Terminal		
M308	2	Ground	Existed

Is the inspection result normal?

- YES >> Replace upper ventilator door motor.
NO >> Repair harness or connector.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

BLOWER MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH 7 INCH DISPLAY]

BLOWER MOTOR


Description

INFOID:000000009722193


COMPONENT DESCRIPTION

Brush-less Motor

The blower motor utilizes a brush-less motor with a rotating magnet. Quietness is improved over previous motors where the brush was the point of contact and the coil rotated.



Blower Motor Circuit



Component Function Check

INFOID:000000009722194

1. CHECK OPERATION

1. Warm up the engine.
2. Operate the fan control dial. Check that the fan speed and indicator are switched for all fan speeds.

Does it operate normally?

YES >> INSPECTION END

NO >> Perform trouble diagnosis for the blower motor. Refer to [HAC-196, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009722195

1. CHECK WITH SELF-DIAGNOSIS FUNCTION OF CONSULT

1. Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
2. Check if any DTC No. is displayed in the self-diagnosis results.

NOTE:

If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-170, "DTC Logic"](#) or [HAC-171, "DTC Logic"](#).

Is any DTC No. displayed?

YES >> Perform the diagnosis that is applicable to the sensor and actuator. Refer to [HAC-230, "DTC Index"](#).

NO >> GO TO 2.

2. CHECK WITH ACTIVE TEST OF CONSULT

1. Using CONSULT, perform "HVAC TEST" "ACTIVE TEST" of HVAC to check each output device. Refer to [HAC-166, "CONSULT Function"](#).

NOTE:

Perform the ACTIVE TEST after starting the engine because the compressor is operated.

BLOWER MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH 7 INCH DISPLAY]

- Check that the blower motor control signal changes according to each indicator signal.

	Test item						
	MODE 1	MODE 2	MODE 3	MODE 4	MODE 5	MODE 6	MODE 7
Mode door position	VENT1	VENT2	B/L1	B/L2	FOOT	D/F	DEF
Intake door position	REC	REC	20%FRE	20%FRE	FRE	FRE	FRE
Air mix door position (driver & passenger side)	FULL COLD	FULL HOT	FULL COLD	FULL HOT	FULL HOT	FULL HOT	FULL HOT
Blower motor duty ratio	35%	35%	61%	61%	81%	81%	35%
Compressor (Magnet clutch)	ON	ON	ON	ON	OFF	OFF	ON
Upper ventilator door	OPEN	SHUT	OPEN	SHUT	SHUT	SHUT	SHUT

NOTE:

Perform the inspection of each output device after starting the engine because the compressor is operated.

Does it operate normally?

- YES >> INSPECTION END
 NO >> GO TO 3.

3.CHECK POWER SUPPLY FOR BLOWER MOTOR

- Disconnect blower motor connector.
- Turn ignition switch ON.
- Check voltage between blower motor harness connector and ground.

(+)		(-)	Voltage
Blower motor		—	
Connector	Terminal		
M98	1	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> GO TO 7.

4.CHECK BLOWER MOTOR GROUND CIRCUIT

- Turn ignition switch OFF.
- Check continuity between blower motor harness connector and ground.

Blower motor		—	Continuity
Connector	Terminal		
M98	3	Ground	Existed

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> Repair harness or connector.

5.CHECK BLOWER MOTOR CIRCUIT CONTINUITY

- Disconnect A/C auto amp. connector.
- Check continuity between blower motor harness connector and A/C auto amp. harness connector.

Blower motor		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M98	2	M50	32	Existed

Is the inspection result normal?

- YES >> GO TO 6.

BLOWER MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH 7 INCH DISPLAY]

NO >> Repair harness or connector.

6. CHECK A/C AUTO AMP. OUTPUT SIGNAL

1. Reconnect blower motor connector and A/C auto amp. connector.
2. Turn ignition switch ON.
3. Set MODE switch to the VENT position.
4. Check the output waveform between blower motor harness connector and ground using an oscilloscope, while varying the fan speed from 1 to 7.

Blower fan speed (Manual) VENT mode	1st	2nd	3rd	4th	5th	6th	7th
Blower motor connector M 98 terminal No. 2 (Oscilloscope)							
	Approx. 1.6 ms	Approx. 1.6 ms	Approx. 1.6 ms	Approx. 1.6 ms	Approx. 1.6 ms	Approx. 1.6 ms	Approx. 1.6 ms
Duty ratio	Approx. 25%	Approx. 33%	Approx. 41%	Approx. 51%	Approx. 61%	Approx. 71%	Approx. 81%

NOTE: Duty ratio = $\frac{T_x}{\text{Approx. } 1.6 \text{ ms}} \times 100 (\%)$

JPIIA0616GB

Is the inspection result normal?

- YES >> Replace the blower motor.
 NO >> Replace the A/C auto amp.

7. CHECK POWER VOLTAGE OF BLOWER RELAY

1. Turn the ignition switch OFF.
2. Remove the blower relay. Refer to [PG-91, "Fuse, Connector and Terminal Arrangement"](#).
3. Turn the ignition switch ON.
4. Check the voltage between blower relay fuse block side terminal and ground. Refer to [PG-91, "Fuse, Connector and Terminal Arrangement"](#) for relay terminal assignment.

(+)	(-)	Voltage
Blower relay	—	
1	Ground	Battery voltage
3		

Is the inspection result normal?

- YES >> GO TO 8.
 NO >> Inspection the power supply circuit. Refer to [PG-47, "Wiring Diagram - IGNITION POWER SUPPLY -"](#).

8. CHECK BLOWER RELAY

1. Turn the ignition switch OFF.
2. Install the blower relay. Refer to [PG-91, "Fuse, Connector and Terminal Arrangement"](#).
3. Turn the ignition switch ON.
4. Check the operating sound of blower relay.

Is the inspection result normal?

- YES >> GO TO 9.
 NO >> Replace the blower relay.

9. CHECK FUSE

Check 15A fuses (Nos. 21 and 22).

NOTE:

BLOWER MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH 7 INCH DISPLAY]

Refer to [PG-91, "Fuse, Connector and Terminal Arrangement"](#) for fuse location.

Is the inspection result normal?

YES >> Repair the harnesses or connectors.

NO >> Replace the fuse after repairing the applicable circuit.

Component Inspection

INFOID:000000009722196

1. CHECK BLOWER MOTOR

1. Remove the blower motor. Refer to [VTL-97, "Exploded View"](#).

2. Check that the blower motor rotates smoothly.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace blower motor.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

MAGNET CLUTCH

Description

INFOID:000000009722197

The magnet clutch drives the compressor, by an IPDM E/R signal.

Component Function Check

INFOID:000000009722198

1. FUNCTION INSPECTION

1. Press AUTO switch.
2. "AUTO" is indicated on the display.
3. Press the A/C switch.
4. Check that the indicator of the A/C switch turns on. Check visually and by sound that the compressor is operating (the discharge air temperature or fan speed varies depending on the ambient temperature, in-vehicle temperature, and temperature setting).
5. Press the A/C switch again.
6. Check that the indicator of the A/C switch turns OFF. Check visually and by sound that the compressor stops.

Does it operate normally?

YES >> INSPECTION END

NO >> Perform trouble diagnosis for the compressor. Refer to [HAC-200. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009722199

1. INSPECTION IN AUTO ACTIVE TEST MODE

Perform "AUTO ACTIVE TEST". Refer to [PCS-10. "Diagnosis Description"](#).

Does it operate normally?

YES >> GO TO 6.

NO >> GO TO 2.

2. CHECK MAGNET CLUTCH POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect compressor connector.
3. Perform auto active test of IPDM E/R. Refer to [PCS-10. "Diagnosis Description"](#).
4. When auto active test operation sequence is compressor (magnet clutch) operation, check voltage between compressor harness connector and ground.

+		-	Voltage
Compressor			
Connector	Terminal		
F18	1	Ground	0 V ↔ Battery voltage

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 3.

3. CHECK FUSE

Check 10 A fuse (No. 49, located in IPDM E/R).

NOTE:

Refer to [PG-93. "Fuse, Connector and Terminal Arrangement"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.

4. CHECK MAGNET CLUTCH POWER SUPPLY CIRCUIT FOR OPEN

1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector and compressor harness connector.

MAGNET CLUTCH

< DTC/CIRCUIT DIAGNOSIS >

[WITH 7 INCH DISPLAY]

IPDM E/R		Compressor		Continuity
Connector	Terminal	Connector	Terminal	
F12	48	F18	1	Existed

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-37, "Removal and Installation"](#).

NO >> Repair harness or connector.

5.CHECK MAGNET CLUTCH GROUND CIRCUIT FOR OPEN

Check continuity between compressor harness connector and ground.

Compressor		—	Continuity
Connector	Terminal		
F18	2	Ground	Existed

Is the inspection result normal?

YES >> Replace magnet clutch. Refer to [HA-38, "MAGNET CLUTCH : Removal and Installation"](#).

NO >> Repair harness or connector.

6.CHECK WITH SELF-DIAGNOSIS FUNCTION OF CONSULT

- Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
- Check if any DTC No. is displayed in the self-diagnosis results.

NOTE:

If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-170, "DTC Logic"](#) or [HAC-171, "DTC Logic"](#).

Is any DTC No. displayed?

YES >> Perform the diagnosis that is applicable to the sensor and actuator. Refer to [HAC-230, "DTC Index"](#).

NO >> GO TO 7.

7.CHECK A/C AUTO AMP. INPUT SIGNAL

Using CONSULT, check "On/Off" of "COMP REQ SIG" and "FAN REQ SIG" in "DATA MONITOR" of HVAC. Refer to [HAC-166, "CONSULT Function"](#).

A/C SWITCH ON : COMP REQ SIG On

A/C SWITCH OFF : COMP REQ SIG Off

FAN CONTROL DIAL ON : FAN REQ SIG On

FAN CONTROL DIAL OFF : FAN REQ SIG Off

Is the inspection result normal?

YES >> GO TO 8.

NO >> Replace A/C auto amp.

8.CHECK REFRIGERANT PRESSURE SENSOR

Check refrigerant pressure sensor. Refer to [EC-465, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace malfunctioning parts.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[WITH 7 INCH DISPLAY]

POWER SUPPLY AND GROUND CIRCUIT

A/C AUTO AMP.

A/C AUTO AMP. : Description

INFOID:000000009722200


COMPONENT DESCRIPTION

A/C Auto Amp. (Air Conditioner Automatic Amplifier)


The A/C auto amp. (1) has a built-in microcomputer that processes information sent from various sensors needed for air conditioner operation. The air mix door motor(s), the mode door motor, the intake door motor, the upper ventilator door motor, the blower motor and the compressor are then controlled.

When the various switches and temperature control dial are operated, data is input to the A/C auto amp. from the AV control unit using CAN communication.

The A/C auto amp. is operated with control mechanisms. Signals from various switches and Potentio Temperature Control (PTC) are directly entered into the A/C auto amp.



Power Supply and Ground Circuit for A/C Auto Amp.



A/C AUTO AMP. : Component Function Check

INFOID:000000009722201

1. CHECK OPERATION

1. Press the AUTO switch, and then check that "AUTO" is shown on the display.
2. Operate the temperature control dial (driver side). Check that the fan speed or outlet changes. (The discharge air temperature or fan speed varies depending on the ambient temperature, in-vehicle temperature, and temperature setting.)

Does it operate normally?

YES >> INSPECTION END

NO >> Perform trouble diagnosis for the A/C system. Refer to [HAC-202. "A/C AUTO AMP. : Diagnosis Procedure"](#).

A/C AUTO AMP. : Diagnosis Procedure

INFOID:000000009722202

1. INSPECTION BY FAIL-SAFE FUNCTION

1. Turn the ignition switch ON.
2. After approximately 30 seconds, check that the air conditioner is operated by the fail-safe function (the operation display of air conditioner is not performed). Refer to [HAC-229. "Fail-Safe"](#).

Is the fail-safe function operated?

YES >> GO TO 5.

NO >> GO TO 2.

2. CHECK A/C AUTO AMP. POWER SUPPLY CIRCUIT

1. Disconnect the A/C auto amp. connector.
2. Check voltage between A/C auto amp. harness connector and ground.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[WITH 7 INCH DISPLAY]

(+)		(-)	Voltage		
A/C auto amp.		—	Ignition switch position		
Connector	Terminal		OFF	ACC	ON
M50	17	Ground	Approx. 0 V	Battery voltage	Battery voltage
	20		Approx. 0 V	Approx. 0 V	Battery voltage
	40		Battery voltage	Battery voltage	Battery voltage

Is the inspection result normal?

YES >> GO TO 4.
NO >> GO TO 3.

3.CHECK FUSE

Check 10A fuses [Nos. 3, 6 and 19, located in the fuse block (J/B)].

NOTE:

Refer to [PG-91, "Fuse, Connector and Terminal Arrangement"](#).

Is the inspection result normal?

YES >> Repair the harnesses or connectors.
NO >> Replace the fuse after repairing the applicable circuit.

4.CHECK A/C AUTO AMP. CIRCUIT CONTINUITY

1. Turn ignition switch OFF.
2. Check continuity between A/C auto amp. harness connector and ground.

A/C auto amp.		—	Continuity
Connector	Terminal		
M50	19	Ground	Existed
	39		

Is the inspection result normal?

YES >> GO TO 5.
NO >> Repair the harnesses or connectors.

5.CHECK PRESET SWITCH

Check the preset switch. Refer to [AV-155, "Removal and Installation"](#) (base audio without navigation), [AV-286, "Removal and Installation"](#) (bose audio without navigation) or [AV-458, "Removal and Installation"](#) (bose audio with navigation).

Is the inspection result normal?

YES >> Replace the A/C auto amp.
NO >> Repair or replace parts according to the inspection results.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

ECU DIAGNOSIS INFORMATION

ECM

Reference Value

INFOID:000000009722203

VALUES ON THE DIAGNOSIS TOOL

NOTE:

- The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.
- Numerical values in the following table are reference values.
- These values are input/output values that ECM receives/transmits and may differ from actual operations.

Example:

The ignition timing shown by the timing light may differ from the ignition timing displayed on the data monitor.

This occurs because the timing light shows a value calculated by ECM according to signals received from the cam shaft position sensor and other sensors related to ignition timing.

For outlines of following items, refer to [EC-129, "CONSULT Function"](#).

Monitor Item	Condition		Values/Status
ENG SPEED	Run engine and compare CONSULT value with the tachometer indication.		Almost the same speed as the tachometer indication.
MAS A/F SE-B1	See EC-140, "Description" .		
B/FUEL SCHDL	See EC-140, "Description" .		
A/F ALPHA-B1	See EC-140, "Description" .		
A/F ALPHA-B2	See EC-140, "Description" .		
COOLANT TEMP/S	• Engine: After warming up		More than 70°C (158°F)
A/F SEN1 (B1)	• Engine: After warming up	Maintaining engine speed at 2,000 rpm	Fluctuates around 2.2 V
A/F SEN1 (B2)	• Engine: After warming up	Maintaining engine speed at 2,000 rpm	Fluctuates around 2.2 V
HO2S2 (B1)	<ul style="list-style-type: none"> • Revving engine from idle to 3,000 rpm quickly after the following conditions are met. - Engine: After warming up - After keeping engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load 		0 - 0.3 V ↔ Approx. 0.6 - 1.0 V
HO2S2 (B2)	<ul style="list-style-type: none"> • Revving engine from idle to 3,000 rpm quickly after the following conditions are met. - Engine: After warming up - After keeping engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load 		0 - 0.3 V ↔ Approx. 0.6 - 1.0 V
HO2S2 MNTR (B1)	<ul style="list-style-type: none"> • Revving engine from idle to 3,000 rpm quickly after the following conditions are met. - Engine: After warming up - After keeping engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load 		LEAN ↔ RICH
HO2S2 MNTR (B2)	<ul style="list-style-type: none"> • Revving engine from idle to 3,000 rpm quickly after the following conditions are met. - Engine: After warming up - After keeping engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load 		LEAN ↔ RICH
VHCL SPEED SE	• Turn drive wheels and compare CONSULT value with the speedometer indication.		Almost the same speed as speedometer indication
BATTERY VOLT	• Ignition switch: ON (Engine stopped)		11 - 14 V
ACCEL SEN 1	• Ignition switch: ON (Engine stopped)	Accelerator pedal: Fully released	0.5 - 1.0 V
		Accelerator pedal: Fully depressed	4.2 - 4.8 V
ACCEL SEN 2*1	• Ignition switch: ON (Engine stopped)	Accelerator pedal: Fully released	0.5 - 1.0 V
		Accelerator pedal: Fully depressed	4.2 - 4.8 V

ECM

< ECU DIAGNOSIS INFORMATION >

[WITH 7 INCH DISPLAY]

Monitor Item	Condition		Values/Status
TP SEN 1-B1	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Selector lever: D position 	Accelerator pedal: Fully released	More than 0.36 V
		Accelerator pedal: Fully depressed	Less than 4.75 V
TP SEN 2-B1*1	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Selector lever: D position 	Accelerator pedal: Fully released	More than 0.36 V
		Accelerator pedal: Fully depressed	Less than 4.75 V
FUEL T/TMP SE	<ul style="list-style-type: none"> Ignition switch: ON 		Indicates fuel tank temperature
INT/A TEMP SE	<ul style="list-style-type: none"> Ignition switch: ON 		Indicates intake air temperature
EVAP SYS PRES	<ul style="list-style-type: none"> Ignition switch: ON 		Approx. 1.8 - 4.8 V
FUEL LEVEL SE	<ul style="list-style-type: none"> Ignition switch: ON 		Depending on fuel level of fuel tank
START SIGNAL	<ul style="list-style-type: none"> Ignition switch: ON → START → ON 		OFF → ON → OFF
CLSD THL POS	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) 	Accelerator pedal: Fully released	ON
		Accelerator pedal: Slightly depressed	OFF
AIR COND SIG	<ul style="list-style-type: none"> Engine: After warming up, idle the engine 	Air conditioner switch: OFF	OFF
		Air conditioner switch: ON (Compressor operates.)	ON
P/N POSI SW	<ul style="list-style-type: none"> Ignition switch: ON 	Selector lever: P or N position	ON
		Selector lever: Except above position	OFF
PW/ST SIGNAL	<ul style="list-style-type: none"> Engine: After warming up, idle the engine 	Steering wheel: Not being turned	OFF
		Steering wheel: Being turned	ON
LOAD SIGNAL	<ul style="list-style-type: none"> Ignition switch: ON 	Rear window defogger switch: ON and/or Lighting switch: 2nd position	ON
		Rear window defogger switch and lighting switch: OFF	OFF
IGNITION SW	<ul style="list-style-type: none"> Ignition switch: ON → OFF → ON 		ON → OFF → ON
HEATER FAN SW	<ul style="list-style-type: none"> Engine: After warming up, idle the engine 	Heater fan switch: ON	ON
		Heater fan switch: OFF	OFF
BRAKE SW	<ul style="list-style-type: none"> Ignition switch: ON 	Brake pedal: Fully released	OFF
		Brake pedal: Slightly depressed	ON
INJ PULSE-B1	<ul style="list-style-type: none"> Engine: After warming up Selector lever: P or N position Air conditioner switch: OFF No load 	Idle	2.0 - 3.0 msec
		2,000 rpm	1.9 - 2.9 msec
INJ PULSE-B2	<ul style="list-style-type: none"> Engine: After warming up Selector lever: P or N position Air conditioner switch: OFF No load 	Idle	2.0 - 3.0 msec
		2,000 rpm	1.9 - 2.9 msec
IGN TIMING	<ul style="list-style-type: none"> Engine: After warming up Selector lever: P or N position Air conditioner switch: OFF No load 	Idle	7 - 17°BTDC
		2,000 rpm	25 - 45°BTDC
CAL/LD VALUE	<ul style="list-style-type: none"> Engine: After warming up Selector lever: P or N position Air conditioner switch: OFF No load 	Idle	5 - 35%
		2,500 rpm	5 - 35%
MASS AIRFLOW	<ul style="list-style-type: none"> Engine: After warming up Selector lever: P or N position Air conditioner switch: OFF No load 	Idle	2.0 - 6.0 g/s
		2,500 rpm	7.0 - 20.0 g/s

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

ECM

< ECU DIAGNOSIS INFORMATION >

[WITH 7 INCH DISPLAY]

Monitor Item	Condition	Values/Status	
PURG VOL C/V	<ul style="list-style-type: none"> Engine: After warming up Selector lever: P or N position Air conditioner switch: OFF No load Idle (Accelerator pedal: Not depressed even slightly, after engine starting.)	0%	
	2,000 rpm	—	
INT/V TIM (B1)	<ul style="list-style-type: none"> Engine: After warming up Selector lever: P or N position Air conditioner switch: OFF No load Idle	-5 - 5°C	
	2,000 rpm	Approx. 0 - 30°C	
INT/V TIM (B2)	<ul style="list-style-type: none"> Engine: After warming up Selector lever: P or N position Air conditioner switch: OFF No load Idle	-5 - 5°C	
	2,000 rpm	Approx. 0 - 30°C	
INT/V SOL (B1)	<ul style="list-style-type: none"> Engine: After warming up Selector lever: P or N position Air conditioner switch: OFF No load Idle	0 - 2%	
	2,000 rpm	Approx. 0 - 50%	
INT/V SOL (B2)	<ul style="list-style-type: none"> Engine: After warming up Selector lever: P or N position Air conditioner switch: OFF No load Idle	0 - 2%	
	2,000 rpm	Approx. 0 - 50%	
VIAS S/V-1	<ul style="list-style-type: none"> Engine: After warming up Selector lever: P or N position Air conditioner switch: OFF No load When revving engine up to 5,000 rpm quickly	OFF → ON → OFF	
VIAS S/V-2	<ul style="list-style-type: none"> Engine: After warming up Selector lever: P or N position Air conditioner switch: OFF No load When revving engine up to 5,000 rpm quickly	OFF → ON → OFF	
AIR COND RLY	<ul style="list-style-type: none"> Engine: After warming up, idle the engine Air conditioner switch: OFF	OFF	
		Air conditioner switch: ON (Compressor operates)	ON
ENGINE MOUNT	<ul style="list-style-type: none"> Engine: After warming up Idle (With vehicle stopped)	IDLE	
		Except above conditions	TRVL
FUEL PUMP RLY	<ul style="list-style-type: none"> For 1 second after turning ignition switch: ON Engine running or cranking 	ON	
	<ul style="list-style-type: none"> Except above 	OFF	
VENT CONT/V	<ul style="list-style-type: none"> Ignition switch: ON 	OFF	
THRTL RELAY	<ul style="list-style-type: none"> Ignition switch: ON 	ON	
COOLING FAN	<ul style="list-style-type: none"> Engine: After warming up, idle the engine Air conditioner switch: OFF Engine coolant temperature: 97°C (206°F) or less	OFF	
		Engine coolant temperature: Between 98°C (208°F) and 99°C (210°F)	LOW
		Engine coolant temperature: Between 100°C (212°F) and 104°C (219°F)	MID
		Engine coolant temperature: 105°C (221°F) or more	HI
HO2S2 HTR (B1)	<ul style="list-style-type: none"> Engine speed: Below 3,600 rpm after the following conditions are met. <ul style="list-style-type: none"> Engine: After warming up Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load 	ON	
	<ul style="list-style-type: none"> Engine speed: Above 3,600 rpm 	OFF	

ECM

< ECU DIAGNOSIS INFORMATION >

[WITH 7 INCH DISPLAY]

Monitor Item	Condition		Values/Status
HO2S2 HTR (B2)	<ul style="list-style-type: none"> Engine speed: Below 3,600 rpm after the following conditions are met. <ul style="list-style-type: none"> Engine: After warming up Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load 		ON
	<ul style="list-style-type: none"> Engine speed: Above 3,600 rpm 		OFF
I/P PULLY SPD	<ul style="list-style-type: none"> Vehicle speed: More than 20 km/h (12 MPH) 		Almost the same speed as the tachometer indication
VEHICLE SPEED	<ul style="list-style-type: none"> Turn drive wheels and compare CONSULT value with the speedometer indication. 		Almost the same speed as the speedometer indication
IDL A/V LEARN	<ul style="list-style-type: none"> Engine: Running 	Idle air volume learning has not been performed yet.	YET
		Idle air volume learning has already been performed successfully.	CMPLT
ENG OIL TEMP	<ul style="list-style-type: none"> Engine: After warming up 		More than 70°C (158°F)
TRVL AFTER MIL	<ul style="list-style-type: none"> Ignition switch: ON 	Vehicle has traveled after MIL has illuminated.	0 - 65,535 km (0 - 40,723 miles)
A/F S1 HTR (B1)	<ul style="list-style-type: none"> Engine: After warming up, idle the engine (More than 140 seconds after starting engine) 		4 - 100%
A/F S1 HTR (B2)	<ul style="list-style-type: none"> Engine: After warming up, idle the engine (More than 140 seconds after starting engine) 		4 - 100%
AC PRESS SEN	<ul style="list-style-type: none"> Engine: Idle Both A/C switch and blower fan switch: ON (Compressor operates) 		1.0 - 4.0 V
VHCL SPEED SE	<ul style="list-style-type: none"> Turn drive wheels and compare CONSULT value with the speedometer indication. 		Almost the same speed as the speedometer indication
SET VHCL SPD	<ul style="list-style-type: none"> Engine: Running 	ASCD: Operating	The preset vehicle speed is displayed
MAIN SW	<ul style="list-style-type: none"> Ignition switch: ON 	MAIN switch: Pressed	ON
		MAIN switch: Released	OFF
CANCEL SW	<ul style="list-style-type: none"> Ignition switch: ON 	CANCEL switch: Pressed	ON
		CANCEL switch: Released	OFF
RESUME/ACC SW	<ul style="list-style-type: none"> Ignition switch: ON 	RESUME/ACCELERATE switch: Pressed	ON
		RESUME/ACCELERATE switch: Released	OFF
SET SW	<ul style="list-style-type: none"> Ignition switch: ON 	SET/COAST switch: Pressed	ON
		SET/COAST switch: Released	OFF
BRAKE SW1 (ASCD brake switch)	<ul style="list-style-type: none"> Ignition switch: ON 	Brake pedal: Fully released	ON
		Brake pedal: Slightly depressed	OFF
BRAKE SW2 (Stop lamp switch)	<ul style="list-style-type: none"> Ignition switch: ON 	Brake pedal: Fully released	OFF
		Brake pedal: Slightly depressed	ON
VHCL SPD CUT	<ul style="list-style-type: none"> Ignition switch: ON 		NON
LO SPEED CUT	<ul style="list-style-type: none"> Ignition switch: ON 		NON
AT OD MONITOR	<ul style="list-style-type: none"> Ignition switch: ON 		OFF
AT OD CANCEL	<ul style="list-style-type: none"> Ignition switch: ON 		OFF
CRUISE LAMP	<ul style="list-style-type: none"> Ignition switch: ON 	MAIN switch: Pressed at the 1st time → at the 2nd time	ON → OFF
SET LAMP	<ul style="list-style-type: none"> MAIN switch: ON When vehicle speed is between 40 km/h (25 MPH) and 144 km/h (89 MPH) 	ASCD: Operating	ON
		ASCD: Not operating	OFF

A

B

C

D

E

F

G

H

HAC

J

K

L

M

N

O

P

ECM

< ECU DIAGNOSIS INFORMATION >

[WITH 7 INCH DISPLAY]


Monitor Item	Condition	Values/Status
ALT DUTY	• Engine: Idle	0 - 80%
A/F ADJ-B1	• Engine: Running	-0.330 - 0.330
A/F ADJ-B2	• Engine: Running	-0.330 - 0.330
BAT CUR SEN	<ul style="list-style-type: none"> • Engine speed: Idle • Battery: Fully charged*2 • Selector lever: P or N position • Air conditioner switch: OFF • No load 	Approx. 2,600 - 3,500 mV
ALT DUTY SIG	• Power generation voltage variable control: Operating	ON
	• Power generation voltage variable control: Not operating	OFF
HO2 S2 DIAG1 (B1)	DTC P0139 self-diagnosis (delayed response) is incomplete.	INCOMP
	DTC P0139 self-diagnosis (delayed response) is complete.	CMPLT
HO2 S2 DIAG1 (B2)	DTC P0159 self-diagnosis (delayed response) is incomplete.	INCOMP
	DTC P0159 self-diagnosis (delayed response) is complete.	CMPLT
HO2 S2 DIAG2 (B1)	DTC P0139 self-diagnosis (slow response) is incomplete.	INCOMP
	DTC P0139 self-diagnosis (slow response) is complete.	CMPLT
HO2 S2 DIAG2 (B2)	DTC P0159 self-diagnosis (slow response) is incomplete.	INCOMP
	DTC P0159 self-diagnosis (slow response) is complete.	CMPLT
A/F SEN1 DIAG1 (B1)	DTC P015A and P015B self-diagnosis is incomplete.	INCOMP
	DTC P015A and P015B self-diagnosis is complete.	CMPLT
A/F SEN1 DIAG1 (B2)	DTC P015C and P015D self-diagnosis is incomplete.	INCOMP
	DTC P015C and P015D self-diagnosis is complete.	CMPLT
A/F SEN1 DIAG2 (B1)	DTC P014C and P014D self-diagnosis is incomplete.	INCOMP
	DTC P014C and P014D self-diagnosis is complete.	CMPLT
A/F SEN1 DIAG2 (B2)	DTC P014E and P014F self-diagnosis is incomplete.	INCOMP
	DTC P014E and P014F self-diagnosis is complete.	CMPLT
A/F SEN1 DIAG3 (B1)	The vehicle condition is not within the diagnosis range of DTC P014C, P014D, P015A or P015B.	ABSNT
	The vehicle condition is within the diagnosis range of DTC P014C, P014D, P015A or P015B.	PRSNT
A/F SEN1 DIAG3 (B2)	The vehicle condition is not within the diagnosis range of DTC P014E, P014F, P015C or P015D.	ABSNT
	The vehicle condition is within the diagnosis range of DTC P014E, P014F, P015C or P015D.	PRSNT
THRTL STK CNT B1*3	—	—
EVAP LEAK DIAG	Ignition switch: ON	Indicates the condition of EVAP leak diagnosis.
EVAP DIAG READY	Ignition switch: ON	Indicates the ready condition of EVAP leak diagnosis.

*1: Accelerator pedal position sensor 2 signal and throttle position sensor 2 signal are converted by ECM internally. Thus, they differ from ECM terminals voltage signal.

*2: Before measuring the terminal voltage, confirm that the battery is fully charged. Refer to [PG-3, "How to Handle Battery"](#).

*3: The item is indicated, but not used.

TERMINAL LAYOUT



PHYSICAL VALUES

NOTE:







- ECM is located in the engine room left side near battery.
- Specification data are reference values.
- Pulse signal is measured by CONSULT.

Terminal No.		Description		Condition	Value (Approx.)
+	--	Signal name	Input/ Output		
1 (P/B)	112 (B)	Fuel injector No. 6	Output	[Engine is running] <ul style="list-style-type: none"> • Warm-up condition • Idle speed NOTE: The pulse cycle changes depending on rpm at idle	BATTERY VOLTAGE (11 - 14 V)★
3 (L/W)		Fuel injector No. 5			
29 (LG/R)		Fuel injector No. 4			
30 (R/Y)		Fuel injector No. 3			
31 (R/W)		Fuel injector No. 2			
32 (R/B)	Fuel injector No. 1	[Engine is running] <ul style="list-style-type: none"> • Warm-up condition • Engine speed: 2,000 rpm 	BATTERY VOLTAGE (11 - 14 V)★ 		
2 (G/W)	112 (B)	Throttle control motor power supply	Input	[Ignition switch: ON]	BATTERY VOLTAGE (11 - 14 V)
4 (BR/Y)	112 (B)	A/F sensor 1 heater (bank 1)	Output	[Engine is running] <ul style="list-style-type: none"> • Warm-up condition • Idle speed (More than 140 seconds after starting engine) 	2.9 - 8.8 V★

ECM

< ECU DIAGNOSIS INFORMATION >



[WITH 7 INCH DISPLAY]

Terminal No.		Description		Condition	Value (Approx.)
+	-	Signal name	Input/Output		
5 (L)	112 (B)	Throttle control motor (Open)	Output	[Ignition switch: ON] • Engine stopped • Selector lever: D position • Accelerator pedal: Fully depressed	0 - 14 V★  JMBIA0031GB
				[Ignition switch: ON] • Engine stopped • Selector lever: D position • Accelerator pedal: Fully released	0 - 14 V★  JMBIA0032GB
6 (P)	112 (B)	Throttle control motor (Close)	Output	[Ignition switch: ON] • Engine stopped • Selector lever: D position • Accelerator pedal: Fully released	0 - 14 V★  JMBIA1125GB
8 (SB)	112 (B)	A/F sensor 1 heater (bank 2)	Output	[Engine is running] • Warm-up condition • Idle speed (More than 140 seconds after starting engine)	2.9 - 8.8 V★  JMBIA0030GB
9 (L/B)	112 (B)	Ignition signal No. 3	Output	[Engine is running] • Warm-up condition • Idle speed NOTE: The pulse cycle changes depending on rpm at idle	0 - 0.2 V★  JMBIA0035GB
10 (G/R)		Ignition signal No. 2			
11 (Y/R)		Ignition signal No. 1			
18 (GR/R)		Ignition signal No. 6			
19 (P)		Ignition signal No. 5			
21 (W)	Ignition signal No. 4	[Engine is running] • Warm-up condition • Engine speed: 2,000 rpm	0.1 - 0.4 V★  JMBIA0036GB		
12 (B)	-	ECM ground	-	-	-

ECM

< ECU DIAGNOSIS INFORMATION >

[WITH 7 INCH DISPLAY]

Terminal No.		Description		Condition	Value (Approx.)
+	—	Signal name	Input/Output		
13 (P/B)	112 (B)	Heated oxygen sensor 2 heater (bank 1)	Output	[Engine is running] <ul style="list-style-type: none"> • Engine speed: Below 3,600 rpm after the following conditions are met - Engine: after warming up - Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load 	10 V★ <div style="text-align: center;">  </div>
				[Ignition switch: ON] <ul style="list-style-type: none"> • Engine stopped [Engine is running] • Engine speed: Above 3,600 rpm 	BATTERY VOLTAGE (11 - 14 V)
14 (GR)	112 (B)	Fuel pump relay	Output	[Ignition switch: ON] <ul style="list-style-type: none"> • For 1 second after turning ignition switch ON [Engine is running]	0 - 1.5 V
				[Ignition switch: ON] <ul style="list-style-type: none"> • More than 1 second after turning ignition switch ON 	BATTERY VOLTAGE (11 - 14 V)
15 (O)	112 (B)	Throttle control motor relay	Output	[Ignition switch: ON → OFF]	0 - 1.0 V → BATTERY VOLTAGE (11 - 14 V) → 0 V
				[Ignition switch: ON]	0 - 1.0 V
16 (B/Y)	—	ECM ground	—	—	—
17 (R)	112 (B)	Heated oxygen sensor 2 heater (bank 2)	Output	[Engine is running] <ul style="list-style-type: none"> • Engine speed: Below 3,600 rpm after the following conditions are met - Engine: after warming up - Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load 	10 V★ <div style="text-align: center;">  </div>
				[Ignition switch: ON] <ul style="list-style-type: none"> • Engine stopped [Engine is running] • Engine speed: Above 3,600 rpm 	BATTERY VOLTAGE (11 - 14 V)
24 (W/B)	112 (B)	ECM relay (Self shut-off)	Output	[Engine is running] [Ignition switch: OFF] <ul style="list-style-type: none"> • A few seconds after turning ignition switch OFF 	0 - 1.5 V
				[Ignition switch: OFF] <ul style="list-style-type: none"> • More than a few seconds after turning ignition switch OFF 	BATTERY VOLTAGE (11 - 14 V)

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

ECM

< ECU DIAGNOSIS INFORMATION >

[WITH 7 INCH DISPLAY]

Terminal No.		Description		Condition	Value (Approx.)
+	-	Signal name	Input/Output		
25 (P/L)	112 (B)	EVAP canister purge volume control solenoid valve	Output	[Engine is running] • Idle speed • Accelerator pedal: Not depressed even slightly, after engine starting	BATTERY VOLTAGE (11 - 14 V)★
				[Engine is running] • Engine speed: approximately 2,000 rpm (More than 100 seconds after starting engine)	BATTERY VOLTAGE (11 - 14 V)★
26 (GR/B)	112 (B)	VIAS control solenoid valve 2	Output	[Engine is running] • Warm-up condition • Idle speed	BATTERY VOLTAGE (11 - 14 V)
				[Engine is running] • Warm-up condition • When revving engine up to 5,000 rpm quickly	BATTERY VOLTAGE (11 - 14 V) ↓ 0 - 1.0 V ↓ BATTERY VOLTAGE (11 - 14 V)
27 (V)	112 (B)	VIAS control solenoid valve 1	Output	[Engine is running] • Warm-up condition • Idle speed	BATTERY VOLTAGE (11 - 14 V)
				[Engine is running] • Warm-up condition • When revving engine up to 5,000 rpm quickly	BATTERY VOLTAGE (11 - 14 V) ↓ 0 - 1.0 V ↓ BATTERY VOLTAGE (11 - 14 V)
28 (BR/W)	112 (B)	Electronic controlled engine mount control solenoid valve	Output	[Engine is running] • Engine speed: For 2 seconds after reaching 950 rpm or less	0 - 1.0 V
				[Engine is running] • Engine speed: After a lapse of 2 seconds after reaching 950 rpm or less	2.0 - 3.0 V
				[Engine is running] • Engine speed: 950 rpm or more	BATTERY VOLTAGE (11 - 14 V)
33 (W)	112 (B)	Heated oxygen sensor 2 (bank 1)	Input	[Engine is running] • Revving engine from idle to 3,000 rpm quickly after the following conditions are met - Engine: after warming up - Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load	0 - 1.0 V

ECM

< ECU DIAGNOSIS INFORMATION >

[WITH 7 INCH DISPLAY]

Terminal No.		Description		Condition	Value (Approx.)	
+	—	Signal name	Input/ Output			
34 (W/L)	112 (B)	Heated oxygen sensor 2 (bank 2)	Input	[Engine is running] • Revving engine from idle to 3,000 rpm quickly after the following conditions are met - Engine: after warming up - Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load	0 - 1.0 V	A B C D
35 (B)	—	Sensor ground (Heated oxygen sensor 2)	—	—	—	
36 (B)	—	Sensor ground (Throttle position sensor)	—	—	—	E
37 (W)	112 (B)	Throttle position sensor 1	Input	[Ignition switch: ON] • Engine stopped • Selector lever: D position • Accelerator pedal: Fully released	More than 0.36 V	F
				[Ignition switch: ON] • Engine stopped • Selector lever: D position • Accelerator pedal: Fully depressed	Less than 4.75 V	G H
38 (R)	112 (B)	Throttle position sensor 2	Input	[Ignition switch: ON] • Engine stopped • Selector lever: D position • Accelerator pedal: Fully released	Less than 4.75 V	HAC
				[Ignition switch: ON] • Engine stopped • Selector lever: D position • Accelerator pedal: Fully depressed	More than 0.36 V	J K
39 (R)	40 (G)	Refrigerant pressure sensor	Input	[Engine is running] • Warm-up condition • Both A/C switch and blower fan motor switch: ON (Compressor operates)	1.0 - 4.0 V	L
40 (G)	—	Sensor ground (Refrigerant pressure sensor)	—	—	—	M
41 (O/B)	48 (B/P)	Power steering pressure sensor	Output	[Engine is running] • Steering wheel: Being turned	0.5 - 4.5 V	N
				[Engine is running] • Steering wheel: Not being turned	0.4 - 0.8 V	O
42 (BR)	44 (G/B)	Battery current sensor	Input	[Engine is running] • Battery: Fully charged*2 • Idle speed	2.6 - 3.5 V	P
44 (G/B)	—	Sensor ground (Battery current sensor)	—	—	—	
45 (P)	49 (L)	A/F sensor 1 (bank 1)	Input	[Ignition switch: ON]	2.2 V	
46 (Y)	52 (B/R)	Engine coolant temperature sensor	Input	[Engine is running]	0 - 4.8 V Output voltage varies with engine coolant temperature.	

ECM

< ECU DIAGNOSIS INFORMATION >







[WITH 7 INCH DISPLAY]

Terminal No.		Description		Condition	Value (Approx.)
+	—	Signal name	Input/ Output		
47 (G)	36 (B)	Sensor power supply (Throttle position sensor)	—	[Ignition switch: ON]	5 V
48 (B/P)	—	Sensor ground (Power steering pressure sensor)	—	—	—
49 (L)	112 (B)	A/F sensor 1 (bank 1)	Input	[Engine is running] • Warm-up condition • Engine speed: 2,000 rpm	1.8 V Output voltage varies with air fuel ratio.
50 (L/Y)	56 (G/B)	Intake air temperature sensor	Input	[Engine is running]	0 - 4.8 V Output voltage varies with intake air temperature.
51 (R/Y)	44 (G/B)	Sensor power supply (Battery current sensor)	—	[Ignition switch: ON]	5 V
52 (B/R)	—	Sensor ground (Engine coolant temperature sensor/Engine oil temperature sensor)	—	—	—
53 (V)	57 (LG)	A/F sensor 1 (bank 2)	Input	[Ignition switch: ON]	2.2 V
54 (G)	52 (B/R)	Engine oil temperature sensor	Input	[Engine is running]	0 - 4.8 V Output voltage varies with engine oil temperature.
55 (SB)	48 (Y)	Sensor power supply (Power steering pressure sensor)	—	[Ignition switch: ON]	5 V
56 (G/B)	—	Sensor ground (Mass air flow sensor/Intake air temperature sensor)	—	—	—
57 (LG)	112 (B)	A/F sensor 1 (bank 2)	Input	[Engine is running] • Warm-up condition • Engine speed: 2,000 rpm	1.8 V Output voltage varies with air fuel ratio.
58 (O)	56 (G/B)	Mass air flow sensor	Input	[Engine is running] • Warm-up condition • Idle speed	0.9 - 1.2 V
				[Engine is running] • Warm-up condition • Engine speed: 2,500 rpm	1.6 - 1.9 V
59 (G/W)	64 (B/R)	Sensor power supply [Camshaft position sensor (PHASE) (bank 1)]	—	[Ignition switch: ON]	5 V
60 (Y/B)	—	Sensor ground [Crankshaft position sensor (POS)]	—	—	—
61 (B)	67 (—)	Knock sensor (bank 1)	Input	[Engine is running] • Idle speed	2.5 V*1
62 (W)	67 (—)	Knock sensor (bank 2)	Input	[Engine is running] • Idle speed	2.5 V*1
63 (R/W)	68 (Y/G)	Sensor power supply [Camshaft position sensor (PHASE) (bank 2)]	—	[Ignition switch: ON]	5 V
64 (B/R)	—	Sensor ground [Camshaft position sensor (PHASE) (bank 1)]	—	—	—

ECM

< ECU DIAGNOSIS INFORMATION >

[WITH 7 INCH DISPLAY]

Terminal No.		Description		Condition	Value (Approx.)
+	-	Signal name	Input/Output		
65 (W/B)	60 (Y/B)	Crankshaft position sensor (POS)	Input	[Engine is running] • Warm-up condition • Idle speed NOTE: The pulse cycle changes depending on rpm at idle	4.0 - 5.0 V★ 
				[Engine is running] • Engine speed: 2,000 rpm	4.0 - 5.0 V★ 
67 (-)	-	Sensor ground (Knock sensor)	-	-	-
68 (Y/G)	-	Sensor ground [Camshaft position sensor (PHASE) (bank 2)]	-	-	-
69 (BR/W)	68 (Y/G)	Camshaft position sensor (PHASE) (bank 2)	Input	[Engine is running] • Warm-up condition • Idle speed NOTE: The pulse cycle changes depending on rpm at idle	3.0 - 5.0 V★ 
				[Engine is running] • Engine speed is 2,000 rpm	3.0 - 5.0 V★ 
70 (W/R)	64 (B/R)	Camshaft position sensor (PHASE) (bank 1)	Input	[Engine is running] • Warm-up condition • Idle speed NOTE: The pulse cycle changes depending on rpm at idle	3.0 - 5.0 V★ 
				[Engine is running] • Engine speed is 2,000 rpm	3.0 - 5.0 V★ 



A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

ECM

< ECU DIAGNOSIS INFORMATION >



[WITH 7 INCH DISPLAY]

Terminal No.		Description		Condition	Value (Approx.)
+	—	Signal name	Input/Output		
72 (BR/W)	40 (G)	Sensor power supply (Refrigerant pressure sensor)	—	[Ignition switch: ON]	5 V
75 (Y)	112 (B)	Intake valve timing control solenoid valve (bank 2)	Output	[Engine is running] • Warm-up condition • Idle speed	BATTERY VOLTAGE (11 - 14 V)
				[Engine is running] • Warm-up condition • Engine speed: 2,000 rpm	7 - 12 V★ 
76 (R/G)	60 (Y/B)	Sensor power supply [Crankshaft position sensor (POS)]	—	[Ignition switch: ON]	5 V
77 (W/L)	112 (B)	Power supply for ECM (Back-up)	Input	[Ignition switch: OFF]	BATTERY VOLTAGE (11 - 14 V)
78 (R/L)	112 (B)	Intake valve timing control solenoid valve (bank 1)	Output	[Engine is running] • Warm-up condition • Idle speed	BATTERY VOLTAGE (11 - 14 V)
				[Engine is running] • Warm-up condition • Engine speed: 2,000 rpm	7 - 12 V★ 
81 (W)	84 (B)	Accelerator pedal position sensor 1	Input	[Ignition switch: ON] • Engine stopped • Accelerator pedal: Fully released	0.5 - 1.0 V
				[Ignition switch: ON] • Engine stopped • Accelerator pedal: Fully depressed	4.2 - 4.8 V
82 (O)	100 (G)	Accelerator pedal position sensor 2	Input	[Ignition switch: ON] • Engine stopped • Accelerator pedal: Fully released	0.25 - 0.50 V
				[Ignition switch: ON] • Engine stopped • Accelerator pedal: Fully depressed	2.0 - 2.5 V
83 (BR)	84 (B)	Sensor power supply (Accelerator pedal position sensor 1)	—	[Ignition switch: ON]	5 V
84 (B)	—	Sensor ground (Accelerator pedal position sensor 1)	—	—	—

ECM

< ECU DIAGNOSIS INFORMATION >

[WITH 7 INCH DISPLAY]

Terminal No.		Description		Condition	Value (Approx.)
+	-	Signal name	Input/Output		
85 (Y)	92 (BR)	ASCD steering switch	Input	[Ignition switch: ON] • ASCD steering switch: OFF	4 V
				[Ignition switch: ON] • MAIN switch: Pressed	0 V
				[Ignition switch: ON] • CANCEL switch: Pressed	1 V
				[Ignition switch: ON] • RESUME/ACCELERATE switch: Pressed	3 V
				[Ignition switch: ON] • SET/COAST switch: Pressed	2 V
86 (SB)	96 (GR)	EVAP control system pressure sensor	Input	[Ignition switch: ON]	1.8 - 4.8 V
87 (GR)	100 (G)	Sensor power supply (Accelerator pedal position sensor 2)	-	[Ignition switch: ON]	5 V
88 (O)	-	Data link connector	Input/Output	-	-
91 (L)	96 (GR)	Sensor power supply (EVAP control system pressure sensor)	-	[Ignition switch: ON]	5 V
92 (BR)	-	Sensor ground (ASCD steering switch)	-	-	-
93 (BR)	112 (B)	Ignition switch	Input	[Ignition switch: OFF]	0 V
				[Ignition switch: ON]	BATTERY VOLTAGE (11 - 14 V)
94 (GR)	112 (B)	Engine speed output signal	Output	[Engine is running] • Warm-up condition • Idle speed NOTE: The pulse cycle changes depending on rpm at idle	1 V★ 
				[Engine is running] • Engine speed: 2,000 rpm	1 V★ 
95 (Y)	104 (SB)	Fuel tank temperature sensor	Input	[Engine is running]	0 - 4.8 V Output voltage varies with fuel tank temperature.
96 (GR)	-	Sensor ground (EVAP control system pressure sensor)	-	-	-
97 (P)	-	CAN communication line (CAN-L)	Input/Output	-	-
98 (L)	-	CAN communication line (CAN-H)	Input/Output	-	-

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

ECM

< ECU DIAGNOSIS INFORMATION >

[WITH 7 INCH DISPLAY]

Terminal No.		Description		Condition	Value (Approx.)
+	—	Signal name	Input/ Output		
100 (G)	—	Sensor ground (Accelerator pedal position sensor 2)	—	—	—
102 (R)	112 (B)	PNP signal	Input	[Ignition switch: ON] • Selector lever: P or N position	BATTERY VOLTAGE (11 - 14 V)
				[Ignition switch: ON] • Selector lever: Except above position	0 V
104 (SB)	—	Sensor ground (Fuel tank temperature sensor)	—	—	—
105 (V)	112 (B)	Power supply for ECM	Input	[Ignition switch: ON]	BATTERY VOLTAGE (11 - 14 V)
106 (SB)	112 (B)	Stop lamp switch	Input	[Ignition switch: OFF] • Brake pedal: Fully released	0 V
				[Ignition switch: OFF] • Brake pedal: Slightly depressed	BATTERY VOLTAGE (11 - 14 V)
107 (B) 108 (B)	—	ECM ground	—	—	—
109 (W)	112 (B)	EVAP canister vent control valve	Output	[Ignition switch: ON]	BATTERY VOLTAGE (11 - 14 V)
110 (G)	112 (B)	ASCD brake switch	Input	[Ignition switch: ON] • Brake pedal: Slightly depressed	0 V
				[Ignition switch: ON] • Brake pedal: Fully released	BATTERY VOLTAGE (11 - 14 V)
111 (B) 112 (B)	—	ECM ground	—	—	—

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

*1: This may vary depending on internal resistance of the tester.

*2: Before measuring the terminal voltage, confirm that the battery is fully charged. Refer to [PG-3. "How to Handle Battery"](#).

A/C AUTO AMP.

< ECU DIAGNOSIS INFORMATION >

[WITH 7 INCH DISPLAY]

A/C AUTO AMP.

Reference Value

INFOID:000000009722204

VALUES ON THE DIAGNOSIS TOOL


NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

CONSULT MONITOR ITEM

Monitor item	Condition		Value/Status
COMP REQ SIG	Engine: Run at idle after warming up	A/C switch: ON (Compressor operation status)	On
		A/C switch: OFF	Off
FAN REQ SIG	Engine: Run at idle after warming up	Blower fan: ON	On
		Blower fan: OFF	Off
AMB TEMP SEN	Ignition switch ON	—	22 - 131°F (-30 - 55°C)
IN-VEH TEMP	Ignition switch ON	—	22 - 131°F (-30 - 55°C)
INT TEMP SEN	Ignition switch ON	—	22 - 131°F (-30 - 55°C)
SUNLOAD SEN	Ignition switch ON	—	0 - 1045 w/m ² (0 - 900 kcal/m ² ·h)
AMB SEN CAL	Ignition switch ON	—	22 -131°F (-30 - 55°C)
IN-VEH CAL	Ignition switch ON	—	22 -131°F (-30 - 55°C)
INT TEMP CAL	Ignition switch ON	—	22 -131°F (-30 - 55°C)
SUNL SEN CAL	Ignition switch ON	—	0 - 1045 w/m ² (0 - 900 kcal/m ² ·h)
FAN DUTY	Engine: Run at idle after warming up	Blower fan: ON	25 - 81
		Blower fan: OFF	0
XM	Ignition switch ON	—	-100 - 155
ENG COOL TEMP	Ignition switch ON	—	Values according to coolant temperature
VEHICLE SPEED	Driving	—	Equivalent to speedometer reading

TERMINAL LAYOUT





PHYSICAL VALUES

A/C AUTO AMP.

< ECU DIAGNOSIS INFORMATION >

[WITH 7 INCH DISPLAY]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
1 (L)	—	CAN-H	Input/ Output	—	—
2 (P)	—	CAN-L	Input/ Output	—	—
10 (L)	Ground	LAN signal	Input/ Output	—	 <p style="text-align: right; font-size: small;">SJIA1453J</p>
11 (R)	Ground	Power supply for each door motor	Input	Ignition switch ON	Battery voltage
15 (BR)	Ground	Sunload sensor	Input	—	—
16 (G)	Ground	Intake sensor	Input	—	—
17 (R)	Ground	Power supply from ACC	—	Ignition switch ACC	Battery voltage
19 (B)	Ground	Ground	—	Ignition switch ON	0 V
20 (G)	Ground	Power supply from IGN	—	Ignition switch ON	Battery voltage
32 (L)	Ground	Blower motor control signal	Output	<ul style="list-style-type: none"> • Ignition switch ON • Blower speed: 1st speed (manual) 	 <p style="text-align: right; font-size: small;">JSIIA0096ZZ</p>
34 (P)	Ground	Power supply for ambient meter	Output	Ignition switch ON	5V
35 (L)	Ground	Ambient sensor	Input	—	—
36 (LG)	Ground	In-vehicle sensor	Input	—	—
37 (Y)	Ground	Sensor ground	—	Ignition switch ON	0 V
39 (B)	Ground	Ground	—	Ignition switch ON	0 V
40 (Y)	Ground	Power supply from BATT	—	Ignition switch OFF	Battery voltage


A/C AUTO AMP.

< ECU DIAGNOSIS INFORMATION >

[WITH 7 INCH DISPLAY]

Wiring Diagram - AIR CONDITIONER CONTROL SYSTEM -

INFOID:000000009722205



2012/08/24

JRIWC0486GB


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

HAC

A/C AUTO AMP.

< ECU DIAGNOSIS INFORMATION >

[WITH 7 INCH DISPLAY]




*: This connector is not shown in "Harness Layout".

JRIWC0487GB

A/C AUTO AMP.

< ECU DIAGNOSIS INFORMATION >

[WITH 7 INCH DISPLAY]




*: This connector is not shown in "Harness Layout".

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

AUTOMATIC AIR CONDITIONING SYSTEM

Connector No.	E6
Connector Name	WIRE TO WIRE
Connector Type	TK18MGZ-1V



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
2	Y	-
3	Y	-
4	R	-
5	GR	-
6	V	-
8	P	-
10	W	-
11	G	-
12	BR	-
13	SB	-
14	B	-

Connector No.	E7
Connector Name	WIRE TO WIRE
Connector Type	NS18MW-CS




Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
2	B	-
3	B	-
4	B	-
5	B	-
6	B	-
7	O	-
10	B	-

Connector No.	E10
Connector Name	ECM INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	TH20EW-CS12-M4-1V




Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	Y	-
3	GR	-
4	B	-
5	GR	-
6	BR	-
7	B	-
8	V	-
9	P	-
10	W	-
11	G	-
12	R	-
13	Y	-
14	L	-
15	O	-
16	SB	-
17	GR	-
18	G	-
19	Y	-
20	W	-
21	O	-
22	SB	-
23	GR	-
24	G	-
25	GR	-
26	Y	-
27	W	-
28	SB	-
29	BR	-
30	BR	-
31	O	-
32	P	-
33	G	-
34	O	-
35	P	-
36	G	-
38	GR	-

Connector No.	E11
Connector Name	ECM INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	TH8BEW-BH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	-
2	P	-
3	P	-
4	B	-
5	SB	-
6	Y	-
7	Y	-
8	W	-
9	O	-
10	BR	-

Connector No.	E16
Connector Name	ECM
Connector Type	RH24FB-F28-L-LH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	ACCELERATOR PEDAL POSITION SENSOR 1
2	O	ACCELERATOR PEDAL POSITION SENSOR 2
3	BR	SENSOR POWER SUPPLY
4	B	SENSOR GROUND
5	B	ASD
6	SB	EVAP CONTROL SYSTEM PRESSURE SENSOR
7	GR	SENSOR POWER SUPPLY
8	O	DATA LINK CONNECTOR
9	L	SENSOR POWER SUPPLY
10	BR	SENSOR GROUND
11	BR	IGNITION SWITCH

84	GR	ENGINE SPEED OUTPUT SIGNAL
85	Y	FUEL TANK LEVEL SENSOR
86	GR	SENSOR GROUND
87	P	CAN COMMUNICATION LINE(CAN-L)
88	L	CAN COMMUNICATION LINE(CAN-H)
100	G	SENSOR GROUND
102	R	PNP SIGNAL
104	SB	SENSOR GROUND
105	V	POWER SUPPLY FOR ECM
106	SB	STOP LAMP SWITCH
107	B	ECM GROUND
108	B	ECM GROUND
109	W	EVAP CANISTER VENT CONTROL VALVE
110	G	ASD BRAKE SWITCH
111	B	ECM GROUND
112	B	ECM GROUND

Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	TH70MM-CS1D-M3




Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
2	Y	-
3	Y	-
4	Y	-
5	LG	-
6	GR	-
7	GR	-
8	G	-
11	P	-
12	L	-
13	Y	-
14	O	-
15	BR	-
20	Y	-
21	BR	-
22	L	-
24	L	-
25	O	-
28	SB	-
29	W	-
30	Y	-

AUTOMATIC AIR CONDITIONING SYSTEM


38	R	-	-	-	-	-
39	L	-	-	-	-	-
40	B	-	-	-	-	-
47	P	-	-	-	-	-
48	L	-	-	-	-	-
49	SB	-	-	-	-	-
50	GR	-	-	-	-	-
51	LG	-	-	-	-	-
52	V	-	-	-	-	-
53	GR	-	-	-	-	-
54	BR	-	-	-	-	-
55	Y	-	-	-	-	-
56	W/L	-	-	-	-	-
60	V	-	-	-	-	-
61	BR	-	-	-	-	-
62	L/O	-	-	-	-	-
64	SHIELD	-	-	-	-	-
66	W	-	-	-	-	-
67	BR	-	-	-	-	-
68	Y	-	-	-	-	-
69	SB	-	-	-	-	-
70	GR	-	-	-	-	-
71	SB	-	-	-	-	-
72	Y	-	-	-	-	-
73	L	-	-	-	-	-
74	W	-	-	-	-	-
75	BR	-	-	-	-	-
76	BR	-	-	-	-	-
78	G	-	-	-	-	-
78	G	-	-	-	-	-
78	Y	-	-	-	-	-
79	Y	-	-	-	-	-
80	R	-	-	-	-	-
81	W	-	-	-	-	-
82	LG	-	-	-	-	-
83	O	-	-	-	-	-

Connector No.	E500
Connector Name	REFRIGERANT PRESSURE SENSOR
Connector Type	FR03ZFB




Terminal No.	1	2	3
Color	P	B	L
Wire	-	-	-
Signal Name	[Specification]	-	-

Connector No. E537
Connector Name AMBIENT SENSOR
Connector Type RS03ZFB




Terminal No.	1	2
Color	SB	BR
Wire	-	-
Signal Name	[Specification]	-

Connector No.	E546
Connector Name	INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	TH18FW-BH



Terminal No.	1	2	3	4	5	6	7	8	9	10	11	12	13	14
Color	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Wire	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Signal Name	[Specification]	-	-	-	-	-	-	-	-	-	-	-	-	-

Connector No. F8
Connector Name ECM
Connector Type RH40FBR-R2B-L-LH



Terminal No.	33	34	35	36	37	38	39	40	41	42	44	45	46	
Color	W	W/L	B	B	W	R	C	O/B	BR	G/B	P	Y	-	
Wire	-	-	-	-	-	-	-	-	-	-	-	-	-	
Signal Name	[Specification]	HEATED OXYGEN SENSOR 2 (BANK 1)	HEATED OXYGEN SENSOR 2 (BANK 2)	SENSOR GROUND	SENSOR GROUND	THROTTLE POSITION SENSOR 1	THROTTLE POSITION SENSOR 2	REFRIGERANT PRESSURE SENSOR	SENSOR GROUND	POWER STEERING PRESSURE SENSOR	BATTERY CURRENT SENSOR	SENSOR GROUND	A/F SENSOR 1 (BANK 1)	ENGINE COOLANT TEMPERATURE SENSOR

47	G	SENSOR POWER SUPPLY
48	B/P	SENSOR GROUND
49	L	A/F SENSOR 1 (BANK 1)
50	L/Y	INTAKE AIR TEMPERATURE SENSOR
51	R/Y	SENSOR POWER SUPPLY
52	B/R	SENSOR GROUND
53	V	A/F SENSOR 1 (BANK 2)
54	G	ENGINE OIL TEMPERATURE SENSOR
55	SB	SENSOR POWER SUPPLY
56	G/B	SENSOR GROUND
57	LG	A/F SENSOR 1 (BANK 2)
58	O	MASS AIR FLOW SENSOR
59	G/W	SENSOR POWER SUPPLY
60	Y/B	SENSOR GROUND
61	B	KNOCK SENSOR (BANK 1)
62	W	SENSOR POWER SUPPLY
63	R/W	SENSOR GROUND
64	R/R	SENSOR GROUND
65	W/B	CRANKSHAFT POSITION SENSOR(POS)
67	SHIELD	SENSOR GROUND
68	Y/G	SENSOR GROUND
69	BR/W	CRANKSHAFT POSITION SENSOR(PHASE) (BANK 1)
70	W/R	CRANKSHAFT POSITION SENSOR(PHASE) (BANK 2)
72	BR/W	SENSOR POWER SUPPLY
73	Y	INTAKE VALVE TIMING CONTROL SOLENOID VALVE (BANK 2)
76	R/G	SENSOR POWER SUPPLY
77	W/L	POWER SUPPLY FOR ECM (BACK-UP)
78	R/L	INTAKE VALVE TIMING CONTROL SOLENOID VALVE (BANK 1)

Connector No.	F12
Connector Name	ANKER INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	TH20FW-C51Z-M4



Terminal No.	1	2	3	4	5	6	7	8	9	10	11	12
Color	W	W	W	W	W	W	W	W	W	W	W	W
Wire	-	-	-	-	-	-	-	-	-	-	-	-
Signal Name	[Specification]	-	-	-	-	-	-	-	-	-	-	-

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

AUTOMATIC AIR CONDITIONING SYSTEM

56	W/L	-
57	R/L	-
58	Y	-
59	W/B	-
70	O	-
72	R/B	-
75	LG	-
76	SB	-
77	GR	-
80	B	-

Connector No.	F18
Connector Name	COMPRESSOR
Connector Type	HS02EB




Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	B	-

Connector No.	F12I
Connector Name	WIRE TO WIRE
Connector Type	NS10FW-CS




Terminal No.	Color Of Wire	Signal Name [Specification]
1	B/Y	-
2	R/Y	-
5	R/W	-
6	B	-
7	R/G	-

Connector No.	10	B
Connector Name	-	-
Connector Type	-	-



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
3	G/R	-
4	G/B	-
5	R	-
6	L/R	-
8	P	-
10	Y/B	-
11	BR/W	-
12	BR	-
13	G	-
14	B	-

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS06FW-AM



Terminal No.	Color Of Wire	Signal Name [Specification]
1A	Y	-
2A	G	-
3A	Y	-
4A	GR	-
7A	LG	-
8A	Y	-

Connector No.	M2
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS10FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
3B	Y	-
4B	G	-
5B	L	-
6B	Y	-
7B	R	-
8B	R	-
9B	GR	-

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS12FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
10C	SB	-
11C	R	-
12C	O	-
9C	BR	-
13C	G	-
9C	GR	-

Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Type	TH10FW-CS10-M3




Terminal No.	Color Of Wire	Signal Name [Specification]
3	BR	-
5	BR	-
6	G	-
8	R	-
11	P	-
12	L	-
13	V	-
14	Y	-
15	R	-
20	W	- [Without colour display]
21	BR	- [With colour display]
22	LG	-
24	Y	-
28	BR	-
29	R	-
38	R	-
39	L	-
40	B	-
47	P	-
48	L	-
49	W	-
50	GR	-
51	LG	-
52	Y	-
53	SB	-
55	P	-
56	LG	-
60	V	-
61	GR	-
62	BR	-
63	V	-

AUTOMATIC AIR CONDITIONING SYSTEM


84	SHIELD	-
85	W	-
86	B	-
87	W	-
88	W	-
89	P	-
90	W	-
91	G	-
92	G	-
93	L	-
94	W	-
95	BR	-
96	R	-
97	G	-
98	Y	-
99	G	-
100	R	-
101	W	-
102	W	-
103	W	-
104	BG	-

Connector No.	M24
Connector Name	COMBINATION METER
Connector Type	TH40FW-NH




Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	BATTERY POWER SUPPLY
2	G	IGNITION
3	B	GROUND
4	B	GROUND
5	SB	ILLUMINATION CONTROL SIGNAL
8	SB	TRIP RESET SIGNAL
9	W	SW ILL POWER
10	LG	METER CONTROL SWITCH GROUND
11	L	ENTER SWITCH SIGNAL
12	R	SELECT SWITCH SIGNAL
13	V	ILLUMINATION CONTROL SWITCH SIGNAL (-)
14	GR	ILLUMINATION CONTROL SWITCH SIGNAL (-)
15	BR	AIR BAG SIGNAL
16	L	AMBIENT SENSOR SIGNAL
18	L	AMBIENT SENSOR POWER
19	Y	AMBIENT SENSOR GROUND
20	Y	AMBIENT SENSOR GROUND
21	L	CAN-T
22	P	CAN-T
23	B	GROUND
24	W	FUEL LEVEL SENSOR GROUND
25	BR	ALTERNATOR SIGNAL
26	G	PARKING BRAKE SWITCH SIGNAL
27	V	BRAKE FLUID LEVEL SWITCH SIGNAL
29	R	WASHER LEVEL SWITCH SIGNAL
30	P	VEHICLE SPEED SIGNAL (2-PULSE)
31	V	VEHICLE SPEED SIGNAL (8-PULSE)
32	LG	OVERDRIVE CONTROL SWITCH SIGNAL
34	G	FUEL LEVEL SENSOR SIGNAL
35	B	SEAT BELT BUOGE SWITCH SIGNAL (DRIVER SIDE)
36	R	SEAT BELT BUOGE SWITCH SIGNAL (PASSENGER SIDE)

Connector No.	M16
Connector Name	A/C DISPLAY
Connector Type	TH1FB-NH




Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	GROUND
6	G	IGN
8	R	ILL+
9	BR	ILL-
10	L	RX (AMP DISP)

Connector No.	M41
Connector Name	IN-VEHICLE SENSOR
Connector Type	ABFW




Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	-
2	SB	-[Without colour display]
3	Y	-[With colour display]

Connector No.	M42
Connector Name	INTAKE SENSOR
Connector Type	CDFW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-[With colour display]
2	SB	-[Without colour display]
3	Y	-[With colour display]

Connector No.	M50
Connector Name	A/C AUTO AMP.
Connector Type	SAB46FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	CAN-H
2	P	CAN-L
3	Y	TX (AMP SW & DSP)
7	P	RX (SW AMP)
10	G	LAN SIG [Without colour display]
11	R	LAN SIG [With colour display]
11	R	VACTR
15	BR	SUN SENS
16	G	INTAKE SENS [With colour display]
16	R	INTAKE SENS [Without colour display]
19	B	GROUND
20	G	IGN
26	GR	RR DEF F/B
27	BR	RR DEF ON
27	L	PAT PWM
34	V	AMB POWER [Without colour display]
34	Y	AMB POWER [With colour display]
35	L	AMB SENS [Without colour display]
35	L	AMB SENS [With colour display]
36	LG	INDCAR SENS
37	SB	SENS GND [Without colour display]
37	Y	SENS GND [With colour display]
39	B	GND (POWER)
40	Y	BAT


A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

AUTOMATIC AIR CONDITIONING SYSTEM


Connector No.	M74
Connector Name	SUNLOAD SENSOR
Connector Type	K02FB



Connector No.	M95
Connector Name	A/C CONTROL
Connector Type	TH12FW-NH




Connector No.	M75
Connector Name	MULTIFUNCTION SWITCH
Connector Type	TH18FW-NH



48	Y	INVERTER VCC
49	BR	INVERTER GND
50	R	VP
51	LG	-
52	B	-
57	SHIELD	SHIELD
58	B	-

Connector No.	M174
Connector Name	AV CONTROL UNIT
Connector Type	TH32FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	GROUND
2	R	ACC
3	R	ACC
4	R	ILL
5	B	ILL CONT
6	SB	AV COMM (H)
8	LG	AV COMM (L)
9	V	SW GND
14	W	EJECT SIGNAL

Connector No.	M172
Connector Name	AV CONTROL UNIT
Connector Type	TH24FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	IGN
2	G	GROUND
3	L	RX (AMP SW)
4	P	TX (SW AMP)
5	R	ILL+
6	BR	ILL-

Connector No.	M98
Connector Name	BLOWER MOTOR
Connector Type	NS03FW-M3



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
2	L	-
3	B	-

Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	B	-
3	G	-
3	L	-



Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	-
2	Y	-

Connector No.	M84
Connector Name	WIRE TO WIRE
Connector Type	A03MW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	B	-
3	G	-
3	L	-

Terminal No.	Color Of Wire	Signal Name [Specification]
76	LG	AV COMM (L)
77	SB	AV COMM (H)
78	LG	AV COMM (L)
79	SB	AV COMM (H)
80	P	CAN-L
81	P	CAN-H
82	V	SW GND
86	SHIELD	SHIELD
87	R	TEL VOICE SIGNAL (+)
88	L	TEL VOICE SIGNAL (-)
92	V	VEHICLE SPEED SIGNAL (8-PULSE)
93	G	PARKING BRAKE (Without BOSE system)
94	SB	REVERSE
95	G	IGNITION
96	W	DISK EJECT SIGNAL
102	W	AUX SOUND SIGNAL GND
103	B	AUX SOUND SIGNAL LH (+)
104	R	AUX SOUND SIGNAL RH (+)

Terminal No.	Color Of Wire	Signal Name [Specification]
36	GR	SIGNAL VCC
37	SB	SIGNAL GND
38	G	HP
39	L	COMM (DISC CONT)
41	L	RGB PARENT SIGNAL
42	SHIELD	SHIELD
43	B	RGB SYNC
43	G	RGB (RED) SIGNAL
44	L	RGB (GREEN) SIGNAL
45	Y	RGB (BLUE) SIGNAL
46	W	-
47	R	-

JRIWC1466GB

AUTOMATIC AIR CONDITIONING SYSTEM

Connector No. M180	Connector No. M292	Connector No. M326	Connector No. M358	Connector No. M358
Connector Name AV CONTROL UNIT	Connector Name WIRE TO WIRE	Connector Name AIR MIX DOOR MOTOR LH	Connector Name UPPER VENT DOOR MOTOR	Connector Name UPPER VENT DOOR MOTOR
Connector Type T132FW-NH	Connector Type A03FW	Connector Type A03FW	Connector Type A03FW	Connector Type A03FW

Terminal No.	Color Of Wire	Signal Name [Specification]
85	LG	PARKING BRAKE
86	LG	-
87	LG	-
71	SHIELD	SHIELD
72	R	MICROPHONE VCC
73	R	COMM CONT- DISP
74	P	CAN-L
75	LG	AV COMM (L)
76	LG	AV COMM (L)
79	R	ILLUMINATION SIGNAL
80	G	IGNITION
81	SB	REVERSE
82	V	VEHICLE SPEED SIGNAL (6-PULSE)
83	B	-
87	W	-
89	W	MICROPHONE SIGNAL
80	L	CAN-H
81	SB	AV COMM (H)
82	SB	AV COMM (H)

Terminal No.	Color Of Wire	Signal Name [Specification]
1	-	-
2	-	-
3	-	-

Terminal No.	Color Of Wire	Signal Name [Specification]
1	-	-
2	-	-
3	-	-

Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	B	-
3	L	-

Terminal No.	Color Of Wire	Signal Name [Specification]
1	-	-
2	-	-
3	-	-

Terminal No.	Color Of Wire	Signal Name [Specification]
1	-	-
2	-	-
3	-	-

Terminal No.	Color Of Wire	Signal Name [Specification]
1	-	-
2	-	-
3	-	-

A

B

C

D

E

F

G

H

HAC

J

K

L

M

N

O

P

Fail-Safe

JRIWC1467GB

INFOID:000000009722206

FAIL-SAFE FUNCTION

- If a communication error exists between the A/C auto amp., and the AV control unit and preset switch for 30 seconds or longer, air conditioner is controlled under the following conditions:

A/C AUTO AMP.

< ECU DIAGNOSIS INFORMATION >

[WITH 7 INCH DISPLAY]

Compressor : ON
Air outlet : AUTO
Air inlet : FRE (Fresh)
Blower fan speed : AUTO
Set temperature : Setting before communication error occurs

DTC Inspection Priority Chart

INFOID:000000009722207

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	Detected items (DTC)
1	<ul style="list-style-type: none"> • U1000: CAN COMM CIRCUIT • U1010: CONTROL UNIT (CAN)
2	<ul style="list-style-type: none"> • B2578: IN-VEHICLE SENSOR • B2579: IN-VEHICLE SENSOR • B257B: AMBIENT SENSOR • B257C: AMBIENT SENSOR • B2581: INTAKE SENSOR • B2582: INTAKE SENSOR • B2630: SUNLOAD SENSOR • B2631: SUNLOAD SENSOR • B2632: DR AIR MIX DOOR MOT • B2633: DR AIR MIX DOOR MOT • B2634: PASS AIR MIX DOOR MOT • B2635: PASS AIR MIX DOOR MOT • B2636: DR VENT DOOR FAIL • B2637: DR B/L DOOR FAIL • B2638: DR D/F1 DOOR FAIL • B2639: DR DEF DOOR FAIL • B263D: FRE DOOR FAIL • B263E: 20P FRE DOOR FAIL • B263F: REC DOOR FAIL • B2654: D/F2 DOOR FAIL • B2655: B/L2 DOOR FAIL • B2661: UPPER VENT DOOR MOT • B2662: UPPER VENT DOOR MOT • B2663: UPPER VENT DOOR MOT

DTC Index

INFOID:000000009722208

DTC	Items (CONSULT screen terms)	Reference
U1000	CAN COMM CIRCUIT	HAC-170, "DTC Logic"
U1010	CONTROL UNIT (CAN)	HAC-171, "DTC Logic"
B257B	IN-VEHICLE SENSOR	HAC-172, "DTC Logic"
B257C	IN-VEHICLE SENSOR	HAC-172, "DTC Logic"
B2578	AMBIENT SENSOR	HAC-175, "DTC Logic"
B2579	AMBIENT SENSOR	HAC-175, "DTC Logic"
B2581	INTAKE SENSOR	HAC-178, "DTC Logic"
B2582	INTAKE SENSOR	HAC-178, "DTC Logic"
B2630*	SUNLOAD SENSOR	HAC-181, "DTC Logic"
B2631*	SUNLOAD SENSOR	HAC-181, "DTC Logic"
B2632	DR AIR MIX DOOR MOT	HAC-184, "DTC Logic"
B2633	DR AIR MIX DOOR MOT	HAC-184, "DTC Logic"

A/C AUTO AMP.

< ECU DIAGNOSIS INFORMATION >

[WITH 7 INCH DISPLAY]

DTC	Items (CONSULT screen terms)	Reference
B2634	PASS AIR MIX DOOR MOT	HAC-186, "DTC Logic"
B2635	PASS AIR MIX DOOR MOT	HAC-186, "DTC Logic"
B2636	DR VENT DOOR FAIL	HAC-188, "DTC Logic"
B2637	DR B/L DOOR FAIL	HAC-188, "DTC Logic"
B2638	DR D/F1 DOOR FAIL	HAC-188, "DTC Logic"
B2639	DR DEF DOOR FAIL	HAC-188, "DTC Logic"
B263D	FRE DOOR FAIL	HAC-191, "DTC Logic"
B263E	20P FRE DOOR FAIL	HAC-191, "DTC Logic"
B263F	REC DOOR FAIL	HAC-191, "DTC Logic"
B2654	D/F2 DOOR FAIL	HAC-188, "DTC Logic"
B2655	B/L2 DOOR FAIL	HAC-188, "DTC Logic"
B2661	UPPER VENT DOOR MOT	HAC-193, "DTC Logic"
B2662	UPPER VENT DOOR MOT	HAC-193, "DTC Logic"
B2663	UPPER VENT DOOR MOT	HAC-193, "DTC Logic"

*: Perform self-diagnosis under sunshine. When performing indoors, aim a light (more than 60 W) at sunload sensor, otherwise self-diagnosis indicates even though the sunload sensor is functioning normally.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

AIR CONDITIONER CONTROL

< SYMPTOM DIAGNOSIS >

[WITH 7 INCH DISPLAY]

SYMPTOM DIAGNOSIS

AIR CONDITIONER CONTROL

Diagnosis Chart By Symptom

INFOID:000000009722209

Symptom	Reference	
A/C system does not activate.	Go to Trouble Diagnosis Procedure for A/C System.	HAC-202. "A/C AUTO AMP. : Diagnosis Procedure"
A/C system cannot be controlled.	Go to Trouble Diagnosis Procedure for Preset Switch System.	AV-142. "Symptom Table" (base audio without navigation), AV-269. "Symptom Table" (BOSE audio without navigation) or AV-436. "Symptom Table" (BOSE audio with navigation)
Air outlet does not change.	Go to Trouble Diagnosis Procedure for Mode Door Motor. (LAN)	HAC-189. "Diagnosis Procedure"
Mode door motor does not operate normally.		
Discharge air temperature does not change.	Go to Trouble Diagnosis Procedure for Air Mix Door Motor. (LAN)	HAC-185. "Diagnosis Procedure" (driver side) or HAC-187. "Diagnosis Procedure" (passenger side)
Air mix door motor does not operate normally.		
Intake door does not change.	Go to Trouble Diagnosis Procedure for Intake Door Motor. (LAN)	HAC-192. "Diagnosis Procedure"
Intake door motor does not operate normally.		
Blower motor operation is malfunctioning.	Go to Trouble Diagnosis Procedure for Blower Motor.	HAC-196. "Diagnosis Procedure"
Magnet clutch does not engage.	Go to Trouble Diagnosis Procedure for Magnet Clutch.	HAC-200. "Diagnosis Procedure"
Insufficient cooling	Go to Trouble Diagnosis Procedure for Insufficient Cooling.	HAC-233. "Inspection procedure"
No cool air comes out. (Air flow volume is normal.)		
Insufficient heating	Go to Trouble Diagnosis Procedure for Insufficient Heating.	HAC-236. "Inspection procedure"
No warm air comes out. (Air flow volume is normal.)		
Noise	Go to Trouble Diagnosis Procedure for Noise.	HAC-239. "Inspection procedure"
Memory function does not operate.	Go to Trouble Diagnosis Procedure for Memory Function.	HAC-241. "Inspection procedure"

INSUFFICIENT COOLING

Description

INFOID:00000000972210

Symptom

- Insufficient cooling
- No cool air comes out. (Air flow volume is normal.)

Inspection procedure

INFOID:00000000972211

1.CHECK WITH A GAUGE OF RECOVERY/RECYCLING RECHARGING EQUIPMENT

Connect the recovery/recycling recharging equipment to the vehicle and perform the pressure inspection with the gauge.

Is there refrigerant?

- YES >> GO TO 2.
 NO-1 >> Check for refrigerant leakages with the refrigerant leakage detecting fluorescent leak detector. Refer to [HA-30, "Inspection"](#).
 NO-2 >> GO TO 2 after repairing or replacing the parts according to the inspection results.

2.CHECK CHARGED REFRIGERANT AMOUNT

1. Connect recovery/recycling recharging equipment to the vehicle and discharge the refrigerant.
2. Recharge with the proper amount of refrigerant and perform the inspection with the refrigerant leakage detecting fluorescent leak detector. Refer to [HA-30, "Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Refill the refrigerant and repair or replace the parts according to the inspection results.

3.CHECK REFRIGERANT CYCLE PRESSURE

Connect recovery/recycling recharging equipment to the vehicle and perform the performance test. Refer to [HA-28, "Performance Chart"](#).

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Perform the diagnosis with the gauge pressure. Refer to [HA-8, "Trouble Diagnosis For Unusual Pressure"](#).

4.CHECK SETTING OF TEMPERATURE SETTING TRIMMER

Using CONSULT, check the setting of "TEMP SET CORRECT" on "WORK SUPPORT" of HVAC. Refer to [HAC-136, "Temperature Setting Trimmer"](#).

1. Check that the temperature setting trimmer is set to "+ direction".
NOTE:
The control temperature can be set with the setting of the temperature setting trimmer.
2. Set temperature control dial to "0".

Are the malfunction solved?

- YES >> Perform the setting separately if necessary. END.
 NO >> GO TO 5.

5.CHECK WITH SELF-DIAGNOSIS FUNCTION OF CONSULT

1. Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
2. Check if any DTC No. is displayed in the trouble diagnosis results.
NOTE:
If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-170, "DTC Logic"](#) or [HAC-171, "DTC Logic"](#).

Is any DTC No. displayed?

- YES >> Perform the diagnosis that is applicable to the sensor and the door motor. Refer to [HAC-230, "DTC Index"](#).
 NO >> GO TO 6.

6.CHECK WITH ACTIVE TEST OF CONSULT

INSUFFICIENT COOLING

< SYMPTOM DIAGNOSIS >

[WITH 7 INCH DISPLAY]

- Using CONSULT, perform "HVAC TEST" "ACTIVE TEST" of HVAC to check each output device. Refer to [HAC-166, "CONSULT Function"](#).

NOTE:

Perform the ACTIVE TEST after starting the engine because the compressor is operated.

- Refer to the table and check the outlet, inlet, air flow temperature, blower motor control signal, magnet clutch operation, and air mix ratio. Visually check each operating condition, by listening for noise, touching air outlets with a hand, etc.

	Test item						
	MODE 1	MODE 2	MODE 3	MODE 4	MODE 5	MODE 6	MODE 7
Mode door position	VENT1	VENT2	B/L1	B/L2	FOOT	D/F	DEF
Intake door position	REC	REC	20%FRE	20%FRE	FRE	FRE	FRE
Air mix door position (driver & passenger side)	FULL COLD	FULL HOT	FULL COLD	FULL HOT	FULL HOT	FULL HOT	FULL HOT
Blower motor duty ratio	35%	35%	61%	61%	81%	81%	35%
Compressor (Magnet clutch)	ON	ON	ON	ON	OFF	OFF	ON
Upper ventilator door	OPEN	SHUT	OPEN	SHUT	SHUT	SHUT	SHUT

NOTE:

Perform the inspection of each output device after starting the engine because the compressor is operated.

Discharge air flow							
Mode position indication	Condition	Air outlet/distribution					
		VENT			FOOT		DEF
		Front	Upper	Rear	Front	Rear	
	DUAL switch: OFF UPPER VENT switch : ON	81%	8%	11%	—	—	—
		41%	10%	17%	24%	8%	—
		12%	12%	16%	27%	10%	23%
		11%	11%	14%	25%	10%	29%
		11%	11%	12%	—	—	66%

JPIIA0509GB

Discharge air flow							
Mode position indication	Condition	Air outlet/distribution					
		VENT			FOOT		DEF
		Front	Upper	Rear	Front	Rear	
	DUAL switch: OFF UPPER VENT switch : OFF	88%	—	12%	—	—	—
		47%	—	18%	26%	9%	—
		13%	—	17%	33%	12%	25%
		12%	—	16%	28%	12%	32%
		11%	—	15%	—	—	74%

JPIIA0510GB

Does it operate normally?

YES >> GO TO 7.

INSUFFICIENT COOLING

[WITH 7 INCH DISPLAY]

< SYMPTOM DIAGNOSIS >

- NO-1 >> Air outlet does not change. Refer to [HAC-189, "Diagnosis Procedure"](#).
- NO-2 >> Air inlet does not change. Refer to [HAC-192, "Diagnosis Procedure"](#).
- NO-3 >> Discharge air temperature does not change. Refer to [HAC-185, "Diagnosis Procedure"](#) and [HAC-187, "Diagnosis Procedure"](#).
- NO-4 >> Blower motor does not operate normally. Refer to [HAC-196, "Diagnosis Procedure"](#).
- NO-5 >> Magnet clutch does not operate. Refer to [HAC-200, "Diagnosis Procedure"](#).

7. CHECK AMBIENT TEMPERATURE DISPLAY

Check that there is not much difference between actual ambient temperature and indicated temperature on information display in combination meter.

Is the inspection result normal?

- YES >> GO TO 8.
- NO >> Perform the diagnosis for the A/C auto amp. connection recognition signal. Refer to [MWI-56, "Diagnosis Procedure"](#).

8. CHECK DRIVE BELT

Check tension of the drive belt. Refer to [EM-17, "Checking"](#).

Is the inspection result normal?

- YES >> GO TO 9.
- NO >> Adjust or replace drive belt.

9. CHECK AIR LEAKAGE FROM DUCT

Check duct and nozzle, etc, of the A/C system for air leakage.

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> Repair or replace parts according to the inspection results.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

INSUFFICIENT HEATING

Description

INFOID:000000009722212

Symptom

- Insufficient heating
- No warm air comes out. (Air flow volume is normal.)

Inspection procedure

INFOID:000000009722213

1. CHECK COOLING SYSTEM

1. Check engine coolant level and check for leakage. Refer to [CO-11, "Inspection"](#).
2. Check radiator cap. Refer to [CO-15, "RADIATOR CAP : Inspection"](#).
3. Check water flow sounds of engine coolant. Refer to [CO-12, "Refilling"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Refill the engine coolant and repair or replace the parts according to the inspection results.

2. CHECK OPERATION

1. Press temperature dial (driver side) and raise temperature setting to 32°C (90°F) after warming up the engine.
2. Check that warm air blows from the outlets.

Is the inspection result normal?

- YES >> INSPECTION END
NO >> GO TO 3.

3. CHECK SETTING OF TEMPERATURE SETTING TRIMMER

Using CONSULT, check the setting of "TEMP SET CORRECT" on "WORK SUPPORT" of HVAC. Refer to [HAC-136, "Temperature Setting Trimmer"](#).

1. Check that the temperature setting trimmer is set to "– direction".
NOTE:
The control temperature can be set by the temperature setting trimmer.
2. Set temperature control dial to "0".

Are the malfunction solved?

- YES >> Perform the setting separately if necessary. END.
NO >> GO TO 4.

4. CHECK WITH SELF-DIAGNOSIS FUNCTION OF CONSULT

1. Using CONSULT, perform "SELF-DIAGNOSIS RESULTS" of HVAC.
2. Check if any DTC No. is displayed in the trouble diagnosis results.

NOTE:

If DTC is displayed along with DTC U1000 or U1010, first diagnose the DTC U1000 or U1010. Refer to [HAC-170, "DTC Logic"](#) or [HAC-171, "DTC Logic"](#).

Is any DTC No. displayed?

- YES >> Perform the diagnosis that is applicable to the sensor and the door motor. Refer to [HAC-230, "DTC Index"](#).
NO >> GO TO 5.

5. CHECK WITH ACTIVE TEST OF CONSULT

1. Using CONSULT, perform "HVAC TEST" in "ACTIVE TEST" of HVAC to check each output device. Refer to [HAC-166, "CONSULT Function"](#).

NOTE:

Perform the ACTIVE TEST after starting the engine because the compressor is operated.

2. Refer to the table and check the outlet, inlet, air flow temperature, blower motor control signal, magnet clutch operation, and air mix ratio. Visually check each operating condition, by listening for noise, touching air outlets with a hand, etc.

INSUFFICIENT HEATING

< SYMPTOM DIAGNOSIS >

[WITH 7 INCH DISPLAY]

	Test item						
	MODE 1	MODE 2	MODE 3	MODE 4	MODE 5	MODE 6	MODE 7
Mode door position	VENT1	VENT2	B/L1	B/L2	FOOT	D/F	DEF
Intake door position	REC	REC	20%FRE	20%FRE	FRE	FRE	FRE
Air mix door position (driver & passenger side)	FULL COLD	FULL HOT	FULL COLD	FULL HOT	FULL HOT	FULL HOT	FULL HOT
Blower motor duty ratio	35%	35%	61%	61%	81%	81%	35%
Compressor (Magnet clutch)	ON	ON	ON	ON	OFF	OFF	ON
Upper ventilator door	OPEN	SHUT	OPEN	SHUT	SHUT	SHUT	SHUT

NOTE:

Perform the inspection of each output device after starting the engine because the compressor is operated.

Discharge air flow							
Mode position indication	Condition	Air outlet/distribution					
		VENT			FOOT		DEF
		Front	Upper	Rear	Front	Rear	
	DUAL switch: OFF UPPER VENT switch : ON	81%	8%	11%	—	—	—
		41%	10%	17%	24%	8%	—
		12%	12%	16%	27%	10%	23%
		11%	11%	14%	25%	10%	29%
		11%	11%	12%	—	—	66%

JPIIA0509GB

Discharge air flow							
Mode position indication	Condition	Air outlet/distribution					
		VENT			FOOT		DEF
		Front	Upper	Rear	Front	Rear	
	DUAL switch: OFF UPPER VENT switch : OFF	88%	—	12%	—	—	—
		47%	—	18%	26%	9%	—
		13%	—	17%	33%	12%	25%
		12%	—	16%	28%	12%	32%
		11%	—	15%	—	—	74%

JPIIA0510GB

Does it operate normally?

YES >> GO TO 6.

NO-1 >> Air outlet does not change. Refer to [HAC-189, "Diagnosis Procedure"](#).

NO-2 >> Air inlet does not change. Refer to [HAC-192, "Diagnosis Procedure"](#).

NO-3 >> Discharge air temperature does not change. Refer to [HAC-185, "Diagnosis Procedure"](#) and [HAC-187, "Diagnosis Procedure"](#).

NO-4 >> Blower motor does not operate normally. Refer to [HAC-196, "Diagnosis Procedure"](#).

NO-5 >> Magnet clutch does not operate. Refer to [HAC-200, "Diagnosis Procedure"](#).

INSUFFICIENT HEATING

< SYMPTOM DIAGNOSIS >

[WITH 7 INCH DISPLAY]

6.CHECK AIR LEAKAGE FROM DUCT

Check duct and nozzle, etc, of the A/C system for air leakage.

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace parts according to the inspection results.

7.CHECK HEATER HOSE INSTALLATION CONDITION

Check the heater hose installation condition visually (for twists, crushes, etc.).

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair or replace parts according to the inspection results.

8.CHECK TEMPERATURE OF HEATER HOSE

1. Check the temperature of inlet hose and outlet hose of heater core.
2. Check that the inlet side of heater core is hot and the outlet side is slightly lower than/almost equal to the inlet side.

CAUTION:

Always perform the temperature inspection in a short period of time because the engine coolant temperature is very hot.

Is the inspection result normal?

YES >> GO TO 9.

NO >> Replace the heater core after performing the procedures after the cooling system inspection. GO TO 1.

9.REPLACE HEATER CORE

Replace the heater core. Refer to heater core. Refer to [VTL-111, "Exploded View"](#).

Are the malfunction solved?

YES >> INSPECTION END

NO >> Perform the procedures again after the cooling system inspection. GO TO 1.

NOISE**Description**

INFOID:000000009722214

Symptom

- Noise
- Noise is heard when the A/C system operates.

Inspection procedure

INFOID:000000009722215

1.CHECK OPERATION

1. Operate the A/C system and check the operation. Refer to [HAC-134. "Description & Inspection"](#).
2. Check the parts where noise is occurring.

Can the parts where noise is occurring be checked?

- YES-1 >> Noise from blower motor: GO TO 2.
 YES-2 >> Noise from compressor: GO TO 3.
 YES-3 >> Noise from expansion valve: GO TO 4.
 YES-4 >> Noise from A/C piping (pipe, flexible hose): GO TO 6.
 YES-5 >> Noise from drive belt: GO TO 7.
 NO >> INSPECTION END

2.CHECK BLOWER MOTOR

1. Remove blower motor.
2. Remove foreign materials that are in the blower unit.
3. Check the noise from blower motor again.

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> Replace blower motor.

3.CHECK COMPRESSOR

Perform trouble diagnosis for the compressor and check the compressor. Refer to [HA-11. "Symptom Table"](#).

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> Refill the refrigerant or replace the compressor according to the inspection results.

4.CHECK WITH GAUGE PRESSURE

Perform the diagnosis with the gauge pressure. Refer to [HA-8. "Trouble Diagnosis For Unusual Pressure"](#).

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> Repair or replace parts according to the inspection results.

5.CHECK EXPANSION VALVE

1. Correct the refrigerant with recovery/recycling recharging equipment.
2. Recharge with the proper amount of the collected refrigerant after recycling or new refrigerant.
3. Check for the noise from expansion valve again.

Are the malfunction solved?

- YES >> INSPECTION END
 NO >> Replace expansion valve.

6.CHECK A/C PIPING (PIPE, FLEXIBLE HOSE)

1. Check the A/C piping (pipes, flexible hoses) (for deformation and damage, etc.).
2. Check the installation condition of clips and brackets, etc, of the A/C piping (pipes, flexible hoses).

Is the inspection result normal?

- YES >> Fix the line with rubber or come vibration absorbing material.
 NO >> Repair or replace parts according to the inspection results.

7.CHECK DRIVE BELTA
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

NOISE

< SYMPTOM DIAGNOSIS >

[WITH 7 INCH DISPLAY]

Check tension of the drive belt. Refer to [EM-17. "Checking"](#).

Is the inspection result normal?

YES >> Check the noise from compressor: GO TO 3.

NO >> Adjust or replace drive belt according to the inspection results.

MEMORY FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[WITH 7 INCH DISPLAY]

MEMORY FUNCTION DOES NOT OPERATE

Description

INFOID:000000009722216

Symptom

- Memory function does not operate normally.
- The setting is not maintained. (It returns to the initial condition.)

Inspection procedure

INFOID:000000009722217

1.CHECK OPERATION

1. Set temperature control dial to 32°C (90°F).
2. Press the ON/OFF switch.
3. Turn the ignition switch OFF.
4. Turn the ignition switch ON.
5. Press the AUTO switch.
6. Check that the set temperature is maintained.

Is the inspection result normal?

- YES >> INSPECTION END
NO >> GO TO 2.

2.CHECK POWER SUPPLY AND GROUND CIRCUIT OF A/C AUTO AMP.

Check power supply and ground circuit of the A/C auto amp. Refer to [HAC-202. "A/C AUTO AMP. : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> Replace the A/C auto amp.
NO >> Repair or replace malfunctioning parts.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

PRECAUTIONS

< PRECAUTION >

[WITH 7 INCH DISPLAY]

PRECAUTION

PRECAUTIONS

FOR USA AND CANADA

FOR USA AND CANADA : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000097222 18

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

FOR USA AND CANADA : Precautions for Removing of Battery Terminal

INFOID:000000010092860

- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.

NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.


NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.



FOR USA AND CANADA : Working with HFC-134a (R-134a)

INFOID:0000000097222 19

CAUTION:

- CFC-12 (R-12) refrigerant and HFC-134a (R-134a) refrigerant are not compatible. Compressor malfunction is likely to occur if the refrigerants are mixed, refer to "CONTAMINATED REFRIGERANT"

PRECAUTIONS

< PRECAUTION >

[WITH 7 INCH DISPLAY]

- below. To determine the purity of HFC-134a (R-134a) in the vehicle and recovery tank, use Refrigerant Recovery/Recycling Recharging equipment and Refrigerant Identifier.
- Use only specified lubricant for the HFC-134a (R-134a) A/C system and HFC-134a (R-134a) components. Compressor malfunction is likely to occur if lubricant other than that specified is used.
 - The specified HFC-134a (R-134a) lubricant rapidly absorbs moisture from the atmosphere. The following handling precautions must be observed:
 - Immediately cap (seal) the component to minimize the entry of moisture from the atmosphere when removing refrigerant components from a vehicle.
 - Never remove the caps (unseal) until just before connecting the components when installing refrigerant components to a vehicle. Connect all refrigerant loop components as quickly as possible to minimize the entry of moisture into system.
 - Use only the specified lubricant from a sealed container. Immediately reseal containers of lubricant. Lubricant becomes moisture saturated and should not be used without proper sealing.
 - Never allow lubricant (NISSAN A/C System Oil Type S) to come in to contact with styrene foam parts. Damage may result.

CONTAMINATED REFRIGERANT

Take the appropriate steps shown below if a refrigerant other than pure HFC-134a (R-134a) is identified in a vehicle:

- Explain to the customer that environmental regulations prohibit the release of contaminated refrigerant into the atmosphere.
- Explain that recovery of the contaminated refrigerant could damage service equipment and refrigerant supply.
- Suggest the customer return the vehicle to the location of previous service where the contamination may have occurred.
- If repairing, recover the refrigerant using only **dedicated equipment and containers. Never reintroduce contaminated refrigerant into the existing service equipment.** Contact a local refrigerant product retailer for available service if the facility does not have dedicated recovery equipment. This refrigerant must be disposed of in accordance with all federal and local regulations. In addition, replacement of all refrigerant system components on the vehicle is recommended.
- The air conditioner warranty is void if the vehicle is within the warranty period. Please contact Nissan Customer Affairs for further assistance.

FOR USA AND CANADA : General Refrigerant Precaution

INFOID:000000009722220

WARNING:

- **Never breath A/C refrigerant, lubricant vapor or mist. Exposure may irritate eyes, nose and throat. Remove HFC-134a (R-134a) from the A/C system, using certified service equipment meeting requirements of SAE J-2210 [HFC-134a (R-134a) recycling equipment], or J-2209 [HFC-134a (R-134a) recovery equipment]. Ventilate work area before resuming service if accidental system discharge occurs. Additional health and safety information may be obtained from refrigerant and lubricant manufacturers.**
- **Never release refrigerant into the air. Use approved recovery/recycling equipment to capture the refrigerant each time an air conditioning system is discharged.**
- **Always wear eye and hand protection (goggles and gloves) when working with any refrigerant or air conditioning system.**
- **Never store or heat refrigerant containers above 52°C (126°F).**
- **Never heat a refrigerant container with an open flame. Place the bottom of the container in a warm pail of water if container warming is required.**
- **Never intentionally drop, puncture, or incinerate refrigerant containers.**
- **Keep refrigerant away from open flames. Poisonous gas is produced if refrigerant burns.**
- **Refrigerant displaces oxygen, therefore be certain to work in well ventilated areas to prevent suffocation.**
- **Never pressure test or leakage test HFC-134a (R-134a) service equipment and/or vehicle air conditioning systems with compressed air during repair. Some mixtures of air and HFC-134a (R-134a) have been shown to be combustible at elevated pressures. These mixtures, if ignited, may cause injury or property damage. Additional health and safety information may be obtained from refrigerant manufacturers.**

FOR USA AND CANADA : Refrigerant Connection

INFOID:000000009722221

A new type refrigerant connection has been introduced to all refrigerant lines except the following location.


PRECAUTIONS

[WITH 7 INCH DISPLAY]

< PRECAUTION >

- Expansion valve to evaporator
- Refrigerant pressure sensor to liquid tank

O-RING AND REFRIGERANT CONNECTION



F: Former type refrigerant connection N: New type refrigerant connection

○: O-ring size

CAUTION:

The new and former refrigerant connections use different O-ring configurations. Never confuse O-rings since they are not interchangeable. Refrigerant may leak at the connection if a wrong O-ring is installed.

O-Ring Part Numbers and Specifications

Connection type	Piping connection point	Part number	QTY	O-ring size	
New	Low-pressure flexible hose to low-pressure pipe	92474 N8210	1	φ19	
	High-pressure pipe to condenser pipe assembly (Outlet)	92471 N8210	1	φ8	
	Condenser pipe assembly (Inlet) to high-pressure flexible hose (One-touch joint)	92472 N8210	1	φ12	
	Condenser assembly to condenser pipe assembly	Inlet	92472 N8210	1	φ12
		Outlet	92471 N8210	1	φ8
	Low-pressure pipe to expansion valve	92473 N8210	1	φ16	
	High-pressure pipe to expansion valve	92471 N8210	1	φ8	
	Compressor to low-pressure flexible hose	92474 N8210	1	φ19	
	Compressor to high-pressure flexible hose	92472 N8210	1	φ12	
Liquid tank to condenser assembly	Inlet	92471 N8210	1	φ8	
	Outlet		1		

PRECAUTIONS

< PRECAUTION >

[WITH 7 INCH DISPLAY]

Connection type	Piping connection point		Part number	QTY	O-ring size
Former	Refrigerant pressure sensor to liquid tank		J2476 89956	1	φ10
	Expansion valve to evaporator pipe assembly	Inlet	92475 71L00	1	φ12
		Outlet	92475 72L00	1	φ16
	Evaporator to evaporator pipe assembly	Inlet	92475 71L00	1	φ12
		Outlet	92475 72L00	1	φ16

WARNING:

Check that all refrigerant is discharged into the recycling equipment and the pressure in the system is less than atmospheric pressure. Then gradually loosen the discharge side hose fitting and remove it.


CAUTION:

Observe the following when replacing or cleaning refrigerant cycle components.

- Store it in the same way as it is when mounted on the car when the compressor is removed. Failure to do so will cause lubricant to enter the low-pressure chamber.
- Always use a torque wrench and a back-up wrench when connecting tubes.
- Immediately plug all openings to prevent entry of dust and moisture after disconnecting tubes.
- Connect the pipes at the final stage of the operation when installing an air conditioner in the vehicle. Never remove the seal caps of pipes and other components until just before required for connection.
- Allow components stored in cool areas to warm to working area temperature before removing seal caps. This prevents condensation from forming inside A/C components.
- Thoroughly remove moisture from the refrigeration system before charging the refrigerant.
- Replace always used O-rings.
- Apply lubricant to circle of the O-rings shown in illustration when connecting tube. Be careful not to apply lubricant to threaded portion.

Name : NISSAN A/C System Oil Type S

- O-ring must be closely attached to the groove portion of tube.
- Be careful not to damage O-ring and tube when replacing the O-ring.
- Connect tube until a click can be heard. Then tighten the nut or bolt by hand. Check that the O-ring is installed to tube correctly.
- Perform leakage test and make sure that there is no leakage from connections after connecting line. Disconnect the line and replace the O-ring when the refrigerant leaking point is found. Then tighten the connections of seal seat to the specified torque.



FOR USA AND CANADA : Service Equipment

INFOID:000000009722222

RECOVERY/RECYCLING EQUIPMENT

Be certain to follow the manufacturer instructions for machine operation and machine maintenance. Never introduce any refrigerant other than that specified into the machine.

ELECTRICAL LEAK DETECTOR

PRECAUTIONS

[WITH 7 INCH DISPLAY]

< PRECAUTION >


Be certain to follow the manufacturer instructions for tester operation and tester maintenance.

VACUUM PUMP

The lubricant contained inside the vacuum pump is not compatible with the specified lubricant for HFC-134a (R-134a) A/C systems. The vent side of the vacuum pump is exposed to atmospheric pressure. So the vacuum pump lubricant may migrate out of the pump into the service hose. This is possible when the pump is switched OFF after evacuation (vacuuming) and hose is connected to it. To prevent this migration, use a manual valve placed near the hose-to-pump connection, as per the following.


- Vacuum pumps usually have a manual isolator valve as part of the pump. Close this valve to isolate the service hose from the pump.
- Use a hose equipped with a manual shut-off valve near the pump end for pumps without an isolator. Close the valve to isolate the hose from the pump.
- Disconnect the hose from the pump if the hose has an automatic shut-off valve. As long as the hose is connected, the valve is open and lubricating oil may migrate.

Some one-way valves open when vacuum is applied and close under no vacuum condition. Such valves may restrict the ability of the pump to create a deep vacuum and are not recommended.




MANIFOLD GAUGE SET

Be certain that the gauge face indicates HFC-134a or R-134a. Be sure the gauge set has 1/2"-16 ACME threaded connections for service hoses. Confirm the set has been used only with refrigerant HFC-134a (R-134a) and specified lubricants.



SERVICE HOSES

Be certain that the service hoses display the markings described (colored hose with a black stripe). All hoses must equip positive shut-off devices (either manual or automatic) near the end of the hoses opposite to the manifold gauge.



SERVICE COUPLERS


PRECAUTIONS

< PRECAUTION >

[WITH 7 INCH DISPLAY]


Never attempt to connect HFC-134a (R-134a) service couplers to a CFC-12 (R-12) A/C system. The HFC-134a (R-134a) couplers do not properly connect to the CFC-12 (R-12) system. However, if an improper connection is attempted, discharge and contamination may occur.

Shut-off valve rotation	A/C service valve
Clockwise	Open
Counterclockwise	Close



REFRIGERANT WEIGHT SCALE

Verify that no refrigerant other than HFC-134a (R-134a) and specified lubricants have been used with the scale. The hose fitting must be 1/2"-16 ACME if the scale controls refrigerant flow electronically.



CHARGING CYLINDER

Use of a charging cylinder is not recommended. Refrigerant may be vented into the air from the top valve of the cylinder when filling the cylinder with refrigerant. Also, the accuracy of the cylinder is generally less than that of an electronic scale or of quality recycle/recharge equipment.

FOR MEXICO

FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009722223

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

PRECAUTIONS

< PRECAUTION >

[WITH 7 INCH DISPLAY]

FOR MEXICO : Precautions for Removing of Battery Terminal

INFOID:000000010092862

- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.

NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.


NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.



FOR MEXICO : Working with HFC-134a (R-134a)

INFOID:000000009722224

CAUTION:

- CFC-12 (R-12) refrigerant and HFC-134a (R-134a) refrigerant are not compatible. Compressor malfunction is likely to occur if the refrigerants are mixed, refer to "CONTAMINATED REFRIGERANT" below. To determine the purity of HFC-134a (R-134a) in the vehicle and recovery tank, use Refrigerant Recovery/Recycling Recharging equipment and Refrigerant Identifier.
- Use only specified lubricant for the HFC-134a (R-134a) A/C system and HFC-134a (R-134a) components. Compressor malfunction is likely to occur if lubricant other than that specified is used.
- The specified HFC-134a (R-134a) lubricant rapidly absorbs moisture from the atmosphere. The following handling precautions must be observed:
 - Immediately cap (seal) the component to minimize the entry of moisture from the atmosphere when removing refrigerant components from a vehicle.
 - Never remove the caps (unseal) until just before connecting the components when installing refrigerant components to a vehicle. Connect all refrigerant loop components as quickly as possible to minimize the entry of moisture into system.
 - Use only the specified lubricant from a sealed container. Immediately reseal containers of lubricant. Lubricant becomes moisture saturated and should not be used without proper sealing.
 - Never allow lubricant (NISSAN A/C System Oil Type S) to come in to contact with styrene foam parts. Damage may result.

CONTAMINATED REFRIGERANT

Take the appropriate steps shown below if a refrigerant other than pure HFC-134a (R-134a) is identified in a vehicle:

- Explain to the customer that environmental regulations prohibit the release of contaminated refrigerant into the atmosphere.
- Explain that recovery of the contaminated refrigerant could damage service equipment and refrigerant supply.
- Suggest the customer return the vehicle to the location of previous service where the contamination may have occurred.
- If repairing, recover the refrigerant using only **dedicated equipment and containers. Never reintroduce contaminated refrigerant into the existing service equipment.** Contact a local refrigerant product retailer for available service if the facility does not have dedicated recovery equipment. This refrigerant must be disposed of in accordance with all federal and local regulations. In addition, replacement of all refrigerant system components on the vehicle is recommended.
- The air conditioner warranty is void if the vehicle is within the warranty period. Please contact Nissan Customer Affairs for further assistance.

FOR MEXICO : General Refrigerant Precaution

INFOID:000000009722225

WARNING:

- Never breath A/C refrigerant, lubricant vapor or mist. Exposure may irritate eyes, nose and throat. Remove HFC-134a (R-134a) from the A/C system, using certified service equipment meeting require-

PRECAUTIONS

< PRECAUTION >

[WITH 7 INCH DISPLAY]

- ments of SAE J-2210 [HFC-134a (R-134a) recycling equipment], or J-2209 [HFC-134a (R-134a) recovery equipment]. Ventilate work area before resuming service if accidental system discharge occurs. Additional health and safety information may be obtained from refrigerant and lubricant manufacturers.
- Never release refrigerant into the air. Use approved recovery/recycling equipment to capture the refrigerant each time an air conditioning system is discharged.
 - Always wear eye and hand protection (goggles and gloves) when working with any refrigerant or air conditioning system.
 - Never store or heat refrigerant containers above 52°C (126°F).
 - Never heat a refrigerant container with an open flame. Place the bottom of the container in a warm pail of water if container warming is required.
 - Never intentionally drop, puncture, or incinerate refrigerant containers.
 - Keep refrigerant away from open flames. Poisonous gas is produced if refrigerant burns.
 - Refrigerant displaces oxygen, therefore be certain to work in well ventilated areas to prevent suffocation.
 - Never pressure test or leakage test HFC-134a (R-134a) service equipment and/or vehicle air conditioning systems with compressed air during repair. Some mixtures of air and HFC-134a (R-134a) have been shown to be combustible at elevated pressures. These mixtures, if ignited, may cause injury or property damage. Additional health and safety information may be obtained from refrigerant manufacturers.


FOR MEXICO : Refrigerant Connection

INFOID:00000000972226

A new type refrigerant connection has been introduced to all refrigerant lines except the following location.

- Expansion valve to evaporator
- Refrigerant pressure sensor to liquid tank

O-RING AND REFRIGERANT CONNECTION



F. Former type refrigerant connection N. New type refrigerant connection

O: O-ring size

CAUTION:

PRECAUTIONS

< PRECAUTION >

[WITH 7 INCH DISPLAY]

The new and former refrigerant connections use different O-ring configurations. Never confuse O-rings since they are not interchangeable. Refrigerant may leak at the connection if a wrong O-ring is installed.

O-Ring Part Numbers and Specifications

Connection type	Piping connection point		Part number	QTY	O-ring size
New	Low-pressure flexible hose to low-pressure pipe		92474 N8210	1	φ19
	High-pressure pipe to condenser pipe assembly (Outlet)		92471 N8210	1	φ8
	Condenser pipe assembly (Inlet) to high-pressure flexible hose (One-touch joint)		92472 N8210	1	φ12
	Condenser assembly to condenser pipe assembly	Inlet	92472 N8210	1	φ12
		Outlet	92471 N8210	1	φ8
	Low-pressure pipe to expansion valve		92473 N8210	1	φ16
	High-pressure pipe to expansion valve		92471 N8210	1	φ8
	Compressor to low-pressure flexible hose		92474 N8210	1	φ19
	Compressor to high-pressure flexible hose		92472 N8210	1	φ12
	Liquid tank to condenser assembly	Inlet	92471 N8210	1	φ8
Outlet		1			
Former	Refrigerant pressure sensor to liquid tank		J2476 89956	1	φ10
	Expansion valve to evaporator pipe assembly	Inlet	92475 71L00	1	φ12
		Outlet	92475 72L00	1	φ16
	Evaporator to evaporator pipe assembly	Inlet	92475 71L00	1	φ12
		Outlet	92475 72L00	1	φ16

WARNING:

Check that all refrigerant is discharged into the recycling equipment and the pressure in the system is less than atmospheric pressure. Then gradually loosen the discharge side hose fitting and remove it.

CAUTION:

Observe the following when replacing or cleaning refrigerant cycle components.

- Store it in the same way as it is when mounted on the car when the compressor is removed. Failure to do so will cause lubricant to enter the low-pressure chamber.
- Always use a torque wrench and a back-up wrench when connecting tubes.
- Immediately plug all openings to prevent entry of dust and moisture after disconnecting tubes.
- Connect the pipes at the final stage of the operation when installing an air conditioner in the vehicle. Never remove the seal caps of pipes and other components until just before required for connection.
- Allow components stored in cool areas to warm to working area temperature before removing seal caps. This prevents condensation from forming inside A/C components.
- Thoroughly remove moisture from the refrigeration system before charging the refrigerant.
- Replace always used O-rings.
- Apply lubricant to circle of the O-rings shown in illustration when connecting tube. Be careful not to apply lubricant to threaded portion.

Name : NISSAN A/C System Oil Type S


- O-ring must be closely attached to the groove portion of tube.
- Be careful not to damage O-ring and tube when replacing the O-ring.
- Connect tube until a click can be heard. Then tighten the nut or bolt by hand. Check that the O-ring is installed to tube correctly.

PRECAUTIONS

[WITH 7 INCH DISPLAY]

< PRECAUTION >

- Perform leakage test and make sure that there is no leakage from connections after connecting line. Disconnect the line and replace the O-ring when the refrigerant leaking point is found. Then tighten the connections of seal seat to the specified torque.



FOR MEXICO : Service Equipment

INFOID:00000000972227

RECOVERY/RECYCLING EQUIPMENT

Be certain to follow the manufacturer instructions for machine operation and machine maintenance. Never introduce any refrigerant other than that specified into the machine.

ELECTRICAL LEAK DETECTOR


Be certain to follow the manufacturer instructions for tester operation and tester maintenance.

VACUUM PUMP

The lubricant contained inside the vacuum pump is not compatible with the specified lubricant for HFC-134a (R-134a) A/C systems. The vent side of the vacuum pump is exposed to atmospheric pressure. So the vacuum pump lubricant may migrate out of the pump into the service hose. This is possible when the pump is switched OFF after evacuation (vacuuming) and hose is connected to it. To prevent this migration, use a manual valve placed near the hose-to-pump connection, as per the following.

- Vacuum pumps usually have a manual isolator valve as part of the pump. Close this valve to isolate the service hose from the pump.
- Use a hose equipped with a manual shut-off valve near the pump end for pumps without an isolator. Close the valve to isolate the hose from the pump.
- Disconnect the hose from the pump if the hose has an automatic shut-off valve. As long as the hose is connected, the valve is open and lubricating oil may migrate.

Some one-way valves open when vacuum is applied and close under no vacuum condition. Such valves may restrict the ability of the pump to create a deep vacuum and are not recommended.




MANIFOLD GAUGE SET

PRECAUTIONS

< PRECAUTION >


Be certain that the gauge face indicates HFC-134a or R-134a. Be sure the gauge set has 1/2"-16 ACME threaded connections for service hoses. Confirm the set has been used only with refrigerant HFC-134a (R-134a) and specified lubricants.

[WITH 7 INCH DISPLAY]



SERVICE HOSES


Be certain that the service hoses display the markings described (colored hose with a black stripe). All hoses must equip positive shut-off devices (either manual or automatic) near the end of the hoses opposite to the manifold gauge.



SERVICE COUPLERS


Never attempt to connect HFC-134a (R-134a) service couplers to a CFC-12 (R-12) A/C system. The HFC-134a (R-134a) couplers do not properly connect to the CFC-12 (R-12) system. However, if an improper connection is attempted, discharge and contamination may occur.

Shut-off valve rotation	A/C service valve
Clockwise	Open
Counterclockwise	Close



REFRIGERANT WEIGHT SCALE

Verify that no refrigerant other than HFC-134a (R-134a) and specified lubricants have been used with the scale. The hose fitting must be 1/2"-16 ACME if the scale controls refrigerant flow electronically.



CHARGING CYLINDER

Use of a charging cylinder is not recommended. Refrigerant may be vented into the air from the top valve of the cylinder when filling the cylinder with refrigerant. Also, the accuracy of the cylinder is generally less than that of an electronic scale or of quality recycle/recharge equipment.

COMPRESSOR

General Precautions

INFOID:000000009722228

CAUTION:

- Plug all openings to prevent moisture and foreign matter from entering.
- Store it in the same way as it is when mounted on the car when the compressor is removed.
- Follow “Maintenance of Lubricant Quantity in Compressor” exactly when replacing or repairing the compressor. Refer to [HA-25, "Maintenance of Lubricant Quantity"](#).
- Keep friction surfaces between clutch and pulley clean. Wipe it off by using a clean waste cloth moistened with thinner if the surface is contaminated with lubricant.
- Turn the compressor shaft by hand more than five turns in both directions after compressor service operation. This equally distributes lubricant inside the compressor. Let the engine idle and operate the compressor for one hour after the compressor is installed.
- Apply voltage to the new compressor and check for normal operation after replacing the compressor magnet clutch.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

FLUORESCENT LEAK DETECTOR

< PRECAUTION >

[WITH 7 INCH DISPLAY]

FLUORESCENT LEAK DETECTOR

General Precautions

INFOID:000000009722229

CAUTION:

- The A/C system contains a fluorescent leak detection dye used for locating refrigerant leakages. An ultraviolet (UV) lamp is required to illuminate the dye when inspecting for leakages.
- Always wear fluorescence enhancing UV safety goggles to protect eyes and enhance the visibility of the fluorescent dye.
- The fluorescent dye leak detector is not a replacement for an electrical leak detector (SST: J-41995). The fluorescent dye leak detector should be used in conjunction with an electrical leak detector (SST: J-41995) to pin-point refrigerant leakages.
- Read and follow all manufacture operating instructions and precautions prior to performing the work for the purpose of safety and customer satisfaction.
- A compressor shaft seal should not necessarily be repaired because of dye seepage. The compressor shaft seal should only be repaired after confirming the leakage with an electrical leak detector (SST: J-41995).
- Always remove any remaining dye from the leakage area after repairs are completed to avoid a misdiagnosis during future service.
- Never allow dye to come into contact with painted body panels or interior components. Clean immediately with the approved dye cleaner if dye is spilled. Fluorescent dye left on a surface for an extended period of time cannot be removed.
- Never spray the fluorescent dye cleaning agent on hot surfaces (engine exhaust manifold, etc.).
- Never use more than one refrigerant dye bottle (1/4 ounce /7.4 cc) per A/C system.
- Leak detection dyes for HFC-134a (R-134a) and CFC-12 (R-12) A/C systems are different. Never use HFC-134a (R-134a) leak detection dye in CFC-12 (R-12) A/C system, or CFC-12 (R-12) leak detection dye in HFC-134a (R-134a) A/C system, or A/C system damage may result.
- The fluorescent properties of the dye remains for three or more years unless a compressor malfunction occurs.

IDENTIFICATION

NOTE:

Vehicles with factory installed fluorescent dye have a green label.

Vehicles without factory installed fluorescent dye have a blue label.

IDENTIFICATION LABEL FOR VEHICLE

Vehicles with factory installed fluorescent dye have an identification label on the front side of hood.