

SECTION LAN
LAN SYSTEM

A
B
C

CONTENTS

D
E

| | | |
|--|----|-----|
| CAN FUNDAMENTAL | | |
| HOW TO USE THIS MANUAL | 10 | |
| HOW TO USE THIS SECTION | 10 | |
| Information | 10 | |
| PRECAUTION | 11 | |
| PRECAUTIONS | 11 | |
| Precautions for Trouble Diagnosis | 11 | |
| Precautions for Harness Repair | 11 | |
| SYSTEM DESCRIPTION | 12 | |
| SYSTEM | 12 | |
| CAN COMMUNICATION SYSTEM | 12 | |
| CAN COMMUNICATION SYSTEM : System De- scription | 12 | |
| DIAG ON CAN | 12 | |
| DIAG ON CAN : System Description | 12 | |
| TROUBLE DIAGNOSIS | 14 | |
| Component Description | 14 | |
| Condition of Error Detection | 14 | |
| Symptom When Error Occurs in CAN Communi- cation System | 15 | |
| CAN Diagnosis with CONSULT | 17 | |
| Self-Diagnosis | 18 | |
| CAN Diagnostic Support Monitor | 18 | |
| How to Use CAN Communication Signal Chart | 20 | |
| BASIC INSPECTION | 21 | |
| DIAGNOSIS AND REPAIR WORKFLOW | 21 | |
| Trouble Diagnosis Flow Chart | 21 | |
| CAN | | |
| HOW TO USE THIS MANUAL | 26 | |
| HOW TO USE THIS SECTION | 26 | |
| Information | 26 | F |
| Abbreviation List | 26 | F |
| PRECAUTION | 27 | G |
| PRECAUTIONS | 27 | |
| Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER" | 27 | H |
| Precautions for Trouble Diagnosis | 27 | |
| Precautions for Harness Repair | 27 | I |
| SYSTEM DESCRIPTION | 29 | |
| COMPONENT PARTS | 29 | J |
| Component Parts Location | 29 | |
| SYSTEM | 30 | K |
| CAN COMMUNICATION SYSTEM | 30 | |
| CAN COMMUNICATION SYSTEM : System De- scription | 30 | L |
| CAN COMMUNICATION SYSTEM : CAN Com- munication Control Circuit | 35 | |
| CAN COMMUNICATION SYSTEM : CAN System Specification Chart | 35 | LAN |
| CAN COMMUNICATION SYSTEM : CAN Com- munication Signal Chart | 37 | |
| WIRING DIAGRAM | 42 | N |
| CAN SYSTEM (WITHOUT AROUND VIEW MONITOR SYSTEM) | 42 | O |
| Wiring Diagram | 42 | |
| CAN SYSTEM (WITH AROUND VIEW MONI- TOR SYSTEM) | 49 | P |
| Wiring Diagram | 49 | |
| BASIC INSPECTION | 62 | |
| DIAGNOSIS AND REPAIR WORKFLOW | 62 | |
| Interview Sheet | 62 | |

| | | | |
|--|----|--|-----|
| DTC/CIRCUIT DIAGNOSIS | 63 | Diagnosis Procedure | 81 |
| MALFUNCTION AREA CHART | 63 | CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2) | 82 |
| CAN Communication Circuit | 63 | Diagnosis Procedure | 82 |
| ITS Communication Circuit | 64 | HVAC BRANCH LINE CIRCUIT | 83 |
| MAIN LINE BETWEEN IPDM-E AND ABS CIRCUIT | 65 | Diagnosis Procedure | 83 |
| Diagnosis Procedure | 65 | PWBD BRANCH LINE CIRCUIT | 84 |
| MAIN LINE BETWEEN ABS AND HVAC CIRCUIT | 66 | Diagnosis Procedure | 84 |
| Diagnosis Procedure | 66 | 4WD BRANCH LINE CIRCUIT | 85 |
| MAIN LINE BETWEEN HVAC AND 4WD CIRCUIT | 67 | Diagnosis Procedure | 85 |
| Diagnosis Procedure | 67 | A-BAG BRANCH LINE CIRCUIT | 86 |
| MAIN LINE BETWEEN HVAC AND DLC CIRCUIT | 68 | Diagnosis Procedure | 86 |
| Diagnosis Procedure | 68 | DLC BRANCH LINE CIRCUIT | 87 |
| MAIN LINE BETWEEN 4WD AND DLC CIRCUIT | 70 | Diagnosis Procedure | 87 |
| Diagnosis Procedure | 70 | DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1) | 88 |
| MAIN LINE BETWEEN DLC AND ADP CIRCUIT | 71 | Diagnosis Procedure | 88 |
| Diagnosis Procedure | 71 | DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2) | 89 |
| MAIN LINE BETWEEN AVM AND RDR-R CIRCUIT | 72 | Diagnosis Procedure | 89 |
| Diagnosis Procedure | 72 | M&A BRANCH LINE CIRCUIT | 90 |
| MAIN LINE BETWEEN RDR-R AND RDR-L CIRCUIT | 73 | Diagnosis Procedure | 90 |
| Diagnosis Procedure | 73 | STRG BRANCH LINE CIRCUIT | 91 |
| MAIN LINE BETWEEN RDR-L AND LASER CIRCUIT | 74 | Diagnosis Procedure | 91 |
| Diagnosis Procedure | 74 | BCM BRANCH LINE CIRCUIT | 92 |
| ECM BRANCH LINE CIRCUIT | 75 | Diagnosis Procedure | 92 |
| Diagnosis Procedure | 75 | ICC BRANCH LINE CIRCUIT | 93 |
| IPDM-E BRANCH LINE CIRCUIT | 76 | Diagnosis Procedure | 93 |
| Diagnosis Procedure | 76 | ADP BRANCH LINE CIRCUIT | 94 |
| TCM BRANCH LINE CIRCUIT | 77 | Diagnosis Procedure | 94 |
| Diagnosis Procedure | 77 | AVM BRANCH LINE CIRCUIT | 95 |
| ABS BRANCH LINE CIRCUIT | 78 | Diagnosis Procedure | 95 |
| Diagnosis Procedure | 78 | RDR-R BRANCH LINE CIRCUIT | 96 |
| EPS/DAST 3 BRANCH LINE CIRCUIT | 79 | Diagnosis Procedure | 96 |
| Diagnosis Procedure | 79 | RDR-L BRANCH LINE CIRCUIT | 97 |
| AV BRANCH LINE CIRCUIT | 80 | Diagnosis Procedure | 97 |
| Diagnosis Procedure | 80 | LASER BRANCH LINE CIRCUIT | 98 |
| CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1) | 81 | Diagnosis Procedure | 98 |
| | | CAN COMMUNICATION CIRCUIT | 99 |
| | | Diagnosis Procedure | 99 |
| | | CAN COMMUNICATION CIRCUIT 1 | 101 |
| | | Diagnosis Procedure | 101 |
| | | CAN COMMUNICATION CIRCUIT 2 | 103 |

| | | | | |
|--|------------|---|------------|-----|
| Diagnosis Procedure | 103 | NOT CONFIGURED : Diagnosis Procedure | 119 | A |
| ITS COMMUNICATION CIRCUIT | 105 | POWER SUPPLY AND GROUND CIRCUIT .. | 121 | B |
| Diagnosis Procedure | 105 | Diagnosis Procedure | 121 | |
| CAN GATEWAY | | REMOVAL AND INSTALLATION | 122 | C |
| PRECAUTION | 107 | CAN GATEWAY | 122 | D |
| PRECAUTIONS | 107 | Removal and Installation | 122 | E |
| Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER" | 107 | CAN SYSTEM (TYPE 1) | | F |
| SYSTEM DESCRIPTION | 108 | DTC/CIRCUIT DIAGNOSIS | 123 | G |
| COMPONENT PARTS | 108 | MAIN LINE BETWEEN IPDM-E AND ABS CIRCUIT | 123 | H |
| Component Parts Location | 108 | Diagnosis Procedure | 123 | I |
| SYSTEM | 109 | MAIN LINE BETWEEN ABS AND HVAC CIR- CUIT | 124 | J |
| System Description | 109 | Diagnosis Procedure | 124 | K |
| DIAGNOSIS SYSTEM (CAN GATEWAY) | 110 | MAIN LINE BETWEEN HVAC AND DLC CIR- CUIT | 125 | L |
| CONSULT Function | 110 | Diagnosis Procedure | 125 | LAN |
| ECU DIAGNOSIS INFORMATION | 111 | ECM BRANCH LINE CIRCUIT | 127 | N |
| CAN GATEWAY | 111 | Diagnosis Procedure | 127 | O |
| Reference Value | 111 | IPDM-E BRANCH LINE CIRCUIT | 128 | P |
| DTC Inspection Priority Chart | 111 | Diagnosis Procedure | 128 | |
| DTC Index | 112 | TCM BRANCH LINE CIRCUIT | 129 | |
| WIRING DIAGRAM | 113 | Diagnosis Procedure | 129 | |
| CAN GATEWAY SYSTEM | 113 | ABS BRANCH LINE CIRCUIT | 130 | |
| Wiring Diagram | 113 | Diagnosis Procedure | 130 | |
| BASIC INSPECTION | 115 | EPS/DAST 3 BRANCH LINE CIRCUIT | 131 | |
| ADDITIONAL SERVICE WHEN REPLACING CAN GATEWAY | 115 | Diagnosis Procedure | 131 | |
| Description | 115 | HVAC BRANCH LINE CIRCUIT | 132 | |
| Work Procedure | 115 | Diagnosis Procedure | 132 | |
| CONFIGURATION (CAN GATEWAY) | 116 | A-BAG BRANCH LINE CIRCUIT | 133 | |
| Work Procedure | 116 | Diagnosis Procedure | 133 | |
| DTC/CIRCUIT DIAGNOSIS | 117 | DLC BRANCH LINE CIRCUIT | 134 | |
| U1000 CAN COMM CIRCUIT | 117 | Diagnosis Procedure | 134 | |
| DTC Description | 117 | M&A BRANCH LINE CIRCUIT | 135 | |
| Diagnosis Procedure | 117 | Diagnosis Procedure | 135 | |
| U1010 CONTROL UNIT (CAN) | 118 | STRG BRANCH LINE CIRCUIT | 136 | |
| DTC Description | 118 | Diagnosis Procedure | 136 | |
| Diagnosis Procedure | 118 | BCM BRANCH LINE CIRCUIT | 137 | |
| B2600 CONFIG ERROR | 119 | Diagnosis Procedure | 137 | |
| DTC Description | 119 | CAN COMMUNICATION CIRCUIT | 138 | |
| WRONG DATA | 119 | Diagnosis Procedure | 138 | |
| WRONG DATA : Diagnosis Procedure | 119 | CAN SYSTEM (TYPE 2) | | |
| NOT CONFIGURED | 119 | DTC/CIRCUIT DIAGNOSIS | 140 | |

| | | | |
|---|-----|---|-----|
| MAIN LINE BETWEEN IPDM-E AND ABS CIRCUIT | 140 | MAIN LINE BETWEEN HVAC AND DLC CIRCUIT | 160 |
| Diagnosis Procedure | 140 | Diagnosis Procedure | 160 |
| MAIN LINE BETWEEN ABS AND HVAC CIRCUIT | 141 | ECM BRANCH LINE CIRCUIT | 162 |
| Diagnosis Procedure | 141 | Diagnosis Procedure | 162 |
| MAIN LINE BETWEEN HVAC AND DLC CIRCUIT | 142 | IPDM-E BRANCH LINE CIRCUIT | 163 |
| Diagnosis Procedure | 142 | Diagnosis Procedure | 163 |
| ECM BRANCH LINE CIRCUIT | 144 | TCM BRANCH LINE CIRCUIT | 164 |
| Diagnosis Procedure | 144 | Diagnosis Procedure | 164 |
| IPDM-E BRANCH LINE CIRCUIT | 145 | ABS BRANCH LINE CIRCUIT | 165 |
| Diagnosis Procedure | 145 | Diagnosis Procedure | 165 |
| TCM BRANCH LINE CIRCUIT | 146 | EPS/DAST 3 BRANCH LINE CIRCUIT | 166 |
| Diagnosis Procedure | 146 | Diagnosis Procedure | 166 |
| ABS BRANCH LINE CIRCUIT | 147 | AV BRANCH LINE CIRCUIT | 167 |
| Diagnosis Procedure | 147 | Diagnosis Procedure | 167 |
| EPS/DAST 3 BRANCH LINE CIRCUIT | 148 | HVAC BRANCH LINE CIRCUIT | 168 |
| Diagnosis Procedure | 148 | Diagnosis Procedure | 168 |
| AV BRANCH LINE CIRCUIT | 149 | PWBD BRANCH LINE CIRCUIT | 169 |
| Diagnosis Procedure | 149 | Diagnosis Procedure | 169 |
| HVAC BRANCH LINE CIRCUIT | 150 | A-BAG BRANCH LINE CIRCUIT | 170 |
| Diagnosis Procedure | 150 | Diagnosis Procedure | 170 |
| A-BAG BRANCH LINE CIRCUIT | 151 | DLC BRANCH LINE CIRCUIT | 171 |
| Diagnosis Procedure | 151 | Diagnosis Procedure | 171 |
| DLC BRANCH LINE CIRCUIT | 152 | M&A BRANCH LINE CIRCUIT | 172 |
| Diagnosis Procedure | 152 | Diagnosis Procedure | 172 |
| M&A BRANCH LINE CIRCUIT | 153 | STRG BRANCH LINE CIRCUIT | 173 |
| Diagnosis Procedure | 153 | Diagnosis Procedure | 173 |
| STRG BRANCH LINE CIRCUIT | 154 | BCM BRANCH LINE CIRCUIT | 174 |
| Diagnosis Procedure | 154 | Diagnosis Procedure | 174 |
| BCM BRANCH LINE CIRCUIT | 155 | CAN COMMUNICATION CIRCUIT | 175 |
| Diagnosis Procedure | 155 | Diagnosis Procedure | 175 |
| CAN COMMUNICATION CIRCUIT | 156 | CAN SYSTEM (TYPE 4) | |
| Diagnosis Procedure | 156 | DTC/CIRCUIT DIAGNOSIS | 177 |
| CAN SYSTEM (TYPE 3) | | MAIN LINE BETWEEN IPDM-E AND ABS CIRCUIT | 177 |
| DTC/CIRCUIT DIAGNOSIS | 158 | Diagnosis Procedure | 177 |
| MAIN LINE BETWEEN IPDM-E AND ABS CIRCUIT | 158 | MAIN LINE BETWEEN ABS AND HVAC CIRCUIT | 178 |
| Diagnosis Procedure | 158 | Diagnosis Procedure | 178 |
| MAIN LINE BETWEEN ABS AND HVAC CIRCUIT | 159 | MAIN LINE BETWEEN HVAC AND DLC CIRCUIT | 179 |
| Diagnosis Procedure | 159 | Diagnosis Procedure | 179 |
| | | MAIN LINE BETWEEN DLC AND ADP CIRCUIT | 181 |

| | | | |
|--|------------|--|------------|
| Diagnosis Procedure | 181 | Diagnosis Procedure | 200 |
| MAIN LINE BETWEEN AVM AND RDR-R CIRCUIT | 182 | ADP BRANCH LINE CIRCUIT | 201 |
| Diagnosis Procedure | 182 | Diagnosis Procedure | 201 |
| MAIN LINE BETWEEN RDR-R AND RDR-L CIRCUIT | 183 | AVM BRANCH LINE CIRCUIT | 202 |
| Diagnosis Procedure | 183 | Diagnosis Procedure | 202 |
| ECM BRANCH LINE CIRCUIT | 184 | RDR-R BRANCH LINE CIRCUIT | 203 |
| Diagnosis Procedure | 184 | Diagnosis Procedure | 203 |
| IPDM-E BRANCH LINE CIRCUIT | 185 | RDR-L BRANCH LINE CIRCUIT | 204 |
| Diagnosis Procedure | 185 | Diagnosis Procedure | 204 |
| TCM BRANCH LINE CIRCUIT | 186 | CAN COMMUNICATION CIRCUIT 1 | 205 |
| Diagnosis Procedure | 186 | Diagnosis Procedure | 205 |
| ABS BRANCH LINE CIRCUIT | 187 | CAN COMMUNICATION CIRCUIT 2 | 207 |
| Diagnosis Procedure | 187 | Diagnosis Procedure | 207 |
| EPS/DAST 3 BRANCH LINE CIRCUIT | 188 | ITS COMMUNICATION CIRCUIT | 209 |
| Diagnosis Procedure | 188 | Diagnosis Procedure | 209 |
| AV BRANCH LINE CIRCUIT | 189 | CAN SYSTEM (TYPE 5) | |
| Diagnosis Procedure | 189 | DTC/CIRCUIT DIAGNOSIS | 211 |
| CGW BRANCH LINE CIRCUIT (CAN COM- MUNICATION CIRCUIT 1) | 190 | MAIN LINE BETWEEN IPDM-E AND ABS CIRCUIT | 211 |
| Diagnosis Procedure | 190 | Diagnosis Procedure | 211 |
| CGW BRANCH LINE CIRCUIT (CAN COM- MUNICATION CIRCUIT 2) | 191 | MAIN LINE BETWEEN ABS AND HVAC CIR- CUIT | 212 |
| Diagnosis Procedure | 191 | Diagnosis Procedure | 212 |
| HVAC BRANCH LINE CIRCUIT | 192 | MAIN LINE BETWEEN HVAC AND DLC CIR- CUIT | 213 |
| Diagnosis Procedure | 192 | Diagnosis Procedure | 213 |
| PWBD BRANCH LINE CIRCUIT | 193 | MAIN LINE BETWEEN DLC AND ADP CIR- CUIT | 215 |
| Diagnosis Procedure | 193 | Diagnosis Procedure | 215 |
| A-BAG BRANCH LINE CIRCUIT | 194 | MAIN LINE BETWEEN AVM AND RDR-R CIRCUIT | 216 |
| Diagnosis Procedure | 194 | Diagnosis Procedure | 216 |
| DLC BRANCH LINE CIRCUIT (CAN COMMU- NICATION CIRCUIT 1) | 195 | MAIN LINE BETWEEN RDR-R AND RDR-L CIRCUIT | 217 |
| Diagnosis Procedure | 195 | Diagnosis Procedure | 217 |
| DLC BRANCH LINE CIRCUIT (CAN COMMU- NICATION CIRCUIT 2) | 196 | MAIN LINE BETWEEN RDR-L AND LASER CIRCUIT | 218 |
| Diagnosis Procedure | 196 | Diagnosis Procedure | 218 |
| M&A BRANCH LINE CIRCUIT | 197 | ECM BRANCH LINE CIRCUIT | 219 |
| Diagnosis Procedure | 197 | Diagnosis Procedure | 219 |
| STRG BRANCH LINE CIRCUIT | 198 | IPDM-E BRANCH LINE CIRCUIT | 220 |
| Diagnosis Procedure | 198 | Diagnosis Procedure | 220 |
| BCM BRANCH LINE CIRCUIT | 199 | TCM BRANCH LINE CIRCUIT | 221 |
| Diagnosis Procedure | 199 | Diagnosis Procedure | 221 |
| ICC BRANCH LINE CIRCUIT | 200 | | |

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

| | | | |
|--|------------|---|------------|
| ABS BRANCH LINE CIRCUIT | 222 | CAN COMMUNICATION CIRCUIT 2 | 243 |
| Diagnosis Procedure | 222 | Diagnosis Procedure | 243 |
| EPS/DAST 3 BRANCH LINE CIRCUIT | 223 | ITS COMMUNICATION CIRCUIT | 245 |
| Diagnosis Procedure | 223 | Diagnosis Procedure | 245 |
| AV BRANCH LINE CIRCUIT | 224 | CAN SYSTEM (TYPE 6) | |
| Diagnosis Procedure | 224 | DTC/CIRCUIT DIAGNOSIS | 247 |
| CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1) | 225 | MAIN LINE BETWEEN IPDM-E AND ABS CIRCUIT | 247 |
| Diagnosis Procedure | 225 | Diagnosis Procedure | 247 |
| CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2) | 226 | MAIN LINE BETWEEN ABS AND HVAC CIRCUIT | 248 |
| Diagnosis Procedure | 226 | Diagnosis Procedure | 248 |
| HVAC BRANCH LINE CIRCUIT | 227 | MAIN LINE BETWEEN HVAC AND 4WD CIRCUIT | 249 |
| Diagnosis Procedure | 227 | Diagnosis Procedure | 249 |
| PWBD BRANCH LINE CIRCUIT | 228 | MAIN LINE BETWEEN 4WD AND DLC CIRCUIT | 250 |
| Diagnosis Procedure | 228 | Diagnosis Procedure | 250 |
| A-BAG BRANCH LINE CIRCUIT | 229 | ECM BRANCH LINE CIRCUIT | 251 |
| Diagnosis Procedure | 229 | Diagnosis Procedure | 251 |
| DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1) | 230 | IPDM-E BRANCH LINE CIRCUIT | 252 |
| Diagnosis Procedure | 230 | Diagnosis Procedure | 252 |
| DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2) | 231 | TCM BRANCH LINE CIRCUIT | 253 |
| Diagnosis Procedure | 231 | Diagnosis Procedure | 253 |
| M&A BRANCH LINE CIRCUIT | 232 | ABS BRANCH LINE CIRCUIT | 254 |
| Diagnosis Procedure | 232 | Diagnosis Procedure | 254 |
| STRG BRANCH LINE CIRCUIT | 233 | EPS/DAST 3 BRANCH LINE CIRCUIT | 255 |
| Diagnosis Procedure | 233 | Diagnosis Procedure | 255 |
| BCM BRANCH LINE CIRCUIT | 234 | HVAC BRANCH LINE CIRCUIT | 256 |
| Diagnosis Procedure | 234 | Diagnosis Procedure | 256 |
| ICC BRANCH LINE CIRCUIT | 235 | 4WD BRANCH LINE CIRCUIT | 257 |
| Diagnosis Procedure | 235 | Diagnosis Procedure | 257 |
| ADP BRANCH LINE CIRCUIT | 236 | A-BAG BRANCH LINE CIRCUIT | 258 |
| Diagnosis Procedure | 236 | Diagnosis Procedure | 258 |
| AVM BRANCH LINE CIRCUIT | 237 | DLC BRANCH LINE CIRCUIT | 259 |
| Diagnosis Procedure | 237 | Diagnosis Procedure | 259 |
| RDR-R BRANCH LINE CIRCUIT | 238 | M&A BRANCH LINE CIRCUIT | 260 |
| Diagnosis Procedure | 238 | Diagnosis Procedure | 260 |
| RDR-L BRANCH LINE CIRCUIT | 239 | STRG BRANCH LINE CIRCUIT | 261 |
| Diagnosis Procedure | 239 | Diagnosis Procedure | 261 |
| LASER BRANCH LINE CIRCUIT | 240 | BCM BRANCH LINE CIRCUIT | 262 |
| Diagnosis Procedure | 240 | Diagnosis Procedure | 262 |
| CAN COMMUNICATION CIRCUIT 1 | 241 | CAN COMMUNICATION CIRCUIT | 263 |
| Diagnosis Procedure | 241 | Diagnosis Procedure | 263 |

CAN SYSTEM (TYPE 7)

| | |
|---|-----|
| DTC/CIRCUIT DIAGNOSIS | 265 |
| MAIN LINE BETWEEN IPDM-E AND ABS CIRCUIT | 265 |
| Diagnosis Procedure | 265 |
| MAIN LINE BETWEEN ABS AND HVAC CIRCUIT | 266 |
| Diagnosis Procedure | 266 |
| MAIN LINE BETWEEN HVAC AND 4WD CIRCUIT | 267 |
| Diagnosis Procedure | 267 |
| MAIN LINE BETWEEN 4WD AND DLC CIRCUIT | 268 |
| Diagnosis Procedure | 268 |
| ECM BRANCH LINE CIRCUIT | 269 |
| Diagnosis Procedure | 269 |
| IPDM-E BRANCH LINE CIRCUIT | 270 |
| Diagnosis Procedure | 270 |
| TCM BRANCH LINE CIRCUIT | 271 |
| Diagnosis Procedure | 271 |
| ABS BRANCH LINE CIRCUIT | 272 |
| Diagnosis Procedure | 272 |
| EPS/DAST 3 BRANCH LINE CIRCUIT | 273 |
| Diagnosis Procedure | 273 |
| AV BRANCH LINE CIRCUIT | 274 |
| Diagnosis Procedure | 274 |
| HVAC BRANCH LINE CIRCUIT | 275 |
| Diagnosis Procedure | 275 |
| 4WD BRANCH LINE CIRCUIT | 276 |
| Diagnosis Procedure | 276 |
| A-BAG BRANCH LINE CIRCUIT | 277 |
| Diagnosis Procedure | 277 |
| DLC BRANCH LINE CIRCUIT | 278 |
| Diagnosis Procedure | 278 |
| M&A BRANCH LINE CIRCUIT | 279 |
| Diagnosis Procedure | 279 |
| STRG BRANCH LINE CIRCUIT | 280 |
| Diagnosis Procedure | 280 |
| BCM BRANCH LINE CIRCUIT | 281 |
| Diagnosis Procedure | 281 |
| CAN COMMUNICATION CIRCUIT | 282 |
| Diagnosis Procedure | 282 |

CAN SYSTEM (TYPE 8)

| | |
|---|-----|
| DTC/CIRCUIT DIAGNOSIS | 284 |
| MAIN LINE BETWEEN IPDM-E AND ABS CIRCUIT | 284 |
| Diagnosis Procedure | 284 |
| MAIN LINE BETWEEN ABS AND HVAC CIRCUIT | 285 |
| Diagnosis Procedure | 285 |
| MAIN LINE BETWEEN HVAC AND 4WD CIRCUIT | 286 |
| Diagnosis Procedure | 286 |
| MAIN LINE BETWEEN 4WD AND DLC CIRCUIT | 287 |
| Diagnosis Procedure | 287 |
| ECM BRANCH LINE CIRCUIT | 288 |
| Diagnosis Procedure | 288 |
| IPDM-E BRANCH LINE CIRCUIT | 289 |
| Diagnosis Procedure | 289 |
| TCM BRANCH LINE CIRCUIT | 290 |
| Diagnosis Procedure | 290 |
| ABS BRANCH LINE CIRCUIT | 291 |
| Diagnosis Procedure | 291 |
| EPS/DAST 3 BRANCH LINE CIRCUIT | 292 |
| Diagnosis Procedure | 292 |
| AV BRANCH LINE CIRCUIT | 293 |
| Diagnosis Procedure | 293 |
| HVAC BRANCH LINE CIRCUIT | 294 |
| Diagnosis Procedure | 294 |
| PWBD BRANCH LINE CIRCUIT | 295 |
| Diagnosis Procedure | 295 |
| 4WD BRANCH LINE CIRCUIT | 296 |
| Diagnosis Procedure | 296 |
| A-BAG BRANCH LINE CIRCUIT | 297 |
| Diagnosis Procedure | 297 |
| DLC BRANCH LINE CIRCUIT | 298 |
| Diagnosis Procedure | 298 |
| M&A BRANCH LINE CIRCUIT | 299 |
| Diagnosis Procedure | 299 |
| STRG BRANCH LINE CIRCUIT | 300 |
| Diagnosis Procedure | 300 |
| BCM BRANCH LINE CIRCUIT | 301 |
| Diagnosis Procedure | 301 |
| CAN COMMUNICATION CIRCUIT | 302 |
| Diagnosis Procedure | 302 |

CAN SYSTEM (TYPE 9)

A

B

C

D

E

F

G

H

I

J

K

L

LAN

N

O

P

| | | | |
|--|-----|--|-----|
| DTC/CIRCUIT DIAGNOSIS | 304 | 4WD BRANCH LINE CIRCUIT | 321 |
| | | Diagnosis Procedure | 321 |
| MAIN LINE BETWEEN IPDM-E AND ABS CIRCUIT | 304 | A-BAG BRANCH LINE CIRCUIT | 322 |
| Diagnosis Procedure | 304 | Diagnosis Procedure | 322 |
| MAIN LINE BETWEEN ABS AND HVAC CIRCUIT | 305 | DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1) | 323 |
| Diagnosis Procedure | 305 | Diagnosis Procedure | 323 |
| MAIN LINE BETWEEN HVAC AND 4WD CIRCUIT | 306 | DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2) | 324 |
| Diagnosis Procedure | 306 | Diagnosis Procedure | 324 |
| MAIN LINE BETWEEN 4WD AND DLC CIRCUIT | 307 | M&A BRANCH LINE CIRCUIT | 325 |
| Diagnosis Procedure | 307 | Diagnosis Procedure | 325 |
| MAIN LINE BETWEEN DLC AND ADP CIRCUIT | 308 | STRG BRANCH LINE CIRCUIT | 326 |
| Diagnosis Procedure | 308 | Diagnosis Procedure | 326 |
| MAIN LINE BETWEEN AVM AND RDR-R CIRCUIT | 309 | BCM BRANCH LINE CIRCUIT | 327 |
| Diagnosis Procedure | 309 | Diagnosis Procedure | 327 |
| MAIN LINE BETWEEN RDR-R AND RDR-L CIRCUIT | 310 | ICC BRANCH LINE CIRCUIT | 328 |
| Diagnosis Procedure | 310 | Diagnosis Procedure | 328 |
| ECM BRANCH LINE CIRCUIT | 311 | ADP BRANCH LINE CIRCUIT | 329 |
| Diagnosis Procedure | 311 | Diagnosis Procedure | 329 |
| IPDM-E BRANCH LINE CIRCUIT | 312 | AVM BRANCH LINE CIRCUIT | 330 |
| Diagnosis Procedure | 312 | Diagnosis Procedure | 330 |
| TCM BRANCH LINE CIRCUIT | 313 | RDR-R BRANCH LINE CIRCUIT | 331 |
| Diagnosis Procedure | 313 | Diagnosis Procedure | 331 |
| ABS BRANCH LINE CIRCUIT | 314 | RDR-L BRANCH LINE CIRCUIT | 332 |
| Diagnosis Procedure | 314 | Diagnosis Procedure | 332 |
| EPS/DAST 3 BRANCH LINE CIRCUIT | 315 | CAN COMMUNICATION CIRCUIT 1 | 333 |
| Diagnosis Procedure | 315 | Diagnosis Procedure | 333 |
| AV BRANCH LINE CIRCUIT | 316 | CAN COMMUNICATION CIRCUIT 2 | 335 |
| Diagnosis Procedure | 316 | Diagnosis Procedure | 335 |
| CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1) | 317 | ITS COMMUNICATION CIRCUIT | 337 |
| Diagnosis Procedure | 317 | Diagnosis Procedure | 337 |
| CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2) | 318 | CAN SYSTEM (TYPE 10) | |
| Diagnosis Procedure | 318 | DTC/CIRCUIT DIAGNOSIS | 339 |
| HVAC BRANCH LINE CIRCUIT | 319 | MAIN LINE BETWEEN IPDM-E AND ABS CIRCUIT | 339 |
| Diagnosis Procedure | 319 | Diagnosis Procedure | 339 |
| PWBD BRANCH LINE CIRCUIT | 320 | MAIN LINE BETWEEN ABS AND HVAC CIRCUIT | 340 |
| Diagnosis Procedure | 320 | Diagnosis Procedure | 340 |
| | | MAIN LINE BETWEEN HVAC AND 4WD CIRCUIT | 341 |
| | | Diagnosis Procedure | 341 |

| | | | | |
|--|------------|--|------------|-----|
| MAIN LINE BETWEEN 4WD AND DLC CIRCUIT | 342 | Diagnosis Procedure | 356 | |
| Diagnosis Procedure | 342 | 4WD BRANCH LINE CIRCUIT | 357 | A |
| MAIN LINE BETWEEN DLC AND ADP CIRCUIT | 343 | Diagnosis Procedure | 357 | |
| Diagnosis Procedure | 343 | A-BAG BRANCH LINE CIRCUIT | 358 | B |
| MAIN LINE BETWEEN AVM AND RDR-R CIRCUIT | 344 | Diagnosis Procedure | 358 | |
| Diagnosis Procedure | 344 | DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1) | 359 | C |
| MAIN LINE BETWEEN RDR-R AND RDR-L CIRCUIT | 345 | Diagnosis Procedure | 359 | |
| Diagnosis Procedure | 345 | DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2) | 360 | D |
| MAIN LINE BETWEEN RDR-L AND LASER CIRCUIT | 346 | Diagnosis Procedure | 360 | |
| Diagnosis Procedure | 346 | M&A BRANCH LINE CIRCUIT | 361 | E |
| ECM BRANCH LINE CIRCUIT | 347 | Diagnosis Procedure | 361 | |
| Diagnosis Procedure | 347 | STRG BRANCH LINE CIRCUIT | 362 | F |
| IPDM-E BRANCH LINE CIRCUIT | 348 | Diagnosis Procedure | 362 | |
| Diagnosis Procedure | 348 | BCM BRANCH LINE CIRCUIT | 363 | G |
| TCM BRANCH LINE CIRCUIT | 349 | Diagnosis Procedure | 363 | |
| Diagnosis Procedure | 349 | ICC BRANCH LINE CIRCUIT | 364 | H |
| ABS BRANCH LINE CIRCUIT | 350 | Diagnosis Procedure | 364 | |
| Diagnosis Procedure | 350 | ADP BRANCH LINE CIRCUIT | 365 | I |
| EPS/DAST 3 BRANCH LINE CIRCUIT | 351 | Diagnosis Procedure | 365 | |
| Diagnosis Procedure | 351 | AVM BRANCH LINE CIRCUIT | 366 | J |
| AV BRANCH LINE CIRCUIT | 352 | Diagnosis Procedure | 366 | |
| Diagnosis Procedure | 352 | RDR-R BRANCH LINE CIRCUIT | 367 | K |
| CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1) | 353 | Diagnosis Procedure | 367 | |
| Diagnosis Procedure | 353 | RDR-L BRANCH LINE CIRCUIT | 368 | L |
| CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2) | 354 | Diagnosis Procedure | 368 | |
| Diagnosis Procedure | 354 | LASER BRANCH LINE CIRCUIT | 369 | |
| HVAC BRANCH LINE CIRCUIT | 355 | Diagnosis Procedure | 369 | |
| Diagnosis Procedure | 355 | CAN COMMUNICATION CIRCUIT 1 | 370 | LAN |
| PWBD BRANCH LINE CIRCUIT | 356 | Diagnosis Procedure | 370 | |
| | | CAN COMMUNICATION CIRCUIT 2 | 372 | N |
| | | Diagnosis Procedure | 372 | |
| | | ITS COMMUNICATION CIRCUIT | 374 | O |
| | | Diagnosis Procedure | 374 | P |

HOW TO USE THIS MANUAL

HOW TO USE THIS SECTION

Information

INFOID:000000011216997

- “CAN FUNDAMENTAL” of LAN Section describes the basic knowledge of the CAN communication system and the method of trouble diagnosis.
- For information peculiar to a vehicle and inspection procedure, refer to “CAN”.

PRECAUTION

PRECAUTIONS

Precautions for Trouble Diagnosis

INFOID:000000011216998

CAUTION:

Follow the instructions listed below. Failure to do this may cause damage to parts:

- Never apply 7.0 V or more to the measurement terminal.
- Use a tester with open terminal voltage of 7.0 V or less.
- Turn the ignition switch OFF and disconnect the battery cable from the negative terminal when checking the harness.


Precautions for Harness Repair

INFOID:000000011216999

- Solder the repaired area and wrap tape around the soldered area.

NOTE:


A fray of twisted lines must be within 110 mm (4.33 in).



- Bypass connection is never allowed at the repaired area.

NOTE:

Bypass connection may cause CAN communication error. The spliced wire becomes separated and the characteristics of twisted line are lost.



- Replace the applicable harness as an assembly if error is detected on the shield lines of CAN communication line.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

SYSTEM DESCRIPTION

SYSTEM

CAN COMMUNICATION SYSTEM

CAN COMMUNICATION SYSTEM : System Description

INFOID:000000011217000


CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

DIAG ON CAN

DIAG ON CAN : System Description

INFOID:000000011217001

SYSTEM DIAGRAM



SYSTEM

< SYSTEM DESCRIPTION >

[CAN FUNDAMENTAL]

| Name | Harness | Description |
|-------------|----------------|---|
| DDL1 | Tx Rx | For communications with the diagnostic tool. (CAN-H and CAN-L are used for controlling) |
| DDL2 | K-LINE | For communications with the diagnostic tool. (CAN-H and CAN-L are used for controlling) |
| Diag on CAN | CAN-H CAN-L | For communications with the diagnostic tool. (CAN-H and CAN-L are also used for control and diagnoses.) |

DESCRIPTION

“Diag on CAN” is a diagnosis method which uses the CAN communication line for the communication between the control unit and the diagnostic tool.

A
B
C
D
E
F
G
H
I
J
K
L


LAN

N
O
P

TROUBLE DIAGNOSIS

Component Description

INFOID:000000011217002



| Component | Description |
|---------------------|---|
| Main line | CAN communication line between splices |
| Branch line | CAN communication line between splice and a control unit |
| Splice | A point connecting a branch line with a main line |
| Termination circuit | Circuit connected across the CAN communication system. (Resistor) |

Condition of Error Detection

INFOID:000000011217003

DTC (e.g. U1000 and U1001) of CAN communication is indicated on SELF-DIAG RESULTS on CONSULT if a CAN communication signal is not transmitted or received between units for 2 seconds or more.

CAN COMMUNICATION SYSTEM ERROR

- CAN communication line open (CAN-H, CAN-L, or both)
- CAN communication line short (ground, between CAN communication lines, other harnesses)
- Error of CAN communication control circuit of the unit connected to CAN communication line

WHEN DTC OF CAN COMMUNICATION IS INDICATED EVEN THOUGH CAN COMMUNICATION SYSTEM IS NORMAL

- Removal/installation of parts: Error may be detected when removing and installing CAN communication unit and related parts while turning the ignition switch ON. (A DTC except for CAN communication may be detected.)
- Fuse blown out (removed): CAN communication of the unit may cease.
- Voltage drop: Error may be detected if voltage drops due to discharged battery when turning the ignition switch ON (Depending on the control unit which carries out CAN communication).
- Error may be detected if the power supply circuit of the control unit, which carries out CAN communication, malfunctions (Depending on the control unit which carries out CAN communication).
- Error may be detected if reprogramming is not completed normally.

NOTE:

CAN communication system is normal if DTC of CAN communication is indicated on SELF-DIAG RESULTS of CONSULT under the above conditions. Erase the memory of the self-diagnosis of each control unit.

TROUBLE DIAGNOSIS

< SYSTEM DESCRIPTION >

[CAN FUNDAMENTAL]

Symptom When Error Occurs in CAN Communication System

INFOID:000000011217004


In CAN communication system, multiple control units mutually transmit and receive signals. Each control unit cannot transmit and receive signals if any error occurs on CAN communication line. Under this condition, multiple control units related to the root cause malfunction or go into fail-safe mode.

ERROR EXAMPLE

NOTE:

Each vehicle differs in symptom of each control unit under fail-safe mode and CAN communication line wiring.

Example: Main Line Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Open Circuit



| Unit name | Major symptom |
|---|--|
| ECM | Engine torque limiting is affected, and shift harshness increases. |
| BCM | <ul style="list-style-type: none"> • Reverse warning buzzer does not sound. • The front wiper moves under continuous operation mode even though the front wiper switch being in the intermittent position. |
| EPS control unit | The steering effort increases. |
| Combination meter | <ul style="list-style-type: none"> • The shift position indicator and OD OFF indicator turn OFF. • The speedometer is inoperative. • The odo/trip meter stops. |
| ABS actuator and electric unit (control unit) | Normal operation. |
| TCM | No impact on operation. |
| IPDM E/R | When the ignition switch is ON, <ul style="list-style-type: none"> • The headlamps (Lo) turn ON. • The cooling fan continues to rotate. |

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P


LAN

TROUBLE DIAGNOSIS

[CAN FUNDAMENTAL]

< SYSTEM DESCRIPTION >

Example: TCM Branch Line Open Circuit




| Unit name | Major symptom |
|---|--|
| ECM | Engine torque limiting is affected, and shift harshness increases. |
| BCM | Reverse warning buzzer does not sound. |
| EPS control unit | Normal operation. |
| Combination meter | <ul style="list-style-type: none"> Shift position indicator and O/D OFF indicator turn OFF. Warning lamps turn ON. |
| ABS actuator and electric unit (control unit) | Normal operation. |
| TCM | No impact on operation. |
| IPDM E/R | Normal operation. |

NOTE:

The model (all control units on CAN communication system are Diag on CAN) cannot perform CAN diagnosis with CONSULT if the following error occurs. The error is judged by the symptom.

| Error | Difference of symptom |
|--|--|
| Data link connector branch line open circuit | Normal operation. |
| CAN-H, CAN-L harness short-circuit | Most of the control units which are connected to the CAN communication system enter fail-safe mode or are deactivated. |

Example: Data Link Connector Branch Line Open Circuit



TROUBLE DIAGNOSIS

< SYSTEM DESCRIPTION >


[CAN FUNDAMENTAL]

| Unit name | Major symptom |
|---|-------------------|
| ECM | Normal operation. |
| BCM | |
| EPS control unit | |
| Combination meter | |
| ABS actuator and electric unit (control unit) | |
| TCM | |
| IPDM E/R | |

NOTE:

When data link connector branch line is open, transmission and reception of CAN communication signals are not affected. Therefore, no symptoms occur. However, be sure to repair malfunctioning circuit.

Example: CAN-H, CAN-L Harness Short Circuit



| Unit name | Major symptom |
|---|--|
| ECM | <ul style="list-style-type: none"> • Engine torque limiting is affected, and shift harshness increases. • Engine speed drops. |
| BCM | <ul style="list-style-type: none"> • Reverse warning buzzer does not sound. • The front wiper moves under continuous operation mode even though the front wiper switch being in the intermittent position. • The room lamp does not turn ON. • The engine does not start (if an error or malfunction occurs while turning the ignition switch OFF.) • The steering lock does not release (if an error or malfunction occurs while turning the ignition switch OFF.) |
| EPS control unit | The steering effort increases. |
| Combination meter | <ul style="list-style-type: none"> • The tachometer and the speedometer do not move. • Warning lamps turn ON. • Indicator lamps do not turn ON. |
| ABS actuator and electric unit (control unit) | Normal operation. |
| TCM | No impact on operation. |
| IPDM E/R | When the ignition switch is ON, <ul style="list-style-type: none"> • The headlamps (Lo) turn ON. • The cooling fan continues to rotate. |

CAN Diagnosis with CONSULT

INFOID:0000000011217005

CAN diagnosis on CONSULT extracts the root cause by receiving the following information.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

TROUBLE DIAGNOSIS

[CAN FUNDAMENTAL]

< SYSTEM DESCRIPTION >

- Response to the system call
- Control unit diagnosis information
- Self-diagnosis
- CAN diagnostic support monitor

Self-Diagnosis

INFOID:000000011217006

If communication signals cannot be transmitted or received among control units communicating via CAN communication line, CAN communication-related DTC is displayed on the CONSULT "Self Diagnostic Result" screen.

NOTE:

The following table shows examples of CAN communication-related DTC. For other DTC, refer to the applicable sections.

| DTC | Self-diagnosis item (CONSULT indication) | DTC detection condition | | Inspection/Action |
|-------|--|---|---|--|
| U1000 | CAN COMM CIRCUIT | ECM | When ECM is not transmitting or receiving CAN communication signal of OBD (emission-related diagnosis) for 2 seconds or more. | Start the inspection. Refer to the applicable section of the indicated control unit. |
| | | Except for ECM | When a control unit (except for ECM) is not transmitting or receiving CAN communication signal for 2 seconds or more. | |
| U1001 | CAN COMM CIRCUIT | When ECM is not transmitting or receiving CAN communication signal other than OBD (emission-related diagnosis) for 2 seconds or more. | | |
| U1002 | SYSTEM COMM | When a control unit is not transmitting or receiving CAN communication signal for 2 seconds or less. | | |
| U1010 | CONTROL UNIT(CAN) | When an error is detected during the initial diagnosis for CAN controller of each control unit. | | |

CAN Diagnostic Support Monitor

INFOID:000000011217007

MONITOR ITEM (CONSULT)

Example: CAN DIAG SUPPORT MNTR indication

| Without PAST | | | | With PAST | | | |
|---------------|---------|------|--|---------------|---------------|------|--|
| BCM | | | | ENGINE | | | |
| MONITOR ITEM | PRESENT | PAST | | MONITOR ITEM | PRESENT | PAST | |
| INITIAL DIAG | OK | - | | TRANSMIT DIAG | OK | OK | |
| TRANSMIT DIAG | OK | - | | VDC/TCS/ABS | OK | 5 | |
| ECM | OK | - | | METER/M&A | Not diagnosed | - | |
| METER/M&A | OK | - | | BCM/SEC | OK | OK | |
| TCM | OK | - | | ICC | Not diagnosed | - | |
| IPDM E/R | OK | - | | HVAC | Not diagnosed | - | |
| I-KEY | OK | - | | TCM | OK | OK | |
| | | | | EPS | OK | OK | |
| | | | | IPDM E/R | OK | 5 | |
| | | | | e4WD | Not diagnosed | - | |
| | | | | AWD/4WD | Not diagnosed | - | |

JSMIA0964GB

Without PAST

| Item | PRESENT | Description |
|-------------------|---------|--|
| Initial diagnosis | OK | Normal at present |
| | NG | Control unit error (Except for some control units) |

TROUBLE DIAGNOSIS

< SYSTEM DESCRIPTION >

[CAN FUNDAMENTAL]

| Item | PRESENT | Description |
|--|---------|---|
| Transmission diagnosis | OK | Normal at present |
| | UNKWN | Unable to transmit signals for 2 seconds or more. |
| | | Diagnosis not performed |
| Control unit name (Reception diagnosis) | OK | Normal at present |
| | UNKWN | Unable to receive signals for 2 seconds or more. |
| | | Diagnosis not performed |
| | | No control unit for receiving signals. (No applicable optional parts) |

With PAST

| Item | PRESENT | PAST | Description |
|---|---------------|--------|--|
| Transmission diagnosis | OK | OK | Normal at present and in the past |
| | | 1 – 39 | Normal at present, but unable to transmit signals for 2 seconds or more in the past. (The number indicates the number of ignition switch cycles from OFF to ON.) |
| | UNKWN | 0 | Unable to transmit signals for 2 seconds or more at present. |
| Control unit name (Reception diagnosis) | OK | OK | Normal at present and in the past |
| | | 1 – 39 | Normal at present, but unable to receive signals for 2 seconds or more in the past. (The number indicates the number of ignition switch cycles from OFF to ON.) |
| | UNKWN | 0 | Unable to receive signals for 2 seconds or more at present. |
| | Not diagnosed | - | Diagnosis not performed. |
| No control unit for receiving signals. (No applicable optional parts) | | | |

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

TROUBLE DIAGNOSIS

< SYSTEM DESCRIPTION >

[CAN FUNDAMENTAL]

How to Use CAN Communication Signal Chart


INFOID:000000011217008

The CAN communication signal chart lists the signals transmitted/received among control units. It is useful for detecting the root cause by finding a signal related to the symptom, and by checking transmission and reception unit.


Example: Tachometer does not move even though the engine rotates.

T: Transmit R: Receive

| Signal name/Connecting unit | ECM | BCM | M&A | STRG | ABS | IPDM-E |
|------------------------------------|-----|-----|-----|------|-----|--------|
| A/C compressor feedback signal | T | | R | | | |
| A/C compressor request signal | T | | | | | R |
| Accelerator pedal position signal | T | | | | R | |
| Cooling fan motor operation signal | T | | | | | R |
| Engine coolant temperature signal | T | | R | | | |
| Engine speed signal | T | | R | | R | |
| Fuel consumption monitor signal | T | | R | | | |
| Malfunction indicator lamp signal | T | | R | | | |
| A/C switch signal | R | T | | | | |
| Ignition switch signal | | T | | | | R |
| Sleep/wake up signal | | T | R | | | R |



No communication between ECM and M&A (Combination meter).



It indicates that an error occurs between ECM and Combination meter (Shaded area).

JSMIA0446GB


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Trouble Diagnosis Flow Chart

INFOID:0000000011217009

DESCRIPTION



DETAIL OF TROUBLE DIAGNOSIS FLOW CHART

1. INTERVIEW WITH CUSTOMER

Interview with the customer is important to detect the root cause of CAN communication system errors and to understand vehicle condition and symptoms for proper trouble diagnosis.

Points in interview

- What: Parts name, system name
- When: Date, Frequency
- Where: Road condition, Place
- In what condition: Driving condition/environment
- Result: Symptom

Notes for checking error symptoms:

- Check normal units as well as error symptoms.
- Example: Circuit between ECM and the combination meter is judged normal if the customer indicates tachometer functions normally.

A
B
C
D
E
F
G
H
I
J
K
L

LAN


N
O
P

DIAGNOSIS AND REPAIR WORKFLOW

[CAN FUNDAMENTAL]

< BASIC INSPECTION >

- When a CAN communication system error is present, multiple control units may malfunction or go into fail-safe mode.
- Indication of the combination meter is important to detect the root cause because it is the most obvious to the customer, and it performs CAN communication with many units.



>> GO TO 2.

2. INSPECTION OF VEHICLE CONDITION

Check whether the symptom is reproduced or not.

NOTE:

Do not turn the ignition switch OFF or disconnect the 12V battery cable while reproducing the error. The error may temporarily correct itself, making it difficult to determine the root cause.

>> GO TO 3.

3. CHECK OF CAN SYSTEM TYPE (HOW TO USE CAN SYSTEM TYPE SPECIFICATION CHART)

Determine CAN system type based on vehicle equipment.

NOTE:

- This chart is used if CONSULT does not automatically recognize CAN system type.
- There are two styles for CAN system type specification charts. Depending on the number of available system types, either style A or style B may be used.
- CAN System Type Specification Chart (Style A)

NOTE:

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[CAN FUNDAMENTAL]

CAN system type is easily checked with the vehicle equipment identification information shown in the chart.

Example:
Vehicle is equipped as follows: Wagon, AWD, VQ35DE, CVT, VDC, and Intelligent Key system. (○ shows an example of CAN system type.)

CAN System Specification Chart
Determine CAN system type from the following specification chart.

| | | | | | | |
|---|--------|---|--------|-----|---|---|
| Body type | Wagon | | | | | |
| Axle | 2WD | | | AWD | | |
| Engine | QR25DE | | VQ35DE | | | |
| Transmission | A/T | | CVT | | | |
| Brake control | ABS | | | VDC | | |
| Intelligent Key system | | × | | × | | × |
| CAN system type | 1 | 2 | 3 | 4 | 5 | 6 |
| CAN communication control unit | | | | | | |
| ECM | × | × | × | × | × | × |
| AWD control unit | | | | | × | × |
| Air bag diagnosis sensor unit | × | × | × | × | × | × |
| BCM | × | × | × | × | × | × |
| Intelligent Key unit | | × | | × | | × |
| Steering angle sensor | | | | | × | × |
| EPS control unit | × | × | × | × | × | × |
| Combination meter | × | × | × | × | × | × |
| ABS actuator and electric unit (control unit) | × | × | × | × | × | × |
| TCM | × | × | × | × | × | × |
| IPDM E/R | × | × | × | × | × | × |

× : Applicable

VEHICLE EQUIPMENT IDENTIFICATION INFORMATION
NOTE:
Check CAN system type from the vehicle shape and equipment.

A

B

1. VDC OFF switch
A. With VDC

2. Ignition knob
B. With Intelligent Key system

For the above case, CAN system type is "6".

JSMIA0529GB

Check the vehicle equipment with the vehicle identification number plate.

Check the vehicle equipment.

The number indicates the CAN system type of the vehicle.

In the above example,

- Checking VDC OFF switch leads to judge whether or not VDC is equipped.
- Checking the ignition knob leads to judge whether or not Intelligent Key system is equipped.

• CAN System Type Specification Chart (Style B)

NOTE:

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[CAN FUNDAMENTAL]

CAN system type is easily checked with the vehicle equipment identification information shown in the chart.

Example:
Vehicle is equipped as follows: Sedan, 2WD, MR20DE, CVT, ABS, Active AFS, Intelligent Key system, Navigation system and Automatic drive positioner. (○ shows an example of CAN system type.)

CAN System Specification Chart
Refer to the specification as shown in the chart.

| | | | |
|---------------------|---------------------------------|---------------------------------|---------------------------------|
| Body type | Sedan | | |
| Axle | 2WD | | AWD |
| Engine | HR15DE | MR20DE | HR15DE |
| Transmission | A/T | CVT | A/T |
| Brake control | ABS | | |
| Specification chart | XX.XX... SPECIFICATION CHART A. | XX.XX... SPECIFICATION CHART B. | XX.XX... SPECIFICATION CHART C. |

×: Applicable

Check the vehicle equipment with the vehicle identification number plate.
Check the vehicle equipment.
Select the applicable vehicle equipment. Refer to the specification chart.

SPECIFICATION CHART B
Determine CAN system type from the following specification chart.

| | | | | | | | | | | | | |
|--------------------------------|--------|----|----|----|----|----|----|----|----|----|----|----|
| Body type | Sedan | | | | | | | | | | | |
| Axle | 2WD | | | | | | | | | | | |
| Engine | MR20DE | | | | | | | | | | | |
| Transmission | CVT | | | | | | | | | | | |
| Brake control | ABS | | | | | | | | | | | |
| Active AFS | | × | | | × | × | | × | × | × | | |
| Intelligent Key system | | | × | | × | | × | × | × | × | | |
| Navigation system | | | | × | | × | | × | | × | | |
| Automatic drive positioner | | | | | | | × | | × | × | | |
| CAN system type | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 |
| CAN communication control unit | | | | | | | | | | | | |
| ECM | × | × | × | × | × | × | × | × | × | × | × | × |
| AFS control unit | | × | | | × | × | | | × | × | | × |
| BCM | × | × | × | × | × | × | × | × | × | × | × | × |
| IPDM E/R | × | × | × | × | × | × | × | × | × | × | × | × |

×: Applicable

Check the vehicle equipment.
The number indicates the CAN system type of the vehicle.

VEHICLE EQUIPMENT IDENTIFICATION INFORMATION
NOTE:
Check CAN system type from the vehicle shape and equipment.

In the above example,

- Checking Xenon bulb and bending lamp lead to judge whether or not Active AFS is equipped.
- Checking the ignition knob leads to judge whether or not Intelligent Key system is equipped.
- Checking display and multifunction switch lead to judge whether or not Navigation system is equipped.
- Checking seat memory switch leads to judge whether or not Automatic drive positioner is equipped.

1. Bending lamp 2. Xenon bulb 3. Ignition knob
4. Display 5. Multifunction switch 6. Seat memory switch
A. With active AFS B. With Intelligent Key system C. With navigation system
D. With automatic drive positioner

For the above case, CAN system type is "20".

JSMIA0530GB

>> GO TO 4.

4. CREATE INTERVIEW SHEET

Fill out the symptom described by the customer, vehicle condition, and CAN system type on the interview sheet.

NOTE:

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[CAN FUNDAMENTAL]

Interview Sheet (Example)

| CAN Communication System Diagnosis Interview Sheet | |
|--|----------------------|
| Date received: | 3, Feb. 2006 |
| Type: DBA-KG11 | VIN No.: KG11-005040 |
| Model: BDRARGZG11EDA-E-J- | |
| First registration: 10, Jan. 2001 | Mileage: 62,140 |
| CAN system type: Type 19 | |
| Symptom (Results from interview with customer) | |
| <ul style="list-style-type: none">• Headlamps suddenly turn ON while driving the vehicle.• The engine does not restart after stopping the vehicle and turning the ignition switch OFF.• The cooling fan continues rotating while turning the ignition switch ON. | |
| Condition at inspection | |
| Error Symptom: <u>Present</u> / Past | |
| <p>The engine does not start.</p> <p>While turning the ignition switch ON,</p> <ul style="list-style-type: none">• The headlamps (Lo) turn ON, and the cooling fan continues rotating.• The interior lamp does not turn ON. | |

JSMIA0531GB

A
B
C
D
E
F
G
H
I
J
K
L

>> GO TO 5.

5. DETECT THE ROOT CAUSE

CAN diagnosis function of CONSULT detects a root cause.

>> GO TO 6.

6. REPAIR OR REPLACE MALFUNCTIONING PART

Repair or replace malfunctioning parts identified by CAN diagnosis function of CONSULT.

CAN communication circuit>> Refer to [LAN-63, "CAN Communication Circuit"](#).
ITS communication circuit>> Refer to [LAN-64, "ITS Communication Circuit"](#).

LAN

N
O
P

HOW TO USE THIS SECTION

< HOW TO USE THIS MANUAL >

[CAN]

HOW TO USE THIS MANUAL

HOW TO USE THIS SECTION

Information

INFOID:0000000011217011

- “CAN” of LAN Section describes information peculiar to a vehicle and inspection procedures.
- For trouble diagnosis procedure, refer to [LAN-21, "Trouble Diagnosis Flow Chart"](#) of “CAN FUNDAMENTAL”.

Abbreviation List

INFOID:0000000011217012

Unit name abbreviations in CONSULT CAN diagnosis and in this section are as per the following list.

| Abbreviation | Unit name |
|--------------|---|
| 4WD | AWD control unit |
| A-BAG | Air bag diagnosis sensor unit |
| ABS | ABS actuator and electric unit (control unit) |
| ADP | Driver seat control unit |
| AV | AV control unit |
| AVM | Around view monitor control unit |
| BCM | BCM |
| CGW | CAN gateway |
| DLC | Data link connector |
| ECM | ECM |
| EPS/DAST 3 | Power steering control module |
| HVAC | A/C auto amp. |
| ICC | ADAS control unit |
| IPDM-E | IPDM E/R |
| LASER | ICC sensor |
| M&A | Combination meter |
| PWBD | Automatic back door control module |
| RDR-L | Side radar LH |
| RDR-R | Side radar RH |
| STRG | Steering angle sensor |
| TCM | TCM |

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000011578120

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precautions for Trouble Diagnosis

INFOID:000000011578121

CAUTION:

Follow the instructions listed below. Failure to do this may cause damage to parts:

- Never apply 7.0 V or more to the measurement terminal.
- Use a tester with open terminal voltage of 7.0 V or less.
- Turn the ignition switch OFF and disconnect the battery cable from the negative terminal when checking the harness.


Precautions for Harness Repair

INFOID:000000011578122

- Solder the repaired area and wrap tape around the soldered area.

NOTE:

A fray of twisted lines must be within 110 mm (4.33 in).



A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

PRECAUTIONS


< PRECAUTION >

[CAN]

- Bypass connection is never allowed at the repaired area.

NOTE:

Bypass connection may cause CAN communication error. The spliced wire becomes separated and the characteristics of twisted line are lost.




- Replace the applicable harness as an assembly if error is detected on the shield lines of CAN communication line.

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:0000000011217016



- | | | |
|---------------------------------|--------------------------------------|---|
| ① Side radar RH | ② AWD control unit | ③ AV control unit |
| ④ A/C auto amp. | ⑤ CAN gateway | ⑥ ABS actuator and electric unit (control unit) |
| ⑦ Power steering control module | ⑧ ICC sensor | ⑨ Around view monitor control unit |
| ⑩ ADAS control unit | ⑪ TCM | ⑫ ECM |
| ⑬ IPDM E/R | ⑭ Data link connector | ⑮ BCM |
| ⑯ Combination meter | ⑰ Steering angle sensor | ⑱ Air bag diagnosis sensor unit |
| ⑲ Driver seat control unit | ⑳ Automatic back door control module | ㉑ Side radar LH |

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

SYSTEM


CAN COMMUNICATION SYSTEM

CAN COMMUNICATION SYSTEM : System Description

INFOID:000000011217017

SYSTEM DIAGRAM

Without Around View Monitor System




SYSTEM

< SYSTEM DESCRIPTION >

[CAN]

With Around View Monitor System



A
B
C
D
E
F
G
H
I
J
K
L

LAN

N

O

P


DESCRIPTION

- CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.
- The following control units include a gateway function and communicate signals between the different CAN communication circuits.

| CAN communication circuit | Gateway control unit | Reference |
|---|----------------------|---|
| CAN communication circuit 1 ↔ CAN communication circuit 2 | CAN gateway | LAN-109. "System Description" |
| CAN communication circuit 2 ↔ ITS communication circuit | ADAS control unit | DAS-7. "System Description" |

CAN Communication Signal Generation


- Termination circuits (resistors) are connected across the CAN communication system. When transmitting a CAN communication signal, each control unit passes a current to the CAN-H line and the current returns to the CAN-L line.




- The current flows separately into the termination circuits connected across the CAN communication system and the termination circuits drop voltage to generate a potential difference between the CAN-H line and the CAN-L line.

NOTE:

A signal with no current passage is called "Recessive" and one with current passage is called "Dominant".



- The system produces digital signals for signal communications, by using the potential difference.




SYSTEM

< SYSTEM DESCRIPTION >

[CAN]


The Construction of CAN Communication Signal (Message)



| No. | Message name | Description |
|-----|-------------------------------|---|
| 1 | Start of frame (1 bit) | Start of message. |
| 2 | Arbitration of field (11 bit) | Priorities of message-sending are shown when there is a possibility that multiple messages are sent at the same time. |
| 3 | Control field (6 bit) | Signal quantity in data field is shown. |
| 4 | Data field (0-64 bit) | Actual signal is shown. |
| 5 | CRC field (16 bit) | <ul style="list-style-type: none"> The transmitting control unit calculates sending data in advance and writes the calculated value in a message. The receiving control unit calculates received data and judges that the data reception is normal when the calculated value is the same as the value written in the sent data. |
| 6 | ACK field (2 bit) | The completion of normal reception is sent to the transmitting control unit. |
| 7 | End of frame (7 bit) | End of message. |

CAN COMMUNICATION LINE


The CAN communication line is a twisted pair wire consisting of strands of CAN-H ① and CAN-L ② and has noise immunity.



NOTE:

The CAN communication system has the characteristics of noise-resistant because this system produces digital signals by using the potential difference between the CAN-H line and the CAN-L line and has the twisted pair wire structure.

Since the CAN-H line and the CAN-L line are always adjacent to each other, the same degree of noise occurs, respectively, when a noise ① occurs. Although the noise changes the voltage, the potential difference ② between the CAN-H line and the CAN-L line is insensitive to noise. Therefore, noise-resistant signals can be obtained.



CAN SIGNAL COMMUNICATIONS


SYSTEM

< SYSTEM DESCRIPTION >


[CAN]

Each control unit of the CAN communication system transmits signals through the CAN communication control circuit included in the control unit and receives only necessary signals from each control unit to perform various kinds of control.

- Example: Transmitted signals



- Example: Received signals



NOTE:

The above signal names and signal communications are provided for reference purposes. For CAN communications signals of this vehicle, refer to [LAN-37, "CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart"](#).

SYSTEM


[CAN]

< SYSTEM DESCRIPTION >

CAN COMMUNICATION SYSTEM : CAN Communication Control Circuit

INFOID:000000011217018

CAN communication control circuit is incorporated into the control unit and transmits/receives CAN communication signals.



| Component | System description |
|---|---|
| CAN controller | It controls CAN communication signal transmission and reception, error detection, etc. |
| Transceiver IC | It converts digital signal into CAN communication signal, and CAN communication signal into digital signal. |
| Noise filter | It eliminates noise of CAN communication signal. |
| Termination circuit* (Resistance of approx. 120 Ω) | Generates a potential difference between CAN-H and CAN-L. |

*: These are the only control units wired with both ends of CAN communication system.

CAN COMMUNICATION SYSTEM : CAN System Specification Chart

INFOID:000000011217019

Determine CAN system type from the following specification chart.

NOTE:

Refer to [LAN-21, "Trouble Diagnosis Flow Chart"](#) for how to use CAN system specification chart.

| Body type | Wagon | | | | | | | | | |
|---|--------|---|---|---|---|-----|---|---|---|----|
| | FWD | | | | | AWD | | | | |
| Axle | | | | | | | | | | |
| Engine | VQ35DE | | | | | | | | | |
| Transmission | CVT | | | | | | | | | |
| Brake control | VDC | | | | | | | | | |
| Navigation system | | x | x | x | x | | x | x | x | x |
| Automatic back door system | | | x | x | x | | | x | x | x |
| Automatic driver positioner | | | | x | x | | | | x | x |
| ICC system | | | | | x | | | | | x |
| CAN system type | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 |
| CAN communication control unit | | | | | | | | | | |
| ECM | x | x | x | x | x | x | x | x | x | x |
| IPDM E/R | x | x | x | x | x | x | x | x | x | x |
| TCM | x | x | x | x | x | x | x | x | x | x |
| ABS actuator and electric unit (control unit) | x | x | x | x | x | x | x | x | x | x |
| Power steering control module | x | x | x | x | x | x | x | x | x | x |

SYSTEM

< SYSTEM DESCRIPTION >

[CAN]

| Body type | Wagon | | | | | | | | | |
|---------------------------------------|--------|---|---|---|---|-----|---|---|---|----|
| Axle | FWD | | | | | AWD | | | | |
| Engine | VQ35DE | | | | | | | | | |
| Transmission | CVT | | | | | | | | | |
| Brake control | VDC | | | | | | | | | |
| Navigation system | | × | × | × | × | | × | × | × | × |
| Automatic back door system | | | × | × | × | | | × | × | × |
| Automatic driver positioner | | | | × | × | | | | × | × |
| ICC system | | | | | × | | | | | × |
| CAN system type | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 |
| CAN communication control unit | | | | | | | | | | |
| AV control unit | | × | × | × | × | | × | × | × | × |
| CAN gateway | | | | × | × | | | | × | × |
| A/C auto amp. | × | × | × | × | × | × | × | × | × | × |
| Automatic back door control module | | | × | × | × | | | × | × | × |
| AWD control unit | | | | | | × | × | × | × | × |
| Air bag diagnosis sensor unit | × | × | × | × | × | × | × | × | × | × |
| Data link connector | × | × | × | × | × | × | × | × | × | × |
| Combination meter | × | × | × | × | × | × | × | × | × | × |
| Steering angle sensor | × | × | × | × | × | × | × | × | × | × |
| BCM | × | × | × | × | × | × | × | × | × | × |
| ADAS control unit | | | | × | × | | | | × | × |
| Driver seat control unit | | | | × | × | | | | × | × |
| ITS communication control unit | | | | | | | | | | |
| ADAS control unit | | | | × | × | | | | × | × |
| Around view monitor control unit | | | | × | × | | | | × | × |
| Side radar RH | | | | × | × | | | | × | × |
| Side radar LH | | | | × | × | | | | × | × |
| ICC sensor | | | | | × | | | | | × |

×: Applicable

VEHICLE EQUIPMENT IDENTIFICATION INFORMATION


NOTE:

Check CAN system type from the vehicle shape and equipment.

SYSTEM

< SYSTEM DESCRIPTION >

[CAN]



- ① Distance switch
- ② Seat memory switch
- ③ Automatic back door switch
- ④ Color display
- ⑤ Map switch
- [A] With ICC system
- [B] With automatic drive positioner
- [C] With automatic back door system
- [D] With navigation system

CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart

INFOID:0000000011217020

Refer to [LAN-20, "How to Use CAN Communication Signal Chart"](#) for how to use CAN communication signal chart.

NOTE:

- CAN data of the air bag diagnosis sensor unit is not used by usual service work, thus it is omitted.
- Refer to [LAN-26, "Abbreviation List"](#) for the abbreviations of the connecting units.

T: Transmit R: Receive

| Signal name | ECM | IPDM-E | TCM | ABS | EPS | AV | CGW | HVAC | PWBD | 4WD | M&A | STRG | BCM | ICC | ADP | AVM | LAN |
|--|-----|--------|-----|-----|-----|----|-----|------|------|-----|-----|------|-----|-----|-----|-----|-----|
| A/C compressor request signal | T | R | | | | | | | | | | | | | | | |
| Accelerator pedal position signal | T | | R | R | | | | | | R | | | | R | | | |
| ASCD operation signal | T | | R | | | | | | | | R | | | | | | |
| ASCD status signal | T | | | | | | | | | | | | | | | | |
| Closed throttle position signal | T | | R | | | | | | | | | | | R | | | |
| Cooling fan speed request signal | T | R | | | | | | | | | | | | | | | |
| Engine and CVT integrated control signal | T | | R | | | | | | | | | | | | | | |
| | R | | T | | | | | | | | | | | | | | |
| Engine coolant temperature signal | T | | R | | | | | R | | | R | | | | | | |
| Engine speed signal | T | | R | R | | | | | | R | R | | | R | | | |
| Engine status signal | T | | | | R | R | | | | | R | | R | | | | |
| Fuel consumption monitor signal | T | | | | | R | | | | | R | | | | | | |

SYSTEM

< SYSTEM DESCRIPTION >

[CAN]

| Signal name | ECM | IPDM-E | TCM | ABS | EPS | AV | CGW | HVAC | PWBD | 4WD | M&A | STRG | BCM | ICC | ADP | AVM |
|---|-----|--------|-----|-----|-----|----|-----|------|------|-----|-----|------|-----|-----|-----|-----|
| Fuel filler cap warning display signal | T | | | | | | | | | | R | | | | | |
| ICC brake switch signal | T | | | | | | | | | | | | | R | | |
| ICC operation signal | R | | | R | | | | | | | | | | T | | |
| ICC prohibition signal | T | | | | | | | | | | | | | R | | |
| ICC steering switch signal | T | | | | | | | | | | | | | R | | |
| Malfunction indicator lamp signal | T | | | | | | | | | | R | | | | | |
| | R | | T | | | | | | | | | | | | | |
| Oil pressure warning lamp signal | T | | | | | | | | | | R | | | | | |
| Power generation command value signal | T | R | | | | | | | | | | | | | | |
| Stop lamp switch signal | T | | | | | | | | | | | | | R | | |
| | | | R | | | | | | | | | | T | | | |
| | | | | T | | | | | R | | | | | R | | |
| A/C compressor feedback signal | R | T | | | R | | R | | | | | | | | | |
| Front wiper position signal | | T | | | | | | | | | | | R | | | |
| High beam status signal | R | T | | | R | | | | | | | | | | | |
| Hood switch signal | | T | | | | | | | | | | | R | | | |
| Low beam status signal | R | T | | | R | | | | | | | | | | | |
| Push-button ignition switch status signal | | T | | | | | | | | | | | R | | | |
| CVT ratio signal | | | T | | | | | | | R | | | | | | |
| CVT position indicator signal | | | T | | | R | | | R | | R | | R | | R | R |
| CVT self-diagnosis signal | R | | T | | | | | | | | | | | | | |
| Current gear position signal | R | | T | | | | | | | | | | | R | | |
| Input speed signal | R | | T | R | | | | | | R | | | | R | | |
| Manual mode shift refusal signal | | | T | | | | | | | | R | | | | | |
| N range signal | | | T | R | | | | | | | | | R | | | |
| Next gear position signal | R | | T | | | | | | | | | | | | | |
| Output shaft revolution signal | R | | T | | | | | | | | | | | R | | |
| P range signal | | | T | | | | | | | | | | R | | | |
| R range signal | | | T | R | | | | | | | | | | | | |
| Shift position signal | | | T | | | | | | | | R | | | R | R | R |
| Shift schedule signal | R | | T | | | | | | | | | | | | | |
| ABS malfunction signal | | | R | T | | | | | | | | | | R | | |
| ABS operation signal | | | R | T | | R | | | | | | | | R | | |
| ABS warning lamp signal | | | | T | | | | | | | R | | | R | | |
| Brake warning lamp signal | | | | T | | | | | | | R | | | | | |
| | | | | | | | | | | | T | | | | | |
| Decel G sensor signal | | | | T | | | | | | R | | | | | | |
| Rear LH wheel speed signal | | | | T | | | | | | | | | | | | R |
| Rear RH wheel speed signal | | | | T | | | | | | | | | | | | R |
| Side G sensor signal | | | | T | | | | | | R | | | | R | | |
| TCS malfunction signal | | | | T | | | | | | | | | | R | | |

SYSTEM

< SYSTEM DESCRIPTION >

[CAN]

| Signal name | ECM | IPDM-E | TCM | ABS | EPS | AV | CGW | HVAC | PWBD | 4WD | M&A | STRG | BCM | ICC | ADP | AVM | |
|--|-----|--------|-----|-----|-----|----|-----|------|------|-----|-----|------|-----|-----|-----|-----|-----|
| TCS operation signal | | | R | T | | | | | | | | | | R | | | A |
| VDC malfunction signal | | | | T | | | | | | | | | | R | | | B |
| VDC OFF indicator lamp signal | | | | T | | | | | | | R | | | | | | C |
| VDC OFF switch signal | | | | T | | | | | | | | | | R | | | C |
| VDC operation signal | | | R | T | | | | | | | | | | R | | | C |
| VDC warning lamp signal | | | | T | | | | | | | R | | | | | | D |
| Yaw rate signal | | | | T | | | | | | R | | | | R | | | D |
| Vehicle speed signal | | | R | T | | | | | R | R | R | | R | R | R | R | E |
| | R | R | | | R | R | | R | R | | T | | R | | R | | E |
| EPS operation signal | R | | | | T | | | | | | | | | | | | E |
| Hydraulic pump electric power steering warning lamp signal | | | | | T | | | | | | R | | | | | | F |
| A/C switch operation signal | | | | | | T | | R | | | | | | | | | F |
| Camera switch signal | | | | | | T | | | | | | | | | | R | G |
| Rear window defogger switch signal | | | | | | T | | | | | | | R | | | | G |
| System setting signal | | | | | | T | | | | | | | R | | | | H |
| | | | | | | R | | | | | | | T | | | | H |
| Voice recognition signal | | | | | | T | | R | | | | | | | | | I |
| A/C display signal | | | | | | R | | T | | | | | | | | | I |
| A/C evaporator temperature signal | R | | | | | | | T | | | | | | | | | J |
| A/C ON signal | R | | | | | | | T | | | | | | | | | J |
| Ambient sensor signal | | | | | | | | T | | | R | | | | | | J |
| Blower fan ON signal | R | | | | | | | T | | | | | | | | | K |
| Target A/C evaporator temperature signal | R | | | | | | | T | | | | | | | | | K |
| Hazard request signal | | | | | | | | | T | | R | | | | | | L |
| AWD signal | | | | R | | | | | | T | | | | | | | L |
| AWD warning icon/display signal | | | | | | | | | | T | R | | | | | | L |
| Brake fluid level switch signal | | | | R | | | | | | | T | | | | | | LAN |
| Distance to empty signal | | | | | | R | | | | | T | | | | | | LAN |
| Fuel filler cap warning reset signal | R | | | | | | | | | | T | | | | | | N |
| Fuel level low warning signal | | | | | | R | | | | | T | | | | | | N |
| Fuel level sensor signal | R | | | | | | | | | | T | | | | | | N |
| Manual mode shift down signal | | | R | | | | | | | | T | | | | | | O |
| Manual mode shift up signal | | | R | | | | | | | | T | | | | | | O |
| Manual mode signal | | | R | | | | | | | | T | | | | | | O |
| Non-manual mode signal | | | R | | | | | | | | T | | | | | | P |
| Odometer signal | | | | | | | | | | | T | | R | | | | P |
| Parking brake switch signal | | | | R | | | | | R | R | T | | R | R | | | P |
| Seat belt buckle switch signal (driver side) | | | | | | | | | | | T | | R | | | | P |

SYSTEM

< SYSTEM DESCRIPTION >

[CAN]

| Signal name | ECM | IPDM-E | TCM | ABS | EPS | AV | CGW | HVAC | PWBD | 4WD | M&A | STRG | BCM | ICC | ADP | AVM |
|---|-----|--------|-----|-----|-----|----|-----|------|------|-----|-----|------|-----|-----|-----|-----|
| Sleep-ready signal | | T | | | | | | | | | T | | R | | | |
| | | | | | | | | | T | | | | R | | | |
| | | | | | | | | | | | | | | | | |
| System selection signal | | | | | | | | | | | T | | | R | | |
| Wake up signal | | | | | | | | | | | T | | R | | | |
| | | | | | | | | | T | | | | R | | | |
| Steering angle sensor malfunction signal | | | | R | R | | | | | | | T | | R | | |
| Steering angle sensor signal | | | | R | R | R | | | | R | | T | | R | | R |
| Steering angle speed signal | | | | R | | | | | | | | T | | R | | |
| Steering calibration signal | | | | R | | | | | | | | T | | | | |
| Automatic back door request signal | | | | | | | | | R | | | | T | | | |
| Back door lock status signal | | | | | | | | | R | | | | T | | | |
| Buzzer request signal | | | | | | | | | | | R | | T | | | |
| Buzzer output signal | | | | | | | | | | | R | | T | | | |
| | | | | | | | | | | | R | | | T | | |
| Day time running light request signal | | R | | | | | | R | | | | | T | | | |
| Dimmer signal | | | | | | | | | | | R | | T | R | | |
| Door switch signal | | R | | | | | | R | | | R | | T | | R | |
| Door unlock signal | | | | | | | | | | | | | T | | R | |
| Front fog light request signal | | R | | | | | | | | | R | | T | | | |
| Front wiper request signal | | R | | | | R | | R | | | | | T | R | | |
| Handle position signal | | | | | | | | | | | | | T | | R | |
| High beam request signal | | R | | | | | | R | | | R | | T | | | |
| Horn reminder signal | | R | | | | | | | | | | | T | | | |
| Ignition switch ON signal | | R | | | | | | | | | | | T | | | |
| | | T | | | | | | | | | | | R | | | |
| Ignition switch signal | | R | | | | | | | | | | | T | | R | |
| Intelligent Key system warning display signal | | | | | | | | | | | R | | T | | | |
| Interlock/PNP switch signal | | R | | | | | | | | | | | T | | | |
| | | T | | | | | | | | | | | R | | | |
| Key ID signal | | | | | | | | R | | | | | T | | R | |
| Low beam request signal | | R | | | | | | R | | | | | T | | | |
| Low tire pressure warning lamp signal | | | | | | | | | | | R | | T | | | |
| Meter TPMS display signal | | | | | | | | | | | R | | T | | | |
| | | | | | | | | | | | R | | | T | | |
| Meter ring illumination request signal | | | | | | | | | | | R | | T | | | |
| Oil pressure switch signal | | | | | | | | | | | R | | T | | | |
| | | T | | | | | | | | | R | | R | | | |
| Position light request signal | | R | | | | | | R | | | R | | T | | | |

SYSTEM

< SYSTEM DESCRIPTION >

[CAN]

| Signal name | ECM | IPDM-E | TCM | ABS | EPS | AV | CGW | HVAC | PWBD | 4WD | M&A | STRG | BCM | ICC | ADP | AVM |
|-------------------------------------|-----|--------|-----|-----|-----|----|-----|------|------|-----|-----|------|-----|-----|-----|-----|
| Rear window defogger control signal | | R | | | | | | R | | | | | T | | | |
| | R | T | | | | R | | | | | | | | | | |
| Sleep wake up signal | | R | | | | | R | | R | | R | | T | | R | |
| Starter control relay signal | | R | | | | | | | | | | | T | | | |
| Starter relay status signal | | R | | | | | | | | | R | | T | | | |
| | | T | | | | | | | | | | | R | | | |
| Starting mode signal | | | | | | | | | R | | | | T | | R | |
| Theft warning horn request signal | | R | | | | | | | | | | | T | | | |
| Back door switch signal | | | | | | | | | | | R | | T | | | R |
| Turn indicator signal | | | | | | R | | R | | | R | | T | R | | |
| Brake fluid pressure control signal | | | | R | | | | | | | | | | T | | |
| FEB warning lamp signal | | | | | | | | | | | R | | | T | | |
| View change signal | | | | | | R | | | | | | | | | | T |

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

CAN SYSTEM (WITHOUT AROUND VIEW MONITOR SYSTEM)

[CAN]

< WIRING DIAGRAM >

WIRING DIAGRAM


CAN SYSTEM (WITHOUT AROUND VIEW MONITOR SYSTEM)

Wiring Diagram

INFOID:000000011217021

CAN SYSTEM - WITHOUT AROUND VIEW MONITOR SYSTEM

- ◁W4▷ : WITH ALL WHEEL DRIVE
- ◁NN▷ : WITH NAVIGATION SYSTEM AND BOSE AUDIO SYSTEM
- ◁NP▷ : WITH NAVIGATION SYSTEM AND WITHOUT BOSE AUDIO SYSTEM
- ◁NV▷ : WITH NAVIGATION SYSTEM
- ◁PB▷ : WITH POWER BACK DOOR




AAMWA1472GB

CAN SYSTEM (WITHOUT AROUND VIEW MONITOR SYSTEM)

< WIRING DIAGRAM >

[CAN]



A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

AAMWA1473GB

CAN SYSTEM (WITHOUT AROUND VIEW MONITOR SYSTEM)

< WIRING DIAGRAM >

[CAN]

CAN SYSTEM CONNECTORS - WITHOUT AROUND VIEW MONITOR SYSTEM

| | |
|-----------------|---------------------------|
| Connector No. | M19 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | BLACK |



| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|---|---|---|---|---|---|---|---|---|
| 60 | 59 | 58 | 57 | 56 | 55 | 54 | 53 | 52 | 51 | 50 | 49 | 48 | 47 | 46 | 45 | 44 | 43 | 42 | 41 | 40 | 39 | 38 | 37 | 36 | 35 | 34 | 33 | 32 | 31 | 30 | 29 | 28 | 27 | 26 | 25 | 24 | 23 | 22 | 21 | 20 | 19 | 18 | 17 | 16 | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|---|---|---|---|---|---|---|---|---|

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 59 | P | CAN-L |
| 60 | L | CAN-H |

| | |
|-----------------|---------------------|
| Connector No. | M22 |
| Connector Name | DATA LINK CONNECTOR |
| Connector Color | WHITE |



| | | | | | | | |
|---|----|----|----|----|----|----|----|
| 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 |
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 6 | L | - |
| 14 | P | - |


| | |
|-----------------|-------------------|
| Connector No. | M23 |
| Connector Name | COMBINATION METER |
| Connector Color | WHITE |



| | | | | | | | |
|----|----|----|----|----|----|----|----|
| 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 |
| 49 | 50 | 51 | 52 | 53 | 54 | 55 | 56 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 52 | P | CAN-L |
| 53 | L | CAN-H |

| | |
|-----------------|--------------|
| Connector No. | M31 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 11G | P | - |
| 12G | L | - |

| | |
|-----------------|------------------------------|
| Connector No. | M35 |
| Connector Name | AIR BAG DIAGNOSIS SENSOR UNI |
| Connector Color | YELLOW |



| | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|
| 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | | |
| 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 |
| 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 | 49 | 50 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 45 | P | CAN-L |
| 46 | L | CAN-H |


AAMIA2918GB

CAN SYSTEM (WITHOUT AROUND VIEW VIEW MONITOR SYSTEM)

< WIRING DIAGRAM >


[CAN]

| | |
|-----------------|--------------|
| Connector No. | M69 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 26 | P | - |
| 27 | L | - |

| | |
|-----------------|-----------------------|
| Connector No. | M54 |
| Connector Name | STEERING ANGLE SENSOR |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2 | P | - |
| 5 | L | - |

| | |
|-----------------|---------------|
| Connector No. | M50 |
| Connector Name | A/C AUTO AMP. |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | CAN-H |
| 21 | P | CAN-L |

| | |
|-----------------|---|
| Connector No. | M162 |
| Connector Name | AV CONTROL UNIT (WITH NAVIGATION SYSTEM WITH BOSE AUDIO SYSTEM) |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 23 | P | CAN-L |
| 43 | L | CAN-H |

| | |
|-----------------|--|
| Connector No. | M123 |
| Connector Name | AV CONTROL UNIT (WITH NAVIGATION SYSTEM WITHOUT BOSE AUDIO SYSTEM) |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 23 | P | CAN-L |
| 43 | L | CAN-H |

| | |
|-----------------|--------------|
| Connector No. | M84 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 21 | P | - |
| 22 | L | - |
| 28 | P | - |
| 29 | L | - |

AAMIA2919GB


A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

CAN SYSTEM (WITHOUT AROUND VIEW MONITOR SYSTEM)

< WIRING DIAGRAM >


[CAN]

| | |
|-----------------|---------------------|
| Connector No. | E45 |
| Connector Name | JOINT CONNECTOR-E12 |
| Connector Color | BLUE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | - |
| 2 | L | - |
| 3 | L | - |
| 4 | L | - |
| 7 | P | - |
| 8 | P | - |
| 9 | P | - |
| 10 | P | - |

| | |
|-----------------|-------|
| Connector No. | E32 |
| Connector Name | ECM |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 123 | P | CAN-L |
| 124 | L | CAN-H |

| | |
|-----------------|--------------|
| Connector No. | E2 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 9 | P | - |
| 10 | L | - |

| | |
|-----------------|---------------------|
| Connector No. | E71 |
| Connector Name | JOINT CONNECTOR-E15 |
| Connector Color | BLACK |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | - |
| 2 | L | - |
| 3 | L | - |
| 4 | L | - |

| | |
|-----------------|---------------------|
| Connector No. | E70 |
| Connector Name | JOINT CONNECTOR-E14 |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | P | - |
| 2 | P | - |
| 3 | P | - |
| 4 | P | - |

| | |
|-----------------|-------------------------------|
| Connector No. | E62 |
| Connector Name | POWER STEERING CONTROL MODULE |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 7 | P | CAN-L |
| 8 | L | CAN-H |


AAMIA2920GB

CAN SYSTEM (WITHOUT AROUND VIEW MONITOR SYSTEM)

< WIRING DIAGRAM >


[CAN]

| | |
|-----------------|--|
| Connector No. | E119 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 28 | P | CAN-L |
| 29 | L | CAN-H |

| | |
|-----------------|---|
| Connector No. | E125 |
| Connector Name | ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) |
| Connector Color | BLACK |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 14 | P | CAN-L |
| 26 | L | CAN-H |

| | |
|-----------------|--------------|
| Connector No. | E152 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 11G | P | - |
| 12G | L | - |

| | |
|-----------------|-----------------------------------|
| Connector No. | F25 |
| Connector Name | TCM (TRANSMISSION CONTROL MODULE) |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 23 | P | CAN-L |
| 33 | L | CAN-H |

AAMIA2921GB

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P



LAN

CAN SYSTEM (WITHOUT AROUND VIEW VIEW MONITOR SYSTEM)

< WIRING DIAGRAM >



[CAN]

| | |
|-----------------|------------------------------------|
| Connector No. | B55 |
| Connector Name | AUTOMATIC BACK DOOR CONTROL MODULE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | CAN-H |
| 17 | P | CAN-L |

| | |
|-----------------|--------------|
| Connector No. | B41 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 26 | P | - |
| 27 | L | - |

| | |
|-----------------|--------------|
| Connector No. | F32 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 9 | P | - |
| 10 | L | - |

| | |
|-----------------|------------------|
| Connector No. | B135 |
| Connector Name | AWD CONTROL UNIT |
| Connector Color | WHITE |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 8 | L | CAN-H |
| 16 | P | CAN-L |

| | |
|-----------------|--------------|
| Connector No. | B101 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 21 | P | - |
| 22 | L | - |
| 28 | P | - |
| 29 | L | - |

AAMIA2922GB

CAN SYSTEM (WITH AROUND VIEW MONITOR SYSTEM)

< WIRING DIAGRAM >

[CAN]


CAN SYSTEM (WITH AROUND VIEW MONITOR SYSTEM)

Wiring Diagram

INFOID:000000011217022

◁ NP ▷ : WITH NAVIGATION SYSTEM
 WITHOUT BOSE AUDIO SYSTEM

CAN SYSTEM - WITH AROUND VIEW MONITOR SYSTEM



A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN


AAMWA1469GB

CAN SYSTEM (WITH AROUND VIEW MONITOR SYSTEM)

< WIRING DIAGRAM >

[CAN]


◁WA▷ : WITH ALL WHEEL DRIVE



AAMWA1470GB


CAN SYSTEM CONNECTORS - WITH AROUND VIEW MONITOR SYSTEM

| | |
|-----------------|-------------|
| Connector No. | M5 |
| Connector Name | CAN GATEWAY |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | CAN-H |
| 4 | L | CAN-H |
| 6 | L | CAN-H |
| 7 | P | CAN-L |
| 10 | P | CAN-L |
| 12 | P | CAN-L |

| | |
|-----------------|---------------------------|
| Connector No. | M19 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | BLACK |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 59 | P | CAN-L |
| 60 | L | CAN-H |

| | |
|-----------------|---------------------|
| Connector No. | M22 |
| Connector Name | DATA LINK CONNECTOR |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 6 | L | - |
| 12 | P | - |
| 13 | L | - |
| 14 | P | - |

| | |
|-----------------|-------------------|
| Connector No. | M23 |
| Connector Name | COMBINATION METER |
| Connector Color | WHITE |






| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 52 | P | CAN-L |
| 54 | L | CAN-H |

AAMIA2908GB

CAN SYSTEM (WITH AROUND VIEW MONITOR SYSTEM)

< WIRING DIAGRAM >

[CAN]



AAMIA2909GB

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P


LAN

CAN SYSTEM (WITH AROUND VIEW MONITOR SYSTEM)

< WIRING DIAGRAM >


[CAN]

| | |
|-----------------|--------------|
| Connector No. | M69 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 26 | P | - |
| 27 | L | - |

| | |
|-----------------|-----------------------|
| Connector No. | M54 |
| Connector Name | STEERING ANGLE SENSOR |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2 | P | - |
| 5 | L | - |

| | |
|-----------------|---------------|
| Connector No. | M50 |
| Connector Name | A/C AUTO AMP. |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | CAN-H |
| 21 | P | CAN-L |

| | |
|-----------------|-----------------|
| Connector No. | M162 |
| Connector Name | AV CONTROL UNIT |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 23 | P | CAN-L |
| 43 | L | CAN-H |

| | |
|-----------------|----------------------------------|
| Connector No. | M96 |
| Connector Name | AROUND VIEW MONITOR CONTROL UNIT |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---------------------|
| 24 | P | CAN-L (WITHOUT ICC) |
| 24 | Y | CAN-L (WITH ICC) |
| 26 | L | CAN-H |

| | |
|-----------------|--------------|
| Connector No. | M84 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 7 | Y | - |
| 8 | L | - |
| 21 | P | - |
| 22 | L | - |
| 28 | P | - |
| 29 | L | - |


AAMIA2910GB

CAN SYSTEM (WITH AROUND VIEW MONITOR SYSTEM)

< WIRING DIAGRAM >


[CAN]

| | |
|-----------------|--------------|
| Connector No. | E2 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 9 | P | - |
| 10 | L | - |

| | |
|-----------------|-------------------|
| Connector No. | M182 |
| Connector Name | ADAS CONTROL UNIT |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2 | L | ITS CAN-H |
| 5 | Y | ITS CAN-L |
| 6 | Y | 3RD CAN-L |
| 9 | L | CAN-H |
| 10 | P | CAN-L |
| 18 | L | 3RD CAN-H |

| | |
|-----------------|---------------------|
| Connector No. | M170 |
| Connector Name | JOINT CONNECTOR-M09 |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 23 | L | - |
| 25 | L | - |
| 26 | L | - |
| 29 | Y | - |
| 30 | Y | - |
| 31 | Y | - |

| | |
|-----------------|--------------|
| Connector No. | E5 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 17 | Y | - |
| 18 | L | - |
| 20 | Y | - |
| 21 | L | - |

AAMIA2911GB

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P


LAN

CAN SYSTEM (WITH AROUND VIEW MONITOR SYSTEM)

< WIRING DIAGRAM >


[CAN]

| | |
|-----------------|-------|
| Connector No. | E32 |
| Connector Name | ECM |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 123 | P | CAN-L |
| 124 | L | CAN-H |

| | |
|-----------------|--------------|
| Connector No. | E34 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 13 | L | - |
| 14 | Y | - |

| | |
|-----------------|---------------------|
| Connector No. | E45 |
| Connector Name | JOINT CONNECTOR-E12 |
| Connector Color | BLUE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | - |
| 2 | L | - |
| 3 | L | - |
| 4 | L | - |
| 7 | P | - |
| 8 | P | - |
| 9 | P | - |
| 10 | P | - |

| | |
|-----------------|-------------------------------|
| Connector No. | E62 |
| Connector Name | POWER STEERING CONTROL MODULE |
| Connector Color | BLACK |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 7 | P | CAN-L |
| 8 | L | CAN-H |

| | |
|-----------------|---------------------|
| Connector No. | E70 |
| Connector Name | JOINT CONNECTOR-E14 |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | P | - |
| 2 | P | - |
| 3 | P | - |
| 4 | P | - |

| | |
|-----------------|---------------------|
| Connector No. | E71 |
| Connector Name | JOINT CONNECTOR-E15 |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | - |
| 2 | L | - |
| 3 | L | - |
| 4 | L | - |


AAMIA2912GB

CAN SYSTEM (WITH AROUND VIEW MONITOR SYSTEM)

< WIRING DIAGRAM >


[CAN]

| | |
|-----------------|--|
| Connector No. | E119 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 28 | P | CAN-L |
| 29 | L | CAN-H |

| | |
|-----------------|---|
| Connector No. | E130 |
| Connector Name | ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) (WITH ICG) |
| Connector Color | BLACK |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 19 | L | CAN-H |
| 30 | P | CAN-L |

| | |
|-----------------|--------------|
| Connector No. | E152 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 11G | P | - |
| 12G | L | - |
| 60G | Y | - |
| 61G | L | - |

| | |
|-----------------|--------------|
| Connector No. | E207 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 17 | Y | - |
| 18 | L | - |
| 20 | Y | - |
| 21 | L | - |

AAMIA2913GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


LAN

CAN SYSTEM (WITH AROUND VIEW MONITOR SYSTEM)

< WIRING DIAGRAM >


[CAN]

| | |
|-----------------|--------------|
| Connector No. | F32 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 9 | P | - |
| 10 | L | - |

| | |
|-----------------|-----------------------------------|
| Connector No. | F25 |
| Connector Name | TCM (TRANSMISSION CONTROL MODULE) |
| Connector Color | BLACK |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 23 | P | CAN-L |
| 33 | L | CAN-H |

| | |
|-----------------|------------|
| Connector No. | E219 |
| Connector Name | ICC SENSOR |
| Connector Color | BLACK |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2 | L | CAN-H |
| 3 | L/R | CAN-L |

| | |
|-----------------|--------------|
| Connector No. | B49 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 6 | L | - |
| 7 | Y | - |

| | |
|-----------------|--------------|
| Connector No. | B41 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 26 | P | - |
| 27 | L | - |

| | |
|-----------------|--------------|
| Connector No. | B40 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 13 | L | - |
| 14 | Y | - |


AAMIA2914GB

CAN SYSTEM (WITH AROUND VIEW MONITOR SYSTEM)

< WIRING DIAGRAM >


[CAN]

| | |
|-----------------|--------------|
| Connector No. | B54 |
| Connector Name | WIRE TO WIRE |
| Connector Color | BROWN |





| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 4 | L | - |
| 5 | P | - |

| | |
|-----------------|------------------------------------|
| Connector No. | B55 |
| Connector Name | AUTOMATIC BACK DOOR CONTROL MODULE |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | CAN-H |
| 17 | P | CAN-L |

| | |
|-----------------|--------------|
| Connector No. | B69 |
| Connector Name | WIRE TO WIRE |
| Connector Color | GRAY |



AAMIA2915GB

| | |
|-----------------|--------------|
| Connector No. | B92 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 6 | Y | - |
| 7 | L | - |

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

CAN SYSTEM (WITH AROUND VIEW MONITOR SYSTEM)

< WIRING DIAGRAM >

[CAN]

| | |
|-----------------|--------------|
| Connector No. | B140 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| | | | | | | | | |
|---|---|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | | |
| 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 6 | L | - |
| 7 | Y | - |

| | |
|-----------------|------------------|
| Connector No. | B135 |
| Connector Name | AWD CONTROL UNIT |
| Connector Color | WHITE |



| | | | | | | | |
|----|----|----|----|----|----|----|---|
| 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 |
| 16 | 15 | 14 | 13 | 12 | 11 | 10 | 9 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 8 | L | CAN-H |
| 16 | P | CAN-L |

| | |
|-----------------|--------------|
| Connector No. | B101 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 |
| 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 7 | Y | - |
| 8 | L | - |
| 21 | P | - |
| 22 | L | - |
| 28 | P | - |
| 29 | L | - |

| | |
|-----------------|--------------------------|
| Connector No. | B209 |
| Connector Name | DRIVER SEAT CONTROL UNIT |
| Connector Color | WHITE |



| | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 16 | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 |
| 32 | 31 | 30 | 29 | 28 | 27 | 26 | 25 | 24 | 23 | 22 | 21 | 20 | 19 | 18 | 17 |

| | |
|-----------------|--------------|
| Connector No. | B200 |
| Connector Name | WIRE TO WIRE |
| Connector Color | BROWN |



| | | | | | | |
|----|----|----|---|---|---|---|
| 5 | 4 | 3 | 2 | 1 | | |
| 12 | 11 | 10 | 9 | 8 | 7 | 6 |

| | |
|-----------------|--------------|
| Connector No. | B142 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| | | | |
|---|---|---|---|
| 1 | 2 | 3 | 4 |
| 5 | 6 | 7 | 8 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 16 | W | - |
| 32 | P | - |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 4 | W | - |
| 5 | P | - |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 6 | Y | - |
| 7 | L | - |


AAMIA2916GB

CAN SYSTEM (WITH AROUND VIEW MONITOR SYSTEM)

< WIRING DIAGRAM >


[CAN]

| | |
|-----------------|---------------|
| Connector No. | B465 |
| Connector Name | SIDE RADAR LH |
| Connector Color | BLACK |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 6 | L | - |
| 7 | Y | - |

| | |
|-----------------|--------------|
| Connector No. | B464 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 6 | Y | - |
| 7 | L | - |

| | |
|-----------------|--------------|
| Connector No. | B463 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 6 | Y | - |
| 7 | L | - |

| | |
|-----------------|---------------|
| Connector No. | B466 |
| Connector Name | SIDE RADAR RH |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 6 | L | - |
| 7 | Y | - |

AAMIA2917GB

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Interview Sheet

INFOID:000000011217024

NOTE:

Refer to [LAN-21, "Trouble Diagnosis Flow Chart"](#) for how to use interview sheet.

| | |
|---|-------------------------------|
| CAN Communication System Diagnosis Interview Sheet | |
| Date received: <input type="text"/> | |
| Type: <input type="text"/> | VIN No.: <input type="text"/> |
| Model: <input type="text"/> | |
| First registration: <input type="text"/> | Mileage: <input type="text"/> |
| CAN system type: <input type="text"/> | |
| Symptom (Results from interview with customer) | |
| <input type="text"/> | |
| Condition at inspection | |
| Error symptom : Present / Past <input type="text"/> | |

SKIB8898E

MALFUNCTION AREA CHART

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

DTC/CIRCUIT DIAGNOSIS

MALFUNCTION AREA CHART

CAN Communication Circuit

INFOID:000000011217025

MAIN LINE

| Malfunction area | Reference |
|---|---|
| Main line between IPDM E/R and ABS actuator and electric unit (control unit) | LAN-65. "Diagnosis Procedure" |
| Main line between ABS actuator and electric unit (control unit) and A/C auto amp. | LAN-66. "Diagnosis Procedure" |
| Main line between A/C auto amp. and AWD control unit | LAN-67. "Diagnosis Procedure" |
| Main line between A/C auto amp. and data link connector | LAN-68. "Diagnosis Procedure" |
| Main line between AWD control unit and data link connector | LAN-70. "Diagnosis Procedure" |
| Main line between data link connector and driver seat control unit | LAN-71. "Diagnosis Procedure" |

BRANCH LINE

| Malfunction area | Reference |
|---|---|
| ECM branch line circuit | LAN-75. "Diagnosis Procedure" |
| IPDM E/R branch line circuit | LAN-76. "Diagnosis Procedure" |
| TCM branch line circuit | LAN-77. "Diagnosis Procedure" |
| ABS actuator and electric unit (control unit) branch line circuit | LAN-78. "Diagnosis Procedure" |
| Power steering control module branch line circuit | LAN-79. "Diagnosis Procedure" |
| AV control unit branch line circuit | LAN-80. "Diagnosis Procedure" |
| CAN gateway branch line circuit (CAN communication circuit 1) | LAN-81. "Diagnosis Procedure" |
| CAN gateway branch line circuit (CAN communication circuit 2) | LAN-82. "Diagnosis Procedure" |
| A/C auto amp. branch line circuit | LAN-83. "Diagnosis Procedure" |
| Automatic back door control module branch line circuit | LAN-84. "Diagnosis Procedure" |
| AWD control unit branch line circuit | LAN-85. "Diagnosis Procedure" |
| Air bag diagnosis sensor unit branch line circuit | LAN-86. "Diagnosis Procedure" |
| Data link connector branch line circuit | LAN-87. "Diagnosis Procedure" |
| Data link connector branch line circuit (CAN communication circuit 1) | LAN-88. "Diagnosis Procedure" |
| Data link connector branch line circuit (CAN communication circuit 2) | LAN-89. "Diagnosis Procedure" |
| Combination meter branch line circuit | LAN-90. "Diagnosis Procedure" |
| Steering angle sensor branch line circuit | LAN-91. "Diagnosis Procedure" |
| BCM branch line circuit | LAN-92. "Diagnosis Procedure" |
| ADAS control unit branch line circuit | LAN-93. "Diagnosis Procedure" |
| Driver seat control unit branch line circuit | LAN-94. "Diagnosis Procedure" |

SHORT CIRCUIT

| Malfunction area | Reference |
|-----------------------------|--|
| CAN communication circuit | LAN-99. "Diagnosis Procedure" |
| CAN communication circuit 1 | LAN-101. "Diagnosis Procedure" |
| CAN communication circuit 2 | LAN-103. "Diagnosis Procedure" |

MALFUNCTION AREA CHART

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

ITS Communication Circuit

INFOID:000000011217026

MAIN LINE

| Malfunction area | Reference |
|---|---|
| Main line between around view monitor and side radar RH | LAN-72. "Diagnosis Procedure" |
| Main line between side radar RH and side radar LH | LAN-73. "Diagnosis Procedure" |
| Main line between side radar LH and ICC sensor | LAN-74. "Diagnosis Procedure" |

BRANCH LINE

| Malfunction area | Reference |
|--|---|
| Around view monitor control unit branch line circuit | LAN-95. "Diagnosis Procedure" |
| Side radar RH branch line circuit | LAN-96. "Diagnosis Procedure" |
| Side radar LH branch line circuit | LAN-97. "Diagnosis Procedure" |
| ICC sensor branch line circuit | LAN-98. "Diagnosis Procedure" |

SHORT CIRCUIT OR OPEN CIRCUIT

| Malfunction area | Reference |
|---------------------------|--|
| ITS communication circuit | LAN-105. "Diagnosis Procedure" |

MAIN LINE BETWEEN IPDM-E AND ABS CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

MAIN LINE BETWEEN IPDM-E AND ABS CIRCUIT

Diagnosis Procedure

INFOID:000000011217027

1. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
 - ECM
 - IPDM E/R
 - ABS actuator and electric unit (control unit)
4. Check the continuity between the IPDM E/R harness connector and the ABS actuator and electric unit (control unit) harness connector.
 - Without around view monitor system

| IPDM E/R harness connector | | ABS actuator and electric unit (control unit) harness connector | | Continuity |
|----------------------------|--------------|---|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E119 | 29 | E125 | 26 | Existed |
| | 28 | | 14 | Existed |

- With around view monitor system

| IPDM E/R harness connector | | ABS actuator and electric unit (control unit) harness connector | | Continuity |
|----------------------------|--------------|---|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E119 | 29 | E130 | 19 | Existed |
| | 28 | | 30 | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the IPDM E/R and the ABS actuator and electric unit (control unit).

NO >> Repair the main line between the IPDM E/R and the ABS actuator and electric unit (control unit).

LAN

MAIN LINE BETWEEN ABS AND HVAC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

MAIN LINE BETWEEN ABS AND HVAC CIRCUIT

Diagnosis Procedure

INFOID:000000011217028

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector E152
 - Harness connector M31

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - ABS actuator and electric unit (control unit)
 - Harness connectors E152 and M31.
2. Check the continuity between the ABS actuator and electric unit (control unit) harness connector and the harness connector.
 - Without around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | Harness connector | | Continuity |
|---|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E125 | 26 | E152 | 12G | Existed |
| | 14 | | 11G | Existed |

- With around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | Harness connector | | Continuity |
|---|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E130 | 19 | E152 | 12G | Existed |
| | 30 | | 11G | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the ABS actuator and electric unit (control unit) and the harness connector E152.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector and the A/C auto amp harness connector.

| Harness connector | | A/C auto amp. harness connector | | Continuity |
|-------------------|--------------|---------------------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M31 | 12G | M50 | 1 | Existed |
| | 11G | | 21 | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the ABS actuator and electric unit (control unit) and the A/C auto amp.

NO >> Repair the main line between the harness connector M31 and the A/C auto amp.

MAIN LINE BETWEEN HVAC AND 4WD CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

MAIN LINE BETWEEN HVAC AND 4WD CIRCUIT

Diagnosis Procedure

INFOID:0000000011217029

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M84
 - Harness connector B101

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - A/C auto amp.
 - Harness connectors M84 and B101
2. Check the continuity between the A/C auto amp. harness connector and the harness connector.

| A/C auto amp. harness connector | | Harness connector | | Continuity |
|---------------------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M50 | 1 | M84 | 22 | Existed |
| | 21 | | 21 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the A/C auto amp. and the harness connector M84.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector terminals.

| Connector No. | Harness connector | | Continuity |
|---------------|-------------------|----|------------|
| | Terminal No. | | |
| B101 | 22 | 29 | Existed |
| | 21 | 28 | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the A/C auto amp. and the AWD control unit.

NO >> Repair the main line between the harness connector B101 and the AWD control unit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

MAIN LINE BETWEEN HVAC AND DLC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

MAIN LINE BETWEEN HVAC AND DLC CIRCUIT

Diagnosis Procedure

INFOID:000000011217030

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M84
 - Harness connector B101

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - A/C auto amp.
 - Harness connectors M84 and B101
2. Check the continuity between the A/C auto amp. harness connector and the harness connector.

| A/C auto amp. harness connector | | Harness connector | | Continuity |
|---------------------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M50 | 1 | M84 | 22 | Existed |
| | 21 | | 21 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the A/C auto amp. and the harness connector M84.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector terminals.

| Harness connector | | | Continuity |
|-------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| B101 | 22 | 29 | Existed |
| | 21 | 28 | Existed |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair the main line between the harness connector B101.

4. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector and the data link connector.

- Without around view monitor

| Harness connector | | Data link connector | | Continuity |
|-------------------|--------------|---------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M84 | 29 | M22 | 6 | Existed |
| | 28 | | 14 | Existed |

- With around view monitor

| Harness connector | | Data link connector | | Continuity |
|-------------------|--------------|---------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |

MAIN LINE BETWEEN HVAC AND DLC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

| | | | | |
|-----|----|-----|----|---------|
| M84 | 29 | M22 | 13 | Existed |
| | 28 | | 12 | Existed |

A

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the A/C auto amp. and the data link connector.

NO >> Repair the main line between the harness connector M84 and the data link connector.

B

C

D

E

F

G

H

I

J

K

L

LAN

N

O

P

MAIN LINE BETWEEN 4WD AND DLC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

MAIN LINE BETWEEN 4WD AND DLC CIRCUIT

Diagnosis Procedure

INFOID:000000011217031

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M84
 - Harness connector B101

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors M84 and B101.
2. Check the continuity between the harness connector terminals.

| Harness connector | | Continuity |
|-------------------|--------------|---------------|
| Connector No. | Terminal No. | |
| B101 | 22 | 29 Existed |
| | 21 | 28 Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the AWD control unit and the harness connector B101.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector and the data link connector.

- Without around view monitor

| Harness connector | | Data link connector | | Continuity |
|-------------------|--------------|---------------------|---------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M84 | 29 | M22 | 6 Existed | |
| | 28 | | 14 Existed | |

- With around view monitor

| Harness connector | | Data link connector | | Continuity |
|-------------------|--------------|---------------------|---------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M84 | 29 | M22 | 13 Existed | |
| | 28 | | 12 Existed | |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the AWD control unit and the data link connector.

NO >> Repair the main line between the harness connector M84 and the data link connector.

MAIN LINE BETWEEN DLC AND ADP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

MAIN LINE BETWEEN DLC AND ADP CIRCUIT

Diagnosis Procedure

INFOID:000000011217032

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M40
 - Harness connector B69

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors M40 and B69.
2. Check the continuity between the data link connector and harness connector.

| Data link connector | | Harness connector | | Continuity |
|---------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M22 | 6 | M40 | 88A | Existed |
| | 14 | | 87A | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the data link connector and the harness connector M40.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector terminals.

| Harness connector | | | Continuity |
|-------------------|--------------|-----|------------|
| Connector No. | Terminal No. | | |
| B69 | 88A | 86A | Existed |
| | 87A | 85A | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the data link connector and drive seat control unit.

NO >> Repair the main line between the harness connector B69 and the drive seat control unit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

MAIN LINE BETWEEN AVM AND RDR-R CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

MAIN LINE BETWEEN AVM AND RDR-R CIRCUIT

Diagnosis Procedure

INFOID:000000011217037

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M84
 - Harness connector B101

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Around view monitor control unit
 - Harness connectors M84 and B101
2. Check the continuity between the around view monitor control unit harness connector and the harness connector.

| Around view monitor control unit harness connector | | Harness connector | | Continuity |
|--|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M96 | 26 | M84 | 8 | Existed |
| | 24 | | 7 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the around view monitor control unit and the harness connector M84.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors B464 and B142.
2. Check the continuity between the harness connectors.

| Harness connector | | Harness connector | | Continuity |
|-------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| B101 | 8 | B142 | 7 | Existed |
| | 7 | | 6 | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the around view monitor control unit and the side radar RH.

NO >> Repair the main line between the harness connector B101 and B142.

MAIN LINE BETWEEN RDR-R AND RDR-L CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

MAIN LINE BETWEEN RDR-R AND RDR-L CIRCUIT

Diagnosis Procedure

INFOID:0000000011217034

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B140
 - Harness connector B49

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Harness connectors B464 and B142
 - Harness connectors B140 and B49
2. Check the continuity between the harness connectors.

| Harness connector | | Harness connector | | Continuity |
|-------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| B142 | 7 | B140 | 6 | Existed |
| | 6 | | 7 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the harness connector B142 and B140.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors B92 and B463.
2. Check the continuity between the harness connectors.

| Harness connector | | Harness connector | | Continuity |
|-------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| B49 | 6 | B92 | 7 | Existed |
| | 7 | | 6 | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the side radar RH and the side radar LH.

NO >> Repair the main line between the harness connector B49 and B92.

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

MAIN LINE BETWEEN RDR-L AND LASER CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

MAIN LINE BETWEEN RDR-L AND LASER CIRCUIT

Diagnosis Procedure

INFOID:000000011217035

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B40
 - Harness connector E34
 - Harness connector E5
 - Harness connector E207

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Harness connectors B92 and B463
 - Harness connectors B40 and E34
2. Check the continuity between the harness connectors.

| Harness connector | | Harness connector | | Continuity |
|-------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| B92 | 7 | B40 | 13 | Existed |
| | 6 | | 14 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the harness connector B92 and B40.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector E5 and E207.
2. Check the continuity between the harness connectors.

| Harness connector | | Harness connector | | Continuity |
|-------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E34 | 13 | E5 | 18 | Existed |
| | 14 | | 17 | Existed |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair the main line between the harness connector E34 and E5.

4.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector terminals.

| Harness connector | | | Continuity |
|-------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| E207 | 18 | 21 | Existed |
| | 17 | 20 | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the side radar LH and the ICC sensor.

NO >> Repair the main line between the harness connector E207 and the ICC sensor.

ECM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

ECM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:0000000011217039

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ECM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ECM.
2. Check the resistance between the ECM harness connector terminals.

| ECM harness connector | | | Resistance (Ω) |
|-----------------------|--------------|-----|-------------------------|
| Connector No. | Terminal No. | | |
| E32 | 124 | 123 | Approx. 108 – 132 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the ECM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ECM. Refer to [EC-188. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ECM. Refer to [EC-579. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ECM branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

IPDM-E BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

IPDM-E BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011217040

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the IPDM E/R for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of IPDM E/R.
2. Check the resistance between the IPDM E/R harness connector terminals.

| IPDM E/R harness connector | | | Resistance (Ω) |
|----------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| E119 | 29 | 28 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the IPDM E/R branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the IPDM E/R. Refer to [PCS-36, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the IPDM E/R. Refer to [PCS-37, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the IPDM E/R branch line.
NO >> Repair the power supply and the ground circuit.

TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

TCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:0000000011217041

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - TCM
 - Harness connector F32
 - Harness connector E2

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of TCM.
2. Check the resistance between the TCM harness connector terminals.

| TCM harness connector | | Resistance (Ω) |
|-----------------------|----------------------------|-----------------|
| Connector No. | Terminal No. | |
| F25 | 33 23 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the TCM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCM. Refer to [TM-178, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the TCM. Refer to [TM-198, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the TCM branch line.

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

ABS BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011217042

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ABS actuator and electric unit (control unit) for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ABS actuator and electric unit (control unit).
 2. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.
- Without around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | | Resistance (Ω) |
|---|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| E125 | 26 | 14 | Approx. 54 – 66 |

- With around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | | Resistance (Ω) |
|---|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| E130 | 19 | 30 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the ABS actuator and electric unit (control unit) branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ABS actuator and electric unit (control unit). Refer to [BRC-77, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ABS actuator and electric unit (control unit). Refer to [BRC-142, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ABS actuator and electric unit (control unit) branch line.
NO >> Repair the power supply and the ground circuit.

EPS/DAST 3 BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

EPS/DAST 3 BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:0000000011217043

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the power steering control module for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of power steering control module.
2. Check the resistance between the power steering control module harness connector terminals.

| Power steering control module harness connector | | | Resistance (Ω) |
|---|--------------|---|-----------------|
| Connector No. | Terminal No. | | |
| E62 | 8 | 7 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the power steering control module branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the power steering control module. Refer to [STC-23, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the power steering oil pump assembly. Refer to [STC-38, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the power steering control module branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

AV BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

AV BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011217045

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the AV control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of AV control unit.
2. Check the resistance between the AV control unit harness connector terminals.
 - With navigation system and without BOSE audio system

| AV control unit harness connector | | | Resistance (Ω) |
|-----------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M123 | 43 | 23 | Approx. 54 – 66 |

- With navigation system and BOSE audio system

| AV control unit harness connector | | | Resistance (Ω) |
|-----------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M162 | 43 | 23 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the AV control unit branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the AV control unit. Refer to [AV-166. "AV CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the AV control unit. Refer to [AV-179. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the AV control unit branch line.
NO >> Repair the power supply and the ground circuit.

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

[CAN]

< DTC/CIRCUIT DIAGNOSIS >

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

Diagnosis Procedure

INFOID:000000011217053

1. CHECK DTC

Check DTC of the CAN gateway with CONSULT.

Is U1010 or B2600 indicated?

- YES >> Perform a diagnosis of the indicated DTC.
- NO >> GO TO 2.

2. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the CAN gateway for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair the terminal and connector.

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of CAN gateway.
2. Check the resistance between the CAN gateway harness connector terminals.

| CAN gateway harness connector | | | Resistance (Ω) |
|-------------------------------|--------------|---|-------------------------|
| Connector No. | Terminal No. | | |
| M5 | 1 | 7 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 4.
- NO >> Repair the CAN gateway branch line (CAN communication circuit 1 side).

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the CAN gateway. Refer to [LAN-121. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the CAN gateway. Refer to [LAN-122. "Removal and Installation"](#).
- YES (Past error)>>Error was detected in the CAN gateway branch line (CAN communication circuit 1 side).
- NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

Diagnosis Procedure

INFOID:000000011217054

1. CHECK DTC

Check DTC of the CAN gateway with CONSULT.

Is U1010 or B2600 indicated?

- YES >> Perform a diagnosis of the indicated DTC.
- NO >> GO TO 2.

2. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors of the CAN gateway for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair the terminal and connector.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

| CAN gateway harness connector | | | Continuity |
|-------------------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| M5 | 4 | 6 | Existed |
| | 10 | 12 | Existed |

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair the CAN gateway branch line (CAN communication circuit 2 side).

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the CAN gateway. Refer to [LAN-121, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the CAN gateway. Refer to [LAN-122, "Removal and Installation"](#).
- YES (Past error)>>Error was detected in the CAN gateway branch line (CAN communication circuit 2 side).
- NO >> Repair the power supply and the ground circuit.

HVAC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

HVAC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011217049

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the A/C auto amp. for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/C auto amp.
2. Check the resistance between the A/C auto amp. harness connector terminals.

| A/C auto amp. harness connector | | | Resistance (Ω) |
|---------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M50 | 1 | 21 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the A/C auto amp. branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the A/C auto amp. Refer to [HAC-73, "A/C AUTO AMP. : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the A/C auto amp. Refer to [HAC-95, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the A/C auto amp. branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

PWBD BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

PWBD BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011217056

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Automatic back door control module
 - Harness connector B41
 - Harness connector M69

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of automatic back door control module.
2. Check the resistance between the automatic back door control module harness connector terminals.

| Automatic back door control module harness connector | | | Resistance (Ω) |
|--|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| B55 | 1 | 17 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the automatic back door control module branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the automatic back door control module. Refer to [DLK-171, "AUTOMATIC BACK DOOR CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the automatic back door control module. Refer to [DLK-311, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the automatic back door control module branch line.

NO >> Repair the power supply and the ground circuit.

4WD BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

4WD BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011217055

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the AWD control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of AWD control unit.
2. Check the resistance between the AWD control unit harness connector terminals.

| AWD control unit harness connector | | | Resistance (Ω) |
|------------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| B135 | 8 | 16 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the AWD control unit branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the AWD control unit. Refer to [DLN-46, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the AWD control unit. Refer to [DLN-58, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the AWD control unit branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

A-BAG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

A-BAG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011217044

WARNING:

- Before servicing, turn ignition switch OFF, disconnect battery negative terminal, and wait 3 minutes or more. (To discharge backup capacitor.)
- Never use unspecified tester or other measuring device.

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the air bag diagnosis sensor unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Replace the main harness.

2.CHECK AIR BAG DIAGNOSIS SENSOR UNIT

Check the air bag diagnosis sensor unit. Refer to [SRC-40, "Work Flow"](#).

Is the inspection result normal?

- YES >> Replace the main harness.
NO >> Replace parts whose air bag system has a malfunction.

DLC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

DLC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:0000000011217046

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the data link connector for damage, bend and loose connection (connector side and harness side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

| Data link connector | | | Resistance (Ω) |
|---------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M22 | 6 | 14 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES (Present error)>>Check CAN system type decision again.
YES (Past error)>>Error was detected in the data link connector branch line circuit.
NO >> Repair the data link connector branch line.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

Diagnosis Procedure

INFOID:000000011217047

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the data link connector for damage, bend and loose connection (connector side and harness side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

| Data link connector | | | Resistance (Ω) |
|---------------------|--------------|----|-------------------------|
| Connector No. | Terminal No. | | |
| M22 | 13 | 12 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the data link connector branch line circuit (CAN communication circuit 1 side).

NO >> Repair the data link connector branch line (CAN communication circuit 1 side).

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

Diagnosis Procedure

INFOID:0000000011217048

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the data link connector for damage, bend and loose connection (connector side and harness side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

| Data link connector | | | Resistance (Ω) |
|---------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M22 | 6 | 14 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES (Present error)>>Check CAN system type decision again.
YES (Past error)>>Error was detected in the data link connector branch line circuit (CAN communication circuit 2 side).
NO >> Repair the data link connector branch line (CAN communication circuit 2 side).

LAN

M&A BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

M&A BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011217050

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the combination meter for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of combination meter.
2. Check the resistance between the combination meter harness connector terminals.

| Combination meter harness connector | | | Resistance (Ω) |
|-------------------------------------|--------------|----|-------------------------|
| Connector No. | Terminal No. | | |
| M23 | 53 | 52 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the combination meter branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the combination meter. Refer to [MWI-59, "COMBINATION METER : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the combination meter. Refer to [MWI-78, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the combination meter branch line.
NO >> Repair the power supply and the ground circuit.

STRG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

STRG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:0000000011217051

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the steering angle sensor for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of steering angle sensor.
2. Check the resistance between the steering angle sensor harness connector terminals.

| Steering angle sensor harness connector | | | Resistance (Ω) |
|---|--------------|---|-----------------|
| Connector No. | Terminal No. | | |
| M54 | 5 | 2 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the steering angle sensor branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle sensor. Refer to [BRC-52. "Wiring Diagram"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering angle sensor. Refer to [BRC-145. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the steering angle sensor branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

BCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

BCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011217057

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the BCM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of BCM.
2. Check the resistance between the BCM harness connector terminals.

| BCM harness connector | | | Resistance (Ω) |
|-----------------------|--------------|----|-------------------|
| Connector No. | Terminal No. | | |
| M19 | 60 | 59 | Approx. 108 – 132 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the BCM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the BCM. Refer to [BCS-75. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the BCM. Refer to [BCS-82. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the BCM branch line.
NO >> Repair the power supply and the ground circuit.

ICC BRANCH LINE CIRCUIT

[CAN]

< DTC/CIRCUIT DIAGNOSIS >

ICC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011217062

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ADAS control unit
 - CAN gateway

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

| CAN gateway harness connector | | | Continuity |
|-------------------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| M5 | 4 | 6 | Existed |
| | 10 | 12 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair the root cause (CAN communication circuit 2 side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway.
2. Disconnect the connector of ADAS control unit.
3. Check the resistance between the ADAS control unit harness connector terminals.

| ADAS control unit harness connector | | | Resistance (Ω) |
|-------------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| B182 | 9 | 10 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the ADAS control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ADAS control unit. Refer to [DAS-84, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the ADAS control unit. Refer to [DAS-85, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the ADAS control unit branch line.

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

ADP BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

ADP BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011217060

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Driver seat control unit
 - Harness connector B200
 - Harness connector B54
 - CAN gateway

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

| CAN gateway harness connector | | | Continuity |
|-------------------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| M5 | 4 | 6 | Existed |
| | 10 | 12 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair the root cause (CAN communication circuit 2 side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of driver seat control unit.
2. Check the resistance between the driver seat control unit harness connector terminals.

| Driver seat control unit harness connector | | | Resistance (Ω) |
|--|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| B209 | 16 | 32 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the driver seat control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the driver seat control unit. Refer to [ADP-71. "DRIVER SEAT CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the driver seat control unit. Refer to [ADP-132. "Removal and Installation"](#).

YES (Past error)>>Error was detected in the driver seat control unit branch line.

NO >> Repair the power supply and the ground circuit.

AVM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

AVM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:0000000011217058

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Around view monitor control unit
 - ADAS control unit

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of ADAS control unit.
2. Check the continuity between the ADAS control unit harness connector terminals.

| ADAS control unit harness connector | | | Continuity |
|-------------------------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| M182 | 2 | 18 | Existed |
| | 5 | 6 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair the root cause (ITS communication circuit side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of ADAS control unit.
2. Disconnect the connector of around view monitor control unit.
3. Check the resistance between the around view monitor control unit harness connector terminals.

| Around view monitor control unit harness connector | | | Resistance (Ω) |
|--|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M96 | 26 | 24 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the around view monitor control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the around view monitor control unit. Refer to [AV-271, "AROUND VIEW MONITOR CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the around view monitor control unit. Refer to [AV-274, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the around view monitor control unit branch line.

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

RDR-R BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

RDR-R BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011217063

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Side radar RH
 - Harness connector B142
 - Harness connector B464
 - ADAS control unit

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of ADAS control unit.
2. Check the continuity between the ADAS control unit harness connector terminals.

| ADAS control unit harness connector | | | Continuity |
|-------------------------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| M182 | 2 | 18 | Existed |
| | 5 | 6 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair the root cause (ITS communication circuit side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of ADAS control unit.
2. Disconnect the connector of side radar RH.
3. Check the resistance between the side radar RH harness connector terminals.

| Side radar RH harness connector | | | Resistance (Ω) |
|---------------------------------|--------------|---|-------------------------|
| Connector No. | Terminal No. | | |
| B466 | 6 | 7 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the side radar RH branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the side radar RH. Refer to [DAS-170, "SIDE RADAR RH: Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the side radar RH. Refer to [DAS-188, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the side radar RH branch line.

NO >> Repair the power supply and the ground circuit.

RDR-L BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

RDR-L BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:0000000011217064

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Side radar LH
 - Harness connector B463
 - Harness connector B92
 - ADAS control unit

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of ADAS control unit.
2. Check the continuity between the ADAS control unit harness connector terminals.

| ADAS control unit harness connector | | | Continuity |
|-------------------------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| M182 | 2 | 18 | Existed |
| | 5 | 6 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair the root cause (ITS communication circuit side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of ADAS control unit.
2. Disconnect the connector of side radar LH.
3. Check the resistance between the side radar LH harness connector terminals.

| Side radar LH harness connector | | | Resistance (Ω) |
|---------------------------------|--------------|---|-----------------|
| Connector No. | Terminal No. | | |
| B465 | 6 | 7 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the side radar LH branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the side radar LH. Refer to [DAS-170, "SIDE RADAR LH : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the side radar LH. Refer to [DAS-188, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the side radar LH branch line.

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

LASER BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

LASER BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011217067

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ICC sensor
 - ADAS control unit

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of ADAS control unit.
2. Check the continuity between the ADAS control unit harness connector terminals.

| ADAS control unit harness connector | | | Continuity |
|-------------------------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| M182 | 2 | 18 | Existed |
| | 5 | 6 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair the root cause (ITS communication circuit side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of ADAS control unit.
2. Disconnect the connector of ICC sensor.
3. Check the resistance between the ICC sensor harness connector terminals.

| ICC sensor harness connector | | | Resistance (Ω) |
|------------------------------|--------------|---|-------------------|
| Connector No. | Terminal No. | | |
| E219 | 2 | 3 | Approx. 108 – 132 |

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the ICC sensor branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ICC sensor. Refer to [CCS-126, "ICC SENSOR : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the ICC sensor. Refer to [CCS-148, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the ICC sensor branch line.

NO >> Repair the power supply and the ground circuit.

CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

CAN COMMUNICATION CIRCUIT

Diagnosis Procedure

INFOID:0000000011217068

1.CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication circuit.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

| Data link connector | | Continuity |
|---------------------|--------------|-------------|
| Connector No. | Terminal No. | |
| M22 | 6 14 | Not existed |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause.

3.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

| Data link connector | | Ground | Continuity |
|---------------------|--------------|--------|-------------|
| Connector No. | Terminal No. | | |
| M22 | 13 | | Not existed |
| | 12 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check the harness and repair the root cause.

4.CHECK ECM AND BCM TERMINATION CIRCUIT

1. Remove the ECM and the BCM.
2. Check the resistance between the ECM terminals.

| ECM | | Resistance (Ω) |
|--------------|-----|-------------------|
| Terminal No. | | |
| 124 | 123 | Approx. 108 – 132 |

3. Check the resistance between the BCM terminals.

| BCM | | Resistance (Ω) |
|--------------|----|-------------------|
| Terminal No. | | |
| 60 | 59 | Approx. 108 – 132 |

Is the measurement value within the specification?

- YES >> GO TO 5.
NO >> Replace the ECM and/or the BCM.

5.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

Inspection result

Reproduced>>GO TO 6.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

6.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication circuit.

NOTE:

ECM and BCM have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

CAN COMMUNICATION CIRCUIT 1

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

CAN COMMUNICATION CIRCUIT 1

Diagnosis Procedure

INFOID:0000000011217069

1.CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication circuit 1.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

| Data link connector | | Continuity |
|---------------------|--------------|-------------|
| Connector No. | Terminal No. | |
| M22 | 13 | Not existed |
| | 12 | |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause.

3.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

| Data link connector | | Ground | Continuity |
|---------------------|--------------|--------|-------------|
| Connector No. | Terminal No. | | |
| M22 | 13 | | Not existed |
| | 12 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check the harness and repair the root cause.

4.CHECK ECM AND BCM TERMINATION CIRCUIT

1. Remove the ECM and the BCM.
2. Check the resistance between the ECM terminals.

| ECM | | Resistance (Ω) |
|--------------|-----|-------------------------|
| Terminal No. | | |
| 124 | 123 | Approx. 108 – 132 |

3. Check the resistance between the BCM terminals.

| BCM | | Resistance (Ω) |
|--------------|----|-------------------------|
| Terminal No. | | |
| 60 | 59 | Approx. 108 – 132 |

Is the measurement value within the specification?

- YES >> GO TO 5.
NO >> Replace the ECM and/or the BCM.

5.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

CAN COMMUNICATION CIRCUIT 1

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

Inspection result

Reproduced>>GO TO 6.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

6.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication circuit 1.

NOTE:

ECM and BCM have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

CAN COMMUNICATION CIRCUIT 2

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

CAN COMMUNICATION CIRCUIT 2

Diagnosis Procedure

INFOID:0000000011217070

1.CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication circuit 2.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

| Data link connector | | | Continuity |
|---------------------|--------------|----|-------------|
| Connector No. | Terminal No. | | |
| M22 | 6 | 14 | Not existed |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause.

3.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

| Data link connector | Terminal No. | Ground | Continuity |
|---------------------|--------------|--------|-------------|
| Connector No. | | | Continuity |
| M22 | 6 | | Not existed |
| | 14 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check the harness and repair the root cause.

4.CHECK CAN GATEWAY TERMINATION CIRCUIT

1. Remove the CAN gateway.
2. Check the resistance between the CAN gateway terminals.

| CAN gateway | | Resistance (Ω) |
|--------------|----|-------------------|
| Terminal No. | | |
| 4 | 10 | Approx. 108 – 132 |
| 6 | 12 | Approx. 108 – 132 |

Is the measurement value within the specification?

- YES >> GO TO 5.
NO >> Replace the CAN gateway.

5.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

Inspection result

- Reproduced>>GO TO 6.
Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

CAN COMMUNICATION CIRCUIT 2

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

6. CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication circuit 2.

NOTE:

CAN gateway has two termination circuits. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

ITS COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

ITS COMMUNICATION CIRCUIT

Diagnosis Procedure

INFOID:0000000011217071

1. CHECK CAN DIAGNOSIS

Check the CAN diagnosis results from CONSULT to see that the CAN communication circuit 1 and CAN communication circuit 2 have no malfunction.

Are the CAN communication 1 and CAN communication 2 circuits normal?

YES >> GO TO 2.

NO >> Check and repair CAN communication circuit 1 and/or CAN communication circuit 2.

2. CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ADAS control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the terminal and connector.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the ADAS control unit harness connector.
2. Check the continuity between the ADAS control unit harness connector terminals.

| ADAS control unit harness connector | | | Continuity |
|-------------------------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| M182 | 2 | 18 | Existed |
| | 5 | 6 | Existed |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair the ADAS control unit branch line. (ITS communication circuit side).

4. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

1. Disconnect the following harness connectors.
 - Around view monitor control unit
 - Side radar RH
 - Side radar LH
 - ICC sensor
2. Check the continuity between the ADAS control unit harness connector terminals.

| ADAS control unit harness connector | | | Continuity |
|-------------------------------------|--------------|---|-------------|
| Connector No. | Terminal No. | | |
| M182 | 2 | 5 | Not existed |

Is the inspection result normal?

YES >> GO TO 5.

NO >> Check the harness and repair the root cause.

5. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the ADAS control unit harness connector and the ground.

| ADAS control unit harness connector | | Ground | Continuity |
|-------------------------------------|--------------|--------|-------------|
| Connector No. | Terminal No. | | |
| M182 | 2 | | Not existed |
| | 5 | | Not existed |

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

ITS COMMUNICATION CIRCUIT

[CAN]

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES >> GO TO 6.
- NO >> Check the harness and repair the root cause.

6.CHECK TERMINATION CIRCUIT

1. Remove the ADAS control unit.
2. Check the resistance between the ADAS control unit terminals.

| ADAS control unit | | Resistance (Ω) |
|-------------------|---|-------------------------|
| Terminal No. | | |
| 2 | 5 | Approx. 108 – 132 |
| 18 | 6 | |

Is the inspection result normal?

- YES >> GO TO 7.
- NO >> Replace the ADAS control unit.

7.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

Inspection result

- Reproduced>>GO TO 8.
- Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

8.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of ITS communication circuit.
NOTE:
ADAS control unit and ICC sensor have a termination circuit. Check other units first.
4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

- Reproduced>>Connect the connector. Check other units as per the above procedure.
- Non-reproduced>>Replace the unit whose connector was disconnected.

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000011578119

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P


LAN

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000011217073




- ① CAN gateway
- Ⓐ Left side of glove box

SYSTEM

System Description

INFOID:000000011217074

SYSTEM DIAGRAM



SYSTEM DESCRIPTION

- The CAN gateway system communicates between two CAN communication circuits.
- This system selects and transmits only necessary information.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

DIAGNOSIS SYSTEM (CAN GATEWAY)

< SYSTEM DESCRIPTION >

[CAN GATEWAY]

DIAGNOSIS SYSTEM (CAN GATEWAY)

CONSULT Function

INFOID:000000011217075

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with CAN gateway.

| Diagnosis mode | Function Description |
|--------------------------|--|
| Ecu Identification | The CAN gateway part number is displayed. |
| Self Diagnostic Result | Displays the diagnosis results judged by CAN gateway. |
| CAN Diag Support Monitor | The results of transmit/receive diagnosis of CAN communication can be read. |
| Configuration | <ul style="list-style-type: none">• Read and save the vehicle specification.• Write the vehicle specification when replacing CAN gateway. |

ECU IDENTIFICATION

The CAN gateway part number is displayed.

SELF DIAGNOSTIC RESULT

Refer to [LAN-112, "DTC Index"](#).

- When "CRNT" is displayed on self-diagnosis result
 - The system is presently malfunctioning.
- When "PAST" is displayed on self-diagnosis result
 - System malfunction in the past is detected, but the system is presently normal.

Freeze Frame Data (FFD)

When DTC is detected, a vehicle state shown below is recorded and displayed on CONSULT.

| Item name | Display item |
|-------------------------|---|
| IGN counter (0 – 39) | <p>The number of times that ignition switch is turned ON after the DTC is detected is displayed.</p> <ul style="list-style-type: none">• When "0" is displayed: It indicates that the system is presently malfunctioning.• When except "0" is displayed: It indicates that system malfunction in the past is detected, but the system is presently normal. <p>NOTE: Each time when ignition switch is turned OFF to ON, numerical number increases in 1 → 2 → 3...38 → 39. When the operation number of times exceeds 39, the number do not increase and "39" is displayed until self-diagnosis result is erased.</p> |

CAN DIAG SUPPORT MONITOR

The results of transmit/receive diagnosis of CAN communication can be read.

CONFIGURATION

| Function | Description |
|----------------------------|--|
| Read / Write Configuration | Before Replace ECU <ul style="list-style-type: none">• Reads the vehicle configuration of current CAN gateway.• Saves the read vehicle configuration. |
| | After Replace ECU <ul style="list-style-type: none">• Writes the vehicle configuration with saved data. |
| Manual Configuration | Writes the vehicle configuration with manual selection. |

CAUTION:

Follow the instructions listed below. Failure to do this may cause malfunctions to the CAN gateway.:

- When replacing CAN gateway, you must perform "Read / Write Configuration" or "Manual Configuration" with CONSULT.
- Complete the procedure of "Read / Write Configuration" or "Manual Configuration" in order.
- If you set incorrect "Read / Write Configuration" or "Manual Configuration", incidents might occur.
- Configuration is different for each vehicle model. Confirm configuration of each vehicle model.
- Never perform "Read / Write Configuration" or "Manual Configuration" except for new CAN gateway.


ECU DIAGNOSIS INFORMATION

CAN GATEWAY

Reference Value

INFOID:0000000011217076

TERMINAL LAYOUT



PHYSICAL VALUES

| Terminal No. (Wire color) | | Description | | Condition | Standard value | Reference value (Approx.) |
|------------------------------|--------|-------------------------------------|------------------|---------------------|----------------|------------------------------|
| + | - | Signal name | Input/ Output | | | |
| 1 (L) | — | CAN-H (CAN communication circuit 1) | Input/ Output | — | — | — |
| 3 (BG) | Ground | Battery power supply | Input | Ignition switch OFF | 6 - 16 V | Battery voltage |
| 4 (L) | — | CAN-H (CAN communication circuit 2) | Input/ Output | — | — | — |
| 5 (B) | Ground | Ground | — | Ignition switch ON | — | 0 V |
| 6 (L) | — | CAN-H (CAN communication circuit 2) | Input/ Output | — | — | — |
| 7 (P) | — | CAN-L (CAN communication circuit 1) | Input/ Output | — | — | — |
| 9 (BG) | Ground | Ignition power supply | Input | Ignition switch ON | 4.5 - 16 V | Battery voltage |
| 10 (P) | — | CAN-L (CAN communication circuit 2) | Input/ Output | — | — | — |
| 11 (B) | Ground | Ground | — | Ignition switch ON | — | 0 V |
| 12 (P) | — | CAN-L (CAN communication circuit 2) | Input/ Output | — | — | — |

LAN

DTC Inspection Priority Chart

INFOID:0000000011217077

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

| Priority | DTC |
|----------|---|
| 1 | <ul style="list-style-type: none"> B2600: CONFIG ERROR U1010: CONTROL UNIT(CAN) |
| 2 | U1000: CAN COMM CIRCUIT |

CAN GATEWAY

< ECU DIAGNOSIS INFORMATION >

[CAN GATEWAY]

DTC Index

INFOID:000000011217078

| DTC | | Reference |
|---|----------------|-------------------------|
| No DTC is detected. Further testing may be required. | | — |
| U1000: CAN COMM CIRCUIT | | LAN-117 |
| U1010: CONTROL UNIT(CAN) | | LAN-118 |
| B2600: CONFIG ERROR | WRONG DATA | LAN-119 |
| | NOT CONFIGURED | |


WIRING DIAGRAM

CAN GATEWAY SYSTEM

Wiring Diagram

INFOID:0000000011217079

CAN GATEWAY SYSTEM




A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

AAMWA1468GB

CAN GATEWAY SYSTEM CONNECTORS

| | |
|-----------------|------------------|
| Connector No. | M3 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2N | BG | - |

| | |
|-----------------|------------------|
| Connector No. | M4 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 8P | BG | - |

| | |
|-----------------|-------------|
| Connector No. | M5 |
| Connector Name | CAN GATEWAY |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | CAN-H |
| 2 | - | - |
| 3 | BG | BATTERY |
| 4 | L | CAN-H |
| 5 | B | GND |
| 6 | L | CAN-H |
| 7 | P | CAN-L |
| 8 | - | - |
| 9 | BG | IGNITION |
| 10 | P | CAN-L |
| 11 | B | GND |
| 12 | P | CAN-L |

BASIC INSPECTION

ADDITIONAL SERVICE WHEN REPLACING CAN GATEWAY

Description

INFOID:0000000011217080

BEFORE REPLACEMENT

When replacing CAN gateway, save or print current vehicle specification with CONSULT configuration before replacement. Refer to [LAN-115. "Work Procedure"](#).

NOTE:

If "Before Replace ECU" of "Read / Write Configuration" can not be used, use the "Manual Configuration" after replacing CAN gateway.

AFTER REPLACEMENT

CAUTION:

Follow the instructions listed below. Failure to do this may cause malfunctions to the CAN gateway.:

- When replacing CAN gateway, you must perform "Read / Write Configuration" or "Manual Configuration" with CONSULT.
- Complete the procedure of "Read / Write Configuration" or "Manual Configuration" in order.
- If you set incorrect "Read / Write Configuration" or "Manual Configuration", incidents might occur.
- Configuration is different for each vehicle model. Confirm configuration of each vehicle model.
- Never perform "Read / Write Configuration" or "Manual Configuration" except for new CAN gateway.

Work Procedure

INFOID:0000000011217081

1. SAVING VEHICLE SPECIFICATION

ⓂCONSULT Configuration

Perform "Before Replace ECU" of "Read / Write Configuration" to save or print current vehicle specification. Refer to [LAN-115. "Description"](#).

NOTE:

If "Before Replace ECU" of "Read / Write Configuration" can not be used, use the "Manual Configuration" after replacing CAN gateway.

>> GO TO 2.

2. REPLACE CAN GATEWAY

Replace CAN gateway. Refer to [LAN-122. "Removal and Installation"](#).

>> GO TO 3.

3. WRITING VEHICLE SPECIFICATION

ⓂCONSULT Configuration

Perform "After Replace ECU" of "Read / Write Configuration" or "Manual Configuration" to write vehicle specification. Refer to [LAN-116. "Work Procedure"](#).

>> WORK END

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

CONFIGURATION (CAN GATEWAY)

Work Procedure

INFOID:000000011217082

1. WRITING MODE SELECTION

ⓅCONSULT Configuration
Select "Re/programming, Configuration" of CAN gateway.

When writing saved data>>GO TO 2.
When writing manually>>GO TO 3.

2. PERFORM "AFTER REPLACE ECU" OF "READ / WRITE CONFIGURATION"

ⓅCONSULT Configuration
Perform "After Replace ECU" of "Read / Write Configuration".

>> GO TO 4.

3. PERFORM "MANUAL CONFIGURATION"

ⓅCONSULT Configuration

1. Select "Manual Configuration".
2. Touch "Next".
3. Touch "OK".
4. Check that the configuration has been successfully written and touch "End".

>> GO TO 4.

4. CHECK ALL ECU SELF-DIAGNOSIS RESULTS

1. Erase all ECU self-diagnosis results using CONSULT.
2. Turn the ignition switch OFF.
3. Turn the ignition switch ON and wait for 2 seconds or more.
4. Check that all ECU self-diagnosis results have no DTC (e.g. U1000 and U1001) of CAN communication.

>> WORK END

DTC/CIRCUIT DIAGNOSIS

U1000 CAN COMM CIRCUIT

DTC Description

INFOID:000000011786836

DESCRIPTION

CAN (Controller Area Network) is a serial communication line for real-time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independently). In CAN communication, control units are connected with 2 communication lines (CAN-H, CAN-L) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Signal Chart. Refer to [LAN-37. "CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart"](#).

DTC DETECTION LOGIC

| DTC | CONSULT screen terms (Trouble diagnosis contents) | DTC detection condition | |
|-------|--|-------------------------|---|
| U1000 | CAN COMM CIRCUIT (CAN communication circuit) | Diagnosis condition | Ignition switch ON |
| | | Signal (terminal) | CAN communication signal |
| | | Threshold | CAN gateway is not transmitting or receiving CAN communication signal |
| | | Diagnosis delay time | Continuously for 2 seconds or more |

POSSIBLE CAUSE

CAN communication system

FAIL-SAFE

Only the CAN signal transmission of control unit which cannot communicate cannot be transmitted

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

With CONSULT

1. Turn ignition switch ON and wait at least 2 seconds or more.
2. Select "Self Diagnostic Result" mode of "CAN GATEWAY" using CONSULT.
3. Check DTC.

Is DTC U1000 detected?

YES >> Proceed to [LAN-117. "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: [GI-42. "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

Diagnosis Procedure

INFOID:000000011786837

1. PERFORM DTC CONFIRMATION PROCEDURE AGAIN

1. Turn ignition switch ON.
2. Erase DTC.
3. Perform DTC confirmation procedure again. Refer to [LAN-117. "DTC Description"](#).
4. Check DTC.

Is DTC U1000 detected again?

YES >> Perform trouble diagnosis procedure for CAN communication system. Refer to [LAN-21. "Trouble Diagnosis Flow Chart"](#).

NO >> INSPECTION END

U1010 CONTROL UNIT (CAN)

DTC Description

INFOID:000000011786838

DESCRIPTION

CAN (Controller Area Network) is a serial communication line for real-time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independently). In CAN communication, control units are connected with 2 communication lines (CAN-H, CAN-L) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Signal Chart. Refer to [LAN-37. "CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart"](#).

DTC DETECTION LOGIC

| DTC | CONSULT screen terms (Trouble diagnosis contents) | DTC detection condition | |
|-------|--|-------------------------|---|
| U1010 | CONTROL UNIT (CAN) [Control unit (CAN)] | Diagnosis condition | Ignition switch ON |
| | | Signal (terminal) | — |
| | | Threshold | CAN controller initial diagnosis abnormality of CAN gateway |
| | | Diagnosis delay time | Continuously for 2 seconds or more |

POSSIBLE CAUSE

CAN gateway

FAIL-SAFE

Transmission and reception of the signal between CAN communication circuit 1 and CAN communication circuit 2 are stopped

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

With CONSULT

1. Turn ignition switch ON and wait at least 2 seconds or more.
2. Select "Self Diagnostic Result" mode of "CAN GATEWAY" using CONSULT.
3. Check DTC.

Is DTC U1010 detected?

- YES >> Proceed to [LAN-118. "Diagnosis Procedure"](#).
 NO-1 >> To check malfunction symptom before repair: [GI-42. "Intermittent Incident"](#).
 NO-2 >> Confirmation after repair: INSPECTION END

Diagnosis Procedure

INFOID:000000011786839

1. PERFORM DTC CONFIRMATION PROCEDURE AGAIN

1. Turn ignition switch ON.
2. Erase DTC.
3. Perform DTC confirmation procedure again. Refer to [LAN-118. "DTC Description"](#).
4. Check DTC.

Is DTC U1010 detected again?

- YES >> Replace CAN gateway. Refer to [LAN-122. "Removal and Installation"](#).
 NO >> INSPECTION END

B2600 CONFIG ERROR

< DTC/CIRCUIT DIAGNOSIS >

[CAN GATEWAY]

B2600 CONFIG ERROR

DTC Description

INFOID:000000011786840

DTC DETECTION LOGIC

| DTC | CONSULT screen terms (Trouble diagnosis contents) | | DTC detection condition | |
|-------|--|----------------------------|---------------------------------------|---|
| | | | Diagnosis condition | Ignition switch ON |
| B2600 | CONFIG ERROR (Configuration error) | WRONG DATA (Wrong data) | Signal (terminal) | — |
| | | | Threshold | Configuration data abnormality of CAN gateway |
| | | | Diagnosis delay time | Continuously for 2 seconds or more |
| | | | Diagnosis condition | Ignition switch ON |
| | NOT CONFIGURED (Not configured) | Signal (terminal) | — | |
| | | Threshold | No data are stored in the CAN gateway | |
| | | Diagnosis delay time | Continuously for 2 seconds or more | |

POSSIBLE CAUSE

- Configuration is incomplete
- CAN gateway

FAIL-SAFE

Transmission and reception of the signal between CAN communication circuit 1 and CAN communication circuit 2 are stopped

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

④ With CONSULT

1. Turn ignition switch ON and wait at least 2 seconds or more.
2. Select "Self Diagnostic Result" mode of "CAN GATEWAY" using CONSULT.
3. Check DTC.

Is DTC B2600 detected?

YES-1 ("CONFIG ERROR WRONG DATA" is detected.)>>Proceed to [LAN-119. "WRONG DATA : Diagnosis Procedure"](#).

YES-2 ("CONFIG ERROR NOT CONFIGURED" is detected.)>>Proceed to [LAN-119. "NOT CONFIGURED : Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: [GI-42. "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

WRONG DATA

WRONG DATA : Diagnosis Procedure

INFOID:000000011786841

1. PERFORM DTC CONFIRMATION PROCEDURE AGAIN

1. Turn ignition switch ON.
2. Erase DTC.
3. Perform DTC confirmation procedure again. Refer to [LAN-119. "DTC Description"](#).
4. Check DTC.

Is DTC B2600 detected again?

YES >> Replace CAN gateway. Refer to [LAN-122. "Removal and Installation"](#).

NO >> INSPECTION END

NOT CONFIGURED

NOT CONFIGURED : Diagnosis Procedure

INFOID:000000011786842

1. PERFORM CONFIGURATION OF CAN GATEWAY

B2600 CONFIG ERROR

< DTC/CIRCUIT DIAGNOSIS >

[CAN GATEWAY]

Perform CAN gateway configuration. Refer to [LAN-116, "Work Procedure"](#).

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE AGAIN

1. Turn ignition switch ON.
2. Perform DTC confirmation procedure again. Refer to [LAN-119, "DTC Description"](#).
3. Check DTC.

Is DTC B2600 detected again?

- YES >> Replace CAN gateway. Refer to [LAN-122, "Removal and Installation"](#).
NO >> INSPECTION END

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN GATEWAY]

POWER SUPPLY AND GROUND CIRCUIT

Diagnosis Procedure

INFOID:0000000011217092

1. CHECK FUSE

Check that the following fuse are not blown.

| Signal name | Fuse No. |
|-----------------------|----------|
| Battery power supply | 25 |
| Ignition power supply | 31 |

Is the fuse fusing?

YES >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.

NO >> GO TO 2.

2. CHECK POWER SUPPLY CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the connector of CAN gateway.
3. Check voltage between CAN gateway harness connector and ground.

| Terminals | | Condition | Standard voltage | Reference voltage (Approx.) |
|-------------|----------|-----------------|------------------|-----------------------------|
| (+) | (-) | | | |
| CAN gateway | | Ignition switch | | |
| Connector | Terminal | | | |
| M5 | 3 | OFF | 6 - 16 V | Battery voltage |
| | 9 | ON | 4.5 - 16 V | Battery voltage |

Is the measurement value normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3. CHECK GROUND CIRCUIT

Check continuity between CAN gateway harness connector and ground.

| CAN gateway | | Ground | Continuity |
|-------------|----------|--------|------------|
| Connector | Terminal | | |
| M5 | 5 | | Existed |
| | 11 | | |

Does continuity exist?

YES >> INSPECTION END

NO >> Repair harness or connector.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

REMOVAL AND INSTALLATION

CAN GATEWAY

Removal and Installation


INFOID:000000011217093

CAUTION:

Before replacing CAN gateway, perform “Before Replace ECU” of “Read / Write Configuration” to save or print current vehicle specification. Refer to [LAN-115, "Description"](#).

REMOVAL

1. Remove the glove box assembly and housing. Refer to [IP-25, "Removal and Installation"](#).
2. Remove the CAN gateway ① from the bracket by sliding it as shown.
3. Disconnect the harness connector ① from the CAN gateway and remove the CAN gateway.

**INSTALLATION**

Installation is in the reverse order of removal.

CAUTION:

To prevent malfunction, be sure to perform “After Replace ECU” of “Read / Write Configuration” or “Manual Configuration” when replacing CAN gateway. Refer to [LAN-116, "Work Procedure"](#).

MAIN LINE BETWEEN IPDM-E AND ABS CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

DTC/CIRCUIT DIAGNOSIS

MAIN LINE BETWEEN IPDM-E AND ABS CIRCUIT

Diagnosis Procedure

INFOID:000000011730853

1. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
 - ECM
 - IPDM E/R
 - ABS actuator and electric unit (control unit)
4. Check the continuity between the IPDM E/R harness connector and the ABS actuator and electric unit (control unit) harness connector.
 - Without around view monitor system

| IPDM E/R harness connector | | ABS actuator and electric unit (control unit) harness connector | | Continuity |
|----------------------------|--------------|---|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E119 | 29 | E125 | 26 | Existed |
| | 28 | | 14 | Existed |

- With around view monitor system

| IPDM E/R harness connector | | ABS actuator and electric unit (control unit) harness connector | | Continuity |
|----------------------------|--------------|---|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E119 | 29 | E130 | 19 | Existed |
| | 28 | | 30 | Existed |

Is the inspection result normal?

- YES (Present error)>>Check CAN system type decision again.
- YES (Past error)>>Error was detected in the main line between the IPDM E/R and the ABS actuator and electric unit (control unit).
- NO >> Repair the main line between the IPDM E/R and the ABS actuator and electric unit (control unit).

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

MAIN LINE BETWEEN ABS AND HVAC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

MAIN LINE BETWEEN ABS AND HVAC CIRCUIT

Diagnosis Procedure

INFOID:000000011730854

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector E152
 - Harness connector M31

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - ABS actuator and electric unit (control unit)
 - Harness connectors E152 and M31.
2. Check the continuity between the ABS actuator and electric unit (control unit) harness connector and the harness connector.
 - Without around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | Harness connector | | Continuity |
|---|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E125 | 26 | E152 | 12G | Existed |
| | 14 | | 11G | Existed |

- With around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | Harness connector | | Continuity |
|---|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E130 | 19 | E152 | 12G | Existed |
| | 30 | | 11G | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the ABS actuator and electric unit (control unit) and the harness connector E152.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector and the A/C auto amp harness connector.

| Harness connector | | A/C auto amp. harness connector | | Continuity |
|-------------------|--------------|---------------------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M31 | 12G | M50 | 1 | Existed |
| | 11G | | 21 | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the ABS actuator and electric unit (control unit) and the A/C auto amp.

NO >> Repair the main line between the harness connector M31 and the A/C auto amp.

MAIN LINE BETWEEN HVAC AND DLC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

MAIN LINE BETWEEN HVAC AND DLC CIRCUIT

Diagnosis Procedure

INFOID:000000011730856

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M84
 - Harness connector B101

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - A/C auto amp.
 - Harness connectors M84 and B101
2. Check the continuity between the A/C auto amp. harness connector and the harness connector.

| A/C auto amp. harness connector | | Harness connector | | Continuity |
|---------------------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M50 | 1 | M84 | 22 | Existed |
| | 21 | | 21 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the A/C auto amp. and the harness connector M84.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector terminals.

| Harness connector | | | Continuity |
|-------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| B101 | 22 | 29 | Existed |
| | 21 | 28 | Existed |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair the main line between the harness connector B101.

4. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector and the data link connector.

- Without around view monitor

| Harness connector | | Data link connector | | Continuity |
|-------------------|--------------|---------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M84 | 29 | M22 | 6 | Existed |
| | 28 | | 14 | Existed |

- With around view monitor

| Harness connector | | Data link connector | | Continuity |
|-------------------|--------------|---------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

MAIN LINE BETWEEN HVAC AND DLC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

| | | | | |
|-----|----|-----|----|---------|
| M84 | 29 | M22 | 13 | Existed |
| | 28 | | 12 | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the A/C auto amp. and the data link connector.

NO >> Repair the main line between the harness connector M84 and the data link connector.

ECM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

ECM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011730865

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ECM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ECM.
2. Check the resistance between the ECM harness connector terminals.

| ECM harness connector | | | Resistance (Ω) |
|-----------------------|--------------|-----|-------------------|
| Connector No. | Terminal No. | | |
| E32 | 124 | 123 | Approx. 108 – 132 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the ECM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ECM. Refer to [EC-188. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ECM. Refer to [EC-579. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ECM branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

IPDM-E BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

IPDM-E BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011730866

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the IPDM E/R for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of IPDM E/R.
2. Check the resistance between the IPDM E/R harness connector terminals.

| IPDM E/R harness connector | | | Resistance (Ω) |
|----------------------------|--------------|----|-------------------------|
| Connector No. | Terminal No. | | |
| E119 | 29 | 28 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the IPDM E/R branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the IPDM E/R. Refer to [PCS-36, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the IPDM E/R. Refer to [PCS-37, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the IPDM E/R branch line.
NO >> Repair the power supply and the ground circuit.

TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

TCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011730867

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - TCM
 - Harness connector F32
 - Harness connector E2

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of TCM.
2. Check the resistance between the TCM harness connector terminals.

| TCM harness connector | | Resistance (Ω) |
|-----------------------|----------------------------|-----------------|
| Connector No. | Terminal No. | |
| F25 | 33 23 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the TCM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCM. Refer to [TM-178, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the TCM. Refer to [TM-198, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the TCM branch line.

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

ABS BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011730868

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ABS actuator and electric unit (control unit) for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ABS actuator and electric unit (control unit).
 2. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.
- Without around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | | Resistance (Ω) |
|---|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| E125 | 26 | 14 | Approx. 54 – 66 |

- With around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | | Resistance (Ω) |
|---|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| E130 | 19 | 30 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the ABS actuator and electric unit (control unit) branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ABS actuator and electric unit (control unit). Refer to [BRC-77, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ABS actuator and electric unit (control unit). Refer to [BRC-142, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ABS actuator and electric unit (control unit) branch line.
NO >> Repair the power supply and the ground circuit.

EPS/DAST 3 BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

EPS/DAST 3 BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011730869

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the power steering control module for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of power steering control module.
2. Check the resistance between the power steering control module harness connector terminals.

| Power steering control module harness connector | | | Resistance (Ω) |
|---|--------------|---|-----------------|
| Connector No. | Terminal No. | | |
| E62 | 8 | 7 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the power steering control module branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the power steering control module. Refer to [STC-23, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the power steering oil pump assembly. Refer to [STC-38, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the power steering control module branch line.
NO >> Repair the power supply and the ground circuit.

HVAC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

HVAC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011730873

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the A/C auto amp. for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/C auto amp.
2. Check the resistance between the A/C auto amp. harness connector terminals.

| A/C auto amp. harness connector | | | Resistance (Ω) |
|---------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M50 | 1 | 21 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the A/C auto amp. branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the A/C auto amp. Refer to [HAC-73, "A/C AUTO AMP. : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the A/C auto amp. Refer to [HAC-95, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the A/C auto amp. branch line.
NO >> Repair the power supply and the ground circuit.

A-BAG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

A-BAG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011730876

WARNING:

- Before servicing, turn ignition switch OFF, disconnect battery negative terminal, and wait 3 minutes or more. (To discharge backup capacitor.)
- Never use unspecified tester or other measuring device.

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the air bag diagnosis sensor unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Replace the main harness.

2. CHECK AIR BAG DIAGNOSIS SENSOR UNIT

Check the air bag diagnosis sensor unit. Refer to [SRC-40, "Work Flow"](#).

Is the inspection result normal?

- YES >> Replace the main harness.
NO >> Replace parts whose air bag system has a malfunction.

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

DLC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

DLC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011730877

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the data link connector for damage, bend and loose connection (connector side and harness side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

| Data link connector | | | Resistance (Ω) |
|---------------------|--------------|----|-------------------------|
| Connector No. | Terminal No. | | |
| M22 | 6 | 14 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES (Present error)>>Check CAN system type decision again.
YES (Past error)>>Error was detected in the data link connector branch line circuit.
NO >> Repair the data link connector branch line.

M&A BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011730880

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the combination meter for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of combination meter.
2. Check the resistance between the combination meter harness connector terminals.

| Combination meter harness connector | | | Resistance (Ω) |
|-------------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M23 | 53 | 52 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the combination meter branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the combination meter. Refer to [MWI-59, "COMBINATION METER : Diagnosis Procedure"](#) .

Is the inspection result normal?

- YES (Present error)>>Replace the combination meter. Refer to [MWI-78, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the combination meter branch line.
 NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

STRG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

STRG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011730881

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the steering angle sensor for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of steering angle sensor.
2. Check the resistance between the steering angle sensor harness connector terminals.

| Steering angle sensor harness connector | | | Resistance (Ω) |
|---|--------------|---|-------------------------|
| Connector No. | Terminal No. | | |
| M54 | 5 | 2 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the steering angle sensor branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle sensor. Refer to [BRC-52, "Wiring Diagram"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering angle sensor. Refer to [BRC-145, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the steering angle sensor branch line.
NO >> Repair the power supply and the ground circuit.

BCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

BCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011730882

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the BCM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of BCM.
2. Check the resistance between the BCM harness connector terminals.

| BCM harness connector | | | Resistance (Ω) |
|-----------------------|--------------|----|-------------------|
| Connector No. | Terminal No. | | |
| M19 | 60 | 59 | Approx. 108 – 132 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the BCM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the BCM. Refer to [BCS-75, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the BCM. Refer to [BCS-82, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the BCM branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

CAN COMMUNICATION CIRCUIT

Diagnosis Procedure

INFOID:000000011730894

1.CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication circuit.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

| Data link connector | | | Continuity |
|---------------------|--------------|----|-------------|
| Connector No. | Terminal No. | | |
| M22 | 6 | 14 | Not existed |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause.

3.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

| Data link connector | | Ground | Continuity |
|---------------------|--------------|--------|-------------|
| Connector No. | Terminal No. | | |
| M22 | 13 | | Not existed |
| | 12 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check the harness and repair the root cause.

4.CHECK ECM AND BCM TERMINATION CIRCUIT

1. Remove the ECM and the BCM.
2. Check the resistance between the ECM terminals.

| ECM | | Resistance (Ω) |
|--------------|-----|-------------------|
| Terminal No. | | |
| 124 | 123 | Approx. 108 – 132 |

3. Check the resistance between the BCM terminals.

| BCM | | Resistance (Ω) |
|--------------|----|-------------------|
| Terminal No. | | |
| 60 | 59 | Approx. 108 – 132 |

Is the measurement value within the specification?

- YES >> GO TO 5.
NO >> Replace the ECM and/or the BCM.

5.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

Inspection result

Reproduced>>GO TO 6.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

6.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication circuit.

NOTE:

ECM and BCM have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

MAIN LINE BETWEEN IPDM-E AND ABS CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

DTC/CIRCUIT DIAGNOSIS

MAIN LINE BETWEEN IPDM-E AND ABS CIRCUIT

Diagnosis Procedure

INFOID:000000011730900

1. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
 - ECM
 - IPDM E/R
 - ABS actuator and electric unit (control unit)
4. Check the continuity between the IPDM E/R harness connector and the ABS actuator and electric unit (control unit) harness connector.
 - Without around view monitor system

| IPDM E/R harness connector | | ABS actuator and electric unit (control unit) harness connector | | Continuity |
|----------------------------|--------------|---|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E119 | 29 | E125 | 26 | Existed |
| | 28 | | 14 | Existed |

- With around view monitor system

| IPDM E/R harness connector | | ABS actuator and electric unit (control unit) harness connector | | Continuity |
|----------------------------|--------------|---|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E119 | 29 | E130 | 19 | Existed |
| | 28 | | 30 | Existed |

Is the inspection result normal?

- YES (Present error)>>Check CAN system type decision again.
- YES (Past error)>>Error was detected in the main line between the IPDM E/R and the ABS actuator and electric unit (control unit).
- NO >> Repair the main line between the IPDM E/R and the ABS actuator and electric unit (control unit).

MAIN LINE BETWEEN ABS AND HVAC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

MAIN LINE BETWEEN ABS AND HVAC CIRCUIT

Diagnosis Procedure

INFOID:000000011730901

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector E152
 - Harness connector M31

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - ABS actuator and electric unit (control unit)
 - Harness connectors E152 and M31.
2. Check the continuity between the ABS actuator and electric unit (control unit) harness connector and the harness connector.
 - Without around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | Harness connector | | Continuity |
|---|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E125 | 26 | E152 | 12G | Existed |
| | 14 | | 11G | Existed |

- With around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | Harness connector | | Continuity |
|---|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E130 | 19 | E152 | 12G | Existed |
| | 30 | | 11G | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the ABS actuator and electric unit (control unit) and the harness connector E152.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector and the A/C auto amp harness connector.

| Harness connector | | A/C auto amp. harness connector | | Continuity |
|-------------------|--------------|---------------------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M31 | 12G | M50 | 1 | Existed |
| | 11G | | 21 | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the ABS actuator and electric unit (control unit) and the A/C auto amp.

NO >> Repair the main line between the harness connector M31 and the A/C auto amp.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

MAIN LINE BETWEEN HVAC AND DLC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

MAIN LINE BETWEEN HVAC AND DLC CIRCUIT

Diagnosis Procedure

INFOID:000000011730903

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M84
 - Harness connector B101

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - A/C auto amp.
 - Harness connectors M84 and B101
2. Check the continuity between the A/C auto amp. harness connector and the harness connector.

| A/C auto amp. harness connector | | Harness connector | | Continuity |
|---------------------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M50 | 1 | M84 | 22 | Existed |
| | 21 | | 21 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the A/C auto amp. and the harness connector M84.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector terminals.

| Harness connector | | | Continuity |
|-------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| B101 | 22 | 29 | Existed |
| | 21 | 28 | Existed |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair the main line between the harness connector B101.

4.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector and the data link connector.

- Without around view monitor

| Harness connector | | Data link connector | | Continuity |
|-------------------|--------------|---------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M84 | 29 | M22 | 6 | Existed |
| | 28 | | 14 | Existed |

- With around view monitor

| Harness connector | | Data link connector | | Continuity |
|-------------------|--------------|---------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |

MAIN LINE BETWEEN HVAC AND DLC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

| | | | | |
|-----|----|-----|----|---------|
| M84 | 29 | M22 | 13 | Existed |
| | 28 | | 12 | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the A/C auto amp. and the data link connector.

NO >> Repair the main line between the harness connector M84 and the data link connector.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

ECM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

ECM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011730912

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ECM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ECM.
2. Check the resistance between the ECM harness connector terminals.

| ECM harness connector | | | Resistance (Ω) |
|-----------------------|--------------|-----|-------------------------|
| Connector No. | Terminal No. | | |
| E32 | 124 | 123 | Approx. 108 – 132 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the ECM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ECM. Refer to [EC-188, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ECM. Refer to [EC-579, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ECM branch line.
NO >> Repair the power supply and the ground circuit.

IPDM-E BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

IPDM-E BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011730913

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the IPDM E/R for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of IPDM E/R.
2. Check the resistance between the IPDM E/R harness connector terminals.

| IPDM E/R harness connector | | | Resistance (Ω) |
|----------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| E119 | 29 | 28 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the IPDM E/R branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the IPDM E/R. Refer to [PCS-36, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the IPDM E/R. Refer to [PCS-37, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the IPDM E/R branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

TCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011730914

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - TCM
 - Harness connector F32
 - Harness connector E2

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of TCM.
2. Check the resistance between the TCM harness connector terminals.

| TCM harness connector | | Resistance (Ω) |
|-----------------------|----------------------------|-----------------|
| Connector No. | Terminal No. | |
| F25 | 33 23 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the TCM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCM. Refer to [TM-178, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the TCM. Refer to [TM-198, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the TCM branch line.

NO >> Repair the power supply and the ground circuit.

ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

ABS BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011730915

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ABS actuator and electric unit (control unit) for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ABS actuator and electric unit (control unit).
2. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.
 - Without around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | | Resistance (Ω) |
|---|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| E125 | 26 | 14 | Approx. 54 – 66 |

- With around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | | Resistance (Ω) |
|---|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| E130 | 19 | 30 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the ABS actuator and electric unit (control unit) branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ABS actuator and electric unit (control unit). Refer to [BRC-77, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ABS actuator and electric unit (control unit). Refer to [BRC-142, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ABS actuator and electric unit (control unit) branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

EPS/DAST 3 BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

EPS/DAST 3 BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011730916

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the power steering control module for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of power steering control module.
2. Check the resistance between the power steering control module harness connector terminals.

| Power steering control module harness connector | | | Resistance (Ω) |
|---|--------------|---|-----------------|
| Connector No. | Terminal No. | | |
| E62 | 8 | 7 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the power steering control module branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the power steering control module. Refer to [STC-23, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the power steering oil pump assembly. Refer to [STC-38, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the power steering control module branch line.
NO >> Repair the power supply and the ground circuit.

AV BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

AV BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011730917

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the AV control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of AV control unit.
2. Check the resistance between the AV control unit harness connector terminals.
 - With navigation system and without BOSE audio system

| AV control unit harness connector | | | Resistance (Ω) |
|-----------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M123 | 43 | 23 | Approx. 54 – 66 |

- With navigation system and BOSE audio system

| AV control unit harness connector | | | Resistance (Ω) |
|-----------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M162 | 43 | 23 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the AV control unit branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the AV control unit. Refer to [AV-166. "AV CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the AV control unit. Refer to [AV-179. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the AV control unit branch line.
NO >> Repair the power supply and the ground circuit.

LAN

HVAC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

HVAC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011730920

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the A/C auto amp. for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/C auto amp.
2. Check the resistance between the A/C auto amp. harness connector terminals.

| A/C auto amp. harness connector | | | Resistance (Ω) |
|---------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M50 | 1 | 21 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the A/C auto amp. branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the A/C auto amp. Refer to [HAC-73, "A/C AUTO AMP. : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the A/C auto amp. Refer to [HAC-95, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the A/C auto amp. branch line.
NO >> Repair the power supply and the ground circuit.

A-BAG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

A-BAG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011730923

WARNING:

- Before servicing, turn ignition switch OFF, disconnect battery negative terminal, and wait 3 minutes or more. (To discharge backup capacitor.)
- Never use unspecified tester or other measuring device.

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the air bag diagnosis sensor unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Replace the main harness.

2.CHECK AIR BAG DIAGNOSIS SENSOR UNIT

Check the air bag diagnosis sensor unit. Refer to [SRC-40, "Work Flow"](#).

Is the inspection result normal?

- YES >> Replace the main harness.
NO >> Replace parts whose air bag system has a malfunction.

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

DLC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

DLC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011730924

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the data link connector for damage, bend and loose connection (connector side and harness side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

| Data link connector | | | Resistance (Ω) |
|---------------------|--------------|----|-------------------------|
| Connector No. | Terminal No. | | |
| M22 | 6 | 14 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES (Present error)>>Check CAN system type decision again.
YES (Past error)>>Error was detected in the data link connector branch line circuit.
NO >> Repair the data link connector branch line.

M&A BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011730927

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the combination meter for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of combination meter.
2. Check the resistance between the combination meter harness connector terminals.

| Combination meter harness connector | | | Resistance (Ω) |
|-------------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M23 | 53 | 52 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the combination meter branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the combination meter. Refer to [MWI-59, "COMBINATION METER : Diagnosis Procedure"](#) .

Is the inspection result normal?

- YES (Present error)>>Replace the combination meter. Refer to [MWI-78, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the combination meter branch line.
 NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

STRG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

STRG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011730928

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the steering angle sensor for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of steering angle sensor.
2. Check the resistance between the steering angle sensor harness connector terminals.

| Steering angle sensor harness connector | | | Resistance (Ω) |
|---|--------------|---|-------------------------|
| Connector No. | Terminal No. | | |
| M54 | 5 | 2 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the steering angle sensor branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle sensor. Refer to [BRC-52, "Wiring Diagram"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering angle sensor. Refer to [BRC-145, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the steering angle sensor branch line.
NO >> Repair the power supply and the ground circuit.

BCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

BCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011730929

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the BCM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of BCM.
2. Check the resistance between the BCM harness connector terminals.

| BCM harness connector | | | Resistance (Ω) |
|-----------------------|--------------|----|-------------------|
| Connector No. | Terminal No. | | |
| M19 | 60 | 59 | Approx. 108 – 132 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the BCM branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the BCM. Refer to [BCS-75, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the BCM. Refer to [BCS-82, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the BCM branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

CAN COMMUNICATION CIRCUIT

Diagnosis Procedure

INFOID:000000011730941

1.CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication circuit.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

| Data link connector | | | Continuity |
|---------------------|--------------|----|-------------|
| Connector No. | Terminal No. | | |
| M22 | 6 | 14 | Not existed |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause.

3.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

| Data link connector | | Ground | Continuity |
|---------------------|--------------|--------|-------------|
| Connector No. | Terminal No. | | |
| M22 | 13 | | Not existed |
| | 12 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check the harness and repair the root cause.

4.CHECK ECM AND BCM TERMINATION CIRCUIT

1. Remove the ECM and the BCM.
2. Check the resistance between the ECM terminals.

| ECM | | Resistance (Ω) |
|--------------|-----|-------------------|
| Terminal No. | | |
| 124 | 123 | Approx. 108 – 132 |

3. Check the resistance between the BCM terminals.

| BCM | | Resistance (Ω) |
|--------------|----|-------------------|
| Terminal No. | | |
| 60 | 59 | Approx. 108 – 132 |

Is the measurement value within the specification?

- YES >> GO TO 5.
NO >> Replace the ECM and/or the BCM.

5.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

Inspection result

Reproduced>>GO TO 6.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

6.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication circuit.

NOTE:

ECM and BCM have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

MAIN LINE BETWEEN IPDM-E AND ABS CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

DTC/CIRCUIT DIAGNOSIS

MAIN LINE BETWEEN IPDM-E AND ABS CIRCUIT

Diagnosis Procedure

INFOID:000000011730947

1. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
 - ECM
 - IPDM E/R
 - ABS actuator and electric unit (control unit)
4. Check the continuity between the IPDM E/R harness connector and the ABS actuator and electric unit (control unit) harness connector.
 - Without around view monitor system

| IPDM E/R harness connector | | ABS actuator and electric unit (control unit) harness connector | | Continuity |
|----------------------------|--------------|---|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E119 | 29 | E125 | 26 | Existed |
| | 28 | | 14 | Existed |

- With around view monitor system

| IPDM E/R harness connector | | ABS actuator and electric unit (control unit) harness connector | | Continuity |
|----------------------------|--------------|---|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E119 | 29 | E130 | 19 | Existed |
| | 28 | | 30 | Existed |

Is the inspection result normal?

- YES (Present error)>>Check CAN system type decision again.
YES (Past error)>>Error was detected in the main line between the IPDM E/R and the ABS actuator and electric unit (control unit).
NO >> Repair the main line between the IPDM E/R and the ABS actuator and electric unit (control unit).

MAIN LINE BETWEEN ABS AND HVAC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

MAIN LINE BETWEEN ABS AND HVAC CIRCUIT

Diagnosis Procedure

INFOID:000000011730948

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector E152
 - Harness connector M31

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - ABS actuator and electric unit (control unit)
 - Harness connectors E152 and M31.
2. Check the continuity between the ABS actuator and electric unit (control unit) harness connector and the harness connector.
 - Without around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | Harness connector | | Continuity |
|---|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E125 | 26 | E152 | 12G | Existed |
| | 14 | | 11G | Existed |

- With around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | Harness connector | | Continuity |
|---|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E130 | 19 | E152 | 12G | Existed |
| | 30 | | 11G | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the ABS actuator and electric unit (control unit) and the harness connector E152.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector and the A/C auto amp harness connector.

| Harness connector | | A/C auto amp. harness connector | | Continuity |
|-------------------|--------------|---------------------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M31 | 12G | M50 | 1 | Existed |
| | 11G | | 21 | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the ABS actuator and electric unit (control unit) and the A/C auto amp.

NO >> Repair the main line between the harness connector M31 and the A/C auto amp.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

MAIN LINE BETWEEN HVAC AND DLC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

MAIN LINE BETWEEN HVAC AND DLC CIRCUIT

Diagnosis Procedure

INFOID:000000011730950

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M84
 - Harness connector B101

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - A/C auto amp.
 - Harness connectors M84 and B101
2. Check the continuity between the A/C auto amp. harness connector and the harness connector.

| A/C auto amp. harness connector | | Harness connector | | Continuity |
|---------------------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M50 | 1 | M84 | 22 | Existed |
| | 21 | | 21 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the A/C auto amp. and the harness connector M84.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector terminals.

| Harness connector | | | Continuity |
|-------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| B101 | 22 | 29 | Existed |
| | 21 | 28 | Existed |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair the main line between the harness connector B101.

4. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector and the data link connector.

- Without around view monitor

| Harness connector | | Data link connector | | Continuity |
|-------------------|--------------|---------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M84 | 29 | M22 | 6 | Existed |
| | 28 | | 14 | Existed |

- With around view monitor

| Harness connector | | Data link connector | | Continuity |
|-------------------|--------------|---------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |

MAIN LINE BETWEEN HVAC AND DLC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

| | | | | |
|-----|----|-----|----|---------|
| M84 | 29 | M22 | 13 | Existed |
| | 28 | | 12 | Existed |

A

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the A/C auto amp. and the data link connector.

NO >> Repair the main line between the harness connector M84 and the data link connector.

B

C

D

E

F

G

H

I

J

K

L

LAN

N

O

P

ECM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

ECM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011730959

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ECM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ECM.
2. Check the resistance between the ECM harness connector terminals.

| ECM harness connector | | | Resistance (Ω) |
|-----------------------|--------------|-----|-------------------|
| Connector No. | Terminal No. | | |
| E32 | 124 | 123 | Approx. 108 – 132 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the ECM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ECM. Refer to [EC-188, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ECM. Refer to [EC-579, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ECM branch line.
NO >> Repair the power supply and the ground circuit.

IPDM-E BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

IPDM-E BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011730960

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the IPDM E/R for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of IPDM E/R.
2. Check the resistance between the IPDM E/R harness connector terminals.

| IPDM E/R harness connector | | | Resistance (Ω) |
|----------------------------|--------------|----|-------------------------|
| Connector No. | Terminal No. | | |
| E119 | 29 | 28 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the IPDM E/R branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the IPDM E/R. Refer to [PCS-36, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the IPDM E/R. Refer to [PCS-37, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the IPDM E/R branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

TCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011730961

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - TCM
 - Harness connector F32
 - Harness connector E2

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of TCM.
2. Check the resistance between the TCM harness connector terminals.

| TCM harness connector | | | Resistance (Ω) |
|-----------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| F25 | 33 | 23 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the TCM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCM. Refer to [TM-178, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the TCM. Refer to [TM-198, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the TCM branch line.
NO >> Repair the power supply and the ground circuit.

ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

ABS BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011730962

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ABS actuator and electric unit (control unit) for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ABS actuator and electric unit (control unit).
2. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.
 - Without around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | | Resistance (Ω) |
|---|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| E125 | 26 | 14 | Approx. 54 – 66 |

- With around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | | Resistance (Ω) |
|---|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| E130 | 19 | 30 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the ABS actuator and electric unit (control unit) branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ABS actuator and electric unit (control unit). Refer to [BRC-77, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ABS actuator and electric unit (control unit). Refer to [BRC-142, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ABS actuator and electric unit (control unit) branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

EPS/DAST 3 BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

EPS/DAST 3 BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011730963

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the power steering control module for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of power steering control module.
2. Check the resistance between the power steering control module harness connector terminals.

| Power steering control module harness connector | | | Resistance (Ω) |
|---|--------------|---|-----------------|
| Connector No. | Terminal No. | | |
| E62 | 8 | 7 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the power steering control module branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the power steering control module. Refer to [STC-23, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the power steering oil pump assembly. Refer to [STC-38, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the power steering control module branch line.
NO >> Repair the power supply and the ground circuit.

AV BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

AV BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011730964

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the AV control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of AV control unit.
 2. Check the resistance between the AV control unit harness connector terminals.
- With navigation system and without BOSE audio system

| AV control unit harness connector | | | Resistance (Ω) |
|-----------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M123 | 43 | 23 | Approx. 54 – 66 |

- With navigation system and BOSE audio system

| AV control unit harness connector | | | Resistance (Ω) |
|-----------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M162 | 43 | 23 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the AV control unit branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the AV control unit. Refer to [AV-166. "AV CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the AV control unit. Refer to [AV-179. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the AV control unit branch line.
NO >> Repair the power supply and the ground circuit.

LAN

HVAC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

HVAC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011730967

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the A/C auto amp. for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/C auto amp.
2. Check the resistance between the A/C auto amp. harness connector terminals.

| A/C auto amp. harness connector | | | Resistance (Ω) |
|---------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M50 | 1 | 21 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the A/C auto amp. branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the A/C auto amp. Refer to [HAC-73, "A/C AUTO AMP. : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the A/C auto amp. Refer to [HAC-95, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the A/C auto amp. branch line.
NO >> Repair the power supply and the ground circuit.

PWBD BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

PWBD BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011730968

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Automatic back door control module
 - Harness connector B41
 - Harness connector M69

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of automatic back door control module.
2. Check the resistance between the automatic back door control module harness connector terminals.

| Automatic back door control module harness connector | | | Resistance (Ω) |
|--|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| B55 | 1 | 17 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the automatic back door control module branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the automatic back door control module. Refer to [DLK-171, "AUTOMATIC BACK DOOR CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the automatic back door control module. Refer to [DLK-311, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the automatic back door control module branch line.

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

A-BAG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011730970

WARNING:

- Before servicing, turn ignition switch OFF, disconnect battery negative terminal, and wait 3 minutes or more. (To discharge backup capacitor.)
- Never use unspecified tester or other measuring device.

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the air bag diagnosis sensor unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Replace the main harness.

2.CHECK AIR BAG DIAGNOSIS SENSOR UNIT

Check the air bag diagnosis sensor unit. Refer to [SRC-40, "Work Flow"](#).

Is the inspection result normal?

- YES >> Replace the main harness.
NO >> Replace parts whose air bag system has a malfunction.

DLC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

DLC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011730971

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the data link connector for damage, bend and loose connection (connector side and harness side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

| Data link connector | | | Resistance (Ω) |
|---------------------|--------------|----|-------------------------|
| Connector No. | Terminal No. | | |
| M22 | 6 | 14 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES (Present error)>>Check CAN system type decision again.
YES (Past error)>>Error was detected in the data link connector branch line circuit.
NO >> Repair the data link connector branch line.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

M&A BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011730974

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the combination meter for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of combination meter.
2. Check the resistance between the combination meter harness connector terminals.

| Combination meter harness connector | | | Resistance (Ω) |
|-------------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M23 | 53 | 52 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the combination meter branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the combination meter. Refer to [MWI-59, "COMBINATION METER : Diagnosis Procedure"](#) .

Is the inspection result normal?

- YES (Present error)>>Replace the combination meter. Refer to [MWI-78, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the combination meter branch line.
 NO >> Repair the power supply and the ground circuit.

STRG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

STRG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011730975

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the steering angle sensor for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of steering angle sensor.
2. Check the resistance between the steering angle sensor harness connector terminals.

| Steering angle sensor harness connector | | | Resistance (Ω) |
|---|--------------|---|-----------------|
| Connector No. | Terminal No. | | |
| M54 | 5 | 2 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the steering angle sensor branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle sensor. Refer to [BRC-52. "Wiring Diagram"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering angle sensor. Refer to [BRC-145. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the steering angle sensor branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

BCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

BCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011730976

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the BCM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of BCM.
2. Check the resistance between the BCM harness connector terminals.

| BCM harness connector | | | Resistance (Ω) |
|-----------------------|--------------|----|-------------------------|
| Connector No. | Terminal No. | | |
| M19 | 60 | 59 | Approx. 108 – 132 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the BCM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the BCM. Refer to [BCS-75. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the BCM. Refer to [BCS-82. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the BCM branch line.
NO >> Repair the power supply and the ground circuit.

CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

CAN COMMUNICATION CIRCUIT

Diagnosis Procedure

INFOID:000000011730988

1.CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication circuit.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

| Data link connector | | | Continuity |
|---------------------|--------------|----|-------------|
| Connector No. | Terminal No. | | |
| M22 | 6 | 14 | Not existed |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause.

3.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

| Data link connector | | Ground | Continuity |
|---------------------|--------------|--------|-------------|
| Connector No. | Terminal No. | | |
| M22 | 13 | | Not existed |
| | 12 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check the harness and repair the root cause.

4.CHECK ECM AND BCM TERMINATION CIRCUIT

1. Remove the ECM and the BCM.
2. Check the resistance between the ECM terminals.

| ECM | | Resistance (Ω) |
|--------------|-----|-------------------|
| Terminal No. | | |
| 124 | 123 | Approx. 108 – 132 |

3. Check the resistance between the BCM terminals.

| BCM | | Resistance (Ω) |
|--------------|----|-------------------|
| Terminal No. | | |
| 60 | 59 | Approx. 108 – 132 |

Is the measurement value within the specification?

- YES >> GO TO 5.
NO >> Replace the ECM and/or the BCM.

5.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

Inspection result

Reproduced>>GO TO 6.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

6.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication circuit.

NOTE:

ECM and BCM have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

MAIN LINE BETWEEN IPDM-E AND ABS CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

DTC/CIRCUIT DIAGNOSIS

MAIN LINE BETWEEN IPDM-E AND ABS CIRCUIT

Diagnosis Procedure

INFOID:000000011730994

1. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
 - ECM
 - IPDM E/R
 - ABS actuator and electric unit (control unit)
4. Check the continuity between the IPDM E/R harness connector and the ABS actuator and electric unit (control unit) harness connector.
 - Without around view monitor system

| IPDM E/R harness connector | | ABS actuator and electric unit (control unit) harness connector | | Continuity |
|----------------------------|--------------|---|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E119 | 29 | E125 | 26 | Existed |
| | 28 | | 14 | Existed |

- With around view monitor system

| IPDM E/R harness connector | | ABS actuator and electric unit (control unit) harness connector | | Continuity |
|----------------------------|--------------|---|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E119 | 29 | E130 | 19 | Existed |
| | 28 | | 30 | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the IPDM E/R and the ABS actuator and electric unit (control unit).

NO >> Repair the main line between the IPDM E/R and the ABS actuator and electric unit (control unit).

LAN

MAIN LINE BETWEEN ABS AND HVAC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

MAIN LINE BETWEEN ABS AND HVAC CIRCUIT

Diagnosis Procedure

INFOID:000000011730995

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector E152
 - Harness connector M31

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - ABS actuator and electric unit (control unit)
 - Harness connectors E152 and M31.
2. Check the continuity between the ABS actuator and electric unit (control unit) harness connector and the harness connector.
 - Without around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | Harness connector | | Continuity |
|---|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E125 | 26 | E152 | 12G | Existed |
| | 14 | | 11G | Existed |

- With around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | Harness connector | | Continuity |
|---|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E130 | 19 | E152 | 12G | Existed |
| | 30 | | 11G | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the ABS actuator and electric unit (control unit) and the harness connector E152.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector and the A/C auto amp harness connector.

| Harness connector | | A/C auto amp. harness connector | | Continuity |
|-------------------|--------------|---------------------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M31 | 12G | M50 | 1 | Existed |
| | 11G | | 21 | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the ABS actuator and electric unit (control unit) and the A/C auto amp.

NO >> Repair the main line between the harness connector M31 and the A/C auto amp.

MAIN LINE BETWEEN HVAC AND DLC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

MAIN LINE BETWEEN HVAC AND DLC CIRCUIT

Diagnosis Procedure

INFOID:000000011730997

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M84
 - Harness connector B101

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - A/C auto amp.
 - Harness connectors M84 and B101
2. Check the continuity between the A/C auto amp. harness connector and the harness connector.

| A/C auto amp. harness connector | | Harness connector | | Continuity |
|---------------------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M50 | 1 | M84 | 22 | Existed |
| | 21 | | 21 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the A/C auto amp. and the harness connector M84.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector terminals.

| Harness connector | | | Continuity |
|-------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| B101 | 22 | 29 | Existed |
| | 21 | 28 | Existed |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair the main line between the harness connector B101.

4.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector and the data link connector.

- Without around view monitor

| Harness connector | | Data link connector | | Continuity |
|-------------------|--------------|---------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M84 | 29 | M22 | 6 | Existed |
| | 28 | | 14 | Existed |

- With around view monitor

| Harness connector | | Data link connector | | Continuity |
|-------------------|--------------|---------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

MAIN LINE BETWEEN HVAC AND DLC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

| | | | | |
|-----|----|-----|----|---------|
| M84 | 29 | M22 | 13 | Existed |
| | 28 | | 12 | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the A/C auto amp. and the data link connector.

NO >> Repair the main line between the harness connector M84 and the data link connector.

MAIN LINE BETWEEN DLC AND ADP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

MAIN LINE BETWEEN DLC AND ADP CIRCUIT

Diagnosis Procedure

INFOID:000000011730999

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M40
 - Harness connector B69

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors M40 and B69.
2. Check the continuity between the data link connector and harness connector.

| Data link connector | | Harness connector | | Continuity |
|---------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M22 | 6 | M40 | 88A | Existed |
| | 14 | | 87A | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the data link connector and the harness connector M40.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector terminals.

| Harness connector | | | Continuity |
|-------------------|--------------|-----|------------|
| Connector No. | Terminal No. | | |
| B69 | 88A | 86A | Existed |
| | 87A | 85A | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the data link connector and drive seat control unit.

NO >> Repair the main line between the harness connector B69 and the drive seat control unit.

MAIN LINE BETWEEN AVM AND RDR-R CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

MAIN LINE BETWEEN AVM AND RDR-R CIRCUIT

Diagnosis Procedure

INFOID:000000011731000

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M84
 - Harness connector B101

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Around view monitor control unit
 - Harness connectors M84 and B101
2. Check the continuity between the around view monitor control unit harness connector and the harness connector.

| Around view monitor control unit harness connector | | Harness connector | | Continuity |
|--|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M96 | 26 | M84 | 8 | Existed |
| | 24 | | 7 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the around view monitor control unit and the harness connector M84.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors B464 and B142.
2. Check the continuity between the harness connectors.

| Harness connector | | Harness connector | | Continuity |
|-------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| B101 | 8 | B142 | 7 | Existed |
| | 7 | | 6 | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the around view monitor control unit and the side radar RH.

NO >> Repair the main line between the harness connector B101 and B142.

MAIN LINE BETWEEN RDR-R AND RDR-L CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

MAIN LINE BETWEEN RDR-R AND RDR-L CIRCUIT

Diagnosis Procedure

INFOID:000000011731001

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B140
 - Harness connector B49

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Harness connectors B464 and B142
 - Harness connectors B140 and B49
2. Check the continuity between the harness connectors.

| Harness connector | | Harness connector | | Continuity |
|-------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| B142 | 7 | B140 | 6 | Existed |
| | 6 | | 7 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the harness connector B142 and B140.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors B92 and B463.
2. Check the continuity between the harness connectors.

| Harness connector | | Harness connector | | Continuity |
|-------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| B49 | 6 | B92 | 7 | Existed |
| | 7 | | 6 | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the side radar RH and the side radar LH.

NO >> Repair the main line between the harness connector B49 and B92.

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

ECM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

ECM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731006

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ECM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ECM.
2. Check the resistance between the ECM harness connector terminals.

| ECM harness connector | | | Resistance (Ω) |
|-----------------------|--------------|-----|-------------------|
| Connector No. | Terminal No. | | |
| E32 | 124 | 123 | Approx. 108 – 132 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the ECM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ECM. Refer to [EC-188, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ECM. Refer to [EC-579, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ECM branch line.
NO >> Repair the power supply and the ground circuit.

IPDM-E BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

IPDM-E BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731007

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the IPDM E/R for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of IPDM E/R.
2. Check the resistance between the IPDM E/R harness connector terminals.

| IPDM E/R harness connector | | | Resistance (Ω) |
|----------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| E119 | 29 | 28 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the IPDM E/R branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the IPDM E/R. Refer to [PCS-36, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the IPDM E/R. Refer to [PCS-37, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the IPDM E/R branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

TCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731008

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - TCM
 - Harness connector F32
 - Harness connector E2

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of TCM.
2. Check the resistance between the TCM harness connector terminals.

| TCM harness connector | | | Resistance (Ω) |
|-----------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| F25 | 33 | 23 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the TCM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCM. Refer to [TM-178, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the TCM. Refer to [TM-198, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the TCM branch line.

NO >> Repair the power supply and the ground circuit.

ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

ABS BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731009

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ABS actuator and electric unit (control unit) for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ABS actuator and electric unit (control unit).
2. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.
 - Without around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | | Resistance (Ω) |
|---|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| E125 | 26 | 14 | Approx. 54 – 66 |

- With around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | | Resistance (Ω) |
|---|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| E130 | 19 | 30 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the ABS actuator and electric unit (control unit) branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ABS actuator and electric unit (control unit). Refer to [BRC-77, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ABS actuator and electric unit (control unit). Refer to [BRC-142, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ABS actuator and electric unit (control unit) branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

EPS/DAST 3 BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

EPS/DAST 3 BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731010

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the power steering control module for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of power steering control module.
2. Check the resistance between the power steering control module harness connector terminals.

| Power steering control module harness connector | | | Resistance (Ω) |
|---|--------------|---|-----------------|
| Connector No. | Terminal No. | | |
| E62 | 8 | 7 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the power steering control module branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the power steering control module. Refer to [STC-23, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the power steering oil pump assembly. Refer to [STC-38, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the power steering control module branch line.
NO >> Repair the power supply and the ground circuit.

AV BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

AV BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:0000000011731011

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the AV control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of AV control unit.
 2. Check the resistance between the AV control unit harness connector terminals.
- With navigation system and without BOSE audio system

| AV control unit harness connector | | | Resistance (Ω) |
|-----------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M123 | 43 | 23 | Approx. 54 – 66 |

- With navigation system and BOSE audio system

| AV control unit harness connector | | | Resistance (Ω) |
|-----------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M162 | 43 | 23 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the AV control unit branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the AV control unit. Refer to [AV-166. "AV CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the AV control unit. Refer to [AV-179. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the AV control unit branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

Diagnosis Procedure

INFOID:000000011731012

1. CHECK DTC

Check DTC of the CAN gateway with CONSULT.

Is U1010 or B2600 indicated?

- YES >> Perform a diagnosis of the indicated DTC.
- NO >> GO TO 2.

2. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the CAN gateway for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair the terminal and connector.

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of CAN gateway.
2. Check the resistance between the CAN gateway harness connector terminals.

| CAN gateway harness connector | | | Resistance (Ω) |
|-------------------------------|--------------|---|-----------------|
| Connector No. | Terminal No. | | |
| M5 | 1 | 7 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 4.
- NO >> Repair the CAN gateway branch line (CAN communication circuit 1 side).

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the CAN gateway. Refer to [LAN-121, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the CAN gateway. Refer to [LAN-122, "Removal and Installation"](#).
- YES (Past error)>>Error was detected in the CAN gateway branch line (CAN communication circuit 1 side).
- NO >> Repair the power supply and the ground circuit.

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

Diagnosis Procedure

INFOID:000000011731013

1.CHECK DTC

Check DTC of the CAN gateway with CONSULT.

Is U1010 or B2600 indicated?

- YES >> Perform a diagnosis of the indicated DTC.
- NO >> GO TO 2.

2.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors of the CAN gateway for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair the terminal and connector.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

| CAN gateway harness connector | | | Continuity |
|-------------------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| M5 | 4 | 6 | Existed |
| | 10 | 12 | Existed |

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair the CAN gateway branch line (CAN communication circuit 2 side).

4.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the CAN gateway. Refer to [LAN-121, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the CAN gateway. Refer to [LAN-122, "Removal and Installation"](#).
- YES (Past error)>>Error was detected in the CAN gateway branch line (CAN communication circuit 2 side).
- NO >> Repair the power supply and the ground circuit.

LAN

HVAC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

HVAC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731014

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the A/C auto amp. for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/C auto amp.
2. Check the resistance between the A/C auto amp. harness connector terminals.

| A/C auto amp. harness connector | | | Resistance (Ω) |
|---------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M50 | 1 | 21 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the A/C auto amp. branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the A/C auto amp. Refer to [HAC-73, "A/C AUTO AMP. : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the A/C auto amp. Refer to [HAC-95, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the A/C auto amp. branch line.
NO >> Repair the power supply and the ground circuit.

PWBD BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

PWBD BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:0000000011731015

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Automatic back door control module
 - Harness connector B41
 - Harness connector M69

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of automatic back door control module.
2. Check the resistance between the automatic back door control module harness connector terminals.

| Automatic back door control module harness connector | | | Resistance (Ω) |
|--|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| B55 | 1 | 17 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the automatic back door control module branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the automatic back door control module. Refer to [DLK-171, "AUTOMATIC BACK DOOR CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the automatic back door control module. Refer to [DLK-311, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the automatic back door control module branch line.

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

A-BAG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

A-BAG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731017

WARNING:

- Before servicing, turn ignition switch OFF, disconnect battery negative terminal, and wait 3 minutes or more. (To discharge backup capacitor.)
- Never use unspecified tester or other measuring device.

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the air bag diagnosis sensor unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Replace the main harness.

2.CHECK AIR BAG DIAGNOSIS SENSOR UNIT

Check the air bag diagnosis sensor unit. Refer to [SRC-40, "Work Flow"](#).

Is the inspection result normal?

- YES >> Replace the main harness.
NO >> Replace parts whose air bag system has a malfunction.

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

Diagnosis Procedure

INFOID:000000011731019

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the data link connector for damage, bend and loose connection (connector side and harness side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

| Data link connector | | | Resistance (Ω) |
|---------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M22 | 13 | 12 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the data link connector branch line circuit (CAN communication circuit 1 side).

NO >> Repair the data link connector branch line (CAN communication circuit 1 side).

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

Diagnosis Procedure

INFOID:000000011731020

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the data link connector for damage, bend and loose connection (connector side and harness side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

| Data link connector | | | Resistance (Ω) |
|---------------------|--------------|----|-------------------------|
| Connector No. | Terminal No. | | |
| M22 | 6 | 14 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the data link connector branch line circuit (CAN communication circuit 2 side).

NO >> Repair the data link connector branch line (CAN communication circuit 2 side).

M&A BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731021

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the combination meter for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of combination meter.
2. Check the resistance between the combination meter harness connector terminals.

| Combination meter harness connector | | | Resistance (Ω) |
|-------------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M23 | 53 | 52 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the combination meter branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the combination meter. Refer to [MWI-59, "COMBINATION METER : Diagnosis Procedure"](#) .

Is the inspection result normal?

- YES (Present error)>>Replace the combination meter. Refer to [MWI-78, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the combination meter branch line.
 NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

STRG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

STRG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731022

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the steering angle sensor for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of steering angle sensor.
2. Check the resistance between the steering angle sensor harness connector terminals.

| Steering angle sensor harness connector | | | Resistance (Ω) |
|---|--------------|---|-------------------------|
| Connector No. | Terminal No. | | |
| M54 | 5 | 2 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the steering angle sensor branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle sensor. Refer to [BRC-52, "Wiring Diagram"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering angle sensor. Refer to [BRC-145, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the steering angle sensor branch line.
NO >> Repair the power supply and the ground circuit.

BCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

BCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731023

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the BCM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of BCM.
2. Check the resistance between the BCM harness connector terminals.

| BCM harness connector | | | Resistance (Ω) |
|-----------------------|--------------|----|-------------------|
| Connector No. | Terminal No. | | |
| M19 | 60 | 59 | Approx. 108 – 132 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the BCM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the BCM. Refer to [BCS-75, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the BCM. Refer to [BCS-82, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the BCM branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

ICC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731025

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ADAS control unit
 - CAN gateway

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

| CAN gateway harness connector | | | Continuity |
|-------------------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| M5 | 4 | 6 | Existed |
| | 10 | 12 | Existed |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Check the harness and repair the root cause (CAN communication circuit 2 side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway.
2. Disconnect the connector of ADAS control unit.
3. Check the resistance between the ADAS control unit harness connector terminals.

| ADAS control unit harness connector | | | Resistance (Ω) |
|-------------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| B182 | 9 | 10 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 4.
 NO >> Repair the ADAS control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ADAS control unit. Refer to [DAS-84, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ADAS control unit. Refer to [DAS-85, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the ADAS control unit branch line.
 NO >> Repair the power supply and the ground circuit.

ADP BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

ADP BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731026

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Driver seat control unit
 - Harness connector B200
 - Harness connector B54
 - CAN gateway

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

| CAN gateway harness connector | | | Continuity |
|-------------------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| M5 | 4 | 6 | Existed |
| | 10 | 12 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair the root cause (CAN communication circuit 2 side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of driver seat control unit.
2. Check the resistance between the driver seat control unit harness connector terminals.

| Driver seat control unit harness connector | | | Resistance (Ω) |
|--|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| B209 | 16 | 32 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the driver seat control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the driver seat control unit. Refer to [ADP-71, "DRIVER SEAT CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the driver seat control unit. Refer to [ADP-132, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the driver seat control unit branch line.

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

AVM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

AVM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731027

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Around view monitor control unit
 - ADAS control unit

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of ADAS control unit.
2. Check the continuity between the ADAS control unit harness connector terminals.

| ADAS control unit harness connector | | | Continuity |
|-------------------------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| M182 | 2 | 18 | Existed |
| | 5 | 6 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair the root cause (ITS communication circuit side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of ADAS control unit.
2. Disconnect the connector of around view monitor control unit.
3. Check the resistance between the around view monitor control unit harness connector terminals.

| Around view monitor control unit harness connector | | | Resistance (Ω) |
|--|--------------|----|-------------------------|
| Connector No. | Terminal No. | | |
| M96 | 26 | 24 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the around view monitor control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the around view monitor control unit. Refer to [AV-271, "AROUND VIEW MONITOR CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the around view monitor control unit. Refer to [AV-274, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the around view monitor control unit branch line.

NO >> Repair the power supply and the ground circuit.

RDR-R BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

RDR-R BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731030

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Side radar RH
 - Harness connector B142
 - Harness connector B464
 - ADAS control unit

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of ADAS control unit.
2. Check the continuity between the ADAS control unit harness connector terminals.

| ADAS control unit harness connector | | | Continuity |
|-------------------------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| M182 | 2 | 18 | Existed |
| | 5 | 6 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair the root cause (ITS communication circuit side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of ADAS control unit.
2. Disconnect the connector of side radar RH.
3. Check the resistance between the side radar RH harness connector terminals.

| Side radar RH harness connector | | | Resistance (Ω) |
|---------------------------------|--------------|---|-----------------|
| Connector No. | Terminal No. | | |
| B466 | 6 | 7 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the side radar RH branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the side radar RH. Refer to [DAS-170, "SIDE RADAR RH: Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the side radar RH. Refer to [DAS-188, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the side radar RH branch line.

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

RDR-L BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

RDR-L BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731031

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Side radar LH
 - Harness connector B463
 - Harness connector B92
 - ADAS control unit

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of ADAS control unit.
2. Check the continuity between the ADAS control unit harness connector terminals.

| ADAS control unit harness connector | | | Continuity |
|-------------------------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| M182 | 2 | 18 | Existed |
| | 5 | 6 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair the root cause (ITS communication circuit side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of ADAS control unit.
2. Disconnect the connector of side radar LH.
3. Check the resistance between the side radar LH harness connector terminals.

| Side radar LH harness connector | | | Resistance (Ω) |
|---------------------------------|--------------|---|-------------------------|
| Connector No. | Terminal No. | | |
| B465 | 6 | 7 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the side radar LH branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the side radar LH. Refer to [DAS-170, "SIDE RADAR LH: Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the side radar LH. Refer to [DAS-188, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the side radar LH branch line.

NO >> Repair the power supply and the ground circuit.

CAN COMMUNICATION CIRCUIT 1

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

CAN COMMUNICATION CIRCUIT 1

Diagnosis Procedure

INFOID:0000000011731036

1. CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication circuit 1.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

| Data link connector | | Continuity |
|---------------------|--------------|-------------|
| Connector No. | Terminal No. | |
| M22 | 13 | Not existed |
| | 12 | |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause.

3. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

| Data link connector | | Ground | Continuity |
|---------------------|--------------|--------|-------------|
| Connector No. | Terminal No. | | |
| M22 | 13 | | Not existed |
| | 12 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check the harness and repair the root cause.

4. CHECK ECM AND BCM TERMINATION CIRCUIT

1. Remove the ECM and the BCM.
2. Check the resistance between the ECM terminals.

| ECM | | Resistance (Ω) |
|--------------|-----|-------------------------|
| Terminal No. | | |
| 124 | 123 | Approx. 108 – 132 |

3. Check the resistance between the BCM terminals.

| BCM | | Resistance (Ω) |
|--------------|----|-------------------------|
| Terminal No. | | |
| 60 | 59 | Approx. 108 – 132 |

Is the measurement value within the specification?

- YES >> GO TO 5.
NO >> Replace the ECM and/or the BCM.

5. CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

CAN COMMUNICATION CIRCUIT 1

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

Inspection result

Reproduced>>GO TO 6.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

6.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication circuit 1.

NOTE:

ECM and BCM have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

CAN COMMUNICATION CIRCUIT 2

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

CAN COMMUNICATION CIRCUIT 2

Diagnosis Procedure

INFOID:000000011731037

1.CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication circuit 2.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

| Data link connector | | | Continuity |
|---------------------|--------------|----|-------------|
| Connector No. | Terminal No. | | |
| M22 | 6 | 14 | Not existed |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Check the harness and repair the root cause.

3.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

| Data link connector | Terminal No. | Ground | Continuity |
|---------------------|--------------|--------|-------------|
| Connector No. | | | |
| M22 | 6 | | Not existed |
| | 14 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Check the harness and repair the root cause.

4.CHECK CAN GATEWAY TERMINATION CIRCUIT

1. Remove the CAN gateway.
2. Check the resistance between the CAN gateway terminals.

| CAN gateway | | Resistance (Ω) |
|--------------|----|-------------------|
| Terminal No. | | |
| 4 | 10 | Approx. 108 – 132 |
| 6 | 12 | Approx. 108 – 132 |

Is the measurement value within the specification?

- YES >> GO TO 5.
 NO >> Replace the CAN gateway.

5.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

Inspection result

- Reproduced>>GO TO 6.
 Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

CAN COMMUNICATION CIRCUIT 2

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

6. CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication circuit 2.

NOTE:

CAN gateway has two termination circuits. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

ITS COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

ITS COMMUNICATION CIRCUIT

Diagnosis Procedure

INFOID:0000000011731038

1. CHECK CAN DIAGNOSIS

Check the CAN diagnosis results from CONSULT to see that the CAN communication circuit 1 and CAN communication circuit 2 have no malfunction.

Are the CAN communication 1 and CAN communication 2 circuits normal?

YES >> GO TO 2.

NO >> Check and repair CAN communication circuit 1 and/or CAN communication circuit 2.

2. CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ADAS control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the terminal and connector.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the ADAS control unit harness connector.
2. Check the continuity between the ADAS control unit harness connector terminals.

| ADAS control unit harness connector | | | Continuity |
|-------------------------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| M182 | 2 | 18 | Existed |
| | 5 | 6 | Existed |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair the ADAS control unit branch line. (ITS communication circuit side).

4. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

1. Disconnect the following harness connectors.
 - Around view monitor control unit
 - Side radar RH
 - Side radar LH
 - ICC sensor
2. Check the continuity between the ADAS control unit harness connector terminals.

| ADAS control unit harness connector | | | Continuity |
|-------------------------------------|--------------|---|-------------|
| Connector No. | Terminal No. | | |
| M182 | 2 | 5 | Not existed |

Is the inspection result normal?

YES >> GO TO 5.

NO >> Check the harness and repair the root cause.

5. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the ADAS control unit harness connector and the ground.

| ADAS control unit harness connector | | Ground | Continuity |
|-------------------------------------|--------------|--------|-------------|
| Connector No. | Terminal No. | | |
| M182 | 2 | | Not existed |
| | 5 | | Not existed |

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

ITS COMMUNICATION CIRCUIT

[CAN SYSTEM (TYPE 4)]

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES >> GO TO 6.
- NO >> Check the harness and repair the root cause.

6.CHECK TERMINATION CIRCUIT

1. Remove the ADAS control unit.
2. Check the resistance between the ADAS control unit terminals.

| ADAS control unit | | Resistance (Ω) |
|-------------------|---|-------------------|
| Terminal No. | | |
| 2 | 5 | Approx. 108 – 132 |
| 18 | 6 | |

Is the inspection result normal?

- YES >> GO TO 7.
- NO >> Replace the ADAS control unit.

7.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

Inspection result

- Reproduced>>GO TO 8.
- Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

8.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of ITS communication circuit.
NOTE:
ADAS control unit and ICC sensor have a termination circuit. Check other units first.
4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

- Reproduced>>Connect the connector. Check other units as per the above procedure.
- Non-reproduced>>Replace the unit whose connector was disconnected.

MAIN LINE BETWEEN IPDM-E AND ABS CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

DTC/CIRCUIT DIAGNOSIS

MAIN LINE BETWEEN IPDM-E AND ABS CIRCUIT

Diagnosis Procedure

INFOID:000000011731041

1. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
 - ECM
 - IPDM E/R
 - ABS actuator and electric unit (control unit)
4. Check the continuity between the IPDM E/R harness connector and the ABS actuator and electric unit (control unit) harness connector.
 - Without around view monitor system

| IPDM E/R harness connector | | ABS actuator and electric unit (control unit) harness connector | | Continuity |
|----------------------------|--------------|---|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E119 | 29 | E125 | 26 | Existed |
| | 28 | | 14 | Existed |

- With around view monitor system

| IPDM E/R harness connector | | ABS actuator and electric unit (control unit) harness connector | | Continuity |
|----------------------------|--------------|---|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E119 | 29 | E130 | 19 | Existed |
| | 28 | | 30 | Existed |

Is the inspection result normal?

- YES (Present error)>>Check CAN system type decision again.
- YES (Past error)>>Error was detected in the main line between the IPDM E/R and the ABS actuator and electric unit (control unit).
- NO >> Repair the main line between the IPDM E/R and the ABS actuator and electric unit (control unit).

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

MAIN LINE BETWEEN ABS AND HVAC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

MAIN LINE BETWEEN ABS AND HVAC CIRCUIT

Diagnosis Procedure

INFOID:000000011731042

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector E152
 - Harness connector M31

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - ABS actuator and electric unit (control unit)
 - Harness connectors E152 and M31.
2. Check the continuity between the ABS actuator and electric unit (control unit) harness connector and the harness connector.
 - Without around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | Harness connector | | Continuity |
|---|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E125 | 26 | E152 | 12G | Existed |
| | 14 | | 11G | Existed |

- With around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | Harness connector | | Continuity |
|---|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E130 | 19 | E152 | 12G | Existed |
| | 30 | | 11G | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the ABS actuator and electric unit (control unit) and the harness connector E152.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector and the A/C auto amp harness connector.

| Harness connector | | A/C auto amp. harness connector | | Continuity |
|-------------------|--------------|---------------------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M31 | 12G | M50 | 1 | Existed |
| | 11G | | 21 | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the ABS actuator and electric unit (control unit) and the A/C auto amp.

NO >> Repair the main line between the harness connector M31 and the A/C auto amp.

MAIN LINE BETWEEN HVAC AND DLC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

MAIN LINE BETWEEN HVAC AND DLC CIRCUIT

Diagnosis Procedure

INFOID:000000011731044

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M84
 - Harness connector B101

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - A/C auto amp.
 - Harness connectors M84 and B101
2. Check the continuity between the A/C auto amp. harness connector and the harness connector.

| A/C auto amp. harness connector | | Harness connector | | Continuity |
|---------------------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M50 | 1 | M84 | 22 | Existed |
| | 21 | | 21 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the A/C auto amp. and the harness connector M84.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector terminals.

| Harness connector | | | Continuity |
|-------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| B101 | 22 | 29 | Existed |
| | 21 | 28 | Existed |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair the main line between the harness connector B101.

4.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector and the data link connector.

- Without around view monitor

| Harness connector | | Data link connector | | Continuity |
|-------------------|--------------|---------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M84 | 29 | M22 | 6 | Existed |
| | 28 | | 14 | Existed |

- With around view monitor

| Harness connector | | Data link connector | | Continuity |
|-------------------|--------------|---------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

MAIN LINE BETWEEN HVAC AND DLC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

| | | | | |
|-----|----|-----|----|---------|
| M84 | 29 | M22 | 13 | Existed |
| | 28 | | 12 | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the A/C auto amp. and the data link connector.

NO >> Repair the main line between the harness connector M84 and the data link connector.

MAIN LINE BETWEEN DLC AND ADP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

MAIN LINE BETWEEN DLC AND ADP CIRCUIT

Diagnosis Procedure

INFOID:000000011731046

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M40
 - Harness connector B69

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors M40 and B69.
2. Check the continuity between the data link connector and harness connector.

| Data link connector | | Harness connector | | Continuity |
|---------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M22 | 6 | M40 | 88A | Existed |
| | 14 | | 87A | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the data link connector and the harness connector M40.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector terminals.

| Harness connector | | | Continuity |
|-------------------|--------------|-----|------------|
| Connector No. | Terminal No. | | |
| B69 | 88A | 86A | Existed |
| | 87A | 85A | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the data link connector and drive seat control unit.

NO >> Repair the main line between the harness connector B69 and the drive seat control unit.

MAIN LINE BETWEEN AVM AND RDR-R CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

MAIN LINE BETWEEN AVM AND RDR-R CIRCUIT

Diagnosis Procedure

INFOID:000000011731047

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M84
 - Harness connector B101

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Around view monitor control unit
 - Harness connectors M84 and B101
2. Check the continuity between the around view monitor control unit harness connector and the harness connector.

| Around view monitor control unit harness connector | | Harness connector | | Continuity |
|--|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M96 | 26 | M84 | 8 | Existed |
| | 24 | | 7 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the around view monitor control unit and the harness connector M84.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors B464 and B142.
2. Check the continuity between the harness connectors.

| Harness connector | | Harness connector | | Continuity |
|-------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| B101 | 8 | B142 | 7 | Existed |
| | 7 | | 6 | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the around view monitor control unit and the side radar RH.

NO >> Repair the main line between the harness connector B101 and B142.

MAIN LINE BETWEEN RDR-R AND RDR-L CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

MAIN LINE BETWEEN RDR-R AND RDR-L CIRCUIT

Diagnosis Procedure

INFOID:000000011731048

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B140
 - Harness connector B49

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Harness connectors B464 and B142
 - Harness connectors B140 and B49
2. Check the continuity between the harness connectors.

| Harness connector | | Harness connector | | Continuity |
|-------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| B142 | 7 | B140 | 6 | Existed |
| | 6 | | 7 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the harness connector B142 and B140.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors B92 and B463.
2. Check the continuity between the harness connectors.

| Harness connector | | Harness connector | | Continuity |
|-------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| B49 | 6 | B92 | 7 | Existed |
| | 7 | | 6 | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the side radar RH and the side radar LH.

NO >> Repair the main line between the harness connector B49 and B92.

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

MAIN LINE BETWEEN RDR-L AND LASER CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

MAIN LINE BETWEEN RDR-L AND LASER CIRCUIT

Diagnosis Procedure

INFOID:000000011731050

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B40
 - Harness connector E34
 - Harness connector E5
 - Harness connector E207

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Harness connectors B92 and B463
 - Harness connectors B40 and E34
2. Check the continuity between the harness connectors.

| Harness connector | | Harness connector | | Continuity |
|-------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| B92 | 7 | B40 | 13 | Existed |
| | 6 | | 14 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the harness connector B92 and B40.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector E5 and E207.
2. Check the continuity between the harness connectors.

| Harness connector | | Harness connector | | Continuity |
|-------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E34 | 13 | E5 | 18 | Existed |
| | 14 | | 17 | Existed |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair the main line between the harness connector E34 and E5.

4. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector terminals.

| Harness connector | | | Continuity |
|-------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| E207 | 18 | 21 | Existed |
| | 17 | 20 | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the side radar LH and the ICC sensor.

NO >> Repair the main line between the harness connector E207 and the ICC sensor.

ECM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

ECM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731053

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ECM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ECM.
2. Check the resistance between the ECM harness connector terminals.

| ECM harness connector | | | Resistance (Ω) |
|-----------------------|--------------|-----|-------------------|
| Connector No. | Terminal No. | | |
| E32 | 124 | 123 | Approx. 108 – 132 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the ECM branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ECM. Refer to [EC-188. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ECM. Refer to [EC-579. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ECM branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

IPDM-E BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

IPDM-E BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731054

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the IPDM E/R for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of IPDM E/R.
2. Check the resistance between the IPDM E/R harness connector terminals.

| IPDM E/R harness connector | | | Resistance (Ω) |
|----------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| E119 | 29 | 28 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the IPDM E/R branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the IPDM E/R. Refer to [PCS-36, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the IPDM E/R. Refer to [PCS-37, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the IPDM E/R branch line.
NO >> Repair the power supply and the ground circuit.

TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

TCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731055

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - TCM
 - Harness connector F32
 - Harness connector E2

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of TCM.
2. Check the resistance between the TCM harness connector terminals.

| TCM harness connector | | Resistance (Ω) |
|-----------------------|----------------------------|-----------------|
| Connector No. | Terminal No. | |
| F25 | 33 23 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the TCM branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCM. Refer to [TM-178, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the TCM. Refer to [TM-198, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the TCM branch line.

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

ABS BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731056

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ABS actuator and electric unit (control unit) for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ABS actuator and electric unit (control unit).
 2. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.
- Without around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | | Resistance (Ω) |
|---|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| E125 | 26 | 14 | Approx. 54 – 66 |

- With around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | | Resistance (Ω) |
|---|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| E130 | 19 | 30 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the ABS actuator and electric unit (control unit) branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ABS actuator and electric unit (control unit). Refer to [BRC-77, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ABS actuator and electric unit (control unit). Refer to [BRC-142, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ABS actuator and electric unit (control unit) branch line.
NO >> Repair the power supply and the ground circuit.

EPS/DAST 3 BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

EPS/DAST 3 BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:0000000011731057

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the power steering control module for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of power steering control module.
2. Check the resistance between the power steering control module harness connector terminals.

| Power steering control module harness connector | | | Resistance (Ω) |
|---|--------------|---|-----------------|
| Connector No. | Terminal No. | | |
| E62 | 8 | 7 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the power steering control module branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the power steering control module. Refer to [STC-23, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the power steering oil pump assembly. Refer to [STC-38, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the power steering control module branch line.
NO >> Repair the power supply and the ground circuit.

AV BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

AV BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731058

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the AV control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of AV control unit.
2. Check the resistance between the AV control unit harness connector terminals.
 - With navigation system and without BOSE audio system

| AV control unit harness connector | | | Resistance (Ω) |
|-----------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M123 | 43 | 23 | Approx. 54 – 66 |

- With navigation system and BOSE audio system

| AV control unit harness connector | | | Resistance (Ω) |
|-----------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M162 | 43 | 23 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the AV control unit branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the AV control unit. Refer to [AV-166. "AV CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the AV control unit. Refer to [AV-179. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the AV control unit branch line.
NO >> Repair the power supply and the ground circuit.

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

Diagnosis Procedure

INFOID:000000011731059

1. CHECK DTC

Check DTC of the CAN gateway with CONSULT.

Is U1010 or B2600 indicated?

- YES >> Perform a diagnosis of the indicated DTC.
- NO >> GO TO 2.

2. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the CAN gateway for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair the terminal and connector.

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of CAN gateway.
2. Check the resistance between the CAN gateway harness connector terminals.

| CAN gateway harness connector | | | Resistance (Ω) |
|-------------------------------|--------------|---|-----------------|
| Connector No. | Terminal No. | | |
| M5 | 1 | 7 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 4.
- NO >> Repair the CAN gateway branch line (CAN communication circuit 1 side).

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the CAN gateway. Refer to [LAN-121. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the CAN gateway. Refer to [LAN-122. "Removal and Installation"](#).
- YES (Past error)>>Error was detected in the CAN gateway branch line (CAN communication circuit 1 side).
- NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

Diagnosis Procedure

INFOID:000000011731060

1. CHECK DTC

Check DTC of the CAN gateway with CONSULT.

Is U1010 or B2600 indicated?

- YES >> Perform a diagnosis of the indicated DTC.
- NO >> GO TO 2.

2. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors of the CAN gateway for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair the terminal and connector.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

| CAN gateway harness connector | | | Continuity |
|-------------------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| M5 | 4 | 6 | Existed |
| | 10 | 12 | Existed |

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair the CAN gateway branch line (CAN communication circuit 2 side).

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the CAN gateway. Refer to [LAN-121, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the CAN gateway. Refer to [LAN-122, "Removal and Installation"](#).
- YES (Past error)>>Error was detected in the CAN gateway branch line (CAN communication circuit 2 side).
- NO >> Repair the power supply and the ground circuit.

HVAC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

HVAC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731061

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the A/C auto amp. for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/C auto amp.
2. Check the resistance between the A/C auto amp. harness connector terminals.

| A/C auto amp. harness connector | | | Resistance (Ω) |
|---------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M50 | 1 | 21 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the A/C auto amp. branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the A/C auto amp. Refer to [HAC-73, "A/C AUTO AMP. : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the A/C auto amp. Refer to [HAC-95, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the A/C auto amp. branch line.
NO >> Repair the power supply and the ground circuit.

PWBD BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

PWBD BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731062

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Automatic back door control module
 - Harness connector B41
 - Harness connector M69

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of automatic back door control module.
2. Check the resistance between the automatic back door control module harness connector terminals.

| Automatic back door control module harness connector | | | Resistance (Ω) |
|--|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| B55 | 1 | 17 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the automatic back door control module branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the automatic back door control module. Refer to [DLK-171, "AUTOMATIC BACK DOOR CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the automatic back door control module. Refer to [DLK-311, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the automatic back door control module branch line.

NO >> Repair the power supply and the ground circuit.

A-BAG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

A-BAG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731064

WARNING:

- Before servicing, turn ignition switch OFF, disconnect battery negative terminal, and wait 3 minutes or more. (To discharge backup capacitor.)
- Never use unspecified tester or other measuring device.

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the air bag diagnosis sensor unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Replace the main harness.

2. CHECK AIR BAG DIAGNOSIS SENSOR UNIT

Check the air bag diagnosis sensor unit. Refer to [SRC-40, "Work Flow"](#).

Is the inspection result normal?

- YES >> Replace the main harness.
NO >> Replace parts whose air bag system has a malfunction.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

Diagnosis Procedure

INFOID:000000011731066

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the data link connector for damage, bend and loose connection (connector side and harness side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

| Data link connector | | | Resistance (Ω) |
|---------------------|--------------|----|-------------------------|
| Connector No. | Terminal No. | | |
| M22 | 13 | 12 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the data link connector branch line circuit (CAN communication circuit 1 side).

NO >> Repair the data link connector branch line (CAN communication circuit 1 side).

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

Diagnosis Procedure

INFOID:000000011731067

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the data link connector for damage, bend and loose connection (connector side and harness side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

| Data link connector | | | Resistance (Ω) |
|---------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M22 | 6 | 14 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the data link connector branch line circuit (CAN communication circuit 2 side).

NO >> Repair the data link connector branch line (CAN communication circuit 2 side).

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

M&A BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731068

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the combination meter for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of combination meter.
2. Check the resistance between the combination meter harness connector terminals.

| Combination meter harness connector | | | Resistance (Ω) |
|-------------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M23 | 53 | 52 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the combination meter branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the combination meter. Refer to [MWI-59, "COMBINATION METER : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the combination meter. Refer to [MWI-78, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the combination meter branch line.
 NO >> Repair the power supply and the ground circuit.

STRG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

STRG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731069

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the steering angle sensor for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of steering angle sensor.
2. Check the resistance between the steering angle sensor harness connector terminals.

| Steering angle sensor harness connector | | | Resistance (Ω) |
|---|--------------|---|-----------------|
| Connector No. | Terminal No. | | |
| M54 | 5 | 2 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the steering angle sensor branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle sensor. Refer to [BRC-52. "Wiring Diagram"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering angle sensor. Refer to [BRC-145. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the steering angle sensor branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

BCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

BCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731070

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the BCM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of BCM.
2. Check the resistance between the BCM harness connector terminals.

| BCM harness connector | | | Resistance (Ω) |
|-----------------------|--------------|----|-------------------|
| Connector No. | Terminal No. | | |
| M19 | 60 | 59 | Approx. 108 – 132 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the BCM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the BCM. Refer to [BCS-75. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the BCM. Refer to [BCS-82. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the BCM branch line.
NO >> Repair the power supply and the ground circuit.

ICC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731072

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ADAS control unit
 - CAN gateway

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

| CAN gateway harness connector | | | Continuity |
|-------------------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| M5 | 4 | 6 | Existed |
| | 10 | 12 | Existed |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Check the harness and repair the root cause (CAN communication circuit 2 side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway.
2. Disconnect the connector of ADAS control unit.
3. Check the resistance between the ADAS control unit harness connector terminals.

| ADAS control unit harness connector | | | Resistance (Ω) |
|-------------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| B182 | 9 | 10 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 4.
 NO >> Repair the ADAS control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ADAS control unit. Refer to [DAS-84, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ADAS control unit. Refer to [DAS-85, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the ADAS control unit branch line.
 NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

ADP BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

ADP BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731073

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Driver seat control unit
 - Harness connector B200
 - Harness connector B54
 - CAN gateway

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

| CAN gateway harness connector | | | Continuity |
|-------------------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| M5 | 4 | 6 | Existed |
| | 10 | 12 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair the root cause (CAN communication circuit 2 side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of driver seat control unit.
2. Check the resistance between the driver seat control unit harness connector terminals.

| Driver seat control unit harness connector | | | Resistance (Ω) |
|--|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| B209 | 16 | 32 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the driver seat control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the driver seat control unit. Refer to [ADP-71. "DRIVER SEAT CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the driver seat control unit. Refer to [ADP-132. "Removal and Installation"](#).

YES (Past error)>>Error was detected in the driver seat control unit branch line.

NO >> Repair the power supply and the ground circuit.

AVM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

AVM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:0000000011731074

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Around view monitor control unit
 - ADAS control unit

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of ADAS control unit.
2. Check the continuity between the ADAS control unit harness connector terminals.

| ADAS control unit harness connector | | | Continuity |
|-------------------------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| M182 | 2 | 18 | Existed |
| | 5 | 6 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair the root cause (ITS communication circuit side).

3.CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of ADAS control unit.
2. Disconnect the connector of around view monitor control unit.
3. Check the resistance between the around view monitor control unit harness connector terminals.

| Around view monitor control unit harness connector | | | Resistance (Ω) |
|--|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M96 | 26 | 24 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the around view monitor control unit branch line.

4.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the around view monitor control unit. Refer to [AV-271, "AROUND VIEW MONITOR CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the around view monitor control unit. Refer to [AV-274, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the around view monitor control unit branch line.

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

RDR-R BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

RDR-R BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731077

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Side radar RH
 - Harness connector B142
 - Harness connector B464
 - ADAS control unit

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of ADAS control unit.
2. Check the continuity between the ADAS control unit harness connector terminals.

| ADAS control unit harness connector | | | Continuity |
|-------------------------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| M182 | 2 | 18 | Existed |
| | 5 | 6 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair the root cause (ITS communication circuit side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of ADAS control unit.
2. Disconnect the connector of side radar RH.
3. Check the resistance between the side radar RH harness connector terminals.

| Side radar RH harness connector | | | Resistance (Ω) |
|---------------------------------|--------------|---|-------------------------|
| Connector No. | Terminal No. | | |
| B466 | 6 | 7 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the side radar RH branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the side radar RH. Refer to [DAS-170, "SIDE RADAR RH: Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the side radar RH. Refer to [DAS-188, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the side radar RH branch line.

NO >> Repair the power supply and the ground circuit.

RDR-L BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

RDR-L BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731078

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Side radar LH
 - Harness connector B463
 - Harness connector B92
 - ADAS control unit

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of ADAS control unit.
2. Check the continuity between the ADAS control unit harness connector terminals.

| ADAS control unit harness connector | | | Continuity |
|-------------------------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| M182 | 2 | 18 | Existed |
| | 5 | 6 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair the root cause (ITS communication circuit side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of ADAS control unit.
2. Disconnect the connector of side radar LH.
3. Check the resistance between the side radar LH harness connector terminals.

| Side radar LH harness connector | | | Resistance (Ω) |
|---------------------------------|--------------|---|-----------------|
| Connector No. | Terminal No. | | |
| B465 | 6 | 7 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the side radar LH branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the side radar LH. Refer to [DAS-170, "SIDE RADAR LH : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the side radar LH. Refer to [DAS-188, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the side radar LH branch line.

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

LASER BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

LASER BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731081

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ICC sensor
 - ADAS control unit

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of ADAS control unit.
2. Check the continuity between the ADAS control unit harness connector terminals.

| ADAS control unit harness connector | | | Continuity |
|-------------------------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| M182 | 2 | 18 | Existed |
| | 5 | 6 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair the root cause (ITS communication circuit side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of ADAS control unit.
2. Disconnect the connector of ICC sensor.
3. Check the resistance between the ICC sensor harness connector terminals.

| ICC sensor harness connector | | | Resistance (Ω) |
|------------------------------|--------------|---|-------------------------|
| Connector No. | Terminal No. | | |
| E219 | 2 | 3 | Approx. 108 – 132 |

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the ICC sensor branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ICC sensor. Refer to [CCS-126, "ICC SENSOR : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the ICC sensor. Refer to [CCS-148, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the ICC sensor branch line.

NO >> Repair the power supply and the ground circuit.

CAN COMMUNICATION CIRCUIT 1

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

CAN COMMUNICATION CIRCUIT 1

Diagnosis Procedure

INFOID:0000000011731083

1. CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication circuit 1.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

| Data link connector | | Continuity |
|---------------------|--------------|-------------|
| Connector No. | Terminal No. | |
| M22 | 13 | Not existed |
| | 12 | |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause.

3. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

| Data link connector | | Ground | Continuity |
|---------------------|--------------|--------|-------------|
| Connector No. | Terminal No. | | |
| M22 | 13 | | Not existed |
| | 12 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check the harness and repair the root cause.

4. CHECK ECM AND BCM TERMINATION CIRCUIT

1. Remove the ECM and the BCM.
2. Check the resistance between the ECM terminals.

| ECM | | Resistance (Ω) |
|--------------|-----|-------------------------|
| Terminal No. | | |
| 124 | 123 | Approx. 108 – 132 |

3. Check the resistance between the BCM terminals.

| BCM | | Resistance (Ω) |
|--------------|----|-------------------------|
| Terminal No. | | |
| 60 | 59 | Approx. 108 – 132 |

Is the measurement value within the specification?

- YES >> GO TO 5.
NO >> Replace the ECM and/or the BCM.

5. CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

CAN COMMUNICATION CIRCUIT 1

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

Inspection result

Reproduced>>GO TO 6.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

6.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication circuit 1.

NOTE:

ECM and BCM have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

CAN COMMUNICATION CIRCUIT 2

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

CAN COMMUNICATION CIRCUIT 2

Diagnosis Procedure

INFOID:0000000011731084

1.CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication circuit 2.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

| Data link connector | | | Continuity |
|---------------------|--------------|----|-------------|
| Connector No. | Terminal No. | | |
| M22 | 6 | 14 | Not existed |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause.

3.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

| Data link connector | Terminal No. | Ground | Continuity |
|---------------------|--------------|--------|-------------|
| Connector No. | | | Not existed |
| M22 | 6 | | Not existed |
| | 14 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check the harness and repair the root cause.

4.CHECK CAN GATEWAY TERMINATION CIRCUIT

1. Remove the CAN gateway.
2. Check the resistance between the CAN gateway terminals.

| CAN gateway | | Resistance (Ω) |
|--------------|----|-------------------|
| Terminal No. | | |
| 4 | 10 | Approx. 108 – 132 |
| 6 | 12 | Approx. 108 – 132 |

Is the measurement value within the specification?

- YES >> GO TO 5.
NO >> Replace the CAN gateway.

5.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

Inspection result

- Reproduced>>GO TO 6.
Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

CAN COMMUNICATION CIRCUIT 2

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

6. CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication circuit 2.

NOTE:

CAN gateway has two termination circuits. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

ITS COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

ITS COMMUNICATION CIRCUIT

Diagnosis Procedure

INFOID:000000011731085

1. CHECK CAN DIAGNOSIS

Check the CAN diagnosis results from CONSULT to see that the CAN communication circuit 1 and CAN communication circuit 2 have no malfunction.

Are the CAN communication 1 and CAN communication 2 circuits normal?

YES >> GO TO 2.

NO >> Check and repair CAN communication circuit 1 and/or CAN communication circuit 2.

2. CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ADAS control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the terminal and connector.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the ADAS control unit harness connector.
2. Check the continuity between the ADAS control unit harness connector terminals.

| ADAS control unit harness connector | | | Continuity |
|-------------------------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| M182 | 2 | 18 | Existed |
| | 5 | 6 | Existed |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair the ADAS control unit branch line. (ITS communication circuit side).

4. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

1. Disconnect the following harness connectors.
 - Around view monitor control unit
 - Side radar RH
 - Side radar LH
 - ICC sensor
2. Check the continuity between the ADAS control unit harness connector terminals.

| ADAS control unit harness connector | | | Continuity |
|-------------------------------------|--------------|---|-------------|
| Connector No. | Terminal No. | | |
| M182 | 2 | 5 | Not existed |

Is the inspection result normal?

YES >> GO TO 5.

NO >> Check the harness and repair the root cause.

5. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the ADAS control unit harness connector and the ground.

| ADAS control unit harness connector | | Ground | Continuity |
|-------------------------------------|--------------|--------|-------------|
| Connector No. | Terminal No. | | |
| M182 | 2 | | Not existed |
| | 5 | | Not existed |

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

ITS COMMUNICATION CIRCUIT

[CAN SYSTEM (TYPE 5)]

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES >> GO TO 6.
- NO >> Check the harness and repair the root cause.

6.CHECK TERMINATION CIRCUIT

1. Remove the ADAS control unit.
2. Check the resistance between the ADAS control unit terminals.

| ADAS control unit | | Resistance (Ω) |
|-------------------|---|-------------------|
| Terminal No. | | |
| 2 | 5 | Approx. 108 – 132 |
| 18 | 6 | |

Is the inspection result normal?

- YES >> GO TO 7.
- NO >> Replace the ADAS control unit.

7.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

Inspection result

- Reproduced>>GO TO 8.
- Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

8.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of ITS communication circuit.

NOTE:

ADAS control unit and ICC sensor have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

- Reproduced>>Connect the connector. Check other units as per the above procedure.
- Non-reproduced>>Replace the unit whose connector was disconnected.

MAIN LINE BETWEEN IPDM-E AND ABS CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

DTC/CIRCUIT DIAGNOSIS

MAIN LINE BETWEEN IPDM-E AND ABS CIRCUIT

Diagnosis Procedure

INFOID:000000011731088

1. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
 - ECM
 - IPDM E/R
 - ABS actuator and electric unit (control unit)
4. Check the continuity between the IPDM E/R harness connector and the ABS actuator and electric unit (control unit) harness connector.
 - Without around view monitor system

| IPDM E/R harness connector | | ABS actuator and electric unit (control unit) harness connector | | Continuity |
|----------------------------|--------------|---|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E119 | 29 | E125 | 26 | Existed |
| | 28 | | 14 | Existed |

- With around view monitor system

| IPDM E/R harness connector | | ABS actuator and electric unit (control unit) harness connector | | Continuity |
|----------------------------|--------------|---|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E119 | 29 | E130 | 19 | Existed |
| | 28 | | 30 | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the IPDM E/R and the ABS actuator and electric unit (control unit).

NO >> Repair the main line between the IPDM E/R and the ABS actuator and electric unit (control unit).

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

MAIN LINE BETWEEN ABS AND HVAC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

MAIN LINE BETWEEN ABS AND HVAC CIRCUIT

Diagnosis Procedure

INFOID:000000011731089

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector E152
 - Harness connector M31

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - ABS actuator and electric unit (control unit)
 - Harness connectors E152 and M31.
2. Check the continuity between the ABS actuator and electric unit (control unit) harness connector and the harness connector.
 - Without around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | Harness connector | | Continuity |
|---|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E125 | 26 | E152 | 12G | Existed |
| | 14 | | 11G | Existed |

- With around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | Harness connector | | Continuity |
|---|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E130 | 19 | E152 | 12G | Existed |
| | 30 | | 11G | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the ABS actuator and electric unit (control unit) and the harness connector E152.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector and the A/C auto amp harness connector.

| Harness connector | | A/C auto amp. harness connector | | Continuity |
|-------------------|--------------|---------------------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M31 | 12G | M50 | 1 | Existed |
| | 11G | | 21 | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the ABS actuator and electric unit (control unit) and the A/C auto amp.

NO >> Repair the main line between the harness connector M31 and the A/C auto amp.

MAIN LINE BETWEEN HVAC AND 4WD CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

MAIN LINE BETWEEN HVAC AND 4WD CIRCUIT

Diagnosis Procedure

INFOID:000000011731090

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M84
 - Harness connector B101

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - A/C auto amp.
 - Harness connectors M84 and B101
2. Check the continuity between the A/C auto amp. harness connector and the harness connector.

| A/C auto amp. harness connector | | Harness connector | | Continuity |
|---------------------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M50 | 1 | M84 | 22 | Existed |
| | 21 | | 21 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the A/C auto amp. and the harness connector M84.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector terminals.

| Connector No. | Harness connector | | Continuity |
|---------------|-------------------|----|------------|
| | Terminal No. | | |
| B101 | 22 | 29 | Existed |
| | 21 | 28 | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the A/C auto amp. and the AWD control unit.

NO >> Repair the main line between the harness connector B101 and the AWD control unit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

MAIN LINE BETWEEN 4WD AND DLC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

MAIN LINE BETWEEN 4WD AND DLC CIRCUIT

Diagnosis Procedure

INFOID:000000011731092

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M84
 - Harness connector B101

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors M84 and B101.
2. Check the continuity between the harness connector terminals.

| Harness connector | | Continuity |
|-------------------|--------------|---------------|
| Connector No. | Terminal No. | |
| B101 | 22 | 29 Existed |
| | 21 | 28 Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the AWD control unit and the harness connector B101.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector and the data link connector.

- Without around view monitor

| Harness connector | | Data link connector | | Continuity |
|-------------------|--------------|---------------------|---------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M84 | 29 | M22 | 6 Existed | |
| | 28 | | 14 Existed | |

- With around view monitor

| Harness connector | | Data link connector | | Continuity |
|-------------------|--------------|---------------------|---------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M84 | 29 | M22 | 13 Existed | |
| | 28 | | 12 Existed | |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the AWD control unit and the data link connector.

NO >> Repair the main line between the harness connector M84 and the data link connector.

ECM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

ECM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731100

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ECM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ECM.
2. Check the resistance between the ECM harness connector terminals.

| ECM harness connector | | | Resistance (Ω) |
|-----------------------|--------------|-----|-------------------|
| Connector No. | Terminal No. | | |
| E32 | 124 | 123 | Approx. 108 – 132 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the ECM branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ECM. Refer to [EC-188. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ECM. Refer to [EC-579. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ECM branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

IPDM-E BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

IPDM-E BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731101

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the IPDM E/R for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of IPDM E/R.
2. Check the resistance between the IPDM E/R harness connector terminals.

| IPDM E/R harness connector | | | Resistance (Ω) |
|----------------------------|--------------|----|-------------------------|
| Connector No. | Terminal No. | | |
| E119 | 29 | 28 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the IPDM E/R branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the IPDM E/R. Refer to [PCS-36, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the IPDM E/R. Refer to [PCS-37, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the IPDM E/R branch line.
NO >> Repair the power supply and the ground circuit.

TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

TCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731102

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - TCM
 - Harness connector F32
 - Harness connector E2

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of TCM.
2. Check the resistance between the TCM harness connector terminals.

| TCM harness connector | | Resistance (Ω) |
|-----------------------|----------------------------|-----------------|
| Connector No. | Terminal No. | |
| F25 | 33 23 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the TCM branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCM. Refer to [TM-178, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the TCM. Refer to [TM-198, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the TCM branch line.

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

ABS BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731103

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ABS actuator and electric unit (control unit) for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ABS actuator and electric unit (control unit).
 2. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.
- Without around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | | Resistance (Ω) |
|---|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| E125 | 26 | 14 | Approx. 54 – 66 |

- With around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | | Resistance (Ω) |
|---|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| E130 | 19 | 30 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the ABS actuator and electric unit (control unit) branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ABS actuator and electric unit (control unit). Refer to [BRC-77, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ABS actuator and electric unit (control unit). Refer to [BRC-142, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ABS actuator and electric unit (control unit) branch line.
NO >> Repair the power supply and the ground circuit.

EPS/DAST 3 BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

EPS/DAST 3 BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731104

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the power steering control module for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of power steering control module.
2. Check the resistance between the power steering control module harness connector terminals.

| Power steering control module harness connector | | | Resistance (Ω) |
|---|--------------|---|-----------------|
| Connector No. | Terminal No. | | |
| E62 | 8 | 7 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the power steering control module branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the power steering control module. Refer to [STC-23, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the power steering oil pump assembly. Refer to [STC-38, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the power steering control module branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

HVAC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

HVAC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731108

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the A/C auto amp. for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/C auto amp.
2. Check the resistance between the A/C auto amp. harness connector terminals.

| A/C auto amp. harness connector | | | Resistance (Ω) |
|---------------------------------|--------------|----|-------------------------|
| Connector No. | Terminal No. | | |
| M50 | 1 | 21 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the A/C auto amp. branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the A/C auto amp. Refer to [HAC-73, "A/C AUTO AMP. : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the A/C auto amp. Refer to [HAC-95, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the A/C auto amp. branch line.
NO >> Repair the power supply and the ground circuit.

4WD BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

4WD BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:0000000011731110

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the AWD control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of AWD control unit.
2. Check the resistance between the AWD control unit harness connector terminals.

| AWD control unit harness connector | | | Resistance (Ω) |
|------------------------------------|--------------|----|-------------------------|
| Connector No. | Terminal No. | | |
| B135 | 8 | 16 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the AWD control unit branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the AWD control unit. Refer to [DLN-46, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the AWD control unit. Refer to [DLN-58, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the AWD control unit branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

A-BAG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

A-BAG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731111

WARNING:

- Before servicing, turn ignition switch OFF, disconnect battery negative terminal, and wait 3 minutes or more. (To discharge backup capacitor.)
- Never use unspecified tester or other measuring device.

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the air bag diagnosis sensor unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Replace the main harness.

2.CHECK AIR BAG DIAGNOSIS SENSOR UNIT

Check the air bag diagnosis sensor unit. Refer to [SRC-40, "Work Flow"](#).

Is the inspection result normal?

- YES >> Replace the main harness.
NO >> Replace parts whose air bag system has a malfunction.

DLC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

DLC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:0000000011731112

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the data link connector for damage, bend and loose connection (connector side and harness side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

| Data link connector | | | Resistance (Ω) |
|---------------------|--------------|----|-------------------------|
| Connector No. | Terminal No. | | |
| M22 | 6 | 14 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES (Present error)>>Check CAN system type decision again.
YES (Past error)>>Error was detected in the data link connector branch line circuit.
NO >> Repair the data link connector branch line.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

M&A BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:0000000011731115

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the combination meter for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of combination meter.
2. Check the resistance between the combination meter harness connector terminals.

| Combination meter harness connector | | | Resistance (Ω) |
|-------------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M23 | 53 | 52 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the combination meter branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the combination meter. Refer to [MWI-59, "COMBINATION METER : Diagnosis Procedure"](#) .

Is the inspection result normal?

- YES (Present error)>>Replace the combination meter. Refer to [MWI-78, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the combination meter branch line.
 NO >> Repair the power supply and the ground circuit.

STRG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

STRG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:0000000011731116

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the steering angle sensor for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of steering angle sensor.
2. Check the resistance between the steering angle sensor harness connector terminals.

| Steering angle sensor harness connector | | | Resistance (Ω) |
|---|--------------|---|-----------------|
| Connector No. | Terminal No. | | |
| M54 | 5 | 2 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the steering angle sensor branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle sensor. Refer to [BRC-52. "Wiring Diagram"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering angle sensor. Refer to [BRC-145. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the steering angle sensor branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

BCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

BCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:0000000011731117

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the BCM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of BCM.
2. Check the resistance between the BCM harness connector terminals.

| BCM harness connector | | | Resistance (Ω) |
|-----------------------|--------------|----|-------------------------|
| Connector No. | Terminal No. | | |
| M19 | 60 | 59 | Approx. 108 – 132 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the BCM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the BCM. Refer to [BCS-75. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the BCM. Refer to [BCS-82. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the BCM branch line.
NO >> Repair the power supply and the ground circuit.

CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

CAN COMMUNICATION CIRCUIT

Diagnosis Procedure

INFOID:0000000011731129

1. CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication circuit.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

| Data link connector | | | Continuity |
|---------------------|--------------|----|-------------|
| Connector No. | Terminal No. | | |
| M22 | 6 | 14 | Not existed |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause.

3. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

| Data link connector | | Ground | Continuity |
|---------------------|--------------|--------|-------------|
| Connector No. | Terminal No. | | |
| M22 | 13 | | Not existed |
| | 12 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check the harness and repair the root cause.

4. CHECK ECM AND BCM TERMINATION CIRCUIT

1. Remove the ECM and the BCM.
2. Check the resistance between the ECM terminals.

| ECM | | Resistance (Ω) |
|--------------|-----|-------------------------|
| Terminal No. | | |
| 124 | 123 | Approx. 108 – 132 |

3. Check the resistance between the BCM terminals.

| BCM | | Resistance (Ω) |
|--------------|----|-------------------------|
| Terminal No. | | |
| 60 | 59 | Approx. 108 – 132 |

Is the measurement value within the specification?

- YES >> GO TO 5.
NO >> Replace the ECM and/or the BCM.

5. CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

Inspection result

Reproduced>>GO TO 6.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

6.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication circuit.

NOTE:

ECM and BCM have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

MAIN LINE BETWEEN IPDM-E AND ABS CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 7)]

DTC/CIRCUIT DIAGNOSIS

MAIN LINE BETWEEN IPDM-E AND ABS CIRCUIT

Diagnosis Procedure

INFOID:000000011731135

1. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
 - ECM
 - IPDM E/R
 - ABS actuator and electric unit (control unit)
4. Check the continuity between the IPDM E/R harness connector and the ABS actuator and electric unit (control unit) harness connector.
 - Without around view monitor system

| IPDM E/R harness connector | | ABS actuator and electric unit (control unit) harness connector | | Continuity |
|----------------------------|--------------|---|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E119 | 29 | E125 | 26 | Existed |
| | 28 | | 14 | Existed |

- With around view monitor system

| IPDM E/R harness connector | | ABS actuator and electric unit (control unit) harness connector | | Continuity |
|----------------------------|--------------|---|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E119 | 29 | E130 | 19 | Existed |
| | 28 | | 30 | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the IPDM E/R and the ABS actuator and electric unit (control unit).

NO >> Repair the main line between the IPDM E/R and the ABS actuator and electric unit (control unit).

LAN

MAIN LINE BETWEEN ABS AND HVAC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 7)]

MAIN LINE BETWEEN ABS AND HVAC CIRCUIT

Diagnosis Procedure

INFOID:0000000011731136

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector E152
 - Harness connector M31

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - ABS actuator and electric unit (control unit)
 - Harness connectors E152 and M31.
2. Check the continuity between the ABS actuator and electric unit (control unit) harness connector and the harness connector.
 - Without around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | Harness connector | | Continuity |
|---|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E125 | 26 | E152 | 12G | Existed |
| | 14 | | 11G | Existed |

- With around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | Harness connector | | Continuity |
|---|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E130 | 19 | E152 | 12G | Existed |
| | 30 | | 11G | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the ABS actuator and electric unit (control unit) and the harness connector E152.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector and the A/C auto amp harness connector.

| Harness connector | | A/C auto amp. harness connector | | Continuity |
|-------------------|--------------|---------------------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M31 | 12G | M50 | 1 | Existed |
| | 11G | | 21 | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the ABS actuator and electric unit (control unit) and the A/C auto amp.

NO >> Repair the main line between the harness connector M31 and the A/C auto amp.

MAIN LINE BETWEEN HVAC AND 4WD CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 7)]

MAIN LINE BETWEEN HVAC AND 4WD CIRCUIT

Diagnosis Procedure

INFOID:000000011731137

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M84
 - Harness connector B101

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - A/C auto amp.
 - Harness connectors M84 and B101
2. Check the continuity between the A/C auto amp. harness connector and the harness connector.

| A/C auto amp. harness connector | | Harness connector | | Continuity |
|---------------------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M50 | 1 | M84 | 22 | Existed |
| | 21 | | 21 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the A/C auto amp. and the harness connector M84.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector terminals.

| Connector No. | Harness connector | | Continuity |
|---------------|-------------------|----|------------|
| | Terminal No. | | |
| B101 | 22 | 29 | Existed |
| | 21 | 28 | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the A/C auto amp. and the AWD control unit.

NO >> Repair the main line between the harness connector B101 and the AWD control unit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

MAIN LINE BETWEEN 4WD AND DLC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 7)]

MAIN LINE BETWEEN 4WD AND DLC CIRCUIT

Diagnosis Procedure

INFOID:000000011731139

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M84
 - Harness connector B101

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors M84 and B101.
2. Check the continuity between the harness connector terminals.

| Harness connector | | Continuity | |
|-------------------|--------------|------------|---------|
| Connector No. | Terminal No. | | |
| B101 | 22 | 29 | Existed |
| | 21 | 28 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the AWD control unit and the harness connector B101.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector and the data link connector.

- Without around view monitor

| Harness connector | | Data link connector | | Continuity |
|-------------------|--------------|---------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M84 | 29 | M22 | 6 | Existed |
| | 28 | | 14 | Existed |

- With around view monitor

| Harness connector | | Data link connector | | Continuity |
|-------------------|--------------|---------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M84 | 29 | M22 | 13 | Existed |
| | 28 | | 12 | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the AWD control unit and the data link connector.

NO >> Repair the main line between the harness connector M84 and the data link connector.

ECM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 7)]

ECM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:0000000011731147

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ECM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ECM.
2. Check the resistance between the ECM harness connector terminals.

| ECM harness connector | | | Resistance (Ω) |
|-----------------------|--------------|-----|-------------------|
| Connector No. | Terminal No. | | |
| E32 | 124 | 123 | Approx. 108 – 132 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the ECM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ECM. Refer to [EC-188. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ECM. Refer to [EC-579. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ECM branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

IPDM-E BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 7)]

IPDM-E BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731148

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the IPDM E/R for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of IPDM E/R.
2. Check the resistance between the IPDM E/R harness connector terminals.

| IPDM E/R harness connector | | | Resistance (Ω) |
|----------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| E119 | 29 | 28 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the IPDM E/R branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the IPDM E/R. Refer to [PCS-36, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the IPDM E/R. Refer to [PCS-37, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the IPDM E/R branch line.
NO >> Repair the power supply and the ground circuit.

TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 7)]

TCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731149

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - TCM
 - Harness connector F32
 - Harness connector E2

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of TCM.
2. Check the resistance between the TCM harness connector terminals.

| TCM harness connector | | | Resistance (Ω) |
|-----------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| F25 | 33 | 23 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the TCM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCM. Refer to [TM-178, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the TCM. Refer to [TM-198, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the TCM branch line.

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 7)]

ABS BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731150

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ABS actuator and electric unit (control unit) for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ABS actuator and electric unit (control unit).
 2. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.
- Without around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | | Resistance (Ω) |
|---|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| E125 | 26 | 14 | Approx. 54 – 66 |

- With around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | | Resistance (Ω) |
|---|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| E130 | 19 | 30 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the ABS actuator and electric unit (control unit) branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ABS actuator and electric unit (control unit). Refer to [BRC-77, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ABS actuator and electric unit (control unit). Refer to [BRC-142, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ABS actuator and electric unit (control unit) branch line.
NO >> Repair the power supply and the ground circuit.

EPS/DAST 3 BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 7)]

EPS/DAST 3 BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:0000000011731151

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the power steering control module for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of power steering control module.
2. Check the resistance between the power steering control module harness connector terminals.

| Power steering control module harness connector | | | Resistance (Ω) |
|---|--------------|---|-----------------|
| Connector No. | Terminal No. | | |
| E62 | 8 | 7 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the power steering control module branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the power steering control module. Refer to [STC-23, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the power steering oil pump assembly. Refer to [STC-38, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the power steering control module branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

AV BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 7)]

AV BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731152

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the AV control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of AV control unit.
2. Check the resistance between the AV control unit harness connector terminals.
 - With navigation system and without BOSE audio system

| AV control unit harness connector | | | Resistance (Ω) |
|-----------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M123 | 43 | 23 | Approx. 54 – 66 |

- With navigation system and BOSE audio system

| AV control unit harness connector | | | Resistance (Ω) |
|-----------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M162 | 43 | 23 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the AV control unit branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the AV control unit. Refer to [AV-166. "AV CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the AV control unit. Refer to [AV-179. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the AV control unit branch line.
NO >> Repair the power supply and the ground circuit.

HVAC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 7)]

HVAC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731155

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the A/C auto amp. for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/C auto amp.
2. Check the resistance between the A/C auto amp. harness connector terminals.

| A/C auto amp. harness connector | | | Resistance (Ω) |
|---------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M50 | 1 | 21 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the A/C auto amp. branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the A/C auto amp. Refer to [HAC-73, "A/C AUTO AMP. : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the A/C auto amp. Refer to [HAC-95, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the A/C auto amp. branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

4WD BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 7)]

4WD BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731157

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the AWD control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of AWD control unit.
2. Check the resistance between the AWD control unit harness connector terminals.

| AWD control unit harness connector | | | Resistance (Ω) |
|------------------------------------|--------------|----|-------------------------|
| Connector No. | Terminal No. | | |
| B135 | 8 | 16 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the AWD control unit branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the AWD control unit. Refer to [DLN-46, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the AWD control unit. Refer to [DLN-58, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the AWD control unit branch line.
NO >> Repair the power supply and the ground circuit.

A-BAG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 7)]

A-BAG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731158

WARNING:

- Before servicing, turn ignition switch OFF, disconnect battery negative terminal, and wait 3 minutes or more. (To discharge backup capacitor.)
- Never use unspecified tester or other measuring device.

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the air bag diagnosis sensor unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Replace the main harness.

2.CHECK AIR BAG DIAGNOSIS SENSOR UNIT

Check the air bag diagnosis sensor unit. Refer to [SRC-40, "Work Flow"](#).

Is the inspection result normal?

- YES >> Replace the main harness.
NO >> Replace parts whose air bag system has a malfunction.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

DLC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 7)]

DLC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731159

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the data link connector for damage, bend and loose connection (connector side and harness side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

| Data link connector | | | Resistance (Ω) |
|---------------------|--------------|----|-------------------------|
| Connector No. | Terminal No. | | |
| M22 | 6 | 14 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES (Present error)>>Check CAN system type decision again.
YES (Past error)>>Error was detected in the data link connector branch line circuit.
NO >> Repair the data link connector branch line.

M&A BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:0000000011731162

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the combination meter for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of combination meter.
2. Check the resistance between the combination meter harness connector terminals.

| Combination meter harness connector | | Resistance (Ω) |
|-------------------------------------|--------------|-----------------|
| Connector No. | Terminal No. | |
| M23 | 53 | Approx. 54 – 66 |
| | 52 | |

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the combination meter branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the combination meter. Refer to [MWI-59, "COMBINATION METER : Diagnosis Procedure"](#) .

Is the inspection result normal?

- YES (Present error)>>Replace the combination meter. Refer to [MWI-78, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the combination meter branch line.
 NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

STRG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 7)]

STRG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731163

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the steering angle sensor for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of steering angle sensor.
2. Check the resistance between the steering angle sensor harness connector terminals.

| Steering angle sensor harness connector | | | Resistance (Ω) |
|---|--------------|---|-------------------------|
| Connector No. | Terminal No. | | |
| M54 | 5 | 2 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the steering angle sensor branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle sensor. Refer to [BRC-52, "Wiring Diagram"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering angle sensor. Refer to [BRC-145, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the steering angle sensor branch line.
NO >> Repair the power supply and the ground circuit.

BCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 7)]

BCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:0000000011731164

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the BCM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of BCM.
2. Check the resistance between the BCM harness connector terminals.

| BCM harness connector | | | Resistance (Ω) |
|-----------------------|--------------|----|-------------------|
| Connector No. | Terminal No. | | |
| M19 | 60 | 59 | Approx. 108 – 132 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the BCM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the BCM. Refer to [BCS-75, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the BCM. Refer to [BCS-82, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the BCM branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 7)]

CAN COMMUNICATION CIRCUIT

Diagnosis Procedure

INFOID:000000011731176

1.CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication circuit.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

| Data link connector | | | Continuity |
|---------------------|--------------|----|-------------|
| Connector No. | Terminal No. | | |
| M22 | 6 | 14 | Not existed |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause.

3.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

| Data link connector | | Ground | Continuity |
|---------------------|--------------|--------|-------------|
| Connector No. | Terminal No. | | |
| M22 | 13 | | Not existed |
| | 12 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check the harness and repair the root cause.

4.CHECK ECM AND BCM TERMINATION CIRCUIT

1. Remove the ECM and the BCM.
2. Check the resistance between the ECM terminals.

| ECM | | Resistance (Ω) |
|--------------|-----|-------------------|
| Terminal No. | | |
| 124 | 123 | Approx. 108 – 132 |

3. Check the resistance between the BCM terminals.

| BCM | | Resistance (Ω) |
|--------------|----|-------------------|
| Terminal No. | | |
| 60 | 59 | Approx. 108 – 132 |

Is the measurement value within the specification?

- YES >> GO TO 5.
NO >> Replace the ECM and/or the BCM.

5.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 7)]

Inspection result

Reproduced>>GO TO 6.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

6.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication circuit.

NOTE:

ECM and BCM have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

MAIN LINE BETWEEN IPDM-E AND ABS CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 8)]

DTC/CIRCUIT DIAGNOSIS

MAIN LINE BETWEEN IPDM-E AND ABS CIRCUIT

Diagnosis Procedure

INFOID:000000011731182

1. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
 - ECM
 - IPDM E/R
 - ABS actuator and electric unit (control unit)
4. Check the continuity between the IPDM E/R harness connector and the ABS actuator and electric unit (control unit) harness connector.
 - Without around view monitor system

| IPDM E/R harness connector | | ABS actuator and electric unit (control unit) harness connector | | Continuity |
|----------------------------|--------------|---|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E119 | 29 | E125 | 26 | Existed |
| | 28 | | 14 | Existed |

- With around view monitor system

| IPDM E/R harness connector | | ABS actuator and electric unit (control unit) harness connector | | Continuity |
|----------------------------|--------------|---|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E119 | 29 | E130 | 19 | Existed |
| | 28 | | 30 | Existed |

Is the inspection result normal?

- YES (Present error)>>Check CAN system type decision again.
- YES (Past error)>>Error was detected in the main line between the IPDM E/R and the ABS actuator and electric unit (control unit).
- NO >> Repair the main line between the IPDM E/R and the ABS actuator and electric unit (control unit).

MAIN LINE BETWEEN ABS AND HVAC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 8)]

MAIN LINE BETWEEN ABS AND HVAC CIRCUIT

Diagnosis Procedure

INFOID:000000011731183

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector E152
 - Harness connector M31

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - ABS actuator and electric unit (control unit)
 - Harness connectors E152 and M31.
2. Check the continuity between the ABS actuator and electric unit (control unit) harness connector and the harness connector.
 - Without around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | Harness connector | | Continuity |
|---|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E125 | 26 | E152 | 12G | Existed |
| | 14 | | 11G | Existed |

- With around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | Harness connector | | Continuity |
|---|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E130 | 19 | E152 | 12G | Existed |
| | 30 | | 11G | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the ABS actuator and electric unit (control unit) and the harness connector E152.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector and the A/C auto amp harness connector.

| Harness connector | | A/C auto amp. harness connector | | Continuity |
|-------------------|--------------|---------------------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M31 | 12G | M50 | 1 | Existed |
| | 11G | | 21 | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the ABS actuator and electric unit (control unit) and the A/C auto amp.

NO >> Repair the main line between the harness connector M31 and the A/C auto amp.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

MAIN LINE BETWEEN HVAC AND 4WD CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 8)]

MAIN LINE BETWEEN HVAC AND 4WD CIRCUIT

Diagnosis Procedure

INFOID:000000011731184

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M84
 - Harness connector B101

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - A/C auto amp.
 - Harness connectors M84 and B101
2. Check the continuity between the A/C auto amp. harness connector and the harness connector.

| A/C auto amp. harness connector | | Harness connector | | Continuity |
|---------------------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M50 | 1 | M84 | 22 | Existed |
| | 21 | | 21 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the A/C auto amp. and the harness connector M84.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector terminals.

| Connector No. | Harness connector | | Continuity |
|---------------|-------------------|----|------------|
| | Terminal No. | | |
| B101 | 22 | 29 | Existed |
| | 21 | 28 | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the A/C auto amp. and the AWD control unit.

NO >> Repair the main line between the harness connector B101 and the AWD control unit.

MAIN LINE BETWEEN 4WD AND DLC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 8)]

MAIN LINE BETWEEN 4WD AND DLC CIRCUIT

Diagnosis Procedure

INFOID:000000011731186

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M84
 - Harness connector B101

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors M84 and B101.
2. Check the continuity between the harness connector terminals.

| Harness connector | | Continuity |
|-------------------|--------------|---------------|
| Connector No. | Terminal No. | |
| B101 | 22 | 29 Existed |
| | 21 | 28 Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the AWD control unit and the harness connector B101.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector and the data link connector.

- Without around view monitor

| Harness connector | | Data link connector | | Continuity |
|-------------------|--------------|---------------------|---------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M84 | 29 | M22 | 6 Existed | |
| | 28 | | 14 Existed | |

- With around view monitor

| Harness connector | | Data link connector | | Continuity |
|-------------------|--------------|---------------------|---------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M84 | 29 | M22 | 13 Existed | |
| | 28 | | 12 Existed | |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the AWD control unit and the data link connector.

NO >> Repair the main line between the harness connector M84 and the data link connector.

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

ECM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 8)]

ECM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731194

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ECM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ECM.
2. Check the resistance between the ECM harness connector terminals.

| ECM harness connector | | | Resistance (Ω) |
|-----------------------|--------------|-----|-------------------------|
| Connector No. | Terminal No. | | |
| E32 | 124 | 123 | Approx. 108 – 132 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the ECM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ECM. Refer to [EC-188, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ECM. Refer to [EC-579, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ECM branch line.
NO >> Repair the power supply and the ground circuit.

IPDM-E BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 8)]

IPDM-E BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731195

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the IPDM E/R for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of IPDM E/R.
2. Check the resistance between the IPDM E/R harness connector terminals.

| IPDM E/R harness connector | | | Resistance (Ω) |
|----------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| E119 | 29 | 28 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the IPDM E/R branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the IPDM E/R. Refer to [PCS-36, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the IPDM E/R. Refer to [PCS-37, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the IPDM E/R branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 8)]

TCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731196

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - TCM
 - Harness connector F32
 - Harness connector E2

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of TCM.
2. Check the resistance between the TCM harness connector terminals.

| TCM harness connector | | | Resistance (Ω) |
|-----------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| F25 | 33 | 23 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the TCM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCM. Refer to [TM-178, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the TCM. Refer to [TM-198, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the TCM branch line.

NO >> Repair the power supply and the ground circuit.

ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 8)]

ABS BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731197

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ABS actuator and electric unit (control unit) for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ABS actuator and electric unit (control unit).
2. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.
 - Without around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | | Resistance (Ω) |
|---|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| E125 | 26 | 14 | Approx. 54 – 66 |

- With around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | | Resistance (Ω) |
|---|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| E130 | 19 | 30 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the ABS actuator and electric unit (control unit) branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ABS actuator and electric unit (control unit). Refer to [BRC-77, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ABS actuator and electric unit (control unit). Refer to [BRC-142, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ABS actuator and electric unit (control unit) branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

EPS/DAST 3 BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 8)]

EPS/DAST 3 BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731198

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the power steering control module for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of power steering control module.
2. Check the resistance between the power steering control module harness connector terminals.

| Power steering control module harness connector | | | Resistance (Ω) |
|---|--------------|---|-----------------|
| Connector No. | Terminal No. | | |
| E62 | 8 | 7 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the power steering control module branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the power steering control module. Refer to [STC-23, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the power steering oil pump assembly. Refer to [STC-38, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the power steering control module branch line.
NO >> Repair the power supply and the ground circuit.

AV BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 8)]

AV BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:0000000011731199

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the AV control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of AV control unit.
 2. Check the resistance between the AV control unit harness connector terminals.
- With navigation system and without BOSE audio system

| AV control unit harness connector | | | Resistance (Ω) |
|-----------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M123 | 43 | 23 | Approx. 54 – 66 |

- With navigation system and BOSE audio system

| AV control unit harness connector | | | Resistance (Ω) |
|-----------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M162 | 43 | 23 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the AV control unit branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the AV control unit. Refer to [AV-166. "AV CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the AV control unit. Refer to [AV-179. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the AV control unit branch line.
NO >> Repair the power supply and the ground circuit.

LAN

HVAC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 8)]

HVAC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731202

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the A/C auto amp. for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/C auto amp.
2. Check the resistance between the A/C auto amp. harness connector terminals.

| A/C auto amp. harness connector | | | Resistance (Ω) |
|---------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M50 | 1 | 21 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the A/C auto amp. branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the A/C auto amp. Refer to [HAC-73, "A/C AUTO AMP. : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the A/C auto amp. Refer to [HAC-95, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the A/C auto amp. branch line.
NO >> Repair the power supply and the ground circuit.

PWBD BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 8)]

PWBD BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:0000000011731203

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Automatic back door control module
 - Harness connector B41
 - Harness connector M69

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of automatic back door control module.
2. Check the resistance between the automatic back door control module harness connector terminals.

| Automatic back door control module harness connector | | | Resistance (Ω) |
|--|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| B55 | 1 | 17 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the automatic back door control module branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the automatic back door control module. Refer to [DLK-171, "AUTOMATIC BACK DOOR CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the automatic back door control module. Refer to [DLK-311, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the automatic back door control module branch line.

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

4WD BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 8)]

4WD BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731204

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the AWD control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of AWD control unit.
2. Check the resistance between the AWD control unit harness connector terminals.

| AWD control unit harness connector | | | Resistance (Ω) |
|------------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| B135 | 8 | 16 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the AWD control unit branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the AWD control unit. Refer to [DLN-46, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the AWD control unit. Refer to [DLN-58, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the AWD control unit branch line.
NO >> Repair the power supply and the ground circuit.

A-BAG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 8)]

A-BAG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731205

WARNING:

- Before servicing, turn ignition switch OFF, disconnect battery negative terminal, and wait 3 minutes or more. (To discharge backup capacitor.)
- Never use unspecified tester or other measuring device.

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the air bag diagnosis sensor unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Replace the main harness.

2. CHECK AIR BAG DIAGNOSIS SENSOR UNIT

Check the air bag diagnosis sensor unit. Refer to [SRC-40, "Work Flow"](#).

Is the inspection result normal?

- YES >> Replace the main harness.
NO >> Replace parts whose air bag system has a malfunction.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

DLC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 8)]

DLC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731206

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the data link connector for damage, bend and loose connection (connector side and harness side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

| Data link connector | | | Resistance (Ω) |
|---------------------|--------------|----|-------------------------|
| Connector No. | Terminal No. | | |
| M22 | 6 | 14 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES (Present error)>>Check CAN system type decision again.
YES (Past error)>>Error was detected in the data link connector branch line circuit.
NO >> Repair the data link connector branch line.

M&A BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731209

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the combination meter for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of combination meter.
2. Check the resistance between the combination meter harness connector terminals.

| Combination meter harness connector | | | Resistance (Ω) |
|-------------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M23 | 53 | 52 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the combination meter branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the combination meter. Refer to [MWI-59, "COMBINATION METER : Diagnosis Procedure"](#) .

Is the inspection result normal?

- YES (Present error)>>Replace the combination meter. Refer to [MWI-78, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the combination meter branch line.
 NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

STRG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 8)]

STRG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731210

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the steering angle sensor for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of steering angle sensor.
2. Check the resistance between the steering angle sensor harness connector terminals.

| Steering angle sensor harness connector | | | Resistance (Ω) |
|---|--------------|---|-------------------------|
| Connector No. | Terminal No. | | |
| M54 | 5 | 2 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the steering angle sensor branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle sensor. Refer to [BRC-52, "Wiring Diagram"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering angle sensor. Refer to [BRC-145, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the steering angle sensor branch line.
NO >> Repair the power supply and the ground circuit.

BCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 8)]

BCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:0000000011731211

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the BCM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of BCM.
2. Check the resistance between the BCM harness connector terminals.

| BCM harness connector | | | Resistance (Ω) |
|-----------------------|--------------|----|-------------------|
| Connector No. | Terminal No. | | |
| M19 | 60 | 59 | Approx. 108 – 132 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the BCM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the BCM. Refer to [BCS-75, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the BCM. Refer to [BCS-82, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the BCM branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 8)]

CAN COMMUNICATION CIRCUIT

Diagnosis Procedure

INFOID:000000011731223

1.CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication circuit.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

| Data link connector | | Continuity |
|---------------------|--------------|-------------|
| Connector No. | Terminal No. | |
| M22 | 6 14 | Not existed |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause.

3.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

| Data link connector | | Ground | Continuity |
|---------------------|--------------|--------|-------------|
| Connector No. | Terminal No. | | |
| M22 | 13 | | Not existed |
| | 12 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check the harness and repair the root cause.

4.CHECK ECM AND BCM TERMINATION CIRCUIT

1. Remove the ECM and the BCM.
2. Check the resistance between the ECM terminals.

| ECM | | Resistance (Ω) |
|--------------|-----|-------------------|
| Terminal No. | | |
| 124 | 123 | Approx. 108 – 132 |

3. Check the resistance between the BCM terminals.

| BCM | | Resistance (Ω) |
|--------------|----|-------------------|
| Terminal No. | | |
| 60 | 59 | Approx. 108 – 132 |

Is the measurement value within the specification?

- YES >> GO TO 5.
NO >> Replace the ECM and/or the BCM.

5.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 8)]

Inspection result

Reproduced>>GO TO 6.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

6.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication circuit.

NOTE:

ECM and BCM have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

MAIN LINE BETWEEN IPDM-E AND ABS CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

DTC/CIRCUIT DIAGNOSIS

MAIN LINE BETWEEN IPDM-E AND ABS CIRCUIT

Diagnosis Procedure

INFOID:000000011731229

1. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
 - ECM
 - IPDM E/R
 - ABS actuator and electric unit (control unit)
4. Check the continuity between the IPDM E/R harness connector and the ABS actuator and electric unit (control unit) harness connector.
 - Without around view monitor system

| IPDM E/R harness connector | | ABS actuator and electric unit (control unit) harness connector | | Continuity |
|----------------------------|--------------|---|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E119 | 29 | E125 | 26 | Existed |
| | 28 | | 14 | Existed |

- With around view monitor system

| IPDM E/R harness connector | | ABS actuator and electric unit (control unit) harness connector | | Continuity |
|----------------------------|--------------|---|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E119 | 29 | E130 | 19 | Existed |
| | 28 | | 30 | Existed |

Is the inspection result normal?

- YES (Present error)>>Check CAN system type decision again.
- YES (Past error)>>Error was detected in the main line between the IPDM E/R and the ABS actuator and electric unit (control unit).
- NO >> Repair the main line between the IPDM E/R and the ABS actuator and electric unit (control unit).

MAIN LINE BETWEEN ABS AND HVAC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

MAIN LINE BETWEEN ABS AND HVAC CIRCUIT

Diagnosis Procedure

INFOID:000000011731230

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector E152
 - Harness connector M31

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - ABS actuator and electric unit (control unit)
 - Harness connectors E152 and M31.
2. Check the continuity between the ABS actuator and electric unit (control unit) harness connector and the harness connector.
 - Without around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | Harness connector | | Continuity |
|---|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E125 | 26 | E152 | 12G | Existed |
| | 14 | | 11G | Existed |

- With around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | Harness connector | | Continuity |
|---|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E130 | 19 | E152 | 12G | Existed |
| | 30 | | 11G | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the ABS actuator and electric unit (control unit) and the harness connector E152.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector and the A/C auto amp harness connector.

| Harness connector | | A/C auto amp. harness connector | | Continuity |
|-------------------|--------------|---------------------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M31 | 12G | M50 | 1 | Existed |
| | 11G | | 21 | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the ABS actuator and electric unit (control unit) and the A/C auto amp.

NO >> Repair the main line between the harness connector M31 and the A/C auto amp.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

MAIN LINE BETWEEN HVAC AND 4WD CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

MAIN LINE BETWEEN HVAC AND 4WD CIRCUIT

Diagnosis Procedure

INFOID:000000011731231

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M84
 - Harness connector B101

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - A/C auto amp.
 - Harness connectors M84 and B101
2. Check the continuity between the A/C auto amp. harness connector and the harness connector.

| A/C auto amp. harness connector | | Harness connector | | Continuity |
|---------------------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M50 | 1 | M84 | 22 | Existed |
| | 21 | | 21 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the A/C auto amp. and the harness connector M84.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector terminals.

| Connector No. | Harness connector | | Continuity |
|---------------|-------------------|----|------------|
| | Terminal No. | | |
| B101 | 22 | 29 | Existed |
| | 21 | 28 | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the A/C auto amp. and the AWD control unit.

NO >> Repair the main line between the harness connector B101 and the AWD control unit.

MAIN LINE BETWEEN 4WD AND DLC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

MAIN LINE BETWEEN 4WD AND DLC CIRCUIT

Diagnosis Procedure

INFOID:000000011731233

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M84
 - Harness connector B101

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors M84 and B101.
2. Check the continuity between the harness connector terminals.

| Harness connector | | Continuity |
|-------------------|--------------|---------------|
| Connector No. | Terminal No. | |
| B101 | 22 | 29 Existed |
| | 21 | 28 Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the AWD control unit and the harness connector B101.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector and the data link connector.

- Without around view monitor

| Harness connector | | Data link connector | | Continuity |
|-------------------|--------------|---------------------|---------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M84 | 29 | M22 | 6 Existed | |
| | 28 | | 14 Existed | |

- With around view monitor

| Harness connector | | Data link connector | | Continuity |
|-------------------|--------------|---------------------|---------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M84 | 29 | M22 | 13 Existed | |
| | 28 | | 12 Existed | |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the AWD control unit and the data link connector.

NO >> Repair the main line between the harness connector M84 and the data link connector.

MAIN LINE BETWEEN DLC AND ADP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

MAIN LINE BETWEEN DLC AND ADP CIRCUIT

Diagnosis Procedure

INFOID:000000011731234

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M40
 - Harness connector B69

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors M40 and B69.
2. Check the continuity between the data link connector and harness connector.

| Data link connector | | Harness connector | | Continuity |
|---------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M22 | 6 | M40 | 88A | Existed |
| | 14 | | 87A | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the data link connector and the harness connector M40.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector terminals.

| Harness connector | | | Continuity |
|-------------------|--------------|-----|------------|
| Connector No. | Terminal No. | | |
| B69 | 88A | 86A | Existed |
| | 87A | 85A | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the data link connector and drive seat control unit.

NO >> Repair the main line between the harness connector B69 and the drive seat control unit.

MAIN LINE BETWEEN AVM AND RDR-R CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

MAIN LINE BETWEEN AVM AND RDR-R CIRCUIT

Diagnosis Procedure

INFOID:000000011731235

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M84
 - Harness connector B101

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Around view monitor control unit
 - Harness connectors M84 and B101
2. Check the continuity between the around view monitor control unit harness connector and the harness connector.

| Around view monitor control unit harness connector | | Harness connector | | Continuity |
|--|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M96 | 26 | M84 | 8 | Existed |
| | 24 | | 7 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the around view monitor control unit and the harness connector M84.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors B464 and B142.
2. Check the continuity between the harness connectors.

| Harness connector | | Harness connector | | Continuity |
|-------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| B101 | 8 | B142 | 7 | Existed |
| | 7 | | 6 | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the around view monitor control unit and the side radar RH.

NO >> Repair the main line between the harness connector B101 and B142.

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

MAIN LINE BETWEEN RDR-R AND RDR-L CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

MAIN LINE BETWEEN RDR-R AND RDR-L CIRCUIT

Diagnosis Procedure

INFOID:000000011731236

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B140
 - Harness connector B49

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Harness connectors B464 and B142
 - Harness connectors B140 and B49
2. Check the continuity between the harness connectors.

| Harness connector | | Harness connector | | Continuity |
|-------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| B142 | 7 | B140 | 6 | Existed |
| | 6 | | 7 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the harness connector B142 and B140.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors B92 and B463.
2. Check the continuity between the harness connectors.

| Harness connector | | Harness connector | | Continuity |
|-------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| B49 | 6 | B92 | 7 | Existed |
| | 7 | | 6 | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the side radar RH and the side radar LH.

NO >> Repair the main line between the harness connector B49 and B92.

ECM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

ECM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731241

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ECM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ECM.
2. Check the resistance between the ECM harness connector terminals.

| ECM harness connector | | | Resistance (Ω) |
|-----------------------|--------------|-----|-------------------------|
| Connector No. | Terminal No. | | |
| E32 | 124 | 123 | Approx. 108 – 132 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the ECM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ECM. Refer to [EC-188. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ECM. Refer to [EC-579. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ECM branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

IPDM-E BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

IPDM-E BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731242

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the IPDM E/R for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of IPDM E/R.
2. Check the resistance between the IPDM E/R harness connector terminals.

| IPDM E/R harness connector | | | Resistance (Ω) |
|----------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| E119 | 29 | 28 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the IPDM E/R branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the IPDM E/R. Refer to [PCS-36, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the IPDM E/R. Refer to [PCS-37, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the IPDM E/R branch line.
NO >> Repair the power supply and the ground circuit.

TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

TCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731243

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - TCM
 - Harness connector F32
 - Harness connector E2

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of TCM.
2. Check the resistance between the TCM harness connector terminals.

| TCM harness connector | | Resistance (Ω) |
|-----------------------|----------------------------|-----------------|
| Connector No. | Terminal No. | |
| F25 | 33 23 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the TCM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCM. Refer to [TM-178, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the TCM. Refer to [TM-198, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the TCM branch line.

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

ABS BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731244

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ABS actuator and electric unit (control unit) for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ABS actuator and electric unit (control unit).
 2. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.
- Without around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | | Resistance (Ω) |
|---|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| E125 | 26 | 14 | Approx. 54 – 66 |

- With around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | | Resistance (Ω) |
|---|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| E130 | 19 | 30 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the ABS actuator and electric unit (control unit) branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ABS actuator and electric unit (control unit). Refer to [BRC-77, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ABS actuator and electric unit (control unit). Refer to [BRC-142, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ABS actuator and electric unit (control unit) branch line.
NO >> Repair the power supply and the ground circuit.

EPS/DAST 3 BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

EPS/DAST 3 BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731245

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the power steering control module for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of power steering control module.
2. Check the resistance between the power steering control module harness connector terminals.

| Power steering control module harness connector | | | Resistance (Ω) |
|---|--------------|---|-----------------|
| Connector No. | Terminal No. | | |
| E62 | 8 | 7 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the power steering control module branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the power steering control module. Refer to [STC-23, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the power steering oil pump assembly. Refer to [STC-38, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the power steering control module branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

AV BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

AV BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731246

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the AV control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of AV control unit.
2. Check the resistance between the AV control unit harness connector terminals.
 - With navigation system and without BOSE audio system

| AV control unit harness connector | | | Resistance (Ω) |
|-----------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M123 | 43 | 23 | Approx. 54 – 66 |

- With navigation system and BOSE audio system

| AV control unit harness connector | | | Resistance (Ω) |
|-----------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M162 | 43 | 23 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the AV control unit branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the AV control unit. Refer to [AV-166. "AV CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the AV control unit. Refer to [AV-179. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the AV control unit branch line.
NO >> Repair the power supply and the ground circuit.

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

Diagnosis Procedure

INFOID:000000011731247

1. CHECK DTC

Check DTC of the CAN gateway with CONSULT.

Is U1010 or B2600 indicated?

- YES >> Perform a diagnosis of the indicated DTC.
- NO >> GO TO 2.

2. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the CAN gateway for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair the terminal and connector.

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of CAN gateway.
2. Check the resistance between the CAN gateway harness connector terminals.

| CAN gateway harness connector | | | Resistance (Ω) |
|-------------------------------|--------------|---|-----------------|
| Connector No. | Terminal No. | | |
| M5 | 1 | 7 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 4.
- NO >> Repair the CAN gateway branch line (CAN communication circuit 1 side).

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the CAN gateway. Refer to [LAN-121. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the CAN gateway. Refer to [LAN-122. "Removal and Installation"](#).
- YES (Past error)>>Error was detected in the CAN gateway branch line (CAN communication circuit 1 side).
- NO >> Repair the power supply and the ground circuit.

LAN

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

Diagnosis Procedure

INFOID:000000011731248

1. CHECK DTC

Check DTC of the CAN gateway with CONSULT.

Is U1010 or B2600 indicated?

- YES >> Perform a diagnosis of the indicated DTC.
- NO >> GO TO 2.

2. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors of the CAN gateway for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair the terminal and connector.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

| CAN gateway harness connector | | | Continuity |
|-------------------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| M5 | 4 | 6 | Existed |
| | 10 | 12 | Existed |

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair the CAN gateway branch line (CAN communication circuit 2 side).

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the CAN gateway. Refer to [LAN-121, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the CAN gateway. Refer to [LAN-122, "Removal and Installation"](#).
- YES (Past error)>>Error was detected in the CAN gateway branch line (CAN communication circuit 2 side).
- NO >> Repair the power supply and the ground circuit.

HVAC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

HVAC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731249

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the A/C auto amp. for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/C auto amp.
2. Check the resistance between the A/C auto amp. harness connector terminals.

| A/C auto amp. harness connector | | Resistance (Ω) |
|---------------------------------|---------------------------|-----------------|
| Connector No. | Terminal No. | |
| M50 | 1 21 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the A/C auto amp. branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the A/C auto amp. Refer to [HAC-73, "A/C AUTO AMP. : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the A/C auto amp. Refer to [HAC-95, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the A/C auto amp. branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

PWBD BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

PWBD BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731250

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Automatic back door control module
 - Harness connector B41
 - Harness connector M69

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of automatic back door control module.
2. Check the resistance between the automatic back door control module harness connector terminals.

| Automatic back door control module harness connector | | | Resistance (Ω) |
|--|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| B55 | 1 | 17 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the automatic back door control module branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the automatic back door control module. Refer to [DLK-171, "AUTOMATIC BACK DOOR CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the automatic back door control module. Refer to [DLK-311, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the automatic back door control module branch line.

NO >> Repair the power supply and the ground circuit.

4WD BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

4WD BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731251

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the AWD control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of AWD control unit.
2. Check the resistance between the AWD control unit harness connector terminals.

| AWD control unit harness connector | | | Resistance (Ω) |
|------------------------------------|--------------|----|-------------------------|
| Connector No. | Terminal No. | | |
| B135 | 8 | 16 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the AWD control unit branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the AWD control unit. Refer to [DLN-46, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the AWD control unit. Refer to [DLN-58, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the AWD control unit branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

A-BAG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731252

WARNING:

- Before servicing, turn ignition switch OFF, disconnect battery negative terminal, and wait 3 minutes or more. (To discharge backup capacitor.)
- Never use unspecified tester or other measuring device.

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the air bag diagnosis sensor unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Replace the main harness.

2.CHECK AIR BAG DIAGNOSIS SENSOR UNIT

Check the air bag diagnosis sensor unit. Refer to [SRC-40, "Work Flow"](#).

Is the inspection result normal?

- YES >> Replace the main harness.
NO >> Replace parts whose air bag system has a malfunction.

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

Diagnosis Procedure

INFOID:000000011731254

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the data link connector for damage, bend and loose connection (connector side and harness side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

| Data link connector | | | Resistance (Ω) |
|---------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M22 | 13 | 12 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the data link connector branch line circuit (CAN communication circuit 1 side).

NO >> Repair the data link connector branch line (CAN communication circuit 1 side).

LAN

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

Diagnosis Procedure

INFOID:000000011731255

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the data link connector for damage, bend and loose connection (connector side and harness side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

| Data link connector | | | Resistance (Ω) |
|---------------------|--------------|----|-------------------------|
| Connector No. | Terminal No. | | |
| M22 | 6 | 14 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the data link connector branch line circuit (CAN communication circuit 2 side).

NO >> Repair the data link connector branch line (CAN communication circuit 2 side).

M&A BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731256

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the combination meter for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of combination meter.
2. Check the resistance between the combination meter harness connector terminals.

| Combination meter harness connector | | | Resistance (Ω) |
|-------------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M23 | 53 | 52 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the combination meter branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the combination meter. Refer to [MWI-59, "COMBINATION METER : Diagnosis Procedure"](#) .

Is the inspection result normal?

- YES (Present error)>>Replace the combination meter. Refer to [MWI-78, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the combination meter branch line.
 NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

STRG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

STRG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731257

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the steering angle sensor for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of steering angle sensor.
2. Check the resistance between the steering angle sensor harness connector terminals.

| Steering angle sensor harness connector | | | Resistance (Ω) |
|---|--------------|---|-------------------------|
| Connector No. | Terminal No. | | |
| M54 | 5 | 2 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the steering angle sensor branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle sensor. Refer to [BRC-52, "Wiring Diagram"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering angle sensor. Refer to [BRC-145, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the steering angle sensor branch line.
NO >> Repair the power supply and the ground circuit.

BCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

BCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731258

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the BCM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of BCM.
2. Check the resistance between the BCM harness connector terminals.

| BCM harness connector | | | Resistance (Ω) |
|-----------------------|--------------|----|-------------------|
| Connector No. | Terminal No. | | |
| M19 | 60 | 59 | Approx. 108 – 132 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the BCM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the BCM. Refer to [BCS-75, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the BCM. Refer to [BCS-82, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the BCM branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

ICC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731260

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ADAS control unit
 - CAN gateway

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

| CAN gateway harness connector | | | Continuity |
|-------------------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| M5 | 4 | 6 | Existed |
| | 10 | 12 | Existed |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Check the harness and repair the root cause (CAN communication circuit 2 side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway.
2. Disconnect the connector of ADAS control unit.
3. Check the resistance between the ADAS control unit harness connector terminals.

| ADAS control unit harness connector | | | Resistance (Ω) |
|-------------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| B182 | 9 | 10 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 4.
 NO >> Repair the ADAS control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ADAS control unit. Refer to [DAS-84, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ADAS control unit. Refer to [DAS-85, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the ADAS control unit branch line.
 NO >> Repair the power supply and the ground circuit.

ADP BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

ADP BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731261

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Driver seat control unit
 - Harness connector B200
 - Harness connector B54
 - CAN gateway

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

| CAN gateway harness connector | | | Continuity |
|-------------------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| M5 | 4 | 6 | Existed |
| | 10 | 12 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair the root cause (CAN communication circuit 2 side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of driver seat control unit.
2. Check the resistance between the driver seat control unit harness connector terminals.

| Driver seat control unit harness connector | | | Resistance (Ω) |
|--|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| B209 | 16 | 32 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the driver seat control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the driver seat control unit. Refer to [ADP-71, "DRIVER SEAT CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the driver seat control unit. Refer to [ADP-132, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the driver seat control unit branch line.

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

AVM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

AVM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731262

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Around view monitor control unit
 - ADAS control unit

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of ADAS control unit.
2. Check the continuity between the ADAS control unit harness connector terminals.

| ADAS control unit harness connector | | | Continuity |
|-------------------------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| M182 | 2 | 18 | Existed |
| | 5 | 6 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair the root cause (ITS communication circuit side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of ADAS control unit.
2. Disconnect the connector of around view monitor control unit.
3. Check the resistance between the around view monitor control unit harness connector terminals.

| Around view monitor control unit harness connector | | | Resistance (Ω) |
|--|--------------|----|-------------------------|
| Connector No. | Terminal No. | | |
| M96 | 26 | 24 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the around view monitor control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the around view monitor control unit. Refer to [AV-271, "AROUND VIEW MONITOR CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the around view monitor control unit. Refer to [AV-274, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the around view monitor control unit branch line.

NO >> Repair the power supply and the ground circuit.

RDR-R BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

RDR-R BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731265

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Side radar RH
 - Harness connector B142
 - Harness connector B464
 - ADAS control unit

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of ADAS control unit.
2. Check the continuity between the ADAS control unit harness connector terminals.

| ADAS control unit harness connector | | | Continuity |
|-------------------------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| M182 | 2 | 18 | Existed |
| | 5 | 6 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair the root cause (ITS communication circuit side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of ADAS control unit.
2. Disconnect the connector of side radar RH.
3. Check the resistance between the side radar RH harness connector terminals.

| Side radar RH harness connector | | | Resistance (Ω) |
|---------------------------------|--------------|---|-----------------|
| Connector No. | Terminal No. | | |
| B466 | 6 | 7 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the side radar RH branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the side radar RH. Refer to [DAS-170, "SIDE RADAR RH: Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the side radar RH. Refer to [DAS-188, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the side radar RH branch line.

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

RDR-L BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

RDR-L BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731266

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Side radar LH
 - Harness connector B463
 - Harness connector B92
 - ADAS control unit

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of ADAS control unit.
2. Check the continuity between the ADAS control unit harness connector terminals.

| ADAS control unit harness connector | | | Continuity |
|-------------------------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| M182 | 2 | 18 | Existed |
| | 5 | 6 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair the root cause (ITS communication circuit side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of ADAS control unit.
2. Disconnect the connector of side radar LH.
3. Check the resistance between the side radar LH harness connector terminals.

| Side radar LH harness connector | | | Resistance (Ω) |
|---------------------------------|--------------|---|-------------------------|
| Connector No. | Terminal No. | | |
| B465 | 6 | 7 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the side radar LH branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the side radar LH. Refer to [DAS-170, "SIDE RADAR LH: Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the side radar LH. Refer to [DAS-188, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the side radar LH branch line.

NO >> Repair the power supply and the ground circuit.

CAN COMMUNICATION CIRCUIT 1

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

CAN COMMUNICATION CIRCUIT 1

Diagnosis Procedure

INFOID:000000011731271

1. CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication circuit 1.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

| Data link connector | | Continuity |
|---------------------|--------------|-------------|
| Connector No. | Terminal No. | |
| M22 | 13 | Not existed |
| | 12 | |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause.

3. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

| Data link connector | | Ground | Continuity |
|---------------------|--------------|--------|-------------|
| Connector No. | Terminal No. | | |
| M22 | 13 | | Not existed |
| | 12 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check the harness and repair the root cause.

4. CHECK ECM AND BCM TERMINATION CIRCUIT

1. Remove the ECM and the BCM.
2. Check the resistance between the ECM terminals.

| ECM | | Resistance (Ω) |
|--------------|-----|-------------------------|
| Terminal No. | | |
| 124 | 123 | Approx. 108 – 132 |

3. Check the resistance between the BCM terminals.

| BCM | | Resistance (Ω) |
|--------------|----|-------------------------|
| Terminal No. | | |
| 60 | 59 | Approx. 108 – 132 |

Is the measurement value within the specification?

- YES >> GO TO 5.
NO >> Replace the ECM and/or the BCM.

5. CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

CAN COMMUNICATION CIRCUIT 1

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

Inspection result

Reproduced>>GO TO 6.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

6.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication circuit 1.

NOTE:

ECM and BCM have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

CAN COMMUNICATION CIRCUIT 2

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

CAN COMMUNICATION CIRCUIT 2

Diagnosis Procedure

INFOID:0000000011731272

1.CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication circuit 2.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

| Data link connector | | | Continuity |
|---------------------|--------------|----|-------------|
| Connector No. | Terminal No. | | |
| M22 | 6 | 14 | Not existed |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause.

3.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

| Data link connector | Terminal No. | Ground | Continuity |
|---------------------|--------------|--------|-------------|
| Connector No. | | | Not existed |
| M22 | 6 | | Not existed |
| | 14 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check the harness and repair the root cause.

4.CHECK CAN GATEWAY TERMINATION CIRCUIT

1. Remove the CAN gateway.
2. Check the resistance between the CAN gateway terminals.

| CAN gateway | | Resistance (Ω) |
|--------------|----|-------------------|
| Terminal No. | | |
| 4 | 10 | Approx. 108 – 132 |
| 6 | 12 | Approx. 108 – 132 |

Is the measurement value within the specification?

- YES >> GO TO 5.
NO >> Replace the CAN gateway.

5.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

Inspection result

- Reproduced>>GO TO 6.
Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

CAN COMMUNICATION CIRCUIT 2

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

6. CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication circuit 2.

NOTE:

CAN gateway has two termination circuits. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

ITS COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

ITS COMMUNICATION CIRCUIT

Diagnosis Procedure

INFOID:0000000011731273

1. CHECK CAN DIAGNOSIS

Check the CAN diagnosis results from CONSULT to see that the CAN communication circuit 1 and CAN communication circuit 2 have no malfunction.

Are the CAN communication 1 and CAN communication 2 circuits normal?

YES >> GO TO 2.

NO >> Check and repair CAN communication circuit 1 and/or CAN communication circuit 2.

2. CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ADAS control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the terminal and connector.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the ADAS control unit harness connector.
2. Check the continuity between the ADAS control unit harness connector terminals.

| ADAS control unit harness connector | | | Continuity |
|-------------------------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| M182 | 2 | 18 | Existed |
| | 5 | 6 | Existed |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair the ADAS control unit branch line. (ITS communication circuit side).

4. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

1. Disconnect the following harness connectors.
 - Around view monitor control unit
 - Side radar RH
 - Side radar LH
 - ICC sensor
2. Check the continuity between the ADAS control unit harness connector terminals.

| ADAS control unit harness connector | | | Continuity |
|-------------------------------------|--------------|---|-------------|
| Connector No. | Terminal No. | | |
| M182 | 2 | 5 | Not existed |

Is the inspection result normal?

YES >> GO TO 5.

NO >> Check the harness and repair the root cause.

5. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the ADAS control unit harness connector and the ground.

| ADAS control unit harness connector | | Ground | Continuity |
|-------------------------------------|--------------|--------|-------------|
| Connector No. | Terminal No. | | |
| M182 | 2 | | Not existed |
| | 5 | | Not existed |

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

ITS COMMUNICATION CIRCUIT

[CAN SYSTEM (TYPE 9)]

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 6.

NO >> Check the harness and repair the root cause.

6.CHECK TERMINATION CIRCUIT

1. Remove the ADAS control unit.
2. Check the resistance between the ADAS control unit terminals.

| ADAS control unit | | Resistance (Ω) |
|-------------------|---|-------------------|
| Terminal No. | | |
| 2 | 5 | Approx. 108 – 132 |
| 18 | 6 | |

Is the inspection result normal?

YES >> GO TO 7.

NO >> Replace the ADAS control unit.

7.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

Inspection result

Reproduced>>GO TO 8.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

8.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of ITS communication circuit.

NOTE:

ADAS control unit and ICC sensor have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

MAIN LINE BETWEEN IPDM-E AND ABS CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

DTC/CIRCUIT DIAGNOSIS

MAIN LINE BETWEEN IPDM-E AND ABS CIRCUIT

Diagnosis Procedure

INFOID:000000011731276

1. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
 - ECM
 - IPDM E/R
 - ABS actuator and electric unit (control unit)
4. Check the continuity between the IPDM E/R harness connector and the ABS actuator and electric unit (control unit) harness connector.
 - Without around view monitor system

| IPDM E/R harness connector | | ABS actuator and electric unit (control unit) harness connector | | Continuity |
|----------------------------|--------------|---|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E119 | 29 | E125 | 26 | Existed |
| | 28 | | 14 | Existed |

- With around view monitor system

| IPDM E/R harness connector | | ABS actuator and electric unit (control unit) harness connector | | Continuity |
|----------------------------|--------------|---|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E119 | 29 | E130 | 19 | Existed |
| | 28 | | 30 | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the IPDM E/R and the ABS actuator and electric unit (control unit).

NO >> Repair the main line between the IPDM E/R and the ABS actuator and electric unit (control unit).

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

MAIN LINE BETWEEN ABS AND HVAC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

MAIN LINE BETWEEN ABS AND HVAC CIRCUIT

Diagnosis Procedure

INFOID:000000011731277

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector E152
 - Harness connector M31

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - ABS actuator and electric unit (control unit)
 - Harness connectors E152 and M31.
2. Check the continuity between the ABS actuator and electric unit (control unit) harness connector and the harness connector.
 - Without around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | Harness connector | | Continuity |
|---|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E125 | 26 | E152 | 12G | Existed |
| | 14 | | 11G | Existed |

- With around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | Harness connector | | Continuity |
|---|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E130 | 19 | E152 | 12G | Existed |
| | 30 | | 11G | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the ABS actuator and electric unit (control unit) and the harness connector E152.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector and the A/C auto amp harness connector.

| Harness connector | | A/C auto amp. harness connector | | Continuity |
|-------------------|--------------|---------------------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M31 | 12G | M50 | 1 | Existed |
| | 11G | | 21 | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the ABS actuator and electric unit (control unit) and the A/C auto amp.

NO >> Repair the main line between the harness connector M31 and the A/C auto amp.

MAIN LINE BETWEEN HVAC AND 4WD CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

MAIN LINE BETWEEN HVAC AND 4WD CIRCUIT

Diagnosis Procedure

INFOID:000000011731278

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M84
 - Harness connector B101

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - A/C auto amp.
 - Harness connectors M84 and B101
2. Check the continuity between the A/C auto amp. harness connector and the harness connector.

| A/C auto amp. harness connector | | Harness connector | | Continuity |
|---------------------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M50 | 1 | M84 | 22 | Existed |
| | 21 | | 21 | Existed |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair the main line between the A/C auto amp. and the harness connector M84.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector terminals.

| Connector No. | Harness connector | | Continuity |
|---------------|-------------------|----|------------|
| | Terminal No. | | |
| B101 | 22 | 29 | Existed |
| | 21 | 28 | Existed |

Is the inspection result normal?

- YES (Present error)>>Check CAN system type decision again.
 YES (Past error)>>Error was detected in the main line between the A/C auto amp. and the AWD control unit.
 NO >> Repair the main line between the harness connector B101 and the AWD control unit.

LAN

MAIN LINE BETWEEN 4WD AND DLC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

MAIN LINE BETWEEN 4WD AND DLC CIRCUIT

Diagnosis Procedure

INFOID:000000011731280

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M84
 - Harness connector B101

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors M84 and B101.
2. Check the continuity between the harness connector terminals.

| Harness connector | | Continuity | |
|-------------------|--------------|------------|---------|
| Connector No. | Terminal No. | | |
| B101 | 22 | 29 | Existed |
| | 21 | 28 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the AWD control unit and the harness connector B101.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector and the data link connector.

- Without around view monitor

| Harness connector | | Data link connector | | Continuity |
|-------------------|--------------|---------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M84 | 29 | M22 | 6 | Existed |
| | 28 | | 14 | Existed |

- With around view monitor

| Harness connector | | Data link connector | | Continuity |
|-------------------|--------------|---------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M84 | 29 | M22 | 13 | Existed |
| | 28 | | 12 | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the AWD control unit and the data link connector.

NO >> Repair the main line between the harness connector M84 and the data link connector.

MAIN LINE BETWEEN DLC AND ADP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

MAIN LINE BETWEEN DLC AND ADP CIRCUIT

Diagnosis Procedure

INFOID:000000011731281

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M40
 - Harness connector B69

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors M40 and B69.
2. Check the continuity between the data link connector and harness connector.

| Data link connector | | Harness connector | | Continuity |
|---------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M22 | 6 | M40 | 88A | Existed |
| | 14 | | 87A | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the data link connector and the harness connector M40.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector terminals.

| Harness connector | | | Continuity |
|-------------------|--------------|-----|------------|
| Connector No. | Terminal No. | | |
| B69 | 88A | 86A | Existed |
| | 87A | 85A | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the data link connector and drive seat control unit.

NO >> Repair the main line between the harness connector B69 and the drive seat control unit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

MAIN LINE BETWEEN AVM AND RDR-R CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

MAIN LINE BETWEEN AVM AND RDR-R CIRCUIT

Diagnosis Procedure

INFOID:000000011731282

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M84
 - Harness connector B101

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Around view monitor control unit
 - Harness connectors M84 and B101
2. Check the continuity between the around view monitor control unit harness connector and the harness connector.

| Around view monitor control unit harness connector | | Harness connector | | Continuity |
|--|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M96 | 26 | M84 | 8 | Existed |
| | 24 | | 7 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the around view monitor control unit and the harness connector M84.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors B464 and B142.
2. Check the continuity between the harness connectors.

| Harness connector | | Harness connector | | Continuity |
|-------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| B101 | 8 | B142 | 7 | Existed |
| | 7 | | 6 | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the around view monitor control unit and the side radar RH.

NO >> Repair the main line between the harness connector B101 and B142.

MAIN LINE BETWEEN RDR-R AND RDR-L CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

MAIN LINE BETWEEN RDR-R AND RDR-L CIRCUIT

Diagnosis Procedure

INFOID:000000011731283

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B140
 - Harness connector B49

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Harness connectors B464 and B142
 - Harness connectors B140 and B49
2. Check the continuity between the harness connectors.

| Harness connector | | Harness connector | | Continuity |
|-------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| B142 | 7 | B140 | 6 | Existed |
| | 6 | | 7 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the harness connector B142 and B140.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors B92 and B463.
2. Check the continuity between the harness connectors.

| Harness connector | | Harness connector | | Continuity |
|-------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| B49 | 6 | B92 | 7 | Existed |
| | 7 | | 6 | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the side radar RH and the side radar LH.

NO >> Repair the main line between the harness connector B49 and B92.

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

MAIN LINE BETWEEN RDR-L AND LASER CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

MAIN LINE BETWEEN RDR-L AND LASER CIRCUIT

Diagnosis Procedure

INFOID:000000011731285

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B40
 - Harness connector E34
 - Harness connector E5
 - Harness connector E207

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Harness connectors B92 and B463
 - Harness connectors B40 and E34
2. Check the continuity between the harness connectors.

| Harness connector | | Harness connector | | Continuity |
|-------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| B92 | 7 | B40 | 13 | Existed |
| | 6 | | 14 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the harness connector B92 and B40.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector E5 and E207.
2. Check the continuity between the harness connectors.

| Harness connector | | Harness connector | | Continuity |
|-------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E34 | 13 | E5 | 18 | Existed |
| | 14 | | 17 | Existed |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair the main line between the harness connector E34 and E5.

4. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector terminals.

| Harness connector | | | Continuity |
|-------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| E207 | 18 | 21 | Existed |
| | 17 | 20 | Existed |

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the side radar LH and the ICC sensor.

NO >> Repair the main line between the harness connector E207 and the ICC sensor.

ECM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

ECM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731288

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ECM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ECM.
2. Check the resistance between the ECM harness connector terminals.

| ECM harness connector | | | Resistance (Ω) |
|-----------------------|--------------|-----|-------------------------|
| Connector No. | Terminal No. | | |
| E32 | 124 | 123 | Approx. 108 – 132 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the ECM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ECM. Refer to [EC-188. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ECM. Refer to [EC-579. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ECM branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

IPDM-E BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

IPDM-E BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731289

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the IPDM E/R for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of IPDM E/R.
2. Check the resistance between the IPDM E/R harness connector terminals.

| IPDM E/R harness connector | | | Resistance (Ω) |
|----------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| E119 | 29 | 28 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the IPDM E/R branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the IPDM E/R. Refer to [PCS-36, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the IPDM E/R. Refer to [PCS-37, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the IPDM E/R branch line.
NO >> Repair the power supply and the ground circuit.

TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

TCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731290

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - TCM
 - Harness connector F32
 - Harness connector E2

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of TCM.
2. Check the resistance between the TCM harness connector terminals.

| TCM harness connector | | | Resistance (Ω) |
|-----------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| F25 | 33 | 23 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the TCM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCM. Refer to [TM-178, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the TCM. Refer to [TM-198, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the TCM branch line.

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

ABS BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731291

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ABS actuator and electric unit (control unit) for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ABS actuator and electric unit (control unit).
 2. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.
- Without around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | | Resistance (Ω) |
|---|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| E125 | 26 | 14 | Approx. 54 – 66 |

- With around view monitor system

| ABS actuator and electric unit (control unit) harness connector | | | Resistance (Ω) |
|---|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| E130 | 19 | 30 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the ABS actuator and electric unit (control unit) branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ABS actuator and electric unit (control unit). Refer to [BRC-77, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ABS actuator and electric unit (control unit). Refer to [BRC-142, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ABS actuator and electric unit (control unit) branch line.
NO >> Repair the power supply and the ground circuit.

EPS/DAST 3 BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

EPS/DAST 3 BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731292

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the power steering control module for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of power steering control module.
2. Check the resistance between the power steering control module harness connector terminals.

| Power steering control module harness connector | | | Resistance (Ω) |
|---|--------------|---|-----------------|
| Connector No. | Terminal No. | | |
| E62 | 8 | 7 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the power steering control module branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the power steering control module. Refer to [STC-23, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the power steering oil pump assembly. Refer to [STC-38, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the power steering control module branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

AV BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

AV BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731293

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the AV control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of AV control unit.
 2. Check the resistance between the AV control unit harness connector terminals.
- With navigation system and without BOSE audio system

| AV control unit harness connector | | | Resistance (Ω) |
|-----------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M123 | 43 | 23 | Approx. 54 – 66 |

- With navigation system and BOSE audio system

| AV control unit harness connector | | | Resistance (Ω) |
|-----------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M162 | 43 | 23 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the AV control unit branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the AV control unit. Refer to [AV-166. "AV CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the AV control unit. Refer to [AV-179. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the AV control unit branch line.
NO >> Repair the power supply and the ground circuit.

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

Diagnosis Procedure

INFOID:000000011731294

1. CHECK DTC

Check DTC of the CAN gateway with CONSULT.

Is U1010 or B2600 indicated?

- YES >> Perform a diagnosis of the indicated DTC.
- NO >> GO TO 2.

2. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the CAN gateway for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair the terminal and connector.

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of CAN gateway.
2. Check the resistance between the CAN gateway harness connector terminals.

| CAN gateway harness connector | | | Resistance (Ω) |
|-------------------------------|--------------|---|-----------------|
| Connector No. | Terminal No. | | |
| M5 | 1 | 7 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 4.
- NO >> Repair the CAN gateway branch line (CAN communication circuit 1 side).

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the CAN gateway. Refer to [LAN-121. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the CAN gateway. Refer to [LAN-122. "Removal and Installation"](#).
- YES (Past error)>>Error was detected in the CAN gateway branch line (CAN communication circuit 1 side).
- NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

Diagnosis Procedure

INFOID:000000011731295

1. CHECK DTC

Check DTC of the CAN gateway with CONSULT.

Is U1010 or B2600 indicated?

- YES >> Perform a diagnosis of the indicated DTC.
- NO >> GO TO 2.

2. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors of the CAN gateway for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair the terminal and connector.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

| CAN gateway harness connector | | | Continuity |
|-------------------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| M5 | 4 | 6 | Existed |
| | 10 | 12 | Existed |

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair the CAN gateway branch line (CAN communication circuit 2 side).

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the CAN gateway. Refer to [LAN-121, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the CAN gateway. Refer to [LAN-122, "Removal and Installation"](#).
- YES (Past error)>>Error was detected in the CAN gateway branch line (CAN communication circuit 2 side).
- NO >> Repair the power supply and the ground circuit.

HVAC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

HVAC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731296

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the A/C auto amp. for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/C auto amp.
2. Check the resistance between the A/C auto amp. harness connector terminals.

| A/C auto amp. harness connector | | | Resistance (Ω) |
|---------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M50 | 1 | 21 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the A/C auto amp. branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the A/C auto amp. Refer to [HAC-73, "A/C AUTO AMP. : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the A/C auto amp. Refer to [HAC-95, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the A/C auto amp. branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

PWBD BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

PWBD BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731297

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Automatic back door control module
 - Harness connector B41
 - Harness connector M69

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of automatic back door control module.
2. Check the resistance between the automatic back door control module harness connector terminals.

| Automatic back door control module harness connector | | | Resistance (Ω) |
|--|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| B55 | 1 | 17 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the automatic back door control module branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the automatic back door control module. Refer to [DLK-171, "AUTOMATIC BACK DOOR CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the automatic back door control module. Refer to [DLK-311, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the automatic back door control module branch line.

NO >> Repair the power supply and the ground circuit.

4WD BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

4WD BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731298

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the AWD control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of AWD control unit.
2. Check the resistance between the AWD control unit harness connector terminals.

| AWD control unit harness connector | | | Resistance (Ω) |
|------------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| B135 | 8 | 16 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the AWD control unit branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the AWD control unit. Refer to [DLN-46, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the AWD control unit. Refer to [DLN-58, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the AWD control unit branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

A-BAG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

A-BAG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731299

WARNING:

- Before servicing, turn ignition switch OFF, disconnect battery negative terminal, and wait 3 minutes or more. (To discharge backup capacitor.)
- Never use unspecified tester or other measuring device.

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the air bag diagnosis sensor unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Replace the main harness.

2.CHECK AIR BAG DIAGNOSIS SENSOR UNIT

Check the air bag diagnosis sensor unit. Refer to [SRC-40, "Work Flow"](#).

Is the inspection result normal?

- YES >> Replace the main harness.
NO >> Replace parts whose air bag system has a malfunction.

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

Diagnosis Procedure

INFOID:000000011731301

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the data link connector for damage, bend and loose connection (connector side and harness side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

| Data link connector | | | Resistance (Ω) |
|---------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M22 | 13 | 12 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the data link connector branch line circuit (CAN communication circuit 1 side).

NO >> Repair the data link connector branch line (CAN communication circuit 1 side).

LAN

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

Diagnosis Procedure

INFOID:000000011731302

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the data link connector for damage, bend and loose connection (connector side and harness side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

| Data link connector | | | Resistance (Ω) |
|---------------------|--------------|----|-------------------------|
| Connector No. | Terminal No. | | |
| M22 | 6 | 14 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the data link connector branch line circuit (CAN communication circuit 2 side).

NO >> Repair the data link connector branch line (CAN communication circuit 2 side).

M&A BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731303

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the combination meter for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of combination meter.
2. Check the resistance between the combination meter harness connector terminals.

| Combination meter harness connector | | | Resistance (Ω) |
|-------------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M23 | 53 | 52 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the combination meter branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the combination meter. Refer to [MWI-59, "COMBINATION METER : Diagnosis Procedure"](#) .

Is the inspection result normal?

- YES (Present error)>>Replace the combination meter. Refer to [MWI-78, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the combination meter branch line.
 NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

STRG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

STRG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731304

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the steering angle sensor for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of steering angle sensor.
2. Check the resistance between the steering angle sensor harness connector terminals.

| Steering angle sensor harness connector | | | Resistance (Ω) |
|---|--------------|---|-------------------------|
| Connector No. | Terminal No. | | |
| M54 | 5 | 2 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the steering angle sensor branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle sensor. Refer to [BRC-52, "Wiring Diagram"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering angle sensor. Refer to [BRC-145, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the steering angle sensor branch line.
NO >> Repair the power supply and the ground circuit.

BCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

BCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731305

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the BCM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of BCM.
2. Check the resistance between the BCM harness connector terminals.

| BCM harness connector | | | Resistance (Ω) |
|-----------------------|--------------|----|-------------------|
| Connector No. | Terminal No. | | |
| M19 | 60 | 59 | Approx. 108 – 132 |

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the BCM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the BCM. Refer to [BCS-75, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the BCM. Refer to [BCS-82, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the BCM branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

ICC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731307

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ADAS control unit
 - CAN gateway

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

| CAN gateway harness connector | | | Continuity |
|-------------------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| M5 | 4 | 6 | Existed |
| | 10 | 12 | Existed |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Check the harness and repair the root cause (CAN communication circuit 2 side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway.
2. Disconnect the connector of ADAS control unit.
3. Check the resistance between the ADAS control unit harness connector terminals.

| ADAS control unit harness connector | | | Resistance (Ω) |
|-------------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| B182 | 9 | 10 | Approx. 54 – 66 |

Is the measurement value within the specification?

- YES >> GO TO 4.
 NO >> Repair the ADAS control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ADAS control unit. Refer to [DAS-84, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ADAS control unit. Refer to [DAS-85, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the ADAS control unit branch line.
 NO >> Repair the power supply and the ground circuit.

ADP BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

ADP BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731308

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Driver seat control unit
 - Harness connector B200
 - Harness connector B54
 - CAN gateway

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

| CAN gateway harness connector | | | Continuity |
|-------------------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| M5 | 4 | 6 | Existed |
| | 10 | 12 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair the root cause (CAN communication circuit 2 side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of driver seat control unit.
2. Check the resistance between the driver seat control unit harness connector terminals.

| Driver seat control unit harness connector | | | Resistance (Ω) |
|--|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| B209 | 16 | 32 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the driver seat control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the driver seat control unit. Refer to [ADP-71, "DRIVER SEAT CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the driver seat control unit. Refer to [ADP-132, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the driver seat control unit branch line.

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

AVM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

AVM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731309

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Around view monitor control unit
 - ADAS control unit

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of ADAS control unit.
2. Check the continuity between the ADAS control unit harness connector terminals.

| ADAS control unit harness connector | | | Continuity |
|-------------------------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| M182 | 2 | 18 | Existed |
| | 5 | 6 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair the root cause (ITS communication circuit side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of ADAS control unit.
2. Disconnect the connector of around view monitor control unit.
3. Check the resistance between the around view monitor control unit harness connector terminals.

| Around view monitor control unit harness connector | | | Resistance (Ω) |
|--|--------------|----|-------------------------|
| Connector No. | Terminal No. | | |
| M96 | 26 | 24 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the around view monitor control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the around view monitor control unit. Refer to [AV-271, "AROUND VIEW MONITOR CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the around view monitor control unit. Refer to [AV-274, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the around view monitor control unit branch line.

NO >> Repair the power supply and the ground circuit.

RDR-R BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

RDR-R BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731312

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Side radar RH
 - Harness connector B142
 - Harness connector B464
 - ADAS control unit

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of ADAS control unit.
2. Check the continuity between the ADAS control unit harness connector terminals.

| ADAS control unit harness connector | | | Continuity |
|-------------------------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| M182 | 2 | 18 | Existed |
| | 5 | 6 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair the root cause (ITS communication circuit side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of ADAS control unit.
2. Disconnect the connector of side radar RH.
3. Check the resistance between the side radar RH harness connector terminals.

| Side radar RH harness connector | | | Resistance (Ω) |
|---------------------------------|--------------|---|-------------------------|
| Connector No. | Terminal No. | | |
| B466 | 6 | 7 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the side radar RH branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the side radar RH. Refer to [DAS-170, "SIDE RADAR RH: Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the side radar RH. Refer to [DAS-188, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the side radar RH branch line.

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

RDR-L BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

RDR-L BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731313

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Side radar LH
 - Harness connector B463
 - Harness connector B92
 - ADAS control unit

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of ADAS control unit.
2. Check the continuity between the ADAS control unit harness connector terminals.

| ADAS control unit harness connector | | | Continuity |
|-------------------------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| M182 | 2 | 18 | Existed |
| | 5 | 6 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair the root cause (ITS communication circuit side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of ADAS control unit.
2. Disconnect the connector of side radar LH.
3. Check the resistance between the side radar LH harness connector terminals.

| Side radar LH harness connector | | | Resistance (Ω) |
|---------------------------------|--------------|---|-------------------------|
| Connector No. | Terminal No. | | |
| B465 | 6 | 7 | Approx. 54 – 66 |

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the side radar LH branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the side radar LH. Refer to [DAS-170, "SIDE RADAR LH: Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the side radar LH. Refer to [DAS-188, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the side radar LH branch line.

NO >> Repair the power supply and the ground circuit.

LASER BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

LASER BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000011731316

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ICC sensor
 - ADAS control unit

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of ADAS control unit.
2. Check the continuity between the ADAS control unit harness connector terminals.

| ADAS control unit harness connector | | | Continuity |
|-------------------------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| M182 | 2 | 18 | Existed |
| | 5 | 6 | Existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair the root cause (ITS communication circuit side).

3.CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of ADAS control unit.
2. Disconnect the connector of ICC sensor.
3. Check the resistance between the ICC sensor harness connector terminals.

| ICC sensor harness connector | | | Resistance (Ω) |
|------------------------------|--------------|---|-------------------|
| Connector No. | Terminal No. | | |
| E219 | 2 | 3 | Approx. 108 – 132 |

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the ICC sensor branch line.

4.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ICC sensor. Refer to [CCS-126, "ICC SENSOR : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the ICC sensor. Refer to [CCS-148, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the ICC sensor branch line.

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

CAN COMMUNICATION CIRCUIT 1

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

CAN COMMUNICATION CIRCUIT 1

Diagnosis Procedure

INFOID:000000011731318

1.CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication circuit 1.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

| Data link connector | | Continuity |
|---------------------|--------------|-------------|
| Connector No. | Terminal No. | |
| M22 | 13 | Not existed |
| | 12 | |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause.

3.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

| Data link connector | | Ground | Continuity |
|---------------------|--------------|--------|-------------|
| Connector No. | Terminal No. | | |
| M22 | 13 | | Not existed |
| | 12 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check the harness and repair the root cause.

4.CHECK ECM AND BCM TERMINATION CIRCUIT

1. Remove the ECM and the BCM.
2. Check the resistance between the ECM terminals.

| ECM | | Resistance (Ω) |
|--------------|-----|-------------------------|
| Terminal No. | | |
| 124 | 123 | Approx. 108 – 132 |

3. Check the resistance between the BCM terminals.

| BCM | | Resistance (Ω) |
|--------------|----|-------------------------|
| Terminal No. | | |
| 60 | 59 | Approx. 108 – 132 |

Is the measurement value within the specification?

- YES >> GO TO 5.
NO >> Replace the ECM and/or the BCM.

5.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

CAN COMMUNICATION CIRCUIT 1

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

Inspection result

Reproduced>>GO TO 6.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

6.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication circuit 1.

NOTE:

ECM and BCM have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

CAN COMMUNICATION CIRCUIT 2

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

CAN COMMUNICATION CIRCUIT 2

Diagnosis Procedure

INFOID:000000011731319

1.CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication circuit 2.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

| Data link connector | | | Continuity |
|---------------------|--------------|----|-------------|
| Connector No. | Terminal No. | | |
| M22 | 6 | 14 | Not existed |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause.

3.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

| Data link connector | Terminal No. | Ground | Continuity |
|---------------------|--------------|--------|-------------|
| Connector No. | | | Continuity |
| M22 | 6 | | Not existed |
| | 14 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check the harness and repair the root cause.

4.CHECK CAN GATEWAY TERMINATION CIRCUIT

1. Remove the CAN gateway.
2. Check the resistance between the CAN gateway terminals.

| CAN gateway | | Resistance (Ω) |
|--------------|----|-------------------|
| Terminal No. | | |
| 4 | 10 | Approx. 108 – 132 |
| 6 | 12 | Approx. 108 – 132 |

Is the measurement value within the specification?

- YES >> GO TO 5.
NO >> Replace the CAN gateway.

5.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

Inspection result

- Reproduced>>GO TO 6.
Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

CAN COMMUNICATION CIRCUIT 2

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

6. CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication circuit 2.

NOTE:

CAN gateway has two termination circuits. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

A

B

C

D

E

F

G

H

I

J

K

L

LAN

N

O

P

ITS COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

ITS COMMUNICATION CIRCUIT

Diagnosis Procedure

INFOID:000000011731320

1. CHECK CAN DIAGNOSIS

Check the CAN diagnosis results from CONSULT to see that the CAN communication circuit 1 and CAN communication circuit 2 have no malfunction.

Are the CAN communication 1 and CAN communication 2 circuits normal?

YES >> GO TO 2.

NO >> Check and repair CAN communication circuit 1 and/or CAN communication circuit 2.

2. CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ADAS control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the terminal and connector.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the ADAS control unit harness connector.
2. Check the continuity between the ADAS control unit harness connector terminals.

| ADAS control unit harness connector | | | Continuity |
|-------------------------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| M182 | 2 | 18 | Existed |
| | 5 | 6 | Existed |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair the ADAS control unit branch line. (ITS communication circuit side).

4. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

1. Disconnect the following harness connectors.
 - Around view monitor control unit
 - Side radar RH
 - Side radar LH
 - ICC sensor
2. Check the continuity between the ADAS control unit harness connector terminals.

| ADAS control unit harness connector | | | Continuity |
|-------------------------------------|--------------|---|-------------|
| Connector No. | Terminal No. | | |
| M182 | 2 | 5 | Not existed |

Is the inspection result normal?

YES >> GO TO 5.

NO >> Check the harness and repair the root cause.

5. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the ADAS control unit harness connector and the ground.

| ADAS control unit harness connector | | Ground | Continuity |
|-------------------------------------|--------------|--------|-------------|
| Connector No. | Terminal No. | | |
| M182 | 2 | | Not existed |
| | 5 | | Not existed |

ITS COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

Is the inspection result normal?

- YES >> GO TO 6.
- NO >> Check the harness and repair the root cause.

6.CHECK TERMINATION CIRCUIT

1. Remove the ADAS control unit.
2. Check the resistance between the ADAS control unit terminals.

| ADAS control unit | | Resistance (Ω) |
|-------------------|---|-------------------|
| Terminal No. | | |
| 2 | 5 | Approx. 108 – 132 |
| 18 | 6 | |

Is the inspection result normal?

- YES >> GO TO 7.
- NO >> Replace the ADAS control unit.

7.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

Inspection result

- Reproduced>>GO TO 8.
- Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

8.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of ITS communication circuit.
4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

ADAS control unit and ICC sensor have a termination circuit. Check other units first.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

- Reproduced>>Connect the connector. Check other units as per the above procedure.
- Non-reproduced>>Replace the unit whose connector was disconnected.

A
B
C
D
E
F
G
H
I
J
K
L

LAN