

# SECTION **SRC**

## SRS AIRBAG CONTROL SYSTEM

### CONTENTS

<b>PRECAUTION</b> .....	4	SEAT BELT WARNING LAMP SYSTEM : System Diagram .....	14
<b>PRECAUTIONS</b> .....	4	SEAT BELT WARNING LAMP SYSTEM : System Description .....	15
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	4	<b>DIAGNOSIS SYSTEM (AIR BAG)</b> .....	16
Precaution for SRS "AIR BAG" and "SEAT BELT PRE-TENSIONER" Service .....	4	Diagnosis Description .....	16
<b>SYSTEM DESCRIPTION</b> .....	5	SRS Operation Check .....	16
<b>COMPONENT PARTS</b> .....	5	Trouble Diagnosis with CONSULT .....	17
Component Parts Location .....	5	SRS History Check .....	17
Component Description .....	6	SRS Final Check .....	17
Driver Air Bag Module .....	7	CONSULT Function (AIR BAG) .....	18
Front Passenger Air Bag Module .....	7	CONSULT Function (OCCUPANT DETECTION)....	18
Left Knee Air Bag Module .....	7	<b>ECU DIAGNOSIS INFORMATION</b> .....	19
Side Air Bag Module .....	8	<b>DIAGNOSIS SENSOR UNIT</b> .....	19
Side Curtain Air Bag Module .....	8	DTC Index .....	19
Front Seat Belt Pre-tensioner .....	8	<b>WIRING DIAGRAM</b> .....	24
Air Bag Diagnosis Sensor Unit .....	8	<b>SRS AIR BAG SYSTEM</b> .....	24
Crash Zone Sensor .....	9	Wiring Diagram .....	24
Front Side Air Bag Satellite Sensor .....	9	<b>BASIC INSPECTION</b> .....	40
Rear Side Air Bag Satellite Sensor .....	9	<b>DIAGNOSIS AND REPAIR WORK FLOW</b> .....	40
Front Door Satellite Sensor .....	9	Work Flow .....	40
Front Passenger Air Bag Off Indicator .....	10	<b>INSPECTION AND ADJUSTMENT</b> .....	43
SRS Component Connectors .....	10	<b>ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT</b> .....	43
<b>SYSTEM</b> .....	12	ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description .....	43
<b>SRS AIR BAG SYSTEM</b> .....	12	ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement .....	43
SRS AIR BAG SYSTEM : System Diagram .....	12	<b>ZERO POINT RESET</b> .....	44
SRS AIR BAG SYSTEM : System Description .....	12	ZERO POINT RESET : Description .....	44
<b>OCCUPANT CLASSIFICATION SYSTEM</b> .....	12	ZERO POINT RESET : Special Repair Requirement .....	44
OCCUPANT CLASSIFICATION SYSTEM : System Diagram .....	13		
OCCUPANT CLASSIFICATION SYSTEM : System Description .....	13		
<b>SEAT BELT WARNING LAMP SYSTEM</b> .....	14		

<b>CONFIGURATION</b> .....	44	DTC Description .....	79
CONFIGURATION : Work Procedure .....	44	Diagnosis Procedure .....	81
<b>INTERMITTENT INCIDENT</b> .....	46	<b>B0097 REAR SIDE AIR BAG SATELLITE</b>	
Inspection Procedure .....	46	<b>SENSOR RH</b> .....	83
Trouble Diagnosis with CONSULT .....	46	DTC Description .....	83
<b>DTC/CIRCUIT DIAGNOSIS</b> .....	47	Diagnosis Procedure .....	85
<b>U1000 CAN COMM CIRCUIT</b> .....	47	<b>B0093 FRONT DOOR SATELLITE SENSOR</b>	
Description .....	47	<b>LH</b> .....	87
DTC Logic .....	47	DTC Description .....	87
Diagnosis Procedure .....	47	Diagnosis Procedure .....	89
<b>U1010 CONTROL UNIT (CAN)</b> .....	48	<b>B0098 FRONT DOOR SATELLITE SENSOR</b>	
Description .....	48	<b>RH</b> .....	91
DTC Logic .....	48	DTC Description .....	91
Diagnosis Procedure .....	48	Diagnosis Procedure .....	93
<b>B0001, B0002 DRIVER AIRBAG MODULE</b> ....	49	<b>B00A0 OCCUPANT CLASSIFICATION SYS-</b>	
DTC Description .....	49	<b>TEM CONTROL UNIT</b> .....	95
Diagnosis Procedure .....	50	Description .....	95
<b>B0010, B0011 PASSENGER AIRBAG MOD-</b>		DTC Description .....	95
<b>ULE</b> .....	53	Diagnosis Procedure (B00A0-00, -02 or -09) .....	96
DTC Description .....	53	Diagnosis Procedure (B00A0-04) .....	97
Diagnosis Procedure .....	54	Diagnosis Procedure (B00A0-83, -86, -87, -88 or -	98
<b>B0020 SIDE AIRBAG MODULE LH</b> .....	56	8F) .....	98
DTC Description .....	56	Diagnosis Procedure (B00A0-93) .....	99
Diagnosis Procedure .....	57	<b>B00D5 PASSENGER AIR BAG OFF INDICA-</b>	
<b>B0028 SIDE AIRBAG MODULE RH</b> .....	59	<b>TOR</b> .....	101
DTC Description .....	59	DTC Description .....	101
Diagnosis Procedure .....	60	Diagnosis Procedure .....	102
<b>B0021 SIDE CURTAIN AIR BAG MODULE LH</b>		<b>B1428 SEAT BELT BUCKLE SWITCH LH</b> ....	104
... ..	62	DTC Description .....	104
DTC Description .....	62	Diagnosis Procedure .....	105
Diagnosis Procedure .....	63	<b>B1429 SEAT BELT BUCKLE SWITCH RH</b> ....	107
<b>B0029 SIDE CURTAIN AIR BAG MODULE</b>		DTC Description .....	107
<b>RH</b> .....	65	Diagnosis Procedure .....	108
DTC Description .....	65	<b>B1430 SEAT BELT PRE-TENSIONER</b> .....	110
Diagnosis Procedure .....	66	DTC Description .....	110
<b>B0094 CRASH ZONE SENSOR</b> .....	68	Diagnosis Procedure .....	111
DTC Description .....	68	<b>B1431 SEAT BELT PRE-TENSIONER</b> .....	113
Diagnosis Procedure .....	69	DTC Description .....	113
<b>B0091 FRONT SIDE AIR BAG SATELLITE</b>		Diagnosis Procedure .....	114
<b>SENSOR LH</b> .....	71	<b>B1433 LAP PRE-TENSIONER</b> .....	116
DTC Description .....	71	DTC Description .....	116
Diagnosis Procedure .....	73	Diagnosis Procedure .....	117
<b>B0096 FRONT SIDE AIR BAG SATELLITE</b>		<b>B1434 KNEE AIR BAG MODULE LH</b> .....	119
<b>SENSOR RH</b> .....	75	DTC Description .....	119
DTC Description .....	75	Diagnosis Procedure .....	120
Diagnosis Procedure .....	77	<b>B1436 ACTIVE VENT</b> .....	122
<b>B0092 REAR SIDE AIR BAG SATELLITE</b>		DTC Description .....	122
<b>SENSOR LH</b> .....	79	Diagnosis Procedure .....	123
		<b>B142A IGNITION VOLTAGE</b> .....	125

DTC Description .....	125	Diagnosis Procedure .....	138	
Diagnosis Procedure .....	126			A
<b>B1427 CONFIG SETTING .....</b>	<b>128</b>	<b>B14XX AIR BAG DIAGNOSIS SENSOR UNIT. 139</b>		
DTC Description .....	128	DTC Description .....	139	
Diagnosis Procedure .....	128	Diagnosis Procedure .....	139	B
<b>B1400, B1401, B1402, B1403, B1404, B1405</b>		<b>SYMPTOM DIAGNOSIS .....</b>	<b>141</b>	
<b>AIR BAG DIAGNOSIS SENSOR UNIT .....</b>	<b>129</b>	<b>SRS AIR BAG WARNING LAMP DOES NOT</b>		C
DTC Description .....	129	<b>TURN ON .....</b>	<b>141</b>	
Diagnosis Procedure .....	130	Air Bag Warning Lamp Does Not Turn On .....	141	
<b>B1406, B1407, B1408, B1409, B1410 AIR</b>		<b>SRS AIR BAG WARNING LAMP DOES NOT</b>		D
<b>BAG DIAGNOSIS SENSOR UNIT .....</b>	<b>131</b>	<b>TURN OFF .....</b>	<b>142</b>	
DTC Description .....	131	Air Bag Warning Lamp Does Not Turn Off .....	142	
Diagnosis Procedure .....	132	<b>SEAT BELT WARNING SYSTEM .....</b>	<b>143</b>	E
<b>B1411, B1412, B1413, B1414, B1415 AIR</b>		Seat Belt Warning System Does Not Function .....	143	
<b>BAG DIAGNOSIS SENSOR UNIT .....</b>	<b>133</b>	<b>A/B WARNING LAMP IS OFF, PASS A/B IN-</b>		F
DTC Description .....	133	<b>DCTR LAMP TURNS ON INTERMIT .....</b>	<b>144</b>	
Diagnosis Procedure .....	133	Description .....	144	
<b>B1416, B1417, B1418, B1419, B1420 AIR</b>		Diagnosis Procedure .....	144	G
<b>BAG DIAGNOSIS SENSOR UNIT .....</b>	<b>135</b>	<b>SEAT BELT INDCTR LAMP IS ON, PASS AIR</b>		
DTC Description .....	135	<b>BAG INDCTR IS ON OR OFF .....</b>	<b>145</b>	
Diagnosis Procedure .....	136	Description .....	145	
<b>B142X COLLISION DETECTION .....</b>	<b>137</b>	Diagnosis Procedure .....	145	SRC
DTC Description .....	137			I
				J
				K
				L
				M
				N
				O
				P

## PRECAUTIONS

< PRECAUTION >

### PRECAUTION

#### PRECAUTIONS

##### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000011550460

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

##### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

##### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

##### **WARNING:**

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

##### Precaution for SRS "AIR BAG" and "SEAT BELT PRE-TENSIONER" Service

INFOID:0000000011219669

- Do not use electrical test equipment to check SRS circuits unless instructed to in this Service Manual.
- Before servicing the SRS, turn ignition switch OFF, disconnect both battery cables and wait at least 3 minutes.  
For approximately 3 minutes after the cables are removed, it is still possible for the air bag and seat belt pretensioner to deploy. Therefore, do not work on any SRS connectors or wires until at least 3 minutes have passed.
- The air bag diagnosis sensor unit must always be installed with the arrow mark "←" pointing toward the front of the vehicle for proper operation. Also check air bag diagnosis sensor unit for cracks, deformities or rust before installation and replace as required.
- The spiral cable must be aligned with the neutral position since its rotations are limited. Do not attempt to turn steering wheel or column after removal of steering gear.
- Handle air bag module carefully. Always place driver and front passenger air bag modules with the pad side facing upward and seat mounted front side air bag module standing with the stud bolt side facing down.
- Conduct self-diagnosis to check entire SRS for proper function after replacing any components.
- After air bag inflates, the front instrument panel assembly should be replaced if damaged.

# COMPONENT PARTS


< SYSTEM DESCRIPTION >

## SYSTEM DESCRIPTION

### COMPONENT PARTS


#### Component Parts Location

INFOID:0000000011219670



# COMPONENT PARTS

## < SYSTEM DESCRIPTION >



- A. Left side of roof line  
(view with headlining removed)
- B. Right of rear passenger seat  
(view with rear wheel house finisher removed)
- C. Base of passenger seat lap belt  
(view with center pillar garnish removed)
- D. Between driver and passenger seat  
(View with center console removed)
- E. Front of passenger compartment
- F. Bottom of passenger seat
- G. Front of engine compartment  
(view with engine air intake plenum removed)
- H. Driver door area  
(view with front door finisher removed)
- I. Driver seat area
- J. Left of driver seat  
(view with center pillar garnish removed)

## Component Description

INFOID:0000000011219671

No.	Component	Function
1.	LH side curtain air bag module	Refer to <a href="#">SRC-8, "Side Curtain Air Bag Module"</a> .
2.	Rear side air bag satellite sensor RH	Refer to <a href="#">SRC-9, "Rear Side Air Bag Satellite Sensor"</a> .
3.	Front RH seat belt pre-tensioner (lap belt)	Refer to <a href="#">SRC-8, "Front Seat Belt Pre-tensioner"</a> .
4.	Air bag diagnosis sensor unit	Refer to <a href="#">SRC-8, "Air Bag Diagnosis Sensor Unit"</a> .
5.	Front passenger air bag module	Refer to <a href="#">SRC-7, "Front Passenger Air Bag Module"</a> .
6.	Front passenger air bag off indicator	Refer to <a href="#">SRC-10, "Front Passenger Air Bag Off Indicator"</a> .
7.	Driver air bag module	Refer to <a href="#">SRC-7, "Driver Air Bag Module"</a> .
8.	Left knee air bag module	Refer to <a href="#">SRC-7, "Left Knee Air Bag Module"</a> .
9.	Occupant classification sensors	Refer to <a href="#">SRC-13, "OCCUPANT CLASSIFICATION SYSTEM : System Description"</a> .
10.	Occupant classification system control unit	Refer to <a href="#">SRC-13, "OCCUPANT CLASSIFICATION SYSTEM : System Description"</a> .
11.	Crash zone sensor	Refer to <a href="#">SRC-9, "Crash Zone Sensor"</a> .
12.	Front door satellite sensor LH	Refer to <a href="#">SRC-9, "Front Door Satellite Sensor"</a> .
13.	Front LH seat belt pre-tensioner	Refer to <a href="#">SRC-8, "Front Seat Belt Pre-tensioner"</a> .
14.	Front side air bag (satellite) sensor	Refer to <a href="#">SRC-9, "Front Side Air Bag Satellite Sensor"</a> .
15.	Side air bag module LH	Refer to <a href="#">SRC-8, "Side Air Bag Module"</a> .
16.	Seat belt buckle switch LH	The seat belt buckle switches (LH/RH) provide the seat belt buckle signals to the air bag diagnosis sensor unit and the combination meter.


## COMPONENT PARTS

### < SYSTEM DESCRIPTION >

#### Driver Air Bag Module

INFOID:0000000011219672


The driver air bag module is dual stage and located in the steering wheel assembly. It operates with the SRS system in a frontal collision exceeding a specified level.



#### Front Passenger Air Bag Module

INFOID:0000000011219673


The front passenger air bag module is dual stage and is located behind the instrument panel assembly. It operates with the SRS system in a frontal collision exceeding a specified level. Refer to [SRC-12, "SRS AIR BAG SYSTEM : System Description"](#) for more information.



#### Left Knee Air Bag Module

INFOID:0000000011541453

The left knee air bag module is single stage and located in the instrument panel assembly below the steering wheel. It operates with the SRS system in a frontal collision exceeding a specified level. Refer to [SRC-12, "SRS AIR BAG SYSTEM : System Description"](#) for more information.




## COMPONENT PARTS

### < SYSTEM DESCRIPTION >

#### Side Air Bag Module

INFOID:0000000011219674


Side air bag modules are built into the front seatback assemblies. Vehicles with side air bags are equipped with labels as shown.



#### Side Curtain Air Bag Module

INFOID:0000000011219675

Side curtain air bag modules are located above the vehicle headlining. Vehicles with side curtain air bags are equipped with labels on the pillar upper finishers.




#### Front Seat Belt Pre-tensioner

INFOID:0000000011219676

The seat belt pre-tensioner system with load limiter is installed for both the driver seat and the front passenger seat. It operates simultaneously with the SRS air bag system in the event of a frontal collision with an impact exceeding a specified level.

When a frontal collision with an impact exceeding a specified level occurs, seat belt slack resulting from clothing or other factors is immediately taken up by the shoulder belt pre-tensioner (1) as well as the passenger seat lap belt pre-tensioner (2). Vehicle passengers are securely restrained.


When passengers in a vehicle are thrown forward in a collision and the restraining force of the seat belt exceeds a specified level, the load limiter permits the specified extension of the seat belt by the twisting of the ELR shaft and a relaxation of the chest-area seat belt web tension while maintaining force.



#### Air Bag Diagnosis Sensor Unit

INFOID:0000000011219677

The air bag diagnosis sensor unit is located under the center console assembly. The air bag diagnosis sensor unit receives signals from multiple SRS sensors and controls the deployment of the air bags. The deployment of the air bags depends on the type and severity of the collision. The air bag diagnosis sensor unit has self-diagnosis capability through the use of the CONSULT as well as flash codes displayed by the air bag warning lamp.






## COMPONENT PARTS

### < SYSTEM DESCRIPTION >

#### Crash Zone Sensor

INFOID:0000000011219678


The crash zone sensor is located behind the radiator and underneath the front air duct. The crash zone sensor sends signals to the air bag diagnosis sensor unit during a frontal collision. This sensor may be identified by a yellow connector.



#### Front Side Air Bag Satellite Sensor

INFOID:0000000011219679


The front side air bag satellite sensors are located on the front center pillar LH and RH next to the seat belt pre-tensioners. The front side air bag satellite sensors send signals to the air bag diagnosis sensor unit during a side collision. These sensors may be identified by yellow connectors.



#### Rear Side Air Bag Satellite Sensor

INFOID:0000000011219680


The rear side air bag satellite sensors are located behind the rear wheel house finisher LH and RH. The rear side air bag satellite sensors send signals to the air bag diagnosis sensor unit during a side collision. These sensors may be identified by yellow connectors.



#### Front Door Satellite Sensor

INFOID:0000000011219681

The front door satellite sensors are located in the driver and passenger doors. The front door satellite sensors send signals to the air bag diagnosis sensor unit during a side collision. These sensors may be identified by yellow connectors.



## COMPONENT PARTS

### < SYSTEM DESCRIPTION >

#### Front Passenger Air Bag Off Indicator

INFOID:000000011541459

Front passenger air bag OFF indicator indicates whether or not passenger air bag is in the activation mode based on the judgment of occupant detection system.



JSHIA00482Z

#### SRS Component Connectors

INFOID:000000011219682


##### DIRECT CONNECT

The following SRS components use direct-connect style harness connectors"

- Driver front air bag module
- Passenger front air bag module
- LH side curtain air bag module
- RH side curtain air bag module
- Front LH seat belt pre-tensioner
- Front RH seat belt pre-tensioner

Always pull up to release locking tab prior to removing connector from SRS component.

Always push down to lock locking tab after installing connector to SRS component. When locked, the locking tab is level with the connector housing.



WHIA0103E

##### SLIDE DOUBLE LOCKING


- A new style slide double locking type connector is used on certain systems and components especially those related to air bag control systems.
- The slide double locking type connectors help prevent incomplete locking and accidental looseness or disconnection.
- The slide double locking type connectors are disconnected by pushing or pulling the slider. Refer to the figure below.

**CAUTION:**

## COMPONENT PARTS

### < SYSTEM DESCRIPTION >

- Do not pull the harness or wires when disconnecting the connector.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

SRC

# SYSTEM


< SYSTEM DESCRIPTION >

## SYSTEM

### SRS AIR BAG SYSTEM

#### SRS AIR BAG SYSTEM : System Diagram

INFOID:0000000011219683



#### SRS AIR BAG SYSTEM : System Description

INFOID:0000000011219684

- The air bag deploys if the air bag diagnosis sensor unit is activated while the ignition switch is in the ON or START position.
- The collision modes for which supplemental restraint systems are activated are different among the SRS systems. For example, the driver air bag module, front passenger air bag module, left knee air bag module and front seat belt pre-tensioner are activated in a frontal collision but not in a side collision.

#### SRS Collision Modes

SRS configuration	Frontal collision	Left side collision	Right side collision	Rollover
Driver air bag module	x	—	—	—
Front passenger air bag module	x	—	—	—
Left knee air bag module	x	—	—	—
Front LH seat belt pre-tensioner	x	—	—	x
Front RH seat belt pre-tensioner	x	—	—	x
Side air bag module LH	—	x	—	—
Side air bag module RH	—	—	x	—
LH side curtain air bag module	—	x	—	x
RH side curtain air bag module	—	—	x	x


## OCCUPANT CLASSIFICATION SYSTEM

# SYSTEM

< SYSTEM DESCRIPTION >

## OCCUPANT CLASSIFICATION SYSTEM : System Diagram

INFOID:0000000011219685



## OCCUPANT CLASSIFICATION SYSTEM : System Description

INFOID:0000000011219686

The occupant classification system (OCS) identifies different size occupants, out of position occupants, and detects if a child seat is present in the front passenger seat. The OCS control unit (2) receives inputs from the occupant classification sensors (1) (located inside the passenger seat cushion assembly). Depending on classification of the passenger, the OCS sends a signal to the air bag diagnosis sensor unit. The air bag diagnosis sensor unit uses this signal and the seat belt buckle switch RH signal to determine deployment or non-deployment of the passenger front air bag in the event of a collision. Depending on the signals received, the air bag diagnosis sensor unit can disable the passenger front air bag completely. The OCS (weight sensors) must be set to zero point using CONSULT after servicing the OCS system.

### NOTE:

- CONSULT can be used to confirm when “zero point reset” for OCS is complete.
- Always perform zero point reset after the removal and installation of the seat or when disconnecting the OCS control unit harness connector even if zero point reset has been completed in the past.
- If zero point reset is incomplete, the passenger air bag will be disabled and the passenger air bag off indicator will be ON.
- In case of customer concern, CONSULT can be used to confirm the passenger air bag status (readiness).

### Passenger Air Bag Status Conditions


Front Passenger Seat (Condition)	PASS AIR BAG OFF Indicator (Status)	Passenger Air Bag Status (Readiness)	CONSULT Display
Seat occupied	OFF	Active (enabled)	ON
Seat occupied <sup>NOTE</sup>	ON	Deactivated (disabled)	OFF
Seat empty	OFF	Deactivated (disabled)	OFF

### NOTE:

Passenger does not meet Occupant Classification System specifications for passenger air bag activation.

# SYSTEM


## < SYSTEM DESCRIPTION >



## SEAT BELT WARNING LAMP SYSTEM

### SEAT BELT WARNING LAMP SYSTEM : System Diagram

INFOID:0000000011219687




SYSTEM

< SYSTEM DESCRIPTION >

SEAT BELT WARNING LAMP SYSTEM : System Description

INFOID:0000000011219688

The seat belt warning lamp (1) will remind the driver if the driver or front passenger seat belt should be buckled. The system works in conjunction with the occupant classification system. Refer to [SRC-13. "OCCUPANT CLASSIFICATION SYSTEM : System Description"](#).



Seat Belt Warning System Operation

Driver seat status (ignition switch ON)	Passenger seat status	Seat belt buckle switch LH status	Seat belt buckle switch RH status	Seat belt warning lamp
Seat occupied	Seat occupied	Buckled	Buckled	Off
			Unbuckled	On
	Seat unoccupied	Unbuckled	—	Off
	—			On

SRC

I

J

K

L

M

N

O

P

# DIAGNOSIS SYSTEM (AIR BAG)

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (AIR BAG)

### Diagnosis Description

INFOID:0000000011219689

#### CAUTION:

- Do not use electrical test equipment on any circuit related to the SRS unless instructed to do so in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harness connectors.
- Do not attempt to repair, splice or modify SRS wiring harnesses. If a harness is damaged, replace it with a new one.
- Keep ground connections clean.

### HOW TO PERFORM TROUBLE DIAGNOSES FOR QUICK AND ACCURATE REPAIR

1. Obtain information about the symptom.
  - WHAT - vehicle model
  - WHEN - date, frequencies
  - WHERE - road conditions
  - HOW - operating conditions, symptoms, passengers
2. Perform Preliminary Check.
  - Battery
  - Fuses
  - Harness connections

### DIAGNOSIS METHODS

SRS "Self Diagnostic Result" can be read by using the AIR BAG warning lamp or CONSULT.

The User Mode is for the customer (driver). This mode warns the driver of a system malfunction through the AIR BAG warning lamp.

The Diagnosis Mode is for the technician. This mode helps the technician locate the malfunctioning circuit or part.

	User Mode	Diagnosis Mode	Display type
AIR BAG warning lamp	X	X	ON/OFF
CONSULT	—	X	Monitoring

### SRS Operation Check

INFOID:0000000011219690

#### USER MODE

1. Turn the ignition switch from OFF to ON and check that the air bag warning lamp blinks.
2. Compare the blinking pattern with the examples in the table.









# DIAGNOSIS SYSTEM (AIR BAG)

## < SYSTEM DESCRIPTION >

### Air bag warning lamp flashing pattern (User Mode)

Warning lamp	SRS condition	Reference item
 <p>SHIA0011E</p>	<ul style="list-style-type: none"> <li>No malfunction is detected.</li> <li>No further action is necessary.</li> </ul>	—
 <p>SHIA0013E</p>	<ul style="list-style-type: none"> <li>Air bag is deployed.</li> <li>Seat belt pre-tensioner is deployed.</li> </ul>	Refer to <a href="#">SR-5, "For Frontal Collision"</a> or <a href="#">SR-7, "For Side and Rollover Collision"</a> .
 <p>SHIA0014E</p>	<ul style="list-style-type: none"> <li>Air bag diagnosis sensor unit is malfunctioning.</li> <li>Air bag power supply circuit is malfunctioning.</li> <li>SRS air bag warning lamp circuit is malfunctioning.</li> </ul>	Refer to <a href="#">SRC-142, "Air Bag Warning Lamp Does Not Turn Off"</a> .
 <p>SHIA0014E</p>	<ul style="list-style-type: none"> <li>Air bag diagnosis sensor unit is malfunctioning.</li> <li>Air bag warning lamp circuit is malfunctioning.</li> </ul>	Refer to <a href="#">SRC-141, "Air Bag Warning Lamp Does Not Turn On"</a> .

A

B

C

D

E

F

G

SRC

I

J

K

## Trouble Diagnosis with CONSULT

INFOID:0000000011219691

1. Connect CONSULT.
2. DTC is displayed on SELF DIAGNOSTIC RESULT.

### NOTE:

If a malfunction is not detected on "Self Diagnostic Result [CURRENT]", but a malfunction is detected during SRS Operation Check, the following cases may exist:

- "Self Diagnostic Result [PAST]" memory might not be erased. Refer to [SRC-17, "SRS Final Check"](#).
- SRS system malfunctions intermittently. Refer to [SRC-46, "Inspection Procedure"](#).

## SRS History Check

INFOID:0000000011219693

### SRS HISTORY CHECK

1. Check repair history of the SRS. If no repairs have been made, perform [SRC-16, "SRS Operation Check"](#). If repairs have been made, GO TO step 2.
2. Erase "Self Diagnostic Result [PAST]" after repair. Refer to [SRC-17, "SRS Final Check"](#).

## SRS Final Check

INFOID:0000000011219694

### DIAGNOSIS MODE

1. Connect CONSULT.

## DIAGNOSIS SYSTEM (AIR BAG)

### < SYSTEM DESCRIPTION >

2. Confirm that zero point reset of OCS is complete.
3. If no DTCs are detected on "Self Diagnostic Result [CURRENT]", repair of SRS is completed. Go to step 4.  
If any DTCs are detected on "Self Diagnostic Result [CURRENT]", the malfunction has not been repaired completely or another malfunction is being detected. Perform SRS Operation Check again. Refer to [SRC-16, "SRS Operation Check"](#).
4. Touch "ERASE".  
**NOTE:**  
Touching "ERASE" will clear the SRS memory of the malfunction ("Self Diagnostic Result [PAST]"). If "Self Diagnostic Result [PAST]" is not erased, User Mode may show the previous system malfunction even if the malfunction has been repaired completely.
5. Check that no malfunction is detected in "Self Diagnostic Result [PAST]".
6. Exit Diagnosis Mode and disconnect the CONSULT.
7. Perform SRS Operation Check. Refer to [SRC-16, "SRS Operation Check"](#).

### CONSULT Function (AIR BAG)

INFOID:0000000011219695

#### CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and no-start condition.

#### APPLICATION ITEMS

CONSULT can display each diagnostic item using the diagnostic test modes shown following:

Diagnostic Test Mode	Diagnostic Item	Description
"Self Diagnostic Result"	SELF DIAGNOSTIC RESULT [CURRENT]	A current "Self Diagnostic Result" (also indicated by the number of warning lamp flashes in the Diagnosis mode) is displayed on the CONSULT screen in real time. This refers to a malfunctioning part requiring repairs.
"Data Monitor"	DATA MONITOR	Displays air bag diagnosis sensor unit input/output data in real time.
"ECU Identification"	ECU DISCRIMINATED NO.	Air bag diagnosis sensor unit ECU discriminated number (identification number) or part number is displayed. Air bag diagnosis sensor unit has individual ECU discriminated number (identification number) or part number based on model and equipment.
"TROUBLE DIAG RECORD"	TROUBLE DIAG RECORD [PAST]	With "TROUBLE DIAG RECORD", diagnosis results previously erased by a reset operation can be displayed on the CONSULT screen.

### CONSULT Function (OCCUPANT DETECTION)

INFOID:0000000011219696

CONSULT can display each diagnostic item using the diagnostic test modes shown following:

Diagnostic Test Mode	Diagnostic Item	Description
"Work support"	ZERO POINT RESET FUNCTION	Perform zero point reset. Refer to <a href="#">SRC-44, "ZERO POINT RESET : Special Repair Requirement"</a> .

# DIAGNOSIS SENSOR UNIT

< ECU DIAGNOSIS INFORMATION >

## ECU DIAGNOSIS INFORMATION

### DIAGNOSIS SENSOR UNIT

#### DTC Index

INFOID:0000000011541473

DTC	Diagnostic item	Reference page
U1000-01	CAN COMM CIRCUIT	<a href="#">SRC-47, "Diagnosis Procedure"</a>
U1010-49	CONTROL UNIT (CAN)	<a href="#">SRC-48, "Diagnosis Procedure"</a>
B0001-00	DRIVER AIRBAG MODULE [SHORT]	<a href="#">SRC-50, "Diagnosis Procedure"</a>
B0001-09	DRIVER AIRBAG MODULE [SHORT]	
B0001-11	DRIVER AIRBAG MODULE [GND-SHORT]	
B0001-12	DRIVER AIRBAG MODULE [VB-SHORT]	
B0001-13	DRIVER AIRBAG MODULE [OPEN]	
B0001-1A	DRIVER AIRBAG MODULE [SHORT]	
B0002-00	DRIVER AIRBAG MODULE 2 [SHORT]	<a href="#">SRC-50, "Diagnosis Procedure"</a>
B0002-09	DRIVER AIRBAG MODULE 2 [SHORT]	
B0002-11	DRIVER AIRBAG MODULE 2 [GND-SHORT]	
B0002-12	DRIVER AIRBAG MODULE 2 [VB-SHORT]	
B0002-13	DRIVER AIRBAG MODULE 2 [OPEN]	
B0002-1A	DRIVER AIRBAG MODULE 2 [SHORT]	
B0010-09	ASSIST A/B MODULE [SHORT]	<a href="#">SRC-54, "Diagnosis Procedure"</a>
B0010-11	ASSIST A/B MODULE [GND-SHORT]	
B0010-12	ASSIST A/B MODULE [VB-SHORT]	
B0010-13	ASSIST A/B MODULE [OPEN]	
B0010-1A	ASSIST A/B MODULE [SHORT]	
B0011-09	ASSIST A/B MODULE 2 [SHORT]	<a href="#">SRC-54, "Diagnosis Procedure"</a>
B0011-11	ASSIST A/B MODULE 2 [GND-SHORT]	
B0011-12	ASSIST A/B MODULE 2 [VB-SHORT]	
B0011-13	ASSIST A/B MODULE 2 [OPEN]	
B0011-1A	ASSIST A/B MODULE 2 [SHORT]	
B0020-09	SIDE A/B MODULE LH [SHORT]	<a href="#">SRC-57, "Diagnosis Procedure"</a>
B0020-11	SIDE A/B MODULE LH [GND-SHORT]	
B0020-12	SIDE A/B MODULE LH [VB-SHORT]	
B0020-13	SIDE A/B MODULE LH [OPEN]	
B0020-1A	SIDE A/B MODULE LH [SHORT]	
B0021-09	CURTAIN A/B MODULE LH [SHORT]	<a href="#">SRC-63, "Diagnosis Procedure"</a>
B0021-11	CURTAIN A/B MODULE LH [GND-SHORT]	
B0021-12	CURTAIN A/B MODULE LH [VB-SHORT]	
B0021-13	CURTAIN A/B MODULE LH [OPEN]	
B0021-1A	CURTAIN A/B MODULE LH [SHORT]	

# DIAGNOSIS SENSOR UNIT

## < ECU DIAGNOSIS INFORMATION >

DTC	Diagnostic item	Reference page
B0028-09	SIDE A/B MODULE RH [SHORT]	<a href="#">SRC-60. "Diagnosis Procedure"</a>
B0028-11	SIDE A/B MODULE RH [GND-SHORT]	
B0028-12	SIDE A/B MODULE RH [VB-SHORT]	
B0028-13	SIDE A/B MODULE RH [OPEN]	
B0028-1A	SIDE A/B MODULE RH [SHORT]	
B0029-09	CURTAIN A/B MODULE RH [SHORT]	<a href="#">SRC-66. "Diagnosis Procedure"</a>
B0029-11	CURTAIN A/B MODULE RH [GND-SHORT]	
B0029-12	CURTAIN A/B MODULE RH [VB-SHORT]	
B0029-13	CURTAIN A/B MODULE RH [OPEN]	
B0029-1A	CURTAIN A/B MODULE RH [SHORT]	
B1434-09	KNEE AIRBAG MODULE LH [SHORT]	<a href="#">SRC-120. "Diagnosis Procedure"</a>
B1434-11	KNEE AIRBAG MODULE LH [GND-SHORT]	
B1434-12	KNEE AIRBAG MODULE LH [VB-SHORT]	
B1434-13	KNEE AIRBAG MODULE LH [OPEN]	
B1434-1A	KNEE AIRBAG MODULE LH [SHORT]	
B0091-11	B-PILLAR SAT SEN LH [GND-SHORT]	<a href="#">SRC-73. "Diagnosis Procedure"</a>
B0091-23	B-PILLAR SAT SEN LH [LOWER LIMIT ERR]	
B0091-24	B-PILLAR SAT SEN LH [UPPER LIMIT ERR]	
B0091-25	B-PILLAR SAT SEN LH [SELF-DIAG ERR]	
B0091-28	B-PILLAR SAT SEN LH [OFFSET ERR]	
B0091-81	B-PILLAR SAT SEN LH [COMM ERR]	
B0091-86	B-PILLAR SAT SEN LH [UNMATCH]	
B0091-88	B-PILLAR SAT SEN LH [OPEN]	
B0091-93	B-PILLAR SAT SEN LH [RESET]	
B0092-11	C-PILLAR SAT SEN LH [GND-SHORT]	<a href="#">SRC-81. "Diagnosis Procedure"</a>
B0092-23	C-PILLAR SAT SEN LH [LOWER LIMIT ERR]	
B0092-24	C-PILLAR SAT SEN LH [UPPER LIMIT ERR]	
B0092-25	C-PILLAR SAT SEN LH [SELF-DIAG ERR]	
B0092-28	C-PILLAR SAT SEN LH [OFFSET ERR]	
B0092-81	C-PILLAR SAT SEN LH [COMM ERR]	
B0092-86	C-PILLAR SAT SEN LH [UNMATCH]	
B0092-88	C-PILLAR SAT SEN LH [DISCONNECT]	
B0092-93	C-PILLAR SAT SEN LH [RESET]	
B0093-11	DOOR SATEL SENS LH [GND-SHORT]	<a href="#">SRC-89. "Diagnosis Procedure"</a>
B0093-23	DOOR SATEL SENS LH [LOWER LIMIT ERR]	
B0093-24	DOOR SATEL SENS LH [UPPER LIMIT ERR]	
B0093-25	DOOR SATEL SENS LH [SELF-DIAG ERR]	
B0093-28	DOOR SATEL SENS LH [OFFSET ERR]	
B0093-81	DOOR SATEL SENS LH [COMM ERR]	
B0093-86	DOOR SATEL SENS LH [UNMATCH]	
B0093-88	DOOR SATEL SENS LH [OPEN]	
B0093-93	DOOR SATEL SENS LH [RESET]	

# DIAGNOSIS SENSOR UNIT

## < ECU DIAGNOSIS INFORMATION >

DTC	Diagnostic item	Reference page
B0094-11	CRASH ZONE SENS [GND-SHORT]	SRC-69. "Diagnosis Procedure"
B0094-23	CRASH ZONE SENS [LOWER LIMIT ERR]	
B0094-24	CRASH ZONE SENS [UPPER LIMIT ERR]	
B0094-25	CRASH ZONE SENS [SELF-DIAG ERR]	
B0094-28	CRASH ZONE SENS [OFFSET ERR]	
B0094-81	CRASH ZONE SENS [COMM ERR]	
B0094-86	CRASH ZONE SENS [UNMATCH]	
B0094-88	CRASH ZONE SENS [OPEN]	
B0094-93	CRASH ZONE SENS [RESET]	
B0096-11	B-PILLAR SAT SEN RH [GND-SHORT]	SRC-77. "Diagnosis Procedure"
B0096-23	B-PILLAR SAT SEN RH [LOWER LIMIT ERR]	
B0096-24	B-PILLAR SAT SEN RH [UPPER LIMIT ERR]	
B0096-25	B-PILLAR SAT SEN RH [SELF-DIAG ERR]	
B0096-28	B-PILLAR SAT SEN RH [OFFSET ERR]	
B0096-81	B-PILLAR SAT SEN RH [COMM ERR]	
B0096-86	B-PILLAR SAT SEN RH [UNMATCH]	
B0096-88	B-PILLAR SAT SEN RH [OPEN]	
B0096-93	B-PILLAR SAT SEN RH [RESET]	
B0097-11	C-PILLAR SAT SEN RH [GND-SHORT]	SRC-85. "Diagnosis Procedure"
B0097-23	C-PILLAR SAT SEN RH [LOWER LIMIT ERR]	
B0097-24	C-PILLAR SAT SEN RH [UPPER LIMIT ERR]	
B0097-25	C-PILLAR SAT SEN RH [SELF-DIAG ERR]	
B0097-28	C-PILLAR SAT SEN RH [OFFSET ERR]	
B0097-81	C-PILLAR SAT SEN RH [COMM ERR]	
B0097-86	C-PILLAR SAT SEN RH [UNMATCH]	
B0097-88	C-PILLAR SAT SEN RH [OPEN]	
B0097-93	C-PILLAR SAT SEN RH [RESET]	
B0098-11	DOOR SATEL SENS RH [GND-SHORT]	SRC-93. "Diagnosis Procedure"
B0098-23	DOOR SATEL SENS RH [LOWER LIMIT ERR]	
B0098-24	DOOR SATEL SENS RH [UPPER LIMIT ERR]	
B0098-25	DOOR SATEL SENS RH [SELF-DIAG ERR]	
B0098-28	DOOR SATEL SENS RH [OFFSET ERR]	
B0098-81	DOOR SATEL SENS RH [COMM ERR]	
B0098-86	DOOR SATEL SENS RH [UNMATCH]	
B0098-88	DOOR SATEL SENS RH [OPEN]	
B0098-93	DOOR SATEL SENS RH [RESET]	

A

B

C

D

E

F

G

SRC

I

J

K

L

M

N

O

P

# DIAGNOSIS SENSOR UNIT

## < ECU DIAGNOSIS INFORMATION >

DTC	Diagnostic item	Reference page
B00A0-00	OCCUPANT SENS [ABNORMAL VOLTAGE]	<a href="#">SRC-95, "Description"</a>
B00A0-02	OCCUPANT SENS [UNIT MALFUNC]	
B00A0-09	OCCUPANT SENS [UNIT MALFUNC]	
B00A0-04	OCCUPANT SENS C/U [UNIT MALFUNC]	
B00A0-83	OCCUPANT SENS C/U [COMM ERR]	
B00A0-86	OCCUPANT SENS C/U [COMM ERR]	
B00A0-87	OCCUPANT SENS C/U [COMM ERR]	
B00A0-88	OCCUPANT SENS C/U [COMM ERR]	
B00A0-8F	OCCUPANT SENS C/U [UNDEFINED]	
B00A0-93	OCCUPANT SENS C/U [RESET]	
B00D5-04	PASS A/B INDCTR CKT [UNIT MALFUNC]	<a href="#">SRC-102, "Diagnosis Procedure"</a>
B00D5-11	PASS A/B INDCTR CKT [GND-SHORT]	
B00D5-12	PASS A/B INDCTR CKT [VB-SHORT]	
B00D5-13	PASS A/B INDCTR CKT [OPEN]	
B00D5-15	PASS A/B INDCTR CKT [PWR-SHORT/OPEN]	
B1428-13	BUCKLE SW LH CIRCUIT [OPEN]	<a href="#">SRC-105, "Diagnosis Procedure"</a>
B1428-12	BUCKLE SW LH CIRCUIT [VB-SHORT]	
B1428-11	BUCKLE SW LH CIRCUIT [GND-SHORT]	
B1428-00	BUCKLE SW LH CIRCUIT [UNDEFINED]	
B1429-13	BUCKLE SW RH CIRCUIT [OPEN]	<a href="#">SRC-108, "Diagnosis Procedure"</a>
B1429-12	BUCKLE SW RH CIRCUIT [VB-SHORT]	
B1429-11	BUCKLE SW RH CIRCUIT [GND-SHORT]	
B1429-00	BUCKLE SW RH CIRCUIT [UNDEFINED]	
B1430-09	PRE-TEN FRONT LH [SHORT]	<a href="#">SRC-111, "Diagnosis Procedure"</a>
B1430-11	PRE-TEN FRONT LH [GND-SHORT]	
B1430-12	PRE-TEN FRONT LH [VB-SHORT]	
B1430-13	PRE-TEN FRONT LH [OPEN]	
B1430-1A	PRE-TEN FRONT LH [SHORT]	
B1431-09	PRE-TEN FRONT RH [SHORT]	<a href="#">SRC-114, "Diagnosis Procedure"</a>
B1431-11	PRE-TEN FRONT RH [GND-SHORT]	
B1431-12	PRE-TEN FRONT RH [VB-SHORT]	
B1431-13	PRE-TEN FRONT RH [OPEN]	
B1431-1A	PRE-TEN FRONT RH [SHORT]	
B1436-09	ACTIVE VENT [SHORT]	<a href="#">SRC-123, "Diagnosis Procedure"</a>
B1436-11	ACTIVE VENT [GND-SHORT]	
B1436-12	ACTIVE VENT [VB-SHORT]	
B1436-13	ACTIVE VENT [OPEN]	
B1436-1A	ACTIVE VENT [SHORT]	
B1433-09	PRE-TEN FRONT RH 2 [SHORT]	<a href="#">SRC-117, "Diagnosis Procedure"</a>
B1433-11	PRE-TEN FRONT RH 2 [GND-SHORT]	
B1433-12	PRE-TEN FRONT RH 2 [VB-SHORT]	
B1433-13	PRE-TEN FRONT RH 2 [OPEN]	
B1433-1A	PRE-TEN FRONT RH 2 [SHORT]	

# DIAGNOSIS SENSOR UNIT

## < ECU DIAGNOSIS INFORMATION >

DTC	Diagnostic item	Reference page
B142A-16	IGNITION VOLTAGE [VB-LOW]	<a href="#">SRC-126, "Diagnosis Procedure"</a>
B142A-17	IGNITION VOLTAGE [VB-HIGH]	
B1400-00	CONTROL UNIT [UNIT MALFUNC]	<a href="#">SRC-130, "Diagnosis Procedure"</a>
B1401-00		
B1402-00		
B1403-00		
B1404-00		
B1405-00		<a href="#">SRC-132, "Diagnosis Procedure"</a>
B1406-00		
B1407-00		
B1408-00		
B1409-00		
B1410-00		<a href="#">SRC-133, "Diagnosis Procedure"</a>
B1411-00		
B1412-00		
B1413-00		
B1414-00		
B1415-00		<a href="#">SRC-136, "Diagnosis Procedure"</a>
B1416-00		
B1417-00		
B1418-00		
B1419-00		
B1420-00		
B1421-00	FRONTAL COLLISION	<a href="#">SRC-130, "Diagnosis Procedure"</a>
B1422-00	SIDE COLLISION	
B1423-00	ROLLOVER DETECTION	
B1425-00	REAR COLLISION	
B14XX-00	AIRBAG DISPOSAL COMPLETION	<a href="#">SRC-139, "Diagnosis Procedure"</a>
B1426-00	AIRBAG DISPOSAL DETECT	
B1427-55	ECU SETTING	<a href="#">SRC-128, "Diagnosis Procedure"</a>

A

B

C

D

E

F

G

SRC

I

J

K

L

M

N

O

P

# SRS AIR BAG SYSTEM


< WIRING DIAGRAM >

## WIRING DIAGRAM

### SRS AIR BAG SYSTEM

#### Wiring Diagram

INFOID:0000000011219699




AAHWA0134GB



# SRS AIR BAG SYSTEM

< WIRING DIAGRAM >



\* : THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PG SECTION.

AAHWA0135GB

# SRS AIR BAG SYSTEM

< WIRING DIAGRAM >

## SRS AIR BAG CONTROL SYSTEM CONNECTORS

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE

7P	8P	5P	4P	3P	2P	1P
16P	15P	14P	13P	12P	11P	10P
9P	8P					



Terminal No.	Color of Wire	Signal Name
1P	R	—
8P	BG	—
13P	W	—

Connector No.	M22
Connector Name	DATA LINK CONNECTOR
Connector Color	WHITE

9	10	11	12	13	14	15	16
1	2	3	4	5	6	7	8



Terminal No.	Color of Wire	Signal Name
7	W	—

Connector No.	M23
Connector Name	COMBINATION METER
Connector Color	WHITE

41	42	43	44	45	46	47	48
49	50	51	52	53	54	55	56



Terminal No.	Color of Wire	Signal Name
43	B	GND1
44	BG	POWER (IGN)
45	B	GND2
46	W	POWER (BAT)

Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40



Terminal No.	Color of Wire	Signal Name
27	BR	SEAT BELT SW (AS)
28	Y	SEAT BELT SW (DR)

Connector No.	M26
Connector Name	WIRE TO WIRE
Connector Color	YELLOW





1	2
---	---



Terminal No.	Color of Wire	Signal Name
1	BG	—
2	W	—

# SRS AIR BAG SYSTEM

< WIRING DIAGRAM >



AAHIA0443GB

# SRS AIR BAG SYSTEM

## < WIRING DIAGRAM >


Connector No.	M39
Connector Name	JOINT CONNECTOR-M06
Connector Color	WHITE

4	3	2	1
---	---	---	---



Terminal No.	Color of Wire	Signal Name
1	V	-
2	SHIELD	-
3	SHIELD	-
4	SHIELD	-

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
51A	Y	-
52A	BR	-
84A	Y	-

Connector No.	M53
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Color	YELLOW

3	2	1
6	5	4



Terminal No.	Color of Wire	Signal Name
4	Y	-
5	BR	-
6	LG	-

Connector No.	M84
Connector Name	WIRE TO WIRE
Connector Color	WHITE

16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
32	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17



Terminal No.	Color of Wire	Signal Name
14	BR	-
15	R	-
16	W	-

Connector No.	M87
Connector Name	DRIVER AIR BAG MODULE
Connector Color	YELLOW

24	23
----	----




Terminal No.	Color of Wire	Signal Name
23	R	-
24	Y	-

# SRS AIR BAG SYSTEM

## < WIRING DIAGRAM >

Connector No.	M105
Connector Name	WIRE TO WIRE
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
1	W	-
2	G	-
3	W	-
4	G	-

Connector No.	M91
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1B	2B	3B	4B	5B	6B	7B	8B	9B	10B	11B	12B	13B	14B	15B
16B	17B	18B	19B	20B	21B	22B	23B	24B	25B	26B	27B	28B	29B	30B
31B	32B	33B	34B	35B	36B	37B	38B	39B	40B	41B	42B	43B	44B	45B
46B	47B	48B	49B	50B	51B	52B	53B	54B	55B	56B	57B	58B	59B	60B

Terminal No.	Color of Wire	Signal Name
16B	B	-
17B	W	-
27B	SHIELD	-

Connector No.	M89
Connector Name	DRIVER AIR BAG MODULE
Connector Color	ORANGE



Terminal No.	Color of Wire	Signal Name
25	L	-
26	G	-

Connector No.	M168
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1C	2C	3C	4C	5C	6C	7C	8C	9C	10C	11C	12C	13C	14C	15C
16C	17C	18C	19C	20C	21C	22C	23C	24C	25C	26C	27C	28C	29C	30C
31C	32C	33C	34C	35C	36C	37C	38C	39C	40C	41C	42C	43C	44C	45C
46C	47C	48C	49C	50C	51C	52C	53C	54C	55C	56C	57C	58C	59C	60C


Terminal No.	Color of Wire	Signal Name
16C	B	-
17C	W	-
27C	SHIELD	-

Connector No.	M116
Connector Name	LEFT KNEE AIR BAG MODULE
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
1	Y	-
2	BR	-

Connector No.	M113
Connector Name	FRONT PASSENGER AIR BAG OFF INDICATOR
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
2	B	-
4	R	-

AAHIA0397GB

# SRS AIR BAG SYSTEM


## < WIRING DIAGRAM >

Connector No.	M251
Connector Name	FRONT PASSENGER AIR BAG MODULE
Connector Color	YELLOW




Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

Connector No.	M250
Connector Name	WIRE TO WIRE
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-
3	R	-
4	R	-

Connector No.	M175
Connector Name	JOINT CONNECTOR-M22
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
20	W	-
21	W	-

Connector No.	M254
Connector Name	FRONT PASSENGER AIR BAG MODULE
Connector Color	ORANGE



Terminal No.	Color of Wire	Signal Name
5	Y	-
6	Y	-

Connector No.	M253
Connector Name	WIRE TO WIRE
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
1	Y	-
2	Y	-

Connector No.	M252
Connector Name	FRONT PASSENGER AIR BAG MODULE
Connector Color	GREEN



Terminal No.	Color of Wire	Signal Name
3	R	-
4	R	-


AAHIA0444GB

# SRS AIR BAG SYSTEM


## < WIRING DIAGRAM >

Terminal No.	Color of Wire	Signal Name
20G	SHIELD	-
21G	B	-
30G	W	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	B	-
3	SHIELD	-
4	W	-




Connector No.	E228
Connector Name	CRASH ZONE SENSOR
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
1	R	-
2	W	-

Connector No.	E210
Connector Name	WIRE TO WIRE
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
2	W	-
3	SHIELD	-
4	R	-

AAHIA0399GB

# SRS AIR BAG SYSTEM

< WIRING DIAGRAM >

Connector No.	B14
Connector Name	FRONT LH SEAT BELT PRE-TENSIONER (SHOULDER BELT)
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
1	G	—
2	O	—

Terminal No.	Color of Wire	Signal Name
59	—	—
60	—	—
61	W	RR SATELLITE SENS LH+
62	B	RR SATELLITE SENS LH-
63	—	—
64	—	—
65	G	ELR LH+
66	O	ELR LH-
67	G/W	BUCKLE SW FR LH
68	B	SIDE SENS LH-
69	W	SIDE SENS LH+
70	SHIELD	GND
71	—	—
72	—	—

Connector No.	B9
Connector Name	AIR BAG DIAGNOSIS SENSOR UNIT
Connector Color	YELLOW

51	52	53	54	55	56
57	58	59	60	61	62
63	64	65	66	67	68
69	70	71	72		



Terminal No.	Color of Wire	Signal Name
51	BR/Y	KN LH+
52	L/O	KN LH-
53	Y	SIDE INF LH+
54	BR	SIDE INF LH-
57	—	—
58	—	—

Connector No.	B38
Connector Name	LH SIDE CURTAIN AIR BAG MODULE
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
1	B	—
2	W	—

Connector No.	B15
Connector Name	FRONT SIDE AIR BAG SATELLITE SENSOR LH
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
1	W	—
2	B	—

AAHIA0445GB



# SRS AIR BAG SYSTEM

## < WIRING DIAGRAM >


Connector No.	B71
Connector Name	REAR SIDE AIR BAG SATELLITE SENSOR LH
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
1	W	—
2	B	—

Terminal No.	Color of Wire	Signal Name
51A	BR/Y	—
52A	L/O	—
84A	G/W	—

Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Connector No.	B99
Connector Name	WIRE TO WIRE (WITHOUT POWER SEATS)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	G/W	—
6	B/V	—

Connector No.	B80
Connector Name	WIRE TO WIRE
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
1	Y	—
2	BR	—

Connector No.	B74
Connector Name	WIRE TO WIRE (WITH POWER SEATS)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	B/V	—
3	G/W	—

AAHIA0446GB

# SRS AIR BAG SYSTEM

< WIRING DIAGRAM >

Connector No.	B101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

Connector No.	B112
Connector Name	FRONT RH SEAT BELT PRE-TENSIONER (LAP BELT)
Connector Color	ORANGE



4	3
---	---

Terminal No.	Color of Wire	Signal Name
14	BR	-
15	L/R	-
16	BR	-

Terminal No.	Color of Wire	Signal Name
3	P	-
4	G	-

Connector No.	B113
Connector Name	AIR BAG DIAGNOSIS SENSOR UNIT
Connector Color	YELLOW



1	2	3	4	5	6
7	8	9	10	11	12
13	14	15	16	17	18
19	20	21	22		

Terminal No.	Color of Wire	Signal Name
8	-	-
9	L	ODS INPUT
10	B	BUCKLE SW FR RH-
11	B	RR SATELLITE SENS RH+
12	W	RR SATELLITE SENS RH-
13	-	-
14	-	-
15	-	-
16	-	-
17	SHIELD	GND
18	B	SIDE SENS RH+
19	W	SIDE SENS RH-
20	BR	BUCKLE SW FR RH+
21	O	ELR RH-
22	W	ELR RH+

Terminal No.	Color of Wire	Signal Name
1	P	ELR RH2+
2	G	ELR RH2-
3	L/W	SIDE INF RH+
4	Y	SIDE INF RH-
5	W	INF CURTAIN RR RH-
6	B	INF CURTAIN RR RH+
7	-	-

Connector No.	B114
Connector Name	FRONT SIDE AIR BAG SATELLITE SENSOR RH
Connector Color	YELLOW



1	2
---	---

Terminal No.	Color of Wire	Signal Name
1	B	-
2	W	-

AAHIA0447GB

# SRS AIR BAG SYSTEM

## < WIRING DIAGRAM >

Connector No.	B128
Connector Name	RH SIDE CURTAIN AIR BAG MODULE
Connector Color	YELLOW




Terminal No.	Color of Wire	Signal Name
1	B	-
2	W	-

Connector No.	B127
Connector Name	FRONT RH SEAT BELT PRE-TENSIONER (SHOULDER BELT)
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
1	W	-
2	O	-

Connector No.	B123
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	BR	-
2	B	-
3	L	-
4	L/R	-

Connector No.	B157
Connector Name	WIRE TO WIRE (WITH POWER SEATS)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	B	-
3	BR	-

Connector No.	B156
Connector Name	WIRE TO WIRE (WITHOUT POWER SEATS)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	BR	-
6	B	-

Connector No.	B155
Connector Name	WIRE TO WIRE
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
1	L/W	-
2	Y	-

AAHIA0448GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

SRC

# SRS AIR BAG SYSTEM

< WIRING DIAGRAM >

Connector No.	B170
Connector Name	SIDE AIR BAG SATELLITE SENSOR RH
Connector Color	YELLOW




Terminal No.	Color of Wire	Signal Name
1	B	-
2	W	-

Connector No.	B219
Connector Name	WIRE TO WIRE
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
1	Y	-
2	Y	-

Connector No.	B220
Connector Name	WIRE TO WIRE (WITH POWER SEATS)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	P	-
3	BR	-

Connector No.	B221
Connector Name	SIDE AIR BAG MODULE LH
Connector Color	YELLOW




Terminal No.	Color of Wire	Signal Name
1	Y	-
2	Y	-

Connector No.	B223
Connector Name	WIRE TO WIRE (WITHOUT POWER SEATS)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	BR	-
6	P	-

Connector No.	B231
Connector Name	SEAT BELT BUCKLE SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	P	-
4	BR	-

AAHIA0449GB

# SRS AIR BAG SYSTEM

< WIRING DIAGRAM >

Connector No.	B307
Connector Name	WIRE TO WIRE
Connector Color	YELLOW




Terminal No.	Color of Wire	Signal Name
1	Y	-
2	Y	-

Connector No.	B303
Connector Name	SIDE AIR BAG MODULE RH
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
1	Y	-
2	Y	-

Connector No.	B300
Connector Name	WIRE TO WIRE (WITH POWER SEATS)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	P	-
3	BR	-

Connector No.	B350
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	GR	-
2	B	-
3	BR/W	-
4	W	-

Connector No.	B331
Connector Name	SEAT BELT BUCKLE SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	P	-
4	BR	-

Connector No.	B318
Connector Name	WIRE TO WIRE (WITHOUT POWER SEATS)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	BR	-
6	P	-

AAHIA0450GB


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

SRC

# SRS AIR BAG SYSTEM


< WIRING DIAGRAM >

Connector No.	B352
Connector Name	OCCUPANT CLASSIFICATION SYSTEM SENSOR FI
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W/L	—
2	SB	—
3	Y	—

Connector No.	B351
Connector Name	OCCUPANT CLASSIFICATION SYSTEM SENSOR FI
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	R/B	—
2	LG	—
3	R	—

Terminal No.	Color of Wire	Signal Name
13	—	—
14	—	—
15	W/L	LOAD SENSOR REAR INNER GND
16	SB	LOAD SENSOR REAR INNER SIGNAL
17	R	LOAD SENSOR FRONT INNER VCC
18	—	—
19	Y	LOAD SENSOR REAR INNER VCC
20	—	—

Terminal No.	Color of Wire	Signal Name
3	LG	LOAD SENSOR FRONT INNER SIGNAL
4	R/B	LOAD SENSOR FRONT INNER GND
5	—	—
6	—	—
7	GR	K-LINE
8	—	—
9	W	IGN
10	—	—
11	—	—
12	BR/W	ACU COMM

Connector No.	B356
Connector Name	OCCUPANT CLASSIFICATION SYSTEM CONTROL UNIT
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	—	—
2	B	GND

AAHIA0451GB

# SRS AIR BAG SYSTEM

< WIRING DIAGRAM >

Connector No.	D3
Connector Name	WIRE TO WIRE
Connector Color	WHITE



15C	14C	13C	12C	11C	10C	9C	8C	7C	6C	5C	4C	3C	2C	1C
46C	45C	44C	43C	42C	41C	40C	39C	38C	37C	36C	35C	34C	33C	32C
31C	30C	29C	28C	27C	26C	25C	24C	23C	22C	21C	20C	19C	18C	17C
16C	15C	14C	13C	12C	11C	10C	9C	8C	7C	6C	5C	4C	3C	2C

Connector No.	D26
Connector Name	FRONT DOOR SATELLITE SENSOR LH
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
1	Y	-
2	L	-

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



15B	14B	13B	12B	11B	10B	9B	8B	7B	6B	5B	4B	3B	2B	1B
46B	45B	44B	43B	42B	41B	40B	39B	38B	37B	36B	35B	34B	33B	32B
31B	30B	29B	28B	27B	26B	25B	24B	23B	22B	21B	20B	19B	18B	17B
16B	15B	14B	13B	12B	11B	10B	9B	8B	7B	6B	5B	4B	3B	2B

Terminal No.	Color of Wire	Signal Name
16C	Y	-
17C	L	-
27C	SHIELD	-

Terminal No.	Color of Wire	Signal Name
16B	Y	-
17B	L	-
27B	SHIELD	-

Connector No.	D126
Connector Name	FRONT DOOR SATELLITE SENSOR RH
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
1	Y	-
2	L	-

AAHIA0452GB

# DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000011545022

OVERALL SEQUENCE



AWHIA0555GB

DETAILED FLOW



# DIAGNOSIS AND REPAIR WORK FLOW

## < BASIC INSPECTION >

### 1. INTERVIEW THE CUSTOMER FOR THE SYMPTOM

Interview the customer for the symptom (the condition and the environment when the incident/malfunction occurs).

>> GO TO 2.

### 2. CHECK SYMPTOM

Check the symptom from the customer information.

>> GO TO 3.

### 3. CHECK WARNING LAMP OPERATION

Check air bag warning lamp operation in the user mode.

Are any malfunctions detected?

YES >> GO TO 5.

NO >> GO TO 4.

### 4. CHECK LOW VOLTAGE

Check low voltage with CONSULT.

Are any malfunctions detected?

YES >> GO TO 9.

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

### 5. CHECK SELF DIAGNOSTIC RESULT

Check "Self Diagnostic Result" with CONSULT or diagnosis mode.

If it is impossible to switch to diagnosis mode, follow the same procedure that DTC is not detected.

#### NOTE:

Perform the following procedure if DTC is detected:

- Record DTC. (Print them out with CONSULT.)
- Erase "Self Diagnostic Result".
- Study the relationship between the malfunction that DTC or air bag warning lamp indicates and the symptom that the customer describes.
- Check related service bulletins for information.

Is DTC detected?

YES >> GO TO 6.

NO >> GO TO 7.

### 6. PERFORM DTC CONFIRMATION PROCEDURE

Perform DTC CONFIRMATION PROCEDURE for the DTC.

>> GO TO 8.

### 7. PERFORM DIAGNOSIS ACCORDING TO WARNING LAMP OPERATION

1. Check air bag warning lamp operation in the user mode.
2. Perform Diagnosis Procedure for the air bag warning lamp operation.

>> GO TO 9.

### 8. DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

Inspect according to Diagnostic Procedure of the DTC.

>> GO TO 9.

### 9. REPAIR OR REPLACE THE MALFUNCTION PART

Repair or replace the malfunctioning part.

A

B

C

D

E

F

G

SRC

I

J

K

L

M

N

O

P

## DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

---

>> GO TO 10.

### 10.ON BOARD DIAGNOSIS FUNCTION

---

Check "Self Diagnostic Result" and air bag warning lamp operation in the user mode.

Is the malfunction repaired?

YES >> Inspection End.

NO >> GO TO 2.

# INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

## INSPECTION AND ADJUSTMENT

### ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

#### ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description

INFOID:0000000011219701

#### AIR BAG DIAGNOSIS SENSOR UNIT

##### Before Replacement

When replacing air bag diagnosis sensor unit, save or print current vehicle specification with CONSULT configuration before replacement.

##### NOTE:

If "Before Replace ECU" of "Read / Write Configuration" cannot be used, use the "Manual Configuration" after replacing air bag diagnosis sensor unit.

##### After Replacement

##### CAUTION:

Follow the instructions listed below. Failure to do this may cause malfunctions to the air bag diagnosis sensor unit.

- Never perform "Read / Write Configuration" or "Manual Configuration" except for new air bag diagnosis sensor unit.
- When replacing air bag diagnosis sensor unit, you must perform "Read / Write Configuration" or "Manual Configuration" with CONSULT.
- Complete the procedure of "Read / Write Configuration" or "Manual Configuration" in order.
- If you set incorrect "Read / Write Configuration" or "Manual Configuration", incidents might occur.
- Configuration is different for each vehicle model. Confirm configuration of each vehicle model.

#### OCS CONTROL UNIT

##### WARNING:

Always perform zero point reset using CONSULT when removing and installing the front passenger seat or servicing the occupant classification system (OCS). If zero point reset is not performed, the OCS may not operate normally, which may increase the risk of serious injury in a collision.

#### ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement

INFOID:0000000011219702

#### WORK PROCEDURE WHEN REPLACING AIR BAG DIAGNOSIS SENSOR UNIT

##### 1. SAVING VEHICLE SPECIFICATION

##### ⓂCONSULT Configuration

Perform "Before Replace ECU" of "Read / Write Configuration" to save or print current vehicle specification.

##### NOTE:

If "Before Replace ECU" of "Read / Write Configuration" cannot be used, use the "Manual Configuration" after replacing air bag diagnosis sensor unit.

>> GO TO 2.

##### 2. REPLACE AIR BAG DIAGNOSIS SENSOR UNIT

Replace air bag diagnosis sensor unit. Refer to [SR-29. "Removal and Installation"](#).

>> GO TO 3.

##### 3. WRITING VEHICLE SPECIFICATION

##### ⓂCONSULT Configuration

Perform "After Replace ECU" of "Read / Write Configuration" or "Manual Configuration" to write vehicle specification. Refer to [SRC-44. "CONFIGURATION : Work Procedure"](#).

>> WORK END

# INSPECTION AND ADJUSTMENT

## < BASIC INSPECTION >

### WORK PROCEDURE WHEN REPLACING OCS CONTROL UNIT

#### 1.PERFORM ZERO POINT RESET

Perform zero point reset. Refer to [SRC-44. "ZERO POINT RESET : Special Repair Requirement"](#).

>> Inspection End.

#### ZERO POINT RESET

##### ZERO POINT RESET : Description

INFOID:0000000011219703

Zero point reset is an initializing procedure for the OCS (weight) sensors that must be performed using CONSULT when removing and installing passenger seat or servicing the OCS system, including removing or installing OCS control unit and sensors. If zero point reset is not performed, the initialization is incomplete and OCS may not operate normally.

##### NOTE:

- When reinstalling the passenger seat, the initial value for the OCS sensors may change, and the OCS may not operate normally.
- When zero point reset is performed after removal and installation of passenger seat, CONSULT displays "complete".

##### ZERO POINT RESET : Special Repair Requirement

INFOID:0000000011219704

#### 1.PERFORM ZERO POINT RESET

1. Perform preliminary checks.

##### NOTE:

- Level the vehicle.
  - Minimize vibrations near the vehicle.
  - Remove any objects on passenger seat.
  - Do not touch the vehicle during zero point reset.
2. Select "Start" on "Zero point reset function" from "Work support" of "OCCUPANT DETECTION".
  3. "Zero point reset function" starts.

>> GO TO 2.

#### 2.CONFIRM RESET

1. Check that "Complete" is displayed on "Zero point reset status".

##### CAUTION:

- "Complete" may be displayed if the seat has been reinstalled or "zero point reset" has already been performed.
- "Incomplete" may be displayed if a new seat is installed.
- Air bag warning lamp blinks in user mode if zero point reset is "incomplete".

Is zero point reset status "complete"?

YES >> Print out "Zero point reset current status" screen. Inspection end.

NO >> Recheck the preliminary check items and perform zero point reset again.

#### CONFIGURATION

##### CONFIGURATION : Work Procedure

INFOID:0000000011506347

#### 1.WRITING MODE SELECTION

CONSULT Configuration

Select "Re/programming, Configuration" of air bag.

When writing saved data>>GO TO 2.

When writing manually>>GO TO 3.

#### 2.PERFORM "AFTER REPLACE ECU" OF "READ / WRITE CONFIGURATION"

CONSULT Configuration

## INSPECTION AND ADJUSTMENT

### < BASIC INSPECTION >

Perform "After Replace ECU" of "Read / Write Configuration".

>> GO TO 4.

### 3.PERFORM "MANUAL CONFIGURATION"

 CONSULT Configuration

1. Select "Manual Configuration".
2. Touch "Next".
3. Select the "Type ID" searched by using FAST (service parts catalogue) to write the "Type ID" into the air bag diagnosis sensor unit.
4. Touch "OK".
5. Check that the configuration has been successfully written and touch "End".

>> GO TO 4.

### 4.CHECK ALL ECU SELF-DIAGNOSIS RESULTS

1. Erase all ECU self-diagnosis results using CONSULT.
2. Turn the ignition switch OFF.
3. Turn the ignition switch ON.
4. Check that all ECU self-diagnosis results have no DTC.

>> WORK END

A

B

C

D

E

F

G

SRC

I

J

K

L

M

N

O

P

# INTERMITTENT INCIDENT

< BASIC INSPECTION >

---

## INTERMITTENT INCIDENT

### Inspection Procedure

INFOID:0000000011219705

### INTERMITTENT TROUBLE

An intermittent incident may have occurred in the past but is not being detected currently. This DTC will not be detected on “Self Diagnostic Result [CURRENT]” but may be viewed on “Self Diagnostic Result [PAST]” if the DTC has not been erased.

### Trouble Diagnosis with CONSULT

INFOID:0000000011219706

### CHECK SRS REPAIR HISTORY

Refer to [SRC-17, "SRS History Check"](#).

# U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## DTC/CIRCUIT DIAGNOSIS

### U1000 CAN COMM CIRCUIT

#### Description

INFOID:0000000011219707

CAN (Controller Area Network) is a serial communication system for real-time application. It is an on-vehicle multiplex communication system with high data communication speed and excellent error detection ability. Many electronic control units are equipped into vehicles, and each control unit shares information and links with other control units during operation. With CAN communication, control units are connected with two communication lines (CAN-H line, CAN-L line), allowing a high rate of information transmission with less wiring. Each control unit transmits and receives data but selectively reads required data only. Refer to [LAN-37, "CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart"](#).

#### DTC Logic

INFOID:0000000011219708

#### DTC DETECTION LOGIC

DTC	CONSULT name	DTC detecting condition	
U1000-01	CAN COMM CIRCUIT	Diagnosis condition	When ignition switch is ON.
		Signal (terminal)	—
		Threshold	—
		Diagnosis delay time	—

SRC

#### POSSIBLE CAUSE

CAN communication system

#### FAIL-SAFE

—

#### DTC CONFIRMATION PROCEDURE

##### 1.PERFORM SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON and wait for 7 seconds or more.
2. Using CONSULT, perform "Self Diagnostic Result" of "AIR BAG".
3. Check if any DTC is displayed in the "Self Diagnostic Result".

##### Is DTC detected?

- YES >> Refer to [SRC-47, "Diagnosis Procedure"](#).  
NO >> Refer to [GI-42, "Intermittent Incident"](#).

#### Diagnosis Procedure

INFOID:0000000011219709

##### 1.CHECK CAN COMMUNICATION SYSTEM

Check CAN communication system. Refer to [LAN-21, "Trouble Diagnosis Flow Chart"](#).

>> Inspection End.

## U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

### U1010 CONTROL UNIT (CAN)

#### Description

INFOID:0000000011219710

Air bag diagnosis sensor unit performs self-tests at key ON. If CAN communication failure within control unit is detected, DTC is set.

#### DTC Logic

INFOID:0000000011219711

#### DTC DETECTION LOGIC

DTC	CONSULT screen items (Trouble diagnosis content)	DTC detecting condition	
		Diagnosis condition	When ignition switch is ON.
U1010	CONTROL UNIT (CAN)	Signal (terminal)	—
		Threshold	—
		Diagnosis delay time	—

#### POSSIBLE CAUSE

Air bag diagnosis sensor unit

#### FAIL-SAFE

—

#### DTC CONFIRMATION PROCEDURE

##### 1.PERFORM SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON.
2. Using CONSULT, perform “Self Diagnostic Result” of “AIR BAG”.
3. Check if DTC is displayed in the “Self Diagnostic Result”.

##### Is DTC detected?

- YES >> Refer to [SRC-48, "Diagnosis Procedure"](#).  
NO >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000011219712

##### 1.REPLACE AIR BAG DIAGNOSIS SENSOR UNIT

Replace air bag diagnosis sensor unit. Refer to [SR-29, "Removal and Installation"](#).

>> Inspection End.



# B0001, B0002 DRIVER AIRBAG MODULE

< DTC/CIRCUIT DIAGNOSIS >

## B0001, B0002 DRIVER AIRBAG MODULE

### DTC Description

INFOID:0000000011219714

### DTC DETECTION LOGIC

DTC	CONSULT name	DTC detecting condition	
B0001	DRIVER AIRBAG MODULE [OPEN]	13	Diagnosis condition
			When ignition switch is ON.
			Signal (terminal)
			Driver air bag module circuit (DR1) (terminal 23 and 24)
	DRIVER AIRBAG MODULE [VB-SHORT]	12	Threshold
			—
			Diagnosis delay time
			—
	DRIVER AIRBAG MODULE [GND-SHORT]	11	Diagnosis condition
			When ignition switch is ON.
			Signal (terminal)
			Driver air bag module circuit (DR1) (terminal 23 and 24)
	DRIVER AIRBAG MODULE [SHORT]	00	Threshold
			—
			Diagnosis delay time
			—
B0002	DRIVER AIRBAG MODULE 2ND [OPEN]	13	Diagnosis condition
			When ignition switch is ON.
			Signal (terminal)
			Driver air bag module circuit (DR2) (terminal 25 and 26)
	DRIVER AIRBAG MODULE 2ND [VB-SHORT]	12	Threshold
			—
			Diagnosis delay time
			—
	DRIVER AIRBAG MODULE 2ND [GND-SHORT]	11	Diagnosis condition
			When ignition switch is ON.
			Signal (terminal)
			Driver air bag module circuit (DR2) (terminal 25 and 26)
	DRIVER AIRBAG MODULE 2ND [SHORT]	00	Threshold
			—
			Diagnosis delay time
			—

## B0001, B0002 DRIVER AIRBAG MODULE

### < DTC/CIRCUIT DIAGNOSIS >

---

#### POSSIBLE CAUSE

##### [OPEN]

- Connection malfunction or open circuit of harness and connector
- Internal malfunction of driver air bag module
- Internal malfunction of air bag diagnosis sensor unit

##### [VB-SHORT]

- Connection malfunction or short circuit to power supply of harness and connector
- Internal malfunction of driver air bag module
- Internal malfunction of air bag diagnosis sensor unit

##### [GND-SHORT]

- Connection malfunction or short circuit to ground of harness and connector
- Internal malfunction of driver air bag module
- Internal malfunction of air bag diagnosis sensor unit

##### [SHORT]

- Connection malfunction or short circuit of harness and connector
- Internal malfunction of driver air bag module
- Internal malfunction of air bag diagnosis sensor unit

#### FAIL-SAFE

—

#### DTC CONFIRMATION PROCEDURE (With CONSULT)

##### 1.CHECK SELF DIAGNOSTIC RESULT

---

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

##### Is the DTC detected?

YES (Current DTC)>>Refer to [SRC-50. "Diagnosis Procedure"](#).

YES (Past DTC)>>GO TO 2.

NO >> Inspection End.

##### 2.ERASE SELF DIAGNOSTIC RESULT

---

Erase the DTC using CONSULT.

##### Can the DTC be erased?

YES >> Inspection End.

NO >> Refer to [SRC-50. "Diagnosis Procedure"](#).

#### DTC CONFIRMATION PROCEDURE (Without CONSULT)

##### 1.CHECK SELF DIAGNOSTIC RESULT

---

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16. "SRS Operation Check"](#).

##### **NOTE:**

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

##### Is the DTC detected?

YES >> Refer to [SRC-50. "Diagnosis Procedure"](#).

NO >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000011219715

##### 1.HARNESS CONNECTOR

---

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

## B0001, B0002 DRIVER AIRBAG MODULE

### < DTC/CIRCUIT DIAGNOSIS >

#### NOTE:

All harness connectors should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

#### Is the inspection result normal?

YES >> GO TO 2.

NO >> Perform one of the following repairs:

- Visible damage: Replace the harness.
- Loose terminal: Secure the terminal.
- Poor connection: Secure the connection.

### 2.CONFIRM DTC

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

#### Is DTC still current?

YES >> GO TO 3.

NO >> Refer to [GI-42. "Intermittent Incident"](#).

### 3.WIRING HARNESS

Check the wiring harness for visible damage.

#### NOTE:

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

#### Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace the harness.

### 4.CHECK SPIRAL CABLE CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver air bag module harness connectors and spiral cable harness connector.
3. Check continuity between driver air bag module harness connector and spiral cable connector.

Driver air bag module		Spiral cable		Continuity
Connector	Terminal	Connector	Terminal	
M87	23	M53	4	Yes
	24		6	
M89	25		4	
	26		5	

4. Check continuity between driver air bag module harness connector and ground.

Driver air bag module		Ground	Continuity
Connector	Terminal		
M87	23		No
	24		
M89	25		
	26		

#### Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace the spiral cable. Refer to [SR-15. "Removal and Installation"](#).

### 5.CONFIRM DTC

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

#### Is DTC still current?

## B0001, B0002 DRIVER AIRBAG MODULE

### < DTC/CIRCUIT DIAGNOSIS >

---

- YES >> GO TO 6.  
NO >> Refer to [GI-42. "Intermittent Incident"](#).

### 6. AIR BAG DIAGNOSIS SENSOR UNIT

---

1. Replace the air bag diagnosis sensor unit. Refer to [SR-29. "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

#### Is DTC still current?

- YES >> GO TO 7.  
NO >> Clear DTC. Inspection End.

### 7. DRIVER AIR BAG MODULE

---

1. Replace the driver air bag module. Refer to [SR-12. "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

#### Is DTC still current?

- YES >> GO TO 8.  
NO >> Clear DTC. Inspection End.

### 8. RELATED HARNESS

---

Replace the related harness.

>> Inspection End.

# B0010, B0011 PASSENGER AIRBAG MODULE

< DTC/CIRCUIT DIAGNOSIS >

## B0010, B0011 PASSENGER AIRBAG MODULE

### DTC Description

INFOID:0000000011219717

### DTC DETECTION LOGIC

DTC	CONSULT name	DTC detecting condition	
B0010	ASSIST AIRBAG MODULE [OPEN]	13	Diagnosis condition
			When ignition switch is ON
			Signal (terminal)
			Front passenger air bag module circuit (AS1) (terminal 5 and 6)
	ASSIST AIRBAG MODULE [VB-SHORT]	12	Threshold
			—
			Diagnosis delay time
			—
	ASSIST AIRBAG MODULE [GND-SHORT]	11	Diagnosis condition
			When ignition switch is ON
			Signal (terminal)
			Front passenger air bag module circuit (AS1) (terminal 5 and 6)
	ASSIST AIRBAG MODULE [SHORT]	09	Threshold
			—
			Diagnosis delay time
			—
B0011	ASSIST AIRBAG MODULE 2ND [OPEN]	13	Diagnosis condition
			When ignition switch is ON
			Signal (terminal)
			Front passenger air bag module circuit (AS2) (terminal 1 and 2)
	ASSIST AIRBAG MODULE 2ND [VB-SHORT]	12	Threshold
			—
			Diagnosis delay time
			—
	ASSIST AIRBAG MODULE 2ND [GND-SHORT]	11	Diagnosis condition
			When ignition switch is ON
			Signal (terminal)
			Front passenger air bag module circuit (AS2) (terminal 1 and 2)
	ASSIST AIRBAG MODULE 2ND [SHORT]	09	Threshold
			—
			Diagnosis delay time
			—

### POSSIBLE CAUSE

## B0010, B0011 PASSENGER AIRBAG MODULE

### < DTC/CIRCUIT DIAGNOSIS >

---

#### [OPEN]

- Connection malfunction or open circuit of harness and connector
- Internal malfunction of passenger air bag module
- Internal malfunction of air bag diagnosis sensor unit

#### [VB-SHORT]

- Connection malfunction or short circuit to power supply of harness and connector
- Internal malfunction of passenger air bag module
- Internal malfunction of air bag diagnosis sensor unit

#### [GND-SHORT]

- Connection malfunction or short circuit to ground of harness and connector
- Internal malfunction of passenger air bag module
- Internal malfunction of air bag diagnosis sensor unit

#### [SHORT]

- Connection malfunction or short circuit of harness and connector
- Internal malfunction of passenger air bag module
- Internal malfunction of air bag diagnosis sensor unit

#### FAIL-SAFE

---

### DTC CONFIRMATION PROCEDURE (With CONSULT)

#### 1.CHECK SELF DIAGNOSTIC RESULT

---

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

##### Is the DTC detected?

- YES (Current DTC)>> Refer to [SRC-54. "Diagnosis Procedure"](#).  
YES (Past DTC)>> GO TO 2.  
NO >> Inspection End.

#### 2.ERASE SELF DIAGNOSTIC RESULT

---

Erase the DTC using CONSULT.

##### Can the DTC be erased?

- YES >> Inspection End.  
NO >> Refer to [SRC-54. "Diagnosis Procedure"](#).

### DTC CONFIRMATION PROCEDURE (Without CONSULT)

#### 1.CHECK SELF DIAGNOSTIC RESULT

---

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16. "SRS Operation Check"](#).

#### **NOTE:**

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

##### Is the DTC detected?

- YES >> Refer to [SRC-54. "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000011219718

#### 1.HARNESS CONNECTOR

---

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

#### **NOTE:**

## B0010, B0011 PASSENGER AIRBAG MODULE

### < DTC/CIRCUIT DIAGNOSIS >

All harness connectors should be inspected from the air bag diagnosis unit to the end component (including any in-line connectors).

#### Is the inspection result normal?

YES >> GO TO 2.

NO >> Perform one of the following repairs:

- Visible damage: Replace the harness.
- Loose terminal: Secure the terminal.
- Poor connection: Secure the connection.

### 2.CONFIRM DTC

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

#### Is DTC still current?

YES >> GO TO 3.

NO >> Refer to [GI-42, "Intermittent Incident"](#).

### 3.WIRING HARNESS

Check the wiring harness for visible damage.

#### **NOTE:**

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

#### Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace the harness.

### 4.CONFIRM DTC

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

#### Is DTC still current?

YES >> GO TO 5.

NO >> Refer to [GI-42, "Intermittent Incident"](#).

### 5.AIR BAG DIAGNOSIS SENSOR UNIT

1. Replace the air bag diagnosis sensor unit. Refer to [SR-29, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

#### Is DTC still current?

YES >> GO TO 6.

NO >> Clear DTC. Inspection End.

### 6.FRONT PASSENGER AIR BAG MODULE

1. Replace the front passenger air bag module. Refer to [SR-18, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

#### Is DTC still current?

YES >> GO TO 7.

NO >> Clear DTC. Inspection End.

### 7.RELATED HARNESS

Replace the related harness.

>> Inspection End.

## B0020 SIDE AIRBAG MODULE LH

< DTC/CIRCUIT DIAGNOSIS >

### B0020 SIDE AIRBAG MODULE LH

#### DTC Description

INFOID:0000000011219720

#### DTC DETECTION LOGIC

DTC	CONSULT name	DTC detecting condition		
B0020	SIDE AIRBAG MODULE LH [OPEN]	13	Diagnosis condition	When ignition switch is ON
			Signal (terminal)	Side air bag module LH circuit (terminal 1 and 2)
			Threshold	—
			Diagnosis delay time	—
	SIDE AIRBAG MODULE LH [VB-SHORT]	12	Diagnosis condition	When ignition switch is ON
			Signal (terminal)	Side air bag module LH circuit (terminal 1 and 2)
			Threshold	—
			Diagnosis delay time	—
	SIDE AIRBAG MODULE LH [GND-SHORT]	11	Diagnosis condition	When ignition switch is ON
			Signal (terminal)	Side air bag module LH circuit (terminal 1 and 2)
			Threshold	—
			Diagnosis delay time	—
	SIDE AIRBAG MODULE LH [SHORT]	00	Diagnosis condition	When ignition switch is ON
			Signal (terminal)	Side air bag module LH circuit (terminal 1 and 2)
			Threshold	—
			Diagnosis delay time	—

#### POSSIBLE CAUSE

[OPEN]

- Connection malfunction or open circuit of harness and connector
- Internal malfunction of side air bag module LH
- Internal malfunction of air bag diagnosis sensor unit

[VB-SHORT]

- Connection malfunction or short circuit to power supply of harness and connector
- Internal malfunction of side air bag module LH
- Internal malfunction of air bag diagnosis sensor unit

[GND-SHORT]

- Connection malfunction or short circuit to ground of harness and connector
- Internal malfunction of side air bag module LH
- Internal malfunction of air bag diagnosis sensor unit

[SHORT]

- Connection malfunction or short circuit of harness and connector
- Internal malfunction of side air bag module LH
- Internal malfunction of air bag diagnosis sensor unit

#### FAIL-SAFE

—

#### DTC CONFIRMATION PROCEDURE (With CONSULT)

##### 1. CHECK SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

Is the DTC detected?



## B0020 SIDE AIRBAG MODULE LH

### < DTC/CIRCUIT DIAGNOSIS >

YES (Current DTC)>> Refer to [SRC-57. "Diagnosis Procedure"](#).

YES (Past DTC)>> GO TO 2.

NO >> Inspection End.

### 2.ERASE SELF DIAGNOSTIC RESULT

Erase the DTC using CONSULT.

Can the DTC be erased?

YES >> Inspection End.

NO >> Refer to [SRC-57. "Diagnosis Procedure"](#).

### DTC CONFIRMATION PROCEDURE (Without CONSULT)

#### 1.CHECK SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON.

2. Check the air bag warning lamp status. Refer to [SRC-16. "SRS Operation Check"](#).

#### **NOTE:**

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

Is the DTC detected?

YES >> Refer to [SRC-57. "Diagnosis Procedure"](#).

NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000011219721

#### 1.HARNESS CONNECTOR

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

#### **NOTE:**

All harness connectors should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Perform one of the following repairs:

- Visible damage: Replace the harness.
- Loose terminal: Secure the terminal.
- Poor connection: Secure the connection.

#### 2.CONFIRM DTC

1. Reconnect all harness connectors.

2. Turn ignition switch ON.

3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 3.

NO >> Refer to [GI-42. "Intermittent Incident"](#).

#### 3.WIRING HARNESS

Check the wiring harness for visible damage.

#### **NOTE:**

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace the harness.

#### 4.CONFIRM DTC

1. Reconnect all harness connectors.

2. Turn ignition switch ON.

3. Check for DTC using CONSULT.

## B0020 SIDE AIRBAG MODULE LH

### < DTC/CIRCUIT DIAGNOSIS >

---

#### Is DTC still current?

YES >> GO TO 5.

NO >> Refer to [GI-42. "Intermittent Incident"](#).

### 5. AIR BAG DIAGNOSIS SENSOR UNIT

---

1. Replace the air bag diagnosis sensor unit. Refer to [SR-29. "Removal and Installation"](#).

2. Turn ignition switch ON.

3. Check for DTC using CONSULT.

#### Is DTC still current?

YES >> GO TO 6.

NO >> Clear DTC. Inspection End.

### 6. SIDE AIR BAG MODULE LH

---

1. Replace the side air bag module LH.

2. Turn ignition switch ON.

3. Check for DTC using CONSULT.

#### Is DTC still current?

YES >> GO TO 7.

NO >> Clear DTC. Inspection End.

### 7. RELATED HARNESS

---

Replace the related harness.

>> Inspection End.

## B0028 SIDE AIRBAG MODULE RH

< DTC/CIRCUIT DIAGNOSIS >

### B0028 SIDE AIRBAG MODULE RH

#### DTC Description

INFOID:0000000011219723

#### DTC DETECTION LOGIC

DTC	CONSULT name	DTC detecting condition		
B0028	SIDE AIRBAG MODULE RH [OPEN]	13	Diagnosis condition	When ignition switch is ON
			Signal (terminal)	Side air bag module RH circuit (terminals 1 and 2)
			Threshold	—
			Diagnosis delay time	—
	SIDE AIRBAG MODULE RH [VB-SHORT]	12	Diagnosis condition	When ignition switch is ON
			Signal (terminal)	Side air bag module RH circuit (terminals 1 and 2)
			Threshold	—
			Diagnosis delay time	—
	SIDE AIRBAG MODULE RH [GND-SHORT]	11	Diagnosis condition	When ignition switch is ON
			Signal (terminal)	Side air bag module RH circuit (terminals 1 and 2)
			Threshold	—
			Diagnosis delay time	—
	SIDE AIRBAG MODULE RH [SHORT]	09	Diagnosis condition	When ignition switch is ON
			Signal (terminal)	Side air bag module RH circuit (terminals 1 and 2)
			Threshold	—
			Diagnosis delay time	—

#### POSSIBLE CAUSE

##### [OPEN]

- Connection malfunction or open circuit of harness and connector
- Internal malfunction of side air bag module RH
- Internal malfunction of air bag diagnosis sensor unit

##### [VB-SHORT]

- Connection malfunction or short circuit to power supply of harness and connector
- Internal malfunction of side air bag module RH
- Internal malfunction of air bag diagnosis sensor unit

##### [GND-SHORT]

- Connection malfunction or short circuit to ground of harness and connector
- Internal malfunction of side air bag module RH
- Internal malfunction of air bag diagnosis sensor unit

##### [SHORT]

- Connection malfunction or short circuit of harness and connector
- Internal malfunction of side air bag module RH
- Internal malfunction of air bag diagnosis sensor unit

#### FAIL-SAFE

—

#### DTC CONFIRMATION PROCEDURE (With CONSULT)

## B0028 SIDE AIRBAG MODULE RH

### < DTC/CIRCUIT DIAGNOSIS >

---

#### 1. CHECK SELF DIAGNOSTIC RESULT

---

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

##### Is the DTC detected?

YES (Current DTC)>> Refer to [SRC-60, "Diagnosis Procedure"](#).

YES (Past DTC)>> GO TO 2.

NO >> Inspection End.

#### 2. ERASE SELF DIAGNOSTIC RESULT

---

Erase the DTC using CONSULT.

##### Can the DTC be erased?

YES >> Inspection End.

NO >> Refer to [SRC-60, "Diagnosis Procedure"](#).

### DTC CONFIRMATION PROCEDURE (Without CONSULT)

#### 1. CHECK SELF DIAGNOSTIC RESULT

---

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16, "SRS Operation Check"](#).

##### **NOTE:**

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

##### Is the DTC detected?

YES >> Refer to [SRC-60, "Diagnosis Procedure"](#).

NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000011219724

#### 1. HARNESS CONNECTOR

---

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

##### **NOTE:**

All harness connectors should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

##### Is the inspection result normal?

YES >> GO TO 2.

NO >> Perform one of the following repairs:

- Visible damage: Replace the harness.
- Loose terminal: Secure the terminal.
- Poor connection: Secure the connection.

#### 2. CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

##### Is DTC still current?

YES >> GO TO 3.

NO >> Refer to [GI-42, "Intermittent Incident"](#).

#### 3. WIRING HARNESS

---

Check the wiring harness for visible damage.

##### **NOTE:**

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

##### Is the inspection result normal?

YES >> GO TO 4.

## B0028 SIDE AIRBAG MODULE RH

### < DTC/CIRCUIT DIAGNOSIS >

NO >> Replace the harness.

#### 4.CONFIRM DTC

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

##### Is DTC still current?

YES >> GO TO 5.

NO >> Refer to [GI-42. "Intermittent Incident"](#).

#### 5.AIR BAG DIAGNOSIS SENSOR UNIT

1. Replace the air bag diagnosis sensor unit. Refer to [SR-29. "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

##### Is DTC still current?

YES >> GO TO 6.

NO >> Clear DTC. Inspection End.

#### 6.SIDE AIR BAG MODULE RH

1. Replace the side air bag module RH.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

##### Is DTC still current?

YES >> GO TO 7.

NO >> Clear DTC. Inspection End.

#### 7.RELATED HARNESS

Replace the related harness.

>> Inspection End.

A

B

C

D

E

F

G

SRC

I

J

K

L

M

N

O

P

## B0021 SIDE CURTAIN AIR BAG MODULE LH

< DTC/CIRCUIT DIAGNOSIS >

### B0021 SIDE CURTAIN AIR BAG MODULE LH

#### DTC Description

INFOID:0000000011219726

#### DTC DETECTION LOGIC

DTC	CONSULT name	DTC detecting condition		
B0021	CURTAIN AIRBAG MODULE LH CIRCUIT [OPEN]	13	Diagnosis condition	When ignition switch is ON
			Signal (terminal)	LH side curtain air bag module circuit (terminal 1 and 2)
			Threshold	—
			Diagnosis delay time	—
	CURTAIN AIRBAG MODULE LH CIRCUIT [VB-SHORT]	12	Diagnosis condition	When ignition switch is ON
			Signal (terminal)	LH side curtain air bag module circuit (terminal 1 and 2)
			Threshold	—
			Diagnosis delay time	—
	CURTAIN AIRBAG MODULE LH CIRCUIT [GND-SHORT]	11	Diagnosis condition	When ignition switch is ON
			Signal (terminal)	LH side curtain air bag module circuit (terminal 1 and 2)
			Threshold	—
			Diagnosis delay time	—
	CURTAIN AIRBAG MODULE LH CIRCUIT [SHORT]	09	Diagnosis condition	When ignition switch is ON
			Signal (terminal)	LH side curtain air bag module circuit (terminal 1 and 2)
			Threshold	—
			Diagnosis delay time	—

#### POSSIBLE CAUSE

##### [OPEN]

- Connection malfunction or open circuit of harness and connector
- Internal malfunction of side curtain air bag module LH
- Internal malfunction of air bag diagnosis sensor unit

##### [VB-SHORT]

- Connection malfunction or short circuit to power supply of harness and connector
- Internal malfunction of side curtain air bag module LH
- Internal malfunction of air bag diagnosis sensor unit

##### [GND-SHORT]

- Connection malfunction or short circuit to ground of harness and connector
- Internal malfunction of side curtain air bag module LH
- Internal malfunction of air bag diagnosis sensor unit

##### [SHORT]

- Connection malfunction or short circuit of harness and connector
- Internal malfunction of side curtain air bag module LH
- Internal malfunction of air bag diagnosis sensor unit

#### FAIL-SAFE

—

#### DTC CONFIRMATION PROCEDURE (With CONSULT)

## B0021 SIDE CURTAIN AIR BAG MODULE LH

### < DTC/CIRCUIT DIAGNOSIS >

#### 1.CHECK SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

##### Is the DTC detected?

YES (Current DTC)>> Refer to [SRC-63, "Diagnosis Procedure"](#).

YES (Past DTC)>> GO TO 2.

NO >> Inspection End.

#### 2.ERASE SELF DIAGNOSTIC RESULT

Erase the DTC using CONSULT.

##### Can the DTC be erased?

YES >> Inspection End.

NO >> Refer to [SRC-63, "Diagnosis Procedure"](#).

### DTC CONFIRMATION PROCEDURE (Without CONSULT)

#### 1.CHECK SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16, "SRS Operation Check"](#).

##### **NOTE:**

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

##### Is the DTC detected?

YES >> Refer to [SRC-63, "Diagnosis Procedure"](#).

NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000011219727

#### 1.HARNESS CONNECTOR

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

##### **NOTE:**

All harness connectors should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

##### Is the inspection result normal?

YES >> GO TO 2.

- NO >> Perform one of the following repairs:
- Visible damage: Replace the harness.
  - Loose terminal: Secure the terminal.
  - Poor connection: Secure the connection.

#### 2.CONFIRM DTC

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

##### Is DTC still current?

YES >> GO TO 3.

NO >> Refer to [GI-42, "Intermittent Incident"](#).

#### 3.WIRING HARNESS

Check the wiring harness for visible damage.

##### **NOTE:**

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

##### Is the inspection result normal?

YES >> GO TO 4.

## B0021 SIDE CURTAIN AIR BAG MODULE LH

### < DTC/CIRCUIT DIAGNOSIS >

---

NO >> Replace the harness.

#### 4.CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

#### Is DTC still current?

YES >> GO TO 5.

NO >> Refer to [GI-42, "Intermittent Incident"](#).

#### 5.AIR BAG DIAGNOSIS SENSOR UNIT

---

1. Replace the air bag diagnosis sensor unit. Refer to [SR-29, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

#### Is DTC still current?

YES >> GO TO 6.

NO >> Clear DTC. Inspection End.

#### 6.SIDE CURTAIN AIR BAG MODULE LH

---

1. Replace the side curtain air bag module LH. Refer to [SR-22, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

#### Is DTC still current?

YES >> GO TO 7.

NO >> Clear DTC. Inspection End.

#### 7.RELATED HARNESS

---

Replace the related harness.

>> Inspection End.



## B0029 SIDE CURTAIN AIR BAG MODULE RH

< DTC/CIRCUIT DIAGNOSIS >

### B0029 SIDE CURTAIN AIR BAG MODULE RH

#### DTC Description

INFOID:0000000011219729

#### DTC DETECTION LOGIC

DTC	CONSULT name	DTC detecting condition	
B0029	CURTAIN AIRBAG MODULE RH [OPEN]	13	Diagnosis condition
			When the ignition switch is ON
			Signal (terminal)
			RH side curtain air bag module circuit (terminal 1 and 2)
B0029	CURTAIN AIRBAG MODULE RH [VB-SHORT]	12	Diagnosis condition
			When the ignition switch is ON
			Signal (terminal)
			RH side curtain air bag module circuit (terminal 1 and 2)
B0029	CURTAIN AIRBAG MODULE RH [GND-SHORT]	11	Diagnosis condition
			When the ignition switch is ON
			Signal (terminal)
			RH side curtain air bag module circuit (terminal 1 and 2)
B0029	CURTAIN AIRBAG MODULE RH [SHORT]	09	Diagnosis condition
			When the ignition switch is ON
			Signal (terminal)
			RH side curtain air bag module circuit (terminal 1 and 2)
B0029	CURTAIN AIRBAG MODULE RH [SHORT]	09	Threshold
			—
			Diagnosis delay time
			—

#### POSSIBLE CAUSE

##### [OPEN]

- Connection malfunction or open circuit of harness and connector
- Internal malfunction of curtain air bag module RH
- Internal malfunction of air bag diagnosis sensor unit

##### [VB-SHORT]

- Connection malfunction or short circuit to power supply of harness and connector
- Internal malfunction of curtain air bag module RH
- Internal malfunction of air bag diagnosis sensor unit

##### [GND-SHORT]

- Connection malfunction or short circuit to ground of harness and connector
- Internal malfunction of curtain air bag module RH
- Internal malfunction of air bag diagnosis sensor unit

##### [SHORT]

- Connection malfunction or short circuit of harness and connector
- Internal malfunction of curtain air bag module RH
- Internal malfunction of air bag diagnosis sensor unit

#### DTC CONFIRMATION PROCEDURE (With CONSULT)

## B0029 SIDE CURTAIN AIR BAG MODULE RH

### < DTC/CIRCUIT DIAGNOSIS >

---

#### 1. CHECK SELF DIAGNOSTIC RESULT

---

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

##### Is the DTC detected?

YES (Current DTC)>> Refer to [SRC-66, "Diagnosis Procedure"](#).

YES (Past DTC)>> GO TO 2.

NO >> Inspection End.

#### 2. ERASE SELF DIAGNOSTIC RESULT

---

Erase the DTC using CONSULT.

##### Can the DTC be erased?

YES >> Inspection End.

NO >> Refer to [SRC-66, "Diagnosis Procedure"](#).

### DTC CONFIRMATION PROCEDURE (Without CONSULT)

#### 1. CHECK SELF DIAGNOSTIC RESULT

---

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16, "SRS Operation Check"](#).

##### **NOTE:**

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

##### Is the DTC detected?

YES >> Refer to [SRC-66, "Diagnosis Procedure"](#).

NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000011219730

#### 1. HARNESS CONNECTOR

---

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

##### **NOTE:**

All harness connectors should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

##### Is the inspection result normal?

YES >> GO TO 2.

NO >> Perform one of the following repairs:

- Visible damage: Replace the harness.
- Loose terminal: Secure the terminal.
- Poor connection: Secure the connection.

#### 2. CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

##### Is DTC still current?

YES >> GO TO 3.

NO >> Refer to [GI-42, "Intermittent Incident"](#).

#### 3. WIRING HARNESS

---

Check the wiring harness for visible damage.

##### **NOTE:**

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

##### Is the inspection result normal?

YES >> GO TO 4.

## B0029 SIDE CURTAIN AIR BAG MODULE RH

### < DTC/CIRCUIT DIAGNOSIS >

NO >> Replace the harness.

#### 4.CONFIRM DTC

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

##### Is DTC still current?

YES >> GO TO 5.

NO >> Refer to [GI-42, "Intermittent Incident"](#).

#### 5.AIR BAG DIAGNOSIS SENSOR UNIT

1. Replace the air bag diagnosis sensor unit. Refer to [SR-29, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

##### Is DTC still current?

YES >> GO TO 6.

NO >> Clear DTC. Inspection End.

#### 6.SIDE CURTAIN AIR BAG MODULE RH

1. Replace the side curtain air bag module RH. Refer to [SR-22, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

##### Is DTC still current?

YES >> GO TO 7.

NO >> Clear DTC. Inspection End.

#### 7.RELATED HARNESS

Replace the related harness.

>> Inspection End.

A

B

C

D

E

F

G

SRC

I

J

K

L

M

N

O

P

# B0094 CRASH ZONE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

## B0094 CRASH ZONE SENSOR

### DTC Description

INFOID:0000000011219732

### DTC DETECTION LOGIC

DTC	CONSULT name	DTC detecting condition	
B0094	CRASH ZONE SENSOR [RESET]	93	Diagnosis condition
			When ignition switch is ON.
			Signal (terminal)
			Crash zone sensor (terminal 1 and 2)
	CRASH ZONE SENSOR [COMM ERR]	81	Threshold
			—
			Diagnosis delay time
			—
	CRASH ZONE SENSOR [OPEN]	88	Diagnosis condition
			When ignition switch is ON.
			Signal (terminal)
			Crash zone sensor (terminal 1 and 2)
	CRASH ZONE SENSOR [UNMATCH]	86	Threshold
			—
			Diagnosis delay time
			—
	CRASH ZONE SENSOR [OFFSET ERR]	28	Diagnosis condition
			When ignition switch is ON.
			Signal (terminal)
			Crash zone sensor (terminal 1 and 2)
	CRASH ZONE SENSOR [SELF-DIAG ERR]	25	Threshold
			—
			Diagnosis delay time
			—
	CRASH ZONE SENSOR [LOWER LIMIT ERR]	23	Diagnosis condition
			When ignition switch is ON.
			Signal (terminal)
			Crash zone sensor (terminal 1 and 2)
	CRASH ZONE SENSOR [UPPER LIMIT ERR]	24	Threshold
			—
			Diagnosis delay time
			—
	CRASH ZONE SENSOR [GND-SHORT]	11	Diagnosis condition
			When ignition switch is ON.
			Signal (terminal)
			Crash zone sensor (terminal 1 and 2)

### POSSIBLE CAUSE

[RESET], [COMM ERR]

- Connection malfunction of harness or connector

## B0094 CRASH ZONE SENSOR

### < DTC/CIRCUIT DIAGNOSIS >

- Internal malfunction of crash zone sensor
- Internal malfunction of air bag diagnosis sensor unit

#### [OPEN]

- Connection malfunction or open circuit of harness or connector
- Internal malfunction of crash zone sensor
- Internal malfunction of air bag diagnosis sensor unit

#### [UNMATCH]

- Air bag diagnosis sensor unit and crash zone sensor is different from the part specified

#### [OFFSET ERR], [SELF-DIAG ERR], [LOWER LIMIT ERR], [UPPER LIMIT ERR]

- Internal malfunction of crash zone sensor
- Internal malfunction of air bag diagnosis sensor unit

#### [GND-SHORT]

- Connection malfunction or short circuit to ground of harness or connector
- Internal malfunction of crash zone sensor
- Internal malfunction of air bag diagnosis sensor unit

#### FAIL-SAFE

### DTC CONFIRMATION PROCEDURE (With CONSULT)

#### 1.CHECK SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

##### Is the DTC detected?

YES (Current DTC)>> Refer to [SRC-69, "Diagnosis Procedure"](#).

YES (Past DTC)>> GO TO 2.

NO >> Inspection End.

#### 2.ERASE SELF DIAGNOSTIC RESULT

Erase the DTC using CONSULT.

##### Can the DTC be erased?

YES >> Inspection End.

NO >> Refer to [SRC-69, "Diagnosis Procedure"](#).

### DTC CONFIRMATION PROCEDURE (Without CONSULT)

#### 1.CHECK SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16, "SRS Operation Check"](#).

##### **NOTE:**

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

##### Is the DTC detected?

YES >> Refer to [SRC-69, "Diagnosis Procedure"](#).

NO >> Inspection End.

### Diagnosis Procedure

#### 1.HARNESS CONNECTOR

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

## B0094 CRASH ZONE SENSOR

### < DTC/CIRCUIT DIAGNOSIS >

---

**NOTE:**

All harness connectors should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Perform one of the following repairs:

- Visible damage: Replace the harness.
- Loose terminal: Secure the terminal.
- Poor connection: Secure the connection.

## 2.CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 3.

NO >> Refer to [GI-42, "Intermittent Incident"](#).

## 3.WIRING HARNESS

---

Check the wiring harness for visible damage.

**NOTE:**

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace the harness.

## 4.CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 5.

NO >> Refer to [GI-42, "Intermittent Incident"](#).

## 5.CRASH ZONE SENSOR

---

1. Replace the crash zone sensor. Refer to [SR-25, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 6.

NO >> Clear DTC. Inspection End.

## 6.AIR BAG DIAGNOSIS SENSOR UNIT

---

1. Replace the air bag diagnosis sensor unit. Refer to [SR-29, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 7.

NO >> Clear DTC. Inspection End.

## 7.RELATED HARNESS

---

Replace the related harness.

>> Inspection End.

# B0091 FRONT SIDE AIR BAG SATELLITE SENSOR LH

< DTC/CIRCUIT DIAGNOSIS >

## B0091 FRONT SIDE AIR BAG SATELLITE SENSOR LH

DTC Description

INFOID:0000000011219735

DTC DETECTION LOGIC

- A
- B
- C
- D
- E
- F
- G
- SRC
- I
- J
- K
- L
- M
- N
- O
- P

# B0091 FRONT SIDE AIR BAG SATELLITE SENSOR LH

< DTC/CIRCUIT DIAGNOSIS >

DTC	CONSULT name	DTC detecting condition	
B0091	B-PILLAR SAT SEN LH [RESET]	93	Diagnosis condition
			When ignition switch is ON.
			Signal (terminal)
			Front side air bag satellite sensor LH (terminals 1 and 2)
	B-PILLAR SAT SEN LH [COMM ERR]	81	Threshold
			—
			Diagnosis delay time
			—
	B-PILLAR SAT SEN LH [OPEN]	88	Diagnosis condition
			When ignition switch is ON.
			Signal (terminal)
			Front side air bag satellite sensor LH (terminals 1 and 2)
	B-PILLAR SAT SEN LH [UNMATCH]	86	Threshold
			—
			Diagnosis delay time
			—
	B-PILLAR SAT SEN LH [OFFSET ERR]	28	Diagnosis condition
			When ignition switch is ON.
			Signal (terminal)
			Front side air bag satellite sensor LH (terminals 1 and 2)
	B-PILLAR SAT SEN LH [SELF-DIAG ERR]	25	Threshold
			—
			Diagnosis delay time
			—
	B-PILLAR SAT SEN LH [LOWER LIMIT ERR]	23	Diagnosis condition
			When ignition switch is ON.
			Signal (terminal)
			Front side air bag satellite sensor LH (terminals 1 and 2)
	B-PILLAR SAT SEN LH [UPPER LIMIT ERR]	24	Threshold
			—
			Diagnosis delay time
			—
	B-PILLAR SAT SEN LH [GND-SHORT]	11	Diagnosis condition
			When ignition switch is ON.
			Signal (terminal)
			Front side air bag satellite sensor LH (terminals 1 and 2)
			Threshold
			—
			Diagnosis delay time
			—



# B0091 FRONT SIDE AIR BAG SATELLITE SENSOR LH

## < DTC/CIRCUIT DIAGNOSIS >

### POSSIBLE CAUSE

#### [RESET], [COMM ERR]

- Connection malfunction of harness or connector
- Internal malfunction of B-pillar satellite sensor LH
- Internal malfunction of air bag diagnosis sensor unit

#### [OPEN]

- Connection malfunction or open circuit of harness or connector
- Internal malfunction of B-pillar satellite sensor LH
- Internal malfunction of air bag diagnosis sensor unit

#### [UNMATCH]

- Air bag diagnosis sensor unit and B-pillar satellite sensor LH is different from part specified

#### [OFFSET ERR], [SELF-DIAG ERR], [LOWER LIMIT ERR], [UPPER LIMIT ERR]

- Internal malfunction of B-pillar satellite sensor LH
- Internal malfunction of air bag diagnosis sensor unit

#### [GND-SHORT]

- Connection malfunction or short circuit to ground of harness or connector
- Internal malfunction of B-pillar satellite sensor LH
- Internal malfunction of air bag diagnosis sensor unit

### FAIL-SAFE

—

## DTC CONFIRMATION PROCEDURE (With CONSULT)

### 1.CHECK SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

#### Is the DTC detected?

YES (Current DTC)>> Refer to [SRC-73, "Diagnosis Procedure"](#).

YES (Past DTC)>> GO TO 2.

NO >> Inspection End.

### 2.ERASE SELF DIAGNOSTIC RESULT

Erase the DTC using CONSULT.

#### Can the DTC be erased?

YES >> Inspection End.

NO >> Refer to [SRC-73, "Diagnosis Procedure"](#).

## DTC CONFIRMATION PROCEDURE (Without CONSULT)

### 1.CHECK SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16, "SRS Operation Check"](#).

#### **NOTE:**

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

#### Is the DTC detected?

YES >> Refer to [SRC-73, "Diagnosis Procedure"](#).

NO >> Inspection End.

## Diagnosis Procedure

INFOID:0000000011219736

### 1.HARNESS CONNECTOR

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal

## B0091 FRONT SIDE AIR BAG SATELLITE SENSOR LH

### < DTC/CIRCUIT DIAGNOSIS >

---

- Loose terminal
- Poor connection

**NOTE:**

All harness connectors should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

Is the inspection result normal?

YES >> GO TO 2.

- NO >> Perform one of the following repairs:
- Visible damage: Replace the harness.
  - Loose terminal: Secure the terminal.
  - Poor connection: Secure the connection.

## 2.CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 3.

NO >> Refer to [GI-42, "Intermittent Incident"](#).

## 3.WIRING HARNESS

---

Check the wiring harness for visible damage.

**NOTE:**

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace the harness.

## 4.CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 5.

NO >> Refer to [GI-42, "Intermittent Incident"](#).

## 5.FRONT SIDE AIR BAG SATELLITE SENSOR LH

---

1. Replace the front side air bag satellite sensor LH. Refer to [SR-27, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 6.

NO >> Clear DTC. Inspection End.

## 6.AIR BAG DIAGNOSIS SENSOR UNIT

---

1. Replace the air bag diagnosis sensor unit. Refer to [SR-29, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 7.

NO >> Clear DTC. Inspection End.

## 7.RELATED HARNESS

---

Replace the related harness.

>> Inspection End.

# B0096 FRONT SIDE AIR BAG SATELLITE SENSOR RH

< DTC/CIRCUIT DIAGNOSIS >

## B0096 FRONT SIDE AIR BAG SATELLITE SENSOR RH

DTC Description

INFOID:0000000011219738

DTC DETECTION LOGIC

A

B

C

D

E

F

G

SRC

I

J

K

L

M

N

O

P

# B0096 FRONT SIDE AIR BAG SATELLITE SENSOR RH

< DTC/CIRCUIT DIAGNOSIS >

DTC	CONSULT name	DTC detecting condition		
B0096	B-PILLAR SAT SEN RH [RESET]	93	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Front side air bag satellite sensor LH (terminals 1 and 2)
			Threshold	—
			Diagnosis delay time	—
	B-PILLAR SAT SEN LH [COMM ERR]	81	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Front side air bag satellite sensor LH (terminals 1 and 2)
			Threshold	—
			Diagnosis delay time	—
	B-PILLAR SAT SEN RH [OPEN]	88	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Front side air bag satellite sensor LH (terminals 1 and 2)
			Threshold	—
			Diagnosis delay time	—
	B-PILLAR SAT SEN RH [UNMATCH]	86	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Front side air bag satellite sensor LH (terminals 1 and 2)
			Threshold	—
			Diagnosis delay time	—
	B-PILLAR SAT SEN RH [OFFSET ERR]	28	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Front side air bag satellite sensor LH (terminals 1 and 2)
			Threshold	—
			Diagnosis delay time	—
	B-PILLAR SAT SEN RH [SELF-DIAG ERR]	25	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Front side air bag satellite sensor LH (terminals 1 and 2)
			Threshold	—
			Diagnosis delay time	—
	B-PILLAR SAT SEN RH [LOWER LIMIT ERR]	23	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Front side air bag satellite sensor LH (terminals 1 and 2)
			Threshold	—
			Diagnosis delay time	—
B-PILLAR SAT SEN RH [UPPER LIMIT ERR]	24	Diagnosis condition	When ignition switch is ON.	
		Signal (terminal)	Front side air bag satellite sensor LH (terminals 1 and 2)	
		Threshold	—	
		Diagnosis delay time	—	
B-PILLAR SAT SEN RH [GND-SHORT]	11	Diagnosis condition	When ignition switch is ON.	
		Signal (terminal)	Front side air bag satellite sensor LH (terminals 1 and 2)	
		Threshold	—	
		Diagnosis delay time	—	

## B0096 FRONT SIDE AIR BAG SATELLITE SENSOR RH

### < DTC/CIRCUIT DIAGNOSIS >

#### POSSIBLE CAUSE

[RESET], [COMM ERR]

- Connection malfunction of harness or connector
- Internal malfunction of front side air bag satellite sensor RH
- Internal malfunction of air bag diagnosis sensor unit

[OPEN]

- Connection malfunction or open circuit of harness or connector
- Internal malfunction of front side air bag satellite sensor RH
- Internal malfunction of air bag diagnosis sensor unit

[UNMATCH]

- Air bag diagnosis sensor unit and front side air bag satellite sensor RH is different from the part specified

[OFFSET ERR], [SELF-DIAG ERR], [LOWER LIMIT ERR], [UPPER LIMIT ERR]

- Internal malfunction of front side air bag satellite sensor RH
- Internal malfunction of air bag diagnosis sensor unit

[OPEN]

- Connection malfunction or short circuit to ground of harness or connector
- Internal malfunction of front side air bag satellite sensor RH
- Internal malfunction of air bag diagnosis sensor unit

#### FAIL-SAFE

—

#### DTC CONFIRMATION PROCEDURE (With CONSULT)

##### 1.CHECK SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

Is the DTC detected?

YES (Current DTC)>> Refer to [SRC-77. "Diagnosis Procedure"](#).

YES (Past DTC)>> GO TO 2.

NO >> Inspection End.

##### 2.ERASE SELF DIAGNOSTIC RESULT

Erase the DTC using CONSULT.

Can the DTC be erased?

YES >> Inspection End.

NO >> Refer to [SRC-77. "Diagnosis Procedure"](#).

#### DTC CONFIRMATION PROCEDURE (Without CONSULT)

##### 1.CHECK SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16. "SRS Operation Check"](#).

#### NOTE:

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

Is the DTC detected?

YES >> Refer to [SRC-77. "Diagnosis Procedure"](#).

NO >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000011219739

##### 1.HARNESS CONNECTOR

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal

## B0096 FRONT SIDE AIR BAG SATELLITE SENSOR RH

### < DTC/CIRCUIT DIAGNOSIS >

---

- Loose terminal
- Poor connection

**NOTE:**

All harness connectors should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

Is the inspection result normal?

YES >> GO TO 2.

- NO >> Perform one of the following repairs:
- Visible damage: Replace the harness.
  - Loose terminal: Secure the terminal.
  - Poor connection: Secure the connection.

## 2.CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 3.

NO >> Refer to [GI-42, "Intermittent Incident"](#).

## 3.WIRING HARNESS

---

Check the wiring harness for visible damage.

**NOTE:**

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace the harness.

## 4.CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 5.

NO >> Refer to [GI-42, "Intermittent Incident"](#).

## 5.FRONT SIDE AIR BAG SATELLITE SENSOR RH

---

1. Replace the front side air bag satellite sensor RH. Refer to [SR-27, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 6.

NO >> Clear DTC. Inspection End.

## 6.AIR BAG DIAGNOSIS SENSOR UNIT

---

1. Replace the air bag diagnosis sensor unit. Refer to [SR-29, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 7.

NO >> Clear DTC. Inspection End.

## 7.RELATED HARNESS

---

Replace the related harness.

>> Inspection End.

# B0092 REAR SIDE AIR BAG SATELLITE SENSOR LH

< DTC/CIRCUIT DIAGNOSIS >

## B0092 REAR SIDE AIR BAG SATELLITE SENSOR LH

### DTC Description

INFOID:0000000011219741

### DTC DETECTION LOGIC

DTC	CONSULT name	DTC detecting condition		
B0092	C-PILLAR SAT SEN LH [RESET]	93	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Rear side air bag satellite sensor LH (terminal 1 and 2)
			Threshold	—
			Diagnosis delay time	—
	C-PILLAR SAT SEN LH [COMM ERR]	81	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Rear side air bag satellite sensor LH (terminal 1 and 2)
			Threshold	—
			Diagnosis delay time	—
	C-PILLAR SAT SEN LH [DISCONNECT]	88	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Rear side air bag satellite sensor LH (terminal 1 and 2)
			Threshold	—
			Diagnosis delay time	—
	C-PILLAR SAT SEN LH [UNMATCH]	86	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Rear side air bag satellite sensor LH (terminal 1 and 2)
			Threshold	—
			Diagnosis delay time	—
	C-PILLAR SAT SEN LH [OFFSET ERR]	28	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Rear side air bag satellite sensor LH (terminal 1 and 2)
			Threshold	—
			Diagnosis delay time	—
	C-PILLAR SAT SEN LH [SELF-DIAG ERR]	25	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Rear side air bag satellite sensor LH (terminal 1 and 2)
			Threshold	—
			Diagnosis delay time	—
	C-PILLAR SAT SEN LH [LOWER LIMIT ERR]	23	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Rear side air bag satellite sensor LH (terminal 1 and 2)
			Threshold	—
			Diagnosis delay time	—
	C-PILLAR SAT SEN LH [UPPER LIMIT ERR]	24	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Rear side air bag satellite sensor LH (terminal 1 and 2)
			Threshold	—
			Diagnosis delay time	—

## B0092 REAR SIDE AIR BAG SATELLITE SENSOR LH

### < DTC/CIRCUIT DIAGNOSIS >

DTC	CONSULT name	DTC detecting condition		
B0092	C-PILLAR SAT SEN LH [GND-SHORT]	11	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Rear side air bag satellite sensor LH (terminal 1 and 2)
			Threshold	—
			Diagnosis delay time	—

### POSSIBLE CAUSE

#### [RESET], [COMM ERR]

- Connection malfunction of harness or connector
- Internal malfunction of C-pillar satellite sensor LH
- Internal malfunction of air bag diagnosis sensor unit

#### [OPEN], [DISCONNECT]

- Connection malfunction or open circuit of harness or connector
- Internal malfunction of C-pillar satellite sensor LH
- Internal malfunction of air bag diagnosis sensor unit

#### [UNMATCH]

- Air bag diagnosis sensor unit and C-pillar satellite sensor LH is different from the part specified

#### [OFFSET ERR], [SELF-DIAG ERR], [LOWER LIMIT ERR], [UPPER LIMIT ERR]

- Internal malfunction of C-pillar satellite sensor LH
- Internal malfunction of air bag diagnosis sensor unit

#### [GND-SHORT]

- Connection malfunction or short circuit to ground of harness or connector
- Internal malfunction of C-pillar satellite sensor LH
- Internal malfunction of air bag diagnosis sensor unit

### FAIL-SAFE

—

### DTC CONFIRMATION PROCEDURE (With CONSULT)

#### 1. CHECK SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

#### Is the DTC detected?

- YES (Current DTC)>> Refer to [SRC-81, "Diagnosis Procedure"](#).  
YES (Past DTC)>> GO TO 2.  
NO >> Inspection End.

#### 2. ERASE SELF DIAGNOSTIC RESULT

Erase the DTC using CONSULT.

#### Can the DTC be erased?

- YES >> Inspection End.  
NO >> Refer to [SRC-81, "Diagnosis Procedure"](#).

### DTC CONFIRMATION PROCEDURE (Without CONSULT)

#### 1. CHECK SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16, "SRS Operation Check"](#).

#### NOTE:



# B0092 REAR SIDE AIR BAG SATELLITE SENSOR LH

## < DTC/CIRCUIT DIAGNOSIS >

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

### Is the DTC detected?

- YES >> Refer to [SRC-81, "Diagnosis Procedure"](#).  
NO >> Inspection End.

## Diagnosis Procedure

INFOID:0000000011219742

### 1. HARNESS CONNECTOR

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

#### **NOTE:**

All harness connectors should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

### Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Perform one of the following repairs:
  - Visible damage: Replace the harness.
  - Loose terminal: Secure the terminal.
  - Poor connection: Secure the connection.

### 2. CONFIRM DTC

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

### Is DTC still current?

- YES >> GO TO 3.  
NO >> Refer to [GI-42, "Intermittent Incident"](#).

### 3. WIRING HARNESS

Check the wiring harness for visible damage.

#### **NOTE:**

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

### Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Replace the harness.

### 4. CONFIRM DTC

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

### Is DTC still current?

- YES >> GO TO 5.  
NO >> Refer to [GI-42, "Intermittent Incident"](#).

### 5. REAR SIDE AIR BAG SATELLITE SENSOR LH

1. Replace the rear side air bag satellite sensor LH. Refer to [SR-27, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

### Is DTC still current?

- YES >> GO TO 6.  
NO >> Clear DTC. Inspection End.

### 6. AIR BAG DIAGNOSIS SENSOR UNIT

## B0092 REAR SIDE AIR BAG SATELLITE SENSOR LH

### < DTC/CIRCUIT DIAGNOSIS >

---

1. Replace the air bag diagnosis sensor unit. Refer to [SR-29. "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

#### Is DTC still current?

- YES    >> GO TO 7.  
NO     >> Clear DTC. Inspection End.

### **7**.RELATED HARNESS

---

Replace the related harness.

>> Inspection End.

**B0097 REAR SIDE AIR BAG SATELLITE SENSOR RH**

< DTC/CIRCUIT DIAGNOSIS >

**B0097 REAR SIDE AIR BAG SATELLITE SENSOR RH**

DTC Description

INFOID:0000000011219744

DTC DETECTION LOGIC

- A
- B
- C
- D
- E
- F
- G
- SRC
- I
- J
- K
- L
- M
- N
- O
- P

# B0097 REAR SIDE AIR BAG SATELLITE SENSOR RH

< DTC/CIRCUIT DIAGNOSIS >

DTC	CONSULT name		DTC detecting condition	
B0097	C-PILLAR SAT SEN RH [RESET]	93	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Rear side air bag satellite sensor RH (terminal 1 and 2)
			Threshold	—
			Diagnosis delay time	—
	C-PILLAR SAT SEN RH [COMM ERR]	81	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Rear side air bag satellite sensor RH (terminal 1 and 2)
			Threshold	—
			Diagnosis delay time	—
	C-PILLAR SAT SEN RH [OPEN]	88	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Rear side air bag satellite sensor RH (terminal 1 and 2)
			Threshold	—
			Diagnosis delay time	—
	C-PILLAR SAT SEN RH [UNMATCH]	86	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Rear side air bag satellite sensor RH (terminal 1 and 2)
			Threshold	—
			Diagnosis delay time	—
	C-PILLAR SAT SEN RH [OFFSET ERR]	28	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Rear side air bag satellite sensor RH (terminal 1 and 2)
			Threshold	—
			Diagnosis delay time	—
	C-PILLAR SAT SEN RH [SELF-DIAG ERR]	25	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Rear side air bag satellite sensor RH (terminal 1 and 2)
			Threshold	—
			Diagnosis delay time	—
	C-PILLAR SAT SEN RH [LOWER LIMIT ERR]	23	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Rear side air bag satellite sensor RH (terminal 1 and 2)
			Threshold	—
			Diagnosis delay time	—
	C-PILLAR SAT SEN RH [UPPER LIMIT ERR]	24	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Rear side air bag satellite sensor RH (terminal 1 and 2)
			Threshold	—
			Diagnosis delay time	—
	C-PILLAR SAT SEN RH [GND-SHORT]	11	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Rear side air bag satellite sensor RH (terminal 1 and 2)
			Threshold	—
			Diagnosis delay time	—

POSSIBLE CAUSE

# B0097 REAR SIDE AIR BAG SATELLITE SENSOR RH

## < DTC/CIRCUIT DIAGNOSIS >

### [RESET], [COMM ERR]

- Connection malfunction of harness or connector
- Internal malfunction of rear side air bag satellite sensor RH
- Internal malfunction of air bag diagnosis sensor unit

### [OPEN]

- Connection malfunction or open circuit of harness or connector
- Internal malfunction of rear side air bag satellite sensor RH
- Internal malfunction of air bag diagnosis sensor unit

### [UNMATCH]

- Air bag diagnosis sensor unit and rear side air bag satellite sensor RH is different from the part specified

### [OFFSET ERR], [SELF-DIAG ERR], [LOWER LIMIT ERR], [UPPER LIMIT ERR]

- Internal malfunction of rear side air bag sensor RH
- Internal malfunction of air bag diagnosis sensor unit

### [GND-SHORT]

- Connection malfunction or short circuit to ground of harness and connector
- Internal malfunction of rear side air bag satellite sensor RH
- Internal malfunction of air bag diagnosis sensor unit

### FAIL-SAFE

—

## DTC CONFIRMATION PROCEDURE (With CONSULT)

### 1.CHECK SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

#### Is the DTC detected?

YES (Current DTC)>> Refer to [SRC-85, "Diagnosis Procedure"](#).

YES (Past DTC)>> GO TO 2.

NO >> Inspection End.

### 2.ERASE SELF DIAGNOSTIC RESULT

Erase the DTC using CONSULT.

#### Can the DTC be erased?

YES >> Inspection End.

NO >> Refer to [SRC-85, "Diagnosis Procedure"](#).

## DTC CONFIRMATION PROCEDURE (Without CONSULT)

### 1.CHECK SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16, "SRS Operation Check"](#).

#### **NOTE:**

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

#### Is the DTC detected?

YES >> Refer to [SRC-85, "Diagnosis Procedure"](#).

NO >> Inspection End.

## Diagnosis Procedure

INFOID:0000000011219745

### 1.HARNESS CONNECTOR

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal

## B0097 REAR SIDE AIR BAG SATELLITE SENSOR RH

### < DTC/CIRCUIT DIAGNOSIS >

---

- Loose terminal
- Poor connection

**NOTE:**

All harness connectors should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

Is the inspection result normal?

YES >> GO TO 2.

- NO >> Perform one of the following repairs:
- Visible damage: Replace the harness.
  - Loose terminal: Secure the terminal.
  - Poor connection: Secure the connection.

## 2.CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 3.

NO >> Refer to [GI-42, "Intermittent Incident"](#).

## 3.WIRING HARNESS

---

Check the wiring harness for visible damage.

**NOTE:**

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace the harness.

## 4.CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 5.

NO >> Refer to [GI-42, "Intermittent Incident"](#).

## 5.REAR SIDE AIR BAG SATELLITE SENSOR RH

---

1. Replace the rear side air bag satellite sensor RH. Refer to [SR-27, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 6.

NO >> Clear DTC. Inspection End.

## 6.AIR BAG DIAGNOSIS SENSOR UNIT

---

1. Replace the air bag diagnosis sensor unit. Refer to [SR-29, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 7.

NO >> Clear DTC. Inspection End.

## 7.RELATED HARNESS

---

Replace the related harness.

>> **END**

## B0093 FRONT DOOR SATELLITE SENSOR LH

< DTC/CIRCUIT DIAGNOSIS >

### B0093 FRONT DOOR SATELLITE SENSOR LH

DTC Description

INFOID:0000000011219747

DTC DETECTION LOGIC

A

B

C

D

E

F

G

SRC

I

J

K

L

M

N

O

P

# B0093 FRONT DOOR SATELLITE SENSOR LH

< DTC/CIRCUIT DIAGNOSIS >

DTC	CONSULT name	DTC detecting condition		
B0093	DOOR SATEL SENS LH [RESET]	93	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Front door satellite sensor LH (terminal 1 and 2)
			Threshold	—
			Diagnosis delay time	—
	DOOR SATEL SENS LH [COMM ERR]	81	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Front door satellite sensor LH (terminal 1 and 2)
			Threshold	—
			Diagnosis delay time	—
	DOOR SATEL SENS LH [OPEN]	88	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Front door satellite sensor LH (terminal 1 and 2)
			Threshold	—
			Diagnosis delay time	—
	DOOR SATEL SENS LH [UNMATCH]	86	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Front door satellite sensor LH (terminal 1 and 2)
			Threshold	—
			Diagnosis delay time	—
	DOOR SATEL SENS LH [OFFSET ERR]	28	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Front door satellite sensor LH (terminal 1 and 2)
			Threshold	—
			Diagnosis delay time	—
	DOOR SATEL SENS LH [SELF-DIAG ERR]	25	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Front door satellite sensor LH (terminal 1 and 2)
			Threshold	—
			Diagnosis delay time	—
	DOOR SATEL SENS LH [LOWER LIMIT ERR]	23	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Front door satellite sensor LH (terminal 1 and 2)
			Threshold	—
			Diagnosis delay time	—
	DOOR SATEL SENS LH [UPPER LIMIT ERR]	24	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Front door satellite sensor LH (terminal 1 and 2)
			Threshold	—
			Diagnosis delay time	—
	DOOR SATEL SENS LH [GND-SHORT]	11	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Front door satellite sensor LH (terminal 1 and 2)
			Threshold	—
			Diagnosis delay time	—

POSSIBLE CAUSE



## B0093 FRONT DOOR SATELLITE SENSOR LH

### < DTC/CIRCUIT DIAGNOSIS >

#### [RESET], [COMM ERR]

- Connection malfunction of harness or connector
- Internal malfunction of front door satellite sensor LH
- Internal malfunction of air bag diagnosis sensor unit

#### [OPEN]

- Connection malfunction or open circuit of harness or connector
- Internal malfunction of front door satellite sensor LH
- Internal malfunction of air bag diagnosis sensor unit

#### [UNMATCH]

- Air bag diagnosis sensor unit and front door satellite sensor LH is different from the part specified

#### [OFFSET ERR], [SELF-DIAG ERR], [LOWER LIMIT ERR], [UPPER LIMIT ERR]

- Internal malfunction of front door satellite sensor LH
- Internal malfunction of air bag diagnosis sensor unit

#### FAIL-SAFE

—

### DTC CONFIRMATION PROCEDURE (With CONSULT)

#### 1.CHECK SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

##### Is the DTC detected?

YES (Current DTC)>> Refer to [SRC-89. "Diagnosis Procedure"](#).

YES (Past DTC)>> GO TO 2.

NO >> Inspection End.

#### 2.ERASE SELF DIAGNOSTIC RESULT

Erase the DTC using CONSULT.

##### Can the DTC be erased?

YES >> Inspection End.

NO >> Refer to [SRC-89. "Diagnosis Procedure"](#).

### DTC CONFIRMATION PROCEDURE (Without CONSULT)

#### 1.CHECK SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16. "SRS Operation Check"](#).

##### **NOTE:**

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

##### Is the DTC detected?

YES >> Refer to [SRC-89. "Diagnosis Procedure"](#).

NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000011219748

#### 1.HARNESS CONNECTOR

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

##### **NOTE:**

All harness connectors should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

##### Is the inspection result normal?

YES >> GO TO 2.

## B0093 FRONT DOOR SATELLITE SENSOR LH

### < DTC/CIRCUIT DIAGNOSIS >

---

- NO >> Perform one of the following repairs:
- Visible damage: Replace the harness.
  - Loose terminal: Secure the terminal.
  - Poor connection: Secure the connection.

### 2.CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

#### Is DTC still current?

- YES >> GO TO 3.  
NO >> Refer to [GI-42, "Intermittent Incident"](#).

### 3.WIRING HARNESS

---

Check the wiring harness for visible damage.

#### **NOTE:**

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

#### Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Replace the harness.

### 4.CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

#### Is DTC still current?

- YES >> GO TO 5.  
NO >> Refer to [GI-42, "Intermittent Incident"](#).

### 5.FRONT DOOR SATELLITE SENSOR LH

---

1. Replace the front door satellite sensor LH. Refer to [SR-27, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

#### Is DTC still current?

- YES >> GO TO 6.  
NO >> Clear DTC. Inspection End.

### 6.AIR BAG DIAGNOSIS SENSOR UNIT

---

1. Replace the air bag diagnosis sensor unit. Refer to [SR-29, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

#### Is DTC still current?

- YES >> GO TO 7.  
NO >> Clear DTC. Inspection End.

### 7.RELATED HARNESS

---

Replace the related harness.

>> Inspection End.

## B0098 FRONT DOOR SATELLITE SENSOR RH

< DTC/CIRCUIT DIAGNOSIS >

---

### B0098 FRONT DOOR SATELLITE SENSOR RH

DTC Description

INFOID:0000000011219750

DTC DETECTION LOGIC

A

B

C

D

E

F

G

SRC

I

J

K

L

M

N

O

P

# B0098 FRONT DOOR SATELLITE SENSOR RH

< DTC/CIRCUIT DIAGNOSIS >

DTC	CONSULT name	DTC detecting condition	
B0098	DOOR SATEL SENS RH [RESET]	93	Diagnosis condition
			When ignition switch is ON.
			Signal (terminal)
			Front door satellite sensor RH (Terminal 1 and 2)
	DOOR SATEL SENS RH [COMM ERR]	81	Threshold
			—
			Diagnosis delay time
			—
	DOOR SATEL SENS RH [OPEN]	88	Diagnosis condition
			When ignition switch is ON.
			Signal (terminal)
			Front door satellite sensor RH (Terminal 1 and 2)
	DOOR SATEL SENS RH [UNMATCH]	86	Threshold
			—
			Diagnosis delay time
			—
	DOOR SATEL SENS RH [OFFSET ERR]	28	Diagnosis condition
			When ignition switch is ON.
			Signal (terminal)
			Front door satellite sensor RH (Terminal 1 and 2)
	DOOR SATEL SENS RH [SELF-DIAG ERR]	25	Threshold
			—
			Diagnosis delay time
			—
	DOOR SATEL SENS RH [LOWER LIMIT ERR]	23	Diagnosis condition
			When ignition switch is ON.
			Signal (terminal)
			Front door satellite sensor RH (Terminal 1 and 2)
	DOOR SATEL SENS RH [UPPER LIMIT ERR]	24	Threshold
			—
			Diagnosis delay time
			—
	DOOR SATEL SENS RH [GND-SHORT]	11	Diagnosis condition
			When ignition switch is ON.
			Signal (terminal)
			Front door satellite sensor RH (Terminal 1 and 2)
			Threshold
			—
			Diagnosis delay time
			—

POSSIBLE CAUSE

## B0098 FRONT DOOR SATELLITE SENSOR RH

### < DTC/CIRCUIT DIAGNOSIS >

#### [RESET], [COMM ERR]

- Connection malfunction of harness or connector
- Internal malfunction of front door satellite sensor RH
- Internal malfunction of air bag diagnosis sensor unit

#### [OPEN]

- Connection malfunction or open circuit of harness or connector
- Internal malfunction of front door satellite sensor RH
- Internal malfunction of air bag diagnosis sensor unit

#### [UNMATCH]

- Air bag diagnosis sensor unit and front door satellite sensor RH is different from the part specified

#### [OFFSET ERR], [SELF-DIAD ERR], [LOWER LIMIT ERR], [UPPER LIMIT ERR]

- Internal malfunction of front door satellite sensor RH
- Internal malfunction of air bag diagnosis sensor unit

#### [GND-SHORT]

- Connection malfunction or short circuit to ground of harness and connector
- Internal malfunction of front door satellite sensor RH
- Internal malfunction of air bag diagnosis sensor unit

#### FAIL-SAFE

—

### DTC CONFIRMATION PROCEDURE (With CONSULT)

#### 1.CHECK SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

##### Is the DTC detected?

YES (Current DTC)>> Refer to [SRC-93. "Diagnosis Procedure"](#).

YES (Past DTC)>> GO TO 2.

NO >> Inspection End.

#### 2.ERASE SELF DIAGNOSTIC RESULT

Erase the DTC using CONSULT.

##### Can the DTC be erased?

YES >> Inspection End.

NO >> Refer to [SRC-93. "Diagnosis Procedure"](#).

### DTC CONFIRMATION PROCEDURE (Without CONSULT)

#### 1.CHECK SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16. "SRS Operation Check"](#).

##### **NOTE:**

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

##### Is the DTC detected?

YES >> Refer to [SRC-93. "Diagnosis Procedure"](#).

NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000011219751

#### 1.HARNESS CONNECTOR

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal

## B0098 FRONT DOOR SATELLITE SENSOR RH

### < DTC/CIRCUIT DIAGNOSIS >

---

- Poor connection

**NOTE:**

All harness connectors should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Perform one of the following repairs:

- Visible damage: Replace the harness.
- Loose terminal: Secure the terminal.
- Poor connection: Secure the connection.

## 2.CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 3.

NO >> Refer to [GI-42, "Intermittent Incident"](#).

## 3.WIRING HARNESS

---

Check the wiring harness for visible damage.

**NOTE:**

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace the harness.

## 4.CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 5.

NO >> Refer to [GI-42, "Intermittent Incident"](#).

## 5.FRONT DOOR SATELLITE SENSOR RH

---

1. Replace the front door satellite sensor RH. Refer to [SR-27, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 6.

NO >> Clear DTC. Inspection End.

## 6.AIR BAG DIAGNOSIS SENSOR UNIT

---

1. Replace the air bag diagnosis sensor unit. Refer to [SR-29, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 7.

NO >> Clear DTC. Inspection End.

## 7.RELATED HARNESS

---

Replace the related harness.

>> Inspection End.

# B00A0 OCCUPANT CLASSIFICATION SYSTEM CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

## B00A0 OCCUPANT CLASSIFICATION SYSTEM CONTROL UNIT

### Description

INFOID:0000000011734952

### DTC B00A0 OCCUPANT CLASSIFICATION SYSTEM (OCS)

The OCS control unit is wired to the air bag diagnosis sensor unit. The air bag diagnosis sensor unit will monitor the OCS for failures and interruptions in communication between the OCS control unit and the air bag diagnosis sensor unit.

### PART LOCATION

Refer to [SRC-5, "Component Parts Location"](#).

### DTC Description

INFOID:0000000011734953

### DTC DETECTION LOGIC

DTC	CONSULT screen items (Trouble diagnosis content)		DTC detecting condition
B00A0-00	OCCUPANT SENS [Occupant Classification System (Subfault)]	[ABNORMAL VOLTAGE]	Power supply malfunction of occupant detection sensor
B00A0-02		[UNIT MALFUNC]	Malfunction of occupant detection sensor
B00A0-09		[UNIT MALFUNC]	Malfunction of occupant detection sensor
B00A0-04	OCCUPANT SENS C/U [Occupant Classification System (Subfault)]	[UNIT MALFUNC]	Malfunction of occupant detection sensor control unit
B00A0-83		[COMM ERR]	• Communication malfunction of occupant detection sensor control unit • Communication blank of occupant detection sensor control unit
B00A0-86		[COMM ERR]	• Communication malfunction of occupant detection sensor control unit • Communication blank of occupant detection sensor control unit
B00A0-87		[COMM ERR]	• Communication malfunction of occupant detection sensor control unit • Communication blank of occupant detection sensor control unit
B00A0-88		[COMM ERR]	• Communication malfunction of occupant detection sensor control unit • Communication blank of occupant detection sensor control unit
B00A0-8F		[UNDEFINED]	Undefined status of occupant detection sensor control unit
B00A0-93		[RESET]	Reset malfunction of occupant detection sensor control unit

### DTC CONFIRMATION PROCEDURE (With CONSULT)

#### 1.CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check the DTC using CONSULT.

#### Is the DTC detected?

YES (Current DTC)>>Refer to:

- B00A0-00, -02 or -09: [SRC-96, "Diagnosis Procedure \(B00A0-00, -02 or -09\)"](#)
- B00A0-04: [SRC-97, "Diagnosis Procedure \(B00A0-04\)"](#)
- B00A0-83, -86, -87, -88 or -8F: [SRC-98, "Diagnosis Procedure \(B00A0-83, -86, -87, -88 or -8F\)"](#)
- B00A0-93: [SRC-99, "Diagnosis Procedure \(B00A0-93\)"](#)

YES (Past DTC)>>GO TO 2.

NO >> Inspection End.

#### 2.ERASE SELF-DIAG RESULT

Erase the DTC using CONSULT.

# B00A0 OCCUPANT CLASSIFICATION SYSTEM CONTROL UNIT

## < DTC/CIRCUIT DIAGNOSIS >

---

### Can the DTC be erased?

- YES >> Inspection End.
- NO >> Refer to:
- B00A0-00, -02 or -09: [SRC-96, "Diagnosis Procedure \(B00A0-00, -02 or -09\)"](#)
  - B00A0-04: [SRC-97, "Diagnosis Procedure \(B00A0-04\)"](#)
  - B00A0-83, -86, -87, -88 or -8F: [SRC-98, "Diagnosis Procedure \(B00A0-83, -86, -87, -88 or -8F\)"](#)
  - B00A0-93: [SRC-99, "Diagnosis Procedure \(B00A0-93\)"](#)

## DTC CONFIRMATION PROCEDURE (Without CONSULT)

### 1. CHECK SELF-DIAG RESULT

---

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16, "SRS Operation Check"](#).

#### **NOTE:**

SRS does not enter the diagnosis mode if no malfunction is detected in the user mode.

### Is the DTC detected?

- YES >> Refer to:
- B00A0-00, -02 or -09: [SRC-96, "Diagnosis Procedure \(B00A0-00, -02 or -09\)"](#)
  - B00A0-04: [SRC-97, "Diagnosis Procedure \(B00A0-04\)"](#)
  - B00A0-83, -86, -87, -88 or -8F: [SRC-98, "Diagnosis Procedure \(B00A0-83, -86, -87, -88 or -8F\)"](#)
  - B00A0-93: [SRC-99, "Diagnosis Procedure \(B00A0-93\)"](#)
- NO >> Inspection End.

## Diagnosis Procedure (B00A0-00, -02 or -09)

INFOID:000000011734954

### 1. HARNESS CONNECTOR

---

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

#### **NOTE:**

All harness connectors should be inspected from the air bag diagnosis unit to the end component (including any in-line connectors)

### Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Perform the following repairs. Then, GO TO 2.
- Visible damage: Replace the harness.
  - Loose terminal: Secure the terminal.
  - Poor connection: Secure the connection.

### 2. CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

### Is DTC still current?

- YES >> GO TO 3.
- NO >> Clear DTC and perform zero point reset. Refer to [SRC-44, "ZERO POINT RESET : Description"](#).

### 3. REPLACE OCS CONTROL UNIT AND SENSORS

---

1. Replace the OCS control unit and sensors. Refer to [SR-33, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

### Is DTC still current?

- YES >> GO TO 4.
- NO >> Clear DTC and perform zero point reset. Refer to [SRC-44, "ZERO POINT RESET : Description"](#).

### 4. AIR BAG DIAGNOSIS SENSOR UNIT

---

1. Replace the air bag diagnosis sensor unit. Refer to [SR-29, "Removal and Installation"](#).
2. Turn ignition switch ON.



# B00A0 OCCUPANT CLASSIFICATION SYSTEM CONTROL UNIT

## < DTC/CIRCUIT DIAGNOSIS >

3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 5.

NO >> Clear DTC and perform zero point reset. Refer to [SRC-44, "ZERO POINT RESET : Description"](#).

## 5.RELATED HARNESS

1. Replace the related harnesses (OCS sensors to OCS control unit, OCS control unit to seat, seat to main harness, main harness to air bag diagnosis sensor unit).

2. Turn ignition switch ON.

3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 6.

NO >> Clear DTC and perform zero point reset. Refer to [SRC-44, "ZERO POINT RESET : Description"](#).

## 6.REPLACE PASSENGER SEAT CUSHION FRAME

1. Replace the passenger seat cushion frame. Refer to [SE-164, "Seat Cushion"](#).

2. Clear DTC and perform zero point reset. Refer to [SRC-44, "ZERO POINT RESET : Description"](#).

>> Inspection End.

## Diagnosis Procedure (B00A0-04)

INFOID:0000000011734955

## 1.HARNESS CONNECTOR

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

### NOTE:

All harness connectors should be inspected from the air bag diagnosis unit to the end component (including any in-line connectors)

Is the inspection result normal?

YES >> GO TO 3.

NO >> Perform the following repairs. Then, GO TO 2.

- Visible damage: Replace the harness.
- Loose terminal: Secure the terminal.
- Poor connection: Secure the connection.

## 2.CONFIRM DTC

1. Reconnect all harness connectors.

2. Turn ignition switch ON.

3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 3.

NO >> Clear DTC and perform zero point reset. Refer to [SRC-44, "ZERO POINT RESET : Description"](#).

## 3.REPLACE OCS CONTROL UNIT

1. Replace the OCS control unit. Refer to [SR-33, "Removal and Installation"](#).

2. Turn ignition switch ON.

3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 4.

NO >> Clear DTC and perform zero point reset. Refer to [SRC-44, "ZERO POINT RESET : Description"](#).

## 4.AIR BAG DIAGNOSIS SENSOR UNIT

1. Replace the air bag diagnosis sensor unit. Refer to [SR-29, "Removal and Installation"](#).

2. Turn ignition switch ON.

3. Check for DTC using CONSULT.

Is DTC still current?

## B00A0 OCCUPANT CLASSIFICATION SYSTEM CONTROL UNIT

### < DTC/CIRCUIT DIAGNOSIS >

---

YES >> GO TO 5.

NO >> Clear DTC and perform zero point reset. Refer to [SRC-44, "ZERO POINT RESET : Description"](#).

### 5. RELATED HARNESS

---

1. Replace the related harnesses (OCS sensors to OCS control unit, OCS control unit to seat, seat to main harness, main harness to air bag diagnosis sensor unit)
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

#### Is DTC still current?

YES >> GO TO 6.

NO >> Clear DTC and perform zero point reset. Refer to [SRC-44, "ZERO POINT RESET : Description"](#).

### 6. REPLACE OCS SENSORS

---

1. Replace the OCS sensors. Refer to [SR-33, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

#### Is DTC still current?

YES >> GO TO 7.

NO >> Clear DTC and perform zero point reset. Refer to [SRC-44, "ZERO POINT RESET : Description"](#).

### 7. REPLACE PASSENGER SEAT CUSHION FRAME

---

1. Replace the passenger seat cushion frame. Refer to [SE-164, "Seat Cushion"](#).
2. Clear DTC and perform zero point reset. Refer to [SRC-44, "ZERO POINT RESET : Description"](#).

>> Inspection End.

## Diagnosis Procedure (B00A0-83, -86, -87, -88 or -8F)

INFOID:0000000011734956

### 1. HARNESS CONNECTOR

---

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

#### **NOTE:**

All harness connectors should be inspected from the air bag diagnosis unit to the end component (including any in-line connectors)

#### Is the inspection result normal?

YES >> GO TO 3.

NO >> Perform the following repairs. Then, GO TO 2.

- Visible damage: Replace the harness.
- Loose terminal: Secure the terminal.
- Poor connection: Secure the connection.

### 2. CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

#### Is DTC still current?

YES >> GO TO 3.

NO >> Clear DTC and perform zero point reset. Refer to [SRC-44, "ZERO POINT RESET : Description"](#).

### 3. REPLACE OCS CONTROL UNIT AND SENSORS

---

1. Replace the OCS control unit and sensors. Refer to [SR-33, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

#### Is DTC still current?

YES >> GO TO 4.

NO >> Clear DTC and perform zero point reset. Refer to [SRC-44, "ZERO POINT RESET : Description"](#).

# B00A0 OCCUPANT CLASSIFICATION SYSTEM CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

## 4. AIR BAG DIAGNOSIS SENSOR UNIT

1. Replace the air bag diagnosis sensor unit. Refer to [SR-29, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 5.

NO >> Clear DTC and perform zero point reset. Refer to [SRC-44, "ZERO POINT RESET : Description"](#).

## 5. RELATED HARNESS

1. Replace the related harnesses (OCS sensors to OCS control unit, OCS control unit to seat, seat to main harness, main harness to air bag diagnosis sensor unit).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 6.

NO >> Clear DTC and perform zero point reset. Refer to [SRC-44, "ZERO POINT RESET : Description"](#).

## 6. REPLACE PASSENGER SEAT CUSHION FRAME

1. Replace the passenger seat cushion frame. Refer to [SE-164, "Seat Cushion"](#).
2. Clear DTC and perform zero point reset. Refer to [SRC-44, "ZERO POINT RESET : Description"](#).

>> Inspection End.

## Diagnosis Procedure (B00A0-93)

INFOID:0000000011734957

SRC

## 1. PERFORM ZERO POINT RESET

1. Perform zero point reset. Refer to [SRC-44, "ZERO POINT RESET : Description"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 2.

NO >> Clear DTC. Inspection End.

## 2. HARNESS CONNECTOR

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

### NOTE:

All harness connectors should be inspected from the air bag diagnosis unit to the end component (including any in-line connectors)

Is the inspection result normal?

YES >> GO TO 4.

NO >> Perform the following repairs. Then, GO TO 3.

- Visible damage: Replace the harness.
- Loose terminal: Secure the terminal.
- Poor connection: Secure the connection.

## 3. CONFIRM DTC

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 4.

NO >> Clear DTC and perform zero point reset. Refer to [SRC-44, "ZERO POINT RESET : Description"](#).

## 4. REPLACE OCS CONTROL UNIT

## B00A0 OCCUPANT CLASSIFICATION SYSTEM CONTROL UNIT

### < DTC/CIRCUIT DIAGNOSIS >

---

1. Replace the OCS control unit. Refer to [SR-33, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

#### Is DTC still current?

YES >> GO TO 5.

NO >> Clear DTC and perform zero point reset. Refer to [SRC-44, "ZERO POINT RESET : Description"](#).

### 5. AIR BAG DIAGNOSIS SENSOR UNIT

---

1. Replace the air bag diagnosis sensor unit. Refer to [SR-29, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

#### Is DTC still current?

YES >> GO TO 6.

NO >> Clear DTC and perform zero point reset. Refer to [SRC-44, "ZERO POINT RESET : Description"](#).

### 6. RELATED HARNESS

---

1. Replace the related harnesses (OCS sensors to OCS control unit, OCS control unit to seat, seat to main harness, main harness to air bag diagnosis sensor unit)
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

#### Is DTC still current?

YES >> GO TO 7.

NO >> Clear DTC and perform zero point reset. Refer to [SRC-44, "ZERO POINT RESET : Description"](#).

### 7. REPLACE OCS SENSORS

---

1. Replace the OCS sensors. Refer to [SR-33, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

#### Is DTC still current?

YES >> GO TO 8.

NO >> Clear DTC and perform zero point reset. Refer to [SRC-44, "ZERO POINT RESET : Description"](#).

### 8. REPLACE PASSENGER SEAT CUSHION FRAME

---

1. Replace the passenger seat cushion frame. Refer to [SE-164, "Seat Cushion"](#).
2. Clear DTC and perform zero point reset. Refer to [SRC-44, "ZERO POINT RESET : Description"](#).

>> Inspection End.

# B00D5 PASSENGER AIR BAG OFF INDICATOR

< DTC/CIRCUIT DIAGNOSIS >

## B00D5 PASSENGER AIR BAG OFF INDICATOR

### DTC Description

INFOID:0000000011219756

### DTC DETECTION LOGIC

DTC	CONSULT name	DTC detecting condition		
B00D5	PASS A/B INDCTR CKT [UNIT MALFUNC]	04	Diagnosis condition	When ignition is ON.
			Signal (terminal)	Front passenger air bag OFF indicator is malfunctioning.
			Threshold	—
			Diagnosis delay time	—
	PASS A/B INDCTR CKT [PWR-SHORT/OPEN]	15	Diagnosis condition	When ignition is ON.
			Signal (terminal)	Front passenger air bag OFF indicator is malfunctioning.
			Threshold	—
			Diagnosis delay time	—
	PASS A/B INDCTR CKT [OPEN]	13	Diagnosis condition	When ignition is ON.
			Signal (terminal)	Front passenger air bag OFF indicator is malfunctioning.
			Threshold	—
			Diagnosis delay time	—
	PASS A/B INDCTR CKT [VB-SHORT]	12	Diagnosis condition	When ignition is ON.
			Signal (terminal)	Front passenger air bag OFF indicator is malfunctioning.
			Threshold	—
			Diagnosis delay time	—
	PASS A/B INDCTR CKT [GND-SHORT]	11	Diagnosis condition	When ignition is ON.
			Signal (terminal)	Front passenger air bag OFF indicator is malfunctioning.
			Threshold	—
			Diagnosis delay time	—

### POSSIBLE CAUSE

#### [UNIT MALFUNC]

- Internal malfunction of front passenger air bag OFF indicator
- Internal malfunction of air bag diagnosis sensor unit

#### [PWE-SHORT/OPEN]

- Connection malfunction or short circuit to power supply of harness and connector
- Connection malfunction or open circuit of harness and connector
- Internal malfunction of front passenger air bag OFF indicator
- Internal malfunction of air bag diagnosis sensor unit

#### [OPEN]

- Connection malfunction or open circuit of harness and connector
- Internal malfunction of front passenger air bag OFF indicator
- Internal malfunction of air bag diagnosis sensor unit

#### [VB-SHORT]

- Connection malfunction or short circuit to power supply of harness and connector

# B00D5 PASSENGER AIR BAG OFF INDICATOR

## < DTC/CIRCUIT DIAGNOSIS >

---

- Internal malfunction of front passenger air bag OFF indicator
- Internal malfunction of air bag diagnosis sensor unit

### [GND-SHORT]

- Connection malfunction or short circuit to ground of harness and connector
- Internal malfunction of front passenger air bag OFF indicator
- Internal malfunction of air bag diagnosis sensor unit

## DTC CONFIRMATION PROCEDURE (With CONSULT)

### 1.CHECK SELF DIAGNOSTIC RESULT

---

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

#### Is the DTC detected?

YES (Current DTC)>> Refer to [SRC-102, "Diagnosis Procedure"](#).

YES (Past DTC)>> GO TO 2.

NO >> Inspection End.

### 2.ERASE SELF DIAGNOSTIC RESULT

---

Erase the DTC using CONSULT.

#### Can the DTC be erased?

YES >> Inspection End.

NO >> Refer to [SRC-102, "Diagnosis Procedure"](#).

## DTC CONFIRMATION PROCEDURE (Without CONSULT)

### 1.CHECK SELF DIAGNOSTIC RESULT

---

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16, "SRS Operation Check"](#).

#### **NOTE:**

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

#### Is the DTC detected?

YES >> Refer to [SRC-102, "Diagnosis Procedure"](#).

NO >> Inspection End.

## Diagnosis Procedure

INFOID:0000000011219757

### 1.HARNESS CONNECTOR

---

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

#### **NOTE:**

All harness connectors should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

#### Is the inspection result normal?

YES >> GO TO 2.

NO >> Perform one of the following repairs:

- Visible damage: Replace the harness.
- Loose terminal: Secure the terminal.
- Poor connection: Secure the connection.

### 2.CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

#### Is DTC still current?

YES >> GO TO 3.

## B00D5 PASSENGER AIR BAG OFF INDICATOR

### < DTC/CIRCUIT DIAGNOSIS >

NO >> Refer to [GI-42, "Intermittent Incident"](#).

### 3. WIRING HARNESS

Check the wiring harness for visible damage.

#### NOTE:

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace the harness.

### 4. CONFIRM DTC

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 5.

NO >> Refer to [GI-42, "Intermittent Incident"](#).

### 5. PASSENGER AIR BAG OFF INDICATOR

1. Replace the passenger air bag off indicator.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 6.

NO >> Clear DTC. Inspection End.

### 6. AIR BAG DIAGNOSIS SENSOR UNIT

1. Replace the air bag diagnosis sensor unit. Refer to [SR-29, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 7.

NO >> Clear DTC. Inspection End.

### 7. RELATED HARNESS

Replace the related harness.

>> Inspection End.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

SRC

## B1428 SEAT BELT BUCKLE SWITCH LH

< DTC/CIRCUIT DIAGNOSIS >

### B1428 SEAT BELT BUCKLE SWITCH LH

#### DTC Description

INFOID:0000000011219759

#### DTC DETECTION LOGIC

DTC	CONSULT name	DTC detecting condition		
B1428	BUCKLE SW LH [OPEN]	13	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Seat belt buckle switch LH circuit is open. (terminal 3 and 4).
			Threshold	—
			Diagnosis delay time	—
	BUCKLE SW LH [VB-SHORT]	12	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Seat belt buckle switch LH circuit is short- ed to power. (terminal 3 and 4).
			Threshold	—
			Diagnosis delay time	—
	BUCKLE SW LH [GND-SHORT]	11	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Seat belt buckle switch LH circuit is short- ed to ground (terminal 3 and 4).
			Threshold	—
			Diagnosis delay time	—
	BUCKLE SW LH [UNDEFINED]	00	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Seat belt buckle switch (terminal 3 and 4).
			Threshold	—
			Diagnosis delay time	—

#### POSSIBLE CAUSE

##### [OPEN]

- Connection malfunction or open circuit of harness and connector
- Internal malfunction of seat belt buckle switch LH

##### [VB-SHORT]

- Connection malfunction or short circuit to power supply of harness and connector
- Internal malfunction of seat belt buckle switch LH
- Internal malfunction of diagnosis sensor unit

##### [GND-SHORT]

- Connection malfunction or short circuit to ground of harness and connector
- Internal malfunction of seat belt buckle switch LH
- Internal malfunction of diagnosis sensor unit

##### [UNDEFINED]

- Connection malfunction or open circuit of harness and connector
- Internal malfunction of seat belt buckle switch LH
- Internal malfunction of diagnosis sensor unit

#### FAIL-SAFE

—

#### DTC CONFIRMATION PROCEDURE (With CONSULT)

##### 1. CHECK SELF DIAGNOSTIC RESULT



## B1428 SEAT BELT BUCKLE SWITCH LH

### < DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

#### Is the DTC detected?

YES (Current DTC)>> Refer to [SRC-105, "Diagnosis Procedure"](#).

YES (Past DTC)>> GO TO 2.

NO >> Inspection End.

### 2.ERASE SELF DIAGNOSTIC RESULT

Erase the DTC using CONSULT.

#### Can the DTC be erased?

YES >> Inspection End.

NO >> Refer to [SRC-105, "Diagnosis Procedure"](#).

### DTC CONFIRMATION PROCEDURE (Without CONSULT)

#### 1.CHECK SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16, "SRS Operation Check"](#).

#### **NOTE:**

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

#### Is the DTC detected?

YES >> Refer to [SRC-105, "Diagnosis Procedure"](#).

NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000011219760

SRC

#### 1.HARNESS CONNECTOR

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

#### **NOTE:**

All harness connectors should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

#### Is the inspection result normal?

YES >> GO TO 2.

NO >> Perform one of the following repairs:

- Visible damage: Replace the harness.
- Loose terminal: Secure the terminal.
- Poor connection: Secure the connection.

#### 2.CONFIRM DTC

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

#### Is DTC still current?

YES >> GO TO 3.

NO >> Refer to [GI-42, "Intermittent Incident"](#).

#### 3.WIRING HARNESS

Check the wiring harness for visible damage.

#### **NOTE:**

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

#### Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace the harness.

## B1428 SEAT BELT BUCKLE SWITCH LH

< DTC/CIRCUIT DIAGNOSIS >

---

### 4.CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 5.

NO >> Refer to [GI-42, "Intermittent Incident"](#).

### 5.SEAT BELT BUCKLE SWITCH LH

---

1. Replace the seat belt buckle switch LH. Refer to [SR-32, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 6.

NO >> Clear DTC. Inspection End.

### 6.AIR BAG DIAGNOSIS SENSOR UNIT

---

1. Replace the air bag diagnosis sensor unit. Refer to [SR-29, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 7.

NO >> Clear DTC. Inspection End.

### 7.RELATED HARNESS

---

Replace the related harness.

>> Inspection End.

# B1429 SEAT BELT BUCKLE SWITCH RH

< DTC/CIRCUIT DIAGNOSIS >

## B1429 SEAT BELT BUCKLE SWITCH RH

### DTC Description

INFOID:0000000011219762

### DTC DETECTION LOGIC

DTC	CONSULT name	DTC detecting condition		
B1429	BUCKLE SW RH [OPEN]	13	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Seat belt buckle switch RH circuit is open. (terminal 3 and 4)
			Threshold	—
			Diagnosis delay time	—
B1429	BUCKLE SW RH [VB-SHORT]	12	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Seat belt buckle switch RH circuit is open. (terminal 3 and 4)
			Threshold	—
			Diagnosis delay time	—
B1429	BUCKLE SW RH [GND-SHORT]	11	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Seat belt buckle switch RH circuit is open. (terminal 3 and 4)
			Threshold	—
			Diagnosis delay time	—
B1429	BUCKLE SW RH [UNDEFINED]	00	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Seat belt buckle switch RH circuit is open. (terminal 3 and 4)
			Threshold	—
			Diagnosis delay time	—

### POSSIBLE CAUSE

#### [OPEN]

- Connection malfunction or open circuit of harness and connector
- Internal malfunction of seat belt buckle switch RH

#### [VB-SHORT]

- Connection malfunction or short circuit to power supply of harness and connector
- Internal malfunction of seat belt buckle switch RH
- Internal malfunction of air bag diagnosis sensor unit

#### [GND-SHORT]

- Connection malfunction or short circuit to ground of harness and connector
- Internal malfunction of seat belt buckle switch RH
- Internal malfunction of air bag diagnosis sensor unit

#### [UNDEFINED]

- Connection malfunction or open circuit of harness and connector
- Internal malfunction of seat belt buckle switch RH
- Internal malfunction of air bag diagnosis sensor unit

### FAIL-SAFE

—

### DTC CONFIRMATION PROCEDURE (With CONSULT)

## B1429 SEAT BELT BUCKLE SWITCH RH

### < DTC/CIRCUIT DIAGNOSIS >

---

#### 1. CHECK SELF DIAGNOSTIC RESULT

---

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

##### Is the DTC detected?

YES (Current DTC)>> Refer to [SRC-108, "Diagnosis Procedure"](#).

YES (Past DTC)>> GO TO 2.

NO >> Inspection End.

#### 2. ERASE SELF DIAGNOSTIC RESULT

---

Erase the DTC using CONSULT.

##### Can the DTC be erased?

YES >> Inspection End.

NO >> Refer to [SRC-108, "Diagnosis Procedure"](#).

### DTC CONFIRMATION PROCEDURE (Without CONSULT)

#### 1. CHECK SELF DIAGNOSTIC RESULT

---

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16, "SRS Operation Check"](#).

##### **NOTE:**

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

##### Is the DTC detected?

YES >> Refer to [SRC-108, "Diagnosis Procedure"](#).

NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000011219763

#### 1. HARNESS CONNECTOR

---

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

##### **NOTE:**

All harness connectors should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

##### Is the inspection result normal?

YES >> GO TO 2.

NO >> Perform one of the following repairs:

- Visible damage: Replace the harness.
- Loose terminal: Secure the terminal.
- Poor connection: Secure the connection.

#### 2. CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

##### Is DTC still current?

YES >> GO TO 3.

NO >> Refer to [GI-42, "Intermittent Incident"](#).

#### 3. WIRING HARNESS

---

Check the wiring harness for visible damage.

##### **NOTE:**

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

##### Is the inspection result normal?

YES >> GO TO 4.

## B1429 SEAT BELT BUCKLE SWITCH RH

### < DTC/CIRCUIT DIAGNOSIS >

NO >> Replace the harness.

#### 4.CONFIRM DTC

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

##### Is DTC still current?

YES >> GO TO 5.

NO >> Refer to [GI-42, "Intermittent Incident"](#).

#### 5.SEAT BELT BUCKLE SWITCH RH

1. Replace the seat belt buckle switch RH. Refer to [SR-32, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

##### Is DTC still current?

YES >> GO TO 6.

NO >> Clear DTC. Inspection End.

#### 6.AIR BAG DIAGNOSIS SENSOR UNIT

1. Replace the air bag diagnosis sensor unit. Refer to [SR-29, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

##### Is DTC still current?

YES >> GO TO 7.

NO >> Clear DTC. Inspection End.

#### 7.RELATED HARNESS

Replace the related harness.

>> Inspection End.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

SRC

# B1430 SEAT BELT PRE-TENSIONER

< DTC/CIRCUIT DIAGNOSIS >

## B1430 SEAT BELT PRE-TENSIONER

### DTC Description

INFOID:0000000011219765

### DTC DETECTION LOGIC

DTC	CONSULT name	DTC detecting condition		
B1430	FRONT PRE-TEN LH CIRCUIT [OPEN]	13	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	LH seat belt pre-tensioner circuit is open (shoulder belt) (terminal 1 and 2).
			Threshold	—
			Diagnosis delay time	—
	FRONT PRE-TEN LH CIRCUIT [VB-SHORT]	12	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	LH seat belt pre-tensioner circuit is shorted to a power supply circuit (shoulder belt) (terminal 1 and 2).
			Threshold	—
			Diagnosis delay time	—
	FRONT PRE-TEN LH CIRCUIT [GND-SHORT]	11	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	LH seat belt pre-tensioner circuit is shorted to ground (shoulder belt) (shoulder belt) (terminal 1 and 2).
			Threshold	—
			Diagnosis delay time	—
	FRONT PRE-TEN LH CIRCUIT [SHORT]	09	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	LH seat belt pre-tensioner circuits are shorted to each other (shoulder belt) (terminal 1 and 2).
			Threshold	—
			Diagnosis delay time	—

### POSSIBLE CAUSE

#### [OPEN]

- Connection malfunction or open circuit of harness and connector
- Internal malfunction of seat belt pre-tensioner LH
- Internal malfunction of air bag diagnosis sensor unit

#### [VB-SHORT]

- Connection malfunction or short circuit to power supply of harness and connector
- Internal malfunction of seat belt pre-tensioner LH
- Internal malfunction of air bag diagnosis sensor unit

#### [GND-SHORT]

- Connection malfunction or short circuit to ground of harness and connector
- Internal malfunction of seat belt pre-tensioner LH
- Internal malfunction of air bag diagnosis sensor unit

#### [SHORT]

- Connection malfunction or short circuit of harness and connector
- Internal malfunction of seat belt pre-tensioner LH
- Internal malfunction of air bag diagnosis sensor unit

### FAIL-SAFE

—

# B1430 SEAT BELT PRE-TENSIONER

## < DTC/CIRCUIT DIAGNOSIS >

### DTC CONFIRMATION PROCEDURE (With CONSULT)

#### 1.CHECK SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

##### Is the DTC detected?

YES (Current DTC)>> Refer to [SRC-111, "Diagnosis Procedure"](#).

YES (Past DTC)>> GO TO 2.

NO >> Inspection End.

#### 2.ERASE SELF DIAGNOSTIC RESULT

Erase the DTC using CONSULT.

##### Can the DTC be erased?

YES >> Inspection End.

NO >> Refer to [SRC-111, "Diagnosis Procedure"](#).

### DTC CONFIRMATION PROCEDURE (Without CONSULT)

#### 1.CHECK SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16, "SRS Operation Check"](#).

##### **NOTE:**

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

##### Is the DTC detected?

YES >> Refer to [SRC-111, "Diagnosis Procedure"](#).

NO >> Inspection End.

## Diagnosis Procedure

INFOID:0000000011219766

#### 1.HARNESS CONNECTOR

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

##### **NOTE:**

All harness connectors should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

##### Is the inspection result normal?

YES >> GO TO 2.

- NO >> Perform one of the following repairs:
- Visible damage: Replace the harness.
  - Loose terminal: Secure the terminal.
  - Poor connection: Secure the connection.

#### 2.CONFIRM DTC

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

##### Is DTC still current?

YES >> GO TO 3.

NO >> Refer to [GI-42, "Intermittent Incident"](#).

#### 3.WIRING HARNESS

Check the wiring harness for visible damage.

##### **NOTE:**

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

##### Is the inspection result normal?

## B1430 SEAT BELT PRE-TENSIONER

### < DTC/CIRCUIT DIAGNOSIS >

---

- YES >> GO TO 4.  
NO >> Replace the harness.

### 4.CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

#### Is DTC still current?

- YES >> GO TO 5.  
NO >> Refer to [GI-42, "Intermittent Incident"](#).

### 5.AIR BAG DIAGNOSIS SENSOR UNIT

---

1. Replace the air bag diagnosis sensor unit. Refer to [SR-29, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

#### Is DTC still current?

- YES >> GO TO 6.  
NO >> Clear DTC. Inspection End.

### 6.SEAT BELT PRE-TENSIONER LH

---

1. Replace the seat belt pre-tensioner LH. Refer to [SR-31, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

#### Is DTC still current?

- YES >> GO TO 7.  
NO >> Clear DTC. Inspection End.

### 7.RELATED HARNESS

---

Replace the related harness.

>> Inspection End.



# B1431 SEAT BELT PRE-TENSIONER

< DTC/CIRCUIT DIAGNOSIS >

## B1431 SEAT BELT PRE-TENSIONER

### DTC Description

INFOID:0000000011219768

### DTC DETECTION LOGIC

DTC	CONSULT name	DTC detecting condition		
B1431	FRONT PRE-TEN RH [OPEN]	13	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	RH seat belt pre-tensioner circuit is open (shoulder belt) (terminal 1 and 2).
			Threshold	—
			Diagnosis delay time	—
	FRONT PRE-TEN RH [VB-SHORT]	12	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	RH seat belt pre-tensioner circuit is shorted to a power supply circuit (shoulder belt) (terminal 1 and 2).
			Threshold	—
			Diagnosis delay time	—
	FRONT PRE-TEN RH [GND-SHORT]	11	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	RH seat belt pre-tensioner circuit is shorted to ground (shoulder belt) (terminal 1 and 2).
			Threshold	—
			Diagnosis delay time	—
	FRONT PRE-TEN RH [SHORT]	09	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	RH seat belt pre-tensioner circuits are shorted to each other (shoulder belt) (terminal 1 and 2).
			Threshold	—
			Diagnosis delay time	—

### POSSIBLE CAUSE

#### [OPEN]

- Connection malfunction or open circuit of harness and connector
- Internal malfunction of seat belt pre-tensioner RH
- Internal malfunction of air bag diagnosis sensor unit

#### [VB-SHORT]

- Connection malfunction or short circuit to power supply of harness and connector
- Internal malfunction of seat belt pre-tensioner RH
- Internal malfunction of air bag diagnosis sensor unit

#### [GND-SHORT]

- Connection malfunction or short circuit to ground of harness and connector
- Internal malfunction of seat belt pre-tensioner RH
- Internal malfunction of air bag diagnosis sensor unit

#### [SHORT]

- Connection malfunction or short circuit of harness and connector
- Internal malfunction of seat belt pre-tensioner RH
- Internal malfunction of air bag diagnosis sensor unit

### FAIL-SAFE

# B1431 SEAT BELT PRE-TENSIONER

## < DTC/CIRCUIT DIAGNOSIS >

---

### DTC CONFIRMATION PROCEDURE (With CONSULT)

#### 1. CHECK SELF DIAGNOSTIC RESULT

---

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

##### Is the DTC detected?

YES (Current DTC)>> Refer to [SRC-114, "Diagnosis Procedure"](#).  
YES (Past DTC)>> GO TO 2.  
NO >> Inspection End.

#### 2. ERASE SELF DIAGNOSTIC RESULT

---

Erase the DTC using CONSULT.

##### Can the DTC be erased?

YES >> Inspection End.  
NO >> Refer to [SRC-114, "Diagnosis Procedure"](#).

### DTC CONFIRMATION PROCEDURE (Without CONSULT)

#### 1. CHECK SELF DIAGNOSTIC RESULT

---

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16, "SRS Operation Check"](#).

##### **NOTE:**

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

##### Is the DTC detected?

YES >> Refer to [SRC-114, "Diagnosis Procedure"](#).  
NO >> Inspection End.

## Diagnosis Procedure

INFOID:0000000011219769

#### 1. HARNESS CONNECTOR

---

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

##### **NOTE:**

All harness connectors should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

##### Is the inspection result normal?

YES >> GO TO 2.  
NO >> Perform one of the following repairs:

- Visible damage: Replace the harness.
- Loose terminal: Secure the terminal.
- Poor connection: Secure the connection.

#### 2. CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

##### Is DTC still current?

YES >> GO TO 3.  
NO >> Refer to [GI-42, "Intermittent Incident"](#).

#### 3. WIRING HARNESS

---

Check the wiring harness for visible damage.

##### **NOTE:**

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

## B1431 SEAT BELT PRE-TENSIONER

### < DTC/CIRCUIT DIAGNOSIS >

#### Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Replace the harness.

#### 4.CONFIRM DTC

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

#### Is DTC still current?

- YES >> GO TO 5.  
NO >> Refer to [GI-42, "Intermittent Incident"](#).

#### 5.AIR BAG DIAGNOSIS SENSOR UNIT

1. Replace the air bag diagnosis sensor unit. Refer to [SR-29, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

#### Is DTC still current?

- YES >> GO TO 6.  
NO >> Clear DTC. Inspection End.

#### 6.SEAT BELT PRE-TENSIONER RH

1. Replace the seat belt pre-tensioner RH. Refer to [SR-31, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

#### Is DTC still current?

- YES >> GO TO 7.  
NO >> Clear DTC. Inspection End.

#### 7.RELATED HARNESS

Replace the related harness.

>> Inspection End.

A  
B  
C  
D  
E  
F  
G  
I  
J  
K  
L  
M  
N  
O  
P

SRC

# B1433 LAP PRE-TENSIONER

< DTC/CIRCUIT DIAGNOSIS >

## B1433 LAP PRE-TENSIONER

### DTC Description

INFOID:0000000011219772

### DTC DETECTION LOGIC

DTC	CONSULT name	DTC detecting condition	
B1433	PRE-TEN FRONT RH 2 [OPEN]	13	Diagnosis condition
			When ignition switch is ON.
			Signal (terminal)
			Lap pre-tensioner RH circuit is open.
	PRE-TEN FRONT RH 2 [VB-SHORT]	12	Threshold
			—
			Diagnosis delay time
			—
	PRE-TEN FRONT RH 2 [GND-SHORT]	11	Diagnosis condition
			When ignition switch is ON.
			Signal (terminal)
			Lap pre-tensioner RH circuit is shorted to ground.
	PRE-TEN FRONT RH 2 [SHORT]	1A	Threshold
			—
			Diagnosis delay time
			—

### POSSIBLE CAUSE

#### [OPEN]

- Connection malfunction or open circuit of harness and connector
- Internal malfunction of lap belt pre-tensioner RH
- Internal malfunction of air bag diagnosis sensor unit

#### [VB-SHORT]

- Connection malfunction or short circuit to power supply of harness and connector
- Internal malfunction of lap belt pre-tensioner RH
- Internal malfunction of air bag diagnosis sensor unit

#### [GND-SHORT]

- Connection malfunction or short circuit to ground of harness and connector
- Internal malfunction of lap belt pre-tensioner RH
- Internal malfunction of air bag diagnosis sensor unit

#### [SHORT]

- Connection malfunction or short circuit of harness and connector
- Internal malfunction of lap belt pre-tensioner RH
- Internal malfunction of air bag diagnosis sensor unit

### FAIL-SAFE

—

### DTC CONFIRMATION PROCEDURE (With CONSULT)

# B1433 LAP PRE-TENSIONER

## < DTC/CIRCUIT DIAGNOSIS >

### 1.CHECK SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

#### Is the DTC detected?

YES (Current DTC)>> Refer to [SRC-117, "Diagnosis Procedure"](#).

YES (Past DTC)>> GO TO 2.

NO >> Inspection End.

### 2.ERASE SELF DIAGNOSTIC RESULT

Erase the DTC using CONSULT.

#### Can the DTC be erased?

YES >> Inspection End.

NO >> Refer to [SRC-117, "Diagnosis Procedure"](#).

## DTC CONFIRMATION PROCEDURE (Without CONSULT)

### 1.CHECK SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16, "SRS Operation Check"](#).

#### **NOTE:**

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

#### Is the DTC detected?

YES >> Refer to [SRC-117, "Diagnosis Procedure"](#).

NO >> Inspection End.

## Diagnosis Procedure

INFOID:0000000011219773

### 1.HARNESS CONNECTOR

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

#### **NOTE:**

All harness connectors should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

#### Is the inspection result normal?

YES >> GO TO 2.

NO >> Perform one of the following repairs:

- Visible damage: Replace the harness.
- Loose terminal: Secure the terminal.
- Poor connection: Secure the connection.

### 2.CONFIRM DTC

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

#### Is DTC still current?

YES >> GO TO 3.

NO >> Refer to [GI-42, "Intermittent Incident"](#).

### 3.WIRING HARNESS

Check the wiring harness for visible damage.

#### **NOTE:**

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

#### Is the inspection result normal?

YES >> GO TO 4.

## B1433 LAP PRE-TENSIONER

### < DTC/CIRCUIT DIAGNOSIS >

---

NO >> Replace the harness.

#### 4.CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

#### Is DTC still current?

YES >> GO TO 5.

NO >> Refer to [GI-42, "Intermittent Incident"](#).

#### 5.AIR BAG DIAGNOSIS SENSOR UNIT

---

1. Replace the air bag diagnosis sensor unit. Refer to [SR-29, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

#### Is DTC still current?

YES >> GO TO 6.

NO >> Clear DTC. Inspection End.

#### 6.LAP PRE-TENSIONER RH

---

1. Replace the lap pre-tensioner RH. Refer to [SR-31, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

#### Is DTC still current?

YES >> GO TO 7.

NO >> Clear DTC. Inspection End.

#### 7.RELATED HARNESS

---

Replace the related harness.

>> Inspection End.

# B1434 KNEE AIR BAG MODULE LH

< DTC/CIRCUIT DIAGNOSIS >

## B1434 KNEE AIR BAG MODULE LH

### DTC Description

INFOID:0000000011554391

### DTC DETECTION LOGIC

DTC	CONSULT name	DTC detecting condition		
B1434	KNEE AIR BAG MODULE LH [OPEN]	13	Diagnosis condition	When ignition switch is ON
			Signal (terminal)	Left knee air bag module circuit (terminal 1 and 2)
			Threshold	—
			Diagnosis delay time	—
	KNEE AIR BAG MODULE LH [VB-SHORT]	12	Diagnosis condition	When ignition switch is ON
			Signal (terminal)	Left knee air bag module circuit (terminal 1 and 2)
			Threshold	—
			Diagnosis delay time	—
	KNEE AIR BAG MODULE LH [GND-SHORT]	11	Diagnosis condition	When ignition switch is ON
			Signal (terminal)	Left knee air bag module circuit (terminal 1 and 2)
			Threshold	—
			Diagnosis delay time	—
	KNEE AIR BAG MODULE LH [SHORT]	00	Diagnosis condition	When ignition switch is ON
			Signal (terminal)	Left knee air bag module circuit (terminal 1 and 2)
			Threshold	—
			Diagnosis delay time	—

### POSSIBLE CAUSE

#### [OPEN]

- Connection malfunction or open circuit of harness and connector
- Internal malfunction of left knee air bag module
- Internal malfunction of air bag diagnosis sensor unit

#### [VB-SHORT]

- Connection malfunction or short circuit to power supply of harness and connector
- Internal malfunction of left knee air bag module
- Internal malfunction of air bag diagnosis sensor unit

#### [GND-SHORT]

- Connection malfunction or short circuit to ground of harness and connector
- Internal malfunction of left knee air bag module
- Internal malfunction of air bag diagnosis sensor unit

#### [SHORT]

- Connection malfunction or short circuit of harness and connector
- Internal malfunction of left knee air bag module
- Internal malfunction of air bag diagnosis sensor unit

### DTC CONFIRMATION PROCEDURE (With CONSULT)

#### 1.CHECK SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

#### Is the DTC detected?

YES (Current DTC)>> Refer to [SRC-120, "Diagnosis Procedure"](#).

YES (Past DTC)>> GO TO 2.

NO >> Inspection End.

## B1434 KNEE AIR BAG MODULE LH

### < DTC/CIRCUIT DIAGNOSIS >

---

#### 2. ERASE SELF DIAGNOSTIC RESULT

---

Erase the DTC using CONSULT.

Can the DTC be erased?

YES >> Inspection End.

NO >> Refer to [SRC-120, "Diagnosis Procedure"](#).

#### DTC CONFIRMATION PROCEDURE (Without CONSULT)

##### 1. CHECK SELF DIAGNOSTIC RESULT

---

1. Turn ignition switch ON.

2. Check the air bag warning lamp status. Refer to [SRC-16, "SRS Operation Check"](#).

**NOTE:**

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

Is the DTC detected?

YES >> Refer to [SRC-120, "Diagnosis Procedure"](#).

NO >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000011554392

##### 1. HARNESS CONNECTOR

---

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

**NOTE:**

All harness connectors should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Perform one of the following repairs:

- Visible damage: Replace the harness.
- Loose terminal: Secure the terminal.
- Poor connection: Secure the connection.

##### 2. CONFIRM DTC

---

1. Reconnect all harness connectors.

2. Turn ignition switch ON.

3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 3.

NO >> Refer to [GI-42, "Intermittent Incident"](#).

##### 3. WIRING HARNESS

---

Check the wiring harness for visible damage.

**NOTE:**

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace the harness.

##### 4. CONFIRM DTC

---

1. Reconnect all harness connectors.

2. Turn ignition switch ON.

3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 5.



## B1434 KNEE AIR BAG MODULE LH

### < DTC/CIRCUIT DIAGNOSIS >

NO >> Refer to [GI-42, "Intermittent Incident"](#).

#### 5. AIR BAG DIAGNOSIS SENSOR UNIT

1. Replace the air bag diagnosis sensor unit. Refer to [SR-29, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

##### Is DTC still current?

YES >> GO TO 6.

NO >> Clear DTC. Inspection End.

#### 6. LEFT KNEE AIR BAG MODULE

1. Replace the left knee air bag module. Refer to [SR-20, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

##### Is DTC still current?

YES >> GO TO 7.

NO >> Clear DTC. Inspection End.

#### 7. RELATED HARNESS

Replace the related harness.

>> Inspection End.

A

B

C

D

E

F

G

SRC

I

J

K

L

M

N

O

P

## B1436 ACTIVE VENT

< DTC/CIRCUIT DIAGNOSIS >

### B1436 ACTIVE VENT

#### DTC Description

INFOID:0000000011219774

#### DTC DETECTION LOGIC

DTC	CONSULT name	DTC detecting condition		
B1436	ACTIVE VENT [OPEN]	13	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Active vent circuit is open.
			Threshold	—
			Diagnosis delay time	—
	ACTIVE VENT [VB-SHORT]	12	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Active vent circuit is shorted to power supply circuit.
			Threshold	—
			Diagnosis delay time	—
	ACTIVE VENT [GND-SHORT]	11	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Active vent circuit is shorted to ground.
			Threshold	—
			Diagnosis delay time	—
	ACTIVE VENT [SHORT]	09	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Active vent circuit is shorted to each other.
			Threshold	—
			Diagnosis delay time	—

#### POSSIBLE CAUSE

##### [OPEN]

- Connection malfunction or open circuit of harness and connector
- Internal malfunction of passenger air bag module (active vent)
- Internal malfunction of air bag diagnosis sensor unit

##### [VB-SHORT]

- Connection malfunction or short circuit to power supply of harness and connector
- Internal malfunction of passenger air bag module (active vent)
- Internal malfunction of air bag diagnosis sensor unit

##### [GND-SHORT]

- Connection malfunction or short circuit to ground of harness and connector
- Internal malfunction of passenger air bag module (active vent)
- Internal malfunction of air bag diagnosis sensor unit

##### [SHORT]

- Connection malfunction or short circuit of harness and connector
- Internal malfunction of passenger air bag module (active vent)
- Internal malfunction of air bag diagnosis sensor unit

#### FAIL-SAFE

—

#### DTC CONFIRMATION PROCEDURE (With CONSULT)

##### 1.CHECK SELF DIAGNOSTIC RESULT

## B1436 ACTIVE VENT

### < DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

#### Is the DTC detected?

YES (Current DTC)>> Refer to [SRC-123, "Diagnosis Procedure"](#).  
YES (Past DTC)>> GO TO 2.  
NO >> Inspection End.

### 2.ERASE SELF DIAGNOSTIC RESULT

Erase the DTC using CONSULT.

#### Can the DTC be erased?

YES >> Inspection End.  
NO >> Refer to [SRC-123, "Diagnosis Procedure"](#).

### DTC CONFIRMATION PROCEDURE (Without CONSULT)

#### 1.CHECK SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16, "SRS Operation Check"](#).

#### **NOTE:**

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

#### Is the DTC detected?

YES >> Refer to [SRC-123, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000011219775

SRC

#### 1.HARNESS CONNECTOR

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

#### **NOTE:**

All harness connectors should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

#### Is the inspection result normal?

YES >> GO TO 2.  
NO >> Perform one of the following repairs:

- Visible damage: Replace the harness.
- Loose terminal: Secure the terminal.
- Poor connection: Secure the connection.

#### 2.CONFIRM DTC

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

#### Is DTC still current?

YES >> GO TO 3.  
NO >> Refer to [GI-42, "Intermittent Incident"](#).

#### 3.WIRING HARNESS

Check the wiring harness for visible damage.

#### **NOTE:**

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

#### Is the inspection result normal?

YES >> GO TO 4.  
NO >> Replace the harness.

## B1436 ACTIVE VENT

< DTC/CIRCUIT DIAGNOSIS >

---

### 4.CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 5.

NO >> Refer to [GI-42, "Intermittent Incident"](#).

### 5.AIR BAG DIAGNOSIS SENSOR UNIT

---

1. Replace the air bag diagnosis sensor unit. Refer to [SR-29, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 6.

NO >> Clear DTC. Inspection End.

### 6.FRONT PASSENGER AIR BAG MODULE

---

1. Replace the front passenger air bag module. Refer to [SR-18, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 7.

NO >> Clear DTC. Inspection End.

### 7.RELATED HARNESS

---

Replace the related harness.

>> Inspection End.

# B142A IGNITION VOLTAGE

< DTC/CIRCUIT DIAGNOSIS >

## B142A IGNITION VOLTAGE

### DTC Description

INFOID:0000000011219777

### DTC DETECTION LOGIC

DTC	CONSULT name	DTC detecting condition		
B142A	IGN VOLTAGE [VB-LOW]	00	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Ignition voltage low at air bag diagnosis sensor unit.
			Threshold	—
			Diagnosis delay time	—
	IGN VOLTAGE [VB-HIGH]	00	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	Ignition voltage high at air bag diagnosis sensor unit.
			Threshold	—
			Diagnosis delay time	—

### POSSIBLE CAUSE

#### [VB-LOW]

- Malfunction of battery voltage (low voltage)
- Connection malfunction of harness or connector
- Internal malfunction of air bag diagnosis sensor unit

#### [VB-HIGH]

- Malfunction of battery voltage (high voltage)
- Connection malfunction of harness or connector
- Internal malfunction of air bag diagnosis sensor unit

### FAIL-SAFE

—

### DTC CONFIRMATION PROCEDURE (With CONSULT)

#### 1.CHECK SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

#### Is the DTC detected?

YES (Current DTC)>> Refer to [SRC-126, "Diagnosis Procedure"](#).

YES (Past DTC)>> GO TO 2.

NO >> Inspection End.

#### 2.ERASE SELF DIAGNOSTIC RESULT

Erase the DTC using CONSULT.

#### Can the DTC be erased?

YES >> Inspection End.

NO >> Refer to [SRC-126, "Diagnosis Procedure"](#).

### DTC CONFIRMATION PROCEDURE (Without CONSULT)

#### 1.CHECK SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16, "SRS Operation Check"](#).

# B142A IGNITION VOLTAGE

## < DTC/CIRCUIT DIAGNOSIS >

---

### NOTE:

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

### Is the DTC detected?

- YES >> Refer to [SRC-126. "Diagnosis Procedure"](#).  
NO >> Inspection End.

## Diagnosis Procedure

INFOID:0000000011219778

### 1. HARNESS CONNECTOR

---

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

#### NOTE:

All harness connectors should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

### Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Perform one of the following repairs:
  - Visible damage: Replace the harness.
  - Loose terminal: Secure the terminal.
  - Poor connection: Secure the connection.

### 2. CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

### Is DTC still current?

- YES >> GO TO 3.  
NO >> Refer to [GI-42. "Intermittent Incident"](#).

### 3. WIRING HARNESS

---

Check the wiring harness for visible damage.

#### NOTE:

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

### Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Replace the harness.

### 4. CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

### Is DTC still current?

- YES >> GO TO 5.  
NO >> Refer to [GI-42. "Intermittent Incident"](#).

### 5. AIR BAG DIAGNOSIS SENSOR UNIT

---

1. Replace the air bag diagnosis sensor unit. Refer to [SR-29. "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

### Is DTC still current?

- YES >> GO TO 6.  
NO >> Clear DTC. Inspection End.

### 6. RELATED HARNESS

---

Replace the related harness.

## B142A IGNITION VOLTAGE

< DTC/CIRCUIT DIAGNOSIS >

---

>> Inspection End.

A

B

C

D

E

F

G

SRC

I

J

K

L

M

N

O

P

## B1427 CONFIG SETTING

< DTC/CIRCUIT DIAGNOSIS >

### B1427 CONFIG SETTING

#### DTC Description

INFOID:0000000011506344

#### DTC DETECTION LOGIC

DTC	CONSULT name		DTC detecting condition	
B1427	ECU SETTING (Configuration setting)	55	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	—
			Threshold	—
			Diagnosis delay time	—

#### POSSIBLE CAUSE

When air bag diagnosis unit is replaced.

#### FAIL-SAFE

—

#### Diagnosis Procedure

INFOID:0000000011506345

#### 1.PERFORM CONFIGURATION

Perform configuration for air bag diagnosis sensor unit.

>> Refer to [SRC-44, "CONFIGURATION : Work Procedure"](#).



# B1400, B1401, B1402, B1403, B1404, B1405 AIR BAG DIAGNOSIS SENSOR UNIT

< DTC/CIRCUIT DIAGNOSIS >

## B1400, B1401, B1402, B1403, B1404, B1405 AIR BAG DIAGNOSIS SENSOR UNIT

### DTC Description

INFOID:0000000011492101

### DTC DETECTION LOGIC

DTC	CONSULT name	DTC detecting condition	
B1400–	CONTROL UNIT [UNIT MALFUNC]	00	Diagnosis condition
			When ignition switch is ON.
			Signal (terminal)
			—
B1401–	CONTROL UNIT [UNIT MALFUNC]	00	Threshold
			—
			Diagnosis delay time
			—
B1402–	CONTROL UNIT [UNIT MALFUNC]	00	Diagnosis condition
			When ignition switch is ON.
			Signal (terminal)
			—
B1403–	CONTROL UNIT [UNIT MALFUNC]	00	Threshold
			—
			Diagnosis delay time
			—
B1404–	CONTROL UNIT [UNIT MALFUNC]	00	Diagnosis condition
			When ignition switch is ON.
			Signal (terminal)
			—
B1405–	CONTROL UNIT [UNIT MALFUNC]	00	Threshold
			—
			Diagnosis delay time
			—

### POSSIBLE CAUSE

Malfunction in air bag diagnosis sensor unit

### FAIL-SAFE

—

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK SELF DIAGNOSTIC RESULT

##### With CONSULT

1. Turn ignition switch ON.
2. Perform "Self Diagnostic Result" of "AIR BAG" using CONSULT.

##### Without CONSULT

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16, "SRS Operation Check"](#).

#### NOTE:

SRS does not enter the diagnosis mode if no malfunction is detected in the user mode.

Is malfunctioning part detected?

# B1400, B1401, B1402, B1403, B1404, B1405 AIR BAG DIAGNOSIS SENSOR UNIT

## < DTC/CIRCUIT DIAGNOSIS >

---

- YES >> Refer to [SRC-130. "Diagnosis Procedure"](#).  
NO-1 >> To check malfunction symptom before repair: Refer to [GI-42. "Intermittent Incident"](#).  
NO-2 >> Confirmation after repair: Inspection End.

## Diagnosis Procedure

INFOID:0000000011492102

### **WARNING:**

- Before servicing, turn ignition switch OFF, disconnect battery negative terminal, and wait at least 3 minutes or more. (to discharge backup capacitor)
- Never use an unspecified tester or other measuring device.

### 1. CHECK HARNESS CONNECTOR

---

Check the harness connector for disconnection, looseness or damage.

#### Is the inspection result normal?

- YES >> GO TO 2.  
NO-1 >> Damage: Replace malfunctioning harness and connector.  
NO-2 >> Disconnection or looseness: Securely lock the connector.

### 2. CHECK WIRING HARNESS

---

Check the wiring harness externals.

#### Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Replace malfunctioning harness and connector.

### 3. REPLACE AIR BAG DIAGNOSIS SENSOR UNIT

---

1. Replace air bag diagnosis sensor unit. Refer to [SR-29. "Removal and Installation"](#).
2. Perform DTC confirmation procedure. Refer to [SRC-129. "DTC Description"](#).

#### Is DTC detected?

- YES >> GO TO 1.  
NO >> Inspection End.

# B1406, B1407, B1408, B1409, B1410 AIR BAG DIAGNOSIS SENSOR UNIT

< DTC/CIRCUIT DIAGNOSIS >

## B1406, B1407, B1408, B1409, B1410 AIR BAG DIAGNOSIS SENSOR UNIT

### DTC Description

INFOID:0000000011492103

### DTC DETECTION LOGIC

DTC	CONSULT screen items (Trouble diagnosis content)	DTC detecting condition		
B1406	CONTROL UNIT [UNIT MALFUNC]	00	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	—
			Threshold	—
			Diagnosis delay time	—
B1407	CONTROL UNIT [UNIT MALFUNC]	00	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	—
			Threshold	—
			Diagnosis delay time	—
B1408	CONTROL UNIT [UNIT MALFUNC]	00	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	—
			Threshold	—
			Diagnosis delay time	—
B1409	CONTROL UNIT [UNIT MALFUNC]	00	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	—
			Threshold	—
			Diagnosis delay time	—
B1410	CONTROL UNIT [UNIT MALFUNC]	00	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	—
			Threshold	—
			Diagnosis delay time	—

### POSSIBLE CAUSE

Malfunction in air bag diagnosis sensor unit

### FAIL-SAFE

—

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK SELF DIAGNOSIS RESULT

##### With CONSULT

1. Turn ignition switch ON.
2. Perform "Self Diagnostic Result" of "AIR BAG" using CONSULT.

##### Without CONSULT

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16, "SRS Operation Check"](#).

#### NOTE:

SRS does not enter the diagnosis mode if no malfunction is detected in the user mode.

#### Is malfunctioning part detected?

YES >> Refer to [SRC-132, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-42, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

# B1406, B1407, B1408, B1409, B1410 AIR BAG DIAGNOSIS SENSOR UNIT

< DTC/CIRCUIT DIAGNOSIS >

## Diagnosis Procedure

INFOID:0000000011492104

### **WARNING:**

- Before servicing, turn ignition switch OFF, disconnect battery negative terminal, and wait at least 3 minutes or more (to discharge backup capacitor).
- Never use an unspecified tester or other measuring device.

### **1.**CHECK HARNESS CONNECTOR

Check the harness connector for disconnection, looseness or damage.

Is the inspection result normal?

YES >> GO TO 2.

NO-1 >> Damage: Replace malfunctioning harness and connector.

NO-2 >> Disconnection or looseness: Securely lock the connector.

### **2.**CHECK WIRING HARNESS

Check the wiring harness externals.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace malfunctioning harness and connector.

### **3.**REPLACE AIR BAG DIAGNOSIS SENSOR UNIT

1. Replace air bag diagnosis sensor unit. Refer to [SR-29, "Removal and Installation"](#).

2. Perform DTC confirmation procedure. Refer to [SRC-131, "DTC Description"](#).

Is DTC detected?

YES >> GO TO 1.

NO >> Inspection End.

# B1411, B1412, B1413, B1414, B1415 AIR BAG DIAGNOSIS SENSOR UNIT

< DTC/CIRCUIT DIAGNOSIS >

## B1411, B1412, B1413, B1414, B1415 AIR BAG DIAGNOSIS SENSOR UNIT

### DTC Description

INFOID:0000000011492105

### DTC DETECTION LOGIC

DTC	CONSULT name	DTC detecting condition	
B1411	CONTROL UNIT [UNIT MALFUNC]	00	Diagnosis condition
			When ignition switch is ON.
			Signal (terminal)
			—
B1412	CONTROL UNIT [UNIT MALFUNC]	00	Diagnosis condition
			When ignition switch is ON.
			Signal (terminal)
			—
B1413	CONTROL UNIT [UNIT MALFUNC]	00	Diagnosis condition
			When ignition switch is ON.
			Signal (terminal)
			—
B1414	CONTROL UNIT [UNIT MALFUNC]	00	Diagnosis condition
			When ignition switch is ON.
			Signal (terminal)
			—
B1415	CONTROL UNIT [UNIT MALFUNC]	00	Diagnosis condition
			When ignition switch is ON.
			Signal (terminal)
			—

### POSSIBLE CAUSE

Malfunction in air bag diagnosis sensor unit

### FAIL-SAFE

—

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK SELF DIAGNOSTIC RESULT

##### ④ With CONSULT

1. Turn ignition switch ON.
2. Perform "Self Diagnostic Result" of "AIR BAG" using CONSULT.

##### ④ Without CONSULT

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16, "SRS Operation Check"](#).

##### NOTE:

SRS does not enter the diagnosis mode if no malfunction is detected in the user mode.

##### Is malfunctioning part detected?

- YES >> Refer to [SRC-133, "Diagnosis Procedure"](#).  
NO-1 >> To check malfunction symptom before repair: Refer to [GI-42, "Intermittent Incident"](#).  
NO-2 >> Confirmation after repair: Inspection End.

### Diagnosis Procedure

INFOID:0000000011492106

### WARNING:

## B1411, B1412, B1413, B1414, B1415 AIR BAG DIAGNOSIS SENSOR UNIT

### < DTC/CIRCUIT DIAGNOSIS >

---

- Before servicing, turn ignition switch OFF, disconnect battery negative terminal, and wait at least 3 minutes or more. (to discharge backup capacitor).
- Never use unspecified tester or other measuring device.

#### 1. CHECK HARNESS CONNECTOR

---

Check the harness connector for disconnection, looseness or damage.

##### Is the inspection result normal?

- YES >> GO TO 2.  
NO-1 >> Damage: Replace malfunctioning harness and connector.  
NO-2 >> Disconnection or looseness: Securely lock the connector.

#### 2. CHECK WIRING HARNESS

---

Check the wiring harness externals.

##### Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Replace malfunctioning harness and connector.

#### 3. REPLACE AIR BAG DIAGNOSIS SENSOR UNIT

---

1. Replace air bag diagnosis sensor unit. Refer to [SR-29, "Removal and Installation"](#).
2. Perform DTC confirmation procedure. Refer to [SRC-133, "DTC Description"](#).

##### Is DTC detected?

- YES >> GO TO 1.  
NO >> Inspection End.

# B1416, B1417, B1418, B1419, B1420 AIR BAG DIAGNOSIS SENSOR UNIT

< DTC/CIRCUIT DIAGNOSIS >

## B1416, B1417, B1418, B1419, B1420 AIR BAG DIAGNOSIS SENSOR UNIT

### DTC Description

INFOID:0000000011492107

### DTC DETECTION LOGIC

DTC	CONSULT screen items (Trouble diagnosis content)	DTC detecting condition	
B1416	CONTROL UNIT [UNIT MALFUNC]	00	Diagnosis condition
			When ignition switch is ON.
			Signal (terminal)
			Air bag control unit internal trouble, EEPROM
B1417	CONTROL UNIT [UNIT MALFUNC]	00	Threshold
			—
			Diagnosis delay time
			—
B1418	CONTROL UNIT [UNIT MALFUNC]	00	Diagnosis condition
			When ignition switch is ON.
			Signal (terminal)
			Air bag control unit internal trouble, Configuration
B1419	CONTROL UNIT [UNIT MALFUNC]	00	Threshold
			—
			Diagnosis delay time
			—
B1420	CONTROL UNIT [UNIT MALFUNC]	00	Diagnosis condition
			When ignition switch is ON.
			Signal (terminal)
			Air bag control unit internal trouble, other component
B1420	CONTROL UNIT [UNIT MALFUNC]	00	Threshold
			—
			Diagnosis delay time
			—

### POSSIBLE CAUSE

Malfunction in air bag diagnosis sensor unit

### FAIL-SAFE

—

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK SELF DIAGNOSTIC RESULT

 With CONSULT

1. Turn ignition switch ON.
2. Perform "Self Diagnostic Result" of "AIR BAG" using CONSULT.

 Without CONSULT

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16, "SRS Operation Check"](#).

#### NOTE:

SRS does not enter the diagnosis mode if no malfunction is detected in the user mode.

#### Is malfunctioning part detected?

- YES >> Refer to [SRC-136, "Diagnosis Procedure"](#).  
NO-1 >> To check malfunction symptom before repair: Refer to [GI-42, "Intermittent Incident"](#).  
NO-2 >> Confirmation after repair: Inspection End.

# B1416, B1417, B1418, B1419, B1420 AIR BAG DIAGNOSIS SENSOR UNIT

< DTC/CIRCUIT DIAGNOSIS >

## Diagnosis Procedure

INFOID:0000000011492108

### **WARNING:**

- Before servicing, turn ignition switch OFF, disconnect battery negative terminal, and wait at least 3 minutes or more (to discharge backup capacitor).
- Never use an unspecified tester or other measuring device.

### **1.**CHECK HARNESS CONNECTOR

Check the harness connector for disconnection, looseness or damage.

Is the inspection result normal?

YES >> GO TO 2.

NO-1 >> Damage: Replace malfunctioning harness and connector.

NO-2 >> Disconnection or looseness: Securely lock the connector.

### **2.**CHECK WIRING HARNESS

Check the wiring harness externals.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace malfunctioning harness and connector.

### **3.**REPLACE AIR BAG DIAGNOSIS SENSOR UNIT

1. Replace air bag diagnosis sensor unit. Refer to [SR-29, "Removal and Installation"](#).

2. Perform DTC confirmation procedure. Refer to [SRC-135, "DTC Description"](#).

Is DTC detected?

YES >> GO TO 1.

NO >> Inspection End.



# B142X COLLISION DETECTION

< DTC/CIRCUIT DIAGNOSIS >

## B142X COLLISION DETECTION

### DTC Description

INFOID:0000000011219780

### DTC DETECTION LOGIC

DTC	CONSULT name	DTC detecting condition		
B1421	FRONTAL COLLISION DETECTION	00	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	—
			Threshold	—
			Diagnosis delay time	—
B1422	SIDE COLLISION DETECTION	00	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	—
			Threshold	—
			Diagnosis delay time	—
B1423	ROLLOVER DETECTION	00	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	—
			Threshold	—
			Diagnosis delay time	—
B1425	REAR COLLISION	00	Diagnosis condition	When ignition switch is ON.
			Signal (terminal)	—
			Threshold	—
			Diagnosis delay time	—

### POSSIBLE CAUSE

[B1421-00]

- Malfunction of frontal-related parts
- Internal malfunction of air bag diagnosis sensor unit

[B1422-00]

- Malfunction of side-related parts
- Internal malfunction of air bag diagnosis sensor unit

[B1423-00]

- B1423—Malfunction of side-related parts
- Internal malfunction of air bag diagnosis sensor unit

[B1425-00]

- B1425—Malfunction of rear-related parts
- Internal malfunction of air bag diagnosis sensor unit

### FAIL-SAFE

—

### DTC CONFIRMATION PROCEDURE (With CONSULT)

#### 1.INSPECTION START

Turn ignition switch ON.

>> GO TO 2.

#### 2.CHECK SELF DIAGNOSTIC RESULT

Check for the DTC on CONSULT.

## B142X COLLISION DETECTION

< DTC/CIRCUIT DIAGNOSIS >

---

Is the DTC detected?

YES >> Refer to [SRC-138, "Diagnosis Procedure"](#).

NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000011219781

Refer to [SR-5, "For Frontal Collision"](#) or [SR-7, "For Side and Rollover Collision"](#).

# B14XX AIR BAG DIAGNOSIS SENSOR UNIT

< DTC/CIRCUIT DIAGNOSIS >

## B14XX AIR BAG DIAGNOSIS SENSOR UNIT

### DTC Description

INFOID:0000000011219783

### DTC DETECTION LOGIC

DTC	CONSULT name	DTC detecting condition	
B14XX	AIRBAG DISPOSAL COMPLETION	Diagnosis condition	When ignition switch is ON.
		Signal (terminal)	Air bag diagnosis sensor unit is malfunctioning.
		Threshold	—
		Diagnosis delay time	—
B1426	AIRBAG DISPOSAL DETECT	Diagnosis condition	When ignition is ON.
		Signal (terminal)	Air bag diagnosis sensor unit is malfunctioning.
		Threshold	—
		Diagnosis delay time	—

### POSSIBLE CAUSE

- Air bag module has been deployed
- Internal malfunction of air bag diagnosis sensor unit

### FAIL-SAFE

—

SRC

### DTC CONFIRMATION PROCEDURE (With CONSULT)

#### 1.CHECK SELF DIAGNOSIS RESULT

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

##### Is the DTC detected?

YES (Current DTC)>> Refer to [SRC-139, "Diagnosis Procedure"](#).

YES (Past DTC)>> GO TO 2.

NO >> Inspection End.

#### 2.ERASE SELF DIAGNOSIS RESULT

Erase the DTC using CONSULT.

##### Can the DTC be erased?

YES >> Inspection End.

NO >> Refer to [SRC-139, "Diagnosis Procedure"](#).

### DTC CONFIRMATION PROCEDURE (Without CONSULT)

#### 1.CHECK SELF DIAGNOSIS RESULT

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-16, "SRS Operation Check"](#).

##### **NOTE:**

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

##### Is the DTC detected?

YES >> Refer to [SRC-139, "Diagnosis Procedure"](#).

NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000011219784

#### 1.HARNESS CONNECTOR

Visually inspect all applicable harness connectors for the following:

## B14XX AIR BAG DIAGNOSIS SENSOR UNIT

### < DTC/CIRCUIT DIAGNOSIS >

---

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

**NOTE:**

All harness connectors should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

Is the inspection result normal?

YES >> GO TO 2.

- NO >> Perform one of the following repairs:
- Visible damage: Replace the harness.
  - Loose terminal: Secure the terminal.
  - Poor connection: Secure the connection.

## 2.CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 3.

NO >> Refer to [GI-42, "Intermittent Incident"](#).

## 3.WIRING HARNESS

---

Check the wiring harness for visible damage.

**NOTE:**

The entire wiring harness should be inspected from the air bag diagnosis sensor unit to the end component (including any in-line connectors).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace the harness.

## 4.CONFIRM DTC

---

1. Reconnect all harness connectors.
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 5.

NO >> Refer to [GI-42, "Intermittent Incident"](#).

## 5.AIR BAG DIAGNOSIS SENSOR UNIT

---

1. Replace the air bag diagnosis sensor unit. Refer to [SR-29, "Removal and Installation"](#).
2. Turn ignition switch ON.
3. Check for DTC using CONSULT.

Is DTC still current?

YES >> GO TO 6.

NO >> Clear DTC. Inspection End.

## 6.RELATED HARNESS

---

Replace the related harness.

>> Inspection End.

# SRS AIR BAG WARNING LAMP DOES NOT TURN ON

< SYMPTOM DIAGNOSIS >

## SYMPTOM DIAGNOSIS

### SRS AIR BAG WARNING LAMP DOES NOT TURN ON

Air Bag Warning Lamp Does Not Turn On

INFOID:0000000011219785

#### 1.CHECK METER FUSE

Check the 10A fuse [No. 13, located in the fuse block (J/B)].

Is the fuse blown?

YES >> GO TO 2.

NO >> GO TO 3.

#### 2.REPLACE METER FUSE AND CHECK AGAIN

Replace 10A fuse [No. 13, located in the fuse block (J/B)] and turn ignition switch ON.

Does the fuse blow again?

YES >> Replace fuse and harness.

NO >> Inspection End.

#### 3.CHECK HARNESS CONNECTIONS BETWEEN AIR BAG DIAGNOSIS SENSOR UNIT AND COMBINATION METER

Inspect the harness and connectors between the air bag diagnosis sensor unit and the combination meter.

Do the harness or connectors have any visible damage?

YES >> Replace harness.

NO >> GO TO 4.

#### 4.CHECK COMBINATION METER

Disconnect the air bag diagnosis sensor unit harness connectors and turn ignition switch ON.

Does air bag warning lamp turn on?

YES >> Replace the air bag diagnosis sensor unit. Refer to [SR-29, "Removal and Installation"](#).

NO >> Replace the combination meter. Refer to [MWI-78, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

SRC

# SRS AIR BAG WARNING LAMP DOES NOT TURN OFF

< SYMPTOM DIAGNOSIS >

---

## SRS AIR BAG WARNING LAMP DOES NOT TURN OFF

### Air Bag Warning Lamp Does Not Turn Off

INFOID:0000000011219786

#### 1.CHECK CONDITION OF AIR BAG MODULE

---

Inspect for any deployed air bag modules or seat belt pre-tensioners.

Are any air bag modules or seat belt pre-tensioners deployed?

YES >> Refer to [SR-5. "For Frontal Collision"](#) or [SR-7. "For Side and Rollover Collision"](#).

NO >> GO TO 2.

#### 2.CHECK THE AIR BAG FUSE

---

Check 10A fuse [No. 32, located in the fuse block (J/B)].

Is the fuse blown?

YES >> GO TO 3.

NO >> GO TO 4.

#### 3.CHECK AIR BAG FUSE AGAIN

---

Replace 10A fuse [No. 32, located in the fuse block (J/B)] and turn ignition switch ON.

Does the fuse blow again?

YES >> Replace fuse and harness.

NO >> Inspection End.

#### 4.CHECK AIR BAG DIAGNOSIS SENSOR UNIT

---

Connect CONSULT.

Is "AIR BAG" displayed on CONSULT?

YES >> GO TO 5.

NO >> Visually inspect the air bag diagnosis sensor unit harness connections. If the connections are OK, replace the air bag diagnosis sensor unit. Refer to [SR-29. "Removal and Installation"](#).

#### 5.CHECK HARNESS CONNECTION

---

Check for loose connections between the combination meter and the air bag diagnosis sensor unit.

Are there any loose connections?

YES >> Properly connect the combination meter and air bag diagnosis sensor unit harness connectors. If air bag warning lamp still does not turn off, replace the wiring harness.

NO >> Replace air bag diagnosis sensor unit. Refer to [SR-29. "Removal and Installation"](#).

# SEAT BELT WARNING SYSTEM

< SYMPTOM DIAGNOSIS >

## SEAT BELT WARNING SYSTEM

### Seat Belt Warning System Does Not Function

INFOID:0000000011219787

#### 1. SEAT BELT WARNING LIGHT

Turn ignition switch ON.

Does the seat belt warning lamp come ON?

YES >> GO TO 2.

- NO >> • Check 10A fuse [No. 13, located in the fuse block (J/B)].  
• Check seat belt buckle switch LH.  
• Check harness between combination meter and seat belt buckle switch LH.  
• Check combination meter. Refer to [MWI-28, "Fail-safe"](#).

#### 2. SEAT BELT BUCKLE LH

Fasten the seat belt buckle LH.

Does the seat belt warning lamp go OFF?

YES >> GO TO 3.

- NO >> • Check seat belt buckle switch LH.  
• Check harness between combination meter and seat belt buckle switch LH.

#### 3. OCCUPANT CLASSIFICATION SYSTEM

Have a helper sit in the passenger seat.

Does the seat belt warning lamp go ON?

YES >> GO TO 4.

- NO >> • Check occupant classification system. Refer to [SRC-13, "OCCUPANT CLASSIFICATION SYSTEM : System Description"](#).  
• Check harness between occupant classification control unit and air bag diagnosis sensor unit.

#### 4. SEAT BELT BUCKLE RH

Fasten the seat belt buckle RH.

Does the seat belt warning lamp go OFF?

YES >> System OK.

- NO >> • Check seat belt buckle switch RH.  
• Check harness between seat belt buckle switch RH and air bag diagnosis sensor unit.  
• Replace air bag diagnosis sensor unit. Refer to [SR-29, "Removal and Installation"](#).

## A/B WARNING LAMP IS OFF, PASS A/B INDCTR LAMP TURNS ON INTERMIT

< SYMPTOM DIAGNOSIS >

### A/B WARNING LAMP IS OFF, PASS A/B INDCTR LAMP TURNS ON INTERMIT

#### Description

INFOID:0000000011734958

SRS air bag warning lamp is OFF, passenger air bag indicator lamp turns ON intermittently with a person of adult stature seated normally in the passenger seat.

#### Diagnosis Procedure

INFOID:0000000011734959

#### 1.REPLACE OCS SENSORS

1. Replace the OCS sensors. Refer to [SR-33. "Removal and Installation"](#).
2. Perform zero point reset. Refer to [SRC-44. "ZERO POINT RESET : Description"](#).

Is symptom still present?

YES >> GO TO 2.

NO >> Inspection End.

#### 2.REPLACE PASSENGER SEAT CUSHION FRAME

1. Replace the passenger seat cushion frame. Refer to [SE-164. "Seat Cushion"](#).
2. Perform zero point reset. Refer to [SRC-44. "ZERO POINT RESET : Description"](#).

>> Inspection End.



# SEAT BELT INDCTR LAMP IS ON, PASS AIR BAG INDCTR IS ON OR OFF

< SYMPTOM DIAGNOSIS >

## SEAT BELT INDCTR LAMP IS ON, PASS AIR BAG INDCTR IS ON OR OFF

### Description

INFOID:0000000011734960

Vehicle conditions:

- Seat belt indicator lamp is ON, passenger air bag indicator lamp is ON or OFF
- Passenger seat is unoccupied
- Driver seat belt is buckled
- Passenger seat belt buckle harness and seat belt buckle switch are OK (buckle passenger seat belt to check if seat belt indicator lamp turns OFF, driver seat belt needs to be buckled)

### Diagnosis Procedure

INFOID:0000000011734961

#### 1.REPLACE OCS SENSORS

1. Replace the OCS sensors. Refer to [SR-33. "Removal and Installation"](#).
2. Perform zero point reset. Refer to [SRC-44. "ZERO POINT RESET : Description"](#).

Is symptom still present?

YES >> GO TO 2.

NO >> Inspection End.

#### 2.REPLACE PASSENGER SEAT CUSHION FRAME

1. Replace the passenger seat cushion frame. Refer to [SE-164. "Seat Cushion"](#).
2. Perform zero point reset. Refer to [SRC-44. "ZERO POINT RESET : Description"](#).

>> Inspection End.

SRC